


PCL11-A,B

PCL11 EXERCISER V020
CZPLAB0

AH-E260B-MC
COPYRIGHT © 1978
FICHE 1 OF 1

DEC 1978
digital
MADE IN USA



I D E N T I F I C A T I O N

SEQ 0001

PROGRAM CODE: AC-E259B-MC
PROGRAM NAME: CZPLAB0 PCL11 EXERCISER V-02A
VERSION: V-02
DATE CREATED: 21-SEP-76
UPDATED: 13-MAR-78
MODIFIED: 11-SEP-78
MAINTAINER: SPECIAL SYSTEMS, KANATA
AUTHOR: DAVID G. WIENS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1978, BY DIGITAL EQUIPMENT OF CANADA, LIMITED.

	TABLE OF CONTENTS	PAGE
	-----	----
1	GENERAL	1-1
1.1	GENERAL DESCRIPTION	1-1
1.2	DIFFERENCES IN EXERCISER V-02	1-2
2	EXERCISER TABLES	2-1
2.1	STATUS TABLE	2-1
2.2	SUMMARY TABLE	2-2
2.3	ERRORS TABLES	2-3
2.4	CLEARING OF THE TABLES	2-4
3	EXERCISER COMMANDS	3-1
3.1	CONTROL CHARACTERS	3-1
3.1.1	CONTROL-C	3-1
3.1.2	CONTROL-O	3-1
3.1.3	CONTROL-U	3-1
3.1.4	CONTROL-S	3-2
3.1.5	CONTROL-Q	3-2
3.1.6	CARRIAGE RETURN	3-2
3.1.7	LINE FEED	3-2
3.1.8	RUBOUT	3-2
3.2	COMMANDS	3-3
3.2.1	SILO	3-3
3.2.2	MASTER	3-4
3.2.3	SECONDARY	3-4
3.2.4	RIB	3-5
3.2.5	RANGE	3-5
3.2.6	ADD	3-6
3.2.7	DELETE	3-6
3.2.8	CLEAR	3-7
3.2.9	INITIALIZE	3-7
3.2.10	STATUS	3-8
3.2.11	SUMMARY	3-8
3.2.12	ERRORS	3-8
3.2.13	ASSIGN	3-9
3.2.14	GO	3-10
3.2.15	CONTINUE	3-10
3.2.16	**SYNTAX ERROR**	3-11
4	GETTING THE EXERCISER STARTED	4-1
4.1	PREPARATION	4-1
4.2	LOADING	4-1
4.3	DEVICE ADDRESSES	4-1
4.4	STARTING ADDRESSES	4-2
4.5	OPERATING PROCEDURES	4-2
4.6	ERRORS	4-3

TABLE OF CONTENTS (CONTD)

	PAGE
-----	----
5 COMMAND INPUT MODE DESCRIPTION	5-1
5.1 SHORTENED COMMANDS	5-1
5.2 RUBOUT FEATURES	5-1
5.3 ENTERING COMMAND MODE	5-1
5.4 UPPER OR LOWER CASE	5-2
6 EXERCISE MODE DESCRIPTION	6-1
6.1 TRANSMIT EVENT	6-1
6.2 RECEIVE EVENT	6-1
6.3 DATA GENERATION EVENT	6-1
6.4 ADDRESS QUEUE EVENT	6-2
6.5 ERRORS UPDATE EVENT	6-2
6.6 SPECIAL EVENTS	6-2
APPENDIX A	
EXERCISER OVERALL FLOW	A-1
APPENDIX B	
EXERCISER COMMANDS	B-1
APPENDIX C	
ERROR DESCRIPTIONS	C-1
APPENDIX D	
STATISTICAL INFORMATION	D-1
LISTING...	

PARALLEL COMMUNICATIONS LINK
EXERCISER PROGRAM

1 GENERAL

1.1 GENERAL DESCRIPTION

THE PDP-11 PARALLEL COMMUNICATIONS LINK (PCL11) EXERCISER IS WRITTEN TO EXERCISE A FULL SET OR PARTIAL SET OF PCL11 UNITS, EACH ON ITS OWN PDP-11. THE MAXIMUM NUMBER OF UNITS (FULL SET) WHICH MAY BE EXERCISED IS 31, ALTHOUGH THE NORMAL MAXIMUM CONFIGURATION INCLUDES ONLY 16 PCL11'S. THE MINIMUM NUMBER OF UNITS IS 1.

THE EXERCISER IS OPERATED BY MEANS OF THE OPERATOR ENTERING COMMANDS AT EACH PDP-11 CONSOLE TERMINAL WHICH WILL DESCRIBE TO THE EXERCISER THE NUMBER OF TARGET RECEIVERS TO BE COMMUNICATED WITH AND THEIR T.D.M. BUS ADDRESSES. STATUS AND ERROR REPORTS ARE ACHIEVED ALSO IN RESPONSE TO OPERATOR COMMANDS.

EACH PCL11 TRANSMITTER IN THE 'CHAIN' OF PDP-11'S MUST BE TOLD HOW MANY OF THE RECEIVERS IN THE 'CHAIN' IT SHOULD SEND DATA TO. THEN, UPON THE OPERATOR'S COMMAND, EACH PCL11 TRANSMITTER INVOLVED WILL BEGIN SENDING RANDOM DATA PATTERNS TO EACH RECEIVER IT HAS BEEN TOLD TO COMMUNICATE WITH.

RECEIVERS IN THE CHAIN ARE ALWAYS RECEPTIVE TO DATA FROM ANY ONE TRANSMITTER AT A TIME AND WILL CHECK THAT THE DATA RECEIVED IS CORRECT. THE RECEIVER HANDLER PORTION OF THE EXERCISER WILL ALSO GENERATE A TABLE OF ERRORS THAT MAY BE EXAMINED UPON ISSUANCE OF THE 'ERRORS' COMMAND.

TRANSMITTERS IN THE CHAIN ARE ACTIVATED OR DE-ACTIVATED BY THE OPERATOR AND ARE DE-ACTIVATED BY A 'MASTER-DOWN' ERROR OR A UNIBUS TIMEOUT (TRAP TO 4). THE TRANSMITTER HANDLER PORTION OF THE EXERCISER WILL LOOK AFTER THE TRANSMISSION OF RANDOM DATA TO EACH RECEIVER ON ITS 'LIST' AND GENERATE A STATUS TABLE AND AN ERROR TABLE. THE STATUS TABLE WILL INFORM THE OPERATOR OF THE SUCCESS OR FAILURE OF THAT TRANSMITTER TO COMMUNICATE WITH EACH OF THE RECEIVERS ON ITS LIST. THE ERROR TABLE WILL SHOW THE OPERATOR ANY HARDWARE ERRORS ENCOUNTERED DURING COMMUNICATION.

A SPECIAL 'SUMMARY' COMMAND WILL GIVE A CONDENSED ERROR TABLE INDICATING ONLY THE ERROR NUMBER, THE ADDRESS IN THE LISTING OF THE ERROR, AND THE TOTAL NUMBER OF OCCURRENCES OF THAT ERROR WITHOUT REGARD TO WHICH RECEIVER AND TRANSMITTER WERE CONNECTED.

1.2 DIFFERENCES IN EXERCISER V-02

-
- 1.2.1 STARTING AND RESTARTING (SEE SEC. 4.4)
V-02 OF THE EXERCISER STARTS AT LOCATION 200. WHEN RESTARTED AT LOCATION 204, THE STATUS AND ERRORS ARE PRESERVED.
- 1.2.2 UPPER/LOWER CASE INPUT (SEE SEC.5.4)
EITHER UPPER OR LOWER CASE ALPHA CHARACTERS ARE ACCEPTED BY V-02 OF THE EXERCISER. WHICHEVER IS TYPED IN, THE UPPER CASE VERSION IS ECHOED.
- 1.2.3 ERRORS COMMAND (SEE SEC.3.2.12)
THE 'ERRORS' COMMAND HAS BEEN ADDED TO THE EXERCISER TO GIVE MORE DETAIL ABOUT THE ERROR CONDITIONS.
- 1.2.4 RIB COMMAND (SEE SEC. 3.2.4)
THE 'RIB' COMMAND HAS BEEN ADDED TO THE EXERCISER TO ALLOW RUNNING IN A RE-TRY - IF - BUSY MODE, WHICH BRINGS THE ATTEMPTS AND SUCCESSES COUNTS MORE IN LINE.
- 1.2.5 ASSIGN COMMAND (SEE SEC. 3.2.13)
THE 'ASSIGN' COMMAND WAS ADDED TO ALLOW CONSOLE CHANGING OF THE PCL11 UNIBUS ADDRESSES AND VECTORS WITHIN THE EXERCISER.
- 1.2.6 GO COMMAND (SEE SEC.3.2.14)
THE 'GO' COMMAND HAS BEEN ALTERED SO THAT THE RECEIVER ADDRESS QUEUE, STATUS OF ATTEMPTS AND SUCCESSES, AND THE ERROR TABLE ARE ALL CLEARED.
- 1.2.7 ADDRESS QUEUE EVENT (SEE SEC. 6.4)
THIS EVENT WAS CHANGED SO THAT IF THE EXERCISER WAS TOLD TO 'GO' OR 'CONTINUE', AND NOTHING WAS LOADED INTO THE 'RECEIVER ADDRESS QUEUE', THE EXERCISER WOULD NOT GO.
- 1.2.8 LOADING OF THE SILO (SEE SEC. 3.2.1)
IN THE PREVIOUS EXERCISER, THE SILO COULD BE LOADED IN SUCH A WAY AS TO CAUSE 'HARD TO TRACE' HARDWARE ERROR INDICATIONS. NOW A 'PAD' VALUE HAS BEEN INSERTED BETWEEN SIMILAR ENTRIES SO THAT THIS CANNOT HAPPEN.
- 1.2.9 NEW CONTROL CHARACTERS (SEE SEC. 3.1)
V-02 OF THE EXERCISER HAS THROWN OUT THE 'ESCAPE/ALTMODE' CHARACTER IN FAVOUR OF 'CNTRL-C'. ALSO, CNTRL-S AND CNTRL-Q WERE ADDED TO CONTROL THE PRINTOUT ON VIDEO TERMINALS.
- 1.2.10 CARRIAGE RETURN (SEE SEC. 3.1.6)
THIS VERSION OF THE EXERCISER WILL NOT GO INTO 'LIMBO' IF A CARRIAGE RETURN IS ENTERED BY ITSELF. IT SIMPLY ECHOES ANOTHER \$.
- 1.2.11 RUBOUT (SEE SEC. 3.1.8)
THE EXERCISER WILL NOW INDICATE WHEN ALL HAS BEEN RUBBED OUT BY RETURNING A <CR-LF> AND '\$' WHEN THE COMMAND INPUT BUFFER IS EMPTY.

1.2.12 STATUS TABLE (SEE SEC. 2.1)
THE 'ATTEMPTS' AND 'SUCCESSSES' COUNTS IN THE STATUS TABLE HAVE BEEN BEEFED UP TO DOUBLE PRECISION DECIMAL NUMBERS. ALSO, AN INDICATION HAS BEEN ADDED TO THE TABLE OF WHETHER THE UNIT IS MASTER OR SECONDARY, AND WHETHER 'RIB' IS SET OR CLEAR. ALSO, THE ELAPSED TIME OF THE RUN SO-FAR IS PRINTED PROVIDING THAT THE PDP-11 HAS A LINE CLOCK.

1.2.13 SUMMARY TABLE (SEE SEC. 2.2)
THE 'NO. OF OCCURRENCES' COUNT IN THE SUMMARY TABLE HAS BEEN GIVEN A CEILING OF 65,528 (DECIMAL) AND WILL PRINT 'MXCNT' AFTER THAT. THE COUNT IS PRINTED IN DECIMAL.

1.2.14 DIFFERENCES IN V02A
THIS REVISION WAS BROUGHT ABOUT BY THE CHANGE OF THE PROMPT PRINTED WHILE IN COMMAND MODE. THE PROMPT WAS SIMPLY '\$'. IT HAS BEEN CHANGED TO 'PCL>' TO REDUCE THE CONFUSION ON SYSTEMS WHERE PDP-11'S ARE ATTACHED TO VAX11780'S. (IT IS ONLY THE DIAGNOSTIC SUPERVISOR ON THE VAX11780 THAT IS ALLOWED TO USE '\$'.)

2 EXERCISER TABLES

THE PCL11 EXERCISER MAINTAINS THREE TABLES: A 'STATUS' TABLE AN 'ERRORS' TABLE, AND A 'SUMMARY' TABLE.

2.1 STATUS TABLE

THE STATUS TABLE IS DESIGNED TO SHOW THE OPERATOR THE NUMBER OF SUCCESSFUL TRANSMISSIONS TO EACH RECEIVER RELATIVE TO THE NUMBER OF ATTEMPTS TO TRANSFER DATA TO EACH RECEIVER. IF THE TRANSMITTER HAS BEEN TOLD TO 'RE-TRY - IF - BUSY', THE NUMBER OF SUCCESSFUL TRANSFERS WILL BE VERY MUCH CLOSER TO THE NUMBER OF ATTEMPTS THAN WOULD BE THE CASE IF 'RE-TRY - IF - BUSY' WERE NOT THE ORDER. HOWEVER, THE TOTAL NUMBER OF ATTEMPTS WOULD BE GREATER WITH 'RIB' CLEAR.

THE INFORMATION GIVEN IN THE TABLE INCLUDES:

- RUN STATE - STATE OF MASTER, SECONDARY, AND 'RIB'
- RECEIVER ADDRESS - THAT THIS TRANSMITTER HAS BEEN INSTRUCTED TO COMMUNICATE WITH.
- CONNECTION ATTEMPTS - NUMBER OF TIMES THIS XMTR TRIED CONNECTING TO THE RECEIVER OF THE ABOVE ADDRESS.
- SUCCESSFUL CONNECTIONS- NUMBER OF TIMES THAT THE ABOVE ATTEMPTS WERE SUCCESSFUL.

RIB IS -SET- (OR CLEAR)
 THIS UNIT IS -MASTER- (OR SECONDARY)
 ELAPSED TIME (HRS,MIN,SEC,TK)...0:0:4:35
 RCVR ADDRESS CONNECTION ATTEMPTS SUCCESSFUL CONNECTIONS

1	X	Y
2	X	Y
3	X	Y
.	.	.
.	.	.
37	X	Y

THE ENTRIES UNDER 'RCVR ADDRESS' INCLUDE ONLY THOSE ADDRESSES ENTERED BY THE OPERATOR USING THE 'RANGE' OR 'ADD' COMMANDS.

THE ENTRIES UNDER 'CONNECTION ATTEMPTS' AND 'SUCCESSFUL CONNECTIONS' ARE DOUBLE PRECISION DECIMAL NUMBERS. THEY ARE CAPABLE OF INCREASING TO A VALUE OF 655,359,999. IF THERE ARE A LARGER NUMBER OF ATTEMPTS OR SUCCESSES FOR A PARTICULAR RECEIVER THAN THAT AMOUNT, THE ENTRY IN THE TABLE WILL APPEAR AS : '*****'.

SINCE ANY DATA RECEIVED BY A PCL11 RECEIVER MUST BE CHECKED, THE DATA PATTERN, WHICH IS RANDOM, MUST BE RECREATED BY THE RECEIVING EXERCISER BASED ON THE FIRST WORD RECEIVED. THIS MUST THEN BE COMPARED WORD-FOR-WORD WITH THE RECEIVED DATA. IT IS READILY APPARENT THAT THIS TAKES TIME AND WILL MAKE THAT PARTICULAR RECEIVER UNAVAILABLE DURING THAT TIME. ON A LARGE SYSTEM, WITH MANY PCL11'S IT MIGHT BE QUITE A WHILE BETWEEN SUCCESSIVE SUCCESSFUL CONNECTIONS OF A GIVEN TRANSMITTER TO THE SAME RECEIVER, SINCE ALL TRANSMITTERS MAY VERY WELL BE TRYING FOR THE SAME RECEIVERS AT THE SAME TIME. IT IS FOR THIS REASON, THEN, THAT IT NEED NOT BE ALARMING THAT

THERE IS A DIFFERENCE BETWEEN THE NUMBER OF SUCCESSES AND THE NUMBER
OF ATTEMPTS.

SEQ 0008

3.

THE PRINTING OF THE STATUS TABLE MUST BE INITIATED BY THE OPERATOR ON EACH PDP-11 INVOLVED DURING THE COURSE OF AN EXERCISE RUN. THE STATUS TABLE OUTPUT IS NOT CAUSED BY ANY OTHER MEANS THAN THE OPERATOR ENTERING COMMAND MODE AND TYPING 'STATUS'. ALSO IT MUST BE NOTED THAT ALL TRANSMITTER ACTIVITY IS SUSPENDED ON THE UNIT WHILE THE STATUS IS BEING PRINTED OUT.

2.2 SUMMARY TABLE

THE SUMMARY TABLE IS DESIGNED TO SHOW THE OPERATOR A SUMMARY OF ERRORS WHICH HAVE OCCURRED IN EITHER THE RECEIVER OR TRANSMITTER HARDWARE ON EACH PDP-11.

INCLUDED IN THIS TABLE ARE:

ERROR NUMBER - FOR REFERENCE LATER IN THIS DOCUMENT TO INDICATE THE TYPE OF FAILURE.

ERROR ADDRESS - FOR REFERENCE IN THE PCL11 EXERCISER LISTING.

NO. OF OCCURRENCES - TO INDICATE HOW OFTEN THIS ERROR HAS OCCURRED DURING RUN TIME.

THE SUMMARY TABLE IS PRINTED IN THE FORM:

ERROR NUMBER	ERROR ADDRESS	NO. OF OCCURRENCES
1	XXX	YYYY
2	XXX	YYYY
3	XXX	YYYY
.	.	.
30	XXX	YYYY

THE ENTRIES UNDER 'ERROR NUMBER' INCLUDE ONLY THOSE ERRORS WHICH HAVE A 'NO. OF OCCURRENCES' GREATER THAN 0.

THE ENTRIES UNDER 'ERROR ADDRESS' REPRESENT THE OCTAL MEMORY ADDRESS OF THE OCCURRENCE OF THE ERROR WHICH OCCURRED. THE OPERATOR MAY FIND THIS USEFUL FOR LOCATING, IN THE LISTING, THE PORTION OF THE PROGRAM WHERE THE ERROR OCCURRED.

THE ENTRIES UNDER 'NO. OF OCCURRENCES' IS THE TOTAL (OR SUMMARY VALUE) OF ALL THE ERRORS OF THAT ERROR NUMBER WHICH OCCURRED AT THIS TERMINAL REGARDLESS OF WHAT TRANSMITTER WAS CONNECTED TO WHAT RECEIVER.

THE PRINTING OF THE SUMMARY TABLE MUST BE INITIATED BY THE OPERATOR ON EACH PDP-11 INVOLVED DURING THE COURSE OF AN EXERCISE RUN. THE SUMMARY TABLE OUTPUT IS NOT CAUSED BY ANY OTHER MEANS THAN THE OPERATOR ENTERING COMMAND MODE AND TYPING 'SUMMARY'. ALSO IT MUST BE NOTED THAT ALL TRANSMITTER ACTIVITY IS SUSPENDED ON THE UNIT WHILE THE SUMMARY TABLE IS BEING PRINTED OUT.

2.3 ERROR TABLES

THE ERROR TABLES ARE DESIGNED TO SHOW THE OPERATOR THE ERRORS WHICH OCCURRED DURING AN EXERCISE RUN IN ENOUGH DETAIL SO THAT HE CAN DETERMINE AS CLOSELY AS POSSIBLE WHICH TRANSMITTER AND/OR WHICH RECEIVER WERE CONNECTED AT THE TIME OF THE ERROR. THERE ARE 15 OCTAL TRANSMITTER TYPE ERRORS AND 13 OCTAL RECEIVER TYPE ERRORS. FOR EACH OF THE TRANSMITTER ERRORS, ANY ONE OF 31 POSSIBLE RECEIVERS MAY HAVE BEEN CONNECTED TO THAT TRANSMITTER AT THE TIME OF THE ERROR. THE ONE THAT ACTUALLY WAS CONNECTED IS LISTED IN THIS ERROR TABLE ALONGSIDE THE ERROR NUMBER AND THE COUNT OF THAT OCCURRENCE. FOR EACH OF THE RECEIVER-TYPE ERRORS, ANY ONE OF 31 TRANSMITTERS MAY HAVE BEEN TALKING TO THIS RECEIVER AT THE TIME OF THE ERROR. AGAIN, THE ACTUAL ONE IS LISTED IN THE RECEIVER ERRORS TABLE.

THE ENTRIES IN THESE TABLES THEN, INCLUDE:

- ERROR NUMBER - FOR REFERENCE LATER IN THIS DOCUMENT TO INDICATE THE TYPE OF FAILURE.
- CONNECTED XMTR (RCVR) - TO INDICATE THE ACTUAL ERRONEOUS LINK.
- ERROR COUNT - TO SHOW THE NUMBER OF OCCURRENCES OF THIS ERROR WITH THIS CONNECTION.

THE TABLES ARE ALWAYS PRINTED TOGETHER AND ARE PRINTED IN THE FOLLOWING FORMAT:

TRANSMITTER ERRORS:

ERROR NO.	CONCTD RCVR	ERROR COUNT
1	1	63
1	2	7
1	6	48
15	37	2

RECEIVER ERRORS:

ERROR NO.	CONCTD XMTR	ERROR COUNT
16	1	22
16	2	22
27	37	12
30	6	2

IF THE COMMAND IS GIVEN TO DUMP THESE ERROR TABLES AND IT IS FOUND THAT NO ERRORS EXIST, THE EXERCISER RESPONDS IN THE FOLLOWING WAY:

** NO ERRORS TO REPORT YET **

IF THERE ARE, FOR EXAMPLE, TRANSMITTER ERRORS BUT NO RECEIVER ERRORS, THEN UNDER THE HEADING 'ERROR NO.' OF THE RECEIVER ERRORS WILL BE PRINTED: (NONE).

2.4 CLEARING OF THE TABLES

THE "STATUS TABLE" IS NORMALLY CREATED BY MEANS OF THE OPERATOR ENTERING, VIA THE "RANGE, OR ADD" COMMANDS, SOME RECEIVER ADDRESSES. FOR EXAMPLE, IF THE "ADD" COMMAND WERE USED TO ENTER RECEIVER ADDRESSES 1, 2, 3, 4, & 5, AND IMMEDIATELY THEREAFTER THE STATUS WAS REQUESTED, THE STATUS TABLE WOULD INDICATE ALL OF THE SELECTED RECEIVERS BUT THE ATTEMPTED AND SUCCESSFUL CONNECTION COUNTS FOR EACH OF THOSE RECEIVERS WOULD BE 0.

THE STATUS TABLE IS COMPLETELY CLEARED BY USING THE "CLEAR" COMMAND, OR BY USING THE "DELETE" COMMAND AND DELETING ALL THOSE ADDRESSES INDICATED IN THE STATUS TABLE. THE "INITIALIZE" COMMAND ALSO CLEARS THE STATUS TABLE COMPLETELY BY INTERNALLY CALLING THE "CLEAR" COMMAND.

THE "SUMMARY TABLE" IS NOT AFFECTED BY THE "CLEAR" COMMAND BUT IS ENTIRELY CLEARED BY THE "INITIALIZE" COMMAND.

LIKewise, THE "ERRORS TABLE" IS COMPLETELY CLEARED BY THE "INITIALIZE" COMMAND BUT IS NOT AFFECTED BY THE "CLEAR" COMMAND.

WHEN THE OPERATOR "STARTS" THE EXERCISER BY USING THE "GO" COMMAND, THE FOLLOWING RESULTS CAN BE EXPECTED ON THE TABLES:

THE ADDRESS ENTRIES OF THE "STATUS" TABLE ARE UNAFFECTED.

THE ATTEMPTS AND SUCCESSES ENTRIES OF THE STATUS TABLE ARE CLR'D

THE ENTIRE SUMMARY TABLE IS CLEARED.

THE ENTIRE ERRORS TABLE IS CLEARED.

! CAUTION !

IT IS IMPORTANT TO NOTE THAT THE RECEIVER ERRORS ARE CLEARED ALONG WITH THE TRANSMITTER ERRORS UPON THE ISSUANCE OF THE "GO" COMMAND. THEREFORE, THE OPERATOR MUST NOTE THAT THE NUMBER OF RECEIVER ERRORS INDICATED IN EITHER THE SUMMARY TABLE OR THE RECEIVER ERRORS TABLE IS ONLY THE NUMBER ACCUMULATED SINCE "GO" WAS TYPED.

3 EXERCISE COMMANDS

3.1 CONTROL CHARACTERS

3.1.1 CONTROL-C

THIS CHARACTER IS USED TO GET THE EXERCISER INTO 'COMMAND' MODE SO THAT ANY OF THE CONTROLLING COMMANDS MAY BE ENTERED.

TYPING CONTROL-C (^C) ECHOS '^C' AND TERMINATES ANY OTHER FUNCTIONS WHICH MAY BE TAKING PLACE AT THE TIME. IF ANY OF THE TABLES ARE BEING PRINTED, THE CURRENT LINE WILL BE COMPLETED BEFORE '^C' IS ECHOED. THEN THE TABLE WILL BE TRUNCATED. THE EXERCISER WILL THEN ENTER 'COMMAND' MODE AND INDICATE THIS BY PRINTING 'PCL>'.

'PCL>' IS THE PROMPT WHICH INDICATES THAT A COMMAND MAY BE ENTERED BY THE OPERATOR.

TYPING 'CNTRL-C' WHILE THE EXERCISER IS 'EXERCISING' WILL CAUSE TERMINATION OF TRANSMITTER ACTIVITY ON THAT PDP-11, ECHO '^C', AND PRINT THE COMMAND MODE PROMPT 'PCL>'.

3.1.2 CONTROL-O

THIS CHARACTER IS USED TO TERMINATE THE CURRENT PRINTOUT. IT CAUSES THE ENTIRE CONTENTS OF THE OUTPUT QUEUE TO BE THROWN AWAY. WHEN TABLES ARE BEING PRINTED, ONLY A SINGLE LINE IS IN THE OUTPUT QUEUE AT ANY GIVEN TIME. THIS ALLOWS 'SKIPPING' OF LINES DURING TABLE OUTPUT TO SAVE TIME.

WHEN CONTROL-O IS TYPED, THE EXERCISER WILL ECHO '^O', CLEAR THE OUTPUT QUEUE, AND THEN RETURN TO WHICHEVER MODE IT WAS IN WHEN 'CNTRL-O' WAS TYPED IN. THEREFORE, IF ^O IS TYPED IN DURING EXERCISE TIME, THE '^O' WILL STILL BE ECHOED. IF 'CNTRL-O' IS TYPED ARBITRARILY WHILE IN COMMAND MODE, THE '^O' WILL BE ECHOED BUT THERE WILL NOT BE ANOTHER 'PCL>' GIVEN (YET THE EXERCISER WILL ACCEPT COMMANDS).

3.1.3 CONTROL-U

THIS CHARACTER IS USED (AS IT IS IN MOST D.E.C. SOFTWARE) TO THROW AWAY THE INPUT TYPED THUS FAR. THIS CONTROL CHARACTER SHOULD BE USED IF A MISTAKE IS NOTICED IN THE COMMAND STRING BEFORE CARRIAGE RETURN IS HIT. IF CARRIAGE RETURN IS HIT, THE ERRONEOUS COMMAND WILL BE EXECUTED UP TO THE POINT OF THE ERROR, THEN A SYNTAX ERROR MESSAGE WILL BE PRINTED.

WHEN CONTROL-U IS TYPED, THE EXERCISER WILL ECHO '^U', CLEAR THE INPUT QUEUE, THEN ISSUE A NEW 'PCL>' AND AWAIT A FURTHER COMMAND.

3.1.4 CONTROL-S

THIS CHARACTER IS USED TO SUSPEND PRINTER OUTPUT. NOTHING IS LOST WHEN IT IS USED, BUT THE PRINTOUT IS 'HELD' UNTIL THE ISSUANCE OF CONTROL-Q OR SIMPLY TYPING ANY OTHER CHARACTER. THIS FEATURE IS USEFUL WHEN GETTING TABLE PRINTOUTS ON A VIDEO TERMINAL AND IT IS DESIREOUS TO STOP THE DISPLAY. IT IS ALSO USEFUL TO STOP THE PRINTOUT IN ORDER TO FIX THE PAPER OR ADD MORE PAPER ON ANY HARD COPY PRINTER.

NOTHING IS ECHOED UPON , OR AFTER, THE ISSUANCE OF A CONTROL-S.

3.1.5 CONTROL-Q

THIS CHARACTER IS USED TO RESUME PRINTOUT AFTER IT WAS STOPPED BY USE OF CONTROL-S. TYPING ANY OTHER CHARACTER WILL ALSO RESUME OUTPUT BUT THE CONTROL-Q CHARACTER IS NOT ENTERED INTO THE INPUT QUEUE, AND SIMPLY RESUMES PRINTOUT.

NOTHING IS ECHOED AS A RESULT OF TYPING CONTROL-Q EXCEPT WHATEVER PRINTOUT HAD BEEN SUSPENDED BY THE CONTROL-S CHARACTER.

3.1.6 CARRIAGE RETURN

THE CARRIAGE RETURN CHARACTER IS USED TO TERMINATE COMMAND STRINGS AND SIGNIFIES ENTRANCE OF A COMMAND. ALL COMMANDS MUST BE TERMINATED WITH EITHER A CARRIAGE RETURN OR A LINE FEED. IF ONLY CARRIAGE RETURN IS TYPED, (BLANK COMMAND) THE EXERCISER SIMPLY ISSUES A NEW 'PCL>'.

WHEN CARRIAGE RETURN <CR> IS TYPED, BOTH CARRIAGE RETURN AND LINE FEED ARE ECHOED.

3.1.7 LINE FEED

THE LINE FEED CHARACTER IS TREATED EXACTLY AS THE CARRIAGE RETURN CHARACTER. IF ONLY A LINE FEED IS TYPED, (BLANK COMMAND) THE EXERCISER ISSUES A NEW 'PCL>'.

3.1.8 RUBOUT

THIS CHARACTER IS USED TO 'EDIT' THE COMMAND STRING WHILE IT IS BEING TYPED. EACH RUBOUT TYPED WILL REMOVE A CHARACTER FROM THE COMMAND BUFFER. WHEN ALL THE CHARACTERS HAVE BEEN REMOVED, THE EXERCISER WILL ISSUE A NEW 'PCL>' TO INDICATE THE ENTIRE COMMAND HAS BEEN ERASED.

EACH TIME A RUBOUT IS TYPED, A '^' IS ECHOED AND THE LAST CHARACTER WHICH WAS INPUT IS REMOVED.

3.2 COMMANDS

THIS SECTION DEALS WITH THE FULL COMMANDS OF THE EXERCISER WHICH ALLOW THE SETTING UP OF CONDITIONS TO BEST SUIT THE SYSTEM BEING TESTED. IN THE COMMANDS SHOWN, THE MINIMUM AMMOUNT REQUIRED TO BE TYPED IS SET IN SQUARE BRACKETS []. FOR EXAMPLE, IN THE COMMAND:

[I]NITIALIZE

ALL OF THE FOLLOWING ARE ACCEPTABLE:

I, IN, INI, INIT, INITI, INITIA, INITIAL, INITIALI, INITIALIZ
AND INITIALIZE

WHEREAS THE FOLLOWING ARE NOT ACCEPTABLE:

INT, INITL, INITIALIZES

THERE ARE SOME COMMANDS WHICH MAY BE EXECUTED WITH OR WITHOUT ARGUMENTS. IN THESE CASES, THE <ARGUMENTS> WILL BE SET IN ANGLE BRACKETS. ARGUMENTS FOR COMMANDS MUST BE NUMERIC, EXCEPT FOR THE COMMANDS 'MASTER', 'SECONDARY', AND 'RIB', AND IF THEY ARE TYPED IN AS DECIMAL NUMBERS, THY MUST BE IMMEDIATELY FOLLOWED BY A DECIMAL POINT (PERIOD). FOR THE 'RANGE' AND 'ASSIGN' COMMANDS, THE ORDER OF THE INPUT OF ARGUMENTS MUST ADHERE TO THE DESCRIPTIONS (SECT 3.2.5, & 3.2.13)

3.2.1 SILO

[SI]LO <A B C ...N>

SILO -- CLEAR THE MASTER ADDRESS SILO AND RETURN TO 'AUTO
ADDRESS MODE'.

SILO A B C . . . N

LOAD THE MASTER ADDRESS SILO WITH THE SEQUENCE 'ABC..N'
AS MANY TIMES AS THE WHOLE SEQUENCE WILL FIT INTO THE
SILO'S 50 LOCATIONS.

THIS COMMAND MONITORS THE ARGUMENTS CAREFULLY CHECKING FOR SEQUENTIAL ARGUMENTS WHICH ARE THE SAME, ARGUMENTS WHICH ARE 0, OR ARE GREATER THAN 37 OCTAL, AND CHECKING THAT THE LAST ARGUMENT IS NOT THE SAME AS THE FIRST.

IF ANY TWO SEQUENTIAL ARGUMENTS ARE FOUND TO BE THE SAME, INCLUDING THE FIRST AND THE LAST, A 'PAD' VALUE IS INSERTED BETWEEN THEM. THE 'PAD' VALUE IS 0. THIS ALSO INCREASES THE NUMBER OF ARGUMENTS IN THE SEQUENCE.

IF ANY OF THE ARGUMENTS ARE '0', OR GREATER THAN '37' OR NON-NUMERIC, OR IF THERE ARE MORE THAN 50. ARGUMENTS, THE COMMAND WILL BE ABORTED AND THE '**SYNTAX ERROR**' MESSAGE WILL BE PRINTED.

WHEN THE SILO HAS BEEN SUCCESSFULLY LOADED, THERE IS THE POSSIBILITY THAT ONE OR TWO MESSAGES WILL BE PRINTED, OR NONE MAY BE PRINTED.

IF THIS UNIT IS NOT MASTER, THE FOLLOWING WILL BE PRINTED:

'THIS UNIT IS NOT MASTER BUT HAS BEEN MADE SECONDARY
THE SILO YOU HAVE JUST LOADED WILL BE USED IF YOU CLEAR
THE CURRENT MASTER.'

IF IT WAS REQUIRED FOR THE EXERCISER TO 'PAD' THE SILO WITH 0'S

THE FOLLOWING WILL BE PRINTED:

SEQ 0015

'THE SILO HAS BEEN PADDED WITH THE ADDRESS '0'.'

S
S
S
T
T
H
M
S
S
C
T
S

S

C
C
C
T

S

C
M

E
I
A
I
C

3.2.2 MASTER

[M]ASTER [S]ET OR [C]LEAR

MASTER SET - WRITE A (1) INTO THE TMMR REGISTER BIT 08 IN THIS TRANSMITTER TO ATTEMPT TO SET MASTER. ANOTHER UNIT HAVING 'MASTER' SET, WILL DIS-ALLOW THIS BIT TO BE SET.

MASTER CLEAR - WRITE A (0) INTO THE TMMR REGISTER BIT 08 IN THIS TRANSMITTER TO CLEAR 'MASTER'. IF NO OTHER UNIT HAS BEEN SET TO BE 'SECONDARY', THIS ACTION WILL CAUSE 'MASTER DOWN' ERRORS ON ALL UNITS ATTEMPTING TO TRANSMIT.

THIS COMMAND IS USED TO 'SOFTWARE SET' ONE OF THE PCL11 UNITS TO BE MASTER OF THE T.D.M. BUS. THE ONLY ARGUMENTS ALLOWED ARE '[S]ET' AND '[C]LEAR'. NO ARGUMENTS, OR ANY OTHER ARGUMENTS THAN THESE, WILL RESULT IN THE MESSAGE '**SYNTAX ERROR**'.

SINCE THE HARDWARE DESIGN WILL NOT ALLOW MASTER TO BE SET ON MORE THAN ONE UNIT CONNECTED TO THE SAME T.D.M. BUS, THIS COMMAND MAY NOT WORK IN SETTING MASTER. THERE IS NOT, HOWEVER, ANY IMMEDIATE INDICATION THAT THE 'MASTER SET' COMMAND WAS OR WASN'T SUCCESSFUL. THE OPERATOR MUST ISSUE THE 'STATUS' COMMAND TO DETERMINE IF A PARTICULAR UNIT IS MASTER.

3.2.3 SECONDARY

[S]ECONDARY [S]ET OR [C]LEAR

SECONDARY SET - WRITE A (1) INTO THE TMMR REGISTER BIT 09 IN THIS TRANSMITTER TO ATTEMPT TO SET 'SECONDARY'. THIS UNIT BEING 'MASTER' WILL DIS-ALLOW THIS BIT TO BE SET.

SECONDARY CLEAR - WRITE A (0) INTO THE TMMR REGISTER BIT 09 IN THIS TRANSMITTER TO CLEAR 'SECONDARY'.

THIS COMMAND IS USED TO 'SOFTWARE SET' ONE OF THE PCL11 UNITS TO BE SECONDARY MASTER OF THE T.D.M. BUS. IF THE PCL11 UNIT WHICH CURRENTLY HAS MASTER SET CLEARS IT, AND THIS UNIT HAS SECONDARY SET, THEN THIS UNIT WILL BECOME THE NEW MASTER. IF THIS UNIT IS IN COMMUNICATION WITH A RECEIVER AT THE TIME IT BECOMES NEW MASTER, THE MESSAGE :

** THIS UNIT HAS BECOME 'NEW MASTER' **

IS PRINTED ON THE CONSOLE AND THE EXERCISER AUTOMATICALLY CONTINUES EXERCISING.

3.2.4 RIB

[R]B [S]ET OR [C]LEAR

RIB SET - WRITE A (1) INTO THE MEMORY LOCATION (BIT 15) WHICH IS USED AS THE TRANSMITTER COMMAND WORD. THE LOCATION IS TAGGED: 'TXMST:'. THIS WILL CAUSE THE NEXT AND SUBSEQUENT TRANSMITTER EVENTS TO OCCUR IN THE 'RE-TRY - IF - BUSY' MODE.

RIB CLEAR - WRITE A (0) INTO THE MEMORY LOCATION (BIT 15) WHICH IS USED AS THE TRANSMITTER COMMAND WORD TAGGED 'TXMST'. THIS WILL CAUSE 'BUSY' INTERRUPTS TO OCCUR WHENEVER THE RECEIVER BEING ADDRESSED IS NOT READY OR NOT THERE.

THIS COMMAND IS USED TO 'SOFTWARE SET' THE 'RIB' OR RE-TRY IF BUSY FEATURE IN THE PCL11 TRANSMITTER. WITH 'RIB' SET, THE TRANSMITTER HARDWARE WILL CONTINUOUSLY RE-TRY TO CONNECT TO THE SELECTED RECEIVER UNTIL EITHER A 'TIME-OUT' OCCURS, OR THE CONNECTION IS MADE AND A 'SUCCESSFUL TRANSFER' OCCURS.

WITH 'RIB' CLEAR, THE HARDWARE PRODUCES AN INTERRUPT IMMEDIATELY UPON FINDING THE ADDRESSED RECEIVER BUSY OR NOT THERE. THE USE OF THIS COMMAND WILL CAUSE A DIFFERENCE IN THE 'SUCCESSFUL CONNECTION' COUNT RELATIVE TO THE 'ATTEMPTED CONNECTION' COUNT IN THE STATUS PRINT-OUT.

3.2.4 RANGE

[R]ANGE [LOW HIGH]

RANGE A B PRODUCE A LIST, IN THE STATUS TABLE, OF ADDRESSES FROM ADDRESS 'A' TO 'B' AND MAKE THEM 'ACTIVE' RECEIVER ADDRESSES. 'B' MUST BE HIGHER THAN 'A'. BOTH 'A' AND 'B' ARE REPRESENTATIVE OF NUMERICAL VALUES WITHIN THE RANGE OF 1-37 OCTAL.

EXAMPLE:

THE COMMAND 'RANGE 12. 16.' WILL ACTIVATE RECEIVER ADDRESSES 12 UP TO AND INCLUDING 16 (DECIMAL), OR 14 UP TO AND INCLUDING 20 (OCTAL). THESE ADDRESSES WILL BE USED SEQUENTIALLY BY THE TRANSMITTER MODULE IN THE EXERCISER AS TARGET RECEIVER ADDRESSES.

3.2.6 ADD

[AD]D [1] 2 3 . . 37

ADD A B C

SELECT TARGET RECEIVER ADDRESSES. ADD THE NUMERIC VALUES OF A, B, C TO THE STATUS TABLE AND MAKE THEM 'ACTIVE RECEIVER ADDRESSES'. THIS COMMAND MAY HAVE ANY NUMBER OF ARGUMENTS PROVIDING THAT THERE IS AT LEAST ONE. THERE IS NO RESTRICTION ON THE ORDER OF THE ARGUMENTS AT ALL. THE SAME NUMBER MAY BE ADDED AS MANY TIMES AS YOU LIKE. THE ARGUMENTS MUST BE NUMERICAL AND BETWEEN THE VALUES 1 AND 31. (DECIMAL) OR 1 AND 37 (OCTAL).

EXAMPLE:

THE COMMAND 'ADD 1 12 3 3 22 8. ' WILL ACTIVATE RECEIVER ADDRESSES 1 3 10 12 AND 22 (OCTAL) OR 1 3 8. 10. AND 18. (DECIMAL) THIS COMMAND AFFECTS ONLY THOSE ADDRESSES INCLUDED IN THE ARGUMENTS OF THE COMMAND. IT MAY BE USED EFFECTIVELY IN CONJUNCTION WITH THE 'RANGE' COMMAND TO PRODUCE A AN EFFICIENT LIST OF THOSE RECEIVER ADDRESSES WHICH ARE TO BE COMMUNICATED WITH BY THIS TRANSMITTER.

3.2.7 DELETE

[D]ELETE [1] 2 3 . . 37

DELETE A B C

DELETE THE NUMERIC VALUES OF A, B, C FROM THE STATUS TABLE AND MAKE THEM 'INACTIVE RECEIVER ADDRESSES'. THIS COMMAND MAY HAVE ANY NUMBER OF ARGUMENTS PROVIDING THERE IS AT LEAST ONE. THERE IS NO RESTRICTION ON THE ORDER OF THE ARGUMENTS AT ALL. AND REDUNDANCIES ARE ACCEPTABLE. THE ARGUMENTS MUST BE NUMERIC AND BETWEEN THE VALUES 1 AND 31. (DECIMAL) OR 1 AND 37 (OCTAL).

EXAMPLE:

THE COMMAND 'DELETE 12 22 ' WILL MAKE RECEIVER ADDRESSES 12 AND 22 'INACTIVE' SO THAT THIS TRANSMITTER WILL NOT ATTEMPT TO COMMUNICATE WITH THEM. THIS COMMAND MAY BE USED EFFECTIVELY IN CONJUNCTION WITH THE 'RANGE' COMMAND AS FOLLOWS:

RANGE 1 7
DELETE 2 5

WILL PRODUCE A LIST OF 'ACTIVE' RECEIVERS WITH THE ADDRESSES:

1, 3, 4, 6, AND 7

3.2.8 CLEAR

[CL]EAR

CLEAR - CLEAR THE ENTIRE STATUS TABLE. REMOVE ALL RECEIVER ACTIVE FLAGS AND CLEAR ALL CONNECTION ATTEMPS AND SUCCESSES FROM EVERY TABLE LOCATION. THIS COMMAND IS MOSTLY USEFUL WHEN IT IS DESIRED TO 'RE-START' THE EXERCISER WITH A FRESH SLATE BUT NOT DISTURB THE ERROR SUMMARY TABLE NOR THE ERRORS TABLES.

THE 'CLEAR' COMMAND HAS NO AFFECT ON ANY OTHER TABLES IN THE EXERCISER BUT IT DOES ALSO CLEAR THE INTERNAL (SOFTWARE) QUEUE OF RECEIVER ADDRESSES.

EXAMPLE:

CONSIDER THE FOLLOWING STRING OF COMMANDS:

```
RANGE 1 21
ADD 27 30 31 32 33 34
DELETE 17 20
CLEAR
RANGE 1 16
ADD 21 37
```

THE RESULT WOULD BE THE 'ACTIVATION' OF RECEIVER ADDRESSES:

1, 2, 3, 4, 5, 6, 7, 10, 11, 12, 13, 14, 15, 16, 21, 37

3.2.9 INITIALIZE

[I]NITIALIZE

INITIALIZE - INITIALIZE EVERYTHING ABOUT THIS TRANSMITTER AND CLEAR ALL TABLES ASSOCIATED WITH THIS PDP-11. INITIALIZE PERFORMS A HARDWARE CLEAR OF THE TRANSMITTER REGISTERS, RESETS ALL OF THE EVENT FLAGS ASSOCIATED WITH THE SENDING OF DATA, CLEARS THE SOFTWARE QUEUE OF RECEIVER ADDRESSES, INITIALIZES THE SEEDS USED FOR GENERATION OF RANDOM DATA, DOES A 'CLEAR' COMMAND AS ABOVE AND CLEARS BOTH ERROR TABLES.

3.2.10 STATUS

[ST]ATUS

STATUS -

SET THE EVENT FLAG WHICH CAUSES THE CURRENT STATUS TABLE TO BE PRINTED. EVERY TIME THE STATUS COMMAND IS ISSUED, A STATUS HEADER IS PRINTED (SEE 2.1). THEN, IN NUMERICAL ORDER THE 'ACTIVE' RECEIVER ADDRESSES, NUMBER OF ATTEMPTED CONNECTIONS, AND NUMBER OF SUCCESSFUL CONNECTIONS IS PRINTED ON A LINE-BY-LINE BASIS. THE PRINTING OF THE STATUS TABLE DOES (LIKE ALL COMMANDS) INHIBIT ANY ACTION BY THE TRANSMITTER IN THAT PDP-11 BUT THE RECEIVER IS ALWAYS ACTIVE.

3.2.11 SUMMARY

[SL]MMARY

SUMMARY -

SET THE EVENT FLAG WHICH CAUSES THE CURRENT ERROR SUMMARY TABLE TO BE PRINTED. EVERY TIME THE SUMMARY COMMAND IS ISSUED, A SUMMARY HEADER IS PRINTED (SEE 2.2). THEN, IN NUMERICAL ORDER, THE ERROR NUMBERS, ERROR ADDRESSES, AND NO. OF OCCURRENCES ARE PRINTED (IF ANY) ON A LINE-BY-LINE BASIS. AGAIN, TRANSMITTER ACTIVITY IS SUSPENDED UNTIL THE EXERCISER IS 'CONTINUED'.

3.2.12 ERRORS

[E]RRORS

ERRORS -

SET THE EVENT FLAG WHICH CAUSES THE CURRENT TRANSMITTER ERROR TABLE TO BE PRINTED. WHEN THE TRANSMITTER ERROR EVENT IS FINISHED, IT WILL AUTOMATICALLY SET THE RECEIVER ERROR EVENT FLAG WHEREBY THE RECEIVER ERROR TABLE WILL BE PRINTED (SEE 2.3).

WHEN THE 'ERROR' COMMAND IS ISSUED, A CHECK IS MADE OF THE ENTIRE TRANSMITTER AND RECEIVER TABLES TO DETERMINE IF THERE HAD BEEN ANY ERROR OCCURRENCES TO DATE. IF THERE WERE NO ERRORS IN EITHER TABLE, THEN THE MESSAGE:

'NO ERRORS TO REPORT YET'

IS PRINTED. OTHERWISE, THE ERROR NUMBER (IN NUMERICAL ORDER), THE CONNECTED RCVR/XMTR, AND THE ERROR COUNT ARE PRINTED ON A LINE-BY-LINE BASIS. TRANSMITTER ACTIVITY IS AGAIN SUSPENDED UNTIL THE EXERCISER IS 'CONTINUED'.

3.2.13 ASSIGN

[AS]SIGN <XM ADDR XM VCT RC ADDR RC VCTR>

ASSIGN -

GIVE TO THE EXERCISER, THE UNIBUS ADDRESSES AND VECTORS OF THE PCL11 UNIT WHICH THE OPERATOR DESIRES TO EXERCISE.

AS IS INDICATED BY THE ANGLE BRACKETS, THE ASSIGN COMMANDS' ARGUMENTS ARE OPTIONAL. IF THE ASSIGN COMMAND IS ISSUED WITH NO ARGUMENTS, THEN THE 'DEFAULT' (NORMAL) ADDRESSES AND VECTORS ARE ASSIGNED. THESE ARE:

XMTR ADDR	164200
XMTR VECTOR	170
RCVR ADDR	164220
RCVR VECTOR	174

THE 'ASSIGN' COMMAND MAY ALSO BE USED WITH ANY, OR ALL OF FOUR ARGUMENTS. HOWEVER THE PROPER FIELD MUST BE USED TO ENTER THE DESIRED ADDRESS:

ASSIGN AAAAA BBB CCCCC DDD

TO ENTER ONLY THE TRANSMITTER ADDRESS, ONLY THE FIELD AAAAA NEED BE USED.

ASSIGN 166200

TO ENTER THE TRANSMITTER VECTOR (BBB), FIRST THE TRANSMITTER ADDRESS, THEN THE VECTOR IS TYPED:

ASSIGN 166200 700

TO ENTER THE RECEIVER ADDRESS (FIELD CCCCC), FIRST THE TRANSMITTER ADDRESS, THEN THE TRANSMITTER VECTOR, THEN THE RECEIVER ADDRESS IS TYPED:

ASSIGN 166200 700 166220

FINALLY, TO ASSIGN THE RECEIVER VECTOR, THE XMTR ADDRESS, XMTR VECTOR, RCVR ADDRESS AND THEN THE RECEIVER VECTOR IS TYPED:

ASSIGN 166200 700 166220 704

NOTE THAT EACH ARGUMENT MUST BE SEPARATED BY A SPACE (NOT A COMMA).

AT THE SUCCESSFUL COMPLETION OF THE 'ASSIGN' COMMAND, THE EXERCISER WILL BE STARTED OVER JUST AS THOUGH THE OPERATOR HAD STARTED AT 200.

A '**SYNTAX ERROR**' WILL OCCUR WITH ANY OF THE FOLLOWING CONDITIONS:

TOO MANY ARGUMENTS

ARGUMENT IS NOT NUMERIC

ADDRESS ARGUMENT NOT IN I/O ADDRESS FIELD
(I.E. ABOVE 163776)

VECTOR ARGUMENT IS NOT IN VECTOR FIELD
(I.E. FROM 0 TO 776)

ADDRESS ARGUMENT HAS WRONG OFFSET
(I.E. LAST 4 BITS MUST BE 0)

VECTOR ARGUMENT HAS WRONG OFFSET
(I.E. LAST 2 BITS MUST BE 0)

IMPROPER SPELLING OF 'ASSIGN' OR IMPROPER USE OF DECIMAL NUMBERS.

3.2.14 GO

[G]O

GC -

START THE EXERCISER. ENTER 'EXERCISE MODE'. GO IS ISSUED TO INITIALLY START THE EXERCISER TRANSMITTING TO OTHER RECEIVERS ON THE T.D.M. BUS. ALL TARGET RECEIVER ADDRESS SHOULD HAVE ALREADY BEEN ENTERED VIA THE 'RANGE' OR 'ADD' COMMANDS, AND ONE OF THE PCL11 UNITS SHOULD HAVE BEEN SET TO BE T.D.M. BUS MASTER. IF THE 'SILO' IS BEING USED TO GENERATE TRANSMITTER ADDRESSES, IT SHOULD HAVE BEEN LOADED PRIOR TO 'GO'.

THE 'GO' COMMAND WILL CAUSE THE CLEARING OF THE ERRORS TABLES AND THE SUMMARY TABLE AND THE 'ATTEMPTS' AND 'SUCCESSSES' PORTIONS OF THE STATUS TABLE. IT ALSO CAUSES THE CLEARING OF THE RECEIVER ADDRESS QUEUE (SOFTWARE). NOTE THAT THE RECEIVER ERRORS ACCUMULATED UP TO THE POINT OF TYPING 'GO' ARE LOST. ONLY THOSE ACCUMULATED AFTER 'GO' IS TYPED CAN BE DISPLAYED IN THE ERRORS TABLE. IT WILL NOT, HOWEVER, CAUSE THE CLEARING OF THE RECEIVER ADDRESSES IN THE STATUS TABLE; SO THAT ALL RECEIVERS SELECTED BY THE RANGE OR ADD COMMANDS WILL STILL BE ACTIVE.

THE TRANSMITTER 'EVENT' FLAG IS SET BY THE GO COMMAND WHICH BEGINS THE TRANSMISSION OF DATA TO THE DE-QUEUED TARGET RECEIVER ADDRESSES. WHEN 'GO' IS ISSUED, THE IMMEDIATE RESPONSE SHOULD BE THAT THE EXERCISER PRINTS:

EXERCISER STARTED

HOWEVER, IF THE OPERATOR FORGOT TO ENTER THE TARGET RECEIVER ADDRESSES, AND NONE WERE PREVIOUSLY ENTERED, THE EXERCISER WILL NOT BE ABLY TO RUN AND WILL APOLOGIZE THUS:

'* SORRY, I HAVE NO RECEIVER ADDRESSES *'

3.2.15 CONTINUE

[C]ONTINUE

CONTINUE -

CONTINUE EXERCISING. RE-ENTER EXERCISE MODE. 'CONTINUE' IS ISSUED TO CAUSE THE EXERCISER TO CONTINUE AFTER A TABLE HAS FINISHED BEEING PRINTED, OR AFTER SOME OTHER COMMAND HAS BEEN EXECUTED TO POSSIBLY CHANGE THE RUNNING OF THE EXERCISER.

THE 'CONTINUE' COMMAND DOES NOTHING TO ANYTHING EXCEPT THAT IT RE-STARTS EXERCISE MODE. ALL TABLES ARE LEFT INTACT AND SOFTWARE QUEUES ARE UNTOUCHED. WHEN 'CONTINUE' IS ISSUED, THE IMMEDIATE RESPONSE SHOULD BE THAT THE EXERCISER PRINTS:

'EXERCISER CONTINUING'

IF, HOWEVER, WHILE THE EXERCISER WAS STOPPED, THE OPERATOR USED THE INITIALIZE OR CLEAR COMMANDS AND DID NOT RE-ENTER ANY TARGET RECEIVER ADDRESSES (VIA RANGE OR ADD), THE RECEIVER ADDRESS QUEUE WOULD EVENTUALLY BECOME EMPTY AND WOULD NEVER BE RE-FILLED. THIS WOULD AGAIN CAUSE THE PRINTOUT:

''* SORRY, I HAVE NO RECEIVER ADDRESSES *''

3.2.16 **SYNTAX ERROR**

SYNTAX ERROR IS NOT A COMMAND BUT IS RELATED TO ALL OF THE COMMANDS OF SECTION 3.2. IN GENERAL, A SYNTAX ERROR WILL RESULT FOR THE FOLLOWING REASONS:

- .1 COMMAND DOES NOT EXIST IN 'KEYWORD' TABLE
- .2 COMMAND WORD IS MISSPELLED
- .3 FEWER THAN THE MINIMUM CHARACTERS WERE USED
(I.E. LESS THAN THAT ENCLOSED IN SQUARE BRACKETS [CL]EAR)
- .4 NO ARGUMENTS GIVEN WHERE REQUIRED
- .5 ARGUMENTS GIVEN WHERE NONE REQUIRED
- .6 ARGUMENTS IN WRONG ORDER (WHERE ORDER IS IMPORTANT)
- .7 NOT ENOUGH ARGUMENTS
- .8 TOO MANY ARGUMENTS
- .9 ARGUMENTS ARE WRONG CLASS (USUALLY SHOULD BE NUMBERS)
- .10 ARGUMENTS ARE OUTSIDE SPECIFIC BOUNDARIES (SEE 3.2.13)
- .11 ARGUMENTS SEPARATED BY OTHER THAN A SPACE
- .12 COMMAND SEPARATED FROM ARGUMENTS BY OTHER THAN A SPACE
- .13 DECIMAL NUMERIC ARGUMENTS USED WITHOUT THE POINT (.)
- .14 ARGUMENTS ARE THE SAME (ONLY IN 'RANGE' COMMAND)

4 GETTING THE EXERCISER STARTED

4.1 PREPARATION

BEFORE RUNNING THE PCL11 EXERCISER, THE FOLLOWING MUST HAVE BEEN PREVIOUSLY PERFORMED:

- INSURE ALL PCL11 UNITS ARE CORRECTLY INSTALLED IN EACH PDP-11 PROCESSOR.
- DETERMINE ALL OF THE T.D.M. BUS ADDRESSES OF THE TRANSMITTERS AND THE RECEIVERS OF THE UNITS WHICH IT IS DESIRED TO BE TESTED. INSURE THAT NO TWO TRANSMITTERS AND NO TWO RECEIVERS HAVE BEEN ASSIGNED THE SAME T.D.M. BUS ADDRESSES.
- RUN THE PCL11 'STANDALONE' TEST (CZPLBA0) WITHOUT ERRORS BEFORE CONNECTING ALL UNITS TOGETHER VIA THE T.D.M. BUS.

4.2 LOADING

THE PCL11 EXERCISER IS SUPPLIED IN ABSOLUTE BINARY FORMAT AND IS LOADED BY MEANS OF THE STANDARD PDP-11 ABSOLUTE LOADER OR THE 'XXDP' LOAD COMMAND.

THE EXERCISER IS APPROXIMATELY 7-K LONG. THEREFORE, WHEN USING 'XXDP', THE PROCESSOR MUST HAVE 16-K OF MEMORY.

THE EXERCISER MUST BE LOADED INTO EACH PDP-11 HOSTING A PCL11 WHICH IS TO BE TESTED.

4.3 DEVICE ADDRESSES

IT MAY BE FOUND THAT THE UNIBUS ADDRESSES OF THE PCL11 UNIT ARE DIFFERENT THAN THE DEFAULT ADDRESSES IN THE EXERCISER (SEE 3.2.13). IF THIS IS THE CASE, AND THERE ARE NO OTHER DEVICES ON THE UNIBUS WITH THE ADDRESSES 164200-164226, THE FOLLOWING PRINTOUT WILL OCCUR:

'DEVICE ADDRESS ERROR. USE 'ASSIGN' COMMAND'

ALSO, IT MAY BE THE CASE THAT THERE IS MORE THAN ONE PCL11 UNIT HOSTED BY ONE PDP-11 AND EACH ONE MUST BE TESTED 'ON-LINE' USING THE EXERCISER.

IN EITHER CASE, THE OPERATOR MUST USE THE 'ASSIGN' COMMAND AS SHOWN IN SECTION 3.2.13 TO ASSIGN THE CORRECT UNIBUS ADDRESSES TO THE EXERCISER IN ORDER TO EXERCISE THE RIGHT PCL11.

NOTE THAT THE EXERCISER WILL RUN WITH ONLY ONE PCL11 PER PDP-11 AT A TIME.

EX
--
CH
--
CN
CN
CN
CN
CN
RU
CA
LI

4.4 STARTING ADDRESSES

THE EXERCISER STARTING ADDRESS IS 200
THIS WILL INITIALIZE EVERYTHING AND START IN COMMAND INPUT MODE.

THE EXERCISER IS RESTARTED AT LOCATION 204
THIS WILL PRESERVE THE ERROR TABLES, STATUS TABLE, AND THE
RECEIVER ADDRESS QUEUE. IT WILL NOT, HOWEVER, PRESERVE THE
STATE OF THE TRANSMITTER ADDRESS SILO (HARDWARE CLEARED BY 'RESET')
NOR THE STATE OF 'MASTER' OR 'SECONDARY'. THESE UNPRESERVED
STATES MUST BE RE-ESTABLISHED PRIOR TO STARTING THE EXERCISE MODE
WITH THE 'GO' COMMAND.

START = 200
RESTART = 204

4.5 OPERATING PROCEDURES

-
- A) LOAD THE PROGRAM USING THE PDP-11 ABS LOADER OR THE LOAD
COMMAND OF 'XXDP'. (SEE 4.2)
 - B) LOAD ADDRESS 200; PRESS START. THE TEST WILL IDENTIFY
ITSELF AND TEST THE DEVICE ADDRESSES.
 - C) IF THE PCL11 UNIBUS ADDRESSES OF THE UNIT TO BE TESTED
ARE NON-STANDARD, USE THE 'ASSIGN' COMMAND AS IN 3.2.13
 - D) DO A) TO C) (ABOVE) ON ALL PDP-11S BEFORE CONTINUING.
 - E) ASSIGN ONE OF THE UNITS AS MASTER EITHER BY USING THE
'MASTER SET' COMMAND, (SEC. 3.2.2) OR BY LOADING THE
XMTR ADDRESS SILO (SEC. 3.2.1) ON THE SELECTED UNIT.
 - F) AT EACH UNIT, DECIDE WHETHER IT IS DESIRED TO RUN THE
TRANSMITTER IN THE 'RE-TRY - IF - BUSY' MODE AND SET OR
CLEAR 'RIB' ACCORDINGLY (SEC. 3.2.4).
 - G) AT EACH UNIT, ENTER THE RECEIVER ADDRESSES OF ALL THE
RECEIVERS THAT THIS TRANSMITTER IS TO COMMUNICATE TO,
INCLUDING THE ADDRESS OF ITS OWN RECEIVER. (3.2.6 OR 3.2.5)
 - H) ON EACH UNIT, TYPE 'GO' TO START THE EXERCISER(S).
 - I) PERIODICALLY, ON EACH UNIT, TYPE CNTRL-C, THEN ISSUE THE
'STATUS' COMMAND TO INSURE THAT ALL RECEIVERS ARE BEING
TALKED TO AND THAT THE CORRECT UNIT IS MASTER.
 - J) ALSO PERIODICALLY, ON EACH UNIT, ISSUE THE 'SUMMARY'
COMMAND TO DISCOVER IF THERE HAVE BEEN ANY ERRORS.
 - K) AT ANY TIME, THE 'ERRORS' COMMAND MAY BE ISSUED TO
DETERMINE WHICH ERRORS HAVE OCCURRED BETWEEN WHICH
RECEIVER AND TRANSMITTER CONNECTION.
 - L) TO RESUME EXERCISING AS BEFORE ON ANY UNIT, TYPE
'CONTINUE' ON THE UNITS WHICH HAD BEEN STOPPED BY

CNTRL-C. (OR MASTER DOWN).

N 2

SEQ 0026

ER

--

4.6 ERRORS

A LIST OF ERROR NUMBERS MAY BE FOUND IN APPENDIX C OF THIS DOCUMENT. THESE 'ERROR NUMBERS' ARE THOSE REFERRED TO IN THE SUMMARY TABLE AND IN THE ERRORS TABLES. A LITTLE MORE DETAIL MAY BE DETERMINED ABOUT THE ERROR BY REFERRING TO THE PROGRAM LISTING AROUND THE ADDRESS SHOWN IN THE SUMMARY TABLE. THE LISTING WILL HAVE, IN THE COMMENT FIELD, THE ERROR IDENTIFIER:

**** XMTR ERROR N **** OR:

**** RCVR ERROR N ****

WHERE 'N' IS THE ERROR NUMBER. ABOVE THIS IDENTIFIER, WILL BE THE DESCRIPTION OR CAUSE OF THE ERROR WITH THAT NUMBER.

IT MAY BE NOTED THAT THE TRANSMITTER ERRORS ARE NUMBERED FROM 1 TO 15 (OCTAL), AND THE RECEIVER ERRORS ARE NUMBERED FROM 16 TO 30 (OCTAL). THIS IS DONE SO THAT ONLY ONE TABLE IS REQUIRED TO SUMMARIZE ALL THE ERRORS (SUMMARY TABLE).

IF THERE IS AN ALARMING NUMBER OF OCCURRENCES OF ERRORS, THE FOLLOWING STEPS SHOULD BE TAKEN:

- A) DETERMINE THE ERROR CAUSE (FROM APPENDIX C)
- B) DETERMINE WHICH TRANSMITTER AND/OR RECEIVER ARE SUSPECT (FROM THE ERRORS TABLES)
- C) IF THE ERROR WAS NOT 'MASTER DOWN' (ERROR 10), RUN THE PCL11 'STANDALONE TEST' (YC-2017D-08) ON THE UNITS WITH THE SUSPECTED RECEIVER OR TRANSMITTER. SEE IF THE SAME ERROR TYPE CAN BE ACHIEVED WITH THE 'STANDALONE TEST'. IF NOT, THEN THE T.D.M. DRIVERS, OR CABLES, OR TERMINATORS ETC. ARE SUSPECT.
- D) IF THE ERROR WAS 'ERROR 10' BUT THIS ERROR HAD NOT OCCURRED ON OTHER UNITS, THE CABLE, OR RECEIVER CHIPS ETC. ARE AGAIN SUSPECT.
- E) USING EITHER THE EXERCISER, OR THE STANDALONE TEST, A DEFECTIVE SINGLE MODULE SHOULD BE RELATIVELY SIMPLE TO LOCALIZE AND REPLACE, CORRECTING THE PROBLEM.
- F) ONCE A MODULE HAS BEEN REPLACED, ALWAYS RUN THE PCL11 STANDALONE TEST (EVEN IF IT WAS A LINE DRIVER MODULE) BEFORE RUNNING THE EXERCISER.

A SMALL NUMBER OF CERTAIN ERRORS IS ACCEPTABLE DURING A LONG EXERCISE RUN. THESE ERRORS WOULD BE ATTRIBUTED TO LINE NOISE, GENERAL SYSTEM NOISE ETC. THESE ERRORS ARE:

ERROR 6 TRANSMITTER CRC ERROR
 ERROR 7 TRANSMITTER MISCELLANEOUS TXM ERROR

ERROR 22 RECEIVER CRC ERROR
 ERROR 24 RECEIVER PARITY ERROR

5 COMMAND MODE DESCRIPTION

5.1 SHORTENED COMMANDS

ANY OF THE COMMANDS MAY BE TYPED IN AS SHORT A FORM AS WOULD SEEM REASONABLE. THAT IS, ONLY ENOUGH LETTERS NEED BE TYPED SO AS TO DISTINGUISH ONE COMMAND FROM ANOTHER WITH THE SAME FIRST LETTER.

FOR EXAMPLE, SINCE THERE IS ONLY ONE COMMAND BEGINNING WITH THE LETTER 'E' (ERRORS), ONLY THE 'E' NEED BE TYPED FOR THAT COMMAND. HOWEVER, THERE ARE FOUR COMMANDS BEGINNING WITH THE LETTER 'S' (SUMMARY, STATUS, SILO, AND SECONDARY). IN EACH OF THESE COMMANDS, THE SECOND LETTER IS DIFFERENT, SO JUST TWO LETTERS NEED BE TYPED: (SU, ST, SI, AND SE).

ON THE OTHER HAND, THE COMMAND DECODER WILL NOT ACCEPT ANY COMMAND WORDS WITH ANY OF THE LETTERS WRONG. THAT IS, EVERY LETTER TYPED IN FOR A PARTICULAR COMMAND MUST BE AT LEAST ON THE WAY TO SPELLING THE WORD CORRECTLY.

FOR EXAMPLE: FOR THE "INITIALIZE" COMMAND:

INITIAL IS ACCEPTABLE, WHEREAS:
INITL IS UNACCEPTABLE.

5.2 RUBOUT FEATURES

THERE ARE TWO EDITING FEATURES EMPLOYED IN THE COMMAND DECODER. "RUBOUT" (DELETE) CHARACTER WILL DELETE THE LAST CHARACTER WHICH WAS TYPED IN AS PART OF A COMMAND WORD OR ARGUMENT. CONTROL-U CHARACTER WILL REMOVE ALL THAT HAS BEEN TYPED IN SO FAR ON THIS LINE.

ONE OTHER METHOD OF HAVING THE EXERCISER IGNORE EVERYTHING TYPED IN SO FAR IS TO TYPE "CONTROL-C".

- A) RUBOUT DELETE LAST CHARACTER
- B) CNTRL-U DELETE THIS LINE
- C) CNTRL-C DELETE THIS LINE

5.3 ENTERING COMMAND MODE

COMMAND MODE IS AUTOMATICALLY ENTERED AT STARTUP OR RESTART OF THE EXERCISER. THERE ARE TIMES, HOWEVER, WHEN IT IS NOT IN "COMMAND" MODE. THEY ARE:

- A) WHEN IN EXERCISE MODE (RUNNING)
- B) WHILE PRINTING THE STATUS, SUMMARY, OR ERRORS TABLES

AT ANY TIME THAT IT IS DESIRED TO ENTER COMMAND MODE, THE OPERATOR NEED ONLY TYPE "CONTROL-C" (^C). THIS WILL TERMINATE ALL TRANSMITTER ACTIVITY ON THE UNIT AND ENTER COMMAND MODE. IT WILL ALSO, (AT COMPLETION OF THE CURRENT LINE), TERMINATE ALL TABLE PRINTING AND RETURN TO COMMAND MODE.

THERE IS ANOTHER CHARACTER WHICH WILL PERFORM THE SAME AS CONTROL-C DUE TO ITS FUNCTION; THAT IS CONTROL-U.

5.4 UPPER OR LOWER CASE

WHEN IN COMMAND MODE, THE OPERATOR MAY FIND HIMSELF USING A KEYBOARD WHICH DOES NOT HAVE A "CAPS LOCK" KEY. SINCE THE COMMAND DECODER REQUIRES THAT ALL INPUT BE IN CAPITAL LETTERS, THE KEYBOARD INPUT ROUTINE WILL AUTOMATICALLY CONVERT ALL LOWER CASE ALPHA CHARACTERS INTO UPPER CASE ALPHA CHARACTERS BY CLEARING BIT05 IN THE ASCII CODE OF THE INPUT CHARACTER.

6 EXERCISER MODE DESCRIPTION

6.1 TRANSMIT EVENT

AN 'EVENT FLAG' IS CHECKED IN THE MAIN LOOP OF THE PROGRAM TO DETERMINE WHETHER THE EXERCISER HAS BEEN TOLD TO 'GO'. THIS FLAG IS THE TRANSMIT EVENT FLAG. IT IS SET WHENEVER THE OPERATOR ISSUES THE 'GO' COMMAND, OR THE 'CONTINUE' COMMAND TO THE EXERCISER. THIS FLAG IS CLEARED WHENEVER THE OPERATOR TYPES CONTROL-C OR IF A MASTER DOWN ERROR OCCURS.

WHEN THE FLAG IS DETECTED AS BEING SET, THE EXERCISER CALLS THE TRANSMITTER MODULE WHICH TRANSMITS A BLOCK OF DATA THAT HAD BEEN PREVIOUSLY GENERATED BY THE DATA GENERATION MODULE. IF THIS DATA HAS ALREADY BEEN USED FOR THE FIFTH TIME, IT SETS THE DATA GENERATION EVENT FLAG AND NEW RANDOM DATA WILL BE GENERATED. WHEN THE TRANSMIT MODULE IS CALLED, THE TRANSMIT EVENT FLAG IS CLEARED AND IS NOT SET AGAIN UNTIL SOME TYPE OF 'COMPLETION' INTERRUPT HAS OCCURRED SUCH AS 'SUCCESSFUL TRANSFER' OR 'ERROR'.

THE TRANSMIT EVENT IS ALSO RESPONSIBLE FOR UPDATING THE ERROR TABLES FOR TRANSMITTER ERRORS, AND ALSO THE STATUS TABLE FOR ATTEMPTS AND SUCCESSES TO EACH RECEIVER IN THE RECEIVER ADDRESS QUEUE.

6.2 RECEIVE EVENT

WHEN THE EXERCISER IS STARTED BY THE OPERATOR STARTING AT LOCATION 200, A SOFTWARE FLAG CALLED 'RECEIVER EVENT FLAG' IS SET. WHEN THIS IS DETECTED IN THE MAIN LOOP, THE RECEIVER MODULE IS CALLED TO SET UP THE RECEIVER TO RECEIVE UP TO 600 (OCTAL) WORDS FROM A TRANSMITTER THAT TRIES. WHEN THE MODULE IS CALLED, THE FLAG (RCVR EVENT) IS CLEARED AND NOT SET AGAIN UNTIL SOME TYPE OF COMPLETION INTERRUPT IS RECEIVED SUCH AS 'SUCCESSFUL TRANSFER', 'ERROR', OR 'REJECT COMPLETED'.

THE RECEIVE EVENT IS ALSO RESPONSIBLE FOR UPDATING THE ERROR TABLES FOR RECEIVER ERRORS, AND FOR CHECKING THE DATA RECEIVED TO DETERMINE ITS CORRECTNESS AND THAT THE RIGHT NUMBER OF WORDS WERE RECEIVED.

UNLIKE THE TRANSMIT EVENT, THE RECEIVE EVENT CANNOT BE SUSPENDED BY THE OPERATOR ISSUING ANY COMMANDS OR CONTROL CHARACTERS. HALTING THE EXERCISER, OR A HARDWARE FAILURE TO INTERRUPT ARE THE ONLY WAYS TO PREVENT THE RECEIVE EVENT FROM OCCURRING.

6.3 DATA GENERATION EVENT

ANOTHER EVENT WHICH OCCURS IN EXERCISE MODE IS 'DATA GENERATION'. A NEW BUFFER FULL OF RANDOM DATA IS GENERATED AFTER 5 PASSES WITH THE OLD DATA ARE COMPLETED. THE LENGTH OF THE DATA BUFFER ALSO RANDOMLY VARIES FROM 1 TO 1000 (OCTAL) WORDS. IF THE BUFFER IS LONGER THAN 600 WORDS, THE RECEIVER WILL BE EXPECTED TO TRUNCATE THE MESSAGE AFTER RECEIVING THE 600TH WORD.

ALSO, IF THE FIRST WORD OF THE BUFFER ('FLAGS' WORD) HAS THE FOUR MOST SIGNIFICANT BITS SET, THE RECEIVER WILL REJECT THE MESSAGE ENTIRELY. ALL OF THESE 'REJECT' AND 'TRUNCATE' OCCURRENCES ARE EXPECTED BY THE TRANSMITTER EVENT AND CHECKS ARE MADE THAT THEY OCCUR AS THEY SHOULD.

6.4 ADDRESS QUEUE EVENT

WHEN THE USER HAS COMPLETED GENERATING THE LIST OF RECEIVER ADDRESSES HE WISHES A PARTICULAR TRANSMITTER TO COMMUNICATE WITH, THE STATUS TABLE HAS THOSE ENTRIES 'ACTIVATED'. DURING EXERCISE MODE ACTIVE ADDRESSES IN THE STATUS TABLE ARE LOADED INTO A SOFTWARE QUEUE TO AWAIT THEIR TURN WITH THE TRANSMIT MODULE. ADDRESSES ARE DEQUEUED ON EVERY ENTRANCE TO THE TRANSMIT MODULE AND THE 'ATTEMPTS' ENTRY OF THE STATUS TABLE IS UPDATED. WHEN THE QUEUE IS EMPTY, THE ADDRESS QUEUE EVENT IS CALLED TO RE-FILL IT FROM THE STATUS TABLE.

NOTE THAT ADDRESSES ARE ALWAYS QUEUED AND DEQUEUED IN NUMERICAL ORDER REGARDLESS OF THE ORDER IN WHICH THEY WERE ENTERED.

6.5 ERRORS UPDATE EVENT

AT ANY TIME, WHETHER THE EXERCISER IS IN 'EXERCISE' MODE OR COMMAND MODE, THE RECEIVE EVENT IS ACTIVE. THEREFORE, RECEIVER ERRORS CAN OCCUR AT ANY TIME. HOWEVER, TRANSMITTER ERRORS CAN ONLY OCCUR WHEN THE EXERCISER IS 'GOING'. WHEN AN ERROR OCCURS, OF THE TRANSMITTER TYPE, THE TRANSMITTER COMMAND REGISTER (TCR) IS READ TO GET THE ADDRESS OF THE CONNECTED RECEIVER. THIS IS USED TO DECIDE WHICH TRANSMITTER ERROR TABLE LOCATION TO INCREMENT ALONG WITH THE ERROR NUMBER. THIS UPDATE IS ACCOMPLISHED AT THE ACTUAL TIME THAT THE ERROR IS DISCOVERED. WHEN AN ERROR OF THE RECEIVE TYPE OCCURS THE RECEIVER COMMAND REGISTER (RCR) IS READ TO GET THE ADDRESS OF THE CONNECTED TRANSMITTER. AGAIN, THIS IS USED TO DETERMINE THE CORRECT TABLE LOCATION TO INCREMENT.

AGAIN, PLEASE NOTE THAT THE 'GO' COMMAND CLEARS BOTH THE TRANSMITTER ERROR TABLES AND THE RECEIVER ERROR TABLES.

ANOTHER FUNCTION OF THE ERRORS EVENT IS TO UPDATE THE 'SUMMARY' TABLE ACCORDING ONLY TO THE ERROR NUMBER.

THERE ARE, THEN, ACTUALLY TWO ERROR EVENTS: ONE FOR TRANSMITTER ERRORS, AND ONE FOR RECEIVER ERRORS.

6.6 SPECIAL EVENTS

DURING AN EXERCISE RUN, THERE ARE TWO INTERRUPTS THAT CAN CAUSE PRINTOUTS ON THE CONSOLE. ONE OF THEM IS MASTER GOING DOWN. THIS WILL CAUSE THE CALLING OF A 'SPECIAL' EVENT TO PRINT THE MESSAGE:

*** MASTER DOWN ***

AND RETURN THE EXERCISER TO COMMAND MODE. THE OTHER INTERRUPT IS CAUSED BY THIS UNIT BECOMING 'MASTER' AFTER HAVING BEEN 'SECONDARY'. THIS WILL CAUSE THE CALLING OF ANOTHER 'SPECIAL' EVENT TO PRINT THE MESSAGE:

** THIS UNIT HAS BECOME 'NEW MASTER' **

AND LEAVE THE EXERCISER IN 'EXERCISE MODE.

APPENDIX A, B, C, D

OVERALL FLOW

[S]-----START

I
LOAD & TRY
DEVICE ADDRESSES

I
INITIALIZE

I
RESTART

[A]-----MAIN LOOP

I
TIQ NOT
EMPTY

<PROCHR>
PROCESS
CHARACTER-----

I PRCTLC I
I PRDEL I
I PRCTLS I
I PRCTLO I-----[A]
I PRCR-LF I
I PRCTLU I
I PRCTLO I

I
TOQ NOT
EMPTY

I DEQUEUE TOO I
I TO TRY IF I-----[A]
I READY I


I
OLDEV
EVENT SET

I LOAD ADDRESS I
I QUEUE. IF NO- I
I THING LOADED, I
I FLAG ERROR, & I-----[A]
I DON'T ALLOW I
I STARTUP I


I
DATGEN
EVENT SET

I GENERATE NEW I
I RANDOM DATA I
I TABLE FOR NEXT I-----[A]
I 5 CYCLES. I

I
▽27
▽



37



I
[A]

K 3

SEQ 0036

CZ
PC

EXERCISER COMMANDS

CONTROL CHARACTERS

CHARACTER	ECHOES	EFFECT
CNTRL-C	^C	ENTER COMMAND INPUT MODE
CNTRL-O	^O	THROW AWAY TTY OUTPUT
CNTRL-U	^U	DISCARD CURRENT INPUT LINE
CNTRL-S		SUSPEND TTY OUTPUT
CNTRL-Q		RESUME TTY OUTPUT
RUBOUT	\	DELETE LAST INPUT CHARACTER
CAR RET	<CR, LF>	PERFORM COMMAND JUST ENTERED
LINE FEED	<CR, LF>	SAME AS CAR RET

COMMANDS

COMMAND	ARGUMENTS	MINIMUM	EFFECT
-----	-----	-----	-----
[AD]D	A B C - N	AD A	ADD ADDRESSES A B C - N
[AS]SIGN	ADR VCT ADR VCT	AS	ASSIGN UNIBUS ADDRESSES AND VECTORS FOR TRANSMITTER AND RECEIVER.
[CL]EAR	-	CL	CLEAR THE STATUS TABLE
[CO]NTINUE	-	CO	CONTINUE EXERCISING
[D]ELETE	A B C - N	D A	DELETE ADDRS A B C - N
[E]RRORS	-	E	PRINT ERRORS TABLES
[G]O	-	G	START THE EXERCISER
[I]NITIALIZE	-	I	INIT THE EXERCISER
[M]ASTER	SET	M S	SET 'MASTER'
[M]ASTER	CLEAR	M C	CLEAR 'MASTER'
[RA]NGE	LOW HI	RA L H	ADD RANGE OF ADDRESSES FROM LOW TO HIGH INCLUSIVE.
[RI]B	SET	RI S	SET 'RIB'
[RI]B	CLEAR	RI C	CLEAR 'RIB'
[SE]CONDARY	SET	SE S	SET 'SECONDARY'
[SE]CONDARY	CLEAR	SE C	CLEAR 'SECONDARY'
[SI]LO	-	SI	CLEAR SILO; SET AUTO ADDR
[SI]LO	A B C - N	SI A	LOAD SILO WITH A B C - N
[ST]ATUS	-	ST	PRINT STATUS TABLE
[SU]MMARY	-	SU	PRINT SUMMARY TABLE

C-1

ERROR DESCRIPTIONS

ERROR NUMBER	DESCRIPTION
-----	-----
1	ERRONEOUS INTERRUPT FROM TRANSMITTER
2	NON EXISTANT LOC. ERROR IN XMTR
3	MEM OVERFLOW ERROR IN TRANSMITTER
4	XMTR TXM ERROR: RCVR ACCEPTED A NULL
5	XMTR TXM ERROR: RCVR HAS GONE OFF-LINE
6	XMTR TXM ERROR: WORD OR C.R.C. REJECTED
7	XMTR TXM ERROR: MISCELLANEOUS TXM ERROR
10	MASTER DOWN
11	TRANSMITTER TIMED OUT
12	SILO OVERRUN ERROR IN TRANSMITTER
13	MESSAGE TRUNCATED UNEXPECTEDLY
14	MESSAGE FAILED TO BE TRUNCATED
15	ERRONEOUS REJECT BY RECEIVER
16	UNKNOWN RECEIVER INTERRUPT OCCURRED
17	NON-EXISTANT LOC. ERROR IN XMTR
20	MEM OVERFLOW ERROR IN RECEIVER
21	RCVR TXM ERROR: XMTR HAS GONE OFF-LINE
22	RCVR TXM ERROR: RCVR C.R.C. ERROR
23	RCVR TXM ERROR: FIRST WORD INVALID
24	RECEIVER DETECTED INVALID PARITY.
25	RECEIVER TIMEOUT ERROR OCCURRED
26	RECEIVER GOT TOO MANY WORDS
27	DATA WORD RECEIVED WAS BAD
30	RECEIVER GOT TOO FEW WORDS

D-1

STATISTICAL INFORMATION

```

-----
STARTING ADDRESS          200
RESTARTING ADDRESS       204
SWITCH OPTIONS           NONE
PROGRAM SIZE             APPROX 7K
MEMORY OCCUPIED
  LOW BOUNDARY           00000
  HIGH BOUNDARY          34474

```

 LOCATIONS TO CHANGE FOR
 DIFFERENT DEVICE ADDRESSES

DEVICE	CHANGE LOCATION
-----	-----
KEYBOARD STATUS	16136
KEYBOARD DATA	16140
TTY STATUS	16142
TTY DATA	16144
KEYBOARD VECTOR	16146
LINE CLK STATUS	16150
XMTR PRIORITY	2334
RCVR PRIORITY	2346
KBD PRIORITY	2360

USEFUL LOCATIONS	ADDRESS
-----	-----
XMTR DATA BUFFER	20666
RCVR DATA BUFFER	22726
DATA SEED IN TRANSMITTER	17726
RANDOM MULTIPLIER	17746
RANDOM INCREMENT	17750

284	DEFINITIONS AND DEVICE INFO
367	PCL11 EXERCISER MAIN PROCEDURE
489	MAIN LOOP
546	COMMAND PROCESSORS:
547	COMMAND PROC. FOR SILO (LOAD)
644	COMMAND PROC. FOR MASTER, SECONDARY AND R.I.B.
713	COMMAND PROC. FOR RANGE
758	COMMAND PROC. FOR ADD AND DELETE
825	COMMAND PROC. FOR CLEAR, STATUS, AND CONTINUE
894	COMMAND PROC. FOR INIT, SUMMARY, AND GO
1008	COMMAND PROC. FOR 'ASSIGN'
1103	COMMAND DECODER AND PROCESSOR
1199	RECEIVER ADDRESS QUEUE LOADER ROUTINE
1243	DATA GENERATION (RANDOM) ROUTINE
1288	MULTIPLY ROUTINE FOR DATA GENERATION
1322	TRANSMIT MODULE
1534	RECEIVER MODULE
1716	STATUS MODULE
1809	TRANSMITTER ERRORS MODULE
1864	RECEIVER ERRORS MODULE
1915	SUMMARY MODULE
1971	ERROR UPDATE ROUTINES
1972	TRANSMITTER ERRORS
2010	RECEIVER ERRORS
2049	UTILITY ROUTINES
2050	PROCESS AN INPUT CHARACTER FROM THE TTY
2072	TTY INPUT CHARACTER PROCESSING ROUTINES
2207	TTY OUTPUT HANDLERS
2225	TTY INPUT INTERRUPT PROCESSORS
2236	MESSAGE PRINT ROUTINE
2265	DATA AREAS
2472	KEYWORD TABLE
2533	SOME MORE ASCII STORAGE:
2590	AUXILIARY ROUTINES
2591	CHARACTER PROCESSOR
2634	BINARY TO ASCII CONVERSION
2737	GENERAL BINARY TO ASCII CONVERSION
2786	DOUBLE PRECISION BINARY TO ASCII
2873	DOUBLE PRECISION DIVIDE ROUTINE
2909	INTEGER DIVIDE MAGNITUDE NUMBERS
2954	QUEUE HANDLING ROUTINES
3077	COMMAND PROCESSOR INITIATING ROUTINE
3122	KEYWORD PROCESSING ROUTINE
3211	REGISTER SAVE & RESTORE ROUTINES
3238	LEXICAL SCAN ROUTINE

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56

```
.TITLE CZPLABO PCL11 EXERCISER V02
.IDENT /0003/ ;DRCMAC.MAC 6-JAN-76

; KEYWD MACRO

; THIS MACRO DETERMINES THE ROUTINE ADDRESS
; ASSOCIATED WITH THE SYNTACTIC OBJECT OBJ, ACCORDING
; TO A KEYWORD TABLE POINTED TO BY KWTABL.

; ON RETURN, IF OBJ WAS IN THE TABLE, THEN THE PS
; C BIT = 0 & THE ROUTINE ADDRESS IS AT THE TOP OF THE
; STACK. IF NOT, THEN C=1 & @SP = 0.

; EACH KEYWORD IN THE TABLE HAS ASSOCIATED WITH IT A
; MINIMUM LENGTH SPECIFYING THE MINIMUM NUMBER
; OF CHARACTERS IN THE KEYWORD THAT MUST MATCH
; THOSE IN OBJ FOR A MATCH TO HAVE BEEN DEEMED
; FOUND. IF OBJ CONTAINS MORE THAN THIS MINIMUM
; NO. OF CHARACTERS, THOUGH, ALL CHARACTERS IN OBJ MUST
; CORRESPOND TO THE TABLE KEYWORD FOR A MATCH TO
; HAVE BEEN DEEMED FOUND. THUS, FOR EXAMPLE, IF
; 'REPEAT' APPEARS IN THE KEYWORD TABLE WITH A
; MINIMUM LENGTH OF 3 ASSOCIATED WITH IT, THEN
; 'REP', 'REPE', 'REPEA', & 'REPEAT' WILL ALL MATCH IT, BUT
; 'R', 'RPT', 'REPEET', & 'REPEATER' WILL NOT.

; THE KEYWORD TABLE CONSISTS OF A SET OF ENTRIES AS FOLLOWS:
;
; OFFSET TYPE
; 0 WORD ROUTINE ADDRESS
; 2 BYTE MINIMUM LENGTH OF KEYWORD
; 3 BYTE FULL LENGTH OF KEYWORD
; 4 STRING KEYWORD

; ENTRIES ARE STORED CONSECUTIVELY IN THE TABLE. EACH ENTRY
; MUST BEGIN ON A WORD BOUNDARY. THE KEYWORD OF
; THE PREVIOUS ENTRY MAY HAVE TO HAVE A BYTE (CONTAINING
; ANYTHING) APPENDED TO IT TO ACCOMPLISH THIS.
; ENTRIES MUST BE ARRANGED IN ALPHABETICAL
; ORDER (MORE SPECIFICALLY, IN ASCII COLLATING SEQUENCE).
; THE TABLE IS ENDED BY AN ENTRY WITH A FULL LENGTH
; OF 0.

; .MACRO KEYWD OBJ,KWTABL
; .IF NB OBJ
; MOV OBJ,-(SP)
; .IF B KWTABL
; .ERROR ;CANNOT SPECIFY OBJ & NOT TABLE ADDRESS.
; MOV #1,-(SP) ;IF RUN, THIS WILL CAUSE TRAP.
; .ENDC
; .ENDC
; .IF NB KWTABL
; MOV KWTABL,-(SP)
; .ENDC
; JSR PC,KEYWD
```

57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112

```

                                .ENDM ;KEYWD
: -----
:
:       LXSCAN MACRO
:
:       THIS MACRO CALLS THE ROUTINE LXSCAN TO CONVERT THE CHARACTER
:       STRING SPECIFIED BY STR INTO ITS CONSTITUENT SYNTACTIC OBJECTS.
:       STR IS AN ASSEMBLER EXPRESSION SPECIFYING THE ADDRESS OF THE
:       BEGINNING OF THE ASCII STRING TO BE CONVERTED. THE STRING
:       MUST BE ENDED BY A CARRIAGE RETURN CODE.
:
:       .MACRO LXSCAN STR
:       MOV   STR,R1
:       JSR   R1,_LXSCAN
:
:       .ENDM ;LXSCAN
: -----
:
:       PROC MACRO
:
:       THIS MACRO DEFINES THE ENTRY POINT FOR A PROCEDURE. THE PARAMS
:       SPECIFIED WILL BE GIVEN THEIR CORRESPONDING OFFSETS RELATIVE TO R5.
:       THUS, A PARAMETER PP CAN BE REFERENCED IN THE PROCEDURE BY THE
:       ASSEMBLER EXPRESSION '@PP(R5)'. THE PROCEDURE CAN BE CALLED
:       USING THE CALL MACRO.
:
:       .MACRO PROC PNAME,PARAMS
:       = 0
:
:       .IRP ZX2 <PARAMS>
:       ZX1 ZX1+2
:       .IRP ZX3 \ZX1
:       .LIST
:       ZX2 ZX3
:       .NLIST
:       .ENDM
:       .ENDM ;ZX2
:
:       .LIST
:
:       PNAME: ;**ENTRY POINT**
:
:       .NLIST
:       .ENDM ;PROC
: -----
:
:       RETURN MACRO
:
:       THIS MACRO RETURNS FROM A PROCEDURE. IF ANSWR IS SPECIFIED IT
:       WILL BE LOADED INTO R0 BEFORE RETURNING.
:
:       .MACRO RETURN ANSWR
:       .IF
:       NB ANSWR
:       MOV ANSWR,R0

```

```

113      .ENDC
114      RTS      FC
115      .ENDM    ;RETURN
116
117      : -----
118
119      :      CALL MACRO
120
121      :      THIS MACRO CALLS A PROCEDURE, SUBR, WITH AN ARGUMENT LIST SPECIFIED
122      :      BY ARGS.  ARGS IS A LIST OF ADDRESSES WHICH WILL BE INCLUDED
123      :      IN THE ASSEMBLED EXPANSION OF THIS MACRO.
124
125      :      THE CALLING SEQUENCE GENERATED IS FORTRAN COMPATIBLE.  R5 IS LEFT
126      :      INTACT THROUGH THE EXECUTION OF THIS MACRO.  OTHER REGISTERS
127      :      ARE DESTROYED.
128      :
129      :      .MACRO  CALL      SUBR,ARGS,?PLIST,?ZXCALL
130      :      JSR      R5,ZXCALL
131      PLIST:  BR        ZXCALL
132      .IF     NB      <ARGS>
133      :      .WORD   ARGS
134      .ENDC
135      ZXCALL: JSR      PC,SUBR
136      :      MOV      (SP)+,R5
137
138      :      .ENDM    ;CALL
139
140      : -----
141
142      :      MACRO TO MULTIPLY A NUMBER BY A CONSTANT.
143      :      THE NUMBER IN DST IS MULTIPLIED BY THE VALUE OF THE EXPRESSION
144      :      CONST; THE RESULT IS LEFT IN DST.  A TEMPORARY LOCATION MAY
145      :      BE SPECIFIED AT WORK WHICH WILL BE USED IN THE MACRO EXPANSION
146      :      IF NECESSARY.  IF WORK IS NOT SPECIFIED & A TEMPORARY LOCATION
147      :      IS NEEDED, A STACK ELEMENT WILL BE ALLOCATED (& SUBSEQUENTLY
148      :      DEALLOCATED) FOR THE PURPOSE.  THE MACRO GENERATES A SERIES OF
149      :      SHIFT & ADD INSTRUCTIONS IN-LINE TO ACCOMPLISH THE MULTIPLICATION.
150      :
151      :      .MACRO  MULT      CONST,DST,WORK
152      ZX1      =          0          ;FLAG: 0==>LEAST SIG 1-BIT NOT TESTED
153      :          :          YET; 1==>OPPOSITE.
154      ZX2      CONST      ;COPY CONSTANT FOR SHIFTING.
155
156      .IF     Z          ZX2
157      :      CLR      DST
158      :      .MEXIT
159      .ENDC
160
161      .REPT   16.
162      .IF     NZ          ZX2&1          ;IF BIT 0 - 1
163      ZX2      ZX2/2      ;SHIFT CONSTANT RIGHT 1 POSITION.
164      .IF     Z          ZX1          ;IF LEAST SIG 1-BIT
165      .IF     NZ          ZX2          ;IF NOT MOST SIG 1-BIT
166      .IF     NB          WORK        ;IF WORK SPECIFIED
167      :      MOV      DST,WORK
168      .IFF          ;ELSE IF WORK BLANK

```

```

169             MOV     DST,-(SP)
170             .ENDC           ;END [.IF NB WORK]
171             .IFF           ;ELSE IF MOST SIG 1-BIT
172             .MEXIT
173             .ENDC           ;END [.IF NZ ZX2]
174             ZX1     -      1 ;INDICATE NO LONGER LEAST SIG 1-BIT.
175             .IFF           ;ELSE IF NOT LEAST SIG 1-BIT
176             .IF     NZ     ZX2 ;IF NOT MOST SIG 1-BIT
177             .IF     NB     WORK ;IF WORK SPECIFIED
178             .ADD     DST,WORK
179             .IFF           ;ELSE IF WORK BLANK
180             .ADD     DST,@SP
181             .ENDC           ;END [.IF NB WORK]
182             .IFF           ;ELSE IF MOST SIG 1-BIT
183             .IF     NB     WORK ;IF WORK SPECIFIED
184             .ADD     WORK,DST
185             .IFF           ;ELSE IF WORK BLANK
186             .ADD     (SP)+,DST
187             .ENDC           ;END [.IF NB WORK]
188             .MEXIT
189             .ENDC           ;END [.IF NZ ZX2]
190             .ENDC           ;END [.IF Z ZX1]
191             .IFF           ;ELSE IF BIT 0 - 0
192             ZX2     =      ZX2/2 ;SHIFT CONSTANT RIGHT 1 POSITION.
193             .ENDC           ;END [.IF NZ ZX2&1]
194             .ASL     DST
195             .ENDM           ;END [.REPT 16.] LOOP.
196             .ENDM           ;MULT
197
198             ; -----
199
200             .MACRO HEDING NAM,VER,EDIT,PATCH
201             .TITLE HEDING
202             .IDENT /VER'EDIT'PATCH/
203             .CSECT HEDING
204             .GLOBL HEDING,HEDLEN
205
206             HEDING: .ASCII /NAM'VER'-'EDIT/
207             .IF     B      PATCH
208             .BYTE   40
209             .IFF
210             .ASCII /PATCH/
211             .ENDC
212             HEDLEN =      .-HEDING
213             .ENDM       ;HEDING
214
215             ;MULTIPLY MACRO FOR UNSIGNED MULTIPLY ROUTINE
216
217             .MACRO MULP A,B
218             MOV     A,-(SP) ;SAVE A ON STACK
219             MOV     B,R4    ;SAVE B IN R4
220             JSR    R4,MLI  ;PERFORM MULTIPLICATION
221             .WORD  .+2
222             MOV     (SP)+,B ;PUT PRODUCT INTO B
223             .ENDM       ;MULP
224

```

```
225
226 ;BOARD INIT MACRO FOR CLEARING PCL HARDWARE
227 ;BOARD INIT RECEIVER OR TRANSMITTER.
228
229 .MACRO BDINIT DEV
230 .NLIST
231 .IF IDN <DEV>,<XMTR>
232 BIS #B01,@TCR
233 .IFF
234 .IF IDN <DEV>,<RCVR>
235 BIS #B01,@RCR
236 .IFF
237 .ERROR ;BAD ARGUMENT FOR BDINIT
238 .ENDC
239 .ENDC
240 .LIST
241 .ENDM
242
243 000001 N = 1 ;INITIAL ERROR NUMBER
244
245 ;ERROR MACROS
246
247 .MACRO ERROT P
248 ERADR =
249 CALL ERRMOD,<P,ERADR> ;UPDATE ENTRIES FOR ERROR P
250 N - N+1
251 .LIST
252
253 ;**** XMTR ERROR P ****
254
255 .NLIST
256 .ENDM
257
258 .MACRO ERROR P
259 ERADR =
260 CALL ERRMOD,<P,ERADR>
261 N - N+1
262 .LIST
263
264 ;**** RCVR ERROR P ****
265
266 .NLIST
267 .ENDM
268
269 ;REGISTER SAVE MACRO
270
271 .MACRO REGSAV
272 JSR R5,REGSAV
273 .ENDM
274
275 ;REGISTER RESTORE MACRO
276
277 .MACRO REGRES
278
279
280
```

CZPLABO PCL11 EXERCISER V02
PCLEXR.P11 12-SEP-78 15:13

MACY11 30A(1052) 20-OCT-78 09:48 ^I4 PAGE 1-5

SEQ 0047

281
282

JSR R5,REGRES
.ENDM


```
284 .SBTTL DEFINITIONS AND DEVICE INFO
285
286 .IDENT '02'
287
288 ;COPYRIGHT AUGUST, 1975
289 ;COMPUTER SPECIAL SYSTEMS,
290 ;DIGITAL EQUIPMENT OF CANADA LTD.
291
292 ; VARIABLE SYMBOL DEFINITIONS.
293
294 ; DEVICE DEFAULT INFORMATION.
295 177560 TTDEV = 177560 ;ADDR OF RCSR FOR TTY.
296 000060 TTVCTR = 60 ;INPUT VECTOR ADDR FOR TTY.
297 000004 TTPRIO = 4 ;PRIORITY LEVEL FOR TTY.
298 164200 PCLTXM = 164200
299 164220 PCLRCV = 164220
300 000174 RCVECT = 174
301 000170 TXVECT = 170
302 000005 TXPRIO = 5
303 000005 RCPRIO = 5
304
305 ; QUEUE SIZES.
306 000024 TISIZE = 20. ;TIQ SIZE.
307 000400 TOSIZE = 256. ;TOQ SIZE.
308 000040 AOSIZE = 32. ;ADR QUEUE SIZE
309
310
311
312 000000 QELEMS = 0 ;#ELEMENTS PRESENTLY IN QUEUE.
313 000002 QSIZE = 2 ;#ELEMENTS IN QUEUE SPACE.
314 000004 QTOP = 4 ;ADDR OF 1ST WORD OF QUEUE SPACE
315 000006 QBOT = 6 ;=#QTOP+(QSIZE*2)
316 000010 QFRONT = 10 ;ADDR OF FRONT ELEMENT OF QUEUE.
317 000012 QBACK = 12 ;ADDR OF BACK ELEMENT OF QUEUE.
318
319 ; REGISTER DEFINITIONS.
320 000000 R0 = %0
321 000001 R1 = %1
322 000002 R2 = %2
323 000003 R3 = %3
324 000004 R4 = %4
325 000005 R5 = %5
326 000006 SP = %6
327 000007 PC = %7
328 177776 PS = 177776
329 177570 SR = 177570 ;SWITCH REGISTER.
330
331 ;SPECIAL CHARACTER DEFINITIONS:
332 000012 LF. = 12 ;CR OR LF TO END LINE.
333 000015 CR. = 15 ;
334 000017 CTL.O = 17 ;^O TO THROW AWAY TTY OUTPUT.
335 000025 CTL.U = 25 ;^U TO DELETE LINE.
336 000003 CTL.C = 3 ;CNTRL-C TO START INPUT.(^C)
337 000021 CTL.Q = 21 ;CNTRL-Q TO RESUME PRINTOUT
338 000023 CTL.S = 23 ;CNTRL-S TO SUSPEND PRINTOUT
339 000177 RUBOUT = 177 ;RUB OUT TO DELETE CHARACTER.
```

340
341
342 100000
343 004000
344 000200
345 000100

; DEVICE BIT DEFINITIONS.
ERR = 100000
BUSY = 4000
DONE = 200
INTENB - 100

```
347  
348  
349      100000      B15      =      100000  
350      040000      B14      =      40000  
351      020000      B13      =      20000  
352      010000      B12      =      10000  
353      004000      B11      =      4000  
354      002000      B10      =      2000  
355      001000      B09      =      1000  
356      000400      B08      =      400  
357      000200      B07      =      200  
358      000100      B06      =      100  
359      000040      B05      =      40  
360      000020      B04      =      20  
361      000010      B03      =      10  
362      000004      B02      =      4  
363      000002      B01      =      2  
364      000001      B00      =      1  
365
```

```

367          .SBTTL PCL11 EXERCISER MAIN PROCEDURE
368
369          .ENABL ABS
370          000000          =          0
371          000200          .REPT 128.
372          .WORD          .+2,0          ;TRAP CATCHERS
373
374          .ENDR
375
376          000200          =          200
377 000200 000167 001574          JMP          PCLEX          ;PROGRAM STARTS AT 200
378 000204 012706 002000          MOV          #STKTOP,SP          ;AND RESTARTS AT 204
379 000210 000167 002354          JMP          PCREST
380
381          002000          =          2000
382          002000          RELZRO =          .
383          002000          STKTOP =          .
384
385          002000          PCLEX:          ;*****START HERE*****
386 002000 012706 002000          MOV          #STKTOP,SP          ;SET STACK POINTER TO TOP
387 002004 016700 014156          MOV          TXDEV,R0          ;PREPARE TO GENERATE TXM ADDR
388 002010 010067 014062          MOV          R0,TCR          ;GENERATE TCR ADDRESS
389 002014 062700 000002          ADD          #2,R0
390 002020 010067 014054          MOV          R0,TSR          ;GENERATE TSR ADDRESS
391 002024 062700 000002          ADD          #2,R0
392 002030 010067 014046          MOV          R0,TSDB          ;GENERATE TSDB ADDRESS
393 002034 062700 000002          ADD          #2,R0
394 002040 010067 014040          MOV          R0,TSBC          ;GENERATE TSBC ADDRESS
395 002044 062700 000002          ADD          #2,R0
396 002050 010067 014032          MOV          R0,TSBA          ;GENERATE TSBA ADDRESS
397 002054 062700 000002          ADD          #2,R0
398 002060 010067 014024          MOV          R0,TMMR          ;GENERATE TMMR ADDRESS
399 002064 005200          INC          R0
400 002066 010067 014020          MOV          R0,TMMRH          ;AND TMMR HIGH BYTE
401 002072 005200          INC          R0
402 002074 010067 014014          MOV          R0,TSCRC          ;GENERATE TSCRC ADDRESS
403 002100 016767 014064 014024          MOV          TXVEC,TXMVEC          ;GENERATE TXMVEC ADDRESS
404
405 002106 016700 014060          MOV          RCDEV,R0          ;PREPARE TO GENERATE RCVR ADDR
406 002112 010067 014000          MOV          R0,RCR          ;GENERATE RCR ADDRESS
407 002116 062700 000002          ADD          #2,R0
408 002122 010067 013772          MOV          R0,RSR          ;GENERATE RSR ADDRESS
409 002126 062700 000002          ADD          #2,R0
410 002132 010067 013764          MOV          R0,RDDB          ;GENERATE RDDB ADDRESS
411 002136 062700 000002          ADD          #2,R0
412 002142 010067 013756          MOV          R0,RDBC          ;GENERATE RDBC ADDRESS
413 002146 062700 000002          ADD          #2,R0
414 002152 010067 013750          MOV          R0,RDBA          ;GENERATE RDBA ADDRESS
415 002156 062700 000004          ADD          #4,R0
416 002162 010067 013742          MOV          R0,RDCRC          ;GENERATE RDCRC ADDRESS
417 002166 016767 014002 013740          MOV          RCVEC,RCVVEC          ;GENERATE RCVVEC ADDR

```

```

419 002174          PCRST:          ;*****RESTART HERE *****
420 002174 012706 002000          ;RESET STACK POINTER
421 002200 012737 003340 000004          ;SET UP VECTOR FOR ADDRESS ERROR
422 002206 012737 000340 000006          ;
423 002214 105067 015420          CLRQB REQINP          ;CLR INPUT REQUEST
424 002220 105067 015415          CLRQB CMDENT          ;CLR COMMAND ENTERED FLAG
425 002224 005067 015450          CLR PCLGO            ;CLR XMTR GO FLAG
426 002230 012767 000204 015524          MOV #204,RSHOLD      ;SAVE RESTART ADDRESS
427          .IRP          LC <TI,TO>          ;INITIALIZE IO QUEUES TO EMPT
428          .LIST          CLR LC'Q
429          CLR LC'Q
430          MOV LC'Q+QTOP,LC'Q+QFRONT
431          MOV LC'Q+QTOP,LC'Q+QBACK
432          .NLIST
433          .ENDM
(1) 002236 005067 014276          CLR TIQ
(1) 002242 016767 014276 014300          MOV TIQ+QTOP,TIQ+QFRONT
(1) 002250 016767 014270 014274          MOV TIQ+QTOP,TIQ+QBACK
(1) 002256 005067 014342          CLR TOQ
(1) 002262 016767 014342 014344          MOV TOQ+QTOP,TOQ+QFRONT
(1) 002270 016767 014334 014340          MOV TOQ+QTOP,TOQ+QBACK
434 002276 012737 000340 177776          MOV #340,@#PS          ;DISABLE INTERRUPTS
435 002304 012777 007600 013620          MOV #XMTINT,@TXMVEC    ;:::SET UP XMTR INTR VECTOR
436 002312 012777 011124 013614          MOV #RCVINT,@RCVVEC    ;:::SET UP RCVR INTR VECTOR
437 002320 012777 015642 013620          MOV #TTIINT,@TTVECT    ;:::SET UP TTY INTR VECTOR
438 002326 016700 013600          MOV TXMVEC,R0
439 002332 012760 000240 000002          MOV #TXPRIO*32.,2(R0)  ;:::SET TXM PRIORITY
440 002340 016700 013570          MOV RCVVEC,R0
441 002344 012760 000240 000002          MOV #RCPRIO*32.,2(R0)  ;:::SET RCVR PRIORITY
442 002352 016700 013570          MOV TTVECT,R0
443 002356 012760 000200 000002          MOV #TTPRIO*32.,2(R0)  ;:::SET TTY PRIORITY
444 002364          CALL PNCRLF
445 002400          CALL PNCRLF
446 002414          CALL PNTLIN,<PCLEXM>   ;:::PRINT TITLE MESSAGE
447 002432          CALL PRINIT           ;:::INITIALIZE TRANSMITTER
448 002446 012700 031023          PRST: MOV #RSADD,R0     ;:::BUFFER ADDR FOR OCTPNT IN R1
449 002452 016701 015304          MOV RSHOLD,R1          ;:::DATA FOR OCTPNT IN R0
450 002456 012702 177777          MOV #-1,R2             ;:::DON'T COMPRESS BLANKS
451 002462 004767 030214          JSR PC,OCTJSP          ;:::COMPUTE RESTART ADDRESS
452 002466          CALL PNTLIN,<RSTMSG>   ;:::PRINT RESTART ADDRESS
453 002504 012737 002550 000004          MOV #STR,@#4           ;:::SET UP TO TEST FOR CLOCK
454 002512 005067 015132          CLR KWFLG              ;:::CLEAR KW11 FLAG
455 002516 005777 013426          TST @LCS               ;:::ANY CLOCK?
456 002522 012767 177777 015120          MOV #-1,KWFLG          ;:::YES, SET KW11 FLAG
457 002530 012737 012230 000100          MOV #CLKINT,@#100     ;:::SET UP CLK VECTOR
458 002536 012737 000340 000102          MOV #340,@#102
459 002544 000167 000020          JMP PCREST             ;:::AND CONTINUE
460 002550 022626          STR:  CMP (SP)+,(SP)+  ;:::NO CLOCK, CLEAR STACK
461 002552 005067 015072          CLR KWFLG              ;:::CLR KW11 FLAG
462 002556 012737 000102 000100          MOV #102,@#100        ;:::SET UP TO TRAP HALT
463 002564 005037 000102          CLR @#102
464 002570 005037 177776          PCREST: CLR @#PS
465 002574 012737 002702 000004          MOV #TRAP4,@#4        ;:::ALLOW INTERRUPTS
466 002602 052767 100000 015072          BIS #B15,RCVEV         ;CHANGE TRAP VECTOR FOR ERROR
467 002610 052777 000100 013320          BIS #B06,@TTRCSR      ;SET RCVR EVENT FLAG
468 002616 005067 015134          CLR ESCFLG            ;SET TTY KBD INTR ENAB
;CLEAR CNTRL-C FLAG

```

```
469 002622 005067 015030          CLR    QLDEV          ;CLR QUEUE LOAD EVENT FLAG
470 002626 005067 015106          CLR    RJCTF          ;CLEAR REJECT FLAG
471 002632 005067 015104          CLR    TRNKF          ;CLEAR TRUNCATE FLAG
472 002636 005067 015042          CLR    SPCEV          ;CLEAR MST DWN EVENT
473 002642 005067 015040          CLR    XSPCEV         ;CLR NOW MST EVENT
474 002646          RTRYA: CALL  PNCRLF        ;ENQUEUE CR, & LF
475 002662          CALL  PRESC          ;ENTER COMMAND MODE!
476 002676 000167 000060          JMP    PCLOOP         ;GO TO MAIN LOOP
477
478
479 002702 011667 014756          TRAP4: MOV   (SP),SUMSV    ;SAVE TRAP ADDRESS
480 002706 162767 000002 014750 SUB   #2,SUMSV          ;ALIGN IT -2
481 002714 012700 031140          MOV   #TRP4AD,R0      ;SHOW OCT CONV RTN RIGHT ADDRESS
482 002720 016701 014740          MOV   SUMSV,R1        ; FOR ASCII CHARS.
483 002724 004767 027752          JSR   PC,OCTJSP
484 002730          CALL PNTLIN,<TRPDMG> ;PRINT TRAP MESSAGE
485 002746 012706 002000          MOV   #STKTOP,SP
486 002752 005037 177776          CLR   @#PS
487 002756 000167 177664          JMP   RTRYA          ;LOWER PRIORITY
```

```

489          .SBTTL MAIN LOOP
490
491
492 002762 005767 013552   PCLOOP: TST      TIQ          ;IS TTY INPUT QUEUE EMPTY?
493 002766 001406          BEQ      NXT0         ;YES, TEST ANOTHER FLAG
494 002770          CALL     TTINP        ;NO, PROCESS A CHARACTER
495 003004 105767 014631   NXT0:  TSTB     CMDENT       ;HAS A COMMAND BEEN ENTERED?
496 003010 100006          BPL      NXT1         ;NO, TEST ANOTHER FLAG
497 003012          CALL     COMENT       ;YES, PROCESS COMMAND
498 003026 005767 013572   NXT1:  TST      TOQ          ;IS TTY OUTPUT QUEUE EMPTY?
499 003032 001406          BEQ      NXT2         ;YES, TEST ANOTHER FLAG
500 003034          CALL     TTOUT        ;NO, OUTPUT A CHAR IF DEV RDY
501 003050 005767 014602   NXT2:  TST      QLDEV        ;IS ADDR QUEUE EMPTY?
502 003054 100006          BPL      NXT3         ;NO, TEST ANOTHER FLAG
503 003056          CALL     ADQLD        ;YES, LOAD ADDR QUEUE
504 003072 005767 014562   NXT3:  TST      DATGEV       ;IS DATA GEN FLAG SET?
505 003076 100006          BPL      NXT4         ;NO, TEST ANOTHER FLAG
506 003100          CALL     DATGEN        ;YES GENERATE NEW RANDOM DATA
507 003114 005767 014554   NXT4:  TST      TXMEV        ;IS TXTR EVENT FLAG SET?
508 003120 100006          BPL      NXT5         ;NO, TEST ANOTHER FLAG
509 003122          CALL     TXMIT        ;YES, ENTER XMIT MODULE
510 003136 005767 014540   NXT5:  TST      RCVEV        ;IS RCVR EVENT FLAG SET?
511 003142 100006          BPL      NXT6         ;NO, TEST ANOTHER FLAG
512 003144          CALL     RECV         ;YES, ENTER RCVR MODULE
513 003160 005767 014520   NXT6:  TST      SPCEV        ;IS SPECIAL EVENT FLAG SET?
514 003164 100006          BPL      NXT7         ;NO, TEST ANOTHER FLAG
515 003166          CALL     SPEC         ;YES, HANDLE SPECIAL EVENT
516 003202 005767 014460   NXT7:  TST      STSEV        ;IS STATUS EVENT FLAG SET?
517 003206 100006          BPL      NXT8         ;NO, TEST ANOTHER FLAG
518 003210          CALL     STATUS        ;YES, OUTPUT STATUS
519 003224 005767 014432   NXT8:  TST      SUMEV        ;IS SUMMARY EVENT FLAG SET?
520 003230 100006          BPL      NXT9         ;NO, TEST ANOTHER FLAG
521 003232          CALL     SUMRY         ;YES, OUTPUT ERROR SUMMARY
522 003246 005767 014434   NXT9:  TST      XSPCEV       ;IS EXTRA-SPECIAL EVENT SET?
523 003252 100006          BPL      NXT10        ;YES, HANDLE NOW MASTER.
524 003254          CALL     XSPEC         ;IS XMTR ERROR EVENT SET?
525 003270 005767 014356   NXT10: TST      TEREV        ;NO, TEST ANOTHER FLAG
526 003274 100006          BPL      NXT11        ;YES OUTPUT XMTR ERROR TABLE
527 003276          CALL     TERS         ;IS RCVR ERROR EVENT SET?
528 003312 005767 014336   NXT11: TST      RREVEV       ;NO,
529 003316 100006          BPL      NXT12        ;YES, OUTPUT RCVR ERROR TABLE
530 003320          CALL     RERS         ;STAY IN MAIN LOOP
531 003334 000167 177422   NXT12: JMP      PCLOOP
532
533          ;TRAP TO 4 HANDLER
534
535
536 003340          ERTRAP: REGSAV
537 003344          CALL     PNTLIN,<ERTMSG>
538 003362 005067 014314          CLR     RCVEV
539 003366 005067 014306          CLR     PCLGO
540 003372 052777 000100 012536          BIS     #B06,@TTRCSR
541 003400 005037 177776          CLR     @#PS
542 003404          REGRES
543 003410 012706 002000          MOV     #STKTOP,SP
544 003414 000167 177226          JMP     RTRYA

```

546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
(1)
(1)
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599

003420
003420
003420 012701 017776
003424 016602 000002
003430 005302
003432 001002
003434 000167 000446
003440 010267 014254
003444 020227 000062
003450 101402
003452 000167 000422
003456 010267 014276
003462 010200
003464 005300
003466
003476 060600
003500 062700 000004
003504 016067 000004 014176
003512 012767 000000 014172
003520 021027 000002
003524 001402
003526 000167 000346
003532 026067 000004 014152
003540 001004
003542 112721 000000
003546 005267 014206
003552 116011 000004
003556 001002
003560 000167 000344
003564 122711 000037
003570 103002
003572 000167 000302
003576 112167 014110
003602 062700 177772
003606 005302
003610 001343

```
.SBTTL COMMAND PROCESSORS:  
.SBTTL COMMAND PROC. FOR SILO (LOAD)  
  
: LOAD OR CLEAR THE TRANSMITTER ADDRESS (HARDWARE) SILO.  
: IF THERE ARE NO ARGUMENTS, CLEAR THE ADDRESS SILO AND SET  
: AUTO ADDRESS. IF THERE ARE ARGUMENTS, LOAD THE TOTAL NUMBER  
: OF ARGUMENTS (INCLUDING PAD VALUES) INTO THE SILO AS MANY TIMES  
: AS THE TOTAL WILL GO INTO 50. LOCATIONS.  
  
: IF ANY 2 SEQUENTIAL ARGUMENTS ARE THE SAME, SEPARATE THEM WITH  
: A PAD VALUE OF '0'. IF THE FIRST ARGUMENT IS THE SAME AS THE LAST  
: ARGUMENT, INSERT A PAD VALUE OF '0' AFTER THE LAST ARGUMENT.  
  
: ARGUMENTS HIGHER THAN 37 (OCTAL) WILL NOT BE ACCEPTED  
: ARGUMENTS LOWER THAN 1 WILL NOT BE ACCEPTED.  
  
: ARGUMENTS MUST BE NUMERIC. DECIMAL ARGUMENTS MUST BE FOLLOWED BY  
: A DECIMAL POINT. ('8.)  
PROC CPSILO  
  
CPSILO: ;**ENTRY POINT**  
MOV #ADSILO,R1 ;SET R1 TO POINT TO SILO BUFFER  
MOV 2(SP),R2  
DEC R2 ;GET # OF ARGS. INTO R2  
BNE 11$ ;O.K IF THERE ARE SOME  
JMP CLEAV ;OTHERWISE, EXIT  
11$: MOV R2,PADFLG ;SAVE COUNT FOR LATER USE.  
CMP R2,#50. ;ARE THERE MORE THAN 50 OBJECTS?  
BLOS 1$ ;NO, CONTINUE  
JMP SYNRTM ;YES, ERROR  
1$: MOV R2,OBJCNT ;SAVE OBJECT COUNT  
MOV R2,R0 ;TURN LOOK-UP AROUND  
DEC R0  
MULT 6,R0,R3  
ADD SP,R0  
ADD #4,R0  
MOV 4(R0),FIRST ;SAVE FIRST ITEM  
MOV #0,NEXT ;SAVE CURRENT ITEM  
CPMLP: CMP (R0),#2 ;IS IT CLASS 2?  
BEQ 2$ ;YES, O.K.  
JMP SYNRTM ;NO, ERROR  
2$: CMP 4(R0),NEXT ;IS THIS ITEM SAME AS LAST?  
BNE 3$ ;NO, O.K.  
MOVB #0,(R1)+ ;YES, INSERT A PAD VALUE  
INC OBJCNT ;KEEP OBJECT COUNT UP TO DATE  
3$: MOVB 4(R0),(R1) ;PUT OBJECT INTO BUFFER  
BNE 4$ ;ERROR IF OBJECT IS 0  
JMP SYNRTM  
4$: CMPB #37,(R1) ;ERROR IF IT WAS > 37  
BHIS 5$  
JMP SYNRTM  
5$: MOVB (R1)+,NEXT ;SAVE REAL ITEM  
ADD #-6,R0 ;SET UP TO GET NEXT OBJECT  
DEC R2 ;ARE WE DONE LOADING BUFF?  
BNE CPMLP ;NO, KEEP GOING
```


600	003612	026767	014074	014070		CMP	NEXT,FIRST		:IS LAST OBJECT = FIRST?
601	003620	001004				BNE	6\$:NO, O.K.
602	003622	112721	000000			MOVB	#0,(R1)+		:YES, INSERT A PAD VALUE
603	003626	005267	014126			INC	OBJCNT		:AND KEEP OBJECT COUNT UP TO DATE
604	003632	026727	014122	000062	6\$:	CMP	OBJCNT,#50.		:OBJECT COUNT GOTTEN TOO BIG?
605	003640	101402				B'OS	7\$:NO, O.K.
606	003642	000167	000232			JMP	SYNRTM		:YES, ERROR
607	003646	152777	000060	012236	7\$:	BISB	#B05+B04,@TMMRH		:PREPARE TO LOAD ADDR SILO
608	003654	012700	000062			MOV	#50.,R0		:HOLD SILO SIZE
609	003660	026767	014074	014032		CMP	OBJCNT,PADFLG		:IS OBJECT COUNT DIFFERENT THAN START?
610	003666	001002				BNE	SILLD		:YES, LEAVE SOMETHING IN PADFLG (SET)
611	003670	005067	014024		8\$:	CLR	PADFLG		:NO, CLEAR PAD FLAG
612	003674	016702	014060		SILLD:	MOV	OBJCNT,R2'		:GET NO. OF OBJECTS
613	003700	012701	017776			MOV	#ADSILO,R1		:GET OBJECT BUFFER
614	003704	112177	012200		SLOLP:	MOVB	(R1)+,@TMMR		:GET AN OBJECT INTO SILO
615	003710	005302				DEC	R2		:LOADED ALL OBJECTS?
616	003712	001374				B'IE	SLOLP		:NO, CONTINUE
617	003714	166700	014040			SUB	OBJCNT,R0		:YES, IS THAT ALL THAT'LL FIT?
618	003720	020067	014034			CMP	R0,OBJCNT		
619	003724	002363				BGE	SILLD		:IF NOT LOAD THEM AGAIN
620	003726	132777	000001	012156		BITB	#1,@TMMRH		:SEE IF I AM MASTER
621	003734	001037				BNE	CPSLV		:IF SO TURN ON SILO AND EXIT
622	003736					CALL	PNTLIN,<MSTMG1>		:PRINT 'THIS UNIT IS NOT MASTER
623	003754					CALL	PNTLIN,<MSTMG2>		: BUT HAS BEEN MADE SECONDARY
624	003772					CALL	PNTLIN,<MSTMG3>		: THE SILO YOU HAVE JUST FILLED
625	004010					CALL	PNTLIN,<MSTMG4>		: WILL BE USED IF YOU CLEAR THE
626	004026	152777	000002	012056		BISB	#B01,@TMMRH		: THE CURRENT MASTER'.
627	004034	005767	013660		CPSLV:	TST	PADFLG		:HAS SILO BEEN PADDED?
628	004040	001407				BEQ	9\$:NO, CARRY ON.
629	004042					CALL	PNTLIN,<MSTMG5>		:YES, TELL OPERATOR.
630	004060	012767	177777	013670	9\$:	MOV	#-1,ESCFLG		:FLAG COMENT TO ISSUE NEW 'PCL>'.
631	004066	142777	000020	012016		BICB	#B04,@TMMRH		:CLR AUTO ADDR
632	004074	000241				CLC			:CLEAR 'C' FOR NON ERROR RETURN
633	004076				CPSEX:	RETURN			
634									
635	004100	000261			SYNRTM:	SEC			:SET 'C' BIT FOR SYNTAX ERROR
636	004102	000167	177770			JMP	CPSEX		:AND RETURN
637									
638									
639	004106	152777	000060	011776	CLEAV:	BISB	#B05+B04,@TMMRH		:RESET AUTO ADDR & CLR SILO
640	004114	012767	177777	013634		MOV	#-1,ESCFLG		:FLAG COMENT TO ISSUE NEW 'PCL>'.
641	004122	000241				CLC			:CLEAR 'C' IN CASE IT WAS SET
642	004124	000167	177746			JMP	CPSEX		:RETURN

```

644 .SBTTL COMMAND PROC. FOR MASTER, SECONDARY AND R.I.B.
645
646 ;PROCESSOR FOR 'MASTER SET (OR CLEAR)' COMMAND
647 ; SET MASTER, OR CLEAR MASTER
648
649 004130 PROC CPMAS
(1)
(1) 004130 CPMAS: ;**ENTRY POINT**
650 004130 022766 000002 000002 CMP #2,2(SP) ;GET # OF ARGUMENTS
651 004136 001402 BEQ CPMOK ;OKAY IF 2
652 004140 000261 SEC
653 004142 000423 BR CPMRET ;OTHERWISE, SYNTAX ERROR
654 004144 010603 CPMOK: MOV SP,R3 ;GET 2ND WORD OF COMMAND
655 004146 062703 000004 ADD #4,R3
656 004152 KEYWD R3,#SCTBL ;PROCESS IT
657 004164 103446 BCS KWDERT ;SYNTAX ERROR IF 'C' SET
658 004166 117702 011720 MOV @TMMRH,R2 ;GET OLD TMMR
659 004172 142702 000001 BICB #1,R2 ;REMOVE OLD STATE OF MASTER
660 004176 052602 BIS (SP)+,R2 ;SET NEW STATE OF MASTER
661 004200 110277 011706 MOV R2,@TMMRH ;LOAD NEW TMMR
662 004204 012767 177777 013544 MOV #-1,ESCFLG ;FLAG COMENT TO ISSUE NEW 'PCL>'.
663 004212 CPMRET: RETURN ;EXIT
664
665
666 ;PROCESSOR FOR 'SECONDARY SET (OR CLEAR)' COMMAND
667 ; SET SECONDARY, OR CLEAR SECONDARY
668
669 004214 PROC CPSEC
(1)
(1) 004214 CPSEC: ;**ENTRY POINT**
670 004214 022766 000002 000002 CMP #2,2(SP) ;ARE THERE 2 ARGUMENTS?
671 004222 001402 BEQ CPSOK ;IF YES, PROCEED
672 004224 000261 SEC
673 004226 000424 BR CPSRET ;OTHERWISE, SYNTAX ERROR
674 004230 010603 CPSOK: MOV SP,R3 ;GET 2ND WORD OF COMMAND
675 004232 062703 000004 ADD #4,R3
676 004236 KEYWD R3,#SCTBL ;PROCESS IT
677 004250 103414 BCS KWDERT ;SYNTAX ERROR IF 'C' SET
678 004252 117702 011634 MOV @TMMRH,R2 ;GET OLD TMMR
679 004256 142702 000002 BICB #2,R2 ;REMOVE OLD STATE OF SECONDARY
680 004262 006316 ASL (SP)
681 004264 052602 BIS (SP)+,R2 ;SET NEW STATE OF SECONDARY
682 004266 110277 011620 MOV R2,@TMMRH ;LOAD NEW TMMR
683 004272 012767 177777 013456 MOV #-1,ESCFLG ;FLAG COMENT TO ISSUE NEW 'PCL>'.
684 004300 CPSRET: RETURN ;EXIT
685
686
687 004302 032600 KWDERT: BIT (SP)+,R0 ;POP BAD WORD OFF STACK
688 004304 000775 BR CPSRET ;EXIT
689
690
691 ;PROCESSOR FOR 'RIB SET' OR 'RIB CLEAR'
692 ; SET 'RIB' BIT IN XMTR COMMAND WORD LOCATION 'TXMST', OR CLEAR IT
693
694 004306 PROC CPRIB
(1)

```

```
(1) 004306
695 004306 022766 000002 000002
696 004314 001402
697 004316 000261
698 004320 000426
699 004322 010603
700 004324 062703 000004
701 004330
702 004342 103757
703 004344 016702 003030
704 004350 042702 100000
705 004354 000241
706 004356 006016
707 004360 006016
708 004362 052602
709 004364 010267 003010
710 004370 012767 177777 013360
711 004376
```

CPRIB: ;**ENTRY POINT**
;2 ARGUMENTS?
;YES, O.K.

CPRRET: ;OTHERWISE, ERROR RETURN
;GET 2ND WORD OF COMMAND

CPRUK: MOV SP,R3
ADD #4,R3
KEYWD R3,#SCTBL
BCS KWDERT
MOV TXMST,R2
BIC #B15,R2
CLC
;OR (SP)
R,R (SP)
BIS (SP)+,R2
MOV R2,TXMST
MOV #-1,ESCFLG

CPRRET: RETURN ;PROCESS IT
;IF ERROR, SHOW IT.
;GET OLD STATE OF TCR
;CLEAR IMAGE OF RIB
;GET NEW STATE OF RIB
;SET IT IN IMAGE
;LOAD NEW STATE OF TCR
;FLAG COMMENT TO ISSUE NEW 'PCL>'
;BACK TO CALLER


```
758 .SBTTL COMMAND PROC. FOR ADD AND DELETE
759
760 ; ADD A RECEIVER ADDRESS TO THE LIST (SET ACTIVE FLAG) OF RCVR ADDRESSES
761 ;
762 ; ACCEPT ARGUMENTS (AT LEAST 1) CHECK THAT THY FALL IN A RANGE FROM
763 ; 1 TO 37; THEN SET THE CORRESPONDING ACTIVE FLAGS IN THE STAT
764 ; TABLE.
765
766 004536 PROC CPADD
(1)
(1) 004536 CPADD: ;**ENTRY POINT**
767 004536 016602 000002 MOV 2(SP),R2 ;GET # OF ARGUMENTS INTO R2
768 004542 005302 DEC R2 ;IGNORE KEYWORD OBJECT
769 004544 010600 MOV SP,R0 ;GENERATE ADDRESS OF ARGUMENTS
770 004546 062700 000004 ADD #4,R0 ;POINT R0 AT 1ST OBJECT CLASS
771 004552 021027 000002 CPALP: CMP (R0),#2 ;IS CLASS = 2?
772 004556 001027 BNE SYNTRA ;NO, INDICATE SYNTAX ERROR
773 004560 016001 000004 MOV 4(R0),R1 ;GET OBJECT INTO R1
774 004564 001424 BEQ SYNTRA ;IF IT'S 0, SYNTAX ERROR
775 004566 022701 000037 CMP #37,R1
776 004572 103421 BLO SYNTRA ;IF IT'S >37, SYNTAX ERROR
777 004574 006301 ASL R1 ;FIND THE TABLE ELEMENT
778 004576 006301 ASL R1
779 004600 010103 MOV R1,R3
780 004602 006301 ASL R1
781 004604 060301 ADD R3,R1
782 004606 062701 020064 ADD #RADB0,R1
783 004612 012711 177777 MOV #-1,(R1) ;SET ACTIVE FLAG FOR THIS TABLE ENTRY
784 004616 062700 000006 ADD #6,R0 ;SET UP FOR NEXT ARGUMENT
785 004622 005302 DEC R2 ;ARE WE DONE?
786 004624 001352 BNE CPALP ;NO, CONTINUE.
787 004626 012767 177777 013122 MOV #-1,ESCFLG ;FLAG COMENT TO ISSUE NEW 'PCL>'
788 004634 CPARTN: RETURN
789 004636 000261 SYNTRA: SEC ;SET 'C' BIT FOR SYNTAX ERROR
790 004640 000167 177770 JMP CPARTN
791
792 ;DELETE RECEIVER ADDRESSES AND ASSOCIATED 'ATTEMPTS' AND 'SUCCESSSES'.
793
794 004644 PROC CPDEL
(1)
(1) 004644 CPDEL: ;**ENTRY POINT**
795 004644 016602 000002 MOV 2(SP),R2 ;GET # OF ARGUMENTS INTO R2
796 004650 005302 DEC R2 ;IGNORE KEYWORD OBJECT
797 004652 010600 MOV SP,R0 ;GENERATE ADDRESS OF ARGUMENTS
798 004654 062700 000004 ADD #4,R0 ;POINT R0 AT 1ST OBJECTS CLASS
799 004660 021027 000002 CPDLP: CMP (R0),#2 ;IS CLASS =2
800 004664 001034 BNE SYNTRD ;NO,INDICATE SYNTAX ERROR
801 004666 016001 000004 MOV 4(R0),R1 ;GET OBJECT INTO R1
802 004672 001431 BEQ SYNTRD ;IF IT'S 0, SYNTAX ERROR
803 004674 022701 000037 CMP #37,R1
804 004700 103426 BLO SYNTRD ;IF IT'S >37, SYNTAX ERROR
805 004702 006301 ASL R1 ;FIND TABLE ELEMENT
806 004704 006301 ASL R1
807 004706 010103 MOV R1,R3
808 004710 006301 ASL R1
809 004712 060301 ADD R3,R1
```

810	004714	062701	020064		ADD	#RADB0,R1	
811	004720	005011			CLR	(R1)	;CLEAR ACTIVE FLAG AT TABLE LOCATION
812	004722	062701	000004		ADD	#4,R1	;AND OTHER ENTRIES...
813	004726	005021			CLR	(R1)+	
814	004730	005021			CLR	(R1)+	
815	004732	005021			CLR	(R1)+	
816	004734	005011			CLR	(R1)	
817	004736	062700	000006		ADD	#6,R0	;SET UP FOR NEXT ARGUMENT
818	004742	005302			DEC	R2	;ARE WE DONE?
819	004744	001345			BNE	CPDLP	;NO, CONTINUE
820	004746	012767	177777	013002	MOV	#-1,ESCFLG	;FLAG COMENT TO ISSUE NEW 'PCL>'
821	004754				CPDRTN: RETURN		
822	004756	000261			SYNTRD: SEC		;SET 'C' BIT FOR SYNTAX ERROR
823	004760	000167	177770		JMP	CPDRTN	

.SBTTL COMMAND PROC. FOR CLEAR, STATUS, AND CONTINUE

825
826
827
828
829
830
831
832
833
834
(1)
(1)
835
836
837
838
839
840
(1)
(1)
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
(1)
(1)
863
864
865
866
867
868
869
870
871
872
873
874

: CLEAR THE ENTIRE LIST OF RECEIVER ADDRESSES (CLEAR ACTIVE FLAGS)
: TO USE THIS ROUTINE BY A CALL MACRO, ENTER AT PRCLR AS FOLLOWS :

: CALL PRCLR ;CLEAR STATUS TABLE
: PROC CPCLR

CPCLR: ;**ENTRY POINT**

MOV 2(SP),R2 ;GET NUMBER OF OBJECTS INTO R2
CMP #1,R2 ;ARE THERE ANY ARGUMENTS?
BNE SYNTRC ;IF SO, INDICATE SYNTAX ERROR
MOV #-1,ESCFLG ;FLAG COMMENT TO ISSUE NEW 'PCL>'
PROC PRCLR

PRCLR: ;**ENTRY POINT**

MOV #37,R1 ;SAVE COUNT OF TABLE ELEMENTS
MOV #RADB,R0 ;SET UP TO CLR ACTIVE FLAGS
CPCLRC: CLR (R0) ;CLEAR ALL ELEMENTS OF ENTRY
ADD #4,R0
CLR (R0)+
CLR (R0)+
CLR (R0)+
CLR (R0)+
DEC R1 ;DONE?
BNE CPCLRC ;IF NOT, CONTINUE
CLR A0Q ;INITIALIZE ADDR QUEUE TO EMPTY
MOV A0Q+QTOP,A0Q+QFRONT
MOV A0Q+QTOP,A0Q+QBACK
CPCLRT: RETURN ;AND LEAVE
SYNTRC: SEC ;SET 'C' BIT FOR SYNTAX ERROR
JMP CPCLRT

: SET THE STATUS EVENT FLAG SO THAT THE STATUS TABLE WILL BE PRINTED.

PROC CPSTAT

CPSTAT: ;**ENTRY POINT**

CMP #1,2(SP) ;ARE THERE ANY ARGUMENTS?
BNE SYNTRS ;IF SO, INDICATE SYNTAX ERROR
BIS #B15,STSEV ;SET STATUS EVENT FLAG
CLR STPNTR ;0 STPNTR INDICATES HEADER FIRST
BIC #B06,@TCR ;CLR TXM INTERRUPT ENABLE
CPSRTN: RETURN
SYNTRS: SEC ;SET 'C' BIT FOR SYNTAX ERROR
JMP CPSRTN

: CONTINUE EXERCISING. DO NOT AFFECT THE STATUS TABLE

875
876
877
878
879
880
881
(1)
(1)
882
883
884
885
886
887
888
889
890
891
892

005126
005126 022766 000001 000002
005134 001027
005136 012767 100000 012534
005144
005160
005176 005767 012446
005202 001403
005204 012777 000100 010736
005212
005214 000261
005216 000167 177770

: DO NOT AFFECT THE ERROR TABLE
: DO NOT AFFECT THE RCVR ADDRESS QUEUE
: SIMPLY SET PCLGO
:

PROC CPCNT

CPCNT:

CMP #1,2(SP)
BNE SYNTCN
MOV #B15,PCLGO
CALL PNCRLF
CALL PNTLIN,<EXCNT>
TST KWFLG
BEQ CPCNRT
MOV #B06,@LCS
CPCNRT: RETURN
SYNTCN: SEC
JMP CPCNRT

:**ENTRY POINT**
:ARE THERE ANY ARGUMENTS?
:IF SO, INDICATE SYNTAX ERROR
:SET PCL GO FLAG
:PRINT CR & LF
:PRINT 'EXERCISER CONTINUING'
:GOT A CLOCK?
:NO
:RE-ENABLE CLOCK.
:SET 'C' BIT FOR SYNTAX ERROR


```

      .SBTTL  COMMAND PROC. FOR INIT, SUMMARY, AND GO
894
895
896      ;TO USE CALL MACRO, ENTER AT PRINT AND PARCLR
897      ; CLEAR STATUS TABLE, SUMMARY TABLE, ERROR TABLE
898      ; CLEAR 'RIB' IN XMTR COMMAND WORD 'TXMST'
899      ; CLEAR CLOCK DATA
900      ; CLEAR TRANSMITTER HARDWARE
901      ; INITIALIZE DATA PATTERN
902
903
904
905      005222          PROC      CPINIT
(1)
(1)      005222          CPINIT:          ;**ENTRY POINT**
906      005222  022766  000001  000002      CMP      #1,2(SP)      ;ARE THERE ANY ARGUMENTS?
907      005230  001114          BNE      SYNTIN      ;IF SO, INDICATE SYNTAX ERROR
908      005232  012767  177777  012516      MOV      #-1,ESCFLG      ;FLAG COMENT TO ISSUE NEW 'PCL>'
909      005240          PROC
(1)
(1)      005240          PRINIT:          ;**ENTRY POINT**
910      005240          BDINIT  XMTR      ;CLEAR XMITTER.
911      005246  105067  012371      CLR      SECNDS      ;CLEAR SECONDS (TIME)
912      005252  105067  012366      CLR      MINUTS      ;CLEAR MINUTES
913      005256  105067  012360      CLR      TICKS      ;CLEAR TICKS
914      005262  005067  012360      CLR      HOURS      ;CLEAR HOURS
915      005266  042767  100000  002104      BIC      #B15,TXMST      ;CLEAR RIB IN COMMAND WORD FOR XMTR
916      005274          CALL      PRCLR      ;CLR STATUS TABLE & ADDR QUEUE
917      005310          PROC      PARCLR:
(1)
(1)      005310          MOV      #ERTBL,R0      ;**ENTRY POINT**
918      005310  012700  024726      ERTBCL:  CMP      #-1,(R0)      ;CLEAR ERROR SUMMARY TABLE
919      005314  022710  177777          BEQ      ERTCD      ;IS ERR NUM = -1?
920      005320  001406          CLR      4(R0)      ;IF SO, DONE CLEARING
921      005322  005060  000004          ADD      #6,R0      ;OTHERWISE, CLR OCURRENCES
922      005326  062700  000006          JMP      ERTBCL      ;STEP TO NEXT ENTRY
923      005332  000167  177756          ERTCD:  MOV      #37*30,R0      ;AND CONTINUE
924      005336  012700  001350          MOV      #TERTBL,R1      ;ALSO CLEAR ERROR DATA
925      005342  012701  025150          1$:      MOV      #0,(R1)+      ;FROM DETAILED ERR TABLE
926      005346  012721  000000          DEC      R0
927      005352  005300          BNE      1$
928      005354  001374          MOV      #37,R0      ;CLEAR ATTEMPS & SUCCESSES
929      005356  012700  000037          MOV      #RADB,R1      ; FROM STATUS TABLE
930      005362  012701  020100          2$:      ADD      #4,R1
931      005366  062701  000004          CLR      (R1)+
932      005372  005021          CLR      (R1)+
933      005374  005021          CLR      (R1)+
934      005376  005021          CLR      (R1)+
935      005400  005021          DEC      R0
936      005402  005300          BNE      2$
937      005404  001370          MOV      ORIGSD,DTSEED      ;RESTORE ORIGINAL DATA SEED
938      005406  016767  012312  012312      MOV      MLSD,MSGLSD      ;AND MSG LENGTH SEED
939      005414  016767  012310  012310      CLR      TXMEV      ;CLR XMIT EVENT FLAG
940      005422  005067  012246          CLR      SUMEV      ;CLR SUMMARY EVENT FLAG
941      005426  005067  012230          CLR      STSEV      ;CLR STATUS EVENT FLAG
942      005432  005067  012230          CLR      TEREV
943      005436  005067  012210
  
```

```
944 005442 005067 012206          CLR    REREV          ;CLR XMTR & RCVR ERROR EVENTS
945 005446 005067 012264          CLR    RCTXPS        ;CLEAR DATA PASS NO.
946 005452 052767 100000 012200  BIS    #B15,DATGEV   ;SET DATA GEN FLAG
947 005460          CPINRT: RETURN
948 005462 000261          SYNTIN: SEC          ;SET 'C' BIT FOR SYNTAX ERROR
949 005464 000167 177770          JMP    CPINRT
950
951
952
953          ; SET THE SUMMARY EVENT FLAG SO THAT THE ERROR SUMMARY TABLE WILL BE PRINTED
954
955
956 005470          PROC    CPSUM
(1)
(1) 005470          CPSUM:          ;**ENTRY POINT**
957 005470 022766 000001 000002  CMP    #1,2(SP)      ;ARE THERE ANY ARGUMENTS?
958 005476 001006          BNE    SYNTSM        ;IF SO, INDICATE SYNTAX ERROR
959 005500 012767 100000 012154  MOV    #B15,SUMEV   ;SET SUMMARY EVENT FLAG
960 005506 005067 012160          CLR    SUMPNT        ;0 SUMPNT INDICATES HEADER FIRST
961 005512          CPSURT: RETURN
962 005514 000261          SYNTSM: SEC          ;SET 'C' BIT FOR SYNTAX ERROR
963 005516 000167 177770          JMP    CPSURT
964
965
966
967
968          ; START THE EXERCISER
969          ; CLEAR 'ATTEMPTS' AND 'SUCCESSSES' IN STATUS TABLE
970          ; CLEAR ERROR TABLES
971          ; CAUSE RCVR ADDRESS QUEUE TO BE LOADED
972          ; SET PCLGO
973          ; IF THE RCVR ADDRESS QUEUE IS EMPTY AFTER BEING LOADED,
974          ; INDICATE THIS BY PRINTING THE FOLLOWING MESSAGE:
975          ;
976          ;     ***SORRY, I HAVE NO RECEIVER ADDRESSES.***
977          ;
978          ; AND RETURN TO COMMAND INPUT MODE.
979
980
981
982 005522          PROC    CPGO
(1)
(1) 005522          CPGO:          ;**ENTRY POINT**
983 005522 022766 000001 000002  CMP    #1,2(SP)      ;ARE THERE ANY ARGUMENTS?
984 005530 001062          BNE    SYNTAX        ;IF SO, INDICATE SYNTAX ERROR
985 005532 005067 012200          CLR    RCTXPS        ;CLEAR PASS NO.
986 005536 005067 010662          CLR    AOQ           ;INIT ADDR QUEUE TO EMPTY
987 005542 105067 012075          CLR    SECNDS        ;CLEAR SECONDS REG.
988 005546 105067 012072          CLR    MINUTS        ;CLEAR MINUTES REG.
989 005552 105067 012064          CLR    TICKS         ;CLEAR TICKS REG.
990 005556 005067 012064          CLR    HOURS         ;CLEAR HOURS REG.
991 005562 016767 010642 010644  MOV    AOQ+QTOP,AOQ+QFRONT
992 005570 016767 010634 010640  MOV    AOQ+QTOP,AOQ+QBACK
993 005576 052767 100000 012052  BIS    #B15,QLDEV    ;SET ADDR QUEUE LOAD EVENT
994 005604 012767 177777 012066  MOV    #-1,PCLGO     ;SET PCL TO GO
995 005612          CALL   PARCLR        ;CLEAR STATUS & ERRORS (NOT RCVR)
```

996	005626				CALL	PNCRLF		:PRINT CR, LF
997	005642				CALL	PNTLIN,<EXRST>		:PRINT 'EXERCISER STARTED'.
998	005660	005767	011764		TST	KWFLG		:GOT A CLOCK?
999	005664	001403			BEQ	STRTRT		:NO.
1000	005666	012777	000100	010254	MOV	#B06,@LCS		:ENABLE CLOCK INTR.
1001	005674				STRTRT:	RETURN		:EXIT
1002								
1003	005676	000261			SYNTAX:	SEC		:SET 'C' TO INDICATE SYNTAX ERROR
1004	005700	000167	177770		JMP	STRTRT		:AND EXIT
1005								
1006								

```

1008 .SBTTL COMMAND PROC. FOR 'ASSIGN'
1009
1010 : ASSIGN XMTR ADDR & VECTOR AND RCVR ADDR & VECTOR.
1011 : THE ASSIGN COMMAND MAY HAVE 0, 1, 2, 3 OR 4 ARGUMENTS:
1012 :
1013 : 0 = ASSIGN STANDARD ADDRESSES & VECTORS TO RCVR & XMTR
1014 : 1 = ARGUMENT IS ASSUMED TO BE XMTR ADDRESS
1015 : 2 = ARGUMENTS ARE ASSUMED TO BE : XMTR ADDR, XMTR VECTOR
1016 : 3 = ARGUMENTS ARE ASSUMED TO BE: XMTR ADDR, XMTR VECT, RCVR ADDR
1017 : 4 = ARGUMENTS IN THE FOLLOWING ORDER:
1018 :
1019 : XMTR ADDRESS, XMTR VECTOR, RCVR ADDRESS, AND RCVR VECTOR.
1020 : CAUTION MUST BE EXERCISED WHEN ASSIGNING ADDRESSES TO GET THEM
1021 : IN THE CORRECT SEQUENCE AND ORDER.
1022

```

```

1023 005704 PROC CPASS
(1)
(1) 005704 CPASS: ;**ENTRY POINT**
1024 005704 010600 MOV SP,R0 ;COPY LIST POINTER
1025 005706 016001 000002 MOV 2(R0),R1 ;GET NO. OF ARGUMENTS
1026 005712 020127 000005 CMP R1,#5 ;4 ARGUMENTS?
1027 005716 101402 BLOS 1$ ;ERROR TOO MANY ARGUMENTS
1028 005720 000167 000372 JMP SYNXR ;LESS THAN 4, PARTIAL ASSIGNMENT
1029 005724 001030 1$: BNE PART1 ;GET CLASS OF OBJECT
1030 005726 016002 000004 MOV 4(R0),R2 ;IF IT'S A NUMBER, O.K.
1031 005732 022702 000002 CMP #2,R2
1032 005736 001402 BEQ 2$ ;ERROR WRONG CLASS
1033 005740 000167 000352 JMP SYNXR ;NOW GET ACTUAL NUMBER
1034 005744 062700 000006 2$: ADD #6,R0
1035 005750 016002 000002 MOV 2(R0),R2
1036 005754 032702 000003 BIT #3,R2 ;IS IT ON VECTOR BOUNDARY?
1037 005760 001402 BEQ 3$ ;YES
1038 005762 000167 000330 JMP SYNXR ;ERROR NOT ON VECTOR BOUNDARY
1039 005766 020227 000774 3$: CMP R2,#774 ;IS IT WITHIN VECTOR AREA?
1040 005772 101402 BLOS 4$ ;YES
1041 005774 000167 000316 JMP SYNXR ;ERROR, OUTSIDE VECTOR AREA
1042 006000 010267 010170 4$: MOV R2,RCVEC ;SAVE AS RCVR VECTOR
1043 006004 005301 DEC R1
1044 006006 020127 000004 PART1: CMP R1,#4 ;ARE THERE ONLY 3 ARGS?
1045 006012 001030 BNE PART2 ;NO, MUST BE FEWER
1046 006014 016002 000004 MOV 4(R0),R2 ;GET CLASS OF OBJECT
1047 006020 022702 000002 CMP #2,R2 ;IF IT'S A NUMBER, O.K.
1048 006024 001402 BEQ 1$
1049 006026 000167 000264 JMP SYNXR ;ERROR, OBJECT NOT A NUMBER
1050 006032 062700 000006 1$: ADD #6,R0 ;NOW, GET THE NUMBER
1051 006036 016002 000002 MOV 2(R0),R2
1052 006042 032702 000017 BIT #17,R2 ;CHECK IF ITS A VALID ADDR
1053 006046 001402 BEQ 2$ ;IT IS. O.K.
1054 006050 000167 000242 JMP SYNXR ;ERROR INVALID ADDRESS
1055 006054 020227 164000 2$: CMP R2,#164000 ;IS IT IN THE ADDRESS FIELD?
1056 006060 103002 BHIS 3$ ;YES, O.K.
1057 006062 000167 000230 JMP SYNXR ;ERROR. ADDR = OUTSIDE DEVICE AREA
1058 006066 010267 010100 3$: MOV R2,RCDEV ;SAVE AS RCVR ADDRESS
1059 006072 005301 DEC R1
1060 006074 020127 000003 PART2: CMP R1,#3 ;ARE THERE ONLY 2 ARGS?
1061 006100 001030 BNE PART3 ;NO, MUST BE ONLY 1.

```

```
1062 006102 016002 000004      MOV      4(R0),R2      ;GET CLASS OF OBJECT
1063 006106 022702 000002      CMP      #2,R2
1064 006112 001402              BEQ      1$           ;IF IT'S A NUMBER, O.K.
1065 006114 000167 000176      JMP      SYNXR       ;ERROR, WRONG CLASS
1066 006120 062700 000006      1$:      ADD      #6,R0      ;NOW GET THE NUMBER
1067 006124 016002 000002      MOV      2(R0),R2
1068 006130 032702 000003      BIT      #3,R2      ;IS IT ON VECTOR BOUNDARY?
1069 006134 001402              BEQ      2$           ;YES
1070 006136 000167 000154      JMP      SYNXR       ;ERROR, NOT ON VECTOR BOUNDARY
1071 006142 020227 000774      2$:      CMP      R2,#774     ;IS IT WITHIN VECTOR AREA?
1072 006146 101402              BLOS     3$           ;YES
1073 006150 000167 000142      JMP      SYNXR       ;ERROR, OUTSIDE VECTOR AREA
1074 006154 010267 010010      3$:      MOV      R2, TXVEC  ;SAVE AS XMTR VECTOR
1075 006160 005301              DEC      R1
1076 006162 020127 000002      PART3:  CMP      R1,#2
1077 006166 001027              BNE     PART4
1078 006170 016002 000004      MOV      4(R0),R2      ;ONLY 1 ARGUMENT?
1079 006174 022702 000002      CMP      #2,R2      ;NO, MUST BE NONE.
1080 006200 001402              BEQ      1$           ;GET CLASS OF OBJECT
1081 006202 000167 000110      JMP      SYNXR       ;IF IT'S A NUMBER, O.K.
1082 006206 062700 000006      1$:      ADD      #6,R0      ;ERROR, WRONG CLASS
1083 006212 016002 000002      MOV      2(R0),R2      ;NOW GET THE NUMBER
1084 006216 032702 000017      BIT      #17,R2
1085 006222 001402              BEQ      2$           ;CHECK FOR VALID ADDRESS
1086 006224 000167 000066      JMP      SYNXR       ;O.K.
1087 006230 020227 164000      2$:      CMP      R2,#164000  ;IS IT IN ADDRESS FIELD?
1088 006234 103002              BHIS     3$           ;YES
1089 006236 000167 000054      JMP      SYNXR       ;ERROR, OUTSIDE ADDRESS FIELD
1090 006242 010267 007720      3$:      MOV      R2, TXDEV  ;SAVE AS XMTR ADDRESS
1091 006246 020127 000001      PART4:  CMP      R1,#1
1092 006252 001014              BNE     ASEX
1093 006254 012767 164200 007704      MOV      #164200, TXDEV ;NO ARGUMENTS?
1094 006262 012767 000170 007700      MOV      #170, TXVEC  ;WE'RE DONE!
1095 006270 012767 164220 007674      MOV      #164220, RCDEV ;NO ARGUMENTS, LOAD DEFAULTS.
1096 006276 012767 000174 007670      MOV      #174, RCVEC
1097 006304 012737 000340 177776      ASEX:   MOV      #340, #PS
1098 006312 000167 173462      JMP      PCLEX
1099
1100 006316 000261      SYNXR:  SEC
1101 006320      RETURN      ;SET 'C' TO FLAG ERROR
                        ;RETURN
```

```
1103 .SBTTL COMMAND DECODER AND PROCESSOR
1104
1105 ;CONVERT COMMAND TO IT'S PROCESSING ROUTINE ADDRESS
1106 ;IF C BIT IS SET, INDICATE SYNTAX ERROR
1107 ;RETURN TO COMMAND INPUT MODE
1108 ;IF ESCFLG <> 0, CALL PRESC (CNTRL-C)
1109
1110 006322 PROC COMENT
(1)
(1) 006322 COMENT: ;**ENTRY POINT**
1111 006322 105067 011313 CLR CMDENT ;CLEAR COMMAND ENTERED FLAG
1112 006326 005067 011424 CLR ESCFLG ;CLR COMMAND INPUT MODE FLAG
1113 006332 CALL COMAND,<CMDBUF,CMDTBL> ;CONVERT COMMAND
1114 006352 103015 BCC CMDRTN ;IF C = 0, EXIT
1115 006354 CALL PNTLIN,<SYNTAX> ;PRINT 'SYNTAX ERROR' IF C SET
1116 006372 CALL PRESC ;GIVE ANOTHER 'PCL>'
1117 006406 005767 011344 CMDRTN: TST ESCFLG ;SHOULD WE FAKE CNTRL-C?
1118 006412 001406 BEQ CMDRET ;NO, EXIT
1119 006414 CALL PRESC ;YES, GIVE A 'PCL>'
1120 006430 CMDRET: RETURN ;RETURN TO MAIN LOOP
1121
1122
1123 ;PROCESSOR FOR SPECIAL EVENT
1124 ;INDICATE 'NO MASTER' AND CLEAR EVENTS
1125 ;THIS EVENT IS CALLED BY THE MAIN LOOP AFTER
1126 ; THE OCCURRENCE OF A MASTER DOWN INTERRUPT
1127 ;THE RESULT OF THIS EVENT IS THAT THE PROGRAM WILL
1128 ; PRINT MASTER DOWN IN THE FOLLOWING FASION:
1129 ;
1130 ; * * * * * MASTER DOWN * * * * *
1131 ;
1132 ;THEN CLEAR ACTIVE EVENT FLAGS BY ENTERING COMMAND MODE.
1133 ;TO RECOVER FROM THIS STATE AND RESUME EXERCISING:
1134 ; (A) SET MASTER ON ANY ONE PCL11
1135 ; (B) TYPE THE COMMAND 'CONTINUE'
1136
1137 006432 PROC SPEC
(1)
(1) 006432 SPEC: ;**ENTRY POINT**
1138 006432 CALL PNCRLF ;ENQUEUE CR & LF
1139 006446 CALL PNTLIN,<MDNER> ;ENQUEUE MASTER DOWN MESSAGE
1140 006464 CALL PNCRLF ;ANOTHER CR & LF
1141 006500 005067 011200 CLR SPCEV ;CLR SPECIAL EVENT FLAG
1142 006504 005067 011170 SPERTN: CLR PCLGO ;DON'T ALLOW TXM EVENT
1143 006510 005067 011152 CLR STSEV ;DISCONTINUE STATUS EVENT
1144 006514 005067 011142 CLR SUMEV ;DISCONTINUE SUM EVENT
1145 006520 CALL PRESC ;FAKE CNTRL-C KEY
1146 006534 RETURN
```

```
1148 ;PROCESSOR FOR 'EXTRA' SPECIAL EVENT
1149 ;TO INDICATE WHEN THIS UNIT HAS JUST BECOME
1150 ;MASTER AS A RESULT OF PREVIOUSLY HAVING
1151 ;SECONDARY SET AND THE CURRENT BUS MASTER
1152 ;HAVING JUST DROPPED MASTER.
1153 ;WHEN 'NOW MASTER' INTERRUPT OCCURS, THE
1154 ;CONSOLE DEVICE WILL PRINT
1155 ;   '** THIS UNIT HAS BECOME NEW MASTER **'
1156
1157 006536          PROC    XSPEC
(1)
(1) 006536      XSPEC:          ;**ENTRY POINT**
1158 006536          CALL    PNCRLF          ;ENQUEUE CR & LF
1159 006552          CALL    PNTLIN,<MSCHNG>   ;ENQUEUE NEW MASTER MESSAGE
1160 006570          CALL    PNCRLF          ;ANOTHER CR & LF
1161 006604 005067 011076 CLR    XSPCEV          ;CLR XSPEC EVENT FLAG
1162 006610          RETURN          ;RETURN TO MAIN _LOOP
1163
1164
1165 ;PROCESSOR FOR 'DETAILED' ERROR TABLE PRINTOUT COMMAND 'ERRORS'
1166
1167 ;THIS ROUTINE WILL INITIALIZE THE TEMPORARY LOCATIONS REQUIRED
1168 ;BY THE XMTR AND RCVR ERROR EVENTS. IT WILL THEN QUICKLY CHECK THE
1169 ;RCVR AND XMTR ERROR TABLES FOR ANY ENTRIES. IF NONE EXIST, THE MESSAGE
1170 ;   '**NO ERRORS TO REPORT YET **'
1171 ;WILL BE PRINTED ON THE CONSOLE AND THAT IS ALL.
1172 ; IF ANY ENTRIES WERE FOUND, THE XMTR ERROR EVENT FLAG 'TEREV' WILL BE SET
1173 ; WHICH WILL CAUSE THE XMTR ERRORS AND THE RCVR ERRORS (IF ANY) TO
1174 ; BE PRINTED.
1175
1176
1177 006612          PROC    CPERR
(1)
(1) 006612      CPERR:          ;**ENTRY POINT**
1178 006612 022766 000001 000002 CMP    #1,2(SP)          ;ANY ARGUMENTS?
1179 006620 001044          BNE    SYNRR          ;ERROR IF THERE ARE.
1180 006622 012700 025150  MOV    #TERTBL,R0          ;POINT AT XMTR TABLE
1181 006626 012701 001350  MOV    #37*30,R1          ;SET TABLE LENGTH COUNTER
1182 006632 005720          1$:    TST    (R0)+          ;ANY ENTRIES?
1183 006634 001016          BNE    SERFL          ;YES, CALL ERROR MODULE
1184 006636 005301          DEC    R1          ;NO, CHECK WHOLE TABLE
1185 006640 001374          BNE    1$
1186 006642          CALL    PNTLIN,<NOERMG>          ;PRINT 'NO ERRORS'
1187 006660 012767 177777 011070 MOV    #-1,ESCFLG          ;FLAG COMENT TO ISSUE 'PCL>'
1188 006666 000167 000036  JMP    CPERTN          ;AND RETURN
1189 006672 012767 100000 010752 SERFL: MOV    #B15,TEREV          ;SET XMTR EVENT FLAG
1190 006700 012767 000001 011062 MOV    #1,ERR0          ;INITIATE ERROR #
1191 006706 012767 000001 011056 MOV    #1,ERR1          ;INITIATE RCVR ADDR
1192 006714 012767 025150 011052 MOV    #TERTBL,ERR2          ;INITIATE TABLE POINTER
1193 006722 052767 100000 010766 BIS    #B15,HDRFLG          ;SET HEADER FLAG
1194 006730          CPERTN: RETURN
1195
1196 006732 000261          SYNRR: SEC
1197 006734 000167 177770          JMP    CPERTN          ;SET 'C' BIT TO INDICATE SYNTAX ERR
```

.SBTTL RECEIVER ADDRESS QUEUE LOADER ROUTINE

: LOAD THE RECEIVER ADDRESS SOFTWARE QUEUE
:
: THE TRANSMITTER EVENT WILL PICK RCVR ADDRESSES FROM THE QUEUE
: UNTIL IT IS EMPTY.
:
: IF THE QUEUE IS LOADED BUT STILL REMAINS EMPTY, AND PCLGO IS SET,
: THIS MEANS THE OPERATOR IS TRYING TO RUN BUT HASN'T ENTERED
: ANY RECEIVER ADDRESSES (USING 'RANGE' OR 'ADD' ETC.)
:
:

1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241

006740
(1)
006740
006744
006750
006754
006760
006764
006766
006772
006776
007000
007002
007006
007010
007014
007022
007026

007030
007036
007056

007060
007064
007066
007102
007120
007134

005067 010706
012702 000037
012700 020100
022710 177777
004767 000036
062700 000014
005302
001367
005767 007416
001424
005267 010722
012767 100000

010652

PROC ADQLD
ADQLD:
REGSAV
CLR QLDEV
MOV #37,R2
MOV #RADB,R0
QCHACT: CMP #-1,(R0)
BNE QLOOK
JSR PC,QLOAD
QLOOK: ADD #14,R0
DEC R2
BNE QCHACT
TST AQQ
BEQ QMTRN
INC RCTXPS
QRTN: MOV #B15, TXMEV
RECRES
RETURN

QLOAD: MOVB 2(R0),BKELEM+1
CALL ENQ,<BKELEM,AQQ>
RTS PC

QMTRN: TST PCLGO
BEQ QRTN
CALL PRCTLO
CALL PNILIN,<MTQMSG>
CALL PRESC
BR QRTN

:**ENTRY POINT**
:SAVE R0...R5
:CLR QUEUE LOAD EVENT FLAG
:POSITION COUNTER
:R0 POINTS AT TABLE
:IS ACTIVE FLAG SET IN TABLE?
:NO, LOOK FOR NEXT ONE
:YES, LOAD ADDR INTO QUEUE

:ALL ENTRIES CHECKED?

:IS THERE ANYTHING IN QUEUE?
:NO, THIS IS NOT A VALID PASS
:YES, INCR PASS NO.
:SET XMTR EVENT FLAG
:RESTORE R0...R5

:GET RCV ADDR INTO HIGH BYTE
:PUT IT IN ADDR QUEUE

:ARE WE RUNNING?
:NO, LEAVE
:STOP PRINTING ANYTHING ELSE
:TELL OPERATOR NO RCVR
:FAKE CNTRL-C
:RETURN

.SBTTL DATA GENERATION (RANDOM) ROUTINE

: GENERATE A BUFFER OF DATA AND NOTE THE FOLLOWING CONDITIONS:

: BITS <8:0> OF THE FIRST WORD = MESSAGE LENGTH
: IF THE FIRST WORD IS 170000 OR HIGHER, EXPECT A REJECT
: IF THE MESSAGE LENGTH IS > 600, EXPECT A TRUNCATE
: GENERATE RANDOM DATA USING THE FOLLOWING FORMULA:
: SN = (SN-1 * RANDOM NO.) + RANDOM INCREMENT

: WHERE S = DATA SEED; AND N = A NUMBER FROM 1 TO MESSAGE LENGTH.

: A MESSAGE LENGTH OF 0 IS NOT ALLOWED AND IS CHANGED TO 1.

1243									
1244									
1245									
1246									
1247									
1248									
1249									
1250									
1251									
1252									
1253									
1254									
1255									
1256									
1257									
1258	007136					PROC	DATGEN		
(1)									
(1)	007136					DATGEN:		:**ENTRY POINT**	
1259	007136	005067	010574			CLR	RCTXPS	:CLEAR DATA PASS FLAG	
1260	007142	005067	010572			CLR	RJCTF	:CLEAR REJECT SOFTWARE FLAG	
1261	007146	005067	010570			CLR	TRNKF	:CLR TRUNCATE SOFTWARE FLAG	
1262	007152	042767	177000	010552		BIC	#177000,MSGLSD	:LENGTH NOT TO EXCEED 1000	
1263	007160	001003				BNE	DTCNT	:IF NON-0, OKAY, CONTINUE.	
1264	007162	012767	000001	010542		MOV	#1,MSGLSD	:IF 0, MAKE IT AT LEAST 1	
1265	007170	026727	010536	000600	DTCNT:	CMP	MSGLSD,#600	:IS LENGTH LESS THAN 600?	
1266	007176	002403				BLT	DTGNC		
1267	007200	012767	177777	010534		MOV	#-1,TRNKF	:NO,SET TRUNCATE SOFTWARE FLAG	
1268	007206	022767	170000	010512	DTGNC:	CMP	#170000,DTSEED	:IS DATA SEED -10000 OR MORE?	
1269	007214	101005				BHI	DTGNCO		
1270	007216	012767	177777	010514		MOV	#-1,RJCTF	:YES SET REJECT SOFTWARE FLAG	
1271	007224	005067	010512			CLR	TRNKF	:AND CLR TRUNCATE SFTWR FLAG	
1272	007230	012700	020666		DTGNCO:	MOV	#DATBUF,R0	:POINT R0 TO TOP OF BUFFER	
1273	007234	016705	010472			MOV	MSGLSD,R5	:R5 IS MESSAGE LENGTH	
1274	007240	006105				ROL	R5	:DOUBLE IT	
1275	007242	005405				NEG	R5	:NEGATE IT	
1276	007244	010567	010474			MOV	R5,TXML	:SAVE IT FOR TRANSMIT MODULE	
1277	007250	016705	010456			MOV	MSGLSD,R5	:R5 IS MSG LENGTH AGAIN	
1278	007254	016720	010446		DTCLP:	MOV	DTSEED,(R0)+	:PUT WORD INTO BUFFER	
1279	007260					MULP	RANM,DTSEED	:GENERATE NEW RANDOM NUMBER	
1280	007302	066767	010442	010416		ADD	.NK,DTSEED		
1281	007310	005305				DEC	R5		
1282	007312	003360				BGT	DTCLP	:IF R5 = 0, FINISHED	
1283	007314	016767	010406	010410	DTCDON:	MOV	DTSEED,MSGLSD	:GET NEW LENGTH	
1284	007322	012767	100000	010344		MOV	#B15,TXMEV	:SET XMIT EVENT FLAG	
1285	007330	005067	010324			CLR	DATGEV	:CLEAR DAT GEN EVENT FLAG	
1286	007334					RETURN			

```
1288                                     .SBTTL MULTIPLY ROUTINE FOR DATA GENERATION
1289
1290                                     ;UNSIGNED MULTIPLY ROUTINE
1291                                     ;CALLED BY 'JSR R4,MLI'
1292                                     ;WITH MULTIPLICAND IN R4 AND MULTIPLIER ON STACK
1293                                     ;PRODUCT RETURNED ON TOP OF STACK
1294
1295 007336 012601 MLI: MOV (SP)+,R1 ;GET MULTIPLICAND
1296 007340 011603 MLI: MCV (SP),R3 ;GET MULTIPLIER
1297 007342 010446 MLI: MOV R4,-(SP) ;SAVE R4
1298 007344 012704 000020 MLI: MCV #16.,R4 ;SET UP FOR 16 BIT MULTIPLY
1299 007350 005002 MLI: CLR R2
1300 007352 006002 MUL: ROR R2 ;SHIFT PRODUCT
1301 007354 006003 MUL: ROR R3
1302 007356 103001 MUL: BCC CYCL ;CHECK IF MULTIPLIER BIT IS 0
1303 007360 060102 MUL: ADD R1,R2 ;ADD IN MULTIPLICAND
1304 007362 005304 CYCL: DEC R4 ;COUNT LOOP
1305 007364 003372 CYCL: BGT MUL
1306 007366 012604 CYCL: MOV (SP)+,R4 ;RESTORE R4
1307 007370 006202 CYCL: ASR R2 ;ONE LAST SHIFT
1308 007372 006003 CYCL: ROR R3 ;PRODUCT IS IN R3
1309 007374 010316 CYCL: MOV R3,(SP) ;STORE RESULT ON STACK
1310 007376 000134 CYCL: JMP @P4+ ;RETURN
1311
1312
1313                                     ;MACRO FOR THE ABOVE IS AS FOLLOWS:
1314                                     ;.MACRO MULP A,B
1315                                     ;MOV A,-(SP) ;SAVE A ON STACK
1316                                     ;MOV B,R4 ;SAVE B IN R4
1317                                     ;JSR R4,MLI ;PERFORM MULTIPLICATION
1318                                     ;.WORD +2
1319                                     ;MOV (SP)+,B ;PUT PRODUCT INTO B
1320                                     ;.ENDM
```

.SBTTL TRANSMIT MODULE

1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
(1)
(1)
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368

: CONTROL TRANSMISSION OF RANDOM DATA TO DE-QUEUED RECEIVER ADDRESSES
: IF 'PCLGO' IS SET, ('GO' OR 'CONTINUE' SET IT), START TRANSMITTING
: THE DATA CONTAINED IN THE BUFFER 'DATBUF'.
: THE TARGET RECEIVER ADDRESS IS DEQUEUED FROM THE ADDRESS QUEUE.
: THE MESSAGE LENGTH WAS DETERMINED DURING THE GENERATION OF THE DATA.
: NOTE THAT BIT 15 OF 'TXMST' MAY BE 1 OR 0 DEPENDING UPON THE USE
: OF THE 'RIB SET' OR 'RIB CLEAR' COMMANDS.

TXMST: .WORD 060101 ;TRANSMITTER COMMAND WORD

PROC TXMIT

TXMIT: ;**ENTRY POINT**
TST PCLGO ;CAN PCL GO?
BEQ TXRTN ;IF NOT, RETURN
CLR TXMEV ;CLR XMTR EVENT FLAG
BDINIT XMTR ;CLR XMTR HARDWARE
TST A00 ;ANY ELEMENTS IN ADDR QUEUE?
BEQ TXOUT ;IF NOT, FILL IT UP AGAIN
MOV TXML,@TSBC ;LOAD BYTE COUNT
MOV #DATBUF,@TSBA ;LOAD BUS ADDRESS
CALL DEQ,<FRELEM,A00> ;DEQUEUE RECEIVER ADDRESS
MOVB FRELEM+1,CURAD ;GET ADDRESS TABLE OFFSET
MOV CURAD,R0 ;FIND ADDRESS TABLE ENTRY
ASL R0 ; IN ORDER TO UPDATE
ASL R0 ; 'ATTEMPTS'
MOV R0,R5
ASL R0
ADD R5,R0
ADD #RADBO,R0 ;UPDATE DOUBLE WORD
ADD #1,6(R0)
ADC 4(R0)
MOV FRELEM,@TCR ;GIVE RECEIVER ADDR TO XMTR
BIS TXMST,@TCR ;START TRANSMISSION
TXRTN: RETURN
TXOUT: MOV #B15,QLDEV ;SET QUEUE LOAD EVENT FLAG
CMP RCTXPS,#4 ;IS THIS THE 5TH PASS?
BEQ TXDGEN ;IF SO, SET DATA GEN EVENT FLAG
JMP TXRTN ;RETURN
TXDGEN: MOV #B15,DATGEV ;SET DAT GEN EVENT FLAG
JMP TXRTN ;RETURN

```
1370      :::TRANSMITTER INTERRUPT HANDLER
1371      ::: SORT THE CAUSES OF TRANSMITTER INTERRUPTS
1372      ::: AND GO TO THE PROPER HANDLING ROUTINE.
1373
1374
1375      100000      TXER      -      100000
1376      000020      TXBSY     =      20
1377      000200      TXSUC     -      200
1378      000040      TXSOR     =      40
1379      000004      NOWMST    =      4
1380
1381      007600      XMTINT:  REGSAV      :::SAVE R0...R5
1382      007604      042777 000100 006264      BIC      #B06,@TCR      :::CLR TXM INTR ENABLE
1383      007612      012737 000200 177776      MOV      #200,@#PS      :::ALLOW RCVR INTR BUT NOT TTY
1384      007620      032777 100000 006252      BIT      #TXER,@TSR      :::IS THERE A HARDWARE ERROR?
1385      007626      001402      BEQ      XMTIS      :::NO, CHECK SUC TXF
1386      007630      000167 000114      JMP      ERRINT      :::HANDLE ERROR
1387      007634      032777 000200 006236      XMTIS:  BIT      #TXSUC,@TSR      :::WAS IT A SUC TRANSFER?
1388      007642      001402      BEQ      XMTSR      :::NO, CHECK SOFTWARE REJECT
1389      007644      000167 000610      JMP      SUCINT      :::HANDLE SUC TXF
1390      007650      032777 000040 006222      XMTSR:  BIT      #TXSOR,@TSR      :::WAS MESSAGE REJECTED?
1391      007656      001402      BEQ      XMTPNM      :::NO,CHECK NOW MASTER
1392      007660      000167 000772      JMP      SORINT      :::HANDLE REJECT
1393      007664      132777 000004 006220      XMTPNM: BITB     #NOWMST,@TMMRH      :::IS THIS UNIT NOW MASTER?
1394      007672      001402      BEQ      XMTIB      :::NO, WAS RECVR BUSY?
1395      007674      000167 001074      JMP      NMINT      :::YES, HANDLE NOW MASTER INT
1396      007700      032777 000020 006172      XMTIB:  BIT      #TXBSY,@TSR      :::WAS RECEIVER BUSY
1397      007706      001402      BEQ      XMTPRB      :::NO, INTERRUPT WAS ERRONEOUS
1398      007710      000167 000514      JMP      BSYINT      :::HANDLE BUSY
1399      007714      012767 100000 007752      XMTPRB: MOV      #B15, TXMEV      :::SET XMTR EVENT FLAG
1400      007722      ERROT      \N      :::ERROR:ERRONEOUS INTERRUPT FROM XMTR
      (1)
      (1)
      (1)
1401      007742      REGRES      :::RESTORE R0...R5
1402      007746      000002      RTI      :::RETURN
```

```

1404      ;XMTR ERROR INTERRUPT ROUTINE
1405
1406
1407      ; DETERMINE AND REPORT THE CAUSE OF THE TRANSMITTER ERROR.
1408
1409
1410 007750 032777 040000 006122 ERRINT: BIT    #B14,@TSR      ;IS ERROR NON EXISTANT LOCATION?
1411 007756 001412          BEQ    ERA          ;
1412 007760          ERROT  \N          ;ERROR:NON-EXISTANT LOC ERROR IN XMTR
(1)
(1)
(1)
1413 010000 000167 000402          JMP    ERRX
1414 010004 032777 020000 006066 ERA:   BIT    #B13,@TSR      ;IS ERROR MEM OFL?
1415 010012 001412          BEQ    ERB          ;
1416 010014          ERROT  \N          ;ERROR:MEM OFL ERROR IN XMTR
(1)
(1)
(1)
1417 010034 000167 000346          JMP    ERRX
1418 010040 032777 010000 006032 ERB:   BIT    #B12,@TSR      ;IS ERROR TXM ERROR?
1419 010046 001472          BEQ    ERRC
1420 010050 017767 006024 007676 MOV    @TSR,RSPC      ;SAVE RESPONSE CODES
1421 010056 042767 177760 007670 BIC    #-20,RSPC     ;REMOVE GARBAGE
1422 010064 022767 000015 007662 CMP    #15,RSPC     ;RSP CODES 11&01?
1423 010072 001012          BNE    ERB1
1424 010074          ERROT  \N          ;ERROR:TXM ERROR. RCVR ACCEPTED A NULL
(1)
(1)
(1)
1425 010114 000167 000266          JMP    ERRX
1426 010120 042767 000003 007626 ERB1:  BIC    #3,RSPC      ;DISCARD RSP A'S
1427 010126 001012          BNE    ERB2
1428 010130          ERROT  \N          ;ERROR:TXM ERROR. RCVR HAS GONE OFF LINE
(1)
(1)
(1)
1429 010150 000167 000232          JMP    ERRX
1430 010154 022767 000010 007572 ERB2:  CMP    #10,RSPC     ;RSP B = 10?
1431 010162 001012          BNE    ERB3
1432 010164          ERROT  \N          ;ERROR:TXM ERROR. WORD OR CRC REJECTED
(1)
(1)
(1)
1433 010204 000167 000176          JMP    ERRX
1434 010210          ERROT  \N          ;ERROR:MISCELLANEOUS TXM ERROR
(1)
(1)
(1)
1435 010230 000167 000152          JMP    ERRX
1436 010234 032777 004000 005636 ERRC:  BIT    #B11,@TSR      ;MASTER DOWN?
1437 010242 001417          BEQ    ERD
1438 010244          ERROT  \N          ;ERROR: M A S T E R D O W N
(1)
(1)
(1)

```

;***** XMTR ERROR 10 *****

```

1439 010264 005067 007410          CLR      PCLGO          ;STOP TRANSMITTER
1440 010270 012767 100000 007406    MOV      #B15,SPCEV     ;SET SPECIAL EVENT FLAG
1441 010276 000167 000104          JMP      ERRX
1442 010302 032777 002000 005570  ERRD:   BIT      #B10,@TSR     ;TIMEOUT ERROR?
1443 010310 001422          BEQ      ERRE
1444 010312 032777 100000 005556    BIT      #B15,@TCR     ;IS 'R.I.B.' SET?
1445 010320 001404          BEQ      1$            ;NO MUST BE WEIRD ERROR.
1446 010322 032777 000020 005550    BIT      #TXBSY,@TSR   ;YES, IS TDM BUS BUSY?
1447 010330 001010          BNE      2$            ;YES, RECEIVER WASN'T THERE
1448 010332          1$:      ERROT      \N          ;ERROR: ERRONEOUS TIMEOUT IN TRANSMITTER
      (1)
      (1)
      (1)
      (1)
1449 010352 000167 000030          JMP      ERRX
1450 010356 032777 001000 005514  ERRE:   BIT      #B09,@TSR     ;TXM SILO OVERRUN?
1451 010364 001410          BEQ      ERRX
1452 010366          ERROT      \N          ;ERROR:SILO OVERRUN ERROR IN XMTR
      (1)
      (1)
      (1)
      (1)
1453 010406          ERRX:   BDINIT      XMTR          ;CLEAR ALL XMTR HARDWARE
1454 010414 012767 100000 007252    MOV      #B15,TXMEV     ;SET XMTR EVENT FLAG
1455 010422          REGRES
1456 010426 000002          RTI                    ;RESTORE R0...R5
                          ;RETURN
  
```

```

1458           ;BUSY INTERRUPT ROUTINE
1459
1460 010430 042777 000020 005442 BSYINT: BIC      #TXBSY,@TSR      ;CLEAR TDM BUS BUSY
1461 010436 012767 100000 007230      MOV      #B15,TXMEV    ;SET TXM EVENT FLAG
1462 010444      BDINIT  XMTR      ;CLEAR HARDWARE
1463 010452      REGRES      ;RESTORE RO...R5
1464 010456 000002      RTI      ;RETURN
1465
1466           ;SUCCESSFUL TRANSFER INTERRUPT ROUTINE
1467
1468
1469 010460 042777 000200 005412 SUCINT: BIC      #TXSUC,@TSR      ;CLEAR SUC TXF
1470 010466 005767 007250      TST      TRMKF      ;IS SFTWR TRUNCATE FLAG SET?
1471 010472 001047      BNE      SUCIA      ;YES, GO CHECK SORE
1472 010474 032777 000040 005376 SUCINY: BIT      #TXSOR,@TSR    ;IS SORE SET?
1473 010502 001414      BEQ      SUCINP      ;NO, CONTINUE
1474 010504      ERROT  \N      ;ERROR:MESSAGE TRUNCATED UNEXPECTEDLY
(1)
(1)
(1)
1475 010524 000421      BR      SHBRT      ;DON'T INC SUC CONNS IF ERROR
1476 010526 042777 000040 005344 SUCINP: BIC      #TXSOR,@TSR    ;CLR SORE
1477 010534 016700 007212      MOV      CURAD,R0      ;PREPARE TO UPDATE STATUS TABLE
1478 010540 006300      ASL      R0      ;GET TABLE ENTRY FOR CURRENT
1479 010542 006300      ASL      R0      ;RECEIVER ADDRESS IN
1480 010544 010005      MOV      R0,R5      ;
1481 010546 006300      ASL      R0      ;
1482 010550 060500      ADD      R5,R0      ;
1483 010552 062700 020064      ADD      #RADBO,R0      ;
1484 010556 062760 000001 000012 ADD      #1,12(R0)      ;
1485 010564 005560 000010      ADC      10(R0)      ;
1486 010570 012767 100000 007076 SHBRT: MOV      #B15,TXMEV    ;SET TRANSMIT EVENT FLAG
1487 010576      BDINIT  XMTR      ;CLEAR HARDWARE
1488 010604      REGRES      ;RESTORE RO...R5
1489 010610 000002      RTI      ;RETURN
1490
1491 010612 032777 000040 005260 SUCIA: BIT      #TXSOR,@TSR    ;IS SORE SET? (SHOULD BE SET)
1492 010620 001011      BNE      SUCCS      ;
1493 010622      ERROT  \N      ;ERROR:MSG FAILED TO BE TRUNCATED
(1)
(1)
(1)
1494 010642 000752      BR      SHBRT      ;DON'T INC SUC CONNS IF ERROR
1495 010644 042777 000040 005226 SUCCS: BIC      #TXSOR,@TSR    ;CLR SORE
1496 010652 000*67 177616      JMP      SUCINY      ;PROCESS SUC TXF AS NORMAL
  
```

```
1498 ;SOFTWARE REJECT INTERRUPT ROUTINE
1499
1500 010656 005767 007056 SORINT: TST RJCTF ;IS SFTWR REJECT FLAG SET?
1501 010662 001432 BEQ SORIP ;IF NOT, SOMETHING'S WRONG
1502 010664 016700 007062 MOV CURAD,R0 ;PREPARE TO UPDATE STATUS TABLE
1503 010670 006300 ASL R0 ;GET TABLE ENTRY FOR CURRENT
1504 010672 006300 ASL R0 ;RECEIVER ADDRESS IN
1505 010674 010003 MOV R0,R3 ;
1506 010676 006300 ASL R0 ;ORDER TO UPDATE
1507 010700 060300 ADD R3,R0 ;
1508 010702 062700 020064 ADD #RADB0,R0 ; 'SUCCESSFUL' ELEMENT
1509 010706 062760 000001 000012 ADD #1,12(R0) ;UPDATE ENTRY
1510 010714 005560 000010 ADC 10(R0)
1511 010720 042777 000040 005152 SORCNT: BIC #TXSOR,@TSR ;CLR SORE
1512 010726 012767 100000 006740 MOV #B15, TXMEV ;SET XMIT EVENT FLAG
1513 010734 BDINIT XMTR ;CLEAR HARDWARE
1514 010742 REGRES ;RESTORE R0...R5
1515 010746 000002 RTI ;RETURN
1516
1517 010750 SORIP: ERROT \N ;ERROR:ERRONEOUS REJECT BY RECEIVER
(1)
(1) ;**** XMTR ERROR 15 ****
(1)
1518 010770 000167 177724 JMP SORCNT ;RETURN
1519
1520
1521
1522 ;NOW MASTER INTERRUPT ROUTINE
1523 ;SET XSPEC EVENT FLAG (XSPEV)
1524 ;AND CLR NOW MST
1525
1526 010774 142777 000004 005110 NMINT: BICB #NOWMST,@TMMRH ;CLEAR NOW MASTER
1527 011002 012767 100000 006676 MOV #B15,XSPCEV ;SET EXTRA-SPECIAL EVENT
1528 011010 052777 000100 005060 BIS #B06,@TCR ;RE-SET INTERRUPT ENABLE
1529 011016 REGRES ;RESTORE R0...R5
1530 011022 000002 RTI ;RETURN
1531
1532
```



```
1534 .SBTTL RECEIVER MODULE
1535
1536 ;CONTROL RECEPTION OF DATA.
1537 ; DATA IS STORED IN A BUFFER 'RCBUF'
1538 ; FOR LATER CHECKING.
1539 ; 'RCBUF' BUFFER IS CLEARED BEFORE RECEPTION.
1540
1541 ;ACTIVE IF RCVEV IS -VE
1542
1543 RCWD - B13
1544
1545 .PROC RECV
1546 (1) 011024 RECV: ;**ENTRY POINT**
1547 (1) 011024 005067 006652 CLR RCVEV ;CLR RCVR EVENT FLAG
1548 011030 004767 000040 JSR PC,DBFCLR ;CLEAR RCVR DATA BUFFER FIRST
1549 011042 012777 022726 005056 BDINIT RCVR ;CLR HARDWARE (REGARDLESS)
1550 011050 012777 176400 005046 MOV #RCBUF,@RDBA ;LOAD RCVR BUS ADDRESS
1551 011056 012777 020000 005032 MOV #-1400,@RDBC ;LOAD BYTE COUNT FOR 600 WORDS
1552 011064 052777 000100 005024 MOV #RCWD,@RCR ;SET RCV WORD IN RCVR
1553 011072 BIS #B06,@RCR ;SET RCVR INTERRUPT ENABLE
1554 RETURN
1555
1556
1557 011074 DBFCLR: REGSAV ;SAVE R0...R5
1558 011100 012700 022726 MOV #RCBUF,R0 ;R0 POINTS AT BUFFER AREA
1559 011104 012701 000700 MOV #700,R1 ;R1 HOLDS BUFFER SIZE
1560 011110 005020 DBCLP: CLR (R0)+ ;CLEAR BUFF LOC
1561 011112 005301 DEC R1 ;DONE ?
1562 011114 003375 BGT DBCLP ;NO,LOOP
1563 011116 REGRES ;YES, RESTORE R0...R5
1564 011122 000207 RTS PC ;AND RETURN
```

```
1566      :::RECEIVER INTERRUPT HANDLER.  
1567  
1568      100000      RCER      =      100000  
1569      000400      RCDOR     =      400  
1570      000200      RCSUC     =      200  
1571      000040      RCRCM     =      40  
1572  
1573 011124      RCVINT: REGSAV      :::SAVE R0...R5  
1574 011130 032777 100000 004752      BIT      #RCER,@RSR      :::IS THERE A HARDWARE ERROR?  
1575 011136 ^01402      BEQ      RCVINA      :::NO,CHECK DATA OUTPUT READY  
1576 011140 000167 000100      JMP      RERINT      :::HANDLE ERROR INTERRUPT  
1577 011144 032777 000400 004746      RCVINA: BIT      #RCDOR,@RSR      :::IS DATA OUTPUT READY?  
1578 011152 001402      BEQ      RCVINB      :::NO, CHECK SUC TXF  
1579 011154 000167 000472      JMP      RDOINT      :::HANDLE DATA OUTPUT RDY INTERRUPT  
1580 011160 032777 000200 004732      RCVINB: BIT      #RCSUC,@RSR      :::SUCCESSFUL TRANSFER SET?  
1581 011166 001402      BEQ      RCVINC      :::NO, CHECK RECECT COMPLETED  
1582 011170 000167 000536      JMP      RSUINT      :::HANDLE SUC TXF INTERRUPT  
1583 011174 032777 000040 004716      RCVINC: BIT      #RCRCM,@RSR      :::REJECT COMPLETED INTERRUPT?  
1584 011202 001402      BEQ      RCVIND      :::NO,ERRONEOUS INTERRUPT  
1585 011204 000167 000776      JMP      RRJINT      :::HANDLE REJ-COM INTERRUPT  
1586 011210      RCVIND: ERROR      \N      :::ERROR:UNKNOWN RECEIVER INTERRUPT OCCURRED  
      (1)  
      (1)  
      (1)  
1587 011230 012767 100000 006444      MOV      #B15,RCVEV      :::SET RCVR EVENT FLAG  
1588 011236      REGRES      :::RESTORE R0...R5  
1589 011242 000002      RTI      :::RETURN
```

```

1591          ;RCVR ERROR INTERRUPT ROUTINE
1592
1593 011244 032777 040000 004646 RERINT BIT #B14,@RSR          ;IS ERROR NON EXST LOC ERR?
1594 011252 001412          BEQ RERRA
1595 011254          ERROR \N          ;ERROR:NON EXST LOC ERR IN RCVR
(1)
(1)          ;**** RCVR ERROR 17 ****
(1)
1596 011274 000167 000332          JMP RERRX
1597 011300 032777 020000 004612 RERRA: BIT #B13,@RSR          ;IS ERROR MEM OFLO?
1598 011306 001412          BEQ RERRB
1599 011310          ERROR \N          ;ERROR:MEM OFLO ERROR IN RCVR
(1)
(1)          ;**** RCVR ERROR 20 ****
(1)
1600 011330 000167 000276          JMP RERRX
1601 011334 032777 010000 004556 RERRB: BIT #B12,@RSR          ;ANY TRANSMISSION ERRORS?
1602 011342 001457          BEQ RERRC
1603 011344 017767 004550 006402 MOV @RSR,RSPC          ;GET RESPONSE CODES
1604 011352 042767 177760 006374 BIC #-20,RSPC          ;REMOVE GARBAGE
1605 011360 032767 000003 006366 BIT #3,RSPC          ;LOOK AT TXM RSP CODES
1606 011366 001012          BNE RERRB1
1607 011370          ERROR \N          ;ERROR:TXM WENT OFF LINE
(1)
(1)          ;**** RCVR ERROR 21 ****
(1)
1608 011410 000167 000216          JMP RERRX
1609 011414 042767 000003 006332 RERRB1: BIC #3,RSPC          ;REMOVE TXM RSP CODES NOW
1610 011422 022767 000010 006324 CMP #10,RSPC          ;WAS THERE A CRC ERROR?
1611 011430 001012          BNE RERRB2
1612 011432          ERROR \N          ;ERROR:RCVR CRC ERROR OCCURRED
(1)
(1)          ;**** RCVR ERROR 22 ****
(1)
1613 011452 000167 000154          JMP RERRX
1614 011456          ERROR \N          ;ERROR:FIRST WORD RECVD NOT VALID
(1)
(1)          ;**** RCVR ERROR 23 ****
(1)
1615 011476 000167 000130          JMP RERRX
1616 011502 032777 004000 004410 RERRC: BIT #B11,@RSR          ;WAS ERROR A PARITY ERROR?
1617 011510 001412          BEQ RERRD
1618 011512          ERROR \N          ;ERROR:RCVR DETECTED INVALID PARITY
(1)
(1)          ;**** RCVR ERROR 24 ****
(1)
1619 011532 000167 000074          JMP RERRX
1620 011536 032777 002000 004354 RERRD: BIT #B10,@RSR          ;DID RCVR TIME OUT?
1621 011544 001412          BEQ RERRE
1622 011546          ERROR \N          ;ERROR:RCVR TIMEOUT ERROR OCCURRED
(1)
(1)          ;**** RCVR ERROR 25 ****
(1)
1623 011566 000167 000040          JMP RERRX
1624 011572 032777 001000 004320 RERRE: BIT #B09,@RSR          ;WAS IT BYTE COUNT OVERFLOW?
1625 011600 001412          BEQ RERRX

```

1626	011602	052777	100000	004306	BIS	#B15,@RCR	;IMMEDIATLY SET REJECT IN RCVR
1627	011610	042777	040000	004300	BIC	#B14,@RCR	;CLEAR RCVR NPR BIT
1628	011616	042777	001000	004274	BIC	#B09,@RSR	;CLR BYTE COUNT OVERFLOW
1629	011624				RERTRN:	REGRES	;RESTORE RO...RS
1630	011630	000002				RTI	;RETURN
1631	011632				RERRX:	BDINIT RCVR	;CLEAR RECVR
1632	011640	012767	100000	006034		MOV #B15,RCVEV	;SET RCV EVENT FLAG
1633	011646	000167	177752			JMP RERTRN	
1634							

```

1636 ;RCVR DATA OUTPUT RDY INTERRUPT ROUTINE
1637
1638 011652 042777 000100 004236 RDOINT: BIC #B06,@RCR ;CLEAR INTR ENAB
1639 011660 017767 004236 006046 MOV @RDDB,RCSEED ;GET FLAG-WORD FOR DATA SEED
1640 011666 022767 170000 006040 CMP #170000,RCSEED ;LOOK AT DATA SEED
1641 011674 101011 BHI RDOINC ;IF MORE -VE THAN -10000
1642 011676 052777 100000 004212 BIS #B15,@RCR ; SET REJECT IN RCVR
1643 011704 RDORTN: REGRES ;RESTORE RO...R5
1644 011710 052777 000100 004200 BIS #B06,@RCR ;RE-SET INTR ENAB
1645 011716 000002 RTI ;RETURN
1646 011720 052777 040001 004170 RDOINC: BIS #B14+B00,@RCR ;START RECEIVER GOING
1647 011726 000167 177752 JMP RDORTN
1648
1649 ;RCVR SUC TXF INTERRUPT ROUTINE
1650
1651 011732 032777 000040 004160 RSUINT: BIT #RCRCM,@RSR ;WAS RECOM SET?
1652 011740 001403 BEQ RSUCNT ;NO, CONTINUE
1653 011742 042777 000040 004150 BIC #RCRCM,@RSR ;YES, CLR IT AND CONTINUE
1654 011750 016701 005760 RSUCNT: MOV RCSEED,R1 ;GET DATA SEED
1655 011754 042701 177000 BIC #177000,R1 ;MASK MSG LENGTH
1656 011760 001002 BNE RSNT0 ;IF NOT 0, OKAY
1657 011762 012701 000001 MOV #1,R1 ;IF 0, MAKE IT 1
1658 011766 162701 000001 RSNT0: SUB #1,R1 ;ACCOUNT FOR FLAG WORD
1659 011772 020127 000600 CMP R1,#600 ;IS IT GREATER THAN 600?
1660 011776 003402 BLE RSFLSZ ;NO, LEAVE IT ALONE
1661 012000 012701 000600 MOV #600,R1 ;YES, SET IT TO LIMIT (600)
1662 012004 012700 001400 RSFLSZ: MOV #1400,R0
1663 012010 067700 004110 ADD @RDBC,R0 ;DETERMINE # OF BYTES RECEIVED
1664 012014 001451 BEQ RSULV ;NOTHING TO CHECK, EXIT
1665 012016 006200 ASR R0 ;R0 = NO. OF WORDS RECEIVED
1666 012020 020001 CMP R0,R1 ;DID WE RECV ALL THE WORDS?
1667 012022 001412 BEQ RSUTST ;YES, CARRY ON
1668 012024 103456 BLO ERNE ;NOT ENOUGH !
1669 012026 ERROR \N ;ERROR:RCVR GOT TOO MANY WORDS..
(1)
(1)
(1)
1670 012046 000434 BR RSULV ;EXIT IF ERROR
1671 012050 012705 022726 RSUTST: MOV #RCBUF,R5 ;R5 POINTS AT RECVD DATA
1672 012054 RSUGEN: MULP RANM,RCSEED ;GENERATE CHECK WORD
1673 012076 066767 005646 005630 ADD RANK,RCSEED ;COMPARE IT WITH RECV'D WORD
1674 012104 026725 005624 CMP RCSEED,(R5)+
1675 012110 001411 BEQ RSUCHK
1676 012112 ERROR \N ;ERROR:DATA WORD RECV'D WAS BAD
(1)
(1)
(1)
1677 012132 000402 BR RSULV ;EXIT IF ERROR
1678 012134 005300 RSUCHK: DEC R0 ;CHECKED ALL WORDS?
1679 012136 001346 BNE RSUGEN ;NO,CONTINUE
1680 012140 RSULV: BDINIT RCVR ;CLR HARDWARE
1681 012146 REGRES ;RESTORE RO...R5
1682 012152 012767 100000 005522 MOV #B15,RCVEV ;SET RCVR EVENT FLAG
1683 012160 000002 RTI ;RETURN
1684
1685 012162 ERNE: ERROR \N ;ERROR: RCVR GOT TOO FEW WORDS ..

```

```

(1)
(1)
(1)
1686 012202 000167 177732          JMP      RSULV          ;**** RCVR ERROR 30 ****
1687                                     ;EXIT IF ERROR
1688                                     ;RCVR REJECT INTERRUPT ROUTINE
1689
1690 012206          RRJINT: BDINIT  RCVR          ;CLEAR HARDWARE
1691 012214 012767 100000 005460    MOV      #B15,RCVEV    ;SET RCVR EVENT FLAG
1692 012222          REGRES          ;RESTORE R0...R5
1693 012226 000002          RTI          ;RETURN
1694
1695                                     ;KW11 CLOCK INTERRUPT ROUTINE
1696                                     ;UPDATE TICKS. IF = 60. UPDATE SECONDS.
1697                                     ;IF SECS = 60, UPDATE MINUTS. IF MINUTS - 60
1698                                     ;UPDATE HOURS.
1699
1700 012230 042777 000200 003712    CLKINT: BIC      #B07,@LCS ;JUST IN CASE IT MATTERS.
1701 012236 105267 005400          INCB     TICKS        ;UPDATE TICKS
1702 012242 126727 005374 000074    CMPB    TICKS,#60.    ;GET TO 60 YET?
1703 012250 103424          BLO     CLKEXT        ;NO
1704 012252 105067 005364          CLRB    TICKS        ;YES, CLR TICKS
1705 012256 105267 005361          INCB    SECNDS       ;& UPDATE SECONDS
1706 012262 126727 005355 000074    CMPB    SECNDS,#60.  ;GET 60 SECS?
1707 012270 103414          BLO     CLKEXT        ;NO
1708 012272 105067 005345          CLRB    SECNDS       ;YES, CLR SECNDS
1709 012276 105267 005342          INCB    MINUTS       ;& UPDATE MINUTES
1710 012302 126727 005336 000074    CMPB    MINUTS,#60.  ;GET 60 MINUTES?
1711 012310 103404          BLO     CLKEXT        ;NO
1712 012312 105067 005326          CLRB    MINUTS       ;YES, CLEAR MINUTS
1713 012316 005267 005324          INC     HOURS        ;& UPDATE HOURS
1714 012322 000002          CLKEXT: RTI          ;RETURN
  
```

.SBTTL STATUS MODULE

1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769

012324
(1)
(1) 012324
012324 005767 004274
012330 001402
012332 000167 000540
012336 005767 005326
012342 001504
012344 026727 005320 020664
012352 002402
012354 000167 000476
012360 005777 005304
012364 001002
012366 000167 000452
012372 012700 032054
012376 062767 000002 005264
012404 017701 005260
012410 012702 177777
012414 004767 020262
012420 062767 000002 005242
012426 012700 032076
012432 016701 005232
012436 012702 177777
012442 004767 020434
012446 020027 032123
012452 103003
012454 112720 000040
012460 000772
012462 062767 000004 005200
012470 012700 032124
012474 016701 005170
012500 012702 177777
012504 004767 020372
012510 020027 032140
012514 103003
012516 112720 000040
012522 000772
012524
012542 062767 000004 005120
012550 000167 000322
012554 132777 000001 003330
012562 001407
012564

: DUMP STATUS TABLE INDICATING ACTIVATED RECEIVERS
: SHOW NO. OF ATTEMPTED CONNECTIONS TO EACH ACTIVE RECEIVER
: AND NO. OF SUCCESSFUL CONNECTIONS TO EACH ACTIVE RECEIVER.
: QUANTITIES ARE IN DECIMAL AND ARE CAPABLE OF EXPANDING TO
: 655,359,999. ANY QUANTITY HIGHER THAN THAT AMOUNT WILL BE
: REPRESENTED AS '*****'. RECEIVER ADDRESS NUMBERS ARE
: PRINTED IN OCTAL
:

PROC	STATUS	
	STATUS:	: **ENTRY POINT**
TST	T00	: IS TTY OUT QUEUE EMPTY?
BEQ	60\$	
JMP	STRTN	: NO, RETURN TO WHEREVER
TST	S:PNTR	: IS OUTPUT POINTER AT TABLE?
BEQ	STHDR	: NO, GO PRINT HEADER
CMP	STPNTR,#RADEND	: IS POINTER AT END OF TABLE?
BLT	59\$: YES, DONE; EXIT
JMP	STARXT	
TST	@STPNTR	: CHECK RCV ADDR ACTIVE FLAG
BNE	58\$	
JMP	STBADV	: ADVANCE TABLE IF FLAG CLR
MOV	#STLIN1,R0	: OUTPUT POINTER FOR OCTJSP
ADD	#2,STPNTR	
MOV	@STPNTR,R1	: OCTJSP DUMPS DATA IN STPNTR
MOV	#-1,R2	: DON'T COMPRESS BLANKS
JSR	PC,OCTJSP	
ADD	#2,STPNTR	
MOV	#STLIN2,R0	: OUTPUT POINTER FOR CDDMG
MOV	STPNTR,R1	: OUTPUT WORD FOR CDDMG
MOV	#-1,R2	: DON'T COMPRESS BLANKS
JSR	PC,CDDMG	
CMP	R0,#STLIN2+25	: BLANK REST OF FIELD OUT
BHIS	STYON	: BY INSERTING SPACES
MOVB	#',(R0)+	
BR	STYHR	
ADD	#4,STPNTR	
MOV	#STLIN3,R0	: OUTPUT POINTER FOR CDDMG
MOV	STPNTR,R1	: OUTPUT WORD FOR CDDMG
MOV	#-1,R2	: DON'T COMPRESS BLANKS
JSR	PC,CDDMG	
CMP	R0,#STLIN3+14	: BLANK REST OF FIELD OUT
BHIS	STYONT	: BY INSERTING SPACES
MOVB	#',(R0)+	
BR	STYHR	
CALL	PNTLIN,<STLIN>	: ENQUEUE STATUS LINE FOR OUTPUT
ADD	#4,STPNTR	: UPDATE POINTER FOR NEXT LINE
JMP	STRTN	: RETURN
BITB	#1,@TMMRH	: IS MASTER SET HERE?
BEQ	1\$: NO.
CALL	PNTLIN,<THUMST>	: YES, TELL OPERATOR.

```

1770 012602 132777 000002 003302 1$: BITB #2,@TMMRH ;WELL, IS SECONDARY SET?
1771 012610 001407 BEQ 2$ ;NO.
1772 012612 CALL PNTLIN,<THUSCN> ;YES, TELL OPERATOR
1773 012630 032767 100000 174542 2$: BIT #B15,TXMST ;IS 'RIB' SET?
1774 012636 001410 BEQ 3$ ;NO, TELL OPERATOR
1775 012640 CALL PNTLIN,<RBSTMG> ;YES, TELL OPERATOR
1776 012656 000407 BR 4$
1777 012660 3$: CALL PNTLIN,<RBCLMG>
1778 012676 005767 004746 4$: TST KWFLG ;GOT A CLOCK?
1779 012702 001444 BEQ 5$ ;NO, FORGET ABOUT TIME.
1780 012704 005002 CLR R2 ;SUPPRESS LEADING ZEROS
1781 012706 012700 031741 MOV #TMLIN1,R0 ;OUTPUT POINTER FOR DECPNT
1782 012712 016701 004730 MOV HOURS,R1 ;OUTPUT DATA FOR DECPNT
1783 012716 004767 020002 JSR PC,DECPNT ;ENQUEUE 'HOURS'
1784 012722 005002 CLR R2 ;SUPPRESS LEADING ZEROS
1785 012724 112720 000072 MOVB #'',(R0)+ ;INSERT COLON
1786 012730 116701 004710 MOVB MINUTS,R1 ;GET 'MINUTES' FOR DECPNT
1787 012734 004767 017764 JSR PC,DECPNT ;ENQUEUE 'MINUTES'
1788 012740 005002 CLR R2 ;SUPPRESS LEADING ZEROS
1789 012742 112720 000072 MOVB #'',(R0)+ ;INSERT ANOTHER COLON
1790 012746 116701 004671 MOVB SECNDS,R1 ;GET 'SECONDS' FOR DECPNT
1791 012752 004767 017746 JSR PC,DECPNT ;ENQUEUE 'SECONDS'
1792 012756 005002 CLR R2 ;SUPPRESS LEADING ZEROS
1793 012760 112720 000072 MOVB #'',(R0)+ ;INSERT ANOTHER COLON
1794 012764 116701 004652 MOVB TICKS,R1 ;GET 'TICKS' FOR DECPNT
1795 012770 004767 017730 JSR PC,DECPNT ;ENQUEUE 'TICKS'
1796 012774 105010 CLRB (R0) ;ENQUEUE '0' PRINT TERMINATOR.
1797 012776 CALL PNTLIN,<ELPSTM> ;PRINT 'ELAPSED TIME'
1798 013014 5$: CALL PNTLIN,<STITLE> ;ENQUEUE STATUS HEADER
1799 013032 012767 020100 004630 MOV #RADB,STPNTR ;SET POINTER TO TOP OF STAT LIST
1800 013040 000167 000032 JMP STRTN ;RETURN
1801
1802 013044 062767 000014 004616 STBADV: ADD #14,STPNTR ;SET POINTER TO NEXT ACTIVE FLAG
1803 013052 000167 000020 JMP STRTN
1804
1805 013056 005067 004604 STARXT: CLR STSEV ;CLR STATUS EVENT FLAG
1806 013062 CALL PRESC ;FAKE CNTRL-C KEY
1807 013076 STRTN: RETURN ;RETURN
  
```


1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
(1)
(1)
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862

013100
013100 005767 003520
013104 001402
013106 000167 000324
013112 005767 004600
013116 001422
013120 005067 004572
013124
013142
013160 000167 000252
013164 026727 004600 000016 1\$:
013172 001042
013174 005067 004452
013200 052767 100000 004446
013206 052767 100000 004502
013214 012767 000001 004550
013222 012767 026616 004544
013230 005767 004460
013234 001007
013236
013254
013270 005067 004420
013274 000167 000136
013300 005777 004470
013304 001434
013306 012700 032362
013312 016701 004452
013316 004767 017360
013322 012700 032377
013326 016701 004440
013332 004767 017344
013336 012700 032416
013342 017701 004426
013346 004767 017344
013352
013370 052767 100000 004316
013376 062767 000002 004370 4\$:
013404 026727 004362 000037
013412 001404
013414 005267 004352
013420 000167 000012
013424 012767 000001 004340 5\$:
013432 005267 004332
013436

.SBTTL TRANSMITTER ERRORS MODULE

:DUMP A TABLE OF TRANSMITTER ERRORS INCLUDING:
: ERROR NO., CONCT'D RCVR, AND ERROR COUNT FOR
: EACH OF THE TRANSMITTER ERRORS.
:IF THE ERROR COUNT FOR ANY ENTRY IS 0, THAT ERROR NO. IS NOT REPERTED
:IF, AFTER CHECKING THE ENTIRE XMTR ERROR TABLE, NO ERRORS
: ARE PRINTED, SIMPLY PRINT (NONE).

PROC TEROS

TEROS:

TST TOQ
BEQ 60\$
JMP TERTN
60\$: TST HDRFLG
BEQ 1\$
CLR HDRFLG
CALL PNTLIN,<TERHDR>
CALL PNTLIN,<TRHLIN>
JMP TERTN
1\$: CMP ERRO,#16
BNE 3\$
CLR TEREV
BIS #B15,REREV
BIS #B15,HDRFLG
MOV #1,ERR1
MOV #RERTBL,ERR2
TST PRINTD
BNE 2\$
CALL PNTLIN,<NONMG>
2\$: CALL PNCRLF
CLR PRINTD
JMP TERTN
3\$: TST @ERR2
BEQ 4\$
MOV #TRRNO,R0
MOV ERRO,R1
JSR PC,OCTJSP
MOV #TRRCN,R0
MOV ERR1,R1
JSR PC,OCTJSP
MOV #TRERC,R0
MOV @ERR2,R1
JSR PC,DECJSP
CALL PNTLIN,<TRELIN>
BIS #B15,PRINTD
4\$: ADD #2,ERR2
CMP ERR1,#37
BEQ 5\$
INC ERR1
JMP TERTN
5\$: MOV #1,ERR1
INC ERRO
TERTN: RETURN

:**ENTRY POINT**
:IS THE TTY OUTPUT QUEUE EMPTY?
:YES, CONTINUE
:NO, EXIT
:HEADER PRINTED YET?
:YES, SKIP IT
:NO, PRINT IT NOW.

:AND RETURN
:IS THIS ERROR # 16?
:NOT YET.
:YES, CLEAR XMTR ERROR EVENT
:SET RCVR ERROR EVENT
:SET HEADER FLAG
:LOAD INITIAL XMTR #
:POINT RCVR ERR EVENT AT ITS TABLE
:DID WE PRINT ANYTHING?
:YES, O.K.
:NO, PRINT '(NONE)'
:NEW LINE

:RETURN
:ANY ERRORS?
:NO.
:READY TO PRINT ERROR NO.

:ERROR NO. IS IN OCTAL
:READY TO PRINT RCVR NO.

:RCVR NO. IS ALSO IN OCTAL
:NOW PRINT ERROR COUNT

:ERROR COUNT IS IN DECIMAL
:ENQUEUE TABLE OUTPUT LINE
:SET 'PRINTED FLAG'
:UPDATE TABLE POINTER
:ALL RCVR'S DONE?
:YES.
:NO, DO NEXT

:NEXT ERROR NO.

```
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873 013440 PROC REROS
(1)
(1) 013440 REROS: ;**ENTRY POINT**
1874 013440 005767 003160 TST TOQ ;IS TTY OUTPUT QUEUE EMPTY?
1875 013444 001402 BEQ 60$ ;YES, CONTINUE
1876 013446 000167 000310 JMP RERTN ;NO, RETURN
1877 013452 005767 004240 60$: TST HDRFLG ;IS HEADER PRINTED YET?
1878 013456 001422 BEQ 1$ ;YES, SKIP IT
1879 013460 005067 004232 CLR HDRFLG ;NO, CLEAR FLAG
1880 013464 CALL PNTLIN,<RERHDR> ;AND PRINT HEADER
1881 013502 CALL PNTLIN,<RRHLIN>
1882 013520 000167 000236 JMP RERTN ;AND RETURN
1883 013524 026727 004240 000031 1$: CMP ERRO,#31 ;DONE LAST ERROR?
1884 013532 001034 BNE 3$ ;NOT YET
1885 013534 005067 004114 CLR REREV ;YES, CLEAR RCVR ERROR EVENT
1886 013540 005767 004150 TST PRINTD ;DID WE PRINT ANYTHING?
1887 013544 001007 BNE 2$ ;YES, O.K.
1888 013546 CALL PNTLIN,<NONMG> ;NO, PRINT '(NONE)''
1889 013564 2$: CALL PNCRLF
1890 013600 005067 004110 CLR PRINTD ;WRAP IT UP!
1891 013604 CALL PRESC
1892 013620 000167 000136 JMP RERTN
1893 013624 005777 004144 3$: TST @ERR2 ;ANY ERRORS?
1894 013630 001434 BEQ 4$ ;NO.
1895 013632 012700 032517 MOV #RCRNO,R0 ;READY TO PRINT ERROR NO.
1896 013636 016701 004126 MOV ERRO,R1
1897 013642 004767 017034 JSR PC,OCTJSP ;ERROR NO.S ARE IN OCTAL
1898 013646 012700 032534 MOV #RCTRN,R0 ;READY TO PRINT XMTR NO.
1899 013652 016701 004114 MOV ERR1,R1
1900 013656 004767 017020 JSR PC,OCTJSP ;XMTR NO.S ARE IN OCTAL
1901 013662 012700 032553 MOV #RCERC,R0 ;NOW PRINT ERROR COUNT
1902 013666 017701 004102 MOV @ERR2,R1
1903 013672 004767 017020 JSR PC,DECJSP ;ERROR COUNTS ARE IN DECIMAL
1904 013676 CALL PNTLIN,<RCELIN> ;ENQUEUE TABLE OUTPUT LINE
1905 013714 052767 100000 003772 BIS #B15,PRINTD ;SET 'PRINTED' FLAG
1906 013722 062767 000002 004044 4$: ADD #2,ERR2 ;UPDATE TABLE POINTER
1907 013730 026727 004036 000037 CMP ERR1,#37 ;ALL XMTRS DONE?
1908 013736 001404 BEQ 5$
1909 013740 005267 004026 INC ERR1 ;NO, DO NEXT
1910 013744 000167 000012 JMP RERTN
1911 013750 012767 000001 004014 5$: MOV #1,ERR1 ;YES, NEXT ERROR
1912 013756 005267 004006 INC ERRO
1913 013762 RERTN: RETURN
```

.SBTTL SUMMARY MODULE

```
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926 013764          PROC      SUMRY
      (1)
      (1) 013764          SUMRY:          ;**ENTRY POINT**
1927 013764 005767 002634          TST      TOQ          ;IS OUTPUT QUEUE EMPTY?
1928 013770 001126          BNE      SMRTN        ;NO, RETURN
1929 013772 005767 003674          TST      SUMPNT       ;IS OUTPUT POINTER AT TABLE?
1930 013776 001472          BEQ      SUMPHDR      ;NO, GO PRINT HEADER
1931 014000 027727 003666 177777 SMCHK:  CMP      @SUMPNT,#-1  ;IS ERROR # = -1 ?
1932 014006 001507          BEQ      SMARXT       ;YES,DONE; EXIT
1933 014010 016704 003656          MOV      SUMPNT,R4
1934 014014 005764 000004          TST      4(R4)        ;CHECK TOTAL COUNT OF THIS ERR
1935 014020 001475          BEQ      SMADV        ;IF 0, TRY NEXT ERROR
1936 014022 012700 032574          MOV      #SMLIN1,R0  ;R0 IS OUTPUT POINTER FOR OCTJSP
1937 014026 011401          MOV      (R4),R1     ;R1 IS DATA BUFF FOR OCTJSP
1938 014030 012702 177777          MOV      #-1,R2     ;DON'T COMPRESS BLANKS
1939 014034 004767 016642          JSR      PC,OCTJSP
1940 014040 012700 032616          MOV      #SMLIN2,R0
1941 014044 016401 000002          MOV      2(R4),R1
1942 014050 012702 177777          MOV      #-1,R2     ;DON'T COMPRESS BLANKS
1943 014054 004767 016622          JSR      PC,OCTJSP
1944 014060 012700 032642          MOV      #SMLIN3,R0
1945 014064 016401 000004          MOV      4(R4),R1
1946 014070 020127 177770          CMP      R1,#177770 ;REACHED MAX COUNT?
1947 014074 101415          BLOS    SMPN         ;NO,OK
1948 014076 112720 000115          MOV      #'M,(R0)+  ;YES, PRINT 'MXCNT' IN
1949 014102 112720 000130          MOV      #'X,(R0)+  ; NOTE THAT 'MXCNT'
1950 014106 112720 000103          MOV      #'C,(R0)+  ; ALSO HAS ONLY 5
1951 014112 112720 000116          MOV      #'N,(R0)+  ; ASCII CHARACTERS.
1952 014116 112720 000124          MOV      #'T,(R0)+
1953 014122 000404          BR      SMSPN
1954 014124 012702 177777          MOV      #-1,R2     ;DON'T COMPRESS BLANKS
1955 014130 004767 016562          SMPN:  JSR      PC,DECJSP
1956 014134          SMSPN: CALL      PNTLIN,<SMLIN> ;ENQUEUE SUM LINE FOR OUTPUT
1957 014152 062767 000006 003512          ADD      #6,SUMPNT  ;UPDATE POINTER FOR NEXT LINE
1958 014160 000167 000062          JMP      SMRTN       ;RETURN
1959
1960 014164          SUMHDR: CALL     PNTLIN,<SMITTLE> ;ENQUEUE SUMMARY HEADER
1961 014202 012767 024726 003462          MOV      #ERTBL,SUMPNT ;SET POINTER TO TOP OF SUM LIST
1962 014210 000167 000032          JMP      SMRTN       ;RETURN
1963
1964 014214 062767 000006 003450          SMADV: ADD      #6,SUMPNT ;SET POINTER TO NEXT ENTRY
1965 014222 000167 177552          JMP      SMCHK
1966
1967 014226 005067 003430          SMARXT: CLR      SUMEV  ;CLEAR SUMMARY EVENT FLAG
1968 014232          CALL     PRESC     ;FAKE CNTRL-C KEY
```

CZPLABO PCL11 EXERCISER V02
PCLEXR.P11 12-SEP-78 15:13

MACY11 30A(1052) 20-OCT-78 09:48 ^{N 7} PAGE 31-1
SUMMARY MODULE

SEQ 0091

1969 014246

SMRTN: RETURN

;RETURN

```

1971          .SBTTL ERROR UPDATE ROUTINES
1972          .SBTTL TRANSMITTER ERRORS
1973
1974          :CALLED BY THE MACRO 'CALL ERRMOD,<P,ERRADR>'
1975
1976 014250    PROC      ERRMOD,<ERRNUM,ERRADR>
(3)          ERRNUM    =      2
(3)          ERRADR    =      4
(1)
(1) 014250    ERRMOD:
1977 014250    010046    MOV      R0,-(SP)          ;**ENTRY POINT**
1978 014252    010146    MOV      R1,-(SP)          ;SAVE R0 ON STACK
1979 014254    010246    MOV      R2,-(SP)          ; AND R1
1980 014256    010346    MOV      R3,-(SP)          ; AND R2
1981 014260    017767    001612 003476  MOV      @TCR,TEMP      ;AND R3
1982 014266    042767    160377 003470  BIC      #160377,TEMP    ;SAVE ADDRESS OF CONNECTED RCVR
1983 014274    000367    003464          SWAB      TEMP          ;GET IT IN THE RIGHT BYTE
1984 014300    016500    000002          MOV      ERRNUM(R5),R0    ;GET ERROR NUMBER
1985 014304    010067    003456          MOV      R0,TEMP1        ;SAVE ERROR NUMBER
1986 014310    006300          ASL      R0              ;FIND TABLE ENTRY
1987 014312    010001          MOV      R0,R1           ;
1988 014314    006300          ASL      R0              ; IN ORDER TO UPDATE
1989 014316    060100          ADD      R1,R0           ; ADDRESS FIELD
1990 014320    062700    024720          ADD      #ERTBLO,R0
1991 014324    016560    000004 000002  MOV      ERRADR(R5),2(R0) ;ENTER ERROR ADDRESS
1992 014332    026027    000004 177771  CMP      4(R0),#177771   ;AT MAX COUNT YET?
1993 014340    103401          BLO      ERMIN           ;NO, INCREMENT COUNT
1994 014342    000444          BR       ERMIS          ;YES SKIP UPDATE.
1995 014344    005260    000004          ERMIN: INC      4(R0)      ;UPDATE OCCURRENCES
1996 014350    005367    003412          DEC      TEMP1          ; (ERR # - 1)
1997 014354          MULT    37,TEMP1,R3    ; (E-1)X37
1998 014420          MULT    2,TEMP1,R3    ; [(E-1)X37]X2
1999 014424    005367    003334          DEC      TEMP          ; RCVR ADDR - 1
2000 014430          MULT    2,TEMP,R3    ; (R-1)X2
2001 014434    066767    003326 003322  ADD      TEMP1,TEMP     ; [(E-1)X37]X2 + (R-1)X2
2002 014442    062767    025150 003314  ADD      #TERTBL,TEMP   ;TEMP = #TERTBL + <[(E-1)X37]X2 + (R-1)X2>
2003 014450    005277    003310          INC      @TEMP          ;UPDATE TABLE ENTRY FOR THIS ERROR
2004 014454    012603          ERMIS: MOV      (SP)+,R3      ;RESTORE R3
2005 014456    012602          MOV      (SP)+,R2      ;RESTORE R2
2006 014460    012601          MOV      (SP)+,R1      ;RESTORE R1
2007 014462    012600          MOV      (SP)+,R0      ;RESTORE R0
2008 014464          RETURN              ;RETURN

```

```

2010                                     .SBTTL  RECEIVER ERRORS
2011
2012                                     ;CALLED BY THE MACRO 'CALL  ERRMOR,<P,ERADR>'
2013
2014 014466                               PROC  ERRMOR,<ERRNUM,ERRADR>
(3) 000002                               ERRNUM = 2
(3) 000004                               ERRADR = 4
(1)
(1) 014466                               ERRMOR:
2015 014466 010046                       MOV  R0,-(SP)                               ;**ENTRY POINT**
2016 014470 010146                       MOV  R1,-(SP)                               ;SAVE R0 ON THE STACK
2017 014472 010246                       MOV  R2,-(SP)                               ;AND R1
2018 014474 010346                       MOV  R3,-(SP)                               ;AND R2
2019 014476 017767 001414 003260         MOV  @RCR,TEMP                             ;AND R3
2020 014504 042767 160377 003252         BIC  #160377,TEMP                          ;GET ADDR OF CONNECTED XMTR
2021 014512 000367 003246                       SWAB  TEMP                                ; INTO RIGHT BYTE
2022 014516 016500 000002                       MOV  ERRNUM(R5),R0                          ;GET ERROR NUMBER
2023 014522 010067 003240                       MOV  R0,TEMP1                              ;AND SAVE IT
2024 014526 006300                               ASL  R0                                    ; FIND 'SUM' TABLE ENTRY
2025 014530 010001                               MOV  R0,R1                                  ; IN ORDER TO UPDATE
2026 014532 006300                               ASL  R0                                    ; ADDRESS FIELD
2027 014534 060100                               ADD  R1,R0                                  ; AND # OF OCCURRENCES
2028 014536 062700 024720                       ADD  #ERTBL0,R0
2029 014542 016560 000004 000002         MOV  ERRADR(R5),2(R0)                       ;ENTER ERROR ADDRESS
2030 014550 026027 000004 177771         CMP  4(R0),#177771                          ;AT MAX COUNT YET?
2031 014556 103401                               BLO  ERMINR                                ;NO, UPDATE ERROR COUNT
2032 014560 000447                               BR   ERMISR                                ;YES, SKIP UPDATES
2033 014562 005260 000004 000004         ERMINR: INC 4(R0)                          ;UPDATE OCCURRENCES
2034 014566 162767 000015 003172         SUB  #15,TEMP1                              ;ALIGN ERRORS TABLE FOR RCVR
2035 014574 005367 003166                       DEC  TEMP1                                  ; ERR # - 1 (E-1)
2036 014600                               MULT 37,TEMP1,R3                          ; (E-1)x37
2037 014644                               MULT 2,TEMP1,R3                          ; [(E-1)x37]x2
2038 014650 005367 003110                       DEC  TEMP                                  ; XMTR ADDR - 1 (T-1)
2039 014654                               MULT 2,TEMP,R3                          ; (T-1)x2
2040 014660 066767 003102 003076         ADD  TEMP1,TEMP                            ; [(E-1)x37]x2 + (T-1)x2
2041 014666 062767 026616 003070         ADD  #RERTBL,TEMP                          ; TEMP = #RERTBL+[(E-1)x37]x2 + (T-1)x2
2042 014674 005277 003064                               INC  @TEMP                                  ;UPDATE RCVR ERROR COUNT
2043 014700 012603                               ERMISR: MOV (SP)+,R3                       ;RESTORE R3
2044 014702 012602                               MOV  (SP)+,R2                             ;RESTORE R2
2045 014704 012601                               MOV  (SP)+,R1                             ;RESTORE R1
2046 014706 012600                               MOV  (SP)+,R0                             ;RESTORE R0
2047 014710                               RETURN

```

```
2049 .SBTTL UTILITY ROUTINES
2050 .SBTTL PROCESS AN INPUT CHARACTER FROM THE TTY
2051
2052 014712 PROC TTINP
(1)
(1) 014712 TTINP: ;**ENTRY POINT**
2053
2054 014712 CALL DEQ,<FRELEM,TIQ> ;GET TTY INPUT CHARACTER.
2055 014732 142767 000200 013324 BICB #200,FRELEM ;CLEAR OFF PARITY BIT.
2056 014740 116700 013320 MOVB FRELEM,R0
2057 014744 120027 000141 CMPB R0,#141 ;CONVERT LOWER CASE INPUT
2058 014750 002405 BLT TTINH ; TO REGULAR (UPPER CASE)
2059 014752 120027 000172 CMPB R0,#172 ; LETTERS INSTEAD.
2060 014756 003002 BGT TTINH
2061 014760 042700 000040 BIC #B05,R0 ;CONVERT CHARACTER
2062 014764 010067 013274 TTINH: MOV R0,FRELEM ; IN 'FRELEM'
2063 014770 012701 016034 MOV #CMCHTB,R1 ; TO ITS PROCESSING
2064 014774 004767 015654 JSR PC,PROCHR ; ROUTINE.
2065 015000 001407 BEQ CMMISC ;IF MISC CHAR, CALL MISC PROC.
2066 015002 CALL @R1,<FRELEM> ;CALL PROCESSING ROUTINE.
2067 015016 000407 BR TTRET ;RETURN.
2068
2069 015020 CMMISC: CALL PRMISC,<FRELEM> ;PROCESS MISCELLANEOUS CHARACTER
2070 015036 TTRET: RETURN ;RETURN.
```

```
2072 .SBTTL TTY INPUT CHARACTER PROCESSING ROUTINES
2073
2074
2075 :
2076 : PROCESSOR FOR CARRIAGE RETURN
2077 : THIS CHARACTER SIGNIFIES THE END OF A COMMAND LINE.
2078 :
2078 015040 PROC PRCR
(1)
(1) 015040 PRCR: ;**ENTRY POINT**
2079 015040 105767 002574 TSTB REQINP ;IF INPUT NOT BEING TYPED,
2080 015044 002015 BGE CRRET ; IGNORE CHARACTER.
2081 015046 112777 000015 001326 MOVB #CR.,@CBUFPT ;PUT CR IN BUFFER.
2082 015054 105367 002561 DECB CMDENT ;SET COMMAND ENTERED FLAG.
2083 015060 105067 002554 CLRB REQINP ;CLEAR INPUT REQUESTED FLAG.
2084 015064 CALL PNCRLF ;ECHO CR & LF.
2085 015100 CRRET: RETURN ;RETURN.
2086
2087 :
2088 : PROCESSOR FOR CONTROL-O CHARACTER.
2089 : ALL CHARACTERS PRESENTLY IN THE TTY OUTPUT QUEUE ARE THROWN AWAY.
2090 :
2091 015102 PROC PRCTLO
(1)
(1) 015102 PRCTLO: ;**ENTRY POINT**
2092 015102 005067 001516 CLR TOQ ;THROW AWAY ALL CHARACTERS
2093 015106 016767 001524 001520 MOV TOQ+QBACK,TOQ+QFRONT ; IN TTY OUTPUT QUEUE.
2094 015114 CALL PNTLIN,<CTLOMG> ;ECHO '^O'.
2095 015132 RETURN ;RETURN.
2096
2097 :
2098 :
2099 :
2100 : PROCESSOR FOR CONTROL S.
2101 : TEMPORARILY SUSPEND PRINTOUT ON CONSOLE DEVICE
2102 :
2103 : PRINTOUT WILL BE RESUMED UPON RECEIPT OF A CNTRL-Q
2104 : OR ANY OTHER KEYBOARD INTERRUPT.
2105 :
2106 015134 PROC PRCTLS
(1)
(1) 015134 PRCTLS: ;**ENTRY POINT**
2107 015134 052767 100000 002560 BIS #B15,THLTFI ;SET TTY HALT FLAG
2108 015142 RETURN
2109
2110 :
2111 :
2112 : PROCESSOR FOR CONTROL Q.
2113 : RESUME PRINTOUT ON CONSOLE IF TTOUT QUEUE HAS NOT BEEN
2114 : CLEARED BY SOME OTHER MEANS.
2115 :
2116 015144 PROC PRCTLQ
(1)
(1) 015144 PRCTLQ: ;**ENTRY POINT**
2117 015144 042767 100000 002550 BIC #B15,THLTFI ;CLEAR TTY HALT FLAG
2118 015152 RETURN
2119
```



```
2120
2121
2122      :
2123      :PROCESSOR FOR CONTROL-C.
2124      :ECHO '^C' AND GO TO PRESC ROUTINE.
2125      PROC   PRCTL
2126      (1) 015154
2127      (1) 015154      PRCTL:      : **ENTRY POINT**
2128      015154      CALL   PNTLIN,<CTLIMG>      :ECHO '^C'
2129      000167 000016      JMP    PRESC      :GO TO PRESC ROUTINE.
2130
2131      :
2132      :PROCESSOR FOR CONTROL-U.
2133      :INPUT COMMAND BEING TYPED IS DISCARDED.
2134      PROC   PRCTLU
2135      (1) 015176
2136      (1) 015176      PRCTLU:     : **ENTRY POINT**
2137      015176      CALL   PNTLIN,<CTLUMG>      :ECHO '^U'.
2138      :DROP INTO PRESC
2139
2140      :
2141      :PROCESSOR FOR CNTRL-C KEY.
2142      :THIS KEY IS USED TO REQUEST INPUT. ALL OTHER EVENTS WILL CEASE
2143      :AFTER THE CURRENT LINE. A 'PCL>' WILL BE ECHOED ON THE TTY. THE
2144      :OPERATOR IS NOW FREE TO TYPE IN A COMMAND.
2145      :
2146      :
2147      PROC   PRESC
2148      (1) 015214
2149      (1) 015214      PRESC:      : **ENTRY POINT**
2150      005767 002430      TST    KWFLG      :GOT A CLOCK?
2151      015220 001402      BEQ    14$      :NO.
2152      015222 005077      CLR    @LCS      :STOP THE CLOCK
2153      015226 105367 002406      14$:  DECB   REQINP      :SET INPUT REQUESTED FLAG.
2154      015232 005067 002430      CLR    STSEV      :CLR STATUS EVENT
2155      015236 005067 002420      CLR    SUMEV      :CLR SUMMARY EVENT
2156      015242 005067 002404      CLR    TEREV      :CLR XMTR ERROR EVENT
2157      015246 005067 002402      CLR    REREV      :AND RCVR ERROR EVENT
2158      015252 005067 002422      CLR    PCLGO      :STOP XMTR
2159      015256      CALL   ENQ,<A.P,TOQ>      :ECHO 'PCL>'.
2160      015276      CALL   ENQ,<A.C,TOQ>
2161      015316      CALL   ENQ,<A.L,TOQ>
2162      015336      CALL   ENQ,<A.PR,TOQ>
2163      015356 012767 016176 001016      MOV    #CMDBUF,CBUFPT      :INITIALIZE COMMAND BUF PTR.
2164      015364 105067 002251      CLRB   CMDENT      :CLEAR COMMAND ENTERED FLAG.
2165      015370      RETURN      :RETURN.
2166
2167      :
2168      :PROCESS RUB OUT KEY.
2169      :LAST CHARACTER IN COMMAND BUFFER IS DELETED. A '^' IS ECHOED.
2170      :
```

```

2170
2171 015372          PROC  PRDEL
(1)
(1) 015372          PRDEL:          : **ENTRY POINT**
2172 015372 105767 002242          TSTB  REQINP          : IF INPUT NOT REQUESTED,
2173 015376 002034          BGE    PDRET          : THEN IGNORE RUBOUT CHAR.
2174 015400 026727 000776 0'6176  CMP    CBUFPT,#CMDBUF : IF AT BEGINNING OF BUFFER,
2175 015406 003016          BGT    1$             : THEN ISSUE NEW 'PCL>'
2176 015410          CALL  PNCRLF
2177 015424          CALL  PRESC
2178 015440 000167 000024          JMP    PDRET
2179 015444 005367 000732          1$:    DEC    CBUFPT          : DECREMENT BUFFER POINTER.
2180 015450          CALL  ENQ,<A.BKSL,TOQ> : ECHO A '\'.
2181 015470          PDRET:  RETURN          : RETURN.
2182
2183
2184
2185 :
2186 : PROCESSOR FOR MISCELLANEOUS CHARACTERS.
2187 : THE CHARACTER IS APPENDED TO THE COMMAND BUFFER.
2188 :
2189
2190 015472          PROC  PRMISC,<CHAR>
(3) 000002          CHAR  -          2
(1)
(1) 015472          PRMISC:          : **ENTRY POINT**
2191 015472 105767 002142          TSTB  REQINP          : IF INPUT NOT REQUESTED,
2192 015476 002034          BGE    PMRET          : THEN JUST IGNORE CHARACTER.
2193 015500 117500 000002          MOVB  @CHAR(R5),R0
2194 015504 120027 000040          CMPB  R0,#'          : IF CHARACTER
2195 015510 002403          BLT  PM176          : IS NONPRINTING
2196 015512 120027 000140          CMPB  R0,#140        : THEN CHANGE
2197 015516 002402          BLT  PM187          : IT TO
2198 015520 012700 000077          PM176: MOV  #'?,R0          : ASCII '?'.
2199 015524 026727 000652 016401  PM187: CMP  CBUFPT,#CBFEND-1 : IF WE ARE AT END OF BUFFER,
2200 015532 001416          BEQ  PMRET          : THEN JUST RETURN.
2201 015534 110077 000642          MOVB  R0,@CBUFPT    : PUT CHARACTER INTO BUFFER
2202 015540 005267 000636          INC  CBUFPT          : UPDATE BUFFER POINTER.
2203 015544 110067 012516          MOVB  R0,BKELEM
2204 015550          CALL  ENQ,<BKELEM,TOQ> : ECHO CHARACTER.
2205 015570          PMRET:  RETURN          : RETURN.

```

2207
2208
2209
2210
2211
2212
2213
(1)
(1)
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234

015572
015572
015572 105777 000344
015576 002020
015600 005767 002116
015604 001402
015606 000167 000026
015612
015632 116777 012426 000304
015640

015642
015642 005067 002054
015646
015652 117767 000262 012414
015660
015700
015704 000002

```
.SBTTL TTY OUTPUT HANDLERS

:
: OUTPUT A CHARACTER TO THE TELETYPE IF IT IS READY.
:
: PROC TTOUT
TTOUT:
: TSTB @TTXCSR ;**ENTRY POINT**
: BGE TORET ;IF DEVICE IS NOT READY,
: TST THLTFI ; THEN JUST RETURN.
: BEQ 1$ ;IS TTY HALTED (CNTRL-S)?
: JMP TORET ;NO, O.K. TO PRINT
: ;YES, DON'T DO ANYTHING.
1$: CALL DEQ,<FRELEM,TOQ> ;GET NEXT CHAR TO TYPE.
: MOVB FRELEM,@TTXBUF ;OUTPUT IT.
: TORET: RETURN ;RETURN.

.SBTTL TTY INPUT INTERRUPT PROCESSORS

TTIINT:
: CLR THLTFI ;**INTERRUPT ENTRY POINT**
: REGSAV ;CLEAR TTY HALT FLAG ON INPUT
: MOVB @TTXBUF,INTTMP ;SAVE R0 - R5.
: CALL ENQ,<INTTMP,TIQ> ;GET INPUT CHARACTER.
: REGRES ;PUT IT IN TTY INPUT QUEUE.
: RTI ;RESTORE R0 - R5.
: ;RETURN.
```

```
2236 .SBTTL MESSAGE PRINT ROUTINE
2237
2238
2239 :
2240 : ENQUEUE CHARACTERS STARTING AT MESSAG IN TTY OUTPUT
2241 : QUEUE TOQ UNTIL A ZERO BYTE IS ENCOUNTERED. ENQUEUE A CR & LF
2242 : INSTEAD OF THE ZERO, & THEN EXIT FROM THE ROUTINE.
2243 :
2244 015706 PROC PNTLIN,<MESSAG>
(3) 000002 MESSAG - 2
(1)
2245 015706 PNTLIN: ;**ENTRY POINT**
015706 016546 000002 MOV MESSAG(R5),-(SP) ;GET ADDRESS OF MESSAGE.
2246 015712 117667 000000 012346 PLODEC: MOVB @ (SP),BKELEM ;GET A CHARACTER.
2247 015720 001412 BEQ PLCRLF ;IF NULL, APPEND CR & LF.
2248 015722 CALL ENQ,<BKELEM,TOQ> ;ENQUEUE CHAR FOR TTY OUTPUT.
2249 015742 005216 INC @SP ;POINT TO NEXT CHARACTER.
2250 015744 000762 BR PLODEC ;PROCESS IT.
2251
2252 015746 005026 PLCRLF: CLR (SP)+ ;POP ADDR FROM STACK.
2253 015750 000400 BR PL219 ;APPEND CR & LF.
2254
2255
2256 :
2257 : ENQUEUE A CR & LF IN TTY OUTPUT QUEUE.
2258 :
2259 015752 PROC PNCRLF
(1)
(1) 015752 PNCRLF: ;**ENTRY POINT**
2260 015752 PL219: CALL ENQ,<A.CR,TOQ> ;ENQUEUE A CR.
2261 015772 CALL ENQ,<A.LF,TOQ> ;ENQUEUE A LF.
2262 016012 CALL ENQ,<ZERO,TOQ> ;ENQUEUE A NULL FILL CHAR.
2263 016032 RETURN ;RETURN.
```

2265
2266
2267
2268
2269 016034
2270 016034 000003 015154
2271 016040 000012 015040
2272 016044 000015 015040
2273 016050 000017 015102
2274 016054 000021 015144
2275 016060 000023 015134
2276 016064 000025 015176
2277 016070 000177 015372
2278 016074 177777
2279
2280
2281
2282
2283 016076 164200
2284 016100 164202
2285 016102 164204
2286 016104 164206
2287 016106 164210
2288 016110 164212
2289 016112 164213
2290 016114 164214
2291 016116 164220
2292 016120 164222
2293 016122 164224
2294 016124 164226
2295 016126 164230
2296 016130 164234
2297
2298 016132 000170
2299 016134 000174
2300
2301 016136 177560
2302 016140 177562
2303 016142 177564
2304 016144 177566
2305 016146 000060
2306 016150 177546
2307
2308
2309
2310
2311 016152 000134
2312 016154 000000
2313 016156 000120
2314 016160 000103
2315 016162 000114
2316 016164 000076
2317
2318
2319
2320

.SBTTL DATA AREAS

; TABLE ASSOCIATING SPECIAL TTY INPUT CHARACTERS WITH THEIR
; PROCESSING ROUTINES.

CMCHTB:
.WORD CTL.C,PRCTL C
A.LF: .WORD LF.,PRCR
A.CR: .WORD CR.,PRCR
.WORD CTL.O,PRCTLO
.WORD CTL.Q,PRCTLQ
.WORD CTL.S,PRCTLS
.WORD CTL.U,PRCTLU
.WORD RUBOUT,PRDEL
.WORD -1

;DEVICE ADDRESS TABLES:

TCR: .WORD PCLTXM
TSR: .WORD PCLTXM+2
TSDB: .WORD PCLTXM+4
TSBC: .WORD PCLTXM+6
TSBA: .WORD PCLTXM+10
TMMR: .WORD PCLTXM+12
TMMRH: .WORD PCLTXM+13
TSCRC: .WORD PCLTXM+14
RCR: .WORD PCLRCV
RSR: .WORD PCLRCV+2
Rddb: .WORD PCLRCV+4
RDBC: .WORD PCLRCV+6
RDBA: .WORD PCLRCV+10
RDCRC: .WORD PCLRCV+14

TXMVEC: .WORD 170
RCVVEC: .WORD 174

TTRCSR: .WORD TTDEV
TTRBUF: .WORD TTDEV+2
TTXCSR: .WORD TTDEV+4
TTXBUF: .WORD TTDEV+6
TTVECT: .WORD TTVCTR
LCS: .WORD 177546

;VECTOR ADDRESS.
;KW11-I. LINE CLOCK ADDR

; CHARACTER CONSTANTS. THESE ARE DEFINED AS WORDS SO THAT THEY MAY
; BE ENQUEUED.

A.BKSL: .WORD '\ :ASCII '\'
ZERO: .WORD 0 :ASCII NULL
A.P: .WORD 'P :ASCII 'P'
A.C: .WORD 'C :ASCII 'C'
A.L: .WORD 'L :ASCII 'L'
A.PR: .WORD '> :ASCII '>' (PROMPT)

.EVEN

;DEVICE ADDRESS AND VECTOR VARIABLES

```
2321 ;CHANGE THESE LOCATIONS TO MODIFY ALL DEVICE ADDRESSES AND VECTORS
2322 ;FOR PCL11.
2323
2324 016166 164200 TXDEV: .WORD 164200 ;DEFAULT IS 164200
2325 016170 000170 TXVEC: .WORD 170 ;DEFAULT IS 170
2326 016172 164220 RCDEV: .WORD 164220 ;DEFAULT IS 164220
2327 016174 000174 RCVEC: .WORD 174 ;DEFAULT IS 174
2328
2329 ; BUFFER & MESSAGE AREAS.
2330 016176 000204 CMDBUF: .BLKB 132. ;TTY INPUT COMMAND BUFFER.
2331 016402 016402 CBFEND =
2332 016402 033333 CBUFPT: .WORD 33333 ;CMDBUF BUFFER POINTER.
2333
2334 016404 047536 000 CTLONG: .ASCIZ "'^O'" ;FOR ECHOING CONTROL CHARACTERS.
2335 016407 136 000125 CTLUMG: .ASCIZ "'^U'"
2336 016412 041536 000 CTLCMG: .ASCIZ "'^C'"
2337
2338 016415 040 051105 047522 RPMSG: .ASCIZ "' ERROR'"
2339 016422 000122
2340 ; QUEUE DEFINITIONS.
2341 .IRP LC <AO, TI, TO>
2342 .EVEN
2343 .LIST
2344 LC'Q: .WORD 0 ;QELEMS
2345 .WORD LC'SIZE ;QSIZE
2346 .WORD LC'AREA, LC'END ;QTOP & QBOT
2347 .WORD 33333, 33333 ;QFRONT & QBACK
2348 LC'AREA: .BLKW LC'SIZE ;LC'Q AREA
2349 LC'END -
2350 .NLIST
2351 .EODM
2352 AQC: .WORD 0 ;QELEMS
2353 .WORD AOSIZE ;QSIZE
2354 .WORD AOAREA, AOEND ;QTOP & QBOT
2355 .WORD 33333, 33333 ;QFRONT & QBACK
2356 AOAREA: .BLKW AOSIZE ;AOQ AREA
2357 AOEND =
2358 TIQ: .WORD 0 ;QELEMS
2359 .WORD TISIZE ;QSIZE
2360 .WORD TIAREA, TIEND ;QTOP & QBOT
2361 .WORD 33333, 33333 ;QFRONT & QBACK
2362 TIAREA: .BLKW TISIZE ;TIQ AREA
2363 TIEND -
2364 TOQ: .WORD 0 ;QELEMS
2365 .WORD TOSIZE ;QSIZE
2366 .WORD TOAREA, TOEND ;QTOP & QBOT
2367 .WORD 33333, 33333 ;QFRONT & QBACK
2368 TOAREA: .BLKW TOSIZE ;TOQ AREA
2369 TOEND =
2370
2371 ; FLAG VARIABLES.
2372 ; < 0 ==> TRUE
2373 ; >-0 ==> FALSE
2374
2375 REQINP: .BYTE 333 ;INPUT REQUEST IS BEING TYPED.
2376 017640 333
2377 017641 333 CMDENT: .BYTE 333 ;COMMAND HAS BEEN ENTERED.
```

2358	017642	000	TICKS:	.BYTE	0
2359	017643	000	SECNDS:	.BYTE	0
2360	017644	000	MINUTS:	.BYTE	0
2361		017646		.EVEN	
2362	017646	000000	HOURS:	.WORD	0
2363	017650	000000	KWFLG:	.WORD	0
2364	017652	000000	TEREV:	.WORD	0
2365	017654	000000	REREV:	.WORD	0
2366	017656	000000	OLDEV:	.WORD	0
2367	017660	000000	DATGEV:	.WORD	0
2368	017662	000000	SUMEV:	.WORD	0
2369	017664	000000	SUMSV:	.WORD	0
2370	017666	000000	STSEV:	.WORD	0
2371	017670	000000	STPNTR:	.WORD	0
2372	017672	000000	SUMPNT:	.WORD	0
2373	017674	000000	TXMEV:	.WORD	0
2374	017676	000000	TXMSV:	.WORD	0
2375	017700	000000	PCLGO:	.WORD	0
2376	017702	000000	RCVEV:	.WORD	0
2377	017704	000000	SPCEV:	.WORD	0
2378	017706	000000	XSPCEV:	.WORD	0
2379	017710	000000	FIRST:	.WORD	0
2380	017712	000000	NEXT:	.WORD	0
2381	017714	000000	PRINTD:	.WORD	0
2382	017716	000000	HDRFLG:	.WORD	0
2383	017720	000000	PADFLG:	.WORD	0
2384	017722	000000	THLTFL:	.WORD	0
2385					
2386				.EVEN	
2387					
2388				. DATA VARIABLES.	
2389	017724	133333	ORIGSD:	.WORD	133333
2390	017726	000000	DTSEED:	.WORD	0
2391	017730	000333	MLSD:	.WORD	333
2392	017732	000000	MSGLSD:	.WORD	0
2393	017734	000000	RCSEED:	.WORD	0
2394	017736	000000	RCTXPS:	.WORD	0
2395	017740	000000	RJCTF:	.WORD	0
2396	017742	000000	TRNKF:	.WORD	0
2397	017744	000000	TXML:	.WORD	0
2398	017746	037565	RANM:	.WORD	37565
2399	017750	012247	RANK:	.WORD	12247
2400	017752	000000	CURAD:	.WORD	0
2401	017754	000000	RSPC:	.WORD	0
2402	017756	000000	ESCFLG:	.WORD	0
2403	017760	000000	OBJCNT:	.WORD	0
2404	017762	000000	RSHOLD:	.WORD	0
2405	017764	000000	TEMP:	.WORD	0
2406	017766	000000	TEMP1:	.WORD	0
2407	017770	000000	ERRO:	.WORD	0
2408	017772	000000	ERR1:	.WORD	0
2409	017774	000000	ERR2:	.WORD	0
2410					
2411					
2412				.ADDRESS SILO DATA BUFFER AREA	
2413					

```
2414 017776 000102 ADSILO: .BLKB 66. ;66. BYTE AREA FOR SILO DATA
2415
2416 ;RECEIVER ADDRESS TABLE
2417
2418 000001 X = 1
2419 020100 RADB: .REPT 31. ;ACTIVITY FLAG
2420 000037 .WORD 0 ;RECEIVER ADDRESS
2421 .WORD X ;ATTEMPTS ENTRY
2422 .WORD 0,0 ;SUCCESSSES ENTRY
2423 .WORD 0,0
2424
2425 X - X+1
2426 .ENDR
2427
2428 020664 020664 RADEND: .WORD .
2429 020064 RADBO= RADB-14
2430
2431 ;TRANSMITTER DATA BUFFER:
2432
2433 020666 001020 DATBUF: .BLKW 1020
2434
2435 ;RECEIVER DATA BUFFER:
2436
2437
2438 022726 001000 RCBUF: .BLKW 1000
2439
2440 ;EXERCISER ERROR TABLE
2441
2442 000001 Y = 1 ;INITIAL ERROR NUMBER
2443 024726 ERTBL: .REPT N-1
2444 000030 .WORD Y ;ERROR NUMBER
2445 .WORD 0 ;ERROR ADDRESS
2446 .WORD 0 ;NO. OF OCCURRENCES SINCE INIT
2447
2448 Y - Y+1
2449 .ENDR
2450 .WORD -1 ;LAST ERROR # IS -1
2451 025146 177777
2452 024720 ERTBLO = ERTBL-6
2453
2454 ; DETAILED ERROR TABLES FOR RCVR AND XMTR ERRORS:
2455
2456
2457
2458 025150 000623 TERTBL: .BLKW 37*15 ;RESERVE SPACE FOR XMTR ERRORS
2459
2460
2461 026616 000623 RERTBL: .BLKW 37*15 ;RESERVE SPACE FOR RCVR ERRORS
2462
2463
2464
2465
2466 030264 033333 FRFLEM: .WORD 33333 ;STORAGE FOR DEQUEUED ELEMENT.
2467 030266 033333 BKELEM: .WORD 33333 ;STORAGE FOR ENQUEUED ELEMENT.
2468 030270 033333 TCBFPT: .WORD 33333 ;CMDBUF POINTER USED DURING SCAN
2469 030272 033333 TCBIN: .WORD 33333 ;BINARY VALUE OF INPUT PARAMETER
```



```

2470 030274 033333 INTIMP: .WORD 33333 ;TEMP STORAGE FOR INTERRUPT PROC
2471
2472 .SBTTL KEYWORD TABLE
2473
2474 ;KEYWORD TABLE ASSOCIATING A COMMAND WITH ITS PROCESSING ROUTINE
2475
2476 030276 004536 CMDTBL: .WORD CPADD
2477 030300 002 003 .BYTE 2,3
2478 030302 042101 020104 .ASCII /ADD /
2479 030306 005704 .WORD CPASS
2480 030310 002 006 .BYTE 2,6
2481 030312 051501 044523 047107 .ASCII /ASSIGN/
2482 030320 004764 .WORD CPCLR
2483 030322 002 005 .BYTE 2,5
2484 030324 046103 040505 020122 .ASCII /CLEAR /
2485 030332 005126 .WORD CPENT
2486 030334 002 010 .BYTE 2,8
2487 030336 047503 052116 047111 .ASCII /CONTINUE /
      030344 042525
2488 030346 004644 .WORD CPDEL
2489 030350 001 006 .BYTE 1,6
2490 030352 042504 042514 042524 .ASCII /DELETE /
2491 030360 006612 .WORD CPERR
2492 030362 001 006 .BYTE 1,6
2493 030364 051105 047522 051522 .ASCII /ERRORS /
2494 030372 005522 .WORD CPGO
2495 030374 001 002 .BYTE 1,2
2496 030376 047507 .ASCII /GO /
2497 030400 005222 .WORD CPINIT
2498 030402 001 012 .BYTE 1,10
2499 030404 047111 052111 040511 .ASCII /INITIALIZE /
      030412 044514 042532
2500 030416 004130 .WORD CPMAS
2501 030420 001 006 .BYTE 1,6
2502 030422 040515 052123 051105 .ASCII /MASTER /
2503 030430 004400 .WORD CPRANG
2504 030432 002 005 .BYTE 2,5
2505 030434 040522 043516 020105 .ASCII /RANGE /
2506 030442 004306 .WORD CPRIB
2507 030444 002 003 .BYTE 2,3
2508 030446 044522 020102 .ASCII /RIB /
2509 030452 004214 .WORD CPSEC
2510 030454 002 011 .BYTE 2,9
2511 030456 042523 047503 042116 .ASCII /SECONDARY /
      030464 051101 020131
2512 030470 003420 .WORD CPSILO
2513 030472 002 004 .BYTE 2,4
2514 030474 044523 047514 .ASCII /SILO /
2515 030500 005066 .WORD CPSTAT
2516 030502 002 006 .BYTE 2,6
2517 030504 052123 052101 051525 .ASCII /STATUS /
2518 030512 005470 .WORD CPSUM
2519 030514 002 007 .BYTE 2,7
2520 030516 052523 046515 051101 .ASCII /SUMMARY /
      030524 020131
2521 030526 000000 000000 .WORD 0,0
  
```

```

2522
2523
2524 030532 000000          SCTBL: .WORD 0
2525 030534      001      005      .BYTE 1,5
2526 030536 046103 040505 020122 .ASCII /CLEAR /
2527 030544 000001          .WORD 1
2528 030546      001      003      .BYTE 1,3
2529 030550 042523 020124 .ASCII /SET /
2530 030554 000000 000000 .WORD 0,0
2531
2532
2533          .SBTTL SOME MORE ASCII STORAGE:
2534
2535 030560 020040 020040 020052 MDNER: .ASCIZ / ***** MASTER DOWN *****/
      030566 020052 020052 020052
      030574 020052 020052 046440
      030602 051501 042524 020122
      030610 047504 047127 020040
      030616 020052 020052 020052
      030624 020052 020052 000052
2536 030632 020040 025052 052040 MSCHNG .ASCIZ / ** THIS UNIT HAS BECOME 'NEW MASTER' **/
      C30640 044510 020123 047125
      030646 052111 044040 051501
      030654 041040 041505 046517
      030662 020105 047042 053505
      030670 046440 051501 042524
      030676 021122 025040 000052
2537 030704 020040 025052 051452 SYNTAX: .ASCIZ / ***SYNTAX ERROR***/
      030712 047131 040524 020130
      030720 051105 047522 025122
      030726 025052      000
2538 030731      120 046103 030461 PCLEXM .ASCIZ /PCL11 EXERCISER V02 CZPLAB0 (SEP-78)/
      030736 042440 042530 041522
      030744 051511 051105 053040
      030752 031060 020040 055103
      030760 046120 041101 020060
      030766 024040 042523 026520
      030774 034067 000051
2539 031000 042522 052123 051101 RSTMSG: .ASCII /RESTART AT ADDRESS /
      031006 020124 052101 040440
      031014 042104 042522 051523
      031022      040
2540 031023      132 055132 055132 RSADD: .ASCIZ /ZZZZZZ/
      031030 000132
2541 031032 025052 051440 051117 MTQMSG: .ASCIZ /** SORRY, I HAVE NO RECEIVER ADDRESSES. **/
      031040 054522 020054 020111
      031046 040510 042526 047040
      031054 020117 042522 042503
      031062 053111 051105 040440
      031070 042104 042522 051523
      031076 051505 020041 025052
      031104      000
2542 031105      124 040522 050120 TRPDMG: .ASCII /TRAPPED TO 4 FROM LOCATION /
      031112 042105 052040 020117
      031120 020064 051106 046517
      031126 046040 041517 052101
  
```

2543	031134	047511	020116	020116	TRP4AD: .ASCIIZ /NNNNN ./
	031140	047116	047116		
	031146	020440	000		
2544	031151	104	053105	041511	ERTMSG: .ASCIIZ /DEVICE ADDRESS ERROR. USE 'ASSIGN' COMMAND./
	031156	020105	042101	051104	
	031164	051505	020123	051105	
	031172	047522	027122	052440	
	031200	042523	021040	051501	
	031206	044523	047107	020042	
	031214	047503	046515	047101	
	031222	027104	000		
2545	031225	105	042530	041522	EXRST: .ASCIIZ /EXERCISER STARTED/
	031232	051511	051105	051440	
	031240	040524	052122	042105	
	031246	000			
2546	031247	105	042530	041522	EXCNT: .ASCIIZ /EXERCISER CONTINUING/
	031254	051511	051105	041440	
	031262	047117	044524	052516	
	031270	047111	000107		
2547	031274	025052	052052	044510	MSTMG1: .ASCIIZ /***THIS UNIT IS NOT MASTER***/
	031302	020123	047125	052111	
	031310	044440	020123	047516	
	031316	020124	040515	052123	
	031324	051105	025052	000052	
2548	031332	052502	020124	040510	MSTMG2: .ASCIIZ /BUT HAS NOW BEEN MADE SECONDARY./
	031340	020123	047516	020127	
	031346	042502	047105	046440	
	031354	042101	020105	042523	
	031362	047503	042116	051101	
	031370	027131	000		
2549	031373	124	042510	051440	MSTMG3: .ASCIIZ /THE SILO YOU HAVE JUST LOADED WILL BE/
	031400	046111	020117	047531	
	031406	020125	040510	042526	
	031414	045040	051525	020124	
	031422	047514	042101	042105	
	031430	053440	046111	020114	
	031436	042502	000		
2550	031441	125	042523	020104	MSTMG4: .ASCIIZ /USED IF YOU CLEAR THE CURRENT MASTER./
	031446	043111	054440	052517	
	031454	041440	042514	051101	
	031462	052040	042510	041440	
	031470	051125	042522	052116	
	031476	046440	051501	042524	
	031504	027122	000		
2551	031507	124	042510	051440	MSTMG5: .ASCIIZ /THE SILO HAS BEEN PADDED WITH ADDRESS '0'/'
	031514	046111	020117	040510	
	031522	020123	042502	047105	
	031530	050040	042101	042504	
	031536	020104	044527	044124	
	031544	040440	042104	042522	
	031552	051523	021040	021060	
	031560	000			
2552	031561	124	044510	020123	THUMST: .ASCIIZ /THIS UNIT IS -MASTER-/'
	031566	047125	052111	044440	
	031574	020123	046455	051501	
	031602	042524	026522	000	

2553	031607	124	044510	020123	THUSCN: .ASCII /THIS UNIT IS -SECONDARY-/ 031614 047125 052111 044440 031622 020123 051455 041505 031630 047117 040504 054522 031636 000055
2554	031640	051042	041111	020042	RBSTMG: .ASCII /'RIB' IS -SET-/ 031646 051511 026440 042523 031654 026524 000
2555	031657	042	044522	021102	RBCLMG: .ASCII /'RIB' IS -CLEAR-/ 031664 044440 020123 041455 031672 042514 051101 000055
2556	031700	046105	050101	042523	ELPSTM: .ASCII /ELAPSED TIME (HRS:MIN:SEC:TIK).../ 031706 020104 044524 042515 031714 024040 051110 035123 031722 044515 035116 042523 031730 035103 044524 024513 031736 027056 056
2557	031741	060	030072	030072	TMLIN1: .ASCII /0:0:0:0 / 031746 030072 020040 020040 031754 020040 020040 000040
2558	031762	041522	051126	040440	STITLE: .ASCII /RCVR ADDRESS CONNECTION ATTEMPTS SUCCESSFUL CONNECTIONS/ 031770 042104 042522 051523 031776 020040 047503 047116 032004 041505 044524 047117 032012 040440 052124 046505 032020 052120 020123 051440 032026 041525 042503 051523 032034 052506 020114 047503 032042 047116 041505 044524 032050 047117 000123
2559	032054				STLIN:
2560	032054	047116	047116	020040	STLIN1: .ASCII /NNNN /
2561	032062	020040	020040	020040	
2562	032070	020040	020040	020040	
2562	032076	047116	047116	020040	STLIN2: .ASCII /NNNN /
2563	032104	020040	020040	020040	
2563	032112	020040	020040	020040	
2563	032120	020040	020040	020040	
2563	032124	047116	047116	020040	STLIN3: .ASCII /NNNN /
2564	032132	020040	020040	020040	
2565	032140	000040			
2566	032142	051105	047522	020122	SMTTLE: .ASCII /ERROR NUMBER ERROR ADDRESS NO. OF OCCURRENCES/ 032150 052516 041115 051105 032156 020040 020040 051105 032164 047522 020122 042101 032172 051104 051505 020123 032200 020040 047040 027117 032206 047440 020106 041517 032214 052503 051122 047105 032222 042503 000123
2567	032226	020040	025052	047040	NOERMG: .ASCII / ** NO ERRORS TO REPORT YET **/ 032234 020117 051105 047522
2568	032234	020117	051105	047522	

CZPLABO PCL11 EXERCISER V02
PCLEXR.P11 12-SEP-78 15:13

MACY11 30A(1052) 20-OCT-78 09:48 F 9 PAGE 38--9
SOME MORE ASCII STORAGE:

SEQ 0109

2587

2589 032654
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
2600
2601
2602
2603
2604
2605
2606
2607
2608
2609
2610
2611
2612
2613
2614 032654
2615 032654 121100
2616
2617 032656 001404
2618
2619 032660 101006
2620
2621 032662 062701 000004
2622
2623 032666 000772
2624
2625 032670 016101 000002
2626
2627 032674 000207
2628
2629
2630 032676 005001
2631 032700 000207
2632

.EVEN
.SBTTL AUXILIARY ROUTINES
.SBTTL CHARACTER PROCESSOR

: CONVERT A CHARACTER TO ITS PROCESSING ROUTINE ADDRESS BASED
: UPON A TABLE OF ENTRIES IN THE FOLLOWING FORM:

(UNUSED)	CHARACTER
PROCESSING ROUTINE ADDR	

: THE TABLE MUST BE ARRANGED IN ASCENDING ORDER OF CHARACTER VALUES.

: THE TABLE ENDS WITH A DUMMY ENTRY FOR CHARACTER FF (HEXADECIMAL).

: ON ENTRY: R0 = CHARACTER
: R1 = TABLE ADDRESS

: CALL: JSR PC,PROCHR

: ON RETURN: R0 = CHARACTER
: R1 = PROCESSING ROUTINE ADDRESS, IF ANY
: Z = 1 ==> CHARACTER NOT IN TABLE

```

PROCHR:
PCLOOK: CMPB @R1,R0      ;**ENTRY POINT**
                        ;COMPARE TABLE CHAR
                        ;WITH ARG. CHAR.
                        ;IF SAME, RETURN PROC.
                        ;ROUTINE ADDR.
                        ;IF >, THEN ARG. CHAR
                        ;NOT IN TABLE.
                        ;IF <, POINT TO NEXT
                        ;TABLE ENTRY.
                        ;TRY AGAIN.

                        ;R1 = PROCESSING
                        ;ROUTINE ADDRESS.
                        ;RETURN: Z BIT IS
                        ;OFF.

PCCALL: MOV 2(R1),R1

RTS PC

PCQUIT: CLR R1          ;R1 = 0
RTS PC                 ;RETURN: Z BIT IS ON.

```

2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666
2667
2668
2669
2670
2671
2672
2673
2674
2675

.SBTTL BINARY TO ASCII CONVERSION

: BINARY TO ASCII CONVERSION

: LOCAL MACROS

: SETUP CONVERSION CONTROL WORD ON STACK

: STCVT RADIX,WIDTH,SIGNED,COMPR,BLANKS

: WHERE:

: RADIX=NUMERIC VALUE SPECIFYING CONVERSION RADIX
: WIDTH=NUMERIC VALUE FROM 1 TO 7 SPECIFYING FIELD WIDTH
: SIGNED=SIGN OR MAGNITUDE FLAG. ASCII STRING 'SIGN' SPECI-
: FIES SIGNED CONVERSION. ANYTHING ELSE SPECIFIES MAGNI-
: TUDE.

: COMPR=COMPRESS LEADING ZEROS FLAG. ASCII STRING 'COMPRES' SPE-
: CIFIES COMPRESSION OF LEADING ZEROS. ANYTHING ELSE MEANS
: INCLUDE LEADING ZEROS OR SPACES IN CONVERSION.

: BLANK REPLACE LEADING ZEROS WITH BLANKS (SPACES). ASCII STRING
: 'BLANKS' MEANS BLANK REPLACEMENT IF ZERO COMPRESS IS DIS-
: ABLED. ANYTHING ELSE SPECIFIES ZERO PADDING.

.MACRO STCVT RADIX,WIDTH,SIGN,COMPR,BLANK

\$BLK 0

\$SGN 0

\$SUP 1*1000

.IF

IDN <BLANK>,<BLANKS>

\$BLK 1*2000

.ENDC

.IF

IDN <SIGN>,<SIGNED>

\$SGN 1*400

.ENDC

.IF

IDN <COMPR>,<COMPRES>

\$SUP 0*1000

.ENDC

MOV

#<WIDTH*4000>.\$BLK \$SGN \$SUP!RADIX,-(SP)

.ENDM

2677
2678
2679
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2690
2691
2692
2693
2694
2695
2696
2697
2698
2699
2700
2701
2702
2703
2704
2705
2706
2707
2708 032702
2709 032702
2710 032706 000411
2711
2712
2713
2714 032710
2715 032710
2716 032714 000406
2717
2718
2719
2720 032716
2721 032716
2722 032722 000403
2723
2724
2725
2726 032724
2727 032724
2728 032730 000400
2729
2730 032732
2731 032732 005702
2732 032734 001002

: INPUTS:

R0 ADDRESS TO STORE FIRST BYTE IN OUTPUT STRING
R1 NUMBER TO BE CONVERTED
R2=ZERO COMPRESSION INDICATOR
IF R2 EQ 0, THEN SUPPRESS ZEROS
IF R2 NE 0, THEN DO NOT SUPPRESS ZEROS.

IF CBTA IS CALLED, THEN R2 MUST CONTAIN THE FOLLOWING INFORMATION

LOW BYTE=CONVERSION RADIX (2-10.)
BIT 8=MAGNITUDE/SIGNED CONVERSION (1 SIGNED)
BIT 9 =ZERO COMPRESS FLAG (0-COMPRESS LEADING ZEROS)
BIT 10=BLANK FILL FLAG (1=REPLACE LEADING ZEROS WITH BLANKS
IF ZERO COMPRESS DISABLED, 0-ZERO FILL).
BITS 11-15=FIELD WIDTH (1-32)

: OUTPUTS:

R0-ADDRESS OF NEXT BYTE AFTER LAST DIGIT STORED.
IF THE CONVERTED DIGIT EXCEEDS 9, THE RESULT IS BIASED TO FALL
IN THE RANGE A - Z

: CONVERT 6 DIGIT OCTAL TO ASCII MAGNITUDE

OCTJSP:

STCVT 8.,6.,MAGN,NOCOMP,BLANKS ;PUSH CONVERSION PARAMETERS
BR SETCN ;CONVERT TO ASCII

: CONVERT 6 DIGIT OCTAL TO ASCII (ZERO COMPR)

OCTPNT:

STCVT 8.,6.,MAGN,COMPRES,NOBLKANK
BR SETCN

: CONVERT 5 DIGIT DECIMAL TO ASCII MAGNITUDE

DECJSP:

STCVT 10.,5.,MAGN,NOCOMP,BLANKS
BR SETCN

: CONVERT 5 DIGIT DECIMAL TO ASCII (ZERO COMPR)

DECPNT:

STCVT 10.,5.,MAGN,COMPRES,NOBLANK
BR SETCN

SETCN:

TST R2 ;SUPPRESS ZEROS?
BNE 20\$;IF NE, NO

CZPLABO PCL11 EXERCISER V02
PCLEXR.P11 12-SEP-78 15:13

J 9
MACY11 30A(1052) 20-OCT-78 09:48 PAGE 41-1
BINARY TO ASCII CONVERSION

SEQ 0113

2733 032736 042716 001000
2734 032742
2735 032742 012602

20\$:

BIC #1*1000,(SP)
MOV (SP+,R2)

;ENABLE ZERO SUPPRESS
;SET CONTROL WORD

CZ
PC

```

2737          .SBTTL  GENERAL BINARY TO ASCII CONVERSION
2738
2739 032744          CBTA:
2740 032744 004567 000406      JSR      R5,SAVRG      ;SAVE THE NON-VOLATILE REGISTERS
2741 032750 110205          MOV      R2,R5      ;COPY RADIX BYTE
2742 032752 000302          SWAB     R2      ;POSITION REMAINING TO LOW BYTE
2743 032754 106202          ASRB     R2      ;SHIFT OFF MAG. FLAG
2744 032756 103005          BCC      10$      ;UNSIGNED IF C IS CLR
2745 032760 005701          TST      R1      ;POSITIVE VALUE?
2746 032762 100003          BPL      10$      ;IF PL, YES
2747 032764 005401          NEG      R1      ;MAKE VALUE POSITIVE
2748 032766 112720 000055      MOV      #'-(R0)+    ;INSERT A MINUS SIGN
2749 032772
2750 032772 010004          10$:      MOV      R0,R4      ;COPY STRING POINTER
2751 032774 000241          CLC          ;CLEAR CARRY
2752 032776 106002          RORB     R2      ;SHIFT OFF SUPPR FLAG
2753 033000 006002          ROR      R2      ;TRANSFER TO R2
2754 033002 006003          ROR      R3      ;GET BLANK/ZERO PAD FLAG
2755 033004 105003          CLRB    R3      ;CLEAR COUNT BYTE
2756 033006 150203          BISB    R2,R3    ;TRANSFER COUNT BYTE
2757 033010 105002          CLRB    R2      ;CLEAR FILL BYTE
2758 033012 152702 000060      BISB    #'0,R2    ;SET FILL BYTE
2759 033016 010100          MOV      R1,R0    ;DIVIDEND TO R0
2760 033020
2761 033020 010501          1$:      MOV      R5,R1      ;SET CONVERSION RADIX
2762 033022 004767 000272      JSR      PC,DIV    ;DIVIDE EM UP
2763 033026 020127 000011      CMP      R1,#9     ;RESULT EXCEED NUMERICS?
2764 033032 101402          BLOS    15$      ;IF LOS, NO
2765 033034 062701 000007      ADD      #7,R1     ;BIAS TO FALL IN ALPHA
2766 033040
2767 033040 060201          15$:     ADD      R2,R1     ;ADD CHARACTER BIAS
2768 033042 010146          MOV      R1,-(SP) ;SAVE CHARACTER
2769 033044 105303          DECB    R3      ;DECREMENT CHARACTER COUNT
2770 033046 003412          BLE     3$      ;IF LE NO DIGITS LEFT
2771 033050 005700          TST     R0      ;ZERO QUOTIENT
2772 033052 001006          BNE     2$      ;IF NE, YES, GO AGAIN
2773 033054 005702          TST     R2      ;SUPPRESS ZEROS
2774 033056 100006          BPL     3$      ;IF PL, YES, ALL DONE
2775 033060 005703          TST     R3      ;SUBSTITUTE BLANKS?
2776 033062 100002          BPL     2$      ;IF PL, NO
2777 033064 042702 000020      BIC     #20,R2   ;CONVERT FILL TO BLANK
2778 033070
2779 033070 004767 177724          2$:      JSR      PC,1$     ;DIVIDE AGAIN
2780 033074          3$:
2781 033074 112624          MOV      (SP)+,(R4)+ ;STORE A DIGIT
2782 033076 010400          MOV      R4,R0    ;STORE TERMINAL ADDRESS
2783 033100          RETURN
2784

```

```

2786 .SBTTL DOUBLE PRECISION BINARY TO ASCII
2787 : CONVERT A DOUBLE PRECISION UNSIGNED QUANTITY TO DECIMAL ASCII
2788 :
2789 : LOCAL MACROS
2790 :
2791 : SET ASCII CONVERSION PARAMETERS
2792 :
2793 : CBTAS RADIX,WIDTH,SIGN,BLANK
2794 :
2795 : WHERE:
2796 :
2797 :     RADIX CONVERSION RADIX
2798 :
2799 :     WIDTH=FIELD WIDTH
2800 :
2801 :     SIGN-'SIGNED' FOR SIGNED CONVERSION. ANYTHING ELSE IMPLIES
2802 :         UNSIGNED CONVERSION
2803 :
2804 :     BLANK-'BLANKS' TO CONVERT LEADING ZEROS TO BLANKS. ANYTHING ELSE
2805 :         IMPLIES NO CONVERSION OF ZEROS .
2806 :
2807 : .MACRO CBTAS RADIX,WIDTH,SIGN,BLANK
2808 $BLKS=0
2809 $SGNS=0
2810 .IF IDN <BLANK>,<BLANKS>
2811 $BLKS=1*2000
2812 .ENDC
2813 .IF IDN <SIGN>,<SIGNED>
2814 $SGNS=1*400
2815 .ENDC
2816 MOV #<WIDTH*400>,$SGNS,$BLKS,RADIX,R5
2817 TST R2
2818 BEQ .+4
2819 BIS #1*1000,R5
2820 .ENDM
2821
2822 : INPUTS:
2823 :
2824 :     R0=POINTER TO ASCII OUTPUT STRING
2825 :     R1=ADDRESS OF DOUBLE PRECISION VALUE
2826 :     R2=ZERO COMPRESS FLAG
2827 :
2828 :
2829 CDDMG:
2830 033102 JSR R5,SAVRG ;SAVE THE NON-VOLATILE REGISTERS
2831 033106 MOV R0,R3 ;COPY THE STRING POINTER
2832 033110 MOV #10000.,R4 ;SET DIVISOR
2833 033114 CBTAS 10.,0,NOSIGN,BLANKS ;SET CONVERSION PARAMETERS
2834 033130 CMP (R1)+,R4 ;TEST FOR OVERFLOW
2835 033132 BHIS 40$ ;IF HIS, OVERFLOW
2836 033134 MOV (R1),R2 ;GET LOW PART OF NUMBER
2837 033136 MOV -(R1),R1 ;GET HIGH PART OF NUMBER
2838 033140 MOV R4,R0 ;COPY DIVISOR
2839 033142 JSR PC,DDIV ;DO DOUBLE PREC. DIVIDE
2840 033146 MOV R0,-(SP) ;SAVE REMAINDER
2841 033150 MOV R2,R1 ;COPY QUOTIENT

```

```
2842 033152 001011          BNE      11$          ;IF NE, SOMETHING TO PRINT
2843 033154 012702 000005    MOV      #5,R2        ;OTHERWISE, FILL FIELD WITH BLANKS
2844 033160 112723 000040    21$:    MOVB     #' ,(R3)+
2845 033164 005302          DEC      R2
2846 033166 001374          BNE     21$
2847 033170 052705 003000    BIS     #3000,R5      ;DISABLE BLANK SUPPRESSION
2848 033174 000411          BR      20$
2849 033176 012702 024000    11$:    MOV     #5*4000,R2  ;SET FIELD WIDTH
2850 033202 004767 000020    JSR     PC,30$        ;OUTPUT HIGH ORDER DIGITS
2851 033206 052705 001000    BIS     #1*1000,R5    ;DISABLE ZERO COMPRESS
2852 033212 042705 002000    BIC     #1*2000,R5    ;DISABLE BLANKS
2853 033216 010003          31$:    MOV     R0,R3        ;SET STRING POINTER
2854 033220          20$:
2855 033220 012601          MOV     (SP)+,R1      ;GET LOW ORDER VALUE
2856 033222 012702 020000    MOV     #4*4000,R2    ;SET FIELD WIDTH
2857 033226          30$:
2858 033226 010300          MOV     R3,R0        ;GET STRING POINTER
2859 033230 050502          BIS     R5,R2        ;INCLUDE RADIX & BLANK SUPPRESS
2860 033232 004767 177506    JSR     PC,CBTA      ;CONVERT TO ASCII
2861 033236 000406          BR      60$        ;EXIT
2862 033240          40$:
2863 033240 012702 000011    MOV     #9.,R2       ;GET COUNT
2864 033244          50$:
2865 033244 112720 000052    MOVB     #'*,(R0)+   ;FILL FIELD WITH ASTERISKS
2866 033250 005302          DEC     R2
2867 033252 001374          BNE     50$         ; 'SOB R2,50$'
2868 033254          60$:
2869 033254          RETURN
```

.SBTTL DOUBLE PRECISION DIVIDE ROUTINE

: INPUTS:

: R2=LOW ORDER OF DIVIDEND
: R1=HIGH ORDER OF DIVIDEND
: R0=DIVISOR (15 BITS UNSIGNED)

: OUTPUTS:

: R2=LOW ORDER OF QUOTIENT
: R1=HIGH ORDER OF QUOTIENT
: R0=REMAINDER

DDIV:

```
2888 033256          MOV     R3,-(SP)      ;SAVF R3
2889 033256 010346          MOV     #32.,R3      ;SET ITERATION COUNT IN R3
2890 033260 012703 000040    MOV     R0,-(SP)     ;STACK DIVISOR
2891 033264 010046          CLR     R0           ;SET REMAINDER TO 0
2892 033266 005000          1$:
2893 033270          ASL     R2           ;SHIFT THE ENTIRE DIVIDEND
2894 033270 006302          ROL     R1           ;... ONE BIT TO THE LEFT AND...
2895 033272 006101          ROL     R0           ;... INTO THE REMAINDER
2896 033274 006100          ROL     R0
2897 033276 020016          CMP     R0,(SP)     ;IS REMAINDER GE DIVISOR?
```

```
2898 033300 103402          BLO      2$          :NO, SKIP TO ITERATION CONTROL
2899 033302 161600          SUB      (SP),R0     :YES, SUB DIVISOR OUT
2900 033304 005202          INC      R2          :AND INCR THE QUOTIENT
2901 033306                2$:
2902 033306 005303          DEC      R3          :REPEAT AS LONG AS NECESSARY
2903 033310 003367          BGT      1$
2904 033312 005726          TST      (SP)+       :PURGE DIVISOR FROM STACK
2905 033314 012603          MOV      (SP)+,R3   :RESTORE R3
2906 033316          RETURN
2907
2908
2909                .SBTTL  INTEGER DIVIDE MAGNITUDE NUMBERS
2910
2911                :
2912                : INPUTS:
2913                :
2914                : R0=DIVIDEND
2915                : R1=DIVISOR
2916                :
2917                : OUTPUTS:
2918                :
2919                : QUOTIENT IS RETURNED IN R0
2920                : REMAINDER IS RETURNED IN R1
2921                :
2922                :
2923                : DIV:
2924 033320 012746 000020          MOV      #20,-(SP)   :SET LOOP COUNT
2925 033324 010146          MOV      R1,-(SP)   :SAVE DIVISOR FOR SUBTRACTS
2926 033326 005001          CLR      R1         :CLEAR REMAINDER
2927 033330                30$:
2928 033330 006300          ASL      R0          :DOUBLE LEFT SHIFT.
2929 033332 006101          ROL      R1
2930 033334 020116          CMP      R1,(SP)    :SUBTRACT OUT DIVISOR
2931 033336 103402          BLO      40$        :IF LO, NO
2932 033340 161601          SUB      (SP),R1    :SUBTRACT OUT DIVISOR
2933 033342 005200          INC      R0         :ADD IN LOW BIT
2934 033344                40$:
2935 033344 005366 000002          DEC      2(SP)      :DECREMENT REPEAT COUNT
2936 033350 003367          BGT      30$        :IF GT, MORE TO GO
2937 033352                50$:
2938 033352 022626          CMP      (SP)+,(SP)+ :CLEAN STACK
2939 033354          RETURN
2940
2941                : SAVE/RESTORE NONVOLATILE REGISTERS
2942
2943
2944                : SAVRG:
2945 033356 010446          MOV      R4,-(SP)   :SAVE R4 & R3
2946 033360 010346          MOV      R3,-(SP)
2947 033362 010546          MOV      R5,-(SP)
2948 033364 016605 000006          MOV      6(SP),R5   :PUT RETURN ADDRESS ON STACK
2949 033370 004736          JSR      PC,@(SP)+  :RETRIEVE REAL R5
2950 033372 012603          MOV      (SP)+,R3   :CALL THE CALLER
2951 033374 012604          MOV      (SP)+,R4   :RESTORE NON VOLATILE REGISTERS
2952 033400          MOV      (SP)+,R5
                RETURN
```

```

2954 .SBTTL QUEUE HANDLING ROUTINES
2955 : THIS MODULE CONTAINS 2 SUBROUTINES, ENQ & DEQ, TO ENQUEUE & DEQUEUE
2956 : WORDS, RESPECTIVELY, IN A FIRST-IN-FIRST-OUT LIST.
2957 :
2958 .LIST MEB
2959
2960
2961 033402 PROC ENQ,<ITEM,QUEUE>
(3) 000002 ITEM - 2
(3) 000004 QUEUE = 4
(1)
(1) 033402 ENQ: ;**ENTRY POINT**
:
: APPEND ITEM (A WORD) TO THE FIRST-IN-FIRST-OUT LIST QUEUE .
:
: MOV QUEUE(R5),R4 ;GET QUEUE ADDRESS.
: CMP @R4,QSIZE(R4) ;IF QUEUE IS FULL,
: BGE NQFULL ; SIGNAL TRAGIC ERROR.
: MOV @ITEM(R5),@QBACK(R4) ;PUT ITEM AT BACK OF QUEUE.
: ADD #2,QBACK(R4) ;UPDATE BACK POINTER.
: CMP QBACK(R4),QBOT(R4) ;
: BLO NQNOWP ;
: MOV QTOP(R4),QBACK(R4) ;
NQNOWP: INC @R4 ;INCREMENT NO. OF ELEMENTS.
CLC ;INDICATE SUCCESSFUL ENQ.
NQRET: RETURN ;RETURN.
RTS PC
:
NQFULL: SEC ;INDICATE UNSUCCESSFUL ENQ.
BR NQRET ;IGNORE ITEM & RETURN.
:
2981 033460 PROC DEQ,<ITEM,QUEUE>
(3) 000002 ITEM - 2
(3) 000004 QUEUE = 4
(1)
(1) 033460 DEQ: ;**ENTRY POINT**
:
: REMOVE A WORD ENTRY FROM THE FIRST-IN-FIRST-OUT LIST QUEUE &
: STORE IT AT ITEM .
:
: MOV QUEUE(R5),R4 ;GET QUEUE ADDRESS.
: TST @R4 ;IF QUEUE IS EMPTY,
: BEQ DQEMP ; SIGNAL TRAGIC ERROR.
: MOV @QFRONT(R4),@ITEM(R5) ;RETRIEVE FRONT ELEMENT.
: ADD #2,QFRONT(R4) ;UPDATE FRONT POINTER.
: CMP QFRONT(R4),QBOT(R4) ;
: BLO DQNOWP ;
: MOV QTOP(R4),QFRONT(R4) ;
DQNOWP: DEC @R4 ;DECREMENT NO. OF ELEMENTS.
CLC ;INDICATE SUCCESSFUL DEQ.
DQRET: RETURN ;RETURN.
RTS PC
:
DQEMP: SEC ;INDICATE UNSUCCESSFUL DEQ.
MOV #-1,@ITEM(R5) ;SET ITEM TO ALL ONES.

```

CZPLABO PCL11 EXERCISER V02
PCLEXR.P11 12-SEP-78 15:13

MACY11 30A(1052) 20-OCT-78 09:48 PAGE 44-1
C 10
QUEUE HANDLING ROUTINES

SEQ 0119

3000 033540 000772

BR DQRET

;RETURN.


```
3002      : SUBROUTINE TO SCAN AN INPUT COMMAND & CALL ITS  
3003      : PROCESSING ROUTINE.  
3004  
3005      .LIST  MEB  
3006  
3007  
3008      .MACRO  SPAN  REG,CHAR,?L  
3009  
3010      : THIS MACRO SCANS THE STRING OF CHARACTERS STARTING AT  
3011      : @REG UNTIL IT FINDS ONE NOT EQUAL TO CHAR.  REG IS  
3012      : SET POINTING TO THAT CHARACTER.  
3013  
3014      L:      CMPB  (REG)+,CHAR  
3015      BEQ    L  
3016      DEC    REG  
3017  
3018      .ENDM  
3019  
3020      .MACRO  BREAK  REG,CHRSET,?HH,?JJ  
3021  
3022      : THIS MACRO SCANS THE STRING STARTING AT @REG UNTIL  
3023      : IT FINDS A CHARACTER THAT IS A MEMBER OF CHRSET.  
3024      : REG IS SET POINTING TO THAT CHARACTER.  
3025  
3026      : EACH MEMBER OF CHRSET IS AN ADDRESSABLE QUANTITY.  
3027  
3028  
3029      HH:  
3030      .IRP   LS,<CHRSET>  
3031      CMPB  @REG,LS  
3032      BEQ   JJ  
3033      .ENDM  
3034      INC   REG  
3035      BR    HH  
3036  
3037      JJ:  
3038      .ENDM  
3039  
3040  
3041      .MACRO  SYNCLS  CHAR,CLASS,?CC,?DD,?EE,?FF,?GG  
3042  
3043      : THIS MACRO DETERMINES THE SYNTACTIC CLASS OF AN  
3044      : OBJECT BEGINNING WITH CHAR.  THE CLASS IS RETURNED  
3045      : IN CLASS AS FOLLOWS:  
3046      : CLASS = 0 (WORD) IF CHAR = (A,....,Z,-)  
3047      :          2 (NUMBER) IF CHAR = (0,....,9)  
3048      :          6 (END OF LINE) IF CHAR = CARRIAGE RETURN  
3049      :          4 (CHARACTER STRING) OTHERWISE  
3050  
3051      CMPB  CHAR,#'A  
3052      BLT  EE  
3053      CMPB  CHAR,#'Z  
3054      BGT  DD  
3055      CLR  CLASS  
3056      BR   GG  
3057
```



```

3077          .SBTTL  COMMAND PROCESSOR INITIATING ROUTINE
3078
3079 033542    PROC    (COMMAND,<INPLIN,KWTABL>
(3)          000002    INPLIN  =      2
(3)          000004    KWTABL  =      4
(1)
(1) 033542    COMMAND:          ;**ENTRY POINT**
3080          :
3081          : THIS ROUTINE CAUSES THE COMMAND SPECIFIED BY INPLIN TO BE
3082          : PROCESSED, AS DESCRIBED BELOW. INPLIN IS A STRING OF ASCII
3083          : CHARACTERS ENDED BY A CARRIAGE RETURN CODE.
3084          :
3085          : - INPLIN IS LEXICALLY SCANNED USING THE LXSCAN ROUTINE.
3086          : - THE 1ST OBJECT IS CONVERTED TO A PROCESSING ROUTINE ADDRESS
3087          :   USING THE KEYWD ROUTINE & THE KEYWORD TABLE KWTABL
3088          :   SUPPLIED BY THE CALLING PROGRAM.
3089          : - THE PROCESSING ROUTINE IS CALLED WITH THE OUTPUT FROM LXSCAN
3090          :   ON THE STACK STARTING AT 2(SP). (THE RETURN ADDRESS OF THIS
3091          :   CALL OCCUPIES THE TOP WORD OF THE STACK.)
3092          : - THE LXSCAN OUTPUT IS REMOVED FROM THE STACK.
3093          :
3094          : IF LXSCAN OR KEYWD OR THE PROCESSING ROUTINE RETURN AN ERROR
3095          : CONDITION, THEN C - 1; OTHERWISE, C - 0.
3096          :
3097 033542 010546      MOV      R5,-(SP)          ;SAVE PAR LIST POINTER.
3098 033544 010667 000076  MOV      SP,CMMARK          ;SAVE STACK POINTER.
3099 033550      LXSCAN  INPLIN(R5)          ;LEXICALLY SCAN INPLIN .
(1) 033550 016501 000002  MOV      INPLIN(R5),R1
(1) 033554 004167 000310  JSR      R1,LXSCAN
3100 033560 103426      BCS      CMRET          ;IF ERROR, RETURN WITH C 1.
3101 033562 005716      TST      @SP          ;HAVE WE ANY OBJECTS ?
3102 033564 003005      BGT      1$          ;NO, IGNORE BLANK COMMAND.
3103 033566 012767 177777 164162  MOV      #-1,ESCLFG
3104 033574 000167 000036  JMP      CMRET
3105 033600 016700 000042  1$:  MOV      CMMARK,R0          ;YES, DETERMINE ADDRESS
3106 033604 162700 000006  SUB      #6,R0          ; OF FIRST OBJECT.
3107 033610 017705 000032  MOV      @CMMARK,R5          ;RESTORE PAR LIST POINTER.
3108 033614      KEYWD   R0,KWTABL(R5)          ;GET ADDR OF COMMAND PROCESSOR.
(1) 033614 010046      MOV      R0,-(SP)
(1) 033616 016546 000004  MOV      KWTABL(R5),-(SP)
(1) 033622 004767 000024  JSR      PC,KEYWD
3109 033626 103403      BCS      CMRET          ;IF INVALID COMMAND, MAKE
3110          : ERROR RETURN.
3111 033630 012705 033650      MOV      #NULPAR,R5          ;LOAD NULL PAR LIST ADDRESS.
3112 033634 004736      JSR      PC,@(SP)+          ;PROCESS COMMAND & POP ADDR.
3113 033636 016706 000004  CMRET:  MOV      CMMARK,SP          ;RESTORE STACK TO ENTRY STATUS.
3114 033642 030026      BIT      R0,(SP)+          ;THROW AWAY SAVED R5 (WITHOUT
3115          : AFFECTING C BIT).
3116 033644      RETURN  ;RETURN TO CALLING PROGRAM.
(1) 033644 000207      RTS      PC
3117
3118          : DATA AREAS.
3119 033646 033333  CMMARK: .WORD 33333          ;STORAGE FOR STACK PTR ON ENTRY.
3120 033650 000000  NULPAR: .WORD 0          ;PAR LIST CONTAINING NO PARS.

```

```

3122          .SBTTL  KEYWORD PROCESSING ROUTINE
3123
3124          : SUBROUTINE TO DETERMINE THE ADDRESS OF THE PROCESSING
3125          : ROUTINE ASSOCIATED WITH THE KEYWORD REPRESENTED BY
3126          : THE SYNTACTIC OBJECT POINTED TO BY THE ARGUMENT
3127          : SRC.  CONVERSION FROM KEYWORD TO ROUTINE ADDRESS
3128          : IS DONE AS DEFINED IN THE KEYWORD TABLE
3129          : POINTED TO BY THE ARGUMENT TABLAD.
3130
3131          : ON ENTRY, THE TOP OF THE STACK IS AS FOLLOWS:
3132          : (SP):  RETURN ADDRESS
3133          : 2(SP):  TABLAD
3134          : 4(SP):  SRC
3135
3136          : CALLING INSTRUCTION:          JSR    PC,KEYWD
3137
3138          : ON RETURN, THE TOP OF THE STACK IS AS FOLLOWS:
3139          : (SP):  ROUTINE ADDRESS, IF KEYWORD IN TABLE; 0 IF NOT.
3140
3141          : IF THE KEYWORD IS IN THE TABLE, C=0 ON RETURN.  IF NOT, C 1.
3142
3143          : STACK POINTER OFFSETS
3144          :ROUTAD -          0          :ROUTINE ADDR FOR
3145          :          :          :CURRENT TABLE
3146          :          :          :ELEMENT.
3147          :          :          :ADDR OF INPUT WORD
3148          :          :          :#CHAR IN INPUT WORD
3149          :          :          :SUBROUTINE RETURN ADDR
3150          :          :          :ADDR OF KEYWORD TABLE
3151          :          :          :ADDR OF INPUT OBJECT
3152          :          :          :RESULT RETURNED
3153
3154          :          :          :**ENTRY POINT**
3155          :          :          :SAVE REGISTERS.
3156          :          :          :ALLOCATE STACK SPACE
3157          :          :          :GET ADDR OF INPUT
3158          :          :          :OBJECT
3159          :          :          :IF OBJECT NOT A WORD
3160          :          :          :THEN EXIT: NOT FOUND
3161          :          :          :GET # CHAR IN OBJECT.
3162          :          :          :STORE ON STACK.
3163          :          :          :GET ADDR OF INPUT WORD.
3164          :          :          :STORE ON STACK.
3165          :          :          :GET ADDR. OF KEYWORD
3166          :          :          :TABLE.
3167          :          :          :SAVE ROUTINE ADDR OF
3168          :          :          :1ST ELEMENT.
3169          :          :          :GET MINIMUM LENGTH
3170          :          :          :OF TABLE WORD.
3171          :          :          :GET FULL LENGTH.
3172          :          :          :
3173          :          :          :IF 0, THEN NO MORE
3174          :          :          :TABLE TO SEARCH
3175          :          :          :COMPARE INPUT CHAR
3176          :          :          :WITH TABLE CHAR.

```

3147	000002	ADRINP	-	2	
3148	000004	LENINP	-	4	
3149	000022	RETURN		22	
3150	000024	TABLAD	=	24	
3151	000026	SRC	=	26	
3152	000026	RESULT	=	26	

```

3154          033652          :          :
3155          033652          :          :
3156          (1) 033652 004567 000160          :          :
3157          033656 162706 000006          :          :
3158          033662 016602 000026          :          :
3159          033666 005722          :          :
3160          033670 001051          :          :
3161          033672 012205          :          :
3162          033674 010566 000004          :          :
3163          033700 011204          :          :
3164          033702 010466 000002          :          :
3165          033706 016603 000024          :          :
3166
3167          033712 012316          :          :
3168
3169          033714 112302          :          :
3170          033716 042702 177400          :          :
3171          033722 112301          :          :
3172          033724 042701 177400          :          :
3173          033730 001431          :          :
3174
3175          033732 122423          :          :
3176

```

```
3177 033734 002427          BLT    NOTHER          ;IF<, THEN NO MATCH
3178                                ; EXISTS.
3179 033736 003005          BGT    NXTWD           ;IF>, THEN TRY NEXT
3180                                ; TABLE WORD.
3181 033740 005305          DEC    R5              ;IF INPUT STRING
3182                                ; EXHAUSTED,
3183 033742 001413          BEQ    THFND           ; WE MAY HAVE FOUND
3184                                ; MATCH.
3185 033744 005301          DEC    R1              ;IF MORE CHAR IN TABLE WORD
3186 033746 001371          BNE    NXTWD           ; TO TEST, GO & TEST THEM.
3187 033750 005201          INC    R1
3188 033752 060103          NXTWD: ADD    R1,R3          ;GET ADDR OF NEXT
3189 033754 042703 000001    BIC    #1,R3          ; TABLE ENTRY.
3190 033760 016604 000002    MOV    ADRINP(SP),R4 ;POINT TO BEGINNING
3191                                ; OF INPUT WORD.
3192 033764 016605 000004    MOV    LENINP(SP),R5 ;GET LENGTH OF INPUT WORD.
3193 033770 000750          BR     GTLENS         ;GET LENGTHS OF TABLE WORD.
3194
3195 033772 026602 000004    THFND: CMP    LENINP(SP),R2 ;IF LEN(INP.WD) < MIN LEN (TABLE
3196 033776 002406          BLT    NOTHER          ; WORD), WORD IS NOT IN TABLE.
3197 034000 011666 000026    MOV    (SP),RESULT(SP) ;SAVE ROUTINE ADDR. OF
3198                                ; MATCH.
3199 034004 062706 000006    ADD    #6,SP          ;FREE LOCAL STACK SPACE.
3200 034010 000241          CLC                    ;CLEAR CARRY BIT.
3201 034012 000405          BR     KWEXIT
3202
3203                                ; WORD IS NOT IN TABLE. SET RESULT TO 0 & SET Z BIT ON.
3204 034014 005066 000026    NOTHER: CLR    RESULT(SP) ;CLEAR RESULT.
3205 034020 062706 000006    ADD    #6,SP          ;FREE LOCAL STACK SPACE.
3206 034024 000261          SEC                    ;SET CARRY BIT.
3207 034026          KWEXIT: REGRES        ;RESTORE REGISTERS.
3208 (1) 034026 004567 000020    JSR    R5,REGRES
3209 034032 012616          MOV    (SP)+,@SP      ;POP AN ARGUMENT.
                                ;RETURN.
                                RTS    PC
```

3211
3212
3213
3214
3215 034036
3216 034036 010446
3217 034040 010346
3218 034042 010246
3219 034044 010146
3220 034046 010046
3221 034050 000115
3222
3223
3224
3225
3226
3227
3228
3229 034052
3230 034052 030026
3231 034054 012600
3232 034056 012601
3233 034060 012602
3234 034062 012603
3235 034064 012604
3236 034066 000205

```
.SBTTL REGISTER SAVE & RESTORE ROUTINES  
:  
: SUBROUTINE TO SAVE R0 - R5 ON STACK  
: CALLING SEQUENCE: JSR R5,REGSAV  
REGSAV: ;**ENTRY POINT**  
      MOV R4,-(SP)  
      MOV R3,-(SP)  
      MOV R2,-(SP)  
      MOV R1,-(SP)  
      MOV R0,-(SP)  
      JMP @R5  
:  
: SUBROUTINE TO RESTORE R0-R5 FROM STACK  
: THE CONDITION CODE BITS IN THE PS ARE DESTROYED,  
: EXCEPT FOR THE CARRY BIT, WHICH IS PRESERVED.  
:  
: CALLING SEQUENCE: JSR R5,REGRES  
REGRES: ;**ENTRY POINT**  
      BIT R0,(SP)+ ;THROW AWAY OLD R5 VALUE.  
      MOV (SP)+,R0  
      MOV (SP)+,R1  
      MOV (SP)+,R2  
      MOV (SP)+,R3  
      MOV (SP)+,R4  
      RTS R5
```

3238
3239
3240
3241
3242
3243
3244
3245
3246
3247
3248
3249
3250
3251
3252
3253
3254
3255
3256
3257
3258
3259
3260
3261
3262
3263
3264
3265
3266
3267
3268
3269
3270
3271
3272
3273
3274
3275
3276
3277
3278
3279
3280
3281
3282
3283
3284
3285
3286
3287
3288
3289
3290
3291
3292
3293

.SBTTL LEXICAL SCAN ROUTINE

: PERFORM LEXICAL SCAN OF INPUT COMMAND IN
: BUFFER.

: THREE CLASSES OF SYNTACTIC OBJECTS ARE RECOGNIZED:
: 1. WORD: A STRING OF CHARACTERS BEGINNING WITH
: A LETTER & TERMINATED WITH A
: BLANK OR CARRIAGE RETURN.
: 2. NUMBER: A STRING OF OCTETS TERMINATED WITH A
: BLANK OR CARRIAGE RETURN, OR A STRING OF DIGITS
: TERMINATED WITH A DOT.
: 3. CHARACTER STRING: A STRING SURROUNDED BY 2 INSTANCES
: (1 ON EACH END) OF A SPECIAL CHARACTER.


: SYNTACTIC OBJECTS ARE SEPARATED BY 1 OR MORE BLANKS.
: THE COMMAND IS ENDED BY A CARRIAGE RETURN.

: THIS LEXICAL SCANNER DETERMINES THE LOCATIONS OF THE
: SYNTACTIC OBJECTS & DETERMINES THEIR CLASSES.
: NUMBERS ARE CONVERTED TO THEIR BINARY VALUES.

: AFTER THE LEXICAL SCAN IS PERFORMED, EACH
: SYNTACTIC OBJECT WILL BE REPRESENTED ON THE STACK
: AS A 3 WORD QUANTITY AS FOLLOWS:

TOP WORD	=	SYNTACTIC CLASS:
		0==>WORD
		2==>NUMBER
		4==>CHARACTER STRING
2ND WORD	-	LENGTH OF OBJECT IN CHARACTERS; NOT SIGNIFICANT FOR NUMBERS; DOES NOT INCLUDE SURROUNDING DELIMITERS FOR CHAR. STRINGS.
3RD WORD	=	VALUE OF NUMBER, OR POINTER TO 1ST LETTER OF KEYWORD OR 1ST SIGNIFICANT CHARACTER OF STRING (IE: NOT SUR- ROUNDING DELIMITER)

: AT THE END OF THE LEXICAL SCAN THE STACK WILL BE
: ARRANGED AS FOLLOWS (N NO. OF SYNTACTIC OBJECTS):



: WHERE EACH OBJECT IS REPRESENTED AS ABOVE.

: CALLING SEQUENCE: R1=BUFFER ADDRESS
: JSR R1,LXSCAN
: ON RETURN, REGISTERS 0-5 ARE UNDEFINED.
: EXCEPT FOR THE ABOVE TABLE, THE STACK IS AS IT
: WAS BEFORE ENTRY TO THE ROUTINE.

3294
3295
3296
3297
3298
3299
3300 034070
3301 034070 005002
3302 034072 012605
3303 034074
(1) 034074 122527 000040
(1) 034100 001775
(1) 034102 005305
3304 034104
(1) 034104 121527 000101
(1) 034110 002410
(1) 034112 121527 000132
(1) 034116 003002
(1) 034120 005004
(1) 034122 000424
(1) 034124 012704 000004
(1) 034130 000421
(1) 034132 121527 000060
(1) 034136 002406
(1) 034140 121527 000071
(1) 034144 003367
(1) 034146 012704 000002
(1) 034152 000410
(1) 034154 121527 000055
(1) 034160 001757
(1) 034162 121527 000015
(1) 034166 001356
(1) 034170 012704 000006
3305 034174 000174 034200
3306
3307 034200 034210
3308 034202 034250
3309 034204 034414
3310 034206 034454
3311
3312 034210 010503
3313 034212
(2) 034212 121527 000040
(2) 034216 001405
(2) 034220 121527 000015
(2) 034224 001402
(1) 034226 005205
(1) 034230 000770
3314 034232 010346
3315 034234 160503
3316 034236 005403
3317 034240 010346
3318 034242 010446
3319
3320 034244 005202
3321 034246 000712

; IF LXSCAN DETECTS AN ERROR CONDITION, IT RETURNS WITH THE CARRY (C)
; BIT SET; OTHERWISE IT IS CLEAR. AT THE MOMENT, THE
; ONLY ERROR CONDITION DETECTED BY LXSCAN IS A STRING WHICH IS MISSING
; ITS CLOSING DELIMITER.

LXSCAN: ;**ENTRY POINT**
CLR R2 ;CLEAR #OBJECTS.
MOV (SP)+,R5 ;GET ADDR. OF COMMAND BUFFER.
NXTTEL: SPAN R5,<#> ;R5 = ADDR (1ST NONBLANK CHAR)
64\$: CMPB (R5)+,#' ;
BEQ 64\$
DEC R5
SYNCLS @R5,R4 ;DETERMINE SYNTACTIC CLASS.
CMPB @R5,#'A
BLT 67\$
CMPB @R5,#'Z
BGT 66\$
65\$: CLR R4
BR 69\$
66\$: MOV #4,R4
BR 69\$
67\$: CMPB @R5,#'0
BLT 68\$
CMPB @R5,#'9
BGT 66\$
MOV #2,R4
BR 69\$
68\$: CMPB @R5,#'-
BEQ 65\$
CMPB @R5,#15
BNE 66\$
MOV #6,R4
JMP @SJT(R4) ;PROCESS OBJECT
SJT: .WORD SCWORD ;WORD PROCESSOR.
.WORD SCNO ;NUMBER PROCESSOR.
.WORD SCCHAR ;CHARACTER STRING PROCESSOR.
.WORD SCEOL ;END OF LINE PROCESSOR.
SCWORD: MOV R5,R3 ;R3 = START ADDR OF OBJECT
BREAK R5,<<#>,<#15>> ;R5 - ADDR (NEXT BLANK OR CR)
CMPB @R5,#'
BEQ 65\$
CMPB @R5,#15
BEQ 65\$
INC R5
BR 64\$
MOV R3,-(SP) ;PUSH ADDR OF OBJECT ONTO STACK.
SUB R5,R3 ;R3 = (-LENGTH OF OBJECT)
PLAC: NEG R3 ;NEGATE TO GET LENGTH.
MOV R3,-(SP) ;PUSH LENGTH ONTO STACK.
MOV R4,-(SP) ;PUSH SYNTACTIC CLASS ONTO
; STACK
LXINCN: INC R2 ;INCREMENT
BR NXTTEL ;GO TO SCAN NEXT ELEMENT

CZ
PC
BD
BR
CA
CB
ER
ER
HE
KE
LX
MU
MU
PR
RE
RE
RE
SP
ST
SY
.
E
P
R
R
C

3322									
3323	034250	005000		SCNO:	CLR	R0			: CLEAR ACCUMULATED NO.
3324	034252	010504			MOV	R5,R4			: SAVE POINTER TO 1ST DIGIT.
3325	034254	121527	000060	SNXTDQ:	CMPB	@R5,#'0			: IF CHAR < '0'
3326	034260	002415			BLT	SNTDIG			: THEN TREAT AS DELIMITER.
3327	034262	121527	000071		CMPB	@R5,#'9			: IF CHAR > '9'
3328	034266	003012			BGT	SNTDIG			: THEN TREAT AS DELIMITER.
3329	034270				MULT	10.,R0,R3			: MULTIPLY PREVIOUS DIGITS BY 10.
(2)	034270	006300			ASL	R0			
(2)	034272	010003			MOV	R0,R3			
(2)	034274	006300			ASL	R0			
(2)	034276	006300			ASL	R0			
(2)	034300	060300			ADD	R3,R0			
3330	034302	112503			MOVB	(R5)+,R3			
3331	034304	142703	000060		BICB	#60,R3			: CLEAR TOP BITS OF ASCII CODE.
3332	034310	060300			ADD	R3,R0			: ADD DIGIT.
3333	034312	000760			BR	SNXTDQ			: GET NEXT DIGIT.
3334									
3335	034314	121527	000040	SNTDIG:	CMPB	@R5,#'			: IF DELIMITER = SPACE, TRY
3336	034320	001413			BEQ	TRYOCT			: CONVERTING OCTAL NO.
3337	034322	121527	000015		CMPB	@R5,#15			: IF DELIMITER = CR, TRY
3338	034326	001410			BEQ	TRYOCT			: CONVERTING OCTAL NO.
3339	034330	122527	000056		CMPB	(R5)+,#'.			: IF DELIMITER IS NOT DOT,
3340	034334	001052			BNE	LXERR			: THEN SIGNAL LXSCAN ERROR.
3341	034336	010046		PUSHNO:	MOV	R0,-(SP)			: PUT CONVERTED NO. ON STACK.
3342	034340	005046			CLR	-(SP)			: SET OBJECT LENGTH TO ZERO.
3343	034342	012746	000002		MOV	#2,-(SP)			: SET OBJECT CLASS TO 2
3344									: (NUMBER).
3345	034346	000736			BR	LXINCN			: INCREMENT OBJ. COUNT &
3346									: SCAN NEXT OBJ.
3347									
3348	034350	005000		TRYOCT:	CLR	R0			: CLEAR ACCUMULATED NO.
3349	034352	121427	000060	ONXTDQ:	CMPB	@R4,#'0			: IF CHAR < '0'
3350	034356	002413			BLT	ODELIM			: THEN TREAT AS DELIMITER.
3351	034360	121427	000067		CMPB	@R4,#'7			: IF CHAR > '7'
3352	034364	003010			BGT	ODELIM			: THEN TREAT AS DELIMITER.
3353	034366				MULT	8.,R0			: MULTIPLY PREVIOUS DIGITS BY 8.
(2)	034366	006300			ASL	R0			
(2)	034370	006300			ASL	R0			
(2)	034372	006300			ASL	R0			
3354	034374	112403			MOVB	(R4)+,R3			: GET CHARACTER.
3355	034376	142703	000060		BICB	#60,R3			: CLEAR TOP BITS OF ASCII CODE.
3356	034402	060300			ADD	R3,R0			: ADD DIGIT.
3357	034404	000762			BR	ONXTDQ			: GET NEXT DIGIT.
3358									
3359	034406	020405		ODELIM:	CMP	R4,R5			: IF NOT AT END OF NO. (DUE TO
3360	034410	001024			BNE	LXERR			: '8' OR '9'), LXSCAN ERROR.
3361	034412	000751			BR	PUSHNO			: GENERATE OBJECT FOR NUMBER.
3362									
3363	034414	112500		SCCHAR:	MOVB	(R5)+,R0			: R0 = DELIMITER OF STRING.
3364	034416	010503			MOV	R5,R3			: R3 = ADDR (1ST CHAR OF
3365									: STRING ITSELF)
3366	034420				BREAK	R5,<R0,#15>			: R5 = ADDR (NEXT DELIM OR CR).
(2)	034420	121500			CMPB	@R5,R0			
(2)	034422	001405			BEQ	65\$			
(2)	034424	121527	000015		CMPB	@R5,#15			

```
(2) 034430 001402          BEQ      65$
(1) 034432 005205          INC      R5
(1) 034434 000771          BR       64$
3367 034436 121527 000015  (MPB)   @R5,#15          ;WAS CR FOUND BEFORE DELIMITER?
3368 034442 001407          BEQ      LXERR          ;YES, PROCESS ERROR
3369 034444 010346          MOV      R3,-(SP)       ;PUSH ADDR. OF STRING ONTO
3370                                ; STACK.
3371 034446 160503          SUB      R5,R3          ;R3 = (-LENGTH OF STRING EXCL.
3372                                ; DELIMITER)
3373 034450 005205          INC      R5             ;R5 = ADDR (CHAR AFTER CLOSING
3374                                ; DELIMITER).
3375 034452 000671          BR       PLAC          ;FINISH OFF PROCESSING STRING.
3376
3377 034454 010246          SCEOL:  MOV      R2,-(SP) ;PUSH NO. OF OBJECTS ONTO STACK
3378 034456 000241          CLC                                ;INDICATE NO ERROR
3379 034460 000111          LXIT:  JMP      @R1      ;RETURN TO CALLING PROGRAMME
3380
3381                                ; PROCESS LFXICAL SCAN ERROR .
3382 034462 000261          LXERR:  SEC                                ;INDICATE ERROR OCCURRED .
3383 034464 005302          DEC      R2             ;CLEAN UP STACK & EXIT .
3384 034466 002774          BLT     LXIT           ; ..
3385 034470 062706 000006          ADD     #6,SP          ; ..
3386 034474 000772          BR      LXERR         ; ..
3387
3388
3389                                000001          .END
```


CPALP	004552	771#	786			
CPARTN	004634	788#	790			
CPASS	005704	1023#	2479			
CPCLR	004764	834#	2482			
CPCLRC	005014	843#	850			
CPCLRT	005056	854#	856			
CPUNRT	005212	888	890#	892		
CPCNT	005126	881#	2485			
CPDEL	004644	794#	2488			
CPDLP	004660	799#	819			
CPDRTN	004754	821#	823			
CPERR	006612	1177#	2491			
CPERTN	006730	1188	1194#	1197		
CPGO	005522	982#	2494			
CPINIT	005222	905#	2497			
CPINRT	005460	947#	949			
CPMAST	004130	649#	2500			
CPMLP	003520	583#	599			
CPMOK	004144	651	654#			
CPMRET	004212	653	663#			
CPRANG	004400	723#	2503			
CPRFIL	004502	747#	751			
CPRIB	004306	694#	2506			
CPRK	004322	696	699#			
CPRRET	004376	698	711#			
CPRRTN	004526	753#	756			
CPSEC	004214	669#	2509			
CPSEX	004076	633#	636	642		
CPSILO	003420	565#	2512			
CPSLV	004034	621	627#			
CPSOK	004230	671	674#			
CPSRET	004300	673	684#	688		
CPSRTN	005116	868#	870			
CPSTAT	005066	862#	2515			
CPSUM	005470	956#	2518			
CPSURT	005512	961#	963			
CRRET	015100	2080	2085#			
CR.	= 000015	333#	2081	2272		
CTLCMG	016412	2126	2336#			
CTLDMG	016404	2094	2334#			
CTLUMG	016'07	2135	2335#			
CTL.C	= 000003	336#	2270			
CTL.O	= 000017	334#	2273			
CTL.Q	= 000021	337#	2274			
CTL.S	= 000023	338#	2275			
CTL.U	= 000025	335#	2276			
CURAD	017752	1349*	1350	1477	1502	2400#
CYCL	007362	1302	1304#			
DATBUF	020666	1272	1347	2433#		
DATGEN	007136	506	1258#			
DATGEV	017660	504	946*	1285*	1367*	2367#
DBCLP	011110	1560#	1562			
DBFCLR	011074	1547	1557#			
DDIV	033256	2839	2888#			
DECJSP	032716	1852	1903	1955	2720#	
DECPNT	032724	1783	1787	1791	1795	2726#

BDINIT	229#	910	1343	1453	1462	1487	1513	1548	1631	1680	1690				
BREAK	3020#	3313	3366												
CALL	129#	444	445	446	447	452	474	475	484	494	497	500	503	506	509
	512	515	518	521	524	527	530	537	622	623	624	625	629	885	886
	916	995	996	997	1113	1115	1116	1119	1138	1139	1140	1145	1158	1159	1160
	1186	1232	1238	1239	1240	1348	1400	1412	1416	1424	1428	1432	1434	1438	1448
	1452	1474	1493	1517	1586	1595	1599	1607	1612	1614	1618	1622	1669	1676	1685
	1763	1769	1772	1775	1777	1797	1798	1806	1826	1827	1838	1839	1853	1880	1881
	1888	1889	1891	1904	1956	1960	1968	2054	2066	2069	2084	2094	2126	2135	2157
	2158	2159	2160	2176	2177	2180	2204	2219	2231	2248	2260	2261	2262		
CBTAS	2807#	2833													
ERROR	260#	1586	1595	1599	1607	1612	1614	1618	1622	1669	1676	1685			
ERROT	248#	1400	1412	1416	1424	1428	1432	1434	1438	1448	1452	1474	1493	1517	
HEDING	200#														
KEYWD	44#	656	676	701	3108										
LXSCAN	69#	3099													
MULP	217#	1279	1672												
MULT	151#	578	1997	1998	2000	2036	2037	2039	3329	3353					
PROC	85#	565	649	669	694	723	766	794	834	840	862	881	905	909	917
	956	982	1023	1110	1137	1157	1177	1212	1258	1339	1545	1728	1819	1873	1926
	1976	2014	2052	2078	2091	2106	2116	2125	2134	2147	2171	2190	2213	2244	2259
	2961	2981	3079												
REGRES	280#	542	1227	1401	1455	1463	1488	1514	1529	1563	1588	1629	1643	1681	1692
	2232	3207													
REGSAV	274#	536	1213	1381	1557	1573	2229	3155							
RETURN	110#	633	663	684	711	753	788	821	854	868	890	947	961	1001	1101
	1120	1146	1162	1194	1228	1286	1361	1553	1807	1862	1913	1969	2008	2047	2070
	2085	2095	2108	2118	2163	2181	2205	2221	2263	2783	2869	2906	2939	2952	2975
	2996	3116													
SPAN	3008#	3303													
STCVT	2661#	2709	2715	2721	2727										
SYNCLS	3041#	3304													

. ABS. 034476 000

ERRORS DETECTED: 0

PCLEXR,PCLEXR/CR/NL:TTM:ME<PCLEXR
 RUN-TIME: 11 15 1 SECONDS
 RUN-TIME RATIO: 137/28 4.8
 CORE USED: 10K (19 PAGES)