

VOLUME 013 MACHINE 4341- -0015871 MODEL M02 SYSTEM 0018167 MODE

SCHED SHIP 82/09/17

LOGIC TYPE -0- SYSTEMS DIAGRAMS

DOC COUNTER 04

PAGE NUM	SH	TITLE	PART NUM	EC NUM	FEATURE B/M OR B/MS	
1000T		TAB	0005666255	865416	.W.	0002676002 .W. 0004432864
10005		MAINTENANCE INFORM	0005666449	379607	.W.	0004432864
10015		SAFETY	0005666450	379605	.W.	0004432864
10025		LOC CONTENTS	0005666239	379836	.W.	0004432864
10035D		FRAME FRONT VIEW	0002676231	379814	.W.	0004154512
10045D		FRAME REAR VIEW	0002676232	379836	.W.	0004154512
10055D		GATE 02A	0002676233	379607	.W.	0004154512
10061		FRAME 02	0005666207	379814	.W.	0004432864
10065		RELAYS	0005666243	379836	.W.	0004432864
10075		TOP CD CROSOVER CONN	0005666224	379814	.W.	0004432864
1100T		TAB	0005666256	865416	.W.	0002676002 .W. 0004432864
11005		TOOLS	0005666283	379602	.W.	0004432864
11015		MAINT TOOLS LST	0005666284	379605	.W.	0004432864
11025		CONTINUITY CK	0005666285	379598	.W.	0004432864
1200T		TAB	0005666257	865416	.W.	0002676002 .W. 0004432864
12005D		REMOVAL/REPLACEMENT	0002676213	379814	.W.	0004154512
12015		LSI BOARD	0005666287	379835	.W.	0004432864
12025		LIST LOG CD	0005666288	379817	.W.	0004432864
12035		I/O SIGNAL CABLE	0005666289	379602	.W.	0004432864
12043D		POWER SUPPLIES	0002676214	379606	.W.	0004154512
12045		PS104	0005666290	379605	.W.	0004432864
12055		PS101	0005666291	379605	.W.	0004432864
12057D		PS210	0002676215	379814	.W.	0004154512
12063D		PS212	0002676216	379814	.W.	0004154512
12069D		PS213	0002676217	379814	.W.	0004154512
12075D		VOLT CONVERSION	0002676218	379607	.W.	0004154512
12081D		TR216	0002676219	379606	.W.	0004154512
12085		PS301	0005666294	379605	.W.	0004432864
1300T		TAB	0005666258	865416	.W.	0002676002 .W. 0004432864
13005F		ADJUSTMENTS	0002676220	379606	.W.	0004230664
13015F		CLOCK ADJ PRODRS	0002676221	379606	.W.	0004230664
13025F		SCOPE & PROBE CALB	0002676222	379607	.W.	0004230664
13035F		HOW TO ADJ CLOCK GRP	0002676223	379606	.W.	0004230664
13045F		HOW TO ADJUST CLOCK	0002676224	379606	.W.	0004230664
1400T		TAB	0005666259	865416	.W.	0002676002 .W. 0004432864
14001		SERVICE AIDS	0005666334	379814	.W.	0004432864
14003		MTNCE INF	0005666432	379607	.W.	0004432864
14005		VOL 1	0005666406	379607	.W.	0004432864
14007		VOL 2	0005666407	379607	.W.	0004432864
14009		VOL 13	0005666408	379607	.W.	0004432864
14011		VOL 16	0005666409	379607	.W.	0004432864
14013		VOL 18	0005666410	379607	.W.	0004432864
14015F		SYSTEM CONFIG	0002676235	379827	.W.	0004230664
14025F		MODWLE TRANS	0002676418	379808	.W.	0004230664
14035		UCW ASSIGN PROCD	0005666336	379814	.W.	0004432864
14051		UCW TYPE ASSIGN	0002676250	379814	.W.	0004432864
14075		DISKETTE UPDATE PROC	0005666337	379814	.W.	0004432864
14079		DISKETTE RECOVER PROC	0005666338	379814	.W.	0004432864
14081		DISKETTE RECOVER PRO	0005666339	379817	.W.	0004432864
14095		EREP FAIL STG ADDR	0005666348	379594	.W.	0004432864
14105F		OIA GATE-CD LAYOUT	0002676260	379815	.W.	0004230664
14111		BD SIG LEVELS	0002676240	379814	.W.	0004432864
14113		LOG BD PIN NUMB	0002676323	379814	.W.	0004432864
14115		PRO UNIT SER AIDS	0005666341	379814	.W.	0004432864
14205		CH SER AIDS	0005666342	379605	.W.	0004432864
14215		LP PROC FOR TIO/SIO	0005666343	379606	.W.	0004432864
14223		INTERF CH CHECK TR	0002676247	379814	.W.	0004432864
14225		IFA CARD	0005666344	379814	.W.	0004432864
14235		LIMITED CH LOGOUT	0005666345	379605	.W.	0004432864
14241		CONN EXT CABLE	0005666419	379607	.W.	0004432864
14305		MSS SER AIDS	0005666346	379814	.W.	0004432864
14317		DCP TO CTCA INTCON	0002676249	379814	.W.	0004432864
14325		BASIC CK LIGHT	0002676246	379606	.W.	0004432864
14405		POWER SERV AIDS	0005666347	379814	.W.	0004432864
14425		STD POWER INTFC	0005666433	379605	.W.	0004432864
14505		REMOTE SUP FAC SV PD	0005666412	379815	.W.	0004432864
14515		REM SUP FAC DIAG	0005666413	379602	.W.	0004432864
14525		RSF & WIRING CONF	0005666414	379607	.W.	0004432864
14535		38LS/ JAP CONF	0005666415	379600	.W.	0004432864
14545		LINE PL CONF	0005666416	379600	.W.	0004432864
14555		EIA ADPT CONF	0005666417	379814	.W.	0004432864
14565		PROT CPLR CONF	0002676261	379606	.W.	0004432864
14605F		CON FCTN SERV AIDS	0002676262	379808	.W.	0004230664
14615		I/O & CHAN TR PROC	0002676230	379605	.W.	0004432864
14619		PROCEDURE	0002676263	379605	.W.	0004432864
14625		SCREEN COPY OPTIONS	0002676248	379605	.W.	0004432864
14635F		CE LOGS	0002676420	379825	.W.	0004230664
14705		GRDG PATHS	0002676236	379605	.W.	0004432864
14715		GRDG MD GRP 2 FR 02	0002676237	379605	.W.	0004432864
14725		GRDG FR 03	0002676238	379814	.W.	0004432864
14735D		GRDG MOD GR2 F02	0002676239	379819	.W.	0004154512
1500T		TAB	0005666260	865416	.W.	0002676002 .W. 0004432864
15005		DISKETTE DRIVE 2D	0005666159	379600	.W.	0004432864
1600T		TAB	0005666261	865416	.W.	0002676002 .W. 0004432864
20005		MAINT INFORMATION	0005666160	379607	.W.	0004432864
20015		SAFETY	0005666161	376694	.W.	0004432864

VOLUME 013 MACHINE 4341- -0015871 MODEL M02 SYSTEM 0018167 MODE

SCHED SHIP 82/09/17

LOGIC TYPE -0- SYSTEMS DIAGRAMS

DOC COUNTER 04

PAGE NUM	SH	TITLE	PART NUM	EC NUM	FEATURE B/M OR B/MS
20025D		CONTENTS	0002676330	379814	.W. 0004154512
20035D		GEN INFORMATION	0002676331	379816	.W. 0004154512
20045		BASIC PWR OFF SEQ	0005666164	379601	.W. 0004432864
20055D		POWER MAINTENANCE	0002676332	379607	.W. 0004154512
20065		PWR MAINT SCREEN	0005666166	376694	.W. 0004432864
20075D		MMT STATUS DISPLAY	0002676333	379605	.W. 0004154512
20085D		ANALOG VOLTAGE	0002676334	379816	.W. 0004154512
20095D		TEMP DISPLAY SCREEN	0002676335	379607	.W. 0004154512
20105D		VOLT TRACK CHART	0002676336	379607	.W. 0004154512
20115		MV SCREEN EXPL 5	0005666171	376694	.W. 0004432864
20125		PWR LOG	0005666172	379598	.W. 0004432864
20135		TEMP TRACE	0005666173	379598	.W. 0004432864
20145		DIAGNOSTICS	0005666174	379598	.W. 0004432864
20155D		VOLT DIST	0002676337	379607	.W. 0004154512
20165D		DC DIST	0002676338	379607	.W. 0004154512
20175D		DC DIST	0002676339	379607	.W. 0004154512
20185D		SWITCHING REGULATORS	0002676340	379605	.W. 0004154512
20195D		IPS BOARD 03AA2	0002676341	379814	.W. 0004154512
20205D		BOARD	0002676342	379607	.W. 0004154512
20211D		VOLT PINS	0002676343	379835	.W. 0004154512
20213		BD 03AA1 VLTG PINS	0002676047	379814	.W. 0004432864
20215D		VOLT ADJUSTMENTS	0002676344	379607	.W. 0004154512
20225D		SENSORS	0002676345	379607	.W. 0004154512
20235D		BOARD 01AB2	0002676346	379816	.W. 0004154512
20241B		BD VLTG SENSE PTS	0005666204	379607	.W. 0004154512
20241D		DD VLTG SENSE PTS	0002676351	379607	.W. 0004154512
20245D		AIR FLOW SENSOR	0002676347	379814	.W. 0004154512
20255		INDICATORS	0005666185	376694	.W. 0004432864
20265		OP CONT PNL INDICATR	0005666186	379814	.W. 0004432864
20275		PWR MICROCODE	0005666187	379601	.W. 0004432864
20285		HRD WIRED SEQ	0005666188	379607	.W. 0004432864
20295		EMC DETECTOR/MONITOR	0005666189	379814	.W. 0004432864
20305		HWS SEC LEVEL SH 1-7	0005666190	376694	.W. 0004432864
20315		HWS SEC LEVEL SH 3	0005666191	379607	.W. 0004432864
20325		HWS SEC LEVEL SH 5	0005666192	379607	.W. 0004432864
20335D		HWS SECOND LEVEL	0002676348	379607	.W. 0004154512
20345		PWR CONT ADAPTER	0005666194	379594	.W. 0004432864
20355		PWR CONT DATA FL	0005666195	379607	.W. 0004432864
20365		SENSE CD	0005666196	379594	.W. 0004432864
20375		VOLT MONITORING FLOW	0005666197	379607	.W. 0004432864
20385D		INTEGRATED PWR SYSTM	0002676349	379607	.W. 0004154512
20395		DET PWR-ON SEQ LOGIC	0005666199	379607	.W. 0004432864
20405		DET PWR OFF SEQ LOG	0005666200	379607	.W. 0004432864
20415D		POWER ON ACT STRINGS	0002676350	379814	.W. 0004154512


TOTAL PART NUMBERS THIS VOLUME

130



## Maintenance Information

VOLUME 01	VOLUME 02	VOLUME 03	VOLUME 13/16	VOLUME 17	VOLUME 18
MAINTENANCE ANALYSIS PROCEDURE	MAINTENANCE ANALYSIS PROCEDURE	MAINTENANCE ANALYSIS PROCEDURE	SUPPLEMENT MAINTENANCE INFORMATION	GENERAL INFORMATION	GENERAL INFORMATION
START EXIT UU = 00 02	UU = 1X	UU = 4X 5X EX FX	LOCATIONS TOOLS REMOVAL/ REPLACEMENT ADJUSTMENTS SERVICE AIDS DISKETTE DRIVE PROCESSOR POWER	GENERAL DESCRIPTION FUNCTIONAL UNITS DIAGNOSTIC INFORMATION PROCESSOR LOGS SYSTEM TESTS FEATURES	CONSOLE FUNCTIONS INDEX INSTALLATION



## Supplement Maintenance Information


## PREFACE

This publication is the primary document needed by service personnel as a supplement to the maintenance analysis procedures to service and maintain the 4341 processor. It contains those items referred to by the maintenance analysis procedures for the basic machine for guided maintenance.

Technical changes and additions to the text and illustrations are indicated by a line to the left of the change.

## LEGIBILITY CONVENTION

This manual contains material that is not fully legible. The size of type and the nature of the material is such that legible reproduction is not possible. This material is provided for illustration, usually serving as a sample, and is not intended for reading. Illegible material is enclosed in wavy lines, and marked with a P, as follows:



The drawings and/or specifications contained herein shall not be produced in whole or in part without written permission from IBM.

IBM has prepared this maintenance documentation for the use of IBM customer engineers for installation, maintenance, and repair of the specific machines indicated. IBM makes no representations that it is suitable for any other purpose.

Information contained in this documentation is subject to change from time to time. Changes will be reflected in subsequent revisions.

EC 379600 30Jun80	PN 5666449	10 010
EC 379607 05Jun81	2 of 2	



## SAFETY

### PERSONAL SAFETY

Personal safety cannot be overemphasized: it is a vital part of customer engineering. To ensure your safety and that of co-workers, always observe the safety precautions given during your safety training and adhere to the following:

#### Danger Notices

Observe all DANGER notices in this manual.

#### DANGER

Do not service any power supply or transformer outside the machine while still connected to the machine. (Page 12 043)

#### DANGER

This ground wire must be installed before you power on the system. (Page 12 072d, Step 11)

#### DANGER

Star washer **F** must be replaced for personal and machine safety. (Page 12 081d, Step 10)

#### DANGER

Use extreme care when you perform service while power is on. (Page 15 050, 15 055, 15 070, 15 075, 15 080)

#### DANGER

Solenoid case becomes hot after continuous use. (Page 15 055)

#### DANGER


Drive motor case becomes hot after continuous use. (Page 15 065)

#### DANGER

To prevent personal injury on the 60Hz motors, ensure two large holes **B** in motor case are positioned up and under bracket. (Page 15 065)

#### Danger Labels

All danger labels must be observed and all necessary precautions must be exercised.



This danger label indicates an area or device containing high voltage.

© IBM Corp. 1981

### General Safety Practices

Observe the general safety practices and the procedure for performing artificial respiration outlined in the *CE Safety Practice* card shown on following page.

#### Grounding

Ground current may reach dangerous levels. Never operate the system with the grounding conductor removed.

#### Line-Powered Equipment

Ground all line-powered test equipment through the third-wire grounding conductor in the power cord of the machine being tested.

#### Machine Warning Labels

Heed the warning labels placed in hazardous areas of the machines.

### CE Safety Practices

All Customer Engineers are expected to take every safety precaution possible, and to observe the following safety practices while maintaining IBM equipment:

1. You should not work alone under hazardous conditions or around equipment with dangerous voltage. Always advise your manager if you **MUST** work alone.
2. Remove all power ac and dc when removing or assembling major components, working in the immediate area of power supplies, performing mechanical inspection of power supplies, and installing changes in machine circuitry.
3. Wall box power switch, when turned off, should be locked or tagged in off position. 'Do Not Operate' tags, order number S229-1266, should be affixed when applicable. Pull power supply cord whenever possible.
4. When it is absolutely necessary to work on equipment having exposed operating mechanical parts or exposed live electrical circuitry anywhere in the machine, the following precautions must be followed:
  - a. Another person familiar with power off controls must be in the immediate vicinity.
  - b. Rings, wrist watches, chains, bracelets, and metal cuff links shall not be worn.
  - c. Only insulated pliers and screwdrivers shall be used.
  - d. Keep one hand in pocket.
  - e. When using test equipment, be certain that controls are set correctly and to the proper capacity, and that insulated probes are used.
  - f. Avoid contacting ground potential (metal floor strips, machine frames, etc. - use suitable rubber mats, purchased locally if necessary).
5. Safety glasses must be worn when:
  - a. Using a hammer to drive pins, riveting, staking, etc.
  - b. Power hand drilling, reaming, grinding, etc.
  - c. Using spring hooks, or attaching springs.
  - d. Soldering, wire cutting, or removing steel bands.
  - e. Parts cleaning using solvents, sprays, cleaners, chemicals, etc.
  - f. Exposed to any other condition that may be hazardous to your eyes. **REMEMBER, THEY ARE YOUR EYES.**
6. Special safety instructions, such as for handling cathode ray tubes and extreme high voltages, must be followed as outlined in CEMs and in the Safety section of the Maintenance Manuals.
7. Do not use solvents, chemicals, greases, or oils that have not been approved by IBM.
8. Avoid using tools or test equipment that has not been approved by IBM.
9. Replace worn or broken tools and test equipment.
10. The maximum load to be lifted is that which, in the opinion of you and of management, does not jeopardize your own health or well-being, or that of other employees.
11. All safety devices, such as guards, shields, signs, ground wires, etc., shall be restored after maintenance.
12. Each Customer Engineer is responsible to be certain that no action on his part renders a product unsafe, or exposes hazards to customer personnel.
13. Place removed covers in an out-of-the-way place where no one can trip over them.
14. All machine covers must be in place before the machine is returned to the customer.
15. Always place CE tool kit away from walk areas (that is, under desk or table) where no one can trip over it.

16. Avoid touching moving mechanical parts (that is, when lubricating, checking for play, etc.).
17. When using stroboscope, do not touch ANYTHING; it may be moving.
18. Avoid wearing loose clothing that may become caught in machinery. Shirt sleeves must be left buttoned, or rolled to above the elbow.
19. Ties must be tucked in shirt or fastened with a tie clasp (preferably non-conductive), approximately 3 inches from the end. Tie chains are not recommended.
20. Before starting equipment, make certain that fellow CEs and customer personnel are not in a hazardous position.
21. Maintain good housekeeping in the area of machines while performing, and after completing, maintenance.

#### Artificial Respiration

##### General Considerations

1. Start Immediately. Seconds Count. Do not move victim unless absolutely necessary to remove from danger. Do not wait or look for help or stop to loosen clothing, warm the victim, or apply stimulants.
2. Check Mouth for Obstructions. Remove foreign objects; pull tongue forward.
3. Loosen Clothing; Keep Warm. Take care of these items after victim is breathing by himself, or when help becomes available.
4. Remain in Position. After victim revives, be ready to resume respiration if necessary.
5. Call a Doctor. Have someone summon medical aid.
6. Don't Give Up. Continue without interruption until victim is breathing without help, or until victim is certainly dead.

#### Rescue Breathing for Adults

##### Victim on His Back Immediately.

1. Clear throat of water, food, or foreign matter.
2. Tilt head back to open air passage.
3. Lift jaw up to keep tongue out of air passage.
4. Pinch nostrils to prevent air leakage when you blow.
5. Blow until you see the chest rise.
6. Remove your lips and allow the lungs to empty.
7. Listen for snoring and gurgling, signs of throat obstruction.
8. Repeat mouth-to-mouth breathing 10-20 times per minute. Continue rescue breathing until victim breathes for himself.



Thumb and finger position



Final mouth-to-mouth position

Reprint Courtesy Mine Safety Appliance Co.

#### Model Groups 1 and 2

EC 379602 15Sep80	PN 5666450	10 015
EC 379605 06Mar81	1 of 1	



# LOCATIONS

## CONTENTS

Front Views Of Frames 01, 02, and 03 .....	10 035
<b>Frame 01</b> .....	10 040
View from Behind Gate 01A .....	10 040
Right Side View .....	10 040
Rear View .....	10 045
<b>Gate 01A (Pin Side)</b> .....	10 050
<b>Frame 02</b> .....	10 055
View from Behind Gate 02A * .....	10 055
Rear View * .....	10 055
<b>Gate 02A</b> .....	10 055
Front View ** .....	10 055
Rear View ** .....	10 055
<b>Card Side of IPS Gate 02A*</b> .....	10 060
<b>Frame 02 (Rear View) **</b> .....	10 060
<b>Frame 03</b> .....	10 061
Front View .....	10 061
Front View of Gate 03A (IPS301) .....	10 061
<b>Connectors and Relays</b> .....	10 065
Connector Pin Numbering .....	10 065
Relay Pin Numbering .....	10 065
<b>Gates 01D, 01E, 01G, and 03E</b> .....	10 070
SPI Gate 01D (Standard Power Interface) .....	10 070
SPI Panel P1 Through P6 .....	10 070
SPI Panel P0 .....	10 070
Gate 01E (Channel Interface) .....	10 071
Bus/Tag Receptacle Pin Numbering .....	10 071
Bus/Tag Cable-End Connector Pin Numbering .....	10 071
Gate 01G .....	10 071
Gate 03E (CTCA) .....	10 071
<b>Top Card Crossover Connectors (TCC)</b> .....	10 075
Pin Numbering .....	10 075
Top Card Crossover Connector (Except for PCA) .....	10 075
PCA Top Card Crossover Connector (01AB2) .....	10 075
<b>Miscellaneous Locations</b> .....	10 080
CE Panel Connectors .....	10 080
Unit Emergency Power Off Switch .....	10 080
Operator Control Panel (OCP) Switches .....	10 080

\* Applies to machines with Ferro Power Supplies


\*\* Applies to machines with Switching Regulator Power Supplies

Model Groups 1 and 2

EC 379814 02Oct81	PN 5666239	10 025
EC 379836 19Apr82	1 of 1	



FRAME 01, 02, and 03 (FRONT VIEW)




Model Group 2, Switching Regulators


EC 379605 06Mar81	PN 2676231	10 035d
EC 379814 02Oct81	1 of 2	

FRAME 01

VIEW FROM BEHIND GATE 01A




RIGHT SIDE VIEW



Model Group 2, Switching Regulators

EC 379605 06Mar81	PN 2676231	10 040d
EC 379814 02Oct81	2 of 2	

FRAME 01 (REAR VIEW)




Model Group 2, Switching Regulators


EC379816 20Oct80	PN 2676232	10 045d
EC379836 19Apr82	1 of 2	




GATE 01A (PIN SIDE)



BOARDS A1, B1  
CONNECTORS A1, C1, and E1




CONNECTORS A4, C4, and E4




Model Group 2, Switching Regulators

EC379816 20Oct80	PN 2676232	10 050d
EC379836 19Apr82	2 of 2	

GATE 02A (FRONT VIEW)




GATE 02A (REAR VIEW)



\* Connectors 240 and 244 are mounted on frame 02 directly to the right of gate 02A.

Model Group 2, Switching Regulators

EC 379605 06Mar81	PN 2676233	10 055d
EC 379607 05Jun81	1 of 2	




Model Group 2, Switching Regulators


EC 379605 06Mar81	PN 2676233	10 060d
EC 379607 05Jun81	2 of 2	

FRAME 03

(FRONT VIEW)



FRONT VIEW OF GATE 03A (IPS301)



CARD SIDE VIEW




Model Groups 1 and 2

EC 379814 02Oct81	PN 5666207	10 061
EC 379837 28Jun82	1 of 1	




# CONNECTORS AND RELAYS


## CONNECTOR PIN NUMBERING




## RELAY PIN NUMBERING




PCC K1 and K3 (Pin Side)




PCC CP1 (Single Pole)




PCC CP1 (Two Pole)



PCC K2







PCC K4 (Four Pole)



PCC K4 (Three Pole)

Below are the four 60Hz K4 relays, indicating the location of the N/O terminal:



Model Groups 1 and 2

EC 379836 19Apr82	PN 5666243	10 065
EC 379839 30Dec82	1 of 3	


# GATES 01D, 01E, 01G, and 03E

## SPI GATE 01D (STANDARD POWER INTERFACE)

**Notes:**


1. Look at the machine to determine the SPI box layout that applies.
2. SPI panels P4, P5, P6 are not present on all machines.
3. The diagrams show relative position of the SPI box and panels in frame 01.

FRAME 01 (REAR VIEW)




One or the other apply

Standard Power Interface Box




Standard Power Interface Box




Note: SPI panels P4, P5, and P6 are mounted directly in front of SPI panels P1, P2, P3, respectively.

## SPI PANELS P1 THROUGH P6 (Component View)



\*If present

## SPI PANEL P0 (Component View)




Model Groups 1 and 2

EC 379836 19Apr82	PN 5666243	10 070
EC 379839 30Dec82	2 of 3	




GATE 01E (CHANNEL INTERFACE)

CHAN 0	CHAN 1	CHAN 2	CHAN 3	CHAN 4	CHAN 5
A1 TAG	B1 TAG	C1 TAG	D1 TAG	E1 TAG	F1 TAG
A2 BUS	B2 BUS	C2 BUS	D2 BUS	E2 BUS	F2 BUS



BUS/TAG CABLE RECEPTACLE PIN NUMBERING  
(Pin Side)

x = Shield Pin



BUS/TAG CABLE-END CONNECTOR PIN NUMBERING  
(Pin Side)

x = Shield Pin

GATE 01G


Spare	Spare
Spare	Spare
Spare	Spare
RSF	Spare
Ext Int	Spare

GATE 03E (CTCA)

A1 TAG IN X	B1 TAG OUT X	C1 TAG IN Y	D1 TAG OUT Y
A2 BUS IN X	B2 BUS OUT X	C2 BUS IN Y	D2 BUS OUT Y


Model Groups 1 and 2

EC 379836 19Apr82	PN 5666243	10 071
EC 379839 30Dec82	3 of 3	




# TOP CARD CROSSOVER CONNECTORS (TCC)

## PIN NUMBERING




COMPONENT SIDE

## TOP CARD CROSSOVER CONNECTORS (EXCEPT FOR THE PCA)



Note: Ensure that TCC connectors are not one pin position high or low when replugging.

## PCA TOP CARD CROSSOVER CONNECTORS (01AB2)





Model Groups 1 and 2

EC 379604 05Dec80	PN 5666224	10 075
EC 379814 02Oct81	1 of 2	


# MISCELLANEOUS LOCATIONS

# OPERATOR CONTROL PANEL (OCP) SWITCHES

## CE PANEL CONNECTORS



## UNIT EMERGENCY POWER OFF SWITCH



Model Groups 1 and 2

EC 379604 05Dec80	PN 5666224	10 080
EC 379814 02Oct81	2 of 2	

# TOOLS

## CONTENTS

<b>Maintenance Tools List</b> .....	11 015
<b>Tool Figures</b> .....	11 016
Power Cable Removal Tool .....	11 016
Probe Assembly .....	11 016
Probe Tip Adapter .....	11 016
Signal Cable Removal Tool .....	11 016
Actuation Tool .....	11 016
Actuation Tool Blade .....	11 016
Continuity Checker .....	11 016
Card Puller .....	11 016
Tektronix* 475/DM44 Oscilloscope .....	11 017
Board Probe Mask .....	11 017
Captive Screw .....	11 017
Cable Probe Adapter .....	11 017
Special Voltage Power	
Decoupling Capacitor Pin Aligner .....	11 017
Cable Clamp Position Tool .....	11 017
Card Container .....	11 017
<b>Actuation Tool</b> .....	11 020
Operation .....	11 020
<b>Continuity Checker</b> .....	11 025
Operation .....	11 025
Maintenance .....	11 025
Battery Replacement .....	11 025
Lamp Replacement .....	11 025
<b>Card Pin Alignment</b> .....	11 030
Single Pin Aligner .....	11 030
Card Pin Aligner .....	11 030

\* Trademark of Tektronix Inc.

Model Groups 1 and 2

EC 379602 15Sep80	PN 5666283	11 005
EC 379837 28Jun82	1 of 1	

1941

1942

1943

1944

1945

1946

1947

1948

1949

1950

1951

1952

1953

1954

1955

1956

1957

1958

1959

1960

1961

1962

1963

1964

1965

1966

1967



## MAINTENANCE TOOLS LIST

The following tools are used to maintain the 4341 processor and Large Scale Integration (LSI) logic.

Tool Description	Part Number	Figure Page
Battery 1.35V	453119	11 025
Battery 2.8V	453120	11 025
Power Cable Removal Tool	453132	11 016
Decoupling Capacitor		
Insert/Removal Tool	453467	12 030
Continuity Checker	453587	11 016
Special Voltage Power		
Decoupling Capacitor		
Pin Aligner	453727	11 017
Card Container	453841	11 017
Card Pin Aligner	453849	11 030
Single-Pin Aligner	453857	11 030
Signal and Ground Probe Tip	453915	11 016
Probe Tip Adapter	1310714	11 016
Adapter	453954	11 025
Tool Bag	963400	
Card Puller	1310707	11 016
Tektronix* 475/DM44		
Oscilloscope	1650782	11 017
Tektronix P6106 Probe	1650776	
Digitec** 2210 Multimeter	1749233	
Board Probe Mask	2360334	11 017
Signal Cable Removal Tool	2360340	11 016
Cable Clamp Position Tool	2360406	11 017
Cable Probe Adapter	2360408	11 017
Lead Extension Assembly	2360417	
Actuation Tool	4134750	11 016
Actuation Tool Blade	4138537	11 016
Channel Wrap Test Cable		
Bus	8483772	
Tag	8483773	

\* Trademark of Tektronix Inc.

\*\* Trademark of United System Corp.


Model Groups 1 and 2

EC 379605 06Mar81	PN 5666284	11 015
EC 379837 28Jun82	1 of 4	




**TOOL FIGURES**

**POWER CABLE REMOVAL TOOL PN 453132**




**PROBE ASSEMBLY PN 453915**




**PROBE TIP ADAPTER Part 1310714**


(Use for voltage level checking.)



**SIGNAL CABLE REMOVAL TOOL PN 2360340**




**CONTINUITY CHECKER PN 453587**




**ACTUATION TOOL PN 4134750**

**ACTUATION TOOL BLADE PN 4138537**




**CARD PULLER PN 1310707**




Model Groups 1 and 2

EC 379605 06Mar81	PN 5666284	11 016
EC 379837 28Jun82	2 of 4	


TEKTRONIX 475/DM44 OSCILLOSCOPE PN 1650782




BOARD PROBE MASK PN 2360334  
(CAPTIVE SCREW PN 2360072)




CABLE PROBE ADAPTER PN 2360408




CARD CONTAINER PN 453841



CABLE CLAMP POSITION TOOL  
PN 2360406



SPECIAL VOLTAGE POWER DECOUPLING  
CAPACITOR PIN ALIGNER PN 453727



Model Groups 1 and 2

EC 379605 06Mar81	PN 5666284	11 017
EC 379837 28Jun82	3 of 4	

## ACTUATION TOOL (Part 4134750)

This tool is used to remove/replace:

- Probe mask
- Power cable (FDS) housing clamp
- Board stiffener assembly
- LSI logic card
- Card guidance hardware
- I/O signal cable groupers.

The actuation tool is a hand-operated tool with a preset torque setting when turned clockwise. Torque control is needed to prevent damage to the screw threads and inserts.

**Note:** Actuation tool blade is part 4138537.

### OPERATION

Ensure the tip of tool is seated in the socket head screw to be removed/replaced. When tightening the screw, turn the tool clockwise until you feel the tool slip and hear a clicking sound. Screw is now fully tightened.

When removing a screw, ensure the tip is fully seated in the socket head screw. The actuation tool has a positive drive in a counterclockwise direction.

ACTUATION TOOL PN 4134750



Model Groups 1 and 2

EC 379605 06Mar81	PN 5666284	11 020
EC 379837 28Jun82	4 of 4	

## CONTINUITY CHECKER (PN 453587)

The continuity checker is a plastic housing with a clear plastic lens that contains an indicator. A 6-32 threaded rod extends from one end and a flexible lead with a 6-32 threaded stud extends from the other end. Various probe tips can be adapted to the continuity checker.

### OPERATION

Assemble the necessary probe tip to the continuity checker. Connect the probe tip on the flexible lead to a convenient checkpoint. Probe with the threaded rod (with probe tip) protruding from the other end of the continuity checker.

**Caution:** Do not use the CE ohm-meter on LSI logic. Circuits could be damaged.

### MAINTENANCE

Maintenance consists of replacement of the following:

1.35V battery	PN 453119
2.8V battery	PN 453120
Indicator lamp	PN 5353889



#### Battery Replacement

Remove the lock screw near the front of the continuity checker. Hold the body, and pull the clear plastic end until the two parts are separated. Replace the bad batteries (observe the polarity). Reassemble checker in reverse order.

#### Lamp Replacement

Disassemble the tool as in Battery Replacement procedure. Loosen locknut and remove the circuit card assembly from the plastic lens. Remove the bad lamp. Remove the lens cap from the new lamp and insert in the circuit card assembly. Reassemble the continuity checker in reverse order.

### CONTINUITY CHECKER



# CARD PIN ALIGNMENT

Card pins must be straight for card installation.

Tools used are:


- Card pin aligner PN 453849
- Single-pin aligner PN 453857

## SINGLE-PIN ALIGNER


The single-pin aligner **A** is used to straighten pins that are bent too much to use the card pin aligner. Use the single-pin aligner to straighten the pin to its approximate position, and then use the card pin aligner.

## CARD PIN ALIGNER


1. Place slot in the narrow end of tool over bent pin **B**. Keep tool at a right angle to the card housing surface.
2. Push the tool on the pin until it is seated against the card housing surface.
3. Remove the tool by pulling straight out.
4. Repeat steps 1, 2, and 3 until pin is straight.
5. Using the wide end of the tool, repeat steps 1, 2, and 3. This ensures alignment with the other pins **C**.




**A** Using the Single Pin Aligner



**B** Using the Card Pin Aligner



**C** Ensuring Alignment of Straightened Pins



EC 376694 16Jul79	PN 5666285	11 030
EC 379598 15Apr80	2 of 2	

# REMOVALS AND REPLACEMENTS

## CONTENTS

<b>CE Safety Practices</b> .....	12 006
<b>LSI Board</b> .....	12 015
Remove Board Assembly.....	12 015
Disassemble the Board.....	12 015
Prepare the New Board Assembly.....	12 015
Install New Board Assembly.....	12 015
<b>MST Board</b> .....	12 020
<b>Probe Mask Installation</b> .....	12 020
<b>LSI Logic Card</b> .....	12 025
Removal.....	12 025
Replacement.....	12 025
<b>Flexible Distribution System (FDS)</b> .....	12 025
Repair.....	12 025
FDS Cable Removal.....	12 025
FDS Cable Replacement.....	12 025
<b>Decoupling Capacitor (C-Pac)</b> .....	12 030
Removal.....	12 030
Replacement.....	12 030
<b>I/O Signal Cable</b> .....	12 035
Removal.....	12 035
Replacement.....	12 035
<b>Power Supplies and Transformers</b> .....	12 043
Power Supplies and Transformers Locations.....	12 043
PS104.....	12 045
TR104.....	12 050
PS101.....	12 055
TR101.....	12 055
PS210.....	12 057
PS211.....	12 060
PS212.....	12 063
Switch Settings and Adjustments.....	12 066
PS213.....	12 069
PS215.....	12 072
PS215 Voltage Conversion.....	12 075
PS216.....	12 078
TR216.....	12 081
PS301.....	12 085
TR301.....	12 090

### CE Safety Practices

All Customer Engineers are expected to take every safety precaution possible, and to observe the following safety practices while maintaining IBM equipment:

1. You should not work alone under hazardous conditions or around equipment with dangerous voltage. Always advise your manager if you **MUST** work alone.
2. Remove all power ac and dc when removing or assembling major components, working in the immediate area of power supplies, performing mechanical inspection of power supplies, and installing changes in machine circuitry.
3. Wall box power switch, when turned off, should be locked or tagged in off position. 'Do Not Operate' tags, order number S229-1266, should be affixed when applicable. Pull power supply cord whenever possible.
4. When it is absolutely necessary to work on equipment having exposed operating mechanical parts or exposed live electrical circuitry anywhere in the machine, the following precautions must be followed:
  - a. Another person familiar with power off controls must be in the immediate vicinity.
  - b. Rings, wrist watches, chains, bracelets, and metal cuff links shall not be worn.
  - c. Only insulated pliers and screwdrivers shall be used.
  - d. Keep one hand in pocket.
  - e. When using test equipment, be certain that controls are set correctly and to the proper capacity, and that insulated probes are used.
  - f. Avoid contacting ground potential (metal floor strips, machine frames, etc. - use suitable rubber mats, purchased locally if necessary).
5. Safety glasses must be worn when:
  - a. Using a hammer to drive pins, riveting, staking, etc.
  - b. Power hand drilling, reaming, grinding, etc.
  - c. Using spring hooks, or attaching springs.
  - d. Soldering, wire cutting, or removing steel bands.
  - e. Parts cleaning using solvents, sprays, cleaners, chemicals, etc.
  - f. Exposed to any other condition that may be hazardous to your eyes. **REMEMBER, THEY ARE YOUR EYES.**
6. Special safety instructions, such as for handling cathode ray tubes and extreme high voltages, must be followed as outlined in CEMs and in the Safety section of the Maintenance Manuals.
7. Do not use solvents, chemicals, greases, or oils that have not been approved by IBM.
8. Avoid using tools or test equipment that has not been approved by IBM.
9. Replace worn or broken tools and test equipment.
10. The maximum load to be lifted is that which, in the opinion of you and of management, does not jeopardize your own health or well-being, or that of other employees.
11. All safety devices, such as guards, shields, signs, ground wires, etc., shall be restored after maintenance.
12. Each Customer Engineer is responsible to be certain that no action on his part renders a product unsafe, or exposes hazards to customer personnel.
13. Place removed covers in an out-of-the-way place where no one can trip over them.
14. All machine covers must be in place before the machine is returned to the customer.
15. Always place CE tool kit away from walk areas (that is, under desk or table) where no one can trip over it.

16. Avoid touching moving mechanical parts (that is, when lubricating, checking for play, etc.).
17. When using stroboscope, do not touch **ANYTHING**; it may be moving.
18. Avoid wearing loose clothing that may become caught in machinery. Shirt sleeves must be left buttoned, or rolled to above the elbow.
19. Ties must be tucked in shirt or fastened with a tie clasp (preferably non-conductive), approximately 3 inches from the end. Tie chains are not recommended.
20. Before starting equipment, make certain that fellow CEs and customer personnel are not in a hazardous position.
21. Maintain good housekeeping in the area of machines while performing, and after completing, maintenance.

### Artificial Respiration

#### General Considerations

1. **Start Immediately. Seconds Count.**  
Do not move victim unless absolutely necessary to remove from danger. Do not wait or look for help or stop to loosen clothing, warm the victim, or apply stimulants.
2. **Check Mouth for Obstructions.**  
Remove foreign objects; pull tongue forward.
3. **Loosen Clothing; Keep Warm.**  
Take care of these items after victim is breathing by himself, or when help becomes available.
4. **Remain in Position.**  
After victim revives, be ready to resume respiration if necessary.
5. **Call a Doctor.**  
Have someone summon medical aid.
6. **Don't Give Up.**  
Continue without interruption until victim is breathing without help, or until victim is certainly dead.

### Rescue Breathing for Adults

#### Victim on His Back Immediately.

1. Clear throat of water, food, or foreign matter.
2. Tilt head back to open air passage.
3. Lift jaw up to keep tongue out of air passage.
4. Pinch nostrils to prevent air leakage when you blow.
5. Blow until you see the chest rise.
6. Remove your lips and allow the lungs to empty.
7. Listen for snoring and gurgling, signs of throat obstruction.
8. Repeat mouth-to-mouth breathing 10-20 times per minute. Continue rescue breathing until victim breathes for himself.



Thumb and finger position



Final mouth-to-mouth position

Reprint Courtesy Mine Safety Appliance Co.

### Model Group 2, Switching Regulators

EC 379606 20Apr81	PN 2676213	12 006d
EC 379814 02Oct81	2 of 2	



## LSI BOARD

### REMOVE BOARD ASSEMBLY

#### Card Side

1. Press **POWER OFF** key on the OCP.

#### CAUTION

Observe label for closing the 01A gate.

2. Remove board card cover.
3. Disconnect I/O signal cables (A2, A3, B1, B4, D1, D4, V2, and V3) by:
  - a. Obtaining an actuation tool (part 4134750) to loosen or tighten captive screws as directed.
  - b. Completely loosening the 16 captive screws **A**.

**Note:** Note the position and placement of the air baffle before removal. The position, placement, and number of the air baffles depend on the board being serviced.

4. Remove air baffle **D** from between the frame and card guidance hardware **E**.

#### Pin Side

1. Disconnect all voltage connectors (FDS and special voltage housings).
2. Completely loosen the 16 captive screws which hold the board assembly to the frame.
  - Loosen *top center screw last*, and support the board assembly with free hand.
3. Carefully remove board assembly from frame. Place the board assembly, pin side down, on a flat surface.

#### Disassemble the Board

1. Remove all logic cards:
  - a. Remove top card connectors (TCCs).
  - b. Completely loosen all logic card captive screws **B**.
  - c. Remove all logic cards and put in container (part 453841).
2. Remove card guidance hardware **E**.
  - a. Completely loosen eight captive screws **C**.
3. Disconnect the decoupling capacitors (A1, C1, E1, A4, C4, and E4) by:
  - a. Obtaining tool (part 453467).
  - b. Disconnecting each decoupling capacitor, one at a time, and plugging into the same location on the new board.

#### Notes:

- Every LSI board does not contain capacitors in all six positions.
- Decoupling capacitor part 4138522 apply to positions A1, A4, E1, and E4. The C1 and C4 positions could have: part 4138522, part 4138587, or none.

### Prepare the New Board Assembly

1. Place new board assembly on a flat surface, pin side down, so the board part number is in the upper right corner **F**.
2. Reinstall the card guidance hardware **E** on the new board:
  - a. Ensure card position lettering is as shown in **G**.
  - b. Tighten eight captive screws **C**.
3. Reinstall logic cards from container into the new board:
  - a. Match the card position lettering shown on the cards to the card position lettering **G**.
    - Ensure that the components are to the right.
  - b. Alternately tighten all logic card captive screws **B**.
4. Reinstall top card connectors (TCCs).
  - To ensure that the TCCs are connected in the correct positions, see the section 14, *Service Aids*, page 14 105, "01A-Gate Card Layout."

### INSTALL NEW BOARD ASSEMBLY


#### Pin Side

1. Carefully install board assembly on the frame, and tighten the 16 board captive screws.
2. Reinstall all voltage connectors (FDS and special voltage housings).

#### Card Side

1. Reinstall the air baffle **D**.
2. Reinstall all I/O signal cables.
  - a. Tighten captive screws **A**. (You may need to remove the cable clamps.)
  - b. Ensure that each connector in the super grouper is seated properly.
3. Reinstall cable clamps (if removed), and ensure that TCCs are fully seated in the correct positions.
4. Install board card cover.
5. Turn on system power.

### LSI BOARD AND CARD GUIDANCE HARDWARE



#### Model Groups 1 and 2

EC 379835 18Dec81	PN 5666287	12 015
EC 379837 28Jun82	1 of 2	

## MST BOARD

### MST Board Removal/Replacement

1. Power off.
2. Open front and rear covers of frame 01.
3. Open gate 01A.

#### CAUTION

Observe label for closing gate 01A.

4. Place CB1 and CB2 in OFF position.
5. Locate board to be removed.
6. Remove front and rear covers from board.
7. Remove all cards from board.

**Note:** Ensure that all cards are labeled for their board positions.

8. Remove all cable connectors from card side (front) of board.

**Note:** Ensure that all cable connectors are labeled for their board positions.

9. Go to pin side of gate 01A and locate rear of board.
10. Remove flat wire and minibus connectors from board.

#### CAUTION

During replacement, be careful to align flat wire and minibus connectors properly on their pin positions.

11. If there are back panel jumpers/capacitors, transfer them to the new board.

**Note:** Record the board and pin positions of any jumpers/capacitors being removed.

12. Remove mounting screws from top and both sides of board.
13. Loosen (do not remove) mounting screws from bottom of board; tilt top of board and lift it from its position.
14. Reverse procedure for MST board replacement.

## PROBE MASK INSTALLATION


1. Turn off processor power.
2. Disconnect two cables from C4 position (bottom center) of board.
3. Remove logic board pin cover.
4. Align the three probe mask locating pins and push probe mask on until it contacts the board stiffener.
5. Tighten all probe mask captive screws with the actuation tool (part 4134750).

**Note:** Captive screw is part 2360072.

6. Connect the two cables into the C4 position (where removed).
7. Turn on processor power.

**Warning:** Do not use CE ohmmeter on LSI logic. Circuits could be damaged.

### PROBE MASK INSTALLED ON LOGIC BOARD



Model Groups 1 and 2

EC 379835 18Dec81  
EC 379837 28Jun82

PN 5666287

2 of 2

12 020

## LSI LOGIC CARD


### REMOVAL

1. Turn off processor power.
2. Open board card cover.
3. Remove (if present) top card crossover connectors (TCCC) from the card to be removed.
4. Using actuation tool (PN 4134750), completely loosen two captive screws **A** of the card to be removed.
5. Using both hands, move upper and lower lever arms, **B** in the direction of the arrows, and pull the card out.

### REPLACEMENT





1. Insert the card so the arrows on the levers and card components point to the right.
2. Using actuation tool (PN 4134750), alternately tighten two screws **A**.
3. Install TCCC (if removed).
4. Close board card cover.
5. Turn on processor power.

LSI CARD EXAMPLE  
VIEW FROM TCCC SIDE



TOP CARD CROSSOVER CONNECTORS (TCC)

PIN NUMBERING  
(x = ground when TCC is plugged.)



C  
O  
M  
P  
O  
N  
E  
N  
T  
S  
I  
D  
E

Note: Ensure that TCC connectors are not one pin position high or low when replugging.

## FLEXIBLE DISTRIBUTION SYSTEM (FDS)

### REPAIR

Repair of the FDS cables is limited to repairing torn or cut insulation. The repair is made by applying one turn, but not more than two, of insulation tape (PN 817979) so that it overlaps itself after one complete turn around the damaged connector. The length of the tape is to be 57 mm (2.25 inches) minimum.

The number of repairs per cable is not limited.

### FDS CABLE REMOVAL

1. Turn off processor power.
2. Disconnect cable housing to be removed from the board (use cable card puller, PN 453132).
3. Remove cable retainers from channel containing the cable to be removed.
4. Tape together the cables that are above the cable to be removed.
5. Remove the cable from the terminal block.
6. Carefully remove the cable from the channel.
7. Turn on processor power.

### FDS CABLE REPLACEMENT

1. Complete cable folding operation by folding at each precrease (fold mark). Make folds in the same direction as the precrease. (Fold mark should be on inside of radius being formed).
2. Insert the replacement cable between the taped cables and those left free.
3. Install the cable housing on the board.
4. Connect the cable to its position on the terminal block.
5. Remove all tape.
6. Install the cable retainers.
7. Turn on processor power.

Model Groups 1 and 2

EC 379598 15Apr80	PN 5666288	12 025
EC 379817 06Mar81	1 of 2	

## DECOUPLING CAPACITOR (C-PAC)

### REMOVAL


Use insert/removal tool (PN 453467) to remove a decoupling capacitor (C-PAC).

1. Turn off processor power.
2. Hold tool so that the small hole and the T-bar are facing up to remove upper C-PACs, and facing down to remove lower C-PACs.
3. Put tool on C-PAC as shown in diagram and pull straight out, at a right angle to the board surface.

### REPLACEMENT

Use insert/removal tool (PN 453467) to install a C-PAC.

1. Turn off processor power.
2. Hold tool so that the small hole and the T-bar are facing up to install upper C-PACs, and facing down to install lower C-PACs.
3. Put the tool on C-PAC, as shown in the diagram, and push straight in at a right angle to the board surface.



Model Groups 1 and 2

EC 379598 15Apr80	PN 5666288	12 030
EC 379817 06Mar81	2 of 2	

# I/O SIGNAL CABLE

## REMOVAL


Use cable extraction tool (PN 2360340) to remove a signal cable from a super grouper.

1. Move pivot **A** to the top of the tool.
2. Position tool above contact side of the super grouper as shown.
3. Ensure tool is seated on the super grouper housing, and then move pivot **A** to the bottom of the tool.
4. Remove cable from super grouper, one cable at a time.
5. Remove cable extraction tool.


## REPLACEMENT

1. Position cable on housing with beveled edges as shown **B**.
2. Push cable in correct slot until the latch arms snap in place.


### **A** ORIENTING THE CABLE EXTRACTION TOOL



### **B** FIVE-POSITION CABLE GROUPE



### **C** SUPER GROUPE DETAIL










# POWER SUPPLIES AND TRANSFORMERS

## POWER SUPPLIES AND TRANSFORMERS LOCATIONS

### DANGER

Do not service any power supply or transformer outside the machine while still connected to the machine.



### Model Group 2, Switching Regulators

EC 379816 20Oct80	PN 2676214	12 043d
EC 379606 20Apr81	1 of 1	

*[Faint, illegible text covering the majority of the page, likely bleed-through from the reverse side.]*





**PS104**

**CAUTION**

Perform steps 1-4 to ensure that power is not in the processor during this procedure.

1. Power off.
2. Open front and rear covers of frame 01.
3. Open gate 01A.

**CAUTION**


Observe label for closing gate 01A.

4. Place CB1 and CB2, located on front of PCC box, in OFF position.
5. Identify the location of PS104 in frame 01. See "Power Supplies and Transformers Locations," page 12 043.
6. Disconnect all connectors at the connector sockets **A** and **B**. Place cables away from PS104.

**Note:** Be careful not to lose the nut and washer **D** when doing the next two steps.

7. Use a metric socket wrench to disconnect FDS cables connected to TB2 **C** and place them away from PS104.
8. Use a metric socket wrench and disconnect FDS cables connected to TB1 **E** and place them away from PS104.
9. Remove four screws **F**.
10. Carefully remove PS104 from frame 01.
11. Reverse this procedure for PS104 replacement.

**Note:** After reinstalling new PS104, ensure that all CP switches are in the ON position.



Model Groups 1 and 2

EC 379604 05Dec80	PN 5666290	12 045
EC 379605 06Mar81	1 of 2	

## TR104

### CAUTION

Perform steps 1-4 to ensure that power is not in the processor during this procedure.

1. Power off.
2. Open front and back covers of frame 01.
3. Open gate 01A.

### CAUTION


Observe label for closing gate 01A.

4. Place CB1 and CB2, on front of PCC box, in OFF position.
5. Identify location of TR104 in front of frame 01. See "Power Supplies and Transformers Locations," page 12 043.
6. Disconnect connectors **A**.
7. Disconnect connector 26 **B** from PCC box.
8. Remove screw, nut, and washer **C**.
9. Remove screw **D**.
10. Carefully remove TR104 from frame 01.

**Note:** If the line voltage at the machine installation is not 208V, the internal TB of the transformer needs to be adjusted to match the line voltage. For TB adjustments, refer to ALD page YA015, and then locate the name of transformer and the voltage needed.

11. Reverse procedure for TR104 replacement.

**Warning:** Be careful not to damage the wires of TR104 while removing or reinstalling it.



Model Groups 1 and 2

EC 379604 05Dec80	PN 5666290	12 050
EC 379605 06Mar81	2 of 2	

## PS101

### CAUTION


Perform steps 1, 2, and 3 to ensure that power is not in the processor during this procedure.

1. Power off.
2. Open rear cover of frame 01.
3. Place CB1 and CB2, located on front of PCC box, in OFF position.
4. Identify location of PS101 at rear of frame 01. See "Power Supplies and Transformers Locations," page 12 043.
5. Disconnect connector at con 01 **A**.
6. Disconnect connectors from sockets **B**. Place cables away from PS101.

**Note:** No connectors are plugged at sockets Con 02, 10, 11, and 12.

7. Remove two screws **C**.
8. Carefully remove PS101 from frame 01.
9. Reverse procedure for PS101 replacement.

**Note:** After reinstalling PS101, ensure that all of its CP switches are in the ON position.



## TR101


### CAUTION

Perform steps 1, 2, and 3 to ensure that power is not in the processor during this procedure.

1. Power off.
2. Open rear cover of frame 01.
3. Place CB1 and CB2, on front of PCC box, in OFF position.
4. Identify location of TR101 at rear of frame 01. See "Power Supplies and Transformers Locations," page 12 043.
5. Disconnect connector 27 **A** from PCC box.
6. Disconnect connector 01 **B** from PS101.
7. Remove two screws **C**.
8. Carefully remove TR101 from frame 01.

**Note:** If the line voltage at the machine installation is not 208V, the internal TB of the transformer needs to be adjusted to match the line voltage. For TB adjustments, refer to ALD page YA015, and then locate the name of transformer and the voltage needed.

9. Reverse procedure for TR101 replacement.



Model Groups 1 and 2

EC 379604 05Dec80  
EC 379605 06Mar81

PN 5666291

1 of 1

12 055



PS210

**CAUTION**

Perform steps 1, 2, and 3 to ensure that power is not in the processor during this procedure.

1. Power off from the OCP.
2. Open rear cover of frame 01.
3. Place CB1 and CB2, on front of PCC box, in OFF position.
4. Open front cover of frame 02.

**Note:** Remove cover if necessary.

5. Identify location of PS210.
6. Open gate 02A.
7. Remove safety shield **A** by removing the two screws.
8. Remove FDS cables from TBs **B**.
9. Close gate 02A.
10. Disconnect connectors from sockets **C**.


**Note:** Sockets J2 and J4 are not used.

11. Remove the four sets of mounting screws, washers, and lock washers **D**.

**Warning:** PS210 weighs 17 kg (38 lb). During the removal of PS210, support it with one hand holding the handle and the other hand supporting the bottom.

12. Carefully remove PS210 from front of gate 02A.
13. Remove front cover by removing the six sets of screws, washers, and lock washers **E**.
14. Record the positions of the switches on the control card.
15. Perform "Switch Settings and Adjustments" on page 12 066; then return.
16. Reverse procedure for PS210 replacement.

**Warning:** Do not interchange PS210 with PS211 because it could cause damage to cards.



# PS211

## CAUTION

Perform steps 1, 2, and 3 to ensure that power is not in the processor during this procedure.

1. Power off from the OCP.
2. Open rear cover of frame 01.
3. Place CB1 and CB2, on front of PCC box, in OFF position.
4. Open front cover of frame 02.

**Note:** Remove cover if necessary.

5. Identify location of PS211.
6. Open gate 02A.
7. Remove safety shield **A** by removing the two screws.
8. Remove FDS cables from TBs **B**.
9. Close gate 02A.
10. Disconnect connectors from sockets **C**.


**Note:** Sockets J2 and J4 are not used.

11. Remove the four sets of mounting screws, washers, and lock washers **D**.

**Warning:** PS211 weighs 17 kg (38 lb). During the removal of PS211, support it with one hand holding the handle and the other hand supporting the bottom.

12. Carefully remove PS211 from front of gate 02A.
13. Remove front cover by removing the six sets of screws, washers, and lock washers **E**.
14. Record the positions of the switches on the control card.
15. Perform "Switch Settings and Adjustments" on page 12 066; then return.
16. Reverse procedure for PS211 replacement.

**Warning:** Do not interchange PS211 with PS210 because it could cause damage to cards.



### Model Group 2, Switching Regulators

EC 379606 20Apr81	PN 2676215	12 060d
EC 379814 02Oct81	2 of 2	

**PS212**

**CAUTION**

Perform steps 1, 2, and 3 to ensure that power is not in the processor during this procedure.

1. Power off from the OCP.
2. Open rear cover of frame 01.
3. Place CB1 and CB2, on front of PCC box, in OFF position.
4. Open front cover of frame 02.

**Note:** Remove cover if necessary.

5. Identify location of PS212.
6. Open gate 02A.
7. Record the position of the toggle switches **A**.

**Note:** Refer to MAP 1005, entry point A, for toggle switch setting procedure if needed.

8. Disconnect connectors from sockets **B** and **C**.
9. Remove FDS cables from TBs **D**.
10. Close gate 02A.
11. Remove connectors from sockets **E**.


**Note:** Socket J4 is not used.

12. Remove the four sets of mounting screws, washers, and lock washers **F**.

**Warning:** PS212 weighs 18 kg (40 lb). During the removal of PS212, support it with one hand holding the handle and the other hand supporting the bottom.

13. Carefully remove PS212 from front of gate 02A.
14. Remove front cover by removing six sets of screws, washers, and lock washers **G**.
15. Record the positions of the switches on the control card.
16. Perform "Switch Settings and Adjustments" on page 12 066; then return.
17. Reverse procedure for PS212 replacement.

**Note:** After replacing PS212, ensure that CP1 and CP2 are in the ON position.



## Switch Settings and Adjustments

This procedure assists MAP 1005 and MAP 1003 to set the switches and to adjust the voltages for PS210, PS211, and PS212.

**Note:** For toggle switches on PS212, page 12 063, **A**, see MAP 1005; for PS213 voltage adjustment, see page 12 069, and MAP 1003.


After the removal procedure for the power supply is complete, perform the following steps on the supply being installed:

1. Set switches **A** and **B** like the switch settings of the supply being removed. To verify the switch settings, see MAP 1005, entry point A.

**Note:** If you are servicing a power supply in JAPAN, remove the GREEN/YELLOW jumper **C** by clipping 25.4 mm (1 inch) from each end.

2. Return to the removal/replacement procedure to assemble and install the power supply in frame 02. Then perform the voltage adjustment through the opening in front of the supply.

To perform voltage adjustments, refer to MAP 1003, entry point A.



Model Group 2, Switching Regulators

EC 379607 05Jun81	PN 2676216	12 066d
EC 379814 02Oct81	2 of 2	



## PS213

### CAUTION

Perform steps 1, 2, and 3 to ensure that power is not in the processor during this procedure.

1. Power off from the OCP.
2. Open rear cover of frame 01.
3. Place CB1 and CB2, on front of PCC box, in OFF position.
4. Open front cover of frame 02.

**Note:** Remove cover if necessary.


5. Identify location of PS213.
6. Open gate 02A.
7. Remove FDS cables from TBs **A**.
8. Disconnect connectors from sockets **B**.
9. Close gate 02A.
10. Remove the four sets of mounting screws, washers, and lock washers **C**.

**Warning:** PS213 weighs 9 kg (20 lb).

11. Carefully remove PS213 from front of gate 02A.
12. For voltage adjustments, see MAP 1003, entry point A.

**Note:** The openings for the 4V and 6V adjustments are indicated by **D**.

13. Reverse procedure for PS213 replacement.



### Model Group 2, Switching Regulators

EC 379607 05Jun81	PN 2676217	12 069d
EC 379814 02Oct81	1 of 2	

## PS215

### CAUTION

Perform steps 1, 2, and 3 to ensure that power is not in the processor during this procedure.

1. Power off from the OCP.
2. Open rear cover of frame 01.
3. Place CB1 and CB2, located on front of PCC box, in OFF position.
4. Open rear cover of frame 02.
5. Identify location of PS215 from rear view of frame 02. See Power Supplies and Transformers Locations, page 12 043d.
6. Remove shields covering TB1, TB3 and TB4. See diagram of PS215 shown to the right.
7. Remove wires **A** from TB3.  
(Note the star washers under each terminal.)
8. Remove wires **B** from TB4.  
(Note the star washers under each terminal.)
9. Remove wires **C** from TB1.
10. Remove the four mounting screws, washers, and lock washers **D** and **E**.


### DANGER

Ground wire **F** must be reinstalled before you power on the processor.

11. Remove ground wire **F**.
12. Carefully remove PS215 from frame 02.

**Note:** If the supply being installed needs to have the line voltage converted, refer to page 12 075d and use ALD page YA015.

13. Reverse procedure for PS215 replacement.



### Model Group 2, Switching Regulators


EC 379607 05Jun81	PN 2676217	12 072d
EC 379814 02Oct81	2 of 2	

## PS215 Voltage Conversion


1. Set power supply on a table.
2. Loosen screws **A** and **B** ; then move screen covers so that they clear the outer plate of the supply.
3. Set PS215 on the back surface to continue.
4. Remove the four screws **C** and **D** .
4. Carefully lift the outer plate of the supply and locate TB2 **E** .
5. Wire TB2 as shown on ALD page YA015. Use the correct wiring configuration as a starting point.

**Note:** If converting from a voltage between 200 and 240 to a voltage of 380 and above, tape the unused jumpers on the inside on frame 02, next to PS215. This ensures that these jumpers are available if a reverse conversion is needed.

6. Reverse procedure to assemble power supply.
7. Install PS215 in frame 02; refer to 12 067d, step 13.



FRONT VIEW



Model Group 2, Switching Regulators

EC 379606 20Apr81	PN 2676218	12 075d
EC 379607 05Jun81	1 of 2	


## PS216

### CAUTION

Perform steps 1, 2, and 3 to ensure that power is not in the processor during this procedure.

1. Power off from the OCP.
2. Open rear cover of frame 01.
3. Place CB1 and CB2, located on front of PCC box, in OFF position.
4. Open rear cover of frame 02.
5. Identify location of PS216 from rear view of frame 02. See Power Supplies and Transformers Locations, page 12 043.
6. Remove connectors from sockets **A**, **B**, and **C**.
7. Remove the four sets of screws, washers, and lock washers **D**.
8. Carefully remove PS216 from frame 02.
9. Reverse this procedure to replace PS216.

**Note:** After replacing PS216, ensure that CP1 and CP2 are in the ON position.



### Model Group 2, Switching Regulators

EC 379606 20Apr81	PN 2676218	12 078d
EC 379607 05Jun81	2 of 2	

## TR216

### CAUTION

Perform steps 1, 2, and 3 to ensure that power is not in the processor during this procedure.

1. Power Off.
2. Open rear cover frame 01.
3. Place CB1 and CB2, on front of PCC box, in OFF position.
4. Open rear cover of frame 02.
5. Identify location of TR216 from rear view of frame 02, see "Power Supplies and Transformers Locations," on page 12 043.

6. Remove shield over TB1.

7. Remove connector **A** from PS216.

**Note:** Record the position of wires on TB1 before removing them.

8. Remove wires **B** from TB1.


**Note:** If the line voltage at the machine installation is not 208V, the TB1 needs to be adjusted to match the line voltage. For TB adjustments, refer to ALD page YA015, and then locate the name of transformer and the voltage needed.

9. Remove ground wire **C** from TB1 mounting plate.

10. Remove the four sets of screws, washers, lock washers **D**, and the star washer **E**.

### DANGER

Star washer **E** is for grounding and must be replaced for personal and machine safety.



Model Group 2, Switching Regulators

EC 379816 20Oct80	PN 2676219	12 081d
EC 379606 20Apr81	1 of 1	




# PS301

## CAUTION

Perform steps 1, 2, and 3 to ensure that power is not in the processor during this procedure.

1. Power off.
2. Open rear cover of frame 01.
3. Place CB1 and CB2, located on front of PCC box, in OFF position.
4. Open front cover of frame 03.
5. Identify location of PS301 from front view of frame 03. See "Power Supplies and Transformers Locations," page 12 043.
6. Disconnect connectors from sockets **A**.
7. Disconnect connectors from sockets **B**.
8. Disconnect wires **C**, **D**, **E**, and **F** from the terminals.
9. Remove two screws **G**.
10. Carefully remove PS301 from frame 03.
11. Reverse procedure for PS301 replacement.

**Note:** After reinstalling PS301, ensure that all its CP switches are in the ON position.



## TR301


### CAUTION

Perform steps 1, 2, and 3 to ensure that power is not in the processor during this procedure.

1. Power off.
2. Open rear cover of frame 01.
3. Place CB1 and CB2, on front of PCC box, in OFF position.
4. Open front cover of frame 03.
5. Identify location of TR301 from front view of frame 03. See "Power Supplies and Transformers Locations," page 12 043.
6. Disconnect connectors **A** from PS301.
7. Disconnect connector **B**.  
Note the position where this connector is removed.
8. Remove two screws **C**.
9. Carefully remove TR301 from frame 03.

**Note:** If the line voltage at the machine installation is not 208V, the internal TB of the transformer needs to be adjusted to match the line voltage. For TB adjustments, refer to ALD page YA015, and then locate the name of transformer and the voltage needed.

10. Reverse procedure for TR301 replacement.



Model Groups 1 and 2

EC 379604 05Dec80	PN 5666294	12 090
EC 379605 06Mar81	2 of 2	




# ADJUSTMENTS

## CONTENTS


<b>Clock Distribution</b> .....	13 010
Clock Distribution Cards .....	13 010
<b>Clock Adjustment Procedures</b> .....	13 015
Timing Verification Test Description .....	13 015
Needed Equipment .....	13 015
DC Voltage Adjustment .....	13 015
Initial Scope Settings .....	13 020
Scope and Probe Calibration .....	13 025
Initial Clock Settings .....	13 030
How to Change a GRP Value .....	13 030
How to Adjust the Clock GRPs .....	13 035
Diskette Clock Value Update .....	13 050
Clock Adjustment Test .....	13 050
Clock Basic Diagnostics Run	
Procedure .....	13 050
MSMD Run Procedure .....	13 050

## CLOCK DISTRIBUTION


The odd and even oscillator outputs are changed by the coarse adjust circuits, and then distributed to several points in the O1A gate. See diagram below.



Because of differing lengths of distribution wiring, clock pulses reach the various logic points at different times. See diagram below.



Adjustable delay circuits in the clock distributor delay the clock pulses so that they reach all the logic points at the same time. See diagram below.



## CLOCK DISTRIBUTION CARDS

The following lists the sources of all the clock GRPs. If you cannot adjust correctly a clock GRP, replace the applicable distribution card.

Clock Card	Clock GRPs
A1H2	11 46
	14 51
	15 52
	16 53
	45 54
A1J2	55
	61
	62
	63 64
A1K2	21 26 36
	22 31 41
	23 32 42
	24 34 43
	25 35 44

Model Group 2

EC 379606 20Apr81	PN 2676220	13 010f
EC 379837 28Jun82	2 of 2	

## CLOCK ADJUSTMENT PROCEDURES

Do the following clock adjustment procedure whenever the Timing Verification Test (TVT) detects that the clocks are improperly adjusted.

### TIMING VERIFICATION TEST (TVT) DESCRIPTION

The TVT is used by the MAPs to determine whether the system clocks are adjusted properly. You can also run the TVT to try to recreate an intermittent failure (especially if you suspect a failing clock signal). The TVT automatically skews the clock group values while running selected MSMD diagnostics.

Do the clock adjustments, only if the TVT detects a failure. (Do the entire clock adjustment procedure because the suspected clock group may not be the one that is actually failing.)

Invoke the TVT by selecting the PUMA option on the Diagnostic General Selection screen. When you are prompted to enter a reference code, key in TVT.

### NEEDED EQUIPMENT

- Tektronix\* Model 475A oscilloscope with DM44 option (PN 1650782), or equivalent.
- Two Tektronix P6106 probes (PN 1650776), or equivalent, of equal length and attenuation.
- Two board probe masks (PN 2360334). Install on board 01AA1 and 01AB1. See "Probe Mask Installation" in Volume 13, "Removals/Replacements."
- Two probe tips (PN 453915).
- One probe-tip adapter (PN 1310714).
- Digitec\*\* 2210 multimeter (PN 1749233), or equivalent.

\* Trademark of Tektronix, Inc.

\*\* Trademark of United Systems Corporation

### DC VOLTAGE ADJUSTMENT

Before you adjust the clock delays, adjust the -1.5V and -4.25V dc voltages.

Use the Digitec and the following chart to check the voltages.

### FERRO POWER SUPPLIES

Checkpoint: PS201 installed in frame 02 (rear side).

If a voltage is out of range, adjust it to the level shown in the column, "Adjust Tolerance."


Voltage	Range	Adjust Tolerance	Measurement Points	Control Card Location
-4.25V	-4.249V to -4.422V	-4.336V $\pm$ .005V	01AA1C2B34 C31 (Gnd)	02AA1D2
-1.5V	-1.439V to -1.554V	-1.524V $\pm$ .005V	01AA1C2B28 C31 (Gnd)	02AA2D4

### SWITCHING REGULATOR POWER SUPPLIES

Checkpoint: PS215 installed in frame 02 (rear side).

If a voltage is out of range, adjust it to the level shown in the column, "Adjust Tolerance."

Voltage	Range	Adjust Tolerance	Measurement Points	Power Supply Location
-4.25V	-4.249V to -4.422V	-4.336V $\pm$ .005V	01AA1C2B34 C31 (Gnd)	PS210
-1.5V	-1.439V to -1.554V	-1.524V $\pm$ .005V	01AA1C2B28 C31 (Gnd)	PS211



Model Group 2


EC 379606 20Apr81  
EC 379837 28Jun82

PN 2676221  
1 of 2

13 015f

# INITIAL SCOPE SETTINGS

Before you begin to adjust the clock, you must set up your scope as shown on this page. Note that the asterisks (\*) on this page identify the controls you adjust during the subsequent clock adjustment procedure.



\* Indicates a control to be adjusted during the clock adjustment procedure.


### Model Group 2

EC 379606 20Apr81	PN 2676221	13 020f
EC 379837 28Jun82	2 of 2	


## Scope and Probe Calibration

When scoping, always connect the black probe tip to ground. Ground is indicated by a yellow circle on the probe mask.

1. Set the CH1 AC-GND-DC switch to GND.
  2. Adjust the CH1 vertical POSITION control until the CH1 trace is along the center line of the scope. Do not change this setting until you are so directed in the clock adjustment procedure.
  3. Set the CH1 AC-GND-DC switch to DC.
  4. Connect the CH1 probe to 01A-A1G2B15 (+ SYS OSC TEST POINT).
  5. Adjust the A TRIGGER LEVEL control (larger knob) to obtain a stable sweep.
  6. Set the DM44 FUNCTION switch to VOLTS.
  7. Vary the horizontal FINE/POSITION control (larger knob) to display one-half cycle of the CH1 waveform. (The scope picture should look like the bottom picture on this page.)
  8. Set the CH2 AC-GND-DC switch to GND.
  9. Adjust the CH2 vertical POSITION control until the CH2 trace is along the center line of the scope.
  10. Set the CH2 AC-GND-DC switch to DC.
  11. Connect the CH2 probe to 01A-A1G2A15 (+ SYS OSC TEST POINT).
  12. Set the DM44 FUNCTION switch to TIME.
  13. Set the DM44  $\Delta$  TIME control so the digital display is approximately 0000.
  14. Set the DM44  $\Delta$  TIME control so the positive-going edges of the CH1 and CH2 traces cross the horizontal reference line at the same point. (See the scope pictures on this page.)
  15. Read the value in the DM44 digital display.
  16. If this value is not 0000, adjust it to 0000 with the ZERO ADJUST screw on the DM44. Repeat steps 14, 15, and 16 until the value is 0000. The scope and probes are now calibrated.
- Note:** If the DM44 does not have a ZERO ADJUST screw, swap probes until a matched pair is found.



Scope and Probe Calibration - Step 14.  
CH1 and CH2 traces before adjustment.



Scope and Probe Calibration - Step 14.  
CH1 and CH2 traces after adjustment.

Model Group 2

EC 379606 20Apr81	PN 2676222	13 025f
EC 379607 05Jun81	1 of 2	

## INITIAL CLOCK SETTINGS

1. Insert the FUNCT diskette into the diskette drive.
2. Set the CE MODE switch to CE MODE.
3. Press "POWER ON/IML" on the operator control panel.
4. Key in QCM and press ENTER.  
This sets the clock values (stored on the diskette) into the clock scan ring latches.
5. Key in QKD and press ENTER.  
This disables machine checks.
6. Key in QVU22ADJUST and press ENTER.  
This sets the clock distribution to adjust mode and displays the clock values on the screen.
7. Copy this screen (recommended to guard against loss of the clock values).
8. If the clock values for your machine have been lost, set them (as a starting point) to the nominal values shown below.
9. If the DL (delay) and PW (pulse width) values in groups 11 and 12 are FF, set DL to 01 and PW to 14.
10. For groups 13 and 15, set DL to 13 and PW to 11.  
These values are not changed during the adjustment.

## NOMINAL ADJUST VALUES DIAGRAM (QVU22ADJUST SCREEN)

	CLOCK RING (QVY)			CGRPNNXX			**IML REQUIRED**																	
	CP	DL	PW	CP	DL	PW	CP	DL	PW	CP	DL	PW	CP	DL	PW									
A ARRAYS	1	0	01	14	2	0	01	14	3	1	13	11	4	1	08	06	5	1	13	11	6	1	08	06
S STATUS SCAN RING	1	0	01	14	2	0	01	14	3	1	13	11	4	1	08	06	5	1	13	11	6	1	08	06
K CHECKS IN SYSTEM	1	0	01	14	2	0	01	14	3	1	13	11	4	1	08	06	5	1	13	11	6	1	08	06
I IPU HARDWARE	2	1	09	07	1	1	10	08	1	1	13	09	1	1	09	06	1	1	13	11	1	1	14	10
B CS HARDWARE	2	1	09	07	1	1	10	08	1	1	13	09	1	1	09	06	1	1	13	11	1	1	14	10
M MS HARDWARE	3	1	13	11	1	1	14	12	1	1	11	11	1	1	08	05	1	1	08	05	1	1	07	05
H CHANNEL HARDWARE	3	1	13	11	1	1	14	12	1	1	11	11	1	1	08	05	1	1	08	05	1	1	07	05
C CHNNL INTERFACE	4	1	13	09	1	1	13	09	1	1	14	10	1	1	14	10	1	1	04	01	1	1	04	01
X EXTERNAL REGS	4	1	13	09	1	1	13	09	1	1	14	10	1	1	14	10	1	1	04	01	1	1	04	01
R SCAN RING	5	1	13	10	1	1	13	10	1	1	12	08	1	1	12	07	1	1	07	05				
Y CLOCK SCAN RING	5	1	13	10	1	1	13	10	1	1	12	08	1	1	12	07	1	1	07	05				
W COMMAND SBA-CAC	6	1	07	03	1	1	08	05	1	1	08	04	1	1	08	04								
T ADDRESS TRANSLAT	6	1	07	03	1	1	08	05	1	1	08	04	1	1	08	04								
G SET CSAR ADDRESS	6	1	07	03	1	1	08	05	1	1	08	04	1	1	08	04								
SERIAL NO. 000000																								
Q GENERAL SELECT																								
Z RTRN TO PROG SYS																								
SELECTION: U22ADJUST																								
MAN TEST																								
CHK: DSBL																								
96D2 96D2																								

## HOW TO CHANGE A GRP VALUE

To change a GRP value on the screen do A or B:

- A. Position the cursor (by using the Tab, Back Tab, or New Line keys) directly under and one line below the value you want to change.

Key in the new value and press ENTER.

The old value is replaced with the new value.

- B. For Fast-Alter:


Key in the GRP number and equal sign (=) after "SELECTION: U22ADJUST."

Press ENTER.

The DL (delay) and PW (pulse width) values for GRPxx are brought down to the selection line (as shown here):

SELECTION: U22ADJUSTxx=xxxx

Key in the new DL and PW value(s) and press ENTER.




Model Group 2

EC 379606 20Apr81	PN 2676222	13 030f
EC 379607 05Jun81	2 of 2	

## HOW TO ADJUST THE CLOCK GRPS

### Notes:

- For groups 11 and 12, the value of PW (pulse width) must be greater than or equal to the value of DL (delay).
  - For groups 13 through 64 the value of DL must be greater than or equal to the value of PW.
1. Set VERT MODE to CH1 and connect CH1 probe to 01A-A1C2B28 (-1.5 volts).
  2. Adjust CH1 vertical POSITION so the CH1 trace is along the horizontal center line of the scope. Disconnect the CH1 probe.
  3. Set VERT MODE to CH2 and connect CH2 probe to 01A-A1C2B28 (-1.5 volts). Adjust CH2 vertical POSITION so the CH2 trace is along the horizontal center line of the scope.
  4. Set VERT MODE to CH1 and vary the DM44 Δ TIME control to display 0000.
  5. Connect the CH1 probe to 01A-A1G2C08 (reference pulse).
  6. Adjust the A TRIGGER LEVEL control (larger knob) until a stable sweep is obtained. Vary the horizontal FINE/POSITION control (larger knob) to position the second minus-going signal near the center of the scope.
  7. Set the DM44 Δ TIME control to display approximately 0215.
  8. Vary the DM44 Δ TIME control until the rising and falling edges cross the horizontal center line at the same point (see the example on this page). This point does not have to be at the exact vertical center line of the scope. If the DM44 digital display is between 0207 and 0223, go to step 10.
  9. If the DM44 digital display is less than 0207, decrease the GRP12 value for PW by one and repeat step 8. If the DM44 digital display is greater than 0223, increase the GRP12 value for PW by one and repeat step 8.
  10. Set VERT MODE to ALT.



How To Adjust the Clock GRPs - Step 8.


**Note:** To save time, you do not need to position the two traces at the exact vertical center of the scope -- anywhere close to the vertical center is acceptable.

### Model Group 2


EC 379808 06Mar81	PN 2676223	13 035f
EC 379606 20Apr81	1 of 2	

**HOW TO ADJUST THE CLOCK GRPS  
(continued)**

11. Connect the CH2 probe to 01A-A1Q2B60 (GRP41 EVEN CLOCK).
12. Set the DM44 Δ TIME control to display approximately 0000.
13. Vary the DM44 Δ TIME control until the falling edges of both pulses cross the horizontal center line at the same point (see the example on this page).  
If the DM44 display is between -0008 and 0008, go to step 15.
14. If the DM44 digital display is less than -0008, increase the PW value of the GRP being probed and repeat step 13.  
If the DM44 digital display is greater than 0008, decrease the PW value of the GRP being probed and repeat step 13.
15. Set the DM44 Δ TIME control to display approximately 0215.
16. Vary the DM44 Δ TIME control until the CH2 rising edge and the CH1 falling edge cross the horizontal center line at the same point (see the example on this page).  
If the DM44 digital display is between 0207 and 0223, record the DL and PW values (see "Even Clock Group Test Points") and go to step 18.
17. If the DM44 digital display is less than 0207, increase by one the DL value of the GRP being probed, and repeat step 16.  
If the DM44 digital display is greater than 0223, decrease by one the DL value of the GRP being probed, and repeat step 16.
18. Connect the CH2 probe to the next GRP (see "Even Clock Group Test Points") and repeat steps 12 through 17.  
Do this for all the remaining GRPs in the even clock group.



How To Adjust the Clock GRPs - Step 13.



How To Adjust the Clock GRPs - Step 16.

NOTES:  
PW = Falling edge CH1 to falling edge CH2 (-0008 to 0008)  
DL = Falling edge CH1 to rising edge CH2 (0207 to 0223)

GRP Numbers	CH2 Probe Points	Old Values		New Values *	
		DL	PW	DL	PW
41	01A-A1 Q2B60				
42	↑ U2D51				
43	↕ N2C29				
44	↓ E2B26				
53	↓ C2A21				
54	01A-A1 B2C21				
16	01A-B1 B2B35				
34	↑ B2C26				
35	↕ K2B50				
36	↓ M2B29				
46	↓ U2B54				
63	↓ N2C58				
64	01A-B1 Q2A62				

EVEN CLOCK GROUP TEST POINTS (used in steps 11-18)

\* For groups 11 and 12, the value of PW (pulse width) must be greater than or equal to the value of DL (delay).

For groups 13 through 64 the value of DL must be greater than or equal to the value of PW.


Model Group 2

EC 379808 06Mar81	PN 2676223	13 040f
EC 379606 20Apr81	2 of 2	




**HOW TO ADJUST THE CLOCK GRPS  
(continued)**

19. Connect the CH2 probe to 01A-A1G2B45 (GRP11 ODD CLOCK).
20. Set the DM44 Δ TIME control to display approximately 0300.
21. Vary the DM44 Δ TIME control until the falling edges of both pulses cross the horizontal center line at the same point (see the example on this page).  
If the DM44 display is between 0292 and 0308, go to step 23.
22. If the DM44 digital display is less than 0292, increase the PW value of the GRP being probed and repeat step 21.  
If the DM44 digital display is greater than 0308, decrease the PW value of the GRP being probed and repeat step 21.
23. Set the DM44 Δ TIME control to display approximately 0515.
24. Vary the DM44 Δ TIME control until the CH2 rising edge and the CH1 falling edge cross the horizontal center line at the same point (see the example on this page).  
If the DM44 digital display is between 0507 and 0523, record the DL and PW values (see "Odd Clock Group Test Points") and go to step 26.
25. If the DM44 digital display is less than 0507, increase by one the DL value of the GRP being probed, and repeat step 24.  
If the DM44 digital display is greater than 0523, decrease by one the DL value of the GRP being probed, and repeat step 24.
26. Connect the CH2 probe to the next GRP (see "Odd Clock Group Test Points") and repeat steps 20 through 25. Do this for all the remaining GRPs in the odd clock group.



How To Adjust the Clock GRPs - Step 21.



How To Adjust the Clock GRPs - Step 24.

NOTES:  
PW = Falling edge CH1 to falling edge CH2 (0292 to 0308)  
DL = Falling edge CH1 to rising edge CH2 (0507 to 0523)

GRP Numbers	CH2 Probe Points	Old Values		New Values *	
		DL	PW	DL	PW
11	01A-A1 G2B45				
23	↑ N2B24				
25	Q2A11				
26	R2B05				
31	C2A14				
32	G2B19				
51	↓ G2B21				
52	01A-A1 B2B36				
14	01A-B1 E2C42				
21	↑ E2D53				
22	E2A51				
24	K2B11				
45	U2D59				
55	N2A56				
61	↓ M2B56				
62	01A-B1 P2C23				

ODD CLOCK GROUP TEST POINTS (used in steps 19-26)

\* For groups 11 and 12, the value of PW (pulse width) must be greater than or equal to the value of DL (delay).

For groups 13 through 64 the value of DL must be greater than or equal to the value of PW.

## DISKETTE CLOCK VALUE UPDATE

This procedure describes the method to update the FUNCT and DIAG4 diskettes with the new values.

**Note:** *This procedure is valid only after the clock adjust procedure has been done.*

1. Key in QVU22UPDATE and press ENTER.
2. Copy the screen and keep for future reference.
3. Exchange the FUNCT diskette with the DIAG4 diskette.  
**Note:** *Only the FUNCT, backup FUNCT, and DIAG4 diskettes have the clock values stored on them.*
4. Key in QVU22UPDATE and press ENTER.
5. Key in QCM and press ENTER.
6. Key in QVW2B and press ENTER.
7. Key in QVY22 and press ENTER.
8. Compare the values now displayed with the values saved in step 2. Also compare these values with those recorded in the Even and Odd Clock Group Test Point tables (obtained during the clock adjustment procedure). If the values are the same, key in QCM and press ENTER.
9. If the values in step 8 are not the same, determine which diskette is incorrectly updated and correct it.
10. Exchange the DIAG4 diskette with the backup FUNCT diskette and repeat steps 4 to 9.

## CLOCK ADJUSTMENT TEST

After adjusting the clock, run the clock basic diagnostics and then the MSMDs.

### Clock Basic Diagnostics Run Procedure

1. Install the DIAG1 diskette.
2. Press and hold the ALT key, and press the DIAG key.
3. Select the B option [SELECTED DIAGNOSTIC(S) MODE] from the Diagnostic Mode General Selection screen.
4. When the system responds with ENTER TEST NAME(S), key in test ID: D120-D1F8 and press ENTER.

### MSMD Run Procedure

1. Install the DIAG4 Diskette.
2. Press and hold the ALT key, and press the DIAG key.
3. Select the G option (RUNALL MSMDs) from the Diagnostic Mode General Selection screen and press ENTER.

Model Group 2

EC 379606 20Apr81	PN 2676224	13 050f
EC 379837 28Jun82	2 of 2	

# SERVICE AIDS

## CONTENTS

Preventive Maintenance .....	14 003	<b>Channel Service Aids</b> .....	14 205	<b>Remote Support Facility Service Aids</b> .....	14 505
System Configuration .....	14 015	Interface Control Check Log Description .....	14 205	Remote Data Bank Invoke Procedure .....	14 505
Module Transfer .....	14 025	Catalog Numbers .....	14 210	Introduction .....	14 505
<b>UCW Assignment Procedure</b> .....	14 035	Loop Procedure for TIO/SIO .....	14 215	Remote Support Facility Keys .....	14 505
UCW Update Procedure .....	14 035	Interface Control Check (IFCC) Save Blocks .....	14 220	Data Bank Mode .....	14 505
UCW/Device Directory .....	14 035	IFCC Save Block (A) Description .....	14 220	Data Bank Invoke Procedures .....	14 505
Directory Update .....	14 040	IFCC Save Block (B) Description .....	14 220	Data Bank Operations .....	14 505
UCW Compressed Directories Display .....	14 045	Interface Control Check (IFCC) Trace .....	14 223	Data Bank Disconnect Procedures .....	14 505
UCW Expanded Directories Display .....	14 045	IFCC Trace Example .....	14 223	Data Bank Mode Restrictions .....	14 505
UCW Type Assignment Table .....	14 051	How to Use the IFCC Trace .....	14 223	Remote Console Support .....	14 505
<b>Diskette EC Update Procedure</b> .....	14 075	IFCC Catalog Numbers and Descriptions .....	14 223	Remote Support Facility (RSF) Diagnostics .....	14 515
<b>Diskette Recovery Procedure</b> .....	14 079	Channel Failure Isolation .....	14 224	EIA Adapter Test (Cable Part 8482930) .....	14 515
<b>Diskette Data Recover Procedure</b> (for Two Damaged FUNCT Diskettes) .....	14 081	Interface Adapter (IFA) Card .....	14 225	RSF Cards and Wiring Configurations .....	14 525
<b>EREP (Failing Storage Address)</b> .....	14 095	TIO Single-Cycle Procedure .....	14 225	38LS/U.S.A. and Canada Configuration .....	14 525
<b>01A Gate-Card Layout</b> .....	14 105	Procedure to Single Cycle TIO .....	14 225	38LS/Japan Configuration .....	14 535
<b>Board Signal Levels</b> .....	14 111	Channel Local Storage Layout (QVALn) or (QDLn) .....	14 230	Line Plate Configuration .....	14 545
<b>Logic Board Pin Numbering</b> .....	14 113	Limited Channel Logout (LCL) Bit Definitions .....	14 235	EIA Adapter Configuration (Cable Part 8482930) .....	14 555
<b>Processing Unit Service Aids</b> .....	14 115	Connect External Interrupt Cable .....	14 241	EIA Adapter Configuration (Cable Part 8482933) .....	14 556
Intermittent or Soft Errors .....	14 115	<b>MSS Service Aids</b> .....	14 305	Protective Coupler Configuration .....	14 565
<b>Metering Service Procedure</b> .....	14 120	Logic Reset .....	14 305	<b>Console Functions Service Aids</b> .....	14 605
		Serial Number Card .....	14 310	Patch Installation and Update Procedure .....	14 605
		OCP to HWS Interconnections .....	14 315	Automatic Patch Installation .....	14 611
		OCP to CTCA Interconnections .....	14 317	Manual Patch Installation .....	14 612
		Burst Mode Control .....	14 320	I/O and Channel Trace Procedure .....	14 615
		Basic Check Light .....	14 325	I/O and Channel Trace Example .....	14 617
		<b>Power Service Aids</b> .....	14 405	Screen Copy Options .....	14 625
		Power ALD Example .....	14 405	Copy Key Options .....	14 628
		Standard Power Interface (SPI) .....	14 425	Display Screen Print (DSP) Function .....	14 628
				CE Logs .....	14 635
				Saved Screens (QEW) .....	14 635
				How to Use CE Logs .....	14 635
				Displaying CE Log Titles .....	14 635
				Displaying CE Logs .....	14 635
				Making a New CE Log Entry .....	14 635
				Editing an Existing CE Log .....	14 635
				Erasing CE Log and Save Screen .....	14 635
				Printing CE Logs .....	14 640
				<b>Grounding Paths</b> .....	14 705
				Grounding, Model Group 2, Frame 01 .....	14 705
				Grounding, Model Group 2, Frame 02 (Ferro) .....	14 715
				Grounding, Model Groups 1 and 2, Frame 03 .....	14 725
				Grounding, Model Group 2, Frame 02 (Switching Regs) .....	14 735
				<b>Problem Analysis (PA)</b> .....	14 805



## PREVENTIVE MAINTENANCE

Item	Preventive Maintenance	Frequency
Filters	Examine the filters for dust accumulation and vacuum as necessary. Replace filters that do not pass light after vacuuming.	12 months or less as the environment requires

Filters are located on the inside of the front and rear covers of frame 01, 02, and 03.

Frame 01      four filters  
Frame 02      two filters  
Frame 03      two filters

Filter part 8483343

Spring part 307984



VOLUME 1

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
SEQ001	5666444						
SEQ005	5666445						
SEQ011A		5666446					
SEQ011B			5666454				
SEQ011C				2676000			
SEQ011D						2676001	
SEQ1T1	5666246						
SEQ1T2	5666247						
SEQ1T3	5666248						
SEQ101E							8632900
SEQ101F					2676460		
SEQ102E							8632901
SEQ102F					2676461		
SEQ103E							d8632902
SEQ104E							d8632903
SEQ2T0	5666249						
SEQ202	8633136						
SEQ205	8632905						
SEQ207	8632925						
SEQ210	8632906						
SEQ211	8633137						
SEQ212	8632927						
SEQ214	8632917						
SEQ220	8632908						
SEQ230	8632907						
SEQ231	8633138						
SEQ232	8632991						
SEQ233	8632992						
SEQ234	8632993						
SEQ235	8632994						
SEQ237	8632914						
SEQ238	8632915						
SEQ239	8632926						
SEQ241	8632995						
SEQ242	8632996						
SEQ243	8632997						
SEQ244	8632998						
SEQ245	8632959						
SEQ246	8633140						
SEQ250	8632922						
SEQ255	8632923						
SEQ260	8632960						
SEQ290	5666226						

VOLUME 2

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
SEQ3AA	5666447						
SEQ3T0	5666250						
SEQ304A		8633008					
SEQ304B			4109271				
SEQ304C				2676016			
SEQ304D						2676055	
SEQ306A		8633009					
SEQ306B			4109272				
SEQ306C				2676017			
SEQ306D						2676056	
SEQ308A		8633010					
SEQ308B			4109273				
SEQ308C				2676018			
SEQ308D						2676057	
SEQ309D						2676058	
SEQ310	8632952						
SEQ311D						2676059	
SEQ314A		8632931					
SEQ314B			4109274				
SEQ314C				2676019			
SEQ315C				2676020			
SEQ316A		8632932					
SEQ316B			4109275				
SEQ316C				2676021			
SEQ316D						2676060	
SEQ317D						2676061	
SEQ318A		8632933					
SEQ318B			4109276				
SEQ318C				2676022			
SEQ318D						2676062	
SEQ320A		8632934					
SEQ320B			4109277				

Model Groups 1 and 2

EC 379605 06Mar81	PN 5666406	14 005
EC 379607 05Jun81	1 of 2	

VOLUME 2 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
SEQ320C				2676023			
SEQ320D						2676063	
SEQ322A	8632935						
SEQ322B			4109278				
SEQ322C				2676024			
SEQ322D						2676064	
SEQ324A	8632936						
SEQ324B			4109279				
SEQ324C				2676025			
SEQ324D						2676065	
SEQ326B			4109280				
SEQ328B			4109281				
SEQ330A	8632937						
SEQ330B			4109282				
SEQ330C				2676026			
SEQ331C				2676027			
SEQ332B			4109283				
SEQ332C				2676028			
SEQ333A	8632938						
SEQ333C				2676029			
SEQ334B			4109284				
SEQ334C				2676030			
SEQ336A	8632939						
SEQ336B			4109285				
SEQ336C				2676031			
SEQ336D						2676066	
SEQ338B			4109286				
SEQ339A	8632940						
SEQ339C				2676032			
SEQ339D						2676067	
SEQ340B			4109287				
SEQ340C				2676033			
SEQ342A	8632941						
SEQ342B			4109288				
SEQ342C				2676034			

VOLUME 2 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
SEQ342D						2676068	
SEQ344B			4109289				
SEQ346A		8632942					
SEQ346B			4109290				
SEQ346C				2676035			
SEQ346D						2676069	
SEQ348A		8632943					
SEQ348B			4109291				
SEQ348C				2676036			
SEQ348D						2676070	
SEQ350A		8632944					
SEQ350B			4109292				
SEQ350C				2676037			
SEQ350D						2676071	
SEQ351D						2676072	
SEQ352A		8632945					
SEQ352C				2676038			
SEQ352D						2676073	
SEQ354B			4109293				
SEQ356A		8633011					
SEQ356B			4109294				
SEQ356C				2676039			
SEQ356D						2676074	
SEQ358A		8632947					
SEQ358C				2676040			
SEQ360A		8632948					
SEQ360B			4109295				
SEQ360C				2676041			
SEQ362A		8632949					
SEQ362C				2676042			
SEQ363C				2676043			
SEQ364A		8632950					
SEQ364B			4109296				

Model Groups 1 and 2

EC 379605 06Mar81	PN 5666406	14 006
EC 379607 05Jun81	2 of 2	



VOLUME 2 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
SEQ364C				2676044			
SEQ364D						d2676075	
SEQ365C				2676045			
SEQ366A		8632951					
SEQ366B			4109297				
SEQ366C				2676046			
SEQ366D						2676076	
SEQ370	8632978						
SEQ372	8633141						
SEQ376	8633142						
SEQ378	8633143						
SEQ380	8633144						
SEQ384	8633145						
SEQ386	8633146						
SEQ388	8633147						
SEQ390	8633148						
SEQ392	8633149						
SEQ395	8632953						
SEQ398	4109240						

VOLUME 3

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
SEQ4AA	5666448						
SEQ4TO	5666251						
SEQ400E							2676098
SEQ400F					2676080		
SEQ460C					d2676081		
SEQ460D						d2676084	
SEQ460E							2676096
SEQ461E							2676097
SEQ470B				d4109216			
SEQ471B				d4109217			
SEQ480A		d8632955					
SEQ480C					d2676083		
SEQ480D							
SEQ481A						d2676085	
SEQ5TO	5666252						
SEQ500A		d8632956					
SEQ500B							
SEQ501A				d4109212			
SEQ501B							
SEQ502A				d4109213			
SEQ502B							
SEQ503E							8632963
SEQ503F					2676082		
SEQ504A		d8632958					
SEQ504B							
SEQ504E							2676099
SEQ504F					2676086		
SEQ505E							8632962
SEQ505F					2676087		
SEQ506E							d4109214
SEQ511E							4109219
SEQ511F					2676088		

Model Groups 1 and 2

EC 379605 06Mar81	PN 5666407	14 007
EC 379607 05Jun81	1 of 2	

VOLUME 3 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
SEQ600E							8632965
SEQ600F					2676089		
SEQ606E							4109218
SEQ606F					2676090		
SEQ8T0	5666253						
SEQ801E							8632966
SEQ801F					2676091		
SEQ802E							8632969
SEQ802F					2676092		
SEQ803E							8632970
SEQ803F					2676093		
SEQ9T0	5666254						
SEQ901E							8632972
SEQ901F					2676473		
SEQ901B			d2676470				
SEQ902A		d8632973					
SEQ902B			d2676471				
SEQ903A		d8632981					
SEQ903B			d2676472				
SEQ904	8632982						
SEQ906	8632976						
SEQ907	8632977						

VOLUME 13

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
10 00T	5666255						
10 005	5666449						
10 015	5666450						
10 025	5666239						
10 035a		5666240					
10 035b			5666236				
10 035c				2676200			
10 035d						2676231	
10 045a		5666241					
10 045b			5666237				
10 045c				2676201			
10 045d						2676232	
10 055a		5666242					
10 055b			5666238				
10 055c				2676202			
10 055d						2676233	
10 061	5666230						
10 065	5666243						
10 075	5666224						
11 00T	5666256						
11 005	5666283						
11 015	5666284						
11 025	5666285						
12 00T	5666257						
12 005a		5666286					
12 005b			5666274				
12 005c				2676210			
12 005d						2676213	
12 015	5666287						
12 025	5666288						
12 035	5666289						
12 035b			d5666426				
12 043a		5666245					
12 043b			5666233				
12 043c				2676211			
12 043d						2676214	
12 045	5666290						
12 055	5666291						
12 057d						2676215	

Model Groups 1 and 2

EC 379605 06Mar81	PN 5666407	14 008
EC 379607 05Jun81	2 of 2	

VOLUME 13 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
12 063d						2676216	
12 065a		5666292					
12 065b			5666234				
12 065c				2676227			
12 069d						2676217	
12 075a		5666293					
12 075b			5666235				
12 075c				2676228			
12 075d						2676218	
12 081d						2676219	
12 085	5666294						
12 095b			5666427				
12 095c				2676212			
13 00T	5666258						
13 005b			d5666331				
13 005e						5666276	
13 005f					2676220		
13 015b			d5666422				
13 015e						5666277	
13 015f					2676221		
13 025b			d5666423				
13 025e						5666278	
13 025f					2676222		
13 035b			d5666424				
13 035e						5666279	
13 035f					2676223		
13 045b			d5666442				
13 045e						5666280	
13 045f					2676224		
13 055b			d5666443				
13 055e						d5666281	
13 055f					d2676225		
13 065b			d5666458				
13 065e						d5666282	
13 065f					d2676226		

VOLUME 13 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
14 00T	5666259						
14 001	5666334						
14 003	5666432						
14 005	5666406						
14 007	5666407						
14 009	5666408						
14 011	5666409						
14 013	5666410						
14 015e							5666431
14 015f					2676235		
14 025e							5666335
14 025f					2676418		
14 035	5666336						
14 065	d5666340						
14 075	5666337						
14 079	5666338						
14 081	5666339						
14 095	5666348						
14 105a		5666228					
14 105b			5666229				
14 105f					2676260		
14 105d						d2676234	
14 115	5666341						
14 205	5666342						
14 215	5666343						
14 223	2676247						
14 225	5666344						
14 235	5666345						
14 241	5666419						

Model Groups 1 and 2

EC 379606 20Apr81	PN 5666408	14 009
EC 379607 05Jun81	1 of 2	

VOLUME 13 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
14 305	5666346						
14 325	d5666349						
14 325	2676246						
14 335	d5666418						
14 405	5666347						
14 425	5666433						
14 505	5666412						
14 515	5666413						
14 525	5666414						
14 535	5666515						
14 545	5666416						
14 555	5666417						
14 565	2676261						
14 605e						2676229	
14 605f					2676262		
14 615	2676230						
14 619	2676263						
14 625	2676248						
14 635e						2676419	
14 635f					2676420		
14 705	2676236						
14 715	2676237						
14 725	2676238						
15 00T	5666260						
15 005	5666159						

VOLUME 16

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
16 00T	5666261						
20 005	5666160						
20 015	5666161						
20 025a		5666162					
20 025b			5666208				
20 025c				2676300			
20 025d						2676330	
20 035a		5666163					
20 035b			5666405				
20 035c				2676318			
20 035d						2676331	
20 045	5666164						
20 055a		5666165					
20 055b			5666411				
20 055c				2676319			
20 055d						2676332	
20 065	5666166						
20 075a		5666167					
20 075b			5666209				
20 075c				2676314			
20 075d						2676333	
20 085a		5666168					
20 085b			5666210				
20 085c				2676301			
20 085d						2676334	
20 095a		5666169					
20 095b			5666211				
20 095c				2676302			
20 095d						2676335	
20 105a		5666170					
20 105b			5666212				
20 105c				2676303			
20 105d						2676336	
20 115	5666171						
20 125	5666172						
20 135	5666173						
20 145	5666174						

Model Groups 1 and 2

EC 379606 20Apr81	PN 5666408	14 010
EC 379607 05Jun81	2 of 2	

VOLUME 16 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
20 155a		5666175					
20 155b			5666213				
20 155c				2676304			
20 155d						2676337	
20 165a		5666176					
20 165b			5666214				
20 165c				2676305			
20 165d						2676338	
20 175a		5666177					
20 175b			5666421				
20 175c				2676320			
20 175d						2676339	
20 185a		5666178					
20 185b			5666215				
20 185c				2676306			
20 185d						2676340	
20 191b			5666216				
20 191c				2676307			
20 195a		5666179					
20 195b			5666217				
20 195c				2676308			
20 195d						2676341	
20 205a		5666180					
20 205b			5666218				
20 205c				2676309			
20 205d						2676342	
20 211a		5666201					
20 211b			5666219				
20 211c				2676315			
20 211d						2676343	
20 215a		5666181					
20 215b			5666220				
20 215c				2676310			
20 215d						2676344	
20 225a		5666182					
20 225b			5666221				

VOLUME 16 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
20 225c				2676311			
20 225d						2676345	
20 235a		5666183					
20 235b			5666222				
20 235c				2676316			
20 235d						2676346	
20 241a		5666203					
20 241b			5666204				
20 241c				2676322			
20 241d						2676351	
20 245a		5666184					
20 245b			5666223				
20 245c				2676312			
20 245d						2676347	
20 255	5666185						
20 265	5666186						
20 275	5666187						
20 285	5666188						
20 295	5666189						
20 305	5666190						
20 315	5666191						
20 325	5666192						
20 335a		5666193					
20 335b			5666244				
20 335c				2676317			
20 335d						2676348	
20 345	5666194						
20 355	5666195						
20 365	5666196						
20 375	5666197						
20 385a		5666198					
20 385b			5666225				
20 385c				2676313			
20 385d						2676349	
20 395	5666199						
20 405	5666200						
20 415a		5666202					
20 415b			5666227				
20 415c				2676321			
20 415d						2676350	

Model Groups 1 and 2

EC 379605 06Mar81	PN 5666409	14 011
EC 379607 05Jun81	1 of 2	

VOLUME 17

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
30 005	5666451						
30 015	5666452						
30 025	5666231						
32 00T	5666262						
32 005	5666232						
32 005b			d5666428				
34 00T	5666263						
34 005	5666295						
34 025a		5666296					
34 025b			5666271				
34 025c				2676400			
34 025d					2676403		
34 055a		5666297					
34 055b			5666429				
34 055f				2676401			
34 055d					d2676404		
34 075	5666298						
34 105	5666299						
36 00T	5666264						
36 005	5666300						
36 015	5666301						
36 015b			d5666310				
36 025e					5666302		
36 025f				2676406			
36 035e					5666303		
36 035f				2676407			
36 045	5666304						
36 045b			d5666311				
36 055	5666305						
36 065a		5666306					
36 065b			5666312				
36 065c				2676402			
36 065d					2676405		
36 075	5666307						

VOLUME 17 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
36 085	5666308						
36 095	5666309						
38 00T	5666265						
38 005	5666313						
38 015	5666314						
38 025	5666315						
38 035	5666316						
38 045	5666317						
40 00T	5666266						
40 005	5666320						
40 015e							5666321
40 015f					2676408		
40 025	5666322						
40 035	5666323						
40 055	5666324						
40 085	5666325						
40 095	5666326						
40 105	5666327						
40 115	5666328						
40 145	5666329						
40 175	5666330						
42 00T	5666267						
42 005	5666332						
42 075e							5666333
42 075f					2676352		

Model Groups 1 and 2

EC 379605 06Mar81	PN 5666409	14 012
EC 379607 05Jun81	2 of 2	

VOLUME 18

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
44 005	5666453						
44 01T	5666268						
44 015e							5666350
44 015f				2676421			
44 025	5666351						
44 035	5666352						
44 045	5666353						
44 051	2676422						
44 055	5666354						
44 071	2676423						
44 075	5666355						
44 085	5666356						
44 115	5666358						
44 125	d5666359						
44 135	5666360						
44 155	5666361						
44 165	5666362						
44 175	5666363						
44 185e							5666364
44 185f				2676455			
44 187	2676425						
44 191e							2676417
44 191f				2676456			
44 195e							5666365
44 195f				2676457			
44 215e							5666366
44 215f				5666357			
44 235e							5666367
44 235f				2676459			
44 245e							5666368
44 255	5666369						
44 265	5666370						
44 275e							5666371
44 275f				5666399			
44 285	5666372						
44 295e							5666373
44 295f				2676409			
44 305e							5666374
44 305f				2676355			
44 315e							5666375
44 315f				2676430			
44 325	5666376						
44 329e							2676432
44 329f				2676431			

VOLUME 18 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
44 335	5666377						
44 345	5666378						
44 355	5666379						
44 365	5666380						
44 375	5666381						
44 395e							5666382
44 395f					2676433		
44 403					2676434		
44 405	5666383						
44 407					2676435		
44 409	2676436						
44 413					2676437		
44 415	5666384						
44 417					2676438		
44 425e							5666385
44 425f					2676410		
44 427					2676440		
44 429	2676441						
44 435	5666386						
44 443					2676442		
44 445	5666387						
44 449e							2676444
44 449f					2676443		
44 453e							2676445
44 453f					5666205		
44 457e							2676447
44 457f					2676446		
44 463e							2676448
44 463f					5666206		
44 495	5666388						
44 501e							2676450
44 501f					2676449		
44 515e							5666389
44 515f					2676427		
44 517					2676451		
44 519	2676452						
44 521e							5666390
44 521f					2676453		
44 525e							2676411
44 525f					2676412		
44 535	5666391						
44 545e							5666392
44 545f					2676413		

Model Groups 1 and 2

EC 379605 06Mar81	PN 5666410	14 013
EC 379607 05Jun81	1 of 2	

VOLUME 18 (Continued)

Page Number	B/M 4432864	B/M 4432845	B/M 4432846	B/M 4154511	B/M 4230664	B/M 4154512	B/M 4230699
44 555e							5666393
44 555f					2676414		
44 565e							5666394
44 565f					2676415		
44 575e							5666395
44 575f					2676458		
44 585	5666396						
44 595	5666397						
44 605	5666398						
44 607e							2676454
44 607f					2676428		
44 615	5666400						
44 635e							5666401
44 635f					2676424		
44 655e							5666402
44 655f					2676426		
44 675e							5666403
44 675f					2676429		
44 695e							5666404
44 695f					2676416		
46 00T	5666269						
46 005	5666420						
46 005b			d5666434				
48 00T	5666270						
48 005	5666435						
48 015	5666436						
48 025a		5666437					
48 025b			5666455				
48 025c				2676480			
48 025d						2676496	
48 035a		5666438					
48 035b			5666456				
48 035c				2676481			
48 035d						2676497	
48 045a		5666439					
48 045b			5666457				
48 045c				2676482			
48 047d						2676498	
48 049b			2676491				
48 049c				2676483			
48 051	2676490						
48 055	5666440						
48 065	5666441						
49 005	5666425						

Model Groups 1 and 2

EC 379605 06Mar81	PN 5666410	14 014
EC 379607 05Jun81	2 of 2	



## SYSTEM CONFIGURATION (QFS)

The System Configuration screen is a CE-only function. To invoke this screen, the 4341 must be in CE mode. This screen can be selected from the Configuration screen or fast-selected from the General Selection screen.

Changes are made by entering the required data, or by using the cursor. The use requirements are restrictive to prevent errors. Be careful when updating the configuration record. Fields displaying a colon (:) on the screen are alterable.

The configuration record is stored on the system diskette and is updated each time a change is made. A support processor re-IML must be performed any time a change is made to the configuration record or if the diskette is changed.

To select the System Configuration screen from the Configuration screen:

1. Place the CE MODE switch ON.
2. Key S next to F on the SELECTION line.
3. Press ENTER. System Configuration screen is displayed.

To update the configuration record:

**Note:** The following sections apply to the areas which can be altered.

**Serial No.:** Move the cursor to the value displayed on the screen for SERIAL NO. and key in the machine serial number. When the entered serial number is verified, key in next to SELECTION:SLOCKSERNUM  
Press ENTER.

The serial number is now locked, and the lock serial number message is no longer displayed on the screen.

**Note:** The serial number update is a one-time occurrence. When entered, it becomes an unalterable field. It is important that the entered serial number be verified.

**Power Logic:** Move the cursor to the value displayed on the screen for POWER LOGIC, and key in the EC number of the power EC just installed.  
Press ENTER.

**Main Store Size:** Move the cursor to the value displayed on the screen for MAIN STORE SIZE, and key in the two-digit number representing the size of main storage.  
Press ENTER.

**Control Store Size:** Move the cursor to the value displayed on the screen for CONTROL STORE SIZE, and key in the two-digit number representing the size of control storage.  
Press ENTER.

```

*SYSTEM CONFIGURATION*

MODEL 4341
SERIAL NO.: 000000
DISKETTE PART NO. 0000000
EC 000000
REA 0000000

POWER LOGIC: 000000

MAIN STORE SIZE: 04 MEG
CONTROL STORE SIZE: 64 KB

LOCKSERNUM - LOCK SERIAL NUMBER

Q GENERAL SELECTION
Z RETURN TO PROG SYS

SELECTION: S

CONSOLE DEVICES
NO N1 N2 N3
INSTALLED: X X X X
OPERATIONAL X X - X
HARDCOPY: - - X

CONSOLE LANGUAGE CODE: 00
ROCF AUTO-ANSWER MODEM: -

NUMBER OF CHANNELS: 06
CHANNEL 4 IN BYTE MODE: -

CHANNEL TO CHANNEL:
I/O POWER-UP TIME-OUT: 02 MINS
POWER GROUP: 00

==>

4341
    
```

**Console Devices Installed:** Move the cursor to the location on the screen for CONSOLE DEVICES INSTALLED, and key in an X if installed or an \_ if not installed. No device should be assigned unless it is installed.

Operational field is for information only; it is not alterable.

**Hardcopy:** Move the cursor to the location on the screen for HARDCOPY, and key in an X if a printer is installed and is to be flagged as a hard-copy device, or an \_ if it is not installed. A hard-copy device can be console device one through three.  
Press ENTER.

**Console Language Code:** Move the cursor to the value displayed on the screen for CONSOLE LANGUAGE CODE, and key in one of the following values:

- 00 U.S. English
- 00 Canadian/French (See Note)
- 01 Austria/German
- 02 Belgium
- 03 Brazil/Portuguese
- 04 Denmark
- 05 Finland
- 06 France/Azerty
- 07 France/Qwerty
- 08 International
- 09 Italy
- 0A Japan/English
- 0B Norway
- 0C Portugal
- 0D Spain
- 0E Spanish Speaking
- 0F United Kingdom
- 10 Sweden
- 11 EBCDIC/World Trade

Press ENTER.

**Note:** The Canadian/French keyboard has the same character set and keyboard layout as the U.S. English, but with French nomenclature on the keys.

**ROCF Auto-Ans Modem:** Move the cursor to the location on the screen displaying ROCF AUTO-ANS MODEM: and key in an X when an ROCF Auto-Ans modem is installed, or an \_ if it is not installed.  
Press ENTER.

**Number of Channels:** Move the cursor to the location on the screen displaying NUMBER OF CHANNELS: and key in the two-digit number representing the number of channels.  
Press ENTER.

**Channel 4 in Byte Mode:** Move the cursor to the location on the screen displaying CHANNEL 4 IN BYTE MODE: and key in an X if channel 4 is to be used as a byte-multiplexer channel, or an \_ if it is to be used as a block-multiplexer channel. This selection is valid only when the processor has been configured for six channels.  
Press ENTER.

**Note:** Always check the Display/Alter UCW Directory (QDU) to verify the assignment.

**Channel to Channel:** Move the cursor to the value displayed on the screen for CHANNEL TO CHANNEL, and key an X next to it for desired assignment, or an \_ if the existing value is to be deleted.  
Press ENTER.

**I/O Power-Up Time-Out:** Move the cursor to the value on the screen for I/O POWER-UP TIME-OUT, and key in the number of minutes (in decimal) that the power code waits for the channel I/O devices attached to the power sequencing relays to power up. (If I/O stepping is not complete in the specified time, the machine posts a reference code.)  
Press ENTER.

### Power Group:

**Note:** Using the Feature BM machine history, determine what Documentation BM is associated with the 4341. The charts on the following page indicate which Power Group Code matches the machine configuration.

Move the cursor to the value displayed on the screen for POWER GROUP code, and key in the correct code.

Press ENTER.

### Return to General Selection (Q)

1. Key Q next to SELECTION.
2. Press ENTER.

### Return to Prog Sys (Z)

1. Key Z next to SELECTION.
2. Press ENTER.

### Model Group 2

EC 379827 02Oct81	PN 2676235	14 015f
EC 379829 28Jun82	1 of 2	

BM	Feature Title	Power Group Code
4154511 and one of the following: 5896667  or 4124111  or 4124101	First Source Storage with Ferro Power Supplies:  First Source 2 Meg (.5 Meg Card) Storage Group  First Source 4 Meg (.5 Meg Card) Storage Group  First Source 8 Meg (.5 Meg Card) Storage Group	21
4154512 and one of the following: 5896667  or 4124111  or 4124101	First Source Storage with Switching Regulators:  First Source 2 Meg (.5 Meg Card) Storage Group  First Source 4 Meg (.5 Meg Card) Storage Group  First Source 8 Meg (.5 Meg Card) Storage Group	22
4154511 and one of the following: 4154406  or 4154407  or 4154408  or 4154409	First Source Storage with Ferro Power Supplies:  First Source 4 Meg (1.0 Meg Card) Storage Group  First Source 8 Meg (1.0 Meg Card) Storage Group  First Source 12 Meg (1.0 Meg Card) Storage Group  First Source 16 Meg (1.0 Meg Card) Storage Group	23
4154512 and one of the following: 4154406  or 4154407  or 4154408  or 4154409	First Source Storage with Switching Regulators:  First Source 4 Meg (1.0 Meg Card) Storage Group  First Source 8 Meg (1.0 Meg Card) Storage Group  First Source 12 Meg (1.0 Meg Card) Storage Group  First Source 16 Meg (1.0 Meg Card) Storage Group	24

4341 Model Group 2

Model Group 2

EC 379827 02Oct81	PN 2676235	14 016f
EC 379829 28Jun82	2 of 2	

## MODULE TRANSFER (QFM)

The Module Transfer screen moves the machine-dependent data module from one support processor diskette to another. When the EC is ready to be installed, take a stock EC disk to be updated with the data from the disk already there. The new disk then is unique for this particular system. Patches and Assists can not be transferred by the Module Transfer screen.

The Module Transfer screen has two different input areas: the first is the area to the left of the module of MACHINE SENSITIVE DATA, and the other is for entering instruction type on the SELECTION line. The first area of input is on the full-screen area. The only inputs that are valid are "X" or "\_" (or blanks). For any other input, an INVALID message appears. The second area of input is through the normal manual function input that is on the SELECTION line. These commands are displayed on the screen.

The module IDs are shown for each line and are taken from the disk that contains the Module Transfer CODE. If the two disks do not have the same module IDs, the transfer does not occur.

The first selection is special in that only part of the total module shown is transferred. For the configuration data, the information unique to a disk (such as part number and EC number) is not transferred. For the reset data, only those bits that are machine sensitive are transferred to the reset data module.

The Status Area of the Module Transfer screen shows the current status of the transfer taking place. The status area has four positions. The first shows the state of the transfer: S - selected for transfer; R - read from the disk and store either in main storage or in the support processor buffer; W - write on the disk from the storage area; T - the module has been transferred completely. The second through fourth positions show any error that has occurred during a read or write portion of the transfer. The "D" is followed by an error indication.

To invoke the Module Transfer screen:

**Warning: Do not press the Copy key during a Module Transfer; the transfer is not completed. If a transfer is desired, rekey the previous command.**

1. Place the CE MODE switch ON if you have not already done so. If you have not, you must select the Configuration screen first.
2. Key M on the SELECTION line.
3. Press ENTER.
4. After the Module Transfer screen is displayed, move the cursor to the module(s) that you do not want to transfer and place an \_ next to that module. Ensure that an X is next to the module(s) that you do want transferred.
5. Press ENTER. The status area displays an S beside those modules which you have selected.

**Note: If an error occurs, INVP is displayed instead of S.**

```

*MODULE TRANSFER SCREEN*
STATUS  MACHINE SENSITIVE DATA (MODULE)
X CLOCKS, IPU, STORE, CS .(8001-8004)
  CONFIGURATION, UCWS .(0001,20A0)
X POWER/TEMP LOGS . . .(1024,1026)
X PU LOG CONTROL 1,2 .(3050,3501)
X PU LOGS 1-9 . . . .(3061-3069)
X SP LOGS . . . . .(3800)
X REFERENCE CODES . . .(3900)
X PROBLEM ANALYSIS DATA(2806-2808)
X SAVED SCREENS/CE LOGS(9BXX)

ERR MODS:

STATUS INFO: S=SELECT R=READ & SAVE W=RETRIEVE & WRITE T=TRANSFER COMPLETE
             DSZ=SIZE DIFFERENT DLA=LOAD ADDRESS DIFFERENT D41=NOT FOUND
             INVP=INVALID INPUT

COMMANDS: MSTARTL START DISK-PU-DISK TRANSFER      Q GENERAL SELECTION
           MSTARTD START DISK-SP-DISK TRANSFER      Z RETURN TO PROG SYS
SELECTION: M                                     ==> ALL LINES SELECTED

                                         4341
    
```

6. Key STARTL or STARTD next to the M on the SELECTION line, depending upon the type of transfer you wish to do.

STARTL requires the processing unit to have been IMLed but not IPLed.

**Warning: If the machine has been IPLed, a QCLEAR is required. However, a loss of customer data can result with this selection.**

If no error occurs, the code transfers modules from the disk to the processor main storage, and asks you to swap disks. After the disk has been swapped, the modules from the processor storage are transferred to the new disk. One disk swap transfers all modules. The request for the ORIGINAL disk indicates that the transfer is complete. If a support processor-processing unit interface error occurs, the process stops, and the transfer must be restarted.

STARTD only requires the support processor and uses a buffer of about 4K. If no selection errors occur, the code transfers modules from the disk to the buffer. You are then asked to swap the disks. The modules are then transferred from the buffer to the new disk. You are then asked to swap back to the old disk. The transfer then continues until all of the modules selected are transferred.

The transfer is completed regardless of the command used, size errors, or load address errors. However, the module in error is flagged as an error module and is not used again.

Once the transfer is started, the microcode asks for the FROM disk. This allows you to use a different disk for the FROM modules.

At the end of the transfer, you are asked to replace the ORIGINAL disk because the transfer routine is reloaded to set up for another pass (if one is required). This message indicates the end of the transfer. However, you can continue and use a different disk (either another FROM or another TO).

7. Press ENTER.

**Note: Always check the System Configuration (QFS), Program Load (QL), and the Display/Alter UCW (QDU) assignment to verify the transfer.**

## Status Area Codes

SZ = From/to modules a different size  
 LA = From/to modules have a different load address  
 01 = Zero length  
 02 = Error during transfer of engineering data  
 0F = Diskette not ready  
 21 = Past end-of-file  
 31 = Address length, memory protect error  
 41 = Module ID not found  
 4F = Write protect error  
 81 = Read error  
 82 = Adapter machine check  
 83 = UC machine check  
 8F = Cylinder index and master index different  
 9F = No current seek issued

## Notes:

- The status shows the last error encountered.
- When the ERR MODS area indicates 0001 (the status area displays WDSZ, and line 21 displays the message TRANSFER HALTED), a machine serial number mismatch exists between the FROM and the TO diskettes.



## UCW ASSIGNMENT

### General Information

A channel directs the flow of information between main storage and various types of I/O devices under the control of a channel facility, which functions independently of the processor program. This permits the processor program to resume processing after initiating an I/O operation.

The channel facility required to sustain a single I/O operation is called a *subchannel*. A subchannel requires internal storage, called a *Unit Control Word (UCW)*, for recording the addresses, count, and any status and control information.

For each device attached to the 4341, there is a device address and an associated UCW. This information is entered into a channel directory (one for each channel) which is stored in auxiliary storage. Each channel directory has 256 entries. Each device entered into the directory has an address specified by a channel designation (c) and a two-character unit designation (uu).

A channel directory entry contains:

- An indication whether or not a UCW is assigned to the associated device address (UNA = unassigned).
- The reference number (REF) of the UCW assigned.
- An indication whether the UCW is shared or unshared (SHR = shared).
- An indication whether the device associated with this entry can operate in selector (SEL), byte-multiplexer (BYT), block-multiplexer (BLK), or data streaming (DST) mode.

Directory information can be displayed by either the UCW Directory (QDUC) screen or the Expanded UCW Directory (QDUE) screen.

Each channel has a local storage area for processing a UCW. When an operation requires using the information in a UCW, that UCW is read from auxiliary storage into local storage. The operation specified by the subchannel is then performed, and the UCW is updated and returned to auxiliary storage. The UCW carries a running record of the operation for the I/O device assigned.

The UCW assignment process is critical to the efficient operation of the processor. Change information to the UCW Directory is provided by personnel responsible for system configuration. System programmers or system analysts configure the Input/Output devices and control units for optimum operation. Poor device assignments can affect processor performance. Reserve addresses for I/O equipment expected; early address definition provides easier installation and testing when these devices are installed.

```
*DISPLAY/ALTER*
G GENERAL REGISTERS
C CONTROL REGISTERS
F FLOATING POINT REGISTERS
P CURRENT PSW
K STORAGE KEY
V VIRTUAL STORAGE
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PRDG SYS
SELECTION: U

*UCW/DEVICE DIRECTORY TASKS*
U CHANGE UCW DIRECTORY
C DISPLAY UCW DIRECTORY
E DISPLAY EXPANDED UCW DIRECTORY

==>
4341
```

### UCW/Device Directory Tasks (QDU) Screen

### UCW Assignment Procedure

The following screens are used for the UCW Assignment procedure:

- UCW/Device Directory Tasks (QDU) - displays the options available to perform the UCW assignment or modification procedure.
- Change UCW Directory (QDUU) - is used to modify the UCW directory by adding or deleting UCW addresses, or to modify the type of UCW address in the directory.
- Display UCW Directory (QDUC) - is used to verify changes made while using the UCW Assignment procedure. Device addresses are displayed as assigned (for example: 301-305).
- Display Expanded UCW Directory (QDUE) - is used to verify changes made while using the UCW Assignment procedure. Device addresses are displayed individually. The Hex field is used by engineering.

To perform a UCW Assignment:

1. Press MODE SEL key. General Selection (Q) screen is displayed.
2. Key QDU next to SELECTION.
3. Press ENTER. UCW/Device Directory Tasks screen is displayed.

**Note:** From this screen, you can select the Change UCW Directory (QDUU) screen to modify the UCW Directory or select one of the directory (QDUC or QDUE) screens to verify any changes.

## Device Assignment

### Notes:

- Before making a UCW assignment, refer to the "UCW Assignment Table" for correct device information.
- The paging keys are not applicable for this function.
- If the characteristics of a device must be changed, first remove (unassign) the UCW for that device address, and then perform a new assignment with proper characteristics. See "Device Assignment Change."

To perform a UCW/Device assignment from the Change UCW Directory (QDUU) screen:

1. Key U next to SELECTION: U.
2. Press ENTER. Change UCW Directory screen is displayed.
3. Key the following next to UU on the SELECTION line:
  - a. CXX = Device address or beginning device address range.

### Notes:

- Sixteen addresses (0F0 through 0FF) are reserved for locally attached devices and for internal functions. To assign or unassign these devices, use the Program Load (QL) function.
- With three channels installed, the addresses can range from 000-2FF, and with six channels installed, from 000-5FF.
- If two ranges of shared UCW devices are adjacent, they must be assigned at different times (a different entry); otherwise, the same reference number is assigned to both ranges. However, for unshared devices, a range over many control units can be assigned at one time.

- b. -CYY = Ending device address range (optional).
- c. CHAR.CODE = Characteristic of the device(s) being assigned (device dependent).

### Notes:

- Any characteristic(s) required after the address replaces the default characteristic. The default assigns the device to a byte- or block-multiplexer UCW.
- The following characteristic codes can be assigned to the address(s):

CHAR.CODE	Display	Characteristic
L	SEL	Selector device on block-multiplexer channel
S	SHR	Shared UCW
D	DST	Data streaming mode
X	UNA	No device assigned or removes device

- An invalid channel configuration entry displays INV in the characteristics field.

```

*DISPLAY/ALTER*
G GENERAL REGISTERS
C CONTROL REGISTERS
F FLOATING POINT REGISTERS
P CURRENT PSW
K STORAGE KEY
V VIRTUAL STORAGE
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PROG SYS
SELECTION: UU 380-387 SL

*CHANGE UCW DIRECTORY*
FORMAT: CXX -CYY CHAR.CODES
        CXX = STARTING DEVICE ADDRESS
        -CYY = ENDING DEVICE ADDRESS (OPTIONAL)
CHANNEL: 0-BYTE  1-BLOCK  2-BLOCK
          3-BLOCK 4-BLOCK  5-BLOCK
CHAR.CODES (OPTIONAL, ANY ORDER)
S SHARED UCW
L SELECTOR MODE -BLOCK ONLY
D DATA STREAMING MODE -BLOCK ONLY
X REMOVE DEVICES

.ONE ENTRY MUST COVER ALL ADDR FOR ANY CTL UNIT
.PU-IML REQUIRED AFTER CHANGES -USE LOAD SCREEN
==>

4341

```

## Change UCW Directory (QDUU) Screen

4. Press ENTER. SELECTION COMPLETE message is displayed. Directory is updated and device(s) are assigned.
 

**Note:** The routine only changes the diskette holding the directories, not the UCWs in auxiliary storage. This requires a processor re-IML (QLM).
5. Key QLM next to SELECTION.
6. Press ENTER. A processor IML is performed and auxiliary storage is updated.
7. Update the backup diskette. For updating a diskette, see Volume 13/16, Section 14, "Module Transfer (QFM)."
8. Verify changes made by using the section titled "UCW Verification."

## Device Assignment Change

To change a device assignment from the Change UCW Directory (QDUU) screen:

1. Key U next to SELECTION: U.
2. Press ENTER. Change UCW Directory screen is displayed.
3. Key the following next to UU on the SELECTION line:
  - a. CXX = Device address or beginning device address range.
  - b. -CYY = Ending device address range (optional).
  - c. X = Characteristic code to remove (unassign) device(S).
4. Press ENTER. SELECTION COMPLETE message is displayed. Device(s) are removed (unassigned).
5. Perform the new UCW assignment. See "Device Assignment."

### Model Groups 1 and 2

EC 379814 02Oct81	PN 5666336	14 040
EC 379837 28Jun82	2 of 3	

### UCW Verification

The UCW Directory (QDUC) or the Expanded UCW Directory (QDUE) screens are used to display the present device assignment or to verify any changes made to the directory. The directory screens display the UCWs as currently stored on the diskette. When verifying the directory, use either screen. The UCW Directory (QDUC) screen displays device addresses as assigned (for example: 301-305). The Expanded UCW Directory (QDUE) screen displays device addresses individually.

### UCW Directory

To select the UCW Directory screen from the UCW/Device Directory Tasks screen:

1. Key C and a three-digit device address (000-5FF) next to SELECTION: U.

**Note:** *The default address is zero.*

2. Press ENTER. The UCW Directory screen is displayed.

#### Notes:

- *The message MORE, PRESS ENTER appears if there is more data than can be displayed on one page.*
- *This screen cannot be altered.*

### Expanded UCW Directory

To select the Expanded UCW Directory screen from the UCW/Device Directory Tasks screen:

1. Place CE MODE switch on.
2. Key E and a three-digit device address (000-5FF) next to SELECTION: U.

**Note:** *The default address is zero.*

3. Press ENTER. The Expanded UCW Directory screen is displayed.

#### Notes:

- *The message MORE, PRESS ENTER appears if there is more data than can be displayed on one page.*
- *This screen cannot be altered.*

```

*DISPLAY/ALTER*
G GENERAL REGISTERS
C CONTROL REGISTERS
F FLOATING POINT REGISTERS
P CURRENT PSW
K STORAGE KEY
V VIRTUAL STORAGE
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PROG SYS
SELECTION: UC

*DISPLAY UCW DIRECTORY*
CXX-CYY REF CHARACTERISTICS
000 010 BYT,SHR
301-305 011 BLK,SHR
306-30F 012 BLK,SHR
310-31F 013-022 SEL,DST

.PU-IML REQUIRED AFTER CHANGES -USE LOAD SCREEN
==>

4341
    
```

### UCW Directory (QDUC) Screen

```

*DISPLAY/ALTER*
G GENERAL REGISTERS
C CONTROL REGISTERS
F FLOATING POINT REGISTERS
P CURRENT PSW
K STORAGE KEY
V VIRTUAL STORAGE
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PROG SYS
SELECTION: UE300

*DISPLAY UCW DIRECTORY*
CXX-CYY REF CHARACTERISTICS HEX
300 00C UNA 0310
301 011 BLK,SHR 0472
302 011 BLK,SHR 0472
303 011 BLK,SHR 0472
304 011 BLK,SHR 0472
305 011 BLK,SHR 0472
306 012 BLK,SHR 04B2
307 012 BLK,SHR 04B2
308 012 BLK,SHR 04B2
309 012 BLK,SHR 04B2
30A 012 BLK,SHR 04B2
30B 012 BLK,SHR 04B2
30C 012 BLK,SHR 04B2
30D 012 BLK,SHR 04B2
30E 012 BLK,SHR 04B2
30F 012 BLK,SHR 04B2

.PU-IML REQUIRED AFTER CHANGES -USE LOAD SCREEN
==> MORE, PRESS ENTER

4341
    
```

### Expanded UCW Directory (QDUE) Screen

### Return to General Selection (Q)

To return to the General Selection (Q) screen from any UCW Assignment screen:

1. Key Q next to SELECTION.
2. Press ENTER. General Selection (Q) screen is displayed.


### Return to Prog Sys (Z)

To return to the Prog Sys (Z) screen from any UCW Assignment screen:

1. Key Z next to SELECTION.
2. Press ENTER. Prog Sys (Z) screen is displayed.

Model Groups 1 and 2

EC 379814 02Oct81	PN 5666336	14 045
EC 379837 28Jun82	3 of 3	





### UCW Assignment Table

This table illustrates the most commonly used assignments. For additional information, refer to the applicable system library document.

**Note:** The channel-to-channel (CTCA) feature has a unshared UCW.

Devices	CHAR.CODE Entry		Notes
	Channel		
	Byte	Block	
Direct Access Storage Units 2314*-2312,2313,2318,2319 2835*-2305 2841*-2311 3540 3830*-3330,3333,3340,3344,3350 3880*-With Speed Matching Buffer #6550 -3330,3340,3344,3350,3370,3375,3380 3880*-Without Speed Matching Buffer #6550 -3330,3340,3344,3350,3370,3375 -3380 (Channel 1 or 2)	- - - NE - - - - - -	LS NE LS NE NE - NE or D - NE or D D	     4,5  4,5 4
Magnetic Tape I/O 2403,2404 2415 2803*-2401,2402,2420 2804*-2401,2402 3411 3411*-3410 3803*-3420	- - - - - -	LS LS LS LS LS LS	
Punched Card I/O and Printers 1442 1443 2501,2520 2821*-1403,2540 3203 3811*-3211 3505,3525 3800	NE NE NE NE NE NE NE NE	NE NE NE NE NE NE NE NE	1 2
Display and Console Printers 2250 2840*-2250 3258*-3251,3255 3272*-3277,3284,3286,3287,3288 3274 1B and 1D -3268,3277,3278,3279,3286, -3287,3288,3284,3289 3274 1A* Unshared UCW -3268,3277,3278,3279,3286, -3287,3288,3284,3289 3791*-3277,3284,3286,3287,3288,3793	NE S - S S S S NE NE NE NE	L LS S S S S S NE NE NE NE	2 1  2,6
Data Security Device 3848	-	NE or D	4
Magnetic Character and Optical Readers 1255 1287,1288 1419 3881,3886 3890 3895	NE NE NE NE NE NE	L NE NE NE NE NE	1 1 1,3 1

\* Device is a Control unit

© IBM Corp. 1981

Devices	CHAR.CODE Entry		Notes
	Channel		
	Byte	Block	
Communication/Data Acquisition/Process Control 2701 2715*-2791,2793 3704 3705 CA1 3705 CA2 and CA3 3705 CA4	NE NE NE NE NE NE	- - - - NE NE	    2 1
Paper Tape I/O 2822*-2671 2826*-1017,1018	NE NE	NE -	
Mass Storage System 3850/51	NE	NE	
Auxiliary Processor 3838-With Feature #4850 3838-Without Feature #4850	- -	D NE	4
Audio Response 7770	NE	-	
* Device is a Control unit			
<b>Characteristic Code (CHAR.CODE) Entries:</b>			
- Invalid selection, do not use.			
<b>NE</b> No Entry - defaults to an unshared channel.			
<b>S</b> Device requires a shared UCW.			
<b>L</b> Device requires a block-multiplexer channel to work in selector mode.			
<b>D</b> Control unit operating in data streaming mode.			
<b>Notes:</b>			
1. Preferred attachment is a byte-multiplexer channel.			
2. Preferred attachment is a block-multiplexer channel.			
3. The number of 1419 devices per byte-multiplexer channel is limited. Consult your system engineer.			
4. When CHAR.CODE D is selected, ensure that the control unit is properly set up for operating in data streaming mode. Follow necessary control unit guidelines and/or procedures.			
5. For Model Group 1, 10, or 11 do not attach a 3880 control unit to channel 5. Attach a 3880 to channel 1 or 2.			
6. Assign only one UCW for each 3272 or 3274 control unit.			

### Channel Configuration

The configuration for the channels is:

- Channel 0 Byte Multiplexer (BYT)
- Channel 1 Block Multiplexer (BLK)
- Channel 2 Block Multiplexer (BLK)
- Channel 3 Block Multiplexer (BLK)
- Channel 4 Block Multiplexer (BLK) (see note)
- Channel 5 Block Multiplexer (BLK)

**Note:** If configured on the System Configuration (QFS) screen, channel 4 can operate as a byte-multiplexer (BYT) channel.

### Assignment Examples

SELECTION:

- UU CXX**  
Device CXX assigned as unshared UCW.
- UU CXX-CYY**  
Devices CXX through CYY assigned as unshared UCW.
- UU CXX-CYY S**  
Devices CXX through CYY assigned as shared UCW.
- UU CXX-CYY L**  
Devices CXX through CYY assigned to selector mode.
- UU CXX-CYY SL**  
Devices CXX through CYY assigned as shared UCW to selector mode.
- UU CXX-CYY D**  
Devices CXX through CYY assigned to data streaming mode.
- UU CXX-CYY X**  
Devices CXX through CYY removed (unassigned).

**Note:** CXX and CYY are in the form of channel designation (c) and a two-character unit designation (uu).

Model Groups 1 and 2

EC 379814 02Oct81	PN 2676250	14 051
EC 379837 28Jun82	1 of 1	



# DISKETTE EC UPDATE PROCEDURE

Perform this procedure when installing an EC to the processor. Four diskettes are updated when an EC is installed:

- Two FUNCT diskettes
- DIAG4 diskette
- 4341 Processor Unit Analysis Diskette.


When performing this procedure, note the following:

- The first FUNCT diskette mounted for EC update is referred to as the EC FUNCT diskette.
- The other FUNCT diskette for EC update is referred to as the *backup* EC FUNCT diskette.

Ensure that you can distinguish between the two EC FUNCT diskettes without marking on them. Be sure that the correct diskette is mounted during each step.

Before starting the procedure, review "Diskette EC Update Flowchart."

## DISKETTE EC UPDATE FLOWCHART



Model Groups 1 and 2

EC 379814 02Oct82	PN 5666337	14 075
EC 379837 28Jun82	1 of 3	

1. Open front and side covers of frame 01.
2. Open gate 01A.

**CAUTION**

Observe label on gate 01A before closing it.

3. Mount the diskette the customer is using in the diskette drive.
  - In this procedure, the diskette mounted during this step is referred to as the **FROM** disk or the **ORIGINAL** disk.
4. Put **CE MODE** switch to **NORMAL** position.
5. Press **Power On/IML** key.
 

**Note:** If the processor does not IML when the **Power On/IML** key is pressed, key in **QLM**.
6. Put **CE MODE** switch to **ON**.
  - The General Selection screen is displayed.
7. Display the Program Load screen by keying in **QL** and pressing **ENTER**; then:
  - Record all mode and assist status.
8. Display the Module Transfer Screen.
  - Key in **QFM**, press **ENTER**, and then note the following:
    - **X**: Selects a modules for transfer.
    - **\_** (underscore): Selects the modules *not* for transfer.

**\*\*\*Update EC FUNCT Diskette\*\*\***

9. Select *all* modules for transfer:
  - All module are automatically selected for transfer.
  - An **\_** (underscore) next to a module stops it from being transferred.

**Notes:**

- a. Observe all screen messages.
- b. The **FROM** disk is the diskette already mounted.
- c. The **TO** disk is the **EC FUNCT** diskette.

10. Transfer the selected modules from the **FROM** disk to storage:
  - Key **STARTL** next to **SELECTION: M**, and then press **ENTER**.
    - Processes the **STARTL** command.
    - Displays the message: Mount **FROM** disk.
  - Mount the **FROM** disk, and then press **ENTER**.
    - Transfers modules from the **FROM** disk.
11. Transfer the modules to the **EC FUNCT** diskette:
  - Swap the **FROM** disk with the **EC FUNCT** diskette (**TO** disk) and press **ENTER**.
    - Final message asks you to put in the **ORIGINAL** disk.

**\*\*\*Update Backup EC FUNCT Diskette\*\*\***

12. Mount the **FUNCT** diskette used in step 3 (**ORIGINAL** disk), and press **ENTER**.
  - Resets for other module transfers.
13. Select *all* modules for transfer:
  - All modules are automatically selected for transfer.
  - An **\_** (underscore) next to a module stops it from being transferred.

**Notes:**

- a. Observe all screen messages.
- b. The **FROM** disk is the diskette already mounted.
- c. The **TO** disk is the backup **EC FUNCT** diskette.

14. Transfer the selected modules from the **FROM** disk to storage:
  - Key **STARTL** next to **SELECTION: M**, and then press **ENTER**.
    - Processes the **STARTL** command.
    - Displays the message: Mount **FROM** disk.
  - Mount the **FROM** disk, and then press **ENTER**.
    - Transfers modules from the **FROM** disk.
15. Transfer the modules to the backup **EC FUNCT** diskette:
  - Swap the **FROM** disk with the backup **EC FUNCT** diskette (**TO** disk) and press **ENTER**.
    - Final message asks you to put in the **ORIGINAL** disk.

**\*\*\*Update DIAG4 Diskette\*\*\***

16. Mount the **FUNCT** diskette used in step 3 (**ORIGINAL** disk) and press **ENTER**.
  - Resets for other module transfers.
17. Select only modules (**8001-8004**) and (**0001-20A0**) for transfer:
  - All modules are automatically selected for transfer.
  - Enter an **\_** (underscore) next to the modules you do *not* want to transfer.

**Notes:**

- a. Observe all screen messages.
  - b. The **FROM** disk is the diskette already mounted.
  - c. The **TO** disk is the **DIAG4** diskette.
18. Transfer the modules selected in step 17 to storage:
    - Key **STARTL** next to **SELECTION: M** and press **ENTER**.
      - Processes the **STARTL** command.
      - Displays the message: Mount **FROM** disk.
    - Mount the **FROM** disk, and then press **ENTER**.
      - Transfers modules from the **FROM** disk.
  19. Transfer the selected modules to the **DIAG4** diskette:
    - Swap the mounted diskette (**FROM** disk) with the **DIAG4** diskette (**TO** disk), and press **ENTER**.
      - Final message asks you to put in the **ORIGINAL** disk.

**Note:** If the processor does not have a **4341 Processor Unit Analysis Diskette**, continue with step 24.

**\*\*\*Update 4341 Processor Unit Analysis Diskette\*\*\***

20. Mount the **FUNCT** diskette used in step 3 (**ORIGINAL** disk), and press **ENTER**.
  - Resets for other module transfers.
21. Select only modules (**8001-8004**) and (**0001-20A0**) for transfer:
  - All modules are automatically selected for transfer.
  - Enter an **\_** (underscore) next to the modules you do *not* want to transfer.

**Notes:**

- a. Observe all screen messages.
- b. The **FROM** disk is the diskette already mounted.
- c. The **TO** disk is the **4341 Processor Unit Analysis diskette**.

**SAMPLE QFM SCREEN**

Module IDs

```

*MODULE TRANSFER SCREEN*
STATUS MACHINE SENSITIVE DATA (MODULE)
  X  CLOCKS,IPU,STORE,CS .(8001-8004)
    CONFIGURATION,UCWS .(0001,20A0)
  -  POWER/TEMP LOGS . . .(1024,1026)
    PU LOG CONTROL 1,2. .(3050,3501)
  X  PU LOGS 1-9 . . . .(3061-3069)
  X  SP LOGS . . . . .(3800)
  X  REFERENCE CODES . . .(3900)
  X  PROBLEM ANALYSIS DATA(2806-2808)
    SAVED SCREENS/CE LOGS(9BXX)
ERR MODS: -
STATUS INFO: S=SELECT R=READ & SAVE W=RETRIEVE & WRITE T=TRANSFER COMPLETE
             DSZ=SIZE DIFFERENT DLA=LOAD ADDRESS DIFFERENT D41=NOT FOUND
             INVP=INVALID INPUT
COMMANDS:  MSTARTL START DISK-PU-DISK TRANSFER      Q GENERAL SELECTION
             MSTARTD START DISK-SP-DISK TRANSFER     Z RETURN TO PROG SYS
SELECTION: M _____ ==> ALL LINES SELECTED

                                     4341
                                     ↑
                                     Enter commands here.

```

Area to enable or disable the transfer of modules.

X = transfer  
 \_ = Do not transfer

**Note:** This is a typical example of a QFM screen. For the QFM screen that reflects the microcode EC level of the machine, see "Console Functions."

**Model Groups 1 and 2**

EC 379814 02Oct82	PN 5666337	14 076
EC 379837 28Jun82	2 of 3	

22. Transfer the modules selected in step 21 to storage:
- Key **STARTL** next to **SELECTION: M** and press **ENTER**.
    - Processes the **STARTL** command.
    - Displays the message: Mount **FROM** disk.
  - Mount the **FROM** disk, and then press **ENTER**.
    - Transfers modules from the **FROM** disk.
23. Transfer the selected modules to the 4341 Processor Unit Analysis diskette:
- Swap the mounted diskette (**FROM** disk) with the 4341 Processor Unit Analysis diskette (**TO** disk), and press **ENTER**.
    - Final message asks you to put in the **ORIGINAL** disk.
- \*\*\*Remaining Procedure Continues\*\*\*
24. If you have a hardware EC, perform it at this time, and then continue with this procedure. For hardware EC, see field bill of material (FBM). If you do *not* have a hardware EC, continue with step 26.
25. If you need to do clock adjustments, perform "Clock Adjustment Procedure." For clock adjustment requirement, see field bill of material. If you do *not* need to adjust the clocks, continue with next step.
26. Mount the EC FUNCT diskette.
27. Put **CE MODE** switch to **ON**.
- Display the General Selection screen.
28. Display the System Configuration screen by keying in **QFS** and pressing **ENTER**.
- Verify that **ALL** fields on the System Configuration screen are correct.
  - Make any corrections or updates.
29. Display the Program Load screen by keying in **QL** and pressing **ENTER**; then:
- a. Display the **MODE-ASSIST SELECTION** screen by keying in **I** and pressing **ENTER**.
  - b. Update this screen with the status recorded in step 7.
  - c. Key in **QLM** and press **ENTER** to record the updates on the diskette.
30. Reset the 4341 Processor to load the new code:
- a. Press the **Power Off** key.
  - b. Put **CE MODE** switch to **NORMAL**.
  - c. Press the **Power On/IML** key.
- Note:** If **IML** is not active on Program Load screen, enter **QLM**.


31. If you have any IML patches to transfer to the EC FUNCT diskette:
- Note:** If you do not have IML patches to transfer, continue with the next step.
- a. Obtain the record that contains the names of the IML patches.
    - This record is kept by the CE who normally services the machine.
  - b. Press **MODE/SEL** key.
    - Displays General Selection screen.
  - c. Key in **QBKpatchname** and press **ENTER**.
    - **Patchname** is one of the IML patchnames contained on the record mentioned in step a.
  - d. Follow the screen messages:
    - The **FROM** disk is the diskette used in step 3.
    - The **TO** disk is the EC FUNCT diskette.
  - e. Repeat steps c through d for any additional IML patches you need to copy to the EC FUNCT diskette.
32. If any IML patches need to be activated during the IML process:
- Note:** If no IML patches need to be activated, continue with next step.
- a. Key in **QBM** and press **ENTER**.
  - b. Enter the first IML patchname of a processor IML set in the coreload field.
33. Mount the backup EC FUNCT diskette.
34. Press **MODE SEL**.
- Displays the General Selection screen.
35. Display the Program Load screen by keying in **QL** and pressing **ENTER**; then:
- a. Display the **MODE-ASSIST SELECTION** screen by keying in **I** and pressing **ENTER**.
  - b. Update this screen with the status recorded in step 7.
  - c. Key in **QLM** and press **ENTER** to record the updates on the diskette.

36. If you have any IML patches to transfer to the backup EC FUNCT diskette:
- Note:** This step should be performed if step 31 is performed. If you do not have any IML patch transfers, continue with next step.
- a. Obtain the record that contains the names of the IML patches.
    - This record is kept by the CE who normally services the machine.
  - b. Press **MODE/SEL** key.
    - Displays General Selection screen.
  - c. Key in **QBKpatchname** and press **ENTER**.
    - **Patchname** is one of the IML patchnames contained on the record mentioned in step a.
  - d. Follow the screen messages:
    - The **FROM** disk is the diskette used in step 3.
    - The **TO** disk is the backup EC FUNCT diskette.
  - e. Repeat steps c through d for any additional IML patches you need to copy to the backup EC FUNCT diskette, and then continue.
- Note:** If no IML patches need to be activated, continue with next step.
- f. Key in **QBM** and press **ENTER**.
  - g. Enter the first IML patchname of a processor IML set in the coreload field.
- Note:** The following screen copies should replace the screen copies in front of **Volume 30**. For details of the copy options, see "Screen Copy Options" in this service aid section, page 14 625.
37. Display and copy the System Configuration screen:
- Key in **QFS**, press **ENTER**, and then copy the screen.
38. Display and copy the Program Load screen:
- Key in **QL**, press **ENTER**, and then copy the screen.
39. Display and copy the UCW Directories Display screen:
- Key in **QDUC**, press **ENTER**, and then copy the screen.
40. Display and copy the Clock Ring screen:
- Key in **QCM** and press **ENTER**.
  - Key in **QVW2B** and press **ENTER**.
  - Key in **QVY22**, press **ENTER**, and then copy the screen.
41. This procedure is now complete.

Model Groups 1 and 2

EC 379814 02Oct82	PN 5666337	14 077
EC 379837 28Jun82	3 of 3	

1950  
1951  
1952



# DISKETTE RECOVERY PROCEDURE

The purpose of this procedure is:

- To update a new DIAG4 diskette (if the one at the customer account is damaged).
- To update a 4341 Processor Unit Analysis Diskette (if the one at the customer account is damaged).
- To update the backup FUNCT diskette with any retrievable error logs (if the main FUNCT diskette was damaged).

If the FUNCT diskette is damaged:

- Use this procedure to update the backup FUNCT diskette.
- Order a new FUNCT diskette to ensure that two working FUNCT diskettes are at the computer installation.

When you receive the new FUNCT diskette, update it by performing steps 1 through 11 of the "Diskette EC Update Procedure," page 14 075.

**Note:** When you update the new FUNCT diskette, use the diskette updated in this procedure as the **FROM** disk.

Ensure that the correct diskette is mounted during each step of this procedure.

**Before starting the procedure, review "Diskette Recovery Flowchart."**


- Power off.
- Open front and side covers of frame 01.
- Open gate 01A.

**Caution:**

Observe label on gate 01A before closing it.

- Mount the FUNCT diskette.
  - Note:** If the FUNCT diskette used by the customer is damaged, mount the backup FUNCT diskette.
- Position **CE MODE** switch to **NORMAL**.
- Press Power On/IML key.
  - Note:** If the processor did not IML when the power was activated, enter **QLM**.
- Put **CE MODE** switch to **ON**.
  - The General Selection screen is displayed.
- Perform the following for the specified diskette:
  - For DIAG4, perform steps 9-13.
  - For 4341 Processor Unit Analysis Diskette, perform steps 14-18.
  - For the backup FUNCT diskette, perform steps 19-26.

## DISKETTE RECOVERY FLOWCHART



\*\*\*Update DIAG4 Diskette\*\*\*

- Display the Module Transfer screen:
  - Key in **QFM** and press **ENTER**.
  - X**: Selects a modules for transfer.
  - \_** (underscore): Selects the modules *not* for transfer.

**Notes:**

- Observe all screen messages.
  - The **FROM** disk is the diskette already mounted.
  - The **TO** disk is the new **DIAG4** diskette.
- Select only modules (8001-8004) and (0001-20A0) for transfer:
    - To select modules for machines at microcode EC 154320 or lower, replace the **\_** with an **X**.
      - Ensure that an **\_** (underscore) is next to the modules you do *not* want to transfer.
    - For machines at microcode EC levels 154321 or 866867 or 856091 or higher:
      - All modules are automatically selected for transfer.
      - Enter an **\_** (underscore) next to the modules you do *not* want to transfer.

Model Groups 1 and 2

EC 379814 02Oct81	PN 5666338	14 079
EC 379837 28Jun82	1 of 2	

11. Transfer the modules selected in step 10 to storage:
  - Key **STARTL** next to **SELECTION: M** and press **ENTER**.
    - Processes the **STARTL** command.
    - Displays the message: Mount **FROM** disk.
  - Mount the **FROM** disk, and then press **ENTER** again.
    - Transfers modules from the **FROM** disk.
12. Transfer the selected modules to the DIAG4 diskette:
  - Swap the **FROM** disk with the **TO** disk; then press **ENTER**.
    - Final message asks you to put in the **ORIGINAL** disk.
    - Mount the **ORIGINAL** disk.
13. DIAG4 diskette update is complete.
  - Return the processor to the customer.

**Note:** If the processor does not have a 4341 Processor Unit Analysis Diskette, continue with step 19.

**\*\*\*Update 4341 Processor Unit Analysis Diskette\*\*\***

14. Display the Module Transfer screen:
  - Key in **QFM** and press **ENTER**.
  - **X**: Selects a modules for transfer.
  - **\_** (underscore): Selects the modules *not* for transfer.

**Notes:**

- a. Observe all screen messages.
  - b. The **FROM** disk is the diskette already mounted.
  - c. The **TO** disk is the new 4341 Processor Unit Analysis diskette.
15. Select only modules (8001-8004) and (0001-20A0) for transfer:
    - All modules are automatically selected for transfer.
    - Enter an **\_** (underscore) next to the modules you do *not* want to transfer.
  16. Transfer the modules selected in step 15 to storage:
    - Key **STARTL** next to **SELECTION: M** and press **ENTER**.
      - Processes the **STARTL** command.
      - Displays the message: Mount **FROM** disk.
    - Mount the **FROM** disk, and then press **ENTER**.
      - Transfers modules from the **FROM** disk.

17. Transfer the selected modules to the 4341 Processor Unit Analysis diskette:
  - Swap the **FROM** disk with the **TO** disk; then press **ENTER**.
    - Final message asks you to put in the **ORIGINAL** disk.
18. This diskette update is complete.
  - Return the processor to the customer.

**\*\*\*Update backup FUNCT Diskette\*\*\***

19. Display the Module Transfer screen:
  - Key in **QFM** and press **ENTER**.
20. Select *all* modules for transfer:
  - To select modules for machines at microcode EC 154320 or lower, replace the **\_** with an **X**.
    - Be sure that an **\_** (underscore) is next to the modules you do *not* want to transfer.
  - For machines at microcode EC levels 154321 or 866867 or 856091 or higher:
    - All modules are automatically selected for transfer.
    - Enter an **\_** (underscore) next to the modules you do *not* want to transfer.

**Notes:**

- a. Observe all screen messages.
  - b. The **FROM** disk is the damaged **FUNCT** disk.
  - c. The **TO** disk is the backup **FUNCT** diskette.
21. Transfer the selected modules from the damaged **FUNCT** diskette to storage:
    - Key **STARTL** next to **SELECTION: M**, and then press **ENTER**.
      - Processes the **STARTL** command.
      - Displays the message: Mount **FROM** disk.
    - Mount the **FROM** disk, and then press **ENTER** again.
      - Transfers modules from the **FROM** disk.
  22. If there are no errors, continue with next step. If there are errors:
    - a. List the modules that fail.
    - b. Mount the backup **FUNCT** diskette.
    - c. Press **MODE SEL** key.
      - Resets for other module transfer options.
    - d. Key in **QFM** and press **ENTER**;
      - Displays the Module Transfer screen.
    - e. Replace the **X** with a **\_** next to each module that fails.
    - f. Go back to step 21.

**Note:** The **TO** disk is the backup **FUNCT** diskette.

23. Transfer the selected modules to the backup **FUNCT** diskette:
  - Swap the **FROM** disk with the **TO** disk, and then press **ENTER**.
    - Final message asks you to put in the **ORIGINAL** disk.
    - The **ORIGINAL** is the backup **FUNCT** disk that is already mounted.
  - Press **ENTER**.

24. Display the Program Load screen by keying in **QL** and pressing **ENTER**; then:
  - a. Display the **MODE-ASSIST SELECTION** screen by keying in **I** and pressing **ENTER**.
  - b. Obtain input from the customer and/or *Volume 30* on how the mode and assist were assigned.
  - c. Update the screen based this input.
  - d. Key in **QLM** and press **ENTER** to record the updates on the diskette.

**Note:** If you do not have IML patches to transfer, the procedure is complete.

25. If you have any IML patches to transfer from the damaged **FUNCT** diskette to the backup **FUNCT** diskette:
  - a. Obtain the record that contains the names of the IML patches.
    - This record is kept by the CE who normally services the machine.
  - b. Press **MODE/SEL** key.
    - Displays General Selection screen.
  - c. Key in **QBM** and press **ENTER**.
    - *Patchname* is one of the IML patchnames contains on the record mentioned in step a.

**SAMPLE QFM SCREEN**

Module IDs

```

*MODULE TRANSFER SCREEN*
STATUS MACHINE SENSITIVE DATA (MODULE)
  X  CLOCKS,IPU,STORE,CS .(8001-8004)
    CONFIGURATION,UCWS .(0001,20A0)
  -  POWER/TEMP LOGS . . .(1024,1026)
    PU LOG CONTROL 1,2 .(3050,3501)
  X  PU LOGS 1-9 . . . . .(3061-3069)
  X  SP LOGS . . . . .(3800)
  X  REFERENCE CODES . . .(3900)
  X  PROBLEM ANALYSIS DATA(2806-2808)
  -  SAVED SCREENS/CE LOGS(9BXX)
ERR MODS: -
STATUS INFO: S=SELECT R=READ & SAVE W=RETRIEVE & WRITE T=TRANSFER COMPLETE
             DSZ=SIZE DIFFERENT DLA=LOAD ADDRESS DIFFERENT D41=NOT FOUND
             INVP=INVALID INPUT
COMMANDS: MSTARTL START DISK-PU-DISK TRANSFER Q GENERAL SELECTION
           MSTARTD START DISK-SP-DISK TRANSFER Z RETURN TO PROG SYS
SELECTION: M ==> ALL LINES SELECTED

                                     4341
                                     ↑
                                     Enter commands here.

```

Area to enable or disable the transfer of modules.

X = transfer  
\_ = Do not transfer

**Note:** This is a typical example of a QFM screen. For the QFM screen that reflects the microcode EC level of the machine, see "Console Functions."

**Model Groups 1 and 2**

EC 379814 02Oct81	PN 5666338	14 080
EC 379837 28Jun82	2 of 2	



## DISKETTE DATA RECOVER PROCEDURE (For Two Damaged FUNCT Diskettes)


The purpose of this procedure is:

- To update two newly ordered FUNCT diskettes with clock configuration, and UCW data.
- To recover as much data (logs) as possible from the two FUNCT diskettes that were damaged.

Ensure that the correct diskette is mounted during each step.

Review the "Diskette Data Recovery Flowchart" before starting this procedure that starts on the following page.

### DISKETTE DATA RECOVERY FLOWCHART



Model Groups 1 and 2

EC 379798 06Jun80	PN 5666339	14 081
EC 379817 06Mar81	1 of 3	

1. Power off.
2. Open front and side covers of frame 01.
3. Open gate 01A.

**CAUTION**

Observe label on gate 01A before closing it.

4. Mount one of the new FUNCT diskettes.
  - The diskette mounted during this step is referred to as the **TO** disk or the **ORIGINAL** disk until directed differently.
- Note:** You will be directed when to use the other **FUNCT** diskette (referred to as the new backup **FUNCT** diskette).
5. Put **CE MODE** switch to **ON** position.
6. Press **Power on/IML** key.
7. Press **MODE SEL** key:
  - Displays the General Selection screen.
8. Display the Module Transfer screen:
  - Key in **QFM** and press **ENTER**.
    - **X**: Selects a modules for transfer.
    - **\_** (underscore): Selects the modules *not* for transfer.
9. Select *all* modules for transfer:
  - To select modules for machines at microcode EC 154320 or lower, replace the **\_** with an **X**.
    - Ensure that an **\_** (underscore) is next to the modules you do *not* want to transfer.
  - For machines at microcode EC levels of 154321 or 866867 or 856092 or higher:
    - All modules are automatically selected for transfer.
    - Enter an **\_** (underscore) next to the modules you do *not* want to transfer.

**Notes:**

- a. Observe all screen messages.
  - b. The **FROM** disk is one of the damaged **FUNCT** diskettes.
  - c. The **TO** disk is the new **FUNCT** diskette used in step 4.
  - d. Do not use the second damaged **FUNCT** diskette until directed.
10. Transfer the selected modules from one of the damaged **FUNCT** diskettes to a buffer:
    - Key **STARTD** next to **SELECTION: M**, and then press **ENTER**.
      - Processes the **STARTD** command.
      - Displays the message: Mount **FROM** disk.
    - Mount one of the damaged **FUNCT** diskettes, and then press **ENTER** again.
      - Transfers modules from the **FROM** disk.

11. Transfer the selected modules to the **TO** diskette:
  - Swap between the **FROM** disk and the **TO** disk as directed by the screen messages.
    - Final message asks you to put in the **ORIGINAL** disk.
12. If there are no errors, continue with the next step; if there are errors:
  - a. List the modules that caused an error.
  - b. List the modules that were successfully transferred.
  - c. Mount the new **FUNCT** diskette (**TO** disk).
  - d. Press **MODE SEL**.
  - e. Key in **QFM** and press **ENTER**.
    - Displays the Module Transfer screen.
  - f. Put a **\_** at:
    - Modules that fail.
    - Modules already transferred.
  - g. Go back to step 10.
13. List the modules you could not obtain from the first damaged **FUNCT** diskette. If you have received all necessary modules, go to step 21 and continue.
14. Mount same diskette used in step 4 (**ORIGINAL** disk), and press **ENTER**.
  - Resets the transfer function for another transfer setup.
15. Select the modules from your list for transfer:
  - To select modules for machines at microcode EC 154320 or lower, replace the **\_** with an **X**.
    - Ensure that an **\_** (underscore) is next to the modules you do *not* want to transfer.
  - For machines at microcode EC levels of 154321 or 866867 or 856092 or higher:
    - All modules are automatically selected for transfer.
    - Enter an **\_** (underscore) next to the modules you do *not* want to transfer.

16. Transfer the selected modules from the second damaged **FUNCT** diskettes:
  - Mount the second damaged **FUNCT** diskettes.
  - Key **STARTD** next to **SELECTION: M**, and then press **ENTER**.
  - Press **ENTER** again.
- Notes:**
  - a. Observe all screen messages.
  - b. The **FROM** disk is the damaged diskette already mounted.
  - c. The **TO** disk is the same **FUNCT** diskette used in step 4.
17. Transfer the selected modules to the **TO** disk:
  - Swap the mounted diskette (**FROM** disk) with the first new **FUNCT** diskette (**TO** disk) and press **ENTER**.
  - Swap between the **FROM** disk and the **TO** disk as directed by the screen messages.
    - Final message asks you to put in the **ORIGINAL** disk.
18. If there are no errors, continue with the next step; if there are errors:
  - a. List the modules that caused an error.
  - b. List the modules that were successfully transferred.
  - c. Mount the new **FUNCT** diskette (**TO** disk).
  - d. Press **MODE SEL**.
  - e. Key in **QFM** and press **ENTER**.
  - f. Put a **\_** at:
    - Modules that fail.
    - Modules already transferred.
  - g. Go back to step 16.
19. Mount the same **FUNCT** disk used in step 4 (**ORIGINAL** disk) and press **ENTER**.

**SAMPLE QFM SCREEN**

Module IDs

\*MODULE TRANSFER SCREEN\*

STATUS	MACHINE SENSITIVE DATA (MODULE)
X	CLOCKS, IPU, STORE, CS .(8001-8004)
	CONFIGURATION, UCWS .(0001, 20A0)
	POWER/TEMP LOGS . . .(1024, 1026)
-	PU LOG CONTROL 1. . .(3050)
X	PU LOG CONTROL 2. . .(3501)
	PU LOGS 1-9 . . . .(3061-3069)
X	SP LOGS . . . . .(3800)
X	REFERENCE CODES . . .(3900)
X	SAVED SCREENS/CE LOGS(9B01, 9BXX)

ERR MODS:

STATUS INFO: S=SELECT R=READ & SAVE W=RETRIEVE & WRITE T=TRANSFER COMPLETE  
 DSZ=SIZE DIFFERENT DLA=LOAD ADDRESS DIFFERENT D41=NOT FOUND  
 INVP=INVALID INPUT

COMMANDS: MSTARTL START DISK-PU-DISK TRANSFER Q GENERAL SELECTION  
 MSTARTD START DISK-SP-DISK TRANSFER Z RETURN TO PROG SYS

SELECTION: M ==> ALL LINES SELECTED

4341

Enter commands here.

Area to enable or disable the transfer of modules.

X= Transfer  
 = Do not Transfer

This is a typical example of a QFM screen. For the QFM screen that reflects the microcode EC level of a specific machine, see "Console Functions."

**Model Groups 1 and 2**

EC 379798 06Jun80	PN 5666339	14 082
EC 379817 06Mar81	2 of 3	

20. If you obtained modules (8001-8004) and (0001,20A0), continue with next step. If you were not able to obtain modules (8001-8004) and (0001,20A0):
- Select only modules (8001-8004) and (0001-20A0) for transfer:
    - To select modules for machines at microcode EC 154320 or lower, replace the \_\_\_ with an X.
      - Ensure that an \_\_\_ (underscore) is next to the modules you do *not* want to transfer.
    - For machines at microcode EC levels of 154321 or 866867 or 856092, or higher:
      - All modules are automatically selected for transfer.
      - Enter an \_\_\_ (underscore) next to the modules you do *not* want to transfer.
- Notes:**
- Observe all screen messages.
  - The **FROM** disk is the **DIAG4** diskette.
  - The **TO** disk is the **FUNCT** diskette used in step 4.
- Transfer the selected modules:
    - Key **STARTD** next to **SELECTION: M** and press **ENTER**.
      - Processes the **STARTD** command.
      - Displays the message: Mount **FROM** disk.
    - Mount the **DIAG4** diskette.
    - Press **ENTER** again.
      - Transfers modules from the **FROM** disk.
  - Transfer the selected modules to the new **FUNCT** diskette:
    - Swap the **FROM** disk with the **TO** disk; then press **ENTER**.
    - Swap between the **FROM** disk and the **TO** disk as directed by the screen messages.
      - Final message asks you to put in the **ORIGINAL** disk.
21. Display and verify the System Configuration screen:
- Press **MODE SEL**.
    - Displays the General Selection screen.
  - Key in **QFS** to display the System Configuration screen.
  - Compare the screen with its hard copy in *Volume 30*.
    - Make any necessary updates.

22. Display and verify the clock scan rings:
- Key in **QMW** and press **ENTER**.
    - Displays the *Partial Power Up/Down* screen.
  - Enter **00** in each of the two input areas, and then press **Enter**.
    - Powers up the processor.
  - Press **MODE SEL** key.
    - Displays General Selection screen.
  - Key in **QCM** and press **ENTER**.
  - Key in **QVW2B** and press **ENTER**.
  - Key in **Y22** and press **ENTER**.
  - Compare the clock scan ring screen with the hard copy in *Volume 30*.
    - Make any necessary updates.
23. Display and verify the UCW Directory screen:
- Key in **QDUC** and press **ENTER**.
  - Compare the screen with the hard copy in *Volume 30*.
    - Make any necessary updates.
24. If you have any IML patches to transfer from the damaged **FUNCT** diskette to the updated **FUNCT** diskette:
- Note** If you do not have IML patches to transfer, continue with step 26.
- Obtain the record that contains the names of the IML patches;
    - This record is kept by the CE who usually services the machine.
  - Press **MODE/SEL** key;
    - Displays General Selection screen.
  - Key in **QBKpatchname** and press **ENTER**.
    - Patchname* is one of the IML patchnames contain on the record mentioned in step a.
  - Follow the screen messages:
    - The **FROM** disk is the damaged **FUNCT** disk.
    - The **TO** disk is the updated **FUNCT** diskette.
  - Repeat steps c through d for any additional IML patches you need to copy to the updated **FUNCT** diskette.

25. If any IML patches need to be activated during the IML process:
- Note:** If no IML patches need to be activated, continue with next step.
- Perform one of the following:
    - For machines at microcode EC levels of 154322 or 856092 or 866867 or lower:
      - Key in **QBP** and press **ENTER**.
    - For machines at microcode EC levels of 154323 or 856093 or 866868 or higher:
      - Key in **QBM** and press **ENTER**.
  - Enter the first IML patchname of a processor IML set in the coreload field.
26. Display and verify the Program Load screen:
- Key in **QL** and press **ENTER**.
  - Compare *all* screen fields with the hard copy in *Volume 30*.
    - Make any necessary updates.
27. Power off.
28. Put **CE MODE** switch to **NORMAL**.
29. Press **Power On/IML**.
- Note:** If IML is not active on Program Load screen, enter **QLM**.
30. Put **CE MODE** switch to **ON**.
31. Display the Module Transfer screen:
  - Key in **QFM** and press **ENTER**.
32. Select *all* modules for transfer:
  - To select modules for machines at microcode EC 154320 or lower, replace the \_\_\_ with an X.
    - Ensure that an \_\_\_ (underscore) is next to the modules you do *not* want to transfer.
  - For machines at microcode EC levels of 154321 or 866867 or 856092 or higher:
    - All modules are automatically selected for transfer.
    - Enter an \_\_\_ (underscore) next to the modules you do *not* want to transfer.

33. Transfer the selected modules from the updated **FUNCT** diskette:
- Key **STARTL** next to **SELECTION: M**, and then press **ENTER**.
  - Press **ENTER** again.
- Notes:**
- Observe all screen messages.
  - The **FROM** disk is the updated **FUNCT** diskette.
  - The **TO** disk is the new backup **FUNCT** diskette.
34. Transfer the modules to the new backup **FUNCT** diskette:
- Swap the mounted diskette (**FROM** disk), with the new backup **FUNCT** diskette (**TO** disk).
  - Press **ENTER**.
  - Final message asks you to put in the **ORIGINAL** disk.
  - Mount the diskette used in step 4.
- This procedure is now complete.

Model Groups 1 and 2

EC 379798 06Jun80	PN 5666339	14 083
EC 379817 06Mar81	3 of 3	



## EREP (Failing Storage Address)

The EREP print-out for the 4300 Processors is not for maintenance purposes. The data can be used to analyze operating conditions of the machine.

The data on the EREP print-out has the same interpretation as past machines; except for the *Failing Storage Address* area. Depending on the mode of operation, the address can be real or virtual (in relation to a physical location on the machine). To verify the real storage address:

- Display the **QECD** screen.  
(See *PU Directory Display* in volume 18.)
- Compare.....  
    *TIME - xx xx xx*  
as shown on the EREP print-out with.....  
    *TODC EQUIVALENT*  
    *xx/xxx xx:xx:xx*  
on the **QECD** screen.
- The real address is under the heading.....  
    *STORAGE ERROR*

**Note:** Any record past the ninth can not be related to the current **QECD** screen.



# 01A GATE-CARD LAYOUT

## Board A1

### Channel Hardware, Instruction Processor

Interface Controller Section  
Location: B2

Channel Data Buffer Section  
Locations: C2, D2, and E2

Channel Control Section  
Location: C2

Shift Circuits  
Locations: D2, E2, L2, and M2

ALU/Local Storage/Data Flow Registers  
Locations: R2, S2, T2, and U2

External Registers  
Locations: F2, P2, and Q2

**Note:** External Registers are also located in other cards.

Clocks  
Locations: G2, H2, and K2

Storage Addressing and Update Registers  
Location: N2

## Board B1

### Instruction Processor, Main Storage and Controls

Control Storage  
Locations: B2 through F2

Array Control  
Locations: G2, J2, and K2

High-Speed Buffer Section  
Locations: M2 through Q2

Main Storage hardware  
Locations: S2 and T2



Storage Addresses and Controls Section  
Location: H2, J2, K2, G2, and U2

## Board C1

Main Storage (BSM)  
Locations: B2 through U2

### Top Card Connector (TCC) Board to Board Connections


Board B1      Board C1



## C STORAGE ARRAY CARDS LOCATION CHART


**Note:** Cards located in positions B2 through U2 are affected by the storage size and the power group code of the machine. See System Configuration screen (QFS) for the storage size and power group code that applies to the machine; then use this chart for specific card locations.

Power Group Code	Storage Size	Card Locations
21	2 M	01AC1G2, L2, Q2, and U2.
21	4 M	01AC1F2, G2, K2, L2, P2, Q2, T2, and U2.
21	8 M	01AC1D2 through U2.
22	2 M	01AC1G2, L2, Q2, and U2.
22	4 M	01AC1F2, G2, K2, L2, P2, Q2, T2, and U2.
22	8 M	01AC1D2 through U2.
23	4 M	01AC1G2, L2, Q2, and U2.
23	8 M	01AC1F2, G2, K2, L2, P2, Q2, T2, and U2.
23	12 M	01AC1E2, F2, G2, J2, K2, L2, N2, P2, Q2, S2, T2, and U2.
23	16 M	01AC1D2 through U2.
24	4 M	01AC1G2, L2, Q2, and U2.
24	8 M	01AC1F2, G2, K2, L2, P2, Q2, T2, and U2.
24	12 M	01AC1E2, F2, G2, J2, K2, L2, N2, P2, Q2, S2, T2, and U2.
24	16 M	01AC1D2 through U2.



- Notes:**
1. For details of boards A2 through D2, see page 14 106f.
  2. For part numbers of top card connectors, see the decal on the cover of board 01AB1.

01A GATE-CARD LAYOUT (CONTINUED)



**Board A2**

**Channel Hardware, Maintenance and Support Subsystem**

Channel Interface Adapters

Locations: D2, E2, F2, Q2, R2, and S2

**Note:** For card-to-channel association, see "Channel Hardware."

Scan Card

Location: J2

CTCA Card

Location: J4

**Note:** This card comes with the optional CTCA Feature. More details are in this service aids section, page 14 317, "OCP to CTCA Interconnections."

Local Channel Adapter

Locations: M2, N2, and P2

RSF Adapter

Locations: B4, K4, and L2

**Board B2**

**Maintenance and Support Subsystem**

Support Bus Adapter

Location: G2

Support Processor Storage

Locations: L2 and M2 (for 32K cards)

or

Location: L2 (for 64K card)

Support Control Logic Adapter

Location: F2

Diskette Drive Adapter

Locations: T2 and U2

Support Processor

Locations: H2, J2, and K2

Power Controller Adapter

Locations: C2, D2, and E2

Device Cluster Adapter

Locations: R2 and S2

Serial Number Card

Location: S4

**Board C2**

Spare

**Board D2**

**Hardwire Sequence**

Hardwire Sequence

Locations: B2, C2, C4, D2, and E2

**Model Group 2**

EC 379814 02Oct81	PN 2676260	14 106f
EC 379815 12Nov81	2 of 2	



# BOARD SIGNAL LEVELS

Board	Valid Up Level	Valid Down Level	Probe Point (see note below)	Net Name	Figure
01A-A1	+2.4 to +5.5	+0.6 to 0.0	G2B56	ABA02AA14	A
	-1.17 to -0.57	-1.83 to -2.3	C2A16	RAAAAAA66(P)	B
	-0.08 to +0.08	-0.9 to -1.4	M2A52	LAAABCA1(P)	C
	+1.7 to +5.5	+0.7 to 0.0	F2C20	ABA02AC1(0)	D
01A-A2	+2.4 to +5.5	+0.6 to 0.0	D2P11	A1AAAAA80	A
	+3.16 to +5.10	+0.15 to 0.0	D2B02	A1AAAAA30(0)	E
	-0.08 to +0.08	-0.9 to -1.4	D2G02	A1AAAAA40(0)	C
01A-B1	+2.4 to +5.5	+0.6 to 0.0	H2A04	ABC00HA14	A
	-0.08 to +0.08	-0.9 to -1.4	J2D49 U2D03*	XAAACAA00(0) U8AAAAA32*	C
	-1.17 to -0.57	-1.83 to -2.3	J2D51 U2C64*	XAAAAAA00(0) U8AABBA42*	B
01A-B2 01A-D2	+2.5 to +5.5 (Call your support center for exceptions to these levels)	+0.8 to 0.0	L2B13		F
01A-C1 (Md1 Gp 2 only)	-0.08 to +0.08	-0.9 to -1.4	B2A48	ABE00AD12	C
	-1.17 to -0.57	-1.83 to -2.3	B2B27	B9AAAAA06(0)	B

\* Model Group 2 only

Note that other probe points and net names besides those given here are available to you.




Figure A




Figure B




Figure C




Figure D




Figure E





Figure F



LOGIC BOARD PIN NUMBERING


BOARDS 01AA1, B1, and C1 (IF INSTALLED)




PIN NUMBERS  
B2 to U2



PIN NUMBERS  
A2, A3  
V2, V3



PIN NUMBERS FOR B1, D1, B4 and D4.




Pin Side

Model Groups 1 and 2

EC 379814 02Oct81	PN 2676323	14 113
	1 of 2	

LOGIC BOARD PIN NUMBERING (CONTINUED)

BOARDS 01AA2, B2, C2 (IF INSTALLED), D2, and 03AA1



Model Groups 1 and 2

EC 379814 02Oct81	PN 2676323	14 114
	2 of 2	

## PROCESSOR UNIT SERVICE AIDS

### INTERMITTENT OR SOFT ERRORS

If you are having intermittent errors or the customer is reporting excessive soft errors (reliable machine checks), the following hints may help to determine the problem.

1. Display the processing unit directory log by entering QECD in CE mode. The log contains the eight most recent machine checks plus the last unrecoverable machine check. Successful retries with the same reference code UU fields indicate a possible problem. Record the reference code any duplicate reference codes.
2. Press **MODE SEL**; and when the General Selection screen is displayed, enter **QEI** and press **ENTER**.
3. Enter the reference code recorded in step 1. If a FRU list is displayed, you may want to invoke the support structure for advice on replacing FRU's to fix the problem.
4. The hardstop option may also be used by entering **QKS**. Hardstop will stop the processor immediately on a machine check with no retry and no reference code. The error latch is set and can be displayed via the QVK screen. In some cases the first error is the most likely; however, some errors may generate a second reference code that can hide the real problem. Enter **QKN** and press **START** key to return to normal after a hardstop.

### CSAR TRACE

A copy of the QVAB screen (CSAR trace) can be helpful in diagnosing intermittent failures.

#### How to Activate CSAR Trace

1. Key QBAQVASAVE.
2. Press ENTER.

The trace remains active until:  
Machine is powered off or  
diagnostics are run or  
the QFS screen is changed.

### How to Display CSAR Trace

1. Key QECD to display PU logout directory.
2. Key needed log ID nnnn.
3. After log ID, key A.
4. Press ENTER.

**Warning: Saving the QVAB screen extends retry logging time. This may cause overruns.**

# METERING SERVICE PROCEDURE

This procedure provides the wiring diagrams to be used with MAP 6600 to service metering problems.

- The open keys in Figure 1 indicate voltage points that are referenced from MAP 6600.
- Figures 2, 3, 4, and 5 give more wiring detail of cards shown in Figure 1.
- For bus/tag pin numbering, see "Gate 01E (Channel Interface)," in the Locations section of this volume.





FIGURE 1

CARD 01AA1G2




FIGURE 2

SUPPORT BUS ADAPTER CARD 01AB2G2




FIGURE 3

CHANNEL 0 INTERFACE ADAPTER CARD




FIGURE 4

CHANNELS 1 THROUGH 5 INTERFACE ADAPTER CARD




FIGURE 5

Model Groups 1 and 2

EC 379814 02Oct81	PN 5666341	14 125
EC 379837 28Jun82	3 of 3	

000000




000000

000000



000000



000000

000000  
 000000  
 000000  
 000000






# CHANNEL SERVICE AIDS

## IFCC LOG

IFCC log data (16 bytes) is:

- Stored in auxiliary storage when an IFCC is sensed.
  - The address depends on the channel ID and the operating mode — S/370 or VSE. When in VSE mode, the address also depends on storage size.
  - If more than one IFCC occurs on a channel, only the data for the first and last occurrence is saved.
- Cleared during IML.
- Displayed by entering: QDAxxxx  
(xxxx is the storage location as shown below.)



**Note:** If only one IFCC has occurred on a channel, nothing is stored at the last log location.

Byte:

0	1	2	3	4	5	6	7
INDIRO	IOADDR	CATNUM	-- Engineering use only --				

Byte:

8	9	A	B	C	D	E	F
BUS IN	TAGOUT	BUSOUT	TAG IN	----- Spare -----			

### Byte 0: INDIRO

Bits 1-3 indicate a channel local storage ID as follows:

- x111 (7) - Channel 0
- x010 (2) - Channel 1
- x011 (3) - Channel 2
- x100 (4) - Channel 3
- x101 (5) - Channel 4
- x110 (6) - Channel 5

To display a channel LS, enter: QDLn  
(n = channel LS ID as shown in parenthesis above.)

### Byte 1: IOADDR

Bits 0-3 = Control unit address  
Bits 4-7 = Device address (See Note.)

**Note:** Channel 0 device addresses F0 through FF are used by the microprogram when addressing devices via the LCA. For definitions, see the following chart.

Addr. in Byte 1	Definition
F2	Device attached to port 0 on the 01F gate.
F3	Device attached to port 1 on the 01F gate.
F4	Device attached to port 2 on the 01F gate.
F5	Device attached to port 3 on the 01F gate.
F6	SP to processing unit communications.
F7	Processing unit to SP communications.
FF	The LCA sent 'disconnect in' to channel 0.

### Byte 2: CATNUM

For definitions, see "Catalog Numbers" in this section.

### Byte 9: TAGOUT

- Bit 0 = 1
- 1 = Address Out
- 2 = Command Out
- 3 = Data Out
- 4 = Service Out
- 5 = Suppress Out
- 6 = Op Out
- 7 = Select Out

### Byte B: TAG IN

- Bit 0 = Request In
- 1 = Op In
- 2 = Disconnect In
- 3 = Address In
- 4 = Select In
- 5 = Status In
- 6 = Service or Data In
- 7 = Command Out/Service Out/Data Out

## Catalog Numbers

Following are complete lists of catalog numbers. The first list shows the general category into which the catalog numbers fall. The second list gives a description of the reason for the catalog number. For more information, invoke your support structure.

### Range Category

00-1F	Interface Sequencing
20-3F	Microcode Timeouts
40-5F	Interface Malfunctions
60-7F	Microcode Detected Hardware Malfunctions
80-8F	Instruction Processing Errors (architecture)
90-9F	Instruction Processing Errors (configuration dependent)
A0-BF	Interrupt Processing
C0-DF	Special Sequences
E0-FF	Support Processor

## Catalog Numbers and Descriptions

Catalog Numbers	Descriptions
00	Reserved for reset state of catalog number.
02	Select-in received during initial selection for an I/O operation.
04 IFCC	During initial selection, the address received either was not the same as the address sent or was out of parity.
06 IFCC	Disconnect-in was received before the end of initial selection. (The connected control unit cannot finish the operation.)
08 IFCC	Disconnect-in was received before ending status. (The connected control unit cannot finish the operation.)
0A IFCC	No response was received when the channel issued select-out to request-in. The expected response was either an op-in/address-in sequence (a device was found) or a select-in tag (a device was not found).
0C IFCC	An interface line (except for request-in) was active after the channel released the device.
0E IFCC	After select-in was received, an interface line (except for request-in) remained active. (The indicated device may not be valid.)

10 CDC	An <i>Any Check</i> (see Note 1) condition was detected at data end time (sequence count 11 or 91).
20 CCC	A timeout occurred while trying to gain control of the block-multiplexer channel.
22 CCC	A timeout occurred while waiting for initial selection status. (Bit 3 in the CHACMD Reg is on.)
24 CCC	A timeout occurred while waiting to gain control of the byte-multiplexer channel.
26 CCC	A timeout occurred while waiting for initial selection status for an Internal Test I/O.
28 CCC	A timeout occurred while trying to gain control of a channel during a selector operation.
40 IFCC	Select-in (address not found) was received during a command chaining sequence. (Select-in should not come up; the same device should be selected.)
42 CDC or IFCC	A bus-in parity check or <i>Any Check</i> (see Note 1) was sensed at initial selection status-in time.
44 IFCC	During initial selection, a tag line was either active or not active at the wrong time.
46	A check occurred during command chaining. The chaining operation is ended.
48 CDC or IFCC	A bus-in parity check or <i>Any Check</i> (see Note 1) was sensed at ending status time.
4A CDC or IFCC	A bus-in parity check or <i>Any Check</i> (see Note 1) was sensed after the <i>Load Loop</i> (see Note 2).
4C	A load trap occurred for a device which does not have a valid directory element.
4E IFCC	A device that requires a shared UCW caused a load trap while another device was using the UCW.
60 CCC	The channel detected an invalid command or an invalid command/sequence count combination.
6A IFCC	A disconnect-in was received while the channel was polling. (The address indicated may not be valid.)
6E	No function was in the CHACMDR upon entry in the Asynchronous Command Completion Trap.
6F IFCC	A bus-in parity check was sensed at address-in time of initial selection.
80	The CCW specified by the CAW is not on a doubleword boundary.
82	Bits 4-7 of the CAW are not zeros.
84	Data end occurred with an error (program check, protection check, or wrong length record).

86	When a load occurred, a check condition from previous processing was detected.
90	Bad status was received during an IPL.
94	Channel specified by I/O instruction is not installed on the system.
96	The UCW directory element for the addressed device has the valid bit off. Possible reasons for this are: <ul style="list-style-type: none"> <li>The device has not yet been validated by the customer engineer.</li> <li>The addressed device is attached via the support processor.</li> </ul>
98	An IPL was issued to an MSS device.
9C	Test Channel - Channel specified is not installed on the system.
9F	Store Channel ID - Channel specified is not installed on the system.
A1	Channel (n) interrupt was due to a logout pending.
A4	Channel (n) interrupt required an Internal Test I/O.
A5	PCI interrupt not reported. Wait for ending status queue.
A6	An asynchronous status interrupt occurred for an MSS device.
C0	A partial UCW fetch to IPU direct local storage storage was required to determine the subchannel state.
C2 IFCC	Command chaining was broken due to a short-busy sequence.
C3	A short-busy sequence occurred during the initial selection sequence.
C4	A device on the byte-multiplexer channel requested a data transfer when it was not expected. (The first such request is not an error condition.)
C6 IFCC	A request for data was received on a byte-multiplexer channel when it was not expected.
C8 IFCC	A request for data was received on a block-multiplexer channel when it was not expected.
CA	Status-in without device-end received while in the load loop (see Note 2). A command chain or a command retry sequence is indicated.
CC	Ending status without device-end received. A command chain or a command retry sequence is indicated.
CE	Nonzero status was received at initial selection time, and did not contain device end.

D0	A halt operation was requested.
D2	An interface disconnect has been performed.
D6 CCC	A channel control check occurred because of a machine check.
E0	A halt operation was attempted while a SIO was queued. The halt operation is queued.
E2	A SIO/TIO was issued to an MSS device while an immediate command was being completed. The SIO/TIO has been queued for re-issue.
E4	One of the following invalid SP command procedures has caused the channel to be unloaded: <ul style="list-style-type: none"> <li>A Signal Processor command (SIGP) was in process while another was trying to start.</li> <li>An invalid TIO (CMD 00) is about to be transferred to the support processor. The TIO (CMD 00) is canceled.</li> </ul>
E6	An interface disconnect has occurred for a queued halt operation for an MSS device.
E8 IFCC	Select-in was received during initial selection for a support processor device (address not found).
<b>Note 1:</b>	<i>Any Check</i> may be: <ol style="list-style-type: none"> <li>Wrong Length Record (No SLI flag)</li> <li>Program or Protection Check</li> <li>Chaining Check</li> <li>Channel Data Check</li> </ol>
<b>Note 2:</b>	<i>Load Loop</i> is the standard request-in, op-in sequence.

### Model Groups 1 and 2

EC379605 06Mar81	PN 5666342	14 210
EC379837 28Jun82	2 of 2	

## LOOP PROCEDURE FOR TIO/SIO

The following program can be used to loop I/O for scoping. This program can be entered as a block by use of the Block Function. The block can be saved on the diskette and invoked by using block function commands described in *Volume 18 under Console Functions*. The block screen contains all the commands necessary to Edit and run the block.

```

01 DO.01.TEST
02 QOI
03 KEY.START.01
04 QDM000=0004000000000400
05 QDM048=00000500
06 QDM070=0002000000FCCECE
07 QDM078=0004000000000400
08 QDM400=9D000CUU47700410
09 QDM408=9C000CUU47F00400
0A QDM410=9104004447800400
0B QDM418=8000007582000070
0C QDM500=0400060020000018
0D QDP0=0004000000000400
0E QON
0F NOP.PUSH.START.KEY.TO.START
10 NOP.CUU.AT.402.AND.40A.
11 NOP.CCW.AT.500.
12 END.XXXX.I.YOURNAME.DATE
  
```

This block stores the necessary information in main storage to loop a specified I/O device as specified by the CUU in locations 402 and 40A. These locations can be changed to specify any device desired.

Locations 400 through 40F contain the TIO/SIO loop. Location 410 does a Test Under Mask for the logout pending bit and falls through to location 418 if the bit is on. Location 418 sets the system mask to allow interrupts and store a CSW. System mask bits FC allow I/O interrupts for every channel at location 75. The mask can be modified to allow interrupts on only one channel. Location 70 is the wait PSW and location 78 is I/O new PSW. The CCW is located at location 500. Lines 0F through 11 are NOP comment lines to describe block run procedures.

## Channel Status Word

KEY	0	L	CC	DATA ADDRESS
	0	3	4	5 6 7 8
				31

UNIT STATUS	CHAN STATUS	BYTE COUNT
32	39 40	47 48
		63

BIT	BIT
5 Logout Pending	40 Program Ctrl'd Interruption
32 Attention	41 Incorrect Length
33 Status Modifier	42 Program Check
34 Control Unit End	43 Protection Check
35 Busy	44 Channel Data Check
36 Channel End	45 Channel Control Check
37 Device End	46 Interface Control Check
38 Unit Check	47 Chaining Check
39 Unit Exception	

## INTERFACE CONTROL CHECK (IFCC) SAVE BLOCKS

This service aid contains a description and procedure for using two IFCC save blocks;

- IFCC Save Block (A)
- IFCC Save Block (B)

Each block is dependent on the microcode EC level of the machine on which it is used.

When intermittent interface control check (IFCC) errors are suspected, the IFCC save block should be used to save IFCC data in the IFCC save area of the FUNCT diskette.

### Notes:

- Processor performance is affected during the process of saving IFCC data.
- When the processor is IMLed, all IFCC data in the PSW and I/O trace buffer and in auxiliary storage is cleared.

## IFCC SAVE BLOCK (A) DESCRIPTION

- This block applies to any machine at microcode EC levels **154322** or **866867** or lower.
- This block stores unformatted IFCC data in the block diskette save area (of the FUNCT diskette) from auxiliary storage.
- Unformatted IFCC data is stored in auxiliary storage for all 4341 processors when an IFCC occurs. However, this data should be used only for machines at microcode EC levels 154322, 866867, or lower.
- This block is designed to save IFCC data for a specific channel. The format of lines 04 through 09 depends on the channel and the mode of operation.

### How To Use

To use this block, it must be installed on the FUNCT diskette as described:

- (1) Review "IFCC Save Block (A) Example," "IFCC Save Block (A) Format," and then return.
- (2) Perform sequence **3**, steps 1 through 6 of the "Patch Installation," page 14 609.

### How To Display

To display the unformatted IFCC data:

- (1) Ensure the **CE MODE** switch is in the **ON** position.
- (2) Press the **MODE SEL** key.
- (3) Key in **QDS**.  
-Displays the unformatted IFCC data.


### How To Deactivate

To deactivate this block:

- (1) Key in **QBUIFCCSAVE**.


## IFCC Save Block (A) Example

This example is formatted for channel 2 and S/370 mode.



## FORMAT FOR IFCC SAVE BLOCK (A) (Lines 04 through 09)

**A**



## IFCC SAVE BLOCK (B) DESCRIPTION

- This block is already installed on machines at any of the following microcode EC levels: 154323, 866868, 856093, or higher.

```

01 DO.01.IFCCSAVE
02 QASM97D4
03 MATCH
04 QDTS
05 KEY.START.01
06 GOTO.03
  
```

- This block can not be used on machines that are not in the range of microcode EC levels specified.
- This block stores formatted IFCC data in the IFCC diskette save area (of the FUNCT diskette) from the PSW and I/O Trace buffer.
- This block saves the IFCC data for all channels and modes of operation.

### How To Use

To use this block:

- (1) Key in **QBAIFCCSAVE** and press **ENTER**.  
- This command activates and places the block in match-wait status, waiting for an IFCC to occur.

### How To Display

To display the formatted IFCC data:

- (1) Press **MODE SEL**.
- (2) Key in **QDTF** and press **ENTER**.  
- Displays the formatted IFCC data.

### How To Deactivate

To deactivate this block:

- (1) Key in **QBDIFCCSAVE**.

### Model Groups 1 and 2

EC 379602 15Sep80	PN 5666343	14 220
EC 379606 20Apr81	2 of 2	

## INTERFACE CONTROL CHECK (IFCC) TRACE

Beginning with microcode EC levels 154322 (Model Group 1) and 856091 (Model Group 2), the trace function (previously selected from the QLI screen) is always active. IFCC trace is also available beginning with these EC levels.

IFCC trace does NOT require a selection from the Compare/Trace (QA) screen. Other trace functions (such as CSW and I/O instruction) still require a selection from the QA screen.

IFCC information is stored in the 4K trace buffer when an IFCC occurs. This buffer is displayed on the PSW and I/O trace screen (QDTP) in either normal or CE mode. IFCC information in the trace buffer includes:

- Device address
- Channel status word (CSW)
- Bus and tag line status
- Catalog number and message

### IFCC Trace Example

(To display,  
enter: QDTP)

```

*DISPLAY/ALTER*                PSW & I/O TRACE                PAGE 00
G GENERAL REGISTERS
C CONTROL REGISTERS             CSW      IFCC DEV=323  CSW=3000 0200 0002 0029
F FLOATING POINT REGISTERS     BUSIN=21 BUSOUT=11 CN=0C  ENG=35 33 06 5F 47
P CURRENT PSW                  TAGIN=  REQ OPL DIS ADR SEL STA SRV/DAT
K STORAGE KEY                  TAGOUT= ADR CMD DAT SRV SUP OPL SEL
V VIRTUAL STORAGE              INTERFACE CLEANUP TIMEOUT
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PROG SYS
SELECTION: TP
    
```

Notes:

1. In addition to IFCC trace entries (as shown above), the buffer may contain PSW and I/O trace entries when selections are made from the Compare/Trace screen (QA).
2. The trace buffer size is 4K. To display additional buffer information, press and hold the ALT key and press the 'Page Up' key.

#### Device Address (DEV)

The device address, indicated in the *DEV* field, is the channel and unit address (cuu) of the device that was active when the IFCC occurred.

#### Channel Status Word (CSW)

The CSW indicates channel and unit status at the time the IFCC occurred.

#### Engineering Data (ENG)

The five bytes of data labeled *ENG* are for engineering use.

### How to Display the IFCC Trace

The PSW and I/O trace buffer (which includes IFCC trace) is contained in 4K of auxiliary storage. To display the buffer, enter: QDTP

See the "IFCC Trace Example." Only one trace entry is shown, but many entries are possible. The entry displayed at the top of the screen is the most recent. To display possible additional entries, press and hold the ALT key and press the Page Up key. See Note.

**Note:** In addition to IFCC trace entries, PSW and I/O trace entries may also be displayed on this screen. This is possible when selections are made from the Compare/Trace screen (QA).

#### Bus and Tag Line Status

The data labeled *BUSIN* and *BUSOUT* indicates bus line status at the time the IFCC occurred.

Tag line status is indicated by the labels *TAGIN* and *TAGOUT*. The tag lines that were active at the time the IFCC occurred are intensified on the display screen.

#### Catalog Number (CN) and Message

The catalog number, labeled *CN*, is a coded indication of the reason for the IFCC.

The message text displayed on the last line of the IFCC entry is a short description of the reason for the IFCC. For a complete description, see "IFCC Catalog Numbers."

### IFCC Catalog Numbers and Descriptions

All channel failures sensed by channel microcode are assigned a catalog number (CN) that provides a coded description of the failure. Only those channel failures that result in interface control check (IFCC) are described here. (For a complete list, see "Catalog Numbers" in this section.)

- 04 ADR MISMATCH OR P-CHK AT ISS  
During initial selection, the address received either was not the same as the address sent or was out of parity.
- 06 DIS-IN DURING ISS STA-IN  
Disconnect-in was received before the end of initial selection. (The connected control unit cannot finish the operation.)
- 08 DIS-IN AT DATA END  
Disconnect-in was received before ending status. (The connected control unit cannot finish the operation.)
- 0A SEL-IN OR OPL-IN, ADR-IN TIMEOUT  
No response was received when the channel issued select-out to a request-in. The expected response was either an op-in/address-in sequence (a device was found) or a select-in tag (a device was not found).
- 0C INTERFACE CLEANUP TIMEOUT  
An interface line (except for request-in) was active after the channel released the device.
- 0E INVALID TAG SEQUENCE AT INTERFACE POLLING  
After select-in was received, an interface line (except for request-in) remained active. (The indicated device address may not be valid.)
- 40 SEL-IN DURING COMMAND CHAINING  
Select-in (address not found) was received during a command chaining sequence. (Select-in should not come up; the same device should be selected.)
- 42 P-CHK AT ISS STA-IN  
A bus-in parity check or *Any Check* (see Note 1) was sensed at initial selection status-in time.
- 44 INTERFACE TIMEOUT DURING ISS  
During initial selection, a tag line was either active or not active at the wrong time.

- 48 P-CHK AT END STATUS TIME  
A bus-in parity check or *Any Check* (see Note 1) was sensed at ending status time.
- 4A STA-IN HAD P-CHK AFTER REQ-IN SEQ  
A bus-in parity check or *Any Check* (see Note 1) was sensed after the *Load Loop* (see Note 2).
- 4E 2ND DEV NEEDS SHARED UCW BEFORE 1ST FINISHED  
A device that requires a shared UCW caused a load trap while another device was using the UCW.
- 6A DIS-IN DURING CHANNEL IDLE LOOP  
Disconnect-in was received while the channel was polling. (The indicated address may not be valid.)
- 6F P-CHK DURING ADR-IN COMPARE DURING ISS  
A bus-in parity check was sensed at address-in time of initial selection.
- C2 SHORT-BUSY SEQUENCE DURING COMMAND CHAINING ISS  
Command chaining was broken due to a short-busy sequence.
- C6 DATA REQUEST AFTER STOP-DATA GIVEN  
A request for data was received on a byte-multiplexer channel when it was not expected.
- C8 UNEXPECTED DATA REQUEST ON BLOCK CHANNEL  
A request for data was received on a block-multiplexer channel when it was not expected.
- E8 SEL-IN DURING ISS FOR SP DEVICE  
Select-in was received during initial selection for a support processor device (address not found).

**Note 1:** *Any Check* may be:

1. Wrong Length Record (No SLI flag)
2. Program or Protection Check
3. Chaining Check
4. Channel Data Check


**Note 2:** *Load Loop* is the standard request-in, op-in sequence.

# CHANNEL FAILURE ISOLATION

Use the following failure isolation procedure when the Channel Wrap Test indicates a failure.

1. Ensure that the machine power is on.
  2. Install the DIAG4 diskette and set the CE MODE switch to ON.
  3. Press and hold the ALT key, and press the DIAG key.
  4. Select option B (selected diagnostics mode) from the Diagnostics Mode General Selection screen.
  5. Enter test ID: M7 (In about two minutes the Special Channel Tests Selection screen is displayed.)
  6. Key in 02 and press ENTER.
- After you have selected the CWT (02) test, detailed run instructions and available options are displayed to aid you in running the tests.
7. Use the point-to-point drawing on this page to scope the failing line for a signal swing of 0.0 to +3.5 volts. If you are not able to isolate the failure, invoke your support structure.

- Be aware that the signal starts at the adapter card, travels across the board net, out its related Yx connector (card side), through its attached cable to the tailgate, and then through the wrap tool.
- The signal then returns from the tailgate, through a cable to the board and through its related Zx connector (card side), and across the board net to the adapter card input pin.



1. The adapter card pins shown are the same for each channel.  
To locate the adapter card for the channel being tested, use the following chart.

Channel	0	1	2	3	4	5
x2(Card)	F2	Q2	D2	R2	E2	S2

2. Select a vertical column of pins under the channel number of the channel being tested.
3. 01E gate connector pins shown are the same for each channel.  
To plug the wrap tool in the proper 01E gate connector for the channel being tested, use the following chart.

01E Tailgate

x1(Tag)	A1	B1	C1	D1	E1	F1
x2(Bus)	A2	B2	C2	D2	E2	F2

4. The Mark-In line is not tested.
5. For Bus/Tag pin numbering, see "Gate 01E (Channel Interface)" in the Locations section of this volume.

Model Groups 1 and 2

EC379814 02Oct81	PN 2676247	14 224
EC379837 28Jun82	2 of 2	

INTERFACE ADAPTER (IFA) CARD

+ NPL OP OUT	D	B	+ NPL BUS OUT 0
+ 5.0	.	2	1
+ NPL SRV. OUT	.	.	2
CMD OUT	.	.	3
ADR OUT	.	.	- 4.25
HOLD OUT	.	.	+ NPL BUS OUT 4
GND	x	.	5
+ NPL DATA OUT	.	.	6
SUPR OUT	.	.	7
SEL OUT	.	.	+ 6.0
MTR OUT	.	.	+ NPL BUS OUT P
	.	13	- 1.5
+ 5.0	J	G	- CHAN DATA BIT 0
- SIG 0	.	.	1
- SIG 1	.	.	2
- PARITY GOOD	.	.	3
- CHAN MTR IN	.	.	----
GND	x	.	4
- CTL IN 0	.	.	5
1	.	.	6
2	.	.	7
3	.	.	+ 6.0
- DATA MODE	.	.	- CHAN DATA BIT P
	.	.	- 1.5
PWR SEQ INHIB	P	M	- AC (STOP)
+ 5.0	.	.	- XFER OK 0
- ODD GATE	.	.	- XFER OK 1
TAG SENSE	.	.	- SCAN MODE
DATA SENSE	.	.	----
STATUS SENSE	.	.	- SUPR DATA 1
GND	x	.	- HALT ADAPTER
- IFA CHECK STOP	.	.	- INPUT MODE
+ LCA OP IN	.	.	+ CHAN MTR OUT
- SS MONITOR	.	.	+ 6.0
+ IN DIRECTION	.	.	+ LCA MTR IN
- SUPR DATA 0	.	.	- 1.5
+ NPL MTR IN	U	S	+ NPL BUS IN 0
+ 5.0	.	.	1
+ NPL STATUS IN	.	.	2
SEL IN	.	.	3
OP IN	.	.	- 4.25
SRV IN	.	.	+ NPL BUS IN 4
GND	x	.	5
+ NPL ADR IN	.	.	6
REQ IN	.	.	7
DISC IN	.	.	+ 6.0
DATA IN	.	.	+ NPL BUS IN P
MARK IN	.	.	- 1.5

Card Loc.	Board 01AA2					
	D	E	F	Q	R	S
CH No.	2	4	0	1	3	5

The following board pins are jumpered as indicated for a processor with the basic three channel configuration:

01AA2 - R2G12 to R2G13  
 01AA2 - E2G12 to E2G13  
 01AA2 - S2G12 to S2G13

TIO SINGLE CYCLE PROCEDURE

Procedure To Single Cycle TIO:

Note: The question mark (?) in steps 2, 3, 4, 5, and 6, indicate channel numbers.

1. Set machine to microstep.  
Key in QOM and press ENTER.
2. Set CH?CMD Reg to 20.  
Key in QVH?2820, and press ENTER.
3. Set sequence count to 00.  
Key in QVH?0700000000000000 and press ENTER.
4. Clear residual data from CHCCAR1 and 2.  
• Key in QVH?0900000000 and press ENTER, and then  
• Key in QVH?1100000000 and press ENTER.
5. Set CH?CMD Ready Latch to 1.  
Key in QVH?311 and press ENTER.
6. Set CH?SYNCO to device address, (example: OE).  
Key in QVH?12UU and press ENTER.
7. Start single cycle.  
Press START key and then press ENTER key.
  - Monitor the Tag and Bus lines.
  - After pressing the START and ENTER keys several times, the Tag and Bus lines change.

EC 379605 06Mar81	PN 5666344	14 225
EC 379814 02Oct81	1 of 2	

**CHANNEL LOCAL STORAGE LAYOUT  
(QVALn) OR (QDLn)**

	0	2	4	6	0	2	4	6
US:UNIT STATUS	n0	00 00	00 00	00 00	n1	00 00	00 00	00 00
BIT 0 ATTENTION		US	CS	KEY	LOGIC	CH	UCW	
1 STATUS MODIFIER			CSW	CCW	DEVADR	SWT	STAT	
2 CONTROL UNIT END			COUNT	ADDR				
3 BUSY								
4 CHANNEL END	n2	00 00	00 00	00 00	n3	00 00	00 00	00 00
5 DEVICE END								
6 UNIT CHECK		I/O	RETRY	CCW WORK				
7 UNIT EXCEPTION		ADR	CCW ADR	COUNT				
CS:CHANNEL STATUS	n4	00 00	00 00	00 00	n5	00 00	00 00	00 00
BIT 0 PCI		CCW	CCW			LIMIT	CHNL	PRIM
1 WRONG LENGTH RECORD		FLAG	COUNT			LOGOUT	DATA	STAT
2 PROGRAM CHECK								
3 PROTECTION CK	n6	00 00	00 00	00 00	n7	00 00	00 00	00 00
4 DATA CHECK							SEC.	IDAW
5 CHNL CONTROL CK							STAT	ADDR
6 CHNL INTERFACE CK								
7 CHAINING CHECK								
CCW FLAG	n8	00 00	00 00	00 00	n9	00 00	00 00	00 00
BIT 0 CHAIN DATA				SEQ				UCW
1 CMD CHAIN				FLAG				ADDR
2 SLI								
3 SKIP								
4 PCI	nA	00 00	00 00	00 00	nB	00 00	00 00	00 00
5 IDA						CATA		UCW
						LOG#		ORIG.
SEQFLAG:SEQUENCE FLAG	nC	00 00	00 00	00 00	nB	00 00	00 00	00 00
BIT 0 BURST MODE MARK								
1 POLL CTRL REQUEST								
2 LOGOUT PENDING								
3 CAI								
4,5,6,7								
0 0 0 1 SID	nE	00 00	00 00	00 00	nF	00 00	00 00	00 00
1 0 1 1 TIO								
1 1 0 0 CLEAR I/O								
0 1 0 1 HIO								
0 1 1 0 H DEV								
0 1 1 1 IPL or SP SID								

UCW STATUS:  
 BIT 0 UCW ACTIVE  
 1 UCW ON PCI QUEUE  
 2 UCW ON NORMAL QUE.  
 3 SEC. STATUS EXPECTED  
 4 DATA EXPECTED  
 5 DCC RECONNECT EXPECTED  
 6 PRIM.STATUS EXPECTED  
 7 DELAY DISCONNECT

CHSWT:CHANSWIT  
 BIT 0 PRIM STAT VALID  
 1 SEC STAT VALID

LIMIT CHNL LOGOUT DATA  
 SEE LCL CHART

PRIM STAT:PRIMARY STATUS

SEC.STAT:SECONDARY STATUS

CATALOG#:  
 SEE CATALOG NUMBER  
 CHART.

NOTE:  
 DISPLAY QVALn or QDLn:

CHNL	n
0	7
1	2
2	3
3	4
4	5
5	6

Model Groups 1 and 2

EC 379605 06Mar81	PN 5666344	14 230
EC 379814 02Oct81	2 of 2	



**LIMITED CHANNEL LOGOUT BIT DEFINITIONS**

Note: Limited Channel Logout (LCL) is at hex address B0-B3.  
To display the LCL: Key in QDMBO and press ENTER.

BIT	DEFINITION
0	When a channel or interface control check occurs, the channel posts an LCL and sets this bit to a zero (0).  Bit 0 = (0) = LCL stored in bytes (B0-B3) Bit 0 = (1) = LCL not stored (reset state)
1-3	Identity of the storage control unit (SCU) through which storage references were directed when an error was detected. When only one path exists between the channel and storage, the storage control unit has the identity of the processing unit.
4-7	Detect fields, identify the type of unit that detected the error. At least one bit is present in this field, and multiple bits may be set when more than one unit detects the error.  Bit 4 = CPU Bit 5 = Channel Bit 6 = Main Storage Control Bit 7 = Main Storage
8-12	Source field indicates the most likely source of error. Normally only one bit is present in this field. When interunit communication cannot be resolved to a single unit, such as when the interface between units is at fault, multiple bits may be set in this field. If detect and source fields indicate different units, the interface between them can also be considered as suspect.  Bit 8 = CPU Bit 9 = Channel Bit 10 = Main Storage Control Bit 11 = Main Storage Bit 12 = Control Unit
13	Reserved--Stored zero
14	Reserved--Stored zero
15	Reserved--Stored zero

BIT	DEFINITION
16-23	Field validity flags indicate the validity of the information stored in the designated fields. When the contents stored is correct, the validity bit is one. When the contents stored is unpredictable, the validity bit is zero. Validity bits for non-stored fields are meaningless. The fields designated are:  Bit 16 - Not used by 4341 Bit 17 = Reserved--Stored zero Bit 18 = Reserved--Stored zero Bit 19 = Sequence Code Bit 20 = Unit Status Bit 21 = Command Address and Key Bit 22 = Channel Address Bit 23 = Device address
24-25	Type of termination that has occurred is indicated by these two bits. This encoded field has meaning only when a channel control check or interface control check is indicated in the CSW. When neither of these two checks is indicated, no termination has been forced by the channel.  00 = Interface disconnect 01 = Stop, stack, or normal termination 10 = Selective Reset 11 = System Reset
26-27	Reserved--Stored zero
28	I/O error-alert bit when set to one indicates that the limited channel logout resulted from the signaling of I/O error alert on the I/O interface by the indicated unit. This signal indicates that the control unit has detected a malfunction that prevents it from communicating properly with the channel. The channel in response, performs a malfunction reset and sets the interface control check.

BIT	DEFINITION
29-31	<p>Sequence count identifies the I/O sequence in progress at the time of error. It is meaningless if stored during the execution of HALT I/O or HALT DEVICE. For all cases, the channel program address, if validity stored and if nonzero, is the address of the current CCW + 8.</p> <p>The sequence code assignments are:</p> <p>000 A channel detected error occurred during the execution of a TEST I/O or CLEAR I/O instruction.</p> <p>001 Command-out with a nonzero command byte on bus-out has been sent by the channel, but device status has not yet been analyzed by the channel. This code is set with a command-out response to address-in during initial selection.</p> <p>010 The command has been accepted by the device, but no data has been transferred. This code is set by a service-out or command-out response to status-in during an initial selection sequence, if the status is either channel-end alone, channel-end and device-end, or channel-end, device-end, and status modifier, or all zeros.</p> <p>011 At least one byte of data has been transferred over the interface. This code is set with a service-out response to service-in and, when appropriate, may be used when the channel is in an idle or polling state.</p> <p>100 The command in the current CCW has either not yet been sent to the device or else was sent but not accepted by the device. This code is set when one of the following conditions occurs:</p> <ol style="list-style-type: none"> <li>1. When the command address is updated during command chaining or a START I/O</li> </ol>

BIT	DEFINITION
29-31	<p>Continued</p> <ol style="list-style-type: none"> <li>2. When service-out or command-out is raised in response to status-in during initial selection sequence with the status on bus-in including attention, control unit end, unit exception, busy, status modifier (without channel-end and devien-end), or device-end (without channel-end).</li> <li>3. When a short, control-unit-busy sequence is signaled.</li> <li>4. When command retry is signaled.</li> <li>5. When the channel issues a TEST I/O command rather than the command in the current CCW.</li> </ol> <p>101 The command has been accepted but data transfer is unpredictable. This code applies from the time a device comes on the interface until the time it is determined that a new sequence code applies. It may be used when a channel goes into the polling or idle state and it is impossible to determine that code 2 or 3 applies. It may also be used at other times when a channel cannot distinguish between code 2 or 3.</p> <p>110 Reserved</p> <p>111 Reserved</p>


Model Groups 1 and 2

EC 379599 14May80	PN 5666345	14 240
EC 379605 06Mar81	2 of 2	

## CONNECT EXTERNAL INTERRUPT CABLE

**Note:** This procedure is designed for use with the Installation Manual.

1. Locate 01G tailgate; see *Installation Manual*, page 48 020, Figure 1.
2. Remove 01G tailgate cover by removing screws **A** and **B**.
3. Connect external interrupt cable **C** in 01GA1 as shown.
4. Reinstall 01G tailgate cover.
5. Return to *Installation Manual*, page 48 070, step 14.0.






# MSS SERVICE AIDS

## LOGIC RESET

LOGIC RESET SIMPLIFIED DIAGRAM:



Note 1: To L2S13 on machines with cards in L2 and M2.  
 Note 2: To L2S13 on machines with no card in M2.


# SERIAL NUMBER CARD

The serial number card (location 01AB2S4) is replaced only when there is indication that the card has failed. The new serial number card must be set with the last three digits of the machine serial number. This is done by setting the card exactly like the one being replaced.

The following is an example of how to setup a serial number card.

Ground = Active; +5V = Inactive

Example Setup → Serial Number 012348  
 Hundreds  
 Tens  
 Units




Note: X indicates a card test point; they are not used in setting the serial number.

SERIAL NUMBER CARD  
 Location: 01AB2S4


Model Groups 1 and 2

EC 379814 02Oct81	PN 5666346	14 310
EC 379837 28Jun82	2 of 3	

OCP TO HWS INTERCONNECTIONS



OCP TO 4341 CABLE ROUTE




Model Groups 1 and 2

EC 379814 02Oct81	PN 5666346	14 315
EC 379837 28Jun82	3 of 3	







# OCF TO CTCA INTERCONNECTIONS



## LOGIC LEVELS FOR J4 CARD-PINS



BURST MODE CONTROL DIAGRAM



Model Groups 1 and 2

EC 379814 02Oct81	PN 2676249	14 320
	2 of 2	

## BASIC CHECK LIGHT

The Basic Check light, on both the operator control panel (OCP) and the CE panel, normally indicates:

- The CE MODE switch is set to ON.
- A power sequence is not complete.
- The support processor (SP) cannot communicate with the console display.
- An SP reset failed.

In addition, unusual conditions (such as low line voltage, frequent EMC hits, or SP microcode errors) can cause the Basic Check light to turn on.

For aid in diagnosing and repairing problems indicated by the Basic Check light, see the "Basic Check Light Conditions" chart shown on this page. As shown in the chart, some Basic Check light conditions are identified by SP stop words. To display stop words, see the following information.

### How to Display Stop Words

A stop word is a two-byte SP storage address displayed at the CE panel. To display a stop word:

1. Press SP switches A and C together and then release. This clears the display.
2. Press and hold SP switch B to display the high-order byte.
3. Press and hold SP switches A and B together to display the low-order byte.

For more information, see "Stop Words" in the "Diagnostic Information" section.

### Basic Check Light Conditions:

BASIC CHECK CONDITION	DESCRIPTION	REPAIR ACTION
The CE MODE switch is set to ON.	The BASIC CHECK light is normally turned on when the CE MODE switch (on the CE panel) is set to ON.	Set the CE MODE switch to NORMAL.
A power sequence is not complete.	The BASIC CHECK and POWER IN PROCESS indicators are on with one of the following: <ul style="list-style-type: none"> <li>• A hardwired sequence (HWS) failure is indicated when one or more POWER FAIL indicators (on the CE panel) is on.</li> <li>• A processing unit power failure is indicated when a reference code with a UU field of 'ix' and an S field of 'E' (UUrrris) is displayed on the console display.</li> </ul>	If you cannot repair the problem using the MAPs (such as when it is intermittent), invoke your support structure.
The SP cannot communicate with the console display.	When the SP cannot communicate with the console display during an SP IML, the microcode waits one minute and then turns on the BASIC CHECK light and loops at address x'16DC' (See "How to Display Stop Words.>").  After an SP IML, if the SP cannot communicate with the console display, the microcode turns on the BASIC CHECK light and goes into a wait. No stop word is displayed.	<ol style="list-style-type: none"> <li>1. Ensure that the coaxial cable from port 0 to the console display is securely attached. If possible, replace it.</li> <li>2. The console display may be failing. If possible, swap it with another unit or replace cards.</li> <li>3. Replace these cards on the 01AB2 board: R2, S2, and E2. (Ensure that R2 is P/N 6835933 or later.)</li> </ol>
An SP reset failed.	Failure to reset the LCA results in turning on the BASIC CHECK light and looping at address x'16E8' (See "How to Display Stop Words.>").  Depending on what failed to reset, other stop words are possible. If the problem is intermittent, the BASIC CHECK light may be reset and processing will continue.	If you cannot repair the problem using the MAPs (such as when it is intermittent), invoke your support structure.
Unusual conditions.	Other conditions, such as low line voltage, frequent EMC hits, or SP microcode errors, can result in turning on the BASIC CHECK light.	<p>Check that:</p> <ol style="list-style-type: none"> <li>1. Line voltage is within the ranges specified in the "IBM 4300 Processor Installation Manual - Physical Planning", GA24-3667.</li> <li>2. EMC logging is disabled. (Display the QK screen.)</li> <li>3. All available microcode patches are installed.</li> </ol> <ul style="list-style-type: none"> <li>• If you cannot perform the checks above (such as when the system is hung), invoke your support structure.</li> </ul>



## POWER SERVICE AIDS


### POWER ALD EXAMPLE

The power ALDs use some new symbols and printing formats. The main difference is that multiple wires are represented by a single line with strand numbers. Detailed information is shown on the next pages.

Model Groups 1 and 2

EC 379594 10Mar80	PN 5666347	14 405
EC 379814 02Oct81	1 of 4	


POWER ALD EXAMPLE (CONT.)



Model Groups 1 and 2

EC 379594 10Mar80	PN 5666347	14 410
EC 379814 02Oct81	2 of 4	

POWER ALD EXAMPLE (CONT.)




Model Groups 1 and 2

EC 379594 10Mar80	PN 5666347	14 415
EC 379814 02Oct81	3 of 4	

POWER ALD EXAMPLE (CONT.)

PSEUDO BLOCK - Symbolically represents a series of connections on a board.




Model Groups 1 and 2


EC 379594 10Mar80	PN 5666347	14 420
EC 379814 02Oct81	4 of 4	




STANDARD POWER INTERFACE (SPI)



\*If present



# STANDARD POWER INTERFACE (SPI)



EC 379605 06Mar81	PN 5666433	14 430
EC 379839 30Dec82	2 of 2	

# REMOTE SUPPORT FACILITY SERVICE AIDS

## REMOTE DATA BANK INVOKE PROCEDURE

### Introduction

The Remote Support Facility (RSF) allows linking the operator console, through a switched network, to a support center or to a data bank system (if available) for diagnostic assistance. The RSF is for service usage, and is not meant to be used as a teleprocessing port. The Remote Operator Console Facility (ROCF) is for customer use. (ROCF is an extension of RSF.) For additional detail, see *Volume 18, "Console Functions," "Remote Operator Console Facility (QFB)."*

**Warning: The Remote Data Bank (RDB) cannot be invoked if using the Remote Operator Console Facility (ROCF); and the ROCF cannot be used if the RDB is invoked.**

If the maintenance package does not successfully resolve a problem, the on-site service personnel can invoke a data bank operation (if a data bank system is available) for additional diagnostic information. The RSF also enables a remote specialist to assist on-site service personnel in problem resolution by observing and initiating functional operations of the 4341. The RSF permits remote operation of all system functions except those requiring manual intervention (power on/off, IML, initial I/O control, etc.).

### Remote Support Facility Keys

Two keys on the 4341 operator console keyboard are dedicated to the RSF:

1. Communications Request (COMM REQ) Key - This key initiates voice or terminal communication between an on-site service representative and a remote specialist. Initiating a communications request can be done by either the on-site service representative or the remote specialist.
2. Line Disconnect (LINE DISC) Key - This key can be used to stop RSF initialization. It can also be used to disconnect the data link.

## Data Bank Mode

If the maintenance package does not successfully resolve a problem, the on-site service personnel can invoke a data bank operation (if a data bank system is available) for additional diagnostic information.

In Remote Data Bank (RDB) mode, the 4341 console operates as a data bank system terminal. For details concerning the use of RDB mode, see your support structure.

## Data Bank Invoke Procedures

To establish a data bank connection:

1. Ensure that the 4341 has the required hardware installed. The hardware consists of two cards. Information on the type of cards, and card setups is in the *Installation Procedures* in volume 18.

### Note:

- If you install the cards, run the diagnostics (MSS option diagnostics, selection E0) before proceeding.
  - Also ensure that a coupler and dataphone are available.
2. Set the NORMAL/CE switch to CE MODE and stop the IPU (QOM).
  3. Select the General Select screen:
    - a. Key in Q next to SELECTION.
    - b. Press the ENTER key.
  4. Select the System Configuration screen:
    - a. Key in QFS next to SELECTION.
    - b. Press the ENTER key.
    - c. Write the EC and REA levels on paper for later reference.
  5. Select the RDB Initialization screen:
    - a. Key in QFD.
    - b. Press the ENTER key.
      - MACHINE TYPE - The data in this field is supplied by the microcode.
      - MACHINE SERIAL NO. - The data in this field is supplied by the microcode.
      - EXTERNAL MODEM INSTALLED - You supply this data.  
You must enter the proper response (N for internal modem; Y for external modem) depending on the hardware configuration. The default answer is N.

6. Put the correct response into the input field of the screen.

7. Press ENTER.

**Note:** The LINE DISC key is now functional.

8. Invoke your support structure.

## Data Bank Operations

Follow the instructions in your support structure.

## Data Bank Disconnect Procedures

Follow the instructions in your support structure.

## Data Bank Mode Restrictions

1. The following 4341 operator console system function keys are NOT supported in RDB mode:

START	CHG DPLY
STOP	SPM/O
INTR	MODE SEL
COMM REQ	DIAG
**PAGE UP	PAGE DOWN

\*\* The (PAGE UP) key transfers patches to diskettes for machines at any of the following microcode EC levels: 154323, 856093, 866868 or above.

2. After the Data Bank mode is terminated, the state of the 4341 is unpredictable. SP reset, re-IML, or re-IPL is necessary, depending on the state of the 4341 at that time.

## Remote Console Support

For Remote Console Support, invoke your support structure.



**REMOTE SUPPORT FACILITY (RSF)  
DIAGNOSTICS**

**EIA ADAPTER TEST (Cable Part 8482930)**

**Note:** To perform this diagnostics, ensure:

- The machine microcode level precedes **Microcode EC 154319**.
- **DIAG4** Disk is mounted,
- **POWER ON/IML** was pressed,
- The **MSS DIAGNOSTIC TEST OPTION SELECT** screen is displayed.

This test, as illustrated to the right, includes:

1. D0 Adapter Diagnostic test; which isolates a failing EIA card.
2. D0 Cable Wrap Diagnostic test; which isolates the failing RSF cable (part 8482930).

The procedure is:

**\*\*\*D0 Adapter Diagnostic\*\*\***

1. Key in D0 and press ENTER.

**Note:** A successful test run is indicated when the **TEST xx RUNNING** message is cleared.


**\*\*\*D0 Cable Wrap Diagnostic\*\*\***

2. Press **POWER OFF** on OCP.
3. Remove card 01AA2K4 **A**.
4. Move jumper **B** from D-\* to \*-E.
5. Place card **A** back to its position.
6. Connect wrap plug **C** to end of cable.
7. Press **POWER ON/IML** on the OCP.
8. Key in D0 and press ENTER.  
Wrap test now runs.

**Note:** A successful test run is indicated when the **TEST xx RUNNING** message is cleared.

9. Move jumper **B** back to D-\* position.
10. Remove wrap plug from end of cable, and connect the cable plug back in telephone connector.
11. Return to the document that lead you here.

**EIA-CARD TEST DIAGRAM**




40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100



RSF CARDS AND WIRING CONFIGURATIONS

38LS/(U.S.A. and CANADA) CONFIGURATION  
(External Cable Part 8482931)



Line Type	Meaning
—	These lines are checked during the "DO" option test.
- - - -	These lines are not check during the "DO" option test.


Model Groups 1 and 2

EC 379599 14May80	PN 5666414	14 525
EC 379607 05Jun81	1 of 1	






**38LS/(JAPAN) CONFIGURATION**  
**(External Cable Part 8482931)**



Line Type	Meaning
—	These lines are checked during the "DO" option test.
- - -	These lines are not check during the "DO" option test.




**LINE PLATE CONFIGURATION**  
(External Cable Part 8482934)






**EIA ADAPTER CONFIGURATION**  
(External Cable Part 8482930)




Line Type	Meaning
—	These are RSF function lines. They are checked during the "EO" option test.
----	These lines are used by the diagnostic function only.
-.-.-	These lines are not used by the 4341 Processor.




Model Groups 1 and 2

EC 379600 30Jun80	PN 5666417	14 555
EC 379814 02Oct81	1 of 2	

**EIA ADAPTER CONFIGURATION**  
 (External Cable Part 8482933)




Line Type	Meaning
—	These are RSF function lines. They are checked during the "E0" option test.
----	These lines are used by the diagnostic function only.
-•-•-	These lines are not used by the 4341 Processor.



Model Groups 1 and 2

EC 379600 30Jun81	PN 5666417	14 556
EC 379814 02Oct81	2 of 2	

**PROTECTIVE COUPLER CONFIGURATION**  
(External Cable Part 4109531)



Line Type	Meaning
——	These lines are checked during the "DO" option test.
----	These lines are not checked during the "DO" option test.

Model Groups 1 and 2

EC 379602 15Sep80	PN 2676261	14 565
EC 379606 20Apr81	1 of 1	

10/10/1975





## CONSOLE FUNCTIONS SERVICE AIDS

### PATCH INSTALLATION AND UPDATE PROCEDURE


A patch is a set of commands that enables you to modify the diskette for special applications or to fix a problem.

This procedure should be used to install patches as a result of field detected problems for machines at any of the following microcode EC levels: 154323, 856093, 866868 or higher.

Patches can be automatically transferred to the diskette by using the remote support facility (RSF) or by entering the patch manually.

The "Patch Installation Flowchart" illustrates the procedure and the numbers direct you to step sequences in the procedure. The flowchart should be reviewed before starting.

PATCH INSTALLATION FLOW CHART



### AUTOMATIC PATCH INSTALLATION

Sequences **1** and **2** can be performed only if the remote support facility is installed and a remote data bank is available.

#### **1** \*\*\*\*\*Obtain Necessary Patches\*\*\*\*\*

1. Set CE MODE switch to ON.
2. Press POWER ON/IML.
3. Key in QFS to display the System Configuration screen.
4. Record the EC, REA, and serial numbers of the machine.
  - Use this data while attached to the remote data bank to identify the correct patches for the machine.
5. Invoke your support structure for RSF initialization.

#### **2** \*\*\*\*\*Patch Installation\*\*\*\*\*

**Note:** To perform the following steps, ensure that the machine has the remote support facility installed.

1. Locate the patch you need.
2. Verify, activate, and install the patch on the diskette as follow:
  - a. Insert the diskette you want to update.
 

**Note:** If a FUNCT diskette is updated during this procedure, ensure that both FUNCT diskettes are updated.
  - b. Press and hold down the ALT key; then press the PAGE UP key.
  - c. Release both keys.
    - Cursor is positioned at the END line (line 13). For reference see "Patch Sample" on the following page.
  - d. Enter your first initial, last name, month, date, and year in the indicated fields on the END line; then press ENTER.
 

**Warning:** Unpredictable error(s) occur if patch does not apply to your EC/REA level of diskette.

    - Patch update action begins.
    - The patch is verified, activated, and permanently installed on the diskette.
  - e. Observe and follow screen messages.
    - If the patch is already installed on the inserted diskette, a message indicates that the patch is active.
    - When the patch installation action is complete, the following message is displayed:

PATCH IS ACTIVE  
PRESS ENTER TO CONTINUE

3. Repeat steps 1 and 2 of sequence **2** for any additional patch transfers to all diskettes that need to be updated during this procedure.

#### Model Group 2

EC 379808 06Mar81	PN 2676262	14 605f
EC 379837 28Jun82	1 of 2	

## MANUAL PATCH INSTALLATION

The following sequences should be performed for manual patch installations for any of the following microcode EC levels: 154323, 856093, 866868, or higher.

### 3 \*\*\*\*\*Obtain Patch List\*\*\*\*\*

1. Set **CE MODE** switch to **ON**.
2. Press **POWER ON/IML**.
3. Key in **QBTP** and press **ENTER**.
  - Displays the patch list.
4. Make a copy of the patch names.
  - Use this data while communicating with your support structure to identify the patches for the machine.

### 4 \*\*\*\*\*Obtain Necessary Patches\*\*\*\*\*

1. Key in **QFS** to display the System Configuration screen.
2. Record the EC, REA, and serial numbers of the machine.
  - Use this data while attached to the remote data bank to identify the correct patches for the machine.
3. Invoke your support structure to get the patches needed; then return.

### 5 \*\*\*\*\*Patch Installation\*\*\*\*\*

1. Key in **QBFpatchname** and press **ENTER**:
  - The patchname is on line 01 **A** of the patch you copied. For reference, see "Patch Sample."
2. Enter the patch data (from line 01 through 13) exactly as it appears on the copy.
  - Press **ENTER** after you enter each line.
    - This checks the syntax of the line.
  - Note:** If an error is found, the cursor is positioned under the error.
3. Enter an **s** in any edit command input area **B**; and then press **ENTER**:
  - The cursor is positioned at the **END** line **C**.
4. Enter your first initial, last name, month, and day in the indicated fields on the **END** line **C**.
5. Press **ENTER**:
  - The patch is verified, activated, and permanently installed on the diskette.

### 6. Observe and follow screen messages:

- When the patch installation action is complete, the following message is displayed:

PATCH IS ACTIVE  
PRESS ENTER TO CONTINUE

- The **PATCH LIST (QBTP)** screen is displayed when **ENTER** is pressed.
  - ACTIVE should appear next to the name of the patch you just entered.

**Note:** If the screen message reads **WGN: CHECK ERROR**:

- The patch may be copied wrongly from the support system (if it was hand copied).
- The patch may be entered wrongly.
  - Return to step 2 of sequence **5** to make correction.
- The CRC **D** may be in error.
  - Return to step 2 of sequence **5** to make correction.
- The patch may be in error.
- The patch may not be for your diskette EC/REA level.

If you are unable to correct the problem, invoke your support structure.

7. Repeat steps 1 through 6 of sequence **5** for each patch installation; then continue.


### 6 \*\*\*\*\*Patch Copy to Backup Disk\*\*\*\*\*

1. Record the patch names to be copied on the backup FUNCT Diskette.
2. Key in **QBKpatchname** and press **ENTER**.
  - Patchname is one of the names you recorded.
3. Follow the prompting messages on the screen.


**Note:** The **TO** disk is the backup **FUNCT** diskette; the **FROM** disk is the diskette that contains the patches.

4. Key in **QBApatchname** and press **ENTER**.
  - Patchname is one of the names you recorded.
  - This command verifies, activates, and places the patch in the active status.
5. Repeat steps 1 through 4 of sequence **6** for each patch to be transferred to the backup **FUNCT** diskette.

## SAMPLE PATCH



## SAMPLE QBTP SCREEN



Model Group 2

EC 379808 06Mar81	PN 2676262	14 606f
EC 379837 28Jun82	2 of 2	

## I/O AND CHANNEL TRACE PROCEDURE

This trace procedure is a system problem determination tool for 4341 Processors.

The trace function stores the results of the trace operations in a 4K buffer in auxiliary storage. The results of a trace operation can be displayed on the QDTP screen. A description of the data on the QDTP screen is on page 44 300 of *Volume 18*. System performance impact is very small.


**Note:** The IFCC trace function is available for machines at any of the following microcode EC levels: **154322**, **856092**, **866867**, or higher. No manual intervention is needed to activate this function. For details, see "Interface Control Check (IFCC) Trace," page 14 223.

This procedure explains the use of I/O and Channel tracing and is sensitive to microcode EC updates. The following pages apply to the microcode EC levels indicated:

- **154322 or lower:** 14 616 through 14 618.
- **154323 or higher:** 14 619 through 14 621.
- **856XXX:** 14 619 through 14 621.
- **866XXX:** 14 619 through 14 621.

## I/O AND CHANNEL TRACE FLOW CHART

This flowchart shows the basic format for performing the I/O and channel trace procedure as outlined in the example.



Model Groups 1 and 2

EC 379604 05Dec80	PN 2676230	14 615
EC 379605 06Mar81	1 of 4	



## I/O and Channel Trace Example

This example shows you how to set and control I/O and channel trace functions. You may need the help of your support structure to analyze the output of the trace function.

### 1 \*\*\*\*\*Symptom\*\*\*\*\*

- The system is in *wait state*.

### 2 \*\*\*\*\*Machine Status\*\*\*\*\*

- Customer was IPLed on device 380 with output to channel 0.
- The Current PSW screen *W* indicates the *wait bit* *W* is set.
- A possible channel or I/O problem is present.

### 3 \*\*\*\*\*Trace Options Selected\*\*\*\*\*

- Key in *QA+* and press **ENTER**.
- Key in *QAWO0..* and press **ENTER**.
- Key in *QAWO380* and press **ENTER**.
- Key in *QAWW* and press **ENTER**.
- Key in *QAWP* and press **ENTER**.

A description of these options is on page 14 616.

### 4 \*\*\*\*\*Restart Failing Operation\*\*\*\*\*

- Key in *QLP* and press **ENTER**.  
Activates the trace functions specified.

**Note:** *This is only one of the ways to activate the trace. The object is to activate the operation that you want to trace.*

## SAMPLE QDP SCREEN

```

*DISPLAY/ALTER*
G GENERAL REGISTERS
C CONTROL REGISTERS
F FLOATING POINT REGISTERS
P CURRENT PSW
K STORAGE KEY
V VIRTUAL STORAGE
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PROG SYS
SELECTION: PO
MAN WAIT TEST

          A CURRENT PSW
          FE02 0000 8000 0EDB
          B
BC: CHNLMSK.E
EC: R TIE PSW.KEY CMWP ILC CC PROG.MASK
    1111 1110 0000 0010 10 0 0000

INSTRUCTION ADDRESS: 000EDB

ADDRESS IN HEXADECIMAL
OTHER DATA IN BINARY

          ==>
370 TIMER: ON INSTR STOP DATA: 8017 R ADDR: 000EDB
    ADDR-COMP: TRWR TYPE: ALLIOP _ADDR: 380
              4341

9473 9473

```

Model Groups 1 and 2

EC 379604 05Dec80	PN 2676230	14 617
EC 379605 06Mar81	3 of 4	

**I/O and Channel Trace Example (Continued)**

**5 \*\*\*\*\*Problem determination\*\*\*\*\***

1. When a failure is detected or suspected, press **STOP**, **MODE SEL**, and key in **QDTP**.
2. The **PSW and I/O TRACE** **C** screen is now displayed.  
If you press and hold **ALT** and press **Page up**, any additional trace screens are displayed.
3. The **CC** value of 3 **D** indicates the device 01F is not available to the system.

**6 \*\*\*\*\*Problem Fix\*\*\*\*\***

1. Display the Program Load screen.
  - Key in **QL** and press **ENTER**.
    - The **CONSOLE ADDR** **E** is in error.
2. Key in **T001F** and press **ENTER**.
  - Changes the **CONSOLE ADDR** **E** to **01F**.

**7 \*\*\*\*\*Verification of Fix\*\*\*\*\***

1. Perform an IPL.
  - Key in **P** and press **ENTER**.
    - If system indicates no error, problem is fixed. Continue with next step-sequence.
    - If system does indicate an error, continue with next step-sequence, and then follow standard maintenance procedures.

**8 \*\*\*\*\*Trace Termination\*\*\*\*\***

1. Reset the trace functions.
  - Key in **QAN** and press **ENTER**.
2. Reset the assist on the Program Load screen.
  - Key in **QLIR** and press **ENTER**.
  - Key in **QLM** and press **ENTER**.
    - IMLs the processor.

**SAMPLE QDTP SCREEN**

```

*DISPLAY/ALTER*
G GENERAL REGISTERS
C CONTROL REGISTERS
F FLOATING POINT REGISTERS
P CURRENT PSW
K STORAGE KEY
V VIRTUAL STORAGE
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PROG SYS
SELECTION: TPOO

          C PSW & I/O TRACE
          TYPE  CC DEV  INT/CAW/CNT  OLD PSW/CCW/CSW
          OPS TIO 3 01F
          OPS TIO 0 380
          OPS TIO 1 380 0000 0001 0000 0168 0C00 0000
          OPS TIO 2 380 0000 0078 0000 0168 0C00 0000
          OPS SID 0 380 0000 0160 0200 0080 0000 0050
          OPS TIO 0 380
          OPS TIO 1 380 0000 0001 0000 0168 0C00 0000
          OPS TIO 2 380 0000 0082 0000 0168 0C00 0000
          OPS SID 0 380 0000 0160 0200 0080 0000 0050
          OPS TIO 0 380
          OPS TIO 1 380 0000 0001 0000 0168 0C00 0000
          OPS TIO 2 380 0000 0081 0000 0168 0C00 0000
          OPS SID 0 380 0000 0160 0200 0080 0000 0050
          OPS TIO 0 380
          OPS TIO 1 380 0000 0001 0000 0168 0C00 0000
          OPS TIO 380 0000 0074

          ==>
          370 TIMER: ON INSTR STOP DATA: 8017 R ADDR: 000EDB
          ADDR-COMP: TRWR TYPE: ALLIOP ADDR: 0..
                   4341
    
```

00= The trace area page number.

This sample QDTP screen applies to machines with a microcode EC level of **154321** or lower.

**SAMPLE QDTP SCREEN**

```

*DISPLAY/ALTER*
G GENERAL REGISTERS
C CONTROL REGISTERS
F FLOATING POINT REGISTERS
P CURRENT PSW
K STORAGE KEY
V VIRTUAL STORAGE
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PROG SYS
SELECTION: TPOO

          C PSW & I/O TRACE
          OPS TIO  CC=3 DEV=01F  CNT=0023 2A4D
          OPS TIO  CC=0 DEV=380
          OPS TIO  CC=1 DEV=380  CSW=0000 0168 0C00 0000
          OPS TIO  CC=2 DEV=380  CNT=0000 0078
          OPS SID  CC=0 DEV=380  CCW=0200 0080 0000 0050
          CAW=0000 0160
          OPS TIO  CC=0 DEV=380
          OPS TIO  CC=1 DEV=380  CSW=0000 0168 0C00 0000
          OPS TIO  CC=2 DEV=380  CNT=0000 0082
          OPS SID  CC=0 DEV=380  CCW=0200 0080 0000 0050
          CAW=0000 0160
          OPS TIO  CC=0 DEV=380
          OPS TIO  CC=1 DEV=380  CSW=0000 0168 0C00 0000
          OPS TIO  CC=2 DEV=380  CNT=0000 0081
          OPS SID  CC=0 DEV=380  CCW=0200 0080 0000 0050
          CAW=0000 0160
          OPS TIO  CC=0 DEV=380
          OPS TIO  CC=1 DEV=380  CSW=0000 0168 0C00 0000

          ==>
          4341
    
```

00= The trace area page number.

This sample QDTP screen applies to machines with a microcode EC level of **154322** or higher.

**SAMPLE QL SCREEN**

```

          *PROGRAM LOAD*
PERFORM IML: M
MODE-ASSIST MENU: I
*MODE*
S/370
*ASSISTS*
(NONE)
IML AT POWER-ON: X1 YES
                  X2 NO
STATUS IPL COMPLETE
SELECTION:
MAN WAIT TEST

          V1 CS TEST
          V2 MS DATA
          V3 MS ADDR
          V4 SCOPE LP
          S SAVE STG
          Y NO CS LD
PERFORM IPL: P
IPL UNIT ADDR: U 380
RESET TYPE: R1 LOAD CLEAR
             R2 LOAD NORMAL
CONSOLE MODE: N1 PTR/KYBD
              N2 DISPLAY
CONSOLE ADDR: T0 010 T2 DSC
              T1 DSC H3 DSC
COPY KEY DEV: K3
Q GENERAL SELECTION
Z RETURN TO PROG SYS

          ==>
          370 TIMER: ON INSTR STOP DATA: 8017 R ADDR: 000EDB
          ADDR COMP: TRWR TYPE: ALLIOP ADDR: 0..
                   4341
    
```

**E**

**Model Groups 1 and 2**

EC 379604 05Dec80	PN 2676230	14 618
EC 379605 06Mar81	4 of 4	

\*\*\*\*\*Procedure\*\*\*\*\*

The pages that follow should *only* be used for machines at any of the following microcode EC levels:

- 154323 or higher
- 856XXX
- 866XXX.

**Note:** The numbers in this procedure direct you to the same sequence of steps in the "I/O and Channel Trace Flowchart" page 14 615, and "I/O and Channel Trace Example," pages 14 620 and 14 621.

- 1 Observe the machine symptoms.  
This is based on the condition of the system when you reached the customer site.
- 2 Obtain machine status.  
This is based on information you obtain from the system.
- 3 Select the trace options needed.
  - This is based on the symptoms, status, and/or experienced with the type of problem.
- 4 Restart the operation that fails or perform an IML.
- 5 Perform problem determination.
  - Key in QDTP to display the trace dump.
  - Analyze the results.

For description of trace output, see page 44 300.
- 6 Fix the problem.
- 7 Verify the fix.
- 8 Reset the trace function.
  - Key in QAN.

Return the system to the customer.

Sample Trace Control (QDTC) Screen

```

*DISPLAY/ALTER*
G GENERAL REGISTERS
C CONTROL REGISTERS
F FLOATING POINT REGISTERS
P CURRENT PSW
K STORAGE KEY
V VIRTUAL STORAGE
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PROG SYS
SELECTION: TC

* PSW TRACE CONTROLS *
ALL:  LOAD I/O MCK PCK SVC EXT VM
      Y  N  N  Y  Y  N  N

* I/O TRACE CONTROLS *
CHANNEL  UNIT  CSW  OPS
0        1F   N    SIO
1        91   N    SIO
2        Y    Y    Y
3        80   N    HIO
4        N    N    N
5        N    N    N

==>
INSTR STOP
4341
    
```

Y = YES/ALL  
N = NO/NONE

OPS = CIO  
HDV  
SIO  
TIO  
HIO  
TCH

Input parameters. These parameters are used to direct the actions outlined by this Trace Control screen.

I/O INSTRUCTION CHART

OPS	Instruction Type
CIO	Clear I/O
HDV	Halt Device
SIO	Start I/O
TIO	Test I/O
HIO	Halt I/O
TCH	Test Channel

I/O TRACE CONTROLS DEFINITIONS

CHANNEL Defines the channel being addressed for tracing.

UNIT Defines the unit(s) to be traced.

- A "Y" in this column activates a trace for all units on the specified channel.
- A "N" blocks all trace functions to all units on the specified channel.
- A two-digit hex address can also be entered in this column to specify a specific device (unit) to be traced.

CSW Channel Status Word, CSW-Swap functions.

- A "Y" in this column activates the CSW-Swap trace function on channel and unit(s) specified.
- A "N" blocks all CSW-Swap tracing of the specified channel and unit(s).

OPS Defines one, all, or none of the I/O instructions defined in the OPS column and in the "I/O Instructions Chart," to be traced.

PSW TRACE CONTROLS DEFINITIONS

ALL: Defines all PSW-Swap functions to be traced.

LOAD Load PSW-Swap trace function.

I/O Input/Output PSW-Swap trace function.

MCK Machine-check PSW-Swap trace function.

PCK Program-check PSW-Swap trace function.

SVC Supervisor call PSW-Swap trace functions.

EXT External PSW-Swap trace function.

VM Virtual machine assist PSW-Swap trace function.

Note: When a "Y" is placed under the ALL:, this "Y" is replaced with a "Y" and a "Y" is placed under each PSW type.

## I/O and Channel Trace Example

This example shows you how to set and control I/O and channel trace functions. You may need the help of your support structure to analyze the output of the trace function located on the QDTP screen.

### 1 \*\*\*\*\*Symptom\*\*\*\*\*

- The system is in *wait state*.

### 2 \*\*\*\*\*Machine Status\*\*\*\*\*

- Customer was IPLed on device 380 with output to channel 0.
- The Current PSW screen **A** indicates the *wait bit* **B** is set.
- A possible channel or I/O problem is present.

### 3 \*\*\*\*\*Trace Options Selected\*\*\*\*\*

- Key in *QDTC* and press **ENTER**.
  - Displays the Trace Control (QDTC) screen.
  - Refer to "Sample Trace Control (QDTC) screen" during the following steps.
  - Do not press **ENTER** until all trace selections are complete.
    - This example indicates when to press **ENTER**.
- Activate the PSW-Swap trace functions:
  - Enter a *Y* under **ALL**: **C**.
- Activate the CSW-swap trace function for *all* channels:
  - Key a *Y* in each of the input areas of the **CSW** column **D**.
- Select *all* units on channels 0, 1, 2, 4, and 5 to be traced:
  - For each channel called out, enter a *Y* in the input area of the **UNIT** column **E**.
- Activate the I/O instruction trace for all OPS on device 80 of channel 3. Enter the following in the row next to channel 3 **F**:
  - 80* under **UNIT**.
    - Enables unit 80 on channel 3 to be traced.
  - Y* under **OPS**.
    - Enables all the I/O instructions shown on the QDTC screen to be traced.
    - For definition of each **OPS**, see the "I/O Instruction Chart," page 14 619.
- Activate the I/O instruction trace on all OPS for all devices of channel 0. Enter the following in the row next to channel 0 **G**:
  - Y* under **OPS**.
    - Enables all the I/O instructions shown on the QDTC screen to be traced.
    - For definition of each **OPS**, see the "I/O Instruction Chart," page 14 619.

## SAMPLE QDP SCREEN

```

*DISPLAY/ALTER*
G GENERAL REGISTERS
C CONTROL REGISTERS
F FLOATING POINT REGISTERS
P CURRENT PSW
K STORAGE KEY
V VIRTUAL STORAGE
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PROG SYS
SELECTION: PO
MAN WAIT TEST

          A CURRENT PSW
          FE02 0000 8000 0EDB
          B
BC: CHNLMSK.E
EC: R TIE PSW.KEY CMWP ILC CC PROG.MASK
    1111 1110 0000 0010 10 0 0000

INSTRUCTION ADDRESS: 000EDB

ADDRESS IN HEXADECIMAL
OTHER DATA IN BINARY

==>
370 TIMER: ON INSTR STOP DATA: 8017 R ADDR: 000EDB
    ADDR-COMP: TRWR TYPE: ALLIOP ADDR: 380
    4341

9473 9473
    
```

## Sample Trace Control (QDTC) Screen

```

*DISPLAY/ALTER*
G GENERAL REGISTERS
C CONTROL REGISTERS
F FLOATING POINT REGISTERS
P CURRENT PSW
K STORAGE KEY
V VIRTUAL STORAGE
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PROG SYS
SELECTION: TC

          * PSW TRACE CONTROLS *
          ALL: LOAD I/O MCK PCK SVC EXT VM
                Y  Y  Y  Y  Y  Y  Y

          * I/O TRACE CONTROLS *
          CHANNEL UNIT CSW OPS
          G 0 Y Y Y
          1 Y Y N
          OPS = CIO 2 Y Y N
                HDV
                SIO F 3 80 Y Y
                TIO
                HIO 4 Y Y N
                TCH 5 Y Y N

          ==>
          INSTR STOP
          4341

          D -CSW Column
          E -UNIT Column
    
```

- Ensure that no I/O instructions are traced on channels 1, 2, 4, and 5:
  - For each channel specified, enter a *N* in the **OPS** column.
- Press **ENTER**.
  - This step enters all the trace selections to the processor.

### 4 \*\*\*\*\*Restart Failing Operation\*\*\*\*\*

- Key in *QLP* and press **ENTER**.
  - Activates the trace functions specified.

**Note:** This is only one of the ways to activate the trace. The object is to activate the operation that you want to trace.

Model Groups 1 and 2

EC 379605 06Mar81	PN 2676263	14 620
2 of 3		



**I/O and Channel Trace Example (Continued)**

- 5 \*\*\*\*\*Problem determination\*\*\*\*\***
- When a failure is detected or suspected, press **STOP**, **MODE SEL**, and key in **QDTP**.
  - The **PSW and I/O TRACE [H]** screen is now displayed.  
If you press and hold **ALT** and press **Page up**, any additional trace screens are displayed.
  - The **CC** value of 3 **[I]** indicates the device 01F is not available to the system.

- 6 \*\*\*\*\*Problem Fix\*\*\*\*\***
- Display the Program Load screen.
    - Key in **QL** and press **ENTER**.
      - The **CONSOLE ADDR [J]** is in error.
  - Key in **T001F** and press **ENTER**.
    - Changes the **CONSOLE ADDR [J]** to **01F**.

- 7 \*\*\*\*\*Verification of Fix\*\*\*\*\***
- Perform an IPL.
    - Key in **P** and press **ENTER**.
      - If system indicates no error, problem is fixed. Continue with next step-sequence.
      - If system does indicate an error, continue with next step-sequence, and then follow standard maintenance procedures.

- 8 \*\*\*\*\*Trace Termination\*\*\*\*\***
- Reset the trace functions.
    - Key in **QAN** and press **ENTER**.

**SAMPLE QDTP SCREEN**

```

*DISPLAY/ALTER*
G GENERAL REGISTERS
C CONTROL REGISTERS
F FLOATING POINT REGISTERS
P CURRENT PSW
K STORAGE KEY
V VIRTUAL STORAGE
M REAL STORAGE
T TRACE AREA
S BLOCK SAVE AREA
A AUXILIARY STORAGE
U UCW/DEVICE DIRECTORY
L LOCAL STORAGE
X EXTERNAL REGISTERS
W SP STORAGE
D CONSOLE DISK FILE
= HEX CALCULATOR
Q GENERAL SELECTION
Z RETURN TO PROG SYS
SELECTION: TPOO

[H] PSW & I/O TRACE
OPS TIO CC=3 DEV=01F CNT=0023 2A4D
OPS TIO CC=0 DEV=380
OPS TIO CC=1 DEV=380 CSW=0000 0168 0C00 0000
OPS TIO CC=2 DEV=380 CNT=0000 007B
OPS SIO CC=0 DEV=380 CCW=0200 00B0 0000 0050
CAW=0000 0160

OPS TIO CC=0 DEV=380
OPS TIO CC=1 DEV=380 CSW=0000 0168 0C00 0000
OPS TIO CC=2 DEV=380 CNT=0000 0082
OPS SIO CC=0 DEV=380 CCW=0200 00B0 0000 0050
CAW=0000 0160

OPS TIO CC=0 DEV=380
OPS TIO CC=1 DEV=380 CSW=0000 0168 0C00 0000
OPS TIO CC=2 DEV=380 CNT=0000 0081
OPS SIO CC=0 DEV=380 CCW=0200 00B0 0000 0050
CAW=0000 0160

OPS TIO CC=0 DEV=380
OPS TIO CC=1 DEV=380 CSW=0000 0168 0C00 0000
==>
    
```

00= The trace area page number.

**SAMPLE QL SCREEN**

```

*PROGRAM LOAD*
PERFORM IML: M
MODE-ASSIST MENU: I
*MODE*
S/370
*ASSISTS*
(NONE)

IML AT POWER-ON: X1 YES
X2 NO

STATUS IPL COMPLETE

SELECTION:
MAN WAIT TEST

V1 CS TEST
V2 MS DATA
V3 MS ADDR
V4 SCOPE LP
S SAVE STG
Y NO CS LD

PERFORM IPL: P
IPL UNIT ADDR: U 380
RESET TYPE: R1 LOAD CLEAR
R2 LOAD NORMAL

CONSOLE MODE: N1 PTR/KYBD
N2 DISPLAY

CONSOLE ADDR: T0 010 T2 DSC
T1 DSC H3 DSC
COPY KEY DEV: K3

Q GENERAL SELECTION
Z RETURN TO PROG SYS

370 TIMER: ON INSTR STOP DATA: 8017 R ADDR: 000EDB
ADDR COMP: TRWR TYPE: ALLIOP ADDR: 0..
4341
    
```

**[J]**

Model Groups 1 and 2

EC 379605 06Mar81	PN 2676263	14 621
	3 of 3	




## SCREEN COPY OPTIONS

This service aid contains the procedures to copy screens. See the "Copy Option Availability Diagram." Locate the microcode EC level of the machine, select a copy option, and then follow the appropriate procedure on the following page.

**Warning:** To ensure that the screen input data is not lost while copying the screen, press the *ENTER* key before pressing the *COPY* key. If you do not save the input data, it is lost when the *COPY* key is pressed.

## COPY OPTION AVAILABILITY DIAGRAM

Details of how to use each copy option is on the following page.



### Model Groups 1 and 2

EC 379605 06Mar81	PN 2676248	14 625
EC 379837 28Jun82	1 of 2	

## Copy Key Options

The **COPY** key can be assigned to copy on a:

- Console Printer - **Kn**.
  - *n* = 1, 2, or 3; as shown under *Console Address* on the Program Load (QL) screen.
- Diskette - **KD**
- Channel Printer - **KC<sub>cuu</sub>**
  - *cuu* = the channel and address of the printer; (example: 00e = channel 0, address hex 0e).

Ensure that the copy option you select is available for the microcode EC level of the processor; see "Copy Option Availability Diagram," page 14 625.

Select one of the following procedures:

### \*\*\*Kn - Console Printer\*\*\*

1. Display the Program Load screen.
  - Key in **QL** and press **ENTER**.
2. Key in **Kn** and press **ENTER**.
  - *n* = 1, 2, or 3; as shown under *Console Address* on the Program Load (QL) screen.

The **COPY** key is now assigned to copy on the specified console printer. Normal operations can be continued without additional action.

### \*\*\*KD - Diskette\*\*\*

1. Set **CE MODE** switch to **ON**.
2. Display the Program Load screen.
  - Key in **QL** and press **ENTER**.
3. Key in **KD** and press **ENTER**.

The **COPY** key is now assigned to copy on a diskette. The screen copies are stored in the save area of the diskette. For information on the diskette save area, see "Saved Screen Logout (QEW)."

### \*\*\*Continuing Normal Operations\*\*\*

1. Ensure that the **FUNCT** disk is mounted.
2. Set **CE MODE** switch to **NORMAL**.
3. Configure **COPY** key to console printer.

### \*\*\*KC<sub>cuu</sub> - Channel Printer\*\*\*

#### Notes:

- The **KC** option is operational when the processor has been **IMLed** but not **IPLed**.
- If the machine has been **IPLed**, a **QCLEAR** is needed to enable the **KC** option.

- To copy the **QVY22** screen on a channel printer:

1. Copy the screen to the diskette, by using the **KD** copy option.
2. Copy the saved **QVY22** screen using the **QEW** option. For details, see "Saved Screen (QEW)."

**Note:** Machine must be re-**IMLed** if options **QVY22** or **QVU22ADJUST** are used.

- To copy other **QV (Insert/Extract)** screens, perform the following steps:

1. Enter **QOM**.
2. Display the **QV** screen you want to copy.
3. Enter **QON**.
4. Press **START** key.
5. Press **COPY** key.

**Warning: A QCLEAR alters customer data in processor storage.**

1. Set **CE MODE** switch to **ON**.
2. Display the Program Load screen.
  - Key in **QL** and press **ENTER**.
3. Key in **KC<sub>cuu</sub>** and press **ENTER**.
  - *cuu* = the channel number and two-digit hex address of the printer.

The **COPY** key is now assigned to copy on the specified channel printer.

**Note:** To copy a **QV (Insert/Extract)** screen, perform the following steps before pressing the **COPY** key:

1. Enter: **QOM**.
2. Display the **QV** screen you want to copy.
3. Enter: **QON**.
4. Press the **START** key.

### \*\*\*Continuing Normal Operations\*\*\*

1. Ensure that the **FUNCT** disk is mounted.
2. Set **CE MODE** switch to **NORMAL**.
3. Configure **COPY** key to console printer.

## Display Screen Print (DSP) Function

The display screen print (DSP) function is a stand-alone program that is loaded into processor storage. The DSP function enables you to print the displayed screen on a channel-attached printer.

**Note:** Some Power screens can not be copied by using this function.

Messages are displayed if the printer is not ready or a printer address is entered wrongly.

DSP is available at microcode EC levels up to 154321; this function is replaced by the **KC<sub>cuu</sub>** option at higher microcode EC levels.

#### Notes:

- The DSP function is operational when the processor has been **IMLed** but not **IPLed**.
- If the machine has been **IPLed**, a **QCLEAR** is needed to enable the DSP function.

**Warning: A QCLEAR destroys customer data in processor storage.**

### \*\*\*DSP Function\*\*\*

1. Ensure that:
  - a. The **FUNCT** diskette is mounted.
  - b. The processor has completed a successful **IML**.
  - c. The channel-attached printer is ready.
2. Set **CE MODE** switch to **ON**.
3. Display the screen you want to copy:

**Note:** To copy a **QV (Insert/Extract)** screen, perform the following steps before continuing:

- a. Enter: **QOM**.
- b. Display the **QV** screen you want to copy.
- c. Enter: **QON**.
- d. Press the **START** key.

4. Activate the DSP function by one of the following:
  - a. Key in **QICOPY<sub>cuu</sub>** and press **ENTER**.
    - *cuu* = the channel number and two-digit hex address of the printer.
  - b. Press and hold the **ALT** key, and then press the **PF5** key.
    - A message is displayed requesting you to enter the channel number and address of the printer.

## Model Groups 1 and 2

EC 379605 06Mar81	PN 2676248	14 628
EC 379837 28Jun82	2 of 2	

## CE LOGS

An area for CE logs is available on the functional (FUNCT) diskette. The CE logs area is included in the Saved Screens (QEW) area.

CE logs, under the direction of MAPs, allow communicating information about repair activities on intermittent problems. When a problem is intermittent, the MAPs direct the service representative to display the CE logs to see what repair activity, if any, has been done. When a repair action cannot be verified, the MAPs direct the service representative to make a new CE log entry.

### Saved Screens (QEW)

Up to four CE Log screens and saved screens can be stored in the saved screens area of the diskette. These screens are numbered in hex, 00 through 03.

Two CE logs are formatted on each CE Log screen. This allows for a possible total of eight CE logs when there are no Saved screens.

When both CE Log and Saved screens have been stored in the saved screens area, the CE Log screens are assigned to the lower-numbered saved screens locations. A new CE log entry is assigned to location 00, and previous entries are incremented by one.

For additional information, see Volume 18, Section 44, "Saved Screens (QEW)."

### How to Use CE Logs

CE logs are part of the saved screens (QEW) function, and can be entered, displayed, and printed in CE mode only.

### Displaying CE Log Titles

To display the Saved Screens List screen, enter: QEWT

The Saved Screens List screen (QEWT) lists titles for all stored CE Log screens and Saved screens. For an example of this screen, see the right (RH) column.

CE Log screen titles, if any, are listed under the heading "LOG TITLE." (Notice that there may be two CE log entries on each screen.) Saved screens titles, if any, are listed under the heading "CE TITLE."

### Displaying CE Logs

To display a CE log, enter: QEWDxx (xx = screen number, 00 through 03, from the Saved Screens List screen.)

Two CE logs may be displayed on each screen. For an example of a CE Log screen (QEWDxx), see the right (RH) column.

### Making a New CE Log Entry

To make a new CE log entry, enter: QEWE

- If space is available in the saved screens area (less than four CE Log and Saved screens stored), a screen with two blank formatted CE logs is displayed. Key in the CE log data and press the ENTER key. This CE Log screen is stored at saved screens location 00. (Previously stored screens are moved to the next higher location.)
- If a total of four CE Log and Saved screens has already been stored, a message is displayed to indicate that the saved screens area is full. Erase (or purge) screens to make space available for the new screen.

### Editing an Existing CE Log

To edit an existing CE log, enter: QEWExx (xx = CE Log screen number, 00-03). To input data move the cursor to the area to be changed. Do not press ENTER until you have completed all data entries. When you press ENTER, the edited CE Log is saved at location 00.

**Note:** Pressing the the *MODE SEL* key or changing the command on the *SELECTION* line prevents saving the displayed CE log screen.

### Erasing CE Log and Saved Screens

- To erase one CE Log screen, enter: QEWRxx (xx = CE Log screen number, 00 - 03)  
If two CE logs are on the screen, both are erased.
- To erase all CE Log screens, enter: QEWX  
This erases CE Log screens only. Saved screens remain.
- To erase all Saved screens, enter: QEWY  
This erases Saved screens only. CE Log screens remain.

### EXAMPLE: Saved Screens List Screen (QEWT)

*SAVED SCREENS*	ADDR RANGE (00/0E)	DATE: 80/199 19:19
T LIST	***** LOG TITLE ***** LOG TITLE *****	
D DISPLAY L RE-TITLE	00 RC 669278AE	
E CE LOG EDIT		
R ERASE ONE X PURGE CE LOG SCRNS Y PURGE CE SCRNS	***** CE TITLE ***** SAVED DATE * 01 QECD	80/175 10:04
F SEND TO CONS PRT C SEND TO CHNL PRT		
Q GENERAL SELECT Z RTN TO PROG SYS		
SELECTION: WT00		==>
		4341

### EXAMPLE: CE Log Screen (QEWDxx)

LOG1: RC 669278AE	(ENTER KEYWORD SYMPTOM)	DATE: 80/10/21
SYMPTOM: Machine check and RC 669278AE.		
FRUS CALLED: A1G B1K		FRUS CHANGED: A1G
DIAGNOSTIC RESULTS/COMMENTS: Tests did not sense failure.		
INCIDENT:	PROBLEM:	CE NAME j smith
LOG2: SYMPTOM:	(ENTER KEYWORD SYMPTOM)	DATE: YY/MM/DD
FRUS CALLED:		FRUS CHANGED:
DIAGNOSTIC RESULTS/COMMENTS:		
INCIDENT:	PROBLEM:	CE NAME
SELECTION: W000		==>
		4341

### Printing CE Logs

CE logs can be printed on either a console printer or a channel-attached printer.

#### Printing CE Logs on a Console Printer

**Warning:** If a job is running, check the Program Load screen (QL) to ensure that the console printer is disconnected before proceeding. (When disconnected, the H device in the "CONSOLE ADDR" field indicates "DSC.")

- To print one CE Log screen on a console printer, enter: QEWFxx (xx = Saved Screens screen number)
- To print all CE Log screens on a console printer, enter: QEWFALL

#### Printing CE Logs on a Channel-Attached Printer

**Warning:** Do not try to print CE logs on a channel-attached printer when a job is running. Main storage must be cleared.

CE logs can be printed on a channel-attached printer after the processing unit (PU) has been IMLed and:


- Before IPL, or
  - After IPL if main storage is first cleared by pressing the MODE SEL key and entering QCLEAR. (Do NOT do this if a job is running.)
- To print one CE Log screen on a channel-attached printer, enter: QEWCxx cuu  
xx = Saved Screens screen number  
cuu = printer address
  - To print all CE Log screens on a channel-attached printer, enter: QEWCALL cuu  
cuu = printer address

#### Model Group 2

EC 379825 05Jun81	PN 2676420	14 640f
EC 379829 28Jun82	2 of 2	


# GROUNDING PATHS

## GROUNDING, MODEL GROUP 2, FRAME 01








- Legend**
- Star Washer Ground
  - ⊥ Frame Ground by Strap and Star Washers
  - ( ) Connector Pin Position
  - ⌋ Internal Assembly Ground. (Star Washer)
  - L  
F  
L  
T = Line Filter
  - ⊕ Power Cord Entry Point

\* If installed.



Model Group 2


EC 379605 06Mar81	PN 2676236	14 705
1 of 3		




Model Group 2

EC 379605 06Mar81	PN 2676236	14 706
	2 of 3	






Diskette Drive



PCC Box




Line Filter

Model Group 2

EC 379605 06Mar81	PN 2676236	14 707
3 of 3		






# GROUNDING, MODEL GROUP 2, FRAME 02 (FERRO)




### Legend

- ▼ Internal Assembly Ground (Star Washer)
- ( ) Connector Pin Position
- Star Washer Ground
- ⊥ Frame Ground by Strap and Star Washer.





Model Group 2, Ferror Power

EC 379605 06Mar81	PN 2676237	14 715
	1 of 2	




Frame 02






Model Group 2, Ferror Power

EC 379605 06Mar81	PN 2676237	14 716
2 of 2		

# GROUNDING, FRAME 03



- Legend**
- Star Washer Ground
  - ⊥ Frame Ground by Strap and Star Washers
  - ( ) Connector Pin Position
  - ⏚ Internal Assembly Ground. (Star Washer)




Model Groups 1 and 2

EC 379605 06Mar81	PN 2676238	14 725
EC 379814 02Oct81	1 of 1	





GROUNDING, MODEL GROUP 2, FRAME 02 (SWITCHING REGS)



Legend


- ↓ Internal Assembly Ground (Star Washer)
- ( ) Connector Pin Position
- 0 Star Washer Ground
- ⊥ Frame Ground by Strap and Star Washer




Model Group 2, Switching Regulators

EC 379819 19Jun81	PN 2676239	14 735d
1 of 4		

Gate 02A





FRONT VIEW



PS213

REAR VIEW



REAR VIEW

TR216



E Four Sets  
(two on each side)

DANGER  
Grounding star washer  
must be reinstalled.

Model Group 2, Switching Regulators




EC 379819 19Jun81	PN 2676239	14 736d
2 of 4		





Model Group 2, Switching Regulators

EC 379819 19Jun81	PN 2676239	14 737d
	3 of 4	



## Problem Analysis (PA)

### Introduction

Problem Analysis (PA) provides the customer with tools to handle problems without involving the local service representative. This procedure collects data, determines problems, and performs selective diagnostic routines without the aid of your Support Structure. Using Problem Analysis solves problems quicker and involves a higher level of expertise sooner.

Problem Analysis also provides repair information for the service representative. It does not replace the existing maintenance package, but is used as directed by the MAPs.

This procedure involves four areas:

**Problem Analysis Routine:** Collects data from areas, such as storage, logs, and PSWs. The routine attempts to determine the problem, such as a hang, loop, I/O error, PU error, or programming error condition. This routine then leads you through steps to solve the problem.

**Diagnostics Routine:** Runs diagnostics with the aid of a special diskette. This routine attempts to identify and isolate the problem. You are then instructed to perform procedures that may require restarting or invoking the Customer Service Request routine.

**Part Number Processing Routine:** Identifies the failing FRU, its location, and part number.

**Customer Service Request Routine:** Transmits log and system data to your Support Structure. This data helps determine the solution.

**Note:** This routine is applicable only when the machine has the Remote Support Facility (RSF) installed.

```

*GENERAL SELECTION*

Y TIME OF DAY-ENABLE          F CONFIGURATION
J INTERVAL TIMER-SWITCH      L PROGRAM LOAD
                              B BLOCK/PATCH
PA PROBLEM ANALYSIS          A COMPARE/TRACE
PROGR SYSTEM RESET-PROGRAM   K CHECK CONTROL
CLEAR SYSTEM RESET-CLEAR    O OPERATION RATE
CM MACHINE RESET

RES RESTART                   D DISPLAY/ALTER
                              V INSERT/EXTRACT

SAVE STORE STATUS

Z RETURN TO PROG SYS         E ERROR LOGOUTS
X SP STORAGE DISPLAY         M POWER/TEMPERAT
                              I DISKETTE IPL

SELECTION:                    ==>
                               4341
  
```

### General Selection (Q) screen

```

*PROBLEM ANALYSIS*

PWR ON OK  PU-IPL ___ INTERRUPTS ___ INSTRUCTION LOOP ___ CHNL OR I/O ERR ___
PU-IML OK  WAIT= ___ MACHINE CHK ___ MICROCODE LOOP ___ ACTIVE DEVICES ___

PA OPTIONS AVAILABLE: SELECT ONE OPTION, THEN PRESS ENTER
1 = START PROBLEM ANALYSIS ROUTINE
2 = START SYSTEM AGAIN (IPL OR IML/IPL)
3 = RUN 4341 PROCESSING UNIT ANALYSIS TEST
4 = SEND SERVICE INFORMATION (IF RSF INSTALLED)
5 = DISPLAY DETAILED PA DATA
6 = CUSTOMER DATA AND SECURITY CONTROL
7 = GO TO PART NUMBER AND FRU-LIST PROGRAM
8 = DISPLAY 4341 PROCESSING UNIT ANALYSIS FRU-LOGS
9 = DISPLAY SERVICE TRANSMISSION HISTORY

Q GEN SELECTION
Z RTN TO PGM SYS
SELECTION: _

                               4341
  
```

### Problem Analysis Option screen

### Invoking Problem Analysis

To invoke the Problem Analysis Option screen:

1. Press MODE SEL key. General Selection (Q) screen is displayed.
2. Key PA next to SELECTION.
3. Press ENTER. Problem Analysis Option screen is displayed.

### Screen Layout

The PA selection from the General Selection (Q) screen displays the Problem Analysis Option screen. The screen shows the options available for problem analysis. This option screen is also displayed when a selected option is completed.

Lines 4 and 5 are blanked when initially invoking the PA selection. Returning to this screen after invoking Option 1 displays the system status on these lines.

Options 7 through 9 are used by the service representative and are displayed in CE mode only.

### Return to General Selection (Q)

To return to the General Selection (Q) screen from any Option screen:

**Note:** For Option 3, be sure that the diagnostics have been completed or been terminated, and that the functional diskette is reinstalled.

1. Key Q next to SELECTION.
2. Press ENTER. General Selection (Q) screen is displayed.

### Return to Prog Sys (Z)

To return to the Prog Sys (Z) screen from any Option screen:

**Note:** For Option 3, be sure that the diagnostics have been completed or been terminated, and that the functional diskette is reinstalled.

1. Key Z next to SELECTION.
2. Press ENTER. Prog Sys (Z) screen is displayed.

Model Groups 1 and 2

EC 379837 28Jun82	PN 2676245	14 805
	1 of 8	

### Option 1: The Start Problem Analysis Routine

The Problem Analysis Routine collects data from areas, such as storage, logs, and PSWs. The routine attempts to determine the problem, such as a hang, loop, I/O error, PU error, or programming error condition.

To invoke Option 1 from the Problem Analysis Option screen:

1. Key 1 next to SELECTION.
2. Press ENTER. Problem Analysis routine is invoked, and the Problem Analysis Routine screen is displayed.

**Note:** Pressing ENTER when the Option 1 screen is displayed returns you to the Problem Analysis Option screen.

The Option 1 screen has three fields:

**Problem Field:** Displays a message describing the problem.  
**Verify Field:** Displays messages describing the problem area. This field may also display as a Warning field.  
**Action Field:** Displays messages describing possible operator action.

If the routine identifies a problem, the screen describes the problem, identifies the area, and provides an action. If the routine does not identify a problem, the screen recommends an action.

### Option 2: Start System Again (IPL or IML/IPL)

The Start System option returns you to the General Selection (Q) screen. Now you can perform a normal IPL or IML/IPL procedure.

To invoke Option 2 from the Problem Analysis Option screen:

1. Key 2 next to SELECTION.
2. Press ENTER. General Selection (Q) screen is displayed.

```

                                *PROBLEM ANALYSIS*
PWR ON  ___  PU-IPL  ___  INTERRUPTS  ___  INSTRUCTION LOOP  ___  CHNL OR I/O ERR  ___
PU-IML  ___  WAIT=  ___  MACHINE CHK  ___  MICROCODE LOOP  ___  ACTIVE DEVICES  ___

PROBLEM: MESSAGE DESCRIBING PROBLEM
VERIFY : MESSAGE(S) DESCRIBING PROBLEM AREAS

ACTION : MESSAGE(S) DESCRIBING POSSIBLE OPERATOR ACTION

Q GEN SELECTION
Z RTN TO PGM SYS
SELECTION:  _

                                ==> MORE, PRESS ENTER

```

### Option 1 Screen: Problem Analysis Routine

```

                                *PROBLEM ANALYSIS*
PWR ON OK  PU-IPL  ___  INTERRUPTS  ___  INSTRUCTION LOOP  ___  CHNL OR I/O ERR  ___
PU-IML OK  WAIT=  ___  MACHINE CHK  ___  MICROCODE LOOP  ___  ACTIVE DEVICES  ___

WARNING: 4341 PROCESSING UNIT ANALYSIS TEST WILL ALTER PROCESSING UNIT DATA
ACTION  * REMOVE SYSTEM FUNCTIONAL DISKETTE
        * INSTALL 4341 PROCESSING UNIT ANALYSIS DISKETTE- PUAD,
          LOCATED IN BACK OF PA-GUIDE
        * PRESS ENTER

        OR

        * PRESS MODE-SEL KEY TO CANCEL AND RETURN TO GENERAL SELECTION SCREEN
Q GEN SELECTION
Z RTN TO PGM SYS
SELECTION:  _

                                4341

```

### Option 3 Screen: 4341 Processing Unit Analysis Test

### Option 3: Run 4341 Processing Unit Analysis Test

The 4341 Processing Unit Analysis Test runs diagnostics by using a special diskette. This test attempts to identify and isolate the problem by using existing machine speed microdiagnostics and selected basic diagnostics.

**Warning:** Invoking the 4341 Processing Unit Analysis Test alters main storage, and requires an IML/IPL. However, a loss of customer data results.

To invoke Option 3 from the Problem Analysis Option screen:

1. Key 3 next to SELECTION.
2. Press ENTER. The screen prompts you to install the 4341 Processing Unit Analysis diskette.

**Note:** An error code may be displayed at this time if the suspected problem has been found before running diagnostics. You have the option of continuing by entering 3 next to SELECTION and pressing ENTER or of canceling by pressing ENTER with no entry next to SELECTION.

3. Install 4341 Processing Unit Analysis diskette.
4. Press ENTER.

The Analysis screen provides status information during the test and, upon completion, prompts you to install the functional diskette. If the diagnostics identify and isolate a problem, the Part Number and FRU List (Option 7) screen is displayed. This screen identifies the suspected FRUs. Invoking option 3 in customer mode displays suspected FRUs as an error code.

Model Groups 1 and 2

EC 379837 28Jun82	PN 2676245	14 806
	2 of 8	

#### Option 4: Send Service Information

With the Send Service Information option, you can transmit data via data link to your Support Structure. Use this option when remote assistance is required to diagnose a problem.

Two screens are involved with this option. The first screen displayed is the Service Request IBM Data screen. Information on this screen is filled in by the CE at the time of installation and normally requires no updating. The second screen displayed is the Service Request and Send Service Information screen. Once completed, the screen allows the data link to your Support Structure.

To invoke Option 4 from the Problem Analysis Option screen:

1. Place CE MODE switch ON.
2. Key 4 next to SELECTION.
3. Press ENTER. Service Request IBM Data screen is displayed.
4. Verify that all fields on the screen are entered correctly. Make any necessary corrections.

**Note:** Routing Code fields are nondisplayable fields.

5. Press ENTER. The screen is updated if any corrections were made. Service Request and Send Service Information screen is displayed.
6. Complete fields only as directed by your Support Structure. If a main store dump is to be performed, have the customer enter the password.

**Notes:**

- A password is not required for a main store dump if the system has not been IPLed.
- The START ADDRESS must be a right-justified, four-byte address.

7. Follow Action step 1 on the screen. If you have entered valid data, the message INITIALIZING RSF LINK is displayed. Blank or invalid fields result in the error message INVALID OR INCOMPLETE INPUT, PLEASE RE-ENTER. Enter correct data and press ENTER.
8. Data transfer begins. The current configuration, patch status, any selected traces or dumps, and all logs with valid data about the machine are transmitted. Messages indicating the progress of transmission appear on line 23. When the DATA SENT OKAY message appears, the console returns to the General Selection (Q) screen or to the PROG SYS (Z) screen if the system was IPLed. Return data set to TALK mode, hang up, and record incident number.

**Note:** To cancel transmission, hold ALT key down and press LINE DISC key. General Selection (Q) screen is displayed.

9. Key QBTP next to SELECTION.
10. Press ENTER. Patch list screen is displayed.
11. Verify the list for any patches that have been transmitted resulting from invoking this option.
12. Install any new patches. For installing a patch, see Volume 13/16, Section 14, Console Function Service Aids, "Patch Installation and Update Procedure."

```
*SERVICE REQUEST IBM DATA*

IBM INSTALLATION DATA:
REGION   BRANCH OFFICE   COUNTRY
CUSTOMER NAME:
STREET.CITY.STATE:

RSF: LINE SPEED (1=600, 2=1200 BPS) :
DATA BLOCK SIZE (1=256B, 2=2KB) :
LINE PLATE INSTALLED (Y OR N) : (WORLD TRADE ONLY)

TO CALL LOCAL SERVICE:
PRIMARY SYSTEM:          BACKUP SYSTEM:
PHONE NUMBER:           PHONE NUMBER:
ROUTING CODE:           ROUTING CODE:

ACTION: FILL IN SPACES, THEN PRESS ENTER KEY.

4341
```

Option 4 Screen: Service Request IBM Data

```
*SERVICE REQUEST AND SEND SERVICE INFORMATION*
4341-010015 TO CALL LOCAL SERVICE: 1-800-555-6666

PLEASE ENTER: YOUR NAME:
TELEPHONE NUMBER: EXT
PROGRAM TYPE/LEVEL:
SYSTEM STATUS (A = NOT WORKING, B = WORKING):
IBM SUPPORT SYSTEM (1 = PRIMARY, 2 = BACKUP):
PROBLEM: DESCRIPTION:

SEND I/O DEVICE TRACE (Y OR N)?
SEND INSTRUCTION TRACE (Y OR N)?
SEND MAIN STORE DUMP (01-64 KB)? KB START ADDRESS
PASSWORD FOR DUMP:
SEND MODULE ID: SEND SP STG DUMP (Y OR N)
ACTION: 1. DIAL ON RSF (CE) TELEPHONE.
AT END OF ANSWER TONE, PUT DATA SET IN DATA MODE.
2. AT -DATA SENT OKAY-, RETURN DATA SET TO TALK MODE.

IF ERROR: DISCONNECT RSF BY PRESSING ALT AND LINE-DISC KEYS.

4341
```

Option 4 Screen: Service Request and Send Service Information

Model Groups 1 and 2

EC 379837 28Jun82	PN 2676245	14 807
	3 of 8	





### Option 6: Customer Data and Security Control

The Customer Data and Security Control option provides the customer with a means of controlling transmission of main storage data. This option also allows the customer to change the local service telephone number, the program type/level, and his telephone number and/or extension.

To invoke Option 6 from the Problem Analysis Option screen:

**Note:** Any changes made to this screen must be approved by the customer.

1. Key 6 next to SELECTION.
2. Press ENTER. The Customer Data and Security Control screen is displayed.

With this screen displayed, the local service telephone number, the program type/level, the customer telephone number, and the decision to allow main storage dumps can be changed by keying over the existing data. When the ENTER key is pressed, the changes are effective, and the DATA SAVED message is displayed.

### Password Change Procedure

To change the password from the Customer Data and Security Control screen:

1. Enter the current password into the ENTER CURRENT PASSWORD field.  
**Notes:**
  - The password is entered into a nondisplayable field.
  - The initial password when shipped is PASSWORD.
2. Enter the new password into the ASSIGN NEW PASSWORD field.  
**Note:** A minimum of one and a maximum of eight uppercase characters are required for the password.
3. Press ENTER. PASSWORD CHANGED, RECORD NEW PASSWORD is displayed. The new password is displayed until the MODE SEL key is pressed.  
**Note:** INCORRECT CURRENT PASSWORD, PLEASE RE-ENTER is displayed if the current password was entered incorrectly.

```
*CUSTOMER DATA AND SECURITY CONTROL*

CUSTOMER NAME: ABC CORPORATION, INCORP.
STREET.CITY.STATE: 924 YOUR ST. ANYWHERE, USA.

TO CALL LOCAL SERVICE: _____

PROGRAM TYPE/LEVEL: _____
TELEPHONE NO.: _____ EXT _____

CUSTOMER DATA AND SECURITY CONTROL (CHANGES REQUIRE CURRENT PASSWORD)

ALLOW MAIN STORAGE DUMPS (Y OR N)?
ENTER CURRENT PASSWORD:
CHANGE PASSWORD (Y OR N)?
ASSIGN NEW PASSWORD : _____

ACTION: FILL IN SPACES, THEN PRESS ENTER KEY.
PRESS MODE-SEL KEY TO GO TO GENERAL SELECTION SCREEN.

4341
```

Option 6 Screen: Customer Data and Security Control

Model Groups 1 and 2

EC 379837 28Jun82	PN 2676245	14 810
	6 of 8	





**Option 9: Display Service Transmission History**

The Service Transmission History option displays the status of data that has been transferred to your Support Structure. This information results from running Option 4. The display contains the following information:

- Time of transfer
- Support Structure Incident number or Problem Management Record number
- Errors detected during transfer
- Log and Dump records received by your Support Structure.

To invoke Option 9 from the Problem Analysis option screen:

1. Place CE MODE switch ON.
2. Key 9 next to SELECTION.
3. Press ENTER. The Service Transmission History screen is displayed.

*SERVICE REQUEST TRANSMISSION HISTORY*												
SYS DATE REC'D	PROBLEM#	SUPPORT SYS ERRORS	====LOGS REC'D=====				==DUMPS=					
=====	=====	=====	PA	RC	PW	SP	PU	IC	ID	SP	ID	MS
=====	=====	=====	==	==	==	==	==	==	==	==	==	==
YY/MM/DD-HH:MM	INCxxxx	NOT REGISTERED										
YY/MM/DD-HH:MM	INCxxxx	SYS SPACE UNAVAIL.										
YY/MM/DD-HH:MM	INCxxxx	SYS READ ONLY MODE	Y	Y						Y	Y	Y
YY/MM/DD-HH:MM	INCxxxx	DB NOT ACCESSIBLE	Y		Y		Y		Y			
YY/MM/DD-HH:MM	INCxxxx	DATA BANK FULL	Y	Y								
YY/MM/DD-HH:MM	INCxxxx	SYS SPACE UNAVAIL.										
YY/MM/DD-HH:MM	INCxxxx	DB NOT ACCESSIBLE	Y		Y		Y		Y			
YY/MM/DD-HH:MM	INCxxxx	DB NOT ACCESSIBLE	Y		Y		Y		Y			
YY/MM/DD-HH:MM	INCxxxx	SYS READ ONLY MODE	Y	Y						Y	Y	Y

PA=PROBLEM ANALYSIS	SP=SUPPORT PROCESSOR	ID=I/O DEVICE TRACE
RC=REFERENCE CODE	PU=PROCESSING UNIT	ID=DISKETTE MODULE
PW=POWER LOG	IC=INSTRUCTION TRACE	MS=MAIN STORAGE

Q GENERAL SELECTION  
 Z RETURN TO PROG SYS  
 SELECTION: \_

4341

**Option 9 Screen: Service Transmission History**

Model Groups 1 and 2

EC 379837 28Jun82	PN 2676245	14 812
	8 of 8	

# DISKETTE DRIVE 2D


## CONTENTS

<b>Introduction</b> 15 010	<b>Head Load Parts</b> 15 050
General Description 15 010	Solenoid and Bail Service Check 15 050
Maintenance 15 010	Solenoid and Bail Adjustment 15 055
Special Tools 15 010	Solenoid and Bail Removal 15 060
Diskette 2D 15 010	Solenoid and Bail Replacement 15 060
Diskette Description 15 010	
Diskette Insertion 15 010	<b>AC Drive Parts</b> 15 065
Diskette Removal 15 010	Belt Removal 15 065
Diskette Care 15 015	Belt Replacement 15 065
	Drive Motor Removal 15 065
<b>Machine Characteristics</b> 15 020	Drive Motor Replacement 15 065
Physical Characteristics 15 020	Drive Pulley Removal 15 065
Environmental Characteristics 15 020	Drive Pulley Replacement 15 065
Functional Characteristics 15 020	Idler Assembly Removal 15 065
	Idler Assembly Replacement 15 065
<b>Access and Return of Diskette Drive 2D Assembly</b> 15 025	
	<b>Index Detection Assemblies</b> 15 070
<b>Diskette Drive 2D Removal/Replacement</b> 15 030	Diskette Speed Service Check 15 070
	LED and PTX Alignment 15 070
<b>Diskette Drive 2D Parts and Location</b> 15 035	LED Output Service Check 15 075
Cover Assembly 15 035	LED Removal 15 075
Head Load Parts 15 035	LED Replacement 15 075
AC Drive Parts 15 035	PTX Amplifier Service Check 15 080
Index Detection Assemblies 15 035	PTX Removal 15 085
Diskette Drive 2D Control Card 15 035	PTX Replacement 15 085
<b>Cover Assembly</b> 15 040	<b>Diskette Drive 2D Control Card</b> 15 090
Cover Removal 15 040	Control Card Removal 15 090
Cover Replacement 15 040	Control Card Replacement 15 090
Latch Assembly Removal 15 040	Control Card Test Pins 15 090
Latch Assembly Replacement 15 040	Control Card Socket and Connector Pins 15 090
Collet Assembly Removal 15 045	Control Card Head Cable Pins 15 090
Collet Assembly Replacement 15 045	Control Card Interconnections 15 095
	<b>Adapter Cable</b> 15 100

## INTRODUCTION

### GENERAL DESCRIPTION

The Diskette Drive 2D (53FD) is a direct access, read/write, data storage device. This device uses a flexible magnetic diskette for data entry, data exchange, and data storage. The 53FD can drive 1, 2, and 2D diskettes, but only 2D diskettes are used for the 4341 Processor.



### MAINTENANCE


The 53FD needs no scheduled maintenance. The MAPs guide you in diagnosing diskette drive failures. The MAPs also point to maintenance procedures in this manual when an adjustment, service check, or FRU replacement is needed.

You can verify a problem offline (isolated from the 4341 processor) by using the 53FD diagnostic programs. You can verify a repair offline by using the 53FD diagnostic programs and online when you IML the 4341 Processor.

The head/carriage assembly, head timing block, and drive hub and pulley assembly are adjusted and tested at the factory. The head timing block and the drive hub and pulley assembly are not field replaceable. If the head timing block or the drive hub and pulley assembly is damaged, replace the complete 53FD.

### SPECIAL TOOLS


Two timing pins (part 5562019) are located inside the cover assembly. They are used to align the LED and PTX assemblies.



### DISKETTE 2D


#### Diskette Description

The diskette 2D is a thin, flexible disk with data on both sides. Both sides of the diskette's surface are covered with magnetic recording material. The diskette is contained in a protective envelope.



### Diskette Insertion

1. Open 53FD cover assembly.
2. Remove diskette from protective envelope.
3. Place diskette into 53FD.
4. Close 53FD cover assembly.




### Diskette Removal

1. Open 53FD cover assembly.
2. Remove diskette.
3. Insert diskette in protective envelope.
4. Close 53FD cover assembly.


EC 379600 30Jun80	PN 5666159	15 010
	2 of 20	

## Diskette Care


Return a diskette to its envelope when it is removed from the diskette drive.




Do not lay diskettes near smoke or other things that can cause the disk to be contaminated.




Do not use clips or rubber bands on a diskette.




Do not touch or attempt to clean diskette surfaces. Contaminated diskettes will not work correctly.




Do not place diskettes near magnetic materials. Data can be lost from a diskette exposed to a magnetic field.




Do not expose diskettes to heat greater than 51.7° C (125° F) or direct sunlight.



Do not write outside the label area on diskettes.




Do not place heavy books on diskettes.



# MACHINE CHARACTERISTICS

## PHYSICAL CHARACTERISTICS



- Weight: 5.44 kg (12 lb)
- Connecting cables: One ac power **A**; and one signal and dc power **B**.
- Diskette speed: 360 rpm

## ELECTRICAL CHARACTERISTICS

The 4341 Processor supplies the following power options to operate the 53FD:

- Logic voltage for the 53FD control card:

Logic Voltage (DC)	Maximum Operating Current	Tolerance
-5V	0.10A	±10%
+5V	0.80A	±10%
+24V	0.59A	±12%

- The following is a selection of the needed ac power:

**Note:** All ac voltage tolerances are ±10%.

- A. 60-Hz, single-phase ac power:

Input Voltage (AC)	Average Operating Current
200V	0.55A
208V	0.55A
220V	0.55A
240V	0.55A

- B. 50-Hz, single-phase ac power:

Input Voltage (AC)	Average Operating Current
200V	0.55A
220V	0.55A
230V	0.55A
240V	0.55A

## ENVIRONMENTAL CHARACTERISTICS

The 53FD can be stored or operated in the following temperature and humidity ranges:

	Temperature		Relative Humidity
	Celsius	Fahrenheit	
Operate (Powered On)	10° to 40.6°	50° to 105°	8% to 80%
Store (Powered Off)	10° to 51.7°	50° to 125°	8% to 80%

## FUNCTIONAL CHARACTERISTICS

Diskette data formatting gives the 53FD the following characteristics:

	Diskette 1	Diskette 2	Diskette 2D
128 Bytes per Sector	242,944*	492,544**	
256 Bytes per Sector	284,160	568,320	985,088***
512 Bytes per Sector	303,104	606,208	1,136,640
1024 Bytes per Sector			1,212,416

- Data storage space (in formatted data bytes):
- Data rate: 250,000 bits (31,250 bytes) per second (FM); 500,000 bits (62,500 bytes) per second (MFM).
- Cylinder-to-cylinder seek time: 5 ms plus 35 ms for the head/carriage assembly to stop. (The total seek time is the number of cylinders the heads moved across multiplied by 5 ms, plus 35 ms.)
- Tracks per diskette side: 77 (Cylinder 00 is the label cylinder; cylinders 01 through 76 are for data.)
- Sectors per track:

	FM	MFM	
-26			128 bytes per sector
-15	-26		256 bytes per sector
-8	-15		512 bytes per sector
		-8	1024 bytes per sector

## ACCESS AND RETURN OF DISKETTE DRIVE 2D ASSEMBLY


To access 53FD assembly:

1. Power off.
2. Open all covers on frame 01.
3. Remove any diskette in 53FD.
4. Open 01A gate.
5. Loosen (but do not remove) four screws holding shield covering the 53FD assembly. The shield is located at the side of frame 01.
6. Carefully remove shield from screws. (Screw holes are slotted.)
7. Remove two screws **A** from bottom front of 53FD frame.
8. Remove screw **B** from top right corner of 53FD frame.
9. Remove screw **C** from rear left side of 53FD frame.
10. Pull 53FD assembly out of frame 01 until assembly stops.
11. Return to service procedure you came from.

To return 53FD assembly to frame 01:

**Caution: When pushing 53FD frame, be careful not to damage wires behind it.**

1. Carefully push 53FD assembly back into frame 01 until assembly stops.
2. Replace two screws **A** to bottom front of 53FD frame.
3. Replace screw **B** to top right corner of 53FD frame.
4. Replace screw **C** to rear left side of 53FD frame.
5. Carefully place shield on four screws located on front of 53FD frame.
6. Tighten the four screws.
7. Close 01A gate.
8. Place a diskette in 53FD.
9. Close all covers on frame 01.



## DISKETTE DRIVE 2D REMOVAL/REPLACEMENT

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Turn off main circuits breakers located on front of PCC box.
3. Disconnect grounding strap **A** by removing screw **B** and star washer **C** from 53FD frame.  
**Note:** Be sure to replace star washer **C** to ensure good grounding.
4. Disconnect cable **D** from connection 7 on PCC box.

**Caution:** When removing or replacing the adapter cable **E**, be careful not to damage the pins.

5. Remove adapter cable **E** from rear of 53FD.
6. Disconnect P1 plug **F** from J1 jack.
7. Carefully lift and pull 53FD assembly out of T-shaped hook **G** located at bottom of 53FD frame. Carefully place assembly in a clean open space to continue 53FD removal.
8. Disconnect drive motor power cable **H** at upper rear of 53FD.
9. Disconnect drive motor grounding wire **R** from 53FD frame by removing screw and washer **S**.
10. Remove 53FD from its frame by loosening four screws **J** and **L** from front and back brackets **I** and **K**. Carefully lift 53FD out of frame.


**Note:** The following items **MUST** be installed on the new 53FD.

11. Remove back bracket **K** by removing screws, nuts, and washers **M** at rear of bracket.
12. Remove front bracket **I** by removing two screws and washers **N**.
13. Remove special file handle **O** by loosening screw **Q** at bottom of handle and removing screw **P** at top of handle.

**Note:** When reinstalling special file handle, follow latch replacement procedure on 15 040.

14. Remove drive motor grounding wire **R** from 53FD by removing screw and washer **T** from top of drive motor.
15. Reinstall 53FD assembly by reversing this procedure up to step 2; then return 53FD assembly to frame 01. (See procedure on 15 025.)

**Caution:** Before installing new 53FD to 53FD frame, remove cardboard from diskette area.





# DISKETTE DRIVE 2D PARTS AND LOCATION

## COVER ASSEMBLY

- A** Latch assembly
- B** Collet Assembly

The collet centers and holds the diskette against the drive hub when the cover is closed.

## HEAD LOAD PARTS

- C** Solenoid
- D** Bail

The solenoid causes the bail to load the heads.

## AC DRIVE PARTS

- E** Belt
- F** Drive motor
- G** Drive pulley
- H** Idler assembly

The ac drive parts turn the diskette at 360 rpm.

*Note: The idler assembly is not present on some models of the 53FD.*


## INDEX DETECTION ASSEMBLIES

- I** LED
- J** PTX


The LED (light source) and PTX (light sensing device) work together to detect the diskette index.

## DISKETTE DRIVE 2D CONTROL CARD

The 53FD control card **K** has drive circuits for the stepper motor, solenoid, write, and erase functions. This control card also has amplifiers for read heads and index sensing circuits.



FRONT VIEW (Facing Front of Frame 01)



## COVER ASSEMBLY

### COVER REMOVAL

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Open 53FD cover assembly.

**Caution: Do not allow read/write heads to touch because this would damage them.**

3. Disconnect spring **A** from cover assembly.
4. Loosen two pivot screws with a wrench.
5. While holding cover assembly, remove pivot screws.
6. Lift cover assembly from 53FD.

### COVER REPLACEMENT


1. Align 53FD cover assembly with mounting holes. Then reinstall two pivot screws. (Ensure that spring **A** is installed.)
2. Tighten pivot screws with a wrench.
3. Connect spring **A** to cover assembly.
4. Close cover assembly.
5. Return 53FD assembly to frame 01. (See procedure on 15 025.)

### LATCH ASSEMBLY REMOVAL

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Remove 53FD cover assembly. (See "Cover Removal.")
3. Carefully remove latch **C**, special file handle **D**, and two pivots, by removing two mounting screws **E**. Do not lose spring **B** or the two pivots.

### LATCH ASSEMBLY REPLACEMENT

1. Place latch **C** and special file handle **D** on cover assembly. Then position the two pivots. Ensure spring **B** is reinstalled.
2. Reinstall two latch mounting screws **E**.
3. Reinstall 53FD cover assembly. (See "Cover Replacement.")
4. Return 53FD assembly to frame 01. (See procedure on 15 025.)




### COLLET ASSEMBLY REMOVAL

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Remove 53FD cover assembly. (See "Cover Removal.")
3. Remove clip **C**, collet, and spring-1.
4. Remove mounting screw **A**.
5. Remove remaining parts of collet assembly **B**.
6. Inspect all parts for wear and install new parts as needed.

### COLLET ASSEMBLY REPLACEMENT

1. Reinstall parts of collet assembly **B** and mounting screw **A** as shown.
3. Reinstall spring-1, collet, and clip **C**.
4. Reinstall 53FD cover assembly. (See "Cover Replacement.")
5. Return 53FD assembly to frame 01. (See procedure on 15 025.)




# HEAD LOAD PARTS

## SOLENOID AND BAIL SERVICE CHECK

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Disconnect drive motor power cable.
3. Remove 53FD cover assembly. (See "Cover Removal" on 15 040.)
4. Insert a strip of clean paper between heads to prevent head surfaces from touching.

**DANGER Use extreme care when you perform service while power is on.**

5. Power on.
  6. Install a jumper **A** (TPB13 to TPA13) to activate solenoid.
  7. Verify a 0.4 mm (0.015 in) gap **C** between bail and carriage arm for carriage movement (cylinder 00 to cylinder 76).
  8. If gap does not meet specification, go to step 7 of "Solenoid and Bail Adjustment." If gap does meet specification, continue with step 9.
  9. Power off.
  10. Remove jumper **A**.
  11. Remove paper from between carriage heads.
  12. Reinstall 53FD cover assembly. (See "Cover Replacement" on 15 040.)
  13. With solenoid de-activated and cover closed, visually check for a very small gap **B** between the carriage head surfaces.
- Note: This gap cannot be measured.**
14. If gap is not in specification, go to step 14 of "Solenoid and Bail Adjustment." If gap is in specification, continue with this procedure.
  15. Connect drive motor power cable.
  16. Return 53FD assembly to frame 01. (See procedure on 15 025.)



## SOLENOID AND BAIL ADJUSTMENT

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Disconnect drive motor power cable.
3. Remove 53FD cover assembly. (See "Cover Removal" on 15 040.)
4. Insert a strip of paper between carriage heads to prevent head surfaces from touching.

### DANGER

Use extreme care when you perform service while power is on.

5. Power on.

### DANGER

Solenoid case becomes hot after continuous use.




6. Install a jumper **F** to activate solenoid.
7. Loosen solenoid locking screw **B**.
8. Turn solenoid in casing and measure for a 0.4 mm (0.015 in) gap **C** between bail and carriage arm (A clockwise turn decreases the gap.)
9. If gap is not as specified for all carriage movement (cylinder 00 to cylinder 76), go back to step 7.

**Note:** If head carriage can not be manually moved with power on, power off, and then move the head carriage to desired cylinder position.

10. Tighten solenoid locking screw.
11. Check clearance between idler arm and solenoid. Adjust tap on idler arm to obtain clearance.
12. Remove jumper **F**.
13. Remove paper between heads.
14. Reinstall 53FD cover assembly. (See "Cover Replacement" on 15 040.)
15. With solenoid de-activated and cover closed, visually check for a gap **D** between the carriage head surfaces.

**Note:** This gap can not be measured.

16. If gap does not meet specifications, turn bail stop setscrew **E** clockwise until heads just touch; then turn counterclockwise one complete turn.
17. Power off.
18. Connect drive motor power cable.
19. Return 53FD assembly to frame 01. (See procedure on 15 025.)





## SOLENOID AND BAIL REMOVAL

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Disconnect drive motor power cable.
3. Remove 53FD cover assembly. (See "Cover Removal" on 15 040.)
4. Insert a clean strip of paper between carriage heads to prevent head surfaces from touching.
5. Remove bail return spring **E**.

**Caution: Be careful not to damage plated surface of the plunger.**

6. Remove mounting screw **D** and bail **C**. (This pulls solenoid plunger out of solenoid.)
7. Disconnect 53FD control cable from location A2 **L**.
8. Remove two screws **K** and connector covers.
9. Remove two solenoid leads **M** by pushing down on tabs with a small screwdriver.
10. Remove plunger from bail.
11. Loosen solenoid locking screw **A**.
12. Remove solenoid by turning it counterclockwise.



## SOLENOID AND BAIL REPLACEMENT

1. Install solenoid about four turns clockwise into casting.

**Caution: Be careful not to damage plated surface of plunger.**

2. Install plunger to bail.
3. Insert plunger into solenoid.
4. Reinstall bail and mounting screw **D**. Ensure that bail is under tab **B** of carriage arm.
5. Reinstall bail return spring **E**.
6. Insert two solenoid leads **M** into 53FD control cable connector. Ensure locking taps **N** on terminals are locked in connector openings.
7. Reinstall cable connector covers and two screws **K**.
8. Plug cable into location A2 **L** on the 53FD control card socket.
9. Go to step 4 of "Solenoid and Bail Adjustment" procedure on 15 055.

EC 379600 30Jun80	PN 5666159	15 060
	12 of 20	

## AC DRIVE PARTS

### BELT REMOVAL

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Release idler tension by hand and remove drive belt.

### BELT REPLACEMENT

1. Install drive belt. Ensure belt is positioned on idler as shown.
2. Return 53FD assembly to frame 01. (See procedure on 15 025.)

### DRIVE MOTOR REMOVAL

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Disconnect drive motor power cable.
3. Disconnect drive motor grounding wire **G** from top of drive motor by removing screw and washer **H**.
4. Remove drive belt; see "Belt Removal".

#### DANGER

Drive motor case becomes hot after continuous use.

5. Loosen two drive motor bracket screws **D** and remove drive motor from two mounting brackets.
6. Loosen setscrew **C**; then remove drive pulley from drive motor shaft.


### DRIVE MOTOR REPLACEMENT

1. Reinstall drive pulley on new drive motor. Ensure setscrew **C** is directly on flat surface of motor shaft. (To locate flat surface, see drawing.)

#### DANGER

To prevent personal injury on 60Hz motors, ensure two large holes **B** in motor case are positioned up and under bracket.

2. Install drive motor on mounting brackets and tighten bracket screws **D**.
3. Install drive motor grounding wire **G** on top of drive motor with screw and washer **H**.
4. Connect drive motor power cable.
5. Reinstall belt; see "Belt Replacement".
6. Return 53FD assembly to frame 01. (See procedure on 15 025.)



### DRIVE PULLEY REMOVAL

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Remove drive belt. (See "Belt Removal.")
3. Loosen the setscrew **C**, then remove drive pulley from drive motor shaft.

### DRIVE PULLEY REPLACEMENT

1. Install drive pulley on drive motor shaft with setscrew **C** directly on flat surface of shaft. (To locate flat surface, see drawing.)
2. Reinstall belt. (See "Belt Replacement.")
3. Return 53FD assembly to frame 01. (See procedure on 15 025.)

### IDLER ASSEMBLY REMOVAL

Note: The idler assembly is not present on some models of the 53FD.

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Remove drive belt. (See "Belt Removal.")
3. Remove idler spring **F**.
4. Remove locking screw **E** and idler assembly.

### IDLER ASSEMBLY REPLACEMENT

1. Reinstall idler assembly and locking screw.
2. Reinstall idler spring **F**.
3. Reinstall belt. (See "Belt Replacement.")



# INDEX DETECTION ASSEMBLIES

## DISKETTE SPEED SERVICE CHECK

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Insert a diskette. (Ensure 53FD cover assembly is closed.)

### DANGER

Use extreme care when you perform service while power is on.

3. Power on.
4. Install a jumper **A** to activate solenoid.
5. Set up an oscilloscope as follows:

**Note:** Use a Tektronix 453, 454, or a similar oscilloscope with x10 probes.

Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	DC
Channel A slope	+
Channel A source	Internal
Tripper Mode	Normal
Channel 1 volts/division	1.0 V/cm
Channel 1 input	DC
Times per division	20 ms
Channel 1 probe to	+Index Test Pin <b>B</b>

6. Observe an index pulse width of 1.5 to 3.0 ms **E** occurring every  $166.7 \pm 4.2$  ms **C**. Pulse amplitude should be between 2.4 and 4.2 Vdc **D**.
7. Power off.
8. Remove jumper **A**.
9. Remove diskette.
10. Return 53FD assembly to frame 01. (See procedure on 15 025.)

## LED AND PTX ALIGNMENT

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Remove 53FD cover assembly. (See "Cover Removal" on 15 040.)
3. Loosen PTX mounting screw **F**.
4. Position PTX assembly against casting stop **G** (away from leads); then tighten mounting screw.
5. Loosen two LED mounting screws **J**.
6. Insert two timing pins **H** through LED into PTX assembly and tighten LED mounting screws.


**Note:** If you can not insert timing pins, the holes of the LED and PTX assemblies are not aligned. Loosen PTX mounting screw **F** and push the PTX assembly very slightly away from casting stop **G**. Then start from step 6 and continue. You may need to repeat this step.

7. Remove timing pins.
8. Reinstall 53FD cover assembly. (See "Cover Replacement" on 15 040.)




### DANGER

Use extreme care when you perform service while power is on.

9. Power on.
10. Perform "Diskette Speed Service Check" procedure.



**Note:** For more detail of test pin description, see "Control Card Test Pins," page 15090.






## LED OUTPUT SERVICE CHECK

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Connect negative probe of a multimeter to ground test pin **C** on 53FD control card.
3. Set multimeter scale to 5 Vdc and connect positive probe to TPB14 LED voltage test pin **A**.

**DANGER Use extreme care when you perform service while power is on.**

4. Power on.
5. Check for a voltage level between 1 and 2 Vdc.
6. Move positive probe to LED voltage at TPA12 test pin **B**.
7. Check for a voltage level between 1 and 2 Vdc.
8. Power off.
9. Return 53FD assembly to frame 01. (See procedure on 15 025.)





## LED REMOVAL

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Remove 53FD cover assembly. (See "Cover Removal" on 15 040.)
3. Disconnect 53FD control cable from location A2 **L**.
4. Remove two screws **K** and connector covers.
5. Remove two 33FD LED leads (wrapped pair) **M** and two 53FD LED leads **J** by pushing down on tabs with a small screwdriver.
6. Remove LED cable from three retainers **F**. (Remember cable path for replacement.)
7. Remove four guide mounting screws **E** and guide.
8. Remove two LED mounting screws **G** and nuts **H**. Then remove LED assembly.

## LED REPLACEMENT


1. Install LED assembly, two mounting screws **G**, and nuts **H** on guide. (Do not tighten.)
2. Reinstall guide and four mounting screws **E**.
3. Follow cable path through three retainers **F** and insert two 33FD LED leads (wrapped pair) **M** and two 53FD LED leads **J** in 53FD control cable connector. Ensure tabs **D** on terminals are locked in connector openings.
4. Reinstall cable connector covers and two screws **K**.
5. Plug cable in location A2 **L** of 53FD control card socket.
6. Go to "LED and PTX Alignment" procedure on 15 070.



## PTX AMPLIFIER SERVICE CHECK


Caution: Always perform this service check with a diskette inserted backward (with label facing 01A gate), or LED light causes a wrong reading and can destroy PTX.

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Disconnect drive motor power cable.
3. Insert a diskette with lable facing 01A gate and small hole pointed toward floor. (See drawing below.) Ensure 53FD cover assembly is closed.



**DANGER** Use extreme care when you perform service and power is on.

4. Power on.
5. Connect positive probe of a multimeter (15 Vdc scale) to index test pin **C** on 53FD control card.
6. Connect negative probe of multimeter to ground test pin **D**.
7. Check multimeter for a reading of less than 1 Vdc.
8. Install one end of a jumper to TPB16 PTX test pin **B**.
9. While observing multimeter, touch other end of jumper to the +5 Vdc test pin **A** several times. Multimeter should read 2.5 Vdc or more when test pin is touched. (A wrong reading can occur first time test pin is touched.)
10. Repeat steps 8 and 9 with jumper on TPA14 PTX test pin **C**.
11. Power off.
12. Remove jumper.
13. Remove diskette.
14. Connect drive motor power cable.
15. Return 53FD assembly to frame 01. (See procedure on 15 025.)



1	
THP1	+Diskette Inserted
THP2	-Hd Ld Osc
THP3	+14 Vdc
THP4	Ground
THP5	Ground
THP6	+53FD Index
THP7	+33FD Index
THP8	Diff Read A
THP9	Diff Read B
THP10	-High Gain
THP11	-Align Access 0
THP12	-High Current
THP13	Preamp TP1
THP14	Preamp TP2
THP15	-High Gain A
THP16	-High Gain B

2	
TPA1	+Write Data
TPA2	+Erase Gate
TPA3	+Write Gate
TPA4	+Inner Tracks
TPA5	+Select Head 1
TPA6	Ground
TPA7	+Current Enabled
TPA8	+24 Vdc
TPA9	-5 Vdc
TPA10	MC-1
TPA11	+Hd Load Solenoid
TPA12	33FD LED Voltage
TPA13	Ground
TPA14	33FD PTX

3	
TPB1	+Access 0
TPB2	+Access 1
TPB3	+Access 2
TPB4	+Access 3
TPB5	+File Data
TPB6	+Diskette Sense
TPB7	+Head Engage
TPB8	+Switch Filter
TPB9	+Index
TPB10	MC-3
TPB11	MC-0
TPB12	MC-2
TPB13	-Head Load
TPB14	53FD LED Voltage
TPB15	+5 Vdc
TPB16	53FD PTX





### PTX REMOVAL

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Remove 53FD cover assembly. (See procedure on 15 040.)
3. Remove four guide mounting screws **H** and guide.
4. Disconnect 53FD control cable from location A2 **E**.
5. Remove two screws **C** and two connector covers.
6. Remove two 33FD PTX leads (wrapped pair) **D** and two 53FD PTX leads **B** by pushing down on tabs with a small screwdriver.
7. Remove PTX mounting screw **F** and washer.
8. Remove PTX assembly. (Remember cable path for replacement.)

### PTX REPLACEMENT

1. Install PTX assembly against casting stop **G** (see note on drawing); then reinstall screw **F** and washer.
2. Follow cable path and insert two 33FD PTX leads (twisted pair of leads) **D** and two 53FD leads **B** into 53FD control cable connector. Ensure tabs **A** on terminals are locked in connector openings.
3. Reinstall connector covers and two screws **C**.
4. Plug connector into location A2 **E** of 53FD control card socket.
5. Reinstall guide and four mounting screws **H**.
6. Go to LED and PTX alignment.



Note: Push PTX in the direction of arrow.



# DISKETTE DRIVE 2D CONTROL CARD CONTROL CARD TEST PINS

## CONTROL CARD REMOVAL

1. Access the 53FD assembly. (See procedure on 15 025.)
2. Disconnect head cable **A** from 53FD control card **B**.
3. Remove card retainers **C**.
4. Remove 53FD control card **B**.




## CONTROL CARD REPLACEMENT


1. Reinstall 53FD control card **B**. Ensure card is seated in socket.
2. Reinstall card retainers **C**.
3. Connect head cable **A** to 53FD control card.
4. Return 53FD assembly to frame 01. (See procedure on 15 025.)

1	2	3
THP1 +Diskette Inserted	TPA1 +Write Data	TPB1 +Access 0
THP2 -Hd Ld Osc	TPA2 +Erase Gate	TPB2 +Access 1
THP3 +14 Vdc	TPA3 +Write Gate	TPB3 +Access 2
THP4 Ground	TPA4 +Inner Tracks	TPB4 +Access 3
THP5 Ground	TPA5 +Select Head 1	TPB5 +File Data
THP6 +53FD Index	TPA6 Ground	TPB6 +Diskette Sense
THP7 +33FD Index	TPA7 +Current Enabled	TPB7 +Head Engage
THP8 Diff Read A	TPA8 +24 Vdc	TPB8 +Switch Filter
THP9 Diff Read B	TPA9 -5 Vdc	TPB9 +Index
THP10 -High Gain	TPA10 MC-1	TPB10 MC-3
THP11 -Align Access 0	TPA11 +Hd Load Solenoid	TPB11 MC-0
THP12 -High Current	TPA12 33FD LED Voltage	TPB12 MC-2
THP13 Preamp TP1	TPA13 Ground	TPB13 -Head Load
THP14 Preamp TP2	TPA14 33FD PTX	TPB14 53FD LED Voltage
THP15 -High Gain A		TPB15 +5 Vdc
THP16 -High Gain B		TPB16 53FD.PTX

## CONTROL CARD SOCKET AND CONNECTOR PINS



## CONTROL CARD HEAD CABLE PINS



## CONTROL CARD INTERCONNECTION

The signal lines between the 4341 Processor adapter connector and control are:

Access Lines 0 through 3 move read/write heads from one cylinder to the next cylinder. A pair of two or four is needed. Notice in the chart, the same pair of access pulses are repeated every four cylinders.

Cylinder Location	In →				← Out					
	0	1	2	3	4	5	60	74	75	76
Access 0	1	0	0	1	1	0	1	0	1	1
Access 1	1	1	0	0	1	1	1	0	0	1
Access 2	0	1	1	0	0	1	0	1	0	0
Access 3	0	0	1	1	0	0	0	1	1	0

The four access pulses are sequenced to move the heads in (toward the drive hub) or out (away from the drive hub).

**+Write Data** activates the current switches in the read/write head to record data on the diskette surfaces. This is done each time the write data signal changes.

**+Write Gate** de-activates the read circuits and activates the write circuits for a write operation.

**+Erase Gate** activates the erase circuits for a write operation.

**+Current Enabled** is active when either the write circuits or the erase circuits are active.

**+Select Head 1** selects head 1 when active.

**+Head Engage** loads the read/write heads when active.

**+Index** is a pulse that indicates the start of a track. It is 1.5 to 3.0 ms wide and occurs every 166.7 ms.


**+File Data** is a series of clock and data pulses that represent the data read from the diskette.

**+Diskette Sense** indicates that a 2 or 2D diskette is being used. **Note: 2D diskettes are the only type to be used on the 4300 Processors.**

**-Diskette Drive Sense** is normally minus indicating that the diskette drive uses 2 or 2D diskettes. **Note: 2D diskettes are the only type to be used on the 4300 Processors.**


**+Inner Tracks** decreases the amount of recording current beyond the center cylinders on write operations. This compensates for bit shifting beyond the center cylinders on read operations.

**+Switch Filter** is used with the inner tracks line to farther compensate for bit shifting beyond cylinder 60 for MFM encoding. This line is not used on a write operation.



# ADAPTER CABLE

Signal Name	Edge Connector 01AB2 Board Pins	Yb-Board- Cable End	Adapter Cable at Location A1 of Control Card
Access 0	T1-A11	D02	D02
Access 1	T1-B11	D03	D03
Access 2	T1-C11	D04	D04
Access 3	T1-D11	D05	D05
Write Data 1	T1-A13	B02	B02
Write Gate	T1-D13	B05	B05
Erase Gate	T1-C13	B04	B04
Head Sel 1	U1-A13	B07	B07
Head Engage	U1-D11	D10	D10
Inner Track	T1-E13	B06	B06
+ Erase Current Sense	U1-C13	B09	B09
+ Index	V1-B11	D13	D13
+ File Data	U1-A11	D07	D07
+ Diskette Sense	U1-B13	B08	D08
Filter Switch	V1-A11	D12	D12
+24V	U1-D13	B10	B10
Ground	U1-B11	D08	B08
- Disk Dr Sense	U1-C11	D09	D09
Spare	V1-A13	B12	B12
Spare	T1-E11	D06	D06
+5V	-----	---	B03
-5V	-----	---	B11



**Note:** The logic reset switch is at pin B03 of the Y6 board cable end. For more information concerning this switch see Volume 13 under the heading "MSS Service Aids."

