

# **BEM — OS/3**

## **Operator Command Summary Card**

SPERRY  UNIVAC

UA-0189 Rev. 1

**The BEM programs described in this document are confidential information and proprietary products of the Sperry Univac Division.**

This document contains the latest information available at the time of publication. However, Sperry Univac reserves the right to modify or revise its contents. To ensure that you have the most recent information, contact your local Sperry Univac representative.

SPERRY UNIVAC NEWSCOMP Newspaper Composition Program was used by Application Services in typesetting this publication.

Sperry Univac is a division of Sperry Rand Corporation.

AccuScan, FASTRAND, PAGEWRITER, SPERRY UNIVAC, UNISCOPE, UNISERVO, and UNIVAC are trademarks of Sperry Rand Corporation.


© 1976, 1977 — Sperry Univac Corporation

Printed in U.S.A.

**OPERATOR COMMAND SUMMARY**

**UNSOLICITED KEY-INS TO BEM**

<b>STATUS</b>	List of users on system
<b>CLOSE</b>	Close system to new users.
<b>OPEN</b>	Allow new users.
<b>CANCEL ALL</b>	Terminate all users.
<b>CANCEL Tnnn</b>	Cancel single user.
<b>EOJ</b>	Terminate BEM.
<b>Tnnn message</b>	Send message to one or more users.
<b>SETUP n</b>	Set communications line up.




If line number is zero the message goes to all lines. If terminal number is zero the message goes to all terminals on the line. Thus, T000 broadcasts a message to all terminals on the system.

**USER MESSAGES**

All messages from BEM users are prefixed by the BEM message identification VI12 and the user's terminal ID. If a question mark (?) precedes the message, a reply is required. This reply will be displayed at the user's terminal.

**ICAM KEY-INS**



After the ICAM connect message is issued, the BEM SETUP command must also be issued for that line. Under level 2, this is done automatically.

## **BEM ERROR MESSAGES**

### **INITIALIZATION MESSAGES**

#### **VI01 ICAM PARAM CARD IS MISSING/INVALID**

One of the two PARAM cards specifying either the network name or buffer quantity is missing. The first PARAM card must contain the buffer specification and the second card, the network name. See the section of the manual (UA-0139) concerning the job stream for additional information.

#### **VI02 ERROR IN REQUESTING OR OPENING A LINE**

The ICAM to be used with BEM was not valid. Either no ICAM was loaded prior to initializing BEM or ICAM was not generated correctly. Consult the section of the manual dealing with ICAM generation and the current ICAM User Reference manual.

#### **VI03 MESSAGE INDEX COULD NOT BE LOADED TO DISK**

During initialization, BEM writes the complete message index to disk. The error message indicates that it could not be done successfully. Possible causes could be the lack of any disk scratch space assignments in the job, or a hardware error during initialization. Check the job stream and rerun. ICAM will need to be reloaded.

#### **VI04 ERROR IN PRE-FORMATting DISK SCRATCH SPACE**

In attempting to format the scratch space on disk, an I/O error was encountered. Retry the job, or investigate for possible hardware malfunction.

#### **VI05 NETWORK xxxx COULD NOT BE LOADED**

The network listed in the message could not be loaded due to an ICAM error. Be sure that an ICAM has been loaded, and that the network PARAM card contains the same identifier as was used to generate ICAM.

#### **VI06 PROGRAM CHECK HAS OCCURRED WITHIN INIT**

The most common cause of this error is that insufficient memory was allocated on the BEM job card. Another cause is that an ICAM was not present when BEM attempted to request the communications network. An ICAM generation with errors could also cause this message. If the ICAM is correct, this message indicates a software problem within BEM. Submit all relevant data (dumps, ICAM-gen, job control, configuration) to your local Sperry Univac Customer Representative.

#### **VI07 BEM SYSTEM READY (VER x.x)**

This indicates a successful completion to BEM initialization. The system is ready for use.

#### **VI08 EXTENDED INSTRUCTION SET NOT PRESENT**

BEM requires the extended instruction set feature of the 90/30 (2K COS). Verify that the correct COS is loaded and rerun.

## **VI11 RSP OR LOAD PARAM CARD INVALID**

BEM has detected an error in the RSP or LOAD param card due to an invalid option or format error. Correct and rerun.

## **VI14 NO DISK SPACE ALLOCATED TO BEM (//WORK)**

The // WORK cards which allocate work space for BEM are not present in the job stream, or do not allocate sufficient space for BEM to create a disk workspace pool. Add //WORK cards.

## **VI15 INSUFFICIENT MEMORY FOR RESIDENT PROGRAMS**

The memory partition size stated on the JOB card does not allow enough memory to load the programs stated on the LOAD param card. Either increase the amount of memory on the JOB card or decrease the number of resident programs.

# **RUN TIME MESSAGES**

## **VI10 OUTPUT BAD L=x,T=y**

An output error has occurred when sending data to a terminal. The message is discarded and operation continues. If the error persists, cancel the affected user and investigate the hardware problem. The line (x) and terminal (y) are displayed in the message text.

## **VI12 Tnnn text**

This is a message sent for the terminal identified by Tnnn. It does not represent any error condition within the system.

## **VI20 status text**

This is one of several lines of system status information displayed as a response to a STATUS request.

## **VI21 INVALID KEYIN**

The last key-in to BEM was not accepted. Correct the format and resubmit the request.

## JOB CONTROL

```

                (1)    (2)
// JOB BEM,,10000,,3
// OPTION JOBDUMP
(3) // DVC 20 // LFD PRNTR
(4) // DVC 40 // LFD PUNCH
(5) // DVC RES // LBL $Y$CAT // LFD $Y$CAT
(6) // WORK1
(7) // DVC 50 // VOL USERPK // LFD A
// EXEC BEM,,1 (8)
// PARAM 1,1 (9)
// PARAM NET1 (10)
(12) // PARAM LOAD = (STD)
(13) // PARAM NR = (RDR), NW = (RDR)
// $
BEM TEST SYSTEM ACTIVE (11)
/*
/&
// FIN
```

- 1) Memory size, 65K
- 2) Terminal task limit, 3 will allow 2 terminals.
- 3) Printer to enable /PRINT command
- 4) Punch to enable /PUNCH command
- 5) Catalog to allow passwords
- 6) One standard scratch space
- 7) Library packs for use at the terminals
- 8) High relative priority
- 9) Input and output buffers (one each)
- 10) ICAM network name
- 11) Logon bulletin
- 12) Standard modules are resident
- 13) RSP param card, RDR inaccessible

## **RSP PARAM CARD OPTIONS**

// PARAM NR = *(list)*, NW = *(list)*

*list* may contain:

- LOG — Log Subfile
- PRI — Print Subfile
- PUN — Punch Subfile
- RDR — Input Reader Subfile
- JCS — Job Control Subfile
- RPR — Remote Batch Print Subfile
- RPU — Remote Batch Punch Subfile
- ALL — All Subfiles

## **LOAD CARD OPTIONS**

// PARAM LOAD = *(list)*

*list* may contain:

- EDT — The Editor
- BAS — OS/3 BASIC
- RSP — The Spoolout Processor
- STD — EDT, BASIC, and RSP
- \$FS — FSTATUS function
- \$PR — PRINT function
- \$PU — PUNCH function
- \$RU — RUN function
- \$DE — DELETE function
- \$DI — DISPLAY function
- \$SC — SCREEN function
- MAX — All of the above