


1. Run FAE_Tool.exe


_hashlib.pyd	2014/6/30 下午 0...	PYD 檔案	699 KB
_socket.pyd	2014/6/30 下午 0...	PYD 檔案	45 KB
_ssl.pyd	2014/6/30 下午 0...	PYD 檔案	1,134 KB
bz2.pyd	2014/6/30 下午 0...	PYD 檔案	67 KB
FAE_Tool	2014/12/9 上午 1...	應用程式	23 KB
library	2014/12/9 上午 1...	WinRAR ZIP 壓縮檔	4,209 KB

2. You will get following dialog




3. Input FD8164 IP Address, HostName and password.

Click Execute.



4. It will show remove dynamic burn-in file success.



5. Then, you should be able to do firmware upgrade.