

## Changing the configuration parameters

You can change the parameters that you defined when you installed the IBM System Storage Support for Microsoft Volume Shadow Copy Service and Virtual Disk Service software. You must use the `ibmvfcg.exe` utility to change the parameters.

Table 43 describes the configuration commands that are provided by the `ibmvfcg.exe` utility.

Command	Description	Example
<code>ibmvfcg showcfg</code>	Lists the current settings.	<code>showcfg</code>
<code>ibmvfcg set username &lt;username&gt;</code>	Sets the user name to access the SAN Volume Controller Console.	<code>set username johnny</code>
<code>ibmvfcg set password &lt;password&gt;</code>	Sets the password of the user name that will access the SAN Volume Controller Console.	<code>set password mypassword</code>
<code>ibmvfcg set targetSVC &lt;ipaddress&gt;</code>	Specifies the IP address of the SAN Volume Controller on which the VDisks are located when VDisks are moved to and from the free pool with the <code>ibmvfcg add</code> and <code>ibmvfcg rem</code> commands. The IP address is overridden if you use the <code>-s</code> flag with the <code>ibmvfcg add</code> and <code>ibmvfcg rem</code> commands.	<code>set targetSVC 64.157.185.191</code>
<code>ibmvfcg set backgroundCopy</code>	Sets the background copy rate for FlashCopy.	<code>set backgroundCopy 80</code>
<code>ibmvfcg set usingSSL</code>	Specifies whether to use Secure Sockets Layer protocol to connect to the SAN Volume Controller Console.	<code>ibmvfcg set usingSSL yes</code>
<code>ibmvfcg set cimomPort &lt;portnum&gt;</code>	Specifies the SAN Volume Controller Console port number. The default value is 5999.	<code>ibmvfcg set cimomPort 5999</code>
<code>ibmvfcg set cimomHost &lt;server name&gt;</code>	Sets the name of the server where the SAN Volume Controller Console is installed.	<code>ibmvfcg set cimomHost cimomserver</code>
<code>ibmvfcg set namespace &lt;namespace&gt;</code>	Specifies the namespace value that master console is using. The default value is <code>\root\ibm</code> for CIM v5.1. and <code>/root/ibm</code> for v5.3 or later	<code>ibmvfcg set namespace \root\ibm</code>
<code>ibmvfcg set vssFreeInitiator &lt;WWPN&gt;</code>	Specifies the WWPN of the host. The default value is 5000000000000000. Modify this value only if there is a host already in your environment with a WWPN of 5000000000000000.	<code>ibmvfcg set vssFreeInitiator 5000000000000000</code>
<code>ibmvfcg set vssReservedInitiator &lt;WWPN&gt;</code>	Specifies the WWPN of the host. The default value is 5000000000000001. Modify this value only if there is a host already in your environment with a WWPN of 5000000000000001.	<code>ibmvfcg set vssReservedInitiator 5000000000000001</code>

Command	Description	Example
ibmvmcfc set incrementalFC Yes No	Specifies if incremental FlashCopy has to be used on SVC for the shadow copy	ibmvmcfc set incrementalFC Yes