SEQ 0001

```
.REM    @
```

IDENTIFICATION

PRODUCT CODE:	AC-8528C-MC
PRODUCT NAME:	CZDLDC0 DL11-W DIAG
DATE CREATED:	MARCH 1978
MAINTAINER:	DIAGNOSTIC ENGINEERING
AUTHOR:	DAN CASALETTO

1.0 GENERAL INFORMATION

1.1 ABSTRACT

THIS DIAGNOSTIC IS A LOGIC TEST TO VERIFY THE OPERATION OF THE
DL11-W SERIAL LINE/ REAL TIME CLOCK INTERFACE. THE PROGRAM
WILL RUN WITHOUT ANY SPECIAL TEST FIXTURES BY DEFAULT. HOWEVER, A WRAP
CABLE CAN BE USED AND TESTED BY OPTION (BIT7 OF SWR).

THIS TEST OPERATES ON THE CONSOLE DL11-W SERIAL LINE AND CLOCK INTERFACES
AS WELL AS UP TO FIFTEEN(15) ADDITIONAL IDENTICALLY CONFIGURED DL11-W
SERIAL LINE INTERFACES. THE DEFAULT ADDRESSES ARE:

A. CONSOLE - 177560 SERIAL LINE
             177546 CLOCK

B. OTHER SERIAL LINE - 776500 FIRST SERIAL LINE ADDRESS
                               OF 15 CONSECUTIVE SERIAL
                               LINE ADDRESSES

THE PROGRAM IS DESIGNED TO RUN ON ANY PDP-11 WITH 8K OF MEMORY
AND A DL11-W MODULE. IT CAN BE RUN UNDER XXDP,APT, AND ACT MONITORS,
AND ON PROCESSORS WITH NO HARDWARE SWITCH REGISTER,
SOFTWARE SWITCH REGISTER = LOCATION 176

POWER FAILURE IS SUPPORTED FOR SYSTEMS WITH CORE MEMORY.

NOTE: THIS DIAGNOSTIC WITH THE SWR = 000020
       (CLOCK TESTS ONLY) SHOULD BE USED ON SWITCHLESS CPU'S
       TO TEST KW-11L LINE CLOCK MODULES.

1.2 SYSTEM REQUIREMENTS

1.2.1 EQUIPMENT

STANDARD 11 FAMILY COMPUTER WITH A CONSOLE OUTPUT DEVICE
AND 8K OF MEMORY.

1.2.2 STORAGE

THE PROGRAM USES MEMORY FROM 00000 TO 22372

1.3 ASSUMPTIONS

A. IF THE UNIT UNDER TEST (UUT) IS THE CONSOLE , THE PROGRAM WILL ASSUME THE REAL TIME CLOCK (RTC) IS ENABLED AND WILL TEST IT UNLESS THE TESTS ARE DISABLED BY BIT6 OF THE SWR.

B. IF THE UUT IS NOT THE CONSOLE, THE RTC IS NOT TESTED FOR THAT DEVICE.

C. THE PROGRAM WILL ASSUME THE ERROR FLAG BITS AND THE BREAK FUNCTION OF THE DL11-W ARE DISABLED AND WILL NOT TEST THESE FUNCTIONS UNLESS ENABLED BY BIT10 (FOR ERROR FLAGS) AND BIT8 (FOR BREAK) OF THE SWR. THE DEFAULT CHARACTER SIZE IS 8 BITS (SEE PARA 2.3.2).

2.0 OPERATING INSTRUCTIONS

2.1 LOADING PROCEDURE

USE STANDARD PROCEDURE FOR PDP-11 ABSOLUTE BINARY FORMATTED TAPES.

2.2 STARTING PROCEDURE

LOAD THE SWITCH REGISTER WITH SETTING
(SOFTWARE SWITCH REGISTER LOCATION = 176)

A. START AT 200.
AFTER CHECKING THE TRANSMITTER, THE PROGRAM WILL PRINT ITS IDENTIFICATION AND REPORT THE NUMBER OF DEVICES UNDER TEST (NUMBER IS OCTAL).
"END PASS" IS PRINTED AFTER A FULL PASS HAS BEEN MADE ON ALL DEVICES UNDER TEST.

B. START AT 204. ****NOTE****
THE "ECHO" TEST WILL BE EXECUTED. AN "*" IS PRINTED AT THE BEGINNING OF THE TEST. THE ECHO TEST READS A CHARACTER FROM THE TERMINAL,WRITES THAT CHARACTER TO THE TERMINAL AND REPORTS ANY ERROR FLAGS SET IN THE RECEIVER BUFFER.
A CONTROL-C HALTS THE TEST AND PRINTS "STOP" AT THE TERMINAL
CONTINUING RESTARTS THE ECHO TEST.

C. START AT 210. ****NOTE****
THE TERMINAL OUTPUT TEST WILL BE EXECUTED. DEPRESSING ANY CHARACTER AT THE TERMINAL, HALTS THE TEST. CONTINUING RESTARTS THE TEST.
THE TEST OUTPUTS 32 CHARACTERS ON A LINE AND REPEATS THE PATTERN EVERY THREE LINES. THE PATTERN IS AS FOLLOWS
(OCTAL CODE 040 --> 377):

	(OCTAL CODE)
!"#$%&'()*+,-./0123456789:;<=>?	(040 --> 077)
@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_	(100 --> 137)
'ABCDEFGHIJKLMNOPQRSTUVWXYZ	(140 --> 177) [LOWER CASE ALPHA]

THIS BOTTOM LINE COULD BE THE FOLLOWING IF THE TERMINAL
DOES NOT HAVE LOWER CASE:

@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\ [UPPER CASE ALPHA]

****NOTE****

IF THE TESTING ON TERMINIALS OTHER THAN THE CONSOLE IS DESIRED ;;++C
FOR TESTS B OR C,SEE SECTION 2.3.4. AND 2.3.5. OF THIS DOCUMENT. ;;++C

2.3 OPERATING PROCEDURE

2.3.1 OPERATIONAL SWITCH SETTINGS

NOTE: IF NO HARDWARE SWITCH REGISTER IS AVAILABLE THE PROGRAM WILL AUTOMATICALLY USE THE CONTENTS OF LOCATION 176 AS THE SOFTWARE SWITCH REGISTER. THE USER SHOULD SET THIS LOCATION BEFORE STARTING THE PROGRAM. IF A HARDWARE SWITCH IS AVAILABLE AND A SOFTWARE SWR IS DESIRED, PUT ALL SWITCHES UP.

BIT15	- HALT ON ERROR
BIT14	- SCOPE LOOP
BIT13	- INHIBIT ERROR TYPEOUT
BIT12	- UNUSED
BIT11	- UNUSED
BIT10	- ENABLE ERROR FLAGS TESTS
BIT09	- LOOP ON ERROR
BIT08	- ENABLE BREAK FUNCTION TESTS
BIT07	- ENABLE DATA TEST WITH WRAP CABLE
BIT06	- INHIBIT RTC TESTS (ALLOW ONLY SLU TESTS)
BIT05	- ALLOW MANUAL SETTING OF "$DEVM" (DEVICE MAP)
BIT04	- INHIBIT SLU TESTS (ALLOW ONLY LINE CLOCK TESTS)

BUILT INTO THE PROGRAM IS THE ABILITY TO DYNAMICALLY CHANGE THE CONTENTS OF SWREG DURING PROGRAM EXECUTION. BY STRIKING ^G (CNTL G) ON CONSOLE TTY THE OPERATOR SETS A REQUEST FLAG TO CHANGE THE CONTENTS OF SWREG, WHICH IS PROCESSED IN KEY AREAS OF THE PROGRAM CODE (IE) ERROR ROUTINES, AFTER HALTS END OF PASS, AND OTHER APPLICABLE AREAS. BECAUSE THIS DIAGNOSTIC USES THE MAINTENANCE BIT OF THE SERIAL LINE, THE CONTROL-G SHOULD BE ISSUED DURING PROGRAM TYPEOUTS AT THAT TIME THE MAINTENANCE BIT IS SURE TO BE CLEAR.

IF A CONTROL-G IS DETECTED, UPON EXECUTION THE CONTENTS OF THE SWREG ARE DUMPED IN OCTAL ON THE CONSOLE TTY AND ANY CHANGES ARE REQUESTED

```
(IE)    SWR=XXXXXX  NEW=
```

POSSIBLE RESPONSES ARE:

1.	<CR>	IF NO CHANGES ARE TO BE MADE
2.	6 DIGITS 0-7	TO REPRESENT IN OCTAL THE NEW SWITCH REGISTER VALUE ;LAST DIGIT FOLLOWED BY <CR>.
3.	^U	TO ALLOW REENTERING VALUE IF ERROR IS COMMITTED KEYING IN SWREG VALUE.

2.3.2 SETTING BITS PER CHARACTER

THIS PROGRAM DEFAULTS TO TESTING 8 BITS PER CHARACTER. IF THE SERIAL LINE IS SET FOR 5-->7 BITS PER CHARACTER, SET THE MEMORY LOCATION "$USWR" AS FOLLOWS:

CHAR. SIZE (# OF BITS)	"$USWR" CONTENTS (BINARY)	(OCTAL)
8	100000000	400
7	010000000	200
6	001000000	100
5	000100000	40

"$USWR" IS USED IN THE DATA PATH TESTS TO LIMIT THE BINARY COUNT TEST PATTERN TO THE NUMBER OF BITS SELECTED ON THE SERIAL LINE.

2.3.3 RUNNING UNDER APT

THE APT MAILBOX IS LOCATED AT LOCATION 500, TO ALLOW ADDITIONAL SERIAL LINE VECTOR ASSIGNMENTS TO THE 400 AREA OF MEMORY.

THE EXECUTION TIMES PROVIDED ARE FOR EXECUTION WITH AN 11/34 PROCESSOR, CORE MEMORY, AND 110 BAUD.

2.3.4 RUN WITH ALTERNATE CONSOLE ADDRESS

TO USE A CONSOLE ADDRESS OTHER THAN 177560, OR VECTOR OTHER THAN 60, THE OPERATOR MUST SUPPLY THE PROGRAM WITH THE CORRECT ADDRESSES BY INSERTING THEM AT THE TAG LABELED "CRCSR":

```
CRCSR:  ADDRESS OF RECEIVER RCSR
CRBUF:  ADDRESS OF RECEIVER BUFFER
CTCSR:  ADDRESS OF TRANSMITTER CSR
CTBUF:  ADDRESS OF TRANSMITTER BUFFER
CRVECT: ADDRESS OF RECEIVER VECTOR
CRPSW:  ADDRESS OF ASSOCIAED PSW
CTVEC:: ADDRESS OF TRANSMITTER VECTOR
CTPSW:  ADDRESS OF ASSOCIATED PSW
```

2.3.5 TESTING ADDITIONAL SERIAL LINES

THIS PROGRAM WILL SUPPORT TESTING OF MULTIPLE SLU'S. IT REQUIRES THE ADDRESS OF THE FIRST ADDITIONAL RCSR (STORED AT "$BASE") AND ITS INTERRUPT VECTOR (STORED AT "$VECT1"); AND WILL BE ABLE TO ADDRESS ANY SLU STARTING AT THE SPECIFIED BASE ADDRESS UP TO 15 CONSECUTIVE DEVICES.

```
EXAMPLE:        $BASE:  776500
                $VECT1: 300
```

THE PROGRAM WILL BE ABLE TO TEST THE CONSOLE PLUS ANY ADDITIONAL DL11-W SLU'S WITHIN THE RANGE 776500 --> 776660

$BASE AND $VECT1 DEFAULT TO 776500 AND 300 RESPECTIVELY.

THE PROGRAM ASSOCIATES UNIT NUMBERS TO DEVICES AS FOLLOWS:
(NUMBERS IN PARENTHESIS ARE OCTAL)

```
UNIT# 0 -->  CONSOLE [ADDRESS STORED AT "CRCSR"]
UNIT# 1 -->  BASE ADDRESS STORED AT "$BASE"
             ASSOCIATED BASE VECTOR STORED AT"$VECT1"
UNIT# 2 -->  BASE ADDRESS + (10)
             BASE VECTOR + (10)
UNIT# 3 -->  BASE ADDRESS + (20)
             BASE VECTOR + (20)
UNIT# 4 -->  BASE ADDRESS + (30)
             BASE VECTOR + (30)
        !
        !
        !
        !
        !
        !
        V
UNIT#17 -->  BASE ADDRESS + (160)
             BASE VECTOR + (160)
```

STARTING AT LOCATION 200 AND HAVING BIT5 OF SWR CLEAR, THE PROGRAM WILL SELF
SIZE THE NUMBER OF DEVICES (STARTING AT THE BAS ADDRESS) AND
STORE A BIT MAP AT "$DEVM" (DEVICE MAP) TO INDICATE WHICH UNIT NUMBERS
ARE PRESENT AND WILL BE TESTED:

```
-------------------------------------------------
! UNIT ! UNIT ! .....! UNIT ! UNIT ! CONSOLE!
!  15  !  14  ! .....!   2  !   1  !        !
-------------------------------------------------
```

A BIT MAP CAN BE ENTERED AT "$DEVM" PRIOR TO STARTING THE PROGRAM
SETTING BIT5 OF THE SWR INHIBITS THE SELF-SIZING AND DEVICE MAP
GENERATION,AND USES THE VALUE STORED BY THE OPERATOR.

EXAMPLE:

```
SWR  =  000040          [BINARY  0 000 000 000 100 000]
$BASE:  776500
$VECT1: 300

$DEVM:  13      [BINARY - 0 000 000 000 001 011]

THE PROGRAM WILL TEST -
        UNIT# 0 = CONSOLE
        UNIT# 1 = 776500 ; 300
        UNIT# 3 = 776520 ; 320
```

2.4 EXECUTION TIMES - (110 BAUD)

```
        LONGEST SUBTEST TIME = 50 SECONDS
        PASS TIME            = 60 SECONDS
        ADDITIONAL DEVICES   = 55 SECONDS/DEVICE
```

3.0 ERROR REPORTING

IF A ROUTINE FAILS AND THE INHIBIT ERROR TYPEOUT (BIT13) OF THE SWR IS NOT SET, A PRINTOUT RESULTS IN THE FORM:

```
        "(SOME ASCII MESSAGE)"
        TEST#   ERR PC   RCSR    [ANY APPLICABLE DAT HEADINGS]
        XXXXXX  XXXXXX   XXXXXX   [ANY APPLICABLE DATA]

                NOTE: "RCSR" IS DEPENDENT ON THE FAILURE
                        & THEREFORE COULD BE TCSR,RBUF,TBUF,OR LKS
```

WHERE "XXXXXX" IS AN OCTAL NUMBER.
THIS ERROR PRINTOUT OCCURS PROVIDED THE ERROR THAT EXISTS WOULD NOT HINDER THE TYPEOUT. IN CASES WHERE IT IS NOT POSSIBLE TO PRINT AN ERROR MESSAGE (I.E. FATAL CONSOLE TRANSMITTER FAILURES), A HALT OCCURS AND THE PC CAN BE EXAMINED BY THE OPERATOR TO FIND THE ERROR INFORMATION IN THE PROGRAM LISTING.

NOTE: FOR SOFTWARE SWITCH OPERATION, THE SWITCH REGISTER CAN BE CHANGED BY TYPING A CONTROL-G AT THE CONSOLE DURING ERROR PRINTOUTS. AFTER CONTINUING FROM THE ERROR HALT THE OLD SWR CONTENTS IS DISPLAYED AND THE NEW CONTENTS CAN BE ENTERED.
IF ERROR HALTS ARE DISABLED, THE CONTROL-G RESPONSE OCCURS IMMEDIATELY FOLLOWING THE TYPEOUT.

4.0 SUBROUTINE ABSTRACTS

4.1 TRAPCATCHER

THIS IS A SERIES OF INSTRUCTIONS STARTING AT LOCATION 0 DESIGNED TO DETECT AND ISOLATE UNEXPECTED TRAPS TO THE TRAP AND INTERRUPT VECTOR AREA OF MEMORY.

EACH VECTOR ENTRANCE ADDRESS IS LOADED WITH THE ADDRESS OF THE NEXT LOCATION. THE NEXT LOCATION IS LOADED WITH A BREAK POINT TRAP (000003). THUS AN ILLEGAL TRAP OR INTERRUPT CAUSES A TRAP THROUGH THE BPT VECTOR(14) WHICH POINTS TO THE "CATCH" ROUTINE.

THE "CATCH" ROUTINE REPORTS THE PC THAT CAUSED THE ORIGINAL TRAP AND THE LOCATION OF THE TRAP VECTOR (IF UNDER APT, AN ERROR IS INDICATED TO APT). AFTER REPORTING THE ERROR THE PROGRAM HALTS. THE PROGRAM MUST BE RESTARTED AT THIS POINT.

4.2 WRPSW

THIS ROUTINE IS USED TO WRITE THE PSW BY POPPING VALUES FROM THE STACK. THIS METHOD IS USED TO BE COMPATIBLE WITH ALL 11 FAMILY PROCESSORS.

4.3 SCOPE

THIS ROUTINE CALL IS PLACED BETWEEN EACH SUBTEST. IT RECORDS THE STARTING ADDRESS OF EACH SUBTEST AS IT IS BEING ENTERED AND UPDATES THE TEST NUMBER. IF A SCOPE LOOP IS REQUESTED, IT WILL JUMP TO THE START OF THE SUBTEST AT WHICH THE SCOPE LOOP IS REQUESTED.

4.4 ERROR

THIS ROUTINE CALL IS PLACED WHEREEVER AN ERROR REPORT
IS DESIRED. THE LOWER BYTE OF THIS CALL IS USED AS THE ERROR NUMBER
AND AS A POINTER INTO THE ERROR TABLE . THIS ROUTINE REPORTS ERRORS
TO APT USING "$APTYPE" AND TYPES ERROR REPORTS TO THE CONSOLE
USING "$ERRTYPE".

4.5 $POWER

THIS ROUTINE SAVES ALL GENERAL REGISTERS DURING POWER-DOWN
AND RESTORES THEM AT POWER-UP. IF A POWER FAILURE OCCURS
"POWER" IS PRINTED AT THE CONSOLE AFTER POWER IS RESTORED.

4.6 CKSWR

THIS ROUTINE CALL IS USED TO DETECT THE RECEPTION OF A CONTROL-G
FROM THE CONSOLE. THE CALL USES "$READ" TO PERFORM THE CONTROL-G
SEQUENCE OF DISPLAYING THE CONTENTS OF THE SOFTWARE SWITCH REGISTER
AND THE ENTERING THE NEW CONTENTS FROM THE TERMINAL.

%

```
                                .SBTTL  BASIC DEFINITIONS

                                ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
001100                          STACK=  1100
                                .EQUIV  EMT,ERROR       ;;BASIC DEFINITION OF ERROR CALL
                                .EQUIV  IOT,SCOPE       ;;BASIC DEFINITION OF SCOPE CALL

                                ;*MISCELLANEOUS DEFINITIONS
000011                          HT=     11              ;;CODE FOR HORIZONTAL TAB
000012                          LF=     12              ;;CODE FOR LINE FEED
000015                          CR=     15              ;;CODE FOR CARRIAGE RETURN
000200                          CRLF=   200             ;;CODE FOR CARRIAGE RETURN-LINE FEED
177776                          PS=     177776          ;;PROCESSOR STATUS WORD
                                .EQUIV  PS,PSW
177774                          STKLMT= 177774          ;;STACK LIMIT REGISTER
177772                          PIRQ=   177772          ;;PROGRAM INTERRUPT REQUEST REGISTER
177570                          DSWR=   177570          ;;HARDWARE SWITCH REGISTER
177570                          DDISP=  177570          ;;HARDWARE DISPLAY REGISTER

                                ;*GENERAL PURPOSE REGISTER DEFINITIONS
000000                          R0=     %0              ;;GENERAL REGISTER
000001                          R1=     %1              ;;GENERAL REGISTER
000002                          R2=     %2              ;;GENERAL REGISTER
000003                          R3=     %3              ;;GENERAL REGISTER
000004                          R4=     %4              ;;GENERAL REGISTER
000005                          R5=     %5              ;;GENERAL REGISTER
000006                          R6=     %6              ;;GENERAL REGISTER
000007                          R7=     %7              ;;GENERAL REGISTER
000006                          SP=     %6              ;;STACK POINTER
000007                          PC=     %7              ;;PROGRAM COUNTER

                                ;*PRIORITY LEVEL DEFINITIONS
000000                          PR0=    0               ;;PRIORITY LEVEL 0
000040                          PR1=    40              ;;PRIORITY LEVEL 1
000100                          PR2=    100             ;;PRIORITY LEVEL 2
000140                          PR3=    140             ;;PRIORITY LEVEL 3
000200                          PR4=    200             ;;PRIORITY LEVEL 4
000240                          PR5=    240             ;;PRIORITY LEVEL 5
000300                          PR6=    300             ;;PRIORITY LEVEL 6
000340                          PR7=    340             ;;PRIORITY LEVEL 7

                                ;*"SWITCH REGISTER" SWITCH DEFINITIONS
100000                          SW15=   100000
040000                          SW14=   40000
020000                          SW13=   20000
010000                          SW12=   10000
004000                          SW11=   4000
002000                          SW10=   2000
001000                          SW09=   1000
000400                          SW08=   400
000200                          SW07=   200
```



```
000100                          SW06=   100
000040                          SW05=   40
000020                          SW04=   20
000010                          SW03=   10
000004                          SW02=   4
000002                          SW01=   2
000001                          SW00=   1
                                .EQUIV  SW09,SW9
                                .EQUIV  SW08,SW8
                                .EQUIV  SW07,SW7
                                .EQUIV  SW06,SW6
                                .EQUIV  SW05,SW5
                                .EQUIV  SW04,SW4
                                .EQUIV  SW03,SW3
                                .EQUIV  SW02,SW2
                                .EQUIV  SW01,SW1
                                .EQUIV  SW00,SW0

                                ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
100000                          BIT15=  100000
040000                          BIT14=  40000
020000                          BIT13=  20000
010000                          BIT12=  10000
004000                          BIT11=  4000
002000                          BIT10=  2000
001000                          BIT09=  1000
000400                          BIT08=  400
000200                          BIT07=  200
000100                          BIT06=  100
000040                          BIT05=  40
000020                          BIT04=  20
000010                          BIT03=  10
000004                          BIT02=  4
000002                          BIT01=  2
000001                          BIT00=  1
                                .EQUIV  BIT09,BIT9
                                .EQUIV  BIT08,BIT8
                                .EQUIV  BIT07,BIT7
                                .EQUIV  BIT06,BIT6
                                .EQUIV  BIT05,BIT5
                                .EQUIV  BIT04,BIT4
                                .EQUIV  BIT03,BIT3
                                .EQUIV  BIT02,BIT2
                                .EQUIV  BIT01,BIT1
                                .EQUIV  BIT00,BIT0

                                ;*BASIC "CPU" TRAP VECTOR ADDRESSES
000004                          ERRVEC= 4               ;;TIME OUT AND OTHER ERRORS
000010                          RESVEC= 10              ;;RESERVED AND ILLEGAL INSTRUCTIONS
000014                          TBITVEC=14              ;;"T" BIT
000014                          TRTVEC= 14              ;;TRACE TRAP
000014                          BPTVEC= 14              ;;BREAKPOINT TRAP (BPT)
000020                          IOTVEC= 20              ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024                          PWRVEC= 24              ;;POWER FAIL
000030                          EMTVEC= 30              ;;EMULATOR TRAP (EMT) **ERROR**
000034                          TRAPVEC=34              ;;"TRAP" TRAP
```

```
                        000060                  TKVEC=  60              ;;TTY KEYBOARD VECTOR
                        000064                  TPVEC=  64              ;;TTY PRINTER VECTOR
                        000240                  PIRQVEC=240             ;;PROGRAM INTERRUPT REQUEST VECTOR
                        176500                          ABASE=  176500
                        000300                          AVECT1= 300
                        000400                          AUSWR=  400
                        000001                          $TN=    1
                        161000                          $SWR=   161000
                        000003                          BPT=    000003          ;THIS IS THE COMMAND FOR A TRAP
                                                                                ;   THROUGH 14 (BPT TRAP)

                        000000                          .=0
                                                ;;**************************************************************
                                                        ;*ALL UNUSED LOCATIONS FROM 4-776 CONTAIN A ".+2,BPT"
                                                        ;*SEQUENCE TO CATCH ILLEGAL TRAPS & INTERRUPPTS
                                                        ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS


                        000014                          .=14                    ;THE BPT TRAP VECTOR POINTS TO THE
000014  012254                                  .WORD   CATCH                   ;   ILLEGAL TRAP HANDLER "CATCH"
000016  000340                                  .WORD   340

                        000042                  .=      42
000042  000000                                  .WORD   0



                        000174                  .=      174
000174  000000                 DISPREG:.WORD   0
000176  000000                 SWREG:  .WORD   0

                        000200                  .=200
000200  000137  002546                          JMP     START           ;DO INTERFACE TEST
000204  000137  014762                          JMP     ECHO            ;DO ECHO TEST
000210  000137  015202                          JMP     OUTTST          ;DO OUTPUT TEST TO TERMINAL
```



```

                        000500                  .=      500
                                                .SBTTL  ACT11 HOOKS

                                                ;;**************************************************************
                                                ;HOOKS REQUIRED BY ACT11
                        000500                          $SVPC=.                 ;SAVE PC
                        000046                          .=46
000046  012152                                  $ENDAD                  ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
                        000052                          .=52
000052  000000                                  .WORD   0               ;;2)SET LOC.52 TO ZERO
                        000500                          .=$SVPC                 ;; RESTORE PC
                                                .SBTTL  APT PARAMETER BLOCK

                                                ;;**************************************************************
                                                ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
                                                ;;**************************************************************
                        000500                          .$X=.   ;;SAVE CURRENT LOCATION
                        000024                          .=24    ;;SET POWER FAIL TO POINT TO START OF PROGRAM
000024  000200                                  200     ;;FOR APT START UP
                        000044                          .=44    ;;POINT TO APT INDIRECT ADDRESS PNTR.
000044  000500                                  $APTHDR ;;POINT TO APT HEADER BLOCK
                        000500                          .=.$X   ;;RESET LOCATION COUNTER
                                                ;;**************************************************************
                                                ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
                                                ;INTERFACE SPEC.

000500                                          $APTHD:
000500  000000                  $HIBTS: .WORD   0       ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
000502  001066                  $MBADR: .WORD   $MAIL   ;;ADDRESS OF APT MAILBOX (BITS 0-15)
000504  000050                  $TSTM:  .WORD   50      ;;RUN TIM OF LONGEST TEST
000506  000060                  $PASTM: .WORD   60      ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
000510  000055                  $UNITM: .WORD   55      ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
000512  000030                          .WORD   $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)

```

```
                                .SBTTL  COMMON TAGS

                                ;;*****************************************************************
                                ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
                                ;*USED IN THE PROGRAM.

001000                                  .=1000
001000                          $CMTAG:                         ;;START OF COMMON TAGS
001000  000000                          .WORD   0
001002     000                  $TSTNM: .BYTE   0               ;;CONTAINS THE TEST NUMBER
001003     000                  $ERFLG: .BYTE   0               ;;CONTAINS ERROR FLAG
001004  000000                  $ICNT:  .WORD   0               ;;CONTAINS SUBTEST ITERATION COUNT
001006  000000                  $LPADR: .WORD   0               ;;CONTAINS SCOPE LOOP ADDRESS
001010  000000                  $LPERR: .WORD   0               ;;CONTAINS SCOPE RETURN FOR ERRORS
001012  000000                  $ERTTL: .WORD   0               ;;CONTAINS TOTAL ERRORS DETECTED
001014     000                  $ITEMB: .BYTE   0               ;;CONTAINS ITEM CONTROL BYTE
001015     001                  $ERMAX: .BYTE   1               ;;CONTAINS MAX. ERRORS PER TEST
001016  000000                  $ERRPC: .WORD   0               ;;CONTAINS PC OF LAST ERROR INSTRUCTION
001020  000000                  $GDADR: .WORD   0               ;;CONTAINS ADDRESS OF 'GOOD' DATA
001022  000000                  $BDADR: .WORD   0               ;;CONTAINS ADDRESS OF 'BAD' DATA
001024  000000                  $GDDAT: .WORD   0               ;;CONTAINS 'GOOD' DATA
001026  000000                  $BDDAT: .WORD   0               ;;CONTAINS 'BAD' DATA
001030  000000                          .WORD   0               ;;RESERVED--NOT TO BE USED
001032  000000                          .WORD   0
001034     000                  $AUTOB: .BYTE   0               ;;AUTOMATIC MODE INDICATOR
001035     000                  $INTAG: .BYTE   0               ;;INTERRUPT MODE INDICATOR
001036  000000                          .WORD   0
001040  177570                  SWR:    .WORD   DSWR            ;;ADDRESS OF SWITCH REGISTER
001042  177570                  DISPLAY: .WORD  DDISP           ;;ADDRESS OF DISPLAY REGISTER
001044  177560                  $TKS:   177560                  ;;TTY KBD STATUS
001046  177562                  $TKB:   177562                  ;;TTY KBD BUFFER
001050  177564                  $TPS:   177564                  ;;TTY PRINTER STATUS REG. ADDRESS
001052  177566                  $TPB:   177566                  ;;TTY PRINTER BUFFER REG. ADDRESS
001054     000                  $NULL:  .BYTE   0               ;;CONTAINS NULL CHARACTER FOR FILLS
001055     002                  $FILLS: .BYTE   2               ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
001056     012                  $FILLC: .BYTE   12              ;;INSERT FILL CHARS. AFTER A "LINE FEED"
001057     000                  $TPFLG: .BYTE   0               ;;"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
001060  000000                  $ESCAPE:0                       ;;ESCAPE ON ERROR ADDRESS
001062     077                  $QUES:  .ASCII  /?/             ;;QUESTION MARK
001063     015                  $CRLF:  .ASCII  <15>            ;;CARRIAGE RETURN
001064  000012                  $LF:    .ASCIZ  <12>            ;;LINE FEED
                                ;;*****************************************************************
                                .SBTTL  APT MAILBOX-ETABLE

                                ;;*****************************************************************
                                .EVEN
001066                          $MAIL:                          ;;APT MAILBOX
001066  000000                  $MSGTY: .WORD   AMSGTY          ;;MESSAGE TYPE CODE
001070  000000                  $FATAL: .WORD   AFATAL          ;;FATAL ERROR NUMBER
001072  000000                  $TESTN: .WORD   ATESTN          ;;TEST NUMBER
001074  000000                  $PASS:  .WORD   APASS           ;;PASS COUNT
001076  000000                  $DEVCT: .WORD   ADEVCT          ;;DEVICE COUNT
001100  000000                  $UNIT:  .WORD   AUNIT           ;;I/O UNIT NUMBER
001102  000000                  $MSGAD: .WORD   AMSGAD          ;;MESSAGE ADDRESS
001104  000000                  $MSGLG: .WORD   AMSGLG          ;;MESSAGE LENGTH
001106                          $ETABLE:                        ;;APT ENVIRONMENT TABLE
```



```
001106     000                  $ENV:   .BYTE   AENV    ;;ENVIRONMENT BYTE
001107     000                  $ENVM:  .BYTE   AENVM   ;;ENVIRONMENT MODE BITS
001110  000000                  $SWREG: .WORD   ASWREG  ;;APT SWITCH REGISTER
001112  000400                  $USWR:  .WORD   AUSWR   ;;USER SWITCHES
001114  000000                  $CPUOP: .WORD   ACPUOP  ;;CPU TYPE,OPTIONS
                                ;*                      BITS 15-11=CPU TYPE
                                ;*                              11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
                                ;*                              11/70=06,PDQ=07,Q=10
                                ;*                      BIT 10=REAL TIME CLOCK
                                ;*                      BIT  9=FLOATING POINT PROCESSOR
                                ;*                      BIT  8=MEMORY MANAGEMENT
001116     000                  $MAMS1: .BYTE   AMAMS1  ;;HIGH ADDRESS,M.S. BYTE
001117     000                  $MTYP1: .BYTE   AMTYP1  ;;MEM. TYPE,BLK#1
                                ;*                      MEM.TYPE BYTE   --  (HIGH BYTE)
                                ;*                              900 NSEC CORE=001
                                ;*                              300 NSEC BIPOLAR=002
                                ;*                              500 NSEC MOS=003
001120  000000                  $MADR1: .WORD   AMADR1  ;;HIGH ADDRESS,BLK#1
                                ;*                        MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE
001122     000                  $MAMS2: .BYTE   AMAMS2  ;;HIGH ADDRESS,M.S. BYTE
001123     000                  $MTYP2: .BYTE   AMTYP2  ;;MEM.TYPE,BLK#2
001124  000000                  $MADR2: .WORD   AMADR2  ;;MEM.LAST ADDRESS,BLK#2
001126     000                  $MAMS3: .BYTE   AMAMS3  ;;HIGH ADDRESS,M.S.BYTE
001127     000                  $MTYP3: .BYTE   AMTYP3  ;;MEM.TYPE,BLK#3
001130  000000                  $MADR3: .WORD   AMADR3  ;;MEM.LAST ADDRESS,BLK#3
001132     000                  $MAMS4: .BYTE   AMAMS4  ;;HIGH ADDRESS,M.S.BYTE
001133     000                  $MTYP4: .BYTE   AMTYP4  ;;MEM.TYPE,BLK#4
001134  000000                  $MADR4: .WORD   AMADR4  ;;MEM.LAST ADDRESS,BLK#4
001136  000300                  $VECT1: .WORD   AVECT1  ;;INTERRUPT VECTOR#1,BUS PRIORITY#1
001140  000000                  $VECT2: .WORD   AVECT2  ;;INTERRUPT VECTOR#2BUS PRIORITY#2
001142  176500                  $BASE:  .WORD   ABASE   ;;BASE ADDRESS OF EQUIPMENT UNDER TEST
001144  000000                  $DEVM:  .WORD   ADEVM   ;;DEVICE MAP
001146                          $ETEND:
                                .MEXIT
```

```
                                .SBTTL  ERROR POINTER TABLE

                                ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
                                ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
                                ;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
                                ;*NOTE1:        IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
                                ;*NOTE2:        EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

                                ;*      EM              ;;POINTS TO THE ERROR MESSAGE
                                ;*      DH              ;;POINTS TO THE DATA HEADER
                                ;*      DT              ;;POINTS TO THE DATA
                                ;*      DF              ;;POINTS TO THE DATA FORMAT


001146                          $ERRTB:

001146                           $ERRTB:
001146  015266                          EM1                     ;"CAN NOT ACCESS TCSR"
001150  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001152  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001154  000000                          0

001156  015312                          EM2                     ;"CAN NOT ACCESS TBUF"
001160  021476                          DH2                     ;"TEST# ERR PC  TBUF"
001162  022214                          DT2                     ;$TESTN,$ERRPC,TBUF
001164  000000                          0

001166  015336                          EM3                     ;"TCSR DONE NOT CLEARED WITH TBUF FULL"
001170  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001172  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001174  000000                          0

001176  015403                          EM4                     ;"TCSR DONE NOT SET"
001200  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001202  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001204  000000                          0

001206  015425                          EM5                     ;TCSR DONE NOT SET WITH RESET
001210  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001212  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001214  000000                          0

001216  015462                          EM6                     ;"CAN NOT ACCESS RCSR"
001220  021523                          DH6                     ;"TEST# ERR PC  RCSR"
001222  022224                          DT6                     ;$TESTN,$ERRPC,RCSR
001224  000000                          0

001226  015506                          EM7                     ;"CAN NOT ACCESS RBUF"
001230  021550                          DH7                     ;"TEST# ERR PC  RBUF"
001232  022234                          DT7                     ;$TESTN,$ERRPC,RBUF
001234  000000                          0

001236  015532                          EM10                    ;"CAN NOT ACCESS LKS"
001240  021575                          DH10                    ;"TEST# ERR PC  LKS"
001242  022244                          DT10                    ;$TESTN,$ERRPC,LKS
001244  000000                          0
```



```
001246  015555                          EM11                    ;"BIT0 OF TCSR NOT CLEAR AFTER RESET"
001250  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001252  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001254  000000                          0

001256  015620                          EM12                    ;"CAN NOT SET BIT0 OF TCSR"
001260  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001262  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001264  000000                          0

001266  015651                          EM13                    ;"CAN NOT CLEAR BIT0 OF TCSR"
001270  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001272  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001274  000000                          0

001276  015704                          EM14                    ;"RESET DID NOT CLEAR BIT0 OF TCSR"
001300  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001302  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001304  000000                          0

001306  015745                          EM15                    ;"BIT2 OF TCSR NOT CLEAR AFTER RESET"
001310  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001312  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001314  000000                          0

001316  016010                          EM16                    ;"CAN NOT SET BIT2 OF TCSR"
001320  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001322  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001324  000000                          0

001326  016041                          EM17                    ;"CAN NOT CLEAR BIT2 OF TCSR"
001330  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001332  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001334  000000                          0

001336  016074                          EM20                    ;"RESET DID NOT CLEAR BIT2 OF TCSR"
001340  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001342  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001344  000000                          0

001346  016135                          EM21                    ;"BIT6 OF TCSR NOT CLEAR AFTER RESET2
001350  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001352  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001354  000000                          0

001356  016201                          EM22                    ;"XMIT INTERRUPT WITH PRIORITY 7"
001360  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001362  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001364  000000                          0

001366  016236                          EM23                    ;"CAN NOT SET BIT6 OF TCSR"
001370  021451                          DH1                     ;"TEST# ERR PC  TCSR"
001372  022204                          DT1                     ;$TESTN,$ERRPC,TCSR
001374  000000                          0
```

```
  807  001376  016267                    EM24            ;"CAN NOT CLEAR BIT6 OF TCSR"
  808  001400  021451                    DH1             ;"TEST# ERR PC  TCSR"
  809  001402  022204                    DT1             ;$TESTN,$ERRPC,TCSR
  810  001404  000000                    0
  811
  812  001406  016322                    EM25            ;"RESET DID NOT CLEAR BIT6 OF TCSR"
  813  001410  021451                    DH1             ;"TEST# ERR PC  TCSR"
  814  001412  022204                    DT1             ;$TESTN,$ERRPC,TCSR
  815  001414  000000                    0
  816
  817  001416  016363                    EM26            ;"BIT6 OF RCSR NOT CLEAR AFTER RESET"
  818  001420  021523                    DH6             ;"TEST# ERR PC  RCSR"
  819  001422  022224                    DT6             ;$TESTN,$ERRPC,RCSR
  820  001424  000000                    0
  821
  822  001426  016426                    EM27            ;"RCVR INTERRUPT WITH PRIORITY 7"
  823  001430  021523                    DH6             ;"TEST# ERR PC  RCSR"
  824  001432  022224                    DT6             ;$TESTN,$ERRPC,RCSR
  825  001434  000000                    0
  826
  827  001436  016465                    EM30            ;"CAN NOT SET BIT6 OF RCSR"
  828  001440  021523                    DH6             ;"TEST# ERR PC  RCSR"
  829  001442  022224                    DT6             ;$TESTN,$ERRPC,RCSR
  830  001444  000000                    0
  831
  832  001446  016516                    EM31            ;"CAN NOT CLEAR BIT6 OF RCSR"
  833  001450  021523                    DH6             ;"TEST# ERR PC  RCSR"
  834  001452  022224                    DT6             ;$TESTN,$ERRPC,RCSR
  835  001454  000000                    0
  836
  837  001456  016551                    EM32            ;"CAN NOT CLEAR BIT6 OF RCSR WITH RESET2
  838  001460  021523                    DH6             ;"TEST# ERR PC  RCSR"
  839  001462  022224                    DT6             ;$TESTN,$ERRPC,RCSR
  840  001464  000000                    0
  841
  842  001466  016617                    EM33            ;"BIT6 OF LKS NOT CLEAR AFTER RESET"
  843  001470  021575                    DH10            ;"TEST# ERR PC  LKS"
  844  001472  022244                    DT10            ;$TESTN,$ERRPC,LKS
  845  001474  000000                    0
  846
  847  001476  016661                    EM34            ;"LKS INTERRUPT WITH PRIORITY 7"
  848  001500  021575                    DH10            ;"TEST# ERR PC  LKS"
  849  001502  022244                    DT10            ;$TESTN,$ERRPC,LKS
  850  001504  000000                    0
  851
  852  001506  016717                    EM35            ;"CAN NOT SET BIT6 OF LKS"
  853  001510  021575                    DH10            ;"TEST# ERR PC  LKS"
  854  001512  022244                    DT10            ;$TESTN,$ERRPC,LKS
  855  001514  000000                    0
  856
  857  001516  016747                    EM36            ;"CAN NOT CLEAR BIT6 OF LKS"
  858  001520  021575                    DH10            ;"TEST# ERR PC  LKS"
  859  001522  022244                    DT10            ;$TESTN,$ERRPC,LKS
  860  001524  000000                    0
  861
  862  001526  017001                    EM37            ;"RESET DID NOT CLEAR BIT6 OF LKS"
```



```
  863  001530  021575                    DH10            ;"TEST# ERR PC  LKS"
  864  001532  022244                    DT10            ;$TESTN,$ERRPC,LKS
  865  001534  000000                    0
  866
  867  001536  017041                    EM40            ;"DUAL ADDRESSING ERROR"
  868  001540  021621                    DH40            ;"TEST# ERR PC  GOOD    BAD"
  869  001542  022254                    DT40            ;$TESTN,$ERRPC,$GDADR,$BDCSR
  870  001544  000000                    0
  871
  872  001546  017067                    EM41            ;"BIT7 OF LKS NOT SET AFTER RESET2
  873  001550  021575                    DH10            ;"TEST# ERR PC  LKS"
  874  001552  022244                    DT10            ;$TESTN,$ERRPC,LKS
  875  001554  000000                    0
  876
  877  001556  017127                    EM42            ;"CAN NOT CLEAR BIT7 OF LKS"
  878  001560  021575                    DH10            ;"TEST# ERR PC  LKS"
  879  001562  022244                    DT10            ;$TESTN,$ERRPC,LKS
  880  001564  000000                    0
  881
  882  001566  017161                    EM43            ;"BIT7 OF LKS DOES NOT SET"
  883  001570  021575                    DH10            ;"TEST# ERR PC  LKS"
  884  001572  022244                    DT10            ;$TESTN,$ERRPC,LKS
  885  001574  000000                    0
  886
  887  001576  017212                    EM44            ;"RTC INTERRUPT AT PRIORITY 7"
  888  001600  021575                    DH10            ;"TEST# ERR PC  LKS"
  889  001602  022244                    DT10            ;$TESTN,$ERRPC,LKS
  890  001604  000000                    0
  891
  892  001606  017246                    EM45            ;"RTC INTERRUPTS WHEN DISABLED"
  893  001610  021575                    DH10            ;"TEST# ERR PC  LKS"
  894  001612  022244                    DT10            ;$TESTN,$ERRPC,LKS
  895  001614  000000                    0
  896
  897  001616  017303                    EM46            ;"RTC INTERRUPT DID NOT OCCUR"
  898  001620  021575                    DH10            ;"TEST# ERR PC  LKS"
  899  001622  022244                    DT10            ;$TESTN,$ERRPC,LKS
  900  001624  000000                    0
  901
  902  001626  017303                    EM47            ;"RTC INTERRUPT DID NOT OCCUR"
  903  001630  021575                    DH10            ;"TEST# ERR PC  LKS"
  904  001632  022244                    DT10            ;$TESTN,$ERRPC,LKS
  905  001634  000000                    0
  906
  907  001636  017337                    EM50            ;"RTC DOUBLE INTERRUPT"
  908  001640  021575                    DH10            ;"TEST# ERR PC  LKS"
  909  001642  022244                    DT10            ;$TESTN,$ERRPC,LKS
  910  001644  000000                    0
  911
  912  001646  017364                    EM51            ;"RESET DID NOT CLEAR RTC INTERRUPT"
  913  001650  021575                    DH10            ;"TEST# ERR PC  LKS"
  914  001652  022244                    DT10            ;$TESTN,$ERRPC,LKS
  915  001654  000000                    0
  916
  917  001656  017414                    EM52            ;"RTC INTERRUPT DID NOT CLEAR WITH BIT7 OF LKS"
  918  001660  021575                    DH10            ;"TEST# ERR PC  LKS"
```

```
  919  001662  022244                    DT10                ;$TESTN,$ERRPC,LKS
  920  001664  000000                    0
  921
  922  001666  017471                    EM53
  923  001670  021655                    DH53                ;"TEST# ERR PC  LKS   CNT1   CNT2"
  924  001672  022266                    DT53                ;$TESTN,$ERRPC,LKS,FIRST,SECND
  925  001674  000000                    0
  926
  927  001676  017515                    EM54                ;"XMIT INTERRUPTS WHEN DISABLED"
  928  001700  021451                    DH1                 ;"TEST# ERR PC  TCSR"
  929  001702  022204                    DT1                 ;$TESTN,$ERRPC,TCSR
  930  001704  000000                    0
  931
  932  001706  017653                    EM55                ;"XMIT DID NOT INTERRUPT"
  933  001710  021451                    DH1                 ;"TEST# ERR PC  TCSR"
  934  001712  022204                    DT1                 ;$TESTN,$ERRPC,TCSR
  935  001714  000000                    0
  936
  937  001716  017553                    EM56                ;"XMIT INTERRUPT AT PRIORITY 7"
  938  001720  021451                    DH1                 ;"TEST# ERR PC  TCSR"
  939  001722  022204                    DT1                 ;$TESTN,$ERRPC,TCSR
  940  001724  000000                    0
  941
  942  001726  017611                    EM57                ;"XMIT INTERRUPTS WITH ENABLE CLEAR"
  943  001730  021451                    DH1                 ;"TEST# ERR PC  TCSR"
  944  001732  022204                    DT1                 ;$TESTN,$ERRPC,TCSR
  945  001734  000000                    0
  946
  947  001736  017653                    EM60                ;"XMIT DID NOT INTERRUPT"
  948  001740  021451                    DH1                 ;"TEST# ERR PC  TCSR"
  949  001742  022204                    DT1                 ;$TESTN,$ERRPC,TCSR
  950  001744  000000                    0
  951
  952  001746  017702                    EM61                ;"XMIT RE-INTERRUPTED"
  953  001750  021451                    DH1                 ;"TEST# ERR PC  TCSR"
  954  001752  022204                    DT1                 ;$TESTN,$ERRPC,TCSR
  955  001754  000000                    0
  956
  957  001756  017726                    EM62                ;"LOADING TBUF DID NOT CLEAR INTERRUPT"
  958  001760  021451                    DH1                 ;"TEST# ERR PC  TCSR"
  959  001762  022204                    DT1                 ;$TESTN,$ERRPC,TCSR
  960  001764  000000                    0
  961
  962  001766  017773                    EM63                ;"RCVR ACTIVE NOT SET"
  963  001770  021523                    DH6                 ;"TEST# ERR PC  RCSR"
  964  001772  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
  965  001774  000000                    0
  966
  967  001776  020017                    EM64                ;"RECEIVER DONE NEVER SET"
  968  002000  021523                    DH6                 ;"TEST# ERR PC  RCSR"
  969  002002  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
  970  002004  000000                    0
  971
  972  002006  020043                    EM65                ;"RCVR ACTIVE NOT CLEARED WITH DONE SET2
  973  002010  021523                    DH6                 ;"TEST# ERR PC  RCSR"
  974  002012  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
```



```
  975  002014  000000                    0
  976
  977  002016  020111                    EM66                ;"RESET DID NOT CLEAR RCVR DONE"
  978  002020  021523                    DH6                 ;"TEST# ERR PC  RCSR"
  979  002022  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
  980  002024  000000                    0
  981
  982  002026  020147                    EM67                ;"RDR ENABLE SET DID NOT CLEAR RCVR DONE"
  983  002030  021523                    DH6                 ;"TEST# ERR PC  RCSR"
  984  002032  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
  985  002034  000000                    0
  986
  987  002036  020212                    EM70                ;"READING RBUF DID NOT CLEAR RCVR DONE"
  988  002040  021523                    DH6                 ;"TEST# ERR PC  RCSR"
  989  002042  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
  990  002044  000000                    0
  991
  992  002046  020257                    EM71                ;"RCVR INTERRUPTS WITH ENABLE CLEAR"
  993  002050  021523                    DH6                 ;"TEST# ERR PC  RCSR"
  994  002052  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
  995  002054  000000                    0
  996
  997  002056  020426                    EM72                ;"RCVR DID NOT INTERRUPT"
  998  002060  021523                    DH6                 ;"TEST# ERR PC  RCSR"
  999  002062  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
 1000  002064  000000                    0
 1001
 1002  002066  020321                    EM73                ;"RCVR INTERRUPTS AT PRIORITY 7"
 1003  002070  021523                    DH6                 ;"TEST# ERR PC  RCSR"
 1004  002072  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
 1005  002074  000000                    0
 1006
 1007  002076  020357                    EM74                ;"RCVR INTERRUPT REQUEST PASSED WITH ENABLE CLEAR"
 1008  002100  021523                    DH6                 ;"TEST# ERR PC  RCSR"
 1009  002102  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
 1010  002104  000000                    0
 1011
 1012  002106  020426                    EM75                ;"RCVR DID NOT INTERRUPT"
 1013  002110  021523                    DH6                 ;"TEST# ERR PC  RCSR"
 1014  002112  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
 1015  002114  000000                    0
 1016
 1017  002116  020455                    EM76                ;"RECEIVER RE-INTERRUPTED"
 1018  002120  021523                    DH6                 ;"TEST# ERR PC  RCSR"
 1019  002122  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
 1020  002124  000000                    0
 1021
 1022  002126  020501                    EM77                ;"READING RBUF DID NOT CLEAR INTERRUPT"
 1023  002130  021523                    DH6                 ;"TEST# ERR PC  RCSR"
 1024  002132  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
 1025  002134  000000                    0
 1026
 1027  002136  020546                    EM100               ;"RESET DID NOT CLEAR RCVR INTERRUPT"
 1028  002140  021523                    DH6                 ;"TEST# ERR PC  RCSR"
 1029  002142  022224                    DT6                 ;$TESTN,$ERRPC,RCSR
 1030  002144  000000                    0
```

```
                                        EM101                   ;"'OR' FLAG DID NOT SET"
002146  020611                          DH6
002150  021523                          DT6                     ;$TESTN,$ERRPC,RCSR
002152  022224                          0
002154  000000

                                        EM102                   ;"'ERROR' NOT SET WITH 'OR' FLAG"
002156  020637                          DH6                     ;"TEST# ERR PC  RCSR"
002160  021523                          DT6                     ;$TESTN,$ERRPC,RCSR
002162  022224                          0
002164  000000

                                        EM103                   ;"BREAK DID NOT TRANSMIT ALL ZEROES"
002166  020676                          DH103                   ;"TEST# ERR PC  RCSR  DATA"
002170  021722                          DT103                   ;$TESTN,$ERRPC,RCSR,$BDDAT
002172  022302                          0
002174  000000

                                        EM104                   ;"BREAK DID NOT SET FRAMING ERROR"
002176  020734                          DH6                     ;"TEST# ERR PC  RCSR"
002200  021523                          DT6                     ;$TESTN,$ERRPC,RCSR
002202  022224                          0
002204  000000

                                        EM105                   ;"DATA COMPARE ERROR"
002206  020771                          DH105                   ;"TEST# ERR PC  RCSR  GOOD  BAD"
002210  021757                          DT105                   ;$TESTN,$ERRPC,RCSR,GD,BD
002212  022314                          0
002214  000000

                                        EM106                   ;"DATA COMPARE ERROR WITH CABLE"
002216  021014                          DH105                   ;"TEST# ERR PC  RCSR    GOOD    BAD"
002220  021757                          DT105                   ;$TESTN,$ERRPC,RCSR,GD,BD
002222  022314                          0
002224  000000

                                        EM107                   ;"TIMEOUT IN EXERCISER TEST"
002226  021052                          DH6                     ;"TEST# ERR PC  RCSR"
002230  021523                          DT6                     ;$TESTN,$ERRPC,RCSR
002232  022224                          0
002234  000000

                                        EM110                   ;"INCORRECT RECEIVE COUNT
002236  021104                          DH110                   ;"TEST# ERR PC  RCSR    TRANS   RCV"
002240  022023                          DT110                   ;$TESTN,$ERRPC,RCSR,XMTCNT,RCVCNT
002242  022330                          0
002244  000000

                                        EM111                   ;"DATA COMPARE ERROR IN EXERCISER"
002246  021134                          DH105                   ;"TEST# ERR PC  RCSR    GOOD    BAD"
002250  021757                          DT105                   ;$TESTN,$ERRPC,RCSR,GD,BD
002252  022314                          0
002254  000000

                                        EM112                   ;"TRAP CATCHER"
002256  021174                          DH112                   ;"TEST#   ERR PC  RCSR   OLDPC  TRAP ADR"
002260  022067                          DT112                   ;$TESTN,$ERRPC,RCSR,OLDPC,BDVECT
002262  022344                          0
002264  000000

                                        EM113                   ;"NO CLK INTERRUPT IN EXERCISER"
002266  021211                          DH10                    ;"TEST#  ERR PC  LKS"
002270  021575                          DT10                    ;$TESTN,$ERRPC,LKS
002272  022244                          0
002274  000000
```



```
                                        EM114                   ;"'ERROR' NOT SET WITH 'FR' FLAG"
002276  021247                          DH6                     ;"TEST# ERR PC  RCSR"
002300  021523                          DT6                     ;$TESTN,$ERRPC,RCSR
002302  022224                          0
002304  000000

                                        EM115                   ;RCV ACTVIE NOT CLEAR WITH INIT
002306  021306                          DH6                     ;"TEST# ERR PC  RCSR"
002310  021523                          DT6                     ;$TESTN,$ERRPC,RCSR
002312  022224                          0
002314  000000

                                        EM116                   ;RCV ACTIVE WITHOUT "START" BIT
002316  021345                          DH6                     ;"TEST# ERR PC  RCSR"
002320  021523                          DT6                     ;$TESTN,$ERRPC,RCSR
002322  022224                          0
002324  000000

                                        EM117                   ;RDR ENABLE NOT CLEAR WITH RCV ACTIVE
002326  021404                          DH6                     ;"TEST# ERR PC  RCSR"
002330  021523                          DT6                     ;$TESTN,$ERRPC,RCSR
002332  022224                          0
002334  000000

002336  000000          CTSTFL: .WORD   0               ;CONSLE UNDER TEST FLAG
002340  000000          TMP1:   .WORD   0               ;TEMP LOCATION FOR TABLE OFFSETS
002342  000000          TMP2:   .WORD   0               ;TEMP LOCATION FOR DEVICE COUNT
002344  000000          TMP3:   .WORD   0               ;LOCATION FOR DEVICE MAP BIT TEST MASK
                        ;REGISTER AND VECTOR ADDRESSES FOR THE DL-11W UNDER TEST

002346  000000          RCSR:   .WORD   0
002350  000000          RBUF:   .WORD   0
002352  000000          TCSR:   .WORD   0
002354  000000          TBUF:   .WORD   0
002356  000000          RVECT:  .WORD   0
002360  000000          RPSW:   .WORD   0
002362  000000          TVECT:  .WORD   0
002364  000000          TPSW:   .WORD   0

                        ;CONSOLE REGISTER AND VECTOR ADDRESSES FOR THE DL-11W

002366  177560          CRCSR:  177560                  ;ADDRESS OF RECEIVER COMMAND/STATUS REGISTER
00237C  177562          CRBUF:  177562                  ;ADDRESS OF RECEIVER BUFFER
002372  177564          CTCSR:  177564                  ;ADDRESS OF TRANSMITTER COMMAND/STATUS REGISTER
002374  177566          CTBUF:  177566                  ;ADDRESS OF TRANSMITTER BUFFER
002376  000060          CRVECT: 60                      ;RECEIVER INTERRUPT VECTOR
002400  000062          CRPSW:  62
002402  000064          CTVECT: 64                      ;TRANSMITTER INTERRUPT VECTOR
002404  000066          CTPSW:  66

                        ;REAL TIME CLOCK REGISTER AND VECTOR ADDRESSES
002406  177546          LKS:    .WORD   177546
002410  000100          RTCVT:  .WORD   100
002412  000102          RTCPSW: .WORD   102

002414  000020          ADRTBL: .BLKW   20
002454  000020          VCTTBL: .BLKW   20
```

```
                                        ERROR POINTER TABLE

                                        ;SUBROUTINE TO GENERATE DEVICE ADDRESS TABLE

002514  012702  002414        DEVADR: MOV     #ADRTBL,R2      ;POINT R2 TO THE DEVICE ADDRESS TABLE
002520  013700  001142                MOV     $BASE,R0        ;LOAD BASE DEVICE ADDRESS IN R0
002524  010001                        MOV     R0,R1           ;
002526  062701  000170                ADD     #170,R1         ;POINT R1 TO LAST DEVICE ADDRESS
002532  010022                1$:     MOV     R0,(R2)+        ;MOVE DEVICE ADDRESS TO TABLE
002534  062700  000010                ADD     #10,R0          ;POINT R0 TO NEXT DEVICE ADDRESS
002540  020001                        CMP     R0,R1           ;FINISHED GENERATING TABLE?
002542  003773                        BLE     1$              ;BR, IF LAST DEVICE ADDRESS NOT LOADED
002544  000207                        RTS     PC


002546  005037  001070        START:  CLR     $FATAL          ;CLEAR ERROR NO.
002552  005037  001066                CLR     $MSGTYP         ;CLEAR MESSAGE TYPE
002556  005037  001072                CLR     $TESTN          ;CLEAR TEST NO.
002562  005037  002336                CLR     CTSTFL          ;CLEAR CONSOLE UNDER TEST FLAG
002566  005037  001076                CLR     $DEVCT          ;CLEAR DEVICE COUNT
002572  005037  001100                CLR     $UNIT           ;CLEAR UNIT NUMBER
002576  005737  001112                TST     $USWR           ;IS $USWR LOADED?
002602  001003                        BNE     1$              ;BR IF YES
002604  012737  000400  001112        MOV     #400,$USWR      ;ELSE, DEFAULT TO $USWR=400
002612  012737  000006  000004 1$:     MOV     #6,@#4          ;INITIALIZE TIMEOUT VECTORS TO TRAP
002620  012737  000003  000006        MOV     #3,@#6          ;  CATCHER ROUTINE


                                        .SBTTL  INITIALIZE THE COMMON TAGS
                                        ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
002626  012706  001000                MOV     #$CMTAG,R6      ;;FIRST LOCATION TO BE CLEARED
002632  005026                        CLR     (R6)+           ;;CLEAR MEMORY LOCATION
002634  022706  001040                CMP     #SWR,R6 ;;DONE?
002640  001374                        BNE     .-6             ;;LOOP BACK IF NO
002642  012706  001000                MOV     #1000,SP                ;;SETUP THE STACK POINTER
                                        ;;INITIALIZE A FEW VECTORS
002646  012737  013000  000020        MOV     #$SCOPE,@#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
002654  012737  000340  000022        MOV     #340,@#IOTVEC+2 ;;LEVEL 7
002662  012737  012304  000030        MOV     #$ERROR,@#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
002670  012737  000340  000032        MOV     #340,@#EMTVEC+2 ;;LEVEL 7
002676  012737  014704  000034        MOV     #$TRAP,@#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
002704  012737  000340  000036        MOV     #340,@#TRAPVEC+2;LEVEL 7
002712  012737  012622  000024        MOV     #$PWRDN,@#PWRVEC ;;POWER FAILURE VECTOR
002720  012737  000340  000026        MOV     #340,@#PWRVEC+2 ;;LEVEL 7
002726  013737  012132  012124        MOV     $ENDCT,$EOPCT   ;;SETUP END-OF-PROGRAM COUNTER
002734  005037  001060                CLR     $ESCAPE         ;;CLEAR THE ESCAPE ON ERROR ADDRESS
002740  112737  000001  001015        MOVB    #1,$ERMAX       ;;ALLOW ONE ERROR PER TEST
002746  012737  002746  001006        MOV     #.,$LPADR       ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
002754  012737  002754  001010        MOV     #.,$LPERR       ;;SETUP THE ERROR LOOP ADDRESS
                                        ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
                                        ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
002762  013746  000004                MOV     @#ERRVEC,-(SP)  ;;SAVE ERROR VECTOR
002766  012737  003022  000004        MOV     #64$,@#ERRVEC   ;;SET UP ERROR VECTOR
002774  012737  177570  001040        MOV     #DSWR,SWR       ;;SETUP FOR A HARDWARE SWICH REGISTER
003002  012737  177570  001042        MOV     #DDISP,DISPLAY  ;;AND A HARDWARE DISPLAY REGISTER
003010  022777  177777  176022        CMP     #-1,@SWR        ;;TRY TO REFERENCE HARDWARE SWR
003016  001012                        BNE     66$             ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
                                                                ;;AND  THE HARDWARE SWR IS NOT = -1
```



```
                                        INITIALIZE THE COMMON TAGS

003020  000403                        BR      65$             ;;BRANCH IF NO TIMEOUT
003022  012716  003030        64$:    MOV     #65$,(SP)       ;;SET UP FOR TRAP RETURN
003026  000002                        RTI
003030  012737  000176  001040 65$:    MOV     #SWREG,SWR      ;;POINT TO SOFTWARE SWR
003036  012737  000174  001042        MOV     #DISPREG,DISPLAY
003044  012637  000004        66$:    MOV     (SP)+,@#ERRVEC  ;;RESTORE ERROR VECTOR

003050  005037  001074                CLR     $PASS           ;;CLEAR PASS COUNT
003054  132737  000200  001107        BITB    #APTSIZE,$ENVM  ;;TEST USER SIZE UNDER APT
003062  001403                        BEQ     67$             ;;YES,USE NON-APT SWITCH
003064  012737  001110  001040        MOV     #$SWREG,SWR     ;;NO,USE APT SWITCH REGISTER
003072                          67$:
003072  032777  000020  175740        BIT     #BIT4,@SWR      ;TEST CLOCK ONLY?
003100  001404                        BEQ     INIT            ;BR IF NOT
003102  005237  002336                INC     CTSTFL          ;ELSE, SET CONSOLE TEST FLAG TO ENABLE CLOCK TESTS
003106  000137  004056                JMP     ID              ;  AND JUMP TO TYPE PROGRAM ID
003112  132737  000001  001106 INIT:  BITB    #BIT0,$ENV      ;CHECK IF ON APT
003120  001404                        BEQ     MANL            ;BR IF NOT APT
003122  132737  000200  001107        BITB    #BIT7,$ENVM     ;DID APT SIZE
003130  001056                        BNE     APTSZD          ;BR, IF APT SIZED
003132  032777  000040  175700 MANL:  BIT     #BIT5,@SWR      ;WAS "$DEVM" MANUALLY SET?
003140  001052                        BNE     APTSZD          ;IF YES, SKIP SELF-SIZING

003142  004737  002514        SIZE:   JSR     PC,DEVADR       ;GENERATE DEVICE ADDRESS TABLE
003146  005037  002342                CLR     TMP2            ;CLR TEMP LOCATION TO KEEP DEVICE COUNT
003152  005037  001144                CLR     $DEVM           ;CLEAR DEVICE MAP
003156  013703  000004                MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
003162  012737  003212  000004        MOV     #4$,@#4         ;SET TIMEOUT POINTER
003170  013700  001142                MOV     $BASE,R0        ;LOAD BASE ADDRESS
003174  062700  000160                ADD     #160,R0         ;POINT R0 TO UNIT #15 (UNIT#0=CONSOLE)
003200  005710                3$:     TST     (R0)            ;CHECK FOR DEVICE EXISTANCE
003202  005237  001144                INC     $DEVM           ;INDICATE DEVICE EXISTANCE IN DEVICE MAP
003206  005237  002342                INC     TMP2            ;INCREMENT DEVICE COUNT
003212  012706  001000        4$:     MOV     #1000,SP                ;RESET STACK POINTER
003216  006337  001144                ASL     $DEVM           ;ADJUST DEVICE MAP FOR NEXT UNIT CHECK
003222  162700  000010                SUB     #10,R0          ;POINT R0 TO NEXT DEVICE NUMBER
003226  023700  001142                CMP     $BASE,R0        ;FINISHED SIZING?
003232  003762                        BLE     3$              ;BR, IF BASE ADDRESS HAS NOT BEEN CHECKED
003234  013700  002366                MOV     CRCSR,R0        ;LOAD CONSOLE DEVICE ADDRESS
003240  012737  003260  000004        MOV     #5$,@#4         ;SET UP TIMEOUT POINTER
003246  005710                        TST     (R0)            ;TEST FOR CONSOLE EXISTANCE
003250  005237  001144                INC     $DEVM           ;INDICATE CONSOLE EXISTANCE IN DEVICE MAP
003254  005237  002342                INC     TMP2            ;INCREMENT DEVICE COUNT
003260  010337  000004        5$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
003264  000415                        BR      VCTADR          ;BR TO GENERATE VECTOR ADDRESS TABLE

003266  005037  002342        APTSZD: CLR     TMP2            ;CLEAR TEMP LOCATION TO KEEP DEVICE CNT
003272  013702  001144                MOV     $DEVM,R2        ;MOVE DEVICE MAP TO R2
003276  005702                TSTDVM: TST     R2              ;TEST MSB OF DEVICE MAP
003300  100002                        BPL     1$              ;BR, IF MSB IS ZERO
003302  005237  002342                INC     TMP2            ;INCREMENT DEVICE COUNT, IF MSB=1
003306  006302                1$:     ASL     R2              ;SHIFT NEXT BIT INTO MSB POSITION
003310  001401                        BEQ     DVADT           ;BR, IF NO OTHER BITS ARE SET IN $DEVM
003312  000771                        BR      TSTDVM          ;CONTINUE CHECKING $DEVM, IF MORE BITS SET
003314  004737  002514        DVADT:  JSR     PC,DEVADR       ;GENERATE DEVICE ADDRESS TABLE
```

```
                                        ;GENERATE VECTOR ADDRESS TABLE
                                        ;
003320  012702  002454          VCTADR: MOV     #VCTTBL,R2      ;GET LOCATION OF VECTOR TABLE
003324  113700  001136                  MOVB    @#$VECT1,R0     ;COPY BASE VECTOR
003330  042700  177400                  BIC     #177400,R0      ;CLEAR BYTE SIGN EXTENSION
003334  010001                          MOV     R0,R1           ;
003336  062701  000170                  ADD     #170,R1         ;POINT R1 TO LAST DEVICE VECTOR
003342  010022                  1$:     MOV     R0,(R2)+        ;PUT VECTOR ADDRESS IN TABLE
003344  062700  000010                  ADD     #10,R0          ;POINT R0 TO NEXT VECTOR ADDRESS
003350  020001                          CMP     R0,R1           ;FINISHED GENERATING VECTOR TABLE?
003352  003773                          BLE     1$              ;BR, IF LAST VECTOR IS NOT LOADED
                                        ;
                                        ;MOVE DEVICE COUNT INTO DEVICE COUNT MESSAGE
                                        ;
003354  013700  002342                  MOV     TMP2,R0         ;COPY DEVICE COUNT INTO R0
003360  005001                          CLR     R1              ;CLEAR AUXILARY REGISTER
003362  000300                          SWAB    R0              ;PUT DEVICE COUNT IN UPPER BYTE OF R0
003364  006300                          ASL     R0              ;MOVE MSB OF COUNT INTO
003366  006300                          ASL     R0              ;MSB OF R0
003370  006300                  SHIFT:  ASL     R0              ;PUT MSB OF COUNT INTO CARRY
003372  106101                          ROLB    R1              ;MOVE MSB OF COUNT INTO R1
003374  006300                          ASL     R0              ;MOVE NEXT BIT TO CARRY
003376  106101                          ROLB    R1              ;MOVE INTO R1
003400  006300                          ASL     R0              ;MOVE LAST BIT OF DIGIT
003402  106101                          ROLB    R1              ;INTO R1
003404  062701  000060                  ADD     #60,R1          ;CONVERT DIGIT TO ASCII
003410  000301                          SWAB    R1              ;MOVE DIGIT TO UPPER BYTE
003412  032701  000020                  BIT     #BIT4,R1        ;HAVE BOTH DIGITS BEEN MOVED TO R1?
003416  001764                          BEQ     SHIFT           ;BR, IF NOT
003420  010137  022154                  MOV     R1,M2A          ;MOVE DEVICE COUNT TO OUTPUT MESSAGE
                                        ;
                                        ;
003424  052737  000002  002344  BEGIN:  BIS     #BIT1,TMP3      ;SET UP BIT MASK TO TEST $DEVM FOR DEVICES EXCEPT CONSOL
003432  005037  002340                  CLR     TMP1            ;CLEAR LOCATION TO STORE TABLE OFFSETS
003436  032737  000001  001144          BIT     #BIT0,$DEVM     ;IS CONSOLE TO BE TESTED?
003444  001001                          BNE     TCONS           ;BR, IF CONSOLE IS TO BE TESTED
003446  000414                          BR      TSTDEV          ;BR, TO TEST OTHER DEVICES
003450  005237  002336          TCONS:  INC     CTSTFL          ;INDICATE CONSOLE UNDER TEST
003454  012700  002366                  MOV     #CRCSR,R0       ;SET UP CONSOLE DEVICE ADDRESSES
003460  012701  002346                  MOV     #RCSR,R1        ;POINT R1 TO UUT ADDRESS TABLE
003464  012021                  1$:     MOV     (R0)+,(R1)+     ;TRANSFER CONSOLE ADDRESSES
003466  022701  002364                  CMP     #TPSW,R1        ;FINISHED TRANSFER?
003472  002374                          BGE     1$              ;BR, IF NOT
003474  000137  003622                  JMP     TST1            ;GO TEST CONSOLE INTERFACE
                                        ;
                                        ;PREPARE ADDRESSES AND VECTORS FOR UUT
003500  033737  002344  001144  TSTDEV: BIT     TMP3,$DEVM      ;CHECK TO SEE IF DEVICE IS TO BE TESTED
003506  001010                          BNE     SETADR          ;BR, IF YES
003510  006337  002344                  ASL     TMP3            ;SHIFT MASK TO CHECK NEXT $DEVM BIT
003514  062737  000002  002340          ADD     #2,TMP1         ;INCREMENT TABLE INDEX
003522  005237  001100                  INC     $UNIT           ;INCREMENT UNIT NUMBER
003526  000764                          BR      TSTDEV          ;GO TEST NEXT BIT OF DEVICE MAP
                                        ;
003530  005237  001100          SETADR: INC     $UNIT           ;UPDATE UNIT NUMBER
003534  006337  002344                  ASL     TMP3            ;UPDATE DEVICE MAP TEST MASK
003540  013702  002340                  MOV     TMP1,R2         ;MOVE TABLE OFFSET TO R2
```



```
003544  062737  000002  002340          ADD     #2,TMP1         ;UPDATE TABLE OFFSET FOR NEXT DEVICE
003552  016200  002414                  MOV     ADRTBL(R2),R0   ;PUT UUT ADDRESS INTO R0
003556  012701  002346                  MOV     #RCSR,R1        ;POINT R1 TO STORAGE AREA FOR UUT ADDRESSES
003562  010021                  ADR:    MOV     R0,(R1)+        ;TRANSFER UUT ADDRESS
003564  062700  000002                  ADD     #2,R0           ;POINT TO NEXT UUT REGISTER
003570  030027  000006                  BIT     R0,#6           ;FINISHED TRANSFER?
003574  001372                          BNE     ADR             ;BR, IF NOT
                                        ;
003576  016200  002454                  MOV     VCTTBL(R2),R0   ;PUT UUT VECTOR INTO R0
003602  010021                  VECT:   MOV     R0,(R1)+        ;TRANSFER UUT VECTORS TO ACTIVE TABLE AREA
003604  062700  000002                  ADD     #2,R0           ;POINT TO NEXT VECTOR
003610  030027  000006                  BIT     R0,#6           ;FINISHED TRANSFER?
003614  001372                          BNE     VECT            ;BR, IF NOT
003616  000137  003622                  JMP     TST1            ;GO TEST DEVICE
                                        ;
                                        ;
```

```
                                        ;;*****************************************************************
                                        ;*TEST 1        TEST ABILITY TO REFERENCE TCSR
                                        ;;*****************************************************************
003622  000004                  TST1:   SCOPE
003624  013703  000004                  MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
003630  012737  003644  000004          MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
003636  005777  176510                  TST     @TCSR           ;REFERENCE THE XMIT COMMAND/STATUS REG.
003642  000412                        BR      4$              ; GO TO END OF TEST

003644  022626                  1$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER TIMEOUT
003646  005737  002336                  TST     CTSTFL          ;CHECK IF DEVICE IS CONSOLE
003652  001002                        BNE     2$              ;IF YES, SKIP ERROR TYPEOUT
003654  104001                        ERROR   1               ;REPORT ERROR TO APT & TTY
003656  000404                        BR      4$              ;BR TO END OF TEST
003660                          2$:
003660  004737  013170                  JSR     PC,$ATY4                ;;ONLY REPORT A FATAL ERROR
003664  000001                        1                               ;;THE ERROR NUMBER (FROM APT LIST)
003666  000000                  3$:     HALT
003670  010337  000004          4$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR


                                        ;;*****************************************************************
                                        ;*TEST 2        TEST ABILITY TO REFERENCE TBUF
                                        ;;*****************************************************************
003674  000004                  TST2:   SCOPE
003676  013703  000004                  MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
003702  012737  003716  000004          MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
003710  005777  176440                  TST     @TBUF           ;REFERENCE THE XMIT BUFFER
003714  000412                        BR      4$              ;GO TO END OF  TEST

003716  022626                  1$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER TIMEOUT
003720  005737  002336                  TST     CTSTFL          ;CHECK IF DEVICE IS CONSOLE
003724  001002                        BNE     2$              ;IF YES, SKIP ERROR TYPEOUT
003726  104002                        ERROR   2               ;REPORT ERROR TO APT & TTY
003730  000404                        BR      4$              ;BR TO END OF TEST
003732                          2$:
003732  004737  013170                  JSR     PC,$ATY4                ;;ONLY REPORT A FATAL ERROR
003736  000002                        2                               ;;THE ERROR NUMBER (FROM APT LIST)
003740  000000                  3$:     HALT
003742  010337  000004          4$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
```



```
                                        ;;*****************************************************************
                                        ;*TEST 3        TEST THAT TCSR BIT7(DONE) CLEARS WHEN XBUF IS LOADED
                                        ;;*****************************************************************
003746  000004                  TST3:   SCOPE
003750  005077  176400                  CLR     @TBUF           ;LOAD XBUF
003754  105777  176372                  TSTB    @TCSR           ;CHECK DONE
003760  100016                        BPL     3$              ;BR IF CLEAR
                                                                ;FILL SECOND BUFFER, BECAUSE REFRESH COULD CAUSE
                                                                ;   FIRST TEST TO FAIL
003762  005077  176366                  CLR     @TBUF           ;FILL DOUBLE BUFFER
003766  105777  176360                  TSTB    @TCSR           ;CHECK DONE
003772  100011                        BPL     3$              ;BR IF CLEAR

003774  005737  002336                  TST     CTSTFL          ;CHECK IF DEVICE IS CONSOLE
004000  001002                        BNE     1$              ;IF YES, SKIP ERROR TYPEOUT
004002  104003                        ERROR   3               ;DONE NOT CLEARED WITH TBUF FULL
004004  000404                        BR      3$              ;BR TO END OF TEST
004006                          1$:
004006  004737  013170                  JSR     PC,$ATY4                ;;ONLY REPORT A FATAL ERROR
004012  000003                        3                               ;;THE ERROR NUMBER (FROM APT LIST)
004014  000000                  2$:     HALT                    ;TCSR "DONE" NOT CLEARED WITH TBUF FULL
004016  005000                  3$:     CLR     R0              ;CLEAR TIMER
004020  105777  176326          4$:     TSTB    @TCSR           ;CHECK FOR XMIT DONE
004024  100414                        BMI     ID              ;IF DONE SETS, BR TO END OF TEST
004026  005200                        INC     R0              ;INCREMENT TIMER
004030  001373                        BNE     4$              ;BR IF TIMER NOT DONE

004032  005737  002336                  TST     CTSTFL          ;CHECK IF DEVICE IS CONSOLE
004036  001002                        BNE     5$
004040  104004                        ERROR   4               ;TCSR "DONE" DOES NOT SET
004042  000405                        BR      ID              ;BR TO END OF TEST
004044                          5$:
004044  004737  013170                  JSR     PC,$ATY4                ;;ONLY REPORT A FATAL ERROR
004050  000004                        4                               ;;THE ERROR NUMBER (FROM APT LIST)
004052  000000                        HALT
004054  000424                        BR      TST4            ;BR TO NEXT TEST, AND SKIP THE TYPEOUT THAT FOLLOWS
                                                                ;  BECAUSE OF THIS FAILURE

004056  023737  000042  000046  ID:     CMP     @#42,@#46       ;UNDER ACT11?
004064  001412                        BEQ     6$              ;IF YES, SKIP IDENT. TYPEOUT
004066  005737  001074                  TST     $PASS           ;IS THIS THE FIRST PASS?
004072  001007                        BNE     6$              ;IF NOT BR TO NEXT TEST & SKIP THE IDENTIFICATION TYPEOU
004074  005737  001076                  TST     $DEVCT          ;IS THIS THE FIRST SUBPASS?
004100  001004                        BNE     6$              ;IF NOT, BRTO NEXT TEST
004102  104401                        TYPE                    ;TYPE PROGRAM INDENTIFICATION
004104  022140                        M1
004106  104401                        TYPE                    ;TYPE NUMBER OF DEVICES UNDER TEST
004110  022152                        M2
004112  032777  000020  174720  6$:     BIT     #BIT4,@SWR      ;CLOCK TEST ONLY?
004120  001402                        BEQ     TST4            ;BR IF NOT
004122  000137  005056                  JMP     TCLOCK          ;ELSE, JUMP TO TEST CLOCK
```

```
                                    ;;*****************************************************************
                                    ;*TEST 4         TEST THAT TCSR "DONE" SETS WITH RESET
                                    ;;*****************************************************************
004126  000004                      TST4:   SCOPE
004130  005077  176220                      CLR     @TBUF           ;LOAD TRANSMIT BUFFER
004134  105777  176212              1$:     TSTB    @TCSR           ;WAIT FOR DONE
004140  100375                              BPL     1$
004142  005077  176206                      CLR     @TBUF           ;LOAD SECOND BUFFER
004146  000240                              NOP
004150  000005                              RESET                   ;CLEAR DONE WITH RESET
004152  105777  176174                      TSTB    @TCSR           ;CHECK FOR DONE SET
004156  100401                              BMI     TST5            ;BR TO NEXT TEST IF DONE SET

004160  104005                              ERROR   5               ;TCSR "DONE" DOES NOT SET WITH RESET



                                    ;;*****************************************************************
                                    ;*TEST 5         TEST ABILITY TO ACCESS RCSR
                                    ;;*****************************************************************
004162  000004                      TST5:   SCOPE
004164  013703  000004                      MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
004170  012737  004204  000004              MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
004176  005777  176144                      TST     @RCSR           ;ACCESS RCSR
004202  000402                              BR      2$              ;BR TO END OF TEST

004204  022626                      1$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER TIMEOUT
004206  104006                              ERROR   6               ;CAN NOT ACCESS RCSR
004210  010337  000004              2$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
```



```
                                    ;;*****************************************************************
                                    ;*TEST 6         TEST ABILITY TO ACCESS RBUF
                                    ;;*****************************************************************
004214  000004                      TST6:   SCOPE
004216  013703  000004                      MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
004222  012737  004236  000004              MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
004230  005777  176114                      TST     @RBUF           ;ACCESS RBUF
004234  000402                              BR      2$              ;BR TO END OF TEST

004236  022626                      1$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER TIMEOUT
004240  104007                              ERROR   7               ;CAN NOT ACCESS RBUF
004242  010337  000004              2$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
```

```
1472
1473
1474                                    ;;*****************************************************************
1475                                    ;*TEST 7        TEST THAT BIT0(BREAK BIT) CAN BE SET & CLEARED & RESET
1476                                    ;;*****************************************************************
1477  004246  000004                   TST7:   SCOPE
1478  004250  032777  000400  174562           BIT     #BIT8,@SWR      ;IS BREAK FUNCTION ENABLED?
1479  004256  001545                           BEQ     TST11           ;BR TO NEXT TEST, IF NOT
1480  004260  000005                           RESET                   ;CLEAR EVERYTHING
1481  004262  032777  000001  176062           BIT     #BIT0,@TCSR     ;CHECK BIT0 OF TCSR CLEAR
1482  004270  001411                           BEQ     3$              ;BR IF CLEAR
1483  004272  005737  002336                   TST     CTSTFL
1484  004276  001002                           BNE     1$
1485  004300  104011                           ERROR   11              ;BIT0 WAS NOT CLEAR AFTER RESET
1486  004302  000404                           BR      3$
1487  004304                           1$:
1488  004304  004737  013170                   JSR     PC,$ATY4                ;;ONLY REPORT A FATAL ERROR
1489  004310  000011                           11                      ;;THE ERROR NUMBER (FROM APT LIST)
1490  004312  000000                   2$:     HALT
1491
1492  004314  052777  000001  176030  3$:     BIS     #BIT0,@TCSR     ;SET BIT0 IN TCSR
1493  004322  032777  000001  176022           BIT     #BIT0,@TCSR     ;TEST BIT0 OF TCSR
1494  004330  001001                           BNE     4$              ;BR IF SET
1495
1496  004332  104012                           ERROR   12              ;BIT0 OF TCSR WILL NOT SET
1497
1498  004334  042777  000001  176010  4$:     BIC     #BIT0,@TCSR     ;CLEAR BIT0 OF TCSR
1499  004342  032777  000001  176002           BIT     #BIT0,@TCSR     ;TEST BIT0 OF TCSR
1500  004350  001411                           BEQ     7$
1501  004352  005737  002336                   TST     CTSTFL
1502  004356  001002                           BNE     5$
1503  004360  104013                           ERROR   13              ;BIT0 OF TCSR WILL NOT CLEAR
1504  004362  000404                           BR      7$
1505  004364                           5$:
1506  004364  004737  013170                   JSR     PC,$ATY4                ;;ONLY REPORT A FATAL ERROR
1507  004370  000013                           13                      ;;THE ERROR NUMBER (FROM APT LIST)
1508  004372  000000                   6$:     HALT
1509
1510  004374  052777  000001  175750  7$:     BIS     #BIT0,@TCSR     ;SET BIT0 IN TCSR
1511  004402  000005                           RESET                   ;CLEAR BIT0 WITH RESET
1512  004404  032777  000001  175740           BIT     #BIT0,@TCSR     ;TEST BIT0 CLEAR
1513  004412  001467                           BEQ     TST11           ;BR IF CLEAR
1514  004414  042777  000001  175730           BIC     #BIT0,@TCSR     ;CLEAR BIT0, TO PRINT ERROR
1515  004422  104014                           ERROR   14              ;RESET DID NOT CLEAR BIT0 OF TCSR
```



```
1516
1517
1518                                    ;;*****************************************************************
1519                                    ;*TEST 10       TEST THAT BIT2(MAINT. BIT) CAN BE SET & RESET
1520                                    ;;*****************************************************************
1521  004424  000004                   TST10:  SCOPE
1522  004426  000005                           RESET                   ;CLEAR EVERYTHING
1523  004430  032777  000004  175714           BIT     #BIT2,@TCSR     ;TEST FOR BIT2 OF TCSR CLEAR
1524  004436  001411                           BEQ     3$              ;BR IF CLEAR
1525
1526  004440  005737  002336                   TST     CTSTFL          ;CHECK IF DEVICE IS CONSOLE
1527  004444  001002                           BNE     1$              ;IF YES, SKIP ERROR TYPEOUT
1528  004446  104015                           ERROR   15              ;BIT2 OF TCSR NOT CLEAR AFTER RESET
1529  004450  000404                           BR      3$
1530
1531  004452                           1$:
1532  004452  004737  013170                   JSR     PC,$ATY4                ;;ONLY REPORT A FATAL ERROR
1533  004456  000015                           15                      ;;THE ERROR NUMBER (FROM APT LIST)
1534  004460  000000                   2$:     HALT
1535
1536  004462  052777  000004  175662  3$:     BIS     #BIT2,@TCSR     ;SET BIT2 OF TCSR
1537  004470  032777  000004  175654           BIT     #BIT2,@TCSR     ;TEST FOR BIT2 SET
1538  004476  001001                           BNE     4$              ;BR IF SET
1539
1540  004500  104016                           ERROR   16              ;BIT2 OF TCSR WILL NOT SET
1541
1542  004502  042777  000004  175642  4$:     BIC     #BIT2,@TCSR     ;CLEAR BIT2 OF TCSR
1543  004510  032777  000004  175634           BIT     #BIT2,@TCSR     ;TEST BIT2 CLEAR
1544  004516  001411                           BEQ     7$              ;BR IF CLEAR
1545
1546  004520  005737  002336                   TST     CTSTFL          ;CHECK IF DEVICE IS CONSOLE
1547  004524  001002                           BNE     5$              ;IF YES, SKIP ERROR TYPEOUT
1548  004526  104017                           ERROR   17
1549  004530  000404                           BR      7$
1550  004532                           5$:
1551  004532  004737  013170                   JSR     PC,$ATY4                ;;ONLY REPORT A FATAL ERROR
1552  004536  000017                           17                      ;;THE ERROR NUMBER (FROM APT LIST)
1553  004540  000000                   6$:     HALT                    ;BIT0 OF TCSR WILL NOT CLEAR
1554
1555  004542  052777  000004  175602  7$:     BIS     #BIT2,@TCSR     ;SET BIT2 OF TCSR
1556  004550  000005                           RESET                   ;CLEAR BIT2 WITH RESET
1557  004552  032777  000004  175572           BIT     #BIT2,@TCSR     ;TEST FOR BIT2 CLEAR
1558  004560  001461                           BEQ     TST12           ;IF CLEAR, GO TO NEXT TEST
1559
1560  004562  042777  000004  175562           BIC     #BIT2,@TCSR     ;CLEAR BIT2, TO PRINT ERROR
1561  004570  104020                           ERROR   20
1562                                                                   ;RESET DID NOT CLEAR BIT2 OF TCSR
```

```
                                        ;;*****************************************************************
                                        ;*TEST 11       TEST THAT BIT6(XMIT INT EN) CAN BE SET & RESET
                                        ;;*****************************************************************
004572  000004                  TST11:  SCOPE
004574  000005                          RESET                   ;CLEAR EVERYTHING
004576  017703  175560                  MOV     @TVECT,R3       ;SAVE XMIT VECTOR
004602  012777  004632  175552          MOV     #1$,@TVECT      ;SET UP INTERRUPT VECTOR FOR ERROR REPORT
004610  004737  012242                  JSR     PC,WRPSW                ;SET PSW TO PRIORITY=7
004614  000340                          .WORD   340
004616  032777  000100  175526          BIT     #BIT6,@TCSR     ;TEST BIT6 OF TCSR
004624  001404                          BEQ     2$              ;BR IF ZERO
004626  104021                          ERROR   21
                                                                ;BIT6 IN TCSR NOT CLEAR AFTER RESET
004630  000402                          BR      2$

004632  022626                  1$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
004634  104022                          ERROR   22
                                                                ;XMIT INTERRUPT OCCURRED  PRIO=7

004636  052777  000100  175506  2$:     BIS     #BIT6,@TCSR     ;SET BIT6 OF TCSR
004644  032777  000100  175500          BIT     #BIT6,@TCSR     ;TEST BIT6 OF TCSR
004652  001001                          BNE     3$              ;BR, IF SET

004654  104023                          ERROR   23
                                                                ;CANNOT SET BIT6 OF TCSR

004656  042777  000100  175466  3$:     BIC     #BIT6,@TCSR     ;CLEAR BIT6 OF TCSR
004664  032777  000100  175460          BIT     #BIT6,@TCSR     ;TEST BIT6 OF TCSR
004672  001401                          BEQ     4$              ;BR IF CLEAR
004674  104024                          ERROR   24
                                                                ;CANNOT CLEAR BIT6 OF TCSR

004676  052777  000100  175446  4$:     BIS     #BIT6,@TCSR     ;SET BIT6 OF TCSR
004704  000005                          RESET                   ;CLEAR BIT6 WITH RESET
004706  032777  000100  175436          BIT     #BIT6,@TCSR     ;TEST BIT6 OF TCSR
004714  001401                          BEQ     5$              ;BR IF CLEAR

004716  104025                          ERROR   25
                                                                ;CANNOT CLEAR BIT6 OF TCSR WITH RESET
004720  010377  175436          5$:     MOV     R3,@TVECT       ;RESTORE XMIT VECTOR
```



```
                                        ;;*****************************************************************
                                        ;*TEST 12       TEST THAT BIT6 OF RCSR CAN BE SET & RESET
                                        ;;*****************************************************************
004724  000004                  TST12:  SCOPE
004726  000005                          RESET                   ;CLEAR EVERYTHING
004730  017703  175422                  MOV     @RVECT,R3       ;SAVE RECEIVE VECTOR
004734  012777  004764  175414          MOV     #1$,@RVECT      ;SET UP INTERRUPT VECTOR FOR ERROR REPORT
004742  004737  012242                  JSR     PC,WRPSW        ;SET PSW TO PRIORITY=7
004746  000340                          .WORD   340
004750  032777  000100  175370          BIT     #BIT6,@RCSR     ;TEST BIT6 OF RCSR
004756  001404                          BEQ     2$
004760  104026                          ERROR   26
                                                                ;BIT6 OF RCSR NOT CLEAR AFTER RESET
004762  000402                          BR      2$

004764  022626                  1$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
004766  104027                          ERROR   27
                                                                ;RCVR INTERRUPT WITH PRIORITY=7

004770  052777  000100  175350  2$:     BIS     #BIT6,@RCSR     ;SET BIT6 OF RCSR
004776  032777  000100  175342          BIT     #BIT6,@RCSR     ;TEST BIT6 OF RCSR
005004  001001                          BNE     3$              ;BR, IF SET

005006  104030                          ERROR   30
                                                                ;CANNOT SET BIT6 OF RCSR

005010  042777  000100  175330  3$:     BIC     #BIT6,@RCSR     ;CLEAR BIT6 OF RCSR
005016  032777  000100  175322          BIT     #BIT6,@RCSR     ;TEST BIT6 OF RCSR
005024  001401                          BEQ     4$              ;BR, IF CLEAR

005026  104031                          ERROR   31
                                                                ;CANNOT CLEAR BIT6 OF RCSR

005030  052777  000100  175310  4$:     BIS     #BIT6,@RCSR     ;SET BIT6 OF RCSR
005036  000005                          RESET                   ;CLEAR BIT6OF RCSR WITH RESET
005040  032777  000100  175300          BIT     #BIT6,@RCSR     ;TEST BIT6 OF RCSR
005046  001401                          BEQ     5$              ;BR, IF CLEAR

005050  104032                          ERROR   32
                                                                ;CANNOT CLEAR BIT6 OF RCSR WITH RESET
005052  010377  175300          5$:     MOV     R3,@RVECT       ;RESTORE RECEIVE VECTOR
```

```
 1649
 1650  005056  012737  000012  001002  TCLOCK: MOV     #12,$TSTNM      ;ADJUST TEST NUMBER TO (NEXT TEST - 1)
 1651                                  ;;**************************************************************
 1652                                  ;*TEST 13        TEST ABILITY TO ACCESS LKS
 1653                                  ;;**************************************************************
 1654  005064  000004                  TST13:  SCOPE
 1655  005066  005737  002336                  TST     CTSTFL          ;IS CONSOLE UNDER TEST?
 1656  005072  001420                  BEQ     TST14           ;IF NOT, SKIP THIS TEST
 1657  005074  032777  000100  173736          BIT     #BIT6,@SWR      ;ARE LINE CLOCK TESTS INHIBITED?
 1658  005102  001014                  BNE     TST14           ;IF YES, SKIP THIS TEST
 1659  005104  013703  000004                  MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
 1660  005110  012737  005124  000004          MOV     #1$,@#4         ;SET UP TIMEOUT VECTOR
 1661  005116  005777  175264                  TST     @LKS            ;ACCESS LKS
 1662  005122  000402                  BR      2$              ;NO TIMEOUT -  BR TO END OF TEST
 1663
 1664  005124  022626                  1$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER TIMEOUT
 1665  005126  104010                          ERROR   10              ;CAN NOT ACCESS LKS
 1666
 1667  005130  010337  000004          2$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
 1668
 1669                                  ;;**************************************************************
 1670                                  ;*TEST 14        TEST THAT BIT6 OF LKS CAN BE SET & RESET
 1671                                  ;;**************************************************************
 1672  005134  000004                  TST14:  SCOPE
 1673  005136  005737  002336                  TST     CTSTFL          ;IS CONSOLE UNDER TEST?
 1674  005142  001460                  BEQ     TST15           ;IF NOT, SKIP THIS TEST
 1675  005144  032777  000100  173666          BIT     #BIT6,@SWR      ;ARE LINE CLOCK TESTS INHIBITED?
 1676  005152  001054                  BNE     TST15           ;IF YES, SKIP THIS TEST
 1677  005154  000005                  RESET
 1678  005156  017703  175226                  MOV     @RTCVT,R3       ;SAVE LINE CLOCK VECTOR
 1679  005162  012777  005212  175220          MOV     #1$,@RTCVT      ;SET UP INTERRUPT VECTOR FOR ERROR REPORT
 1680  005170  004737  012242                  JSR     PC,WRPSW        ;SET PSW TO PRIORITY 7
 1681  005174  000340                          .WORD   340
 1682  005176  032777  000100  175202          BIT     #BIT6,@LKS      ;TEST BIT6 OF LKS
 1683  005204  001404                  BEQ     2$
 1684  005206  104033                          ERROR   33
 1685                                                                  ;BIT6 OF LKS NOT CLEAR AFTER RESET
 1686  005210  000402                  BR      2$
 1687
 1688  005212  022626                  1$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
 1689  005214  104034                          ERROR   34
 1690                                                                  ;LKS INTERRUPT WITH PRIORITY=7
 1691
 1692  005216  052777  000100  175162  2$:     BIS     #BIT6,@LKS      ;SET BIT6 OF LKS
 1693  005224  032777  000100  175154          BIT     #BIT6,@LKS      ;TEST BIT6 OF LKS
 1694  005232  001001                  BNE     3$              ;BR IF SET
 1695
 1696  005234  104035                          ERROR   35
 1697                                                                  ;CANNOT SET BIT6 OF LKS
 1698
 1699  005236  042777  000100  175142  3$:     BIC     #BIT6,@LKS      ;CLEAR BIT6 OF LKS
 1700  005244  032777  000100  175134          BIT     #BIT6,@LKS      ;TEST BIT6 OF LK
 1701  005252  001401                  BEQ     4$
 1702  005254  104036                          ERROR   36
 1703                                                                  ;CANNOT CLEAR BIT6 OF LKS
 1704  005256  052777  000100  175122  4$:     BIS     #BIT6,@LKS      ;SET BIT6 OF LKS
```



```
 1705  005264  000005                          RESET                   ;CLEAR BIT6 OF LKS WITH RESET
 1706  005266  032777  000100  175112          BIT     #BIT6,@LKS      ;TEST BIT6 OF LKS
 1707  005274  001401                  BEQ     5$              ;BR IF CLEAR
 1708
 1709  005276  104037                          ERROR   37
 1710                                                                  ;CANNOT CLEAR BIT6 OF LKS WITH RESET
 1711  005300  010377  175104          5$:     MOV     R3,@RTCVT       ;RESTORE LINE CLOCK VECTOR
```

```
                                        T14     TEST THAT BIT6 OF LKS CAN BE SET & RESET

                                        ;;*****************************************************************
                                        ;*TEST 15       TEST FOR DUAL ADDRESSING OF REGISTERS
                                        ;;*****************************************************************
005304  000004                  TST15:  SCOPE
005306  013703  000004                  MOV     @#4,R3          ;SAVE TIMEOUT VECTOR
005312  013704  000006                  MOV     @#6,R4          ;SAVE TIMEOUT PSW
005316  012737  005450  000004          MOV     #4$,@#4         ;SET UP TIMEOUT VECTOR
005324  012737  000340  000006          MOV     #340,@#6        ;KEEP PRIO=7
005332  000005                          RESET                   ;CLEAR EVERYTHING
005334  012700  000002                  MOV     #BIT1,R0        ;SET UP BIT MASK
005340  032777  000020  173472          BIT     #BIT4,@SWR      ;CLOCK TEST ONLY?
005346  001404                          BEQ     1$              ;BR IF NOT
005350  013737  002406  001020          MOV     LKS,$GDADR      ;ELSE, MOVE GOOD LKS ADDRESS INTO $GDADR
005356  000403                          BR      2$
005360  013737  002346  001020  1$:     MOV     RCSR,$GDADR     ;MOVE GOOD RCSR ADDRESS INTO $GDADR
005366  013737  001020  001022  2$:     MOV     $GDADR,$BDADR   ;MOVE GOOD ADDRESS INTO TEST ADDRESS LOCATION
005374  040037  001022                  BIC     R0,$BDADR       ;CREATE BAD ADDRESS BY COMPLEMENTING ONE BIT
005400  023737  001020  001022          CMP     $GDADR,$BDADR   ;ARE ADDRESSES IDENTICAL?
005406  001002                          BNE     3$              ;IF NOT, TEST THIS ADDRESS
005410  050037  001022                  BIS     R0,$BDADR       ;ELSE, BIT SET THIS BIT POSITION TO GENERATE BAD ADDRESS
005414  017737  173402  001024  3$:     MOV     @$BDADR,$GDDAT  ;SAVE CONTENTS OF BAD ADDRESS IF IT EXISTS
005422  052777  000100  173372          BIS     #BIT6,@$BDADR   ;SET BIT6 USING BAD ADDRESS
005430  032777  000100  173362          BIT     #BIT6,@$GDADR   ;CHECK TO SEE IF GOOD ADDRESS CONTAINS BIT6
005436  001011                          BNE     6$              ;BR IF SET ---> ERROR
005440  013777  001024  173354          MOV     $GDDAT,@$BDADR  ;RESTORE ANY MEMORY LOCATION THAT WAS ALTERED
005446  000401                          BR      5$              ;BR TO CONTINUE TEST
005450  022626                  4$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER TIMEOUT
005452  006300                  5$:     ASL     R0              ;SHIFT BIT MASK TO NEXT POSITION
005454  105700                          TSTB    R0              ;COMPLEMENTED ALL BITS FROM 1 - 7?
005456  100343                          BPL     2$              ;BR, IF NOT.
005460  000401                          BR      7$              ;BR TO NEXT TEST

005462  104040                  6$:     ERROR   40              ;DUAL ADDRESSING ERROR
                                                                ;$BDADR = DUAL ADDRESS
                                                                ;$GDADR = GOOD ADDRESS

005464  010337  000004          7$:     MOV     R3,@#4          ;RESTORE TIMEOUT VECTOR
005470  010437  000006                  MOV     R4,@#6          ;RESTORE TIMEOUT PSW
```



```
                                        T15     TEST FOR DUAL ADDRESSING OF REGISTERS

                                        ;;*****************************************************************
                                        ;*TEST 16       TEST THAT BIT7 OF LKS SETS & CAN BE CLEARED
                                        ;;*****************************************************************
005474  000004                  TST16:  SCOPE
005476  005737  002336                  TST     CTSTFL          ;IS CONSOLE UNDER TEST?
005502  001437                          BEQ     TST17           ;IF NOT, SKIP THIS TEST
005504  032777  000100  173326          BIT     #BIT6,@SWR      ;ARE LINE CLOCK TESTS INHIBITED?
005512  001033                          BNE     TST17           ;IF YES, SKIP THIS TEST
005514  000005                          RESET                   ;CLEAR EVERYTHING & SET BIT7 OF LKS
005516  105777  174664          1$:     TSTB    @LKS            ;TEST FOR BIT7 OF LKS
005522  100401                          BMI     2$              ;BR IF SET

005524  104041                          ERROR   41              ;BIT7 OF LKS DID NOT SET WITH RESET

005526  042777  000200  174652  2$:     BIC     #BIT7,@LKS      ;CLEAR BIT7 OF LKS
005534  032777  000200  174644          BIT     #BIT7,@LKS      ;TEST BIT7 OF LKS
005542  001410                          BEQ     3$
005544  042777  000200  174634          BIC     #BIT7,@LKS      ;TRY ONE MORE TIME BECAUSE THE CLOCK
005552  032777  000200  174626          BIT     #BIT7,@LKS      ;  MAY HAVE SET IMMEDIATELY AFTER THE FIRST CLEAR
005560  001401                          BEQ     3$

005562  104042                          ERROR   42              ;CAN NOT CLEAR BIT7 OF LKS

005564  005000                  3$:     CLR     R0              ;CLEAR TIMER
005566  105777  174614          CONT:   TSTB    @LKS            ;TEST FOR BIT7 OF LKS
005572  100403                          BMI     TST17           ;BR, IF SET
005574  005200                          INC     R0              ;INCREMENT TIMER
005576  001373                          BNE     CONT            ;CONTINUE UNTIL TIME EXPIRES

005600  104043                          ERROR   43              ;BIT7 OF LKS DOES NOT SET
```

```
1785
1786                                    ;;*****************************************************************
1787                                    ;*TEST 17       TEST THAT THE REAL TIME CLOCK INTERRUPTS PROPERLY
1788                                    ;;*****************************************************************
1789  005602  000004                    TST17:  SCOPE
1790  005604  005737  002336                    TST     CTSTFL          ;IS CONSOLE UNDER TEST?
1791  005610  001503                            BEQ     TST20           ;IF NOT, SKIP THIS TEST
1792  005612  032777  000100  173220            BIT     #BIT6,@SWR      ;ARE LINE CLOCK TESTS INHIBITED?
1793  005620  001077                            BNE     TST20           ;IF YES, SKIP THIS TEST
1794  005622  004737  012242                    JSR     PC,WRPSW        ;SET PSW TO PRIORITY 7
1795  005626  000340                                    .WORD   340
1796  005630  017703  174554                    MOV     @RTCVT,R3       ;SAVE LINE CLOCK VECTOR
1797  005634  017704  174552                    MOV     @RTCPSW,R4      ;SAVE LINE CLOCK PSW VECTOR
1798  005640  012777  005702  174542            MOV     #2$,@RTCVT      ;SET RTC INTERRUPT VECTOR TO ERROR REPORT
1799  005646  012777  000340  174536            MOV     #340,@RTCPSW    ;KEEP PRIORITY AT 7
1800  005654  042777  000200  174524            BIC     #BIT7,@LKS      ;CLEAR CLOCK DONE FLAG
1801  005662  052777  000100  174516            BIS     #BIT6,@LKS      ;SET INTERRUPT ENABLE
1802  005670  105777  174512            1$:     TSTB    @LKS            ;WAIT FOR RTC DONE(INTERRUPT REQUEST)
1803  005674  100375                            BPL     1$
1804  005676  000240                            NOP                     ;GIVE TIME FOR ANY INTERRUPTS
1805  005700  000402                            BR      3$              ;BR, IF NO INTERRUPT OCCURS
1806
1807  005702  022626                    2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
1808  005704  104044                            ERROR   44              ;RTC INTERRUPTS AT PRIORITY 7
1809
1810  005706  005077  174474            3$:     CLR     @LKS    ;DISABLE RTC INTERRUPTS & CLEAR DONE
1811  005712  012777  005740  174470            MOV     #4$,@RTCVT      ;SET RTC INTERRUPT VECTOR FOR ERROR
1812  005720  004737  012242                    JSR     PC,WRPSW        ;CHANGE PSW TO PRIORITY 5
1813  005724  000240                                    .WORD   240
1814  005726  105777  174454            20$:    TSTB    @LKS            ;WAIT FOR DONE (INTERRUPT REQUEST)
1815  005732  100375                            BPL     20$
1816  005734  000240                            NOP                     ;GIVE TIME FOR ANY INTERRUPT
1817  005736  000402                            BR      5$              ;IF NO INTERRUPT - BR TO CONTINUE TEST
1818
1819  005740  022626                    4$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
1820  005742  104045                            ERROR   45              ;RTC INTERRUPTS WITH INTERRUPTS DISABLED
1821
1822  005744  012777  006000  174436    5$:     MOV     #7$,@RTCVT      ;POINT RTC VECTOR TO END OF TEST
1823  005752  042777  000200  174426            BIC     #BIT7,@LKS      ;CLEAR CLOCK DONE FLAG
1824  005760  052777  000100  174420            BIS     #BIT6,@LKS      ;ALLOW INTERRUPTS
1825  005766  105777  174414            6$:     TSTB    @LKS            ;WAIT FOR RTC DONE
1826  005772  100375                            BPL     6$
1827  005774  000240                            NOP                     ;GIVE TIME FOR INTERRUPT
1828
1829  005776  104046                            ERROR   46              ;RTC INTERRUPT DID NOT OCCUR
1830
1831  006000  022626                    7$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
1832  006002  042777  000100  174376            BIC     #BIT6,@LKS      ;DISABLE INTERRUPTS
1833  006010  010377  174374                    MOV     R3,@RTCVT       ;RESTORE LINE CLOCK VECTOR
1834  006014  010477  174372                    MOV     R4,@RTCPSW      ;RESTORE LINE CLOCK PSW VECTOR
1835
1836
```



```
1837
1838
1839
1840                                    ;;*****************************************************************
1841                                    ;*TEST 20       TEST RTC FOR DOUBLE INTERRUPTS
1842                                    ;;*****************************************************************
1843  006020  000004                    TST20:  SCOPE
1844  006022  005737  002336                    TST     CTSTFL          ;IS CONSOLE UNDER TEST?
1845  006026  001457                            BEQ     TST21           ;IF NOT, SKIP THIS TEST
1846  006030  032777  000100  173002            BIT     #BIT6,@SWR      ;ARE LINE CLOCK TESTS INHIBITED?
1847  006036  001053                            BNE     TST21           ;IF YES, SKIP THIS TEST
1848  006040  000005                            RESET                   ;CLEAR EVERYTHING
1849  006042  017703  174342                    MOV     @RTCVT,R3       ;SAVE LINE CLOCK VECTOR
1850  006046  017704  174340                    MOV     @RTCPSW,R4      ;SAVE LINE CLOCK PSW VECTOR
1851  006052  012777  006122  174330            MOV     #2$,@RTCVT      ;SET UP RTC INTERRUPT VECTOR
1852  006060  012777  000340  174324            MOV     #340,@RTCPSW    ;DISALLOW INTERRUPTS AFTER THE INTERRUPT
1853  006066  004737  012242                    JSR     PC,WRPSW        ;SET PRIORITY TO 5
1854  006072  000240                                    .WORD   240
1855  006074  042777  000200  174304            BIC     #BIT7,@LKS      ;CLEAR CLOCK DONE FLAG
1856  006102  052777  000100  174276            BIS     #BIT6,@LKS      ;ENABLE CLOCK INTERRUPTS
1857  006110  105777  174272            1$:     TSTB    @LKS            ;WAIT FOR DONE
1858  006114  100375                            BPL     1$
1859  006116  000240                            NOP                     ;GIVE TIME FOR ANY INTERRUPT
1860
1861  006120  104047                            ERROR   47              ;RTC INTERRUPT DID NOT OCCUR
1862
1863  006122  022626                    2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
1864  006124  012777  006144  174256            MOV     #3$,@RTCVT      ;POINT RTC VECTOR TO ERROR REPORT
1865  006132  004737  012242                    JSR     PC,WRPSW        ;SET PSW TO PRIORITY 5
1866  006136  000240                                    .WORD   240
1867  006140  000240                            NOP                     ;GIVE SOME TIME FOR AN INTERRUPT
1868  006142  000402                            BR      4$              ;NO INTERRUPT - BR TO END OF TEST
1869
1870  006144  022626                    3$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
1871  006146  104050                            ERROR   50              ;INTERRUPT SEQUENCE DID NOT CLEAR
1872                                                                    ;INTERRUPT REQUEST
1873
1874  006150  042777  000100  174230    4$:     BIC     #BIT6,@LKS      ;DISABLE CLOCK INTERRUPTS
1875  006156  010377  174226                    MOV     R3,@RTCVT       ;RESTORE LINE CLOCK VECTOR
1876  006162  010477  174224                    MOV     R4,@RTCPSW      ;RESTORE LINE CLOCK PSW VECTOR
```

```
                                        ;;*****************************************************************
                                        ;*TEST 21       TEST THAT RTC INTERRUPT CLEARS WITH RESET
                                        ;;*****************************************************************
006166  000004                  TST21:  SCOPE
006170  005737  002336                  TST     CTSTFL          ;IS CONSOLE UNDER TEST?
006174  001442                          BEQ     TST22           ;IF NOT, SKIP THIS TEST
006176  032777  000100  172634          BIT     #BIT6,@SWR      ;ARE LINE CLOCK TESTS INHIBITED?
006204  001036                          BNE     TST22           ;IF YES, SKIP THIS TEST
006206  004737  012242                  JSR     PC,WRPSW        ;SET PRIORITY TO 7
006212  000340                          .WORD   340
006214  017703  174170                  MOV     @RTCVT,R3       ;SAVE LINE CLOCK VECTOR
006220  012777  006272  174162          MOV     #2$,@RTCVT      ;POINT RTC VECTOR TO ERROR REPORT
006226  042777  000200  174152          BIC     #BIT7,@LKS      ;CLEAR CLOCK DONE FLAG
006234  052777  000100  174144          BIS     #BIT6,@LKS      ;ENABLE CLOCK INTERRUPTS
006242  105777  174140          1$:     TSTB    @LKS            ;WAIT FOR DONE (INTERRUPT REQUEST)
006246  100375                          BPL     1$
006250  000005                          RESET                   ;CLEAR PENDING INTERRUPT WITH RESET
006252  004737  012242                  JSR     PC,WRPSW        ;SET PRIORITY TO 5
006256  000240                          .WORD   240
006260  000240                          NOP                     ;GIVE TIME FOR ANY INTERRUPT
006262  042777  000100  174116          BIC     #BIT6,@LKS      ;DISALLOW INTERRUPTS
006270  000402                          BR      3$              ;BR TO END OF TEST

006272  022626                  2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
006274  104051                          ERROR   51              ;RESET DID NOT CLEAR INTERRUPT

006276  010377  174106          3$:     MOV     R3,@RTCVT       ;RESTORE LINE CLOCK VECTOR
```



```
                                        ;;*****************************************************************
                                        ;*TEST 22       TEST THAT RTC INTERRUPT CLEARS BY CLEARING BIT7 OF LKS
                                        ;;*****************************************************************
006302  000004                  TST22:  SCOPE
006304  005737  002336                  TST     CTSTFL          ;IS CONSOLE UNDER TEST?
006310  001447                          BEQ     TST23           ;IF NOT, SKIP THIS TEST
006312  032777  000100  172520          BIT     #BIT6,@SWR      ;ARE LINE CLOCK TESTS INHIBITED?
006320  001043                          BNE     TST23           ;IF YES, SKIP THIS TEST
006322  004737  012242                  JSR     PC,WRPSW        ;SET PRIORITY TO 7
006326  000340                          .WORD   340
006330  017703  174054                  MOV     @RTCVT,R3       ;SAVE LINE CLOCK VECTOR
006334  012777  006412  174046          MOV     #2$,@RTCVT      ;POINT RTC VECTOR TO ERROR REPORT
006342  042777  000200  174036          BIC     #BIT7,@LKS      ;CLEAR CLOCK DONE FLAG
006350  052777  000100  174030          BIS     #BIT6,@LKS      ;ENABLE CLOCK INTERRUPTS
006356  105777  174024          1$:     TSTB    @LKS            ;WAIT FOR DONE (INTERRUPT REQUEST)
006362  100375                          BPL     1$
006364  042777  000200  174014          BIC     #BIT7,@LKS      ;CLEAR DONE & INTERRUPT
006372  004737  012242                  JSR     PC,WRPSW        ;ALLOW INTERRUPTS
006376  000240                          .WORD   240
006400  000240                          NOP                     ;GIVE TIME FOR ANY INTERRUPT
006402  042777  000100  173776          BIC     #BIT6,@LKS      ;DISALLOW INTERRUPTS
006410  000402                          BR      3$              ;BR TO END OF TEST

006412  022626                  2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
006414  104052                          ERROR   52              ;CLEARING BIT7 OF LKS DID NOT CLEAR INTERRUPT

006416  010377  173766          3$:     MOV     R3,@RTCVT       ;RESTORE LINE CLOCK VECTOR
006422  004737  012242                  JSR     PC,WRPSW        ;RESTORE PRIORITY TO 7
006426  000340                          .WORD   340
```

```
1938
1939
1940                                    ;;*****************************************************************
1941                                    ;*TEST 23        TEST CLOCK REPEATABILITY
1942                                    ;;*****************************************************************
1943  006430  000004                    TST23:  SCOPE
1944  006432  005737  002336                    TST     CTSTFL          ;IS CONSOLE UNDER TEST?
1945  006436  001462                            BEQ     TST24           ;IF NOT, SKIP THIS TEST
1946  006440  032777  000100  172372            BIT     #BIT6,@SWR      ;ARE LINE CLOCK TESTS INHIBITED?
1947  006446  001056                            BNE     TST24           ;IF YES, SKIP THIS TEST
1948  006450  042777  000100  173730            BIC     #BIT6,@LKS      ;DISALLOW INTERRUPTS
1949
1950  006456  005000                            CLR     R0              ;CLEAR A TIMER
1951  006460  012701  177777                    MOV     #-1,R1          ;SET A FLAG INDICATING FIRST PASS THRU THIS LOOP
1952  006464  005002                    1$:     CLR     R2              ;CLEAR CLOCK COUNTER
1953  006466  005077  173714                    CLR     @LKS            ;CLEAR DONE
1954  006472  105777  173710            2$:     TSTB    @LKS            ;SYNC ON DONE
1955  006476  100375                            BPL     2$
1956  006500  005077  173702                    CLR     @LKS            ;CLEAR DONE
1957  006504  105777  173676            3$:     TSTB    @LKS            ;IS CLOCK DONE?
1958  006510  100003                            BPL     4$              ;BR IF NOT , TO INCREMENT TIMER
1959  006512  005202                            INC     R2              ;IF DONE, INCREMENT CLOCK COUNT
1960  006514  005077  173666                    CLR     @LKS            ;CLEAR DONE
1961  006520  005200                    4$:     INC     R0              ;INCREMENT TIMER
1962  006522  001370                            BNE     3$              ;BR IF TIME REMAINS
1963  006524  005201                            INC     R1              ;INCREME::T LOOP PASS FLAG
1964  006526  001003                            BNE     CMPARE          ;BR IF TWO PASSES HAVE BEEN MADE
1965  006530  010237  006600                    MOV     R2,FIRST        ;IF NOT, STORE FIRST CLOCK COUNT
1966  006534  000753                            BR      1$              ;DO LOOP AGAIN
1967  006536  013701  006600            CMPARE: MOV     FIRST,R1        ;RECALL FIRST CLOCK COUNT
1968  006542  160201                            SUB     R2,R1           ;CALCULATE DIFFERENCE OF TWO COUNTS
1969  006544  100001                            BPL     TOLER           ;IF POSITIVE,SKIP NEGATION OF DIFFERENCE
1970  006546  005401                            NEG     R1              ;MAKE DIFFERENCE A POSITIVE NUMBER
1971  006550  020127  000001            TOLER:  CMP     R1,#1           ;COMPARE DIFFERENCE WITH DESIRED TOLERANCE
1972  006554  003403                            BLE     5$              ;BR, IF LOWER/EQUAL TO TOLERANCE
1973
1974  006556  010237  006602                    MOV     R2,SECND        ;STORE SECOND COUNT
1975  006562  104053                            ERROR   53              ;CLOCK REPEATABILITY ERROR
1976
1977  006564  032777  000020  172246  5$:       BIT     #BIT4,@SWR      ;CLOCK TESTS ONLY?
1978  006572  001404                            BEQ     TST24           ;BR IF NOT
1979  006574  000137  012102                    JMP     $EOP            ;ELSE, JUMP TO END OF PASS ROUTINE
1980
1981  006600  000000            FIRST:  .WORD   0
1982  006602  000000            SECND:  .WORD   0
```



```
1983
1984
1985                                    ;;*****************************************************************
1986                                    ;*TEST 24        TEST THAT XMIT INTERRUPTS ONLY WHEN ENABLED
1987                                    ;;*****************************************************************
1988  006604  000004            TST24:  SCOPE
1989  006606  042777  000100  173536            BIC     #BIT6,@TCSR     ;CLEAR TRANSMIT INTERRUPT ENABLE
1990  006614  017703  173542                    MOV     @TVECT,R3       ;SAVE XMIT VECTOR
1991  006620  012777  006644  173534            MOV     #2$,@TVECT      ;POINT XMIT VECTOR TO ERROR REPORT
1992  006626  105777  173520            1$:     TSTB    @TCSR           ;WAIT FOR DONE
1993  006632  100375                            BPL     1$
1994  006634  004737  012242                    JSR     PC,WRPSW        ;SET PSW TO PRIORITY 3
1995  006640  000140                                    .WORD   140
1996  006642  000402                            BR      3$
1997
1998  006644  022626                    2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
1999  006646  104054                            ERROR   54
                                                                        ;XMIT INTERRUPTS WITH INTERRUPT ENABLE CLEAR
2000
2001  006650  012777  006670  173504    3$:     MOV     #4$,@TVECT      ;SET XMIT VECTOR TO END OF TEST
2002  006656  052777  000100  173466            BIS     #BIT6,@TCSR     ;ENABLE INTERRUPTS
2003  006664  000240                            NOP
2004
2005  006666  104055                            ERROR   55              ;XMIT DID NOT INTERRUPT
2006
2007  006670  042777  000100  173454    4$:     BIC     #BIT6,@TCSR     ;DISABLE INTERRUPTS
2008  006676  022626                            CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
2009  006700  010377  173456                    MOV     R3,@TVECT       ;RESTORE XMIT VECTOR
2010
```

```
2011
2012                                    ;;*****************************************************************
2013                                    ;*TEST 25        TEST THAT XMIT INTERRUPTS DO NOT OCCUR WHEN DISABLED
2014                                    ;;*****************************************************************
2015  006704  000004                    TST25:  SCOPE
2016  006706  042777  000100  173436            BIC     #BIT6,@TCSR     ;DISABLE INTERRUPTS
2017  006714  004737  012242                    JSR     PC,WRPSW        ;SET PSW TO PRIORITY 7
2018  006720  000340                            .WORD   340
2019  006722  017703  173434                    MOV     @TVECT,R3       ;SAVE XMIT VECTOR
2020  006726  012777  006754  173426            MOV     #2$,@TVECT      ;POINT XMIT VECTOR TO ERROR REPORT
2021  006734  105777  173412            1$:     TSTB    @TCSR           ;WAIT FOR DONE
2022  006740  100375                            BPL     1$
2023  006742  052777  000100  173402            BIS     #BIT6,@TCSR     ;ENABLE INTERRUPT
2024  006750  000240                            NOP
2025  006752  000402                            BR      3$              ;CONTINUE TEST
2026
2027  006754  022626                    2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
2028  006756  104056                            ERROR   56
2029                                            ;XMIT INTERRUPTS AT PRIORITY=7
2030  006760  042777  000100  173364    3$:     BIC     #BIT6,@TCSR     ;CLEAR INTERRUPT ENABLE
2031  006766  012777  007006  173366            MOV     #4$,@TVECT      ;POINT XMIT VECTOR TO ERROR REPORT
2032  006774  004737  012242                    JSR     PC,WRPSW        ;SET PSW TO PRIORITY 3
2033  007000  000140                            .WORD   140
2034  007002  000240                            NOP
2035  007004  000402                            BR      5$              ;BR TO END OF TEST-NO INTERRUPT
2036
2037  007006  022626                    4$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
2038  007010  104057                            ERROR   57
2039                                            ;XMIT INTERRUPT OCCURES WITH BIT6 CLEAR
2040  007012  010377  173344            5$:     MOV     R3,@TVECT       ;RESTORE XMIT VECTOR
```



```
2041
2042
2043                                    ;;*****************************************************************
2044                                    ;*TEST 26        TEST TRANSMITTER FOR DOUBLE INTERRUPTS
2045                                    ;;*****************************************************************
2046  007016  000004                    TST26:  SCOPE
2047  007020  042777  000100  173324            BIC     #BIT6,@TCSR     ;CLEAR INTERRUPT ENABLE
2048  007026  017703  173330                    MOV     @TVECT,R3       ;SAVE XMIT VECTOR
2049  007032  017704  173326                    MOV     @TPSW,R4        ;SAVE XMIT PSW VECTOR
2050  007036  012777  007100  173316            MOV     #2$,@TVECT      ;SET UP XMIT VECTOR
2051  007044  012777  000340  173312            MOV     #340,@TPSW      ;SET PIO 7 AFTER INTERRUPT
2052  007052  004737  012242                    JSR     PC,WRPSW        ;SET PSW TO PRIORITY 3
2053  007056  000140                            .WORD   140
2054  007060  105777  173266            1$:     TSTB    @TCSR           ;WAIT FOR DONE
2055  007064  100375                            BPL     1$
2056  007066  052777  000100  173256            BIS     #BIT6,@TCSR     ;ENABLE INTERRUPTS
2057  007074  000240                            NOP
2058
2059  007076  104060                            ERROR   60
2060                                            ;XMIT INTERRUPT DID NOT OCCUR
2061  007100  022626                    2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
2062  007102  012777  007130  173252            MOV     #4$,@TVECT      ;POINT XMIT VECTOR TO ERROR
2063  007110  004737  012242                    JSR     PC,WRPSW        ;SET PSW TO PRIORITY 3
2064  007114  000140                            .WORD   140
2065  007116  000240                            NOP                     ;GIVE TIME FOR ANY INTERRUPTS
2066  007120  042777  000100  173224            BIC     #BIT6,@TCSR     ;DISABLE INTERRUPTS
2067  007126  000402                            BR      5$              ;BR TO END OF TEST
2068
2069  007130  022626                    4$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
2070  007132  104061                            ERROR   61
2071                                            ;XMIT RE-INTERRUPTED
2072  007134  010377  173222            5$:     MOV     R3,@TVECT       ;RESTORE XMIT VECTOR
2073  007140  010477  173220                    MOV     R4,@TPSW        ;RESTORE XMIT PSW VECTOR
2074
2075                                    ;;*****************************************************************
2076                                    ;*TEST 27        TEST THAT XMIT INTERRUPT CLEARS WITH LOADING TBUF
2077                                    ;;*****************************************************************
2078  007144  000004                    TST27:  SCOPE
2079  007146  042777  000100  173176            BIC     #BIT6,@TCSR     ;DISABLE INTERRUPTS
2080  007154  004737  012242                    JSR     PC,WRPSW        ;SET PSW TO PRIORITY 7
2081  007160  000340                            .WORD   340
2082  007162  017703  173174                    MOV     @TVECT,R3       ;SAVE XMIT VECTOR
2083  007166  012777  007240  173166            MOV     #2$,@TVECT      ;POINT XMIT VECTOR TO ERROR
2084  007174  052777  000100  173150            BIS     #BIT6,@TCSR     ;ENABLE INTERRUPTS
2085  007202  005077  173146                    CLR     @TBUF           ;LOAD TBUF
2086  007206  105777  173140            1$:     TSTB    @TCSR           ;WAIT FOR DONE (INTERRUPT)
2087  007212  100375                            BPL     1$
2088  007214  005077  173134                    CLR     @TBUF           ;FILL SECOND BUFFER TO RESET INT.
2089  007220  004737  012242                    JSR     PC,WRPSW        ;ALLOW INTERRUPTS
2090  007224  000140                            .WORD   140
2091  007226  000240                            NOP                     ;GIVE TIME FOR ANY INTERRUPTS
2092  007230  042777  000100  173114            BIC     #BIT6,@TCSR     ;DISABLE INTERRUPTS
2093  007236  000402                            BR      3$              ;BR TO END OF TEST
2094
2095  007240  022626                    2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
2096  007242  104062                            ERROR   62
```

```
                                                        ;LOADING TBUF DID NOT CLEAR INTERRUPT.
007244  010377  173112          3$:     MOV     R3,@TVECT       ;RESTORE XMIT VECTOR
```



```
                                        ;;**************************************************************
                                        ;*TEST 30       TEST THAT RCVR ACTIVE (11) & DONE (7) SET & CLEAR PROPERLY
                                        ;;**************************************************************
007250  000004                  TST30:  SCOPE
007252  000005                          RESET                   ;CLEAR EVERYTHING
007254  052777  000004  173070          BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
007262  005000                          CLR     R0              ;CLEAR A TIMER
007264  005077  173064                  CLR     @TBUF           ;LOAD TRANSMIT BUFFER
007270  032777  004000  173050  WACTV:  BIT     #BIT11,@RCSR    ;TEST RCVR ACTIVE BIT
007276  001006                          BNE     2$              ;BR IF SET
007300  005200                          INC     R0              ;INCREMENT TIMER IF NOT SET
007302  001372                          BNE     WACTV           ;CONTINUE WAIT IF TIME REMAINS
007304  042777  000004  173040          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT

007312  104063                          ERROR   63              ;RCVR ACTIVE DID NOT SET WHILE RECEIVING

007314  000005                  2$:     RESET
007316  032777  004000  173022          BIT     #BIT11,@RCSR    ;VERIFY "INIT" CLEARS RCV ACTIVE
007324  001401                          BEQ     3$

007326  104115                          ERROR   115             ;INIT DID NOT CLEAR RCV ACTIVE

007330  005000                  3$:     CLR     R0              ;CLEAR A TIMER
007332  052777  000004  173012          BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
007340  062700  000000          WT:     ADD     #0,R0           ;WAIT AT LEAST ONE BIT TIME
007344  005200                          INC     R0
007346  001374                          BNE     WT
007350  033777  004000  172770          BIT     BIT11,@RCSR     ;VERIFY RCV ACTIVE STILL CLEAR
007356  001404                          BEQ     4$              ;BR IF CLEAR

007360  042777  000004  172764          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE WRAP
007366  104116                          ERROR   116             ;RCV ACTIVE WITHOUT "START" BIT

007370  005000                  4$:     CLR     R0              ;CLEAR TIMER
007372  005077  172756                  CLR     @TBUF           ;LOAD TRANSMIT BUFFER
007376  105777  172744          WDONE:  TSTB    @RCSR           ;CHECK FOR RECEIVER DONE
007402  100406                          BMI     5$              ;BR, IF DONE
007404  005200                          INC     R0              ;INCREMENT TIMER, IF NOT DONE
007406  001373                          BNE     WDONE           ;CONTINUE WAIT IF TIME REMAINS
007410  042777  000004  172734          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
007416  104064                          ERROR   64
                                                        ;RECEIVER DONE NEVER SET

007420  032777  004000  172720  5$:     BIT     #BIT11,@RCSR    ;CHECK FOR RCVR ACTIVE CLEAR
007426  001404                          BEQ     6$              ;BR, IF CLEAR
007430  042777  000004  172714          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
007436  104065                          ERROR   65
                                                        ;RCVR ACTIVE DID NOT CLEAR WITH RCVR DONE

007440  000005                  6$:     RESET                   ;CLEAR DONE WITH RESET
007442  105777  172700                  TSTB    @RCSR           ;CHECK FOR DONE CLEAR
007446  001404                          BEQ     7$

007450  042777  000004  172674          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
007456  104066                          ERROR   66
```

```
                                                                        ;RESET DID NOT CLEAR RCVR DONE

007460  042777  000004  172660  7$:     BIC     #BIT2,@RCSR     ;CLEAR MAINTENANCE BIT
007466  000400                          BR      TST31           ;BR TO NEXT TEST
```



```
                                ;;*****************************************************************
                                ;*TEST 31        TEST THAT RDR ENABLE CLEARS RECEIVER DONE FLAG
                                ;;*****************************************************************
007470  000004                  TST31:  SCOPE
007472  000005                          RESET                   ;CLEAR EVERYTHING
007474  052777  000001  172644        BIS     #BIT0,@RCSR     ;SET RDR ENABLE
007502  052777  000004  172642        BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
007510  005077  172640                CLR     @TBUF           ;LOAD TRANSMITTER
007514  105777  172626          1$:   TSTB    @RCSR           ;WAIT FOR RECEIVER DONE
007520  100375                        BPL     1$
007522  032777  000001  172616        BIT     #BIT0,@RCSR     ;VERIFY RCV ACTIVE CLEARED RDR ENABLE
007530  001401                        BEQ     2$              ;BR IF CLEAR

007532  104117                        ERROR   117             ;RDR ENABLE NOT CLEARED WITH RCV ACTIVE

007534  052777  000001  172604  2$:   BIS     #BIT0,@RCSR     ;CLEAR DONE BY SETTING RDR ENABLE
007542  105777  172600                TSTB    @RCSR           ;CHECK FOR DONE CLEAR
007546  001404                        BEQ     TST32           ;BR, IF CLEAR TO NEXT TEST
007550  042777  000004  172574        BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
007556  104067                        ERROR   67
                                                                ;SETTING RDR ENABLE DID NOT CLEAR RCVR DONE


                                ;;*****************************************************************
                                ;*TEST 32        TEST THAT READING RBUF CLEARS RECEIVER DONE
                                ;;*****************************************************************
007560  000004                  TST32:  SCOPE
007562  000005                          RESET                   ;CLEAR EVERYTHING
007564  052777  000004  172560        BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
007572  005077  172556                CLR     @TBUF           ;LOAD TRANSMITTER
007576  105777  172544          1$:   TSTB    @RCSR           ;WAIT FOR RECEIVER DONE
007602  100375                        BPL     1$
007604  017700  172540                MOV     @RBUF,R0        ;READ RECEIVE BUFFER
007610  042777  000004  172534        BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
007616  105777  172524                TSTB    @RCSR           ;CHECK FOR RECEIVE DONE CLEAR
007622  001401                        BEQ     TST33           ;BR, IF CLEAR TO NEXT TEST
007624  104070                        ERROR   70
                                                                ;READING RBUF DID NOT CLEAR RCVR DONE
```

```
                                        ;;*****************************************************************
                                        ;*TEST 33       TEST THAT RCVR INTERRUPTS ONLY WHEN ENABLED
                                        ;;*****************************************************************
007626  000004                  TST33:  SCOPE
007630  042777  000100  172514          BIC     #BIT6,@TCSR     ;DISABLE TRANSMIT INTERRUPTS
007636  042777  000100  172502          BIC     #BIT6,@RCSR     ;DISABLE RECEIVER INTERRUPTS
007644  052777  000004  172500          BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
007652  017703  172500                  MOV     @RVECT,R3       ;SAVE RECEIVE VECTOR
007656  012777  007714  172472          MOV     #2$,@RVECT      ;POINT RCV VECTOR TO ERROR REPORT
007664  004737  012242                  JSR     PC,WRPSW        ;SET PSW TO PRIORITY 3
007670  000140                          .WORD   140
007672  005077  172456                  CLR     @TBUF           ;SEND A CHARACTER
007676  105777  172444          1$:     TSTB    @RCSR           ;WAIT FOR RECEIVER DONE
007702  100375                          BPL     1$
007704  042777  000004  172440          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
007712  000405                          BR      3$              ;CONTINUE TEST
                                
007714  042777  000004  172430  2$:     BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
007722  022626                          CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
007724  104071                          ERROR   71
                                                                ;RECEIVER INTERRPUTS WITH INT. ENABLE CLEAR
                                
007726  012777  007754  172422  3$:     MOV     #4$,@RVECT      ;POINT RCV VECTOR TO END OF TEST
007734  052777  000100  172404          BIS     #BIT6,@RCSR     ;ENABLE RCV INTERRUPTS
007742  000240                          NOP                     ;GIVE ANY INTERRUPTS TIME
007744  042777  000004  172400          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
007752  104072                          ERROR   72
                                                                ;RCVR DID NOT INTERRUPT
                                
007754  042777  000100  172364  4$:     BIC     #BIT6,@RCSR     ;DISABLE INTERRUPTS
007762  042777  000004  172362          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
007770  022626                          CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
007772  010377  172360                  MOV     R3,@RVECT       ;RESTORE RECEIVE VECTOR
```



```
                                        ;;*****************************************************************
                                        ;*TEST 34       TEST THAT RCVR INTERRUPTS DO NOT OCCUR WHEN DISABLED
                                        ;;*****************************************************************
007776  000004                  TST34:  SCOPE
010000  000005                          RESET                   ;CLEAR EVERYTHING
010002  004737  012242                  JSR     PC,WRPSW        ;SET PSW TO PRIORITY 7
010006  000340                          .WORD   340
010010  017703  172342                  MOV     @RVECT,R3       ;SAVE RECEIVE VECTOR
010014  012777  010054  172334          MOV     #2$,@RVECT      ;POINT RCVR VECTOR TO ERROR REPORT
010022  052777  000004  172322          BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
010030  005077  172320                  CLR     @TBUF           ;SEND A CHARACTER
010034  105777  172306          1$:     TSTB    @RCSR           ;WAIT FOR RECEIVER DONE
010040  100375                          BPL     1$
010042  052777  000100  172276          BIS     #BIT6,@RCSR     ;ENABLE INTERRUPTS
010050  000240                          NOP                     ;GIVE TIME FOR INTERRUPT
010052  000405                          BR      3$              ;CONTINUE TEST
010054  042777  000004  172270  2$:     BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
010062  022626                          CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
010064  104073                          ERROR   73
                                                                ;RCVR INTERRUPTS AT PRIORITY 7
                                
010066  042777  000100  172252  3$:     BIC     #BIT6,@RCSR     ;CLEAR INTERRUPT ENABLE
010074  012777  010122  172254          MOV     #4$,@RVECT      ;POINT RCVR VECTOR TO ERROR REPORT
010102  004737  012242                  JSR     PC,WRPSW        ;SET PSW TO PRIORITY 3
010106  000140                          .WORD   140
010110  000240                          NOP                     ;GIVE TIME FOR ANY INTERRUPT
010112  042777  000004  172232          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
010120  000405                          BR      5$              ;BR TO END OF TEST, IF NO INTERRUPT
                                
010122  042777  000004  172222  4$:     BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
010130  022626                          CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
010132  104074                          ERROR   74
                                                                ;RCVR INTERRUPT REQUEST PASSED WITH BIT6 CLEAR
010134  010377  172216          5$:     MOV     R3,@RVECT       ;RESTORE RECEIVE VECTOR
```

```
                                        ;;*****************************************************************
                                        ;*TEST 35       TEST RECEIVER FOR DOUBLE INTERRUPTS
                                        ;;*****************************************************************
010140  000004                  TST35:  SCOPE
010142  000005                          RESET                   ;CLEAR EVERYTHING
010144  017703  172206                  MOV     @RVECT,R3       ;SAVE RECEIVE VECTOR
010150  017704  172204                  MOV     @RPSW,R4        ;SAVE RECEIVE PSW VECTOR
010154  012777  010236  172174          MOV     #2$,@RVECT      ;POINT RCV VECTOR TO CONTINUE TEST
010162  012777  000340  172170          MOV     #340,@RPSW      ;SET PRIORITY TO 7 AFTER INTERRUPT
010170  004737  012242                  JSR     PC,WRPSW        ;SET PSW TO PRIORITY 3
010174  000140                          .WORD   140
010176  052777  000004  172146          BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
010204  005077  172144                  CLR     @TBUF           ;SEND A CHARACTER
010210  105777  172132          1$:     TSTB    @RCSR           ;WAIT FOR RCVR DONE
010214  100375                          BPL     1$
010216  042777  000004  172126          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
010224  052777  000100  172114          BIS     #BIT6,@RCSR     ;ENABLE RCV INTERRUPTS
010232  000240                          NOP                     ;GIVE SOME TIME

010234  104075                          ERROR   75
                                                                ;RCVR INTERRUPT DID NOT OCCUR

010236  022626                  2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
010240  012777  010276  172110          MOV     #3$,@RVECT      ;POINT RCV VECTOR TO ERROR REPORT
010246  004737  012242                  JSR     PC,WRPSW        ;RESET PSW TO PRIORITY 3
010252  000140                          .WORD   #140
010254  000240                          NOP                     ;GIVE SOME TIME
010256  042777  000100  172062          BIC     #BIT6,@RCSR     ;CLEAR INTERRUPT ENABLE
010264  010377  172066                  MOV     R3,@RVECT       ;RESTORE RECEIVE VECTOR
010270  010477  172064                  MOV     R4,@RPSW        ;RESTORE RECEIVE PSW VECTOR
010274  000402                          BR      4$              ;BR TO END OF TEST

010276  022626                  3$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
010300  104076                          ERROR   76
                                                                ;RECEIVER RE-INTERRUPTED
010302  010377  172050          4$:     MOV     R3,@RVECT       ;RESTORE RECEIVE VECTOR
```



```
                                        ;;*****************************************************************
                                        ;*TEST 36       TEST THAT RCVR INTERRUPT CLEARS BY READING RBUF
                                        ;;*****************************************************************
010306  000004                  TST36:  SCOPE
010310  000005                          RESET                   ;CLEAR EVERYTHING
010312  004737  012242                  JSR     PC,WRPSW        ;SET PSW PRIORITY TO 7
010316  000340                          .WORD   340
010320  017703  172032                  MOV     @RVECT,R3       ;SAVE RECEIVE VECTOR
010324  012777  010412  172024          MOV     #2$,@RVECT      ;POINT RCV VECTOR TO ERROR REPORT
010332  052777  000100  172006          BIS     #BIT6,@RCSR     ;SET RCVR INTERRUPT ENABLE
010340  052777  000004  172004          BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
010346  005077  172002                  CLR     @TBUF           ;SEND A CHARACTER
010352  105777  171770          1$:     TSTB    @RCSR           ;WAIT FOR DONE (INTERRUPT)
010356  100375                          BPL     1$
010360  042777  000004  171764          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
010366  005077  171756                  CLR     @RBUF           ;READ RBUF TO CLEAR PENDING INTERRPUT
010372  004737  012242                  JSR     PC,WRPSW        ;SET PSW TO PRIORITY 3
010376  000140                          .WORD   140
010400  000240                          NOP                     ;ALLOW TIME FOR ANY ERRONEOUS INTERRUPT
010402  042777  000100  171736          BIC     #BIT6,@RCSR     ;NO INTERRUPT-CLEAR INT. ENABLE
010410  000402                          BR      3$

010412  022626                  2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
010414  104077                          ERROR   77              ;READING RBUF DID NOT CLEAR INTERRUPT

010416  010377  171734          3$:     MOV     R3,@RVECT       ;RESTORE RECEIVE VECTOR
```

```
2339
2340
2341                                    ;;*****************************************************************
2342                                    ;*TEST 37       TEST THAT RESET CLEARS RECEIVE INTERRUPT
2343                                    ;;*****************************************************************
2344  010422  000004                    TST37:  SCOPE
2345  010424  000005                            RESET                   ;CLEAR EVERYTHING
2346  010426  004737  012242                    JSR     PC,WRPSW        ;SET PSW TO PRIORITY 7
2347  010432  000340                            .WORD   340
2348  010434  017703  171716                    MOV     @RVECT,R3       ;SAVE RECEIVE VECTOR
2349  010440  012777  010520  171710            MOV     #2$,@RVECT      ;POINT RCV VECTOR TO ERROR REPORT
2350  010446  052777  000100  171672            BIS     #BIT6,@RCSR     ;SET RCV INTERRUPT ENABLE
2351  010454  052777  000004  171670            BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
2352  010462  012777  000377  171664            MOV     #377,@TBUF      ;SEND AN ALL 1'S CHARACTER
2353  010470  105777  171652          1$:       TSTB    @RCSR           ;WAIT FOR RCV DONE
2354  010474  100375                            BPL     1$
2355  010476  000005                            RESET                   ;CLEAR RCV INTERRUPT & RBUF
2356  010500  004737  012242                    JSR     PC,WRPSW        ;SET PSW TO PRIORITY 3
2357  010504  000140                            .WORD   140
2358  010506  000240                            NOP                     ;ALLOW TIME FOR AN ERRONEOUS INTERRUPT
2359  010510  042777  000100  171630            BIC     #BIT6,@RCSR     ;NO INTERRUPT-CLEAR INT. ENABLE
2360  010516  000402                            BR      3$              ;CONTINUE TEST
2361
2362
2363  010520  022626                    2$:     CMP     (SP)+,(SP)+     ;RESTORE SP AFTER INTERRUPT
2364  010522  104100                            ERROR   100             ;RESET DID NOT CLEAR RCVR INTERRUPT
2365
2366  010524  010377  171626            3$:     MOV     R3,@RVECT       ;RESTORE RECEIVE VECTOR
```



```
2367
2368
2369                                    ;;*****************************************************************
2370                                    ;*TEST 40       TEST THAT THE "OR" ERROR (BIT14) & "ERROR" (BIT15) CAN BE SET
2371                                    ;;*****************************************************************
2372  010530  000004                    TST40:  SCOPE
2373  010532  032777  002000  170300            BIT     #BIT10,@SWR     ;IS THIS TEST ENABLED
2374  010540  001432                            BEQ     TST41           ;IF NOT ENABLED, BR TO NEXT TEST
2375  010542  000005                            RESET                   ;CLEAR EVERYTHING
2376  010544  052777  000004  171600            BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
2377  010552  012700  000003                    MOV     #3,R0           ;SET CHARACTER COUNT TO SEND 3 CHAR.
2378  010556  005077  171572          1$:       CLR     @TBUF           ;LOAD TRANSMIT BUFFER
2379  010562  105777  171564          2$:       TSTB    @TCSR           ;WAIT FOR TRANSMIT DONE
2380  010566  100375                            BPL     2$
2381  010570  005300                            DEC     R0              ;DECREMENT CHARACTER COUNT
2382  010572  001371                            BNE     1$              ;BR IF ALL CHARACTERS NOT TRANSMITTED
2383  010574  042777  000004  171550            BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
2384  010602  032777  040000  171540            BIT     #BIT14,@RBUF    ;TEST FOR "OR" ERROR FLAG
2385  010610  001001                            BNE     3$              ;BR, IF SET
2386  010612  104101                            ERROR   101
2387                                                                    ;"OR" ERROR FLAG DID NOT SET
2388
2389  010614  032777  100000  171526  3$:       BIT     #BIT15,@RBUF    ;TEST "ERROR" FLAG
2390  010622  001001                            BNE     4$              ;BR, IF SET
2391  010624  104102                            ERROR   102
2392                                                                    ;"ERROR" FLAG DID NOT SET WITH "OR" FLAG
2393  010626                            4$:
```

```
2394
2395
2396                                    ;;*****************************************************************
2397                                    ;*TEST 41        TEST THAT BREAK TRANSMITS ALL ZEROES
2398                                    ;;*****************************************************************
2399  010626  000004                    TST41:  SCOPE
2400  010630  032777  000400  170202            BIT     #BIT8,@SWR      ;IS BREAK FUNCTION TEST ENABLED?
2401  010636  001444                            BEQ     TST42           ;BR TO NEXT TEST, IF NOT ENABLED
2402  010640  000005                            RESET                   ;CLEAR EVERYTHING
2403  010642  052777  000004  171502            BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
2404  010650  012777  177777  171476            MOV     #-1,@TBUF       ;TRANSMIT ALL ONES TO RCVR
2405  010656  105777  171464            1$:     TSTB    @RCSR           ;WAIT FOR RCVR DONE
2406  010662  100375                            BPL     1$
2407  010664  005077  171460                    CLR     @RBUF           ;CLEAR DONE (LEAVING ALL ONES IN RBUF)
2408  010670  052777  000001  171454            BIS     #BIT0,@TCSR     ;TRANSMIT BREAK
2409  010676  005000                            CLR     R0              ;CLEAR A TIMER
2410  010700  117737  171442  001026    2$:     MOVB    @RCSR,$BDDAT    ;WAIT FOR RCVR DONE
2411  010706  100406                            BMI     CONT41          ;BR IF DONE
2412  010710  005200                            INC     R0              ;IF NOT, INCREMENT TIMER
2413  010712  001372                            BNE     2$              ;BR IF TIME REMAINS
2414
2415  010714  042777  000005  171430            BIC     #BIT0!BIT2,@TCSR  ;CLEAR MAINTENANCE & BREAK BITS
2416  010722  104103                            ERROR   103             ;BREAK DID NOT TRANSMIT ANYTHING
2417
2418  010724  105777  171420            CONT41: TSTB    @RBUF           ;CHECK RECEIVE BUFFER FOR ZERO
2419  010730  001404                            BEQ     3$              ;BR, IF ZERO
2420  010732  042777  000005  171412            BIC     #BIT0!BIT2,@TCSR  ;CLEAR MAINTENANCE & BREAK BITS
2421
2422  010740  104103                            ERROR   103             ;BREAK DID NOT TRANSMIT ALL ZEROES
2423
2424  010742  042777  000005  171402    3$:     BIC     #BIT0!BIT2,@TCSR ;CLEAR MAINTENANCE & BREAK BITS
```



```
2425
2426
2427                                    ;;*****************************************************************
2428                                    ;*TEST 42        TEST THAT "FR" ERROR CAN BE SET DURING BREAK
2429                                    ;;*****************************************************************
2430  010750  000004                    TST42:  SCOPE
2431  010752  032777  002000  170060            BIT     #BIT10,@SWR     ;IS THE "TEST ERROR FLAGS" BIT SET
2432  010760  001435                            BEQ     TST43           ;BR TO NEXT TEST, IF NOT SET
2433  010762  032777  000400  170050            BIT     #BIT8,@SWR      ;IS BREAK FUNCTION ENABLED
2434  010770  001431                            BEQ     TST43           ;BR TO NEXT TEST, IF NOT SET
2435  010772  000005                            RESET                   ;CLEAR EVERYTHING
2436  010774  052777  000004  171350            BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
2437  011002  052777  000001  171342            BIS     #BIT0,@TCSR     ;SEND BREAK
2438  011010  005077  171340                    CLR     @TBUF           ;TRANSMIT A CHARACTER TO TIME BREAK
2439  011014  105777  171326            1$:     TSTB    @RCSR           ;WAIT FOR RCVR DONE
2440  011020  100375                            BPL     1$
2441  011022  042777  000005  171322            BIC     #BIT0!BIT2,@TCSR ;CLEAR MAINTENANCE & BREAK BITS
2442  011030  032777  020000  171312            BIT     #BIT13,@RBUF    ;CHECK FOR FRAMING ERROR FLAG
2443  011036  001001                            BNE     2$              ;BR, IF SET
2444
2445  011040  104104                            ERROR   104
                                                                        ;BREAK DID NOT SET FRAMING ERROR
2446
2447  011042  032777  100000  171300    2$:     BIT     #BIT15,@RBUF    ;TEST "ERROR"FLAG
2448  011050  001001                            BNE     3$              ;BR, IF SET
2449
2450  011052  104114                            ERROR   114
                                                                        ;"ERROR" FLAG DID NOT SET WITH "OR" FLAG
2451
2452  011054                            3$:
```

```
                                        ;;*************************************************************
                                        ;*TEST 43       TEST DATA PATH FROM TRANSMITTER TO RECEIVER USING MAINTENANCE WRAP
                                        ;;*************************************************************
011054  000004                  TST43:  SCOPE

011056  000005                          RESET                   ;CLEAR EVERYTHING
011060  005001                          CLR     R1              ;CLEAR REGISTER FOR TEST DATA
011062  052777  000004  171262          BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
                                                                ;TRANSMIT A BINARY COUNT PATTERN - UP
                                                                ;TO THE BIT POSITION INDICATED BY THE
                                                                ;CONTENTS OF LOCATION "$USWR"
011070  005201                  1$:     INC     R1              ;INCREMENT THE TEST DATA
011072  010177  171256                  MOV     R1,@TBUF        ;XMIT A CHARACTER
011076  105777  171244          2$:     TSTB    @RCSR           ;WAIT FOR RECEIVER DONE
011102  100375                          BPL     2$
011104  017702  171240                  MOV     @RBUF,R2        ;GET RECEIVED CHARACTER
011110  043701  001112                  BIC     @#$USWR,R1      ;CLEAR LOWEST UNUSED DATA BIT POSITITON IN TEST DATA
011114  020102                          CMP     R1,R2           ;COMPARE DATA
011116  001003                          BNE     3$              ;BR, IF NON-COMPARE
011120  105701                          TSTB    R1              ;TEST XMIT DATA FOR ZERO
011122  001411                          BEQ     4$              ;BR, IF FINISHED
011124  000761                          BR      1$              ;CONTINUE IF NOT
011126  010137  001024          3$:     MOV     R1,$GDDAT       ;STORE THE EXPECTED DATA
011132  010237  001026                  MOV     R2,$BDDAT       ;STORE RECEIVED DATA
011136  042777  000004  171206          BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT
011144  104105                          ERROR   105             ;DATA COMPARE DATA

011146  042777  000004  171176  4$:     BIC     #BIT2,@TCSR     ;CLEAR MAINTENANCE BIT


                                        ;;*************************************************************
                                        ;*TEST 44       TEST DATA PATHS USING WRAP CABLE
                                        ;;*************************************************************
011154  000004                  TST44:  SCOPE
011156  032777  000200  167654          BIT     #BIT7,@SWR      ;IS THIS TEST ENABLED
011164  001432                          BEQ     TST45           ;BR, IF NOT
011166  000005                          RESET                   ;CLEAR EVERYTHING
011170  005001                          CLR     R1              ;CLEAR REGISTER FOR TEST DATA
                                                                ;TRANSMIT A BINARY COUNT PATTERN - UP
                                                                ;TO THE BIT POSITION INDICATED BY THE
                                                                ;CONTENTS OF LOCATION "$USWR"
011172  105201                  1$:     INCB    R1              ;INCREMENT THE TEST DATA
011174  010177  171154                  MOV     R1,@TBUF        ;XMIT A CHARACTER
011200  005000                          CLR     R0              ;CLEAR A TIMER
011202  105777  171140          2$:     TSTB    @RCSR           ;WAIT FOR RECEIVER DONE
011206  100403                          BMI     3$              ;BR IF DONE
011210  005200                          INC     R0              ;INCREMENT TIMER IF NOT
011212  001373                          BNE     2$              ;BR IF TIME REMAINS

011214  104064                          ERROR   64              ;RECEIVER DONE NOT SET

011216  017702  171126          3$:     MOV     @RBUF,R2        ;GET RECEIVED CHARACTER
011222  043701  001112                  BIC     @#$USWR,R1      ;CLEAR LOWEST UNUSED DATA BIT POSITITON IN TEST DATA
```



```
011226  020102                          CMP     R1,R2           ;COMPARE DATA
011230  001003                          BNE     4$              ;BR, IF NON-COMPARE
011232  105701                          TSTB    R1              ;TEST XMIT DATA FOR ZERO
011234  001406                          BEQ     TST45           ;BR, IF FINISHED
011236  000755                          BR      1$              ;CONTINUE IF NOT
011240  010137  001024          4$:     MOV     R1,$GDDAT       ;STORE EXPECTED DATA
011244  010237  001026                  MOV     R2,$BDDAT       ;STORE RECEIVED DATA

011250  104106                          ERROR   106             ;DATA COMPARE ERROR WITH WRAP CABLE
```

```
                                        ;;*****************************************************************
                                        ;*TEST 45       TEST DL11-W LOGIC BY EXERCISING THE XMIT,RECEIVE, & CLOCK(IF AVAILABLE)
                                        ;;*****************************************************************
011252  000004                TST45:  SCOPE
011254  000005                        RESET                   ;CLEAR EVERYTHING
011256  004737  012242                JSR     PC,WRPSW        ;SET PRIORITY TO 7
011262  000340                        .WORD   340
011264  017703  171072                MOV     @TVECT,R3       ;SAVE XMIT VECTOR
011270  017704  171062                MOV     @RVECT,R4       ;SAVE RECEIVE VECTOR
011274  017705  171110                MOV     @RTCVT,R5       ;SAVE CLOCK VECTOR
011300  017737  171060  011734        MOV     @TPSW,STPSW     ;SAVE XMIT PSW VECTOR
011306  017737  171046  011736        MOV     @RPSW,SRPSW     ;SAVE RECEIVE PSW VECTOR
011314  017737  171072  011740        MOV     @RTCPSW,SCPSW   ;SAVE CLOCK PSW VECTOR
011322  012777  011650  171032        MOV     #XMIT,@TVECT    ;POINT TRANSMIT VECTOR TO TRANSMIT ROUTINE
011330  005077  171030                CLR     @TPSW           ;ALLOW INTERRUPTS AFTER XMIT INTERRUPT
011334  012777  011704  171014        MOV     #RCV,@RVECT     ;POINT RECEIVE VECTOR TO RECEIVE ROUTINE
011342  005077  171012                CLR     @RPSW           ;ALLOW INTERRPUTS AFTER RCVR INTERRUPT
011346  005737  002336                TST     CTSTFL          ;IS CONSOLE UNDER TEST?
011352  001414                        BEQ     1$              ;IF NOT SKIP CLOCK SET UP
011354  032777  000100  167456        BIT     #BIT6,@SWR      ;IF YES, ARE CLOCK TEST DISABLED?
011362  001010                        BNE     1$              ;IF YES, SKIP CLOCK SET UP
011364  012777  011720  171016        MOV     #CLK,@RTCVT     ;POINT VECTOR TO CLOCK INTERRUPT ROUTINE
011372  005077  171014                CLR     @RTCPSW         ;ALLOW INTERRUPTS AFTER CLOCK INTERRUPT
011376  052777  000100  171002        BIS     #BIT6,@LKS      ;ENABLE CLOCK INTERRUPTS
011404  052777  000004  170740  1$:   BIS     #BIT2,@TCSR     ;SET MAINTENANCE WRAP
011412  052777  000100  170732        BIS     #BIT6,@TCSR     ;ENABLE TRANSMIT INTERRUPTS
011420  052777  000100  170720        BIS     #BIT6,@RCSR     ;ENABLE RECEIVE INTERRUPTS
011426  005037  011730                CLR     XMTCNT          ;CLEAR XMIT INTERRUPT COUNTER
011432  005037  011726                CLR     RCVCNT          ;CLEAR RCV INTERRUPT COUNTER
011436  005001                        CLR     R1              ;CLEAR A REGISTER FOR TEST DATA USE
011440  005000                        CLR     R0              ;CLEAR TIMER
011442  012702  011742                MOV     #BUF,R2         ;POINT R2 TO RECEIVE DATA STORAGE
011446  005077  170702                CLR     @TBUF           ;SEND FIRST CHARACTER
011452  004737  012242                JSR     PC,WRPSW        ;SET PSW TO PRIORITY 3
011456  000140                        .WORD   140
                                                            ;WAIT FOR INTERRUPTS
011460  062700  000000        2$:     ADD     #0,R0           ;ADD INSTRUCTIONS ARE USED TO LENGTHEN LOOP TIME
011464  062700  000001                ADD     #1,R0           ;  TO COVER THE SLOWEST BAUD RATE ON THE FASTEST CPU
011470  001373                        BNE     2$
011472  032777  000100  170652        BIT     #BIT6,@TCSR     ;FINISHED ENTIRE TRANSMISSION
011500  001402                        BEQ     3$              ;BR, IF INTERRPUTS ARE DISABLED (FINISHED)
011502  000005                        RESET                   ;CLEAR EVERYTHING
                                                            
011504  104107                        ERROR   107             ;TRANSMIT INTERRUPT TIMEOUT IN MAIN. DATA TEST
                                                            
011506  023737  011730  011726  3$:   CMP     XMTCNT,RCVCNT   ;COMPARE THE NUMBER OF INTERRUPTS
011514  001402                        BEQ     4$              ;BR, IF EQUAL
011516  000005                        RESET                   ;CLEAR EVERYTHING
                                                            
011520  104110                        ERROR   110             ;RECEIVER DID NOT GET FULL TRANSMISSION
                                                            ;   IF RCVCNT=0, NO DATA RECEIVED
                                                            ;   IF RCVCNT=?, THEN (XMTCNT-RCVCNT)
                                                            ;   EQUALS THE NO. OF INTERRUPTS LOST.
```



```
011522  005737  002336        4$:     TST     CTSTFL          ;IS CONCOLE UNDER TEST?
011526  001410                        BEQ     5$              ;IF NOT, SKIP CLOCK COUNT CHECK
011530  032777  000100  167302        BIT     #BIT6,@SWR      ;IF YES, ARE CLOCK TESTS DISABLED?
011536  001004                        BNE     5$              ;IF YES, SKIP CLOCK COUNT CHECK
011540  005737  011732                TST     CLKCNT          ;CHECK FOR AT LESST ONE CLOCK INTERRUPT
011544  001001                        BNE     5$              ;BR IF INTERRUPTS OCCURRED
                                                            
011546  104113                        ERROR   113             ;NO CLOCK INTERRUPTS IN EXERCISER
                                                            
011550  000005                5$:     RESET                   ;CLEAR EVERYTHING
011552  012700  011742                MOV     #BUF,R0         ;LOAD RECEIVED DATA POINTER TO R0
011556  005001                        CLR     R1              ;SET UP REGISTER FOR COMPARISON
011560  022001                COMP:   CMP     (R0)+,R1        ;COMPARE XMIT & RCV DATA
011562  001005                        BNE     6$              ;BR, IF NOT EQUAL
011564  105201                        INCB    R1              ;INCREMENT COMPARE DATA
011566  032701  000040                BIT     #BIT5,R1        ;FINISHED CHECKING RECEIVED DATA?
011572  001772                        BEQ     COMP            ;BR, IF NOT FINISHED
011574  000405                        BR      7$              ;BR TO END OF TEST
                                                            
011576  014037  001026        6$:     MOV     -(R0),$BDDAT    ;STORE BAD DATA FOR ERROR REPORT
011602  010137  001024                MOV     R1,$GDDAT       ;STORE GOOD DATA FOR ERROR REPORT
011606  104111                        ERROR   111             ;DATA COMPARE ERROR IN EXERCISER
                                                            
011610  010377  170546        7$:     MOV     R3,@TVECT       ;RESTORE XMIT VECTOR
011614  010477  170536                MOV     R4,@RVECT       ;RESTORE RECEIVE VECTOR
011620  010577  170564                MOV     R5,@RTCVT       ;RESTORE CLOCK VECTOR
011624  013777  011734  170532        MOV     STPSW,@TPSW     ;RESTORE XMIT PSW VECTOR
011632  013777  011736  170520        MOV     SRPSW,@RPSW     ;RESTORE RECEIVE PSW VECTOR
011640  013777  011740  170540        MOV     SCPSW,@RTCPSW   ;RESTORE CLOCK PSW VECTOR
011646  000501                        BR      ENDEV           ;BR TO END OF DEVICE TEST ROUTINE
                                                            
011650  005237  011730        XMIT:   INC     XMTCNT          ;INCREMENT XMIT INTERRUPT COUNTER
011654  105201                        INCB    R1              ;INCREMENT TEST DATA
011656  032701  000040                BIT     #BIT5,R1        ;SEND DATA PATTERN FROM 00 --> 37
011662  001404                        BEQ     XCONT           ;BR, IF MORE DATA TO BE SENT
011664  042777  000100  170460        BIC     #BIT6,@TCSR     ;CLEAR XMIT INTERRUPT ENABLE
011672  000402                        BR      XRET            ;RETURN, WITHOUT SENDING ANY MORE DATA
011674  110177  170454        XCONT:  MOVB    R1,@TBUF        ;SEND NEW CHARACTER
011700  005000                XRET:   CLR     R0              ;CLEAR TIMER
011702  000002                        RTI                     ;RETURN
                                                            
011704  017722  170440        RCV:    MOV     @RBUF,(R2)+     ;STORE RECEIVED DATA
011710  005237  011726                INC     RCVCNT          ;INCREMENT RCV INTERRUPT COUNTER
011714  005000                        CLR     R0              ;CLEAR TIMER
011716  000002                        RTI                     ;RETURN
                                                            
011720  005237  011732        CLK:    INC     CLKCNT          ;INCREMENT CLOCK INTERRUPT COUNT
011724  000002                        RTI                     ;RETURN
                                                            
011726  000000                RCVCNT: .WORD   0
011730  000000                XMTCNT: .WORD   0
011732  000000                CLKCNT: .WORD   0
011734  000000                STPSW:  .WORD   0
011736  000000                SRPSW:  .WORD   0
```

```
  2630  011740  000000                SCPSW:  .WORD   0
  2631  011742  000044                BUF:    .BLKW   44
  2632
```



```
  2633
  2634                                  ;END OF DEVICE PASS ROUTINE
  2635
  2636  012052  005037  001002          ENDEV:  CLR     $TSTNM          ;CLEAR TEST NO. COUNT FOR SCOPE ROUTINE
  2637  012056  005237  001076                  INC     $DEVCT          ;INCREMENT DEVICE COUNTER
  2638  012062  023737  002342  001076          CMP     TMP2,$DEVCT     ;ALL DEVICES TESTED
  2639  012070  001404                          BEQ     $EOP            ;BR, IF YES
  2640  012072  005037  002336                  CLR     CTSTFL          ;CLEAR CONSOLE UNDER TEST FLAG
  2641  012076  000137  003500                  JMP     TSTDEV          ;GO TEST NEXT DEVICE
  2642
  2643
  2644
  2645                                  .SBTTL  END OF PASS ROUTINE
  2646
  2647                                  ;;*****************************************************************
  2648                                  ;*INCREMENT THE PASS NUMBER ($PASS)
  2649                                  ;*IF THERES A MONITOR GO TO IT
  2650                                  ;*IF THERE ISN'T JUMP TO GOAGIN
  2651
  2652  012102                          $EOP:
  2653  012102  000004                          SCOPE
  2654  012104  005037  001002                  CLR     $TSTNM          ;;ZERO THE TEST NUMBER
  2655  012110  005237  001074                  INC     $PASS           ;;INCREMENT THE PASS NUMBER
  2656  012114  042737  100000  001074          BIC     #100000,$PASS   ;;DON'T ALLOW A NEG. NUMBER
  2657  012122  005327                          DEC     (PC)+           ;;LOOP?
  2658  012124  000001                  $EOPCT: .WORD   1
  2659  012126  003015                          BGT     $DOAGN          ;;YES
  2660  012130  012737                          MOV     (PC)+,@(PC)+    ;;RESTORE COUNTER
  2661  012132  000001                  $ENDCT: .WORD   1
  2662  012134  012124                          $EOPCT
  2663  012136  104401  012172                  TYPE    ,ENDMG          ;;TYPE "END PASS"
  2664  012142  013700  000042          $GET42: MOV     @#42,R0         ;;GET MONITOR ADDRESS
  2665  012146  001405                          BEQ     $DOAGN          ;;BRANCH IF NO MONITOR
  2666  012150  000005                          RESET                   ;;CLEAR THE WORLD
  2667  012152  004710                  $ENDAD: JSR     PC,(R0)         ;;GO TO MONITOR
  2668  012154  000240                          NOP                     ;;SAVE ROOM
  2669  012156  000240                          NOP                     ;;FOR
  2670  012160  000240                          NOP                     ;;ACT11
  2671  012162                          $DOAGN:
  2672  012162  000137                          JMP     @(PC)+          ;;RETURN
  2673  012164  012206                  $RTNAD: .WORD   GOAGIN
  2674  012166     377     377     000  $ENULL: .BYTE   -1,-1,0          ;;NULL CHARACTER STRING
  2675          012172                          .EVEN
  2676  012172  005015  047105  020104  ENDMG:  .ASCIZ  <CR><LF>/END PASS /
  2677  012200  040520  051523  000040
```

```
                                                ;CLEAR DEVICE COUNT
012206  005037  001076          GOAGIN: CLR     $DEVCT
012212  022737  000001  002342          CMP     #1,TMP2         ;IS THERE ONLY ONE DEVICE UNDER TEST?
012220  001004                          BNE     RSTRT           ;BR, IF NOT
012222  012706  001000                  MOV     #1000,SP                ;RESET STACK POINTER
012226  000137  003622                  JMP     TST1            ;GO DO ANOTHER PASS

012232  005037  001100          RSTRT:  CLR     $UNIT           ;CLEAR UNIT NUMBER
012236  000137  003424                  JMP     BEGIN

012242  011646                  WRPSW:  MOV(SP),-(SP)           ;COPY RETUN PC
012244  013616                          MOV     @(SP)+,(SP)     ;MOVE NEW PSW TO STACK
012246  062746  000002                  ADD     #2,-(SP)        ;ADJUST JSR RETURN
012252  000002                          RTI                     ;POP RETURN PC & NEW PSW

                                ;SUBROUTINE TO REPORT UNEXPECTED OR ERRONEOUS TRAPS OR INTERRUPTS

012254  012600                  CATCH:  MOV     (SP)+,R0        ;GET ADDRESS OF TRAP VECTOR + 4
012256  162700  000004                  SUB     #4,R0           ;ADJUST TO POINT TO TRAP ADDRESS
012262  010037  012302                  MOV     R0,BDVECT       ;STORE TRAP OR INTERRUPT ADDRESS
012266  016637  000002  012300          MOV     2(SP),OLDPC     ;GET PC WHERE TRAP OR INTERRUPT OCCURRED
012274  104112                          ERROR   112             ;REPORT ERROR

012276  000000                          HALT                    ;PROGRAM MUST BE RESTARTED AT THIS POINT
012300  000000                  OLDPC:  .WORD   0
012302  000000                  BDVECT: .WORD   0
```



```
                                ;;*****************************************************************
                                ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
                                ;*SAVE THE ERROR ITEM NUMBER AND ADDRESS OF THE ERROR CALL
                                ;*AND GO TO $ERRTYP ON ERROR
                                ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
                                ;*SW15=1         HALT ON ERROR
                                ;*SW13=1         INHIBIT ERROR TYPEOUTS
                                ;*SW09=1         LOOP IN ERROR
                                ;*CALL
                                ;*      ERROR   N       ;;ERROR=EMT AND N=ERROR ITEM NUMBER
                                ;;*****************************************************************

                                $ERROR:
012304                          7$:     INCB    $ERFLG          ;SET THE ERROR FLAG
012304  105237  001003                  BEQ     7$              ;DON'T LET FLAG GO TO ZERO
012310  001775                  
012312  013777  001002  166522          MOV     $TSTNM,@DISPLAY ;DISPLAY TEST NUMBER AND ERROR FLAG
012320  005237  001012                  INC     $ERTTL          ;INCREMENT ERROR COUNT
012324  011637  001016                  MOV     (SP),$ERRPC     ;GET ADDRESS OF ERROR INSTRUCTION
012330  162737  000002  001016          SUB     #2,$ERRPC
012336  117737  166454  001014          MOVB    @$ERRPC,$ITEMB  ;STRIP AND SAVE THE ERROR ITEM CODE
012344  032777  020000  166466          BIT     #BIT13,@SWR     ;SKIP TYPEOUT IF SET
012352  001004                          BNE     20$             ;SKIP TYPEOUTS
012354  004737  012466                  JSR     PC,$ERRTYP      ;GO TO USER ERROR ROUTINE
012360  104401  001063                  TYPE    ,$CRLF
012364                          20$:
012364  122737  000001  001106          CMPB    #APTENV,$ENV    ;RUNNING IN APT MODE
012372  001007                          BNE     2$              ;NO, SKIP APT ERROR REPORT
012374  113737  001014  012406          MOVB    $ITEMB,21$      ;SET ITEM NUMBER AS ERROR NUMBER
012402  004737  013170                  JSR     PC,$ATY4        ;REPORT FATAL ERROR TO APT
012406     000                  21$:    .BYTE   0
012407     000                          .BYTE   0
012410  000777                  22$:    BR      22$             ;APT ERROR LOOP
012412  005777  166422          2$:     TST     @SWR            ;HALT ON ERROR
012416  100001                          BPL     3$              ;SKIP IF CONTINUE
012420  000000                          HALT                    ;HALT ON ERROR!
012422  104406                  3$:     CKSWR                   ;TEST FOR CHANGE IN SOFT-SWR
012424  032777  001000  166406          BIT     #BIT09,@SWR     ;LOOP ON ERROR SWITCH SET?
012432  001402                          BEQ     4$              ;BR IF NO
012434  013716  001010                  MOV     $LPERR,(SP)     ;FUDGE RETURN FOR LOOPING
012440  005737  001060          4$:     TST     $ESCAPE         ;CHECK FOR AN ESCAPE ADDRESS
012444  001402                          BEQ     5$              ;BR IF NONE
012446  013716  001060                  MOV     $ESCAPE,(SP)    ;FUDGE RETURN ADDRESS FOR ESCAPE
012452                          5$:
012452  022737  012152  000042          CMP     #$ENDAD,@#42    ;ACT-11 AUTO-ACCEPT?
012460  001001                          BNE     6$              ;BR IF NO
012462  000000                          HALT                    ;YES
012464                          6$:
012464  000002                          RTI                     ;RETURN
```

```
                                        .SBTTL  ERROR MESSAGE TYPEOUT ROUTINE

                                        ;;*************************************************************
                                        ;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
                                        ;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
                                        ;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

012466                                  $ERRTYP:
012466  104401  001063                          TYPE    ,$CRLF          ;;"CARRIAGE RETURN" & "LINE FEED"
012472  010046                          1$:     MOV     R0,-(SP)        ;;SAVE R0
012474  005000                                  CLR     R0              ;;PICKUP THE ITEM INDEX
012476  153700  001014                          BISB    @#$ITEMB,R0
012502  001004                                  BNE     1$              ;;IF ITEM NUMBER IS ZERO, JUST
                                                                        ;;TYPE THE PC OF THE ERROR
012504  013746  001016                          MOV     $ERRPC,-(SP)    ;;SAVE $ERRPC FOR TYPEOUT
                                                                        ;;ERROR ADDRESS
012510  104402                                  TYPOC                   ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
012512  000426                                  BR      6$              ;;GET OUT
012514  005300                                  DEC     R0              ;;ADJUST THE INDEX SO THAT IT WILL
012516  006300                                  ASL     R0              ;;       WORK FOR THE ERROR TABLE
012520  006300                                  ASL     R0
012522  006300                                  ASL     R0
012524  062700  001146                          ADD     #$ERRTB,R0      ;;FORM TABLE POINTER
012530  012037  012540                          MOV     (R0)+,2$        ;;PICKUP "ERROR MESSAGE" POINTER
012534  001404                                  BEQ     3$              ;;SKIP T:PEOUT IF NO POINTER
012536  104401                                  TYPE                    ;;TYPE THE "ERROR MESSAGE"
012540  000000                          2$:     .WORD   0               ;;"ERROR MESSAGE" POINTER GOES HERE
012542  104401  001063                          TYPE    ,$CRLF          ;;"CARRIAGE RETURN" & "LINE FEED"
012546  012037  012556                  3$:     MOV     (R0)+,4$        ;;PICKUP 'DATA HEADER" POINTER
012552  001404                                  BEQ     5$              ;;SKIP TYPEOUT IF 0
012554  104401                                  TYPE                    ;;TYPE THE "DATA HEADER"
012556  000000                          4$:     .WORD   0               ;;"DATA HEADER" POINTER GOES HERE
012560  104401  001063                          TYPE    ,$CRLF          ;;"CARRIAGE RETURN" & "LINE FEED"
012564  011000                          5$:     MOV     (R0),R0         ;;PICKUP "DATA TABLE" POINTER
012566  001004                                  BNE     7$              ;;GO TYPE THE DATA
012570  012600                          6$:     MOV     (SP)+,R0        ;;RESTORE R0
012572  104401  001063                          TYPE    ,$CRLF          ;;"CARRIAGE RETURN" & "LINE FEED"
012576  000207                                  RTS     PC              ;;RETURN
012600                                  7$:
012600  013046                                  MOV     @(R0)+,-(SP)    ;;SAVE @(R0)+ FOR TYPEOUT
012602  104402                                  TYPOC                   ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
012604  005710                                  TST     (R0)            ;;IS THERE ANOTHER NUMBER?
012606  001770                                  BEQ     6$              ;;BR IF NO
012610  104401  012616                          TYPE    ,8$             ;;TYPE TWO(2) SPACES
012614  000771                                  BR      7$              ;;LOOP
012616  020040     000                  8$:     .ASCIZ  /  /            ;;TWO(2) SPACES
        012622                                  .EVEN
```



```
                                        .SBTTL  POWER DOWN AND UP ROUTINES
                                        ;;*************************************************************
                                                ;*POWER DOWN ROUTINE
                                        ;;*************************************************************
012622  012737  012762  000024  $PWRDN: MOV     #$ILLUP,@#PWRVEC ;SET FOR FAST UP
012630  012737  000340  000026          MOV     #340,@#PWRVEC+2 ;PRIO:7
012636  010046                          MOV     R0,-(SP)        ;PUSH R0 ON STACK
012640  010146                          MOV     R1,-(SP)        ;PUSH R1 ON STACK
012642  010246                          MOV     R2,-(SP)        ;PUSH R2 ON STACK
012644  010346                          MOV     R3,-(SP)        ;PUSH R3 ON STACK
012646  010446                          MOV     R4,-(SP)        ;PUSH R4 ON STACK
012650  010546                          MOV     R5,-(SP)        ;PUSH R5 ON STACK
012652  017746  166162                  MOV     @SWR,-(SP)      ;PUSH @SWR ON STACK
012656  010637  012766                  MOV     SP,$SAVR6       ;SAVE SP
012662  012737  012674  000024          MOV     #$PWRUP,@#PWRVEC ;SET UP VECTOR
012670  000000                          HALT
012672  000776                          BR      .-2             ;HANG UP


                                        ;;*************************************************************
                                                ;*POWER UP ROUTINE
                                        ;;*************************************************************
012674  012737  012762  000024  $PWRUP: MOV     #$ILLUP,@#PWRVEC ;SET FOR FAST DOWN
012702  013706  012766                  MOV     $SAVR6,SP       ;GET SP
012706  012677  166126                  MOV     (SP)+,@SWR      ;POP STACK INTO @SWR
012712  012605                          MOV     (SP)+,R5
012714  012604                          MOV     (SP)+,R4        ;POP STACK INTO R4
012716  012603                          MOV     (SP)+,R3        ;POP STACK INTO R3
012720  012602                          MOV     (SP)+,R2        ;POP STACK INTO R2
012722  012601                          MOV     (SP)+,R1        ;POP STACK INTO R1
012724  012600                          MOV     (SP)+,R0        ;POP STACK INTO R0
012726  012737  012622  000024          MOV     #$PWRDN,@#PWRVEC ;SET UP THE POWER DOWN VECTOR
012734  012737  000340  000026          MOV     #340,@#PWRVEC+2 ;PRIO:7
012742  005037  012766                  CLR     $SAVR6          ;WAIT LOOP FOR THE TTY
012746  005237  012766          1$:     INC     $SAVR6          ;WAIT FOR THE INC
012752  001375                          BNE     1$              ;OF WORD
012754  104401                          TYPE                    ;REPORT THE POWER FAILURE
012756  012770                  $PWRMG: .WORD   $POWER          ;POWER FAIL MESSAGE POINTER
012760  000002                          RTI
012762  000000                  $ILLUP: HALT                    ;THE POWER UP SEQUENCE WAS STARTED
012764  000776                          BR      .-2             ; BEFORE THE POWER DOWN WAS COMPLETE
012766  000000                  $SAVR6: 0                       ;PUT THE SP HERE
012770  005015  047520  042527  $POWER: .ASCIZ  <15><12>"POWER"
012776  000122
```

```
                                        .SBTTL  SCOPE HANDLER ROUTINE

                                        ;;*****************************************************************
                                        ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
                                        ;*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
                                        ;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
                                        ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
                                        ;*SW14=1         LOOP ON TEST
                                        ;*SW09=1         LOOP ON ERROR
                                        ;*CALL
                                        ;*      SCOPE           ;;SCOPE=IOT

013000                                  $SCOPE:
013000  104406                                 CKSWR                   ;;TEST  FOR CHANGE IN SOFT-SWR
013002  032777  040000  166030          1$:     BIT     #BIT14,@SWR     ;;LOOP ON PRESENT TEST?
013010  001052                                 BNE     $OVER           ;;YES IF SW14=1
                                        ;#####START OF CODE FOR THE XOR TESTER#####
013012  000416                          $XTSTR: BR      6$              ;;IF RUNNING ON THE "XOR" TESTER CHANGE
                                                                        ;;THIS INSTRUCTION TO A "NOP" (NOP=240)
013014  013746  000004                          MOV     @#ERRVEC,-(SP)  ;;SAVE THE CONTENTS OF THE ERROR VECTOR
013020  012737  013040  000004                  MOV     #5$,@#ERRVEC    ;;SET FOR TIMEOUT
013026  005737  177060                          TST     @#177060        ;;TIME OUT ON XOR?
013032  012637  000004                          MOV     (SP)+,@#ERRVEC  ;;RESTORE THE ERROR VECTOR
013036  000421                                  BR      $SVLAD          ;;GO TO THE NEXT TEST
013040  022626                          5$:     CMP     (SP)+,(SP)+     ;;CLEAR THE STACK AFTER A TIME OUT
013042  012637  000004                          MOV     (SP)+,@#ERRVEC  ;;RESTORE THE ERROR VECTOR
013046  000407                                  BR      7$              ;;LOOP ON THE PRESENT TEST
013050                                  6$:;#####END OF CODE FOR THE XOR TESTER#####
013050  105737  001003                  2$:     TSTB    $ERFLG          ;;HAS AN ERROR OCCURRED?
013054  001412                                  BEQ     $SVLAD          ;;BR IF NO
013056  032777  001000  165754                  BIT     #BIT09,@SWR     ;;LOOP ON ERROR?
013064  001404                                  BEQ     4$              ;;BR IF NO
013066  013737  001010  001006          7$:     MOV     $LPERR,$LPADR   ;;SET LOOP ADDRESS TO LAST SCOPE
013074  000420                                  BR      $OVER
013076  105037  001003                  4$:     CLRB    $ERFLG          ;;ZERO THE ERROR FLAG
013102  105237  001002                  $SVLAD: INCB    $TSTNM          ;;COUNT TEST NUMBERS
013106  113737  001002  001072                  MOVB    $TSTNM,$TESTN   ;;SET TEST NUMBER IN APT MAILBOX
013114  011637  001006                          MOV     (SP),$LPADR     ;;SAVE SCOPE LOOP ADDRESS
013120  011637  001010                          MOV     (SP),$LPERR     ;;SAVE ERROR LOOP ADDRESS
013124  005037  001060                          CLR     $ESCAPE         ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
013130  112737  000001  001015                  MOVB    #1,$ERMAX       ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
013136  013777  001002  165676          $OVER:  MOV     $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER
013144  013716  001006                          MOV     $LPADR,(SP)     ;;FUDGE RETURN ADDRESS
013150  000002                                  RTI                     ;;FIXES PS
```



```
                                        ;;*****************************************************************
                                        .SBTTL  APT COMMUNICATIONS ROUTINE
                                        ;;*****************************************************************

013152  112737  000001  013416  $ATY1:  MOVB    #1,$FFLG        ;TO REPORT FATAL ERROR
013160  112737  000001  013414  $ATY3:  MOVB    #1,$MFLG        ;TO TYPE A MESSAGE
013166  000403                          BR      $ATYC
013170  112737  000001  013416  $ATY4:  MOVB    #1,$FFLG        ;TO ONLY REPORT FATAL ERROR
013176                          $ATYC:
013176  010046                          MOV     R0,-(SP)        ;PUSH R0 ON STACK
013200  010146                          MOV     R1,-(SP)        ;PUSH R1 ON STACK
013202  105737  013414                  TSTB    $MFLG           ;SHOULD TYPE A MESSAGE?
013206  001450                          BEQ     5$              ;IF NOT: BR
013210  122737  000001  001106          CMPB    #APTENV,$ENV    ;OPERATING UNDER APT?
013216  001031                          BNE     3$              ;IF NOT: BR
013220  132737  000100  001107          BITB    #APTSPOOL,$ENVM ;SHOULD SPOOL MESSAGE?
013226  001425                          BEQ     3$              ;IF NOT: BR
013230  017600  000004                  MOV     @4(SP),R0       ;GET MESSAGE ADDRESS
013234  062766  000002  000004          ADD     #2,4(SP)        ;BUMP RETURN ADDRESS
013242  005737  001066          1$:     TST     $MSGTYPE                ;SEE IF DONE W/ LAST XMISSION?
013246  001375                          BNE     1$              ;IF NOT: WAIT
013250  010037  001102                  MOV     R0,$MSGAD       ;PUT ADDRESS IN MAILBOX
013254  105720                  2$:     TSTB    (R0)+           ;FIND END OF MESSAGE
013256  001376                          BNE     2$
013260  163700  001102                  SUB     $MSGAD,R0       ;SUB START OF MESSAGE
013264  006200                          ASR     R0              ;GET MESSAGE LENGTH IN WORDS
013266  010037  001104                  MOV     R0,$MSGLGT      ;PUT LENGTH IN MAILBOX
013272  012737  000004  001066          MOV     #4,$MSGTYPE     ;TELL APT TO TAKE MESSAGE
013300  000413                          BR      5$
013302  017637  000004  013326  3$:     MOV     @4(SP),4$       ;PUT MSG ADDR IN JSR LINKAGE
013310  062766  000002  000004          ADD     #2,4(SP)        ;BUMP RETURN ADDRESS
013316  013746  177776                  MOV     177776,-(SP)    ;PUSH 177776 ON STACK
013322  004737  013420                  JSR     PC,$TYPE        ;CALL TYPE MACRO
013326  000000                  4$:     .WORD   0
013330                          5$:
013330  105737  013416          10$:    TSTB    $FFLG           ;SHOULD REPORT FATAL ERROR?
013334  001413                          BEQ     12$             ;IF NOT: BR
013336  005737  001106                  TST     $ENV            ;RUNNING UNDER APT?
013342  001410                          BEQ     12$             ;IF NOT: BR
013344  005737  001066          11$:    TST     $MSGTYPE        ;FINISHED LAST MESSAGE?
013350  001375                          BNE     11$             ;IF NOT: WAIT
013352  017637  000004  001070          MOV     @4(SP),$FATAL   ;GET ERROR #
013360  005237  001066                  INC     $MSGTYPE        ;TELL APT TO TAKE ERROR
013364  062766  000002  000004  12$:    ADD     #2,4(SP)        ;BUMP RETURN ADDRESS
013372  105037  013416                  CLRB    $FFLG           ;CLEAR FATAL FLAG
013376  105037  013415                  CLRB    $LFLG           ;CLEAR LOG FLAG
013402  105037  013414                  CLRB    $MFLG           ;CLEAR MESSAGE FLAG
013406  012601                          MOV     (SP)+,R1        ;POP STACK INTO R1
013410  012600                          MOV     (SP)+,R0        ;POP STACK INTO R1
013412  000207                          RTS     PC              ;RETURN
013414     000                  $MFLG:  .BYTE   0
013415     000                  $LFLG:  .BYTE   0               ;LOG FLAG
013416     000                  $FFLG:  .BYTE   0               ;FATAL FLAG

          013420                        .EVEN
```

```
 2952          000200                  APTSIZE=200
 2953          000001                  APTENV=001
 2954          000100                  APTSPOOL=100
 2955          000040                  APTCSUP=040
 2956
```



```
 2957
 2958                                  .SBTTL  TYPE ROUTINE
 2959
 2960                                  ;;*****************************************************************
 2961                                  ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
 2962                                  ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
 2963                                  ;*NOTE1:        $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
 2964                                  ;*NOTE2:        $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
 2965                                  ;*NOTE3:        $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
 2966                                  ;*
 2967                                  ;*CALL:
 2968                                  ;*1) USING A TRAP INSTRUCTION
 2969                                  ;*      TYPE    ,MESADR         ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
 2970                                  ;*OR
 2971                                  ;*      TYPE
 2972                                  ;*      MESADR
 2973                                  ;*
 2974
 2975  013420  105737  001057          $TYPE:  TSTB    $TPFLG          ;;IS THERE A TERMINAL?
 2976  013424  100002                          BPL     1$              ;;BR IF YES
 2977  013426  000000                          HALT                    ;;HALT HERE IF NO TERMINAL
 2978  013430  000430                          BR      3$              ;;LEAVE
 2979  013432  010046                  1$:     MOV     R0,-(SP)        ;;SAVE R0
 2980  013434  017600  000002                  MOV     @2(SP),R0       ;;GET ADDRESS OF ASCIZ STRING
 2981  013440  122737  000001  001106          CMPB    #APTENV,$ENV    ;;RUNNING IN APT MODE
 2982  013446  001011                          BNE     62$             ;;NO,GO CHECK FOR APT CONSOLE
 2983  013450  132737  000100  001107          BITB    #APTSPOOL,$ENVM ;;SPOOL MESSAGE TO APT
 2984  013456  001405                          BEQ     62$             ;;NO,GO CHECK FOR CONSOLE
 2985  013460  010037  013470                  MOV     R0,61$          ;;SETUP MESSAGE ADDRESS FOR APT
 2986  013464  004737  013160                  JSR     PC,$ATY3        ;;SPOOL MESSAGE TO APT
 2987  013470  000000                  61$:    .WORD   0               ;;MESSAGE ADDRESS
 2988  013472  132737  000040  001107  62$:    BITB    #APTCSUP,$ENVM  ;;APT CONSOLE SUPPRESSED
 2989  013500  001003                          BNE     60$             ;;YES,SKIP TYPE OUT
 2990  013502  112046                  2$:     MOVB    (R0)+,-(SP)     ;;PUSH CHARACTER TO BE TYPED ONTO STACK
 2991  013504  001005                          BNE     4$              ;;BR IF IT ISN'T THE TERMINATOR
 2992  013506  005726                          TST     (SP)+           ;;IF TERMINATOR POP IT OFF THE STACK
 2993  013510  012600                  60$:    MOV     (SP)+,R0        ;;RESTORE R0
 2994  013512  062716  000002          3$:     ADD     #2,(SP)         ;;ADJUST RETURN PC
 2995  013516  000002                          RTI                     ;;RETURN
 2996  013520  122716  000011          4$:     CMPB    #HT',(SP)       ;;BRANCH IF <HT>
 2997  013524  001430                          BEQ     8$
 2998  013526  122716  000200                  CMPB    #CRLF,(SP)      ;;BRANCH IF NOT <CRLF>
 2999  013532  001006                          BNE     5$
 3000  013534  005726                          TST     (SP)+           ;;POP  <CR><LF> EQUIV
 3001  013536  104401                          TYPE                    ;;TYPE A CR AND LF
 3002  013540  001063                          $CRLF
 3003  013542  105037  013676                  CLRB    $CHARCNT        ;;CLEAR CHARACTER COUNT
 3004  013546  000755                          BR      2$              ;;GET NEXT CHARACTER
 3005  013550  004737  013632          5$:     JSR     PC,$TYPEC       ;;GO TYPE THIS CHARACTER
 3006  013554  123726  001056          6$:     CMPB    $FILLC,(SP)+    ;;IS IT TIME FOR FILLER CHARS.?
 3007  013560  001350                          BNE     2$              ;;IF NO GO GET NEXT CHAR.
 3008  013562  013746  001054                  MOV     $NULL,-(SP)     ;;GET # OF FILLER CHARS. NEEDED
 3009                                                                  ;;AND THE NULL CHAR.
 3010  013566  105366  000001          7$:     DECB    1(SP)           ;;DOES A NULL NEED TO BE TYPED?
 3011  013572  002770                          BLT     6$              ;;BR IF NO--GO POP THE NULL OFF OF STACK
 3012  013574  004737  013632                  JSR     PC,$TYPEC       ;;GO TYPE A NULL
```

```
3013  013600  105337  013676                  DECB    $CHARCNT        ;;DO NOT COUNT AS A COUNT
3014  013604  000770                          BR      7$              ;;LOOP
3015
3016                                          ;HORIZONTAL TAB PROCESSOR
3017
3018  013606  112716  000040                  8$:     MOVB    #' ,(SP)        ;;REPLACE TAB WITH SPACE
3019  013612  004737  013632                  9$:     JSR     PC,$TYPEC       ;;TYPE A SPACE
3020  013616  132737  000007  013676                  BITB    #7,$CHARCNT     ;;BRANCH IF NOT AT
3021  013624  001372                                  BNE     9$              ;;TAB STOP
3022  013626  005726                                  TST     (SP)+           ;;POP SPACE OFF STACK
3023  013630  000724                                  BR      2$              ;;GET NEXT CHARACTER
3024  013632  105777  165212                  $TYPEC: TSTB    @$TPS           ;;WAIT UNTIL PRINTER IS READY
3025  013636  100375                                  BPL     $TYPEC
3026  013640  116677  000002  165204                  MOVB    2(SP),@$TPB     ;;LOAD CHAR TO BE TYPED INTO DATA REG.
3027  013646  122766  000015  000002                  CMPB    #CR,2(SP)       ;;IS CHARACTER A CARRIAGE RETURN?
3028  013654  001003                                  BNE     1$              ;;BRANCH IF NO
3029  013656  105037  013676                          CLRB    $CHARCNT        ;;YES--CLEAR CHARACTER COUNT
3030  013662  000406                                  BR      $TYPEX          ;;EXIT
3031  013664  122766  000012  000002          1$:     CMPB    #LF,2(SP)       ;;IS CHARACTER A LINE FEED?
3032  013672  001402                                  BEQ     $TYPEX          ;;BRANCH IF YES
3033  013674  105227                                  INCB    (PC)+           ;;COUNT THE CHARACTER
3034  013676  000000                  $CHARCNT:.WORD  0               ;;CHARACTER COUNT STORAGE
3035  013700  000207                  $TYPEX: RTS     PC
3036
3037                                          .SBTTL  BINARY TO OCTAL (ASCII) AND TYPE
3038
3039                                          ;;*************************************************************
3040                                          ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
3041                                          ;*OCTAL (ASCII) NUMBER AND TYPE IT.
3042                                          ;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
3043                                          ;*CALL:
3044                                          ;*      MOV     NUM,-(SP)       ;;NUMBER TO BE TYPED
3045                                          ;*      TYPOS                   ;;CALL FOR TYPEOUT
3046                                          ;*      .BYTE   N               ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
3047                                          ;*      .BYTE   M               ;;M=1 OR 0
3048                                          ;*                                      ;;1=TYPE LEADING ZEROS
3049                                          ;*                                      ;;0=SUPPRESS LEADING ZEROS
3050                                          ;*
3051                                          ;*$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
3052                                          ;*$TYPOS OR $TYPOC
3053                                          ;*CALL:
3054                                          ;*      MOV     NUM,-(SP)       ;;NUMBER TO BE TYPED
3055                                          ;*      TYPON                   ;;CALL FOR TYPEOUT
3056                                          ;*
3057                                          ;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
3058                                          ;*CALL:
3059                                          ;*      MOV     NUM,-(SP)       ;;NUMBER TO BE TYPED
3060                                          ;*      TYPOC                   ;;CALL FOR TYPEOUT
3061
3062  013702  017646  000000          $TYPOS: MOV     @(SP),-(SP)     ;;PICKUP THE MODE
3063  013706  116637  000001  014125          MOVB    1(SP),$OFILL    ;;LOAD ZERO FILL SWITCH
3064  013714  112637  014127                  MOVB    (SP)+,$OMODE+1  ;;NUMBER OF DIGITS TO TYPE
3065  013720  062716  000002                  ADD     #2,(SP)         ;;ADJUST RETURN ADDRESS
3066  013724  000406                          BR      $TYPON
3067  013726  112737  000001  014125  $TYPOC: MOVB    #1,$OFILL       ;;SET THE ZERO FILL SWITCH
3068  013734  112737  000006  014127          MOVB    #6,$OMODE+1     ;;SET FOR SIX(6) DIGITS
```



```
3069  013742  112737  000005  014124  $TYPON: MOVB    #5,$OCNT        ;;SET THE ITERATION COUNT
3070  013750  010346                          MOV     R3,-(SP)        ;;SAVE R3
3071  013752  010446                          MOV     R4,-(SP)        ;;SAVE R4
3072  013754  010546                          MOV     R5,-(SP)        ;;SAVE R5
3073  013756  113704  014127                  MOVB    $OMODE+1,R4     ;;GET THE NUMBER OF DIGITS TO TYPE
3074  013762  005404                          NEG     R4
3075  013764  062704  000006                  ADD     #6,R4           ;;SUBTRACT IT FOR MAX. ALLOWED
3076  013770  110437  014126                  MOVB    R4,$OMODE       ;;SAVE IT FOR USE
3077  013774  113704  014125                  MOVB    $OFILL,R4       ;;GET THE ZERO FILL SWITCH
3078  014000  016605  000012                  MOV     12(SP),R5       ;;PICKUP THE INPUT NUMBER
3079  014004  005003                          CLR     R3              ;;CLEAR THE OUTPUT WORD
3080  014006  006105                  1$:     ROL     R5              ;;ROTATE MSB INTO "C"
3081  014010  000404                          BR      3$              ;;GO DO MSB
3082  014012  006105                  2$:     ROL     R5              ;;FORM THIS DIGIT
3083  014014  006105                          ROL     R5
3084  014016  006105                          ROL     R5
3085  014020  010503                          MOV     R5,R3
3086  014022  006103                  3$:     ROL     R3              ;;GET LSB OF THIS DIGIT
3087  014024  105337  014126                  DECB    $OMODE          ;;TYPE THIS DIGIT?
3088  014030  100016                          BPL     7$              ;;BR IF NO
3089  014032  042703  177770                  BIC     #177770,R3      ;;GET RID OF JUNK
3090  014036  001002                          BNE     4$              ;;TEST FOR 0
3091  014040  005704                          TST     R4              ;;SUPPRESS THIS 0?
3092  014042  001403                          BEQ     5$              ;;BR IF YES
3093  014044  005204                  4$:     INC     R4              ;;DON'T SUPPRESS ANYMORE 0'S
3094  014046  052703  000060                  BIS     #'0,R3          ;;MAKE THIS DIGIT ASCII
3095  014052  052703  000040          5$:     BIS     #' ,R3          ;;MAKE ASCII IF NOT ALREADY
3096  014056  110337  014122                  MOVB    R3,8$           ;;SAVE FOR TYPING
3097  014062  104401  014122                  TYPE    ,8$             ;;GO TYPE THIS DIGIT
3098  014066  105337  014124          7$:     DECB    $OCNT           ;;COUNT BY 1
3099  014072  003347                          BGT     2$              ;;BR IF MORE TO DO
3100  014074  002402                          BLT     6$              ;;BR IF DONE
3101  014076  005204                          INC     R4              ;;INSURE LAST DIGIT ISN'T A BLANK
3102  014100  000744                          BR      2$              ;;GO DO THE LAST DIGIT
3103  014102  012605                  6$:     MOV     (SP)+,R5        ;;RESTORE R5
3104  014104  012604                          MOV     (SP)+,R4        ;;RESTORE R4
3105  014106  012603                          MOV     (SP)+,R3        ;;RESTORE R3
3106  014110  016666  000002  000004          MOV     2(SP),4(SP)     ;;SET THE STACK FOR RETURNING
3107  014116  012616                          MOV     (SP)+,(SP)
3108  014120  000002                          RTI                     ;;RETURN
3109  014122     000                  8$:     .BYTE   0               ;;STORAGE FOR ASCII DIGIT
3110  014123     000                          .BYTE   0               ;;TERMINATOR FOR TYPE ROUTINE
3111  014124     000                  $OCNT:  .BYTE   0               ;;OCTAL DIGIT COUNTER
3112  014125     000                  $OFILL: .BYTE   0               ;;ZERO FILL SWITCH
3113  014126  000000                  $OMODE: .WORD   0               ;;NUMBER OF DIGITS TO TYPE
3114
```

```
                                        .SBTTL  TTY INPUT ROUTINE
                                        ;;*****************************************************************
                                        .ENABL  LSB
                                        ;;*****************************************************************
                                        ;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
                                        ;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
                                        ;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
                                        ;*WHEN OPERATING IN TTY FLAG MODE.
014130  022737  000176  001040  $CKSWR: CMP     #SWREG,SWR      ;;IS THE SOFT-SWR SELECTED?
014136  001074                        BNE     15$             ;;BRANCH IF NO
014140  105777  164700                TSTB    @$TKS           ;;CHAR THERE?
014144  100071                        BPL     15$             ;;IF NO, DON'T WAIT AROUND
014146  117746  164674                MOVB    @$TKB,-(SP)     ;;SAVE THE CHAR
014152  042716  177600                BIC     #^C177,(SP)     ;;STRIP-OFF THE ASCII
014156  022726  000007                CMP     #7,(SP)+        ;;IS IT A CONTROL G?
014162  001062                        BNE     15$             ;;NO, RETURN TO USER
014164  123727  001034  000001        CMPB    $AUTOB,#1       ;;ARE WE RUNNING IN AUTO-MODE?
014172  001456                        BEQ     15$             ;;BRANCH IF YES

014174  104401  014655                TYPE    ,$CNTLG         ;;ECHO THE CONTROL-G (^G)
014200  104401  014662        $GTSWR: TYPE    ,$MSWR          ;;TYPE CURRENT CONTENTS
014204  013746  000176                MOV     SWREG,-(SP)     ;;SAVE SWREG FOR TYPEOUT
014210  104402                        TYPOC                   ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
014212  104401  014673                TYPE    ,$MNEW          ;;PROMPT FOR NEW SWR
014216  005046                19$:    CLR     -(SP)           ;;CLEAR COUNTER
014220  005046                        CLR     -(SP)           ;;THE NEW SWR
014222  105777  164616          7$:   TSTB    @$TKS           ;;CHAR THERE?
014226  100375                        BPL     7$              ;;IF NOT TRY AGAIN

014230  117746  164612                MOVB    @$TKB,-(SP)     ;;PICK UP CHAR
014234  042716  177600                BIC     #^C177,(SP)     ;;MAKE IT 7-BIT ASCII


014240  021627  000025          9$:   CMP     (SP),#25        ;;IS IT A CONTROL-U?
014244  001005                        BNE     10$             ;;BRANCH IF NOT
014246  104401  014650                TYPE    ,$CNTLU         ;;YES, ECHO CONTROL-U (^U)
014252  062706  000006          20$:  ADD     #6,SP           ;;IGNORE PREVIOUS INPUT
014256  000757                        BR      19$             ;;LET'S TRY IT AGAIN


014260  021627  000015          10$:  CMP     (SP),#15        ;;IS IT A <CR>?
014264  001022                        BNE     16$             ;;BRANCH IF NO
014266  005766  000004                TST     4(SP)           ;;YES, IS IT THE FIRST CHAR?
014272  001403                        BEQ     11$             ;;BRANCH IF YES
014274  016677  000002  164536        MOV     2(SP),@SWR      ;;SAVE NEW SWR
014302  062706  000006          11$:  ADD     #6,SP           ;;CLEAR UP STACK
014306  104401  001063          14$:  TYPE    ,$CRLF          ;;ECHO <CR> AND <LF>
014312  123727  001035  000001        CMPB    $INTAG,#1       ;;RE-ENABLE TTY KBD INTERRUPTS?
014320  001003                        BNE     15$             ;;BRANCH IF NOT
014322  012777  000100  164514        MOV     #100,@$TKS      ;;RE-ENABLE TTY KBD INTERRUPTS
014330  000002                15$:    RTI                     ;;RETURN
014332  004737  013632          16$:  JSR     PC,$TYPEC       ;;ECHO CHAR
```



```
014336  021627  000060                CMP     (SP),#60        ;;CHAR < 0?
014342  002420                        BLT     18$             ;;BRANCH IF YES
014344  021627  000067                CMP     (SP),#67        ;;CHAR > 7?
014350  003015                        BGT     18$             ;;BRANCH IF YES
014352  042726  000060                BIC     #60,(SP)+       ;;STRIP-OFF ASCII
014356  005766  000002                TST     2(SP)           ;;IS THIS THE FIRST CHAR
014362  001403                        BEQ     17$             ;;BRANCH IF YES
014364  006316                        ASL     (SP)            ;;NO, SHIFT PRESENT
014366  006316                        ASL     (SP)            ;;   CHAR OVER TO MAKE
014370  006316                        ASL     (SP)            ;;   ROOM FOR NEW ONE.
014372  005266  000002          17$:  INC     2(SP)           ;;KEEP COUNT OF CHAR
014376  056616  177776                BIS     -2(SP),(SP)     ;;SET IN NEW CHAR
014402  000707                        BR      7$              ;;GET THE NEXT ONE
014404  104401  001062          18$:  TYPE    ,$QUES          ;;TYPE ?<CR><LF>
014410  000720                        BR      20$             ;;SIMULATE CONTROL-U
                                .DSABL  LSB


                                        ;;*****************************************************************
                                        ;*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
                                        ;*CALL:
                                        ;*      RDCHR                   ;;INPUT A SINGLE CHARACTER FROM THE TTY
                                        ;*      RETURN HERE             ;;CHARACTER IS ON THE STACK
                                        ;*                              ;;WITH PARITY BIT STRIPPED OFF
                                        ;

014412  011646                $RDCHR: MOV     (SP),-(SP)      ;;PUSH DOWN THE PC
014414  016666  000004  000002        MOV     4(SP),2(SP)     ;;SAVE THE PS
014422  105777  164416          1$:   TSTB    @$TKS           ;;WAIT FOR
014426  100375                        BPL     1$              ;;A CHARACTER
014430  117766  164412  000004        MOVB    @$TKB,4(SP)     ;;READ THE TTY
014436  042766  177600  000004        BIC     #^C<177>,4(SP)  ;;GET RID OF JUNK IF ANY
014444  026627  000004  000023        CMP     4(SP),#23       ;;IS IT A CONTROL-S?
014452  001013                        BNE     3$              ;;BRANCH IF NO
014454  105777  164364          2$:   TSTB    @$TKS           ;;WAIT FOR A CHARACTER
014460  100375                        BPL     2$              ;;LOOP UNTIL ITS THERE
014462  117746  164360                MOVB    @$TKB,-(SP)     ;;GET CHARACTER
014466  042716  177600                BIC     #^C177,(SP)     ;;MAKE IT 7-BIT ASCII
014472  022627  000021                CMP     (SP)+,#21       ;;IS IT A CONTROL-Q?
014476  001366                        BNE     2$              ;;IF NOT DISCARD IT
014500  000750                        BR      1$              ;;YES, RESUME
014502  026627  000004  000140  3$:   CMP     4(SP),#140      ;;IS IT UPPER CASE?
014510  002407                        BLT     4$              ;;BRANCH IF YES
014512  026627  000004  000175        CMP     4(SP),#175      ;;IS IT A SPECIAL CHAR?
014520  003003                        BGT     4$              ;;BRANCH IF YES
014522  042766  000040  000004        BIC     #40,4(SP)       ;;MAKE IT UPPER CASE
014530  000002                4$:     RTI                     ;;GO BACK TO USER
                                        ;;*****************************************************************
                                        ;*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
                                        ;*CALL:
                                        ;*      RDLIN                   ;;INPUT A STRING FROM THE TTY
                                        ;*      RETURN HERE             ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
                                        ;*                              ;;TERMINATOR WILL BE A BYTE OF ALL 0'S

014532  010346                $RDLIN: MOV     R3,-(SP)        ;;SAVE R3
014534  012703  014640          1$:   MOV     #$TTYIN,R3      ;;GET ADDRESS
```

```
 3227  014540  022703  014650          2$:     CMP     #$TTYIN+8.,R3   ;;BUFFER FULL?
 3228  014544  101405                          BLOS    4$              ;;BR IF YES
 3229  014546  104407                          RDCHR                   ;;GO READ ONE CHARACTER FROM THE TTY
 3230  014550  112613                          MOVB    (SP)+,(R3)      ;;GET CHARACTER
 3231  014552  122713  000177          10$:    CMPB    #177,(R3)       ;;IS IT A RUBOUT
 3232  014556  001003                          BNE     3$              ;;SKIP IF NOT
 3233  014560  104401  001062          4$:     TYPE    ,$QUES          ;;TYPE A '?'
 3234  014564  000763                          BR      1$              ;;CLEAR THE BUFFER AND LOOP
 3235  014566  111337  014636          3$:     MOVB    (R3),9$         ;;ECHO THE CHARACTER
 3236  014572  104401  014636                  TYPE    ,9$
 3237  014576  122723  000015                  CMPB    #15,(R3)+       ;;CHECK FOR RETURN
 3238  014602  001356                          BNE     2$              ;;LOOP IF NOT RETURN
 3239  014604  105063  177777                  CLRB    -1(R3)          ;;CLEAR RETURN (THE 15)
 3240  014610  104401  001064                  TYPE    ,$LF            ;;TYPE A LINE FEED
 3241  014614  012603                          MOV     (SP)+,R3        ;;RESTORE R3
 3242  014616  011646                          MOV     (SP),-(SP)      ;;ADJUST THE STACK AND PUT ADDRESS OF THE
 3243  014620  016666  000004  000002          MOV     4(SP),2(SP)     ;;      FIRST ASCII CHARACTER ON IT
 3244  014626  012766  014640  000004          MOV     #$TTYIN,4(SP)
 3245  014634  000002                          RTI                     ;;RETURN
 3246  014636     000                  9$:     .BYTE   0               ;;STORAGE FOR ASCII CHAR. TO TYPE
 3247  014637     000                          .BYTE   0               ;;TERMINATOR
 3248  014640  000010                  $TTYIN: .BLKB   8.              ;;RESERVE 8 BYTES FOR TTY INPUT
 3249  014650  052536  005015     000  $CNTLU: .ASCIZ  /^U/<15><12>    ;;CONTROL "U"
 3250  014655     136  006507  000012  $CNTLG: .ASCIZ  /^G/<15><12>    ;;CONTROL "G"
 3251  014662  005015  053523  020122  $MSWR:  .ASCIZ  <15><12>/SWR = /
 3252  014670  020075     000
 3253  014673     040  047040  053505  $MNEW:  .ASCIZ  /  NEW = /
 3254  014700  036440  000040
 3255
```



```
 3256
 3257
 3258                                  .SBTTL  TRAP DECODER
 3259
 3260                                  ;;*****************************************************************
 3261                                  ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
 3262                                  ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
 3263                                  ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
 3264                                  ;*GO TO THAT ROUTINE.
 3265
 3266  014704  010046                  $TRAP:  MOV     R0,-(SP)        ;;SAVE R0
 3267  014706  016600  000002                  MOV     2(SP),R0        ;;GET TRAP ADDRESS
 3268  014712  005740                          TST     -(R0)           ;;BACKUP BY 2
 3269  014714  111000                          MOVB    (R0),R0         ;;GET RIGHT BYTE OF TRAP
 3270  014716  006300                          ASL     R0              ;;POSITION FOR INDEXING
 3271  014720  016000  014740                  MOV     $TRPAD(R0),R0   ;;INDEX TO TABLE
 3272  014724  000200                          RTS     R0              ;;GO TO ROUTINE
 3273
 3274
 3275                                  ;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
 3276
 3277  014726  011646                  $TRAP2: MOV     (SP),-(SP)      ;;MOVE THE PC DOWN
 3278  014730  016666  000004  000002          MOV     4(SP),2(SP)     ;;MOVE THE PSW DOWN
 3279  014736  000002                          RTI                     ;;RESTORE THE PSW
 3280
 3281                                  .SBTTL  TRAP TABLE
 3282
 3283                                  ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
 3284                                  ;*BY THE "TRAP" INSTRUCTION.
 3285
 3286                                  ;       ROUTINE
 3287                                  ;       -------
 3288  014740  014726                  $TRPAD: .WORD   $TRAP2
 3289  014742  013420                          $TYPE   ;;CALL=TYPE     TRAP+1(104401)  TTY TYPEOUT ROUTINE
 3290  014744  013726                          $TYPOC  ;;CALL=TYPOC    TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
 3291  014746  013702                          $TYPOS  ;;CALL=TYPOS    TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
 3292  014750  013742                          $TYPON  ;;CALL=TYPON    TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
 3293
 3294  014752  014200                          $GTSWR  ;;CALL=GTSWR    TRAP+5(104405)  GET SOFT-SWR SETTING
 3295
 3296  014754  014130                          $CKSWR  ;;CALL=CKSWR    TRAP+6(104406)  TEST FOR CHANGE IN SOFT-SWR
 3297  014756  014412                          $RDCHR  ;;CALL=RDCHR    TRAP+7(104407)  TTY TYPEIN CHARACTER ROUTINE
 3298  014760  014532                          $RDLIN  ;;CALL=RDLIN    TRAP+10(104410) TTY TYPEIN STRING ROUTINE
 3299
```

```
                                        .SBTTL  ECHO TEST
                                ;;**************************************************************
                                        ;*THIS ROUTINE WILL ECHO ANY CHARACTER TYPED
                                        ;*AT THE CONSOLE
                                        ;*THE TEST IS HALTED BY TYPING A CONTROL-C
                                        ;*TEST CAN BE RESTARTED AFTER HALTING BY JUST CONTINUING
                                ;;**************************************************************
014762                          ECHO:
014762  000005                        RESET                   ;CLEAR EVERYTHING
014764  112777  000052  165402        MOVB    #'*,@CTBUF      ;TRANSMIT PROMPT "*"
014772  105777  165370          2$:   TSTB    @CRCSR          ;WAIT FOR INPUT
014776  100375                        BPL     2$
015000  117777  165364  165366        MOVB    @CRBUF,@CTBUF   ;ECHO INPUT
015006  017700  165356                MOV     @CRBUF,R0       ;STORE INPUT
015012  100023                        BPL     5$              ;BR IF "ERROR"NOT SET
015014  052701  010000                BIS     #BIT12,R1       ;SET PARITY ERROR TEST MASK
015020  030100                        BIT     R1,R0           ;CHECK  FOR PARITY ERROR FLAG
015022  001403                        BEQ     3$              ;BR IF NOT SET
015024  004737  015106                JSR     PC,MSG          ;REPORT PARITY ERROR
015030  015134                        MPAR
015032  006301                  3$:   ASL     R1              ;SHIFT MASK TO TEST "FR" FLAG
015034  030100                        BIT     R1,R0           ;TEST FOR FRAMING ERROR FLAG
015036  001403                        BEQ     4$              ;BR IF NOT SET
015040  004737  015106                JSR     PC,MSG          ;REPSORT FRAMING ERROR
015044  015145                        MFR
015046  006301                  4$:   ASL     R1              ;SHIFT MASK TO TEST "OR" FLAG
015050  030100                        BIT     R1,R0           ;TEST FOR OVERFLOW ERROR
015052  001403                        BEQ     5$              ;BR IF NOT SET
015054  004737  015106                JSR     PC,MSG          ;REPORT OVERFLOW ERROR
015060  015157                        MOR
015062  042700  000200          5$:   BIC     #BIT7,R0        ;CLEAR ANY PARITY BIT
015066  022700  000003                CMP     #3,R0           ;WAS INPUT CONTROL-C
015072  001337                        BNE     2$              ;BR IF NOT
015074  004737  015106                JSR     PC,MSG          ;REPORT PROGRAM STOP
015100  015172                        MSTOP
015102  000000                        HALT                    ;END OF TEST HALT
015104  000726                        BR      ECHO            ;AFTER END OF TEST HALT
                                                            ;   PRESS CONTINUE TO RESTART ECHO TEST
015106  013600                  MSG:  MOV     @(SP)+,R0       ;PICK UP MESSAGE POINTER
015110  062746  000002                ADD     #2,-(SP)        ;ADJUST RETURN PC
015114  105777  165252          WAIT: TSTB    @CTCSR          ;WAIT FOR XMIT DONE
015120  100375                        BPL     WAIT
015122  112077  165246                MOVB    (R0)+,@CTBUF    ;SEND CHARACTER
015126  105710                        TSTB    (R0)            ;IS THIS END OF MESSAGE?
015130  001371                        BNE     WAIT            ;BR IF NOT
015132  000207                        RTS     PC              ;RETURN

015134  005015  040520  044522  MPAR: .ASCIZ  <CR><LF>/PARITY/
015142  054524     000
015145     015  043012  040522  MFR:  .ASCIZ  <CR><LF>/FRAMING/
015152  044515  043516     00(
015157     015  047412  042526  MOR:  .ASCIZ  <CR><LF>/OVERFLOW/
015164  043122  047514  000127
015172  005015  052123  050117  MSTOP: .ASCIZ  <CR><LF>/STOP/
015200     000
```



```
015202                                  .EVEN

                                .SBTTL  TERMINAL OUTPUT TEST

                                ;;**************************************************************
                                        ;*THIS ROUTINE WILL OUTPUT ALL WRITABLE CHARACTERS FOR THE
                                        ;*THE OCTAL CODE 040 --> 377
                                        ;*32 CHARACTERS ARE PRINTED ON EACH LINE
                                        ;*THE PATTERN IS REPEATED EVERY THREE LINES
                                        ;*
                                ;;**************************************************************

015202  012701  000040          OUTTST: MOV     #40,R1          ;LOAD FIRST WRITABLE CHARACTER
015206  012700  000040          1$:     MOV     #40,R0          ;LOAD CHAR COUNT PER LINE
015212  105777  165154          2$:     TSTB    @CTCSR          ;WAIT FOR DONE
015216  100375                          BPL     2$
015220  010177  165150                  MOV     R1,@CTBUF       ;TRANSMIT A CHARACTER
015224  105201                          INCB    R1              ;INCREMENT CHARACTER CODE
015226  005300                          DEC     R0              ;DECREMENT CHAR COUNT
015230  001370                          BNE     2$              ;BR IF LINE NOT COMPLETE
015232  004737  015106                  JSR     PC,MSG          ;SSUE CR,LINE FEED

015236  001063                          $CRLF
015240  105777  165122                  TSTB    @CRCSR          ;ANY CHARACTER RECEIVED?
015244  100404                          BMI     3$              ;BR IF YES
015246  032701  000200                  BIT     #BIT7,R1        ;FINISHED ONE PASS OF WRITABLE CHARACTERS?
015252  001353                          BNE     OUTTST          ;BR IF YES
015254  000754                          BR      1$              ;IF NOT WRITE NEXT LINE

015256  005077  165106          3$:     CLR     @CRBUF          ;CLEAR RECEIVER
015262  000000                          HALT                    ;STOP TEST
015264  000746                          BR      OUTTST          ;RESTART TEST IF CONTINUED
```

```
 3390
 3391
 3392  015266  040503  020116  047516  EM1:    .ASCIZ  /CAN NOT ACCESS TCSR/
 3393  015274  020124  041501  042503
 3394  015302  051523  052040  051503
 3395  015310  000122
 3396  015312  040503  020116  047516  EM2:    .ASCIZ  /CAN NOT ACCESS TBUF/
 3397  015320  020124  041501  042503
 3398  015326  051523  052040  052502
 3399  015334  000106
 3400  015336  041524  051123  042040  EM3:    .ASCIZ  /TCSR DONE NOT CLEARED WITH TBUF FULL/
 3401  015344  047117  020105  047516
 3402  015352  020124  046103  040505
 3403  015360  042522  020104  044527
 3404  015366  044124  052040  052502
 3405  015374  020106  052506  046114
 3406  015402     000
 3407  015403     124  051503  020122  EM4:    .ASCIZ  /TCSR DONE NOT SET/
 3408  015410  047504  042516  047040
 3409  015416  052117  051440  052105
 3410  015424     000
 3411  015425     124  051503  020122  EM5:    .ASCIZ  /TCSR DONE NOT SET WITH RESET/
 3412  015432  047504  042516  047040
 3413  015440  052117  051440  052105
 3414  015446  053440  052111  020110
 3415  015454  042522  042523  000124
 3416  015462  040503  020116  047516  EM6:    .ASCIZ  /CAN NOT ACCESS RCSR/
 3417  015470  020124  041501  042503
 3418  015476  051523  051040  051503
 3419  015504  000122
 3420  015506  040503  020116  047516  EM7:    .ASCIZ  /CAN NOT ACCESS RBUF/
 3421  015514  020124  041501  042503
 3422  015522  051523  051040  0525C3
 3423  015530  000106
 3424  015532  040503  020116  047516  EM10:   .ASCIZ  /CAN NOT ACCESS LKS/
 3425  015540  020124  041501  042503
 3426  015546  051523  046040  051513
 3427  015554     000
 3428  015555     102  052111  020060  EM11:   .ASCIZ  /BIT0 OF TCSR NOT CLEAR AFTER RESET/
 3429  015562  043117  052040  051503
 3430  015570  020122  047516  020124
 3431  015576  046103  040505  020122
 3432  015604  043101  042524  020122
 3433  015612  042522  042523  000124
 3434  015620  040503  020116  047516  EM12:   .ASCIZ  /CAN NOT SET BIT0 OF TCSR/
 3435  015626  020124  042523  020124
 3436  015634  044502  030124  047440
 3437  015642  020106  041524  051123
 3438  015650     000
 3439  015651     103  047101  047040  EM13:   .ASCIZ  /CAN NOT CLEAR BIT0 OF TCSR/
 3440  015656  052117  041440  042514
 3441  015664  051101  041040  052111
 3442  015672  020060  043117  052040
 3443  015700  051503  000122
 3444  015704  042522  042523  020124  EM14:   .ASCIZ  /RESET DID NOT CLEAR BIT0 OF TCSR/
 3445  015712  044504  020104  047516
```



```
 3446  015720  020124  046103  040505
 3447  015726  020122  044502  030124
 3448  015734  047440  020106  041524
 3449  015742  051123     000
 3450  015745     102  052111  020062  EM15:   .ASCIZ  /BIT2 OF TCSR NOT CLEAR AFTER RESET/
 3451  015752  043117  052040  051503
 3452  015760  020122  047516  020124
 3453  015766  046103  040505  020122
 3454  015774  043101  042524  020122
 3455  016002  042522  042523  000124
 3456  016010  040503  020116  047516  EM16:   .ASCIZ  /CAN NOT SET BIT2 OF TCSR/
 3457  016016  020124  042523  020124
 3458  016024  044502  031124  047440
 3459  016032  020106  041524  051123
 3460  016040     000
 3461  016041     103  047101  047040  EM17:   .ASCIZ  /CAN NOT CLEAR BIT2 OF TCSR/
 3462  016046  052117  041440  042514
 3463  016054  051101  041040  052111
 3464  016062  020062  043117  052040
 3465  016070  051503  000122
 3466  016074  042522  042523  020124  EM20:   .ASCIZ  /RESET DID NOT CLEAR BIT2 OF TCSR/
 3467  016102  044504  020104  047516
 3468  016110  020124  046103  040505
 3469  016116  020122  044502  031124
 3470  016124  047440  020106  041524
 3471  016132  051123     000
 3472  016135     102  052111  020066  EM21:   .ASCIZ  ;BIT6 OF TCSR NOT CLEAR AFTER RESET/
 3473  016142  043117  052040  051503
 3474  016150  020122  047516  020124
 3475  016156  046103  040505  020122
 3476  016164  043101  042524  020122
 3477  016172  042522  042523  027524
 3478  016200     000
 3479  016201     130  044515  020124  EM22:   .ASCIZ  /XMIT INTERRUPT AT PRIORITY 7/
 3480  016206  047111  042524  051122
 3481  016214  050125  020124  052101
 3482  016222  050040  044522  051117
 3483  016230  052111  020131  000067
 3484  016236  040503  020116  047516  EM23:   .ASCIZ  /CAN NOT SET BIT6 OF TCSR/
 3485  016244  020124  042523  020124
 3486  016252  044502  033124  047440
 3487  016260  020106  041524  051123
 3488  016266     000
 3489  016267     103  047101  047040  EM24:   .ASCIZ  /CAN NOT CLEAR BIT6 OF TCSR/
 3490  016274  052117  041440  042514
 3491  016302  051101  041040  052111
 3492  016310  020066  043117  052040
 3493  016316  051503  000122
 3494  016322  042522  042523  020124  EM25:   .ASCIZ  /RESET DID NOT CLEAR BIT6 OF TCSR/
 3495  016330  044504  020104  047516
 3496  016336  020124  046103  040505
 3497  016344  020122  044502  033124
 3498  016352  047440  020106  041524
 3499  016360  051123     000
 3500  016363     102  052111  020066  EM26:   .ASCIZ  /BIT6 OF RCSR NOT CLEAR AFTER RESET/
 3501  016370  043117  051040  051503
```

```
3502  016376  020122  047516  020124
3503  016404  046103  040505  020122
3504  016412  043101  042524  020122
3505  016420  042522  042523  000124
3506  016426  041522  051126  044440  EM27:   .ASCIZ  /RCVR INTERRUPT WITH PRIORITY 7/
3507  016434  052116  051105  052522
3508  016442  052120  053440  052111
3509  016450  020110  051120  047511
3510  016456  044522  054524  033440
3511  016464     000
3512  016465     103  047101  047040  EM30:   .ASCIZ  /CAN NOT SET BIT6 OF RCSR/
3513  016472  052117  051440  052105
3514  016500  041040  052111  020066
3515  016506  043117  051040  051503
3516  016514  000122
3517  016516  040503  020116  047516  EM31:   .ASCIZ  /CAN NOT CLEAR BIT6 OF RCSR/
3518  016524  020124  046103  040505
3519  016532  020122  044502  033124
3520  016540  047440  020106  041522
3521  016546  051123     000
3522  016551     103  047101  047040  EM32:   .ASCIZ  /CAN NOT CLEAR BIT6 OF RCSR WITH RESET/
3523  016556  052117  041440  042514
3524  016564  051101  041040  052111
3525  016572  020066  043117  051040
3526  016600  051503  020122  044527
3527  016606  044124  051040  051505
3528  016614  052105     000
3529  016617     102  052111  020066  EM33:   .ASCIZ  /BIT6 OF LKS NOT CLEAR AFTER RESET/
3530  016624  043117  046040  051513
3531  016632  047040  052117  041440
3532  016640  042514  051101  040440
3533  016646  052106  051105  051040
3534  016654  051505  052105     000
3535  016661     114  051513  044440  EM34:   .ASCIZ  /LKS INTERRUPT WITH PRIORITY 7/
3536  016665  052116  051105  052522
3537  016674  052120  053440  052111
3538  016702  020110  051120  047511
3539  016710  044522  054524  033440
3540  016716     000
3541  016717     103  047101  047040  EM35:   .ASCIZ  /CAN NOT SET BIT6 OF LKS/
3542  016724  052117  051440  052105
3543  016732  041040  052111  020066
3544  016740  043117  046040  051513
3545  016746     000
3546  016747     103  047101  047040  EM36:   .ASCIZ  /CAN NOT CLEAR BIT6 OF LKS/
3547  016754  052117  041440  042514
3548  016762  051101  041040  052111
3549  016770  020066  043117  046040
3550  016776  051513     000
3551  017001     122  051505  052105  EM37:   .ASCIZ  /RESET DID NOT CLEAR BIT6 OF LKS/
3552  017006  042040  042111  047040
3553  017014  052117  041440  042514
3554  017022  051101  041040  052111
3555  017030  020066  043117  046040
3556  017036  051513     000
3557  017041     104  040525  020114  EM40:   .ASCIZ  /DUAL ADDRESSING ERROR/
```



```
3558  017046  042101  051104  051505
3559  017054  044523  043516  042440
3560  017062  051122  051117     000
3561  017067     102  052111  020066  EM41:   .ASCIZ  /BIT6 OF LKS NOT SET AFTER RESET/
3562  017074  043117  046040  051513
3563  017102  047040  052117  051440
3564  017110  052105  040440  052106
3565  017116  051105  051040  051505
3566  017124  052105     000
3567  017127     103  047101  047040  EM42:   .ASCIZ  /CAN NOT CLEAR BIT7 OF LKS/
3568  017134  052117  041440  042514
3569  017142  051101  041040  052111
3570  017150  020067  043117  046040
3571  017156  051513     000
3572  017161     102  052111  020067  EM43:   .ASCIZ  /BIT7 OF LKS DOES NOT SET/
3573  017166  043117  046040  051513
3574  017174  042040  042517  020123
3575  017202  047516  020124  042523
3576  017210  000124
3577  017212  052122  020103  047111  EM44:   .ASCIZ  /RTC INTERRUPT AT PRIORITY 7/
3578  017220  042524  051122  050125
3579  017226  020124  052101  050040
3580  017234  044522  051117  052111
3581  017242  020131  000067
3582  017246  052122  020103  047111  EM45:   .ASCIZ  /RTC INTERRUPTS WHEN DISABLED/
3583  017254  042524  051122  050125
3584  017262  051524  053440  042510
3585  017270  020116  044504  040523
3586  017276  046102  042105     000
3587  017303                          EM47:
3588  017303     122  041524  044440  EM46:   .ASCIZ  /RTC INTERRUPT DID NOT OCCUR/
3589  017310  052116  051105  052522
3590  017316  052120  042040  04211
3591  017324  047040  052117  047440
3592  017332  041503  051125     000
3593  017337     122  041524  042040  EM50:   .ASCIZ  /RTC DOUBLE INTERRUPT/
3594  017344  052517  046102  020105
3595  017352  047111  042524  051122
3596  017360  050125  000124
3597  017364  042522  042523  020124  EM51:   .ASCIZ  /RESET DID NOT INTERRUPT/
3598  017372  044504  020104  047516
3599  017400  020124  047111  042524
3600  017406  051122  050125  000124
3601  017414  052122  020103  047111  EM52:   .ASCIZ  /RTC INTERRUPT DID NOT CLEAR WITH BIT7 OF LKS/
3602  017422  042524  051122  050125
3603  017430  020124  044504  020104
3604  017436  047516  020124  046103
3605  017444  040505  020122  044527
3606  017452  044124  041040  052111
3607  017460  020067  043117  046040
3608  017466  051513     000
3609  017471     103  047514  045503  EM53:   .ASCIZ  /CLOCK REPEATABILITY/
3610  017476  051040  050105  040505
3611  017504  040524  044502  044514
3612  017512  054524     000
3613  017515     130  044515  020124  EM54:   .ASCIZ  /XMIT INTERRUPTS WHEN DISABLED/
```

```
3614  017522  047111  042524  051122
3615  017530  050125  051524  053440
3616  017536  042510  020116  044504
3617  017544  040523  046102  042105
3618  017552     000
3619  017553     130  044515  020124  EM56:   .ASCIZ  /XMIT INTERRUPTS AT PRIORITY 7/
3620  017560  047111  042524  051122
3621  017566  050125  051524  040440
3622  017574  020124  051120  047511
3623  017602  044522  054524  033440
3624  017610     000
3625  017611     130  044515  020124  EM57:   .ASCIZ  /XMIT INTERRUPTS WITH ENABLE CLEAR/
3626  017616  047111  042524  051122
3627  017624  050125  051524  053440
3628  017632  052111  020110  047105
3629  017640  041101  042514  041440
3630  017646  042514  051101     000
3631  017653                          EM55:
3632  017653     130  044515  020124  EM60:   .ASCIZ  /XMIT DID NOT INTERRUPT/
3633  017660  044504  020104  047516
3634  017666  020124  047111  042524
3635  017674  051122  050125  000124
3636  017702  046530  052111  051040  EM61:   .ASCIZ  /XMIT RE-INTERRUPTED/
3637  017710  026505  047111  042524
3638  017716  051122  050125  042524
3639  017724  000104
3640  017726  047514  042101  047111  EM62:   .ASCIZ  /LOADING TBUF DID NOT CLEAR INTERRUPT/
3641  017734  020107  041124  043125
3642  017742  042040  042111  047040
3643  017750  052117  041440  042514
3644  017756  051101  044440  052116
3645  017764  051105  052522  052120
3646  017772     000
3647  017773     122  053103  020122  EM63:   .ASCIZ  /RCVR ACTIVE NOT SET/
3648  020000  041501  044524  042526
3649  020006  047040  052117  051440
3650  020014  052105     000
3651  020017     122  053103  020122  EM64:   .ASCIZ  /RCVR DONE NEVER SET/
3652  020024  047504  042516  047040
3653  020032  053105  051105  051440
3654  020040  052105     000
3655  020043     122  053103  020122  EM65:   .ASCIZ  /RCVR ACTIVE NOT CLEARED WITH DONE SET/
3656  020050  041501  044524  042526
3657  020056  047040  052117  041440
3658  020064  042514  051101  042105
3659  020072  053440  052111  020110
3660  020100  047504  042516  051440
3661  020106  052105     000
3662  020111     122  051505  052105  EM66:   .ASCIZ  /RESET DID NOT CLEAR RCVR DONE/
3663  020116  042040  042111  047040
3664  020124  052117  041440  042514
3665  020132  051101  051040  053105
3666  020140  020122  047504  042516
3667  020146     000
3668  020147     122  051104  042440  EM67:   .ASCIZ  /RDR ENABLE DID NOT CLEAR RCVR DONE/
3669  020154  040516  046102  020105
```



```
3670  020162  044504  020104  047516
3671  020170  020124  046103  040505
3672  020176  020122  041522  051126
3673  020204  042040  047117  000105
3674  020212  042522  042101  047111  EM70:   .ASCIZ  /READING RBUF DID NOT CLEAR RCVR DONE/
3675  020220  020107  041122  043125
3676  020226  042040  042111  047040
3677  020234  052117  041440  042514
3678  020242  051101  051040  053103
3679  020250  020122  047504  042516
3680  020256     000
3681  020257     122  053103  020122  EM71:   .ASCIZ  /RCVR INTERRUPTS WITH ENABLE CLEAR/
3682  020264  047111  042524  051122
3683  020272  050125  051524  053440
3684  020300  052111  020110  047105
3685  020306  041101  042514  041440
3686  020314  042514  051101     000
3687  020321     122  053103  020122  EM73:   .ASCIZ  /RCVR INTERRUPTS AT PRIORITY 7/
3688  020326  047111  042524  051122
3689  020334  050125  051524  040440
3690  020342  020124  051120  047511
3691  020350  044522  054524  033440
3692  020356     000
3693  020357     122  053103  020122  EM74:   .ASCIZ  /RCVR INT RQST PASSED WITH ENABLE CLEAR/
3694  020364  047111  020124  050522
3695  020372  052123  050040  051501
3696  020400  042523  020104  044527
3697  020406  044124  042440  040516
3698  020414  046102  020105  046103
3699  020422  040505  000122
3700  020426                          EM72:
3701  020426  041522  051126  042040  EM75:   .ASCIZ  /RCVR DID NOT INTERRUPT/
3702  020434  042111  047040  052117
3703  020442  044440  052116  051105
3704  020450  052522  052120     000
3705  020455     122  053103  020122  EM76:   .ASCIZ  /RCVR RE-INTERRUPTED/
3706  020462  042522  044455  052116
3707  020470  051105  052522  052120
3708  020476  042105     000
3709  020501     122  040505  044504  EM77:   .ASCIZ  /READING RBUF DID NOT CLEAR INTERRUPT/
3710  020506  043516  051040  052502
3711  020514  020106  044504  020104
3712  020522  047516  020124  046103
3713  020530  040505  020122  047111
3714  020536  042524  051122  050125
3715  020544  000124
3716  020546  042522  042523  020124  EM100:  .ASCIZ  /RESET DID NOT CLEAR RCVR INTERRUPT/
3717  020554  044504  020104  047516
3718  020562  020124  046103  040505
3719  020570  020122  041522  051126
3720  020576  044440  052116  051105
3721  020604  052522  052120     000
3722  020611     047  051117  020047  EM101:  .ASCIZ  /'OR' FLAG DID NOT SET/
3723  020616  046106  043501  042040
3724  020624  042111  047040  052117
3725  020632  051440  052105     000
```

```
 3726  020637      047  051105  047522  EM102:  .ASCIZ  /'ERROR' NOT SET WITH 'OR' FLAG/
 3727  020644   023522  047040  052117
 3728  020652   051440  052105  053440
 3729  020660   052111  020110  047447
 3730  020666   023522  043040  040514
 3731  020674   000107
 3732  020676   051102  040505  020113  EM103:  .ASCIZ  /BREAK DID NOT XMIT ALL ZEROES/
 3733  020704   044504  020104  047516
 3734  020712   020124  046530  052111
 3735  020720   040440  046114  055040
 3736  020726   051105  042517  000123
 3737  020734   051102  040505  020113  EM104:  .ASCIZ  /BREAK DID NOT SET 'FR' ERROR/
 3738  020742   044504  020104  047516
 3739  020750   020124  042523  020124
 3740  020756   043047  023522  042440
 3741  020764   051122  051117     000
 3742  020771      104  052101  020101  EM105:  .ASCIZ  /DATA COMPARE ERROR/
 3743  020776   047503  050115  051101
 3744  021004   020105  051105  047522
 3745  021012   000122
 3746  021014   040504  040524  041440  EM106:  .ASCIZ  /DATA COMPARE ERROR WITH CABLE/
 3747  021022   046517  040520  042522
 3748  021030   042440  051122  051117
 3749  021036   053440  052111  020110
 3750  021044   040503  046102  000105
 3751  021052   044524  042515  052517  EM107:  .ASCIZ  /TIMEOUT IN EXERCISER TEST/
 3752  021060   020124  047111  042440
 3753  021066   042530  041522  051511
 3754  021074   051105  052040  051505
 3755  021102   000124
 3756  021104   047111  047503  051122  EM110:  .ASCIZ  /INCORRECT RECEIVE COUNT/
 3757  021112   041505  020124  042522
 3758  021120   042503  053111  020103
 3759  021126   047503  047125  000124
 3760  021134   040504  040524  041440  EM111:  .ASCIZ  /DATA COMPARE ERROR IN EXERCISER/
 3761  021142   046517  040520  042522
 3762  021150   042440  051122  051117
 3763  021156   044440  020116  054105
 3764  021164   051105  044503  042523
 3765  021172   000122
 3766  021174   051124  050101  041440  EM112:  .ASCIZ  /TRAP CATCHER/
 3767  021202   052101  044103  051105
 3768  021210      000
 3769  021211      116  020117  046103  EM113:  .ASCIZ  /NO CLK INTERRUPT IN EXERCISER/
 3770  021215   020113  047111  042524
 3771  021224   051122  050125  020124
 3772  021232   047111  042440  042530
 3773  021240   041522  051511  051105
 3774  021246      000
 3775  021247      042  051105  047522  EM114:  .ASCIZ  /"ERROR" NOT SET WITH "FR" FLAG/
 3776  021254   021122  047040  052117
 3777  021262   051440  052105  053440
 3778  021270   052111  020110  043042
 3779  021276   021122  043040  040514
 3780  021304   000107
 3781  021306   041522  020126  041501  EM115:  .ASCIZ  /RCV ACTIVE NOT CLEAR WITH INIT/
```



```
 3782  021314   044524  042526  047040
 3783  021322   052117  041440  042514
 3784  021330   051101  053440  052111
 3785  021336   020110  047111  052111
 3786  021344      000
 3787  021345      122  053103  040440  EM116:  .ASCIZ  /RCV ACTIVE WITHOUT "START" BIT/
 3788  021352   052103  053111  020105
 3789  021360   044527  044124  052517
 3790  021366   020124  051442  040524
 3791  021374   052122  020042  044502
 3792  021402   000124
 3793  021404   042122  020122  047105  EM117:  .ASCIZ  /RDR ENABLE NOT CLEAR WITH RCV ACTIVE/
 3794  021412   041101  042514  047040
 3795  021420   052117  041440  042514
 3796  021426   051101  053440  052111
 3797  021434   020110  041522  020126
 3798  021442   041501  044524  042526
 3799  021450      000
 3800
 3801  021451      124  051505  021524  DH1:    .ASCIZ  /TEST#   ERROR#  TCSR/
 3802  021456   020040  042440  051122
 3803  021464   051117  020043  052040
 3804  021472   051503  000122
 3805  021476   042524  052123  020043  DH2:    .ASCIZ  /TEST#   ERR PC  TBUF/
 3806  021504   020040  051105  020122
 3807  021512   041520  020040  041124
 3808  021520   043125     000
 3809  021523      124  051505  021524  DH6:    .ASCIZ  /TEST#   ERR PC  RCSR/
 3810  021530   020040  042440  051122
 3811  021536   050040  020103  051040
 3812  021544   051503  000122
 3813  021550   042524  052123  020043  DH7:    .ASCIZ  /TEST#   ERR PC  RBUF/
 3814  021556   020040  051105  020122
 3815  021564   041520  020040  041122
 3816  021572   043125     000
 3817  021575      124  051505  021524  DH10:   .ASCIZ  /TEST#   ERR PC  LKS/
 3818  021602   020040  042440  051122
 3819  021610   050040  020103  046040
 3820  021616   051513     000
 3821  021621      124  051505  021524  DH40:   .ASCIZ  /TEST#   ERR PC  GOOD    BAD/
 3822  021626   020040  042440  051122
 3823  021634   050040  020103  043440
 3824  021642   047517  020104  020040
 3825  021650   041040  042101     000
 3826  021655      124  051505  021524  DH53:   .ASCIZ  /TEST#   ERR PC  LKS     CNT1    CNT2/
 3827  021662   020040  042440  051122
 3828  021670   050040  020103  046040
 3829  021676   051513  020040  020040
 3830  021704   041440  052116  020061
 3831  021712   020040  041440  052116
 3832  021720   000062
 3833  021722   042524  052123  020040  DH103:  .ASCIZ  /TEST#   ERR PC  RCSR    DATA/
 3834  021730   020040  051105  020122
 3835  021736   041520  020040  041522
 3836  021744   051123  020040  020040
 3837  021752   040504  040524     000
```

```
 3838  021757     124  051505  021524  DH105:  .ASCIZ  /TEST#   ERR PC  RCSR    GOOD    BAD/
 3839  021764  020040  042440  051122
 3840  021772  050040  020103  051040
 3841  022000  051503  020122  020040
 3842  022006  043440  047517  020104
 3843  022014  020040  041040  042101
 3844  022022     000
 3845  022023     124  051505  021524  DH110:  .ASCIZ  /TEST#   ERR PC  RCSR    TRANS   RCV/
 3846  022030  020040  042440  051122
 3847  022036  050040  020103  051040
 3848  022044  051503  020122  020040
 3849  022052  052040  040522  051516
 3850  022060  020040  051040  053103
 3851  022066     000
 3852  022067     124  051505  021524  DH112:  .ASCIZ  /TEST#   ERR PC  RCSR    OLDPC   TRAP ADR/
 3853  022074  020040  042440  051122
 3854  022102  050040  020103  051040
 3855  022110  051503  020122  020040
 3856  022116  047440  042114  041520
 3857  022124  020040  052040  040522
 3858  022132  020120  042101  000122
 3859                                  .EVEN
 3860  022140  005015  055103  046104  M1:     .ASCIZ  <CR><LF>/CZDLD-C/
 3861  022146  026504  000103
 3862                                  .EVEN
 3863  022152  005015                  M2:     .ASCII  <CR><LF>
 3864  022154  020040  042040  053105  M2A:    .ASCIZ  /   DEVICES UNDER TEST  /
 3865  022162  041511  051505  052440
 3866  022170  042116  051105  052040
 3867  022176  051505  020124  000040
 3868
 3869                                  .EVEN
 3870  022204  001072  001016  002352  DT1:    .WORD   $TESTN,$ERRPC,TCSR,0
 3871  022212  000000
 3872  022214  001072  001016  002354  DT2:    .WORD   $TESTN,$ERRPC,TBUF,0
 3873  022222  000000
 3874  022224  001072  001016  002346  DT6:    .WORD   $TESTN,$ERRPC,RCSR,0
 3875  022232  000000
 3876  022234  001072  001016  002350  DT7:    .WORD   $TESTN,$ERRPC,RBUF,0
 3877  022242  000000
 3878  022244  001072  001016  002406  DT10:   .WORD   $TESTN,$ERRPC,LKS,0
 3879  022252  000000
 3880  022254  001072  001016  001020  DT40:   .WORD   $TESTN,$ERRPC,$GDADR,$BDADR,0
 3881  022262  001022  000000
 3882  022266  001072  001016  002406  DT53:   .WORD   $TESTN,$ERRPC,LKS,FIRST,SECND,0
 3883  022274  006600  006602  000000
 3884  022302  001072  001016  002346  DT103:  .WORD   $TESTN,$ERRPC,RCSR,$BDDAT,0
 3885  022310  001026  000000
 3886  022314  001072  001016  002346  DT105:  .WORD   $TESTN,$ERRPC,RCSR,$GDDAT,$BDDAT,0
 3887  022322  001024  001026  000000
 3888  022330  001072  001016  002346  DT110:  .WORD   $TESTN,$ERRPC,RCSR,XMTCNT,RCVCNT,0
 3889  022336  011730  011726  000000
 3890  022344  001072  001016  002343  DT112:  .WORD   $TESTN,$ERRPC,RCSR,OLDPC,BDVECT,0
 3891  022352  012300  012302  000000
 3892          000001                  .END
```



```
ABASE = 176500            537#    650     691
ACDW1 = 000000            650
ACDW2 = 000000            650
ACPUOP= 000000            650     665
ADDW0 = 000000            650
ADDW1 = 000000            650
ADDW10= 000000            650
ADDW11= 000000            650
ADDW12= 000000            650
ADDW13= 000000            650
ADDW14= 000000            650
ADDW15= 000000            650
ADDW2 = 000000            650
ADDW3 = 000000            650
ADDW4 = 000000            650
ADDW5 = 000000            650
ADDW6 = 000000            650
ADDW7 = 000000            650
ADDW8 = 000000            650
ADDW9 = 000000            650
ADEVCT= 000000            650     656
ADEVM = 000000            650     692
ADR     003562           1314#   1317
ADRTBL  002414           1139#   1145    1312
AENV  = 000000            650     661
AENVM = 000000            650     662
AFATAL= 000000            650     653
AMADR1= 000000            650     678
AMADR2= 000000            650     682
AMADR3= 000000            650     685
AMADR4= 000000            650     688
AMAMS1= 000000            650     672
AMAMS2= 000000            650     680
AMAMS3= 000000            650     683
AMAMS4= 000000            650     686
AMSGAD= 000000            650     658
AMSGLG= 000000            650     659
AMSGTY= 000000            650     652
AMTYP1= 000000            650     673
AMTYP2= 000000            650     681
AMTYP3= 000000            650     684
AMTYP4= 000000            650     687
APASS = 000000            650     655
APRIOR= 000000            650
APTCSU= 000040           2955#   2988
APTENV= 000001           2731    2910    2953#   2981
APTSIZ= 000200           1207    2952#
APTSPD= 000100           2912    2954#   2983
APTSZD  003266           1218    1220    1245#
ASWREG= 000000            650     663
ATESTN= 000000            650     654
AUNIT = 000000            650     657
AUSWR = 000400            539#    650     664
AVECT1= 000300            538#    650     689
AVECT2= 000000            650     690
BDVECT  012302           2697*   2703#   3890
```

```
BEGIN   003424          1287#   2686
BIT0    = 000001         522#   1215    1289    1481    1492    1493    1498    1499    1510    1512    1514    2167    2172
                        2177    2408    2415    2420    2424    2437    2441
BIT00   = 000001         512#    522
BIT01   = 000002         511#    521
BIT02   = 000004         510#    520
BIT03   = 000010         509#    519
BIT04   = 000020         508#    518
BIT05   = 000040         507#    517
BIT06   = 000100         506#    516
BIT07   = 000200         505#    515
BIT08   = 000400         504#    514
BIT09   = 001000         503#    513    2742    2881
BIT1    = 000002         521#   1287    1723
BIT10   = 002000         502#   2373    2431
BIT11   = 004000         501#   2109    2118    2128    2144
BIT12   = 010000         500#   3315
BIT13   = 020000         499#   2442    2726
BIT14   = 040000         498#   2384    2865
BIT15   = 100000         497#   2389    2447
BIT2    = 000004         520#   1523    1536    1537    1542    1543    1555    1557    1560    2106    2113    2124    2131
                        2140    2146    2154    2158    2168    2180    2191    2196    2209    2217    2220    2228    2233
                        2247    2254    2264    2267    2285    2289    2322    2326    2351    2376    2383    2403    2415
                        2420    2424    2436    2441    2462    2479    2482    2544
BIT3    = 000010         519#
BIT4    = 000020         518#   1211    1282    1420    1724    1977
BIT5    = 000040         517#   1219    2591    2609
BIT6    = 000100         516#   1574    1584    1585    1591    1592    1597    1599    1616    1626    1627    1633    1634
                        1640    1642    1657    1675    1682    1692    1693    1699    1700    1704    1706    1735    1736
                        1760    1792    1801    1824    1832    1846    1856    1874    1885    1892    1899    1914    1921
                        1928    1946    1948    1989    2002    2007    2016    2023    2030    2047    2056    2066    2079
                        2084    2092    2207    2208    2226    2232    2251    2259    2290    2301    2321    2331    2350
                        2359    2539    2543    2545    2546    2559    2578    2611
BIT7    = 000200         515#   1217    1768    1769    1771    1772    1800    1823    1855    1891    1920    1924    2490
                        3330    3383
BIT8    = 000400         514#   1478    2400    2433
BIT9    = 001000         513#
BPT     = 000003         542#
BPTVEC= 000014           529#
BUF     011742          2551    2586    2631#
CATCH   012254           553    2695#
CKSWR   = 104406        2741    2864    3296#
CLK     011720          2541    2622#
CLKCNT  011732          2580    2622*   2627#
CMPARE  006536          1964    1967#
COMP    011560          2588#   2592
CONT    005566          1778#   1781
CONT41  010724          2411    2418#
CR      = 000015         437#   2676    3027    3037    3348    3350    3352    3354    3860    3863
CRBUF   002370          1126#   3312    3313    3387*
CRCSR   002366          1125#   1237    1293    3310    3381
CRLF    = 000200         438#   2998    3037
CRPSW   002400          1130#
CRVECT  002376          1129#
CTBUF   002374          1128#   3309*   3312*   3343*   3374*
CTCSR   002372          1127#   3341    3372
```



```
CTPSW   002404          1132#
CTSTFL  002336          1108#   1160*   1213*   1292*   1339    1361    1385    1399    1483    1501    1526    1546    1655
                        1673    1758    1790    1844    1883    1912    1944    2537    2576    2640*
CTVECT  002402          1131#
DDISP   = 177570         444#    633    1195
DEVADR  002514          1145#   1222    1253
DH1     021451           713     723     728     733     753     758     763     768     773     778     783     788     793
                         798     803     808     813     928     933     938     943     948     953     958    3801#
DH10    021575           748     843     848     853     858     863     873     878     883     888     893     898     903
                         908     913     918    1084    3817#
DH103   021722          1044    3833#
DH105   021757          1054    1059    1074    3838#
DH110   022023          1069    3845#
DH112   022067          1079    3852#
DH2     021476           718    3805#
DH40    021621           868    3821#
DH53    021655           923    3826#
DH6     021523           738     818     823     828     833     838     963     968     973     978     983     988     993
                         998    1003    1008    1013    1018    1023    1028    1034    1039    1049    1064    1089    1094
                        1099    1104    3809#
DH7     021550           743    3813#
DISPLA  001042           633#   1195*   1203*   2721*   2892*
DISPRE  000174           563#   1203
DSWR    = 177570         443#    632    1194
DT1     022204           714     724     729     734     754     759     764     769     774     779     784     789     794
                         799     804     809     814     929     934     939     944     949     954     959    3870#
DT10    022244           749     844     849     854     859     864     874     879     884     889     894     899     904
                         909     914     919    1085    3878#
DT103   022302          1045    3884#
DT105   022314          1055    1060    1075    3886#
DT110   022330          1070    3888#
DT112   022344          1080    3890#
DT2     022214           719    3872#
DT40    022254           869    3880#
DT53    022266           924    3882#
DT6     022224           739     819     824     829     834     839     964     969     974     979     984     989     994
                         999    1004    1009    1014    1019    1024    1029    1035    1040    1050    1065    1090    1095
                        1100    1105    3874#
DT7     022234           744    3876#
DVADT   003314          1251    1253#
ECHO    014762           568    3307#   3336
EMTVEC= 000030           532#   1179*   1180*
EM1     015266           712    3392#
EM10    015532           747    3424#
EM100   020546          1027    3716#
EM101   020611          1033    3722#
EM102   020637          1038    3726#
EM103   020676          1043    3732#
EM104   020734          1048    3737#
EM105   020771          1053    3742#
EM106   021014          1058    3746#
EM107   021052          1063    3751#
EM11    015555           752    3426#
EM110   021104          1068    3756#
EM111   021134          1073    3760#
EM112   021174          1078    3766#
```

```
EM113   021211          1083    3769#
EM114   021247          1088    3775#
EM115   021306          1093    3781#
EM116   021345          1098    3787#
EM117   021404          1103    3793#
EM12    015620           757    3434#
EM13    015651           762    3439#
EM14    015704           767    3444#
EM15    015745           772    3450#
EM16    016010           777    3456#
EM17    016041           782    3461#
EM2     015312           717    3396#
EM20    016074           787    3466#
EM21    016135           792    3472#
EM22    016201           797    3479#
EM23    016236           802    3484#
EM24    016267           807    3489#
EM25    016322           812    3494#
EM26    016363           817    3500#
EM27    016426           822    3506#
EM3     015336           722    3400#
EM30    016465           827    3512#
EM31    016516           832    3517#
EM32    016551           837    3522#
EM33    016617           842    3529#
EM34    016661           847    3535#
EM35    016717           852    3541#
EM36    016747           857    3546#
EM37    017001           862    3551#
EM4     015403           727    3407#
EM40    017041           867    3557#
EM41    017067           872    3561#
EM42    017127           877    3567#
EM43    017161           882    3572#
EM44    017212           887    3577#
EM45    017246           892    3582#
EM46    017303           897    3588#
EM47    017303           902    3587#
EM5     015425           732    3411#
EM50    017337           907    3593#
EM51    017364           912    3597#
EM52    017414           917    3601#
EM53    017471           922    3609#
EM54    017515           927    3613#
EM55    017653           932    3631#
EM56    017553           937    3619#
EM57    017611           942    3625#
EM6     015462           737    3416#
EM60    017653           947    3632#
EM61    017702           952    3636#
EM62    017726           957    3640#
EM63    017773           962    3647#
EM64    020017           967    3651#
EM65    020043           972    3655#
EM66    020111           977    3662#
EM67    020147           982    3668#
```



```
EM7     015506           742    3420#
EM70    020212           987    3674#
EM71    020257           992    3681#
EM72    020426           997    3700#
EM73    020321          1002    3687#
EM74    020357          1007    3693#
EM75    020426          1012    3701#
EM76    020455          1017    3705#
EM77    020501          1022    3709#
ENDEV   012052          2605    2636#
ENDMG   012172          2663    2676#
ERRVEC= 000004           525#   1192    1193*   1204*   2870    2871*   2873*   2876*
FIRST   006600          1965*   1967    1981#   3882
GNS   = ****** U        3289    3290    3291    3292    3294    3296    3297    3298
GOAGIN  012206          2673    2679#
GTSWR = 104405          3294#
HT    = 000011           435#   2996    3037
ID      004056          1214    1395    1402    1410#
INIT    003112          1212    1215#
IOTVEC= 000020           530#   1177*   1178*
LF    = 000012           436#   2676    3031    3037    3348    3350    3352    3354    3860    3863
LKS     002406          1135#   1661    1682    1692*   1693    1699*   1700    1704*   1706    1726    1763    1768*   1769
                        1771*   1772    1778    1800*   1801*   1802    1810*   1814    1823*   1824*   1825    1832*   1855*
                        1856*   1857    1874*   1891*   1892*   1893    1899*   1920*   1921*   1922    1924*   1928*   1948*
                        1953*   1954    1956*   1957    1960*   2543*   3878    3882
MANL    003132          1216    1219#
MFR     015145          3324    3350#
MOR     015157          3329    3352#
MPAR    015134          3319    3348#
MSG     015106          3318    3323    3328    3333    3339#   3378
MSTOP   015172          3334    3354#
M1      022140          1417    3860#
M2      022152          1419    3863#
M2A     022154          1284*   3864#
OLDPC   012300          2698*   2702#   3890
OUTTST  015202           569    3370#   3384    3389
PIRQ  = 177772           442#
PIRQVE= 000240           536#
PR0   = 000000           459#
PR1   = 000040           460#
PR2   = 000100           461#
PR3   = 000140           462#
PR4   = 000200           463#
PR5   = 000240           464#
PR6   = 000300           465#
PR7   = 000340           466#
PS    = 177776           439#    440
PSW   = 177776           440#
PWRVEC= 000024           531#   1183*   1184*   2809*   2810*   2819*   2827*   2836*   2837*
RBUF    002350          1115#   1462    2195    2327*   2384    2389    2407*   2418    2442    2447    2470    2507    2617
                        3876
RCSR    002346          1114#   1294    1313    1448    1616    1626*   1627    1633*   1634    1640*   1642    1728    2109
                        2118    2128    2136    2144    2151    2158*   2167*   2170    2172    2177*   2178    2193    2197
                        2208*   2215    2226*   2232*   2249    2251*   2259*   2287    2290*   2301*   2321*   2324    2331*
                        2350*   2353    2359*   2405    2410    2439    2468    2500    2546*   3874    3884    3886    3888
                        3890
```

```
RCV     011704          2535    2617#
RCVCNT  011726          2548*   2565    2618*   2625#   3888
RDCHR = 104407          3229    3297#
RDLIN = 104410          3298#
RESVEC= 000010           526#
RPSW    002360          1119#   2280    2282*   2303*   2531    2536*   2603*
RSTRT   012232          2681    2685#
RTCPSW  002412          1137#   1797    1799*   1834*   1850    1852*   1876*   2532    2542*   2604*
RTCVT   002410          1136#   1678    1679*   1711*   1796    1798*   1811*   1822*   1833*   1849    1851*   1864*   1875*
                        1889    1890*   1905*   1918    1919*   1935*   2529    2541*   2601*
RVECT   002356          1118#   1612    1613*   1647*   2210    2211*   2225*   2235*   2245    2246*   2260*   2271*   2279
                        2281*   2297*   2302*   2309*   2319    2320*   2337*   2348    2349*   2366*   2528    2535*   2600*
SCPSW   011740          2532*   2604    2630#
SECND   006602          1974*   1982#   3882
SETADR  003530          1302    1308#
SHIFT   003370          1274#   1283
SIZE    003142          1222#
SRPSW   011736          2531*   2603    2629#
STACK = 001100           430#
START   002546           567    1157#
STKLMT= 177774           441#
STPSW   011734          2530*   2602    2628#
SWR     001040           632#   1173    1194*   1196    1202*   1209*   1211    1219    1420    1478    1657    1675    1724
                        1760    1792    1846    1885    1914    1946    1977    2373    2400    2431    2433    2490    2539
                        2578    2726    2738    2742    2817    2829*   2865    2881    3126    3163*
SWREG   000176           564#   1202    3126    3139
SW0   = 000001           494#
SW00  = 000001           484#    494
SW01  = 000002           483#    493
SW02  = 000004           482#    492
SW03  = 000010           481#    491
SW04  = 000020           480#    490
SW05  = 000040           479#    489
SW06  = 000100           478#    488
SW07  = 000200           477#    487
SW08  = 000400           476#    486
SW09  = 001000           475#    485
SW1   = 000002           493#
SW10  = 002000           474#
SW11  = 004000           473#
SW12  = 010000           472#
SW13  = 020000           471#
SW14  = 040000           470#
SW15  = 100000           469#
SW2   = 000004           492#
SW3   = 000010           491#
SW4   = 000020           490#
SW5   = 000040           489#
SW6   = 000100           488#
SW7   = 000200           487#
SW8   = 000400           486#
SW9   = 001000           485#
TBITVE= 000014           527#
TBUF    002354          1117#   1357    1376*   1381*   1429*   1432*   2085*   2088*   2108*   2135*   2169*   2192*   2214*
                        2248*   2286*   2323*   2352*   2378*   2404*   2438*   2467*   2498*   2552*   2613*   3872
TCLOCK  005056          1422    1650#
```



```
TCONS   003450          1290    1292#
TCSR    002352          1116#   1335    1377    1382    1394    1430    1435    1481    1492*   1493    1498*   1499    1510*
                        1512    1514*   1523    1536*   1537    1542*   1543    1555*   1557    1560*   1574    1584*   1585
                        1591*   1592    1597*   1599    1989*   1992    2002*   2007*   2016*   2021    2023*   2030*   2047*
                        2054    2056*   2066*   2079*   2084*   2086    2092*   2106*   2113*   2124*   2131*   2140*   2146*
                        2154*   2168*   2180*   2191*   2196*   2207*   2209*   2217*   2220*   2228*   2233*   2247*   2254*
                        2264*   2267*   2285*   2289*   2322*   2326*   2351*   2376*   2379    2383*   2403*   2408*   2415*
                        2420*   2424*   2436*   2437*   2441*   2462*   2479*   2482*   2544*   2545*   2559    2611*   3870
TKVEC = 000060           534#
TMP1    002340          1109#   1288*   1304*   1310    1311*
TMP2    002342          1110#   1223*   1231*   1241*   1245*   1249*   1269    2638    2680
TMP3    002344          1111#   1287*   1301    1303*   1309*
TOLER   006550          1969    1971#
TPSW    002364          1121#   1296    2049    2051*   2073*   2530    2534*   2602*
TPVEC = 000064           535#
TRAPVE= 000034           533#   1181*   1182*
TRTVEC= 000014           528#
TSTDEV  003500          1291    1301#   1306    2641
TSTDVM  003276          1247#   1252
TST1    003622          1298    1324    1332#   2683
TST10   004424          1521#
TST11   004572          1479    1513    1568#
TST12   004724          1558    1610#
TST13   005064          1654#
TST14   005134          1656    1658    1672#
TST15   005304          1674    1676    1717#
TST16   005474          1757#
TST17   005602          1759    1761    1779    1789#
TST2    003674          1354#
TST20   006020          1791    1793    1843#
TST21   006166          1845    1847    1882#
TST22   006302          1884    1886    1911#
TST23   006430          1913    1915    1943#
TST24   006604          1945    1947    1978    1988#
TST25   006704          2015#
TST26   007016          2046#
TST27   007144          2078#
TST3    003746          1375#
TST30   007250          2104#
TST31   007470          2159    2165#
TST32   007560          2179    2189#
TST33   007626          2198    2206#
TST34   007776          2241#
TST35   010140          2277#
TST36   010306          2315#
TST37   010422          2344#
TST4    004126          1407    1421    1428#
TST40   010530          2372#
TST41   010626          2374    2399#
TST42   010750          2401    2430#
TST43   011054          2432    2434    2458#
TST44   011154          2489#
TST45   011252          2491    2512    2523#
TST5    004162          1436    1445#
TST6    004214          1459#
TST7    004246          1477#
```

```
TVECT   002362          1120#   1570    1571*   1604*   1990    1991*   2001*   2009*   2019    2020*   2031*   2040*   2048
                        2050*   2062*   2072*   2082    2083*   2098*   2527    2533*   2599*
TYPE  = 104401          1416    1418    2663    2729    2764    2781    2783    2786    2788    2792    2799    2841    3001
                        3097    3137    3138    3141    3154    3165    3184    3233    3236    3240    3289#
TYPOC = 104402          2772    2796    3140    3290#
TYPON = 104404          3292#
TYPOS = 104403          3291#
VCTADR  003320          1243    1257#
VCTTBL  002454          1140#   1257    1319
VECT    003602          1320#   1323
WACTV   007270          2109#   2112
WAIT    015114          3341#   3342    3345
WDONE   007376          2136#   2139
WRPSW   012242          1572    1614    1680    1794    1812    1853    1865    1887    1896    1916    1925    1936    1994
                        2017    2032    2052    2063    2080    2089    2212    2243    2261    2283    2298    2317    2328
                        2346    2356    2525    2553    2688#
WT      007340          2125#   2127
XCONT   011674          2610    2613#
XMIT    011650          2533    2607#
XMTCNT  011730          2547*   2565    2607*   2626#   3888
XRET    011700          2612    2614#
$APTHD  000500           591     597#
$ASTAT= ****** U        1344    1366    1390    1404    1488    1506    1532    1551
$ATYC   013176          2903    2905#
$ATY1   013152          2901#
$ATY3   013160          2902#   2986
$ATY4   013170          1344    1366    1390    1404    1488    1506    1532    1551    2734    2904#
$AUTOB  001034           629#   3134    3255
$BASE   001142           691#   1146    1227    1235
$BDADR  001022           624#   1729*   1730*   1731    1733*   1734    1735*   1738*   3880
$BDDAT  001026           626#   2410*   2478*   2515*   2595*   3884    3886
$CHARC  013676          3003*   3013*   3020    3029*   3034#
$CKSWR  014130          3126#   3296
$CMTAG  001000           612#   1170    1171    1179    1185    1186
$CM3  = 000000           642#
$CNTLG  014655          3137    3250#
$CNTLU  014650          3154    3249#
$CPUOP  001114           665#
$CRLF   001063           644#   2729    2764    2783    2788    2792    3002    3037    3165    3249    3380
$DEVCT  001076           656#   1161*   1414    2637*   2638    2679*
$DEVM   001144           692#   1224*   1230*   1233*   1240*   1246    1289    1301
$DOAGN  012162          2659    2665    2671#
$ENDAD  012152           578    2667#   2749
$ENDCT  012132          1185    2661#
$ENULL  012166          2674#
$ENV    001106           661#   1215    2731    2910    2934    2981
$ENVM   001107           662#   1207    1217    2912    2983    2988
$EOP    012102          1979    2639    2652#
$EOPCT  012124          1185*   2658#   2662
$ERFLG  001003           615#   2719*   2856    2879    2885*   2895
$ERMAX  001015           621#   1187*   2891*   2895
$ERROR  012304          1179    2718#
$ERRPC  001016           622#   2723*   2724*   2725    2770    3870    3872    3874    3876    3878    3880    3882    3884
                        3886    3888    3890
$ERRTB  001146           709#   2778
$ERRTY  012466          2728    2763#
```



```
$ERTTL  001012           619#   2722*
$ESCAP  001060           642#   1186*   2745    2747    2890*
$ETABL  001106           660#
$ETEND  001146           603     693#
$FATAL  001070           653#   1157*   2938*
$FFLG   013416          2901*   2904*   2932    2941*   2949#
$FILLC  001056           640#   3006    3037
$FILLS  001055           639#   3037
$GDADR  001020           623#   1726*   1728*   1729    1731    1736    3880
$GDDAT  001024           625#   1734*   1738    2477*   2514*   2596*   3886
$GET42  012142          2664#
$GTSWR  014200          3138#   3294
$HIBTS  000500           598#
$ICNT   001004           616#
$ILLUP  012762          2809    2827    2844#
$INTAG  001035           630#   3166    3255
$ITEMB  001014           620#   2725*   2733    2767
$LF     001064           645#   3037    3240    3249
$LFLG   013415          2942*   2948#
$LPADR  001006           617#   1188*   2883*   2888*   2893    2895
$LPERR  001010           618#   1189*   2744    2883    2889*   2895
$MADR1  001120           678#
$MADR2  001124           682#
$MADR3  001130           685#
$MADR4  001134           688#
$MAIL   001066           599     603     651#   1206    2887    2981
$MAMS1  001116           672#
$MAMS2  001122           680#
$MAMS3  001126           683#
$MAMS4  001132           686#
$MBADR  000502           599#
$MFLG   013414          2902*   2908    2943*   2947#
$MNEW   014673          3141    3253#
$MSGAD  001102           658#   2918*   2921
$MSGLG  001104           659#   2923*
$MSGTY  001066           652#   1158*   2916    2924*   2936    2939*
$MSWR   014662          3138    3251#
$MTYP1  001117           673#
$MTYP2  001123           681#
$MTYP3  001127           684#
$MTYP4  001133           687#
$NULL   001054           638#   3008    3037
$NWTST= 000001          1329#   1351#   1372#   1425#   1442#   1456#   1474#   1518#   1565#   1607#   1651#   1669#   1714#
                        1754#   1786#   1840#   1879#   1908#   1940#   1985#   2012#   2043#   2075#   2101#   2162#   2186#
                        2203#   2238#   2274#   2312#   2341#   2369#   2396#   2427#   2455#   2486#   2520#
$OCNT   014124          3069*   3098*   3111#
$OMODE  014126          3064*   3068*   3073    3076*   3087*   3113#
$OVER   013136          2866    2884    2892#
$PASS   001074           655#   1206*   1412    2655*   2656*   2674
$PASTM  000506           601#
$POWER  012770          2842    2847#
$PWRDN  012622          1183    2809#   2836
$PWRMG  012756          2842#
$PWRUP  012674          2819    2827#
$QUES   001062           643#   3037    3184    3233    3249
$RDCHR  014412          3197#   3297
```

```
$RDDEC= ****** U        3299
$RDLIN  014532          3225#   3298
$RDOCT= ****** U        3299
$RDSZ = 000010          3218#
$RTNAD  012164          2673#
$R2A  = ****** U        3299
$SAVRE= ****** U        3299
$SAVR6  012766          2818*   2828    2838*   2839*   2846#
$SCOPE  013000          1177    2863#
$SETUP= 000137           560#   1176    1177    1179    1181    1183    1185    1186    1188    2654    2864    3121    3255
$STUP = 177777           560#
$SVLAD  013102          2874    2880    2886#
$SVPC = 000500           576#    581
$SWR  = 161000           541#    642     643    1186    1188    1189    1333    1355    1376    1429    1446    1460    1478
                        1522    1569    1611    1655    1673    1718    1758    1790    1844    1883    1912    1944    1989
                        2016    2047    2079    2105    2166    2190    2207    2242    2278    2316    2345    2373    2400
                        2431    2459    2490    2524    2649    2655    2666    2672    2674    2857    2858    2859    2860
                        2865    2877    2879    2880    2881    2886    2889    2892    2895
$SWREG  001110           663#   1209
$SWRMK= 000000          2860
$TESTN  001072           654#   1159*   2887*   3870    3872    3874    3876    3878    3880    3882    3884    3886    3888
                        3890
$TKB    001046           635#   3119    3130    3147    3201    3207
$TKS    001044           634#   3119    3128    3144    3168*   3199    3205
$TN   = 000046           540#   1329    1333#   1351    1355#   1372    1376#   1425    1429#   1442    1446#   1456    1460#
                        1474    1478#   1518    1522#   1565    1569#   1607    1611#   1650    1651    1655#   1669    1673#
                        1714    1718#   1754    1758#   1786    1790#   1840    1844#   1879    1883#   1908    1912#   1940
                        1944#   1985    1989#   2012    2016#   2043    2047#   2075    2079#   2101    2105#   2162    2166#
                        2186    2190#   2203    2207#   2238    2242#   2274    2278#   2312    2316#   2341    2345#   2369
                        2373#   2396    2400#   2427    2431#   2455    2459#   2486    2490#   2520    2524#
$TPB    001052           637#   3026*   3037
$TPFLG  001057           641#   2975    3037
$TPS    001050           636#   3024    3037
$TRAP   014704          1181    3266#
$TRAP2  014726          3277#   3288
$TRP  = 000011          3281#   3290#   3291#   3292#   3293#   3294    3295#   3296    3297#   3298#   3299#
$TRPAD  014740          3271    3288#
$TSTM   000504           600#
$TSTNM  001002           614#   1650*   2636*   2654*   2721    2856    2886*   2887    2892    2895
$TTYIN  014640          3226    3227    3244    3248#
$TYPBN= ****** U        3293
$TYPDS= ****** U        3293
$TYPE   013420          2929    2975#   3281    3289
$TYPEC  013632          3005    3012    3019    3024#   3025    3170
$TYPEX  013700          3030    3032    3035#
$TYPOC  013726          3067#   3290
$TYPON  013742          3066    3069#   3292
$TYPOS  013702          3062#   3291
$UNIT   001100           657#   1162*   1305*   1308*   2685*
$UNITM  000510           602#
$USWR   001112           664#   1163    1165*   2471    2508
$VECT1  001136           689#   1258
$VECT2  001140           690#
$XTSTR  013012          2868#
$$GET4= 000000          2666#
$OFILL  014125          3063*   3067*   3077    3112#
```



```
$40CAT= ****** U        2865
.     = 022360           545#    551     552#    556#    562#    566#    571#    576     577#    579#    581#    587     588#
                         590#    592#    611#    646    1139#   1140#   1174    1188    1189    2631#   2674    2675#   2802#
                        2821    2845    2895    2951#   3037    3119    3248#   3249    3255    3358#
.$ERRT  001146           711#
.$X   = 000500           587#    592
```

```
. ABS.  022360     000

 ERRORS DETECTED:  0

 DSKZ:CZDLDC,DSKZ:CZDLDC.SEQ=DSKZ:CZDLDC.P11
 RUN-TIME: 25 14 1 SECONDS
 RUN-TIME RATIO: 357/41=8.6
 CORE USED:  21K  (41 PAGES)

 DOCUMENT PAGES:  103
```