

---

## Configuring for Cut Sheet Emulation

To enable cut-sheet emulation, ensure that your printer has a microcode level of at least 9.216, then ensure that the appropriate personnel perform the following tasks at your installation on the systems specified:

1. At the Infoprint AIX server, the print administrator for your installation must disable the physical printer that you intend to run in cut sheet emulation mode.
2. At the printer console, an operator must set the printer to cut-sheet emulation mode.
3. The operator must then restart the printer.
4. At the Infoprint AIX server, the print administrator must create a logical printer for the physical printer.
5. The print administrator must ensure that both the logical and physical printer has been enabled.

To submit a job, see "Using Cut Sheet Emulation."