

AIX and VIO Software Levels supporting POWER7 & POWER7+ Hardware**

2013-06-20

Name	MTM	AIX 7.1			AIX 6.1						AIX 5.3 - Extended Support*				VIO Server			
		TL02	TL01	TL00	TL08	TL07	TL06	TL05	TL04	TL03	TL02	TL12	TL11	TL10	TL09	v2.2	v2.1	
"D" Models POWER7+	Power 710+	8231-E1D	SP2	SP7	SP9	SP2	SP7	SP11	none	none	none	none	SP8	none	none	none	2.2.2 or 2.2.1.6	none
	Power 720+	8202-E4D	SP2	SP7	SP9	SP2	SP7	SP11	none	none	none	none	SP8	none	none	none	2.2.2 or 2.2.1.6	none
	Power 730+	8231-E2D	SP2	SP7	SP9	SP2	SP7	SP11	none	none	none	none	SP8	none	none	none	2.2.2 or 2.2.1.6	none
	Power 740+	8205-E6D	SP2	SP7	SP9	SP2	SP7	SP11	none	none	none	none	SP8	none	none	none	2.2.2 or 2.2.1.6	none
	Power 750+	8408-E8D	SP2	SP7	SP9	SP2	SP7	SP11	none	none	none	none	SP8	none	none	none	2.2.2 or 2.2.1.6	none
	Power 760+	9109-RMD	SP2	SP7	SP9	SP2	SP7	SP11	none	none	none	none	SP8	none	none	none	2.2.2 or 2.2.1.6	none
	Power 770+	9117-MMD	base	SP6	SP8	base	SP6	SP10	none	none	none	none	SP7	none	none	none	2.2.2 or 2.2.1.5	none
	Power 780+	9179-MHD	base	SP6	SP8	base	SP6	SP10	none	none	none	none	SP7	none	none	none	2.2.2 or 2.2.1.5	none
"C" Models (PCIe-Gen2)	Power 710	8231-E1C	base	base	SP4	base	base	SP6	SP7	none	none	none	SP5	none	none	none	2.2.1	none
	Power 720	8202-E4C	base	base	SP4	base	base	SP6	SP7	none	none	none	SP5	none	none	none	2.2.1	none
	Power 730	8231-E2C	base	base	SP4	base	base	SP6	SP7	none	none	none	SP5	none	none	none	2.2.1	none
	Power 740	8205-E6C	base	base	SP4	base	base	SP6	SP7	none	none	none	SP5	none	none	none	2.2.1	none
	Power 770	9117-MMC	base	base	SP4	base	base	SP6	SP7	none	none	none	SP5	none	none	none	2.2.1	none
	Power 780	9179-MHC	base	base	SP4	base	base	SP6	SP7	none	none	none	SP5	none	none	none	2.2.1	none
"B" Models (PCIe-Gen1)	Power 710	8231-E2B	base	base	base	base	base	base	SP3	SP7	SP7	none	SP1	SP5	SP5	none	base	none
	Power 720	8202-E4B	base	base	base	base	base	base	SP3	SP7	SP7	none	SP1	SP5	SP5	none	base	none
	Power 730	8231-E2B	base	base	base	base	base	base	SP3	SP7	SP7	none	SP1	SP5	SP5	none	base	none
	Power 740	8205-E6B	base	base	base	base	base	base	SP3	SP7	SP7	none	SP1	SP5	SP5	none	base	none
	Power 750	8233-E8B	base	base	base	base	base	base	base	SP2	SP5	SP8	base	SP2	SP4	SP7	base	2.1.2.11 FP 22.1 w/ SP1
	Power 755	8236-E8C	base	base	base	base	base	base	base	SP2	SP5	SP8	base	SP2	SP4	SP7	base	
	Power 770	9117-MMB	base	base	base	base	base	base	base	SP3	SP5	SP8	base	SP2	SP4	SP7	base	none
	Power 780	9179-MHB	base	base	base	base	base	base	base	SP3	SP5	SP8	base	SP2	SP4	SP7	base	none
Power 795	9119-FHB	base	base	base	base	base	base	SP3	SP7	SP7	none	SP1	SP5	SP5	none	base	none	
PureFlex	p260	7895-22X	base	SP4	SP6	base	SP4	SP8	none	none	none	none	SP6	none	none	none	2.2.1.4	none
	p260+	7895-23X	base	SP7	SP9	base	SP7	SP11	none	none	none	none	SP7	none	none	none	2.2.2 or 2.2.1.5	none
	p460	7895-42X	base	SP4	SP6	base	SP4	SP8	none	none	none	none	SP6	none	none	none	2.2.1.4	none
Power Blades	PS700	8406-70Y	base	base	base	base	base	base	SP7	SP7	none	base	SP5	SP5	none	base	2.1.3	
	PS701	8406-71Y	base	base	base	base	base	base	SP7	SP7	none	base	SP5	SP5	none	base	2.1.3	
	PS702	8406-71Y	base	base	base	base	base	base	SP7	SP7	none	base	SP5	SP5	none	base	2.1.3	
	PS703	7891-73X	base	base	SP3	base	base	SP5	SP6	SP10	none	none	SP4	SP7	none	none	2.2.0.12 FP24-SP2	none
	PS704	7891-74X	base	base	SP3	base	base	SP5	SP6	SP10	none	none	SP4	SP7	none	none	2.2.0.12 FP24-SP2	none

Support Lifecycles <http://www-01.ibm.com/software/support/ aix/lifecycle/index.html>

Certain components (drawers, adapters, firmware) may require higher software levels

Prerequisite Site: https://www-912.ibm.com/e_dir/eserverprereq.nsf