

ML11

PERF EXERCISER
CZMLBBO

AH-S430B-MC
FICHE 1 OF 2

JUL 1982
COPYRIGHT © 81-82
MADE IN USA



ML11

PERF EXERCISER
CZMLBBO

AH-S430B-MC
FICHE 2 OF 2

JUL 1982
COPYRIGHT © 81-82
MADE IN USA



The main body of the document is a large grid of 14 columns and 20 rows of small, illegible text or data. The text is too faint to be transcribed accurately. A vertical barcode is located at the bottom right of the grid area.

.REM 8

IDENTIFICATION

PRODUCT CODE: AC-S428B-MC
PRODUCT NAME: CZMLBBO ML11 PERFORMANCE EXERCISER
PRODUCT DATE: 19-MAR-82
MAINTAINER: MEMORY DIAGNOSTICS ENGINEERING
AUTHOR: MICHELE D. ROSEN

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1981, 1982 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL
DEC

PDP
DECUS

UNIBUS
DECTAPE

MASSBUS

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.5	SOFTWARE QUESTIONS
2.6	EXTENDED P-TABLE DIALOGUE
2.7	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES
7.0	MAINTENANCE HISTORY

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THE ML11 PERFORMANCE EXERCISER IS A BLISS PROGRAM WHICH RUNS UNDER THE PDP-11 DIAGNOSTIC SUPERVISOR AND WHICH EXERCISES UP TO 8 ML11 UNITS ON A SINGLE RH CONTROLLER. AN ML11 UNIT IS A FAST, RANDOM ACCESS, BLOCK MODE MOS MEMORY SYSTEM WITH ECC CAPABILITY. IT IS MADE UP OF 3 CONTROL MODULES AND UP TO 16 ARRAY MODULES. IT IS A MASSBUS DEVICE, AND AS SUCH, CONFORMS TO MASSBUS STANDARDS.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

1. PDP-11 WITH 28K WORDS OF MEMORY
2. CONSOLE TERMINAL
3. RH11 OR RH70 CONTROLLER
4. 1 TO 8 ML11A OR ML11B DRIVES
5. XXDP+ LOAD MEDIA

1.3 RELATED DOCUMENTS AND STANDARDS

THE HARDWARE DESIGN IS EXPECTED TO CONFORM TO THE STANDARDS SET FORTH IN THE MASSBUS SPECIFICATION (DEC STANDARD 159).

THE FOLLOWING DOCUMENTATION MAY PROVE USEFUL IN LEARNING MORE ABOUT THE ML11:

1. ML11 ENGINEERING SPECIFICATION
2. RWS04 FIXED-HEAD DISK SUBSYSTEM USER'S MANUAL
3. THE ML11 PERFORMANCE EXERCISER'S PROGRAM LISTING
4. THE ML11 LOGIC TEST'S SPECIFICATIONS AND LISTINGS
5. ML11 PROJECT PLAN
6. XXDP+ USER'S MANUAL (CHQUS)
7. PDP-11 DIAGNOSTIC SUPERVISOR DOCUMENTATION (SUPINT, SUPFUN,

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

ML11 SUBSYSTEM FAULTS WILL BE DETECTED BUT NOT ISOLATED, SINCE OTHER DIAGNOSTICS WILL BE AVAILABLE FOR TROUBLESHOOTING THE EXACT CAUSE OF

FAILURE. A LIST OF AVAILABLE DIAGNOSTIC TOOLS IS INCLUDED IN APPENDIX A OF THE ML11 FUNCTIONAL SPECIFICATION.

1.5 ASSUMPTIONS

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A VERY BRIEF DESCRIPTION OF THOSE PARTS OF THE DIAGNOSTIC RUNTIME SERVICES OF THE PDP-11 DIAGNOSTIC SUPERVISOR WHICH ARE APPLICABLE FOR THIS EXERCISER. CONSULT THE XXDP+ USER'S MANUAL (CHOUS) FOR MORE DETAILS.

2.1 COMMANDS

THE FOLLOWING IS A LIST OF THE 11 COMMANDS AVAILABLE TO THE DRS. ANY COMMAND IS RECOGNIZED BY ITS FIRST 3 CHARACTERS, AND MANY COMMANDS MAY BE MODIFIED BY OPTIONAL SWITCHES WHICH ARE DESCRIBED IN THE NEXT SECTION.

DRS COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ^C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO THE XXDP+ MONITOR
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

2.2 SWITCHES

SWITCHES ARE USED TO MODIFY PROGRAM OPERATION, AND ARE APPENDED TO COMMANDS. THE SWITCHES WHICH HAVE MEANING FOR THIS EXERCISER AND INFORMATION ABOUT THEIR USE ARE GIVEN IN THE FOLLOWING TWO TABLES.

SWITCH	EFFECT
/PASS:DDDD	EXECUTE DDDD PASSES (DDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS (SEE SECTION 2.3)
/EOP:DDDD	REPORT END OF PASS MESSAGE AFTER EVERY

DDDDD PASSES ONLY (DDDDD = 1 TO 64000).

/UNITS:LIST TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED
 IN THE LIST. LIST EXAMPLE: /UNITS:0:3:5-7
 USE UNITS 0,3,5,6,7 (UNIT NUMBERS = 0-7)

EXAMPLE OF SWITCH USAGE:

START/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE:

1. ALL UNITS WILL BE TESTED 1000 TIM
2. THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY.

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	PASS	FLAGS	EOP	UNITS
START	X	X	X	X
RESTART	X	X	X	X
CONTINUE	X	X	X	
PROCEED		X		
DROP				X
ADD				X
PRINT				
DISPLAY				X
FLAGS				
ZFLAGS				
EXIT				

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATION PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS. THEY REMAIN SET OF CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO DRS COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBE*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)

IXE*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
BOE	'BELL' ON ERROR
ISR	INHIBIT STATISTICAL REPORTS
IDU	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE

* ERROR MESSAGES ARE DESCRIBED IN SECTION 4.7

SEE THE XXDP+ USER'S MANUAL FOR MORE DETAILS ON FLAGS. MORE THAN ONE FLAG MAY BE SPECIFIED WITH THE /FLAGS SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A 'BELL' ON ERROR, YOU MAY USE THE FOLLOWING STRING:

/FLAGS:LOE:IER:BOE

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE DIAGNOSTIC RUNTIME SERVICES PROMPTS THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?". YOU MUST ANSWER 'Y' AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN PRELOADED USING THE SETUP UTILITY (SEE CHAP. 6 OF THE XXDP+ USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A 'Y' THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL). YOU WILL THEN BE ASKED THE FOLLOWING QUESTIONS FOR EACH UNIT:

2.4.1 QUESTIONS AND ANSWERS

1. CSR ADDRESS (172000) 0?

ANSWER: THE CSR ADDRESS OF THE RM CONTROLLER (OCTAL, DEFAULT 172000).

2. INTERRUPT VECTOR (204) 0?

ANSWER: THE INTERRUPT VECTOR ADDRESS (OCTAL, DEFAULT 204).

3. BR LEVEL FOR INTERRUPT (5) 0?

ANSWER: THE BUS REQUEST LEVEL FOR INTERRUPT (OCTAL, DEFAULT 5).

4. DRIVE NUMBER (0) 0?

ANSWER: THE PHYSICAL DRIVE NUMBER(S) OF THE DRIVE(S) TO BE TESTED (OCTAL, {0-7}, DEFAULT 0).

2.4.2 SUMMARY OF HARDWARE QUESTION SEQUENCE

```
*****  
* # UNITS? *  
*          *  
*****  
|  
*****  
* CSR ADDRESS? *  
*          *  
*****  
|  
*****  
* VECTOR? *  
*          *  
*****  
|  
*****  
* BR LEVEL? *  
*          *  
*****  
|  
*****  
* DRIVE NUMBER? *  
*          *  
*****
```

2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS, OR AFTER A RESTART OR OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

INCLUDED IN THIS SECTION ARE QUESTIONS ABOUT PARAMETERS WHICH AFFECT PROGRAM OPERATION. REQUESTS FOR SOFTWARE OPTIONS SHOULD BE DISCUSSED AND INCORPORATED INTO THIS SPECIFICATION AS SOON AS POSSIBLE, AND CERTAINLY BEFORE SIGNOFF TIME.

IF A ^Z (CONTROL-Z) IS TYPED AS THE ANSWER TO ANY QUESTION, THE PROGRAM WILL START TO EXECUTE.

IF A ^C (CONTROL-C) IS TYPED AT ANY TIME, CONTROL WILL RETURN TO THE DIAGNOSTIC SUPERVISOR.

2.5.1 QUESTIONS AND ANSWERS

1. LIMIT RANGE OF SECTORS TO BE TESTED (N) L?

ANSWER: TO TEST ONLY A CERTAIN RANGE OF SECTORS INSTEAD OF AN ENTIRE UNIT. ALTHOUGH THIS QUESTION IS NOT OPTIONAL, IT SHOULD BE ANSWERED 'NO' UNLESS THE ANSWER TO THE HARDWARE QUESTION '# UNITS ?' WAS 1.
(LOGICAL, {Y TO TEST PARTIAL UNIT, N FOR ENTIRE UNIT}, DEFAULT N).

THE QUESTIONS WHICH FOLLOW ARE OPTIONAL, AND DEPEND ON AN AFFIRMATIVE ANSWER TO THE PREVIOUS QUESTION:

2. DO YOU KNOW THE EXACT RANGE OF SECTORS TO BE TESTED (N) L?

ANSWER: THIS DECIDES WHETHER TO ASK FOR SECTOR NUMBERS OR BOARD NUMBER.

THE NEXT TWO QUESTIONS WILL BE ASKED ONLY IF QUESTION 2 IS ANSWERED YES:

3. FIRST SECTOR TO TEST (O) O?

ANSWER: THE SECTOR NUMBER WHERE TESTING BEGINS
(OCTAL, {0-7777 FOR ML11A, 0-37777 FOR ML11B},
DEFAULT 0).

4. LAST SECTOR TO TEST (LAST) O?

ANSWER: THE LAST SECTOR NUMBER TO BE TESTED
(OCTAL, {0-7777 FOR ML11A, 0-37777 FOR ML11B},
DEFAULT 37777).

THE NEXT QUESTION WILL BE ASKED ONLY IF QUESTION 2 IS ANSWERED NO:

5. WHICH BOARD {1-16} SHOULD BE TESTED (1) D?

ANSWER: THE NUMBER OF THE ONLY BOARD TO BE TESTED
(DECIMAL, {1-16}, DEFAULT 1).

6. THE PROGRAM OPTIONS INCLUDE:

1. ADDRESS CHECK
2. PATTERN TEST

3. UNIQUE DATA CHECK
4. MARCH TEST
5. RANDOMNESS TESTS

DO YOU WANT TO DROP ANY OF THESE FROM THE EXERCISER (N) L?

ANSWER: THIS DECIDES WHETHER TO ASK FOR OPTION NUMBERS.
(LOGICAL, {Y FOR PARTIAL EXERCISER, N FOR COMPLETE EX-
ERCISER}, DEFAULT N).

THE FOLLOWING SET OF QUESTIONS WILL BE ASKED ONLY IF QUESTION
6 IS ANSWERED YES:

7. DROP OPTION 1 (N) L?
8. DROP OPTION 2 (N) L?
9. DROP OPTION 3 (N) L?
10. DROP OPTION 4 (N) L?
11. DROP OPTION 5 (N) L?
12. ENABLE REFRESH MARGINING (N) L?

ANSWER: NORMAL OPERATION IS WITHOUT REFRESH MARGINING.
(LOGICAL, {Y TO ENABLE, N TO DISABLE}, DEFAULT N).

13. DISABLE ERROR CORRECTION (N) L?

ANSWER: NORMAL OPERATION IS WITH ECC ENABLED.
(LOGICAL, {Y TO DISABLE, N TO ENABLE}, DEFAULT N).


14. ENABLE END OF PASS SUMMARY PRINTOUT (N) L?

ANSWER: NORMAL OPERATION IS WITHOUT END OF PASS SUMMARY PRINTOUT.
(LOGICAL, {Y TO ENABLE, N TO DISABLE PRINTOUT}, DEFAULT N).


15. ENABLE ERROR PRINTOUTS (N) L?

ANSWER: NORMAL OPERATION IS WITHOUT ERROR PRINTOUTS.
(LOGICAL, {Y TO ENABLE, N TO DISABLE PRINTOUT}, DEFAULT N).

2.5.2 SUMMARY OF SOFTWARE QUESTION SEQUENCE



(CONTINUED ON NEXT PAGE)



```

          *****
          <-----!
          |
          | *****
          | * ENABL REFRESH *
          | * MARGINING?   *
          | *****
          |
          | *****
          | *   DISABLE   *
          | *   ECC?     *
          | *****
          |
          | *****
          | *   ENABLE   *
          | * EOP SUMMARY? *
          | *****
          |
          | *****
          | *   ENABLE   *
          | * PRINTOUTS? *
          | *****
  
```

2.6 EXTENDED P-TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE, SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THE DIALOGUE BECOMES TEDIOUS BECAUSE MOST OF THE ANSWERS ARE REPETITIOUS.

SUPPOSE YOU ARE TESTING A HYPOTHETICAL DEVICE, THE XY11 WHICH IS MADE UP OF ONE CONTROL MODULE WITH 8 UNITS (SUB-DEVICES). THESE 8 UNITS, NUMBERED 0 THROUGH 7, HAVE JUST ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS, CALLED THE Q-FACTOR.

THE 3 EXAMPLES WHICH FOLLOW SHOW DIFFERENT WAYS OF ANSWERING THE HARDWARE QUESTIONS TO ACHIEVE IDENTICAL RESULTS. IN EACH EXAMPLE, THERE ARE TO BE 8 XY11'S TESTED WHICH HAVE THE FOLLOWING Q-FACTORS:

UNIT #	Q-FACTOR
0	0
1	1
2	0
3	0
4	0
5	0
6	1
7	1

EXAMPLE 1: ANSWER SEPARATELY FOR EACH UNIT

```
# UNITS (D) ? 8<CR>

UNIT 0
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 0<CR>
Q-FACTOR (O) 0 ? 0<CR>

UNIT 1
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 1<CR>
Q-FACTOR (O) 0 ? 1<CR>

UNIT 2
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 2<CR>
Q-FACTOR (O) 1 ? 0<CR>

UNIT 3
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 3<CR>
Q-FACTOR (O) 0 ? <CR>

UNIT 4
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 4<CR>
Q-FACTOR (O) 0 ? <CR>

UNIT 5
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 5<CR>
Q-FACTOR (O) 0 ? 1<CR>

UNIT 6
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 6<CR>
Q-FACTOR (O) 1 ? 1<CR>

UNIT 7
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 7<CR>
Q-FACTOR (O) 1 ? <CR>
```

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE, THE HARDWARE PARAMETERS DO NOT DIFFER SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

EXAMPLE 2: USE THE MULTIPLE SPECIFICATION FEATURE OF THE RUNTIME SERVICES TO MAKE FEWER PASSES THROUGH THE QUESTIONS.

UNITS (D) ? 8<CR>

UNIT 0
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 0,1<CR>

UNIT 2
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 1 ? 0<CR>

UNIT 6
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1,1<CR>

AS YOU CAN SEE IN THE ABOVE DIALOGUE, RUNTIME SERVICES

WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. THE FIRST PASS BUILDS 2 ENTRIES, BECAUSE 2 SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE DRS ASSUMES THAT THE CSR ADDRESS IS 160000 FOR BOTH UNITS. IN THE SECOND PASS, 4 ENTRIES WERE BUILT. THE "-" CONSTRUCT TELLS THE DRS TO INCREMENT THE DATA FROM THE FIRST VALUE TO THE SECOND. IN THIS CASE, "2-5" SPECIFIES SUB-DEVICES 2,3,4, AND 5. THE CSR ADDRESS AND Q-FACTOR FOR THE 4 ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST 2 UNITS ARE SPECIFIED IN THE THIRD PASS.

EXAMPLE 3: ACCOMPLISH THE WHOLE PROCESS IN JUST ONE PASS THROUGH THE QUESTIONS.

UNITS (D) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0-7<CR>
Q-FACTOR (0) 0 ? 0,1,0,,,,,1,1<CR>

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS
ENCLOSING A BLANK FIELD) DIRECT THE DRS TO REPEAT THE
LAST REPLY.

2.7 QUICK START-UP PROCEDURE

2.7.1 TO START-UP THIS PROGRAM WHEN RUNNING UNDER XXDP+

1. BOOT XXDP+
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ QUESTIONS
3. TYPE 'R NAME', WHERE 'NAME' IS THE FILENAME OF THE
.BIN OR .BIC FILE FOR THIS PROGRAM
4. TYPE 'START'
5. ANSWER THE 'CHANGE HW' QUESTION WITH 'Y'
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE 'CHANGE SW' QUESTION WITH 'N'

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE
DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THE DEFAULTS
ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

2.7.2 TO START-UP THIS PROGRAM WHEN RUNNING UNDER ACT

THE FILE WHICH WILL BE STARTED MUST, AT SOME TIME, HAVE BEEN CREATED
WITH THE 'SETUP' UTILITY PROGRAM. ASSUMING THAT THIS HAS BEEN DONE,
THE START-UP PROCEDURE IS THE SAME AS THE ONE IN SECTION 2.7.1.

TO CREATE A FILE USING THE SETUP UTILITY:

1. TYPE 'R SETUP'
2. THE TARGET ENVIRONMENT IS ACT, SO TYPE 'AC'
3. TYPE THE SETUP COMMAND:
*SETUP OUTFILE.EXT=INFILE.EXT
WHERE OUTFILE.EXT = THE NEWLY CREATED FILE
AND INFILE.EXT = THE RELEASED .BIN FILE
4. YOU WILL HAVE AN OPPORTUNITY TO SET UP A PERMANENT
DEFAULT TEST CONFIGURATION BY ANSWERING THE HARDWARE
AND SOFTWARE QUESTIONS. ONCE THIS IS DONE, YOU WILL
NO LONGER BE FORCED TO ANSWER 'Y' TO 'CHANGE HW ?'
EVERY TIME YOU START THE PROGRAM. YOU WILL ALSO BE
ASKED THE LSI AND 50HZ QUESTIONS HERE.
5. TYPE 'EXIT'

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE 'IER' FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE

WHERE:

NAME = DIAGNOSTIC NAME
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
NUMBER = ERROR NUMBER
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE 'IER' OR 'IBR' FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE 'IER', 'IBR' OR 'IXR' FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

3.2.1 MESSAGES DURING INITIALIZATION

DURING INITIALIZATION, THERE ARE 3 ERROR CONDITIONS WHICH CAN BE DETECTED AND WHICH CAUSE THE DRIVE TO BE DROPPED:

CAUSE1 = ' (NOT POWERED UP) '
CAUSE2 = ' (NOT AN ML11 UNIT) '
CAUSE3 = ' (OPERATOR SELECTED TEST LIMITS INCORRECTLY) '

THE 'CAUSE3' MESSAGE IS THEN FOLLOWED BY
EITHER: '!TOP SECTOR OF XXXXXX EXCEEDS SYSTEM LIMIT OF YYYYYY'
OR: '!LOW SECTOR OF XXXXXX EXCEEDS TOP SECTOR OF YYYYYY'

3.2.2 MESSAGES DURING TESTING

AFTER INITIALIZATION, THERE ARE 4 ERROR DIAGNOSES WHICH ARE POSSIBLE:

MSG1 = '--> RUN ML11 LOGIC TEST'

THIS MESSAGE APPEARS WHEN AN ML11

SYSTEM ERROR OCCURS. THE USER IS INSTRUCTED TO RUN THE LOGIC TEST TO SEE IF THAT PROGRAM CAN ISOLATE THE REASON FOR THE FAILURE. NOTE THAT THIS MESSAGE IS NOT USED FOR DATA ERRORS.

MSG2 = '--> RUN ML11 PROM MAINTENANCE PROGRAM'

THIS MESSAGE APPEARS WHENEVER ANY OF THE FOLLOWING CONDITIONS IS TRUE:

- A) AN ECC HARD ERROR (ECH OR UNC) IS DETECTED
- B) AN ARRAY REACHES ITS HARD OR SOFT ERROR THRESHOLD
- C) DURING A PERFORMANCE SUMMARY, IF AN ARRAY HAS REACHED OR EXCEEDED ITS HARD OR SOFT ERROR THRESHOLD.

MSG3 = 'SOFT ERROR'

A SOFT ERROR IS A CORRECTABLE DATA ERROR WHICH CAN BE ELIMINATED BY REWRITING AND REREADING.

MSG4 = 'HARD ERROR'

A HARD ERROR IS A CORRECTABLE DATA ERROR WHICH PERSISTS AFTER A REWRITE AND A REREAD.

ANY WRITE COMMAND HAS 3 POSSIBLE ERROR CALLS ASSOCIATED WITH IT:

ERROR POSITION	ERROR TYPE	DIAGNOSTIC MESSAGE	CAUSE OF ERROR/ACTION
1ST	ERRDF	MSG1	ALL 6 RETRIES FAILED FOR AN ML11 SYSTEM ERROR WHICH WAS ORIGINALLY CONSIDERED TO BE NON-FATAL. DROP THE DRIVE.
2ND	ERRDF	MSG1	CONTROLLER FATA. ERROR. DROP THE DRIVE.
3RD	ERRDF	MSG1	DRIVE FATAL ERROR. DROP THE DRIVE.

ANY READ OR WRITE CHECK COMMAND HAS 8 ERROR CALLS ASSOCIATED WITH IT, 5 FOR SYSTEM ERRORS (WHICH RESULT IN DROPPING THE DRIVE) AND 3 FOR HARD AND SOFT DATA ERRORS (WHICH ARE COUNTED ON A PER ARRAY BASIS):

THE SYSTEM ERRORS:

ERROR ERROR DIAGNOSTIC

POSITION	TYPE	MESSAGE	CAUSE OF ERROR/ACTION
1ST	ERRDF	MSG1	AFTER A SUCCESSFUL READ COMMAND, THE WRITE AND READ BUFFERS ARE COMPARED. IF THEY DO NOT MATCH PERFECTLY, THEN THE ECC LOGIC FAILED. DROP THE DRIVE.
2ND	ERRDF	MSG1	ALL 6 RETRIES FAILED FOR AN ML11 SYSTEM ERROR WHICH WAS ORIGINALLY CONSIDERED TO BE NON-FATAL. DROP THE DRIVE.
3RD	ERRDF	MSG1	CONTROLLER FATAL ERROR. DROP THE DRIVE.
4TH	ERRDF	MSG1	DRIVE FATAL ERROR. DROP THE DRIVE.
5TH	ERRDF	MSG2	ECC HARD ERROR DETECTED. DROP THE DRIVE.

THE DATA ERRORS:

ERROR POSITION	ERROR TYPE	DIAGNOSTIC MESSAGE	CAUSE OF ERROR/ACTION
6TH	ERRHRD	MSG4	HARD ERROR. DURING ERROR CLASSIFICATION, RETRY FAILED AGAIN (AS IF A DATA ERROR IN THE SAME BIT POSITION). UPDATE THE HARD COUNT FOR THE ASSOCIATED ARRAY AND CHECK THE NEW COUNT AGAINST THE THRESHOLD.
7TH	ERRSOFT	MSG3	SOFT ERROR. DURING ERROR CLASSIFICATION, RETRY FAILED AGAIN (AS IF A DATA ERROR IN A DIFFERENT BIT POSITION). UPDATE THE SOFT COUNT FOR THE ASSOCIATED ARRAY AND CHECK THE NEW COUNT AGAINST THE THRESHOLD.
8TH	ERRSOFT	MSG3	SOFT ERROR. DURING ERROR CLASSIFICATION, RETRY DID NOT PRODUCE ANOTHER DATA ERROR (THE RETRY MAY PASS, OR IT MAY FAIL FOR SOME NEW REASON). UPDATE THE SOFT COUNT FOR THE ASSOCIATED ARRAY AND CHECK THE NEW COUNT AGAINST THE THRESHOLD.

THERE IS A CORRESPONDENCE BETWEEN EVERY NUMBER AND THE PLACE IN THE PROGRAM WHERE THE ERROR WAS DETECTED:

A) THE MOST SIGNIFICANT DIGIT IDENTIFIES THE OPTION NUMBER.

EXCEPTION: THE COMMAND INTEGRITY ROUTINE IS THOUGHT OF AS OPTION 0, AND SO ALL ITS ERROR NUMBERS WILL APPEAR TO ONLY BE 1 OR 2 SIGNIFICANT DIGITS. TAKE THE 0 TO BE A SIGNIFICANT DIGIT (SEE EXAMPLES).

B) THE 2 LEAST SIGNIFICANT DIGITS ARE THE POSITIONAL NUMBERS TO IDENTIFY WHERE THE ERROR CALL IS LOCATED WITHIN THE OPTION.

C) FOR OPTION 5, THE SECOND MOST SIGNIFICANT DIGIT IS
USED TO IDENTIFY WHICH RANDOM TEST IS RUNNING.

EXAMPLES:

- 1) ERROR NUMBER: 6 => COMMAND INTEGRITY ROUTINE
(OPTION 0), ERROR 06
- 2) ERROR NUMBER: 208 => OPTION 2, ERROR 08
- 3) ERROR NUMBER: 5311 => OPTION 5, RAND3, ERROR 11

BELOW IS A SUMMARY OF THE ACTUAL ERROR CALLS IN EACH TEST OPTION:

```
! THE 'INTEGRITY' ROUTINE:
!
!WRITE COMMAND:
!ERRDF(1,MSG1,0): !**** INTEGRITY ROUTINE ERROR 01 ****
!ERRDF(2,MSG1,0): !**** INTEGRITY ROUTINE ERROR 02 ****
!ERRDF(3,MSG1,0): !**** INTEGRITY ROUTINE ERROR 03 ****
!
!READ COMMAND:
!ERRDF(4,MSG1,0): !**** INTEGRITY ROUTINE ERROR 04 ****
!ERRDF(5,MSG1,0): !**** INTEGRITY ROUTINE ERROR 05 ****
!ERRDF(6,MSG1,0): !**** INTEGRITY ROUTINE ERROR 06 ****
!ERRDF(7,MSG1,0): !**** INTEGRITY ROUTINE ERROR 07 ****
!ERRDF(8,MSG2,0): !**** INTEGRITY ROUTINE ERROR 08 ****
!ERRHRD(9,MSG4,0): !**** INTEGRITY ROUTINE ERROR 09 ****
!ERRSOFT(10,MSG3,0): !**** INTEGRITY ROUTINE ERROR 10 ****
!ERRSOFT(11,MSG3,1): !**** INTEGRITY ROUTINE ERROR 10 ****
!
!WRITE CHECK COMMAND:
!ERRDF(12,MSG1,0): !**** INTEGRITY ROUTINE ERROR 12 ****
!ERRDF(13,MSG1,0): !**** INTEGRITY ROUTINE ERROR 13 ****
!ERRDF(14,MSG1,0): !**** INTEGRITY ROUTINE ERROR 14 ****
!ERRDF(15,MSG2,0): !**** INTEGRITY ROUTINE ERROR 15 ****
!ERRHRD(16,MSG4,0): !**** INTEGRITY ROUTINE ERROR 16 ****
!ERRSOFT(17,MSG3,8): !**** INTEGRITY ROUTINE ERROR 17 ****
!ERRSOFT(18,MSG3,1): !**** INTEGRITY ROUTINE ERROR 18 ****
!
! OPTION 1:
!
!WRITE COMMAND:
!ERRDF(101,MSG1,0): !**** OPTION 1 ERROR 01 ****
!ERRDF(102,MSG1,0): !**** OPTION 1 ERROR 02 ****
!ERRDF(103,MSG1,0): !**** OPTION 1 ERROR 03 ****
!
!CHECK OR READ:
!ERRDF(104,MSG1,0): !**** OPTION 1 ERROR 04 ****
```

```
!ERRDF(105,MSG1,0):  !**** OPTION 1 ERROR 05 ****
!ERRDF(106,MSG1,0):  !**** OPTION 1 ERROR 06 ****
!ERRDF(107,MSG1,0):  !**** OPTION 1 ERROR 07 ****
!ERRDF(108,MSG2,0):  !**** OPTION 1 ERROR 08 ****
!ERRHRD(109,MSG4,0): !**** OPTION 1 ERROR 09 ****
!ERRSOFT(110,MSG3,0): !**** OPTION 1 ERROR 10 ****
!ERRSOFT(111,MSG3,0): !**** OPTION 1 ERROR 11 ****
```

! OPTION 2:

!WRITE COMMAND

```
!ERRDF(201,MSG1,0): !**** OPTION 2 ERROR 01 ****
!ERRDF(202,MSG1,0): !**** OPTION 2 ERROR 02 ****
!ERRDF(203,MSG1,0): !**** OPTION 2 ERROR 03 ****
```

!CHECK OR READ:

```
!ERRDF(204,MSG1,0): !**** OPTION 2 ERROR 04 ****
!ERRDF(205,MSG1,0): !**** OPTION 2 ERROR 05 ****
!ERRDF(206,MSG1,0): !**** OPTION 2 ERROR 06 ****
!ERRDF(207,MSG1,0): !**** OPTION 2 ERROR 07 ****
!ERRDF(208,MSG2,0): !**** OPTION 2 ERROR 08 ****
!ERRHRD(209,MSG4,0): !**** OPTION 2 ERROR 09 ****
!ERRSOFT(210,MSG3,0): !**** OPTION 2 ERROR 10 ****
!ERRSOFT(211,MSG3,1): !**** OPTION 2 ERROR 10 ****
```

!LOOP CHECK OR READ:

```
!ERRDF(212,MSG1,0): !**** OPTION 2 ERROR 12 ****
!ERRDF(213,MSG1,0): !**** OPTION 2 ERROR 13 ****
!ERRDF(214,MSG1,0): !**** OPTION 2 ERROR 14 ****
!ERRDF(215,MSG1,0): !**** OPTION 2 ERROR 15 ****
!ERRDF(216,MSG2,0): !**** OPTION 2 ERROR 16 ****
!ERRHRD(217,MSG4,0): !**** OPTION 2 ERROR 17 ****
!ERRSOFT(218,MSG3,0): !**** OPTION 2 ERROR 18 ****
!ERRSOFT(219,MSG3,0): !**** OPTION 2 ERROR 19 ****
```

! OPTION 3:

!WRITE COMMAND:

```
!ERRDF(301,MSG1,0): !**** OPTION 3 ERROR 01 ****
!ERRDF(302,MSG1,0): !**** OPTION 3 ERROR 02 ****
!ERRDF(303,MSG1,0): !**** OPTION 3 ERROR 03 ****
```

!CHECK OR READ:

```
!ERRDF(304,MSG1,0): !**** OPTION 3 ERROR 04 ****
!ERRDF(305,MSG1,0): !**** OPTION 3 ERROR 05 ****
!ERRDF(306,MSG1,0): !**** OPTION 3 ERROR 06 ****
!ERRDF(307,MSG1,0): !**** OPTION 3 ERROR 07 ****
!ERRDF(308,MSG2,0): !**** OPTION 3 ERROR 08 ****
!ERRHRD(309,MSG4,0): !**** OPTION 3 ERROR 09 ****
```

!ERRSOFT(310,MSG3,0); !**** OPTION 3 ERROR 10 ****
!ERRSOFT(311,MSG3,0); !**** OPTION 3 ERROR 11 ****

! OPTION 4:

!MARCHING UP:

!WRITE DATA:

!ERRDF(401,MSG1,0); !**** OPTION 4 ERROR 01 ****
!ERRDF(402,MSG1,0); !**** OPTION 4 ERROR 02 ****
!ERRDF(403,MSG1,0); !**** OPTION 4 ERROR 03 ****

!MARCHING UP:

!CHECK OR READ DATA:

!ERRDF(404,MSG1,0); !**** OPTION 4 ERROR 04 ****
!ERRDF(405,MSG1,0); !**** OPTION 4 ERROR 05 ****
!ERRDF(406,MSG1,0); !**** OPTION 4 ERROR 06 ****
!ERRDF(407,MSG1,0); !**** OPTION 4 ERROR 07 ****
!ERRDF(408,MSG2,0); !**** OPTION 4 ERROR 08 ****
!ERRHRD(409,MSG4,0); !**** OPTION 4 ERROR 09 ****
!ERRSOFT(410,MSG3,0); !**** OPTION 4 ERROR 10 ****
!ERRSOFT(411,MSG3,0); !**** OPTION 4 ERROR 11 ****

!WRITE COMP:

!ERRDF(412,MSG1,0); !**** OPTION 4 ERROR 12 ****
!ERRDF(413,MSG1,0); !**** OPTION 4 ERROR 13 ****
!ERRDF(414,MSG1,0); !**** OPTION 4 ERROR 14 ****

!MARCHING DOWN:

!CHECK OR READ COMP:

!ERRDF(415,MSG1,0); !**** OPTION 4 ERROR 15 ****
!ERRDF(416,MSG1,0); !**** OPTION 4 ERROR 16 ****
!ERRDF(417,MSG1,0); !**** OPTION 4 ERROR 17 ****
!ERRDF(418,MSG1,0); !**** OPTION 4 ERROR 18 ****
!ERRDF(419,MSG2,0); !**** OPTION 4 ERROR 19 ****
!ERRHRD(420,MSG4,0); !**** OPTION 4 ERROR 20 ****
!ERRSOFT(421,MSG3,0); !**** OPTION 4 ERROR 21 ****
!ERRSOFT(422,MSG3,0); !**** OPTION 4 ERROR 22 ****

!WRITE DATA:

!ERRDF(423,MSG1,0); !**** OPTION 4 ERROR 23 ****
!ERRDF(424,MSG1,0); !**** OPTION 4 ERROR 24 ****
!ERRDF(425,MSG1,0); !**** OPTION 4 ERROR 25 ****

!MARCHING UP:

!CHECK OR READ DATA:

```
!ERRDF(426,MSG1,0):  !**** OPTION 4 ERROR 26 ****  
!ERRDF(427,MSG1,0):  !**** OPTION 4 ERROR 27 ****  
!ERRDF(428,MSG1,0):  !**** OPTION 4 ERROR 28 ****  
!ERRDF(429,MSG1,0):  !**** OPTION 4 ERROR 29 ****  
!ERRDF(430,MSG2,0):  !**** OPTION 4 ERROR 30 ****  
!ERRHRD(431,MSG4,0): !**** OPTION 4 ERROR 31 ****  
!ERRSOFT(432,MSG3,0): !**** OPTION 4 ERROR 32 ****  
!ERRSOFT(433,MSG3,0): !**** OPTION 4 ERROR 33 ****
```

```
!  
! OPTION 5:  
!
```

!'RAND1' ROUTINE:

!WRITE COMMAND:

```
!ERRDF(5101,MSG1,0): !**** OPTION 5, RAND1 ERROR 01 ****  
!ERRDF(5102,MSG1,0): !**** OPTION 5, RAND1 ERROR 02 ****  
!ERRDF(5103,MSG1,0): !**** OPTION 5, RAND1 ERROR 03 ****
```

!CHECK OR READ:

```
!ERRDF(5104,MSG1,0): !**** OPTION 5, RAND1 ERROR 04 ****  
!ERRDF(5105,MSG1,0): !**** OPTION 5, RAND1 ERROR 05 ****  
!ERRDF(5106,MSG1,0): !**** OPTION 5, RAND1 ERROR 06 ****  
!ERRDF(5107,MSG1,0): !**** OPTION 5, RAND1 ERROR 07 ****  
!ERRDF(5108,MSG2,0): !**** OPTION 5, RAND1 ERROR 08 ****  
!ERRHRD(5109,MSG4,0): !**** OPTION 5, RAND1 ERROR 09 ****  
!ERRSOFT(5110,MSG3,0): !**** OPTION 5, RAND1 ERROR 10 ****  
!ERRSOFT(5111,MSG3,0): !**** OPTION 5, RAND1 ERROR 11 ****
```

!'RAND2' ROUTINE:

!WRITE COMMAND:

```
!ERRDF(5201,MSG1,0): !**** OPTION 5, RAND2 ERROR 01 ****  
!ERRDF(5202,MSG1,0): !**** OPTION 5, RAND2 ERROR 02 ****  
!ERRDF(5203,MSG1,0): !**** OPTION 5, RAND2 ERROR 03 ****
```

!CHECK OR READ:

```
!ERRDF(5204,MSG1,0): !**** OPTION 5, RAND2 ERROR 04 ****  
!ERRDF(5205,MSG1,0): !**** OPTION 5, RAND2 ERROR 05 ****  
!ERRDF(5206,MSG1,0): !**** OPTION 5, RAND2 ERROR 06 ****  
!ERRDF(5207,MSG1,0): !**** OPTION 5, RAND2 ERROR 07 ****  
!ERRDF(5208,MSG2,0): !**** OPTION 5, RAND2 ERROR 08 ****  
!ERRHRD(5209,MSG4,0): !**** OPTION 5, RAND2 ERROR 09 ****  
!ERRSOFT(5210,MSG3,0): !**** OPTION 5, RAND2 ERROR 10 ****  
!ERRSOFT(5211,MSG3,0): !**** OPTION 5, RAND2 ERROR 11 ****
```

!'RAND3' ROUTINE:

!WRITE COMMAND:

```
!ERRDF(5301,MSG1,0): !**** OPTION 5, RAND3 ERROR 01 ****
```

!ERRDF(5302,MSG1,0): !**** OPTION 5, RAND3 ERROR 02 ****
!ERRDF(5303,MSG1,0): !**** OPTION 5, RAND3 ERROR 03 ****

!CHECK OR READ:

!ERRDF(5304,MSG1,0): !**** OPTION 5, RAND3 ERROR 04 ****
!ERRDF(5305,MSG1,0): !**** OPTION 5, RAND3 ERROR 05 ****
!ERRDF(5306,MSG1,0): !**** OPTION 5, RAND3 ERROR 06 ****
!ERRDF(5307,MSG1,0): !**** OPTION 5, RAND3 ERROR 07 ****
!ERRDF(5308,MSG2,0): !**** OPTION 5, RAND3 ERROR 08 ****
!ERRHRD(5309,MSG4,0): !**** OPTION 5, RAND3 ERROR 09 ****
!ERRSOFT(5310,MSG3,0): !**** OPTION 5, RAND3 ERROR 10 ****
!ERRSOFT(5311,MSG3,0): !**** OPTION 5, RAND3 ERROR 11 ****

!'RAND4' ROUTINE:

!WRITE COMMAND:

!ERRDF(5401,MSG1,0): !**** OPTION 5, RAND4 ERROR 01 ****
!ERRDF(5402,MSG1,0): !**** OPTION 5, RAND4 ERROR 02 ****
!ERRDF(5403,MSG1,0): !**** OPTION 5, RAND4 ERROR 03 ****

!CHECK OR READ:

!ERRDF(5404,MSG1,0): !**** OPTION 5, RAND4 ERROR 04 ****
!ERRDF(5405,MSG1,0): !**** OPTION 5, RAND4 ERROR 05 ****
!ERRDF(5406,MSG1,0): !**** OPTION 5, RAND4 ERROR 06 ****
!ERRDF(5407,MSG1,0): !**** OPTION 5, RAND4 ERROR 07 ****
!ERRDF(5408,MSG2,0): !**** OPTION 5, RAND4 ERROR 08 ****
!ERRHRD(5409,MSG4,0): !**** OPTION 5, RAND4 ERROR 09 ****
!ERRSOFT(5410,MSG3,0): !**** OPTION 5, RAND4 ERROR 10 ****
!ERRSOFT(5411,MSG3,0): !**** OPTION 5, RAND4 ERROR 11 ****

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH A SUMMARY WHICH SHOWS THE DIAGNOSTIC'S PERFORMANCE SINCE IT WAS STARTED. THE SAME PROGRESS REPORT CAN BE OBTAINED BY STOPPING THE PROGRAM'S EXECUTION (VIA A ^C) AND BY ISSUING THE 'PRINT' COMMAND. A TYPICAL REPORT FOR 2 DRIVES IS SHOWN BELOW:

PERFORMANCE SUMMARY

NUMBER OF MBYTES TRANSFERRED:

1028 MBYTES WRITTEN
250 MBYTES READ
1145 MBYTES WRITE CHECKED

LOGICAL UNIT: 0 DRIVE: 1 SERIAL #: 1234

SOFT ERROR COUNT: 9
ARRAY 3: 9
HARD ERROR COUNT: 11
ARRAY 0: 6
ARRAY 10: 2
ARRAY 15: 3
TRANSFER RETRIES: 0

LOGICAL UNIT: 1 DRIVE: 1 SERIAL #: 9876
DRIVE DROPPED (CONTROLLER FATAL ERROR)
SOFT ERROR COUNT: 100
ARRAY 1: 9
ARRAY 13: 10 --> RUN ML11 PROM MAINTENANCE PROGRAM
ARRAY 14: 1
ARRAY 15: 80 --> RUN ML11 PROM MAINTENANCE PROGRAM
HARD ERROR COUNT: 2
ARRAY 14: 1
ARRAY 15: 1
TRANSFER RETRIES: 0

5.0 DEVICE INFORMATION TABLES

AT THE START OF THE PROGRAM, AN AUTOMATIC CHECK OF THE SYSTEM CONFIGURATION IS MADE AND DEVICE INFORMATION SIMILAR TO THE FOLLOWING IS PRINTED FOR EACH UNIT:

LOGICAL UNIT: 0 DRIVE: 0 SERIAL #: 1234
ML11-A SECTORS UNDER TEST: 000000 TO 017777
TRANSFER RATE: 1 MBYTES/SECOND CSR ADDRESS: 176400

6.0 TEST SUMMARIES

THERE IS JUST ONE HARDWARE TEST IN THE EXERCISER, AND ITS PURPOSE IS TO ACT AS A SCHEDULER TO CALL THE SUBROUTINES WHICH ACTUALLY PERFORM ALL OF THE TEST CODE. THE SUBROUTINES, CALLED OPTIONS, ARE DESCRIBED BELOW:

6.1 OPTION 1 (OPT1)

PURPOSE: TO CHECK ADDRESSES USING DATA = SECTOR NUMBER.
TRANSFERS ARE 4K WORDS IN LENGTH, AND ALL SECTORS ARE TESTED.

THE CODE FOR 'OPT1' IN BRIEF:

```
BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COMPLEMENT FLAG FROM 0 TO 1
: BEGIN 2 (START OF COMPLEMENT FLAG SELECTION LOOP)
: INCR LOGICAL UNIT FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : : TESTLOOP:
: : : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS ONE UNIT)
: : : : IF UNIT IS ACTIVE
: : : : THEN
: : : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : : INITIALIZE WRITE AND READ BUFFER POINTERS
: : : : : SECTOR = LOWEST
: : : : : WHILE SECTOR LEQ HIGHEST DO
: : : : : : BEGIN 6 (START OF SECTOR SELECTION LOOP)
: : : : : : GET WRDCNT
: : : : : : GENERATE THE PATTERN
```

```
: : : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : UPDATE SECTOR NUMBER BY NUMBER OF SECTORS IN PREVIOUS TRANSFER
: : : : : END 6 (END OF SECTOR SELECTION LOOP)
: : : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : : : END 4 (END OF TESTLOOP)
: : : : : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
: : : : : END 2 (END OF COMPLEMENT FLAG SELECTION LOOP)
RETURN
END 1 (END OF ROUTINE)
```

6.2 OPTION 2 (OPT2)

PURPOSE: TO CHECK ON DATA RELIABILITY USING THE PATTERNS FROM THE PATTERN TABLE.

THE CODE FOR 'OPT2' IN BRIEF:

```
BEGIN 1 (START OF ROUTINE)
SAY THE ROUTINE IS RUNNING
CHOOSE A MAXIMUM PATTERN NUMBER
INCR COUNT FROM 1 TO (2*MAX)
: BEGIN 2 (START OF PATTERN SELECTION LOOP)
: GENERATE THE PATTERN
: INCR LUN FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : INITIALIZE THE WRITE AND READ BUFFER POINTERS
: : : : SECTOR = LOWEST
: : : : WHILE SECTOR LEQ HIGHEST DO
: : : : : BEGIN 6 (START OF SECTOR SELECTION LOOP)
: : : : : GET WRDCNT
: : : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : UPDATE SECTOR NUMBER BY NUMBER OF SECTORS IN PREVIOUS TRANSFER
: : : : : END 6 (END OF SECTOR SELECTION LOOP)
: : : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : : : END 4 (END OF TESTLOOP)
: : : : : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
: : : : : IF NOT THE QUICK VERIFY PASS THEN 'LOOP READ' (DESCRIBED BELOW)
: : : : : END 2 (END OF PATTERN SELECTION LOOP)
RETURN
END 1 (END OF ROUTINE)
```

THE 'LOOP READ' CODE IN BRIEF:

```

BEGIN 11 (START OF LOOP READING SECTION)
INCR LUN FROM 0 TO LAST
: BEGIN 12 (START OF LOGICAL UNIT SELECTION LOOP)
: TESTLOOP2:
: : BEGIN 13 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : IF UNIT IS ACTIVE
: : THEN
: : : BEGIN 14 (START OF TEST FOR AN ACTIVE UNIT)
: : : INITIALIZE THE WRITE AND READ BUFFER POINTERS
: : : SECTOR = LOWEST
: : : WHILE SECTOR LEQ HIGHEST DO
: : : : BEGIN 15 (START OF SECTOR SELECTION LOOP)
: : : : GET WRDCNT
: : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : INCR KOUNT FROM 1 TO TIMES
: : : : : BEGIN 16 (START OF COUNTING LOOP FOR LOOP READING)
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP2)
: : : : : END 16 (END OF COUNTING LOOP FOR LOOP READING)
: : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : UPDATE SECTOR NUMBER BY # SECTORS IN PREVIOUS TRANSFER
: : : : END 15 (END OF SECTOR SELECTION LOOP)
: : : END 14 (END OF TEST FOR AN ACTIVE UNIT)
: : END 13 (END OF TESTLOOP2)
: END 12 (END OF LOGICAL UNIT SELECTION LOOP)
END 11 (END OF LOOP READING SECTION)
  
```

6.3 OPTION 3 (GPT3)

PURPOSE: TO DO A UNIQUE DATA CHECK ON ALL AVAILABLE UNITS.

THE CODE FOR 'OPT3' IN BRIEF:

```

BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COMPLEMENT FLAG FROM 0 TO 1
: BEGIN 2 (START OF COMPLEMENT FLAG SELECTION LOOP)
: GENERATE THE PATTERN
: INCR LUN FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : INITIALIZE THE WRITE AND READ BUFFER POINTERS
: : : : SECTOR = LOWEST
: : : : WHILE SECTOR LEQ HIGHEST DO
: : : : : BEGIN 6 (START OF SECTOR SELECTION LOOP)
: : : : : GET WRDCNT
: : : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
  
```

```
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : UPDATE SECTOR NUMBER BY NUMBER OF SECTORS IN PREVIOUS TRANSFER
: : : : : END 6 (END OF SECTOR SELECTION LOOP)
: : : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : : : END 4 (END OF TESTLOOP)
: : : : : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
: : : : : END 2 (END OF COMPLEMENT FLAG SELECTION LOOP)
RETURN
END 1 (END OF ROUTINE)
```

6.4 OPTION 4 (OPT4)

PURPOSE: TO LOOK FOR INTERACTIONS BETWEEN SECTORS
USING A MARCH TEST.

THE CODE FOR 'OPT4' IN BRIEF:

```
BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
WORD COUNT = 256
GENERATE A BUFFER OF DATA
GENERATE A BUFFER OF COMP
INITIALIZE POINTERS TO 4 BUFFERS FOR WRITE/READ DATA/COMP
INCR LUN FROM 0 TO LAST
: BEGIN 2 (START OF LOGICAL UNIT SELECTION LOOP)
: TESTLOOP:
: : BEGIN 3 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : IF UNIT IS ACTIVE
: : THEN
: : : BEGIN 4 (START OF TEST FOR AN ACTIVE UNIT)
: : : INCR SECTOR FROM LOWEST TO HIGHEST
: : : : BEGIN 4A (START OF 1ST SECTOR SELECTION LOOP)
: : : : WRITE 'DATA'
: : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : END 4A (END OF 1ST SECTOR SELECTION LOOP)
: : : : CHOOSE WHETHER TO WRITE CHECK OR READ 'DATA'
: : : : INCR SECTOR FROM LOWEST TO HIGHEST
: : : : : BEGIN 4B (START OF 2ND SECTOR SELECTION LOOP)
: : : : : DO THE WRITE CHECK OR READ OF 'DATA'
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : WRITE 'COMP'
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : END 4B (END OF 2ND SECTOR SELECTION LOOP)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ 'COMP'
: : : : : DECR SECTOR FROM HIGHEST TO LOWEST
: : : : : BEGIN 4C (START OF 3RD SECTOR SELECTION LOOP)
: : : : : DO THE WRITE CHECK OR READ OF 'COMP'
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : WRITE DATA
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : END 4C (END OF 3RD SECTOR SELECTION LOOP)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ 'DATA'
: : : : : INCR SECTOR FROM LOWEST TO HIGHEST
: : : : : BEGIN 4D (START OF 4TH SECTOR SELECTION LOOP)
```

```

: : : : DO THE WRITE CHECK OR READ OF 'DATA'
: : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : END 4D (END OF 4TH SECTOR SELECTION LOOP)
: : : : END 4 (END OF TEST FOR AN ACTIVE UNIT)
: : : : END 3 (END OF TESTLOOP)
: : : : END 2 (END OF LOGICAL UNIT SELECTION LOOP)
RETURN
END 1 (END OF ROUTINE)
    
```

6.5 OPTION 5 (OPT5)

PURPOSE: TO EXERCISE THE ML11 SYSTEMS UNDER TEST IN A RANDOM MANNER, SO AS TO SIMULATE THE FLEXIBILITY OF TESTING THAT WOULD BE DONE BY AN OPERATING SYSTEM.

THERE ARE 4 RANDOM TESTS WHICH ARE CALLED BY 'OPT5' TO ACCOMPLISH ALL TESTING. IT IS THE RESPONSIBILITY OF THIS ROUTINE TO DECIDE HOW MANY TIMES THOSE 4 RANDOM TESTS WILL BE EXECUTED. REFER TO 'RAND1' TO 'RAND4' BELOW FOR MORE INFORMATION.

6.5.1 RAND1 ROUTINE

PURPOSE: TO TEST USING RANDOM DATA

THE CODE FOR 'RAND1' IN BRIEF:

```

BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COUNT FROM 1 TO REPEAT
: BEGIN 2 (START OF REPEAT LOOP FOR THE ROUTINE)
: GENERATE THE RANDOM PATTERN
: INCR LUN FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : INITIALIZE THE WRITE AND READ BUFFER POINTERS
: : : : SECTOR = LOWEST
: : : : WHILE SECTOR LEQ HIGHEST DO
: : : : : BEGIN 6 (START OF SECTOR SELECTION LOOP)
: : : : : GET WRDCNT
: : : : : SET-UP BUFFER POINTERS BEFORE TRANSFER
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : UPDATE SECTOR NUMBER BY NUMBER OF SECTORS IN PREVIOUS TRANSFER
: : : : : END 6 (END OF SECTOR SELECTION LOOP)
: : : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : : : END 4 (END OF TESTLOOP)
: : : : : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
    
```

: END 2 (END OF REPEAT LOOP FOR THIS ROUTINE)
RETURN
END 1 (END OF ROUTINE)

6.5.2 RAND2 ROUTINE

PURPOSE: TO TEST USING RANDOM DATA AND WORD COUNTS

THE CODE FOR 'RAND2' IN BRIEF:

```
BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COUNT FROM 1 TO REPEAT
: BEGIN 2 (START OF REPEAT LOOP FOR THE ROUTINE)
: INCR LUN FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : GENERATE THE RANDOM PATTERN
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : SECTOR = LOWEST
: : : : INITIALIZE THE WRITE AND READ BUFFER POINTERS
: : : : WHILE SECTOR LEQ HIGHEST DO
: : : : : BEGIN 6 (START OF A PASS THROUGH ALL SECTORS)
: : : : : CHOOSE A RANDOM WORD COUNT
: : : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : : CALCULATE NEXT STARTING SECTOR (BASED ON WORD COUNT)
: : : : : IF NEXT STARTING SECTOR GTR HIGHEST
: : : : : THEN ADJUST THE WORD COUNT AND NEXT SECTOR SO THEY FIT
: : : : : : WITHIN THE TESTABLE SECTOR LIMITS
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : SECTOR = THE CALCULATED NEXT STARTING SECTOR
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : END 6 (END OF A PASS THROUGH ALL SECTORS)
: : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : END 4 (END TESTLOOP)
: : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
: END 2 (END OF REPEAT LOOP FOR THIS ROUTINE)
RETURN
END 1 (END OF ROUTINE)
```

6.5.3 RAND3 ROUTINE

PURPOSE: TO TEST USING RANDOM DATA, WORD COUNTS AND SECTORS

THE CODE FOR 'RAND3' IN BRIEF:

```
BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COUNT FROM 1 TO REPEAT
: BEGIN 2 (START OF REPEAT LOOP FOR THIS ROUTINE)
: GENERATE THE RANDOM PATTERN
: INCR LUN FROM 0 TO LAST
```

```
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : INITIALIZE BUFFER POINTERS
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : : TIMES = (HIGHEST - LOWEST)/2 + 1
: : : : : INCR KOUNT FROM 1 TO TIMES
: : : : : BEGIN 6 (START OF COUNTING LOOP FOR SECTOR SELECTION)
: : : : : CHOOSE A RANDOM WORD COUNT
: : : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : : CHOOSE A RANDOM SECTOR
: : : : : CALCULATE WHERE TRANSFER WILL END (BASED ON WORD COUNT)
: : : : : IF CALCULATED VALUE GTR HIGHEST
: : : : : : THEN ADJUST THE WORD COUNT SO IT FITS
: : : : : : : WITHIN THE TESTABLE SECTOR LIMITS
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE LABEL)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE LABEL)
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : END 6 (END OF COUNTING LOOP FOR SECTOR SELECTION)
: : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : END 4 (END OF TESTLOOP)
: : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
: END 2 (END OF REPEAT LOOP FOR THIS ROUTINE)
RETURN
END 1 (END OF ROUTINE)
```

6.5.4 RAND4 ROUTINE

PURPOSE: TO TEST USING RANDOM DATA, WORD COUNTS, SECTORS
AND UNITS

THE CODE FOR 'RAND4' IN BRIEF:

BEGIN 1 (START OF ROUTINE)

SAY ROUTINE IS RUNNING

INCR COUNT FROM 1 TO REPEAT

: BEGIN 2 (START OF REPEAT LOOP FOR THIS ROUTINE)

: GENERATE THE RANDOM PATTERN

: TIMES = NUMBER OF UNITS * 4

: INCR KOUNT FROM 1 TO TIMES

: : BEGIN 3 (START OF COUNTING LOOP FOR UNIT SELECTION)

: : CHOOSE A RANDOM LOGICAL UNIT WHICH IS ACTIVE

: : INITIALIZE BUFFER POINTERS

: : TESTLOOP:

: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)

: : : INCR KOUNT2 FROM 1 TO 10

: : : : BEGIN 5 (START OF COUNTING LOOP FOR SECTOR SELECTION)

: : : : CHOOSE A RANDOM WORD COUNT

: : : : SET UP BUFFER POINTERS BEFORE TRANSFER

: : : : CHOOSE A RANDOM SECTOR

: : : : CALCULATE WHERE TRANSFER WILL END (BASED ON WORD COUNT)

: : : : IF CALCULATED VALUE GTR HIGHEST

: : : : : THEN ADJUST THE WORD COUNT SO IT FITS

: : : : : : WITHIN THE TESTABLE SECTOR LIMITS

: : : : : WRITE

```
: : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : DO THE WRITE CHECK OR READ
: : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : END 5 (END OF COUNTING LOOP FOR SECTOR SELECT'ON)
: : : : END 4 (END OF TESTLOOP)
: : : : END 3 (END OF COUNTING LOOP FOR UNIT SELECTION)
: : : : END 2 (END OF REPEAT LOOP FOR THIS ROUTINE)
RETURN
END 1 (END OF ROUTINE)
```

7.0 MAINTENANCE HISTORY

MODIFIED BY: D.W. NEALE DATE: 18-FEB-82 VERSION: B

ALL FUNCTIONAL CHANGES TO THIS DIAGNOSTIC ARE LABELED WITH A COMMENT LINE OF 'VER CZMLBB' PRECEDING ANY MODIFIED OR ADDED LINE/BLOCK OF CODE.

FUNCTIONAL CHANGES TO THIS DIAGNOSTIC INCLUDE:

1. MODIFYING CODE TO ENSURE QUALITY TESTING OF ML-11B AND ML-11A BLOCK MODE MEMORY SYSTEMS.
2. CORRECT EXERCISER FUNCTIONALITY TO CALL OUT ML11 PROM MAINTENANCE PROGRAM AFTER 10 UNIQUE FAILING SINGLE BIT ERRORS (SBE'S) HAVE BEEN DISCOVERED PER ARRAY MODULE.

VERSION 'A' PROM MAINTENANCE CALL OUT OCCURES AFTER ANY TEN SBE'S ARE DISCOVERED PER ARRAY MODULE.

3. PER REQUEST OF F/S AND MEMORY ENGINEERING, THE REPORTING OF 'MOPE' ERRORS DURING SBE'S CORRECTION WILL BE IGNORED.
4. ADDING TO THE REPORT SUMMARY CODE SECTION A TABLE OF SBE LOCATIONS AND PRINTING OF THIS TABLE DURING REPORT CODE PRINTING.

1
33
35 000000
36 002000
38
39 002000
40
41
42
43
44
45
46 002000
47
64
65 002000
002000
002000 103
002001 132
002002 115
002003 114
002004 102
002005 000
002006 000
002007 000
002010
002010 102
002011
002011 060
002012
002012 000000
002014
002014 003410
002016
002016 002266
002020
002020 002450
002022
002022 002210
002024
002024 002222
002026
002026 105050
002030
002030 000000
002032
002032 000000
002034
002034 000001
002036
002036 000000
002040
002040 002204
002042
002042 000000
002044
002044 000000

.SBTTL PROGRAM HEADER AND TABLES

.ENABL ABS,AMA
= 2000

BGNMOD

..++
: THE PROGRAM HEADER IS THE INTERFACE BETWEEN
: THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
:--

POINTER ALL

HEADER CZMLB,B,0,1800.,1

LSNAME::
.ASCII /C/
.ASCII /Z/
.ASCII /M/
.ASCII /L/
.ASCII /B/
.BYTE 0
.BYTE 0
.BYTE 0
LSREV::
LSDEPO:: .ASCII /B/
LSUNIT:: .ASCII /O/
LSTIML:: .WORD TSPTHV
LSHPCP:: .WORD 1800.
LSSPCP:: .WORD LSHARD
LSHPTP:: .WORD LSSOFT
LSSPTP:: .WORD LSHW
LSLADP:: .WORD LSSW
LSSTA:: .WORD LSLAST
LSCO:: .WORD 0
LSDTYP:: .WORD 0
LSAPT:: .WORD 1
LSDTP:: .WORD 0
LSPRIO:: .WORD LSDISPATCH
LSENV1:: .WORD 0
.WORD 0

002046
002046 000000
002050
002050 003
002051 003
002052
002052 000000
002054 000000
002056
002056 000000
002060
002060 002122
002062
002062 005474
002064
002064 000000
002066
002066 000000
002070
002070 005652
002072
002072 005640
002074
002074 000000
002076
002076 002130
002100
002100 104035
002102
002102 002172
002104
002104 040722
002106
002106 105034
002110
002110 005506
002112
002112 004126
002114
002114 000000
002116
002116 000000
002120
002120 000000

66
77
78
79
80

002122
002122 115 114 061
002122

⋮

NAMES OF DEVICES SUPPORTED BY THIS PROGRAM
DEV TYP <ML11>

LSEXP1:: .WORD 0
LSMREV:: .BYTE CSREVISION
.BYTE CSREDIT
LSEF:: .WORD 0
.WORD 0
LSSPC:: .WORD 0
LSDEVP:: .WORD LSDVTYP
LSREPP:: .WORD LSRPT
LSEXP4:: .WORD 0
LSEXP5:: .WORD 0
LSAUT:: .WORD L3AU
LSDUT:: .WORD LSDU
LSLUN:: .WORD 0
LSDESP:: .WORD LSDESC
LSLOAD:: EMT ESLOAD
LSETP:: .WORD LSERRTBL
LSICP:: .WORD LSINIT
LSCCP:: .WORD LSCLEAN
LSACP:: .WORD LSAUTO
LSPRT:: .WORD LSPROT
LSTEST:: .WORD 0
LSDLY:: .WORD 0
LSHIME:: .WORD 0

LSDVTYP:: .ASCIZ /ML11/
.EVEN

```
82
83
84
85 002130
   002130
   002130      103      132      115
                                LSDESC::
                                .ASCIZ /CZMLBB ML11 PERFORM
                                .EVEN

86
87
88
89
90
91
92
93
94 002172
   002172
   002172      000000
   002174      000000
   002176      000000
   002200      000000
                                LSERRTBL::
ERRTBL
ERRTYP::      .WORD      0
ERRNBR::      .WORD      0
ERRMSG::      .WORD      0
ERRBLK::      .WORD      0

95
96
97
98
99
100
101 002202
     002202      000001
     002204
     002204      102712
                                LSDISPATCH::
                                .WORD      1
                                .WORD      T1

102
109
110
111
112
113
114
115
116
117 002206
     002206      000004
     002210
     002210
                                LSHW::      .WORD      L10000-LSHW/2
                                DFPTBL::
                                .WORD      176400      ;CSR ADDRESS
                                .WORD      204          ;RH VECTOR ADDRESS
                                .WORD      5           ;BR LEVEL FOR INTERRUPT
                                .WORD      0           ;ML11 DRIVE NUMBER

118
128
129 002210      176400
130 002212      000204
131 002214      000005
132 002216      000000
133
134 002220
     002220
                                L10000:
```

136
137
138
139
140
141
142
143
144
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196

002220
002220 000021
002222
002222

002222 000000
002224 000000
002226 000000
002230 000000
002232 000000
002234 000000
002236 000000
002240 000000
002242 000000
002244 000000
002246 000001
002250 000000
002252 000000
002254 000000

: THE DEFAULT SOFTWARE P-TABLE CONTAINS VARIOUS DATA USED BY THE
: PROGRAM AS OPERATIONAL PARAMETERS. THESE PARAMETERS ARE SET
: UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR AT RUN
: TIME.
:--

BGNSW SFPTBL

.WORD L10001-L8SW/2
L8SW::
SFPTBL::

LIMIT:: .WORD 0 ;LIMIT RANGE OF SECTORS TO BE TESTED
: 0 = NO 1 = YES
RANGE:: .WORD 0 ;DOES OPERATOR KNOW EXACT SECTOR NUMBERS?
: 0 = NO 1 = YES
LSECT:: .WORD 0 ;LOW SECTOR NUMBER
TSECT:: .WORD 0 ;TOP SECTOR NUMBER
ONLY:: .WORD 0 ;ONLY BOARD TO TEST (BOARD #'S ARE 0 TO 15)
DROPNE:: .WORD 0 ;DROP ANY OPTIONS? 0 = NO 1 = YES
DROP1:: .WORD 0 ;DROP OPTION #1? 0 = NO 1 = YES
DROP2:: .WORD 0 ;DROP OPTION #2? 0 = NO 1 = YES
DROP3:: .WORD 0 ;DROP OPTION #3? 0 = NO 1 = YES
DROP4:: .WORD 0 ;DROP OPTION #4? 0 = NO 1 = YES
MARPAT:: .WORD 1 ;PATTERN NUMBER USED FOR MARCH TEST
DROPS:: .WORD 0 ;DROP OPTION #5? 0 = NO 1 = YES
REFRESH:: .WORD 0 ;ENABLE MARGINING? 0 = NO (LEAVE DISABLED)
: 1 = YES (ENABLE IT)
ECCDIS:: .WORD 0 ;DISABLE ECC? 0 = NO (LEAVE ENABLED)
: 1 = YES (DISABLE IT)

***** IMPORTANT NOTE *****
: THE FOLLOWING 2 SOFTWARE PARAMETERS :
: HAVE NON-STANDARD DEFAULTS. ERRORS :
: AND END OF PASS PERFORMANCE SUMMARY :
: REPORTS WILL ** N O T ** BE PRINTED :
: UNLESS THE OPERATOR SPECIFICALLY :
: REQUESTS THE PRINTOUTS VIA SUITABLE :
: ANSWERS TO THE SOFTWARE QUESTIONS. :
: THIS OPERATING FEATURE WAS INCLUDED :
: IN THE ML11 PERFORMANCE EXERCISER'S :
: FUNCTIONAL SPECIFICATION AT THE RE- :
: QUEST OF FIELD SERVICE. :

EOPSUM:: .WORD 0 ;ENABLE EOP SUMMARIES? 0 = NO PRINTOUT
: 1 = YES
ERROUT:: .WORD 0 ;ENABLE ERROR PRINTOUTS? 0 = NO PRINTOUT
: 1 = YES
EFNS21:: .WORD 0 ;ENABLE SOFT ERROR TESTING 0 = NO (DEFAULT)
: 1 = YES
: THIS OPTION IS DESIGNED FOR MEMORY ENGINEERING
: FOR DMT PURPOSES

ENDSW

197 002264
222
248
249
250
251
252
253
254
255
256
257
258

L10001:

```

:++
: THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
: THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
: MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
: INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
: MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
: WITH THE OPERATOR.
:--

```

259 002264 000022
002264
002266

BGNHRD

.WORD L10002-LSHARD/2
LSHARD::

260
270
271
272 002266
002266 000031
002270 002332
002272 000000
002274 177777

GPRMA QH1,0,0,0,177777,YES

.WORD TSCODE
.WORD QH1
.WORD TSLOLIM
.WORD TSHILIM

273 002276
002276 001031
002300 002351
002302 000000
002304 000377

GPRMA QH2,2,0,0,377,YES

.WORD TSCODE
.WORD QH2
.WORD TSLOLIM
.WORD TSHILIM

274 002306
002306 002032
002310 002374
002312 000007
002314 000001
002316 000007

GPRMD QH3,4,0,7,1,7,YES

.WORD TSCODE
.WORD QH3
.WORD 7
.WORD TSLOLIM
.WORD TSHILIM

275 002320
002320 003032
002322 002425
002324 000007
002326 000000
002330 000007

GPRMD QH4,6,0,7,0,7,YES

.WORD TSCODE
.WORD QH4
.WORD 7
.WORD TSLOLIM
.WORD TSHILIM

276
277 002332

ENDHRD

L10002: .EVEN

278 002332
285
286 002332 103 123 122
287 002351 111 116 124
288 002374 102 122 040
289 002425 104 122 111

```

QH1: .ASCIZ /CSR ADDRESS ?/
QH2: .ASCIZ /INTERRUPT VECTOR ?/
QH3: .ASCIZ /BR LEVEL FOR INTERRUPT ?/
QH4: .ASCIZ /DRIVE NUMBER ?/
.EVEN

```

290
291
292
293
294

```

:++
: THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS

```

```

295
296
297
298
299
300
301
302 002446          BGNSFT
    002446 000106
    002450
303
312
313 002450          GPRML  QS1,0,1,YES
    002450 000130
    002452 002664
    002454 000001
314 002456          XFERF  6$
    002456 025044
315 002460          GPRML  QS2,2,1,YES
    002460 001130
    002462 002732
    002464 000001
316 002466          XFERF  5$
    002466 014044
317 002470          GPRMD  QS3,4,0,177777,0,177777,YES
    002470 002032
    002472 003007
    002474 177777
    002476 000000
    002500 177777
318 002502          GPRMD  QS4,6,0,177777,0,177777,YES
    002502 003032
    002504 003047
    002506 177777
    002510 000000
    002512 177777
319 002514          XFER  6$
    002514 006004
320 002516          5$: GPRMD  QS5,10,D,37,0,15.,YES
    002516 004052
    002520 003107
    002522 000037
    002524 000000
    002526 000017
321 002530          6$: GPRML  QS6,12,1,YES
    002530 005130
    002532 003147
    002534 000001
322 002536          XFERF  7$
    002536 007024
323 002540          GPRMD  QS11,24,D,77,1,10.,YES
    002540 012052
    002542 003554
    002544 000077
    002546 000001
    002550 000012
324 002552          XFER  13$

```

```

: THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
: MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
: INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
: MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
: WITH THE OPERATOR.
:--

```

```

.L$SOFT: .WORD L10003-L$SOFT/2

```

```

.WORD T$CODE
.WORD QS1
.WORD 1
.WORD T$CODE
.WORD T$CODE
.WORD QS2
.WORD 1
.WORD T$CODE
.WORD T$CODE
.WORD QS3
.WORD 177777
.WORD T$LOLIM
.WORD T$HILIM
.WORD T$CODE
.WORD QS4
.WORD 177777
.WORD T$LOLIM
.WORD T$HILIM
.WORD T$CODE
.WORD QS5
.WORD 37
.WORD T$LOLIM
.WORD T$HILIM
.WORD T$CODE
.WORD QS6
.WORD 1
.WORD T$CODE
.WORD T$CODE
.WORD QS11
.WORD 77
.WORD T$LOLIM
.WORD T$HILIM

```

325	002552	026004							
	002554		7\$:	GPRML	QS7,14,1,YES	.WORD	T\$CODE		
	002554	006130				.WORD	T\$CODE		
	002556	003454				.WORD	QS7		
	002560	000001				.WORD	1		
326	002562			GPRML	QS8,16,1,YES	.WORD	T\$CODE		
	002562	007130				.WORD	QS8		
	002564	003474				.WORD	1		
	002566	000001				.WORD	T\$CODE		
327	002570			GPRML	QS9,20,1,YES	.WORD	QS9		
	002570	010130				.WORD	1		
	002572	003514				.WORD	T\$CODE		
	002574	000001				.WORD	QS9		
328	002576			GPRML	QS10,22,1,YES	.WORD	1		
	002576	011130				.WORD	T\$CODE		
	002600	003534				.WORD	QS10		
	002602	000001				.WORD	1		
329	002604			XFERT	12\$.WORD	T\$CODE		
	002604	006024				.WORD	QS11		
330	002606			GPRMD	QS11,24,D,77,1,10.,YES	.WORD	T\$CODE		
	002606	012052				.WORD	QS11		
	002610	003554				.WORD	77		
	002612	000077				.WORD	T\$LOLIM		
	002614	000001				.WORD	T\$HILIM		
	002616	000012				.WORD	T\$CODE		
331	002620		12\$:	GPRML	QS12,26,1,YES	.WORD	QS12		
	002620	013130				.WORD	1		
	002622	003637				.WORD	T\$CODE		
	002624	000001				.WORD	QS13		
332	002626		13\$:	GPRML	QS13,30,1,YES	.WORD	1		
	002626	014130				.WORD	T\$CODE		
	002630	003657				.WORD	QS13		
	002632	000001				.WORD	1		
333	002634			GPRML	QS14,32,1,YES	.WORD	T\$CODE		
	002634	015130				.WORD	QS14		
	002636	003724				.WORD	1		
	002640	000001				.WORD	T\$CODE		
334	002642			GPRML	QS15,34,1,YES	.WORD	QS15		
	002642	016130				.WORD	1		
	002644	003763				.WORD	T\$CODE		
	002646	000001				.WORD	QS16		
335	002650			GPRML	QS16,36,1,YES	.WORD	1		
	002650	017130				.WORD	T\$CODE		
	002652	004030				.WORD	QS16		
	002654	000001				.WORD	1		
336	002656			GPRML	QS17,40,1,YES	.WORD	T\$CODE		
	002656	020130				.WORD	QS17		
	002660	004066				.WORD	1		
	002662	000001				.WORD	T\$CODE		
337				.EVEN					
338									
339	002664			ENDSFT					
	002664								
						L10003:	.EVEN		

```

347 002664      114      111      115  QS1:  .ASCIZ  /LIMIT RANGE OF SECTORS TO BE TESTED ?/
348 002732      104      117      040  QS2:  .ASCIZ  /DO YOU KNOW EXACT RANGE OF SECTORS TO TEST ?/
349 003007      106      111      122  QS3:  .ASCIZ  /FIRST SECTOR TO BE TESTED ?/
350 003047      114      101      123  QS4:  .ASCIZ  /LAST SECTOR TO BE TESTED ?/
351 003107      127      110      111  QS5:  .ASCIZ  /WHICH BOARD (0-15) TESTED ?/
352 003147      124      110      105  QS6:  .ASCII  /THE PROGRAM OPTIONS INCLUDE:/
353 003203      012      015      040  .ASCII <12><15>/ 1. ADDRESS CHECK/
354 003231      012      015      040  .ASCII <12><15>/ 2. PATTERN TEST/
355 003256      012      015      040  .ASCII <12><15>/ 3. UNIQUE DATA CHECK/
356 003310      012      015      040  .ASCII <12><15>/ 4. MARCH TEST/
357 003333      012      015      040  .ASCII <12><15>/ 5. RANDOMNESS TESTS/
358 003364      012      015      104  .ASCIZ <12><15>/DO YOU WANT TO DROP ANY OF THESE FROM THE EXERCISER ?/
359 003454      104      122      117  QS7:  .ASCIZ  /DROP OPTION 1 ?/
360 003474      104      122      117  QS8:  .ASCIZ  /DROP OPTION 2 ?/
361 003514      104      122      117  QS9:  .ASCIZ  /DROP OPTION 3 ?/
362 003534      104      122      117  QS10: .ASCIZ  /DROP OPTION 4 ?/
363 003554      120      101      124  QS11: .ASCIZ  /PATTERN NUMBER (1-10) TO BE USED WITH MARCH TEST ?/
364 003637      104      122      117  QS12: .ASCIZ  /DROP OPTION 5 ?/
365 003657      105      116      101  QS13: .ASCIZ  /ENABLE REFRESH MARGINING ?/
366 003724      104      111      123  QS14: .ASCIZ  /DISABLE ERROR CORRECTION ?/
367 003763      105      116      101  QS15: .ASCIZ  /ENABLE END OF PASS SUMMARY PRINTOUT ?/
368 004030      105      116      101  QS16: .ASCIZ  /ENABLE ERROR PRINTOUTS ?/
369 004066      105      116      101  QS17: .ASCIZ  /ENABLE SOFT ERROR TESTING ?/
370
371
372
373
374
375
376
377
378
379 004126      177777      BGNPROT
    004126      LSPROT::
380
381 004126      177777      -1      :OFFSET INTO P-TABLE FOR CSR ADDRESS
382 004130      177777      -1      :OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
383 004132      177777      -1      :OFFSET INTO P-TABLE FOR DRIVE NUMBER
384
385 004134      ENDPROT
386
400
401
402 004134      SPATCH:: .BLKW 32.      ;THIS LEAVES ROOM FOR THE 22 ML-11 REGISTERS TOO
403
410
411 004234      ENDMOD
412
413
414
415
428

```

```

:++
: THE PROTECTION TABLE IS USED BY THE RUNTIME
: SERVICES TO PROTECT THE LOAD MEDIA.
:--

```



```

1
2
3
4
5
6
7
8
9
10
11
12 005370 010046
13 005372 016700 000062
14 005376 000241
15 005400 005367 000052
16 005404 006100
17 005406 006100
18 005410 066700 000042
19 005414 066700 000042
20 005420 010067 000034
21 005424 006100
22 005426 006100
23 005430 066700 000026
24 005434 006100
25 005436 006100
26 005440 010067 000016
27 005444 016767 000010 000012
28 005452 012600
29 005454 000207
30
31
32
33 005456 000000
34 005460 001233
35 005462 007622
36
37 005464 000000
  
```

```

.SBTTL 'RANDOM NUMBER GENERATOR'
:ROUTINE TO GENERATE 16-BIT PSEUDO RANDOM NUMBERS
:INPUTS: NONE
:IMPLIED INPUTS: SEED1, SEED2, SEED3 are global values which will
                  be used by, but not input to the generator.
:OUTPUTS: 'RANDOM'--WORD CONTAINING RANDOM 16-BIT INTEGER VALUE
:IMPLIED OUTPUTS: NONE
:CALLING SEQUENCE: JSR PC,RN
  
```

```

RN::  MOV    R0,-(SP)
      MOV    SEED2,R0
      CLC
      DEC    SEED1
      ROL    R0
      ROL    R0
      ADD    SEED1,R0
      ADD    SEED3,R0
      MOV    R0,SEED2
      ROL    R0
      ROL    R0
      ADD    SEED3,R0
      ROL    R0
      ROL    R0
      MOV    R0,SEED3
      MOV    SEED2,RANDOM      ;SAVE NEW R.N.
      MOV    (SP)+,R0
      RTS    PC
  
```

```

SEED1:: .WORD 0
SEED2:: .WORD 1233
SEED3:: .WORD 7622
RANDOM:: .WORD 0
  
```

25-Mar-1982 22:23:37
 25-Mar-1982 22:21:30

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX3.BLI.1 (1)

```

6 :MLX3
7 :
8 :
9 :      0001  MODULE MLX3 =
10 :      0002  BEGIN
11 :      0003
12 :      0004  REQUIRE 'BLSMAC.REQ';
13 :      1494
14 :      1495  ZSBTTL 'REPORT CODING SECTION'
15 :      1496
16 :      1497  EXTERNAL ROUTINE
17 :      1498      EOP: NOVALUE;
18 :      1499
19 :      1500  BGNRPT;
20 :      1501
21 :      1502  EOP();
22 :      1503
23 :      1504  RETURN;
24 :      1505
25 :      1506  ENDRPT;
    
```

.GLOBL EOP

.SBTTL LRPT REPORT CODING SECTION

```

39 005466 004767 075234
40 005472 000207
    
```

```

LRPT: JSR PC,EOP
      RTS PC
    
```

1502
1498

```

: Routine Size: 3 words
: Maximum stack depth per invocation: 0 words
    
```

```

54 005474 004767 177766
    
```

```

.SBTTL LSRPT REPORT CODING SECTION
LSRPT:: JSR PC,LRPT
:MLX3
:
:
    
```

25-Mar-1982 22:23:37
 25-Mar-1982 22:21:30

1504
TOPS
PA:<

```

62 005500 104425
63 005502 000207
    
```

```

TRAP 25
RTS PC
    
```

```

: Routine Size: 4 words
: Maximum stack depth per invocation: 0 words
    
```

64
65
66
71
72

25-Mar-1982 22:23:57 TOPS-20 Bliss-16 V2(212)
 25-Mar-1982 22:21:30 PA:<NEALE>MLX3.BLI.1 (2)

```

74 :MLX3
75 :
76 :
77 : 1507 %SBTTL 'AUTODROP SECTION'
78 : 1508
79 : 1509
80 : 1510
81 : 1511
82 : 1512
83 : 1513
84 : 1514
85 : 1515
86 : 1516
87 : 1517
88 : 1518 BGAUTO;
89 : 1519
90 : 1520 RETURN;
91 : 1521
92 : 1522 ENDAUTO;
96 :
97 :
  
```

```

!++
THIS SECTION IS OPTIONALLY EXECUTED IMMEDIATELY AFTER THE INITIALIZATION
CODE IF THE /ADR FLAG WAS SET. THE INTENT IS TO EXAMINE THE UNITS UNDER
TEST TO SEE IF THEY WILL RESPOND. THOSE THAT DON'T RESPOND ARE DROPPED.

THIS FUNCTION IS AN INTEGRAL PART OF THE INITIALIZATION CODE ITSELF, AND
THEREFORE A SEPARATE AUTODROP SECTION IS REDUNDANT AND NOT PROVIDED.
!--
  
```

```

101 005504 000207          LAUTO: .SBTTL LAUTO AUTODROP SECTION
102                        RTS      PC                               ;          1506
103                        ; Routine Size: 1 word
104                        ; Maximum stack depth per invocation: 0 words
109
110
114
115
119 005506 004767 177772  LSAUTO: .SBTTL LSAUTO AUTODROP SECTION
120 005512 104461          :JSR    PC,LAUTO                       ;          1520
121 005514 000207          TRAP   61
122                        RTS      PC
123                        ; Routine Size: 4 words
124                        ; Maximum stack depth per invocation: 0 words
  
```

```

130 :MLX3
131 :
132 : DROP UNIT SECTION
133 : 1523 XSBTTL 'DROP UNIT SECTION'
134 : 1524
135 : 1525 !++
136 : 1526 ! THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DRIVE TO NO
137 : 1527 ! LONGER BE TESTED. WHEN THIS HAPPENS, THE FOLLOWING ACTIONS WILL BE
138 : 1528 ! TAKEN:
139 : 1529
140 : 1530 ! (1) SET THE DRIVE STATUS TO INACTIVE AND SET THE DRIVE'S DROP FLAG.
141 : 1531
142 : 1532 ! (2) DECREMENT THE NUMBER OF ACTIVE DRIVES, AND IF ZERO ABORT PASS.
143 : 1533 !--
144 : 1534
145 : 1535 BGNDU;
146 : 1536
147 : 1537 !+
148 : 1538 ! DELCARE THE EXTERNAL SUMMARY REPORT CODE
149 : 1539 ! DATA STORAGE LOCATIONS TO THIS SECTION
150 : 1540 !-
151 : 1541
152 : 1542 EXTERNAL
153 : 1543 LSLUN, !DEFINES NUMBER OF UUT'S ATTACHED
154 : 1544 DRIVE_STATUS:BITVECTOR[8], !DRIVE STATUS FLAG REGISTER
155 : 1545 DROPT_DRIVES:BITVECTOR[8], !DRIVE DROP STATUS FLAG REGISTER
156 : 1546 NUM_DRIVES; !INDICATES THE NUMBER OF ATTACHED UUT'S TO TEST
157 : 1547
158 : 1548
159 : 1549 LITERAL
160 : 1550 INACTIVE = 0, !CODE TO DESELECT UUT'S
161 : 1551 ACTIVE = 1; !CODE TO SELECT UUT'S
162 : 1552
163 : 1553
164 : 1554 !+
165 : 1555 ! THIS SECTION IS CALLED FOR THE PURPOSE OF
166 : 1556 ! DROPPING THIS UUT FROM FURTHER TESTING.
167 : 1557
168 : 1558 ! THEREFORE CLEAR THIS UUT'S DRIVE ACTIVE FLAG BIT
169 : 1559 ! AND SET THIS UUT'S DRIVE DROPPED FLAG.
170 : 1560 !-
171 : 1561
172 : 1562 DRIVE_STATUS[.LSLUN] = INACTIVE; !CLEAR THE DRIVE ACTIVE FLAG
173 : 1563 DROPT_DRIVES[.LSLUN] = ACTIVE; !SET THE DRIVES DROPPED FLAG
174 : 1564
175 : 1565 !+
176 : 1566 ! DECRIMENT THE GLOBAL VARIABLE 'NUM DRIVES' WHICH
177 : 1567 ! STORES THE NUMBER OF UUT'S WHICH ARE TESTED BY THIS
178 : 1568 ! EXERCISER.
179 : 1569
180 : 1570 ! IF THE NUMBER OF DRIVES REMAINING TO TEST IS ZERO
181 : 1571 ! THEN CALL THE CLEAN UP CODE SECTION AND EXIT THIS
182 : 1572 ! PROGRAM ELSE CONTINUE TESTING THE REMAINING ACTIVE
183 : 1573 ! UUT'S.
184 : 1574 !-
185 :MLX3
186 : DROP UNIT SECTION

```

25-Mar-1982 22:23:37
25-Mar-1982 22:21:30

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX3.BLI.1 (3)

25-Mar-1982 22:23:37
25-Mar-1982 22:21:30

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX3.BLI.1 (3)

LSAUTO AUTODROP SECTION

```
187  
188 :  
189 :  
190 :  
191 :  
192 :  
193 :  
194 :  
195 :  
196 :  
200  
201  
202  
203  
204  
205
```

```
1575  
1576 NUM_DRIVES = .NUM_DRIVES - 1;           !DECRIEMENT THE NUMBER OF DRIVES REMAINING TO TEST  
1577  
1578  
1579 IF .NUM_DRIVES EQL 0 THEN DOCLN;         !DO CLEAN UP CODE AND EXIT PROG IF ZERO  
1580  
1581 RETURN;  
1582  
1583 ENDDU;
```

```
.GLOBL LSLUN, DRIVE.STATUS, DROPT.DRIVES  
.GLOBL NUM.DRIVES
```

```
.SBTTL LDU DROP UNIT SECTION
```

210 005516 016700 174352
 211 005522 006200
 212 005524 006200
 213 005526 006200
 214 005530 062700 034442
 215 005534 010046
 216 005536 016746 174332
 217 005542 042716 177770
 218 005546 012746 000001
 219 005552 005046
 220 005554 004767 177034
 221 005560 016700 174310
 222 005564 006200
 223 005566 006200
 224 005570 006200
 225 005572 062700 034444
 226 005576 010016
 227 005600 016746 174270
 228 005604 042716 177770
 229 005610 012746 000001
 230 005614 011646
 231 005616 004767 176772
 232 005622 005367 026630
 233 005626 001001
 234 005630 104444
 235 005632 062706 000016
 236 005636 000207
 237
 238
 239
 247
 248
 252
 253
 257 005640 004767 177652
 258 005644 104453
 259 005646 000207
 260
 261
 262
 267
 268

```

LDU:  MOV    L$LUN,RO      ;
      ASR    RO              ;
      ASR    RO              ;
      ASR    RO              ;
      ADD    #DRIVE.STATUS,RO
      MOV    RO,-(SP)
      MOV    L$LUN,-(SP)
      BIC    #177770,(SP)
      MOV    #1,-(SP)
      CLR    -(SP)
      JSR    PC,BL$PU2
      MOV    L$LUN,RO      ;
      ASR    RO              ;
      ASR    RO              ;
      ASR    RO              ;
      ADD    #DROPT.DRIVES,RO
      MOV    RO,(SP)
      MOV    L$LUN,-(SP)
      BIC    #177770,(SP)
      MOV    #1,-(SP)
      MOV    (SP),-(SP)
      JSR    PC,BL$PU2
      DEC    NUM.DRIVES    ;
      BNE    1$            ;
      TRAP   44            ;
1$:   ADD    #16,SP      ;
      RTS    PC
    
```

1562

1563

1576

1579

1522

: Routine Size: 41 words
 : Maximum stack depth per invocation: 7 words

```

.LSBTTL  LSDU DROP UNIT SECTION
LSDU::  JSR    PC,LDU      ;
      TRAP   53
      RTS    PC
    
```

1581

: Routine Size: 4 words
 : Maximum stack depth per invocation: 0 words

270 :MLX3
271 :
272 :
273 :
274 :
275 :
276 :
277 :
278 :
279 :
280 :
281 :
282 :
283 :
284 :
285 :
286 :
287 :
291
292
296 005650 000207
297

ADD UNIT SECTION

25-Mar-1982 22:23:37
25-Mar-1982 22:21:30

TOPS-20 BLISS-16 V2(212)
PA:<NEALE>MLX3.BLI.1 (4)

%SBTTL 'ADD UNIT SECTION'

!++
THE ADD UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
TO THE TEST CYCLE. SINCE THE INITIALIZATION CODE WILL HAVE
TO BE EXECUTED IMMEDIATELY AFTER AN 'ADD', THERE IS NO NEED
FOR ANY CODE IN THIS SECTION.
!--

BGNAU;
RETURN;
ENDAU;

LAU: .SBTTL LAU ADD UNIT SECTION
RTS PC ;

1583

299 : Routine Size: 1 word
300 : Maximum stack depth per invocation: 0 words
305
306
310

311
315 005652 004767 177772
316 005656 104452
317 005660 000207
318
319

LSAU:: .SBTTL LSAU ADD UNIT SECTION
JSR PC,LAU
TRAP S2
RTS PC

1596

320 : Routine Size: 4 words
325 : Maximum stack depth per invocation: 0 words
326 : MLX3 1599

327 : ADD UNIT SECTION
328

25-Mar-1982 22:23:37 TOPS-20 Bliss-16 V2(212)
25-Mar-1982 22:21:30 PA:<NEALE>MLX3.BLI.1 (4)

329 : 1600
330 : 1601 END
331 : 1602
332 : 1603 ELUDOM
336

338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353

; OTS external references
 .GLOBL BL\$PU2

:
:
:
: Size: 1604
: 1605
: Run Time: 62 code + 0 data words
: Elapsed Time: 00:03.3
: Memory Used: 26 pages
: Compilation Complete

6	:MLX4			
7	:			
8	:			
9	:	0001	MODULE MLX4 =	
10	:	0002	BEGIN	
11	:	0003	:	
12	:	0004	PERTTY BLF COMMANDS	
13	:	0005	:	
14	:	0006	<BLF/NOERRORS>	
15	:	0007	<BLF/LOWERCASE_KEY>	
16	:	0008	:	
17	:	0009	:	
18	:	0010	require 'BLSMAC.REQ';	
19	:	1500	:	
20	:MLX4			
21	:		VARIABLES AND CONSTANTS	
22	:			
23	:	1501	%sbttl 'VARIABLES AND CONSTANTS'	
24	:	1502	:	
25	:	1503	Literal	
26	:	1504	:	
27	:	1505	VER CZMLBB ADDED LITERAL TRUE, FALSE AND ZERO	
28	:	1506	:	
29	:	1507	ZERO = %o'000000',	!DEFINE ZERO DATA
30	:	1508	TRUE = 1,	!LOGICAL TRUE INDICATOR
31	:	1509	FALSE = 0,	!LOGICAL FALSE INDICATOR
32	:	1510	:	
33	:	1511	OTHER LITERAL DEFINITIONS	
34	:	1512	:	
35	:	1513	ONE = 1,	!NUMBER OF TIMES TO RETRY FOR DATA ERROR
36	:	1514	SIX = 6,	!NUMBER OF TIMES TO RETRY FOR SYSTEM ERROR
37	:	1515	NUM_PATS = 10,	!NUMBER OF REGULAR PATTERNS
38	:	1516	NUM_REGS = 22,	!NUMBER OF ML11 REGISTERS
39	:	1517	TIMES TO LOOP = 2,	!LOOP READING CONSTANT
40	:	1518	BUFSIZ = 256*8,	!2048 16-BIT WORDS IN A FULL BUFFER
41	:	1519	256 = NUMBER OF WORDS IN A SECTOR	
42	:	1520	8 = NUMBER OF SECTORS IN THE BUFFER	
43	:	1521	:	
44	:	1522	ML11 DRIVE TYPES:	
45	:	1523	:	
46	:	1524	ML11A = %o'000110',	!16K CHIPS
47	:	1525	ML11B = %o'000111',	!64K CHIPS
48	:	1526	:	
49	:	1527	FUNCTION CODES:	
50	:	1528	:	
51	:	1529	DRV_CLR = %o'11',	
52	:	1530	WC_CMD = %o'51',	
53	:	1531	WR_CMD = %o'61',	
54	:	1532	RD_CMD = %o'71',	
55	:	1533	:	
56	:	1534	STATUS CODES:	
57	:	1535	:	
58	:	1536	INACTIVE = 0,	
59	:	1537	ACTIVE = 1,	
60	:	1538	:	
61	:	1539	ERROR THRESHOLD VALUES:	
62	:	1540	:	

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (1)

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (2)

LSAU ADD UNIT SECTION

63 :	1541	S16K_LIMIT = 10,	!SOFT ERROR, 16K ARRAYS
64 :	1542	H16K_LIMIT = 10,	!HARD ERROR, 16K ARRAYS
65 :	1543	S64K_LIMIT = 10,	!SOFT ERROR, 64K ARRAYS
66 :	1544	H64K_LIMIT = 10,	!HARD ERROR, 64K ARRAYS
67 :	1545		!
68 :	1546	! SUMMARY OF ERROR CODES:	
69 :	1547		
70 :	1548	! THE 'INTEGRITY' ROUTINE:	
71 :	1549		
72 :	1550		
73 :	1551	!WRITE COMMAND:	
74 :	1552	!ERRDF(1,MSG1,0):	!*** INTEGRITY ROUTINE ERROR 01 ***

76 :MLX4

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (2)

VARIABLES AND CONSTANTS

```

79 : 1553 :ERRDF(2,MSG1,0): :**** INTEGRITY ROUTINE ERROR 02 ****
80 : 1554 :ERRDF(3,MSG1,0): :**** INTEGRITY ROUTINE ERROR 03 ****
81 : 1555 :READ COMMAND:
82 : 1556 :ERRDF(4,MSG1,0): :**** INTEGRITY ROUTINE ERROR 04 ****
83 : 1557 :ERRDF(5,MSG1,0): :**** INTEGRITY ROUTINE ERROR 05 ****
84 : 1558 :ERRDF(6,MSG1,0): :**** INTEGRITY ROUTINE ERROR 06 ****
85 : 1559 :ERRDF(7,MSG1,0): :**** INTEGRITY ROUTINE ERROR 07 ****
86 : 1560 :ERRDF(8,MSG2,0): :**** INTEGRITY ROUTINE ERROR 08 ****
87 : 1561 :ERRHRD(9,MSG4,0): :**** INTEGRITY ROUTINE ERROR 09 ****
88 : 1562 :ERRSOFT(10,MSG3,0): :**** INTEGRITY ROUTINE ERROR 10 ****
89 : 1563 :ERRSOFT(11,MSG3,1): :**** INTEGRITY ROUTINE ERROR 10 ****
90 : 1564 :WRITE CHECK COMMAND:
91 : 1565 :ERRDF(12,MSG1,0): :**** INTEGRITY ROUTINE ERROR 12 ****
92 : 1566 :ERRDF(13,MSG1,0): :**** INTEGRITY ROUTINE ERROR 13 ****
93 : 1567 :ERRDF(14,MSG1,0): :**** INTEGRITY ROUTINE ERROR 14 ****
94 : 1568 :ERRDF(15,MSG2,0): :**** INTEGRITY ROUTINE ERROR 15 ****
95 : 1569 :ERRHRD(16,MSG4,0): :**** INTEGRITY ROUTINE ERROR 16 ****
96 : 1570 :ERRSOFT(17,MSG3,8): :**** INTEGRITY ROUTINE ERROR 17 ****
97 : 1571 :ERRSOFT(18,MSG3,1): :**** INTEGRITY ROUTINE ERROR 18 ****
98 : 1572
99 : 1573 :OPTION 1:
100 : 1574
101 : 1575 :WRITE COMMAND:
102 : 1576 :ERRDF(101,MSG1,0): :**** OPTION 1 ERROR 01 ****
103 : 1577 :ERRDF(102,MSG1,0): :**** OPTION 1 ERROR 02 ****
104 : 1578 :ERRDF(103,MSG1,0): :**** OPTION 1 ERROR 03 ****
105 : 1579 :CHECK OR READ:
106 : 1580 :ERRDF(104,MSG1,0): :**** OPTION 1 ERROR 04 ****
107 : 1581 :ERRDF(105,MSG1,0): :**** OPTION 1 ERROR 05 ****
108 : 1582 :ERRDF(106,MSG1,0): :**** OPTION 1 ERROR 06 ****
109 : 1583 :ERRDF(107,MSG1,0): :**** OPTION 1 ERROR 07 ****
110 : 1584 :ERRDF(108,MSG2,0): :**** OPTION 1 ERROR 08 ****
111 : 1585 :ERRHRD(109,MSG4,0): :**** OPTION 1 ERROR 09 ****
112 : 1586 :ERRSOFT(110,MSG3,0): :**** OPTION 1 ERROR 10 ****
113 : 1587 :ERRSOFT(111,MSG3,0): :**** OPTION 1 ERROR 11 ****
114 : 1588
115 : 1589 :OPTION 2:
116 : 1590
117 : 1591 :WRITE COMMAND:
118 : 1592 :ERRDF(201,MSG1,0): :**** OPTION 2 ERROR 01 ****
119 : 1593 :ERRDF(202,MSG1,0): :**** OPTION 2 ERROR 02 ****
120 : 1594 :ERRDF(203,MSG1,0): :**** OPTION 2 ERROR 03 ****
121 : 1595 :CHECK OR READ:
122 : 1596 :ERRDF(204,MSG1,0): :**** OPTION 2 ERROR 04 ****
123 : 1597 :ERRDF(205,MSG1,0): :**** OPTION 2 ERROR 05 ****
124 : 1598 :ERRDF(206,MSG1,0): :**** OPTION 2 ERROR 06 ****
125 : 1599 :ERRDF(207,MSG1,0): :**** OPTION 2 ERROR 07 ****
126 : 1600 :ERRDF(208,MSG2,0): :**** OPTION 2 ERROR 08 ****
127 : 1601 :ERRHRD(209,MSG4,0): :**** OPTION 2 ERROR 09 ****
128 : 1602 :ERRSOFT(210,MSG3,0): :**** OPTION 2 ERROR 10 ****
129 : 1603 :ERRSOFT(211,MSG3,1): :**** OPTION 2 ERROR 10 ****
130 : 1604 :LOOP CHECK OR READ:
    
```

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (2)

132 :MLX4
133 :
134 :
135 :
136 :
137 :
138 :
139 :
140 :
141 :
142 :
143 :
144 :
145 :
146 :
147 :
148 :
149 :
150 :
151 :
152 :
153 :
154 :
155 :
156 :
157 :
158 :
159 :
160 :
161 :
162 :
163 :
164 :
165 :
166 :
167 :
168 :
169 :
170 :
171 :
172 :
173 :
174 :
175 :
176 :
177 :
178 :
179 :
180 :
181 :
182 :
183 :
184 :
185 :
186 :

VARIABLES AND CONSTANTS

```
!ERRDF(212,MSG1,0): !**** OPTION 2 ERROR 12 ****
!ERRDF(213,MSG1,0): !**** OPTION 2 ERROR 13 ****
!ERRDF(214,MSG1,0): !**** OPTION 2 ERROR 14 ****
!ERRDF(215,MSG1,0): !**** OPTION 2 ERROR 15 ****
!ERRDF(216,MSG2,0): !**** OPTION 2 ERROR 16 ****
!ERRHRD(217,MSG4,0): !**** OPTION 2 ERROR 17 ****
!ERRSOFT(218,MSG3,0): !**** OPTION 2 ERROR 18 ****
!ERRSOFT(219,MSG3,0): !**** OPTION 2 ERROR 19 ****

OPTION 3:

WRITE COMMAND:
!ERRDF(301,MSG1,0): !**** OPTION 3 ERROR 01 ****
!ERRDF(302,MSG1,0): !**** OPTION 3 ERROR 02 ****
!ERRDF(303,MSG1,0): !**** OPTION 3 ERROR 03 ****

CHECK OR READ:
!ERRDF(304,MSG1,0): !**** OPTION 3 ERROR 04 ****
!ERRDF(305,MSG1,0): !**** OPTION 3 ERROR 05 ****
!ERRDF(306,MSG1,0): !**** OPTION 3 ERROR 06 ****
!ERRDF(307,MSG1,0): !**** OPTION 3 ERROR 07 ****
!ERRDF(308,MSG2,0): !**** OPTION 3 ERROR 08 ****
!ERRHRD(309,MSG4,0): !**** OPTION 3 ERROR 09 ****
!ERRSOFT(310,MSG3,0): !**** OPTION 3 ERROR 10 ****
!ERRSOFT(311,MSG3,0): !**** OPTION 3 ERROR 11 ****

OPTION 4:

MARCHING UP:
WRITE DATA:
!ERRDF(401,MSG1,0): !**** OPTION 4 ERROR 01 ****
!ERRDF(402,MSG1,0): !**** OPTION 4 ERROR 02 ****
!ERRDF(403,MSG1,0): !**** OPTION 4 ERROR 03 ****

MARCHING UP:
CHECK OR READ DATA:
!ERRDF(404,MSG1,0): !**** OPTION 4 ERROR 04 ****
!ERRDF(405,MSG1,0): !**** OPTION 4 ERROR 05 ****
!ERRDF(406,MSG1,0): !**** OPTION 4 ERROR 06 ****
!ERRDF(407,MSG1,0): !**** OPTION 4 ERROR 07 ****
!ERRDF(408,MSG2,0): !**** OPTION 4 ERROR 08 ****
!ERRHRD(409,MSG4,0): !**** OPTION 4 ERROR 09 ****
!ERRSOFT(410,MSG3,0): !**** OPTION 4 ERROR 10 ****
!ERRSOFT(411,MSG3,0): !**** OPTION 4 ERROR 11 ****

WRITE COMP:
!ERRDF(412,MSG1,0): !**** OPTION 4 ERROR 12 ****
!ERRDF(413,MSG1,0): !**** OPTION 4 ERROR 13 ****
!ERRDF(414,MSG1,0): !**** OPTION 4 ERROR 14 ****

MARCHING DOWN:
CHECK OR READ COMP:
!ERRDF(415,MSG1,0): !**** OPTION 4 ERROR 15 ****
!ERRDF(416,MSG1,0): !**** OPTION 4 ERROR 16 ****
!ERRDF(417,MSG1,0): !**** OPTION 4 ERROR 17 ****
!ERRDF(418,MSG1,0): !**** OPTION 4 ERROR 18 ****
```

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (2)

188 :MLX4
189 :
190 :
191 :
192 :
193 :
194 :
195 :
196 :
197 :
198 :
199 :
200 :
201 :
202 :
203 :
204 :
205 :
206 :
207 :
208 :
209 :
210 :
211 :
212 :
213 :
214 :
215 :
216 :
217 :
218 :
219 :
220 :
221 :
222 :
223 :
224 :
225 :
226 :
227 :
228 :
229 :
230 :
231 :
232 :
233 :
234 :
235 :
236 :
237 :
238 :
239 :
240 :
241 :
242 :

VARIABLES AND CONSTANTS

```
1657 :ERRDF(419,MSG2,0): :**** OPTION 4 ERROR 19 ****
1658 :ERRHRD(420,MSG4,0): :**** OPTION 4 ERROR 20 ****
1659 :ERRSOFT(421,MSG3,0): :**** OPTION 4 ERROR 21 ****
1660 :ERRSOFT(422,MSG3,0): :**** OPTION 4 ERROR 22 ****
1661 :WRITE DATA:
1662 :ERRDF(423,MSG1,0): :**** OPTION 4 ERROR 23 ****
1663 :ERRDF(424,MSG1,0): :**** OPTION 4 ERROR 24 ****
1664 :ERRDF(425,MSG1,0): :**** OPTION 4 ERROR 25 ****
1665 :MARCHING UP:
1666 :CHECK OR READ DATA:
1667 :ERRDF(426,MSG1,0): :**** OPTION 4 ERROR 26 ****
1668 :ERRDF(427,MSG1,0): :**** OPTION 4 ERROR 27 ****
1669 :ERRDF(428,MSG1,0): :**** OPTION 4 ERROR 28 ****
1670 :ERRDF(429,MSG1,0): :**** OPTION 4 ERROR 29 ****
1671 :ERRDF(430,MSG2,0): :**** OPTION 4 ERROR 30 ****
1672 :ERRHRD(431,MSG4,0): :**** OPTION 4 ERROR 31 ****
1673 :ERRSOFT(432,MSG3,0): :**** OPTION 4 ERROR 32 ****
1674 :ERRSOFT(433,MSG3,0): :**** OPTION 4 ERROR 33 ****

1676 : OPTION 5:
1678 : 'RAND1' ROUTINE:
1679 : WRITE COMMAND:
1680 :ERRDF(5101,MSG1,0): :**** OPTION 5, RAND1 ERROR 01 ****
1681 :ERRDF(5102,MSG1,0): :**** OPTION 5, RAND1 ERROR 02 ****
1682 :ERRDF(5103,MSG1,0): :**** OPTION 5, RAND1 ERROR 03 ****
1683 :CHECK OR READ:
1684 :ERRDF(5104,MSG1,0): :**** OPTION 5, RAND1 ERROR 04 ****
1685 :ERRDF(5105,MSG1,0): :**** OPTION 5, RAND1 ERROR 05 ****
1686 :ERRDF(5106,MSG1,0): :**** OPTION 5, RAND1 ERROR 06 ****
1687 :ERRDF(5107,MSG1,0): :**** OPTION 5, RAND1 ERROR 07 ****
1688 :ERRDF(5108,MSG2,0): :**** OPTION 5, RAND1 ERROR 08 ****
1689 :ERRHRD(5109,MSG4,0): :**** OPTION 5, RAND1 ERROR 09 ****
1690 :ERRSOFT(5110,MSG3,0): :**** OPTION 5, RAND1 ERROR 10 ****
1691 :ERRSOFT(5111,MSG3,0): :**** OPTION 5, RAND1 ERROR 11 ****
1692 : 'RAND2' ROUTINE:
1693 : WRITE COMMAND:
1694 :ERRDF(5201,MSG1,0): :**** OPTION 5, RAND2 ERROR 01 ****
1695 :ERRDF(5202,MSG1,0): :**** OPTION 5, RAND2 ERROR 02 ****
1696 :ERRDF(5203,MSG1,0): :**** OPTION 5, RAND2 ERROR 03 ****
1697 :CHECK OR READ:
1698 :ERRDF(5204,MSG1,0): :**** OPTION 5, RAND2 ERROR 04 ****
1699 :ERRDF(5205,MSG1,0): :**** OPTION 5, RAND2 ERROR 05 ****
1700 :ERRDF(5206,MSG1,0): :**** OPTION 5, RAND2 ERROR 06 ****
1701 :ERRDF(5207,MSG1,0): :**** OPTION 5, RAND2 ERROR 07 ****
1702 :ERRDF(5208,MSG2,0): :**** OPTION 5, RAND2 ERROR 08 ****
1703 :ERRHRD(5209,MSG4,0): :**** OPTION 5, RAND2 ERROR 09 ****
1704 :ERRSOFT(5210,MSG3,0): :**** OPTION 5, RAND2 ERROR 10 ****
1705 :ERRSOFT(5211,MSG3,0): :**** OPTION 5, RAND2 ERROR 11 ****
1706 : 'RAND3' ROUTINE:
1707 : WRITE COMMAND:
1708 :ERRDF(5301,MSG1,0): :**** OPTION 5, RAND3 ERROR 01 ****
```

244 :MLX4
 245 :
 246 :
 247 :
 248 :
 249 :
 250 :
 251 :
 252 :
 253 :
 254 :
 255 :
 256 :
 257 :
 258 :
 259 :
 260 :
 261 :
 262 :
 263 :
 264 :
 265 :
 266 :
 267 :
 268 :
 269 :
 270 :
 271 :
 272 :
 273 :
 274 :
 275 :
 276 :
 277 :
 278 :
 279 :
 280 :
 281 :
 282 :
 283 :
 284 :
 285 :
 286 :
 287 :
 288 :
 289 :
 290 :
 291 :
 292 :
 293 :
 294 :
 295 :
 296 :
 297 :
 298 :

VARIABLES AND CONSTANTS

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (2)

```

1709 :ERRDF(5302,MSG1,0): :**** OPTION 5, RAND3 ERROR 02 ****
1710 :ERRDF(5303,MSG1,0): :**** OPTION 5, RAND3 ERROR 03 ****
1711 :CHECK OR READ:
1712 :ERRDF(5304,MSG1,0): :**** OPTION 5, RAND3 ERROR 04 ****
1713 :ERRDF(5305,MSG1,0): :**** OPTION 5, RAND3 ERROR 05 ****
1714 :ERRDF(5306,MSG1,0): :**** OPTION 5, RAND3 ERROR 06 ****
1715 :ERRDF(5307,MSG1,0): :**** OPTION 5, RAND3 ERROR 07 ****
1716 :ERRDF(5308,MSG2,0): :**** OPTION 5, RAND3 ERROR 08 ****
1717 :ERRHRD(5309,MSG4,0): :**** OPTION 5, RAND3 ERROR 09 ****
1718 :ERRSOFT(5310,MSG3,0): :**** OPTION 5, RAND3 ERROR 10 ****
1719 :ERRSOFT(5311,MSG3,0): :**** OPTION 5, RAND3 ERROR 11 ****
1720 :'RAND4' ROUTINE:
1721 :WRITE COMMAND:
1722 :ERRDF(5401,MSG1,0): :**** OPTION 5, RAND4 ERROR 01 ****
1723 :ERRDF(5402,MSG1,0): :**** OPTION 5, RAND4 ERROR 02 ****
1724 :ERRDF(5403,MSG1,0): :**** OPTION 5, RAND4 ERROR 03 ****
1725 :CHECK OR READ:
1726 :ERRDF(5404,MSG1,0): :**** OPTION 5, RAND4 ERROR 04 ****
1727 :ERRDF(5405,MSG1,0): :**** OPTION 5, RAND4 ERROR 05 ****
1728 :ERRDF(5406,MSG1,0): :**** OPTION 5, RAND4 ERROR 06 ****
1729 :ERRDF(5407,MSG1,0): :**** OPTION 5, RAND4 ERROR 07 ****
1730 :ERRDF(5408,MSG2,0): :**** OPTION 5, RAND4 ERROR 08 ****
1731 :ERRHRD(5409,MSG4,0): :**** OPTION 5, RAND4 ERROR 09 ****
1732 :ERRSOFT(5410,MSG3,0): :**** OPTION 5, RAND4 ERROR 10 ****
1733 :ERRSOFT(5411,MSG3,0): :**** OPTION 5, RAND4 ERROR 11 ****
    
```

CODES FOR WHY A UNIT WAS DROPPED:

```

1737 :CODE_1 = 1, :DRIVE NOT POWERED UP
1738 :CODE_2 = 2, :DRIVE NOT AN ML11 UNIT
1739 :CODE_3 = 3, :OPERATOR SET TEST LIMITS INCORRECTLY
1740 :CODE_4 = 4, :FAILED ALL RETRIES FOR A NON-FATAL ERROR
1741 :CODE_5 = 5, :CONTROLLER FATAL ERROR
1742 :CODE_6 = 6, :DRIVE FATAL ERROR
1743 :CODE_7 = 7, :ECC HARD ERROR
1744 :CODE_8 = 8, :ECC LOGIC FAILED TO DETECT ERROR
    
```

FIELD DECLARTIONS

field

VER CZMLBB ADD FIELD DECLARATION

FIELD DECLARATION TO MAP THE SINGLE BIT
 ERROR LOG TABLE.

SBE_TBL_MAP =

set

BNKS_SBE = [0, 0, 2, 0],
 BRDS_SBE = [0, 2, 4, 0].

!LOG BANK OF SBE
 !LOG BOARD OF SBE

```

300 :MLX4
301 :
302 :
303 :      1761          BITS_SBE = [0, 6, 7, 0],
304 :      1762          UNITS_SBE = [0, 13, 3, 0],
305 :      1763          SUMS_SBE = [1, 0, 16, 0],
306 :      1764          WRDS_0 = [0, 0, 16, 0],
307 :      1765          WRDS_1 = [1, 0, 16, 0]
308 :      1766          tes,
309 :
310 :      1768          VER CZMLBB ADDED FIELD DECLARATION
311 :
312 :      1770          FIELD DECLARATION FOR PROM MAINTENANCE
313 :      1771          SUM TABLE
314 :
315 :      1773          PM_SBE_MAP =
316 :      1774          set
317 :      1775          PM_SBE$SUM = [0, 16, 0]
318 :      1776          tes,
319 :
320 :      1778          FIELD DECLARATION FOR PATTERN TABLE
321 :
322 :      1780          PATMAP =
323 :      1781          set
324 :      1782          COUNT1 = [0, 0, 16, 0],
325 :      1783          COUNT2 = [1, 0, 16, 0]
326 :      1784          tes;
327 :
328 :      1786          own
329 :      1787          :
330 :      1788          : Single bit error logging and Prom Maint
331 :      1789          : program storage structures
332 :      1790          :
333 :      1791          VER CZMLBB ADDED FOLLOWING THREE DATA DECLARATIONS
334 :      1792          :
335 :      1793          SBE_LOG : blockvector [128, 2, word] field (SBE_TBL_MAP), !SBE LOCATION TABLE
336 :      1794          PM_SBE_CNT : blockvector [8, 16, word] field (PM_SBE_MAP), !ARRAY SBE COUNT TABLE
337 :      1795          SBE$COUNT : word, !COUNTS NUMBER OF SBE LOCATION TABLE ENTRIES
338 :      1796          BIT_NUM, !STORS FAILING SBE CHIP NUMBER
339 :      1797          :
340 :      1798          ML-11 EXERCISER STORAGE ALLOCATION
341 :      1799          :
342 :      1800          WBUFF : vector [BUFSIZ] volatile, !IMPORTANT -- WBUFF AND RBUFF MUST
343 :      1801          RBUFF : vector [BUFSIZ] volatile, !BE CONTIGUOUS AND IN THAT ORDER!!
344 :      1802          WPTR : volatile,
345 :      1803          RPTR : volatile,
346 :      1804          QUICK : volatile,
347 :      1805          PATTERN : volatile,
348 :      1806          DATA_COUNT : volatile,
349 :      1807          COMP_COUNT : volatile,
350 :      1808          EOP_COUNT : volatile,
351 :      1809          BASE_ADDR,
352 :      1810          VEC,
353 :      1811          BR_LEVEL,
354 :      1812          SOFTS : blockvector [8, 16], !COUNTS FOR 8 LUNS, 16 ARRAYS EACH
    
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (2)

!LOG BIT OF SBE
 !LOG UNIT OF SBE
 !LOG NUMBER OF TIMES OCCURRING
 !ACCESS FIRST WORD OF TABLE
 !ACCESS SECOND WORD OF TABE

!ACCESS NUMBER OF SBE PER ARRAY

!SBE LOCATION TABLE
 !ARRAY SBE COUNT TABLE
 !COUNTS NUMBER OF SBE LOCATION TABLE ENTRIES
 !STORS FAILING SBE CHIP NUMBER

!IMPORTANT -- WBUFF AND RBUFF MUST
 !BE CONTIGUOUS AND IN THAT ORDER!!

!COUNTS FOR 8 LUNS, 16 ARRAYS EACH

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (2)

356 :MLX4
 357 :
 358 :
 359 :
 360 :
 361 :
 362 :
 363 :
 364 :
 365 :
 366 :
 367 :
 368 :
 369 :
 370 :
 371 :
 372 :
 373 :
 374 :
 375 :
 376 :
 377 :
 378 :
 379 :
 380 :
 381 :
 382 :
 383 :
 384 :
 385 :
 386 :
 387 :
 388 :
 389 :
 390 :
 391 :
 392 :
 393 :
 394 :
 395 :
 396 :
 397 :
 398 :
 399 :
 400 :
 401 :
 402 :
 403 :
 404 :
 405 :
 406 :
 407 :
 408 :
 409 :
 410 :

VARIABLES AND CONSTANTS

```

1813 HARDS : blockvector [8, 16],
1814 TRIES : blockvector [8, 16],
1815 WR_COUNT,
1816 WR_THOUSANDS,
1817 WR_MILLIONS,
1818 RD_COUNT,
1819 RD_THOUSANDS,
1820 RD_MILLIONS,
1821 WC_COUNT,
1822 WC_THOUSANDS,
1823 WC_MILLIONS,
1824 I_AM_DONE,
1825 RETRYING,
1826 BOARD,
1827 BANK;

global
1830 ML_REG : vector [NUM_REGS] volatile,
1831 PTABLE_ADDR : vector [8] volatile,
1832 DRIVE_STATUS : bitvector [8] volatile,
1833 DROPT_DRIVES : bitvector [8] volatile,
1834 WHY_DROPT : vector [8, byte],
1835 NUM_DRIVES,
1836 LOW_SECT : vector [8] volatile,
1837 TOP_SECT : vector [8] volatile;

EQUALS:
1840
1841 macro
1842 :
1843 : TO CALCULATE THE TEST RANGES FOR A PARTICULAR LOGICAL UNIT:
1844 :
1845 M 1845 : LOWEST =
1846 : .LOW_SECT[.LUN]%, !THE FIRST SECTOR TO TEST
1847 M 1847 : HIGHEST =
1848 : .TOP_SECT[.LUN]%, !THE LAST SECTOR TO TEST
1849 :
1850 : ADDRESS IN MAIN MEMORY THAT CONTAINS THE PHYSICAL DRIVE
1851 : NUMBER THAT CORRESPONDS TO A PARTICULAR LOGICAL UNIT:
1852 :
1853 M 1853 : DRIVE =
1854 : (.PTABLE_ADDR[.LUN] + 6)%,
1855 :
1856 : ML-11 REGISTER NAMES:
1857 :
1858 M 1858 : MLCS1 =
1859 : .ML_REGE0]%, !CONTROL AND STATUS REGISTER 1
1860 M 1860 : MLWC =
1861 : .ML_REGE1]%, !WORD COUNT REGISTER
1862 M 1862 : MLBA =
1863 : .ML_REGE2]%, !UNIBUS ADDRESS REGISTER
1864 M 1864 : MLDA =
    
```

412 :MLX4
 413 :
 414 :
 415 :
 416 : M
 417 : M
 418 : M
 419 :
 420 : M
 421 :
 422 : M
 423 :
 424 : M
 425 :
 426 : M
 427 :
 428 : M
 429 :
 430 : M
 431 :
 432 : M
 433 :
 434 : M
 435 :
 436 : M
 437 :
 438 : M
 439 :
 440 : M
 441 :
 442 : M
 443 :
 444 : M
 445 :
 446 : M
 447 :
 448 : M
 449 :
 450 : M
 451 :
 452 :
 453 :
 454 :
 455 :
 456 :
 457 :
 458 : M
 459 :
 460 : M
 461 :
 462 : M
 463 :
 464 : M
 465 :
 466 : M

VARIABLES AND CONSTANTS

1865 .ML REG[3]%,
 1866 MLCS2 =
 1867 .ML REG[4]%,
 1868 MLDS =
 1869 .ML REG[5]%,
 1870 MLER =
 1871 .ML REG[6]%,
 1872 MLAS =
 1873 .ML REG[7]%,
 1874 MLPA =
 1875 .ML REG[8]%,
 1876 MLDB =
 1877 .ML REG[9]%,
 1878 MLMR =
 1879 .ML REG[10]%,
 1880 MLDT =
 1881 .ML REG[11]%,
 1882 MLSN =
 1883 .ML REG[12]%,
 1884 MLE1 =
 1885 .ML REG[13]%,
 1886 MLE2 =
 1887 .ML REG[14]%,
 1888 MLD1 =
 1889 .ML REG[15]%,
 1890 MLD2 =
 1891 .ML REG[16]%,
 1892 MLEE =
 1893 .ML REG[17]%,
 1894 MLEL =
 1895 .ML REG[18]%,
 1896 MLPD =
 1897 .ML REG[19]%,
 1898 MLBAE =
 1899 .ML REG[20]%,
 1900 MLCS3 =
 1901 .ML REG[21]%,
 1902 !
 1903 ! BIT ASSIGNMENTS:
 1904 !
 1905 ! MLCS1 BITS:
 1906 !
 1907 ! SC =
 1908 (MLCS1)<15,1>%,
 1909 TRE =
 1910 (MLCS1)<14,1>%,
 1911 MCPE =
 1912 (MLCS1)<13,1>%,
 1913 DVA =
 1914 (MLCS1)<11,1>%,
 1915 RDY =
 1916

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (2)

!DESIRED ADDRESS REGISTER
 !CONTROL AND STATUS REGISTER 2
 !DRIVE STATUS REGISTER
 !ERROR REGISTER
 !ATTENTION SUMMARY REGISTER
 !PROM ADDRESS REGISTER
 !DATA BUFFER REGISTER
 !MAINTENANCE REGISTER
 !DRIVE TYPE REGISTER
 !SERIAL NUMBER REGISTER
 !ECC REGISTER 1
 !ECC REGISTER 2
 !DATA DIAGNOSTIC REGISTER 1
 !DATA DIAGNOSTIC REGISTER 2
 !ECC ERROR REGISTER
 !ECC ERROR LOCATION REGISTER
 !PROM DATA REGISTER
 !BUS ADDRESS EXTENSION REGISTER
 !CONTROL AND STATUS REGISTER 3
 !SPECIAL CONDITION
 !TRANSFER ERROR
 !MASSBUS CONTROL BUS PARITY ERROR
 !DRIVE AVAILABLE

```

468 :MLX4
469 :
470 :
471 : 1917 (MLCS1)<7,1>X,
472 : M 1918 IE =
473 : 1919 (MLCS1)<6,1>X,
474 : M 1920 FUNC =
475 : 1921 (MLCS1)<0,6>X,
476 : 1922 !
477 : 1923 ! MLCS2 BITS:
478 : 1924 !
479 : M 1925 DLT =
480 : 1926 (MLCS2)<15,1>X,
481 : M 1927 WCE =
482 : 1928 (MLCS2)<14,1>X,
483 : M 1929 PE =
484 : 1930 (MLCS2)<13,1>X,
485 : M 1931 NED =
486 : 1932 (MLCS2)<12,1>X,
487 : M 1933 NEM =
488 : 1934 (MLCS2)<11,1>X,
489 : M 1935 PGE =
490 : 1936 (MLCS2)<10,1>X,
491 : M 1937 MXF =
492 : 1938 (MLCS2)<9,1>X,
493 : M 1939 MDPE =
494 : 1940 (MLCS2)<8,1>X,
495 : M 1941 ORDY =
496 : 1942 (MLCS2)<7,1>X,
497 : M 1943 IRDY =
498 : 1944 (MLCS2)<6,1>X,
499 : M 1945 CLR =
500 : 1946 (MLCS2)<5,1>X,
501 : M 1947 PAT =
502 : 1948 (MLCS2)<4,1>X,
503 : M 1949 BAI =
504 : 1950 (MLCS2)<3,1>X,
505 : M 1951 UNIT =
506 : 1952 (MLCS2)<0,3>X,
507 : 1953 !
508 : 1954 ! MLDS BITS:
509 : 1955 !
510 : M 1956 ATA =
511 : 1957 (MLDS)<15,1>X,
512 : M 1958 ERR =
513 : 1959 (MLDS)<14,1>X,
514 : M 1960 MOL =
515 : 1961 (MLDS)<12,1>X,
516 : M 1962 LBT =
517 : 1963 (MLDS)<10,1>X,
518 : M 1964 DPR =
519 : 1965 (MLDS)<8,1>X,
520 : M 1966 DRY =
521 : 1967 (MLDS)<7,1>X,
522 : M 1968 VV =
    
```

27-Mar-1982 19:24:42 TCPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (2)

```

!READY
!INTERRUPT ENABLE
!FUNCTION (COMMAND) CODE AND GO BIT

!DATA LATE
!WRITE CHECK ERROR
!PARITY ERROR
!NON-EXISTENT DRIVE
!NON-EXISTENT MEMORY
!PROGRAM ERROR
!MISSED TRANSFER
!MASSBUS DATA BUS PARITY ERROR
!OUTPUT READY
!INPUT READY
!CONTROLLER CLEAR
!PARITY TEST
!UNIBUS ADDRESS INCREMENT INHIBIT
!UNIT SELECT

!ATTENTION ACTIVE
!ERROR SUMMARY
!MEDIUM ON LINE
!LAST BLOCK TRANSFERRED
!DRIVE PRESENT
!DRIVE READY
    
```

524 :MLX4
 525 :
 526 :
 527 :
 528 :
 529 :
 530 :
 531 :
 532 :
 533 :
 534 :
 535 :
 536 :
 537 :
 538 :
 539 :
 540 :
 541 :
 542 :
 543 :
 544 :
 545 :
 546 :
 547 :
 548 :
 549 :
 550 :
 551 :
 552 :
 553 :
 554 :
 555 :
 556 :
 557 :
 558 :
 559 :
 560 :
 561 :
 562 :
 563 :
 564 :
 565 :
 566 :
 567 :
 568 :
 569 :
 570 :
 571 :
 572 :
 573 :
 574 :
 575 :
 576 :
 577 :
 578 :

VARIABLES AND CONSTANTS
 !
 ! MLER BITS:
 !
 M 1969 (MLDS)<6,1>%,
 !
 ! DCK =
 M 1973 (MLER)<15,1>%,
 !
 M 1974 UNS =
 M 1975 (MLER)<14,1>%,
 !
 M 1976 OPI =
 M 1977 (MLER)<13,1>%,
 !
 M 1978 IAE =
 M 1979 (MLER)<10,1>%,
 !
 M 1981 AOE =
 M 1982 (MLER)<9,1>%,
 !
 M 1983 ECH =
 M 1984 (MLER)<6,1>%,
 !
 M 1985 DPAR =
 M 1986 (MLER)<5,1>%,
 !
 M 1987 CPAR =
 M 1988 (MLER)<3,1>%,
 !
 M 1989 RMR =
 M 1990 (MLER)<2,1>%,
 !
 M 1991 ILR =
 M 1992 (MLER)<1,1>%,
 !
 M 1993 ILF =
 M 1994 (MLER)<0,1>%,
 !
 ! MLMR BITS:
 !
 M 1998 SZ =
 M 1999 (MLMR)<11,5>%,
 !
 M 2000 ARR TYP =
 M 2001 (MLMR)>10,1>%,
 !
 M 2002 TRT =
 M 2003 (MLMR)<8,2>%,
 !
 M 2004 REF MAR =
 M 2005 (MLMR)>7,1>%,
 !
 M 2006 PROM RW =
 M 2007 (MLMR)<6,1>%,
 !
 M 2008 PROM DIS =
 M 2009 (MLMR)<5,1>%,
 !
 M 2010 DAT CLK =
 M 2011 (MLMR)>4,1>%,
 !
 M 2012 DAT DM =
 M 2013 (MLMR)>3,1>%,
 !
 M 2014 DCK EN =
 M 2015 (MLMR)>2,1>%,
 !
 M 2016 ECC DIS =
 M 2017 (MLMR)>1,1>%,
 !
 M 2018 ECC DM =
 M 2019 (MLMR)>0,1>%,
 !
 2020 !

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (2)

!VOLUME VALID

!DATA CHECK

!DRIVE UNSAFE

!OPERATION INCOMPLETE

!INVALID ADDRESS ERROR

!ADDRESS OVERFLOW ERROR

!ECC HARD ERROR

!DATA PARITY ERROR

!CONTROL PARITY ERROR

!REGISTER MODIFICATION REFUSED

!ILLEGAL REGISTER

!ILLEGAL FUNCTION

!SYSTEM SIZE (# ARRAY CARDS)

!ARRAY TYPE (0=16K;1=64K CHIPS)

!TRANSFER RATE

!REFRESH MARGIN

!PROM READ/WRITE

!PROM DISABLE

!DATA CLOCK

!DATA DIAGNOSTIC MODE

!DATA CHECK ENABLE

!ECC DISABLE

!ECC DIAGNOSTIC MODE

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (2)

580 :MLX4
 581 :
 582 :
 583 :
 584 :
 585 :
 586 :
 587 :
 588 :
 589 :
 590 :
 591 :
 592 :
 593 :
 594 :
 595 :
 596 :
 597 :
 598 :
 599 :
 600 :
 601 :
 602 :
 603 :
 604 :
 605 :
 606 :
 607 :
 608 :
 609 :
 610 :
 611 :
 612 :
 613 :
 614 :
 615 :
 616 :
 617 :
 618 :
 619 :
 620 :
 621 :
 622 :
 623 :
 624 :
 625 :
 626 :
 627 :
 628 :
 629 :
 630 :
 631 :
 632 :
 633 :
 634 :

VARIABLES AND CONSTANTS

```

2021 : MLSN BITS:
2022 :
M 2023 : SN3 =
2024 : (MLSN)<12,4>%,
M 2025 : SN2 =
2026 : (MLSN)<8,4>%,
M 2027 : SN1 =
2028 : (MLSN)<4,4>%,
M 2029 : SNO =
2030 : (MLSN)<0,4>%,
2031 :
2032 : MLEE BITS:
2033 :
M 2034 : UNC =
2035 : (MLEE)<15,1>%,
M 2036 : SGL =
2037 : (MLEE)<14,1>%,
M 2038 : CRC =
2039 : (MLEE)<13,1>%,
M 2040 : CHAN =
2041 : (MLEE)<6,6>%,
M 2042 : EFUN =
2043 : (MLEE)<0,6>%;
```

!HIGH ORDER DECADE
 !THIRD DECADE
 !SECOND DECADE
 !LOW ORDER DECADE

!UNCORRECTABLE ERROR
 !SINGLE ERROR
 !CRC ERROR
 !CHANNEL IN ERROR
 !ERROR FUNCTION

external

!HEADER INFORMATION:

```

2049 : EFNS21,
2050 : L$UNIT,
2051 : L$SLUN,
```

! VER CZMLBB EVENT FLAG TO TURN ON SBE TESTING

!ALL OF THE SOFTWARE P-TABLE LOCATIONS:

```

2055 : LIMIT,
2056 : RANGE,
2057 : LSECT,
2058 : TSECT,
2059 : ONLY,
2060 : DROPNE,
2061 : DROP1,
2062 : DROP2,
2063 : DROP3,
2064 : DROP4,
2065 : DROPS,
2066 : MARPAT,
2067 : REFRESH,
2068 : ECCDIS,
2069 : EOPSUM,
2070 : ERROUT,
```

!RANDOM NUMBER GENERATION VALUES:

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (2)

636 : MLX4
 637 :
 638 :
 639 : 2073
 640 : 2074
 641 : 2075
 642 : 2076
 643 : 2077
 644 : 2078
 645 : 2079
 646 : 2080
 647 : 2081
 648 : 2082
 649 : 2083
 650 : 2084
 651 : 2085
 652 : 2086
 653 : 2087
 654 : 2088
 655 : 2089
 656 : 2090
 657 : 2091
 658 : 2092
 659 : 2093
 660 : 2094
 661 : 2095
 662 : 2096
 663 : 2097
 664 : 2098
 665 : 2099
 666 : 2100
 667 : 2101
 668 : 2102
 669 : 2103
 670 : 2104
 671 : 2105
 672 : 2106
 673 : 2107
 674 : 2108
 675 : 2109
 676 : 2110
 677 : 2111
 678 : 2112
 679 : 2113
 680 : 2114
 681 : 2115
 682 : 2116
 683 : 2117
 684 : 2118
 685 : 2119
 686 : 2120
 687 : 2121
 688 : 2122
 689 : 2123
 690 : 2124

VARIABLES AND CONSTANTS

```

!
SEED1,
SEED2,
SEED3,
RANDOM:
external routine
RN : novalue;
    
```

!FOR 16-BIT RANDOM NUMBER GENERATION

THE PATTERN TABLE:

REGULAR PATTERNS

PATTERN NUMBER	THE TWO ASSOCIATED COUNTS		VALUE OF DATA	VALUE OF COMP
1	0 NIBBLES OF DATA,	1024 NIBBLES OF COMP	0101	1010
2	1 NIBBLE OF DATA,	1 NIBBLE OF COMP	0101	1010
3	4 NIBBLES OF DATA,	4 NIBBLES OF COMP	0101	1010
4	9 NIBBLES OF DATA,	9 NIBBLES OF COMP	0101	1010
5	1024 NIBBLES OF DATA,	1024 NIBBLES OF COMP	0101	1010
6	0 NIBBLES OF DATA,	1024 NIBBLES OF COMP	0000	1111
7	1 NIBBLE OF DATA,	1 NIBBLE OF COMP	0000	1111
8	4 NIBBLES OF DATA,	4 NIBBLES OF COMP	0000	1111
9	9 NIBBLES OF DATA,	9 NIBBLES OF COMP	0000	1111
10	1024 NIBBLES OF DATA,	1024 NIBBLES OF COMP	0000	1111

COMPLEMENT PATTERNS

PATTERN NUMBER	THE TWO ASSOCIATED COUNTS		VALUE OF DATA	VALUE OF COMP
- 1	0 NIBBLES OF DATA,	1024 NIBBLES OF COMP	1010	0101
- 2	1 NIBBLE OF DATA,	1 NIBBLE OF COMP	1010	0101
- 3	4 NIBBLES OF DATA,	4 NIBBLES OF COMP	1010	0101
- 4	9 NIBBLES OF DATA,	9 NIBBLES OF COMP	1010	0101
- 5	1024 NIBBLES OF DATA,	1024 NIBBLES OF COMP	1010	0101
- 6	0 NIBBLES OF DATA,	1024 NIBBLES OF COMP	1111	0000
- 7	1 NIBBLE OF DATA,	1 NIBBLE OF COMP	1111	0000
- 8	4 NIBBLES OF DATA,	4 NIBBLES OF COMP	1111	0000
- 9	9 NIBBLES OF DATA,	9 NIBBLES OF COMP	1111	0000
-10	1024 NIBBLES OF DATA,	1024 NIBBLES OF COMP	1111	0000

global

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (2)

692 :MLX4
693 :
694 :
695 :
696 :
697 :
698 :
699 :
700 :
701 :
702 :
703 :
704 :
705 :
706 :
707 :
708 :
709 :
710 :
711 :
712 :
713 :
714 :
715 :
716 :
717 :
718 :
719 :
720 :

VARIABLES AND CONSTANTS

```

!<BLF/NOFORMAT>
PATTBL: blockvector [NUM_PATS/2,2] field(PATMAP)
  preset (
    [0,COUNT1] = %decimal'0'           !FOR PATTERNS 1, -1, 6, -6
    [0,COUNT2] = %decimal'1024'       !FOR PATTERNS 2, -2, 7, -7
    [1,COUNT1] = %decimal'1'         !FOR PATTERNS 3, -3, 8, -8
    [1,COUNT2] = %decimal'1'         !FOR PATTERNS 4, -4, 9, -9
    [2,COUNT1] = %decimal'4'         !FOR PATTERNS 5, -5, 10, -10
    [2,COUNT2] = %decimal'4'
    [3,COUNT1] = %decimal'9'
    [3,COUNT2] = %decimal'9'
    [4,COUNT1] = %decimal'1024'
    [4,COUNT2] = %decimal'1024'
  );

```

!<BLF/FORMAT>

bind

DEFINITIONS OF LOCATIONS WITHIN THE WRITE AND READ BUFFERS:

```

WDBUFF = WBUFF,           !256-WORD WRITE DATA BUFFER
WCBUFF = WBUFF + 512,    !256-WORD WRITE COMP BUFFER
RDBUFF = RBUFF,          !256-WORD READ DATA BUFFER
RCBUFF = RBUFF + 512,   !256-WORD READ COMP BUFFER
END_WBUFF = (WBUFF + BUFSIZ*2), !JUST BEYOND END OF FULL WRITE BUFFER
END_RBUFF = (RBUFF + BUFSIZ*2), !JUST BEYOND END OF FULL READ BUFFER

```

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (3)

722 :MLX4
723 :
724 :
725 :
726 :
727 :
728 :
729 :
730 :
731 :
732 :
733 :
734 :
735 :
736 :
737 :
738 :
739 :
740 :
741 :
742 :
743 :
744 :
745 :
746 :
747 :
748 :
749 :
750 :
751 :
752 :
753 :
754 :
755 :
756 :
757 :
758 :
759 :
760 :
761 :
762 :
763 :
764 :
765 :
766 :
767 :
768 :
769 :
770 :
771 :
772 :
773 :
774 :
775 :
776 :

2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200
2201
2202

MESSAGES AND PRINT FORMATS

%sbttl 'MESSAGES AND PRINT FORMATS'

SINGLE BIT ERROR LOGGING TABLE MESSAGE STRINGS

PHR21 = uplit (%asciz' SINGLE BIT ERROR LOG SUMMARY REPORT'),
FMT16 = uplit (%asciz'%N%D1%A(D) %D2%A(D) %D1%A(D) %D2%A(D) %D6%A(D)'),
SBESHEADER = uplit (%asciz'UNIT #: ARRAY #: BANK #: BIT #: COUNT #:'),

SPECIAL PURPOSE FORMATS (WITH SAMPLE PRINTOUTS):

FMT1A = uplit (%asciz'%N%T%S2%D2'),
!'PATTERN NUMBER XX'
FMT1B = uplit (%asciz'%S7%T%S%A-%D2'),
!'PATTERN NUMBER -XX'
FMT2 = uplit (%asciz'%S2%T'),
!'(NOT POWERED UP)'
!'(NOT AN ML11 UNIT)'
!'(OPERATOR SELECTED TEST LIMITS INCORRECTLY)'
!'(ALL RETRIES FAILED FOR A NON-FATAL ERROR)'
!'(CONTROLLER FATAL ERROR)'
!'(DRIVE FATAL ERROR)'
!'(ECC HARD ERROR)'
!'UP'
!'DOWN'
!--> RUN ML11 PROM MAINTENANCE PROGRAM'
FMT3 = uplit (%asciz'%N%A**%S%T%S%T%D3%S%A**'),
!'** END PASS X **'
FMT4A = uplit (%asciz'%N2%T%A:%S%D1%S4%T%A:%S%D1'),
!'LOGICAL UNIT: X DRIVE: Y'
FMT4B = uplit (%asciz'%S4%T%A:%S%O6'),
!'SERIAL #: ZZZZZZ'
!'CSR ADDRESS: XXXXXX'
FMT4C = uplit (%asciz'%S4%T%A:%S%D1%D1%D1%D1'),
!'SERIAL #: DDDD'
FMT5 = uplit (%asciz'%N%T%S3%A%SECTORS UNDER TEST:%S%O6%S%ATO%S%O6'),
!'ML11-X SECTORS UNDER TEST: XXXXXX TO YYYYYY'
FMT6 = uplit (%asciz'%N%ABEGAN %D4%A WORD%S%T%A AT%S%T%S%O6'),
!'BEGAN YYY WORD WRITE AT SECTOR ZZZZZZ'
!'BEGAN YYY WORD READ AT SECTOR ZZZZZZ'
!'BEGAN YYY WORD WRITE CHECK AT SECTOR ZZZZZZ'
FMT7 = uplit (%asciz'%N%S2%T%A:%S%D5'),
!'SOFT ERROR COUNT: DDDDD'
!'HARD ERROR COUNT: DDDDD'
!'TRANSFER RETRIES: DDDDD'
FMT8 = uplit (%asciz'%N%AT%TRANSFER RATE: %T%A MBYTES/SECOND'),
!'TRANSFER RATE: X MBYTES/SECOND'
FMT9 = uplit (%asciz'%N%S4%A%ARRAY%D3%A:%S%D5'),
!'ARRAY XX: YYYYY'
FMT10A = uplit (%asciz'%N%T%A:%S2%T%S%O6%S2%A%BOARD%D3%S2%A%BANK%D2'),
!'FAILED: SECTOR XXXXXX BOARD YY BANK Z'
FMT10B = uplit (%asciz'%S2%A%BIT%D3'),
!'BIT QQ'

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (3)

778 :MLX4
779 :
780 :
781 :
782 :
783 :
784 :
785 :
786 :
787 :
788 :
789 :
790 :
791 :
792 :
793 :
794 :
795 :
796 :
797 :
798 :
799 :
800 :
801 :
802 :
803 :
804 :
805 :
806 :
807 :
808 :
809 :
810 :
811 :
812 :
813 :
814 :
815 :
816 :
817 :
818 :
819 :
820 :
821 :
822 :
823 :
824 :
825 :
826 :
827 :
828 :
829 :
830 :
831 :
832 :

MESSAGES AND PRINT FORMATS

FMT11 = uplit (%asciz'XNXTXSX06XA EXCEEDS XTXSX06'),
!'TOP SECTOR OF XXXXXX EXCEEDS SYSTEM LIMIT OF YYYYYY'
!'LOW SECTOR OF XXXXXX EXCEEDS TOP SECTOR OF YYYYYY'
FMT12A = uplit (%asciz'XNZAGOOD DATA: X06XA AT LOCATION X06'),
!'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
FMT12B = uplit (%asciz'XNZABAD DATA: X06XA AT LOCATION X06'),
!'BAD DATA: XXXXXX AT LOCATION YYYYYY'
FMT13 = uplit (%asciz'XNZARRAYXD3XS2XT'),
!'ARRAY XX --> RUN ML11 PROM MAINTENANCE PROGRAM'
FMT14 = uplit (%asciz'XNXD5XSXT'),
!'XXXXX MBYTES WRITTEN'
!'XXXXX MBYTES READ'
!'XXXXX MBYTES WRITE CHECKED'
FMT15 = uplit (%asciz'XS2XT'),
!' ECH'
!' NED'
!(ANY OF THE ERROR BITS)
CRLF = uplit (%asciz'XN'),

MESSAGE MAPS:

SAY1 = uplit (%asciz'XNXT')
SAY2 = uplit (%asciz'XNXTXSXT')
SAY3 = uplit (%asciz'XNXTXSXTXSXT')
SAY4 = uplit (%asciz'XNXTXSXTXSXTXSXT')
SAY5 = uplit (%asciz'XNXTXSXTXSXTXSXTXSXT'),

WORDS:

WRD2 = uplit (%asciz'BEGIN'),
WRD3 = uplit (%asciz'END'),
WRD4 = uplit (%asciz'PASS'),
WRD6 = uplit (%asciz'ML11-A'),
WRD7 = uplit (%asciz'ML11-B'),
WRD11 = uplit (%asciz'DRIVE'),
WRD15 = uplit (%asciz'SECTOR'),
WRD16 = uplit (%asciz'WRITE'),
WRD17 = uplit (%asciz'READ'),
WRD18 = uplit (%asciz'RETRY'),
WRD19 = uplit (%asciz'SUCCEEDED'),
WRD20 = uplit (%asciz'FAILED'),
WRD21 = uplit (%asciz'DROPPED'),
WRD24 = uplit (%asciz'UP'),
WRD25 = uplit (%asciz'DOWN'),
WRD34 = uplit (%asciz'RUNNING'),
WRD35 = uplit (%asciz'MARCHING: '),
WRD36 = uplit (%asciz'ENABLED'),
WRD37 = uplit (%asciz'DISABLED'),
WRD38 = uplit (%asciz'ECC'),
WRD40 = uplit (%asciz'WITH'),
WRD41 = uplit (%asciz'AND'),
!

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (3)

834 :MLX4
835 :
836 :
837 :
838 :
839 :
840 :
841 :
842 :
843 :
844 :
845 :
846 :
847 :
848 :
849 :
850 :
851 :
852 :
853 :
854 :
855 :
856 :
857 :
858 :
859 :
860 :
861 :
862 :
863 :
864 :
865 :
866 :
867 :
868 :
869 :
870 :
871 :
872 :
873 :
874 :
875 :
876 :
877 :
878 :
879 :
880 :
881 :
882 :
883 :
884 :
885 :
886 :
887 :
888 :

MESSAGES AND PRINT FORMATS

2255 : ML-11 BITS:
2256 :
2257 : MLB2 = uplit (%asciz'NED'),
2258 : MLB3 = uplit (%asciz'NEM'),
2259 : MLB4 = uplit (%asciz'PGE'),
2260 : MLB5 = uplit (%asciz'DLT'),
2261 : MLB6 = uplit (%asciz'WCE'),
2262 : MLB7 = uplit (%asciz'PE'),
2263 : MLB8 = uplit (%asciz'MXF'),
2264 : MLB9 = uplit (%asciz'MDPE'),
2265 : MLB10 = uplit (%asciz'MCPE'),
2266 : MLB11 = uplit (%asciz'UNS'),
2267 : MLB12 = uplit (%asciz'IAE'),
2268 : MLB13 = uplit (%asciz'AOE'),
2269 : MLB14 = uplit (%asciz'RMR'),
2270 : MLB15 = uplit (%asciz'ILR'),
2271 : MLB16 = uplit (%asciz'ILF'),
2272 : MLB17 = uplit (%asciz'OPI'),
2273 : MLB18 = uplit (%asciz'DPAR'),
2274 : MLB19 = uplit (%asciz'CPAR'),
2275 : MLB20 = uplit (%asciz'DCK'),
2276 : MLB21 = uplit (%asciz'ECH'),
2277 : MLB22 = uplit (%asciz'CRC'),
2278 : MLB23 = uplit (%asciz'SGL'),
2279 : MLB24 = uplit (%asciz'UNC').

ROUTINE NAMES:

2280 :
2281 :
2282 :
2283 : RTN0 = uplit (%asciz'COMMAND INTEGRITY ROUTINE'),
2284 : RTN1 = uplit (%asciz'OPT1'),
2285 : RTN2 = uplit (%asciz'OPT2'),
2286 : RTN3 = uplit (%asciz'OPT3'),
2287 : RTN4 = uplit (%asciz'OPT4'),
2288 : RTN5 = uplit (%asciz'OPT5'),
2289 : RTN5A = uplit (%asciz'RAND1'),
2290 : RTN5B = uplit (%asciz'RAND2'),
2291 : RTN5C = uplit (%asciz'RAND3'),
2292 : RTN5D = uplit (%asciz'RAND4').

!RANDOM DATA
!DATA & WORD COUNTS
!DATA, WORD COUNTS & SECTORS
!DATA, WORD COUNTS, SECTORS & UNITS

PHRASES:

2293 :
2294 :
2295 :
2296 : PHR1 = uplit (%asciz'WRITE CHECK'),
2297 : PHR2 = uplit (%asciz'QUICK VERIFY'),
2298 : PHR3 = uplit (%asciz'REFRESH MARGINING'),
2299 : PHR4 = uplit (%asciz'CSR ADDRESS'),
2300 : PHR5 = uplit (%asciz'SOFT ERROR COUNT'),
2301 : PHR6 = uplit (%asciz'TRANSFER RETRIES'),
2302 : PHR7 = uplit (%asciz'LOGICAL UNIT'),
2303 : PHR8 = uplit (%asciz'SERIAL #'),
2304 : PHR9 = uplit (%asciz'PATTERN NUMBER'),
2305 : PHR10 = uplit (%asciz'ERROR BITS SET:'),
2306 : PHR11 = uplit (%asciz'SC SET BUT NO SYSTEM ERRORS FOUND').

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (3)

890 :MLX4
891 :
892 :
893 :
894 :
895 :
896 :
897 :
898 :
899 :
900 :
901 :
902 :
903 :
904 :
905 :
906 :
907 :
908 :
909 :
910 :
911 :
912 :
913 :
914 :
915 :
916 :
917 :
918 :
919 :
920 :
921 :
922 :
923 :
924 :
925 :
926 :
927 :
928 :
929 :

MESSAGES AND PRINT FORMATS

2307 PHR12 = uplit (%asciz'NUMBER OF MBYTES TRANSFERED:'),
2308 PHR13 = uplit (%asciz'MBYTES WRITE CHECKED'),
2309 PHR14 = uplit (%asciz'TOP SECTOR OF'),
2310 PHR15 = uplit (%asciz'LOW SECTOR OF'),
2311 PHR16 = uplit (%asciz'SYSTEM LIMIT OF'),
2312 PHR17 = uplit (%asciz'PERFORMANCE SUMMARY'),
2313 PHR18 = uplit (%asciz'HARD ERROR COUNT'),
2314 PHR19 = uplit (%asciz'MBYTES WRITTEN'),
2315 PHR20 = uplit (%asciz'MBYTES READ'),
2316 :
2317 : TRANSFER RATES:
2318 :
2319 TRT00 = uplit (%asciz'2'),
2320 TRT01 = uplit (%asciz'1'),
2321 TRT10 = uplit (%asciz'.5'),
2322 TRT11 = uplit (%asciz'.25'),
2323 :
2324 : DROP MESSAGES:
2325 :
2326 CAUSE1 = uplit (%asciz'(NOT POWERED UP)'),
2327 CAUSE2 = uplit (%asciz'(NOT AN ML11 UNIT)'),
2328 CAUSE3 = uplit (%asciz'(OPERATOR SELECTED TEST LIMITS INCORRECTLY)'),
2329 CAUSE4 = uplit (%asciz'(ALL RETRIES FAILED FOR A NON-FATAL ERROR)'),
2330 CAUSE5 = uplit (%asciz'(CONTROLLER FATAL ERROR)'),
2331 CAUSE6 = uplit (%asciz'(DPIVE FATAL ERROR)'),
2332 CAUSE7 = uplit (%asciz'(ECC HARD ERROR)'),
2333 CAUSE8 = uplit (%asciz'(ECC LOGIC FAILURE)'),
2334 :
2335 : DIAGNOSES:
2336 :
2337 MSG0 = uplit (%asciz'INTERRUPT DID NOT OCCUR, BUT THE TRANSFER IS COMPLETE'),
2338 MSG1 = uplit (%asciz'--> RUN ML11 LOGIC TEST'),
2339 MSG2 = uplit (%asciz'--> RUN ML11 PROM MAINTENANCE PROGRAM'),
2340 MSG3 = uplit (%asciz'SOFT ERROR'),
2341 MSG4 = uplit (%asciz'HARD ERROR'),
2342 MSG5 = uplit (%asciz'ECC LOGIC FAILED TO DETECT DATA ERROR');
2343 :

LSAU ADD UNIT SECTION

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (4)

```

931 :MLX4
932 :
933 :
934 : 2344 %sbttl 'ML11 INTERRUPT SERVICE ROUTINE'
935 : 275 BGNSRV (SERVICE);
936 : 236 I AM DONE = ACTIVE;
937 : 247 *RDSRV;
941
942
943
944 005662 040 040 040 P.AAA: .ASCII / /
945 005665 040 040 011 .ASCII / /<11>
946 005670 011 123 111 .ASCII <11>/SI/
947 005673 116 107 114 .ASCII /NGL/
948 005676 105 040 102 .ASCII /E B/
949 005701 111 124 040 .ASCII /IT /
950 005704 105 122 122 .ASCII /ERR/
951 005707 117 122 040 .ASCII /OR /
952 005712 114 117 107 .ASCII /LOG/
953 005715 040 123 125 .ASCII / SU/
954 005720 115 115 101 .ASCII /MMA/
955 005723 122 131 040 .ASCII /RY /
956 005726 122 105 120 .ASCII /REP/
957 005731 117 122 124 .ASCII /ORT/
958 005734 000 000 .ASCII <00><00>
959 005736 045 116 045 P.AAB: .ASCII /XN%/
960 005741 104 061 045 .ASCII /D1%/
961 005744 101 050 104 .ASCII /A(D/
962 005747 051 040 040 .ASCII /) /
963 005752 040 040 040 .ASCII / /
964 005755 040 045 104 .ASCII / X/
965 005760 062 045 101 .ASCII /2XA/
966 005763 050 104 051 .ASCII /(D)/
967 005766 040 040 040 .ASCII / /
968 005771 040 040 040 .ASCII / /
969 005774 045 104 061 .ASCII /XD1/
970 005777 045 101 050 .ASCII /XA(/
971 006002 104 051 040 .ASCII /D) /
972 006005 040 040 040 .ASCII / /
973 006010 040 040 045 .ASCII / X/
974 006013 104 062 045 .ASCII /D2%/
975 006016 101 050 104 .ASCII /A(D/
976 006021 051 040 040 .ASCII /) /
977 006024 040 040 040 .ASCII / /
978 006027 040 040 045 .ASCII / X/
979 006032 104 066 045 .ASCII /D6%/
980 006035 101 050 104 .ASCII /A(D/
981 006040 051 000 .ASCII /)/<00>
982 006042 125 116 111 P.AAC: .ASCII /UNI/
983 006045 124 040 043 .ASCII /T #/
984
985 :MLX4
986 : ML11 INTERRUPT SERVICE ROUTINE
987 006050 072 040 040 .ASCII /: /
988 006053 040 101 122 .ASCII / AR/
989 006056 122 101 131 .ASCII /RAY/
990 006061 040 043 072 .ASCII / #:/

```

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44
TOPS
PA:<

991	006064	040	040	040		.ASCII	/ /
992	006067	102	101	116		.ASCII	/BAN/
993	006072	113	040	043		.ASCII	/K #/
994	006075	072	040	040		.ASCII	/: /
995	006100	040	102	111		.ASCII	/ BI/
996	006103	124	040	043		.ASCII	/T #/
997	006106	072	040	040		.ASCII	/: /
998	006111	040	040	040		.ASCII	/ /
999	006114	040	103	117		.ASCII	/ CO/
1000	006117	125	116	124		.ASCII	/UNT/
1001	006122	040	043	072		.ASCII	/ #: /
1002	006125	000				.ASCII	<00>
1003	006126	045	116	045	P.AAD:	.ASCII	/XN%/
1004	006131	124	045	123		.ASCII	/TXS/
1005	006134	062	045	104		.ASCII	/2%D/
1006	006137	062	000	000		.ASCII	/2/<00><00>
1007	006142	045	123	067	P.AAE:	.ASCII	/XS7/
1008	006145	045	124	045		.ASCII	/XT%/
1009	006150	123	045	101		.ASCII	/SXA/
1010	006153	055	045	104		.ASCII	/-XD/
1011	006156	062	000			.ASCII	/2/<00>
1012	006160	045	123	062	P.AAF:	.ASCII	/XS2/
1013	006163	045	124	000		.ASCII	/XT/<00>
1014	006166	045	116	045	P.AAG:	.ASCII	/XN%/
1015	006171	101	052	052		.ASCII	/A**/
1016	006174	045	123	045		.ASCII	/XS%/
1017	006177	124	045	123		.ASCII	/TXS/
1018	006202	045	124	045		.ASCII	/XT%/
1019	006205	104	063	045		.ASCII	/D3%/
1020	006210	123	045	101		.ASCII	/SXA/
1021	006213	052	052	000		.ASCII	/**/<00>
1022	006216	045	116	062	P.AAH:	.ASCII	/XN2/
1023	006221	045	124	045		.ASCII	/XT%/
1024	006224	101	072	045		.ASCII	/A:%/
1025	006227	123	045	104		.ASCII	/SXD/
1026	006232	061	045	123		.ASCII	/1XS/
1027	006235	064	045	124		.ASCII	/4XT/
1028	006240	045	101	072		.ASCII	/XA:/
1029	006243	045	123	045		.ASCII	/XS%/
1030	006246	104	061	000		.ASCII	/D1/<00>
1031	006251	000				.ASCII	<00>
1032	006252	045	123	064	P.AAI:	.ASCII	/XS4/
1033	006255	045	124	045		.ASCII	/XT%/
1034	006260	101	072	045		.ASCII	/A:%/
1035	006263	123	045	117		.ASCII	/SX0/
1036	006266	066	000			.ASCII	/6/<00>
1037	006270	045	123	064	P.AAJ:	.ASCII	/XS4/
1038	006273	045	124	045		.ASCII	/XT%/

27-Mar-1982 19:24:42 TUPS
 27-Mar-1982 19:23:44 PA:<

Address	OpCode	OpCode	OpCode	OpCode	Comment
1040					:MLX4
1041					:
1042					ML11 INTERRUPT SERVICE ROUTINE
1043	006276	101	072	045	.ASCII /A:Z/
1044	006301	123	045	104	.ASCII /S%D/
1045	006304	061	045	104	.ASCII /1%D/
1046	006307	061	045	104	.ASCII /1%D/
1047	006312	061	045	104	.ASCII /1%D/
1048	006315	061	000	000	.ASCII /1/<00><00>
1049	006320	045	116	045	P.AAK: .ASCII /XNZ/
1050	006323	124	045	123	.ASCII /T%S/
1051	006326	063	045	101	.ASCII /3%A/
1052	006331	123	105	103	.ASCII /SEC/
1053	006334	124	117	122	.ASCII /TOR/
1054	006337	123	040	125	.ASCII /S U/
1055	006342	116	104	105	.ASCII /NDE/
1056	006345	122	040	124	.ASCII /R T/
1057	006350	105	123	124	.ASCII /EST/
1058	006353	072	045	123	.ASCII /:XS/
1059	006356	045	117	066	.ASCII /%06/
1060	006361	045	123	045	.ASCII /XSZ/
1061	006364	101	124	117	.ASCII /ATO/
1062	006367	045	123	045	.ASCII /XSZ/
1063	006372	117	066	000	.ASCII /06/<00>
1064	006375	000			.ASCII <00>
1065	006376	045	116	045	P.AAL: .ASCII /XNZ/
1066	006401	101	102	105	.ASCII /ABE/
1067	006404	107	101	116	.ASCII /GAN/
1068	006407	040	045	104	.ASCII / %D/
1069	006412	064	045	101	.ASCII /4ZA/
1070	006415	040	127	117	.ASCII / WO/
1071	006420	122	104	045	.ASCII /RDZ/
1072	006423	123	045	124	.ASCII /SXT/
1073	006426	045	101	040	.ASCII /%A /
1074	006431	101	124	045	.ASCII /ATZ/
1075	006434	123	045	124	.ASCII /SXT/
1076	006437	045	123	045	.ASCII /XSZ/
1077	006442	117	066	000	.ASCII /06/<00>
1078	006445	000			.ASCII <00>
1079	006446	045	116	045	P.AAM: .ASCII /XNZ/
1080	006451	123	062	045	.ASCII /S2Z/
1081	006454	124	045	101	.ASCII /TZA/
1082	006457	072	045	123	.ASCII /:XS/
1083	006462	045	104	065	.ASCII /%D5/
1084	006465	000			.ASCII <00>
1085	006466	045	116	045	P.AAN: .ASCII /XNZ/
1086	006471	101	124	122	.ASCII /ATR/
1087	006474	101	116	123	.ASCII /ANS/
1088	006477	106	105	122	.ASCII /FER/
1089	006502	040	122	101	.ASCII / RA/
1090	006505	124	105	072	.ASCII /TE:/
1091	006510	040	045	124	.ASCII / %T/
1092	006513	045	101	040	.ASCII /%A /
1093	006516	115	102	131	.ASCII /MBY/
1094	006521	124	105	123	.ASCII /TES/

```
1096      ;MLX4
1097      :
1098      :
1099 006524 057 123 105      .ASCII <57>/SE/
1100 006527 103 117 116      .ASCII /CON/
1101 006532 104 000          .ASCII /D/<00>
1102 006534 045 116 045 P.AAO: .ASCII /XNZ/
1103 006537 123 064 045      .ASCII /S4%/
1104 006542 101 101 122      .ASCII /AAR/
1105 006545 122 101 131      .ASCII /RAY/
1106 006550 045 104 063      .ASCII /XD3/
1107 006553 045 101 072      .ASCII /XA:/
1108 006556 045 123 045      .ASCII /XS%/
1109 006561 104 065 000      .ASCII /D5/<00>
1110 006564 045 116 045 P.AAP: .ASCII /XNZ/
1111 006567 124 045 101      .ASCII /TZA/
1112 006572 072 045 123      .ASCII /:XS/
1113 006575 062 045 124      .ASCII /2XT/
1114 006600 045 123 045      .ASCII /XS%/
1115 006603 117 066 045      .ASCII /O6%/
1116 006606 123 062 045      .ASCII /S2%/
1117 006611 101 102 117      .ASCII /ABO/
1118 006614 101 122 104      .ASCII /ARD/
1119 006617 045 104 063      .ASCII /XD3/
1120 006622 045 123 062      .ASCII /XS2/
1121 006625 045 101 102      .ASCII /ZAB/
1122 006630 101 116 113      .ASCII /ANK/
1123 006633 045 104 062      .ASCII /XD2/
1124 006636 000 000          .ASCII <00><00>
1125 006640 045 123 062 P.AAQ: .ASCII /XS2/
1126 006643 045 101 102      .ASCII /ZAB/
1127 006646 111 124 045      .ASCII /IT%/
1128 006651 104 063 000      .ASCII /D3/<00>
1129 006654 045 116 045 P.AAR: .ASCII /XNZ/
1130 006657 124 045 123      .ASCII /TXS/
1131 006662 045 117 066      .ASCII /XO6/
1132 006665 045 101 040      .ASCII /XA /
1133 006670 105 130 103      .ASCII /EXC/
1134 006673 105 105 104      .ASCII /EED/
1135 006676 123 040 045      .ASCII /S %/
1136 006701 124 045 123      .ASCII /TXS/
1137 006704 045 117 066      .ASCII /XO6/
1138 006707 000          .ASCII <00>
1139 006710 045 116 045 P.AAS: .ASCII /XNZ/
1140 006713 101 107 117      .ASCII /AGO/
1141 006716 117 104 040      .ASCII /OD /
1142 006721 104 101 124      .ASCII /DAT/
1143 006724 101 072 040      .ASCII /A: /
1144 006727 045 117 066      .ASCII /XO6/
1145 006732 045 101 040      .ASCII /XA /
1146 006735 101 124 040      .ASCII /AT /
1147 006740 114 117 103      .ASCII /LOC/
1148 006743 101 124 111      .ASCII /ATI/
1149 006746 117 116 040      .ASCII /ON /
1150 006751 045 117 066      .ASCII /XO6/
```

```

1152      :MLX4
1153      :
1154      :
1155 006754      000      000
1156 006756      045      116      045 P.AAT: .ASCII <00><00>
1157 006761      101      102      101      .ASCII /XN%/
1158 006764      104      040      104      .ASCII /ABA/
1159 006767      101      124      101      .ASCII /D D/
1160 006772      072      040      040      .ASCII /ATA/
1161 006775      045      117      066      .ASCII /:/
1162 007000      045      101      040      .ASCII /%06/
1163 007003      101      124      040      .ASCII /%A /
1164 007006      114      117      103      .ASCII /AT /
1165 007011      101      124      111      .ASCII /LOC/
1166 007014      117      116      040      .ASCII /ATI/
1167 007017      045      117      066      .ASCII /ON /
1168 007022      000      000
1169 007024      045      116      045 P.AAU: .ASCII <00><00>
1170 007027      101      101      122      .ASCII /XN%/
1171 007032      122      101      131      .ASCII /AAR/
1172 007035      045      104      063      .ASCII /RAY/
1173 007040      045      123      062      .ASCII /%D3/
1174 007043      045      124      000      .ASCII /%S2/
1175 007046      045      116      045 P.AAV: .ASCII /%T/<00>
1176 007051      104      065      045      .ASCII /XN%/
1177 007054      123      045      124      .ASCII /D5%/
1178 007057      000
1179 007060      045      123      062 P.AAW: .ASCII <00>
1180 007063      045      124      000      .ASCII /%S2/
1181 007066      045      116      000 P.AAX: .ASCII /%T/<00>
1182 007071      000
1183 007072      045      116      045 P.AAY: .ASCII /%N/<00>
1184 007075      124      000      000      .ASCII <00>
1185 007100      045      116      045 P.AAZ: .ASCII /T/<00><00>
1186 007103      124      045      123      .ASCII /XN%/
1187 007106      045      124      000      .ASCII /T%S/
1188 007111      000
1189 007112      045      116      045 P.ABA: .ASCII <00>
1190 007115      124      045      123      .ASCII /XN%/
1191 007120      045      124      045      .ASCII /T%S/
1192 007123      123      045      124      .ASCII /%T%T/
1193 007126      000      000
1194 007130      045      116      045 P.ABB: .ASCII <00><00>
1195 007133      124      045      123      .ASCII /XN%/
1196 007136      045      124      045      .ASCII /T%S/
1197 007141      123      045      124      .ASCII /%T%T/
1198 007144      045      123      045      .ASCII /S%T/
1199 007147      124      000      000      .ASCII /%S%T/
1200 007152      045      116      045 P.ABC: .ASCII /T/<00><00>
1201 007155      124      045      123      .ASCII /XN%/
1202 007160      045      124      045      .ASCII /T%S/
1203 007163      123      045      124      .ASCII /%T%T/
1204 007166      045      123      045      .ASCII /S%T/
1205 007171      124      045      123      .ASCII /%S%T/
1206 007174      045      124      000      .ASCII /T%S/

```



```

1264      ;MLX4
1265      ;
1266      ;
1267 007412    105    103    103 P.ABW: .ASCII /ECC/
1268 007415    000                .ASCII <00>
1269 007416    127    111    124 P.ABX: .ASCII /WIT/
1270 007421    110    000    000 .ASCII /H/<00><00>
1271 007424    101    116    104 P.ABY: .ASCII /AND/
1272 007427    000                .ASCII <00>
1273 007430    116    105    104 P.ABZ: .ASCII /NED/
1274 007433    000                .ASCII <00>
1275 007434    116    105    115 P.ACA: .ASCII /NEM/
1276 007437    000                .ASCII <00>
1277 007440    120    107    105 P.ACB: .ASCII /PGE/
1278 007443    000                .ASCII <00>
1279 007444    104    114    124 P.ACC: .ASCII /DLT/
1280 007447    000                .ASCII <00>
1281 007450    127    103    105 P.ACD: .ASCII /WCE/
1282 007453    000                .ASCII <00>
1283 007454    120    105    000 P.ACE: .ASCII /PE/<00>
1284 007457    000                .ASCII <00>
1285 007460    115    130    106 P.ACF: .ASCII /MXF/
1286 007463    000                .ASCII <00>
1287 007464    115    104    120 P.ACG: .ASCII /MDP/
1288 007467    105    000    000 .ASCII /E/<00><00>
1289 007472    115    103    120 P.ACH: .ASCII /MCP/
1290 007475    105    000    000 .ASCII /E/<00><00>
1291 007500    125    116    123 P.ACI: .ASCII /UNS/
1292 007503    000                .ASCII <00>
1293 007504    111    101    105 P.ACJ: .ASCII /IAE/
1294 007507    000                .ASCII <00>
1295 007510    101    117    105 P.ACK: .ASCII /AOE/
1296 007513    000                .ASCII <00>
1297 007514    122    115    122 P.ACL: .ASCII /RMR/
1298 007517    000                .ASCII <00>
1299 007520    111    114    122 P.ACM: .ASCII /ILR/
1300 007523    000                .ASCII <00>
1301 007524    111    114    106 P.ACN: .ASCII /ILF/
1302 007527    000                .ASCII <00>
1303 007530    117    120    111 P.ACO: .ASCII /OPI/
1304 007533    000                .ASCII <00>
1305 007534    104    120    101 P.ACP: .ASCII /DPA/
1306 007537    122    000    000 .ASCII /R/<00><00>
1307 007542    103    120    101 P.ACQ: .ASCII /CPA/
1308 007545    122    000    000 .ASCII /R/<00><00>
1309 007550    104    103    113 P.ACR: .ASCII /DCK/
1310 007553    000                .ASCII <00>
1311 007554    105    103    110 P.ACS: .ASCII /ECH/
1312 007557    000                .ASCII <00>
1313 007560    103    122    103 P.ACT: .ASCII /CRC/
1314 007563    000                .ASCII <00>
1315 007564    123    107    114 P.ACU: .ASCII /SGL/
1316 007567    000                .ASCII <00>
1317 007570    125    116    103 P.ACV: .ASCII /UNC/
1318 007573    000                .ASCII <00>

```

```

1320      :MLX4
1321      :
1322      :
1323 007574 103 117 115 P.ACW: .ASCII /COM/
1324 007577 115 101 116      .ASCII /MAN/
1325 007602 104 040 111      .ASCII /D I/
1326 007605 116 124 105      .ASCII /NTE/
1327 007610 107 122 111      .ASCII /GRI/
1328 007613 124 131 040      .ASCII /TY /
1329 007616 122 117 125      .ASCII /ROU/
1330 007621 124 111 116      .ASCII /TIN/
1331 007624 105 000      .ASCII /E/<00>
1332 007626 117 120 124 P.ACX: .ASCII /OPT/
1333 007631 061 000 000      .ASCII /1/<00><00>
1334 007634 117 120 124 P.ACY: .ASCII /OPT/
1335 007637 062 000 000      .ASCII /2/<00><00>
1336 007642 117 120 124 P.ACZ: .ASCII /OPT/
1337 007645 063 000 000      .ASCII /3/<00><00>
1338 007650 117 120 124 P.ADA: .ASCII /OPT/
1339 007653 064 000 000      .ASCII /4/<00><00>
1340 007656 117 120 124 P.ADB: .ASCII /OPT/
1341 007661 065 000 000      .ASCII /5/<00><00>
1342 007664 122 101 116 P.ADC: .ASCII /RAN/
1343 007667 104 061 000      .ASCII /D1/<00>
1344 007672 122 101 116 P.ADD: .ASCII /RAN/
1345 007675 104 062 000      .ASCII /D2/<00>
1346 007700 122 101 116 P.ADE: .ASCII /RAN/
1347 007703 104 063 000      .ASCII /D3/<00>
1348 007706 122 101 116 P.ADF: .ASCII /RAN/
1349 007711 104 064 000      .ASCII /D4/<00>
1350 007714 127 122 111 P.ADG: .ASCII /WRI/
1351 007717 124 105 040      .ASCII /TE /
1352 007722 103 110 105      .ASCII /CHE/
1353 007725 103 113 000      .ASCII /CK/<00>
1354 007730 121 125 111 P.ADH: .ASCII /QUI/
1355 007733 103 113 040      .ASCII /CK /
1356 007736 126 105 122      .ASCII /VER/
1357 007741 111 106 131      .ASCII /IFY/
1358 007744 000 000      .ASCII <00><00>
1359 007746 122 105 106 P.ADI: .ASCII /REF/
1360 007751 122 105 123      .ASCII /RES/
1361 007754 110 040 115      .ASCII /H M/
1362 007757 101 122 107      .ASCII /ARG/
1363 007762 111 116 111      .ASCII /INI/
1364 007765 116 107 000      .ASCII /NG/<00>
1365 007770 103 123 122 P.ADJ: .ASCII /CSR/
1366 007773 040 101 104      .ASCII / AD/
1367 007776 104 122 105      .ASCII /DRE/
1368 010001 123 123 000      .ASCII /SS/<00>
1369 010004 123 117 106 P.ADK: .ASCII /SOF/
1370 010007 124 040 105      .ASCII /T E/
1371 010012 122 122 117      .ASCII /RRO/
1372 010015 122 040 103      .ASCII /R C/
1373 010020 117 125 116      .ASCII /OUN/
1374 010023 124 000 000      .ASCII /T/<00><00>
  
```

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

Line No.	Address	Hex 1	Hex 2	Hex 3	Label	Comment
1376					:MLX4	
1377					:	
1378						ML11 INTERRUPT SERVICE ROUTINE
1379	010026	124	122	101	P.ADL:	.ASCII /TRA/
1380	010031	116	123	106		.ASCII /NSF/
1381	010034	105	122	040		.ASCII /ER /
1382	010037	122	105	124		.ASCII /RET/
1383	010042	122	111	105		.ASCII /RIE/
1384	010045	123	000	000		.ASCII /S/<00><00>
1385	010050	114	117	107	P.ADM:	.ASCII /LOG/
1386	010053	111	103	101		.ASCII /ICA/
1387	010056	114	040	125		.ASCII /L U/
1388	010061	116	111	124		.ASCII /NIT/
1389	010064	000	000			.ASCII <00><00>
1390	010066	123	105	122	P.ADN:	.ASCII /SER/
1391	010071	111	101	114		.ASCII /IAL/
1392	010074	040	043	000		.ASCII / #/<00>
1393	010077	000				.ASCII <00>
1394	010100	120	101	124	P.ADO:	.ASCII /PAT/
1395	010103	124	105	122		.ASCII /TER/
1396	010106	116	040	116		.ASCII /N N/
1397	010111	125	115	102		.ASCII /UMB/
1398	010114	105	122	000		.ASCII /ER/<00>
1399	010117	000				.ASCII <00>
1400	010120	105	122	122	P.ADP:	.ASCII /ERR/
1401	010123	117	122	040		.ASCII /OR /
1402	010126	102	111	124		.ASCII /BIT/
1403	010131	123	040	123		.ASCII /S S/
1404	010134	105	124	072		.ASCII /ET:/
1405	010137	000				.ASCII <00>
1406	010140	123	103	040	P.ADQ:	.ASCII /SC /
1407	010143	123	105	124		.ASCII /SET/
1408	010146	040	102	125		.ASCII / BU/
1409	010151	124	040	116		.ASCII /T N/
1410	010154	117	040	123		.ASCII /O S/
1411	010157	131	123	124		.ASCII /YST/
1412	010162	105	115	040		.ASCII /EM /
1413	010165	105	122	122		.ASCII /ERR/
1414	010170	117	122	123		.ASCII /ORS/
1415	010173	040	106	117		.ASCII / FO/
1416	010176	125	116	104		.ASCII /UND/
1417	010201	000				.ASCII <00>
1418	010202	116	125	115	P.ADR:	.ASCII /NUM/
1419	010205	102	105	122		.ASCII /BER/
1420	010210	040	117	106		.ASCII / OF/
1421	010213	040	115	102		.ASCII / MB/
1422	010216	131	124	105		.ASCII /YTE/
1423	010221	123	040	124		.ASCII /S T/
1424	010224	122	101	116		.ASCII /RAN/
1425	010227	123	106	105		.ASCII /SFE/
1426	010232	122	105	104		.ASCII /RED/
1427	010235	072	000	000		.ASCII /:/<00><00>
1428	010240	115	102	131	P.ADS:	.ASCII /MBY/
1429	010243	124	105	123		.ASCII /TES/
1430	010246	040	127	122		.ASCII / WR/

```

1432      :MLX4
1433      :
1434      :
1435 010251 111 124 105 .ASCII /ITE/
1436 010254 040 103 110 .ASCII / CH/
1437 010257 105 103 113 .ASCII /ECK/
1438 010262 105 104 000 .ASCII /ED/<00>
1439 010265 000 .ASCII <00>
1440 010266 124 117 120 P.ADT: .ASCII /TOP/
1441 010271 040 123 105 .ASCII / SE/
1442 010274 103 124 117 .ASCII /CTO/
1443 010277 122 040 117 .ASCII /R O/
1444 010302 106 000 .ASCII /F/<00>
1445 010304 114 117 127 P.ADU: .ASCII /LOW/
1446 010307 040 123 105 .ASCII / SE/
1447 010312 103 124 117 .ASCII /CTO/
1448 010315 122 040 117 .ASCII /R O/
1449 010320 106 000 .ASCII /F/<00>
1450 010322 123 131 123 P.ADV: .ASCII /SYS/
1451 010325 124 105 115 .ASCII /TEM/
1452 010330 040 114 111 .ASCII / LI/
1453 010333 115 111 124 .ASCII /MIT/
1454 010336 040 117 106 .ASCII / OF/
1455 010341 000 .ASCII <00>
1456 010342 120 105 122 P.ADW: .ASCII /PER/
1457 010345 106 117 122 .ASCII /FOR/
1458 010350 115 101 116 .ASCII /MAN/
1459 010353 103 105 040 .ASCII /CE /
1460 010356 123 125 115 .ASCII /SUM/
1461 010361 115 101 122 .ASCII /MAR/
1462 010364 131 000 .ASCII /Y/<00>
1463 010366 110 101 122 P.ADX: .ASCII /HAR/
1464 010371 104 040 105 .ASCII /D E/
1465 010374 122 122 117 .ASCII /RRO/
1466 010377 122 040 103 .ASCII /R C/
1467 010402 117 125 116 .ASCII /OUN/
1468 010405 124 000 000 .ASCII /T/<00><00>
1469 010410 115 102 131 P.ADY: .ASCII /MBY/
1470 010413 124 105 123 .ASCII /TES/
1471 010416 040 127 122 .ASCII / WR/
1472 010421 111 124 124 .ASCII /ITT/
1473 010424 105 116 000 .ASCII /EN/<00>
1474 010427 000 .ASCII <00>
1475 010430 115 102 131 P.ADZ: .ASCII /MBY/
1476 010433 124 105 123 .ASCII /TES/
1477 010436 040 122 105 .ASCII / RE/
1478 010441 101 104 000 .ASCII /AD/<00>
1479 010444 062 000 P.AEA: .ASCII /2/<00>
1480 010446 061 000 P.AEB: .ASCII /1/<00>
1481 010450 056 065 000 P.AEC: .ASCII /.5/<00>
1482 010453 000 .ASCII <00>
1483 010454 056 062 065 P.AED: .ASCII /.25/
1484 010457 000 .ASCII <00>
1485 010460 050 116 117 P.AEE: .ASCII /<NO/
1486 010463 124 040 120 .ASCII /T P/

```

```
1488  
1489 :MLX4  
1490 :  
1491 01066 117 127 105 .ASCII /OWE/  
1492 010471 122 105 104 .ASCII /RED/  
1493 010474 040 125 120 .ASCII / UP/  
1494 010477 051 000 000 .ASCII /)/<00><00>  
1495 010502 050 116 117 P.AEF: .ASCII /(NO/  
1496 010505 124 040 101 .ASCII /T A/  
1497 010510 116 040 115 .ASCII /N M/  
1498 010513 114 061 061 .ASCII /L11/  
1499 010516 040 125 116 .ASCII / UN/  
1500 010521 111 124 051 .ASCII /IT)/  
1501 010524 000 000 .ASCII <00><00>  
1502 010526 050 117 120 P.AEG: .ASCII /(OP/  
1503 010531 105 122 101 .ASCII /ERA/  
1504 010534 124 117 122 .ASCII /TOR/  
1505 010537 040 123 105 .ASCII / SE/  
1506 010542 114 105 103 .ASCII /LEC/  
1507 010545 124 105 104 .ASCII /TED/  
1508 010550 040 124 105 .ASCII / TE/  
1509 010553 123 124 040 .ASCII /ST /  
1510 010556 114 111 115 .ASCII /LIM/  
1511 010561 111 124 123 .ASCII /ITS/  
1512 010564 040 111 116 .ASCII / IN/  
1513 010567 103 117 122 .ASCII /COR/  
1514 010572 122 105 103 .ASCII /REC/  
1515 010575 124 114 131 .ASCII /TLY/  
1516 010600 051 000 .ASCII /)/<00>  
1517 010602 050 101 114 P.AEH: .ASCII /(AL/  
1518 010605 114 040 122 .ASCII /L R/  
1519 010610 105 124 122 .ASCII /ETR/  
1520 010613 111 105 123 .ASCII /IES/  
1521 010616 040 106 101 .ASCII / FA/  
1522 010621 111 114 105 .ASCII /ILE/  
1523 010624 104 040 106 .ASCII /D F/  
1524 010627 117 122 040 .ASCII /OR /  
1525 010632 101 040 116 .ASCII /A N/  
1526 010635 117 116 055 .ASCII /ON-/  
1527 010640 106 101 124 .ASCII /FAT/  
1528 010643 101 114 040 .ASCII /AL /  
1529 010646 105 122 122 .ASCII /ERR/  
1530 010651 117 122 051 .ASCII /OR)/  
1531 010654 000 000 .ASCII <00><00>  
1532 010656 050 103 117 P.AEI: .ASCII /(CO/  
1533 010661 116 124 122 .ASCII /NTR/  
1534 010664 117 114 114 .ASCII /OLL/  
1535 010667 105 122 040 .ASCII /ER /  
1536 010672 106 101 124 .ASCII /FAT/  
1537 010675 101 114 040 .ASCII /AL /  
1538 010700 105 122 122 .ASCII /ERR/  
1539 010703 117 122 051 .ASCII /OR)/  
1540 010706 000 000 .ASCII <00><00>  
1541 010710 050 104 122 P.AEJ: .ASCII /(DR/  
1542 010713 111 126 105 .ASCII /IVE/
```

```
1544      :MLX4
1545      :
1546      :
1547 010716      040      106      101      .ASCII / FA/
1548 010721      124      101      114      .ASCII /TAL/
1549 010724      040      105      122      .ASCII / ER/
1550 010727      122      117      122      .ASCII /ROR/
1551 010732      051      000      .ASCII /)/<00>
1552 010734      050      105      103 P.AEK: .ASCII /(EC/
1553 010737      103      040      110      .ASCII /C H/
1554 010742      101      122      104      .ASCII /ARD/
1555 010745      040      105      122      .ASCII / ER/
1556 010750      122      117      122      .ASCII /ROR/
1557 010753      051      000      000      .ASCII /)/<00><00>
1558 010756      050      105      103 P.AEL: .ASCII /(EC/
1559 010761      103      040      114      .ASCII /C L/
1560 010764      117      107      111      .ASCII /OGI/
1561 010767      103      040      106      .ASCII /C F/
1562 010772      101      111      114      .ASCII /AIL/
1563 010775      125      122      105      .ASCII /URE/
1564 011000      051      000      .ASCII /)/<00>
1565 011002      111      116      124 P.AEM: .ASCII /INT/
1566 011005      105      122      122      .ASCII /ERR/
1567 011010      125      120      124      .ASCII /UPT/
1568 011013      040      104      111      .ASCII / DI/
1569 011016      104      040      116      .ASCII /D N/
1570 011021      117      124      040      .ASCII /OT /
1571 011024      117      103      103      .ASCII /OCC/
1572 011027      125      122      054      .ASCII /UR,/
1573 011032      040      102      125      .ASCII / BU/
1574 011035      124      040      124      .ASCII /T T/
1575 011040      110      105      040      .ASCII /HE /
1576 011043      124      122      101      .ASCII /TRA/
1577 011046      116      123      106      .ASCII /NSF/
1578 011051      105      122      040      .ASCII /ER /
1579 011054      111      123      040      .ASCII /IS /
1580 011057      103      117      115      .ASCII /COM/
1581 011062      120      114      105      .ASCII /PLE/
1582 011065      124      105      000      .ASCII /TE/<00>
1583 011070      055      055      076 P.AEN: .ASCII /-->/
1584 011073      040      122      125      .ASCII / RU/
1585 011076      116      040      115      .ASCII /N M/
1586 011101      114      061      061      .ASCII /L11/
1587 011104      040      114      117      .ASCII / LO/
1588 011107      107      111      103      .ASCII /GIC/
1589 011112      040      124      105      .ASCII / TE/
1590 011115      123      124      000      .ASCII /ST/<00>
1591 011120      055      055      076 P.AEO: .ASCII /-->/
1592 011123      040      122      125      .ASCII / RU/
1593 011126      116      040      115      .ASCII /N M/
1594 011131      114      061      061      .ASCII /L11/
1595 011134      040      120      122      .ASCII / PR/
1596 011137      117      115      040      .ASCII /OM /
1597 011142      115      101      111      .ASCII /MAI/
1598 011145      116      124      105      .ASCII /NTE/
```

```

1600          :MLX4
1601          :
1602          : ML11 INTERRUPT SERVICE ROUTINE
1603 011150   116   101   116          .ASCII /NAN/
1604 011153   103   105   040          .ASCII /CE /
1605 011156   120   122   117          .ASCII /PRO/
1606 011161   107   122   101          .ASCII /GRA/
1607 011164   115   000          .ASCII /M/<00>
1608 011166   123   117   106 P.AEP:  .ASCII /SOF/
1609 011171   124   040   105          .ASCII /T E/
1610 011174   122   122   117          .ASCII /RRO/
1611 011177   122   000   000          .ASCII /R/<00><00>
1612 011202   110   101   122 P.AEQ:  .ASCII /HAR/
1613 011205   104   040   105          .ASCII /D E/
1614 011210   122   122   117          .ASCII /RRO/
1615 011213   122   000   000          .ASCII /R/<00><00>
1616 011216   105   103   103 P.AER:  .ASCII /ECC/
1617 011221   040   114   117          .ASCII / LO/
1618 011224   107   111   103          .ASCII /GIC/
1619 011227   040   106   101          .ASCII / FA/
1620 011232   111   114   105          .ASCII /ILE/
1621 011235   104   040   124          .ASCII /D T/
1622 011240   117   040   104          .ASCII /O D/
1623 011243   105   124   105          .ASCII /ETE/
1624 011246   103   124   040          .ASCII /CT /
1625 011251   104   101   124          .ASCII /DAT/
1626 011254   101   040   105          .ASCII /A E/
1627 011257   122   122   117          .ASCII /RRO/
1628 011262   122   000          .ASCII /R/<00>

```

```

1629
1630
1631
1632 011264   SBE.LOG: .BLKW 400
1633 012264   PM.SBE.CNT:
1634 012264   .BLKW 200
1635 012664   SBES.COUNT:
1636 012664   .BLKW 1
1637 012666   BIT.NUM: .BLKW 1
1638 012670   WBUFF: .BLKW 4000
1639 022670   RBUFF: .BLKW 4000
1640 032670   WPTR: .BLKW 1
1641 032672   RPTR: .BLKW 1
1642 032674   QUICK: .BLKW 1
1643 032676   PATTERN: .BLKW 1
1644 032700   DATA.COUNT:
1645 032700   .BLKW 1
1646 032702   COMP.COUNT:
1647 032702   .BLKW 1
1648 032704   EOP.COUNT:
1649 032704   .BLKW 1
1650 032706   BASE.ADDR:
1651 032706   .BLKW 1
1652 032710   VEC: .BLKW 1
1653 032712   BR.LEVEL:

```


27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

```

1655      :MLX4
1656      :
1657      :
1658 032712
1659 032714
1660 033314
1661 033714
1662 034314
1663 034314
1664 034316
1665 034316
1666 034320
1667 034320
1668 034322
1669 034322
1670 034324
1671 034324
1672 034326
1673 034326
1674 034330
1675 034330
1676 034332
1677 034332
1678 034334
1679 034334
1680 034336
1681 034336
1682 034340
1683 034340
1684 034342
1685 034344
1686
1687
1688
1689 034346
1690 034422
1691 034422
1692 034442
1693 034442
1694
1695 034444
1696 034444
1697
1698 034446
1699 034446
1700 034456
1701 034456
1702 034460
1703 034460
1704 034500
1705 034500
1706 034520 000000
1707 034522 002000
1708 034524 000001
  
```

```

:MLX4
:
ML11 INTERRUPT SERVICE ROUTINE
SOFTS: .BLKW 1
HARDS: .BLKW 200
TRIES: .BLKW 200
WR.COUNT:
      .BLKW 1
WR.THOUSANDS:
      .BLKW 1
WR.MILLIONS:
      .BLKW 1
RD.COUNT:
      .BLKW 1
RD.THOUSANDS:
      .BLKW 1
RD.MILLIONS:
      .BLKW 1
WC.COUNT:
      .BLKW 1
WC.THOUSANDS:
      .BLKW 1
WC.MILLIONS:
      .BLKW 1
I.AM.DONE:
      .BLKW 1
RETRYING:
      .BLKW 1
BOARD: .BLKW 1
BANK:  .BLKW 1

ML.REG: .BLKW 26
PTABLE.ADDR:
      .BLKW 10
DRIVE.STATUS:
      .BLKB 1
      .EVEN
DROPT.DRIVES:
      .BLKB 1
      .EVEN
WHY.DROPT:
      .BLKW 4
NUM.DRIVES:
      .BLKW 1
LOW.SECT:
      .BLKW 10
TOP.SECT:
      .BLKW 10
PATTBL: .WORD 0
      .WORD 2000
      .WORD 1
  
```

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

```
1710      ;MLX4
1711      ;
1712      ;
1713 034526 000001      .WORD 1
1714 034530 000004      .WORD 4
1715 034532 000004      .WORD 4
1716 034534 000011      .WORD 11
1717 034536 000011      .WORD 11
1718 034540 002000      .WORD 2000
1719 034542 002000      .WORD 2000
1720
1721
1722      .GLOBL EFNS$21, LSUNIT, L$LUN, LIMIT, RANGE
1723      .GLOBL LSECT, TSECT, ONLY, DROPNE, DROP1
1724      .GLOBL DRCP2, DROP3, DROP4, DROP5, MARPAT
1725      .GLOBL REFRESH, ECCDIS, EOPSUM, ERRROUT
1726      .GLOBL SEED1, SEED2, SEED3, RANDOM, RN
1727
1728
1729      100000      BIT15==      -100000
1730      040000      BIT14==      40000
1731      020000      BIT13==      20000
1732      010000      BIT12==      10000
1733      004000      BIT11==      4000
1734      002000      BIT10==      2000
1735      001000      BIT09==      1000
1736      000400      BIT08==      400
1737      000200      BIT07==      200
1738      000100      BIT06==      100
1739      000040      BIT05==      40
1740      000020      BIT04==      20
1741      000010      BIT03==      10
1742      000004      BIT02==      4
1743      000002      BIT01==      2
1744      000001      BIT00==      1
1745      001000      BIT9==      1000
1746      000400      BIT8==      400
1747      000200      BIT7==      200
1748      000100      BIT6==      100
1749      000040      BIT5==      40
1750      000020      BIT4==      20
1751      000010      BIT3==      10
1752      000004      BIT2==      4
1753      000002      BIT1==      2
1754      000001      BIT0==      1
1755      000040      EF.START==      40
1756      000037      EF.RESTART==      37
1757      000036      EF.CONTINUE==      36
1758      000035      EF.NEW==      35
1759      000034      EF.PWR==      34
1760      000340      PRI07==      340
1761      000300      PRI06==      300
1762      000240      PRI05==      240
1763      000200      PRI04==      200
1764      000140      PRI03==      140
1765      ;MLX4
1766      ;
```

ML11 INTERRUPT SERVICE ROUTINE

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

LSAU ADD UNIT SECTION			
1767			
1768	000100	PRI02==	100
1769	000040	PRI01==	40
1770	000000	PRI00==	0
1771	000004	EVL==	4
1772	000010	LOT==	10
1773	000020	ADR==	20
1774	000040	IDU==	40
1775	000100	ISR==	100
1776	000200	UAM==	200
1777	000400	BUE==	400
1778	001000	PNT==	1000
1779	002000	PRI==	2000
1780	004000	IXE==	4000
1781	010000	IBE==	10000
1782	020000	IER==	20000
1783	040000	LOE==	40000
1784	100000	HOE==	-100000
1785	012670	WDBUFF=	WDBUFF
1786	013670	WCBUFF=	WCBUFF+1000
1787	022670	RDBUFF=	RDBUFF
1788	023670	RCBUFF=	RCBUFF+1000
1789	022670	END.WBUFF=	END.WBUFF+10000
1790	032670	END.RBUFF=	END.RBUFF+10000
1791	005662	PHR21=	P.AAA
1792	005736	FMT16=	P.AAB
1793	006042	SBESHEADER=	P.AAC
1794	006126	FMT1A=	P.AAD
1795	006142	FMT1B=	P.AAE
1796	006160	FMT2=	P.AAF
1797	006166	FMT3=	P.AAG
1798	006216	FMT4A=	P.AAH
1799	006252	FMT4B=	P.AAI
1800	006270	FMT4C=	P.AAJ
1801	006320	FMT5=	P.AAK
1802	006376	FMT6=	P.AAL
1803	006446	FMT7=	P.AAM
1804	006466	FMT8=	P.AAN
1805	006534	FMT9=	P.AAO
1806	006564	FMT10A=	P.AAP
1807	006640	FMT10B=	P.AAQ
1808	006654	FMT11=	P.AAR
1809	006710	FMT12A=	P.AAS
1810	006756	FMT12B=	P.AAT
1811	007024	FMT13=	P.AAU
1812	007046	FMT14=	P.AAV
1813	007060	FMT15=	P.AAW
1814	007066	CRLF=	P.AAX
1815	007072	SAY1=	P.AAY
1816	007100	SAY2=	P.AAZ
1817	007112	SAY3=	P.ABA
1818	007130	SAY4=	P.ABB
1819	007152	SAY5=	P.ABC
1820		:MLX4	
1821		:	
1822			
1823	007200	WRD2=	P.ABD

ML11 INTERRUPT SERVICE ROUTINE

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS
PA:<

1824	007206	WRD3=	P.ABE
1825	007212	WRD4=	P.ABF
1826	007220	WRD6=	P.ABG
1827	007230	WRD7=	P.ABH
1828	007240	WRD11=	P.ABI
1829	007246	WRD15=	P.ABJ
1830	007256	WRD16=	P.ABK
1831	007264	WRD17=	P.ABL
1832	007272	WRD18=	P.ABM
1833	007300	WRD19=	P.ABN
1834	007312	WRD20=	P.ABO
1835	007322	WRD21=	P.ABP
1836	007332	WRD24=	P.ABQ
1837	007336	WRD25=	P.ABR
1838	007344	WRD34=	P.ABS
1839	007354	WRD35=	P.ABT
1840	007370	WRD36=	P.ABU
1841	007400	WRD37=	P.ABV
1842	007412	WRD38=	P.ABW
1843	007416	WRD40=	P.ABX
1844	007424	WRD41=	P.ABY
1845	007430	MLB2=	P.ABZ
1846	007434	MLB3=	P.ACA
1847	007440	MLB4=	P.ACB
1848	007444	MLB5=	P.ACC
1849	007450	MLB6=	P.ACD
1850	007454	MLB7=	P.ACE
1851	007460	MLB8=	P.ACF
1852	007464	MLB9=	P.ACG
1853	007472	MLB10=	P.ACH
1854	007500	MLB11=	P.ACI
1855	007504	MLB12=	P.ACJ
1856	007510	MLB13=	P.ACK
1857	007514	MLB14=	P.ACL
1858	007520	MLB15=	P.ACM
1859	007524	MLB16=	P.ACN
1860	007530	MLB17=	P.ACO
1861	007534	MLB18=	P.ACP
1862	007542	MLB19=	P.ACQ
1863	007550	MLB20=	P.ACR
1864	007554	MLB21=	P.ACS
1865	007560	MLB22=	P.ACT
1866	007564	MLB23=	P.ACU
1867	007570	MLB24=	P.ACV
1868	007574	RTN0=	P.ACW
1869	007626	RTN1=	P.ACX
1870	007634	RTN2=	P.ACY
1871	007642	RTN3=	P.ACZ
1872	007650	RTN4=	P.ADA
1873	007656	RTN5=	P.ADB
1874	007664	RTN5A=	P.ADC
1875		:MLX4	
1876		:	
1877			
1878	007672	RTN5B=	P.ADD
1879	007700	RTN5C=	P.ADE
1880	007706	RTN5D=	P.ADF

ML11 INTERRUPT SERVICE ROUTINE

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

1881	007714	PHR1=	P.ADG
1882	007730	PHR2=	P.ADH
1883	007746	PHR3=	P.ADI
1884	007770	PHR4=	P.ADJ
1885	010004	PHR5=	P.ADK
1886	010026	PHR6=	P.ADL
1887	010050	PHR7=	P.ADM
1888	010066	PHR8=	P.ADN
1889	010100	PHR9=	P.ADO
1890	010120	PHR10=	P.ADP
1891	010140	PHR11=	P.ADQ
1892	010202	PHR12=	P.ADR
1893	010240	PHR13=	P.ADS
1894	010266	PHR14=	P.ADT
1895	010304	PHR15=	P.ADU
1896	010322	PHR16=	P.ADV
1897	010342	PHR17=	P.ADW
1898	010366	PHR18=	P.ADX
1899	010410	PHR19=	P.ADY
1900	010430	PHR20=	P.ADZ
1901	010444	TRT00=	P.AEA
1902	010446	TRT01=	P.AEB
1903	010450	TRT10=	P.AEC
1904	010454	TRT11=	P.AED
1905	010460	CAUSE1=	P.AEE
1906	010502	CAUSE2=	P.AEF
1907	010526	CAUSE3=	P.AEG
1908	010602	CAUSE4=	P.AEH
1909	010656	CAUSE5=	P.AEI
1910	010710	CAUSE6=	P.AEJ
1911	010734	CAUSE7=	P.AEK
1912	010756	CAUSE8=	P.AEL
1913	011002	MSG0=	P.AEM
1914	011070	MSG1=	P.AEN
1915	011120	MSG2=	P.AEO
1916	011166	MSG3=	P.AEP
1917	011202	MSG4=	P.AEQ
1918	011216	MSG5=	P.AER

.SBTTL SERVICE ML11 INTERRUPT SERVICE ROUTINE

1926 034544
 1927 034544 012767 000001 177564
 1928 034552 000002
 1929
 1930
 1931
 1932
 1933
 1934
 1939
 1940
 1941 :MLX4
 1942 :
 1943 :
 1944 :

SERVICE::
 MOV #1,I.AM.DONE
 RTI
 :MLX4
 : ML11 INTERRUPT SERVICE ROUTINE

: Routine Size: 4 words
 : Maximum stack depth per invocation: 0 words

ONCE-ONLY CODE

2348 %sbttl 'ONCE-ONLY CODE'

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (5)

2346
 2345
 TOPS
 PA:<

```

1945 : 2349 routine CLRTBLS : novalue =
1946 : 2350 begin !* 1 *
1947 : 2351
1948 : 2352 !++
1949 : 2353 ROUTINE: CLRTBLS
1950 : 2354
1951 : 2355 PURPOSE: THIS ROUTINE IS CALLED BY THE INITIALIZATION CODE WHEN
1952 : 2356 A 'START' OR 'RESTART' COMMAND HAS BEEN USED TO BEGIN
1953 : 2357 THE PROGRAM. THE PURPOSES OF THE ROUTINE ARE:
1954 : 2358
1955 : 2359 (1) TO INITIALIZE STATISTICS TABLES
1956 : 2360
1957 : 2361 (2) TO SET ALL DRIVE AND ARRAY STATUS LOCATIONS TO ACTIVE
1958 : 2362 NOTE: EVEN IF A UNIT WAS DROPPED DURING A PREVIOUS
1959 : 2363 RUN, THE START OR RESTART COMMAND GUARANTEES
1960 : 2364 THAT THE DRIVE WILL ONCE AGAIN BE TESTABLE.
1961 : 2365
1962 : 2366 (3) TO ENABLE THE RUNNING OF ALL TEST OPTIONS IF THE
1963 : 2367 OPERATOR WANTED THEM ALL TO RUN.
1964 : 2368 !--
1965 : 2369
1966 : 2370 !+
1967 : 2371 !THIS IS THE CODE FOR PURPOSE 1:
1968 : 2372 !-
1969 : 2373
1970 : 2374 incr LUN from 0 to (.LSUNIT - 1) do
1971 : 2375 begin
1972 : 2376
1973 : 2377 incr ARRAY from 0 to 15 do
1974 : 2378 begin
1975 : 2379 SOFTS [.LUN, .ARRAY, 0, 16, 0] = 0;
1976 : 2380 HARDS [.LUN, .ARRAY, 0, 16, 0] = 0;
1977 : 2381 TRIES [.LUN, .ARRAY, 0, 16, 0] = 0;
1978 : 2382 end;
1979 : 2383
1980 : 2384 end;
1981 : 2385
1982 : 2386 SBES_COUNT = 0; ! VER CZMLBB ADDED CLEARING THIS VARIABLE
1983 : 2387 EOP_COUNT = 0;
1984 : 2388 NUM_DRIVES = 0;
1985 : 2389 RETRYING = INACTIVE;
1986 : 2390 WR_COUNT = 0;
1987 : 2391 WR_THOUSANDS = 0;
1988 : 2392 WR_MILLIONS = 0;
1989 : 2393 RD_COUNT = 0;
1990 : 2394 RD_THOUSANDS = 0;
1991 : 2395 RD_MILLIONS = 0;
1992 : 2396 WC_COUNT = 0;
1993 : 2397 WC_THOUSANDS = 0;
1994 : 2398 WC_MILLIONS = 0;
1995 : 2399 !+
1996 : MLX4
1997 : ONCE-ONLY CODE 27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
1998 : 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (5)
1999 : 2400 !THIS IS THE CODE FOR PURPOSE 2:
2000 : 2401 !-
2001 : 2402
    
```

```

2002 :      2403      incr LUN from 0 to (.LSUNIT - 1) do
2003 :      2404          begin
2004 :      2405              L$LUN = .LUN;
2005 :      2406              LOW_SECT [.LUN] = 0;
2006 :      2407              DRIVE_STATUS [.LUN] = ACTIVE;
2007 :      2408              DROPT_DRIVES [.LUN] = INACTIVE;
2008 :      2409              WHY_DROPT [.LUN] = 0;
2009 :      2410          end;
2010 :      2411
2011 :      2412      !+
2012 :      2413      ! THIS IS THE CODE FOR PURPOSE 3:
2013 :      2414      !-
2014 :      2415
2015 :      2416      if .DROPNE eql 0
2016 :      2417      then
2017 :      2418          begin
2018 :      2419              DROP1 = 0;
2019 :      2420              DROP2 = 0;
2020 :      2421              DROP3 = 0;
2021 :      2422              DROP4 = 0;
2022 :      2423              DROP5 = 0;
2023 :      2424          end;
2024 :      2425
2025 :      2426      !+
2026 :      2427      ! VER CZMLBB ADDED CLEARING OF THIS STRUCTURE
2027 :      2428      !
2028 :      2429      ! The single bit error log table stores all
2029 :      2430      ! detected sbe's detected during the run time
2030 :      2431      ! of the exerciser. In this table is stored
2031 :      2432      ! the sbe's: unit #, board #, bank #, bit #
2032 :      2433      ! and a count of how many times this sbe has
2033 :      2434      ! reoccured.
2034 :      2435      !
2035 :      2436      ! This code initializes this structure to zeroes
2036 :      2437      ! before starting execution of the exerciser.
2037 :      2438      !-
2038 :      2439
2039 :      2440      incr index from 0 to 127 do
2040 :      2441          begin
2041 :      2442              SBE_LOG [.index, WRDS_0] = ZERO;
2042 :      2443              SBE_LOG [.index, WRDS_1] = ZERO;
2043 :      2444          end;
2044 :      2445
2045 :      2446      !+
2046 :      2447      ! VER CZMLBB ADDED CLEARING OF THIS STRUCTURE
2047 :      2448      !
2048 :      2449      ! The prom maintenance program is called out
2049 :      2450      ! to be run on a particular array module when
2050 :      2451      ! that array module has collected 10 unique
    
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (5)

```

2052 : MLX4
2053 : ONCE-ONLY CODE
2054 :
2055 : 2452 | failing chips. This structure stores for
2056 : 2453 | each array within each unit its total number
2057 : 2454 | of unique failing chips.
2058 : 2455 |
2059 : 2456 | This code initializes this structure to zeroes
2060 : 2457 | before the exerciser is executed.
2061 : 2458 |
2062 : 2459 |
2063 : 2460 | incr UNIT_SEL from 0 to 7 do !Clear each units table
2064 : 2461 |
2065 : 2462 | incr ARRAY_SEL from 0 to 15 do !Clear each array within each unit
2066 : 2463 | PM_SBE_CNT [UNIT_SEL, .ARRAY_SEL, PM_SBE_SUM] = ZERO; !Clear this array sum
2067 : 2464 |
2068 : 2465 |
2069 : 2466 |
2070 : return;
2071 : end;
    
```

```

2074 : .SBTTL CLRTBLS ONCE-ONLY CODE
2078 034554 004167 150534 CLRTBLS:JSR R1,$SAVE4 : 2349
2079 034560 016704 145226 MOV L$UNIT,R4 : 2374
2080 034564 005001 CLR R1 : LUN
2081 034566 000424 BR 3$ :
2082 034570 010100 1$: MOV R1,R0 : LUN,* 2379
2083 034572 006300 ASL R0
2084 034574 006300 ASL R0
2085 034576 006300 ASL R0
2086 034600 006300 ASL R0
2087 034602 005003 CLR R3 : ARRAY 2377
2088 034604 010002 2$: MOV R0,R2 : 2379
2089 034606 060302 ADD R3,R2 : ARRAY,*
2090 034610 006302 ASL R2
2091 034612 005062 032714 CLR SOFTS(R2)
2092 034616 005062 033314 CLR HARDS(R2)
2093 034620 005062 033714 CLR TRIES(R2) : 2380
2094 034626 005203 INC R3 : 2381
2095 034630 020327 000017 CMP R3,#17 : ARRAY 2377
2096 034634 003763 BLE 2$ : ARRAY,*
2097 034636 005201 INC R1 : LUN
2098 034640 020104 3$: CMP R1,R4 : LUN,* 2374
2099 034642 002752 BLT 1$ :
2100 034644 005067 156014 CLR SBES.COUNT : 2386
2101 034650 005067 176030 CLR EOP.COUNT : 2387
2102 034654 005067 177576 CLR NUM.DRIVES : 2388
2103 034660 005067 177454 CLR RETRYING : 2389
2104 034664 005067 177424 CLR WR.COUNT : 2390
2105 034670 005067 177422 CLR WR.THOUSANDS : 2391
2106 034674 005067 177420 CLR WR.MILLIONS : 2392
    
```


J 7

SEQ 0087

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

Line	Code	Address	Oper	Operand	Comment	Page
2108						
2109						
2110						
2111	034700	005067	177416	CLR	RD.COUNT	
2112	034704	005067	177414	CLR	RD.THOUSANDS	
2113	034710	005067	177412	CLR	RD.MILLIONS	
2114	034714	005067	177410	CLR	WC.COUNT	
2115	034720	005067	177406	CLR	WC.THOUSANDS	
2116	034724	005067	177404	CLR	WC.MILLIONS	
2117	034730	005002		CLR	R2	
2118	034732	000445		BR	5\$: LUN
2119	034734	010267	145134	4\$: MOV	R2,L\$LUN	: LUN,*
2120	034740	010201		MOV	R2,R1	: LUN,*
2121	034742	006301		ASL	R1	
2122	034744	005061	034460	CLR	LOW.SECT(R1)	
2123	034750	010201		MOV	R2,R1	: LUN,*
2124	034752	006201		ASR	R1	
2125	034754	006201		ASR	R1	
2126	034756	006201		ASR	R1	
2127	034760	010146		MOV	R1,-(SP)	
2128	034762	062716	034442	ADD	#DRIVE.STATUS,(SP)	
2129	034766	010246		MOV	R2,-(SP)	: LUN,*
2130	034770	042716	177770	BIC	#177770,(SP)	
2131	034774	012746	000001	MOV	#1,-(SP)	
2132	035000	011646		MOV	(SP),-(SP)	
2133	035002	004767	147606	JSR	PC,BL\$PU2	
2134	035006	010116		MOV	R1,(SP)	
2135	035010	062716	034444	ADD	#DROPT.DRIVES,(SP)	
2136	035014	010246		MOV	R2,-(SP)	: LUN,*
2137	035016	042716	177770	BIC	#177770,(SP)	
2138	035022	012746	000001	MOV	#1,-(SP)	
2139	035026	005046		CLR	-(SP)	
2140	035030	004767	147560	JSR	PC,BL\$PU2	
2141	035034	105062	034446	CLRB	WHY.DROPT(R2)	: *(LUN)
2142	035040	062706	000016	ADD	#16,SP	
2143	035044	005202		INC	R2	: LUN
2144	035046	020204		5\$: CMP	R2,R4	: LUN,*
2145	035050	002731		BLT	4\$	
2146	035052	005767	145156	TST	DROPNE	
2147	035056	001012		BNE	6\$: 2416
2148	035060	005067	145152	CLR	DROP1	
2149	035064	005067	145150	CLR	DROP2	: 2419
2150	035070	005067	145146	CLR	DROP3	: 2420
2151	035074	005067	145144	CLR	DROP4	: 2421
2152	035100	005067	145144	CLR	DROP5	: 2422
2153	035104	005003		6\$: CLR	R3	: INDEX
2154	035106	010302		7\$: MOV	R3,R2	: INDEX,*
2155	035110	006302		ASL	R2	
2156	035112	006302		ASL	R2	
2157	035114	005062	011264	CLR	SBE.LOG(R2)	
2158	035120	005062	011266	CLR	SBE.LOG+2(R2)	
2159	035124	005203		INC	R3	: INDEX
2160	035126	020327	000177	CMP	R3,#177	: INDEX,*
2161	035132	003765		BLE	7\$	
2162	035134	005003		CLR	R3	: UNIT.SEL

```
2164      ;MLX4
2165      ;
2166      ONCE-ONLY CODE
2167 035136 010300      8$:  MOV  R3,R0      : UNIT.SEL,*
2168 035140 006300      ASL  R0
2169 035142 006300      ASL  R0
2170 035144 006300      ASL  R0
2171 035146 006300      ASL  R0
2172 035150 005002      CLR  R2      : ARRAY.SEL
2173 035152 010001      9$:  MOV  R0,R1      :
2174 035154 060201      ADD  R2,R1      : ARRAY.SEL,*
2175 035156 005301      ASL  R1
2176 035160 005061 012264 CLR  PM.SBE.CNT(R1)
2177 035164 005202      INC  R2      : ARRAY.SEL
2178 035166 020227 000017 CMP  R2,#17      : ARRAY.SEL,*
2179 035172 003767      BLE  9$
2180 035174 005203      INC  R3      : UNIT.SEL
2181 035176 020327 000007 CMP  R3,#7      : UNIT.SEL,*
2182 035202 003755      BLE  8$
2183 035204 000207      RTS  PC
2184      ;
2185      : Routine Size: 141 words
2186      : Maximum stack depth per invocation: 12 words
2191
2192
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (6)

```

2194 :MLX4
2195 :
2196 :
2197 : 2467 routine INIT_ADDRESSES (PLOC) : novalue =
2198 : 2468 begin
2199 : 2469
2200 : 2470
2201 : 2471
2202 : 2472
2203 : 2473
2204 : 2474
2205 : 2475
2206 : 2476
2207 : 2477
2208 : 2478
2209 : 2479
2210 : 2480
2211 : 2481
2212 : 2482
2213 : 2483
2214 : 2484
2215 : 2485
2216 : 2486
2217 : 2487
2218 : 2488
2219 : 2489
2220 : 2490
2221 : 2491
2222 : 2492
2223 : 2493
2224 : 2494
2225 : 2495
2226 : 2496
2227 : 2497
2228 : 2498
2229 : 2499
2230 : 2500
2231 : 2501
2232 : 2502
2233 : 2503
2234 : 2504
2235 : 2505
2236 : 2506
2237 : 2507
2238 : 2508
2239 : 2509
2240 : 2510
2241 : 2511
2242 : 2512
2243 : 2513
2244 : 2514
2245 : 2515
2246 : 2516
2247 : 2517
2248 : 2518

ONCE-ONLY CODE

! * 1 *

ROUTINE: INIT_ADDRESSES(PLOC)
PURPOSE: THIS ROUTINE IS CALLED ONLY ONCE DURING THE INITIALIZATION
CODE, EVEN IF THERE IS MORE THAN ONE DRIVE PRESENT. THE
PURPOSES OF THE ROUTINE ARE:
(1) TO OBTAIN HARDWARE P-TABLE INFORMATION FROM
MAIN MEMORY WHICH PERTAINS TO ALL DRIVES.
(2) TO SET UP THE ADDRESSES FOR THE 22 ML-11 REGISTERS.
(3) TO SET UP THE INTERRUPT SERVICE ROUTINE AT THE
CORRECT PRIORITY, AND LOWER THE CPU PRIORITY TO
ALLOW INTERRUPTS TO OCCUR.
ARGUMENT: PLOC = THE POINTER TO THE LOCATION IN MAIN MEMORY WHERE
THE HARDWARE P-TABLE IS TO BE FOUND.

local
TEMP,
PRIORITY,
OFFSET;

THIS IS THE CODE FOR PURPOSE 1:

BASE_ADDR = (.PLOC + 0);
VEC = (.PLOC + 2);
BR_LEVEL = (.PLOC + 4);
PRIORITY = .BR_LEVEL^5;

if .ECCDIS
then
TEMP = WRD37 !ECC IS DISABLED
else
TEMP = WRD36; !ECC IS ENABLED (NORMAL OPERATION)

PRINTB (CRLF);
PRINTB (SAYS, WRD34, WRD40, WRD38, .TEMP, WRD41);
!'RUNNING WITH ECC ENABLED/DISABLED AND'

if .REFRESH
then
TEMP = WRD36 !REFRESH MARGINING IS ENABLED
else
TEMP = WRD37; !REFRESH MARGINING IS DISABLED (NORMAL OPERATION)
    
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (6)

```

2250 :MLX4
2251 :
2252 : ONCE-ONLY CODE
2253 :
2254 : 2519
2255 : 2520 PRINTB (SAY3, WRD40, PHR3, .TEMP);
2256 : 2521 !'WITH REFRESH MARGINING ENABLED/DISABLED'
2257 : 2522 PRINTB (CRLF);
2258 : 2523
2259 : 2524 !+
2260 : 2525 !THIS IS THE CODE FOR PURPOSE 2:
2261 : 2526 !-
2262 : 2527
2263 : 2528 OFFSET = 0;
2264 : 2529
2265 : 2530 incr COUNT from 0 to (NUM_REGS - 1) do
2266 : 2531 begin !* 2 *
2267 : 2532 ML_REG [.COUNT] = .BASE_ADDR + .OFFSET;
2268 : 2533 OFFSET = .OFFSET + 2;
2269 : 2534 end; !* 2 *
2270 : 2535
2271 : 2536 !+
2272 : 2537 !THIS IS THE CODE FOR PURPOSE 3:
2273 : 2538 !-
2274 : 2539
2275 : 2540 SETPRI (PRI00);
2276 : 2541 SETVEC (.VEC, SERVICE, .PRIORITY);
2277 : 2542 return;
2281 : 2543 end; !* 1 *
  
```

Address	Label	Offset	Value	SBTTL	INIT.ADDRESSES	ONCE-ONLY CODE	Address
2286	035206			INIT.ADDRESSES:			
2287	035206	004167	150102	JSR	R1,\$SAVE4		
2288	035212	016602	000014	MOV	14(SP),R2	: PLOC,*	2467
2289	035216	011267	175464	MOV	(R2),BASE_ADDR		2499
2290	035222	016267	000002	MOV	2(R2),VEC		
2291	035230	016267	000004	MOV	4(R2),BR_LEVEL		2500
2292	035236	016746	175450	MOV	BR_LEVEL,-(SP)		2501
2293	035242	012746	000005	MOV	#5,-(SP)		2502
2294	035246	004767	147742	JSR	PC,BL\$SHF		
2295	035252	010003		MOV	R0,R3	: *,PRIORITY	
2296	035254	032767	000001	BIT	#1,ECCDIS		
2297	035262	001403		BEQ	1\$		2504
2298	035264	012701	007400	MOV	#WRD37,R1	: *,TEMP	2506
2299	035270	000402		BR	2\$		2504
2300	035272	012701	007370	MOV	#WRD36,R1	: *,TEMP	2508
2301	035276	012716	007066	MOV	#CRLF,(SP)		2510
2302	035302	012746	000001	MOV	#1,-(SP)		
2303	035306	010600		MOV	SP,R0	: SP,*	
2304	035310	104414		TRAP	14		

Address	OpCode	Operand1	Operand2	Operand3	Comment	Line No.
2306						
2307						
2308					ONCE-ONLY CODE	
2309	035312	012716	007424	MOV	#WRD41,(SP)	
2310	035316	010146		MOV	R1,-(SP)	: TEMP,*
2311	035320	012746	007412	MOV	#WRD38,-(SP)	
2312	035324	012746	007416	MOV	#WRD40,-(SP)	
2313	035330	012746	007344	MOV	#WRD34,-(SP)	
2314	035334	012746	007152	MOV	#SAY5,-(SP)	
2315	035340	012746	000006	MOV	#6,-(SP)	
2316	035344	010600		MOV	SP,R0	: SP,*
2317	035346	104414		TRAP	14	
2318	035350	032767	000001	BIT	#1,REFRESH	
2319	035356	001403	144674	BEQ	3\$: 2514
2320	035360	012701	007370	MOV	#WRD36,R1	: *,TEMP
2321	035364	000402		BR	4\$: 2516
2322	035366	012701	007400	MOV	#WRD37,R1	: 2514
2323	035372	010116		MOV	R1,(SP)	: *,TEMP
2324	035374	012746	007746	MOV	#PHR3,-(SP)	: TEMP,*
2325	035400	012746	007416	MOV	#WRD40,-(SP)	
2326	035404	012746	007112	MOV	#SAY3,-(SP)	
2327	035410	012746	000004	MOV	#4,-(SP)	
2328	035414	010600		MOV	SP,R0	: SP,*
2329	035416	104414		TRAP	14	
2330	035420	012716	007066	MOV	#CRLF,(SP)	
2331	035424	012746	000001	MOV	#1,-(SP)	: 2522
2332	035430	010600		MOV	SP,R0	: SP,*
2333	035432	104414		TRAP	14	
2334	035434	005002		CLR	R2	: OFFSET
2335	035436	005000		CLR	R0	: COUNT
2336	035440	010001		MOV	R0,R1	: COUNT,*
2337	035442	006301		ASL	R1	
2338	035444	016704	175236	MOV	BASE.ADDR,R4	
2339	035450	060204		ADD	R2,R4	: OFFSET,*
2340	035452	010461	034346	MOV	R4,ML.REG(R1)	
2341	035456	062702	000002	ADD	#2,R2	: *,OFFSET
2342	035462	005200		INC	R0	: COUNT
2343	035464	020027	000025	CMP	R0,#25	: COUNT,*
2344	035470	003763		BLE	5\$	
2345	035472	005000		CLR	R0	: 2540
2346	035474	104441		TRAP	41	
2347	035476	010316		MOV	R3,(SP)	: PRIORITY,*
2348	035500	012746	034544	MOV	#SERVICE,-(SP)	: 2541
2349	035504	016746	175200	MOV	VEC,-(SP)	
2350	035510	012746	000003	MOV	#3,-(SP)	
2351	035514	104437		TRAP	37	
2352	035516	062706	000042	ADD	#42,SP	: 2467
2353	035522	000207		RTS	PC	
2354						
2355						
2356						

: Routine Size: 103 words
: Maximum stack depth per invocation: 22 words

2362 :MLX4
 2363 :
 2364 :
 2365 :
 2366 :
 2367 :
 2368 :
 2369 :
 2370 :
 2371 :
 2372 :
 2373 :
 2374 :
 2375 :
 2376 :
 2377 :
 2378 :
 2379 :
 2380 :
 2381 :
 2382 :
 2383 :
 2384 :
 2385 :
 2386 :
 2387 :
 2388 :
 2389 :
 2390 :
 2391 :
 2392 :
 2393 :
 2394 :
 2395 :
 2396 :
 2397 :
 2398 :
 2399 :
 2400 :
 2401 :
 2405 :
 2406 :

DRIVE IDENTIFICATION ROUTINES

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (7)

```

2544 %sbttl 'DRIVE IDENTIFICATION ROUTINES'
2545 routine SAYWHO (LUN) : novalue =
2546 begin
2547
2548 +-+
2549 ROUTINE: SAYWHO(LUN)
2550
2551 PURPOSE: TO PRINT OUT AN IDENTIFICATION LINE WHICH INCLUDES:
2552 LOGICAL UNIT: X DRIVE: Y SERIAL #: ZZZZ
2553
2554 THE UNIT'S SERIAL NUMBER IN EITHER BCD OR OCTAL FORMAT.
2555 BCD WILL BE PRINTED AS LONG AS THE DIGITS ARE ALL VALID.
2556
2557 --
2558 local
2559 D3,
2560 D2,
2561 D1,
2562 D0:
2563
2564 D3 = .SN3:
2565 D2 = .SN2:
2566 D1 = .SN1:
2567 D0 = .SN0:
2568 PRINTB (FMT4A, PHR7, .LUN, WRD11, .DRIVE);
2569 !'LOGICAL UNIT: X DRIVE: Y'
2570
2571 if ((.D3 gtr 9) or (.D2 gtr 9) or (.D1 gtr 9) or (.D0 gtr 9))
2572 then
2573 PRINTB (FMT4B, PHR8, .MLSN)
2574 !' SERIAL #: ZZZZZZ'
2575 else
2576 PRINTB (FMT4C, PHR8, .D3, .D2, .D1, .D0);
2577
2578 !' SERIAL #: DDDD'
2579 return;
2580 end;
    
```

2410 035524 004167 147604
 2411 035530 017705 176642
 2412 035534 006205
 2413 035536 006205
 2414 035540 006205
 2415 035542 006205
 2416 035544 000305
 2417 :
 2418 :
 2419 :
 2420 035546 042705 177760
 2421 035552 017704 176620
 2422 035556 000304
 2423 035560 042704 177760
 2424 035564 117701 176606

```

.SBTTL SAYWHO DRIVE IDENTIFICATION ROUTINES
SAYWHO: JSR R1,$SAVES
MOV @ML.REG+30,R5
ASR R5
ASR R5
ASR R5
ASR R5
SWAB R5
:MLX4
:
DRIVE IDENTIFICATION ROUTINES
BIC #177760,R5
MOV @ML.REG+30,R4
SWAB R4
BIC #177760,R4
MOVB @ML.REG+30,R1
    
```

2545
 2564
 2565
 2566

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44
 TOPS
 PA:<

2425	035570	006201		ASR	R1	:	D1	
2426	035572	006201		ASR	R1	:	D1	
2427	035574	006201		ASR	R1	:	D1	
2428	035576	006201		ASR	R1	:	D1	
2429	035600	042701	177760	BIC	#177760,R1	:	*D1	
2430	035604	117702	176566	MOVB	@ML,REG+30,R2	:	*D0	2567
2431	035610	042702	177760	BIC	#177760,R2	:	*D0	
2432	035614	016603	000016	MOV	16(SP),R3	:	LUN,*	2568
2433	035620	006303		ASL	R3	:		
2434	035622	016303	034422	MOV	PTABLE.ADDR(R3),R3	:		
2435	035626	016346	000006	MOV	6(R3),-(SP)	:		
2436	035632	012746	007240	MOV	#WRD11,-(SP)	:		
2437	035636	016646	000022	MOV	22(SP),-(SP)	:	LUN,*	
2438	035642	012746	010050	MOV	#PHR7,-(SP)	:		
2439	035646	012746	006216	MOV	#FMT4A,-(SP)	:		
2440	035652	012746	000005	MOV	#5,-(SP)	:		
2441	035656	010600		MOV	SP,R0	:	SP,*	
2442	035660	104414		TRAP	14	:		
2443	035662	020527	000011	CMP	R5,#11	:	D3,*	2571
2444	035666	003011		BGT	1\$:		
2445	035670	020427	000011	CMP	R4,#11	:	D2,*	
2446	035674	003006		BGT	1\$:		
2447	035676	020127	000011	CMP	R1,#11	:	D1,*	
2448	035702	003003		BGT	1\$:		
2449	035704	020227	000011	CMP	R2,#11	:	D0,*	
2450	035710	003413		BLE	2\$:		
2451	035712	017746	176460	MOV	@ML,REG+30,-(SP)	:		2573
2452	035716	012746	010066	MOV	#PHR8,-(SP)	:		
2453	035722	012746	006252	MOV	#FMT4B,-(SP)	:		
2454	035726	012745	000003	MOV	#3,-(SP)	:		
2455	035732	010600		MOV	SP,R0	:	SP,*	
2456	035734	104414		TRAP	14	:		
2457	035736	000416		BR	3\$:		
2458	035740	010246		MOV	R2,-(SP)	:	D0,*	2571
2459	035742	010146		MOV	R1,-(SP)	:	D1,*	2576
2460	035744	010446		MOV	R4,-(SP)	:	D2,*	
2461	035746	010546		MOV	R5,-(SP)	:	D3,*	
2462	035750	012746	010066	MOV	#PHR8,-(SP)	:		
2463	035754	012746	006270	MOV	#FMT4C,-(SP)	:		
2464	035760	012746	000006	MOV	#6,-(SP)	:		
2465	035764	010600		MOV	SP,R0	:	SP,*	
2466	035766	104414		TRAP	14	:		
2467	035770	062706	000006	ADD	#6,SP	:		
2468	035774	062706	000024	ADD	#24,SP	:		
2469	036000	000207		RTS	PC	:		2545

: Routine Size: 87 words
 :MLX4
 : DRIVE IDENTIFICATION ROUTINES
 : Maximum stack depth per invocation: 19 words

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

2481 :MLX4
 2482 :
 2483 : DRIVE IDENTIFICATION ROUTINES
 2484 :
 2485 : 2581 routine CONFIG (LUN) : novalue =

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (8)

```

2486 :      2582      begin                               !* 1 *
2487 :      2583
2488 :      2584      +-
2489 :      2585      ROUTINE:      CONFIG(LUN)
2490 :      2586
2491 :      2587      PURPOSE:      CONFIG IS CALLED BY THE INITIALIZATION CODE FOR EACH DRIVE
2492 :      2588      WHICH SUCCESSFULLY RESPONDS TO A REQUEST FOR ITS HARDWARE
2493 :      2589      P-TABLE.  THE PURPOSES OF THIS ROUTINE ARE:
2494 :      2590
2495 :      2591      (1)  TO CHECK THAT THE DRIVE IS POWERED UP.
2496 :      2592
2497 :      2593      (2)  TO VERIFY THAT THE DRIVE IS AN ML11 UNIT.
2498 :      2594
2499 :      2595      (3)  TO VERIFY THAT THE OPERATOR DEFINED TEST RANGES ARE
2500 :      2596      WITHIN THE CALCULATED SYSTEM SIZE.
2501 :      2597
2502 :      2598      (4)  TO PRINT DRIVE IDENTIFICATION INFORMATION.
2503 :      2599
2504 :      2600      ARGUMENT:      LUN = THE LOGICAL UNIT NUMBER, COUNTING FROM 0 TO
2505 :      2601      NUMBER OF DRIVES MINUS 1.
2506 :      2602      --
2507 :      2603
2508 :      2604      local
2509 :      2605      TYPE,
2510 :      2606      TEMP,
2511 :      2607      TOP;
2512 :      2608
2513 :      2609      !+
2514 :      2610      !THIS IS THE CODE FOR PURPOSE 1:
2515 :      2611      !-
2516 :      2612
2517 :      2613      UNIT = .DRIVE;
2518 :      2614
2519 :      2615      if .DPR neq 1
2520 :      2616      then
2521 :      2617      begin
2522 :      2618      PRINTB (FMT4A, PHR7, .LUN, WRD11, .DRIVE);
2523 :      2619      !'LOGICAL UNIT: X  DRIVE: Y'
2524 :      2620      PRINTB (SAY2, WRD11, WRD21);
2525 :      2621      !'DRIVE DROPPED'
2526 :      2622      PRINTB (FMT2, CAUSE1);
2527 :      2623      !' (NOT POWERED UP)'
2528 :      2624      WHY DROPT [.LUN] = CODE_1;
2529 :      2625      DODD (.LUN);
2530 :      2626      return;
2531 :      2627      end;
2532 :      2628
2533 :      2629      !+
2534 :      2630      !THIS IS THE CODE FOR PURPOSE 2:
2535 :      2631      !-
2536 :      2632

```


2538 :MLX4
 2539 :
 2540 :
 2541 :
 2542 :
 2543 :
 2544 :
 2545 :
 2546 :
 2547 :
 2548 :
 2549 :
 2550 :
 2551 :
 2552 :
 2553 :
 2554 :
 2555 :
 2556 :
 2557 :
 2558 :
 2559 :
 2560 :
 2561 :
 2562 :
 2563 :
 2564 :
 2565 :
 2566 :
 2567 :
 2568 :
 2569 :
 2570 :
 2571 :
 2572 :
 2573 :
 2574 :
 2575 :
 2576 :
 2577 :
 2578 :
 2579 :
 2580 :
 2581 :
 2582 :
 2583 :
 2584 :
 2585 :
 2586 :
 2587 :
 2588 :
 2589 :
 2590 :
 2591 :
 2592 :

DRIVE IDENTIFICATION ROUTINES

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (8)

```

2633 SAYWHO (.LUN);
2634 !'LOGICAL UNIT: X DRIVE: Y SERIAL #: ZZZZ'
2635 TYPE = .MLDT;
2636
2637 if ((.TYPE neq ML11A) and (.TYPE neq ML11B))
2638 then
2639 begin
2640 PRINTB (SAY2, WRD11, WRD21);
2641 !'DRIVE DROPPED'
2642 PRINTB (FMT2, CAUSE2);
2643 !' (NOT AN ML11 UNIT)';
2644 WHY DROPT [.LUN] = CODE_2;
2645 DODD (.LUN);
2646 return;
2647 end
2648 else
2649 begin
2650 !* 3 *
2651 if .ARR_TYP eql 0
2652 then
2653 begin
2654 TYPE = WRD6;
2655 TOP = 1;
2656 end
2657 !* 4 *
2658 else
2659 begin
2660 TYPE = WRD7;
2661 TOP = 4;
2662 end;
2663 !* 5 *
2664 !+
2665 !THIS IS THE CODE FOR PURPOSE 3:
2666 !-
2667 TOP_SECT [.LUN] = (.TOP)*(512)*(.SZ) - 1;
2668
2669 if .LIMIT
2670 then
2671 !+
2672 !THE OPERATOR HAS CHOSEN LIMITS:
2673 !-
2674
2675 begin
2676 !* 6 *
2677 if .RANGE eql 0
2678 then
2679 !+
2680 !THE BOARD NUMBER (0-15) IS CONTAINED IN 'ONLY'
2681 !-
2682
2683
2684
  
```

```

2594 :MLX4
2595 :
2596 :
2597 : 2685
2598 : 2686
2599 : 2687
2600 : 2688
2601 : 2689
2602 : 2690
2603 : 2691
2604 : 2692
2605 : 2693
2606 : 2694
2607 : 2695
2608 : 2696
2609 : 2697
2610 : 2698
2611 : 2699
2612 : 2700
2613 : 2701
2614 : 2702
2615 : 2703
2616 : 2704
2617 : 2705
2618 : 2706
2619 : 2707
2620 : 2708
2621 : 2709
2622 : 2710
2623 : 2711
2624 : 2712
2625 : 2713
2626 : 2714
2627 : 2715
2628 : 2716
2629 : 2717
2630 : 2718
2631 : 2719
2632 : 2720
2633 : 2721
2634 : 2722
2635 : 2723
2636 : 2724
2637 : 2725
2638 : 2726
2639 : 2727
2640 : 2728
2641 : 2729
2642 : 2730
2643 : 2731
2644 : 2732
2645 : 2733
2646 : 2734
2647 : 2735
2648 : 2736

DRIVE IDENTIFICATION ROUTINES

begin
! * 10 *
!
! VER CZMLBB CHANGED .TYPE TO .ARR_TYP
!
!
! if .ARR_TYP
! then
!
! +
! ! THE CHIPS ARE 64K
! !-
!
! begin
! LSECT = 2048*.ONLY;
! TSECT = .LSECT + 2047;
! end
! * 7 *
!
! else
!
! +
! ! THE CHIPS ARE 16K
! !-
!
! begin
! LSECT = 512*.ONLY;
! TSECT = .LSECT + 511;
! end;
! * 8 *
!
! end;
! * 10 *
!
! if .TSECT leqa .TOP_SECT [.LUN]
! then
! TOP_SECT [.LUN] = .TSECT
! else
! begin
! PRINTB (SAY2, WRD11, WRD21);
! !'DRIVE DROPPED'
! PRINTB (FMT2, CAUSE3);
! !' (OPERATOR SELECTED TEST LIMITS INCORRECTLY)'
! PRINTB (FMT11, PHR14, .TSECT, PHR16, .TOP SECT [.LUN]);
! !'TOP SECTOR OF XXXXXX EXCEEDS SYSTEM LIMIT OF YYYYYY'
! WHY DROPT [.LUN] = CODE_3;
! DODD (.LUN);
! return;
! end;
!
! if .LSECT leqa .TSECT
! then
! LOW_SECT [.LUN] = .LSECT
! else
! begin
! PRINTB (SAY2, WRD11, WRD21);
! !'DRIVE DROPPED'
    
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (8)

```

2650 :MLX4
2651 :
2652 :
2653 : 2737
2654 : 2738
2655 : 2739
2656 : 2740
2657 : 2741
2658 : 2742
2659 : 2743
2660 : 2744
2661 : 2745
2662 : 2746
2663 : 2747
2664 : 2748
2665 : 2749
2666 : 2750
2667 : 2751
2668 : 2752
2669 : 2753
2670 : 2754
2671 : 2755
2672 : 2756
2673 : 2757
2674 : 2758
2675 : 2759
2676 : 2760
2677 : 2761
2678 : 2762
2679 : 2763
2680 : 2764
2681 : 2765
2682 : 2766
2683 : 2767
2684 : 2768
2685 : 2769
2686 : 2770
2687 : 2771
2688 : 2772
2689 : 2773
2690 : 2774
2691 : 2775
2692 : 2776
2693 : 2777
2694 : 2778
2698 :
2699 :
    
```

DRIVE IDENTIFICATION ROUTINES

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (8)

```

PRINTB (FMT2, CAUSE3);
!' (OPERATOR SELECTED TEST LIMITS INCORRECTLY)'
PRINTB (FMT11, PHR15, .LSECT, PHR14, .TSECT);
!'LOW SECTOR OF XXXXXX EXCEEDS TOP SECTOR OF YYYYYY'
WHY DROPT [.LUN] = CODE_3;
DODD (.LUN);
return;
end;
    
```

end; !* 6 *

!+
 THIS IS THE CODE FOR PURPOSE 4:
 !-

```

PRINTB (FMT5, .TYPE, LOWEST, HIGHEST);
!'ML11-X SECTORS UNDER TEST: XXXXXX TO YYYYYY'
    
```

```

selectone .TRT of
set
[0] :
TEMP = TRT00;
[1] :
TEMP = TRT01;
[2] :
TEMP = TRT10;
[3] :
TEMP = TRT11;
tes;
    
```

```

PRINTB (FMT8, .TEMP);
!'TRANSFER RATE: X MBYTES/SECOND'
PRINTB (FMT4B, PHR4, .BASE_ADDR);
!' CSR ADDRESS: XXXXXX'
end;
    
```

!* 3 *

```

return;
end;
    
```

!* 1 *

2703 036002 004167 147326
 2704 036006 016603 000016

CONFIG: .SBTTL CONFIG DRIVE IDENTIFICATION ROUTINES
 JSR R1, \$SAVE5
 MOV 16(SP), R3
 : LUN, *

2581
 2613

Address	OpCode	Operand1	Operand2	Operand3	Instruction	Comments	Label
2706							
2707							
2708							
2709	036012	010304			MOV R3,R4		
2710	036014	006304			ASL R4		
2711	036016	016401	034422		MOV PTABLE,ADDR(R4),R1		
2712	036022	016105	000006		MOV 6(R1),R5		
2713	036026	042705	177770		BIC #177770,R5		
2714	036032	142777	000007	176316	BICB #7,@ML.REG+10		
2715	036040	150577	176312		BISB R5,@ML.REG+10		
2716	036044	032777	000400	176306	BIT #400,@ML.REG+12		
2717	036052	001051			BNE 1\$		2615
2718	036054	016401	034422		MOV PTABLE,ADDR(R4),R1		
2719	036060	016146	000006		MOV 6(R1),-(SP)		2618
2720	036064	012746	007240		MOV #WRD11,-(SP)		
2721	036070	010346			MOV R3,-(SP)		
2722	036072	012746	010050		MOV #PHR7,-(SP)		
2723	036076	012746	006216		MOV #FMT4A,-(SP)		
2724	036102	012746	000005		MOV #5,-(SP)		
2725	036106	010600			MOV SP,R0	: SP,*	
2726	036110	104414			TRAP 14		
2727	036112	012716	007322		MOV #WRD21,(SP)		
2728	036116	012746	007240		MOV #WRD11,-(SP)		2620
2729	036122	012746	007100		MOV #SAY2,-(SP)		
2730	036126	012746	000003		MOV #3,-(SP)		
2731	036132	010600			MOV SP,R0	: SP,*	
2732	036134	104414			TRAP 14		
2733	036136	012716	010460		MOV #CAUSE1,(SP)		
2734	036142	012746	006160		MOV #FMT2,-(SP)		2622
2735	036146	012746	000002		MOV #2,-(SP)		
2736	036152	010600			MOV SP,R0	: SP,*	
2737	036154	104414			TRAP 14		
2738	036156	112763	000001	034446	MOVB #1,WHY.DROPT(R3)		
2739	036164	010300			MOV R3,R0		2624
2740	036166	104451			TRAP 51		2625
2741	036170	062706	000026		ADD #26,SP		
2742	036174	000207			RTS PC		2615
2743	036176	010346			MOV R3,-(SP)		2617
2744	036200	004767	177320		JSR PC,SAYWHO		2633
2745	036204	017702	176164		MOV @ML.REG+26,R2	: *,TYPE	
2746	036210	020227	000110		CMP R2,#110	: TYPE,*	2635
2747	036214	001435			BEQ 2\$		2637
2748	036216	020227	000111		CMP R2,#111	: TYPE,*	
2749	036222	001432			BEQ 2\$		
2750	036224	012746	007322		MOV #WRD21,-(SP)		
2751	036230	012746	007240		MOV #WRD11,-(SP)		2640
2752	036234	012746	007100		MOV #SAY2,-(SP)		
2753	036240	012746	000003		MOV #3,-(SP)		
2754	036244	010600			MOV SP,R0	: SP,*	
2755	036246	104414			TRAP 14		
2756	036250	012716	010502		MOV #CAUSE2,(SP)		
2757	036254	012746	006160		MOV #FMT2,-(SP)		2642
2758	036260	012746	000002		MOV #2,-(SP)		
2759	036264	010600			MOV SP,R0	: SP,*	
2760	036266	104414			TRAP 14		

Address	OpCode	Operand1	Operand2	Operand3	Instruction	Comments	Line Number
2762							
2763							
2764							
2765	036270	112763	000002	034446	MOVB	#2,WHY.DROPT(R3)	
2766	036276	010300			MOV	R3,R0	2644
2767	036300	104451			TRAP	51	2645
2768	036302	062706	000016		ADD	#16,SP	
2769	036306	000207			RTS	PC	2637
2770	036310	032777	002000	176054	BIT	#2000,AML.REG+24	2639
2771	036316	001005			BNE	3\$	2651
2772	036320	012702	007220		MOV	#WORD6,R2	*.TYPE
2773	036324	012701	000001		MOV	#1,R1	*.TOP
2774	036330	000404			BR	4\$	2654
2775	036332	012702	007230		MOV	#WORD7,R2	*.TYPE
2776	036336	012701	000004		MOV	#4,R1	*.TOP
2777	036342	012705	034500		MOV	#TOP,SECT,R5	*.TOP
2778	036346	060405			ADD	R4,R5	
2779	036350	010146			MOV	R1,-(SP)	TOP,*
2780	036352	017701	176014		MOV	AML.REG+24,R1	2649
2781	036356	006201			ASR	R1	
2782	036360	006201			ASR	R1	
2783	036362	006201			ASR	R1	
2784	036364	000301			SWAB	R1	
2785	036366	042701	177740		BIC	#177740,R1	
2786	036372	010146			MOV	R1,-(SP)	
2787	036374	004767	146344		JSR	PC,BLSMUL	
2788	036400	000300			SWAB	R0	
2789	036402	105000			CLRB	R0	2667
2790	036404	006300			ASL	R0	
2791	036406	010001			MOV	R0,R1	
2792	036410	005301			DEC	R1	
2793	036412	010115			MOV	R1,(R5)	
2794	036414	032767	000001	143600	BIT	#1,LIMIT	
2795	036422	001575			BEQ	11\$	2669
2796	036424	005767	143574		TST	RANGE	
2797	036430	001037			BNE	6\$	2678
2798	036432	032777	002000	175732	BIT	#2000,AML.REG+24	
2799	036440	001417			BEQ	5\$	2690
2800	036442	016700	143564		MOV	ONLY,R0	
2801	036446	000300			SWAB	R0	2698
2802	036450	105000			CLRB	R0	
2803	036452	006300			ASL	R0	
2804	036454	006300			ASL	R0	
2805	036456	006300			ASL	R0	
2806	036460	010067	143542		MOV	R0,LSECT	
2807	036464	010067	143540		MOV	R0,TSECT	
2808	036470	062767	003777	143532	ADD	#3777,TSECT	: LSECT,*
2809	036476	000414			BR	6\$	
2810	036500	016700	143526		MOV	ONLY,R0	
2811	036504	000300			SWAB	R0	2690
2812	036506	105000			CLRB	R0	2708
2813	036510	006300			ASL	R0	
2814	036512	010067	143510		MOV	R0,LSECT	
2815	036516	010067	143506		MOV	R0,TSECT	: LSECT,*
2816	036522	062767	000777	143500	ADD	#777,TSECT	2709

Address	Hex	Hex	Hex	Label	Code	Comment	Time	Page
2818				:MLX4			27-Mar-1982 19:24:42	TOPS
2819				:			27-Mar-1982 19:23:44	PA:<
2820						DRIVE IDENTIFICATION ROUTINES		
2821	036530	026715	143474	6\$:	CMP	TSECT,(R5)		2714
2822	036534	101003			BHI	7\$		
2823	036536	016715	143466		MOV	TSECT,(R5)		2716
2824	036542	000445			BR	8\$		2714
2825	036544	012746	007322	7\$:	MOV	#WRD21,-(SP)		2719
2826	036550	012745	007240		MOV	#WRD11,-(SP)		
2827	036554	012746	007100		MOV	#SAY2,-(SP)		
2828	036560	012746	000003		MOV	#3,-(SP)		
2829	036564	010600			MOV	SP,R0	: SP,*	
2830	036566	104414			TRAP	14		
2831	036570	012716	010526		MOV	#CAUSE3,(SP)	:	2721
2832	036574	012746	006160		MOV	#FMT2,-(SP)		
2833	036600	012746	000002		MOV	#2,-(SP)		
2834	036604	010600			MOV	SP,R0	: SP,*	
2835	036606	104414			TRAP	14		
2836	036610	011516			MOV	(R5),(SP)	:	2723
2837	036612	012746	010322		MOV	#PHR16,-(SP)		
2838	036616	016746	143406		MOV	TSECT,-(SP)		
2839	036622	012746	010266		MOV	#PHR14,-(SP)		
2840	036626	012746	006654		MOV	#FMT11,-(SP)		
2841	036632	012746	000005		MOV	#5,-(SP)		
2842	036636	010600			MOV	SP,R0	: SP,*	
2843	036640	104414			TRAP	14		
2844	036642	112763	000003 034446		MOVB	#3,WHY.DROPT(R3)	:	2725
2845	036650	010300			MOV	R3,R0	:	2726
2846	036652	104451			TRAP	51		
2847	036654	000455			BR	10\$		2714
2848	036656	026767	143344 143344	8\$:	CMP	LSECT,TSECT	:	2730
2849	036664	101004			BHI	9\$		
2850	036666	016764	143334 034460		MOV	LSECT,LOW.SECT(R4)	:	2732
2851	036674	000450			BR	11\$:	2730
2852	036676	012746	007322	9\$:	MOV	#WRD21,-(SP)	:	2735
2853	036702	012746	007240		MOV	#WRD11,-(SP)		
2854	036706	012746	007100		MOV	#SAY2,-(SP)		
2855	036712	012746	000003		MOV	#3,-(SP)		
2856	036716	010600			MOV	SP,R0	: SP,*	
2857	036720	104414			TRAP	14		
2858	036722	012716	010526		MOV	#CAUSE3,(SP)	:	2737
2859	036726	012746	006160		MOV	#FMT2,-(SP)		
2860	036732	012746	000002		MOV	#2,-(SP)		
2861	036736	010600			MOV	SP,R0	: SP,*	
2862	036740	104414			TRAP	14		
2863	036742	016716	143262		MOV	TSECT,(SP)	:	2739
2864	036746	012746	010266		MOV	#PHR14,-(SP)		
2865	036752	016746	143250		MOV	LSECT,-(SP)		
2866	036756	012746	010304		MOV	#PHR15,-(SP)		
2867	036762	012746	006654		MOV	#FMT11,-(SP)		
2868	036766	012746	000005		MOV	#5,-(SP)		
2869	036772	010600			MOV	SP,R0	: SP,*	
2870	036774	104414			TRAP	14		
2871	036776	112763	000003 034446		MOVB	#3,WHY.DROPT(R3)	:	2741
2872	037004	010300			MOV	R3,R0	:	2742

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

Address	OpCode	Operand1	Operand2	Label	Instruction	Comments	Address
2874							
2875							
2876							
2877	037006	104451			TRAP	51	
2878	037010	062706	000034	10\$:	ADD	#34,SP	
2879	037014	000207			RTS	PC	
2880	037016	011516		11\$:	MOV	(R5),(SP)	
2881	037020	016446	034460		MOV	LOW.SECT(R4),-(SP)	
2882	037024	010246			MOV	R2,-(SP)	: TYPE,*
2883	037026	012746	006320		MOV	#FMT5,-(SP)	
2884	037032	012746	000004		MOV	#4,-(SP)	
2885	037036	010600			MOV	SP,R0	: SP,*
2886	037040	104414			TRAP	14	
2887	037042	017701	175324		MOV	@ML.REG+24,R1	
2888	037046	000301			SWAB	R1	
2889	037050	042701	177774		BIC	#177774,R1	
2890	037054	001003			BNE	12\$	
2891	037056	012700	010444		MOV	#TRT00,R0	: *,TEMP
2892	037062	000421			BR	15\$	
2893	037064	020127	000001	12\$:	CMP	R1,#1	
2894	037070	001003			BNE	13\$	
2895	037072	012700	010446		MOV	#TRT01,R0	: *,TEMP
2896	037076	000413			BR	15\$	
2897	037100	020127	000002	13\$:	CMP	R1,#2	
2898	037104	001003			BNE	14\$	
2899	037106	012700	010450		MOV	#TRT10,R0	: *,TEMP
2900	037112	000405			BR	15\$	
2901	037114	020127	000003	14\$:	CMP	R1,#3	
2902	037120	001002			BNE	15\$	
2903	037122	012700	010454		MOV	#TRT11,R0	: *,TEMP
2904	037126	010016		15\$:	MOV	R0,(SP)	: TEMP,*
2905	037130	012746	006466		MOV	#FMT8,-(SP)	
2906	037134	012746	000002		MOV	#2,-(SP)	
2907	037140	010600			MOV	SP,R0	: SP,*
2908	037142	104414			TRAP	14	
2909	037144	016716	173536		MOV	BASE.ADDR,(SP)	
2910	037150	012746	007770		MOV	#PHR4,-(SP)	
2911	037154	012746	006252		MOV	#FMT4B,-(SP)	
2912	037160	012746	000003		MOV	#3,-(SP)	
2913	037164	010600			MOV	SP,R0	: SP,*
2914	037166	104414			TRAP	14	
2915	037170	062706	000030		ADD	#30,SP	
2916	037174	000207			RTS	PC	

: Routine Size: 318 words
 : Maximum stack depth per invocation: 20 words

2917
 2918
 2919
 2924
 2925

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (9)

```

2927 :MLX4
2928 :
2929 :
2930 : 2779 routine DECODE (SECT) : novalue =
2931 : 2780 begin
2932 : 2781
2933 : 2782 |++
2934 : 2783 ROUTINE: DECODE(SECT)
2935 : 2784
2936 : 2785 PURPOSE: TO INTERPRET THE FIELDS OF THE FAILING SECTOR
2937 : 2786 FOR BOTH 16K AND 64K CHIPS.
2938 : 2787
2939 : 2788 ARGUMENT: SECT = FAILING SECTOR NUMBER
2940 : 2789
2941 : 2790 RESULTS: (1) BANK = WHICH ROW OF CHIPS (0-4)
2942 : 2791
2943 : 2792 (2) BOARD = WHICH ARRAY MODULE (0-15)
2944 : 2793 |--
2945 : 2794
2946 : 2795 if .MLDT
2947 : 2796 then !THE CHIPS ARE 64K
2948 : 2797 begin
2949 : 2798 BANK = .SECT<9, 2>;
2950 : 2799 BOARD = .SECT<11, 4>;
2951 : 2800 end
2952 : 2801 else !THE CHIPS ARE 16K
2953 : 2802 begin
2954 : 2803 BANK = .SECT<7, 2>;
2955 : 2804 BOARD = .SECT<9, 4>;
2956 : 2805 end;
2957 : 2806
2958 : 2807
2959 : 2808 ! VER CZMLBB ADDED LOADING OF BIT_NUM TO ROUTINE
2960 : 2809
2961 : 2810 BIT_NUM = .CHAN; !SAVE THE FAILING CHIP NUMBER
2962 : 2811 return;
2963 : 2812 end;
  
```

```

2968
2972 037176 032777 000001 175170 DECODE: .SBTTL DECODE DRIVE IDENTIFICATION ROUTINES
2973 037204 001415 BIT #1, @ML.REG+26
2974 037206 016600 000002 BEQ 1$
2975 037212 006200 MOV 2(SP),R0 ; SECT,*
2976 037214 000300 ASR R0
2977 037216 042700 SWAB R0
2978 037222 010067 175116 BIC #177774,R0
2979 037226 016600 000002 MOV R0,BANK
2980 037232 006200 MOV 2(SP),R0 ; SECT,*
2981 037234 006200 ASR R0
  
```


27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

2983				:MLX4				
2984				:		DRIVE IDENTIFICATION ROUTINES		
2985								
2986	037236	000412			BR	2\$		
2987	037240	016600	000002	1\$:	MOV	2(SP),R0	: SECT,*	2803
2988	037244	006100			ROL	R0		
2989	037246	000300			SWAB	R0		
2990	037250	042700	177774		BIC	#177774,R0		
2991	037254	010067	175064		MOV	R0,BANK		
2992	037260	016600	000002		MOV	2(SP),R0	: SECT,*	2804
2993	037264	006200		2\$:	ASR	R0		
2994	037266	000300			SWAB	R0		
2995	037270	042700	177760		BIC	#177760,R0		
2996	037274	010067	175042		MOV	R0,BOARD		
2997	037300	017700	175104		MOV	@ML.REG+42,R0	:	2810
2998	037304	006200			ASR	R0		
2999	037306	006200			ASR	R0		
3000	037310	006200			ASR	R0		
3001	037312	006200			ASR	R0		
3002	037314	006200			ASR	R0		
3003	037316	006200			ASR	R0		
3004	037320	042700	177700		BIC	#177700,R0		
3005	037324	010067	153336		MOV	R0,BIT.NUM		
3006	037330	000207			RTS	PC	:	2779
3007								
3008								
3009								
3014								
3015								

: Routine Size: 46 words
 : Maximum stack depth per invocation: 0 words

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (10)

3017 :MLX4
 3018 :
 3019 :
 3020 : 2813
 3021 : 2814
 3022 : 2815
 3023 : 2816
 3024 : 2817
 3025 : 2818
 3026 : 2819
 3027 : 2820
 3028 : 2821
 3029 : 2822
 3030 : 2823
 3031 : 2824
 3032 : 2825
 3033 : 2826
 3034 : 2827
 3035 : 2828
 3036 : 2829
 3037 : 2830
 3038 : 2831
 3039 : 2832
 3043 :
 3044 :
 3048 037332 017746 175054
 3049 037336 004767 177634
 3050 037342 032767 000001 142710
 3051 037350 001422
 3052 037352 016746 174766
 3053 037356 016746 174760
 3054 037362 017746 175024
 3055 037366 012746 007246
 3056 037372 012746 007312
 3057 037376 012746 006564
 3058 037402 012746 000006
 3059 037406 010600
 3060 037410 104414
 3061 037412 062706 000016
 3062 037416 005726
 3063 037420 000207
 3064 :
 3065 :
 3066 :

DRIVE IDENTIFICATION ROUTINES
 routine ISOLATE : novalue =
 begin
 !++
 ROUTINE: ISOLATE
 PURPOSE: UPON THE DETECTION OF A DATA ERROR (EITHER RECOVERABLE OR NOT) TO EXAMINE THE SECTOR ADDRESS CONTAINED IN THE ECC ERROR LOCATION REGISTER AND PINPOINT THE LOCATION OF THE ERROR. THE SECTOR, BOARD (0-15) AND BANK (0-3) WILL BE REPORTED.
 !--
 DECODE (.MLEL):
 if .ERROUT then PRINTB (FMT10A, WRD20, WRD15, .MLEL, .BOARD, .BANK);
 !'FAILED: SECTOR XXXXXX BOARD YY BANK Z'
 return;
 end;

```

.SBTTL ISOLATE DRIVE IDENTIFICATION ROUTINES
ISOLATE:MOV @ML.REG+44,-(SP)
JSR PC,DECODE
BIT #1,ERROUT
BEQ 1$
MOV BANK,-(SP)
MOV BOARD,-(SP)
MOV @ML.REG+44,-(SP)
MOV #WRD15,-(SP)
MOV #WRD20,-(SP)
MOV #FMT10A,-(SP)
MOV SP,R0
TRAP 14
ADD #16,SP
1$: TST (SP)+
RTS PC
    
```

2826
 2828
 2813

: Routine Size: 28 words
 : Maximum stack depth per invocation: 8 words

```

3072 :MLX4
3073 :
3074 :
3075 : 2833 routine UP_HARD_COUNT (LUN, ARRAY) : novalue =
3076 : 2834 begin
3077 : 2835
3078 : 2836 !++
3079 : 2837 ROUTINE: UP_HARD_COUNT(LUN,ARRAY)
3080 : 2838
3081 : 2839 PURPOSE: TO INCREMENT THE HARD ERROR COUNT FOR THE GIVEN
3082 : 2840 ARRAY, AND TO SEE IF THE HARD ERROR THRESHOLD HAS
3083 : 2841 BEEN REACHED.
3084 : 2842
3085 : 2843 ARGUMENTS: LUN = LOGICAL UNIT WHICH HAS THE HARD ERROR
3086 : 2844 ARRAY = THE BOARD NUMBER (0-15)
3087 : 2845 !--
3088 : 2846
3089 : 2847 local
3090 : 2848 SBE_EXIST; ! VER CZMLBB ADDED THIS LOCAL STORAGE
3091 : 2849 !Indicates if the searched sbe already exists
3092 : 2850 HARDS [.LUN, .ARRAY, 0, 16, 0] = .HARDS [.LUN, .ARRAY, 0, 16, 0] + 1;
3093 : 2851
3094 : 2852 VER CZMLBB ADDED FOLLOWING CODE TO LOG SBE'S
3095 : 2853
3096 : 2854 First search the sbe log table and see if
3097 : 2855 this single bit error already exists in
3098 : 2856 the table. If it does exist then just
3099 : 2857 increment its occurrence count, else
3100 : 2858 record its failing location into the
3101 : 2859 table.
3102 : 2860
3103 : 2861 Only log away 128 single bit errors.
3104 : 2862
3105 : 2863
3106 : 2864 if .SBE$_COUNT lss 127 !Have 128 errors been logged yet
3107 : 2865 then
3108 : 2866 begin !There is room for at least one more sbe
3109 : 2867 SBE_EXIST = FALSE; !Init the existance flag to false
3110 : 2868
3111 : 2869 !+
3112 : 2870 Search the single bit error log table
3113 : 2871 and see if this error already exist.
3114 : 2872 !-
3115 : 2873
3116 : 2874 incr index from 0 to .SBE$_COUNT do
3117 : 2875 begin
3118 : 2876
3119 : 2877 if (.SBE_LOG [.index, BITS_SBE] eql .BIT_NUM) and !Does this bit exist
3120 : 2878 (.SBE_LOG [.index, BNKS_SBE] eql .BANK) and !Does this bank exist
3121 : 2879 (.SBE_LOG [.index, BRDS_SBE] eql .BOARD) and !Does this board exist
3122 : 2880 (.SBE_LOG [.index, UNITS_SBE] eql .LUN) !Does this unit exist
3123 : 2881 then
3124 : 2882 begin
3125 : 2883 SBE_LOG [.index, SUMS_SBE] = .SBE_LOG [.index, SUMS_SBE] + 1; !This sbe already exist so just up its occurrence count
3126 : 2884 SBE_EXIST = TRUE; !Indicate that this sbe already exist
    
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 BLISS-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (11)

3128 :MLX4
 3129 :
 3130 :
 3131 :
 3132 :
 3133 :
 3134 :
 3135 :
 3136 :
 3137 :
 3138 :
 3139 :
 3140 :
 3141 :
 3142 :
 3143 :
 3144 :
 3145 :
 3146 :
 3147 :
 3148 :
 3149 :
 3150 :
 3151 :
 3152 :
 3153 :
 3154 :
 3155 :
 3156 :
 3157 :
 3158 :
 3159 :
 3160 :
 3161 :
 3162 :
 3163 :
 3164 :
 3165 :
 3166 :
 3167 :
 3168 :
 3169 :
 3170 :
 3171 :
 3172 :
 3173 :
 3174 :
 3175 :
 3176 :
 3177 :
 3178 :
 3179 :
 3180 :
 3181 :
 3182 :

DRIVE IDENTIFICATION ROUTINES

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (11)

```

exitloop;
end;

end;

+
Test to see if this sbe was already in the table
by testing the flag sbe_exist. If it did not exist then
up the Prom Maintenance count, load this sbe into the table
and test to see if this array module needs to be Prom Maintained.
If the sbe did exist then return from this routine.
-

if not .SBE_EXIST !Was this sbe found in the table
then
begin !It was not found in the table so up the pm count
PM_SBE_CNT [.LUN, .BOARD, PM_SBE$SUM] = .PM_SBE_CNT [.LUN, .BOARD, PM_SBE$SUM] + 1;
!Now see if the Prom Maint Program needs to be
run on this array module.

if .PM_SBE_CNT [.LUN, .BOARD, PM_SBE$SUM] eql 10 !Is the limit exceeded
then
begin !The limit was exceeded
SAYWHO (.LUN);
PRINTB (FMT13, .ARRAY, MSG2);
!'ARRAY XX --> RUN ML11 PROM MAINTENANCE PROGRAM'
end;

+
This sbe was not found in the table so
load this failing sbe into the table
at the bottom of the list.
-

SBE_LOG [.SBE$COUNT, BITS_SBE] = .BIT_NUM; !Load the failing bit
SBE_LOG [.SBE$COUNT, BNKS_SBE] = .BANK; !Load the failing bank
SBE_LOG [.SBE$COUNT, BRDS_SBE] = .BOARD; !Load the failing board
SBE_LOG [.SBE$COUNT, UNITS_SBE] = .LUN; !Load the failing unit
SBE_LOG [.SBE$COUNT, SUMP_SBE] = 1; !Indicate this is the first one
SBE$COUNT = .SBE$COUNT + 1; !Up the count of unique sbe's detected
end;

end;

!
! VER COMMENTED OUT THIS CODE
! REPLACED BY ABOVE CODE
!

if (((.ARR_TYP eql 1) and (.HARDS [.LUN, .ARRAY, 0, 16, 0] eql H64K_LIMIT)) or ((.ARR_TYP eql 0) and (
.HARDS [.LUN, .ARRAY, 0, 16, 0] eql H16K_LIMIT)))

```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (11)

3184 :MLX4
 3185 :
 3186 :
 3187 :
 3188 :
 3189 :
 3190 :
 3191 :
 3192 :
 3193 :
 3194 :
 3198 :
 3199 :

DRIVE IDENTIFICATION ROUTINES

```

then
begin
  SAYWHO (.LUN);
  PRINTB (FMT13, .ARRAY, MSG2);
  !'ARRAY XX --> RUN ML11 FROM MAINTENANCE PROGRAM'
end;
return;
end;
    
```

Address	Hex	Dec	Hex	Label	Code	Comment	Address
3203	037422			UP.HARD.COUNT:	.SBTTL	UP.HARD.COUNT DRIVE IDENTIFICATION ROUTINES	
3204	037422	004167	145706		JSR	R1,\$SAVE5	
3205	037426	016605	000020		MOV	20(SP),R5	2833
3206	037432	010500			MOV	R5,R0	2850
3207	037434	006300			ASL	R0	
3208	037436	006300			ASL	R0	
3209	037440	006300			ASL	R0	
3210	037442	006300			ASL	R0	
3211	037444	010002			MOV	R0,R2	
3212	037446	066602	000016		ADD	16(SP),R2	
3213	037452	006302			ASL	R2	: ARRAY,*
3214	037454	005262	033314		INC	HARDS(R2)	
3215	037460	026727	153200	000177	CMP	SBES.COUNT,#177	
3216	037466	002401			BLT	1\$	2864
3217	037470	000207			RTS	PC	
3218	037472	005004		1\$:	CLR	R4	: SBE.EXIST
3219	037474	005001			CLR	R1	: INDEX
3220	037476	000463			BR	4\$	2874
3221	037500	010102			MOV	R1,R2	: INDEX,*
3222	037502	006302		2\$:	ASL	R2	2877
3223	037504	006302			ASL	R2	
3224	037506	012703	011264		MOV	#SBE.LOG,R3	
3225	037512	060203			ADD	R2,R3	
3226	037514	016746	153146		MOV	BIT.NUM,-(SP)	
3227	037520	011346			MOV	(R3),-(SP)	
3228	037522	006216			ASR	(SP)	
3229	037524	006216			ASR	(SP)	
3230	037526	006216			ASR	(SP)	
3231	037530	006216			ASR	(SP)	
3232	037532	006216			ASR	(SP)	
3233	037534	006216			ASR	(SP)	
3234	037536	042716	177600		BIC	#177600,(SP)	
3235	037542	022626			CMP	(SP)+,(SP)+	
3236	037544	001037			BNE	3\$	
3237	037546	016746	174572		MOV	BANK,-(SP)	
3238	037552	111346			MOVB	(R3),-(SP)	2878

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

Address	OpCode	Operand1	Operand2	Operand3	Comment	Line
3240					:MLX4	
3241					:	
3242					DRIVE IDENTIFICATION ROUTINES	
3243	037554	042716	177774		BIC #177774,(SP)	
3244	037560	022626			CMP (SP)+,(SP)+	
3245	037562	001030			BNE 3\$	
3246	037564	016746	174552		MOV BOARD,-(SP)	
3247	037570	111346			MOV#B (R3),-(SP)	2879
3248	037572	006216			ASR (SP)	
3249	037574	006216			ASR (SP)	
3250	037576	042716	177760		BIC #177760,(SP)	
3251	037602	022626			CMP (SP)+,(SP)+	
3252	037604	001017			BNE 3\$	
3253	037606	010546			MOV R5,-(SP)	
3254	037610	011346			MOV (R3),-(SP)	2880
3255	037612	006116			ROL (SP)	
3256	037614	006116			ROL (SP)	
3257	037616	006116			ROL (SP)	
3258	037620	006116			ROL (SP)	
3259	037622	042716	177770		BIC #177770,(SP)	
3260	037626	022626			CMP (SP)+,(SP)+	
3261	037630	001005			BNE 3\$	
3262	037632	005262	011266		INC SBE.LOG+2(R2)	2883
3263	037636	012704	000001		MOV #1,R4	2884
3264	037642	000404			BR 5\$	2885
3265	037644	005201			INC R1	2874
3266	037646	020167	153012		4\$: CMP R1,SBE\$.COUNT	
3267	037652	003712			BLE 2\$	
3268	037654	006004			5\$: ROR R4	
3269	037656	103511			BLO 7\$	2898
3270	037660	010002			MOV R0,R2	
3271	037662	066702	174454		ADD BOARD,R2	2901
3272	037666	006302			ASL R2	
3273	037670	005262	012264		INC PM.SBE.CNT(R2)	
3274	037674	026227	012264	000012	CMP PM.SBE.CNT(R2),#12	2907
3275	037702	001017			BNE 6\$	
3276	037704	010546			MOV R5,-(SP)	2910
3277	037706	004767	175612		JSR PC,SA:WHO	
3278	037712	012716	011120		MOV #MSG2,(SP)	2911
3279	037716	016646	000020		MOV 20(SP),-(SP)	
3280	037722	012746	007024		MOV #FMT13,-(SP)	
3281	037726	012746	000003		MOV #3,-(SP)	
3282	037732	010600			MOV SP,R0	
3283	037734	104414			TRAP 14	
3284	037736	062706	000010		ADD #10,SP	2909
3285	037742	016702	152716		6\$: MOV SBE\$.COUNT,R2	2921
3286	037746	006302			ASL R2	
3287	037750	006302			ASL R2	
3288	037752	012701	011264		MOV #SBE.LOG,R1	
3289	037756	060201			ADD R2,R1	
3290	037760	016704	152702		MOV BIT.NUM,R4	
3291	037764	000304			SWAB R4	
3292	037766	106004			RORB R4	
3293	037770	006004			ROR R4	
3294	037772	006004			ROR R4	

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

```

3296          :MLX4
3297          :
3298          :
3299 037774 042704 160077      BIC      #160077,R4
3300 040000 042711 017700      BIC      #17700,(R1)
3301 040004 050411              BIS      R4,(R1)
3302 040006 016704 174332      MOV      BANK,R4
3303 040012 042704 177774      BIC      #177774,R4
3304 040016 142711 000003      BICB     #3,(R1)
3305 040022 150411              BISB     R4,(R1)
3306 040024 016704 174312      MOV      BOARD,R4
3307 040030 006304              ASL      R4
3308 040032 006304              ASL      R4
3309 040034 042704 177703      BIC      #177703,R4
3310 040040 142711 000074      BICB     #74,(R1)
3311 040044 150411              BISB     R4,(R1)
3312 040046 006005              ROR      R5
3313 040050 006005              ROR      R5
3314 040052 006005              ROR      R5
3315 040054 006005              ROR      R5
3316 040056 042705 017777      BIC      #17777,R5
3317 040062 042711 160000      BIC      #160000,(R1)
3318 040066 050511              BIS      R5,(R1)
3319 040070 012762 000001 011266      MOV      #1,SBE.LOG+2(R2)
3320 040076 005267 152562      INC      SBES.COUNT
3321 040102 000207      7s:     RTS      PC
    
```

2922
 2923
 2924
 2925
 2926
 2833

: Routine Size: 153 words
 : Maximum stack depth per invocation: 10 words

3322
 3323
 3324
 3329
 3330

```

3332 :MLX4
3333 :
3334 :
3335 : 2945 routine UP_SOFT_COUNT (LUN, ARRAY) : novalue =
3336 : 2946     begin
3337 : 2947
3338 : 2948     !++
3339 : 2949     ROUTINE:     UP_SOFT_COUNT(LUN,ARRAY)
3340 : 2950
3341 : 2951     PURPOSE:    TO INCREMENT THE SOFT ERROR COUNT FOR THE GIVEN
3342 : 2952                ARRAY, AND TO SEE IF THE SOFT ERROR THRESHOLD HAS
3343 : 2953                BEEN REACHED.
3344 : 2954
3345 : 2955     ARGUMENTS:   LUN  = LOGICAL UNIT WHICH HAS THE SOFT ERROR
3346 : 2956                ARRAY = THE BOARD NUMBER (0-15)
3347 : 2957     !--
3348 : 2958
3349 : 2959     local
3350 : 2960         SBE_EXIST;                ! VER CZMLBB ADD THIS LOCAL STORAGE
3351 : 2961                                     !Flag to indicate if sbe already exists
3352 : 2962     SOFTS [.LUN, .ARRAY, 0, 16, 0] = .SOFTS [.LUN, .ARRAY, 0, 16, 0] + 1;
3353 : 2963
3354 : 2964     ! VER CZMLBB ADDED FOLLOWING CODE TO LOG SBE'S
3355 : 2965
3356 : 2966     ! First search the sbe log table and see if
3357 : 2967     ! this single bit error already exists in
3358 : 2968     ! the table. If it does exist then just
3359 : 2969     ! increment its occurrence count, else
3360 : 2970     ! record its failing location into the
3361 : 2971     ! table.
3362 : 2972
3363 : 2973     ! Only log away 128 single bit errors.
3364 : 2974
3365 : 2975
3366 : 2976     if .SBES_COUNT lss 127
3367 : 2977     then
3368 : 2978         begin
3369 : 2979             SBE_EXIST = FALSE;
3370 : 2980
3371 : 2981             !+
3372 : 2982             ! Search the single bit error log table
3373 : 2983             ! and see if this error already exist.
3374 : 2984             !-
3375 : 2985
3376 : 2986             incr index from 0 to .SBES_COUNT do
3377 : 2987                 begin
3378 : 2988
3379 : 2989                     if (.SBE_LOG [.index, BITS_SBE] eql .BIT_NUM) and !Does this bit exist
3380 : 2990                         (.SBE_LOG [.index, BNKS_SBE] eql .BANK) and !Does this bank exist
3381 : 2991                         (.SBE_LOG [.index, BRDS_SBE] eql .BOARD) and !Does this board exist
3382 : 2992                         (.SBE_LOG [.index, UNITS_SBE] eql .LUN) !Does this unit exist
3383 : 2993                     then
3384 : 2994                         begin
3385 : 2995                             SBE_LOG [.index, SUMS_SBE] = .SBE_LOG [.index, SUMS_SBE] + 1;
3386 : 2996                             SBE_EXIST = TRUE;
3387 :
3388 :                                     !This sbe already exist so just up its occurrence count
3389 :                                     !Indicate that this sbe already exist
    
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (12)

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (12)

3388 :MLX4
3389 :
3390 :
3391 :
3392 :
3393 :
3394 :
3395 :
3396 :
3397 :
3398 :
3399 :
3400 :
3401 :
3402 :
3403 :
3404 :
3405 :
3406 :
3407 :
3408 :
3409 :
3410 :
3411 :
3412 :
3413 :
3414 :
3415 :
3416 :
3417 :
3418 :
3419 :
3420 :
3421 :
3422 :
3423 :
3424 :
3425 :
3426 :
3427 :
3428 :
3429 :
3430 :
3431 :
3432 :
3433 :
3434 :
3435 :
3436 :
3437 :
3438 :
3439 :

DRIVE IDENTIFICATION ROUTINES

```

exitloop;
end;

end;

!+
Test to see if this sbe was already in the table
by testing the flag sbe_exist. If it did not exist then
enter this SBE into the table.

NOTE:
Soft errors are not counted toward the Prom Maintenance
call out.

-
if not .SBE_EXIST                               !Was this sbe found in the table
then
begin                                           !It was not found in the table so up the pm count

!+
This sbe was not found in the table so
load this failing sbe into the table
at the bottom of the list.

-
SBE_LOG [.SBES_COUNT, BITS_SBE] = .BIT_NUM; !Load the failing bit
SBE_LOG [.SBES_COUNT, BNKS_SBE] = .BANK;    !Load the failing bank
SBE_LOG [.SBES_COUNT, BRDS_SBE] = .BOARD;   !Load the failing board
SBE_LOG [.SBES_COUNT, UNITS_SBE] = .LUN;    !Load the failing unit
SBE_LOG [.SBES_COUNT, SUMS_SBE] = 1;        !Indicate this is the first one
SBES_COUNT = .SBES_COUNT + 1;               !Up the count of unique sbe's detected
end;

end;

!+
VER CZMLBB THIS CODE WAS COMMENTED OUT AND REPLACED BY THE
ABOVE CODE.

!+
if (((.ARR_TYP eql 1) and (.SOFTS [.LUN, .ARRAY, 0, 16, 0] eql S64K_LIMIT)) or ((.ARR_TYP eql 0) and (
.SOFTS [.LUN, .ARRAY, 0, 16, 0] eql S16K_LIMIT)))
then
begin
SAYWHO (.LUN);
PRINTB (FMT13, .ARRAY, MSG2);
!'ARRAY XX --> RUN ML11 PROM MAINTENANCE PROGRAM'
end;

return;
end;

```

Address	Hex	Hex	Hex	Instruction	Comment	Address
3444						
3445						
3446						
3447						
3448						
3452	040104					
3453	040104	004167	145224			
3454	040110	016605	000020			
3455	040114	010500				
3456	040116	006300				
3457	040120	006300				
3458	040122	006300				
3459	040124	006300				
3460	040126	066600	000016			
3461	040132	006300				
3462	040134	005260	032714			
3463	040140	016701	152520			
3464	040144	020127	000177			
3465	040150	002150				
3466	040152	005003				
3467	040154	005000				
3468	040156	000463				
3469	040160	010004				
3470	040162	006304				
3471	040164	006304				
3472	040166	012702	011264			
3473	040172	060402				
3474	040174	016746	152466			
3475	040200	011246				
3476	040202	006216				
3477	040204	006216				
3478	040206	006216				
3479	040210	006216				
3480	040212	006216				
3481	040214	006216				
3482	040216	042716	177600			
3483	040222	022626				
3484	040224	001037				
3485	040226	016746	174112			
3486	040232	111246				
3487	040234	042716	177774			
3488	040240	022626				
3489	040242	001030				
3490	040244	016746	174072			
3491	040250	111246				
3492	040252	006216				
3493	040254	006216				
3494	040256	042716	177760			
3495	040262	022626				
3496	040264	001017				
3497	040266	010546				
3498	040270	011246				

```

:MLX4
:
DRIVE IDENTIFICATION ROUTINES

UP.SOFT.COUNT:
UP.SOFT.COUNT DRIVE IDENTIFICATION ROUTINES
JSR R1,$SAVE5
MOV 20(SP),R5
MOV R5,R0
ASL R0
ASL R0
ASL R0
ASL R0
ADD 16(SP),R0
ASL R0
INC SOFTS(R0)
MOV SBES.COUNT,R1
CMP R1,#177
BGE 5$
CLR R3
CLR R0
BR 3$
1$: MOV R0,R4
ASL R4
ASL R4
MOV #SBE.LOG,R2
ADD R4,R2
MOV BIT.NUM,-(SP)
MOV (R2),-(SP)
ASR (SP)
ASR (SP)
ASR (SP)
ASR (SP)
ASR (SP)
ASR (SP)
ASR (SP)
BIC #177600,(SP)
CMP (SP)+,(SP)+
BNE 2$
MOV BANK,-(SP)
MOVB (R2),-(SP)
BIC #177774,(SP)
CMP (SP)+,(SP)+
BNE 2$
MOV BOARD,-(SP)
MOVB (R2),-(SP)
ASR (SP)
ASR (SP)
BIC #177760,(SP)
CMP (SP)+,(SP)+
BNE 2$
MOV R5,-(SP)
MOV (R2),-(SP)

```

2945
 2962

 2976

 2979
 2986

 2989

 2990

 2991

 2992

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

Address	OpCode	Operand1	Operand2	Comment	Label
3500				:MLX4	
3501				:	
3502					
3503	040272	006116		ROL (SP)	
3504	040274	006116		ROL (SP)	
3505	040276	006116		ROL (SP)	
3506	040300	006116		ROL (SP)	
3507	040302	042716	177770	BIC #177770,(SP)	
3508	040306	022626		CMP (SP)+,(SP)+	
3509	040310	001005		BNE 2\$	
3510	040312	005264	011266	INC SBE.LOG+2(R4)	
3511	040316	012703	000001	MCV #1,R3	: *SBE.EXIST 2995
3512	040322	000403		BR 4\$: 2996
3513	040324	005200		2\$: INC R0	: INDEX 2997
3514	040326	020001		3\$: CMP R0,R1	: INDEX,* 2986
3515	040330	003713		BLE 1\$	
3516	040332	006003		4\$: ROR R3	: SBE.EXIST 3012
3517	040334	103456		BLO 5\$	
3518	040336	006301		ASL R1	: 3022
3519	040340	006301		ASL R1	
3520	040342	012700	011264	MOV #SBE.LOG,R0	
3521	040346	060100		ADD R1,R0	
3522	040350	016704	152312	MOV BIT.NUM,R4	
3523	040354	000304		SWAB R4	
3524	040356	106004		RORB R4	
3525	040360	006004		ROR R4	
3526	040362	006004		ROR R4	
3527	040364	042704	160077	BIC #160077,R4	
3528	040370	042710	017700	BIC #17700,(R0)	
3529	040374	050410		BIS R4,(R0)	
3530	040376	016704	173742	MOV BANK,R4	
3531	040402	042704	177774	BIC #177774,R4	: 3023
3532	040406	142710	000003	BICB #3,(R0)	
3533	040412	150410		BISB R4,(R0)	
3534	040414	016704	173722	MOV BOARD,R4	: 3024
3535	040420	006304		ASL R4	
3536	040422	006304		ASL R4	
3537	040424	042704	177703	BIC #177703,R4	
3538	040430	142710	000074	BICB #74,(R0)	
3539	040434	150410		BISB R4,(R0)	
3540	040436	006005		ROR R5	: 3025
3541	040440	006005		ROR R5	
3542	040442	006005		ROR R5	
3543	040444	006005		ROR R5	
3544	040446	042705	017777	BIC #17777,R5	
3545	040452	042710	160000	BIC #160000,(R0)	
3546	040456	050510		BIS R5,(R0)	
3547	040460	012761	000001 011266	MOV #1,SBE.LOG+2(R1)	
3548	040466	005267	152172	INC SBE\$.COUNT	: 3026
3549	040472	000207		5\$: RTS PC	: 3027
3550					: 2945
3551				: Routine Size: 124 words	
3552				: Maximum stack depth per invocation: 8 words	
3560					
3561					

```

3563 :MLX4
3564 :
3565 :
3566 : 3046 Zsbttl 'INITIALIZATION CODE'
3567 : 3047 BGNINIT;
3568 : 3048 !* 1 *
3569 : 3049 INITIALIZATION CODE IS EXECUTED AT THE BEGINNING OF EACH
3570 : 3050 PASS, WHEN POWER DOWN/POWER UP HAS OCCURRED, OR WHEN THE
3571 : 3051 OPERATOR HAS ISSUED A START, RESTART OR CONTINUE COMMAND.
3572 : 3052
3573 : 3053 DURING INITIALIZATION, THE 'GPHARD' MACRO IS USED TO GET
3574 : 3054 P-TABLE INFORMATION FOR THE LOGICAL UNIT UNDER TEST. THE
3575 : 3055 NUMBER OF UNITS AVAILABLE FOR TESTING IS CONTAINED IN A
3576 : 3056 HEADER LOCATION ('LSUNIT').
3577 : 3057
3578 : 3058 THE CODE WITHIN THE INITIALIZATION SECTION IS DIVIDED
3579 : 3059 INTO THREE CATEGORIES:
3580 : 3060 1) ONCE-ONLY CODE WHICH IS EXECUTED
3581 : 3061 ONLY ON THE VERY FIRST PASS (I.E.,
3582 : 3062 WHEN THE OPERATOR HAS JUST TYPED
3583 : 3063 IN THE 'START' COMMAND;
3584 : 3064 2) CODE WHICH SHOULD NOT BE EXECUTED
3585 : 3065 ON THE FIRST PASS, BUT WHICH IS
3586 : 3066 TO BE RUN ON EVERY SUBSEQUENT PASS;
3587 : 3067 3) COMMON CODE WHICH IS TO BE EXECUTED
3588 : 3068 ON EVERY PASS (INCLUDING THE FIRST).
3589 : 3069
3590 : 3070 local
3591 : 3071 PLOC;
3592 : 3072 if ((READEF (EF_START)) or (READEF (EF_RESTART)))
3593 : 3073 then
3594 : 3074 !THIS IS CATEGORY 1 CODE
3595 : 3075 !* 2 *
3596 : 3076 begin
3597 : 3077 QUICK = 1;
3598 : 3078 CLRTBLS ();
3599 : 3079
3600 : 3080 incr LUN from 0 to (.LSUNIT - 1) do
3601 : 3081 begin
3602 : 3082 L$LUN = .LUN;
3603 : 3083 !* 3 *
3604 : 3084 if GPHARD (.LUN, PLOC) neq 0
3605 : 3085 then
3606 : 3086 begin
3607 : 3087 !* 4 *
3608 : 3088 P$TABLE_ADDR [.LUN] = .PLOC;
3609 : 3089 if .NUM_DRIVES eql 0 then INIT_ADDRESSES (.PLOC);
3610 : 3090 NUM_DRIVES = .NUM_DRIVES + 1;
3611 : 3091 DRIVE_STATUS [.LUN] = ACTIVE;
3612 : 3092 CONFIG (.LUN),
3613 : 3093 end
3614 : 3094 !* 4 *
3615 : 3095 else
3616 : 3096 DRIVE_STATUS [.LUN] = INACTIVE;
3617 : 3097 end;
3617 : 3097 !* 3 *
    
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (13)

```

3619 :MLX4
3620 :      INITIALIZATION CODE
3621 :
3622 :      3098      end
3623 :      3099      else
3624 :      3100      QUICK = 0;
3625 :      3101
3626 :      3102      !CATEGORY 3 CODE WOULD GO HERE, BUT THERE IS NONE.
3627 :      3103      ENDINIT;
3631 :
3632 :
3633 :
3634 :
3635 :
3636 :
3637 :
3638 :
3639 :
3640 :
3641 :
3642 :
3643 :
3644 :
3645 :
3646 :
3647 :
3648 :
3649 :
3650 :
3651 :
3652 :
3653 :
3654 :
3655 :
3656 :
3657 :
3658 :
3659 :
3660 :
3661 :
3662 :
3663 :
3664 :
3665 :
3666 :
3667 :
3668 :
3669 :
3670 :
3671 :
3672 :
3673 :
    
```

```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (13)
! * 2 *
! THIS IS CATEGORY 2 CODE
! * 1 *
    
```

```

3636 040474 004167 144614          LINIT: .SBTTL LINIT INITIALIZATION CODE
3637 040500 012700 000040          JSR      R1,$SAVE4
3638 040504 104447                   MOV      #40,R0
3639 040506 103404                   TRAP    47
3640 040510 012700 000037          BCS     1$
3641 040514 104447                   MOV      #37,R0
3642 040516 103076                   TRAP    47
3643 040520 012767 000001 172146 1$: BHIS    7$
3644 040526 004767 174022          MOV      #1,QUICK
3645 040532 016704 141254          JSR      PC,CLRTBLS
3646 040536 005003                   MOV      L$UNIT,R4
3647 040540 000462                   CLR     R3
3648 040542 010367 141326          BR      6$
3649 040546 010302                   MOV      R3,L$LUN
3650 040550 006202                   MOV      R3,R2
3651 040552 006202                   ASR     R2
3652 040554 006202                   ASR     R2
3653 040556 062702 034442          ASR     R2
3654 040562 010300                   ADD     #DRIVE.STATUS,R2
3655 040564 104442                   MOV      R3,R0
3656 040566 010001                   TRAP    42
3657 040570 001432                   MOV      R0,R1
3658 040572 010300                   BEQ     4$
3659 040574 006300                   MOV      R3,R0
3660 040576 010160 034422          ASL     R0
3661 040602 005767 173650          MOV      R1,PTABLE.ADDR(R0)
3662 040606 001004                   TST     NUM.DRIVES
3663 040610 010146                   BNE     3$
3664 040612 004767 174370          MOV      R1,-(SP)
3665 040616 005726                   JSR      PC,INIT.ADDRESSES
3666 040620 005267 173632          TST     (SP)+
3667 040624 010246                   INC     NUM.DRIVES
3668 040626 010346                   MOV      R2,-(SP)
3669 040630 042716 177770          MOV      R3,-(SP)
3670 040634 012746 000001          BIC     #177770,(SP)
3671 040640 011646                   MOV      #1,-(SP)
3672 040642 004767 143746          MOV      (SP),-(SP)
3673 040646 010316                   JSR      PC,BL$PU2
3674 :                               MOV      R3,(SP)
    
```

```

3045
3072
3075
3076
3078
3080
3090
3082
3085
3087
3089
3090
3091
    
```

3675
 3676
 3677
 3678 040650 004767 175126
 3679 040654 000411
 3680 040656 010246
 3681 040660 010346
 3682 040662 042716 177770
 3683 040666 012746 000001
 3684 040672 005046
 3685 040674 004767 143714
 3686 040700 062706 000010
 3687 040704 005203
 3688 040706 020304
 3689 040710 002714
 3690 040712 000207
 3691 040714 005067 171754
 3692 040720 000207
 3693
 3694
 3695
 3700
 3701
 3705
 3706
 3710 040722 004767 177546
 3711 040726 104411
 3712 040730 000207
 3713
 3714
 3715
 3720
 3721

```

:MLX4
:
INITIALIZATION CODE
:
:
:
4$: JSR PC,CONFIG
BR 5$
MOV R2,-(SP)
MOV R3,-(SP)
BIC #177770,(SP)
MOV #1,-(SP)
CLR -(SP)
JSR PC,BL$PU2
5$: ADD #10,SP
INC R3
6$: CMP R3,R4
BLT 2$
RTS PC
7$: CLR QUICK
RTS PC

```

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

: Routine Size: 75 words
 : Maximum stack depth per invocation: 9 words

```

.SBTTL L$INIT INITIALIZATION CODE
L$INIT::JSR PC,LINIT
TRAP 11
RTS PC

```

: Routine Size: 4 words
 : Maximum stack depth per invocation: 0 words

3082
 3094
 3079
 3078
 3072
 3100
 3045
 3100

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (14)

```

3723 :MLX4
3724 :
3725 :
3726 : 3104 %sbttl 'GENERATOR FOR OPTION 1'
3727 : 3105 routine GEN1 (SECTOR, COMP_FLAG) : novalue =
3728 : 3106 begin
3729 : 3107
3730 : 3108 !* 1 *
3731 : 3109 !++
3732 : 3110 ROUTINE: GEN1(SECTOR,COMP_FLAG)
3733 : 3111 PURPOSE: TO GENERATE THE ENTIRE 4K-WORD WRITE BUFFER FOR OPTION 1.
3734 : 3112 THE GENERATION IS IN 16 GROUPS OF 256 WORDS (THE SIZE
3735 : 3113 OF 1 SECTOR). EACH GROUP OF 256 WORDS RECEIVES THE
3736 : 3114 SECTOR ADDRESS WHERE THE WORDS WILL BE TRANSFERRED.
3737 : 3115
3738 : 3116 ARGUMENTS: (1) SECTOR - CURRENT SECTOR NUMBER.
3739 : 3117
3740 : 3118 (2) COMP_FLAG - AN INDICATOR WHICH IS USED TO DECIDE
3741 : 3119 WHETHER THE LOCATION IN THE WRITE BUFFER
3742 : 3120 SHOULD BE COMPLEMENTED.
3743 : 3121 !--
3744 : 3122
3745 : 3123 local
3746 : 3124 OFFSET;
3747 : 3125
3748 : 3126 OFFSET = 0;
3749 : 3127
3750 : 3128 if .COMP_FLAG
3751 : 3129 then
3752 : 3130 !GENERATE COMPLEMENT DATA
3753 : 3131 incru SECT from (.SECTOR) to ((.SECTOR) + 15) do
3754 : 3132 begin
3755 : 3133 BREAK;
3756 : 3134
3757 : 3135 incru COUNT from 1 to 256 do
3758 : 3136 begin
3759 : 3137 (WBUFF + (.OFFSET)) = not (.SECT); !* 2A * !COMPLEMENT DATA
3760 : 3138 OFFSET = .OFFSET + 2;
3761 : 3139 end; !* 2A *
3762 : 3140
3763 : 3141 end
3764 : 3142
3765 : 3143 else
3766 : 3144 !GENERATE REGULAR DATA
3767 : 3145 incru SECT from (.SECTOR) to ((.SECTOR) + 15) do
3768 : 3146 begin
3769 : 3147 BREAK;
3770 : 3148
3771 : 3149 incru COUNT from 1 to 256 do
3772 : 3150 begin
3773 : 3151 (WBUFF + (.OFFSET)) = (.SECT); !* 2B * !REGULAR DATA
3774 : 3152 OFFSET = .OFFSET + 2;
3775 : 3153 end; !* 2B *
3776 : 3154
3777 : 3155 end;
  
```

3779 :MLX4
 3780 :
 3781 :
 3782 : 3156
 3783 : 3157
 3784 : 3158
 3788 :
 3789 :
 3793 040732 004167 144356
 3794 040736 005002
 3795 040740 016601 000016
 3796 040744 010104
 3797 040746 062704 000017
 3798 040752 032766 000001 000014
 3799 040760 001437
 3800 040762 010103
 3801 040764 000416
 3802 040766 104422
 3803 040770 010301
 3804 040772 005101
 3805 040774 012700 000001
 3806 041000 010162 012670
 3807 041004 062702 000002
 3808 041010 005200
 3809 041012 020027 000400
 3810 041016 101770
 3811 041020 005203
 3812 041022 020304
 3813 041024 101760
 3814 041026 000207
 3815 041030 104422
 3816 041032 012700 000001
 3817 041036 010162 012670
 3818 041042 062702 000002
 3819 041046 005200
 3820 041050 020027 000400
 3821 041054 101770
 3822 041056 005201
 3823 041060 020104
 3824 041062 101762
 3825 041064 000207
 3826 :
 3827 :
 3828 :

GENERATOR FOR OPTION 1

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (14)

return;
 end;

!* 1 *

Label	Instruction	Address	Comment	Address
GEN1:	.SBTTL	GEN1 GENERATOR FOR OPTION 1		
	JSR	R1,%SAVE4		3105
	CLR	R2	: OFFSET	3126
	MOV	16(SP),R1	: SECTOR,*	3131
	MOV	R1,R4		
	ADD	#17,R4		
	BIT	#1,14(SP)	: *,COMP.FLAG	3128
	BEQ	6\$		
	MOV	R1,R3	: *,SECT	3131
	BR	3\$		
1\$:	TRAP	22		3132
	MOV	R3,R1	: SECT,*	3137
	COM	R1		
	MOV	#1,R0	: *,COUNT	3135
2\$:	MOV	R1,WBUFF(R2)	: *,*(OFFSET)	3137
	ADD	#2,R2	: *,OFFSET	3138
	INC	R0	: COUNT	3135
	CMP	R0,#400	: COUNT,*	
	BLOS	2\$		
	INC	R3	: SECT	3131
3\$:	CMP	R3,R4	: SECT,*	
	BLOS	1\$		
	RTS	PC		3128
4\$:	TRAP	22		3146
	MOV	#1,R0	: *,COUNT	3149
5\$:	MOV	R1,WBUFF(R2)	: SECT,*(OFFSET)	3151
	ADD	#2,R2	: *,OFFSET	3152
	INC	R0	: COUNT	3149
	CMP	R0,#400	: COUNT,*	
	BLOS	5\$		
	INC	R1	: SECT	3145
6\$:	CMP	R1,R4	: SECT,*	
	BLOS	4\$		
	RTS	PC		3105

: Routine Size: 46 words
 : Maximum stack depth per invocation: 5 words

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (15)

3834 .MLX4
 3835
 3836
 3837
 3838
 3839
 3840
 3841
 3842
 3843
 3844
 3845
 3846
 3847
 3848
 3849
 3850
 3851
 3852
 3853
 3854
 3855
 3856
 3857
 3858
 3859
 3860
 3861
 3865
 3866
 3870 041066 005467 171604
 3871 041072 005767 171600
 3872 041076 002402
 3873 041100 005267 171572
 3874 041104 000207
 3875
 3876
 3877
 3882
 3883

PATTERN NUMBER SELECTION

3159 %sbttl 'PATTERN NUMBER SELECTION'
 3160 routine SELPAT : novalue =
 3161 begin

3162
 3163 |++

ROUTINE: SELPAT

3164
 3165 | PURPOSE: TO SELECT THE NEXT PATTERN NUMBER IN OPTION 2.
 3166

3167 THIS ROUTINE AUTOMATICALLY COMPLEMENTS THE CURRENT
 3168 PATTERN NUMBER AND EXAMINES THE SIGN OF THE RESULT.
 3169 IF THE RESULT IS NEGATIVE, THEN IT IS TAKEN TO BE
 3170 THE PATTERN NUMBER OF A COMPLEMENT PATTERN AND A
 3171 'RETURN' IS EXECUTED. IF, HOWEVER, THE RESULT IS
 3172 POSITIVE, THEN AN ENTIRELY NEW PATTERN NUMBER IS
 3173 REQUIRED. THE NEW PATTERN NUMBER IS OBTAINED BY
 3174 INCREMENTING THE OLD.
 3175
 3176 |--

3177
 3178 PATTERN = -(.PATTERN);

3179
 3180 if .PATTERN geq 0 then PATTERN = .PATTERN + 1;

3181
 3182 return;
 3183 end;

3178 .SBTTL SELPAT PATTERN NUMBER SELECTION
 3180 SELPAT: NEG PATTERN :
 TST PATTERN :
 BLT 1\$:
 3182 1\$: INC PATTERN :
 RTS PC :

: Routine Size: 8 words
 : Maximum stack depth per invocation: 0 words

3178
 3180
 3160

3885 :MLX4
3886 :
3887 :
3888 :
3889 :
3890 :
3891 :
3892 :
3893 :
3894 :
3895 :
3896 :
3897 :
3898 :
3899 :
3900 :
3901 :
3902 :
3903 :
3904 :
3905 :
3906 :
3907 :
3908 :
3909 :
3910 :
3911 :
3912 :
3913 :
3914 :
3915 :
3916 :
3917 :
3918 :
3919 :
3920 :
3921 :
3922 :
3923 :
3924 :
3925 :
3926 :
3927 :
3928 :
3929 :
3930 :
3931 :
3932 :
3933 :
3934 :
3935 :
3936 :
3937 :
3938 :
3939 :
3940 :MLX4
3941 :

USING THE PATTERN TABLE

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (16)

%sbttl 'USING THE PATTERN TABLE'
routine GETCNTS (PATTERN) =
begin

!++
ROUTINE: GETCNTS(PATTERN)
PURPOSE: TO POINT TO THE APPROPRIATE BLOCK OF THE PATTERN
TABLE AND GRAB THE VALUES WHICH ARE REQUIRED FOR THE
PATTERN GENERATOR FOR OPTIONS 2 AND 4.
ARGUMENT: PATTERN = THE CURRENT PATTERN NUMBER.
RESULTS: (1) 'VALUE' RECEIVES THE VALUE WHICH IS RETURNED FOR
THE SUBROUTINE. IT IS THE 4-BIT BINARY AMOUNT WHICH
WILL BE USED AS THE CONTENTS OF A NIBBLE OF COMPLEMENT
DATA.
(2) 'DATA_COUNT' RECEIVES THE NUMBER OF NIBBLES OF DATA.
(3) 'COMP COUNT' RECEIVES THE NUMBER OF NIBBLES OF
COMPLEMENT DATA.
!--

local
PATNUM,
VALUE;

selectone .PATTERN of
set

[1 to 5] :
begin
PATNUM = .PATTERN - 1;
VALUE = %b'1010';
end;

[-5 to -1] :
begin
PATNUM = -(.PATTERN) - 1;
VALUE = %b'0101';
end;

[5 to 10] :
begin
PATNUM = .PATTERN - 6;
VALUE = %b'1111';
end;

[-10 to -6] :
begin
PATNUM = -(.PATTERN) - 6;

USING THE PATTERN TABLE

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (16)

SELPAT PATTERN NUMBER SELECTION

3942
 3943 : 3236
 3944 : 3237
 3945 : 3238
 3946 : 3239
 3947 : 3240
 3948 : 3241
 3949 : 3242
 3950 : 3243
 3954
 3955

```

VALUE = %b'0000';
end;
res;
DATA_COUNT = .PATTBL [.PATNUM, COUNT1];
COMP_COUNT = .PATTBL [.PATNUM, COUNT2];
return .VALUE;
end;
    
```

Address	OpCode	Operand 1	Operand 2	Operand 3	Operand 4	Comment	Address
3959	041106	004167	144150				
3960	041112	016600	000010				
3961	041116	003410					
3962	041120	020027	000005				
3963	041124	003005					
3964	041126	010001					
3965	041130	005301					
3966	041132	012702	000012				
3967	041136	000441					
3968	041140	020027	177773	1\$:			
3969	041144	002410					
3970	041146	005700					
3971	041150	002006					
3972	041152	012701	177777				
3973	041156	160001					
3974	041160	012702	000005				
3975	041164	000426					
3976	041166	020027	000006	2\$:			
3977	041172	002411					
3978	041174	020027	000012				
3979	041200	003006					
3980	041202	010001					
3981	041204	162701	000006				
3982	041210	012702	000017				
3983	041214	000412					
3984	041216	020027	177766	3\$:			
3985	041222	002407					
3986	041224	020027	177772				
3987	041230	003004					
3988	041232	012701	177772				
3989	041236	160001					
3990	041240	005002					
3991	041242	006301		4\$:			
3992	041244	006301					
3993	041246	016167	034520	171424			
3994	041254	016167	034522	171420			
3995				:MLX4			
3996				:			
3997				:	USING THE PATTERN TABLE		
3998	041262	010200					
3999	041264	000207					
4000							
4001							
4002							
4007							
4008							

```

; Routine Size: 56 words
; Maximum stack depth per invocation: 3 words
    
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

3185
 3212
 3217
 3218
 3212
 3223
 3224
 3212
 3229
 3230
 3212
 3235
 3236
 3240
 3241
 TOPS
 PA:<
 3186
 3185

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (17)

4010 :MLX4
 4011 :
 4012 :
 4013 :
 4014 :
 4015 :
 4016 :
 4017 :
 4018 :
 4019 :
 4020 :
 4021 :
 4022 :
 4023 :
 4024 :
 4025 :
 4026 :
 4027 :
 4028 :
 4029 :
 4030 :
 4031 :
 4032 :
 4033 :
 4034 :
 4035 :
 4036 :
 4037 :
 4038 :
 4039 :
 4040 :
 4041 :
 4042 :
 4043 :
 4044 :
 4045 :
 4046 :
 4047 :
 4048 :
 4049 :
 4050 :
 4051 :
 4052 :
 4053 :
 4054 :
 4055 :
 4056 :
 4057 :
 4058 :
 4059 :
 4060 :
 4061 :
 4062 :
 4063 :
 4064 :

```

NIBBLE GENERATOR
Zsbttl 'NIBBLE GENERATOR'
routine FILLER (BUFFER, WRDCNT, VALUE) : novalue =
begin
!* 1 *
!++
ROUTINE: FILLER(BUFFER,WRDCNT,VALUE)
PURPOSE: TO LOAD A CHOSEN WRITE BUFFER, ONE NIBBLE AT A TIME, WITH A
PARTICULAR PATTERN, FOR A SPECIFIED NUMBER OF 16-BIT WORDS.
THIS ROUTINE IS THE HEART OF THE GENERATOR FOR OPTIONS 2 AND 4.
THE 'FILLER' ROUTINE IS A LOOP WHICH WILL ALTERNATE BETWEEN
THE TWO COUNTS AND FILL THE APPROPRIATE NUMBER OF NIBBLES OF
THE CHOSEN BUFFER WITH THE CONTENTS OF 'VALUE'. EVERY TIME
A COUNT IS EXHAUSTED, THE OTHER COUNT IS STARTED UP AGAIN,
AND EACH TIME A NEW COUNT IS BEGUN, 'VALUE' IS COMPLEMENTED.
NOTE THAT THE FIRST COUNT THAT WILL BE USED WILL ALWAYS BE
'DATA_COUNT', SO THAT THE BUFFER WILL BE REPETITIONS OF:
DATA,_COMP, DATA, COMP ...
ARGUMENTS: (1) BUFFER = THE STARTING ADDRESS OF THE CHOSEN WRITE BUFFER.
(2) WRDCNT = THE NUMBER OF WORDS OF PATTERN TO BE GENERATED.
(3) VALUE = NIBBLE OF DATA TO BE PLACED IN THE WRITE BUFFER
--
local
NIBBLE,
OFFSET,
FLAG,
THE_COUNT;
FLAG = 0;
OFFSET = 0;
NIBBLE = 0;
while 1 do
begin
!* 2 *
FLAG = not .FLAG; !FLIP THE FLAG
VALUE = not .VALUE; !AND THE DATA
if .FLAG eql 0 !CHOOSE A COUNT
then
THE_COUNT = .COMP_COUNT
else
THE_COUNT = .DATA_COUNT;
decr COUNT from .THE_COUNT to 1 do !EXHAUST THE COUNT
begin
!* 3 *
(.BUFFER + (.OFFSET))<.NIBBLE, 4, 0> = .VALUE; !LOAD THE NIBBLE
NIBBLE = (((.NIBBLE) + 4) mod 16); !CHANGE NIBBLE POINTER

```

```

4066 :MLX4
4067 :
4068 :
4069 : 3296
4070 : 3297
4071 : 3298
4072 : 3299
4073 : 3300
4074 : 3301
4075 : 3302
4076 : 3303
4077 : 3304
4078 : 3305
4079 : 3306
4080 : 3307
4081 : 3308
4082 : 3309
4083 : 3310
4084 : 3311
4085 : 3312
4089 :
4090 :

      NIBBLE GENERATOR

      if .NIBBLE eql 0
      then
      begin
      BREAK;
      OFFSET = .OFFSET + 2;
      WRDCNT = .WRDCNT - 1;

      if .WRDCNT eql 0 then return;
      end;
      end;
      end;
      end;
  
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (17)

4094	041266	004167	144042	FILLER:	.SBTTL JSR	FILLER NIBBLE GENERATOR		
4095	041272	005001			CLR	R1,\$SAVE5	:	3245
4096	041274	005005			CLR	R1	:	3277
4097	041276	005002			CLR	R5	:	3278
4098	041300	005101		1\$:	COM	R2	:	3279
4099	041302	005166	000016		COM	R1	:	3283
4100	041306	005701			COM	16(SP)	:	3284
4101	041310	001003			TST	R1	:	3286
4102	041312	016704	171364		BNE	2\$:	
4103	041316	000402			MOV	COMP.COUNT,R4	:	3288
4104	041320	016704	171354	2\$:	BR	3\$:	3286
4105	041324	010403		3\$:	MOV	DATA.COUNT,R4	:	3290
4106	041326	003764			MOV	R4,R3	:	3297
4107	041330	010546		4\$:	BLE	1\$:	
4108	041332	066616	000024		MOV	R5,-(SP)	:	3294
4109	041336	010246			ADD	24(SP),(SP)	:	
4110	041340	012746	000004		MOV	R2,-(SP)	:	
4111	041344	016646	000024		MOV	#4,-(SP)	:	
4112	041350	004767	143240		MOV	24(SP),-(SP)	:	
4113	041354	010216			JSR	PC,BLSPU2	:	
4114	041356	062716	000004		MOV	R2,(SP)	:	3295
4115	041362	012746	000020		ADD	#4,(SP)	:	
4116	041366	004767	143610		MOV	#20,-(SP)	:	
4117	041372	010002			JSR	PC,BLSMOD	:	
4118	041374	001011			MOV	R0,R2	:	
4119	041376	104422			BNE	6\$:	3297
4120	041400	062705	000002		TRAP	22	:	3299
					ADD	#2,R5	:	3301

```

4122
4123
4124
4125 041404 005366 000032
4126 041410 001003
4127 041412 062706 000012
4128 041416 000207
4129 041420 062706 000012
4130 041424 005303
4131 041426 001340
4132 041430 000723
4133
4134
4135
4140
4141

```

:MLX4
:

NIBBLE GENERATOR

```

DEC 32(SP)
BNE 6$
ADD #12,SP
5$: RTS PC
6$: ADD #12,SP
DEC R3
BNE 4$
BR 1$

```

```

: WRDCNT
:
:
: COUNT
:
:

```

```

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

```

```

TOPS
PA:<
3302
3304
3245
3304
3293
3292
3281

```

```

: Routine Size: 50 words
: Maximum stack depth per invocation: 11 words

```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (18)

```

4143 :MLX4
4144 :
4145 : GENERATOR FOR OPTION 2
4146 : 3313 %sbttl 'GENERATOR FOR OPTION 2'
4147 : 3314 routine GEN2 : novalue =
4148 : 3315 begin
4149 : 3316
4150 : 3317 !++
4151 : 3318 ROUTINE: GEN2
4152 : 3319
4153 : 3320 PURPOSE: TO GENERATE THE ENTIRE WRITE BUFFER (WHICH
4154 : 3321 WILL BE USED IN CONJUNCTION WITH OPTION 2)
4155 : 3322 BASED ON PATTERN TABLE ENTRIES.
4156 : 3323 !--
4157 : 3324
4158 : 3325 local
4159 : 3326 VALUE:
4160 : 3327
4161 : 3328 VALUE = GETCNTS (.PATTERN);
4162 : 3329 FILLER (WBUF, BUFSIZ, .VALUE);
4163 : 3330 return;
4164 : 3331 end;
4168 :
4169 :

```

```

4173 041432 016746 171240 GEN2: .SBTTL GEN2 GENERATOR FOR OPTION 2
4174 041436 004767 177444 : MOV PATTERN, -(SP) : 3328
4175 041442 012716 012670 : JSR PC, GETCNTS :
4176 041446 012746 004000 : MOV #WBUF, (SP) : 3329
4177 041452 010046 : MOV R0, -(SP) : VALUE,*
4178 041454 004767 177606 : JSR PC, FILLER :
4179 041460 062706 000006 : ADD #6, SP :
4180 041464 000207 : RTS PC : 3314
4181 :
4182 : Routine Size: 14 words
4183 : Maximum stack depth per invocation: 3 words
4188 :
4189 :

```

27-Mar-1982 19:24:42 TOPS-20 BLISS-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (19)

```

4191 :MLX4
4192 :
4193 :
4194 : 3332 %sbttl 'GENERATOR FOR OPTION 3'
4195 : 3333 routine GEN3 (COMP_FLAG) : novalue =
4196 : 3334 begin
4197 : 3335
4198 : 3336 !++
4199 : 3337 ROUTINE: GEN3(COMP_FLAG)
4200 : 3338
4201 : 3339 PURPOSE: TO GENERATE THE ENTIRE WRITE BUFFER WHICH WILL BE MADE
4202 : 3340 UP OF WORDS WHICH CONTAIN THE UNIQUE COUNT FROM ONE TO
4203 : 3341 BUFSIZ.
4204 : 3342
4205 : 3343 ARGUMENT: COMP_FLAG - THIS IS AN INDICATOR OF WHETHER OR NOT TO
4206 : 3344 COMPLEMENT EVERY WORD IN THE WRITE BUFFER.
4207 : 3345 !--
4208 : 3346
4209 : 3347 local
4210 : 3348 OFFSET;
4211 : 3349
4212 : 3350 OFFSET = 0;
4213 : 3351
4214 : 3352 if .COMP_FLAG
4215 : 3353 then
4216 : 3354 !GENERATE COMPLEMENT DATA
4217 : 3355 incru COUNT from 1 to BUFSIZ do
4218 : 3356 begin
4219 : 3357 (WBUF + (.OFFSET)) = not (.COUNT); !COMPLEMENT DATA
4220 : 3358 OFFSET = .OFFSET + 2;
4221 : 3359 end
4222 : 3360
4223 : 3361 else
4224 : 3362 !GENERATE REGULAR DATA
4225 : 3363 incru COUNT from 1 to BUFSIZ do
4226 : 3364 begin
4227 : 3365 (WBUF + (.OFFSET)) = (.COUNT); !REGULAR DATA
4228 : 3366 OFFSET = .OFFSET + 2;
4229 : 3367 end;
4230 : 3368
4231 : 3369 return;
4232 : 3370 end;
4233 :
4234 :
4235 :
4236 :
4237 :
    
```

```

4241 041466 010146 GEN3: .SBTTL GEN3 GENERATOR FOR OPTION 3
4242 041470 005001 MOV R1,-(SP)
4243 041472 032766 000001 000004 CLR R1
4244 041500 001415 BIT #1,4(SP)
4245 041502 012700 000001 BEQ 2$
MOV #1,R0
    
```

: 3333
 : OFFSET 3350
 : *.COMP.FLAG 3352
 : *.COUNT 3355


```
4247      ;MLX4
4248      ;
4249      ;
4250 041506 010061 012670      1$:  MOV    R0,WBUFF(R1)      ; COUNT,*(OFFSET)
4251 041512 005161 012670      COM    WBUFF(R1)          ; *(OFFSET) 3357
4252 041516 062701 000002      ADD    #2,R1              ; *(OFFSET)
4253 041522 005200              INC    R0                  ; COUNT      3358
4254 041524 020027 004000      CMP    R0,#4000          ; COUNT      3355
4255 041530 101766              BLOS   1$
4256 041532 000412              BR     4$
4257 041534 012700 000001      2$:  MOV    #1,R0          ; * ,COUNT 3352
4258 041540 010061 012670      3$:  MOV    R0,WBUFF(R1)   ; COUNT,*(OFFSET) 3363
4259 041544 062701 000002      ADD    #2,R1              ; *(OFFSET) 3365
4260 041550 005200              INC    R0                  ; COUNT      3366
4261 041552 020027 004000      CMP    R0,#4000          ; COUNT      3363
4262 041556 101770              BLOS   3$
4263 041560 012601              4$:  MOV    (SP)+,R1       ;
4264 041562 000207              RTS    PC                  ;
4265
4266      ; Routine Size: 31 words
4267      ; Maximum stack depth per invocation: 2 words
4272
4273
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (20)

4275 ;MLX4
 4276 :
 4277 :
 4278 :
 4279 :
 4280 :
 4281 :
 4282 :
 4283 :
 4284 :
 4285 :
 4286 :
 4287 :
 4288 :
 4289 :
 4290 :
 4291 :
 4292 :
 4293 :
 4294 :
 4295 :
 4296 :
 4297 :
 4298 :
 4299 :
 4300 :
 4301 :
 4305 :
 4306 :
 4310 041564 016646 000004
 4311 041570 004767 177312
 4312 041574 016616 000004
 4313 041600 012746 000400
 4314 041604 010046 :
 4315 041606 004767 177454 :
 4316 041612 062706 000006 :
 4317 041616 000207 :
 4318 :
 4319 :
 4320 :
 4325 :
 4326 :

GENERATOR FOR OPTION 4
 %sbttl 'GENERATOR FOR OPTION 4'
 routine GEN4 (MARPAT, BUFFER) : novalue =
 begin
 !++
 ROUTINE: GEN4(MARPAT,BUFFER)
 PURPOSE: THIS IS THE GENERATOR WHICH IS USED FOR OPTION 4, THE
 MARCH TEST. IT BEGINS AT THE START OF THE CHOSEN
 BUFFER AND GENERATES 256 WORDS IN THE EXACT WAY THAT
 OPTION 2 DOES.
 ARGUMENTS: (1) MARPAT - THE MARCH PATTERN NUMBER
 (2) BUFFER - THE STARTING ADDRESS OF THE CHOSEN BUFFER
 !--
 local
 VALUE;
 VALUE = GETCNTS (.MARPAT);
 FILLER (.BUFFER, 256, .VALUE);
 return;
 end;

```

GEN4: .SBTTL GEN4 GENERATOR FOR OPTION 4
      MOV 4(SP),-(SP) ; MARPAT,* 3391
      JSR PC,GETCNTS
      MOV 4(SP),(SP) ; BUFFER,* 3392
      MOV #400,-(SP) ; VALUE,*
      JSR PC,FILLER
      ADD #6,SP
      RTS PC ; 3372
    
```

: Routine Size: 14 words
 : Maximum stack depth per invocation: 3 words

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (21)

```
4328 :MLX4  
4329 :  
4330 :  
4331 : 3395 %sbttl 'GENERATOR FOR OPTION 5'  
4332 : 3396 routine GEN5 : novalue =  
4333 : 3397 begin  
4334 : 3398  
4335 : 3399 !++  
4336 : 3400 ROUTINE: GEN5  
4337 : 3401  
4338 : 3402 PURPOSE: THIS IS THE GENERATOR WHICH IS USED FOR OPTION 5.  
4339 : 3403 IT BEGINS AT THE START OF THE WRITE BUFFER, AND GENERATES  
4340 : 3404 A FULL BUFFER OF RANDOM DATA. THE FIRST 3 WORDS OF THE BUFFER  
4341 : 3405 RECEIVE THE 3 SEEDS WHICH WERE USED IN THE GENERATION.  
4342 : 3406 !--  
4343 : 3407  
4344 : 3408 local  
4345 : 3409 OFFSET:  
4346 : 3410  
4347 : 3411 (WBUF + 0) = .SEED1;  
4348 : 3412 (WBUF + 2) = .SEED2;  
4349 : 3413 (WBUF + 4) = .SEED3;  
4350 : 3414 OFFSET = 6;  
4351 : 3415  
4352 : 3416 incru COUNT from 4 to BUFSIZ do  
4353 : 3417 begin  
4354 : 3418 RN ();  
4355 : 3419 BREAK;  
4356 : 3420 (WBUF + .OFFSET) = .RANDOM;  
4357 : 3421 OFFSET = .OFFSET + 2;  
4358 : 3422 end;  
4359 : 3423  
4360 : 3424 return;  
4361 : 3425 end;  
4365 :
```

!THE FIRST 3 WORDS OF THE
!WRITE BUFFER RECEIVE THE
!3 GENERATING SEEDS.

!NOTE: USING SIGNED VALUES (FULL 16 BITS)

4367										
4371	041620	004167	143436		GEN5:	.SBTTL	GEN5 GENERATOR FOR OPTION 5			
4372	041624	016767	143626	151036		JSR	R1,\$SAVE2	:		3396
4373	041632	016767	143622	151032		MOV	SEED1,WBUFF	:		3411
4374	041640	016767	143616	151026		MOV	SEED2,WBUFF+2	:		3412
4375	041646	012701	000006			MOV	SEED3,WBUFF+4	:		3413
4376	041652	012702	000004			MOV	#6,R1	:	*,OFFSET	3414
4377	041656	004767	143506		1S:	MOV	#4,R2	:	*,COUNT	3416
4378	041662	104422				JSR	PC,RN	:		3418
4379	041664	016761	143574	012670		TRAP	22	:		
4380	041672	062701	000002			MOV	RANDOM,WBUFF(R1)	:	*,*(OFFSET)	3420
4381	041676	005202				ADD	#2,R1	:	*,OFFSET	3421
4382	041700	020227	004000			INC	R2	:	COUNT	3416
4383	041704	101764				CMP	R2,#4000	:	COUNT,*	
4384						BLOS	1S	:		
4385					:MLX4					
4386					:		GENERATOR FOR OPTION 5			
4387	041706	000207				RTS	PC	:		
4388										3396
4389										
4390										
4395										
4396										

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

: Routine Size: 28 words
: Maximum stack depth per invocation: 3 words

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (22)

4398 :MLX4
4399 :
4400 :
4401 : 3426
4402 : 3427
4403 : 3428
4404 : 3429
4405 : 3430
4406 : 3431
4407 : 3432
4408 : 3433
4409 : 3434
4410 : 3435
4411 : 3436
4412 : 3437
4413 : 3438
4414 : 3439
4415 : 3440
4416 : 3441
4417 : 3442
4418 : 3443
4419 : 3444
4420 : 3445
4421 : 3446
4422 : 3447
4423 : 3448
4424 : 3449
4425 : 3450
4426 : 3451
4427 : 3452
4428 : 3453
4429 : 3454
4430 : 3455
4431 : 3456
4432 : 3457
4433 : 3458
4434 : 3459
4435 : 3460
4436 : 3461
4437 : 3462
4438 : 3463
4439 : 3464
4440 : 3465
4441 : 3466
4442 : 3467
4443 : 3468
4444 : 3469
4445 : 3470
4446 : 3471
4447 : 3472
4448 : 3473
4449 : 3474
4450 : 3475
4451 : 3476
4452 : 3477

SYSTEM ERROR DETECTOR

%sbttl 'SYSTEM ERROR DETECTOR'
routine SYSERR (LUN) =
begin

!* 1 *

ROUTINE: SYSERR(LUN)
PURPOSE: (1) TO SCAN FOR SYSTEM ERRORS AFTER A TRANSFER HAS ENDED.
(2) PRINT ERROR MESSAGES IF APPROPRIATE:
A) ERROR MESSAGES DURING RETRIES WILL NOT BE PRINTED.
B) THE OPERATOR HAS THE ABILITY TO INHIBIT THE PRINTING OF DATA ERRORS, BUT NOT SYSTEM ERRORS.
(3) DECIDE ON A VALUE TO RETURN WHICH WILL INDICATE THE RELATIVE SEVERITY OF THE ERROR.

ARGUMENT: LUN = THE CURRENT LOGICAL UNIT NUMBER
[0 TO NUMBER OF DRIVES MINUS 1].

RESULT: VALUE RETURNED FOR THE SUBROUTINE SHOWS TYPE OF ERROR:
0 = NO ERRORS AT ALL
1 = RETRY ALLOWED FOR THESE TYPES OF ERRORS
2 = FATAL CONTROLLER ERROR
3 = FATAL DRIVE ERROR
4 = UNCORRECTABLE DATA ERROR
5 = CORRECTABLE DATA ERROR

FIGURE OUT WHICH VALUE TO RETURN BY THE FOLLOWING SCHEME:
(1) IF THERE IS A CHOICE BETWEEN DATA ERROR AND SYSTEM ERROR,
FIRST CHOOSE THE DATA ERROR.
(2) IF THERE IS A CHOICE BETWEEN FATAL AND NON-FATAL ERROR,
FIRST CHOOSE THE FATAL ERROR.
(3) IF THERE IS A CHOICE BETWEEN CONTROLLER ERROR AND DRIVE ERROR,
FIRST CHOOSE CONTROLLER ERROR.

Label
PURPOSE_2_CODE;

Local
ERR2,
ERR3,
ERR4,
ERR5,
ERR6,
ERR7,
ERR8,

! VER CZMLBB ADDED THIS LOCAL

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (22)

4454 :MLX4
 4455 :
 4456 :
 4457 :
 4458 :
 4459 :
 4460 :
 4461 :
 4462 :
 4463 :
 4464 :
 4465 :
 4466 :
 4467 :
 4468 :
 4469 :
 4470 :
 4471 :
 4472 :
 4473 :
 4474 :
 4475 :
 4476 :
 4477 :
 4478 :
 4479 :
 4480 :
 4481 :
 4482 :
 4483 :
 4484 :
 4485 :
 4486 :
 4487 :
 4488 :
 4489 :
 4490 :
 4491 :
 4492 :
 4493 :
 4494 :
 4495 :
 4496 :
 4497 :
 4498 :
 4499 :
 4500 :
 4501 :
 4502 :
 4503 :
 4504 :
 4505 :
 4506 :
 4507 :
 4508 :

SYSTEM ERROR DETECTOR

ERR9:

ERR2 = INACTIVE;
 ERR3 = INACTIVE;
 ERR4 = INACTIVE;
 ERR5 = INACTIVE;
 ERR6 = INACTIVE;
 ERR7 = INACTIVE;
 ERR8 = INACTIVE;
 ERR9 = INACTIVE;

! VER CZMLBB ADDED THIS LOCAL

! VER CZMLBB
 ! VER CZMLBB

!+
 ! THIS IS THE CODE FOR PURPOSE 1:
 !-

if .SC
 then
 begin

! THERE ARE SOME ERRORS -- FIND OUT WHAT KIND
 ! * 2 *

if ((.NED) or (.NEM) or (.PGE)) then ERR2 = ACTIVE;
 if ((.DLT) or (.PE) or (.MXF) or (.MDPE) or (.MCPE)) then ERR3 = ACTIVE;

! VER ADDED THIS ERR9

if (.MDPE) and (not .SGL) then ERR9 = ACTIVE;

! VER ADDED THIS ERR8

if ((.DLT) or (.PE) or (.MXF) or (.MCPE)) then ERR8 = ACTIVE;
 if ((.WCE) and (.ECCDIS eql 0)) then ERR3 = ACTIVE;
 if ((.UNS) or (.IAE) or (.AOE) or (.RMR) or (.ILR) or (.ILF)) then ERR4 = ACTIVE;
 if ((.OPI) or (.DPAR) or (.CPAR)) then ERR5 = ACTIVE;
 if ((.DCK) or (.crc) or (.SGL)) then ERR7 = ACTIVE;
 if ((.WCE) and (.ECCDIS eql 1)) then ERR7 = ACTIVE;
 if ((.ECH) or (.UNC)) then ERR6 = ACTIVE;

end
 else
 return 0;

! * 2 *
 ! THERE ARE NO ERRORS -- RETURN SUCCESSFULLY
 ! NO ERRORS AT ALL

!+
 ! THIS IS THE CODE FOR PURPOSE 2:

LABEL:
 BEGIN 3

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (22)

```

4510 :MLX4
4511 :
4512 :
4513 : 3530
4514 : 3531
4515 : 3532
4516 : 3533
4517 : 3534
4518 : 3535
4519 : 3536
4520 : 3537
4521 : 3538
4522 : 3539
4523 : 3540
4524 : 3541
4525 : 3542
4526 : 3543
4527 : 3544
4528 : 3545
4529 : 3546
4530 : 3547
4531 : 3548
4532 : 3549
4533 : 3550
4534 : 3551
4535 : 3552
4536 : 3553
4537 : 3554
4538 : 3555
4539 : 3556
4540 : 3557
4541 : 3558
4542 : 3559
4543 : 3560
4544 : 3561
4545 : 3562
4546 : 3563
4547 : 3564
4548 : 3565
4549 : 3566
4550 : 3567
4551 : 3568
4552 : 3569
4553 : 3570
4554 : 3571
4555 : 3572
4556 : 3573
4557 : 3574
4558 : 3575
4559 : 3576
4560 : 3577
4561 : 3578
4562 : 3579
4563 : 3580
4564 : 3581

SYSTEM ERROR DETECTOR
IF RETRYING
THEN LEAVE LABEL (NO PRINTOUTS AT ALL)
ELSE
BEGIN 4
IF ERROR PRINTOUTS ARE ALLOWED
THEN
BEGIN 5A
IDENTIFY THE LOGICAL UNIT
SCAN FOR & PRINT DATA ERRORS
END 5A
ELSE
BEGIN 5B
IF THERE ARE SYSTEM ERRORS TO REPORT
THEN IDENTIFY THE LOGICAL UNIT
ELSE LEAVE LABEL
END 5B
SCAN FOR & PRINT SYSTEM ERRORS
END 4
END 3

PURPOSE_2_CODE :
begin
!* 3 *
if .RETRYING
then
leave PURPOSE_2_CODE
!(NO PRINTOUTS AT ALL)
else
begin
!* 4 *
if .ERR0UT
then
begin
!* 5A *
SAYWHO (.LUN);
PRINTB (SAY1, PHR10);
!'ERROR BITS SET:

if .ERR7
then
begin
if .DCK then PRINTB (FMT15, MLB20);
if .crc then PRINTB (FMT15, MLB22);
if .SGL then PRINTB (FMT15, MLB23);
if ((.WCE) and (.ECCDIS eql 1)) then PRINTB (FMT15, MLB6);
end;
if .ERR6

```

```

4566 :MLX4
4567 :
4568 :
4569 : 3582
4570 : 3583
4571 : 3584
4572 : 3585
4573 : 3586
4574 : 3587
4575 : 3588
4576 : 3589
4577 : 3590
4578 : 3591
4579 : 3592
4580 : 3593
4581 : 3594
4582 : 3595
4583 : 3596
4584 : 3597
4585 : 3598
4586 : 3599
4587 : 3600
4588 : 3601
4589 : 3602
4590 : 3603
4591 : 3604
4592 : 3605
4593 : 3606
4594 : 3607
4595 : 3608
4596 : 3609
4597 : 3610
4598 : 3611
4599 : 3612
4600 : 3613
4601 : 3614
4602 : 3615
4603 : 3616
4604 : 3617
4605 : 3618
4606 : 3619
4607 : 3620
4608 : 3621
4609 : 3622
4610 : 3623
4611 : 3624
4612 : 3625
4613 : 3626
4614 : 3627
4615 : 3628
4616 : 3629
4617 : 3630
4618 : 3631
4619 : 3632
4620 : 3633

SYSTEM ERROR DETECTOR

    then
    begin
        if .ECH then PRINTB (FMT15, MLB21);
        if .UNC then PRINTB (FMT15, MLB24);
    end;
    end
    else
    begin
        !* 5A *
        !* 5B *
        ! VER CZMLBB CHANGED ERR3 TO ERR8
        if ((.ERR2) or (.ERR8) or (.ERR4) or (.ERR5))
        then
        begin
            SAYWHO (.LUN);
            PRINTB (SAY1, PHR10);
            !'ERROR BITS SET:
        end
        else
        ! VER CZMLBB ADDED TEST OF ERR9 HERE
        if .ERR9
        then
        begin
            SAYWHO (.LUN);
            PRINTB (SAY1, PHR10);
            !'ERROR BITS SET:
        end
        else
        begin
            leave PURPOSE_2_CODE;
        end;
    end;
    !* 5B *
    if .ERR2
    then
    begin
        if .NED then PRINTB (FMT15, MLB2);
        if .NEM then PRINTB (FMT15, MLB3);
        if .PGE then PRINTB (FMT15, MLB4);
    end;
    if .ERR3
    then
    
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (22)

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (22)

4622 :MLX4
4623 :
4624 :
4625 :
4626 :
4627 :
4628 :
4629 :
4630 :
4631 :
4632 :
4633 :
4634 :
4635 :
4636 :
4637 :
4638 :
4639 :
4640 :
4641 :
4642 :
4643 :
4644 :
4645 :
4646 :
4647 :
4648 :
4649 :
4650 :
4651 :
4652 :
4653 :
4654 :
4655 :
4656 :
4657 :
4658 :
4659 :
4660 :
4661 :
4662 :
4663 :
4664 :
4665 :
4666 :
4667 :
4668 :
4669 :
4670 :
4671 :
4672 :
4673 :
4674 :
4675 :
4676 :

3634
3635
3636
3637
3638
3639
3640
3641
3642
3643
3644
3645
3646
3647
3648
3649
3650
3651
3652
3653
3654
3655
3656
3657
3658
3659
3660
3661
3662
3663
3664
3665
3666
3667
3668
3669
3670
3671
3672
3673
3674
3675
3676
3677
3678
3679
3680
3681
3682
3683
3684
3685

SYSTEM ERROR DETECTOR

```
begin
if .DLT then PRINTB (FMT15, MLB5);
if ((.WCE) and (.ECCDIS eql 0)) then PRINTB (FMT15, MLB6);
if .PE then PRINTB (FMT15, MLB7);
if .MXF then PRINTB (FMT15, MLB8);
! VER CZMLBB ADDED 'AND NOT .SGL'
if ((.MDPE) and ( not .SGL)) then PRINTB (FMT15, MLB9);
if .MCPE then PRINTB (FMT15, MLB10);
end;
if .ERR4
then
begin
if .UNS then PRINTB (FMT15, MLB11);
if .IAE then PRINTB (FMT15, MLB12);
if .AOE then PRINTB (FMT15, MLB13);
if .RMR then PRINTB (FMT15, MLB14);
if .ILR then PRINTB (FMT15, MLB15);
if .ILF then PRINTB (FMT15, MLB16);
end;
if .ERR5
then
begin
if .OPI then PRINTB (FMT15, MLB17);
if .DPAR then PRINTB (FMT15, MLB18);
if .CPAR then PRINTB (FMT15, MLB19);
end;
end;
end;
```

!* 4 *
!* 3 *

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (22)

```

4678 :MLX4
4679 :
4680 SYSTEM ERROR DETECTOR
4681 :
4682 :+
4683 : THIS IS THE CODE FOR PURPOSE 3:
4684 :-
4685 if .ERR6
4686 then
4687 return 4;
4688
4689 if .ERR7
4690 then
4691 return 5;
4692
4693 if .ERR2
4694 then
4695 return 2;
4696
4697 if .ERR4
4698 then
4699 return 3;
4700
4701 if (.ERR3 or .ERR5)
4702 then
4703 return 1
4704 else
4705 begin
4706
4707 if ((.ERR0UT) and ( not .RETRYING)) then PRINTB (SAY1, PHR11);
4708
4709 !'SC SET BUT NO SYSTEM ERRORS FOUND'
4710 return 1;
4711 end;
4712
4713 end;
4714
4715
4716
4717
4718
4719
4720
4721
4722
4723
4724
4725
4726
4727
4728
4729
4730
4731
4732
4733
4734
4735
4736
4737
4738
4739
4740
    
```

!* 1 *

4722	041710	004167	143420	SYSERR:	.SBTTL	SYSERR SYSTEM ERROR DETECTOR		
4723	041714	005746			JSR	R1,SSAVES	:	3427
4724	041716	005046			TST	-(SP)		
4725	041720	005046			CLR	-(SP)	: ERR2	3480
4726	041722	005001			CLR	-(SP)	: ERR3	3481
4727	041724	005002			CLR	R1	: ERR4	3482
4728	041726	005066	000004		CLR	R2	: ERR5	3483
4729	041732	005003			CLR	4(SP)	: ERR6	3484
4730	041734	005004			CLR	R3	: ERR7	3485
4731	041736	005005			CLR	R4	: ERR8	3486
4732	041740	005777	172402		CLR	R5	: ERR9	3487
4733					TST	@ML.REG	:	3493
4734				:MLX4				27-Mar-1982 19:24:42
4735				:				27-Mar-1982 19:23:44
4736	041744	100402						TOPS
4737	041746	000167	002344		BMI	1\$		PA:<
4738	041752	032777	010000	1\$:	JMP	53\$		
4739	041760	001010	172376		BIT	#10000,@ML.REG+10	:	3497
4740	041762	032777	004000	172366	BNE	2\$		
					BIT	#4000,@ML.REG+10		

4741	041770	001004				BNE	2\$			
4742	041772	032777	002000	172356		BIT	#2000,AML.REG+10			
4743	042000	001403				BEQ	3\$			
4744	042002	012766	000001	000002	2\$:	MOV	#1,2(SP)	:	*.ERR2	
4745	042010	005777	172342		3\$:	TST	AML.REG+10	:		
4746	042014	100420				BMI	4\$			3499
4747	042016	032777	020000	172332		BIT	#2000,AML.REG+10			
4748	042024	001014				BNE	4\$			
4749	042026	032777	001000	172322		BIT	#1000,AML.REG+10			
4750	042034	001010				BNE	4\$			
4751	042036	032777	000400	172312		BIT	#400,AML.REG+10			
4752	042044	001004				BNE	4\$			
4753	042046	032777	020000	172272		BIT	#2000,AML.REG			
4754	042054	001402				BEQ	5\$			
4755	042056	012716	000001		4\$:	MOV	#1,(SP)	:	*.ERR3	
4756	042062	032777	000400	172266	5\$:	BIT	#400,AML.REG+10	:		3503
4757	042070	001406				BEQ	6\$			
4758	042072	032777	040000	172310		BIT	#40000,AML.REG+42			
4759	042100	001002				BNE	6\$			
4760	042102	012705	000001			MOV	#1,R5	:	*.ERR9	
4761	042106	005777	172244		6\$:	TST	AML.REG+10	:		3507
4762	042112	100414				BMI	7\$			
4763	042114	032777	020000	172234		BIT	#2000,AML.REG+10			
4764	042122	001010				BNE	7\$			
4765	042124	032777	001000	172224		BIT	#1000,AML.REG+10			
4766	042132	001004				BNE	7\$			
4767	042134	032777	020000	172204		BIT	#2000,AML.REG			
4768	042142	001402				BEQ	8\$			
4769	042144	012704	000001		7\$:	MOV	#1,R4	:	*.ERR8	
4770	042150	032777	040000	172200	8\$:	BIT	#40000,AML.REG+10	:		3509
4771	042156	001405				BEQ	9\$			
4772	042160	005767	140070			TST	ECCDIS			
4773	042164	001002				BNE	9\$			
4774	042166	012716	000001			MOV	#1,(SP)	:	*.ERR3	
4775	042172	032777	040000	172162	9\$:	BIT	#40000,AML.REG+14	:		3511
4776	042200	001024				BNE	10\$			
4777	042202	032777	002000	172152		BIT	#2000,AML.REG+14			
4778	042210	001020				BNE	10\$			
4779	042212	032777	001000	172142		BIT	#1000,AML.REG+14			
4780	042220	001014				BNE	10\$			
4781	042222	132777	000004	172132		BITB	#4,AML.REG+14			
4782	042230	001010				BNE	10\$			
4783	042232	132777	000002	172122		BITB	#2,AML.REG+14			
4784	042240	001004				BNE	10\$			
4785	042242	132777	000001	172112		BITB	#1,AML.REG+14			
4786	042250	001402				BEQ	11\$			
4787	042252	012701	000001		10\$:	MOV	#1,R1	:	*.ERR4	
4788					:MLX4					
4789					:					
4790					:		SYSTEM ERROR DETECTOR			
4791	042256	032777	020000	172076	11\$:	BIT	#2000,AML.REG+14	:		
4792	042264	001010				BNE	12\$			3513
4793	042266	132777	000040	172066		BITB	#40,AML.REG+14			
4794	042274	001004				BNE	12\$			
4795	042276	132777	000010	172056		BITB	#10,AML.REG+14			
4796	042304	001402				BEQ	13\$			
4797	042306	012702	000001		12\$:	MOV	#1,R2	:	*.ERR5	

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

4798	042312	005777	172044		13\$:	TST	@ML.REG+14	:	
4799	042316	100410				BMI	14\$:	3515
4800	042320	032777	020000	172062		BIT	#20000,@ML.REG+42	:	
4801	042326	001004				BNE	14\$:	
4802	042330	032777	040000	172052		BIT	#40000,@ML.REG+42	:	
4803	042336	001402				BEQ	15\$:	
4804	042340	012703	000001		14\$:	MOV	#1,R3	:	*.ERR7
4805	042344	032777	040000	172004	15\$:	BIT	#40000,@ML.REG+10	:	
4806	042352	001406				BEQ	16\$:	3517
4807	042354	026727	137674	000001		COMP	ECCDIS,#1	:	
4808	042362	001002				BNE	16\$:	
4809	042364	012703	000001			MOV	#1,R3	:	*.ERR7
4810	042370	132777	000100	171764	16\$:	BITB	#100,@ML.REG+14	:	
4811	042376	001003				BNE	17\$:	3519
4812	042400	005777	172004			TST	@ML.REG+42	:	
4813	042404	100003				BPL	18\$:	
4814	042406	012766	000001	000004	17\$:	MOV	#1,4(SP)	:	*.ERR6
4815	042414	032767	000001	171716	18\$:	BIT	#1,RETRYING	:	
4816	042422	001402				BEQ	19\$:	3554
4817	042424	000167	001520			JMP	47\$:	3556
4818	042430	032767	000001	137622	19\$:	BIT	#1,ERROUT	:	
4819	042436	001552				BEQ	25\$:	3560
4820	042440	016646	000024			MOV	24(SP),-(SP)	:	LUN.*
4821	042444	004767	173054			JSR	PC,SAYWHO	:	3563
4822	042450	012716	010120			MOV	#PHR10,(SP)	:	
4823	042454	012746	007072			MOV	#SAY1,-(SP)	:	3564
4824	042460	012746	000002			MOV	#2,-(SP)	:	
4825	042464	010600				MOV	SP,R0	:	SP.*
4826	042466	104414				TRAP	14	:	
4827	042470	032703	000001			BIT	#1,R3	:	*.ERR7
4828	042474	001473				BEQ	23\$:	3567
4829	042476	005777	171660			TST	@ML.REG+14	:	
4830	042502	100012				BPL	20\$:	3571
4831	042504	012746	007550			MOV	#MLB20,-(SP)	:	
4832	042510	012746	007060			MOV	#FMT15,-(SP)	:	
4833	042514	012746	000002			MOV	#2,-(SP)	:	
4834	042520	010600				MOV	SP,R0	:	SP.*
4835	042522	104414				TRAP	14	:	
4836	042524	062706	000006			ADD	#6,SP	:	
4837	042530	032777	020000	171652	20\$:	BIT	#20000,@ML.REG+42	:	
4838	042536	001412				BEQ	21\$:	3573
4839	042540	012746	007560			MOV	#MLB22,-(SP)	:	
4840	042544	012746	007060			MOV	#FMT15,-(SP)	:	
4841	042550	012746	000002			MOV	#2,-(SP)	:	
4842	042554	010600				MOV	SP,R0	:	SP.*
4843								:	
4844					:MLX4			:	
4845					:			:	
4846	042556	104414				TRAP	14	:	
4847	042560	062706	000006			ADD	#6,SP	:	
4848	042564	032777	040000	171616	21\$:	BIT	#40000,@ML.REG+42	:	
4849	042572	001412				BEQ	22\$:	3575
4850	042574	012746	007564			MOV	#MLB23,-(SP)	:	
4851	042600	012746	007060			MOV	#FMT15,-(SP)	:	
4852	042604	012746	000002			MOV	#2,-(SP)	:	
4853	042610	010600				MOV	SP,R0	:	SP.*
4854	042612	104414				TRAP	14	:	

SYSTEM ERROR DETECTOR

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS
 PA:<

4855	042614	062706	000006			ADD	#6,SP			
4856	042620	032777	040000	171530	22\$:	BIT	#40000,@ML.REG+10	:		3577
4857	042626	001416				BEQ	23\$			
4858	042630	026727	137420	000001		CMP	ECCDIS,#1			
4859	042636	001012				BNE	23\$			
4860	042640	012746	007450			MOV	#MLB6,-(SP)			
4861	042644	012746	007060			MOV	#FMT15,-(SP)			
4862	042650	012746	000002			MOV	#2,-(SP)			
4863	042654	010600				MOV	SP,R0	:	SP,*	
4864	042656	104414				TRAP	14			
4865	042660	062706	000006			ADD	#6,SP			
4866	042664	032766	000001	000012	23\$:	BIT	#1,12(SP)	:	*,ERR6	3581
4867	042672	001505				BEQ	29\$			
4868	042674	132777	000100	171460		BITB	#100,@ML.REG+14	:		3585
4869	042702	001412				BEQ	24\$			
4870	042704	012746	007554			MOV	#MLB21,-(SP)			
4871	042710	012746	007060			MOV	#FMT15,-(SP)			
4872	042714	012746	000002			MOV	#2,-(SP)			
4873	042720	010600				MOV	SP,R0	:	SP,*	
4874	042722	104414				TRAP	14			
4875	042724	062706	000006			ADD	#6,SP			
4876	042730	005777	171454		24\$:	TST	@ML.REG+42	:		3587
4877	042734	100064				BPL	29\$			
4878	042736	012746	007570			MOV	#MLB24,-(SP)			
4879	042742	012746	007060			MOV	#FMT15,-(SP)			
4880	042746	012746	000002			MOV	#2,-(SP)			
4881	042752	010600				MOV	SP,R0	:	SP,*	
4882	042754	104414				TRAP	14			
4883	042756	062706	000006			ADD	#6,SP			
4884	042762	000451				BR	29\$:		
4885	042764	032766	000001	000002	25\$:	BIT	#1,2(SP)	:	*,ERR2	3562
4886	042772	001010				BNE	26\$			3596
4887	042774	006004				ROR	R4	:	ERR8	
4888	042776	103406				BLO	26\$			
4889	043000	032701	000001			BIT	#1,R1	:	*,ERR4	
4890	043004	001003				BNE	26\$			
4891	043006	032702	000001			BIT	#1,R2	:	*,ERR5	
4892	043012	001415				BEQ	27\$			
4893	043014	016646	000024		26\$:	MOV	24(SP),-(SP)	:	LUN,*	3599
4894	043020	004767	172500			JSR	PC,SAYWHO			
4895	043024	012716	010120			MOV	#PHR10,(SP)	:		3600
4896	043030	012746	007072			MOV	#SAY1,-(SP)			
4897	043034	012746	000002			MOV	#2,-(SP)			
4898										
4899										
4900										
4901	043040	010600				MOV	SP,R0	:	SP,*	
4902	043042	104414				TRAP	14			
4903	043044	000420				BR	29\$:		
4904	043046	006005			27\$:	ROR	R5	:	ERR9	3598
4905	043050	103402				BLO	28\$			3606
4906	043052	000167	001072			JMP	47\$			
4907	043056	016646	000024		28\$:	MOV	24(SP),-(SP)	:	LUN,*	3609
4908	043062	004767	172436			JSR	PC,SAYWHO			
4909	043066	012716	010120			MOV	#PHR10,(SP)	:		3610
4910	043072	012746	007072			MOV	#SAY1,-(SP)			
4911	043076	012746	000002			MOV	#2,-(SP)			

:MLX4
:

SYSTEM ERROR DETECTOR

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS
 PA:<

4912	043102	010600				MOV	SP,R0	:	SP,*	
4913	043104	104414				TRAP	14	:		
4914	043106	062706	000006		29\$:	ADD	#6,SP	:		
4915	043112	032766	000001	000002		BIT	#1,2(SP)	:	*,ERR2	3608
4916	043120	001452				BEQ	32\$:		3620
4917	043122	032777	010000	171226		BIT	#10000,@ML.REG+10	:		
4918	043130	001412				BEQ	30\$:		3624
4919	043132	012746	007430			MOV	#MLB2,-(SP)			
4920	043136	012746	007060			MOV	#FMT15,-(SP)			
4921	043142	012746	000002			MOV	#2,-(SP)			
4922	043146	010600				MOV	SP,R0	:	SP,*	
4923	043150	104414				TRAP	14	:		
4924	043152	062706	000006			ADD	#6,SP			
4925	043156	032777	004000	171172	30\$:	BIT	#4000,@ML.REG+10	:		
4926	043164	001412				BEQ	31\$:		3626
4927	043166	012746	007434			MOV	#MLB3,-(SP)			
4928	043172	012746	007060			MOV	#FMT15,-(SP)			
4929	043176	012746	000002			MOV	#2,-(SP)			
4930	043202	010600				MOV	SP,R0	:	SP,*	
4931	043204	104414				TRAP	14	:		
4932	043206	062706	000006			ADD	#6,SP			
4933	043212	032777	002000	171136	31\$:	BIT	#2000,@ML.REG+10	:		
4934	043220	001412				BEQ	32\$:		3628
4935	043222	012746	007440			MOV	#MLB4,-(SP)			
4936	043226	012746	007060			MOV	#FMT15,-(SP)			
4937	043232	012746	000002			MOV	#2,-(SP)			
4938	043236	010600				MOV	SP,R0	:	SP,*	
4939	043240	104414				TRAP	14	:		
4940	043242	062706	000006			ADD	#6,SP			
4941	043246	032716	000001		32\$:	BIT	#1,(SP)	:	*,ERR3	
4942	043252	001532				BEQ	38\$:		3632
4943	043254	005777	171076			TST	@ML.REG+10	:		
4944	043260	100012				BPL	33\$:		3636
4945	043262	012746	007444			MOV	#MLB5,-(SP)			
4946	043266	012746	007060			MOV	#FMT15,-(SP)			
4947	043272	012746	000002			MOV	#2,-(SP)			
4948	043276	010600				MOV	SP,R0	:	SP,*	
4949	043300	104414				TRAP	14	:		
4950	043302	062706	000006			ADD	#6,SP			
4951	043306	032777	040000	171042	33\$:	BIT	#40000,@ML.REG+10	:		
4952	043314	001415				BEQ	34\$:		3638
4953										
4954										
4955										
4956	043316	005767	136732			TST	ECCDIS			
4957	043322	001012				BNE	34\$			
4958	043324	012746	007450			MOV	#MLB6,-(SP)			
4959	043330	012746	007060			MOV	#FMT15,-(SP)			
4960	043334	012746	000002			MOV	#2,-(SP)			
4961	043340	010600				MOV	SP,R0	:	SP,*	
4962	043342	104414				TRAP	14	:		
4963	043344	062706	000006			ADD	#6,SP			
4964	043350	032777	020000	171000	34\$:	BIT	#20000,@ML.REG+10	:		
4965	043356	001412				BEQ	35\$:		3640
4966	043360	012746	007454			MOV	#MLB7,-(SP)			
4967	043364	012746	007060			MOV	#FMT15,-(SP)			
4968	043370	012746	000002			MOV	#2,-(SP)			

:MLX4
 :

SYSTEM ERROR DETECTOR

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS
 PA:<

4969	043374	010600				MOV	SP,R0		: SP,*	
4970	043376	104414				TRAP	14			
4971	043400	062706	000006			ADD	#6,SP			
4972	043404	032777	001000	170744	35\$:	BIT	#1000,@ML.REG+10		:	3642
4973	043412	001412				BEQ	36\$			
4974	043414	012746	007460			MOV	#MLB8,-(SP)			
4975	043420	012746	007060			MCV	#FMT15,-(SP)			
4976	043424	012746	000002			MOV	#2,-(SP)			
4977	043430	010600				MOV	SP,R0		: SP,*	
4978	043432	104414				TRAP	14			
4979	043434	062706	000006			ADD	#6,SP			
4980	043440	032777	000400	170710	36\$:	BIT	#400,@ML.REG+10		:	3646
4981	043446	001416				BEQ	37\$			
4982	043450	032777	040000	170732		BIT	#40000,@ML.REG+42			
4983	043456	001012				BNE	37\$			
4984	043460	012746	007464			MOV	#MLB9,-(SP)			
4985	043464	012746	007060			MOV	#FMT15,-(SP)			
4986	043470	012746	000002			MOV	#2,-(SP)			
4987	043474	010600				MOV	SP,R0		: SP,*	
4988	043476	104414				TRAP	14			
4989	043500	062706	000006			ADD	#6,SP			
4990	043504	032777	020000	170634	37\$:	BIT	#20000,@ML.REG		:	3648
4991	043512	001412				BEQ	38\$			
4992	043514	012746	007472			MOV	#MLB10,-(SP)			
4993	043520	012746	007060			MOV	#FMT15,-(SP)			
4994	043524	012746	000002			MOV	#2,-(SP)			
4995	043530	010600				MOV	SP,R0		: SP,*	
4996	043532	104414				TRAP	14			
4997	043534	062706	000006			ADD	#6,SP			
4998	043540	032701	000001		38\$:	BIT	#1,R1		: *,ERR4	3652
4999	043544	001524				BEQ	44\$			
5000	043546	032777	040000	170606		BIT	#40000,@ML.REG+14		:	3656
5001	043554	001412				BEQ	39\$			
5002	043556	012746	007500			MOV	#MLB11,-(SP)			
5003	043562	012746	007060			MOV	#FMT15,-(SP)			
5004	043566	012746	000002			MOV	#2,-(SP)			
5005	043572	010600				MOV	SP,R0		: SP,*	
5006	043574	104414				TRAP	14			
5007	043576	062706	000006			ADD	#6,SP			
5008					:MLX4					
5009					:					
5010					:					
							SYSTEM ERROR DETECTOR			27-Mar-1982 19:24:42 TOPS
										27-Mar-1982 19:23:44 PA:<
5011	043602	032777	002000	170552	39\$:	BIT	#2000,@ML.REG+14		:	3658
5012	043610	001412				BEQ	40\$			
5013	043612	012746	007504			MOV	#MLB12,-(SP)			
5014	043616	012746	007060			MOV	#FMT15,-(SP)			
5015	043622	012746	000002			MOV	#2,-(SP)			
5016	043626	010600				MCV	SP,R0		: SP,*	
5017	043630	104414				TRAP	14			
5018	043632	062706	000006			ADD	#6,SP			
5019	043636	032777	001000	170516	40\$:	BIT	#1000,@ML.REG+14		:	3660
5020	043644	001412				BEQ	41\$			
5021	043646	012746	007510			MOV	#MLB13,-(SP)			
5022	043652	012746	007060			MOV	#FMT15,-(SP)			
5023	043656	012746	000002			MOV	#2,-(SP)			
5024	043662	010600				MOV	SP,R0		: SP,*	
5025	043664	104414				TRAP	14			

5026	043666	062706	000006			ADD	#6,SP			
5027	043672	132777	000004	170462	41\$:	BITB	#4,@ML.REG+14	:		
5028	043700	001412				BEQ	42\$			3662
5029	043702	012746	007514			MOV	#MLB14,-(SP)			
5030	043706	012746	007060			MOV	#FMT15,-(SP)			
5031	043712	012746	000002			MOV	#2,-(SP)			
5032	043716	010600				MOV	SP,R0	:	SP,*	
5033	043720	104414				TRAP	14			
5034	043722	062706	000006			ADD	#6,SP			
5035	043726	132777	000002	170426	42\$:	BITB	#2,@ML.REG+14	:		
5036	043734	001412				BEQ	43\$			3664
5037	043736	012746	007520			MOV	#MLB15,-(SP)			
5038	043742	012746	007060			MOV	#FMT15,-(SP)			
5039	043746	012746	000002			MOV	#2,-(SP)			
5040	043752	010600				MOV	SP,R0	:	SP,*	
5041	043754	104414				TRAP	14			
5042	043756	062706	000006			ADD	#6,SP			
5043	043762	132777	000001	170372	43\$:	BITB	#1,@ML.REG+14	:		
5044	043770	001412				BEQ	44\$			3666
5045	043772	012746	007524			MOV	#MLB16,-(SP)			
5046	043776	012746	007060			MOV	#FMT15,-(SP)			
5047	044002	012746	000002			MOV	#2,-(SP)			
5048	044006	010600				MOV	SP,R0	:	SP,*	
5049	044010	104414				TRAP	14			
5050	044012	062706	000006			ADD	#6,SP			
5051	044016	032702	000001		44\$:	BIT	#1,R2	:	*,ERR5	3670
5052	044022	001452				BEQ	47\$			
5053	044024	032777	020000	170330		BIT	#20000,@ML.REG+14	:		3674
5054	044032	001412				BEQ	45\$			
5055	044034	012746	007530			MOV	#MLB17,-(SP)			
5056	044040	012746	007060			MOV	#FMT15,-(SP)			
5057	044044	012746	000002			MOV	#2,-(SP)			
5058	044050	010600				MOV	SP,R0	:	SP,*	
5059	044052	104414				TRAP	14			
5060	044054	062706	000006			ADD	#6,SP			
5061	044060	132777	000040	170274	45\$:	BITB	#40,@ML.REG+14	:		3676
5062	044066	001412				BEQ	46\$			
5063										
5064					:MLX4					
5065					:					
							SYSTEM ERROR DETECTOR			
									27-Mar-1982 19:24:42	TOPS
									27-Mar-1982 19:23:44	PA:<
5066	044070	012746	007534			MOV	#MLB18,-(SP)			
5067	044074	012746	007060			MOV	#FMT15,-(SP)			
5068	044100	012746	000002			MOV	#2,-(SP)			
5069	044104	010600				MOV	SP,R0	:	SP,*	
5070	044106	104414				TRAP	14			
5071	044110	062706	000006			ADD	#6,SP			
5072	044114	132777	000010	170240	46\$:	BITB	#10,@ML.REG+14	:		3678
5073	044122	001412				BEQ	47\$			
5074	044124	012746	007542			MOV	#MLB19,-(SP)			
5075	044130	012746	007060			MOV	#FMT15,-(SP)			
5076	044134	012746	000002			MOV	#2,-(SP)			
5077	044140	010600				MOV	SP,R0	:	SP,*	
5078	044142	104414				TRAP	14			
5079	044144	062706	000006			ADD	#6,SP			
5080	044150	032766	000001	000004	47\$:	BIT	#1,4(SP)	:	*,ERR6	3690
5081	044156	001403				BEQ	48\$			
5082	044160	012700	000004			MOV	#4,R0	:		3692

5083	044164	000455			BR	54\$			
5084	044166	006003			ROR	R3		: ERR7	3694
5085	044170	103003			BCC	49\$			
5086	044172	012700	000005		MOV	#5,R0			3690
5087	044176	000450			BR	54\$			
5088	044200	032766	000001	000002	49\$: BIT	#1,2(SP)		: *,ERR2	3698
5089	044206	001403			BEQ	50\$			
5090	044210	012700	000002		MOV	#2,R0			3700
5091	044214	000441			BR	54\$			
5092	044216	006001			50\$: ROR	R1		: ERR4	3702
5093	044220	103003			BCC	51\$			
5094	044222	012700	000003		MOV	#3,R0			3704
5095	044226	000434			BR	54\$			
5096	044230	032716	000001		51\$: BIT	#1,(SP)		: *,ERR3	3706
5097	044234	001024			BNE	52\$			
5098	044236	006022			ROR	R2		: ERR5	
5099	044240	103422			BLO	52\$			
5100	044242	032767	000001	136010	BIT	#1,ERROUT			3712
5101	044250	001416			BEQ	52\$			
5102	044252	032767	000001	170060	BIT	#1,RETRYING			
5103	044260	001012			BNE	52\$			
5104	044262	012746	010140		MOV	#PHR11,-(SP)			
5105	044266	012746	007072		MOV	#SAY1,-(SP)			
5106	044272	012746	000002		MOV	#2,-(SP)			
5107	044276	010600			MOV	SP,R0		: SP,*	
5108	044300	104414			TRAP	14			
5109	044302	062706	000006		ADD	#6,SP			
5110	044306	012705	000001		52\$: MOV	#1,R5			3706
5111	044312	010500			MOV	R5,R0			3428
5112	044314	000401			BR	54\$			
5113	044316	005000			53\$: CLR	R0			3427
5114	044320	062706	000006		54\$: ADD	#6,SP			
5115	044324	000207			RTS	PC			
5116									
5117									
5118					: Routine Size:	647 words			
5119					: MLX4				
5120					: SYSTEM ERROR DETECTOR				
5121					: Maximum stack depth per invocation:	15 words			
5126									
5127									

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

5129 :MLX4
 5130 :
 5131 :
 5132 :
 5133 :
 5134 :
 5135 :
 5136 :
 5137 :
 5138 :
 5139 :
 5140 :
 5141 :
 5142 :
 5143 :
 5144 :
 5145 :
 5146 :
 5147 :
 5148 :
 5149 :
 5150 :
 5151 :
 5152 :
 5153 :
 5154 :
 5155 :
 5156 :
 5157 :
 5158 :
 5159 :
 5160 :
 5161 :
 5162 :
 5163 :
 5164 :
 5165 :
 5166 :
 5167 :
 5168 :
 5169 :
 5170 :
 5171 :
 5172 :
 5173 :
 5174 :
 5175 :
 5176 :
 5177 :
 5178 :
 5179 :
 5180 :
 5181 :
 5182 :
 5183 :

```

DATA COMPARISON ROUTINE
%sbttl 'DATA COMPARISON ROUTINE'
routine DOUBLE_CHECK (W_POINTER, R_POINTER, COUNT) =
begin
    !* 1 *
    !++
ROUTINE:    DOUBLE_CHECK(W_POINTER,R_POINTER,COUNT)
PURPOSE:    TO DOUBLE CHECK THE ECC DETECTION LOGIC AFTER A
             SUCCESSFUL READ COMMAND. THE WRITE AND READ BUFFERS
             ARE COMPARED, AND NO ERRORS SHOULD BE FOUND UNDER
             NORMAL CIRCUMSTANCES.
ARGUMENTS:  W_POINTER = POINTER TO THE WRITE BUFFER
             R_POINTER = POINTER TO THE READ BUFFER
             COUNT = THE NUMBER OF WORDS TO COMPARE
RESULTS:    VALUE RETURNED IS EITHER:
             0 = NO ERRORS WERE FOUND
             N > 0 = ADDRESS IN WRITE BUFFER WHERE ERROR WAS FOUND
    !--
    local
        VALUE,
        OFFSET,
        GOOD,
        BAD;
    label
        LOOP;
    OFFSET = 0;
    VALUE = 0;
LOOP :
begin
    !* 2 *
    incr I from 1 to .COUNT do
begin
    !* 3 *
    GOOD = (.W_POINTER + .OFFSET);
    BAD = (.R_POINTER + .OFFSET);
    if .GOOD eql .BAD
    then
        OFFSET = .OFFSET + 2
    else
begin
    !* 4 *
        VALUE = (.W_POINTER + .OFFSET);
        !ADDRESS OF GOOD
        leave LOOP;
    !* 4 *
    end;
    !* 3 *
end;
    !* 2 *
end;
end;
    
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (23)

5185 :MLX4
 5186 :
 5187 :
 5188 : 3771
 5189 : 3772

DATA COMPARISON ROUTINE

return .VALUE;
 end;

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (23)

!EITHER 0 OR THE ADDRESS OF GOOD DATA
 !* 1 *

5194
 5198 044326
 5199 044326 004167 141002
 5200 044332 005746
 5201 044334 005003
 5202 044336 005001
 5203 044340 005002
 5204 044342 000417
 5205 044344 010304
 5206 044346 066604 000024
 5207 044352 011416
 5208 044354 010305
 5209 044356 066605 000022
 5210 044362 011500
 5211 044364 021600
 5212 044366 001003
 5213 044370 062703 000002
 5214 044374 000402
 5215 044376 010401
 5216 044400 000404
 5217 044402 005202
 5218 044404 020266 000020
 5219 044410 003755
 5220 044412 010100
 5221 044414 005726
 5222 044416 000207

.SBTTL DOUBLE.CHECK DATA COMPARISON ROUTINE

DOUBLE.CHECK:

```

JSR R1,$SAVE5 :
TST -(SP) :
CLR R3 : OFFSET 3749
CLR R1 : VALUE 3750
CLR R2 : I 3754
BR 3$
1$: MOV R3,R4 : OFFSET,* 3756
ADD 24(SP),R4 : W.POINTER,*
MOV (R4),(SP) : *GOOD
MOV R3,R5 : OFFSET,* 3757
ADD 22(SP),R5 : R.POINTER,*
MOV (R5),R0 : *BAD
CMP (SP),R0 : *BAD 3759
BNE 2$
ADD #2,R3 : *.OFFSET 3761
BR 3$ : 3759
2$: MOV R4,R1 : *.VALUE 3764
BR 4$ : 3765
3$: INC R2 : I 3754
CMP R2,20(SP) : I.COUNT
BLE 1$
4$: MOV R1,R0 : VALUE,* 3721
TST (SP)+ : 3720
RTS PC
    
```

; Routine Size: 29 words
 ; Maximum stack depth per invocation: 7 words

5223
 5224
 5225
 5230
 5231

```

5233 :MLX4
5234 :
5235 :
5236 : 3773 %sbttl 'COMMAND INITIATION AND TERMINATION'
5237 : 3774 routine WAITER : novalue =
5238 : 3775 begin
5239 : 3776 !+
5240 : 3777 ! THIS ROUTINE DOES NOTHING, BUT IT IS CALLED BY 'START IT' TO
5241 : 3778 ! WASTE TIME WHILE WAITING TO BEGIN OR END AN ML11 TRANSFER.
5242 : 3779 !-
5243 : 3780 BREAK;
5244 : 3781 return;
5245 : 3782 end;
5249 :
5250 :
5254 044420 104422 .SBTTL WAITER COMMAND INITIATION AND TERMINATION
5255 044422 000207 WAITER: TRAP 22
5256 : RTS PC
5257 :
5258 : ; Routine Size: 2 words
5263 : ; Maximum stack depth per invocation: 0 words
5264 :

```

```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (24)

```

```

3775
3774

```

5266 :MLX4
 5267 :
 5268 :
 5269 :
 5270 :
 5271 :
 5272 :
 5273 :
 5274 :
 5275 :
 5276 :
 5277 :
 5278 :
 5279 :
 5280 :
 5281 :
 5282 :
 5283 :
 5284 :
 5285 :
 5286 :
 5287 :
 5288 :
 5289 :
 5290 :
 5291 :
 5292 :
 5293 :
 5294 :
 5295 :
 5296 :
 5297 :
 5298 :
 5299 :
 5300 :
 5301 :
 5302 :
 5303 :
 5304 :
 5305 :
 5306 :
 5307 :
 5308 :
 5309 :
 5310 :
 5311 :
 5312 :
 5313 :
 5314 :
 5315 :
 5316 :
 5317 :
 5318 :
 5319 :
 5320 :

COMMAND INITIATION AND TERMINATION

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (25)

routine START_IT (COMMAND, LUN, WRDCNT, BUFFER, SECTOR) =
 begin

```

++
ROUTINE:    START_IT(COMMAND,LUN,WRDCNT,BUFFER,SECTOR)
PURPOSE:    TO INITIATE A TRANSFER TO OR FROM THE ML11,
             TO WAIT FOR THE TRANSFER TO COMPLETE, AND TO CALL
             THE 'SYSERR' ROUTINE TO LOOK FOR RESULTING ERRORS.
ARGUMENTS:  (1)  COMMAND - THE FUNCTION CODE FOR THE TYPE OF TRANSFER
             DESIRED. THIS CODE WILL BE SENT TO THE MLCS1
             REGISTER TO START THE OPERATION, SINCE IT
             ALSO CONTAINS THE GO BIT.
             (2)  LUN     - LOGICAL UNIT NUMBER
             (3)  WRDCNT - NUMBER OF 16-BIT WORDS TO TRANSFER
             (4)  BUFFER  - THE ADDRESS IN MAIN MEMORY OF THE SELECTED
             WRITE OR READ BUFFER
             (5)  SECTOR  THE TRANSFER'S STARTING ADDRESS IN THE ML11
RESULTS:    VALUES RETURNED ARE IDENTICAL TO THOSE DEFINED ABOVE IN
             THE 'SYSERR' ROUTINE.
    
```

```

--
local
    TEMP,
    READY_BIT,
    RTN;
    
```

```

label
    LOOP;
    
```

```

! WAIT FOR DRIVE READY:
    
```

```

UNIT = .DRIVE;           !SELECT THE UNIT
READY_BIT = 0;
    
```

```

until .READY_BIT neq 0 do !WAIT FOR DRIVE READY
begin
    WAITER ();
    READY_BIT = .MLCS1 and BIT7;
end;
    
```

```

! INITIALIZE BEFORE EACH TRANSFER:
    
```

```

CLR = 1;                !CONTROLLER CLEAR
    
```

5322 :MLX4
5323 :
5324 :
5325 :
5326 :
5327 :
5328 :
5329 :
5330 :
5331 :
5332 :
5333 :
5334 :
5335 :
5336 :
5337 :
5338 :
5339 :
5340 :
5341 :
5342 :
5343 :
5344 :
5345 :
5346 :
5347 :
5348 :
5349 :
5350 :
5351 :
5352 :
5353 :
5354 :
5355 :
5356 :
5357 :
5358 :
5359 :
5360 :
5361 :
5362 :
5363 :
5364 :
5365 :
5366 :
5367 :
5368 :
5369 :
5370 :
5371 :
5372 :
5373 :
5374 :
5375 :
5376 :

COMMAND INITIATION AND TERMINATION

```
3835 DELAY (1);  
3836 MLCS1 = DRV_CLR;  
3837 DELAY (1);  
3838 UNIT = .DRIVE;  
3839  
3840 SET UP THE REQUIRED ENABLE/DISABLE BITS:  
3841  
3842 DCK_EN = 1;  
3843  
3844 if .REFRESH then REF_MAR = 1;  
3845  
3846 if .ECCDIS then ECC_DIS = 1;  
3847  
3848  
3849 SEND REQUIRED INFORMATION TO DEVICE REGISTERS:  
3850  
3851 MLWC = -(.WRDCNT);  
3852 MLBA = .BUFFER;  
3853 MLDA = .SECTOR;  
3854  
3855 GO:  
3856  
3857 I_AM_DONE = INACTIVE;  
3858 TEMP = .COMMAND + BIT6;  
3859 MLCS1 = .TEMP;  
3860  
3861 WAIT FOR DRIVE TO FINISH:  
3862  
3863 LOOP :  
3864 begin  
3865 READY_BIT = 0;  
3866  
3867 until .I_AM_DONE do  
3868 begin  
3869 WAITER ();  
3870 READY_BIT = .MLCS1 and BIT7;  
3871  
3872 if ((.READY_BIT neq 0) and (.I_AM_DONE eql INACTIVE))  
3873 then  
3874 begin  
3875  
3876 if ( not .RETRYING)  
3877 then  
3878 begin  
3879 SAYWHO (.LUN);  
3880  
3881 if .COMMAND eql WR_CMD then RTN = WRD16;  
3882  
3883 if .COMMAND eql RD_CMD then RTN = WRD17;  
3884  
3885 if .COMMAND eql WC_CMD then RTN = PHR1;  
3886
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (25)

!DELAY FOR CLEAR TO COMPLETE
!DRIVE CLEAR
!DELAY FOR CLEAR TO COMPLETE
!PUT BACK THE DRIVE NUMBER

!ALLOW REPORTING OF DATA CHECK ERRORS
!TURN ON REFRESH MARGINING IF OPERATOR SELECTED IT
!TURN OFF ECC IF OPERATOR SELECTED IT

!WORD COUNT REGISTER
!BUS ADDRESS REGISTER (ADDRESS IN MAIN MEMORY)
!DESIRED SECTOR ADDRESS REGISTER (ADDRESS IN ML11)

!SET THE INTERRUPT ENABLE BIT WHILE LOADING THE
!CONTROL AND STATUS REGISTER WITH THE COMMAND

5378 :MLX4
 5379 :
 5380 :
 5381 :
 5382 :
 5383 :
 5384 :
 5385 :
 5386 :
 5387 :
 5388 :
 5389 :
 5390 :
 5391 :
 5392 :
 5393 :
 5394 :
 5395 :
 5399 :
 5400 :
 5401 :
 5402 :
 5403 :
 5407 044424
 5408 044424
 5409 044430
 5410 044432
 5411 044436
 5412 044440
 5413 044442
 5414 044446
 5415 044452
 5416 044456
 5417 044464
 5418 044470
 5419 044472
 5420 044474
 5421 044476
 5422 044502
 5423 044506
 5424 044512
 5425 044514
 5426 044522
 5427 044526
 5428 044530
 5429 044534
 5430 044536
 5431 044540
 5432 044542

COMMAND INITIATION AND TERMINATION

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (25)

```

3887 PRINTB (FMT6, .WRDCNT, .RTN, WRD15, .SECTOR);
3888 !'BEGAN YYYY WORD (???) AT SECTOR ZZZZZZ'
3889 !WHERE (???) IS EITHER 'WRITE', 'READ' OR 'WRITE CHECK'
3890 PRINTB (SAY1, MSG0);
3891 !INTERRUPT DID NOT OCCUR, BUT THE TRANSFER IS COMPLETE
3892 end;
3893
3894 Leave LOOP;
3895 end;
3896
3897 end;
3898
3899 return SYSERR (.LUN);
3900 end;
3901
    
```

!PASS ALONG THE ERROR VALUES THAT 'SYSERR' OBTAINED.

.GLOBL LSDLY

.SBTTL START.IT COMMAND INITIATION AND TERMINATION

START.IT:

```

JSR R1,$SAVE4 ;
TST -(SP) ;
MOV 24(SP),R4 ; LUN,*
MOV R4,R1 ;
ASL R1 ;
MOV PTABLE.ADDR(R1),R2 ;
MOV 6(R2),R3 ;
BIC #177770,R3 ;
BICB #7,@ML.REG+10 ;
BISB R3,@ML.REG+10 ;
CLR R3 ; READY.BIT
CMP PC,PC ;
BNE 2$ ;
JSR PC,WAITER ;
MOV @ML.REG,R3 ; *,READY.BIT
BIC #177577,R3 ; *,READY.BIT
BR 1$ ;
BISB #40,@ML.REG+10 ;
MOV #1,R0 ; *,SSTMP2
BEQ 6$ ;
MOV LSDLY,R2 ; *,SSTMP1
BEQ 5$ ;
CLR (SP) ; SSTMP
DEC R2 ; SSTMP1
BNE 4$ ;
    
```

167672

167634

3783
 3822
 3823
 3825
 3827
 3828
 3825
 3834
 3835

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

Address	OpCode	Operand 1	Operand 2	Operand 3	Label	Instruction	Comments	Page
5434						:MLX4		
5435						:		
5436						COMMAND INITIATION AND TERMINATION		
5437	044544	005300			5\$:	DEC R0	: \$STMP2	
5438	044546	000767				BR 3\$		
5439	044550	012777	000011	167570	6\$:	MOV #11,@ML.REG		
5440	044556	012700	000001			MOV #1,R0	: *,\$STMP2	3836
5441	044562	001410			7\$:	BEQ 10\$		3837
5442	044564	016702	135326			MOV LSDLY,R2	: *,\$STMP1	
5443	044570	001403				BEQ 9\$		
5444	044572	005016			8\$:	CLR (SP)	: \$STMP	
5445	044574	005302				DEC R2	: \$STMP1	
5446	044576	001375				BNE 8\$		
5447	044600	005300			9\$:	DEC R0	: \$STMP2	
5448	044602	000767				BR 7\$		
5449	044604	016102	034422		10\$:	MOV PTABLE.ADDR(R1),R2	:	
5450	044610	016201	000006			MOV 6(R2),R1		3838
5451	044614	042701	177770			BIC #177770,R1		
5452	044620	142777	000007	167530		BICB #7,@ML.REG+10		
5453	044626	150177	167524			BISB R1,@ML.REG+10		
5454	044632	152777	000004	167532		BISB #4,@ML.REG+24		
5455	044640	032767	000001	135404		BIT #1,REFRESH	:	3842
5456	044646	001403				BEQ 11\$:	3844
5457	044650	152777	000200	167514		BISB #200,@ML.REG+24		
5458	044656	032767	000001	135370	11\$:	BIT #1,ECCDIS	:	3846
5459	044664	001403				BEQ 12\$		
5460	044666	152777	000002	167476		BISB #2,@ML.REG+24		
5461	044674	016677	000022	167446	12\$:	MOV 22(SP),@ML.REG+2	: WRDCNT,*	3851
5462	044702	005477	167442			NEG @ML.REG+2		
5463	044706	016677	000020	167436		MOV 20(SP),@ML.REG+4	: BUFFER,*	3852
5464	044714	016677	000016	167432		MOV 16(SP),@ML.REG+6	: SECTOR,*	3853
5465	044722	005067	167410			CLR I.AM.DONE	: :	3857
5466	044726	016602	000026			MOV 26(SP),R2	: :	3858
5467	044732	010201				MOV R2,R1	: COMMAND,*	
5468	044734	062701	000100			ADD #100,R1	: *,TEMP	
5469	044740	010177	167402			MOV R1,@ML.REG	: *,TEMP	
5470	044744	005003				CLR R3	: TEMP,*	3859
5471	044746	032767	000001	167362	13\$:	BIT #1,I.AM.DONE	: READY.BIT	3865
5472	044754	001067				BNE 17\$:	3867
5473	044756	004767	177436			JSR PC,WAITER	:	
5474	044762	017703	167360			MOV @ML.REG,R3	: *,READY.BIT	3869
5475	044766	042703	177577			BIC #177577,R3	: *,READY.BIT	3870
5476	044772	001765				BEQ 13\$:	
5477	044774	005767	167336			TST I.AM.DONE	:	3872
5478	045000	001362				BNE 13\$:	
5479	045002	032767	000001	167330		BIT #1,RETRYING	:	3876
5480	045010	001051				BNE 17\$:	
5481	045012	010446				MOV R4,-(SP)	:	3879
5482	045014	004767	170504			JSR PC,SAYWHO	:	
5483	045020	020227	000061			CMP R2,#61	:	3881
5484	045024	001002				BNE 14\$:	
5485	045026	012701	007256			MOV #WRD16,R1	: *,RTN	
5486	045032	020227	000071		14\$:	CMP R2,#71	:	3883
5487	045036	001002				BNE 15\$:	
5488	045040	012701	007264			MOV #WRD17,R1	: *,RTN	

Address	OpCode	Op1	Op2	Op3	Op4	Comments	PC
5490							
5491							
5492							
5493	045044	020227	000051				
5494	045050	001002					
5495	045052	012701	007714				
5496	045056	016616	000020				
5497	045062	012746	007246				
5498	045066	010146					
5499	045070	016646	000030				
5500	045074	012746	006376				
5501	045100	012746	000005				
5502	045104	010600					
5503	045106	104414					
5504	045110	012716	011002				
5505	045114	012746	007072				
5506	045120	012746	000002				
5507	045124	010600					
5508	045126	104414					
5509	045130	062706	000020				
5510	045134	010446					
5511	045136	004767	174546				
5512	045142	022626					
5513	045144	000207					
5514							
5515							
5516							
5521							
5522							

: Routine Size: 169 words
 : Maximum stack depth per invocation: 14 words

COMMAND INITIATION AND TERMINATION

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

```

:MLX4
:
15$:  CMP      R2,#51
      BNE     16$
      MOV     #PHR1,R1
      MOV     20(SP),-(SP)
      MOV     #WRD15,-(SP)
      MOV     R1,-(SP)
      MOV     30(SP),-(SP)
      MOV     #FMT6,-(SP)
      MOV     #5,-(SP)
      MOV     SP,R0
      TRAP   14
      MOV     #MSG0,(SP)
      MOV     #SAY1,-(SP)
      MOV     #2,-(SP)
      MOV     SP,R0
      TRAP   14
      ADD     #20,SP
      MOV     R4,-(SP)
      JSR     PC,SYSERR
      CMP     (SP)+,(SP)+
      RTS     PC
    
```

3885

3887

3890

3878

3900

3783

```

5524 :MLX4
5525 :
5526 :
5527 : 3902 %sbttl 'COUNTING BYTES TRANSFERED'
5528 : 3903 routine UP_WR_COUNT (WORD_COUNT) : novalue =
5529 : 3904 begin
5530 : 3905 WR_COUNT = .WR_COUNT + (.WORD_COUNT*2);
5531 : 3906
5532 : 3907 if .WR_COUNT geq 20000
5533 : 3908 then
5534 : 3909 begin
5535 : 3910 WR_THOUSANDS = .WR_THOUSANDS + 20;
5536 : 3911 WR_COUNT = .WR_COUNT - 20000;
5537 : 3912
5538 : 3913 if .WR_THOUSANDS geq 1000
5539 : 3914 then
5540 : 3915 begin
5541 : 3916 WR_THOUSANDS = .WR_THOUSANDS - 1000;
5542 : 3917 WR_MILLIONS = .WR_MILLIONS + 1;
5543 : 3918
5544 : 3919 if .WR_MILLIONS lss 0 then WR_MILLIONS = 0;
5545 : 3920
5546 : 3921 end;
5547 : 3922
5548 : 3923 end;
5549 : 3924
5550 : 3925 return;
5551 : 3926 end;
5555
5556

```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (26)

Address	Hex	Dec	Hex	Dec	Hex	Dec	Instruction	Comment	Line
5560	045146	016600	000002				UP.WR.COUNT:		
5561	045146	016600	000002				MOV	2(SP),R0	3905
5562	045152	006300					ASL	R0	
5563	045154	066700	167134				ADD	WR.COUNT,R0	
5564	045160	010067	167130				MOV	R0,WR.COUNT	
5565	045164	020027	047040				CMP	R0,#47040	
5566	045170	002422					BLT	1\$	3907
5567	045172	062767	000024	167116			ADD	#24,WR.THOUSANDS	3910
5568	045200	162767	047040	167106			SUB	#47040,WR.COUNT	3911
5569	045206	026727	167104	001750			CMP	WR.THOUSANDS,#1750	3913
5570	045214	002410					BLT	1\$	
5571	045214	162767	001750	167072			SUB	#1750,WR.THOUSANDS	3916
5572	045224	005267	167070				INC	WR.MILLIONS	3917
5573	045230	100002					BPL	1\$	3919
5574	045232	005067	167062				CLR	WR.MILLIONS	
5575	045236	000207					RTS	PC	3903

: Routine Size: 29 words
 : Maximum stack depth per invocation: 0 words

5579 :MLX4
 5580 :
 5581 :
 5586 :
 5587 :
 COUNTING BYTES TRANSFERED
 27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (27)

```

5589 :MLX4
5590 :
5591 :
5592 : 3927 routine UP_RD_COUNT (WORD_COUNT) : novalue =
5593 : 3928 begin
5594 : 3929 RD_COUNT = .RD_COUNT + (.WORD_COUNT*2);
5595 : 3930
5596 : 3931 if .RD_COUNT geq 20000
5597 : 3932 then
5598 : 3933 begin
5599 : 3934 RD_THOUSANDS = .RD_THOUSANDS + 20;
5600 : 3935 RD_COUNT = .RD_COUNT - 20000;
5601 : 3936
5602 : 3937 if .RD_THOUSANDS geq 1000
5603 : 3938 then
5604 : 3939 begin
5605 : 3940 RD_THOUSANDS = .RD_THOUSANDS - 1000;
5606 : 3941 RD_MILLIONS = .RD_MILLIONS + 1;
5607 : 3942
5608 : 3943 if .RD_MILLIONS lss 0 then RD_MILLIONS = 0;
5609 : 3944
5610 : 3945 end;
5611 : 3946
5612 : 3947 end;
5613 : 3948
5614 : 3949 return;
5615 : 3950 end;
5619 :
5620 :
    
```

Address	Hex	Dec	Hex	Dec	Instruction	Comment	Address
5624	045240				.SBTTL UP.RD.COUNT COUNTING BYTES TRANSFERED		
5625	045240	016600	000002		UP.RD.COUNT:		
5626	045244	006300			MOV 2(SP),R0	: WORD.COUNT,*	3929
5627	045246	066700	167050		ASL R0		
5628	045252	010067	167044		ADD RD.COUNT,R0		
5629	045256	020027	047040		MOV R0,RD.COUNT		
5630	045262	002422			CMP R0,#47040	: RD.COUNT,*	3931
5631	045264	062767	000024	167032	BLT 1\$		
5632	045272	162767	047040	167022	ADD #24,RD.THOUSANDS	:	3934
5633	045300	026727	167020	001750	SUB #47040,RD.COUNT	:	3935
5634	045306	002410			CMP RD.THOUSANDS,#1750	:	3937
5635	045310	162767	001750	167006	BLT 1\$:	
5636	045316	005267	167004		SUB #1750,RD.THOUSANDS	:	3940
5637	045322	100002			INC RD.MILLIONS	:	3941
5638	045324	005067	166776		BPL 1\$:	3943
5639	045330	000207			CLR RD.MILLIONS	:	
5640					1\$: RTS PC	:	3927
5641							
5642					: Routine Size: 29 words		
5650					: Maximum stack depth per invocation: 0 words		
5651							

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (28)

```

5653 :MLX4
5654 :
5655 :
5656 : 3951 routine UP_WC_COUNT (WORD_COUNT) : novalue =
5657 : 3952 begin
5658 : 3953 WC_COUNT = .WC_COUNT + (.WORD_COUNT*2);
5659 : 3954
5660 : 3955 if .WC_COUNT geq 20000
5661 : 3956 then
5662 : 3957 begin
5663 : 3958 WC_THOUSANDS = .WC_THOUSANDS + 20;
5664 : 3959 WC_COUNT = .WC_COUNT - 20000;
5665 : 3960
5666 : 3961 if .WC_THOUSANDS geq 1000
5667 : 3962 then
5668 : 3963 begin
5669 : 3964 WC_THOUSANDS = .WC_THOUSANDS - 1000;
5670 : 3965 WC_MILLIONS = .WC_MILLIONS + 1;
5671 : 3966
5672 : 3967 if .WC_MILLIONS lss 0 then WC_MILLIONS = 0;
5673 : 3968
5674 : 3969 end;
5675 : 3970
5676 : 3971 end;
5677 : 3972
5678 : 3973 return;
5679 : 3974 end;
5683 :
5684 :

```

Address	Hex	Dec	Hex	Label	Instruction	Comment	Address
5688	045332	016600	000002	UP.WC.COUNT:	MOV	2(SP),RO	3953
5689	045332	006300			ASL	RO	
5690	045336	006300			ADD	WC_COUNT,RO	
5691	045340	066700	166764		MOV	RO,WC_COUNT	
5692	045344	010067	166760		CMP	RO,#47040	
5693	045350	020027	047040		BLT	1\$	3955
5694	045354	002422			ADD	#24,WC_THOUSANDS	
5695	045356	062767	000024	166746	SUB	#47040,WC_COUNT	3958
5696	045364	162767	047040	166736	CMP	WC_THOUSANDS,#1750	3959
5697	045372	026727	166734	001750	BLT	1\$	3961
5698	045400	002410			SUB	#1750,WC_THOUSANDS	
5699	045402	162767	001750	166722	INC	WC_MILLIONS	3964
5700	045410	005267	166720		BPL	1\$	3965
5701	045414	100002			CLR	WC_MILLIONS	3967
5702	045416	005067	166712		RTS	PC	
5703	045422	000207		1\$:			3951

: Routine Size: 29 words
 : Maximum stack depth per invocation: 0 words

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (29)

5717 :MLX4
 5718 :
 5719 :
 5720 :
 5721 :
 5722 :
 5723 :
 5724 :
 5725 :
 5726 :
 5727 :
 5728 :
 5729 :
 5730 :
 5731 :
 5732 :
 5733 :
 5734 :
 5735 :
 5736 :
 5737 :
 5738 :
 5739 :
 5740 :
 5741 :
 5742 :
 5743 :
 5744 :
 5745 :
 5746 :
 5747 :
 5748 :
 5749 :
 5750 :
 5751 :
 5752 :
 5753 :
 5754 :
 5755 :
 5756 :
 5760 :
 5761 :

3975
 3976
 3977
 3978
 3979
 3980
 3981
 3982
 3983
 3984
 3985
 3986
 3987
 3988
 3989
 3990
 3991
 3992
 3993
 3994
 3995
 3996
 3997
 3998
 3999
 4000
 4001
 4002
 4003
 4004
 4005
 4006
 4007
 4008
 4009
 4010
 4011

ML11 TRANSFER COMMANDS

```
%sbttl 'ML11 TRANSFER COMMANDS'
routine write (LUN, WRDCNT, BUFFER, SECTOR) =
begin
!++
ROUTINE:    WRITE(LUN,WRDCNT,BUFFER,SECTOR)
PURPOSE:    TO TRANSFER INFORMATION FROM MAIN MEMORY TO THE ML11
            AND TO DECIDE ON THE ADVISABILITY OF A RETRY.
ARGUMENTS:  SEE 'START_IT' ROUTINE ABOVE FOR DETAILS
RESULTS:    UPON TERMINATION OF THE TRANSFER, ERROR DETECTION OCCURS
            AND THE CONTENTS OF 'VALUE' BECOMES IMPORTANT IN TERMS OF
            WHETHER THE TRANSFER WAS COMPLETELY SUCCESSFUL OR WHETHER A
            RETRY SHOULD OR SHOULD NOT BE PERMITTED.

            THE VALUES RETURNED FOR THIS SUBROUTINE ARE THE SAME AS
            FOR THE SYSERR ROUTINE ABOVE.
!--
```

local
 VALUE,
 COMMAND;

```
COMMAND = WR_CMD;
VALUE = START_IT (.COMMAND, .LUN, .WRDCNT, .BUFFER, .SECTOR);
if ( not .RETRYING) then UP_WR_COUNT (.WRDCNT);
if .VALUE eql 0 then return 0;          !NO ERRORS AT ALL
if ((.ERROUT) and ( not .RETRYING)) then PRINTB (FMT6, .WRDCNT, WRD16, WRD15, .SECTOR);
!'BEGAN YYYY WORD WRITE AT SECTOR ZZZZZZ'
return .VALUE;
end;
```

5765 045424 004167 137632
 5766 045430 012700 000061
 5767 045434 010046
 5768 045436 016646 000020
 5769 045442 016601 000020
 5770 045446 010146
 5771 045450 016646 000020

```
WRITE: .SBTTL WRITE ML11 TRANSFER COMMANDS
        JSR R1,$SAVE2
        MOV #61,R0
        MOV R0,-(SP)
        MOV 20(SP),-(SP)
        MOV 20(SP),R1
        MOV R1,-(SP)
        MOV 20(SP),-(SP)
        :
        : *COMMAND
        : COMMAND,*
        : LUN,*
        : WRDCNT,*
        : BUFFER,*
```

3976
 4000
 4001

```
5773                                     :MLX4
5774                                     :
5775                                     : ML11 TRANSFER COMMANDS
5776 045454 016646 000020                MOV    20(SP),-(SP)           ; SECTOR,*
5777 045460 004767 176740                JSR   PC,START.IT
5778 045464 010002                        MOV    R0,R2                 ; *,VALUE
5779 045466 032767 000001 166644        BIT   #1,RETRYING           ;
5780 045474 001004 1$                    BNE   1$                     ;
5781 045476 010146                        MOV    R1,-(SP)
5782 045500 004767 177442                JSR   PC,UP.WR.COUNT
5783 045504 005726                        TST   (SP)+
5784 045506 005702 1$                    TST   R2                     ; VALUE
5785 045510 001003 2$                    BNE   2$                     ;
5786 045512 062706 000012                ADD   #12,SP
5787 045516 000433                        BR    4$
5788 045520 032767 000001 134532 2$    BIT   #1,ERROUT            ;
5789 045526 001423                        BEQ   3$                     ;
5790 045530 032767 000001 166602        BIT   #1,RETRYING
5791 045536 001017                        BNE   3$
5792 045540 016646 000022                MOV    22(SP),-(SP)         ; SECTOR,*
5793 045544 012746 007246                MOV   #WRD15,-(SP)
5794 045550 012746 007256                MOV   #WRD16,-(SP)
5795 045554 010146                        MOV   R1,-(SP)
5796 045556 012746 006376                MOV   #FMT6,-(SP)
5797 045562 012746 000005                MOV   #5,-(SP)
5798 045566 010600                        MOV   SP,R0
5799 045570 104414                        TRAP  14                     ; SP,*
5800 045572 062706 000014                ADD   #14,SP
5801 045576 062706 000012 3$            ADD   #12,SP
5802 045602 010200                        MOV   R2,R0
5803 045604 000207                        RTS   PC                     ; VALUE,*
5804 045606 005000 4$                    CLR   R0
5805 045610 000207                        RTS   PC                     ;
5806
5807
5808
5813
5814
```

: Routine Size: 59 words
: Maximum stack depth per invocation: 14 words

4003

4005

4007

3976

3977

3976

5816 :MLX4
 5817 :
 5818 :
 5819 : 4012
 5820 : 4013
 5821 : 4014
 5822 : 4015
 5823 : 4016
 5824 : 4017
 5825 : 4018
 5826 : 4019
 5827 : 4020
 5828 : 4021
 5829 : 4022
 5830 : 4023
 5831 : 4024
 5832 : 4025
 5833 : 4026
 5834 : 4027
 5835 : 4028
 5836 : 4029
 5837 : 4030
 5838 : 4031
 5839 : 4032
 5840 : 4033
 5841 : 4034
 5842 : 4035
 5843 : 4036
 5844 : 4037
 5845 : 4038
 5846 : 4039
 5847 : 4040
 5848 : 4041
 5849 : 4042
 5850 : 4043
 5851 : 4044
 5852 : 4045
 5853 : 4046
 5854 : 4047
 5858 :
 5859 :

ML11 TRANSFER COMMANDS

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (30)

routine read (LUN, WRDCNT, BUFFER, SECTOR) =
 begin
 +-
 ROUTINE: READ(LUN,WRDCNT,BUFFER,SECTOR)
 PURPOSE: TO TRANSFER INFORMATION FROM THE ML11 TO MAIN MEMORY
 USING A 'READ' COMMAND.
 ARGUMENTS: SEE 'START_IT' ROUTINE ABOVE FOR DETAILS
 RESULTS: UPON TERMINATION OF THE TRANSFER, ERROR DETECTION OCCURS
 AND THE CONTENTS OF 'VALUE' BECOMES IMPORTANT IN TERMS OF
 WHETHER THE TRANSFER WAS COMPLETELY SUCCESSFUL OR WHETHER A
 RETRY SHOULD OR SHOULD NOT BE PERMITTED.
 THE VALUES RETURNED FOR THIS SUBROUTINE ARE THE SAME AS
 FOR THE SYSERR ROUTINE ABOVE.

Local
 VALUE,
 COMMAND;

COMMAND = RD CMD;
 VALUE = START_IT (.COMMAND, .LUN, .WRDCNT, .BUFFER, .SECTOR);
 if (not .RETRYING) then UP_RD_COUNT (.WRDCNT);
 if .VALUE eql 0 then return 0; !NO ERRORS AT ALL
 if ((.ERROUT) and (not .RETRYING)) then PRINTB (FMT6, .WRDCNT, WRD17, WRD15, .SECTOR);
 !'BEGAN YYYY WORD READ AT SECTOR ZZZZZZ'
 return .VALUE;
 end;

5863 045612 004167 137444
 5864 045616 012700 000071
 5865 045622 010046
 5866 045624 016646 000020
 5867 045630 016601 000020
 5868 045634 010146
 5869 045636 016646 000020
 5870 045642 016646 000020

READ: .SBTTL READ ML11 TRANSFER COMMANDS
 JSR R1,\$SAVE2
 MOV #71,R0
 MOV R0,-(SP)
 MOV 20(SP),-(SP)
 MOV 20(SP),R1
 MOV R1,-(SP)
 MOV 20(SP),-(SP)
 MOV 20(SP),-(SP)

4012
 4036
 4037

:
 : * ,COMMAND
 : COMMAND,*
 : LUN,*
 : WRDCNT,*
 :
 : BUFFER,*
 : SECTOR,*

```
5872      :MLX4
5873      :
5874      :
5875 045646 004767 176552      JSR  PC,START.IT
5876 045652 010002      MOV  R0,R2
5877 045654 032767 000001 166456  BIT  #1,RETRYING      : *,VALUE
5878 045662 001004      BNE  1$
5879 045664 010146      MOV  R1,-(SP)
5880 045666 004767 177346      JSR  PC,UP.RD.COUNT
5881 045672 005726      TST  (SP)+
5882 045674 005702      TST  R2              : VALUE
5883 045676 001003      BNE  2$
5884 045700 062706 000012      ADD  #12,SP
5885 045704 000433      BR   4$
5886 045706 032767 000001 134344 2$: BIT  #1,ERROUT
5887 045714 001423      BEQ  3$
5888 045716 032767 000001 166414  BIT  #1,RETRYING
5889 045724 001017      BNE  3$
5890 045726 016646 000022      MOV  22(SP),-(SP)   : SECTOR,*
5891 045732 012746 007246      MOV  #WORD15,-(SP)
5892 045736 012746 007264      MOV  #WORD17,-(SP)
5893 045742 010146      MOV  R1,-(SP)
5894 045744 012746 006376      MOV  #FMT6,-(SP)
5895 045750 012746 000005      MOV  #5,-(SP)
5896 045754 010600      MOV  SP,R0          : SP,*
5897 045756 104414      TRAP 14
5898 045760 062706 000014      ADD  #14,SP
5899 045764 062706 000012 3$: ADD  #12,SP
5900 045770 010200      MOV  R2,R0
5901 045772 000207      RTS  PC
5902 045774 005000      CLR  R0
5903 045776 000207      RTS  PC
5904
5905      : Routine Size: 59 words
5906      : Maximum stack depth per invocation: 14 words
5911
5912
```


5914 :MLX4

27-Mar-1982 19:24:42

TOPS-20 Bliss-16 V2(212)

27-Mar-1982 19:23:44

PA:<NEALE>MLX4.BLI.5 (31)

5915 :
5916 :
5917 : 4048
5918 : 4049
5919 : 4050
5920 : 4051
5921 : 4052
5922 : 4053
5923 : 4054
5924 : 4055
5925 : 4056
5926 : 4057
5927 : 4058
5928 : 4059
5929 : 4060
5930 : 4061
5931 : 4062
5932 : 4063
5933 : 4064
5934 : 4065
5935 : 4066
5936 : 4067
5937 : 4068
5938 : 4069
5939 : 4070
5940 : 4071
5941 : 4072
5942 : 4073
5943 : 4074
5944 : 4075
5945 : 4076
5946 : 4077
5947 : 4078
5948 : 4079
5949 : 4080
5950 : 4081
5951 : 4082
5952 : 4083
5956 :
5957 :

ML11 TRANSFER COMMANDS

routine CHECK (LUN, WRDCNT, BUFFER, SECTOR) =
begin

!++

ROUTINE: CHECK(LUN,WRDCNT,BUFFER,SECTOR)

PURPOSE: TO TRANSFER INFORMATION FROM THE ML11 TO MAIN MEMORY
USING A 'WRITE CHECK' COMMAND.

ARGUMENTS: SEE 'START_IT' ROUTINE ABOVE FOR DETAILS

RESULTS: UPON TERMINATION OF THE TRANSFER, ERROR DETECTION OCCURS
AND THE CONTENTS OF 'VALUE' BECOMES IMPORTANT IN TERMS OF
WHETHER THE TRANSFER WAS COMPLETELY SUCCESSFUL OR WHETHER A
RETRY SHOULD OR SHOULD NOT BE PERMITTED.

!--
THE VALUES RETURNED FOR THIS SUBROUTINE ARE THE SAME AS
FOR THE SYSERR ROUTINE ABOVE.

local

VALUE,
COMMAND;

COMMAND = WC_CMD;

VALUE = START_IT (.COMMAND, .LUN, .WRDCNT, .BUFFER, .SECTOR);

if (not .RETRYING) then UP_WC_COUNT (.WRDCNT);

if .VALUE eql 0 then return 0; !NO ERRORS AT ALL

if ((.ERROUT) and (not .RETRYING)) then PRINTB (FMT6, .WRDCNT, PHR1, WRD15, .SECTOR);

!'BEGAN YYYY WORD WRITE CHECK AT SECTOR ZZZZZZ'

return .VALUE;

end;

5961 046000 004167 137256
5962 046004 012700 000051
5963 046010 010046
5964 046012 016646 000020
5965 046016 016601 000020
5966 046022 010146
5967 046024 016646 000020
5968 046030 016646 000020

CHECK: .SBTTL CHECK ML11 TRANSFER COMMANDS
JSR R1,\$SAVE2
MOV #51,R0
MOV R0,-(SP)
MOV 20(SP),-(SP)
MOV 20(SP),R1
MOV R1,-(SP)
MOV 20(SP),-(SP)
MOV 20(SP),-(SP)

:
: * ,COMMAND
: COMMAND,*
: LUN,*
: WRDCNT,*
:
: BUFFER,*
: SECTOR,*

4048
4072
4073

Address	Hex	Hex	Hex	Label	Command	Comment	Line
5970				:MLX4			
5971				:			
5972					ML11 TRANSFER COMMANDS		
5973	046034	004767	176364		JSR PC,START.IT		
5974	046040	010002			MOV R0,R2	: *,VALUE	
5975	046042	032767	000001 166270		BIT #1,RETRYING	:	
5976	046050	001004			BNE 1\$:	4075
5977	046052	010146			MOV R1,-(SP)		
5978	046054	004767	177252		JSR PC,UP.WC.COUNT		
5979	046060	005726			TST (SP)+		
5980	046062	005702		1\$:	TST R2	: VALUE	
5981	046064	001003			BNE 2\$		4077
5982	046066	062706	000012		ADD #12,SP		
5983	046072	000433			BR 4\$		
5984	046074	032767	000001 134156	2\$:	BIT #1,ERROUT	:	
5985	046102	001423			BEQ 3\$		4079
5986	046104	032767	000001 166226		BIT #1,RETRYING		
5987	046112	001017			BNE 3\$		
5988	046114	016646	000022		MOV 22(SP),-(SP)	: SECTOR,*	
5989	046120	012746	007246		MOV #WRD15,-(SP)		
5990	046124	012746	007714		MOV #PHR1,-(SP)		
5991	046130	010146			MOV R1,-(SP)		
5992	046132	012746	006376		MOV #FMT6,-(SP)		
5993	046136	012746	000005		MOV #5,-(SP)		
5994	046142	010600			MOV SP,R0	: SP,*	
5995	046144	104414			TRAP 14		
5996	046146	062706	000014		ADD #14,SP		
5997	046152	062706	000012	3\$:	ADD #12,SP	:	
5998	046156	010200			MOV R2,R0	: VALUE,*	4048
5999	046160	000207			RTS PC		4049
6000	046162	005000		4\$:	CLR R0	:	
6001	046164	000207			RTS PC		4048
6002							
6003							
6004							
6009							
6010							

: Routine Size: 59 words
: Maximum stack depth per invocation: 14 words

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (32)

6012 :MLX4
 6013 :
 6014 :
 6015 :
 6016 :
 6017 :
 6018 :
 6019 :
 6020 :
 6021 :
 6022 :
 6023 :
 6024 :
 6025 :
 6026 :
 6027 :
 6028 :
 6029 :
 6030 :
 6031 :
 6032 :
 6033 :
 6034 :
 6035 :
 6036 :
 6037 :
 6038 :
 6039 :
 6040 :
 6041 :
 6042 :
 6043 :
 6047 :
 6048 :
 6052 :
 6053 :
 6054 :
 6055 :
 6056 :
 6057 :
 6058 :
 6059 :
 6060 :
 6061 :
 6062 :
 6063 :
 6071 :
 6072 :

ML11 TRANSFER COMMANDS

4084 routine CHOOSE =
 4085 begin

4086
 4087
 4088 ROUTINE: CHOOSE

4089
 4090 PURPOSE: TO DECIDE WHETHER TO DO A 'WRITE CHECK' OR A 'READ'.
 4091 THE 'READ' WILL BE SELECTED APPROXIMATELY 25% OF THE
 4092 TIME. THIS IS ACCOMPLISHED BY EXAMINING THE MOST AND
 4093 THE LEAST SIGNIFICANT BITS OF A RANDOM NUMBER. IF
 4094 BOTH ARE SET, THEN 'READ' IS CHOSEN.

4095
 4096 RESULTS: THE VALUE RETURNED FOR THIS ROUTINE IS THE ADDRESS OF
 4097 THE CHOSEN COMMAND (EITHER 'READ' OR 'CHECK').
 4098

4099
 4100 Local
 4101 VALUE;

4102
 4103 RN ();

4104
 4105 if ((.RANDOM) and (.RANDOM lss 0))
 4106 then

4107 VALUE = read !CHOOSE THE READ COMMAND

4108 else !CHOOSE THE WRITE CHECK COMMAND
 4109 VALUE = CHECK;

4110
 4111 return .VALUE;
 4112 end;

.SBTTL CHOOSE ML11 TRANSFER COMMANDS

CHOOSE: JSR PC,RN
 BIT #1,RANDOM
 BEQ 1\$
 TST RANDOM
 BGE 1\$
 MOV #READ,RO
 RTS PC
 1\$: MOV #CHECK,RO
 RTS PC

4103
 4105
 4107
 4105
 4109
 4084

: Routine Size: 15 words
 : Maximum stack depth per invocation: 0 words

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(2:2)
PA:<NEALE>MLX4.BLI.5 (33)

6074 :MLX4
6075 :
6076 :
6077 : 4113
6078 : 4114
6079 : 4115
6080 : 4116
6081 : 4117
6082 : 4118
6083 : 4119
6084 : 4120
6085 : 4121
6086 : 4122
6087 : 4123
6088 : 4124
6089 : 4125
6090 : 4126
6091 : 4127
6092 : 4128
6093 : 4129
6094 : 4130
6095 : 4131
6096 : 4132
6097 : 4133
6098 : 4134
6099 : 4135
6100 : 4136
6101 : 4137
6102 : 4138
6103 : 4139
6104 : 4140
6105 : 4141
6106 : 4142
6107 : 4143
6108 : 4144
6109 : 4145
6110 : 4146
6111 : 4147
6112 : 4148
6113 : 4149
6114 : 4150
6115 : 4151
6116 : 4152
6117 : 4153
6118 : 4154
6119 : 4155
6120 : 4156
6121 : 4157
6122 : 4158
6123 : 4159
6124 : 4160
6125 : 4161
6126 : 4162
6127 : 4163
6128 : 4164

ML11 TRANSFER COMMANDS

routine RETRY (TIMES, COMMAND, LUN, WRDCNT, BUFFER, SECTOR) =
begin

!* 1 *

!++

ROUTINE: RETRY(TIMES,COMMAND,LUN,WRDCNT,BUFFER,SECTOR)

- PURPOSE:
- (1) IF THE OPERATOR HAS ALLOWED ERROR PRINTOUTS, AND IF THE RETRY IS NOT TO CATEGORIZE ERRORS, THEN SAY THAT THE RETRY IS BEGINNING.
 - (2) REISSUE THE WRITE, WRITE CHECK OR READ COMMAND UNTIL THE COMMAND SUCCEEDS OR UNTIL ALL PERMITTED RETRIES HAVE FAILED.
 - (3) IF A 'BEGIN RETRY' MESSAGE WAS PRINTED, THEN A FINAL MESSAGE ABOUT THE SUCCESS OR FAILURE OF THE RETRIES SHOULD ALSO BE PRINTED.
 - (4) INCREMENT THE RETRY COUNTER FOR EVERY RETRY DONE WHICH WAS NOT FOR ERROR CLASSIFICATION.

- ARGUMENTS:
- (1) TIMES - THE NUMBER OF RETRIES PERMITTED BEFORE IT IS CALLED A FAILURE.
 - (2) OTHER ARGUMENTS ARE THE SAME AS FOR 'START_IT' ROUTINE ABOVE.

RESULTS: THE VALUES RETURNED FOR THIS SUBROUTINE ARE THE SAME AS FOR THE SYSERR ROUTINE ABOVE.

!--

Label
LOOP;

Local
TEMP,
VALUE,
COUNT,
TBOARD,
TBANK;

!+

! THIS IS THE CODE FOR PURPOSE 1:
!--

RETRYING = ACTIVE;
if ((.TIMES neq 1) and (.ERROUT))
then
begin

!* 2 *

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (33)

```

6130 :MLX4
6131 :
6132 : ML11 TRANSFER COMMANDS
6133 : 4165 if .COMMAND eql write then PRINTB (SAY3, WRD2, WRD16, WRD18);
6134 : 4166 !BEGIN WRITE RETRY
6135 : 4167
6136 : 4168 if .COMMAND eql CHECK then PRINTB (SAY3, WRD2, PHR1, WRD18);
6137 : 4169 !BEGIN WRITE CHECK RETRY
6138 : 4170
6139 : 4171 if .COMMAND eql read then PRINTB (SAY3, WRD2, WRD17, WRD18);
6140 : 4172 !BEGIN READ RETRY
6141 : 4173
6142 : 4174 end:
6143 : 4175 !* 2 *
6144 : 4176
6145 : 4177
6146 : 4178 !+
6147 : 4179 ! THIS IS THE CODE FOR PURPOSE 2:
6148 : 4180 !-
6149 : 4181
6150 : 4182 LOOP :
6151 : 4183 begin
6152 : 4184 !* 3 *
6153 : 4185
6154 : 4186 incr KOUNT from 1 to .TIMES do
6155 : 4187 begin
6156 : 4188 !* 4 *
6157 : 4189 if .COMMAND eql write then VALUE = write (.LUN, .WRDCNT, .BUFFER, .SECTOR);
6158 : 4190
6159 : 4191 if .COMMAND eql CHECK
6160 : 4192 then
6161 : 4193 begin
6162 : 4194 write (.LUN, .WRDCNT, .BUFFER, .SECTOR);
6163 : 4195 VALUE = CHECK (.LUN, .WRDCNT, .BUFFER, .SECTOR);
6164 : 4196 end;
6165 : 4197
6166 : 4198 if .COMMAND eql read
6167 : 4199 then
6168 : 4200 begin
6169 : 4201 write (.LUN, .WRDCNT, (.BUFFER - BUFSIZ*2), .SECTOR);
6170 : 4202 VALUE = read (.LUN, .WRDCNT, .BUFFER, .SECTOR);
6171 : 4203 end;
6172 : 4204
6173 : 4205 !+
6174 : 4206 ! THIS IS THE CODE FOR PURPOSE 3:
6175 : 4207 !-
6176 : 4208
6177 : 4209 if .VALUE eql 0
6178 : 4210 then
6179 : 4211 begin
6180 : 4212 !THE RETRY WAS SUCCESSFUL
6181 : 4213 !* 5 *
6182 : 4214
6183 : 4215 if ((.TIMES neq 1) and (.ERROUT))
6184 : 4216 then
        begin
        PRINTB (SAY2, WRD18, WRD19);
        PRINTB (CRLF);
    
```

0186 :MLX4
6187 :
6188 :
6189 :
6190 :
6191 :
6192 :
6193 :
6194 :
6195 :
6196 :
6197 :
6198 :
6199 :
6200 :
6201 :
6202 :
6203 :
6204 :
6205 :
6206 :
6207 :
6208 :
6209 :
6210 :
6211 :
6212 :
6213 :
6214 :
6215 :
6216 :
6217 :
6218 :
6219 :
6220 :
6221 :
6222 :
6223 :
6224 :
6225 :
6226 :
6227 :
6228 :
6229 :
6230 :
6231 :
6232 :
6236 :
6237 :

ML11 TRANSFER COMMANDS

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (33)

```

      4217          !RETRY SUCCEEDED
      4218          end;
      4219
      4220          COUNT = .KOUNT;
      4221          Leave LOOP;
      4222          end;
      4223
      4224          end;
      4225
      4226          !+
      4227          ! FALLS THROUGH HERE IF ALL RETRIES FAILED:
      4228          !-
      4229
      4230          if ((.TIMES neq 1) and (.ERRORT))
      4231          then
      4232              begin
      4233                  PRINTB (SAY2, WRD18, WRD20);
      4234
      4235          ! VER CZMLBB COMMENTED OUT THIS PRINT CRLF
      4236          PRINTB (CRLF);
      4237          !RETRY FAILED
      4238          COUNT = .TIMES;
      4239          end;
      4240
      4241          end;
      4242
      4243          !+
      4244          ! THIS IS THE CODE FOR PURPOSE 4:
      4245          !-
      4246
      4247          if .TIMES neq 1
      4248          then
      4249              begin
      4250                  TBOARD = .BOARD;
      4251                  TBANK = .BANK;
      4252                  DECODE (.SECTOR);
      4253                  TRIES [.LUN, .BOARD, 0, 16, 0] = .TRIES [.LUN, .BOARD, 0, 16, 0] + .COUNT;
      4254                  BOARD = .TBOARD;
      4255                  BANK = .TBANK;
      4256                  end;
      4257
      4258          RETRYING = INACTIVE;
      4259          return .VALUE;
      4260          end;

```

!* 5 *

!* 4 *

!* 3 *

!* 1 *

.SBTTL RETRY ML11 TRANSFER COMMANDS

Address	Hex	Hex	Hex	Label	Command	Comments	Time	Page
6242				:MLX4			27-Mar-1982 19:24:42	TOPS
6243				:			27-Mar-1982 19:23:44	PA:<
6244					ML11 TRANSFER COMMANDS			
6245	046224	004167	137104	RETRY:	JSR R1,\$SAVE5			4113
6246	046230	012767	000001	166102	MOV #1,RETRYING			4159
6247	046236	016601	000030		MOV 30(SP),R1			4161
6248	046242	005046			CLR -(SP)	TIMES,*		
6249	046244	020127	000001		CMP R1,#1			
6250	046250	001472			BEQ 3\$			
6251	046252	005216			INC (SP)			
6252	046254	032767	000001	133776	BIT #1,ERROUT			
6253	046262	001465			BEQ 3\$			
6254	046264	016602	000030		MOV 30(SP),R2	COMMAND,*		4165
6255	046270	020227	045424		CMP R2,#WRITE			
6256	046274	001016			BNE 1\$			
6257	046276	012746	007272		MOV #WORD18,-(SP)			
6258	046302	012746	007256		MOV #WORD16,-(SP)			
6259	046305	012746	007200		MOV #WORD2,-(SP)			
6260	046312	012746	007112		MOV #SAY3,-(SP)			
6261	046316	012746	000004		MOV #4,-(SP)			
6262	046322	010600			MOV SP,R0	SP,*		
6263	046324	104414			TRAP 14			
6264	046326	062706	000012		ADD #12,SP			
6265	046332	020227	046000	1\$:	CMP R2,#CHECK			4169
6266	046336	001016			BNE 2\$			
6267	046340	012746	007272		MOV #WORD18,-(SP)			
6268	046344	012746	007714		MOV #PHR1,-(SP)			
6269	046350	012746	007200		MOV #WORD2,-(SP)			
6270	046354	012746	007112		MOV #SAY3,-(SP)			
6271	046360	012746	000004		MOV #4,-(SP)			
6272	046364	010600			MOV SP,R0	SP,*		
6273	046366	104414			TRAP 14			
6274	046370	062706	000012		ADD #12,SP			
6275	046374	020227	045612	2\$:	CMP R2,#READ			4173
6276	046400	001016			BNE 3\$			
6277	046402	012746	007272		MOV #WORD18,-(SP)			
6278	046406	012746	007264		MOV #WORD17,-(SP)			
6279	046412	012746	007200		MOV #WORD2,-(SP)			
6280	046416	012746	007112		MOV #SAY3,-(SP)			
6281	046422	012746	000004		MOV #4,-(SP)			
6282	046426	010600			MOV SP,R0	SP,*		
6283	046430	104414			TRAP 14			
6284	046432	062706	000012		ADD #12,SP			
6285	046436	016602	000030	3\$:	MOV 30(SP),R2	COMMAND,*		4188
6286	046442	005004			CLR R4	KOUNT		4185
6287	046444	000543			BR 9\$			
6288	046446	020227	045424	4\$:	CMP R2,#WRITE			4188
6289	046452	001015			BNE 5\$			
6290	046454	016646	000026		MOV 26(SP),-(SP)	LUN,*		
6291	046460	016646	000026		MOV 26(SP),-(SP)	WRDCNT,*		
6292	046464	016646	000026		MOV 26(SP),-(SP)	BUFFER,*		
6293	046470	016646	000026		MOV 26(SP),-(SP)	SECTOR,*		
6294	046474	004767	176724		JSR PC,WRITE			
6295	046500	010003			MOV R0,R3	*.VALUE		
6296	046502	062706	000010		ADD #10,SP			

Address	Hex	Hex	Hex	Label	Command	Comments	Address
6298				:MLX4			
6299				:			
6300					ML11 TRANSFER COMMANDS		
6301	046506	020227	046000	5\$:	CMP R2,#CHECK		
6302	046512	001027			BNE 6\$		4190
6303	046514	016646	000026		MOV 26(SP),-(SP)	: LUN,*	
6304	046520	016646	000026		MOV 26(SP),-(SP)	: WRDCNT,*	4193
6305	046524	016646	000026		MOV 26(SP),-(SP)	: BUFFER,*	
6306	046530	016646	000026		MOV 26(SP),-(SP)	: SECTOR,*	
6307	046534	004767	176664		JSR PC,WRITE		
6308	046540	016616	000036		MOV 36(SP),(SP)	: LUN,*	4194
6309	046544	016646	000034		MOV 34(SP),-(SP)	: WRDCNT,*	
6310	046550	016646	000034		MOV 34(SP),-(SP)	: BUFFER,*	
6311	046554	016646	000034		MOV 34(SP),-(SP)	: SECTOR,*	
6312	046560	004767	177214		JSR PC,CHECK		
6313	046564	010003			MOV R0,R3	: *.VALUE	
6314	046566	062706	000016		ADD #16,SP		
6315	046572	020227	045612	6\$:	CMP R2,#READ		4192
6316	046576	001031			BNE 7\$		4197
6317	046600	016646	000026		MOV 26(SP),-(SP)	: LUN,*	
6318	046604	016646	000026		MOV 26(SP),-(SP)	: WRDCNT,*	4200
6319	046610	016646	000026		MOV 26(SP),-(SP)	: BUFFER,*	
6320	046614	162716	010000		SUB #10000,(SP)		
6321	046620	016646	000026		MOV 26(SP),-(SP)	: SECTOR,*	
6322	046624	004767	17574		JSR PC,WRITE		
6323	046630	016616	000036		MOV 36(SP),(SP)	: LUN,*	4201
6324	046634	016646	000034		MOV 34(SP),-(SP)	: WRDCNT,*	
6325	046640	016646	000034		MOV 34(SP),-(SP)	: BUFFER,*	
6326	046644	016646	000034		MOV 34(SP),-(SP)	: SECTOR,*	
6327	046650	004767	176736		JSR PC,READ		
6328	046654	010003			MOV R0,R3	: *.VALUE	
6329	046656	062706	000016		ADD #16,SP		
6330	046662	005703		7\$:	TST R3	: VALUE	4199
6331	046664	001033			BNE 9\$		4208
6332	046666	032716	000001		BIT #1,(SP)		
6333	046672	001426			BEQ 8\$		4212
6334	046674	032767	000001	133356	BIT #1,ERROUT		
6335	046702	001422			BEQ 8\$		
6336	046704	012746	007300		MOV #WRD19,-(SP)		
6337	046710	012746	007272		MOV #WRD18,-(SP)		4215
6338	046714	012746	007100		MOV #SAY2,-(SP)		
6339	046720	012746	000003		MOV #3,-(SP)		
6340	046724	010600			MOV SP,R0	: SP,*	
6341	046726	104414			TRAP 14		
6342	046730	012716	007066		MOV #CRLF,(SP)		
6343	046734	012746	000001		MOV #1,-(SP)		4216
6344	046740	010600			MOV SP,R0	: SP,*	
6345	046742	104414			TRAP 14		
6346	046744	062706	000012		ADD #12,SP		
6347	046750	010405		8\$:	MOV R4,R5	: KOUNT,COUNT	4214
6348	046752	000427			BR 10\$		4220
6349	046754	005204		9\$:	INC R4	: KOUNT	4221
6350	046756	020401			CMP R4,R1	: KOUNT,*	4185
6351	046760	003632			BLE 4\$		
6352	046762	032716	000001		BIT #1,(SP)		4230

Address	Hex	Hex	Hex	Hex	Label	Code	Comments	Address
6354					:MLX4			
6355					:			
6356						ML11 TRANSFER COMMANDS		
6357	046766	001454				BEQ	11\$	
6358	046770	032767	000001	133262		BIT	#1,ERROUT	
6359	046776	001415				BEQ	10\$	
6360	047000	012746	007312			MOV	#WRD20,-(SP)	:
6361	047004	012746	007272			MOV	#WRD18,-(SP)	4233
6362	047010	012746	007100			MOV	#SAY2,-(SP)	
6363	047014	012746	000003			MOV	#3,-(SP)	
6364	047020	010600				MOV	SP,R0	: SP,*
6365	047022	104414				TRAP	14	
6366	047024	010105				MOV	R1,R5	: *,COUNT
6367	047026	062706	000010			ADD	#10,SP	4238
6368	047032	032716	000001		10\$:	BIT	#1,(SP)	4232
6369	047036	001430				BEQ	11\$	4247
6370	047040	016701	165276			MOV	BOARD,R1	: *,TBOARD
6371	047044	016702	165274			MOV	BANK,R2	: *,TBANK
6372	047050	016646	000020			MOV	20(SP),-(SP)	4251
6373	047054	004767	170116			JSR	PC,DECODE	: SECTOR,*
6374	047060	016600	000030			MOV	30(SP),R0	: LUN,*
6375	047064	006300				ASL	R0	4253
6376	047066	006300				ASL	R0	
6377	047070	006300				ASL	R0	
6378	047072	006300				ASL	R0	
6379	047074	066700	165242			ADD	BOARD,R0	
6380	047100	006300				ASL	R0	
6381	047102	060560	033714			ADD	R5,TRIES(R0)	: COUNT,*
6382	047106	010167	165230			MOV	R1,BOARD	: TBOARD,*
6383	047112	010267	165226			MOV	R2,BANK	: TBANK,*
6384	047116	005726				TST	(SP)+	4254
6385	047120	005067	165214		11\$:	CLR	RETRYING	4249
6386	047124	010300				MOV	R3,R0	4258
6387	047126	005726				TST	(SP)+	4114
6388	047130	000207				RTS	PC	4113
6389								
6390								
6391								
6396								
6397								

: Routine Size: 227 words
 : Maximum stack depth per invocation: 14 words

```

6399 :MLX4
6400 :
6401 : TO SET UP BUFFER POINTERS BEFORE A TRANSFER 27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
6402 : 4261 %sbttl 'TO SET UP BUFFER POINTERS BEFORE A TRANSFER' 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (34)
6403 : 4262 routine SET_PTRS (WRDCNT) : novalue =
6404 : 4263 begin
6405 : 4264
6406 : 4265
6407 : 4266
6408 : 4267
6409 : 4268
6410 : 4269
6411 : 4270
6412 : 4271
6413 : 4272
6414 : 4273
6415 : 4274
6416 : 4275
6417 : 4276
6418 : 4277
6419 : 4278
6420 : 4279
6421 : 4280
6422 : 4281
6423 : 4282
6424 : 4283
6425 : 4284
6426 : 4285
  
```

```

!--
ROUTINE: SET_PTRS(WRDCNT)
PURPOSE: TO MAKE SURE THAT THE BUFFER POINTERS ARE SUITABLY PLACED
BEFORE A TRANSFER, SO THAT THEY WILL SUPPORT THE CHOSEN WORD
COUNT WITHIN THE BUFFER SPACE.
ARGUMENT: WRDCNT = THE NUMBER OF WORDS IN A TRANSFER.
RESULTS: 'WPTR' AND 'RPTR' ARE SET BACK TO THE START OF THE BUFFERS
ONLY IF THE WORD COUNT WON'T FIT. OTHERWISE, THEY ARE LEFT
UNCHANGED.
NOTE: THE WRITE BUFFER IS LOCATED BEFORE THE READ BUFFER.
--
  
```

```

if (.WPTR + .WRDCNT*2) geqa END_WBUFF then WPTR = WBUFF;
RPTR = .WPTR + (BUFSIZ*2);
return;
end;
  
```

```

6431
6435 047132 .SBTTL SET_PTRS TO SET UP BUFFER POINTERS BEFORE A TRANSFER
6436 047132 016600 000002 SET_PTRS:
6437 047136 006300 163524 MOV 2(SP),R0 ; WRDCNT,* 4281
6438 047140 066700 163524 ASL R0
6439 047144 020027 022670 ADD WPTR,R0
6440 047150 103403 012670 CMP R0,#END.WBUFF
6441 047152 012767 012670 163510 BLO 1$
6442 047160 016700 163504 1$: MOV #WBUFF,WPTR
6443 047164 062700 010000 MOV WPTR,R0 ; 4283
6444 047170 010067 163476 ADD #10000,R0
6445 047174 000207 RTS R0,RPTR ;
6446 : 4262
6447 :
6448 : Routine Size: 18 words
: Maximum stack depth per invocation: 0 words
  
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (35)

```

6454 :MLX4
6455 :
6456 :
6457 :      4286 %sbttl 'CHOOSING A WORD COUNT'
6458 :      4287 routine GET_WRCNT (SECTOR, LAST) =
6459 :      4288     begin
6460 :      4289
6461 :      4290     local
6462 :      4291     TEMP,
6463 :      4292     WRDCNT;
6464 :      4293
6465 :      4294     TEMP = .LAST - .SECTOR + 1;
6466 :      4295
6467 :      4296     !
6468 :      4297     ! version czmlbb changed gtr to gtru
6469 :      4298     !
6470 :      4299     if (BUFSIZ/256) gtru .TEMP
6471 :      4300     then
6472 :      4301     WRDCNT = .TEMP*256
6473 :      4302     else
6474 :      4303     WRDCNT = BUFSIZ;
6475 :      4304
6476 :      4305     return .WRDCNT;
6477 :      4306     end;
6481 :
6482 :

```

!NUMBER OF SECTORS LEFT TO TEST
 !LESS THAN A FULL BUFFER LEFT?
 !YES -- USE AS LARGE A COUNT AS FITS
 !NO -- USE THE ENTIRE BUFFER SIZE

6486	047176	016600	000002	GET.WRCNT:	.SBTTL	GET.WRCNT CHOOSING A WORD COUNT		
6487	047176	166600	000004	MOV	2(SP),RO	:	LAST,*	4294
6488	047202	005200		SUB	4(SP),RO	:	SECTOR,*	
6489	047206	020027	000010	INC	RO	:		
6490	047210	103003		CMP	RO,#10	:	TEMP,*	4299
6491	047214	000300		BHIS	1\$:		
6492	047216	105000		SWAB	RO	:		4301
6493	047220	000207		CLRB	RO	:		
6494	047222	012700	004000	RTS	PC	:		4299
6495	047224	000207		1\$: MOV	#4000,RO	:	*,WRCNT	4303
6496	047230			RTS	PC	:		4287

: Routine Size: 14 words
 : Maximum stack depth per invocation: 0 words

6498
 6499
 6504
 6505

6507 :MLX4
 6508 :
 6509 :
 6510 :
 6511 :
 6512 :
 6513 :
 6514 :
 6515 :
 6516 :
 6517 :
 6518 :
 6519 :
 6520 :
 6521 :
 6522 :
 6523 :
 6524 :
 6525 :
 6526 :
 6527 :
 6528 :
 6529 :
 6530 :
 6531 :
 6532 :
 6533 :
 6534 :
 6535 :
 6536 :
 6537 :
 6538 :
 6539 :
 6540 :
 6541 :
 6542 :
 6543 :
 6544 :
 6545 :
 6546 :
 6547 :
 6548 :
 6549 :
 6550 :
 6551 :
 6552 :
 6553 :
 6554 :
 6555 :
 6556 :
 6557 :
 6558 :
 6559 :
 6560 :
 6561 :

COMMAND INTEGRITY ROUTINE

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (36)

Zsbttl 'COMMAND INTEGRITY ROUTINE'
 routine INTEGRITY : novalue =
 begin

!* 1 * START OF ROUTINE

!++

ROUTINE: INTEGRITY

PURPOSE: TO MAKE SURE THAT THE BASIC ML11 TRANSFER COMMANDS
 WHICH WILL BE USED BY THE EXERCISER (WRITE,READ,
 WRITE CHECK) WORK PROPERLY.

THE CODE FOR 'INTEGRITY' IN BRIEF:

```

BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COMPLEMENT FLAG FROM 0 TO 1
: BEGIN 2 (START OF COMPLEMENT FLAG SELECTION LOOP)
: GENERATE THE PATTERN
: INCR LOGICAL UNIT NUMBER FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : SECTOR = LOWEST
: : : : GET WRDCNT
: : : : WRITE
: : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : READ
: : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : WRITE CHECK
: : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : : END 4 (END OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
: : END 2 (END OF COMPLEMENT FLAG SELECTION LOOP)
RETURN
END 1 (END OF ROUTINE)
    
```

label
 LOOP;

local
 VALUE,
 WRDCNT,
 OLDSEC,
 OLDCHN,
 SECTOR,
 DBL_VALUE;

4358

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 v2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (36)

```

6563 :MLX4
6564 :
6565 :
6566 :
6567 :
6568 :
6569 :
6570 :
6571 :
6572 :
6573 :
6574 :
6575 :
6576 :
6577 :
6578 :
6579 :
6580 :
6581 :
6582 :
6583 :
6584 :
6585 :
6586 :
6587 :
6588 :
6589 :
6590 :
6591 :
6592 :
6593 :
6594 :
6595 :
6596 :
6597 :
6598 :
6599 :
6600 :
6601 :
6602 :
6603 :
6604 :
6605 :
6606 :
6607 :
6608 :
6609 :
6610 :
6611 :
6612 :
6613 :
6614 :
6615 :
6616 :
6617 :
    COMMAND INTEGRITY ROUTINE
    PRINTB (SAY2, WRD34, RTNO);
    !'RUNNING COMMAND INTEGRITY ROUTINE'
    incr COMP_FLAG from 0 to 1 do
    begin
    GEN3 (.COMP_FLAG);
    !* 2 * START OF COMPLEMENT FLAG SELECTION LOOP
    incr LUN from 0 to (.LSUNIT - 1) do
    begin
    LOOP :
    begin
    !* 3 * START OF LOGICAL UNIT SELECTION LOOP
    !* 4 * START OF LOOP THAT COMPLETELY TESTS 1 UNIT
    if .DRIVE_STATUS [.LUN] eql ACTIVE
    then
    begin
    !* 5 * START OF TEST FOR AN ACTIVE UNIT
    L$LUN = .LUN;
    SECTOR = LOWEST;
    WRDCNT = GET_WRDCNT (.SECTOR, HIGHEST);
    VALUE = write (.LUN, .WRDCNT, WBUFF, LOWEST);
    !+
    !- SEE HOW SUCCESSFUL THE WRITE WAS:
    !-
    selectone .VALUE of
    set
    !SEE 'SYSERR' FOR DEFINITION
    !OF ERROR # CONTAINED IN 'VALUE'
    [1] :
    begin
    !* 5A * RETRY ALLOWED
    if RETRY (SIX, write, .LUN, .WRDCNT, WBUFF, LOWEST) neq 0
    then
    !THE RETRY FAILED -- SYSTEM FATAL ERROR
    begin
    WHY DROPT [.LUN] = CODE_4;
    ERRDF (1, MSG1, 0); !*** INTEGRITY ROUTINE ERROR 01 ***
    DODU (.LUN);
    leave LOOP;
    !JUMP JUST BEYOND END OF BLOCK * 4 *
    end;
    end;
    !* 5A *
    [2] :
    begin
    !* 5B * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
    WHY DROPT [.LUN] = CODE_5;
    ERRDF (2, MSG1, 0); !**** INTEGRITY ROUTINE ERROR 02 ****
    DODU (.LUN);
    leave LOOP;
    !JUMP JUST BEYOND END OF BLOCK * 4 *
    end;
    !* 5B *
    [3] :
    begin
    !* 5C * FATAL DRIVE ERROR -- NO RETRY ALLOWED
    ERRDF (3, MSG1, 0); !**** INTEGRITY ROUTINE ERROR 03 ****
    
```

```

6619 :MLX4
6620 :
6621 :
6622 : 4411
6623 : 4412
6624 : 4413
6625 : 4414
6626 : 4415
6627 : 4416
6628 : 4417
6629 : 4418
6630 : 4419
6631 : 4420
6632 : 4421
6633 : 4422
6634 : 4423
6635 : 4424
6636 : 4425
6637 : 4426
6638 : 4427
6639 : 4428
6640 : 4429
6641 : 4430
6642 : 4431
6643 : 4432
6644 : 4433
6645 : 4434
6646 : 4435
6647 : 4436
6648 : 4437
6649 : 4438
6650 : 4439
6651 : 4440
6652 : 4441
6653 : 4442
6654 : 4443
6655 : 4444
6656 : 4445
6657 : 4446
6658 : 4447
6659 : 4448
6660 : 4449
6661 : 4450
6662 : 4451
6663 : 4452
6664 : 4453
6665 : 4454
6666 : 4455
6667 : 4456
6668 : 4457
6669 : 4458
6670 : 4459
6671 : 4460
6672 : 4461
6673 : 4462

COMMAND INTEGRITY ROUTINE
                                27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
                                27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLT.5 (36)

                                WHY DROPT [.LUN] = CODE_6:
                                DODD (.LUN);
                                leave LOOP;
                                end;
                                !JUMP JUST BEYOND END OF BLOCK * 4 *
                                !* 5C *
tes;

VALUE = read (.LUN, .WRDCNT, RBUFF, LOWEST);

!+
!- SEE HOW SUCCESSFUL THE READ WAS:

selectone .VALUE of
set
                                !SEE 'SYSERR' FOR DEFINITION
                                !OF ERROR # CONTAINED IN 'VALUE'

[0] :
                                if (DBL_VALUE = DOUBLE_CHECK (WBUFF, RBUFF, .WRDCNT)) neq 0
                                then
                                begin
                                SAYWHO (.LUN);
                                PRINTB (SAY1, MSG5);
                                !'ECC LOGIC FAILED TO DETECT DATA ERROR'
                                PRINTB (FMT12A, ..DBL VALUE, .DBL VALUE);
                                !'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
                                DBL VALUE = .DBL VALUE + BUFSIZ*2;
                                PRINTB (FMT12B, ..DBL VALUE, .DBL VALUE);
                                !'BAD DATA: PPPPPP AT LOCATION QQQQQQ'
                                WHY DROPT [.LUN] = CODE_8;
                                ERRDF (4, MSG1, 0); !*** INTEGRITY ROUTINE ERROR 04 ***
                                DODU (.LUN);
                                leave LOOP;
                                end;
                                !JUMP JUST BEYOND END OF BLOCK * 4 *

[1] :
                                begin
                                !* 5D * RETRY ALLOWED
                                if RETRY (SIX, read, .LUN, .WRDCNT, RBUFF, LOWEST) neq 0
                                then
                                !THE RETRY FAILED -- SYSTEM FATAL ERROR
                                begin
                                WHY DROPT [.LUN] = CODE_4;
                                ERRDF (5, MSG1, 0); !*** INTEGRITY ROUTINE ERROR 05 ***
                                DODU (.LUN);
                                leave LOOP;
                                end;
                                !JUMP JUST BEYOND END OF BLOCK * 4 *

                                end;
                                !* 5D *

[2] :
                                begin
                                !* 5E * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
                                WHY DROPT [.LUN] = CODE_5;
                                ERRDF (6, MSG1, 0); !*** INTEGRITY ROUTINE ERROR 06 ***
    
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (36)

```

6675 :MLX4
6676 :
6677 :
6678 : 4463
6679 : 4464
6680 : 4465
6681 : 4466
6682 : 4467
6683 : 4468
6684 : 4469
6685 : 4470
6686 : 4471
6687 : 4472
6688 : 4473
6689 : 4474
6690 : 4475
6691 : 4476
6692 : 4477
6693 : 4478
6694 : 4479
6695 : 4480
6696 : 4481
6697 : 4482
6698 : 4483
6699 : 4484
6700 : 4485
6701 : 4486
6702 : 4487
6703 : 4488
6704 : 4489
6705 : 4490
6706 : 4491
6707 : 4492
6708 : 4493
6709 : 4494
6710 : 4495
6711 : 4496
6712 : 4497
6713 : 4498
6714 : 4499
6715 : 4500
6716 : 4501
6717 : 4502
6718 : 4503
6719 : 4504
6720 : 4505
6721 : 4506
6722 : 4507
6723 : 4508
6724 : 4509
6725 : 4510
6726 : 4511
6727 : 4512
6728 : 4513
6729 : 4514

COMMAND INTEGRITY ROUTINE

DODU (.LUN);
leave LOOP;
end;
!* 5E *

[3] :
begin
ERRDF (7, MSG1, 0);
WHY_DROPT [.LUN] = CODE_6;
DODU (.LUN);
leave LOOP;
end;
!* 5F * FATAL DRIVE ERROR -- NO RETRY ALLOWED
!*** INTEGRITY ROUTINE ERROR 07 ***

[4] :
begin
ISOLATE ();
ERRDF (8, MSG2, 0);
WHY_DROPT [.LUN] = CODE_7;
DODU (.LUN);
leave LOOP;
end;
!* 5G * UNRECOVERABLE DATA ERROR
!*** INTEGRITY ROUTINE ERROR 08 ***

[5] :
begin
ISOLATE ();
!* 5H * RECOVERABLE DATA ERROR

if .ERROUT then PRINTB (FMT10B, .CHAN);

!* BIT 00'
OLDSEC = .MLEL;
OLDCHN = .CHAN;

if RETRY (ONE, read, .LUN, .WRDCNT, RBUFF, LOWEST) eql 5
then
    if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
    then
        begin
            if .ERROUT then ERRHRD (9, MSG4, 0);

            UP_HARD_COUNT (.LUN, .BOARD);
            !*** INTEGRITY ROUTINE ERROR 09 ***
        end
    else
        begin
            if .ERROUT then ERRSOFT (10, MSG3, 0);

            UP_SOFT_COUNT (.LUN, .BOARD);
            !*** INTEGRITY ROUTINE ERROR 10 ***
        end
    end
end
    
```

6731 :MLX4
 6732 :
 6733 :
 6734 : 4515
 6735 : 4516
 6736 : 4517
 6737 : 4518
 6738 : 4519
 6739 : 4520
 6740 : 4521
 6741 : 4522
 6742 : 4523
 6743 : 4524
 6744 : 4525
 6745 : 4526
 6746 : 4527
 6747 : 4528
 6748 : 4529
 6749 : 4530
 6750 : 4531
 6751 : 4532
 6752 : 4533
 6753 : 4534
 6754 : 4535
 6755 : 4536
 6756 : 4537
 6757 : 4538
 6758 : 4539
 6759 : 4540
 6760 : 4541
 6761 : 4542
 6762 : 4543
 6763 : 4544
 6764 : 4545
 6765 : 4546
 6766 : 4547
 6767 : 4548
 6768 : 4549
 6769 : 4550
 6770 : 4551
 6771 : 4552
 6772 : 4553
 6773 : 4554
 6774 : 4555
 6775 : 4556
 6776 : 4557
 6777 : 4558
 6778 : 4559
 6779 : 4560
 6780 : 4561
 6781 : 4562
 6782 : 4563
 6783 : 4564
 6784 : 4565
 6785 : 4566

COMMAND INTEGRITY ROUTINE

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (36)

```

else
begin
if .ERRORT then ERRSOFT (11, MSG3, 0);

UP_SOFT_COUNT (.LUN, .BOARD);
end;

end;          !* 5H *
tes;

VALUE = CHECK (.LUN, .WRDCNT, WBUFF, LOWEST);

!+
SEE HOW SUCCESSFUL THE WRITE CHECK WAS:
!-

selectone .VALUE of
set          !SEE 'SYSERR' FOR DEFINITION
            !OF ERROR # CONTAINED IN 'VALUE'

[1] :
begin      !* 5I * RETRY ALLOWED
if RETRY (SIX, CHECK, .LUN, .WRDCNT, WBUFF, LOWEST) neg 0
then
begin
WHY DROPT [.LUN] = CODE_4;
ERRDF (12, MSG1, 0);      !**** INTEGRITY ROUTINE ERROR 12 ****
DODU (.LUN);
leave LOOP;              !JUMP JUST BEYOND END OF BLOCK * 4 *
end;

end;          !* 5I *

[2] :
begin      !* 5J * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
WHY DROPT [.LUN] = CODE_5;
ERRDF (13, MSG1, 0);      !**** INTEGRITY ROUTINE ERROR 13 ****
DODU (.LUN);
leave LOOP;              !JUMP JUST BEYOND END OF BLOCK * 4 *
end;          !* 5J *

[3] :
begin      !* 5K * FATAL DRIVE ERROR -- NO RETRY ALLOWED
ERRDF (14, MSG1, 0);      !**** INTEGRITY ROUTINE ERROR 14 ****
WHY DROPT [.LUN] = CODE_6;
DODD (.LUN);
leave LOOP;              !JUMP JUST BEYOND END OF BLOCK * 4 *
end;          !* 5K *

[4] :
    
```



```

6787 :MLX4
6788 :
6789 :
6790 : 4567
6791 : 4568
6792 : 4569
6793 : 4570
6794 : 4571
6795 : 4572
6796 : 4573
6797 : 4574
6798 : 4575
6799 : 4576
6800 : 4577
6801 : 4578
6802 : 4579
6803 : 4580
6804 : 4581
6805 : 4582
6806 : 4583
6807 : 4584
6808 : 4585
6809 : 4586
6810 : 4587
6811 : 4588
6812 : 4589
6813 : 4590
6814 : 4591
6815 : 4592
6816 : 4593
6817 : 4594
6818 : 4595
6819 : 4596
6820 : 4597
6821 : 4598
6822 : 4599
6823 : 4600
6824 : 4601
6825 : 4602
6826 : 4603
6827 : 4604
6828 : 4605
6829 : 4606
6830 : 4607
6831 : 4608
6832 : 4609
6833 : 4610
6834 : 4611
6835 : 4612
6836 : 4613
6837 : 4614
6838 : 4615
6839 : 4616
6840 : 4617
6841 : 4618

COMMAND INTEGRITY ROUTINE

begin
ISOLATE ();
ERRDF (15, MSG2, 0);
WHY DROPT [.LUN] = CODE_7;
DODU (.LUN);
leave LOOP;
end;
!* 5L * UNRECOVERABLE DATA ERROR
!**** INTEGRITY ROUTINE ERROR 15 ****
!JUMP JUST BEYOND END OF BLOCK * 4 *
!* 5L *

[5] :
begin
ISOLATE ();
!* 5M * RECOVERABLE DATA ERROR

if .ERROUT then PRINTB (FMT10B, .CHAN);

!' BIT 00'
OLDSEC = .MLEL;
OLDCHN = .CHAN;

if RETRY (ONE, CHECK, .LUN, .WRDCNT, WBUFF, LOWEST) eql 5
then
    if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
    then
        begin
            if .ERROUT then ERRHRD (16, MSG4, 0);

            UP_HARD_COUNT (.LUN, .BOARD);
            end
        else
            begin
                if .ERROUT then ERRSOFT (17, MSG3, 0);

                UP_SOFT_COUNT (.LUN, .BOARD);
                end
            else
                begin
                    if .ERROUT then ERRSOFT (18, MSG3, 0);

                    UP_SOFT_COUNT (.LUN, .BOARD);
                    end
                end;
            tes;
        end;
    end;
end;
!* 5 * END OF TEST FOR AN ACTIVE DRIVE
    
```

```

6843 :MLX4
6844 :
6845 :
6846 : 4619
6847 : 4620
6848 : 4621
6849 : 4622
6850 : 4623
6851 : 4624
6852 : 4625
6853 : 4626
6857 :
6858 :
  
```

COMMAND INTEGRITY ROUTINE

```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (36)

!* 4 * END OF LOOP THAT COMPLETELY TESTS 1 UNIT
!* 3 * END OF LOGICAL UNIT SELECTION LOOP

!* 2 * END OF COMPLEMENT FLAG SELECTION LOOP

!* 1 * END OF ROUTINE
  
```

.SBTTL INTEGRITY COMMAND INTEGRITY ROUTINE

Address	Hex	Dec	Hex	Dec	Label	Instruction	Comment	Address
6862	047232					INTEGRITY:		
6863	047232	004167	136076			JSR	R1,\$\$SAVE5	
6864	047236	162706	000012			SUB	#12,SP	4308
6865	047242	012746	007574			MOV	#RTNO,-(SP)	
6866	047246	012746	007344			MOV	#WRD34,-(SP)	4359
6867	047252	012746	007100			MOV	#SAY2,-(SP)	
6868	047256	012746	000003			MOV	#3,-(SP)	
6869	047262	010600				MOV	SP,R0	
6870	047264	104414				TRAP	14	: SP,*
6871	047266	005001				CLR	R1	: COMP.FLAG
6872	047270	010146			1\$:	MOV	R1,-(SP)	: COMP.FLAG,* 4362
6873	047272	004767	172170			JSR	PC,GEN3	4364
6874	047276	016766	132510	000020		MOV	L\$UNIT,20(SP)	
6875	047304	005004				CLR	R4	: LUN 4366
6876	047306	000167	002110			JMP	38\$	
6877	047312	010400			2\$:	MOV	R4,R0	: LUN,* 4371
6878	047314	006200				ASR	R0	
6879	047316	006200				ASR	R0	
6880	047320	006200				ASR	R0	
6881	047322	062700	034442			ADD	#DRIVE.STATUS,R0	
6882	047326	010046				MOV	R0,-(SP)	
6883	047330	010446				MOV	R4,-(SP)	: LUN,*
6884	047332	042716	177770			BIC	#177770,(SP)	
6885	047336	012746	000001			MOV	#1,-(SP)	
6886	047342	005046				CLR	-(SP)	
6887	047344	004767	135006			JSR	PC,BL\$GT2	
6888	047350	062706	000010			ADD	#10,SP	
6889	047354	005300				DEC	R0	
6890	047356	001117				BNE	6\$	
6891	047360	010467	132510			MOV	R4,L\$LUN	: LUN,* 4374
6892	047364	010400				MOV	R4,R0	: LUN,* 4375
6893	047366	006300				ASL	R0	
6894	047370	012702	034460			MOV	#LOW.SECT,R2	
6895	047374	060002				ADD	R0,R2	
6896	047376	011266	000022			MOV	(R2),22(SP)	: * SECTOR
6897	047402	016646	000022			MOV	22(SP),-(SP)	: SECTOR,* 4376

Address	Hex	Hex	Hex	Label	Command	Comments	Address
6899							
6900				:MLX4			
6901				:	COMMAND INTEGRITY ROUTINE		
6902	047406	016046	034500		MOV TOP,SECT(R0),-(SP)		
6903	047412	004767	177560		JSR PC,GET.WRDCNT		
6904	047416	010003			MOV R0,R3	: *,WRDCNT	
6905	047420	010416			MOV R4,(SP)	: LUN,*	4377
6906	047422	010346			MOV R3,-(SP)	: WRDCNT,*	
6907	047424	012746	012670		MOV #WBUF,-(SP)		
6908	047430	011246			MOV (R2),-(SP)		
6909	047432	004767	175766		JSR PC,WRITE		
6910	047436	010005			MOV R0,R5	: *,VALUE	
6911	047440	020527	000001		CMP R5,#1	: VALUE,*	4383
6912	047444	001031			BNE 3\$		
6913	047446	012746	000006		MOV #6,-(SP)		4389
6914	047452	012746	045424		MOV #WRITE,-(SP)		
6915	047456	010446			MOV R4,-(SP)	: LUN,*	
6916	047460	010346			MOV R3,-(SP)	: WRDCNT,*	
6917	047462	012746	012670		MOV #WBUF,-(SP)		
6918	047466	011246			MOV (R2),-(SP)		
6919	047470	004767	176530		JSR PC,RETRY		
6920	047474	062706	000014		ADD #14,SP		
6921	047500	005700			TST R0		
6922	047502	001446			BEQ 7\$		
6923	047504	112764	000004 034446		MOVB #4,WHY.DROPT(R4)	: *,*(LUN)	4392
6924	047512	104455			TRAP 55	:	4393
6925	047514	000001			.WORD 1		
6926	047516	011070			.WORD MSG1		
6927	047520	000000			.WORD 0		
6928	047522	010400			MOV R4,R0	: LUN,*	4394
6929	047524	104451			TRAP 51		
6930	047526	000431			BR 5\$		
6931	047530	020527	000002	3\$:	CMP R5,#2	: VALUE,*	4395
6932	047534	001012			BNE 4\$		4383
6933	047536	112764	000005 034446		MOVB #5,WHY.DROPT(R4)	: *,*(LUN)	4402
6934	047544	104455			TRAP 55	:	4403
6935	047546	000002			.WORD 2		
6936	047550	011070			.WORD MSG1		
6937	047552	000000			.WORD 0		
6938	047554	010400			MOV R4,R0	: LUN,*	4404
6939	047556	104451			TRAP 51		
6940	047560	000414			BR 5\$		
6941	047562	020527	000003	4\$:	CMP R5,#3	: VALUE,*	4405
6942	047566	001014			BNE 7\$		4383
6943	047570	104455			TRAP 55		
6944	047572	000003			.WORD 3		4410
6945	047574	011070			.WORD MSG1		
6946	047576	000000			.WORD 0		
6947	047600	112764	000006 034446		MOVB #6,WHY.DROPT(R4)	: *,*(LUN)	4411
6948	047606	010400			MOV R4,R0	: LUN,*	4412
6949	047610	104451			TRAP 51		
6950	047612	062706	000012	5\$:	ADD #12,SP		4413
6951	047616	000502		6\$:	BR 8\$		
6952	047620	010416		7\$:	MOV R4,(SP)	: LUN,*	4417
6953	047622	010346			MOV R3,-(SP)	: WRDCNT,*	

PS
:<
13
59
61

55

9

3

8
5
8

Address	Hex	Hex	Hex	Label	Command	Comments	Address
6955				:MLX4			
6956				:	COMMAND INTEGRITY ROUTINE		
6957							
6958	047624	012746	022670		MOV #RBUF,-(SP)		
6959	047630	011246			MOV (R2),-(SP)		
6960	047632	004767	175754		JSR PC,READ		
6961	047636	010005			MOV R0,R5	: *.VALUE	
6962	047640	001072			BNE 9\$:	
6963	047642	012746	012670		MOV #WBUF,-(SP)	:	4423
6964	047646	012746	022670		MOV #RBUF,-(SP)	:	4428
6965	047652	010346			MOV R3,-(SP)	: WRDCNT,*	
6966	047654	004767	174446		JSR PC,DOUBLE.CHECK		
6967	047660	062706	000006		ADD #6,SP		
6968	047664	010066	000032		MOV R0,32(SP)	: *.DBL.VALUE	
6969	047670	001477			BEQ 10\$		
6970	047672	010446			MOV R4,-(SP)	: LUN,*	4431
6971	047674	004767	165624		JSR PC,SAYWHO		
6972	047700	012716	011216		MOV #MSG5,(SP)		4432
6973	047704	012746	007072		MOV #SAY1,-(SP)		
6974	047710	012746	000002		MOV #2,-(SP)		
6975	047714	010600			MOV SP,R0	: SP,*	
6976	047716	104414			TRAP 14		
6977	047720	016616	000040		MOV 40(SP),(SP)	: DBL.VALUE,*	
6978	047724	017646	000040		MOV @40(SP),-(SP)	: DBL.VALUE,*	4434
6979	047730	012746	006710		MOV #FMT12A,-(SP)		
6980	047734	012746	000003		MOV #3,-(SP)		
6981	047740	010600			MOV SP,R0	: SP,*	
6982	047742	104414			TRAP 14		
6983	047744	062766	010000 000046		ADD #10000,46(SP)	: *.DBL.VALUE	4436
6984	047752	016616	000046		MOV 46(SP),(SP)	: DBL.VALUE,*	4437
6985	047756	017646	000046		MOV @46(SP),-(SP)	: DBL.VALUE,*	
6986	047762	012746	006756		MOV #FMT12B,-(SP)		
6987	047766	012746	000003		MOV #3,-(SP)		
6988	047772	010600			MOV SP,R0	: SP,*	
6989	047774	104414			TRAP 14		
6990	047776	112764	000010 034446		MOV #10,WHY.DROPT(R4)	: *,*(LUN)	4439
6991	050004	104455			TRAP 55	:	4440
6992	050006	000004			.WORD 4		
6993	050010	011070			.WORD MSG1		
6994	050012	000000			.WORD 0		
6995	050014	010400			MOV R4,R0	: LUN,*	4441
6996	050016	104451			TRAP 51		
6997	050020	062706	000042		ADD #42,SP		4442
6998	050024	000510		8\$:	BR 16\$		
6999	050026	020527	000001	9\$:	CMP R5,#1	: VALUE,*	4423
7000	050032	001033			BNE 12\$		
7001	050034	012746	000006		MOV #6,-(SP)		4448
7002	050040	012746	045612		MOV #READ,-(SP)		
7003	050044	010446			MOV R4,-(SP)	: LUN,*	
7004	050046	010346			MOV R3,-(SP)	: WRDCNT,*	
7005	050050	012746	022670		MOV #RBUF,-(SP)		
7006	050054	011246			MOV (R2),-(SP)		
7007	050056	004767	176142		JSR PC,RETRY		
7008	050062	062706	000014		ADD #14,SP		
7009	050066	005700			TST R0		

6
 PS
 :<
 90
 93
 94
 92
 97
 90
 91
 99
 98
 2
 5
 6
 4
 0
 1
 5
 0

Address	OpCode	Operand 1	Operand 2	Operand 3	Label	Instruction	Comments	Address
7011								
7012					:MLX4			
7013					:			
7014	050070	001002			10\$:	BNE 11\$		
7015	050072	000167	000520			JMP 24\$		
7016	050076	112764	000004	034446	11\$:	MOVB #4,WHY.DROPT(R4)	: *,*(LUN)	4451
7017	050104	104455				TRAP 55	:	4452
7018	050106	000005				.WORD 5	:	
7019	050110	011070				.WORD MSG1	:	
7020	050112	000000				.WORD 0	:	
7021	050114	010400				MOV R4,R0	: LUN,*	4453
7022	050116	104451				TRAP 51	:	
7023	050120	000450				BR 15\$:	4454
7024	050122	020527	000002		12\$:	CMP R5,#2	: VALUE,*	4423
7025	050126	001012				BNE 13\$:	
7026	050130	112764	000005	034446		MOVB #5,WHY.DROPT(R4)	: *,*(LUN)	4461
7027	050136	104455				TRAP 55	:	4462
7028	050140	000006				.WORD 6	:	
7029	050142	011070				.WORD MSG1	:	
7030	050144	000000				.WORD 0	:	
7031	050146	010400				MOV R4,R0	: LUN,*	4463
7032	050150	104451				TRAP 51	:	
7033	050152	000433				BR 15\$:	4464
7034	050154	020527	000003		13\$:	CMP R5,#3	: VALUE,*	4423
7035	050160	001012				BNE 14\$:	
7036	050162	104455				TRAP 55	:	4469
7037	050164	000007				.WORD 7	:	
7038	050166	011070				.WORD MSG1	:	
7039	050170	000000				.WORD 0	:	
7040	050172	112764	000006	034446		MOVB #6,WHY.DROPT(R4)	: *,*(LUN)	4470
7041	050200	010400				MOV R4,R0	: LUN,*	4471
7042	050202	104451				TRAP 51	:	
7043	050204	000416				BR 15\$:	4472
7044	050206	020527	000004		14\$:	CMP R5,#4	: VALUE,*	4423
7045	050212	001017				BNE 17\$:	
7046	050214	004767	167112			JSR PC,ISOLATE	:	4477
7047	050220	104455				TRAP 55	:	4478
7048	050222	000010				.WORD 10	:	
7049	050224	011120				.WORD MSG2	:	
7050	050226	000000				.WORD 0	:	
7051	050230	112764	000007	034446		MOVB #7,WHY.DROPT(R4)	: *,*(LUN)	4479
7052	050236	010400				MOV R4,R0	: LUN,*	4480
7053	050240	104451				TRAP 51	:	
7054	050242	062706	000020		15\$:	ADD #20,SP	:	4481
7055	050246	000167	001146		16\$:	JMP 37\$:	
7056	050252	020527	000005		17\$:	CMP R5,#5	: VALUE,*	4423
7057	050256	001157				BNE 24\$:	
7058	050260	004767	167046			JSR PC,ISOLATE	:	4486
7059	050264	032767	000001	131766		BIT #1,ERROUT	:	4488
7060	050272	001423				BEQ 18\$:	
7061	050274	017700	164110			MOV @ML.REG+42,R0	:	
7062	050300	006200				ASR R0	:	
7063	050302	006200				ASR R0	:	
7064	050304	006200				ASR R0	:	
7065	050306	006200				ASR R0	:	

Address	OpCode	Operand1	Operand2	Operand3	Operand4	Label	Instruction	Comments	Line No.
7123						:MLX4			
7124						:			
7125							COMMAND INTEGRITY ROUTINE		
7126	050540	032767	000001	131512	20\$:		BIT #1,ERROUT	:	
7127	050546	001415					BEQ 22\$:	4509
7128	050550	104457					TRAP 57		
7129	050552	000012					.WORD 12		
7130	050554	011166					.WORD MSG3		
7131	050556	000000					.WORD 0		
7132	050560	000410					BR 22\$:	
7133	050562	032767	000001	131470	21\$:		BIT #1,ERROUT	:	4512
7134	050570	001404					BEQ 22\$:	4518
7135	050572	104457					TRAP 57		
7136	050574	000013					.WORD 13		
7137	050576	011166					.WORD MSG3		
7138	050600	000000					.WORD 0		
7139	050602	010446			22\$:		MOV R4,-(SP)	: LUN,*	4521
7140	050604	016746	163532				MOV BOARD,-(SP)		
7141	050610	004767	167270				JSR PC,UP.SOFT.COUNT		
7142	050614	022626			23\$:		CMP (SP)+,(SP)+	:	4535
7143	050616	010416			24\$:		MOV R4,(SP)	: LUN,*	4527
7144	050620	010346					MOV R3,-(SP)	: WRDCNT,*	
7145	050622	012746	012670				MOV #WBUF,-(SP)		
7146	050626	011246					MOV (R2)-,(SP)		
7147	050630	004767	175144				JSR PC,CHECK		
7148	050634	010005					MOV R0,R5	: *,VALUE	
7149	050636	020527	000001				CMP R5,#1	: VALUE,*	4533
7150	050642	001031					BNE 25\$		
7151	050644	012746	000006				MOV #6,-(SP)	:	4539
7152	050650	012746	046000				MOV #CHECK,-(SP)		
7153	050654	010446					MOV R4,-(SP)	: LUN,*	
7154	050656	010346					MOV R3,-(SP)	: WRDCNT,*	
7155	050660	012746	012670				MOV #WBUF,-(SP)		
7156	050664	011246					MOV (R2)-,(SP)		
7157	050666	004767	175332				JSR PC,RETRY		
7158	050672	062706	000014				ADD #14,SP		
7159	050676	005700					TST R0		
7160	050700	001462					BEQ 28\$		
7161	050702	112764	000004	034446			MOVB #4,WHY.DROPT(R4)	: *,*(LUN)	4542
7162	050710	104455					TRAP 55	:	4543
7163	050712	000014					.WORD 14		
7164	050714	011070					.WORD MSG1		
7165	050716	000000					.WORD 0		
7166	050720	010400					MOV R4,R0	: LUN,*	4544
7167	050722	104451					TRAP 51		
7168	050724	000450					BR 28\$:	4545
7169	050726	020527	000002		25\$:		CMP R5,#2	: VALUE,*	4533
7170	050732	001012					BNE 26\$		
7171	050734	112764	000005	034446			MOVB #5,WHY.DROPT(R4)	: *,*(LUN)	4552
7172	050742	104455					TRAP 55	:	4553
7173	050744	000015					.WORD 15		
7174	050746	011070					.WORD MSG1		
7175	050750	000000					.WORD 0		
7176	050752	010400					MOV R4,R0	: LUN,*	4554
7177	050754	104451					TRAP 51		

Address	OpCode	Operand 1	Operand 2	Operand 3	Label	Instruction	Comments	Address
7179					:MLX4			
7180					:			
7181						COMMAND INTEGRITY ROUTINE		
7182	050756	000433				BR 26\$		
7183	050760	020527	000003		26\$:	CMP R5,#3	: VALUE,*	4555
7184	050764	001012				BNE 27\$		4533
7185	050766	104455				TRAP 55	:	
7186	050770	000016				.WORD 16	:	4560
7187	050772	011070				.WORD MSG1		
7188	050774	000000				.WORD 0		
7189	050776	112764	000006	034446		MOVB #6,WHY.DROPT(R4)	: *,*(LUN)	4561
7190	051004	010400				MOV R4,R0	: LUN,*	4562
7191	051006	104451				TRAP 51		
7192	051010	000416				BR 28\$:	
7193	051012	020527	000004		27\$:	CMP R5,#4	: VALUE,*	4563
7194	051016	001014				BNE 29\$		4533
7195	051020	004767	166306			JSR PC,ISOLATE	:	
7196	051024	104455				TRAP 55	:	4568
7197	051026	000017				.WORD 17	:	4569
7198	051030	011120				.WORD MSG2		
7199	051032	000000				.WORD 0		
7200	051034	112764	000007	034446		MOVB #7,WHY.DROPT(R4)	: *,*(LUN)	4570
7201	051042	010400				MOV R4,R0	: LUN,*	4571
7202	051044	104451				TRAP 51		
7203	051046	000562				BR 36\$:	
7204	051050	020527	000005		28\$:	CMP R5,#5	: VALUE,*	4572
7205	051054	001157			29\$:	BNE 36\$		4533
7206	051056	004767	166250			JSR PC,ISOLATE	:	
7207	051062	032767	000001	131170		BIT #1,ERROUT	:	4577
7208	051070	001423				BEQ 30\$:	4579
7209	051072	017700	163312			MOV @ML.REG+42,R0		
7210	051076	006200				ASR R0		
7211	051100	006200				ASR R0		
7212	051102	006200				ASR R0		
7213	051104	006200				ASR R0		
7214	051106	006200				ASR R0		
7215	051110	006200				ASR R0		
7216	051112	042700	177700			BIC #177700,R0		
7217	051116	010046				MOV R0,-(SP)		
7218	051120	012746	006640			MOV #FMT10B,-(SP)		
7219	051124	012746	000002			MOV #2,-(SP)		
7220	051130	010600				MOV SP,R0	: SP,*	
7221	051132	104414				TRAP 14		
7222	051134	062706	000006			ADD #6,SP		
7223	051140	017766	163246	000044	30\$:	MOV @ML.REG+44,44(SP)	: *.OLDSEC	4582
7224	051146	017700	163236			MOV @ML.REG+42,R0	:	4583
7225	051152	006200				ASR R0		
7226	051154	006200				ASR R0		
7227	051156	006200				ASR R0		
7228	051160	006200				ASR R0		
7229	051162	006200				ASR R0		
7230	051164	006200				ASR R0		
7231	051166	042700	177700			BIC #177700,R0		
7232	051172	010066	000042			MOV R0,42(SP)	: *.OLDCHN	
7233	051176	012746	000001			MOV #1,-(SP)	:	4585

Address	OpCode	Operand 1	Operand 2	Operand 3	Comment	Address
7235					:MLX4	
7236					:	
7237					COMMAND INTEGRITY ROUTINE	
7238	051202	012746	046000		MOV #CHECK,-(SP)	
7239	051206	010446			MOV R4,-(SP)	
7240	051210	010346			MOV R3,-(SP)	: LUN,*
7241	051212	012746	012670		MOV #WBUF,-(SP)	: WRDCNT,*
7242	051216	011246			MOV (R2),-(SP)	
7243	051220	004767	175000		JSR PC,RETRY	
7244	051224	062706	000014		ADD #14,SP	
7245	051230	020027	000005		CMP R0,#5	
7246	051234	001051			BNE 33\$	
7247	051236	027766	163150	000044	CMP @ML.REG+44,44(SP)	: *,OLDSEC
7248	051244	001034			BNE 32\$	4588
7249	051246	016600	000042		MOV 42(SP),R0	: OLDCHN,*
7250	051252	017702	163132		MOV @ML.REG+42,R2	
7251	051256	006202			ASR R2	
7252	051260	006202			ASR R2	
7253	051262	006202			ASR R2	
7254	051264	006202			ASR R2	
7255	051266	006202			ASR R2	
7256	051270	006202			ASR R2	
7257	051272	042702	177700		BIC #177700,R2	
7258	051276	020200			CMP R2,R0	
7259	051300	001016			BNE 32\$	
7260	051302	032767	000001	130750	BIT #1,ERROUT	:
7261	051310	001404			BEQ 31\$	4592
7262	051312	104456			TRAP 56	
7263	051314	000020			.WORD 20	
7264	051316	011202			.WORD MSG4	
7265	051320	000000			.WORD 0	
7266	051322	010446			MOV R4,-(SP)	: LUN,*
7267	051324	016746	163012	31\$:	MOV BOARD,-(SP)	4595
7268	051330	004767	166066		JSR PC,UP.HARD.COUNT	
7269	051334	000426			BR 35\$:
7270	051336	032767	000001	130714	32\$:	BIT #1,ERROUT
7271	051344	001415			BEQ 34\$:
7272	051346	104457			TRAP 57	:
7273	051350	000021			.WORD 21	:
7274	051352	011166			.WORD MSG3	:
7275	051354	000000			.WORD 0	:
7276	051356	000410			BR 34\$:
7277	051360	032767	000001	130672	33\$:	BIT #1,ERROUT
7278	051366	001404			BEQ 34\$:
7279	051370	104457			TRAP 57	:
7280	051372	000022			.WORD 22	:
7281	051374	011166			.WORD MSG3	:
7282	051376	000000			.WORD 0	:
7283	051400	010446			MOV R4,-(SP)	: LUN,*
7284	051402	016746	162734	34\$:	MOV BOARD,-(SP)	4612
7285	051406	004767	166472		JSR PC,UP.SOFT.COUNT	
7286	051412	022626			CMP (SP)+,(SP)+	:
7287	051414	062706	000026	35\$:	ADD #26,SP	:
7288	051420	005204			INC R4	:
7289	051422	020466	000020	38\$:	CMP R4,20(SP)	: LUN,*

7291
7292
7293
7294 051426 002002
7295 051430 000167 175656
7296 051434 005726
7297 051436 005201
7298 051440 020127 000001
7299 051444 003002
7300 051446 000167 175616
7301 051452 062706 000022
7302 051456 000207
7303
7304
7305
7310
7311

:MLX4
:
COMMAND INTEGRITY ROUTINE
39\$: BGE 39\$
JMP 2\$
TST (SP)+
INC R1
CMP R1,#1
BGT 40\$
JMP 1\$
40\$: ADD #22,SP
RTS PC

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

: COMP.FLAG 4363
: COMP.FLAG,* 4362

4308

: Routine Size: 587 words
: Maximum stack depth per invocation: 33 words

7313 :MLX4
7314 :
7315 :
7316 :
7317 :
7318 :
7319 :
7320 :
7321 :
7322 :
7323 :
7324 :
7325 :
7326 :
7327 :
7328 :
7329 :
7330 :
7331 :
7332 :
7333 :
7334 :
7335 :
7336 :
7337 :
7338 :
7339 :
7340 :
7341 :
7342 :
7343 :
7344 :
7345 :
7346 :
7347 :
7348 :
7349 :
7350 :
7351 :
7352 :
7353 :
7354 :
7355 :
7356 :
7357 :
7358 :
7359 :
7360 :
7361 :
7362 :
7363 :
7364 :
7365 :
7366 :
7367 :

DEFINITION OF OPTION 1

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (37)

4627 %sbttl 'DEFINITION OF OPTION 1'
4628 routine OPT1 : novalue =
4629 begin

!* 1 * START OF ROUTINE

++

ROUTINE: OPT1

PURPOSE: TO CHECK ADDRESSES USING DATA = SECTOR NUMBER.
TRANSFERS ARE 4K WORDS IN LENGTH, AND ALL SECTORS
ARE TESTED.

THE CODE FOR 'OPT1' IN BRIEF:

BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COMPLEMENT FLAG FROM 0 TO 1
: BEGIN 2 (START OF COMPLEMENT FLAG SELECTION LOOP)
: INCR LOGICAL UNIT FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS ONE UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : INITIALIZE WRITE AND READ BUFFER POINTERS
: : : : SECTOR = LOWEST
: : : : WHILE SECTOR LEQ HIGHEST DO
: : : : : BEGIN 6 (START OF SECTOR SELECTION LOOP)
: : : : : GET WRDCNT
: : : : : GENERATE THE PATTERN
: : : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : UPDATE SECTOR NUMBER BY NUMBER OF SECTORS IN PREVIOUS TRANSFER
: : : : : END 6 (END OF SECTOR SELECTION LOOP)
: : : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : : : END 4 (END OF TESTLOOP)
: : : : : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
: : : : : END 2 (END OF COMPLEMENT FLAG SELECTION LOOP)
RETURN
END 1 (END OF ROUTINE)

Label
LOOP:
local
VALUE,

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (37)

```

7369 :MLX4
7370 :
7371 :      DEFINITION OF OPTION 1
7372 :      4679      WRDCNT,
7373 :      4680      COMMAND,
7374 :      4681      PTR,
7375 :      4682      OLDSEC,
7376 :      4683      OLDCHN,
7377 :      4684      SECTOR,
7378 :      4685      DBL_VALUE;
7379 :
7380 :      PRINTB (SAY2, WRD34, RTN1);
7381 :      !'RUNNING OPT1'
7382 :
7383 :      incr COMP_FLAG from 0 to 1 do
7384 :      4691      begin
7385 :      4692      !* 2 * START OF COMPLEMENT FLAG SELECTION LOOP
7386 :      4693      incr LUN from 0 to (.LSUNIT - 1) do
7387 :      4694      begin
7388 :      4695      LOOP :
7389 :      4696      begin
7390 :      4697      !* 4 * START OF THE LOOP THAT COMPLETELY TESTS ONE UNIT
7391 :      4698      if .DRIVE_STATUS [.LUN] eql ACTIVE
7392 :      4699      then
7393 :      4700      begin
7394 :      4701      !* 5 * START OF TEST FOR AN ACTIVE UNIT
7395 :      4702      LSLUN = .LUN;
7396 :      4703      WPTR = WBUFF;
7397 :      4704      RPTR = RBUFF;
7398 :      4705      SECTOR = LOWEST;
7399 :      4706      while .SECTOR lequ HIGHEST do
7400 :      4707      begin
7401 :      4708      !* 6 * START OF SECTOR SELECTION LOOP
7402 :      4709      GEN1 (.SECTOR, .COMP_FLAG);
7403 :      4710      WRDCNT = GET WRDCNT (.SECTOR, HIGHEST);
7404 :      4711      SET PTRS (.WRDCNT);
7405 :      4712      VALDE = write (.LUN, .WRDCNT, .WPTR, .SECTOR);
7406 :      4713      !+
7407 :      4714      ! SEE HOW SUCCESSFUL THE WRITE WAS:
7408 :      4715      !-
7409 :      4716      selectone .VALUE of
7410 :      4717      set
7411 :      4718      !SEE 'SYSERR' FOR DEFINITION
7412 :      4719      !OF ERROR # CONTAINED IN 'VALUE'
7413 :      4720      [1] :
7414 :      4721      begin
7415 :      4722      !* 6A * RETRY ALLOWED
7416 :      4723      if RETRY (SIX, write, .LUN, .WRDCNT, .WPTR, .SECTOR) neq 0
7417 :      4724      then
7418 :      4725      !THE RETRY FAILED -- SYSTEM FATAL ERROR
7419 :      4726      begin
7420 :      4727      WHY DROPT [.LUN] = CODE_4;
7421 :      4728      ERRDF (101, MSG1, 0); -!**** OPTION 1 ERROR 01 ****
7422 :      4729      DODU (.LUN);
7423 :      4730      leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
7423 :      4730      end;
    
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (37)

7425 :MLX4
 7426 :
 7427 :
 7428 :
 7429 :
 7430 :
 7431 :
 7432 :
 7433 :
 7434 :
 7435 :
 7436 :
 7437 :
 7438 :
 7439 :
 7440 :
 7441 :
 7442 :
 7443 :
 7444 :
 7445 :
 7446 :
 7447 :
 7448 :
 7449 :
 7450 :
 7451 :
 7452 :
 7453 :
 7454 :
 7455 :
 7456 :
 7457 :
 7458 :
 7459 :
 7460 :
 7461 :
 7462 :
 7463 :
 7464 :
 7465 :
 7466 :
 7467 :
 7468 :
 7469 :
 7470 :
 7471 :
 7472 :
 7473 :
 7474 :
 7475 :
 7476 :
 7477 :
 7478 :
 7479 :

DEFINITION OF OPTION 1

```

end;                !* 6A *

[2] :
begin              !* 6B * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
WHY DROPT [.LUN] = CODE_5;
ERRDF (102, MSG1, 0);    !**** OPTION 1 ERROR 02 ****
DODU (.LUN);
leave LOOP;          !JUMP JUST BEYOND END OF BLOCK * 4 *
end;                !* 6B *

[3] :
begin              !* 6C * FATAL DRIVE ERROR -- NO RETRY ALLOWED
ERRDF (103, MSG1, 0);    !**** OPTION 1 ERROR 03 ****
WHY DROPT [.LUN] = CODE_6;
DODD (.LUN);
leave LOOP;          !JUMP JUST BEYOND END OF BLOCK * 4 *
end;                !* 6C *

tes;

COMMAND = CHOOSE ();

if .COMMAND eql read
then
begin
PTR = .RPTR;
VALUE = read (.LUN, .WRDCNT, .RPTR, .SECTOR);
end
else
begin
PTR = .WPTR;
VALUE = CHECK (.LUN, .WRDCNT, .WPTR, .SECTOR);
end;

!+
!- SEE HOW SUCCESSFUL THE OPERATION WAS:
!-

selectone .VALUE of      !SEE 'SYSERR' FOR DEFINITION
set                      !OF ERROR # CONTAINED IN 'VALUE'

[0] :
if .COMMAND eql read
then
begin
if (DBL_VALUE = DOUBLE_CHECK (.WPTR, .RPTR, .WRDCNT)) neq 0
then
begin
SAYWHO (.LUN);
PRINTB (SAY1, MSG5);    !'ECC LOGIC FAILED TO DETECT DATA ERROR'

```

7481 :MLX4

DEFINITION OF OPTION 1

27-Mar-1982 19:24:42 PS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 P :<NEALE>MLX4.BLI.5 (37)

7482 :
 7483 :
 7484 : 4783
 7485 : 4784
 7486 : 4785
 7487 : 4786
 7488 : 4787
 7489 : 4788
 7490 : 4789
 7491 : 4790
 7492 : 4791
 7493 : 4792
 7494 : 4793
 7495 : 4794
 7496 : 4795
 7497 : 4796
 7498 : 4797
 7499 : 4798
 7500 : 4799
 7501 : 4800
 7502 : 4801
 7503 : 4802
 7504 : 4803
 7505 : 4804
 7506 : 4805
 7507 : 4806
 7508 : 4807
 7509 : 4808
 7510 : 4809
 7511 : 4810
 7512 : 4811
 7513 : 4812
 7514 : 4813
 7515 : 4814
 7516 : 4815
 7517 : 4816
 7518 : 4817
 7519 : 4818
 7520 : 4819
 7521 : 4820
 7522 : 4821
 7523 : 4822
 7524 : 4823
 7525 : 4824
 7526 : 4825
 7527 : 4826
 7528 : 4827
 7529 : 4828
 7530 : 4829
 7531 : 4830
 7532 : 4831
 7533 : 4832
 7534 : 4833
 7535 : 4834

```

PRINTB (FMT12A, ..DBL VALUE, .DBL VALUE);
!'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
DBL VALUE = .DBL_VALUE + BUFSIZ*2;
PRINTB (FMT12B, ..DBL VALUE, .DBL VALUE);
!'BAD DATA: PPPPPP AT LOCATION QQQQQQ'
WHY DROPT [.LUN] = CODE_8;
ERRDF (104, MSG1, 0); !**** OPTION 1 ERROR 04 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;

end;

[1] :
begin !* 6D * RETRY ALLOWED
if RETRY (SIX, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) neg 0
then !THE RETRY FAILED -- SYSTEM FATAL ERROR
begin
WHY DROPT [.LUN] = CODE_4;
ERRDF (105, MSG1, 0); !**** OPTION 1 ERROR 05 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;
end; !* 6D *

[2] :
begin !* 6E * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
WHY DROPT [.LUN] = CODE_5;
ERRDF (106, MSG1, 0); !**** OPTION 1 ERROR 06 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end; !* 6E *

[3] :
begin !* 6F * FATAL DRIVE ERROR -- NO RETRY ALLOWED
WHY DROPT [.LUN] = CODE_6;
ERRDF (107, MSG1, 0); !**** OPTION 1 ERROR 07 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end; !* 6F *

[4] :
begin !* 6G * UNRECOVERABLE DATA ERROR
ISOLATE ();
ERRDF (108, MSG2, 0); !**** OPTION 1 ERROR 08 ****
WHY DROPT [.LUN] = CODE_7;
DODD (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end; !* 6G *
    
```

27-Mar-1982 19:24:42 TOPS-20 BLISS-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (37)

```

7537 :MLX4
7538 :
7539 :      DEFINITION OF OPTION 1
7540 :      4835      [5] :
7541 :      4836      begin
7542 :      4837      ISOLATE ();          !* 6H * RECOVERABLE DATA ERROR
7543 :      4838
7544 :      4839      if .ERROUT then PRINTB (FMT10B, .CHAN);
7545 :      4840
7546 :      4841      !' BIT 00'
7547 :      4842      OLDSEC = .MLEL;
7548 :      4843      OLDCHN = .CHAN;
7549 :      4844
7550 :      4845      if RETRY (ONE, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) eql 5
7551 :      4846      then
7552 :      4847
7553 :      4848          if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
7554 :      4849          then
7555 :      4850              begin
7556 :      4851                  if .ERROUT then ERRHRD (109, MSG4, 0);          !**** OPTION 1 ERROR 09 ****
7557 :      4852                  UP_HARD_COUNT (.LUN, .BOARD);
7558 :      4853                  end
7559 :      4854              else
7560 :      4855                  begin
7561 :      4856                      if .ERROUT then ERRSOFT (110, MSG3, 0);          !**** OPTION 1 ERROR 10 ****
7562 :      4857                      UP_SOFT_COUNT (.LUN, .BOARD);
7563 :      4858                      end
7564 :      4859                  else
7565 :      4860                      begin
7566 :      4861                          if .ERROUT then ERRSOFT (111, MSG3, 0); !**** OPTION 1 ERROR 11 ****
7567 :      4862                          UP_SOFT_COUNT (.LUN, .BOARD);
7568 :      4863                          end
7569 :      4864                      end
7570 :      4865                  end
7571 :      4866              end
7572 :      4867              if .ERROUT then ERRSOFT (111, MSG3, 0); !**** OPTION 1 ERROR 11 ****
7573 :      4868              UP_SOFT_COUNT (.LUN, .BOARD);
7574 :      4869              end;
7575 :      4870          end;
7576 :      4871      end;
7577 :      4872      tes;          !* 6H *
7578 :      4873
7579 :      4874
7580 :      4875      WPTR = .WPTR + (.WRDCNT*2);
7581 :      4876      SECTOR = .SECTOR + (.WRDCNT/256);
7582 :      4877      end;          !* 6 * END OF SECTOR SELECTION LOOP
7583 :      4878
7584 :      4879      end;          !* 5 * END OF TEST FOR AN ACTIVE UNIT
7585 :      4880
7586 :      4881
7587 :      4882      !+
7588 :      4883      Test to see if this uut's address space is
7589 :      4884      to be read for soft errors. This test is
7590 :      4885      is intended for DMT purposes.
7591 :      4886      !-
    
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (37)

```

7593 :MLX4
7594 :
7595 :
7596 :         4887
7597 :         4888
7598 :         4889
7599 :         4890
7600 :         4891
7601 :         4892
7602 :         4893
7603 :         4894
7604 :         4895
7605 :         4896
7606 :         4897
7607 :         4898
7608 :         4899
7609 :         4900
7610 :         4901
7611 :         4902
7612 :         4903
7613 :         4904
7614 :         4905
7615 :         4906
7616 :         4907
7617 :         4908
7618 :         4909
7619 :         4910
7620 :         4911
7621 :         4912
7622 :         4913
7623 :         4914
7624 :         4915
7625 :         4916
7626 :         4917
7627 :         4918
7628 :         4919
7629 :         4920
7630 :         4921
7631 :         4922
7632 :         4923
7633 :         4924
7634 :         4925
7635 :         4926
7636 :         4927
7637 :         4928
7638 :         4929
7639 :         4930
7640 :         4931
7641 :         4932
7642 :         4933
7643 :         4934
7644 :         P 4935
7645 :         P 4936
7646 :         4937
7647 :         4938

DEFINITION OF OPTION 1
    if .EFNS21
    then
        begin
            !Is the background pattern to be read

            !
            ! version czmlbb changed incr to incru
            !
            incru SECTOR from LOWEST to HIGHEST do
                if read (.LUN, 256, RBUFF, .SECTOR) eql 5
                then
                    begin
                        ISOLATE ();                !Find the failing bank and board no.

                        if .ERROUT then PRINTB (FMT10B, .CHAN);

                        ! Print where the error is
                        !
                        ! Save the contents of the ML error location
                        ! register so we can compare it to the new
                        ! contents of this register after the retry.
                        ! This is done to classify the error.
                        OLDSEC = .MLEL;
                        OLDCHN = .CHAN;

                        ! Do a classify retry call. If the same error
                        ! occurs then classify it as a hard error. If
                        ! a different error occurred or the error went away
                        ! then classify it as a soft error.
                        !
                        if RETRY (ONE, .COMMAND, .LUN, 256, .PTR, .OLDSEC) eql 5
                        then
                            !
                            ! The same error occurred so see if it is at the same
                            ! sector and channel number, if so then classify
                            ! it as a hard error else classiy it as a soft
                            ! error.
                            !
                            if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
                            then
                                begin
                                    !Same error occurred 'hard'

                                    if .ERROUT
                                    then
                                        !Print error if enabled
                                        begin
                                            ERRHRD (112,
                                                MSG4,
                                                0);
                                            !Error number
                                            !Error message
                                            !Additional message routine
                                        end;
                                end;
                            end;
                    end;
                end;
            end;
        end;
    end;

```


27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (37)

```

7649 :MLX4
7650 :      DEFINITION OF OPTION 1
7651 :
7652 :      4939
7653 :      4940      UP_HARD_COUNT (.LUN, .BOARD);
7654 :      4941      end
7655 :      4942      else
7656 :      4943      begin          !Not the same error 'soft'
7657 :      4944
7658 :      4945      if .ERROUT      !Print error if enabled
7659 :      4946      then
7660 :      4947          begin
7661 :      4948              ERRSOFT (113,          !Error number
7662 :      4949                  MSG3,          !Error message
7663 :      4950                      0);          !Additional message routine
7664 :      4951          end;
7665 :      4952
7666 :      4953      UP_SOFT_COUNT (.LUN, .BOARD);
7667 :      4954      end
7668 :      4955
7669 :      4956      else          !Not the same error 'soft'
7670 :      4957      begin
7671 :      4958
7672 :      4959      if .ERROUT      !Print error if enabled
7673 :      4960      then
7674 :      4961          begin
7675 :      4962              ERRSOFT (114,          !Error number
7676 :      4963                  MSG3,          !Error message
7677 :      4964                      0);          !Additional message routine
7678 :      4965          end;
7679 :      4966
7680 :      4967      UP_SOFT_COUNT (.LUN, .BOARD);
7681 :      4968      end;
7682 :      4969
7683 :      4970      end;
7684 :      4971
7685 :      4972      end;
7686 :      4973
7687 :      4974      end;          !* 4 * END OF LOOP THAT COMPLETELY TESTS ONE UNIT
7688 :      4975      end;          !* 3 * END OF LOGICAL UNIT SELECTION LOOP
7689 :      4976
7690 :      4977      end;          !* 2 * END OF COMPLEMENT FLAG SELECTION LOOP
7691 :      4978
7692 :      4979      return;
7693 :      4980      end;          !* 1 * END OF ROUTINE
7697 :
7698 :
7702 051460 004167 133650      OPT1: .SBTTL OPT1 DEFINITION OF OPTION 1
7703 051464 162706 000020      JSR   R1,SSAVES
      SUB   #20,SP
    
```


				DEFINITION OF OPTION 1		27-Mar-1982 19:24:42		TOPS
						27-Mar-1982 19:23:44		PA:<
7761								
7762				:MLX4				
7763				:				
7764	051752	016646	000030	MOV	30(SP),-(SP)	:	LUN,*	
7765	051756	010246		MOV	R2,-(SP)	:	WRDCNT,*	
7766	051760	016746	160704	MOV	WPTR,-(SP)	:		
7767	051764	010446		MOV	R4,-(SP)	:	SECTOR,*	
7768	051766	004767	174232	JSR	PC,RETRY	:		
7769	051772	062706	000014	ADD	#14,SP	:		
7770	051776	005700		TST	R0	:		
7771	052000	001456		BEQ	9\$:		
7772	052002	016601	000024	MOV	24(SP),R1	:	LUN,*	
7773	052006	112761	000004	MOVB	#4,WHY.DROPT(R1)			4726
7774	052014	104455		TRAP	55	:		
7775	052016	000145		.WORD	145	:		4727
7776	052020	011070		.WORD	MSG1	:		
7777	052022	000000		.WORD	0	:		
7778	052024	016600	000024	MOV	24(SP),R0	:	LUN,*	
7779	052030	104451		TRAP	51	:		4728
7780	052032	000436		BR	8\$:		
7781	052034	020327	000002	CMP	R3,#2	:	VALUE,*	4729
7782	052040	001015		BNE	7\$:		4717
7783	052042	016601	000024	MOV	24(SP),R1	:	LUN,*	
7784	052046	112761	000005	MOVB	#5,WHY.DROPT(R1)			4736
7785	052054	104455		TRAP	55	:		
7786	052056	000146		.WORD	146	:		4737
7787	052060	011070		.WORD	MSG1	:		
7788	052062	000000		.WORD	0	:		
7789	052064	016600	000024	MOV	24(SP),R0	:	LUN,*	
7790	052070	104451		TRAP	51	:		4738
7791	052072	000416		BR	8\$:		
7792	052074	020327	000003	CMP	R3,#3	:	VALUE,*	4739
7793	052100	001016		BNE	9\$:		4717
7794	052102	104455		TRAP	55	:		
7795	052104	000147		.WORD	147	:		4744
7796	052106	011070		.WORD	MSG1	:		
7797	052110	000000		.WORD	0	:		
7798	052112	016601	000024	MOV	24(SP),R1	:	LUN,*	
7799	052116	112761	000006	MOVB	#6,WHY.DROPT(R1)			4745
7800	052124	010100		MOV	R1,R0	:	LUN,*	
7801	052126	104451		TRAP	51	:		4746
7802	052130	062706	000014	ADD	#14,SP	:		
7803	052134	000543		BR	14\$:		4747
7804	052136	004767	174024	JSR	PC,CHOOSE	:		
7805	052142	010066	000034	MOV	R0,34(SP)	:	*.COMMAND	4751
7806	052146	005001		CLR	R1	:		
7807	052150	020027	045612	CMP	R0,#READ	:	COMMAND,*	4753
7808	052154	001015		BNE	10\$:		
7809	052156	005201		INC	R1	:		
7810	052160	016766	160506	MOV	RPTR,36(SP)	:	*.PTR	4756
7811	052166	016646	000024	MOV	24(SP),-(SP)	:	LUN,*	4757
7812	052172	010246		MOV	R2,-(SP)	:	WRDCNT,*	
7813	052174	016746	160472	MOV	RPTR,-(SP)	:		
7814	052200	010446		MOV	R4,-(SP)	:	SECTOR,*	
7815	052202	004767	173404	JSR	PC,READ	:		

Address	OpCode	Operand 1	Operand 2	Operand 3	Label	Instruction	Comment	Address
7817								
7818					:MLX4			
7819					:			
7820	052206	000413				BR 11\$		
7821	052210	016766	160454	000036	10\$:	MOV WPTR,36(SP)	: *,PTR	4761
7822	052216	016646	000024			MOV 24(SP),-(SP)	: LUN,*	4762
7823	052222	010246				MOV R2,-(SP)	: WRDCNT,*	
7824	052224	016746	160440			MOV WPTR,-(SP)		
7825	052230	010446				MOV R4,-(SP)	: SECTOR,*	
7826	052232	004767	173542			JSR PC,CHECK		
7827	052236	010003			11\$:	MOV R0,R3	: *,VALUE	
7828	052240	001102				BNE 15\$:	
7829	052242	006001				ROR R1	:	4769
7830	052244	103402				BLO 13\$:	4774
7831	052246	000167	001016		12\$:	JMP 28\$		
7832	052252	016746	160412		13\$:	MOV WPTR,-(SP)	:	4778
7833	052256	016746	160410			MOV RPTR,-(SP)		
7834	052262	010246				MOV R2,-(SP)	: WRDCNT,*	
7835	052264	004767	172036			JSR PC,DOUBLE.CHECK		
7836	052270	062706	000006			ADD #6,SP		
7837	052274	010066	000042			MOV R0,42(SP)	: *,DBL.VALUE	
7838	052300	001762				BEQ 12\$		
7839	052302	016646	000034			MOV 34(SP),-(SP)	: LUN,*	4781
7840	052306	004767	163212			JSR PC,SAYWHO		
7841	052312	012716	011216			MOV #MSG5,(SP)	:	4782
7842	052316	012746	007072			MOV #SAY1,-(SP)		
7843	052322	012746	000002			MOV #2,-(SP)		
7844	052326	010600				MOV SP,R0	: SP,*	
7845	052330	104414				TRAP 14		
7846	052332	016616	000050			MOV 50(SP),(SP)	: DBL.VALUE,*	4783
7847	052336	017646	000050			MOV #50(SP),-(SP)	: DBL.VALUE,*	
7848	052342	012746	006710			MOV #FMT12A,-(SP)		
7849	052346	012746	000003			MOV #3,-(SP)		
7850	052352	010600				MOV SP,R0	: SP,*	
7851	052354	104414				TRAP 14		
7852	052356	062766	010000	000056		ADD #10000,56(SP)	: *,DBL.VALUE	4785
7853	052364	016616	000056			MOV 56(SP),(SP)	: DBL.VALUE,*	4786
7854	052370	017646	000056			MOV #56(SP),-(SP)	: DBL.VALUE,*	
7855	052374	012746	006756			MOV #FMT12B,-(SP)		
7856	052400	012746	000003			MOV #3,-(SP)		
7857	052404	010600				MOV SP,R0	: SP,*	
7858	052406	104414				TRAP 14		
7859	052410	016601	000056			MOV 56(SP),R1	: LUN,*	4788
7860	052414	112761	000010	034446		MOVB #10,WHY.DROPT(R1)		
7861	052422	104455				TRAP 55	:	4789
7862	052424	000150				.WORD 150		
7863	052426	011070				.WORD MSG1		
7864	052430	000000				.WORD 0		
7865	052432	016600	000056			MOV 56(SP),R0	: LUN,*	4790
7866	052436	104451				TRAP 51		
7867	052440	062706	000046			ADD #46,SP	:	4791
7868	052444	000522			14\$:	BR 20\$		
7869	052446	020327	000001		15\$:	CMP R3,#1	: VALUE,*	4769
7870	052452	001035				BNE 16\$		
7871	052454	012746	000006			MOV #6,-(SP)	:	4799

Address	OpCode	Operand 1	Operand 2	Operand 3	Instruction	Comments	Address
7873							
7874							
7875							
7876	052466	016646	000046		MOV 46(SP),-(SP)	: COMMAND,*	
7877	052464	016646	000040		MOV 40(SP),-(SP)	: LUN,*	
7878	052470	010246			MOV R2,-(SP)	: WRDCNT,*	
7879	052472	016646	000056		MOV 56(SP),-(SP)	: PTR,*	
7880	052476	010446			MOV R4,-(SP)	: SECTOR,*	
7881	052500	004767	173520		JSR PC,RETRY		
7882	052504	062706	000014		ADD #14,SP		
7883	052510	005700			TST R0		
7884	052512	001655			BEQ 12\$		
7885	052514	016601	000034		MOV 34(SP),R1	: LUN,*	4802
7886	052520	112761	000004	034446	MOVB #4,WHY.DROPT(R1)		
7887	052526	104455			TRAP 55	:	4803
7888	052530	000151			.WORD 151		
7889	052532	011070			.WORD MSG1		
7890	052534	000000			.WORD 0		
7891	052536	016600	000034		MOV 34(SP),R0	: LUN,*	4804
7892	052542	104451			TRAP 51		
7893	052544	000460			BR 19\$		
7894	052546	020327	000002	16\$:	CMP R3,#2	: VALUE,*	4805
7895	052552	001015			BNE 17\$		4769
7896	052554	016601	000034		MOV 34(SP),R1	: LUN,*	4812
7897	052560	112761	000005	034446	MOVB #5,WHY.DROPT(R1)		
7898	052566	104455			TRAP 55	:	4813
7899	052570	000152			.WORD 152		
7900	052572	011070			.WORD MSG1		
7901	052574	000000			.WORD 0		
7902	052576	016600	000034		MOV 34(SP),R0	: LUN,*	4814
7903	052602	104451			TRAP 51		
7904	052604	000440			BR 19\$		
7905	052606	020327	000003	17\$:	CMP R3,#3	: VALUE,*	4815
7906	052612	001015			BNE 18\$		4769
7907	052614	016601	000034		MOV 34(SP),R1	: LUN,*	4820
7908	052620	112761	000006	034446	MOVB #6,WHY.DROPT(R1)		
7909	052626	104455			TRAP 55	:	4821
7910	052630	000153			.WORD 153		
7911	052632	011070			.WORD MSG1		
7912	052634	000000			.WORD 0		
7913	052636	016600	000034		MOV 34(SP),R0	: LUN,*	4822
7914	052642	104451			TRAP 51		
7915	052644	000420			BR 19\$		
7916	052646	020327	000004	18\$:	CMP R3,#4	: VALUE,*	4823
7917	052652	001021			BNE 21\$		4769
7918	052654	004767	164452		JSR PC,ISOLATE		4828
7919	052660	104455			TRAP 55	:	4829
7920	052662	000154			.WORD 154		
7921	052664	011120			.WORD MSG2		
7922	052666	000000			.WORD 0		
7923	052670	016601	000034		MOV 34(SP),R1	: LUN,*	4830
7924	052674	112761	000007	034446	MOVB #7,WHY.DROPT(R1)		
7925	052702	010100			MOV R1,R0	: LUN,*	4831
7926	052704	104451			TRAP 51		
7927	052706	062706	000024	19\$:	ADD #24,SP	:	4832

Address	OpCode	Operand 1	Operand 2	Operand 3	Label	Definition	Comments	Page
7985								
7986								
7987								
7988	053150	001017				BNE 24\$		
7989	053152	032767	000001	127100		BIT #1,ERROUT	:	
7990	053160	001404				BEQ 23\$:	4852
7991	053162	104456				TRAP 56		
7992	053164	000155				.WORD 155		
7993	053166	011202				.WORD MSG4		
7994	053170	000000				.WORD 0		
7995	053172	016646	000034		23\$:	MOV 34(SP),-(SP)	: LUN,*	
7996	053176	016746	161140			MOV BOARD,-(SP)		4854
7997	053202	004767	164214			JSR PC,UP.HARD.COUNT		
7998	053206	000427				BR 27\$:	
7999	053210	032767	000001	127042	24\$:	BIT #1,ERROUT	:	4848
8000	053216	001415				BEQ 26\$:	4859
8001	053220	104457				TRAP 57		
8002	053222	000156				.WORD 156		
8003	053224	011166				.WORD MSG3		
8004	053226	000000				.WORD 0		
8005	053230	000410				BR 26\$:	
8006	053232	032767	000001	127020	25\$:	BIT #1,ERROUT	:	4861
8007	053240	001404				BEQ 26\$:	4867
8008	053242	104457				TRAP 57		
8009	053244	000157				.WORD 157		
8010	053246	011166				.WORD MSG3		
8011	053250	000000				.WORD 0		
8012	053252	016646	000034		26\$:	MOV 34(SP),-(SP)	: LUN,*	
8013	053256	016746	161060			MOV BOARD,-(SP)		4869
8014	053262	004767	164616			JSR PC,UP.SOFT.COUNT		
8015	053266	022626			27\$:	CMP (SP)+,(SP)+	:	4836
8016	053270	010200			28\$:	MOV R2,R0	: WRDCNT,*	4875
8017	053272	006300				ASL R0		
8018	053274	066700	157370			ADD WPTR,R0		
8019	053300	010067	157364			MOV R0,WPTR		
8020	053304	010216				MOV R2,(SP)	: WRDCNT,*	
8021	053306	012746	000400			MOV #400,-(SP)		4876
8022	053312	004767	131652			JSR PC,BLSDIV		
8023	053316	060400				ADD R4,R0	: SECTOR,*	
8024	053320	010004				MOV R0,R4	: *,SECTOR	
8025	053322	062706	000026			ADD #26,SP	:	
8026	053326	000167	176316			JMP 5\$:	4707
8027	053332	032767	000001	126722	29\$:	BIT #1,EFNS21	:	4706
8028	053340	001002				BNE 30\$:	4887
8029	053342	000167	000440			JMP 40\$		
8030	053346	016600	000010		30\$:	MOV 10(SP),R0	: LUN,*	
8031	053352	006300				ASL R0		4894
8032	053354	016001	034500			MOV TOP.SECT(R0),R1		
8033	053360	016005	034460			MOV LOW.SECT(R0),R5	: *,SECTOR	
8034	053364	000167	000406			JMP 39\$		
8035	053370	016646	000010		31\$:	MOV 10(SP),-(SP)	: LUN,*	
8036	053374	012746	000400			MOV #400,-(SP)		4896
8037	053400	012746	022670			MOV #RBUF,-(SP)		
8038	053404	010546				MOV R5,-(SP)	: SECTOR,*	
8039	053406	004767	172200			JSR PC,READ		

Address	OpCode	Operand1	Operand2	Operand3	Label	Definition	Comments	Address
8041					:MLX4			
8042					:			
8043						DEFINITION OF OPTION 1		27-Mar-1982 19:24:42 TOPS
8044	053412	062706	000010			ADD #10,SP		27-Mar-1982 19:23:44 PA:<
8045	053416	020027	000005			CMP R0,#5		
8046	053422	001164				BNE 38\$		
8047	053424	004767	163702			JSR PC,ISOLATE		
8048	053430	032767	000001	126622		BIT #1,ERROUT	:	4899
8049	053436	001423				BEQ 32\$:	4901
8050	053440	017700	160744			MOV @ML.REG+42,R0		
8051	053444	006200				ASR R0		
8052	053446	006200				ASR R0		
8053	053450	006200				ASR R0		
8054	053452	006200				ASR R0		
8055	053454	006200				ASR R0		
8056	053456	006200				ASR R0		
8057	053460	042700	177700			BIC #177700,R0		
8058	053464	010046				MOV R0,-(SP)		
8059	053466	012746	006640			MOV #FMT10B,-(SP)		
8060	053472	012746	000002			MOV #2,-(SP)		
8061	053476	010600				MOV SP,R0	: SP,*	
8062	053500	104414				TRAP 14		
8063	053502	062706	000006			ADD #6,SP		
8064	053506	017766	160700	000024	32\$:	MOV @ML.REG+44,24(SP)	: *,OLDSEC	4910
8065	053514	017700	160670			MOV @ML.REG+42,R0	:	4911
8066	053520	006200				ASR R0	:	
8067	053522	006200				ASR R0	:	
8068	053524	006200				ASR R0	:	
8069	053526	006200				ASR R0	:	
8070	053530	006200				ASR R0	:	
8071	053532	006200				ASR R0	:	
8072	053534	042700	177700			BIC #177700,R0		
8073	053540	010066	000014			MOV R0,14(SP)	: *,OLDCHN	
8074	053544	012746	000001			MOV #1,-(SP)	:	
8075	053550	016646	000022			MOV 22(SP),-(SP)	: COMMAND,*	4919
8076	053554	016646	000014			MOV 14(SP),-(SP)	: LUN,*	
8077	053560	012746	000400			MOV #400,-(SP)		
8078	053564	016646	000032			MOV 32(SP),-(SP)	: PTR,*	
8079	053570	016646	000036			MOV 36(SP),-(SP)	: OLDSEC,*	
8080	053574	004767	172424			JSR PC,RETRY		
8081	053600	062706	000014			ADD #14,SP		
8082	053604	020027	000005			CMP R0,#5		
8083	053610	001052				BNE 35\$		
8084	053612	027766	160574	000024		CMP @ML.REG+44,24(SP)	: *,OLDSEC	4928
8085	053620	001035				BNE 34\$		
8086	053622	016646	000014			MOV 14(SP),-(SP)	: OLDCHN,*	
8087	053626	017700	160556			MOV @ML.REG+42,R0		
8088	053632	006200				ASR R0		
8089	053634	006200				ASR R0		
8090	053636	006200				ASR R0		
8091	053640	006200				ASR R0		
8092	053642	006200				ASR R0		
8093	053644	006200				ASR R0		
8094	053646	042700	177700			BIC #177700,R0		
8095	053652	020026				CMP R0,(SP)+		

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (38)

3152 :MLX4
8153 :
8154 :
8155 :
8156 :
8157 :
8158 :
8159 :
8160 :
8161 :
8162 :
8163 :
8164 :
8165 :
8166 :
8167 :
8168 :
8169 :
8170 :
8171 :
8172 :
8173 :
8174 :
8175 :
8176 :
8177 :
8178 :
8179 :
8180 :
8181 :
8182 :
8183 :
8184 :
8185 :
8186 :
8187 :
8188 :
8189 :
8190 :
8191 :
8192 :
8193 :
8194 :
8195 :
8196 :
8197 :
8198 :
8199 :
8200 :
8201 :
8202 :
8203 :
8204 :
8205 :
8206 :

DEFINITION OF OPTION 2

%sbttl 'DEFINITION OF OPTION 2'
routine OPT2 : novalue =
begin

!* 1 * START OF ROUTINE

```
++
ROUTINE:      OPT2
PURPOSE:      TO CHECK ON DATA RELIABILITY USING THE PATTERNS FROM
               THE PATTERN TABLE.
THE CODE FOR 'OPT2' IN BRIEF:
BEGIN 1 (START OF ROUTINE)
SAY THE ROUTINE IS RUNNING
CHOOSE A MAXIMUM PATTERN NUMBER
INCR COUNT FROM 1 TO (2*MAX)
: BEGIN 2 (START OF PATTERN SELECTION LOOP)
: GENERATE THE PATTERN
: INCR LUN FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : INITIALIZE THE WRITE AND READ BUFFER POINTERS
: : : : SECTOR = LOWEST
: : : : WHILE SECTOR LEQ HIGHEST DO
: : : : : BEGIN 6 (START OF SECTOR SELECTION LOOP)
: : : : : GET WIDCNT
: : : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : UPDATE SECTOR NUMBER BY NUMBER OF SECTORS IN PREVIOUS TRANSFER
: : : : : END 6 (END OF SECTOR SELECTION LOOP)
: : : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : : : END 4 (END OF TESTLOOP)
: : : : : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
: : : IF NOT THE QUICK VERIFY PASS THEN 'LOOP READ' (DESCRIBED BELOW)
: : END 2 (END OF PATTERN SELECTION LOOP)
RETURN
END 1 (END OF ROUTINE)
```

Label
LOOP
LOOP2;

5028
5029
5030
5031
5032

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (38)

```

8208 :MLX4
8209 :
8210 :      DEFINITION OF OPTION 2
8211 :      5033      local
8212 :      5034          WRDCNT,
8213 :      5035          VALUE,
8214 :      5036          TEMP,
8215 :      5037          MAXPAT,
8216 :      5038          OLDSEC,
8217 :      5039          OLDCHN,
8218 :      5040          SECTOR,
8219 :      5041          PTR,
8220 :      5042          COMMAND,
8221 :      5043          DBL_VALUE:
8222 :      5044
8223 :      5045      PRINTB (SAY2, WRD34, RTN2);
8224 :      5046      !'RUNNING OPT2'
8225 :      5047      PATTERN = 0;
8226 :      5048
8227 :      5049      if .QUICK neq 0 then MAXPAT = 1 else MAXPAT = NUM_PATS;
8228 :      5050
8229 :      5051      incr COUNT from 1 to (.MAXPAT*2) do
8230 :      5052          begin
8231 :      5053              SELPAT ();
8232 :      5054
8233 :      5055              if .PATTERN gtr 0
8234 :      5056                  then
8235 :      5057                  PRINTB (FMT1A, PHR9, .PATTERN)
8236 :      5058                  !'PATTERN NUMBER  XX'
8237 :      5059              else
8238 :      5060                  begin
8239 :      5061                      TEMP = -(.PATTERN);
8240 :      5062                      PRINTB (FMT1B, PHR9, .TEMP);
8241 :      5063                      !'      PATTERN NUMBER - XX'
8242 :      5064                  end;
8243 :      5065
8244 :      5066              GEN2 (.PATTERN);
8245 :      5067
8246 :      5068              incr LUN from 0 to (.LSUNIT - 1) do
8247 :      5069                  begin
8248 :      5070                      LOOP :
8249 :      5071                          begin
8250 :      5072                              begin
8251 :      5073                                  if .DRIVE_STATUS [LUN] eql ACTIVE
8252 :      5074                                      then
8253 :      5075                                          begin
8254 :      5076                                              LSLUN = .LUN;
8255 :      5077                                              WPTR = WBIFF;
8256 :      5078                                              RPTR = RBUFF;
8257 :      5079                                              SECTOR = LOWEST;
8258 :      5080
8259 :      5081                                              while .SECTOR lequ HIGHEST do
8260 :      5082                                                  begin
8261 :      5083                                                      WRDCNT = GET WRDCNT (.SECTOR, HIGHEST);
8262 :      5084                                                      SET_PTRS (.WRDCNT);
    
```

!* 2 * START OF PATTERN SELECTION LOOP

!* 3 * START OF LOGICAL UNIT SELECTION LOOP

!* 4 * START OF THE LOOP THAT COMPLETELY TESTS 1 UNIT

!* 5 * START OF TEST FOR AN ACTIVE UNIT

!* 6 * START OF SECTOR SELECTION LOOP

8264 :MLX4
 8265 :
 8266 :
 8267 :
 8268 :
 8269 :
 8270 :
 8271 :
 8272 :
 8273 :
 8274 :
 8275 :
 8276 :
 8277 :
 8278 :
 8279 :
 8280 :
 8281 :
 8282 :
 8283 :
 8284 :
 8285 :
 8286 :
 8287 :
 8288 :
 8289 :
 8290 :
 8291 :
 8292 :
 8293 :
 8294 :
 8295 :
 8296 :
 8297 :
 8298 :
 8299 :
 8300 :
 8301 :
 8302 :
 8303 :
 8304 :
 8305 :
 8306 :
 8307 :
 8308 :
 8309 :
 8310 :
 8311 :
 8312 :
 8313 :
 8314 :
 8315 :
 8316 :
 8317 :
 8318 :

DEFINITION OF OPTION 2

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (38)

```

VALUE = write (.LUN, .WRDCNT, .WPTR, .SECTOR);

!+
!- SEE HOW SUCCESSFUL THE WRITE WAS:

selectone .VALUE of
  set
    [1] :
      begin
        !* 6A * RETRY ALLOWED
        if RETRY (SIX, write, .LUN, .WRDCNT, .WPTR, .SECTOR) neq 0
          then
            !THE RETRY FAILED -- SYSTEM FATAL ERROR
            begin
              WHY DROPT [.LUN] = CODE_4;
              ERRDF (201, MSG1, 0); !**** OPTION 2 ERROR 01 ****
              DODU (.LUN);
              leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
            end;
          end;
        !* 6A *

    [2] :
      begin
        !* 6B * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
        WHY DROPT [.LUN] = CODE_5;
        ERRDF (202, MSG1, 0); !**** OPTION 2 ERROR 02 ****
        DODU (.LUN);
        leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
      end;
      !* 6B *

    [3] :
      begin
        !* 6C * FATAL DRIVE ERROR -- NO RETRY ALLOWED
        ERRDF (203, MSG1, 0); !**** OPTION 2 ERROR 03 ****
        WHY DROPT [.LUN] = CODE_6;
        DODU (.LUN);
        leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
      end;
      !* 6C *

  tes;

COMMAND = CHOOSE ();

if .COMMAND eql read
then
  begin
    PTR = .RPTR;
    VALUE = read (.LUN, .WRDCNT, .RPTR, .SECTOR);
  end
else
  begin
    PTR = .WPTR;
    VALUE = CHECK (.LUN, .WRDCNT, .WPTR, .SECTOR);
  end

```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (38)

8320 :MLX4
8321 :
8322 :
8323 :
8324 :
8325 :
8326 :
8327 :
8328 :
8329 :
8330 :
8331 :
8332 :
8333 :
8334 :
8335 :
8336 :
8337 :
8338 :
8339 :
8340 :
8341 :
8342 :
8343 :
8344 :
8345 :
8346 :
8347 :
8348 :
8349 :
8350 :
8351 :
8352 :
8353 :
8354 :
8355 :
8356 :
8357 :
8358 :
8359 :
8360 :
8361 :
8362 :
8363 :
8364 :
8365 :
8366 :
8367 :
8368 :
8369 :
8370 :
8371 :
8372 :
8373 :
8374 :

5137
5138
5139
5140
5141
5142
5143
5144
5145
5146
5147
5148
5149
5150
5151
5152
5153
5154
5155
5156
5157
5158
5159
5160
5161
5162
5163
5164
5165
5166
5167
5168
5169
5170
5171
5172
5173
5174
5175
5176
5177
5178
5179
5180
5181
5182
5183
5184
5185
5186
5187
5188

DEFINITION OF OPTION 2

```
end:
!+
SEE HOW SUCCESSFUL THE OPERATION WAS:
!-
selectone .VALUE of      !SEE 'SYSERR' FOR DEFINITION
set                      !OF ERROR # CONTAINED IN 'VALUE'

[0] :
  if .COMMAND eql read
  then
  begin
    if (DBL_VALUE = DOUBLE_CHECK (.WPTR, .RPTR, .WRDCNT)) neq 0
    then
    begin
      SAYWHO (.LUN);
      PRINTB (SAY1, MSG5);
      PRINTB (FMT12A, .DBL_VALUE, .DBL_VALUE);
      !'ECC LOGIC FAILED TO DETECT DATA ERROR'
      !'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
      DBL_VALUE = .DBL_VALUE + BUFSIZ*2;
      PRINTB (FMT12B, .DBL_VALUE, .DBL_VALUE);
      !'BAD DATA: PPPPPP AT LOCATION QQQQQQ'
      WHY DROPT [.LUN] = CODE_8;
      ERRDF (204, MSG1, 0);
      DODU (.LUN);
      !'**** OPTION 2 ERROR 04 ****'
      leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
    end;
  end;

[1] :
  begin
    !* 6D * RETRY ALLOWED
    if RETRY (SIX, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) neq 0
    then
    begin
      !THE RETRY FAILED -- SYSTEM FATAL ERROR
      WHY DROPT [.LUN] = CODE_4;
      ERRDF (205, MSG1, 0);
      !'**** OPTION 2 ERROR 05 ****'
      DODU (.LUN);
      !JUMP JUST BEYOND END OF BLOCK * 4 *
      leave LOOP;
    end;
  end;
  !* 6D *

[2] :
  begin
    !* 6E * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
    WHY DROPT [.LUN] = CODE_5;
    ERRDF (206, MSG1, 0);
    !'**** OPTION 2 ERROR 06 ****'
    DODU (.LUN);
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (38)

```

8376 :MLX4
8377 :
8378 :
8379 : 5189          leave LOOP;          !JUMP JUST BEYOND END OF BLOCK * 4 *
8380 : 5190          end;          !* 6E *
8381 :
8382 :
8383 : [3] :
8384 : 5191          begin          !* 6F * FATAL DRIVE ERROR -- NO RETRY ALLOWED
8385 : 5192          ERRDF (207, MSG1, 0);          !**** OPTION 2 ERROR 07 ****
8386 : 5193          WHY DROPT [.LUN] = CODE_6;
8387 : 5194          DODD (.LUN);
8388 : 5195          leave LOOP;          !JUMP JUST BEYOND END OF BLOCK * 4 *
8389 : 5196          end;          !* 6F *
8390 :
8391 : [4] :
8392 : 5200          begin          !* 6G * UNRECOVERABLE DATA ERROR
8393 : 5201          ISOLATE ();
8394 : 5202          ERRDF (208, MSG2, 0);          !**** OPTION 2 ERROR 08 ****
8395 : 5203          WHY DROPT [.LUN] = CODE_7;
8396 : 5204          DODD (.LUN);
8397 : 5205          leave LOOP;          !JUMP JUST BEYOND END OF BLOCK * 4 *
8398 : 5206          end;          !* 6G *
8399 :
8400 : [5] :
8401 : 5207          begin          !* 6H * RECOVERABLE DATA ERROR
8402 : 5208          ISOLATE ();
8403 : 5209
8404 : 5210          if .ERROUT then PRINTB (FMT10B, .CHAN);
8405 : 5211
8406 : 5212          !' BIT QQ'
8407 : 5213          OLDSEC = .MLEL;
8408 : 5214          OLDCHN = .CHAN;
8409 : 5215
8410 : 5216          if RETRY (ONE, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) eql 5
8411 : 5217          then
8412 : 5218
8413 : 5219          if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
8414 : 5220          then
8415 : 5221          begin
8416 : 5222          if .ERROUT then ERRHRD (209, MSG4, 0);          !**** OPTION 2 ERROR 09 ****
8417 : 5223          UP_HARD_COUNT (.LUN, .BOARD);
8418 : 5224          end
8419 : 5225          else
8420 : 5226          begin
8421 : 5227          if .ERROUT then ERRSOFT (210, MSG3, 0);          !**** OPTION 2 ERROR 10 ****
8422 : 5228          UP_SOFT_COUNT (.LUN, .BOARD);
8423 : 5229          end
8424 : 5230          else
8425 : 5231          begin
8426 : 5232
8427 : 5233
8428 : 5234
8429 : 5235
8430 : 5236
    
```

```

8432 :MLX4
8433 :
8434 :
8435 : 5241
8436 : 5242
8437 : 5243
8438 : 5244
8439 : 5245
8440 : 5246
8441 : 5247
8442 : 5248
8443 : 5249
8444 : 5250
8445 : 5251
8446 : 5252
8447 : 5253
8448 : 5254
8449 : 5255
8450 : 5256
8451 : 5257
8452 : 5258
8453 : 5259
8454 : 5260
8455 : 5261
8456 : 5262
8457 : 5263
8458 : 5264
8459 : 5265
8460 : 5266
8461 : 5267
8462 : 5268
8463 : 5269
8464 : 5270
8465 : 5271
8466 : 5272
8467 : 5273
8468 : 5274
8469 : 5275
8470 : 5276
8471 : 5277
8472 : 5278
8473 : 5279
8474 : 5280
8475 : 5281
8476 : 5282
8477 : 5283
8478 : 5284
8479 : 5285
8480 : 5286
8481 : 5287
8482 : 5288
8483 : 5289
8484 : 5290
8485 : 5291
8486 : 5292

DEFINITION OF OPTION 2

if .ERROUT then ERRSOFT (211, MSG3, 0); !*** OPTION 2 ERROR 11 ***
UP_SOFT_COUNT (.LUN, .BOARD);
end;

end; !* 6H *
tes:

WPTR = .WPTR + (.WRDCNT*2);
SECTOR = .SECTOR + (.WRDCNT/256);
end; !* 6 * END OF SECTOR SELECTION LOOP

end; !* 5 * END OF TEST FOR AN ACTIVE UNIT

end; !* 4 * END OF TESTLOOP
end; !* 3 * END OF LOGICAL UNIT SELECTION LOOP

if .QUICK eql 0
then
begin !* 11 * START OF LOOP READING SECTION

++
THIS IS THE 'LOOP READ' SECTION WHICH WAS MENTIONED IN
THE DOCUMENTATION AT THE BEGINNING OF THIS ROUTINE. IT
IS NOT EXECUTED DURING THE QUICK VERIFY PASS, BUT IT IS
FOR EVERY OTHER PASS THROUGH OPT2.

THE CODE IN BRIEF:

BEGIN 11 (START OF LOOP READING SECTION)
INCR LUN FROM 0 TO LAST
: BEGIN 12 (START OF LOGICAL UNIT SELECTION LOOP)
: TESTLOOP2:
: : BEGIN 13 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : IF UNIT IS ACTIVE
: : THEN
: : : BEGIN 14 (START OF TEST FOR AN ACTIVE UNIT)
: : : INITIALIZE THE WRITE AND READ BUFFER POINTERS
: : : SECTOR = LOWEST
: : : WHILE SECTOR LEQ HIGHEST DO
: : : : BEGIN 15 (START OF SECTOR SELECTION LOOP)
: : : : GET WRDCNT
: : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : INCR KOUNT FROM 1 TO TIMES
: : : : : BEGIN 16 (START OF COUNTING LOOP FOR LOOP READING)
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP2)
: : : : : END 16 (END OF COUNTING LOOP FOR LOOP READING)
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : UPDATE SECTOR NUMBER BY # SECTORS IN PREVIOUS TRANSFER
: : : : : END 15 (END OF SECTOR SELECTION LOOP)

```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (38)

```

8488 :MLX4
8489 :
8490 :
8491 : 5293
8492 : 5294
8493 : 5295
8494 : 5296
8495 : 5297
8496 : 5298
8497 : 5299
8498 : 5300
8499 : 5301
8500 : 5302
8501 : 5303
8502 : 5304
8503 : 5305
8504 : 5306
8505 : 5307
8506 : 5308
8507 : 5309
8508 : 5310
8509 : 5311
8510 : 5312
8511 : 5313
8512 : 5314
8513 : 5315
8514 : 5316
8515 : 5317
8516 : 5318
8517 : 5319
8518 : 5320
8519 : 5321
8520 : 5322
8521 : 5323
8522 : 5324
8523 : 5325
8524 : 5326
8525 : 5327
8526 : 5328
8527 : 5329
8528 : 5330
8529 : 5331
8530 : 5332
8531 : 5333
8532 : 5334
8533 : 5335
8534 : 5336
8535 : 5337
8536 : 5338
8537 : 5339
8538 : 5340
8539 : 5341
8540 : 5342
8541 : 5343
8542 : 5344

```

```

DEFINITION OF OPTION 2
: : : END 14 (END OF TEST FOR AN ACTIVE UNIT)
: : : END 13 (END OF TESTLOOP2)
: : : END 12 (END OF LOGICAL UNIT SELECTION LOOP)
: : : END 11 (END OF LOOP READING SECTION)
--
incr LUN from 0 to (.LSUNIT - 1) do
begin
LOOP2 :
begin
if .DRIVE_STATUS [.LUN] eql ACTIVE
then
begin
LSLUN = .LUN;
WPTR = WBUFF;
RPTR = RBUFF;
SECTOR = LOWEST;
while .SECTOR lequ HIGHEST do
begin
WRDCNT = GET WRDCNT (.SECTOR, HIGHEST);
SET PTRS (.WRDCNT);
COMMAND = CHOOSE ();
incr KOUNT from 1 to TIMES_TO_LOOP do
begin
if .COMMAND eql read
then
begin
PTR = .RPTR;
VALUE = read (.LUN, .WRDCNT, .RPTR, .SECTOR);
end
else
begin
PTR = .WPTR;
VALUE = CHECK (.LUN, .WRDCNT, .WPTR, .SECTOR);
end;
!+
SEE HOW SUCCESSFUL THE OPERATION WAS:
!-
selectone .VALUE of
set
[0] :
if .COMMAND eql read
then
begin
!SEE 'SYSERR' FOR DEFINITION
!OF ERROR # CONTAINED IN 'VALUE'

```


27-Mar-1982 19:24:42 IOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (38)

8544 :MLX4
 8545 :
 8546 :
 8547 :
 8548 :
 8549 :
 8550 :
 8551 :
 8552 :
 8553 :
 8554 :
 8555 :
 8556 :
 8557 :
 8558 :
 8559 :
 8560 :
 8561 :
 8562 :
 8563 :
 8564 :
 8565 :
 8566 :
 8567 :
 8568 :
 8569 :
 8570 :
 8571 :
 8572 :
 8573 :
 8574 :
 8575 :
 8576 :
 8577 :
 8578 :
 8579 :
 8580 :
 8581 :
 8582 :
 8583 :
 8584 :
 8585 :
 8586 :
 8587 :
 8588 :
 8589 :
 8590 :
 8591 :
 8592 :
 8593 :
 8594 :
 8595 :
 8596 :
 8597 :
 8598 :

DEFINITION OF OPTION 2

5345
 5346
 5347
 5348
 5349
 5350
 5351
 5352
 5353
 5354
 5355
 5356
 5357
 5358
 5359
 5360
 5361
 5362
 5363
 5364
 5365
 5366
 5367
 5368
 5369
 5370
 5371
 5372
 5373
 5374
 5375
 5376
 5377
 5378
 5379
 5380
 5381
 5382
 5383
 5384
 5385
 5386
 5387
 5388
 5389
 5390
 5391
 5392
 5393
 5394
 5395
 5396

```

if (DBL_VALUE = DOUBLE_CHECK (.WPTR, .RPTR, .WRDCNT)) neq 0
then
begin
  SAYWHO (.LUN);
  PRINTB (SAY1, MSG5);
  !'ECC LOGIC FAILED TO DETECT DATA ERROR'
  PRINTB (FMT12A, .DBL_VALUE, .DBL_VALUE);
  !'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
  DBL_VALUE = .DBL_VALUE + BUFSIZ*2;
  PRINTB (FMT12B, .DBL_VALUE, .DBL_VALUE);
  !'BAD DATA: P P P P P AT LOCATION Q Q Q Q Q'
  WHY DROPT [.LUN] = CODE_8;
  ERRDF (212, MSG1, 0);          !**** OPTION 2 ERROR 12 ****
  DODU (.LUN);
  leave LOOP2;                  !JUMP JUST BEYOND END OF BLOCK * 4 *
end;
    
```

end;

```

[1] :
begin      !* 16A *          RETRY ALLOWED
if RETRY (SIX, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) neq 0
then      !THE RETRY FAILED -- SYSTEM FATAL ERROR
begin
  WHY DROPT [.LUN] = CODE_4;
  ERRDF (213, MSG1, 0);      !**** OPTION 2 ERROR 13 ****
  DODU (.LUN);
  leave LOOP2;              !JUMP JUST BEYOND END OF BLOCK * 13 *
end;
end;      !* 16A *

[2] :
begin      !* 16B *          FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
WHY DROPT [.LUN] = CODE_5;
ERRDF (214, MSG1, 0);      !**** OPTION 2 ERROR 14 ****
DODU (.LUN);
leave LOOP2;              !JUMP JUST BEYOND END OF BLOCK * 13 *
end;      !* 16B *

[3] :
begin      !* 16C *          FATAL DRIVE ERROR -- NO RETRY ALLOWED
ERRDF (215, MSG1, 0);      !**** OPTION 2 ERROR 15 ****
WHY DROPT [.LUN] = CODE_6;
DODU (.LUN);
leave LOOP2;              !JUMP JUST BEYOND END OF BLOCK * 13 *
end;      !* 16C *

[4] :
begin      !* 16D *          UNRECOVERABLE DATA ERROR
    
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (38)

```

8600 :MLX4
8601 :
8602 :
8603 : 5397
8604 : 5398
8605 : 5399
8606 : 5400
8607 : 5401
8608 : 5402
8609 : 5403
8610 : 5404
8611 : 5405
8612 : 5406
8613 : 5407
8614 : 5408
8615 : 5409
8616 : 5410
8617 : 5411
8618 : 5412
8619 : 5413
8620 : 5414
8621 : 5415
8622 : 5416
8623 : 5417
8624 : 5418
8625 : 5419
8626 : 5420
8627 : 5421
8628 : 5422
8629 : 5423
8630 : 5424
8631 : 5425
8632 : 5426
8633 : 5427
8634 : 5428
8635 : 5429
8636 : 5430
8637 : 5431
8638 : 5432
8639 : 5433
8640 : 5434
8641 : 5435
8642 : 5436
8643 : 5437
8644 : 5438
8645 : 5439
8646 : 5440
8647 : 5441
8648 : 5442
8649 : 5443
8650 : 5444
8651 : 5445
8652 : 5446
8653 : 5447
8654 : 5448
    
```

DEFINITION OF OPTION 2

```

ISOLATE ();
ERRDF (216, MSG2, 0);
WHY DROPT [.LUN] = CODE_7;
DODD (.LUN);
leave LOOP2;
end;
!* 16D *

[5] :
begin
ISOLATE ();
!* 16E * RECOVERABLE DATA ERROR

if .ERROUT then PRINTB (FMT10B, .CHAN);
!* BIT 00'

OLDSEC = .MLEL;
OLDCHN = .CHAN;

if RETRY (ONE, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) eql 5
then
    if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
    then
        begin
            if .ERROUT then ERRHRD (217, MSG4, 0);

            !**** OPTION 2 ERROR 17 ****
            UP_HARD_COUNT (.LUN, .BOARD);
        end
    else
        begin
            if .ERROUT then ERRSOFT (218, MSG3, 0);

            !**** OPTION 2 ERROR 18 ****
            UP_SOFT_COUNT (.LUN, .BOARD);
        end
    else
        begin
            if .ERROUT then ERRSOFT (219, MSG3, 0); !**** OPTION 2 ERROR 19 ****

            UP_SOFT_COUNT (.LUN, .BOARD);
        end;
    end;
!* 16E *
tes;

end;
!* 16 * END OF COUNTING LOOP FOR LOOP READING

WPTR = .WPTR + (.WRDCNT*2);
SECTOR = .SECTOR + (.WRDCNT/256);
    
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (38)

```

8656 :MLX4
8657 :
8658 :
8659 : 5449
8660 : 5450
8661 : 5451
8662 : 5452
8663 : 5453
8664 : 5454
8665 : 5455
8666 : 5456
8667 : 5457
8668 : 5458
8669 : 5459
8670 : 5460
8671 : 5461
8672 : 5462
8673 : 5463
8674 : 5464
8675 : 5465
8676 : 5466
8677 : 5467
8678 : 5468
8679 : 5469
8680 : 5470
8681 : 5471
8682 : 5472
8683 : 5473
8684 : 5474
8685 : 5475
8686 : 5476
8687 : 5477
8688 : 5478
8689 : 5479
8690 : 5480
8691 : 5481
8692 : 5482
8693 : 5483
8694 : 5484
8695 : 5485
8696 : 5486
8697 : 5487
8698 : 5488
8699 : 5489
8700 : 5490
8701 : 5491
8702 : 5492
8703 : 5493
8704 : 5494
8705 : 5495
8706 : 5496
8707 : 5497
8708 : 5498
8709 : 5499
8710 : 5500

DEFINITION OF OPTION 2

end:
!* 15 * END OF SECTOR SELECTION LOOP

end:
!* 14 * END OF TEST FOR AN ACTIVE UNIT

!+
! Test to see if this uut's address space is
! to be read for soft errors. This test is
! is intended for DMT purposes.
:-
if .EFNS21
then
begin
!* Is the background pattern to be read

!
! version czmlbb changed incr to incru
incru SECTOR from LOWEST to HIGHEST do
    if read (.LUN, 256, RBUFF, .SECTOR) eql 5
    then
        begin
            ISOLATE ();
            !Find the failing bank and board no.
            if .ERROUT then PRINTB (FMT10B, .CHAN);
            ! Print where the error is
            ! Save the contents of the ML error location
            ! register so we can compare it to the new
            ! contents of this register after the retry.
            ! This is done to classify the error.
            OLDSEC = .MLEL;
            OLDCHN = .CHAN;
            ! Do a classify retry call. If the same error
            ! occurs then classify it as a hard error. If
            ! a different error occurred or the error went away
            ! then classify it as a soft error.

            if RETRY (ONE, .COMMAND, .LUN, 256, .PTR, .OLDSEC) eql 5
            then
                ! The same error occurred so see if it is at the same
                ! sector and channel number, if so then classify
                ! it as a hard error else classiy it as a soft
                ! error.

                if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
    
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (38)

8712 :MLX4
 8713 :
 8714 :
 8715 : 5501
 8716 : 5502
 8717 : 5503
 8718 : 5504
 8719 : 5505
 8720 : 5506
 8721 : P 5507
 8722 : P 5508
 8723 : 5509
 8724 : 5510
 8725 : 5511
 8726 : 5512
 8727 : 5513
 8728 : 5514
 8729 : 5515
 8730 : 5516
 8731 : 5517
 8732 : 5518
 8733 : 5519
 8734 : P 5520
 8735 : P 5521
 8736 : 5522
 8737 : 5523
 8738 : 5524
 8739 : 5525
 8740 : 5526
 8741 : 5527
 8742 : 5528
 8743 : 5529
 8744 : 5530
 8745 : 5531
 8746 : 5532
 8747 : 5533
 8748 : P 5534
 8749 : P 5535
 8750 : 5536
 8751 : 5537
 8752 : 5538
 8753 : 5539
 8754 : 5540
 8755 : 5541
 8756 : 5542
 8757 : 5543
 8758 : 5544
 8759 : 5545
 8760 : 5546
 8761 : 5547
 8762 : 5548
 8763 : 5549
 8764 : 5550
 8765 : 5551
 8766 : 5552

DEFINITION OF OPTION 2

```

then
  begin
    !Same error ocured 'hard'
    if .ERROUT !Print error if enabled
    then
      begin
        ERRHRD (220, !Error number
                MSG4, !Error message
                0); !Additional message routine
      end;
      UP_HARD_COUNT (.LUN, .BOARD);
    end
  else
    begin
      !Not the same error 'soft'
      if .ERROUT !Print error if enabled
      then
        begin
          ERRSOFT (221, !Error number
                  MSG3, !Error message
                  0); !Additional message routine
        end;
        UP_SOFT_COUNT (.LUN, .BOARD);
      end
    else
      begin
        !Not the same error 'soft'
        if .ERROUT !Print error if enabled
        then
          begin
            ERRSOFT (222, !Error number
                    MSG3, !Error message
                    0); !Additional message routine
          end;
          UP_SOFT_COUNT (.LUN, .BOARD);
        end;
      end;
    end;
  end;
end;
end;
end;
end;
end;

```

!* 13 * END OF TESTLOOP2
 !* 12 * END OF LOGICAL UNIT SELECTION LOOP
 !* 11 * END OF LOOP READING SECTION
 !* 2 * END OF PATTERN SELECTION LOOP

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (38)

!* 1 * END OF ROUTINE

Address	Label	Hex	Hex	Hex	Instruction	Comment	Address
8768	:MLX4						
8769	:						
8770	:						
8771	:	5553			return;		
8772	:	5554			end;		
8776	:						
8777	:						
8781	054054	004167	131254		OPT2: JSR	.SBTTL OPT2 DEFINITION OF OPTION 2	
8782	054060	162706	000026		SUB	R1,\$SAVE5	4982
8783	054064	012746	007634		MOV	#26,SP	
8784	054070	012746	007344		MOV	#RTN2,-(SP)	5045
8785	054074	012746	007100		MOV	#WRD34,-(SP)	
8786	054100	012746	000003		MOV	#SAY2,-(SP)	
8787	054104	010600			MOV	#3,-(SP)	
8788	054106	104414			MOV	SP,R0	: SP,*
8789	054110	005067	156562		TRAP	14	
8790	054114	005767	156554		CLR	PATTERN	
8791	054120	001403			TST	QUICK	5047
8792	054122	012705	000001		BEQ	1\$	5049
8793	054126	000402			MOV	#1,R5	: *,MAXPAT
8794	054130	012705	000012		BR	2\$	
8795	054134	010566	000032	1\$:	MOV	#12,R5	: *,MAXPAT
8796	054140	006366	000032	2\$:	MOV	R5,32(SP)	: MAXPAT,*
8797	054144	005066	000030		ASL	32(SP)	5051
8798	054150	000167	003650		CLR	30(SP)	: COUNT
8799	054154	004767	164706	3\$:	JMP	74\$	
8800	054160	005767	156512		JSR	PC,SELPAT	
8801	054164	003413			TST	PATTERN	5053
8802	054166	016746	156504		BLE	4\$	5055
8803	054172	012746	010100		MOV	PATTERN,-(SP)	
8804	054176	012746	006126		MOV	#PHR9,-(SP)	5057
8805	054202	012746	000003		MOV	#FMT1A,-(SP)	
8806	054206	010600			MOV	#3,-(SP)	
8807	054210	104414			MOV	SP,R0	: SP,*
8808	054212	000417			TRAP	14	
8809	054214	016766	156456	000034	BR	5\$	
8810	054222	005466	000034	4\$:	MOV	PATTERN,34(SP)	: *,TEMP
8811	054226	016646	000034		NEG	34(SP)	: TEMP
8812	054232	012746	010100		MOV	34(SP),-(SP)	: TEMP,*
8813	054236	012746	006142		MOV	#PHR9,-(SP)	5062
8814	054242	012746	000003		MOV	#FMT1B,-(SP)	
8815	054246	010600			MOV	#3,-(SP)	
8816	054250	104414			MOV	SP,R0	: SP,*
8817	054252	016716	156420	5\$:	TRAP	14	
8818	054256	004767	165150		MOV	PATTERN,(SP)	
8819	054262	016766	125524	000034	JSR	PC,GEN2	5066
8820	054270	005005			MOV	L\$UNIT,34(SP)	
8821	054272	000167	001462		CLR	R5	: LUN
8822	054276	010500		6\$:	JMP	33\$	
					MOV	R5,R0	: LUN,*

Address	OpCode	Operand 1	Operand 2	Operand 3	Label	Instruction	Comments	Address	Time	Page
8880										
8881										
8882										
8883	054532	000431				BR 10\$				
8884	054534	020327	000002		8\$:	CMP R3,#2	: VALUE,*		27-Mar-1982 19:24:42	TOPS
8885	054540	001012				BNE 9\$			27-Mar-1982 19:23:44	PA:<
8886	054542	112765	000005	034446		MOVB #5,WHY.DROPT(R5)	: *,*(LUN)			5103
8887	054550	104455				TRAP 55				5091
8888	054552	000312				.WORD 312				5110
8889	054554	011070				.WORD MSG1				5111
8890	054556	000000				.WORD 0				
8891	054560	010500				MOV R5,R0	: LUN,*			
8892	054562	104451				TRAP 51				5112
8893	054564	000414				BR 10\$				
8894	054566	020327	000003		9\$:	CMP R3,#3	: VALUE,*			5113
8895	054572	001014				BNE 12\$				5091
8896	054574	104455				TRAP 55				
8897	054576	000313				.WORD 313				5118
8898	054600	011070				.WORD MSG1				
8899	054602	000000				.WORD 0				
8900	054604	112765	000006	034446		MOVB #6,WHY.DROPT(R5)	: *,*(LUN)			5119
8901	054612	010500				MOV R5,R0	: LUN,*			5120
8902	054614	104451				TRAP 51				
8903	054616	062706	000012		10\$:	ADD #12,SP				
8904	054622	000537			11\$:	BR 15\$				5121
8905	054624	004767	171336		12\$:	JSR PC,CHOOSE				
8906	054630	010066	000034			MOV R0,34(SP)	: *,COMMAND			5125
8907	054634	005066	000040			CLR 40(SP)				
8908	054640	020027	045612			CMP R0,#READ	: COMMAND,*			5127
8909	054644	001015				BNE 13\$				
8910	054646	005266	000040			INC 40(SP)				
8911	054652	016766	156014	000036		MOV RPTR,36(SP)	: *,PTR			5130
8912	054660	010546				MOV R5,-(SP)	: LUN,*			5131
8913	054662	010246				MOV R2,-(SP)	: WRDCNT,*			
8914	054664	016746	156002			MOV RPTR,-(SP)				
8915	054670	010446				MOV R4,-(SP)	: SECTOR,*			
8916	054672	004767	170714			JSR PC,READ				
8917	054676	000412				BR 14\$				
8918	054700	016766	155764	000036	13\$:	MOV WPTR,36(SP)	: *,PTR			5135
8919	054706	010546				MOV R5,-(SP)	: LUN,*			5136
8920	054710	010246				MOV R2,-(SP)	: WRDCNT,*			
8921	054712	016746	155752			MOV WPTR,-(SP)				
8922	054716	010446				MOV R4,-(SP)	: SECTOR,*			
8923	054720	004767	171054			JSR PC,CHECK				
8924	054724	010003			14\$:	MOV R0,R3	: *,VALUE			
8925	054726	001076				BNE 16\$				
8926	054730	032766	000001	000050		BIT #1,50(SP)				5143
8927	054736	001513				BEQ 17\$				5148
8928	054740	016746	155724			MOV WPTR,-(SP)				
8929	054744	016746	155722			MOV RPTR,-(SP)				5152
8930	054750	010246				MOV R2,-(SP)	: WRDCNT,*			
8931	054752	004767	167350			JSR PC,DOUBLE.CHECK				
8932	054756	062706	000006			ADD #6,SP				
8933	054762	010066	000060			MOV R0,60(SP)	: *,DBL.VALUE			
8934	054766	001477				BEQ 17\$				

Address	Offset	Value	Label	Operation	Definition	Comments	Date/Time	Page
8936								
8937								
8938								
8939	054770	010546		MOV	R5,-(SP)			
8940	054772	004767	160526	JSR	PC,SAYWHO	: LUN,*	27-Mar-1982 19:24:42	TOPS
8941	054776	012716	011216	MOV	#MSG5,(SP)	:	27-Mar-1982 19:23:44	PA:<
8942	055002	012746	007072	MOV	#SAY1,-(SP)			5155
8943	055006	012746	000002	MOV	#2,-(SP)			5156
8944	055012	010600		MOV	SP,R0	: SP,*		
8945	055014	104414		TRAP	14			
8946	055016	016316	000066	MOV	66(SP),(SP)	: DBL.VALUE,*		5157
8947	055022	017646	000066	MOV	@66(SP),-(SP)	: DBL.VALUE,*		
8948	055026	012746	006710	MOV	#FMT12A,-(SP)			
8949	055032	012746	000003	MOV	#3,-(SP)			
8950	055036	010600		MOV	SP,R0	: SP,*		
8951	055040	104414		TRAP	14			
8952	055042	062766	010000	ADD	#10000,74(SP)	: *,DBL.VALUE		5159
8953	055050	016616	000074	MOV	74(SP),(SP)	: DBL.VALUE,*		5160
8954	055054	017646	000074	MOV	@74(SP),-(SP)	: DBL.VALUE,*		
8955	055060	012746	006756	MOV	#FMT12B,-(SP)			
8956	055064	012746	000003	MOV	#3,-(SP)			
8957	055070	010600		MOV	SP,R0	: SP,*		
8958	055072	104414		TRAP	14			
8959	055074	112765	000010	MOVB	#10,WHY.DROPT(R5)	: *,*(LUN)		5162
8960	055102	104455		TRAP	55	:		5163
8961	055104	000314		.WORD	314	:		
8962	055106	011070		.WORD	MSG1			
8963	055110	000000		.WORD	0			
8964	055112	010500		MOV	R5,R0	: LUN,*		5164
8965	055114	104451		TRAP	51			
8966	055116	062706	000044	ADD	#44,SP	:		5165
8967	055122	000510		BR	23\$			
8968	055124	020327	000001	CMP	R3,#1	: VALUE,*		5143
8969	055130	001033		BNE	19\$			
8970	055132	012746	000006	MOV	#6,-(SP)			5173
8971	055136	016646	000046	MOV	46(SP),-(SP)	: COMMAND,*		
8972	055142	010546		MOV	R5,-(SP)	: LUN,*		
8973	055144	010246		MOV	R2,-(SP)	: WRDCNT,*		
8974	055146	016646	000056	MOV	56(SP),-(SP)	: PTR,*		
8975	055152	010446		MOV	R4,-(SP)	: SECTOR,*		
8976	055154	004767	171044	JSR	PC,RETRY			
8977	055160	062706	000014	ADD	#14,SP			
8978	055164	005700		TST	R0			
8979	055166	001002		BNE	18\$			
8980	055170	000167	000520	JMP	31\$			
8981	055174	112765	000004	MOVB	#4,WHY.DROPT(R5)	: *,*(LUN)		5176
8982	055202	104455		TRAP	55	:		5177
8983	055204	000315		.WORD	315			
8984	055206	011070		.WORD	MSG1			
8985	055210	000000		.WORD	0			
8986	055212	010500		MOV	R5,R0	: LUN,*		5178
8987	055214	104451		TRAP	51			
8988	055216	000450		BR	22\$			
8989	055220	020327	000002	CMP	R3,#2	: VALUE,*		5179
8990	055224	001012		BNE	20\$			5143

Address	OpCode	Operand1	Operand2	Label	Instruction	Comments	Date/Time	Page
8992								
8993								
8994								
8995	055226	112765	000005	034446	MOVB #5,WHY.DROPT(R5)	: *,*(LUN)	27-Mar-1982 19:24:42	TOPS
8996	055234	104455			TRAP 55	: *	27-Mar-1982 19:23:44	PA:<
8997	055236	000316			.WORD 316			5186
8998	055240	011070			.WORD MSG1			5187
8999	055242	000000			.WORD 0			
9000	055244	010500			MOV R5,R0	: LUN,*		
9001	055246	104451			TRAP 51			5188
9002	055250	000433			BR 22\$			
9003	055252	020327	000003	20\$:	CMP R3,#3	: VALUE,*		5189
9004	055256	001012			BNE 21\$			5143
9005	055260	104455			TRAP 55			
9006	055262	000317			.WORD 317			5194
9007	055264	011070			.WORD MSG1			
9008	055266	000000			.WORD 0			
9009	055270	112765	000006	034446	MOVB #6,WHY.DROPT(R5)	: *,*(LUN)		5195
9010	055276	010500			MOV R5,R0	: LUN,*		5196
9011	055300	104451			TRAP 51			
9012	055302	000416			BR 22\$			
9013	055304	020327	000004	21\$:	CMP R3,#4	: VALUE,*		5197
9014	055310	001017			BNE 24\$			5143
9015	055312	004767	162014		JSR PC,ISOLATE			
9016	055316	104455			TRAP 55			5202
9017	055320	000320			.WORD 320			5203
9018	055322	011120			.WORD MSG2			
9019	055324	000000			.WORD 0			
9020	055326	112765	000007	034446	MOVB #7,WHY.DROPT(R5)	: *,*(LUN)		5204
9021	055334	010500			MOV R5,R0	: LUN,*		5205
9022	055336	104451			TRAP 51			
9023	055340	062706	000022	22\$:	ADD #22,SP			
9024	055344	000167	000406	23\$:	JMP 32\$			5206
9025	055350	020327	000005	24\$:	CMP R3,#5	: VALUE,*		
9026	055354	001157			BNE 31\$			5143
9027	055356	004767	161750		JSR PC,ISOLATE			
9028	055362	032767	000001	124670	BIT #1,ERROUT			5211
9029	055370	001423			BEQ 25\$			5213
9030	055372	017700	157012		MOV @ML.REG+42,R0			
9031	055376	006200			ASR R0			
9032	055400	006200			ASR R0			
9033	055402	006200			ASR R0			
9034	055404	006200			ASR R0			
9035	055406	006200			ASR R0			
9036	055410	006200			ASR R0			
9037	055412	042700	177700		BIC #177700,R0			
9038	055416	010046			MOV R0,-(SP)			
9039	055420	012746	006640		MOV #FMT10B,-(SP)			
9040	055424	012746	000002		MOV #2,-(SP)			
9041	055430	010600			MOV SP,R0	: SP,*		
9042	055432	104414			TRAP 14			
9043	055434	062706	000006		ADD #6,SP			
9044	055440	017766	156746	000052	MOV @ML.REG+44,52(SP)	: *,OLDSEC		5216
9045	055446	017700	156736		MOV @ML.REG+42,R0			5217
9046	055452	006200			ASR R0			

Address	OpCode	Operand 1	Operand 2	Operand 3	Operand 4	Comment	Label
9048							
9049							
9050							
9051	055454	006200				ASR R0	
9052	055456	006200				ASR R0	
9053	055460	006200				ASR R0	
9054	055462	006200				ASR R0	
9055	055464	006200				ASR R0	
9056	055466	042700	177700			BIC #177700,R0	
9057	055472	010066	000054			MOV R0,54(SP)	
9058	055476	012746	000001			MOV #1,-(SP)	: *,OLDCHN
9059	055502	016646	000046			MOV 46(SP),-(SP)	: COMMAND,*
9060	055506	010546				MOV R5,-(SP)	: LUN,*
9061	055510	010246				MOV R2,-(SP)	: WRDCNT,*
9062	055512	016646	000056			MOV 56(SP),-(SP)	: PTR,*
9063	055516	010446				MOV R4,-(SP)	: SECTOR,*
9064	055520	004767	170500			JSR PC,RETRY	
9065	055524	062706	000014			ADD #14,SP	
9066	055530	020027	000005			CMP R0,#5	
9067	055534	001051				BNE 28\$	
9068	055536	027766	156650	000052		CMP @ML.REG+44,52(SP)	: *,OLDSEC
9069	055544	001034				BNE 27\$: 5222
9070	055546	016646	000054			MOV 54(SP),-(SP)	: OLDCHN,*
9071	055552	017700	156632			MOV @ML.REG+42,R0	
9072	055556	006200				ASR R0	
9073	055560	006200				ASR R0	
9074	055562	006200				ASR R0	
9075	055564	006200				ASR R0	
9076	055566	006200				ASR R0	
9077	055570	006200				ASR R0	
9078	055572	042700	177700			BIC #177700,R0	
9079	055576	020026				CMP R0,(SP)+	
9080	055600	001016				BNE 27\$	
9081	055602	032767	000001	124450		BIT #1,ERROUT	: 5226
9082	055610	001404				BEQ 26\$	
9083	055612	104456				TRAP 56	
9084	055614	000321				.WORD 321	
9085	055616	011202				.WORD MSG4	
9086	055620	000000				.WORD 0	
9087	055622	010546				MOV R5,-(SP)	: LUN,*
9088	055624	016746	156512			MOV BOARD,-(SP)	: 5228
9089	055630	004767	161566			JSR PC,UP.HARD.COUNT	
9090	055634	000426				BR 30\$	
9091	055636	032767	000001	124414	27\$:	BIT #1,ERROUT	: 5222
9092	055644	001415				BEQ 29\$: 5233
9093	055646	104457				TRAP 57	
9094	055650	000322				.WORD 322	
9095	055652	011166				.WORD MSG3	
9096	055654	000000				.WORD 0	
9097	055656	000410				BR 29\$	
9098	055660	032767	000001	124372	28\$:	BIT #1,ERROUT	: 5235
9099	055666	001404				BEQ 29\$: 5241
9100	055670	104457				TRAP 57	
9101	055672	000323				.WORD 323	
9102	055674	011166				.WORD MSG3	

Address	Label	Code	Target	Comment	File	Line
9104						
9105	:MLX4					
9106	:			DEFINITION OF OPTION 2		
9107		055676	000000	.WORD 0		
9108		055700	010546	MOV R5,-(SP)		
9109		055702	016746	MOV BOARD,-(SP)	: LUN,*	5243
9110		055706	004767	JSR PC,UP.SOFT.COUNT		
9111		055712	022626	CMP (SP)+,(SP)+		
9112		055714	010200	MOV R2,R0	: WRDCNT,*	5210
9113		055716	006300	ASL R0		5249
9114		055720	066700	ADD WPTR,R0		
9115		055724	010067	MOV R0,WPTR		
9116		055730	010216	MOV R2,(SP)	: WRDCNT,*	
9117		055732	012746	MOV #400,-(SP)		5250
9118		055736	004767	JSR PC,BL\$DIV		
9119		055742	060400	ADD R4,R0	: SECTOR,*	
9120		055744	010004	MOV R0,R4	: *,SECTOR	
9121		055746	062706	ADD #24,SP		
9122		055752	000167	JMP 7\$		5082
9123		055756	005205	INC R5	: LUN	5081
9124		055760	020566	CMP R5,34(SP)	: LUN,*	5068
9125		055764	002002	BGE 34\$		
9126		055766	000167	JMP 6\$		
9127		055772	005767	TST QUICK	:	
9128		055776	001402	BEQ 35\$		5258
9129		056000	000167	JMP 73\$		
9130		056004	016766	MOV L\$UNIT,34(SP)		
9131		056012	005005	CLR R5	: LUN	5299
9132		056014	000167	JMP 72\$		
9133		056020	010500	MOV R5,R0	: LUN,*	
9134		056022	006200	ASR R0		5304
9135		056024	006200	ASR R0		
9136		056026	006200	ASR R0		
9137		056030	062700	ADD #DRIVE.STATUS,R0		
9138		056034	010046	MOV R0,-(SP)		
9139		056036	010546	MOV R5,-(SP)	: LUN,*	
9140		056040	042716	BIC #177770,(SP)		
9141		056044	012746	MOV #1,-(SP)		
9142		056050	005046	CLR -(SP)		
9143		056052	004767	JSR PC,BL\$GT2		
9144		056056	062706	ADD #10,SP		
9145		056062	005300	DEC R0		
9146		056064	001402	BEQ 38\$		
9147		056066	000167	JMP 60\$		
9148		056072	010567	MOV R5,L\$LUN	: LUN,*	5307
9149		056076	012767	MOV #WBUFF,WPTR		5308
9150		056104	012767	MOV #RBUFF,RPTR		5309
9151		056112	010501	MOV R5,R1	: LUN,*	5310
9152		056114	006301	ASL R1		
9153		056116	016104	MOV LOW.SECT(R1),R4	: *,SECTOR	
9154		056122	020461	CMP R4,TOP.SECT(R1)	: SECTOR,*	
9155		056126	101357	BHI 37\$		5312
9156		056130	010446	MOV R4,-(SP)	: SECTOR,*	
9157		056132	016146	MOV TOP.SECT(R1),-(SP)		5314
9158		056136	004767	JSR PC,GET.WRDCNT		

Address	OpCode	Operand1	Operand2	Label	Comment	Register	Value
9216							
9217				:MLX4			
9218				:	DEFINITION OF OPTION 2		
9219	056426	010600			MOV	SP,R0	: SP,*
9220	056430	104414			TRAP	14	
9221	056432	112765	000010	034446	MOVB	#10,WHY.DROPT(R5)	: *,*(LUN)
9222	056440	104455			TRAP	55	
9223	056442	000324			.WORD	324	
9224	056444	011070			.WORD	MSG1	
9225	056446	000000			.WORD	0	
9226	056450	010500			MOV	R5,R0	: LUN,*
9227	056452	104451			TRAP	51	
9228	056454	062706	000036		ADD	#36,SP	
9229	056460	000510			BR	50\$	
9230	056462	020327	000001		CMP	R3,#1	: VALUE,*
9231	056466	001033		43\$:	BNE	46\$	
9232	056470	012746	000006		MOV	#6,-(SP)	
9233	056474	016646	000040		MOV	40(SP),-(SP)	: COMMAND,*
9234	056500	010546			MOV	R5,-(SP)	: LUN,*
9235	056502	010246			MOV	R2,-(SP)	: WRDCNT,*
9236	056504	016646	000050		MOV	50(SP),-(SP)	: PTR,*
9237	056510	010446			MOV	R4,-(SP)	: SECTOR,*
9238	056512	004767	167506		JSR	PC,RETRY	
9239	056516	062706	000014		ADD	#14,SP	
9240	056522	005700			TST	R0	
9241	056524	001002		44\$:	BNE	45\$	
9242	056526	000167	000520		JMP	58\$	
9243	056532	112765	000004	034446	MOVB	#4,WHY.DROPT(R5)	: *,*(LUN)
9244	056540	104455		45\$:	TRAP	55	
9245	056542	000325			.WORD	325	
9246	056544	011070			.WORD	MSG1	
9247	056546	000000			.WORD	0	
9248	056550	010500			MOV	R5,R0	: LUN,*
9249	056552	104451			TRAP	51	
9250	056554	000450			BR	49\$	
9251	056556	020327	000002		CMP	R3,#2	: VALUE,*
9252	056562	001012		46\$:	BNE	47\$	
9253	056564	112765	000005	034446	MOVB	#5,WHY.DROPT(R5)	: *,*(LUN)
9254	056572	104455			TRAP	55	
9255	056574	000326			.WORD	326	
9256	056576	011070			.WORD	MSG1	
9257	056600	000000			.WORD	0	
9258	056602	010500			MOV	R5,R0	: LUN,*
9259	056604	104451			TRAP	51	
9260	056606	000433			BR	49\$	
9261	056610	020327	000003		CMP	R3,#3	: VALUE,*
9262	056614	001012		47\$:	BNE	48\$	
9263	056616	104455			TRAP	55	
9264	056620	000327			.WORD	327	
9265	056622	011070			.WORD	MSG1	
9266	056624	000000			.WORD	0	
9267	056626	112765	000006	034446	MOVB	#6,WHY.DROPT(R5)	: *,*(LUN)
9268	056634	010500			MOV	R5,R0	: LUN,*
9269	056636	104451			TRAP	51	
9270	056640	000416			BR	49\$	

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

5357
5358
5359
5360
5337
5368
5371
5372
5373
5374
5337
5381
5382
5383
5384
5337
5389
5390
5391
5392

DEFINITION OF OPTION 2

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

Address	OpCode	Operands	Comments	Label	Value	Seq
9272						
9273						
9274						
9275	056642	020327 000004				
9276	056646	001017				
9277	056650	004767 160456				
9278	056654	104455				
9279	056656	000330				
9280	056660	011120				
9281	056662	000000				
9282	056664	112765 000007 034446				
9283	056672	010500				
9284	056674	104451				
9285	056676	062706 000014				
9286	056702	000167 001076				
9287	056706	020327 000005				
9288	056712	001157				
9289	056714	004767 160412				
9290	056720	032767 000001 123332				
9291	056726	001423				
9292	056730	017700 155454				
9293	056734	006200				
9294	056736	006200				
9295	056740	006200				
9296	056742	006200				
9297	056744	006200				
9298	056746	006200				
9299	056750	042700 177700				
9300	056754	010046				
9301	056756	012746 006640				
9302	056762	012746 000002				
9303	056766	010600				
9304	056770	104414				
9305	056772	062706 000006				
9306	056776	017766 155410 000044 52\$:				
9307	057004	017700 155400				
9308	057010	006200				
9309	057012	006200				
9310	057014	006200				
9311	057016	006200				
9312	057020	006200				
9313	057022	006200				
9314	057024	042700 177700				
9315	057030	010066 000046				
9316	057034	012746 000001				
9317	057040	016646 000040				
9318	057044	010546				
9319	057046	010246				
9320	057050	016646 000050				
9321	057054	010446				
9322	057056	004767 167142				
9323	057062	062706 000014				
9324	057066	020027 000005				
9325	057072	001051				
9326	057074	027766 155312 000044				

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

Address	Instruction	Comments	Label	Value
9328				
9329				
9330				
9331	057102	001034		
9332	057104	016646		
9333	057110	017700		
9334	057114	006200		
9335	057116	006200		
9336	057120	006200		
9337	057122	006200		
9338	057124	006200		
9339	057126	006200		
9340	057130	042700		177700
9341	057134	020026		
9342	057136	001016		
9343	057140	032767		000001 123112
9344	057146	001404		
9345	057150	104456		
9346	057152	000331		
9347	057154	011202		
9348	057156	000000		
9349	057160	010546		53\$:
9350	057162	016746		155154
9351	057166	004767		160230
9352	057172	000426		
9353	057174	032767		000001 123056 54\$:
9354	057202	001415		
9355	057204	104457		
9356	057206	000332		
9357	057210	011166		
9358	057212	000000		
9359	057214	000410		
9360	057216	032767		000001 123034 55\$:
9361	057224	001404		
9362	057226	104457		
9363	057230	000333		
9364	057232	011166		
9365	057234	000000		
9366	057236	010546		56\$:
9367	057240	016746		155076
9368	057244	004767		160634
9369	057250	022626		
9370	057252	062706		000010 57\$:
9371	057256	005266		000032 58\$:
9372	057262	026627		000032 000002
9373	057270	003002		
9374	057272	000167		176672
9375	057276	010200		
9376	057300	006300		59\$:
9377	057302	066700		153362
9378	057306	010067		153356
9379	057312	010216		
9380	057314	012746		000400
9381	057320	004767		125644
9382	057324	060400		

Address	OpCode	Operand 1	Operand 2	Label	Comment	Definition	Timestamp	Page
9384								
9385				:MLX4			27-Mar-1982 19:24:42	TOPS
9386				:		DEFINITION OF OPTION 2	27-Mar-1982 19:23:44	PA:<
9387	057326	010004			MOV R0,R4	: *,SECTOR		
9388	057330	062706	000006		ADD #6,SP	:		
9389	057334	000167	176562		JMP 39\$:		5313
9390	057340	032767	000001	122714	60\$: BIT #1,EFNS21	:		5312
9391	057346	001002			BNE 61\$:		5459
9392	057350	000167	000430		JMP 71\$			
9393	057354	010500			61\$: MOV R5,R0	: LUN,*		5466
9394	057356	006300			ASL R0			
9395	057360	016066	034500	000026	MOV TOP.SECT(R0),26(SP)			
9396	057366	016001	034460		MOV LOW.SECT(R0),R1	: *,SECTOR		
9397	057372	000577			BR 70\$			
9398	057374	010546			62\$: MOV R5,-(SP)	: LUN,*		5468
9399	057376	012746	000400		MOV #400,-(SP)			
9400	057402	012746	022670		MOV #RBUF,-(SP)			
9401	057406	010146			MOV R1,-(SP)	: SECTOR,*		
9402	057410	004767	166176		JSR PC,READ			
9403	057414	062706	000010		ADD #10,SP			
9404	057420	020027	000005		CMP R0,#5			
9405	057424	001161			BNE 69\$			
9406	057426	004767	157700		JSR PC,ISOLATE			
9407	057432	032767	000001	122620	BIT #1,ERROUT	:		5471
9408	057440	001423			BEQ 63\$:		5473
9409	057442	017700	154742		MOV @ML.REG+42,R0			
9410	057446	006200			ASR R0			
9411	057450	006200			ASR R0			
9412	057452	006200			ASR R0			
9413	057454	006200			ASR R0			
9414	057456	006200			ASR R0			
9415	057460	006200			ASR R0			
9416	057462	042700	177700		BIC #177700,R0			
9417	057466	010046			MOV R0,-(SP)			
9418	057470	012746	006640		MOV #FMT10B,-(SP)			
9419	057474	012746	000002		MOV #2,-(SP)			
9420	057500	010600			MOV SP,R0	: S*,*		
9421	057502	104414			TRAP 14			
9422	057504	062706	000006		ADD #6,SP			
9423	057510	017766	154676	000030	63\$: MOV @ML.REG+44,30(SP)	: *,OLDSEC		5482
9424	057516	017700	154666		MOV @ML.REG+42,R0	:		5483
9425	057522	006200			ASR R0			
9426	057524	006200			ASR R0			
9427	057526	006200			ASR R0			
9428	057530	006200			ASR R0			
9429	057532	006200			ASR R0			
9430	057534	006200			ASR R0			
9431	057536	042700	177700		BIC #177700,R0			
9432	057542	010066	000032		MOV R0,32(SP)	: *,OLDCHN		
9433	057546	012746	000001		MOV #1,-(SP)	:		
9434	057552	016646	000024		MOV 24(SP),-(SP)	: COMMAND,*		5491
9435	057556	010546			MOV R5,-(SP)	: LUN,*		
9436	057560	012746	000400		MOV #400,-(SP)			
9437	057564	016646	000034		MOV 34(SP),-(SP)	: PTR,*		
9438	057570	016646	000042		MOV 42(SP),-(SP)	: OLDSEC,*		

Address	Instruction	Operand 1	Operand 2	Operand 3	Label	Comment	Address
9440							
9441							
9442							
9443	057574	004767	166424				
9444	057600	062706	000014				
9445	057604	020027	000005				
9446	057610	001051					
9447	057612	027766	154574	070030			
9448	057620	001034					
9449	057622	016646	000032				
9450	057626	017700	154556				
9451	057632	006200					
9452	057634	006200					
9453	057636	006200					
9454	057640	006200					
9455	057642	006200					
9456	057644	006200					
9457	057646	042700	177700				
9458	057652	020026					
9459	057654	001016					
9460	057656	032767	000001	122374			
9461	057664	001404					
9462	057666	104456					
9463	057670	000334					
9464	057672	011202					
9465	057674	000000					
9466	057676	010546					
9467	057700	016746	154436		64\$:		
9468	057704	004767	157512				
9469	057710	000426					
9470	057712	032767	000001	122340	65\$:		
9471	057720	001415					
9472	057722	104457					
9473	057724	000335					
9474	057726	011166					
9475	057730	000000					
9476	057732	000410					
9477	057734	032767	000001	122316	66\$:		
9478	057742	001404					
9479	057744	104457					
9480	057746	000336					
9481	057750	011166					
9482	057752	000000					
9483	057754	010546					
9484	057756	016746	154360		67\$:		
9485	057762	004767	160116				
9486	057766	022626			68\$:		
9487	057770	005201			69\$:		
9488	057772	020166	000026		70\$:		
9489	057776	101002					
9490	060000	000167	177370				
9491	060004	005205			71\$:		
9492	060006	020566	000034		72\$:		
9493	060012	002002					
9494	060014	000167	176000				

:MLX4
:

DEFINITION OF OPTION 2

```

JSR    PC,RETRY
ADD    #14,SP
CMP    R0,#5
BNE    66$
CMP    @ML.REG+44,30(SP)       ; *,OLDSEC
BNE    65$
MOV    32(SP),-(SP)           ; OLDCHN,*
MOV    @ML.REG+42,R0
ASR    R0
ASR    R0
ASR    R0
ASR    R0
ASR    R0
BIC    #177700,R0
CMP    R0,(SP)+
BNE    65$
BIT    #1,ERROUT
BEQ    64$
TRAP   56
.WORD  334
.WORD  MSG4
.WORD  0
MOV    R5,-(SP)
MOV    BOARD,-(SP)           ; LUN,*
JSR    PC,UP.HARD.COUNT
BR     68$
BIT    #1,ERROUT
BEQ    67$
TRAP   57
.WORD  335
.WORD  MSG3
.WORD  0
BR     67$
BIT    #1,ERROUT
BEQ    67$
TRAP   57
.WORD  336
.WORD  MSG3
.WORD  0
MOV    R5,-(SP)
MOV    BOARD,-(SP)           ; LUN,*
JSR    PC,UP.SOFT.COUNT
CMP    (SP)+,(SP)+
INC    R1
CMP    R1,26(SP)
BHI    71$
JMP    62$
INC    R5
CMP    R5,34(SP)
BGE    73$
JMP    36$

```

5500

5504

5509

5512

5500

5517

5522

5525

5531

5536

5539

5470

5466

5299

9496
9497
9498
9499 060020 062706 000010
9500 060024 005266 000030
9501 060030 026666 000030 000032
9502 060036 003002
9503 060040 000167 174110
9504 060044 062706 000036
9505 060050 000207
9506
9507
9508
9513
9514

:MLX4
:

DEFINITION OF OPTION 2

73\$: ADD #10,SP
74\$: INC 30(SP) :
CMP 30(SP),32(SP) : COUNT
BGT 75\$: COUNT,*
JMP 3\$:
75\$: ADD #36,SP
RTS PC :

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

5052
5051

4982

: Routine Size: 1023 words
: Maximum stack depth per invocation: 43 words

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (39)

9516 :MLX4
 9517 :
 9518 :
 9519 :
 9520 :
 9521 :
 9522 :
 9523 :
 9524 :
 9525 :
 9526 :
 9527 :
 9528 :
 9529 :
 9530 :
 9531 :
 9532 :
 9533 :
 9534 :
 9535 :
 9536 :
 9537 :
 9538 :
 9539 :
 9540 :
 9541 :
 9542 :
 9543 :
 9544 :
 9545 :
 9546 :
 9547 :
 9548 :
 9549 :
 9550 :
 9551 :
 9552 :
 9553 :
 9554 :
 9555 :
 9556 :
 9557 :
 9558 :
 9559 :
 9560 :
 9561 :
 9562 :
 9563 :
 9564 :
 9565 :
 9566 :
 9567 :
 9568 :
 9569 :
 9570 :

DEFINITION OF OPTION 3

5555 %sbttl 'DEFINITION OF OPTION 3'
 5556 routine OPT3 : novalue =
 5557 begin

!* 1 * START OF ROUTINE

++

ROUTINE: OPT3
 PURPOSE: TO DO A UNIQUE DATA CHECK ON ALL AVAILABLE UNITS.
 THE CODE FOR 'OPT3' IN BRIEF:

```

BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COMPLEMENT FLAG FROM 0 TO 1
: BEGIN 2 (START OF COMPLEMENT FLAG SELECTION LOOP)
: GENERATE THE PATTERN
: INCR LUN FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : INITIALIZE THE WRITE AND READ BUFFER POINTERS
: : : : SECTOR = LOWEST
: : : : WHILE SECTOR LEQ HIGHEST DO
: : : : : BEGIN 6 (START OF SECTOR SELECTION LOOP)
: : : : : GET WRDCNT
: : : : : SET-UP BUFFER POINTERS BEFORE TRANSFER
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : UPDATE SECTOR NUMBER BY NUMBER OF SECTORS IN PREVIOUS TRANSFER
: : : : : END 6 (END OF SECTOR SELECTION LOOP)
: : : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : : : END 4 (END OF TESTLOOP)
: : : : : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
: : : : : END 2 (END OF COMPLEMENT FLAG SELECTION LOOP)
RETURN
END 1 (END OF ROUTINE)
    
```

Label
 LOOP;

Local
 WRDCNT,
 VALUE,
 OLDSEC,

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (39)

```

9572 :MLX4
9573 :
9574 :
9575 :      5607      OLDCHN,
9576 :      5608      SECTOR,
9577 :      5609      PTR,
9578 :      5610      COMMAND,
9579 :      5611      DBL_VALUE;
9580 :
9581 :      5613      PRINTB (SAY2, WRD34, RTN3);
9582 :      5614      !'RUNNING OPT3'
9583 :
9584 :      5616      incr COMP_FLAG from 0 to 1 do
9585 :      5617      begin
9586 :      5618      GEN3 (.COMP_FLAG);
9587 :
9588 :      5619      incr LUN from 0 to (.LSUNIT - 1) do
9589 :      5620      begin
9590 : LOOP :      5622      begin
9591 :      5623      begin
9592 :      5624      if .DRIVE_STATUS [.LUN] eql ACTIVE
9593 :      5625      then
9594 :      5626      begin
9595 :      5627      !* 5 * START OF TEST FOR AN ACTIVE UNIT
9596 :      5628      L$LUN = .LUN;
9597 :      5629      WPTR = WBUFF;
9598 :      5630      RPTR = RBUFF;
9599 :      5631      SECTOR = LOWEST;
9600 :
9601 :      5632      while .SECTOR lequ HIGHEST do
9602 :      5633      begin
9603 :      5634      !* 6 * START OF SECTOR SELECTION LOOP
9604 :      5635      WRDCNT = GET WRDCNT (.SECTOR, HIGHEST);
9605 :      5636      SET PTRS (.WRDCNT);
9606 :      5637      VALUE = write (.LUN, .WRDCNT, .WPTR, .SECTOR);
9607 :      5638
9608 :      5639      !+
9609 :      5640      ! SEE HOW SUCCESSFUL THE WRITE WAS:
9610 :      5641      !-
9611 :
9612 :      5642      selectone .VALUE of
9613 :      5643      set
9614 :      5644      !SEE 'SYSERR' FOR DEFINITION
9615 :      5645      !OF ERROR # CONTAINED IN 'VALUE'
9616 :
9617 :      5646      [1] :
9618 :      5647      begin
9619 :      5648      !* 6A * RETRY ALLOWED
9620 :      5649      if RETRY (SIX, write, .LUN, .WRDCNT, .WPTR, .SECTOR) neq 0
9621 :      5650      then
9622 :      5651      !THE RETRY FAILED -- SYSTEM FATAL ERROR
9623 :      5652      begin
9624 :      5653      WHY_DROPT [.LUN] = CODE_4;
9625 :      5654      ERRDF (301, MSG1, 0); -!**** OPTION 3 ERROR 01 ****
9626 :      5655      DODU (.LUN);
9627 :      5656      leave LOOP;
9628 :      5657      !JUMP JUST BEYOND END OF BLOCK * 4 *
9629 :      5658      end;
9630 :
9631 :      5659      end;
9632 :
9633 :      5660      !* 6A *
    
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (39)

9628 :MLX4
9629 :
9630 :
9631 : 5659
9632 : 5660
9633 : 5661
9634 : 5662
9635 : 5663
9636 : 5664
9637 : 5665
9638 : 5666
9639 : 5667
9640 : 5668
9641 : 5669
9642 : 5670
9643 : 5671
9644 : 5672
9645 : 5673
9646 : 5674
9647 : 5675
9648 : 5676
9649 : 5677
9650 : 5678
9651 : 5679
9652 : 5680
9653 : 5681
9654 : 5682
9655 : 5683
9656 : 5684
9657 : 5685
9658 : 5686
9659 : 5687
9660 : 5688
9661 : 5689
9662 : 5690
9663 : 5691
9664 : 5692
9665 : 5693
9666 : 5694
9667 : 5695
9668 : 5696
9669 : 5697
9670 : 5698
9671 : 5699
9672 : 5700
9673 : 5701
9674 : 5702
9675 : 5703
9676 : 5704
9677 : 5705
9678 : 5706
9679 : 5707
9680 : 5708
9681 : 5709
9682 : 5710

DEFINITION OF OPTION 3

```
[2] :
begin
WHY DROPT [.LUN] = CODE_5;          !* 6B * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
ERRDF (302, MSG1, 0);              !**** OPTION 3 ERROR 02 ****
DODU (.LUN);
leave LOOP;                          !JUMP JUST BEYOND END OF BLOCK * 4 *
end;                                  !* 6B *
```

```
[3] :
begin
ERRDF (303, MSG1, 0);              !* 6C * FATAL DRIVE ERROR -- NO RETRY ALLOWED
WHY DROPT [.LUN] = CODE_6;          !**** OPTION 3 ERROR 03 ****
DODU (.LUN);
leave LOOP;                          !JUMP JUST BEYOND END OF BLOCK * 4 *
end;                                  !* 6C *
```

```
tes;
COMMAND = CHOOSE ();
if .COMMAND eql read
then
begin
PTR = .RPTR;
VALUE = read (.LUN, .WRDCNT, .RPTR, .SECTOR);
end
else
begin
PTR = .WPTR;
VALUE = CHECK (.LUN, .WRDCNT, .WPTR, .SECTOR);
end;

!+
!- SEE HOW SUCCESSFUL THE OPERATION WAS:
!-

selectone .VALUE of
set                                  !SEE 'SYSERR' FOR DEFINITION
                                       !OF ERROR # CONTAINED IN 'VALUE'
```

```
[0] :
if .COMMAND eql read
then
begin
if (DBL_VALUE = DOUBLE_CHECK (.WPTR, .RPTR, .WRDCNT)) neq 0
then
begin
SAYWHO (.LUN);
PRINTB (SAY1, MSG5);                !'ECC LOGIC FAILED TO DETECT DATA ERROR'
PRINTB (FMT12A, ..DBL_VALUE, .DBL_VALUE);
                                       !'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
```

9684 :MLX4
 9685 :
 9686 :
 9687 :
 9688 :
 9689 :
 9690 :
 9691 :
 9692 :
 9693 :
 9694 :
 9695 :
 9696 :
 9697 :
 9698 :
 9699 :
 9700 :
 9701 :
 9702 :
 9703 :
 9704 :
 9705 :
 9706 :
 9707 :
 9708 :
 9709 :
 9710 :
 9711 :
 9712 :
 9713 :
 9714 :
 9715 :
 9716 :
 9717 :
 9718 :
 9719 :
 9720 :
 9721 :
 9722 :
 9723 :
 9724 :
 9725 :
 9726 :
 9727 :
 9728 :
 9729 :
 9730 :
 9731 :
 9732 :
 9733 :
 9734 :
 9735 :
 9736 :
 9737 :
 9738 :

DEFINITION OF OPTION 3

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (39)

```

        DBL VALUE = .DBL_VALUE + BUFSIZ*2;
        PRINTB (FMT12B, .DBL_VALUE, .DBL_VALUE);
        !'BAD DATA: P P P P P AT LOCATION Q Q Q Q Q Q'
        WHY DROPT [.LUN] = CODE_8;
        ERRDF (304, MSG1, 0);          !**** OPTION 3 ERROR 04 ****
        DODU (.LUN);
        Leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
    end;

    end;

[1] :
    begin
        !* 6D * RETRY ALLOWED
    if RETRY (SIX, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) neq 0
    then
        !THE RETRY FAILED -- SYSTEM FATAL ERROR
        begin
            WHY DROPT [.LUN] = CODE_4;
            ERRDF (305, MSG1, 0);    !**** OPTION 3 ERROR 05 ****
            DODU (.LUN);
            leave LOOP;             !JUMP JUST BEYOND END OF BLOCK * 4 *
        end;
    end;
    !* 6D *

[2] :
    begin
        !* 6E * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
        WHY DROPT [.LUN] = CODE_5;
        ERRDF (306, MSG1, 0);      !**** OPTION 3 ERROR 06 ****
        DODU (.LUN);
        leave LOOP;               !JUMP JUST BEYOND END OF BLOCK * 4 *
    end;
    !* 6E *

[3] :
    begin
        !* 6F * FATAL DRIVE ERROR -- NO RETRY ALLOWED
        ERRDF (307, MSG1, 0);      !**** OPTION 3 ERROR 07 ****
        WHY DROPT [.LUN] = CODE_6;
        DODU (.LUN);
        leave LOOP;               !JUMP JUST BEYOND END OF BLOCK * 4 *
    end;
    !* 6F *

[4] :
    begin
        !* 6G * UNRECOVERABLE DATA ERROR
        ISOLATE ();
        ERRDF (308, MSG2, 0);      !**** OPTION 3 ERROR 08 ****
        WHY DROPT [.LUN] = CODE_7;
        DODU (.LUN);
        leave LOOP;               !JUMP JUST BEYOND END OF BLOCK * 4 *
    end;
    !* 6G *

[5] :
    begin
        !* 6H * RECOVERABLE DATA ERROR
    
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (39)

9740 :MLX4
9741 :
9742 :
9743 :
9744 :
9745 :
9746 :
9747 :
9748 :
9749 :
9750 :
9751 :
9752 :
9753 :
9754 :
9755 :
9756 :
9757 :
9758 :
9759 :
9760 :
9761 :
9762 :
9763 :
9764 :
9765 :
9766 :
9767 :
9768 :
9769 :
9770 :
9771 :
9772 :
9773 :
9774 :
9775 :
9776 :
9777 :
9778 :
9779 :
9780 :
9781 :
9782 :
9783 :
9784 :
9785 :
9786 :
9787 :
9788 :
9789 :
9790 :
9791 :
9792 :
9793 :
9794 :

DEFINITION OF OPTION 3

```
ISOLATE ();  
if .ERROUT then PRINTB (FMT10B, .CHAN);  
!' BIT qq'  
OLDSEC = .MLEL;  
OLDCHN = .CHAN;  
if RETRY (ONE, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) eql 5  
then  
    if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))  
    then  
        begin  
            if .ERROUT then ERRHRD (309, MSG4, 0); !**** OPTION 3 ERROR 09 ****  
            UP_HARD_COUNT (.LUN, .BOARD);  
        end  
    else  
        begin  
            if .ERROUT then ERRSOFT (310, MSG3, 0); !**** OPTION 3 ERROR 10 ****  
            UP_SOFT_COUNT (.LUN, .BOARD);  
        end  
    else  
        begin  
            if .ERROUT then ERRSOFT (311, MSG3, 0); !**** OPTION 3 ERROR 11 ****  
            UP_SOFT_COUNT (.LUN, .BOARD);  
        end  
    end;  
    tes; !* 6H *  
    WPTR = .WPTR + (.WRDCNT*2);  
    SECTOR = .SECTOR + (.WRDCNT/256);  
    end; !* 6 * END OF SECTOR SELECTION LOOP  
end; !* 5 * END OF TEST FOR AN ACTIVE UNIT  
+  
Test to see if this uut's address space is  
to be read for soft errors. This test is  
is intended for DMT purposes.  
-  
if .EFNS21  
then !Is the background pattern to be read
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (39)

```

9796 :MLX4
9797 :
9798 :
9799 : 5815
9800 : 5816
9801 : 5817
9802 : 5818
9803 : 5819
9804 : 5820
9805 : 5821
9806 : 5822
9807 : 5823
9808 : 5824
9809 : 5825
9810 : 5826
9811 : 5827
9812 : 5828
9813 : 5829
9814 : 5830
9815 : 5831
9816 : 5832
9817 : 5833
9818 : 5834
9819 : 5835
9820 : 5836
9821 : 5837
9822 : 5838
9823 : 5839
9824 : 5840
9825 : 5841
9826 : 5842
9827 : 5843
9828 : 5844
9829 : 5845
9830 : 5846
9831 : 5847
9832 : 5848
9833 : 5849
9834 : 5850
9835 : 5851
9836 : 5852
9837 : 5853
9838 : 5854
9839 : 5855
9840 : 5856
9841 : 5857
9842 : 5858
9843 : 5859
9844 : 5860
9845 : P 5861
9846 : P 5862
9847 : 5863
9848 : 5864
9849 : 5865
9850 : 5866

DEFINITION OF OPTION 3
begin
:
: version czmlbb changed incr to incru
:
incru SECTOR from LOWEST to HIGHEST do
    if read (.LUN, 256, RBUFF, .SECTOR) eql 5
    then
        begin
            ISOLATE ();          !Find the failing bank and board no.
            if .ERROUT then PRINTB (FMT10B, .CHAN);
            ! Print where the error is
            ! Save the contents of the ML error location
            ! register so we can compare it to the new
            ! contents of this register after the retry.
            ! This is done to classify the error.
            OLDSEC = .MLEL;
            OLDCHN = .CHAN;
            ! Do a classify retry call. If the same error
            ! occurs then classify it as a hard error. If
            ! a different error occurred or the error went away
            ! then classify it as a soft error.
            if RETRY (ONE, .COMMAND, .LUN, 256, .PTR, .OLDSEC) eql 5
            then
                ! The same error occurred so see if it is at the same
                ! sector and channel number, if so then classify
                ! it as a hard error else classiy it as a soft
                ! error.
                if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
                then
                    begin
                        !Same error occurred 'hard'
                        if .ERROUT          !Print error if enabled
                        then
                            begin
                                ERRHRD (312,          !Error number
                                MSG4,          !Error message
                                0);          !Additional message routine
                            end;
                        UP_HARD_COUNT (.LUN, .BOARD);
                    end;
                end;
            end;
        end;
    end;
end;

```


27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (39)

```

9852 :MLX4
9853 :
9854 :
9855 : 5867
9856 : 5868
9857 : 5869
9858 : 5870
9859 : 5871
9860 : 5872
9861 : 5873
9862 : P 5874
9863 : P 5875
9864 : 5876
9865 : 5877
9866 : 5878
9867 : 5879
9868 : 5880
9869 : 5881
9870 : 5882
9871 : 5883
9872 : 5884
9873 : 5885
9874 : 5886
9875 : 5887
9876 : P 5888
9877 : P 5889
9878 : 5890
9879 : 5891
9880 : 5892
9881 : 5893
9882 : 5894
9883 : 5895
9884 : 5896
9885 : 5897
9886 : 5898
9887 : 5899
9888 : 5900
9889 : 5901
9890 : 5902
9891 : 5903
9892 : 5904
9893 : 5905
9894 : 5906
9898 :
9899 :
9903 060052 004167 125256
9904 060056 162706 000020
9905 060062 012746 007642
9906 060066 012746 007344
    
```

```

DEFINITION OF OPTION 3

    end
  else
    begin
      !Not the same error 'soft'
      if .ERROUT
      then
        !Print error if enabled
        begin
          ERRSOFT (313,
            MSG3,
            0);
          !Error number
          !Error message
          !Additional message routine
        end;
        UP_SOFT_COUNT (.LUN, .BOARD);
      end
    else
      !Not the same error 'soft'
      begin
        if .ERROUT
        then
          !Print error if enabled
          begin
            ERRSOFT (314,
              MSG3,
              0);
            !Error number
            !Error message
            !Additional message routine
          end;
          UP_SOFT_COUNT (.LUN, .BOARD);
        end;
      end;
    end;
  end;
end;
end;
end;
end;
return;
end;
! * 4 * END OF TESTLOOP
! * 3 * END OF LOGICAL UNIT SELECTION LOOP
! * 2 * END OF COMPLEMENT FLAG SELECTION LOOP
! * 1 * END OF ROUTINE
    
```

```

.SBTTL OPT3 DEFINITION OF OPTION 3
OPT3: JSR R1,$SAVE5
SUB #20,SP
MOV #RTN3,-(SP)
MOV #WRD34,-(SP)
    
```

5556
 5613

Address	OpCode	Op1	Op2	Op3	Label	Instruction	Comments	Address
9908								
9909					:MLX4			
9910						DEFINITION OF OPTION 3		
9911	060072	012746	007100			MOV #SAY2,-(SP)		
9912	060076	012746	000003			MOV #3,-(SP)		
9913	060102	010600				MOV SP,R0	: SP,*	
9914	060104	104414				TRAP 14		
9915	060106	005066	000026			CLR 26(SP)	: COMP.FLAG	5616
9916	060112	016646	000026		1\$:	MOV 26(SP),-(SP)	: COMP.FLAG,*	5618
9917	060116	004767	161344			JSR PC,GEN\$		
9918	060122	016766	121664	000014		MOV L\$UNIT,14(SP)		
9919	060130	005066	000012			CLR 12(SP)	: LUN	5620
9920	060134	000167	002240			JMP 41\$		
9921	060140	016600	000012		2\$:	MOV 12(SP),R0	: LUN,*	5625
9922	060144	006200				ASR R0		
9923	060146	006200				ASR R0		
9924	060150	006200				ASR R0		
9925	060152	062700	034442			ADD #DRIVE.STATUS,R0		
9926	060156	010046				MOV R0,-(SP)		
9927	060160	016646	000014			MOV 14(SP),-(SP)	: LUN,*	
9928	060164	042716	177770			BIC #177770,(SP)		
9929	060170	012746	000001			MOV #1,-(SP)		
9930	060174	005046				CLR -(SP)		
9931	060176	004767	124154			JSR PC,BL\$GT2		
9932	060202	062706	000010			ADD #10,SP		
9933	060206	0C5300				DEC R0		
9934	060210	001402				BEQ 4\$		
9935	060212	000167	001502		3\$:	JMP 29\$		
9936	060216	016667	000012	121650	4\$:	MOV 12(SP),L\$LUN	: LUN,*	
9937	060224	012767	012670	152436		MOV #WBUF,WPTR		5628
9938	060232	012767	022670	152432		MOV #RBUF,RPTR		5629
9939	060240	016605	000012			MOV 12(SP),R5	: LUN,*	5630
9940	060244	006305				ASL R5		5631
9941	060246	016503	034460			MOV LOW.SECT(R5),R3	: *,SECTOR	
9942	060252	020365	034500		5\$:	CMP R3,TOP.SECT(R5)	: SECTOR,*	
9943	060256	101355				BHI 3\$		5633
9944	060260	010346				MOV R3,-(SP)	: SECTOR,*	
9945	060262	016546	034500			MOV TOP.SECT(R5),-(SP)		5635
9946	060266	004767	166704			JSR PC,GET.WRDCNT		
9947	060272	010002				MOV R0,R2	: *,WRDCNT	
9948	060274	010216				MOV R2,(SP)	: WRDCNT,*	
9949	060276	004767	166630			JSR PC,SET.PTRS		5636
9950	060302	016616	000016			MOV 16(SP), (SP)	: LUN,*	
9951	060306	010246				MOV R2,-(SP)	: WRDCNT,*	5637
9952	060310	016746	152354			MOV WPTR,-(SP)		
9953	060314	010346				MOV R3,-(SP)	: SECTOR,*	
9954	060316	004767	165102			JSR PC,WRITE		
9955	060322	010004				MOV R0,R4	: *,VALUE	
9956	060324	020427	000001			CMP R4,#1	: VALUE,*	5643
9957	060330	001035				BNE 6\$		
9958	060332	012746	000006			MOV #6,-(SP)		
9959	060336	012746	045424			MOV #WRITE,-(SP)		5649
9960	060342	016646	000030			MOV 30(SP),-(SP)	: LUN,*	
9961	060346	010246				MOV R2,-(SP)	: WRDCNT,*	
9962	060350	016746	152314			MOV WPTR,-(SP)		

Address	Hex	Hex	Hex	Label	Instruction	Comment	Page
9964							
9965				:MLX4			
9966				:			
9967	060354	010346			MOV R3,-(SP)		
9968	060356	004767	165642		JSR PC,RETRY	: SECTOR,*	
9969	060362	0627C6	000014		ADD #14,SP		
9970	060366	005700			TST R0		
9971	060370	001456			BEQ 9\$		
9972	060372	016601	000024		MOV 24(SP),R1	: LUN,*	
9973	060376	112761	000004	034446	MOVB #4,WHY.DROPT(R1)		5652
9974	060404	104455			TRAP 55	:	
9975	060406	000455			.WORD 455		5653
9976	060410	011070			.WORD MSG1		
9977	060412	000000			.WORD 0		
9978	060414	016600	000024		MOV 24(SP),R0	: LUN,*	
9979	060420	104451			TRAP 51		5654
9980	060422	000436			BR 8\$:	
9981	060424	020427	000002	6\$:	CMP R4,#2	: VALUE,*	5655
9982	060430	001015			BNE 7\$		5643
9983	060432	016601	000024		MOV 24(SP),R1	: LUN,*	
9984	060436	112761	000005	034446	MOVB #5,WHY.DROPT(R1)		5662
9985	060444	104455			TRAP 55	:	
9986	060446	000456			.WORD 456		5663
9987	060450	011070			.WORD MSG1		
9988	060452	000000			.WORD 0		
9989	060454	016600	000024		MOV 24(SP),R0	: LUN,*	
9990	060460	104451			TRAP 51		5664
9991	060462	000416			BR 8\$:	
9992	060464	020427	000003	7\$:	CMP R4,#3	: VALUE,*	5665
9993	060470	001016			BNE 9\$		5643
9994	060472	104455			TRAP 55	:	
9995	060474	000457			.WORD 457		5670
9996	060476	011070			.WORD MSG1		
9997	060500	000000			.WORD 0		
9998	060502	016601	000024		MOV 24(SP),R1	: LUN,*	
9999	060506	112761	000006	034446	MOVB #6,WHY.DROPT(R1)		5671
10000	060514	010100			MOV R1,R0	: LUN,*	
10001	060516	104451			TRAP 51		5672
10002	060520	062706	000012	8\$:	ADD #12,SP	:	
10003	060524	000543			BR 14\$		5673
10004	060526	004767	165434	9\$:	JSR PC,CHOOSE	:	
10005	060532	010066	000040		MOV R0,40(SP)	: *,COMMAND	5677
10006	060536	005001			CLR R1	:	
10007	060540	020027	045612		CMP R0,#READ	: COMMAND,*	5679
10008	060544	001015			BNE 10\$		
10009	060546	005201			INC R1		
10010	060550	016766	152116	000036	MOV RPTR,36(SP)	: *,PTR	5682
10011	060556	016646	000024		MOV 24(SP),-(SP)	: LUN,*	5683
10012	060562	010246			MOV R2,-(SP)	: WRDCNT,*	
10013	060564	016746	152102		MOV RPTR,-(SP)		
10014	060570	010346			MOV R3,-(SP)	: SECTOR,*	
10015	060572	004767	165014		JSR PC,READ		
10016	060576	000413			BR 11\$		
10017	060600	016766	152064	000036	MOV WPTR,36(SP)	: *,PTR	5687
10018	060606	016646	000024	10\$:	MOV 24(SP),-(SP)	: LUN,*	5688

Address	Hex	Hex	Hex	Label	Instruction	Comment	Value
10020							
10021				:MLX4			
10022				:		DEFINITION OF OPTION 3	
10023	060612	010246			MOV R2,-(SP)	: WRDCNT,*	
10024	060614	016746	152050		MOV WPTR,-(SP)	:	
10025	060620	010346			MOV R3,-(SP)	: SECTOR,*	
10026	060622	004767	165152		JSR PC,CHECK	:	
10027	060626	010004		11\$:	MOV R0,R4	: *,VALUE	
10028	060630	001102			BNE 15\$:	
10029	060632	006001			ROR R1	:	5695
10030	060634	103402			BLO 13\$:	5700
10031	060636	000167	001014		JMP 28\$:	
10032	060642	016746	152022	12\$:	MOV WPTR,-(SP)	:	
10033	060646	016746	152020	13\$:	MOV RPTR,-(SP)	:	5704
10034	060652	010246			MOV R2,-(SP)	: WRDCNT,*	
10035	060654	004767	163446		JSR PC,DOUBLE.CHECK	:	
10036	060660	062706	000006		ADD #6,SP	:	
10037	060664	010066	000042		MOV R0,42(SP)	: *,DBL.VALUE	
10038	060670	001762			BEQ 12\$:	
10039	060672	016646	000034		MOV 34(SP),-(SP)	: LUN,*	5707
10040	060676	004767	154622		JSR PC,SAYWHO	:	
10041	060702	012716	011216		MOV #MSG5,(SP)	:	5708
10042	060706	012746	007072		MOV #SAY1,-(SP)	:	
10043	060712	012746	000002		MOV #2,-(SP)	:	
10044	060716	010600			MOV SP,R0	: SP,*	
10045	060720	104414			TRAP 14	:	
10046	060722	016616	000050		MOV 50(SP),(SP)	: DBL.VALUE,*	
10047	060726	017646	000050		MOV @50(SP),-(SP)	: DBL.VALUE,*	5709
10048	060732	012746	006710		MOV #FMT12A,-(SP)	:	
10049	060736	012746	000003		MOV #3,-(SP)	:	
10050	060742	010600			MOV SP,R0	: SP,*	
10051	060744	104414			TRAP 14	:	
10052	060746	062766	010000	000056	ADD #10000,56(SP)	: *,DBL.VALUE	5711
10053	060754	016616	000056		MOV 56(SP),(SP)	: DBL.VALUE,*	5712
10054	060760	017646	000056		MOV @56(SP),-(SP)	: DBL.VALUE,*	
10055	060764	012746	006756		MOV #FMT12B,-(SP)	:	
10056	060770	012746	000003		MOV #3,-(SP)	:	
10057	060774	010600			MOV SP,R0	: SP,*	
10058	060776	104414			TRAP 14	:	
10059	061000	016601	000056		MOV 56(SP),R1	: LUN,*	5714
10060	061004	112761	000010	034446	MOV #10,WHY.DROPT(R1)	:	
10061	061012	104455			TRAP 55	:	5715
10062	061014	000460			.WORD 460	:	
10063	061016	011070			.WORD MSG1	:	
10064	061020	000000			.WORD 0	:	
10065	061022	016600	000056		MOV 56(SP),R0	: LUN,*	5716
10066	061026	104451			TRAP 51	:	
10067	061030	062706	000044		ADD #44,SP	:	
10068	061034	000521			BR 20\$:	5717
10069	061036	020427	000001		14\$: CMP R4,#1	: VALUE,*	5695
10070	061042	001035			15\$: BNE 16\$:	
10071	061044	012746	000006		MOV #6,-(SP)	:	
10072	061050	016646	000052		MOV 52(SP),-(SP)	: COMMAND,*	5725
10073	061054	016646	000040		MOV 40(SP),-(SP)	: LUN,*	
10074	061060	010246			MOV R2,-(SP)	: WRDCNT,*	

Address	Offset	Hex	OpCode	OpData	Comment	Seq
10076						
10077						
10078						
10079	061062	016646	000056			
10080	061066	010346				
10081	061070	004767	165130			
10082	061074	062706	000014			
10083	061100	005700				
10084	061102	001655				
10085	061104	016601	000034			
10086	061110	112761	000004	034446		5728
10087	061116	104455				
10088	061120	000461				5729
10089	061122	011070				
10090	061124	000000				
10091	061126	016600	000034			
10092	061132	104451				5730
10093	061134	000457				
10094	061136	020427	000002	16\$:		5731
10095	061142	001015				5695
10096	061144	016601	000034			
10097	061150	112761	000005	034446		5738
10098	061156	104455				
10099	061160	000462				5739
10100	061162	011070				
10101	061164	000000				
10102	061166	016600	000034			
10103	061172	104451				5740
10104	061174	000437				
10105	061176	020427	000003	17\$:		5741
10106	061202	001014				5695
10107	061204	104455				
10108	061206	000463				5746
10109	061210	011070				
10110	061212	000C30				
10111	061214	016601	000034			
10112	061220	112761	000006	034446		5747
10113	061226	010100				
10114	061230	104451				5748
10115	061232	000420				
10116	061234	020427	000004	18\$:		5749
10117	061240	001021				5695
10118	061242	004767	156064			
10119	061246	104455				5754
10120	061250	000464				5755
10121	061252	011120				
10122	061254	000000				
10123	061256	016601	000034			
10124	061262	112761	000007	034446		5756
10125	061270	010100				
10126	061272	104451				5757
10127	061274	062706	000022	19\$:		
10128	061300	000167	001070	20\$:		5758
10129	061304	020427	000005	21\$:		
10130	061310	001162				5695

10300									27-Mar-1982 19:24:42	TOPS
10301									27-Mar-1982 19:23:44	PA:<
10302										
10303	062254	104456								
10304	062256	000470								5863
10305	062260	011202								
10306	062262	000000								
10307	062264	016646	000012	33\$:						
10308	062270	016746	152046							5866
10309	062274	004767	155122							
10310	062300	000427								
10311	062302	032767	000001	117750	34\$:					5854
10312	062310	001415								5871
10313	062312	104457								
10314	062314	000471								5876
10315	062316	011166								
10316	062320	000000								
10317	062322	000410								
10318	062324	032767	000001	117726	35\$:					5879
10319	062332	001404								5885
10320	062334	104457								
10321	062336	000472								5890
10322	062340	011166								
10323	062342	000000								
10324	062344	016646	000012	36\$:						
10325	062350	016746	151766							5893
10326	062354	004767	155524							
10327	062360	022626								
10328	062362	005205								
10329	062364	020501								5824
10330	062366	101002								5820
10331	062370	000167	177362							
10332	062374	005266	000012							
10333	062400	026666	000012	000014	40\$:					
10334	062406	002002			41\$:					5620
10335	062410	000167	175524							
10336	062414	005726								
10337	062416	005266	000026		42\$:					
10338	062422	026627	000026	000001						5617
10339	062430	003002								5616
10340	062432	000167	175454							
10341	062436	062706	000030							
10342	062442	000207			43\$:					5556
10343										
10344										
10345										
10350										
10351										

: Routine Size: 637 words
 : Maximum stack depth per invocation: 37 words

10353 :MLX4
 10354 :
 10355 :
 10356 :
 10357 :
 10358 :
 10359 :
 10360 :
 10361 :
 10362 :
 10363 :
 10364 :
 10365 :
 10366 :
 10367 :
 10368 :
 10369 :
 10370 :
 10371 :
 10372 :
 10373 :
 10374 :
 10375 :
 10376 :
 10377 :
 10378 :
 10379 :
 10380 :
 10381 :
 10382 :
 10383 :
 10384 :
 10385 :
 10386 :
 10387 :
 10388 :
 10389 :
 10390 :
 10391 :
 10392 :
 10393 :
 10394 :
 10395 :
 10396 :
 10397 :
 10398 :
 10399 :
 10400 :
 10401 :
 10402 :
 10403 :
 10404 :
 10405 :
 10406 :
 10407 :

```

DEFINITION OF OPTION 4
%sbttl 'DEFINITION OF OPTION 4'
routine OPT4 : novalue =
begin
    ++
    ROUTINE:      OPT4
    PURPOSE:      TO LOOK FOR INTERACTIONS BETWEEN SECTORS
                  USING A MARCH TEST.

    THE CODE IN BRIEF:

    BEGIN 1 (START OF ROUTINE)
    SAY ROUTINE IS RUNNING
    WORD COUNT = 256
    GENERATE A BUFFER OF DATA
    GENERATE A BUFFER OF COMP
    INITIALIZE POINTERS TO 4 BUFFERS FOR WRITE/READ DATA/COMP
    INCR LUN FROM 0 TO LAST
    : BEGIN 2 (START OF LOGICAL UNIT SELECTION LOOP)
    : TESTLOOP:
    : : BEGIN 3 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
    : : IF UNIT IS ACTIVE
    : : THEN
    : : : BEGIN 4 (START OF TEST FOR AN ACTIVE UNIT)
    : : : INCR SECTOR FROM LOWEST TO HIGHEST
    : : : : BEGIN 4A (START OF 1ST SECTOR SELECTION LOOP)
    : : : : WRITE 'DATA'
    : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
    : : : : END 4A (END OF 1ST SECTOR SELECTION LOOP)
    : : : : CHOOSE WHETHER TO WRITE CHECK OR READ 'DATA'
    : : : : INCR SECTOR FROM LOWEST TO HIGHEST
    : : : : BEGIN 4B (START OF 2ND SECTOR SELECTION LOOP)
    : : : : DO THE WRITE CHECK OR READ OF 'DATA'
    : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
    : : : : WRITE 'COMP'
    : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
    : : : : END 4B (END OF 2ND SECTOR SELECTION LOOP)
    : : : : CHOOSE WHETHER TO WRITE CHECK OR READ 'COMP'
    : : : : DECR SECTOR FROM HIGHEST TO LOWEST
    : : : : BEGIN 4C (START OF 3RD SECTOR SELECTION LOOP)
    : : : : DO THE WRITE CHECK OR READ OF 'COMP'
    : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
    : : : : WRITE DATA
    : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
    : : : : END 4C (END OF 3RD SECTOR SELECTION LOOP)
    : : : : CHOOSE WHETHER TO WRITE CHECK OR READ 'DATA'
    : : : : INCR SECTOR FROM LOWEST TO HIGHEST
    : : : : BEGIN 4D (START OF 4TH SECTOR SELECTION LOOP)
    : : : : DO THE WRITE CHECK OR READ OF 'DATA'
    : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
    : : : : END 4D (END OF 4TH SECTOR SELECTION LOOP)
    
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (40)

!* 1 * START OF ROUTINE

10521 :MLX4
 10522 :
 10523 :
 10524 :
 10525 :
 10526 :
 10527 :
 10528 :
 10529 :
 10530 :
 10531 :
 10532 :
 10533 :
 10534 :
 10535 :
 10536 :
 10537 :
 10538 :
 10539 :
 10540 :
 10541 :
 10542 :
 10543 :
 10544 :
 10545 :
 10546 :
 10547 :
 10548 :
 10549 :
 10550 :
 10551 :
 10552 :
 10553 :
 10554 :
 10555 :
 10556 :
 10557 :
 10558 :
 10559 :
 10560 :
 10561 :
 10562 :
 10563 :
 10564 :
 10565 :
 10566 :
 10567 :
 10568 :
 10569 :
 10570 :
 10571 :
 10572 :
 10573 :
 10574 :
 10575 :

DEFINITION OF OPTION 4

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (40)

```

begin
PTR = .RDPTR;
VALUE = read (.LUN, 256, .PTR, .SECTOR);
end
else
begin
PTR = .WDPTR;
VALUE = CHECK (.LUN, 256, .PTR, .SECTOR);
end;

!+
!- SEE HOW SUCCESSFUL THE OPERATION WAS:

selectone .VALUE of
set
[0] :
    if .COMMAND eql read
    then
        begin
            if (DBL_VALUE = DOUBLE_CHECK (.WDPTR, .RDPTR, 256)) neq 0
            then
                begin
                    SAYWHO (.LUN);
                    PRINTB (SAY1, MSG5);
                    !'ECC LOGIC FAILED TO DETECT DATA ERROR'
                    PRINTB (FMT12A, ..DBL_VALUE, .DBL_VALUE);
                    !'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
                    DBL_VALUE = .DBL_VALUE + BUFSIZ*2;
                    PRINTB (FMT12B, ..DBL_VALUE, .DBL_VALUE);
                    !'BAD DATA: PPPPPP AT LOCATION QQQQQQ'
                    WHY DROPT [.LUN] = CODE_8;
                    ERRDF (404, MSG1, 0); !**** OPTION 4 ERROR 04 ****
                    DODU (.LUN);
                    leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
                end;
            end;
        end;
    [1] :
        begin
            !* 4B1 * RETRY ALLOWED
            if RETRY (SIX, .COMMAND, .LUN, 256, .PTR, .SECTOR) neq 0
            then
                !THE RETRY FAILED -- SYSTEM FATAL ERROR
                begin
                    WHY DROPT [.LUN] = CODE_4;
                    ERRDF (405, MSG1, 0); !**** OPTION 4 ERROR 05 ****
                    DODU (.LUN);
                    leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 3 *
                end;
            end;
        end;
    end;

```


27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (40)

10689 :MLX4
 10690 :
 10691 :
 10692 :
 10693 :
 10694 :
 10695 :
 10696 :
 10697 :
 10698 :
 10699 :
 10700 :
 10701 :
 10702 :
 10703 :
 10704 :
 10705 :
 10706 :
 10707 :
 10708 :
 10709 :
 10710 :
 10711 :
 10712 :
 10713 :
 10714 :
 10715 :
 10716 :
 10717 :
 10718 :
 10719 :
 10720 :
 10721 :
 10722 :
 10723 :
 10724 :
 10725 :
 10726 :
 10727 :
 10728 :
 10729 :
 10730 :
 10731 :
 10732 :
 10733 :
 10734 :
 10735 :
 10736 :
 10737 :
 10738 :
 10739 :
 10740 :
 10741 :
 10742 :
 10743 :

DEFINITION OF OPTION 4

```

        DODU (.LUN);
        leave LOOP;
    end;
tes;
end;
PRINTB (FMT2, WRD25);
!' DOWN'
COMMAND = CHOOSE ();
decr SECTOR from HIGHEST to LOWEST do
begin
!* 4C * START OF 3RD SECTOR SELECTION LOOP
    if .COMMAND eql read
    then
        begin
            PTR = .RCPTR;
            VALUE = read (.LUN, 256, .PTR, .SECTOR);
        end
    else
        begin
            PTR = .WCPTR;
            VALUE = CHECK (.LUN, 256, .PTR, .SECTOR);
        end;
    !+
    !- SEE HOW SUCCESSFUL THE OPERATION WAS:
    selectone .VALUE of
        set
        [0] :
            if .COMMAND eql read
            then
                begin
                    if (DBL_VALUE = DOUBLE_CHECK (.WCPTR, .RCPTR, 256)) neq 0
                    then
                        begin
                            SAYWHO (.LUN);
                            PRINTB (SAY1, MSG5);
                            !'ECC LOGIC FAILED TO DETECT DATA ERROR'
                            PRINTB (FMT12A, ..DBL_VALUE, .DBL_VALUE);
                            !'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
                            DBL_VALUE = .DBL_VALUE + BUFSIZ*2;
                            PRINTB (FMT12B, ..DBL_VALUE, .DBL_VALUE);
                            !'BAD DATA: PPPPPP AT LOCATION QQQQQQ'
                            WHY DROPT [.LUN] = CODE_8;
                            ERRDF (415, MSG1, 0); !**** OPTION 4 ERROR 15 ****
                        end
                    end
                end
            end
        end
    !* 4B * END OF 2ND SECTOR SELECTION LOOP
    !* 48 *
!* JUMP JUST BEYOND END OF BLOCK * 3 *
!* 4B8 *

```


10745 :MLX4
 10746 :
 10747 :
 10748 :
 10749 :
 10750 :
 10751 :
 10752 :
 10753 :
 10754 :
 10755 :
 10756 :
 10757 :
 10758 :
 10759 :
 10760 :
 10761 :
 10762 :
 10763 :
 10764 :
 10765 :
 10766 :
 10767 :
 10768 :
 10769 :
 10770 :
 10771 :
 10772 :
 10773 :
 10774 :
 10775 :
 10776 :
 10777 :
 10778 :
 10779 :
 10780 :
 10781 :
 10782 :
 10783 :
 10784 :
 10785 :
 10786 :
 10787 :
 10788 :
 10789 :
 10790 :
 10791 :
 10792 :
 10793 :
 10794 :
 10795 :
 10796 :
 10797 :
 10798 :
 10799 :

DEFINITION OF OPTION 4

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (40)

```

DODU (.LUN);
leave LOOP;
end;
!JUMP JUST BEYOND END OF BLOCK * 4 *

end;

[1] :
begin
! * 4C1 *          RETRY ALLOWED
if RETRY (SIX, .COMMAND, .LUN, 256, .PTR, .SECTOR) neq 0
then
!THE RETRY FAILED -- SYSTEM FATAL ERROR
begin
WHY DROPT [.LUN] = CODE_4;
ERRDF (416, MSG1, 0);
DODU (.LUN);
leave LOOP;
end;
!JUMP JUST BEYOND END OF BLOCK * 3 *
end;
! * 4C1 *

[2] :
begin
WHY DROPT [.LUN] = CODE_5;
ERRDF (417, MSG1, 0);
DODU (.LUN);
leave LOOP;
end;
! * 4C2 *          FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
! * * * * OPTION 4 ERROR 17 * * * *
!JUMP JUST BEYOND END OF BLOCK * 3 *
! * 4C2 *

[3] :
begin
ERRDF (418, MSG1, 0);
WHY DROPT [.LUN] = CODE_6;
DODU (.LUN);
leave LOOP;
end;
! * 4C3 *          FATAL DRIVE ERROR -- NO RETRY ALLOWED
! * * * * OPTION 4 ERROR 18 * * * *
!JUMP JUST BEYOND END OF BLOCK * 3 *
! * 4C3 *

[4] :
begin
ISOLATE ();
ERRDF (419, MSG2, 0);
WHY DROPT [.LUN] = CODE_7;
DODU (.LUN);
leave LOOP;
end;
! * 4C4 *          UNRECOVERABLE DATA ERROR
! * * * * OPTION 4 ERROR 19 * * * *
!JUMP JUST BEYOND END OF BLOCK * 3 *
! * 4C4 *

[5] :
begin
ISOLATE ();
if .ERROUT then PRINTB (FMT10B, .CHAN);
! * 4C5 *          RECOVERABLE DATA ERROR
! * BIT 00'
    
```

```

10801 :MLX4
10802 :
10803 :
10804 : 6323
10805 : 6324
10806 : 6325
10807 : 6326
10808 : 6327
10809 : 6328
10810 : 6329
10811 : 6330
10812 : 6331
10813 : 6332
10814 : 6333
10815 : 6334
10816 : 6335
10817 : 6336
10818 : 6337
10819 : 6338
10820 : 6339
10821 : 6340
10822 : 6341
10823 : 6342
10824 : 6343
10825 : 6344
10826 : 6345
10827 : 6346
10828 : 6347
10829 : 6348
10830 : 6349
10831 : 6350
10832 : 6351
10833 : 6352
10834 : 6353
10835 : 6354
10836 : 6355
10837 : 6356
10838 : 6357
10839 : 6358
10840 : 6359
10841 : 6360
10842 : 6361
10843 : 6362
10844 : 6363
10845 : 6364
10846 : 6365
10847 : 6366
10848 : 6367
10849 : 6368
10850 : 6369
10851 : 6370
10852 : 6371
10853 : 6372
10854 : 6373
10855 : 6374

DEFINITION OF OPTION 4

OLDSEC = .MLEL;
OLDCHN = .CHAN;

if RETRY (ONE, .COMMAND, .LUN, 256, .PTR, .SECTOR) eq 5
then
    if ((.MLEL eq .OLDSEC) and (.CHAN eq .OLDCHN))
    then
        begin
            if .ERROUT then ERRHRD (420, MSG4, 0); !**** OPTION 4 ERROR 20 ****
            UP_HARD_COUNT (.LUN, .BOARD);
        end
    else
        begin
            if .ERROUT then ERRSOFT (421, MSG3, 0); !**** OPTION 4 ERROR 21 ****
            UP_SOFT_COUNT (.LUN, .BOARD);
        end
    else
        begin
            if .ERROUT then ERRSOFT (422, MSG3, 0); !**** OPTION 4 ERROR 22 ****
            UP_SOFT_COUNT (.LUN, .BOARD);
        end;
    end;
tes; !* 4C5 *

VALUE = write (.LUN, 256, .WDPTR, .SECTOR);
!+
! SEE HOW SUCCESSFUL THE WRITE WAS:
!-

selectone .VALUE of !SEE 'SYSERR' FOR DEFINITION
set !OF ERROR # CONTAINED IN 'VALUE'

[1] :
begin !* 4C6 * RETRY ALLOWED
if RETRY (SIX, write, .LUN, 256, .WDPTR, .SECTOR) neg 0
then !THE RETRY FAILED -- SYSTEM FATAL ERROR
begin
WHY DROPT [.LUN] = CODE_4;
ERRDF (423, MSG1, 0); !**** OPTION 4 ERROR 23 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 3 *

```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (40)

10857 :MLX4
 10858 :
 10859 :
 10860 :
 10861 :
 10862 :
 10863 :
 10864 :
 10865 :
 10866 :
 10867 :
 10868 :
 10869 :
 10870 :
 10871 :
 10872 :
 10873 :
 10874 :
 10875 :
 10876 :
 10877 :
 10878 :
 10879 :
 10880 :
 10881 :
 10882 :
 10883 :
 10884 :
 10885 :
 10886 :
 10887 :
 10888 :
 10889 :
 10890 :
 10891 :
 10892 :
 10893 :
 10894 :
 10895 :
 10896 :
 10897 :
 10898 :
 10899 :
 10900 :
 10901 :
 10902 :
 10903 :
 10904 :
 10905 :
 10906 :
 10907 :
 10908 :
 10909 :
 10910 :
 10911 :

DEFINITION OF OPTION 4

```

        end;
    end;
    end;
    [2] :
        begin
            WHY DROPT [.LUN] = CODE_5;
            ERRDF (424, MSG1, 0);
            DODU (.LUN);
            leave LOOP;
        end;
    [3] :
        begin
            ERRDF (425, MSG1, 0);
            WHY DROPT [.LUN] = CODE_6;
            DODU (.LUN);
            leave LOOP;
        end;
    tes;
end;
PRINTB (FMT2, WRD24);
UP;
COMMAND = CHOOSE ();
:
: version czmlbb changed incr to incru
:
    incru SECTOR from LOWEST to HIGHEST do
        begin
            if .COMMAND eql read
            then
                begin
                    PTR = .RDPTR;
                    VALUE = read (.LUN, 256, .PTR, .SECTOR);
                end
            else
                begin
                    PTR = .WDPTR;
                    VALUE = CHECK (.LUN, 256, .PTR, .SECTOR);
                end;
        end;
    !+
    !- SEE HOW SUCCESSFUL THE OPERATION WAS:
    !-
selectone .VALUE of
set

```

!* 4C6 *
 !* 4C7 * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
 !**** OPTION 4 ERROR 24 ****
 !JUMP JUST BEYOND END OF BLOCK * 3 *
 !* 4C7 *
 !* 4C8 * FATAL DRIVE ERROR -- NO RETRY ALLOWED
 !**** OPTION 4 ERROR 25 ****
 !JUMP JUST BEYOND END OF BLOCK * 3 *
 !* 4C8 *
 !* 4C * END OF 3RD SECTOR SELECTION LOOP
 !* 4D * START OF 4TH SECTOR SELECTION LOOP
 !SEE 'SYSERR' FOR DEFINITION
 !OF ERROR # CONTAINED IN 'VALUE'

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (40)

10913 :MLX4
 10914 :
 10915 :
 10916 :
 10917 :
 10918 :
 10919 :
 10920 :
 10921 :
 10922 :
 10923 :
 10924 :
 10925 :
 10926 :
 10927 :
 10928 :
 10929 :
 10930 :
 10931 :
 10932 :
 10933 :
 10934 :
 10935 :
 10936 :
 10937 :
 10938 :
 10939 :
 10940 :
 10941 :
 10942 :
 10943 :
 10944 :
 10945 :
 10946 :
 10947 :
 10948 :
 10949 :
 10950 :
 10951 :
 10952 :
 10953 :
 10954 :
 10955 :
 10956 :
 10957 :
 10958 :
 10959 :
 10960 :
 10961 :
 10962 :
 10963 :
 10964 :
 10965 :
 10966 :
 10967 :

6427
 6428
 6429
 6430
 6431
 6432
 6433
 6434
 6435
 6436
 6437
 6438
 6439
 6440
 6441
 6442
 6443
 6444
 6445
 6446
 6447
 6448
 6449
 6450
 6451
 6452
 6453
 6454
 6455
 6456
 6457
 6458
 6459
 6460
 6461
 6462
 6463
 6464
 6465
 6466
 6467
 6468
 6469
 6470
 6471
 6472
 6473
 6474
 6475
 6476
 6477
 6478

DEFINITION OF OPTION 4

```
[0] :
    if .COMMAND eq read
    then
    begin
        if (DBL_VALUE = DOUBLE_CHECK (.WDPTR, .RDPTR, 256)) neq 0
        then
        begin
            SAYWHO (.LUN);
            PRINTB (SAY1, MSG5);
            !'ECC LOGIC FAILED TO DETECT DATA ERROR'
            PRINTB (FMT12A, ..DBL_VALUE, .DBL_VALUE);
            !'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
            DBL_VALUE = .DBL_VALUE + BUFSIZ*2;
            PRINTB (FMT12B, ..DBL_VALUE, .DBL_VALUE);
            !'BAD DATA: PPPPPP AT LOCATION QQQQQQ'
            WHY DROPT [.LUN] = CODE_8;
            ERRDF (426, MSG1, 0); !**** OPTION 4 ERROR 26 ****
            DODU (.LUN);
            leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
        end;
    end;

[1] :
    begin !* 4D1 * RETRY ALLOWED
    if RETRY (SIX, .COMMAND, .LUN, 256, .PTR, .SECTOR) neq 0
    then !THE RETRY FAILED -- SYSTEM FATAL ERROR
    begin
        WHY DROPT [.LUN] = CODE_4;
        ERRDF (427, MSG1, 0); !**** OPTION 4 ERROR 27 ****
        DODU (.LUN);
        leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 3 *
    end;
    end; !* 4D1 *

[2] :
    begin !* 4D2 * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
    WHY DROPT [.LUN] = CODE_5;
    ERRDF (428, MSG1, 0); !**** OPTION 4 ERROR 28 ****
    DODU (.LUN);
    leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 3 *
    end; !* 4D2 *

[3] :
    begin !* 4D3 * FATAL DRIVE ERROR -- NO RETRY ALLOWED
    ERRDF (429, MSG1, 0); !**** OPTION 4 ERROR 29 ****
    WHY DROPT [.LUN] = CODE_6;
    DODU (.LUN);
```

```

10969 ;MLX4
10970 :
10971 :
10972 : 6479
10973 : 6480
10974 : 6481
10975 : 6482
10976 : 6483
10977 : 6484
10978 : 6485
10979 : 6486
10980 : 6487
10981 : 6488
10982 : 6489
10983 : 6490
10984 : 6491
10985 : 6492
10986 : 6493
10987 : 6494
10988 : 6495
10989 : 6496
10990 : 6497
10991 : 6498
10992 : 6499
10993 : 6500
10994 : 6501
10995 : 6502
10996 : 6503
10997 : 6504
10998 : 6505
10999 : 6506
11000 : 6507
11001 : 6508
11002 : 6509
11003 : 6510
11004 : 6511
11005 : 6512
11006 : 6513
11007 : 6514
11008 : 6515
11009 : 6516
11010 : 6517
11011 : 6518
11012 : 6519
11013 : 6520
11014 : 6521
11015 : 6522
11016 : 6523
11017 : 6524
11018 : 6525
11019 : 6526
11020 : 6527
11021 : 6528
11022 : 6529
11023 : 6530

DEFINITION OF OPTION 4

leave LOOP;
end;
!* 4D3 *

[4] :
begin
ISOLATE ();
ERRDF (430, MSG2, 0);
WHY DROPT [.LUN] = CODE_7;
DODD (.LUN);
leave LOOP;
end;
!* 4D4 * UNRECOVERABLE DATA ERROR
!**** OPTION 4 ERROR 30 ****
!* JUMP JUST BEYOND END OF BLOCK * 3 *
!* 4D4 *

[5] :
begin
ISOLATE ();
!* 4D5 * RECOVERABLE DATA ERROR

if .ERROUT then PRINTB (FMT10B, .CHAN);

!' BIT 00'
OLDSEC = .MLEL;
OLDCHN = .CHAN;

if RETRY (ONE, .COMMAND, .LUN, 256, .PTR, .SECTOR) eql 5
then

if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
then
begin
if .ERROUT then ERRHRD (431, MSG4, 0); !**** OPTION 4 ERROR 31 ****
UP_HARD_COUNT (.LUN, .BOARD);
end
else
begin
if .ERROUT then ERRSOFT (432, MSG3, 0); !**** OPTION 4 ERROR 32 ****
UP_SOFT_COUNT (.LUN, .BOARD);
end
end
else
begin
if .ERROUT then ERRSOFT (433, MSG3, 0); !**** OPTION 4 ERROR 33 ****
UP_SOFT_COUNT (.LUN, .BOARD);
end;
end;
!* 4D5 *
tes;

```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (40)

```

11025 :MLX4
11026 :
11027 :
11028 : 6531
11029 : 6532
11030 : 6533
11031 : 6534
11032 : 6535
11033 : 6536
11034 : 6537
11035 : 6538
11036 : 6539
11037 : 6540
11038 : 6541
11039 : 6542
11040 : 6543
11041 : 6544
11042 : 6545
11043 : 6546
11044 : 6547
11045 : 6548
11046 : 6549
11047 : 6550
11048 : 6551
11049 : 6552
11050 : 6553
11051 : 6554
11052 : 6555
11053 : 6556
11054 : 6557
11055 : 6558
11056 : 6559
11057 : 6560
11058 : 6561
11059 : 6562
11060 : 6563
11061 : 6564
11062 : 6565
11063 : 6566
11064 : 6567
11065 : 6568
11066 : 6569
11067 : 6570
11068 : 6571
11069 : 6572
11070 : 6573
11071 : 6574
11072 : 6575
11073 : 6576
11074 : 6577
11075 : 6578
11076 : 6579
11077 : 6580
11078 : 6581
11079 : 6582

DEFINITION OF OPTION 4

end;
end;

+
Test to see if this uut's address space is
to be read for soft errors. This test is
is intended for DMT purposes.
-

if .EFNS21
then
begin
!Is the background pattern to be read

version czmlbb changed incr to incru
incru SECTOR from LOWEST to HIGHEST do
if read (.LUN, 256, RBUFF, .SECTOR) eql 5
then
begin
ISOLATE (); !Find the failing bank and board no.
if .ERROUT then PRINTB (FMT10B, .CHAN);
! Print where the error is
! Save the contents of the ML error location
! register so we can compare it to the new
! contents of this register after the retry.
! This is done to classify the error.
OLDSEC = .MLEL;
OLDCHN = .CHAN;
! Do a classify retry call. If the same error
! occurs then classify it as a hard error. If
! a different error occurred or the error went away
! then classify it as a soft error.

if RETRY (ONE, .COMMAND, .LUN, 256, .PTR, .OLDSEC) eql 5
then
! The same error occurred so see if it is at the same
! sector and channel number, if so then classify
! it as a hard error else classiy it as a soft
! error.

if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))

```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (40)

!* 4D * END OF 4TH SECTOR SELECTION LOOP
 !* 4 * END OF TEST FOR AN ACTIVE UNIT

!Is the background pattern to be read

! version czmlbb changed incr to incru

!Find the failing bank and board no.

OLDSEC = .MLEL;
 OLDCHN = .CHAN;

if RETRY (ONE, .COMMAND, .LUN, 256, .PTR, .OLDSEC) eql 5

! The same error occurred so see if it is at the same
 ! sector and channel number, if so then classify
 ! it as a hard error else classiy it as a soft
 ! error.

if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (40)

```

11081 :MLX4
11082 :
11083 :           DEFINITION OF OPTION 4
11084 :           6583
11085 :           6584
11086 :           6585
11087 :           6586
11088 :           6587
11089 :           6588
11090 :           P 6589
11091 :           P 6590
11092 :           6591
11093 :           6592
11094 :           6593
11095 :           6594
11096 :           6595
11097 :           6596
11098 :           6597
11099 :           6598
11100 :           6599
11101 :           6600
11102 :           6601
11103 :           P 6602
11104 :           P 6603
11105 :           6604
11106 :           6605
11107 :           6606
11108 :           6607
11109 :           6608
11110 :           6609
11111 :           6610
11112 :           6611
11113 :           6612
11114 :           6613
11115 :           6614
11116 :           6615
11117 :           P 6616
11118 :           P 6617
11119 :           6618
11120 :           6619
11121 :           6620
11122 :           6621
11123 :           6622
11124 :           6623
11125 :           6624
11126 :           6625
11127 :           6626
11128 :           6627
11129 :           6628
11130 :           6629
11131 :           6630
11132 :           6631
11133 :           6632

           then
           begin
           !Same error occurred 'hard'
           if .ERROUT
           !Print error if enabled
           then
           begin
           ERRHRD (434,
           !Error number
           MSG4,
           !Error message
           0);
           !Additional message routine
           end;
           UP_HARD_COUNT (.LUN, .BOARD);
           end
           else
           begin
           !Not the same error 'soft'
           if .ERROUT
           !Print error if enabled
           then
           begin
           ERRSOFT (435,
           !Error number
           MSG3,
           !Error message
           0);
           !Additional message routine
           end;
           UP_SOFT_COUNT (.LUN, .BOARD);
           end
           else
           begin
           !Not the same error 'soft'
           if .ERROUT
           !Print error if enabled
           then
           begin
           ERRSOFT (436,
           !Error number
           MSG3,
           !Error message
           0);
           !Additional message routine
           end;
           UP_SOFT_COUNT (.LUN, .BOARD);
           end;
           end;
           end;
           end;
           end;
           end;
           return;
           end;

!* 3 * END OF LOOP THAT COMPLETELY TESTS 1 UNIT
!* 2 * END OF LOGICAL UNIT SELECTION LOOP

!* 1 * END OF ROUTINE
    
```

Address	Hex	Hex	Hex	Label	Instruction	Comment	Address
11141							
11142							
11146	062444	004167	122664	OPT4:	.SBTTL OPT4 DEFINITION OF OPTION 4		
11147	062450	162706	000030		JSR R1,\$SAVE5	:	5908
11148	062454	012746	007650		SUB #30,SP	:	
11149	062460	012746	007344		MOV #RTN4,-(SP)	:	5981
11150	062464	012746	007100		MOV #WRD34,-(SP)	:	
11151	062470	012746	000003		MOV #SAY2,-(SP)	:	
11152	062474	010600			MOV #3,-(SP)	:	
11153	062476	104414			MOV SP,RO	: SP,*	
11154	062500	016716	117542		TRAP 14	:	
11155	062504	012746	012670		MOV MARPAT,(SP)	:	5983
11156	062510	004767	157050		MOV #WDBUFF,-(SP)	:	
11157	062514	016716	117526		JSR PC,GEN4	:	5984
11158	062520	005416			MOV MARPAT,(SP)	:	
11159	062522	012746	013670		NEG (SP)	:	5984
11160	062526	004767	157032		MOV #WCBUFF,-(SP)	:	
11161	062532	012766	012670	000016	JSR PC,GEN4	:	
11162	062540	012766	013670	000026	MOV #WDBUFF,16(SP)	: *,WDPTR	5985
11163	062546	012766	022670	000024	MOV #WCBUFF,26(SP)	: *,WCPTR	5986
11164	062554	012766	023670	000034	MOV #RDBUFF,24(SP)	: *,RDPTR	5987
11165	062562	016766	117224	000042	MOV #RCBUFF,34(SP)	: *,RCPTR	5988
11166	062570	005066	000014		MOV L\$UNIT,42(SP)	:	5990
11167	062574	000167	005362		CLR 14(SP)	: LUN	
11168	062600	016600	000014	1\$:	JMP 95\$:	
11169	062604	006200			MOV 14(SP),RO	: LUN,*	5995
11170	062606	006200			ASR RO	:	
11171	062610	006200			ASR RO	:	
11172	062612	062700	034442		ASR RO	:	
11173	062616	010046			ADD #DRIVE.STATUS,RO	:	
11174	062620	016646	000016		MOV RO,-(SP)	:	
11175	062624	042716	177770		MOV 16(SP),-(SP)	: LUN,*	
11176	062630	012746	000001		BIC #177770,(SP)	:	
11177	062634	005046			MOV #1,-(SP)	:	
11178	062636	004767	121514		CLR -(SP)	:	
11179	062642	062706	000010		JSR PC,BL\$GT2	:	
11180	062646	005300			ADD #10,SP	:	
11181	062650	001402			DEC RO	:	
11182	062652	000167	004630		BEQ 2\$:	
11183	062656	016667	000014	117210 2\$:	JMP 83\$:	
11184	062664	012746	007354		MOV 14(SP),L\$LUN	: LUN,*	5998
11185	062670	012746	007072		MOV #WRD35,-(SP)	:	5999
11186	062674	012746	000002		MOV #SAY1,-(SP)	:	
11187	062700	010600			MOV #2,-(SP)	:	
11188	062702	104414			MOV SP,RO	: SP,*	
11189	062704	012716	000332		TRAP 14	:	
11190	062710	012746	006160		MOV #WRD24,(SP)	:	6001
11191	062714	012746	000002		MOV #FMT2,-(SP)	:	
					MOV #2,-(SP)	:	

Address	OpCode	Operand 1	Operand 2	Operand 3	Label	Instruction	Comments	Address
11249								
11250								
11251								
11252	063166	000623				.WORD 623		
11253	063170	011070				.WORD MSG1		
11254	063172	000000				.WORD 0		
11255	063174	016600	000036			MOV 36(SP),R0		
11256	063200	112760	000006	034446		MOVB #6,WHY.DROPT(R0)	: LUN,*	6043
11257	063206	104451				TRAP 51		
11258	063210	062706	000022		6\$:	ADD #22,SP	:	6044
11259	063214	000565				BR 14\$:	6045
11260	063216	062706	000010		7\$:	ADD #10,SP	:	
11261	063222	005204				INC R4	:	6008
11262	063224	020401			8\$:	CMP R4,R1	: SECTOR	6007
11263	063226	101660				BLOS 3\$: SECTOR,*	
11264	063230	012716	007332			MOV #WRD24,(SP)	:	
11265	063234	012746	006160			MOV #FMT2,-(SP)	:	6051
11266	063240	012746	000002			MOV #2,-(SP)	:	
11267	063244	010600				MOV SP,R0	: SP,*	
11268	063246	104414				TRAP 14		
11269	063250	004767	162712			JSR PC,CHOOSE	:	
11270	063254	010002				MOV R0,R2	: * ,COMMAND	6053
11271	063256	017666	000054	000046		MOV @54(SP),46(SP)	:	
11272	063264	017604	000056			MOV @56(SP),R4	:	6058
11273	063270	000167	001350			JMP 33\$: * ,SECTOR	
11274	063274	005001			9\$:	CLR R1	:	
11275	063276	020227	045612			CMP R2,#READ	: COMMAND *	6061
11276	063302	001014				BNE 10\$		
11277	063304	005201				INC R1		
11278	063306	016603	000042			MOV 42(SP),R3	: RDPTR,PTR	6064
11279	063312	016646	000032			MOV 32(SP),-(SP)	: LUN,*	6065
11280	063316	012746	000400			MOV #400,-(SP)		
11281	063322	010346				MOV R3,-(SP)	: PTR,*	
11282	063324	010446				MOV R4,-(SP)	: SECTOR,*	
11283	063326	004767	162260			JSR PC,READ		
11284	063332	000412				BR 11\$		
11285	063334	016603	000034		10\$:	MOV 34(SP),R3	: WDPTR,PTR	6069
11286	063340	016646	000032			MOV 32(SP),-(SP)	: LUN,*	6070
11287	063344	012746	000400			MOV #400,-(SP)		
11288	063350	010346				MOV R3,-(SP)	: PTR,*	
11289	063352	010446				MOV R4,-(SP)	: SECTOR,*	
11290	063354	004767	162420			JSR PC,CHECK		
11291	063360	010005			11\$:	MOV R0,R5	: * ,VALUE	
11292	063362	001103				BNE 15\$:	
11293	063364	006001				ROR R1	:	6077
11294	063366	103402				BLO 13\$:	6082
11295	063370	000167	001012		12\$:	JMP 28\$		
11296	063374	016646	000044		13\$:	MOV 44(SP),-(SP)	: WDPTR,*	
11297	063400	016646	000054			MOV 54(SP),-(SP)	: RDPTR,*	6086
11298	063404	012746	000400			MOV #400,-(SP)		
11299	063410	004767	160712			JSR PC,DOUBLE.CHECK		
11300	063414	062706	000006			ADD #6,SP		
11301	063420	010066	000060			MOV R0,60(SP)	: * ,DBL.VALUE	
11302	063424	001761				BEQ 12\$		
11303	063426	016646	000042			MOV 42(SP),-(SP)	: LUN,*	6089

Address	Hex	Hex	Hex	Label	Instruction	Comments	Address
11305							
11306				:MLX4			
11307				:	DEFINITION OF OPTION 4		
11308	063432	004767	152066		JSR	PC,SAYWHO	
11309	063436	012716	011216		MOV	#MSG5,(SP)	
11310	063442	012746	007072		MOV	#SAY1,-(SP)	6090
11311	063446	012746	000002		MOV	#2,-(SP)	
11312	063452	010600			MOV	SP,R0	: SP,*
11313	063454	104414			TRAP	14	
11314	063456	016616	000066		MOV	66(SP),(SP)	: DBL.VALUE,*
11315	063462	017646	000066		MOV	@66(SP),-(SP)	: DBL.VALUE,*
11316	063466	012746	006710		MOV	#FMT12A,-(SP)	
11317	063472	012746	000003		MOV	#3,-(SP)	
11318	063476	010600			MOV	SP,R0	: SP,*
11319	063500	104414			TRAP	14	
11320	063502	062766	010000	000074	ADD	#10000,74(SP)	: *,DBL.VALUE
11321	063510	016616	000074		MOV	74(SP),(SP)	: DBL.VALUE,*
11322	063514	017646	000074		MOV	@74(SP),-(SP)	: DBL.VALUE,*
11323	063520	012746	006756		MOV	#FMT12B,-(SP)	
11324	063524	012746	000003		MOV	#3,-(SP)	
11325	063530	010600			MOV	SP,R0	: SP,*
11326	063532	104414			TRAP	14	
11327	063534	016601	000064		MOV	64(SP),R1	: LUN,*
11328	063540	112761	000010	034446	MOVB	#10,WHY.DROPT(R1)	6097
11329	063546	104455			TRAP	55	
11330	063550	000624			.WORD	624	6098
11331	063552	011070			.WORD	MSG1	
11332	063554	000000			.WORD	0	
11333	063556	016600	000064		MOV	64(SP),R0	: LUN,*
11334	063562	104451			TRAP	51	6099
11335	063564	062706	000050		ADD	#50,SP	
11336	063570	000520		14\$:	BR	20\$	6100
11337	063572	020527	000001	15\$:	CMP	R5,#1	: VALUE,*
11338	063576	001034			BNE	16\$	6077
11339	063600	012746	000006		MOV	#6,-(SP)	
11340	063604	010246			MOV	R2,-(SP)	: COMMAND,*
11341	063606	016646	000046		MOV	46(SP),-(SP)	: LUN,*
11342	063612	012746	000400		MOV	#400,-(SP)	
11343	063616	010346			MOV	R3,-(SP)	: PTR,*
11344	063620	010446			MOV	R4,-(SP)	: SECTOR,*
11345	063622	004767	162376		JSR	PC,RETRY	
11346	063626	062706	000014		ADD	#14,SP	
11347	063632	005700			TST	R0	
11348	063634	001655			BEQ	12\$	
11349	063636	016601	000042		MOV	42(SP),R1	: LUN,*
11350	063642	112761	000004	034446	MOVB	#4,WHY.DROPT(R1)	6111
11351	063650	104455			TRAP	55	
11352	063652	000625			.WORD	625	6112
11353	063654	011070			.WORD	MSG1	
11354	063656	000000			.WORD	0	
11355	063660	016600	000042		MOV	42(SP),R0	: LUN,*
11356	063664	104451			TRAP	51	6113
11357	063666	000457			BR	19\$	
11358	063670	020527	000002	16\$:	CMP	R5,#2	: VALUE,*
11359	063674	001015			BNE	17\$	6077

Address	Hex	Hex	Hex	Label	Instruction	Comment	Date/Time	Page
11361								
11362				:MLX4			27-Mar-1982 19:24:42	TOPS
11363				:	DEFINITION OF OPTION 4		27-Mar-1982 19:23:44	PA:C
11364	063676	016601	000042		MOV 42(SP),R1	: LUN,*		
11365	063702	112761	000005	034446	MOVB #5,WHY.DROPT(R1)			6121
11366	063710	104455			TRAP 55	:		
11367	063712	000626			.WORD 626			6122
11368	063714	011070			.WORD MSG1			
11369	063716	000000			.WORD 0			
11370	063720	016600	000042		MOV 42(SP),R0	: LUN,*		
11371	063724	104451			TRAP 51			6123
11372	063726	000437			BR 19\$:		
11373	063730	020527	000003	17\$:	CMP R5,#3	: VALUE,*		6124
11374	063734	001014			BNE 18\$			6077
11375	063736	104455			TRAP 55	:		
11376	063740	000627			.WORD 627			6129
11377	063742	011070			.WORD MSG1			
11378	063744	000000			.WORD 0			
11379	063746	016601	000042		MOV 42(SP),R1	: LUN,*		
11380	063752	112761	000006	034446	MOVB #6,WHY.DROPT(R1)			6130
11381	063760	010100			MOV R1,R0	: LUN,*		
11382	063762	104451			TRAP 51			6131
11383	063764	000420			BR 19\$:		
11384	063766	020527	000004	18\$:	CMP R5,#4	: VALUE,*		6132
11385	063772	001021			BNE 21\$			6077
11386	063774	004767	153332		JSR PC,ISOLATE	:		
11387	064000	104455			TRAP 55	:		6137
11388	064002	000630			.WORD 630			6138
11389	064004	011120			.WORD MSG2			
11390	064006	000000			.WORD 0			
11391	064010	016601	000042		MOV 42(SP),R1	: LUN,*		
11392	064014	112761	000007	034446	MOVB #7,WHY.DROPT(R1)			6139
11393	064022	010100			MOV R1,R0	: LUN,*		
11394	064024	104451			TRAP 51			6140
11395	064026	062706	000026	19\$:	ADD #26,SP	:		
11396	064032	000167	004120	20\$:	JMP 94\$			6141
11397	064036	020527	000005	21\$:	CMP R5,#5	: VALUE,*		
11398	064042	001161			BNE 28\$			6077
11399	064044	004767	153262		JSR PC,ISOLATE	:		
11400	064050	032767	000001	116202	BIT #1,ERROUT	:		6146
11401	064056	001423			BEQ 22\$			6148
11402	064060	017701	150324		MOV @ML.REG+42,R1			
11403	064064	006201			ASR R1			
11404	064066	006201			ASR R1			
11405	064070	006201			ASR R1			
11406	064072	006201			ASR R1			
11407	064074	006201			ASR R1			
11408	064076	006201			ASR R1			
11409	064100	042701	177700		BIC #177700,R1			
11410	064104	010146			MOV R1,-(SP)			
11411	064106	012746	006640		MOV #FMT10B,-(SP)			
11412	064112	012746	000002		MOV #2,-(SP)			
11413	064116	010600			MOV SP,R0	: SP,*		
11414	064120	104414			TRAP 14			
11415	064122	062706	000006		ADD #6,SP			

						27-Mar-1982 19:24:42	TOPS
						27-Mar-1982 19:23.44	PA:<
11417							
11418				:MLX4			
11419				:	DEFINITION OF OPTION 4		
11420	064126	017766	150260	000046 22\$:	MOV @ML.REG+44,46(SP)	: *.OLDSEC	6151
11421	064134	017701	150250		MOV @ML.REG+42,R1	:	6152
11422	064140	006201			ASR R1	:	
11423	064142	006201			ASR R1	:	
11424	064144	006201			ASR R1	:	
11425	064146	006201			ASR R1	:	
11426	064150	006201			ASR R1	:	
11427	064152	006201			ASR R1	:	
11428	064154	042701	177700		BIC #177700,R1	:	
11429	064160	010166	000050		MOV R1,50(SP)	: *.OLDCHN	
11430	064164	012746	000001		MOV #1,-(SP)	:	
11431	064170	010246			MOV R2,-(SP)	: COMMAND,*	6154
11432	064172	016646	000046		MOV 46(SP),-(SP)	: LUN,*	
11433	064176	012746	000400		MOV #400,-(SP)	:	
11434	064202	010346			MOV R3,-(SP)	: PTR,*	
11435	064204	010446			MOV R4,-(SP)	: SECTOR,*	
11436	064206	004767	162012		JSR PC,RETRY	:	
11437	064212	062706	000014		ADD #14,SP	:	
11438	064216	020027	000005		CMP R0,#5	:	
11439	064222	001052			BNE 25\$:	
11440	064224	027766	150162	000046	CMP @ML.REG+44,46(SP)	: *.OLDSEC	6157
11441	064232	001035			BNE 24\$:	
11442	064234	016600	000050		MOV 50(SP),R0	: OLDCHN,*	
11443	064240	017701	150144		MOV @ML.REG+42,R1	:	
11444	064244	006201			ASR R1	:	
11445	064246	006201			ASR R1	:	
11446	064250	006201			ASR R1	:	
11447	064252	006201			ASR R1	:	
11448	064254	006201			ASR R1	:	
11449	064256	006201			ASR R1	:	
11450	064260	042701	177700		BIC #177700,R1	:	
11451	064264	020100			CMP R1,R0	:	
11452	064266	001017			BNE 24\$:	
11453	064270	032767	000001	115762	BIT #1,ERROUT	:	6161
11454	064276	001404			BEQ 23\$:	
11455	064300	104456			TRAP 56	:	
11456	064302	000631			.WORD 631	:	
11457	064304	011202			.WORD MSG4	:	
11458	064306	000000			.WORD 0	:	
11459	064310	016646	000042	23\$:	MOV 42(SP),-(SP)	: LUN,*	6163
11460	064314	016746	150022		MOV BOARD,-(SP)	:	
11461	064320	004767	153076		JSR PC,UP.HARD.COUNT	:	
11462	064324	000427			BR 27\$:	
11463	064326	032767	000001	115724 24\$:	BIT #1,ERROUT	:	6157
11464	064334	001415			BEQ 26\$:	6168
11465	064336	104457			TRAP 57	:	
11466	064340	000632			.WORD 632	:	
11467	064342	011166			.WORD MSG3	:	
11468	064344	000000			.WORD 0	:	
11469	064346	000410			BR 26\$:	
11470	064350	032767	000001	115702 25\$:	BIT #1,ERROUT	:	6170
11471	064356	001404			BEQ 26\$:	6176

Address	OpCode	Operand 1	Operand 2	Label	Instruction	Comments	Address
11473							
11474							
11475							
11476	064360	104457			TRAP	57	
11477	064362	000633			.WORD	633	
11478	064364	011166			.WORD	MSG3	
11479	064366	000000			.WORD	0	
11480	064370	016646	000042	26\$:	MOV	42(SP),-(SP)	: LUN,*
11481	064374	016746	147742		MOV	BOARD,-(SP)	
11482	064400	004767	153500		JSR	PC,UP.SOFT.COUNT	
11483	064404	022626		27\$:	CMP	(SP)+,(SP)+	
11484	064406	016616	000042	28\$:	MOV	42(SP),(SP)	: LUN,*
11485	064412	012746	000400		MOV	#400,-(SP)	
11486	064416	016646	000056		MOV	56(SP),-(SP)	: WCPTR,*
11487	064422	010446			MOV	R4,-(SP)	: SECTOR,*
11488	064424	004767	160774		JSR	PC,WRITE	
11489	064430	010005			MOV	R0,R5	: *,VALUE
11490	064432	020527	000001		CMP	R5,#1	: VALUE,*
11491	064436	001036			BNE	29\$	
11492	064440	012746	000006		MOV	#6,-(SP)	
11493	064444	012746	045424		MOV	#WRITE,-(SP)	
11494	064450	016646	000054		MOV	54(SP),-(SP)	: LUN,*
11495	064454	012746	000400		MOV	#400,-(SP)	
11496	064460	016646	000072		MOV	72(SP),-(SP)	: WCPTR,*
11497	064464	010446			MOV	R4,-(SP)	: SECTOR,*
11498	064466	004767	161532		JSR	PC,RETRY	
11499	064472	062706	000014		ADD	#14,SP	
11500	064476	005700			TST	R0	
11501	064500	001456			BEQ	32\$	
11502	064502	016601	000050		MOV	50(SP),R1	: LUN,*
11503	064506	112761	000004	034446	MOVB	#4,WHY.DROPT(R1)	
11504	064514	104455			TRAP	55	
11505	064516	000634			.WORD	634	
11506	064520	011070			.WORD	MSG1	
11507	064522	000000			.WORD	0	
11508	064524	016600	000050		MOV	50(SP),R0	: LUN,*
11509	064530	104451			TRAP	51	
11510	064532	000436			BR	31\$	
11511	064534	020527	000002	29\$:	CMP	R5,#2	: VALUE,*
11512	064540	001015			BNE	30\$	
11513	064542	016601	000050		MOV	50(SP),R1	: LUN,*
11514	064546	112761	000005	034446	MOVB	#5,WHY.DROPT(R1)	
11515	064554	104455			TRAP	55	
11516	064556	000635			.WORD	635	
11517	064560	011070			.WORD	MSG1	
11518	064562	000000			.WORD	0	
11519	064564	016600	000050		MOV	50(SP),R0	: LUN,*
11520	064570	104451			TRAP	51	
11521	064572	000416			BR	31\$	
11522	064574	020527	000003	30\$:	CMP	R5,#3	: VALUE,*
11523	064600	001016			BNE	32\$	
11524	064602	104455			TRAP	55	
11525	064604	000636			.WORD	636	
11526	064606	011070			.WORD	MSG1	
11527	064610	000000			.WORD	0	

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

Address	Hex	Hex	Hex	Label	Instruction	Comments	Seq
11529				:MLX4			
11530				:			
11531					DEFINITION OF OPTION 4		
11532	064612	016601	000050		MOV 50(SP),R1	: LUN,*	
11533	064616	112761	000006	034446	MOVB #6,WHY.DROPT(R1)		6218
11534	064624	010100			MOV R1,RC	: LUN,*	
11535	064626	104451			TRAP 51		6219
11536	064630	062706	000034	31\$:	ADD #34,SP	:	
11537	064634	000570			BR 40\$:	6220
11538	064636	062706	000016	32\$:	ADD #16,SP	:	
11539	064642	005204			INC R4	: SECTOR	6059
11540	064644	020406	000046	33\$:	CMP R4,46(SP)	: SECTOR,*	6058
11541	064650	101002			BHI 34\$		
11542	064652	000167	176416		JMP 9\$		
11543	064656	012716	007336	34\$:	MOV #WRD25,(SP)	:	
11544	064662	012746	006160		MOV #FMT2,-(SP)		6226
11545	064666	012746	000002		MOV #2,-(SP)		
11546	064672	010600			MOV SP,R0	: SP,*	
11547	064674	104414			TRAP 14		
11548	064676	004767	161264		JSR PC,CHOOSE	:	
11549	064702	010002			MOV R0,R2	: *,COMMAND	6228
11550	064704	017666	000062	000052	MOV @62(SP),52(SP)	:	
11551	064712	017604	000060		MOV @60(SP),R4	: *,SECTOR	6230
11552	064716	000167	001350		JMP 59\$		
11553	064722	005001		35\$:	CLR R1	:	
11554	064724	020227	045612		CMP R2,#READ	: COMMAND,*	6233
11555	064730	001014			BNE 36\$		
11556	064732	005201			INC R1		
11557	064734	016603	000056		MOV 56(SP),R3	: RCPTR,PTR	6236
11558	064740	016646	000036		MOV 36(SP),-(SP)	: LUN,*	6237
11559	064744	012746	000400		MOV #400,-(SP)		
11560	064750	010346			MOV R3,-(SP)	: PTR,*	
11561	064752	010446			MOV R4,-(SP)	: SECTOR,*	
11562	064754	004767	160632		JSR PC,READ		
11563	064760	000412			BR 37\$		
11564	064762	016603	000050	36\$:	MOV 50(SP),R3	: WCPTR,PTR	6241
11565	064766	016646	000036		MOV 36(SP),-(SP)	: LUN,*	6242
11566	064772	012746	000400		MOV #400,-(SP)		
11567	064776	010346			MOV R3,-(SP)	: PTR,*	
11568	065000	010446			MOV R4,-(SP)	: SECTOR,*	
11569	065002	004767	160772		JSR PC,CHECK		
11570	065006	010005		37\$:	MOV R0,R5	: *,VALUE	
11571	065010	001103			BNE 41\$:	
11572	065012	006001			ROR R1	:	6249
11573	065014	103402			BLO 39\$:	6254
11574	065016	000167	001012	38\$:	JMP 54\$		
11575	065022	016646	000060	39\$:	MOV 60(SP),-(SP)	: WCPTR,*	
11576	065026	016646	000070		MOV 70(SP),-(SP)	: RCPTR,*	6258
11577	065032	012746	000400		MOV #400,-(SP)		
11578	065036	004767	157264		JSR PC,DOUBLE.CHECK		
11579	065042	062706	000006		ADD #6,SP		
11580	065046	010066	000064		MOV R0,64(SP)	: *,DBL.VALUE	
11581	065052	001761			BEQ 38\$		
11582	065054	016646	000046		MOV 46(SP),-(SP)	: LUN,*	
11583	065060	004767	150440		JSR PC,SAYWHO		6261

Address	Hex	Hex	Hex	Op	Op	Op	Op	Time	Time	Time
11585										
11586										
11587										
11588	065064	012716	011216	MOV	#MSG5,(SP)	:				
11589	065070	012746	007072	MOV	#SAY1,-(SP)	:				
11590	065074	012746	000002	MOV	#2,-(SP)	:				6262
11591	065100	010600		MOV	SP,R0	:	SP,*			
11592	065102	104414		TRAP	14	:				
11593	065104	016616	000072	MOV	72(SP),(SP)	:	DBL.VALUE,*			
11594	065110	017646	000072	MOV	@72(SP),-(SP)	:	DBL.VALUE,*			6264
11595	065114	012746	006710	MOV	#FMT12A,-(SP)	:				
11596	065120	012746	000003	MOV	#3,-(SP)	:				
11597	065124	010600		MOV	SP,R0	:	SP,*			
11598	065126	104414		TRAP	14	:				
11599	065130	062766	010000	ADD	#10000,100(SP)	:	*DBL.VALUE			
11600	065136	016616	000100	MOV	100(SP),(SP)	:	DBL.VALUE,*			6266
11601	065142	017646	000100	MOV	@100(SP),-(SP)	:	DBL.VALUE,*			6267
11602	065146	012746	006756	MOV	#FMT12B,-(SP)	:				
11603	065152	012746	000003	MOV	#3,-(SP)	:				
11604	065156	010600		MOV	SP,R0	:	SP,*			
11605	065160	104414		TRAP	14	:				
11606	065162	016601	000070	MOV	70(SP),R1	:	LUN,*			
11607	065166	112761	000010	MOVB	#10,WHY.DROPT(R1)	:				6269
11608	065174	104455		TRAP	55	:				
11609	065176	000637		.WORD	637	:				6270
11610	065200	011070		.WORD	MSG1	:				
11611	065202	000000		.WORD	0	:				
11612	065204	016600	000070	MOV	70(SP),R0	:	LUN,*			
11613	065210	104451		TRAP	51	:				6271
11614	065212	062706	000054	ADD	#54,SP	:				
11615	065216	000520		BR	46\$:				6272
11616	065220	020527	000001	CMP	R5,#1	:	VALUE,*			
11617	065224	001034		BNE	42\$:				6249
11618	065226	012746	000006	MOV	#6,-(SP)	:				
11619	065232	010246		MOV	R2,-(SP)	:				6280
11620	065234	016646	000052	MOV	52(SP),-(SP)	:	COMMAND,*			
11621	065240	012746	000400	MOV	#400,-(SP)	:	LUN,*			
11622	065244	010346		MOV	R3,-(SP)	:				
11623	065246	010446		MOV	R4,-(SP)	:	PTR,*			
11624	065250	004767	160750	JSR	PC,RETRY	:	SECTOR,*			
11625	065254	062706	000014	ADD	#14,SP	:				
11626	065260	005700		TST	R0	:				
11627	065262	001655		BEQ	38\$:				
11628	065264	016601	000046	MOV	46(SP),R1	:	LUN,*			
11629	065270	112761	000004	MOVB	#4,WHY.DROPT(R1)	:				6283
11630	065276	104455		TRAP	55	:				
11631	065300	000640		.WORD	640	:				6284
11632	065302	011070		.WORD	MSG1	:				
11633	065304	000000		.WORD	0	:				
11634	065306	016600	000046	MOV	46(SP),R0	:	LUN,*			
11635	065312	104451		TRAP	51	:				6285
11636	065314	000457		BR	45\$:				
11637	065316	020527	000002	CMP	R5,#2	:	VALUE,*			6286
11638	065322	001015		BNE	43\$:				6249
11639	065324	016601	000046	MOV	46(SP),R1	:	LUN,*			6293

Address	OpCode	Operand 1	Operand 2	Operand 3	Instruction	Comments	Address	Seq
11641							27-Mar-1982 19:24:42	TOPS
11642							27-Mar-1982 19:23:44	PA:<
11643					DEFINITION OF OPTION 4			
11644	065330	112761	000005	034446	MOVB #5,WHY.DROPT(R1)			
11645	065336	104455			TRAP 55			
11646	065340	000641			.WORD 641	:		6294
11647	065342	011070			.WORD MSG1			
11648	065344	000000			.WORD 0			
11649	065346	016600	000046		MOV 46(SP),R0	:		
11650	065352	104451			TRAP 51	: LUN,*		6295
11651	065354	000437			BR 45\$:		
11652	065356	020527	000003	43\$:	CMP R5,#3	:		6296
11653	065362	001014			BNE 44\$: VALUE,*		6249
11654	065364	104455			TRAP 55	:		
11655	065366	000642			.WORD 642			6301
11656	065370	011070			.WORD MSG1			
11657	065372	000000			.WORD 0			
11658	065374	016601	000046		MOV 46(SP),R1	:		
11659	065400	112761	000006	034446	MOVB #6,WHY.DROPT(R1)	: LUN,*		6302
11660	065406	010100			MOV R1,R0	:		
11661	065410	104451			TRAP 51	: LUN,*		6303
11662	065412	000420			BR 45\$:		
11663	065414	020527	000004	44\$:	CMP R5,#4	:		6304
11664	065420	001021			BNE 47\$: VALUE,*		6249
11665	065422	004767	151704		JSR PC,ISOLATE	:		
11666	065426	104455			TRAP 55	:		6309
11667	065430	000643			.WORD 643	:		6310
11668	065432	011120			.WORD MSG2			
11669	065434	000000			.WORD 0			
11670	065436	016601	000046		MOV 46(SP),R1	:		
11671	065442	112761	000007	034446	MOVB #7,WHY.DROPT(R1)	: LUN,*		6311
11672	065450	010100			MOV R1,R0	:		
11673	065452	104451			TRAP 51	: LUN,*		6312
11674	065454	062706	000032	45\$:	ADD #32,SP	:		
11675	065460	000167	002472	46\$:	JMP 94\$:		6313
11676	065464	020527	000005	47\$:	CMP R5,#5	:		
11677	065470	001161			BNE 54\$: VALUE,*		6249
11678	065472	004767	151634		JSR PC,ISOLATE	:		
11679	065476	032767	000001	114554	BIT #1,ERROUT	:		6318
11680	065504	001423			BEQ 48\$:		6320
11681	065506	017701	146676		MOV @ML.REG+42,R1			
11682	065512	006201			ASR R1			
11683	065514	006201			ASR R1			
11684	065516	006201			ASR R1			
11685	065520	006201			ASR R1			
11686	065522	006201			ASR R1			
11687	065524	006201			ASR R1			
11688	065526	042701	177700		BIC #177700,R1			
11689	065532	010146			MOV R1,-(SP)			
11690	065534	012746	006640		MOV #FMT10B,-(SP)			
11691	065540	012746	000002		MOV #2,-(SP)			
11692	065544	010600			MOV SP,R0	:		
11693	065546	104414			TRAP 14	: SP,*		
11694	065550	062706	000006		ADD #6,SP			
11695	065554	017766	146632	000052	MOV @ML.REG+44,52(SP)	: *,OLDSEC		6323

```

11697                               :MLX4
11698                               :
11699                               :
11700 065562 017701 146622          MOV    @ML.REG+42,R1
11701 065566 006201                ASR    R1
11702 065570 006201                ASR    R1
11703 065572 006201                ASR    R1
11704 065574 006201                ASR    R1
11705 065576 006201                ASR    R1
11706 065600 006201                ASR    R1
11707 065602 042701 177700         BIC    #177700,R1
11708 065606 010166 000054         MOV    R1,54(SP)
11709 065612 012746 000001         MOV    #1,-(SP)
11710 065616 010246                MOV    R2,-(SP)
11711 065620 016646 000052         MOV    52(SP),-(SP)
11712 065624 012746 000400         MOV    #400,-(SP)
11713 065630 010346                MOV    R3,-(SP)
11714 065632 010446                MOV    R4,-(SP)
11715 065634 004767 160364         JSR    PC,RETRY
11716 065640 062706 000014         ADD    #14,SP
11717 065644 020027 000005         CMP    R0,#5
11718 065650 001052                BNE    51$
11719 065652 027766 146534 000052  CMP    @ML.REG+44,52(SP)
11720 065660 001035                BNE    50$
11721 065662 016600 000054         MOV    54(SP),R0
11722 065666 017701 146516         MOV    @ML.REG+42,R1
11723 065672 006201                ASR    R1
11724 065674 006201                ASR    R1
11725 065676 006201                ASR    R1
11726 065700 006201                ASR    R1
11727 065702 006201                ASR    R1
11728 065704 006201                ASR    R1
11729 065706 042701 177700         BIC    #177700,R1
11730 065712 020100                CMP    R1,R0
11731 065714 001017                BNE    50$
11732 065716 032767 000001 114334  BIT    #1,ERROUT
11733 065724 001404                BEQ    49$
11734 065726 104456                TRAP   56
11735 065730 000644                .WORD 644
11736 065732 011202                .WORD MSG4
11737 065734 000000                .WORD 0
11738 065736 016646 000046 49$:   MOV    46(SP),-(SP)
11739 065742 016746 146374                MOV    BOARD,-(SP)
11740 065746 004767 151450                JSR    PC,UP.HARD.COUNT
11741 065752 000427                BR     53$
11742 065754 032767 000001 114276 50$:   BIT    #1,ERROUT
11743 065762 001415                BEQ    52$
11744 065764 104457                TRAP   57
11745 065766 000645                .WORD 645
11746 065770 011166                .WORD MSG3
11747 065772 000000                .WORD 0
11748 065774 000410                BR     52$
11749 065776 032767 000001 114254 51$:   BIT    #1,ERROUT
11750 066004 001404                BEQ    52$
11751 066006 104457                TRAP   57

```

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

6324

6326

6329

6333

6335

6329

6340

6342

6348

Address	Label	OpCode	OpData	OpComment	SeqNo
11753					
11754	:MLX4			DEFINITION OF OPTION 4	
11755	:				
11756	066010	000646		.WORD 646	
11757	066012	011166		.WORD MSG3	
11758	066014	000000		.WORD 0	
11759	066016	016646	000046	MOV 46(SP),-(SP)	
11760	066022	016746	146314	MOV BOARD,-(SP)	: LUN,* 6350
11761	066026	004767	152052	JSR PC,UP.SOFT.COUNT	
11762	066032	022626		CMP (SP)+,(SP)+	
11763	066034	016616	000046	MOV 46(SP),(SP)	: LUN,* 6317
11764	066040	012746	000400	MOV #400,-(SP)	6356
11765	066044	016646	000052	MOV 52(SP),-(SP)	: WDPTR,*
11766	066050	010446		MOV R4,-(SP)	: SECTOR,*
11767	066052	004767	157346	JSR PC,WRITE	
11768	066056	010005		MOV R0,R5	: *,VALUE
11769	066060	020527	000001	CMP R5,#1	: VALUE,*
11770	066064	001036		BNE 55\$	6362
11771	066066	012746	000006	MOV #6,-(SP)	
11772	066072	012746	045424	MOV #WRITE,-(SP)	: 6368
11773	066076	016646	000060	MOV 60(SP),-(SP)	
11774	066102	012746	000400	MOV #400,-(SP)	: LUN,*
11775	066106	016646	000066	MOV 66(SP),-(SP)	: WDPTR,*
11776	066112	010446		MOV R4,-(SP)	: SECTOR,*
11777	066114	004767	160104	JSR PC,RETRY	
11778	066120	062706	000014	ADD #14,SP	
11779	066124	005700		TST R0	
11780	066126	001456		BEQ 58\$	
11781	066130	016601	000054	MOV 54(SP),R1	: LUN,*
11782	066134	112761	000004 034446	MOVB #4,WHY.DROPT(R1)	6371
11783	066142	104455		TRAP 55	
11784	066144	000647		.WORD 647	: 6372
11785	066146	011070		.WORD MSG1	
11786	066150	000000		.WORD 0	
11787	066152	016600	000054	MOV 54(SP),R0	: LUN,*
11788	066156	104451		TRAP 51	6373
11789	066160	000436		BR 57\$	
11790	066162	020527	000002	CMP R5,#2	: VALUE,* 6374
11791	066166	001015		BNE 56\$	6362
11792	066170	016601	000054	MOV 54(SP),R1	: LUN,*
11793	066174	112761	000005 034446	MOVB #5,WHY.DROPT(R1)	6381
11794	066202	104455		TRAP 55	
11795	066204	000650		.WORD 650	: 6382
11796	066206	011070		.WORD MSG1	
11797	066210	000000		.WORD 0	
11798	066212	016600	000054	MOV 54(SP),R0	: LUN,*
11799	066216	104451		TRAP 51	6383
11800	066220	000416		BR 57\$	
11801	066222	020527	000003	CMP R5,#3	: VALUE,* 6384
11802	066226	001016		BNE 58\$	6362
11803	066230	104455		TRAP 55	
11804	066232	000651		.WORD 651	: 6389
11805	066234	011070		.WORD MSG1	
11806	066236	000000		.WORD 0	
11807	066240	016601	000054	MOV 54(SP),R1	: LUN,* 6390

Address	Instruction	Labels	Comments	Address	Instruction	Comments
11809						
11810						
11811						
11812	066244	112761	000006	034446	MOV ^B #6,WHY.DROPT(R1)	
11813	066252	010100			MOV R1,R0	
11814	066254	104451			TRAP 51	: LUN,*
11815	066256	062706	000040	57\$:	ADD #40,SP	
11816	066262	000570			BR 66\$	
11817	066264	062706	000016	58\$:	ADD #16,SP	
11818	066270	005304			DEC R4	: SECTOR
11819	066272	020466	000052	59\$:	CMP R4,52(SP)	: SECTOR,*
11820	066276	002402			BLT 60\$	
11821	066300	000167	176416		JMP 35\$	
11822	066304	012716	007332	60\$:	MOV #WRD24,(SP)	
11823	066310	012746	006160		MOV #FMT2,-(SP)	
11824	066314	012746	000002		MOV #2,-(SP)	
11825	066320	010600			MOV SP,R0	: SP,*
11826	066322	104414			TRAP 14	
11827	066324	004767	157636		JSR PC,CHOOSE	
11828	066330	010002			MOV R0,R2	: *,COMMAND
11829	066332	017666	000064	000064	MOV #64(SP),64(SP)	
11830	066340	017604	000066		MOV #66(SP),R4	: *,SECTOR
11831	066344	000167	001120		JMP 81\$	
11832	066350	005001			CLR R1	
11833	066352	020227	045612	61\$:	CMP R2,#READ	: COMMAND,*
11834	066356	001014			BNE 62\$	
11835	066360	005201			INC R1	
11836	066362	016603	000052		MOV 52(SP),R3	: RDPTR,PTR
11837	066366	016646	000042		MOV 42(SP),-(SP)	: LUN,*
11838	066372	012746	000400		MOV #400,-(SP)	
11839	066376	010346			MOV R3,-(SP)	: PTR,*
11840	066400	010446			MOV R4,-(SP)	: SECTOR,*
11841	066402	004767	157204		JSR PC,READ	
11842	066406	000412			BR 63\$	
11843	066410	016603	000044	62\$:	MOV 44(SP),R3	: WDPTR,PTR
11844	066414	016646	000042		MOV 42(SP),-(SP)	: LUN,*
11845	066420	012746	000400		MOV #400,-(SP)	
11846	066424	010346			MOV R3,-(SP)	: PTR,*
11847	066426	010446			MOV R4,-(SP)	: SECTOR,*
11848	066430	004767	157344		JSR PC,CHECK	
11849	066434	010005		63\$:	MOV R0,R5	: *,VALUE
11850	066436	001103			BNE 67\$	
11851	066440	006001			ROR R1	
11852	066442	103402			BLO 65\$	
11853	066444	000167	001012	64\$:	JMP 80\$	
11854	066450	016646	000054	65\$:	MOV 54(SP),-(SP)	: WDPTR,*
11855	066454	016646	000064		MOV 64(SP),-(SP)	: RDPTR,*
11856	066460	012746	000400		MOV #400,-(SP)	
11857	066464	004767	155636		JSR PC,DOUBLE.CHECK	
11858	066470	062706	000006		ADD #6,SP	
11859	066474	010066	000070		MOV R0,70(SP)	: *,DBL.VALUE
11860	066500	001761			BEQ 64\$	
11861	066502	016646	000052		MOV 52(SP),-(SP)	: LUN,*
11862	066506	004767	147012		JSR PC,SAYWHO	
11863	066512	012716	011216		MOV #MSG5,(SP)	

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

Address	Offset	Operation	Comment	Label	Destination	Source
11865						
11866						
11867						
11868	066516	012746	007072		MOV #SAY1,-(SP)	
11869	066522	012746	000002		MOV #2,-(SP)	
11870	066526	010600			MOV SP,R0	: SP,*
11871	066530	104414			TRAP 14	
11872	066532	016616	000076		MOV 76(SP),(SP)	: DBL.VALUE,*
11873	066536	017646	000076		MOV @76(SP),-(SP)	: DBL.VALUE,*
11874	066542	012746	006710		MOV #FMT12A,-(SP)	
11875	066546	012746	000003		MOV #3,-(SP)	
11876	066552	010600			MOV SP,R0	: SP,*
11877	066554	104414			TRAP 14	
11878	066556	062766	010000	000104	ADD #10000,104(SP)	: *,DBL.VALUE
11879	066564	016616	000104		MOV 104(SP),(SP)	: DBL.VALUE,*
11880	066570	017646	000104		MOV @104(SP),-(SP)	: DBL.VALUE,*
11881	066574	012746	006756		MOV #FMT12B,-(SP)	
11882	066600	012746	000003		MOV #3,-(SP)	
11883	066604	010600			MOV SP,R0	: SP,*
11884	066606	104414			TRAP 14	
11885	066610	016601	000074		MOV 74(SP),R1	: LUN,*
11886	066614	112761	000010	034446	MOV #10,WHY.DROPT(R1)	
11887	066622	104455			TRAP 55	
11888	066624	000652			.WORD 652	
11889	066626	011070			.WORD MSG1	
11890	066630	000000			.WORD 0	
11891	066632	016600	000074		MOV 74(SP),R0	: LUN,*
11892	066636	104451			TRAP 51	
11893	066640	062706	000060		ADD #60,SP	
11894	066644	000520			BR 72\$	
11895	066646	020527	000001	66\$:	CMP R5,#1	: VALUE,*
11896	066652	001034		67\$:	BNE 68\$	
11897	066654	012746	000006		MOV #6,-(SP)	
11898	066660	010246			MOV R2,-(SP)	: COMMAND,*
11899	066662	016646	000056		MOV 56(SP),-(SP)	: LUN,*
11900	066666	012746	000400		MOV #400,-(SP)	
11901	066672	010346			MOV R3,-(SP)	: PTR,*
11902	066674	010446			MOV R4,-(SP)	: SECTOR,*
11903	066676	004767	157322		JSR PC,RETRY	
11904	066702	062706	009014		ADD #14,SP	
11905	066706	005700			TST R0	
11906	066710	001655			BEQ 64\$	
11907	066712	016601	000052		MOV 52(SP),R1	: LUN,*
11908	066716	112761	000004	034446	MOV #4,WHY.DROPT(R1)	
11909	066724	104455			TRAP 55	
11910	066726	000653			.WORD 653	
11911	066730	011070			.WORD MSG1	
11912	066732	000000			.WORD 0	
11913	066734	016600	000052		MOV 52(SP),R0	: LUN,*
11914	066740	104451			TRAP 51	
11915	066742	000457			BR 71\$	
11916	066744	020527	000002	68\$:	CMP R5,#2	: VALUE,*
11917	066750	001015			BNE 69\$	
11918	066752	016601	000052		MOV 52(SP),R1	: LUN,*
11919	066756	112761	000005	034446	MOV #5,WHY.DROPT(R1)	

Address	OpCode	Operand 1	Operand 2	Operand 3	Label	Instruction	Comments	Address
11921								
11922								
11923								
11924	066764	104455				TRAP 55		
11925	066766	000654				.WORD 654	:	6469
11926	066770	011070				.WORD MSG1	:	
11927	066772	000000				.WORD 0	:	
11928	066774	016600	000052			MOV 52(SP),R0	:	
11929	067000	104451				TRAP 51	:	6470
11930	067002	000437				BR 71\$:	
11931	067004	020527	000003	69\$:		CMP R5,#3	:	6471
11932	067010	001014				BNE 70\$:	6424
11933	067012	104455				TRAP 55	:	
11934	067014	000655				.WORD 655	:	6476
11935	067016	011070				.WORD MSG1	:	
11936	067020	000000				.WORD 0	:	
11937	067022	016601	000052			MOV 52(SP),R1	:	
11938	067026	112761	000006	034446		MOVB #6,WHY.DROPT(R1)	:	6477
11939	067034	010100				MOV R1,R0	:	
11940	067036	104451				TRAP 51	:	6478
11941	067040	000420				BR 71\$:	
11942	067042	020527	000004	70\$:		CMP R5,#4	:	6479
11943	067046	001021				BNE 73\$:	6424
11944	067050	004767	150256			JSR PC,ISOLATE	:	
11945	067054	104455				TRAP 55	:	6484
11946	067056	000656				.WORD 656	:	6485
11947	067060	011120				.WORD MSG2	:	
11948	067062	000000				.WORD 0	:	
11949	067064	016601	000052			MOV 52(SP),R1	:	
11950	067070	112761	000007	034446		MOVB #7,WHY.DROPT(R1)	:	6486
11951	067076	010100				MOV R1,R0	:	
11952	067100	104451				TRAP 51	:	6487
11953	067102	062706	000036	71\$:		ADD #36,SP	:	
11954	067106	000167	001044	72\$:		JMP 94\$:	6488
11955	067112	020527	000005	73\$:		CMP R5,#5	:	
11956	067116	001161				BNE 80\$:	6424
11957	067120	004767	150206			JSR PC,ISOLATE	:	
11958	067124	032767	000001	113126		BIT #1,ERROUT	:	6493
11959	067132	001423				BEQ 74\$:	6495
11960	067134	017701	145250			MOV @ML.REG+42,R1	:	
11961	067140	006201				ASR R1	:	
11962	067142	006201				ASR R1	:	
11963	067144	006201				ASR R1	:	
11964	067146	006201				ASR R1	:	
11965	067150	006201				ASR R1	:	
11966	067152	006201				ASR R1	:	
11967	067154	042701	177700			ASR R1	:	
11968	067160	010146				BIC #177700,R1	:	
11969	067162	012746	006640			MOV R1,-(SP)	:	
11970	067166	012746	000002			MOV #FMT10B,-(SP)	:	
11971	067172	010600				MOV #2,-(SP)	:	
11972	067174	104414				MOV SP,R0	:	
11973	067176	062706	000006			TRAP 14	:	6498
11974	067202	017766	145204	000056	74\$:	ADD #6,SP	:	
11975	067210	017701	145174			MOV @ML.REG+44,56(SP)	:	6499
						MOV @ML.REG+42,R1	:	

				:MLX4		DEFINITION OF OPTION 4			
11977									
11978									
11979									
11980	067214	006201			ASR	R1			
11981	067216	006201			ASR	R1			
11982	067220	006201			ASR	R1			
11983	067222	006201			ASR	R1			
11984	067224	006201			ASR	R1			
11985	067226	006201			ASR	R1			
11986	067230	042701	177700		BIC	#177700,R1			
11987	067234	010166	000060		MOV	R1,60(SP)			
11988	067240	012746	000001		MOV	#1,-(SP)	:	*,OLDCHN	
11989	067244	010246			MOV	R2,-(SP)	:		
11990	067246	016646	000056		MOV	56(SP),-(SP)	:	COMMAND,*	6501
11991	067252	012746	000400		MOV	#400,-(SP)	:	LUN,*	
11992	067256	010346			MOV	R3,-(SP)	:		
11993	067260	010446			MOV	R4,-(SP)	:	PTR,*	
11994	067262	004767	156736		JSR	PC,RETRY	:	SECTOR,*	
11995	067266	062706	000014		ADD	#14,SP			
11996	067272	020027	000005		CMP	RO,#5			
11997	067276	001052			BNE	77\$			
11998	067300	027766	145106	000056	CMP	@ML.REG+44,56(SP)	:	*,OLDSEC	6504
11999	067306	001035			BNE	76\$			
12000	067310	016600	000060		MOV	60(SP),RO	:	OLDCHN,*	
12001	067314	017701	145070		MOV	@ML.REG+42,R1			
12002	067320	006201			ASR	R1			
12003	067322	006201			ASR	R1			
12004	067324	006201			ASR	R1			
12005	067326	006201			ASR	R1			
12006	067330	006201			ASR	R1			
12007	067332	006201			ASR	R1			
12008	067334	042701	177700		ASR	R1			
12009	067340	020100			BIC	#177700,R1			
12010	067342	001017			CMP	R1,RO			
12011	067344	032767	000001	112706	BNE	76\$			
12012	067352	001404			BIT	#1,ERROUT	:		
12013	067354	104456			BEQ	75\$			6508
12014	067356	000657			TRAP	56			
12015	067360	011202			.WORD	657			
12016	067362	000000			.WORD	MSG4			
12017	067364	016646	000052	75\$:	.WORD	0			
12018	067370	016746	144746		MOV	52(SP),-(SP)	:	LUN,*	6510
12019	067374	004767	150022		MOV	BOARD,-(SP)			
12020	067400	000427			JSR	PC,UP.HARD.COUNT			
12021	067402	032767	000001	112650	BR	79\$:		6504
12022	067410	001415			BIT	#1,ERROUT	:		6515
12023	067412	104457			BEQ	78\$			
12024	067414	000660			TRAP	57			
12025	067416	011166			.WORD	660			
12026	067420	000000			.WORD	MSG3			
12027	067422	000410			.WORD	0			
12028	067424	032767	000001	112626	BR	78\$:		6517
12029	067432	001404			BIT	#1,ERROUT	:		6523
12030	067434	104457			BEQ	78\$			
12031	067436	000661			TRAP	57			
					.WORD	661			

Address	Hex	Hex	Hex	Label	Instruction	Comment	Address
12033							
12034				:MLX4			
12035				:			
12036	067440	011166			.WORD	MSG3	
12037	067442	000000			.WORD	0	
12038	067444	016646	000052	78\$:	MOV	52(SP),-(SP)	: LUN,*
12039	067450	016746	144666		MOV	BOARD,-(SP)	
12040	067454	004767	150424		JSR	PC,UP.SOFT.COUNT	
12041	067460	022626		79\$:	CMP	(SP)+,(SP)+	
12042	067462	062706	000010	80\$:	ADD	#10,SP	:
12043	067466	005204			INC	R4	: SECTOR
12044	067470	020466	000064	81\$:	CMP	R4,64(SP)	: SECTOR,*
12045	067474	101002			BHI	82\$	
12046	067476	000167	176646		JMP	61\$	
12047	067502	062706	000026	82\$:	ADD	#26,SP	:
12048	067506	032767	000001	112546	83\$:	BIT	#1,EFNS21
12049	067514	001002			BNE	84\$:
12050	067516	000167	000434		JMP	94\$	
12051	067522	016600	000014	84\$:	MOV	14(SP),R0	: LUN,*
12052	067526	006300			ASL	R0	
12053	067530	016001	034500		MOV	TOP.SECT(R0),R1	
12054	067534	016004	034460		MOV	LOW.SECT(R0),R4	: *,SECTOR
12055	067540	000167	000402		JMP	93\$	
12056	067544	016646	000014	85\$:	MOV	14(SP),-(SP)	: LUN,*
12057	067550	012746	000400		MOV	#400,-(SP)	
12058	067554	012746	022670		MOV	#RBUF,-(SP)	
12059	067560	010446			MOV	R4,-(SP)	: SECTOR,*
12060	067562	004767	156024		JSR	PC,READ	
12061	067566	062706	000010		ADD	#10,SP	
12062	067572	020027	000005		CMP	R0,#5	
12063	067576	001162			BNE	92\$	
12064	067600	004767	147526		JSR	PC,ISOLATE	:
12065	067604	032767	000001	112446	BIT	#1,ERROUT	: 6553
12066	067612	001423			BEQ	86\$: 6555
12067	067614	017700	144570		MOV	@ML.REG+42,R0	
12068	067620	006200			ASR	R0	
12069	067622	006200			ASR	R0	
12070	067624	006200			ASR	R0	
12071	067626	006200			ASR	R0	
12072	067630	006200			ASR	R0	
12073	067632	006200			ASR	R0	
12074	067634	042700	177700		BIC	#177700,R0	
12075	067640	010046			MOV	R0,-(SP)	
12076	067642	012746	006640		MOV	#FMT10B,-(SP)	
12077	067646	012746	000002		MOV	#2,-(SP)	
12078	067652	010600			MOV	SP,R0	: SP,*
12079	067654	104414			TRAP	14	
12080	067656	062706	000006		ADD	#6,SP	
12081	067662	017766	144524	000020	86\$:	MOV	@ML.REG+44,20(SP)
12082	067670	017700	144514		MOV	@ML.REG+42,R0	: *,OLDSEC
12083	067674	006200			ASR	R0	: 6564
12084	067676	006200			ASR	R0	: 6565
12085	067700	006200			ASR	R0	
12086	067702	006200			ASR	R0	
12087	067704	006200			ASR	R0	


```
12145 ;MLX4
12146 .
12147 DEFINITION OF OPTION 4
12148 070142 022626 91$: CMP (SP)+,(SP)+
12149 070144 005204 92$: INC R4 ; SECTOR
12150 070146 020401 93$: CMP R4,R1 ; SECTOR,*
12151 070150 101002 BHI 94$
12152 070152 000167 177366 JMP 85$
12153 070156 005266 000014 94$: INC 14(SP) ; LUN
12154 070162 026666 000014 000042 95$: CMP 14(SP),42(SP) ; LUN,*
12155 070170 002002 BGE 96$
12156 070172 000167 172402 JMP 1$
12157 070176 062706 000044 96$: ADD #44,SP
12158 070202 000207 RTS PC ;
12159
12160 ; Routine Size: 1456 words
12161 ; Maximum stack depth per invocation: 48 words
12166
12167
```

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

6552
6548

5990

5908

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (41)

```

12169 :MLX4
12170 :
12171 :
12172 : 6633 %sbttl 'SELECTING A RANDOM WORD COUNT'
12173 : 6634 routine RNDWC =
12174 : 6635 begin
12175 : 6636
12176 : 6637 !++
12177 : 6638 ROUTINE: RNDWC
12178 : 6639
12179 : 6640 PURPOSE: TO SELECT A RANDOM WORD COUNT WITHIN THE RANGE
12180 : 6641 1 TO BUFSIZ.
12181 : 6642
12182 : 6643 RESULT: THE VALUE RETURNED WILL BE USED BY THE CALLER
12183 : 6644 AS ITS 'WRDCNT'
12184 : 6645 !--
12185 : 6646
12186 : 6647 local
12187 : 6648 WRDCNT:
12188 : 6649
12189 : 6650 RN ();
12190 : 6651 RANDOM = .RANDOM and %o'077777';
12191 : 6652 WRDCNT = ((.RANDOM mod BUFSIZ) + 1);
12192 : 6653 return .WRDCNT;
12193 : 6654 end;
    
```

```

12198
12202 070204 004767 115160 .SBTTL RNDWC SELECTING A RANDOM WORD COUNT
12203 070210 042767 100000 115246 JSR PC,RN
12204 070216 016746 115242 BIC #100000,RANDOM
12205 070222 012746 004000 MOV RANDOM,-(SP)
12206 070226 004767 114750 MOV #4000,-(SP)
12207 070232 005200 JSR PC,BL$MOD
12208 070234 022626 INC R0
12209 070236 000207 CMP (SP)+,(SP)+
12210 RTS PC
    
```

6650
 6651
 6652
 6634

; Routine Size: 14 words
 ; Maximum stack depth per invocation: 2 words

12211
 12212
 12217
 12218

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (42)

12220 :MLX4
 12221 :
 12222 :
 12223 :
 12224 :
 12225 :
 12226 :
 12227 :
 12228 :
 12229 :
 12230 :
 12231 :
 12232 :
 12233 :
 12234 :
 12235 :
 12236 :
 12237 :
 12238 :
 12239 :
 12240 :
 12241 :
 12242 :
 12243 :
 12244 :
 12245 :
 12246 :
 12247 :
 12248 :
 12249 :
 12250 :
 12251 :
 12252 :
 12253 :
 12254 :
 12255 :
 12256 :
 12257 :
 12258 :
 12259 :
 12260 :
 12261 :
 12262 :
 12263 :
 12264 :
 12265 :
 12266 :
 12267 :
 12268 :
 12269 :
 12270 :
 12271 :
 12272 :
 12273 :
 12274 :

```

SELECTING A RANDOM SECTOR
6655 %sbttl 'SELECTING A RANDOM SECTOR'
6656 routine RNDSEC (LUN) =
6657     begin
6658
6659     +-
6660     ROUTINE:      RNDSEC(LUN)
6661
6662     PURPOSE:      TO SELECT A RANDOM SECTOR NUMBER WITHIN THE RANGE
6663                  OF TESTABLE SECTORS (LOWEST TO HIGHEST)
6664
6665     ARGUMENT:     LUN = THE CURRENT LOGICAL UNIT
6666                  NOTE: 'LUN' IS REQUIRED TO CALCULATE LOWEST/HIGHEST
6667                  FOR THE PARTICULAR LOGICAL UNIT.
6668
6669     RESULT:       THE VALUE RETURNED WILL BE USED BY THE CALLER
6670                  AS ITS 'SECTOR'.
6671     --
6672
6673     local
6674         SECTOR,
6675         SIZE;
6676
6677     version czmlbb changed eql to eqlu
6678
6679     if LOWEST eqlu HIGHEST
6680     then
6681         SECTOR = LOWEST
6682     else
6683         begin
6684             RN ();
6685             RANDOM = .RANDOM and %o'077777';           !IGNORE THE SIGN BIT
6686
6687     version czmlbb
6688
6689     'Highest - Lowest + 1' when testing an ML-11B with
6690     16 array modules results in a negative number which
6691     causes the Bliss operator 'mod' to hang the CPU.
6692     Due to this malfunction the '+ 1' has been deleted
6693     which will avoid this malfunction
6694
6695     SIZE = HIGHEST - LOWEST;
6696     SECTOR = (LOWEST + (.RANDOM mod .SIZE));           !FIND THE SECTOR RANGE
6697                                                     !FORCE RANGE
6698     end;
6699
6700     return .SECTOR;
6701     end;

```

.SBTTL RNDSEC SELECTING A RANDOM SECTOR

SEQ 0275

12276									
12277				:MLX4					
12278				:		SELECTING A RANDOM SECTOR		27-Mar-1982 19:24:42	TOPS
12282	070240	004167	115032					27-Mar-1982 19:23:44	PA:<
12283	070244	016601	000012	RNDSEC:	JSR	R1,\$SAVE3	:		6656
12284	070250	006301			MOV	12(SP),R1	:	LUN,*	6680
12285	070252	012703	034460		ASL	R1	:		
12286	070256	060103			MOV	#LOW.SECT,R3	:		
12287	070260	021361	C34500		ADD	R1,R3	:		
12288	070264	001602			CMP	(R3),TOP.SECT(R1)	:		
12289	070266	011302			BNE	1\$:		
12290	070270	000420			MOV	(R3),R2	:	*.SECTOR	6682
12291	070272	004767	115072		BR	2\$:		6680
12292	070276	042767	100000	115160	1\$:	JSR	PC,RN	:	6685
12293	070304	016101	034500			BIC	#100000,RANDOM	:	6686
12294	070310	161301				MOV	TOP.SECT(R1),R1	:	6696
12295	070312	016746	115146			SUB	(R3),R1	:	*.SIZE
12296	070316	010146				MOV	RANDOM,-(SP)	:	*.SIZE
12297	070320	004767	114656			MOV	R1,-(SP)	:	6697
12298	070324	061300				JSR	PC,BL\$MOD	:	
12299	070326	010002				ADD	(R3),R0	:	
12300	070330	022626				MOV	R0,R2	:	*.SECTOR
12301	070332	010200				CMP	(SP)+,(SP)+	:	
12302	070334	000207		2\$:		MOV	R2,R0	:	6684
12303						RTS	PC	:	6657
12304								:	6656
12305								:	
12310								:	
12311								:	

: Routine Size: 31 words
 : Maximum stack depth per invocation: 6 words

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (43)

```

12313 :MLX4
12314 :
12315 :      SELECTING A RANDOM UNIT
12316 :      6702 %sbttl 'SELECTING A RANDOM UNIT'
12317 :      6703 routine RNDU =
12318 :      6704     begin
12319 :      6705
12320 :      6706 !++
12321 :      6707 ROUTINE:      RNDU
12322 :      6708
12323 :      6709 PURPOSE:    TO SELECT A RANDOM LOGICAL UNIT NUMBER WITHIN
12324 :      6710             THE RANGE OF TESTABLE UNITS (0 TO .LSUNIT-1)
12325 :      6711 !--
12326 :      6712
12327 :      6713     local
12328 :      6714       LUN;
12329 :      6715
12330 :      6716     if .LSUNIT eql 1
12331 :      6717     then
12332 :      6718       LUN = 0
12333 :      6719     else
12334 :      6720       begin
12335 :      6721         RN ();
12336 :      6722         RANDOM = .RANDOM and %o'077777';
12337 :      6723         RANDOM = (.RANDOM mod .LSUNIT);
12338 :      6724
12339 :      6725       !+
12340 :      6726       ! MAKE SURE THE DRIVE IS ACTIVE. IF IT ISN'T,
12341 :      6727       ! THEN FIND THE NEXT AVAILABLE ACTIVE DRIVE:
12342 :      6728       !-
12343 :      6729
12344 :      6730       incr COUNT from 0 to (.LSUNIT - 1) do
12345 :      6731
12346 :      6732         if .DRIVE_STATUS [.RANDOM] eql ACTIVE
12347 :      6733         then
12348 :      6734           begin
12349 :      6735             LUN = .RANDOM;
12350 :      6736             exitloop;
12351 :      6737             end
12352 :      6738         else
12353 :      6739           RANDOM = ((.RANDOM + 1) mod .LSUNIT);
12354 :      6740
12355 :      6741         end;
12356 :      6742
12357 :      6743     return .LUN;
12358 :      6744     end;
12362 :
12363 :
12367 070336 004167 114752      RNDU:  .SBTTL RNDU SELECTING A RANDOM UNIT
                                       JSR   R1,$SAVE4
  
```

!* 1 *

!* 2 *

! IGNORE THE SIGN BIT
 ! FORCE THE RANGE

!* 2 *

!* 1 *

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (44)

12423 :MLX4
12424 :
12425 :
12426 :
12427 :
12428 :
12429 :
12430 :
12431 :
12432 :
12433 :
12434 :
12435 :
12436 :
12437 :
12438 :
12439 :
12440 :
12441 :
12442 :
12443 :
12444 :
12445 :
12446 :
12447 :
12448 :
12449 :
12450 :
12451 :
12452 :
12453 :
12454 :
12455 :
12456 :
12457 :
12458 :
12459 :
12460 :
12461 :
12462 :
12463 :
12464 :
12465 :
12466 :
12467 :
12468 :
12469 :
12470 :
12471 :
12472 :
12473 :
12474 :
12475 :
12476 :
12477 :

TESTING RANDOM DATA

%sbttl 'TESTING RANDOM DATA'
routine RAND1 (REPEAT) : novalue =
begin

! * 1 * START OF ROUTINE

!++
ROUTINE: RAND1(REPEAT)
PURPOSE: TO TEST USING RANDOM DATA
ARGUMENT: REPEAT = NUMBER OF TIMES TO EXECUTE THIS ROUTINE
BEFORE RETURNING TO THE CALLER (OPT5).

NOTE: THIS TEST CODE FOLLOWS THE SAME FLOW AS OPT3,
BUT USES A RANDOM DATA PATTERN.

THE CODE FOR 'RAND1' IN BRIEF:

BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COUNT FROM 1 TO REPEAT
: BEGIN 2 (START OF REPEAT LOOP FOR THE ROUTINE)
: GENERATE THE RANDOM PATTERN
: INCR LUN FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : INITIALIZE THE WRITE AND READ BUFFER POINTERS
: : : : SECTOR = LOWEST
: : : : WHILE SECTOR LEQ HIGHEST DO
: : : : : BEGIN 6 (START OF SECTOR SELECTION LOOP)
: : : : : GET WRDCNT
: : : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : UPDATE SECTOR NUMBER BY NUMBER OF SECTORS IN PREVIOUS TRANSFER
: : : : : END 6 (END OF SECTOR SELECTION LOOP)
: : : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : : : END 4 (END OF TESTLOOP)
: : : : : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
: : : : : END 2 (END OF REPEAT LOOP FOR THIS ROUTINE)
RETURN
END 1 (END OF ROUTINE)

Label

12535 :MLX4
 12536 :
 12537 :
 12538 :
 12539 :
 12540 :
 12541 :
 12542 :
 12543 :
 12544 :
 12545 :
 12546 :
 12547 :
 12548 :
 12549 :
 12550 :
 12551 :
 12552 :
 12553 :
 12554 :
 12555 :
 12556 :
 12557 :
 12558 :
 12559 :
 12560 :
 12561 :
 12562 :
 12563 :
 12564 :
 12565 :
 12566 :
 12567 :
 12568 :
 12569 :
 12570 :
 12571 :
 12572 :
 12573 :
 12574 :
 12575 :
 12576 :
 12577 :
 12578 :
 12579 :
 12580 :
 12581 :
 12582 :
 12583 :
 12584 :
 12585 :
 12586 :
 12587 :
 12588 :
 12589 :

TESTING RANDOM DATA

6849
 6850
 6851
 6852
 6853
 6854
 6855
 6856
 6857
 6858
 6859
 6860
 6861
 6862
 6863
 6864
 6865
 6866
 6867
 6868
 6869
 6870
 6871
 6872
 6873
 6874
 6875
 6876
 6877
 6878
 6879
 6880
 6881
 6882
 6883
 6884
 6885
 6886
 6887
 6888
 6889
 6890
 6891
 6892
 6893
 6894
 6895
 6896
 6897
 6898
 6899
 6900

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (44)

```

ERRDF (5101, MSG1, 0); !**** OPTION 5, RAND1 ERROR 01 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;

end; !* 6A *

[2] :
begin !* 6B * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
WHY DROPT [.LUN] = CODE_5;
ERRDF (5102, MSG1, 0); !**** OPTION 5, RAND1 ERROR 02 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end; !* 6B *

[3] :
begin !* 6C * FATAL DRIVE ERROR -- NO RETRY ALLOWED
ERRDF (5103, MSG1, 0); !**** OPTION 5, RAND1 ERROR 03 ****
WHY DROPT [.LUN] = CODE_6;
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end; !* 6C *

tes;

COMMAND = CHOOSE ();

if .COMMAND eql read
then
begin
PTR = .RPTR;
VALUE = read (.LUN, .WRDCNT, .RPTR, .SECTOR);
end
else
begin
PTR = .WPTR;
VALUE = CHECK (.LUN, .WRDCNT, .WPTR, .SECTOR);
end;

!+
!- SEE HOW SUCCESSFUL THE OPERATION WAS:

selectone .VALUE of !SEE 'SYSERR' FOR DEFINITION
set !OF ERROR # CONTAINED IN 'VALUE'

[0] :

if .COMMAND eql read
then
begin

if (DBL_VALUE = DOUBLE_CHECK (.WPTR, .RPTR, .WRDCNT)) neq 0
    
```

12591 :MLX4
 12592 :
 12593 :
 12594 : 5901
 12595 : 6702
 12596 : 6903
 12597 : 6904
 12598 : 6905
 12599 : 6906
 12600 : 6907
 12601 : 6908
 12602 : 6909
 12603 : 6910
 12604 : 6911
 12605 : 6912
 12606 : 6913
 12607 : 6914
 12608 : 6915
 12609 : 6916
 12610 : 6917
 12611 : 6918
 12612 : 6919
 12613 : 6920
 12614 : 6921
 12615 : 6922
 12616 : 6923
 12617 : 6924
 12618 : 6925
 12619 : 6926
 12620 : 6927
 12621 : 6928
 12622 : 6929
 12623 : 6930
 12624 : 6931
 12625 : 6932
 12626 : 6933
 12627 : 6934
 12628 : 6935
 12629 : 6936
 12630 : 6937
 12631 : 6938
 12632 : 6939
 12633 : 6940
 12634 : 6941
 12635 : 6942
 12636 : 6943
 12637 : 6944
 12638 : 6945
 12639 : 6946
 12640 : 6947
 12641 : 6948
 12642 : 6949
 12643 : 6950
 12644 : 6951
 12645 : 6952

TESTING RANDOM DATA

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (44)

```

then
begin
  SAYWHO (.LUN);
  PRINTB (SAY1, MSG5);
  PRINTB (FMT12A, .DBL_VALUE, .DBL_VALUE);
  !'ECC LOGIC FAILED TO DETECT DATA ERROR'
  !'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
  DBL_VALUE = .DBL_VALUE + BUFSIZ*2;
  PRINTB (FMT12B, .DBL_VALUE, .DBL_VALUE);
  !'BAD DATA: PPPPPP AT LOCATION QQQQQQ'
  WHY_DROPT [.LUN] = CODE_8;
  ERRDF (5104, MSG1, 0); !**** OPTION 5, RAND1 ERROR 04 ****
  DODU (.LUN);
  leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;

end;

[1] :
begin
  !* 6D * RETRY ALLOWED
  if RETRY (SIX, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) neq 0
  then
  !THE RETRY FAILED -- SYSTEM FATAL ERROR
  begin
  WHY_DROPT [.LUN] = CODE_4;
  ERRDF (5105, MSG1, 0); !**** OPTION 5, RAND1 ERROR 05 ****
  DODU (.LUN);
  leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
  end;
end;
!* 6D *

[2] :
begin
  !* 6E * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
  WHY_DROPT [.LUN] = CODE_5;
  ERRDF (5106, MSG1, 0); !**** OPTION 5, RAND1 ERROR 06 ****
  DODU (.LUN);
  leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;
!* 6E *

[3] :
begin
  !* 6F * FATAL DRIVE ERROR -- NO RETRY ALLOWED
  ERRDF (5107, MSG1, 0); !**** OPTION 5, RAND1 ERROR 07 ****
  WHY_DROPT [.LUN] = CODE_6;
  DODU (.LUN);
  leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;
!* 6F *

[4] :
begin
  !* 6G * UNRECOVERABLE DATA ERROR
  ISOLATE ();
  ERRDF (5108, MSG2, 0); !**** OPTION 5, RAND1 ERROR 08 ****
  WHY_DROPT [.LUN] = CODE_7;

```

12647 :MLX4
 12648 :
 12649 :
 12650 :
 12651 :
 12652 :
 12653 :
 12654 :
 12655 :
 12656 :
 12657 :
 12658 :
 12659 :
 12660 :
 12661 :
 12662 :
 12663 :
 12664 :
 12665 :
 12666 :
 12667 :
 12668 :
 12669 :
 12670 :
 12671 :
 12672 :
 12673 :
 12674 :
 12675 :
 12676 :
 12677 :
 12678 :
 12679 :
 12680 :
 12681 :
 12682 :
 12683 :
 12684 :
 12685 :
 12686 :
 12687 :
 12688 :
 12689 :
 12690 :
 12691 :
 12692 :
 12693 :
 12694 :
 12695 :
 12696 :
 12697 :
 12698 :
 12699 :
 12700 :
 12701 :

TESTING RANDOM DATA

6953
 6954
 6955
 6956
 6957
 6958
 6959
 6960
 6961
 6962
 6963
 6964
 6965
 6966
 6967
 6968
 6969
 6970
 6971
 6972
 6973
 6974
 6975
 6976
 6977
 6978
 6979
 6980
 6981
 6982
 6983
 6984
 6985
 6986
 6987
 6988
 6989
 6990
 6991
 6992
 6993
 6994
 6995
 6996
 6997
 6998
 6999
 7000
 7001
 7002
 7003
 7004

```

DODU (.LUN);
leave LOOP;
end;
!* JUMP JUST BEYOND END OF BLOCK * 4 *
!* 6G *

[5] :
begin
ISOLATE ();
!* 6H * RECOVERABLE DATA ERROR

if .ERROUT then PRINTB (FMT10B, .CHAN);

!' BIT QQ'
OLDSEC = .MLEL;
OLDCHN = .CHAN;

if RETRY (ONE, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) eql 5
then
  if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
  then
    begin
      if .ERROUT then ERRHRD (5109, MSG4, 0);

      !**** OPTION 5, RAND1 ERROR 09 ****
      UP_HARD_COUNT (.LUN, .BOARD);
    end
  else
    begin
      if .ERROUT then ERRSOFT (5110, MSG3, 0);

      !**** OPTION 5, RAND1 ERROR 10 ****
      UP_SOFT_COUNT (.LUN, .BOARD);
    end
  else
    begin
      if .ERROUT then ERRSOFT (5111, MSG3, 0);

      !**** OPTION 5, RAND1 ERROR 11 ****
      UP_SOFT_COUNT (.LUN, .BOARD);
    end
  end;
end;
!* 6H *
tes;

WPTR = .WPTR + (.WRDCNT*2);
SECTOR = .SECTOR + (.WRDCNT/256);
end;
!* 6 * END OF SECTOR SELECTION LOOP

end;
!* 5 * END OF TEST FOR AN ACTIVE UNIT
  
```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (44)

12703 :MLX4
 12704 :
 12705 :
 12706 :
 12707 :
 12708 :
 12709 :
 12710 :
 12711 :
 12712 :
 12713 :
 12714 :
 12715 :
 12716 :
 12717 :
 12718 :
 12719 :
 12720 :
 12721 :
 12722 :
 12723 :
 12724 :
 12725 :
 12726 :
 12727 :
 12728 :
 12729 :
 12730 :
 12731 :
 12732 :
 12733 :
 12734 :
 12735 :
 12736 :
 12737 :
 12738 :
 12739 :
 12740 :
 12741 :
 12742 :
 12743 :
 12744 :
 12745 :
 12746 :
 12747 :
 12748 :
 12749 :
 12750 :
 12751 :
 12752 :
 12753 :
 12754 :
 12755 :
 12756 :
 12757 :

TESTING RANDOM DATA

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (44)

7005
 7006
 7007
 7008
 7009
 7010
 7011
 7012
 7013
 7014
 7015
 7016
 7017
 7018
 7019
 7020
 7021
 7022
 7023
 7024
 7025
 7026
 7027
 7028
 7029
 7030
 7031
 7032
 7033
 7034
 7035
 7036
 7037
 7038
 7039
 7040
 7041
 7042
 7043
 7044
 7045
 7046
 7047
 7048
 7049
 7050
 7051
 7052
 7053
 7054
 7055
 7056

```

  Test to see if this uut's address space is
  to be read for soft errors. This test is
  is intended for DMT purposes.

  if .EFNS21
  then
    begin
      !Is the background pattern to be read

      ! version czmlbb changed incr to incru
      incru SECTOR from LOWEST to HIGHEST do
        if read (.LUN, 256, RBUFF, .SECTOR) eql 5
        then
          begin
            ISOLATE ();
            !Find the failing bank and board no.
            if .ERROUT then PRINTB (FMT10B, .CHAN);
            ! Print where the error is
            ! Save the contents of the ML error location
            ! register so we can compare it to the new
            ! contents of this register after the retry.
            ! This is done to classify the error.
            OLDSEC = .MLEL;
            OLDCHN = .CHAN;
            ! Do a classify retry call. If the same error
            ! occurs then classify it as a hard error. If
            ! a different error occurred or the error went away
            ! then classify it as a soft error.

            if RETRY (ONE, .COMMAND, .LUN, 256, .PTR, .OLDSEC) eql 5
            then
              ! The same error occurred so see if it is at the same
              ! sector and channel number, if so then classify
              ! it as a hard error else classiy it as a soft
              ! error.

              if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
              then
                begin
                  !Same error occurred 'hard'

```

```

12759 :MLX4
12760 :
12761 : TESTING RANDOM DATA
12762 : 7057
12763 : 7058
12764 : 7059
12765 : P 7060
12766 : P 7061
12767 : 7062
12768 : 7063
12769 : 7064
12770 : 7065
12771 : 7066
12772 : 7067
12773 : 7068
12774 : 7069
12775 : 7070
12776 : 7071
12777 : 7072
12778 : P 7073
12779 : P 7074
12780 : 7075
12781 : 7076
12782 : 7077
12783 : 7078
12784 : 7079
12785 : 7080
12786 : 7081
12787 : 7082
12788 : 7083
12789 : 7084
12790 : 7085
12791 : 7086
12792 : P 7087
12793 : P 7088
12794 : 7089
12795 : 7090
12796 : 7091
12797 : 7092
12798 : 7093
12799 : 7094
12800 : 7095
12801 : 7096
12802 : 7097
12803 : 7098
12804 : 7099
12805 : 7100
12806 : 7101
12807 : 7102
12808 : 7103
12809 : 7104
12810 : 7105
  
```

```

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (44)

if .ERROUT !Print error if enabled
then
  begin
  ERRHRD (5112, !Error number
    MSG4, !Error message
    0); !Additional message routine
  end;

  UP_HARD_COUNT (.LUN, .BOARD);
end
else
  begin !Not the same error 'soft'
  if .ERROUT !Print error if enabled
  then
    begin
    ERRSOFT (5113, !Error number
      MSG3, !Error message
      0); !Additional message routine
    end;

    UP_SOFT_COUNT (.LUN, .BOARD);
  end
  else
    begin !Not the same error 'soft'
    if .ERROUT !Print error if enabled
    then
      begin
      ERRSOFT (5114, !Error number
        MSG3, !Error message
        0); !Additional message routine
      end;

      UP_SOFT_COUNT (.LUN, .BOARD);
    end;
  end;
end;

end;
end;
end;
return;
end;

!* 4 * END OF LOOP THAT COMPLETELY TESTS 1 UNIT
!* 3 * END OF LOGICAL UNIT SELECTION LOOP
!* 2 * END OF REPEAT LOOP FOR THIS ROUTINE
!* 1 * END OF ROUTINE
  
```

Address	OpCode	Op1	Op2	Op3	Op4	Comments	Time	Page
12815								
12816								
12817								
12818								
12819								
12823	070540	004167	114570					
12824	070544	162706	000020					6746
12825	070550	012746	007664					
12826	070554	012746	007072					6809
12827	070560	012746	000002					
12828	070564	010600						
12829	070566	104414						
12830	070570	005066	000024					
12831	070574	000167	002276					6812
12832	070600	004767	151014					
12833	070604	016766	111202	000010				6814
12834	070612	005066	000006					6816
12835	070616	000167	002240					
12836	070622	016600	000006					
12837	070626	006200						6821
12838	070630	006200						
12839	070632	006200						
12840	070634	062700	034442					
12841	070640	010046						
12842	070642	016646	000010					
12843	070646	042716	177770					
12844	070652	012746	000001					
12845	070656	005046						
12846	070660	004767	113472					
12847	070664	062706	000010					
12848	070670	005300						
12849	070672	001402						
12850	070674	000167	001502					
12851	070700	016667	000006	111166				
12852	070706	012767	012670	141754				
12853	070714	012767	022670	141750				6824
12854	070722	016605	000006					6825
12855	070726	006305						6826
12856	070730	016503	034460					6827
12857	070734	020365	034500					
12858	070740	101355						
12859	070742	010346						6829
12860	070744	016546	034500					6831
12861	070750	004767	156222					
12862	070754	010002						
12863	070756	010216						
12864	070760	004767	156146					6832
12865	070764	016616	000012					
12866	070770	010246						
12867	070772	016746	141672					6833
12868	070776	010346						
12869	071000	004767	154420					
12870								
12871								
12872								
12873	071004	010004						
12874	071006	020427	000001					6839

12875	071012	001035		BNE	6\$			
12876	071014	012746	000006	MOV	#6,-(SP)	:		
12877	071020	012746	045424	MOV	#WRITE,-(SP)	:		6845
12878	071024	016646	000024	MOV	24(SP),-(SP)	:	LUN,*	
12879	071030	010246		MOV	R2,-(SP)	:	WRDCNT,*	
12880	071032	016746	141632	MOV	WPTR,-(SP)	:	SECTOR,*	
12881	071036	010346		MOV	R3,-(SP)	:		
12882	071040	004767	155160	JSR	PC,RETRY	:		
12883	071044	062706	000014	ADD	#14,SP	:		
12884	071050	005700		TST	R0	:		
12885	071052	001456		BEQ	9\$:		
12886	071054	016601	000020	MOV	20(SP),R1	:	LUN,*	
12887	071060	112761	000004	MOVB	#4,WHY.DROPT(R1)	:		6848
12888	071066	104455		TRAP	55	:		
12889	071070	011755		.WORD	11755	:		6849
12890	071072	011070		.WORD	MSG1	:		
12891	071074	000000		.WORD	0	:		
12892	071076	016600	000020	MOV	20(SP),R0	:	LUN,*	
12893	071102	104451		TRAP	51	:		6850
12894	071104	000436		BR	8\$:		
12895	071106	020427	000002	CMP	R4,#2	:	VALUE,*	6851
12896	071112	001015		BNE	7\$:		6839
12897	071114	016601	000020	MOV	20(SP),R1	:	LUN,*	
12898	071120	112761	000005	MOVB	#5,WHY.DROPT(R1)	:		6858
12899	071126	104455		TRAP	55	:		
12900	071130	011756		.WORD	11756	:		6859
12901	071132	011070		.WORD	MSG1	:		
12902	071134	000000		.WORD	0	:		
12903	071136	016600	000020	MOV	20(SP),R0	:	LUN,*	
12904	071142	104451		TRAP	51	:		6860
12905	071144	000416		BR	8\$:		
12906	071146	020427	000003	CMP	R4,#3	:	VALUE,*	6861
12907	071152	001016		BNE	9\$:		6839
12908	071154	104455		TRAP	55	:		
12909	071156	011757		.WORD	11757	:		6866
12910	071160	011070		.WORD	MSG1	:		
12911	071162	000000		.WORD	0	:		
12912	071164	016601	000020	MOV	20(SP),R1	:	LUN,*	
12913	071170	112761	000006	MOVB	#6,WHY.DROPT(R1)	:		6867
12914	071176	010100		MOV	R1,R0	:	LUN,*	
12915	071200	104451		TRAP	51	:		6868
12916	071202	062706	000012	ADD	#12,SP	:		
12917	071206	000543		BR	14\$:		6869
12918	071210	004767	154752	JSR	PC,CHOOSE	:		
12919	071214	010066	000034	MOV	R0,34(SP)	:	*,COMMAND	6873
12920	071220	005001		CLR	R1	:		
12921	071222	020027	045612	CMP	R0,#READ	:	COMMAND,*	6875
12922	071226	001015		BNE	10\$:		
12923	071230	005201		INC	R1	:		
12924	071232	016766	141434	MOV	RPTR,32(SP)	:	*,PTR	
12925								6878
12926								TOPS
12927								PA:<
					TESTING RANDOM DATA			27-Mar-1982 19:24:42
								27-Mar-1982 19:23:44
12928	071240	016646	000020	MOV	20(SP),-(SP)	:	LUN,*	
12929	071244	010246		MOV	R2,-(SP)	:	WRDCNT,*	6879
12930	071246	016746	141420	MOV	RPTR,-(SP)	:		
12931	071252	010346		MOV	R3,-(SP)	:	SECTOR,*	

;MLX4
;

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

Address	OpCode	Operand 1	Operand 2	Label	Comment	Value
12932	JSR	PC,READ	154332			
12933	BR	11\$				
12934	MOV	WPT?,32(SP)	141402	000032	10\$:	
12935	MOV	20(SP),-(SP)	000020			6883
12936	MOV	R2, -(SP)				6884
12937	MOV	WPTR, -(SP)	141366			
12938	MOV	R3, -(SP)				
12939	JSR	PC,CHECK	154470			
12940	MOV	RO,R4			11\$:	
12941	BNE	15\$				
12942	ROR	R1				6891
12943	BLO	13\$				6896
12944	JMP	28\$	001014		12\$:	
12945	MOV	WPTR, -(SP)	141340		13\$:	
12946	MOV	RPTR, -(SP)	141336			6900
12947	MOV	R2, -(SP)				
12948	JSR	PC,DOUBLE.CHECK	152764			
12949	ADD	#6,SP	000006			
12950	MOV	RO,36(SP)	000036			
12951	BEQ	12\$				
12952	MOV	30(SP),-(SP)	000030			
12953	JSR	PC,SAYWHO	144140			6903
12954	MOV	#MSG5,(SP)	011216			
12955	MOV	#SAY1, -(SP)	007072			6904
12956	MOV	#2, -(SP)	000002			
12957	MOV	SP,RO				
12958	TRAP	14				
12959	MOV	44(SP),(SP)	000044			
12960	MOV	@44(SP),-(SP)	000044			6905
12961	MOV	#FMT12A, -(SP)	006710			
12962	MOV	#3, -(SP)	000003			
12963	MOV	SP,RO				
12964	TRAP	14				
12965	ADD	#10000,52(SP)	010000	000052		
12966	MOV	52(SP),(SP)	000052			6907
12967	MOV	@52(SP),-(SP)	000052			6908
12968	MOV	#FMT12B, -(SP)	006756			
12969	MOV	#3, -(SP)	000003			
12970	MOV	SP,RO				
12971	TRAP	14				
12972	MOV	52(SP),R1	000052			
12973	MOVB	#10,WHY.DROPT(R1)	000010	034446		6910
12974	TRAP	55				
12975	.WORD	11760				6911
12976	.WORD	MSG1				
12977	.WORD	0				
12978	MOV	52(SP),RO	000052			
12979	TRAP	51				6912
12980						
12981						
12982						
12983	ADD	#44,SP	000044			
12984	BR	20\$				6913
12985	CMP	R4,#1	000001			
12986	BNE	16\$				6891
12987	MOV	#6, -(SP)	000006			
12988	MOV	46(SP),-(SP)	000046			6921

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

12989	071536	016646	000034		MOV	34(SP),-(SP)				
12990	071542	010246			MOV	R2, -(SP)	:	LUN,*		
12991	071544	016646	000052		MOV	52(SP),-(SP)	:	WRDCNT,*		
12992	071550	010346			MOV	R3, -(SP)	:	PTR,*		
12993	071552	004767	154446		JSR	PC,RETRY	:	SECTOR,*		
12994	071556	062706	000014		ADD	#14,SP				
12995	071562	005700			TST	R0				
12996	071564	001655			BEQ	12\$				
12997	071566	016601	000030		MOV	30(SP),R1	:	LUN,*		
12998	071572	112761	000004	034446	MOVB	#4,WHY.DROPT(R1)	:			6924
12999	071600	104455			TRAP	55	:			
13000	071602	011761			.WORD	11761	:			6925
13001	071604	011070			.WORD	MSG1				
13002	071606	000000			.WORD	0				
13003	071610	016600	000030		MOV	30(SP),R0	:	LUN,*		
13004	071614	104451			TRAP	51	:			6926
13005	071616	000457			BR	19\$:			
13006	071620	020427	000002	16\$:	CMP	R4,#2	:	VALUE,*		6927
13007	071624	001015			BNE	17\$:			6891
13008	071626	016601	000030		MOV	30(SP),R1	:	LUN,*		
13009	071632	112761	000005	034446	MOVB	#5,WHY.DROPT(R1)	:			6934
13010	071640	104455			TRAP	55	:			
13011	071642	011762			.WORD	11762	:			6935
13012	071644	011070			.WORD	MSG1				
13013	071646	000000			.WORD	0				
13014	071650	016600	000030		MOV	30(SP),R0	:	LUN,*		
13015	071654	104451			TRAP	51	:			6936
13016	071656	000437			BR	19\$:			
13017	071660	020427	000003	17\$:	CMP	R4,#3	:	VALUE,*		6937
13018	071664	001014			BNE	18\$:			6891
13019	071666	104455			TRAP	55	:			
13020	071670	011763			.WORD	11763	:			6942
13021	071672	011070			.WORD	MSG1				
13022	071674	000000			.WORD	0				
13023	071676	016601	000030		MOV	30(SP),R1	:	LUN,*		
13024	071702	112761	000006	034446	MOVB	#6,WHY.DROPT(R1)	:			6943
13025	071710	010100			MOV	R1,R0	:	LUN,*		
13026	071712	104451			TRAP	51	:			6944
13027	071714	000420			BR	19\$:			
13028	071716	020427	000004	18\$:	CMP	R4,#4	:	VALUE,*		6945
13029	071722	001021			BNE	21\$:			6891
13030	071724	004767	145402		JSR	PC,ISOLATE	:			
13031	071730	104455			TRAP	55	:			6950
13032	071732	011764			.WORD	11764	:			6951
13033	071734	011120			.WORD	MSG2				
13034	071736	000000			.WORD	0				
13035										
13036				:MLX4						
13037				:						
						TESTING RANDOM DATA			27-Mar-1982 19:24:42	TOPS
									27-Mar-1982 19:23:44	PA:<
13038	071740	016601	000030		MOV	30(SP),R1	:	LUN,*		
13039	071744	112761	000007	034446	MOVB	#7,WHY.DROPT(R1)	:			6952
13040	071752	010100			MOV	R1,R0	:	LUN,*		
13041	071754	104451			TRAP	51	:			6953
13042	071756	062706	000022	19\$:	ADD	#22,SP	:			
13043	071762	000167	001070	20\$:	JMP	40\$:			6954
13044	071766	020427	000005	21\$:	CMP	R4,#5	:	VALUE,*		
13045	071772	001162			BNE	28\$:			6891

13046	071774	004767	145332		JSR	PC,ISOLATE			
13047	072000	032767	000001	110252	BIT	#1,ERROUT	:		6959
13048	072006	001423			BEQ	22\$:		6961
13049	072010	017701	142374		MOV	@ML.REG+42,R1			
13050	072014	006201			ASR	R1			
13051	072016	006201			ASR	R1			
13052	072020	006201			ASR	R1			
13053	072022	006201			ASR	R1			
13054	072024	006201			ASR	R1			
13055	072026	006201			ASR	R1			
13056	072030	042701	177700		BIC	#177700,R1			
13057	072034	010146			MOV	R1,-(SP)			
13058	072036	012746	006640		MOV	#FMT10B,-(SP)			
13059	072042	012746	000002		MOV	#2,-(SP)			
13060	072046	010600			MOV	SP,R0			
13061	072050	104414			TRAP	14	:	SP,*	
13062	072052	062706	000006		ADD	#6,SP			
13063	072056	017766	142330	000040	MOV	@ML.REG+44,40(SP)	:	*,OLDSEC	
13064	072064	017701	142320		MOV	@ML.REG+42,R1	:		6964
13065	072070	006201			ASR	R1	:		6965
13066	072072	006201			ASR	R1			
13067	072074	006201			ASR	R1			
13068	072076	006201			ASR	R1			
13069	072100	006201			ASR	R1			
13070	072102	006201			ASR	R1			
13071	072104	042701	177700		BIC	#177700,R1			
13072	072110	010166	000034		MOV	R1,34(SP)			
13073	072114	012746	000001		MOV	#1,-(SP)	:	*,OLDCHN	
13074	072120	016646	000046		MOV	46(SP),-(SP)	:		6967
13075	072124	016646	000034		MOV	34(SP),-(SP)	:	COMMAND,*	
13076	072130	010246			MOV	R2,-(SP)	:	LUN,*	
13077	072132	016646	000052		MOV	52(SP),-(SP)	:	WRDCNT,*	
13078	072136	010346			MOV	R3,-(SP)	:	PTR,*	
13079	072140	004767	154060		JSR	PC,RETRY	:	SECTOR,*	
13080	072144	062706	000014		ADD	#14,SP			
13081	072150	020027	000005		CMP	R0,#5			
13082	072154	001052			BNE	25\$			
13083	072156	027766	142230	000040	CMP	@ML.REG+44,40(SP)	:	*,OLDSEC	6970
13084	072164	001035			BNE	24\$			
13085	072166	016600	000034		MOV	34(SP),R0	:	OLDCHN,*	
13086	072172	017701	142212		MOV	@ML.REG+42,R1			
13087	072176	006201			ASR	R1			
13088	072200	006201			ASR	R1			
13089	072202	006201			ASR	R1			
13090									
13091									
13092									
13093	072204	006201			ASR	R1			
13094	072206	006201			ASR	R1			
13095	072210	006201			ASR	R1			
13096	072212	042701	177700		BIC	#177700,R1			
13097	072216	020100			CMP	R1,R0			
13098	072220	001017			BNE	24\$			
13099	072222	032767	000001	110030	BIT	#1,ERROUT	:		
13100	072230	001404			BEQ	23\$			6974
13101	072232	104456			TRAP	56			
13102	072234	011765			.WORD	11765			

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

13103	072236	011202				.WORD	MSG4				
13104	072240	000000				.WORD	0				
13105	072242	016646	000030		23\$:	MOV	30(SP),-(SP)	:	LUN,*		6977
13106	072246	016746	142070			MOV	BOARD, -(SP)	:			
13107	072252	004767	145144			JSR	PC,UP.HARD.COUNT	:			
13108	072256	000427				BR	27\$:			
13109	072260	032767	000001	107772	24\$:	BIT	#1,ERROUT	:			6970
13110	072266	001415				BEQ	26\$:			6982
13111	072270	104457				TRAP	57	:			
13112	072272	011766				.WORD	11766	:			
13113	072274	011166				.WORD	MSG3	:			
13114	072276	000000				.WORD	0	:			
13115	072300	000410				BR	26\$:			
13116	072302	032767	000001	107750	25\$:	BIT	#1,ERROUT	:			6985
13117	072310	001404				BEQ	26\$:			6971
13118	072312	104457				TRAP	57	:			
13119	072314	011767				.WORD	11767	:			
13120	072316	011166				.WORD	MSG3	:			
13121	072320	C00000				.WORD	0	:			
13122	072322	016646	000030		26\$:	MOV	30(SP),-(SP)	:	LUN,*		6994
13123	072326	016746	142010			MOV	BOARD, -(SP)	:			
13124	072332	004767	145546			JSR	PC,UP.SOFT.COUNT	:			
13125	072336	022626			27\$:	CMP	(SP)+,(SP)+	:			
13126	072340	010200			28\$:	MOV	R2,R0	:	WRDCNT,*		6958
13127	072342	006300				ASL	R0	:			7000
13128	072344	066700	140320			ADD	WPTR,R0	:			
13129	072350	010067	140314			MOV	R0,WPTR	:			
13130	072354	010216				MOV	R2,(SP)	:	WRDCNT,*		
13131	072356	012746	000400			MOV	#400, -(SP)	:			7001
13132	072362	004767	112602			JSR	PC,BLSDIV	:			
13133	072366	060300				ADD	R3,R0	:	SECTOR,*		
13134	072370	010003				MOV	R0,R3	:	* ,SECTOR		
13135	072372	062706	000024			ADD	#24,SP	:			
13136	072376	000167	176332			JMP	5\$:			6830
13137	072402	032767	000001	107652	29\$:	BIT	#1,EFNS21	:			6829
13138	072410	001002				BNE	30\$:			7012
13139	072412	000167	000440			JMP	40\$:			
13140	072416	016600	000006		30\$:	MOV	6(SP),R0	:	LUN,*		7019
13141	072422	006300				ASL	R0	:			
13142	072424	016001	034500			MOV	TOP.SECT(R0),R1	:			
13143	072430	016005	034460			MOV	LOW.SECT(R0),R5	:	* ,SECTOR		
13144	072434	000167	000406			JMP	39\$:			
13145											
13146					:MLX4						
13147					:		TESTING RANDOM DATA			27-Mar-1982 19:24:42	TOPS
										27-Mar-1982 19:23:44	PA:<
13148	072440	016646	000006		31\$:	MOV	6(SP),-(SP)	:	LUN,*		7021
13149	072444	012746	000400			MOV	#400, -(SP)	:			
13150	072450	012746	022670			MOV	#RBUFF, -(SP)	:			
13151	072454	010546				MOV	R5, -(SP)	:	SECTOR,*		
13152	072456	004767	153130			JSR	PC,READ	:			
13153	072462	062706	000010			ADD	#10,SP	:			
13154	072466	020027	000005			CMP	R0,#5	:			
13155	072472	001164				BNE	38\$:			
13156	072474	004767	144632			JSR	PC,ISOLATE	:			7024
13157	072500	032767	000001	107552		BIT	#1,ERROUT	:			7026
13158	072506	001423				BEQ	32\$:			
13159	072510	017700	141674			MOV	@ML.REG+42,R0	:			

13160	072514	006200			ASR	R0			
13161	072516	006200			ASR	R0			
13162	072520	006200			ASR	R0			
13163	072522	006200			ASR	R0			
13164	072524	006200			ASR	R0			
13165	072526	006200			ASR	R0			
13166	072530	042700	177700		BIC	#177700,R0			
13167	072534	010046			MOV	R0,-(SP)			
13168	072536	012746	006640		MOV	#FMT10B,-(SP)			
13169	072542	012746	000002		MOV	#2,-(SP)			
13170	072546	010600			MOV	SP,R0			
13171	072550	104414			TRAP	14		: SP,*	
13172	072552	062706	000006		ADD	#6,SP			
13173	072556	017766	141630	000016 32\$:	MOV	@ML.REG+44,16(SP)		: *,OLDSEC	7035
13174	072564	017700	141620		MOV	@ML.REG+42,R0		:	7036
13175	072570	006200			ASR	R0			
13176	072572	006200			ASR	R0			
13177	072574	006200			ASR	R0			
13178	072576	006200			ASR	R0			
13179	072600	006200			ASR	R0			
13180	072602	006200			ASR	R0			
13181	072604	042700	177700		BIC	#177700,R0			
13182	072610	010066	000012		MOV	R0,12(SP)		: *,OLDCHN	
13183	072614	012746	000001		MOV	#1,-(SP)		:	
13184	072620	016646	000024		MOV	24(SP),-(SP)		: COMMAND,*	7044
13185	072624	016646	000012		MOV	12(SP),-(SP)		: LUN,*	
13186	072630	012746	000400		MOV	#400,-(SP)			
13187	072634	016646	000030		MOV	30(SP),-(SP)		: PTR,*	
13188	072640	016646	000030		MOV	30(SP),-(SP)		: OLDSEC,*	
13189	072644	004767	153354		JSR	PC,RETRY			
13190	072650	062706	000014		ADD	#14,SP			
13191	072654	020027	000005		CMP	R0,#5			
13192	072660	001052			BNE	35\$			
13193	072662	027766	141524	000016	CMP	@ML.REG+44,16(SP)		: *,OLDSEC	7053
13194	072670	001035			BNE	34\$			
13195	072672	016646	000012		MOV	12(SP),-(SP)		: OLDCHN,*	
13196	072676	017700	141506		MOV	@ML.REG+42,R0			
13197	072702	006200			ASR	R0			
13198	072704	006200			ASR	R0			
13199	072706	006200			ASR	R0			
13200									
13201				:MLX4					
13202				:					
13203	072710	006200							
13204	072712	006200			ASR	R0			
13205	072714	006200			ASR	R0			
13206	072716	042700	177700		ASR	R0			
13207	072722	020026			BIC	#177700,R0			
13208	072724	001017			CMP	R0,(SP)+			
13209	072726	032767	000001 107324		BNE	34\$			
13210	072734	001404			BIT	#1,ERROUT		:	7057
13211	072736	104456			BEQ	33\$:	7062
13212	072740	011770			TRAP	56			
13213	072742	011202			.WORD	11770			
13214	072744	000000			.WORD	MSG4			
13215	072746	016646	000006	33\$:	.WORD	0			
13216	072752	016746	141364		MOV	6(SP),-(SP)		: LUN,*	7065
					MOV	BOARD,-(SP)			

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

13217	072756	004767	144440			JSR	PC,UP.HARD.COUNT		
13218	072762	000427				BR	37\$:	
13219	072764	032767	000001	107266	34\$:	BIT	#1,ERROUT	:	7053
13220	072772	001415				BEQ	36\$:	7070
13221	072774	104457				TRAP	57	:	
13222	072776	011771				.WORD	11771	:	7075
13223	073000	011166				.WORD	MSG3		
13224	073002	000000				.WORD	0		
13225	073004	000410				BR	36\$:	
13226	073006	032767	000001	107244	35\$:	BIT	#1,ERROUT	:	7078
13227	073014	001404				BEQ	36\$:	7084
13228	073016	104457				TRAP	57	:	
13229	073020	011772				.WORD	11772	:	7089
13230	073022	011166				.WORD	MSG3		
13231	073024	000000				.WORD	0		
13232	073026	016646	000006		36\$:	MOV	6(SP),-(SP)	:	
13233	073032	016746	141304			MOV	BOARD,-(SP)	:	LUN,*
13234	073036	004767	145042			JSR	PC,UP.SOFT.COUNT		
13235	073042	022626				CMP	(SP)+,(SP)+	:	
13236	073044	005205			37\$:	INC	R5	:	7023
13237	073046	020501			38\$:	CMP	R5,R1	:	SECTOR
13238	073050	101002			39\$:	BHI	40\$:	SECTOR,*
13239	073052	000167	177362			JMP	31\$		
13240	073056	005266	000006		40\$:	INC	6(SP)	:	LUN
13241	073062	026666	000006	000010	41\$:	CMP	6(SP),10(SP)	:	LUN,*
13242	073070	002002				BGE	42\$		
13243	073072	000167	175524			JMP	2\$		
13244	073076	005266	000024		42\$:	INC	24(SP)	:	COUNT
13245	073102	026666	000024	000044		CMP	24(SP),44(SP)	:	COUNT,REPEAT
13246	073110	003002				BGT	43\$		
13247	073112	000167	175462			JMP	1\$		
13248	073116	062706	000026		43\$:	ADD	#26,SP	:	
13249	073122	000207				RTS	PC	:	6746

: Routine Size: 634 words
 : Maximum stack depth per invocation: 35 words

13250
 13251
 13252
 13260
 13261

13263 :MLX4
 13264 :
 13265 :
 13266 :
 13267 :
 13268 :
 13269 :
 13270 :
 13271 :
 13272 :
 13273 :
 13274 :
 13275 :
 13276 :
 13277 :
 13278 :
 13279 :
 13280 :
 13281 :
 13282 :
 13283 :
 13284 :
 13285 :
 13286 :
 13287 :
 13288 :
 13289 :
 13290 :
 13291 :
 13292 :
 13293 :
 13294 :
 13295 :
 13296 :
 13297 :
 13298 :
 13299 :
 13300 :
 13301 :
 13302 :
 13303 :
 13304 :
 13305 :
 13306 :
 13307 :
 13308 :
 13309 :
 13310 :
 13311 :
 13312 :
 13313 :
 13314 :
 13315 :
 13316 :
 13317 :

TESTING RANDOM DATA & WORD COUNTS

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (45)

```
%sbttl 'TESTING RANDOM DATA & WORD COUNTS'
routine RAND2 (REPEAT) : novalue =
begin
```

!* 1 * START OF ROUTINE

```
++
ROUTINE:      RAND2(REPEAT)
PURPOSE:      TO TEST ALL UNITS IN A SEQUENTIAL FASHION, BUT
                USING RANDOM WORD COUNTS
ARGUMENT:      REPEAT = NUMBER OF TIMES TO EXECUTE THIS ROUTINE
                BEFORE RETURNING TO THE CALLER (OPT5).
NOTE:          SINCE ONLY THE WORD COUNTS AND THE DATA ARE RANDOM,
                THE OTHER TRANSFER VALUES MUST BE SET UP BY THIS
                ROUTINE. THESE VALUES INCLUDE:
                THE LUN, SECTOR AND BUFFER POINTERS.
```

THE CODE FOR 'RAND2' IN BRIEF:

```
BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COUNT FROM 1 TO REPEAT
: BEGIN 2 (START OF REPEAT LOOP FOR THE ROUTINE)
: INCR LUN FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : GENERATE THE RANDOM PATTERN
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : SECTOR = LOWEST
: : : : INITIALIZE THE WRITE AND READ BUFFER POINTERS
: : : : WHILE SECTOR LEQ HIGHEST DO
: : : : : BEGIN 6 (START OF A PASS THROUGH ALL SECTORS)
: : : : : CHOOSE A RANDOM WORD COUNT
: : : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : : CALCULATE NEXT STARTING SECTOR (BASED ON WORD COUNT)
: : : : : IF NEXT STARTING SECTOR GTR HIGHEST
: : : : : THEN ADJUST THE WORD COUNT & NEXT SECTOR SO THEY FIT
: : : : : : WITHIN THE TESTABLE SECTOR LIMITS
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : : SECTOR = THE CALCULATED NEXT STARTING SECTOR
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : END 6 (END OF A PASS THROUGH ALL SECTORS)
: : : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : : : END 4 (END TESTLOOP)
```

```

13319 :MLX4
13320 :
13321 :
13322 : 7158 : : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
13323 : 7159 : : END 2 (END OF REPEAT LOOP FOR THIS ROUTINE)
13324 : 7160 : RETURN
13325 : 7161 : END 1 (END OF ROUTINE)
13326 : 7162 :
13327 : 7163 :
13328 : 7164 : local
13329 : 7165 :     WRDCNT,
13330 : 7166 :     SECTOR,
13331 : 7167 :     NEXT_SECT,
13332 : 7168 :     VALUE,
13333 : 7169 :     OLDSEC,
13334 : 7170 :     OLDCHN,
13335 : 7171 :     PTR,
13336 : 7172 :     COMMAND,
13337 : 7173 :     DBL_VALUE;
13338 : 7174 :
13339 : 7175 : label
13340 : 7176 :     LOOP;
13341 : 7177 :
13342 : 7178 : PRINTB (SAY1, RTN5B);
13343 : 7179 : !'RAND2'
13344 : 7180 :
13345 : 7181 : incr COUNT from 1 to .REPEAT do
13346 : 7182 :     begin
13347 : 7183 :
13348 : 7184 :         incr LUN from 0 to (.LSUNIT - 1) do
13349 : 7185 :             begin
13350 : 7186 :                 GENS ();
13351 : 7187 :             LOOP :
13352 : 7188 :                 begin
13353 : 7189 :                     if .DRIVE_STATUS [.LUN] eql ACTIVE
13354 : 7190 :                         then
13355 : 7191 :                             begin
13356 : 7192 :                                 begin
13357 : 7193 :                                     L$LUN = .LUN;
13358 : 7194 :                                     SECTOR = LOWEST;
13359 : 7195 :                                     WPTR = WBUFF;
13360 : 7196 :                                     RPTR = RBUFF;
13361 : 7197 :
13362 : 7198 :                                     while .SECTOR leqa HIGHEST do
13363 : 7199 :                                         begin
13364 : 7200 :                                             WRDCNT = RNDWC ();
13365 : 7201 :                                             SET PTRS (.WRDCNT);
13366 : 7202 :                                             NEXT_SECT = .SECTOR + (.WRDCNT/256);
13367 : 7203 :
13368 : 7204 :                                             if .SECTOR eql .NEXT_SECT then NEXT_SECT = .NEXT_SECT + 1;
13369 : 7205 :
13370 : 7206 :                                             if .NEXT_SECT gtra HIGHEST
13371 : 7207 :                                                 then
13372 : 7208 :                                                     begin
13373 : 7209 :                                                         WRDCNT = 256*(HIGHEST - .SECTOR + 1);
  
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TJPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (45)

!* 2 * START OF REPEAT LOOP FOR THIS ROUTINE

!* 3 * START OF LOGICAL UNIT SELECTION LOOP
 !RANDOM DATA PATTERN

!* 4 * START OF THE LOOP FOR COMPLETELY TESTING 1 UNIT

!* 5 * START OF TEST FOR AN ACTIVE UNIT

!* 6 * START OF A PASS THROUGH ALL SECTORS
 !EXPECT VALUE BETWEEN 1 AND BUFSIZ

13375 :ML X4
 13376 :
 13377 :
 13378 : 7210
 13379 : 7211
 13380 : 7212
 13381 : 7213
 13382 : 7214
 13383 : 7215
 13384 : 7216
 13385 : 7217
 13386 : 7218
 13387 : 7219
 13388 : 7220
 13389 : 7221
 13390 : 7222
 13391 : 7223
 13392 : 7224
 13393 : 7225
 13394 : 7226
 13395 : 7227
 13396 : 7228
 13397 : 7229
 13398 : 7230
 13399 : 7231
 13400 : 7232
 13401 : 7233
 13402 : 7234
 13403 : 7235
 13404 : 7236
 13405 : 7237
 13406 : 7238
 13407 : 7239
 13408 : 7240
 13409 : 7241
 13410 : 7242
 13411 : 7243
 13412 : 7244
 13413 : 7245
 13414 : 7246
 13415 : 7247
 13416 : 7248
 13417 : 7249
 13418 : 7250
 13419 : 7251
 13420 : 7252
 13421 : 7253
 13422 : 7254
 13423 : 7255
 13424 : 7256
 13425 : 7257
 13426 : 7258
 13427 : 7259
 13428 : 7260
 13429 : 7261

TESTING RANDOM DATA & WORD COUNTS

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (45)

```

NEXT_SECT = HIGHEST + 1;
end;

VALUE = write (.LUN, .WRDCNT, .WPTR, .SECTOR);

!+
!- SEE HOW SUCCESSFUL THE WRITE WAS:

selectone .VALUE of
set
[1] :
begin
! * 6A * RETRY ALLOWED
if RETRY (SIX, write, .LUN, .WRDCNT, .WPTR, .SECTOR) neq 0
then
! THE RETRY FAILED -- SYSTEM FATAL ERROR
begin
WHY DROPT [.LUN] = CODE_4;
ERRDF (5201, MSG1, 0); !**** OPTION 5, RAND2 ERROR 01 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;
end;
! * 6A *

[2] :
begin
! * 6B * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
WHY DROPT [.LUN] = CODE_5;
ERRDF (5202, MSG1, 0); !**** OPTION 5, RAND2 ERROR 02 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;
! * 6B *

[3] :
begin
! * 6C * FATAL DRIVE ERROR -- NO RETRY ALLOWED
ERRDF (5203, MSG1, 0); !**** OPTION 5, RAND2 ERROR 03 ****
WHY DROPT [.LUN] = CODE_6;
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;
! * 6C *
tes;

COMMAND = CHOOSE ();

if .COMMAND eql read
then
begin
PTR = .RPTR;
VALUE = read (.LUN, .WRDCNT, .RPTR, .SECTOR);
end
else

```

13431 :MLX4
 13432 :
 13433 :
 13434 : 7262
 13435 : 7263
 13436 : 7264
 13437 : 7265
 13438 : 7266
 13439 : 7267
 13440 : 7268
 13441 : 7269
 13442 : 7270
 13443 : 7271
 13444 : 7272
 13445 : 7273
 13446 : 7274
 13447 : 7275
 13448 : 7276
 13449 : 7277
 13450 : 7278
 13451 : 7279
 13452 : 7280
 13453 : 7281
 13454 : 7282
 13455 : 7283
 13456 : 7284
 13457 : 7285
 13458 : 7286
 13459 : 7287
 13460 : 7288
 13461 : 7289
 13462 : 7290
 13463 : 7291
 13464 : 7292
 13465 : 7293
 13466 : 7294
 13467 : 7295
 13468 : 7296
 13469 : 7297
 13470 : 7298
 13471 : 7299
 13472 : 7300
 13473 : 7301
 13474 : 7302
 13475 : 7303
 13476 : 7304
 13477 : 7305
 13478 : 7306
 13479 : 7307
 13480 : 7308
 13481 : 7309
 13482 : 7310
 13483 : 7311
 13484 : 7312
 13485 : 7313

TESTING RANDOM DATA & WORD COUNTS

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (45)

```

begin
PTR = .WPTR;
VALUE = CHECK (.LUN, .WRDCNT, .WPTR, .SECTOR);
end;

!+
SEE HOW SUCCESSFUL THE OPERATION WAS:
!-

selectone .VALUE of
set
[0] :
if .COMMAND eql read
then
begin
if (DBL_VALUE = DOUBLE_CHECK (.WPTR, .RPTR, .WRDCNT)) neq 0
then
begin
SAYWHO (.LUN);
PRINTB (SAY1, MSG5);
PRINTB (FMT12A, .DBL_VALUE, .DBL_VALUE);
DBL_VALUE = .DBL_VALUE + BUFSIZ*2;
PRINTB (FMT12B, .DBL_VALUE, .DBL_VALUE);
WHY DROPT [.LUN] = CODE_8;
ERRDF (5204, MSG1, 0);
DODU (.LUN);
leave LOOP;
end;
end;

[1] :
begin
if RETRY (SIX, .COMMAND, .LUN, .WRDCNT, PTR, .SECTOR) neq 0
then
begin
WHY DROPT [.LUN] = CODE_4;
ERRDF (5205, MSG1, 0);
DODU (.LUN);
leave LOOP;
end;
end;

[2] :
begin

```

!SEE 'SYSERR' FOR DEFINITION
 !OF ERROR # CONTAINED IN 'VALUE'
 !'ECC LOGIC FAILED TO DETECT DATA ERROR'
 !'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
 !'BAD DATA: PPPPPP AT LOCATION QQQQQQ'
 !**** OPTION 5, RAND2 ERROR 04 ****
 !JUMP JUST BEYOND END OF BLOCK * 4 *
 !* 6D * RETRY ALLOWED
 !THE RETRY FAILED -- SYSTEM FATAL ERROR
 !**** OPTION 5, RAND2 ERROR 05 ****
 !JUMP JUST BEYOND END OF BLOCK * 4 *
 !* 6D *
 !* 6E * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED

13487 :MLX4
13488 :
13489 :
13490 :
13491 :
13492 :
13493 :
13494 :
13495 :
13496 :
13497 :
13498 :
13499 :
13500 :
13501 :
13502 :
13503 :
13504 :
13505 :
13506 :
13507 :
13508 :
13509 :
13510 :
13511 :
13512 :
13513 :
13514 :
13515 :
13516 :
13517 :
13518 :
13519 :
13520 :
13521 :
13522 :
13523 :
13524 :
13525 :
13526 :
13527 :
13528 :
13529 :
13530 :
13531 :
13532 :
13533 :
13534 :
13535 :
13536 :
13537 :
13538 :
13539 :
13540 :
13541 :

7314
7315
7316
7317
7318
7319
7320
7321
7322
7323
7324
7325
7326
7327
7328
7329
7330
7331
7332
7333
7334
7335
7336
7337
7338
7339
7340
7341
7342
7343
7344
7345
7346
7347
7348
7349
7350
7351
7352
7353
7354
7355
7356
7357
7358
7359
7360
7361
7362
7363
7364
7365

TESTING RANDOM DATA & WORD COUNTS

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (45)

```
WHY DROPT [.LUN] = CODE_5;  
ERRDF (5206, MSG1, 0); !**** OPTION 5, RAND2 ERROR 06 ****  
DODU (.LUN);  
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *  
end; !* 6E *  
[3] :  
begin !* 6F * FATAL DRIVE ERROR -- NO RETRY ALLOWED  
ERRDF (5207, MSG1, 0); !**** OPTION 5, RAND2 ERROR 07 ****  
WHY DROPT [.LUN] = CODE_6;  
DODU (.LUN);  
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *  
end; !* 6F *  
[4] :  
begin !* 6G * UNRECOVERABLE DATA ERROR  
ISOLATE ();  
ERRDF (5208, MSG2, 0); !**** OPTION 5, RAND2 ERROR 08 ****  
WHY DROPT [.LUN] = CODE_7;  
DODU (.LUN);  
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *  
end; !* 6G *  
[5] :  
begin !* 6H * RECOVERABLE DATA ERROR  
ISOLATE ();  
  
if .ERROUT then PRINTB (FMT10B, .CHAN);  
  
!' BIT QQ'  
OLDSEC = .MLEL;  
OLDCHN = .CHAN;  
  
if RETRY (ONE, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) eql 5  
then  
    if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))  
    then  
        begin  
            if .ERROUT then ERRHRD (5209, MSG4, 0);  
            !**** OPTION 5, RAND2 ERROR 09 ****  
            UP_HARD_COUNT (.LUN, .BOARD);  
        end  
    else  
        begin  
            if .ERROUT then ERRSOFT (5210, MSG3, 0);  
            !**** OPTION 5, RAND2 ERROR 10 ****  
            UP_SOFT_COUNT (.LUN, .BOARD);  
        end  
    end  
end
```

13543 :MLX4
 13544 :
 13545 :
 13546 :
 13547 :
 13548 :
 13549 :
 13550 :
 13551 :
 13552 :
 13553 :
 13554 :
 13555 :
 13556 :
 13557 :
 13558 :
 13559 :
 13560 :
 13561 :
 13562 :
 13563 :
 13564 :
 13565 :
 13566 :
 13567 :
 13568 :
 13569 :
 13570 :
 13571 :
 13572 :
 13573 :
 13574 :
 13575 :
 13576 :
 13577 :
 13578 :
 13579 :
 13580 :
 13581 :
 13582 :
 13583 :
 13584 :
 13585 :
 13586 :
 13587 :
 13588 :
 13589 :
 13590 :
 13591 :
 13592 :
 13593 :
 13594 :
 13595 :
 13596 :
 13597 :

TESTING RANDOM DATA & WORD COUNTS

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (45)

```

end
else
begin
if .ERROUT then ERRSOFT (5211, MSG3, 0);
UP_SOFT_COUNT (**** OPTION 5, RAND2 ERROR 11 ****
.LUN, .BOARD);
end;
end;
tes;
!* 6H *

SECTOR = .NEXT_SECT;
WPTR = .WPTR + 2;
end;
!* 6 * END OF A PASS THROUGH ALL SECTORS

end;
!* 5 * END OF TEST FOR AN ACTIVE UNIT

+
Test to see if this uut's address space is
to be read for soft errors. This test is
is intended for DMT purposes.
-

if .EFNS21
then
begin
!* Is the background pattern to be read

version czmlbb changed incr to incru
incru SECTOR from LOWEST to HIGHEST do
if read (.LUN, 256, RBUFF, .SECTOR) eql 5
then
begin
ISOLATE ();
!* Find the failing bank and board no.

if .ERROUT then PRINTB (FMT10B, .CHAN);

! Print where the error is

! Save the contents of the ML error location
! register so we can compare it to the new
! contents of this register after the retry.
! This is done to classify the error.

OLDSEC = .MLEL;
OLDCHN = .CHAN;

```

13599 :MLX4
 13600 :
 13601 :
 13602 :
 13603 :
 13604 :
 13605 :
 13606 :
 13607 :
 13608 :
 13609 :
 13610 :
 13611 :
 13612 :
 13613 :
 13614 :
 13615 :
 13616 :
 13617 :
 13618 :
 13619 :
 13620 :
 13621 :
 13622 :
 13623 :
 13624 : P
 13625 : P
 13626 :
 13627 :
 13628 :
 13629 :
 13630 :
 13631 :
 13632 :
 13633 :
 13634 :
 13635 :
 13636 :
 13637 : P
 13638 : P
 13639 :
 13640 :
 13641 :
 13642 :
 13643 :
 13644 :
 13645 :
 13646 :
 13647 :
 13648 :
 13649 :
 13650 :
 13651 : P
 13652 : P
 13653 :

TESTING RANDOM DATA & WORD COUNTS

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (45)

```

Do a classify retry call.  If the same error
occures then classify it as a hard error.  If
a different error occured or the error went away
then classify it as a soft error.

if RETRY (ONE, .COMMAND, .LUN, 256, .PTR, .OLDSEC) eql 5
then
The same error occured so see if it is at the same
sector and channel number, if so then classify
it as a hard error else classiy it as a soft
error.

if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
then
begin
!Same error occured 'hard'
if .ERROUT
!Print error if enabled
then
begin
ERRHRD (5212,
!Error number
MSG4,
!Error message
0);
!Additional message routine
end;
UP HARD_COUNT (.LUN, .BOARD);
end
else
begin
!Not the same error 'soft'
if .ERROUT
!Print error if enabled
then
begin
ERRSOFT (5213,
!Error number
MSG3,
!Error message
0);
!Additional message routine
end;
UP SOFT_COUNT (.LUN, .BOARD);
end
else
begin
!Not the same error 'soft'
if .ERROUT
!Print error if enabled
then
begin
ERRSOFT (5214,
!Error number
MSG3,
!Error message
0);
!Additional message routine
    
```

7418
 7419
 7420
 7421
 7422
 7423
 7424
 7425
 7426
 7427
 7428
 7429
 7430
 7431
 7432
 7433
 7434
 7435
 7436
 7437
 7438
 7439
 7440
 7441
 7442
 7443
 7444
 7445
 7446
 7447
 7448
 7449
 7450
 7451
 7452
 7453
 7454
 7455
 7456
 7457
 7458
 7459
 7460
 7461
 7462
 7463
 7464
 7465
 7466
 7467
 7468
 7469

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (45)

```

13655 :MLX4
13656 :
13657 :
13658 : 7470
13659 : 7471
13660 : 7472
13661 : 7473
13662 : 7474
13663 : 7475
13664 : 7476
13665 : 7477
13666 : 7478
13667 : 7479
13668 : 7480
13669 : 7481
13670 : 7482
13671 : 7483
13672 : 7484
13673 : 7485
13677 :
13678 :

        end;
        UP_SOFT_COUNT (.LUN, .BOARD);
        end;
        end;
        end;
        end;
        return;
        end;
    
```

```

!* 4 * END OF LOOP THAT COMPLETELY TESTS 1 UNIT
!* 3 * END OF LOGICAL UNIT SELECTION LOOP
!* 2 * END OF REPEAT LOOP FOR THIS ROUTINE
!* 1 * END OF ROUTINE
    
```

```

13682 073124 004167 112204
13683 073130 162706 000022
13684 073134 012746 007672
13685 073140 012746 007072
13686 073144 012746 000002
13687 073150 010600
13688 073152 104414
13689 073154 005066 000022
13690 073160 000167 002232
13691 073164 016766 106622 000026 1$:
13692 073172 005001
13693 073174 000167 002204
13694 073200 004767 146414 2$:
13695 073204 010100
13696 073206 006200
13697 073210 006200
13698 073212 006200
13699 073214 062700 034442
13700 073220 010046
13701 073222 010146
13702 073224 042716 177770
13703 073230 012746 000001
13704 073234 005046
13705 073236 004767 111114
13706 073242 062706 000010
13707 073246 005300
13708 073250 001402
13709 073252 000167 001460 3$:
    
```

```

.SBTTL RAND2 TESTING RANDOM DATA & WORD COUNTS
RAND2: JSR R1,$SAVE5
        SUB #22,SP
        MOV #RTN5B,-(SP)
        MOV #SAY1,-(SP)
        MOV #2,-(SP)
        MOV SP,R0
        TRAP 14
        CLR 22(SP)
        JMP 44$
        MOV LSUNIT,26(SP)
        CLR R1
        JMP 43$
        JSR PC,GEN5
        MOV R1,R0
        ASR R0
        ASR R0
        ASR R0
        ADD #DRIVE.STATUS,R0
        MOV R0,-(SP)
        MOV R1,-(SP)
        BIC #177770,(SP)
        MOV #1,-(SP)
        CLR -(SP)
        JSR PC,BLSGT2
        ADD #10,SP
        DEC R0
        BEQ 4$
        JMP 31$
    
```

7107
 7178
 7181
 7184
 7186
 7190

Address	Hex	Hex	Hex	Hex	Label	Op	Comments	Time	Page
13711					:MLX4				
13712					:				
13713					:		TESTING RANDOM DATA & WORD COUNTS	27-Mar-1982 19:24:42	TOPS
13714	073256	010167	106612		4\$:	MOV	R1,LSLUN		
13715	073262	010100				MOV	R1,R0	: LUN,*	7193
13716	073264	006300				ASL	R0	: LUN,*	7194
13717	073266	016003	034460			MOV	LOW.SECT(R0),R3	: *,SECTOR	
13718	073272	012767	012670	137370		MOV	#WBUF,WPTR	:	
13719	073300	012767	022670	137364		MOV	#RBUF,RPTR	:	7195
13720	073306	012766	034500	000024		MOV	#TOP.SECT,24(SP)	:	7196
13721	073314	060066	000024			ADD	R0,24(SP)	:	7198
13722	073320	020376	000024		5\$:	CMP	R3,@24(SP)	: SECTOR,*	
13723	073324	101352				BHI	3\$:	
13724	073326	004767	174652			JSR	PC,RNDWC	:	
13725	073332	010002				MOV	R0,R2	: *,WRDCNT	7200
13726	073334	010246				MOV	R2,-(SP)	: WRDCNT,*	
13727	073336	004767	153570			JSR	PC,SET.PTRS	:	7201
13728	073342	010216				MOV	R2,(SP)	: WRDCNT,*	
13729	073344	012746	000400			MOV	#400,-(SP)	:	7202
13730	073350	004767	111614			JSR	PC,BLSDIV	:	
13731	073354	060300				ADD	R3,R0	: SECTOR,*	
13732	073356	010066	000012			MOV	R0,12(SP)	: *,NEXT.SECT	
13733	073362	020300				CMP	R3,R0	: SECTOR,NEXT.SECT	
13734	073364	001002				BNE	6\$:	7204
13735	073366	005266	000012			INC	12(SP)	: NEXT.SECT	
13736	073372	026676	000012	000030	6\$:	CMP	12(SP),@30(SP)	: NEXT.SECT,*	
13737	073400	101415				BLOS	7\$:	7206
13738	073402	017600	000030			MOV	@30(SP),R0	:	
13739	073406	160300				SUB	R3,R0	: SECTOR,*	7209
13740	073410	000300				SWAB	R0	:	
13741	073412	105000				CLRB	R0	:	7208
13742	073414	010002				MOV	R0,R2	: *,WRDCNT	
13743	073416	062702	000400			ADD	#400,R2	: *,WRDCNT	7209
13744	073422	017666	000030	000012		MOV	@30(SP),12(SP)	: *,NEXT.SECT	
13745	073430	005266	000012			INC	12(SP)	: NEXT.SECT	7210
13746	073434	010116			7\$:	MOV	R1,(SP)	: LUN,*	
13747	073436	010246				MOV	R2,-(SP)	: WRDCNT,*	7213
13748	073440	016746	137224			MOV	WPTR,-(SP)	:	
13749	073444	010346				MOV	R3,-(SP)	: SECTOR,*	
13750	073446	004767	151752			JSR	PC,WRITE	:	
13751	073452	010004				MOV	R0,R4	: *,VALUE	
13752	073454	020427	000001			CMP	R4,#1	: VALUE,*	7219
13753	073460	001031				BNE	8\$:	
13754	073462	012746	000006			MOV	#6,-(SP)	:	7225
13755	073466	012746	045424			MOV	#WRITE,-(SP)	:	
13756	073472	010146				MOV	R1,-(SP)	: LUN,*	
13757	073474	010246				MOV	R2,-(SP)	: WRDCNT,*	
13758	073476	016746	137166			MOV	WPTR,-(SP)	:	
13759	073502	010346				MOV	R3,-(SP)	: SECTOR,*	
13760	073504	004767	152514			JSR	PC,RETRY	:	
13761	073510	062706	000014			ADD	#14,SP	:	
13762	073514	005700				TST	R0	:	
13763	073516	001446				BEQ	11\$:	
13764	073520	112761	000004	034446		MOVB	#4,WHY.DROPT(R1)	: *,*(LUN)	7228
13765	073526	104455				TRAP	55	:	7229

Address	OpCode	Operand 1	Operand 2	Label	Instruction	Comments	Address
13767							
13768							
13769							
13770	073530	012121			.WORD	12121	
13771	073532	011070			.WORD	MSG1	
13772	073534	000000			.WORD	0	
13773	073536	010100			MOV	R1,R0	
13774	073540	104451			TRAP	51	: LUN,*
13775	073542	000431			BR	10\$	
13776	073544	020427	000002	8\$:	CMP	R4,#2	: VALUE,*
13777	073550	001012			BNE	9\$	
13778	073552	112761	000005	034446	MOVB	#5,WHY.DROPT(R1)	: *,*(LUN)
13779	073560	104455			TRAP	55	
13780	073562	012122			.WORD	12122	
13781	073564	011070			.WORD	MSG1	
13782	073566	000000			.WORD	0	
13783	073570	010100			MOV	R1,R0	
13784	073572	104451			TRAP	51	: LUN,*
13785	073574	000414			BR	10\$	
13786	073576	020427	000003	9\$:	CMP	R4,#3	: VALUE,*
13787	073602	001014			BNE	11\$	
13788	073604	104455			TRAP	55	
13789	073606	012123			.WORD	12123	
13790	073610	011070			.WORD	MSG1	
13791	073612	000000			.WORD	0	
13792	073614	112761	000006	034446	MOVB	#6,WHY.DROPT(R1)	: *,*(LUN)
13793	073622	010100			MOV	R1,R0	: LUN,*
13794	073624	104451			TRAP	51	
13795	073626	062706	000012	10\$:	ADD	#12,SP	
13796	073632	000535			BR	16\$	
13797	073634	004767	152326	11\$:	JSR	PC,CHOOSE	
13798	073640	010066	000022		MOV	R0,22(SP)	: *,COMMAND
13799	073644	005005			CLR	R5	
13800	073646	020027	045612		CMP	R0,#READ	: COMMAND,*
13801	073652	001014			BNE	12\$	
13802	073654	005205			INC	R5	
13803	073656	016766	137010	000024	MOV	RPTR,24(SP)	: *,PTR
13804	073664	010146			MOV	R1,-(SP)	: LUN,*
13805	073666	010246			MOV	R2,-(SP)	: WRDCNT,*
13806	073670	016746	136776		MOV	RPTR,-(SP)	
13807	073674	010346			MOV	R3,-(SP)	: SECTOR,*
13808	073676	004767	151710		JSR	PC,READ	
13809	073702	000412			BR	13\$	
13810	073704	016766	136760	000024	12\$:	MOV	WPTR,24(SP)
13811	073712	010146			MOV	R1,-(SP)	: *,PTR
13812	073714	010246			MOV	R2,-(SP)	: LUN,*
13813	073716	016746	136746		MOV	WPTR,-(SP)	: WRDCNT,*
13814	073722	010346			MOV	R3,-(SP)	
13815	073724	004767	152050		JSR	PC,CHECK	: SECTOR,*
13816	073730	010004			MOV	R0,R4	
13817	073732	001075		13\$:	BNE	17\$: *,VALUE
13818	073734	006005			ROR	R5	
13819	073736	103402			BLO	15\$	
13820	073740	000167	000750	14\$:	JMP	30\$	
13821	073744	016746	136720	15\$:	MOV	WPTR,-(SP)	

Address	Hex	Hex	Hex	Hex	Instruction	Comments	Line
13823							
13824							
13825							
13826	073750	016746	136716		MOV RPTR, -(SP)		
13827	073754	010246			MOV R2, -(SP)		
13828	073756	004767	150344		JSR PC, DOUBLE.CHECK	: WRDCNT, *	
13829	073762	062706	000006		ADD #6, SP		
13830	073766	010066	000040		MOV R0, 40(SP)	: *, DBL.VALUE	
13831	073772	001762			BEQ 14\$		
13832	073774	010146			MOV R1, -(SP)	: LUN, *	
13833	073776	004767	141522		JSR PC, SAYWHO		7283
13834	074002	012716	011216		MOV #MSG5, (SP)		
13835	074006	012746	007072		MOV #SAY1, -(SP)		7284
13836	074012	012746	000002		MOV #2, -(SP)		
13837	074016	010600			MOV SP, R0	: SP, *	
13838	074020	104414			TRAP 14		
13839	074022	016616	000046		MOV 46(SP), (SP)	: DBL.VALUE, *	
13840	074026	017646	000046		MOV @46(SP), -(SP)	: DBL.VALUE, *	7285
13841	074032	012746	006710		MOV #FMT12A, -(SP)		
13842	074036	012746	000003		MOV #3, -(SP)		
13843	074042	010600			MOV SP, R0	: SP, *	
13844	074044	104414			TRAP 14		
13845	074046	062766	010000	000054	ADD #10000, 54(SP)	: *, DBL.VALUE	
13846	074054	016616	000054		MOV 54(SP), (SP)	: DBL.VALUE, *	7287
13847	074060	017646	000054		MOV @54(SP), -(SP)	: DBL.VALUE, *	7288
13848	074064	012746	006756		MOV #FMT12B, -(SP)		
13849	074070	012746	000003		MOV #3, -(SP)		
13850	074074	010600			MOV SP, R0	: SP, *	
13851	074076	104414			TRAP 14		
13852	074100	112761	000010	034446	MOVB #10, WHY.DROPT(R1)	: *, *(LUN)	
13853	074106	104455			TRAP 55		7290
13854	074110	012124			.WORD 12124		7291
13855	074112	011070			.WORD MSG1		
13856	074114	000000			.WORD 0		
13857	074116	010100			MOV R1, R0	: LUN, *	
13858	074120	104451			TRAP 51		7292
13859	074122	062706	000044		ADD #44, SP		
13860	074126	000506			BR 22\$		7293
13861	074130	020427	000001		CMP R4, #1	: VALUE, *	
13862	074134	001031			BNE 18\$		7271
13863	074136	012746	000006		MOV #6, -(SP)		
13864	074142	016646	000034		MOV 34(SP), -(SP)	: COMMAND, *	7301
13865	074146	010146			MOV R1, -(SP)	: LUN, *	
13866	074150	010246			MOV R2, -(SP)	: WRDCNT, *	
13867	074152	016646	000044		MOV 44(SP), -(SP)	: PTR, *	
13868	074156	010346			MOV R3, -(SP)	: SECTOR, *	
13869	074160	004767	152040		JSR PC, RETRY		
13870	074164	062706	000014		ADD #14, SP		
13871	074170	005700			TST R0		
13872	074172	001662			BEQ 14\$		
13873	074174	112761	000004	034446	MOVB #4, WHY.DROPT(R1)	: *, *(LUN)	
13874	074202	104455			TRAP 55		7304
13875	074204	012125			.WORD 12125		7305
13876	074206	011070			.WORD MSG1		
13877	074210	000000			.WORD 0		

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

Address	Hex	OpCode	Label	Comment	Time	Page
13879			:MLX4			
13880			:	TESTING RANDOM DATA & WORD COUNTS	27-Mar-1982 19:24:42	TOPS
13881			:		27-Mar-1982 19:23:44	PA:<
13882	0742i2	010100		MOV R1,R0		
13883	074214	104451		TRAP 51	: LUN,*	7306
13884	074216	000450		BR 21\$:	
13885	074220	020427	000002	CMP R4,#2	: VALUE,*	7307
13886	074224	001012		BNE 19\$:	7271
13887	074226	112761	000005	MOVB #5,WHY.DROPT(R1)	: *,*(LUN)	
13888	074234	104455		TRAP 55	:	7314
13889	074236	012126		.WORD 12126	:	7315
13890	074240	011070		.WORD MSG1		
13891	074242	000000		.WORD 0		
13892	074244	010100		MOV R1,R0	: LUN	
13893	074246	104451		TRAP 51	:	7316
13894	074250	000433		BR 21\$:	
13895	074252	020427	000003	CMP R4,#3	: VALUE,*	7317
13896	074256	001012		BNE 20\$:	7271
13897	074260	104455		TRAP 55	:	
13898	074262	012127		.WORD 12127	:	7322
13899	074264	011070		.WORD MSG1		
13900	074266	000000		.WORD 0		
13901	074270	112761	000006	MOVB #6,WHY.DROPT(R1)	: *,*(LUN)	
13902	074276	010100		MOV R1,R0	: LUN,*	7323
13903	074300	104451		TRAP 51	:	7324
13904	074302	000416		BR 21\$:	
13905	074304	020427	000004	CMP R4,#4	: VALUE,*	7325
13906	074310	001017		BNE 23\$:	7271
13907	074312	004767	143014	JSR PC,ISOLATE	:	
13908	074316	104455		TRAP 55	:	7330
13909	074320	012130		.WORD 12130	:	7331
13910	074322	011120		.WORD MSG2		
13911	074324	000000		.WORD 0		
13912	074326	112761	000007	MOVB #7,WHY.DROPT(R1)	: *,*(LUN)	
13913	074334	010100		MOV R1,R0	: LUN,*	7332
13914	074336	104451		TRAP 51	:	7333
13915	074340	062706	000022	ADD #22,SP	:	
13916	074344	000167	001032	JMP 42\$:	7334
13917	074350	020427	000005	CMP R4,#5	: VALUE,*	
13918	074354	001157		BNE 30\$:	7271
13919	074356	004767	142750	JSR PC,ISOLATE	:	
13920	074362	032767	000001	BIT #1,ERROUT	:	7339
13921	074370	001423		BEQ 24\$:	7341
13922	074372	017705	140012	MOV @ML.REG+42,R5		
13923	074376	006205		ASR R5		
13924	074400	006205		ASR R5		
13925	074402	006205		ASR R5		
13926	074404	006205		ASR R5		
13927	074406	006205		ASR R5		
13928	074410	006205		ASR R5		
13929	074412	042705	177700	BIC #177700,R5		
13930	074416	010546		MOV R5,-(SP)		
13931	074420	012746	006640	MOV #FMT10B,-(SP)		
13932	074424	012746	000002	MOV #2,-(SP)		
13933	074430	010600		MOV SP,R0	: SP,*	

SEQ 0305

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

Address	Hex	Hex	Hex	Hex	Hex	Instruction	Value/Label	Flags	Notes	Page
13935										
13936					:MLX4					
13937					:					
13938	074432	104414				TRAP	14			
13939	074434	062706	000006			ADD	#6,SP			
13940	074440	017766	137746	000036	24\$:	MOV	@ML.REG+44,36(SP)	:	*.OLDSEC	7344
13941	074446	017705	137736			MOV	@ML.REG+42,R5	:		7345
13942	074452	006205				ASR	R5	:		
13943	074454	006205				ASR	R5	:		
13944	074456	006205				ASR	R5	:		
13945	074460	006205				ASR	R5	:		
13946	074462	006205				ASR	R5	:		
13947	074464	006205				ASR	R5	:		
13948	074466	042705	177700			BIC	#177700,R5			
13949	074472	010566	000042			MOV	R5,42(SP)	:	*.OLDCHN	
13950	074476	012746	000001			MOV	#1,-(SP)	:		
13951	074502	016646	000034			MOV	34(SP),-(SP)	:		7347
13952	074506	010146				MOV	R1,-(SP)	:	COMMAND,*	
13953	074510	010246				MOV	R2,-(SP)	:	LUN,*	
13954	074512	016646	000044			MOV	44(SP),-(SP)	:	WRDCNT,*	
13955	074516	010346				MOV	R3,-(SP)	:	PTR,*	
13956	074520	004767	151500			JSR	PC,RETRY	:	SECTOR,*	
13957	074524	062706	000014			ADD	#14,SP			
13958	074530	020027	000005			CMP	R0,#5			
13959	074534	001051				BNE	27\$			
13960	074536	027766	137650	000036		CMP	@ML.REG+44,36(SP)	:	*.OLDSEC	7350
13961	074544	001034				BNE	26\$			
13962	074546	016600	000042			MOV	42(SP),R0	:	OLDCHN,*	
13963	074552	017705	137632			MOV	@ML.REG+42,R5			
13964	074556	006205				ASR	R5			
13965	074560	006205				ASR	R5			
13966	074562	006205				ASR	R5			
13967	074564	006205				ASR	R5			
13968	074566	006205				ASR	R5			
13969	074570	006205				ASR	R5			
13970	074572	042705	177700			BIC	#177700,R5			
13971	074576	020500				CMP	R5,R0			
13972	074600	001016				BNE	26\$			
13973	074602	032767	000001	105450		BIT	#1,ERRROUT	:		7354
13974	074610	001404				BEQ	25\$			
13975	074612	104456				TRAP	56			
13976	074614	012131				.WORD	12131			
13977	074616	011202				.WORD	MSG4			
13978	074620	000000				.WORD	0			
13979	074622	010146				MOV	R1,-(SP)	:	LUN,*	7357
13980	074624	016746	137512			MOV	BOARD,-(SP)			
13981	074630	004767	142566			JSR	PC,UP.HARD.COUNT			
13982	074634	000426				BR	29\$			
13983	074636	032767	000001	105414	26\$:	BIT	#1,ERRROUT	:		7350
13984	074644	001415				BEQ	28\$			7362
13985	074646	104457				TRAP	57			
13986	074650	012132				.WORD	12132			
13987	074652	011166				.WORD	MSG3			
13988	074654	000000				.WORD	0			
13989	074656	000410				BR	28\$:		7365

Address	Hex	Hex	Hex	Hex	Hex	Op	Op	Op	Time	Time	Time
13991											
13992											
13993											
13994	074660	032767	000001	105372	27\$:	BIT	#1,ERROUT	:	27-Mar-1982 19:24:42	TOPS	
13995	074666	001404				BEQ	28\$:	27-Mar-1982 19:23:44	PA:<	7371
13996	074670	104457				TRAP	57	:			
13997	074672	012133				.WORD	12133	:			
13998	074674	011166				.WORD	MSG3	:			
13999	074676	000000				.WORD	0	:			
14000	074700	010146			28\$:	MOV	R1,-(SP)	:			
14001	074702	016746	137434			MOV	BOARD,-(SP)	:		LUN,*	7374
14002	074706	004767	143172			JSR	PC,UP.SOFT.COUNT	:			
14003	074712	022626			29\$:	CMP	(SP)+,(SP)+	:			
14004	074714	016603	000030		30\$:	MOV	30(SP),R3	:		NEXT.SECT,SECTOR	7338
14005	074720	062767	000002	135742		ADD	#2,WPTR	:			7380
14006	074726	062706	000022			ADD	#2,SP	:			7381
14007	074732	000167	176362			JMP	5\$:			7199
14008	074736	032767	000001	105316	31\$:	BIT	#1,EFNS21	:			7198
14009	074744	001002				BNE	32\$:			7392
14010	074746	000167	000430			JMP	42\$:			
14011	074752	010100			32\$:	MOV	R1,R0	:		LUN,*	7399
14012	074754	006300				ASL	R0	:			
14013	074756	016066	034500	000024		MOV	TOP.SECT(R0),24(SP)	:			
14014	074764	016005	034460			MOV	LOW.SECT(R0),R5	:		*,SECTOR	
14015	074770	000577				BR	41\$:			
14016	074772	010146			33\$:	MOV	R1,-(SP)	:		LUN,*	7401
14017	074774	012746	000400			MOV	#400,-(SP)	:			
14018	075000	012746	022670			MOV	#RBUF,-(SP)	:			
14019	075004	010546				MOV	R5,-(SP)	:		SECTOR,*	
14020	075006	004767	150600			JSR	PC,READ	:			
14021	075012	062706	000010			ADD	#10,SP	:			
14022	075016	020027	000005			CMP	R0,#5	:			
14023	075022	001161				BNE	40\$:			
14024	075024	004767	142302			JSR	PC,ISOLATE	:			
14025	075030	032767	000001	105222		BIT	#1,ERROUT	:			7404
14026	075036	001423				BEQ	34\$:			7406
14027	075040	017700	137344			MOV	@ML.REG+42,R0	:			
14028	075044	006200				ASR	R0	:			
14029	075046	006200				ASR	R0	:			
14030	075050	006200				ASR	R0	:			
14031	075052	006200				ASR	R0	:			
14032	075054	006200				ASR	R0	:			
14033	075056	006200				ASR	R0	:			
14034	075060	042700	177700			BIC	#177700,R0	:			
14035	075064	010046				MOV	R0,-(SP)	:			
14036	075066	012746	006640			MOV	#FMT10B,-(SP)	:			
14037	075072	012746	000002			MOV	#2,-(SP)	:			
14038	075076	010600				MOV	SP,R0	:		SP,*	
14039	075100	104414				TRAP	14	:			
14040	075102	062706	000000			ADD	#6,SP	:			
14041	075106	017766	137300	000014	34\$:	MOV	@ML.REG+44,14(SP)	:		*,OLDSEC	7415
14042	075114	017766	137270			MOV	@ML.REG+42,R0	:			7416
14043	075120	006200				ASR	R0	:			
14044	075122	006200				ASR	R0	:			
14045	075124	006200				ASR	R0	:			

Address	Op Code	Operand 1	Operand 2	Operand 3	Operand 4	Instruction	Comment	Count
14047								
14048								
14049								
14050	075126	006200				ASR R0		
14051	075130	006200				ASR R0		
14052	075132	006200				ASR R0		
14053	075134	042700	177700			BIC #177700,R0		
14054	075140	010066	000020			MOV R0,20(SP)		
14055	075144	012746	000001			MOV #1,-(SP)	: *.OLDCHN	
14056	075150	016646	000012			MOV 12(SP),-(SP)		
14057	075154	010146				MOV R1,-(SP)	: COMMAND,*	7424
14058	075156	012746	000400			MOV #400,-(SP)	: LUN,*	
14059	075162	016646	000022			MOV 22(SP),-(SP)		
14060	075166	016646	000026			MOV 26(SP),-(SP)	: PTR,*	
14061	075172	004767	151026			JSR PC,RETRY	: OLDSEC,*	
14062	075176	062706	000014			ADD #14,SP		
14063	075202	020027	000005			CMP R0,#5		
14064	075206	001051				BNE 37\$		
14065	075210	027766	137176	000014		CMP @ML.REG+44,14(SP)	: *.OLDSEC	7433
14066	075216	001034				BNE 36\$		
14067	075220	016646	000020			MOV 20(SP),-(SP)	: OLDCHN,*	
14068	075224	017700	137160			MOV @ML.REG+42,R0		
14069	075230	006200				ASR R0		
14070	075232	006200				ASR R0		
14071	075234	006200				ASR R0		
14072	075236	006200				ASR R0		
14073	075240	006200				ASR R0		
14074	075242	006200				ASR R0		
14075	075244	042700	177700			BIC #177700,R0		
14076	075250	020026				CMP R0,(SP)+		
14077	075252	001016				BNE 36\$		
14078	075254	032767	000001	104776		BIT #1,ERROUT		
14079	075262	001404				BEQ 35\$		7437
14080	075264	104456				TRAP 56		
14081	075266	012134				.WORD 12134		7442
14082	075270	11202				.WORD MSG4		
14083	075272	000000				.WORD 0		
14084	075274	010146				MOV R1,-(SP)	: LUN,*	7445
14085	075276	016746	137040			MOV BOARD,-(SP)		
14086	075302	004767	142114			JSR PC,UP.HARD.COUNT		
14087	075306	000426				BR 39\$		
14088	075310	032767	000001	104742	36\$:	BIT #1,ERROUT		7433
14089	075316	001415				BEQ 38\$		7450
14090	075320	104457				TRAP 57		
14091	075322	012135				.WORD 12135		7455
14092	075324	011166				.WORD MSG3		
14093	075326	000000				.WORD 0		
14094	075330	000410				BR 38\$		
14095	075332	032767	000001	104720	37\$:	BIT #1,ERROUT		7458
14096	075340	001404				BEQ 38\$		7464
14097	075342	104457				TRAP 57		
14098	075344	012136				.WORD 12136		7469
14099	075346	011166				.WORD MSG3		
14100	075350	000000				.WORD 0		
14101	075352	010146				MOV R1,-(SP)	: LUN,*	7472

SEQ 0308

```

14103
14104          :MLX4
14105          :
14106 075354 016746 136762          MOV BOARD,-(SP)
14107 075360 004767 142520          JSR PC,UP.SOFT.COUNT
14108 075364 022626          39$: CMP (SP)+,(SP)+
14109 075366 005205          40$: INC R5
14110 075370 020566 000024          41$: CMP R5,24(SP)
14111 075374 101002          BHI 42$
14112 075376 000167 177370          JMP 33$
14113 075402 005201          42$: INC R1
14114 075404 020166 000026          43$: CMP R1,26(SP)
14115 075410 002002          BGE 44$
14116 075412 000167 175562          JMP 2$
14117 075416 005266 000022          44$: INC 22(SP)
14118 075422 026666 000022 000046 CMP 22(SP),46(SP)
14119 075430 003002          BGT 45$
14120 075432 000167 175526          JMP 1$
14121 075436 062706 000030          45$: ADD #30,SP
14122 075442 000207          RTS PC
14123
14124          : Routine Size: 616 words
14125          : Maximum stack depth per invocation: 36 words
14130
14131
    27-Mar-1982 19:24:42 TOPS
    27-Mar-1982 19:23:44 PA:<
                                     : SECTOR
                                     : SECTOR,*
                                     : LUN
                                     : LUN,*
                                     : COUNT
                                     : COUNT,REPEAT
                                     :
    7403
    7399
    7184
    7181
    7107
    
```

```

14133 :MLX4
14134 :
14135 :
14136 : 7486
14137 : 7487
14138 : 7488
14139 : 7489
14140 : 7490
14141 : 7491
14142 : 7492
14143 : 7493
14144 : 7494
14145 : 7495
14146 : 7496
14147 : 7497
14148 : 7498
14149 : 7499
14150 : 7500
14151 : 7501
14152 : 7502
14153 : 7503
14154 : 7504
14155 : 7505
14156 : 7506
14157 : 7507
14158 : 7508
14159 : 7509
14160 : 7510
14161 : 7511
14162 : 7512
14163 : 7513
14164 : 7514
14165 : 7515
14166 : 7516
14167 : 7517
14168 : 7518
14169 : 7519
14170 : 7520
14171 : 7521
14172 : 7522
14173 : 7523
14174 : 7524
14175 : 7525
14176 : 7526
14177 : 7527
14178 : 7528
14179 : 7529
14180 : 7530
14181 : 7531
14182 : 7532
14183 : 7533
14184 : 7534
14185 : 7535
14186 : 7536
14187 : 7537

TESTING RANDOM SECTORS, DATA, WORD COUNTS
%sbttl 'TESTING RANDOM SECTORS, DATA, WORD COUNTS'
routine RAND3 (REPEAT) : novalue =
begin
! * 1 * START OF ROUTINE

++
ROUTINE: RAND3(REPEAT)
PURPOSE: TO CHECK RANDOM SECTORS
ARGUMENT: REPEAT = NUMBER OF TIMES TO EXECUTE ENTIRE ROUTINE

THE CODE FOR 'RAND3' IN BRIEF:
BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COUNT FROM 1 TO REPEAT
: BEGIN 2 (START OF REPEAT LOOP FOR THIS ROUTINE)
: GENERATE THE RANDOM PATTERN
: INCR LUN FROM 0 TO LAST
: : BEGIN 3 (START OF LOGICAL UNIT SELECTION LOOP)
: : INITIALIZE BUFFER POINTERS
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : IF UNIT IS ACTIVE
: : : THEN
: : : : BEGIN 5 (START OF TEST FOR AN ACTIVE UNIT)
: : : : TIMES = (HIGHEST - LOWEST)/2 + 1
: : : : INCR KOUNT FROM 1 TO TIMES
: : : : : BEGIN 6 (START OF COUNTING LOOP FOR SECTOR SELECTION)
: : : : : CHOOSE A RANDOM WORD COUNT
: : : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : : CHOOSE A RANDOM SECTOR
: : : : : CALCULATE WHERE TRANSFER WILL END (BASED ON WORD COUNT)
: : : : : IF CALCULATED VALUE GTR HIGHEST
: : : : : THEN ADJUST THE WORD COUNT SO IT FITS
: : : : : : WITHIN THE TESTABLE SECTOR LIMITS
: : : : : WRITE
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE LABEL)
: : : : : CHOOSE WHETHER TO WRITE CHECK OR READ
: : : : : DO THE WRITE CHECK OR READ
: : : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE LABEL)
: : : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : : END 6 (END OF COUNTING LOOP FOR SECTOR SELECTION)
: : : : : END 5 (END OF TEST FOR AN ACTIVE UNIT)
: : : : : END 4 (END OF TESTLOOP)
: : : : : END 3 (END OF LOGICAL UNIT SELECTION LOOP)
: : : : : END 2 (END OF REPEAT LOOP FOR THIS ROUTINE)
RETURN
END 1 (END OF ROUTINE)

--
local

```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (46)

```

14189 :MLX4
14190 :
14191 :
14192 : 7538 WRDCNT,
14193 : 7539 SECTOR,
14194 : 7540 TIMES,
14195 : 7541 VALUE,
14196 : 7542 OLDSEC,
14197 : 7543 OLDCHN,
14198 : 7544 PTR,
14199 : 7545 COMMAND,
14200 : 7546 DBL_VALUE;
14201 :
14202 : Label
14203 : LOOP;
14204 :
14205 : PRINTB (SAY1, RTN5C);
14206 : !'RAND3'
14207 :
14208 : incr COUNT from 1 to .REPEAT do
14209 : begin
14210 :
14211 : incr LUN from 0 to (.LSUNIT - 1) do
14212 : begin
14213 : GENS ();
14214 : LOOP :
14215 : begin
14216 :
14217 : if .DRIVE_STATUS [.LUN] eql ACTIVE
14218 : then
14219 : begin
14220 : LSLUN = .LUN;
14221 : WPTR = WBUFF;
14222 : RPTR = RBUFF;
14223 : TIMES = (HIGHEST - LOWEST)/2 + 1;
14224 :
14225 : incr KOUNT from 1 to .TIMES do
14226 : begin
14227 : WRDCNT = RNDWC ();
14228 : SET PTRS (.WRDCNT);
14229 : SECTOR = RNDSEC (.LUN);
14230 :
14231 : if (.SECTOR + .WRDCNT/256) gtra HIGHEST then WRDCNT = 256*(HIGHEST - .SECTOR + 1);
14232 : VALUE = write (.LUN, .WRDCNT, .WPTR, .SECTOR);
14233 :
14234 : !+
14235 : ! SEE HOW SUCCESSFUL THE WRITE WAS:
14236 : !-
14237 :
14238 : selectone .VALUE of
14239 : set
14240 : [1] :
14241 : begin
14242 :
14243 :
  
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (46)

!* 2 * START OF REPEAT LOOP FOR THIS ROUTINE

!* 3 * START OF LOGICAL UNIT SELECTION LOOP

!* 4 * START OF THE LOOP THAT COMPLETELY TESTS 1 UNIT

!* 5 * START OF TEST FOR AN ACTIVE UNIT

!* 6 * START OF COUNTING LOOP FOR SECTOR SELECTION
 !VALUE BETWEEN 1 AND BUFSIZ

!VALUE BETWEEN LOWEST AND HIGHEST

!SEE 'SYSERR' FOR DEFINITION
 !OF ERROR # CONTAINED IN 'VALUE'

!* 6A * RETRY ALLOWED

14245 :MLX4
 14246 :
 14247 :
 14248 :
 14249 :
 14250 :
 14251 :
 14252 :
 14253 :
 14254 :
 14255 :
 14256 :
 14257 :
 14258 :
 14259 :
 14260 :
 14261 :
 14262 :
 14263 :
 14264 :
 14265 :
 14266 :
 14267 :
 14268 :
 14269 :
 14270 :
 14271 :
 14272 :
 14273 :
 14274 :
 14275 :
 14276 :
 14277 :
 14278 :
 14279 :
 14280 :
 14281 :
 14282 :
 14283 :
 14284 :
 14285 :
 14286 :
 14287 :
 14288 :
 14289 :
 14290 :
 14291 :
 14292 :
 14293 :
 14294 :
 14295 :
 14296 :
 14297 :
 14298 :
 14299 :

TESTING RANDOM SECTORS, DATA, WORD COUNTS

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (46)

7590
 7591
 7592
 7593
 7594
 7595
 7596
 7597
 7598
 7599
 7600
 7601
 7602
 7603
 7604
 7605
 7606
 7607
 7608
 7609
 7610
 7611
 7612
 7613
 7614
 7615
 7616
 7617
 7618
 7619
 7620
 7621
 7622
 7623
 7624
 7625
 7626
 7627
 7628
 7629
 7630
 7631
 7632
 7633
 7634
 7635
 7636
 7637
 7638
 7639
 7640
 7641

```

if RETRY (SIX, write, .LUN, .WRDCNT, .WPTR, .SECTOR) neq 0
then
  !THE RETRY FAILED -- SYSTEM FATAL ERROR
  begin
    WHY DROPT [.LUN] = CODE_4;
    ERRDF (5301, MSG1, 0); -!**** OPTION 5, RAND3 ERROR 01 ****
    DODU (.LUN);
    leave LOOP;      !JUMP JUST BEYOND END OF BLOCK * 4 *
  end;
end;                !* 6A *

[2] :
begin
  !* 6B * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
  WHY DROPT [.LUN] = CODE_5;
  ERRDF (5302, MSG1, 0); -!**** OPTION 5, RAND3 ERROR 02 ****
  DODU (.LUN);
  leave LOOP;      !JUMP JUST BEYOND END OF BLOCK * 4 *
end;                !* 6B *

[3] :
begin
  !* 6C * FATAL DRIVE ERROR -- NO RETRY ALLOWED
  ERRDF (5303, MSG1, 0); -!**** OPTION 5, RAND3 ERROR 03 ****
  WHY DROPT [.LUN] = CODE_6;
  DODU (.LUN);
  leave LOOP;      !JUMP JUST BEYOND END OF BLOCK * 4 *
end;                !* 6C *

tes;

COMMAND = CHOOSE ();

if .COMMAND eql read
then
  begin
    PTR = .RPTR;
    VALUE = read (.LUN, .WRDCNT, .RPTR, .SECTOR);
  end
else
  begin
    PTR = .WPTR;
    VALUE = CHECK (.LUN, .WRDCNT, .WPTR, .SECTOR);
  end;

!+
!- SEE HOW SUCCESSFUL THE OPERATION WAS:
!-

selectone .VALUE of
set
!SEE 'SYSERR' FOR DEFINITION
!OF ERROR # CONTAINED IN 'VALUE'

[0] :
  
```

14301 :MLX4
 14302 :
 14303 :
 14304 :
 14305 :
 14306 :
 14307 :
 14308 :
 14309 :
 14310 :
 14311 :
 14312 :
 14313 :
 14314 :
 14315 :
 14316 :
 14317 :
 14318 :
 14319 :
 14320 :
 14321 :
 14322 :
 14323 :
 14324 :
 14325 :
 14326 :
 14327 :
 14328 :
 14329 :
 14330 :
 14331 :
 14332 :
 14333 :
 14334 :
 14335 :
 14336 :
 14337 :
 14338 :
 14339 :
 14340 :
 14341 :
 14342 :
 14343 :
 14344 :
 14345 :
 14346 :
 14347 :
 14348 :
 14349 :
 14350 :
 14351 :
 14352 :
 14353 :
 14354 :
 14355 :

7642
 7643
 7644
 7645
 7646
 7647
 7648
 7649
 7650
 7651
 7652
 7653
 7654
 7655
 7656
 7657
 7658
 7659
 7660
 7661
 7662
 7663
 7664
 7665
 7666
 7667
 7668
 7669
 7670
 7671
 7672
 7673
 7674
 7675
 7676
 7677
 7678
 7679
 7680
 7681
 7682
 7683
 7684
 7685
 7686
 7687
 7688
 7689
 7690
 7691
 7692
 7693

TESTING RANDOM SECTORS, DATA, WORD COUNTS

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (46)

```

if .COMMAND eq1 read
then
begin
if (DBL_VALUE = DOUBLE_CHECK (.WPTR, .RPTR, .WRDCNT)) neq 0
then
begin
SAYWHO (.LUN);
PRINTB (SAY1, MSG5);          !'ECC LOGIC FAILED TO DETECT DATA ERROR'
PRINTB (FMT12A, .DBL_VALUE, .DBL_VALUE);
                                !'GOOD DATA: XXXXXX AT LOCATION YYYYYY'
DBL_VALUE = .DBL_VALUE + BUFSIZ*2;
PRINTB (FMT12B, .DBL_VALUE, .DBL_VALUE);
                                !'BAD DATA: PPPPPP AT LOCATION QQQQQQ'
WHY DROPT [.LUN] = CODE_8;
ERRDF (5304, MSG1, 0);        !**** OPTION 5, RAND3 ERROR 04 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;
end;

[1] :
begin
                                !* 6D * RETRY ALLOWED
if RETRY (SIX, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) neq 0
then
                                !THE RETRY FAILED -- SYSTEM FATAL ERROR
begin
WHY DROPT [.LUN] = CODE_4;
ERRDF (5305, MSG1, 0);        !**** OPTION 5, RAND3 ERROR 05 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;
end;
                                !* 6D *

[2] :
begin
                                !* 6E * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
WHY DROPT [.LUN] = CODE_5;
ERRDF (5306, MSG1, 0);        !**** OPTION 5, RAND3 ERROR 06 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;

[3] :
begin
                                !* 6F * FATAL DRIVE ERROR -- NO RETRY ALLOWED
ERRDF (5307, MSG1, 0);        !**** OPTION 5, RAND3 ERROR 07 ****
WHY DROPT [.LUN] = CODE_6;
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;
                                !* 6F *
    
```

14357 :MLX4
 14358 :
 14359 :
 14360 :
 14361 :
 14362 :
 14363 :
 14364 :
 14365 :
 14366 :
 14367 :
 14368 :
 14369 :
 14370 :
 14371 :
 14372 :
 14373 :
 14374 :
 14375 :
 14376 :
 14377 :
 14378 :
 14379 :
 14380 :
 14381 :
 14382 :
 14383 :
 14384 :
 14385 :
 14386 :
 14387 :
 14388 :
 14389 :
 14390 :
 14391 :
 14392 :
 14393 :
 14394 :
 14395 :
 14396 :
 14397 :
 14398 :
 14399 :
 14400 :
 14401 :
 14402 :
 14403 :
 14404 :
 14405 :
 14406 :
 14407 :
 14408 :
 14409 :
 14410 :
 14411 :

TESTING RANDOM SECTORS, DATA, WORD COUNTS

27-Mar-1982 19:24.42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (46)

```
[4] :
begin
ISOLATE ();
ERRDF (5308, MSG2, 0);
WHY DROPT [.LUN] = CODE_7;
DODC (.LUN);
leave LOOP;
end;
!* 6G * UNRECOVERABLE DATA ERROR
!* 6G * RECOVERABLE DATA ERROR

[5] :
begin
ISOLATE ();

if .ERROUT then PRINTB (FMT10B, .CHAN);

!' BIT qq'
OLDSEC = .MLEL;
OLDCHN = .CHAN;

if RETRY (ONE, CHECK, .LUN, .WRDCNT, .WPTR, .SECTOR) eql 5
then
    if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
    then
        begin
            if .ERROUT then ERRHRD (5309, MSG4, 0);

            !*** OPTION 5, RAND3 ERROR 09 ***
            UP_HARD_COUNT (.LUN, .BOARD);
        end
    else
        begin
            if .ERROUT then ERRSOFT (5310, MSG3, 0);

            !*** OPTION 5, RAND3 ERROR 10 ***
            UP_SOFT_COUNT (.LUN, .BOARD);
        end
    else
        begin
            if .ERROUT then ERRSOFT (5311, MSG3, 0);

            !*** OPTION 5, RAND3 ERROR 11 ***
            UP_SOFT_COUNT (.LUN, .BOARD);
        end
    end;
end;
!* 6H *
tes;
```

14413 :MLX4
 14414 :
 14415 :
 14416 :
 14417 :
 14418 :
 14419 :
 14420 :
 14421 :
 14422 :
 14423 :
 14424 :
 14425 :
 14426 :
 14427 :
 14428 :
 14429 :
 14430 :
 14431 :
 14432 :
 14433 :
 14434 :
 14435 :
 14436 :
 14437 :
 14438 :
 14439 :
 14440 :
 14441 :
 14442 :
 14443 :
 14444 :
 14445 :
 14446 :
 14447 :
 14448 :
 14449 :
 14450 :
 14451 :
 14452 :
 14453 :
 14454 :
 14455 :
 14456 :
 14457 :
 14458 :
 14459 :
 14460 :
 14461 :
 14462 :
 14463 :
 14464 :
 14465 :
 14466 :
 14467 :

TESTING RANDOM SECTORS, DATA, WORD COUNTS

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (46)

```

WPTR = .WPTR + 2;
end;
!* 6 * END OF COUNTING LOOP FOR SECTOR SELECTION

end;
!* 5 * END OF TEST FOR AN ACTIVE UNIT

!+
!-
Test to see if this uut's address space is
to be read for soft errors. This test is
is intended for DMT purposes.

if .EFNS21
then
begin
!*Is the background pattern to be read

!-
version czmlbb changed incr to incru
incru SECTOR from LOWEST to HIGHEST do
if read (.LUN, 256, RBUFF, .SECTOR) eql 5
then
begin
ISOLATE ();
!*Find the failing bank and board no.

if .ERROUT then PRINTB (FMT10B, .CHAN);

! Print where the error is
! Save the contents of the ML error location
! register so we can compare it to the new
! contents of this register after the retry.
! This is done to classify the error.

OLDSEC = .MLEL;
OLDCHN = .CHAN;

! Do a classify retry call. If the same error
! occurs then classify it as a hard error. If
! a different error occurred or the error went away
! then classify it as a soft error.

if RETRY (ONE, .COMMAND, .LUN, 256, .PTR, .OLDSEC) eql 5
then
! The same error occurred so see if it is at the same
! sector and channel number, if so then classify
! it as a hard error else classiy it as a soft
! error.
    
```

14469	:	MLX4		27-Mar-1982 19:24:42	TOPS-20 Bliss-16 V2(212)
14470	:		TESTING RANDOM SECTORS, DATA, WORD COUNTS	27-Mar-1982 19:23:44	PA:<NEALE>MLX4.BLI.5 (46)
14471	:				
14472	:				
14473	:				
14474	:				
14475	:				
14476	:				
14477	:				
14478	:				
14479	:	P			
14480	:	P			
14481	:				
14482	:				
14483	:				
14484	:				
14485	:				
14486	:				
14487	:				
14488	:				
14489	:				
14490	:				
14491	:				
14492	:	P			
14493	:	P			
14494	:				
14495	:				
14496	:				
14497	:				
14498	:				
14499	:				
14500	:				
14501	:				
14502	:				
14503	:				
14504	:				
14505	:				
14506	:	P			
14507	:	P			
14508	:				
14509	:				
14510	:				
14511	:				
14512	:				
14513	:				
14514	:				
14515	:				
14516	:				
14517	:				
14518	:				
14519	:				
14520	:				
14521	:				
14522	:				
14523	:				

```

if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
then
begin
!Same error occurred 'hard'
if .ERROUT
!Print error if enabled
then
begin
ERRHRD (5312,
MSG4, !Error number
0); !Error message
!Additional message routine
end;
UP_HARD_COUNT (.LUN, .BOARD);
end
else
begin
!Not the same error 'soft'
if .ERROUT
!Print error if enabled
then
begin
ERRSOFT (5313,
MSG3, !Error number
0); !Error message
!Additional message routine
end;
UP_SOFT_COUNT (.LUN, .BOARD);
end
else
begin
!Not the same error 'soft'
if .ERROUT
!Print error if enabled
then
begin
ERRSOFT (5314,
MSG3, !Error number
0); !Error message
!Additional message routine
end;
UP_SOFT_COUNT (.LUN, .BOARD);
end;
end;
end;
end;
end;
return;

```

* 4 * END OF LOOP THAT COMPLETELY TESTS 1 UNIT
 * 3 * END OF LOGICAL UNIT SELECTION LOOP
 * 2 * END OF REPEAT LOOP FOR THIS ROUTINE

14525 :MLX4
 14526 :
 14527 :
 14528 : 7850 end:
 14532 :
 14533 :
 14537 075444 004167 107664
 14538 075450 162706 000024
 14539 075454 012746 007700
 14540 075460 012746 007072
 14541 075464 012746 000002
 14542 075470 010600
 14543 075472 104414
 14544 075474 005066 000030
 14545 075500 000167 002254
 14546 075504 016766 104302 000012 1\$:
 14547 075512 005003
 14548 075514 000167 002226
 14549 075520 004767 144074 2\$:
 14550 075524 010300
 14551 075526 006200
 14552 075530 006200
 14553 075532 006200
 14554 075534 062700 034442
 14555 075540 010046
 14556 075542 010346
 14557 075544 042716 177770
 14558 075550 012746 000001
 14559 075554 005046
 14560 075556 004767 106574
 14561 075562 062706 000010
 14562 075566 005300
 14563 075570 001402
 14564 075572 000167 001502
 14565 075576 010367 104272 3\$:
 14566 075602 012767 012670 135060
 14567 075610 012767 022670 135054
 14568 075616 010300
 14569 075620 006300
 14570 075622 012766 034500 000010
 14571 075630 060066 000010
 14572 075634 017646 000010
 14573 075640 166016 034460
 14574 075644 012746 000002
 14575 075650 004767 107314
 14576 075654 010066 000020
 14577 075660 005266 000020
 14578 075664 005066 000012
 14579 075670 000167 001362

TESTING RANDOM SECTORS, DATA, WORD COUNTS

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (46)

!* 1 * END OF ROUTINE

RAND3: .SBTTL RAND3 TESTING RANDOM SECTORS, DATA, WORD COUNTS

```

JSR R1,$SAVE5 ;
SUB #24,SP ;
MOV #RTN5C,-(SP) ;
MOV #SAY1,-(SP) ;
MOV #2,-(SP) ;
MOV SP,R0 ; SP,*
TRAP 14 ;
CLR 30(SP) ; COUNT
JMP 44$ ;
MOV L$UNIT,12(SP) ;
CLR R3 ; LUN
JMP 43$ ;
JSR PC,GEN5 ;
MOV R3,R0 ; LUN,*
ASR R0 ;
ASR R0 ;
ASR R0 ;
ADD #DRIVE.STATUS,R0 ;
MOV R0,-(SP) ;
MOV R3,-(SP) ; LUN,*
BIC #177770,(SP) ;
MOV #1,-(SP) ;
CLR -(SP) ;
JSR PC,BL$GT2 ;
ADD #10,SP ;
DEC R0 ;
BEQ 3$ ;
JMP 31$ ;
MOV R3,L$LUN ; LUN,*
MOV #W$BUFF,W$PTR ;
MOV #R$BUFF,R$PTR ;
MOV R3,R0 ; LUN,*
ASL R0 ;
MOV #TOP.SECT,10(SP) ;
ADD R0,10(SP) ;
MOV @10(SP),-(SP) ;
SUB LOW.SECT(R0),(SP) ;
MOV #2,-(SP) ;
JSR PC,BL$DIV ;
MOV R0,20(SP) ; *TIMES
INC 20(SP) ; TIMES
CLR 12(SP) ; KOUNT
JMP 29$ ;

```

7571

Address	Op1	Op2	Op3	Op4	Label	Instruction	Comments	Time	Page
14581									
14582					:MLX4				
14583					:				
14584	075674	004767	172304		4\$:	JSR PC,RNDWC		27-Mar-1982 19:24:42	TOPS
14585	075700	010002				MOV R0,R2	: *	27-Mar-1982 19:23:44	PA:<
14586	075702	010246				MOV R2,-(SP)	: WRDCNT		7573
14587	075704	004767	151222			JSR PC,SET.PTRS	: WRDCNT,*		7574
14588	075710	010316				MOV R3,(SP)	: LUN,*		7575
14589	075712	004767	172322			JSR PC,RNDSEC			
14590	075716	010001				MOV R0,R1	: *,SECTOR		
14591	075720	010246				MOV R2,-(SP)	: WRDCNT,*		7577
14592	075722	012746	000400			MOV #400,-(SP)			
14593	075726	004767	107236			JSR PC,BLSDIV			
14594	075732	022626				CMP (SP)+,(SP)+			
14595	075734	060100				ADD R1,R0	: SECTOR,*		
14596	075736	020076	000016			CMP R0,@16(SP)			
14597	075742	101410				BLOS 5\$			
14598	075744	017600	000016			MOV @16(SP),R0			
14599	075750	160100				SUB R1,R0	: SECTOR,*		
14600	075752	000300				SWAB R0			
14601	075754	105000				CLRB R0			
14602	075756	010002				MOV R0,R2	: *,WRDCNT		
14603	075760	062702	000400			ADD #400,R2	: *,WRDCNT		
14604	075764	010316			5\$:	MOV R3,(SP)	: LUN,*		7579
14605	075766	010246				MOV R2,-(SP)	: WRDCNT,*		
14606	075770	016746	134674			MOV WPTR,-(SP)			
14607	075774	010146				MOV R1,-(SP)	: SECTOR,*		
14608	075776	004767	147422			JSR PC,WRITE			
14609	076002	010004				MOV R0,R4	: *,VALUE		
14610	076004	020427	000001			CMP R4,#1	: VALUE,*		7585
14611	076010	001031				BNE 6\$			
14612	076012	012746	000006			MOV #6,-(SP)			
14613	076016	012746	045424			MOV #WRITE,-(SP)			7591
14614	076022	010346				MOV R3,-(SP)	: LUN,*		
14615	076024	010246				MOV R2,-(SP)	: WRDCNT,*		
14616	076026	016746	134636			MOV WPTR,-(SP)			
14617	076032	010146				MOV R1,-(SP)	: SECTOR,*		
14618	076034	004767	150164			JSR PC,RETRY			
14619	076040	062706	000014			ADD #14,SP			
14620	076044	005700				TST R0			
14621	076046	001446				BEQ 9\$			
14622	076050	112763	000004	034446		MOVB #4,WHY.DROPT(R3)	: *,*(LUN)		7594
14623	076056	104455				TRAP 55	:		7595
14624	076060	012265				.WORD 12265	:		
14625	076062	011070				.WORD MSG1			
14626	076064	000000				.WORD 0			
14627	076066	010300				MOV R3,R0	: LUN,*		7596
14628	076070	104451				TRAP 51			
14629	076072	000431				BR 8\$			
14630	076074	020427	000002		6\$:	CMP R4,#2	: VALUE,*		7597
14631	076100	001012				BNE 7\$			7585
14632	076102	112763	000005	034446		MOVB #5,WHY.DROPT(R3)	: *,*(LUN)		7604
14633	076110	104455				TRAP 55	:		7605
14634	076112	012266				.WORD 12266	:		
14635	076114	011070				.WORD MSG1			

Address	Word 1	Word 2	Word 3	Word 4	Label	Instruction	Comments	Address	Time	Page
14637					:MLX4				27-Mar-1982 19:24:42	TOPS
14638					:				27-Mar-1982 19:23:44	PA:-
14639						TESTING RANDOM SECTORS, DATA, WORD COUNTS				
14640	076116	000000				.WORD 0				
14641	076120	010300				MOV R3,R0				
14642	076122	104451				TRAP 51	: LUN,*			7606
14643	076124	000414				BR 8\$				
14644	076126	020427	000003		7\$:	CMP R4,#3	: VALUE,*			7607
14645	076132	001014				BNE 9\$				7585
14646	076134	104455				TRAP 55				
14647	076136	012267				.WORD 12767				7612
14648	076140	011070				.WORD MSG1				
14649	076142	000000				.WORD 0				
14650	076144	112763	000006	034446		MOVB #6,WHY.DROPT(R3)	: *,*(LUN)			7613
14651	076152	010300				MOV R3,R0	: LUN,*			7614
14652	076154	104451				TRAP 51				
14653	076156	062706	000014		8\$:	ADD #14,SP				
14654	076162	000535				BR 14\$				7615
14655	076164	004767	147776		9\$:	JSR PC,CHOOSE				
14656	076170	010066	000036			MOV R0,36(SP)	: *,COMMAND			7619
14657	076174	005005				CLR R5				
14658	076176	020027	045612			CMP R0,#READ	: COMMAND,*			7621
14659	076202	001014				BNE 10\$				
14660	076204	005205				INC R5				
14661	076206	016766	134460	000034		MOV RPTR,34(SP)	: *,PTR			7624
14662	076214	010346				MOV R3,-(SP)	: LUN,*			7625
14663	076216	010246				MOV R2,-(SP)	: WRDCNT,*			
14664	076220	016746	134446			MOV RPTR,-(SP)				
14665	076224	010146				MOV R1,-(SP)	: SECTOR,*			
14666	076226	004767	147360			JSR PC,READ				
14667	076232	000412				BR 11\$				
14668	076234	016766	134430	000034	10\$:	MOV WPTR,34(SP)	: *,PTR			7629
14669	076242	010346				MOV R3,-(SP)	: LUN,*			7630
14670	076244	010246				MOV R2,-(SP)	: WRDCNT,*			
14671	076246	016746	134416			MOV WPTR,-(SP)				
14672	076252	010146				MOV R1,-(SP)	: SECTOR,*			
14673	076254	004767	147520			JSR PC,CHECK				
14674	076260	010004			11\$:	MOV R0,R4	: *,VALUE			
14675	076262	001076				BNE 15\$				
14676	076264	006005				ROR R5				7637
14677	076266	103402				BLO 13\$				7642
14678	076270	000167	000750		12\$:	JMP 28\$				
14679	076274	016746	134370		13\$:	MOV WPTR,-(SP)				
14680	076300	016746	134366			MOV RPTR,-(SP)				7646
14681	076304	010246				MOV R2,-(SP)	: WRDCNT,*			
14682	076306	004767	146014			JSR PC,DOUBLE.CHECK				
14683	076312	062706	000006			ADD #6,SP				
14684	076316	010066	000050			MOV R0,50(SP)	: *,DBL.VALUE			
14685	076322	001762				BEQ 12\$				
14686	076324	010346				MOV R3,-(SP)	: LUN,*			7649
14687	076326	004767	137172			JSR PC,SAYWHO				
14688	076332	012716	011216			MOV #MSG5,(SP)				
14689	076336	012746	007072			MOV #SAY1,-(SP)				7650
14690	076342	012746	000002			MOV #2,-(SP)				
14691	076346	010600				MOV SP,R0	: SP,*			

SEQ 0319

27-Mar-1982 19:24:42 TOPS
 27-Mar-1982 19:23:44 PA:<

Address	OpCode	Operand1	Operand2	Operand3	Instruction	Comment	Address
14693							
14694							
14695							
14696	076350	104414			TRAP	14	
14697	076352	016616	000056		MOV	56(SP), (SP)	
14698	076356	017646	000056		MOV	@56(SP), -(SP)	: DBL.VALUE,*
14699	076362	012746	006710		MOV	#FMT12A, -(SP)	: DBL.VALUE,*
14700	076366	012746	000003		MOV	#3, -(SP)	
14701	076372	010600			MOV	SP, R0	
14702	076374	104414			TRAP	14	: SP,*
14703	076376	062766	010000	000064	ADD	#10000, 64(SP)	
14704	076404	016616	000064		MOV	64(SP), (SP)	: *, DBL.VALUE
14705	076410	017646	000064		MOV	@64(SP), -(SP)	: DBL.VALUE,*
14706	076414	012746	006756		MOV	#FMT12B, -(SP)	: DBL.VALUE,*
14707	076420	012746	000003		MOV	#3, -(SP)	
14708	076424	010600			MOV	SP, R0	
14709	076426	104414			TRAP	14	: SP,*
14710	076430	112763	000010	034446	MOVB	#10, WHY.DROPT(R3)	
14711	076436	104455			TRAP	55	: *,*(LUN)
14712	076440	012270			.WORD	12270	
14713	076442	011070			.WORD	MSG1	
14714	076444	000000			.WORD	0	
14715	076446	010300			MOV	R3, R0	
14716	076450	104451			TRAP	51	: LUN,*
14717	076452	062706	000046		ADD	#46, SP	
14718	076456	000506			BR	20\$	
14719	076460	020427	000001		CMP	R4, #1	
14720	076464	001031			BNE	16\$: VALUE,*
14721	076466	012746	000006		MOV	#6, -(SP)	
14722	076472	016646	000050		MOV	50(SP), -(SP)	
14723	076476	010346			MOV	R3, -(SP)	: COMMAND,*
14724	076500	010246			MOV	R2, -(SP)	: LUN,*
14725	076502	016646	000054		MOV	54(SP), -(SP)	: WRDCNT,*
14726	076506	010146			MOV	R1, -(SP)	: PTR,*
14727	076510	004767	147510		JSR	PC, RETRY	: SECTOR,*
14728	076514	062706	000014		ADD	#14, SP	
14729	076520	005700			TST	R0	
14730	076522	001662			BEQ	12\$	
14731	076524	112763	000004	034446	MOVB	#4, WHY.DROPT(R3)	
14732	076532	104455			TRAP	55	: *,*(LUN)
14733	076534	012271			.WORD	12271	
14734	076536	011070			.WORD	MSG1	
14735	076540	000000			.WORD	0	
14736	076542	010300			MOV	R3, R0	
14737	076544	104451			TRAP	51	: LUN,*
14738	076546	000450			BR	19\$	
14739	076550	020427	000002		CMP	R4, #2	
14740	076554	001012			BNE	17\$: VALUE,*
14741	076556	112763	000005	034446	MOVB	#5, WHY.DROPT(R3)	
14742	076564	104455			TRAP	55	: *,*(LUN)
14743	076566	012272			.WORD	12272	
14744	076570	011070			.WORD	MSG1	
14745	076572	000000			.WORD	0	
14746	076574	010300			MOV	R3, R0	
14747	076576	104451			TRAP	51	: LUN,*

:MLX4

TESTING RANDOM SECTORS, DATA, WORD COUNTS

14\$:
15\$:

16\$:

Address	OpCode	Operand1	Operand2	Operand3	Operand4	Instruction	Comments	Address	Time	Page
14749										
14750										
14751										
14752	076600	000433				BR	19\$			
14753	076602	020427	000003			CMP	R4,#3			
14754	076606	001012				BNE	18\$			7683
14755	076610	104455				TRAP	55			7637
14756	076612	012273				.WORD	12273			
14757	076614	011070				.WORD	MSG1			7688
14758	076616	000000				.WORD	0			
14759	076620	112763	000006	034446		MOVB	#6,WHY.DROPT(R3)			
14760	076626	010300				MOV	R3,R0			7689
14761	076630	104451				TRAP	51			7690
14762	076632	000416				BR	19\$			
14763	076634	020427	000004			CMP	R4,#4			7691
14764	076640	001017				BNE	21\$			7637
14765	076642	004767	140464			JSR	PC,ISOLATE			
14766	076646	104455				TRAP	55			7696
14767	076650	012274				.WORD	12274			7697
14768	076652	011120				.WORD	MSG2			
14769	076654	000000				.WORD	0			
14770	076656	112763	000007	034446		MOVB	#7,WHY.DROPT(R3)			
14771	076664	010300				MOV	R3,R0			7698
14772	076666	104451				TRAP	51			7699
14773	076670	062706	000024			ADD	#24,SP			
14774	076674	000167	001044			JMP	42\$			7700
14775	076700	020427	000005			CMP	R4,#5			
14776	076704	001157				BNE	28\$			7637
14777	076706	004767	140420			JSR	PC,ISOLATE			
14778	076712	032767	000001	103340		BIT	#1,ERROUT			7705
14779	076720	001423				BEQ	22\$			7707
14780	076722	017705	135462			MOV	@ML.REG+42,R5			
14781	076726	006205				ASR	R5			
14782	076730	006205				ASR	R5			
14783	076732	006205				ASR	R5			
14784	076734	006205				ASR	R5			
14785	076736	006205				ASR	R5			
14786	076740	006205				ASR	R5			
14787	076742	042705	177700			BIC	#177700,R5			
14788	076746	010546				MOV	R5, -(SP)			
14789	076750	012746	006640			MOV	#FMT108, -(SP)			
14790	076754	012746	000002			MOV	#2, -(SP)			
14791	076760	010600				MOV	SP,R0			
14792	076762	104414				TRAP	14			
14793	076764	062706	000006			ADD	#6,SP			
14794	076770	017766	135416	000052	22\$	MOV	@ML.REG+44,52(SP)			
14795	076776	017705	135406			MOV	@ML.REG+42,R5			7710
14796	077002	006205				ASR	R5			7711
14797	077004	006205				ASR	R5			
14798	077006	006205				ASR	R5			
14799	077010	006205				ASR	R5			
14800	077012	006205				ASR	R5			
14801	077014	006205				ASR	R5			
14802	077016	042705	177700			BIC	#177700,R5			
14803	077022	010566	000042			MOV	R5,42(SP)			

SEQ 0323

Address	Hex	Hex	Hex	Hex	Hex	Operation	Comment	Time	PA
14917									
14918									
14919									
14920	077524	016646	000030			MOV	30(SP),-(SP)	27-Mar-1982 19:24:42	TOPS
14921	077530	016646	000040			MOV	40(SP),-(SP)	27-Mar-1982 19:23:44	PA:<
14922	077534	004767	146464			JSR	PC,RETRY		
14923	077540	062706	000014			ADD	#14,SP		
14924	077544	020027	000005			CMP	R0,#5		
14925	077550	001051				BNE	37\$		
14926	077552	027766	134634	000026		CMP	@ML.REG+44,26(SP)		
14927	077560	001034				BNE	36\$		7798
14928	077562	016646	000016			MOV	16(SP),-(SP)		
14929	077566	017700	134616			MOV	@ML.REG+42,R0		
14930	077572	006200				ASR	R0		
14931	077574	006200				ASR	R0		
14932	077576	006200				ASR	R0		
14933	077600	006200				ASR	R0		
14934	077602	006200				ASR	R0		
14935	077604	006200				ASR	R0		
14936	077606	042700	177700			BIC	#177700,R0		
14937	077612	020026				CMP	R0,(SP)+		
14938	077614	001016				BNE	36\$		
14939	077616	032767	000001	102434		BIT	#1,ERROUT		
14940	077624	001404				BEQ	35\$		7802
14941	077626	104456				TRAP	56		
14942	077630	012300				.WORD	12300		7807
14943	077632	011202				.WORD	MSG4		
14944	077634	000000				.WORD	0		
14945	077636	010346			35\$:	MOV	R3,-(SP)		
14946	077640	016746	134476			MOV	BOARD,-(SP)		7810
14947	077644	004767	137552			JSR	PC,UP.HARD.COUNT		
14948	077650	000426				BR	39\$		
14949	077652	032767	000001	102400	36\$:	BIT	#1,ERROUT		7798
14950	077660	001415				BEQ	38\$		7815
14951	077662	104457				TRAP	57		
14952	077664	012301				.WORD	12301		7820
14953	077666	011166				.WORD	MSG3		
14954	077670	000000				.WORD	0		
14955	077672	000410				BR	38\$		
14956	077674	032767	000001	102356	37\$:	BIT	#1,ERROUT		7823
14957	077702	001404				BEQ	38\$		7829
14958	077704	104457				TRAP	57		
14959	077706	012302				.WORD	12302		7834
14960	077710	011166				.WORD	MSG3		
14961	077712	000000				.WORD	0		
14962	077714	010346			38\$:	MOV	R3,-(SP)		
14963	077716	016746	134420			MOV	BOARD,-(SP)		7837
14964	077722	004767	140156			JSR	PC,UP.SOFT.COUNT		
14965	077726	022626			39\$:	CMP	(SP)+,(SP)+		
14966	077730	005205			40\$:	INC	R5		7768
14967	077732	020566	000010		41\$:	CMP	R5,10(SP)		7764
14968	077736	101002				BHI	42\$		
14969	077740	000167	177370			JMP	33\$		
14970	077744	005203			42\$:	INC	R3		
14971	077746	020366	000012		43\$:	CMP	R3,12(SP)		7557

SEQ 0324

```
14973
14974 :MLX4
14975 :
14976 077752 002002          BGE 44$
14977 077754 000167 175540  JMP 2$
14978 077760 005266 000030 44$: INC 30(SP)
14979 077764 026666 000030 000050 CMP 30(SP),50(SP) : COUNT
14980 077772 003002          BGT 45$ : COUNT,REPEAT
14981 077774 000167 175504  JMP 1$
14982 100000 062706 000032 45$: ADD #32,SP
14983 100004 000207          RTS PC :
14984
14985 ; Routine Size: 625 words
14986 ; Maximum stack depth per invocation: 38 words
14991
14992
```

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

7554

7487

14994 :MLX4
 14995 :
 14996 :
 14997 :
 14998 :
 14999 :
 15000 :
 15001 :
 15002 :
 15003 :
 15004 :
 15005 :
 15006 :
 15007 :
 15008 :
 15009 :
 15010 :
 15011 :
 15012 :
 15013 :
 15014 :
 15015 :
 15016 :
 15017 :
 15018 :
 15019 :
 15020 :
 15021 :
 15022 :
 15023 :
 15024 :
 15025 :
 15026 :
 15027 :
 15028 :
 15029 :
 15030 :
 15031 :
 15032 :
 15033 :
 15034 :
 15035 :
 15036 :
 15037 :
 15038 :
 15039 :
 15040 :
 15041 :
 15042 :
 15043 :
 15044 :
 15045 :
 15046 :
 15047 :
 15048 :

7851
 7852
 7853
 7854
 7855
 7856
 7857
 7858
 7859
 7860
 7861
 7862
 7863
 7864
 7865
 7866
 7867
 7868
 7869
 7870
 7871
 7872
 7873
 7874
 7875
 7876
 7877
 7878
 7879
 7880
 7881
 7882
 7883
 7884
 7885
 7886
 7887
 7888
 7889
 7890
 7891
 7892
 7893
 7894
 7895
 7896
 7897
 7898
 7899
 7900
 7901
 7902

```

TESTING RANDOM UNITS, SECTORS, DATA, WORD COUNT 27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
routine RAND4 (REPFAT) : novalue = 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (47)
begin                                     !* 1 * START OF ROUTINE
++
ROUTINE:      RAND4(REPEAT)
PURPOSE:      TO CHECK RANDOM UNITS
ARGUMENT:     REPEAT = NUMBER OF TIMES TO EXECUTE ENTIRE ROUTINE
THE CODE FOR 'RAND4' IN BRIEF:
BEGIN 1 (START OF ROUTINE)
SAY ROUTINE IS RUNNING
INCR COUNT FROM 1 TO REPEAT
: BEGIN 2 (START OF REPEAT LOOP FOR THIS ROUTINE)
: GENERATE THE RANDOM PATTERN
: TIMES = NUMBER OF UNITS * 4
: INCR KOUNT FROM 1 TO TIMES
: : BEGIN 3 (START OF COUNTING LOOP FOR UNIT SELECTION)
: : CHOOSE A RANDOM LOGICAL UNIT WHICH IS ACTIVE
: : INITIALIZE BUFFER POINTERS
: : TESTLOOP:
: : : BEGIN 4 (START OF LOOP THAT COMPLETELY TESTS 1 UNIT)
: : : INCR KOUNT2 FROM 1 TO 10
: : : : BEGIN 5 (START OF COUNTING LOOP FOR SECTOR SELECTION)
: : : : CHOOSE A RANDOM WORD COUNT
: : : : SET UP BUFFER POINTERS BEFORE TRANSFER
: : : : CHOOSE A RANDOM SECTOR
: : : : CALCULATE WHERE TRANSFER WILL END (BASED ON WORD COUNT)
: : : : IF CALCULATED VALUE GTR HIGHEST
: : : : THEN ADJUST THE WORD COUNT SO IT FITS
: : : : WITHIN THE TESTABLE SECTOR LIMITS
: : : : WRITE
: : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : CHOOSE WHETHER TO WRITE CHECK GR READ
: : : : DO THE WRITE CHECK OR READ
: : : : LOOK FOR ERRORS (IF DROP UNIT, LEAVE TESTLOOP)
: : : : CHANGE BUFFER POINTERS AFTER TRANSFER
: : : : END 5 (END OF COUNTING LOOP FOR SECTOR SELECTION)
: : : : END 4 (END OF TESTLOOP)
: : : : END 3 (END OF COUNTING LOOP FOR UNIT SELECTION)
: : : : END 2 (END OF REPEAT LOOP FOR THIS ROUTINE)
RETURN
END 1 (END OF ROUTINE)

--
local
  LUN,
  WRDCNT,
  SECTOR,
  
```

```

15050 :MLX4
15051 :
15052 : TESTING RANDOM UNITS, SECTORS, DATA, WORD COUNT
15053 : 7903 VALUE,
15054 : 7904 OLDSEC,
15055 : 7905 OLDCHN,
15056 : 7906 PTR,
15057 : 7907 COMMAND,
15058 : 7908 DBL_VALUE;
15059 : 7909
15060 : 7910 Label
15061 : 7911 LOOP;
15062 : 7912
15063 : PRINTB (SAY1, RTN5D);
15064 : !'RAND4'
15065 : 7915
15066 : 7916 incr COUNT from 1 to .REPEAT do
15067 : 7917 begin
15068 : 7918 GENS ();
15069 : 7919
15070 : 7920 incr KOUNT from 1 to (.NUM_DRIVES*4) do
15071 : 7921 begin
15072 : 7922 LUN = RNDU ();
15073 : 7923 L$LUN = .LUN;
15074 : 7924 WPTR = WBUFF;
15075 : 7925 RPTR = RBUFF;
15076 : 7926 LOOP :
15077 : 7927 begin
15078 : 7928
15079 : 7929 incr KOUNT2 from 1 to 10 do
15080 : 7930 begin
15081 : 7931 WRDCNT = RNDWC ();
15082 : 7932 SET PTRS (.WRDCNT);
15083 : 7933 SECTOR = RNDSEC (.LUN);
15084 : 7934
15085 : 7935 if (.SECTOR + .WRDCNT/256) gtra HIGHEST then WRDCNT = 256*(HIGHEST - .SECTOR + 1);
15086 : 7936 VALUE = write (.LUN, .WRDCNT, .WPTR, .SECTOR);
15087 : 7937
15088 : 7938 !+
15089 : 7939 ! SEE HOW SUCCESSFUL THE WRITE WAS:
15090 : 7940 !-
15091 : 7941
15092 : 7942
15093 : 7943 selectone .VALUE of
15094 : 7944 set
15095 : 7945 !SEE 'SYSERR' FOR DEFINITION
15096 : 7946 !OF ERROR # CONTAINED IN 'VALUE'
15097 : 7947
15098 : 7948 [1] :
15099 : 7949 begin
15100 : 7950 !* 5A * RETRY ALLOWED
15101 : 7951 if RETRY (SIX, write, .LUN, .WRDCNT, .WPTR, .SECTOR) neq 0
15102 : 7952 then
15103 : 7953 begin
15104 : 7954 WHY DROPT [.LUN] = CODE_4;
ERRDF (5401, MSG1, 0); !**** OPTION 5, RAND4 ERROR 01 ****
DODU (.LUN);
  
```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (47)


```

15106 :MLX4
15107 :
15108 :
15109 : 7955
15110 : 7956
15111 : 7957
15112 : 7958
15113 : 7959
15114 : 7960
15115 : 7961
15116 : 7962
15117 : 7963
15118 : 7964
15119 : 7965
15120 : 7966
15121 : 7967
15122 : 7968
15123 : 7969
15124 : 7970
15125 : 7971
15126 : 7972
15127 : 7973
15128 : 7974
15129 : 7975
15130 : 7976
15131 : 7977
15132 : 7978
15133 : 7979
15134 : 7980
15135 : 7981
15136 : 7982
15137 : 7983
15138 : 7984
15139 : 7985
15140 : 7986
15141 : 7987
15142 : 7988
15143 : 7989
15144 : 7990
15145 : 7991
15146 : 7992
15147 : 7993
15148 : 7994
15149 : 7995
15150 : 7996
15151 : 7997
15152 : 7998
15153 : 7999
15154 : 8000
15155 : 8001
15156 : 8002
15157 : 8003
15158 : 8004
15159 : 8005
15160 : 8006

TESTING RANDOM (UNITS, SECTORS, DATA, WORD COUNT) 27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (47)

leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end;
end; !* 5A *
[2] :
begin !* 5B * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED
WHY DROPT [.LUN] = CODE_5;
ERRDF (5402, MSG1, 0); !**** OPTION 5, RAND4 ERROR 02 ****
DODU (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end; !* 5B *
[3] :
begin !* 5C * FATAL DRIVE ERROR -- NO RETRY ALLOWED
ERRDF (5403, MSG1, 0); !**** OPTION 5, RAND4 ERROR 03 ****
WHY DROPT [.LUN] = CODE_6;
DODD (.LUN);
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *
end; !* 5C *
tes;
COMMAND = CHOOSE ();
if .COMMAND eql read
then
begin
PTR = .RPTR;
VALUE = read (.LUN, .WRDCNT, .RPTR, .SECTOR);
end
else
begin
PTR = .WPTR;
VALUE = CHECK (.LUN, .WRDCNT, .WPTR, .SECTOR);
end;
!+
!- SEE HOW SUCCESSFUL THE OPERATION WAS:
selectone .VALUE of !SEE 'SYSERR' FOR DEFINITION
set !OF ERROR # CONTAINED IN 'VALUE'
[0] :
if .COMMAND eql read
then
begin
if (DBL_VALUE = DOUBLE_CHECK (.WPTR, .RPTR, .WRDCNT)) neq 0
then
begin

```

15162 :MLX4
15163 :
15164 :
15165 : 8007
15166 : 8008
15167 : 8009
15168 : 8010
15169 : 8011
15170 : 8012
15171 : 8013
15172 : 8014
15173 : 8015
15174 : 8016
15175 : 8017
15176 : 8018
15177 : 8019
15178 : 8020
15179 : 8021
15180 : 8022
15181 : 8023
15182 : 8024
15183 : 8025
15184 : 8026
15185 : 8027
15186 : 8028
15187 : 8029
15188 : 8030
15189 : 8031
15190 : 8032
15191 : 8033
15192 : 8034
15193 : 8035
15194 : 8036
15195 : 8037
15196 : 8038
15197 : 8039
15198 : 8040
15199 : 8041
15200 : 8042
15201 : 8043
15202 : 8044
15203 : 8045
15204 : 8046
15205 : 8047
15206 : 8048
15207 : 8049
15208 : 8050
15209 : 8051
15210 : 8052
15211 : 8053
15212 : 8054
15213 : 8055
15214 : 8056
15215 : 8057
15216 : 8058

TESTING RANDOM UNITS, SECTORS, DATA, WORD COUNT 27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (47)

```
SAYWHO (.LUN);  
PRINTB (SAY1, MSG5);  
!'ECC LOGIC FAILED TO DETECT DATA ERROR'  
PRINTB (FMT12A, ..DBL VALUE, .DBL VALUE);  
!'GOOD DATA: XXXXXX AT LOCATION YYYYYY'  
DBL VALUE = .DBL VALUE + BUFSIZ*2;  
PRINTB (FMT12B, ..DBL VALUE, .DBL VALUE);  
!'BAD DATA: PPPPPP AT LOCATION QQQQQQ'  
WHY DROPT [.LUN] = CODE_8;  
ERRDF (5404, MSG1, 0); !**** OPTION 5, RAND4 ERROR 04 ****  
DODU (.LUN);  
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *  
end;  
  
end;  
  
[1] :  
begin !* 5D * RETRY ALLOWED  
if RETRY (SIX, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) neq 0  
then !THE RETRY FAILED -- SYSTEM FATAL ERROR  
begin  
WHY DROPT [.LUN] = CODE_4;  
ERRDF (5405, MSG1, 0); !**** OPTION 5, RAND4 ERROR 05 ****  
DODU (.LUN);  
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *  
end;  
  
end; !* 5D *  
  
[2] :  
begin !* 5E * FATAL CONTROLLER ERROR -- NO RETRY ALLOWED  
WHY DROPT [.LUN] = CODE_5;  
ERRDF (5406, MSG1, 0); !**** OPTION 5, RAND4 ERROR 06 ****  
DODU (.LUN);  
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *  
end; !* 5E *  
  
[3] :  
begin !* 5F * FATAL DRIVE ERROR -- NO RETRY ALLOWED  
ERRDF (5407, MSG1, 0); !**** OPTION 5, RAND4 ERRGR 07 ****  
WHY DROPT [.LUN] = CODE_6;  
DODD (.LUN);  
leave LOOP; !JUMP JUST BEYOND END OF BLOCK * 4 *  
end; !* 5F *  
  
[4] :  
begin !* 5G * UNRECOVERABLE DATA ERROR  
ISOLATE ();  
ERRDF (5408, MSG2, 0); !**** OPTION 5, RAND4 ERROR 08 ****  
WHY DROPT [.LUN] = CODE_7;  
DODD (.LUN);
```

```

15218 :MLX4
15219 :
15220 : TESTING RANDOM UNITS, SECTORS, DATA, WORD COUNT
15221 : 8059
15222 : 8060
15223 : 8061
15224 : 8062
15225 : 8063
15226 : 8064
15227 : 8065
15228 : 8066
15229 : 8067
15230 : 8068
15231 : 8069
15232 : 8070
15233 : 8071
15234 : 8072
15235 : 8073
15236 : 8074
15237 : 8075
15238 : 8076
15239 : 8077
15240 : 8078
15241 : 8079
15242 : 8080
15243 : 8081
15244 : 8082
15245 : 8083
15246 : 8084
15247 : 8085
15248 : 8086
15249 : 8087
15250 : 8088
15251 : 8089
15252 : 8090
15253 : 8091
15254 : 8092
15255 : 8093
15256 : 8094
15257 : 8095
15258 : 8096
15259 : 8097
15260 : 8098
15261 : 8099
15262 : 8100
15263 : 8101
15264 : 8102
15265 : 8103
15266 : 8104
15267 : 8105
15268 : 8106
15269 : 8107
15270 : 8108
15271 : 8109
15272 : 8110

                Leave LOOP;
                end;
                !* 5G *

[5] :
begin
ISOLATE ();
                !* 5H * RECOVERABLE DATA ERROR

if .ERROUT then PRINTB (FMT10B, .CHAN);

!' BIT 00'
OLDSEC = .MLEL;
OLDCHN = .CHAN;

if RETRY (ONE, .COMMAND, .LUN, .WRDCNT, .PTR, .SECTOR) eql 5
then
    or ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
    then
        begin
            if .ERROUT then ERRHRD (5409, MSG4, 0); !*** OPTION 5, RAND4 ERROR 09 ***
            UP_HARD_COUNT (.LUN, .BOARD);
        end
    else
        begin
            if .ERROUT then ERRSOFT (5410, MSG3, 0);
            UP_SOFT_COUNT (.LUN, .BOARD);
            !*** OPTION 5, RAND4 ERROR 10 ***
        end
    else
        begin
            if .ERROUT then ERRSOFT (5411, MSG3, 0); !*** OPTION 5, RAND4 ERROR 11 ***
            UP_SOFT_COUNT (.LUN, .BOARD);
        end;
    end;
end;
                !* 5H *

tes;
WPTR = .WPTR + 2;
end;
                !* 5 * END OF COUNTING LOOP FOR SECTOR SELECTION

!+
! Test to see if this uut's address space is
! to be read for soft errors. This test is
! is intended for DMT purposes.
!-

```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (47)

```

15274 :MLX4
15275 :
15276 : TESTING RANDOM UNITS, SECTORS, DATA, WORD COUNT
15277 : 8111
15278 : 8112
15279 : if .EFNS21 !Is the background pattern to be read
15280 : then
15281 : begin
15282 : 8116
15283 : 8117
15284 : 8118
15285 : 8119
15286 : 8120
15287 : 8121
15288 : 8122
15289 : 8123
15290 : 8124
15291 : 8125
15292 : 8126
15293 : 8127
15294 : 8128
15295 : 8129
15296 : 8130
15297 : 8131
15298 : 8132
15299 : 8133
15300 : 8134
15301 : 8135
15302 : 8136
15303 : 8137
15304 : 8138
15305 : 8139
15306 : 8140
15307 : 8141
15308 : 8142
15309 : 8143
15310 : 8144
15311 : 8145
15312 : 8146
15313 : 8147
15314 : 8148
15315 : 8149
15316 : 8150
15317 : 8151
15318 : 8152
15319 : 8153
15320 : 8154
15321 : 8155
15322 : 8156
15323 : 8157
15324 : 8158
15325 : 8159
15326 : P 8160
15327 : P 8161
15328 : 8162

: version czmlbb changed incr to incru
incru SECTOR from LOWEST to HIGHEST do
  if read (.LUN, 256, RBUFF, .SECTOR) eql 5
  then
    begin
      ISOLATE (); !Find the failing bank and board no.
      if .ERROUT then PRINTB (FMT10B, .CHAN);
      : Print where the error is
      : Save the contents of the ML error location
      : register so we can compare it to the new
      : contents of this register after the retry.
      : This is done to classify the error.
      OLDSEC = .MLEL;
      OLDCHN = .CHAN;
      : Do a classify retry call. If the same error
      : occurs then classify it as a hard error. If
      : a different error occurred or the error went away
      : then classify it as a soft error.
      if RETRY (ONE, .COMMAND, .LUN, 256, .PTR, .OLDSEC) eql 5
      then
        : The same error occurred so see if it is at the same
        : sector and channel number, if so then classify
        : it as a hard error else classify it as a soft
        : error.
        if ((.MLEL eql .OLDSEC) and (.CHAN eql .OLDCHN))
        then
          begin !Same error occurred 'hard'
            if .ERROUT !Print error if enabled
            then
              begin
                ERRHRD (5412, !Error number
                MSG4, !Error message
                0); !Additional message routine
          end
        end
      end
    end
  end

```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (47)

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (47)

15330 :MLX4
15331 :
15332 :
15333 : 8163
15334 : 8164
15335 : 8165
15336 : 8166
15337 : 8167
15338 : 8168
15339 : 8169
15340 : 8170
15341 : 8171
15342 : 8172
15343 : P 8173
15344 : P 8174
15345 : 8175
15346 : 8176
15347 : 8177
15348 : 8178
15349 : 8179
15350 : 8180
15351 : 8181
15352 : 8182
15353 : 8183
15354 : 8184
15355 : 8185
15356 : 8186
15357 : P 8187
15358 : P 8188
15359 : 8189
15360 : 8190
15361 : 8191
15362 : 8192
15363 : 8193
15364 : 8194
15365 : 8195
15366 : 8196
15367 : 8197
15368 : 8198
15369 : 8199
15370 : 8200
15371 : 8201
15372 : 8202
15373 : 8203
15374 : 8204
15375 : 8205
15379 :
15380 :
15384 100006 004167 105322

```
TESTING RANDOM UNITS, SECTORS, DATA, WORD COUNT  
end;  
UP_HARD_COUNT (.LUN, .BOARD);  
end  
else  
begin  
!Not the same error 'soft'  
if .ERROUT  
!Print error if enabled  
then  
begin  
ERRSOFT (5413, !Error number  
MSG3, !Error message  
0); !Additional message routine  
end;  
UP_SOFT_COUNT (.LUN, .BOARD);  
end  
else  
begin  
!Not the same error 'soft'  
if .ERROUT  
!Print error if enabled  
then  
begin  
ERRSOFT (5414, !Error number  
MSG3, !Error message  
0); !Additional message routine  
end;  
UP_SOFT_COUNT (.LUN, .BOARD);  
end;  
end;  
end;  
end;  
end;  
end;  
return;  
end;
```

!* 4 * END OF LOOP THAT COMPLETELY TESTS 1 UNIT
!* 3 * END OF COUNTING LOOP FOR UNIT SELECTION
!* 2 * END OF REPEAT LOOP FOR THIS ROUTINE
!* 1 * END OF ROUTINE

RAND4: .SBTTL RAND4 TESTING RANDOM UNITS, SECTORS, DATA, WORD COUNT
JSR R1,\$SAVE5 ;

Address	Offset	Value	Label	Instruction	Comment	Time	Page
15442							
15443			:MLX4				
15444			:				
15445	100274	012746	000006	MOV	#6,-(SP)	27-Mar-1982 19:24:42	TOPS
15446	100300	012746	045424	MOV	#WRITE,-(SP)	27-Mar-1982 19:23:44	PA:<
15447	100304	010246		MOV	R2,-(SP)		7949
15448	100306	010346		MOV	R3,-(SP)		
15449	100310	016746	132354	MOV	WPTR,-(SP)		
15450	100314	010146		MOV	R1,-(SP)		
15451	100316	004767	145702	JSR	PC,RETRY		
15452	100322	062706	000014	ADD	#14,SP		
15453	100326	005700		TST	R0		
15454	100330	001446		BEQ	9\$		
15455	100332	112762	000004 034446	MOVB	#4,WHY.DROPT(R2)		
15456	100340	104455		TRAP	55		7952
15457	100342	012431		.WORD	12431		7953
15458	100344	011070		.WORD	MSG1		
15459	100346	000000		.WORD	0		
15460	100350	010200		MOV	R2,R0		
15461	100352	104451		TRAP	51		7954
15462	100354	000431		BR	7\$		
15463	100356	020427	000002 5\$:	CMP	R4,#2		7955
15464	100362	001012		BNE	6\$		7943
15465	100364	112762	000005 034446	MOVB	#5,WHY.DROPT(R2)		
15466	100372	104455		TRAP	55		7962
15467	100374	012432		.WORD	12432		7963
15468	100376	011070		.WORD	MSG1		
15469	100400	000000		.WORD	0		
15470	100402	010200		MOV	R2,R0		
15471	100404	104451		TRAP	51		7964
15472	100406	000414		BR	7\$		
15473	100410	020427	000003 6\$:	CMP	R4,#3		7965
15474	100414	001014		BNE	9\$		7943
15475	100416	104455		TRAP	55		
15476	100420	012433		.WORD	12433		7970
15477	100422	011070		.WORD	MSG1		
15478	100424	000000		.WORD	0		
15479	100426	112762	000006 034446	MOVB	#6,WHY.DROPT(R2)		
15480	100434	010200		MOV	R2,R0		7971
15481	100436	104451		TRAP	51		7972
15482	100440	062706	000010 7\$:	ADD	#10,SP		
15483	100444	000535		BR	14\$		7973
15484	100446	004767	145514 8\$:	JSR	PC,CHOOSE		
15485	100452	010066	000040 9\$:	MOV	R0,40(SP)		7977
15486	100456	005005		CLR	R5		
15487	100460	020027	045612	CMP	R0,#READ		7979
15488	100464	001014		BNE	10\$		
15489	100466	005205		INC	R5		
15490	100470	016766	132176 000036	MOV	RPTR,36(SP)		
15491	100476	010246		MOV	R2,-(SP)		7982
15492	100500	010346		MOV	R3,-(SP)		7983
15493	100502	016746	132164	MOV	RPTR,-(SP)		
15494	100506	010146		MOV	R1,-(SP)		
15495	100510	004767	145076	JSR	PC,READ		
15496	100514	000412		BR	11\$		

Address	Offset	Word Count	Count	Label	Instruction	Comments	Time	Page
15498								
15499								
15500								
15501	100516	016766	132146	000036	10\$:	MOV WPTR,36(SP)	27-Mar-1982 19:24:42	TOPS
15502	100524	010246				MOV R2,-(SP)	27-Mar-1982 19:23:44	PA:<
15503	100526	010346				MOV R3,-(SP)		7987
15504	100530	016746	132134			MOV WPTR,-(SP)		7988
15505	100534	010176				MOV R1,-(SP)		
15506	100536	004767	145236			JSR PC,CHECK		
15507	100542	010004			11\$:	MOV R0,R4		
15508	100544	001076				BNE 15\$		
15509	100546	006005				ROR R5		7995
15510	100550	103402				BLO 13\$		8000
15511	100552	000167	000750		12\$:	JMP 28\$		
15512	100556	016746	132106		13\$:	MOV WPTR,-(SP)		
15513	100562	016746	132104			MOV RPTR,-(SP)		8004
15514	100566	010346				MOV R3,-(SP)		
15515	100570	004767	143532			JSR PC,DOUBLE.CHECK		
15516	100574	062706	000006			ADD #6,SP		
15517	100600	010066	000042			MOV R0,42(SP)		
15518	100604	001762				BEQ 12\$		
15519	100606	010246				MOV R2,-(SP)		
15520	100610	004767	134710			JSR PC,SAYWHO		8007
15521	100614	012716	011216			MOV #MSG5,(SP)		
15522	100620	012746	007072			MOV #SAY1,-(SP)		8008
15523	100624	012746	000002			MOV #2,-(SP)		
15524	100630	010600				MOV SP,R0		
15525	100632	104414				TRAP 14		
15526	100634	016616	000050			MOV 50(SP),(SP)		
15527	100640	017646	000050			MOV @50(SP),-(SP)		
15528	100644	012746	006710			MOV #FMT12A,-(SP)		8010
15529	100650	012746	000003			MOV #3,-(SP)		
15530	100654	010600				MOV SP,R0		
15531	100656	104414				TRAP 14		
15532	100660	062766	010000	000056		ADD #10000,56(SP)		
15533	100666	016616	000056			MOV 56(SP),(SP)		8012
15534	100672	017646	000056			MOV @56(SP),-(SP)		8013
15535	100676	012746	006756			MOV #FMT12B,-(SP)		
15536	100702	012746	000003			MOV #3,-(SP)		
15537	100706	010600				MOV SP,R0		
15538	100710	104414				TRAP 14		
15539	100712	112762	000010	034446		MOVB #10,WHY.DROPT(R2)		
15540	100720	104455				TRAP 55		8015
15541	100722	012434				.WORD 12434		8016
15542	100724	011070				.WORD MSG1		
15543	100726	000000				.WORD 0		
15544	100730	010200				MOV R2,R0		
15545	100732	104451				TRAP 51		8017
15546	100734	062706	000042			ADD #42,SP		
15547	100740	000506			14\$:	BR 20\$		8018
15548	100742	020427	000001		15\$:	CMP R4,#1		
15549	100746	001031				BNE 16\$		7995
15550	100750	012746	000006			MOV #6,-(SP)		
15551	100754	016646	003052			MOV 52(SP),-(SP)		8026
15552	100760	010246				MOV R2,-(SP)		

Address	Offset	Count	Label	Instruction	Comments	Date/Time	Page
15554			:MLX4				
15555			:				
15556				TESTING RANDOM UNITS, SECTORS, DATA, WORD COUNT		27-Mar-1982 19:24:42	TOPS
15557	100762	010346		MOV R3, -(SP)		27-Mar-1982 19:23:44	PA:<
15558	100764	016646	000056	MOV 56(SP), -(SP)	: WRDCNT, *		
15559	100770	010146		MOV R1, -(SP)	: PTR, *		
15560	100772	004767	145226	JSR PC, RETRY	: SECTOR, *		
15561	100776	062706	000014	ADD #14, SP			
15562	101002	005700		TST R0			
15563	101004	001662		BEQ 12\$			
15564	101006	112762	000004 034446	MOVB #4, WHY.DROPT(R2)	: *, *(LUN)		8029
15565	101014	104455		TRAP 55	:		8030
15566	101016	012435		.WORD 12435			
15567	101020	011070		.WORD MSG1			
15568	101022	000000		.WORD 0			
15569	101024	010200		MOV R2, R0	: LUN, *		8031
15570	101026	104451		TRAP 51			
15571	101030	000450		BR 19\$			
15572	101032	020427	000002	CMP R4, #2	: VALUE, *		8032
15573	101036	001012		BNE 17\$			7995
15574	101040	112762	000005 034446	MOVB #5, WHY.DROPT(R2)	: *, *(LUN)		8039
15575	101046	104455		TRAP 55	:		8040
15576	101050	012436		.WORD 12436			
15577	101052	011070		.WORD MSG1			
15578	101054	000000		.WORD 0			
15579	101056	010200		MOV R2, R0	: LUN, *		8041
15580	101060	104451		TRAP 51			
15581	101062	000433		BR 19\$			
15582	101064	020427	000003	CMP R4, #3	: VALUE, *		8042
15583	101070	001012		BNE 18\$			7995
15584	101072	104455		TRAP 55	:		8047
15585	101074	012437		.WORD 12437			
15586	101076	011070		.WORD MSG1			
15587	101100	000000		.WORD 0			
15588	101102	112762	000006 034446	MOVB #6, WHY.DROPT(R2)	: *, *(LUN)		8048
15589	101110	010200		MOV R2, R0	: LUN, *		8049
15590	101112	104451		TRAP 51			
15591	101114	000416		BR 19\$			
15592	101116	020427	000004	CMP R4, #4	: VALUE, *		8050
15593	101122	001017		BNE 21\$			7995
15594	101124	004767	136202	JSR PC, ISOLATE			
15595	101130	104455		TRAP 55	:		8055
15596	101132	012440		.WORD 12440			8056
15597	101134	011120		.WORD MSG2			
15598	101136	000000		.WORD 0			
15599	101140	112762	000007 034446	MOVB #7, WHY.DROPT(R2)	: *, *(LUN)		8057
15600	101146	010200		MOV R2, R0	: LUN, *		8058
15601	101150	104451		TRAP 51			
15602	101152	062706	000020	ADD #20, SP	:		8059
15603	101156	000167	001042	JMP 40\$			
15604	101162	020427	000005	CMP R4, #5	: VALUE, *		7995
15605	101166	001157		BNE 28\$			
15606	101170	004767	136136	JSR PC, ISOLATE			
15607	101174	032767	000001 101056	BIT #1, ERR0UT	:		8064
15608	101202	001423		BEQ 22\$:		8066

Address	Offset	Value	Label	Instruction	Comments	Count	Address	Offset	Value	Label
15610			:MLX4							
15611			:							
15612			:							
15613	101204	017705	133200	MOV	@ML.REG+42,R5					
15614	101210	006205		ASR	R5					
15615	101212	006205		ASR	R5					
15616	101214	006205		ASR	R5					
15617	101216	006205		ASR	R5					
15618	101220	006205		ASR	R5					
15619	101222	006205		ASR	R5					
15620	101224	042705	177700	BIC	#177700,R5					
15621	101230	010546		MOV	R5,-(SP)					
15622	101232	012746	006640	MOV	#FMT10B,-(SP)					
15623	101236	012746	000002	MOV	#2,-(SP)					
15624	101242	010600		MOV	SP,R0					
15625	101244	104414		TRAP	14					: SP,*
15626	101246	062706	000006	ADD	#6,SP					
15627	101252	017766	133134	MOV	@ML.REG+44,44(SP)					: *,OLDSEC
15628	101260	017705	133124	MOV	@ML.REG+42,R5					
15629	101264	006205		ASR	R5					
15630	101266	006205		ASR	R5					
15631	101270	006205		ASR	R5					
15632	101272	006205		ASR	R5					
15633	101274	006205		ASR	R5					
15634	101276	006205		ASR	R5					
15635	101300	042705	177700	BIC	#177700,R5					
15636	101304	010566	000040	MOV	R5,40(SF)					: *,OLDCHN
15637	101310	012746	000001	MOV	#1,-(SP)					
15638	101314	016646	000052	MOV	52(SP),-(SP)					: COMMAND,*
15639	101320	010246		MOV	R2,-(SP)					: LUN,*
15640	101322	010346		MOV	R3,-(SP)					: WRDCNT,*
15641	101324	016646	000056	MOV	56(SP),-(SP)					: PTR,*
15642	101330	010146		MOV	R1,-(SP)					: SECTOR,*
15643	101332	004767	144666	JSR	PC,RETRY					
15644	101336	062706	000014	ADD	#14,SP					
15645	101342	020027	000005	CMP	R0,#5					
15646	101346	001051		BNE	25\$					
15647	101350	027766	133036	CMP	@ML.REG+44,44(SP)					: *,OLDSEC
15648	101356	001034	000044	BNE	24\$					
15649	101360	016600	000040	MOV	40(SP),R0					: OLDCHN,*
15650	101364	017705	133020	MOV	@ML.REG+42,R5					
15651	101370	006205		ASR	R5					
15652	101372	006205		ASR	R5					
15653	101374	006205		ASR	R5					
15654	101376	006205		ASR	R5					
15655	101400	006205		ASR	R5					
15656	101402	006205		ASR	R5					
15657	101404	042705	177700	BIC	#177700,R5					
15658	101410	020500		CMP	R5,R0					
15659	101412	001016		BNE	24\$					
15660	101414	032767	000001	BIT	#1,ERROUT					
15661	101422	001404	100636	BEQ	23\$: 8079
15662	101424	104456		TRAP	56					
15663	101426	012441		.WORD	12441					
15664	101430	011202		.WORD	MSG4					

Address	Offset	Count	Label	Instruction	Comment	Date/Time	Page
15666							
15667			:M1 X4				
15668			:				
15669	101432	000000		.WORD	0		
15670	101434	010246		MOV	R2,-(SP)		
15671	101436	016746	23\$:	MOV	BOARD,-(SP)	: LUN,*	8081
15672	101442	004767	132700	JSR	PC,UP.HARD.COUNT		
15673	101446	000426		BR	27\$		
15674	101450	032767	000001	24\$:	BIT	#1,ERRRUT	8075
15675	101456	001415		BEQ	26\$		8086
15676	101460	104457		TRAP	57		
15677	101462	012442		.WORD	12442		
15678	101464	011166		.WORD	MSG3		
15679	101466	000000		.WORD	0		
15680	101470	000410		BR	26\$		
15681	101472	032767	000001	25\$:	BIT	#1,ERRRUT	8089
15682	101500	001404		BEQ	26\$		8095
15683	101502	104457		TRAP	57		
15684	101504	012443		.WORD	12443		
15685	101506	011166		.WORD	MSG3		
15686	101510	000000		.WORD	0		
15687	101512	010246		26\$:	MOV	R2,-(SP)	: LUN,*
15688	101514	016746	132622	MOV	BOARD,-(SP)		8097
15689	101520	004767	136360	JSR	PC,UP.SOFT.COUNT		
15690	101524	022626		27\$:	CMP	(SP)+,(SP)+	
15691	101526	062767	000002	28\$:	ADD	#2,WPTR	8063
15692	101534	062706	000020	ADD	#20,SP		8103
15693	101540	005266	000006	INC	6(SP)		7930
15694	101544	026627	000006	000012	CMP	6(SP),#12	: KOUNT2
15695	101552	003002		BGT	29\$: KOUNT2,*	7929
15696	101554	000167	176376	JMP	3\$		
15697	101560	032767	000001	29\$:	BIT	#1,EFNS21	
15698	101566	001002		BNE	30\$		8112
15699	101570	000167	000430	JMP	40\$		
15700	101574	017666	000010	30\$:	MOV	@10(SP),10(SP)	
15701	101602	016600	000012	MOV	12(SP),R0		8119
15702	101606	016005	034460	MOV	LOW.SECT(R0),R5		
15703	101612	000577		BR	39\$: *,SECTOR	
15704	101614	010246		31\$:	MOV	R2,-(SP)	: LUN,*
15705	101616	012746	000400	MOV	#400,-(SP)		8121
15706	101622	012746	022670	MOV	#RBUF,-(SP)		
15707	101626	010546		MOV	R5,-(SP)	: SECTOR,*	
15708	101630	004767	143756	JSR	PC,READ		
15709	101634	062706	000010	ADD	#10,SP		
15710	101640	020027	000005	CMP	R0,#5		
15711	101644	001161		BNE	38\$		
15712	101646	004767	135460	JSR	PC,ISOLATE		
15713	101652	032767	000001	100400	BIT	#1,ERRRUT	: 8124
15714	101660	001423		BEQ	32\$		8126
15715	101662	017700	132522	MOV	@ML.REG+42,R0		
15716	101666	006200		ASR	R0		
15717	101670	006200		ASR	R0		
15718	101672	006200		ASR	R0		
15719	101674	006200		ASR	R0		
15720	101676	006200		ASR	R0		

Address	Offset	Value	Label	Instruction	Comment	Time	Page
15722							
15723			:MLX4				
15724			:				
15725	101700	006200		ASR	R0		
15726	101702	042700	177700	BIC	#177700,R0		
15727	101706	010046		MOV	R0,-(SP)		
15728	101710	012746	006640	MOV	#FMT108,-(SP)		
15729	101714	012746	000002	MOV	#2,-(SP)		
15730	101720	010600		MOV	SP,R0		
15731	101722	1044;		TRAP	14	: SP,*	
15732	101724	062706	000006	ADD	46,SP		
15733	101730	017766	132456	MOV	@ML.REG+44,24(SP)	: *,OLDSEC	
15734	101736	01770C	132446	MOV	@ML.REG+42,R0	:	8135
15735	101742	006200		ASR	R0	:	8136
15736	101744	006200		ASR	R0		
15737	101746	006200		ASR	R0		
15738	101750	006200		ASR	R0		
15739	101752	006200		ASR	R0		
15740	101754	006200		ASR	R0		
15741	101756	042700	177700	BIC	#177700,R0		
15742	101762	010066	000020	MOV	R0,20(SP)	: *,OLDCHN	
15743	101766	012746	000001	MOV	#1,-(SP)	:	
15744	101772	016646	000032	MOV	32(SP),-(SP)	: COMMAND,*	8144
15745	101776	010246		MOV	R2,-(SP)	: LUN,*	
15746	102000	012746	000400	MOV	#400,-(SP)		
15747	102004	016646	000036	MOV	36(SP),-(SP)	: PTR,*	
15748	102010	016646	000036	MOV	36(SP),-(SP)	: OLDSEC,*	
15749	102014	004767	144204	JSR	PC,RETRY		
15750	102020	062706	000014	ADD	#14,SP		
15751	102024	020027	000905	CMP	R0,#5		
15752	102030	001051		BNE	35\$		
15753	102032	027766	132354	CMP	@ML.REG+44,24(SP)	: *,OLDSEC	
15754	102040	001034		BNE	34\$		8153
15755	102042	016646	000020	MOV	20(SP),-(SP)	: OLDCHN,*	
15756	102046	017700	132336	MOV	@ML.REG+42,R0		
15757	102052	006200		ASR	R0		
15758	102054	006200		ASR	R0		
15759	102056	006200		ASR	R0		
15760	102060	006200		ASR	R0		
15761	102062	006200		ASR	R0		
15762	102064	006200		ASR	R0		
15763	102066	042700	177700	BIC	#177700,R0		
15764	102072	020026		CMP	R0,(SP)+		
15765	102074	001016		BNE	34\$		
15766	102076	032767	000001	BIT	#1,ERROUT	:	8157
15767	102104	001404		BEQ	33\$:	
15768	102106	104456		TRAP	56	:	8162
15769	102110	012444		.WORD	12444		
15770	102112	011202		.WORD	MSG4		
15771	102114	000000		.WORD	0		
15772	102116	010246		MOV	R2,-(SP)	: LUN,*	
15773	102120	016746	132216	MOV	BOARD,-(SP)		8165
15774	102124	004767	135272	JSR	PC,UP.HARD.COUNT		
15775	102130	000426		BR	37\$:	
15776	102132	032767	000001	BIT	#1,ERROUT	:	8153 8170

Address	Offset	Value	Label	Instruction	Comment	Address	Value	Label
15778			:MLX4					
15779			:					
15780				TESTING RANDOM UNITS, SECTORS, DATA, WORD COUNT		27-Mar-1982 19:24:42		TOPS
15781	102140	001415		BEQ	36\$	27-Mar-1982 19:23:44		PA:<
15782	102142	104457		TRAP	57			
15783	102144	012445		.WORD	12445			8175
15784	102146	011166		.WORD	MSG3			
15785	102150	000000		.WORD	0			
15786	102152	000410		BR	36\$			
15787	102154	032767	000001 100076	35\$: BIT	#1,ERROUT			8178
15788	102162	001404		BEQ	36\$			8184
15789	102164	104457		TRAP	57			
15790	102166	012446		.WORD	12446			8189
15791	102170	011166		.WORD	MSG3			
15792	102172	000000		.WORD	0			
15793	102174	010246		36\$: MOV	R2,-(SP)			
15794	102176	016746	132140	MOV	BOARD,-(SP)		: LUN,*	8192
15795	102202	004767	135676	JSR	PC,UP.SOFT.COUNT			
15796	102206	022626		37\$: CMP	(SP)+,(SP)+			
15797	102210	005205		38\$: INC	R5			8123
15798	102212	020566	000010	39\$: CMP	R5,10(SP)		: SECTOR	8119
15799	102216	101602		BHI	40\$: SECTOR,*	
15800	102220	000167	177370	JMP	31\$			
15801	102224	005266	000014	40\$: INC	14(SP)		: KOUNT	
15802	102230	026666	000014 000016	CMP	14(SP),16(SP)		: KOUNT,*	7920
15803	102236	003002		BGT	41\$			
15804	102240	000167	175632	JMP	2\$			
15805	102244	005266	000032	41\$: INC	32(SP)		: COUNT	
15806	102250	026666	000032 000052	CMP	32(SP),52(SP)		: COUNT,REPEAT	7916
15807	102256	003002		BGT	42\$			
15808	102260	000167	175562	JMP	1\$			
15809	102264	062706	000034	42\$: ADD	#34,SP			
15810	102270	000207		RTS	PC			7852

: Routine Size: 602 words
 : Maximum stack depth per invocation: 37 words

15811
 15812
 15813
 15818
 15819

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (48)

15821 :MLX4
 15822 :
 15823 :
 15824 :
 15825 :
 15826 :
 15827 :
 15828 :
 15829 :
 15830 :
 15831 :
 15832 :
 15833 :
 15834 :
 15835 :
 15836 :
 15837 :
 15838 :
 15839 :
 15840 :
 15841 :
 15842 :
 15843 :
 15844 :
 15845 :
 15846 :
 15847 :
 15848 :
 15849 :
 15850 :
 15851 :
 15852 :
 15853 :
 15854 :
 15855 :
 15856 :
 15857 :
 15858 :
 15859 :
 15860 :
 15861 :
 15862 :
 15863 :
 15864 :
 15865 :
 15866 :
 15867 :
 15868 :
 15869 :
 15870 :
 15871 :
 15872 :
 15873 :
 15874 :
 15875 :

8206
 8207
 8208
 8209
 8210
 8211
 8212
 8213
 8214
 8215
 8216
 8217
 8218
 8219
 8220
 8221
 8222
 8223
 8224
 8225
 8226
 8227
 8228
 8229
 8230
 8231
 8232
 8233
 8234
 8235
 8236
 8237
 8238
 8239
 8240
 8241
 8242
 8243
 8244
 8245
 8246
 8247
 8248
 8249
 8250
 8251
 8252
 8253
 8254
 8255
 8256
 8257

DEFINITION OF OPTION 5

```
%sbttl 'DEFINITION OF OPTION 5'
routine OPT5 : novalue =
begin
```

!* 1 *

!+
 !-
 !+

ROUTINE: OPT5

PURPOSE: TO EXERCISE THE ML11 SYSTEMS UNDER TEST IN A RANDOM MANNER, SO AS TO SIMULATE THE FLEXIBILITY OF TESTING THAT WOULD BE DONE BY AN OPERATING SYSTEM.

THERE ARE 4 RANDOM TESTS WHICH ARE CALLED BY 'OPT5' TO ACCOMPLISH ALL TESTING. IT IS THE RESPONSIBILITY OF THIS ROUTINE TO DECIDE HOW MANY TIMES THOSE 4 RANDOM TESTS WILL BE EXECUTED. REFER TO 'RAND1' TO 'RAND4' ABOVE FOR MORE INFORMATION.

local REPEAT;

PRINTB (SAY2, WRD34, RTN5);
 !'RUNNING OPT5'

REPEAT = 9 - .NUM_DRIVES;
 !FEWER TIMES EACH RANDOM TEST WILL BE RUN.

!THE MORE UNITS THERE ARE ON THE SYSTEM, THE

incr LUN from 0 to (.LSUNIT - 1) do
 begin

!SEE IF THERE ARE ANY UNITS
 !* 2 *

!WHICH HAVE 64K CHIPS (ML11-B)

if .DRIVE_STATUS [.LUN] eql ACTIVE
 then

begin
 UNIT = .DRIVE;

!* 3 *

if .MLDT
 then

begin
 REPEAT = 1;
 !LOWER THE REPEAT TIME FOR ALL TESTABLE UNITS.
 exitloop;
 end;

!* 4 *
 !THERE IS AT LEAST 1 UNIT WHICH IS AN ML11-B, SO

!* 4 *

end;

!* 3 *

end;

!* 2 *

!+
 !-
 !+
 AT THIS POINT, 'REPEAT' IS BASED ON THE SYSTEM CONFIGURATION. NOW WEIGHT THE LOOP COUNTS OF THE 4 RANDOM TESTS SO THAT RAND1 AND RAND2 ARE MUCH QUICKER THAN RAND3 AND RAND4. RAND3 IS LONGEST.

RAND1 (.REPEAT);

!TEST USING RANDOM DATA

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEALE>MLX4.BLI.5 (48)

!TEST USING RANDOM DATA, WORD COUNTS
 !TEST USING RANDOM SECTORS, DATA, WORD COUNTS
 !TEST USING RANDOM UNITS, SECTORS, DATA, WORD COUNTS

!* 1 *

```

15877 :MLX4
15878 :
15879 :
15880 :      8258      RAND2 (.REPEAT);
15881 :      8259      RAND3 (.REPEAT);
15882 :      8260      RAND4 ((.REPEAT*16));
15883 :      8261      return;
15884 :      8262      end;
15888 :
15889 :
  
```

```

15893 102272 004167 103016      OPT5:  .SBTTL  OPT5 DEFINITION OF OPTION 5
15894 102276 012746 007656      JSR     R1,$SAVE4
15895 102302 012746 007344      MOV     #RTN5,-(SP)
15896 102306 012746 007100      MOV     #WRD34,-(SP)
15897 102312 012746 000003      MOV     #SAY2,-(SP)
15898 102316 010600      MOV     #3,-(SP)
15899 102320 104414      MOV     SP,R0
15900 102322 012703 000011      TRAP   14
15901 102326 166703 132124      MOV     #11,R3
15902 102332 016704 077454      SUB     NUM.DRIVES,R3
15903 102336 005001      MOV     L$UNIT,R4
15904 102340 000450      CLR     R1
15905 102342 010102      BR      3$
15906 102344 006202      1$:    MOV     R1,R2
15907 102346 006202      ASR     R2
15908 102350 006202      ASR     R2
15909 102352 062702 034442      ASR     R2
15910 102356 010246      ADD     #DRIVE.STATUS,R2
15911 102360 010146      MOV     R2,-(SP)
15912 102362 042716 177770      MOV     R1,-(SP)
15913 102366 012746 000001      BIC     #177770,(SP)
15914 102372 005046      MOV     #1,-(SP)
15915 102374 004767 101756      CLR     -(SP)
15916 102400 062706 000010      JSR     PC,BLSGT2
15917 102404 005300      ADD     #10,SP
15918 102406 001074      DEC     R0
15919 102410 010102      BNE     2$
15920 102412 006302      MOV     R1,R2
15921 102414 016202 034422      ASL     R2
15922 102420 016200 000006      MOV     PTABLE.ADDR(R2),R2
15923 102424 042700 177770      MOV     6(R2),R0
15924 102430 142777 000007 131720      BIC     #177770,R0
15925 102436 150077 131714      BICB   #7,@ML.REG+10
15926 102442 032777 000001 131724      BISB   R0,@ML.REG+10
15927 102450 001403      BIT     #1,@ML.REG+26
15928 102452 012703 000001      BEQ     2$
15929 102456 000403      MOV     #1,R3
15930 102460 005201      BR      4$
15931 102462 020104      2$:    INC     R1
      3$:    CMP     R1,R4
  
```

8207
8227

8229

8232

8235

8238

8240

8243

8245

8232

15933
15934
15935
15936 102464 002726
15937 102466 010316
15938 102470 004767 166044
15939 102474 010316
15940 102476 004767 170422
15941 102502 010316
15942 102504 004767 172734
15943 102510 010300
15944 102512 006300
15945 102514 006300
15946 102516 006300
15947 102520 006300
15948 102522 010016
15949 102524 004767 175256
15950 102530 062706 000010
15951 102534 000207
15952
15953
15954
15959
15960

:MLX4
:

DEFINITION OF OPTION 5

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

4\$:
BLT 1\$
MOV R3,(SP)
JSR PC,RAND1 : REPEAT,*
MOV R3,(SP)
JSR PC,RAND2 : REPEAT,*
MOV R3,(SP)
JSR PC,RAND3 : REPEAT,*
MOV R3,R0 : REPEAT,*
ASL R0
ASL R0
ASL R0
ASL R0
MOV R0,(SP)
JSR PC,RAND4
ADD #10,SP
RTS PC :

8257

8258

8259

8260

8207

: Routine Size: 82 words
: Maximum stack depth per invocation: 13 words

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (49)

```

15962 :MLX4
15963 :
15964 :
15965 :      8263 %sbttl 'THE OPTION SCHEDULER'
15966 :      8264 BGNTST;
15967 :      8265
15968 :      8266 :++
15969 :      8267 ROUTINE: T1
15970 :      8268
15971 :      8269 PURPOSE: THIS IS THE ONE MAIN TEST OF THE EXERCISER. IT LOOKS
15972 :      8270 AT THE AVAILABILITY OF TEST OPTIONS AND MAKES CALLS TO
15973 :      8271 THE OPTIONS WHEN APPROPRIATE.
15974 :      8272
15975 :      8273 THE QUICK VERIFY PASS INCLUDES THE FOLLOWING ROUTINES:
15976 :      8274
15977 :      8275 (1) INTEGRITY
15978 :      8276 (2) OPT1
15979 :      8277 (3) OPT2
15980 :      8278 (4) OPT3
15981 :      8279
15982 :      8280 SUBSEQUENT PASSES INCLUDE:
15983 :      8281
15984 :      8282 (1) OPT1
15985 :      8283 (2) OPT2
15986 :      8284 (3) OPT3
15987 :      8285 (4) OPT4
15988 :      8286 (5) OPT5
15989 :      8287 :--
15990 :      8288
15991 :      8289 if .QUICK neq 0
15992 :      8290 then
15993 :      8291 begin
15994 :      8292 PRINTB (CRLF);
15995 :      8293 PRINTB (SAY3, WRD2, PHR2, WRD4);
15996 :      8294 !'BEGIN QUICK VERIFY PASS'
15997 :      8295 INTEGRITY ();
15998 :      8296 end;
15999 :      8297
16000 :      8298 if .DROP1 eql 0
16001 :      8299 then
16002 :      8300 OPT1 ();
16003 :      8301
16004 :      8302 if .DROP2 eql 0
16005 :      8303 then
16006 :      8304 OPT2 ();
16007 :      8305
16008 :      8306 if .DROP3 eql 0
16009 :      8307 then
16010 :      8308 OPT3 ();
16011 :      8309
16012 :      8310 if .QUICK eql 0
16013 :      8311 then
16014 :      8312 begin
16015 :      8313
16016 :      8314 if .DROP4 eql 0
    
```

!THIS IS THE QUICK VERIFY PASS

!OPTION 1 IS AVAILABLE

!OPTION 2 IS AVAILABLE

!OPTION 3 IS AVAILABLE

27-Mar-1982 19:24:42 TOPS-20 Bliss-16 V2(212)
 27-Mar-1982 19:23:44 PA:<NEAL2>MLX4.BLI.5 (49)

'OPTION 4 IS AVAILABLE

!OPTION 5 IS AVAILABLE

```

16018 ;MLX4
16019 :
16020 THE OPTION SCHEDULER
16021 : 8315 then
16022 : 8316 OPT4 ();
16023 : 8317
16024 : 8318 if .DROP5 eql 0
16025 : 8319 then
16026 : 8320 OPT5 ();
16027 : 8321
16028 : 8322 end;
16029 : 8323
16030 : 8324 ENDTST;
    
```

Address	Hex	Dec	Hex	Label	Code	Comment	Address
16039	102536	005767	130132	\$T1:	.SBTTL	\$T1 THE OPTION SCHEDULER	
16040	102542	001426			TST	QUICK	8289
16041	102544	012746	007066		BEQ	1\$	
16042	102550	012746	000001		MOV	#CRLF,-(SP)	8292
16043	102554	010600			MOV	#1,-(SP)	
16044	102556	104414			MOV	SP,R0	SP,*
16045	102560	012716	007212		TRAP	14	
16046	102564	012746	007730		MOV	#WRD4,(SP)	8293
16047	102570	012746	007200		MOV	#PHR2,-(SP)	
16048	102574	012746	007112		MOV	#WRD2,-(SP)	
16049	102600	012746	000004		MOV	#SAY3,-(SP)	
16050	102604	010600			MOV	#4,-(SP)	
16051	102606	104414			MOV	SP,R0	SP,*
16052	102610	004767	144416		TRAP	14	
16053	102614	062706	000014		JSR	PC,INTEGRITY	8295
16054	102620	005767	077412	1\$:	ADD	#14,SP	8291
16055	102624	001002			TST	DROP1	8298
16056	102626	004767	146626		BNE	2\$	
16057	102632	005767	077402	2\$:	JSR	PC,OPT1	8300
16058	102636	001002			TST	DROP2	8302
16059	102640	004767	151210		BNE	3\$	
16060	102644	005767	077372	3\$:	JSR	PC,OPT2	8304
16061	102650	001002			TST	DROP3	8306
16062	102652	004767	155174		BNE	4\$	
16063	102656	005767	130012	4\$:	JSR	PC,OPT3	8308
16064	102662	001012			TST	QUICK	8310
16065	102664	005767	077354		BNE	6\$	
16066	102670	001002			TST	DROP4	8314
16067	102672	004767	157546		BNE	5\$	
16068	102676	005767	077346	5\$:	JSR	PC,OPT4	8316
16069	102702	001002			TST	DROP5	8318
16070	102704	004767	177362		BNE	6\$	
16071	102710	000207		6\$:	JSR	PC,OPT5	8320
16072					RTS	PC	8262

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

16074
16075
16076
16077
16078
16083
16084
16088
16089
16093 102712
16094 102712 004767 177620
16095 102716 104466
16096 102720 006000
16097 102722 103773
16098 102724 000207
16099
16100
16101
16106
16107

:MLX4
:
THE OPTION SCHEDULER
:
: Routine Size: 54 words
: Maximum stack depth per invocation: 6 words

.SBTTL T1 THE OPTION SCHEDULER

T1::
1\$: JSR PC,\$T1
TRAP 66
ROR R0
BLO 1\$
RTS PC

8322

: Routine Size: 6 words
: Maximum stack depth per invocation: 0 words

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (50)

16109 :MLX4
16110 :
16111 :
16112 :
16113 :
16114 :
16115 :
16116 :
16117 :
16118 :
16119 :
16120 :
16121 :
16122 :
16123 :
16124 :
16125 :
16126 :
16127 :
16128 :
16129 :
16130 :
16131 :
16132 :
16133 :
16134 :
16135 :
16136 :
16137 :
16138 :
16139 :
16140 :
16141 :
16142 :
16143 :
16144 :
16145 :
16146 :
16147 :
16148 :
16149 :
16150 :
16151 :
16152 :
16153 :
16154 :
16155 :
16156 :
16157 :
16158 :
16159 :
16160 :
16161 :
16162 :
16163 :

END OF PASS SUMMARY

%sbttl 'END OF PASS SUMMARY'
routine EOP : novalue =
begin

!* 1 *

++

ROUTINE: EOP

PURPOSE: TO PRINT A STATUS REPORT FOR EACH DRIVE. IF AN
ARRAY HAS ANY HARD OR SOFT ERRORS, THEN ITS ERROR
COUNT WILL APPEAR, AND IF THE COUNT IS TOO HIGH,
THEN A DIAGNOSIS TO RUN THE ML11 PROM MAINTENANCE
PROGRAM WILL ALSO APPEAR.

THE FOLLOWING IS A SAMPLE REPORT FOR 2 DRIVES:

PERFORMANCE SUMMARY

NUMBER OF MBYTES TRANSFERRED:
1028 MBYTES WRITTEN
250 MBYTES READ
1145 MBYTES WRITE CHECKED

LOGICAL UNIT: 0 DRIVE: 1 SERIAL #: 1234
SOFT ERROR COUNT: 9
ARRAY 3: 9
HARD ERROR COUNT: 11
ARRAY 0: 6
ARRAY 10: 2
ARRAY 15: 3
TRANSFER RETRIES: 0

LOGICAL UNIT: 1 DRIVE: 1 SERIAL #: 9876
DRIVE DROPPED (CONTROLLER FATAL ERROR)
SOFT ERROR COUNT: 100
ARRAY 1: 9 --> RUN ML11 PROM MAINTENANCE PROGRAM
ARRAY 13: 10 --> RUN ML11 PROM MAINTENANCE PROGRAM
ARRAY 14: 1
ARRAY 15: 2
HARD ERROR COUNT: 2
ARRAY 14: 1
ARRAY 15: 1
TRANSFER RETRIES: 0

Local

SFT_TOT,
HRD_TOT,
TRY_TOT:

if .EOPSUM
then

!THE OPERATOR HAS ALLOWED THE SUMMARY TO PRINT

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(21?)
PA:<NEALE>MLX4.BLI.5 (50)

16165 :MLX4
16166 :
16167 :
16168 :
16169 :
16170 :
16171 :
16172 :
16173 :
16174 :
16175 :
16176 :
16177 :
16178 :
16179 :
16180 :
16181 :
16182 :
16183 :
16184 :
16185 :
16186 :
16187 :
16188 :
16189 :
16190 :
16191 :
16192 :
16193 :
16194 :
16195 :
16196 :
16197 :
16198 :
16199 :
16200 :
16201 :
16202 :
16203 :
16204 :
16205 :
16206 :
16207 :
16208 :
16209 :
16210 :
16211 :
16212 :
16213 :
16214 :
16215 :
16216 :
16217 :
16218 :
16219 :

END OF PASS SUMMARY

```
begin
PRINTB (CRLF);
PRINTB (SAY1, PHR17);
!'PERFORMANCE SUMMARY'
PRINTB (CRLF);
PRINTB (SAY1, PHR12);
!NUMBER OF MBYTES TRANSFERED:
PRINTB (FMT14, .WR MILLIONS, PHR19);
!'XXXXX MBYTES WRITTEN'
PRINTB (FMT14, .WR MILLIONS, PHR20);
!'XXXXX MBYTES READ'
PRINTB (FMT14, .WC MILLIONS, PHR13);
!'XXXXX MBYTES WRITE CHECKED'

incr LUN from 0 to (.LSUNIT - 1) do
begin
UNIT = .DRIVE;
if .DPR eq 0
then
PRINTB (FMT4A, PHR7, .LUN, WRD11, .DRIVE)
!'LOGICAL UNIT: X DRIVE: Y'
else
SAYWHO (.LUN);

!'LOGICAL UNIT: X DRIVE: Y SERIAL #: ZZZZ'

if .DROPT_DRIVES [.LUN] eq 1 ACTIVE
then
begin
PRINTB (SAY2, WRD11, WRD21);
!'DRIVE DROPPED'

selectone .WHY_DROPT [.LUN] of
set
[CODE 1] :
PRINTB (FMT2, CAUSE1);
!' (NOT POWERED UP)'
[CODE 2] :
PRINTB (FMT2, CAUSE2);
!' (NOT AN ML11 UNIT)'
[CODE 3] :
PRINTB (FMT2, CAUSE3);
!' (OPERATOR SELECTED TEST LIMITS INCORRECTLY)'
[CODE 4] :
PRINTB (FMT2, CAUSE4);
!' (ALL RETRIES FAILED FOR A NON-FATAL ERROR)'
```

!* 2 *

!* 3 *

!* 4 *

```
16221 :MLX4
16222 :
16223 :           END OF PASS SUMMARY
16224 :           8429
16225 :           8430
16226 :           8431
16227 :           8432
16228 :           8433
16229 :           8434
16230 :           8435
16231 :           8436
16232 :           8437
16233 :           8438
16234 :           8439
16235 :           8440
16236 :           8441
16237 :           8442
16238 :           8443
16239 :           8444
16240 :           8445
16241 :           8446
16242 :           8447
16243 :           8448
16244 :           8449
16245 :           8450
16246 :           8451
16247 :           8452
16248 :           8453
16249 :           8454
16250 :           8455
16251 :           8456
16252 :           8457
16253 :           8458
16254 :           8459
16255 :           8460
16256 :           8461
16257 :           8462
16258 :           8463
16259 :           8464
16260 :           8465
16261 :           8466
16262 :           8467
16263 :           8468
16264 :           8469
16265 :           8470
16266 :           8471
16267 :           8472
16268 :           8473
16269 :           8474
16270 :           8475
16271 :           8476
16272 :           8477
16273 :           8478
16274 :           8479
16275 :           8480

[CODE 5] :
PRINTB (FMT2, CAUSE5);
!' (CONTROLLER FATAL ERROR)'

[CODE 6] :
PRINTB (FMT2, CAUSE6);
!' (DRIVE FATAL ERROR)'

[CODE 7] :
PRINTB (FMT2, CAUSE7);
!' (ECC HARD ERROR)'

[CODE 8] :
PRINTB (FMT2, CAUSE8);
!' (ECC LOGIC FAILURE)'
tes;

end;
!* 4 *

SFT_TOT = 0;
HRD_TOT = 0;
TRY_TOT = 0;

incr ARRAY from 0 to 15 do
begin
SFT_TOT = .SFT_TOT + .SOFTS [.LUN, .ARRAY, 0, 16, 0];
HRD_TOT = .HRD_TOT + .HARDS [.LUN, .ARRAY, 0, 16, 0];
TRY_TOT = .TRY_TOT + .TRIES [.LUN, .ARRAY, 0, 16, 0];
end;

PRINTB (FMT7, PHRS, .SFT_TOT);
!' SOFT ERROR COUNT: DDDDD'

if .SFT_TOT neq 0
then
incr ARRAY from 0 to 15 do
if .SOFTS [.LUN, .ARRAY, 0, 16, 0] neq 0
then
begin
PRINTB (FMT9, .ARRAY, .SOFTS [.LUN, .ARRAY, 0, 16, 0]);
!' ARRAY XX: YYYYY'
end;
end;

VER CZMLBB THE FOLLOWING CODE HAS BEEN COMMENTED OUT BECAUSE SOFT ERRORS
SHOULD NOT BE COUNTED TOWARD THE CALLING OUT OF THE PROM MAINEANCE PROGRAM
+
NOW SEE IF THRESHOLDS FOR SOFT ERRORS
HAVE BEEN REACHED FOR THIS ARRAY BOARD:

if ((.ARR_TYP eql 0) and (.SOFTS [.LUN, .ARRAY, 0, 16, 0] geq S16K_LIMIT))
```

```
16277 :MLX4
16278 :
16279 :
16280 : 8481
16281 : 8482
16282 : 8483
16283 : 8484
16284 : 8485
16285 : 8486
16286 : 8487
16287 : 8488
16288 : 8489
16289 : 8490
16290 : 8491
16291 : 8492
16292 : 8493
16293 : 8494
16294 : 8495
16295 : 8496
16296 : 8497
16297 : 8498
16298 : 8499
16299 : 8500
16300 : 8501
16301 : 8502
16302 : 8503
16303 : 8504
16304 : 8505
16305 : 8506
16306 : 8507
16307 : 8508
16308 : 8509
16309 : 8510
16310 : 8511
16311 : 8512
16312 : 8513
16313 : 8514
16314 : 8515
16315 : 8516
16316 : 8517
16317 : 8518
16318 : 8519
16319 : 8520
16320 : 8521
16321 : 8522
16322 : 8523
16323 : 8524
16324 : 8525
16325 : 8526
16326 : 8527
16327 : 8528
16328 : 8529
16329 : 8530
16330 : 8531
16331 : 8532

END OF PASS SUMMARY

then
  PRINTB (FMT2, MSG2);
!' --> RUN ML11 PROM MAINTENANCE PROGRAM'
if ((.ARR_TYP eq 1) and (.SOFTS [.LUN, .ARRAY, 0, 16, 0] geq S64K_LIMIT))
then
  PRINTB (FMT2, MSG2);
!' --> RUN ML11 PROM MAINTENANCE PROGRAM'
end;

PRINTB (FMT7, PHR18, .HRD_TOT);
!' HARD ERROR COUNT: DDDDD'
if .HRD_TOT neq 0
then
  incr ARRAY from 0 to 15 do
    if .HARDS [.LUN, .ARRAY, 0, 16, 0] neq 0
    then
      begin
        PRINTB (FMT9, .ARRAY, .HARDS [.LUN, .ARRAY, 0, 16, 0]);
        !' ARRAY XX: YYYYYY'
        !+
        ! NOW SEE IF THRESHOLDS FOR HARD ERRORS
        ! HAVE BEEN REACHED FOR THIS ARRAY BOARD:
        !-
      end
    end
  end

VER CZMLBB CHANGED TESTING HARDs [TABLE] TO TESTING PM_SBE_CNT [TABLE]

if ((.ARR_TYP eq 0) and (.PM_SBE_CNT [.LUN, .ARRAY, PM_SBE$_SUM] geq H16K_LIMIT))
then
  PRINTB (FMT2, MSG2);
!' --> RUN ML11 PROM MAINTENANCE PROGRAM'

VER CZMLBB CHANGED TESTING HARDs [TABLE] TO TESTING PM_SBE_CNT [TABLE]

if ((.ARR_TYP eq 1) and (.PM_SBE_CNT [.LUN, .ARRAY, PM_SBE$_SUM] geq H64K_LIMIT))
then
  PRINTB (FMT2, MSG2);
!' --> RUN ML11 PROM MAINTENANCE PROGRAM'
end;

PRINTB (FMT7, PHR6, .TRY_TOT);
```

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (50)

27-Mar-1982 19:24:42
27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
PA:<NEALE>MLX4.BLI.5 (50)

```

16333 :MLX4
16334 :
16335
16336      8533
16337      8534
16338      8535
16339      8536
16340      8537
16341      8538
16342      8539
16343      8540
16344      8541
16345      P 8542
16346      P 8543
16347      8544
16348      8545
16349      8546
16350      8547
16351      8548
16352      8549
16353      8550
16354      8551
16355      8552
16356      8553
16357      8554
16358      8555
16359      8556
16360      8557
16361      8558
16362      8559
16363      8560
16364      8561
16365      8562
16366      8563
16367      8564
16368      8565
16369      8566
16370      8567
16371      8568
16372      8569
16373      8570
16374      8571
16375      8572
16376      8573
16377      8574
16378      P 8575
16379      P 8576
16380      P 8577
16381      P 8578
16382      P 8579
16383      8580
16384      8581
16385      8582
16386      8583
16387      8584

```

```

END OF PASS SUMMARY

! ' TRANSFER RETRIES: DDDD'

if .TRY_TOT neq 0
then
    incr ARRAY from 0 to 15 do
        if .TRIES [.LUN, .ARRAY, 0, 16, 0] neq 0
        then
            PRINTB (FMT9, .ARRAY,
                .TRIES [.LUN,
                    .ARRAY, 0, 16, 0]);

! ' ARRAY XX: YYYYY'
end;          !* 3 *

+
Examine the number of single
bit errors detected during
execution of the exerciser
thus far. If any were detected
then print them out to the
operator.
-

if .SBES_COUNT gtr ZERO
then
begin
PRINTB (CRLF);
PRINTB (SAY1, PHR21);          !Print single bit log summary report
PRINTB (CRLF);
PRINTB (SAY1, SBES$HEADER);   !Print the column headings

+
Print to the console terminal for the
operator review all the detected single
bit errors during the execution of this
exerciser thus far.
-

incr index from 0 to .SBES_COUNT - 1 do    !Print all errors logged in this table
begin
PRINTB (FMT16, .SBES_LOG [.index, UNITS$ SBE], !This is the printing format
    .SBES_LOG [.index, BRDS$ SBE], !Print the failing unit of this sbe
    .SBES_LOG [.index, BNKS$ SBE], !Print the failing board number
    .SBES_LOG [.index, BITS$ SBE], !Print the failing bank number
    .SBES_LOG [.index, SUMS$ SBE]); !Print the failing bit number
end;
end;

```


27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (50)

16389 :MLX4
 16390 :
 16391 :
 16392 : 8585
 16393 : 8586
 16394 : 8587
 16395 : 8588
 16396 : 8589
 16400 :
 16401 :

END OF PASS SUMMARY

PRINTB (CRLF);
 end;

return;
 end;

!* 2 *

!* 1 *

Address	Instruction	Operand 1	Operand 2	Operand 3	Label	Comment	Address
16405	102726	004167	102402		EOP:	.SBTTL EOP END OF PASS SUMMARY	
16406	102732	162706	000010			JSR P1,\$SAVE5	8326
16407	102736	032767	000001	077312		SUB #10,SP	
16408	102744	001002				BIT #1,EOPSUM	8375
16409	102746	000167	001744			BNE 1\$	
16410	102752	012746	007066		1\$:	JMP 32\$	
16411	102756	012746	000001			MOV #CRLF,-(SP)	8378
16412	102762	010600				MOV #1,-(SP)	
16413	102764	104414				MOV SP,R0	: SP,*
16414	102766	012716	010342			TRAP 14	
16415	102772	012746	007072			MOV #PHR17,(SP)	
16416	102776	012746	000002			MOV #SAY1,-(SP)	8379
16417	103002	010600				MOV #2,-(SP)	
16418	103004	104414				MOV SP,R0	: SP,*
16419	103006	012716	007066			TRAP 14	
16420	103012	012746	000001			MOV #CRLF,(SP)	
16421	103016	010600				MOV #1,-(SP)	8381
16422	103020	104414				MOV SP,R0	: SP,*
16423	103022	012716	010202			TRAP 14	
16424	103026	012746	007072			MOV #PHR12,(SP)	
16425	103032	012746	000002			MOV #SAY1,-(SP)	8382
16426	103036	010600				MOV #2,-(SP)	
16427	103040	104414				MOV SP,R0	: SP,*
16428	103042	012716	010410			TRAP 14	
16429	103046	016746	131246			MOV #PHR19,(SP)	
16430	103052	012746	007046			MOV WR.MILLIONS,-(SP)	8384
16431	103056	012746	000003			MOV #FMT14,-(SP)	
16432	103062	010600				MOV #3,-(SP)	
16433	103064	104414				MOV SP,R0	: SP,*
16434	103066	012716	010430			TRAP 14	
16435	103072	016746	131230			MOV #PHR20,(SP)	
16436	103076	012746	007046			MOV RD.MILLIONS,-(SP)	8386
16437	103102	012746	000003			MOV #FMT14,-(SP)	
16438	103106	010600				MOV #3,-(SP)	
16439	103110	104414				MOV SP,R0	: SP,*
16440	103112	012716	010240			TRAP 14	
16441	103116	016746	131212			MOV #PHR13,(SP)	
16442	103122	012746	007046			MOV WC.MILLIONS,-(SP)	8388
16443	103126	012746	000003			MOV #FMT14,-(SP)	
						MOV #3,-(SP)	

Address	Instruction	Operand 1	Operand 2	Operand 3	Operand 4	Label	Comment	Address	Instruction	Operand 1	Operand 2	Operand 3	Operand 4	Comment
16557														
16558														
16559														
16560	103634	000413												
16561	103636	020327	000010											
16562	103642	00 012												
16563	103644	012746	010756											
16564	103650	012746	006160											
16565	103654	012746	000002											
16566	103660	010600												
16567	103662	104414												
16568	103664	062706	000006											
16569	103670	062706	000010											
16570	103674	005066	000046											
16571	103700	005066	000044											
16572	103704	005066	000042											
16573	103710	010500												
16574	103712	006300												
16575	103714	006300												
16576	103716	006300												
16577	103720	006300												
16578	103722	010004												
16579	103724	005002												
16580	103726	010403												
16581	103730	060203												
16582	103732	006303												
16583	103734	066366	032714	000046										
16584	103742	066366	033314	000044										
16585	103750	066366	033714	000042										
16586	103756	005202												
16587	103760	020227	000017											
16588	103764	003760												
16589	103766	016616	000046											
16590	103772	012746	010004											
16591	103776	012746	006446											
16592	104002	012746	000003											
16593	104006	010600												
16594	104010	104414												
16595	104012	005766	000054											
16596	104016	001425												
16597	104020	005002												
16598	104022	010403												
16599	104024	060203												
16600	104026	006303												
16601	104030	016303	032714											
16602	104034	001412												
16603	104036	010346												
16604	104040	010246												
16605	104042	012746	006534											
16606	104046	012746	000003											
16607	104052	010600												
16608	104054	104414												
16609	104056	062706	000010											
16610	104062	005202												
16611	104064	020227	000017											

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

8410
8442
8406
8448
8449
8450
8454
8452
8454
8455
8455
8452
8459
8462
8465
8467
8470
8469
8465

Address	Instruction	Operand 1	Operand 2	Operand 3	Operand 4	Label	Comment	Address	Instruction	Operand 1	Operand 2	Operand 3	Operand 4	Label	Comment
16613															
16614															
16615															
16616	104070	003754													
16617	104072	016616	000052												
16618	104076	012746	010366												
16619	104102	012746	006446												
16620	104106	012746	000003												
16621	104112	010600													
16622	104114	104414													
16623	104116	005766	000060												
16624	104122	001471													
16625	104124	005001													
16626	104126	010403													
16627	104130	060103													
16628	104132	006303													
16629	104134	016302	033314												
16630	104140	001456													
16631	104142	010246													
16632	104144	010146													
16633	104146	012746	006534												
16634	104152	012746	000003												
16635	104156	010600													
16636	104160	104414													
16637	104162	032777	002000	130202											
16638	104170	001016													
16639	104172	026327	012264	000012											
16640	104200	002412													
16641	104202	012746	011120												
16642	104206	012746	006160												
16643	104212	012746	000002												
16644	104216	010600													
16645	104220	104414													
16646	104222	062706	000006												
16647	104226	032777	002000	130136	20\$:										
16648	104234	001416													
16649	104236	026327	012264	000012											
16650	104244	002412													
16651	104246	012746	011120												
16652	104252	012746	006160												
16653	104256	012746	000002												
16654	104262	010600													
16655	104264	104414													
16656	104266	062706	000006												
16657	104272	062706	000010												
16658	104276	005201													
16659	104300	020127	000017												
16660	104304	003710													
16661	104306	016616	000056												
16662	104312	012746	010026												
16663	104316	012746	006446												
16664	104322	012746	000003												
16665	104326	010600													
16666	104330	104414													
16667	104332	005766	000064												

27-Mar-1982 19:24:42 TOPS
27-Mar-1982 19:23:44 PA:<

Address	OpCode	Operand1	Operand2	Operand3	Comment	Time	Page
16669					:MLX4		
16670					:		
16671					END OF PASS SUMMARY	27-Mar-1982 19:24:42	TOPS
16672	104336	001425				27-Mar-1982 19:23:44	PA:<
16673	104340	005002			BEQ 26\$		
16674	104342	010403			CLR R2		
16675	104344	060203			24\$: MOV R4,R3	: ARRAY	8538
16676	104346	006303			ADD R2,R3	: ARRAY,*	8540
16677	104350	016303	033714		ASL R3		
16678	104354	001412			MOV TRIES(R3),R3		
16679	104356	010346			BEQ 25\$		
16680	104360	010246			MOV R3,-(SP)	: ARRAY,*	8544
16681	104362	012746	006534		MOV R2,-(SP)		
16682	104366	012746	000003		MOV #FMT9,-(SP)		
16683	104372	010600			MOV #3,-(SP)		
16684	104374	104414			MOV SP,R0	: SP,*	
16685	104376	062706	000010		TRAP 14		
16686	104402	005202			25\$: ADD #10,SP		
16687	104404	020227	000017		INC R2	: ARRAY	8538
16688	104410	003754			CMP R2,#17	: ARRAY,*	
16689	104412	062706	000024		26\$: BLE 24\$		
16690	104416	005205			ADD #24,SP		
16691	104420	020566	000046		27\$: INC R5	: LUN	8392
16692	104424	002002			CMP R5,46(SP)	: LUN,*	8391
16693	104426	000167	176520		BGE 28\$		
16694	104432	005767	106226		JMP 2\$		
16695	104436	003517			28\$: TST SBES.COUNT		
16696	104440	012746	007066		BLE 31\$		8558
16697	104444	012746	000001		MOV #CRLF,-(SP)		
16698	104450	010600			MOV #1,-(SP)		8561
16699	104452	104414			MOV SP,R0	: SP,*	
16700	104454	012716	005662		TRAP 14		
16701	104460	012746	007072		MOV #PHR21,(SP)		
16702	104464	012746	000002		MOV #SAY1,-(SP)		8562
16703	104470	010600			MOV #2,-(SP)		
16704	104472	104414			MOV SP,R0	: SP,*	
16705	104474	012716	007065		TRAP 14		
16706	104500	012746	000001		MOV #CRLF,(SP)		
16707	104504	010600			MOV #1,-(SP)		8563
16708	104506	104414			MOV SP,R0	: SP,*	
16709	104510	012716	006042		TRAP 14		
16710	104514	012746	007072		MOV #SBESHEADER,(SP)		
16711	104520	012746	000002		MOV #SAY1,-(SP)		8564
16712	104524	010600			MOV #2,-(SP)		
16713	104526	104414			MOV SP,R0	: SP,*	
16714	104530	016705	106130		TRAP 14		
16715	104534	005002			MOV SBES.COUNT,R5		
16716	104536	000453			CLR R2	: INDEX	8573
16717	104540	010203			BR 30\$		
16718	104542	006303			29\$: MOV R2,R3	: INDEX,*	8580
16719	104544	006303			ASL R3		
16720	104546	016346	011266		ASL R3		
16721	104552	062703	011264		MOV SBE.LOG+2(R3),-(SP)		
16722	104556	011304			ADD #SBE.LOG,R3		
16723	104560	006204			MOV (R3),R4		
					ASR R4		

```

16725
16726
16727
16728 104562 006204
16729 104564 006204
16730 104566 006204
16731 104570 006204
16732 104572 006204
16733 104574 042704 177600
16734 104600 010446
16735 104602 111346
16736 104604 042716 177774
16737 104610 111304
16738 104612 006204
16739 104614 006204
16740 104616 042704 177760
16741 104622 010446
16742 104624 011304
16743 104626 006104
16744 104630 006104
16745 104632 006104
16746 104634 006104
16747 104636 042704 177770
16748 104642 010446
16749 104644 012746 005736
16750 104650 012746 000006
16751 104654 010600
16752 104656 104414
16753 104660 062706 000016
16754 104664 005202
16755 104666 020205
16756 104670 002723
16757 104672 062706 000016
16758 104676 012716 007066
16759 104702 012746 000001
16760 104706 010600
16761 104710 104414
16762 104712 062706 000042
16763 104716 062706 000010
16764 104722 000207
16765
16766
16767
16772
16773

```

:MLX4
:

END OF PASS SUMMARY

```

ASR R4
ASR R4
ASR R4
ASR R4
ASR R4
BIC #177600,R4
MOV R4,-(SP)
MOVB (R3),-(SP)
BIC #177774,(SP)
MOVB (R3),R4
ASR R4
ASR R4
BIC #177760,R4
MOV R4,-(SP)
MOV (R3),R4
ROL R4
ROL R4
ROL R4
ROL R4
BIC #177770,R4
MOV R4,-(SP)
MOV #FMT16,-(SP)
MOV #6,-(SP)
MOV SP,R0
TRAP 14 : SP,*
ADD #16,SP
INC R2
30$: CMP R2,R5 : INDEX
BLT 29$ : INDEX,*
ADD #16,SP
31$: MOV #CRLF,(SP)
MOV #1,-(SP)
MOV SP,R0 : SP,*
TRAP 14
32$: ADD #42,SP
ADD #10,SP
RTS PC

```

```

8574
8573
8560
8585
8377
8326

```

```

: Routine Size: 511 words
: Maximum stack depth per invocation: 40 words

```

27-Mar-1982 19:24:42
 27-Mar-1982 19:23:44

TOPS-20 Bliss-16 V2(212)
 PA:<NEALE>MLX4.BLI.5 (51)

```

16775 :MLX4
16776 :
16777 :
16778 :
16779 :
16780 :
16781 :
16782 :
16783 :
16784 :
16785 :
16786 :
16787 :
16788 :
16789 :
16790 :
16791 :
16792 :
16793 :
16794 :
16795 :
16796 :
16800 :
16801 :
16805 104724 005267 125754
16806 104730 026727 125750 000001
16807 104736 001015
16808 104740 012746 007212
16809 104744 012746 007730
16810 104750 012746 007206
16811 104754 012746 007112
16812 104760 012746 000004
16813 104764 010600
16814 104766 104414
16815 104770 000414
16816 104772 016746 125706
16817 104776 012746 007212
16818 105002 012746 007206
16819 105006 012746 006166
16820 105012 012746 000004
16821 105016 010600
16822 105020 104414
16823 105022 004767 175700
16824 105026 062706 000012
16825 105032 000207
16826 :
16827 :
16828 :
  
```

CLEANUP CODING SECTION

```

8590 %sbttl 'CLEANUP CODING SECTION'
8591 BGNCLN:
8592 !+
8593 ! THE CLEANUP CODING SECTION IS EXECUTED AFTER
8594 ! EACH PASS THROUGH THE EXERCISER.
8595 !-
8596 EOP_COUNT = .EOP_COUNT + 1;
8597
8598 if .EOP_COUNT eql 1
8599 then
8600 PRINTB (SAY3, WRD3, PHR2, WRD4)
8601 !'END QUICK VERIFY PASS'
8602 else
8603 PRINTB (FMT3, WRD3, WRD4, .EOP_COUNT);
8604
8605 !'** END PASS XX **'
8606 EOP ();
8607 return;
8608 ENDCLN:
  
```

16801					.SBTTL	LCLEAN CLEANUP CODING SECTION		
16805	104724	005267	125754		LCLEAN: INC	EOP_COUNT	:	
16806	104730	026727	125750	000001	CMP	EOP_COUNT,#1	:	8596
16807	104736	001015			BNE	1\$:	8598
16808	104740	012746	007212		MOV	#WRD4,-(SP)	:	
16809	104744	012746	007730		MOV	#PHR2,-(SP)	:	8600
16810	104750	012746	007206		MOV	#WRD3,-(SP)	:	
16811	104754	012746	007112		MOV	#SAY3,-(SP)	:	
16812	104760	012746	000004		MOV	#4,-(SP)	:	
16813	104764	010600			MOV	SP,R0	:	
16814	104766	104414			TRAP	14	:	SP,*
16815	104770	000414			BR	2\$:	
16816	104772	016746	125706		1\$: MOV	EOP_COUNT,-(SP)	:	8598
16817	104776	012746	007212		MOV	#WRD4,-(SP)	:	8603
16818	105002	012746	007206		MOV	#WRD3,-(SP)	:	
16819	105006	012746	006166		MOV	#FMT3,-(SP)	:	
16820	105012	012746	000004		MOV	#4,-(SP)	:	
16821	105016	010600			MOV	SP,R0	:	
16822	105020	104414			TRAP	14	:	SP,*
16823	105022	004767	175700		2\$: JSR	PC,EOP	:	
16824	105026	062706	000012		ADD	#12,SP	:	8606
16825	105032	000207			RTS	PC	:	8589

: Routine Size: 36 words
 : Maximum stack depth per invocation: 5 words

16837
16838
16842
16843
16847 105034
16848 105034 004767 177664
16849 105040 104412
16850 105042 000207
16851
16852
16853
16858
16859
16860 ; 8609 LASTAD;
16861 ; 8610 BGNSETUP (0);
16862 ; 8611 ENDSETUP;
16866
16867
16868 105044 105050
16869 105046 000000
16870 105050 000000
16871
16872
16873 105050
16874 000000
16875
16876
16877
16881 105052
16882 105052 000207
16883
16884

.SBTTL LSCLEAN CLEANUP CODING SECTION
LSCLEAN:: JSR PC,LCCLEAN ;
TRAP 12
RTS PC
; Routine Size: 4 words
; Maximum stack depth per invocation: 0 words

8607

BL\$LAS::.WORD T\$FREE
.WORD <<T\$FREE-<BL\$LAS+4>>/2>
T\$FREE::.WORD 0
LSLAST== BLSLAS+4
T\$PTHV== 0

.SBTTL SEND.LINK CLEANUP CODING SECTION
SEND.LINK:: RTS PC ;
; Routine Size: 1 word

8608

```
16886 ;MLX4
16887 ;
16888 ; CLEANUP CODING SECTION
16889 ;
16894 ; Maximum stack depth per invocation: 0 words
16895
16896 : 8612 end
16897 : 8613
16898 : 8614 eludom
16902
16903 ; OTS external references
16904 .GLOBL BLSGT2, $SAVE5, $SAVE4, $SAVE3
16905 .GLOBL $SAVE2, BL$PU2, BL$SHF, BL$DIV
16906 .GLOBL BLSMOD, BLSMUL
16907
16908
16909
16910
16911
16912
16913 ; Size: 10337 code + 5852 data words
16914 ; Run Time: 01:43.8
16915 ; Elapsed Time: 02:08.4
16916 ; Memory Used: 161 pages
16917 ; Compilation Complete
16918
16919 000001 .END
```

SYMBOL TABLE

ADF = 000020 G	CSAU = 000052	DIVMOD 005006	FSEND = 000041	ISHRD = 000041
ASSEMB = 000010	CSAUTO= 000061	DOUBLE 044326	FSHARD= 000004	ISINIT= 000041
BANK 034344	CSBRK = 000022	DRIVE. 034442 G	FSHW = 000013	ISMOD = 000041
BASE.A 032706	CSBSEG= 000004	DROPNE 002234 G	FSINIT= 000006	ISMSG = 000041
BIT.NU 012666	CSBSUB= 000002	DROPT. 034444 G	FSJMP = 000050	ISPROT= 000040
BIT0 = 000001 G	CSCEFG= 000045	DROP1 002236 G	FSMOD = 000000	ISPTAB= 000041
BIT00 = 000001 G	CSCLCK= 000062	DROP2 002240 G	FMSG = 000011	ISPWR = 000041
BIT01 = 000002 G	CSCLEA= 000012	DROP3 002242 G	FSPROT= 000021	ISRPT = 000041
BIT02 = 000004 G	CSCLOS= 000035	DROP4 002244 G	FSPWR = 000017	ISSEG = 000041
BIT03 = 000010 G	CSCLP1= 000006	DROP5 002250 G	FSRPT = 000012	ISSETU= 000041
BIT04 = 000020 G	CSCVEC= 000036	ECCDIS 002254 G	FSSEG = 000003	ISSFT = 000041
BIT05 = 000040 G	CSDCLN= 000044	EFNS21 002262 G	FSSOFT= 000005	ISSRV = 000041
BIT06 = 000100 G	CSDODU= 000051	EF.CON= 000036 G	FSSRV = 000010	ISSUB = 000041
BIT07 = 000200 G	CSDRPT= 000024	EF.NEW= 000035 G	FSSUB = 000002	ISTST = 000041
BIT08 = 000400 G	CSDU = 000053	EF.PWR= 000034 G	FSSW = 000014	I.A.M.D 034336
BIT09 = 001000 G	CSEDIT= 000003	EF.RES= 000037 G	FSTEST= 000001	JSJMP = 000167
BIT1 = 000002 G	CSERDF= 000055	EF.STA= 000040 G	GEN1 040732	LAU 005650
BIT10 = 002000 G	CSERHR= 000056	END.RB= 032670	GEN2 041432	LAUTO 005504
BIT11 = 004000 G	CSERRO= 000060	END.WB= 022670	GEN3 041466	LCLEAN 104724
BIT12 = 010000 G	CSERSF= 000054	EOP 102726 G	GEN4 041564	LDU 005516
BIT13 = 020000 G	CSERSO= 000057	EOPSUM 002256 G	GEN5 041620	LIMIT 002222 G
BIT14 = 040000 G	CSESCA= 000010	EOP.CO 032704	GETCNT 041106	LINIT 040474
BIT15 = 100000 G	CSSEGA= 000005	ERRBLK 002200 G	GET.WR 047176	LOE = 040000 G
BIT2 = 000004 G	CSSESUB= 000003	ERRMSG 002176 G	GSCNTO= 000200	LOT = 000010 G
BIT3 = 000010 G	CSSETST= 000001	ERRNBR 002174 G	G\$DELM= 000372	LOW.SE 034460 G
BIT4 = 000020 G	CS\$EXIT= 000032	ERROUT 002260 G	G\$DISP= 000003	LRPT 005466
BIT5 = 000040 G	CS\$GETB= 000026	ERRTYP 002172 G	G\$EXCP= 000400	LSECT 002226 G
BIT6 = 000100 G	CS\$GETW= 000027	EVL = 000004 G	G\$HILI= 000002	LSACP 002110 G
BIT7 = 000200 G	CS\$GMAN= 000043	ESEND = 002100	G\$LOLI= 000001	LSAPT 002036 G
BIT8 = 000400 G	CS\$GPHR= 000042	ESLOAD= 000035	G\$NO = 000000	LSAU 005652 G
BIT9 = 001000 G	CS\$GPLO= 000030	FILLER 041266	G\$OFFS= 000400	LSAUT 002070 G
BL\$DIV 005170 G	CS\$GPRI= 000040	FMT1A = 006126	G\$OFSI= 000376	LSAUTO 005506 G
BL\$GT1 004234 G	CS\$INIT= 000011	FMT1B = 006142	G\$PRMA= 000001	L\$CCP 002106 G
BL\$GT2 004356 G	CS\$INLP= 000020	FMT10A= 006564	G\$PRMD= 000002	L\$CLEA 105034 G
3L\$LAS 105044 G	CS\$MANI= 000050	FMT10B= 006640	G\$PRML= 000000	L\$CO 002032 G
BL\$MOD 005202 G	CS\$MEM = 000031	FMT11 = 006654	G\$RADA= 000140	L\$DEPO 002011 G
BL\$MUL 004744 G	CS\$MSG = 000023	FMT12A= 006710	G\$RADB= 000700	L\$DESC 002130 G
BL\$PU1 004520 G	CS\$OPEN= 000034	FMT12B= 006756	G\$RADD= 000040	L\$DESP 002076 G
BL\$PU2 004614 G	CS\$PNTB= 000014	FMT13 = 007024	G\$RADL= 000120	L\$DEVP 002060 G
BL\$SHF 005214 G	CS\$PNTF= 000017	FMT14 = 007046	G\$RADO= 000020	L\$DISP 002204 G
BOARD 034342	CS\$PNTS= 000016	FMT15 = 007060	G\$XFER= 000004	L\$DLY 002116 G
BOE = 000400 G	CS\$PNTX= 000015	FMT16 = 005736	G\$YES = 000010	L\$DTP 002040 G
BR.LEV 032712	CS\$QIO = 000377	FMT2 = 006160	HARDS 033314	L\$DTYP 002034 G
CAUSE1= 010460	CS\$RDBU= 000007	FMT3 = 006166	HELP = 000000	L\$DU 005640 G
CAUSE2= 010502	CS\$REFG= 000047	FMT4A = 006216	HOE = 100000 G	L\$DUT 002072 G
CAUSE3= 010526	CS\$RESE= 000033	FMT4B = 006252	IBE = 010000 G	L\$DVTY 002122 G
CAUSE4= 010602	CS\$REVI= 000003	FMT4C = 006270	IDU = 000040 G	L\$EF 002052 G
CAUSE5= 010656	CS\$RFLA= 000021	FMT5 = 006320	IER = 020000 G	L\$ENVI 002044 G
CAUSE6= 010710	CS\$RPT = 000025	FMT6 = 006376	INIT.A 035206	L\$ERRT 002172 G
CAUSE7= 010734	CS\$SEFG= 000046	FMT7 = 006446	INTEGR 047232	L\$ETP 002102 G
CAUSE8= 010756	CS\$SPRI= 000041	FMT8 = 006466	ISOLAT 037332	L\$EXP1 002046 G
CHECK 046000	CS\$SVEC= 000037	FMT9 = 006534	ISR = 000100 G	L\$EXP4 002064 G
CHOOSE 046166	CS\$TPRI= 000013	FSAU = 000015	IXE = 004000 G	L\$EXP5 002066 G
CLRTBL 034554	DATA.C 032700	FSAUTO= 000020	ISAU = 000041	L\$HARD 002266 G
COMP.C 032702	DECODE 037176	F\$BGN = 000040	ISAUTO= 000041	L\$HIME 002120 G
CONFIG 036002	DFPTBL 002210 G	F\$CLEA= 000007	ISCLN = 000041	L\$HPCP 002016 G
CRLF = 007066	DIAGMC= 000000	F\$DU = 000016	ISDU = 000041	L\$HPTP 002022 G

LSHW 002210 G
 LSICP 002104 G
 LSINIT 040722 G
 LSLADF 002026 G
 LSLAST= 105050 G
 L\$LOAD 002100 G
 LSLUN 002074 G
 L\$MREV 002050 G
 L\$NAME 002000 G
 L\$PRIO 002042 G
 L\$PROT 004126 G
 L\$PRT 002112 G
 L\$REPP 002062 G
 L\$REV 002010 G
 L\$RPT 005474 G
 L\$SOFT 002450 G
 L\$SPC 002056 G
 L\$SPCP 002020 G
 L\$SPTP 002024 G
 L\$STA 002030 G
 L\$SW 002222 G
 L\$TEST 002114 G
 L\$TML 002014 G
 L\$UNIT 002012 G
 L10000 002220
 L10001 002264
 L10002 002332
 L10003 002664
 MARPAT 002246 G
 MLB10 = 007472
 MLB11 = 007500
 MLB12 = 007504
 MLB13 = 007510
 MLB14 = 007514
 MLB15 = 007520
 MLB16 = 007524
 MLB17 = 007530
 MLB18 = 007534
 MLB19 = 007542
 MLB2 = 007430
 MLB20 = 007550
 MLB21 = 007554
 MLB22 = 007560
 MLB23 = 007564
 MLB24 = 007570
 MLB3 = 007434
 MLB4 = 007440
 MLB5 = 007444
 MLB6 = 007450
 MLB7 = 007454
 MLB8 = 007460
 MLB9 = 007464
 ML.REG 034346 G
 MSG0 = 011002
 MSG1 = 011070
 MSG2 = 011120
 MSG3 = 011166

MSG4 = 011202
 MSG5 = 011216
 NUM.DR 034456 G
 ONEFIL= 000001
 ONLY 002232 G
 OPT1 051460
 OPT2 054054
 OPT3 060052
 OPT4 062444
 OPT5 102272
 OSAPTS= 000001
 OSAU = 000001
 OSBGNR= 000001
 OSBGNS= 000001
 OS\$DU = 000001
 OSERRT= 000001
 OS\$GNSW= 000001
 OS\$POIN= 000001
 OS\$SETU= 000001
 PATTBL 034520 G
 PATER 032676
 PHR1 = 007714
 PHR10 = 010120
 PHR11 = 010140
 PHR12 = 010202
 PHR13 = 010240
 PHR14 = 010266
 PHR15 = 010304
 PHR16 = 010322
 PHR17 = 010342
 PHR18 = 010366
 PHR19 = 010410
 PHR2 = 007730
 PHR20 = 010430
 PHR21 = 005662
 PHR3 = 007746
 PHR4 = 007770
 PHR5 = 010004
 PHR6 = 010026
 PHR7 = 010050
 PHR8 = 010066
 PHR9 = 010100
 PM.SBE 012264
 PNT = 001000 G
 PRI = 002000 G
 PRI00 = 000000 G
 PRI01 = 000040 G
 PRI02 = 000100 G
 PRI03 = 000140 G
 PRI04 = 000200 G
 PRI05 = 000240 G
 PRI06 = 000300 G
 PRI07 = 000340 G
 PTABLE 034422 G
 P.AAA 005662
 P.AAB 005736
 P.AAC 006042

P.AAD 006126
 P.AAE 006142
 P.AAF 006160
 P.AAG 006166
 P.AAH 006216
 P.AAI 006252
 P.AAJ 006270
 P.AAK 006320
 P.AAL 006376
 P.AAM 006446
 P.AAN 006466
 P.AAO 006534
 P.AAP 006564
 P.AAQ 006640
 P.AAR 006654
 P.AAS 006700
 P.AAT 006756
 P.AAU 007024
 P.AAV 007046
 P.AAW 007060
 P.AAX 007066
 P.AAY 007072
 P.AAZ 007100
 P.ABA 007112
 P.ABB 007130
 P.ABC 007152
 P.ABD 007200
 P.ABE 007206
 P.ABF 007212
 P.ABG 007220
 P.ABH 007230
 P.ABI 007240
 P.ABJ 007246
 P.ABK 007256
 P.ABL 007264
 P.ABM 007272
 P.ABN 007300
 P.ABO 007312
 P.ABP 007322
 P.ABQ 007332
 P.ABR 007336
 P.ABS 007344
 P.ABT 007354
 P.ABU 007370
 P.ABV 007400
 P.ABW 007412
 P.ABX 007416
 P.ABY 007424
 P.ABZ 007430
 P.ACA 007434
 P.ACB 007440
 P.ACC 007444
 P.ACD 007450
 P.ACE 007454
 P.ACF 007460
 P.ACG 007464
 P.ACH 007472

P.ACI 007500
 P.ACJ 007504
 P.ACK 007510
 P.ACL 007514
 P.ACM 007520
 P.ACN 007524
 P.ACO 007530
 P.ACP 007534
 P.ACQ 007542
 P.ACR 007550
 P.ACS 007554
 P.ACT 007560
 P.ACU 007564
 P.ACV 007570
 P.ACW 007574
 P.ACX 007626
 P.ACY 007634
 P.ACZ 007642
 P.ADA 007650
 P.ADB 007656
 P.ADC 007664
 P.ADD 007672
 P.ADE 007700
 P.ADF 007706
 P.ADG 007714
 P.ADH 007730
 P.ADI 007746
 P.ADJ 007770
 P.ADK 010004
 P.ADL 010026
 P.ADM 010050
 P.ADN 010066
 P.ADO 010100
 P.ADP 010120
 P.ADQ 010140
 P.ADR 010202
 P.ADS 010240
 P.ADT 010266
 P.ADU 010304
 P.ADV 010322
 P.ADW 010342
 P.ADX 010366
 P.ADY 010410
 P.ADZ 010430
 P.AEA 010444
 P.AEB 010446
 P.AEC 010450
 P.AED 010454
 P.AEE 010460
 P.AEF 010502
 P.AEG 010526
 P.AEH 010602
 P.AEI 010656
 P.AEJ 010710
 P.AEK 010734
 P.AEL 010756
 P.AEM 011002

P.AEN 011070
 P.AEO 011120
 P.AEP 011166
 P.AEQ 011202
 P.AER 011216
 QH1 002332
 QH2 002351
 QH3 002374
 QH4 002425
 QS1 002664
 QS10 003534
 QS11 003554
 QS12 003637
 QS13 003657
 QS14 003724
 QS15 003763
 QS16 004030
 QS17 004066
 QS2 002732
 QS3 003007
 QS4 003047
 QS5 003107
 QS6 003147
 QS7 003454
 QS8 003474
 QS9 003514
 QUICK 032674
 RANDOM 005464 G
 RAND1 070540
 RAND2 073124
 RAND3 075444
 RAND4 100006
 RANGE 002224 G
 RBUFF 022670
 RCBUFF= 023670
 RDBUFF= 022670
 RD.COU 034322
 RD.MIL 034326
 RD.THO 034324
 READ 045612
 REFRES 002252 G
 RETRY 046224
 RETRYI 034340
 RE2 005362
 RE3 005360
 RE4 005356
 RN 005370 G
 RNDSEC 070240
 RNDU 070336
 RNDWC 070204
 RPTR 032672
 RTNO = 007574
 RTN1 = 007626
 RTN2 = 007634
 RTN3 = 007642
 RTN4 = 007650
 RTN5 = 007656

RTNSA = 007664
 RTNSB = 007672
 RTNSC = 007700
 RTNSD = 007706
 SAYWHO 035524
 SAY1 = 007072
 SAY2 = 007100
 SAY3 = 007112
 SAY4 = 007130
 SAY5 = 007152
 SBESHE = 006042
 SBES.C 012664
 SBE.LO 011264
 SEED1 005456 G
 SEED2 005460 G
 SEED3 005462 G
 SELPAT 041066
 SERVIC 034544 G
 SET.PT 047132
 SFPTBL 002222 G
 SOFTS 032714
 START. 044424
 SVCGBL = 000001
 SVCINS = 000001

SVCSLB = 000001
 SVCTAG = 000001
 SVCTST = 000001
 SYSERR 041710
 SLSYM = 010000
 TOP.SE 034500 G
 TRIES 033714
 TRT00 = 010444
 TRT01 = 010446
 TRT10 = 010450
 TRT11 = 010454
 TSECT 002230 G
 T\$ARGC = 000002
 T\$CODE = 020130
 T\$ERRN = 000000
 T\$EXCP = 000000
 T\$FREE 105050 G
 T\$GMAN = 000000
 T\$HILI = 000012
 T\$LAST = 000000
 T\$LOLI = 000001
 T\$LSYM = 010000
 T\$NEST = 177777
 T\$NSO = 000000

T\$NS1 = 000021
 T\$PTHV = 000000 G
 T\$PTNU = 000000
 T\$SAVL = 177777
 T\$SEGL = 177777
 T\$SUBN = 000000
 T\$TAGL = 177777
 T\$TAGN = 010005
 T\$TEMP = 000000
 T\$TEST = 000000
 T\$TSTM = 177777
 T\$TSTS = 000000
 T\$SHAR = 010002
 T\$SHW = 010000
 T\$SPRO = 010004
 T\$SOF = 010003
 T\$SSW = 010001
 T1 102712 G
 UAM = 000200 G
 UP.HAR 037422
 UP.RD. 045240
 UP.SOF 040104
 UP.WC. 045332
 UP.WR. 045146

VEC 032710
 WAITER 044420
 WBUFF 012670
 WCBUFF = 013670
 WC.COU 034330
 WC.MIL 034334
 WC.THO 034332
 WDBUFF = 012670
 WHY.DR 034446 G
 WPTR 032670
 WRD11 = 007240
 WRD15 = 007246
 WRD16 = 007256
 WRD17 = 007264
 WRD18 = 007272
 WRD19 = 007300
 WRD2 = 007200
 WRD20 = 007312
 WRD21 = 007322
 WRD24 = 007332
 WRD25 = 007336
 WRD3 = 007206
 WRD34 = 007344
 WRD35 = 007354

WRD36 = 007370
 WRD37 = 007400
 WRD38 = 007412
 WRD4 = 007212
 WRD40 = 007416
 WRD41 = 007424
 WRD6 = 007220
 WRD7 = 007230
 WRITE 045424
 WR.COU 034314
 WR.MIL 034320
 WR.THO 034316
 X\$ALWA = 000000
 X\$FALS = 000040
 X\$OFFS = 000400
 X\$TRUE = 000020
 \$END.L 105052 G
 \$PATCH 004134 G
 \$SAVE2 005262 G
 \$SAVE3 005276 G
 \$SAVE4 005314 G
 \$SAVE5 005334 G
 \$T1 102536

. ABS. 105054 000
 000000 001
 ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 31919 WORDS (125 PAGES)
 DYNAMIC MEMORY: 21558 WORDS (82 PAGES)
 ELAPSED TIME: 00:09:52
 CZMLBB.BIN,CZMLBB/CR/-SP=SVC/ML,CZMLBB.DGC,MLX2,OTS,RANDOM,MLX3,MLX4

SYMBOL	VALUE	CROSS REFERENCE	REFERENCES								
ADR	= 000020	G	#83-1773								
ASSEMB	= 000010		6-13	6-13							
BANK	034344		#82-1685	*98-2978	*99-2991	100-3052	103-3237	105-3302	108-3485	109-3530	155-6371
			*155-6383								
BASE.A	032706		#81-1650	*88-2289	89-2338	97-2909					
BIT.NU	012666		#81-1637	*99-3005	103-3226	104-3290	108-3474	109-3522			
BIT0	= 000001	G	#83-1754								
BIT00	= 000001	G	#83-1744								
BIT01	= 000002	G	#83-1743								
BIT02	= 000004	G	#83-1742								
BIT03	= 000010	G	#83-1741								
BIT04	= 000020	G	#83-1740								
BIT05	= 000040	G	#83-1739								
BIT06	= 000100	G	#83-1738								
BIT07	= 000200	G	#83-1737								
BIT08	= 000400	G	#83-1736								
BIT09	= 001000	G	#83-1735								
BIT1	= 000002	G	#83-1753								
BIT10	= 002000	G	#83-1734								
BIT11	= 004000	G	#83-1733								
BIT12	= 010000	G	#83-1732								
BIT13	= 020000	G	#83-1731								
BIT14	= 040000	G	#83-1730								
BIT15	= 100000	G	#83-1729								
BIT2	= 000004	G	#83-1752								
BIT3	= 000010	G	#83-1751								
BIT4	= 000020	G	#83-1750								
BIT5	= 000040	G	#83-1749								
BIT6	= 000100	G	#83-1748								
BIT7	= 000200	G	#83-1747								
BIT8	= 000400	G	#83-1746								
BIT9	= 001000	G	#83-1745								
BLSDIV	005170	G	#37-1170	185-8022	205-9118	209-9381	225-10222	273-13132	282-13730	297-14575	298-14593
			313-15422	341-16905							
BLSGT1	004234	G	#13-169								
BLSGT2	004356	G	#18-384	164-6887	180-7728	200-8836	205-9143	220-9931	242-11178	265-12395	273-12846
			281-13705	297-14560	322-15915	333-16485	341-16904				
BLSLAS	105044	G	#340-16868	340-16869	340-16873						
BL\$MOD	005202	G	#38-1201	118-4116	261-12206	263-12297	265-12380	265-12404	341-16906		
BL\$MUL	004744	G	#34-1022	95-2787	341-16906						
BL\$PU1	004520	G	#23-592								
BL\$PU2	004614	G	#29-829	47-220	47-231	50-339	85-2133	85-2140	111-3672	112-3685	118-4112
			341-16905								
BL\$SHF	005214	G	13-181	13-184	13-188	13-192	14-217	19-406	19-409	19-413	19-417
			19-438	23-595	23-599	23-605	24-632	29-838	29-842	29-848	30-880
			#39-1236	88-2294	341-16905						
BOARD	034342		#82-1684	*99-2996	100-3053	104-3246	104-3271	105-3306	108-3490	109-3534	155-6370
			155-6379	*155-6382	168-7119	169-7140	171-7267	171-7284	185-7996	185-8013	187-8108
			187-8125	204-9088	205-9109	209-9350	209-9367	211-9467	211-9484	225-10196	225-10213
			227-10308	227-10325	247-11460	248-11481	252-11739	253-11760	257-12018	258-12039	259-12125
			259-12142	273-13106	273-13123	273-13216	273-13233	286-13980	287-14001	288-14085	289-14106
			302-14838	302-14855	304-14946	304-14963	318-15671	318-15688	319-15773	320-15794	

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
BOE		= 000400 G	#83-1777
BR.LEV		032712	#81-1653 *88-2291 88-2292
CAUSE1		= 010460	#83-1905 94-2733 333-16499
CAUSE2		= 010502	#83-1906 94-2756 334-16511
CAUSE3		= 010526	#83-1907 96-2831 96-2858 334-16519
CAUSE4		= 010602	#83-1908 334-16527
CAUSE5		= 010656	#83-1909 334-16535
CAUSE6		= 010710	#83-1910 334-16543
CAUSE7		= 010734	#83-1911 334-16551
CAUSE8		= 010756	#83-1912 335-16563
CHECK		046000	#147-5961 149-6059 153-6265 154-6301 154-6312 169-7147 169-7152 171-7238 182-7826 201-8923 206-9185 222-10026 244-11290 249-11569 254-11848 273-12939 283-13815 299-14673 302-14809 315-15506
CHOOSE		046166	#149-6052 181-7804 201-8905 206-9166 221-10004 244-11269 249-11548 254-11827 273-12918 283-13797 299-14655 314-15484
CLRTBL		034554	#84-2078 111-3644
COMP.C		032702	#81-1646 *116-3994 118-4102
CONFIG		036002	#93-2703 112-3678
CRLF		= 007066	#83-1814 88-2301 89-2330 154-6342 325-16041 332-16410 332-16419 337-16696 337-16705 338-16758
C\$AU		= 000052	#6-13
C\$AUTO		= 000061	#6-13
C\$BRK		= 000022	#6-13
C\$BSEG		= 000004	#6-13
C\$BSUB		= 000002	#6-13
C\$CEFG		= 000045	#6-13
C\$CLCK		= 000062	#6-13
C\$CLEA		= 000012	#6-13
C\$CLOS		= 000035	#6-13
C\$CLP1		= 000006	#6-13
C\$CVEC		= 000036	#6-13
C\$DCLN		= 000044	#6-13
C\$DODU		= 000051	#6-13
C\$DRPT		= 000024	#6-13
C\$DU		= 000053	#6-13
C\$EDIT		= 000003	#6-13
C\$ERDF		= 000055	#6-13
C\$ERHR		= 000056	#6-13
C\$ERRO		= 000060	#6-13
C\$ERSF		= 000054	#6-13
C\$ERSO		= 000057	#6-13
C\$ESCA		= 000010	#6-13
C\$ESEG		= 000005	#6-13
C\$ESUB		= 000003	#6-13
C\$ETST		= 000001	#6-13
C\$EXIT		= 000032	#6-13
C\$GETB		= 000026	#6-13
C\$GETW		= 000027	#6-13
C\$GMAN		= 000043	#6-13
C\$GPHR		= 000042	#6-13
C\$GPLO		= 000030	#6-13
C\$GPRI		= 000040	#6-13

6-65

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
CSINIT	=	000011	#6-13
CSINLP	=	000020	#6-13
CSMANI	=	000050	#6-13
CSMEM	=	000031	#6-13
CSMSG	=	000023	#6-13
CSOPEN	=	000034	#6-13
CSPNTB	=	000014	#6-13
CSPNTF	=	000017	#6-13
CSPNTS	=	000016	#6-13
CSPNTX	=	000015	#6-13
CSQIO	=	000377	#6-13
CSRDBU	=	000007	#6-13
CSREFG	=	000047	#6-13
CSRESE	=	000033	#6-13 #6-13
CSREVI	=	000003	#6-13 6-65
CSRFLA	=	000021	#6-13
CSRPT	=	000025	#6-13
CSSFFG	=	000046	#6-13
CSSPRI	=	000041	#6-13
CSSVEC	=	000037	#6-13
CSTPRI	=	000013	#6-13
DATA.C		032700	#81-1644 *116-3993 118-4104
DECODE		037176	#98-2972 100-3049 155-6373
DGPTBL		002210	#7-117
DIAGMC	=	000000	6-13
DIVMOD		005006	#35-1091 37-1171 38-1202
DOUBLE		044326	#133-5198 166-6966 182-7835 201-8931
DRIVE.	034442	G	273-12948 284-13828 299-14682 315-15515 206-9193 222-10035 244-11299 249-11578 254-11857
DROPNE	002234	G	46-201 47-214 #82-1692 85-2128 111-3653 164-6881 180-7722 200-8830 205-9137
DROPT.	034444	G	220-9925 242-11172 265-12389 273-12840 281-13699 297-14554 322-15909
DROP1	002236	G	#8-160 83-1723 85-2146
DROP2	002240	G	46-201 47-225 #82-1695 85-2135 333-16479
DROP3	002242	G	#8-161 83-1723 *85-2148 325-16054
DROP4	002244	G	#8-162 83-1724 *85-2149 325-16057
DROP5	002250	G	#8-163 83-1724 *85-2150 325-16060
ECCDIS	002254	G	#8-164 83-1724 *85-2151 325-16065
EFNS21	002262	G	#8-166 83-1724 *85-2152 325-16068
EF.CON	=	000036	G #8-169 83-1725 88-2296 131-4772 131-4807 131-4858 131-4956 138-5458
EF.NEW	=	000035	G #8-192 83-1722 185-8027 210-9390 225-10227 258-12048 273-13137 287-14008 303-14869
EF.PWR	=	000034	G #8-192 318-15697
EF.RES	=	000037	G #83-1757
EF.STA	=	000040	G #83-1758
END.RB	=	032670	#83-1759
END.WB	=	022670	#83-1756
EOP		102726	G #83-1755
EOPSUM		002256	G #83-1755
EOP.CO		032704	#83-1790
ERRBLK		002200	G #83-1789 156-6439
ERRMSG		002176	G #83-1789 44-31 44-39 #332-16405 339-16823
			#8-188 83-1725 332-16407
			#81-1648 *84-2101 *339-16805 339-16806 339-16816
			#7-94
			#7-94

CZMLBB
SYMBOL CROSS REFERENCE
ERRNBR VALUE
ERROUT

CREATED BY MACRO ON 29-MAR-82 AT 13:44

PAGE 4
CREF

F 13

SEQ 0367

SYMBOL	VALUE	CROSS REFERENCE	REFERENCES															
ERRNBR	002174	G	#7-94															
ERROUT	002260	G	#8-190	83-1725	100-3050	131-4818	131-5100	144-5788	146-5886	148-5984	153-6252							
			154-6334	155-6358	167-7059	168-7112	169-7126	169-7133	170-7207	171-7260	171-7270							
			171-7277	184-7936	185-7989	185-7999	185-8006	186-8048	187-8101	187-8111	187-8118							
			203-9028	204-9081	204-9091	204-9098	208-9290	209-9343	209-9353	209-9360	210-9407							
			211-9460	211-9470	211-9477	224-10136	224-10185	225-10199	225-10206	226-10248	226-10297							
			227-10311	227-10318	246-11400	247-11453	247-11463	247-11470	251-11679	252-11732	252-11742							
			252-11749	256-11958	257-12011	257-12021	257-12028	258-12065	259-12118	259-12128	259-12135							
			273-13047	273-13099	273-13109	273-13116	273-13157	273-13209	273-13219	273-13226	285-13920							
			286-13973	286-13983	287-13994	287-14025	288-14078	288-14088	288-14095	301-14778	302-14831							
			302-14841	302-14848	303-14886	304-14939	304-14949	304-14956	316-15607	317-15660	318-15674							
			318-15681	318-15713	319-15766	319-15776	320-15787											
ERRTYP	002172	G	#7-94															
EVL	= 000004	G	#83-1771															
E\$END	= 002100		#6-13															
E\$LOAD	= 000035		#6-13	6-65														
FILLER	= 041266		#118-4094	120-4178	123-4315													
FMT1A	= 006126		#83-1794	199-8804														
FMT1B	= 006142		#83-1795	199-8813														
FMT10A	= 006564		#83-1806	100-3057														
FMT10B	= 006640		#83-1807	168-7074	170-7218	184-7947	186-8059	203-9039	208-9301	210-9418	224-10147							
			226-10259	246-11411	251-11690	256-11969	258-12076	273-13058	273-13168	285-13931	287-14036							
			301-14789	303-14897	317-15622	319-15728												
FMT11	= 006654		#83-1808	96-2840	96-2867													
FMT12A	= 006710		#83-1809	166-6979	182-7848	202-8948	206-9206	222-10048	245-11316	250-11595	255-11874							
			273-12961	284-13841	300-14699	315-15528												
FMT12B	= 006756		#83-1810	166-6986	182-7855	202-8955	206-9213	222-10055	245-11323	250-11602	255-11881							
			273-12968	284-13848	300-14706	315-15535												
FMT13	= 007024		#83-1811	104-3280														
FMT14	= 007046		#83-1812	332-16430	332-16436	332-16442												
FMT15	= 007060		#83-1813	131-4832	131-4840	131-4851	131-4861	131-4871	131-4879	131-4920	131-4928							
			131-4936	131-4946	131-4959	131-4967	131-4975	131-4985	131-4993	131-5003	131-5014							
			131-5022	131-5030	131-5038	131-5046	131-5056	131-5067	131-5075									
FMT16	= 005736		#83-1792	338-16749														
FMT2	= 006160		#83-1796	94-2734	94-2757	96-2832	96-2859	242-11190	244-11265	249-11544	254-11823							
			334-16504	334-16512	334-16520	334-16528	334-16536	334-16544	334-16552	335-16564	336-16642							
			336-16652															
FMT3	= 006166		#83-1797	339-16819														
FMT4A	= 006216		#83-1798	90-2439	94-2723	333-16467												
FMT4B	= 006252		#83-1799	90-2453	97-2911													
FMT4C	= 006270		#83-1800	90-2463														
FMT5	= 006320		#83-1801	97-2883														
FMT6	= 006376		#83-1802	139-5500	144-5796	146-5894	148-5992											
FMT7	= 006446		#83-1803	335-16591	336-16619	336-16663												
FMT8	= 006466		#83-1804	97-2905														
FMT9	= 006534		#83-1805	335-16605	336-16633	337-16681												
F\$AU	= 000015		#6-13															
F\$AUTO	= 000020		#6-13															
F\$BGN	= 000040		#6-13	6-39	8-259	8-302	9-379	9-411										
F\$CLEA	= 000007		#6-13															
F\$DU	= 000016		#6-13															
F\$END	= 000041		#6-13	6-13	6-13	6-13	6-13	6-13	6-13	6-13	6-13							

REFERENCES

SYMBOL	VALUE	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES
FSHARD	= 000004	6-13	6-13	6-13	6-13	6-13	6-13	6-13	6-39
FSHW	= 000013	8-277	8-339	9-411	8-314	8-316	8-319	8-322	8-324
FSINIT	= 000006	#6-13	8-259	8-277					8-329
FSJMP	= 000050	#6-13	7-117	7-134					
FSMOD	= 000000	#6-13							
FSMSG	= 000011	#6-13	6-39	9-411					
FSPROT	= 000021	#6-13	9-379	9-385					
FSPWR	= 000017	#6-13							
FSRPT	= 000012	#6-13							
FSSEG	= 000003	#6-13							
FSOFT	= 000005	#6-13	8-302	8-314	8-316	8-319	8-322	8-324	8-329
FSRV	= 000010	#6-13							
FSSUB	= 000002	#6-13							
FSSW	= 000014	#6-13	8-143	8-196					
FSTEST	= 000001	#6-13							
GEN1	040732	#114-3793	180-7743						
GEN2	041432	#120-4173	199-8818						
GEN3	041466	#121-4241	164-6873	220-9917					
GEN4	041564	#123-4310	242-11156	242-11160					
GEN5	041620	#125-4371	273-12832	281-13694	297-14549	313-15397			
GETCNT	041106	#116-3959	120-4174	123-4311					
GET.WR	047176	#157-6486	165-6903	180-7746	200-8850	205-9158	220-9946	273-12861	
GSCNTO	= 000200	#6-13							
G\$DELM	= 000372	#6-13							
G\$DISP	= 000003	#6-13							
G\$EXCP	= 000400	#6-13							
G\$HIL!	= 000002	#6-13							
G\$LOLI	= 000001	#6-13							
G\$NO	= 000000	#6-13							
G\$OFFS	= 000400	#6-13	8-272	8-273	8-274	8-275	8-313	8-315	8-317
		8-320	8-321	8-323	8-325	8-326	8-327	8-328	8-318
		8-332	8-333	8-334	8-335	8-336			8-331
G\$OF SI	= 000376	#6-13	8-272	8-273	8-274	8-275	8-313	8-315	8-317
		8-320	8-321	8-323	8-325	8-326	8-327	8-328	8-330
		8-332	8-333	8-334	8-335	8-336			8-331
G\$PRMA	= 000001	#6-13	8-272	8-273					
G\$PRMD	= 000002	#6-13	8-274	8-275	8-317	8-318	8-320	8-323	8-330
G\$PRML	= 000000	#6-13	8-313	8-315	8-321	8-325	8-326	8-327	8-328
		8-332	8-333	8-334	8-335	8-336			8-331
G\$RADA	= 000140	#6-13							
G\$RADB	= 000000	#6-13							
G\$RADD	= 000040	#6-13	8-320	8-323	8-330				
G\$RADL	= 000120	#6-13	8-313	8-315	8-321	8-325	8-326	8-327	8-328
		8-332	8-333	8-334	8-335	8-336			8-331
G\$RADO	= 000020	#6-13	8-272	8-273	8-274	8-275	8-317	8-318	
G\$XFER	= 000004	#6-13	8-314	8-316	8-319	8-322	8-324	8-329	
G\$YES	= 000010	#6-13	8-272	8-273	8-274	8-275	8-313	8-315	8-317
		8-320	8-321	8-323	8-325	8-326	8-327	8-328	8-330
		8-332	8-333	8-334	8-335	8-336			8-331
HARDS	033314	#82-1660	*84-2092	*103-3214	335-16584	336-16629			

CZMLBB
SYMBOL
SYMBOL
HELP

CREATED BY
CROSS REFERENCE

MACRO ON 29-MAR-82 AT 13:44

PAGE 6
CREF

M 13

SEQ 0369

SYMBOL	VALUE	REFERENCE	REFERENCES	6-8	6-30	6-48	6-67	7-103	7-119	8-145	#8-200
HOE	= 100000	G	#6-4	6-8	6-30	6-48	6-67	7-103	7-119	8-145	#8-200
IBE	= 010000	G	8-261	8-279	8-304	9-341	9-387	9-404	9-416		
IDU	= 000040	G	#83-1784								
IER	= 020000	G	#83-1781								
INIT.A	035206		#83-1774								
INTEGR	047232		#83-1782								
ISOLAT	037332		#88-2286	111-3664							
			#164-6862	325-16052							
			#100-3048	167-7046	167-7058	170-7195	170-7206	183-7918	184-7935	186-8047	203-9015
			203-9027	208-9277	208-9289	210-9406	223-10118	224-10135	226-10247	246-11386	246-11399
			251-11665	251-11678	256-11944	256-11957	258-12064	273-13030	273-13046	273-13156	285-13907
			285-13919	287-14024	301-14765	301-14777	303-14885	316-15594	316-15606	318-15712	
ISR	= 000100	G	#83-1775								
IXE	= 004000	G	#83-1780								
ISAU	= 000041		#6-13								
ISAUTO	= 000041		#6-13								
ISCLN	= 000041		#6-13								
ISDU	= 000041		#6-13								
ISHRD	= 000041		#8-259	#8-277							
ISINIT	= 000041		#6-13								
ISMOD	= 000041		#6-13	6-39	#6-39	9-411	#9-411				
ISMSG	= 000041		#6-13								
ISPROT	= 000040		#6-13	#9-379							
ISPTAB	= 000041		#6-13								
ISPWR	= 000041		#6-13								
ISRPT	= 000041		#6-13								
ISSEG	= 000041		#6-13								
ISSETU	= 000041		#6-13								
ISSFT	= 000041		#8-302	#8-339							
ISSRV	= 000041		#6-13								
ISSUB	= 000041		#6-13								
ISTST	= 000041		#6-13								
I.AM.D	034336		#82-1680	*83-1927	*138-5465	138-5471	138-5477				
JSJMP	= 000167		#6-13								
LAU	005650		#48-296	49-315							
LAUTO	005504		#45-101	45-119							
LCLEAN	104724		#339-16805	340-16848							
LDU	005516		#47-210	47-257							
LIMIT	002222	G	#8-153	83-1722	95-2794						
LINIT	040474		#111-3636	112-3710							
LOE	= 040000	G	#83-1783								
LOT	= 000010	G	#83-1772								
LOW.SE	034460	G	#82-1702	*85-2122	*96-2850	97-2881	164-6894	180-7738	185-8033	200-8845	205-9153
			210-9396	220-9941	225-10233	243-11200	258-12054	263-12285	273-12856	273-13143	282-13717
			287-14014	297-14573	303-14875	318-15702					
LQPT	005466		#44-39	44-58							
LSECT	002226	G	#8-157	83-1723	*95-2806	*95-2814	96-2848	96-2850	96-2865		
LSACP	002110	G	#6-65								
LSAPT	002036	G	#6-65								
LSAU	005652	G	6-65	#49-315							
LSAUT	002070	G	#6-65								
LSAUTO	005506	G	6-65	#45-119							

SYMBOL	VALUE	CROSS REFERENCE	REFERENCES
LSMREV	002050	G	#6-65
LSNAME	002000	G	#6-65
LSP7IO	002042	G	#6-65
LSPROT	004126	G	6-65 #9-379
LSPRT	002112	G	#6-65
LSREPP	002062	G	#6-65
LSREV	002010	G	#6-65
LSRPT	005474	G	6-65 #44-58
LSOFT	002450	G	6-65 8-302 #8-302
LSGPC	002056	G	#6-65
LSGPCP	002020	G	#6-65
LSPTP	002024	G	#6-65
LSSTA	002030	G	#6-65
LSW	002222	G	6-65 8-143 #8-143
LSTEST	002114	G	#6-65
LSTIML	002014	G	#6-65
LSUNIT	002012	G	#6-65 242-11165 83-1722 84-2079 111-3645 164-6874 180-7715 199-8819 205-9130 220-9918 265-12372 265-12379 265-12382 265-12403 273-12833 281-13691 297-14546 322-15902

SYMBOL	VALUE	REFERENCES
L10000	002220	333-16450
L10001	002264	7-117 #7-134
L10002	002332	8-143 #8-196
L10003	002664	8-259 #8-277
MARPAT	002246 G	8-302 #8-339
MLB10	= 007472	#8-165 83-1724 242-11154 242-11157
MLB11	= 007500	#83-1853 131-4992
MLB12	= 007504	#83-1854 131-5002
MLB13	= 007510	#83-1855 131-5013
MLB14	= 007514	#83-1856 131-5021
MLB15	= 007520	#83-1857 131-5029
MLB16	= 007524	#83-1858 131-5037
MLB17	= 007530	#83-1859 131-5045
MLB18	= 007534	#83-1860 131-5055
MLB19	= 007542	#83-1861 131-5066
MLB2	= 007430	#83-1862 131-5074
MLB20	= 007550	#83-1845 131-4919
MLB21	= 007554	#83-1863 131-4831
MLB22	= 007560	#83-1864 131-4870
MLB23	= 007564	#83-1865 131-4839
MLB24	= 007570	#83-1866 131-4850
MLB3	= 007434	#83-1867 131-4878
MLB4	= 007440	#83-1846 131-4927
MLB5	= 007444	#83-1847 131-4935
MLB6	= 007450	#83-1848 131-4945
MLB7	= 007454	#83-1849 131-4860 131-4958
MLB8	= 007460	#83-1850 131-4966
MLB9	= 007464	#83-1851 131-4974
ML.REG	034346 G	#83-1852 131-4984
		#82-1689 *89-2340
		90-2411 90-2421 90-2424 90-2430 90-2451 94-2714 94-2715
		94-2716 94-2745 95-2770 95-2780 95-2798 97-2887 98-2972 99-2997 100-3048
		100-3054 131-4732 131-4739 131-4740 131-4742 131-4745 131-4747 131-4751
		131-4753 131-4756 131-4758 131-4761 131-4763 131-4765 131-4767 131-4770 131-4775
		131-4777 131-4779 131-4781 131-4783 131-4785 131-4791 131-4793 131-4795 131-4798
		131-4800 131-4802 131-4805 131-4810 131-4812 131-4829 131-4837 131-4848 131-4856
		131-4868 131-4876 131-4917 131-4925 131-4933 131-4943 131-4951 131-4964 131-4972
		131-4980 131-4982 131-4990 131-5000 131-5011 131-5019 131-5027 131-5035 131-5043
		131-5053 131-5061 131-5072 137-5416 137-5417 137-5422 137-5425 138-5439 138-5452
		138-5453 138-5454 138-5457 138-5460 138-5461 138-5462 138-5463 138-5464 138-5469
		138-5474 167-7061 168-7079 168-7080 168-7099 168-7102 170-7209 170-7223 170-7224
		171-7247 171-7250 184-7938 184-7952 184-7953 184-7972 184-7975 186-8050 186-8064
		186-8065 186-8084 186-8087 203-9030 203-9044 203-9045 204-9068 204-9071 208-9292
		208-9306 208-9307 208-9326 209-9333 210-9409 210-9423 210-9424 211-9447 211-9450
		224-10138 224-10152 224-10153 224-10172 224-10175 226-10250 226-10264 226-10265 226-10284
		226-10287 246-11402 247-11420 247-11421 247-11440 247-11443 251-11681 251-11695 252-11700
		252-11719 252-11722 256-11960 256-11974 256-11975 257-11998 257-12001 258-12067 258-12081
		258-12082 259-12105 259-12108 273-13049 273-13063 273-13064 273-13083 273-13086 273-13159
		273-13173 273-13174 273-13193 273-13196 285-13922 286-13940 286-13941 286-13960 286-13963
		287-14027 287-14041 287-14042 288-14065 288-14068 301-14780 301-14794 301-14795 302-14818
		302-14821 303-14888 303-14902 303-14903 304-14926 304-14929 317-15013 317-15627 317-15628
		317-15647 317-15650 318-15715 319-15733 319-15734 319-15753 319-15756 322-15924 322-15925
		322-15926 333-16458 333-16459 333-16460 336-16637 336-16647

CZMLBB		CREATED BY		MACRO ON 29-MAR-82 AT 13:44		PAGE 9		K 13		SEQ 0372		
SYMBOL		CROSS REFERENCE		REFERENCES		PAGE 9		K 13		SEQ 0372		
SYMBOL		VALUE		REFERENCES		PAGE 9		K 13		SEQ 0372		
MSG0	= 011002			#83-1913	139-5504							
MSG1	= 011070			#83-1914	165-6926	165-6936	165-6945	166-6993	167-7010	167-7029	167-7038	169-7164
				169-7174	170-7187	181-7776	181-7787	181-7796	182-7863	183-7889	183-7900	183-7911
				200-8875	201-8889	201-8898	202-8962	202-8984	203-8998	203-9007	207-9224	207-9246
				207-9256	207-9265	221-9976	221-9987	221-9996	222-10063	223-10089	223-10100	223-10109
				243-11229	243-11240	244-11253	245-11331	245-11353	246-11368	246-11377	248-11506	248-11517
				248-11526	250-11610	250-11632	251-11647	251-11656	253-11785	253-11785	253-11805	255-11889
				255-11911	256-11926	256-11935	273-12890	273-12901	273-12910	273-12910	273-13001	273-13012
				273-13021	283-13771	283-13781	283-13790	284-13855	284-13876	285-13890	285-13899	298-14625
				298-14635	299-14648	300-14713	300-14734	300-14744	301-14757	314-15458	314-15468	314-15477
				315-15542	316-15567	316-15577	316-15586					
MSG2	= 011120			#83-1915	104-3278	167-7049	170-7198	183-7921	203-9018	208-9280	223-10121	246-11389
				251-11668	256-11947	273-13033	285-13910	301-14768	316-15597	336-16641	336-16651	
MSG3	= 011166			#83-1916	169-7130	169-7137	171-7274	171-7281	185-8003	185-8010	187-8115	187-8122
				204-9095	204-9102	209-9357	209-9364	211-9474	211-9481	225-10203	225-10210	227-10315
				227-10322	247-11467	248-11478	252-11746	253-11757	257-12025	258-12036	259-12132	259-12139
				273-13113	273-13120	273-13223	273-13230	286-13987	287-13998	288-14092	288-14099	302-14845
				302-14852	304-14953	304-14960	318-15678	318-15685	320-15784	320-15791		
MSG4	= 011202			#83-1917	168-7116	171-7264	185-7993	187-8105	204-9085	209-9347	211-9464	225-10193
				227-10305	247-11457	252-11736	257-12015	259-12122	273-13103	273-13213	286-13977	288-14082
				302-14835	304-14943	317-15664	319-15770					
MSG5	= 011216			#83-1918	166-6972	182-7841	202-8941	206-9199	222-10041	245-11309	250-11588	254-11863
				273-12954	284-13834	299-14688	315-15521					
NUM.DR	= 034456	G		46-202	*47-232	#82-1700	*84-2102	111-3661	*111-3666	313-15398	322-15901	
ONEFIL	= 000001			#2-5	4-1665	5-1666	6-34	8-223	9-429			
ONLY	= 002232	G		#8-159	83-1723	95-2800	95-2810					
OPT1	= 051460			#179-7702	325-16056							
OPT2	= 054054			#199-8781	325-16059							
OPT3	= 060052			#219-9903	325-16062							
OPT4	= 062444			#242-11146	325-16067							
OPT5	= 022272			#322-15893	325-16070							
OSAPTS	= 000001			#6-13	#6-46	6-65						
OSAU	= 000001			#6-13	#6-46	6-65						
OSBGNR	= 000001			#6-13	#6-46	6-65						
OSBGNS	= 000001			#6-13	#6-46	6-65						
OSDU	= 000001			#6-13	#6-46	6-65						
OSERRT	= 000001			#6-13	#6-46	6-65						
OSGNSW	= 000001			#6-13	#6-46	6-65						
OSPOIN	= 000001			#6-13	#6-46	6-65						
OSSETU	= 000001			#6-13	#6-46	6-46	6-65	6-65				
PATTBL	= 034520	G		#82-1706	116-3993	116-3994						
PATTER	= 032676			#81-1643	*115-3870	115-3871	*115-3873	120-4173	*199-8789	199-8800	199-8802	199-8809
				199-8817								
PHR1	= 007714			#83-1881	139-5495	148-5990	153-6268					
PHR10	= 010120			#83-1890	131-4822	131-4895	131-4909					
PHR11	= 010140			#83-1891	131-5104							
PHR12	= 010202			#83-1892	332-16423							
PHR13	= 010240			#83-1893	332-16440							
PHR14	= 010266			#83-1894	96-2839	96-2864						
PHR15	= 010304			#83-1895	96-2866							
PHR16	= 010322			#83-1896	96-2837							
PHR17	= 010342			#83-1897	332-16414							

SYMBOL	VALUE	REFERENCES
PHR18	= 010366	#83-1898 336-16618
PHR19	= 010410	#83-1899 332-16428
PHR2	= 007730	#83-1882 325-16046 339-16809
PHR20	= 010430	#83-1900 332-16434
PHR21	= 005662	#83-1791 337-16700
PHR3	= 007746	#83-1883 89-2324
PHR4	= 007770	#83-1884 97-2910
PHR5	= 010004	#83-1885 335-16590
PHR6	= 010026	#83-1886 336-16662
PHR7	= 010050	#83-1887 90-2438 94-2722 333-16466
PHR8	= 010066	#83-1888 90-2452 90-2462
PHR9	= 010100	#83-1889 199-8803 199-8812
PM.SBE	= 012264	#81-1633 *86-2176 *104-3273 104-3274 336-16639 336-16649
PNT	= 001000	#83-1778
PRI	= 002000	#83-1779
PRI00	= 000000	#83-1770
PRI01	= 000040	#83-1769
PRI02	= 000100	#83-1768
PRI03	= 000140	#83-1764
PRI04	= 000200	#83-1763
PRI05	= 000240	#83-1762
PRI06	= 000300	#83-1761
PRI07	= 000340	#83-1760
PTABLE	034422	#82-1690 90-2434 94-2711 94-2718 *111-3660 137-5413 138-5449 322-15921 333-16455 333-16462
P.AAA	005662	#70-944 83-1791
P.AAB	005736	#70-959 83-1792
P.AAC	006042	#70-982 83-1793
P.AAD	006126	#70-1003 83-1794
P.AAE	006142	#70-1007 83-1795
P.AAF	006160	#70-1012 83-1796
P.AAG	006166	#70-1014 83-1797
P.AAH	006216	#70-1022 83-1798
P.AAI	006252	#70-1032 83-1799
P.AAJ	006270	#70-1037 83-1800
P.AAK	006320	#71-1049 83-1801
P.AAL	006376	#71-1065 83-1802
P.AAM	006446	#71-1079 83-1803
P.AAN	006466	#71-1085 83-1804
P.AAO	006534	#72-1102 83-1805
P.AAP	006564	#72-1110 83-1806
P.AAQ	006640	#72-1125 83-1807
P.AAR	006654	#72-1129 83-1808
P.AAS	006710	#72-1139 83-1809
P.AAT	006756	#73-1156 83-1810
P.AAU	007024	#73-1169 83-1811
P.AAV	007046	#73-1175 83-1812
P.AAW	007060	#73-1179 83-1813
P.AAX	007066	#73-1181 83-1814
P.AAY	007072	#73-1183 83-1815
P.AAZ	007100	#73-1185 83-1816
P.ABA	007112	#73-1189 83-1817

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
P.ABB		007130	#73-1194 83-1818
P.ABC		007152	#73-1200 83-1819
P.ABD		007200	#74-1212 83-1823
P.ABE		007206	#74-1214 83-1824
P.ABF		007212	#74-1216 83-1825
P.ABG		007220	#74-1218 83-1826
P.ABH		007230	#74-1221 83-1827
P.ABI		007240	#74-1224 83-1828
P.ABJ		007246	#74-1226 83-1829
P.ABK		007256	#74-1229 83-1830
P.ABL		007264	#74-1231 83-1831
P.ABM		007272	#74-1233 83-1832
P.ABN		007300	#74-1235 83-1833
P.ABO		007312	#74-1239 83-1834
P.ABP		007322	#74-1242 83-1835
P.ABQ		007332	#74-1245 83-1836
P.ABR		007336	#74-1247 83-1837
P.ABS		007344	#74-1249 83-1838
P.ABT		007354	#74-1252 83-1839
P.ABU		007370	#74-1256 83-1840
P.ABV		007400	#74-1259 83-1841
P.ABW		007412	#75-1267 83-1842
P.ABX		007416	#75-1269 83-1843
P.ABY		007424	#75-1271 83-1844
P.ABZ		007430	#75-1273 83-1845
P.ACA		007434	#75-1275 83-1846
P.ACB		007440	#75-1277 83-1847
P.ACC		007444	#75-1279 83-1848
P.ACD		007450	#75-1281 83-1849
P.ACE		007454	#75-1283 83-1850
P.ACF		007460	#75-1285 83-1851
P.ACG		007464	#75-1287 83-1852
P.ACH		007472	#75-1289 83-1853
P.ACI		007500	#75-1291 83-1854
P.ACJ		007504	#75-1293 83-1855
P.ACK		007510	#75-1295 83-1856
P.ACL		007514	#75-1297 83-1857
P.ACM		007520	#75-1299 83-1858
P.ACN		007524	#75-1301 83-1859
P.ACO		007530	#75-1303 83-1860
P.ACP		007534	#75-1305 83-1861
P.ACQ		007542	#75-1307 83-1862
P.ACR		007550	#75-1309 83-1863
P.ACS		007554	#75-1311 83-1864
P.ACT		007560	#75-1313 83-1865
P.ACU		007564	#75-1315 83-1866
P.ACV		007570	#75-1317 83-1867
P.ACW		007574	#76-1323 83-1868
P.ACX		007626	#76-1332 83-1869
P.ACY		007634	#76-1334 83-1870
P.ACZ		007642	#76-1336 83-1871
P.ADA		007650	#76-1338 83-1872

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
P.ADB		007656	#76-1340 83-1873
P.ADC		007664	#76-1342 83-1874
P.ADD		007672	#76-1344 83-1878
P.ADE		007700	#76-1346 83-1879
P.ADF		007706	#76-1348 83-1880
P.ADG		007714	#76-1350 83-1881
P.ADH		007730	#76-1354 83-1882
P.ADI		007746	#76-1359 83-1883
P.ADJ		007770	#76-1365 83-1884
P.ADK		010004	#76-1369 83-1885
P.ADL		010026	#77-1379 83-1886
P.ADM		010050	#77-1385 83-1887
P.ADN		010066	#77-1390 83-1888
P.ADO		010100	#77-1394 83-1889
P.ADP		010120	#77-1400 83-1890
P.ADQ		010140	#77-1406 83-1891
P.ADR		010202	#77-1418 83-1892
P.ADS		010240	#77-1428 83-1893
P.ADT		010266	#78-1440 83-1894
P.ADU		010304	#78-1445 83-1895
P.ADV		010322	#78-1450 83-1896
P.ADW		010342	#78-1456 83-1897
P.ADX		010366	#78-1463 83-1898
P.ADY		010410	#78-1469 83-1899
P.ADZ		010430	#78-1475 83-1900
P.AEA		010444	#78-1479 83-1901
P.AEB		010446	#78-1480 83-1902
P.AEC		010450	#78-1481 83-1903
P.AED		010454	#78-1483 83-1904
P.AEE		010460	#78-1485 83-1905
P.AEF		010502	#79-1495 83-1906
P.AEG		010526	#79-1502 83-1907
P.AEH		010602	#79-1517 83-1908
P.AEI		010656	#79-1532 83-1909
P.AEJ		010710	#79-1541 83-1910
P.AEK		010734	#80-1552 83-1911
P.AEL		010756	#80-1558 83-1912
P.AEM		011002	#80-1565 83-1913
P.AEN		011070	#80-1583 83-1914
P.AEO		011120	#80-1591 83-1915
P.AEP		011166	#81-1608 83-1916
P.AEQ		011202	#81-1612 83-1917
P.AER		011216	#81-1616 83-1918
QH1		002332	8-272 #8-286
QH2		002351	8-273 #8-287
QH3		002374	8-274 #8-288
QH4		002425	8-275 #8-289
QS1		002664	8-313 #9-347
QS10		003534	8-328 #9-362
QS11		003554	8-323 8-330 #9-363
QS12		003637	8-331 #9-364
QS13		003657	8-332 #9-365

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
QS14		003724	8-333 #9-366
QS15		003763	8-334 #9-367
QS16		004030	8-335 #9-368
QS17		004066	8-336 #9-369
QS2		002732	8-315 #9-348
QS3		003007	8-317 #9-349
QS4		003047	8-318 #9-350
QS5		003107	8-320 #9-351
QS6		003147	8-321 #9-352
QS7		003454	8-325 #9-359
QS8		003474	8-326 #9-360
QS9		003514	8-327 #9-361
QUICK		032674	#81-1642 *111-3643 *112-3691 199-8790 205-9127 325-16039 325-16063
RANDOM		005464	G *42-27 #42-37 83-1726 125-4379 149-6053 149-6055 *261-12203 261-12204 *263-12292
			263-12295 *265-12377 265-12378 *265-12381 265-12385 265-12391 265-12399 265-12401 *265-12405
RAND1		070540	#273-12823 323-15938
RAND2		073124	#281-13682 323-15940
RAND3		075444	#297-14537 323-15942
RAND4		100006	#312-15384 323-15949
RANGE		002224	G #8-155 83-1722 95-2796
RBUFF		022670	#81-1639 83-1787 83-1788 83-1790 166-6958 166-6964 166-7005 168-7093 180-7735
			185-8037 200-8842 205-9150 210-9400 220-9938 225-10237 258-12058 273-12853 273-13150
			282-13719 287-14018 297-14567 303-14879 313-15407 318-15706
RCBUFF	=	023470	#83-1788 42-11164
RDBUFF	=	022670	#83-1787 242-11163
RD.CO		034322	#82-1668 *85-2111 141-5627 *141-5628 *141-5632
RD.MIL		034326	#82-1672 *85-2113 *141-5636 *141-5638 332-16435
RD.THO		034324	#82-1670 *85-2112 *141-5631 141-5633 *141-5635
READ		045612	#145-5863 149-6057 153-6275 154-6315 154-6327 166-6960 166-7002 168-7090 181-7807
			181-7815 185-8039 201-8908 201-8916 206-9170 206-9178 210-9402 221-10007 221-10015
			225-10239 244-11275 244-11283 249-11554 249-11562 254-11833 254-11841 258-12060 273-12921
			273-12932 273-13152 283-13800 283-13808 287-14020 299-14658 299-14666 303-14881 314-15487
REFRES		002252	G #8-167 83-1725 89-2318 138-5455
RETRY		046224	#153-6245 165-6919 166-7007 168-7095 169-7157 171-7243 181-7768 183-7881 184-7968
			186-8080 200-8868 202-8976 204-9064 207-9238 208-9322 211-9443 221-9968 223-10081
			224-10168 226-10280 243-11221 245-11345 247-11436 248-11498 250-11624 252-11715 253-11777
			255-11903 257-11994 259-12101 273-12882 273-12993 273-13079 273-13189 282-13760 284-13869
			286-13956 288-14061 298-14618 300-14727 302-14814 304-14922 314-15451 316-15560 317-15643
RETRY:		034340	#82-1682 *84-2103 131-4815 131-5102 138-5479 144-5779 144-5790 146-5877 146-5888
			148-5975 148-5986 *153-6246 *155-6385
RE2		005362	41-1349 #41-1379
RE3		005360	41-1357 #41-1378
RE4		005356	41-1366 #41-1377
RN		005370	G #42-12 83-1726 125-4377 149-6052 261-12202 263-12291 265-12376
RNDSEC		070240	#263-12282 298-14589 313-15418
RNDU		070336	#264-12367 313-15403
RNDWC		070204	#261-12202 282-13724 298-14584 313-15413
RPTR		032672	#81-1641 *156-6444 *180-7735 181-7810 181-7813 182-7833 *200-8842 201-8911 201-8914
			201-8929 *205-9150 206-9173 206-9176 206-9191 *220-9938 221-10010 221-10013 222-10033
			*273-12853 273-12924 273-12930 273-12946 *282-13719 283-13803 283-13806 284-13826 *297-14567

REFERENCES

6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	5-65
6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65
6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65
6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65
6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65
6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65
6-80	6-80	6-80	6-80	6-80	6-80	6-80	6-80	6-80	6-80
7-85	7-85	7-101	7-101	7-101	7-101	7-85	7-85	7-85	7-85
7-117	7-117	8-143	8-143	8-143	8-143	7-101	7-101	7-101	7-117
8-272	8-272	8-272	8-272	8-272	8-272	8-259	8-259	8-259	8-272
8-272	8-272	8-272	8-272	8-272	8-272	8-272	8-272	8-272	8-272
8-273	8-273	8-273	8-273	8-273	8-273	8-273	8-273	8-273	8-273
8-274	8-274	8-274	8-274	8-274	8-274	8-274	8-274	8-274	8-274
8-274	8-274	8-274	8-274	8-274	8-274	8-274	8-274	8-274	8-274
8-275	8-275	8-275	8-275	8-275	8-275	8-275	8-275	8-275	8-275
8-277	8-277	8-302	8-302	8-302	8-302	8-275	8-275	8-275	8-277
8-313	8-313	8-313	8-313	8-313	8-313	8-313	8-313	8-313	8-313
8-315	8-315	8-315	8-315	8-315	8-315	8-314	8-314	8-314	8-315
8-316	8-316	8-317	8-317	8-317	8-317	8-315	8-315	8-315	8-316
8-317	8-317	8-317	8-317	8-317	8-317	8-317	8-317	8-317	8-317
8-318	8-318	8-318	8-318	8-318	8-318	8-317	8-317	8-317	8-318
8-318	8-318	8-318	8-318	8-318	8-318	8-318	8-318	8-318	8-318
8-320	8-320	8-320	8-320	8-320	8-320	8-318	8-318	8-318	8-320
8-320	8-320	8-320	8-320	8-320	8-320	8-319	8-319	8-319	8-320
8-321	8-321	8-321	8-321	8-321	8-321	8-320	8-320	8-320	8-321
8-321	8-321	8-321	8-321	8-321	8-321	8-321	8-321	8-321	8-321
8-323	8-323	8-323	8-323	8-323	8-323	8-322	8-322	8-322	8-323
8-323	8-323	8-323	8-323	8-323	8-323	8-323	8-323	8-323	8-323
8-325	8-325	8-325	8-325	8-325	8-325	8-324	8-324	8-324	8-325
8-326	8-326	8-326	8-326	8-326	8-326	8-325	8-325	8-325	8-326
8-327	8-327	8-327	8-327	8-327	8-327	8-326	8-326	8-326	8-327
8-328	8-328	8-328	8-328	8-328	8-328	8-327	8-327	8-327	8-328
8-329	8-329	8-330	8-330	8-330	8-330	8-328	8-328	8-328	8-329
8-330	8-330	8-330	8-330	8-330	8-330	8-330	8-330	8-330	8-330
8-331	8-331	8-331	8-331	8-331	8-331	8-331	8-331	8-331	8-331
8-332	8-332	8-332	8-332	8-332	8-332	8-332	8-332	8-332	8-332
8-333	8-333	8-333	8-333	8-333	8-333	8-333	8-333	8-333	8-333
8-334	8-334	8-334	8-334	8-334	8-334	8-334	8-334	8-334	8-334
8-335	8-335	8-335	8-335	8-335	8-335	8-335	8-335	8-335	8-335
8-336	8-336	8-336	8-336	8-336	8-336	8-336	8-336	8-336	8-336
8-339	8-339					8-336	8-336	8-336	8-339
SVCSUB = 000001	#6-13	#6-21							
SVCTAG = 000001	#6-13	#6-23	7-134	8-196	8-277	8-339			
SVCTST = 000001	#6-13	#6-20							
SYSERR = 041710	#131-4722	139-5511							
SLSYM = 010000	#6-13	#7-134	#8-196	#8-277	#8-339				
TOP.SE = 034500	#82-1704	95-2777	165-6902	180-7739	180-7745	185-8032	200-8846	200-8849	205-9154
	205-9157	210-9395	220-9942	220-9945	225-10232	243-11202	258-12053	263-12287	263-12293
	273-12857	273-12860	273-13142	282-13720	287-14013	297-14570	303-14874	313-15410	
TRIES = 033714	#82-1661	*84-2093	*155-6391	335-16585	337-16677				
TRT00 = 010444	#83-1901	97-2891							
TRT01 = 010446	#83-1902	97-2895							
TRT10 = 010450	#83-1903	97-2899							

SVCSUB = 000001
 SVCTAG = 000001
 SVCTST = 000001
 SYSERR = 041710
 SLSYM = 010000
 TOP.SE = 034500
 G
 TRIES = 033714
 TRT00 = 010444
 TRT01 = 010446
 TRT10 = 010450

CZMLBB
SYMBOL CROSS REFERENCE

CREATED BY MACRO ON 29-MAR-82 AT 13:44

PAGE 16
CREF

E 14

SEQ 0379

TRT11 = 010454
TSECT = 002230 G
TSARGC = 000002
TSCODE = 020130

REFERENCES

#83-1904	97-2903								
#8-158	83-1723	*95-2807	*95-2808	*95-2815	*95-2816	96-2821	96-2823	96-2338	
96-2848	96-2863								
#6-65	6-65	#6-65	6-65	6-65	#6-65	6-65	6-65	#6-65	
6-65	6-65	#6-65	6-65	6-65	#6-65	6-65	6-65	#6-65	
#8-272	8-272	#8-272	8-272	#8-272	8-272	#8-273	8-273	#8-273	
8-273	#8-273	8-273	#8-274	8-274	#8-274	8-274	#8-274	8-274	#8-274
#8-275	8-275	#8-275	8-275	#8-275	8-275	#8-313	8-313	#8-313	
8-313	#8-313	8-313	#9-314	8-314	8-314	#8-314	8-314	8-314	#8-314
#8-314	8-314	#8-314	8-314	#8-315	8-315	#8-315	8-315	#8-315	
8-315	#8-316	8-316	8-316	#8-316	8-316	8-316	#8-316	8-316	#8-316
#8-316	8-316	#8-317	8-317	#8-317	8-317	#8-317	8-317	8-317	#8-317
8-318	#8-318	8-318	#8-318	8-318	#8-319	8-319	8-319	8-319	#8-318
8-319	8-319	#8-319	8-319	#8-319	8-319	#8-320	8-320	8-320	#8-319
8-320	#8-320	8-320	#8-321	8-321	#8-321	8-321	#8-321	8-321	#8-320
#8-322	8-322	8-322	#8-322	8-322	8-322	#8-322	8-322	8-322	#8-321
8-322	#8-323	8-323	#8-323	8-323	#8-323	8-323	#8-323	8-323	#8-322
8-324	#8-324	8-324	#8-324	8-324	#8-324	8-324	#8-324	8-324	#8-323
8-325	#8-325	8-325	#8-325	8-325	#8-325	8-325	#8-325	8-325	#8-324
#8-326	8-326	#8-327	8-327	#8-327	8-327	#8-327	8-327	8-327	#8-325
8-328	#8-328	8-328	#8-328	8-328	#8-329	8-329	8-329	8-329	#8-326
8-329	8-329	#8-329	8-329	#8-329	8-329	#8-330	8-330	8-330	#8-327
8-330	#8-330	8-330	#8-331	8-331	#8-331	8-331	#8-331	8-331	#8-328
#8-332	8-332	#8-332	8-332	#8-332	8-332	#8-332	8-332	8-332	#8-329
8-333	#8-333	8-333	#8-334	8-334	#8-334	8-334	#8-334	8-334	#8-330
#8-335	8-335	#8-335	8-335	#8-335	8-335	#8-335	8-335	8-335	#8-331
8-336	#8-336	8-336				#8-336	8-336	#8-336	#8-332
#6-13									#8-333
#8-272	8-272	#8-273	8-273	#8-274	8-274	#8-275	8-275	#8-317	#8-334
8-317	#8-318	8-318	#8-320	8-320	#8-323	8-323	#8-330	8-330	#8-335
340-16868	340-16869	#340-16870							
#6-13									
#8-272	8-272	#8-273	8-273	#8-274	8-274	#8-275	8-275	#8-317	
8-317	#8-318	8-318	#8-320	8-320	#8-323	8-323	#8-330	8-330	
#6-13									
#8-272	8-272	#8-273	8-273	#8-274	8-274	#8-275	8-275	#8-317	
8-317	#8-318	8-318	#8-320	8-320	#8-323	8-323	#8-330	8-330	
#6-13									
#8-272	8-272	#8-273	8-273	#8-274	8-274	#8-275	8-275	#8-317	
8-317	#8-318	8-318	#8-320	8-320	#8-323	8-323	#8-330	8-330	
#6-13	6-13	7-134	8-196	8-277	8-339				
#6-13	6-39	#6-39	6-39	7-117	#7-117	7-117	7-134	7-134	
7-134	#7-134	8-143	#8-143	8-143	8-196	8-196	8-196	#8-196	
8-259	#8-259	8-259	8-277	8-277	8-277	#8-277	8-302	#8-302	
8-302	8-314	8-316	8-319	8-322	8-324	8-329	8-339	8-339	
8-339	#8-339	9-379	#9-379	9-379	9-385	9-385	9-385	#9-385	
9-411	9-411	9-411	#9-411						
#6-39	9-411								
#7-117	7-134	#8-143	8-196	#8-259	8-277	#8-302	8-314	8-316	
8-319	8-322	8-324	8-329	8-339	#9-379	9-385			
6-65	#340-16874								
#6-13									
#6-13									
#6-13									
#6-13									

TSERRN = 000000
TSEXCP = 000000
TSFREE = 105050 G
TSGMAN = 000000
TSHILI = 000012
TSLAST = 000000
TSLOLI = 000001
TSLSYM = 010000
TSNEST = 177777

TSNSO = 000000
TSNS1 = 000021
TSPTHV = 000000 G
TSPTHV = 000000
TSSAVL = 177777
TSSAVL = 177777
TSSUBN = 000000

CZMLBB
 SYMBOL CROSS REFERENCE
 SYMBOL VALUE
 T\$TAGL = 177777
 T\$TAGN = 010005
 T\$TEMP = 000000

MACRO ON 29-MAR-82 AT 13:44

PAGE 17
 CREF

F 14

SEQ 0380

REFERENCES

T\$TEST = 000000
 T\$TSTM = 177777
 T\$TSTS = 000000
 T\$SHAR = 010002
 T\$SHW = 010000
 T\$SPRO = 010004
 T\$SOF = 010003
 T\$SSW = 010001
 T1 = 102712
 UAM = 000200
 UP.HAR = 037422
 UP.RD. = 045240
 UP.SOF = 040104
 UP.WC. = 045332
 UP.WR. = 045146
 VEC = 032710
 WAITER = 044420
 WBUFF = 012670
 WCBUFF = 013670
 WC.COU = 034330
 WC.MIL = 034334
 WC.THO = 034332
 WDBUFF = 012670
 WHY.DR = 034446

G
 G

#6-13	7-117	7-117	#7-117	8-143	8-143	#8-143	8-259	8-259
#8-259	8-302	8-302	#8-302	9-379	9-379	#9-379		
#7-101	7-101	7-101	#7-101	#7-134	7-134	#8-196	8-196	#8-272
8-272	#8-272	8-272	#8-272	8-272	#8-273	8-273	#8-273	8-273
#8-273	8-273	#8-274	8-274	#8-274	8-274	#8-274	8-274	#8-275
8-275	#8-275	8-275	#8-275	8-275	#8-277	8-277	#8-313	8-313
#8-313	8-313	#8-313	8-313	#8-315	8-315	#8-315	8-315	#8-315
8-315	#8-317	8-317	#8-317	8-317	#8-317	8-317	#8-318	8-318
#8-318	8-318	#8-318	8-318	#8-320	8-320	#8-320	8-320	#8-320
8-320	#8-321	8-321	#8-321	8-321	#8-321	8-321	#8-323	8-323
#8-323	8-323	#8-323	8-323	#8-325	8-325	#8-325	8-325	#8-325
8-325	#8-326	8-326	#8-326	8-326	#8-326	8-326	#8-327	8-327
#8-327	8-327	#8-327	8-327	#8-328	8-328	#8-328	8-328	#8-328
8-328	#8-330	8-330	#8-330	8-330	#8-330	8-330	#8-331	8-331
#8-331	8-331	#8-331	8-331	#8-332	8-332	#8-332	8-332	#8-332
8-332	#8-333	8-333	#8-333	8-333	#8-333	8-333	#8-334	8-334
#8-334	8-334	#8-334	8-334	#8-335	8-335	#8-335	8-335	#8-335
8-335	#8-336	8-336	#8-336	8-336	#8-336	8-336	#8-339	8-339
#9-385	9-385	#9-411	9-411					
#6-13								
#6-13								
#6-13								
#8-259	8-259	8-277						
#7-117	7-117	7-134						
#9-379								
#8-302	8-302	8-339						
#8-143	8-143	8-196						
7-101	#326-16093							
#83-1776								
#103-3203	168-7120	171-7268	185-7997	187-8109	204-9089	209-9351	211-9468	225-10197
227-10309	247-11461	252-11740	257-12019	259-12126	273-13107	273-13217	286-13981	288-14086
302-14839	304-14947	318-15672	319-15774					
#141-5624	146-5880							
#108-3452	169-7141	171-7285	185-8014	187-8126	205-9110	209-9368	211-9485	225-10214
227-10326	248-11482	253-11761	258-12040	259-12143	273-13124	273-13234	287-14002	289-14107
302-14856	304-14964	318-15689	320-15795					
#142-5688	148-5978							
#140-5560	144-5782							
#81-1652	*88-2290	89-2349						
#134-5254	137-5421	138-5473						
#81-1638	83-1785	83-1786	83-1789	*114-3806	*114-3817	120-4175	*122-4250	*122-4251
*122-4258	*125-4372	*125-4373	*125-4374	*125-4379	156-6441	165-6907	165-6917	166-6963
169-7145	169-7155	171-7241	180-7734	200-8841	205-9149	220-9937	273-12852	282-13718
297-14566	313-15406							
#83-1786	242-11159	242-11162						
#82-1674	*85-2114	142-5691	*142-5692	*142-5696				
#82-1678	*85-2116	*142-5700	*142-5702	332-16441				
#82-1676	*85-2115	*142-5695	142-5697	*142-5699				
#83-1785	242-11155	242-11161						
#82-1698	*85-2141	*94-2738	*95-2765	*96-2844	*96-2871	*165-6923	*165-6933	*165-6947
*166-6990	*167-7016	*167-7026	*167-7040	*167-7051	*169-7161	*169-7171	*170-7189	*170-7200

REFERENCES

SYMBOL	VALUE	REFERENCES
		*181-7773 *181-7784 *181-7799 *182-7860 *183-7886 *183-7897 *183-7908 *183-7924 *200-8872
		*201-8886 *201-8900 *202-8959 *202-8981 *203-8995 *203-9009 *203-9020 *207-9221 *207-9243
		*207-9253 *207-9267 *208-9282 *221-9973 *221-9984 *221-9999 *222-10060 *223-10086 *223-10097
		*223-10112 *223-10124 *243-11226 *243-11237 *244-11256 *245-11328 *245-11350 *246-11365 *246-11380
		*246-11392 *248-11503 *248-11514 *249-11533 *250-11607 *250-11629 *251-11644 *251-11659 *251-11671
		*253-11782 *253-11793 *254-11812 *255-11886 *255-11908 *255-11919 *256-11938 *256-11950 *273-12887
		*273-12898 *273-12913 *273-12973 *273-12998 *273-13009 *273-13024 *273-13039 *282-13764 *283-13778
		*283-13792 *284-13852 *284-13873 *285-13887 *285-13901 *285-13912 *298-14622 *298-14632 *299-14650
		*300-14710 *300-14731 *300-14741 *301-14759 *301-14770 *301-14770 *314-15455 *314-15465 *314-15479 *315-15539
WPTR	032670	*316-15564 *316-15574 *316-15588 *316-15599 *333-16496 *180-7734 180-7752 181-7766 182-7821 182-7824
		#81-1640 156-6438 *156-6441 156-6442 200-8856 201-8918 201-8921 201-8928
		182-7832 185-8018 *185-8019 *200-8841 200-8856 201-8918 201-8921 201-8928
		205-9114 *205-9115 *205-9149 206-9180 206-9183 206-9190 209-9377 *209-9378 *220-9937
		220-9952 220-9962 221-10017 222-10024 222-10032 225-10218 *225-10219 *273-12852 273-12867
		273-12880 273-12934 273-12937 273-12945 273-13128 *273-13129 *282-13718 282-13748 282-13758
		283-13810 283-13813 283-13821 *287-14005 *297-14566 298-14606 298-14616 299-14668 299-14671
		299-14679 302-14812 *302-14858 *313-15406 313-15435 314-15449 315-15501 315-15504 315-15512
		*318-15691
WRD11	= 007240	#83-1828 90-2436 94-2720 94-2728 94-2751 96-2826 96-2853 333-16464 333-16490
WRD15	= 007246	#83-1829 100-3055 139-5497 144-5793 146-5891 148-5989
WRD16	= 007256	#83-1830 138-5485 144-5794 153-6258
WRD17	= 007264	#83-1831 138-5488 146-5892 153-6278
WRD18	= 007272	#83-1832 153-6257 153-6267 153-6277 154-6337 155-6361
WRD19	= 007300	#83-1833 154-6336
WRD2	= 007200	#83-1823 153-6259 153-6269 153-6279 325-16047
WRD20	= 007312	#83-1834 100-3056 155-6360
WRD21	= 007322	#83-1835 94-2727 94-2750 96-2825 96-2852 333-16489
WRD24	= 007332	#83-1836 242-11189 244-11264 254-11822
WRD25	= 007336	#83-1837 249-11543
WRD3	= 007206	#83-1824 339-16810 339-16818
WRD34	= 007344	#83-1838 89-2313 164-6866 180-7709 199-8784 219-9906 242-11149 322-15895
WRD35	= 007354	#83-1839 242-11184
WRD36	= 007370	#83-1840 88-2300 89-2320
WRD37	= 007400	#83-1841 88-2298 89-2322
WRD38	= 007412	#83-1842 89-2311
WRD4	= 007212	#83-1825 325-16045 339-16808 339-16817
WRD40	= 007416	#83-1843 89-2312 89-2325
WRD41	= 007424	#83-1844 89-2309
WRD6	= 007220	#83-1826 95-2772
WRD7	= 007230	#83-1827 95-2775
WRITE	045424	#143-5765 153-6255 153-6288 153-6294 154-6307 154-6322 165-6909 165-6914 180-7754
		180-7759 200-8858 200-8863 220-9954 220-9959 243-11211 243-11216 248-11488 248-11493
		253-11767 253-11772 273-12869 273-12877 282-13750 282-13755 298-14608 298-14613 313-15437
		314-15446
WR.COU	034314	#82-1662 *84-2104 140-5563 *140-5564 *140-5568
WR.MIL	034320	#82-1666 *84-2106 *140-5572 *140-5574 332-16429
WR.THO	034316	#82-1664 *84-2105 *140-5567 140-5569 *140-5571
X\$ALWA	= 000000	#6-13 8-319 8-324
X\$FALS	= 000040	#6-13 8-314 8-316
X\$OFFS	= 000400	#6-13 8-314 8-316 8-319 8-322 8-324 8-329
X\$TRUE	= 000020	#6-13 8-314 8-316 8-319 8-322 8-324 8-329
SEND.L	105052 G	#340-16881

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
\$PATCH		004134 G	#9-402
\$SAVE2		005262 G	34-1022 39-1269 #41-1344 116-3959 125-4371 143-5765 145-5863 147-5961 341-16905
\$SAVE3		005276 G	13-169 14-217 18-384 19-438 29-829 30-880 #41-1351 263-12282 341-16904
\$SAVE4		005314 G	#41-1359 84-2078 88-2287 111-3636 114-3793 137-5408 264-12367 322-15893 341-16904
\$SAVE5		005334 G	35-1091 39-1269 #41-1368 90-2410 93-2703 103-3204 108-3453 118-4094 131-4722
			133-5199 153-6245 164-6863 179-7702 199-8781 219-9903 242-11146 273-12823 281-13682
\$T1		102536	297-14537 312-15384 332-16405 341-16904
			#325-16039 326-16094

MACRO NAME	REFERENCES									
BGNHRD	8-259									
BGNHW	#7-117									
BGNMOD	6-39									
BGNPRO	9-379									
BGNSFT	#8-302									
BGNSW	#8-143									
DESCRI	#7-85									
DEVTYP	#6-80									
DISPAT	7-101									
ENDHRD	#8-277									
ENDHW	7-134									
ENDMOD	9-4,1									
ENDPRO	#9-385									
ENDSFT	8-339									
ENDSW	8-196									
ERRTBL	7-94									
GPRMA	#8-272	#8-273								
GPRMD	8-274	8-275	8-317	8-318	8-320	8-323	8-330			
GPRML	#8-313	#8-315	#8-321	#8-325	#8-326	#8-327	#8-328	#8-331	#8-332	#8-333
	#8-334	#8-335	#8-336							
HEADER	6-65									
MSBYTE	#6-65	#6-65	#6-65	#6-65						
MSCNTO	#8-272	8-272	#8-273	8-273	#8-274	8-274	#8-275	8-275	#8-313	8-313
	#8-315	8-315	#8-317	8-317	#8-318	8-318	#8-320	8-320	#8-321	8-321
	#8-323	8-323	#8-325	8-325	#8-326	8-326	#8-327	8-327	#8-328	8-328
	#8-330	8-330	#8-331	8-331	#8-332	8-332	#8-333	8-333	#8-334	8-334
	#8-335	8-335	#8-336	8-336						
MSDATA	#6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65
	6-65	6-65	6-65	6-65	6-65	6-65	#6-65	6-65	6-65	6-65
	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65
	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65	6-65
	6-80	#7-85	7-85	6-65	6-65	6-65	6-65	6-65	6-65	#6-80
MSDECR	#7-134	7-134	#8-196	8-196	#8-277	8-277	#8-339	8-339	#9-385	9-385
	#9-411	9-411								
MSDEFA	#8-272	#8-272	#8-273	#8-273	#8-274	#8-274	#8-275	#8-275	#8-313	#8-313
	#8-315	#8-315	#8-317	#8-317	#8-318	#8-318	#8-320	#8-320	#8-321	#8-321
	#8-323	#8-323	#8-325	#8-325	#8-326	#8-326	#8-327	#8-327	#8-328	#8-328
	#8-330	#8-330	#8-331	#8-331	#8-332	#8-332	#8-333	#8-333	#8-334	#8-334
	#8-335	#8-335	#8-336	#8-336						
MSENDE	#7-134	#8-196	#8-277	#8-339	#9-411					
MSEXCP	#8-272	8-272	8-272	#8-273	8-273	8-273	#8-274	8-274	8-274	#8-275
	8-275	8-275	#8-317	8-317	8-317	#8-318	8-318	8-318	#8-320	8-320
	8-320	#8-323	8-323	8-323	#8-330	8-330	8-330			
MSGEN	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65
	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65
	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65
	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65
	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65
	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65
	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65
	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65
	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65
	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65	#6-65
	#7-94	#7-94	#7-101	#7-101	#7-117	#7-117	#7-117	#7-117	#7-85	#7-85
									#7-134	#7-134

MACRO NAME	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	
MSGETS	#8-143 #8-302 #7-134 #8-319 #9-385	#8-143 #8-302 7-134 8-319 9-385	#8-143 #8-339 #8-196 #8-322 #9-411	#8-143 #8-339 8-196 8-322 9-411	#8-196 #9-379 #8-277 #8-324	#8-196 #9-379 8-277 8-324	#8-259 #8-259 #8-314 #8-329	#8-259 #8-259 8-314 8-329	#8-277 #8-277 #8-316 #8-339	#8-277 #8-277 8-316 8-339	
MSGETT	#8-314 #8-329	8-314 8-329	#8-316	8-316	#8-319	8-319	#8-322	8-322	#8-324	8-324	
MSGNGB	#6-39 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #7-85 #8-143	#6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #7-94 #8-259	#6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #7-94 #8-259	#6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #7-101 #8-302	#6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #7-101 #8-302	#6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #7-117 #9-379	#6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #7-117 #9-379	#6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #7-117 #9-379	#6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #7-117 #9-379	#6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #7-117 #9-379	#6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #7-117 #9-379
MSGNIB	#6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-80 #7-101 8-272 8-274 #8-277 #8-315 8-317 #8-320 #8-322 #8-325 8-327 8-330 8-332 #8-335	6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 #6-80 7-101 8-272 8-274 8-277 8-315 8-317 8-320 8-322 8-325 8-327 8-330 8-332 8-335	6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 #6-65 6-80 #7-117 8-272 8-274 #8-302 8-315 #8-318 8-320 #8-323 8-325 #8-328 8-330 #8-333 8-335	6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-80 7-117 #8-273 8-274 8-302 8-315 8-318 8-320 8-323 8-325 8-328 8-330 8-333 8-335	6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-80 #7-85 #8-143 8-273 8-275 #8-313 #8-316 8-318 8-320 8-323 8-326 8-328 #8-331 8-333 #8-336 #8-277	6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 #7-85 #8-143 8-273 8-275 8-313 8-316 8-318 8-320 8-323 8-326 8-328 8-331 8-333 8-336 #8-277	6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 #7-85 #8-143 8-273 8-275 8-313 8-316 8-318 8-320 8-323 8-326 8-328 8-331 8-333 8-336 #8-277	6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 #7-85 #8-143 8-273 8-275 8-313 8-316 8-318 8-320 8-323 8-326 8-328 8-331 8-333 8-336 #8-277	6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 #7-85 #8-143 8-273 8-275 8-313 8-316 8-318 8-320 8-323 8-326 8-328 8-331 8-333 8-336 #8-277	6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 #7-85 #8-143 8-273 8-275 8-313 8-316 8-318 8-320 8-323 8-326 8-328 8-331 8-333 8-336 #8-277	6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 6-65 #7-85 #8-143 8-273 8-275 8-313 8-316 8-318 8-320 8-323 8-326 8-328 8-331 8-333 8-336 #8-277
MSGNTA	#7-134	#7-134	#8-196	#8-196	#8-277	#8-277	#8-339	#8-339	#8-339	#8-339	
MSHAPT	#6-65	#6-65									
MSHNAP	#6-65	#6-65									
MSINCR	#6-39 #8-259 #9-379	#6-39 #8-259 #9-379	#7-117 #8-259	#7-117 #8-259	#7-117 #8-302	#7-117 #8-302	#8-143 #8-302	#8-143 #8-302	#8-143 #9-379	#8-143 #9-379	
MSMCHI	#6-13	#6-13									
MSMCLO	#6-13	#6-13									
MSPOP	#7-134 #9-411	7-134 9-411	#8-196	8-196	#8-277	8-277	#8-339	8-339	#9-385	9-385	
MSPUSH	#6-39 #9-379	#6-39 #9-379	#7-117	#7-117	#8-143	#8-143	#8-259	#8-259	#8-302	#8-302	

