


TA11

MOTION TEST
MD-11-DZTAD-C

EP-DZTAD-C-DL-A
COPYRIGHT © 1976
FICHE 1 OF 1

NOV 1976
digital
MADE IN U.S.A.



IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZTAD-0-0
PRODUCT NAME: TALL MOTION TEST
DATE REVISED: 21 JUNE 76
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: JIM LACEY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1973, 1976 BY DIGITAL EQUIPMENT CORPORATION

CONTENTS

1. ABSTRACT
2. REQUIREMENTS
 - 2.1 EQUIPMENT
 - 2.2 STORAGE
 - 2.3 PRELIMINARY PROGRAMS
3. LOADING PROCEDURE
4. STARTING PROCEDURE
 - 4.1 CONTROL SWITCH SETTINGS
 - 4.2 STARTING ADDRESS
 - 4.3 PROGRAM & OPERATOR ACTION
5. OPERATING PROCEDURE
 - 5.1 OPERATIONAL SWITCH SETTINGS
 - 5.2 SUBROUTINE ABSTRACTS
6. ERRORS
7. RESTRICTIONS
8. MISCELLANEOUS
 - 8.1 EXECUTION TIME
 - 8.2 STACK POINTER
 - 8.3 PASS COUNTER
 - 8.4 ITERATIONS
 - 8.5 SPECIAL REGISTERS
9. PROGRAM DESCRIPTION

1. ABSTRACT

THIS PROGRAM CONTAINS A SERIES OF TESTS THAT CHECK THE TUBO DRIVE FOR PROPER OPERATION.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 COMPUTER WITH OR WITHOUT HARDWARE SWITCH REGISTER WITH CONSOLE TELETYPE, AND A TAII CASSETTE

2.2 STORAGE

THIS PROGRAM REQUIRES APPROX. 4K STORAGE.

2.3 PRELIMINARY PROGRAMS

MAINDEC-11-DZTAA
 MAINDEC-11-DZTAB
 MAINDEC-11-DZTAC

3. LOADING PROCEDURE

USE STANDARD PROCEDURE FOR LOADING .ABS TAPES OR A CASSETTE TAPE.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

SEE 5.1.

4.2 STARTING ADDRESSES

200 NORMAL STARTING ADDRESS
 204 SELECT DRIVE(S) BEFORE STARTING TEST
 210 SELECT DRIVE(S) AND ADDRESSES BEFORE STARTING TEST
 214 SETUP FOR MANUAL LOOPING
 220 WRITE FILE GAP FROM BOT TO EOT
 224 WRITE CONTINUOUS BLOCKS OF DATA
 230 READ CONTINUOUS BLOCKS OF DATA
 234 WRITE FILE GAP AND A BLOCK OF DATA
 240 READ BLOCK OF DATA AND INTO A FILE GAP
 244 SPACE FWD FILE GAP FROM BOT TO EOT
 250 BACK SPACE FILE GAPS



4.3 PROGRAM & OPERATOR ACTION

1. LOAD PROGRAM INTO MEMORY (SEE SECTION 3.1)
2. LOAD A WRITE ENABLED CASSETTE IN BOTH DRIVES
3. REWIND BOTH DRIVES
4. LOAD ADDRESS 200.
5. SET SWITCHES (SEE SECTION 5.1)
6. PRESS START.
7. THE PROGRAM WILL LOOP & TTY BELL WILL RING ONCE EVERY PASS. IF SW<10>=0.

*** NOTE: IF USING THE SOFTWARE SWITCH REGISTER THE PROGRAM WILL TYPE "SWR=XXXXXX NEW=" AFTER TYPING THE NAME OF THE PROGRAM.

4.3.1 DRIVE SELECTION

STARTING THE PROGRAM AT 200 WILL RESULT IN AUTOMATIC SELECTION OF DRIVES "A" AND "B" TO BE TESTED.

NOTE: IF LOAD MEDIUM IS CASSETTE WITH STANDARD VECTOR PROGRAM WILL RESPOND AS IF STARTED AT 210.

STARTING THE PROGRAM AT 204, 210, OR 214 ALLOWS THE OPERATOR TO SELECT THE DRIVE(S) TO BE TESTED.

THE PROGRAM WILL TYPE "DRIVE(S)?".

EITHER OR BOTH DRIVES CAN BE SELECTED BY TYPING "A" AND/OR "B" FOLLOWED BY A CARRIAGE RETURN.

4.3.1.1 DRIVE SELECTION EXAMPLES

```
DRIVE(S)? A,B
DRIVE(S)? AB
DRIVE(S)? B,A
DRIVE(S)? B
```

4.3.2 ADDRESS SELECTION

STARTING THE PROGRAM AT 210 OR 214 ALLOWS THE OPERATOR TO CHANGE THE "CONTROL AND STATUS" AND "DATA BUFFER" REGISTER ADDRESSES, THE VECTOR ADDRESS AND THE PRIORITY LEVEL.

THE PROGRAM WILL ASK FOR THE DRIVES TO BE TESTED AS PER 4.3.1. AFTER THE DRIVES HAVE BEEN SELECTED IT WILL ASK FOR:

1. BUS ADDRESS OF THE CONTROL AND STATUS REGISTER (TACS)
2. VECTOR ADDRESS
3. PRIORITY LEVEL

AND THE OPERATOR MUST RESPOND WITH THE DESIRED PARAMETER OR A CARRIAGE RETURN (WHICH IMPLIES LEAVE AS IS). WHEN ALL PARAMETERS HAVE BEEN DEFINED THE PROGRAM WILL TYPE THEM BACK OUT AND ASK IF THEY ARE OK AT WHICH TIME THE OPERATOR RESPONDES WITH A "Y" OR A "CARRIAGE RETURN" FOR "YES" ANYTHING ELSE IS A "NO".

4.3.2.1 ADDRESS SELECTION EXAMPLES

```
DRIVES(S) A
TACS? 177500
VECTOR? 260
PRIORITY? 6
TACS=177500 TADB=177502 VECTOR=000260 PRIORITY=000300
OK?
```

```
DRIVE(S) A,B
TACS? 470
VECTOR?
PRIORITY?
TACS=177470 TADB=177472 VECTOR=000260 PRIORITY=000300
OK?
```

4.3.3 SUBTEST LOOPING

THE SCOPE ROUTINE (REFER 5.2.1) PROVIDES A MEANS BY WHICH THE OPERATOR CAN SPECIFY THE FIRST ADDRESS OF A SCOPE LOOP.

THE OPERATOR TYPES A "CONTROL C" (IC) AND WHEN THE NEXT SCOPE STATEMENT IS EXECUTED THE PROGRAM WILL ASK FOR:

1. TEST PC--- THE FIRST ADDRESS OF THE TEST (MUST BE A SCOPE)
2. LOOP PC--- THE ADDRESS TO LOOP BACK TO

4.3.3.1 SUBTEST LOOPING EXAMPLES

```
:OPERATOR TYPES "IC"
↑TEST PC" 2242
LOOP PC"
```

```
:OPERATOR TYPES "2242""CARRIAGE RETURN "(CR)"
:OPERATOR TYPES "CR" WHICH
;IMPLIES "LOOP PC"="TEST PC"
```

```
:OPERATOR TYPES "IC"
↑TEST PC" 3000
LOOP PC" 3020
```

```
:OPERATOR TYPES "3000""CR"
:OPERATOR TYPES "3020""CR"
:PROGRAM USES THIS AS THE
:FIRST ADDRESS OF THE SCOPE
;LOOP
```

```
:OPERATOR TYPES "IC"
↑TEST PC"
```

```
:OPERATOR TYPES "CR"
:PROGRAM CONTINUES
:FROM THIS POINT
```

5. OPERATING PROCEDURE

SEG 0007

5.1 OPERATIONAL SWITCH SETTINGS

IF THE DIAGNOSTIC IS RUN ON A CPU WITHOUT A SWITCH REGISTER THEN A SOFTWARE SWITCH REGISTER IS USED WHICH ALLOWS THE USER THE SAME SWITCH OPTIONS AS THE HARDWARE SWITCH REGISTER. IF THE HARDWARE SWITCH REGISTER DOES NOT EXIST OR IF ONE DOES AND IT CONTAINS ALL ONES (177777) THEN THE SOFTWARE SWITCH REGISTER (LOC. 176) IS USED.

CONTROL:

THIS PROGRAM ALSO SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER (LOC. 176) FROM THE TTY. THIS CAN BE ACCOMPLISHED BY DOING THE FOLLOWING:

- 1) TYPE CONTROL G (<G>); THIS WILL ALLOW THE TTY TO ENTER DATA INTO LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
- 2) THE MACHINE WILL THEN TYPE: SWR=XXXXXXNEW= (XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWITCH REGISTER.)
- 3) AFTER THE '*NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE TTY:
 - A) TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A <CR>. (ONLY NUMBERS BETWEEN 0-7 WILL BE ACCEPTED AND ONLY 6 NUMBERS WILL BE ALLOWED) IF A <CP> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH REGISTER CONTENTS WILL NOT BE CHANGED.
 - B) IF A CONTROL U (<U>) IS DEPRESSED THEN THE PROGRAM WILL SEND YOU BACK TO STEP 2.

WITH SW<15:08>=0 THE PROGRAM WILL PRINT OUT ON ERRORS AND CONTINUE IN TEST. BELL WILL RING AT COMPLETION OF A PASS. THE SWITCH SETTINGS ARE:

SW<15>=1...HALT ON ERROR
 SW<14>=1...LOOP ON TEST
 SW<13>=1...INHIBIT ERROR TYPEOUTS
 SW<11>=1...INHIBIT ITERATIONS
 SW<10>=1...RING BELL ON ERROR
 SW<10>=0...RING BELL ON PASS COMPLETE
 SW<09>=1...LOOP ON ERROR
 SW<07>=1...LOCK ON CURRENT DRIVE
 SW<06>=1...DELAY AT END OF EACH FUNCTION
 SW<05>=1...RUN WITHOUT INTERRUPTS
 SW<04>=1...IGNORE BLOCK CHECK ERRORS
 SW<03>=1...INHIBIT DATA COMPARE

5.2 SUBROUTINE ABSTRACTS

5.2.1 SCOPE

THIS SUBROUTINE CALL (VIA AN IOT INSTRUCTION) IS PLACED BETWEEN EACH TEST IN THE INSTRUCTION SECTION. IT RECORDS THE STARTING ADDRESS OF EACH TEST IN LOCATION "\$LPADR" AND "\$LPERR" AS IT IS BEING ENTERED.

THIS ROUTINE SUPPORTS THE S/W SWITCH REG FUNCTIONS
NOTE: THIS ROUTINE CHECKS THE TTY INPUT BUFFER FOR A "CONTROL C" (REFER TO 4.3.3)

5.2.2 TRAPCATCHER

A ".+2" - "HALT" SEQUENCE IS REPEATED FROM LOC. 0 TO LOC. 776 TO CATCH ANY UNEXPECTED TRAPS. THUS, ANY UNEXPECTED TRAPS WILL HALT AT THE DEVICE TRAP VECTOR +2.

5.2.3 ERROR

THIS SUBROUTINE CALL (VIA A EMT INSTRUCTION) IS USED TO REPORT ALL ERRORS. (REFER TO 6.)

*** THIS ROUTINE SUPPORTS THE S/W SWITCH REG FUNCTIONS
*** IF THE PROCESSOR HALTS (BIT 15=1), OPERATOR CAN RESET S/W SWITCH REGISTER BY HITTING A "CONTROL G" (<G>) BEFORE HITTING CONTINUE.

5.2.4 TRAP

A NUMBER OF SUBROUTINES ARE CALLED BY THE TRAP INSTRUCTION. FOLLOWING IS THE CALLS USED AND THE STARTING ADDRESS OF THE ROUTINE.

5.2.4.1 TYPE (\$TYPE)

TYPE AN ASCIZ STRING ON THE TTY

5.2.4.2 RDCHR (\$RDCHR)

READ A SINGLE ASCII CHARACTER FROM THE TTY

5.2.4.3 RDLIN (\$RDLIN)

READ AN ASCII STRING FROM THE TTY

5.2.4.4 SETLOOP (T.SETLOOP)

SETUP TO LOOP AS PER THE TTY

5.2.5 THE FOLLOWING "TRAP" CALLS ARE WHAT ARE USED TO PERFORM THE TESTS.

THE ROUTINES THAT ARE CALLED IS WHAT MAKES UP THE HEART OF THIS PROGRAM.

5.2.5.1 WFG (T.WFG) WRITE A FILE GAP

5.2.5.2 WRITE (T.WRIT) WRITE A BLOCK OF DATA

5.2.5.3 READ (T.READ) READ A BLOCK OF DATA

5.2.5.4 BSFG (T.BSFG) BACK SPACE A FILE GAP

5.2.5.5 BSBG (T.BSBG) BACK SPACE A BLOCK GAP

5.2.5.6 SFFG (T.SFFG) SPACE FORWARD A FILE GAP

5.2.5.7 SFBG (T.SFBG) SPACE FORWARD A BLOCK GAP

5.2.5.8 REWIND (T.RWIND) REWIND THE TAPE TO BOT

5.2.5.9 SELDRV (T.SELDRV) SELECT A DRIVE

5.2.5.10 BLKCMP (T.BLKCMP) COMPARE READ AND WRITE BUFFERS



5.2.6 THE FOLLOWING SUBROUTINES ARE CALLED BY A JSR

5.2.6.1 DO.CMD

THIS ROUTINE WILL LOAD THE LOW BYTE OF THE "TACS" WITH THE FIRST BYTE FOLLOWING THE CALL.

WHEN THE FUNCTION IS TO BE PERFORMED WITH "INTERRUPT ENABLE"=1 THE TAIL VECTOR IS SET TO "SERV". WHEN THE FUNCTION IS TO BE PERFORMED WITH "INTERRUPT ENABLE"=0 THE VECTOR IS SET TO "BADINT"

NOTE SWR(5) PROVIDES OVERRIDE CAPABILITIES OF "INTERRUPT ENABLE"=1.

5.2.6.2 WAITFLAG

THIS ROUTINE IS CALLED AFTER A COMMAND HAS BEEN SENT TO THE TAIL. IT WAITS A PREDETERMINED AMOUNT OF TIME AND TAKES ONE OF THREE EXITS.

THE EXITS FOLLOW THE CALL AND ARE:

1. ERROR NO FLAGS OCCURRED
2. ERROR NO INTERRUPT OCCURRED
3. NORMAL RETURN

5.2.6.3 FLAGS

THIS ROUTINE IS CALLED TO DETERMINE WHAT FLAGS ARE UP. THIS ROUTINE WILL TAKE ONE OF FOUR RETURNS DEPENDING ON THE FLAGS.

THE RETURNS FOLLOW THE CALL AND ARE:

1. "TRANSFER REQUEST"=0 AND "READY"=0
2. "TRANSFER REQUEST"=1
3. "READY"=1 AND "ERROR"=0
4. "READY"=1 AND "ERROR"=1

5.2.6.3 DO.CRC

THIS ROUTINE IS USED TO CALCULATE "CRC". IT WORKS ON ONE BYTE AT A TIME WHICH MUST BE IN R0 WHEN CALLED.

5.2.6.4 A2OCT

THIS ROUTINE CHANGES AN ASCII STRING TO AN OCTAL NUMBER.

5.2.6.5 GETDRV

THIS ROUTINE IS USED TO ASK THE OPERATOR WHICH DRIVE(S) ARE TO BE TESTED

5.2.6.6 ASKPDR

THIS ROUTINE IS USED TO INPUT THE ADDRESSES FOR THE "TACS", "TADB" AND THE VECTOR AND THE PRIORITY LEVEL TO USE.

5.2.6.7 TYPERR

THIS ROUTINE IS USED TO TYPE OUT THE "ERROR" DATA

5.2.6.8 EXAM

THIS ROUTINE IS USED TO DETERMINE WHICH DRIVE(S) ARE AVAILABLE FOR TESTING.

5.2.7 THE FOLLOW ROUTINES ARE USED TO MAKE ADJUSTMENTS TO THE TUBO. BEFORE USING ANY OF THEM LOAD AND START 214.

5.2.7.1 WFGSUB

WRITE FILE GAPS FROM "BOT" TO "EOT"
START AT 220
THIS ROUTINE CAN BE USED TO ADJUST THE "WRITE GAP MONO" AND THE "WRITE DELAY MONO".

5.2.7.2 WRTSUB

WRITE CONTINUOUS BLOCKS OF DATA
START AT 224
THE PROGRAM WILL HALT THREE(3) TIMES
AFTER EACH HALT SET THE SWR AND PRESS CONTINUE
HALT 1 --- SWR<7:0> = NUMBER OF BYTES PER BLOCK
HALT 2 ---SWR<7:0> = PATTERN DESIRED
HALT 3 --- SWR<15:0> = OPERATIONAL SWITCH SETTINGS
THIS ROUTINE CAN BE USED TO ADJUST THE "GAP TIME MONO"
** IF USING SOFTWARE SWITCH REGISTER, AFTER
EACH HALT OPERATOR WILL BE PROMPTED
FOR THE VALUE WITH "SWR=XXXXXX NEW="

5.2.7.3 RDSUB

READ CONTINUOUS BLOCKS OF DATA
START AT 230
THIS ROUTINE CAN BE USED TO ADJUST THE "SIGNAL MONO"
AND THE "THRESHOLD POT"

5.2.7.4 WGPBLK

WRITE A FILE GAP AND A BLOCK OF DATA FROM BOT TO ECT
START AT 234
THE PROGRAM WILL HALT THREE (3) TIMES
AFTER EACH HALT SET THE SWR AND PRESS CONTINUE
HALT 1 --- SWR<7:0> = NUMBER OF BYTES PER BLOCK
HALT 2 --- SWR<7:0> = PATTERN DESIRED
HALT 3 --- SWR<15:0> = OPERATIONAL SWITCH SETTINGS
THIS ROUTINE CAN BE USED TO ADJUST THE "WRITE GAP MONO"
AND THE "GAP TIME MONO".

** IF USING SOFTWARE SWITCH REGISTER, AFTER
EACH HALT OPERATOR WILL BE PROMPTED
FOR THE VALUE WITH "SWR=XXXXX, NEW="

5.2.7.5 RGBLK

READ A BLOCK OF DATA AND A FILE GAP
START AT 240
THIS ROUTINE IS USED AFTER "WRITE A BLOCK AND A FILE GAP" ROUTINE
IT CAN BE USED TO ADJUST THE "SIGNAL MCN". THE THRESHOLD POT"
AND THE "TAPE BLANK MONO".

5.2.7.6 SFFGSB

SPACE FORWARD FILE GAP FROM "BOT" TO "EOT"
START AT 244
THIS ROUTINE CAN BE USED AFTER "WRITE FILE GAP" FOR LOW SPEED
SPACE FOWARD (TAPE BLANK MONO CAN BE ADJUSTED). OR AFTER READ OR
WRITE A FILE GAP AND A BLOCK OF DATA FOR HIGH SPEED SPACE FORWARD
(SIGNAL MONO CAN BE CHECKED).

5.2.7.7 BSFGSB

BACK SPACE FILE GAP
START AT 250
THIS ROUTINE CAN BE USED TO ADJUST OR CHECK THE "SIGNAL MCNC".

6. ERRORS

THERE ARE A NUMBER OF ERRORS THAT CAN OCCUR IN THIS PROGRAM. WHEN AN ERROR IS ENCOUNTERED THE CALL TO THE ERROR (ERROR) ROUTINE IS MADE AND IF SW<13> IS NOT SET AN ERROR MESSAGE PERTAINING TO THE ERROR WILL BE TYPED. EACH ERROR TYPE OUT WILL CONTAIN THE FOLLOWING:

1. THE FUNCTION BEING PERFORM
2. AN ERROR MESSAGE
3. A DATA HEADER
4. A DATA STRING

REFER TO THE LISTING UNDER \$ERRTB FOR THE DIFFERENT ERRORS THAT CAN OCCUR.

7. RESTRICTIONS

BEFORE STARTING THE PROGRAM THE OPERATOR MUST INSURE THAT A CASSETTE IS LOADED IN THE DRIVE(S) TO BE TESTED AND IS WRITE ENABLED.

8. MISCELLANEOUS

8.1 EXECUTION TIME

THE FIRST PASS TAKES APPROXIMATELY 4 MINUTES ALL SUBSEQUENT PASSES TAKE APPROXIMATELY 8 MINUTES

8.2 STACK POINTER

STACK IS INITIALLY SET TO 1100.

8.3 PASS COUNT

A PROGRAM PASS THRU COUNT IS KEPT IN "\$PASS".

8.4 ITERATIONS

THE FIRST PASS OF THE PROGRAM WILL AUTOMATICALLY INHIBIT ITERATIONS. ALL SUBSEQUENT PASSES WILL PERFORM FULL (ONE PER DRIVE), ITERATIONS.

8.5 SPECIAL REGISTERS

R4 AND R5 ARE RESERVED FOR "TACS" AND "TADB" THROUGH OUT THE PROGRAM.

9. PROGRAM DESCRIPTION

THIS PROGRAM IS A SEQUENCE OF INDEPENDENT TESTS THAT CHECK THE TALI FOR PROPER OPERATION.

EACH TESTS IS A SERIES OF "TRAP" CALLS TO ROUTINES THAT PERFORM THE DESIRED FUNCTION.

THE PROGRAM STARTS WITH A SIMPLE SEQUENCE OF FUNCTIONS AND BUILDS IN COMPLEXITY INTRODUCING ONE NEW FUNCTION AT A TIME UNTIL ALL LEGAL COMBINATIONS HAVE BEEN PERFORMED. IN MANY CASES SPECIAL IS PERFORMED TO TRY AND GENERATE PROBLEMS DUE TO SPEED CHANGES AND START STOPPING.

GENERAL INFORMATION
 OPERATIONAL SWITCH SETTINGS
 BASIC DEFINITIONS
 STARTING ADDRESSES
 TRAP CATCHER
 STARTING ADDRESS(ES)
 COMMON TAGS
 ERROR POINTER TABLE
 START OF TEST
 INITIALIZE THE COMMON TAGS
 TYPE PROGRAM NAME
 VALUE FOR SOFTWARE SWITCH REGISTER
 1.0 REWIND WRITE REWIND READ
 1.1 TEST BSBG AFTER WRITE AND READ AFTER BSBG
 1.2 TEST BSFG AFTER WRITE AND READ AFTER BSFG
 1.3 TEST BSBG AFTER READ
 1.4 TEST BSFG AFTER READ
 1.5 TEST SFBG AFTER REWIND AND BSFG AFTER SFBG
 1.6 TEST WRITE AFTER READ
 1.7 TEST WRITE AFTER WRITE AND READ AFTER READ
 1.8 TEST BSBG AFTER BSBG
 1.9 TEST READ AFTER BSFG
 1.10 TEST SFBG AFTER BSBG
 1.11 TEST SFBG AFTER BSFG
 1.12 REWRITE THE LAST BLOCK 3 TIMES AFTER DOING A WRITE AFTER WRITE
 1.13 REWRITE THE LAST BLOCK 3 TIMES AFTER DOING A WRITE AFTER READ
 1.14 TEST WFG AFTER WRITE AND BSFG AFTER WFG
 1.15 TEST BSBG AFTER WFG
 1.16 TEST WRITE AFTER WFG
 1.17 TEST WFG AFTER READ AND BSFG AFTER WRITE
 1.18 TEST SFBG AFTER REWIND AND READ AFTER SFBG
 1.19 TEST BSBG AFTER SFBG
 1.20 TEST SFBG AFTER SFBG
 1.21 TEST SFBG AFTER SFBG
 1.22 TEST BSFG AFTER SFBG AND BSFG AFTER BSFG
 1.23 TEST BSBG THRU A FILE GAP
 1.24 TEST BSFG AFTER BSBG
 1.25 TEST BSFG AFTER BSFG
 1.26 TEST BSFG AFTER SFBG AND SFBG AFTER READ
 1.27 TEST SFBG AFTER SFBG
 1.28 TEST SFBG AFTER SFBG
 1.29 TEST WFG AFTER SFBG
 1.30 TEST WRITE AFTER SFBG
 *****THE FOLLOWING TESTS TRY TO GENERATE NOISE***
 1.40 3 ONE BLOCK FILES---MULTI SPACING & TEST SFBG AFTER BSFG
 1.41 TWO BLOCK FILES---MULTI SPACING FUNCTIONS
 1.42 MULTI SPACING & TEST SFBG AFTER READ
 1.43 TWO BLOCK FILES--MULTI SPACING & TEST SFBG AFTER BSFG
 1.44 6 ONE BLOCK FILES---MULTI SPACING
 END OF PASS ROUTINE
 ROUTINE TO EXAMINE DRIVE(S) FOR AVAILABILITY
 SCOPE HANDLER ROUTINE
 ERROR HANDLER ROUTINE
 ERROR TIMEOUT ROUTINE
 ROUTINE TO ASK THE OPERATOR WHAT DRIVE(S) TO TEST
 ROUTINE TO INPUT CSR, DBR, AND VECTOR ADDRESS AND PRIORITY

1.0
 1.1
 1.2
 1.3
 1.4
 1.5
 1.6
 1.7
 1.8
 1.9
 1.10
 1.11
 1.12
 1.13
 1.14
 1.15
 1.16
 1.17
 1.18
 1.19
 1.20
 1.21
 1.22
 1.23
 1.24
 1.25
 1.26
 1.27
 1.28
 1.29
 1.30
 1.40
 1.41
 1.42
 1.43
 1.44


```

.TITLE TAIL MOTION TEST          MAINDEC-11-DZTAD-C
:*COPYRIGHT (C) 1973,1976
:*DIGITAL EQUIPMENT CORP.
:*MAYNARD, MASS. 01754
:*
:*PROGRAM BY JIM LACEY
:*
:*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
:*PACKAGE (MAINDEC-11-DZQAC-C2), SEPT 14, 1976.
:*
:*****
:*****
:*****
.REM!

```

GENERAL INFORMATION ABOUT THE TAIL/TU60 CASSETTE

ADDRESS MNEMONIC DESCRIPTION

```

777500 TACS CONTROL AND STATUS REGISTER
777502 TADB DATA BUFFER REGISTER
      260 TAVEC INTERRUPT VECTOR

```

TACS REGISTER DESCRIPTION

BIT	NAME	INIT STATE	READ AND/OR WRITE?
15	ERROR	?	READ ONLY
14	BLOCK CHECK ERROR	0	READ ONLY
13	CLEAR LEADER	?	READ ONLY
12	WRITE LOCK	?	READ ONLY
11	FILE GAP	0	READ ONLY
10	TIMING ERROR	0	READ ONLY
09	OFF LINE	?	READ ONLY
08	UNIT SELECT	0	READ/WRITE
07	TRANSFER REQUEST	0	READ ONLY
06	INTERRUPT ENABLE	0	READ/WRITE
05	READY	1	READ ONLY
04	ILBS	0	READ/WRITE
03	FUNCTION BIT 02	0	READ/WRITE
02	FUNCTION BIT 01	0	READ/WRITE
01	FUNCTION BIT 00	0	READ/WRITE

0=WRITE-FILE-GAP
1=WRITE
2=READ
3=BACK SPACE FILE GAP
4=BACK SPACE BLOCK GAP
5=SPACE FORWARD FILE GAP
6=SPACE FORWARD BLOCK GAP
7=REWIND

Vertical text on the left margin, likely a page number or sequence indicator.

F02

TRAIL MOTION TEST
DZTACC.NEW 24-MAY-76 00:00

MAINDEC-11-DZTAD-C

MAY11 27(1005) 23-SEP-76 10:33 PAGE 2
GENERAL INFORMATION

SEQ 0018

57

00

GO BIT

0

WRITE ONLY!

58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113

.SBTTL OPERATIONAL SWITCH SETTINGS

SWITCH	USE
15	HALT ON ERROR
14	LOOP ON TEST
13	INHIBIT ERROR TYPEOUTS
11	INHIBIT ITERATIONS
10	BELL ON ERROR
9	LOOP ON ERROR
8	LOCK ON CURRENT DRIVE
6	DELAY AT END OF EACH FUNCTION
5	RUN WITHOUT INTERRUPTS
4	IGNORE BLOCK CHECK ERRORS
3	INHIBIT DATA COMPARE

.SBTTL BASIC DEFINITIONS

```

001100  ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
          STACK= 1100
          .EQUIV EMT.ERROR      ;;BASIC DEFINITION OF ERROR CALL
          .EQUIV TOT.SCOPE     ;;BASIC DEFINITION OF SCOPE CALL

```

;*MISCELLANEOUS DEFINITIONS

```

000011 HT= 11      ;;CODE FOR HORIZONTAL TAB
000012 LF= 12      ;;CODE FOR LINE FEED
000015 CR= 15      ;;CODE FOR CARRIAGE RETURN
000200 CRLF= 200    ;;CODE FOR CARRIAGE RETURN-LINE FEED
177776 PS= 177776 ;;PROCESSOR STATUS WORD
          .EQUIV PS,PSW
177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
177772 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
177570 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER

```

;*GENERAL PURPOSE REGISTER DEFINITIONS

```

000000 R0= %0      ;;GENERAL REGISTER
000001 R1= %1      ;;GENERAL REGISTER
000002 R2= %2      ;;GENERAL REGISTER
000003 R3= %3      ;;GENERAL REGISTER
000004 R4= %4      ;;GENERAL REGISTER
000005 R5= %5      ;;GENERAL REGISTER
000006 R6= %6      ;;GENERAL REGISTER
000007 R7= %7      ;;GENERAL REGISTER
000006 SP= %6      ;;STACK POINTER
000007 PC= %7      ;;PROGRAM COUNTER

```

;*PRIORITY LEVEL DEFINITIONS

```

000000 PR0= 0      ;;PRIORITY LEVEL 0
000040 PR1= 40     ;;PRIORITY LEVEL 1
000100 PR2= 100    ;;PRIORITY LEVEL 2
000140 PR3= 140    ;;PRIORITY LEVEL 3
000200 PR4= 200    ;;PRIORITY LEVEL 4
000240 PR5= 240    ;;PRIORITY LEVEL 5

```

114 J00300
115 000340

PR6= 300
PR7= 340

::PRIORITY LEVEL 6
::PRIORITY LEVEL 7

116
117
118 100000
119 C40000
120 020000
121 010000
122 004000
123 002000
124 001000
125 J00400
126 000200
127 000100
128 000040
129 000020
130 000010
131 000004
132 000002
133 020001

.*"SWITCH REGISTER" SWITCH DEFINITIONS

SW15= 100000
SW14= 40000
SW13= 20000
SW12= 10000
SW11= 4000
SW10= 2000
SW09= 1000
SW08= 400
SW07= 200
SW06= 100
SW05= 40
SW04= 20
SW03= 10
SW02= 4
SW01= 2
SW00= 1

.EQUIV SW09, SW9
.EQUIV SW08, SW8
.EQUIV SW07, SW7
.EQUIV SW06, SW6
.EQUIV SW05, SW5
.EQUIV SW04, SW4
.EQUIV SW03, SW3
.EQUIV SW02, SW2
.EQUIV SW01, SW1
.EQUIV SW00, SW0

145 100000
146 040000
147 020000
148 010000
149 004000
150 002000
151 001000
152 J00400
153 000200
154 000100
155 000040
156 000020
157 000010
158 000004
159 000002
160 000001

.*DATA BIT DEFINITIONS (BIT00 TO BIT15)

BIT15= 100000
BIT14= 40000
BIT13= 20000
BIT12= 10000
BIT11= 4000
BIT10= 2000
BIT09= 1000
BIT08= 400
BIT07= 200
BIT06= 100
BIT05= 40
BIT04= 20
BIT03= 10
BIT02= 4
BIT01= 2
BIT00= 1

.EQUIV BIT09, BIT9
.EQUIV BIT08, BIT8
.EQUIV BIT07, BIT7
.EQUIV BIT06, BIT6
.EQUIV BIT05, BIT5
.EQUIV BIT04, BIT4
.EQUIV BIT03, BIT3
.EQUIV BIT02, BIT2

161
162
163
164
165
166
167
168
169

170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223

.EQUIV BIT01,BIT1
.EQUIV BIT00,BIT0

000004
000010
000014
000014
000014
000020
000024
000030
000034
000060
000064
000240

000000
000002
000004
000006
000010
000012
000014
000016

100000
040000
020000
010000
004000
002000
001000
000400
000200
000100
000040
000020
000010
000004
000002
000001
000016

000004
000005

```

.*BASIC "CPU" TRAP VECTOR ADDRESSES
ERRVEC= 4           ;; TIME OUT AND OTHER ERRORS
RESVEC= 10          ;; RESERVED AND ILLEGAL INSTRUCTIONS
TBITVEC=14          ;; "T" BIT
TRTVEC= 14          ;; TRACE TRAP
BPTVEC= 14          ;; BREAKPOINT TRAP (BPT)
IOTVEC= 20          ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
PWRVEC= 24          ;; POWER FAIL
EMTVEC= 30          ;; EMULATOR TRAP (EMT) **ERROR**
TRAPVEC=34          ;; "TRAP" TRAP
TKVEC= 60           ;; TTY KEYBOARD VECTOR
TPVEC= 64           ;; TTY PRINTER VECTOR
PIRQVEC=240         ;; PROGRAM INTERRUPT REQUEST VECTOR
;:*****

;*****TAIL FUNCTIONS*****
XWFG= 0             ;;WRITE FILE GAP FUNCTION
XWRITE= 2           ;;WRITE FUNCTION
XREAD= 4            ;;READ FUNCTION
XBSFG= 6            ;;BACK SPACE FILE GAP FUNCTION
XBSBG= 10           ;;BACK SPACE BLOCK GAP FUNCTION
XSFFG= 12           ;;SPACE FWD FILE GAP FUNCTION
XSFBG= 14           ;;SPACE FWD BLOCK GAP FUNCTION
XRWND= 16           ;;REWIND FUNCTION

;*****TAIL BIT ASSIGNMENT*****
ERROR= BIT15
CRCERR= BIT14
LEADER= BIT13
WRTLOCK=BIT12
FGAP= BIT11
TIMERR= BIT10
OFFLINE=BIT09
UNIT= BIT08
TR.REQ= BIT07
INT.EN= BIT06
READY= BIT05
ILBS= BIT04
FUNC2= BIT03
FUNC1= BIT02
FUNCO= BIT01
GO= BIT00
FUNCTION=          FUNC2+FUNC1+FUNCO

;////////////////////////////////////
;////////////////////////////////////
;SPECIAL REGISTERS
TACS= %4           ;;R4 IS USED AS A POINTER TO THE TACS REGISTER
TADB= %5           ;;R5 IS USED AS A POINTER TO THE TADB REGISTER.
;////////////////////////////////////
```

224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246

000000

.SBTTL TRAP CATCHER

.=0

;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS

000174

.=174

000174 000000
000176 000000

DISPREG: .WORD 0 ;:SOFTWARE DISPLAY REGISTER
SWREG: .WORD 0 ;:SOFTWARE SWITCH REGISTER

.SBTTL STARTING ADDRESS(ES)

000200 000137 001450
000204 000137 001502
000210 000137 001510
000214 000137 002052
000220 000137 012374
000224 000137 012450
000230 000137 012532
000234 000137 012620
000240 000137 012712
000244 000137 013010
000250 000137 013064

JMP @#BEGIN1 ;:JUMP TO STARTING ADDRESS OF PROGRAM
JMP @#BEGIN2 ;SELECT DRIVE(S) BEFORE STARTING TEST
JMP @#BEGIN3 ;SELECT DRIVE(S) AND ADDRESSES BEFORE TESTING
JMP @#BEGINX ;SETUP FOR MANUAL LOOPING
JMP @#WFGSUB ;WRITE FILE GAP FROM BOT TO EOT
JMP @#WRTSUB ;WRITE CONTINUOUS BLOCKS OF DATA
JMP @#RDSUB ;READ CONTINUOUS BLOCKS OF DATA
JMP @#WGPBLK ;WRITE FILE GAP AND A BLOCK OF DATA
JMP @#RGPBLK ;READ BLOCK OF DATA AND INTO A FILE GAP
JMP @#SFFGSB ;SPACE FWD FILE GAP FROM BOT TO EOT
JMP @#BSFGSB ;BACK SPACE FILE GAPS

;;*****

.SBTTL COMMON TAGS

::*****
;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
;*USED IN THE PROGRAM.

247									
248									
249									
250									
251									
252									
253		001100							
254	001100			\$CMTAG:	.WORD	0		:: START OF COMMON TAGS	
255	001100	000000		\$PASS:	.WORD	0		:: CONTAINS PASS COUNT	
256	001102	000		\$TSTNM:	.BYTE	00		:: CONTAINS THE TEST NUMBER	
257	001103	000		\$ERFLG:	.BYTE	00		:: CONTAINS ERROR FLAG	
258	001104	000000		\$ICNT:	.WORD	00		:: CONTAINS SUBTEST ITERATION COUNT	
259	001106	000000		\$LPADR:	.WORD	00		:: CONTAINS SCOPE LOOP ADDRESS	
260	001110	000000		\$LPERR:	.WORD	00		:: CONTAINS SCOPE RETURN FOR ERRORS	
261	001112	000000		\$ERTTL:	.WORD	00		:: CONTAINS TOTAL ERRORS DETECTED	
262	001114	000		\$ITEMB:	.BYTE	0		:: CONTAINS ITEM CONTROL BYTE	
263	001115	001		\$ERMAX:	.BYTE	1		:: CONTAINS MAX. ERRORS PER TEST	
264	001116	000000		\$ERRPC:	.WORD	00		:: CONTAINS PC OF LAST ERROR INSTRUCTION	
265	001120	000000		\$GDADR:	.WORD	00		:: CONTAINS ADDRESS OF 'GOOD' DATA	
266	001122	000000		\$BDADR:	.WORD	00		:: CONTAINS ADDRESS OF 'BAD' DATA	
267	001124	000000		\$GDDAT:	.WORD	00		:: CONTAINS 'GOOD' DATA	
268	001126	000000		\$BDDAT:	.WORD	00		:: CONTAINS 'BAD' DATA	
269	001130	000000			.WORD	00		:: RESERVED--NOT TO BE USED	
270	001132	000000			.WORD	00			
271	001134	000		\$AUTOB:	.BYTE	0		:: AUTOMATIC MODE INDICATOR	
272	001135	000		\$INTAG:	.BYTE	0		:: INTERRUPT MODE INDICATOR	
273	001136	000000			.WORD	0			
274	001140	177570		\$SWR:	.WORD	DSWR		:: ADDRESS OF SWITCH REGISTER	
275	001142	177570		\$DISPLAY:	.WORD	DDISP		:: ADDRESS OF DISPLAY REGISTER	
276	001144	177560		\$TKS:	177560			:: TTY KBD STATUS	
277	001146	177562		\$TKB:	177562			:: TTY KBD BUFFER	
278	001150	177564		\$TPS:	177564			:: TTY PRINTER STATUS REG. ADDRESS	
279	001152	177566		\$TPB:	177566			:: TTY PRINTER BUFFER REG. ADDRESS	
280	001154	000		\$NULL:	.BYTE	0		:: CONTAINS NULL CHARACTER FOR FILLS	
281	001155	002		\$FILLS:	.BYTE	2		:: CONTAINS # OF FILLER CHARACTERS REQUIRED	
282	001156	012		\$FILLC:	.BYTE	12		:: INSERT FILL CHARS. AFTER A "LINE FEED"	
283	001157	000		\$TPFLG:	.BYTE	0		:: "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)	
284	001160	000000		\$REGAD:	.WORD	0		:: CONTAINS THE ADDRESS FROM WHICH (\$REGO) WAS OBTAINED	
285									
286	001162	000000		\$REGO:	.WORD	0		:: CONTAINS ((\$REGAD)+0)	
287	001164	000000		\$REG1:	.WORD	0		:: CONTAINS ((\$REGAD)+2)	
288	001166	000000		\$TMPO:	.WORD	0		:: USER DEFINED	
289	001170	000000		\$TIMES:	0			:: MAX. NUMBER OF ITERATIONS	
290	001172	000000		\$ESCAPE:	0			:: ESCAPE ON ERROR ADDRESS	
291	001174	177607	000377	\$BELL:	.ASCIZ	<207><377><377>		:: CODE FOR BELL	
292	001200	077		\$QUES:	.ASCII	/?/		:: QUESTION MARK	
293	001201	015		\$CRLF:	.ASCII	<15>		:: CARRIAGE RETURN	
294	001202	000012		\$LF:	.ASCIZ	<12>		:: LINE FEED	
295				::*****					
296	001204	000000		\$AVPC:	.WORD	0		:: STORAGE FOR THE PC	
297	001206	000000		\$BYTNUM:	.WORD	0		:: THE NUMBER OF BYTES "READ" OR "WRITTEN"	
298	001210	000000		\$RCRCO:	.WORD	0		:: CRC CALCULATED FOR "WRITE"	
299	001212	000000		\$RCRC1:	.WORD	0		:: CRC CALCULATED FOR "READ"	
300	001214	000000		\$RCRC2:	.WORD	0		:: CRC FROM THE TAIL FOR "READ"	
301									
302	001216	000001		\$MXCNT:	1			:: MAX. NUMBER OF ITERATIONS	

303	001220	177500		TACSL:	177500		;LOW BYTE ADDRESS OF TACS
304	001222	177501		TACSH:	177501		;HIGH BYTE ADDRESS OF TACS
305	001224	177502		TADBL:	177502		;LOW BYTE ADDRESS OF TADB
306	001226	177503		TADBH:	177503		;HIGH BYTE ADDRESS OF TADB
307	001230	000260	000262	TAVEC:	260,262		;TAIL VECTOR ADDRESS
309	001234	000300		TAPRIO:	300		;TAIL BR LEVEL 6
309	001236	000000		DRIVE:	0		;NEXT DRIVE TO TEST
310	001240	000000	000000	DRVKEY:	0,0		;DRIVE SELECT KEY:
311	001244	001240		DRVPT:	DRVKEY		
312	001246	000000		ASKKEY:	0		
313	001250	177777	000000	CURDRV:	-1,0		;CURRENT DRIVE BEING TESTED
314	001254	000000		WAITKEY:	0		;WAIT ON INTERRUPT KEY
315	001256	001260		RWDFLG:	RWDA		;REWIND FLAG POINTER
316	001260	000000		RWDA:	0		;DRIVE "A" REWIND FLAG
317	001262	000000		RWDB:	0		;DRIVE "B" REWIND FLAG
318	001264	000000	000000	STALL:	0,0		;STALL TIME

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;;POINTS TO THE ERROR MESSAGE
;* DH ;;POINTS TO THE DATA HEADER
;* DT ;;POINTS TO THE DATA
;* DF ;;POINTS TO THE DATA FORMAT

\$ERRTB:
;NOTE: ALL NUMBERS WILL BE TYPED AS 6 DIGIT OCTAL NUMBERS

;ITEM 1
EM1 ;IMPROPER FLAG SETTING
DH1 ;TEST ERROR
;PC PC TACS TADB
DT1 ;SAVPC \$ERRPC \$REGO \$REG1
0

;ITEM 2
EM2 ;IMPROPER FLAG OCCURRED
DH1 ;TEST ERROR
;PC PC TACS TADB
DT1 ;SAVPC \$ERRPC \$REGO \$REG1
0

;ITEM 3
EM3 ;MISSED A FLAG
DH1 ;TEST ERROR
;PC PC TACS TADB
DT1 ;SAVPC \$ERRPC \$REGO \$REG1
0

;ITEM 4
EM4 ;INTERRUPT FAILED
DH1 ;TEST ERROR
;PC PC TACS TADB
DT1 ;SAVPC \$ERRPC \$REGO \$REG1
0

;ITEM 5
EM5 ;PREMATURE READY OCCURRED
DH1 ;TEST ERROR
;PC PC TACS TADB
DT1 ;SAVPC \$ERRPC \$REGO \$REG1
0

;ITEM 6
EM6 ;DIDN'T STOP IN A FILE GAP
DH1 ;TEST ERROR
;PC PC TACS TADB

319
320
321
322
323
324
325
326
327
328
329
330
331
332
333 001270
334
335
336
337 001270 015550
338 001272 016112
339
340 001274 015054
341 001276 000000
342
343
344 001300 015576
345 001302 016112
346
347 001304 015054
348 001306 000000
349
350
351 001310 015625
352 001312 016112
353
354 001314 015054
355 001316 000000
356
357
358 001320 015643
359 001322 016112
360
361 001324 015054
362 001326 000000
363
364
365 001330 015664
366 001332 016112
367
368 001334 015054
369 001336 000000
370
371
372 001340 015715
373 001342 016112
374

375	001344	015054	DT1	:SAVPC \$ERRPC \$REGO \$REG1				
376	001346	000000	0					
377								
378			:ITEM 7					
379	001350	015747	EM7	:DIDN'T STOP ON CLEAR LEADER				
380	001352	016112	DH1	:TEST ERROR				
381				:PC PC TACS TADB				
382	001354	015054	DT1	:SAVPC \$ERRPC \$REGO \$REG1				
383	001356	000000	0					
384								
385			:ITEM 10					
386	001360	016003	EM10	:BAD DATA READ				
387	001362	016172	DH2	:TEST ERROR	EXPT'D	RCV'D	BYTE	
388				:PC PC TACS	DATA	DATA	NUMBER	
389	001364	015066	DT2	:SAVPC \$ERRPC \$REGO	\$GDDAT	\$BDDAT	BYTNUM	
390	001366	000000	0					
391								
392			:ITEM 11					
393	001370	016021	EM11	:ILLEGAL BUFFER				
394	001372	016611	DH5	:TEST ERROR				
395				:PC PC TACS				
396	001374	015136	DT5	:SAVPC \$ERRPC \$REGO				
397	001376	000000	0					
398								
399			:ITEM 12					
400	001400	016045	EM12	:CRC ERROR				
401	001402	016333	DH3	:TEST ERROR	WRITE	READ	TU60	
402				:PC PC TACS	CRC	CRC	CRC	
403	001404	015104	DT3	:SAVPC \$ERRPC \$REGO	RCRC0	RCRC1	RCRC2	
404	001406	000000	0					
405								
406			:ITEM 13					
407	001410	016057	EM13	:SHORT RECORD				
408	001412	016471	DH4	:TEST ERROR		BYTES		
409				:PC PC TACS	TADB	LEFT		
410	001414	015122	DT4	:SAVPC \$ERRPC \$REGO	\$REG1	\$TMP0		
411	001416	000000	0					
412								
413			:ITEM 14					
414	001420	016074	EM14	:BAD INTERRUPT				
415	001422	016611	DH5	:TEST ERROR				
416				:PC PC TACS				
417	001424	015136	DT5	:SAVPC \$ERRPC \$REGO				
418	001426	000000	0					
419								
420	001430		ITEMS2:	:ITEMS 201-202				
421								
422	001430	016674	EM201	:TA11 FAILED TO RESPOND				
423	001432	016746	DH201	:PC TACS				
424	001434	016662	DT201	:SERRPC TACS				
425	001436	000000	0	:BOTH NUMBERS ARE TYPED AS OCTAL NUMBERS				
426								
427	001440	016723	EM202	:NO DRIVES AVAILABLE				
428	001442	016763	DH202	:PC				
429	001444	016670	DT202	:SERRPC				
430	001446	000000	0	:				


```

001730 001730 012716 001730 645: MOV #655,(SP) ::SET UP FOR TRAP RETURN
001730 001730 000000 RTI
001730 012716 000176 177202 655: MOV #SWREG,SWR ::POINT TO SOFTWARE SWR
001730 012716 000174 177175 MOV #DISPREG,DISPLAY
001744 012637 000004 665: MOV (SP)+,2#ERRVEC ::RESTORE ERROR VECTOR

.SBTTL TYPE PROGRAM NAME
::TYPE THE NAME OF THE PROGRAM IF FIRST PASS
001750 005227 177777 INC #-1 ::FIRST TIME?
001754 001036 BNE HERE ::BRANCH IF NO
001756 022737 006442 000042 CMP #SENDAD,2#42 ::ACT-11?
001754 001432 BEQ HERE ::BRANCH IF YES
001766 104401 002024 TYPE MSGID ::TYPE ASCIZ STRING

.SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
001772 005737 000042 TST 2#42 ::ARE WE RUNNING UNDER XXDP/ACT?
001776 001006 BNE 675 ::BRANCH IF YES
002000 026727 177134 000176 CMP SWR,#SWREG ::SOFTWARE SWITCH REG SELECTED?
002006 001005 BNE 685 ::BRANCH IF NO
002010 104405 GTSWR ::GET SOFT-SWR SETTINGS
002012 000403 BR 685
002014 112767 000001 177112 675: MOVB #1,SAUTOB ::SET AUTO-MODE INDICATOR
002020 685: BR HERE ::GET OVER THE ASCIZ
002022 000413 ::MSGID:
002052 .ASCIZ (CRLF) MAINDEC-11-DZTAD-C (CRLF)
HERE:

```


F03

TALI MOTION TEST
DZTAD.C.NEW

MAINDEC-11-DZTAD-C
24-MAY-76 00:00

MACY:1 27(1006) 23-SEP-76 10:33 PAGE 15
GET VALUE FOR SOFTWARE SWITCH REGISTER

SEQ 0031

```

620 002326 012777 012366 176674 START: MOV #BADINT,@TAVEC ;SETUP TALI TRAP VECTOR
621 002334 013777 001234 176670 MOV @TAPRIO,@TAVEC+2
622 002342 012737 002340 177776 MOV #340,@#PS ;LOCKOUT ALL I/O INT
623 002350 013704 001220 MOV @TACSL,TACS ;SETUP TACS
624 002354 013705 001224 MOV @TADBL,TADB ;SETUP TADB
625 002360 005037 001102 CLR @#STSTNM ;ZERO THE TEST NUMEEP
626 002364 005037 006624 CLR @#LOOPKEY ;CLEAR THE LOOP UNDER TTY CONTROL KEY
627 002370 012737 000001 001216 MOV #1,@#SMXCNT ;SET FOR ONE ITERATION PER TEST
628 002376 013701 001244 MOV @#DRVPT,R1 ;GET DRIVE POINTER
629 002402 010167 176630 MOV R1,DRIVE ;SET DRIVE TO POINTER
630 ////////////////////////////////////////////////////
631 ;TYPE THE DRIVE(S) THAT WILL BE TESTED
632 002406 111137 001250 MOVB (R1),@#CURDRV ;GET CURRENT DRIVE FOR TYPE-OUT
633 002412 104401 015271 TYPE ,MTSTDRV ;TYPE "TESTING DRIVE"
634 002416 104401 001250 TYPE ,CURDRV ;TYPE THE CURRENT DRIVE
635 002422 032777 000200 176510 BIT #SW07,@SWR ;LOCK ON ONE DRIVE?
636 002430 001021 BNE 2$ ;BR IF YES
637 002432 105737 001241 TSTB @#DRVKEY+1 ;TWO DRIVES AVAILABLE?
638 002436 001416 BEQ 2$ ;BR IF NO
639 002440 005237 001216 INC @#SMXCNT ;SET FOR TWO ITERATIONS PER TEST (ONE PER DRIVE)
640 002444 005201 INC R1 ;INCREMENT THE POINTER
641 002446 111137 001250 MOVB (R1),@#CURDRV ;SET SECO.0 DRIVE FOR TYPE-OUT
642 002452 001004 BNE 1$ ;GO TYPE IT
643 002454 012701 001240 MOV #DRVKEY,R1 ;RESET POINTER
644 002460 111137 001250 MOVB (R1),@#CURDRV ;NOW GET THE SECOND DRIVE
645 002464 104401 015312 1$: TYPE ,MANDRV ;TYPE "AND DRIVE"
646 002470 104401 001250 TYPE ,CURDRV ;TYPE DRIVE
647 002474 010137 001244 2$: MOV R1,@#DRVPT ;SAVE POINTER FOR NEXT TRIP THRU
648 002500 012737 002700 001106 MOV #55,@#SLPADR ;SETUP THE SCOPE LOOP ADDRESS
649 002506 005737 001100 TST @#SPASS ;ONCE ONLY
650 002512 001131 BNE TST1
651 ////////////////////////////////////////////////////
652 ;ON THE FIRST PASS OF THE PROGRAM DETERMINE THE AMOUNT OF TIME TO
653 ;WAIT ON A FLAG ("READY"/"TRANSFER REQUEST") AND THE STALL TIME TO USE
654 ;WHEN STALLING AFTER A FUNCTION IS COMPLETED
655 002514 104422 SELDRV ;SELECT DRIVE
656 002516 012737 002716 001172 MOV #FATAL,@#SESCAPE ;SETUP ESCAPE ON ERROR
657 002524 005077 176526 CLR @RWDFLG ;SET FOR NO REWIND ERRORS
658 002530 012737 077777 012022 MOV #1CBIT15,@#MAXCNT ;SETUP IMPOSSIBLE COUNT
659 002536 112714 000016 MOVB #XRWIND,@TACS ;INSURE NO ERROR DUE TO "CLEAR LEADER"
660 002542 104421 REWIND ;GO TO BOT
661 002544 104412 WFG ;NOW TIME A WFG
662 002546 163737 012020 012022 SUB @#HICNT,@#MAXCNT ;GET THE TIME IT TOOK TO WFG
663 002554 005237 012022 INC @#MAXCNT ;MAKE IT BIGGER
664 002560 006137 012022 ROL @#MAXCNT
665 002564 006137 012022 ROL @#MAXCNT
666 002570 005000 CLR R0
667 002572 005001 CLR R1
668 002574 012777 002632 176426 MOV #45,@TAVEC ;SETUP TALI VECTOR
669 002602 112714 000101 MOVB #XWFG!INT.EN!GO,@TACS ;START A "WFG"
670 002606 005037 177776 CLR @#PS ;ALLOW INTERRUPTS
671 002612 162700 000001 3$: SUB #1,R0 ;START TIMING HOW LONG
672 002616 005601 SBC R1 ; IT TAKES TO WRITE A FILE GAP
673 002620 001374 BNE 3$
674 002622 012737 000340 177776 MOV #340,@#PS ;LOCK OUT INTERRUPTS
675 002630 000432 BR FATAL ;IT TOOK TO LONG

```

G03

TAII MOTION TEST
DZTADC.NEW

24-MAY-76 00:00
MAINDEC-11-DZTAD-C

MACY:1 27(1006) 23-SEP-76 10:33 PAGE 16
GET VALUE FOR SOFTWARE SWITCH REGISTER

SEG 0032

```

676 002632 006201          4$:  ASR      R1          ;DIVIDE THE TIME BY 2
677 002634 006000          ROR      RO
678 002636 010037 001264    MOV      RO,@#STALL    ;AND SAVE IT AS THE STALL TIME
679 002642 010137 001266    MOV      R1,@#STALL+2
690 002646 012777 012366 176354  MOV      #BADINT,@TAVEC ;SET TRAP CATCHER
681 002654 105737 001241    TSTB    @#DRVKEY+1    ;TWO DRIVES?
692 002660 001407          SEQ      SS          ;BR IF NO
683 002662 104422          SELDRV
684 002664 005077 176366    CLR      @RWDFLG      ;SELECT THE OTHER DRIVE
695 002670 112714 000016    MOVB    #XRWND,@TACS ;SET REWIND FLAG
696 002674 104421          REWIND
687 002676 104412          WFG
698 002700 005737 001246    5$:  TST      @#ASKKEY    ;GO TO BOT
699 002704 002034          BGE     TST1         ;GO TO OXIDE
690 002706 005000          CLR      RO          ;GO START TESTING IF NO MANUAL
691 002710 006137 012022    ROL     @#MAXCNT     ;OPERATIONS REQUESTED
692 002714 000000          HALT
693
694 002716          FATAL:
695 002716 104401 002724    TYPE    ,65$        ;;TYPE ASCIZ STRING
696 002722 000414          BR      64$        ;;GET OVER THE ASCIZ
697
698 002754          ;;65$: .ASCIZ <15><12>*FATAL ERROR ON DRIVE *
699 002754 104401 001250    64$:  TYPE    ,CURDRV   ;CURRENT DRIVE
700 002760 013700 000042    MOV     @#42,RO     ;CHECK FOR A MONITOR
701 002764 001402          BEQ     1$         ;BR IF NONE
702 002766 000137 006442    JMP     @#SENDAD    ;LEAVE
703 002772 000000          1$:  HALT          ;ERROR OCCURRED BEFORE TESTING STARTED
704 002774 000776          BR      1$        ;HANGUP

```

H03

TAPE MOTION TEST
DZTADC.NEW

24-MAY-76

MAINDEC-11-DZTAD-C
00:00 T1

MACY11 27(1006) 23-SEP-76 10:33 PAGE 17
REWIND,WRITE,REWIND,READ

SEQ 0033

```

705
706
707
708 002776 000004
709 003000 012767 003032 176164
710 003006 104422
711 003010 104421
712 003012 104413 017022
713 003016 104421
714 003020 104414 016766
715 003024 104423
716 003026 016766
717 003030 017022
718
719
720
721 003032 000004
722 003034 012767 003066 176130
723 003042 104422
724 003044 104421
725 003046 104413 017022
726 003052 104416
727 003054 104414 016766
728 003060 104423
729 003062 016766
730 003064 017022
731
732
733
734 003066 000004
735 003070 012767 003122 176074
736 003076 104422
737 003100 104421
738 003102 104413 017022
739 003106 104415
740 003110 104414 016766
741 003114 104423
742 003116 016766
743 003120 017022
744
745
746
747 003122 000004
748 003124 012767 003172 176040
749 003132 104422
750 003134 104421
751 003136 104413 017022
752 003142 104421
753 003144 104414 016766
754 003150 104423
755 003152 016766
756 003154 017022
757 003156 104416
758 003160 104414 016766
759 003164 104423
760 003166 016766

*****
*TEST 1 REWIND,WRITE,REWIND,READ
*****
TST1: SCOPE
MOV #TST2.$ESCAPE ;;ESCAPE TO TEST 2 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "CLEAR LEADER"
WRITE ,WLNK1 ;WRITE ON TAPE
REWIND ;GO TO BEGINNING OF TAPE
READ ,RLNK1 ;READ
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK1 ;LINK TO THE READ BUFFER
WLNK1 ;LINK TO THE WRITE BUFFER

*****
*TEST 2 TEST BSBG AFTER WRITE AND READ AFTER BSBG
*****
TST2: SCOPE
MOV #TST3.$ESCAPE ;;ESCAPE TO TEST 3 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "BOT"
WRITE ,WLNK1 ;WRITE ONE BLOCK
BSBG ;BACK OVER THE BLOCK
READ ,RLNK1 ;NOW READ
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK1 ;LINK TO THE READ BUFFER
WLNK1 ;LINK TO THE WRITE BUFFER

*****
*TEST 3 TEST BSFG AFTER WRITE AND READ AFTER BSFG
*****
TST3: SCOPE
MOV #TST4.$ESCAPE ;;ESCAPE TO TEST 4 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "BOT"
WRITE ,WLNK1 ;WRITE ONE BLOCK
BSFG ;BACK OVER THE BLOCK
READ ,RLNK1 ;NOW READ
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK1 ;LINK TO THE READ BUFFER
WLNK1 ;LINK TO THE WRITE BUFFER

*****
*TEST 4 TEST BSBG AFTER READ
*****
TST4: SCOPE
MOV #TST5.$ESCAPE ;;ESCAPE TO TEST 5 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "BOT"
WRITE ,WLNK1 ;WRITE ONE BLOCK
REWIND ;GO TO "BOT"
READ ,RLNK1 ;READ
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK1 ;LINK TO THE READ BUFFER
WLNK1 ;LINK TO THE WRITE BUFFER
BSBG ;BACK UP
READ ,RLNK1 ;READ
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK1 ;LINK TO THE READ BUFFER

```

```

761 003170 017022          WLNK1          ;LINK TO THE WRITE BUFFER
762          ;*****
763          ;*TEST 5      TEST BSBG AFTER READ
764          ;*****
765 003172 000004          TST5:  SCOPE
766 003174 012767 003242 175770  MOV      #TST6,$ESCAPE  ;;ESCAPE TO TEST 6 ON ERROR
767 003202 104422          SELDRV   ;SELECT DRIVE FOR TESTING
768 003204 104421          REWIND   ;GO TO "BOT"
769 003206 104413 017022  WRITE    ,WLNK1      ;WRITE A BLOCK
770 003212 104421          REWIND   ;GO TO "BOT"
771 003214 104414 016766  READ     ,RLNK1      ;READ A BLOCK
772 003220 104423          BLKCMP   ;COMPARE THE READ AND WRITE BUFFERS
773 003222 016766          RLNK1    ;LINK TO THE READ BUFFER
774 003224 017022          WLNK1    ;LINK TO THE WRITE BUFFER
775 003226 104415          BSFG    ;BACK OVER THE DATA
776 003230 104414 016766  READ     ,RLNK1      ;NOW READ THE DATA
777 003234 104423          BLKCMP   ;COMPARE THE READ AND WRITE BUFFERS
778 003236 016766          RLNK1    ;LINK TO THE READ BUFFER
779 003240 017022          WLNK1    ;LINK TO THE WRITE BUFFER
780          ;*****
781          ;*TEST 6      TEST SFBG AFTER REWIND AND BSFG AFTER SFBG
782          ;*****
783 003242 000004          TST6:  SCOPE
784 003244 012767 003302 175720  MOV      #TST7,$ESCAPE  ;;ESCAPE TO TEST 7 ON ERROR
785 003252 104422          SELDRV   ;SELECT DRIVE FOR TESTING
786 003254 104421          REWIND   ;GO TO "BOT"
787 003256 104413 017022  WRITE    ,WLNK1      ;WRITE ONE BLOCK OF DATA
788 003262 104421          REWIND   ;GO TO "BOT"
789 003264 104420          SFBG    ;SPACE OVER THE DATA
790 003266 104415          BSFG    ;BACK OVER THE DATA
791 003270 104414 016766  READ     ,RLNK1      ;READ THE BLOCK
792 003274 104423          BLKCMP   ;COMPARE THE READ AND WRITE BUFFERS
793 003276 016766          RLNK1    ;LINK TO THE READ BUFFER
794 003300 017022          WLNK1    ;LINK TO THE WRITE BUFFER
795          ;*****
796          ;*TEST 7      TEST WRITE AFTER READ
797          ;*****
799 003302 000004          TST7:  SCOPE
799 003304 012767 003356 175660  MOV      #TST10,$ESCAPE ;;ESCAPE TO TEST 10 ON ERROR
800 003312 104422          SELDRV   ;SELECT DRIVE FOR TESTING
801 003314 104421          REWIND   ;GO TO "CLEAR LEADER"
802 003316 104413 017022  WRITE    ,WLNK1      ;WRITE ONE BLOCK
803 003322 104416          BSBG    ;BACK OVER THE DATA BLOCK
804 003324 104414 016766  READ     ,RLNK1      ;AND READ IT
805 003330 104423          BLKCMP   ;COMPARE THE READ AND WRITE BUFFERS
806 003332 016766          RLNK1    ;LINK TO THE READ BUFFER
807 003334 017022          WLNK1    ;LINK TO THE WRITE BUFFER
808 003336 104413 017026  WRITE    ,WLNK2      ;WRITE A SECOND BLOCK
809 003342 104416          BSBG    ;BACK OVER IT
810 003344 104414 016772  READ     ,RLNK2      ;AND READ IT
811 003350 104423          BLKCMP   ;COMPARE THE READ AND WRITE BUFFERS
812 003352 016772          RLNK2    ;LINK TO THE READ BUFFER
813 003354 017026          WLNK2    ;LINK TO THE WRITE BUFFER
814          ;*****
815          ;*TEST 10     TEST WRITE AFTER WRITE AND READ AFTER READ
816          ;*****

```

J03

TA11 MOTION TEST
DZTADC.NEW 24-MAY-76

MAINDEC-11-DZTAD-C
00:00 T10

MACY11 27(1006) 23-SEP-76 10:33 PAGE 19
TEST WRITE AFTER WRITE AND READ AFTER READ

SEQ 0035

```

817 003356 000004 TST10: SCOPE
818 003360 012767 003422 175604 MOV #TST11,$ESCAPE ;;ESCAPE TO TEST 11 ON ERROR
819 003366 104422 SELDRV ;SELECT DRIVE FOR TESTING
820 003370 104421 REWIND ;GO TO "CLEAR LEADER"
821 003372 104413 017022 WRITE ,WLNK1 ;WRITE TWO(2) BLOCKS
822 003376 104413 017026 WRITE ,WLNK2
823 003402 104421 REWIND ;GO TO BOT
824 003404 104414 016766 READ ,RLNK1 ;READ BOTH BLOCKS
825 003410 104414 016772 READ ,RLNK2
826 003414 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
827 003416 016772 RLNK2 ;LINK TO THE READ BUFFER
828 003420 017026 WLNK2 ;LINK TO THE WRITE BUFFER
829
830 ;:*****
831 ;*TEST 11 TEST BSBG AFTER BSBG
832 ;:*****
833 003422 000004 TST11: SCOPE
834 003424 012767 003464 175540 MOV #TST12,$ESCAPE ;;ESCAPE TO TEST 12 ON ERROR
835 003432 104422 SELDRV ;SELECT DRIVE FOR TESTING
836 003434 104421 REWIND ;GO TO "CLEAR LEADER"
837 003436 104413 017022 WRITE ,WLNK1 ;WRITE TWO(2) BLOCKS
838 003442 104413 017026 WRITE ,WLNK2
839 003446 104416 BSBG ;BACK OVER THE 2ND BLOCK
840 003450 104416 BSBG ;BACK OVER THE 1ST BLOCK
841 003452 104414 016766 READ ,RLNK1 ;READ THE 1ST BLOCK
842 003456 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
843 003460 016766 RLNK1 ;LINK TO THE READ BUFFER
844 003462 017022 WLNK1 ;LINK TO THE WRITE BUFFER
845
846 ;:*****
847 ;*TEST 12 TEST READ AFTER SFBG
848 ;:*****
849 003464 000004 TST12: SCOPE
850 003466 012767 003526 175476 MOV #TST13,$ESCAPE ;;ESCAPE TO TEST 13 ON ERROR
851 003474 104422 SELDRV ;SELECT DRIVE FOR TESTING
852 003476 104421 REWIND ;GO TO "CLEAR LEADER"
853 003500 104413 017022 WRITE ,WLNK1 ;WRITE TWO(2) BLOCKS
854 003504 104413 017026 WRITE ,WLNK2
855 003510 104421 REWIND ;BOT
856 003512 104420 SFBG ;SPACE OVER THE 1ST BLOCK
857 003514 104414 016772 READ ,RLNK2 ;READ THE 2ND BLOCK
858 003520 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
859 003522 016772 RLNK2 ;LINK TO THE READ BUFFER
860 003524 017026 WLNK2 ;LINK TO THE WRITE BUFFER
861
862 ;:*****
863 ;*TEST 13 TEST SFBG AFTER BSBG
864 ;:*****
865 003526 000004 TST13: SCOPE
866 003530 012767 003572 175434 MOV #TST14,$ESCAPE ;;ESCAPE TO TEST 14 ON ERROR
867 003536 104422 SELDRV ;SELECT DRIVE FOR TESTING
868 003540 104421 REWIND ;GO TO "CLEAR LEADER"
869 003542 104413 017022 WRITE ,WLNK1 ;WRITE TWO(2) BLOCKS
870 003546 104413 017026 WRITE ,WLNK2
871 003552 104416 BSBG ;BACK SPACE OVER BOTH BLOCKS
872 003554 104416 BSBG ;SPACE FWD OVER 1ST BLOCK
873 003556 104420 SFBG ;READ 2ND BLOCK
874 003560 104414 016772 READ ,RLNK2 ;COMPARE THE READ AND WRITE BUFFERS
875 003564 104423 BLKCMP

```


K03

TA11 MOTION TEST
DZTADC.NEW

24-MAY-76

MAINDEC-11-DZTAD-C
00:00 T13

MACY11 27(1006) 23-SEP-76 10:33 PAGE 2C
TEST SFBG AFTER BSBG

SEQ 0036

```

873 003566 016772          RLNK2          ;LINK TO THE READ BUFFER
874 003570 017026          WLNK2          ;LINK TO THE WRITE BUFFER
875                                     ;*****
876                                     ;*TEST 14      TEST SFBG AFTER BSFG
877                                     ;*****
878 003572 000004          TST14: SCOPE
879 003574 012767 003634 175370      MOV          #TST15,$ESCAPE ;;ESCAPE TO TEST 15 ON ERROR
880 003602 104422          SELDRV       ;SELECT DRIVE FOR TESTING
881 003604 104421          REWIND       ;GO TO "CLEAR LEADER"
882 003606 104413 017022          WRITE      ,WLNK1      ;WRITE TWO BLOCKS
883 003612 104413 017026          WRITE      ,WLNK2
884 003616 104415          BSBG
885 003620 104420          SFBG        ;SPACE REV FILE
886 003622 104414 016772          READ       ,RLNK2     ;SPACE FWD BLOCK
887 003626 104423          BLKCMP     ;READ THE 2ND BLOCK
888 003630 016772          RLNK2      ;COMPARE THE READ AND WRITE BUFFERS
889 003632 017026          WLNK2      ;LINK TO THE READ BUFFER
890                                     ;LINK TO THE WRITE BUFFER
891                                     ;*****
892                                     ;*TEST 15-    REWRITE THE LAST BLOCK 3 TIMES AFTER DOING A WRITE AFTER WRITE
893                                     ;*****
893 003634 000004          TST15: SCOPE
894 003636 012767 004026 175326      MOV          #TST16,$ESCAPE ;;ESCAPE TO TEST 16 ON ERROR
895 003644 104422          SELDRV       ;SELECT DRIVE FOR TESTING
896 003646 104421          REWIND       ;GO TO "CLEAR LEADER"
897 003650 104413 017022          WRITE      ,WLNK1      ;WRITE 2 BLOCKS
898 003654 104413 017026          WRITE      ,WLNK2
899 003660 104416          BSBG        ;BACK OVER BOTH OF THEM
900 003662 104416          BSBG
901 003664 104414 016766          READ       ,RLNK1     ;READ THE FIRST ONE
902 003670 104423          BLKCMP     ;COMPARE THE READ AND WRITE BUFFERS
903 003672 016766          RLNK1      ;LINK TO THE READ BUFFER
904 003674 017022          WLNK1      ;LINK TO THE WRITE BUFFER
905 003676 104414 016772          READ       ,RLNK2     ;NOW READ THE 2ND ONE
906 003702 104423          BLKCMP     ;COMPARE THE READ AND WRITE BUFFERS
907 003704 016772          RLNK2      ;LINK TO THE READ BUFFER
908 003706 017026          WLNK2      ;LINK TO THE WRITE BUFFER
909 003710 104416          BSBG        ;BACK OVER THE 2ND ONE
910 003712 104413 017032          WRITE      ,WLNK3     ;WRITE OVER THE 2ND BLOCK
911 003716 104416          BSBG        ;NOW BACK UP AND
912 003720 104414 016776          READ       ,RLNK3     ;READ IT
913 003724 104423          BLKCMP     ;COMPARE THE READ AND WRITE BUFFERS
914 003726 016776          RLNK3      ;LINK TO THE READ BUFFER
915 003730 017032          WLNK3      ;LINK TO THE WRITE BUFFER
916 003732 104416          BSBG        ;BACK OVER IT AGAIN
917 003734 104413 017036          WRITE      ,WLNK4     ;AND WRITE OVER IT AGAIN
918 003740 104416          BSBG        ;BACK UP AND
919 003742 104414 017002          READ       ,RLNK4     ;READ THE BLOCK
920 003746 104423          BLKCMP     ;COMPARE THE READ AND WRITE BUFFERS
921 003750 017002          RLNK4      ;LINK TO THE READ BUFFER
922 003752 017036          WLNK4      ;LINK TO THE WRITE BUFFER
923 003754 104416          BSBG        ;BACK OVER THE BLOCK AGAIN
924 003756 104413 017026          WRITE      ,WLNK2     ;AND WRITE OVER IT AGAIN
925 003762 104416          BSBG        ;NOW BACK UP
926 003764 104414 016772          READ       ,RLNK2     ;AND READ IT
927 003770 104423          BLKCMP     ;COMPARE THE READ AND WRITE BUFFERS
928 003772 016772          RLNK2      ;LINK TO THE READ BUFFER

```

L03

TAII MOTION TEST
DZTADC.NEW

MAINDEC-11-DZTAD-C
24-MAY-76 00:00 T15

MACY11 27(1006) 23-SEP-76 10:33 PAGE 21
REWRITE THE LAST BLOCK 3 TIMES AFTER DOING A WRITE AFTER WRITE

SEQ 0037

```

929 003774 017026          WLNK2          ;LINK TO THE WRITE BUFFER
930 003776 104416          BSBG           ;BACK OVER BOTH BLOCKS
931 004000 104416          BSBG
932 004002 104414 016766  READ          ,RLNK1      ;AND READ THE 1ST ONE
933 004006 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
934 004010 016766          RLNK1         ;LINK TO THE READ BUFFER
935 004012 017022          WLNK1         ;LINK TO THE WRITE BUFFER
936 004014 104414 016772  READ          ,RLNK2      ;AND THE 2ND ONE
937 004020 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
938 004022 016772          RLNK2         ;LINK TO THE READ BUFFER
939 004024 017026          WLNK2         ;LINK TO THE WRITE BUFFER
940
941  ;*****
942  ;*TEST 16 REWRITE THE LAST BLOCK 3 TIMES AFTER DOING A WRITE AFTER READ
943  ;*****
944  004026 000004          TS-16: SCOPE
945  004030 012767 004204 175134  MOV          #TST17,$ESCAPE ;;ESCAPE TO TEST 17 ON ERROR
946  004036 104422          SELDRV        ;SELECT DRIVE FOR TESTING
947  004040 104421          REWIND        ;GO TO "CLEAR LEADER"
948  004042 104413 017022  WRITE          ,WLNK1      ;WRITE A BLOCK OF DATA
949  004046 104416          BSBG           ;BACK OVER IT
950  004050 104414 016766  READ          ,RLNK1      ;AND READ IT
951  004054 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
952  004056 016766          RLNK1         ;LINK TO THE READ BUFFER
953  004060 017022          WLNK1         ;LINK TO THE WRITE BUFFER
954  004062 104413 017026  WRITE          ,WLNK2      ;WRITE 2ND BLOCK
955  004066 104416          BSBG           ;BACK OVER IT
956  004070 104414 016772  READ          ,RLNK2      ;AND READ IT
957  004074 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
958  004076 016772          RLNK2         ;LINK TO THE READ BUFFER
959  004100 017026          WLNK2         ;LINK TO THE WRITE BUFFER
960  004102 104416          BSBG           ;BACK OVER IT AND
961  004104 104413 017036  WRITE          ,WLNK4      ;WRITE OVER 2ND BLOCK
962  004110 104416          BSBG           ;BACK UP AND
963  004112 104414 017002  READ          ,RLNK4      ;READ IT
964  004116 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
965  004120 017002          RLNK4         ;LINK TO THE READ BUFFER
966  004122 017036          WLNK4         ;LINK TO THE WRITE BUFFER
967  004124 104416          BSBG           ;BACK OVER IT AGAIN
968  004126 104413 017042  WRITE          ,WLNK5      ;REWRITE 2ND BLOCK
969  004132 104416          BSBG
970  004134 104414 017006  READ          ,RLNK5      ;READ 2ND BLOCK
971  004140 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
972  004142 017006          RLNK5         ;LINK TO THE READ BUFFER
973  004144 017042          WLNK5         ;LINK TO THE WRITE BUFFER
974  004146 104416          BSBG           ;BACK OVER IT AGAIN
975  004150 104413 017032  WRITE          ,WLNK3      ;WRITE ANOTHER BLOCK OVER IT
976  004154 104416          BSBG           ;BACK OVER 2 BLOCKS
977  004156 104416          BSBG
978  004160 104414 016766  READ          ,RLNK1      ;READ THE 1ST BLOCK
979  004164 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
980  004166 016766          RLNK1         ;LINK TO THE READ BUFFER
981  004170 017022          WLNK1         ;LINK TO THE WRITE BUFFER
982  004172 104414 016776  READ          ,RLNK3      ;READ 2ND BLOCK
983  004176 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
984  004200 016776          RLNK3         ;LINK TO THE READ BUFFER
          WLNK3         ;LINK TO THE WRITE BUFFER

```

M03

TAII MOTION TEST
DZTADC.NEW

MAINDEC-11-DZTAD-C
24-MAY-76 00:00 T17

MACY11 27(1005) 23-SEP-76 10:33 PAGE 22
TEST WFG AFTER WRITE AND BSFG AFTER WFG

SEQ 0038

```

995                                     ;:*****
996                                     ;:*TEST 17      TEST WFG AFTER WRITE AND BSFG AFTER WFG
997                                     ;:*****
999 004204 000004 004242 174756  †TST17: SCOPE
999 004206 012767 004242 174756      MOV      #TST20,$ESCAPE  ;;ESCAPE TO TEST 20 ON ERROR
990 004214 104422                      SELDRV                      ;SELECT DRIVE FOR TESTING
991 004216 104421                      REWIND                      ;GO TO "BOT"
992 004220 104413 017022              WRITE      ,WLNK1          ;WRITE ONE BLOCK
993 004224 104412                      WFG                          ;FOLLOWED BY A FILE GAP
994 004226 104415                      BSFG                         ;BACK OVER THE DATA BLOCK
995 004230 104414 016766              READ       ,RLNK1         ;READ THE DATA
996 004234 104423                      BLKCOMP                      ;COMPARE THE READ AND WRITE BUFFERS
997 004236 016766                      RLNK1                        ;LINK TO THE READ BUFFER
998 004240 017022                      WLNK1                        ;LINK TO THE WRITE BUFFER
999                                     ;:*****
1000                                    ;:*TEST 20      TEST BSBG AFTER WFG
1001                                    ;:*****
1002 004242 000004 004300 174720  †TST20: SCOPE
1003 004244 012767 004300 174720      MOV      #TST21,$ESCAPE  ;;ESCAPE TO TEST 21 ON ERROR
1004 004252 104422                      SELDRV                      ;SELECT DRIVE FOR TESTING
1005 004254 104421                      REWIND                      ;GO TO BOT
1006 004256 104413 017022              WRITE      ,WLNK1          ;WRITE ONE BLOCK OF DATA
1007 004262 104412                      WFG                          ;WRITE A FILE GAP
1008 004264 104416                      BSBG                         ;BACK OVER THE DATA
1009 004266 104414 016766              READ       ,RLNK1         ;READ ONE BLOCK
1010 004272 104423                      BLKCOMP                      ;COMPARE THE READ AND WRITE BUFFERS
1011 004274 016766                      RLNK1                        ;LINK TO THE READ BUFFER
1012 004276 017022                      WLNK1                        ;LINK TO THE WRITE BUFFER
1013                                     ;:*****
1014                                    ;:*TEST 21      TEST WRITE AFTER WFG
1015                                    ;:*****
1016 004300 000004 004356 174662  †TST21: SCOPE
1017 004302 012767 004356 174662      MOV      #TST22,$ESCAPE  ;;ESCAPE TO TEST 22 ON ERROR
1018 004310 104422                      SELDRV                      ;SELECT DRIVE FOR TESTING
1019 004312 104421                      REWIND                      ;GO TO BOT
1020 004314 104413 017022              WRITE      ,WLNK1          ;WRITE ONE BOCK
1021 004320 104421                      REWIND                      ;GO TO BOT
1022 004322 104414 016766              READ       ,RLNK1         ;READ ONE BLOCK
1023 004326 104423                      BLKCOMP                      ;COMPARE THE READ AND WRITE BUFFERS
1024 004330 016766                      RLNK1                        ;LINK TO THE READ BUFFER
1025 004332 017022                      WLNK1                        ;LINK TO THE WRITE BUFFER
1026 004334 104412                      WFG                          ;WRITE A FILE GAP
1027 004336 104413 017026              WRITE      ,WLNK2          ;WRITE ANOTHER BLOCK
1028 004342 104416                      BSBG                         ;BACK OVER THE LAST BLOCK
1029 004344 104414 016772              READ       ,RLNK2         ;READ THE SECOND BLOCK
1030 004350 104423                      BLKCOMP                      ;COMPARE THE READ AND WRITE BLFFERS
1031 004352 016772                      RLNK2                        ;LINK TO THE READ BUFFER
1032 004354 017026                      WLNK2                        ;LINK TO THE WRITE BUFFER
1033                                     ;:*****
1034                                    ;:*TEST 22      TEST WFG AFTER READ AND BSFG AFTER WRITE
1035                                    ;:*****
1036 004356 000004 004434 174604  †TST22: SCOPE
1037 004360 012767 004434 174604      MOV      #TST23,$ESCAPE  ;;ESCAPE TO TEST 23 ON ERROR
1038 004366 104422                      SELDRV                      ;SELECT DRIVE FOR TESTING
1039 004370 104421                      REWIND                      ;GO TO "BOT"
1040 004372 104413 017022              WRITE      ,WLNK1          ;WRITE ONE BLOCK

```

N03

TAII MOTION TEST
DZTADC.NEW

24-MAY-76 00:00

MAINDEC-11-DZTAD-C
T22

MACY11 27(1005) 23-SEP-76 10:33 PAGE 23
TEST WFG AFTER READ AND BSFG AFTER WRITE

SEQ 0039

```

1041 004376 104421 REWIND ;GO TO "BOT"
1042 004400 104414 016766 READ ,RLNK1 ;READ ONE BLOCK
1043 004404 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1044 004406 016766 RLNK1 ;LINK TO THE READ BUFFER
1045 004410 017022 WLNK1 ;LINK TO THE WRITE BUFFER
1046 004412 104412 WFG ;WRITE A FILE GAP
1047 004414 104413 017026 WRITE ,WLNK2 ;WRITE A BLOCK
1048 004420 104415 BSFG ;BACK OVER THE DATA
1049 004422 104414 016772 READ ,RLNK2 ;READ SECOND BLOCK
1050 004426 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1051 004430 016772 RLNK2 ;LINK TO THE READ BUFFER
1052 004432 017026 WLNK2 ;LINK TO THE WRITE BUFFER
1053 ;*****
1054 ;*TEST 23 TEST SFFG AFTER REWIND AND READ AFTER SFFG
1055 ;*****
1056 004434 000004 †ST23: SCOPE
1057 004436 012767 004500 174526 MOV #TST24,$ESCAPE ;;ESCAPE TO TEST 24 ON ERROR
1058 004444 104422 SELDRV ;SELECT DRIVE FOR TESTING
1059 004446 104421 REWIND ;GO TO "BOT"
1060 004450 104413 017022 WRITE ,WLNK1 ;WRITE A BLOCK OF DATA
1061 004454 104412 WFG ;WRITE A FILE GAP
1062 004456 104413 017026 WRITE ,WLNK2 ;WRITE A BLOCK OF DATA
1063 004462 104421 REWIND ;GO TO "BOT"
1064 004464 104417 SFFG ;SPACE OVER FIRST BLOCK
1065 004466 104414 016772 READ ,RLNK2 ;READ THE 2ND BLOCK
1066 004472 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1067 004474 016772 RLNK2 ;LINK TO THE READ BUFFER
1068 004476 017026 WLNK2 ;LINK TO THE WRITE BUFFER
1069 ;*****
1070 ;*TEST 24 TEST BSBG AFTER SFFG
1071 ;*****
1072 004500 000004 †ST24: SCOPE
1073 004502 012767 004546 174462 MOV #TST25,$ESCAPE ;;ESCAPE TO TEST 25 ON ERROR
1074 004510 104422 SELDRV ;SELECT DRIVE FOR TESTING
1075 004512 104421 REWIND ;GO TO "BOT"
1076 004514 104413 017022 WRITE ,WLNK1 ;WRITE DATA
1077 004520 104412 WFG ;WRITE FILE GAP
1078 004522 104413 017026 WRITE ,WLNK2 ;WRITE DATA
1079 004526 104421 REWIND ;GO TO "BOT"
1080 004530 104417 SFFG ;SPACE OVER FIRST FILE
1081 004532 104416 BSBG ;BACKUP TO FIRST BLOCK
1082 004534 104414 016766 READ ,RLNK1 ;READ THE BLOCK
1083 004540 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1084 004542 016766 RLNK1 ;LINK TO THE READ BUFFER
1085 004544 017022 WLNK1 ;LINK TO THE WRITE BUFFER
1086 ;*****
1087 ;*TEST 25 TEST SFBG AFTER SFFG
1088 ;*****
1089 004546 000004 †ST25: SCOPE
1090 004550 012767 004622 174414 MOV #TST26,$ESCAPE ;;ESCAPE TO TEST 26 ON ERROR
1091 004556 104422 SELDRV ;SELECT DRIVE FOR TESTING
1092 004560 104421 REWIND ;GO TO "BOT"
1093 004562 104413 017022 WRITE ,WLNK1 ;WRITE A BLOCK OF DATA
1094 004566 104412 WFG ;FOLLOWED BY A FILE GAP
1095 004570 104413 017026 WRITE ,WLNK2 ;FOLLOWED BY 2 BLOCKS OF DATA
1096 004574 104412 017032 WRITE ,WLNK3

```

004600	010421		REWIND		:GO TO "BOT"
004601	010422		SFBG		:SPACE OVER 1ST FILE
004602	010423		SFBG		:SPACE OVER BLOCK
004603	010424		BSFG		:BACK OVER THE BLOCK
004604	010425	016772	READ	.RLNK2	:READ THE LAST BLOCK
004605	010426		BLKCMP		:COMPARE THE READ AND WRITE BUFFERS
004606	010427		RLNK2		:LINK TO THE READ BUFFER
004607	010428		WLNK2		:LINK TO THE WRITE BUFFER

 :TEST 26 TEST SFBG AFTER SFBG

004622	010004		↑ST26: SCOPE		
004624	012767	004702 174340	MOV	*TST27,SESCAPE	::ESCAPE TO TEST 27 ON ERROR
004632	104422		SELDRV		:SELECT DRIVE FOR TESTING
004634	104421		REWIND		:GO TO "BOT"
004636	104413	017022	WRITE	.WLNK1	:WRITE A BLOCK OF DATA
004642	104412		WFG		:WRITE A FILE GAP
004644	104413	017026	WRITE	.WLNK2	:WRITE 3 BLOCKS OF DATA
004650	104413	017032	WRITE	.WLNK3	
004654	104413	017036	WRITE	.WLNK4	
004660	104421		REWIND		:GO TO "BOT"
004662	104417		SFBG		:SPACE OVER THE 1ST FILE
004664	104420		SFBG		:SPACE OVER TWO BLOCK
004666	104420		SFBG		
004670	104414	017002	READ	.RLNK4	:READ LAST BLOCK OF DATA
004674	104423		BLKCMP		:COMPARE THE READ AND WRITE BUFFERS
004676	017002		RLNK4		:LINK TO THE READ BUFFER
004700	017036		WLNK4		:LINK TO THE WRITE BUFFER

 :TEST 27 TEST BSFG AFTER SFBG AND BSFG AFTER BSFG

004702	000004		↑ST27: SCOPE		
004704	012767	004754 174260	MOV	*TST30,SESCAPE	::ESCAPE TO TEST 30 ON ERROR
004712	104422		SELDRV		:SELECT DRIVE FOR TESTING
004714	104421		REWIND		:GO TO "BOT"
004716	104413	017022	WRITE	.WLNK1	:WRITE ONE BLOCK OF DATA
004722	104412		WFG		:WRITE A FILE GAP
004724	104413	017026	WRITE	.WLNK2	:WRITE A BLOCK OF DATA
004730	104421		REWIND		:GO TO "BOT"
004732	104417		SFBG		:SPACE OVER 1ST FILE
004734	104420		SFBG		:SPACE OVER 1ST BLOCK OF 2ND FILE
004736	104415		BSFG		:BACK TO BEGINNING OF 2ND FILE
004740	104415		BSFG		:BACK TO BEGINNING OF 1ST FILE
004742	104414	016766	READ	.RLNK1	:READ 1ST BLOCK OF 1ST FILE
004746	104423		BLKCMP		:COMPARE THE READ AND WRITE BUFFERS
004750	016766		RLNK1		:LINK TO THE READ BUFFER
004752	017022		WLNK1		:LINK TO THE WRITE BUFFER

 :TEST 30 TEST BSFG THRU A FILE GAP

004754	000004		↑ST30: SCOPE		
004756	012767	005032 174206	MOV	*TST31,SESCAPE	::ESCAPE TO TEST 31 ON ERROR
004764	104422		SELDRV		:SELECT DRIVE FOR TESTING
004766	104421		REWIND		:GO TO "BOT"
004770	104413	017022	WRITE	.WLNK1	:WRITE ONE BLOCK OF DATA
004774	104412		WFG		:WRITE A FILE GAP

```

1153 004776 104413 017026 WRITE ,WLNK2 ;WRITE TWO BLOCKS OF DATA
1154 005000 104413 017032 WRITE ,WLNK3
1155 005006 104421 REWIND ;GO TO "BOT"
1156 005010 104417 SFFG ;SPACE OVER 1ST FILE
1157 005012 104420 SFBG ;SPACE OVER 1ST BLOCK OF 2ND FILE
1158 005014 104416 BSBG ;BACK OVER 1 BLOCK
1159 005016 104416 BSBG ;BACK OVER 1 BLOCK
1160 005020 104414 016766 READ ,RLNK1 ;READ
1161 005024 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1162 005026 016766 RLNK1 ;LINK TO THE READ BUFFER
1163 005030 017022 WLNK1 ;LINK TO THE WRITE BUFFER

```

```

*****
*TEST 31 TEST BSBG AFTER BSBG
*****

```

```

1167 005032 000004 TST31: SCOPE
1168 005034 012767 005104 174130 MOV #TST32,$ESCAPE ;;ESCAPE TO TEST 32 ON ERROR
1169 005042 104422 SELDRV ;SELECT DRIVE FOR TESTING
1170 005044 104421 REWIND ;GO TO "BOT"
1171 005046 104413 017022 WRITE ,WLNK1 ;WRITE ONE BLOCK OF DATA
1172 005052 104412 WFG ;WRITE A FILE GAP
1173 005054 104413 017026 WRITE ,WLNK2 ;WRITE A BLOCK OF DATA
1174 005060 104421 REWIND ;GO TO "BOT"
1175 005062 104417 SFFG ;SPACE OVER FILE
1176 005064 104420 SFBG ;SPACE OVER 1ST BLOCK OF 2ND FILE
1177 005066 104416 BSBG ;BACK OVER BLOCK
1178 005070 104415 BSBG ;BACK OVER FILE
1179 005072 104414 016766 READ ,RLNK1 ;READ 1ST BLOCK ON TAPE
1180 005076 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1181 005100 016766 RLNK1 ;LINK TO THE READ BUFFER
1182 005102 017022 WLNK1 ;LINK TO THE WRITE BUFFER

```

```

*****
*TEST 32 TEST BSBG AFTER BSFG
*****

```

```

1186 005104 000004 TST32: SCOPE
1187 005106 012767 005150 174056 MOV #TST33,$ESCAPE ;;ESCAPE TO TEST 33 ON ERROR
1188 005114 104422 SELDRV ;SELECT DRIVE FOR TESTING
1189 005116 104421 REWIND ;GO TO "CLEAR LEADER"
1190 005120 104413 017022 WRITE ,WLNK1 ;WRITE BLOCK
1191 005124 104412 WFG ;WRITE A FILE GAP
1192 005126 104413 017026 WRITE ,WLNK2 ;FOLLOW WITH ANOTHER BLOCK
1193 005132 104415 BSFG ;BACK UP 1 FILE
1194 005134 104416 BSBG ;BACK UP 1 BLOCK
1195 005136 104414 016766 READ ,RLNK1 ;READ 1ST BLOCK ON TAPE
1196 005142 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1197 005144 016766 RLNK1 ;LINK TO THE READ BUFFER
1198 005146 017022 WLNK1 ;LINK TO THE WRITE BUFFER

```

```

*****
*TEST 33 TEST BSFG AFTER SFFG AND SFFG AFTER READ
*****

```

```

1202 005150 000004 TST33: SCOPE
1203 005152 012767 005232 174012 MOV #TST34,$ESCAPE ;;ESCAPE TO TEST 34 ON ERROR
1204 005160 104422 SELDRV ;SELECT DRIVE FOR TESTING
1205 005162 104421 REWIND ;GO TO "BOT"
1206 005164 104413 017022 WRITE ,WLNK1 ;WRITE A BLOCK OF DATA
1207 005170 104412 WFG ;WRITE A FILE GAP
1208 005172 104413 017026 WRITE ,WLNK2 ;WRITE A BLOCK OF DATA

```

```

1209 005176 104421 REWIND ;GO TO "BOT"
1210 005200 104417 SFFG ;SPACE OVER 1ST FILE
1211 005202 104415 BSFG ;BACK TO BEGINNING OF 1ST FILE
1212 005204 104414 016766 READ ,RLNK1 ;READ FIRST DATA BLOCK
1213 005210 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1214 005212 016766 RLNK1 ;LINK TO THE READ BUFFER
1215 005214 017022 WLNK1 ;LINK TO THE WRITE BUFFER
1216 005216 104417 SFFG ;SPACE TO BEGINNING ON 2ND FILE
1217 005220 104414 016772 READ ,RLNK2 ;READ 1ST BLOCK OF 2ND FILE
1218 005224 104423 BLKCMP ;COMPARE THE READ AND WRITE BLFFERS
1219 005226 016772 RLNK2 ;LINK TO THE READ BUFFER
1220 005230 017026 WLNK2 ;LINK TO THE WRITE BUFFER
1221 *****
1222 ;*TEST 34 TEST SFFG AFTER SFFG
1223 *****
1224 005232 000004 †TST34: SCOPE
1225 005234 012767 005310 173730 MOV #TST35,$ESCAPE ;;ESCAPE TO TEST 35 ON ERROR
1226 005242 104422 SELDRV ;SELECT DRIVE FOR TESTING
1227 005244 104421 REWIND ;GO TO BOT
1228 005246 104413 017022 WRITE ,WLNK1 ;WRITE A BLOCK
1229 005252 104412 WFG ;WRITE FILE GAP
1230 005254 104413 017026 WRITE ,WLNK2 ;WRITE A BLOCK
1231 005260 104412 WFG ;WRITE A FILE GAP
1232 005262 104413 017032 WRITE ,WLNK3 ;WRITE A BLOCK
1233 005266 104412 WFG ;WRITE A FILE GAP
1234 005270 104421 REWIND ;GO TO "BOT"
1235 005272 104417 SFFG ;SPACE OVER 1ST FILE
1236 005274 104417 SFFG ;SPACE OVER 2ND FILE
1237 005276 104414 016776 READ ,RLNK3 ;READ BLOCK OF 3RD FILE
1238 005302 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1239 005304 016776 RLNK3 ;LINK TO THE READ BUFFER
1240 005306 017032 WLNK3 ;LINK TO THE WRITE BUFFER
1241 *****
1242 ;*TEST 35 TEST SFFG AFTER SFBG
1243 *****
1244 005310 000004 †TST35: SCOPE
1245 005312 012767 005364 173652 MOV #TST36,$ESCAPE ;;ESCAPE TO TEST 36 ON ERROR
1246 005320 104422 SELDRV ;SELECT DRIVE FOR TESTING
1247 005322 104421 REWIND ;GO TO "BOT"
1248 005324 104413 017022 WRITE ,WLNK1 ;WRITE A BLOCK
1249 005330 104413 017026 WRITE ,WLNK2 ;WRITE A BLOCK
1250 005334 104412 WFG ;WRITE A GAP
1251 005336 104413 017032 WRITE ,WLNK3 ;WRITE A BLOCK
1252 005342 104412 WFG ;WRITE A GAP
1253 005344 104421 REWIND ;GO TO "BOT"
1254 005346 104420 SFBG ;SPACE OVER THE 1ST BLOCK(AND 1ST FILE)
1255 005350 104417 SFFG ;SPACE TO BEGINNING OF 2ND FILE
1256 005352 104414 016776 READ ,RLNK3 ;READ 1ST BLOCK OF 2RD FILE
1257 005356 104423 BLKCMP ;COMPARE THE READ AND WRITE 3UFFERS
1258 005360 016776 RLNK3 ;LINK TO THE READ BUFFER
1259 005362 017032 WLNK3 ;LINK TO THE WRITE BUFFER
1260 *****
1261 ;*TEST 36 TEST WFG AFTER SFBG
1262 *****
1263 005364 000004 †TST36: SCOPE
1264 005366 012767 005436 173576 MOV #TST37,$ESCAPE ;;ESCAPE TO TEST 37 ON ERROR

```



```

1255 005374 104422 SELDRV ;SELECT DRIVE FOR TESTING
1256 005376 104421 REWIND
1257 005400 104413 017022 WRITE ,WLNK1 ;WRITE 2 BLOCKS
1258 005404 104413 017026 WRITE ,WLNK2
1259 005410 104421 REWIND ;GO TO "BOT"
1260 005412 104420 SFBG ;GET OVER THE 1ST BLOCK
1261 005414 104412 WFG ;WRITE A GAP OVER 2ND BLOCK
1262 005416 104413 017032 WRITE ,WLNK3 ;WRITE A BLOCK
1263 005422 104415 BSFG ;BACK OVER THE BLOCK
1264 005424 104414 016776 READ ,RLNK3 ;AND READ IT
1265 005430 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1266 005432 016776 RLNK3 ;LINK TO THE READ BUFFER
1267 005434 017032 WLNK3 ;LINK TO THE WRITE BUFFER
1268
1269 *****
1270 *TEST 37 TEST WRITE AFTER SFBG
1271 *****
1272 *ST37: SCOPE
1273 MOV #TST40,$ESCAPE ;;ESCAPE TO TEST 40 ON ERROR
1274 SELDRV ;SELECT DRIVE FOR TESTING
1275 REWIND ;GO TO BOT
1276 WRITE ,WLNK1 ;WRITE 2 BLOCK
1277 WRITE ,WLNK2
1278 REWIND ;GO TO BOT
1279 SFBG ;SPACE OVER 1ST BLOCK
1280 WRITE ,WLNK3 ;WRITE OVER 2ND BLOCK
1281 BSFG ;GO TO BEGINNING OF FILE
1282 SFBG ;SPACE OVER 1ST BLOCK
1283 READ ,RLNK3 ;READ THE NEW 2ND BLOCK
1284 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1285 RLNK3 ;LINK TO THE READ BUFFER
1286 WLNK3 ;LINK TO THE WRITE BUFFER
1287
1288 *****
1289 *TEST 40 3 ONE BLOCK FILES---MULTI SPACING & TEST SFFG AFTER BSFG
1290 *****
1291 *ST40: SCOPE
1292 MOV #TST41,$ESCAPE ;;ESCAPE TO TEST 41 ON ERROR
1293 SELDRV ;SELECT DRIVE FOR TESTING
1294 REWIND ;GO TO "BOT"
1295 WRITE ,WLNK1 ;WRITE A BLOCK
1296 WFG ;FILE GAP
1297 WRITE ,WLNK2 ;BLOCK
1298 WFG ;FILE GAP
1299 WRITE ,WLNK3 ;BLOCK
1300 WFG ;FILE GAP
1301 REWIND ;GO TO "BOT"
1302 SFFG ;SPACE OVER 1ST FILE
1303 SFFG ;SPACE OVER 2ND FILE
1304 SFFG ;SPACE OVER 3RD FILE
1305 BSFG ;BACK OVER 3RD FILE
1306 BSFG ;BACK OVER 2ND FILE
1307 BSFG ;BACK OVER 1ST FILE
1308 SFFG ;GO TO BEGINNING OF 2ND FILE
1309 READ ,RLNK2 ;READ THE BLOCK
1310 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1311 RLNK2 ;LINK TO THE READ BUFFER
1312 WLNK2 ;LINK TO THE WRITE BUFFER
1313
1314
1315
1316
1317
1318
1319
1320

```


F04

TAII MOTION TEST
DZTADC.NEW

MAINDEC-11-DZTAD-C
24-MAY-76 00:00 T41

MACY11 27(1006) 23-SEP-76 10:33 PAGE 28
TWO BLOCK FILES---MULTI SPACING FUNCTIONS

SEQ 0044

```

1321
1322
1323
1324 005600 000004
1325 005602 012767 005706 173362
1326 005610 104422
1327 005612 104421
1328 005614 104413 017022
1329 005620 104413 017026
1330 005624 104412
1331 005626 104413 017032
1332 005632 104413 017036
1333 005636 104412
1334 005640 104413 017042
1335 005644 104413 017046
1336 005650 104412
1337 005652 104421
1338 005654 104417
1339 005656 104417
1340 005660 104414 017006
1341 005664 104423
1342 005666 017006
1343 005670 017042
1344 005672 104415
1345 005674 104414 017006
1346 005700 104423
1347 005702 017006
1348 005704 017042
1349
1350
1351
1352 005706 000004
1353 005710 012767 006056 173254
1354 005716 104422
1355 005720 104421
1356 005722 104413 017022
1357 005726 104413 017026
1358 005732 104413 017032
1359 005736 104412
1360 005740 104413 017036
1361 005744 104413 017042
1362 005750 104412
1363 005752 104421
1364 005754 104417
1365 005756 104417
1366 005760 104415
1367 005762 104414 017002
1368 005766 104423
1369 005770 017002
1370 005772 017036
1371 005774 104415
1372 005776 104415
1373 006000 104414 016766
1374 006004 104423
1375 006006 016766
1376 006010 017022

*****
*TEST 41 TWO BLOCK FILES---MULTI SPACING FUNCTIONS
*****
TST41: SCOPE
MOV #TST42,$ESCAPE ;;ESCAPE TO TEST 42 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "BOT"
WRITE ,WLNK1 ;WRITE A 2 BLOCK FILE
WRITE ,WLNK2
WFG
WRITE ,WLNK3 ;WRITE A 2 BLOCK FILE
WRITE ,WLNK4
WFG
WRITE ,WLNK5 ;WRITE A 2 BLOCK FILE
WRITE ,WLNK6
WFG
REWIND ;GO TO "BOT"
SFFG ;SPACE OVER 1ST FILE
SFFG ;SPACE OVER 2ND FILE
READ ,RLNK5 ;READ 1ST BLOCK OF 3RD FILE
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK5 ;LINK TO THE READ BUFFER
WLNK5 ;LINK TO THE WRITE BUFFER
BSFG ;BACK TO BEGINNING OF 3RD FILE
READ ,RLNK5 ;READ 1ST BLOCK OF 3RD FILE
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK5 ;LINK TO THE READ BUFFER
WLNK5 ;LINK TO THE WRITE BUFFER
*****
*TEST 42 MULTI SPACING & TEST SFBG AFTER READ
*****
TST42: SCOPE
MOV #TST42,$ESCAPE ;;ESCAPE TO TEST 43 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "BOT"
WRITE ,WLNK1 ;WRITE A 3 BLOCK FILE
WRITE ,WLNK2
WRITE ,WLNK3
WFG
WRITE ,WLNK4 ;WRITE A 2 BLOCK FILE
WRITE ,WLNK5
WFG
REWIND ;GO TO "BOT"
SFFG ;SPACE OVER THE 1ST FILE
SFFG ;SPACE OVER THE 2ND FILE
BSFG ;BACK TO BEGINNING OF 2 FILE
READ ,RLNK4 ;READ 1ST BLOCK OF 2ND FILE
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK4 ;LINK TO THE READ BUFFER
WLNK4 ;LINK TO THE WRITE BUFFER
BSFG ;BACK TO BEGINNING OF 2ND FILE
BSFG ;BACK OVER 1ST FILE
READ ,RLNK1 ;READ 1ND BLOCK OF 1ST FILE
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK1 ;LINK TO THE READ BUFFER
WLNK1 ;LINK TO THE WRITE BUFFER

```

```

1377 006012 104415          BSFG          ;GO TO BEGINNING OF 1ST FILE
1378 006014 104414 016766  READ          .RLNK1      ;READ 1ST BLOCK
1379 006020 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
1380 006022 016766          RLNK1         ;LINK TO THE READ BUFFER
1381 006024 017022          WLNK1         ;LINK TO THE WRITE BUFFER
1382 006026 104420          SFBG         ;GET OVER 2ND BLOCK
1383 006030 104414 016776  READ          .RLNK3      ;READ 3RD BLOCK
1384 006034 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
1385 006036 016776          RLNK3         ;LINK TO THE READ BUFFER
1386 006040 017032          WLNK3         ;LINK TO THE WRITE BUFFER
1387 006042 104417          SFFG         ;GO TO BEGINNING OF 2ND FILE
1388 006044 104414 017002  READ          ,RLNK4      ;READ 1ST BLOCK OF 2ND FILE
1389 006050 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
1390 006052 017002          RLNK4         ;LINK TO THE READ BUFFER
1391 006054 017036          WLNK4         ;LINK TO THE WRITE BUFFER
1392
1393
1394
1395 006056 000004          ;*****
1396 006060 012767 006176 173104  ;*TEST 43      TWO BLOCK FILES--MULTI SPACING & TEST SFFG AFTER BSBG
1397 006066 104422          ;*****
1398 006070 104421          †ST43: SCOPE
1399 006072 104413 017022  MOV          #TST44,$ESCAPE ;:ESCAPE TO TEST 44 ON ERROR
1400 006076 104413 017026  SELDRV      ;SELECT DRIVE FOR TESTING
1401 006102 104412          REWIND       ;GO TO BOT
1402 006104 104413 017032  WRITE       .WLNK1      ;WRITE A 2 BLOCK FILE
1403 006110 104413 017036  WRITE       .WLNK2
1404 006114 104412          WFG
1405 006116 104413 017042  WRITE       .WLNK3      ;WRITE A 2 BLOCK FILE
1406 006122 104413 017046  WRITE       ,WLNK4
1407 006126 104412          WFG
1408 006130 104421          WRITE       .WLNK5      ;WRITE A 2 BLOCK FILE
1409 006132 104417          WRITE       ,WLNK6
1410 006134 104417          WFG
1411 006136 104417          REWIND       ;BOT
1412 006140 104415          SFFG         ;SPACE OVER 3 FILES
1413 006142 104415          SFFG
1414 006144 104416          SFFG
1415 006146 104417          BSFG         ;BACK OVER 2 FILES
1416 006150 104414 016776  BSFG
1417 006154 104423          BSFG
1418 006156 016776          BSBG
1419 006160 017032          SFFG
1420 006162 104417          BSFG         ;BACK TO 2ND BLOCK OF 1ST FILE
1421 006164 104414 017006  BSFG
1422 006170 104423          SFFG
1423 006172 017006          READ          .RLNK3      ;GO TO BEGINNING OF 2ND FILE
1424 006174 017042          BLKCMP        ;READ 1ST RECORD OF 2ND FILE
1425          RLNK3        ;COMPARE THE READ AND WRITE BUFFERS
1426          WLNK3        ;LINK TO THE READ BUFFER
1427          SFFG        ;LINK TO THE WRITE BUFFER
1428          READ          .RLNK5      ;GO TO 3RD FILE
1429          BLKCMP        ;READ 1ST RECORD OF 3RD FILE
1430          RLNK5        ;COMPARE THE READ AND WRITE BUFFERS
1431          WLNK5        ;LINK TO THE READ BUFFER
1432          ;LINK TO THE WRITE BUFFER
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000

```

1433	006216	104412		WFG		
1434	006220	104413	017026	WRITE	,WLNK2	;WRITE A 1 BLOCK FILE
1435	006224	104412		WFG		
1436	006226	104413	017032	WRITE	,WLNK3	;WRITE A 1 BLOCK FILE
1437	006232	104412		WFG		
1438	006234	104413	017036	WRITE	,WLNK4	;WRITE A 1 BLOCK FILE
1439	006240	104412		WFG		
1440	006242	104413	017042	WRITE	,WLNK5	;WRITE A 1 BLOCK FILE
1441	006246	104412		WFG		
1442	006250	104413	017046	WRITE	,WLNK6	;WRITE A 1 BLOCK FILE
1443	006254	104412		WFG		
1444	006256	104421		REWIND		;BOT
1445	006260	104417		SFFG		;SPACE OVER 1ST FILE
1446	006262	104417		SFFG		;SPACE OVER 2ND FILE
1447	006264	104417		SFFG		;SPACE OVER 3RD FILE
1448	006266	104417		SFFG		;SPACE OVER 4TH FILE
1449	006270	104417		SFFG		;SPACE OVER 5TH FILE
1450	006272	104417		SFFG		;SPACE OVER 6TH FILE
1451	006274	104415		BSFG		;NOW BACK UP AND READ IT
1452	006276	104414	017012	READ	,RLNK6	
1453	006302	104423		BLKCMP		;COMPARE THE READ AND WRITE BUFFERS
1454	006304	017012		RLNK6		;LINK TO THE READ BUFFER
1455	006306	017046		WLNK6		;LINK TO THE WRITE BUFFER
1456	006310	104415		BSFG		;BACK UP TO 5TH FILE
1457	006312	104415		BSFG		
1458	006314	104414	017006	READ	,RLNK5	;AND READ IT
1459	006320	104423		BLKCMP		;COMPARE THE READ AND WRITE BUFFERS
1460	006322	017006		RLNK5		;LINK TO THE READ BUFFER
1461	006324	017042		WLNK5		;LINK TO THE WRITE BUFFER
1462	006326	104415		BSFG		;BACK UP TO 3RD FILE
1463	006330	104415		BSFG		
1464	006332	104415		BSFG		
1465	006334	104414	016776	READ	,RLNK3	;AND READ IT
1466	006340	104423		BLKCMP		;COMPARE THE READ AND WRITE BUFFERS
1467	006342	016776		RLNK3		;LINK TO THE READ BUFFER
1468	006344	017032		WLNK3		;LINK TO THE WRITE BUFFER
1469	006346	104415		BSFG		;BACK UP TO 1ST FILE
1470	006350	104415		BSFG		
1471	006352	104415		BSFG		
1472	006354	104414	016766	READ	,RLNK1	;AND READ IT
1473	006360	104423		BLKCMP		;COMPARE THE READ AND WRITE BUFFERS
1474	006362	016766		RLNK1		;LINK TO THE READ BUFFER
1475	006364	017022		WLNK1		;LINK TO THE WRITE BUFFER

```

1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486 006366
1487 006356 000004
1488 006370 005067 172506
1489 006374 005067 172570
1490 006400 005267 172474
1491 006404 042767 100000 172466
1492 006412 005327
1493 006414 000001
1494 006416 003015
1495 006420 012737
1496 006422 000001
1497 006424 006414
1498 006426 104401 006461
1499 006432 013700 000042
1500 006436 001405
1501 006440 000005
1502 006442 004710
1503 006444 000240
1504 006446 000240
1505 006450 000240
1506 006452
1507 006452 000137
1508 006454 002326
1509 006456 377 377 000
1510 006461 015 042412 042116
1511 006466 050040 051501 000123

```

```

.SBTTL END OF PASS ROUTINE
:*****
:*INCREMENT THE PASS NUMBER ($PASS)
:*TYPE "END PASS"
:*IF THERES A MONITOR GO TO IT
:*IF THERE ISN'T JUMP TO START
:*IF IT IS DESIRED TO HAVE A BELL INDICATE THE "END OF PASS" LOCATION
:*SENDMG CAN BE CHANGED TO 7.

$EOP:
SCOPE
CLR $STNM ;;ZERO THE TEST NUMBER
CLR $TIMES ;;ZERO THE NUMBER OF ITERATIONS
INC $PASS ;;INCREMENT THE PASS NUMBER
BIC *100000,$PASS ;;DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;;LOOP?

$EOPCT: .WORD 1
BGT $DOAGN ;;YES
MOV (PC)+,a(PC)+ ;;RESTORE COUNTER

$ENDCT: .WORD 1
TYPE $SENDMG ;;TYPE "END PASS"
MOV a#42,RO ;;GET MONITOR ADDRESS
BEQ $DOAGN ;;BRANCH IF NO MONITOR
RESET ;;CLEAR THE WORLD
$ENDAD: JSR PC,(RO) ;;GO TO MONITOR
NOP ;;SAVE ROOM
NOP ;;FOR
NOP ;;ACT11

$DOAGN:
JMP a(PC)+ ;;RETURN

$RTNAD: .WORD START
$ENULL: .BYTE -1,-1,0 ;;NULL CHARACTER STRING
$ENDMG: .ASCIZ <15><12>/END PASS/

```

```

1512      ;:*****
1513      ;
1514      .SBTTL          ROUTINE TO EXAMINE DRIVE(S) FOR AVAILABILITY
1515
1516      ;CALL:
1517      ;               MOV      #DRVKEY,RO
1518      ;               JSR      PC,@#EXAM          ;R1 IS DESTROYED
1519      ;               NORMAL RETURN
1520      ;               ERROR RETURN
1521
1522 006474 013701 001220 EXAM: MOV      @#TACSL,R1          ;PICKUP THE "CONTROL & STATUS" REG. ADR.
1523 006500 005011          CLR      (R1)          ;DRIVE="A" FUNCTION="WFG"
1524 006502 122710 000101 CMPB    #'A,(R0)          ;EXAMINE DRIVE "A"?
1525 006506 001402          BEQ      1$          ;BR IF YES
1526 006510 052711 000400 BIS     #UNIT,(R1)          ;SELECT DRIVE "B"
1527 006514 032711 000040 1$: BIT   #READY,(R1)          ;WAIT ON READY
1528 006520 001775          BEQ      1$
1529 006522 005711          TST     (R1)          ;ANY ERROR?
1530 006524 100024          BPL     4$          ;BR IF NO
1531 006526 032711 001000 BIT     #OFFLINE,(R1)          ;ERROR DUE TO "OFF LINE"?
1532 006532 001017          BNE     3$          ;BR IF YES
1533 006534 032711 010000 BIT     #WRTLOCK,(R1)          ;ERROR DUE TO "WRITE LOCK"?
1534 006540 001411          BEQ      2$          ;BR IF NO
1535 006542 122777 000201 172370 CMPB    #BIT07!BIT00,@SWR          ;"READONLY" SELECTED? (RD1PAS)
1536 006550 001412          BEQ      4$          ;BR IF YES
1537 006552 122777 000203 172360 CMPB    #BIT07!BIT01!BIT00,@SWR          ;(RD2PAS)?
1538 006560 001406          BEQ      4$          ;BR IF YES
1539 006562 000403          BR      3$          ;TAKE THE ERROR EXIT
1540 006564 032711 020000 2$: BIT   #LEADER,(R1)          ;ERROR DUE TO "CLEAR LEADER"?
1541 006570 001002          BNE     4$          ;BR IF YES
1542 006572 062716 000002 3$: ADD   #2,(SP)          ;TAKE ERROR RETURN
1543 006576 000207          RTS     PC          ;RETURN

```

```

1544 .SBTTL SCOPE HANDLER ROUTINE
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557 006600
1558 006600 104406
1559 006602 105777 172336
1560 006606 001405
1561 006610 104407
1562 006612 122627 000003
1563 006616 001001
1564 006620 104424
1565 006622 005727
1566 006624 000000
1567 006626 001105
1568 006630 032777 040000 172302
1569 006636 001101
1570
1571 006640 000416
1572
1573 006642 013746 000004
1574 006646 012737 006666 000004
1575 006654 005737 177060
1576 006660 012637 000004
1577 006664 000453
1578 006666 022626
1579 006670 012637 000004
1580 006674 000413
1581 006676
1582 006676 105767 172201
1583 006702 001421
1584 006704 126767 172205 172171
1585 006712 101015
1586 006714 032777 001000 172216
1587 006722 001404
1588 006724 016767 172160 172154
1589 006732 000443
1590 006734 105067 172143
1591 006740 005067 172224
1592 006744 000415
1593 006746 032777 004000 172164
1594 006754 001011
1595 006756 005767 172116
1596 006762 001406
1597 006764 005267 172114
1598 006770 026767 172174 172106
1599 006776 002021

;*****
;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;SW14=1 LOOP ON TEST
;SW11=1 INHIBIT ITERATIONS
;SW09=1 LOOP ON ERROR
;CALL
;* SCOPE ;:SCOPE=IOT

$SCOPE:
CKSWR ;:TEST FOR CHANGE IN SOFT-SWR
TSTB $STKS ;TTY FLAG UP?
BEQ 100$ ;BR IF NO
RDCHR ;GO GET ONE CHARACTER FROM TTY
CMPB (SP)+,#3 ;IS IT A CONTROL/C ?
BNE 100$ ;BR IF NO
SETLOOP ;GO GET "TEST" AND "SCOPE LOOP" ADDRESSES
100$: TST (PC)+ ;LOOP ON TEST?
LOOPKEY: 0
BNE $OVER ;BR IF YES
1$: BIT #BIT14,$SWR ;:LOOP ON PRESENT TEST?
BNE $OVER ;YES IF SW14=1
;*****START OF CODE FOR THE XOR TESTER*****
$XTSTR: BR 6$ ;IF RUNNING ON THE "XOR" TESTER CHANGE
;THIS INSTRUCTION TO A "NOP" (NOP=240)
;SAVE THE CONTENTS OF THE ERROR VECTOR
MOV $#ERRVEC,-(SP) ;SET FOR TIMEOUT
MOV #5,$#ERRVEC ;TIME OUT ON XOR?
TST $#177060 ;RESTORE THE ERROR VECTOR
MOV (SP)+,$#ERRVEC ;GO TO THE NEXT TEST
BR $SVLAD ;CLEAR THE STACK AFTER A TIME OUT
5$: CMP (SP)+,(SP)+ ;RESTORE THE ERROR VECTOR
MOV (SP)+,$#ERRVEC ;LOOP ON THE PRESENT TEST
BR 7$ ;*****END OF CODE FOR THE XOR TESTER*****
6$: ;HAS AN ERROR OCCURRED?
2$: TSTB $ERFLG ;BR IF NO
BEQ 3$ ;MAX. ERRORS FOR THIS TEST OCCURRED?
CMPB $ERMAX,$ERFLG ;BR IF NO
BHI 3$ ;LOOP ON ERROR?
BIT #BIT09,$SWR ;BR IF NO
BEQ 4$ ;SET LOOP ADDRESS TO LAST SCOPE
7$: MOV $LPERR,$LPADR ;ZERO THE ERROR FLAG
BR $OVER ;CLEAR THE NUMBER OF ITERATIONS TO MAKE
4$: CLRB $ERFLG ;ESCAPE TO THE NEXT TEST
CLR $TIMES ;INHIBIT ITERATIONS?
BR 1$ ;BR IF YES
1$: BIT #BIT11,$SWR ;IF FIRST PASS OF PROGRAM
BNE 1$ ; INHIBIT ITERATIONS
TST $PASS ;INCREMENT ITERATION COUNT
BEQ 1$ ;CHECK THE NUMBER OF ITERATIONS MADE
INC $ICNT ;BR IF MORE ITERATION REQUIRED
CMP $TIMES,$ICNT
BGE $OVER

```

1600	007000	012767	000001	172076	IS:	MOV	#1,SICNT	::REINITIALIZE THE ITERATION COUNTER
1601	007006	016767	172204	172154		MOV	\$MYCNT,\$TIMES	::SET NUMBER OF ITERATIONS TO DO
1602	007014	105267	172062		\$SVLAD:	INCB	\$TSTNM	::COUNT TEST NUMBERS
1603	007020	011567	172062			MOV	(SP), \$LPADR	::SAVE SCOPE LOOP ADDRESS
1604	007024	011667	172060			MOV	(SP), \$LPERR	::SAVE ERROR LOOP ADDRESS
1605	007030	005067	172136			CLR	\$ESCAPE	::CLEAR THE ESCAPE FROM ERROR ADDRESS
1606	007034	112767	000001	172053		MOVB	#1,\$ERMAX	::ONLY ALLOW ONE(1) ERROR ON NEXT TEST
1607	007042	016777	172034	172072	\$OVER:	MOV	\$TSTNM,\$DISPLAY	::DISPLAY TEST NUMBER
1608	007050	016716	172032			MOV	\$LPADR,(SP)	::FUDGE RETURN ADDRESS
1609	007054	000002				RTI		::FIXES PS

```

1610      .SBTTL  ERROR HANDLER ROUTINE
1611
1612      ;*****
1613      ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
1614      ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
1615      ;*AND GO TO TYPERR ON ERROR
1616      ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
1617      ;*SW15=1      HALT ON ERROR
1618      ;*SW13=1      INHIBIT ERROR TYPEOUTS
1619      ;*SW10=1      BELL ON ERROR
1620      ;*SW09=1      LOOP ON ERROR
1621      ;*CALL
1622      ;*      ERROR  N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
1623
1624      007056      $ERROR:      CKSWR      ;;TEST FOR CHANGE IN SOFT-SWR
1625      007056      104406      MOV      @TACS,@#$REG0      ;SAVE THE TAIL STATUS
1626      007060      011437      001162      MOV      @TADB,@#$REG1      ;SAVE THE DATA BUFFER
1627      007064      011537      001164      TSTB     @TACS      ;IF "XFER REQ" IS UP KNOCK IT DOWN
1628      007070      105714      BPL      100$
1629      007072      100003      MOV      #ILBS,@TACS
1630      007074      112714      000020      BR      101$
1631      007100      000406      100$:    BIT      #READY,@TACS      ;IS READY SET?
1632      007102      032714      000040      BNE     101$      ;BR IF YES
1633      007106      001003      RESET   ;REGAIN CONTROL
1634      007110      000005      MOV     @#$REG0,@TACS      ;RESTORE THE TACS
1635      007112      013714      001162      CMP     (SP)+,(SP)+      ;POP THE STACK
1636      007116      022626      101$:    TST     ASKKEY      ;MANUAL LOOPING?
1637      007120      005767      172122      BGE     102$      ;BR IF NO
1638      007124      002002      MOV     (SP), $ESCAPE      ;SETUP FOR MANUAL ESCAPE
1639      007126      011667      172040      MOV     -4(SP), (SP)      ;GET PC+2 OF ERROR
1640      007132      016616      177774      102$:   INCB   $ERFLG      ;;SET THE ERROR FLAG
1641      007136      105267      171741      BEQ     7$      ;;DON'T LET THE FLAG GO TO ZERO
1642      007142      001775      MOV     $STNM,@DISPLAY      ;;DISPLAY TEST NUMBER AND ERROR FLAG
1643      007144      016777      171732      171770      BIT     #BIT10,@SWR      ;;BELL ON ERROR?
1644      007152      032777      002000      171760      BEQ     1$      ;;NO - SKIP
1645      007160      001402      TYPE    $BELL      ;;RING BELL
1646      007162      104401      001174      INC     $ERTTL      ;;COUNT THE NUMBER OF ERRORS
1647      007166      005267      171720      1$:     MOV     (SP), $ERRPC      ;;GET ADDRESS OF ERROR INSTRUCTION
1648      007172      011667      171720      SUB     #2,$ERRPC
1649      007176      162767      000002      171712      MOV     @ $ERRPC,$ITEMB      ;;STRIP AND SAVE THE ERROR ITEM CODE
1650      007204      117767      171706      171702      BIT     #BIT13,@SWR      ;;SKIP TYPEOUT IF SET
1651      007212      032777      020000      171720      BNE     20$      ;;SKIP TYPEOUTS
1652      007220      001004      JSR     PC,TYPERR      ;;GO TO USEF ERROR ROUTINE
1653      007222      004767      000060      TYPE    $CRLF
1654      007226      104401      001201      20$:   TST     @SWR      ;;HALT ON ERROR
1655      007232      007232      005777      171702      2$:   BPL     3$      ;;SKIP IF CONTINUE
1656      007236      100002      HALT    ;HALT ON ERROR!
1657      007240      000000      CKSWR   ;TEST FOR CHANGE IN SOFT-SWR
1658      007242      104406      3$:   BIT     #BIT09,@SWR      ;LOOP ON ERROR SWITCH SET?
1659      007244      032777      001000      171666      BEQ     4$      ;BR IF NO
1660      007246      001402      MOV     $LPERR,(SP)      ;FUDGE RETURN FOR LOOPING
1661      007252      001402      TST     $ESCAPE      ;CHECK FOR AN ESCAPE ADDRESS
1662      007254      016716      171630      4$:   BEQ     5$      ;BR IF NONE
1663      007260      005767      171706      MOV     $ESCAPE,(SP)      ;FUDGE RETURN ADDRESS FOR ESCAPE
1664      007264      001402
1665      007266      016716      171700

```


N04

TA11 MOTION TEST
DZTADC.NEW

24-MAY-76 00:00

MAINDEC-11-DZTAD-C

ERROR HANDLER ROUTINE

MACY11 27(1006)

23-SEP-76 10:33 PAGE 36

SEQ 0052

1666	007272			5\$:				
1667	007272	022737	006442	000042	CMP	#SENDAD,2#42	::ACT-11 AUTO-ACCEPT?	
1668	007300	001001			BNE	6\$::BRANCH IF NO	
1669	007302	000000			HALT		::YES	
1670	007304			6\$:				
1671	007304	000002			RTI		::RETURN	

```

*****
***** ROUTINE WILL TYPEOUT THE ERROR MESSAGES *****
1685 007306 104401 001201  TYPERR: TYPE .SCLF          :TYPE A CARRIAGE RETURN & LINE FEED
1686 007312 104401          :TYPE THE FUNCTION BEING PERFORMED
1687 007314 000000          :MESSAGE POINTER GOES HERE
1688 007316 104401 001201  MFUNC: 0          :ADJUST THE MAIN FLOW PC
1689 007322 162737 000002 001204  SUB 02,0,SAVPC      :SAVE RO
1690 007330 010046          MOV  RO - (SP)
1691 007332 113700 001114  MOVB 20,ITEMB,RO   :PICKUP THE ITEM INDEX
1692 007336 005300          DEC  RO           :ADJUST THE INDEX
1693 007340 006300          ASL  RO           :SO IT WILL WORK FOR
1694 007342 006300          ASL  RO           :THE ERROR TABLE
1695 007344 006300          ASL  RO
1696 007346 062700 001270  ADD  0,ERRTB,RO    :FORM THE TABLE POINTER
1697 007352 012067 000002  MOV  (RO)+,1$     :PICKUP "ERROR MESSAGE" POINTER
1698 007356 104401          TYPE "ERROR MESSAGE"
1699 007360 000000          1$: 0           :"ERROR MESSAGE POINTER" GOES HERE
1700 007362 012067 000004  MOV  (RO)+,2$     :PICKUP "DATA HEADER" POINTER
1701 007366 001402          BEQ  3$           :IF "0" DON'T TYPE
1702 007370 104401          TYPE "DATA HEADER"
1703 007372 000000          2$: 0           :"DATA HEADER" POINTER GOES HERE
1704 007374 012000 3$: MOV  (RO)+,RO     :PICKUP "DATA POINTER"
1705 007376 001004          BNE  5$           :IF THERE IS DATA TO TYPE GO DO IT
1706 007400 012600 4$: MOV  (SP)+,RO    :RESTORE RO
1707 007402 104401 001201  TYPE .SCLF        :TYPE A CAPRAGE RETURN&LINE FEED
1708 007406 000207          RTS  PC          :RETURN
1709 007410 5$:
1710 007410 013046          MOV  2(RO)+,-(SP) :SAVE 2(RO)+ FOR TYPEOUT
1711 007412 104402          TYPDC          :TYPE DATA
1712 007414 005710          TST  (RO)        :GO TYPE--OCTAL ASCII(ALL DIGITS)
1713 007416 001770          BEQ  4$          :TERMINATOR"
1714 007420 104401 007426  TYPE  6$          :BR IF YES
1715 007424 000771          BR   5$          :TYPE 2 SPACES
1716 007426 020040 000          5$: .ASCIZ ' '     :LOOP
1717 007432 007432          .EVEN         :ASCII STRING OF 2 SPACES

```

1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763

007432 104401 015146
007436 005067 171576
007442 104410
007444 012500
007446 105710
007450 001425
007452 012701 001240
007456 122710 000101
007462 001002
007464 112021
007466 000411
007470 122710 000102
007474 001002
007476 112021
007500 000404
007502 122710 000054
007506 001006
007510 105720
007512 105710
007514 001406
007516 022701 001242
007522 101355
007524 104401 001200
007530 000740
007532 005767 171502
007536 001772
007540 000207

::*****

.SBTTL ROUTINE TO ASK THE OPERATOR WHAT DRIVE(S) TO TEST

:CALL
:JSR PC,2*ASKDRV
:RETURN ;NOTE: R0 AND R1 ARE DESTROYED

ASKDRV: TYPE MSGDRV ;(CRLF)"DRIVE(S)"
CLR DRVKEY ;GO GET A DRIVE
RDLIN ;SETUP TO CHECK FOR VALID DRIVE(S)
MOV (SP)+,R0 ;WAS A DRIVE SELECTED?
TSTB JRC ;BR IF NO
BEQ NOTLGL
MOV #DRVKEY,R1 ;WAS DRIVE "A" SELECTED?
LOOP: CMPB #'A,JRC ;BR IF NO
BNE NOTA ;SET KEY FOR DRIVE "A"
MOVB (R0)+,(R1)+
BR NEXT ;WAS DRIVE "B" SELECTED?
NOTA: CMPB #'B,JRC ;BR IF NO
BNE NOTB ;SET KEY FOR DRIVE "B"
MOVB (R0)+,(R1)+
BR NEXT ;WAS A COMMA TYPED?
NOTB: CMPB #54,JRC ;BR IF NO
BNE NOTLGL ;DUMP THE COMMA
TSTB (R0)+ ;TERMINATOR?
NEXT: TSTB JRC ;BR IF YES
BEQ EXIT ;TWO DRIVES SELECTED?
CMP #DRVKEY+2,R1 ;BR IF NO
BHI LOOP ;ILLEGAL INPUT DETECTED
NOTLGL: TYPE \$QUES ;GO TRY AGAIN
BR ASKDRV ;ANY DRIVE SELECTED?
EXIT: TST DRVKEY ;BR IF NO
BEQ NOTLGL
RTS PC

::*****

:CALL
:JSR PC,2*ASKADR

ASKADR: MOV R0, -(SP) ;SAVE R0
IS: TYPE ,MSGASK ;"TACS?"
RDOCT ;GET VALUE
MOV (SP)+,R0 ;PICK UP THE OCTAL NUMBER
BEQ 3\$;IF "0" USE OLD VALUES
CMP R0,#160000 ;MAKE SURE IT IS A BUS ADDRESS
BLO 1\$
MOV R0,2*TACSL ;SAVE THE TACS
ADD #2,R0 ;STEP TO TADB ADDRESS
MOV R0,2*TADBL ;AND SAVE IT
MOV 2*TACSL,2*TACSH ;SET UP TACS UPPER
INC 2*TACSH ;BYTE POINTER
MOV 2*TADBL,2*TADBH ;SET UP TADB UPPER
INC 2*TADBH ;BYTE POINTER
3\$: TYPE ,MSGVEC ;"VECTOR?"

```

1764 007630 104411 RDOCT
1765 007632 012600 MOV (SP)+,RO
1766 007634 001411 BEQ 5$
1767 007636 020027 001000 CMP RO,#1000 ;MAKE SURE ADDRESS IS IN VECTOR AREA
1768 007642 103370 BHIS 3$
1769 007644 010037 001230 MOV RO,2#TAVEC ;SAVE AS VECTOR ADDRESS
1770 007650 062700 000002 ADD #2,RO
1771 007654 010037 001232 MOV RO,2#TAVEC+2
1772 007660 104401 015202 5$: TYPE ,MSGPRI ;ASK FOR PRIORITY
1773 007664 104411 RDOCT
1774 007666 012600 MOV (SP)+,RO
1775 007670 001413 BEQ 6$ ;IF "0" USE OLD VALUE
1776 007672 020027 000007 CMP RO,#7 ;MAKE SURE ITS VALID
1777 007676 101370 BHI 5$
1778 007700 000300 SWAB RO ;PUT INTO HIGH BYTE
1779 007702 006200 ASR RO ;AND SHIFT
1780 007704 006200 ASR RO ;INTO PROPER
1781 007706 006200 ASR RO ;POSITION
1782 007710 042700 177437 BIC #1C(340),RO ;SAVE ONLY PRIORITY BITS
1783 007714 010037 001234 MOV RO,2#TAPRIO ;STORE IT AWAY
1784 007720 104401 015214 6$: TYPE ,TACS ;TACS="
1785 007724 016746 171270 MOV TACSL,-(SP) ;;SAVE TACSL FOR TYPEOUT
1786 007730 104402 TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
1787 007732 104401 015223 TYPE ,MTADB ;"TADB="
1788 007736 016746 171262 MOV TADBL,-(SP) ;;SAVE TADBL FOR TYPEOUT
1789 007742 104402 TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
1790 007744 104401 015232 TYPE ,MTAVEC ;"VECTOR="
1791 007750 016746 171254 MOV TAVEC,-(SP) ;;SAVE TAVEC FOR TYPEOUT
1792 007754 104402 TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
1793 007756 104401 015243 TYPE ,MTAPRI ;"PRIORITY="
1794 007762 016746 171246 MOV TAPRIO,-(SP) ;;SAVE TAPRIO FOR TYPEOUT
1795 007766 104402 TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
1796 007770 104401 015256 TYPE ,MSGOK ;"OK?"
1797 007774 104407 RDCHR ;GO READ ONE CHARACTER
1798 007776 012600 MOV (SP)+,RO ;GET IT
1799 010000 022700 000015 CMP #15,RO ;IS IT "CR"?
1800 010004 001406 BEQ 7$ ;BRANCH IF YES
1801 010006 022700 000131 CMP #Y,RO ;IS IT "Y"?
1802 010012 001403 BEQ 7$ ;IT WAS
1803 010014 104401 001200 TYPE ,SQUES ;TYPE "?"
1804 010020 000651 BR 1$ ;AND LET HIM CORRECT THEM
1805 010022 104401 015264 7$: TYPE ,MYES ;TYPE OUT "YES"
1806 010026 012600 MOV (SP)+,RO ;RESTORE RO
1807 010030 000207 RTS PC ;AND RETURN

```

```

1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819

```

```

:*****
:THIS ROUTINE WILL CHANGE AN .ASCII STRING TO AN OCTAL NUMBER

```

```

:REGISTER R1 MUST BE INITIALIZED BEFORE ENTERING

```

```

:CALL:

```

```

JSR R3,2#A20CT
POINTER

```

```

:CALL THE ROUTINE
:ADDRESS OF THE FIRST CHARACTER IN THE STRING
:STRING MUST BE TERMINATED BY A BYTE OF ALL 0'S
:RETURN HERE IF ILLEGAL CHARACTER

```

```

ERROR RETURN

```


F05

TA11 MOTION TEST
DZTADC.NEW

MAINDEC-11-DZTAD-C
24-MAY-76 00:00

MACY11 27(1006) 23-SEP-76 10:33 PAGE 41
ROUTINE TO GET "TEST" AND "SCOPE LOOP" ADDRESSES FROM THE TTY

SEQ 0057

```

1844
1845
1846
1847 010116
1848 010116 104401 015326
1849 010122 104410
1850 010124 012667 000022
1851 010130 105777 000016
1852 010134 001442
1853 010136 022626
1854 010140 010167 000110
1855 010144 005001
1856 010146 004337 010032
1857 010152 000000
1858 010154 000760
1859 010156 005721
1860 010160 010116
1861 010162 104401 015341
1862 010166 104410
1863 010170 012667 000014
1864 010174 105777 000010
1865 010200 001410
1866 010202 005001
1867 010204 004337 010032
1868 010210 000000
1869 010212 000763
1870 010214 010137 001106
1871 010220 000402
1872 010222 011637 001106
1873 010226 011637 001110
1874 010232 012737 177777 006624
1875 010240 000402
1876 010242 005037 006624
1877 010246 016701 000002
1878 010252 000002
1879 010254 000000

;*****
;THIS ROUTINE WILL INPUT THE ADDRESSES OF "TEST" AND "SCOPE LOOP" FROM THE TTY

T.SETLOOP:
    TYPE      .MTEST
    RDLIN
    MOV      (SP)+,11$
    TSTB    @11$
    BEQ      3$
    CMP      (SP)+,(SP)+
    MOV      R1,SAVR1
    CLR      R1
    JSR      R3,@#A20CT
11$:    D
    BR      T.SETLOOP
    TST      (R1)+
    MOV      R1,(SP)
5$:    TYPE      ,MLOOP
    RDLIN
    MOV      (SP)+,12$
    TSTB    @12$
    BEQ      1$
    CLR      R1
    JSR      R3,@#A20CT
12$:    D
    BR      5$
    MOV      R1,@#SLPADR
    BR      2$
1$:    MOV      (SP),@#SLPADR
2$:    MOV      (SP),@#SLPERR
    MOV      #-1,@#LOOPKEY
    BR      4$
3$:    CLR      @#LOOPKEY
4$:    MOV      SAVR1,R1
    RTI
SAVR1:  D

;TYPE "TEST PC?"
;GET AN ASCII STRING
;GET FIRST ADDRESS OF INPUT BUFFER
;FIRST CHAR. A "CR" ?
;BR IF YES---GO CLEAR THE LOOP KEY
;POP POP
;SAVE R1
;SET PARTIAL TO ZERO
;GO CHANGE ASCII TO OCTAL
;POINTER TO STRING
;ERROR RETURN--GO TRY AGAIN
;JUST INCREMENTING
;PUT "TEST PC"; ON THE STACK
;TYPE "LOOP PC ?"
;GET A STRING OF ASCII
;GET FIRST ADDRESS OF INPUT BUFFER
;JUST A "CR" ?
;BR IF YES
;CLEAR PARTIAL
;CHANGE TO OCTAL

;SAVE SCOPE LOOP ADDRESS
;GO SET LOOP KEY
;SAVE SCOPE LOOP ADDRESS
;ERROR LOOP SAME AS THE TEST ADDRESS
;SET THE LOOP KEY

;CLEAR THE LOOP KEY
;RESTORE R1
;BYE BYE
;HOLD R1 HERE

```

G05

TAII MOTION TEST
DZTADC.NEW

24-MAY-76 00:00
MAINDEC-11-DZTAD-C

MACY11 27(1006) 23-SEP-76 10:33 PAGE 42
ROUTINE TO SELECT THE DRIVE TO BE TESTED

SEQ 0058

```

1890
1891
1892
1893
1894 010256
1895 010256 032777 000200 170654
1896 010264 001041
1897 010266 010146
1898 010270 016701 170742
1899 010274 111137 001250
1900 010300 121127 000101
1901 010304 001406
1902 010306 052714 000400
1903 010312 012737 001262 001256
1904 010320 000405
1905 010322 042714 000400 1S:
1906 010326 012737 001260 001256 2S:
1907 010334 005201
1908 010336 105711
1909 010340 001002
1910 010342 012701 001240
1911 010346 010167 170664 3S:
1912 010352 032777 001000 170560
1913 010360 001002
1914 010362 105037 001103
1915 010366 012601 4S:
1916 010370 000002 5S:

```

```

*****
; THIS ROUTINE WILL SELECT THE NEXT DRIVE TO TEST
T.SELDRV:
BIT #SW07,@SWR ;LOCK ON CURRENT DRIVE?
BNE 5S ;BR IF YES
MOV R1,-(SP) ;SAVE R1 ON THE STACK
MOV DRIVE,R1 ;GET THE DRIVE
MOVB (R1),@#CURDRV ;SAVE CURRENT DRIVE
CMPB (R1),#'A ;IS IT DRIVE "A"?
BEQ 1S ;BR IF YES
SIS #UNIT,@TACS ;SELECT DRIVE "B"
MOV #RW0B,@#RWDFLG ;SET REWIND POINTER TO "B"
BR 2S
BIC #UNIT,@TACS ;SELECT DRIVE "A"
MOV #RW0A,@#RWDFLG ;SET REWIND POINTER TO "A"
INC R1 ;INCREMENT TO THE NEXT DRIVE
TSTB (R1) ;OUT OF DRIVES TO TEST?
BNE 3S ;BR IF NO
MOV #DRVKEY,R1 ;RESET TO THE FIRST DRIVE
MOV R1,DRIVE ;SAVE FOR NEXT TIME
BIT #SW09,@SWR ;IS SWITCH 9=1?
BNE 4S ;BR IF YES
CLRB @#SERFLG ;CLEAR THE ERROR INDICATOR
MOV (SP)+,R1 ;RESTORE R1
RTI

```

H05

TAII MOTION TEST
DZTADC.NEW

MAINDEC-11-DZTAD-C
24-MAY-76 00:00

MACY11 27(1006) 23-SEP-76 10:33 PAGE 43
ROUTINE TO COMPARE THE READ AND WRITE BUFFERS

SEQ C059

```
1907 ::*****
1908 ::THIS ROUTINE WILL COMPARE THE READ AND WRITE BUFFERS
1909 †.BLKCMP:
1910 MOV (SP),R0 ;GET THE PC OF THE CALL
1911 MOV R0,@#SAVPC ;SAVE THE PC OF THE CALL
1912 MOV #MBUFCK,@#MFUNC ;POINTER FOR .ASCII MESSAGE
1913 MOV (R0)+,R3 ;PICKUP THE READ LINK ADDRESS
1914 MOV (R3)+,R1 ;PICKUP THE READ BUFFER ADDRESS
1915 MOV (R3),R3 ;PICKUP THE READ BUFFER SIZE
1916 MOV @ (R0)+,R2 ;PICKUP THE WRITE BUFFER ADDRESS
1917 CLR 2$+2 ;ZERO THE OFFSET
1918 MOV R0,(SP) ;SET THE RETURN
1919 CLR @#BYTNUM ;ZERO THE BYTE NUMBER
1920 BIT #SW03,@SWR ;COMPARE DATA BUFFERS?
1921 BEQ 1$ ;BR IF YES
1922 RTI ;NO---GO BACK
1923 1$: DEC R3 ;CHECK FOR THE TERMINATION
1924 BGE 4$ ;BR IF MORE BYTES TO COMPARE
1925 RTI ;RETURN
1926 4$: INC @#BYTNUM ;COUNT THIS BYTE
1927 2$: CMPB (R1)+,0(R2) ;COMPARE READ AND WRITE BLFFER
1928 BNE 3$ ;BR IF NOT EQUAL
1929 INC 2$+2 ;INCREMENT WRITE BUFFER INDEX
1930 BIC #1C3,2$+2 ;DON'T LET IT GET BIGGER THAN 3
1931 BR 1$
1932 3$: MOVB -(R1),@#SBDDAT ;GET THE RECEIVED BYTE
1933 ADD 2$+2,R2 ;FORM ADDRESS
1934 MOVB (R2),@#SGDDAT ;GET THE EXPECTED BYTE
1935 ERROR 10 ;RECEIVED AND EXPECTED DATA NOT EQUAL
1936 ::*****
1937 ::THIS ROUTINE WILL WRITE A FILE GAP ON THE TAPE
1938 †.WFG: MOV (SP),@#SAVPC ;SAVE THE PC OF THE CALL
1939 MOV #MXWFG,@#MFUNC ;SET MESSAGE POINTER FOR "WFG"
1940 1$: JSR R0,@#D0.CMD ;GO STAP A "WFG"
1941 XWFG!INT.EN!GO
1942 CLR @#PS ;ALLOW INTERRUPTS
1943 JSR R0,@#WAITFLAG ;GO WAIT FOR A FLAG
1944 ERROR 3 ;NO FLAGS OCCURRED
1945 ERROR 4 ;NO INTERRUPT
1946 JSR R0,@#FLAGS ;NORMAL RETURN---FIND OUT WHAT FLAG
1947 ERROR 2 ;RETURN HERE IF "XFER REQ" AND "READY" =0
1948 ERROR 2 ;RETURN HERE IF "XFER REQ" =1
1949 RTI ;"RETURN HERE IF "READY"=1 AND "ERROR" =0
1950 ERROR 2 ;"READY"=1 AND "ERROR"=1
```



```

1951
1952
1953 010564 011637 001204
1954 010570 012737 015363 007314
1955 010576 017602 000000
1956 010602 062716 000002
1957 010606 012201
1958 010610 005037 012232
1959 010614 005067 000066
1960 010620 012202
1961 010622 003001
1962 010624 104011
1963 010626 004037 012234 2$:
1964 010632 000103
1965 010634 005037 177776 3$:
1966 010640 004037 011726
1967 010644 104003
1968 010646 104004
1969 010650 005037 001254
1970 010654 012737 000340 177776
1971 010662 004037 012024
1972 010666 104002
1973 010670 000402
1974 010672 104005
1975 010674 104002
1976 010676 005302 4$:
1977 010700 002417
1978 010702 005000
1979 010704 156100 000000 6$:
1980 010710 110015
1981 010712 004737 012112
1982 010716 005267 177764
1983 010722 042767 177756 177756
1984 010730 012777 012350 170272
1985 010736 000736
1986 010740 013761 012232 000004 5$:
1987 010746 004037 012234
1988 010752 000122
1989 010754 005037 177776
1990 010760 004037 011726
1991 010764 104003
1992 010766 104004
1993 010770 004037 012024
1994 010774 104002
1995 010776 104002
1996 011000 000002
1997 011002 104002

```

```

*****
THIS ROUTINE WILL WRITE A RECORD ON THE TAPE
↑.WRIT: MOV (SP),@#SAVPC ;SAVE PC OF CALL
MOV #MXWRIT,@#MFUNC ; POINTER FOR .ASCIZ OF "WRITE"
MOV @ (SP),R2 ;GET THE WRITE LINK POINTER
ADD #2,(SP) ;ADJUST THE RETURN
MOV (R2)+,R1 ;GET FIRST ADDRESS OF WRITE BUFFER
CLR @#CRC.WD ;CLEAR THE CRC WORD
CLR 6$+2 ;ZERO THE INDEX
MOV (R2)+,R2 ;GET NUMBER OF BYTE TO WRITE
BGT 2$ ;CHECK FOR LEGAL NUMBER
ERROR 1 ;BAD NUMBER OF BYTES
JSR RO,@#DO.CMD ;GO START A "WRITE"
XWRITE!INT.EN!GO
CLR @#PS ;ALLOW INTERRUPTS
JSR RO,@#WAITFLAG ;WAIT FOR A FLAG
ERROR 3 ;NO FLAGS OCCURRED
ERROR 4 ;INTERRUPT FAILED
CLR @#WAITKEY ;CLEAR THE WAIT FOR INTERRUPT KEY
MOV #340,@#PS ;LOCK OUT THE WORLD
JSR RO,@#FLAGS ;WAIT FLAG OCCURRED?
ERROR 2 ;"READY"=0 & "XFER REQ" =0
BR 4$ ;"XFER REQ"=1
ERROR 5 ;"READY"=1 & "ERROR"=0
ERROR 2 ;"READY"=1 & "ERROR"=1
DEC R2 ;NEED TO WRITE A BYTE ON TAPE
BLT 5$ ;BR IF NO
CLR RO
BISB 0(R1),RO ;PICKUP BYTE FOR TRANSFER
MOVB RO,@TADB ;TRANSFER A BYTE TO THE TAIL
JSR PC,@#DO.CRC ;CALCULATE CRC FOR THIS BYTE
INC 6$+2 ;INCREASE THE INDEX
BIC #1C3,6$+2 ;KEEP IT LESS THAN 4
MOV #SERV,@TAVEC ;SETUP TO SERVICE THE INTERRUPT
BR 3$ ;LOOP
MOV @#CRC.WD,4(R1) ;SAVE THE CRC WORD
JSR RO,@#DO.CMD ;START A "ILBS"
XWRITE!INT.EN!ILBS
CLR @#PS ;ALLOW INTERRUPTS
JSR RO,@#WAITFLAG ;WAIT FOR A FLAG
ERROR 3 ;NO FLAG
ERROR 4 ;NO INTERRUPT
JSR RO,@#FLAGS ;WHAT FLAG IS SET?
ERROR 2 ;NONE ("XFER REQ"=0 & "READY"=0)
ERROR 2 ;"XFER REQ"
RTI ;"READY"
ERROR 2 ;"READY" & "ERROR"

```

```

1998
1999
2000 011004 011637 001204
2001 011010 012737 015371 007314
2002 011016 017602 000000
2003 011022 062716 000000
2004 011026 010200
2005 011030 016000 000034
2006 011034 016067 000004 170146
2007 011042 012201
2008 011044 012202
2009 011046 003001
2010 011050 104011
2011 011052 005037 012232 2$:
2012 011056 004037 012234
2013 011062 000105
2014 011064 005037 177776 3$:
2015 011070 105011
2016 011072 004037 011726
2017 011076 104003
2018 011100 104004
2019 011102 005037 001254
2020 011106 012737 000340 177776
2021 011114 004037 012024
2022 011120 104002
2023 011122 000402
2024 011124 104005
2025 011126 000413
2026 011130 005302 4$:
2027 011132 002431
2028 011134 005000
2029 011136 151500
2030 011140 110021
2031 011142 004737 012112
2032 011146 012777 012350 170054
2033 011154 000743
2034 011156 010237 001166 8$:
2035 011162 001414
2036 011164 013746 001172
2037 011170 005037 001172
2038 011174 016646 000004
2039 011200 016646 000004
2040 011204 104013
2041 011206 012637 001172
2042 011212 000002
2043 011214 104002 9$:
2044 011216 013737 012232 001212 5$:
2045 011224 004037 012234
2046 011230 000124
2047 011232 111537 001214
2048 011236 005037 177776
2049 011242 004037 011726
2050 011246 104003
2051 011250 104004
2052 011252 111567 167737
2053 011256 004037 012024

```

```

:*****
:THIS ROUTINE WILL READ A RECORD FROM THE TAPE
:READ: MOV (SP),@#SAVPC ;SAVE THE PC OF THE CALL
MOV @#MXREAD,@#MFUNC ;SET POINTER OF .ASCIZ MESSAGE
MOV @#(SP),R2 ;GET THE READ LINK POINTER
ADD #2,(SP) ;ADJUST FOR RETURN
MOV R2,R0 ;PICKUP AND SAVE THE "CRC" THAT
MOV WLNK1-RLNK1(R0),R0 ; WAS CALCULATED ON THE WRITE
MOV 4(R0),RCRC0 ; DATA FOR THIS BLOCK
MOV (R2)+,R1 ;GET ADDRESS OF BUFFER
MOV (R2)+,R2 ;GET NUMBER OF BYTES
BGT 2$ ;MAKE SURE NUMBER IS LEGAL
ERROR 11 ;ILLEGAL NUMBER OF BYTES
CLR @#CRC.WD ;CLEAR CRC WORD
JSR R0,@#DO.CMD ;GO START A "READ"
XREAD!INT.EN!GO
3$: CLR @#PS ;ALLOW INTERRUPTS
CLRB (R1) ;SET TERMINATOR IF LAST BYTE
JSR R0,@#WAITFLAG ;WAIT FOR A FLAG
ERROR 3 ;NONE OCCURRED
ERROR 4 ;NO INTERRUPT
CLR @#WAITKEY ;CLEAR THE WAIT ON INTERRUPT KEY
MOV #340,@#PS ;LOCK OUT ALL INTERRUPTS
JSR R0,@#FLAGS ;WHAT FLAG OCCURRED
ERROR 2 ;?UNKNOWN FLAG
BR 4$ ;"XFER REQ"
ERROR 5 ;"READY"
BR 8$ ;"READY" WITH "ERROR"
4$: DEC R2 ;READ A BYTE?
BLT 5$ ;BR IF NO
CLR R0
BISB @TADB,R0 ;READ ONE BYTE
MOVB R0,(R1)+ ;AND PUT IT IN THE BUFFER
JSR PC,@#DO.CRC ;CALCULATE CRC FOR THIS BYTE
MOV @#SERV,@TAVEC ;SETUP TO SERVICE THE INTERRUPT
BR 3$ ;LOOP
8$: MOV R2,@#STMP0 ;GET NUMBER OF BYTES NOT READ
BEQ 9$ ;SKIP OUT IF 0
MOV @#$ESCAPE,-(SP) ;SAVE THE ESCAPE ADDRESS
CLR @#$ESCAPE ;NO ESCAPE DESIRED
MOV 4(SP),-(SP) ;COPY THE STACK
MOV 4(SP),-(SP)
ERROR 13 ;BLOCK READ SHORT
MOV (SP)+,@#$ESCAPE ;RESTORE ESCAPE ADDRESS
RTI ;LEAVE
9$: ERROR 2 ;ERROR OCCURRED DURING READ
MOV @#CRC.WD,@#RCRC1 ;SAVE THE CALCULATED CRC
JSR R0,@#DO.CMD ;DO AN ILBS
XREAD!INT.EN!ILBS
MOV @TADB,@#RCRC2 ;SAVE 1ST BYTE OF CRC FROM TAIL
CLR @#PS ;ALLOW INTERRUPTS
JSR R0,@#WAITFLAG ;WAIT ON FLAG
ERROR 3 ;NONE OCCURRED
ERROR 4 ;INTERRUPT FAILED
MOVB @TADB,RCRC2+1 ;SAVE 2ND BYTE OF CRC FROM TAIL
JSR R0,@#FLAGS ;CHECK FLAGS

```


L05

TA11 MOTION TEST
DZTADC.NEW

24-MAY-76 00:00
MAINDEC-11-DZTAD-C

MACY:1 27(1006) 23-SEP-76 10:33 PAGE 47
ROUTINE TO "BACK-SPACE-FILE-GAP"

SEQ 0063

```

2065
2066
2067 011314 011637 001204
2068 011320 012737 015443 007314
2069 011326 004037 012234
2070 011332 000107
2071 011334 005037 177776
2072 011340 004037 011726
2073 011344 104003
2074 011346 104004
2075 011350 004037 012024
2076 011354 104002
2077 011356 104002
2078 011360 000401
2079 011362 104002
2080 011364 032714 004000
2081 011370 001401
2082 011372 000002
2083 011374 104006
2084
2085
2086
2087
2088 011376 011637 001204
2089 011402 012737 015467 007314
2090 011410 004037 012234
2091 011414 000111
2092 011416 005037 177776
2093 011422 004037 011726
2094 011426 104003
2095 011430 104004
2096 011432 004037 012024
2097 011436 104002
2098 011440 104002
2099 011442 000002
2100 011444 104002

;:*****
;:THIS ROUTINE WILL BACK SPACE ONE FILE GAP
↑.BSFG: MOV (SP),@#SAVPC ;SAVE PC OF CALL
MOV #MXBSFG,@#MFUNC ;SAVE POINTER OF .ASCIZ NAME
1$: JSR RO,@#DO.CMD ;START A "BSFG"
XBSFG!INT. EN!GO
CLR @#PS ;ALLOW INTERRUPTS
JSR RO,@#WAITFLAG ;WAIT ON FLAG
ERROR 3 ;NO FLAG
ERROR 4 ;FLAG DIDN'T INTERRUPT
JSR RO,@#FLAGS ;FIND OUT WHAT FLAG OCCURRED
ERROR 2 ;UNKNOWN
ERROR 2 ;"XFER REQ"
BR 2$ ;"READY"
ERROR 2 ;"READY" & "ERROR"
2$: BIT #FGAP,@TACS ;IN A FILE GAP?
BEQ 3$ ;BR IN NO
RTI ;GO BACK
3$: ERROR 6 ;"BSFG" DIDN'T STOP IN A FILE GAP

;:*****
;:THIS ROUTINE WILL BACK SPACE ONE BLOCK GAP
↑.BSBG: MOV (SP),@#SAVPC ;SAVE THE PC OF THE CALL
MOV #MXBSBG,@#MFUNC ;MESSAGE POINTER
1$: JSR RO,@#DO.CMD ;START A "BSBG"
XBSBG!INT. EN!GO
CLR @#PS ;ALLOW INTERRUPTS
JSR RO,@#WAITFLAG ;WAIT FOR A FLAG
ERROR 3 ;NO FLAG OCCURRED
ERROR 4 ;FLAG DIDN'T INTERRUPT
JSR RO,@#FLAGS ;WHAT FLAG OCCURRED
ERROR 2 ;UNKNOWN
ERROR 2 ;"XFER REQ"
RTI ;"READY"-- GO BACK TO USER
ERROR 2 ;"READY" & "ERROR"

```

M05

TA11 MOTION TEST
DZTADC.NEW

24-MAY-76 00:00
MAINDEC-11-DZTAD-C

MACY11 27(1006) 23-SEP-76 10:33 PAGE 48
ROUTINE TO "SPACE-FORWARD-FILE-GAP"

SEQ 0064

```

2101      ;:*****
2102      ; THIS ROUTINE WILL SPACE FORWARD FOR ONE FILE GAP
2103      T.SFFG: MOV      (SP),A#SAVPC      ;SAVE PC OF CALL
2104      MOV      #MXSFFG,A#MFUNC      ; POINTER TO .ASCIZ MESSAGE
2105      JSR      RO,A#DO.CMD      ; START A "SFFG"
2106      XSFFG: INT. EN!GO
2107      CLR      A#PS      ; ALLOW INTERRUPTS
2108      JSR      RO,A#WAITFLAG      ; WAIT FOR A FLAG
2109      ERROR    3      ; FLAG FAILED TO OCCUR
2110      ERROR    4      ; FLAG DIDN'T INTERRUPT
2111      JSR      RO,A#FLAGS      ; WHAT FLAG OCCURRED
2112      ERROR    2      ; UNKNOWN
2113      ERROR    2      ; "XFER REQ"
2114      BR      2$      ; "READY"
2115      ERROR    2      ; "READY" AND "ERROR"
2116      2$: BIT      #FGAP,A#TACS      ; DID "SFFG" STOP IN A "FILE GAP"?
2117      BEQ      3$      ; BR IF NO
2118      RTI      ; RETURN TO CALLER
2119      3$: ERROR    6      ; "SFFG" DIDN'T STOP IN A FILE GAP
2120
2121      ;:*****
2122      ; THIS ROUTINE WILL SPACE FORWARD ONE BLOCK GAP
2123      T.SFBG: MOV      (SP),A#SAVPC      ;SAVE PC OF CALL
2124      MOV      #MXSFBG,A#MFUNC      ; POINTER TO .ASCIZ MESSAGE
2125      JSR      RO,A#DO.CMD      ; START A "SFBG"
2126      XSFBG: INT. EN!GO
2127      CLR      A#PS      ; ALLOW INTERRUPTS
2128      JSR      RO,A#WAITFLAG      ; WAIT FOR A FLAG
2129      ERROR    3      ; NO FLAG
2130      ERROR    4      ; NO INTERRUPT
2131      JSR      RO,A#FLAGS      ; FIND OUT WHAT FLAG
2132      ERROR    2      ; UNKNOWN
2133      ERROR    2      ; "XFER REQ"
2134      RTI      ; "READY"
2135      TST      A#ASKKEY      ; RUNNING UNDER MANUAL LOOPING?
2136      BGE      2$      ; BR IF NO
2137      RTI      ; RETURN
2138      2$: ERROR    2      ; "READY" AND "ERROR"
2139

```

```

2140
2141
2142 011610 011637 001204
2143 011614 012737 015354 007314
2144 011622 004037 012024
2145 011626 104001
2146 011630 104001
2147 011632 000411
2148 011634 005777 167416
2149 011640 001406
2150 011642 032714 020000
2151 011646 001403
2152 011650 005077 167402
2153 011654 104001
2154 011656 004037 012234
2155 011662 000117
2156 011664 005037 177776
2157 011670 004037 011726
2158 011674 104003
2159 011676 104004
2160 011700 004037 012024
2161 011704 104002
2162 011706 104002
2163 011710 000401
2164 011712 104002
2165 011714 032714 020000
2166 011720 001401
2167 011722 000002
2168 011724 104007

```

```

:*****
:THIS ROUTINE WILL REWIND THE TAPE
↑.RWND: MOV (SP),@#SAVPC ;SAVE PC OF CALL
MOV #MXRWND,@#MFUNC ;POINTER TO .ASCIZ MESSAGE
JSR RO,@#FLAGS ;CHECK THE FLAGS
ERROR 1 ;NO FLAGS
ERROR 1 ;"XFER REQ"
BR 1$ ;NORMAL RETURN
TST @RWDFLG ;WAS LAST FUNCTION A REWIND?
BEQ 1$ ;BR IF YES
BIT #LEADER,@TACS ;ON CLEAR LEADER?
BEQ 1$ ;BR IF NO
CLR @RWDFLG ;ALLOW THIS ERROR ONLY ONE TIME
ERROR 1 ;ON CLEAR LEADER BUT SHOULDN'T BE
JSR RO,@#DO.CMD ;GO START A "REWIND"
XRWND:INT.EN!GO
CLR @#PS ;ALLOW INTERRUPTS
JSR RO,@#WAITFLAG ;WAIT ON FLAG
ERROR 3 ;NO FLAG OCCURRED
ERROR 4 ;NO INTERRUPT
JSR RO,@#FLAGS ;WHAT FLAG OCCURRED
ERROR 2 ;UNKNOWN
ERROR 2 ;"XFER REQ"
BR 2$ ;"READY"
ERROR 2 ;"READY" & "ERROR"
BIT #LEADER,@TACS ;ON "CLEAR LEADER"?
BEQ 3$ ;BR IF NO
RTI ;YES---RETURN
ERROR 7 ;"REWIND" FAILED TO GO TO "CLEAR LEADER"

```

THIS ROUTINE IS USED TO WAIT ON A FLAG

CALL:

JSR RO, @WAITFLAG
RETURN FOR NO FLAGS
RETURN FOR NO INTERRUPT
NORMAL RETURN

WAITFLAG:

CLR LOCNT ; ZERO THE LOW COUNTER
MOV MAXCNT, HICNT ; SET THE HIGH COUNTER TO MAX. COUNT
BIT @SWOS, @SWR ; RUNNING WITH INTERRUPTS?
BNE @S ; BR IF YES
MOV @-1, WAITKEY ; SET THE INTERRUPT OCCURRED FLAG
BIT @TR:REQ:READY, @TACS ; TEST FOR FLAGS
BNE @S ; BR IF A FLAG IS UP
INC LOCNT ; COUNT THE LOW COUNTER
BNE @S ; LOOP IF NOT ZERO
DEC HICNT ; COUNT THE HIGH COUNTER
BPL @S ; LOOP IF NOT NEG.
BR @S ; LEAVE
TST (RO)+ ; INCREMENT THE RETURN ADDRESS
TST WAITKEY ; LOOK AT THE WAIT ON INT. KEY
BNE @S ; BR IF NOT SET
TST (RO)+ ; INCREMENT THE RETURN ADDRESS
RO ; RETURN TO USER

LOCNT: 0
HICNT: 0
MAXCNT: 0

011172E 005067 000064
0111730 016767 000064 000060
0111740 032777 000040 167172
0111746 001403
0111750 012767 177777 167276
0111756 032714 000240
0111762 001007
0111764 005267 000026
0111770 001372
0111772 005367 000022
0111776 100367
012000 000405
012002 005720
012004 005767 167244
012010 001401
012012 005720
012014 000200
012016 000000
012020 000000
012022 000000

000000
000001
000002
000003
000004
000005
000006
000007
000008
000009
000010
000011
000012
000013
000014
000015
000016
000017
000018
000019
000020
000021
000022
000023
000024
000025
000026
000027
000028
000029
000030
000031
000032
000033
000034
000035
000036
000037
000038
000039
000040
000041
000042
000043
000044
000045
000046
000047
000048
000049
000050
000051
000052
000053
000054
000055
000056
000057
000058
000059
000060
000061
000062
000063
000064
000065
000066
000067
000068
000069
000070
000071
000072

012112
012112
012114
012116
012120
012122
012124
012132
012136
012140
012142
012146
012150
012152
012154
012156
012160
012162
012164
012166
012172
012174
012176
012200
012202
012204
012206
012210
012212
012216
012220
012222
012224
012226
012230
012232

000010 000054
000074
177776
040002
000014

```
*****  
: THIS ROUTINE WILL CALCULATE THE CRC  
: CALL:  
: JSR PC, @DO.CRC ;RO=1 BYTE OF DATA  
DO.CRC:  
: MOV R0, -(SP) ;: PUSH R0 ON STACK  
: MOV R1, -(SP) ;: PUSH R1 ON STACK  
: MOV R2, -(SP) ;: PUSH R2 ON STACK  
: MOV R3, -(SP) ;: PUSH R3 ON STACK  
: MOV R4, -(SP) ;: PUSH R4 ON STACK  
: MOV #8, R3 ;: MAKE EIGHT ITERATIONS  
: MOV CRC.WD, R3 ;: PICKUP THE CRC WORD  
1$: CLR R1 ;: GET THE PARTIAL CRC WORD  
: MOV R3, R2 ;: STRIP AWAY EVERYTHING BUT BIT00  
: BIC #1, BIT00, R2 ;: PULL OFF THIS BIT  
: ROR R0 ;: AND SETUP TO XOR IT  
: ROL R1 ;: FORM THE XOR OF "R1" AND "R2"  
: MOV R1, R4  
: BIC R2, R4  
: BIC R1, R2  
: BIS R4, R2 ;: RESULTS TO "R2"  
: ROR R2  
: BCC #8, R3  
: MOV #BIT14!BIT01, R1 ;: FORM THE XOR OF "R1" AND "R3"  
: MOV R1, R4  
: BIC R3, R4  
: BIC R1, R3  
: BIS R4, R3 ;: RESULTS TO "R3"  
: ROR R3  
2$: DEC (PC)+  
3$: O ;: BR IF MORE BITS TO DO  
: BGT 1$,  
: MOV R3, CRC.WD ;: POP STACK INTO R4  
: MOV (SP)+, R4 ;: POP STACK INTO R3  
: MOV (SP)+, R3 ;: POP STACK INTO R2  
: MOV (SP)+, R2 ;: POP STACK INTO R1  
: MOV (SP)+, R1 ;: POP STACK INTO R0  
: MOV (SP)+, R0  
RTS  
PC  
CRC.WD: C ;: CRC WORD
```

E06

TAIL MOTION TEST
DZTACC.NEW

24-MAY-76
CO:00

MACY11 27(1006) 23-SEP-76 10:33 PAGE 53
ROUTINE TO PERFORM THE REQUESTED FUNCTION

SEQ 0069

227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316

012234 010146
012236 012737 000340 177776
012244 012001
012246 042701 177640
012252 032777 000040 166660
012260 001405
012262 042701 000100
012266 012777 012366 166734
012274 005067 166754
012300 032701 000100
012304 001403
012306 012777 012350 166714
012314 110114
012316 032701 000001
012322 001403
012324 032714 000040
012330 001375
012332 005101
012334 042701 177761
012340 010177 166712
012344 012601
012346 000200

: THIS ROUTINE WILL LOAD THE LOW BYTE OF TACS WITH THE DESIRED FUNCTION

CALL:

JSR RO, @DO.CMD
DESIRED FUNCTIN
RETURN

DO.CMD: MOV R1, -(SP) ;SAVE R1
MOV #340, @#PS ;LOCK OUT ALL INERRUPTS
MOV (RO)+, R1 ;GET THE COMMAND
BIC #1<INT.EN!ILBS!FUNCTION!GO>, R1 ;STRIP AWAY JUNK
BIT #SMOS, @SWR ;WITH OR WITHOUT INTERRUPTS
BEQ 4\$;BR IF WITH
BIC #INT.EN, R1 ;CLEAR INTERRUPT ENABLE IF SET
MOV #BADINT, @TAVEC ;SETUP TO CATCH BAD INTERRUPT
4\$: CLR WAITKEY ;ZERO THE WAIT ON INTERRUPT KEY
BIT #INT.EN, R1 ;RUNNING WITH INTERRUPTS?
BEQ 3\$;BR IF NO
MOV #SERV, @TAVEC ;SETUP TO SERVICE THE INTERRUPT
3\$: MOVB R1, @TACS ;LOAD THE COMMAND
BIT #GO, R1 ;IS GO BIT ON A "1"?
BEQ 2\$;BR IF GO =0
1\$: BIT #READY, @TACS ;WAIT FOR "READY" TO CLEAR
BNE 1\$
2\$: COM R1 ;SET OR CLEAR REWIND FLAG
BIC #1<FUNCTION>, R1 ;EXTRACT FUNCTION BITS
MOV R1, @RWDFLG ;AND SAVE AS THE REWIND FLAG
MOV (SP)+, R1 ;GET R1 BACK
RTS RO ;RETURN TO USER

: THIS ROUTINE WILL SERVICE ALL LEGAL INTERRUPTS

SERV: MOV #-1, @WAITKEY ;SET THE WAIT KEY
MOV #BADINT, @TAVEC ;SET TO CATCH ILLEGAL INTERRUPTS
RTI

: THIS ROUTINE WILL CATCH ILLEGAL INTERRUPTS FROM THE TAIL

BADINT: MOV (SP), @SAVPC ;SAVE WHERE WE WERE AT
ERROR 14 ;ILLEGAL INTERRUPT OCCURRED

F06

TA11 MOTION TEST
DZTADC.NEW

MAINDEC-11-DZTAD-C
24-MAY-76 00:00

MACY11 27(1005) 23-SEP-76 10:33 PAGE 54

***** MANUAL ADJUSTMENT ROUTINES *****

SEQ 0070

2317
2318
2319
2320

:*****
:*****
:THE FOLLOWING ROUTINES CAN BE USED TO MAKE ADJUSTMENTS TO THE TUBC
:NOTE: *** BEFORE USING ANY OF THE ROUTINES LOAD AND START AT 214 ***

2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361

: ** NOTE: IF USING SOFTWARE SWITCH REGISTER THE
: PROGRAM MUST HAVE BEEN STARTED AT A
: NORMAL STARTING ADDRESS FIRST SO THAT
: THE AUTO-SIZING ROUTINE CAN SET UP ADDRESS
: 176 AS THE SOFTWARE SWITCH REGISTER
: PLACE VALUE INTO 176
: *****

: WRITE FILE GAPS FROM "BOT" TO "EOT"
: START AT 220
: THIS ROUTINE CAN BE USED TO ADJUST THE "WRITE GAP MONO" AND
: THE "WRITE DELAY MONO".
: *****

012374 012706 001100
012400 013704 001220
012404 013705 001224
012410 000005
012412 012737 012374 001110
012420 104422
012422 112714 000017
012426 032714 000040
012432 001775
012434 104412
012436 032714 020000
012442 001774
012444 000000
012446 000752

WFGSUB: MOV #STACK, SP ;KEEP THE STACK OUT OF THE WAY
MOV @TACSL, TACS ;SETUP THE TAI1 STATUS AND
MOV @TADBL, TADB ;DATA BUFFER REGISTERS
RESET ;RESET THE WORLD
MOV #WFGSUB, @SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
SELDRV ;SELECT THE DRIVE
100\$: MOVB #XRWD!GO, @TACS ;SEND TAPE TO "BOT"
BIT #READY, @TACS ;WAIT ON READY
BEQ 100\$
1\$: WFG ;WRITE A FILE GAP
BIT #LEADER, @TACS ;AT "CLEAR LEADER"?
BEQ 1\$;BR IF NO
HALT ;STOP IF YES
BR WFGSUB ;LOOP ON CONT.

: WRITE CONTINUOUS BLOCKS OF DATA
: START AT 224
: THE PROGRAM WILL HALT THREE(3) TIMES
: AFTER EACH HALT SET THE SWR AND PRESS CONTINUE
: HALT 1 --- SWR<7:0> = NUMBER OF BYTES PER BLOCK
: HALT 2 --- SWR<7:0> = PATTERN DESIRED
: HALT 3 --- SWR<15:0> = OPERATIONAL SWITCH SETTINGS
: THIS ROUTINE CAN BE USED TO ADJUST THE "GAP TIME MONO"

H06

TAII MOTION TEST
DZTADC.NEW

MAINDEC-11-DZTAD-C
24-MAY-76 00:00

MACY11 27(1006) 23-SEP-76 10:33 PAGE 56
WRITE CONTINUOUS BLOCKS OF DATA

SEQ 0072

```
2362 ; THIS ROUTINE SUPPORTS THE S/W SWITCH REG FUNCTIONS
2363 ;*****
2364 012450 004737 013116 WRTSUB: JSR PC, @#SETBUF ; GET BLOCK SIZE AND PATTERN
2365 012454 012706 001100 WLOOP: MOV #STACK, SP ; KEEP THE STACK OUT OF THE WAY
2366 012460 013704 001220 MOV @#TACSL, TACS ; SETUP THE TAIL STATUS AND
2367 012464 013705 001224 MOV @#TADBL, TADB ; DATA BUFFER REGISTERS
2368 012470 000005 RESET ; RESET THE WORLD
2369 012472 012737 012454 001110 MOV #WLOOP, @#SLPERR ; SETUP THE LOOP ON ERROR ADDRESS
2370 012500 104422 SELDRV ; SELECT THE DRIVE
2371 012502 112714 000017 MOVB #XRWND!GO, @TACS ; SEND TAPE TO "BOT"
2372 012506 032714 000040 100$: BIT #READY, @TACS ; WAIT ON READY
2373 012512 001775 BEQ 100$
2374 012514 104413 017052 1$: WRITE ,WLNKX ; WRITE A BLOCK
2375 012520 032714 020000 BIT #LEADER, @TACS ; AT "CLEAR LEADER"?
2376 012524 001773 BEQ 1$ ; BR IF NO
2377 012526 000000 HALT ; STOP IF "EOT"
2378 012530 000751 BR WLOOP ; LOOP IF CONT.
2379
2380
2381 ;*****
2382 ; READ AND COMPARE CONTINUOUS BLOCKS OF DATA
2383 ; START AT 230
2384 ; THIS ROUTINE CAN BE USED TO ADJUST THE "SIGNAL MONO"
2385 ; AND THE "THRESHOLD POT".
2386 ;*****
2387 012532 012706 001100 RDSUB: MOV #STACK, SP ; KEEP THE STACK OUT OF THE WAY
2388 012536 013704 001220 MOV @#TACSL, TACS ; SETUP THE TAIL STATUS AND
2389 012542 013705 001224 MOV @#TADBL, TADB ; DATA BUFFER REGISTERS
2390 012546 000005 RESET ; RESET THE WORLD
2391 012550 012737 012532 001110 MOV #RDSUB, @#SLPERR ; SETUP THE LOOP ON ERROR ADDRESS
2392 012556 104422 SELDRV ; SELECT THE DRIVE
2393 012560 112714 000017 MOVB #XRWND!GO, @TACS ; SEND TAPE TO "BOT"
2394 012564 032714 000040 100$: BIT #READY, @TACS ; WAIT ON READY
2395 012570 001775 BEQ 100$
2396 012572 104414 017016 1$: READ ,RLNKX ; READ A BLOCK
2397 012576 012706 001100 MOV #STACK, SP ; INIT. IN CASE OF ERROR
2398 012602 032714 020000 BIT #LEADER, @TACS ; AT "CLEAR LEADER"?
2399 012606 001351 BNE RDSUB ; BR IF YES---LOOP
2400 012610 104423 BLKCMP ; COMPARE THE READ AND WRITE BUFFERS
2401 012612 017016 RLNKX ; LINK TO THE READ BUFFER
2402 012614 017052 WLNKX ; LINK TO THE WRITE BUFFER
2403 012616 000765 BR 1$
2404
2405
2406 ;*****
2407 ; WRITE A FILE GAP AND A BLOCK OF DATA FROM BOT TO EOT
2408 ; START AT 234
2409 ; THE PROGRAM WILL HALT THREE(3) TIMES
2410 ; AFTER EACH HALT SET THE SWR AND PRESS CONTINUE
2411 ; HALT 1 --- SWR<7:0> = NUMBER OF BYTES PER BLOCK
2412 ; HALT 2 --- SWR<7:0> = PATTERN DESIRED
2413 ; HALT 3 --- SWR<15:0> = OPERATIONAL SWITCH SETTINGS
2414 ; THIS ROUTINE CAN BE USED TO ADJUST THE "WRITE GAP MONO"
2415 ; AND THE "GAP TIME MONO".
```

```

2416
2417
2418 012620 004737 013116
2419 012624 012706 001100
2420 012630 013704 001220
2421 012634 013705 001224
2422 012640 000005
2423 012642 012737 012624 001110
2424 012650 104422
2425 012652 112714 000017
2426 012656 032714 000040
2427 012652 001775
2428 012654 104412
2429 012666 032714 020000
2430 012672 001005
2431 012674 104413 017052
2432 012700 032714 020000
2433 012704 001767
2434 012706 000000
2435 012710 000745
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445 012712 012706 001100
2446 012716 013704 001220
2447 012722 013705 001224
2448 012726 000005
2449 012730 012737 012712 001110
2450 012736 104422
2451 012740 112714 000017
2452 012744 032714 000040
2453 012750 001775
2454 012752 104414 017016
2455 012756 012706 001100
2456 012762 032714 020000
2457 012766 001351
2458 012770 104423
2459 012772 017016
2460 012774 017052
2461 012776 104420
2462 013000 032714 020000
2463 013004 001342
2464 013006 000761
2465
2466
2467
2468
2469
2470
2471

```

```

; THIS ROUTINE SUPPORTS THE S/W SWITCH REG FUNCTIONS
;*****
WGPBLK: JSR PC,@SETBUF ;GET BLOCK SIZE AND PATTERN
WGBLOP: MOV #STACK,SP ;KEEP THE STACK OUT OF THE WAY
MOV @TACSL,TACS ;SETUP THE TAIL STATUS AND
MOV @TADBL,TADB ;DATA BUFFER REGISTERS
RESET ;RESET THE WORLD
MOV #WGBLOP,@$SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
SELDRV ;SELECT THE DRIVE
MOVB #XRWNO!GO,@TACS ;SEND TAPE TO "BOT"
100$: BIT #READY,@TACS ;WAIT ON READY
BEQ 100$
1$: WFG ;WRITE A FILE GAP
BIT #LEADER,@TACS ;AT "CLEAR LEADER"?
BNE 2$ ;BR IF YES
WRITE ,WLNKX ;WRITE A BLOCK
BIT #LEADER,@TACS ;AT "CLEAR LEADER"?
BEQ 1$ ;BR IF NO
2$: HALT ;STOP AT "EOT"
BR WGBLOP ;START OVER ON CONT.

;*****
; READ AND COMPARE A BLOCK OF DATA AND A FILE GAP
; START AT 240
; THIS ROUTINE IS USED AFTER "WRITE A BLOCK AND A FILE GAP" ROUTINE
; IT CAN BE USED TO ADJUST THE "SIGNAL MONO", THE THRESHOLD POT"
; AND THE "TAPE BLANK MONO".
;*****
RGPBLK: MOV #STACK,SP ;KEEP THE STACK OUT OF THE WAY
MOV @TACSL,TACS ;SETUP THE TAIL STATUS AND
MOV @TADBL,TADB ;DATA BUFFER REGISTERS
RESET ;RESET THE WORLD
MOV #RGPBLK,@$SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
SELDRV ;SELECT THE DRIVE
MOVB #XRWNO!GO,@TACS ;SEND TAPE TO "BOT"
100$: BIT #READY,@TACS ;WAIT ON READY
BEQ 100$
1$: READ ,RLNKX ;READ A BLOCK OF DATA
MOV #STACK,SP ;KEEP OUT OF THE WAY
BIT #LEADER,@TACS ;AT "CLEAR LEADER"?
BNE RGPBLK ;BR IF YES
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNKX ;LINK TO THE READ BUFFER
WLNKX ;LINK TO THE WRITE BUFFER
SFBG ;GET INTO FILE GAP
BIT #LEADER,@TACS ;AT "CLEAR LEADER"?
BNE RGPBLK ;BR IF YES
BR 1$ ;LOOP

;*****
; SPACE FORWARD FILE GAP FROM "BOT" TO "EOT"
; START AT 244
; THIS ROUTINE CAN BE USED AFTER "WRITE FILE GAP" FOR LOW SPEED
; SPACE FOWARD (TAPE BLANK MONO CAN BE ADJUSTED), OR AFTER READ JR

```

J06

TAIL MOTION TEST
DZTADC.NEW

24-MAY-76 00:00

MAINDEC-11-DZTAD-C

MACY11 27(1006) 23-SEP-76 10:33 PAGE 58
SPACE FORWARD FILE GAP FROM "BOT" TO "EOT"

SEQ 0074

```

2472                                     ;WRITE A FILE GAP AND A BLOCK OF DATA FOR HIGH SPEED SPACE FORWARD
2473                                     ;(SIGNAL MONO CAN BE CHECKED).
2474                                     ;*****
2475 013010 012706 001100 $FFGSB: MOV #STACK,SP ;KEEP THE STACK OUT OF THE WAY
2476 013014 013704 001220 MOV @#TACSL,TACS ;SETUP THE TAIL STATUS AND
2477 013020 013705 001224 MOV @#TADBL,TADB ;DATA BUFFER REGISTERS
2478 013024 000005 RESET ;RESET THE WORLD
2479 013026 012737 013010 001110 MOV #SFFGSB,@#$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
2480 013034 104422 SELDRV ;SELECT THE DRIVE
2481 013036 112714 000017 MOVB #XRWND!GO,@TACS ;SEND TAPE TO "BOT"
2482 013042 032714 000040 100$: BIT #READY,@TACS ;WAIT ON READY
2483 013046 001775 BEQ 100$
2484 013050 104417 1$: SFFG ;SPACE INTO A FILE GAP
2485 013052 032714 020000 BIT #LEADER,@TACS ;AT "CLEAR LEADER"?
2486 013056 001774 BEQ 1$ ;BF IF NO
2487 013060 000000 HALT ;STOP AT "EOT"
2488 013062 000752 BR SFFGSB ;LOOP ON CONT.
2489
2490
2491 ;*****
2492 ; BACK SPACE FILE GAP
2493 ; START AT 250
2494 ; THIS ROUTINE CAN BE USED TO ADJUST OR CHECK THE "SIGNAL MONO".
2495 ;*****
2496 013064 000005 BSFGSB: RESET ;RESET THE WORLD
2497 013066 012737 013064 001110 MOV #BSFGSB,@#$LPERR ;LOOP ON ERROR ADDRESS
2498 013074 005067 166072 CLR $ESCAPE ;DON'T ESCAPE ON ERROR
2499 013100 104422 SELDRV ;SELECT THE DRIVE
2500 013102 104415 1$: BSFG ;BACK SPACE A FILE GAP
2501 013104 032714 020000 BIT #LEADER,@TACS ;AT "CLEAR LEADER"?
2502 013110 001774 BEQ 1$ ;BR IF NO
2503 013112 000000 HALT ;STOP AT BOT
2504 013114 000753 BR BSFGSB ;START OVER ON CONT.
2505
2506
2507 ;*****
2508 ; SETUP READ AND WRITE LINKS FOR SUBROUTINES
2509 013116 005000 SETBUF: CLR RO
2510 013120 000000 HALT ;OPERATOR PUTS BYTE COUNT IN THE SWR

```

K06

TA11 MOTION TEST MAINDEC-11-DZTAD-C
 DZTADC.NEW 24-MAY-76 00:00

MACY11 27(1006) 23-SEP-76 10:33 PAGE 59
 SETUP READ AND WRITE LINKS FOR SUBROUTINES

SEQ 0075

2511	013122	022767	000176	166010		CMP	#SWREG,SWR	; USING S/W SWITCH REG?
2512	013130	001001				BNE	20\$; NO- GET OUT
2513	013132	104405				GTSWR		; GET VALUE
2514	013134				20\$:			; CONTINUE
2515	013134	157700	166000			BISB	2SWR,RO	; PICKUP THE BYTE COUNT
2516	013140	001006				BNE	2\$; BR IF NON-ZERO
2517	013142	105777	165773			TSTB	7SWR+1	; CHECK IF GREATER THAN 377
2518	013146	001402				BEQ	1\$; BR IF NO
2519	013150	012700	000376			MOV	#376,RO	; SET FOR MAX ALLOWED
2520	013154	005200			1\$:	INC	RO	; MAKE IT 377 OR 1
2521	013156	010037	017020		2\$:	MOV	RO,2#RLNKX+2	; SETUP READ LINK
2522	013152	010037	017054			MOV	RO,2#WLNKX+2	; SETUP WRITE LINK
2523	013166	000000				HALT		; SET PATTERN INTO THE SWR

M06

TAI1 MOTION TEST
DZTADC.NEW 24-MAY-76 00:00

MACY11 27(1006) 23-SEP-76 10:33 PAGE 61
SETUP READ AND WRITE LINKS FOR SUBROUTINES

SEQ 0077

2535 013224 022767 000176 165706
2536 013232 001001
2537 013234 104405
2538 013236 22\$:
2539 013236 000207

CMP #SWREG,SWR
BNE 22\$
GT SWR
RTS PC

; USING S/W SWITCH REG?
; NO- GET OUT
; GET VALUE
; CONTINUE
; RETURN

2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584
2585
2586
2587
2588
2589
2590
2591
2592
2593
2594
2595

.SBTTL TYPE ROUTINE

*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: \$NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: \$FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: \$FILLC CONTAINS THE CHARACTER TO FILL AFTER.

*CALL:
*1) USING A TRAP INSTRUCTION
* TYPE ,MESADR ;:MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
* TYPE
* MESADR
*

013240	105767	165713	\$TYPE:	TSTB	\$TFPLG	:: IS THERE A TERMINAL?
013244	100002			BPL	1\$:: BR IF YES
013246	000000			HALT		:: HALT HERE IF NO TERMINAL
013250	000407			BR	3\$:: LEAVE
013252	010046		1\$:	MOV	RO, -(SP)	:: SAVE RO
013254	017600	000002		MOV	22(SP), RO	:: GET ADDRESS OF ASCIZ STRING
013260	112046		2\$:	MOVB	(RO)+, -(SP)	:: PUSH CHARACTER TO BE TYPED ONTO STACK
013262	001005			BNE	4\$:: BR IF IT ISN'T THE TERMINATOR
013264	005726			TST	(SP)+	:: IF TERMINATOR POP IT OFF THE STACK
013266	012600		60\$:	MOV	(SP)+, RO	:: RESTORE RO
013270	062716	000002	20\$:	ADD	#2, (SP)	:: ADJUST RETURN PC
013274	000002			RTI		:: RETURN
013276	122716	000011	4\$:	CMPB	#HT, (SP)	:: BRANCH IF <HT>
013302	001430			BEQ	8\$	
013304	122716	000200		CMPB	#CRLF, (SP)	:: BRANCH IF NOT <CRLF>
013310	001006			BNE	5\$	
013312	005726			TST	(SP)+	:: POP <CR><LF> EQUIV
013314	104401			TYPE		:: TYPE A CR AND LF
013316	001201			\$CRLF		
013320	105067	000130		CLRB	\$CHARCNT	:: CLEAR CHARACTER COUNT
013324	000755			BR	2\$:: GET NEXT CHARACTER
013326	004767	000056	5\$:	JSR	PC, \$TYPEC	:: GO TYPE THIS CHARACTER
013332	126726	165620	6\$:	CMPB	\$FILLC, (SP)+	:: IS IT TIME FOR FILLER CHARS.?
013336	001350			BNE	2\$:: IF NO GO GET NEXT CHAR.
013340	016746	165610		MOV	\$NULL, -(SP)	:: GET # OF FILLER CHARS. NEEDED
						:: AND THE NULL CHAR.
013344	105366	000001	7\$:	DECB	1(SP)	:: DOES A NULL NEED TO BE TYPED?
013350	002770			BLT	6\$:: BR IF NO--GO POP THE NULL OFF OF STACK
013352	004767	000032		JSR	PC, \$TYPEC	:: GO TYPE A NULL
013356	105367	000072		DECB	\$CHARCNT	:: DO NOT COUNT AS A COUNT
013362	000770			BR	7\$:: LOOP

;HORIZONTAL TAB PROCESSOR

013364	112716	000040	8\$:	MOVB	#' (SP)	:: REPLACE TAB WITH SPACE
013370	004767	000014	9\$:	JSR	PC, \$TYPEC	:: TYPE A SPACE
013374	132767	000007		BITB	#7, \$CHARCNT	:: BRANCH IF NOT AT
013402	001372			BNE	9\$:: TAB STOP
013404	005726			TST	(SP)+	:: POP SPACE OFF STACK

02650	013610	021627	000015	10\$:	CMP	(SP),#15	:: IS IT A <CR>?
02651	013614	001022			BNE	16\$:: BRANCH IF NO
02652	013616	005766	000004		TST	4(SP)	:: YES, IS IT THE FIRST CHAR?
02653	013622	001403			BEQ	11\$:: BRANCH IF YES
02654	013624	016677	000002	165306	MOV	2(SP),2SWR	:: SAVE NEW SWR
02655	013632	062705	000006	11\$:	ADD	#6,SP	:: CLEAR UP STACK
02656	013636	104401	001201	14\$:	TYPE	\$CRLF	:: ECHO <CR> AND <LF>
02657	013642	126727	165267	000001	CMPB	\$INTAG,#1	:: RE-ENABLE TTY KBD INTERRUPTS?
02658	013650	001003			BNE	15\$:: BRANCH IF NOT
02659	013652	012777	000100	165264	MOV	#100,2\$TKS	:: RE-ENABLE TTY KBD INTERRUPTS
02660	013650	000902		15\$:	RTI		:: RETURN
02661	013652	004767	177522	16\$:	JSR	PC,\$TYPEC	:: ECHO CHAR
02662	013666	021527	000060		CMP	(SP),#60	:: CHAR < 0?
02663	013672	002420			BLT	18\$:: BRANCH IF YES
02664	013674	021627	000067		CMP	(SP),#67	:: CHAR > 7?
02665	013700	003015			BGT	18\$:: BRANCH IF YES
02666	013702	042726	000060		BIC	#60,(SP)+	:: STRIP-OFF ASCII
02667	013706	005766	000002		TST	2(SP)	:: IS THIS THE FIRST CHAR
02668	013712	001403			BEQ	17\$:: BRANCH IF YES
02669	013714	006316			ASL	(SP)	:: NO, SHIFT PRESENT
02670	013716	006316			ASL	(SP)	:: CHAR OVER TO MAKE
02671	013716	006316			ASL	(SP)	:: ROOM FOR NEW ONE.
02672	013722	005266	000002	17\$:	INC	2(SP)	:: KEEP COUNT OF CHAR
02673	013726	056616	177776		BIS	-2(SP),SP	:: SET IN NEW CHAR
02674	013732	000707			BR	7\$:: GET THE NEXT ONE
02675	013734	104401	001200	18\$:	TYPE	\$QUES	:: TYPE ?<CR><LF>
02676	013740	000720			BR	20\$:: SIMULATE CONTROL-U
02677					.DSABL	LSB	

::*****

::THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

::CALL:

*	RDCHR	:: INPUT A SINGLE CHARACTER FROM THE TTY
*	RETURN HERE	:: CHARACTER IS ON THE STACK
*		:: WITH PARITY BIT STRIPPED OFF

02691	013742	011646		\$RDCHR:	MOV	(SP),-(SP)	:: PUSH DOWN THE PC	
02692	013744	016666	000004	000002	MOV	4(SP),2(SP)	:: SAVE THE PS	
02693	013752	105777	165166	1\$:	TSTB	2\$TKS	:: WAIT FOR	
02694	013756	100375			BPL	1\$:: A CHARACTER	
02695	013760	117766	165162	000004	MOVB	2\$TKB,4(SP)	:: READ THE TTY	
02696	013766	042766	177600	000004	BIC	#1C(177),4(SP)	:: GET RID OF JUNK IF ANY	
02697	013774	026627	000004	000023	CMP	4(SP),#23	:: IS IT A CONTROL-S?	
02698	014002	001013			BNE	3\$:: BRANCH IF NO	
02699	014004	105777	165134	2\$:	TSTB	2\$TKS	:: WAIT FOR A CHARACTER	
02700	014010	100375			BPL	2\$:: LOOP UNTIL ITS THERE	
02701	014012	117746	165130		MOVB	2\$TKB,-(SP)	:: GET CHARACTER	
02702	014016	042716	177600		BIC	#1C177,(SP)	:: MAKE IT 7-BIT ASCII	
02703	014022	022627	000021		CMP	(SP)+,#21	:: IS IT A CONTROL-Q?	
02704	014026	001366			BNE	2\$:: IF NOT DISCARD IT	
02705	014030	000750			BR	1\$:: YES, RESUME	
02706	014032	026627	000004	000140	3\$:	CMP	4(SP),#140	:: IS IT UPPER CASE?
02707	014040	002407			BLT	4\$:: BRANCH IF YES	

```

2708 014042 026627 000004 000175      CMP      4(SP),#175      ;; IS IT A SPECIAL CHAR?
2709 014050 003003                BGT      4$              ;; BRANCH IF YES
2710 014052 042766 000040 000004      BIC      #40,4(SP)      ;; MAKE IT UPPER CASE
2711 014060 000002                RTI                      ;; GO BACK TO USER
4$:
*****
*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
*CALL:
*      RDLIN              ;; INPUT A STRING FROM THE TTY
*      RETURN HERE       ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
*                          ;; TERMINATOR WILL BE A BYTE OF ALL 0'S

2718 014052 010346      $RDLIN: MOV      R3,-(SP)      ;; SAVE R3
2719 014054 012703 014170 1$:      MOV      #STTYIN,R3      ;; GET ADDRESS
2720 014070 022703 014200 2$:      CMP      #STTYIN+8.,R3   ;; BUFFER FULL?
2721 014074 101405                BLOS     4$              ;; BR IF YES
2722 014076 104407                RDCHR    ;; GO READ ONE CHARACTER FROM THE TTY
2723 014100 112613                MOVVB   (SP)+,(R3)      ;; GET CHARACTER
2724 014102 122713 000177 13$:     CMPB    #177,(R3)      ;; IS IT A RUBOUT
2725 014106 001003                BNE     3$              ;; SKIP IF NOT
2726 014110 104401 001200 4$:      TYPE    'QUES          ;; TYPE A '?'
2727 014114 000763                BR      1$              ;; CLEAR THE BUFFER AND LOOP
2728 014116 111367 000044 3$:      MOVVB   (R3),9$        ;; ECHO THE CHARACTER
2729 014122 104401 014166                TYPE    '9$
2730 014126 122723 000015                CMPB    #15,(R3)+      ;; CHECK FOR RETURN
2731 014132 001356                BNE     2$              ;; LOOP IF NOT RETURN
2732 014134 105063 177777                CLRB   -1(R3)          ;; CLEAR RETURN (THE 15)
2733 014140 104401 001202                TYPE    'LF            ;; TYPE A LINE FEED
2734 014144 012603                MOV     (SP)+,R3        ;; RESTORE R3
2735 014146 011646                MOV     (SP),-(SP)      ;; ADJUST THE STACK AND PUT ADDRESS OF THE
2736 014150 016666 000004 000002      MOV     4(SP),2(SP)     ;; FIRST ASCII CHARACTER ON IT
2737 014156 012766 014170 000004      MOV     #STTYIN,4(SP)
2738 014164 000002                RTI                      ;; RETURN
2739 014166 000          9$:      .BYTE   0              ;; STORAGE FOR ASCII CHAR. TO TYPE
2740 014167 000          .BYTE   0              ;; TERMINATOR
2741 014170 000010      STTYIN: .BLKB   8.      ;; RESERVE 8 BYTES FOR TTY INPUT
2742 014200 052536 005015 000          SCNTLU: .ASCIZ  /TU<15><12>  ;; CONTROL "U"
2743 014205 136 006507 000012      SCNTLG: .ASCIZ  /TG<15><12>  ;; CONTROL "G"
2744 014212 005015 053523 020122      SMSWR:  .ASCIZ  <15>'12'<SWR = /
2745 014220 020075 000
2746 014223 040 047040 053505      $MNEW:  .ASCIZ  / NEW = /
2747 014230 036440 000040
2748 .SBTTL READ AN OCTAL NUMBER FROM THE TTY
2749
*****
*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
*CHANGE IT TO BINARY.
*CALL:
*      RDOCT              ;; READ AN OCTAL NUMBER
*      RETURN HERE       ;; LOW ORDER BITS ARE ON TOP OF THE STACK
*                          ;; HIGH ORDER BITS ARE IN $HIIOCT

2759 014234 011646      $RDOCT: MOV     (SP),-(SP)  ;; PROVIDE SPACE FOR THE
2760 014236 016666 000004 000002      MOV     4(SP),2(SP)    ;; INPUT NUMBER
2761 014244 010046                MOV     R0,-(SP)       ;; PUSH R0 ON STACK
2762 014246 010146                MOV     R1,-(SP)       ;; PUSH R1 ON STACK
2763 014250 010246                MOV     R2,-(SP)       ;; PUSH R2 ON STACK

```

E07

TAIL MOTION TEST
DZTADC.NEW 24-MAY-76

MAINDEC-11-DZTAD-C
00:00

MACY1: 27(1005) 23-SEP-76 10:33 PAGE 66
READ AN OCTAL NUMBER FROM THE TTY

SEQ 0082

2764	014252	104410	
2765	014254	012600	
2766	014256	005001	
2767	014260	005002	
2768	014262	112046	
2769	014264	001412	
2770	014266	006301	
2771	014270	006102	
2772	014272	006301	
2773	014274	006102	
2774	014276	006301	
2775	014300	006102	
2776	014302	042716	177770
2777	014306	062601	
2778	014310	000764	
2779	014312	005726	
2780	014314	010166	000012
2781	014320	010267	000010
2782	014324	012602	
2783	014326	012601	
2784	014330	012600	
2785	014332	000002	
2786	014334	000000	

```

1$:  RULIN          ;; READ AN ASCII LINE
      MOV          (SP)+,R0      ;; GET ADDRESS OF 1ST CHARACTER
      CLR         R1          ;; CLEAR DATA WORD
      CLR         R2
2$:  MOVB          (R0)+,-(SP)   ;; PICKUP THIS CHARACTER
      BEQ         Z$          ;; IF ZERO GET OUT
      ASL         R1          ;; *2
      ROL         R2          ;; *4
      ASL         R1          ;; *8
      ROL         R2          ;; *8
      BIC         #1C7,(SP)     ;; STRIP THE ASCII JUNK
      ADD         (SP)+,R1      ;; ADD IN THIS DIGIT
      BR         Z$          ;; LOOP
3$:  TST          (SP)+        ;; CLEAN TERMINATOR FROM STACK
      MOV         R1,12(SP)     ;; SAVE THE RESULT
      MOV         R2,$SHIOCT
      MOV         (SP)+,R2     ;; POP STACK INTO R2
      MOV         (SP)+,R1     ;; POP STACK INTO R1
      MOV         (SP)+,R0     ;; POP STACK INTO R0
      RTI                    ;; RETURN
SHIOCT: .WORD      J          ;; HIGH ORDER BITS GO HERE

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 15-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOS    ;;CALL FOR TYPEOUT
*      .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*      .BYTE   M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS

```

```

*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC

```

```

*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPON    ;;CALL FOR TYPEOUT

```

```

*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOC    ;;CALL FOR TYPEOUT

```

2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835
2836
2837
2838
2839
2840
2841
2842

```

014336 017546 000000
014342 116667 000001 000211
014350 112667 000207
014354 062716 000002
014360 000406
014362 112767 000001 000171
014370 112767 000006 000165
014376 112767 000005 000154
014404 010346
014406 010446
014410 010546
014412 116704 000145
014416 005404
014420 062704 000006
014424 110467 000132
014430 116704 000125
014434 016605 000012
014440 005003
014442 006105
014444 000404
014446 006105
014450 006105
014452 006105
014454 010503
014456 006103 000076
014460 105367 177770
014464 100016
014466 042703
014472 001002
014474 005704
014476 001403

```

```

$TYPOS: MOV      2(SP),-(SP)      ;;PICKUP THE MODE
        MOVVB   1(SP),%SFILL    ;;LOAD ZERO FILL SWITCH
        MOVVB   (SP)+,%SOMODE+1 ;;NUMBER OF DIGITS TO TYPE
        ADD     #2,(SP)         ;;ADJUST RETURN ADDRESS
        BR      $TYPON
$TYPOC: MOVVB   #1,%SFILL      ;;SET THE ZERO FILL SWITCH
        MOVVB   #6,%SOMODE+1   ;;SET FOR SIX(6) DIGITS
$TYPON: MOVVB   #5,%SOCNT      ;;SET THE ITERATION COUNT
        MOV     R3,-(SP)        ;;SAVE R3
        MOV     R4,-(SP)        ;;SAVE R4
        MOV     R5,-(SP)        ;;SAVE R5
        MOVVB   %SOMODE+1,R4    ;;GET THE NUMBER OF DIGITS TO TYPE
        NEG     R4
        ADD     #6,R4           ;;SUBTRACT IT FOR MAX. ALLOWED
        MOVVB   R4,%SOMODE     ;;SAVE IT FOR USE
        MOVVB   %SFILL,R4     ;;GET THE ZERO FILL SWITCH
        MOV     12(SP),R5      ;;PICKUP THE INPUT NUMBER
        CLR     R3             ;;CLEAR THE OUTPJT WORD
        ROL     R5             ;;ROTATE MSB INTO "C"
        BR     3$             ;;GO DO MSB
        ROL     R5             ;;FORM THIS DIGIT
        ROL     R5
        ROL     R5
        MOV     R5,R3
        ROL     R3             ;;GET LSB OF THIS DIGIT
        DECB   %SOMODE         ;;TYPE THIS DIGIT?
        BPL    7$             ;;BR IF NO
        BIC    #177770,R3     ;;GET RID OF JUNK
        BNE   4$             ;;TEST FOR 0
        TST   R4             ;;SUPPRESS THIS 0?
        BEQ   5$             ;;BR IF YES

```


G07

TAIL MOTION TEST MAINDEC-11-DZTAD-C MACY11 27(1006) 23-SEP-76 10:33 PAGE 68
 DZTADC.NEW 24-MAY-76 00:00 BINARY TO OCTAL (ASCII) AND TYPE

SEQ 0084

2843	014500	005204		4\$:	INC	R4	:: DON'T SUPPRESS ANYMORE 0'S
2844	014502	052703	000060		BIS	*'0,R3	:: MAKE THIS DIGIT ASCII
2845	014506	052703	000040	5\$:	BIS	*',R3	:: MAKE ASCII IF NOT ALREADY
2846	014512	110367	000040		MOVB	R3,8\$:: SAVE FOR TYPING
2847	014516	104401	014556		TYPE	8\$:: GO TYPE THIS DIGIT
2848	014522	105367	000032	7\$:	DECB	\$OCNT	:: COUNT BY 1
2849	014526	003347			BGT	2\$:: BR IF MORE TO DO
2850	014530	002402			BLT	6\$:: BR IF DONE
2851	014532	005204			INC	R4	:: INSURE LAST DIGIT ISN'T A BLANK
2852	014534	000744			BR	2\$:: GO DO THE LAST DIGIT
2853	014536	012605		6\$:	MOV	(SP)+,R5	:: RESTORE R5
2854	014540	012604			MOV	(SP)+,R4	:: RESTORE R4
2855	014542	012603			MOV	(SP)+,R3	:: RESTORE R3
2856	014544	016666	000002 000004		MOV	2(SP),4(SP)	:: SET THE STACK FOR RETURNING
2857	014552	012616			MOV	(SP)+,(SP)	
2858	014554	000002			RTI		:: RETURN
2859	014556	000		9\$:	.BYTE	0	:: STORAGE FOR ASCII DIGIT
2860	014557	000			.BYTE	00	:: TERMINATOR FOR TYPE ROUTINE
2861	014560	000		\$OCNT:	.BYTE	00	:: OCTAL DIGIT COUNTER
2862	014561	000		\$OFILL:	.BYTE	00	:: ZERO FILL SWITCH
2863	014562	000000		\$CMODE:	.WORD	0	:: NUMBER OF DIGITS TO TYPE

.SBTTL TRAP DECODER

*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
*GO TO THAT ROUTINE.

2864
2865
2866
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880

```
$TRAP:  MOV    RO, -(SP)           ;; SAVE RO
        MOV    2(SP), RO         ;; GET TRAP ADDRESS
        TST    -(RO)             ;; BACKUP BY 2
        MOVB   (RO), RO          ;; GET RIGHT BYTE OF TRAP
        ASL    RO                 ;; POSITION FOR INDEXING
        MOV    $TRPAD(RO), RO     ;; INDEX TO TABLE
        RTS    RO                 ;; GO TO ROUTINE
```

;; THIS IS USE TO HANDLE THE "GETPRI" MACRO

2881
2882
2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893

```
$TRAP2: MOV    (SP), -(SP)        ;; MOVE THE PC DOWN
        MOV    4(SP), 2(SP)       ;; MOVE THE PSW DOWN
        RTI                          ;; RESTORE THE PSW
```

.SBTTL TRAP TABLE

*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
*BY THE "TRAP" INSTRUCTION.

2894
2895
2896
2897
2898
2899
2900
2901
2902
2903
2904
2905
2906
2907
2908
2909
2910
2911
2912
2913
2914
2915
2916

ROUTINE	STARTING ADDRESS	ROUTINE
WORD	\$TRAP2	
\$TYPE	;;CALL=TYPE	TRAP+1(104401) TTY TYPEOUT ROUTINE
\$TYPOC	;;CALL=TYPOC	TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
\$TYPOS	;;CALL=TYPOS	TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
\$TYPON	;;CALL=TYPON	TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
\$GTSWR	;;CALL=GTSWR	TRAP+5(104405) GET SOFT-SWR SETTING
\$CKSWR	;;CALL=CKSWR	TRAP+6(104406) TEST FOR CHANGE IN SOFT-SWR
\$RDCHR	;;CALL=RDCHR	TRAP+7(104407) TTY TYPEIN CHARACTER ROUTINE
\$RDLIN	;;CALL=RDLIN	TRAP+10(104410) TTY TYPEIN STRING ROUTINE
\$RDOCT	;;CALL=RDOCT	TRAP+11(104411) READ AN OCTAL NUMBER FROM TTY
T.WFG	;;CALL=WFG	TRAP+12(104412) ROUTINE TO WRITE A FILE GAP
T.WRIT	;;CALL=WRITE	TRAP+13(104413) ROUTINE TO WRITE A BLOCK OF DATA
T.READ	;;CALL=READ	TRAP+14(104414) ROUTINE TO READ A BLOCK OF DATA
T.BSFG	;;CALL=BSFG	TRAP+15(104415) ROUTINE TO BACK SPACE A FILE GAP
T.BSBG	;;CALL=BSBG	TRAP+16(104416) ROUTINE TO BACK SPACE A BLOCK GAP
T.SFFG	;;CALL=SFFG	TRAP+17(104417) ROUTINE TO SPACE FWD A FILE GAP
T.SFBG	;;CALL=SFBG	TRAP+20(104420) ROUTINE TO SPACE FWD A BLOCK GAP
T.RWND	;;CALL=REWIND	TRAP+21(104421) ROUTINE TO REWIND THE TAPE
T.SELDRV	;;CALL=SELDRV	TRAP+22(104422) ROUTINE TO SELECT THE NEXT DRIVE
T.BLKCMP	;;CALL=BLKCMP	TRAP+23(104423) COMPARE READ AND WRITE BUFFERS
T.SETLOOP	;;CALL=SETLOOP	TRAP+24(104424) SETUP TO LOOP AS PER THE TTY

.SBTTL POWER DOWN AND UP ROUTINES

```

2917
2918
2919
2920
2921 014672 012737 015036 000024 $PWRDN: MOV $SILLUP,@#PWRVEC ;;SET FOR FAST UP
2922 014700 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;PRIO:7
2923 014706 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
2924 014710 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
2925 014712 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
2926 014714 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
2927 014716 010446 MOV R4,-(SP) ;;PUSH R4 ON STACK
2928 014720 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
2929 014722 017746 164212 MOV @SWR,-(SP) ;;PUSH @SWR ON STACK
2930 014726 010667 000110 MOV SP,$SAVR6 ;;SAVE SP
2931 014732 012737 014744 000024 MOV $PWRUP,@#PWRVEC ;;SET UP VECTOR
2932 014740 000000 HALT
2933 014742 000776 BR -.2 ;;HANG UP
2934
2935
2936
2937 014744 012737 015036 000024 $PWRUP: MOV $SILLUP,@#PWRVEC ;;SET FOR FAST DOWN
2938 014752 016706 000064 MOV $SAVR6,SP ;;GET SP
2939 014756 005067 000060 CLR $SAVR6 ;;WAIT LOOP FOR THE TTY
2940 014762 005267 000054 1$: INC $SAVR6 ;;WAIT FOR THE INC
2941 014766 001375 BNE 1$ ;;OF WORD
2942 014770 012677 164144 MOV (SP)+,@SWR ;;POP STACK INTO @SWR
2943 014774 012605 MOV (SP)+,R5 ;;POP STACK INTO R5
2944 014776 012604 MOV (SP)+,R4 ;;POP STACK INTO R4
2945 015000 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
2946 015002 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
2947 015004 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
2948 015006 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
2949 015010 012737 014672 000024 MOV $PWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
2950 015016 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;PRIO:7
2951 015024 104401 TYPE ;;REPORT THE POWER FAILURE
2952 015026 015044 $PWRMG: .WORD $POWER ;;POWER FAIL MESSAGE POINTER
2953 015030 012716 MOV (PC)+,(SP) ;;RESTART AT PWRST
2954 015032 002314 $PWRAD: .WORD PWRST ;;RESTART ADDRESS
2955 015034 000002 RTI
2956 015036 000000 $SILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
2957 015040 000776 BR -.2 ;;BEFORE THE POWER DOWN WAS COMPLETE
2958 015042 000000 $SAVR6: 0 ;;PUT THE SP HERE
2959 015044 005015 047520 042527 $POWER: .ASCIZ <15><12>"POWER"
2960 015052 000122
2961 .EVEN

```

2962
2963
2964
2965
2966
2967
2968
2969
2970
2971
2972
2973
2974
2975
2976
2977
2978
2979
2980
2981
2982

:DATA POINTERS

015054	001204	001116	001162	DT1:	.WORD	SAVPC,\$ERRPC,\$REGO,\$REG1,0
015062	001164	000000				
015066	001204	001116	001162	DT2:	.WORD	SAVPC,\$ERRPC,\$REGO,\$GDDAT,\$BDDAT,BYTNUM,0
015074	001124	001126	001206			
015102	000000					
015104	001204	001116	001162	DT3:	.WORD	SAVPC,\$ERRPC,\$REGO,RCRC0,RCRC1,RCRC2,0
015112	001210	001212	001214			
015120	000000					
015122	001204	001116	001162	DT4:	.WORD	SAVPC,\$ERRPC,\$REGO,\$REG1,\$TMPO,0
015130	001164	001166	000000			
015136	001204	001116	001162	DT5:	.WORD	SAVPC,\$ERRPC,\$REGO,0
015144	000000					

```

2983 ;*****
2984 ;
2985 ;MESSAGES
2986
2987 015146 042200 044522 042526 MSGDRV: .ASCIZ <CRLF>"DRIVE(S)? "
2988 015154 051450 037451 000040
2989 015162 005015 040524 051503 MSGASK: .ASCIZ <15><12>/TACS?/
2990 015170 000077
2991 015172 042526 052103 051117 MSGVEC: .ASCIZ /VECTOR?/
2992 015200 000077
2993 015202 051120 047511 044522 MSGPRI: .ASCIZ /PRIORITY?/
2994 015210 054524 000077
2995 015214 052040 041501 036523 MTACS: .ASCIZ / TACS=/
2996 015222 000
2997 015223 040 040524 041104 MTADB: .ASCIZ / TADB=/
2998 015230 000075
2999 015232 053040 041505 047524 MTAVEC: .ASCIZ / VECTOR=/
3000 015240 036522 000
3001 015243 040 051120 047511 MTAPRI: .ASCIZ / PRIORITY=/
3002 015250 044522 054524 000075
3003 015256 005015 045517 000077 MSGOK: .ASCIZ <15><12>/OK?/
3004 015264 042531 100123 000 MYES: .ASCIZ /YES/<CRLF>
3005 015271 015 052012 051505 MTSTDRV: .ASCIZ <15><12>/TESTING DRIVE /
3006 015276 044524 043516 042040
3007 015304 044522 042526 000040
3008 015312 040440 042116 042040 MANDRV: .ASCIZ / AND DRIVE /
3009 015320 044522 042526 000040
3010 015326 005015 042524 052123 MTEST: .ASCIZ <15><12>/TEST PC?/
3011 015334 050040 037503 000
3012 015341 015 046012 047517 MLJOP: .ASCIZ <15><12>/LOOP PC?/
3013 015346 020120 041520 000077
3014 015354 042522 044527 042116 MXRWND: .ASCIZ /REWIND/
3015 015362 000
3016 015363 127 044522 042524 MXWRIT: .ASCIZ /WRITE/
3017 015370 000
3018 015371 122 040505 000104 MXREAD: .ASCIZ /READ/
3019 015376 050123 041501 026505 MXSFFG: .ASCIZ /SPACE-FWD-FILE-GAP/
3020 015404 053506 026504 044506
3021 015412 042514 043455 050101
3022 015420 000
3023 015421 123 040520 042503 MXSFBG: .ASCIZ /SPACE-FWD-BLK-GAP/
3024 015426 043055 042127 041055
3025 015434 045514 043455 050101
3026 015442 000
3027 015443 102 041501 026513 MXBSFG: .ASCIZ /BACK-SPACE-FILE-GAP/
3028 015450 050123 041501 026505
3029 015456 044506 042514 043455
3030 015464 050101 000
3031 015467 102 041501 026513 MXBSBG: .ASCIZ /BACK-SPACE-BLK-GAP/
3032 015474 050123 041501 026505
3033 015502 046102 026513 040507
3034 015510 000120
3035 015512 051127 052111 026505 MXWFG: .ASCIZ /WRITE-FILE-GAP/
3036 015520 044506 042514 043455
3037 015526 050101 000
3038 015531 102 043125 042506 MBUFCK: .ASCIZ /BUFFER COMPARE/

```

3039	015536	020122	047503	050115					
3040	015544	051101	000105						
3041	015550	046511	051120	050117	EM1:	.ASCIZ	/IMPROPER FLAG SETTING/		
3042	015556	051105	043040	040514					
3043	015564	020107	042523	052124					
3044	015572	047111	000107						
3045	015576	046511	051120	050117	EM2:	.ASCIZ	/IMPROPER FLAG OCCURRED/		
3046	015604	051105	043040	040514					
3047	015612	020107	041517	052503					
3048	015620	051122	042105	000					
3049	015625	115	051511	042523	EM3:	.ASCIZ	/MISSED A FLAG/		
3050	015632	020104	020101	046106					
3051	015640	043501	000						
3052	015643	111	052116	051105	EM4:	.ASCIZ	/INTERRUPT FAILED/		
3053	015650	052522	052120	043040					
3054	015656	044501	042514	000104					
3055	015664	051120	046505	052101	EM5:	.ASCIZ	/PREMATURE READY OCCURRED/		
3056	015672	051125	020105	042522					
3057	015700	042101	020131	041517					
3058	015706	052503	051122	042105					
3059	015714	000							
3060	015715	104	042111	023516	EM6:	.ASCIZ	/DIDN'T STOP IN A FILE GAP/		
3061	015722	020124	052123	050117					
3062	015730	044440	020116	020101					
3063	015736	044506	042514	043440					
3064	015744	050101	000						
3065	015747	104	042111	023516	EM7:	.ASCIZ	/DIDN'T STOP ON CLEAR LEADER/		
3066	015754	020124	052123	050117					
3067	015762	047440	020116	046103					
3068	015770	040505	020122	042514					
3069	015776	042101	051105	000					
3070	016003	102	042101	042040	EM10:	.ASCIZ	/BAD DATA READ/		
3071	016010	052101	020101	042522					
3072	016016	042101	000						
3073	016021	111	046114	043505	EM11:	.ASCIZ	/ILLEGAL BUFFER SIZE/		
3074	016026	046101	041040	043125					
3075	016034	042506	020122	044523					
3076	016042	042532	000						
3077	016045	103	041522	042440	EM12:	.ASCIZ	/CRC ERROR/		
3078	016052	051122	051117	000					
3079	016057	123	047510	052122	EM13:	.ASCIZ	/SHORT RECORD/		
3080	016064	051040	041505	051117					
3081	016072	000104							
3082	016074	040502	020104	047111	EM14:	.ASCIZ	/BAD INTERRUPT/		
3083	016102	042524	051122	050125					
3084	016110	000124							
3085	016112	005015			DH1:	.ASCII	<15><12>		
3086	016114	042524	052123	020040		.ASCII	/TEST ERROR/<15><12>		
3087	016122	020040	051105	047522					
3088	016130	006522	012						
3089	016133	120	020103	020040		.ASCIZ	/PC PC TACS TADB/<15><12>		
3090	016140	020040	050040	020103					
3091	016146	020040	020040	052040					
3092	016154	041501	020123	020040					
3093	016162	052040	042101	006502					
3094	016170	000012							

NO7

TAIL MOTION TEST
DZTADC.NEW 24-MAY-76

MAINDEC-11-DZTAD-C
00:00

MACY11 27(1006) 23-SEP-76 10:33 PAGE 75
ASCII MESSAGES

SEQ 0091

3151	016646	020040	020040	040524				
3152	016654	051503	005015	000				
3153		016662						
3154	016662	001116	001220	000000	DT201:	.EVEN		
3155						.WORD	\$ERRPC,TACSL,0	
3156	016670	001116	000000		DT202:	.WORD	\$ERRPC,0	
3157								
3158	016674	040524	030461	043040	EM201:	.ASCII	"TAIL FAILED TO RESPOND"	
3159	016702	044501	042514	020104				
3160	016710	047524	051040	051505				
3161	016716	047520	042116	000				
3162	016723	116	020117	051104	EM202:	.ASCIZ	"NO DRIVE AVAILABLE"	
3163	016730	053111	020105	053101				
3164	016736	044501	040514	046102				
3165	016744	000105						
3166	016746	041520	020040	020040	DH201:	.ASCIZ	/FC TACS/	
3167	016754	020040	040524	051503				
3168	016762	000						
3169	016763	120	000103		DH202:	.ASCIZ	/PC/	
3170						.EVEN		

017056
017057
017060
017061
017062
017064
017065
017066
017067
017070
017072
017073
017074
017075
017076
017100
017101
017102
017103
017104
017106
017107
017110
017111
017112

017130 000200
017132 000200
017134 000010
017136 000040
020140 000020
020342 000100
017130 000000
017056 000200
017064 000200
017072 000010
017100 000040
017106 000020
017114 000100
017122 000000

017056 000002
017056 314
017057 063
017060 314
017061 063
017062 000000
017064 000002
017064 377
017065 000
017066 377
017067 000
017070 000000
017072 000002
017073 231
017073 146
017074 231
017075 146
017076 000000
017100 000002
017100 360
017101 017
017102 360
017103 017
017104 000000
017106 000002
017106 252
017107 125
017110 252
017111 125
017112 000000

:BUFFER LINKS
:THESE LINKS POINT TO THE STARTING ADDRESS OF THE BUFFERS
:AND ALSO INDICATE HOW MANY BYTES TO READ OR WRITE

RLNK1: RBUF1,168.
RLNK2: RBUF2,128.
RLNK3: RBUF3,8.
RLNK4: RBUF4,32.
RLNK5: RBUF5,16.
RLNK6: RBUF6,64.
RLNKX: RBUF1,0
WLNK1: WBUF1,128.
WLNK2: WBUF2,128.
WLNK3: WBUF3,8.
WLNK4: WBUF4,32.
WLNK5: WBUF5,16.
WLNK6: WBUF6,64.
WLNKX: WBUF6,0

:BUFFERS

WBUF1: .BYTE #B11001100
.BYTE #B00110011
.BYTE #B11001100
.BYTE #B00110011
WCRC1: .WORD 0 ;CRC STORAGE FOR WBUF1
WBUF2: .BYTE #B11111111
.BYTE #B00000000
.BYTE #B11111111
.BYTE #B00000000
WCRC2: .WORD 0 ;CRC STORAGE FOR WBUF2
WBUF3: .BYTE #B10011001
.BYTE #B01100110
.BYTE #B10011001
.BYTE #B01100110
WCRC3: .WORD 0 ;CRC STORAGE FOR WBUF3
WBUF4: .BYTE #B11110000
.BYTE #B00001111
.BYTE #B11110000
.BYTE #B00001111
WCRC4: .WORD 0 ;CRC STORAGE FOR WBUF4
WBUF5: .BYTE #B10101010
.BYTE #B01010101
.BYTE #B10101010
.BYTE #B01010101
WCRC5: .WORD 0 ;CRC STORAGE FOR WBUF5

TAB: MOTION TEST
DZTADCC.NEW

24-MAY-76 00:00

MAINDEC-11-DZTAD-C

MACY11 27(1006) 23-SEP-76 10:33 PAGE 78
READ AND WRITE BUFFERS AND LINKS

SEQ 0094

01.7736 000202
020140 000202
020342 000202
020544
000001

RBUF4: .BLKB 130.
RBUF5: .BLKB 130.
RBUF6: .BLKB 130.
LASTADDRESS= .
.END

TAIL MOTION TEST
DZTADC.NEW

24-MAY-76 00:00

MAINDEC-11-DZTAD-C

MACY11 27(1006)

23-SEP-76 10:33 PAGE 89

CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0104

\$TRAP	014564	467	2872*																	
\$TRAP2	014606	2883*	2894																	
\$TRP =	000025	2887*	2896*	2897*	2898*	2899*	2900	2901*	2902	2903*	2904*	2905*	2906*	2907*						
		2908*	2909*	2910*	2911*	2912*	2913*	2914*	2915*	2916*	2917*									
\$TRPAD	014620	2877	2894*																	
\$TSTNM	001102	256*	625*	1488*	1549	1602*	1607	1610	1643	1672										
\$TTYIN	014170	2720	2721	2738	2742*															
\$TYPBN	***** U	2899																		
\$TYPDS	***** U	2899																		
\$TYPE	J13240	2557*	2887	2895																
\$TYPEC	013410	2578	2585	2592	2597*	2598	2664													
\$TYPEX	013456	2603	2605	2608*																
\$TYPOC	014362	2817*	2896																	
\$TYPON	014376	2816	2819*	2898																
\$TYPOS	014336	2812*	2897																	
\$XTSTR	006640	1571*																		
\$GET4	000000	1501*																		
\$OFILL	014561	2913*	2817*	2827	2862*															
\$40CAT	***** U	1568	1653																	
.	= 020544	226*	230*	253*	295	460	475	476	511*	1509	1512	1610	1672	1707*						
		2610	2613	2742*	2743	2749	2933	2957	3153*	3243*	3244*	3245*	3246*	3247*						
		3248*	3250																	

. ABS. 020544 000

ERRORS DETECTED: 0
DEFAULT GLOBALS GENERATED: 0

TADC TADC/SOL/CRF:SYM=DZTADC.NEW
RUN-TIME: 48 37 3 SECONDS
RUN-TIME RATIO: 185/90=2.0
CORE USED: 24K (47 PAGES)

