

.REM %

IDENTIFICATION

PRODUCT CODE: AC-E499B-MC
PRODUCT NAME: CZTUSBO TM03/TU45 DR FCTN TMR
DATE CREATED: 25 MAY 1978
UPDATE INFORMATION: DATE AUTHOR
 29-FEB-80 VIJAY ANANDWALA
MAINTAINER: COMPUTER SPECIAL SYSTEMS
AUTHOR: CSS DIAGNOSTICS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1975, 1980 BY DIGITAL EQUIPMENT CORPORATION

TMO3 DRIVE FUNCTION TIMER
TABLE OF CONTENTS

PAGE 2

TABLE OF CONTENTS

ABSTRACT

CHAPTER 1 REQUIREMENTS

1.1 EQUIPMENT

1.2 MEMORY STORAGE

1.3 PRELIMINARY PROGRAMS

CHAPTER 2 LOADING AND STARTING PROCEDURE

2.1 ACT11 OPERATION

CHAPTER 3 SWITCH SETTINGS

CHAPTER 4 ERRORS

4.1 ERROR TYPEOUT FORMAT (HARDWARE)

4.2 ERROR TYPEOUT FORMAT (FUNCTION OUT OF RANGE)

CHAPTER 5 SUBROUTINE ABSTRACTS

CHAPTER 6 MISCELLANEOUS

6.1 STACK POINTER

6.2 EXECUTION TIME

CHAPTER 7 PROGRAM DESCRIPTION

7.1 FUNCTION TIME DOCUMENT

7.2 TEST SEQUENCE / RELATED ADJUSTMENTS / ASSOCIATED HARDWARE

7.3 SUBTEST DESCRIPTIONS

TM03 DRIVE FUNCTION TIMER
ABSTRACT

PAGE 3

ABSTRACT

PROGRAM CZTUSBO MEASURES THE TIME REQUIRED AND GAP SIZES PRODUCED BY THE TM03/TU45 MAGTAPE DRIVE/SLAVE.

THE TEST WILL CHECK BOTH THE LOGIC GENERATED TIME DELAYS, AND THE DISTANCES TRAVELED BY THE TAPE.

ACTUAL TAPE SPEED MAY ALSO BE CHECKED BY USING THE SPEED TESTS WITH AN 800 BPI SKEW TAPE.

DEVICE ERRORS ARE CHECKED AND PRINTED AS THEY OCCUR. IF AN ERROR IS DATA RELATED(PARITY; ETC) THEY ARE PRINTED AS SOFT ERRORS.

IF A TIME CHECK IS OUT OF RANGE, IT IS PRINTED AS AN OUT OF RANGE ERROR.

TMO3 DRIVE FUNCTION TIMER
REQUIREMENTS

PAGE 4

CHAPTER 1
REQUIREMENTS

PDP-11 FAMILY CENTRAL PROCESSOR WITH 4K MEMORY WITH UP TO 64 TMO3/TU45
CONTROLLER/MAGTAPE STATIONS.

1.1 OPTIONAL EQUIPMENT USED

1. NONE

1.2 STORAGE

PROGRAM LOADS AND RUNS IN THE FIRST 4K OF MEMORY.

1.3 PRELIMINARY PROGRAMS (TO ASSURE HARDWARE OPERATION)

CZTUOA CONTROL LOGIC TEST(PART 1)
CZTUPAO BASIC FUNCTION TEST

TMO3 DRIVE FUNCTION TIMER
LOADING AND STARTING PROCEDURE

PAGE 5

CHAPTER 2
LOADING AND STARTING PROCEDURE

2.0 LOAD & START PROCEDURE:

LOAD PROGRAM USING THE ABSOLUTE LOADER
LOAD ADDRESS = 200
SET OPERATING SWITCHES SEE CHAPT 3 SWITCH SETTINGS
PRESS START

THE PROGRAM WILL THEN REQUEST THE FIRST BUS ADDRESS OF THE RMX
CONTROLLER, TMO3 DRIVES TO BE TESTED, TU45 SLAVES TO BE TESTED,
AND IF SPEED TESTS ARE TO BE RUN. IN ADDITION TO EACH REQUEST A
DEFAULT ANSWER WILL BE TYPED. TO INVOKE THE DEFAULT TYPE A
CARRIAGE RETURN.

THE REQUESTS & THEIR DEFAULTS ARE:

TYPE FIRST ADDRESS OF CONTROLLER:172440
TYPE TMO3 DRIVE #'S TO BE TESTED:ALL
FOR TMO3 DRIVE X-TYPE SLAVE #'S TO BE TESTED:ALL
SPEED TESTS?(YES/NO):NO

NOTES: SLAVE #'S ARE NOT REQUESTED IF DEFAULT TO DRIVE REQUEST
IS INVOKED.

IF MORE THAN 1 DRIVE OR SLAVE IS TO BE TESTED, TYPE A COMMA
BETWEEN EACH DRIVE OR SLAVE # TO BE TESTED.

SPEED TESTS CAN & WILL ONLY BE RUN BY ANSWERING YES TO THE REQUEST.

TYPE CONTROL U (^U) TO DELETE LINE TYPED;TYPE 'RUBOUT' TO DELETE LAST
CHARACTER(S).
PROGRAM WILL REPORT ERRORS, AND END OF PASS.

2.1 RESTART PROCEDURE

THE PROGRAM MAY BE RESTARTED USING START UP PARAMETERS AT ADDRESS 210.

THE PROGRAM MAY ALSO BE RESTARTED BY TYPING A CONTROL C (^C).
A ^C RESTART WILL REQUEST PARAMETERS.

NOTE: AFTER RESTARTING THE SWITCH REGISTER SHOULD
BE SET TO PROGRAM SWITCH SETTINGS. IF 210
IS LEFT AS THE SWITCH SETTING THE PROGRAM
WILL SELECT & RUN TEST 10 ONLY. SEE SWITCH
SETTINGS FOR EXPLANATION.

2.2 AUTOMATIC MODE OPERATION

IF THE PROGRAM IS LOADED AND RUN IN AUTOMATIC (CHAIN) MODE
DEFAULT RESPONSES TO OPERATOR REQUESTS ARE USED, AND ALL AVAIL-
ABLE TM03/TU45 COMBINATIONS ARE TESTED. ADDITIONALLY THE SOFTWARE
SWR IS INVOKED WITH A SWITCH SETTING OF 100000 IF LOADED VIA ACT11.
NO OPERATOR INTERVENTION IS REQUIRED

** EXCEPTION: IF LOADED VIA TMDP TM03 DRIVE 0 TU45 SLAVE 0 IS
NOT TESTED.

TMO3 DRIVE FUNCTION TIMER
SWITCH SETTINGS

PAGE 6

CHAPTER 3 SWITCH SETTINGS

CONTROL:

- 1) CONTROL G <^G>:
SELECTS THE SOFTWARE SWR AND ALLOWS NEW SWITCH SETTINGS.
THE MACHINE WILL THEN TYPE: SWR=XXXXXXNEW=
WHERE: XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWR.
AFTER THE ''NEW='' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE
OF THE FOLLOWING AT THE TTY:
A) TYPE A NUMBER TO BE LOADED INTO THE SOFTWARE SWR.
B) IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH
REGISTER CONTENTS WILL NOT BE CHANGED.
- 2) CONTROL A <^A>:
ALTERNATES USAGE OF THE SWR BETWEEN HARDWARE & SOFTWARE.
- 3) CONTROL C <^C>:
RESTARTS PROGRAM AT 200
- 4) CONTROL U <^U>:
DELETES ALL CHARACTERS TYPED IN RESPONSE TO A REQUEST.

SW15 (100000)		HALT ON ERROR THIS SWITCH WHEN SET WILL HALT THE PROCESSOR WHEN AN ERROR IS DETECTED. THE PC+2 AND PSW AT THE TIME OF THE ERROR IS STORED ON THE STACK. PRESSING CONTINUE WILL CAUSE THE ERROR TO BE TYPED (IF SELECTED) AND FURTHER TESTING RESUMED.
SW14 (040000)	LOOP SUBTEST	THIS SWITCH WHEN SET LOOPS THE CURRENT SUBTEST REGARDLESS OF ERROR CONDITION.
SW13 (020000)	INHIBIT ERROR TYPEOUT	THIS SWITCH WHEN SET INHIBITS ERROR TYPEOUT.
SW11 (004000)	INHIBIT SUB-TEST ITERATION	THIS SWITCH WHEN SET CAUSES EACH SUBTEST TO BE EXECUTED ONLY ONCE.
SW10 (002000)	INHIBIT FUNCTION TIME PUBLICATION	THIS SWITCH WHEN SET WILL INHIBIT THE PRINTING OF THE FUNCTION TIMES. (SEE CHAPTER 8.)
SW09 (001000)	RING BELL ON ERROR	THIS SWITCH WHEN SET WILL RING THE BELL ON THE TTY WHEN AN ERROR IS DETECTED.
SW08 (000900)	PRINT TIME	THIS SWITCH WHEN SET WILL PRINT A TIME LINE AFTER EACH ITERATION.
SW06 (000100)	CONTINUOUS CYCLE	THIS SWITCH WHEN SET WILL CAUSE THE PROGRAM TO RUN CONTINUOUSLY UNTIL STOPPED BY THE OPERATOR.
SW5-0	TEST SELECT	RUN SUBTEST SELECTED

NOTE: A TEST CAN ONLY BE SELECTED DURING STARTUP (OR RESTART).
DO NOT INHIBIT SUBTEST ITERATIONS WHEN PROGRAM IS RUNNING.

TM03 DRIVE FUNCTION TIMER
ERRORS

PAGE 7

CHAPTER 4

ERRORS

TWO TYPES OF ERRORS ARE DETECTED BY THIS PROGRAM, HARDWARE ERRORS AND INCORRECT FUNCTION TIMES.

4.1 ERROR TYPEOUT FORMAT (HARDWARE): DATA RELATED ERRORS (IE: PARITY ERROR) ARE PRINTED AS SOFT ERRORS AND HAVE NO EFFECT ON TIME.

TEST # XXXXXX DEVICE ERROR

CS1	WE	BA	FC	CS2	DS	ER1
AAAAAA	BBBBBB	CCCCCC	DDDDDD	EEEEEE	FFFFFF	GGGGGG

WHERE:

XXXXXX = TEST NUMBER
AAAAAA-IIIIII = CONTENTS OF TAPE REGISTER 172440-172454

4.2 ERROR TYPEOUT FORMAT (FUNCTION TIME OUT OF RANGE)

TEST # XXXYXX OUT OF RANGE ERROR

RANGE = <AAAAAA-BBBBBB> ACTUAL = CCCCCC

TMO3 DF 'F FUNCTION TIMER
SUBROUTINE ABSTRACTS

PAGE 8

CHAPTER 5 SUBROUTINE ABSTRACTS

5.1 .SCOPE

THE SCOPE ROUTINE IS CALLED BY THE SCOPE (EMT) INSTRUCTION AT THE START OF EACH SUBTEST. THE .SCOPE ROUTINE PERFORMS THE FOLLOWING FUNCTIONS:

1. LOADS R5 WITH BASE ADDRESS
2. TYPES TIME LINE <SW08>=1
3. PROVIDES CONTINUOUS LOOP <SW14>
4. MOVES FUNCTION TIME INTO TABLE
5. OUTPUTS LINE ITEM <SW10>=1
6. DELAYS 350MS BEFORE STARTING TEST
7. INIT'S DRIVE/SLAVE
8. CLEARS THE ERROR FLAG (ERFLG)
9. CHECK FOR CONTROL G (^G)

THE ROUTINE MONITORS SW14, SW11, SW10, SW08, AND SW07.

5.2 PUBLISH

THE PUBLISH ROUTINE IS CALLED FROM THE SCOPE ROUTINE IF SW10 IS EQUAL TO 0 (PUBLISH TIME DOCUMENT). THE ROUTINE WILL PRINT A THE TIME RECORDED BY THE SUBTEST.

TMO3 DRIVE FUNCTION TIMER
SUBROUTINE ABSTRACTS

PAGE 9

5.3 .HLT

THE HLT ROUTINE IS CALLED BY THE HLT (TRAP) INSTRUCTION WHEN AN ERROR IS DETECTED. A HLT (TRAP) INSTRUCTION FORMATS THE ERROR INFORMATION AS SHOWN IN SEC 4.1. A HLT+1 (TRAP+1) FORMATS THE ERROR AS SHOWN IN SEC 4.2.

TMO3 DRIVE FUNCTION TIMER
MISCELLANEOUS

PAGE 10

CHAPTER 6 MISCELLANEOUS

6.1 STACK POINTER

THE STACK POINTER IS INITIALLY SET TO 500.

6.2 EXECUTION TIME

WHEN SW11=1 (INHIBIT ITERATIONS) THE TIME REQUIRED IS 2 MIN.

WHEN SW11=0 (ITERATE SUBTESTS) THE TIME REQUIRED IS 9 MIN.

TMO3 DRIVE FUNCTION TIMER
PROGRAM DESCRIPTION

PAGE 11

CHAPTER 7

PROGRAM DESCRIPTION

7.1 SAMPLE TIME DOCUMENT

TYPE FIRST ADDRESS OF CONTROLLER:172440
TYPE TMO3 DRIVE #'S TO BE TESTED:ALL 0
FOR TMO3 DRIVE 0- TYPE SLAVE #'S TO BE TESTED:ALL 0
TAPE SPEED TESTS ONLY? (YES/NO):NO

* TMO3 DRIVE FUNCTION TIMES- DRIVE # 0 SLAVE # 7 9 CHAN. SER. # 5009
*

* FUNCTION	TIME(SPECIFICATION)	TIME(ACTUAL)
* WRITE FROM BOT	RANGE=<063000-059000>	ACTUAL=061000
* WRITE START	RANGE=<004500-003700>	ACTUAL=004100
* WRITE SHUTDOWN	RANGE=<003600-002600>	ACTUAL=003100
* WRITE SETTLEDOWN	RANGE=<007600-001400>	ACTUAL=4500
* READ FROM BOT	RANGE=<009200-005200>	ACTUAL=007200
* READ START	RANGE=<001700-000900>	ACTUAL=001300
* READ SHUTDOWN	RANGE=<001450-000350>	ACTUAL=000900
* READ SETTLEDOWN	RANGE=<007600-001400>	ACTUAL=004500
* READ REV START	RANGE=<001700-000900>	ACTUAL=001300
* READ REV SHUTDOWN	RANGE=<001900-001500>	ACTUAL=001700
* READ REV SETTLEDOWN	RANGE=<007600-001400>	ACTUAL=004500
* TURN AROUND DELAY F-R	RANGE=<008800-002800>	ACTUAL=005800
* TURN AROUND DELAY R-F	RANGE=<008800-002800>	ACTUAL=005800
* GAP SIZE-STOP HALF	RANGE=<007900-004500>	ACTUAL=006200
* GAP SIZE-START HALF	RANGE=<008550-005250>	ACTUAL=006900
* GAP SIZE-INTERRECORD	RANGE=<006150-004450>	ACTUAL=005300
* GAP CONSISANCY	RANGE=<007050-005350>	ACTUAL=006200
* DATA TIME-800BPI	RANGE=<012000-011000>	ACTUAL=011500
* DATA TIME-1600BPI	RANGE=<012500-011500>	ACTUAL=012000
* ERASE GAP TIME	RANGE=<049900-046900>	ACTUAL=048400
* WRITE FILE MARK	RANGE=<051200-049200>	ACTUAL=050200

TMO3 DRIVE FUNCTION TIMER

7.1.1 SAMPLE TIME DOCUMENT FOR TAPE SPEED TESTS

TYPE FIRST ADDRESS OF CONTROLLER 172440:
TYPE TMO3 DRIVE #'S TO BE TESTED:ALL 0
FOR TMO3 DRIVE 0- TYPE SLAVE #'S TO BE TESTED:ALL 7
SPEED TESTS ONLY? (YES/NO):NO Y

*TMO3 DRIVE FUNCTION TIMES- DRIVE # 0 SLAVE # 7 9 CHAN. SER. # 5009
*

*FUNCTION	TIME(SPECIFICATION)	TIME(ACTUAL)
*TAPE SPEED FWD	RANGE=<011300-010300>	ACTUAL=010800
*TAPE SPEED REV	RANGE=<011300-010300>	ACTUAL=010800

TMO3 DRIVE FUNCTION TIMER

7.2 TEST SEQUENCE WITH RELATED ADJUSTMENTS AND ASSOCIATED HARDWARE

TEST NO./NAME	RELATED ADJUSTMENTS	ASSOCIATED HARDWARE
1. WRITE FROM BOT	*NONE	*M8928 ROM*M8903 ACCL CNTR
2. WRITE START	* ''	* '' * ''
3. WRITE SHUTDOWN	* ''	* '' * ''
4. WRITE SETTLEDOWN	* ''	*M8928 SETTLEDOWN ONE SHOT
5. READ FROM BOT	* ''	*M8928 ROM*M8903 ACCL CNTR
6. READ START	* ''	* '' * ''
7. READ SHUTDOWN	* ''	* '' * ''
10. READ SETTLEDOWN	* ''	*M8928 SETTLEDOWN ONE SHOT
11. READ REVERSE START	* ''	*M8928 ROM*M8903 ACCL CNTR
12. READ REVERSE SHUTDOWN	* ''	* '' * ''
13. READ REVERSE SETTLEDOWN	* ''	*M8928 SETTLEDOWN ONE SHOT
14. TURN AROUND F-R	* ''	*M8928 ROM*M8903 ACCL CNTR
15. TURN AROUND R-F	* ''	* '' * ''
16. GAP SIZE-STOP HALF	*FWRD/REV SPEED-START/STOP-RAMPS	*CAPSTAN SERVO LOOP
17. GAP SIZE-START HALF	*SAME AS IN TEST 16	* '' '' ''
20. GAP SIZE INTERRECORD	*FWD/REV SPEED	* '' '' ''

TMO3 DRIVE FUNCTION TIMER

PAGE 14

21. GAP CONSISTENCY	*SAME AS IN TEST 16	*WRITE CLOCK
22. DATA TIME 800 BPI	*NONE	* " "
23. DATA TIME 1600 BPI	* "	* " "
24. ERASE GAP TIME	* "	*MB928 ROM*MB903 ACCL CNTR
25. WRITE FILE MARK	* "	* " " * " " "
26. TAPE SPEED-FORWARD	*FWD SPEED	*CAPSTAN SERVO LOOP
27. TAPE SPEED-REVERSE	*REVERSE SPEED	*CAPSTAN SERVO LOOP

*****NOTE: IF TIME PROBLEMS APPEAR IN T1 THRU T25, RUN TAPE SPEED TESTS FIRST*****
TEST 26 & 27 REQUIRE AN 800 BPI SKEW TAPE

TMO3 DRIVE FUNCTION TIMER

PAGE 15

7.3 SUBTEST DESCRIPTIONS:

THE FIRST THIRTEEN (13) TESTS (T1 - T15) ARE CHECKS OF THE ROM CIRCUITS IN THE TU45 (M9811), THE ACCL COUNTER IN THE TMO3 (M8903), AND THE SETTLEDOWN ONE SHOT (M8928).

T1. WRITE FROM BOT:

THIS TEST WILL MEASURE ACCELERATION DELAY REQUIRED TO MOVE THE TAPE APPROXIMATELY SEVEN (7) INCHES FORWARD FROM DEAD STOP AT BOT BEFORE STARTING TO TRANSFER DATA.

1. ASSURE TAPE IS STOPPED AT BOT.
2. ISSUE A WRITE COMMAND
3. MONITOR BIT 15 OF TC (ACCL)
4. TIME FROM GO TO ACCL RESET IS BOT DELAY
5. STOP

T2. WRITE START:

THIS TEST WILL MEASURE ACCELERATION DELAY JUST AS IN T1. HOWEVER THE TIME WILL BE LESS WHEN NOT STARTING FROM BOT.

1. LEAVE TAPE AT ITS PRESENT POSITION. ASSURE THAT IT IS STOPPED
2. ISSUE A WRITE COMMAND
3. MONITOR BIT 15 OF TC (ACCL)
4. TIME FROM GO TO RESET OF ACCL IS START DELAY
5. STOP

T3. WRITE SHUTDOWN:

THIS TEST WILL MEASURE THE TIME FROM EOR (LAST CHARACTER WRITTEN ON TAPE) TO THE START OF SETTLEDOWN TIME. THIS ASSURES, IN PART, A PROPER INTERROCORD GAP.

1. LEAVE TAPE AT ITS PRESENT POSITION. ASSURE THAT IT IS STOPPED
2. ISSUE A WRITE COMMAND.
3. MONITOR FRAME COUNTER AND BIT 4 OF DS (SDWN)
4. TIME FROM FC=0 TO ASSERTION OF SDWN IS THE SHUTDOWN TIME.
5. STOP

14. WRITE SETTLEDOWN:

THIS TEST WILL MEASURE THE SLOWDOWN TIME. THE TIME FROM THE START OF SLOWDOWN UNTIL THE TAPE SHOULD BE STOPPED. THIS IS A PART OF THE GAP TIMING IN LOGIC. THE MECHANICAL POSITIONING OF THE TAPE IN THE GAP DISTANCE WILL BE MEASURED IN A LATER TEST.

1. LEAVE TAPE AT ITS PRESENT POSITION. ASSURE THAT IT IS STOPPED
2. ISSUE A WRITE COMMAND
3. MONITOR BIT 4 OF DS (SDWN)
4. TIME FROM SET OF SDWN TO RESET OF SDWN IS THE SETTLEDOWN DELAY
5. STOP

15. READ FROM BOT

THIS MEASUREMENT IS MADE EXACTLY AS THE WRITE MEASUREMENT IN T1. USE THE SAME RECORD THAT WAS WRITTEN IN T1.

1. REWIND TO BOT
2. ASSURE TAPE HAS HAD TIME TO COME TO A COMPLETE STOP
3. READ FORWARD 1 RECORD.
4. MONITOR BIT 15 OF TC (ACCL)
5. TIME FROM GO TO ACCL IS BOT DELAY
6. STOP

T6. READ START

THIS TEST MEASURES THE SAME DELAY AS IN T2.

1. WRITE 1 RECORD, THEN BACKSPACE OVER IT, ASSURE TAPE IS STOPPED.
2. ISSUE A READ FORWARD OF THE RECORD WRITTEN IN STEP 1.
3. MONITOR BIT 15 OF TC (ACCL)
4. TIME FROM GO TO RESET OF ACCL IS START DELAY
5. STOP

T7. READ SHUTDOWN:

THIS TEST MEASURES THE SAME DELAY AS IN T3.

1. WRITE 1 RECORD, THEN BACKSPACE OVER IT, ASSURE TAPE IS STOPPED.
2. READ FORWARD THE RECORD WRITTEN IN STEP 1.
3. MONITOR FRAME COUNT AND BIT 4 OF DS (SDWN).
4. TIME FROM FC=RECORD SIZE (LAST FRAME READ) TO SDWN=1 IS THE SHUTDOWN TIME.
5. STOP

T10. READ SETTLEDOWN:

THIS TEST MEASURES THE SAME DELAY AS IN T4.

1. WRITE 1 RECORD, THEN BACKSPACE OVER IT, ASSURE TAPE IS STOPPED.
2. READ FORWARD THE RECORD WRITTEN IN STEP 1.
3. MONITOR BIT 4 OF DS (SDWN)
4. TIME FROM SET OF SDWN TO RESET OF SDWN IS THE SETTLEDOWN DELAY.
5. STOP

TMO3 DRIVE FUNCTION TIMER

PAGE 17

T11. READ REVERSE START:

THIS TEST WILL MEASURE THE START DELAY IN THE REVERSE DIRECTION.

1. WRITE 1 RECORD, ASSURE TAPE IS STOPPED.
2. READ REVERSE THE RECORD WRITTEN IN STEP 1.
3. MONITOR BIT 15 OF TC (ACCL)
4. THE TIME FROM GO TO RESET OF ACCL IS THE START TIME
5. STOP

T12. READ REVERSE SHUTDOWN

THIS TEST WILL MEASURE THE READ SHUTDOWN IN THE REVERSE DIRECTION.

1. WRITE 1 RECORD, ASSURE TAPE IS STOPPED.
2. READ REVERSE THE RECORD WRITTEN IN STEP 1.
3. MONITOR FRAME COUNTER AND BIT 4 OF DS (SDWN).
4. TIME FROM FC=RECORD SIZE (LAST FRAME READ) TO SDWN=1 IS THE READ REVERSE SHUTDOWN TIME.
5. STOP

T13. READ REVERSE SETTLEDOWN:

THIS TEST WILL MEASURE THE READ SETTLEDOWN IN THE REVERSE DIRECTION.

1. WRITE 1 RECORD, ASSURE TAPE IS STOPPED.
2. READ REVERSE THE RECORD WRITTEN IN STEP 1.
3. MONITOR BIT 4 OF DS (SDWN)
4. TIME FROM SET OF SDWN TO RESET OF SDWN IS THE SETTLEDOWN DELAY
5. STOP

T14. TURN AROUND DELAY-FORWARD TO REVERSE

THIS TEST WILL MEASURE THE TIME REQUIRED FOR THE TAPE TO CHANGE DIRECTION.

1. LEAVE TAPE AT ITS PRESENT POSITION. ASSURE THAT IT IS STOPPED
2. ISSUE A WRITE FORWARD OF AT LEAST 20 FRAMES
3. MONITOR BIT 7 OF DS (DRY)
4. WHEN DRY IS ASSERTED (EOR), IMMEDIATELY ISSUE A READ REVERSE OF THAT RECORD.
5. MONITOR BIT 15 OF TC (ACCL).
6. TIME FROM GO OF READ REVERSE TO RESET OF ACCL IS THE TURNAROUND TIME.
7. STOP

TMO3 DRIVE FUNCTION TIMER

PAGE 18

T15. TURN AROUND DELAY-REVERSE TO FORWARD

THIS TEST WILL MEASURE THE TIME AS IN T14, BUT IN THE OPPOSITE DIRECTION.

1. WRITE 1 RECORD.
2. ASSURE TAPE IS STOPPED
3. READ REVERSE
4. MONITOR DRY (BIT 7 OF DS)
5. WHEN DRY = 1, ISSUE A READ FORWARD
6. MONITOR ACCL (BIT 15 OF TC)
7. TIME FROM GO FORWARD TO ACCL = 1 IS THE TURN AROUND TIME.
8. STOP.

TM03 DRIVE FUNCTION TIMER

PAGE 19

GAP MEASUREMENTS:

THE PREVIOUS THIRTEEN (13) TESTS WERE MEASUREMENTS OF LOGIC DELAYS PERFORMED BY THE TM03 OR TU45 IN ORDER TO ALLOW FOR PROPER ACCELERATION AND DECELERATION OF TAPE ACCORDING TO THE DESIRED INTERCORD GAP (.6 INCHES). THIS TEST, HOWEVER, WILL MEASURE THE PHYSICAL SIZE OF THE INTERCORD GAP THAT EXISTS ON TAPE AS A RESULT OF THE START/STOP TIMES OF THE CAPSTAN ITSELF. BECAUSE THE INTERCORD GAP IS CREATED BY TWO ACTIONS, THE START OF MOTION AND THE STOP OF MOTION IT IS NECESSARY TO MAKE TWO SEPERATE MEASUREMENTS. A THIRD MEASUREMENT, MADE ON THE FLY, OF THE ENTIRE LENGTH OF THE GAP WILL ALSO BE MADE.

T16. GAP SIZE (STOP HALF)

THIS TEST WILL MEASURE THE DISTANCE TRAVLED BY THE TAPE IN A STOP CYCLE. IN OTHER WORDS, THE DISTANCE INTO THE IRG.

1. WRITE 1 RECORD.
2. ASSURE TAPE IS STOPPED.
3. ISSUE A READ REVERSE OVER THE RECORD
4. MONITOR THE FRAME COUNT FOR THE FIRST FRAME READ (FC = 1)
5. THE TIME FROM GO=1 TO FC=1 IS THE LENGTH OF THE GAP
6. STOP

T17. GAP SIZE (START HALF)

THIS TEST WILL MEASURE THE DISTANCE OF TAPE TRAVEL DURING START UP.

1. WRITE 1 RECORD, THEN REVERSE OVER IT, ASSURE TAPE IS STOPPED.
2. ISSUE A READ FORWARD
3. MONITOR FC FOR FC=1
4. TIME FROM GO=1 TO FC=1 IS START DISTANCE
5. STOP

T20. GAP SIZE (INTERRECORD)

THIS TEST WILL MEASURE THE ENTIRE LENGTH OF THE IRG ON THE FLG. THE TIME VALUE OF THIS TEST SHOULD NOT BE EQUAL TO A SUMMATION OF T16 AND T17 DUE TO THE FACT THAT THE ACCELERATION AND DECELERATION CURVES ARE NOT IN EFFECT. THE VALUE HERE SHOULD ACTUALLY BE LESS THAN THE SUM OF T16 AND T17.

1. WRITE 2 RECORDS.
2. READ REVERSE OVER THE SECOND RECORD
3. MONITOR DRY (BIT 7 OF DS)
4. WHEN DRY = 1, ISSUE A SECOND READ REVERSE
5. MONITOR FRAME COUNT
6. TIME FROM GO=1 OF SECOND READ REVERSE TO FC=1 IS THE LENGTH OF THE GAP.

CZTUSBO TM03/TU45 DRIVE FUNCTION TIMER MACY11 30A(1052) 15-MAY-80^{K 2} 08:34 PAGE 22-1
CZTUSB.P1; 15-MAY-80 08:31

SEQ 0023

7. STOP

TM03 DRIVE FUNCTION TIMER

PAGE 20

T21. GAP CONSISTENCY:

NOW THAT WE HAVE ESTABLISHED THAT THE INTERCORD GAP IS THE PROPER SIZE, LET US DETERMINE THE CONSISTENCY OF THE GAP UNDER VARIOUS COMMAND EXECUTION TIMES. BY WRITING A SERIES OF RECORDS, EACH WITH A DIFFERENT DELAY BETWEEN EXECUTION, WE CAN ESTABLISH THE CONSISTENCY OF THE GAPS BY READING THESE RECORDS AND MONITORING THEIR INTERRECORD GAPS, ON THE FLY.

1. REWIND TAPE TO BOT.
 2. WRITE ONE (1) RECORD TO GET TAPE OFF BOT
 3. WRITE SIXTEEN (16) RECORDS WITH A PROGRESSIVE DELAY OF FROM 0 TO 16 MILLISECONDS (APPROX) BETWEEN COMMANDS.
 4. BACKSPACE 16 RECORDS AND ALLOW THE TAPE TO STOP.
 5. READ FORWARD (NON-STOP) OVER THESE 16 RECORDS, EACH TIME MONITORING THE TIME FROM THE END OF RECORD (DRY) UNTIL THE FRAME COUNT NEXT GOES FROM 0 TO 1 (FC=1).
 6. THE TIMES FROM DRY TO FC=1 IS THE GAP TIME AND IT SHOULD REMAIN CONSISTANT FOR ALL RECORDS.
 7. STOP
- ** (SEE GTIMTBL IN LISTING FOR GAP TIMES)**

T22. DATA TIME AT 800 BPI:

THIS TEST WILL MEASURE THE TIME REQUIRED TO WRITE ONE (1) INCH OF TAPE AT 800 BPI. BY WRITING A RECORD OF ENOUGH FRAMES TO MOVE THE TAPE 1 INCH (800 FRAMES), DATA RATE CAN BE VARIFIED.

1. REWIND TO BOT AND ALLOW TAPE TO STOP
2. WRITE A RECORD AT 200 BPI.
3. MONITOR DRY (BIT 7 OF DS) FOR EACH RECORD
4. THE TIME FROM FC=FC+1 TO DRY WILL BE THE TIME REQUIRED FOR 1 INCH AT THE SELECTED DENSITY
5. STOP

T23. DATA TIME AT 1600 BPI (PE):
REPEAT STEPS 1 THRU 5 AT 1600 BPI.

TM03 DRIVE FUNCTION TIMER

PAGE 21

T24. ERASE:

THE ERASE COMMAND WILL CAUSE AN AREA OF THE THREE (3) INCHES TO BE DC ERASED IN THE FORWARD DIRECTION. THIS TEST WILL ASSURE THAT THE PROPER DISTANCE IS ERASED.

1. LEAVE TAPE AT ITS PRESENT POSITION.
2. ISSUE AN ERASE COMMAND.
3. MONITOR DRY (BIT 7 OF DS)
4. THE TIME FROM GO TO DRY WILL BE THE TIME REQUIRED TO ERASE 3 INCHES OF TAPE AND WILL REFLECT THE DISTANCE. DENSITY IS NOT A FACTOR.
5. STOP

T25. TAPE MARK:

THIS TEST IS ALSO A CHECK ON THE THREE (3) INCH GAP. WHEN A TAPE MARK IS WRITTEN, A 3 INCH GAP IS CREATED BEFORE DATA IS PUT ON TAPE.

1. LEAVE TAPE AT ITS PRESENT POSITION
2. ISSUE A WRITE TAPE MARK COMMAND
3. MONITOR DRY (BIT 7 OF DS)
4. THE TIME FROM GO TO DRY WILL BE THE TIME REQUIRED TO WRITE THE TM RECORD PLUS THE 3 INCH GAP.
5. STOP

TM03 DRIVE FUNCTION TIMER

T26. TAPE SPEED FORWARD:

THIS TEST REQUIRES THE USE OF AN 800 BPI SKEW TAPE!
THE OPERATOR WILL BE REQUIRED TO MOUNT THE SKEW TAPE
BEFORE EXECUTING THE TEST. THE SKEW TAPE IS THE ONLY
WAY TO ASSURE THAT TAPE IS MOVING AT THE PROPER SPEED
BECAUSE THE FREQUENCY OF FRAMES ON A SKEW TAPE IS
GUARANTEED TO BE ACCURATE.

1. ASSURE TAPE IS STOPPED AT BOT.
2. ISSUE A READ FORWARD (800 BPI, NORMAL)
3. MONITOR FC FOR FC = 800(10)
4. MONITOR FC FOR FC = 8800(10)
5. TIME FROM FC = 800 TO FC = 8800 IS THE TIME REQUIRED
FOR TAPE TO TRAVEL 10 INCHES
6. DIVIDE THE TIME FOR 10 INCHES BY 10.
7. THE RESULT IS AN AVERAGE SPEED FOR 1 INCH.
8. STOP.

T27. TAPE SPEED REVERSE:

THIS TEST IS THE SAME AS TEST 31, BUT SPEED IS
MEASURED IN THE REVERSE DIRECTION.

1. ADVANCE TAPE OFF OF BOT.
2. ISSUE A READ REVERSE.
3. REPEAT STEPS 3 THRU 6 IN THE REVERSE DIRECTION.
4. STOP.

x
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320

```

.LIST BIN,LOC,SEQ
.NLIST MC
.NLIST TOC
.LIST ME
.ENABLE ABS,AMA
.MCALL SCPVEC, $CPREG, $CATCH, $TYPE, .SACT11, .SEOP, $CHAIN
.TITLE CZTUSB0 TM03/TU45 DRIVE FUNCTION TIMER
.SBTTL STARTING INSTRUCTIONS
;LOADING AND STARTING PROCEDURE
LOAD PROGRAM USING ABS LOADER
LOAD ADDRESS 200
SET SWITCH OPTIONS
PRESS START

;RESTART PROCEDURE
LOAD ADDRESS 210
SET SWITCH OPTIONS
PRESS START

;SWITCH REGISTER SWITCH ASSIGNMENTS
SW15= 100000 ;HALT ON ERROR
SW14= 040000 ;LOOP SUBTEST
SW13= 020000 ;INHIBIT ERROR TYPE OUT

```

```

2321      004000      SW11= 004000      ;INHIBIT SUBTEST ITERATION
2322      002000      SW10= 002000      ;INHIBIT PUBLISHING TIME SPECIFICATION
2323      001000      SW09= 001000      ;RING BELL ON ERROR
2324      000400      SW08= 000400      ;TYPE LINE ITEM AFTER EACH ITERATION
2325      000200      SW07= 00200      ;NOT USED
2326      000100      SW06= 000100      ;CONTINUOUS CYCLE
2327      ;           SW05-SW00      ;RUN TEST SELECTED
2328      ;           ;*NOTE: IF <SW15-SW00> = 177777 AT STARTUP USE SOFTWARE
2329      ;           SWITCH REGISTER.
2330
2331      ;CONSOLE COMMANDS
2332      ;           CONTROL C           ;RESTART PROGRAM (SAME AS START @ 200)
2333      ;           CONTROL G           ;SET NEW SOFTWARE SWITCH REGISTER
2334      ;           CONTROL U           ;DELETE LINE TYPED
2335      ;           RUBOUT (DELETE)     ;DELETE LAST CHAR TYPED
2336
2337      ;GENERAL REGISTER USAGE:
2338      ;           R0=ADDRESS OF 'FC' REGISTER (SET BY SCOPE)
2339      ;           R1=ADDRESS OF 'DS' REGISTER (SET BY SCOPE)
2340      ;           R2=RETURN PC FROM TIMER (SET BY EACH TEST)
2341      ;           R3=INDEX INDICATING PREVIOUS OSCILLATOR POLARITY (SET BY TIMER)
2342      ;           R4=CONTAINS 'TICK' COUNT WHEN TIMER IS RUNNING (SET BY TIMER)
2343      ;           R5=ADDRESS OF CS1 (SET BY SCOPE)
2344
2345      .SBTTL  MACRO DEFINITIONS
2346      .MACRO  SAVE
2347      JSR    PC,.SAVE                ;SAVE REGISTERS ON THE STACK
2348      .ENDM  SAVE
2349      .MACRO  RESTORE
2350      JSR    PC,.RESTORE             ;RESTORE REGISTERS FROM THE STACK
2351      .ENDM  RESTORE
2352      .MACRO  INPUT
2353      JSR    PC,.INPUT               ;GET USER INPUT
2354      .ENDM  INPUT
2355      .MACRO  REWIND
2356      JSR    PC,.REWIND              ;REWIND SLAVE
2357      BVS    99$                     ;BRANCH IF ERROR ON REWIND
2358      .ENDM  REWIND
2359      .MACRO  TIMEON
2360      JSR    PC,.TIMON               ;TURN TIMER ON
2361      .ENDM  TIMEON
2362      .MACRO  TIMCHK
2363      JMP    TIMER(R3)               ;GO TO TIMER & RETURN VIA R2
2364      .ENDM  TIMCHK
2365      .MACRO  SETGO
2366      INC    (R5)                    ;SET 'GO' BIT
2367      .ENDM  SETGO
2368
2369      .SBTTL  REGISTER ASSIGNMENTS
2370      ;;DEFINITIONS AND REGISTER ASSIGNMENTS
2371      ;;GENERAL REGISTER ASSIGNMENTS
2372      (1)      000000      R0=X0
2373      (1)      000001      R1=X1
2374      (1)      000002      R2=X2
2375      (1)      000003      R3=X3
2376      (1)      000004      R4=X4
  
```

```

(1)      000005      R5=%5
(1)      000006      SP=%6
(1)      000007      PC=%7
(1)      000000      R10=%0
(1)      000001      R11=%1
(1)      000002      R12=%2
(1)      000003      R13=%3
(1)      000004      R14=%4
(1)      000005      R15=%5
(1)
(1)
(1)      177776      ;;REGISTER ADDRESSES
(1)      177774      PSW= 177776      ;;PROCESSER STATUS WORD
(1)      177774      SLR= 177774      ;;STACK LIMIT REGISTER (11/40,11/45)
(1)      177772      PIRQ= 177772      ;;PROGRAM INTERRUPT REQ. (11/45)
(1)      177770      UBREAK= 177770      ;;MICRO-BREAK REGISTER (11/45)
(1)      177560      TKS= 177560      ;;KEYBOARD CSR
(1)      177562      TKB= 177562      ;;KEYBOARD DATA BUFFER REGISTER
(1)      177564      TPS= 177564      ;;TELEPRINTER CSR
(1)      177566      TPB= 177566      ;;TELEPRINTER DATA BUFFER REGISTER
(1)
(1)
2371      ;;VECTOR ADDRESSES
(1)      000004      ERRVEC=4      ;;ADDRESS OF ERRGR VECTOR
(1)      000010      RESVEC=10      ;;ADDRESS OF RESERVED INST. TRAP VECTOR
(1)      000014      TBITVEC=14      ;;ADDRESS OF 'T' BIT TRAP VECTOR
(1)      000014      TRTVEC=14      ;;ADDRESS OF 'TRACE' TRAP VECTOR
(1)      000014      BPTVEC=14      ;;ADDRESS OF 'BREAKPOINT' TRAP VECTOR
(1)      000020      IOTVEC=20      ;;ADDRESS OF IOT TRAP VECTOR
(1)      000024      PFVEC=24      ;;ADDRESS OF POWER FAIL TRAP VECTOR
(1)      000030      EMTVEC=30      ;;ADDRESS OF EMT VECTOR
(1)      000034      TRAPVEC=34      ;;ADDRESS OF TRAP VECTOR
(1)      000060      TKVEC= 60      ;;ADDRESS OF TTY KEYBOARD INT. VECTOR
(1)      000064      TPVEC=64      ;;ADDRESS OF TTY PRINTER INTERRUPT VECTOR
(1)      000114      PARVEC= 114      ;;ADDRESS OF MA/MF PARITY ERROR VECTOR
(1)      000240      PIRVEC=240      ;;ADDRESS OF PIRQ VECTOR
(1)      000244      FPEVEC=244      ;;ADDRESS OF FLOATING POINT INT. VECTOR
(1)      000250      MMVEC=250      ;;ADDRESS OF MEM MGMT ERROR TRAP VECTOR
(1)
(1)
2372      ;CLOCK ADDRESS AND VECTORS
2373      172540      PLKCSR= 172540      ;KW11-P
2374      000104      PLKVEC= 104      ;KW11-L
2375      177546      LKS= 177546      ;KW11-L
2376      000100      LKVEC= 100      ;LP11
2377      177514      LPS= 177514
2378      177516      LPB= 177516
2379
2380      ;RH, TM03/TU45 REGISTERS
2381      172440      TMCS1= 172440
2382
2383      ;TM03/TU45 INDEX VALUES
2384      000000      CS1= 00      ;CONTROL STATUS #1
2385      000002      WC= 02
2386      000004      BA= 04      ;BUS ADDRESS REGISTER
2387      000006      FC= 06      ;FRAME COUNT
2388      000010      CS2= 10      ;CONTROL STATUS #2
2389      000012      DS= 12      ;DRIVE STATUS
2390      000014      ER= 14      ;ERROR REG #1
    
```

2391	000016	AS=	16	;ATTENTION SUMMARY
2392	000022	DB=	22	;DATA BUFFER REG
2393	000024	MR=	24	;MAINTENANCE REG
2394	000026	DT=	26	;DRIVE TYPE REG
2395	000030	SN=	30	;SERIAL NUMBER REGISTER
2396	000032	TC=	32	;TAPE CONTROL REG

.SBTTL TM03/TU45 REGISTER BITS

2397				
2398				
2399		:RHCS1-(S1(R5)		
2400	000001	GO=	1	
2401	000000	NOP=	0	
2402	000002	RWDOFF=	2	
2403	000006	RWD=	6	
2404	000010	DRYCLR=	10	
2405	000026	WFMK=	26	
2406	000024	ERASE=	24	
2407	000030	SPCFWD=	30	
2408	000032	SPCREV=	32	
2409	000050	WCHKF=	50	
2410	000056	WCHKR=	56	
2411	000060	WFWD=	60	
2412	000070	PDFWD=	70	
2413	000076	RDREV=	76	
2414	000100	IE=	100	
2415	000200	RDY=	200	
2416	000400	A16=	400	
2417	001000	A17=	1000	
2418	002000	PSEL=	2000	
2419	004000	DVA=	4000	
2420	020000	MCPE=	20000	
2421	040000	TRE=	40000	
2422	100000	SC=	100000	
2423		:RHCS2-(S2(R5)		
2424	000000	DV0=	0	
2425	000001	DV1=	1	
2426	000002	DV2=	2	
2427	000003	DV3=	3	
2428	000004	DV4=	4	
2429	000005	DV5=	5	
2430	000006	DV6=	6	
2431	000007	DV7=	7	
2432	000010	BA1=	10	
2433	000020	PAT=	20	
2434	000040	CLR=	40	
2435	000100	IR=	100	
2436	000200	OR=	200	
2437	000400	MDPE=	400	
2438	001000	MXF=	1000	
2439	002000	PGE=	2000	
2440	004000	NEM=	4000	
2441	010000	NED=	10000	
2442	020000	UPE=	20000	
2443	040000	WCE=	40000	
2444	100000	DLT=	100000	
2445		:RHDS-DS(R5)		
2446	000001	SLA=	1	

2447	000002	BOT=	2
2448	000004	TMK=	4
2449	000010	IDB=	10
2450	000020	SDWN=	20
2451	000040	PES=	40
2452	000100	SSC=	100
2453	000200	DRY=	200
2454	000400	DPR=	400
2455	002000	EOT=	2000
2456	004000	WRL=	4000
2457	010000	MOL=	10000
2458	020000	PIP=	20000
2459	040000	ERR=	40000
2460	100000	ATA=	100000
2461		;RHER-ER(R5)	
2462	000001	ILF=	1
2463	000002	ILR=	2
2464	000004	RMR=	4
2465			
2466	000020	FMT=	20
2467	000100	INCVAE=	100
2468	000200	PEFLRC=	200
2469	000400	NSG=	400
2470	001000	FCE=	1000
2471	002000	CSITM=	2000
2472	004000	NEF=	4000
2473	010000	DTE=	10000
2474	020000	OPI=	20000
2475	040000	UNS=	40000
2476			
2477		;RHMR-MR(R5)	
2478	000100	OSC=	100
2479			
2480		;RHDT-DT(R5)	
2481	002000	SPR=	2000
2482	010000	CH7=	10000
2483	040000	TAP=	40000
2484			
2485		;RHTC-TC(R5)	
2486	001700	NORM11=	1700
2487	000320	CDM11=	320
2488	000000	BPI200=	0
2489	000400	BPI556=	000400
2490	001000	BPI800=	001000
2491	002300	PE1600=	002300
2492	100000	ACCL=	100000
2493			
2494			
2495			
2496		;INSTRUCTION EQUATES	
2497	104400	HLT=	TRAP
2498	104000	SCOPE=	EMT
2499	000004	TYPE=	IOT
2500			
2501		;MISCELLANEOUS EQUATES	
2502	005650	OUTBUF=	INIT

;OUTPUT BUFFER STARTS AT BEG OF PROGRAM

2503 177400
2504 177600
2505
2506 000001
2507 000003
2508 000007
2509 000011
2510 000012
2511 000015
2512 000017
2513 000025

FRMCNT= -256.
WRDCNT= -128.
;ASCII EQUATES
CNTRLA= 1
CNTRLC= 3
CNTRLG= 7
HT= 11
LF= 12
CR= 15
CNTRLO= 17
CNTRLU= 25

;FRAME COUNT
;WORD COUNT
;ASCII CODE FOR CONTROL A (^A)
;ASCII CODE FOR CONTROL C (^C)
;ASCII CODE FOR CONTROL G (^G)
;ASCII CODE FOR HORIZONTAL TAB
;ASCII CODE FOR LINE FEED
;ASCII CODE FOR CARRIAGE RETURN
;ASCII CODE FOR CONTROL O (^O)
;ASCII CODE FOR CONTROL U (^U)

```

2516
2517
2518 000014 000014
2519 000016 000000
2520 000020 002130
2521 000022 000000
2522 000024 000026
2523 000026 000000
2524 000030 004010
2525 000032 000340
2526 000034 003544
2527 000036 000340
2528
(1)
(1)
(1)
(1) 000046 012712
(1)
(1) 000052 000000
(1)
(1)
2529
2530 000060 003420
2531 000062 000200
2532
2533
2534
2535 000176 000100
2536
2537
2538 000200 000137 005650
2539
2540 000210 000137 006756
2541
2542
2543
2544
2545
2546
2547 001000 177570
2548 001002 000000
2549 001004 000
2550 001005 000
2551 001006 000000
2552 001010 172440
2553 001012 000000
2554 001014 000020
2555
2556 001054 000020
2557 001114 000000
2558 001116 000000
2559 001120 000
2560 001121 000
2561 001122 000
2562 001123 000
2563 001124 000

;SETUP TRAP VECTORS
.=TBITVEC
.WORD .+2 ;SET 'T' TRAP TO TIMER ROUTINE
.WORD HALT ;PRIORITY LEVEL 7
.WORD .TYPE ;SET IOT TRAP TO .TYPE ROUTINE
.WORD 0 ;PRIORITY LEVEL 0
.WORD PFVEC+2 ;POWER FAIL TRAP TO HALT
.WORD HALT ;AT PFVEC+2
.WORD .SCOPE ;SET EMT TRAP TO .SCOPE ROUTINE
.WORD 340 ;PRIORITY LEVEL 7
.WORD .HLT ;SET TRAP TRAP TO .HLT ROUTINE
.WORD 340 ;PRIORITY LEVEL 7

;ACT11 HOOK *****
$SVPC= . ;SAVE CURRENT LOCATION CTR
.=46
.WORD $ENDAD ;SET LOCATION 46
.=52
.WORD 0 ;SET LOCATION 52 = 0
.=$SVPC ;RESTORE LOCATION CTR

.=TKVEC
.WORD TKISR
.WORD 200

;SOFTWARE SWITCH REGISTER LOC. 176
.=176
SWREG: .WORD SW06 ;SOFTWARE SWITCH REGISTER

.=200
JMP @#INIT ;GO TO START OF PROGRAM
.=210
JMP @#RSTRT ;RESTART ADDRESS

.=500
STKPTR= 600 ;STACK

.=1000
;PROGRAM TAGS
SWR: 177570 ;SWITCH REGISTER
SCPADR: .WORD 0
DRVNUM: .BYTE 0 ;TMO3 DRIVE UNDER TEST
SLVNUM: .BYTE 0 ;TU45 SLAVE UNDER TEST
SLVPTR: .WORD 0 ;POINTER TO SLAVE TABLE (SLVTBL) BELOW
TMBASE: .WORD TMCS1 ;BASE ADDRESS OF TMO3/TU45 REGISTERS
ATIME: .WORD 0 ;CONTAINS 'TICK' COUNT
ATIMTBL: .BLKW 16. ;EACH ENTRY CONTAINS TIME FOR FUNCTION
;ENTRIES ARE MADE BY 'SCOPE' ROUTINE
;TIMES RECORDED BY 'GAP CONSISTANCY' TEST

GAPTBL: .BLKW 16.
DELTIM: .WORD 0 ;VARIABLE DELAY
OCTALO: .WORD 0
GAP: .BYTE 0 ;CONTAINS GAP # (USED FOR TST 021)
ITCNT: .BYTE 0 ;ITERATION COUNT
TSTNUM: .BYTE 0 ;TEST #
ERFLG: .BYTE 0 ;ERROR FLAG
PRGFLG: .BYTE 0 ;PROGRAM FLAG
    
```


2564 001125 000
 2565 001126 000
 2566 001127 000
 2567 001130 000
 2568 001132 001132
 2569 001132 030460
 2570 001134 031462
 2571 001136 032464
 2572 001140 033466
 2573 001142 034470
 2574 001144 000006
 2575 001152 000
 2576 001154 001154
 2577 001154 000010
 2578 001164 000100
 2579 001264 000110
 2580 001374 005015 000
 2581 001377 134 000
 2582 001401 060 000
 2583 001403 007 000
 2584 001405 055 000
 2585 001407 040
 2586 001410 000040
 2587 001412 004476 000
 2588 001416 001416

UNTFND: .BYTE 0 ;UNIT FOUND INDICATOR
 TYPFLG: .BYTE 0
 PSCNT: .BYTE 0 ;CONTAINS PASS COUNT
 ASFLG: .BYTE 0 ;1/0 = YES/NO.
 .EVEN
 DIGTAB: '01
 '23
 '45
 '67
 '89
 ODIGITS: .BLKB 6 ;RESERVE SPACE FOR CONVERTED DIGITS
 .BYTE 0 ;TERMINATOR
 .EVEN
 DRVTBL: .BLKB 8. ;A 0/-1 = DRIVE NOT TO BE/TO BE TESTED
 SLVTBL: .BLKB 64. ;A 0/-1 = SLAVE NOT TO BE/TO BE TESTED
 INBUF: .BLKB 72. ;TELETYPE INPUT BUFFER
 CRLF: .ASCIZ <CR><LF> ;MISCELLANEOUS ASCII CHARACTERS
 BKSLSH: .ASCIZ '\'
 ECHO: .ASCIZ '0'
 BELL: .ASCIZ <7>
 DASH: .ASCIZ '-'
 SPACE2: .ASCIZ ' '
 SPACE: .ASCIZ ' '
 ANGTAB: .ASCIZ '>'<HT>
 .EVEN

2590
 2591
 2592
 2593
 2594
 2595
 2596
 2597
 2598
 2599
 2600
 2601
 2602
 2603
 2604
 2605
 2606
 2607
 2608
 2609
 2610
 2611
 2612
 2613
 2614
 2615
 2616
 2617
 2618
 2619
 2620
 2621
 2622

001416 000000 000000
 001422 014234 013414
 001426 000702 000562
 001432 000550 000404
 001436 001370 000214
 001442 001630 001010
 001446 000252 000132
 001452 000221 000043
 001456 001370 000214
 001462 000252 000132
 001466 000276 000226
 001472 001370 000214
 001476 001560 000430
 001502 001560 000430
 001506 001426 000702
 001512 001527 001015
 001516 001147 000675
 001522 001301 001027
 001526 002260 002114
 001532 002342 002176
 001536 011576 011122
 001542 012000 011470
 001546 002152 002006
 001552 002152 002006

.SBTTL TIME SPECIFICATION TABLE
 :THE BELOW TABLE CONTAINS THE SPECIFIED FUNCTION TIMES IN TENS OF
 :MICROSECONDS. NOTE THAT WHEN TIMES ARE TYPED THAT THEY ARE TYPED IN
 :MICROSECONDS (BY APPENDING A 0).
 :FORMAT IS
 : .WORD MAX,MIN :TIME IN MS FUNCTION TEST #

.WORD	MAX,MIN	:TIME IN MS	FUNCTION	TEST #
STIMBL: .WORD	0,0	:SPARE		
.WORD	6300.,5900.	:63.0-59.0	WRITE FROM BOT	TST001
.WORD	00450.,00370.	:4.5-3.7	WRITE START	TST002
.WORD	00360.,00260.	:3.6-2.6	WRITE SHUTDOWN	TST003
.WORD	00760.,00140.	:7.6-1.4	WRITE STLDOWN	TST004
.WORD	00920.,00520.	:9.2-5.2	READ FROM BOT	TST005
.WORD	00170.,00090.	:1.7-0.9	READ START	TST006
.WORD	00145.,00035.	:1.45-0.35	READ SHUTDOWN	TST007
.WORD	00760.,00140.	:7.6-1.4	READ SETTLEDOWN	TST010
.WORD	00170.,00090.	:1.7-0.9	RD REV START	TST011
.WORD	00190.,00150.	:1.9-1.5	RD REV SHTDWN	TST012
.WORD	00760.,00140.	:7.6-1.4	RD REV STLDWN	TST013
.WORD	00880.,00280.	:8.8-2.8	TRN RND DLY F-R	TST014
.WORD	00880.,00280.	:8.8-2.8	TRN RND DLY R-F	TST015
.WORD	00790.,00450.	:7.9-4.5	GAP SIZE STOP	TST016
.WORD	00855.,00525.	:8.55-5.25	GAP SIZE STRT	TST017
.WORD	00615.,00445.	:6.15-4.45	GAP SIZE INTER	TST020
.WORD	00705.,00535.	:7.05-5.35	GAP CONSISANCY	TST021
.WORD	01200.,01100.	:12.0-11.0	DAT TIME 800BPI	TST022
.WORD	01250.,01150.	:12.5-11.5	DAT TIME 1600PE	TST023
.WORD	04990.,04690.	:49.9-46.9	ERASE	TST024
.WORD	05120.,04920.	:51.2-49.2	WRT FILE MARK	TST025
.WORD	01130.,01030.	:11.3-10.3	TAPE SPEED FWD	TST026
.WORD	01130.,01030.	:11.3-10.3	TAPE SPEED REV	TST027

:NOTE: TEST 26 AND 27 REQUIRE PRERECORDED 800BPI SKEW TAPE.

2624
 2625
 2626
 2627
 2628
 2629
 2630
 2631
 2632
 2633
 2634
 2635
 2636
 2637
 2638
 2639
 2640
 2641
 2642
 2643
 2644
 2645
 2646

001556 001274 001041
 001562 001344 001200
 001566 001370 001154
 001572 001274 001060
 001576 001306 000776
 001602 001351 000707
 001606 001351 000733
 001612 001351 000733
 001616 001274 000764
 001622 001262 000764
 001626 001262 000764
 001632 001262 000764
 001636 001262 000764
 001642 001262 000764
 001646 001262 000764
 001652 001262 000764

.SBTTL GAP TIME SPECIFICATION TABLE
 ;THIS TABLE CONTAINS THE GAP SIZES (IN TENS OF MICROSECONDS) FOR EACH
 ;OF THE 16. GAPS RECORDED BY THE GAP CONSISTANCY TEST (TST021).
 ;NOTE: GAP #'S ARE IN OCTAL.

;	.WORD	MAX,MIN(10)	;TIME IN MS(10)	GAP #	DELAY IN MS(10)
GTIMTBL:	.WORD	00700.,00545.	:7.00-5.45	GAP-0	0 MS
	.WORD	00740.,00640.	:7.4-6.4	GAP-1	1.0 MS
	.WORD	00760.,00620.	:7.6-6.2	GAP-2	2.0 MS
	.WORD	00700.,00560.	:7.0-5.6	GAP-3	3.0 MS
	.WORD	00710.,00510.	:7.1-5.1	GAP-4	4.0 MS
	.WORD	00745.,00455.	:7.45-4.55	GAP-5	5.0 MS
	.WORD	00745.,00475.	:7.45-4.75	GAP-6	6.0 MS
	.WORD	00700.,00500.	:7.0-5.0	GAP-7	7.0 MS
	.WORD	00690.,00500.	:6.9-5.0	GAP-10	8.0 MS
	.WORD	00690.,00500.	:6.9-5.0	GAP-11	9.0 MS
	.WORD	00690.,00500.	:6.9-5.0	GAP-12	10.0 MS
	.WORD	00690.,00500.	:6.9-5.0	GAP-13	11.0 MS
	.WORD	00690.,00500.	:6.9-5.0	GAP-14	12.0 MS
	.WORD	00690.,00500.	:6.9-5.0	GAP-15	13.1 MS
	.WORD	00690.,00500.	:6.9-5.0	GAP-16	14.1 MS
	.WORD	00690.,00500.	:6.9-5.0	GAP-17	15.1 MS

2648
2649
2650 001656 000000
2651 001660 015103
2652 001662 015125
2653 001664 015145
2654 001666 015167
2655 001670 015213
2656 001672 015235
2657 001674 015254
2658 001676 015276
2659 001700 015321
2660 001702 015343
2661 001704 015370
2662 001706 015417
2663 001710 015450
2664 001712 015501
2665 001714 015527
2666 001716 015556
2667 001720 015606
2668 001722 015631
2669 001724 015655
2670 001726 015702
2671 001730 015724
2672 001732 015747
2673 001734 015771
2674
2675
2676 001736 007224
2677 001740 007474
2678 001742 007560
2679 001744 007636
2680 001746 007726
2681 001750 010034
2682 001752 010120
2683 001754 010204
2684 001756 010304
2685 001760 010424
2686 001762 010522
2687 001764 010632
2688 001766 010772
2689 001770 011064
2690 001772 011172
2691 001774 011266
2692 001776 011376
2693 002000 011516
2694 002002 012022
2695 002004 012152
2696 002006 012302
2697 002010 012422
2698 002012 012764
2699 002014 013112

.SBTTL TEST HEADER POINTERS
;THE BELOW TABLE CONTAINS POINTERS TO EACH TEST'S DESCRIPTOR
NAMPTR: .WORD 0

.WORD A.T001
.WORD A.T002
.WORD A.T003
.WORD A.T004
.WORD A.T005
.WORD A.T006
.WORD A.T007
.WORD A.T010
.WORD A.T011
.WORD A.T012
.WORD A.T013
.WORD A.T014
.WORD A.T015
.WORD A.T016
.WORD A.T017
.WORD A.T020
.WORD A.T021
.WORD A.T022
.WORD A.T023
.WORD A.T024
.WORD A.T025
.WORD A.T026
.WORD A.T027

;TABLE OF TEST STARTING ADDRESSES
TSTTBL: .WORD TST000

.WORD TST001
.WORD TST002
.WORD TST003
.WORD TST004
.WORD TST005
.WORD TST006
.WORD TST007
.WORD TST010
.WORD TST011
.WORD TST012
.WORD TST013
.WORD TST014
.WORD TST015
.WORD TST016
.WORD TST017
.WORD TST020
.WORD TST021
.WORD TST022
.WORD TST023
.WORD TST024
.WORD TST025
.WORD TST026
.WORD TST027

```

2701 002016 000000          TIB: .WORD 0
2702                               ;ROUTINE TO LOAD SSOFTWARE SWR
2703
2704 002020 022737 000176 001000 GTSWR: CMP #SWREG,SWR ;BRANCH IF SOFTWARE SWR
2705 002026 001027          BNE 2$ ;NOT INVOKED
2706 002030 004737 002354 001000 JSR PC,SAVE ;SAVE REGISTERS ON THE STACK
2707 002034 000004 016020          TYPE,L,SWR
2708 002040 017702 176734          MOV @SWR,R2
2709 002044 004737 002426          JSR PC,TYPECT
2710 002050 000004 016027          TYPE,L,NEW
2711 002054 004737 003272          JSR PC,INPUT ;GET USER INPUT
2712 002060 122737 000015 001264 CMPB #CR,@INBUF ;EXIT IF FIRST CHAR IS <CR>
2713 002066 001405          BEQ 1$
2714 002070 004737 003056          JSR PC,CNVTAO ;CONERT ASCII TO OCTAL
2715 002074 013777 001116 176676 MOV @OCTALO,@SWR ;SET NEW SWITCH REG CONTENTS
2716 002102 004737 002376          JSR PC,RESTORE
2717 002106 000207          2$: RTS PC
2718
2719
2720                               .SBTTL PROGRAM SUBROUTINES
2721                               .SBTTL TYPE SUBROUTINE
2722                               ;;ROUTINE TO TYPE ASCII MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
(1)                               ;;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
(1)                               ;;CALL: TYPE ;A TRAP TYPE INSTRUCTION
(1)                               ;; MESADR ;MESADR IS FIRST ADDRESS OF ASCII STRING
(1)
(1)                               ;;TAGS USED BY THE TYPE ROUTINE BELOW
(1)                               $HT=11 ;:HORIZONTAL TAB
(1) 002110 000          $NULL: .BYTE 0 ;:CONTAINS NULL CHARACTER
(1) 002111 002          $FILL: .BYTE 2 ;:CONTAINS # OF FILLER CHARACTERS
(1) 002112 000          $TPFLG: .BYTE 0 ;:CONTAINS TELEPRINTER AVAILABLE FLAG
(1)                               ;:0/377 = AVAIL/NOT AVAIL
(1) 002113 000          $TKFLG: .BYTE 0 ;:CONTAINS KEYBOARD AVAILABLE FLAG
(1) 002114 177564          $TPS: .WORD 177564 ;:ADDRESS OF TELEPRINTER STATUS REGISTER
(1) 002116 177566          $TPB: .WORD 177566 ;:ADDRESS OF TELEPRINTER DATA BUFFER
(1) 002120 000          $CHARCNT: .BYTE 0 ;:CONTAINS # OF CHARS TYPED
(1) 002121 000          $CNTRLO: .BYTE 0 ;:CONTAINS CONTROL 0 CHAR (IF TYPED)
(1) 002122 005015 000          $CRLF: .ASCII <15><12>
(1) 002126 000000          RDSW: .WORD 0
(1)
(1) 002130 010046          .TYPE: MOV R0,-(SP) ;:SAVE R0
(1) 002132 017600 000002          MOV @2(SP),R0 ;:GET MESSAGE ADDRESS
(1) 002136 062766 000002 000002          ADD #2,2(SP) ;:ADJUST RETURN PC
(1) 002144 105037 002121          CLRB $CNTRLO
(1)
(1) 002150 105737 002121          TYPE1: TSTB $CNTRLO ;:BRANCH IF CONTROL 0(^O) WASN'T TYPED
(1) 002154 001410          BEQ TYPE2
(1) 002156 000004 002122          TCRLF: TYPE,$CRLF ;:TYPE <CR><LF>
(1) 002162 105737 002126          TSTB RDSW
(1) 002166 100006          BPL TYPE3
(1) 002170 005037 002126          CLR RDSW
(1) 002174 000207          RTS PC
(1) 002176 112046          TYPE2: MOVB (R0)+,-(SP) ;:PUSH CHARACTER TO BE TYPED ONTO STACK
(1) 002200 001003          BNE TYPE4 ;:BRANCH IF NOT THE TERMINATOR
(1) 002202 005726          TST (SP)+ ;:POP TERMINATOR CHAR OFF THE STACK

```

```

(1) 002204 012600 TYPE3: MOV (SP)+,R0 ;;RESTORE R0
(1) 002206 000002 RTI ;;RETURN TO CALLER
(1)
(1) 002210 122716 000011 TYPE4: CMPB #SHT,(SP) ;;BRANCH IF HORIZONTAL TAB <HT>
(1) 002214 001445 BEQ 9$
(1) 002216 004737 002250 JSR PC,5$ ;;TYPE CHARACTER
(1) 002222 122726 000012 3$: CMPB #12,(SP)+ ;;CHECK IF CHARACTER WAS A LINE FEED
(1) 002226 001350 BNE TYPE1 ;;BRANCH IF NOT LINE FEED
(1) 002230 013746 002110 MOV $NULL,-(SP) ;;GET # OF FILLERS REQUIRED AND FILLER
(1) ;;CHARACTER.
(1)
(1) 002234 105366 000001 4$: DECB 1(SP) ;;DECREMENT FILLERS REQ. COUNT
(1) 002240 002770 BLT 3$ ;;BRANCH IF NO MORE FILLERS ARE REQUIRED
(1) 002242 004737 002250 JSR PC,5$ ;;TYPE FILLER CHARACTER
(1) 002246 000772 BR 4$
(1)
(1) 002250 105777 177640 5$: TSTB @STPS ;;WAIT FOR OUTPUT DEVICE
(1) 002254 100375 BPL -4
(1) 002256 122737 000017 002121 CMPB #17,@#SCNTRLO ;;CHECK IF CONTROL O WAS TYPED
(1) 002264 001403 BEQ 6$ ;;STOP TYPING MESSAGE IF ^O WAS TYPED
(1) 002266 116677 000002 177622 MOVB 2(SP),@STPB ;;OUTPUT CHARACTER
(1) 002274 122766 000015 000002 6$: CMPB #15,2(SP) ;;BRANCH IF NOT <CR>
(1) 002302 001003 BNE 7$
(1) 002304 105037 002120 CLRB $CHARCNT ;;CLEAR CHARACTERS TYPED COUNT
(1) 002310 000406 BR 8$
(1) 002312 122766 000012 000002 7$: CMPB #12,2(SP) ;;BRANCH IF <LF> OR 'NULL'
(1) 002320 002002 BGE 8$
(1) 002322 105237 002120 INCB $CHARCNT ;;INCREMENT CHARACTER TYPED COUNT
(1) 002326 000207 8$: RTS PC
(1)
(1) ;;HORIZONTAL TAB <HT> PROCESSER
(1) 002330 112716 000040 9$: MOVB #40,(SP) ;;LOAD 'SPACE'
(1) 002334 004737 002250 10$: JSR PC,5$ ;;TYPE 'SPACE'
(1) 002340 132737 000007 002120 BITB #7,$CHARCNT ;;TYPE SPACES UNTIL A MULTIPLE
(1) 002346 001372 BNE 10$ ;;OF 8 CHARACTERS HAVE BEEN TYPED
(1) 002350 105726 TSTB (SP)+ ;;POP SPACE
(1) 002352 000676 BR TYPE1 ;;GET NEXT CHARACTER
2723
2724 ;SUBROUTINE TO SAVE GENERAL REGISTERS ON THE STACK
2725 ;CALL: SAVE
2726 002354 010546 .SAVE: MOV R5,-(SP) ;SAVE REGISTERS ON THE STACK
2727 002356 010446 MOV R4,-(SP)
2728 002360 010346 MOV R3,-(SP)
2729 002362 010246 MOV R2,-(SP)
2730 002364 010146 MOV R1,-(SP)
2731 002366 010046 MOV R0,-(SP)
2732 002370 016646 000014 MOV 14(SP),-(SP) ;GET RETURN PC
2733 002374 000207 RTS PC ;RETURN
2734
2735 ;SUBROUTINE TO RESTORE GENERAL REGISTERS FROM THE STACK
2736 ;CALL: RESTORE
2737 002376 012666 000014 .RESTORE:MOV (SP)+,14(SP) ;MOVE RETURN PC
2738 002402 012600 MOV (SP)+,R0 ;RESTORE REGISTERS
2739 002404 012601 MOV (SP)+,R1
2740 002406 012602 MOV (SP)+,R2
2741 002410 012603 MOV (SP)+,R3

```

```

2742 002412 012604      MOV      (SP)+,R4
2743 002414 012605      MOV      (SP)+,R5
2744 002416 000207      RTS      PC                ;RETURN
2745
2746      ;SUBROUTINE TO CONVERT OCTAL DATA TO ASCII
2747      ;CALL: MOV      NUMBER,R2          ;MOVE NUMBER TO R2
2748      ;      JSR      PC,CNVOCT
2749
2750 002420 110637 001126  CNVOCT: MOVVB   SP,TYPFLG          ;SET DO NOT TYPE FLAG
2751 002424 000402      BR      CNVTO
2752
2753      .SBTTL      OCTAL TO ASCII & TYPE ROUTINE
2754      ;SUBROUTINE TO CONVERT OCTAL NUMBER TO ASCII AND TYPE IT OUT
2755      ;CALL: MOV      NUMBER,R2          ;PUT # IN R2
2756      ;      JSR      PC,TYPOCT        ;CALL ROUTINE
2757
2758 002426 105037 001126  TYPOCT: CLRB   @#TYPFLG          ;SET TYPE FLAG
2759 002432      CNVTO:
2760      (1) 002432 004737 002354      JSR      PC,SAVE              ;SAVE REGISTERS ON THE STACK
2761 002436 012704 001144      MOV      #ODIGITS,R4        ;SET PTR TO OUTPUT
2762 002442 005003      CLR      R3                ;R3 WILL CONTAIN OCTAL DIGIT
2763 002444 010201      MOV      R2,R1             ;GET # TO BE TYPED
2764 002446 006302 1$: ASL      R2                ;SHIFT #
2765 002450 006103      ROL      R3
2766 002452 012700 000006      MOV      #6,R0             ;SET DIGIT COUNTER
2767 002456 000404      BR      3$
2768 002460 006302 2$: ASL      R2                ;SHIFT # 3 PLACES LEFT
2769 002462 006103      ROL      R3
2770 002464 005301      DEC      R1
2771 002466 001374      BNE      2$
2772 002470 012701 000003 3$: MOV      #3,R1             ;SET SHIFT COUNTER
2773 002474 116324 001132      MOVVB   DIGTAB(R3),(R4)+    ;MOVE ASCII EQUIV TO OUTPUT
2774 002500 005003      CLR      R3
2775 002502 005300      DEC      R0                ;DECREMENT DIGIT COUNT
2776 002504 001365      BNE      2$                ;GET NEXT DIGIT
2777 002506 105737 001126      TSTB   @#TYPFLG           ;BRANCH IF ASCII IS
2778 002512 001002      BNE      4$                ;NOT TO BE TYPED
2779 002514 000004 001144      TYPE,ODIGITS
2780 002520 4$: JSR      PC,RESTORE        ;RESTORE REGISTERS FROM THE STACK
2781 002524 000207      RTS      PC
2782
2783      ;SUBROUTINE TO CONVERT OCTAL DATA TO DECIMAL ASCII
2784      ;CALL: MOV      NUMBER,R2          ;MOVE NUMBER TO R2
2785      ;      JSR      PC,CNVDEC
2786
2787 002526 110637 001126  CNVDEC: MOVVB   SP,@#TYPFLG    ;SET DO NOT TYPE FLAG
2788 002532 000402      BR      CNVTD
2789
2790      .SBTTL      OCTAL TO DECIMAL & TYPE ROUTINE
2791      ;THIS ROUTINE CONVERTS AN OCTAL # TO DECIMAL ASCII AND TYPES IT OUT
2792      ;CALL: MOV      NUMBER,R2          ;PUT # IN R2
2793      ;      JSR      PC,TYPDEC        ;CALL ROUTINE
2794
2795 002534 105037 001126  TYPDEC: CLRB   @#TYPFLG          ;SET TYPE FLAG
    
```

2796 002540
 (1) 002540 004737 002354
 2797 002544 005000
 2798 002546 012704 001144
 2799 002552 005003
 2800 002554 166002 002634
 2801 002560 103402
 2802 002562 005203
 2803 002564 000773
 2804 002566 066002 002634
 2805 002572 116324 001132
 2806 002576 062700 000002
 2807 002602 005760 002634
 2808 002606 001361
 2809 002610 112724 000060
 2810 002614 105737 001126
 2811 002620 001002
 2812 002622 000004 001144
 2813 002626
 (1) 002626 004737 002376
 2814 002632 000207
 2815
 2816 002634 023420
 2817 002636 001750
 2818 002640 000144
 2819 002642 000012
 2820 002644 000001
 2821 002646 000000
 2822
 2823
 2824
 2825
 2826
 2827
 2828
 2829
 2830
 2831
 2832
 2833
 2834 002650 010246
 2835 002652 010346
 2836 002654 006302
 2837 002656 006302
 2838 002660 010203
 2839 002662 000004 015063
 2840 002666 016302 001416
 2841 002672 004737 002534
 2842 002676 000004 001405
 2843 002702 016302 001420
 2844 002706 004737 002534
 2845 002712 000004 001412
 2846 002716 000004 015073
 2847 002722 013702 001012
 2848 002726 004737 002534
 2849 002732 000004 001374

```

CNVTD:
      JSR    PC, .SAVE          ;SAVE REGISTERS ON THE STACK
      CLR    R0                ;R0 IS INDEX TO DECIMAL CONSTANT
      MOV    #ODIGITS,R4      ;SET OUTPUT PTR
1$:    CLR    R3                ;R3 CONTAINS DECIMAL DIGIT
2$:    SUB    DCONST(R0),R2    ;SUBTRACT DECIMAL CONSTANT UNTIL
      BLO    3$                ;INPUT # GOES NEGATIVE
      INC    R3                ;KEEPING TRACK OF SUBTRACTIONS
      BR     2$
3$:    ADD    DCONST(R0),R2    ;ADD BACK CONSTANT WHEN NEGATIVE
      MOVB   DIGTAB(R3),(R4)+  ;MOVE ASCII EQUIVALENT
      ADD    #2,R0             ;NEXT CONSTANT
      TST    DCONST(R0)       ;UNTIL ALL CONSTANTS DONE
      BNE    1$
      MOVB   #'0,(R4)+        ;LAST DIGIT IS 0
      TSTB   @#TYPFLG         ;BRANCH IF ASCII IS
      BNE    4$                ;NOT TO BE TYPED
4$:    TYPE,ODIGITS

      JSR    PC, .RESTORE      ;RESTORE REGISTERS FROM THE STACK
      RTS    PC

DCONST: .WORD 10000.
        .WORD 1000.
        .WORD 100.
        .WORD 10.
        .WORD 1.
        .WORD 0              ;TERMINATOR

      .SBTTL                    TYPE SPECIFIED TIMES ROUTINE
      ;THIS SUBROUTINE OUTPUTS THE TIME SPECIFICATIONS FOR THE TEST
      ;AND ALSO THE ACTUAL TIME RECORDED (ATIME)
      ;FORMAT OF LINE TYPED
      ;RANGE=<AAAAAA-BBBBBB>
      ;WHERE:
      ;AAAAAA IS MAXIMUM TIME FOR TEST (STIMTBL(TSTNUMX4)).
      ;BBBBBB IS MINIMUM TIME FOR TEST (STIMTBL(TSTNUMX4+2)).
      ;CCCCC IS ACTUAL TIME RECORDED BY TEST (ATIME).
      ;CALL:  MOVB   TEST NUMBER,R2 ;LOAD TEST NUMBER
      ;      MOV    #TIME,@#ATIME ;MOVE TIME TO ATIME
      ;      JSR    PC,OUTSPC
      ;      OUTSPC: MOV    R2,-(SP) ;SAVE R2 & R3 ON THE STACK
      ;              MOV    R3,-(SP)
      ;              ASL    R2 ;MULTIPLY TEST # TIMES 4
      ;              ASL    R2 ;TO FORM INDEX INTO STIMTBL
      ;              MOV    R2,R3 ;R3 CONTAINS INDEX INTO TABLE
      ;              TYPE,L,RNG
      ;              MOV    STIMTBL(R3),R2 ;GET MAXIMUM SPEC TIME
      ;              JSR    PC,TYPDEC ;CONVERT TO DECIMAL & TYPE
      ;              TYPE,DASH
      ;              MOV    STIMTBL+2(R3),R2 ;GET MINIMUM TIME
      ;              JSR    PC,TYPDEC ;CONVERT TO DECIMAL & TYPE
      ;              TYPE,ANGTAB
      ;              TYPE,L,ACT
      ;              MOV    @#ATIME,R2 ;GET ACTUAL TIME
      ;              JSR    PC,TYPDEC ;CONVERT TO DECIMAL & TYPE
      ;              TYPE,CRLF
  
```


2850 002736 012603
 2851 002740 012602
 2852 002742 000207

MOV (SP)+,R3
 MOV (SP)+,R2
 RTS PC ;RETURN

2853

.SBTTL TYPE GAP TIMES SUBROUTINE

2854

;THIS SUBROUTINE IS USED TO TYPE THE SPECIFIED GAP SIZES (RECORDED IN
 ;TST021). IT IS CALLED BY THE GAPOK ROUTINE IF THE GAP SIZE IS OUT OF
 ;RANGE VIA THE HLT ROUTINE (HLT+2).

2855

;CALL: MOVB #GAP,GAP ;LOAD GAP # INTO GAP
 ; MOV #TIME,ATIME ;LOAD ACTUAL TIME INTO ATIME
 ; JSR PC,OUTGAP

2856

2857

2858

2859

2860

2861

OUTGAP: MOV R2,-(SP) ;SAVE R2 AND R3

2862

2863

2864

2865

2866

2867

2868

2869

2870

2871

2872

2873

2874

2875

2876

2877

2878

2879

2880

2881

2882

2883

2884

2885

2886

2887

2888

(1)

2889

2890

2891

2892

2893

2894

2895

2896

2897

2898

2899

2900

2901

2902

2903

2904

MOV R3,-(SP)
 MOVB GAP,R3 ;GET GAP #
 ASL R3
 ASL R3
 TYPE,L.RNG
 MOV GTIMTBL(R3),R2 ;GET MAX TIME
 JSR PC,TYPDEC ;CONVERT TO DECIMAL & TYPE
 TYPE,DASH
 MOV GTIMTBL+2(R3),R2 ;GET MIN TIME
 JSR PC,TYPDEC ;CONVERT TO DECIMAL & TYPE
 TYPE,ANGTAB
 TYPE,L.ACT
 MOV @#ATIME,R2 ;GET ACTUAL TIME
 JSR PC,TYPDEC ;CONVERT TO DECIMAL & TYPE
 TYPE,E.GAP
 MOVB @#GAP,R2 ;GET GAP #
 JSR PC,TYPDEC ;TYPE GAP #
 TYPE,CRLF
 MOV (SP)+,R3 ;RESTORE R3 AND R2
 MOV (SP)+,R2
 RTS PC

.SBTTL ASCII TO OCTAL CONVERT SUBROUTINE
 ;SUBROUTINE TO CONVERT ASCII DATA TO OCTAL. CONVERTED OCTAL DATA
 ;IS LEFT IN OCTALO <15-00>.

CNVTAO:
 JSR PC,SAVE ;SAVE REGISTERS ON THE STACK
 MOV #INBUF,R0 ;SET PTR TO ASCII DATA
 MOV #OCTALO,R1 ;GET ADDRESS OF OCTAL DATA
 CLR (R1) ;CLEAR OUT OLD OCTAL DATA
 CLR 2(R1)
 1\$: CMPB #CR,(R0) ;<CR> TERMINATES INPUT
 BEQ 3\$
 MOVB (R0)+,R2 ;GET 'OCTAL' DATA
 BIC #177770,R2 ;STRIP UNUSED BITS
 MOV #3,R3 ;SET SHIFT COUNT
 2\$: ASL (R1) ;SHIFT LAST
 ROL 2(R1) ;OCTAL DIGIT
 DEC R3
 BNE 2\$
 BIS R2,(R1) ;AND INSERT THIS DIGIT
 BR 1\$;GO GET NEXT DIGIT
 3\$:

```

(1) 003136 004737 002376      JSR    PC,.RESTORE      ;RESTORE REGISTERS FROM THE STACK
2905 003142 000207              RTS     PC               ;RETURN
2906
2907      .SBTTL          PUBLISH SUBROUTINE
2908      ;THE PUBLISH SUBROUTINE AVERAGES THE RECORDED TIMES FOR EACH TEST IT-
2909      ;ERATION (IF 16. ITERATIONS) AND PLACES THE AVERAGE RESULT IN 'ATIME'.
2910      ;IT TYPES THE NAME OF THE FUNCTION THAT WAS TIMED,THE TIME SPEC-
2911      ;IFICATION AND THE ACTUAL TIME .
2912
2913      PUBLISH:
(1) 003144 004737 002354      JSR    PC,.SAVE        ;SAVE REGISTERS ON THE STACK
2914 003150 012700 001014      MOV    #ATIMTBL,R0    ;GET TABLE ADDRESS CONTAINING TIMES
2915 003154 113701 001121      MOVB  @#ITCNT,R1      ;GET # OF ENTRIES (GIVEN BY ITERATION COUNT)
2916 003160 122701 000001      CMPB  #1,R1           ;BRANCH IF SINGLE ITERATION
2917 003164 001423              BEQ    4$              ;
2918 003166 005002              CLR    R2              ;CLEAR 'SUM' REGISTERS
2919 003170 005003              CLR    R3              ;
2920 003172 122701 000004      CMPB  #4.,R1          ;BRANCH IF 4. ITERATIONS
2921 003176 001402              BEQ    1$              ;
2922 003200 000000              HALT                    ;ITERATION COUNT MUST BE 1 OR 4.
2923 003202 000777              BR     .                ;DO NOT CHANGE POSIT OF SW11
2924                          ;WHEN TEST IS RUNNING.
2925
2926 003204 062002 1$:      ADD    (R0)+,R2        ;SUM INDIVIDUAL TIMES
2927 003206 005503              ADC    R3
2928 003210 005301              DEC    R1
2929 003212 001374              BNE   1$
2930
2931 003214 012700 000002      2$:      MOV    #2,R0
2932 003220 006203      3$:      ASR    R3              ;SHIFT TIME IN R3 & R2 2 PLACES
2933 003222 006002              ROR    R2              ;RIGHT = DIVIDE BY 4.
2934 003224 005300              DEC    R0
2935 003226 001374              BNE   3$
2936 003230 010237 001012      MOV    R2,@#ATIME     ;MOVE AVERAGED TIMES
2937
2938 003234 113700 001122      4$:      MOVB  @#TSTNUM,R0     ;GET TEST #
2939 003240 006300              ASL    R0
2940 003242 016037 001656 003252      MOV    NAMPTR(R0),5$  ;GET TEST NAME STRING ADDRESS
2941 003250 000004              TYPE
2942 003252 000000      5$:      .WORD 0
2943 003254 113702 001122      MOVB  @#TSTNUM,R2     ;GET TEST #
2944 003260 004737 002650      JSR    PC,OUTSPC      ;OUTPUT TIMES
2945 003264 004737 002376      JSR    PC,.RESTORE    ;RESTORE REGISTERS FROM THE STACK
2946 003270 000207              RTS     PC
2947
2948      .SBTTL          INPUT SUBROUTINE
2949      ;SUBROUTINE TO GET TTY INPUT
2950      ;CALL: JSR    PC,.INPUT
2951      ;INPUT DATA IS RETURNED IN BUFFER BEGINNING AT INBUF.
2952
2953 003272 010046      .INPUT: MOV    R0,-(SP)   ;SAVE R0 ON THE STACK
2954 003274 012700 001264      1$:      MOV    #INBUF,R0
2955 003300 105737 177560      2$:      TSTB  @#TKS
2956 003304 100375              BPL   2$
2957
2958 003306 113746 177562      MOVB  @#TKB,-(SP)    ;GET CHARACTER
    
```

```

2959 003312 042716 000200      BIC      #200,(SP)
2960 003316 122716 000177      CMPB     #177,(SP)      ;CHECK RUBOUT
2961 003322 001004      BNE      3$
2962 003324 124026      CMPB     -(RO),(SP)+   ;REMOVE CHARACTER FROM INPUT
2963 003326 000004 001377      TYPE,BKSLSH
2964 003332 000762      BR       2$           ;WAIT FOR NEXT CHARACTER
2965 003334 122716 000025      3$:     CMPB     #CNTRLU,(SP) ;CHECK CONTROL U (^U)
2966 003340 001004      BNE      4$
2967 003342 005726      TST     (SP)+
2968 003344 000004 001374      TYPE,CRLF
2969 003350 000751      BR       1$
2970 003352 122716 000003      4$:     CMPB     #CNTRLC,(SP) ;BRANCH IF NOT CONTROL C
2971 003356 001003      BNE      40$
2972 003360 000005      RESET
2973 003362 000137 005650      JMP      @#INIT      ;RESTART PROGRAM
2974 003366 111637 001401      40$:    MOVB     (SP),@#ECHO
2975 003372 111620      MOVB     (SP),(RO)+
2976 003374 122726 000015      CMPB     #CR,(SP)+
2977 003400 001403      BEQ      5$
2978 003402 000004 001401      TYPE,ECHO
2979 003406 000734      BR       2$
2980 003410 000004 001374      5$:     TYPE,CRLF
2981 003414 012600      MOV      (SP)+,RO
2982 003416 000207      RTS       PC

2983
2984      ;KEYBOARD INTERRUPT SERVICE ROUTINE
2985 003420 113746 177562      TKISR:  MOVB     @#TKB,-(SP) ;GET TYPED CHARACTER
2986 003424 042716 000200      BIC      #200,(SP)      ;STRIP PARITY BIT
2987 003430 122716 000017      CMPB     #CNTRLO,(SP) ;BRANCH IF NOT CONTROL O (^O)
2988 003434 001002      BNE      1$
2989 003436 111637 002121      MOVB     (SP),%CNTRLO ;SET CONTROL O INDICATOR IN TYPE ROUTINE
2990
2991 003442 122716 000003      1$:     CMPB     #3,(SP)      ;BRANCH IF NOT CONTROL C (^C)
2992 003446 001007      BNE      2$
2993 003450 023727 000042 012712      CMP      @#42,#SENDAD ;INHIBIT ^C IF ACT11 QV OR AA
2994 003456 001403      BEQ      2$
2995 003460 000005      RESET
2996 003462 000137 005650      JMP      @#INIT      ;RESTART PROGRAM
2997
2998 003466 122716 000001      2$:     CMPB     #CNTRLA,(SP) ;BRANCH IF NOT ^A
2999 003472 001011      BNE      3$
3000 003474 022737 000176 001000      CMP      #SWREG,SWR ;BRANCH IF HARDWARE SWR IS INVOKED
3001 003502 001010      BNE     4$
3002 003504 012737 177570 001000      MOV      #177570,SWR ;INVOKE HARDWARE SWR
3003 003512 000004 013475      TYPE,M.HSWR
3004 003516 122716 000007      3$:     CMPB     #CNTRLG,(SP) ;BRANCH IF NOT ^G
3005 003522 001005      BNE      5$
3006 003524 012737 000176 001000      4$:     MOV      #SWREG,SWR ;INVOKE SOFTWARE SWR
3007 003532 004737 002020      JSR      PC,GTSWR ;GET NEW SWITCH REGISTER
3008 003536 005726      5$:     TST     (SP)+ ;POP CHARACTER OFF THE STACK
3009 003540 000002      RTI
    
```

```

3011 .SBTTL ERROR SERVICE ROUTINES
3012 ;ROUTINE TO PROCESS ERROR TRAPS (TRAPS TO 4)
3013 003542 000000 ERRTRP: HALT
3014
3015 ;ERROR SERVICE ROUTINE
3016 ;THIS ROUTINE PROCESSES TWO TYPES OF ERRORS (OUT OF RANGE AND HARDWARE)
3017 ;THE CALLS FOR AN OUT OF RANGE ERROR ARE <HLT+1>,<HLT+2> AND, FOR A
3018 ;HARDWARE ERROR THE CALL IS <HLT>.
3019
3020 003544 004737 002354 .HLT: JSR PC,SAVE ;SAVE REGISTERS ON THE STACK
3021 003550 110637 001123 1$: MOVB SP,@#ERFLG ;SET ERROR FLAG
3022 003554 032777 020000 175216 BIT #SW13,@SWR ;BRANCH IF NO TYP0UT
3023 003562 001075 BNE 4$
3024 003564 000004 014353 TYPE,E.HDR
3025 003570 113702 001122 MOVB @#TSTNUM,R2 ;GET TEST #
3026 003574 004737 002426 JSR PC,TYPOCT ;AND TYPE IT
3027 003600 016600 000016 MOV 16(SP),R0 ;GET RETURN PC
3028 003604 162700 000002 SUB #2,R0 ;NOW PC OF HLT CALL
3029 003610 111000 MOVB (R0),R0 ;NOW HLT CALL ITSELF
3030 003612 001417 BEQ 2$ ;BRANCH IF HLT
3031 003614 000004 014436 TYPE,E.HDR2
3032 003620 122700 000002 CMPB #2,R0 ;BRANCH IF NOT HLT+2
3033 003624 001005 BNE 10$
3034 003626 004737 002744 JSR PC,OUTGAP ;TYPE GAP SPECIFIED TIMES
3035 003632 000004 001374 TYPE,CRLF
3036 003636 000447 BR 4$
3037 003640 004737 002650 10$: JSR PC,OUTSPC ;TYPE SPECIFIED TIMES
3038 003644 000004 001374 TYPE,CRLF
3039 003650 000442 BR 4$
3040 003652 016500 000014 2$: MOV ER(R5),R0
3041 003656 032765 002300 000032 BIT #PE1600,TC(R5)
3042 003664 001403 BEQ 20$
3043 003666 042700 102100 BIC #102100,R0
3044 003672 000402 BR 21$
3045 003674 042700 102300 20$: BIC #102300,R0
3046 003700 003700 005700 21$: TST R0
3047 003702 001003 BNE 22$
3048 003704 000004 014327 TYPE,E.SFT ;TYPE SOFT ERROR MESSAGE
3049 003710 000434 BR 6$
3050
3051 003712 000004 014363 22$: TYPE,E.HDR1
3052 003716 010500 MOV R5,R0 ;GET FIRST ADDRESS OF REGS.
3053 003720 012701 000007 MOV #7,R1 ;TYPE FIRST 7 REGS.
3054 003724 012002 3$: MOV (R0)+,R2 ;GET REG CONTENTS
3055 003726 004737 002426 JSR PC,TYPOCT ;AND TYPE IT
3056 003732 000004 001407 TYPE,SPACE2
3057 003736 005301 DEC R1
3058 003740 001371 BNE 3$
3059 003742 016502 000032 MOV TC(R5),R2 ;GET CONTENTS OF TC REGISTER
3060 003746 004737 002426 JSR PC,TYPOCT
3061 003752 000004 001374 TYPE,CRLF
3062
3063 003756 032777 001000 175014 4$: BIT #SW09,@SWR ;BRANCH IF NO RING THE BELL
3064 003764 001402 BEQ 5$
3065 003766 000004 001403 TYPE,BELL
3066 003772 005777 175002 5$: TST @SWR ;HALT ON ERROR?
    
```

3067	003776	100001		BPL	6\$	
3068	004000	000000		HALT		
3069	004002		6\$:			
(1)	004002	004737	002376	JSR	PC,.RESTORE	:RESTORE REGISTERS FROM THE STACK
3070	004006	000002		RTI		:RETURN
3071						
3072						

```

3074 .SBTTL SCOPE SUBROUTINE
3075 ;SCOPE ROUTINE
3076 ;THIS ROUTINE IS ENTERED UPON COMPLETION OF EACH SUBTEST
3077 ;THE SCOPE ROUTINE:
3078 ; OUTPUTS TIME SPEC ON EACH ITERATION IF SW08 IS SET
3079 ; REPEATS TEST IF SW14 IS SET
3080 ; STORES ACTUAL TIME FOR FUNCTION IN TIME TABLE (ATIMTBL)
3081 ; PUBLISHES TIME IF SW10=0
3082 ; UPDATES ITERATION COUNT AND IF ITERATIONS COMPLETE CONTINUES
3083 ; TO NEXT TEST, OTHERWISE REPEATS TEST.
3084 ; DELAYS BEFORE CONTINUING OR REPEATING TEST.
3085 ; INITIALIZES DRIVE
3086 ;RETURNS: R5=BASE ADDRESS OF TMO3 REGISTERS (ADDRESS OF CS1)
3087 ; R1='DS' REG ADDRESS
3088 ; RO='FC' REG ADDRESS
3089
3090 004010 013705 001010 .SCOPE: MOV @#TMBASE,R5 ;SET R5 TO FIRST TM REG
3091 004014 032777 000400 174756 BIT #SW08,@SWR ;BRANCH IF SPECIFICATION LINE
3092 004022 001404 BEQ 10$ ;NOT DESIRED ON EACH ITERATION
3093 004024 113702 001122 MOV#B @#TSTNUM,R2 ;GET TEST NUMBER
3094 004030 004737 002650 JSR PC,OUTSPC ;OUTPUT TIME RECORDED
3095 004034 032777 040000 174736 10$: BIT #SW14,@SWR ;BRANCH IF CONTINUOUS LOOP
3096 004042 001432 BEQ 2$ ;NOT DESIRED
3097 004044 017701 174730 1$: MOV @SWR,R1 ;GET SWITCHES
3098 004050 042701 177740 BIC #177740,R1 ;CLEAR ALL BUT TEST #
3099 004054 001406 BEQ 11$ ;BRANCH IF ALL SELECTED
3100 004056 020137 001122 CMP R1,@#TSTNUM ;BRANCH IF RUNNING SELECTED TEST
3101 004062 001403 BEQ 11$
3102 004064 012737 007224 001002 MOV #TST000,SCPADR ;RESTART AT TST000
3103 004072 004737 004634 11$: JSR PC,DELAY ;DELAY 350 MS
3104 004076 004737 005120 JSR PC,RHINIT ;INIT
3105 004102 105037 001123 CLR#B @#ERFLG ;CLEAR ERROR FLAG
3106 004106 013716 001002 MOV SCPADR,(SP)
3107 004112 010501 MOV R5,R1
3108 004114 062701 000012 ADD #DS,R1 ;ADDRESS OF 'DS' REG IS IN R1
3109 004120 010500 MOV R5,RO
3110 004122 062700 000006 ADD #FC,RO ;ADDRESS OF 'FC' REG IS IN RO
3111 004126 000002 RTI
3112
3113 004130 105737 001123 2$: TSTB @#ERFLG ;BRANCH IF ERROR FLAG IS SET
3114 004134 001006 BNE 3$
3115 004136 113700 001121 MOV#B @#ITCNT,RO ;GET ITERATION COUNT
3116 004142 006300 ASL RO ;STORE TIME IN TABLE
3117 004144 013760 001012 001014 MOV @#ATIME,ATIMTBL(RO)
3118 004152 105237 001121 3$: INCB @#ITCNT ;INCREMENT ITERATION COUNT
3119 004156 105737 001127 TSTB @#PSCNT ;INHIBIT ITERATIONS ON
3120 004162 001410 BEQ 4$ ;ON FIRST PASS
3121 004164 032777 004000 174606 BIT #SW11,@SWR ;BRANCH IF SINGLE ITERATION DESIRED
3122 004172 001004 BNE 4$
3123 004174 122737 000004 001121 CMP#B #4,@#ITCNT ;BRANCH IF ITERATIONS INCOMPLETE
3124 004202 001320 BNE 1$
3125 004204 032777 000037 174566 4$: BIT #37,@SWR ;IF TEST SELECTED IS TEST 0
3126 004212 001002 BNE 42$ ;TREAT AS ALL TESTS
3127 004214 011637 001002 40$: MOV (SP),@#SCPADR ;SET SCOPE ADDRESS TO NEXT TEST
3128 004220 032777 002000 174552 42$: BIT #SW10,@SWR ;BRANCH IF NO PUBLICATION DESIRED
3129 004226 001005 BNE 5$
    
```

```

3130 004230 005737 005746 TST CHNFLG ;BRANCH IF IN CHAIN MODE
3131 004234 001002 BNE 5$
3132 004236 004737 003144 JSR PC,PUBLISH ;GO PUBLISH TEST DATA
3133 004242 105037 001121 5$: CLRBR @#ITCNT ;RESET ITERATION COUNT
3134 004246 000676 BR 1$
3135
3136 .SBTTL TIMER SUBROUTINES
3137
3138 ;SUBROUTINE TO SYNCHRONIZE THE TIMER AND TURN IT ON.
3139 ;REGISTER 4 IS CLEARED, AND THE OSCILLATOR POLARITY IS MONITORED
3140 ;THE ROUTINE IS EXITED WHEN THE OSCILLATOR POLARITY CHANGES WITH R3
3141 ;SET TO INDICATE THE POLARITY OF THE OSCILLATOR.
3142 ;CALL: JSR PC,TIMON
3143 ;RETURNS: R3 SET TO INDICATE LAST POLARITY (+24/-24=0/1)
3144 ; R4 = 0
3145
3146 004250 005004 TIMON: CLR R4 ;CLEAR TIME COUNT
3147 004252 012703 000024 MOV #24,R3 ;SET POLARITY TO '0' STATE
3148 004256 032765 000100 000024 BIT #OSC,MR(R5) ;BRANCH IF POLARITY IS '0'
3149 004264 001405 BEQ 2$
3150 004266 032765 000100 000024 1$: BIT #OSC,MR(R5) ;WAIT FOR OSCILLATOR TO RETURN
3151 004274 001374 BNE 1$
3152 004276 000405 BR 4$
3153
3154 004300 005403 2$: NEG R3 ;NEGATE PREV POLARITY INDICATOR
3155 004302 032765 000100 000024 3$: BIT #OSC,MR(R5) ;WAIT FOR OSCILLATOR TO RETURN
3156 004310 001774 BEQ 3$ ;TO '1' STATE
3157 004312 000207 4$: RTS PC
3158
3159 ;SUBROUTINE TO COUNT TIME
3160 ;EACH TIME THE OSCILLATOR TOGGLES (BIT <06> IN MR REG) REGISTER
3161 ;R4 IS INCREMENTED, AND THE REGISTER R3 IS NEGATED TO INDICATE
3162 ;THE LAST STATE OF THE OSCILLATOR.
3163 ;CALL JMP TIMER(R3) ;R3 IS SET BY TIMON ROUTINE
3164 ; R2=RETURN ADDRESS TO CALLER
3165 ;NOTE: THE TIME TO EXECUTE THIS ROUTINE IS VERY CRITICAL. IT MUST BE
3166 ;LESS THAN 40 US.
3167
3168 ;ENTER HERE VIA JMP TIMER(R3) WHEN R3=-24 (PREV STATE=1)
3169 004314 032765 000100 000024 TIMER1: BIT #OSC,MR(R5) ;BRANCH IF CURRENT STATE IS '0'
3170 004322 001406 BEQ TIMER ;GO INCREMENT TIME
3171 004324 000112 JMP (R2) ;RETURN TO TEST
3172
3173 .=TIMER1+24
3174 004340 005403 TIMER: NEG R3 ;NEGATE PREV STATE INDICATOR
3175 004342 005204 INC R4 ;INCREMENT 'TICK' COUNT
3176 004344 100401 BMI TIMERR ;BRANCH ON OVERFLOW
3177 004346 000112 JMP (R2) ;RETURN TO TEST
3178 004350 000004 014464 TIMERR: TYPE,E.TIMOV ;TYPE 'TIMER OVERFLOWED'
3179 004354 104400 HLT ;REPORT HARDWARE ERROR
3180 004356 000177 174420 JMP @SCPADR ;RETURN TO BEGINNING OF TEST
3181
3182 .=TIMER+24
3183 ;ENTER HERE VIA JMP TIMER(R3) WHEN R3=+24 (PREV STATE=0)
3184 004364 032765 000100 000024 TIMERO: BIT #OSC,MR(R5) ;BRANCH IF CURRENT STATE - '1'
3185 004372 001362 BNE TIMER
    
```

```

3186 004374 000112          JMP      (R2)
3187
3188 ;SUBROUTINE TO CHECK TIME RECORDED BY SUBTEST.
3189 ;THIS SUBROUTINE COMPUTES THE ACTUAL TIME (IN MICROSECONDS) AND CHECKS
3190 ;THAT THE TIME RECORDED BY THE SUBTEST IS CORRECT BY COMPARING THE TIME
3191 ;WITH THE HIGH LIMIT (STIMTBL(R0)) AND THE LOW LIMIT (STIMTBL+2(R0)).
3192 ;IF THE TIME IS OUT OF RANGE AN OUT OF RANGE ERROR TYPEOUT RESULTS.
3193 ;THE SUBROUTINE IS ENTERED WITH:
3194 ;      R4=TICK COUNT
3195
3196 004376          TIMOK:
    (1) 004376 004737 002354      JSR      PC,SAVE          ;SAVE REGISTERS ON THE STACK
3197 004402 012700 000070      MOV      #56,R0          ;GET TIME PER TICK
3198 004406 010401          MOV      R4,R1          ;GET TICKS COUNT
3199 004410 005002          CLR      R2              ;CLEAR SUMMING REGISTERS
3200 004412 005003          CLR      R3
3201 004414 060002      1$:  ADD      R0,R2          ;MULTIPLY TIME PER TICK
3202 004416 005503          ADC      R3              ;BY TICK COUNT
3203 004420 005301          DEC      R1
3204 004422 001374          BNE      1$
3205 004424 010246          MOV      R2,-(SP)        ;DIVIDE COUNT BY 10.
3206
3207 004426 010346          MOV      R3,-(SP)
3208 004430 012746 000012      MOV      #10,-(SP)
3209 004434 004737 004722      JSR      PC,DIVIDE
3210 004440 005726          TST      (SP)+          ;DISCARD REMAINDER
3211 004442 012637 001012      MOV      (SP)+,@#ATIME   ;STORE QUOTIENT
3212 004446 113700 001122      MOVB     @#TSTNUM,R0    ;GET TEST #
3213 004452 006300          ASL      R0
3214 004454 006300          ASL      R0
3215 004456 023760 001012 001416  CMP      @#ATIME,STIMTBL(R0) ;CHECK THAT TIME IS WITHIN
3216 004464 101004          BHI      2$              ;LIMITS SPECIFIED
3217 004466 023760 001012 001420  CMP      @#ATIME,STIMTBL+2(R0)
3218 004474 101001          BHI      3$
3219 004476 104401      2$:  HLT+1          ;CALL ERROR ROUTINE
3220 004500          3$:
    (1) 004500 004737 002376      JSR      PC,RESTORE      ;RESTORE REGISTERS FROM THE STACK
3221 004504 000207          RTS      PC              ;RETURN
3222
3223 ;SUBROUTINE TO CHECK INDIVIDUAL GAP TIMES (PRODUCED BY TST021)
3224 ;SUBROUTINE COMPUTES THE ACTUAL TIME (IN MICROSECONDS) AND CHECKS
3225 ;THAT THE GAP TIME RECORDED BY THE SUBTEST (TST021) BY COMPARING THE
3226 ;TIME WITH THE MAX LIMIT (GTIMTBL-GAPTBL(R1)) AND THE MIN LIMIT
3227 ;(GTIMTBL+2-GAPTBL(R1)).
3228 ;CALL: MOV      #TICK COUNT,R4 ;R4 CONTAINS TICK COUNT
3229 ;      MOVB     #GAP,@#GAP      ;LOCATION GAP CONTAINS GAP #
3230 ;      JSR      PC,GAPOK
3231
3232 004506          GAPOK:
    (1) 004506 004737 002354      JSR      PC,SAVE          ;SAVE REGISTERS ON THE STACK
3233 004512 012700 000070      MOV      #56,R0          ;GET TIME PER TICK
3234 004516 010401          MOV      R4,R1          ;GET TICK COUNT
3235 004520 005002          CLR      R2              ;CLEAR SUMMING REGISTERS
3236 004522 005003          CLR      R3
3237 004524 060002      1$:  ADD      R0,R2          ;MULTIPLY TICK COUNT
3238 004526 005503          ADC      R3              ;BY TIME PER TICK
    
```



```

3239 004530 005301          DEC      R1
3240 004532 001374          BNE     1$
3241
3242 004534 010246          MOV     R2,-(SP)          ;DIVIDE TIME BY 10.
3243 004536 010346          MOV     R3,-(SP)
3244 004540 012746 000012          MOV     #10,-(SP)
3245 004544 004737 004722          JSR    PC,DIVIDE
3246 004550 005726          TST    (SP)+
3247 004552 012637 001012          MOV     (SP)+,@#ATIME    ;DISCARD REMAINDER
3248 004556 113703 001120          MOVB   @#GAP,R3         ;STORE QUOTIENT
3249 004562 006303          ASL    R3               ;GET GAP #
3250 004564 006303          ASL    R3               ;MULTPLY BY 4
3251 004566 023763 001012 001556          CMP    @#ATIME,GTIMTBL(R3) ;TO GET AT TABLE ENTRY
3252 004574 101004          BHI    2$               ;CHECK TIME (MAX)
3253 004576 023763 001012 001560          CMP    @#ATIME,GTIMTBL+2(R3) ;CHECK TIME (MIN)
3254 004604 101002          BHI    3$
3255 004606 104402          HLT+2  2$              ;REPORT OUT OF RANGE ERROR
3256 004610 000406          BR     100$
3257 004612 032777 000400 174160 3$          BIT    #SW08,@SWR       ;BRANCH IF TIMES NOT WANTED
3258 004620 001402          BEQ    100$
3259 004622 004737 002744          JSR    PC,OUTGAP        ;TYPE GAP TIMES
3260
3261 004626          100$:
3262 004632 004737 002376          JSR    PC,.RESTORE      ;RESTORE REGISTERS FROM THE STACK
3263 004632 000207          RTS    PC               ;RETURN TO TEST
3264
3265          .SBTTL          DELAY SUBROUTINES
3266          ;THIS SUBROUTINE CAUSES A DELAY OF 350 MS.
3267 004634 004737 004250          DELAY: JSR    PC,TIMON
3268 004640 010246          MOV     R2,-(SP)        ;SAVE R2 ON THE STACK
3269 004642 012702 004652          MOV     #2$,R2         ;SET RETURN ADDRESS FOR TIMER
3270 004646          1$:
3271 004646 000163 004340          JMP     TIMER(R3)       ;GO TO TIMER & RETURN VIA R2
3272 004652 032704 004000          2$: BIT    #4000,R4
3273 004656 001773          BEQ    1$
3274 004660 012602          MOV     (SP)+,R2       ;RESTORE R2
3275 004662 000207          RTS    PC
3276          ;THIS SUBROUTINE ALLOWS A CALLER SPECIFIED DELAY (UP TO 65MS.)
3277          ;CALL: MOV     DELAY TIME,DELTIM    ;LOAD DELAY TIME (IN US)
3278          ;      JSR    PC,DELAYV
3279 004664 005737 001114          DELAYV: TST    DELTIM    ;BRANCH IF 0 DELAY
3280 004670 001413          BEQ    3$
3281 004672 004737 004250          JSR    PC,TIMON        ;TURN TIMER ON
3282 004676 010246          MOV     R2,-(SP)        ;SAVE R2 ON THE STACK
3283 004700 012702 004710          MOV     #2$,R2         ;SET RETURN ADDRESS FROM TIMER
3284 004704          1$:
3285 004704 000163 004340          JMP     TIMER(R3)       ;GO TO TIMER & RETURN VIA R2
3286 004710 023704 001114          2$: CMP    @#DELTIM,R4
3287 004714 101373          BHI    1$
3288 004716 012602          MOV     (SP)+,R2       ;RESTORE R2
3289 004720 000207          3$: RTS    PC
3290          .SBTTL          DIVIDE SUBROUTINE
3291          ;THIS SUBROUTINE DIVIDES A DOUBLE PRECISION # AND RETURNS THE RESULT
          ;TO THE CALLER ON THE STACK. BOTH DIVIDEND & DIVISOR MUST BE POSITIVE.
    
```

```

3292 ;CALL: MOV LEAST SIGNIFICANT HALF DIVIDEND,-(SP)
3293 ;      MOV #MOST SIGNIFICANT HALF DIVIDEND,-(SP)
3294 ;      MOV #DIVISOR,-(SP)
3295 ;      JSR PC,DIVIDE
3296 ;RETURN
3297 ;      (SP)=REMAINDER ON STACK
3298 ;      2(SP)=QUOTIENT
3299
3300 ;NOTE: THIS SUBROUTINE DESTROYS PREVIOUS CONTENTS OF R0,R1,R2 & R3.
3301
3302 DIVIDE: CLR -(SP) ;SAVE LOC FOR SIGNS
3303 004722 012746 000021 MOV #17,-(SP) ;SET ITERATION COUNT
3304 004730 016601 000012 MOV 12(SP),R1 ;GET LSH DIVIDEND
3305 004734 016600 000010 MOV 10(SP),R0 ;GET MSH DIVIDEND
3306 004740 016602 000006 MOV 6(SP),R2 ;GET DIVISOR
3307 004744 005402 NEG R2 ;NEGATE DIVISOR
3308 004746 000241 CLC ;CLEAR 'C' BIT IN PSW
3309 004750 000405 BR 2$
3310 004752 006100 1$: ROL R0 ;ROTATE MSH DIVIDEND
3311 004754 010003 MOV R0,R3 ;SAVE IN R3
3312 004756 060203 ADD R2,R3 ;SUBTRACT DIVISOR FROM MSH DIVIDEND
3313 004760 103001 BCC 2$ ;BRANCH IF DIVIDEND > DIVISOR
3314 004762 010300 MOV R3,R0 ;SAVE REMAINDER IN R0
3315 004764 006101 2$: ROL R1 ;ROTATE LSH DIVIDEND
3316 004766 005316 DEC (SP) ;DECREMENT ITERATION COUNT
3317 004770 001370 BNE 1$
3318 004772 005726 TST (SP)+ ;POP ITERATION COUNTER
3319 004774 005726 TST (SP)+ ;POP SIGN CORRECTION
3320 004776 010166 000006 MOV R1,6(SP) ;PUSH REMAINDER ON STACK
3321 005002 010066 000004 MOV R0,4(SP) ;PUSH QUOTIENT ONTO STACK
3322 005006 012616 MOV (SP)+,(SP)
3323 005010 000207 RTS PC
3324
3325 .SBTTL DRIVE SUBROUTINES
3326 ;SUBROUTINE TO CHECK IF DRIVE IS AVAILABLE
3327 ;CALL: MOV# DRIVE#,DRVNUM
3328 ;      JSR PC,DRVAVA
3329 ;RETURN: 'C' BIT SET IF NOT AVAILABLE
3330 005012 113765 001004 000010 DRVAVA: MOV# @DRVNUM,CS2(R5) ;LOAD DRIVE #
3331 005020 032765 040000 000026 BIT #TAP,DT(R5) ;CHECK IF TAPE UNIT
3332 005026 001003 BNE 1$
3333 005030 004737 005120 JSR PC,RHINIT
3334 005034 000262 SEV ;SET 'V' TO IND NOT AVAIL
3335 005036 000207 1$: RTS PC ;RETURN
3336
3337 ;SUBROUTINE TO CHECK IF TU45 SLAVE IS AVAILABLE FOR TEST
3338 ;CALL: MOV# DRIVE #,@DRVNUM ;PASS DRIVE # VIA DRVNUM
3339 ;      MOV# SLAVE #,@SLVNUM ;PASS SLAVE # VIA SLVNUM
3340 ;      JSR PC,SLVAVA ;CALL SUBROUTINE
3341 005040 113765 001004 000010 SLVAVA: MOV# @DRVNUM,CS2(R5) ;LOAD DRIVE #
3342 005046 113765 001005 000032 MOV# @SLVNUM,TC(R5) ;AND SLAVE #
3343 005054 032765 002000 000026 BIT #SPR,DT(R5) ;BRANCH IF SLAVE NOT PRESENT
3344 005062 001414 BEQ 1$
3345 005064 032765 010000 000012 BIT #MOL,DS(R5) ;BRANCH IF ON LINE
3346 005072 001011 BNE 2$
3347 005074 116037 001132 014234 MOV# DIGTAB(R0),@#E.NSL1 ;SET DRIVE # IN MESSAGE

```

```

3348 005102 116137 001132 014245      MOVB  DIGTAB(R1),@#E.MSG      ;SET SLAVE # IN MESSAGE
3349 005110 000004 014226      TYPE,E.NDR1                  ;PRINT DRIVE #,SLAVE # NOT
3350                                     ;ON LINE
3351 005114 000262                1$: SEV                      ;SET 'V' TO INDICATE NO SLAVE
3352 005116 000207                2$: RTS      PC
3353
3354 ;SUBROUTINE TO INITIALIZE RH CONTROLLER
3355 ;CALL: JSR PC,RHINIT
3356
3357 005120 012765 000040 000010 RHINIT: MOV      #40,CS2(R5)
3358 005126 113765 001004 000010      MOVB  @#DRVNUM,CS2(R5)
3359 005134 005046                  CLR   -(SP)
3360 005136 113716 001005          MOVB  @#SLVNUM,(SP)
3361 005142 012665 000032          MOV   (SP)+,TC(R5)          ;LOAD SLAVE # INTO TC REG
3362 005146 052765 001700 000032      BIS   #NORM11,TC(R5)
3363 005154 000207                  RTS      PC
3364
3365 ;SUBROUTINE TO WAIT FOR DRIVE READY (DRY)
3366 005156 005027      WAITRDY:CLR      (PC)+      ;CLEAR WAIT TIMER
3367 005160 000000      WAITTIM:.WORD 0
3368 005162 105765 000012      1$: TSTB  DS(R5)          ;WAIT FOR READY TO SET
3369 005166 100406          BMI   2$
3370 005170 005237 005160          INC   WAITTIM          ;INCREMENT WAIT TIMER
3371 005174 001372          BNE   1$              ;BRANCH IF TIME HAS NOT EXPIRED
3372 005176 000004 014511          TYPE,E.TIMEXP          ;TYPE 'TIME EXPIRED WAITING FOR RDY'
3373 005202 000425          BR   99$              ;TAKE ERROR EXIT
3374 005204 032765 002000 000012  2$: BIT   #EOT,DS(R5)      ;CHECK FOR END OF TAPE
3375 005212 001415          BEQ   3$              ;BRANCH IF NO EOT
3376 005214 000004 013322          TYPE,M.NAM
3377 005220 000004 014035          TYPE,M.EOT          ;TYPE 'END OF TAPE'
3378 005224 004737 005262          JSR   PC,.REWIND      ;REWIND SLAVE
3379 (1) 005230 102412          BVS   99$              ;BRANCH IF ERROR ON REWIND
3380 005232 004737 005344          JSR   PC,WRITE        ;WRITE A RECORD
3381 005236 005215          INC   (R5)            ;SET 'GO' BIT
3382 005240 004737 005156          JSR   PC,WAITRDY      ;WAIT FOR READY
3383 005244 000404          3R   99$              ;TAKE ERROR EXIT
3384 005246 032765 040000 000012  3$: BIT   #ERR,DS(R5)      ;CHECK ERROR EXIT
3385 005254 001401          BEQ   100$
3386 005256 000262          99$: SEV
3387 005260 000207          100$: RTS      PC
3388 ;SUBROUTINE TO REWIND A UNIT (DRIVE/SLAVE COMBINATION)
3389 ;CALL MOVB  DRIVE #,@#DRVNUM
3390 ;      MOVB  SLAVE #,@#SLVNUM
3391 ;      JSR   PC,.REWIND
3392 ;SUBROUTINE RETURNS TO CALLER WITH SELECTED SLAVE AT 'BOT', & 'V' SET IF
3393 ;AN ERROR OCCURS.
3394 005262 004737 005120      .REWIND:JSR      PC,RHINIT      ;INITIALIZE CONTROLLER
3395 005266 004337 005500          JSR      R3,TMCMDB          ;GO TO TM COMMAND SUBROUTINE
3396 005272 000000          .WORD 0                  ;BUS ADDRESS (NOT USED)
3397 005274 000000          .WORD 0                  ;WORD COUNT (NOT USED)
3398 005276 000000          .WORD 0                  ;FRAME COUNT (NOT USED)
3399 005300 000006          .WORD RWD                ;REWIND COMMAND
3400 005302 005215          INC   (R5)                ;SET 'GO' BIT
3401 005304 032765 000002 000012  1$: BIT   #BOT,DS(R5)          ;BRANCH IF 'BOT' SET
3402 005312 001005          BNE   2$

```

```

3403 005314 032765 040000 000012      BIT      #ERR,DS(R5)      ;CHECK ERROR BIT
3404 005322 001006      BNE      99$          ;BRANCH IF ERROR BIT SET
3405 005324 000767      BR       1$
3406
3407 005326 032765 020000 000012 2$:      BIT      #PIP,DS(R5)      ;WAIT FOR TAPE MOTION TO STOP
3408 005334 001374      BNE      2$
3409 005336 000401      BR       100$
3410 005340 000262      99$:      SEV      000262
3411 005342 000207      100$:     RTS       PC
3412
3413      ;SUBROUTINE TO WRITE 256. WORD RECORD
3414      ;CALL: JSR      PC,WRITE
3415
3416 005344 004337 005500  WRITE: JSR      R3,TMCMD      ;GO TO TM COMMAND SUBROUTINE
3417 005350 016046      .WORD   WTBUF          ;BUS ADDRESS
3418 005352 177600      .WORD   WRDCNT        ;WORD COUNT
3419 005354 177400      .WORD   FRMCNT        ;FRAME COUNT
3420 005356 000060      .WORD   WFW          ;WRITE FORWARD COMMAND
3421 005360 000207      RTS       PC
3422
3423      ;SUBROUTINE TO READ A 256. WORD RECORD.
3424      ;CALL: JSR      PC,READ
3425
3426 005362 004337 005500  READ:  JSR      R3,@#TMCMD
3427 005366 016046      .WORD   RDBUF          ;ADDRESS OF READ BUFFER
3428 005370 177600      .WORD   WRDCNT        ;2'S COMPLEMENT OF WORD COUNT
3429 005372 177400      .WORD   FRMCNT        ;2'S COMPLEMENT OF FRAME COUNT
3430 005374 000070      .WORD   RDFWD         ;READ FORWARD COMMAND
3431 005376 000207      RTS       PC
3432
3433      ;SUBROUTINE TO INITIATE READ REVERSE COMMAND
3434      ;CALL: JSR      PC,REVRD
3435
3436 005400 004337 005500  REVRD: JSR      R3,TMCMD
3437 005404 016446      .WORD   RDBUF+256.    ;ADDRESS OF READ REVERSE BUFFER
3438 005406 177600      .WORD   WRDCNT        ;2'S COMPLEMENT OF WORD COUNT
3439 005410 177400      .WORD   FRMCNT        ;2'S COMPLEMENT OF FRAME COUNT
3440 005412 000076      .WORD   RDREV         ;READ REVERSE COMMAND
3441 005414 000207      RTS       PC
3442
3443      ;SUBROUTINE TO SPACE FORWARD 1 RECORD
3444 005416 012765 177777 000006  FWDSPC: MOV      #-1,FC(R5)      ;LOAD RECORD COUNT
3445 005424 012715 000031      MOV      #SPCFWD+1,(R5) ;LOAD COMMAND
3446 005430 004737 005156      JSR      PC,WAITRDY    ;WAIT FOR READY
3447 005434 000207      RTS       PC          ;RETURN
3448
3449      ;SUBROUTINE TO WRITE A RECORD AND BACK SPACE OVER THE RECORD.
3450 005436 004737 005344  WRT.BK: JSR      PC,WRITE ;WRITE THE RECORD
3451 005442 005215      INC      (R5)          ;SET 'GO' BIT
3452 005444 004737 005156      JSR      PC,WAITRDY
3453 005450 102412      BVS     2$
3454 005452 012765 177777 000006  MOV      #-1,FC(R5)      ;LOAD RECORD COUNT
3455 005460 012715 000033      MOV      #SPCREV+1,(R5) ;LOAD COMMAND
3456 005464 004737 005156      JSR      PC,WAITRDY
3457 005470 102402      BVS     2$
3458 005472 004737 004634  1$:      JSR      PC,DELAY      ;WAIT FOR TAPE MOTION TO STOP

```

3459 005476 000207
 3460
 3461
 3462
 3463
 3464
 3465
 3466
 3467
 3468 005500 012365 000004
 3469 005504 012365 000002
 3470 005510 012365 000006
 3471 005514 012315
 3472 005516 000203
 3473
 3474
 3475
 3476
 3477 005520 016503 000030
 3478 005524 012701 001144
 3479 005530 000303
 3480 005532 006003
 3481 005534 006003
 3482 005536 006003
 3483 005540 006003
 3484 005542 042703 177760
 3485 005546 052703 000260
 3486 005552 110321
 3487 005554 016503 000030
 3488 005560 000303
 3489 005562 042703 177760
 3490 005566 052703 000260
 3491 005572 110321
 3492 005574 016503 000030
 3493 005600 006003
 3494 005602 006003
 3495 005604 006003
 3496 005606 006003
 3497 005610 042703 177760
 3498 005614 052703 000260
 3499 005620 110321
 3500 005622 016503 000030
 3501 005626 042703 177760
 3502 005632 052703 000260
 3503 005636 110321
 3504 005640 105011
 3505 005642 000004 001144
 3506 005646 000207
 3507

```

2$:   RTS       PC

:SUBROUTINE TO LOAD A COMMAND
:CALL: JSR      R3,TMCMO
:      .WORD    BUS ADDRESS
:      .WORD    WORD COUNT (2'S COMPLEMENT)
:      .WORD    FRAME COUNT (2'S COMPLEMENT)
:      .WORD    COMMAND

TMCMO: MOV      (R3)+,BA(R5)      ;LOAD BUS ADDRESS
      MOV      (R3)+,WC(R5)      ;LOAD WORD COUNT
      MOV      (R3)+,FC(R5)      ;LOAD FRAME COUNT
      MOV      (R3)+,(R5)        ;LOAD COMMAND
      RTS      R3                ;RETURN

:SUBROUTINE TO PRINT TU45 SERIAL NUMBER
:JSR   PC,SNPT

SNPT:  MOV      SN(R5),R3
      MOV      #ODIGITS,R1
      SWAB    R3
      ROR     R3
      ROR     R3
      ROR     R3
      ROR     R3                ;GET FIRST DIGIT
      BIC     #177760,R3
      BIS     #260,R3
      MOVB    R3,(R1)+          ;FILL FIRST DIGIT
      MOV     SN(R5),R3
      SWAB    R3
      BIC     #177760,R3
      BIS     #260,R3
      MOVB    R3,(R1)+          ;GET SECOND DIGIT
      MOV     SN(R5),R3
      ROR     R3
      ROR     R3
      ROR     R3
      BIC     #177760,R3
      BIS     #260,R3
      MOVB    R3,(R1)+          ;GET THIRD DIGIT
      MOV     SN(R5),R3
      BIC     #177760,R3
      BIS     #260,R3
      MOVB    R3,(R1)+          ;GET FOURTH DIGIT
      CLRB   (R1)
      TYPE,ODIGITS              ;TYPE SERIAL NUMBER
      RTS    PC                ;RETURN
  
```

```

3509          .SBTTL  PROGRAM INITIALIZATION
3510 005650 012706 000600 INIT:  MOV    #STKPTR,SP      ;SET STACK PTR
3511 005654 005037 001264      CLR    @#INBUF
3512
3513 005660 013746 000006      MOV    @#6,-(SP)          ;SAVE VECTORS
3514 005664 013746 000004      MOV    @#4,-(SP)
3515 005670 012737 005710 000004      MOV    #61$,@#4          ;SET UP FOR TIMEOUT
3516 005676 022777 177777 173074      CMP    #-1,@SWR          ;REFERENCE HARDWARE SWITCH REGISTER
3517 005704 001402      BEQ    60$
3518 005706 000404      BR     62$
3519 005710 022626      61$:  CMP    (SP)+,(SP)+      ;ADJUST STACK
3520 005712 012737 000176 001000      60$:  MOV    #SWREG,SWR      ;POINT TO SOFTWARE SWITCH REG
3521 005720 012637 000004      62$:  MOV    (SP)+,@#4      ;RESTORE VECTORS
3522 005724 012637 000006      MOV    (SP)+,@#6
3523 005730 105037 001124      CLRB   @#PRGFLG          ;CLEAR PROGRAM FLAG
3524 005734 105037 001130      CLRB   @#ASFLG          ;CLEAR ASK FLAG
3525 005740 105037 001127      CLRB   @#PSCNT          ;SET PASS COUNT = 0
3526 005744 005027      CLR    (PC)+            ;;CLEAR CHAIN INDICATOR
(1) 005746 000000      CHNFLG: .WORD 0        ;;CHAIN MODE INDICATOR
(1)                                ;;1/0 = CHAIN/NOT CHAIN MODE
(1)                                ;;BRANCH IF LOADED VIA ACT11 CHAIN MODE
(1) 005750 022737 012712 000042      CMP    #SENDAD,@#42
(1) 005756 001404      BEQ    50$
(1) 005760 005737 000042      TST   @#42              ;;BRANCH IF IN DUMP MODE
(1) 005764 001413      BEQ    52$
(1) 005766 000406      BR     51$
(1) 005770 012737 000176 001000      50$:  MOV    #SWREG,SWR      ;;INVOKE SOFTWARE SWR
(1) 005776 012777 100000 172774      MOV    #100000,@SWR    ;;WITH HALT ON ERROR SET
(1) 006004 005237 005746      51$:  INC    CHNFLG          ;;SET CHNFLG = CHAIN MODE
(1) 006010 000137 006106      JMP    5$              ;;GO TO CHAIN ADDRESS
(1) 006014      52$:
3527 006014 122737 000006 000041      CMPB   #6,@#41          ;BRANCH IF NOT LOADED VIA TMDP
3528 006022 001002      BNE    1$
3529 006024 000004 013525      TYPE,I.REM             ;ADVISE USER TO REMOVE TMDP
3530 006030 000004 013322      1$:  TYPE,M.NAM             ;TYPE TITLE
3531 006034 105037 013322      CLRB   M.NAM           ;DO NOT TYPE TITLE ON RESTART
3532 006040 000004 013572      TYPE,I.REG             ;ASK USER TO TYPE CONT BASE ADRS
3533 006044 013702 001010      MOV    @#TMBASE,R2     ;GET CURRENT CONT BASE ADDRESS
3534 006050 004737 002426      JSR    PC,TYPEOCT      ;AND TYPE IT
3535 006054 000004 001410      TYPE,SPACE
3536 006060 004737 003272      JSR    PC,.INPUT       ;GET USER INPUT
3537 006064 122737 000015 001264      CMPB   #CR,@#INBUF     ;DO NOT CHANGE CURRENT VALUE
3538 006072 001405      BEQ    5$              ;IF USER TYPES <CR>
3539 006074 004737 003056      4$:  JSR    PC,CNVTAO      ;CONVERT ASCII TO OCTAL
3540 006100 013737 001116 001010      MOV    @#OCTALO,@#TMBASE ;SET NEW ADDRESS
3541 006106 013705 001010      5$:  MOV    @#TMBASE,R5
3542
3543 ;ROUTINE TO CHECK IF CONTROLLER (RH11) IS AVAILAABLE
3544 006112 000261      SEC                    ;SET 'C' IN PSW
3545 006114 005715      TST    (R5)            ;BRANCH IF CONTROLLER AVAIL
3546 006116 103003      BCC    6$
3547 006120 000004 014074      TYPE,E.NCON
3548 006124 000651      BR     INIT
3549 006126 012737 003542 000004      6$:  MOV    #ERRTRP,@#ERRVEC ;SET ERROR TRAP VECTOR

```

```

3551 ;ROUTINE TO GET TMO3 DRIVES USER DESIRES TO TEST
3552 006134 105037 001123 DRIVES: CLR @#ERFLG ;CLEAR ERROR FLAG
3553 006140 012701 001154 MOV #DRVTBL,R1 ;MARK ALL DRIVES AS NOT TO
3554 006144 012700 000004 MOV #4,RO ;BE TESTED. A '0' INDICATES
3555 006150 005021 1$: CLR (R1)+ ;THAT A DRIVE IS NOT TO BE
3556 006152 005300 DEC RO ;TESTED
3557 006154 001375 BNE 1$
3558 006156 005737 005746 TST CHNFLG ;BRANCH IF IN CHAIN MODE
3559 006162 001014 BNE 2$
3560 006164 000004 013637 TYPE,1,DRVS
3561 006170 004737 003272 JSR PC,,INPUT ;GET USER INPUT
3562 006174 012700 001264 MOV #INBUF,RO
3563 006200 122710 000101 CMPB #'A',(RO) ;IF USER RESPONDS WITH 'A' OR
3564 006204 001403 BEQ 2$ ;<CR> THEN ALL AVAILABLE DRIVES
3565 006206 122710 000015 CMPB #CR,(RO) ;ARE TO BE TESTED
3566 006212 001013 BNE 4$
3567 006214 110637 001124 2$: MOVB SP,PRGFLG ;SET FLAG TO IND ALL DRIVES
3568 006220 012701 001154 MOV #DRVTBL,R1 ;MARK ALL DRIVES TO BE TESTED
3569 006224 012700 000004 MOV #4,RO ;A '-1' INDICATES THAT A DRIVE
3570 006230 012721 177777 3$: MOV #-1,(R1)+ ;IS TO BE TESTED
3571 006234 005300 DEC RO
3572 006236 001374 BNE 3$
3573 006240 000417 BR CHKDRV ;GO CHECK DRIVE AVAILABILITY
3574
3575 ;GET USER SELECTED DRIVES AND MARK EACH DRIVE SELECTED TO BE TESTED
3576 006242 122710 000015 4$: CMPB #CR,(RO)
3577 006246 001414 BEQ CHKDRV
3578 006250 121027 000054 CMPB (RO),#', ;CHECK IF 'COMMA'
3579 006254 001001 BNE 5$
3580 006256 105720 TSTB (RO)+ ;STEP PTR PAST 'COMMA'
3581 006260 112001 5$: MOVB (RO)+,R1
3582 006262 042701 177770 BIC #177770,R1
3583 006266 112761 177777 001154 MOVB #-1,DRVTBL(R1)
3584 006274 000240 NOP
3585 006276 000761 BR 4$
3586
3587 ;ASCERTAIN THAT DRIVES (TMO3'S) SPECIFIED ARE AVAILABLE
3588 006300 005000 CHKDRV: CLR RO ;A (0) IN DRVTBL(RO) INDICATES
3589 006302 105760 001154 1$: TSTB DRVTBL(RO) ;THE DRIVE IS NOT TO BE TESTED
3590 006306 001005 BNE 3$ ;A '1' INDICATES TO BE TESTED
3591 006310 005200 2$: INC RO
3592 006312 122700 000010 CMPB #8.,RO
3593 006316 001371 BNE 1$
3594 006320 000424 BR 5$
3595 006322 110037 001004 3$: MOVB RO,@#DRVNUM ;GET DRIVE #
3596 006326 004737 005012 JSR PC,@#DRVAVA ;AND CHECK IF AVAILABLE
3597 006332 102366 BVC 2$ ;'V' BIT SET INDICATES NOT AVAIL
3598 006334 105737 001124 TSTB @#PRGFLG ;DO NOT TYPE NOT AVAILABLE
3599 006340 001011 BNE 4$ ;MESSAGE IF ALL SELECTED
3600 006342 000004 014141 TYPE,E,NDRV
3601 006346 116037 001132 014173 MOVB DIGTAB(RO),@#E.NAVA ;SET DRIVE # IN MESSAGE
3602 006354 000004 014173 TYPE,E,NAVA
3603 006360 110637 001123 MOVB SP,@#ERFLG ;SET 'ERROR' FLAG
3604 006364 105060 001154 4$: CLRB DRVTBL(RO) ;MARK DRIVE UNAVAILABLE
3605 006370 000747 BR 2$ ;CHECK NEXT DRIVE
3606 006372 105737 001123 5$: TSTB @#ERFLG ;GO GET SLAVES IF NO ERROR

```

```

3607 006376 001256          BNE      DRIVES          ;ELSE ASK USER TO RETYPE DRIVES
3608
3609 ;ROUTINE TO GET SLAVES (TU45'S) USER DESIRES TO TEST
3610 SLAVES: CLR      @#ERFLG          ;CLEAR ERROR INDICATOR
3611          MOV      #SLVTBL,R1      ;MARK ALL SLAVES (64.) AS NOT
3612          MOV      #32.,R0         ;TO BE TESTED.A 0 INDICATES THAT
3613          CLR      (R1)+           ;A DRIVE'S SLAVE IS NOT TO BE
3614          DEC      R0              ;TESTED
3615          BNE     1$
3616          MOV      #SLVTBL,R1      ;R1 POINTS TO DRIVE'S SLAVE
3617          TSTB   DRVTBL(R0)       ;BRANCH IF DRIVE IS TO BE TESTED
3618          BNE     4$              ;& IS AVAILABLE
3619          ADD     #8.,R1           ;STEP SLAVE PTR TO NEXT DRIVE'S
3620          INC     R0              ;SLAVES AND INCREMENT DRIVE #
3621          CMPB   #8.,R0           ;CHECK ALL DRIVES
3622          BNE     2$              ;AND WHEN ALL DRIVES CHECKED
3623          BR     CHKSLV           ;GO CHECK SLAVE AVAILABILITY
3624
3625          TSTB   @#PRGFLG         ;BRANCH IF USER SELECTED ALL
3626          BNE     5$              ;DRIVES
3627          MOVB   RO,DRVNUM         ;GET DRIVE #
3628          MOVB   DIGTAB(RO),@#1.DRV ;PREPARE USER ACTION MESSAGE
3629          TYPE ,I.SLVS
3630          JSR   PC, .INPUT        ;GET USER INPUT
3631          MOV   #INBUF,R3         ;SET PTR TO USER INPUT
3632          CMPB  #'A,(R3)         ;AN 'A' OR <CR> AS FIRST CHAR
3633          BEQ   5$                ;INDICATES TEST ALL SLAVES
3634          CMPB  #CR,(R3)
3635          BNE   7$
3636          MOVB  SP,@#PRGFLG       ;SET 'ALL' INDICATOR
3637          MOV  #SLVTBL,R1        ;MARK ALL SLAVES FOR ALL
3638          MOV  #32.,R0           ;DRIVES AS TO BE TESTED
3639          MOV  #-1,(R1)+
3640          DEC  R0
3641          BNE  6$
3642          TSTB  @#PRGFLG         ;BRANCH IF ALL WAS SELECTED
3643          BNE  CHKSLV
3644
3645          CMPB  #CR,(R3)         ;GET USER SELECTED SLAVES FOR
3646          BEQ  3$                ;DRIVE
3647          CMPB  (R3),#',         ;STEP PTR PAST 'COMMA'
3648          BNE  8$
3649          TSTB  (R3)+
3650          MOVB  (R3)+,R4         ;AND MARK SELECED SLAVE
3651          BIC  #17770,R4        ;AS TO BE TESTED
3652          ADD  R1,R4
3653          MOVB  #-1,(R4)
3654          BR   7$
3655
3656 ;ASCERTAIN THAT SLAVES (TU45'S) SELECTED ARE AVAILABLE
3657 CHKSLV: CLR      R0              ;RO WILL CONTAIN THE DRIVE #
3658          COM      R0              ;COMPLEMENT DRIVE #
3659          MOV      #SLVTBL,R2     ;SET PTR TO SLAVE TABLE
3660          INC      R0              ;INCREMENT DRIVE NUMBER
3661          CMP      #8.,R0         ;CHECK FOR END
3662          BEQ      8$              ;IF SO:BR
  
```

013726


```

3663 006630 105760 001154          TSTB  DRVTBL(R0)          ;BRANCH IF DRIVE SELECTED
3664 006634 001003          BNE   3$                  ;AND AVAILABLE FOR TEST
3665 006636 062702 000010          ADD   #8.,R2              ;ELSE STEP SLAVE PTR TO
3666 006642 000766          BR    1$                  ;NEXT DRIVES SLAVES AND CHECK
3667                                     ;FOR DRIVE
3668
3669 006644 005001          3$: CLR   R1              ;SET SLAVE # 0
3670 006646 105712          4$: TSTB (R2)             ;BRANCH IF DRIVE'S SLAVE IS SEL-
3671 006650 001006          BNE   6$                  ;ECTED FOR TEST
3672 006652 005201          5$: INC  R1              ;INCREMENT SLAVE #
3673 006654 005202          INC  R2                  ;STEP PTR TO NEXT SLAVE
3674 006656 022701 000010          CMP   #8.,R1             ;GO TO 4$ IF ALL SLAVES NOT
3675 006662 001371          BNE   4$                  ;CHECKED
3676 006664 000755          BR    1$                  ;OTHERWISE GO TO 1$ ABOVE
3677
3678 006666 110037 001004          6$: MOVB  R0,@#DRVNUM     ;PASS DRIVE & SLAVE #
3679 006672 110137 001005          MOVB  R1,@#SLVNUM
3680 006676 004737 005040          JSR   PC,@#SLVAVA       ;AND CHECK IF AVAILABLE
3681 006702 102363          BVC   5$                  ;'V' SET INDICATES ERROR
3682 006704 105737 001124          TSTB  @#PRGFLG          ;DO NOT TYPE ERROR MSG IF ALL
3683 006710 001012          BNE   7$                  ;SLAVES SELECTED
3684 006712 116037 001132 014163          MOVB  DIGTAB(R0),@#E.DRV ;ICATES ERROR. PREPARE ERROR
3685 006720 116137 001132 014173          MOVB  DIGTAB(R1),@#E.NAVA ;MESSAGE
3686 006726 000004 014155          TYPE ,E.NSLV
3687 006732 110637 001123          MOVB  SP,@#ERFLG
3688 006736 105012          7$: CLRB (R2)             ;SET ERROR INDICATOR
3689 006740 000744          BR    5$                  ;CLEAR SLAVE TABLE ENTRY
3690                                     ;GET NEXT SLAVE
3691 006742 105737 001123          8$: TSTB  @#ERFLG       ;BRANCH IF ERROR
3692 006746 001214          BNE   SLAVES             ;ASK USER TO RETYPE SLAVES
3693 006750 012737 003542 000004          100$: MOV  #ERRTRP,@#ERRVEC
3694
3695          ;SCAN DRIVE AND SLAVE TABLE FOR DRIVE/SLAVE COMBINATION TO TEST.
3696          ;RESTART ADDRESS--PROGRAM STARTS HERE WHEN START ADDRESS = 210 AND
3697          ;AFTER EACH PASS
3698 006756 105037 001004          RSTRT: CLRB @#DRVNUM     ;SET DRIVE AND SLAVE # 0
3699 006762 105037 001005          CLRB  @#SLVNUM
3700 006766 012737 001164 001006          MOV   #SLVTBL,@#SLVPTR  ;SET PTR TO SLAVE TABLE
3701 006774 105037 001125          CLRB  @#UNTFND          ;CLEAR 'UNIT FOUND' IND.
3702
3703          ;PROGRAM RESTARTS HERE AFTER EACH DRIVE/SLAVE HAS BEEN TESTED.
3704 BEGIN: MOVB  @#DRVNUM,R0  ;GET DRIVE #
3705          MOVB  @#SLVNUM,R1  ;AND SLAVE #
3706          MOV   @#SLVPTR,R2  ;GET SLAVE PTR
3707          CMPB  #6,@#41      ;BRANCH IF LOADED VIA TMDP
3708          BNE   1$
3709          TST   @#DRVNUM     ;TEST FOR DRIVE#0,SLAVE#0
3710          BNE   1$          ;IF NOT : BR
3711          CLRB (R2)         ;SET DRIVE #0,SLAVE #0 NOT TO
3712                                     ;BE TESTED.
3713 007034 105760 001154          1$: TSTB  DRVTBL(R0)     ;BRANCH IF DRIVE AVAIL TO TEST
3714 007040 001011          BNE   3$
3715 007042 005001          CLR   R1                  ;CLEAR SLAVE #
3716 007044 062702 000010          ADD   #8.,R2              ;AND STEP PTR TO NEXT DRIVE'S
3717 007050 005200          2$: INC  R0                ;SLAVES AND INCREMENT DRIVE #
3718 007052 022700 000010          CMP   #8.,R0              ;EXIT TEST IF ALL DRIVES

```

```
3719 007056 001366          BNE 1$           ;CHECKED OTHERWISE CONTINUE
3720 007060 000137 012632    JMP @#END        ;SCAN FOR NEXT 'UNIT'
3721
3722 007064 105712          3$: TSTB (R2)     ;BRANCH IF SLAVE ON DRIVE IS
3723 007066 001007          BNE 4$           ;AVAILABLE THERWISE STEP
3724 007070 005202          INC R2           ;PTR TO NEXT SLAVE
3725 007072 005201          INC R1           ;INCREMENT SLAVE #
3726 007074 122701 000010    CMPB #B.,R1     ;UNTIL ALL SLAVES CHECKED
3727 007100 001371          BNE 3$           ;WHEN ALL SLAVES CHECKED
3728 007102 005001          CLR R1          ;SET SLAVE # 0
3729 007104 000761          BR 2$           ;AND CONTINUE SCAN
3730
3731 007106 110637 001125    4$: MOVB SP,@#UNTFND ;INDICATE THAT A 'UNIT' IS FOUND
3732 007112 110037 001004    MOVB RO,@#DRVNUM ;SET DRIVE 3
```

```

3737 007116 110137 001005      MOVB  R1,@#SLVNUM      ;SET SLAVE #
3738 007122 010237 001006      MOV   R2,@#SLVPTR     ;SAVE SLAVE PTR
3739
3740 007126 105737 001130      5$:  TSTB  @#ASFLG
3741 007132 001034              BNE   7$
3742 007134 112737 000001 001130  MOVB  #1,ASFLG
3743 007142 105037 001124      CLRB  @#PRGFLG      ;CLEAR PROGRAM INDICATOR
3744 007146 005737 005746      TST   CHNFLG        ;BRANCH IF IN CHAIN MODE
3745 007152 001024              BNE   7$
3746 007154 000004 013773      TYPE,.I.SPD        ;ASK USER IF HE WANTS TO RUN SPEED TESTS
3747 007160 004737 003272      JSR   PC,..INPUT    ;GET USER INPUT
3748 007164 012703 001264      MOV   #INBUF,R3     ;GET REPLY
3749 007170 122713 000015      CMPB  #CR,'R3'      ;DO NOT DO SKEW TESTS IF <CR> IS FIRST
3750 007174 001405              BEQ   6$
3751 007176 132713 000001      BITB  #1,(R3)       ;BRANCH IF 'N'
3752 007202 001402              BEQ   6$
3753 007204 111337 001124      MOVB  (R3),@#PRGFLG ;SET INDICATOR
3754 007210 022737 000176 001000  6$:  CMP   #SWREG,SWR    ;BRANCH IF SOFTWARE SWR
3755 007216 001002              BNE   7$            ;NOT INVOKED
3756 007220 004737 002020      JSR   PC,GTSWR      ;GET SWITCH REGISTER
3757 007224
3758
3759
3760
3761 007224 105037 001122      ;NOTE THIS IS NOT A TEST
3762 007230 013705 001010      ;INITIALIZE PROGRAM FLAGS
3763 007234 010500              TST000: CLRB @#TSTNUM
3764 007236 062700 000006      MOV   @#TMBASE,R5   ;SET ADDRESS OF FIRST TMO3 REG
3765 007242 010501              MOV   R5,R0
3766 007244 062701 000012      ADD   #FC,R0        ;R0 CONTAINS ADDRESS OF FC REG
3767 007250 012703 004340      MOV   R5,R1
3768 007254 105037 001121      ADD   #DS,R1        ;R1 CONTAINS ADDRESS OF DS REG
3769 007260 052737 000100 177560  MOV   #TIMER,R3     ;SET JUMP ADDRESS TO TIMER
3770
3771
3772
3773
3774 007266 105737 001124      CLRB  @#ITCNT       ;CLEAR SUBTEST ITERATION COUNT
3775 007272 001042              BIS   #100,@#TKS    ;SET KEYBOARD IE BIT
3776
3777 007274 004737 005262      ;GET USER RUN PROCEDURE
3778 (1) 007300 102471              ;IF SWR<05::00> IS NOT 0 THEN RUN TEST IN SWR<05::00>
3779 007302 004737 005344      ;OTHERWISE RUN ALL TESTS
3780 007310 004737 005156      TSTB  @#PRGFLG      ;SPEED TESTS?
3781 007314 102463              BNE   2$            ;IF SO: BR
3782 007316 005737 005746      JSR   PC,..REWIND   ;REWIND SLAVE
3783 007322 001061              BVS   99$           ;BRANCH IF ERROR ON REWIND
3784 007324 117702 171450      JSR   PC,WRITE      ;WRITE A RECORD
3785 007330 042702 177740      INC   (R5)          ;SET 'GO' BIT
3786 007334 001421              JSR   PC,WAITRDY    ;WAIT FOR READY
3787 007336 000004 014353      BVS   99$
3788 007342 004737 002426      TST   CHNFLG        ;BRANCH IF IN CHAIN MODE
3789 007346 006302              BNE   100$
3790 007350 016237 001656 007360  MOVB  @SWR,R2        ;GET SWITCHES
3791 007356 000004              BIC  #177740,R2     ;CLEAR ALL BUT TEST #
3792
3793
3794
3795
3796
3797
3798
3799
3800
3801
3802
3803
3804
3805
3806
3807
3808
3809
3810
3811
3812
3813
3814
3815
3816
3817
3818
3819
3820
3821
3822
3823
3824
3825
3826
3827
3828
3829
3830
3831
3832
3833
3834
3835
3836
3837
3838
3839
3840
3841
3842
3843
3844
3845
3846
3847
3848
3849
3850
3851
3852
3853
3854
3855
3856
3857
3858
3859
3860
3861
3862
3863
3864
3865
3866
3867
3868
3869
3870
3871
3872
3873
3874
3875
3876
3877
3878
3879
3880
3881
3882
3883
3884
3885
3886
3887
3888
3889
3890
3891
3892
3893
3894
3895
3896
3897
3898
3899
3900
3901
3902
3903
3904
3905
3906
3907
3908
3909
3910
3911
3912
3913
3914
3915
3916
3917
3918
3919
3920
3921
3922
3923
3924
3925
3926
3927
3928
3929
3930
3931
3932
3933
3934
3935
3936
3937
3938
3939
3940
3941
3942
3943
3944
3945
3946
3947
3948
3949
3950
3951
3952
3953
3954
3955
3956
3957
3958
3959
3960
3961
3962
3963
3964
3965
3966
3967
3968
3969
3970
3971
3972
3973
3974
3975
3976
3977
3978
3979
3980
3981
3982
3983
3984
3985
3986
3987
3988
3989
3990
3991
3992
3993
3994
3995
3996
3997
3998
3999
4000

```

3792	007360	000000			1\$:	.WORD 0	
3793	007362	000004	001374			TYPE,CRLF	
3794	007366	016237	001736	001002		MOV TSTTBL(R2),@#SCPADR	;SET SCOPE ADDRESS FOR TEST
3795	007374	000172	001736			JMP @TSTTBL(R2)	;GO TO TEST
3796	007400	000004	014562		2\$:	TYPE,L.HDR1	
3797	007404	113702	001004			MOVB DRVNUM,R2	;GET DRIVE #
3798	007410	113704	001005			MOVB SLVNUM,R4	;AND SLAVE #
3799	007414	116237	001132	014742		MOVB DIGTAB(R2),@#L.DRV	;SET DRIVE AND SLAVE #'S
3800	007422	116437	001132	014754		MOVB DIGTAB(R4),@#L.SLV	;INTO L.HDR2 MESSAGE
3801	007430	112737	000071	014757		MOVB #'9,@#L.CHAN	;GET SLAVES CHANNEL TYPE
3802	007436	000004	014675			TYPE,L.HDR2	
3803	007442	004737	005520			JSR PC,SNPT	;PRINT SLAVE SERIAL #
3804	007446	000004	014776			TYPE,L.HDR3	
3805	007452	105737	001124			TSTB @#PRGFLG	;BRANCH IF SPEED TESTS NOT
3806	007456	001403				BEQ 100\$;SELECTED
3807	007460	000137	012756			JMP @#SKEWTST	;GO DO SPEED TESTS
3808	007464	104400			99\$:	HLT	
3809	007466	012737	007474	001002	100\$:	MOV #TST001,@#SCPADR	;SET SCOPE LOOP ADDRESS
3810							

```
3812          .SBTTL START OF TESTS
3813          :TEST 001 - WRITE FROM BOT
3814          :THIS TEST WILL MEASURE ACCELERATION DELAY REQUIRED TO
3815          :MOVE THE TAPE APPROXIMATELY SEVEN (7) INCHES FORWARD
3816          :FROM DEAD STOP BEFORE STARTING TO TRANSFER DATA.
3817
3818          :THIS TEST MEASURES TIME FROM 'GO'=1 TO 'ACCL'=0.
3819 007474 112737 000001 001122 TST001: MOVB #1,@#TSTNUM      ;SET TEST #
3820 007502 012702 007526          MOV #1$,R2          ;SET RETURN PC FROM TIMER
3821 007506 004737 005262          JSR PC,.REWIND     ;REWIND SLAVE
(1) 007512 102420          BVS 99$           ;BRANCH IF ERROR ON REWIND
3822 007514 004737 005344          JSR PC,WRITE      ;GO SETUP WRITE COMMAND
3823 007520 004737 004250          JSR PC,TIMON     ;TURN TIMER ON
3824 007524 005215          INC (R5)         ;SET 'GO' BIT
3825
3826 007526 005765 000032          1$: TST TC(R5)    ;BRANCH WHEN 'ACCL'=0
3827 007532 100002          BPL 2$
3828 007534 000163 004340          JMP TIMER(R3)    ;GO TO TIMER & RETURN VIA R2
3829
3830 007540 004737 005156          2$: JSR PC,WAITRDY ;WAIT FOR COMMAND TO FINISH
3831 007544 102403          BVS 99$           ;BRANCH IF ERROR
3832 007546 004737 004376          JSR PC,TIMOK     ;GO CHECK TIME
3833 007552 000401          BR 100$
3834 007554 104400          99$: HLT
3835 007556 104000          100$: SCOPE
3836
3837          :TEST 002 - WRITE START
3838          :THIS TST MEASURES TIME FROM 'GO'=1 TO 'ACCL'=0.
3839 007560 112737 000002 001122 TST002: MOVB #2,@#TSTNUM      ;SET TEST # 2
3840 007566 004737 005344          JSR PC,WRITE     ;INITIATE WRITE COMMAND
3841 007572 012702 007604          MOV #1$,R2      ;SET RETURN PC FROM TIMER
3842 007576 004737 004250          JSR PC,TIMON     ;SET 'GO' BIT
3843 007602 005215          INC (R5)
3844
3845 007604 005765 000032          1$: TST TC(R5)    ;BRANCH WHEN 'ACCL'=0
3846 007610 100002          BPL 2$
3847 007612 000163 004340          JMP TIMER(R3)    ;GO TO TIMER & RETURN VIA R2
3848
3849 007616 004737 005156          2$: JSR PC,WAITRDY ;WAIT FOR READY
3850 007622 102403          BVS 99$           ;BRANCH IF ERROR
3851 007624 004737 004376          JSR PC,TIMOK     ;GO CHECK TIME RECORDED
3852 007630 000401          BR 100$           ;EXIT VIA SCOPE
3853
3854 007632 104400          99$: HLT           ;REPORT ERROR
3855 007634 104000          100$: SCOPE
3856
3857          :TEST 003- WRITE SHUTDOWN
3858          :THIS TEST MEASURES TIME FROM 'FC REG'=0 TO 'SWDN'=1.
3859 007636 112737 000003 001122 TST003: MOVB #3,@#TSTNUM      ;SET TEST#3
3860 007644 004737 005344          JSR PC,WRITE     ;INITIATE WRITE COMMAND
3861 007650 005215          INC (R5)         ;SET 'GO' BIT
3862
3863 007652 005710          1$: TST (R0)      ;BRANCH WHEN WRITING FINISHED
3864 007654 001404          BEQ 2$
3865 007656 032711 040000          BIT #ERR,(R1)   ;MONITOR ERROR BIT
3866 007662 001017          BNE 99$
```

```

3867 007664 000772          BR      1$
3868
3869 007666          2$:      JSR      PC,TIMON      ;TURN TIMER ON
(1) 007666 004737 004250      MOV      PC,R2      ;LOAD RETURN PC FROM TIMER
3870 007672 010702          BIT      #SDWN,(R1)  ;BRANCH WHEN DS <SDWN> SETS
3871 007674 032711 000020          BNE      4$
3872 007700 001002          JMP      TIMER(R3)  ;GO TO TIMER & RETURN VIA R2
3873 007702 000163 004340          JSR      PC,WAITRDY ;WAIT FOR READY
3874
3875 007706 004737 005156          BVS      99$
3876 007712 102403          JSR      PC,TIMOK   ;GO CHECK TIME RECORDED
3877 007714 004737 004376          BR      100$
3878 007720 000401          99$:     HLT
3879 007722 104400          100$:    SCOPE      ;REPORT ERROR
3880 007724 104000
3881
3882          ;TEST 004 - WRITE SETTLEDOWN
3883          ;THIS TEST MEASURES TIME FROM 'SWDN'=1 TO 'SWDN'=0.
3884 007726 112737 000004 001122 TST004: MOVB #4,#TSTNUM
3885 007734 004737 005344          JSR      PC,WRITE
3886 007740 005215          INC      (R5)      ;SET 'GO' BIT
3887
3888 007742 005710          1$:     TST      (R0)  ;BRANCH WHEN WRITING FINISHED
3889 007744 001404          BEQ      2$
3890 007746 032711 040000          BIT      #ERR,(R1) ;CHECK ERROR BIT
3891 007752 001026          BNE      99$
3892 007754 000772          BR      1$
3893
3894 007756 032711 000020          2$:     BIT      #SDWN,(R1) ;WAIT FOR ASSERTION OF 'SDWN'
3895 007762 001004          BNE      3$
3896 007764 032711 040000          BIT      #ERR,(R1) ;MONITOR ERROR BIT
3897 007770 001017          BNE      99$
3898 007772 000771          BR      2$
3899
3900          3$:
(1) 007774 004737 004250          JSR      PC,TIMON   ;TURN TIMER ON
3901 010000 010702          MOV      PC,R2     ;SET RETURN PC FROM TIMER
3902 010002 032711 000020          BIT      #SDWN,(R1) ;BRANCH WHEN SWDN CLEARS
3903 010006 001402          BEQ      5$
3904 010010 000163 004340          JMP      TIMER(R3) ;GO TO TIMER & RETURN VIA R2
3905
3906 010014 004737 005156          5$:     JSR      PC,WAITRDY ;WAIT FOR READY
3907 010020 102403          BVS      99$
3908 010022 004737 004376          JSR      PC,TIMOK
3909 010026 000401          BR      100$
3910
3911          99$:     HLT
3912 010032 104000          100$:    SCOPE
3913
3914          ;TEST 005 - READ FROM BOT
3915          ;THIS TEST MEASURES TIME FROM 'GO'=1 TO 'ACCL'=0.
3916 010034 112737 000005 001122 TST005: MOVB #5,#TSTNUM
3917 010042 004737 005262          JSR      PC,.REWIND ;SET TEST #5
(1) 010046 102422          BVS      99$      ;REWIND SLAVE
3918 010050 004737 005362          JSR      PC,READ   ;BRANCH IF ERROR ON REWIND
3919 010054 012702 010066          MOV      #1$,R2   ;SET RETURN PC FROM TIMER
  
```

```

3920 010060 004737 004250      JSR    PC,TIMON      ;TURN TIMER ON
3921 010064 005215              INC    (R5)          ;SET 'GO' BIT
3922
3923 010066 005765 000032      1$:   TST    TC(R5)      ;BRANCH WHEN 'ACCL' RESETS
3924 010072 100002              BPL    2$            ;
3925 010074 000163 004340      JMP    TIMER(R3)     ;GO TO TIMER & RETURN VIA R2
3926
3927 010100 004737 005156      2$:   JSR    PC,WAITRDY   ;WAIT FOR READY
3928 010104 102403              BVS    99$          ;BRANCH IF ERROR
3929 010106 004737 004376      JSR    PC,TIMOK      ;CHECK RECORDED TIME
3930 010112 000401              BR     100$         ;
3931
3932 010114 104400      99$:   HLT
3933 010116 104000      100$:  SCOPE
3934
3935      ;TEST 006 - READ START
3936      ;THIS TEST MEASURES TIME FROM 'GO'=1 TO 'ACCL'=0.
3937 010120 112737 000006 001122  TST006: MOVB    #6,#TSTNUM      ;SET TEST #6
3938 010126 004737 005436      JSR    PC,WRT.BK     ;WRITE A RECORD & BACK SPACE
3939 010132 102422              BVS    99$
3940 010134 004737 005362      JSR    PC,READ
3941 010140 012702 010152      MOV    #1$,R2        ;SET RETURN PC FROM TIMER
3942 010144 004737 004250      JSR    PC,TIMON      ;TURN TIMER ON
3943 010150 005215              INC    (R5)          ;SET 'GO' BIT
3944
3945 010152 005765 000032      1$:   TST    TC(R5)      ;BRANCH WHEN 'ACCL' RESETS
3946 010156 100002              BPL    2$            ;
3947 010160 000163 004340      JMP    TIMER(R3)     ;GO TO TIMER & RETURN VIA R2
3948
3949 010164 004737 005156      2$:   JSR    PC,WAITRDY   ;
3950 010170 102403              BVS    99$
3951 010172 004737 004376      JSR    PC,TIMOK      ;
3952 010176 000401              BR     100$
3953
3954 010200 104400      99$:   HLT
3955 010202 104000      100$:  SCOPE
3956
3957      ;TEST 007 - READ SHUTDOWN
3958      ;THIS TEST MEASURES TIME FROM 'FC REG'=FRAME COUNT TO 'SDWN'=1.
3959 010204 112737 000007 001122  TST007: MOVB    #7,#TSTNUM      ;SET TEST #7
3960 010212 004737 005436      JSR    PC,WRT.BK     ;WRITE A RECORD & BACK SPACE
3961 010216 102430              BVS    99$          ;BRANCH IF ERROR
3962 010220 004737 005362      JSR    PC,READ
3963 010224 005215              INC    (R5)          ;SET 'GO' BIT
3964
3965 010226 022710 000400      1$:   CMP    #-FRMCNT,(R0)   ;WAIT FOR FRAME COUNT TO
3966 010232 001404              BEQ    2$            ;= # OF FRAMES WRITTEN
3967 010234 032711 040000      BIT    #ERR,(R1)     ;MONITOR ERROR BIT
3968 010240 001017              BNE    99$
3969 010242 000771              BR     1$
3970
3971 010244              2$:   JSR    PC,TIMON      ;TURN TIMER ON
3972 010250 010702              MOV    PC,R2        ;SET RETURN PC FROM TIMER
3973 010252 032711 000020      BIT    #SDWN,(R1)    ;BRANCH WHEN SDWN SETS
3974 010256 001002              BNE    3$
  
```

```

3975 010260 000163 004340          JMP      TIMER(R3)          ;GO TO TIMER & RETURN VIA R2
3976
3977 010264 004737 005156          3$:     JSR      PC, WAITRDY
3978 010270 102403                    BVS     99$
3979 010272 004737 004376          JSR     PC, TIMOK
3980 010276 000401                    BR      100$
3981
3982 010300 104400                    99$:    HLT
3983 010302 104000                    100$:   SCOPE                ;REPORT ERROR
3984
3985
3986
3987 010304 112737 000010 001122  ;TEST 010 - READ SETTLEDOWN
3988 010312 012702 010370          ;THIS TEST MEASURES TIME FROM 'SDWN'=1 TO 'SDWN'=0.
3989 010316 004737 005436          TST010: MOVB    #10, @#TSTNUM ;SET TEST #10
3990 010322 102436                    MOV     #4$, R2             ;SET RETURN PC FROM TIMER
3991 010324 004737 005362          JSR     PC, WRT.BK         ;WRITE A RECORD & BACK SPACE
3992 010330 005215                    BVS     99$
3993
3994 010332 105711                    JSR     PC, READ          ;SET 'GO' BIT
3995 010334 100404                    INC     (R5)
3996 010336 032711 040000          1$:     TSTB    (R1)        ;WAIT FOR READY
3997 010342 001026                    BMI     2$                ;BRANCH WHEN SET
3998 010344 000772                    BIT     #ERR, (R1)       ;CHECK ERROR BIT
3999
4000 010346 032711 000020          2$:     BNE     #SDWN, (R1) ;WAIT FOR ASSERTION OF 'SDWN'
4001 010352 001004                    BNE     3$
4002 010354 032711 040000          BIT     #ERR, (R1)       ;MONITOR ERROR BIT
4003 010360 001017                    BNE     99$
4004 010362 000771                    BR      2$
4005
4006 010364
4007 010364 004737 004250          (1)    JSR     PC, TIMON      ;TURN TIMER ON
4008 010370 07.75 000020 000012  4$:     BIT     #SDWN, DS(R5) ;WAIT FOR NEGATION OF SDWN
4009 010376 001402                    BEQ     5$
4010 010400 000163 004340          JMP     TIMER(R3)        ;GO TO TIMER & RETURN VIA R2
4011 010404 004737 005156          5$:     JSR     PC, WAITRDY
4012 010410 102403                    BVS     99$
4013 010412 004737 004376          JSR     PC, TIMOK
4014 010416 000401                    BR      100$
4015
4016 010420 104400                    99$:    HLT
4017 010422 104000                    100$:   SCOPE
4018
4019
4020
4021
4022 010424 112737 000011 001122  ;TEST 011-READ REVERSE START
4023 010432 012702 010470          ;THIS TEST MEASURES TIME FROM 'GO'=1 TO 'ACCL'-0.
4024 010436 004737 005344          TST011: MOVB    #11, @#TSTNUM ;SET RETURN PC FROM TIMER
4025 010442 005215                    MOV     #1$, R2           ;WRITE A RECORD
4026 010444 004737 005156          JSR     PC, WRITE
4027 010450 102422                    INC     (R5)              ;SET 'GO' BIT
4028 010452 004737 004634          JSR     PC, WAITRDY
4029 010456 004737 005400          JSR     PC, DELAY        ;WAIT FOR TAPE MOTION TO STOP
4030
4031
4032
4033
4034
4035
4036
4037
4038
4039
4040
4041
4042
4043
4044
4045
4046
4047
4048
4049

```



```

4030 010462 004737 004250      JSR    PC,TIMON      ;TURN TIMER ON
4031 010466 005215              INC    (R5)          ;SET 'GO' BIT
4032
4033 010470 005765 000032      1$:   TST    TC(R5)      ;BRANCH WHEN 'ACCL' = 0
4034 010474 100002              BPL    2$
4035 010476 000163 004340      JMP    TIMER(R3)     ;GO TO TIMER & RETURN VIA R2
4036
4037 010502 004737 005156      2$:   JSR    PC,WAITRDY
4038 010506 102403              BVS    99$          ;BRANCH IF ERROR
4039 010510 004737 004376      JSR    PC,TIMOK
4040 010514 000401              BR     100$
4041
4042 010516 104400              99$:   HLT
4043 010520 104000              100$:  SCOPE
4044
4045
4046
4047 010522 112737 000012 001122 ;TEST 012-READ REVERSE SHUTDOWN
4048 010530 012702 010600 ;THIS TEST MEASURES TIME FROM 'FC REG' = FRAME COUNT TO 'SDWN'=1.
4049 010534 004737 005344 TST012: MOVB    #12,@#TSTNUM
4050 010540 005215              MOV    #3$,R2      ;SET RETURN PC FROM TIMER
4051 010542 004737 005156      JSR    PC,WRITE     ;WRITE A RECORD
4052 010546 102427              INC    (R5)        ;SET 'GO' BIT
4053 010550 004737 005400      JSR    PC,WAITRDY
4054 010554 005215              BVS    99$
4055
4056 010556 022710 000400      1$:   JSR    PC,REVRD   ;SET 'GO' BIT
4057 010562 001404              INC    (R5)
4058 010564 032711 040000      1$:   CMP    #-FRMCNT,(R0) ;BRANCH WHEN FRAME COUNT
4059 010570 001016              BEQ    2$          ;= # OF RECORD WRITTEN
4060 010572 000771              BIT    #ERR,(R1)  ;MONITOR ERROR BIT IN 'DS' REG
4061
4062 010574
4063 010574 004737 004250      2$:   JSR    PC,TIMON   ;TURN TIMER ON
4064 010600 032711 000020      3$:   BIT    #SDWN,(R1) ;BRANCH WHEN SDWN SETS
4065 010604 001002              BNE    4$
4066 010606 000163 004340      JMP    TIMER(R3)   ;GO TO TIMER & RETURN VIA R2
4067 010612 004737 005156      4$:   JSR    PC,WAITRDY ;WAIT FOR READY
4068 010616 102403              BVS    99$
4069 010620 004737 004376      JSR    PC,TIMOK
4070 010624 000401              BR     100$
4071
4072 010626 104400              99$:   HLT
4073 010630 104000              100$:  SCOPE
4074
4075
4076
4077 010632 112737 000013 001122 ;TEST 013-READ REVERSE SETTLEDOWN
4078 010640 012702 010724 ;THIS TEST MEASURES TIME FROM 'SDWN'=1 TO 'SDWN'=0.
4079 010644 004737 005344 TST013: MOVB    #13,@#TSTNUM
4080 010650 005215              MOV    #4$,R2      ;SET RETURN PC FROM TIMER
4081 010652 004737 005156      JSR    PC,WRITE     ;WRITE A RECORD
4082 010656 102435              INC    (R5)        ;SET 'GO' BIT
4083 010660 004737 005400      JSR    PC,WAITRDY
4084 010664 005215              BVS    99$
4085
4086 010666 004737 005400      JSR    PC,REVRD   ;SET 'GO' BIT
4087 010666 005215              INC    (R5)

```

```

4085
4086 010666 105711      1$:   TSTB   (R1)           ;BRANCH WHEN
4087 010670 100404      BMI     2$             ;READY SETS
4088 010672 032711 040000 BIT     #ERR,(R1)
4089 010676 001025      BNE     99$
4090 010700 C00772      BR      1$
4091
4092 010  ?  03 ,11 000020 2$:   BIT     #SDWN,(R1)
4093 010706 C01004      BNE     3$
4094 010710 032711 040000 BIT     #ERR,(R1)
4095 010714 001016      BNE     99$
4096 010716 000771      BR      2$
4097
4098 010720      3$:
(1) 010720 004737 004250 JSR     PC,TIMON      ;TURN TIMER ON
4099 010724 032711 000020 4$:   BIT     #SDWN,(R1)  ;BRANCH WHEN SWDN = 0
4100 010730 001402      BEQ     5$
4101 010732 000163 004340 JMP     TIMER(R3)    ;GO TO TIMER & RETURN VIA R2
4102
4103 010736 004737 005156 5$:   JSR     PC,WAITRDY  ;WAIT FOR READY
4104 010742 102403      BVS     99$
4105 010744 004737 004376 JSR     PC,TIMOK
4106 010750 000401      BR      100$
4107
4108 010752 104400      99$:   HLT
4109 010754 104000      100$: SCOPE
4110
4111 ;REWIND DRIVE
4112 010756      A:
(1) 010756 004737 005262 JSR     PC,.REWIND   ;REWIND SLAVE
(1) 010762 102401      BVS     99$          ;BRANCH IF ERROR ON REWIND
4113 010764 102002      BVC     100$
4114 010766 104400      99$:   HLT
4115 010770 000772      BR      A
4116 010772      100$:
4117
4118 ;TEST 014-TURN AROUND DELAY (FORWARD-REVERSE)
4119 ;THIS TEST MEASURES TIME FROM 'GO'=1 (READ REVERSE) TO 'ACCL'=0
4120 010772 112737 000014 001122 TST014: MOVB  #14,@#TSTNUM
4121 011000 012702 011032 MOV     #2$,R2      ;SET RETURN PC FROM TIMER
4122 011004 004737 005344 JSR     PC,WRITE    ;WRITE A RECORD
4123 011010 005215      INC     (R5)       ;SET 'GO' BIT
4124 011012 004737 005156 JSR     PC,WAITRDY
4125 011016 102420      BVS     99$
4126
4127 011020 004737 005400 1$:   JSR     PC,REVRD   ;READ THE RECORD (REVERSE)
4128 011024 004737 004250 JSR     PC,TIMON    ;TURN TIMER ON
4129 011030 005215      INC     (R5)       ;SET 'GO' BIT
4130
4131 011032 005765 000032 2$:   TST     TC(R5)    ;WAIT FOR 'ACCL' - 0
4132 011036 100002      BPL     3$
4133 011040 000163 004340 JMP     TIMER(R3)   ;GO TO TIMER & RETURN VIA R2
4134
4135 011044 004737 005156 3$:   JSR     PC,WAITRDY
4136 011050 102403      BVS     99$
4137 011052 004737 004376 JSR     PC,TIMOK
    
```

```

4138 011056 000401          BR      100$
4139
4140 011060 104400          99$:   HLT
4141 011062 104000          100$:  SCOPE
4142
4143                          ;TEST 015- TURN AROUND DELAY (REVERSE-FORWARD)
4144                          ;THIS TEST MEASURES TIME FROM 'GO'=1 (READ) TO 'ACCL'=0.
4145 C11064 112737 000015 001122 TST015: MOVB  #15,@#TSTNUM
4146 011072 012702 011140          MOV   #2$,R2          ;SET RETURN PC FROM TIMER
4147 011076 004737 005344          JSR   PC,WRITE        ;WRITE A RECORD
4148 011102 005215          INC   (R5)           ;SET 'GO' BIT
4149 011104 004737 005156          JSR   PC,WAITPDY     ;WAIT FOR READY
4150 011110 102426          BVS  99$
4151 011112 004737 005400          JSR   PC,REVRD       ;READ A RECORD IN THE
4152 011116 005215          INC   (R5)           ;SET 'GO' BIT
4153
4154 011120 004737 005156          JSR   PC,WAITRDY
4155 011124 102420          BVS  99$
4156
4157 011126 004737 005362          1$:   JSR   PC,READ   ;READ RECORD FORWARD
4158 011132 004737 004250          JSR   PC,TIMON       ;TURN TIMER ON
4159 011136 005215          INC   (R5)           ;SET 'GO' BIT
4160
4161 011140 005765 000032          2$:   TST   TC(R5)    ;WAIT FOR 'ACCL' = 0
4162 011144 100002          BPL  3$
4163 011146 000163 004340          JMP   TIMER(R3)     ;GO TO TIMER & RETURN VIA R2
4164
4165 011152 004737 005156          3$:   JSR   PC,WAITRDY
4166 011156 102403          BVS  99$
4167 011160 004737 004376          JSR   PC,TIMOK
4168 011164 000401          BR    100$
4169
4170 011166 104400          99$:   HLT
4171 011170 104000          100$:  SCOPE
4172
4173                          ;TEST 016-GAP SIZE (STOP HALF)
4174 011172 112737 000016 001122 TST016: MOVB  #16,@#TSTNUM
4175 011200 012702 011236          MOV   #1$,R2          ;SET RETURN PC FROM TIMER
4176 011204 004737 005344          JSR   PC,WRITE        ;WRITE A RECORD
4177 011210 005215          INC   (R5)           ;SET 'GO' BIT
4178 011212 004737 005156          JSR   PC,WAITRDY
4179 011216 102421          BVS  99$
4180 011220 004737 004634          JSR   PC,DELAY       ;DELAY 350 MS
4181 011224 004737 005400          JSR   PC,REVRD       ;READ REVERSE RECORD
4182 011230 004737 004250          JSR   PC,TIMON       ;TURN TIMER ON
4183 011234 005215          INC   (R5)           ;SET 'GO' BIT
4184
4185 011236 005710          1$:   TST   (R0)        ;WAIT FOR FRAME COUNT > 0
4186 011240 001002          BNE  2$
4187 011242 000163 004340          JMP   TIMER(R3)     ;GO TO TIMER & RETURN VIA R2
4188
4189 011246 004737 005156          2$:   JSR   PC,WAITRDY  ;WAIT FOR READY BIT TO SET
4190 011252 102403          BVS  99$
4191 011254 004737 004376          JSR   PC,TIMOK
4192 011260 000401          BR    100$
4193

```

```

4194 011262 104400          99$:   HLT
4195 011264 104000          100$:  SCOPE
4196
4197
4198 011266 112737 000017 001122 ;TEST 017-GAP SIZE (START HALF)
4199 011274 012702 011346          TST017: MOVB   #17,#TSTNUM
4200 011300 004737 005344          MOV    #1$,R2          ;SET RETURN PC FROM TIMER
4201 011304 005215          JSR    PC,WRITE        ;WRITE A RECORD
4202 011306 004737 005156          INC    (R5)           ;SET 'GO' BIT
4203 011312 102427          JSR    PC,WAITRDY     ;WAIT FOR READY
4204 011314 004737 005400          BVS   99$
4205 011320 005215          JSR    PC,REVRD       ;READ REVERSE THE RECORD
4206 011322 004737 005156          INC    (R5)           ;SET 'GO' BIT
4207 011326 102421          JSR    PC,WAITRDY     ;WAIT FOR READY
4208 011330 004737 004634          BVS   99$             ;BRANCH ON ERROR
4209 011334 004737 005362          JSR    PC,DELAY       ;WAIT FOR TAPE MOTION TO STOP
4210 011340 004737 004250          JSR    PC,READ        ;READ RECORD
4211 011344 005215          JSR    PC,TIMON       ;TURN TIMER ON
4212
4213 011346 005710          INC    (R5)           ;SET 'GO' BIT
4214 011350 001002          1$:   TST    (R0)       ;WAIT FOR FRAME COUNT > 0
4215 011352 000163 004340          BNE   2$
4216
4217 011356 004737 005156          JMP   TIMER(R3)       ;GO TO TIMER & RETURN VIA R2
4218 011362 102403          2$:   JSR    PC,WAITRDY     ;WAIT FOR READY
4219 011364 004737 004376          BVS   99$
4220 011370 000401          JSR    PC,TIMOK       ;CHECK TIME
4221
4222 011372 104400          BR    100$
4223 011374 104000          99$:   HLT
4224
4225          100$:  SCOPE
4226
4227 011376 112737 000020 001122 ;TEST 020- GAP SIZE (INTERRECORD)
4228 011404 012702 011466          ;THIS TEST MEASURES TIME FROM 'GO'=1 TO 'FC REG' >0.
4229 011410 004737 005344          TST020: MOVB   #20,#TSTNUM
4230 011414 005215          MOV    #1$,R2          ;SET RETURN PC FROM TIMER
4231 011416 004737 005156          JSR    PC,WRITE        ;WRITE A RECORD
4232 011422 102433          INC    (R5)           ;SET 'GO' BIT
4233 011424 004737 005344          JSR    PC,WAITRDY     ;WAIT FOR READY
4234 011430 005215          BVS   99$
4235 011432 004737 005156          JSR    PC,WRITE        ;WRITE SECOND RECORD
4236 011436 102425          INC    (R5)           ;SET 'GO' BIT
4237 011440 004737 005400          JSR    PC,WAITRDY     ;WAIT FOR READY
4238 011444 005215          BVS   99$
4239 011446 004737 005156          JSR    PC,REVRD       ;READ REVERSE SECOND RECORD
4240 011452 102417          INC    (R5)           ;SET 'GO' BIT
4241 011454 004737 005400          JSR    PC,WAITRDY     ;WAIT FOR READY
4242 011460 004737 004250          BVS   99$
4243 011464 005215          JSR    PC,REVRD       ;READ REVERSE FIRST RECORD
4244
4245 011466 005710          JSR    PC,TIMON       ;TURN TIMER ON
4246 011470 001002          INC    (R5)           ;SET 'GO' BIT
4247 011472 000163 004340          1$:   TST    (R0)       ;WAIT FOR FRAME COUNT > 0
4248
4249 011476 004737 005156          BNE   2$
4249          JMP   TIMER(R3)       ;GO TO TIMER & RETURN VIA R2
4249          2$:   JSR    PC,WAITRDY     ;WAIT FOR READY

```

E 6

```

4250 011502 102403          BVS 99$
4251 011504 004737 004376 JSR PC,TIMOK
4252 011510 000401          BR 100$
4253
4254 011512 104400          99$: HLT
4255 011514 104000          100$: SCOPE
4256
4257 ;TEST 021- GAP CONSISTANCY
4258 ;THIS TEST MEASURES TIME FROM 'GO'=1 TO 'FC REG' > 0.
4259 ;THE TEST REWINDS THE TAPE,WRITES 17 RECORDS WITH A DELAY FROM 1-16 MC
4260 ;BETWEEN EACH WRITE COMMAND. AFTER THE 17. RECORDS ARE WRITTEN THE
4261 ;PROGRAM READ REVERSES 16 RECORDS. AT THIS POINT THE TAPE IS STOPPED BE-
4262 ;TWEEN THE FIRST AND SECOND RECORD. A READ COMMAND IS EXECUTED TO READ
4263 ;THE 16 RECORDS WITH THE TIME BETEWEN GO=1 TO FC > 0 STORED IN 'GAPTBL'
4264 ;FOR EACH RECORD READ. AFTER 16 RECORDS HAVE BEEN READ THE TIME IS VER-
4265 ;IFIED FOR EACH READ. AFTER ALL RECORD TIMES ARE VERIFIED THEY ARE AVER-
4266 ;AGED AND PLACED IN THE 'ATIMTBL' (BY SCOPE). THE ABOVE PROCESS IS RE-
4267 ;PEATED FOR EACH ITERATION.
4268
4269 011516 112737 000021 001122 TST021: MOVB #21,@#TSTNUM
4270 011524 012702 011662          MOV #4$,R2 ;SET RETURN PC FROM TIMER
4271 011530 004737 005262          JSR PC,,REWIND ;REWIND SLAVE
(1) 011534 102530          BVS 99$ ;BRANCH IF ERROR ON REWIND
4272 011536 005037 001114          CLR DELTIM ;CLEAR VARIABLE DELAY TIME
4273 011542 012700 000021          MOV #17,,RO ;SET # OF RECORDS TO WRITE
4274 011546 004737 005344          1$: JSR PC,WRITE ;WRITE 17. RECORDS
4275 011552 005215          INC (R5) ;SET 'GO' BIT
4276 011554 004737 005156          JSR PC,WAITRDY ;WAIT FOR READY
4277 011560 102516          BVS 99$
4278 011562 004737 004664          JSR PC,DELAYV ;DELAY BEFORE WRITING NEXT REC.
4279 011566 062737 000022 001114 ADD #18,,DELTIM ;SET NEXT DELAY TIME
4280 011574 005300          DEC RO ;DECREMENT RECORDS WRITTEN COUNT
4281 011576 001363          BNE 1$
4282
4283 011600 012700 000021          MOV #17,,RO ;SET # OF RECS. TO REVERSE READ
4284 011604 004737 005400          2$: JSR PC,REVRD ;REVERSE READ 17. RECORDS
4285 011610 005215          INC (R5) ;SET 'GO' BIT
4286 011612 004737 005156          JSR PC,WAITRDY ;WAIT FOR READY
4287 011616 102477          BVS 99$
4288 011620 005300          DEC RO ;DECREMENT RECORD COUNT
4289 011622 001370          BNE 2$
4290
4291 011624 012700 000020          MOV #16,,RO ;SET # OF RECORDS TO READ
4292 011630 012701 001054          MOV #GAPTBL,R1 ;SET PTR TO GAP TABLE FOR TEST
4293 011634 004737 005362          JSR PC,READ ;READ A RECORD
4294 011640 005215          INC (R5) ;SET 'GO' BIT
4295
4296 011642 004737 005156          3$: JSR PC,WAITRDY ;WAIT FOR READY
4297 011646 102463          BVS 99$
4298 011650 004737 005362          JSR PC,READ ;READ NEXT RECORD
4299 011654 004737 004250          JSR PC,TIMON ;TURN TIMER ON
4300 011660 005215          INC (R5) ;SET 'GO' BIT
4301
4302 011662 005765 000006          4$: TST FC(R5) ;WAIT FOR FRAME COUNT > 0
4303 011666 001002          BNE 5$
4304 011670 000163 004340          JMP TIMER(R3) ;GO TO TIMER & RETURN VIA R2
  
```

```

4305
4306 011674 004737 005156 5$: JSR PC, WAITRDY ;WAIT FOR READY
4307 011700 102446 BVS 99$
4308 011702 010421 MOV R4, (R1)+ ;STORE TIME IN GAP TBL
4309 011704 005300 DEC R0 ;DECREMENT # OF RECORDS READ
4310 011706 001355 BNE 3$
4311
4312 011710 105037 001120 CLR R0 ;SET GAP # 0
4313 011714 012700 000020 MOV #16., R0
4314 011720 012701 001054 MOV #GAP TBL, R1
4315
4316 011724 012104 6$: MOV (R1)+, R4 ;GET GAP TICK COUNT
4317 011726 004737 004506 JSR PC, GAPOK ;CHECK TIME
4318 011732 105237 001120 INCB #GAP ;INCREMENT GAP #
4319 011736 122737 000020 001120 CMPB #16., #GAP ;BRANCH IF ALL GAPS NOT CHECKED
4320 011744 001367 BNE 6$
4321
4322 011746 012700 000020 MOV #16., R0 ;SETUP TO AVERAGE GAP SIZES
4323 011752 012701 001054 MOV #GAP TBL, R1 ;SET PTR TO TABLE
4324 011756 005002 CLR R2 ;CLEAR 'SUM' REGISTERS
4325 011760 005003 CLR R3
4326 011762 062102 7$: ADD (R1)+, R2 ;ADD ALL GAP SIZES TOGETHER
4327 011764 005503 ADC R3
4328 011766 005300 DEC R0
4329 011770 001374 BNE 7$
4330 011772 012700 000004 MOV #4., R0 ;NOW DIVIDE BY 16.
4331 011776 006203 8$: ASR R3 ;BY SHIFTING 4 PLACES RIGHT
4332 012000 006002 ROR R2
4333 012002 005300 DEC R0
4334 012004 001374 BNE 8$
4335 012006 010204 MOV R2, R4 ;MOVE AVERAGED TIMES TO R4
4336 012010 004737 004376 JSR PC, TIMOK ;CHECK AVERAGED TIMES
4337 012014 000401 BR 100$
4338
4339 012016 104400 99$: HLT
4340 012020 104000 100$: SCOPE
4341
4342
4343
4344 ;TEST 022-DATA TIME (800BPI)
4345 ;THIS TEST MEASURES THE TIME FROM FC REG >-6400 TO 'RDY' = 1.
4346 012022 112737 000022 001122 TST022: MOVB #022, #TSTNUM
4347 012030 012702 012110 MOV #3$, R2 ;SET RETURN PC FROM TIMER
4348 012034 004737 005262 JSR PC, .REWIND ;REWIND SLAVE
(1) 012040 102442 BVS 99$ ;BRANCH IF ERROR ON REWIND
4349 012042 052765 001700 000032 BIS #NORM11, TC(R5) ;SET 800 BPI
4350 012050 004337 005500 JSR R3, TMCMD ;WRITE 3200. WORD RECORD
4351 012054 016046 .WORD WTBUF
4352 012056 171600 .WORD -3200.
4353 012060 163400 .WORD -6400.
4354 012062 000060 .WORD WFW
4355 012064 005215 INC (R5) ;SET 'GO' BIT
4356
4357 012066 022710 163400 1$: CMP #-6400., (R0) ;WAIT FOR WRITING TO START
4358 012072 001J04 BNE 2$
4359 012074 032711 040000 BIT #ERR, (R1) ;MONITOR ERROR BIT
    
```

```

4360 012100 001022          BNE 99$
4361 012102 000771          BR 1$
4362
4363 012104          2$:
(1) 012104 004737 004250      JSR PC,TIMON          ;TURN TIMER ON
4364 012110 105711          3$: TSTB (R1)          ;BRANCH WHEN READY SETS
4365 012112 100402          BMI 4$
4366 012114 000163 004340      JMP TIMER(R3)        ;GO TO TIMER & RETURN VIA R2
4367
4368 012120 012700 000003      4$: MOV #3,R0          ;SET SHIFT COUNT
4369 012124 006204          5$: ASR R4
4370 012126 005300          DEC R0
4371 012130 001375          BNE 5$
4372 012132 004737 005156      JSR PC,WAITRDY
4373 012136 102403          BVS 99$
4374 012140 004737 004376      JSR PC,TIMOK        ;CHECK TIME
4375 012144 000401          BR 100$
4376
4377 012146 104400          99$: HLT
4378 012150 104000          100$: SCOPE
4379
4380          ;TEST 023-DATA TIME (1600BPI)
4381          ;THIS TEST MEASURES THE TIME FROM FC REG >-6400 TO 'RDY' = 1.
4382 012152 112737 000023 001122 TST023: MOVB #023,#TSTNUM
4383 012160 012702 012246          MOV #3$,R2          ;SET RETURN PC FROM TIMER
4384 012164 004737 005262          JSR PC,.REWIND      ;REWIND SLAVE
(1) 012170 102442          BVS 99$            ;BRANCH IF ERROR ON REWIND
4385 012172 042765 003700 000032      BIC #3700,TC(R5)   ;CLEAR CURRENT DENSITY
4386 012200 052765 002300 000032      BIS #PE1600,TC(R5) ;SET 1600 BPI
4387 012206 004337 005500          JSR R3,TMCMO        ;WRITE 3200. WORD RECORD
4388 012212 016046          .WORD WTBUF
4389 012214 171600          .WORD -3200.
4390 012216 163400          .WORD -6400.
4391 012220 000060          .WORD WFWO
4392 012222 005215          INC (R5)           ;SET 'GO' BIT
4393
4394 012224 022710 163400          1$: CMP #-6400.,(R0)  ;BRANCH WHEN WRITING STARTS
4395 012230 001004          BNE 2$
4396 012232 032711 040000          BIT #ERR,(R1)      ;MONITOR ERROR BIT
4397 012236 001017          BNE 99$
4398 012240 000771          BR 1$
4399
4400 012242          2$:
(1) 012242 004737 004250      JSR PC,TIMON          ;TURN TIMER ON
4401 012246 105711          3$: TSTB (R1)          ;BRANCH WHEN READY SETS
4402 012250 100402          BMI 4$
4403 012252 000163 004340      JMP TIMER(R3)        ;GO TO TIMER & RETURN VIA R2
4404
4405 012256 006204          4$: ASR R4          ;DIVIDE TIME BY 4
4406 012260 006204          ASR R4
4407 012262 004737 005156      JSR PC,WAITRDY
4408 012266 102403          BVS 99$
4409 012270 004737 004376      JSR PC,TIMOK        ;CHECK TIME
4410 012274 000401          BR 100$
4411
4412 012276 104400          99$: HLT
    
```

```

4413 012300 104000          100$: SCOPE
4414
4415
4416          ;TEST 024-ERASE
4417          ;THIS TEST MEASURES TIME FROM 'GO'=1 TO 'RDY'=1.
4418 012302 112737 000024 001122 TST024: MOVB #24,@TSTNUM
4419 012310 012702 012372          MOV #2$,R2          ;SET RETURN PC FROM TIMER
4419 012314 004737 005262          JSR PC,REWIND      ;REWIND SLAVE
(1) 012320 102436          BVS 99$           ;BRANCH IF ERROR ON REWIND
4420 012322 004737 005120          JSR PC,RHINIT     ;SET NRZ
4421 012326 004737 005344          JSR PC,WRITE      ;WRITE A RECORD
4422 012332 005215          INC (R5)         ;SET 'GO' BIT
4423 012334 004737 005156          JSR PC,WAITRDY
.24 012340 102426          BVS 99$
.425 012342 012737 012350 001002 MOV #1$,@NSCPADR
4426 012350 004337 005500          JSR R3,@TMCMD
4427 012354 000000          .WORD 0
4428 012356 000000          .WORD 0
4429 012360 000000          .WORD 0
4430 012362 000024          .WORD ERASE
4431 012364 004737 004250          JSR PC,TIMON     ;TURN TIMER ON
4432 012370 005215          INC (R5)         ;SET 'GO' BIT
4433
4434 012372 105711          2$: TSTB (R1)    ;BRANCH WHEN READY SETS
4435 012374 100402          BMI 3$
4436 012376 000163 004340          JMP TIMER(R3)   ;GO TO TIMER & RETURN VIA R2
4437
4438 012402 004737 005156          3$: JSR PC,WAITRDY
4439 012406 102403          BVS 99$
4440 012410 004737 004376          JSR PC,TIMOK
4441 012414 000401          BR 100$
4442
4443 012416 104400          99$: HLT
4444 012420 104000          100$: SCOPE
4445
4446          ;TEST 025 TAPE MARK
4447          ;THIS TEST MEASURES TIME FROM 'GO'=1 TO 'RDY'=1.
4448 012422 112737 000025 001122 TST025: MOVB #25,@TSTNUM
4449 012430 012702 012472          MOV #1$,R2          ;SET RETURN PC FROM TIMER
4450 012434 004737 005344          JSR PC,WRITE      ;WRITE A RECORD
4451 012440 005215          INC (R5)         ;SET 'GO' BIT
4452 012442 004737 005156          JSR PC,WAITRDY
4453 012446 102423          BVS 99$
4454 012450 004337 005500          JSR R3,@TMCMD
4455 012454 000000          .WORD 0
4456 012456 000000          .WORD 0
4457 012460 000000          .WORD 0
4458 012462 000026          .WORD WFMK
4459 012464 004737 004250          JSR PC,TIMON     ;TURN TIMER ON
4460 012470 005215          INC (R5)         ;SET 'GO' BIT
4461
4462 012472 105711          1$: TSTB (R1)    ;BRANCH WHEN READY SETS
4463 012474 100402          BMI 2$
4464 012476 000163 004340          JMP TIMER(R3)   ;GO TO TIMER & RETURN VIA R2
4465
4466 012502 004737 005156          2$: JSR PC,WAITRDY
4467 012506 102403          BVS 99$
    
```



```

4476 012530 032777 002000 166242 FINISH: BIT #SW10,@SWR ;DO NOT SPACE PAPER
4477 012536 001011 BNE 2$ ;IF USER SELECTED NO OUTPUT
4478 012540 005737 005746 TST CHNFLG ;OR IF IN CHAIN MODE
4479 012544 001006 BNE 2$
4480 012546 012700 000012 MOV #10.,RO ;SET LINE FEED COUNT
4481 012552 000004 001374 1$: TYPE,CRLF
4482 012556 005300 DEC RO
4483 012560 001374 BNE 1$
4484
4485
4486 012562 105237 001005 2$: INCB @#SLVNUM ;SET NEXT SLAVE #
4487 012566 005237 001006 INC @#SLVPTR ;AND ITS POINTER
4488 012572 122737 000010 001005 CMPB #8.,@#SLVNUM ;BRANCH IF LAST SLAVE (?)
4489 012600 001402 BEQ 3$
4490 012602 000137 007000 JMP @#BEGIN ;BEGIN TEST ON NEXT SLAVE
4491 012606 105037 001005 3$: CLRB @#SLVNUM ;SET SLAVE #0
4492 012612 105237 001004 INCB @#DRVNUM ;AND INCREMENT DRIVE #
4493 012616 122737 000010 001004 CMPB #8.,@#DRVNUM ;AND CHECK IF LAST DRIVE
4494 012624 001402 BEQ END
4495 012626 000137 007000 JMP @#BEGIN
4496
4497 012632 105737 001125 END: TSTB @#UNTFND ;BRANCH IF A UNIT WAS FOUND
4498 012636 001007 BNE 1$
4499 012640 000004 014265 TYPE,E.UNIT
4500 012644 005737 005746 TST CHNFLG ;CHAIN MODE ?
4501 012650 001002 BNE 1$ ;YES BRANCH
4502 012652 000137 005650 JMP @#INIT
4503 012656 105237 001127 1$: INCB @#PSCNT ;INCREMENT PASS COUNT
4504 012662 000004 013456 TYPE,M.EOP
4505 012666 113702 001127 MOVB @#PSCNT,R2 ;GET PASSCOUNT
4506 012672 004737 002426 JSR PC,TYPEOCT ;AND TYPE IT
4507 012676 000004 001374 TYPE,CRLF
4508 012702 013700 000042 MOV @#42,RO ;GET ACT11 RETURN ADDRESS
(1) 012706 001405 BEQ HERE ;BRANCH IF NOT ACT11
(1) 012710 000005 RESET
(1) 012712 004710 SENDAD: JSR PC,(RO)
(1) 012714 000240 NOP
(1) 012716 000240 NOP
(1) 012720 000240 NOP
(1) 012722 000240 HERE: NOP
4509 012724 005737 005746 TST CHNFLG ;BRANCH IF CHAIN MODE
4510 012730 001004 BNE 1$
4511 012732 032777 000100 166040 BIT #SW06,@SWR ;BRANCH IF NOT CONTINUOUS LOOP
4512 012740 001402 BEQ 2$
4513 012742 000137 006756 1$: JMP @#RSTRT ;RESTART
4514 012746 000000 2$: HALT
4515 012750 000005 RESET
4516 012752 000137 005650 JMP @#INIT ;RESTART

```

```

4518 ;SKEW TAPE TIMING TESTS
4519 ;THE FOLLOWING TESTS REQUIRE A SPECIALLY WRITTEN 800 BPI SKEW TAPE
4520 012756 012737 012764 001002 SKEWTST:MOV #TST026,@#SCPADR ;SET SCOPE POINTER
4521
4522 ;TEST 026- SKEW TAPE SPEED TEST-FORWARD
4523 ;THIS TEST READS 32" OF TAPE (26400.-800. = 25600. FRAMES), THEN
4524 ;DIVIDES TIME BY 32. TO GET TIME TO READ 1" (800. FRAMES) OF TAPE.
4525 012764 112737 000026 001122 TST026: MOV #26,@#TSTNUM
4526 012772 012702 013050 MOV #2$,R2 ;SET RETURN PC FROM TIMER
4527 012776 004737 005262 JSR PC,.REWIND ;REWIND SLAVE
(1) 013002 102441 BVS 99$ ;BRANCH IF ERROR ON REWIND
4528 013004 052765 001700 000032 BIS #NORM11,TC(R5) ;SET 800 BPI
4529 013012 052765 000010 000010 BIS #BA1,CS2(R5) ;INHIBIT BUS ADDRESS INCREMENT
4530 013020 004337 005500 JSR R3,@#TMCMD ;READ 32" OF TAPE-FORWARD
4531 013024 016046 .WORD RDBUF
4532 013026 177777 .WORD -1.
4533 013030 063440 10$: .WORD 26400. ;FRAME COUNT
4534 013032 000070 .WORD RDFWD
4535 013034 005215 INC (R5) ;SET 'GO' BIT
4536
4537 013036 022710 001440 1$: CMP #800.,(R0) ;WAIT FOR FIRST 800 FRAMES
4538 013042 101375 BHI 1$ ;TO BE READ
4539
4540 013044 004737 004250 JSR PC,TIMON ;TURN TIMER ON
4541 013050 023710 013030 2$: CMP @#10$, (R0) ;WAIT FOR READING TO FINISH
4542 013054 10340? BLO 3$
4543 013056 00016. 004340 JMP TIMER(R3) ;GO TO TIMER & RETURN VIA R2
4544
4545 013062 012700 000005 3$: MOV #5,R0 ;DIVIDE TIME BY 32.
4546 013066 006204 4$: ASR R4
4547 013070 005300 DEC R0
4548 013072 001375 BNE 4$
4549 013074 004737 005120 JSR PC,RH:INIT ;INIT DRIVE
4550 013100 004737 004376 JSR PC,TIMCK ;CHECK TIME
4551 013104 000401 BR 100$
4552
4553 013106 104400 99$: HLT
4554 013110 104000 100$: SCOPE
4555
4556 ;TEST 027-SKEW TAPE SPEED TEST-REVERSE
4557 ;THIS TEST READS FORWARD 40" (32000. FRAMES) OF TAPE, THEN READS REVERSE
4558 ;32" (26400.-800. = 25600. FRAMES) OF TAPE. THE TIME IS THEN DIVIDED BY
4559 ;32. TO GET TIME TO READ 1" (800. FRAMES) OF TAPE.
4560 013112 112737 000027 001122 TST027: MOV #27,@#TSTNUM
4561 013120 012702 013246 MOV #3$,R2 ;SET RETURN PC FROM TIMER
4562 013124 004737 005262 JSR PC,.REWIND ;REWIND SLAVE
(1) 013130 102465 BVS 99$ ;BRANCH IF ERROR ON REWIND
4563 013132 052765 001700 000032 BIS #NORM11,TC(R5)
4564 013140 052765 000010 000010 BIS #BA1,CS2(R5)
4565 013146 004337 005500 JSR R3,@#TMCMD ;READ FORWARD 32000. FRAMES
4566 013152 016046 .WORD RDBUF
4567 013154 177777 .WORD -1.
4568 013156 076400 10$. .WORD 32000. ;WORD COUNT
4569 013160 000070 .WORD RDFWD ;FRAME COUNT
4570 013162 005215 INC (R5) ;READ FORWARD
4571 ;SET 'GO' BIT

```

4572	013164	023710	013156	1\$:	CMP	@#10\$, (R0)	
4573	013170	101375			BHI	1\$	
4574							
4575	013172	004737	05120		JSR	PC, RHINIT	; INIT DRIVE
4576	013176	004737	004634		JSR	PC, DELAY	; WAIT FOR TAPE MOTION TO STOP
4577	013202	052765	001700	000032	BIS	#NORM11, TC(R5)	; SET 800 BPI
4578	013210	052765	000010	000010	BIS	#BA1, CS2(R5)	; INHIBIT BUS ADDRESS INCREMENT
4579	013216	004337	005500		JSR	R3, @#TMCMD	; READ REVERSE 32" OF TAPE
4580	013222	016046			.WORD	RDBUF	; READ BUFFER
4581	013224	177777			.WORD	-1.	; WORD COUNT
4582	013226	063440		11\$:	.WORD	26400.	; FRAME COUNT
4583	013230	000076			.WORD	RDREV	; READ REVERSE
4584	013232	005215			INC	(R5)	; SET 'GO' BIT
4585							
4586	013234	022710	001440	2\$:	CMP	#800., (R0)	; WAIT FOR FIRST 800 FRAMES
4587	013240	101375			BHI	2\$; TO BE READ
4588							
4589	013242	004737	004250		JSR	PC, TIMON	; TURN TIMER ON
4590	013246	023710	013226	3\$:	CMP	@#11\$, (R0)	; WAIT FOR ALL FRAMES TO BE READ
4591	013252	103402			BLO	4\$	
4592	013254	000163	004340		JMP	TIMER(R3)	; GO TO TIMER & RETURN VIA R2
4593							
4594	013260	012700	000005	4\$:	MOV	#5, R0	; DIVIDE TIME BY 32.
4595	013264	006204		5\$:	ASR	R4	
4596	013266	005300			DEC	R0	
4597	013270	001375			BNE	5\$	
4598	013272	004737	005120		JSR	PC, RHINIT	
4599	013276	004737	004376		JSR	PC, TIMOK	
4600	013302	000401			BR	100\$	
4601							
4602	013304	104400		99\$:	HLT		
4603	013306			100\$:			
(1)	013306	004737	005262		JSR	PC, .REWIND	; REWIND SLAVE
(1)	013312	102774			BVS	99\$; BRANCH IF ERROR ON REWIND
4604	013314	104000			SCOPE		
4605							
4606	013316	000137	012530		JMP	@#FINISH	
4607							
4608							
4609							

```
4611          .SBTTL      PROGRAM MESSAGES
4612          :OPERATOR INSTRUCTIONS
4613 013322 005015 046524 031460 M.NAM: .ASCII <CR><LF>'TM03/TU45 DRIVE FUNCTION TIMER (CZTUSBO)'  
013330 052057 032125 020065  
013336 051104 053111 020105  
013344 052506 041516 044524  
013352 047117 052040 046511  
013360 051105 024040 055103  
013366 052524 041123 024460  
4614 013374 005015 054524 042520 .ASCIIZ <CR><LF>'TYPE <CR> TO TERMINATE RESPONSE & ^C TO RESTART'  
013402 036040 051103 020076  
013410 047524 052040 051105  
013416 044515 040516 042524  
013424 051040 051505 047520  
013432 051516 020105 020046  
013440 041536 052040 020117  
013446 042522 052123 051101  
013454 000124  
4615 013456 005015 047105 020104 M.EOP: .ASCIIZ <CR><LF>'END OF PASS '  
013464 043117 050040 051501  
013472 020123 000  
4616 013475 015 044012 051101 M.HSWR: .ASCIIZ <CR><LF>'HARDWARE SWR IN USE'<CR><LF>  
013502 053504 051101 020105  
013510 053523 020122 047111  
013516 052440 042523 005015  
013524 000  
4617 013525 015 051012 046505 I.REM: .ASCIIZ <CR><LF>'REMOVE TMDP FROM TU45 TO BE TESTED'  
013532 053117 020105 046524  
013540 050104 043040 047522  
013546 020115 052524 032464  
013554 052040 020117 042502  
013562 052040 051505 042524  
013570 000104  
4618 013572 005015 054524 042520 I.REG: .ASCIIZ <CR><LF>'TYPE FIRST ADDRESS OF CONTROLLER '  
013600 043040 051111 052123  
013606 040440 042104 042522  
013614 051523 047440 020106  
013622 047503 052116 047522  
013630 046114 051105 020040  
013636 000  
4619 013637 124 050131 020105 I.DRVS: .ASCIIZ %TYPE TM03 DRIVE #'S TO BE TESTED: ALL %  
013644 046524 031460 042040  
013652 044522 042526 021440  
013660 051447 052040 020117  
013666 042502 052040 051505  
013674 042524 035104 020040  
013702 046101 020114 000  
4620 013707 106 051117 052040 I.SLVS: .ASCII 'FOR TM03 DRIVE '  
013714 030115 020063 051104  
013722 053111 020105  
4621 013726 026460 052040 050131 I.DRV: .ASCIIZ %0- TYPE SLAVE #'S TO BE TESTED: ALL %  
013734 020105 046123 053101  
013742 020105 023443 020123  
013750 047524 041040 020105  
013756 042524 052123 042105  
013764 020072 046101 020114
```

```

4622 013772 000
      013773 123 042520 042105 J.SPD: .ASCIZ 'SPEED TESTS? (YES=1/NO=<CR>): NO '
      014000 052040 051505 051524
      014006 020077 054450 051505
      014014 030475 047057 036517
      014022 041474 037122 035051
      014030 047040 020117 000
4623 014035 015 042412 042116 M.EOT: .ASCIZ <CR><LF>'END OF TAPE'<CR><LF>
      014042 047440 020106 040524
      014050 042520 005015 000

4624
4625 ;ERROR MESSAGES
4626 014055 015 052012 040522 E.TRP4: .ASCIZ <CR><LF>'TRAPPED TO 4'
      014062 050120 042105 052040
      014070 020117 000064
4627 014074 047516 041440 047117 E.NCON: .ASCIZ 'NO CONTROLLER AT ADDRESS SPECIFIED'<CR><LF>
      014102 051124 046117 042514
      014110 020122 052101 040440
      014116 042104 042522 051523
      014124 051440 042520 044503
      014132 044506 042105 005015
      014140 000
4628 014141 124 030115 020063 E.NDRV: .ASCIZ 'TMO3 DRIVE '
      014146 051104 053111 020105
      014154 000
4629 014155 104 044522 042526 E.NSLV: .ASCII 'DRIVE '
      014162 040
4630 014163 060 051440 040514 E.DRV: .ASCII '0 SLAVE '
      014170 042526 040
4631 014173 060 047040 052117 E.NAVA: .ASCIZ '0 NOT AVAILABLE FOR TEST'<CR><LF>
      014200 040440 040526 046111
      014206 041101 042514 043040
      014214 051117 052040 051505
      014222 006524 000012
4632 014226 051104 053111 020105 E.NDR1: .ASCII 'DRIVE '
4633 014234 026060 051440 040514 E.NSL1: .ASCII '0, SLAVE '
      014242 042526 040
4634 014245 060 047040 052117 E.MSG: .ASCIZ '0 NOT ON LINE'<CR><LF>
      014252 047440 020116 044514
      014260 042516 005015 000
4635 014265 116 020117 046524 E.UNIT: .ASCIZ 'NO TMO3/TU45 UNIT FOUND TO TEST'<CR><LF>
      014272 031460 052057 032125
      014300 020065 047125 052111
      014306 043040 052517 042116
      014314 052040 020117 042524
      014322 052123 005015 000
4636 014327 123 043117 020124 E.SFT: .ASCIZ 'SOFT ERROR (DATA)'<CR><LF>
      014334 051105 047522 020122
      014342 042050 052101 024501
      014350 005015 000
4637 014353 124 051505 020124 E.HDR: .ASCIZ 'TEST # '
      014360 020043 000
4638 014363 040 042504 044526 E.HDR1: .ASCII ' DEVICE ERROR'<CR><LF>
      014370 042503 042440 051122
      014376 051117 005015
4639 014402 051503 004461 041527 .ASCIZ 'CS1'<HT>'WC'<HT>'BA'<HT>'FC'<HT>'CS2'<HT>'DS'<HT>'ER'<HT>'TC'<CR><LF>
  
```

	014410	041011	004501	041506		
	014416	041411	031123	042011		
	014424	004523	051105	052011		
	014432	006503	000012			
4640	014436	047440	052125	047440	E.HDR2:	.ASCIZ ' OUT OF RANGE ERROR'<CR><LF>
	014444	020106	040522	043516		
	014452	020105	051105	047522		
	014460	006522	000012			
4641	014464	005015	044524	042515	E.TIMOV:	.ASCIZ <CR><LF>'TIMER OVERFLOWED'<CR><LF>
	014472	020122	053117	051105		
	014500	046106	053517	042105		
	014506	005015	000			
4642	014511	015	052012	046511	E.TIMEX:	.ASCIZ <CR><LF>'TIME EXPIRED WAITING FOR RDY'<CR><LF>
	014516	020105	054105	044520		
	014524	042522	020104	040527		
	014532	052111	047111	020107		
	014540	047506	020122	042122		
	014546	006531	000012			
4643	014552	043440	050101	021440	E.GAP:	.ASCIZ ' GAP # '
	014560	000040				
4644						
4645						
4646	014562	025052	025052	025052		
	014570	025052	025052	025052		
	014576	025052	025052	025052		
	014604	025052	025052	025052		
	014612	025052	025052	025052		
	014620	025052	025052	025052		
	014626	025052	025052	025052		
	014634	025052	025052	025052		
	014642	025052	025052	025052		
	014650	025052	025052	025052		
	014656	025052	025052	025052		
	014664	025052	025052	025052		
	014672	005015	000			
4647	014675	052	052040	030115	L.HDR2:	.ASCIZ '* TMO3 DRIVE FUNCTION TIMES- DRIVE # '
	014702	020063	051104	053111		
	014710	020105	052506	041516		
	014716	044524	047117	052040		
	014724	046511	051505	020055		
	014732	051104	053111	020105		
	014740	020043				
4648	014742	020060	046123	053101	L.DRV:	.ASCIZ '0 SLAVE # '
	014750	020105	020043			
4649	014754	020060	040		L.SLV:	.ASCIZ '0 '
4650	014757	071	041440	040510	L.CHAN:	.ASCIZ '9 CHAN. SER # '
	014764	027116	051440	051105		
	014772	021440	000040			
4651	014776	006440	025012	005015	L.HDR3:	.ASCIZ '<CR><LF>*'<CR><LF>
4652	015004	020052	052506	041516		.ASCIZ '* FUNCTION'<HT><HT>'TIME(SPECIFICATION)'<HT>'TIME(ACTUAL)'<CR><LF>
	015012	044524	047117	004411		
	015020	044524	042515	051450		
	015026	042520	044503	044506		
	015034	040503	044524	047117		
	015042	004451	044524	042515		
	015050	040450	052103	040525		

4653	015056	024514	005015	000	
4654	015063	122	047101	042507	L.RNG: .ASCIZ 'RANGE=<'
	015070	036075	000		
4655	015073	101	052103	040525	L.ACT: .ASCIZ 'ACTUAL='
	015100	036514	000		
4656					
4657					:TEST DESCRIPTOR HEADERS
4658	015103	052	053440	044522	A.T001: .ASCIZ '* WRITE FROM BOT'<HT>
	015110	042524	043040	047522	
	015116	020115	047502	004524	
	015124	000			
4659	015125	052	053440	044522	A.T002: .ASCIZ '* WRITE START'<HT><HT>
	015132	042524	051440	040524	
	015140	052122	004411	000	
4660	015145	052	053440	044522	A.T003: .ASCIZ '* WRITE SHUTDOWN'<HT>
	015152	042524	051440	052510	
	015160	042124	053517	004516	
	015166	000			
4661	015167	052	053440	044522	A.T004: .ASCIZ '* WRITE SETTLEDOWN'<HT>
	015174	042524	051440	052105	
	015202	046124	042105	053517	
	015210	004516	000		
4662	015213	052	051040	040505	A.T005: .ASCIZ '* READ FROM BOT'<HT><HT>
	015220	020104	051106	046517	
	015226	041040	052117	004411	
	015234	000			
4663	015235	052	051040	040505	A.T006: .ASCIZ '* READ START'<HT><HT>
	015242	020104	052123	051101	
	015250	004524	000011		
4664	015254	020052	042522	042101	A.T007: .ASCIZ '* READ SHUTDOWN'<HT><HT>
	015262	051440	052510	042124	
	015270	053517	004516	000011	
4665	015276	020052	042522	042101	A.T010: .ASCIZ '* READ SETTLEDOWN'<HT>
	015304	051440	052105	046124	
	015312	042105	053517	004516	
	015320	000			
4666	015321	052	051040	040505	A.T011: .ASCIZ '* READ REV START'<HT>
	015326	020104	042522	020126	
	015334	052123	051101	004524	
	015342	000			
4667	015343	052	051040	040505	A.T012: .ASCIZ '* READ REV SHUTDOWN'<HT>
	015350	020104	042522	020126	
	015356	044123	052125	047504	
	015364	047127	000011		
4668	015370	020052	042522	042101	A.T013: .ASCIZ '* READ REV SETTLEDOWN'<HT>
	015376	051040	053105	051440	
	015404	052105	046124	042105	
	015412	053517	004516	000	
4669	015417	052	052040	051125	A.T014: .ASCIZ '* TURN AROUND DELAY F-R'<HT>
	015424	020116	051101	052517	
	015432	042116	042040	046105	
	015440	054501	043040	051055	
	015446	000011			
4670	015450	020052	052524	047122	A.T015: .ASCIZ '* TURN AROUND DELAY R-F'<HT>
	015456	040440	047522	047125	

	015464	020104	042504	040514	
	015472	020131	026522	004506	
4671	015500	000			
	015501	052	043440	050101	A.T016: .ASCIZ '* GAP SIZE-STOP HALF'<HT>
	015506	051440	055111	026505	
	015514	052123	050117	044040	
4672	015522	046101	004506	000	
	015527	052	043440	050101	A.T017: .ASCIZ '* GAP SIZE-START HALF'<HT>
	015534	051440	055111	026505	
	015542	052123	051101	020124	
4673	015550	040510	043114	000011	
	015556	020052	040507	020120	A.T020: .ASCIZ '* GAP SIZE-INTERRECORD'<HT>
	015564	044523	042532	044455	
	015572	052116	051105	042522	
4674	015600	047503	042122	000011	
	015606	020052	040507	020120	A.T021: .ASCIZ '* GAP CONSISTANCY'<HT>
	015614	047503	051516	051511	
	015622	040524	041516	004531	
	015630	000			
4675	015631	052	042040	052101	A.T022: .ASCIZ '* DATA TIME-800BPI'<HT>
	015636	020101	044524	042515	
	015644	034055	030060	050102	
	015652	004511	000		
4676	015655	052	042040	052101	A.T023: .ASCIZ '* DATA TIME-1600BPI'<HT>
	015662	020101	044524	042515	
	015670	030455	030066	041060	
	015676	044520	000011		
4677	015702	020052	051105	051501	A.T024: .ASCIZ '* ERASE GAP TIME'<HT>
	015710	020105	040507	020120	
	015716	044524	042515	000011	
4678	015724	020052	051127	052111	A.T025: .ASCIZ '* WRITE FILE MARK'<HT>
	015732	020105	044506	042514	
	015740	046440	051101	004513	
	015746	000			
4679	015747	052	052040	050101	A.T026: .ASCIZ '* TAPE SPEED-FWD'<HT>
	015754	020105	050123	042505	
	015762	026504	053506	004504	
	015770	000			
4680	015771	052	052040	050101	A.T027: .ASCIZ '* TAPE SPEED-REV'<HT>
	015776	020105	050123	042505	
	016004	026504	042522	004526	
	016012	000			
4681					
4682	016013	015	057012	000107	L.CNTG: .ASCIZ <CR><LF>'*G'
4683	016020	005015	053523	036522	L.SWR: .ASCIZ <CR><LF>'SWR='
	016026	000			
4684	016037	040	047040	053505	L.NEW: .ASCIZ ' NEW= '
	016034	020075	000		
4685	016037	015	037412	005015	L.QUEST: .ASCIZ <CR><LF>'?'<CR><LF>
	016044	000			
4686		016046			.EVEN
4687		016046			RDBUF=.
4688		016046			WTBUF=.
4689	016046	000200			.BLKW 128.
4690		000001			.END

READ	005362	3426#	3918	3940	3962	3991	4157	4209	4293	4298					
RESVEC=	000010	2371#													
REVRD	005400	3436#	4029	4053	4083	4127	4151	4181	4204	4237	4241	4284			
RHINIT	005120	3104	3333	3357#	3394	4420	4549	4575	4598						
RMR =	000004	2464#													
RSTRT	006756	2540	3698#	4513											
RWD =	000006	2403#	3399												
RWDOFF=	000002	2402#													
SC =	100000	2422#													
SCOPE =	104000	2498#	3835	3855	3880	3912	3933	3955	3983	4017	4043	4073	4109	4141	
		4171	4195	4223	4255	4340	4378	4413	4444	4473	4554	4604			
SCPADR	001002	2548#	3102*	3106	3127*	3180	3794*	3809*	4425*	4520*					
SDWN =	000020	2450#	3871	3894	3902	3973	4000	4007	4063	4092	4099				
SKEWTS	012756	3807	4520#												
SLA =	000001	2446#													
SLAVES	006400	3610#	3692												
SLR =	177774	2370#													
SLVAVA	005040	3341#	3680												
SLVNUM	001005	2550#	3342	3360	3679*	3699*	3705	3737*	3798	4486*	4488	4491*			
SLVPTR	001006	2551#	3700*	3706	3738*	4487*									
SLVTBL	001164	2578#	3611	3616	3637	3659	3700								
SN =	000030	2395#	3477	3487	3492	3500									
SNPT	005520	3477#	3803												
SPACE	001410	2586#	3535												
SPACE2	001407	2585#	3056												
SPCFWD=	000030	2407#	3445												
SPCREV=	000032	2408#	3455												
SPR =	002000	2481#	3343												
SSC =	000100	2452#													
STIMTB	001416	2597#	2840	2843	3215	3217									
TKPTR=	000600	2543#	3510												
SWR	001000	2547#	2704	2708	2715*	3000	3002*	3006*	3022	3063	3066	3091	3095	3097	
		3121	3125	3128	3257	3516	3520*	3526*	3754	3784	4476	4511			
SWREG	000176	2535#	2704	3000	3006	3520	3526	3754							
SW06 =	000100	2326#	2535	4511											
SW07 =	000200	2325#													
SW08 =	000400	2324#	3091	3257											
SW09 =	001000	2323#	3063												
SW10 =	002000	2322#	3128	4476											
SW11 =	004000	2321#	3121												
SW13 =	020000	2320#	3022												
SW14 =	040000	2319#	3095												
SW15 =	100000	2318#													
TAP =	040000	2483#	3331												
TBITVE=	000014	2371#	2517												
TC =	000032	2396#	3041	3059	3342*	3361*	3362*	3826	3845	3923	3945	4033	4131	4161	
		4349*	4385*	4386*	4528*	4563*	4577*								
TCRLF	002156	2722#													
TIB	002016	2701#													
TIMER	004340	3170	3174#	3182	3185	3269	3283	3767	3828	3847	3873	3904	3925	3947	
		3975	4009	4035	4065	4101	4133	4163	4187	4215	4247	4304	4366	4403	
		4436	4464	4543	4592										
TIMERR	004350	3176	3178#												
TIMERO	004364	3184#													
TIMER1	004314	3169#	3173												
TIMOK	004376	3196#	3832	3851	3877	3908	3929	3951	3979	4013	4039	4069	4105	4137	

TIMON	004250	4167	4191	4219	4251	4336	4374	4409	4440	4468	4550	4599	4030	4062
		3146#	3266	3280	3823	3842	3869	3900	3920	3942	3971	4006	4540	4589
		4098	4128	4158	4182	4210	4242	4299	4363	4400	4431	4459		
TKB	= 177562	2370#	2958	2985										
TKISR	003420	2530	2985#											
TKS	= 177560	2370#	2955	3769*										
TKVEC	= 000060	2371#	2529											
TMBASE	001010	2552#	3090	3533	3540*	3541	3762							
TMCMD	005500	3395	3416	3426	3436	3468#	4350	4387	4426	4454	4530	4565	4579	
TMCS1	= 172440	2381#	2552											
TMK	= 000004	2448#												
TPB	= 177566	2370#												
TPS	= 177564	2370#												
TPVEC	= 000064	2371#												
TRAPVE	= 000034	2371#												
TRE	= 040000	2421#												
TRTVEC	= 000014	2371#												
TSTNUM	001122	2561#	2938	2943	3025	3093	3100	3212	3761*	3819*	3839*	3859*	3884*	3916*
		3937*	3959*	3987*	4022*	4047*	4077*	4120*	4145*	4174*	4198*	4227*	4269*	4346*
		4382*	4417*	4448*	4525*	4560*								
TSTTBL	001736	2676#	3794	3795										
TST000	007224	2676	3102	3761#										
TST001	007474	2677	3809	3819#										
TST002	007560	2678	3839#											
TST003	007636	2679	3859#											
TST004	007726	2680	3884#											
TST005	010034	2681	3916#											
TST006	010120	2682	3937#											
TST007	010204	2683	3959#											
TST010	010304	2684	3987#											
TST011	010424	2685	4022#											
TST012	010522	2686	4047#											
TST013	010632	2687	4077#											
TST014	010772	2688	4120#											
TST015	011064	2689	4145#											
TST016	011172	2690	4174#											
TST017	011266	2691	4198#											
TST020	011376	2692	4227#											
TST021	011516	2693	4269#											
TST022	012022	2694	4346#											
TST023	012152	2695	4382#											
TST024	012302	2696	4417#											
TST025	012422	2697	4448#											
TST026	012764	2698	4520	4525#										
TST027	013112	2699	4560#											
TYPE	= 000004	2795#	2841	2844	2848	2869	2872	2876						
		2499#	2707	2710	2722	2779	2812	2839	2842	2845	2846	2849	2867	2870
		2873	2874	2877	2880	2941	2963	2968	2978	2980	3003	3024	3031	3035
		3038	3048	3051	3056	3061	3065	3178	3349	3372	3376	3377	3505	3529
		3530	3532	3535	3547	3560	3600	3602	3629	3686	3746	3787	3791	3793
		3796	3802	3804	4481	4499	4504	4507						
TYPE1	002150	2722#												
TYPE2	002176	2722#												
TYPE3	002204	2722#												
TYPE4	002210	2722#												
TYPEFLG	001126	2565#	2750*	2758*	2777	2788*	2795*	2810						

STCREG	192#		
STRAPS	402#		
STYPE	518#	2303#	2722
STYPER	592#		
SUMMRE	272#		
SVECTA	1163#		
.SACT1	67#	2303#	2528
.SEOP	78#	2303#	4508

. ABS. 016446 000

ERRORS DETECTED: 0

CZTUSB,CZTUSB/CRF=CZTUSB.P11
RUN-TIME: 16 26 2 SECONDS
RUN-TIME RATIO: 100/45=2.2
CORE USED: 15K (29 PAGES)