

**DOMAIN Graphics Primitive Resource  
Call Reference**

**Order No. 007194  
Revision 01**

Apollo Computer Inc.  
330 Billerica Road  
Chelmsford, MA 01824

Copyright © 1986 Apollo Computer Inc.

All rights reserved.

Printed in U.S.A.

First Printing: January, 1987

This document was produced using the SCRIBE<sup>®</sup> document preparation system. (SCRIBE is a registered trademark of Unilogic, Ltd.)

APOLLO and DOMAIN are registered trademarks of Apollo Computer Inc.

AEGIS, DGR, DOMAIN/BRIDGE, DOMAIN/DFL-100, DOMAIN/DQC-100, DOMAIN/Dialogue, DOMAIN/IX, DOMAIN/Laser-26, DOMAIN/PCI, DOMAIN/SNA, D3M, DPSS, DSEE, GMR, and GPR are trademarks of Apollo Computer Inc.

Apollo Computer Inc. reserves the right to make changes in specifications and other information contained in this publication without prior notice, and the reader should in all cases consult Apollo Computer Inc. to determine whether any such changes have been made.

THE TERMS AND CONDITIONS GOVERNING THE SALE OF APOLLO COMPUTER INC. HARDWARE PRODUCTS AND THE LICENSING OF APOLLO COMPUTER INC. SOFTWARE CONSIST SOLELY OF THOSE SET FORTH IN THE WRITTEN CONTRACTS BETWEEN APOLLO COMPUTER INC. AND ITS CUSTOMERS. NO REPRESENTATION OR OTHER AFFIRMATION OF FACT CONTAINED IN THIS PUBLICATION, INCLUDING BUT NOT LIMITED TO STATEMENTS REGARDING CAPACITY, RESPONSE-TIME PERFORMANCE, SUITABILITY FOR USE OR PERFORMANCE OF PRODUCTS DESCRIBED HEREIN SHALL BE DEEMED TO BE A WARRANTY BY APOLLO COMPUTER INC. FOR ANY PURPOSE, OR GIVE RISE TO ANY LIABILITY BY APOLLO COMPUTER INC. WHATSOEVER.

IN NO EVENT SHALL APOLLO COMPUTER INC. BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING BUT NOT LIMITED TO LOST PROFITS) ARISING OUT OF OR RELATING TO THIS PUBLICATION OR THE INFORMATION CONTAINED IN IT, EVEN IF APOLLO COMPUTER INC. HAS BEEN ADVISED, KNEW OR SHOULD HAVE KNOWN OF THE POSSIBILITY OF SUCH DAMAGES.

THE SOFTWARE PROGRAMS DESCRIBED IN THIS DOCUMENT ARE CONFIDENTIAL INFORMATION AND PROPRIETARY PRODUCTS OF APOLLO COMPUTER INC. OR ITS LICENSORS.

## Preface

The *DOMAIN Graphics Primitive Resource Call Reference* describes the constants, data types, and user-callable routines used by the DOMAIN<sup>®</sup>Graphics Primitive Resource (GPR) system for developing two-dimensional graphics applications.

### Audience

This manual is for programmers who use the GPR to develop application programs. Users of this manual should have some knowledge of computer graphics and have experience in using the DOMAIN system.

We suggest that you read the task-oriented handbook *Programming with DOMAIN Graphics Primitives* before using this reference manual.

### Organization of this Manual

This manual contains three chapters:

- Chapter 1       Presents the constants and data types used by GPR.
- Chapter 2       Presents a description of each routine including format and parameters. The organization of routines is alphabetical.
- Chapter 3       Presents a GPR error listing.

### Additional Reading

Use this reference as a companion to the *Programming With DOMAIN Graphics Primitives* manual (005808).

The *DOMAIN 3D Graphics Metafile Resource Call Reference* manual (005812 01) describes the constants, data types, and user-callable routines used by the DOMAIN 3D Graphics Metafile Resource (3D GMR) system for developing three-dimensional graphics applications.

The *Programming With DOMAIN 3D Graphics Metafile Resource* manual (005807) describes how to write programs that use the DOMAIN 3D Graphics Metafile Resource.

The *DOMAIN 2D Graphics Metafile Resource Call Reference* manual (009793) describes the constants, data types, and user-callable routines used by the DOMAIN 2D Graphics Metafile Resource (GMR) system for developing two-dimensional graphics applications.

The *Programming With DOMAIN 2D Graphics Metafile Resource* manual (005097) describes how to write graphics programs using DOMAIN Graphics Primitives.

The *Programming With General System Calls* manual (005506) describes how to write programs that use standard DOMAIN systems calls.

The *DOMAIN Language Level Debugger Reference* (001525) describes the high-level language debugger.

The *Programming With Graphics Service Routines* (009797) manual describes how to write programs that use Graphics Service Routines.

The *DOMAIN Graphics Instruction Set* (009791) manual describes the instruction set used by the Graphics Service Routines.

For language-specific information, see the *DOMAIN FORTRAN Language Reference* (000530), the *DOMAIN Pascal User's Guide* (000792), and the *DOMAIN C Language Reference* (002093).

### Documentation Conventions

Unless otherwise noted in the text, this manual uses the following symbolic conventions.

**UPPERCASE** Uppercase words or characters in formats and command descriptions represent commands or keywords that you must use literally.

**lowercase** Lowercase words or characters in formats and command descriptions represent values that you must supply.

**[ ]** Square brackets enclose optional items in formats and command descriptions. In sample Pascal statements, square brackets assume their Pascal meanings.

**{ }** Braces enclose a list from which you must choose an item in formats and command descriptions. In sample Pascal statements, braces assume their Pascal meanings.

**CTRL/Z** The notation CTRL/ followed by the name of a key indicates a control character sequence. You should hold down the <CTRL> key while typing the character.

Vertical ellipses represent additional information in a program fragment that is either too lengthy to include or not relevant to the example.

### Problems, Questions, and Suggestions

We appreciate comments from the people who use our system. In order to make it easy for you to communicate with us, we provide the User Change Request (UCR) system for software-related comments, and the Reader's Response form for documentation comments. By using these formal channels, you make it easy for us to respond to your comments.

You can get more information about how to submit a UCR by consulting the *DOMAIN System Command Reference* manual. Refer to the CRUCR (Create User Change Request) Shell command. You can also view the same description on-line by typing:

```
$ HELP CRUCR <RETURN>
```

For your comments on documentation, a Reader's Response form is located at the back of this manual.

# Chapter 1

## Constants and Data Types

This chapter describes the constants and data types used by the Graphics Primitive Resource package (hereafter referred to as GPR). Each data type description includes an atomic data type translation (i.e., `GPR_$LINESYLE_T = 2-byte integer`) as well as a brief description of the type's purpose. The description includes any predefined values associated with the type. The following is an example of a data type description for the `GPR_$LINESYLE_T` type:

`GPR_$LINESYLE_T`

A 2-byte integer. Specifies the linestyle for line-drawing operations. One of the following predefined values:

`GPR_$SOLID`

Draw solid lines.

`GPR_$DOTTED`

Draw dotted lines.

This chapter also illustrates the record data types in detail. These illustrations will help FORTRAN programmers construct record-like structures, as well as provide useful information for all programmers. Each record type illustration:

- Shows FORTRAN programmers the structure of the record that they must construct using standard FORTRAN data-type statements. The illustrations show the size and type of each field.
- Describes the fields that make up the record.
- Lists the byte offsets for each field. Use these offsets to access individual fields. Bytes are numbered from left to right and bits are numbered from right to left.
- Indicates whether any fields of the record are, in turn, predefined records.

## GPR DATA TYPES

### CONSTANTS

MNEMONIC	Value	Explanation
GPR_\$BACKGROUND	-2	pixel value for window background
GPR_\$BLACK	0	color value for black
GPR_\$BLUE	16#0000FF	color value for blue
GPR_\$BMF_MAJOR_VERSION	1	major identifier for a bitmap file
GPR_\$BMF_MINOR_VERSION	1	minor identifier for a bitmap file
GPR_\$CYAN	16#00FFFF	color value for cyan (blue + green)
GPR_\$DEFAULT_LIST_SIZE	10	
GPR_\$GREEN	16#00FF00	color value for green
GPR_\$HIGHEST_PLANE	7	max plane number in a bitmap
GPR_\$MAGENTA	16#FF00FF	color value for magenta (red + blue)
GPR_\$MAX_BMF_GROUP	0	max group in external bitmaps
GPR_\$MAX_X_SIZE	8192	max bits in bitmap x dimension
GPR_\$MAX_Y_SIZE	8192	max bits in bitmap y dimension
GPR_\$NIL_ATTRIBUTE_DESC	0	descriptor of nonexistent attributes
GPR_\$NIL_BITMAP_DESC	0	descriptor of a nonexistent bitmap
GPR_\$RED	16#FF0000	color value for red
GPR_\$STRING_SIZE	256	number of chars in a gpr string
GPR_\$TRANSPARENT	-1	pixel value for transparent (no change)
GPR_\$WHITE	16#FFFFFF	color value for white
GPR_\$YELLOW	16#FFFF00	color value for yellow (red + green)
GPR_\$ROP_ZEROS	0	
GPR_\$ROP_SRC_AND_DST	1	

GPR_\$ROP_SRC_AND_NOT_DST	2
GPR_\$ROP_SRC	3
GPR_\$ROP_NOT_SRC_AND_DST	4
GPR_\$ROP_DST	5
GPR_\$ROP_SRC_XOR_DST	6
GPR_\$ROP_SRC_OR_DST	7
GPR_\$ROP_NOT_SRC_AND_NOT_DST	8
GPR_\$ROP_SRC_EQUIV_DS	9
GPR_\$ROP_NOT_DST	10
GPR_\$ROP_SRC_OR_NOT_DST	11
GPR_\$ROP_NOT_SRC	12
GPR_\$ROP_NOT_SRC_OR_DST	13
GPR_\$ROP_NOT_SRC_OR_NOT_DS	14
GPR_\$ROP_ONES	15

**DATA TYPES**

GPR\_\$ACCELERATOR\_TYPE\_T

A 2-byte integer. Unique number corresponding to the graphics accelerator processor type One of the following predefined values:

GPR\_\$ACCEL\_NONE  
None or not applicable.

GPR\_\$ACCEL\_1  
3DGA.

GPR\_\$ACCESS\_ALLOCATION\_T

A 2-byte integer. The legal allocated sizes of pixel cells in bitmap sections for direct access. One of the following predefined values:

GPR\_\$ALLOC\_1  
One bit per pixel cell.

GPR\_\$ALLOC\_2  
Two bits per pixel cell.

GPR\_\$ALLOC\_4  
Four bits per pixel cell.

## GPR DATA TYPES

GPR\_\$ALLOC\_8  
One byte per pixel cell.

GPR\_\$ALLOC\_16  
Two bytes per pixel cell.

GPR\_\$ALLOC\_32  
Four bytes per pixel cell.

GPR\_\$ACCESS\_MODE\_T

A 2-byte integer. The ways to access an external bitmap. One of the following predefined values:

GPR\_\$CREATE  
Create a file on disk.

GPR\_\$UPDATE  
Update a file on disk.

GPR\_\$WRITE  
Write to a file on disk.

GPR\_\$READONLY  
Read a file on disk.

GPR\_\$ACCESS\_SET\_T

A 2-byte integer. The set of legal allocated sizes of pixel cells in bitmap sections for direct access.

GPR\_\$ATTRIBUTE\_DESC\_T

A 4-byte integer. Identifies an attribute block.

GPR\_\$BITMAP\_DESC\_T

A 4-byte integer. Identifies a bitmap.

GPR\_\$BMF\_GROUP\_HEADER\_T

The group header description for an external bitmap. The diagram below illustrates the GPR\_\$BMF\_GROUP\_HEADER\_T data type:

predefined type	byte: offset	field name
	15	0
	0:	integer n_sects
	2:	integer pixel_size
	4:	integer allocated_size
	6:	integer bytes_per_line
	8:	integer bytes_per_sect
	10:	integer
	12:	integer storage_offset
	14:	integer

## Field Description:

n\_sects

The number of sections in a group.

pixel\_size

The number of bits per pixel in each section of a group.

allocated\_size

bytes\_per\_line

The number of bytes in one row of a bitmap.

bytes\_per\_sect

The number of bytes\_per\_line multiplied by the height of the bitmap. This value must be rounded up to a page boundary, or for small bitmaps rounded up to the next largest binary submultiple of a page.


storage\_offset

A pointer to the group storage area.

GPR DATA TYPES

GPR\_\$BMF\_GROUP\_HEADER\_ARRAY\_T

A gpr\_\$max\_bmf\_group-element array of gpr\_bmf\_group\_header\_t record structures. The diagram below illustrates a single element:



Field Description:

n\_sects

The number of sections in a group.

pixel\_size

The number of bits per pixel in each section of a group.

allocated\_size

bytes\_per\_line

The number of bytes in one row of a bitmap.

bytes\_per\_sect

The number of bytes\_per\_line multiplied by the height of the bitmap. This value must be rounded up to a page boundary, or for small bitmaps rounded up to the next largest binary submultiple of a page.

storage\_offset

A pointer to the group storage area.

GPR\_\$COLOR\_T

A 4-byte integer. Defines a color.

GPR\_\$COLOR\_VECTOR\_T

A 256-element array of 4-byte integers. Stores multiple color values. Arrays of this type are used as input parameters of color values to be inserted into consecutive slots of a color map. They are also used as output parameters to store color values when inquiries are performed on color maps.

GPR\_\$CONTROLLER\_TYPE\_T

A 2-byte integer. Unique number corresponding to the display controller type. One of the following predefined values:

GPR\_\$CTL\_NONE  
None or not applicable

GPR\_\$CTL\_MONO\_1  
DN100/400/420/460

GPR\_\$CTL\_MONO\_2  
DN300/320/330

GPR\_\$CTL\_COLOR\_1  
DN600/660/550/560

GPR\_\$CTL\_COLOR\_2  
DN580

GPR\_\$CTL\_COLOR\_3  
DN570/570A

GPR\_\$CTL\_COLOR\_4  
DN3000

GPR\_\$CTL\_MONO\_4  
DN3000

GPR\_\$COORDINATE\_ARRAY\_T

A 10-element array of 2-byte integers. Specifies several coordinates in a bitmap. Generally, x coordinates are passed in one array and y coordinates are passed in another array.

GPR\_\$COORDINATE\_T

A 2-byte integer. Specifies one coordinate in a bitmap.

GPR\_\$DECOMP\_TECHNIQUE\_T

A 2-byte integer. Specifies a decomposition technique. One of the following predefined values:

GPR\_\$FAST\_TRAPS  
Decomposes polygons into trapezoids using integer arithmetic.

GPR\_\$PRECISE\_TRAPS  
Decomposes polygons into trapezoids using double integer arithmetic.

## GPR DATA TYPES

GPR\_\$NON\_OVERLAPPING\_TRIS

Decomposes polygons into nonoverlapping triangles.

GPR\_\$RENDER\_EXACT

Renders polygons directly without decomposing them into simpler polygons.

GPR\_\$DIRECTION\_T

A 2-byte integer. Specifies the direction of movement from one text character position to another in a bitmap. One of the following predefined values:

GPR\_\$UP

GPR\_\$DOWN

GPR\_\$LEFT

GPR\_\$RIGHT

GPR\_\$DISP\_CHAR\_T

Stores display characteristics. The diagram below illustrates the-gpr\_\$disp\_char\_t data type:

predefined type	byte: offset	15	0	field name
gpr_\$controller_type_t	0:	integer		controller_type
gpr_\$accelerator_type_t	2:	integer		accelerator_type
	4:	integer		x_window_origin
	6:	integer		y_window_origin
	8:	integer		x_window_size
	10:	integer		y_window_size
	12:	integer		x_visible_size
	14:	integer		y_visible_size
	16:	integer		x_extension_size
	18:	integer		y_extension_size
	20:	integer		x_total_size
	22:	integer		y_total_size
	24:	integer		x_pixels_per_cm
	26:	integer		y_pixels_per_cm

GPR DATA TYPES

predefined type	byte: offset	field name
gpr_\$overlap_set_t	28:	integer n_planes
	30:	integer n_buffers
	32:	integer delta_x_per_buffer
	34:	integer delta_y_per_buffer
	36:	integer delta_planes_per_buffer
	38:	integer mem_overlaps
	40:	integer x_zoom_max
	42:	integer y_zoom_min
	44:	integer video_refresh_rate
	46:	integer n primaries
gpr_\$format_set_t	48:	integer lut_width_per_primary
	50:	integer avail_formats
gpr_\$access_set_t	52:	integer avail_access
	54:	integer access_address_space
gpr_disp_invert_t	56:	integer invert

Field Description:

CONTROLLER\_TYPE

A 2-byte integer. The type of graphics hardware controller. One of the following predefined values:

GPR\_\$CTL\_NONE  
none or not applicable.

GPR\_\$CTL\_MONO\_1  
DN100/400/420/460

GPR\_\$CTL\_MONO\_2  
DN300/320/330

GPR\_\$CTL\_COLOR\_1  
DN600/550/560

GPR\_\$CTL\_COLOR\_2  
580

GPR\_\$CTL\_COLOR\_3  
DN570

GPR\_\$CTL\_COLOR\_4  
DN3000 color.

For gpr\_\$no\_display mode, gpr\_\$ctl\_none is returned.  
Note that code which makes use of these values may not automatically extend to new node types, since as new controllers are released, they will be given new values, and this list will be extended.

ACCELERATOR\_TYPE

A 2-byte integer. The type of graphics hardware processing accelerator for the node. Only one of the following values is returned. One of the following predefined values:

GPR\_\$ACCEL\_NONE  
none or not applicable.

**NOTE:**

Code which makes use of these values may not automatically extend to new node types, since as new controllers are released, they will be given new values, and this list will be extended.

For gpr\_\$no\_display mode, gpr\_\$accel\_none is returned.

X\_WINDOW\_ORIGIN

X origin of the frame or window in frame and direct mode respectively. For borrow mode and no-display mode the origin is (0,0).

Y\_WINDOW\_ORIGIN

Y origin of the frame or window in frame and direct mode respectively. For borrow mode and no-display mode the origin is (0,0).

X\_WINDOW\_SIZE

X dimension of the frame or window in frame and direct mode respectively. For borrow mode this is the x dimension of the screen. For no-display mode this is the x dimension of the maximum legal bitmap.

**Y\_WINDOW\_SIZE**

Y dimension of the frame or window in frame and direct mode respectively. For borrow mode this is the x dimension of the screen. For no-display mode this is the y dimension of the maximum legal bitmap.

**X\_VISIBLE\_SIZE**

X dimension of the visible area of the screen for frame, direct, and borrow modes. For no-display mode this is the x dimension of the maximum legal bitmap size.

**Y\_VISIBLE\_SIZE**

X dimension of the visible area of the screen for frame, direct, and borrow modes. For no-display mode this is the x dimension of the maximum legal bitmap size.

**X\_EXTENSION\_SIZE**

The maximum x dimension of the bitmap after having been extended by GPR\_\$SET\_BITMAP\_DIMENSIONS. For frame, direct and no-display modes, this size is the same as X\_VISIBLE\_SIZE. For borrow-mode, this size may be bigger if the device has more display memory past the edges of the visible area.

**Y\_EXTENSION\_SIZE**

The maximum y dimension of the bitmap after having been extended by GPR\_\$SET\_BITMAP\_DIMENSIONS. For frame, direct and no-display modes, this size is the same as Y\_VISIBLE\_SIZE. For borrow-mode, this size may be bigger if the device has more display memory past the edges of the visible area.

**X\_TOTAL\_SIZE**

X dimension of total bitmap memory. In particular, this is the number of addressable pixel positions, in a linear pixel addressing space, between the first pixel of a scan line and the first pixel of the next scan line. This value may be larger than x\_extension\_size. For no-display mode this value is the x dimension of the maximum legal bitmap.

**Y\_TOTAL\_SIZE**

Y dimension of total bitmap memory. This value may be larger than y\_extension\_size. For no-display mode this value is the y dimension of the maximum legal bitmap.

**X\_PIXELS\_PER\_CM**

The number of physical pixels per centimeter on the screen in the x dimension. For no-display mode, this value is set to zero.

**Y\_PIXELS\_PER\_CM**

The number of physical pixels per centimeter on the screen in the y dimension. For no-display mode, this value is set to zero.

**N\_PLANES**

The maximum number of planes of bitmap memory available on the device. For no-display mode, this parameter is the maximum legal bitmap depth.

**N\_BUFFERS**

The number of displayable refresh buffers available on the device, in borrow mode. In frame, direct, and no-display modes, this parameter is set to one.

**DELTA\_X\_PER\_BUFFER**

The "distance" in x, in pixel addresses between refresh buffers on a device with more than one buffer, in borrow mode. For frame, direct and no-display modes, and for devices with only one buffer, this parameter is set to zero.

**DELTA\_Y\_PER\_BUFFER**

The "distance" in y, in pixel addresses between refresh buffers on a device with more than one buffer, in borrow mode. For frame, direct and no-display modes, and for devices with only one buffer, this parameter is set to zero.

**DELTA\_PLANES\_PER\_BUFFER**

This parameter gives the "distance" in pixel depth between refresh buffers on a device with more than one buffer, in borrow mode. Currently no such device capability is supported, but it may be in the future. For frame, direct and no-display modes, and for devices with only one buffer, this parameter is set to zero.

**MEM\_OVERLAPS**

A 2-byte integer. This parameter gives the kinds of overlap situations that can exist between refresh buffer memory that may be used for different purposes in the device. Sometimes a device comes with extra refresh buffer memory beyond what is used to hold the screen image. There are several recognized purposes for particular parts of such memory, and sometimes some memory locations may be available for more than one purpose. If so, the program using this memory will have to take care not to use the same memory for two different purposes at the same time. In order to decide whether this is a possibility, the program can inspect this parameter. For frame, direct and no-display modes, this parameter is set to the null set. Any combination of the following predefined values:

**GPR\_\$HDM\_WITH\_BITM\_EXT**

Hidden display memory (HDM), used for loaded text fonts and HDM bitmaps, overlaps with the area into which a bitmap can be extended by use of the **GPR\_\$SET\_BITMAP\_DIMENSIONS** call.

**GPR\_\$HDM\_WITH\_BUFFERS**

HDM overlaps with extra displayable refresh buffers.

**GPR\_\$BITM\_EXT\_WITH\_BUFFERS**

The bitmap extension area overlaps with displayable refresh buffers.

**X\_ZOOM\_MAX**

The maximum pixel-replication zoom factor for x on a device in borrow mode. For frame, direct and no-display modes, and for devices which do not support pixel-replication zoom, these parameters are set to 1.

**Y\_ZOOM\_MAX**

The maximum pixel-replication zoom factor for y on a device in borrow mode. For frame, direct and no-display modes, and for devices which do not support pixel-replication zoom, these parameters are set to 1.

**VIDEO\_REFRESH\_RATE**

The refresh rate of the screen in Hertz. For no-display mode, this value is set to zero.

**N\_PRIMARIES**

The number of independent primary colors supported by the video for the device. For color devices, this value is three; for monochrome devices it is one. For no-display mode, this value is set to zero.

**LUT\_WIDTH\_PER\_PRIMARY**

The value gives the number of bits of precision available in each column of a video lookup table (color map) for representing the intensity of a primary color in an overall color value. If a primary color can only be on or off, this value is one. If it can have 16 intensities, this value will be four. If it can have 256 intensities, this value will be eight. For no-display mode, this parameter is set to zero.

**AVAIL\_FORMATS**

A 2-byte integer. The set of available interactive or imaging formats available on the device. Any combination of the following predefined values:

GPR\_\$INTERACTIVE

Interactive format

GPR\_\$IMAGING\_1024X1024X8

8-bit pixel format on a two-board configuration

GPR\_\$IMAGING\_512X512X24

24-bit pixel format on a three-board configuration

**AVAIL\_ACCESS**

A 2-byte integer. This parameter gives the possible legal pixel cell sizes, in bits, which are available to a program making direct read or write access to the refresh buffer. Currently, the only supported pixel cell size is one bit. This means that the refresh buffers can only be accessed by plane. In the future, other pixel cell sizes may be supported. Any combination of the following predefined values:

GPR\_\$ALLOC\_1

One bit per pixel cell

GPR\_\$ALLOC\_2

Two bits per pixel cell

GPR\_\$ALLOC\_4

Four bits per pixel cell

GPR\_\$ALLOC\_8  
One byte per pixel cell

GPR\_\$ALLOC\_16  
Two bytes per pixel cell

GPR\_\$ALLOC\_32  
Four bytes per pixel cell

#### ACCESS\_ADDRESS\_SPACE

This parameter gives the amount of address space available for making direct access to the refresh buffer of the device, in units of 1K-byte pages. For example, if the address space is of a size sufficient to cover 1024 scan lines, each of 1024 bits, its extent will be 128K bytes, thus the value of this parameter will be 128.

#### INVERT

A 2-byte integer. This parameter is intended for monochromatic devices. It indicates how the display manager's INV is implemented on the device. One of the following predefined values:

GPR\_\$ACCEL\_NONE  
The display is not a monochromatic display or there is no display.

GPR\_\$INVERT\_SIMULATE  
Color map is simulated in software.

GPR\_\$INVERT\_HARDWARE  
Color map is implemented in hardware.

#### GPR\_\$DISPLAY\_CONFIG\_T

A 2-byte integer. Specifies the hardware configuration. One of the following predefined values:

GPR\_\$BW\_800X1024  
A portrait black and white display.

GPR\_\$BW\_1024X800  
A landscape black and white display.

GPR\_\$COLOR\_1024X1024X4  
A four-plane color display.

GPR\_\$COLOR\_1024X1024X8  
An eight-plane color display.

GPR\_\$COLOR\_1024X800X4  
An four-plane color display.

GPR\_\$COLOR\_1024X800X8  
An eight-plane color display.

GPR\_\$COLOR\_1280X1024X8  
Two-board, eight-plane display.

## GPR DATA TYPES

GPR\_\$COLOR1\_1024X800X8  
Two-board, eight-plane display.

GPR\_\$COLOR2\_1024X800X4  
One-board, four-plane display.

GPR\_\$BW\_1280X1024  
Black and white display.

GPR\_\$DISPLAY\_INVERT\_T

A 2-byte integer. The different color map implementations on monochromatic displays. One of the following predefined values:

GPR\_\$NO\_INVERT  
Not applicable, that is, a color monitor or no display.

GPR\_\$INVERT\_SIMULATE  
The color map is simulated in software.

GPR\_\$INVERT\_HARDWARE  
The color map is in hardware.

GPR\_\$DISPLAY\_MODE\_T

A 2-byte integer. Specifies the mode of operation. One of the following predefined values:

GPR\_\$BORROW  
Uses the entire screen.

GPR\_\$FRAME  
Uses a frame of the Display Manager.

GPR\_\$NO\_DISPLAY  
Uses a main-memory bitmap.

GPR\_\$DIRECT  
Uses a display-manager window.

GPR\_\$BORROW\_NC  
Uses the entire screen but does not clear the bitmap.

GPR\_\$EC\_KEY\_T

A 2-byte integer. GPR\_\$INPUT\_EC is a predefined value.

GPR\_\$EVENT\_T

A 2-byte integer. Specifies the type of input event. One of the following predefined values:

GPR\_\$KEYSTROKE  
When keyboard character is typed.

GPR\_\$BUTTONS  
When you press button on the mouse or bitpad puck.

**GPR\_\$LOCATOR**

When you move the mouse or bitpad puck or use the touchpad.

**GPR\_\$LOCATOR\_UPDATE**

Only the most recent location when you move the mouse or bitpad puck or use the touchpad.

**GPR\_\$ENTERED\_WINDOW**

When the cursor enters a window in which the GPR bitmap resides. Direct mode is required.

**GPR\_\$LEFT\_WINDOW**

When the cursor leaves a window in which the GPR bitmap resides. Direct mode is required.

**GPR\_\$LOCATOR\_STOP**

When you stop moving the mouse or bitpad puck, or stop using the touchpad.

**GPR\_\$NO\_EVENT**


**GPR\_\$FORMAT\_SET\_T**

A 2-byte integer. Specifies a set of imaging formats.

**GPR\_\$HORIZ\_SEG\_T**

Defines the left- and right-hand x coordinates and the y coordinate of a horizontal line segment. The diagram below illustrates the `gpr_$horiz_seg_t` data type:

predefined  
type



**Field Description:**

`x_coord_l`

The left-hand x coordinate of the line.

`x_coord_r`

The right-hand x coordinate of the line.

`y_coord`

The y coordinate of the line.

## GPR DATA TYPES

GPR\_\$IMAGING\_FORMAT\_T

A 2-byte integer. Specifies an imaging or interactive display format. One of the following predefined values:

GPR\_\$INTERACTIVE  
Specifies interactive format.

GPR\_\$IMAGING\_1024X1024X8  
Specifies 8-bit imaging format.

GPR\_\$IMAGING\_512X512X24  
Specifies 24-bit imaging format.

GPR\_\$KEYSET\_T

An 8-element array of 4-byte integers. Specifies the set of characters that make up a keyset associated with the graphics input event types GPR\_\$KEYSTROKE and GPR\_\$BUTTONS. The maximum number of elements in a keyset is 256. Each element of the set is represented by one bit.

GPR\_\$LINE\_PATTERN\_T

A 4-element array of 2-byte integers. Specifies the line-pattern to use for line-drawing operations

GPR\_\$LINESTYLE\_T

A 2-byte integer. Specifies the linestyle for line-drawing operations One of the following predefined values:

GPR\_\$SOLID  
Draw solid lines.

GPR\_\$DOTTED  
Draw dotted lines.

GPR\_\$MASK\_T

A 2-byte integer. Specifies a set of planes to be used in a plane mask.

GPR\_\$MEMORY\_OVERLAP\_T

A 2-byte integer. Kinds of memory overlaps between different classes of buffer memory. One of the following predefined values:

GPR\_\$HDM\_WITH\_BITM\_EXT  
Hidden display memory (HDM), used for loaded text fonts and HDM bitmaps, overlaps with the area into which a bitmap can be extended by use of the GPR\_\$SET\_BITMAP\_DIMENSIONS call

GPR\_\$HDM\_WITH\_BUFFERS  
HDM overlaps with extra displayable refresh buffers

GPR\_\$BITM\_EXT\_WITH\_BUFFERS  
The bitmap extension area overlaps with displayable refresh buffers.

GPR\_\$OBSCURED\_OPT\_T

A 2-byte integer. Specifies the action when a window is obscured. One of the following predefined values:

GPR\_\$OK\_IF\_OBS

Acquire the display even though the window is obscured.

GPR\_\$INPUT\_OK\_IF\_OBS

Acquire the display and allows input into the window even though the window is obscured.

GPR\_\$ERROR\_IF\_OBS

Do not acquire the display; return an error message.

GPR\_\$POP\_IF\_OBS

Pop the window if it is obscured.


GPR\_\$BLOCK\_IF\_OBS

Do not acquire the display until the window is popped.

GPR\_\$OFFSET\_T

Specifies the width and height of a window. The diagram below illustrates the gpr\_\$offset\_t data type:

predefined type



Field Description:

x\_size

The width of the window in pixels.

y\_size

The height of the window in pixels.

GPR\_\$OVERLAP\_SET\_T

A 2-byte integer. Specifies a set of overlaps between different classes of buffer memory.

GPR\_\$PIXEL\_ARRAY\_T

A 131073-element array of 4-byte integers. Stores multiple pixel values.

GPR\_\$PIXEL\_VALUE\_T

A 4-byte integer. Defines an index into a color map to identify the color of an individual pixel.


GPR DATA TYPES

GPR\_\$PLANE\_T

A 2-byte integer. Specifies the number of planes in a bitmap.

GPR\_\$POSITION\_T

Specifies the x and y coordinates of a point in a bitmap. The diagram below illustrates the gpr\_\$position\_t data type:



Field Description:

x\_coord  
The x\_coordinate of the point in the bitmap.

y\_coord  
The y\_coordinate of the point in the bitmap.

GPR\_\$RASTER\_OP\_ARRAY\_T

A 8-element array of 2-byte integers. Stores multiple raster operation opcodes

GPR\_\$RASTER\_OP\_T

A 2-byte integer. Specifies raster operation opcodes.

GPR\_\$ROP\_PRIM\_SET\_ELEMS\_T

A 2-byte integer. Specifies the primitives to which raster operations are applied. Any combination of the following predefined values:

GPR\_\$ROP\_BLT  
Apply raster operations to block transfers.


GPR\_\$ROP\_LINE  
Apply raster operations to unfilled line primitives.

GPR\_\$ROP\_FILL  
Apply raster operations to filled primitives.

GPR\_\$ROP\_PRIM\_SET\_T

A 2-byte integer. Specifies the set of primitives that can have a raster operation established with GPR\_\$RASTER\_OP\_PRIM\_SET. In addition, this set specifies the primitives for which a raster operation can be returned with GPR\_\$INQ\_RASTER\_OPS. The maximum number of elements in the set is 3. Each element of the set is represented by one bit.

- GPR\_\$RHDM\_PR\_T                      A 4-byte integer. A pointer to a procedure used for refresh-hidden display memory procedures.
  
- GPR\_\$RWIN\_PR\_T                     A 4-byte integer. A pointer to a procedure used for refresh-window procedures.
  
- GPR\_\$STRING\_T                      An array of up to 256 characters. Stores up to 256 characters.
  
- GPR\_\$TRAP\_LIST\_T                  A 10-element array of gpr\_\$trap\_t record structures. The diagram below illustrates a single element:




**Field Description:**

- top.x\_coord\_l  
The left-hand x\_\_coordinate of the top line.
  
- top.x\_coord\_r  
The right-hand x\_\_coordinate of the top line.
  
- top.y\_coord  
The y\_\_coordinate of the top line.
- bot.x\_coord\_l  
The left-hand x\_\_coordinate of the bottom line.
  
- bot.x\_coord\_r  
The right-hand x\_\_coordinate of the bottom line.
  
- bot.y\_coord  
The y\_\_coordinate of the bottom line.

GPR DATA TYPES

GPR\_\$TRAP\_T

Specifies the coordinates of the top and bottom line segments of a trapezoid. The diagram below illustrates the gpr\_\$trap\_t data type:



Field Description:

top.x\_coord\_l  
The left-hand x\_\_coordinate of the top line.

top.x\_coord\_r  
The right-hand x\_\_coordinate of the top line.

top.y\_coord  
The y\_\_coordinate of the top line.


bot.x\_coord\_l  
The left-hand x\_\_coordinate of the bottom line.

bot.x\_coord\_r  
The right-hand x\_\_coordinate of the bottom line.

bot.y\_coord  
The y\_\_coordinate of the bottom line.


GPR\_\$TRIANGLE\_LIST\_T

A 10-element array of gpr\_\$triangle\_t record structures. The diagram below illustrates a single element:



GPR\_\$TRIANGLE\_FILL\_CRITERIA\_T

Specifies the filling criterion to use on polygons decomposed into triangles or polygons rendered with GPR\_\$RENDER\_EXACT. The diagram below illustrates the gpr\_\$triangle\_fill\_criteria\_t data type:



Field Description:

wind\_type  
 The type of fill criterion to use. That is, GPR\_\$PARITY, GPR\_\$NONZERO, or GPR\_\$SPECIFIC.


GPR DATA TYPES

winding\_no

The winding number to be used when the wind\_type is GPR\_\$SPECIFIC.

GPR\_\$TRIANGLE\_T

Specifies the coordinates of a triangle. The diagram below illustrates the gpr\_\$triangle\_t data type:



Field Description:

p1.x\_coord  
The x coordinate of point 1.

p1.y\_coord  
The y coordinate of point 1.

p2.x\_coord  
The x coordinate of point 2.

p2.y\_coord  
The y coordinate of point 2.

p3.x\_coord\_  
The x coordinate of point 3.

p3.y\_coord  
The y coordinate of point 3.

winding  
The winding number.


GPR\_\$VERSION\_T

The version number of an external bitmap header. The diagram below illustrates the gpr\_\$version\_t data type:

predefined  
type

byte:  
offset

field name



Field Description:

**major**  
The major version number.

**minor**  
The minor version number.

GPR\_\$WINDING\_SET\_T

A 2-byte integer. Specifies a fill criterion. One of the following predefined values:

GPR\_\$PARITY  
Apply a parity fill.

GPR\_\$NONZERO  
Apply a nonzero fill.

GPR\_\$SPECIFIC  
Fill areas with a specific winding number.

GPR\_\$WINDOW\_LIST\_T

A 10-element array of gpr\_\$window\_t record structures. The diagram below illustrates a single element:

predefined type	byte: offset	field name
window_base	0:	integer x_coord
	2:	integer y_coord
window_size	4:	integer x_size
	6:	integer y_size

**Field Description:**

**window\_base.x\_coord**  
 The x coordinate of the top left-hand corner of the window.


**window\_base.y\_coord**  
 The y coordinate of the top left-hand corner of the window.

**window\_size.x\_size**  
 The width of the widow in pixels.

**window\_size.y\_size**  
 The height of the window in pixels.

GPR\_\$WINDOW\_T

Defines a rectangular section of a bitmap. X\_coord and y\_coord specify the coordinates of the top left-hand corner of a rectangle. X\_size and y\_size specify the width and height of the rectangle. The diagram below illustrates the gpr\_\$window\_t data type:



Field Description:

window\_base.x\_coord  
The x coordinate of the top left-hand corner of the window.


window\_base.y\_coord  
The y coordinate of the top left-hand corner of the window.

window\_size.x\_size  
The width of the widow in pixels.

window\_size.y\_size  
The height of the window in pixels.

STATUS\_\$\$T

A status code. The diagram below illustrates the STATUS\_\$\$T data type:



Field Description:

**all**  
All 32 bits in the status code.

**fail**  
The fail bit. If this bit is set, the error was not within the scope of the module invoked, but occurred within a lower-level module (bit 31).

**subsys**  
The subsystem that encountered the error (bits 24 - 30).

**modc**  
The module that encountered the error (bits 16 - 23).

**code**  
A signed number that identifies the type of error that occurred (bits 0 - 15).

## Chapter 2

### GPR Routines

This chapter lists user-callable routine descriptions alphabetically for quick reference. Each routine description contains:

- An abstract of the routine's function
- The order of the routine parameters
- A brief description of each parameter
- A description of the routine's function and use

If the parameter can be declared using a predefined data type, the description contains the phrase "in XXX format", where XXX is the predefined data type. Pascal and C programmers, look for this phrase to determine how to declare a parameter.

FORTTRAN programmers, look for the phrase that describes the data type in atomic terms, such as "This parameter is a 2-byte integer." For a complete description of each data type see Chapter 1.

The rest of the parameter description describes the use of the parameter and the values it may hold.

The following is an example of a parameter description:

#### **event\_type**

The type of event that occurred, in GPR\_\$EVENT\_T format. This is a 2-byte integer. One of the following predefined values is returned:

GPR_\$KEYSTROKE	Input from a keyboard
GPR_\$BUTTONS	Input from mouse or bitpad puck buttons
GPR_\$LOCATOR	Input from a touchpad or mouse
GPR_\$LOCATOR_UPDATE	Most recent input from a touchpad or mouse
GPR_\$ENTERED_WINDOW	Cursor has entered window
GPR_\$LEFT_WINDOW	Cursor has left window
GPR_\$LOCATOR_STOP	Input from a locator has stopped
GPR_\$NO_EVENT	No event has occurred

The GPR (Graphics Primitives) programming calls perform graphics operations within windows and window panes. This section describes their data types, call syntax, and error codes. Refer to the Introduction at the beginning of this manual for a description of data type diagrams and call syntax format.

GPR\_\$ACQUIRE\_DISPLAY

GPR\_\$ACQUIRE\_DISPLAY

Establishes exclusive access to the display hardware and the display driver.

#### FORMAT

unobscured := GPR\_\$ACQUIRE\_DISPLAY (status)

#### RETURN VALUE

##### unobscured

A Boolean value that indicates whether or not the window is obscured (false = obscured). This parameter is always true unless the option GPR\_\$OK\_IF\_OBS was specified to GPR\_\$SET\_OBSCURED\_OPT.

#### OUTPUT PARAMETERS

##### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

#### USAGE

While the display is acquired, the Display Manager cannot run. Hence, it cannot respond to pad calls or to stream calls to input or transcript pads. If you need to call any of these routines, you must release the display to do so.

Since no other display output can occur while the display is acquired, it is not a good idea to acquire the display for long periods of time. The acquire routine automatically times out after a default period of one minute; programs can change this time-out with the routine GPR\_\$SET\_ACQ\_TIME\_OUT.

Although this call is needed only in direct mode, it can be called from any of the other display modes, where it performs no operation and returns the status code GPR\_\$NOT\_IN\_DIRECT\_MODE.

If the display is already acquired when this call is made, a count of calls is incremented such that pairs of acquire/release display calls can be nested.

**GPR\_\$ADDITIVE\_BLT**

Transfers a single plane of any bitmap to all active planes of the current bitmap.

**FORMAT**

GPR\_\$ADDITIVE\_BLT (source\_bitmap\_desc, source\_window, source\_plane,  
dest\_origin, status)

**INPUT PARAMETERS****source\_bitmap\_desc**

Descriptor of the source bitmap which contains the source window to be transferred, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

**source\_window**

Rectangular section of the bitmap from which to transfer pixels, in GPR\_\$WINDOW\_T format. This data type is 8 bytes long. See the GPR Data Types section for more information.

**source\_plane**

The identifier of the source plane to add, in GPR\_\$PLANE\_T format. This is a 2-byte integer. Valid values are in the range 0 through the identifier of the source bitmap's highest plane.

**dest\_origin**

Start position (top left coordinate position) of the destination rectangle, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information. Coordinate values must be within the limits of the current bitmap, unless clipping is enabled.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Both the source and destination bitmaps can be in either display memory or main memory.

The source window origin is added to the coordinate origin for the source bitmap, and the result is the actual origin of the source rectangle for the BLT. Similarly, the destination origin is added to the coordinate origin for the current bitmap, and the result is the actual origin of the destination rectangle for the BLT.

If the source bitmap is a Display Manager frame, the only allowed raster op codes are 0, 5, A, and F. These are the raster operations in which the source plays no role.

If a rectangle is transferred by a BLT to a display manager frame and the frame is refreshed for any reason, the BLT is re-executed. Therefore, if the information in the source bitmap has changed, the appearance of the frame changes accordingly.

GPR\_\$ALLOCATE\_ATTRIBUTE\_BLOCK

GPR\_\$ALLOCATE\_ATTRIBUTE\_BLOCK

Allocates a data structure that contains a set of default bitmap attribute settings, and returns the descriptor for the data structure.

#### FORMAT

GPR\_\$ALLOCATE\_ATTRIBUTE\_BLOCK (attrib\_block\_desc, status)

#### OUTPUT PARAMETERS

##### **attrib\_block\_desc**

Attribute block descriptor, in GPR\_\$ATTRIBUTE\_DESC\_T format. This is a 4-byte integer.

##### **status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

#### USAGE

To associate an attribute block with the current bitmap, use GPR\_\$SET\_ATTRIBUTE\_BLOCK.

To deallocate an attribute block, use GPR\_\$DEALLOCATE\_ATTRIBUTE\_BLOCK.

**GPR\_\$ALLOCATE\_BITMAP**

Allocates a bitmap in main memory and returns a bitmap descriptor.

**FORMAT**

GPR\_\$ALLOCATE\_BITMAP (size, hi\_plane\_id, attrib\_block\_desc, bitmap\_desc, status)

**INPUT PARAMETERS****size**

Bitmap width and height, in GPR\_\$OFFSET\_T format. Possible values for width and height are 1 - 8192. This data type is four bytes long. See the GPR Data Types section for more information.

**hi\_plane\_id**

Identifier of the highest plane which the bitmap will use, in GPR\_\$PLANE\_T format. This is a 2-byte integer. Valid values are 0 - 7.

**attrib\_block\_desc**

Descriptor of the attribute block which the bitmap will use, in GPR\_\$ATTRIBUTE\_DESC\_T format. This is a 4-byte integer.

**OUTPUT PARAMETERS****bitmap\_desc**

Descriptor of the allocated bitmap, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To deallocate a bitmap, use GPR\_\$DEALLOCATE\_BITMAP.

A program can not use a bitmap after it is deallocated.

To establish an allocated bitmap as the current bitmap, use GPR\_\$SET\_BITMAP.

GPR\_\$ALLOCATE\_BITMAP\_NC

GPR\_\$ALLOCATE\_BITMAP\_NC

Allocates a bitmap in main memory without setting all the pixels in the bitmap to zero, and returns a bitmap descriptor.

## FORMAT

GPR\_\$ALLOCATE\_BITMAP\_NC (size,hi\_plane\_id,attrib\_block\_desc,bitmap\_desc,status)

## INPUT PARAMETERS

### size

Bitmap width and height, in GPR\_\$OFFSET\_T format. This data type is 4 bytes long. The maximum size for a main-memory bitmap is 8192 x 8192. See the GPR Data Types section for more information.

### hi\_plane\_id

Identifier of the highest plane which the bitmap will use, in GPR\_\$PLANE\_T format. This is a 2-byte integer. Valid values are 0 - 7.

### attrib\_block\_desc

Descriptor of the attribute block which the bitmap will use, in GPR\_\$ATTRIBUTE\_DESC\_T format. This is a 4-byte integer.

## OUTPUT PARAMETERS

### bitmap\_desc

Descriptor of the allocated bitmap, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To deallocate a bitmap, use GPR\_\$DEALLOCATE\_BITMAP.

A program can not use a bitmap after it is deallocated.

To establish an allocated bitmap as the current bitmap, use GPR\_\$SET\_BITMAP

GPR\_\$ALLOCATE\_BITMAP sets all pixels in the bitmap to zero; this routine does not. As a result, GPR\_\$ALLOCATE\_BITMAP\_NC executes faster, but the initial contents of the bitmap are unpredictable.

**GPR\_\$ALLOCATE\_HDM\_BITMAP**

Allocates a bitmap in hidden display memory.

**FORMAT**

GPR\_\$ALLOCATE\_HDM\_BITMAP (size, hi\_plane\_id, attrib\_block\_desc, bitmap\_desc, status)

**INPUT PARAMETERS****size**

The width and height of the bitmap, in GPR\_\$OFFSET\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**hi\_plane\_id**

The identifier of the highest plane of the bitmap, in GPR\_\$PLANE\_T format. This is a 2-byte integer.

**attrib\_block\_desc**

The descriptor of the bitmap's attribute block, in GPR\_\$ATTRIBUTE\_DESC\_T format. This is a 4-byte integer.

**OUTPUT PARAMETERS****bitmap\_desc**

The descriptor of the bitmap in hidden display memory, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$ALLOCATE\_HDM\_BITMAP allocates a GPR bitmap in hidden display memory for programs in borrow-display or direct mode. In frame mode, hidden display memory bitmaps cannot be used.

In direct mode you must acquire the display before calling GPR\_\$ALLOCATE\_HDM\_BITMAP.

The maximum size allowed for hidden display memory bitmaps is 224 bits by 224 bits.

Use GPR\_\$DEALLOCATE\_BITMAP to deallocate a hidden display bitmap.

GPR\_\$ARC\_3P

GPR\_\$ARC\_3P

Draws an arc from the current position through two other specified points.

### FORMAT

GPR\_\$ARC\_3P (point\_2, point\_3, status)

### INPUT PARAMETERS

**point\_2**

The second point on the arc, in GPR\_\$POSITION\_\$T format. This data type is 4 bytes long. See the GPR Data Type section for more information.

**point\_3**

The third point on the arc, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

### OUTPUT PARAMETERS

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

### USAGE

The coordinates you specify are added to the corresponding elements of the coordinate origin for the current bitmap. The resultant coordinate positions are the points through which the arc is drawn.

After the arc is drawn, point\_3 becomes the current position.

An error is returned if any of the three points are equal.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

**GPR\_\$ATTRIBUTE\_BLOCK**

Returns the descriptor of the attribute block associated with the given bitmap.

**FORMAT**

attrib\_block\_desc = GPR\_\$ATTRIBUTE\_BLOCK (bitmap\_desc, status)

**RETURN VALUE****attrib\_block\_desc**

Descriptor of the attribute block used for the given bitmap, in GPR\_\$ATTRIBUTE\_DESC\_T format. This is a 4-byte integer.

**INPUT PARAMETERS****bitmap-desc**

Descriptor of the bitmap that is using the requested attribute block, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To set an attribute block as the block for the current bitmap, use GPR\_\$SET\_ATTRIBUTE\_BLOCK.

GPR\_\$BIT\_BLT

GPR\_\$BIT\_BLT

Performs a bit block transfer from a single plane of any bitmap to a single plane of the current bitmap.

## FORMAT

GPR\_\$BIT\_BLT (source\_bitmap\_desc, source\_window, source\_plane,  
dest\_origin, dest\_plane, status)

## INPUT PARAMETERS

### source\_bitmap\_desc

Descriptor of the source bitmap which contains the source window to be transferred, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

### source\_window

Rectangular section of the bitmap from which to transfer pixels, in GPR\_\$WINDOW\_T format. This data type is 8 bytes long. See the GPR Data Types section for more information.

### source\_plane

Identifier of the single plane of the source bitmap to move, in GPR\_\$PLANE\_T format. This is a 2-byte integer. Valid values are in the range 0 through the identifier of the source bitmap's highest plane.

### dest\_origin

Start position (top left coordinate position) of the destination rectangle, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

### dest\_plane

Identifier of the plane of the destination bitmap, in GPR\_\$PLANE\_T format. This is a 2-byte integer. Valid values are in the range 0 through the identifier of the destination bitmap's highest plane.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

Both the source and destination bitmaps can be in either display memory or main memory.

The source window origin is added to the coordinate origin for the source bitmap, and the result is the actual origin of the source rectangle for the BLT. Similarly, the destination origin is added to the coordinate origin for the current bitmap, and the result is the actual origin of the destination rectangle for the BLT.

If the source bitmap is a Display Manager frame, the only allowed raster op codes are 0, 5, A, and F. These are the raster operations in which the source plays no role.

If a rectangle is transferred by a BLT to a Display Manager frame and the frame is refreshed for any reason, the BLT is re-executed. Therefore, if the information in the source bitmap has changed, the appearance of the frame changes accordingly.

GPR\_\$CIRCLE

GPR\_\$CIRCLE

Draws a circle with the specified radius around the specified center point.

## FORMAT

GPR\_\$CIRCLE(center, radius, status)

## INPUT PARAMETERS

### center

The center of the circle, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

### radius

The radius of the circle. This is a 2-byte integer in the range 1 - 32767.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

The coordinates you specify for the parameter "center" are added to the corresponding coordinates of the origin for the current bitmap. The resultant coordinate position is the center of the circle.

GPR\_\$CIRCLE does not change the current position.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

**GPR\_\$CIRCLE\_FILLED**

Draws and fills a circle with the specified radius around the specified center point.

**FORMAT**

GPR\_\$CIRCLE\_FILLED (center, radius, status)

**INPUT PARAMETERS****center**

The center of the circle, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**radius**

The radius of the circle. This is a 2-byte integer in the range 1 - 32767.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

The coordinates you specify for the parameter "center" are added to the corresponding coordinates of the origin for the current bitmap. The resultant coordinate position is the center of the circle.

GPR\_\$CIRCLE\_FILLED does not change the current position.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

GPR\_\$CLEAR

GPR\_\$CLEAR

Sets all pixels in the current bitmap to the given color/intensity value.

## FORMAT

GPR\_\$CLEAR (index, status)

## INPUT PARAMETERS

### index

New color map index specifying a color/intensity value for all pixels in the current bitmap, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer. Valid values are:

- 0 - 1 for monochromatic displays
- 0 - 15 for color displays in 4-bit pixel format
- 0 - 255 for color displays in 8-bit or 24-bit pixel format
- 2 for all displays.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

A special case occurs if the specified index is -2. A value of -2 specifies clearing the bitmap to the current background color/intensity value. For memory bitmaps and borrowed displays, the background color/intensity index is zero. For Display Manager frames, the background color/intensity value is the same as that used for the window background color.

For monochromatic displays, only the low-order bit of the color value is considered, because bitmaps currently have only one plane. For color displays in 4-bit pixel mode, only the four lowest-order bits of the color value are considered because these displays have four planes.

You can use GPR\_\$SET\_COLOR\_MAP to establish the correspondence between color map indexes and color/intensity values. This means that you can use GPR\_\$SET\_COLOR\_MAP to assign the pixel value 0 to bright intensity, and then use GPR\_\$CLEAR either to make the screen bright by passing the pixel value 0, or make the screen dark by passing the value 1. This routine is subject to the restrictions of the current clipping window and plane mask.

**GPR\_\$CLOSE\_FILL\_PGON**

Closes and fills the currently open polygon.

**FORMAT**

GPR\_\$CLOSE\_FILL\_PGON (status)

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$CLOSE\_FILL\_PGON closes and fills the series of polygon boundaries created with the routines GPR\_\$START\_PGON and GPR\_\$PGON\_POLYLINE.

GPR\_\$CLOSE\_FILL\_PGON does not use the current raster operation setting.

Filled areas rasterized when the decomposition technique is GPR\_\$NON\_OVERLAPPING\_TRIS contain fewer pixels than filled areas rasterized with the decomposition technique set to either GPR\_\$FAST\_TRAPS or GPR\_\$PRECISE\_TRAPS.

Abutting filled areas rasterized when the decomposition technique is gpr\_\$non\_overlapping\_tris do not overlap.

Abutting filled areas rasterized when the decomposition technique is either GPR\_\$FAST\_TRAPS or GPR\_\$PRECISE\_TRAPS OVERLAP.

GPR\_\$CLOSE\_RETURN\_PGON

GPR\_\$CLOSE\_RETURN\_PGON

Closes the currently open polygon and returns the list of trapezoids within its interior.

## FORMAT

GPR\_\$CLOSE\_RETURN\_PGON (list\_size, trapezoid\_list, trapezoid\_number, status)

## INPUT PARAMETERS

**list\_size**

The maximum number of trapezoids that the routine is to return. This is a 2-byte integer.

## OUTPUT PARAMETERS

**trapezoid\_list**

The trapezoids returned. This is a GPR\_\$TRAP\_LIST\_T array of up to 10 elements. See GPR Data Types section for more information.

**trapezoid\_number**

The number of trapezoids that exist within the polygon interior. This is a 2-byte integer.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

GPR\_\$CLOSE\_RETURN\_PGON returns a list of trapezoids within a polygon interior that the graphics program can draw at a later time with the routine GPR\_\$MULTITRAPEZOID.

The trapezoid\_number parameter is always the total number of trapezoids composing the polygon interior. If this number is greater than the list-size parameter, some trapezoids were left out of the trapezoid\_list for lack of space.

**GPR\_\$CLOSE\_RETURN\_PGON\_TRI**

Closes the currently open polygon and returns a list of triangles within its interior.

**FORMAT**

GPR\_\$CLOSE\_RETURN\_PGON\_TRI (list\_size, t\_list, n\_triangles, status)

**INPUT PARAMETERS****list\_size**

Maximum number of triangles that the routine is to return.

**OUTPUT PARAMETERS****t\_list**

Triangles returned. This is a GPR\_\$TRIANGLE\_LIST\_T array. See the GPR Data Types section for more information.

**n\_triangles**

Number of triangles that exist within the polygon interior. This is a 2-byte integer.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$CLOSE\_RETURN\_PGON\_TRI returns a list of triangles within a polygon interior that the graphics program can fill at a later time with the routine GPR\_\$MULTITRIANGLE.

GPR\_\$CLOSE\_RETURN\_PGON\_TRI returns a list of triangles when a polygon has been defined using GPR\_\$START\_PGON and GPR\_\$PGON\_POLYLINE with the decomposition technique set to gpr\_\$non\_overlapping\_tris.

The n\_triangles parameter is always the total number of triangles composing the polygon interior. If this number is greater than the list\_size parameter, some triangles were left out of the t\_list for lack of space.

GPR\_\$COLOR\_ZOOM

GPR\_\$COLOR\_ZOOM

Sets the zoom scale factor for a color display.

## FORMAT

GPR\_\$COLOR\_ZOOM (xfactor, yfactor, status)

## INPUT PARAMETERS

### xfactor

A 2-byte integer that denotes the scale factor for the x-coordinate, in the range 1 through 16.

### yfactor

A 2-byte integer that denotes the scale factor for the y-coordinate, in the range 1 through 16.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

If the x value is not equal to 1, then the y value must be not equal to 1.

GPR\_\$COLOR\_ZOOM uses the integer zoom feature of the color hardware.

GPR\_\$COLOR\_ZOOM works only in borrow-display mode.

GPR\_\$COLOR\_ZOOM always zooms from the upper-left corner of the display.

GPR\_\$COLOR\_ZOOM returns an error on models DN570/570A and DN3000 if any values other than xfactor = 1, yfactor = 1 are entered.

DN580s allow the xfactor and yfactor to be 2.

**GPR\_\$COND\_EVENT\_WAIT**

Returns information about the occurrence of any event without entering a wait state.

**FORMAT**

unobscured := GPR\_\$COND\_EVENT\_WAIT (event\_type, event\_data, position, status)

**RETURN VALUE****unobscured**

A Boolean value that indicates whether or not the window is obscured; a false value means that the window is obscured. This value is always true unless the program has called GPR\_\$SET\_OBSCURED\_OPT and specified an option of GPR\_\$OK\_IF\_OBS.

**OUTPUT PARAMETERS****event\_type**

The type of event that occurred, in GPR\_\$EVENT\_T format. This is a 2-byte integer. One of the following values is returned:

GPR_\$KEYSTROKE	Input from a keyboard
GPR_\$BUTTONS	Input from mouse or bitpad puck buttons
GPR_\$LOCATOR	Input from a touchpad or mouse
GPR_\$LOCATOR_UPDATE	Most recent input from a touchpad or mouse
GPR_\$ENTERED_WINDOW	Cursor has entered window
GPR_\$LEFT_WINDOW	Cursor has left window
GPR_\$LOCATOR_STOP	Input from a locator has stopped
GPR_\$NO_EVENT	No event has occurred

**event\_data**

The keystroke or button character associated with the event, or the character that identifies the window associated with an entered window event. This parameter is not modified for other events.

**position**

The position on the screen or within the window at which graphics input occurred, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

When called, this routine returns immediately and reports information about any event that has occurred. Typically, this routine is called following return from an EC2\_\$WAIT call involving the eventcount returned by GPR\_\$GET\_EC. The routine allows the program to obtain information about an event without having to suspend all of its activities.

## GPR\_\$COND\_EVENT\_WAIT

Unless locator data has been processed since the last event was reported, "position" will be the last position given to GPR\_\$SET\_CURSOR\_POSITION.

If locator data is received during this call, and GPR\_\$LOCATOR events are not enabled, the GPR software will display the arrow cursor and will set the keyboard cursor position.

Unlike GPR\_\$EVENT\_WAIT, this call never releases the display.

The input routines report button events as ASCII characters. "Down" transitions range from "a" to "d"; "up" transitions range from "A" to "D". The three mouse keys start with (a/A) on the left side. As with keystroke events, button events can be selectively enabled by specifying a button keyset.

**GPR\_\$DEALLOCATE\_ATTRIBUTE\_BLOCK**

Deallocates an attribute block allocated by GPR\_\$ALLOCATE\_ATTRIBUTE\_BLOCK.

**FORMAT**

GPR\_\$DEALLOCATE\_ATTRIBUTE\_BLOCK (attrib\_block\_desc, status)

**INPUT PARAMETERS****attrib\_block\_desc**

The descriptor of the attribute block to deallocate, in GPR\_\$ATTRIBUTE\_DESC\_T format. This is a 4-byte integer.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To allocate an attribute block, use GPR\_\$ALLOCATE\_ATTRIBUTE\_BLOCK.

To associate an attribute block with the current bitmap, use GPR\_\$SET\_ATTRIBUTE\_BLOCK.

GPR\_\$DEALLOCATE\_BITMAP

GPR\_\$DEALLOCATE\_BITMAP

Deallocates an allocated bitmap.

## FORMAT

GPR\_\$DEALLOCATE\_BITMAP (bitmap\_desc, status)

## INPUT PARAMETERS

**bitmap\_desc**

Descriptor of the bitmap to deallocate, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

## OUTPUT PARAMETERS

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To allocate a bitmap, use GPR\_\$ALLOCATE\_BITMAP, GPR\_\$OPEN\_BITMAP\_FILE, or GPR\_\$ALLOCATE\_HDM\_BITMAP.

**GPR\_\$DISABLE\_INPUT**

Disables a previously enabled event type.

**FORMAT**

GPR\_\$DISABLE\_INPUT (event\_type, status)

**INPUT PARAMETERS****event\_type**

The type of event to be disabled, in GPR\_\$EVENT\_T format. This is a 2-byte integer. Specify only one of the following events:

**GPR\_\$KEYSTROKE**

Input from a keyboard. GPR\_\$BUTTONS

Input from mouse or bitpad puck buttons. GPR\_\$LOCATOR

Input from a touchpad or mouse. GPR\_\$LOCATOR\_UPDATE

Most recent input from a touchpad or mouse.

GPR\_\$ENTERED\_WINDOW

Cursor has entered window. GPR\_\$LEFT\_WINDOW

Cursor has left window. GPR\_\$LOCATOR\_STOP

Input from a locator has stopped. GPR\_\$NO\_EVENT

No event has occurred.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Following this call, no events of the given event type will be returned by GPR\_\$EVENT\_WAIT or GPR\_\$COND\_EVENT\_WAIT.

In borrow-display mode, disabled events received by the GPR software will be ignored.

In direct mode or frame mode, disabled keystroke or button events are processed by the Display Manager.

When locator events are disabled, the GPR software will display the arrow cursor and will set the keyboard cursor position when locator data is received.

GPR\_\$DRAW\_BOX

GPR\_\$DRAW\_BOX

Draws an unfilled box based on the coordinates of two opposing corners.

#### FORMAT

GPR\_\$DRAW\_BOX (X1, Y1, X2, Y2, status)

#### INPUT PARAMETERS

**X1**

The x coordinate of the top left-hand corner of the box. This is a 2-byte integer.

**Y1**

The y coordinate of the top left-hand corner of the box. This is a 2-byte integer.

**X2**

The x coordinate of the bottom right-hand corner of the box. This is a 2-byte integer.

**Y2**

The y coordinate of the bottom right-hand corner of the box. This is a 2-byte integer.

#### OUTPUT PARAMETERS

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

#### USAGE

The coordinates you specify are added to the corresponding elements of the coordinate origin for the current bitmap. The resultant coordinate positions are the top left-hand and bottom right-hand corners of the box.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

**GPR\_\$ENABLE\_DIRECT\_ACCESS**

Ensures completion of display hardware operations before the program uses the pointer to access display memory.

**FORMAT**

GPR\_\$ENABLE\_DIRECT\_ACCESS (status)

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

If a program uses the GPR\_\$INQ\_BITMAP\_POINTER to get the address of display memory for a monochromatic or color display, it should call GPR\_\$ENABLE\_DIRECT\_ACCESS after any calls that change the display and before using the pointer returned from the GPR\_\$INQ\_BITMAP\_POINTER.

GPR\_\$ENABLE\_INPUT

GPR\_\$ENABLE\_INPUT

Enables an event type and a selected set of keys.

## FORMAT

GPR\_\$ENABLE\_INPUT (event\_type, key\_set, status)

## INPUT PARAMETERS

### event\_type

The type of event to be enabled, in GPR\_\$EVENT\_T format. The types of events are:

GPR_\$KEYSTROKE	Input from a keyboard.
GPR_\$BUTTONS	Input from mouse or bitpad puck buttons.
GPR_\$LOCATOR	Input from a touchpad or mouse.
GPR_\$LOCATOR_UPDATE	Most recent input from a touchpad or mouse.
GPR_\$ENTERED_WINDOW	Cursor has entered window.
GPR_\$LEFT_WINDOW	Cursor has left window.
GPR_\$LOCATOR_STOP	Input from a locator has stopped.
GPR_\$NO_EVENT	No event has occurred.

### key\_set

The set of specifically enabled characters when the event class is in GPR\_\$KEYSET\_T format. In Pascal, this is a set of characters. In FORTRAN and C this can be implemented as an eight element array of 4-byte integers. This parameter is specified for event types of GPR\_\$KEYSTROKE and GPR\_\$BUTTONS. See GPR Data Types section for more information.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is four bytes long. See the GPR Data Types section for more information.

## USAGE

This routine specifies the type of event and event input for which GPR\_\$EVENT\_WAIT is to wait.

This routine applies to the current bitmap. However, enabled input events are stored in attribute blocks (not with bitmaps) in much the same way as attributes are. When a program changes attribute blocks for a bitmap during a graphics session, the input events you enabled are lost unless you enable those events for the new attribute block.

Programs must call this routine once for each event type to be enabled.

No event types are enabled by default.

The keyset must correspond to the specified event type. For example, use ['#'..'~'] (in Pascal) to enable all normal printing graphics. Use [chr(0)..chr(127)] to enable the entire ASCII character set. Except in borrow-display mode, it is a good idea to leave at least the CMD and NEXT\_WINDOW keys out of the keyset so that the user can access other Display Manager windows.

The insert file /SYS/INS/KBD.INS.PAS contains definitions for the non-ASCII keyboard keys in the range 128 - 255.

Events and keyset data not enabled with this routine will be handled by the Display Manager in frame or direct mode and discarded in borrow-display mode.

When locator events are disabled, the GPR software will display the arrow cursor and will set the keyboard cursor position when locator data is received.

A group of calls is available for manipulating large sets. The calls are: LIB\_\$INIT\_SET, LIB\_\$ADD\_TO\_SET, LIB\_\$CLR\_FROM\_SET, and LIB\_\$MEMBER\_OF\_SET. The calls are fully described in *Programming with General System Calls*.

For an exact cursor path use GPR\_\$LOCATOR with GPR\_\$SET\_CURSOR\_POSITION. Most applications can use GPR\_\$LOCATOR\_UPDATE. With this value, GPR automatically tracks the most recent cursor location and GPR\_\$SET\_CURSOR\_POSITION is not needed.

GPR\_\$LOCATOR\_UPDATE eliminates multiple locator events between GPR\_\$EVENT\_WAIT calls. Only one locator event will be delivered at a time, and the reported position will be the most recent one.

Custom cursor patterns cannot be used with GPR\_\$LOCATOR\_UPDATE.

GPR\_\$EVENT\_WAIT

GPR\_\$EVENT\_WAIT

Waits for an event.

## FORMAT

unobscured := GPR\_\$EVENT\_WAIT (event\_type, event\_data, position, status)

## RETURN VALUE

### unobscured

A Boolean value that indicates whether or not the window is obscured; a false value means that the window is obscured. This value is always true unless the program has called GPR\_\$SET\_OBSCURED\_OPT and specified an option of GPR\_\$OK\_IF\_OBS.

## OUTPUT PARAMETERS

### event\_type

The type of event that occurred, in GPR\_\$EVENT\_T format. This is a 2-byte integer. One of the following predefined values is returned:

GPR_\$KEYSTROKE	Input from a keyboard
GPR_\$BUTTONS	Input from mouse or bitpad puck buttons
GPR_\$LOCATOR	Input from a touchpad or mouse
GPR_\$LOCATOR_UPDATE	Most recent input from a touchpad or mouse
GPR_\$ENTERED_WINDOW	Cursor has entered window
GPR_\$LEFT_WINDOW	Cursor has left window
GPR_\$LOCATOR_STOP	Input from a locator has stopped
GPR_\$NO_EVENT	No event has occurred

### event\_data

The keystroke or button character associated with the event, or the character that identifies the window associated with an entered window event. This parameter is not modified for other events.

### position

The position on the screen or within the window at which graphics input occurred, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

This routine suspends process execution until the occurrence of an event type enabled with the GPR\_\$ENABLE\_INPUT. If the event type is keystroke or button, this routine reports only characters in the enabled keyset. Input routines report button events as ASCII characters.

In direct mode, time-out values do not apply to calls to GPR\_\$EVENT\_WAIT; that is, GPR\_\$EVENT\_WAIT waits indefinitely.

The input routines report button events as ASCII characters. "Down" transitions range from "a" to "d"; "up" transitions range from "A" to "D". The three mouse keys start with (a/A) on the left side. As with keystroke events, button events can be selectively enabled by specifying a button keyset.

Unless locator data has been processed since the last event was reported, "position" will be the last position given to GPR\_\$SET\_CURSOR\_POSITION.

If locator data is received during this call, and GPR\_\$LOCATOR events are not enabled, the GPR software will display the arrow cursor and will set the keyboard cursor position.

The display does not need to be acquired to call GPR\_\$EVENT\_WAIT.

This routine will implicitly release the display when the current process is waiting for an event to occur, or when an event that has not been enabled occurs and that event must be handled by the Display Manager.

GPR\_\$FORCE\_RELEASE

GPR\_\$FORCE\_RELEASE

Releases the display regardless of how many times it has previously been acquired.

## FORMAT

GPR\_\$FORCE\_RELEASE (acquire\_count, status)

## OUTPUT PARAMETERS

### acquire\_count

The number of times the display has been acquired. This is a 2-byte integer.

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

This call releases the display regardless of how many times GPR\_\$ACQUIRE\_DISPLAY has been called.

**GPR\_\$GET\_EC**

Returns the eventcount associated with a graphic event.

**FORMAT**

GPR\_\$GET\_EC (gpr\_key, eventcount\_pointer, status)

**INPUT PARAMETERS****gpr\_key**

The key that specifies which eventcount to obtain, in GPR\_\$EC\_KEY\_T format. Currently, this key is always GPR\_\$INPUT\_EC.

**OUTPUT PARAMETERS****eventcount\_pointer**

A pointer to the eventcount for graphics input, in EC2\_\$PTR\_T format.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Type section for more information.

**USAGE**

GPR\_\$GET\_EC returns the eventcount pointer for the graphics input eventcount, which is advanced whenever graphics input may be available.

When this eventcount is advanced, it does not guarantee that GPR\_\$COND\_EVENT\_WAIT will return an event, or that GPR\_\$EVENT\_WAIT will not wait. The advance is merely an optimization of a simple polling loop that suspends execution of the process until an event might be available.

GPR\_\$INIT

GPR\_\$INIT

Initializes the graphics primitives package.

## FORMAT

GPR\_\$INIT (op\_mode, unit, size, hi\_plane\_id, init\_bitmap\_desc, status)

## INPUT PARAMETERS

### op\_mode

One of four modes of operation. Graphics primitives routines can operate in two borrow-display modes, within a Display Manager window, within a frame of a Display Manager pad, or without using the display. Use GPR\_\$DISPLAY\_MODE\_T format for this parameter. This is a 2-byte integer. Possible values for this parameter are:

GPR\_\$BORROW

Program borrows the full screen and the keyboard from the Display Manager and uses the display driver directly through GPR software.

GPR\_\$BORROW\_NC

Same as GPR\_\$BORROW except that all the pixels are not set to zero. (screen is not cleared.)

GPR\_\$DIRECT Program borrows a window from the Display Manager instead of borrowing the whole display.

GPR\_\$FRAME Program executes within a frame of a Display Manager Pad.

GPR\_\$NO\_DISPLAY

GPR allocates a bitmap in main memory. No graphics is displayed on the screen.

### unit

This parameter has three possible meanings, as follows:

1. The display unit, if the graphics routines are to operate in a borrowed display. This is a 2-byte integer. Currently, the only valid display unit number for borrow-display mode is 1.
2. The stream identifier for the pad, if the graphics routines are to operate in frame or direct mode. Use STREAM\_\$ID\_T format. This is a 2-byte integer.
3. Any value, such as zero, if the graphics routines do not use the display.

### size

The size of the initial bitmap (and the size of the frame, in frame mode), in GPR\_\$OFFSET\_T format. This data type is 4 bytes long. See the GPR Data Type section for more information. Possible values are listed below.

	X	Y
Borrow-display or direct mode (limits are reduced to display or window size if necessary):	1 to 1024	1 to 1024
Display Manager Frame:	1 - 32767	1 - 32767
Main Memory Bitmap:	1 - 8192	1 - 8192

**hi\_plane\_id**

Identifier of the bitmap's highest plane, in GPR\_\$PLANE\_T format. This is a 2-byte integer. Valid values are:

For display memory bitmaps:

- 0 for monochromatic displays
- 0 - 3 for color displays in two-board configuration
- 0 - 7 for color displays in three-board configuration

For main memory bitmaps:

- 0 - 7 for all displays

**OUTPUT PARAMETERS****init\_bitmap\_desc**

Descriptor of the initial bitmap, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer that uniquely identifies the bitmap.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Type section for more information.

**USAGE**

To use multiple windows, you must call GPR\_\$INIT for each window.

GPR\_\$BORROW\_NC allows you to allocate a bitmap in display memory without setting all the pixels to zero.

In GPR\_\$NO\_DISPLAY mode, the program can manipulate only main memory bitmaps.

If a program executes in borrow-display mode or direct mode, the size of the initial bitmap can be equal to or smaller than the display. If the program executes in a frame of a Display Manager pad, "size" specifies the size of both the frame and the initial bitmap. (In frame mode, the frame and the bitmap must be the same size.) If the program does not use the display, GPR\_\$INIT creates a bitmap in main memory. The program specifies the size of this bitmap.

To use imaging formats, a program must be initialized in borrow-display mode.

GPR\_\$INQ\_BITMAP

GPR\_\$INQ\_BITMAP

Returns the descriptor of the current bitmap.

#### FORMAT

GPR\_\$INQ\_BITMAP (bitmap\_desc, status)

#### OUTPUT PARAMETERS

##### bitmap\_desc

The descriptor of the current bitmap, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

##### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Type section for more information.

#### USAGE

To establish a bitmap as the current bitmap, use GPR\_\$SET\_BITMAP.

**GPR\_\$INQ\_BITMAP\_DIMENSIONS**

Returns the size and number of planes of a bitmap.

**FORMAT**

GPR\_\$INQ\_BITMAP\_DIMENSIONS (bitmap\_desc, size, hi\_plane\_id, status)

**INPUT PARAMETERS****bitmap\_desc**

The descriptor of the bitmap, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

**OUTPUT PARAMETERS****size**

Width and height of the bitmap, in GPR\_\$OFFSET\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**hi\_plane\_id**

The identifier of the bitmap's highest plane, in GPR\_\$PLANE\_T format. This is a 2-byte integer.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

A program can use the information returned by this call to retrieve the actual bitmap size. This could be useful, for example, if the program specified a bitmap size that was too large for the display, causing a reduction in bitmap size.

GPR\_\$INQ\_BITMAP\_POINTER

GPR\_\$INQ\_BITMAP\_POINTER

Returns a pointer to bitmap storage in virtual address space. Also returns offset in memory from beginning of one scan line to the next.

## FORMAT

GPR\_\$INQ\_BITMAP\_POINTER (bitmap\_desc, storage\_ptr, storage\_line\_width, status)

## INPUT PARAMETERS

**bitmap\_desc**

Descriptor of the bitmap, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

## OUTPUT PARAMETERS

**storage\_ptr**

Start address of bitmap in virtual address space. This is a 4-byte integer.

**storage\_line\_width**

Number of 16-bit words in virtual memory between the beginning of one of the bitmap's scan lines and the next. This is a 2-byte integer.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

A program can use the information returned by this call to access individual bits.

Each scan line (horizontal line of a bitmap) starts on a word boundary. The parameter `storage_line_width` gives the offset in memory from the beginning of one scan line to the beginning of the next, in units of 16-bit words.

When a program uses the parameter `storage_ptr` to access the screen bitmap on a monochrome system that uses a simulated color map pixels which are white have a pixel value of 1 and pixels that are black have a pixel value of 0, regardless of any calls to `GPR_$SET_COLOR_MAP`. In other words, the pixel value itself specifies the color of the pixel: the pixel value is not used as an index into the color map. On systems that have the color map in hardware, the pixel value is used as an index into the color map. The color of the pixel is determined by the color value in the color map.

On monochromatic devices, use `GPR_$INQ_DISP_CHARACTERISTICS` to determine whether the color map is simulated or in hardware. See the datatype `gpr_$disp_char_t` in Chapter 1 of this manual for more information.

If the cursor is active, the cursor pattern appears in the bitmap.

A program cannot use this routine on a bitmap which is a Display Manager frame.

**GPR\_\$INQ\_BITMAP\_POSITION**

Returns the position of the upper left corner of the specified bitmap. This is normally the screen position; although, it does have some significance for main memory bitmaps.

**FORMAT**

GPR\_\$INQ\_BITMAP\_POSITION(bitmap\_desc,origin,status);

**INPUT PARAMETERS****bitmap\_desc**

The descriptor of the bitmap in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

**OUTPUT PARAMETERS****origin**

The position of the upper left-hand corner of the bitmap in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

This call is not meaningful if the bitmap is a display manager pad (i.e., a frame mode bitmap).

GPR\_\$INQ\_BM\_BIT\_OFFSET

GPR\_\$INQ\_BM\_BIT\_OFFSET

Returns the bit offset that corresponds to the left edge of a bitmap in virtual address space.

### FORMAT

GPR\_\$INQ\_BM\_BIT\_OFFSET (bitmap\_desc, offset, status)

### INPUT PARAMETERS

#### bitmap\_desc

The descriptor of the bitmap, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

### OUTPUT PARAMETERS

#### offset

The number of bits between a 16-bit word boundary and the left edge of the specified bitmap. This is a 2-byte integer in the range 0 - 15.

#### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

### USAGE

Each scan line (horizontal line of a bitmap) starts on a word boundary. For all scan lines, this routine returns the number of bits in the most significant part of the first word that are not part of the specified bitmap.

Currently, the offset will be zero for any bitmap other than a direct-mode window.

**GPR\_\$INQ\_BITMAP\_FILE\_COLOR\_MAP**

Returns the specified entries from the external-bitmap color map.

**FORMAT**

GPR\_\$INQ\_BITMAP\_FILE\_COLOR\_MAP (bitmap, start, entries, color, status)

**INPUT PARAMETERS****bitmap**

The bitmap descriptor for the bitmap file in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

**start**

The index of the first entry. This is a 2-byte integer.

**entries**

The number of consecutive color-map entries to return. This is a 2-byte integer.

**OUTPUT PARAMETERS****color**

The color values in UNIV GPR\_\$COLOR\_VECTOR\_T format. This is an array of long integers (4-byte integers).

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Each external bitmap is allocated its own color map. The external bitmap's color map is copied into the system color map whenever the external bitmap becomes the current bitmap.

You can inquire or change the values of the external bitmap's color map without making the external bitmap current.

Use GPR\_\$SET\_BITMAP\_FILE\_COLOR\_MAP to change the values of an external bitmap's color map.

For the monochromatic display, the default start-index is 0. The value of entries is 2, and the color values are GPR\_\$BLACK and GPR\_\$WHITE. Dark has the value GPR\_\$BLACK, and bright has the value GPR\_\$WHITE.

For the monochromatic display, if the program provides fewer than two values, or if the first two values are the same (both black or both white), the routine returns an error.

GPR\_\$INQ\_CHARACTER\_WIDTH

GPR\_\$INQ\_CHARACTER\_WIDTH

Returns the width of the specified character in the specified font.

## FORMAT

GPR\_\$INQ\_CHARACTER\_WIDTH (font\_id, character, width, status)

## INPUT PARAMETERS

**font\_id**

Identifier of the text font. This is a 2-byte integer.

**character**

The specified character. This is a character variable.

## OUTPUT PARAMETERS

**width**

The width parameter of the specified character. This is a 2-byte integer. Possible values are -127 to 127.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To set a character's width, use GPR\_\$SET\_CHARACTER\_WIDTH.

The initial character widths are defined in the font file.

This routine returns the character width in the local copy of the font. Initially, this is a copy of the font file; but the local copy may have been changed. Change in the local copy does not affect the font file or the use of the font by other processes.

**GPR\_\$INQ\_COLOR\_MAP**

Returns the current color map values.

**FORMAT**

GPR\_\$INQ\_COLOR\_MAP (start\_index, n\_entries, values, status)

**INPUT PARAMETERS****start\_index**

Index of the first color value entry, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer.

**n\_entries**

Number of entries. This is a 2-byte integer.

**OUTPUT PARAMETERS****values**

Color value entries, in GPR\_\$COLOR\_VECTOR\_T format. This is a 256-element array of 4-byte integers.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To set the color map, use GPR\_\$SET\_COLOR\_MAP.

GPR\_\$INQ\_CONFIG

GPR\_\$INQ\_CONFIG

Returns the current display configuration.

## FORMAT

GPR\_\$INQ\_CONFIG (config, status)

## OUTPUT PARAMETERS

### config

Display configuration, in GPR\_\$DISPLAY\_CONFIG\_T format. This is a 2-byte integer. One of the following predefined values is returned:

Returned Value	Display Type
GPR_\$BW_800x1024	monochromatic portrait
GPR_\$BW_1024x800	monochromatic landscape
GPR_\$COLOR_1024x1024x4	color 1024 x 1024 (DN6xx) 2-board config
GPR_\$COLOR_1024x1024x8	color 1024 x 1024 (DN6xx) 3-board config
GPR_\$COLOR_1024x800x4	color 1024 x 800 (DN5xx) 2-board config
GPR_\$COLOR_1024x800x8	color 1024 x 800 (DN5xx) 3-board config
GPR_\$COLOR1_1024X800X8	color 1024 x 800 (DN570) 2-board config
GPR_\$COLOR_1280X1024X8	color 1280 x 1024 (DN580) 2-board config
GPR_\$COLOR2_1024X800X4	color 1024 x 800 (DN3000) 1-board config

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

GPR\_\$INQ\_CONFIG can be used before GPR\_\$INIT. This is useful to determine the number of possible planes in bitmaps on color displays before initializing GPR.

**GPR\_\$INQ\_CONSTRAINTS**

Returns the clipping window and plane mask used for the current bitmap.

**FORMAT**

GPR\_\$INQ\_CONSTRAINTS (window, active, plane\_mask, status)

**OUTPUT PARAMETERS****window**

The clipping window, in GPR\_\$WINDOW\_T format. This data type is 8 bytes long. See the GPR Data Type section for more information.

**active**

Boolean (logical) value which specifies whether the clip window is enabled. If the value is false, the clip window is disabled; if the value is true, the clip window is enabled.

**plane\_mask**

The plane mask, which specifies the active bitmap plane(s), in GPR\_\$MASK\_T format. This is a 2-byte integer.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To establish a new clipping window for the current bitmap, use GPR\_\$SET\_CLIP\_WINDOW.

To enable the new clipping window, use GPR\_\$SET\_CLIPPING\_ACTIVE.

To establish a plane mask, use GPR\_\$SET\_PLANE\_MASK.

GPR\_\$INQ\_COORDINATE\_ORIGIN

GPR\_\$INQ\_COORDINATE\_ORIGIN

Returns the x- and y-offsets added to all x- and y-coordinates used as input to move, drawing, and BLT operations on the current bitmap.

#### FORMAT

GPR\_\$INQ\_COORDINATE\_ORIGIN (origin, status)

#### OUTPUT PARAMETERS

##### origin

The current coordinate origin for the bitmap, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

##### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

#### USAGE

To set a new coordinate origin, use GPR\_\$SET\_COORDINATE\_ORIGIN.

**GPR\_\$INQ\_CP**

Returns the current position in the current bitmap.

**FORMAT**

GPR\_\$INQ\_CP (x, y, status)

**OUTPUT PARAMETERS****x**

The x-coordinate of the current position, in GPR\_\$COORDINATE\_T format. This is a 2-byte integer.

**y**

The y-coordinate of the current position, in GPR\_\$COORDINATE\_T format. This is a 2-byte integer.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$INQ\_CP can be used to verify that the current position is at the desired location. If it is not, use GPR\_\$MOVE to move the current position without drawing a line.

GPR\_\$INQ\_CURSOR

GPR\_\$INQ\_CURSOR

Returns information about the cursor.

## FORMAT

GPR\_\$INQ\_CURSOR (curs\_pat, curs\_raster\_op, active, position, origin, status)

## OUTPUT PARAMETERS

### cursor\_pat

Identifier of the cursor pattern bitmap, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

### cursor\_raster\_op

Cursor raster operation code, in GPR\_\$RASTER\_OP\_ARRAY\_T format. This is an eight-element array of 2-byte integers. The default value is three. (The operation assigns all source values to the new destination).

### active

A Boolean (logical) value which indicates whether the cursor is displayed. The parameter is set to true if the cursor is displayed; it is set to false if the cursor is not displayed.

### position

The cursor's current position on the screen, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Type section for more information.

### origin

The pixel currently set as the cursor origin, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Type section for more information.

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

Cursor position: If a program calls this routine when in borrow-display mode, the x- and y-coordinates represent an absolute position on the screen. If a program calls this routine when the cursor is inside a frame of a display manager pad, the x- and y-coordinates are relative to the top left corner of the frame.

To alter the cursor, use one of the following:

GPR\_\$SET\_CURSOR\_PATTERN  
GPR\_\$SET\_CURSOR\_ACTIVE  
GPR\_\$SET\_CURSOR\_POSITION  
GPR\_\$SET\_CURSOR\_ORIGIN

Currently, a program can not alter the cursor raster operation.

If no cursor pattern has been set, the default rectangle cursor is returned.

GPR\_\$INQ\_DISP\_CHARACTERISTICS

GPR\_\$INQ\_DISP\_CHARACTERISTICS

Allows the application program to obtain a variety of information about the nature of the actual display device or external bitmap if the program is operating in no-display mode.

## FORMAT

GPR\_\$INQ\_DISP\_CHARACTERISTICS(op,unit\_or\_pad,disp\_len,disp,disp\_len\_ret,status)

## INPUT PARAMETERS

### op

One of four modes of operation. Graphics primitives routines can operate in two borrow-display modes, within a Display Manager window, within a frame of a Display Manager pad, or without using the display. Use GPR\_\$DISPLAY\_MODE\_T format for this parameter. This is a 2-byte integer. Possible values for this parameter are:

GPR\_\$BORROW

Returns information about to a borrowed display.

GPR\_\$BORROW\_NC

Returns information about to a borrowed display.

GPR\_\$DIRECT Returns information about to a direct-mode window.

GPR\_\$FRAME Returns information about to a frame of a Display Manager Pad.

GPR\_\$NO\_DISPLAY

Returns information about to a main-memory bitmap.

### unit\_or\_pad

This parameter has three possible meanings, as follows:

1. The display unit, if the graphics routines are to operate in a borrowed display. This is a 2-byte integer. Currently, the only valid display unit number for borrow-display mode is 1.
2. The stream identifier for the pad, if the graphics routines are to operate in frame or direct mode. Use STREAM\_\$ID\_T format. This is a 2-byte integer.
3. For gpr\_\$no\_display this parameter is ignored.

**disp\_len**

Size of the buffer (the DISP parameter described below) provided by the calling program, which will contain the returned display or device information in bytes. For example, if the buffer is ten 16-bit words in length, the program gives 20 as the value of this parameter. No checking is (or can be) done to verify that this length is correct, so unpredictable results are obtained if the program gives a size that is larger than the actual size of the buffer. This parameter allows the calling program to request that less than the full set of characteristics be returned. It also allows the program to continue to function correctly if the list of returned characteristics is extended in the future.

**OUTPUT PARAMETERS****disp**

Returned display device characteristics in GPR\_\$DISP\_CHAR\_T format. This is an array of up to 56 bytes. See the GPR data types section for more information.

**disp\_len\_ret**

Actual number of bytes of data returned in the "disp" parameter. This is a 2-byte integer. It will always be less than or equal to the "disp\_len" input parameter value. Presently, the length of the full set of characteristics is 28 16-bit words, or 56 bytes, so 56 is the current maximum possible value for this parameter.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Prior to SR9.2, programs using GPR could only obtain a value that identified a particular display type, for example, a monochrome display, 1024 by 800 pixels. Programs then derived the particular display characteristics from this value. As a result, a program that wanted to determine display characteristics had to assign a value to each device type that it might want to obtain. Each time we added new display types, user programs had to be modified to identify the new display types.

GPR\_\$INQ\_DISP\_CHARACTERISTICS eliminates the need for user programs to include values that identify display device characteristics. This call returns all of a node's display characteristics as a data item in the "disp" parameter. If you use this call, you will not need to extend your programs to support any future display types.

## GPR\_\$INQ\_DISP\_CHARACTERISTICS

You can call GPR\_\$INQ\_DISP\_CHARACTERISTICS at any time, regardless of whether or not GPR has been initialized. If you have initialized GPR, calling this routine has no effect on the current bitmap or its attributes.

When the program calls GPR\_\$INQ\_DISP\_CHARACTERISTICS, the values it specifies in the first two parameters are the same as the values it specifies to GPR\_\$INIT. These parameters identify the display mode and unit or stream to the call, which can then return specific information about the window or bitmap to be used, as well as general information about the display device. The application program must supply a buffer variable, typically of a record type in Pascal, a structure type in C, or an array type in FORTRAN, in which the data can be returned.

In the future, we may extend the list of data items that this call returns as we release new display devices with new characteristics. However, programs written to use the existing set of characteristics will continue to operate correctly.

**GPR\_\$INQ\_DRAW\_VALUE**

Returns the color/intensity value used for drawing lines.

**FORMAT**

GPR\_\$INQ\_DRAW\_VALUE (index, status)

**OUTPUT PARAMETERS****index**

The color map index that indicates the current color/intensity value used for drawing lines, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer. Valid values are:

- 0 - 1            For monochromatic displays
- 0 - 15          For color displays in 4-bit pixel Format
- 0 - 255        For color displays in 8-bit or 24-bit pixel Format
- 1             For all displays. This specifies that the background is transparent; that is, the old values of the pixels are not changed.
- 2             For all displays. This specifies using the color/intensity value of the bitmap background as the line drawing value. For borrowed displays and memory bitmaps, the fill background is always zero. For Display Manager frames, this is the pixel value in use for the window background.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To set a new draw value, use GPR\_\$SET\_DRAW\_VALUE.

GPR\_\$INQ\_FILL\_BACKGROUND\_VALUE

GPR\_\$INQ\_FILL\_BACKGROUND\_VALUE

Returns the color/intensity value of the background used for tile fills.

## FORMAT

GPR\_\$INQ\_FILL\_BACKGROUND\_VALUE (index, status)

## OUTPUT PARAMETERS

### index

The color map index that indicates the current color/intensity value used for tile fills, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer. Valid values are:

- 0 - 1            For monochromatic displays
- 0 - 15           For color displays in 4-bit pixel format
- 0 - 255          For color displays in 8-bit or 24-bit pixel format
- 1               For all displays. This specifies that the background is transparent; that is, the old values of the pixels are not changed.
- 2               For all displays. This specifies using the color/intensity value of the bitmap background as the tile fill background. For borrowed displays and memory bitmaps, the fill background is always zero. For Display Manager frames, this is the pixel value in use for the window background.

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To set a new background value, use GPR\_\$SET\_FILL\_BACKGROUND\_VALUE.

**GPR\_\$INQ\_FILL\_PATTERN**

Returns the fill pattern for the current bitmap.

**FORMAT**

GPR\_\$INQ\_FILL\_PATTERN(pattern, scale, status)

**OUTPUT PARAMETERS****pattern**

The descriptor of the bitmap containing the fill pattern, in GPR\_\_\$BITMAP\_DESC\_T format.

**scale**

The number of times each bit in this pattern is to be replicated before proceeding to the next bit in the pattern in both the x and y directions. This is a 2-byte integer.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To set a new fill pattern for the current bitmap, use GPR\_\_\$SET\_FILL\_PATTERN.

Currently, the tile pattern must be stored in a bitmap that is 32 x 32 pixels. The scale factor must be one. Any other pattern size or scale value results in an error.

With a one-plane bitmap as the pattern, the pixel values used are those set by GPR\_\_\$SET\_FILL\_VALUE and GPR\_\_\$SET\_FILL\_BACKGROUND\_VALUE. Pixels corresponding to "1" bits of the pattern are drawn in the fill value; pixels corresponding to "0" bits of the pattern are drawn in the fill background value.

GPR\_\$INQ\_FILL\_VALUE

GPR\_\$INQ\_FILL\_VALUE

Returns the color/intensity value used to fill circles, rectangles, triangles, and trapezoids.

## FORMAT

GPR\_\$INQ\_FILL\_VALUE (index, status)

## OUTPUT PARAMETERS

### index

The color map index that indicates the current color/intensity fill value, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer. Valid values are:

- 0 - 1            For monochromatic displays
- 0 - 15          For color displays in 4-bit pixel format
- 0 - 255        For color displays in 8-bit or 24-bit pixel format

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To set a new fill value, use GPR\_\$SET\_FILL\_VALUE.

**GPR\_\$INQ\_HORIZONTAL\_SPACING**

Returns the parameter for the width of spacing between displayed characters for the specified font.

**FORMAT**

GPR\_\$INQ\_HORIZONTAL\_SPACING (font\_id, horizontal\_spacing, status)

**INPUT PARAMETERS****font\_id**

Identifier of the text font. This is a 2-byte integer.

**OUTPUT PARAMETERS****horizontal\_spacing**

The parameter for horizontal spacing of the specified font. This is a 2-byte integer. Possible values are in the range -127 - 127.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Use GPR\_\$SET\_HORIZONTAL\_SPACING to set the width of spacing for a font.

The initial width of horizontal spacing is defined in the font file.

This routine returns the horizontal spacing in the local copy of the font. Initially, this is a copy of the font file; however, the local copy may have been changed. Change in the local copy does not affect the font file or the use of the font by other processes.

GPR\_\$INQ\_IMAGING\_FORMAT

GPR\_\$INQ\_IMAGING\_FORMAT

Returns the current imaging format.

## FORMAT

GPR\_\$INQ\_IMAGING\_FORMAT (format, status)

## OUTPUT PARAMETERS

### format

Imaging format in GPR\_\$IMAGING\_FORMAT\_T configuration. This is a 2-byte integer. If you are using an interactive format, the returned value is GPR\_\$INTERACTIVE. If you are using the imaging 8-bit pixel format on a two-board configuration, the returned value is GPR\_\$IMAGING\_1024x1024x8. If you are using the imaging 24-bit pixel format, the returned value is GPR\_\$IMAGING\_512x512x24.

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To set the imaging format, use GPR\_\$SET\_IMAGING\_FORMAT.

**GPR\_\$INQ\_LINE\_PATTERN**

Returns the pattern used in drawing lines.

**FORMAT**

GPR\_\$INQ\_LINE\_PATTERN (repeat, pattern, length, status)

**OUTPUT PARAMETERS****repeat**

The replication factor for each bit in the pattern. This is a 2-byte integer.

**pattern**

The bit pattern, left justified, in GPR\_\$LINE\_PATTERN\_T format. This is a four-element array of 2-byte integers.

**length**

The length of the pattern in bits. This is a 2-byte integer in the range of 0 - 64.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$INQ\_LINE\_PATTERN returns the current line pattern set explicitly with GPR\_\$SET\_LINE\_PATTERN or set implicitly with GPR\_\$SET\_LINestyle.

Use GPR\_\$SET\_LINE\_PATTERN to specify a new line pattern. You can also use GPR\_\$SET\_LINestyle to set a line pattern within the limits of the parameter GRP\_\$DOTTED.

GPR\_\$INQ\_LINestyle

GPR\_\$INQ\_LINestyle

Returns information about the current line-style.

## FORMAT

GPR\_\$INQ\_LINestyle (style, scale, status)

## OUTPUT PARAMETERS

### style

The style of line, in GPR\_\$LINestyle\_T format. This is a 2-byte integer. One of the following predefined values is returned:

GPR\_\$SOLID For solid lines

GPR\_\$DOTTED  
For dotted lines.

### scale

The scale factor for dashes if the style parameter is GPR\_\$DOTTED. This is a 2-byte integer.

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

When the line-style attribute is GPR\_\$DOTTED, lines are drawn in dashes. The scale factor determines the number of pixels in each dash and in each space between the dashes.

To set the line-style attribute, use GPR\_\$SET\_LINestyle.

## GPR\_\$INQ\_PGON\_DECOMP\_TECHNIQUE

Returns the mode which controls the algorithm used to decompose and rasterize polygons.

**FORMAT**

GPR\_\$INQ\_PGON\_DECOMP\_TECHNIQUE(decomp\_technique,status)

**OUTPUT PARAMETERS****decomp\_technique**

Returns a mode which controls the algorithm used to decompose and render polygons into trapezoids in GPR\_\$DECOMP\_TECHNIQUE\_T format. This is a 2-byte integer. Only one of the following predefined values is returned:

**GPR\_\$FAST\_TRAPS**

This is the default value on DN3XX/4XXs, DN550/560s, and DN6XXs which indicates that the faster but imprecise algorithm is to be used. This is the only algorithm that existed prior to SR9.

**GPR\_\$PRECISE\_TRAPS**

This value indicates that a slower but more precise version of the decomposition algorithm is to be used.

**GPR\_\$NON\_OVERLAPPING\_TRIS**

This is the default value on DN570/580s and DN3000s which indicates that a triangle decomposition algorithm is to be used.

**GPR\_\$RENDER\_EXACT**

This value indicates that the most precise rendering algorithm is to be used. It provides the best performance for rectilinear and axis aligned polygons, and it renders self-intersecting polygons more accurately than any of the other techniques in the following situation: when the intersection of two edges of the polygon is located at a noninteger.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$INQ\_PGON\_DECOMP\_TECHNIQUE returns a mode setting, not an attribute.

GPR\_\$INQ\_RASTER\_OP\_PRIM\_SET

GPR\_\$INQ\_RASTER\_OP\_PRIM\_SET

Returns the primitive(s) which will be affected by the next GPR\_\$SET\_RASTER\_OP call, or the primitive(s) for which GPR\_\$INQ\_RASTER\_OP will return the current raster-op.

## FORMAT

GPR\_\$INQ\_RASTER\_OP\_PRIM\_SET (prim\_set, status)

## OUTPUT PARAMETERS

### prim\_set

The set of primitives (lines, fills, and bit-block transfers) in GPR\_\$ROP\_PRIM\_SET\_T format for which raster-ops can be set or inquired with GPR\_\$SET\_RASTER\_OP or GPR\_\$INQ\_RASTER\_OP, respectively. See the GPR Data Types section for more information.

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

Use GPR\_\$INQ\_RASTER\_OP\_PRIM\_SET to return the set of primitives that will be affected by GPR\_\$SET\_RASTER\_OP. Use GPR\_\$RASTER\_OP\_PRIM\_SET to modify the set if necessary.

Use GPR\_\$INQ\_RASTER\_OP\_PRIM\_SET to return the set of primitives that will have a raster-op returned with GPR\_\$INQ\_RASTER\_OP.

If prim\_set contains the values GPR\_\$ROP\_LINE and GPR\_\$ROP\_FILL, and the raster-ops for these operations are different, GPR\_\$INQ\_RASTER\_OP returns an error. When the values in prim\_set have different raster-ops, call GPR\_\$RASTER\_OP\_PRIM\_SET to establish the set with one value; then call GPR\_\$INQ\_RASTER\_OP.

**GPR\_\$INQ\_RASTER\_OPS**

Returns the raster operation for the primitives (lines, fills, and bit-block transfers) specified with GPR\_\$RASTER\_OP\_PRIM\_SET.

**FORMAT**

GPR\_\$INQ\_RASTER\_OPS (raster\_op, status)

**OUTPUT PARAMETERS****raster\_op**

Raster operation codes, in GPR\_\$RASTER\_OP\_ARRAY\_T format. This is an eight-element array of 2-byte integers. Each element corresponds to the raster operation for a single plane of the bitmap. Possible raster op values are zero through fifteen.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To set a new raster operation for the primitives (lines, fills, and bit-block transfers) specified with GPR\_\$RASTER\_OP\_PRIM\_SET, use GPR\_\$SET\_RASTER\_OP.

If the set of primitives established with GPR\_\$RASTER\_OP\_PRIM\_SET have different raster-ops, this call returns an error.

If the set of primitives established with GPR\_\$RASTER\_OP\_PRIM\_SET is empty, this call returns an error.

Use GPR\_\$INQ\_RASTER\_OP\_PRIM\_SET to return the set of primitives established with GPR\_\$RASTER\_OP\_PRIM\_SET.

When the values in the set of primitives established with GPR\_\$RASTER\_OP\_PRIM\_SET have different raster-ops, call GPR\_\$RASTER\_OP\_PRIM\_SET to establish the set with one value, then call GPR\_\$INQ\_RASTER\_OP.

GPR\_\$INQ\_REFRESH\_ENTRY

GPR\_\$INQ\_REFRESH\_ENTRY

Returns two pointers: one to the procedure which refreshes the window; one to the procedure which refreshes hidden display memory.

## FORMAT

GPR\_\$INQ\_REFRESH\_ENTRY (window\_procedure, disp\_mem\_procedure, status)

## OUTPUT PARAMETERS

### window\_procedure

Entry point for the application-supplied procedure that refreshes the Display Manager window, in GPR\_\$RWIN\_PR\_T format. This is a pointer to a procedure.

### disp\_mem\_procedure

Entry point for the application-supplied procedure that refreshes the application's hidden display memory, in GPR\_\$RHDM\_PR\_T format. This is a pointer to a procedure.

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

The returned routines apply to the current bitmap and current attribute block.

Applications can also direct the Display Manager to refresh the window automatically; see the routine GPR\_\$SET\_AUTO\_REFRESH.

**GPR\_\$INQ\_SPACE\_SIZE**

Returns the width of the space to be displayed when a character requested is not in the specified font.

**FORMAT**

GPR\_\$INQ\_SPACE\_SIZE (font\_id, space\_size, status)

**INPUT PARAMETERS****font\_id**

Identifier of the text font. This is a 2-byte integer.

**OUTPUT PARAMETERS****space\_size**

The space size of the specified font. This is a 2-byte integer. Possible values are in the range -127 to 127.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To set a font's space size, use GPR\_\$SET\_SPACE\_SIZE.

The initial space size is defined in the font file.

The space size is the number of pixels to skip in the horizontal direction when a character not included in the font is written.

GPR\_\$INQ\_TEXT

GPR\_\$INQ\_TEXT

Returns the text font and text path used for the current bitmap.

## FORMAT

GPR\_\$INQ\_TEXT (font\_id, direction, status)

## OUTPUT PARAMETERS

### font\_id

Identifier of the text font used for the current bitmap. This is a 2-byte integer.

### direction

The direction of movement from one text character position to the next in the current bitmap, in GPR\_\$DIRECTION\_T format. This is a 2-byte integer. One of the following predefined values is returned:

GPR\_\$UP,  
GPR\_\$DOWN,  
GPR\_\$LEFT,  
GPR\_\$RIGHT

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To set a new text font for the current bitmap, use GPR\_\$SET\_TEXT\_FONT.

To change the direction of text, use GPR\_\$SET\_TEXT\_PATH.

**GPR\_\$INQ\_TEXT\_EXTENT**

Returns the x- and y-offsets a string spans when written by GPR\_\$TEXT.

**FORMAT**

GPR\_\$INQ\_TEXT\_EXTENT (string, string\_length, size, status)

**INPUT PARAMETERS****string**

A string, in GPR\_\$STRING\_T format. This is a 256 element character array.

**string\_length**

Number of characters in the string. This is a 2-byte integer. The maximum value is 256.

**OUTPUT PARAMETERS****size**

Width and height of the area the written string will occupy, in GPR\_\$OFFSET\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**status**


Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

When the text path is GPR\_\$RIGHT or GPR\_\$LEFT, the width is the x-offset. When the text path is GPR\_\$UP or GPR\_\$DOWN, the height is the y-offset.

To change the direction of text, use GPR\_\$SET\_TEXT\_PATH.

Figure GPR-1 shows two examples of the extent of text in relation to offsets. For horizontal text, use GPR\_\$RIGHT with GPR\_\$SET\_TEXT\_PATH. For rotated text, use GPR\_\$UP with GPR\_\$SET\_TEXT\_PATH.



**Figure GPR-1. Height and Width for Horizontal and Rotated Text**

**GPR\_\$INQ\_TEXT\_OFFSET**

Returns the x- and y-offsets from the top left pixel of a string to to the origin of the string's first character. This routine also returns the x- or y-offset to the pixel which is the new current position after the text is written with GPR\_\$TEXT.

**FORMAT**

GPR\_\$INQ\_TEXT\_OFFSET (string, string\_length, start, xy\_end, status)

**INPUT PARAMETERS****string**

A string, in GPR\_\$STRING\_T format. This is a 256-element character array.

**string\_length**

Number of characters in the string. This is a 2-byte integer. The maximum value is 256.

**OUTPUT PARAMETERS****start**

X- and Y-offsets from the top left pixel of the string to the origin of its first character, in GPR\_\$OFFSET\_T format. This data type is 4 bytes long. See the GPR Data Type section for more information.

**xy\_end**

The X- or Y-offset from the top left pixel of the string to the pixel that will be the new current position after the string is written with GPR\_\$TEXT. This is the X-offset when the text path is specified as GPR\_\$RIGHT or GPR\_\$LEFT. This is The Y-offset when the text path is specified as GPR\_\$UP or GPR\_\$DOWN. This is a 2-byte integer.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

A program can use the information derived from the "start" output parameter to set the current position to the character origin, rather than the top left corner of the string, before writing the string with GPR\_\$TEXT.

When the text path is GPR\_\$RIGHT or GPR\_\$LEFT, the offset is to the x-axis. When the text path is GPR\_\$UP or GPR\_\$DOWN, the offset is to the y-axis.

See GPR\_\$SET\_TEXT\_PATH for use of GPR\_\$RIGHT, GPR\_\$LEFT, GPR\_\$UP, and GPR\_\$DOWN.

Figure GPR-2 shows an example of text offsets, after using GPR\_\$RIGHT and GPR\_\$UP with GPR\_\$SET\_TEXT\_PATH.





Figure GPR-2. Text Offsets

**GPR\_\$INQ\_TEXT\_PATH**

Returns the direction for writing a line of text.

**FORMAT**

GPR\_\$INQ\_TEXT\_PATH (direction, status)

**OUTPUT PARAMETERS****direction**

Direction for writing text, in GPR\_\$DIRECTION\_T format. This is a 2-byte integer. One of the following predefined values is returned: GPR\_\$UP, GPR\_\$DOWN, GPR\_\$LEFT, GPR\_\$RIGHT

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To set the current text path, use GPR\_\$SET\_TEXT\_PATH.

GPR\_\$INQ\_TEXT\_VALUES

GPR\_\$INQ\_TEXT\_VALUES

Returns the text color/intensity value and the text background color/intensity value used in the current bitmap.

#### FORMAT

GPR\_\$INQ\_TEXT\_VALUES (text\_value, text\_bkgd\_value, status)

#### OUTPUT PARAMETERS

##### text\_value

A color map index that indicates the text color/intensity value, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer.

##### text\_bkgd\_value

A color map index that indicates the text background color/intensity value, in GPR\_\$PIXEL\_T format. This is a 4-byte integer.

##### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

#### USAGE

To establish the text color/intensity value, use GPR\_\$SET\_TEXT\_VALUE. To establish the text background color/intensity value, use GPR\_\$SET\_TEXT\_BACKGROUND\_VALUE.

**GPR\_\$INQ\_TRIANGLE\_FILL\_CRITERIA**

Returns the filling criteria used with polygons decomposed into triangles.

**FORMAT**

GPR\_\$INQ\_TRIANGLE\_FILL\_CRITERIA(fill\_crit, status)

**OUTPUT PARAMETERS****fill\_crit**

Returns the filling criteria. This is a 2-byte integer. Possible values for this parameter are:

**GPR\_\$PARITY** Provides a means for filling polygons decomposed into triangles using an odd parity scheme. Regions filled in these polygons will match regions filled in polygons decomposed into trapezoids.

**GPR\_\$NONZERO**

Provides a means for filling all nonzero regions of a polygon.

**GPR\_\$SPECIFIC**

Provides a means for filling specific regions of a polygon. This is done by specifying a winding number. The only restriction is that regions with a winding number of zero cannot be filled.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Use GPR\_\$PGON\_DECOMP\_TECHNIQUE to set a mode which controls the algorithm used to decompose polygons.

Use GPR\_\$SET\_TRIANGLE\_FILL\_CRITERIA to set the filling criteria used with polygons decomposed into triangles or for polygons rendered with the render exact algorithm.

GPR\_\$INQ\_VIS\_LIST

GPR\_\$INQ\_VIS\_LIST

Returns a list of the visible sections of an obscured window.

## FORMAT

GPR\_\$INQ\_VIS\_LIST (slots\_available, slots\_total, vis\_list, status)

## INPUT PARAMETERS

### slots\_available

Size of the array of visible window sections. This is a 2-byte integer, which is the maximum number of visible rectangles that can be returned. If you want to list all existing sections, you must specify a number that is greater than or equal to the number returned in the slots\_total argument (see output parameters).

## OUTPUT PARAMETERS

### slots\_total

Number of existing visible rectangles. This is a 2-byte integer. If this value is greater than the slots\_available parameter, then only the number of rectangles specified in slots\_available is returned.

### vis\_list

List of visible window sections. This is an array in GPR\_\$WINDOW\_T format. This data type is eight bytes long. See the GPR Data Types section for more information.

There is no set limit to the number of visible regions that may be returned.

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

If the display has been acquired but the target window is obscured, programs can call GPR\_\$INQ\_VIS\_LIST to locate any visible sections of the window.

If the target window is visible, this routine returns a base of (0,0) and the size of the entire window.

If the window is obscured, the application should call GPR\_\$SET\_CLIP\_WINDOW once for each rectangle returned by GPR\_\$INQ\_VIS\_LIST before making calls to drawing routines. Clipping is to rectangles only. The GPR software will not perform clipping automatically.

GPR\_\$INQ\_VIS\_LIST implicitly releases and reacquires the display in order to communicate with the Display Manager.

**GPR\_\$INQ\_WINDOW\_ID**

Returns the character that identifies the current bitmap's window.

**FORMAT**

GPR\_\$INQ\_WINDOW\_ID (character, status)

**OUTPUT PARAMETERS****character**

The character that identifies the current bitmap's window.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

This character is returned by GPR\_\$EVENT\_WAIT and GPR\_\$COND\_EVENT\_WAIT when they return GPR\_\$ENTERED\_WINDOW events. The character indicates which window was entered.

The character "A" is the default value of the window identification for all windows.

GPR\_\$LINE

GPR\_\$LINE

Draws a line from the current position to the end point supplied. The current position is updated to the end point.

## FORMAT

GPR\_\$LINE (x,y, status)

## INPUT PARAMETERS

**x**

The x-coordinate, which designates the end point of the line and then becomes the current x-coordinate. Use GPR\_\$COORDINATE\_T format. This is a 2-byte integer. Its values must be within the bitmap limits, unless clipping is enabled.

**y**

The y-coordinate, which designates the end point of the line and then becomes the current y-coordinate. Use GPR\_\$COORDINATE\_T format. This is a 2-byte integer. Its values must be within the bitmap limits, unless clipping is enabled.

## OUTPUT PARAMETERS

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

The given coordinates are added to the corresponding elements of the coordinate origin for the current bitmap. The resultant coordinate position is the destination of the line drawn.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

After the line has been drawn, its end point becomes the current position.

To set a new position without drawing a line, use GPR\_\$MOVE.

**GPR\_\$LOAD\_FONT\_FILE**

Loads a font from a file into the display's font storage area.

**FORMAT**

GPR\_\$LOAD\_FONT\_FILE (pathname, pathname\_length, font\_id, status)

**INPUT PARAMETERS****pathname**

Pathname of the file containing the font, in NAME\_\$PNAME\_T format. This is a character string. Additional information on fonts can be found in the Command Reference manual.

**pathname\_length**

Number of characters in font file pathname. This is a 2-byte integer.

**OUTPUT PARAMETERS****font\_id**

Font identifier. This is a 2-byte integer. Available fonts are listed in the directory /sys/dm/fonts.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Use the font-id returned from this file as input for GPR\_\$SET\_TEXT\_FONT.

To unload fonts loaded with this routine, use GPR\_\$UNLOAD\_FONT\_FILE.

GPR\_\$MOVE

GPR\_\$MOVE

Sets the current position to the given position.

## FORMAT

GPR\_\$MOVE (x, y, status)

## INPUT PARAMETERS

**x**

The x-coordinate, which becomes the current x-coordinate, in GPR\_\$COORDINATE\_T format. This is a 2-byte integer. Its values must be within bitmap limits, unless clipping is enabled.

**y**

The y-coordinate, which becomes the current y-coordinate, in GPR\_\$COORDINATE\_T format. This is a 2-byte integer. Its values must be within bitmap limits, unless clipping is enabled.

## OUTPUT PARAMETERS

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

The current position is the starting point for many drawing and text operations.

GPR\_\$MOVE does not draw any lines.

The given coordinates are added to the corresponding elements of the coordinate origin for the current bitmap. The resultant coordinate position is the destination of the move operation.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

**GPR\_\$MULTILINE**

Draws a series of disconnected lines.

**FORMAT**

GPR\_\$MULTILINE (x, y, npositions, status)

**INPUT PARAMETERS****x**

List of the x-coordinates of all the successive coordinate positions in GPR\_\$COORDINATE\_ARRAY\_T format. This is an array of 2-byte integers. The values must be within the bitmap limits, unless clipping is enabled.

**y**

List of the y-coordinates of all the successive coordinate positions in GPR\_\$COORDINATE\_ARRAY\_T format. This is an array of 2-byte integers. The values must be within the bitmap limits, unless clipping is enabled.

**npositions**

Number of coordinate positions. This is a 2-byte integer in the range 1 - 32767.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$MULTILINE alternately moves to a new position and draws lines: it moves to the first given position, draws a line from the first to the second given position, updates the current position, moves to the third position, etc. After the last line has been drawn or the last move has been made, the endpoint becomes the current position.

The given coordinates are added to the corresponding elements of the coordinate origin for the current bitmap. The resultant coordinate position is the destination of the multiline drawn.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

GPR\_ \$MULTITRAPEZOID

GPR\_ \$MULTITRAPEZOID

Draws and fills a list of trapezoids in the current bitmap.

## FORMAT

GPR\_ \$MULTITRAPEZOID (trapezoid\_list, trapezoid\_number, status)

## INPUT PARAMETERS

### trapezoid\_list

Trapezoids to fill, in GPR\_ \$TRAP\_LIST\_T format. This data type is 12 bytes long. See the GPR Data Types section for more information.

### trapezoid\_number

Number of trapezoids to fill. This is a 2-byte integer.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_ \$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

GPR\_ \$MULTITRAPEZOID fills in a list of trapezoids with the color/intensity value specified with GPR\_ \$SET\_FILL\_VALUE.

To retrieve the current fill value, use GPR\_ \$INQ\_FILL\_VALUE.

Filled areas rasterized when the decomposition technique is GPR\_ \$NON\_OVERLAPPING\_TRIS contain fewer pixels than filled areas rasterized with the decomposition technique set to either GPR\_ \$FAST\_TRAPS or GPR\_ \$PRECISE\_TRAPS.

Abutting filled areas rasterized when the decomposition technique is gpr\_ \$non\_overlapping\_tris do not overlap.

Abutting filled areas rasterized when the decomposition technique is either GPR\_ \$FAST\_TRAPS or GPR\_ \$PRECISE\_TRAPS OVERLAP.

**GPR\_\$MULTITRIANGLE**

Draws and fills a list of triangles in the current bitmap.

**FORMAT**

GPR\_\$MULTITRIANGLE (t\_list, n\_triangles, status)

**INPUT PARAMETERS****t\_list**

Triangles to fill in GPR\_\$TRIANGLE\_LIST\_T format. This data type is a variable size array where each element of the array contains 14 bytes. See the GPR Data Types section for more information.

**n\_triangles**

Number of triangles to fill. This is a 2-byte integer.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

This call fills a list of triangles with the color/intensity value specified with GPR\_\$SET\_FILL\_VALUE.

To retrieve the current fill value, use GPR\_\$INQ\_FILL\_VALUE.

When entering coordinates for each triangle, you must set a winding number. The winding number must agree with filling criterion established with GPR\_\$SET\_TRIANGLE\_FILL\_CRITERIA. For example, if the filling criterion is gpr\_\$parity, the winding number of triangles to be filled must equal 1. The default filling criterion is gpr\_\$parity.

Individual triangles can be assigned different winding numbers making it possible to fill specific triangles in the list using GPR\_\$SET\_TRIANGLE\_FILL\_CRITERIA.

Filled areas rasterized when the decomposition technique is gpr\_\$non\_overlapping\_tris contain fewer pixels than filled areas rasterized with the decomposition technique set to either gpr\_\$fast\_traps or gpr\_\$precise\_traps.

GPR\_\$MULTITRIANGLE

Abutting filled areas rasterized when the decomposition technique is  
gpr\_\$non\_overlapping\_tris do not overlap.

Abutting filled areas rasterized when the decomposition technique is either  
gpr\_\$fast\_traps or gpr\_\$precise\_traps overlap.

**GPR\_\$OPEN\_BITMAP\_FILE**

Opens a file for external storage of a bitmap.

**FORMAT**

GPR\_\$OPEN\_BITMAP\_FILE (access, filename, name\_size, version, size, groups, group\_header, attributes, bitmap, created, status)

**INPUT PARAMETERS****access**

One of four ways to access external bitmap objects, in GPR\_\$ACCESS\_MODE\_T format. This is a 2-byte integer. Specify only one of the following values:

**GPR\_\$CREATE**

Allocates a new file on disk for storage of a graphic image.

**GPR\_\$UPDATE**

Allows you to modify a previously created file or create a new one.

**GPR\_\$WRITE** Allows you to write to an existing file.

**GPR\_\$READONLY**

Allows you to read a previously created file.

**filename**

The pathname of the bitmap file, in NAME\_\$PNAME\_T format.

**name\_size**

The length of the file name. This is a 2-byte integer.

**INPUT/OUTPUT PARAMETERS****version**

The version number on the header of the external bitmap file, in GPR\_\$VERSION\_T format. This is a two-element array of two 2-byte integers: a major version number and a minor version number. Currently, version is not used and is always returned as major version 1, minor version 1.

**size**

Bitmap width and height, in GPR\_\$OFFSET\_T format. This is a two-element array of 2-byte integers. The first element is bitmap width, in raster units; the second element is the bitmap height, in raster units. Possible values for x are 1-4096; possible values for y are 1-4096.

**groups**

The number of groups in external bitmaps. This is a 2-byte integer. Possible values are 1..(GPR\_\$MAX\_BMF\_GROUP +1). Currently, a bitmap can contain only 1 group.

**group\_header**

Description of the external bitmap, in GPR\_\$BMF\_GROUP\_HEADER\_ARRAY\_T format. This is an array [0..GPR\_\$MAX\_BMF\_GROUP] of GPR\_\$BMF\_GROUP\_HEADER\_T. A description of the fields in a group header and the possible values are listed below.

**N\_SECTS**            The number of sections in the group. Currently, there must be 1 section for each plane of a bitmap. N\_SECTS is a 2-byte integer which can have a value in the range 1 - 8.

**PIXEL\_SIZE**        The number of bits per pixel in each section of a group. Since each section currently can contain only 1 plane of a bitmap, this value must be 1. PIXEL\_SIZE is a 2-byte integer.

**ALLOCATED\_SIZE**    2-byte integer. Currently, this value must be 1, but you can specify this value as 0 and GPR will perform the necessary calculations.

**BYTES\_PER\_LINE**    The number of bytes in one row of one plane of the bitmap. BYTES\_PER\_LINE is a 2-byte integer. The value must be a multiple of 4, but can be specified as 0 and GPR will perform the necessary calculations.

**BYTES\_PER\_SECT**    The number of BYTES\_PER\_LINE multiplied by the height of the bitmap. This value must then be either rounded up to a page boundary, or for small bitmaps rounded up to the next largest binary submultiple of a page, for example, one-half, one-fourth, or one-eighth. One page equals 1024 bytes. BYTES\_PER\_SECT is a 4-byte integer. This value can be specified as 0 and GPR will perform the necessary calculations.

**STORAGE\_OFFSET**    UNIV\_PTR format

**INPUT PARAMETERS**

**attribs**

The attributes which the bitmap will use, in GPR\_\$ATTRIBUTE\_DESC\_T format. This is a 4-byte integer.

**OUTPUT PARAMETERS**

**bitmap**

Descriptor of the bitmap, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

**created**

Boolean (logical) value which specifies whether the bitmap file was created. If the value is true, the file was created.

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Currently, a section is equivalent to one plane of a bitmap. N\_SECTS may include up to eight bit planes.

For ALLOCATED\_SIZE, BYTES\_PER\_LINE and BYTES\_PER\_SECT, you can specify values as 0, and the GPR package will calculate and return the appropriate values.

BYTES\_PER\_SECT is not necessarily a multiple of BYTES\_PER\_LINE. This means that GPR will leave unused space at the end of one section to satisfy alignment constraints. The result is that the next section starts on an alignment boundary, which is normally a page boundary.

The access parameter specifies one of four ways to use external bitmaps. As shown in the table below, the value given for this parameter determines whether four other parameters are input (IN) or output (OUT). The values for these parameters are used to validate your input with GPR\_\$CREATE and GPR\_\$UPDATE.

	GPR_\$CREATE	GPR_\$UPDATE file exists no yes	GPR_\$WRITE	GPR_\$READONLY
version, size, groups, group- headers	IN	IN OUT	OUT	OUT

GPR\_\$CREATE indicates that you want a new external bitmap file. GPR\_\$UPDATE means that you want to create a new file or overwrite an existing one.

When you specify GPR\_CREATE as the access parameter and you specify a file name that already exists, the file is superseded only if it is a bitmap file. If the file is not a bitmap file, you get the error message NAME\_\$ALREADY\_EXISTS.

Attributes are not stored with the bitmap. You assign attributes when you open the bitmap file. See the routines GPR\_\$ALLOCATE\_ATTRIBUTE\_BLOCK and GPR\_\$ALLOCATE\_BITMAP.

Figure GPR-3 is a global view of one group.




Figure GPR-3. View of One Group

GPR\_\$PGON\_DECOMP\_TECHNIQUE

GPR\_\$PGON\_DECOMP\_TECHNIQUE

Sets a mode which controls the algorithm used to decompose and render polygons.

## FORMAT

GPR\_\$PGON\_DECOMP\_TECHNIQUE(decomp\_technique,status)

## INPUT PARAMETERS

### decomp\_technique

Sets a mode that controls the algorithm used to decompose and render polygons in GPR\_\$DECOMP\_TECHNIQUE\_T format. This is a 2-byte integer. Specify only one of the following predefined values:

GPR\_\$FAST\_TRAPS

This is the default value on DN3XX, DN4XX, DN550/560, DN600/660 which indicates that the fast but imprecise algorithm is to be used. This is the only algorithm that existed prior to SR9.

GPR\_\$PRECISE\_TRAPS

This value indicates that a slower but more precise version of the trapezoid decomposition algorithm is to be used.

GPR\_\$NON\_OVERLAPPING\_TRIS

This is the default value on the following models: DN570/570A/580 and DN3000.

GPR\_\$RENDER\_EXACT

This value indicates that the most precise rendering algorithm is to be used. It provides the best performance for rectilinear and axis aligned polygons, and it renders self-intersecting polygons more accurately than any of the other techniques in the following situation: when the intersection of two edges of the polygon is located at a noninteger.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

GPR\_\$PGON\_DECOMP\_TECHNIQUE establishes a mode setting, not an attribute. Setting the decomposition technique applies to all polygons drawn during a particular session of GPR (within a GPR\_\$INIT and GPR\_\$TERMINATE), not just the polygons drawn in the current bitmap.

Polygons without self-crossing and "normal" self-crossing polygons work with the GPR\_\$FAST\_TRAPS setting. Polygons with multiple self-crossings and/or vertices in close proximity may not be filled correctly with the GPR\_\$FAST\_TRAPS setting. Fill these polygons using the GPR\_\$PRECISE\_TRAPS, GPR\_\$NON\_OVERLAPPING\_TRIS, or GPR\_\$RENDER\_EXACT setting.

See Appendix E of Programming with DOMAIN Graphics Primitives for information on decomposition and rendering.

**GPR\_\$PGON\_POLYLINE**

Defines a series of line segments forming part of a polygon boundary.

**FORMAT**

GPR\_\$PGON\_POLYLINE (x, y, npositions, status)

**INPUT PARAMETERS****x**

List of the x-coordinates of all the successive positions.

GPR\_\$COORDINATE\_ARRAY\_T, a ten-element array of 2-byte integers, is an example of such an array. The actual array can have up to 32767 elements. The values must be within the bitmap limits, unless clipping is enabled.

**y**

List of the y-coordinates of all the successive positions.

GPR\_\$COORDINATE\_ARRAY\_T, a ten-element array of 2-byte integers, is an example of such an array. The actual array can have up to 32767 elements. The values must be within the bitmap limits, unless clipping is enabled.

**npositions**

Number of coordinate positions. This is a 2-byte integer in the range 1 - 32767.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$PGON\_POLYLINE defines a series of line segments that comprise part of a polygon to be filled in by either (1) GPR\_\$CLOSE\_FILL\_PGON, by (2) GPR\_\$CLOSE\_RETURN\_PGON and GPR\_\$MULTITRAPEZOID, or by (3) GPR\_\$CLOSE\_RETURN\_PGON\_TRI and GPR\_\$MULTITRIANGLE. The lines are not drawn on the screen until the polygon is filled in by either routines (1), (2), or (3) above. To draw an unfilled polygon, use GPR\_\$POLYLINE.

GPR\_\$PGON\_POLYLINE must be called only when the line segments of a polygon are being defined. See the routine GPR\_\$START\_PGON for more information.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

GPR\_\$PIXEL\_BLT

GPR\_\$PIXEL\_BLT

Performs a pixel block transfer from any bitmap to the current bitmap.

## FORMAT

GPR\_\$PIXEL\_BLT (source\_bitmap\_desc, source\_window, dest\_origin, status)

## INPUT PARAMETERS

**source\_bitmap\_desc**

Descriptor of the source bitmap which contains the source window to be transferred, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

**source\_window**

Rectangular section of the bitmap from which to transfer pixels, in GPR\_\$WINDOW\_T format. This data type is 8 bytes long. See the GPR Data Types section for more information.

**dest\_origin**

Start position (top left coordinate position) of the destination rectangle, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## OUTPUT PARAMETERS

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

Use GPR\_\$SET\_BITMAP to establish the current bitmap for this routine.

Both the source and destination bitmaps can be in either display memory or main memory.

The source window origin is added to the coordinate origin for the source bitmap, and the result is the actual origin of the source rectangle for the BLT. Similarly, the destination origin is added to the coordinate origin for the current bitmap, and the result is the actual origin of the destination rectangle for the BLT.

If the source bitmap is a Display Manager frame, the only allowed raster op codes are 0, 5, A, and F. These are the raster operations in which the source plays no role.

If a rectangle is transferred by a BLT to a Display Manager frame and the frame is refreshed for any reason, the BLT is re-executed. Therefore, if the information in the source bitmap has changed, the appearance of the frame changes accordingly.

**GPR\_\$POLYLINE**

Draws a series of connected lines: drawing begins at the current position, draws to the first given coordinate position, then sets the current position to the first given position. This is repeated for all given positions.

**FORMAT**

GPR\_\$POLYLINE (x, y, npositions, status)

**INPUT PARAMETERS****x**

List of the x-coordinates of all the successive positions.

GPR\_\$COORDINATE\_ARRAY\_T, a ten-element array of 2-byte integers, is an example of such an array. The actual array can have up to 32767 elements. The values must be within the bitmap limits, unless clipping is enabled.

**y**

List of the y-coordinates of all the successive positions.

GPR\_\$COORDINATE\_ARRAY\_T, a ten-element array of 2-byte integers, is an example of such an array. The actual array can have up to 32767 elements. The values must be within the bitmap limits, unless clipping is enabled.

**npositions**

Number of coordinate positions. This is a 2-byte integer in the range 1 - 32767.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

The given coordinates are added to the corresponding elements of the coordinate origin for the current bitmap. The resultant coordinate position is the destination of the polyline drawn.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

GPR\_\$RASTER\_OP\_PRIM\_SET

GPR\_\$RASTER\_OP\_PRIM\_SET

Specifies the primitive(s) which will be affected by the next GPR\_\$SET\_RASTER\_OP call, or the primitive(s) for which GPR\_\$INQ\_RASTER\_OP will return the current raster-op.

## FORMAT

GPR\_\$RASTER\_OP\_PRIM\_SET (prim\_set, status)

## INPUT PARAMETERS

### prim\_set

The set of primitives (lines, fills, and bit-block transfers) in GPR\_\$ROP\_PRIM\_SET\_ELEMS\_T format for which raster-ops can be set or inquired with GPR\_\$SET\_RASTER\_OP or GPR\_\$INQ\_RASTER\_OP, respectively. See the GPR Data Types section for more information.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

Use GPR\_\$RASTER\_OP\_PRIM\_SET to specify which primitives will be affected when a raster operation is set with GPR\_\$SET\_RASTER\_OP. For example, if prim\_set contains the values GPR\_\$ROP\_LINE and GPR\_\$ROP\_FILL, only line and fill raster operations will be affected with the next call to GPR\_\$SET\_RASTER\_OP.

Use GPR\_\$RASTER\_OP\_PRIM\_SET to specify the primitives for which GPR\_\$INQ\_RASTER\_OP will return the raster-op. If the members of the set have different raster-ops or if the set is empty, an error message is returned.

Raster-ops for lines, fills, and blts can be different at the same time by making successive calls to GPR\_\$RASTER\_OP\_PRIM\_SET and GPR\_\$SET\_RASTER\_OP.

The default prim\_set contains GPR\_\$ROP\_LINE and GPR\_\$ROP\_BLT.

GPR\_\$ROP\_LINE affects the following routines: GPR\_\$LINE, GPR\_\$POLYLINE, GPR\_\$MULTILINE, GPR\_\$DRAW\_BOX, GPR\_\$CIRCLE, and GPR\_\$ARC\_3P.

GPR\_\$ROP\_FILL affects the following routines: GPR\_\$TRIANGLE, GPR\_\$MULTITRIANGLE, GPR\_\$TRAPEZOID, GPR\_\$CLOSE\_FILL\_PGON, GPR\_\$CIRCLE\_FILLED, and GPR\_\$RECTANGLE.

GPR\_\$ROP\_BLT affects the following routines: GPR\_\$BIT\_BLT, GPR\_\$PIXEL\_BLT, and GPR\_\$ADDITIVE\_BLT.

**GPR\_ \$READ\_ PIXELS**

Reads the pixel values from a window of the current bitmap and stores the values in a pixel array.

**FORMAT**

GPR\_ \$READ\_ PIXELS (source\_window, pixel\_array, status)

**INPUT PARAMETERS****source\_window**

Rectangular section of the current bitmap from which to read pixel values (color/intensity), in GPR\_ \$WINDOW\_ T format. This data type is 8 bytes long. See the GPR Data Types section for more information.

**OUTPUT PARAMETERS****pixel\_array**

An array of the pixel values (color/intensity) in GPR\_ \$PIXEL\_ ARRAY\_ T format. This is a 131,073-element array of 4-byte integers.

**status**

Completion status, in STATUS\_ \$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

The pixel values from the source window of the current bitmap are stored in the pixel array in row-major order, one in each 4-byte integer.

To write pixel values from an array to the current bitmap, use GPR\_ \$WRITE\_ PIXELS.

A program cannot use this routine on a bitmap corresponding to a Display Manager frame.

A program cannot read pixels values in imaging formats.

If you read more pixels than there are in pixel\_array, unpredictable results may occur.

GPR\_\$RECTANGLE

GPR\_\$RECTANGLE

Draws and fills a rectangle.

## FORMAT

GPR\_\$RECTANGLE (rectangle, status)

## INPUT PARAMETERS

### rectangle

The rectangle in the current bitmap to be filled in. Rectangle is in GPR\_\$WINDOW\_T format. This data type is 8 bytes long. See the GPR Data Type section for more information.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

GPR\_\$RECTANGLE fills in a rectangle with the color/intensity value specified with GPR\_\$SET\_FILL\_VALUE. To retrieve the current fill value, use GPR\_\$INQ\_FILL\_VALUE.

To draw an unfilled rectangle use GPR\_\$DRAW\_BOX or GPR\_\$POLYLINE.

**GPR\_\$RELEASE\_DISPLAY**

Decrements a counter associated with the number of times a display has been acquired.

**FORMAT**

GPR\_\$RELEASE\_DISPLAY (status)

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$RELEASE\_DISPLAY decrements a counter whose value reflects the number of times the display has been acquired. If the counter value reaches zero, the routine releases the display, allowing other processes, including the Display Manager, to use the display.

Programs that call GPR\_\$EVENT\_WAIT may not need to call GPR\_\$RELEASE\_DISPLAY, since GPR\_\$EVENT\_WAIT releases the display implicitly whenever the process waits for input.

GPR\_\$REMAP\_COLOR\_MEMORY

GPR\_\$REMAP\_COLOR\_MEMORY

Defines the plane in color display memory for which a pointer will be returned when using GPR\_\$INQ\_BITMAP\_POINTER. This allows a single plane of color display memory to be accessed directly.

## FORMAT

GPR\_\$REMAP\_COLOR\_MEMORY (plane, status)

## INPUT PARAMETERS

### plane

The plane in color display memory in GPR\_\$PLANE\_T. This is a 2-byte integer. A pointer can be returned to the plane using GPR\_\$INQ\_BITMAP\_POINTER. Valid values are 0 - 7.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

When accessing color display memory directly (i.e. by dereferencing the pointer returned by GPR\_\$INQ\_BITMAP\_POINTER), the program can access only one plane at a time. This is unlike access to multi-plane memory bitmaps, in which the first scan line of a plane immediately follows the last scan line of the previous plane in virtual memory, or access to bitmaps stored in bitmap files where bytes\_per\_section specifies the address difference between planes. Therefore, a program must use GPR\_\$REMAP\_COLOR\_MEMORY to establish which plane of color display memory will be accessible through the "storage\_ptr" returned by GPR\_\$INQ\_BITMAP\_POINTER.

**GPR\_\$REMAP\_COLOR\_MEMORY\_1**

Defines the plane in hidden color display memory for which a pointer is returned when GPR\_INQ\_BITMAP\_POINTER is used. This allows direct access to a single plane of color display memory.

**FORMAT**

GPR\_\$REMAP\_COLOR\_MEMORY\_1 (plane, status)

**INPUT PARAMETERS****plane**

The plane in hidden color display memory in GPR\_\$PLANE\_T. This is a 2-byte integer. A pointer can be returned to the plane using GPR\_\$INQ\_BITMAP\_POINTER. Valid values are 0 - 7.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$REMAP\_COLOR\_MEMORY\_1 allows access to the normally hidden frame 1 of color display memory. GPR\_\$REMAP\_COLOR\_MEMORY allows access to frame 0.

GPR\_\$REMAP\_COLOR\_MEMORY\_1 returns an error on the following machine models: DN570/570A/580 and DN3000.

GPR\_\$REPLICATE\_FONT

GPR\_\$REPLICATE\_FONT

Creates and loads a modifiable copy of a font.

## FORMAT

GPR\_\$REPLICATE\_FONT (font\_id, repli\_font\_id, status)

## INPUT PARAMETERS

**font\_id**

Identifier of the original text font. This is a 2-byte integer.

## OUTPUT PARAMETERS

**repl\_font\_id**

Identifier of the copied text font. This is a 2-byte integer.

**status**

Completion status, in STATUS\_\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To use routines which change fonts, you must first call GPR\_\$REPLICATE\_FONT to create a modifiable copy of a font. The font-modifying routines include GPR\_\$SET\_CHARACTER\_WIDTH, GPR\_\$SET\_HORIZONTAL\_SPACING, and GPR\_\$SET\_SPACE\_SIZE. These calls change only the local copy of the font. If you unload a font and reload it, the font is reset to the values in the font file.

**GPR\_\$SELECT\_COLOR\_FRAME**

Selects whether frame 0 or frame 1 of color display memory is visible.

**FORMAT**

GPR\_\$SELECT\_COLOR\_FRAME (frame, status)

**INPUT PARAMETERS****frame**

This is a 2-byte integer. Denotes which frame is to be visible. Possible values are zero or one. Normally, frame 0 is visible.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$SELECT\_COLOR\_FRAME returns an error if any value other than 0 is entered on the following models: DN570/570A/580 and DN3000.

GPR\_\$SET\_ACQ\_TIME\_OUT

GPR\_\$SET\_ACQ\_TIME\_OUT

Establishes the length of time the display will be acquired.

## FORMAT

GPR\_\$SET\_ACQ\_TIME\_OUT (timeout, status)

## INPUT PARAMETERS

### timeout

The maximum real time, in TIME\_\$CLOCK\_T format, for which the program can acquire the display.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

If the program has not released the display when the time-out expires and another process (for example, the Display Manager) needs the display, an acquire time-out fault (SMD\_\$ACQUIRE\_TIMEOUT) is generated in the user process. The acquire time-out fault is a warning fault that the program can intercept with a cleanup handler or static fault handler. If the program does not release the display within a few seconds of the acquire timeout fault, a second fault occurs (with the status code FAULT\_\$QUIT) and the program loses control of the display.

If this routine is not called, the default time-out value is one minute.

**GPR\_\$SET\_ATTRIBUTE\_BLOCK**

Associates an attribute block with the current bitmap.

**FORMAT**

GPR\_\$SET\_ATTRIBUTE\_BLOCK (attrib\_block\_desc, status)

**INPUT PARAMETERS****attrib\_block\_desc**

Descriptor of the attribute block, in GPR\_\$ATTRIBUTE\_DESC\_T format. This is a 4-byte integer.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To allocate and deallocate attribute blocks, use GPR\_\$ALLOCATE\_ATTRIBUTE\_BLOCK and GPR\_\$DEALLOCATE\_ATTRIBUTE\_BLOCK.

To request the descriptor of the current bitmap's attribute block, use GPR\_\$ATTRIBUTE\_BLOCK.

This routine may release and reacquire the display if the events enabled in the current and new attribute blocks are different.

GPR\_\$SET\_AUTO\_REFRESH

GPR\_\$SET\_AUTO\_REFRESH

Directs the Display Manager to refresh the window automatically.

## FORMAT

GPR\_\$SET\_AUTO\_REFRESH (auto\_refresh, status)

## INPUT PARAMETERS

### auto\_refresh

A Boolean value that indicates whether or not the Display Manager will automatically refresh the application's window. A value of true means that auto-refresh is enabled; a value of false (the default) means that auto-refresh is disabled.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

Automatic refresh of windows can affect system performance and reduce the amount of disk space available, especially if the application's windows are large.

As an alternative, the application program can also provide procedures that refresh the screen and hidden display. See the routine GPR\_\$SET\_REFRESH\_ENTRY.

GPR\_\$AUTO\_REFRESH implicitly releases and reacquires the display in order to communicate with the Display Manager.

This routine applies to the current bitmap. When a program changes attribute blocks for a bitmap during a graphics session, the auto refresh flag is lost unless you set it for the new attribute block.

**GPR\_\$SET\_BITMAP**

Establishes a bitmap as the current bitmap for subsequent operations.

**FORMAT**

GPR\_\$SET\_BITMAP (bitmap\_desc, status)

**INPUT PARAMETERS****bitmap\_desc**

A unique bitmap descriptor, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

The program can obtain the bitmap descriptor by using GPR\_\$INQ\_BITMAP.

After a bitmap is established using GPR\_\$SET\_BITMAP or GPR\_\$INIT, it is called the "current bitmap."

GPR\_\$SET\_BITMAP\_DIMENSIONS

GPR\_\$SET\_BITMAP\_DIMENSIONS

Modifies the size and the number of planes of a bitmap.

## FORMAT

GPR\_\$SET\_BITMAP\_DIMENSIONS (bitmap\_desc, size, hi\_plane\_id, status)

## INPUT PARAMETERS

### bitmap\_desc

The descriptor of the bitmap, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

### size

New width and height of the bitmap, in GPR\_\$OFFSET\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

### hi\_plane\_id

The new identifier of the bitmap's highest plane, in GPR\_\$PLANE\_T format. This is a 2-byte integer.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

A program can use this call to change the size of a bitmap after the bitmap has been created. This is useful if the program wishes to restrict itself to an upper-left subset of the original bitmap or to use hidden memory on a borrowed display.

In direct mode when you allocate a bitmap, you request a size. You may get a smaller size if the Display Manager window is smaller than the size you requested. These restrictions apply to resizing bitmaps. Any bitmap can be shrunk from its original dimensions in x, y or the highest plane. Once the bitmap has been shrunk, it can grow up to its requested size. The maximum allowed sizes for x, y and the highest plane for the various DOMAIN displays are given in the following table.

	max X	max Y	max high plane
Monochromatic display (either portrait or landscape)	1024	1024	0
Color display--Interactive format			
4-bit pixels	1024	2048	3
8-bit pixels	1024	2048	7

If a program uses hidden display memory, it must be careful not to modify areas that are being used to store fill constants or text fonts. The following areas may be used by these functions on the various DOMAIN displays.

**Fill constants:**

Both monochromatic displays:  $800 \leq X \leq 1023$  and  $Y = 1023$ .

Color displays: none.

**Stand-alone font:**

Monochromatic portrait display:  $800 \leq X \leq 1023$  and  $0 \leq Y \leq 39$ .

Monochromatic landscape display:  $800 \leq X \leq 1023$  and  $983 \leq Y \leq 1022$ .

Color displays: same as monochromatic portrait display, plane 0 only, Y offset by 1024.

**User text fonts:** (only if text fonts are loaded)

Monochromatic portrait display:  $800 \leq X \leq 1023$  and  $40 \leq Y \leq 1022$ , allocated from top to bottom.

Monochromatic landscape display:  $0 \leq X \leq 1023$  and  $800 \leq Y \leq 1023$ , in columns 224 bits wide, allocated top to bottom and left to right.

Color displays: same as monochromatic portrait display, plane 0 only, Y offset by 1024.

Note that these areas may move, grow or shrink in future DOMAIN software releases. Therefore, only limited use should be made of hidden display memory in conjunction with text or cursor operations.

GPR\_\$SET\_BITMAP\_FILE\_COLOR\_MAP

GPR\_\$SET\_BITMAP\_FILE\_COLOR\_MAP

Establishes new values for the external-bitmap color map.

## FORMAT

GPR\_\$SET\_BITMAP\_FILE\_COLOR\_MAP (bitmap, start, entries, color, status)

## INPUT PARAMETERS

### bitmap

The bitmap descriptor for the bitmap file in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

### start

The index of the first entry to be modified. This is a 2-byte integer.

### entries

The number of consecutive entries to be modified. This is a 2-byte integer.

### color

The color values in UNIV GPR\_\$COLOR\_VECTOR\_T format. This is an array of long integers (4-byte integers).

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

Each external bitmap is allocated its own color map. The external bitmap's color map is copied into the system color map whenever the external bitmap becomes the current bitmap.

You can inquire or change the values of the external bitmap's color map without making the external bitmap current.

For the monochromatic display, the default start-index is 0. The value of entries is 2, and the color values are GPR\_\$BLACK and GPR\_\$WHITE. Dark has the value GPR\_\$BLACK, and bright has the value GPR\_\$WHITE. A program can use this routine to redefine the pixel values corresponding to bright and dark intensity.

For the monochromatic display, if the program provides fewer than two values, or if the first two values are the same (both black or both white), the routine returns an error.

Use GPR\_\$INQ\_BITMAP\_FILE\_COLOR\_MAP to return the values of an external-bitmap's color map.

**GPR\_\$SET\_CHARACTER\_WIDTH**

Specifies the width of the specified character in the specified font.

**FORMAT**

GPR\_\$SET\_CHARACTER\_WIDTH (font\_id, character, width, status)

**INPUT PARAMETERS****font\_id**

Identifier of the text font. This is a 2-byte integer.

**character**

The specified character. This is a character variable.

**width**

The width parameter of the specified character. This is a 2-byte integer. Possible values are -127 to 127.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To retrieve a character's width, use GPR\_\$INQ\_CHARACTER\_WIDTH.

The initial character widths are defined in the font file.

To use routines which change fonts, you must first call GPR\_\$REPLICATE\_FONT to create a modifiable copy of a font. The font-modifying routines include GPR\_\$SET\_CHARACTER\_WIDTH, GPR\_\$SET\_HORIZONTAL\_SPACING, and GPR\_\$SET\_SPACE\_SIZE. These calls change only the local copy of the font. If you unload a font and reload it, the font is reset to the values in the font file.

GPR\_\$SET\_CLIP\_WINDOW

GPR\_\$SET\_CLIP\_WINDOW

Changes the clipping window for the current bitmap.

## FORMAT

GPR\_\$SET\_CLIP\_WINDOW (window, status)

## INPUT PARAMETERS

### window

The new clipping window, in GPR\_\$WINDOW\_T format. This data type is 8 bytes long. See GPR Data Types section for more information.




Figure GPR-4 Clipping Window Origin, Width, Height

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

The default clip window is the entire bitmap.

In direct mode, the clip window and coordinate origin are relative to the the upper left-hand corner of the window.

A clip window cannot be made larger than the dimensions specified for a bitmap. For applications that run in windows that are dynamically enlarged, specify the size parameter of GPR\_\$INIT to be the size of the display. In this way, the clip rectangle will automatically be enlarged with the window whenever the window is enlarged.

Pixels outside the clip window in the current bitmap are not modified by subsequent operations.

To enable the clip window, use GPR\_\$SET\_CLIPPING\_ACTIVE.

To request the dimensions of the current clip window, use GPR\_\$INQ\_CONSTRAINTS.

This call is not allowed on the bitmap corresponding to the Display Manager frame.

GPR\_\$SET\_CLIPPING\_ACTIVE

GPR\_\$SET\_CLIPPING\_ACTIVE

Enables/disables a clipping window for the current bitmap.

## FORMAT

GPR\_\$SET\_CLIPPING\_ACTIVE (active, status)

## INPUT PARAMETERS

### active

A Boolean (logical) value which specifies whether or not to enable the clipping window. Set this value to true to enable the clipping window; set it to false to disable the clipping window.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To specify a clipping window, use the routine GPR\_\$SET\_CLIP\_WINDOW.

Initially, in borrow-display, the clip window is disabled. In direct mode, the clip window is enabled and clipped to the size of the window. Clipping cannot be enabled in a bitmap corresponding to a Display Manager frame.

To inquire whether the clip window is enabled, use GPR\_\$INQ\_CONSTRAINTS.

**GPR\_\$SET\_COLOR\_MAP**

Establishes new values for the color map.

**FORMAT**

GPR\_\$SET\_COLOR\_MAP (start\_index, n\_entries, values, status)

**INPUT PARAMETERS****start\_index**

Index of first color value entry, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer.

**n\_entries**

Number of entries. This is a 2-byte integer. Valid values are:

- |         |  |
|---------|--|
| 2       | For monochromatic displays                         |
| 1 - 16  | For color displays in 4-bit pixel format           |
| 1 - 256 | For color displays in 8-bit or 24-bit pixel format |

**values**

Color value entries, in GPR\_\$COLOR\_VECTOR\_T format. This is a 256-element array of 4-byte integers.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

For the monochromatic display, the default start-index is 0, n-entries is 2, and the values are GPR\_\$BLACK and GPR\_\$WHITE. Dark has the value GPR\_\$BLACK, and bright has the value GPR\_\$WHITE. A program can use this routine to redefine the pixel values corresponding to bright and dark intensity.

For the monochromatic display, if the program provides fewer than two values, or if the first two values are the same (both black or both white), the routine returns an error.

On monochromatic devices, use GPR\_\$INQ\_DISP\_CHARACTERISTICS to determine whether the color map is simulated or in hardware. See the datatype gpr\_\$disp\_char\_t in Chapter 1 of this manual for more information.

On a monochrome system that uses a simulated color map pixels which are white have a pixel value of 1 and pixels that are black have a pixel value of 0, regardless of any calls to GPR\_\$SET\_COLOR\_MAP. In other words, the pixel value specifies the color of the pixel: the pixel value is not used as an index into the color map. On systems that have the

GPR\_\$SET\_COLOR\_MAP

color map in hardware, the pixel value is used as an index into the color map. The color of the pixel is determined by the color value in the color map.

In direct mode, you must acquire the display before establishing new values for the color map.

To retrieve the current color map, use GPR\_\$INQ\_COLOR\_MAP.

**GPR\_\$SET\_COORDINATE\_ORIGIN**

Establishes x- and y-offsets to add to all x- and y-coordinates used for move, draw, text, fill, and BLT operations on the current bitmap.

**FORMAT**

GPR\_\$SET\_COORDINATE\_ORIGIN (origin, status)

**INPUT PARAMETERS****origin**

The new coordinate origin for the bitmap, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To retrieve the current coordinate origin, use GPR\_\$INQ\_COORDINATE\_ORIGIN.

The default coordinate origin is (0,0).

In direct mode, the clip window and coordinate origin are relative to the the upper left-hand corner of the window.

This routine may not be used on a bitmap corresponding to a Display Manager frame.

GPR\_\$\$SET\_CURSOR\_ACTIVE

GPR\_\$\$SET\_CURSOR\_ACTIVE

Specifies whether the cursor is displayed.

## FORMAT

GPR\_\$\$SET\_CURSOR\_ACTIVE (active, status)

## INPUT PARAMETERS

### active

Boolean (logical) value that specifies whether to display the cursor. Set the parameter to true to display the cursor; set it to false if you do not want to display the cursor.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

Initially, the cursor is not displayed.

To inquire whether the cursor is currently displayed, use GPR\_\$\$INQ\_CURSOR.

A program may call this routine only while operating in borrow-display or direct mode.

**GPR\_\$SET\_CURSOR\_ORIGIN**

Defines one of the cursor's pixels as the cursor origin.

**FORMAT**

GPR\_\$SET\_CURSOR\_ORIGIN (origin, status)

**INPUT PARAMETERS****origin**

The position of one cursor pixel (the origin) relative to the entire cursor, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

A program uses GPR\_\$SET\_CURSOR\_ORIGIN to designate one pixel in the cursor pattern as the cursor origin. Thereafter, when the cursor is moved, the pixel designated as the cursor origin moves to the screen coordinate designated as the cursor position.

The default cursor origin depends on the default cursor size, which depends on the size of the Display Manager's standard font.

To inquire about the current cursor origin, pattern, position and whether the cursor is enabled, use GPR\_\$INQ\_CURSOR.

GPR\_\$SET\_CURSOR\_PATTERN

GPR\_\$SET\_CURSOR\_PATTERN

Loads a cursor pattern.

## FORMAT

GPR\_\$SET\_CURSOR\_PATTERN (cursor\_pattern, status)

## INPUT PARAMETERS

### cursor\_pattern

The descriptor of the bitmap which contains the cursor pattern, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

Initially, the cursor pattern is a rectangle, which varies in size according to the size of the Display Manager's standard font. A program can use GPR\_\$SET\_CURSOR\_PATTERN to redefine the cursor pattern. The bitmap that represents the cursor pattern consists of one plane, which is a maximum of 16x16 pixels in size.

To inquire about the current cursor pattern, use GPR\_\$INQ\_CURSOR.

**GPR\_\$SET\_CURSOR\_POSITION**

Establishes a position on the screen for display of the cursor.

**FORMAT**

GPR\_\$SET\_CURSOR\_POSITION (position, status)

**INPUT PARAMETERS****position**

Screen coordinate position for display of the cursor, in GPR\_\$POSITION\_T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

The first element is the cursor position's x-coordinate; the second element is the y-coordinate. Coordinate values must be within the limits of the display in use, as follows:

	X	Y
<hr/>		
Borrowed Display:		
Monochromatic Portrait:	0 - 799	0 - 1023
Monochromatic Landscape:	0 - 1023	0 - 799
Color:	0 - 1023	0 - 1023
Color : 550	0 - 1023	0 - 799
Display Manager Frame:	0 - 32767	0 - 32767

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Cursor position: If a program calls this routine when in borrow-display mode, the x- and y-coordinates represent an absolute position on the screen. If a program calls this routine when the cursor is inside a frame of a Display Manager pad, the x- and y-coordinates are offsets from the top left corner of the frame.

## GPR\_\$SET\_CURSOR\_POSITION

If the coordinate position would cause any part of the cursor to be outside the screen or frame, the cursor moves only as far as the edge of the screen. The cursor is neither clipped nor made to disappear.

To request the current cursor position, use GPR\_\$INQ\_CURSOR.

In a Display Manager frame, this routine moves the cursor only if the cursor is in the window viewing this frame when the call is issued. If not, a "next window" command which moves to that window will move the cursor to its new position.

**GPR\_\$SET\_DRAW\_VALUE**

Specifies the color/intensity value to use to draw lines.

**FORMAT**

GPR\_\$SET\_DRAW\_VALUE (index, status)

**INPUT PARAMETERS****index**

The color map index that indicates the current color/intensity value used for drawing lines, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer. Valid values are:

- 0 - 1                   For monochromatic displays
- 0 - 15                 For color displays in 4-bit pixel format
- 0 - 255                For color displays in 8-bit or 24-bit pixel format
- 2                     For all displays. This specifies using the color/intensity value of the bitmap background as the line drawing value. For borrowed displays and memory bitmaps, the fill background is always zero. For Display Manager frames, this is the pixel value in use for the window background.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To retrieve the current draw value, use GPR\_\$INQ\_DRAW\_VALUE.

The default draw value is 1.

For monochromatic displays, only the low-order bit of the draw value is considered, because monochromatic displays have only one plane.

For color displays in 4-bit pixel format, only the four lowest-order bits of the draw value are considered, because these displays have four planes.

GPR\_\$SET\_FILL\_BACKGROUND\_VALUE

GPR\_\$SET\_FILL\_BACKGROUND\_VALUE

Specifies the color/intensity value used for drawing the background of tile fills.

## FORMAT

GPR\_\$SET\_FILL\_BACKGROUND\_VALUE (index, status)

## INPUT PARAMETERS

### index

The color map index that indicates the current color/intensity value used for tile fills, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer. Valid values are:

- 0 - 1                For monochromatic displays
- 0 - 15              For color displays in 4-bit pixel format
- 0 - 255             For color displays in 8-bit or 24-bit pixel format
- 1                   For all displays. This specifies that the fill background is transparent; that is, the old values of the pixels are not changed.
- 2                   For all displays. This specifies using the color/intensity value of the bitmap background as the fill background. For borrowed displays and memory bitmaps, the fill background is always zero. For Display Manager frames, this is the pixel value in use for the window background.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To retrieve the current background value, use GPR\_\$INQ\_FILL\_BACKGROUND\_VALUE.

The default fill background value is -2.

This routine defines the background fill value for 1-bit patterns. In all other fill patterns, the values set with this routine are ignored.

**GPR\_\$SET\_FILL\_PATTERN**

Specifies the fill pattern used for the current bitmap.

**FORMAT**

GPR\_\$SET\_FILL\_PATTERN (pattern, scale, status)

**INPUT PARAMETERS****pattern**

The descriptor of the bitmap containing the fill pattern, in GPR\_\$BITMAP\_DESC\_T format. This is a 4-byte integer. See restriction below.

**scale**

The number of times each bit in this pattern is to be replicated before proceeding to the next bit in the pattern. This is a 2-byte integer. See restriction below.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Currently, the tile pattern must be stored in a bitmap that is 32x32 pixels by n planes. The scale factor must be one. Any other pattern size or scale value results in an error.

To retrieve the current fill pattern for the current bitmap, use GPR\_\$INQ\_FILL\_PATTERN.

With a one-plane bitmap as the pattern, the pixel values used are those set by GPR\_\$SET\_FILL\_VALUE and GPR\_\$SET\_FILL\_BACKGROUND\_VALUE. Pixels corresponding to "1" bits of the pattern are drawn in the fill value; pixels corresponding to "0" bits of the pattern are drawn in the fill background value.

With a multiplane bitmap as the pattern, the pixel values used are those contained in the pattern bitmap.

To re-establish solid fills, set the fill pattern descriptor to GPR\_\$NIL\_BITMAP\_DESC.

GPR\_\$SET\_FILL\_VALUE

GPR\_\$SET\_FILL\_VALUE

Specifies the color/intensity value to use to fill circles, rectangles, triangles, and trapezoids.

## FORMAT

GPR\_\$SET\_FILL\_VALUE (index, status)

## INPUT PARAMETERS

### index

The color map index that indicates the current fill color/intensity value, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer. The default fill value is 1. Valid values are:

0 - 1 for monochromatic displays 0 - 15 for color displays in 4-bit pixel format 0 - 255 for color displays in 8-bit or 24-bit pixel format

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To retrieve the current fill value, use GPR\_\$INQ\_FILL\_VALUE.

For monochromatic displays, only the low-order bit of the fill value is considered, because monochromatic displays have only one plane.

For color displays in 4-bit pixel format, only the four lowest-order bits of the fill value are considered, because these displays have four planes.

"Index" is a color map index, not a color value.

**GPR\_\$SET\_HORIZONTAL\_SPACING**

Specifies the parameter for horizontal spacing of the specified font.

**FORMAT**

GPR\_\$SET\_HORIZONTAL\_SPACING (font\_id, horizontal\_spacing, status)

**INPUT PARAMETERS****font\_id**

The identifier of the text font. This is a 2-byte integer.

**horizontal\_spacing**

The horizontal spacing parameter of the specified font. This is a 2-byte integer. Possible values are -127 - 127.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Use GPR\_\$INQ\_HORIZONTAL\_SPACING to retrieve a font's horizontal spacing.

The initial horizontal spacing is defined in the font file.

To use routines which change fonts, you must first call GPR\_\$REPLICATE\_FONT to create a modifiable copy of a font. The font-modifying routines include GPR\_\$SET\_CHARACTER\_WIDTH, GPR\_\$SET\_HORIZONTAL\_SPACING, and GPR\_\$SET\_SPACE\_SIZE. These calls change only the local copy of the font. If you unload a font and reload it, the font is reset to the values in the font file.

Horizontal spacing is the space between each character in a string.

GPR\_\$SET\_IMAGING\_FORMAT

GPR\_\$SET\_IMAGING\_FORMAT

Sets the imaging format of the color display.

## FORMAT

GPR\_\$SET\_IMAGING\_FORMAT (format, status)

## INPUT PARAMETERS

### format

Color format in GPR\_\$IMAGING\_FORMAT\_T. This is a two-byte integer. Valid values are:

GPR\_\$INTERACTIVE

Either two- or three-board

GPR\_\$IMAGING\_1024x1024x8

Two-board only

GPR\_\$IMAGING\_512x512x24

Three-board only

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To retrieve the current imaging format, use GPR\_\$INQ\_IMAGING\_FORMAT.

To use GPR\_\$SET\_IMAGING\_FORMAT, you must be in borrow display mode and be using a color node.

Imaging formats support only limited GPR operations - displaying pixel data and changing the color map. Other functions return error messages.

1024x1024x8 imaging format is not supported on a three-board system because it offers no advantages over interactive formats.

GPR\_\$SET\_IMAGING\_FORMAT accepts only GPR\_\$INTERACTIVE on the following models: DN570/570A/580 and DN3000.

**GPR\_\$SET\_INPUT\_SID**

Specifies the input pad from which graphics input is to be taken.

**FORMAT**

GPR\_\$SET\_INPUT\_SID (stream\_id, status)

**INPUT PARAMETERS****stream\_id**

The stream-id that GPR software will use for input in frame mode, in STREAM\_\$ID\_T format. The stream must be a Display Manager input pad.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Programs use this call only when they call input routines in frame mode (GPR\_\$EVENT\_WAIT and GPR\_\$COND\_EVENT\_WAIT).

If this routine is not called, the default stream ID is STREAM\_\$STDIN (a stream id of zero).

To work properly, the input pad must be the pad associated with the transcript pad passed to GPR\_\$INIT. STREAM\_\$STDIN is associated with STREAM\_\$STDOUT in this way in a normal Shell process window. Other process input pads derive their association from the PAD\_\$CREATE call that created them.

GPR\_\$SET\_LINE\_PATTERN

GPR\_\$SET\_LINE\_PATTERN

Specifies the pattern to use in drawing lines.

## FORMAT

GPR\_\$SET\_LINE\_PATTERN (repeat\_count, pattern, length, status)

## INPUT PARAMETERS

### repeat\_count

The replication factor for each bit in the pattern. This is a 2-byte integer. Specifying a value of 0 results in a solid line.

### pattern

The bit pattern, left justified, in GPR\_\$LINE\_PATTERN\_T format. This is a four-element array of 2-byte integers.

### length

The length of the pattern in bits. This is a 2-byte integer in the range of 0 to 64. Specifying a value of 0 results in a solid line.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

GPR\_\$LINE, GPR\_\$POLYLINE, GPR\_\$MULTILINE use the pattern/style most recently defined by either GPR\_\$SET\_LINE\_PATTERN or GPR\_\$SET\_LINestyle. The actual bits in the integers define the line pattern. You should set the first bit in the pattern; otherwise, the vectors you draw will not show the beginning of the line correctly.

Specifying the value of 0 for either repeat or length results in a solid line.

You may also set a line pattern with GPR\_\$SET\_LINestyle. The pattern is defined by the parameter GPR\_\$DOTTED.

Within each element of the bit pattern, the bits are used in order of decreasing significance. This starts with the most significant bit of entry 1 down to the least significant of entry 4.

Use GPR\_\$INQ\_LINE\_PATTERN to retrieve the current line pattern. This routine returns the pattern set explicitly with GPR\_\$SET\_LINE\_PATTERN or set implicitly with GPR\_\$SET\_LINestyle.

**GPR\_\$SET\_LINestyle**

Sets the line-style attribute of the current bitmap.

**FORMAT**

GPR\_\$SET\_LINestyle (style, scale, status)

**INPUT PARAMETERS****style**

The style of line, in GPR\_\$LINestyle\_T format. This is a 2-byte integer. Specify only one of the following values:

GPR\_\$SOLID For solid lines,

GPR\_\$DOTTED  
For dotted lines

**scale**

The scale factor for dashes if the style parameter is GPR\_\$DOTTED. This is a 2-byte integer.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

When the line-style attribute is GPR\_\$DOTTED, lines are drawn in dashes. The scale factor determines the number of pixels in each dash and in each space between the dashes.

For greater flexibility in setting line styles, use GPR\_\$SET\_LINE\_PATTERN.

Use GPR\_\$INQ\_LINestyle to retrieve the current line-style attribute.

GPR\_\$SET\_OBSCURED\_OPT

GPR\_\$SET\_OBSCURED\_OPT

Establishes the action to be taken when a window to be acquired is obscured.

## FORMAT

GPR\_\$SET\_OBSCURED\_OPT (if\_obscured, status)

## INPUT PARAMETERS

### if\_obscured

If the window to be acquired by GPR\_\$ACQUIRE\_DISPLAY is obscured, this argument specifies, in GPR\_\$OBSCURED\_OPT\_T format, the action to be taken. This is a 2-byte integer. Specify only one of the following values:

GPR\_\$POP\_IF\_OBS

Pop the window.

GPR\_\$ERR\_IF\_OBS

Return an error and do not acquire the display.

GPR\_\$BLOCK\_IF\_OBS

Block display acquisition until the window is popped.

GPR\_\$OK\_IF\_OBS

Acquire the display even though the window is obscured.

GPR\_\$INPUT\_OK\_IF\_OBS

Blocks display acquisitions, but allows input into the window even if the window is obscured.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

If this routine is not called, the action to be taken defaults to GPR\_\$ERR\_IF\_OBS.

These options apply whenever the display is acquired, either by GPR\_\$ACQUIRE\_DISPLAY or implicitly by GPR\_\$EVENT\_WAIT.

If the program specifies the option GPR\_\$ERR\_IF\_OBS, it must check the status code returned from GPR\_\$ACQUIRE\_DISPLAY or GPR\_\$EVENT\_WAIT before calling any drawing routines.

Use GPR\_\$INQ\_VIS\_LIST to retrieve a list of visible sections of an obscured window.

When a program specifies GPR\_\$OK\_IF\_OBS, the output is performed even when the

window is obscured. To avoid overwriting other Display Manager windows, the program must inquire the visible areas by calling GPR\_\$INQ\_VIS\_LIST and set clipping windows accordingly.

When a program specifies GPR\_INPUT\_OK\_IF\_OBS, the input is performed even when the window is obscured.

The cursor state (cursor pattern and whether the cursor is active) is in effect at all times, even when the display is not acquired. Two exceptions are: when the window is an icon, when the window is in hold mode, and when the window is obscured and GPR\_\$SET\_OBSCURED\_OPT does not specify GPR\_\$INPUT\_OK\_IF\_OBS.

Setting if\_obscured to GPR\_\$BLOCK\_IF\_OBS or GPR\_\$OK\_IF\_OBS has an effect on the refresh procedure specified by GPR\_\$SET\_REFRESH\_ENTRY.

Setting if\_obscured to GPR\_\$BLOCK\_IF\_OBS causes only the hidden display memory refresh routine to be called.

Setting if\_obscured to GPR\_\$OK\_IF\_OBS causes both the hidden display memory and display memory refresh routines to be called.

GPR\_\$SET\_PLANE\_MASK

GPR\_\$SET\_PLANE\_MASK

Establishes a plane mask for subsequent write operations.

## FORMAT

GPR\_\$SET\_PLANE\_MASK (mask, status)

## INPUT PARAMETERS

### mask

The plane mask, which specifies which planes to use, in GPR\_\$MASK\_T format. This is a two-byte integer.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

The default mask specifies that all planes are used.

Operations occur only on the planes specified in the mask. A program can use this routine, for example, to perform raster operations on separate planes or groups of planes in the bitmap.

Using the mask, a program can partition the 8-bit pixels into subunits. For example, the program can use planes 0 - 3 for one picture and planes 4 - 7 for another. Thus, one bitmap may contain two color pictures. This does not, however, increase the number of colors available for one bitmap.

To retrieve the current plane mask, use GPR\_\$INQ\_CONSTRAINTS.

**GPR\_\$SET\_RASTER\_OP**

Specifies a raster operation for the primitives established with GPR\_\$RASTER\_OP\_PRIM\_SET.

**FORMAT**

GPR\_\$SET\_RASTER\_OP (plane\_id, raster\_op, status)

**INPUT PARAMETERS****plane\_id**

Identifier of the bitmap plane involved in the raster operation, in GPR\_\$PLANE\_T format. This is a 2-byte integer. Valid values are zero through the identifier of the bitmap's highest plane. See GPR Data Types section for more information.

**raster\_op**

Raster operation code, in GPR\_\$RASTER\_OP\_T format. This is a 2-byte integer. Possible values are zero through fifteen.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

Use GPR\_\$INQ\_RASTER\_OPS to retrieve the current raster operation for the primitives which are specified by GPR\_\$RASTER\_OP\_PRIM\_SET.

The default raster operation for all primitives is 3.

The following is a list of the op codes and logical functions of the sixteen raster operations and a truth table of the raster operations.

### Raster Operations and Their Functions

Op Code	Logical Function
0	Assign zero to all new destination values.
1	Assign source AND destination to new destination.
2	Assign source AND complement of destination to new destination.
3	Assign all source values to new destination.
4	Assign complement of source AND destination to new destination.
5	Assign all destination values to new destination.
6	Assign source EXCLUSIVE OR destination to new destination.
7	Assign source OR destination to new destination.
8	Assign complement of source AND complement of destination to new destination.
9	Assign source EQUIVALENCE destination to new destination.
10	Assign complement of destination to new destination.
11	Assign source OR complement of destination to new destination.
12	Assign complement of source to new destination.
13	Assign complement of source OR destination to new destination.
14	Assign complement of source OR complement of destination to new destination.
15	Assign 1 to all new destination values.

### Raster Operations: Truth Table

Source Bit Value	Destination Bit Value	Resultant Bit Values for the following OP Codes:														
		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14
0	0	0	0	0	0	0	0	0	0	1	1	1	1	1	1	1
0	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1
1	0	0	0	1	1	0	0	1	1	0	0	1	1	0	0	1
1	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	1

**GPR\_\$SET\_REFRESH\_ENTRY**

Specifies the entry points of application-supplied procedures that refresh the displayed image in a direct window and hidden display memory.

**FORMAT**

GPR\_\$SET\_REFRESH\_ENTRY (window\_procedure, disp\_mem\_procedure, status)

**INPUT PARAMETERS****window\_procedure**

Entry point for the application-supplied procedure that refreshes the Display Manager window, in GPR\_\$RWIN\_PR\_T format. This is a pointer to a procedure.

**disp\_mem\_procedure**

Entry point for the application-supplied procedure that refreshes the application's hidden display memory, in GPR\_\$RHDM\_PR\_T format. This is a pointer to a procedure.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

The Display Manager determines when the window needs to be redrawn based on the amount of activity the user generates on the screen. When a redrawing operation is necessary, the Display Manager calls the application-supplied procedure the next time that the application acquires the display. Two input parameters are passed to the window refresh procedure:

Callback of refresh routines are effected by your obscured option. See GPR\_\$SET\_OBSCURED\_OPT for more information.

- unobscured -- When false, this Boolean value indicates that the window is obscured.
- position\_changed -- When true, this Boolean value indicates that the window has moved or grown since the display was released.

The *Programming With General System Calls* describes the pointer data type.

See *Programming With DOMAIN Graphic Primitives* for an algorithm using procedure pointers.

GPR\_\$SET\_SPACE\_SIZE

GPR\_\$SET\_SPACE\_SIZE

Specifies the size of horizontal spacing for the specified font.

## FORMAT

GPR\_\$SET\_SPACE\_SIZE (font\_id, space\_size, status)

## INPUT PARAMETERS

**font\_id**

Identifier of the text font. This is a 2-byte integer.

**space\_size**

Space size is the number of pixels to skip in the horizontal direction when you include a character that is not in the font. This is a 2-byte integer. Possible values are -127 to 127.

## OUTPUT PARAMETERS

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To retrieve a font's space size, use GPR\_\$INQ\_SPACE\_SIZE.

The initial character widths are defined in the font file.

To use routines which change fonts, you must first call GPR\_\$REPLICATE\_FONT to create a modifiable copy of a font. The font-modifying routines include GPR\_\$SET\_CHARACTER\_WIDTH, GPR\_\$SET\_HORIZONTAL\_SPACING, and GPR\_\$SET\_SPACE\_SIZE. These calls change only the local copy of the font. If you unload a font and reload it, the font is reset to the values in the font file.

The space size is the number of pixels to skip in the horizontal direction when you write a character that is not in the font. Space size is not the size of the space character. To set the size of the space character use GPR\_\$SET\_CHAR\_WIDTH.

**GPR\_\$SET\_TEXT\_BACKGROUND\_VALUE**

Specifies the color/intensity value to use for text background.

**FORMAT**

GPR\_\$SET\_TEXT\_BACKGROUND\_VALUE (index, status)

**INPUT PARAMETERS****index**

The color map index that indicates the current color/intensity value used for the text background, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer. This parameter is an index into a color map; it is not a color value. Valid values are:

- 0 - 1            For monochromatic displays
- 0 - 15         For color displays in 4-bit pixel format
- 0 - 255        For color displays in 8-bit or 24-bit pixel format
- 1             For all displays. This specifies that the text background is transparent; that is, the old values of the pixels are not changed.
- 2             For all displays. This specifies using the color/intensity value of the bitmap background as the text background. For borrowed displays and memory bitmaps, this value is always zero. For Display Manager frames, this is the pixel value in use for the window background.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To retrieve the current text background value, use GPR\_\$INQ\_VALUES.

The default text background value is -2.

For monochromatic displays, only the low-order bit of the text background value is considered, because monochromatic displays have only one plane.

For color displays in 4-bit pixel mode, only the four lowest-order bits of the text background value are considered, because these displays have four planes.

GPR\_\$SET\_TEXT\_FONT

GPR\_\$SET\_TEXT\_FONT

Establishes a new font for subsequent text operations.

## FORMAT

GPR\_\$SET\_TEXT\_FONT (font\_id, status)

## INPUT PARAMETERS

**font\_id**

Identifier of the new text font. This is a 2-byte integer.

## OUTPUT PARAMETERS

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

Obtain the font-id when loading a font with GPR\_\$LOAD\_FONT\_FILE.

To request the identifier of the current font, use GPR\_\$INQ\_TEXT.

There is no default text font. A program must load and set the font.

Call GPR\_\$SET\_TEXT\_FONT for each main memory bitmap. Otherwise, an error is returned (invalid font id).

**GPR\_\$SET\_TEXT\_PATH**

Specifies the direction for writing a line of text.

**FORMAT**

GPR\_\$SET\_TEXT\_PATH (direction, status)

**INPUT PARAMETERS****direction**

The direction used for writing text, in GPR\_\$DIRECTION\_T format. This is a 2-byte integer. Specify only one of the following values:

GPR\_\$UP

GPR\_\$DOWN

GPR\_\$LEFT

GPR\_\$RIGHT

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

To retrieve the current text path, use GPR\_\$INQ\_TEXT\_PATH.

The initial text path is GPR\_\$RIGHT.

GPR\_\$SET\_TEXT\_VALUE

GPR\_\$SET\_TEXT\_VALUE

Specifies the color/intensity value to use for writing text.

## FORMAT

GPR\_\$SET\_TEXT\_VALUE (index, status)

## INPUT PARAMETERS

### index

The color map index that indicates the current color/intensity value used for writing text, in GPR\_\$PIXEL\_VALUE\_T format. This is a 4-byte integer. The valid values are listed below:

- |         |  |
|---------|--|
| 0 - 1   | For monochromatic displays                         |
| 0 - 15  | For color displays in 4-bit pixel format           |
| 0 - 255 | For color displays in 8-bit or 24-bit pixel format |

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

To retrieve the current text value, use GPR\_\$INQ\_VALUES.

The default text value is 1 for borrowed displays, memory bitmaps, and Display Manager frames on monochromatic displays; 0 for Display Manager frames on color displays.

For monochromatic displays, only the low-order bit of the text value is considered, because monochromatic displays have only one plane.

For color displays in 4-bit pixel format, only the four lowest-order bits of the text value are considered, because these displays have four planes.

The color specification parameter is a color map index, not a color value.

**GPR\_\$SET\_TRIANGLE\_FILL\_CRITERIA**

Sets the filling criteria used with polygons that are rendered directly (decomposition technique set to render exact) or polygons that are decomposed into triangles before being rendered.

**FORMAT**

GPR\_\$SET\_TRIANGLE\_FILL\_CRITERIA(fill\_crit, status)

**INPUT PARAMETERS****fill\_crit**

Sets the filling criteria. This is a 2-byte integer. Possible values for this parameter are:

**GPR\_\$PARITY** Provides a means for filling polygons decomposed into triangles using an odd parity scheme. Regions filled in these polygons will match regions filled in polygons decomposed into trapezoids.

**GPR\_\$NONZERO**

Provides a means for filling all non-zero regions of a polygon.

**GPR\_\$SPECIFIC**

Provides a means for filling specific regions of a polygon. This is done by specifying a winding number. The only restriction is that regions with a winding number of zero cannot be filled.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

This call allows you to choose how polygons decomposed into triangles or polygons that are rendered without being decomposed (decomposition technique set to render exact) are filled.

Use GPR\_\$PGON\_DECOMP\_TECHNIQUE to choose a mode which controls the algorithm used to decompose polygons into trapezoids or non-overlapping triangles.

GPR\_\$SET\_WINDOW\_ID

GPR\_\$SET\_WINDOW\_ID

Establishes the character that identifies the current bitmap's window.

## FORMAT

GPR\_\$SET\_WINDOW\_ID (character, status)

## INPUT PARAMETERS

### character

The character that identifies the current bitmaps's window. This is a character variable.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

This character is returned by GPR\_\$EVENT\_WAIT and GPR\_\$COND\_EVENT\_WAIT when they return GPR\_\$ENTERED\_WINDOW events. The character indicates which window was entered.

The character 'A' is the default value of the window identification for all windows.

You may assign the same character to more than one window. However, if you do so, you cannot distinguish input from the two windows.

**GPR\_\$\$SPLINE\_CUBIC\_P**

Draws a parametric cubic spline through the control points.

**FORMAT**

GPR\_\$\$SPLINE\_CUBIC\_P (x, y, npositions, status)

**INPUT PARAMETERS****x**

List of the x-coordinates of all the successive positions.

GPR\_\$\$COORDINATE\_ARRAY\_T, a ten-element array of 2-byte integers, is an example of such an array. The actual array can have up to 32767 elements. The values must be within the bitmap limits, unless clipping is enabled.

**y**

List of the y-coordinates of all the successive positions.

GPR\_\$\$COORDINATE\_ARRAY\_T, a ten-element array of 2-byte integers, is an example of such an array. The actual array can have up to 32767 elements. The values must be within the bitmap limits, unless clipping is enabled.

**npositions**

Number of coordinate positions. This is a 2-byte integer in the range 1 - 32767.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$\$SPLINE\_CUBIC\_P draws a smooth curve starting from the current position, through each of the specified points.

After the spline is drawn, the last point becomes the current position.

The specified coordinates are added to the corresponding elements of the coordinate origin for the current bitmap. The resultant coordinate positions are the points through which the spline is drawn.

An error is returned if any two consecutive points are equal.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

GPR\_\$SPLINE\_CUBIC\_X

GPR\_\$SPLINE\_CUBIC\_X

Draws a cubic spline as a function of x through the control points.

## FORMAT

GPR\_\$SPLINE\_CUBIC\_X (x, y, npositions, status)

## INPUT PARAMETERS

**x**

List of the x-coordinates of all the successive positions.

GPR\_\$COORDINATE\_ARRAY\_T, a ten-element array of 2-byte integers, is an example of such an array. The actual array can have up to 32767 elements. The values must be within the bitmap limits, unless clipping is enabled.

**y**

List of the y-coordinates of all the successive positions.

GPR\_\$COORDINATE\_ARRAY\_T, a ten-element array of 2-byte integers, is an example of such an array. The actual array can have up to 32767 elements. The values must be within the bitmap limits, unless clipping is enabled.

**npositions**

Number of coordinate positions. This is a 2-byte integer in the range 1 - 32767.

## OUTPUT PARAMETERS

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

GPR\_\$SPLINE\_CUBIC\_X draws a smooth curve starting from the current position and through each of the specified points.

After the spline is drawn, the last point becomes the current position.

The specified coordinates are added to the corresponding elements of the coordinate origin for the current bitmap. The resultant coordinate positions are the points through which the spline is drawn.

An error is returned if any x-coordinate is less than or equal to a previous x-coordinate. The x-coordinate array must be sorted into increasing order.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

**GPR\_\$\$SPLINE\_CUBIC\_Y**

Draws a cubic spline as a function of y through the control points.

**FORMAT**

GPR\_\$\$SPLINE\_CUBIC\_Y (x, y, npositions, status)

**INPUT PARAMETERS****x**

List of the x-coordinates of all the successive positions.

GPR\_\$\$COORDINATE\_ARRAY\_T, a ten-element array of 2-byte integers, is an example of such an array. The actual array can have up to 32767 elements. The values must be within the bitmap limits, unless clipping is enabled.

**y**

List of the y-coordinates of all the successive positions.

GPR\_\$\$COORDINATE\_ARRAY\_T, a ten-element array of 2-byte integers, is an example of such an array. The actual array can have up to 32767 elements. The values must be within the bitmap limits, unless clipping is enabled.

**npositions**

Number of coordinate positions. This is a 2-byte integer in the range 1 - 32767.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$\$SPLINE\_CUBIC\_Y draws a smooth curve starting from the current position and through each of the specified points.

After the spline is drawn, the last point becomes the current position.

The specified coordinates are added to the corresponding elements of the coordinate origin for the current bitmap. The resultant coordinate positions are the points through which the spline is drawn.

An error is returned if any y-coordinate is less than or equal to a previous y-coordinate. The y-coordinate array must be sorted into increasing order.

When you have clipping enabled, you can specify coordinates outside the bitmap limits. With clipping disabled, specifying coordinates outside the bitmap limits results in an error.

GPR\_ \$START\_PGON

GPR\_ \$START\_PGON

Defines the starting position of a polygon.

## FORMAT

GPR\_ \$START\_PGON (x, y, status)

## INPUT PARAMETERS

x

The x-coordinate, in GPR\_ \$COORDINATE\_T format. This is a 2-byte integer. Its values must be within bitmap limits, unless clipping is enabled.

y

The y-coordinate, in GPR\_ \$COORDINATE\_T format. This is a 2-byte integer. Its values must be within bitmap limits, unless clipping is enabled.

## OUTPUT PARAMETERS

status

Completion status, in STATUS\_ \$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

GPR\_ \$START\_PGON defines the first point in a polygon boundary. This routine is used in conjunction with GPR\_ \$PGON\_POLYLINE to define a connected series of edges composing one closed loop of a polygon's boundary. To see the polygon, you must fill it using either GPR\_ \$CLOSE\_FILL\_PGON or GPR\_ \$CLOSE\_RETURN\_PGON and GPR\_ \$MULTITRAPEZOID.

This routine closes any previously open loop of edges by connecting its last endpoint to its first endpoint with an edge. Then, the routine starts the new loop.

**GPR\_ \$TERMINATE**

Terminates the graphics primitives package.

**FORMAT**

GPR\_ \$TERMINATE (delete\_display, status)

**INPUT PARAMETERS****delete\_display**

A Boolean (logical) value which specifies whether to delete the frame of the Display Manager pad. If the program has operated in a Display Manager frame and needs to delete the frame at the end of a graphics session, set this value to true. If the program needs to close, but not delete the frame, set this value to false. If the program has not used a Display Manager frame, the value is ignored.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_ \$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_ \$TERMINATE deletes the frame regardless of the value of the delete-display argument in the following case. A BLT operation from a memory bitmap has been done to a Display Manager frame since the last time GPR\_ \$CLEAR was called for the frame.

No GPR information is valid after calling GPR\_ \$TERMINATE.

GPR\_\$TEXT

GPR\_\$TEXT

Writes text to the current bitmap, beginning at the current position.

## FORMAT

GPR\_\$TEXT (string, string\_length, status)

## INPUT PARAMETERS

### string

The string to write, in GPR\_\$STRING\_T format. This is an array of up to 256 characters.

### string\_length

Number of characters in the string. This is a 2-byte integer. The maximum value is 256.

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

GPR\_\$TEXT always clips to the edge of the bitmap, regardless of whether clipping is enabled.

GPR\_\$TEXT writes the characters in the current font which correspond to the ASCII values of the characters in the specified string. If the font does not have a character which corresponds to a character in the string, GPR\_\$TEXT leaves a space. The size of the space is set by GPR\_\$SET\_SPACE\_SIZE.

Text is written at the current position. The origin of the first character of the character string is placed at the current position. Generally, the origin of the character is at the bottom left, excluding descenders of the character.

Upon completion of the GPR\_\$TEXT routine, the current position is updated to the coordinate position where a next character would be written. This is the case even if the string is partly or completely clipped. However, the current position always remains within the boundaries of the bitmap.

**GPR\_\$TRAPEZOID**

Draws and fills a trapezoid.

**FORMAT**

GPR\_\$TRAPEZOID (trapezoid, status)

**INPUT PARAMETERS****trapezoid**

Trapezoid in GPR\_\$TRAP\_T format. This data type is 12 bytes long. See the GPR Data Types section for more information.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

GPR\_\$TRAPEZOID fills in a trapezoid with the color/intensity value specified with GPR\_\$SET\_FILL\_VALUE or the pattern set by GPR\_\$SET\_FILL\_PATTERN. To retrieve the current fill value, use GPR\_\$INQ\_FILL\_VALUE.

The GPR routines define a trapezoid as a quadrilateral with two horizontally parallel sides.

To draw an unfilled trapezoid use GPR\_\$POLYLINE.

Filled areas rasterized when the decomposition technique is GPR\_\$NON\_OVERLAPPING\_TRIS contain fewer pixels than filled areas rasterized with the decomposition technique set to either GPR\_\$FAST\_TRAPS or GPR\_\$PRECISE\_TRAPS.

Abutting filled areas rasterized when the decomposition technique is GPR\_\$NON\_OVERLAPPING\_TRIS do not overlap.

Abutting filled areas rasterized when the decomposition technique is either GPR\_\$FAST\_TRAPS or GPR\_\$PRECISE\_TRAPS OVERLAP.

**GPR\_\$TRIANGLE**

**GPR\_\$TRIANGLE**

Draws and fills a triangle.

## **FORMAT**

**GPR\_\$TRIANGLE** (vertex\_1, vertex\_2, vertex\_3, status)

## **INPUT PARAMETERS**

### **vertex\_1**

First vertex of the triangle, in **GPR\_\$POSITION\_T** format. This data type is 4 bytes long. See the GPR Data Types section for more information.

### **vertex\_2**

Second vertex of the triangle, in **GPR\_\$POSITION\_T** format. This data type is 4 bytes long. See the GPR Data Types section for more information.

### **vertex\_3**

Third vertex of the triangle, in **GPR\_\$POSITION\_T** format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## **OUTPUT PARAMETERS**

### **status**

Completion status, in **STATUS\_\$T** format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## **USAGE**

**GPR\_\$TRIANGLE** fills in a triangle with the color/intensity value specified with **GPR\_\$SET\_FILL\_VALUE** or the fill pattern set by **GPR\_\$SET\_FILL\_PATTERN**.

To retrieve the current fill value, use **GPR\_\$INQ\_FILL\_VALUE**.

Filled areas rasterized when the decomposition technique is **gpr\_\$non\_overlapping\_tris** contain fewer pixels than filled areas rasterized with the decomposition technique set to either **gpr\_\$fast\_traps** or **gpr\_\$precise\_traps**.

Abutting filled areas rasterized when the decomposition technique is **gpr\_\$non\_overlapping\_tris** do not overlap.

Abutting filled areas rasterized when the decomposition technique is either **gpr\_\$fast\_traps** or **gpr\_\$precise\_traps** overlap.

**GPR\_\$UNLOAD\_FONT\_FILE**

Unloads a font that has been loaded by GPR\_\$LOAD\_FONT\_FILE.

**FORMAT**

GPR\_\$UNLOAD\_FONT\_FILE (font\_id, status)

**INPUT PARAMETERS**

**font\_id**

Font identifier. This is a 2-byte integer.

**OUTPUT PARAMETERS**

**status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

The font\_id is returned when a program loads a file with the routine GPR\_\$LOAD\_FONT\_FILE.

GPR\_\$WAIT\_FRAME

GPR\_\$WAIT\_FRAME

Waits for the current frame refresh cycle to end before executing operations that modify the color display.

## FORMAT

GPR\_\$WAIT\_FRAME (status)

## OUTPUT PARAMETERS

### status

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

## USAGE

This routine is for use on color displays only.

Operations that modify the color display include block transfers and drawing and text operations.

This routine is useful primarily for animation. It delays execution of display modifications until the scan beam has completely covered the screen.

A program can also use this routine to synchronize changes to the color map with the beginning of the frame.

**GPR\_\$WRITE\_PIXELS**

Writes the pixel values from a pixel array into a window of the current bitmap.

**FORMAT**

GPR\_\$WRITE\_PIXELS (pixel\_array, destination\_window, status)

**INPUT PARAMETERS****pixel\_array**

A 131,073-element array of 4-byte integers in GPR\_\$PIXEL\_ARRAY\_T format from which to write pixel values (color/intensity).

**destination\_window**

Rectangular section of the current bitmap into which to write the pixel values, in GPR\_\$WINDOW\_T format. This data type is 8 bytes long. See the GPR Data Types section for more information.

**OUTPUT PARAMETERS****status**

Completion status, in STATUS\_\$T format. This data type is 4 bytes long. See the GPR Data Types section for more information.

**USAGE**

The pixel values in the pixel array, one in each 4-byte integer, are stored in the destination window of the bitmap in row-major order.

For monochromatic displays, only the low-order bit of each pixel value is significant.

For color displays in 4-bit pixel format, only the four lowest-order bits of each pixel value are considered because the bitmaps have four planes.

GPR\_\$WRITE\_PIXELS overwrites the old contents of the bitmap.

To read pixel values from the current bitmap into an array, use GPR\_\$READ\_PIXELS.

A program cannot use this routine on a bitmap corresponding to a Display Manager frame.



## Chapter 3 GPR Errors

This chapter lists possible GPR errors. A brief explanation is provided with each error.

**GPR\_\$ALREADY\_INITIALIZED**

Primitives are already initialized.

**GPR\_\$ARC\_OVERFLOW\_16BIT\_BOUNDS**

Distance between points on arc exceeds the allowable 16 bits of precision.

**GPR\_\$ARRAY\_NOT\_SORTED**

Array must be in ascending order.

**GPR\_\$BAD\_ATTRIBUTE\_BLOCK**

The attribute block descriptor is incorrect.

**GPR\_\$BAD\_BITMAP**

The bitmap descriptor is incorrect.

**GPR\_\$BAD\_DECOMP\_TECH**

Invalid decomposition technique.

**GPR\_\$BAD\_FONT\_FILE**

Font file is incorrect.

**GPR\_\$BITMAP\_IS\_READ\_ONLY**

Bitmap is read-only.

**GPR\_\$BITMAP\_NOT\_A\_FILE\_BITMAP**

Attempting to set or inquire a bitmap file color map when you have not passed a bitmap descriptor to an external bitmap.

**GPR\_\$CANT\_DEALLOCATE**

You cannot deallocate this bitmap.

**GPR\_\$CANT\_MIX\_MODES**

You cannot mix display modes, for example, borrow and direct.

**GPR\_\$CHARACTER\_NOT\_IN\_FONT**

Character is not in a font.

**GPR\_\$COORD\_OUT\_OF\_BOUNDS**

Coordinate value is out of bounds.

**GPR\_\$DEST\_OUT\_OF\_BOUNDS**

Destination window origin is out of bitmap bounds.

**GPR\_\$DIMENSION\_TOO\_BIG**

The bitmap dimension is too big.

**GPR\_\$DIMENSION\_TOO\_SMALL**

The bitmap dimension is too small.

**GPR\_\$DISPLAY\_NOT\_ACQ**

Display has not been acquired.

**GPR\_\$DUPLICATE\_POINTS**

Duplicate points are illegal.

GPR\_\$EMPTY\_ROP\_PRIM\_SET  
Raster operation primitive set is empty.

GPR\_\$FONT\_TABLE\_FULL  
Font table is full.

GPR\_\$FONT\_IS\_READ\_ONLY  
The following calls cannot be used to modify a read-only font:  
GPR\_\$SET\_SPACE\_SIZE, GPR\_\$SET\_HORIZONTAL\_SPACING, and  
GPR\_\$SET\_CHARACTER\_WIDTH.

GPR\_\$ILLEGAL\_FILL\_PATTERN  
Illegal bitmap for a fill pattern.

GPR\_\$ILLEGAL\_FILL\_SCALE  
Fill pattern scale must be one.

GPR\_\$ILLEGAL\_FOR\_FRAME  
Operation is illegal for DM frame.

GPR\_\$ILLEGAL\_FOR\_PIXEL\_BITMAP

GPR\_\$ILLEGAL\_PATTERN\_LENGTH  
The length of a line pattern must be less than 64 and greater than 0.

GPR\_\$ILLEGAL\_PIXEL\_VALUE  
Pixel value range is illegal.

GPR\_\$ILLEGAL\_SOFTWARE\_VERSION  
Pad is not compatible with current software version.

GPR\_\$ILLEGAL\_TEXT\_PATH  
Value is not in GPR\_\$DIRECTION\_T.

GPR\_\$ILLEGAL\_WHEN\_IMAGING  
Operation is illegal in imaging format.

GPR\_\$INCORRECT\_ALIGNMENT  
Bitmap layout specifications do not satisfy GPR alignment constraints.

GPR\_\$INCORRECT\_DECOMP\_TECH  
Attempting to close a polygon and return a set of trapezoids when the decomposition technique is not set to one of the trapezoid techniques or attempting to close a polygon and return a set of triangles when the decomposition technique is not set to non\_overlapping\_tris.

GPR\_\$INTERNAL\_ERROR  
This is an internal error.

GPR\_\$INVALID\_COLOR\_MAP  
The color map is invalid.

GPR\_\$INVALID\_FONT\_ID  
Font id is invalid.

GPR\_\$INVALID\_IMAGING\_FORMAT  
Format is invalid for display hardware.

GPR\_\$INVALID\_PLANE  
The plane number is invalid.

GPR\_ \$INVALID\_RASTER\_OP  
The raster operation value is invalid.

GPR\_ \$INVALID\_VIRTUAL\_DEVICE\_ID  
Invalid virtual device identification number.

GPR\_ \$KBD\_NOT\_ACQ  
Keyboard has not been acquired.

GPR\_ \$MUST\_BORROW\_DISPLAY  
You must borrow the display for this operation.

GPR\_ \$MUST\_HAVE\_DISPLAY  
Display must be acquired.

GPR\_ \$MUST\_RELEASE\_DISPLAY  
You must release the display for this operation.

GPR\_ \$NO\_ATTRIBUTES\_DEFINED  
No attributes are defined for the bitmap.

GPR\_ \$NO\_COLOR\_MAP\_IN\_FILE  
Attempting to inquire a bitmap file color map when you have not passed a bitmap descriptor to an external bitmap.

GPR\_ \$NO\_INPUT\_ENABLED  
No input events are enabled.

GPR\_ \$NO\_MORE\_SPACE  
No more bitmap space is available.

GPR\_ \$NO\_RESET\_DECOMP\_IN\_PGON  
Cannot set the decomposition technique between GPR\_ \$START\_PGON and GPR\_ \$CLOSE\_RETURN\_PGON, GPR\_ \$CLOSE\_FILL\_PGON, or GPR\_ \$CLOSE\_RETURN\_PGON\_TRI.

GPR\_ \$NOT\_IN\_DIRECT\_MODE  
Display is not in direct mode.

GPR\_ \$NOT\_IN\_POLYGON  
No polygon is being defined.

GPR\_ \$NOT\_INITIALIZED  
Primitives are not initialized.

GPR\_ \$ROP\_SETS\_NOT\_EQUAL  
Raster operations sets are not equal.

GPR\_ \$SOURCE\_OUT\_OF\_BOUNDS  
Source window origin is out of bitmap bounds.

GPR\_ \$SPECIFIC\_NONZERO\_ONLY  
Must specify a winding number when the fill criterion is GPR\_ \$SPECIFIC.

GPR\_ \$UNABLE\_TO\_ROTATE\_FONT  
Rotated character cannot fit into allocated character space.

GPR\_ \$WINDOW\_OBSCURED  
Window is obscured.

GPR\_\$WINDOW\_OUT\_OF\_BOUNDS

Window origin is out of bitmap bounds.

GPR\_\$WRONG\_DISPLAY\_HARDWARE

The display hardware is wrong for this operation.

# Index

GPR\_\$ACQUIRE\_DISPLAY 2-2  
GPR\_\$ADDITIVE\_BLT 2-3  
GPR\_\$ALLOCATE\_ATTRIBUTE\_BLOCK 2-4  
GPR\_\$ALLOCATE\_BITMAP 2-5  
GPR\_\$ALLOCATE\_BITMAP\_NC 2-6  
GPR\_\$ALLOCATE\_HDM\_BITMAP 2-7  
GPR\_\$ARC\_3P 2-8  
GPR\_\$ATTRIBUTE\_BLOCK 2-9  
GPR\_\$BIT\_BLT 2-10  
GPR\_\$CIRCLE 2-12  
GPR\_\$CIRCLE\_FILLED 2-13  
GPR\_\$CLEAR 2-14  
GPR\_\$CLOSE\_FILL\_PGON 2-15  
GPR\_\$CLOSE\_RETURN\_PGON 2-16  
GPR\_\$CLOSE\_RETURN\_PGON\_TRI 2-17  
GPR\_\$COLOR\_ZOOM 2-18  
GPR\_\$COND\_EVENT\_WAIT 2-19  
GPR\_\$DEALLOCATE\_ATTRIBUTE\_BLOCK 2-21  
GPR\_\$DEALLOCATE\_BITMAP 2-22  
GPR\_\$DISABLE\_INPUT 2-23  
GPR\_\$DRAW\_BOX 2-24  
GPR\_\$ENABLE\_DIRECT\_ACCESS 2-25  
GPR\_\$ENABLE\_INPUT 2-26  
GPR\_\$EVENT\_WAIT 2-28  
GPR\_\$FORCE\_RELEASE 2-30  
GPR\_\$GET\_EC 2-31  
GPR\_\$INIT 2-32  
GPR\_\$INQ\_BITMAP 2-34  
GPR\_\$INQ\_BITMAP\_DIMENSIONS 2-35  
GPR\_\$INQ\_BITMAP\_FILE\_COLOR\_MAP 2-39  
GPR\_\$INQ\_BITMAP\_POINTER 2-36  
GPR\_\$INQ\_BITMAP\_POSITION 2-37  
GPR\_\$INQ\_BM\_BIT\_OFFSET 2-38  
GPR\_\$INQ\_CHARACTER\_WIDTH 2-40  
GPR\_\$INQ\_COLOR\_MAP 2-41  
GPR\_\$INQ\_CONFIG 2-42  
GPR\_\$INQ\_CONSTRAINTS 2-43  
GPR\_\$INQ\_COORDINATE\_ORIGIN 2-44  
GPR\_\$INQ\_CP 2-45  
GPR\_\$INQ\_CURSOR 2-46  
GPR\_\$INQ\_DISP\_CHARACTERISTICS 2-48  
GPR\_\$INQ\_DRAW\_VALUE 2-51

GPR\_\$INQ\_FILL\_BACKGROUND\_VALUE 2-52  
GPR\_\$INQ\_FILL\_PATTERN 2-53  
GPR\_\$INQ\_FILL\_VALUE 2-54  
GPR\_\$INQ\_HORIZONTAL\_SPACING 2-55  
GPR\_\$INQ\_IMAGING\_FORMAT 2-56  
GPR\_\$INQ\_LINE\_PATTERN 2-57  
GPR\_\$INQ\_LINESTYLE 2-58  
GPR\_\$INQ\_PGON\_DECOMP\_TECHNIQUE 2-59  
GPR\_\$INQ\_RASTER\_OP\_PRIM\_SET 2-60  
GPR\_\$INQ\_RASTER\_OPS 2-61  
GPR\_\$INQ\_REFRESH\_ENTRY 2-62  
GPR\_\$INQ\_SPACE\_SIZE 2-63  
GPR\_\$INQ\_TEXT 2-64  
GPR\_\$INQ\_TEXT\_EXTENT 2-65  
GPR\_\$INQ\_TEXT\_OFFSET 2-67  
GPR\_\$INQ\_TEXT\_PATH 2-69  
GPR\_\$INQ\_TEXT\_VALUES 2-70  
GPR\_\$INQ\_TRIANGLE\_FILL\_CRITERIA 2-71  
GPR\_\$INQ\_VIS\_LIST 2-72  
GPR\_\$INQ\_WINDOW\_ID 2-73  
GPR\_\$LINE 2-74  
GPR\_\$LOAD\_FONT\_FILE 2-75  
GPR\_\$MOVE 2-76  
GPR\_\$MULTILINE 2-77  
GPR\_\$MULTITRAPEZOID 2-78  
GPR\_\$MULTITRIANGLE 2-79  
GPR\_\$OPEN\_BITMAP\_FILE 2-81  
GPR\_\$PGON\_DECOMP\_TECHNIQUE 2-85  
GPR\_\$PGON\_POLYLINE 2-87  
GPR\_\$PIXEL\_BLT 2-88  
GPR\_\$POLYLINE 2-89  
GPR\_\$RASTER\_OP\_PRIM\_SET 2-90  
GPR\_\$READ\_PIXELS 2-91  
GPR\_\$RECTANGLE 2-92  
GPR\_\$RELEASE\_DISPLAY 2-93  
GPR\_\$REMAP\_COLOR\_MEMORY 2-94  
GPR\_\$REMAP\_COLOR\_MEMORY\_1 2-95  
GPR\_\$REPLICATE\_FONT 2-96  
GPR\_\$SELECT\_COLOR\_FRAME 2-97  
GPR\_\$SET\_ACQ\_TIME\_OUT 2-98  
GPR\_\$SET\_ATTRIBUTE\_BLOCK 2-99  
GPR\_\$SET\_AUTO\_REFRESH 2-100  
GPR\_\$SET\_BITMAP 2-101  
GPR\_\$SET\_BITMAP\_DIMENSIONS 2-102  
GPR\_\$SET\_BITMAP\_FILE\_COLOR\_MAP 2-104

GPR\_\$SET\_CHARACTER\_WIDTH 2-105  
GPR\_\$SET\_CLIP\_WINDOW 2-106  
GPR\_\$SET\_CLIPPING\_ACTIVE 2-108  
GPR\_\$SET\_COLOR\_MAP 2-109  
GPR\_\$SET\_COORDINATE\_ORIGIN 2-111  
GPR\_\$SET\_CURSOR\_ACTIVE 2-112  
GPR\_\$SET\_CURSOR\_ORIGIN 2-113  
GPR\_\$SET\_CURSOR\_PATTERN 2-114  
GPR\_\$SET\_CURSOR\_POSITION 2-115  
GPR\_\$SET\_DRAW\_VALUE 2-117  
GPR\_\$SET\_FILL\_BACKGROUND\_VALUE 2-118  
GPR\_\$SET\_FILL\_PATTERN 2-119  
GPR\_\$SET\_FILL\_VALUE 2-120  
GPR\_\$SET\_HORIZONTAL\_SPACING 2-121  
GPR\_\$SET\_IMAGING\_FORMAT 2-122  
GPR\_\$SET\_INPUT\_SID 2-123  
GPR\_\$SET\_LINE\_PATTERN 2-124  
GPR\_\$SET\_LINESTYLE 2-125  
GPR\_\$SET\_OBSCURED\_OPT 2-126  
GPR\_\$SET\_PLANE\_MASK 2-128  
GPR\_\$SET\_RASTER\_OP 2-129  
GPR\_\$SET\_REFRESH\_ENTRY 2-131  
GPR\_\$SET\_SPACE\_SIZE 2-132  
GPR\_\$SET\_TEXT\_BACKGROUND\_VALUE 2-133  
GPR\_\$SET\_TEXT\_FONT 2-134  
GPR\_\$SET\_TEXT\_PATH 2-135  
GPR\_\$SET\_TEXT\_VALUE 2-136  
GPR\_\$SET\_TRIANGLE\_FILL\_CRITERIA 2-137  
GPR\_\$SET\_WINDOW\_ID 2-138  
GPR\_\$SPLINE\_CUBIC\_P 2-139  
GPR\_\$SPLINE\_CUBIC\_X 2-140  
GPR\_\$SPLINE\_CUBIC\_Y 2-141  
GPR\_\$START\_PGON 2-142  
GPR\_\$TERMINATE 2-143  
GPR\_\$TEXT 2-144  
GPR\_\$TRAPEZOID 2-145  
GPR\_\$TRIANGLE 2-146  
GPR\_\$UNLOAD\_FONT\_FILE 2-147  
GPR\_\$WAIT\_FRAME 2-148  
GPR\_\$WRITE\_PIXELS 2-149



## Reader's Response

Please take a few minutes to send us the information we need to revise and improve our manuals from your point of view.

Document Title: *DOMAIN Graphics Primitive Resource Call Reference*

Order No.: 007194

Revision: 01

Date of Publication: January, 1987

What type of user are you?

- |  |   |
|--|---|
| <input type="checkbox"/> System programmer; language _____       |   |
| <input type="checkbox"/> Applications programmer; language _____ |   |
| <input type="checkbox"/> System maintenance person               | <input type="checkbox"/> Manager/Professional   |
| <input type="checkbox"/> System Administrator                    | <input type="checkbox"/> Technical Professional |
| <input type="checkbox"/> Student Programmer                      | <input type="checkbox"/> Novice                 |
| <input type="checkbox"/> Other                                   |   |

How often do you use the DOMAIN system? \_\_\_\_\_

What parts of the manual are especially useful for the job you are doing?

\_\_\_\_\_

What additional information would you like the manual to include?

\_\_\_\_\_

Please list any errors, omissions, or problem areas in the manual. (Identify errors by page, section, figure, or table number wherever possible. Specify additional index entries.)

\_\_\_\_\_

\_\_\_\_\_  
Your Name

\_\_\_\_\_  
Date

\_\_\_\_\_  
Organization

\_\_\_\_\_  
Street Address

\_\_\_\_\_  
City

\_\_\_\_\_  
State

\_\_\_\_\_  
Zip

No postage necessary if mailed in the U.S.

cut or fold along dotted line

FOLD



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**

FIRST CLASS PERMIT NO. 78 CHELMSFORD, MA 01824

POSTAGE WILL BE PAID BY ADDRESSEE



**APOLLO COMPUTER INC.**  
**Technical Publications**  
**P.O. Box 451**  
**Chelmsford, MA 01824**

FOLD

## Reader's Response

Please take a few minutes to send us the information we need to revise and improve our manuals from your point of view.

Document Title: *DOMAIN Graphics Primitive Resource Call Reference*

Order No.: 007194

Revision: 01

Date of Publication: January, 1987

What type of user are you?

- |  |   |
|--|---|
| <input type="checkbox"/> System programmer; language _____       |   |
| <input type="checkbox"/> Applications programmer; language _____ |   |
| <input type="checkbox"/> System maintenance person               | <input type="checkbox"/> Manager/Professional   |
| <input type="checkbox"/> System Administrator                    | <input type="checkbox"/> Technical Professional |
| <input type="checkbox"/> Student Programmer                      | <input type="checkbox"/> Novice                 |
| <input type="checkbox"/> Other                                   |   |

How often do you use the DOMAIN system? \_\_\_\_\_

What parts of the manual are especially useful for the job you are doing?

\_\_\_\_\_

What additional information would you like the manual to include?

\_\_\_\_\_

Please list any errors, omissions, or problem areas in the manual. (Identify errors by page, section, figure, or table number wherever possible. Specify additional index entries.)

\_\_\_\_\_

\_\_\_\_\_  
Your Name

\_\_\_\_\_  
Date

\_\_\_\_\_  
Organization

\_\_\_\_\_  
Street Address

\_\_\_\_\_  
City

\_\_\_\_\_  
State

\_\_\_\_\_  
Zip

No postage necessary if mailed in the U.S.

cut or fold along dotted line

FOLD



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**

FIRST CLASS PERMIT NO. 78 CHELMSFORD, MA 01824

POSTAGE WILL BE PAID BY ADDRESSEE



**APOLLO COMPUTER INC.**  
**Technical Publications**  
**P.O. Box 451**  
**Chelmsford, MA 01824**

FOLD

## Reader's Response

Please take a few minutes to send us the information we need to revise and improve our manuals from your point of view.

Document Title: *DOMAIN Graphics Primitive Resource Call Reference*

Order No.: 007194

Revision: 01

Date of Publication: January, 1987

What type of user are you?

- |  |   |
|--|---|
| <input type="checkbox"/> System programmer; language _____       |   |
| <input type="checkbox"/> Applications programmer; language _____ |   |
| <input type="checkbox"/> System maintenance person               | <input type="checkbox"/> Manager/Professional   |
| <input type="checkbox"/> System Administrator                    | <input type="checkbox"/> Technical Professional |
| <input type="checkbox"/> Student Programmer                      | <input type="checkbox"/> Novice                 |
| <input type="checkbox"/> Other                                   |   |

How often do you use the DOMAIN system? \_\_\_\_\_

What parts of the manual are especially useful for the job you are doing?

\_\_\_\_\_

What additional information would you like the manual to include?

\_\_\_\_\_

Please list any errors, omissions, or problem areas in the manual. (Identify errors by page, section, figure, or table number wherever possible. Specify additional index entries.)

\_\_\_\_\_

Your Name

Date

Organization

Street Address

City

State

Zip

No postage necessary if mailed in the U.S.

cut or fold along dotted line

FOLD



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**  
FIRST CLASS      PERMIT NO. 78      CHELMSFORD, MA 01824

POSTAGE WILL BE PAID BY ADDRESSEE



**APOLLO COMPUTER INC.**  
**Technical Publications**  
**P.O. Box 451**  
**Chelmsford, MA 01824**

FOLD