

FP11-F

FP11F FLTG PNT PRT B
CKFPBCO

AH-F635C-MC
FICHE 1 OF 1

APR 1982
COPYRIGHT © 79-82
MADE IN USA



The main body of the document is a large grid of approximately 15 columns and 20 rows of data. Each cell in the grid contains a small, dense table or set of data points. The text is very small and difficult to read, but the overall structure is a comprehensive data matrix. The data appears to be organized in a hierarchical or sequential manner across the rows and columns.

.REM 8

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46

IDENTIFICATION

PRODUCT CODE: AC-F633C-MC
PRODUCT NAME: CKFPBC0 FP11F FLTG PNT PRT B
DATE CREATED: OCTOBER, 1981
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: ANTHONY VEZZA, DAN MILLEVILLE

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY OCCUR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1979, 1982 BY DIGITAL EQUIPMENT CORPORATION

48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93

HISTORY

NO CHANGES TO THE 11/34 FLOATING POINT DIAGNOSTICS PART 'A' WERE FOUND TO BE NEEDED TO ADAPT IT FOR USE ON THE 11/44.

THE FOLLOWING WAS ADDED TO THE 11/34 FLOATING POINT DIAGNOSTIC TO MAKE THE 'B' VERSION COVER THE 11/44:

1. TEST 22 - PROCESSOR LOOKS TO SEE IF APT IS CONTROLLING THE TEST, AND IF IT IS, CHECKS TO SEE IF THE USER HAS SELECTED THIS TEST BY CHECKING BIT 7 IN THE SWITCH REGISTER. IT HAS ALSO BEEN CHANGED SO THAT IF BIT 7 IS *ONE*, THE CODE WILL SELECT THE TEST.

THE FOLLOWING WAS ADDED TO THE 11/34 FLOATING POINT DIAGNOSTIC TO MAKE THE 'C' VERSION COVER THE 11/44:

1. TEST 76 - CHECKS THAT FP PROCESSOR DOESN'T ACCESS D-SPACE UNTIL CONDITIONS WARRANT.
2. TEST 77 - CHECKS THAT SR1 MATCHES WHAT ACTUALLY HAPPENED TO THE REGISTER OF THE INSTRUCTION, AND THAT THE VALUE OF AUTO INCREMENT/DECREMENT WAS PROPER.

ALL THREE PARTS WERE RE-RELEASED WITH NEW SCOPE AND ERROR ROUTINES THAT CHECK BIT 0 OF THE CPU ERROR REGISTER (POWER MONITOR BIT). THE ADDITIONS WERE MADE IN THE SCOPE ROUTINE, EXECUTED AT THE BEGINNING OF EACH TEST. IF THE BIT BECOMES SET, AN ERROR IS CALLED FROM THE SCOPE ROUTINE. THE BIT IS CLEARED, AND THE TEST IS CONTINUED. IF THE BIT BECOMES SET IN THE MIDDLE OF A TEST, AND AN ERROR OCCURS FOR ANY REASON, THE ERROR ROUTINE WILL CALL *TWO* ERRORS, THE POWER MONITOR BIT ERROR FIRST, THEN THE ERROR ORIGINALLY CALLED. IN ADDITION, THE \$READ ROUTINE NOW CHECKS FOR A RANDOMLY INPUTED ^Q BEFORE A ^S IS TYPED. THIS BECAME NECESSARY WITH CERTAIN DATA CONNECTIONS OF SOME SYSTEMS.

THE FOLLOWING WAS ADDED TO THE 'D' VERSION:

THE END-OF-PASS MESSAGES ARE NOW PRINTED EVERY 200 PASSES. THESE MESSAGES CAN BE DISABLED BY TYPING ANY KEY. THEY CAN BE REENABLED BY AGAIN TYPING ANY KEY THIS IS HELPFUL FOR OVERNIGHT RUNS ON HARD COPY TERMINALS. IT ALSO MAKES THE DIAGNOSTIC HARDWARE INTENSIVE INSTEAD OF TERMINAL INTENSIVE.

94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143

CONTENTS

- 1. ABSTRACT
- 2. REQUIREMENTS
 - 2.1 EQUIPMENT
 - 2.2 STORAGE
 - 2.3 PRELIMINARY PROGRAMS
- 3. LOADING PROCEDURE
- 4. STARTING PROCEDURE
 - 4.1 CONTROL SWITCH SETTINGS
 - 4.2 STARTING ADDRESS
 - 4.3 PROGRAM AND OPERATOR INTERACTION
- 5. OPERATING PROCEDURE
 - 5.1 OPERATIONAL SWITCH SETTINGS
 - 5.3 OPERATOR ACTION
- 6. ERRORS
 - 6.1 SUMMARY
 - 6.2 ERROR RECOVERY
- 7. RESTRICTIONS
 - 7.1 STARTING RESTRICTIONS
 - 7.2 OPERATING RESTRICTIONS
- 8. MISCELLANEOUS
 - 8.1 EXECUTION TIMES
 - 8.2 STACK POINTER
 - 8.3 PASS COUNT
 - 8.4 T-BIT TRAPPING
 - 8.5 SOFTWARE SWITCH REGISTER
 - 8.6 INTERRUPTS TEST
 - 8.7 ACT, APT AND XXDF COMPATIBILITY
- 9. PROGRAM DESCRIPTION
 - 9.1 CKFPBCO
- 10. LISTING
 - 10.1 CKFPBCO

145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201

1.

ABSTRACT

THE THREE PROGRAMS:

CKFPADO CKFPBCO CKFPCDO

ARE DESIGN TO DETECT AND REPORT LOGIC FAULTS IN THE PDP 11/44 FP11-F FLOATING POINT PROCESSOR. THE DESIGN IS AN ATTEMPT TO REACH ALL ROM STATES, TAKE ALL BRANCH MICRO TESTS (BUT'S) AND VERIFY ALL THE LOGIC. THEY CONSIST OF 157 (OCT) INDIVIDUAL TESTS SEQUENCED TO DETECT AND ATTEMPT TO IDENTIFY FAULTS WITH A MINIMUM HARDWARE OR SOFTWARE LEVEL. THE TESTS ARE PARTIONED INTO THREE STAND-ALONE PROGRAMS DESCRIBED BELOW.

NOTE THAT ERROR REPORTS IN THESE PROGRAMS ARE BASED UPON THE KNOWLEDGE THAT ALL PREVIOUS TESTS HAVE BEEN RUN AND IN MOST CASE THAT THERE IS ONLY A SINGLE POINT FAULT IN THE FP11-F. IF THE PROGRAMS OR TESTS ARE NOT RUN IN ORDER THEN ERROR MESSAGES MAY NOT BE ACCURATE.

A. CKFPADO

CKFPADO TESTS:

LDFPS
STFPS
CFCC
SETF, SETD, SETI AND SETL
STST
LDF AND LDD (ALL SOURCE MODES)
STD (MODE 0 AND 1)
ADDF, ADDD AND SUBD (MOST CONDITIONS)

B. CKFPBCO

CKFPBCO TESTS:

ADDF, ADDC AND SUBD (ALL CONDITIONS NOT TESTED IN CKFPBCO)
CMPD AND CMPF
DIVD AND DIVF
MULD AND MULF
MODD AND MODF

C. CKFPCDO

CKFPCDO TESTS:

STF AND STD (ALL MODES)
STCFD AND STCDF
CLRD AND CLRF

202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258

NEGF AND NEGD
ABSF AND ABSD
TSTF AND TSTD
NEGF, ABSF AND TSTF (ALL SOURCE MODES)
NEGF, ABSF AND TSTF (ALL SOURCE MODES)
LDFPS (ALL SOURCE MODES)
LDCIF AND LDCLF
LDCID AND LDCLD
LDEXP
STFPS (ALL DESTINATION MODES)
STCFL AND STCFI
STCDL AND STCDI
STEXP
STST

2. REQUIREMENTS

2.1 EQUIPMENT

A PDP 11/44 (WITH OR WITHOUT CONSOLE), LA30 (OR EQUIVALENT) AND AN FP11-F FLOATING POINT PROCESSOR. NOTE THAT A SPECIAL INTERRUPTS TEST MODULE IS BEING DESIGNED FOR USE IN THE MANUFACTURING ENVIRONMENT. WHEN THIS DEVICE IS PRESENT THE PROGRAM CKFPBCO WILL MAKE USE OF IT TO TEST THE FPP INTERRUPT ON BUS REQUEST FUNCTIONS.

2.2 STORAGE

ALL THREE PROGRAM REQUIRE A MEMORY SYSTEM OF AT LEAST 16K TO LOAD AND RUN.

2.3 PRELIMINARY PROGRAMS

THESE THREE DIAGNOSTICS WILL ASSUME THAT THE PDP 11/44 CENTRAL PROCESSOR IS FAULTLESS, THEREFORE WHEN IN DOUBT RUN THE PDP 11/44 PROCESSOR DIAGNOSTICS BEFORE THESE FP11-F DIAGNOSTICS.

3. LOADING PROCEDURE

THE PROGRAMS WILL BE SUPPLIED ON THE 11/44 DIAGNOSTIC MEDIA. REFER TO THE XXDP OPERATING MANUAL FOR FURTHER INFORMATION.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

SEE SECTION 5.1

4.2 PROGRAM AND OPERATOR ACTION

259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315

1. LOAD PROGRAM INTO MEMORY
2. LOAD ADDRESS 200
3. SET CONSOLE SWITCHES (IF CONSOLE IS PRESENT)
4. PRESS START
ON FIRST PASS THE PROGRAM WILL IDENTIFY ITSELF. NOTE THAT IF THERE IS NO PHYSICAL CONSOLE THE PROGRAM WILL REQUEST THE OPERATOR FOR INITIAL VALUE FOR THE SOFTWARE SWITCH REGISTER (SEE SECTION 8.5). IF RUNNING UNDER ACT, APT OR CHAIN THIS DOES NOT APPLY.
5. THE PROGRAM WILL LOOP AND AN END OF PASS AND ERROR SUMMARY WILL BE TYPED AT THE END OF EVERY PASS.

5. OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

THE SWITCH SETTING ARE:

	OCTAL	
SW<15>=1...	100000	HALT ON ERROR
SW<14>=1...	40000	LOOP ON CURRENT TEST
SW<13>=1...	20000	INHIBIT ERROR TYPE OUTS
SW<12>=1...	10000	INHIBIT T-BIT TRAPPING
SW<11>=1...	4000	INHIBIT ITERATIONS
SW<10>=1...	2000	RING TTY BELL ON ERROR
SW<9>=1....	1000	LOOP ON ERROR
SW<8>=1....	400	LOOP ON TEST SPECIFIED IN SW<6> THROUGH SW<0>
SW<7>=1....	200	PRINT ERROR SUMMARY EVEN IF SW<13>=1, THIS APPLIES ONLY TO PROGRAM CKFPADO.
SW<7>=1....	200	SELECT CORRECT INTERRUPT TEST IN PROGRAM CKFPBCO. IF APT IS SELECTING THE TEST, THE SWITCH REGISTER IS EXAMINED TO SEE IF THE USER HAS SELECTED THIS TEST BY A <1> IN SW<7>

6. ERRORS

6.1 SUMMARIES

IN PROGRAM CKFPADO, TESTS 1 AND 11 HAVE A SPECIAL ERROR SUMMARY FEATURE. THESE TWO TEST RUN MANY TEST PATTERNS THROUGH THE LOGIC. AFTER AN ERROR IS ENCOUNTERED, ONLY THE FIRST FIVE ERRORS ARE REPORTED (TYPED ON THE TTY). EVERY ERROR THOUGH IS LOGGED AND AN ERROR SUMMARY IS PRINTED WHEN THE TEST IS COMPLETE. NOTE THAT IF SW<13>=1 THIS

316 SUMMARY WILL NOT BE TYPED UNLESS SW<7>=1. IN OTHER
317 WORDS TO GET JUST AN ERROR SUMMARY FROM EITHER OF
318 THESE TWO TESTS 1 AND 11 IN PROGRAM CKFPADO BOTH
319 SWITCHES 13 AND 7 MUST = 1.

320 6.2 ERROR RECOVERY

321 SW<15:9>=0... MOST ERRORS WILL CAUSE EXECUTION TO
322 GO TO THE START OF THE NEXT TEST
323 AFTER THE MESSAGE IS TYPED. A FEW
324 TESTS ARE IN SECTIONS. IN THESE
325 TESTS AN ERROR WILL CAUSE EXECUTION
326 TO GO TO THE NEXT SECTION AFTER THE
327 MESSAGE IS TYPED.

328 SW<15>=1... THE PROGRAM WILL HALT AFTER TYPING
329 THE ERROR MESSAGE. PRESSING THE
330 CONSOLE CONTINUE WILL CAUSE THE
331 PROGRAM TO CONTINUE AS IF SW<15>=0.

332 7. RESTRICTIONS
333 -----

334 NONE

335 8. MISCELLANEOUS
336 -----

337 8.1 EXECUTION TIMES

338 LESS THAN 10 SECONDS FOR EACH PROGRAM ON ANY PASS.

339 8.2 STACK POINTER

340 THE STACK POINTER IS INITIALIZED TO 1100 IN EACH OF
341 THE THREE PROGRAMS.

342 8.3 PASS COUNT

343 THE PROGRAM MAKES ONE PASS FOR EACH END OF PASS
344 MESSAGE TYPED. THE END OF PASS MESSAGE DESCRIBES
345 THE TOTAL NUMBER OF PASSES COMPLETED AND THE TOTAL
346 NUMBER OF ERRORS SINCE THE LAST END OF PASS MESSAGE.

347 8.4 T-BIT TRAPPING

348 IF SW<12>=0 EACH PROGRAM WILL RUN WITH TRACE TRAPS
349 ON EVERY OTHER PASS. FIRST PASS WILL NOT ENABLE
350 TRACE TRAPS. NOTE SW<12>=1 DISABLES T-BIT TRAPS.

351 8.5 SOFTWARE SWITCH REGISTER

352 EACH OF THE THREE PROGRAMS WILL RUN WITH OR WITHOUT
353 A CONSOLE SWITCH REGISTER. IF A PHYSICAL CONSOLE
354 SWITCH REGISTER IS PRESENT ON THE SYSTEM, THEN THESE
355 PROGRAMS WILL GO AHEAD AND USE IT FOR THE SWITCH

356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372

373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429

FUNCTIONS DESCRIBED IN 5.1 ABOVE. IF HOWEVER THERE IS NO CONSOLE SWITCH REGISTER ON THE SYSTEM A SOFTWARE SWITCH REGISTER WILL BE USED. THIS SOFTWARE SWITCH REGISTER CAN BE EXAMINED OR MODIFIED AT ANY TIME BY THE USER IF HE TYPES CONTROL G WHILE THE PROGRAM IS RUNNING. THIS CONTROL G WILL CAUSE THE CONTENTS OF THE SOFTWARE SWITCH REGISTER TO BE TYPED ON THE TTY AND ASK THE USER FOR A NEW VALUE. WHEN THE USER TYPES A VALUE AND CARRIAGE RETURN THEN THE PROGRAM WILL RESUME TESTING AT THE SAME POINT AT WHICH IT LEFT OFF WHEN THE USER TYPED CONTROL G. NOTE THAT WHEN NOT RUNNING UNDER ACT, APT OR CHAIN THE USER WILL BE ASKED FOR A SOFTWARE SWITCH REGISTER VALUE AFTER LOADING ADDRESS 200 AND STARTING THE PROGRAM THE FIRST TIME THE PROGRAM IS RUN AFTER LOADING (ONLY IF NO CONSOLE SWITCH REGISTER IS ON THE SYSTEM).

8.6 INTERRUPTS TEST

IN PROGRAM CKFPBCO, THERE IS A SPECIAL TEST FOR CHECKING THE CORRECT FLOWS OF THE FPP. THIS TEST CAN BE RUN ONLY IF A SPECIAL TEST MODULE IS IN THE SYSTEM. THIS MODULE WILL PROBABLY ONLY BE USED IN MANUFACTURING. IF THIS MODULE IS NOT IN THE SYSTEM THIS TEST WILL AUTOMATICALLY BE DESELECTED. IF THIS TEST MODULE IS ON THE SYSTEM AND SW<7>=0 THIS TEST WILL BE RUN. IF SW<7>=1 THIS TEST WILL BE DESELECTED.

8.7 ACT, APT AND XXDP COMPATIBILITY

THESE PROGRAMS ARE FULLY COMPATIBLE WITH:
APT
ACT
XXDP MONITOR AND CHAIN PROGRAMS.

9. PROGRAM DESCRIPTION

TEST 1 ROUND\TRUNK TEST

430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486

THIS IS A TEST OF THE ROUND\TRUNK FLOWS. IN PARTICULAR TWO THINGS ARE TESTED: FIRST A CONDITION IN WHICH ROUNDING RESULTS IN THE NEED FOR RENORMALIZATION, AND SECOND THE PSW CONDITION CODES N AND Z BIT COMBINATIONS

TEST 2 OVER\UNDER TEST

THIS IS A PARTIAL TEST OF THE OVER\UNDER FLOWS. ONE OVERFLOW AND TWO UNDERFLOW CONDITIONS ARE CHECKED. THE REMAINING UNDERFLOW COND. AND THE REMAINING OVERFLOW COND. WILL BE CHECKED LATER USING THE XXX INSTRUCTION. HERE EACH CONDITION TESTED IS CHECKED BOTH WITH TRAPS ENABLED (FIU=1 OR FIV=1) AND ALSO WITH TRAPS DISABLED (FIU=0 OR FIV=0).

TEST 3 LDCFD AND LDCDF TEST

THIS IS A TEST OF LDCFD AND LDCDF.

TEST 4 CMPD TEST

THIS IS A TEST OF THE CMPD INSTRUCTION. NOTE THAT A SUBROUTINE IS USED TO SET UP OPERANDS, EXECUTE THE INSTRUCTION AND CHECK THE RESULTS

TEST 5 DIVD WITH (FSRC=0) AND (BUT FD) TEST

THIS IS A TEST OF THE DIVD INSTRUCTION WITH A ZERO DIVISOR. THE CONDITION IS CHECKED WITH BOTH TRAP ENABLED AND TRAPS DISABLED.

TEST 6 DIVF TEST

THIS IS A TEST OF THE DIVF INSTRUCTION. NOTE THAT A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE INSTRUCTION AND CHECK THE RESULTS.

TEST 7 DIVD TEST

THIS IS A TEST OF THE DIVD INSTRUCTION. NOTE THAT A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE INSTRUCTION AND CHECK THE RESULTS.

TEST 10 MULF TEST

THIS IS A TEST OF THE MULF INSTRUCTION. IT MAKES USE OF A SUBROUTINE TO SET UP THE OPERANDS, EXECUTE THE MULF INSTRUCTION AND CHECK THE RESULTS.

487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543

TEST 11 MULD TEST

THIS IS A TEST OF THE MULD INSTRUCTION. NOTE THAT A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE MULD INSTRUCTION AND CHECK THE RESULTS.

TEST 12 UNDER\OVER FLOW, USING MULF WITH TRAPS DISABLED, TEST

THIS IS A TEST OF THE OVERFLOW AND UNDERFLOW CONDITIONS USING THE MULF INSTRUCTION WITH TRAPS DISABLED. NOTE THAT A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE MULF INSTRUCTION AND CHECK THE RESULTS.

TEST 13 UNDER\OVER FLOW, USING MULD WITH TRAPS DISABLED, TEST

THIS IS A TEST OF THE OVERFLOW AND UNDERFLOW CONDITIONS THAT CAN ARRISE USING THE MULD INSTRUCTION WITH TRAPS DISABLED. A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE MULD INSTRUCTION AND CHECK THE RESULTS.

TEST 14 UNDER\OVER FLOW, USING MULF WITH TRAPS ENABLED, TEST

THIS IS A TEST OF THE UNDERFLOW AND OVERFLOW CONDITIONS THAT CAN OCCUR USING THE MULF INSTRUCTION. A SUBROUTINE IS CALLED TO SET UP THE OPERANDS, EXECUTE THE MULF INSTRUCTION AND CHECK THE RESULTS. HERE THE PARTICULAR INTERRUPT, EITHER OVERFLOW OR UNDERFLOW, IS ENABLED SO A TRAP SHOULD OCCUR.

TEST 15 UNDER\OVER FLOW, USING MULD WITH TRAPS ENABLED, TEST

THIS IS A TEST OF THE OVER FLOW AND UNDER FLOW CONDITIONS USING THE MULD INSTRUCTION WITH TRAPS ENABLED. A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE MULD INSTRUCTION AND CHECK THE RESULTS.

TEST 16 MODF TEST

THIS IS A TEST OF THE MODF INSTRUCTION, WHICH MAKES USE OF A SUBROUTINE TO SET UP THE OPERANDS, EXECUTE THE MODF INSTRUCTION AND CHECK THE RESULTS.

TEST 17 MODD TEST

THIS IS A TEST OF THE MODD INSTRUCTION. IT MAKES USE OF A SUBROUTINE TO SET UP THE ARGUMENTS, EXECUTE

544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600

THE INSTRUCTION AND CHECK THE RESULTS.

TEST 20 UNDER\OVER FLOW, USING MODF WITH TRAPS DISABLED, TEST

THIS IS A TEST OF THE MODF OVERFLOW AND UNDERFLOW CONDITIONS. IT MAKES USE OF A SUBROUTINE TO SETUP THE OPERANDS, EXECUTE THE MODF INSTRUCTION AND CHECK THE RESULTS. TRAPS ARE DISABLED DURING THIS TEST.

TEST 21 UNDER\OVER FLOW, USING MODD WITH TRAPS DISABLED, TEST

THIS IS A TEST OF THE MODD INSTRUCTION'S OVER FLOW AND UNDER FLOW CONDITIONS. A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE MODD INSTRUCTION AND CHECK THE RESULTS.

TEST 22 INTERRUPT CORRECT FLOWS TEST

THIS IS A TEST OF THE 'CORRECT' FLOWS. THIS PART OF THE MICRO CODE HAS AS ITS PURPOSE INSURING THAT INTERRUPT REQUESTS MADE DURING CERTAIN LENGTHY FPP INSTRUCTIONS GET HONORED. THIS IS DONE IN A WAY SUCH THAT IF AN INTERRUPT REQUEST OCCURS DURING ONE OF THESE INSTRUCTIONS THE STATE OF THAT INSTRUCTION'S EXECUTION WILL BE THE SAME AS IF THAT INSTRUCTION HAD NEVER BEEN FETCHED AND ITS EXECUTION NEVER STARTED. THUS THE MICRO CODE WILL RESTORE ALL REGISTERS, BACK UP THE PC AND LEAVE THE FPS AND ACO THROUGH ACS UNMODIFIED. THE INSTRUCTIONS FOR WHICH THIS IS NECESSARY ARE:

- ADD (OR SUB)
- DIV
- MUL
- MOD

(BOTH DOUBLE AND FLOATING)

ALL ADDRESSING MODES WILL BE TRIED WITH THE ADDD INSTRUCTION. THEN EACH OF THE OTHER INSTRUCTIONS WILL BE TRIED USING MODE 1. NOTE THAT THIS TEST NEEDS A SPECIAL INTERRUPT MODULE, WHICH WILL PROBABLY ONLY BE PRESENT IN DEC'S MANUFACTURING ENVIRONMENT, TO RUN. THIS SPECIAL EQUIPMENT IS DESIGNED TO RAISE AN INTERRUPT REQUEST IN THE PROCESSOR IF A BIT IS SET IN ITS STATUS REGISTER AND ONLY WHEN AN FPP INSTRUCTION IS ENCOUNTERED. THEREFORE THIS TEST WILL BE RUN CONDITIONALLY (DEPENDENT UPON WHETHER OR NOT THE STATUS REGISTER OF THE TEST EQUIPMENT TIMES OUT WHEN REFERENCED). THIS TEST CAN ALSO BE SELECTED BY TURNING SWITCH 7 OF THE SWITCH REGISTER (PHYSICAL OR VIRTUAL) ON. THE TEST ASSUMES THAT THE TEST EQUIPMENT'S STATUS REGISTER IS AT LOCATION 777774 (NOTE THAT ALL REFERENCES TO THIS LOCATION ARE MADE INDIRECT

601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623

THROUGH THIS PROGRAMS LOCATION CORINT, SO THAT IF THE USER HAS MODIFIED THE TEST EQUIPMENT'S STATUS REGISTER TO RESPOND TO A DIFFERENT ADDRESS LOCATION CORINT MUST BE MADE TO CONTAIN THAT STATUS REGISTER'S NEW ADDRESS). THIS PROGRAM ASSUMES THAT THE TRAP VECTOR FOR THE TEST EQUIPMENT IS 110. AGAIN NOTE THAT ALL REFERENCES TO THIS TRAP VECTOR ARE INDIRECT, THROUGH THIS PROGRAM'S LOCATION CORTRP (IF THE TEST EQUIPMENT IS MADE TO TRAP TO A DIFFERENT VECTOR LOCATION CORTRP MUST CONTAIN THE ADDRESS OF THIS VECTOR).

10.

LISTING
-----g


```

624      000267      MNUMBER=267
625      000002      PROGNUM=2
626      .LIST      ME
627      .NLIST     MD
628      .NLIST     MC
629      .NLIST     CND
630      .NLIST     BEX
1645     .MCALL     .HEADER, .SWRHI, .EQUAT, .SETUP, .SCATCH, .SACT11, .SCMTAG
1646     .MCALL     NEWTST, $$NEWTST, $$SAVE, $TYPE
1647     .MCALL     .STYPDEC, .STRAP, .SPOWER, .SAPTHDR, .SAPTBL
1648     .MCALL     .STYPE, .SAPTYE, .SREAD
1649     .MCALL     .EQUIV ;REMOVE FOR PDP-10 ASSEMBLY
1650     .TITLE     CKFPBCO FP11F FLTG PNT PRT B
        .*COPYRIGHT (C) 1981
        .*DIGITAL EQUIPMENT CORP.
        .*MAYNARD, MASS. 01754
        .*
        .*
        .*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
        .*PACKAGE (MAINDEC-11-DZQAC-C5), JAN, 1981.
        .*
000001   $TN=1
160000   $$SWR=160000 ;:HALT ON ERROR, LOOP ON TEST, INHIBIT ERROR TYP0UT

1651
1652
1653     000244      FPVECT=244
1654     177400      $$SWR=177400
1655     000200      $$SWRMSK=200
1656     000011      TAB=11
1657     000015      CRLF=15
1658
1659     .SBTTL     BASIC DEFINITIONS
        .*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
001100   STACK= 1100
104000   ERROR=EMT
000004   SCOPE=IOT
        .*MISCELLANEOUS DEFINITIONS
000011   HT= 11 ;:CODE FOR HORIZONTAL TAB
000012   LF= 12 ;:CODE FOR LINE FEED
000015   CR= 15 ;:CODE FOR CARRIAGE RETURN
000200   CRLF= 200 ;:CODE FOR CARRIAGE RETURN-LINE FEED
177776   PS= 177776 ;:PROCESSOR STATUS WORD
177776   PSW=PS
177774   STKLMT= 177774 ;:STACK LIMIT REGISTER
177772   PIRQ= 177772 ;:PROGRAM INTERRUPT REQUEST REGISTER
177570   DSWR= 177570 ;:HARDWARE SWITCH REGISTER
177570   DDISP= 177570 ;:HARDWARE DISPLAY REGISTER
        .*GENERAL PURPOSE REGISTER DEFINITIONS
000000   R0= %0 ;:GENERAL REGISTER
000001   R1= %1 ;:GENERAL REGISTER
000002   R2= %2 ;:GENERAL REGISTER
000003   R3= %3 ;:GENERAL REGISTER
000004   R4= %4 ;:GENERAL REGISTER
000005   R5= %5 ;:GENERAL REGISTER
000006   R6= %6 ;:GENERAL REGISTER
000007   R7= %7 ;:GENERAL REGISTER
000006   SP= %6 ;:STACK POINTER
    
```

```
000007 PC= 27 ::PROGRAM COUNTER
          :*PRIORITY LEVEL DEFINITIONS
000000 PR0= 0 ::PRIORITY LEVEL 0
000040 PR1= 40 ::PRIORITY LEVEL 1
000100 PR2= 100 ::PRIORITY LEVEL 2
000140 PR3= 140 ::PRIORITY LEVEL 3
000200 PR4= 200 ::PRIORITY LEVEL 4
000240 PR5= 240 ::PRIORITY LEVEL 5
000300 PR6= 300 ::PRIORITY LEVEL 6
000340 PR7= 340 ::PRIORITY LEVEL 7
          :*"SWITCH REGISTER" SWITCH DEFINITIONS
100000 SW15= 100000
040000 SW14= 40000
020000 SW13= 20000
010000 SW12= 10000
004000 SW11= 4000
002000 SW10= 2000
001000 SW09= 1000
000400 SW08= 400
000200 SW07= 200
000100 SW06= 100
000040 SW05= 40
000020 SW04= 20
000010 SW03= 10
000004 SW02= 4
000002 SW01= 2
000001 SW00= 1
          SW9=SW09
          SW8=SW08
          SW7=SW07
          SW6=SW06
          SW5=SW05
          SW4=SW04
          SW3=SW03
          SW2=SW02
          SW1=SW01
          SW0=SW00
          :*DATA BIT DEFINITIONS (BIT00 TO BIT15)
100000 BIT15= 100000
040000 BIT14= 40000
020000 BIT13= 20000
010000 BIT12= 10000
004000 BIT11= 4000
002000 BIT10= 2000
001000 BIT09= 1000
000400 BIT08= 400
000200 BIT07= 200
000100 BIT06= 100
000040 BIT05= 40
000020 BIT04= 20
000010 BIT03= 10
000004 BIT02= 4
000002 BIT01= 2
000001 BIT00= 1
          BIT9=BIT09
          BIT8=BIT08
          BIT7=BIT07
```

```

000100          BIT6=BIT06
000040          BIT5=BIT05
000020          BIT4=BIT04
000010          BIT3=BIT03
000004          BIT2=BIT02
000002          BIT1=BIT01
000001          BIT0=BIT00

;*BASIC "CPU" TRAP VECTOR ADDRESSES
000004          ERRVEC= 4          ;; TIME OUT AND OTHER ERRORS
000010          RESVEC= 10         ;; RESERVED AND ILLEGAL INSTRUCTIONS
000014          TBITVEC=14        ;; "T" BIT
000014          TRTVEC= 14         ;; TRACE TRAP
000014          BPTVEC= 14         ;; BREAKPOINT TRAP (BPT)
000020          IOTVEC= 20         ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024          PWRVEC= 24         ;; POWER FAIL
000030          EMTVEC= 30         ;; EMULATOR TRAP (EMT) **ERROR**
000034          TRAPVEC=34        ;; "TRAP" TRAP
000060          TKVEC= 60          ;; TTY KEYBOARD VECTOR
000064          TPVEC= 64          ;; TTY PRINTER VECTOR
000240          PIRQVEC=240        ;; PROGRAM INTERRUPT REQUEST VECTOR

1660          .SBTTL FPP REGISTER DEFINITIONS
1661          AC0          =%0
1662          AC1          =%1
1663          AC2          =%2
1664          AC3          =%3
1665          AC4          =%4
1666          AC5          =%5
1667          AC6          =%6
1668          AC7          =%7

1670          .SBTTL TRAP CATCHER
1671          =0
          ;;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
          ;;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
          ;;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS

000174          =174
000174          000000          DISPREG: .WORD 0          ;; SOFTWARE DISPLAY REGISTER
000176          000000          SWREG: .WORD 0          ;; SOFTWARE SWITCH REGISTER

000200          000137          004346          .SBTTL STARTING ADDRESS(ES)
          JMP @#START ;; JUMP TO STARTING ADDRESS OF PROGRAM
    
```


1672

001100 001100
001100 000000
001102 000
001103 000
001104 000000
001106 000000
001110 000000
001112 000000
001114 000
001115 001
001116 000000
001120 000000
001122 000000
001124 000000
001126 000000
001130 000000
001132 000000
001134 000
001135 000
001136 000000
001140 177570
001142 177570
001144 177560
001146 177562
001150 177564
001152 177566
001154 000
001155 002
001156 012
001157 000
001160 000000

001162 000024
001164 000000
001166 000000
001170 000000
001172 000000
001174 000000
001176 000000
001200 000000
001202 000000
001204 000000
001206 000000
001210 000000
001212 000000
001214 000000
001216 000000
001220 000000
001222 000000
001224 000000
001226 000000

.SBTTL COMMON TAGS

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.

.=1100
SCMTAG: .WORD 0
\$TSTNM: .BYTE 0
\$ERFLG: .BYTE 0
\$ICNT: .WORD 0
\$LPADR: .WORD 0
\$LPERR: .WORD 0
\$ERTTL: .WORD 0
\$ITEMB: .BYTE 0
\$ERMAX: .BYTE 1
\$ERRPC: .WORD 0
\$GDADR: .WORD 0
\$BDADR: .WORD 0
\$GDDAT: .WORD 0
\$BDDAT: .WORD 0
\$AUTOB: .BYTE 0
\$INTAG: .BYTE 0
\$SWR: .WORD DSWR
\$DISPLAY: .WORD DDISP
\$TKS: 177560
\$TKB: 177562
\$TPS: 177564
\$TPB: 177566
\$NULL: .BYTE 0
\$FILLS: .BYTE 2
\$FILLC: .BYTE 12
\$TPFLG: .BYTE 0
\$REGAD: .WORD 0

\$REG0: .REPT \$rM3
\$REG1: .WORD 0
\$REG2: .WORD 0
\$REG3: .WORD 0
\$REG4: .WORD 0
\$REG5: .WORD 0
\$REG6: .WORD 0
\$REG7: .WORD 0
\$REG10: .WORD 0
\$REG11: .WORD 0
\$REG12: .WORD 0
\$REG13: .WORD 0
\$REG14: .WORD 0
\$REG15: .WORD 0
\$REG16: .WORD 0
\$REG17: .WORD 0
\$REG20: .WORD 0
\$REG21: .WORD 0
\$REG22: .WORD 0

:::START OF COMMON TAGS
:::CONTAINS THE TEST NUMBER
:::CONTAINS ERROR FLAG
:::CONTAINS SUBTEST ITERATION COUNT
:::CONTAINS SCOPE LOOP ADDRESS
:::CONTAINS SCOPE RETURN FOR ERRORS
:::CONTAINS TOTAL ERRORS DETECTED
:::CONTAINS ITEM CONTROL BYTE
:::CONTAINS MAX. ERRORS PER TEST
:::CONTAINS PC OF LAST ERROR INSTRUCTION
:::CONTAINS ADDRESS OF 'GOOD' DATA
:::CONTAINS ADDRESS OF 'BAD' DATA
:::CONTAINS 'GOOD' DATA
:::CONTAINS 'BAD' DATA
:::RESERVED--NOT TO BE USED

:::AUTOMATIC MODE INDICATOR
:::INTERRUPT MODE INDICATOR

:::ADDRESS OF SWITCH REGISTER
:::ADDRESS OF DISPLAY REGISTER
:::TTY KBD STATUS
:::TTY KBD BUFFER
:::TTY PRINTER STATUS REG. ADDRESS
:::TTY PRINTER BUFFER REG. ADDRESS
:::CONTAINS NULL CHARACTER FOR FILLS
:::CONTAINS # OF FILLER CHARACTERS REQUIRED
:::INSERT FILL CHARS. AFTER A 'LINE FEED'
:::'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
:::CONTAINS THE ADDRESS FROM
:::WHICH (\$REG0) WAS OBTAINED

:::CONTAINS ((\$REGAD)+0)
:::CONTAINS ((\$REGAD)+2)
:::CONTAINS ((\$REGAD)+4)
:::CONTAINS ((\$REGAD)+6)
:::CONTAINS ((\$REGAD)+10)
:::CONTAINS ((\$REGAD)+12)
:::CONTAINS ((\$REGAD)+14)
:::CONTAINS ((\$REGAD)+16)
:::CONTAINS ((\$REGAD)+20)
:::CONTAINS ((\$REGAD)+22)
:::CONTAINS ((\$REGAD)+24)
:::CONTAINS ((\$REGAD)+26)
:::CONTAINS ((\$REGAD)+30)
:::CONTAINS ((\$REGAD)+32)
:::CONTAINS ((\$REGAD)+34)
:::CONTAINS ((\$REGAD)+36)
:::CONTAINS ((\$REGAD)+40)
:::CONTAINS ((\$REGAD)+42)
:::CONTAINS ((\$REGAD)+44)

```
001230 000000 $REG23: .WORD 0 ;;CONTAINS (($REGAD)+46)
000024 .REPT 24
001232 000000 $TMP0: .WORD 0 ;;USER DEFINED
001234 000000 $TMP1: .WORD 0 ;;USER DEFINED
001236 000000 $TMP2: .WORD 0 ;;USER DEFINED
001240 000000 $TMP3: .WORD 0 ;;USER DEFINED
001242 000000 $TMP4: .WORD 0 ;;USER DEFINED
001244 000000 $TMP5: .WORD 0 ;;USER DEFINED
001246 000000 $TMP6: .WORD 0 ;;USER DEFINED
001250 000000 $TMP7: .WORD 0 ;;USER DEFINED
001252 000000 $TMP10: .WORD 0 ;;USER DEFINED
001254 000000 $TMP11: .WORD 0 ;;USER DEFINED
001256 000000 $TMP12: .WORD 0 ;;USER DEFINED
001260 000000 $TMP13: .WORD 0 ;;USER DEFINED
001262 000000 $TMP14: .WORD 0 ;;USER DEFINED
001264 000000 $TMP15: .WORD 0 ;;USER DEFINED
001266 000000 $TMP16: .WORD 0 ;;USER DEFINED
001270 000000 $TMP17: .WORD 0 ;;USER DEFINED
001272 000000 $TMP20: .WORD 0 ;;USER DEFINED
001274 000000 $TMP21: .WORD 0 ;;USER DEFINED
001276 000000 $TMP22: .WORD 0 ;;USER DEFINED
001300 000000 $TMP23: .WORD 0 ;;USER DEFINED
001302 000000 $TIMES: 0 ;;MAX. NUMBER OF ITERATIONS
001304 000000 $ESCAPE: 0 ;;ESCAPE ON ERROR ADDRESS
001306 207 377 377 $BELL: .ASCII <207><377><377> ;;CODE FOR BELL
001312 077 $QUES: .ASCII /?/ ;;QUESTION MARK
001313 015 $CRLF: .ASCII <15> ;;CARRIAGE RETURN
001314 012 000 $LF: .ASCII <12> ;;LINE FEED
*****
.SBTTL APT MAILBOX-ETABLE
*****
.EVEN
001316 $MAIL: ;;APT MAILBOX
001316 000000 $MSGTY: .WORD AMSGTY ;;MESSAGE TYPE CODE
001320 000000 $FATAL: .WORD AFATAL ;;FATAL ERROR NUMBER
001322 000000 $TESTN: .WORD ATESTN ;;TEST NUMBER
001324 000000 $PASS: .WORD APASS ;;PASS COUNT
001326 000000 $DEVCT: .WORD ADEVCT ;;DEVICE COUNT
001330 000000 $UNIT: .WORD AUNIT ;;I/O UNIT NUMBER
001332 000000 $MSGAD: .WORD AMSGAD ;;MESSAGE ADDRESS
001334 000000 $MSGLG: .WORD AMGLG ;;MESSAGE LENGTH
001336 $ETABLE: ;;APT ENVIRONMENT TABLE
001336 000 $ENV: .BYTE AENV ;;ENVIRONMENT BYTE
001337 000 $ENVM: .BYTE AENVM ;;ENVIRONMENT MODE BITS
001340 000000 $SWREG: .WORD ASWREG ;;APT SWITCH REGISTER
001342 000000 $USWR: .WORD AUSWR ;;USER SWITCHES
001344 000000 $CPUOP: .WORD ACPUOP ;;CPU TYPE, OPTIONS
BITS 15-11=CPU TYPE
11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
11/70=06,PDQ=07,Q=10
BIT 10=REAL TIME CLOCK
BIT 9=FLOATING POINT PROCESSOR
BIT 8=MEMORY MANAGEMENT
001346 000 $MAMS1: .BYTE AMAMS1 ;;HIGH ADDRESS, M.S. BYTE
001347 000 $MTYP1: .BYTE AMTYP1 ;;MEM. TYPE, BLK#1
MEM. TYPE BYTE -- (HIGH BYTE)
900 NSEC CORE=001
*
```

```

                                300 NSEC BIPOLAR=002
                                500 NSEC MOS=003
001350 000000 $MADR1: .WORD AMADR1 ;;HIGH ADDRESS,BLK#1
                                MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
001352 000 $MAMS2: .BYTE AMAMS2 ;;HIGH ADDRESS,M.S. BYTE
001353 000 $SMTYP2: .BYTE AMTYP2 ;;MEM.TYPE,BLK#2
001354 000000 $MADR2: .WORD AMADR2 ;;MEM.LAST ADDRESS,BLK#2
001356 000 $MAMS3: .BYTE AMAMS3 ;;HIGH ADDRESS,M.S.BYTE
001357 000 $SMTYP3: .BYTE AMTYP3 ;;MEM.TYPE,BLK#3
001360 000000 $MADR3: .WORD AMADR3 ;;MEM.LAST ADDRESS,BLK#3
001362 000 $MAMS4: .BYTE AMAMS4 ;;HIGH ADDRESS,M.S.BYTE
001363 000 $SMTYP4: .BYTE AMTYP4 ;;MEM.TYPE,BLK#4
001364 000000 $MADR4: .WORD AMADR4 ;;MEM.LAST ADDRESS,BLK#4
001366 000000 $VECT1: .WORD AVECT1 ;;INTERRUPT VECTOR#1,BUS PRIORITY#1
001370 000000 $VECT2: .WORD AVECT2 ;;INTERRUPT VECTOR#2BUS PRIORITY#2
001372 000000 $BASE: .WORD ABASE ;;BASE ADDRESS OF EQUIPMENT UNDER TEST
001374 000000 $DEVN: .WORD ADEVN ;;DEVICE MAP
001376 000000 $CDW1: .WORD ACDW1 ;;CONTROLLER DESCRIPTION WORD#1
001400 000000 $CDW2: .WORD ACDW2 ;;CONTROLLER DESCRIPTION WORD#2
001402 000000 $DDW0: .WORD ADDW0 ;;DEVICE DESCRIPTOR WORD#0
001404 000000 $DDW1: .WORD ADDW1 ;;DEVICE DESCRIPTOR WORD#1
001406 000000 $DDW2: .WORD ADDW2 ;;DEVICE DESCRIPTOR WORD#2
001410 000000 $DDW3: .WORD ADDW3 ;;DEVICE DESCRIPTOR WORD#3
001412 000000 $DDW4: .WORD ADDW4 ;;DEVICE DESCRIPTOR WORD#4
001414 000000 $DDW5: .WORD ADDW5 ;;DEVICE DESCRIPTOR WORD#5
001416 000000 $DDW6: .WORD ADDW6 ;;DEVICE DESCRIPTOR WORD#6
001420 000000 $DDW7: .WORD ADDW7 ;;DEVICE DESCRIPTOR WORD#7
001422 000000 $DDW8: .WORD ADDW8 ;;DEVICE DESCRIPTOR WORD#8
001424 000000 $DDW9: .WORD ADDW9 ;;DEVICE DESCRIPTOR WORD#9
001426 000000 $DDW10: .WORD ADDW10 ;;DEVICE DESCRIPTOR WORD#10
001430 000000 $DDW11: .WORD ADDW11 ;;DEVICE DESCRIPTOR WORD#11
001432 000000 $DDW12: .WORD ADDW12 ;;DEVICE DESCRIPTOR WORD#12
001434 000000 $DDW13: .WORD ADDW13 ;;DEVICE DESCRIPTOR WORD#13
001436 000000 $DDW14: .WORD ADDW14 ;;DEVICE DESCRIPTOR WORD#14
001440 000000 $DDW15: .WORD ADDW15 ;;DEVICE DESCRIPTOR WORD#15
001442 $ETEND:
```


.SBTTL ERROR POINTER TABLE
:*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
:*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
:*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
:*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
:*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
:* EM :POINTS TO THE ERROR MESSAGE
:* DH :POINTS TO THE DATA HEADER
:* DT :POINTS TO THE DATA
:* DF :POINTS TO THE DATA FORMAT

		\$ERRTB:			MNUMBER
		.REPT			
1676	001442	000267			
1678	001442	040514	067106	071474	.WORD EM1,DH1,DT1,DF1
	001452	040546	067176	071532	.WORD EM2,DH2,DT2,DF2
	001462	040602	067106	071474	.WORD EM3,DH3,DT3,DF3
	001472	040707	067106	071474	.WORD EM4,DH4,DT4,DF4
	001502	041014	067106	071474	.WORD EM5,DH5,DT5,DF5
	001512	041121	067106	071474	.WORD EM6,DH6,DT6,DF6
	001522	041226	067106	071474	.WORD EM7,DH7,DT7,DF7
	001532	041333	067106	071474	.WORD EM10,DH10,DT10,DF10
	001542	041440	067106	071474	.WORD EM11,DH11,DT11,DF11
	001552	041547	067106	071474	.WORD EM12,DH12,DT12,DF12
	001562	041656	067106	071474	.WORD EM13,DH13,DT13,DF13
	001572	041772	067106	071474	.WORD EM14,DH14,DT14,DF14
	001602	042104	067106	071474	.WORD EM15,DH15,DT15,DF15
	001612	042216	067106	071474	.WORD EM16,DH16,DT16,DF16
	001622	042313	067237	071560	.WORD EM17,DH17,DT17,DF17
	001632	042370	067106	071600	.WORD EM20,DH20,DT20,DF20
	001642	042422	067312	071622	.WORD EM21,DH21,DT21,DF21
	001652	042454	067401	071644	.WORD EM22,DH22,DT22,DF22
	001662	042535	067106	071662	.WORD EM23,DH23,DT23,DF23
	001672	042612	067106	071662	.WORD EM24,DH24,DT24,DF24
	001702	042710	067106	071662	.WORD EM25,DH25,DT25,DF25
	001712	042775	067106	071662	.WORD EM26,DH26,DT26,DF26

:ITEM 27

001722	042710	067106	071662		.WORD	EM27,DH27,DT27,DF27
001732	043073	067106	071662	:ITEM 30	.WORD	EM30,DH30,DT30,DF30
001742	043145	067106	071662	:ITEM 31	.WORD	EM31,DH31,DT31,DF31
001752	042560	067106	071662	:ITEM 32	.WORD	EM32,DH32,DT32,DF32
001762	043212	067106	071662	:ITEM 33	.WORD	EM33,DH33,DT33,DF33
001772	043235	067106	071662	:ITEM 34	.WORD	EM34,DH34,DT34,DF34
002002	043267	067106	071662	:ITEM 35	.WORD	EM35,DH35,DT35,DF35
002012	043342	067106	071662	:ITEM 36	.WORD	EM36,DH36,DT36,DF36
002022	043410	067106	071662	:ITEM 37	.WORD	EM37,DH37,DT37,DF37
002032	043433	067106	071662	:ITEM 40	.WORD	EM40,DH40,DT40,DF40
002042	043465	067106	071662	:ITEM 41	.WORD	EM41,DH41,DT41,DF41
002052	043540	067106	071662	:ITEM 42	.WORD	EM42,DH42,DT42,DF42
002062	043671	067106	071662	:ITEM 43	.WORD	EM43,DH43,DT43,DF43
002072	044022	067106	071662	:ITEM 44	.WORD	EM44,DH44,DT44,DF44
002102	044070	067106	071662	:ITEM 45	.WORD	EM45,DH45,DT45,DF45
002112	044143	067106	071662	:ITEM 46	.WORD	EM46,DH46,DT46,DF46
002122	044220	067106	071662	:ITEM 47	.WORD	EM47,DH47,DT47,DF47
002132	044354	067106	071662	:ITEM 50	.WORD	EM50,DH50,DT50,DF50
002142	044427	067106	071662	:ITEM 51	.WORD	EM51,DH51,DT51,DF51
002152	044475	067106	071662	:ITEM 52	.WORD	EM52,DH52,DT52,DF52
002162	052325	067106	071734	:ITEM 53	.WORD	EM53,DH53,DT53,DF53
002172	052356	067106	071734	:ITEM 54	.WORD	EM54,DH54,DT54,DF54
002202	052273	067106	071734	:ITEM 55	.WORD	EM55,DH55,DT55,DF55
002212	052406	067106	071734	:ITEM 56	.WORD	EM56,DH56,DT56,DF56
002222	052477	067106	071734	:ITEM 57	.WORD	EM57,DH57,DT57,DF57
002232	052567	067106	071734	:ITEM 60	.WORD	EM60,DH60,DT60,DF60
002242	052671	067106	071734	:ITEM 61	.WORD	EM61,DH61,DT61,DF61
002252	053065	067106	071734	:ITEM 62	.WORD	EM62,DH62,DT62,DF62
002262	053261	067106	071734	:ITEM 63	.WORD	EM63,DH63,DT63,DF63

002272	053372	067106	071734	:ITEM 64	.WORD	EM64,DH64,DT64,DF64
002302	053511	067106	071734	:ITEM 65	.WORD	EM65,DH65,DT65,DF65
002312	053624	067106	071734	:ITEM 66	.WORD	EM66,DH66,DT66,DF66
002322	053673	067106	071734	:ITEM 67	.WORD	EM67,DH67,DT67,DF67
002332	053756	067106	071734	:ITEM 70	.WORD	EM70,DH70,DT70,DF70
002342	054007	067106	071734	:ITEM 71	.WORD	EM71,DH71,DT71,DF71
002352	054037	067106	071734	:ITEM 72	.WORD	EM72,DH72,DT72,DF72
002362	054037	067106	071734	:ITEM 73	.WORD	EM73,DH73,DT73,DF73
002372	054071	067106	071734	:ITEM 74	.WORD	EM74,DH74,DT74,DF74
002402	054200	067106	071734	:ITEM 75	.WORD	EM75,DH75,DT75,DF75
002412	054271	067106	071734	:ITEM 76	.WORD	EM76,DH76,DT76,DF76
002422	054361	067106	071734	:ITEM 77	.WORD	EM77,DH77,DT77,DF77
002432	054471	067106	071734	:ITEM 100	.WORD	EM100,DH100,DT100,DF100
002442	054554	067106	071734	:ITEM 101	.WORD	EM101,DH101,DT101,DF101
002452	054750	067106	071734	:ITEM 102	.WORD	EM102,DH102,DT102,DF102
002462	055144	067106	071734	:ITEM 103	.WORD	EM103,DH103,DT103,DF103
002472	055256	067106	071734	:ITEM 104	.WORD	EM104,DH104,DT104,DF104
002502	055423	067106	071734	:ITEM 105	.WORD	EM105,DH105,DT105,DF105
002512	055532	067106	071734	:ITEM 106	.WORD	EM106,DH106,DT106,DF106
002522	055641	067106	071734	:ITEM 107	.WORD	EM107,DH107,DT107,DF107
002532	055750	067106	071734	:ITEM 110	.WORD	EM110,DH110,DT110,DF110
002542	044565	067106	071662	:ITEM 111	.WORD	EM111,DH111,DT111,DF111
002552	044642	067106	071662	:ITEM 112	.WORD	EM112,DH112,DT112,DF112
002562	044720	067106	071662	:ITEM 113	.WORD	EM113,DH113,DT113,DF113
002572	044776	067106	071662	:ITEM 114	.WORD	EM114,DH114,DT114,DF114
002602	045055	067447	072022	:ITEM 115	.WORD	EM115,DH115,DT115,DF115
002612	045133	067447	072022	:ITEM 116	.WORD	EM116,DH116,DT116,DF116
002622	045212	067447	072022	:ITEM 117	.WORD	EM117,DH117,DT117,DF117
				:ITEM 120		

002632	045350	067447	072022		WORD	EM120,DH120,DT120,DF120
002642	045506	067447	072022	:ITEM 121	WORD	EM121,DH121,DT121,DF121
002652	045643	067447	072022	:ITEM 122	WORD	EM122,DH122,DT122,DF122
002662	046000	067106	071662	:ITEM 123	WORD	EM123,DH123,DT123,DF123
002672	046056	067106	071662	:ITEM 124	WORD	EM124,DH124,DT124,DF124
002702	046135	067106	071662	:ITEM 125	WORD	EM125,DH125,DT125,DF125
002712	046213	067106	071662	:ITEM 126	WORD	EM126,DH126,DT126,DF126
002722	046272	067447	072022	:ITEM 127	WORD	EM127,DH127,DT127,DF127
002732	046350	067447	072022	:ITEM 130	WORD	EM130,DH130,DT130,DF130
002742	046427	067447	072022	:ITEM 131	WORD	EM131,DH131,DT131,DF131
002752	046565	067106	071662	:ITEM 132	WORD	EM132,DH132,DT132,DF132
002762	046723	067447	072022	:ITEM 133	WORD	EM133,DH133,DT133,DF133
002772	047061	067447	072022	:ITEM 134	WORD	EM134,DH134,DT134,DF134
003002	047216	067106	071662	:ITEM 135	WORD	EM135,DH135,DT135,DF135
003012	047353	067447	072022	:ITEM 136	WORD	EM136,DH136,DT136,DF136
003022	047510	067447	072022	:ITEM 137	WORD	EM137,DH137,DT137,DF137
003032	047576	067447	072022	:ITEM 140	WORD	EM140,DH140,DT140,DF140
003042	044565	067447	072022	:ITEM 141	WORD	EM141,DH141,DT141,DF141
003052	044642	067447	072022	:ITEM 142	WORD	EM142,DH142,DT142,DF142
003062	047665	067447	072022	:ITEM 143	WORD	EM143,DH143,DT143,DF143
003072	047743	067447	072022	:ITEM 144	WORD	EM144,DH144,DT144,DF144
003102	050022	067106	071662	:ITEM 145	WORD	EM145,DH145,DT145,DF145
003112	050167	067106	071662	:ITEM 146	WORD	EM146,DH146,DT146,DF146
003122	050334	067106	071662	:ITEM 147	WORD	EM147,DH147,DT147,DF147
003132	050500	067106	071662	:ITEM 150	WORD	EM150,DH150,DT150,DF150
003142	050644	067447	072022	:ITEM 151	WORD	EM151,DH151,DT151,DF151
003152	050732	067447	072022	:ITEM 152	WORD	EM152,DH152,DT152,DF152
003162	046000	067447	072022	:ITEM 153	WORD	EM153,DH153,DT153,DF153
003172	046056	067447	072022	:ITEM 154	WORD	EM154,DH154,DT154,DF154

003202	051021	067447	072022	:ITEM 155	WORD	EM155,DH155,DT155,DF155
003212	051077	067447	072022	:ITEM 156	WORD	EM156,DH156,DT156,DF156
003222	051156	067106	071662	:ITEM 157	WORD	EM157,DH157,DT157,DF157
003232	051323	067447	072022	:ITEM 160	WORD	EM160,DH160,DT160,DF160
003242	051461	067106	071662	:ITEM 161	WORD	EM161,DH161,DT161,DF161
003252	051626	067106	071662	:ITEM 162	WORD	EM162,DH162,DT162,DF162
003262	051772	067447	072022	:ITEM 163	WORD	EM163,DH163,DT163,DF163
003272	052127	067106	071662	:ITEM 164	WORD	EM164,DH164,DT164,DF164
003302	056060	067447	072076	:ITEM 165	WORD	EM165,DH165,DT165,DF165
003312	056144	067447	072076	:ITEM 166	WORD	EM166,DH166,DT166,DF166
003322	056227	067447	072076	:ITEM 167	WORD	EM167,DH167,DT167,DF167
003332	056261	067447	072076	:ITEM 170	WORD	EM170,DH170,DT170,DF170
003342	056347	067447	072076	:ITEM 171	WORD	EM171,DH171,DT171,DF171
003352	056472	067447	072076	:ITEM 172	WORD	EM172,DH172,DT172,DF172
003362	056557	067447	072076	:ITEM 173	WORD	EM173,DH173,DT173,DF173
003372	056725	067447	072076	:ITEM 174	WORD	EM174,DH174,DT174,DF174
003402	057073	067447	072076	:ITEM 175	WORD	EM175,DH175,DT175,DF175
003412	057205	067447	072076	:ITEM 176	WORD	EM176,DH176,DT176,DF176
003422	057271	067546	072164	:ITEM 177	WORD	EM177,DH177,DT177,DF177
003432	057325	067447	072076	:ITEM 200	WORD	EM200,DH200,DT200,DF200
003442	057357	067447	072076	:ITEM 201	WORD	EM201,DH201,DT201,DF201
003452	057446	067447	072076	:ITEM 202	WORD	EM202,DH202,DT202,DF202
003462	057610	067447	072076	:ITEM 203	WORD	EM203,DH203,DT203,DF203
003472	057752	067447	072076	:ITEM 204	WORD	EM204,DH204,DT204,DF204
003502	060040	067447	072076	:ITEM 205	WORD	EM205,DH205,DT205,DF205
003512	060206	067447	072076	:ITEM 206	WORD	EM206,DH206,DT206,DF206
003522	060354	067647	072174	:ITEM 207	WORD	EM207,DH207,DT207,DF207
003532	060416	067737	072246	:ITEM 210	WORD	EM210,DH210,DT210,DF210
				:ITEM 211		

003542	060460	067737	072174	:ITEM 212	WORD	EM211,DH211,DT211,DF211
003552	060624	067647	072270	:ITEM 213	WORD	EM212,DH212,DT212,DF212
003562	061010	067647	072270	:ITEM 214	WORD	EM213,DH213,DT213,DF213
003572	061174	067647	072270	:ITEM 215	WORD	EM214,DH214,DT214,DF214
003602	061360	067647	072270	:ITEM 216	WORD	EM215,DH215,DT215,DF215
003612	061544	067737	072174	:ITEM 217	WORD	EM216,DH216,DT216,DF216
003622	061726	070000	072352	:ITEM 220	WORD	EM217,DH217,DT217,DF217
003632	061770	067607	072174	:ITEM 221	WORD	EM220,DH220,DT220,DF220
003642	062220	067737	072174	:ITEM 222	WORD	EM221,DH221,DT221,DF221
003652	062464	067607	072174	:ITEM 223	WORD	EM222,DH222,DT222,DF222
003662	062715	067737	072174	:ITEM 224	WORD	EM223,DH223,DT223,DF223
003672	063162	067607	072174	:ITEM 225	WORD	EM224,DH224,DT224,DF224
003702	063413	067737	072174	:ITEM 226	WORD	EM225,DH225,DT225,DF225
003712	063660	070053	072270	:ITEM 227	WORD	EM226,DH226,DT226,DF226
003722	064013	070142	072270	:ITEM 230	WORD	EM227,DH227,DT227,DF227
003732	064146	070053	072270	:ITEM 231	WORD	EM230,DH230,DT230,DF230
003742	064302	070142	072246	:ITEM 232	WORD	EM231,DH231,DT231,DF231
003752	060416	070142	072174	:ITEM 233	WORD	EM232,DH232,DT232,DF232
003762	064436	070231	072372	:ITEM 234	WORD	EM233,DH233,DT233,DF233
003772	064475	070272	072426	:ITEM 235	WORD	EM234,DH234,DT234,DF234
004002	064561	070360	072446	:ITEM 236	WORD	EM235,DH235,DT235,DF235
004012	064627	070420	072426	:ITEM 237	WORD	EM236,DH236,DT236,DF236
004022	064662	070272	072426	:ITEM 240	WORD	EM237,DH237,DT237,DF237
004032	064746	070506	072426	:ITEM 241	WORD	EM240,DH240,DT240,DF240
004042	065002	070231	072372	:ITEM 242	WORD	EM241,DH241,DT241,DF241
004052	065105	070506	072426	:ITEM 243	WORD	EM242,DH242,DT242,DF242
004062	065141	070231	072372	:ITEM 244	WORD	EM243,DH243,DT243,DF243
004072	065244	070231	072372	:ITEM 245	WORD	EM244,DH244,DT244,DF244
004102	065303	070231	072372		WORD	EM245,DH245,DT245,DF245

004112	044175	067106	071662	:ITEM 246	WORD	EM246,DH246,DT246,DF246
004122	065365	070576	072460	:ITEM 247	WORD	EM247,DH247,DT247,DF247
004132	065421	070643	072476	:ITEM 250	WORD	EM250,DH250,DT250,DF250
004142	065453	070643	072476	:ITEM 251	WORD	EM251,DH251,DT251,DF251
004152	065506	067176	072510	:ITEM 252	WORD	EM252,DH252,DT252,DF252
004162	065577	067106	072522	:ITEM 253	WORD	EM253,DH253,DT253,DF253
004172	065663	067106	072522	:ITEM 254	WORD	EM254,DH254,DT254,DF254
004202	065750	067106	072522	:ITEM 255	WORD	EM255,DH255,DT255,DF255
004212	066036	067106	072522	:ITEM 256	WORD	EM256,DH256,DT256,DF256
004222	066125	067106	072522	:ITEM 257	WORD	EM257,DH257,DT257,DF257
004232	066213	067106	072522	:ITEM 260	WORD	EM260,DH260,DT260,DF260
004242	066302	067106	072522	:ITEM 261	WORD	EM261,DH261,DT261,DF261
004252	066372	067106	072522	:ITEM 262	WORD	EM262,DH262,DT262,DF262
004262	066463	067106	072522	:ITEM 263	WORD	EM263,DH263,DT263,DF263
004272	066550	067106	072522	:ITEM 264	WORD	EM264,DH264,DT264,DF264
004302	066635	067106	072522	:ITEM 265	WORD	EM265,DH265,DT265,DF265
004312	066722	070703	072510	:ITEM 266	WORD	EM266,DH266,DT266,DF266
004322	067023	067447	072076	:ITEM 267	WORD	EM267,DH267,DT267,DF267

1679
1680
1681

.SBTTL ACT11 HOOKS

:HOOKS REQUIRED BY ACT11

000046	004332	\$SVPC=.	:SAVE PC
	000046	.=46	
000052	034024	\$ENDAD	::1)SET LOC.46 TO ADDRESS OF \$ENDAD IN .SEOP
	000052	.=52	
	000000	.WORD 0	::2)SET LOC.52 TO ZERO
	004332	.=\$SVPC	:: RESTORE PC

1682

.SBTTL APT PARAMETER BLOCK

:SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT

000024	004332	.\$X=.	::SAVE CURRENT LOCATION
	000024	.=24	::SET POWER FAIL TO POINT TO START OF PROGRAM
	000200	200	::FOR APT START UP
	000044	.=44	::POINT TO APT INDIRECT ADDRESS PNTR.
000044	004332	\$.APTHDR	::POINT TO APT HEADER BLOCK
	004332	.=\$X	::RESET LOCATION COUNTER

004332
004332 000000
004334 001316
004336 000010
004340 000040
004342 000000
004344 000052

1683
1684
1685 004346

004346 012706 001100
004352 005026
004354 022706 001140
004360 001374
004362 012706 001100

004366 012737 034110 000020
004374 012737 000340 000022
004402 012737 034426 000030
004410 012737 000340 000032
004416 012737 036570 000034
004424 012737 000340 000036
004432 012737 036654 000024
004440 012737 000340 000026
004446 013737 033404 033372
004454 005037 001302
004460 005037 001304
004464 112737 000001 001115

004472 012737 034070 000014
004500 012737 000340 000016
004506 012737 000002 034070
004514 012737 004542 000010
004522 005046
004524 012746 004532
004530 000006
004532 012737 000006 034070 64\$:
004540 000402
004542 062706 000010
004546 012737 000012 000010 65\$:
004554 005037 034076 66\$:
004560 012737 004560 001106
004566 012737 004566 001110

004574 013746 000004
004600 012737 004634 000004
004606 012737 177570 001140
004614 012737 177570 001142
004622 022777 177777 174310
004630 001012

```
*****  
: SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC  
: INTERFACE SPEC.  
$APTHD:  
$HIBTS: .WORD 0 ;; TWO HIGH BITS OF 18 BIT MAILBOX ADDR.  
$MADR: .WORD $MAIL ;; ADDRESS OF APT MAILBOX (BITS 0-15)  
$STMT: .WORD 10 ;; RUN TIM OF LONGEST TEST  
$PASTM: .WORD 40 ;; RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)  
$UNITM: .WORD 0 ;; ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT  
 .WORD $ETEND-$MAIL/2 ;; LENGTH MAILBOX-ETABLE(WORDS)  
  
START:  
.SBTTL INITIALIZE THE COMMON TAGS  
: CLEAR THE COMMON TAGS ($CMTAG) AREA  
MOV # $CMTAG, R6 ;; FIRST LOCATION TO BE CLEARED  
CLR (R6)+ ;; CLEAR MEMORY LOCATION  
CMP # $SWR, R6 ;; DONE?  
BNE .-6 ;; LOOP BACK IF NO  
MOV # $STACK, SP ;; SETUP THE STACK POINTER  
: INITIALIZE A FEW VECTORS  
MOV # $SCOPE, @IOTVEC ;; IOT VECTOR FOR SCOPE ROUTINE  
MOV # 340, @IOTVEC+2 ;; LEVEL 7  
MOV # $ERROR, @EMTVEC ;; EMT VECTOR FOR ERROR ROUTINE  
MOV # 340, @EMTVEC+2 ;; LEVEL 7  
MOV # $TRAP, @TRAPVEC ;; TRAP VECTOR FOR TRAP CALLS  
MOV # 340, @TRAPVEC+2 ;; LEVEL 7  
MOV # $PWRDN, @PWRVEC ;; POWER FAILURE VECTOR  
MOV # 340, @PWRVEC+2 ;; LEVEL 7  
MOV $ENDCT, $EOPCT ;; SETUP END-OF-PROGRAM COUNTER  
CLR $TIMES ;; INITIALIZE NUMBER OF ITERATIONS  
CLR $ESCAPE ;; CLEAR THE ESCAPE ON ERROR ADDRESS  
MOVB # 1, $ERMAX ;; ALLOW ONE ERROR PER TEST  
: INITIALIZE THE 'T-BIT' TRAP VECTOR. THEN LOAD LOCATION '$RTRN', IN  
: THE 'END-OF-PASS' ($EOP) ROUTINE, WITH A 'RTI' OR 'RTT'.  
MOV # $RTRN, @TBITVEC ;; SET 'T' BIT VECTOR TO $RTRN  
MOV # 340, @TBITVEC+2 ;; LEVEL 7  
MOV # RTI, $RTRN ;; SET $RTRN TO A RTI  
MOV # 65$, @RESVEC ;; TRY TO DO A RTT  
CLR -(SP) ;; DUMMY PS  
MOV # 64$, -(SP) ;; AND PC  
RTT ;; TRY THE RTT  
64$: MOV # RTT, $RTRN ;; RTT IS LEGAL--SET $RTRN TO A RTT  
BR 66$  
65$: ADD # 10, SP ;; RTT ILLEGAL--CLEAN OFF THE STACK  
66$: MOV # RESVEC+2, @RESVEC ;; RESTORE TRAP CATCHER  
CLR $TBIT ;; CLEAR 'T' BIT SWITCH  
MOV # ., $LPADR ;; INITIALIZE THE LOOP ADDRESS FOR SCOPE  
MOV # ., $LPERR ;; SETUP THE ERROR LOOP ADDRESS  
: SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS  
: EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.  
MOV @ERRVEC, -(SP) ;; SAVE ERROR VECTOR  
MOV # 67$, @ERRVEC ;; SET UP ERROR VECTOR  
MOV # $DSWR, $SWR ;; SETUP FOR A HARDWARE SWICH REGISTER  
MOV # $DDISP, $DISPLAY ;; AND A HARDWARE DISPLAY REGISTER  
CMP # -1, @SWR ;; TRY TO REFERENCE HARDWARE SWR  
BNE 69$ ;; BRANCH IF NO TIMEOUT TRAP OCCURRED
```

```

004632 000403
004634 012716 004642
004640 000002
004642 012737 000176 001140
004650 012737 000174 001142
004656 012637 000004
004662 005037 001324
004666 132737 000200 001337
004674 001403
004676 012737 001340 001140
004704
1686
004704 005227 177777
004710 001047
004712 022737 034024 000042
004720 001443
004722 104401 004770
004726 005737 000042
004732 001012
004734 123727 001336 000001
004742 001406
004744 023727 001140 000176
004752 001005
004754 104405
004756 000403
004760 112737 000001 001134
004766
004766 000420
005030
1687 005030 104401 005036
005034 000434
005126
1688 005126 104401 005134
005132 000426
005210
1689 005210 005037 034104
1690 005214
1691
1692
RR 68$
MOV #68$, (SP)
RTI
MOV #SWREG, SWR
MOV #DISPREG, DISPLAY
MOV (SP)+, @#ERRVEC
CLR $PASS
BITB #APTSIZE, $ENVM
BEQ 70$
MOV #SSWREG, SWR
::AND THE HARDWARE SWR IS NOT = -1
::BRANCH IF NO TIMEOUT
::SET UP FOR TRAP RETURN
::POINT TO SOFTWARE SWR
::RESTORE ERROR VECTOR
::CLEAR PASS COUNT
::TEST USER SIZE UNDER APT
::YES, USE NON-APT SWITCH
::NO, USE APT SWITCH REGISTER
70$:
.SBTTL TYPE PROGRAM NAME
::TYPE NAME OF THE PROGRAM IF FIRST PASS
INC #-1
BNE 71$
CMP #SENDAD, @#42
BEQ 71$
TYPE ,72$
.SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
TST @#42
BNE 73$
CMPB $ENV, #1
BEQ 73$
CMP SWR, #SWREG
BNE 74$
GTSWR
BR 74$
MOV #1, $AUTOB
73$:
74$:
BR 71$
::72$: .ASCIZ <CRLF>*CKFPBCO FP11F FLTG PNT PRT B*<CRLF>
71$:
TYPE ,76$
BR 75$
::76$: .ASCIZ !EOP MESSAGES WILL PRINT EVERY 2000 PASSES (15 SECONDS)!<CRLF>
75$:
TYPE ,78$
BR 77$
::78$: .ASCIZ !HIT ANY KEY TO DISABLE/ENABLE EOP MESSAGES!<CRLF>
77$:
CLR EPENDS
LOOP:
;CLR EOP ENABLE/DISABLE FLAG ;DPM002

```

1703

```
.SBTTL TEST # 1 - ROUND\TRUNK TEST  
*****  
*TEST 1 ROUND\TRUNK TEST  
*  
* THIS IS A TEST OF THE ROUND\TRUNK  
* FLOWS. IN PARTICULAR TWO THINGS ARE TESTED:  
* FIRST A CONDITION IN WHICH ROUNDING  
* RESULTS IN THE NEED FOR RENORMALIZATION, AND  
* SECOND THE PSW CONDITION CODES N AND  
* Z BIT COMBINATIONS  
*  
*****
```

```
005214 000004  
1704  
1705  
1706  
1707 005216  
005216 104413  
1708 005220 012704 003200  
1709 005224 170104  
1710 005226 012737 005246 001236  
1711 005234 012700 006776  
1712 005240 172410  
1713 005242 012700 007006  
1714 005246 172010  
1715 005250 170205  
1716 005252 012700 006766  
1717 005256 174010  
1718 005260 012701 007016  
1719 005264 012702 000004  
1720 005270 022021  
1721 005272 001415  
1722 005274 012700 006766  
1723 005300 012701 007026  
1724 005304 012702 000004  
1725 005310 022021  
1726 005312 001402  
1727 005314 000137 006006  
1728 005320 077205  
1729 005322 000137 006054  
1730 005326 077220  
1731 005330 020405  
1732 005332 001402  
1733 005334 000137 006122
```

```
TST1: SCOPE  
;ROUND AND NORMALIZE TEST  
HH1: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
MOV #3200,R4 ;SET FIU, FIV, AND FD  
LDFPS R4  
MOV #HH2,$TMP2  
MOV #HHP0,R0 ;SET ACO OPERAND  
LDD (R0),ACO  
MOV #HHP1,R0 ;FSPC  
HH2: ADDD (R0),ACO ;TEST INSTRUCTION  
STFPS R5 ;GET FPS  
MOV #HHDATO,R0 ;GET THE RESULT  
STD ACO,(R0)  
MOV #HHP2,R1 ;IS IT CORRECT  
MOV #4,R2  
HH3: CMP (R0)+,(R1)+  
BEQ HH6  
MOV #HHDATO,R0 ;DID FLOW GO  
MOV #HHP3,R1 ;FROM STATE 663  
MOV #4,R2 ;TO 313 INSTEAD  
HH4: CMP (R0)+,(R1)+ ;OF TO 353  
BEQ HH5  
JMP HHERO  
HH5: SOB R2,HH4  
JMP HHER1  
HH6: SOB R2,HH3  
CMP R4,R5 ;FPS CORRECT?  
BEQ HH7  
JMP HHERO0
```

```
1734  
1735  
1736  
1737  
1738
```

```
;THIS IS A TEST OF THE ABILITY  
;OF NORMALIZE TO PRODUCE A ZERO EXP. AND  
;OF THE R\T ALGORITHM TO PORPERLY SET THE FPS
```

```
1739 005340  
005340 104413  
1740 005342 012704 043200  
1741  
1742 005346 170104  
1743 005350 012737 005376 001236  
1744 005356 012737 006716 000244  
1745 005364 012700 007046
```

```
HH7: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
MOV #043200,R4 ;SET FIU,FIV,AND FD  
;FID  
LDFPS R4  
MOV #HH8,$TMP2 ;IN CASE UNDERFLOW  
MOV #HHTRAP,FPVECT ;TRAP OCCURS  
MOV #HHP5,R0 ;SET ACO OPERAND
```


1746	005370	172410			LDD	(R0),ACO	
1747	005372	012700	007056		MOV	#HHP6,R0	:FSPC
1748	005376	172010		HH8:	ADDD	(R0),ACO	:TEST INSTRUCTION
1749	005400	170205			STFPS	R5	:GET FPS
1750	005402	012700	006766		MOV	#HHDATO,R0	:GET THE RESULT
1751	005406	174010			STD	ACO,(R0)	
1752	005410	012701	007036		MOV	#HHP4,R1	:IS IT CORRECT
1753	005414	012702	000004		MOV	#4,R2	
1754	005420	022021		HH9:	CMP	(R0)+,(R1)+	
1755	005422	001402			BEQ	HH10	
1756	005424	000137	006170		JMP	HHER2	
1757	005430	077205		HH10:	SOB	R2,HH9	
1758	005432	052704	100004		BIS	#100004,R4	:FPS CORRECT?
1759	005436	020405			CMP	R4,R5	
1760	005440	001402			BEQ	HH11	
1761	005442	000137	006236		JMP	HHER3	
1762							
1763							
1764	005446						
	005446	104413		HH11:	LPERR		:SET UP THE LOOP ON ERROR ADDRESS. :SET FIV, FIV, AND FD
1765							
1766	005450	012704	043200		MOV	#043200,R4	
1767	005454	170104			LDFPS	R4	
1768	005456	012737	005476	001236	MOV	#HH12,\$TMP2	
1769	005464	012700	007076		MOV	#HHP8,R0	:SET ACO OPERAND
1770	005470	172410			LDD	(R0),ACO	
1771	005472	012700	007106		MOV	#HHP9,R0	:FSPC
1772	005476	172010		HH12:	ADDD	(R0),ACO	:TEST INSTRUCTION
1773	005500	170205			STFPS	R5	:GET FPS
1774	005502	012700	006766		MOV	#HHDATO,R0	:GET THE RESULT
1775	005506	174010			STD	ACO,(R0)	
1776	005510	012701	007066		MOV	#HHP7,R1	:IS IT CORRECT
1777	005514	012702	000004		MOV	#4,R2	
1778	005520	022021		HH13:	CMP	(R0)+,(R1)+	
1779	005522	001415			BEQ	HH16	
1780	005524	012700	006766		MOV	#HHDATO,R0	
1781	005530	012701	007036		MOV	#HHP4,R1	
1782	005534	012702	000004		MOV	#4,R2	
1783	005540	022021		HH14:	CMP	(R0)+,(R1)+	
1784	005542	001402			BEQ	HH15	
1785	005544	000137	006304		JMP	HHER4	
1786	005550	077205		HH15:	SOB	R2,HH14	
1787	005552	000137	006352		JMP	HHER5	
1788	005556	077220		HH16:	SOB	R2,HH13	
1789	005560	052704	100014		BIS	#100014,R4	:FPS CORRECT?
1790	005564	020405			CMP	R4,R5	
1791	005566	001402			BEQ	HH17	
1792	005570	000137	006420		JMP	HHER6	
1793							
1794	005574						
	005574	104413		HH17:	LPERR		:SET UP THE LOOP ON ERROR ADDRESS. :SET FIV, FIV, AND FD
1795	005576	012704	000200		MOV	#00200,R4	
1796	005602	170104			LDFPS	R4	
1797	005604	012737	005632	001236	MOV	#HH18,\$TMP2	
1798	005612	012737	037450	000244	MOV	#FPSPUR,FPVECT	
1799	005620	012700	007076		MOV	#HHP8,R0	:SET ACO OPERAND
1800	005624	172410			LDD	(R0),ACO	

:THIS IS A TEST OF THE R\T ALGORITHM'S
 :ABILITY TO SET BOTH N AND Z ON A - 0 RESULT.

:TEST THAT CC ARE CLEARED BY R\T

1801	005626	012700	007076			MOV	#HHP8,R0		:FSPC
1802	005632	172010				HH18: ADDD	(R0),ACO		:TEST INSTRUCTION
1803	005634	170205				STFPS	R5		:GET FPS
1804	005636	012700	006766			MOV	#HHDATA,R0		:GET THE RESULT
1805	005642	174010				STD	ACO,(R0)		
1806	005644	012701	007116			MOV	#HHP10,R1		:IS IT CORRECT
1807	005650	012702	000004			MOV	#4,R2		
1808	005654	022021				HH19: CMP	(R0)+,(R1)+		
1809	005656	001402				BEQ	HH20		
1810	005660	000137	006466			JMP	HHER7		
1811	005664	077205				HH20: SOB	R2,HH19		
1812	005666	052704	000000			BIS	#00000,R4		:FPS CORRECT?
1813	005672	020405				CMP	R4,R5		
1814	005674	001402				BEQ	HH21		
1815	005676	000137	006534			JMP	HHER8		
1816									
1817	005702					:TEST THAT N IS SET BY R\T			
	005702	104413				HH21: LPERR			:SET UP THE LOOP ON ERROR ADDRESS.
1818	005704	012704	003200			MOV	#3200,R4		:SET FIV, FIV, AND FD
1819	005710	170104				LDFPS	R4		
1820	005712	012737	005732	001236		MOV	#HH22,\$TMP2		
1821	005720	012700	007046			MOV	#HHP5,R0		:SET ACO OPERAND
1822	005724	172410				LDD	(R0),ACO		
1823	005726	012700	007046			MOV	#HHP5,R0		:FSPC
1824	005732	172010				HH22: ADDD	(R0),ACO		:TEST INSTRUCTION
1825	005734	170205				STFPS	R5		:GET FPS
1826	005736	012700	006766			MOV	#HHDATA,R0		:GET THE RESULT
1827	005742	174010				STD	ACO,(R0)		
1828	005744	012701	007126			MOV	#HHP11,R1		:IS IT CORRECT
1829	005750	012702	000004			MOV	#4,R2		
1830	005754	022021				HH23: CMP	(R0)+,(R1)+		
1831	005756	001402				BEQ	HH24		
1832	005760	000137	006602			JMP	HHER9		
1833	005764	077205				HH24: SOB	R2,HH23		
1834	005766	052704	000010			BIS	#10,R4		
1835	005772	020405				CMP	R4,R5		:FPS CORRECT?
1836	005774	001402				BEQ	HH25		
1837	005776	000137	006650			JMP	HHER10		
1838	006002	000137	007136			HH25: JMP	HHDONE		
1839	006006					HHER0: MOV	R5,\$TMP10		
	006012	010537	001252			MOV	R4,\$TMP11		
	006016	010437	001254			MOV	#HHP1,\$TMP3		
	006024	012737	007006	001240		MOV	#HHP0,\$TMP4		
	006032	012737	006776	001242		MOV	#HHDATA,\$TMP5		
	006040	012737	006766	001244		MOV	#HHP2,\$TMP6		
	006046	104207	007016	001246		1\$: ERROR	+207		
	006050	000137	007136			JMP	HHDONE		
1840	006054					HHER1: MOV	R5,\$TMP10		
	006054	010537	001252			MOV	R4,\$TMP11		
	006060	010437	001254			MOV	#HHP1,\$TMP3		
	006064	012737	007006	001240		MOV	#HHP0,\$TMP4		
	006072	012737	006776	001242		MOV	#HHDATA,\$TMP5		
	006100	012737	006766	001244		MOV	#HHP2,\$TMP6		
	006106	012737	007016	001246		1\$: ERROR	+211		
	006114	104211				JMP	HHDONE		
	006116	000137	007136						

1841	006122				HHER00:	MOV	R5,\$TMP10
	006122	010537	001252			MOV	R4,\$TMP11
	006126	010437	001254			MOV	#HHP1,\$TMP3
	006132	012737	007006	001240		MOV	#HHP0,\$TMP4
	006140	012737	006776	001242		MOV	#HHDATA0,\$TMP5
	006146	012737	006766	001244		MOV	#HHP2,\$TMP6
	006154	012737	007016	001246		1\$:	ERROR
	006162	104210					+210
	006164	000137	007136			JMP	HHDONE
1842	006170				HHER2:	MOV	R5,\$TMP10
	006170	010537	001252			MOV	R4,\$TMP11
	006174	010437	001254			MOV	#HHP6,\$TMP3
	006200	012737	007056	001240		MOV	#HHP5,\$TMP4
	006206	012737	007046	001242		MOV	#HHDATA0,\$TMP5
	006214	012737	006766	001244		MOV	#HHP4,\$TMP6
	006222	012737	007036	001246		1\$:	ERROR
	006230	104207					+207
	006232	000137	007136			JMP	HHDONE
1843	006236				HHER3:	MOV	R5,\$TMP10
	006236	010537	001252			MOV	R4,\$TMP11
	006242	010437	001254			MOV	#HHP6,\$TMP3
	006246	012737	007056	001240		MOV	#HHP5,\$TMP4
	006254	012737	007046	001242		MOV	#HHDATA0,\$TMP5
	006262	012737	006766	001244		MOV	#HHP4,\$TMP6
	006270	012737	007036	001246		1\$:	ERROR
	006276	104214					+214
	006300	000137	007136			JMP	HHDONE
1844	006304				HHER4:	MOV	R5,\$TMP10
	006304	010537	001252			MOV	R4,\$TMP11
	006310	010437	001254			MOV	#HHP9,\$TMP3
	006314	012737	007106	001240		MOV	#HHP8,\$TMP4
	006322	012737	007076	001242		MOV	#HHDATA0,\$TMP5
	006330	012737	006766	001244		MOV	#HHP7,\$TMP6
	006336	012737	007066	001246		1\$:	ERROR
	006344	104207					+207
	006346	000137	007136			JMP	HHDONE
1845	006352				HHER5:	MOV	R5,\$TMP10
	006352	010537	001252			MOV	R4,\$TMP11
	006356	010437	001254			MOV	#HHP9,\$TMP3
	006362	012737	007106	001240		MOV	#HHP8,\$TMP4
	006370	012737	007076	001242		MOV	#HHDATA0,\$TMP5
	006376	012737	006766	001244		MOV	#HHP7,\$TMP6
	006404	012737	007066	001246		1\$:	ERROR
	006412	104216					+216
	006414	000137	007136			JMP	HHDONE
1846	006420				HHER6:	MOV	R5,\$TMP10
	006420	010537	001252			MOV	R4,\$TMP11
	006424	010437	001254			MOV	#HHP9,\$TMP3
	006430	012737	007106	001240		MOV	#HHP8,\$TMP4
	006436	012737	007076	001242		MOV	#HHDATA0,\$TMP5
	006444	012737	006766	001244		MOV	#HHP7,\$TMP6
	006452	012737	007066	001246		1\$:	ERROR
	006460	104215					+215
	006462	000137	007136			JMP	HHDONE
1847	006466				HHER7:	MOV	R5,\$TMP10
	006466	010537	001252			MOV	R4,\$TMP11
	006472	010437	001254				

006476	012737	007076	001240	MOV	#HHP8,\$TMP3	
006504	012737	007076	001242	MOV	#HHP8,\$TMP4	
006512	012737	006766	001244	MOV	#HHDATO,\$TMP5	
006520	012737	007116	001246	MOV	#HHP10,\$TMP6	
006526	104207			1\$:	ERROR	+207
006530	000137	007136			JMP	HHDONE
1848 006534				HHER8:		
006534	010537	001252		MOV	R5,\$TMP10	
006540	010437	001254		MOV	R4,\$TMP11	
006544	012737	007076	001240	MOV	#HHP8,\$TMP3	
006552	012737	007076	001242	MOV	#HHP8,\$TMP4	
006560	012737	006766	001244	MOV	#HHDATO,\$TMP5	
006566	012737	007116	001246	MOV	#HHP10,\$TMP6	
006574	104212			1\$:	ERROR	+212
006576	000137	007136			JMP	HHDONE
1849 006602				HHER9:		
006602	010537	001252		MOV	R5,\$TMP10	
006606	010437	001254		MOV	R4,\$TMP11	
006612	012737	007046	001240	MOV	#HHP5,\$TMP3	
006620	012737	007046	001242	MOV	#HHP5,\$TMP4	
006626	012737	006766	001244	MOV	#HHDATO,\$TMP5	
006634	012737	007126	001246	MOV	#HHP11,\$TMP6	
006642	104207			1\$:	ERROR	+207
006644	000137	007136			JMP	HHDONE
1850 006650				HHER10:		
006650	010537	001252		MOV	R5,\$TMP10	
006654	010437	001254		MOV	R4,\$TMP11	
006660	012737	007046	001240	MOV	#HHP5,\$TMP3	
006666	012737	007046	001242	MOV	#HHP5,\$TMP4	
006674	012737	006766	001244	MOV	#HHDATO,\$TMP5	
006702	012737	007126	001246	MOV	#HHP11,\$TMP6	
006710	104213			1\$:	ERROR	+213
006712	000137	007136			JMP	HHDONE
1851 006716	013703	001236		HHTRAP:	MOV	\$TMP2,R3
1852 006722	062703	000002			ADD	#2,R3
1853 006726	020316				CMP	R3,(SP)
1854 006730	001402				BEQ	1\$
1855 006732	000137	037450			JMP	FSPUR
1856 006736	011637	001236		1\$:	MOV	(SP),\$TMP2
1857						
1858 006742	022626				CMP	(SP)+,(SP)+
1859 006744	170201				STFPS	R1
1860 006746	010137	001240			MOV	R1,\$TMP3
1861 006752	170301				STST	R1
1862 006754	010137	001242			MOV	R1,\$TMP4
1863 006760	104217			2\$:	ERROR	+217
1864 006762	000137	007136			JMP	HHDONE
1865 006766	000000			HHDATO:	0	
1866 006770	000000				0	
1867 006772	000000				0	
1868 006774	000000				0	
1869 006776	000452			HHP0:	452	
1870 007000	125252				125252	
1871 007002	125252				125252	
1872 007004	125253				125253	
1873 007006	000252			HHP1:	252	
1874 007010	125252				125252	

:WAS THE TRAP TO 264
 :ON THE INSTRUCTION
 :BEING TESTED?

:FAILURE OF FPS INTERRUPT
 :DISABLE BIT (FID=1)
 :TO INHIBIT TRAP.

1875	007012	125252		125252
1876	007014	125252		125252
1877	007016	000600	HHP2:	600
1878	007020	000000		0
1879	007022	000000		0
1880	007024	000000		0
1881	007026	000400	HHP3:	400
1882	007030	000000		0
1883	007032	000000		0
1884	007034	000000		0
1885	007036	000000	HHP4:	0
1886	007040	000000		0
1887	007042	000000		0
1888	007044	000000		0
1889	007046	100200	HHP5:	100200
1890	007050	000000		0
1891	007052	000000		0
1892	007054	000000		0
1893	007056	000300	HHP6:	300
1894	007060	000000		0
1895	007062	000000		0
1896	007064	000000		0
1897	007066	100000	HHP7:	100000
1898	007070	000000		0
1899	007072	000000		0
1900	007074	000000		0
1901	007076	000200	HHP8:	200
1902	007100	000000		0
1903	007102	000000		0
1904	007104	000000		0
1905	007106	100300	HHP9:	100300
1906	007110	000000		0
1907	007112	000000		0
1908	007114	000000		0
1909	007116	000400	HHP10:	400
1910	007120	000000		0
1911	007122	000000		0
1912	007124	000000		0
1913	007126	100400	HHP11:	100400
1914	007130	000000		0
1915	007132	000000		0
1916	007134	000000		0
1917	007136		HHDONE:	
	007136	104412		RSETUP

;HHP0 + HHP1 WITH
;PROPER NORMALIZATION

;HHP0 + HHP1 WITH
;BAD NORMALIZATION

;HHP7 = HHP8 + HHP9
; = HHP5 + HHP6

;HHP10 = HHP8 + HHP8

;HHP11 = HHP5 + HHP5

;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

1918
1932

1933

```
.SBTTL TEST # 2 - OVER\UNDER TEST
:*****
:*TEST 2 OVER\UNDER TEST
:*
:*THIS IS A PARTIAL TEST OF THE OVER\UNDER
:*FLOWS. ONE OVERFLOW AND TWO UNDERFLOW
:*CONDITIONS ARE CHECKED. THE REMAINING
:*UNDERFLOW COND. AND THE REMAINING OVERFLOW
:*COND. WILL BE CHECKED LATER USING THE
:*XXX INSTRUCTION. HERE EACH CONDITION TESTED
:*IS CHECKED BOTH WITH TRAPS ENABLED
:*(FIU=1 OR FIV=1) AND ALSO WITH TRAPS
:*DISABLED (FIU=0 OR FIV=0).
:*
:*****
```

```
007140 000004
1934
1935
1936 007142
007142 104413
1937 007144 012704 000200
1938 007150 170104
1939 007152 012737 007200 001236
1940 007160 012737 010232 000244
1941 007166 012700 012004
1942 007172 172410
1943 007174 012700 012004
1944 007200 172010
1945 007202 170205
1946 007204 012700 011734
1947 007210 174010
1948 007212 012701 012014
1949 007216 012702 000004
1950 007222 022021
1951 007224 001402
1952 007226 000137 010330
1953 007232 077205
1954 007234 052704 000006
1955 007240 020405
1956 007242 001402
1957 007244 000137 010376
1958
1959
1960 007250
007250 104413
1961 007252 012704 001200
1962 007256 170104
1963 007260 012737 007306 001236
1964 007266 012737 007324 000244
1965 007274 012700 012004
1966 007300 172410
1967 007302 012700 012004
1968 007306 172010
1969 007310 170000
1970 007312 012700 011734
1971 007316 174010
1972 007320 000137 010444
```

```
TST2: SCOPE
:TEST OVERFLOW CONDITION WITH TRAP DISABLER FIV=0
GG1:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
MOV #200,R4 ;CLEAR FIU, FIV, AND SET FD
LDFPS R4
MOV #GG2,$TMP2
MOV #GGER0,FPVECT
MOV #GGP5,R0 ;SET ACO OPERAND
LDD (R0),ACO
MOV #GGP5,R0 ;FSRC
GG2: ADDD (R0),ACO ;TEST INSTRUCTION
STFPS R5 ;GET FPS
MOV #GGDAT0,R0 ;GET THE RESULT
STD ACO,(R0)
MOV #GGP6,R1 ;IS IT CORRECT
MOV #4,R2
GG3: CMP (R0)+,(R1)+
BEQ GG4
JMP GGER1
GG4: SOB R2,GG3
BIS #6,R4 ;FPS CORRECT?
CMP R4,R5
BEQ GG5
JMP GGER2
;TEST OVERFLOW WITH TRAPS ENABLED
:FIV = 1
GG5:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
MOV #1200,R4 ;CLEAR FIU, SET FIV, AND FD
LDFPS R4
MOV #GG6,$TMP2
MOV #GG7,FPVECT
MOV #GGP5,R0 ;SET ACO OPERAND
LDD (R0),ACO
MOV #GGP5,R0 ;FSRC
GG6: ADDD (R0),ACO ;TEST INSTRUCTION
CFCC
MOV #GGDAT0,R0
STD ACO,(R0)
JMP GGER3
```

1973	007324	013703	001236		GG7:	MOV	\$TMP2,R3	
1974	007330	062703	000002			ADD	#2,R3	
1975	007334	020316				CMP	R3,(SP)	
1976	007336	001402				BEQ	1\$	
1977	007340	000137	037450			JMP	FPSPUR	
1978	007344	011637	001236		1\$:	MOV	(SP),\$TMP2	
1979	007350	022626				CMP	(SP)+,(SP)+	
1980	007352	170205				STFPS	R5	
1981	007354	012700	011734			MOV	#GGDATO,R0	;GET THE RESULT
1982	007360	174010				STD	ACO,(R0)	
1983	007362	012701	012014			MOV	#GGP6,R1	;IS IT CORRECT
1984	007366	012702	000004			MOV	#4,R2	
1985	007372	022021			GG8:	CMP	(R0)+,(R1)+	
1986	007374	001402				BEQ	GG9	
1987	007376	000137	010512			JMP	GGER4	
1988	007402	077205			GG9:	SOB	R2,GG8	
1989	007404	052704	100006			BIS	#100006,R4	
1990	007410	020405				CMP	R4,R5	;FPS CORRECT?
1991	007412	001402				BEQ	1\$	
1992	007414	000137	010562			JMP	GGER6	
1993	007420	012704	000010		1\$:	MOV	#10,R4	
1994					;CHECK	FEC		
1995	007424	170305				STST	R5	
1996	007426	020405				CMP	R4,R5	
1997	007430	001402				BEQ	GG10	
1998	007432	000137	010514			JMP	GGER5	
1999					;CHECK	UNDER FLOW CONDITION WITH		
2000					;TRAPS	DISABLED (FIU = 0)		
2001	007436				GG10:			
	007436	104413				LPERR		;SET UP THE LOOP ON ERROR ADDRESS.
2002	007440	012704	000200			MOV	#0200,R4	;SET FIU, FIV, AND FD
2003	007444	170104				LDFPS	R4	
2004	007446	012737	007474	001236		MOV	#GG11,\$TMP2	
2005	007454	012737	010630	000244		MOV	#GGER7,FPVECT	
2006	007462	012700	011754			MOV	#GGP2,R0	;SET ACO OPERAND
2007	007466	172410				LDD	(R0),ACO	;FSRC
2008	007470	012700	011764			MOV	#GGP3,R0	
2009	007474	172010			GG11:	ADD	(R0),ACO	;TEST INSTRUCTION
2010	007476	170205				STFPS	R5	;GET FPS
2011	007500	012700	011734			MOV	#GGDATO,R0	;GET THE RESULT
2012	007504	174010				STD	ACO,(R0)	
2013	007506	012701	012014			MOV	#GGP6,R1	;IS IT CORRECT
2014	007512	012702	000004			MOV	#4,R2	
2015	007516	022021			GG12:	CMP	(R0)+,(R1)+	
2016	007520	001402				BEQ	GG13	
2017	007522	000137	010726			JMP	GGER8	
2018	007526	077205			GG13:	SOB	R2,GG12	
2019	007530	052704	000004			BIS	#4,R4	;FPS CORRECT?
2020	007534	020405				CMP	R4,R5	
2021	007536	001402				BEQ	GG14	
2022	007540	000137	010774			JMP	GGER9	
2023					;CHECK	UNDERFLOW CONDITION WITH		
2024					;TRAP	ENABLED (FIU = 1)		
2025	007544				GG14:			
	007544	104413				LPERR		;SET UP THE LOOP ON ERROR ADDRESS.
2026	007546	012704	002200			MOV	#2200,R4	;SET FIU, FIV, AND FD
2027	007552	170104				LDFPS	R4	

```

2028 007554 012737 007602 001236      MOV      #GG15,$TMP2
2029 007562 012737 007620 000244      MOV      #GG16,FPVECT
2030 007570 012700 011754      MOV      #GGP2,R0      ;SET ACO OPERAND
2031 007574 172410      LDD      (R0),ACO      ;FSPC
2032 007576 012700 011764      MOV      #GGP3,R0
2033 007602 172010      GC15:    ADDD     (R0),ACO      ;TEST INSTRUCTION
2034 007604 170000      CFCC
2035 007606 012700 011734      MOV      #GGDAT0,R0
2036 007612 174010      STD      ACO,(R0)
2037 007614 000137 011042      JMP      GGER10
2038 007620 013703 001236      GG16:    MOV      $TMP2,R3
2039 007624 062703 000002      ADD      #2,R3
2040 007630 021603      CMP      (SP),R3
2041 007632 001402      BEQ      1$
2042 007634 000137 037450      JMP      FPSPUR
2043 007640 011637 001236      1$:     MOV      (SP),$TMP2
2044 007644 022626      CMP      (SP)+,(SP)+
2045 007646 170205      STFPS   R5      ;GET FPS
2046 007650 012700 011734      MOV      #GGDAT0,R0      ;GET THE RESULT
2047 007654 174010      STD      ACO,(R0)
2048 007656 012701 012024      MOV      #GGP7,R1      ;IS IT CORRECT
2049 007662 012702 000004      MOV      #4,R2
2050 007666 022021      GG17:    CMP      (R0)+,(R1)+
2051 007670 001402      BEQ      GG18
2052 007672 000137 011110      JMP      GGER11
2053 007676 077205      GG18:    SOB      R2,GG17
2054 007700 052704 100000      BIS      #100000,R4
2055 007704 020405      CMP      R4,R5      ;FPS CORRECT?
2056 007706 001402      BEQ      2$
2057 007710 000137 011156      JMP      GGER12
2058 007714      2$:
2059 007714 012704 000012      1$:     MOV      #12,R4
2060      ;CHECK FEC
2061 007720 170305      STST    R5
2062 007722 020405      CMP      R4,R5
2063 007724 001402      BEQ      GG19
2064 007726 000177 001272      JMP      @GGER13
2065      ;CHECK UNDERFLOW CONDITION WITH TRAPS
2066      ;DISABLED (FIU = 0)
2067      GG19:
2068 007732 104413      LPERR   ;SET UP THE LOOP ON ERROR ADDRESS.
2069 007734 012704 000200      MOV      #0200,R4      ;SET FIU, FIV, AND FD
2070 007740 170104      LDFPS  R4
2071 007742 012737 007770 001236      MOV      #GG20,$TMP2
2072 007750 012737 011272 000244      MOV      #GGER14,FPVECT
2073 007756 012700 011754      MOV      #GGP2,R0      ;SET ACO OPERAND
2074 007762 172410      LDD      (R0),ACO
2075 007770 172010      GG20:    MOV      #GGP8,R0      ;FSPC
2076 007772 170205      ADDD     (R0),ACO      ;TEST INSTRUCTION
2077 007774 012700 011734      STFPS   R5      ;GET FPS
2078 010000 174010      MOV      #GGDAT0,R0      ;GET THE RESULT
2079 010002 012701 012014      STD      ACO,(R0)
2080 010006 012702 000004      MOV      #GGP6,R1      ;IS IT CORRECT
2081 010012 022021      GG21:    MOV      #4,R2
2082 010014 001402      CMP      (R0)+,(R1)+
2083 010016 000137 011370      BEQ      GG22
      JMP      GGER15

```

2084 010022 077205
2085 010024 052704 000004
2086 010030 020405
2087 010032 001402
2088 010034 000137 011436

GG22: SOB R2,GG21
BIS #4,R4
CMP R4,R5
BEQ GG23
JMP GGER16

:FPS CORRECT?

2090

;CHECK UNDERFLOW CONDITION WITH TRAP


```

2092                                     :ENABLED (FIU = 1)
2093 010040                               GG23: LPERR
      010040 104413                       MOV #2200,R4 ;SET UP THE LOOP ON ERROR ADDRESS.
2094 010042 012704 002200                 LDFPS R4 ;SET FIU, FIV, AND FD
2095 010046 170104                       MOV #GG24,$TMP2
2096 010050 012737 010076 001236         MOV #GG25,FPVECT
2097 010056 012737 010114 000244         MOV #GGP2,R0 ;SET ACO OPERAND
2098 010064 012700 011754                 LDD (R0),ACO
2099 010070 172410                       MOV #GGP8,R0 ;FSRC
2100 010072 012700 012034                 GG24: ADDD (R0),ACO ;TEST INSTRUCTION
2101 010076 172010                       CFCC
2102 010100 170000                       MOV #GGDAT0,R0
2103 010102 012700 011734                 STD ACO,(R0)
2104 010106 174010                       JMP GGER17
2105 010110 000137 011504                 GG25: MOV $TMP2,R0
2106 010114 013700 001236                 ADD #2,R0
2107 010120 062700 000002                 CMP R0,(SP)
2108 010124 020016                       BEQ 1$
2109 010126 001402                       JMP FPSPUR
2110 010130 000137 037450                 1$: MOV (SP),$TMP2
2111 010134 011637 001236                 CMP (SP)+,(SP)+
2112 010140 022626                       STFPS R5 ;GET FPS
2113 010142 170205                       MOV #GGDAT0,R0 ;GET THE RESULT
2114 010144 012700 011734                 STD ACO,(R0)
2115 010150 174010                       MOV #GGP9,R1 ;IS IT CORRECT
2116 010152 012701 012044                 MOV #4,R2
2117 010156 012702 000004                 GG26: CMP (R0)+,(R1)+
2118 010162 022021                       BEQ GG27
2119 010164 001402                       JMP GGER18
2120 010166 000137 011552                 GG27: SOB R2,GG26
2121 010172 077205                       BIS #100004,R4
2122 010174 052704 100004                 CMP R4,R5 ;FPS CORRECT?
2123 010200 020405                       BEQ 1$
2124 010202 001402                       JMP GGER20
2125 010204 000137 011666                 1$: MOV #12,R4
2126 010210 012704 000012                 :CHECK FEC
2127                                     STST R5
2128 010214 170305                       CMP R4,R5
2129 010216 020405                       BEQ GG28
2130 010220 001402                       JMP GGER19
2131 010222 000137 011620                 GG28: JMP GGDONE
2132                                     GG28:
2133 010226 000137 012054                 GG28: JMP GGDONE
2134                                     GG28:
2135 010232 013701 001236                 GGER0: MOV $TMP2,R1
2136 010236 062701 000002                 ADD #2,R1
2137 010242 020116                       CMP R1,(SP)
2138 010244 001402                       BEQ 10$
2139 010246 000137 037450                 5$: JMP FPSPUR
2140 010252                                     10$:
2141 010252 170301                       STST R1
2142 010254 020127 000010                 CMP R1,#10
2143 010260 001372                       BNE 5$
2144 010262 022626                       CMP (SP)+,(SP)+
2145 010264 012700 011734                 MOV #GGDAT0,R0
2146 010270 174010                       STD ACO,(R0)
2147 010272 012737 012004 001240         MOV #GGP5,$TMP3

```

	010300	012737	012004	001242		MOV	#GGP5,\$TMP4
	010306	012737	011734	001244		MOV	#GGDAT0,\$TMP5
	010314	012737	012014	001246		MOV	#GGP6,\$TMP6
	010322	104220			1\$:	ERROR	+220
	010324	000137	012054			JMP	GGDONE
2148							
2149	010330				GGER1:		
	010330	010537	001252			MOV	R5,\$TMP10
	010334	010437	001254			MOV	R4,\$TMP11
	010340	012737	012004	001240		MOV	#GGP5,\$TMP3
	010346	012737	012004	001242		MOV	#GGP5,\$TMP4
	010354	012737	011734	001244		MOV	#GGDAT0,\$TMP5
	010362	012737	012014	001246		MOV	#GGP6,\$TMP6
	010370	104207			1\$:	ERROR	+207
	010372	000137	012054			JMP	GGDONE
2150							
2151	010376				GGER2:		
	010376	010537	001252			MOV	R5,\$TMP10
	010402	010437	001254			MOV	R4,\$TMP11
	010406	012737	012004	001240		MOV	#GGP5,\$TMP3
	010414	012737	012004	001242		MOV	#GGP5,\$TMP4
	010422	012737	011734	001244		MOV	#GGDAT0,\$TMP5
	010430	012737	012014	001246		MOV	#GGP6,\$TMP6
	010436	104232			1\$:	ERROR	+232
	010440	000137	012054			JMP	GGDONE
2152							
2153	010444				GGER3:		
	010444	010537	001252			MOV	R5,\$TMP10
	010450	010437	001254			MOV	R4,\$TMP11
	010454	012737	012004	001240		MOV	#GGP5,\$TMP3
	010462	012737	012004	001242		MOV	#GGP5,\$TMP4
	010470	012737	011734	001244		MOV	#GGDAT0,\$TMP5
	010476	012737	012014	001246		MOV	#GGP6,\$TMP6
	010504	104221			1\$:	ERROR	+221
	010506	000137	012054			JMP	GGDONE
2154							
2155	010512	000706			GGER4:	BR	GGER1
2156							
2157	010514				GGER5:		
	010514	010537	001252			MOV	R5,\$TMP10
	010520	010437	001254			MOV	R4,\$TMP11
	010524	012737	012004	001240		MOV	#GGP5,\$TMP3
	010532	012737	012004	001242		MOV	#GGP5,\$TMP4
	010540	012737	011734	001244		MOV	#GGDAT0,\$TMP5
	010546	012737	012014	001246		MOV	#GGP6,\$TMP6
	010554	104226			1\$:	ERROR	+226
	010556	000137	012054			JMP	GGDONE
2158							
2159	010562				GGER6:		
	010562	010537	001252			MOV	R5,\$TMP10
	010566	010437	001254			MOV	R4,\$TMP11
	010572	012737	012004	001240		MOV	#GGP5,\$TMP3
	010600	012737	012004	001242		MOV	#GGP5,\$TMP4
	010606	012737	011734	001244		MOV	#GGDAT0,\$TMP5
	010614	012737	012014	001246		MOV	#GGP6,\$TMP6
	010622	104227			1\$:	ERROR	+227
	010624	000137	012054			JMP	GGDONE

2160						
2161	010630	013701	001236		GGER7:	MOV \$TMP2,R1
2162	010634	062701	000002			ADD #2,R1
2163	010640	020116				CMP R1,(SP)
2164	010642	001402				BEQ 10\$
2165	010644	000137	037450		5\$:	JMP FPSPUR
2166	010650				10\$:	
2167	010650	170301				STST R1
2168	010652	020127	000012			CMP R1,#12
2169	010656	001372				BNE 5\$
2170	010660	022626				CMP (SP)+,(SP)+
2171	010662	012700	011734			MOV #GGDATO,R0
2172	010666	174010				STD ACO,(R0)
2173	010670	012737	011764	001240		MOV #GGP3,\$TMP3
	010676	012737	011754	001242		MOV #GGP2,\$TMP4
	010704	012737	011734	001244		MOV #GGDATO,\$TMP5
	010712	012737	012014	001246		MOV #GGP6,\$TMP6
	010720	104224			1\$:	ERROR +224
	010722	000137	012054			JMP GGDONE
2174						
2175	010726				GGER8:	MOV R5,\$TMP10
	010726	010537	001252			MOV R4,\$TMP11
	010732	010437	001254			MOV #GGP3,\$TMP3
	010736	012737	011764	001240		MOV #GGP2,\$TMP4
	010744	012737	011754	001242		MOV #GGDATO,\$TMP5
	010752	012737	011734	001244		MOV #GGP6,\$TMP6
	010760	012737	012014	001246		MOV #GGP6,\$TMP6
	010766	104207			1\$:	ERROR +207
	010770	000137	012054			JMP GGDONE
2176						
2177	010774				GGER9:	MOV R5,\$TMP10
	010774	010537	001252			MOV R4,\$TMP11
	011000	010437	001254			MOV #GGP3,\$TMP3
	011004	012737	011764	001240		MOV #GGP2,\$TMP4
	011012	012737	011754	001242		MOV #GGDATO,\$TMP5
	011020	012737	011734	001244		MOV #GGP6,\$TMP6
	011026	012737	012014	001246		MOV #GGP6,\$TMP6
	011034	104232			1\$:	ERROR +232
	011036	000137	012054			JMP GGDONE
2178						
2179	011042				GGER10:	MOV R5,\$TMP10
	011042	010537	001252			MOV R4,\$TMP11
	011046	010437	001254			MOV #GGP3,\$TMP3
	011052	012737	011764	001240		MOV #GGP2,\$TMP4
	011060	012737	011754	001242		MOV #GGDATO,\$TMP5
	011066	012737	011734	001244		MOV #GGP7,\$TMP6
	011074	012737	012024	001246		MOV #GGP7,\$TMP6
	011102	104225			1\$:	ERROR +225
	011104	000137	012054			JMP GGDONE
2180						
2181	011110				GGER11:	MOV R5,\$TMP10
	011110	010537	001252			MOV R4,\$TMP11
	011114	010437	001254			MOV #GGP3,\$TMP3
	011120	012737	011764	001240		MOV #GGP2,\$TMP4
	011126	012737	011754	001242		MOV #GGDATO,\$TMP5
	011134	012737	011734	001244		MOV #GGP7,\$TMP6
	011142	012737	012024	001246		MOV #GGP7,\$TMP6

	011150	104207		1\$:	ERROR	+207
	011152	000137	012054		JMP	GGDONE
2182						
2183	011156			GGER12:		
	011156	010537	001252		MOV	R5,\$TMP10
	011162	010437	001254		MOV	R4,\$TMP11
	011166	012737	011764	001240	MOV	#GGP3,\$TMP3
	011174	012737	011754	001242	MOV	#GGP2,\$TMP4
	011202	012737	011734	001244	MOV	#GGDAT0,\$TMP5
	011210	012737	012024	001246	MOV	#GGP7,\$TMP6
	011216	104231		1\$:	ERROR	+231
	011220	000137	012054		JMP	GGDONE
2184						
2185	011224			GGER13:		
	011224	010537	001252		MOV	R5,\$TMP10
	011230	010437	001254		MOV	R4,\$TMP11
	011234	012737	011764	001240	MOV	#GGP3,\$TMP3
	011242	012737	011754	001242	MOV	#GGP2,\$TMP4
	011250	012737	011734	001244	MOV	#GGDAT0,\$TMP5
	011256	012737	012024	001246	MOV	#GGP7,\$TMP6
	011264	104230		1\$:	ERROR	+230
	011266	000137	012054		JMP	GGDONE
2186						
2187	011272	013701	001236	GGER14:	MOV	\$TMP2,R1
2188	011276	062701	000002		ADD	#2,R1
2189	011302	020116			CMP	R1,(SP)
2190	011304	001402			BEQ	10\$
2191	011306	000137	037450	5\$:	JMP	FPSPUR
2192	011312			10\$:		
2193	011312	170301			STST	R1
2194	011314	020127	000012		CMP	R1,#12
2195	011320	00137c			BNE	5\$
2196	011322	022626			CMP	(SP)+,(SP)+
2197	011324	012700	011734		MOV	#GGDAT0,R0
2198	011330	174010			STD	AC0,(R0)
2199						
2200	011332	012737	011744	001240	MOV	#GGP1,\$TMP3
	011340	012737	011764	001242	MOV	#GGP3,\$TMP4
	011346	012737	011734	001244	MOV	#GGDAT0,\$TMP5
	011354	012737	012014	001246	MOV	#GGP6,\$TMP6
	011362	104222		1\$:	ERROR	+222
	011364	000137	012054		JMP	GGDONE
2201						
2202	011370			GGER15:		
	011370	010537	001252		MOV	R5,\$TMP10
	011374	010437	001254		MOV	R4,\$TMP11
	011400	012737	011754	001240	MOV	#GGP2,\$TMP3
	011406	012737	012034	001242	MOV	#GGP8,\$TMP4
	011414	012737	011734	001244	MOV	#GGDAT0,\$TMP5
	011422	012737	012014	001246	MOV	#GGP6,\$TMP6
	011430	104207		1\$:	ERROR	+207
	011432	000137	012054		JMP	GGDONE
2203						
2204	011436			GGER16:		
	011436	010537	001252		MOV	R5,\$TMP10
	011442	010437	001254		MOV	R4,\$TMP11
	011446	012737	011754	001240	MOV	#GGP2,\$TMP3

	011454	012737	012034	001242	MOV	#GGP8,\$TMP4
	011462	012737	011734	001244	MOV	#GGDAT0,\$TMP5
	011470	012737	012014	001246	MOV	#GGP6,\$TMP6
	011476	104232			1\$:	ERROR
	011500	000137	012054		JMP	GGDONE
2205						
2206	011504				GGER17:	
	011504	010537	001252		MOV	R5,\$TMP10
	011510	010437	001254		MOV	R4,\$TMP11
	011514	012737	011754	001240	MOV	#GGP2,\$TMP3
	011522	012737	012034	001242	MOV	#GGP8,\$TMP4
	011530	012737	011734	001244	MOV	#GGDAT0,\$TMP5
	011536	012737	012044	001246	MOV	#GGP9,\$TMP6
	011544	104223			1\$:	ERROR
	011546	000137	012054		JMP	GGDONE
2207						
2208	011552				GGER18:	
	011552	010537	001252		MOV	R5,\$TMP10
	011556	010437	001254		MOV	R4,\$TMP11
	011562	012737	011754	001240	MOV	#GGP2,\$TMP3
	011570	012737	012034	001242	MOV	#GGP8,\$TMP4
	011576	012737	011734	001244	MOV	#GGDAT0,\$TMP5
	011604	012737	012044	001246	MOV	#GGP9,\$TMP6
	011612	104207			1\$:	ERROR
	011614	000137	012054		JMP	GGDONE
2209						
2210	011620				GGER19:	
	011620	010537	001252		MOV	R5,\$TMP10
	011624	010437	001254		MOV	R4,\$TMP11
	011630	012737	011754	001240	MOV	#GGP2,\$TMP3
	011636	012737	012034	001242	MOV	#GGP8,\$TMP4
	011644	012737	011734	001244	MOV	#GGDAT0,\$TMP5
	011652	012737	012044	001246	MOV	#GGP9,\$TMP6
	011660	104230			1\$:	ERROR
	011662	000137	012054		JMP	GGDONE
2211						
2212	011666				GGER20:	
	011666	010537	001252		MOV	R5,\$TMP10
	011672	010437	001254		MOV	R4,\$TMP11
	011676	012737	011754	001240	MOV	#GGP2,\$TMP3
	011704	012737	012034	001242	MOV	#GGP8,\$TMP4
	011712	012737	011734	001244	MOV	#GGDAT0,\$TMP5
	011720	012737	012044	001246	MOV	#GGP9,\$TMP6
	011726	104231			1\$:	ERROR
	011730	000137	012054		JMP	GGDONE
2213						
2214	011734	000000			GGDAT0:	0
2215	011736	000000				0
2216	011740	000000				0
2217	011742	000000				0
2218						
2219	011744	000300			GGP1:	300
2220	011746	000000				0
2221	011750	000000				0
2222	011752	000000				0
2223	011754	100200			GGP2:	100200
2224	011756	000000				0

```
2225 011760 000000
2226 011762 000000
2227 011764 000200      GGP3:
2228 011766 000000
2229 011770 000000
2230 011772 000001
2231 011774 010200      GGP4:
2232 011776 000000
2233 012000 000000
2234 012002 000000
2235 012004 077600      GGP5:
2236 012006 000000
2237 012010 000000
2238 012012 000000
2239 012014 000000      GGP6:
2240 012016 000000
2241 012020 000000
2242 012022 000000
2243
2244 012024 062400      GGP7:
2245 012026 000000
2246 012030 000000
2247 012032 000000
2248 012034 000340      GGP8:
2249 012036 000000
2250 012040 000000
2251 012042 000000
2252 012044 060100      GGP9:
2253 012046 000000
2254 012050 000000
2255 012052 000000
2256 012054 104412      GGDONE:
                                RSETUP
```

:OVER FLOW = GGP5 + GGP5

```
:OVERFLOW RESULT
:UNDERFLOW RESULT
:GGP6 = GGP4 + GGP5
:      = GGP3 + GGP2 (FIU = 0)
:      = GGP3 + GGP1
:GGP7 = GGP3 + GGP2 (FIU = 1)
```

```
:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).
```

2257
2263

2264
 2265 012056 000004
 2266 012060 104413
 2267 012062 012704 000200
 2268 012066 170104
 2269 012070 012700 013474
 2270 012074 172410
 2271 012076 012700 013504
 2272 012102 012737 012110 001236
 2273 012110 177420
 2274 012112 020027 013510
 2275 012116 001402
 2276 012120 000137 013052
 2277 012124
 2278 012124 170205
 2279 012126 012700 013464
 2280 012132 174010
 2281 012134 012701 013554
 2282 012140 012702 000004
 2283 012144 022120
 2284 012146 001415
 2285 012150 012701 013504
 2286 012154 012700 013464
 2287 012160 012702 000004
 2288 012164 022120
 2289 012166 001402
 2290 012170 000137 013112
 2291 012174 077205
 2292 012176 000137 013142
 2293 012202 077220
 2294 012204 012704 000200
 2295 012210 020405
 2296 012212 001402
 2297 012214 000137 013210
 2298
 2299 012220
 2300 012220 104413
 2301 012222 012704 000200
 2302 012226 170104
 2303 012230 012700 013474
 2304 012234 172410
 2305
 2306 012236 012700 013504
 2307 012242 012737 012252 001236
 2308
 2309 012250 170001
 2310
 2311 012252 177420

```

.SBTTL TEST # 3 - LDCFD AND LDCDF TEST
*****
:TEST 3 LDCFD AND LDCDF TEST
:
:THIS IS A TEST OF LDCFD AND LDCDF.
:
*****
TST3: SCOPE
:TEST FOR CORRECT AUTO INCREMENT CONSTANT.
HX1: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      MOV #200,R4
      LDFPS R4
      MOV #HXP1,R0
      LDD (R0),ACO
      MOV #HXP2,R0
      MOV #HX2,$TMP2
HX2: LDCFD (R0)+,ACO ;IS R0 CORRECT
      CMP R0,#HXP2+4
      BEQ HX3
      JMP HXER1
HX3: STFPS R5 ;GET FPS
      MOV #HXDAT0,R0
      STD ACO,(R0) ;GET ACO
      MOV #HXP7,R1 ;SEE IF RESULT IS
      MOV #4,R2 ;CORRECT
HX4: CMP (R1)+,(R0)+
      BEQ HX7
      MOV #HXP2,R1 ;DID FD GET
      MOV #HXDAT0,R0 ;COMPLIMENTED?
      MOV #4,R2
HX5: CMP (R1)+,(R0)+
      BEQ HX6
      JMP HXER2
HX6: SOB R2,HX5
      JMP HXER3
HX7: SOB R2,HX4 ;FPS CORRECT?
      MOV #200,R4
      CMP R4,R5
      BEQ HX8
      JMP HXER8
:NOW
HX8: TEST LDCDF
      LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      MOV #200,R4
      LDFPS R4
      MOV #HXP1,R0
      LDD (R0),ACO
      MOV #HXP2,R0
      MOV #HX9,$TMP2
      SETF
HX9: LDCDF (R0)+,ACO ;TEST INSTRUCTION
    
```


2312									
2313	012254	020027	013514		CMP	R0,#HXP2+10		:WAS A GOOD	
2314	012260	001402			BEQ	HX10		:CONSTANT USED	
2315	012262	000137	013072		JMP	HXER5		:TO INCREMENT R0?	
2316									
2317	012266				HX10:				
2318	012266	170205			STFPS	R5			
2319	012270	012700	013464		MOV	#HXDAT0,R0			
2320	012274	170011			SETD				
2321	012276	174010			STD	AC0,(R0)		:GET RESULT	
2322	012300	012701	013564		MOV	#HXP8,R1			
2323	012304	012702	000004		MOV	#4,R2			
2324	012310	022120			HX11:	CMP	(R1)+,(R0)+	:IS IT CORRECT?	
2325	012312	001415			BEQ	HX14			
2326									
2327	012314	012701	013554		MOV	#HXP7,R1			
2328	012320	012700	013464		MOV	#HXDAT0,R0			
2329	012324	012702	000004		MOV	#4,R2			
2330	012330	022110			HX12:	CMP	(R1)+,(R0)	:DID FD FAIL TO GET	
2331	012332	001402			BEQ	HX13		:COMPLIMENTED?	
2332	012334	000137	013226		JMP	HXER6			
2333	012340	077205			HX13:	SOB	R2,HX12		
2334	012342	000137	013256		JMP	HXER7			
2335									
2336	012346	077220			HX14:	SOB	R2,HX11		
2337									
2338	012350	012704	000000		MOV	#0,R4		:FPS CORRECT?	
2339	012354	020405			CMP	R4,R5			
2340	012356	001402			BEQ	HX15			
2341	012360	000137	013210		JMP	HXER8			
2342									
2343									
2344									
2345	012364				HX15:				
2346	012364	104413			LPERR			:SET UP THE LOOP ON ERROR ADDRESS.	
2347	012366	012704	000200		MOV	#200,R4			
2348	012372	170104			LDFPS	R4		:SET FD	
2349	012374	012737	012412	001236	MOV	#HX16,\$TMP2			
2350	012402	012737	013306	000004	MOV	#HXER9,ERRVECT			
2351	012410	005001			CLR	R1			
2352	012412	177427	043243		HX16:	LDCFD	#5201,AC0		
2353	012416	005201			HX165:	INC	R1		
2354	012420	005201			INC	R1			
2355	012422	005201			INC	R1			
2356	012424	012737	037502	000004	MOV	#CPSPUR,ERRVECT			
2357	012432	020127	000003		CMP	R1,#3		:SEE IF PC WAS	
2358	012436	001402			BEQ	HX17		:CORRECT	
2359	012440	000137	013342		JMP	HXER10			
2360									
2361	012444				HX17:				
2362	012444	104413			LPERR			:SET UP THE LOOP ON ERROR ADDRESS.	
2363	012446	012704	000200		MOV	#200,R4			
2364	012452	170104			LDFPS	R4			
2365	012454	012737	012502	001236	MOV	#HX18,\$TMP2			
2366	012462	012700	013544		MOV	#HXP6,R0			

```

2367 012466 172410          LDD      (R0),ACO
2368 012470 012737 037502 000004    MOV      #CPSPUR,ERRVECT
2369 012476 012700 013504          MOV      #HXP2,R0
2370 012502 177410          HX18:   LDCFD   (R0),ACO
2371
2372 012504 012700 013464          MOV      #HXDATO,R0
2373 012510 174010          STD      ACC,(R0)          ;GET RESULT.
2374 012512 012701 013554          MOV      #HXP7,R1
2375 012516 012702 000004          MOV      #4,R2
2376 012522 022021          HX19:   CMP      (R0)+,(R1)+      ;IS RESULT CORRECT?
2377 012524 001402          BEQ      HX20
2378 012526 000137 013112          JMP      HXER2
2379 012532 077205          HX20:   SOB      R2,HX19
2380
2381          ;TEST LDCFD WITH NEGATIVE OPERAND
2382          HX21:
2383 012534          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
2384 012536 104413          MOV      #200,R4
2385 012542 170104          LDFPS   R4
2386 012544 012737 012564 001236    MOV      #HX22,$TMP2
2387 012552 012700 013544          MOV      #HXP6,R0
2388 012560 012700 013524          LDD      (R0),ACO
2389 012564 177410          HX22:   MOV      #HXP4,R0
2390          LDCFD   (R0),ACO
2391 012566 012700 013464          MOV      #HXDATO,R0
2392 012572 174010          STD      ACC,(R0)          ;GET RESULT
2393
2394 012574 012701 013534          MOV      #HXP5,R1
2395 012600 012702 000004          MOV      #4,R2
2396 012604 022120          HX23:   CMP      (R1)+,(R0)+
2397 012606 001415          BEQ      HX26
2398
2399 012610 012701 013554          MOV      #HXP7,R1
2400 012614 012700 013464          MOV      #HXDATO,R0
2401 012620 012702 000004          MOV      #4,R2
2402 012624 022120          HX24:   CMP      (R1)+,(R0)+      ;WAS SIGN INCORRECT
2403 012626 001402          BEQ      HX25
2404 012630 000137 013374          JMP      HXER11
2405 012634 077205          HX25:   SOB      R2,HX24
2406 012636 000137 013414          JMP      HXER12
2407
2408 012642 077220          HX26:   SOB      R2,HX23
2409
2410          ;TEST LDCFD 0
2411          HX27:
2412 012644          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
2413 012646 104413          MOV      #200,R4
2414 012652 170104          LDFPS   R4
2415
2416 012654 012700 013474          MOV      #HXP1,R0
2417 012660 172410          LDD      (R0),ACO
2418 012662 172010          ADDD    (R0),ACO
2419
2420 012664 012737 012676 001236    MOV      #HX28,$TMP2
2421 012672 012700 013474          MOV      #HXP1,R0
    
```

TEST # 3 - LDCFD AND LDCDF TEST

```

2422 012676 177410          HX28:  LDCFD  (R0),ACO
2423
2424 012700 170205          STFPS  R5
2425
2426 012702 012700 013464    MOV    #HXDATO,R0
2427 012706 174010          STD    ACO,(R0)          ;GET RESULT
2428
2429 012710 012701 013474    MOV    #HXP1,R1
2430 012714 012702 000004    MOV    #4,R2
2431 012720 022120          HX29:  CMP    (R1)+,(R0)+    ;IS IT 0?
2432 012722 001402          BEQ    HX30
2433 012724 000137 013444    JMP    HXER13
2434 012730 077205          HX30:  SOB    R2,HX29
2435
2436 012732 012704 000204    MOV    #204,R4          ;FPS CORRECT
2437 012736 020405          CMP    R4,R5
2438 012740 001402          BEQ    HX31
2439 012742 000137 013172    JMP    HXER4
2440
2441          ;TEST  LDCFD  0
2442
2443          HX31:
2443 012746 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
2444 012750 012704 000200    MOV    #200,R4
2445 012754 170104          LDFPS  R4
2446
2447 012756 012700 013544    MOV    #HXP6,R0
2448 012762 172410          LDD    (R0),ACO
2449
2450 012764 012737 012776 001236    MOV    #HX32,$TMP2
2451 012772 012700 013474    MOV    #HXP1,R0
2452 012776 177410          HX32:  LDCFD  (R0),ACO
2453
2454 013000 170205          STFPS  R5
2455
2456 013002 012700 013464    MOV    #HXDATO,R0
2457 013006 174010          STD    ACO,(R0)          ;GET RESULT
2458
2459 013010 012701 013474    MOV    #HXP1,R1
2460 013014 012702 000004    MOV    #4,R2
2461 013020 022120          HX33:  CMP    (R1)+,(R0)+    ;IS IT ZERO?
2462 013022 001402          BEQ    HX34
2463 013024 000137 013444    JMP    HXER13
2464 013030 077205          HX34:  SOB    R2,HX33
2465
2466 013032 012704 000204    MOV    #204,R4          ;FPS CORRECT?
2467 013036 020405          CMP    R4,R5
2468 013040 001402          BEQ    HX35
2469 013042 000137 013172    JMP    HXER4
2470 013046 000137 013574    HX35:  JMP    HXDONE
2471
2472          ;RO INCORRECT
2473
2474 013052 012737 013510 001242    HXER1:  MOV    #HXP2+4,$TMP4
2475 013060 010037 001240    MOV    R0,$TMP3
2476 013064 104234          1$:    ERROR +234
2477 013066 000137 013574    JMP    HXDONE

```

```

2478
2479 013072 012737 013514 001242 HXER5: MOV #HXP2+10,$TMP4
2480 013100 010037 001240          MOV R0,$TMP3
2481 013104 104237          1$: ERROR +237
2482 013106 000137 013574          JMP HXDONE
2483          ;REPORT BAD DATA
2484 013112 012737 013504 001244 HXER2: MOV #HXP2,$TMP5
2485 013120 012737 013554 001250          MOV #HXP7,$TMP7
2486 013126 012737 013464 001246 HXER22: MOV #HXDAT0,$TMP6
2487 013134 104233          1$: ERROR +233
2488 013136 000137 013574          JMP HXDONE
2489          ;
2490 013142 012737 013504 001244 HXER3: MOV #HXP2,$TMP5
2491 013150 012737 013554 001250          MOV #HXP7,$TMP7
2492 013156 012737 013464 001246 HXER33: MOV #HXDAT0,$TMP6
2493 013164 104241          1$: ERROR +241
2494 013166 000137 013574          JMP HXDONE
2495
2496 013172 010537 001240          HXER4: MOV R5,$TMP3
2497 013176 010437 001242          MOV R4,$TMP4
2498 013202 104240          1$: ERROR +240
2499 013204 000137 013574          JMP HXDONE
2500
2501 013210 010537 001240          HXER8: MOV R5,$TMP3
2502 013214 010437 001242          MOV R4,$TMP4
2503 013220 104242          1$: ERROR +242
2504 013222 000137 013574          JMP HXDONE
2505 013226 012737 013504 001244 HXER6: MOV #HXP2,$TMP5
2506 013234 012737 013564 001250          MOV #HXP8,$TMP7
2507 013242 012737 013464 001246 HXER66: MOV #HXDAT0,$TMP6
2508 013250 104244          1$: ERROR +244
2509 013252 000137 013574          JMP HXDONE
2510
2511 013256 012737 013504 001244 HXER7: MOV #HXP2,$TMP5
2512 013264 012737 013564 001250          MOV #HXP8,$TMP7
2513 013272 012737 013464 001246          MOV #HXDAT0,$TMP6
2514 013300 104243          1$: ERROR +243
2515 013302 000137 013574          JMP HXDONE
2516
2517 013306 032716 000001          HXER9: BIT #1,(SP)          ;SEE IF IT
2518 013312 001005          BNE 1$          ;AN ODD ADDRESS
2519 013314 022716 012416          CMP #HX165,(SP)
2520 013320 001402          BEQ 1$
2521 013322 000137 037502          JMP CPSPUR
2522
2523 013326 011637 001236          1$: MOV (SP),$TMP2
2524 013332 022626          CMP (SP)+,(SP)+
2525 013334 104235          2$: ERROR +235
2526 013336 000137 013574          JMP HXDONE
2527
2528 013342 162701 000003          HXER10: SUB #3,R1
2529 013346 006301          ASL R1
2530 013350 012702 012416          MOV #HX165,R2
2531 013354 010237 001242          MOV R2,$TMP4
2532 013360 160102          SUB R1,R2
2533 013362 010237 001240          MOV R2,$TMP3
2534 013366 104236          1$: ERROR +236
    
```

```

2535 013370 000137 013574          JMP      HXDONE
2536
2537 013374 012737 013524 001244 HXER11: MOV      #HXP4,$TMP5
2538 013402 012737 013534 001250      MOV      #HXP5,$TMP7
2539 013410 000137 013126          JMP      HXER22
2540 013414 012737 013524 001244 HXER12: MOV      #HXP4,$TMP5
2541 013422 012737 013534 001250      MOV      #HXP5,$TMP7
2542 013430 012737 013464 001246      MOV      #HXDAT0,$TMP6
2543 013436 104245          1$:      ERROR   +245
2544 013440 000137 013574          JMP      HXDONE
2545
2546 013444 012737 013474 001244 HXER13: MOV      #HXP1,$TMP5
2547 013452 012737 013474 001250      MOV      #HXP1,$TMP7
2548 013460 000137 013126          JMP      HXER22
2549
2550 013464 000000          HXDAT0: 0
2551 013466 000000              0
2552 013470 000000              0
2553 013472 000000              0
2554
2555 013474 000000          HXP1:    0
2556 013476 000000              0
2557 013500 000000              0
2558 013502 000000              0
2559
2560 013504 000577          HXP2:    577
2561 013506 177776              177776
2562 013510 177777              177777
2563 013512 177776              177776
2564 013514 005201          HXP3:    5201
2565 013516 000000              0
2566 013520 000000              0
2567 013522 000000              0
2568 013524 100577          HXP4:    100577
2569 013526 177776              177776
2570 013530 177777              177777
2571 013532 177776              177776
2572 013534 100577          HXP5:    100577
2573 013536 177776              177776
2574 013540 000000              0
2575 013542 000000              0
2576 013544 000252          HXP6:    252
2577 013546 125252              125252
2578 013550 125252              125252
2579 013552 125252              125252
2580
2581 013554 000577          HXP7:    577
2582 013556 177776              177776
2583 013560 000000              0
2584 013562 000000              0
2585 013564 000577          HXP8:    577
2586 013566 177777              177777
2587 013570 000000              0
2588 013572 000000              0
2589
2590 013574          HXDONE:
      013574 104412          RSETUP
    
```

;GO INITIALIZE THE FPS AND STACK; AND

:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

2591
2592
2593
2601

2602

```
.SBTTL TEST # 4 - CMPD TEST
:*****
:*TEST 4      CMPD TEST
:*
:*THIS IS A TEST OF THE CMPD INSTRUCTION. NOTE THAT A SUBROUTINE
:*IS USED TO SET UP OPERANDS, EXECUTE THE INSTRUCTION AND CHECK THE
:*RESULTS
:*
:*****
```

2603 013576 000004

TST4: SCOPE

2604

:TEST THE CMPD INSTRUCTION WITH (FSRC=AC=0)

2605

AAA1:

013600 104413
013602 004737 014412
013606 000000 000000 000000
013616 000000 000000 000000
013626 000200
013630 000204
013632 000200
013634 104001

```
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,CMPD SUB
1$: .WORD 0,0,0,0 ;AC
2$: .WORD 0,0,0,0 ;FSRC
3$: 200 ;FPS BEFORE EXECUTION
204 ;FPS AFTER EXECUTION
200 ;ERROR FPS
4$: ERROR +1 ;FPS ERROR
```

2613

2614

2615

:TEST CMPD WITH (AC=0) AND FSRC POSITIVE.

2616

AAA2:

013636 104413
013640 004737 014412
013644 000000 000000 000000
013654 025252
013656 052525
013660 125252
013662 052525
013664 000200
013666 000200
013670 000210
013672 104003

```
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,CMPD SUB
1$: .WORD 0,0,0,0 ;AC
2$: 25252 ;FSRC
52525
125252
52525
3$: 200 ;FPS BEFORE EXECUTION
200 ;FPS AFTER EXECUTION
210 ;ERROR FPS
4$: ERROR +3 ;FPS ERROR
```

2627

2628

2629

:TEST CMPD WITH (AC=0) AND FSRC NEGATIVE

AAA3:

013674 104413
013676 004737 014412
013702 000000 000000 000000
013712 125252
013714 125252
013716 052525
013720 125252
013722 000200
013724 000210
013726 000200
013730 104004

```
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,CMPD SUB
1$: .WORD 0,0,0,0 ;AC
2$: 125252 ;FSRC
125252
52525
125252
3$: 200 ;FPS BEFORE EXECUTION
210 ;FPS AFTER EXECUTION
200 ;ERROR FPS
4$: ERROR +4 ;FPS ERROR.
```

2640

2641

2642

:TEST CMPD WITH (FSRC=0) AND AC POSITIVE

AAA4:

013732 104413
013734 004737 014412
013740 025252
013742 052525

```
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,CMPD SUB
1$: 25252 ;AC
52525
```



```

TEST # 4 - CMPD TEST

2646 013744 125252          125252
2647 013746 052525          52525
2648 013750 000000 000000 000000 2$: .WORD 0,0,0,0          ;FSRC
2649 013760 000200          200          ;FPS BEFORE EXECUTION
2650 013762 000210          210          ;FPS AFTER EXECUTION
2651 013764 000200          200          ;ERROR FPS
2652 013766 104005          4$: ERROR +5          ;FPS ERROR
2653
2654
2655 ;TEST CMPD WITH (FSRC=0) AND AC NEGATIVE
2656 013770 AAA5: LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
      013770 104413          JSR PC,CMPD SUB
2657 013772 004737 014412          1$: 125252          ;AC
2658 013776 125252          125252
2659 014000 125252          52525
2660 014002 052525          125252
2661 014004 125252          2$: .WORD 0,0,0,0          ;FSRC
2662 014006 000000 000000 000000 3$: 200          ;FPS BEFORE EXECUTION
2663 014016 000200          200          ;FPS AFTER EXECUTION
2664 014020 000200          210          ;ERROR FPS
2665 014022 000210          4$: ERROR +6          ;FPS ERROR
2666 014024 104006
2667
2668 ;TEST CMPD WITH AC POSITIVE AND FSRC NEGATIVE
2669 014026 AAA6: LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
      014026 104413          JSR PC,CMPD SUB
2670 014030 004737 014412          1$: 52525          ;AC
2671 014034 052525          125252
2672 014036 125252          52525
2673 014040 052525          125252
2674 014042 125252          2$: 125252          ;;FSRC
2675 014044 125252          52525
2676 014046 052525          125252
2677 014050 125252          52525
2678 014052 052525          3$: 200          ;FPS BEFORE EXECUTION
2679 014054 000200          210          ;FPS AFTER EXECUTION
2680 014056 000210          200          ;ERROR FPS
2681 014060 000200          4$: ERROR +7          ;FPS ERROR
2682 014062 104007
2683
2684
2685 ;TEST CMPD WITH AC NEGATIVE AND FSRC POSITIVE
2686 014064 AAA7: LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
      014064 104413          JSR PC,CMPD SUB
2687 014066 004737 014412          1$: 125252          ;AC
2688 014072 125252          52525
2689 014074 052525          125252
2690 014076 125252          52525
2691 014100 052525          2$: 52525          ;FSRC
2692 014102 052525          125252
2693 014104 125252          52525
2694 014106 052525          125252
2695 014110 125252          3$: 200          ;FPS BEFORE EXECUTION
2696 014112 000200          200          ;FPS AFTER EXECUTION
2697 014114 000200          210          ;ERROR FPS
2698 014116 000210          4$: ERROR +10          ;FPS ERROR.
2699 014120 104010

```

```
2700
2701 ;TEST CMPD WITH AC POSITIVE AND FSRC POSITIVE
2702 ;AND EAC LESS THAN EFSRC.
2703 014122 AAA8: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      014122 104413 JSR PC,CMPD SUB ;AC
2704 014124 004737 014412 1$: 12345 ;AC
      014130 012345 67654
2706 014132 067654 32101
2707 014134 032101 23456
2708 014136 023456 2$: 23456 ;FSRC
      014140 023456 76543
2710 014142 076543 21012
2711 014144 021012 34567
2712 014146 034567 3$: 200 ;FPS BEFORE EXECUTION
      014150 000200 200 ;FPS AFTER EXECUTION
2714 014152 000200 210 ;ERROR FPS
2715 014154 000210 4$: ERROR +11 ;FPS ERROR
2716 014156 104011
2717
2718 ;TEST CMPD WITH AC POSITIVE, FSRC POSITIVE AND EAC GREATER THAN EFSRC
2719 AAA9: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      014160 104413 JSR PC,CMPD SUB ;AC
2721 014162 004737 014412 1$: 45676 ;AC
      014166 045676 54321
2723 014170 054321 12345
2724 014172 012345 67654
2725 014174 067654 2$: 34567 ;FSRC
      014176 034567 65432
2726 014176 034567 101234
2727 014200 065432 56765
2728 014202 101234 3$: 200 ;FPS BEFORE EXECUTION
      014204 056765 210 ;FPS AFTER EXECUTION
2730 014206 000200 200 ;ERROR FPS
2731 014210 000210 4$: ERROR +12
2732 014212 000200
2733 014214 104012
2734
2735 ;TEST CMPD WITH AC POSITIVE, FSRC POSITIVE AND AC EQUAL TO FSRC
2736 014216 AAA10: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      014216 104413 JSR PC,CMPD SUB ;AC
2737 014220 004737 014412 1$: 12345 ;AC
      014224 012345 67012
2739 014226 067012 34567
2740 014230 034567 012345
2741 014232 012345 2$: 12345 ;FSRC
      014234 012345 67012
2742 014234 012345 34567
2743 014236 067012 3$: 012345 ;FPS BEFORE EXECUTION
2744 014240 034567 200
2745 014242 012345
2746 014244 000200
```

```

2748 014246 000204          204          :FPS AFTER EXECUTION
2749 014250 000200          200          :ERROR FPS
2750 014252 104013      4$:  ERROR  +13      :FPS ERROR
2751
2752          :TEST CMPD WITH AC POSITIVE, FSRC POSITIVE, EAC EQUAL TO EFSRC,
2753          :AND FSRC GREATER THAN AC.
2754 014254          AAA11:
      014254 104413          LPERR          :SET UP THE LOOP ON ERROR ADDRESS.
2755 014256 004737 014412      JSR          PC,CMPD SUB
2756 014262 012345      1$: 12345          :AC
      014264 067012          67012
2757 014264 067012          34567
2758 014266 034567          012345
2759 014270 012345      2$: 12345          :FSRC
2760 014272 012345          70123
2761 014274 070123          45670
2762 014276 045670          123456
2763 014300 123456      3$: 200          :FPS BEFORE EXECUTION
2764 014302 000200          200          :FPS AFTER EXECUTION
2765 014304 000200          210          :ERROR FPS
2766 014306 000210          4$:  ERROR  +14      :FPS ERROR
2767 014310 104014
2768
2769          :TEST CMPD WITH AC POSITIVE, FSRC POSITIVE, EAC EQUAL TO EFSRC,
2770          :AND AC GREATER THAN FSRC.
2771 014312          AAA12:
      014312 104413          LPERR          :SET UP THE LOOP ON ERROR ADDRESS.
2772 014314 004737 014412      JSR          PC,CMPD SUB
2773 014320 054321      1$: 54321          :AC
      014322 076543          76543
2774 014322 076543          21076
2775 014324 021076          54321
2776 014326 054321      2$: 54321          :FSRC
2777 014330 054321          65432
2778 014332 065432          107654
2779 014334 107654          32107
2780 014336 032107      3$: 200          :FPS BEFORE EXECUTION
2781 014340 000200          210          :FPS AFTER EXECUTION
2782 014342 000210          200          :ERROR FPS
2783 014344 000200          4$:  ERROR  +15      :FPS ERROR
2784 014346 104015
2785
2786          :TEST CMPD WITH AC NEGATIVE, FSRC NEGATIVE, EAC EQUAL TO EFSRC,
2787          :AND AC GREATER THAN FSRC
2788 014350          AAA13:
      014350 104413          LPERR          :SET UP THE LOOP ON ERROR ADDRESS.
2789 014352 004737 014412      JSR          PC,CMPD SUB
2790 014356 112345      1$: 112345          :AC
      014360 043210          43210
2791 014360 043210          76543
2792 014362 076543          21076
2793 014364 021076          112345
2794 014366 112345      2$: 112345          :FSRC
2795 014370 054321          54321
2796 014372 007654          07654
2797 014374 032107          32107
2798 014376 000200      3$: 200          :FPS BEFORE EXECUTION
2799 014400 000210          210          :FPS AFTER EXECUTION
2800 014402 000200          200          :ERROR FPS
2801 014404 104016          4$:  ERROR  +16      :FPS ERROR
    
```

```

2802
2803
2804 014406 000137 014602          JMP      AADONE          ;FINISHED CMPD TEST.
2805
2806
2807          ;THIS SUBROUTINE, CMPSUB, IS CALLED TO SET UP, EXECUTE
2808          ;AND CHECK THE RESULTS OF A CMPD INSTRUCTION.
2809          ;IT IS CALLED THUS:
2810          ;
2811          ;
2812          ;
2813          ;
2814          ;
2815          ;
2816          ;
2817          ;
2818          ;
2819          ;
2820          ;
2821          ;
2822          ;
2823          ;
2824          ;
2825          ;
2826          ;
2827          ;
2828          ;
2829          ;
2830 014412 012601          CMPSUB: MOV      (SP)+,R1          ;PICK UP A POINTER TO THE
2831          ;ARGUMENTS.
2832 014414 016100 000020          MOV      20(R1),R0          ;GET THE FPS BEFORE EXECUTION.
2833 014420 170100          LDFPS   R0                  ;LOAD IT INTO THE FPS.
2834
2835 014422 012737 014444 001236          MOV      #1$, $TMP2          ;SAVE ADDRESS OF CMPD INSTRUCTION.
2836 014430 010100          MOV      R1,R0              ;GET ADDRESS OF AC OPERAND.
2837 014432 172410          LDD      (R0),ACO           ;LOAD ACO OPERAND
2838
2839 014434 010100          MOV      R1,R0              ;COMPUTE FSRC OPERAND
2840 014436 062700 000010          ADD      #10,R0              ;ADDRESS
2841
2842 014442 000240          NOP
2843 014444 173410          1$:    CMPD      (R0),ACO          ;FOR SCOPING.
2844          ;EXECUTE THE TEST INSTRUCTION.
2845 014446 170205          STFPS   R5                  ;SAVE FPS AFTER INSTRUCTION.
2846
2847 014450 016104 000022          MOV      22(R1),R4          ;GET EXPECTED FPS.
2848          ;IF INCORRECT SET UP FOR
2849 014454 010137 001240          MOV      R1,$TMP3          ;AN ERROR CALL.
2850 014460 010137 001242          MOV      R1,$TMP4
2851 014464 062737 000010 001242          ADD      #10,$TMP4
2852 014472 010537 001244          MOV      R5,$TMP5
2853 014476 010437 001246          MOV      R4,$TMP6
2854 014502 020405          CMP      R5,R5              ;WAS FPS CORRECT?
2855 014504 001410          BEQ     3$                  ;BRANCH IF YES.
2856
2857
2858 014506 026105 000024          CMP      24(R1),R5          ;WAS THE FPS THE SAME

```

```
2859                                     ;AS THE EXPECTED INCORRECT FPS?  
2860 014512 001003                       BNE      2$      ;BRANCH IF NO MATCH.  
2861  
2862 014514 062701 000026                 ADD      #26,R1  ;IF THE EXPECTED INCORRECT  
2863                                     ;FPS MATCHED THE RESULTANT FPS  
2864 014520 000111                       JMP      (R1)    ;RETURN TO THE ERROR CALL  
2865                                     ;IN THE CALLING ROUTINE.  
2866  
2867 014522 104001 2$: ERROR +1          ;OTHERWISE REPORT INCORRECT FPS  
2868 014524 000411                       BR       5$  
2869  
2870 014526 012700 014572 3$: MOV      #CMPTMP,R0    ;IF FPS WAS CORRECT MAKE SURE  
2871 014532 174010                       STD      ACO,(R0) ;ACO WAS NOT AFFECTED BY CMPD.  
2872 014534 010102                       MOV      R1,R2  
2873 014536 012703 000004                 MOV      #4,R3  
2874 014542 022220 4$: CMP      (R2)+,(R0)+  
2875 014544 001003                       BNE      6$  
2876 014546 077303                       SOB      R3,4$  
2877  
2878 014550 000161 000030 5$: JMP      30(R1)      ;RETURN  
2879  
2880 014554 6$:                               ;REPORT ACO MODIFIED BY CMPD  
2881 014554 010137 001240                 MOV      R1,$TMP3  
2882 014560 012737 014572 001242         MOV      #CMPTMP,$TMP4  
2883 014566 104002 7$: ERROR +2  
2884 014570 000767                       BR       5$      ;RETURN  
2885  
2886 014572 000000 000000 000000 CMPTMP: .WORD 0,0,0,0  
2887  
2888  
2889  
2890 014602 AAADONE:                          ;GO INITIALIZE THE FPS AND STACK; AND  
014602 104412 RSETUP                       ;SEE IF THE USER HAS EXPRESSED  
                                           ;THE DESIRE TO CHANGE THE SOFTWARE  
                                           ;VIRTUAL CONSOLE SWITCH REGISTER (HAS  
                                           ;THE USER TYPED CONTROL G?).  
  
2891  
2892  
2893  
2901
```

2902

```
.SBTTL TEST # 5 - DIVD WITH (FSRC=0) AND (BUT FD) TEST
:*****
:TEST 5 DIVD WITH (FSRC=0) AND (BUT FD) TEST
:
:*THIS IS A TEST OF THE DIVD INSTRUCTION WITH A
:*ZERO DIVISOR. THE CONDITION IS CHECKED WITH BOTH
:*TRAP ENABLED AND TRAPS DISABLED.
:
:*****
TST5: SCOPE
```

2903 014604 000004

2904

2905 014606 104413

2906 014610 012704 040200

2907

2908

2909 014614 170104

2910 014616 012737 015060 000244

2911 014624 012737 014644 001236

2912 014632 012700 015264

2913 014636 172410

2914 014640 012701 015264

2915

2916 014644 174411

2917

2918 014646 170205

2919 014650 170303

2920

2921 014652 012704 140204

2922 014656 020405

2923 014660 001131

2924

2925 014662 012702 000004

2926 014666 020203

2927 014670 001140

2928

2929

2930 014672

2931 014674 104413

2932 014700 012704 040200

2933

2934 014702 012737 014722 001236

2935 014710 012700 015274

2936 014714 172410

2937 014716 012700 015264

2938 014722 174410

2939

2940 014724 170205

2941 014726 170303

2942

2943 014730 012704 140200

2944 014734 020405

2945 014736 001102

2946

2947 014740 012702 000004

2948 014744 020203

```
:FIRST TEST DIVD WITH (FSRC=AC=0) AND TRAPS DISABLED.
BBB0: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
MOV #40200,R4 ;SET UP FPS
LDFPS R4 ;WITH INTERRUPTS
MOV #BBBER1,FPVECT;SET UP FOR ANY FP INTERRUPTS.
MOV #BBB1,$TMP2
MOV #BBBP1,R0 ;SET UP ACO = 0
LDD (R0),ACO
MOV #BBBP1,R1 ;FSRC = 0
BBB1: DIVD (R1),ACO ;TEST INSTRUCTION
STFPS R5 ;GET FPS
STST R3 ;GET FEC
MOV #140204,R4 ;EXPECTED FPS.
CMP R4,R5 ;IS FPS CORRECT.
BNE BBBER2 ;IF INCORRECT BRANCH.
MOV #4,R2 ;EXPECTED FEC.
CMP R2,R3 ;IS FEC CORRECT?
BNE BBBER3 ;IF INCORRECT BRANCH.
;TEST DIVD WITH (FSRC=0) AND TRAPS DISABLED.
BBB2: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
MOV #40200,R4 ;LOAD FPS WITH TRAPS DISABLED.
LDFPS R4
MOV #BBB3,$TMP2
MOV #BBBP2,R0 ;SET UP ACO OPERAND (NON ZERO).
LDD (R0),ACO
MOV #BBBP1,R0 ;FSRC=0
BBB3: DIVD (R0),ACO
STFPS R5 ;GET FPS.
STST R3 ;GET FEC.
MOV #140200,R4 ;EXPECTED FPS.
CMP R4,R5 ;IS FPS CORRECT?
BNE BBBER2 ;IF INCORRECT BRANCH.
MOV #4,R2 ;EXPECTED FEC.
CMP R2,R3 ;WAS FEC CORRECT?
```

```

2949 014746 001111          BNE      BBBER3          ;IF INCORRECT BRANCH.
2950
2951          ;TEST DIVD WITH FSRC=0) AND TRAPS ENABLED.
2952 014750          BBB4:
      014750 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
2953 014752 012704 000200      MOV      #200,R4          ;SET UP FPS. TRAP ENABLED.
2954 014756 170104          LDFPS      R4
2955
2956 014760 012737 015006 001236      MOV      #BBB5,$TMP2
2957 014766 012700 015274          MOV      #BBBP2,R0          ;SET UP ACO OPERAND (NON ZERO).
2958 014772 172410          LDD      (R0),ACO
2959
2960 014774 012737 015014 000244      MOV      #BBB6,FPVECT          ;SET UP FOR THE EXPECTED INTERRUPT.
2961 015002 012700 015264          MOV      #BBBP1,R0          ;FSRC=0
2962
2963 015006 174410          BBB5:  DIVD      (R0),ACO          ;TEST INSTRUCTION (SHOULD RESULT IN TRAP).
2964 015010 170000          CFCC
2965
2966 015012 000502          BR      BBBER4          ;GO REPORT FAILURE, NO TRAP.
2967
2968 015014 022716 015010          BBB6:  CMP      #BBB5+2,(SP)          ;TRAP TO HERE WHEN THE DIVISION BY 0
2969                                     ;OCCURS. FIRST SEE IF THE ADDRESS OF
2970                                     ;THE TRAP IS 2+THE ADDRESS OF THE TEST
2971                                     ;DIVD INSTRUCTION.
2972 015020 001402          BEQ      1$
2973 015022 000137 037450          JMP      FPSPUR          ;IF NOT THEN REPORT AN UNEXPECTED
2974                                     ;FP TRAP.
2975 015026 170205          1$:  STFPS      R5          ;GET FPS.
2976 015030 170303          STST     R3          ;GET FEC.
2977 015032 022626          CMP      (SP)+,(SP)+          ;RESET THE STACK.
2978
2979 015034 012704 100200          MOV      #100200,R4          ;EXPECTED FPS.
2980 015040 020405          CMP      R4,R5          ;IS FPS CORRECT?
2981 015042 001040          BNE      BBBER2          ;IF INCORRECT BRANCH.
2982
2983 015044 012702 000004          MOV      #4,R2          ;EXPECTED FEC.
2984 015050 020203          CMP      R2,R3          ;IS FEC CORRECT?
2985 015052 001047          BNF      BBBER3          ;IF INCORRECT BRANCH.
2986
2987 015054 000137 015304          JMP      BBBDONE          ;OTHERWISE GO TO NEXT TEST.
2988
2989
2990          ;TRAP HERE IF AN UNEXPECTED INTERRUPT OCCURS.
2991 015060 062737 000002 001236          BBBER1: ADD     #2,$TMP2          ;SEE IF THE INTERRUPT OCCURRED
2992                                     ;DURING THE EXECUTION OF THE DIVD
2993                                     ;INSTRUCTION BEING TESTED.
2994 015066 021637 001236          CMP      (SP),$TMP2
2995 015072 001402          BEQ      1$
2996 015074 000137 037450          JMP      FPSPUR          ;IF NOT REPORT UNEXPECTED FP TRAP.
2997
2998 015100 022626          1$:  CMP      (SP)+,(SP)+          ;RESET THE STACK.
2999 015102 170303          STST     R3          ;GET FEC.
3000 015104 170205          STFPS     R5          ;GET FPS.
3001 015106 012737 000004 001240          MOV      #4,$TMP3          ;EXPECTED FEC.
3002 015114 010337 001242          MOV      R3,$TMP4
3003 015120 010537 001244          MOV      R5,$TMP5
3004 015124 010037 001250          MOV      R0,$TMP7
    
```



```

3005 015130 012737 140200 001246      MOV    #140200,$TMP6
3006 015136 104017      2$:    ERROR    +17      ;REPORT (BUT FD) FAILED RESULTING IN AN FP TRAP
3007                                     ;WITH TRAPS DISABLED.
3008 015140 000137 015304      JMP    BBBDONE
3009
3010                                     ;REPORT FPS INCORRECT:
3011 015144 010537 001242      BBBER2: MOV    R5,$TMP4
3012 015150 010437 001244      MOV    R4,$TMP5
3013 015154 010037 001246      MOV    R0,$TMP6
3014 015160 010137 001250      MOV    R1,$TMP7
3015 015164 104020      1$:    ERROR    +20
3016 015166 000137 015304      JMP    BBBDONE
3017
3018                                     ;REPORT FEC INCORRECT:
3019 015172 010337 001242      BBBER3: MOV    R3,$TMP4
3020 015176 010237 001240      MOV    R2,$TMP3
3021 015202 010037 001246      MOV    R0,$TMP6
3022 015206 010137 001250      MOV    R1,$TMP7
3023 015212 104021      1$:    ERROR    +21
3024 015214 000137 015304      JMP    BBBDONE
3025
3026                                     ;REPORT NO TRAP OCCURRED AFTER TRYING TO DIVIDE
3027                                     ;BY ZERO WITH ALL TRAPS ENABLED.
3028 015220 170303      BBBER4: STST   R3      ;GET FEC.
3029 015222 170205      STFPS  R5      ;GET FPS.
3030 015224 012737 000004 001242      MOV    #4,$TMP4
3031 015232 010337 001240      MOV    R3,$TMP3
3032 015236 010537 001244      MOV    R5,$TMP5
3033 015242 012737 100200 001246      MOV    #100200,$TMP6
3034 015250 010037 001250      MOV    R0,$TMP7
3035 015254 010137 001252      MOV    R1,$TMP10
3036 015260 104022      1$:    ERROR    +22
3037 015262 000410      BR     BBBDONE
3038
3039 015264 000000 000000 000000 BBBP1:  .WORD   0,0,0,0
3040 015274 012345 054321 023456 BBBP2:  .WORD   12345,54321,23456,76543
3041
3042
3043
3044 015304      BBBDONE:
      015304 104412      RSETUP      ;GO INITIALIZE THE FPS AND STACK; AND
                                     ;SEE IF THE USER HAS EXPRESSED
                                     ;THE DESIRE TO CHANGE THE SOFTWARE
                                     ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                     ;THE USER TYPED CONTROL G?).
3045
3046
3054
  
```

3055

```
.SBTTL TEST # 6 - DIVF TEST
:*****
:*TEST 6      DIVF TEST
:*
:*THIS IS A TEST OF THE DIVF INSTRUCTION. NOTE THAT A SUBROUTINE IS
:*USED TO SET UP THE OPERANDS, EXECUTE THE INSTRUCTION AND CHECK THE
:*RESULTS.
:*
:*****
```

```
015306 000004
3056
3057
3058 015310
015310 104413
3059 015312 004737 016070
3060 015316 000000 000000
3061 015322 012345 067012
3062 015326 000000 000000
3063 015332 000000
3064 015334 000004
3065 015336 012345 067012
3066 015342 104023
3067
3068
3069 015344
015344 104413
3070 015346 004737 016070
3071 015352 065652 125252
3072 015356 065600 000000
3073 015362 040252 125252
3074 015366 003000
3075 015370 003000
3076 015372 040052 125252
3077 015376 104024
3078
3079
3080 015400
015400 104413
3081 015402 004737 016070
3082 015406 076400 000000
3083 015412 076400 000000
3084 015416 040200 000000
3085 015422 001000
3086 015424 001000
3087 015426 140200 000000
3088
3089 015432 104025
3090
3091
3092 015434
015434 104413
3093 015436 004737 016070
3094 015442 056777 177777
3095 015446 054200 000000
3096 015452 042777 177777
3097 015456 000000
3098 015460 000000
```

```
TST6: SCOPE
:CHECK DIVF WITH (AC=0).
CCC1:
LPERR JSR PC, DIVFSUB ;SET UP THE LOOP ON ERROR ADDRESS.
1$: .WORD 0,0 ;AC
2$: .WORD 12345,67012 ;FSRC
3$: .WORD 0,0 ;RES
4$: 0 ;FPS BEFORE EXECUTION.
4 4 ;FPS AFTER EXECUTION
5$: .WORD 12345,67012 ;ERROR RESULT
6$: ERROR +23 ;RESULT BAD.
:TEST DIVF WITH AC POSITIVE, FSRC POSITIVE AND IN ROUND MODE.
CCC2:
LPERR JSR PC, DIVFSUB ;SET UP THE LOOP ON ERROR ADDRESS.
1$: .WORD 65652,125252 ;AC
2$: .WORD 65600,0 ;FSRC
3$: .WORD 40252,125252 ;RES
4$: 3000 ;FPS BEFORE EXECUTION.
3000 ;FPS AFTER EXECUTION.
5$: .WORD 40052,125252 ;ERROR RESULT.
6$: ERROR +24 ;DIV NORMALIZE FAILURE
:TEST DIVF WITH AC POSITIVE, FSRC POSITIVE.
CCC3:
LPERR JSR PC, DIVFSUB ;SET UP THE LOOP ON ERROR ADDRESS.
1$: .WORD 76400,0 ;AC
2$: .WORD 76400,0 ;FSRC
3$: .WORD 40200,0 ;RES
4$: 1000 ;FPS BEFORE EXECUTION.
1000 ;FPS AFTER EXECUTION.
5$: .WORD 140200,0 ;ERROR RES.
6$: ERROR +25 ;SIGN BAD.
:TEST DIVF WITH BOTH OPERANDS POSITIVE.
CCC4:
LPERR JSR PC, DIVFSUB ;SET UP THE LOOP ON ERROR ADDRESS.
1$: .WORD 56777,177777 ;AC
2$: .WORD 54200,0 ;FSRC
3$: .WORD 42777,177777 ;RES
4$: 0 ;FPS BEFORE EXECUTION.
0 ;FPS AFTER EXECUTION.
```

```

3099 015462 002000 002000 5$: .WORD 2000,2000 ;ERROR RES.
3100 015466 104023 6$: ERROR +23
3101
3102 ;TEST THE DIVF INSTRUCTION:
3103 015470 CCC5: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      015470 104413 JSR PC,DIVFSUB
3104 015472 004737 016070 1$: .WORD 12377,177777 ;AC
3105 015476 012377 177777 2$: .WORD 12300,0 ;FSRC
3106 015502 012300 000000 3$: .WORD 40252,125252 ;RES
3107 015506 040252 125252 4$: 0 ;FPS BEFORE EXECUTION.
3108 015512 000000 0 ;FPS AFTER EXECUTION.
3109 015514 000000 5$: .WORD -1,-1 ;ERROR RES.
3110 015516 177777 6$: ERROR +23
3111 015522 104023
3112
3113 ;TEST DIVIDE ALGORITHM. TEST ROUND CONSTANT.
3114 015524 CCC6: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      015524 104413 JSR PC,DIVFSUB
3115 015526 004737 016070 1$: .WORD 64600,1 ;AC
3116 015532 064600 000001 2$: .WORD 66600,0 ;FSRC
3117 015536 066600 000000 3$: .WORD 36200,1 ;RES
3118 015542 036200 000001 4$: 0 ;FPS BEFORE EXECUTION.
3119 015546 000000 0 ;FPS AFTER EXECUTION.
3120 015550 000000 5$: .WORD 3000,3000 ;ERROR RES.
3121 015552 003000 003000 6$: ERROR +23
3122 015556 104023
3123
3124 ;TEST DIVF.
3125 015560 CCC7: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      015560 104413 JSR PC,DIVFSUB
3126 015562 004737 016070 1$: .WORD 34577,177776 ;AC
3127 015566 034577 177776 2$: .WORD 23400,0 ;FSRC
3128 015572 023400 000000 3$: .WORD 51377,177776 ;RES
3129 015576 051377 177776 4$: 17 ;FPS BEFORE EXECUTION.
3130 015602 000017 0 ;FPS AFTER EXECUTION.
3131 015604 000000 5$: .WORD 3400,3400 ;ERROR RES.
3132 015606 003400 003400 6$: ERROR +23
3133 015612 104023
3134
3135 ;DIVF TEST.
3136 CCC8: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
3137 015614 104413 JSR PC,DIVFSUB
      015614 104413 1$: .WORD 67652,125252 ;AC
3138 015616 004737 016070 2$: .WORD 56500,0 ;FSRC
3139 015622 067652 125252 3$: .WORD 51343,107070 ;RES
3140 015626 056500 000000 4$: 0 ;FPS BEFORE EXECUTION.
3141 015632 051343 107070 5$: 0 ;FPS AFTER EXECUTION.
3142 015636 000000 6$: .WORD 51543,107070 ;ERROR RES.
3143 015640 000000 7$: ERROR +26 ;DIDN'T INCREMENT THE EXPONENT
3144 015642 051543 107070 ;AFTER DIVID NORMALIZATION.
3145 015646 104026
3146
3147
3148 ;DIVF WITH AC NEGATIVE, FSRC NEGATIVE.
3149 CCC9: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      015650 104413 JSR PC,DIVFSUB
3150 015652 004737 016070
    
```

```

3151 015656 140400 000000 1$: .WORD 140400,0 ;AC
3152 015662 140500 000000 2$: .WORD 140500,0 ;FSRC
3153 015666 040052 125253 3$: .WORD 040052,125253 ;RES
3154 015672 000000 4$: 0 ;FPS BEFORE EXECUTION.
3155 015674 000000 0 ;FPS AFTER EXECUTION.
3156 015676 140052 125253 5$: .WORD 140052,125253 ;ERROR RES.
3157 015702 104027 6$: ERROR +27 ;BAD SIGN.
3158
3159 ;DIVF WITH AC NEGATIVE AND FSRC POSITIVE.
3160 015704 CCC10: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
015704 104413 JSR PC,DIVFSUB
3161 015706 004737 016070 1$: .WORD 160077,0 ;AC
3162 015712 160077 000000 2$: .WORD 40277,0 ;FSRC
3163 015716 040277 000000 3$: .WORD 160000,0 ;RES
3164 015722 160000 000000 4$: 7 ;FPS BEFORE EXECUTION.
3165 015726 000007 10 ;FPS AFTER EXECUTION.
3166 015730 000010 5$: .WORD 60000,0 ;ERROR RES.
3167 015732 060000 000000 6$: ERROR +27 ;BAD SIGN.
3168 015736 104027
3169
3170 ;DIVF WITH AC POSITIVE AND FSRC NEGATIVE.
3171 015740 CCC11: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
015740 104413 JSR PC,DIVFSUB
3172 015742 004737 016070 1$: .WORD 40400,0 ;AC
3173 015746 040400 000000 2$: .WORD 140500,0 ;FSRC
3174 015752 140500 000000 3$: .WORD 140052,125253 ;RES
3175 015756 140052 125253 4$: 17 ;FPS BEFORE EXECUTION.
3176 015762 000017 10 ;FPS AFTER EXECUTION.
3177 015764 000010 5$: .WORD 40052,125253 ;ERROR RES.
3178 015766 040052 125253 6$: ERROR +27 ;BAD SIGN.
3179 015772 104027
3180
3181 ;TEST DIVF BOTH OPERANDS POSITIVE AND TRUNCATE MODE.
3182 CCC12: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
3183 015774 104413 JSR PC,DIVFSUB
015774 004737 016070 1$: .WORD 60100,1 ;AC
3184 015776 004737 016070 2$: .WORD 40300,0 ;FSRC
3185 016002 060100 000001 3$: .WORD 60000,0 ;RES
3186 016006 040300 000000 4$: 52 ;FPS BEFORE EXECUTION.
3187 016012 060000 000000 40 ;FPS AFTER EXECUTION.
3188 016016 000052 5$: .WORD 60000,1 ;ERROR RES.
3189 016020 000040 6$: ERROR +30 ;TRUNCATION ERROR
3190 016022 060000 000001
3191 016026 104030
3192
3193 ;DIVF WITH POSITIVE OPERANDS AND ROUND MODE.
3194 016030 CCC13: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
016030 104413 JSR PC,DIVFSUB
3195 016032 004737 016070 1$: .WORD 60100,1 ;AC
3196 016036 060100 000001 2$: .WORD 40300,0 ;FSRC
3197 016042 040300 000000 3$: .WORD 60000,1 ;RES
3198 016046 060000 000001 4$: 5 ;FPS BEFORE EXECUTION.
3199 016052 000005 0 ;FPS AFTER EXECUTION.
3200 016054 000000 5$: .WORD 60000,0 ;ERROR RES.
3201 016056 060000 000000 6$: ERROR +31 ;ROUND ERROR.
3202 016062 104031
3203

```



```

3261
3262 016214 021061 000010      CMP      (R0),10(R1)      ;IS THE RESULT CORRECT?
3263 016220 001011      BNE      10$              ;IF INCORRECT BRANCH.
3264 016222 026061 000002 000012      CMP      2(R0),12(R1)
3265 016230 001005      BNE      10$
3266
3267 016232 026104 000016      CMP      16(R1),R4        ;IS FPS CORRECT?
3268 016236 001020      BNE      15$              ;IF INCORRECT BRANCH.
3269 016240 000161 000026      JMP      26(R1)          ;IF NO ERRORS OCCURRED RETURN.
3270
3271 016244 021061 000020      10$:    CMP      (R0),20(R1)    ;DOES THE INCORRECT RESULT
3272 016250 001010      BNE      11$              ;MATCH THE ANTICIPATED INCORRECT RESULT.
3273 016252 026061 000002 000022      CMP      2(R0),22(R1)
3274 016260 001004      BNE      11$              ;BRANCH IF NO.
3275
3276 016262 010102      MOV      R1,R2           ;IT MATCHED SO RETURN TO THE ERROR
3277                                ;REPORT AT THE CALLING ROUTINE.
3278 016264 062702 000024      ADD      #24,R2
3279 016270 000112      JMP      (R2)
3280
3281 016272      11$:
3282 016272 104023      12$:    ERROR   +23
3283 016274 000161 000026      13$:    JMP      26(R1)
3284
3285 016300      15$:
3286 016300 104032      16$:    ERROR   +32
3287 016302 000774      BR      13$
3288
3289 016304 000000 000000 000000 000000  DIVFT: .WORD 0,0,0,0
3290
3291 016314      CCCDONE:
      016314 104412      RSETUP
                                ;GO INITIALIZE THE FPS AND STACK; AND
                                ;SEE IF THE USER HAS EXPRESSED
                                ;THE DESIRE TO CHANGE THE SOFTWARE
                                ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                ;THE USER TYPED CONTROL G?).

3292
3293
3300
    
```

3301

```
.SBTTL TEST # 7 - DIVD TEST
*****
*TEST 7      DIVD TEST
*
*THIS IS A TEST OF THE DIVD INSTRUCTION. NOTE THAT A SUBROUTINE IS
*USED TO SET UP THE OPERANDS. EXECUTE THE INSTRUCTION AND CHECK THE RESULTS.
*
*****
```

016316 000004

TST7: SCOPE

3302

:DIVD TEST WITH POSITIVE OPERANDS AND IN ROUND MODE.

3303

DDD1:

3304

016320

016320

3305

016322

3306

016326

3307

016336

3308

016346

3309

016356

3310

016360

3311

016362

3312

016372

3313

3314

3315

016374

016374

3316

016376

3317

016402

3318

016412

3319

016422

3320

016432

3321

016434

3322

016436

3323

016446

3324

3325

3326

016450

016450

3327

016452

3328

016456

3329

016466

3330

016476

3331

016506

3332

016510

3333

016512

3334

016522

3335

3336

3337

016524

016524

3338

016526

3339

016532

3340

016542

3341

016552

3342

016562

3343

016564

3344

016566

3345

016576

```
104413
004737 017010
034277 000000 000000 1$
040277 000000 000000 2$
034200 000000 000000 3$
000200 000200 4$
177777 177777 5$
104033 6$

104413
004737 017010
134277 000000 000000 1$
040277 000000 000000 2$
134200 000000 000000 3$
000207 000207 4$
000210 210
177777 177777 5$
104033 6$

104413
004737 017010
134300 000000 000000 1$
140300 000000 000000 2$
034200 000000 000000 3$
000250 250
000240 240
034200 000000 000000 5$
104035 6$

104413
004737 017010
034300 000000 000000 1$
140300 000000 000000 2$
134200 000000 000000 3$
000207 207
000210 210
134200 000000 000000 5$
104036 6$
```

```
;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC, DIVDSUB
;AC
;FSRC
;RES
;FPS BEFORE EXECUTION.
;FPS AFTER EXECUTION.
;ERROR RES.
-1,-1,-1,-1
+3$

;DIVD WITH AC NEGATIVE AND FSRC POSITIVE IN TRUNCATE MODE.
DDD2:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC, DIVDSUB
;AC
;FSRC
;RES
;FPS BEFORE EXECUTION.
;FPS AFTER EXECUTION.
;ERROR RESULT.
-1,-1,-1,-1
+3$

;DIVD TEST WITH OPERANDS BOTH NEGATIVE AND IN TRUNCATE MODE.
DDD3:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC, DIVDSUB
;AC
;FSRC
;RES
;FPS BEFORE EXECUTION.
;FPS AFTER EXECUTION.
;ERROR RES.
;TRUNCATION ERROR.
34200,0,0,1
+3$

;DIVD WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.
DDD4:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC, DIVDSUB
;AC
;FSRC
;RES
;FPS BEFORE EXECUTION.
;FPS AFTER EXECUTION.
;ERROR RES.
;ROUND ERROR.
34300,0,0,1
140300,0,0,0
134200,0,0,1
207
210
134200,0,0,0
+36
```



```

3346
3347 ;DIVD TEST.
3348 J16600 DDD5: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      016600 104413 JSR PC,DIVDSUB
3349 016602 004737 017010 .WORD 100400,0,0,0 ;AC
3350 016606 100400 000000 000000 1$: .WORD 500,0,0,0 ;FSRC
3351 016616 000500 000000 000000 2$: .WORD 140052,125252 ;RES
3352 016626 140052 125252 3$: .WORD 125252,125252
3353 016632 125252 125252
3354 016636 007647 4$: 7647 ;FPS BEFORE EXECUTION.
3355 016640 007650 7650 ;FPS AFTER EXECUTION.
3356 016642 177777 177777 5$: .WORD -1,-1,-1,-1 ;ERROR RES.
3357 016652 104033 6$: ERROR +33
3358
3359
    
```

```

3360 ;DIVD TEST WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.
3361 016654 DDD6: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      016654 104413 JSR PC,DIVDSUB
3362 016656 004737 017010 .WORD 400,0,0,0 ;AC
3363 016662 000400 000000 000000 1$: .WORD 100500,0,0,0 ;FSRC
3364 016672 100500 000000 000000 2$: .WORD 140052,125252 ;RES
3365 016702 140052 125252 3$: .WORD 125252,125253
3366 016706 125252 125253
3367 016712 007707 4$: 7707 ;FPS BEFORE EXECUTION.
3368 016714 007710 7710 ;FPS AFTER EXECUTION.
3369 016716 177777 177777 5$: .WORD -1,-1,-1,-1 ;ERROR RES.
3370 016726 104033 6$: ERROR +33
3371
    
```

```

3372 ;DIVD TEST.
3373 016730 DDD7: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      016730 104413 JSR PC,DIVDSUB
3374 016732 004737 017010 .WORD 170360,170360 ;AC
3375 016736 170360 170360 1$: .WORD 170360,170360 ;FSRC
3376 016742 170360 170360 2$: .WORD 170360,170360
3377 016746 170360 170360 3$: .WORD 170360,170360
3378 016752 170360 170360 .WORD 40200,0,0,0 ;RES
3379 016756 040200 000000 000000 3$: .WORD 7717 ;FPS BEFORE EXECUTION.
3380 016766 007717 7717 ;FPS AFTER EXECUTION.
3381 016770 007700 7700 ;ERROR RES.
3382 016772 177777 177777 5$: .WORD -1,-1,-1,-1
3383 017002 104033 6$: ERROR +33
3384
3385 017004 000137 017250 JMP DDDDONE ;GO TO NEXT TEST.
3386
    
```

3387 ;THIS SUBROUTINE, DIVDSUB, IS CALLED TO SET UP, EXECUTE
 3388 ;AND CHECK THE RESULT OF A DIVD INSTRUCTION. IT IS CALLED THUS:
 3389

```

3390 :
3391 : JSR PC,DIVDSUB
3392 : ACARG: .WORD X,X,X,X ;AC OPERAND
3393 : FSRCARG: .WORD X,X,X,X ;FSRC OPERAND
3394 : RES: .WORD X,X,X,X ;EXPECTED RESULT
3395 : FPSB: .WORD X ;FPS BEFORE EXECUTION
3396 : FPSA: .WORD X ;FPS AFTER EXECUTION
3397 : ERRES: .WORD X,X,X,X ;ERROR RESULT
3398 : ERR: ERROR +X ;RESULT ERROR
3399 : CONT: ;RETURN ADDRESS
    
```

3400
3401
3402

∴ THE OPERANDS ARE SET UP (USING ACO FOR THE AC OPERAND). THEN
∴ FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, DIVD IS EXECUTED.

```

3404                                     :AFTER THE EXECUTION THE RESULT IS CHECKED AGAINST THE
3405                                     :EXPECTED CORRECT RESULT, RES. IF IT IS CORRECT THEN THE FPS
3406                                     :IS CHECKED WITH THE EXPECTED CORRECT FPS, FPSA. IF THE FPS WAS
3407                                     :INCORRECT THEN IT IS REPORTED. IF THE RESULT WAS INCORRECT IT
3408                                     :IS COMPARED WITH ERRES IN AN ATTEMPT TO ANALYSE THE ERROR. IF
3409                                     :THE INCORRECT RESULT MATCHED ERRES THEN CONTROL IS PASSED TO
3410                                     :THE ERROR CALL AT ERR. IF THE INCORRECT RESULT DID NOT MATCH ERRES
3411                                     :THEN THE FAILURE IS REPORTED IN DIVDSUB AND CONTROL IS PASSED TO
3412                                     :CONT. IF NO ERRORS ARE DETECTED THEN DIVDSUB RETURNS CONTROL
3413                                     :TO CONT.
3414
3415 017010 012601                       DIVDSUB:      MOV      (SP)+,R1      ;GET A POINTER TO THE ARGUMENTS.
3416 017012 012700 000200                MOV      #200,R0      ;SET FD MODE.
3417 017016 170100                       LDFPS     R0
3418
3419 017020 010100                       MOV      R1,R0        ;SET UP THE ACO OPERAND.
3420 017022 172410                       LDD      (R0),ACO
3421 017024 016100 000030                MOV      30(R1),R0    ;LOAD THE FPS.
3422 017030 170100                       LDFPS     R0
3423
3424 017032 012737 017046 001236          MOV      #1$,STMP2
3425 017040 010100                       MOV      R1,R0        ;ESTABLISH A POINTER TO FSRC.
3426 017042 062700 000010                ADD      #10,R0
3427
3428 017046 174410                       1$:      DIVD      (R0),ACO      ;EXECUTE THE TEST INSTRUCTION.
3429
3430 017050 170204                       STFPS    R4           ;GET THE FPS.
3431 017052 012700 000200                MOV      #200,R0      ;SET FD MODE.
3432 017056 170100                       LDFPS     R0
3433
3434 017060 012700 017240                MOV      #DIVDT,R0    ;GET THE RESULT.
3435 017064 174010                       STD      ACO,(R0)
3436
3437 017066 010102                       MOV      R1,R2        ;SAVE DATA IN CASE OF ERROR.
3438 017070 010237 001240                MOV      R2,STMP3
3439 017074 062702 000010                ADD      #10,R2
3440 017100 010237 001242                MOV      R2,STMP4
3441 017104 062702 000010                ADD      #10,R2
3442 017110 010237 001244                MOV      R2,STMP5
3443 017114 012737 017240 001246          MOV      #DIVDT,STMP6
3444 017122 010437 001250                MOV      R4,STMP7
3445 017126 016137 000032 001252          MOV      32(R1),STMP10
3446
3447 017134 010102                       MOV      R1,R2        ;CHECK THE RESULT.
3448 017136 062702 000020                ADD      #20,R2
3449 017142 012703 017240                MOV      #DIVDT,R3
3450 017146 012705 000004                MOV      #4,R5
3451 017152 022223                       2$:      CMP      (R2)+,(R3)+
3452 017154 001006                       BNE     10$           ;BRANCH IF RESULT INCORRECT.
3453 017156 077503                       SOB     R5,2$
3454
3455 017160 026104 000032                CMP      32(R1),R4    ;IS FPS CORRECT?
3456 017164 001023                       BNE     15$           ;BRANCH IF INCORRECT.
3457 017166 000161 000046                JMP     46(R1)        ;RETURN.
3458
3459 017172 010102                       10$:     MOV      R1,R2        ;WAS INCORRECT RESULT ANTICIPATED?
3460 017174 062702 000034                ADD      #34,R2

```

```

3461 017200 012703 017240      MOV    #DIVDT,R3
3462 017204 012705 000004      MOV    #4,R5
3463 017210 022223      11$:  CMP    (R2)+,(R3)+
3464 017212 001005      BNE    12$           ;BRANCH IF NO.
3465 017214 077503      SOB    R5,11$
3466 017216 010102      MOV    R1,R2
3467 017220 062702 000044      ADD    #4,R2
3468
3469 017224 000112      JMP    (R2)
3470
3471 017226      12$:
3472 017226 104033      13$:  ERROR  +33
3473 017230 000161 000046      14$:  JMP    46(R1)
3474
3475 017234      15$:
3476 017234 104034      16$:  ERROR  +34
3477 017236 000774      BR     14$
3478
3479 017240 000000 000000 000000  DIVDT: .WORD 0,0,0,0
3480
3481 017250      DDDDONE:
      017250 104412      RSETUP
      ;GO INITIALIZE THE FPS AND STACK; AND
      ;SEE IF THE USER HAS EXPRESSED
      ;THE DESIRE TO CHANGE THE SOFTWARE
      ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
      ;THE USER TYPED CONTROL G?).

3482
3483
3491
    
```

3492

```
.SBTTL TEST # 10 - MULF TEST  
:*****  
:TEST 10 MULF TEST  
:*****  
:THIS IS A TEST OF THE MULF INSTRUCTION. IT MAKES USE OF A SUBROUTINE  
:TO SET UP THE OPERANDS, EXECUTE THE MULF INSTRUCTION AND CHECK THE  
:RESULTS.  
:*****
```

```
3493 017252 000004  
3494  
3495 017254  
3496 017254 104413  
3497 017256 004737 020034  
3498 017262 000000 000000  
3499 017266 000000 000000  
3500 017272 000000 000000  
3501 017276 007517  
3502 017300 007504  
3503 017302 177777 177777  
3504 017306 104037  
3505  
3506 017310  
3507 017310 104413  
3508 017312 004737 020034  
3509 017316 071625 034435  
3510 017322 000000 000000  
3511 017326 000000 000000  
3512 017332 000013  
3513 017334 000004  
3514 017336 177777 177777  
3515 017342 104037  
3516  
3517 017344  
3518 017344 104413  
3519 017346 004737 020034  
3520 017352 000000 000000  
3521 017356 071625 153443  
3522 017362 000000 000000  
3523 017366 007500  
3524 017370 007504  
3525 017372 177777 177777  
3526 017376 104037  
3527  
3528 017400  
3529 017400 104413  
3530 017402 004737 020034  
3531 017406 040200 000000  
3532 017412 040177 177777  
3533 017416 040177 177777  
3534 017422 000017  
3535 017424 000000  
3536 017426 140177 177777
```

```
TST10: SCOPE
```

```
:MULF WITH (FSRC=AC=0)
```

```
EEE1: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
JSR PC,MULFSUB  
1$: .WORD 0,0 ;AC  
2$: .WORD 0,0 ;FSRC  
3$: .WORD 0,0 ;RES  
4$: 7517 ;FPS BEFORE EXECUTION.  
7504 ;FPS AFTER EXECUTION.  
5$: .WORD -1,-1  
6$: ERROR +37
```

```
:MULF WITH (FSRC=0).
```

```
EEE2: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
JSR PC,MULFSUB  
1$: .WORD 71625,34435 ;AC  
2$: .WORD 0,0 ;FSRC  
3$: .WORD 0,0 ;RES  
4$: 13 ;FPS BEFORE EXECUTION.  
4 ;FPS AFTER EXECUTION.  
5$: .WORD -1,-1 ;ERROR RES.  
6$: ERROR +37
```

```
:MULF WITH (AC=0)
```

```
EEE3: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
JSR PC,MULFSUB  
1$: .WORD 0,0 ;AC  
2$: .WORD 071625,153443 ;FSRC  
3$: .WORD 0,0 ;RES  
4$: 7500 ;FPS BEFORE EXECUTION.  
7504 ;FPS AFTER EXECUTION.  
5$: .WORD -1,-1 ;ERROR RES.  
6$: ERROR +37
```

```
:MULF WITH AC POSITIVE AND FSRC POSITIVE IN ROUND MODE.
```

```
EEE4: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
JSR PC,MULFSUB  
1$: .WORD 40200,0 ;AC  
2$: .WORD 40177,-1 ;FSRC  
3$: .WORD 40177,-1 ;RES  
4$: 17 ;FPS BEFORE EXECUTION.  
0 ;FPS AFTER EXECUTION.  
5$: .WORD 140177,-1 ;ERROR RES.
```

```

3536 017432 104041      6$:      ERROR      +41      ;BAD SIGN.
3537
3538      ;MULF WITH AC POSITIVE AND FSRC POSITIVE IN TRUNCATE MODE.
3539 017434      EEE5:      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
          017434 104413      JSR      PC,MULFSUB
3540 017436 004737 020034      1$:      .WORD      40177,-1      ;AC
3541 017442 040177 177777      2$:      .WORD      40200,0      ;FSRC
3542 017446 040200 000000      3$:      .WORD      40177,-1      ;RES
3543 017452 040177 177777      4$:      40      ;FPS BEFORE EXECUTION.
3544 017456 000040      ;FPS AFTER EXECUTION.
3545 017460 000040      5$:      .WORD      37777,-1      ;ERROR RES.
3546 017462 037777 177777      6$:      ERROR      +42      ;ST 252 TO 044 INTO 444 (BUT Y62)
3547 017466 104042      ;MUL. NORMALIZATION FAILURE.
3548
3549
3550      ;MULF WITH BOTH OPERANDS POSITIVE NORMALIZE TEST.
3551 017470      EEE6:      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
          017470 104413      JSR      PC,MULFSUB
3552 017472 004737 020034      1$:      .WORD      40100,0      ;AC
3553 017476 040100 000000      2$:      .WORD      40100,0      ;FSRC
3554 017502 040100 000000      3$:      .WORD      40020,0      ;RES
3555 017506 040020 000000      4$:      12      ;FPS BEFORE EXECUTION.
3556 017512 000012      ;FPS AFTER EXECUTION.
3557 017514 000000      5$:      .WORD      42040,0      ;ERROR RES.
3558 017516 042040 000000      6$:      ERROR      +43      ;ST 252 TO 444 INTO 042 (BUT Y62)
3559 017522 104043      ;MUL. NORMALIZATION FAILURE.
3560
3561
3562      ;MULF WITH BOTH OPERANDS POSITIVE IN ROUND MODE.
3563 017524      EEE7:      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
          017524 104413      JSR      PC,MULFSUB
3564 017526 004737 020034      1$:      .WORD      17500,0      ;AC
3565 017532 017500 000000      2$:      .WORD      23652,125252      ;FSRC
3566 017536 023652 125252      3$:      .WORD      3177,-1      ;RES
3567 017542 003177 177777      4$:      7417      ;FPS BEFORE EXECUTION.
3568 017546 007417      ;FPS AFTER EXECUTION.
3569 017550 007400      5$:      .WORD      -1,-1
3570 017552 177777 177777      6$:      ERROR      +37
3571 017556 104037
3572
3573      ;MULF WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.
3574 017560      EEE8:      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
          017560 104413      JSR      PC,MULFSUB
3575 017562 004737 020034      1$:      .WORD      40342,0      ;AC
3576 017566 040342 000000      2$:      .WORD      176542,0      ;FSRC
3577 017572 176542 000000      3$:      .WORD      176707,102000      ;RES
3578 017576 176707 102000      4$:      7      ;FPS BEFORE EXECUTION.
3579 017602 000007      ;FPS AFTER EXECUTION.
3580 017604 000010      7$:      .WORD      76507,102000      ;ERROR RES.
3581 017606 076507 102000      6$:      ERROR      +41      ;BAD SIGN.
3582 017612 104041
3583
3584      ;MULF WITH AC NEGATIVE AND FSRC POSITIVE IN ROUND MODE.
3585 017614      EEE9:      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
          017614 104413      JSR      PC,MULFSUB
3586 017616 004737 020034      1$:      .WORD      140200,0      ;AC
3587 017622 140200 000000
  
```

3588	017626	007417	007417	2\$:	.WORD	7417,7417	:FSRC
3589	017632	107417	007417	3\$:	.WORD	107417,7417	:RES
3590	017636	000000		4\$:	0		:FPS BEFORE EXECUTION.
3591	017640	000010			10		:FPS AFTER EXECUTION.
3592	017642	007417	007417	5\$:	.WORD	7417,7417	:ERROR RES.
3593	017646	104041		6\$:	ERROR	+41	:BAD SIGN.
3594							
3595							
3596	017650						
	017650	104413		EEE10:	LPERR		:SET UP THE LOOP ON ERROR ADDRESS.
3597	017652	004737	020034		JSR	PC,MULFSUB	
3598	017656	144600	000000	1\$:	.WORD	144600,0	:AC
3599	017662	154000	000000	2\$:	.WORD	154000,0	:FSRC
3600	017666	060400	000000	3\$:	.WORD	60400,0	:RES
3601	017672	000017		4\$:	17		:FPS BEFORE EXECUTION.
3602	017674	000000			0		:FPS AFTER EXECUTION.
3603	017676	160400	000000	5\$:	.WORD	160400,0	:ERROR RES.
3604	017702	104041		6\$:	ERROR	+41	:BAD SIGN.
3605							
3606							
3607	017704						
	017704	104413		EEE11:	LPERR		:SET UP THE LOOP ON ERROR ADDRESS.
3608	017706	004737	020034		JSR	PC,MULFSUB	
3609	017712	140300	000000	1\$:	.WORD	140300,0	:AC
3610	017716	160000	000001	2\$:	.WORD	160000,1	:FSRC
3611	017722	060100	000002	3\$:	.WORD	60100,2	:RES
3612	017726	000010		4\$:	10		:FPS BEFORE EXECUTION.
3613	017730	000000			0		:FPS AFTER EXECUTION.
3614	017732	060100	000001	5\$:	.WORD	60100,1	:ERROR RES.
3615	017736	104044		6\$:	ERROR	+44	:ROUND FAILURE.
3616							
3617							
3618	017740						
	017740	104413		EEE12:	LPERR		:SET UP THE LOOP ON ERROR ADDRESS.
3619	017742	004737	020034		JSR	PC,MULFSUB	
3620	017746	060000	000001	1\$:	.WORD	60000,1	:AC
3621	017752	140300	000000	2\$:	.WORD	140300,0	:FSRC
3622	017756	160100	000001	3\$:	.WORD	160100,1	:RES
3623	017762	007547		4\$:	7547		:FPS BEFORE EXECUTION.
3624	017764	007550			7550		:FPS AFTER EXECUTION.
3625	017766	160100	000001	5\$:	.WORD	160100,1	:ERROR RES.
3626	017772	104045		6\$:	ERROR	+45	:TRUNCATION ERROR.
3627							
3628							
3629	017774						
	017774	104413		EEE13:	LPERR		:SET UP THE LOOP ON ERROR ADDRESS.
3630	017776	004737	020034		JSR	PC,MULFSUB	
3631	020002	040277	000000	1\$:	.WORD	40277,0	:AC
3632	020006	060000	000001	2\$:	.WORD	60000,1	:FSRC
3633	020012	060077	000001	3\$:	.WORD	60077,1	:RES
3634	020016	000014		4\$:	14		:FPS BEFORE EXECUTION.
3635	020020	000000			0		:FPS AFTER EXECUTION.
3636	020022	060077	000002	5\$:	.WORD	60077,2	:ERROR RES.
3637	020026	104044		6\$:	ERROR	+44	:ROUND FAILURE. CONSTANT BAD.
3638							
3639	020030	000137	020260		JMP	EEEDONE	:GO TO THE NEXT TEST.
3640							

3641
3642
3643
3644
3645
3646
3647
3648
3649
3650
3651
3652
3653
3654
3655
3656
3657
3658
3659
3660
3661
3662
3663
3664
3665
3666
3667 020034 012601
3668 020036 012700 000200
3669 020042 170100
3670 020044 010100
3671 020046 172410
3672 020050 016100 000014
3673 020054 170100
3674 020056 012737 020072 001236
3675 020064 010100
3676 020066 062700 000004
3677
3678 020072 171010
3679
3680 020074 170204
3681 020076 012700 000200
3682 020102 170100
3683
3684 020104 012700 020250
3685 020110 174010
3686
3687 020112 010102
3688 020114 010237 001240
3689 020120 062702 000004
3690 020124 010237 001242
3691 020130 062702 000004
3692 020134 010237 001244
3693 020140 012737 020250 001246
3694 020146 010437 001250
3695 020152 016137 000016 001252
3696
3697 020160 021061 000010

: THIS SUBROUTINE, MULFSUB, IS CALLED TO SET UP, EXECUTE
: AND CHECK THE RESULT OF A MULF INSTRUCTION. IT IS CALLED THUS:

```

      JSR      PC,MULFSUB
ACARG: .WORD  X,X      ;AC OPERAND
FSRCARG: .WORD X,X     ;FSRC OPERAND
RES:     .WORD  X,X     ;EXPECTED RESULT
FPSB:    .WORD  X       ;FPS BEFORE EXECUTION
FPSA:    .WORD  X       ;FPS AFTER EXECUTION
ERRES:   .WORD  X,X     ;ERROR RESULT
ERR:     ERROR  +X      ;RESULT ERROR
CONT:
    
```

: THE OPERANDS ARE SET UP (USING ACO FOR THE AC OPERAND). THEN
: FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, MULF IS EXECUTED.
: AFTER THE EXECUTION THE RESULT IS CHECKED AGAINST THE
: EXPECTED CORRECT RESULT, RES. IF IT IS CORRECT THEN THE FPS
: IS CHECKED WITH THE EXPECTED CORRECT FPS, FPSA. IF THE FPS WAS
: INCORRECT THEN IT IS REPORTED. IF THE RESULT WAS INCORRECT IT
: IS COMPARED WITH ERRES IN AN ATTEMPT TO ANALYSE THE ERROR. IF
: THE INCORRECT RESULT MATCHED ERRES THEN CONTROL IS PASSED TO
: THE ERROR CALL AT ERR. IF THE INCORRECT RESULT DID NOT MATCH ERRES
: THEN THE FAILURE IS REPORTED IN MULFSUB AND CONTROL IS PASSED TO
: CONT. IF NO ERRORS ARE DETECTED THEN MULFSUB RETURNS CONTROL
: TO CONT.

```

MULFSUB:      MOV      (SP)+,R1      ;GET A POINTER TO THE ARGUMENTS.
              MOV      #200,R0      ;SET FD MODE.
              LDFPS   R0
              MOV      R1,R0        ;LOAD THE AC OPERAND.
              LDD     (R0),ACO
              MOV      14(R1),R0     ;LOAD THE FPS
              LDFPS   R0
              MOV      #1$, $TMP2
              MOV      R1,R0
              ADD      #4,R0         ;ESTABLISH A POINTER TO FSRC.
1$:           MULF    (R0),ACO       ;TEST INSTRUCTION.
              STFPS   R4            ;GET THE FPS.
              MOV      #200,R0      ;SET FD MODE
              LDFPS   R0
              MOV      #MULFT,R0     ;GET THE RESULT OF THE MULF.
              STD     ACO,(R0)
              MOV      R1,R2        ;SAVE THE DATA IN CASE OF ERROR.
              MOV      R2,$TMP3
              ADD      #4,R2
              MOV      R2,$TMP4
              ADD      #4,R2
              MOV      R2,$TMP5
              MOV      #MULFT,$TMP6
              MOV      R4,$TMP7
              MOV      16(R1),$TMP10
              CMP     (R0),10(R1)    ;IS THE RESULT CORRECT?
    
```


3698	020164	001011			BNE	10\$:IF INCORRECT BRANCH.
3699	020166	026061	000002	000012	CMP	2(R0),12(R1)		
3700	020174	001005			BNE	10\$		
3701								
3702	020176	026104	000016		CMP	16(R1),R4		:IS FPS CORRECT?
3703	020202	001020			BNE	15\$:IF INCORRECT BRANCH.
3704	020204	000161	000026		JMP	26(R1)		:IF NO ERRORS OCCURRED RETURN.
3705								
3706	020210	021061	000020	10\$:	CMP	(R0),20(R1)		:DOES THE INCORRECT RESULT
3707	020214	001010			BNE	11\$:MATCH THE ANTICIPATED INCORRECT RESULT.
3708	020216	026061	000002	000022	CMP	2(R0),22(R1)		
3709	020224	001004			BNE	11\$:BRANCH IF NO.
3710								
3711	020226	010102			MOV	R1,R2		:IT MATCHED SO RETURN TO THE ERROR
3712								:REPORT AT THE CALLING ROUTINE.
3713	020230	062702	000024		ADD	#24,R2		
3714	020234	000112			JMP	(R2)		
3715								
3716	020236			11\$:				:REPORT RESULT INCORRECT.
3717	020236	104037		12\$:	ERROR	+37		
3718	020240	000161	000026	13\$:	JMP	26(R1)		
3719								
3720	020244			15\$:				:REPORT FPS INCORRECT.
3721	020244	104040		16\$:	ERROR	+40		
3722	020246	000774			BR	13\$		
3723								
3724	020250	000000	000000	000000	MULFT:	.WORD	0,0,0,0	
3725								
3726	020260				EEEDUNE:			
	020260	104412			RSETUP			:GO INITIALIZE THE FPS AND STACK; AND
								:SEE IF THE USER HAS EXPRESSED
								:THE DESIRE TO CHANGE THE SOFTWARE
								:VIRTUAL CONSOLE SWITCH REGISTER (HAS
								:THE USER TYPED CONTROL G?).
3727								
3728								
3736								

3737

```
.SBTTL TEST # 11 - MULD TEST
:*****
:TEST 11      MULD TEST
:
:THIS IS A TEST OF THE MULD INSTRUCTION. NOTE THAT A SUBROUTINE IS
:USED TO SET UP THE OPERANDS, EXECUTE THE MULD INSTRUCTION AND
:CHECK THE RESULTS.
:*****
```

020262 000004

TST11: SCOPE

3738

:MULD TEST WITH AC POSITIVE AND FSRC POSITIVE.

3739

FFF1:

3740

020264

104413

LPERR

:SET UP THE LOOP ON ERROR ADDRESS.

3741

C20266

004737

020550

JSR

PC,MULDSUB

3742

020272

040200

000000

000000

1\$:

.WORD

40200,0,0,0

:AC

3743

020302

023777

177777

177777

2\$:

.WORD

23777,-1,-1,-1

:FSRC

3744

020312

023777

177777

177777

3\$:

.WORD

23777,-1,-1,-1

:RES

3745

020322

000217

4\$:

217

:FPS BEFORE EXECUTION.

3746

020324

000200

200

:FPS AFTER EXECUTION.

3747

020326

023777

177777

000000

5\$:

.WORD

23777,-1,0,0

:ERROR RES.

3748

020336

104047

6\$:

ERROR

+47

:BAD CONSTANT USED IN ALGORITHM

3749

3750

3751

:MULD TEST WITH BOTH OPERANDS POSITIVE TRUNCATION TEST.

3752

020340

FFF2:

3753

020340

104413

LPERR

:SET UP THE LOOP ON ERROR ADDRESS.

3754

020342

004737

020550

JSR

PC,MULDSUB

3755

020346

065400

000000

000000

1\$:

.WORD

65400,0,0,1

:AC

3756

020356

037577

177777

177777

2\$:

.WORD

37577,-1,-1,-2

:FSRC

3757

020366

064777

177777

177777

3\$:

.WORD

64777,-1,-1,-1

:RES

3758

020376

000247

4\$:

247

:FPS BEFORE EXECUTION.

3759

020400

000240

240

:FPS AFTER EXECUTION.

3760

020402

065000

000000

000000

5\$:

.WORD

65000,0,0,0

:ERROR RES.

3761

020412

104050

6\$:

ERROR

+50

:TRUNCATION ERROR.

3762

3763

020414

:MULD TEST WITH BOTH OPERANDS NEGATIVE IN ROUND MODE.

FFF3:

3764

020414

104413

LPERR

:SET UP THE LOOP ON ERROR ADDRESS.

3765

020416

004737

020550

JSR

PC,MULDSUB

3766

020422

137577

177777

177777

1\$:

.WORD

137577,-1,-1,-2

:AC

3767

C20432

165400

000000

000000

2\$:

.WORD

165400,0,0,1

:FSRC

3768

020442

065000

000000

000000

3\$:

.WORD

65000,0,0,0

:RES

3769

020452

007717

4\$:

7717

:FPS BEFORE EXECUTION.

3770

020454

007700

7700

:FPS AFTER EXECUTION.

3771

020456

064777

177777

177777

5\$:

.WORD

64777,-1,-1,-1

:ERROR RES.

3772

020466

104051

6\$:

ERROR

+51

:ROUND ERROR.

3773

3774

020470

:MULD TEST WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.

FFF4:

3775

020470

104413

LPERR

:SET UP THE LOOP ON ERROR ADDRESS.

3776

020472

004737

020550

JSR

PC,MULDSUB

3777

020476

017500

000000

000000

1\$:

.WORD

17500,0,0,0

:AC

3778

020506

123652

125252

2\$:

.WORD

123652,125252

:FSRC

3779

020512

125252

125252

3\$:

.WORD

125252,125252

:RES

3780

020516

103177

177777

177777

4\$:

.WORD

103177,-1,-1,-1

:RES

3780

020526

000200

200

:FPS BEFORE EXECUTION.

3781 020530 000210
 3782 020532 103200 000000 000000
 3783 020542 104052
 3784
 3785 020544 000137 021010
 3786
 3787
 3788
 3789
 3790
 3791
 3792
 3793
 3794
 3795
 3796
 3797
 3798
 3799
 3800
 3801
 3802
 3803
 3804
 3805
 3806
 3807
 3808
 3809
 3810
 3811
 3812
 3813 020550 012601
 3814 020552 012700 000200
 3815 020556 170100
 3816
 3817 020560 010100
 3818 020562 172410
 3819 020564 016100 000030
 3820 020570 170100
 3821
 3822 020572 012737 020606 001236
 3823 020600 010100
 3824 020602 062700 000010
 3825
 3826 020606 171010
 3827
 3828 020610 170204
 3829 020612 012700 000200
 3830 020616 170100
 3831
 3832 020620 012700 021000
 3833 020624 174010
 3834
 3835 020626 010102
 3836 020630 010237 001240
 3837 020634 062702 000010

210 :FPS AFTER EXECUTION.
 5\$: .WORD 103200,0,0,0 :ERROR RES.
 6\$: ERROR +52 :ROUND ERROR (BAD CONSTANT).

JMP FFFDONE

:THIS SUBROUTINE, MULDSUB, IS CALLED TO SET UP, EXECUTE
 :AND CHECK THE RESULT OF A MULD INSTRUCTION. IT IS CALLED THUS:

```

    JSR PC,MULDSUB
    ACARG: .WORD X,X,X,X ;AC OPERAND
    FSRCARG: .WORD X,X,X,X ;FSRC OPERAND
    RES: .WORD X,X,X,X ;EXPECTED RESULT
    FPSB: .WORD X ;FPS BEFORE EXECUTION
    FPSA: .WORD X ;FPS AFTER EXECUTION
    ERRES: .WORD X,X,X,X ;ERROR RESULT
    ERR: ERROR +X ;RESULT ERROR
    CONT: ;RETURN ADDRESS
    
```

:THE OPERANDS ARE SET UP (USING ACO FOR THE AC OPERAND). THEN
 :FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, MULD IS EXECUTED.
 :AFTER THE EXECUTION THE RESULT IS CHECKED AGAINST THE
 :EXPECTED CORRECT RESULT, RES. IF IT IS CORRECT THEN THE FPS
 :IS CHECKED WITH THE EXPECTED CORRECT FPS, FPSA. IF THE FPS WAS
 :INCORRECT THEN IT IS REPORTED. IF THE RESULT WAS INCORRECT IT
 :IS COMPARED WITH ERRES IN AN ATTEMPT TO ANALYSE THE ERROR. IF
 :THE INCORRECT RESULT MATCHED ERRES THEN CONTROL IS PASSED TO
 :THE ERROR CALL AT ERR. IF THE INCORRECT RESULT DID NOT MATCH ERRES
 :THEN THE FAILURE IS REPORTED IN MULDSUB AND CONTROL IS PASSED TO
 :CONT. IF NO ERRORS ARE DETECTED THEN MULDSUB RETURNS CONTROL
 :TO CONT.

```

MULDSUB: MOV (SP)+,R1 ;GET A POINTER TO THE ARGUMENTS.
        MOV #200,R0 ;SET FD MODE.
        LDFPS R0
        MOV R1,R0 ;SET UP THE ACO OPERAND.
        LDD (R0),ACO
        MOV 30(R1),R0 ;LOAD THE FPS.
        LDFPS R0
        MOV #18,$TMP2
        MOV R1,R0 ;ESTABLISH A POINTER TO FSRC.
        ADD #10,R0
        1$: MULD (R0),ACO ;EXECUTE THE TEST INSTRUCTION.
        STFPS R4 ;GET THE FPS.
        MOV #200,R0 ;SET FD MODE.
        LDFPS R0
        MOV #MULDT,R0 ;GET THE RESULT.
        STD ACO,(R0)
        MOV R1,R2 ;SAVE DATA IN CASE OF ERROR.
        MOV R2,$TMP3
        ADD #10,R2
    
```

```

3838 020640 010237 001242      MOV    R2,$TMP4
3839 020644 062702 000010      ADD    #10,R2
3840 020650 010237 001244      MOV    R2,$TMP5
3841 020654 012737 021000 001246      MOV    #MULDT,$TMP6
3842 020662 010437 001250      MOV    R4,$TMP7
3843 020666 016137 000032 001252      MOV    32(R1),$TMP10
3844
3845 020674 010102      MOV    R1,R2          ;CHECK THE RESULT.
3846 020676 062702 000020      ADD    #20,R2
3847 020702 012703 021000      MOV    #MULDT,R3
3848 020706 012705 000004      MOV    #4,R5
3849 020712 022223      2$:  CMP    (R2)+,(R3)+
3850 020714 001006      BNE   10$            ;BRANCH IF RESULT INCORRECT.
3851 020716 077503      SOB   R5,2$
3852
3853 020720 026104 000032      CMP    32(R1),R4     ;IS FPS CORRECT?
3854 020724 001023      BNE   15$            ;BRANCH IF INCORRECT.
3855 020726 000161 000046      JMP   46(R1)         ;RETURN.
3856
3857 020732 010102      10$: MOV    R1,R2          ;WAS INCORRECT RESULT ANTICIPATED?
3858 020734 062702 000034      ADD    #34,R2
3859 020740 012703 021000      MOV    #MULDT,R3
3860 020744 012705 000004      MOV    #4,R5
3861 020750 022223      11$: CMP    (R2)+,(R3)+
3862 020752 001005      BNE   12$            ;BRANCH IF NO.
3863 020754 077503      SOB   R5,11$
3864 020756 010102      MOV    R1,R2          ;IF THE INCORRECT RESULT WAS
3865 020760 062702 000044      ADD    #44,R2        ;ANTICIPATED RETURN TO THE
3866                                     ;ERROR REPORT IN THE CALLING
3867 020764 000112      JMP   (R2)           ;ROUTINE.
3868
3869 020766      12$:                                     ;REPORT RESULT INCORRECT.
3870 020766 104246      13$: ERROR  +246
3871 020770 000161 000046      14$: JMP   46(R1)
3872
3873 020774      15$:                                     ;REPORT FPS INCORRECT.
3874 020774 104046      16$: ERROR  +46
3875 020776 000774      BR    14$
3876
3877 021000 000000 000000 000000 MULDT: .WORD 0,0,0,0
3878
3879 021010      FFFDONE:
      021010 104412      RSETUP              ;GO INITIALIZE THE FPS AND STACK; AND
                                     ;SEE IF THE USER HAS EXPRESSED
                                     ;THE DESIRE TO CHANGE THE SOFTWARE
                                     ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                     ;THE USER TYPED CONTROL G?).

3880
3881
3890
3891                                     ;TEST TITLE:UNDER/OVERFLOW, USING MULF WITH TRAPS DISABLED
    
```

3892

```
.SBTTL TEST # 12 - SEE COMMENT ABOVE FOR TEST TITLE
:*****
:*TEST 12      SEE COMMENT ABOVE FOR TEST TITLE
:*
:*THIS IS A TEST OF THE OVERFLOW AND UNDERFLOW CONDITIONS USING
:*THE MULF INSTRUCTION WITH TRAPS DISABLED. NOTE THAT A SUBROUTINE
:*IS USED TO SET UP THE OPERANDS, EXECUTE THE MULF INSTRUCTION AND
:*CHECK THE RESULTS.
:*
:*****
TST12: SCOPE
```

```
3893 021012 000004
3894
3895 021014
3896 021014 104413
3897 021016 004737 021240
3898 021022 020200 000000
3899 021026 020000 000000
3900 021032 000000 000000
3901 021036 177777 177777
3902 021042 000000
3903 021044 000004
3904 021046 000012
3905 021050 177777
3906 021052 104117
3907 021054 000401
3908 021056 104114
3909
3910
3911 021060
```

```
:UNDERFLOW, WITH EXPONENT OF RESULT = -129
IIII:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,OVUNFNT
1$: .WORD 20200,0 ;AC
2$: .WORD 20000,0 ;FSRC
3$: .WORD 0,0 ;RES
4$: .WORD -1,-1 ;ERROR RES.
5$: 0 ;FPS BEFORE EXECUTION.
4 ;FPS AFTER EXECUTION.
6$: 12 ;FEC
-1 ;FLAG
7$: ERROR +117 ;ST 331 TO 155 INTO 115 (BUT FIU)
BR 8$
ERROR +114
8$:
```

```
3912 021060 104413
3913 021062 004737 021240
3914 021066 010200 000000
3915 021072 010000 000000
3916 021076 000000 000000
3917 021102 010000 000000
3918 021106 005013
3919 021110 005004
3920 021112 000012
3921 021114 177777
3922 021116 104120
3923 021120 000401
3924 021122 104114
3925 021124
3926
3927
3928 021124
```

```
:UNDERFLOW, WITH EXPONENT OF RESULT = -193
IIII:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,OVUNFNT
1$: .WORD 10200,0 ;AC
2$: .WORD 10000,0 ;FSRC
3$: .WORD 0,0 ;RES
4$: .WORD 10000,0 ;ERROR RES.
5$: 5013 ;FPS BEFORE EXECUTION.
5004 ;FPS AFTER EXECUTION.
6$: 12 ;FEC
-1 ;FLAG
7$: ERROR +120 ;SETTING FIUV OR FIV CAUSES TRAP
BR 8$ ;WITH FIU CLEAR.
ERROR +114
8$:
```

```
3929 021124 104413
3930 021126 004737 021240
3931 021132 060200 000000
3932 021136 060000 000000
3933 021142 000000 000000
3934 021146 060000 000000
3935 021152 000000
3935 021154 000006
```

```
:OVERFLOW, EXPONENT OF RESULT = 128
IIII:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,OVUNFNT
1$: .WORD 60200,0 ;AC
2$: .WORD 60000,0 ;FSRC
3$: .WORD 0,0 ;RES
4$: .WORD 60000,0 ;ERROR RES.
5$: 0 ;FPS BEFORE EXECUTION.
6 ;FPS AFTER EXECUTION.
```

```

3936 021156 000010      6$:      10      :FEC
3937 021160 000000      0      :FLAG
3938 021162 104121      7$:      ERROR +121 :ST 333 TO 136 INTO 116 (BUT FIV).
3939 021164 000401      BR      8$
3940 021166 104113      ERROR +113
3941 021170
3942
3943
3944 021170      :OVERFLOW, EXPONENT OF RESULT = 130
III4:
3945 021170 104413      LPERR      :SET UP THE LOOP ON ERROR ADDRESS.
3946 021172 004737 021240      JSR      PC,OVUNFNT
3947 021176 060200 000000      1$:      .WORD 60200,0      :AC
3948 021202 060200 000000      2$:      .WORD 60200,0      :FSRC
3949 021212 177777 177777      3$:      .WORD 0,0      :RES
3950 021216 006011      4$:      .WORD -1,-1      :ERROR RES.
3951 021220 006006      5$:      6011      :FPS BEFORE EXECUTION.
3952 021222 000010      6$:      6006      :FPS AFTER EXECUTION.
3953 021224 000000      7$:      10      :FEC
3954 021226 104122      0      :FLAG
3955      :SETTING FIUV OR FIU WITH
3956 021230 000401      BR      8$      :FIV CLEAR CAUSES TRAP.
3957 021232 104113      ERROR +113
3958 021234 000137 021650      8$:      JMP      IIIDONE      ;GO TO NEXT TEST.
3959
3960
3961
3962      :THIS SUBROUTINE, OVUNFNT, IS USED TO SET UP THE OPERANDS, EXECUTE
3963      :THE MULF INSTRUCTION AND CHECK THE RESULTS OF AN INSTRUCTION WITH
3964      :OPERANDS WHICH SHOULD RESULT IN EITHER OVERFLOW OR UNDERFLOW. A CALL
3965      :TO IT IS MADE THUS:
3966      :
3967      :
3968      :
3969      :
3970      :
3971      :
3972      :
3973      :
3974      :
3975      :
3976      :
3977      :
3978      :
3979      :
3980      :
3981      :
3982      :
3983      :
3984      :
3985      :
3986      :
3987      :
3988      :
3989      :
3990      :
3991      :

```

```

ACARG: .WORD X,X      :AC OPERAND
FSRCARG: .WORD X,X      :FSRC OPERAND
RES: .WORD X,X      :EXPECTED RESULT
ERRES: .WORD X,X      :ERROR RESULT
FPSB: .WORD X      :FPS BEFORE EXECUTION
FPSA: .WORD X      :FPS AFTER EXECUTION
FEC: .WORD X      :EXPECTED FEC
FLAG: .WORD X      :0/-1,OVER/UNDER FLOW FLAG
ERR1: ERROR +X      :TRAP ERROR.
BR CONT
ERR2: ERROR +X      :DATA, RESULT ERROR
CONT:      :RETURN ADDRESS

```

```

:THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN
:THE MULF INSTRUCTION IS EXECUTED. IF NO TRAP OCCURS THEN THE
:RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
:COMPARED WITH FPSA IF THIS TOO IS CORRECT OVUNFNT RETURNS CONTROL
:TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNFNT
:REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
:MULF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
:ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
:THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNFNT
:WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE
:RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNFNT WILL
:REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.

```

```

3992 ;IF A TRAP OCCURS (IT SHOULD NOT) THEN OVUNFNT WILL READ THE FEC.
3993 ;SHOULD THE FEC MATCH THE ANTICIPATED FEC OVUNFNT WILL
3994 ;STORE ALL DATA AND TRANSFER CONTROL TO THE ERROR CALL AT ERR1. IF THE
3995 ;FEC IS NOT THE SAME AS THE ANTICIPATED FEC OVUNFNT WILL REPORT
3996 ;THE ERROR AND RETURN TO CONT. NOTE THAT OVUNFNT USES THE FLAG
3997 ;TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN
3998 ;UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).
3999
4000 021240 012601 OVUNFNT: MOV (SP)+,R1 ;GET A POINTER TO THE ARGUMENTS.
4001 021242 012700 000200 MOV #200,R0 ;SET FD MODE.
4002 021246 170100 LDFPS R0
4003
4004 021250 010100 MOV R1,R0 ;LOAD ACO, OPERAND.
4005 021252 172410 LDD (R0),ACO
4006
4007 021254 010102 MOV R1,R2 ;SAVE THE DATA PATTERNS IN CASE OF
4008 021256 010237 001240 MOV R2,$TMP3 ;ERROR.
4009 021262 062702 000004 ADD #4,R2
4010 021266 010237 001242 MOV R2,$TMP4
4011 021272 062702 000004 ADD #4,R2
4012 021276 010237 001244 MOV R2,$TMP5
4013 021302 016137 000022 001252 MOV 22(R1),$TMP10
4014 021310 012737 021640 001246 MOV #OVFNIT,$TMP6
4015
4016 021316 016100 000020 MOV 20(R1),R0 ;LOAD THE FPS.
4017 021322 170100 LDFPS R0
4018 021324 012737 021346 001236 MOV #1,$TMP2
4019 021332 012737 021532 000244 MOV #25$,FPVECT ;SET UP THE FP TRAP VECTOR IN CASE
4020 ;OF ERROR.
4021 021340 010100 MOV R1,R0 ;COMPUTE THE ADDRESS OF FSRC.
4022 021342 062700 000004 ADD #4,R0
4023
4024 021346 171010 1$: MULF (R0),ACO ;TEST INSTRUCTION.
4025
4026 021350 170204 2$: STFPS R4 ;GET FPS.
4027 021352 170305 STST R5 ;GET FEC.
4028 021354 012700 000200 MOV #200,R0 ;SET FD MODE.
4029 021360 170100 LDFPS R0
4030 021362 012700 021640 MOV #OVFNIT,R0 ;GET THE RESULT.
4031 021366 174010 STD ACO,(R0)
4032 021370 010437 001250 MOV R4,$TMP7
4033 021374 010537 001254 MOV R5,$TMP11
4034
4035 021400 012700 021640 MOV #OVFNIT,R0 ;CHECK THE RESULT.
4036 021404 010102 MOV R1,R2
4037 021406 062702 000010 ADD #10,R2
4038 021412 012703 000002 MOV #2,R3
4039 021416 022022 3$: CMP (R0)+,(R2)+ ;BRANCH IF INCORRECT.
4040 021420 001015 BNE 15$
4041 021422 077303 SOB R3,3$
4042
4043 021424 026104 000022 CMP 22(R1),R4 ;WAS FPS CORRECT?
4044 021430 001002 BNE 10$ ;BRANCH IF FPS IS INCORRECT.
4045
4046 021432 000161 000036 4$: JMP 36(R1) ;RETURN, TEST COMPLETED.
4047
4048 ;REPORT INCORRECT FPS.
    
```

4049 021436 005761 000026
4050 021442 001002
4051
4052
4053 021444 104111
4054 021446 000771
4055
4056 021450
4057 021450 104112
4058 021452 000767
4059

10\$: TST 26(R1)
BNE 12\$

11\$: ERROR +111
BR 4\$

12\$:
13\$: ERROR +112
BR 4\$

;WAS THE RESULT OVER OR UNDER FLOW?
;BRANCH IF UNDERFLOW.

;REPORT FPS BAD AFTER OVERFLOW.

;REPORT FPS BAD AFTER UNDERFLOW.


```

4061          ;RESULT INCORRECT.
4062 021454 012700 021640 15$: MOV #OVFNTT,R0 ;SEE IF FAILURE IS ANTICIPATED
4063 021460 010102          MOV R1,R2 ;FAILURE.
4064 021462 062702 000014      ADD #14,R2
4065 021466 012703 000002      MOV #2,R3
4066 021472 022022          16$: CMP (R0)+,(R2)+ ;BRANCH IF NOT ANTICIPATED.
4067 021474 001007          BNE 17$
4068 021476 077303          SOB R3,16$
4069
4070 021500 010102          MOV R1,R2 ;ERROR WAS ANTICIPATED SO RETURN
4071 021502 062702 000034      ADD #34,R2 ;TO THE ERROR REPORT IN THE CALLING
4072 021506 010237 001236      MOV R2,$TMP2 ;ROUTINE.
4073 021512 000112          JMP (R2)
4074
4075 021514 005761 000026          17$: TST 26(R1) ;RESULT WAS NOT ANTICIPATED
4076          ;SO ERROR MUST BE REPORTED HERE.
4077          ;FIRST SEE IF ARGUMENTS SHOULD
4078          ;HAVE RESULTED IN OVERFLOW OR UNDER
4079          ;FLOW BY LOOKING AT THE FLAG.
4080 021520 001002          BNE 19$ ;BRANCH IF UNDERFLOW EXPECTED.
4081
4082          ;REPORT RESULT INCORRECT, EXPECTING
4083 021522 104113          18$: ERROR +113 ;OVERFLOW.
4084 021524 000742          BR 4$
4085
4086 021526          19$: ;REPORT RESULT INCORRECT, EXPECTING
4087 021526 104114          20$: ERROR +114 ;UNDERFLOW.
4088 021530 000740          BR 4$
4089
4090          ;IF AN FP TRAP OCCURS COME HERE.
4091 021532 011602          25$: MOV (SP),R2 ;GET ADDRESS OF TRAP.
4092 021534 022702 021350      CMP #2$,R2 ;WAS THE TRAP DURING THE MULF INSTRUCTION?
4093 021540 001402          BEQ 26$ ;BRANCH IF YES.
4094 021542 000137 037450      JMP FPSPUR ;OTHERWISE GO REPORT A SPURIOUS
4095          ;FP TRAP.
4096 021546 022626          26$: CMP (SP)+,(SP)+ ;RESET THE STACK.
4097 021550 010237 001236      MOV R2,$TMP2 ;SAVE DATA FOR ERROR REPORT.
4098 021554 170204          STFPS R4 ;GET FPS.
4099 021556 170305          STST R5 ;GET FEC.
4100 021560 012700 000200      MOV #200,R0 ;SET FD MODE.
4101 021564 170100          LDFPS R0
4102 021566 012700 021640      MOV #OVFNTT,R0 ;GET THE RESULT.
4103 021572 174010          STD ACO,(R0)
4104 021574 010537 001254      MOV R5,$TMP11
4105 021600 020561 000024      CMP R5,24(R1)
4106 021604 001004          BNE 27$ ;WAS THE FEC ANTICIPATED?
4107          ;BRANCH IF NOT ANTICIPATED.
4108 021606 010102          MOV R1,R2 ;ERROR WAS ANTICIPATED SO
4109 021610 062702 000030      ADD #30,R2 ;RETURN TO THE ERROR REPORT OF THE
4110          ;CALLING ROUTINE.
4111 021614 000112          JMP (R2)
4112
4113 021616 005761 000026          27$: TST 26(R1) ;THE ERROR WAS NOT ANTICIPATED SO
4114          ;IT MUST BE REPORTED HERE. FIRST SEE IF EXPECTED
4115          ;OVERFLOW OR UNDER FLOW.
4116 021622 001003          BNE 29$ ;BRANCH IF EXPECTING UNDERFLOW
4117
    
```

4118
4119 021624 104115 28S: ERROR +115
4120 021626 000161 000036 JMP 36(R1)
4121
4122 021632 29S:
4123 021632 104116 30S: ERROR +116
4124 021634 000161 000036 JMP 36(R1)
4125
4126 021640 000000 000000 000000 OVFNTT: .WORD 0,0,0,0
4127
4128 021650 IIIDONE:
021650 104412 RSETUP

;REPORT TRAPPED ON OVERFLOW WITH FIV=0
;REPORT TRAPPED ON UNDER FLOW WITH FIU=0
;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

4129
4130
4131
4140
4141

;TEST TITLE:UNDER/OVERFLOW, USING MULD WITH TRAP DISABLED

```

4142          .SBTTL TEST # 13 - SEE COMMENT ABOVE FOR TEST TITLE
              :*****
              :*TEST 13      SEE COMMENT ABOVE FOR TEST TITLE
              :*
              :*THIS IS A TEST OF THE OVERFLOW AND UNDERFLOW CONDITIONS THAT CAN
              :*ARRISE USING THE MULD INSTRUCTION WITH TRAPS DISABLED. A SUBROUTINE IS
              :*USED TO SET UP THE OPERANDS, EXECUTE THE MULD INSTRUCTION AND
              :*CHECK THE RESULTS.
              :*
              :*****
              :TST13: SCOPE
4143          021652 000004
4144          ;UNDERFLOW, EXPONENT OF RESULT=-129
4145          JJJ1:
4146          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
4147          JSR          PC,OVUNDNT
4148          1$:          .WORD 20200,0          ;AC
4149          2$:          .WORD 127272,0
4150          3$:          .WORD 20000,0,0,0      ;FSRC
4151          4$:          .WORD 0,0,0,0          ;RES
4152          5$:          .WORD 127272,0        ;ERROR RES.
4153          6$:          200                    ;FPS BEFORE EXECUTION.
4154          7$:          204                    ;FPS AFTER EXECUTION.
4155          8$:          12                    ;FEC
4156          9$:          -1                    ;FLAG
4157          10$:         ERROR +131             ;ST 331 TO 155 INTO 115 (BUT FIU)
4158          11$:         BR 8$
4159          12$:         ERROR +132             ;ST 115 (BUT FD)
4160          13$:
4161          ;UNDERFLOW, EXPONENT OF RESULT = -193
4162          JJJ2:
4163          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
4164          JSR          PC,OVUNDNT
4165          1$:          .WORD 10200,0          ;AC
4166          2$:          .WORD 123456,0
4167          3$:          .WORD 10000,0,0,0      ;FSRC
4168          4$:          .WORD 0,0,0,0          ;RES
4169          5$:          .WORD 0,0,123456,0    ;ERROR RES
4170          6$:          5213                  ;FPS BEFORE EXECUTION.
4171          7$:          5204                  ;FPS AFTER EXECUTION.
4172          8$:          12                    ;FEC
4173          9$:          -1                    ;FLAG
4174          10$:         ERROR +133            ;SETTING FIUV OR FIV BAD.
4175          11$:         BR 8$
4176          12$:         ERROR +132            ;ST 115 (BUT FD)
4177          13$:
4178          ;OVERFLOW, EXPONENT OF RESULT = 128
4179          JJJ3:
4180          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
4181          JSR          PC,OVUNDNT
4182          1$:          .WORD 60200,0          ;AC
4183          2$:          .WORD 65432,0
4184          3$:          .WORD 60000,0,0,0      ;FSRC
4185          4$:          .WORD 0,0,0,0          ;RES
    
```

```

4186 022062 000000 000000 065432 4$: .WORD 0,0,65432,0 ;ERROR RES.
4187 022072 000200 5$: 200 ;FPS BEFORE EXECUTION.
4188 022074 000206 206 ;FPS AFTER EXECUTION.
4189 022076 000010 6$: 10 ;FEC
4190 022100 000000 0 ;FLAG
4191 022102 104134 7$: ERROR +134 ;ST 333 TO 136 INTO 116 (BUT FIV)
4192 022104 000401 BR 8$
4193 022106 104135 ERROR +135 ;ST 116 (BUT FD)
4194 022110 8$:
4195
4196
4197
4198 022110
    
```

;OVERFLOW, EXPONENT OF RESULT = 130
 JJJ4:

```

4199 022110 104413 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
4199 022112 004737 022200 JSR PC,OVUNDNT
4200 022116 060200 000000 1$: .WORD 60200,0 ;AC
4201 022122 125252 000000 .WORD 125252,0
4202 022126 060200 000000 000000 2$: .WORD 60200,0,0,0 ;FSRC
4203 022136 000000 000000 000000 3$: .WORD 0,0,0,0 ;RES
4204 022146 000000 000000 125252 4$: .WORD 0,0,125252,0 ;ERROR RES.
4205 022156 006211 5$: 6211 ;FPS BEFORE EXECUTION.
4206 022160 006206 6206 ;FPS AFTER EXECUTION.
4207 022162 000010 6$: 10 ;FEC
4208 022164 000000 0 ;FLAG
4209 022166 104136 7$: ERROR +136 ;SETTING FIUV OR FIV BAD.
4210 022170 000401 BR 8$
4211 022172 104135 ERROR +135 ;ST 116 (BUT FD)
4212 022174 000137 022610 8$: JMP JJJDONE ;GO TO NEXT TEST.
    
```

;THIS SUBROUTINE, OVUNDNT, IS USED TO SET UP THE OPERANDS, EXECUTE
 ;THE MULD INSTRUCTION AND CHECK THE RESULTS OF AN INSTRUCTION WITH
 ;OPERANDS WHICH SHOULD RESULT IN EITHER OVERFLOW OR UNDERFLOW. A CALL
 ;TO IT IS MADE THUS:

```

ACARG: .WORD X,X,X,X ;AC OPERAND
FSRCARG: .WORD X,X,X,X ;FSRC OPERAND
RES: .WORD X,X,X,X ;EXPECTED RESULT
ERRES: .WORD X,X,X,X ;ERROR RESULT
FPSB: .WORD X ;FPS BEFORE EXECUTION
FPSA: .WORD X ;FPS AFTER EXECUTION
FEC: .WORD X ;EXPECTED FEC
FLAG: .WORD X ;0/-1,OVER/UNDER FLOW FLAG
ERR1: ERROR +X ;TRAP ERROR.
BR CONT
ERR2: ERROR +X ;DATA, RESULT ERROR
CONT: ;RETURN ADDRESS
    
```

;THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN
 ;THE MULD INSTRUCTION IS EXECUTED. IF NO TRAP OCCURS THEN THE
 ;RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
 ;COMPARED WITH FPSA IF THIS TOO IS CORRECT OVUNDNT RETURNS CONTROL
 ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNDNT
 ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
 ;MULD IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
 ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
 ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNDNT
 ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE

4213
4214
4215
4216
4217
4218
4219
4220
4221
4222
4223
4224
4225
4226
4227
4228
4229
4230
4231
4232
4233
4234
4235
4236
4237
4238
4239
4240
4241

```

4242 :RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNDNT WILL
4243 :REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
4244 :IF A TRAP OCCURS (IT SHOULD NOT) THEN OVUNDNT WILL READ THE FEC.
4245 :SHOULD THE FEC MATCH THE ANTICIPATED FEC OVUNDNT WILL
4246 :STORE ALL DATA AND TRANSFER CONTROL TO THE ERROR CALL AT ERR1. IF THE
4247 :FEC IS NOT THE SAME AS THE ANTICIPATED FEC OVUNDNT WILL REPORT
4248 :THE ERROR AND RETURN TO CONT. NOTE THAT OVUNDNT USES THE FLAG
4249 :TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN
4250 :UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).
4251
4252 022200 012601 00020G OVUNDNT: MOV (SP)+,R1 ;GET A POINTER TO THE ARGUMENTS.
4253 022202 012700 MOV #200,R0 ;SET FD MODE.
4254 022206 170100 LDFPS R0
4255
4256 022210 010100 MOV R1,R0 ;LOAD ACO, OPERAND.
4257 022212 172410 LDD (R0),ACO
4258
4259 022214 010102 MOV R1,R2 ;SAVE THE DATA PATTERNS IN CASE OF
4260 022216 010237 001240 MOV R2,$TMP3 ;ERROR.
4261 022222 062702 000010 ADD #10,R2
4262 022226 010237 001242 MOV R2,$TMP4
4263 022232 062702 000010 ADD #10,R2
4264 022236 010237 001244 MOV R2,$TMP5
4265 022242 016137 000042 001252 MOV 42(R1),$TMP10
4266 022250 012737 022600 001246 MOV #OVDNTT,$TMP6
4267
4268 022256 016100 000040 MOV 40(R1),R0 ;LOAD THE FPS.
4269 022262 170100 LDFPS R0
4270 022264 012737 022306 001236 MOV #1,$TMP2
4271 022272 012737 022472 000244 MOV #25$,FPVECT ;SET UP THE FP TRAP VECTOR IN CASE
4272 :OF ERROR.
4273 022300 010100 MOV R1,R0 ;COMPUTE THE ADDRESS OF FSRC.
4274 022302 062700 000010 ADD #10,R0
4275
4276 022306 171010 1$: MULD (R0),ACO ;TEST INSTRUCTION.
4277
4278 022310 170204 2$: STFPS R4 ;GET FPS.
4279 022312 170305 STST R5 ;GET FEC.
4280 022314 012700 000200 MOV #200,R0 ;SET FD MODE.
4281 022320 170100 LDFPS R0
4282 022322 012700 022600 MOV #OVDNTT,R0 ;GET THE RESULT.
4283 022326 174010 STD ACO,(R0)
4284 022330 010437 001250 MOV R4,$TMP7
4285 022334 010537 001254 MOV R5,$TMP11
4286
4287 022340 012700 022600 MOV #OVDNTT,R0 ;CHECK THE RESULT.
4288 022344 010102 MOV R1,R2
4289 022346 062702 000020 ADD #20,R2
4290 022352 012703 000004 MOV #4,R3
4291 022356 022022 3$: CMP (R0)+,(R2)+ ;BRANCH IF INCORRECT.
4292 022360 001015 BNE 15$
4293 022362 077303 SOB R3,3$
4294
4295 022364 026104 000042 CMP 42(R1),R4 ;WAS FPS CORRECT?
4296 022370 001002 BNE 10$ ;BRANCH IF FPS IS INCORRECT.
4297
4298 022372 000161 000056 4$: JMP 56(R1) ;RETURN, TEST COMPLETED.
    
```

```

4299
4300
4301 022376 005761 000046      ;REPORT INCORRECT FPS.
10$:   TST      46(R1)          ;WAS THE RESULT OVER OR UNDER FLOW?
4302 022402 001002              ;BRANCH IF UNDERFLOW.
4303
4304
4305 022404 104123              ;REPORT FPS BAD AFTER OVERFLOW.
4306 022406 000771              ;
4307
4308 022410
4309 022410 104124              ;REPORT FPS BAD AFTER UNDERFLOW.
4310 022412 000767              ;
4311
4312
4313 022414 012700 022600      ;RESULT INCORRECT.
15$:   MOV      #OVDNTT,R0      ;SEE IF FAILURE IS ANTICIPATED
4314 022420 010102              ;FAILURE.
4315 022422 062702 000030      ;
4316 022426 012703 000004      ;
4317 022432 022022              ;
4318 022434 001007              ;
4319 022436 077303              ;
4320
4321 022440 010102              ;
4322 022442 062702 000054      ;ERROR WAS ANTICIPATED SO RETURN
4323 022446 010237 001236      ;TO THE ERROR REPORT IN THE CALLING
4324 022452 000112              ;ROUTINE.
4325
4326 022454 005761 000046      ;
17$:   TST      46(R1)          ;RESULT WAS NOT ANTICIPATED
4327
4328
4329
4330
4331 022460 001002              ;SO ERROR MUST BE REPORTED HERE.
4332
4333
4334 022462 104125              ;FIRST SEE IF ARGUMENTS SHOULD
4335 022464 000742              ;HAVE RESULTED IN OVERFLOW OR UNDER
4336
4337 022466
4338 022466 104126              ;FLOW BY LOOKING AT THE FLAG.
4339 022470 000740              ;BRANCH IF UNDERFLOW EXPECTED.
4340
4341
4342 022472 011602              ;REPORT RESULT INCORRECT, EXPECTING
4343 022474 022702 022310      ;OVERFLOW.
4344 022500 001402              ;
4345 022502 000137 037450      ;
4346
4347 022506 022626              ;REPORT RESULT INCORRECT, EXPECTING
4348 022510 010237 001236      ;UNDERFLOW.
4349 022514 170204              ;
4350 022516 170305              ;
4351 022520 012700 000200      ;
4352 022524 170100              ;
4353 022526 012700 022600      ;
4354 022532 174010              ;
4355 022534 010537 001254      ;IF AN FP TRAP OCCURS COME HERE.
25$:   MOV      (SP),R2          ;GET ADDRESS OF TRAP.
4356
4357
4358
4359
4360
4361
4362
4363
4364
4365
4366
4367
4368
4369
4370
4371
4372
4373
4374
4375
4376
4377
4378
4379
4380
4381
4382
4383
4384
4385
4386
4387
4388
4389
4390
4391
4392
4393
4394
4395
4396
4397
4398
4399
4400
4401
4402
4403
4404
4405
4406
4407
4408
4409
4410
4411
4412
4413
4414
4415
4416
4417
4418
4419
4420
4421
4422
4423
4424
4425
4426
4427
4428
4429
4430
4431
4432
4433
4434
4435
4436
4437
4438
4439
4440
4441
4442
4443
4444
4445
4446
4447
4448
4449
4450
4451
4452
4453
4454
4455
4456
4457
4458
4459
4460
4461
4462
4463
4464
4465
4466
4467
4468
4469
4470
4471
4472
4473
4474
4475
4476
4477
4478
4479
4480
4481
4482
4483
4484
4485
4486
4487
4488
4489
4490
4491
4492
4493
4494
4495
4496
4497
4498
4499
4500
    
```

4356	022540	020561	000044		CMP	R5,44(R1)		: WAS THE FEC ANTICIPATED?
4357	022544	001004			BNE	27\$: BRANCH IF NOT ANTICIPATED.
4358								
4359	022546	010102			MOV	R1,R2		: ERROR WAS ANTICIPATED SO
4360	022550	062702	000050		ADD	#50,R2		: RETURN TO THE ERROR REPORT OF THE
4361								: CALLING ROUTINE.
4362	022554	000112			JMP	(R2)		
4363								
4364	022554	005761	000026	27\$:	TST	26(R1)		: THE ERROR WAS NOT ANTICIPATED SO
4365								: IT MUST BE REPORTED HERE. FIRST SEE IF EXPECTED
4366								: OVERFLOW OR UNDER FLOW.
4367	022562	001003			BNE	29\$: BRANCH IF EXPECTING UNDERFLOW
4368								
4369								: REPORT TRAPPED ON OVERFLOW WITH FIV=0
4370	022564	104127		28\$:	ERROR	+127		
4371	022566	000161	000056		JMP	56(R1)		
4372								
4373	022572			29\$:				: REPORT TRAPPED ON UNDER FLOW WITH FIU=0
4374	022572	104130		30\$:	ERROR	+130		
4375	022574	000161	000056		JMP	56(R1)		
4376								
4377	022600	000000	000000	000000	OVDNTT:	.WORD	0,0,0,0	
4378								
4379	022610				JJJDONE:			
	022610	104412			RSETUP			: GO INITIALIZE THE FPS AND STACK; AND
								: SEE IF THE USER HAS EXPRESSED
								: THE DESIRE TO CHANGE THE SOFTWARE
								: VIRTUAL CONSOLE SWITCH REGISTER (HAS
								: THE USER TYPED CONTROL G?).

4380
 4381
 4382
 4394
 4395

: TEST TITLE: UNDER/OVERFLOW, USING MULF WITH TRAPS ENABLED

4396

```
.SBTTL TEST # 14 - SEE COMMENT ABOVE FOR TEST TITLE
:*****
:*TEST 14 SEE COMMENT ABOVE FOR TEST TITLE
:*
:*THIS IS A TEST OF THE UNDERFLOW AND OVERFLOW
:*CONDITIONS THAT CAN OCCUR USING THE MULF INSTRUCTION.
:*A SUBROUTINE IS CALLED TO SET UP THE OPERANDS,
:* EXECUTE THE MULF INSTRUCTION AND CHECK
:*THE RESULTS. HERE THE PARTICULAR INTERRUPT,
:*EITHER OVERFLOW OR UNDERFLOW, IS ENABLED SO A TRAP SHOULD
:*OCCUR.
:*
:*****
TST14: SCOPE
```

```
022612 000004
4397
4398
4399 022614
022614 104413
4400 022616 004737 023040
4401 022622 020123 045676
4402 022626 020200 000000
4403 022632 000123 045676
4404 022636 177777 177777
4405 022642 002000
4406 022644 102004
4407 022646 000012
4408 022650 177777
4409 022652 104145
4410 022654 000401
4411 022656 104144
4412 022660
4413
4414
4415 022660
022660 104413
4416 022662 004737 023040
4417 022666 010127 127272
4418 022672 010200 000000
4419 022676 060127 127272
4420 022702 177777 177777
4421 022706 007017
4422 022710 107000
4423 022712 000012
4424 022714 177777
4425 022716 104146
4426 022720 000401
4427 022722 104144
4428 022724
4429
4430
4431 022724
022724 104413
4432 022726 004737 023040
4433 022732 060252 125252
4434 022736 060000 000000
4435 022742 000052 125252
4436 022746 177777 177777
```

```
:UNDERFLOW, EXPONENT OF RESULT = -129
KKK1:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,OVUNFT
1$: .WORD 20123,45676 ;AC
2$: .WORD 20200,0 ;FSRC
3$: .WORD 123,45676 ;RES
4$: .WORD -1,-1 ;ERROR RES.
5$: 2000 ;FPS BEFORE EXECUTION.
102004 ;FPS AFTER EXECUTION.
6$: 12 ;FEC
-1 ;FLAG
7$: ERROR +145 ;ST 331 (BUT FIU) NO TRAP.
BR 8$
ERROR +144
8$:

:UNDERFLOW, EXPONENT OF THE RESULT = -193
KKK3:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,OVUNFT
1$: .WORD 10127,127272 ;AC
2$: .WORD 10200,0 ;FSRC
3$: .WORD 60127,127272 ;RES
4$: .WORD -1,-1 ;ERROR RES.
5$: 7017 ;FPS BEFORE EXECUTION.
107000 ;FPS AFTER EXECUTION.
6$: 12 ;FEC
-1
7$: ERROR +146 ;ST 137 (BUT FIU) NO TRAP.
BR 8$
ERROR +144
8$:

:OVERFLOW, EXPONENT OF THE RESULT = 128
KKK4:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,OVUNFT
1$: .WORD 60252,125252 ;AC
2$: .WORD 60000,0 ;FSRC
3$: .WORD 000052,125252 ;RES
4$: .WORD -1,-1 ;ERROR RES.
```


4437 022752 001000
 4438 022754 101006
 4439 022756 000010
 4440 022760 000000
 4441 022762 104147
 4442 022764 000401
 4443 022766 104143
 4444 022770
 4445
 4446
 4447 022770
 022770 104413
 4448 022772 004737 023040
 4449 022776 060345 067654
 4450 023002 060200 000000
 4451 023006 000345 067654
 4452 023012 177777 177777
 4453 023016 007015
 4454 023020 107002
 4455 023022 000010
 4456 023024 000000
 4457 023026 104150
 4458 023030 000401
 4459 023032 104143
 4460 023034 000137 023452
 4461
 4462
 4463
 4464
 4465
 4466
 4467
 4468
 4469
 4470
 4471
 4472
 4473
 4474
 4475
 4476
 4477
 4478
 4479
 4480
 4481
 4482
 4483
 4484
 4485
 4486
 4487
 4488
 4489
 4490
 4491
 4492

5S: 1000 ;FPS BEFORE EXECUTION.
 101006 ;FPS AFTER EXECUTION.
 6S: 10 ;FEC
 0 ;FLAG
 7S: ERROR +147 ;ST 333 (BUT FIV) NO TRAP
 BR 8\$
 ERROR +143
 8S:
 ;OVERFLOW, EXPONENT OF RESULT = 130
 KKK5:
 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
 JSR PC_OVUNFT
 1S: .WORD 60345,67654 ;AC
 2S: .WORD 60200,0 ;FSRC
 3S: .WORD 345,67654 ;RES
 4S: .WORD -1,-1 ;ERROR RES.
 5S: 7015 ;FPS BEFORE EXECUTION.
 107002 ;FPS AFTER EXECUTION.
 6S: 10 ;FEC
 0 ;FLAG
 7S: ERROR +150 ;ST 133 (BUT FIV) NO TRAP
 BR 8\$
 ERROR +143
 8S: JMP KKKDONE

;THIS SUBROUTINE, OVUNFT, IS USED TO SET UP THE OPERANDS, EXECUTE
 ;THE MULF INSTRUCTION AND CHECK THE RESULTS OF AN INSTRUCTION WITH
 ;OPERANDS WHICH SHOULD RESULT IN EITHER OVERFLOW OR UNDERFLOW. A CALL
 ;TO IT IS MADE THUS:

```

    ACARG: .WORD X,X ;AC OPERAND
    FSRCARG: .WORD X,X ;FSRC OPERAND
    RES: .WORD X,X ;EXPECTED RESULT
    ERRES: .WORD X,X ;ERROR RESULT
    FPSB: .WORD X ;FPS BEFORE EXECUTION
    FPSA: .WORD X ;FPS AFTER EXECUTION
    FEC: .WORD X ;EXPECTED FEC
    FLAG: .WORD X ;0/-1,OVER/UNDER FLOW FLAG
    ERR1: ERROR +X ;TRAP ERROR.
    BR CONT
    ERR2: ERROR +X ;DATA, RESULT ERROR
    CONT: ;RETURN ADDRESS
    
```

;THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN
 ;THE MULF INSTRUCTION IS EXECUTED. IF THE TRAP OCCURS THEN THE
 ;RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
 ;COMPARED WITH FPSA IF THIS TOO IS CORRECT OVUNFT RETURNS CONTROL
 ;TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNFT
 ;REPORTS THIS FAILURE AND THEN RETURNS TO CONT. THE FEC IS TREATED
 ;IN THE SAME WAY. IF THE RESULT OF THE
 ;MULF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
 ;ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
 ;THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNFT
 ;WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE
 ;RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNFT WILL
 ;REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.

```

4493      ;IF NO TRAP OCCURS CONTROL IS PASSED TO ERR1.
4494      ;NOTE THAT OVUNFT USES THE FLAG
4495      ;TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN
4496      ;UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).
4497
4498 023040 012601      OVUNFT: MOV      (SP)+,R1      ;GET A POINTER TO THE ARGUMENTS.
4499 023042 012700 000200      MOV      #200,R0      ;SET FD MODE.
4500 023046 170100      LDFPS   R0
4501
4502 023050 010100      MOV      R1,R0      ;LOAD ACO, OPERAND.
4503 023052 172410      LDD     (R0),ACO
4504
4505 023054 010102      MOV      R1,R2      ;SAVE THE DATA PATTERNS IN CASE OF
4506 023056 010237 001240      MOV      R2,$TMP3    ;ERROR.
4507 023062 062702 000004      ADD     #4,R2
4508 023066 010237 001242      MOV      R2,$TMP4
4509 023072 062702 000004      ADD     #4,R2
4510 023076 010237 001244      MOV      R2,$TMP5
4511 023102 06137 000022 001252      MOV     22(R1),$TMP10
4512 023110 012737 023442 001246      MOV     #OVFTT,$TMP6
4513
4514 023116 016100 000020      MOV     20(R1),R0    ;LOAD THE FPS.
4515 023122 170100      LDFPS   R0
4516 023124 012737 023146 001236      MOV     #1$, $TMP2
4517 023132 012737 023156 000244      MOV     #50$, FPVECT ;SET UP THE FP TRAP VECTOR IN CASE
4518                                     ;OF ERROR.
4519 023140 010100      MOV     R1,R0      ;COMPUTE THE ADDRESS OF FSRC.
4520 023142 062700 000004      ADD     #4,R0
4521
4522 023146 171010      1$:    MULF   (R0),ACO ;TEST INSTRUCTION. SHOULD CAUSE TRAP.
4523 023150 170000      2$:    CFCC
4524
4525 023152 000137 023402      JMP     25$        ;FAILURE, NO TRAP.
4526
4527 023156 011602      50$:   MOV     (SP),R2    ;TRAP TO HERE AND SEE IF THE PC OF THE
4528 023160 020227 023150      CMP     R2,#2$      ;TRAP WAS THAT OF THE MULF INSTRUCTION.
4529 023164 001402      BEQ    51$         ;BRANCH IF YES.
4530 023166 000137 037450      JMP     FPSPUR ;OTHERWISE REPORT SPURIOUS FP ERROR.
4531
4532 023172 022626      51$:   CMP     (SP)+,(SP)+ ;RESET THE STACK
4533 023174 170204      STFPS  R4          ;GET FPS.
4534 023176 170305      STST   R5          ;GET FEC.
4535 023200 012700 000200      MOV     #200,R0     ;SET FD MODE.
4536 023204 170100      LDFPS   R0
4537 023206 012700 023442      MOV     #OVFTT,R0   ;GET THE RESULT.
4538 023212 174010      STD    ACO,(R0)
4539 023214 010437 001250      MOV     R4,$TMP7
4540 023220 010537 001254      MOV     R5,$TMP11
4541
4542 023224 012700 023442      MOV     #OVFTT,R0   ;CHECK THE RESULT.
4543 023230 010102      MOV     R1,R2
4544 023232 062702 000010      ADD     #10,R2
4545 023236 012703 000002      MOV     #2,R3
4546 023242 022022      3$:   CMP     (R0)+,(R2)+ ;BRANCH IF INCORRECT.
4547 023244 001027      BNE    15$
4548 023246 077303      SOB    R3,3$
4549
    
```

4550	023250	026104	000022		CMP	22(R1),R4	:WAS FPS CORRECT?
4551	023254	001014			BNE	10\$:BRANCH IF FPS IS INCORRECT.
4552							
4553	023256	026105	000024		CMP	24(R1),R5	:IS FEC CORRECT?
4554	023262	001002			BNE	5\$:IF INCORRECT BRANCH.
4555	023264	000161	000036	4\$:	JMP	36(R1)	:RETURN, TEST COMPLETED.
4556							
4557					:REPORT INCORRECT FEC.		
4558	023270	005761	000026	5\$:	TST	26(R1)	:WAS THE RESULT OVERFLOW OR UNDERFLOW?
4559	023274	001002			BNE	7\$:BRANCH IF UNDERFLOW.
4560							
4561							:REPORT BAD FEC ON EXPECTED OVERFLOW.
4562	023276	104137		6\$:	ERROR	+137	
4563	023300	000771			BR	4\$	
4564							
4565	023302			7\$:			:REPORT BAD FEC ON EXPECTED UNDERFLOW.
4566	023302	104140		8\$:	ERROR	+140	
4567	023304	000767			BR	4\$	
4568							
4569					:REPORT INCORRECT FPS.		
4570	023306	005761	000026	10\$:	TST	26(R1)	:WAS THE RESULT OVER OR UNDER FLOW?
4571	023312	001002			BNE	12\$:BRANCH IF UNDERFLOW.
4572							
4573							:REPORT FPS BAD AFTER OVERFLOW.
4574	023314	104141		11\$:	ERROR	+141	
4575	023316	000762			BR	4\$	
4576							
4577	023320			12\$:			:REPORT FPS BAD AFTER UNDERFLOW.
4578	023320	104142		13\$:	ERROR	+142	
4579	023322	000760			BR	4\$	
4580							
4581					:RESULT INCORRECT.		
4582	023324	012700	023442	15\$:	MOV	#OVFTT,R0	:SEE IF FAILURE IS ANTICIPATED
4583	023330	010102			MOV	R1,R2	:FAILURE.
4584	023332	062702	000014		ADD	#14,R2	
4585	023336	012703	000002		MOV	#2,R3	
4586	023342	022022		16\$:	CMP	(R0)+,(R2)+	
4587	023344	001007			BNE	17\$:BRANCH IF NOT ANTICIPATED.
4588	023346	077303			SOB	R3,16\$	
4589							
4590	023350	010102			MOV	R1,R2	:ERROR WAS ANTICIPATED SO RETURN
4591	023352	062702	000034		ADD	#34,R2	:TO THE ERROR REPORT IN THE CALLING
4592	023356	010237	001236		MOV	R2,\$TMP2	:ROUTINE.
4593	023362	000112			JMP	(R2)	
4594							
4595	023364	005761	000026	17\$:	TST	26(R1)	:RESULT WAS NOT ANTICIPATED
4596							:SO ERROR MUST BE REPORTED HERE.
4597							:FIRST SEE IF ARGUMENTS SHOULD
4598							:HAVE RESULTED IN OVERFLOW OR UNDER
4599							:FLOW BY LOOKING AT THE FLAG.
4600	023370	001002			BNE	19\$:BRANCH IF UNDERFLOW EXPECTED.
4601							
4602							:REPORT RESULT INCORRECT, EXPECTING
4603	023372	104143		18\$:	ERROR	+143	:OVERFLOW.
4604	023374	000733			BR	4\$	
4605							
4606	023376			19\$:			:REPORT RESULT INCORRECT, EXPECTING

```

4607 023376 104144          20$:  ERROR  +144          :UNDERFLOW.
4608 023400 000731          BR      4$
4609
4610          ;IF NO FP TRAP OCCURS COME HERE.
4611 023402 170204          25$:  STFPS  R4          :GET FPS.
4612 023404 170305          STST  R5          :GET FEC.
4613 023406 012700 000200  MOV   #200,R0     :SET FD MODE.
4614 023412 170100          LDFPS R0
4615 023414 012700 023442  MOV   #OVFTT,R0   :GET THE RESULT.
4616 023420 174010          STD   ACO,(R0)
4617 023422 010437 001250  MOV   R4,$TMP7
4618 023426 010537 001254  MOV   R5,$TMP11
4619 023432 010102          MOV   R1,R2      :ERROR WAS ANTICIPATED SO
4620 023434 062702 000030  ADD   #30,R2     :RETURN TO THE ERROR REPORT OF THE
4621                                     :CALLING ROUTINE.
4622 023440 000112          JMP   (R2)
4623
4624 023442 000000 000000 000000  OVFTT: .WORD 0,0,0,0
4625
4626 023452          KKKDONE:
      023452 104412          RSETUP          :GO INITIALIZE THE FPS AND STACK; AND
                                     :SEE IF THE USER HAS EXPRESSED
                                     :THE DESIRE TO CHANGE THE SOFTWARE
                                     :VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                     :THE USER TYPED CONTROL G?).

4627
4628
4629
4637
4638          ;TEST TITLE:UNDER/OVERFLOW, USING MULD WITH TRAPS ENABLED
    
```

4639

```
.SBTTL TEST # 15 - SEE COMMENT ABOVE FOR TEST TITLE
:*****
:*TEST 15 SEE COMMENT ABOVE FOR TEST TITLE
:*
:*THIS IS A TEST OF THE OVER FLOW AND UNDER FLOW CONDITIONS USING THE
:*MULD INSTRUCTION WITH TRAPS ENABLED. A SUBROUTINE IS USED TO SET UP
:*THE OPERANDS, EXECUTE THE MULD INSTRUCTION AND CHECK THE RESULTS.
:*
:*****
```

```
023454 000004
4640
4641
4642 023456
4643 023456 104413
4644 023456 004737 024002
4645 023464 020052 125252
4646 023470 125252 125252
4647 023474 020300 000000 000000
4648 023504 000177 177777 177777
4649 023514 000177 177777
4650 023520 125252 125252
4651 023524 002200
4652 023526 102204
4653 023530 000012
4654 023532 177777
4655 023534 104157
4656 023536 000401
4657 023540 104160
4658
4659
```

```
TST15: SCOPE
:UNDERFLOW, EXPONENT OF RESULT = -129
LLL1:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,OVUNDT
1$: .WORD 20052,125252 ;AC
. WORD 125252,125252
2$: .WORD 20300,0,0,0 ;FSRC
3$: .WORD 177,-1,-1,-1 ;RES
4$: .WORD 177,-1 ;ERROR RES.
. WORD 125252,125252
5$: 2200 ;FPS BEFORE EXECUTION.
102204 ;FPS AFTER EXECUTION.
6$: 12 ;FEC
-1 ;FLAG
7$: ERROR +157 ;ST 331 (BUT FIU) NO TRAP.
BR 8$
ERROR +160 ;ST 155 (BUT FD)
8$:
```

```
4660 023542
4661 023542 104413
4662 023544 004737 024002
4663 023550 010327 127272
4664 023554 036363 045454
4665 023560 010000 000000 000000
4666 023570 060127 127272
4667 023574 036363 045454
4668 023600 177777 177777
4669 023610 007217
4670 023612 107200
4671 023614 000012
4672 023616 177777
4673 023620 104161
4674 023622 000401
4675 023624 104155
4676
4677
```

```
:UNDERFLOW, EXPONENT OF THE RESULT = -193
LLL2:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,OVUNDT
1$: .WORD 10327,127272 ;AC
. WORD 36363,45454
2$: .WORD 10000,0,0,0 ;FSRC
3$: .WORD 60127,127272 ;RES
. WORD 36363,45454
4$: .WORD -1,-1,-1,-1 ;ERROR RES.
5$: 7217 ;FPS BEFORE EXECUTION.
107200 ;FPS AFTER EXECUTION.
6$: 12 ;FEC
-1 ;FLAG
7$: ERROR +161 ;ST 137 (BUT FIU) NO TRAP.
BR 8$
ERROR +156
8$:
```

```
4678 023626
4679 023626 104413
4680 023630 004737 024002
4681 023634 060252 125252
4682 023640 125252 125252
4683 023644 160100 000000 000000
4683 023654 100177 177777 177777
```

```
:OVERFLOW, EXPONENT OF THE RESULT = 128
LLL3:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,OVUNDT
1$: .WORD 60252,125252 ;AC
. WORD 125252,125252 ;FSRC
2$: .WORD 160100,0,0,0 ;FSRC
3$: .WORD 100177,-1,-1,-1 ;RES
```

```

4684 023664 100177 177777 4$: .WORD 100177,-1 ;ERROR RES.
4685 023670 125252 125252 .WORD 125252,125252
4686 023674 001200 5$: 1200 ;FPS BEFORE EXECUTION.
4687 023676 101216 101216 ;FPS AFTER EXECUTION.
4688 023700 000010 6$: 10 ;FEC
4689 023702 000000 0 ;FLAG
4690 023704 104162 7$: ERROR +162 ;ST 333 (BUT FIV) NO TRAP.
4691 023706 000401 BR 8$
4692 023710 104163 ERROR +163 ;ST 700 (BUT FD).
4693 023712 8$:
4694
4695 ;OVERFLOW, EXPONENT OF THE RESULT = 130
4696 023712 LLL4: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
023712 104413 JSR PC,OVUNDT
4697 023714 004737 024002 .WORD 60345,67654 ;AC
4698 023720 060345 067654 1$: .WORD 56765,45676
4699 023724 056765 045676 .WORD 60200,0,0,0 ;FSRC
4700 023730 060200 000000 000000 2$: .WORD 345,67654 ;RES
4701 023740 000345 067654 3$: .WORD 56765,45676
4702 023744 056765 045676 .WORD -1,-1,-1,-1 ;ERROR RES.
4703 023750 177777 177777 177777 4$: 7215 ;FPS BEFORE EXECUTION.
4704 023760 007215 5$: 107202 ;FPS AFTER EXECUTION.
4705 023762 107202 6$: 10 ;FEC
4706 023764 000010 0 ;FLAG
4707 023766 000000 7$: ERROR +164 ;ST 133 (BUT FIV) NO TRAP
4708 023770 104164 BR 8$
4709 023772 000401 ERROR +155
4710 023774 104155 8$: JMP LLLDONE
4711 023776 000137 024414
4712
4713 ;THIS SUBROUTINE, OVUNDT, IS USED TO SET UP THE OPERANDS, EXECUTE
4714 ;THE MULD INSTRUCTION AND CHECK THE RESULTS OF AN INSTRUCTION WITH
4715 ;OPERANDS WHICH SHOULD RESULT IN EITHER OVERFLOW OR UNDERFLOW. A CALL
4716 ;TO IT IS MADE THUS:
4717 :
4718 : ACARG: .WORD X,X,X,X ;AC OPERAND
  
```

```

4720      :
4721      :
4722      :
4723      :
4724      :
4725      :
4726      :
4727      :
4728      :
4729      :
4730      :
4731      :
4732      :
4733      :
4734      :
4735      :
4736      :
4737      :
4738      :
4739      :
4740      :
4741      :
4742      :
4743      :
4744      :
4745      :
4746      :
4747      :
4748      :
4749      :
4750      :
4751      :
4752      :
4753      :
4754      :
4755      :
4756      :
4757      :
4758      :
4759      :
4760      :
4761      :
4762      :
4763      :
4764      :
4765      :
4766      :
4767      :
4768      :
4769      :
4770      :
4771      :
4772      :
4773      :
4774      :
4775      :
4776      :
    
```

```

FSRCARG: .WORD X,X,X,X      ;FSRC OPERAND
RES:      .WORD X,X,X,X      ;EXPECTED RESULT
ERRES:    .WORD X,X,X,X      ;ERROR RESULT
FPSB:     .WORD X              ;FPS BEFORE EXECUTION
FPSA:     .WORD X              ;FPS AFTER EXECUTION
FEC:      .WORD X              ;EXPECTED FEC
FLAG:     .WORD X              ;0/-1,OVER/UNDER FLOW FLAC
ERR1:     ERROR +X           ;TRAP ERROR.
BR        CONT
ERR2:     ERROR +X           ;DATA, RESULT ERROR
CONT:
    
```

```

:THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN
:THE MULD INSTRUCTION IS EXECUTED. IF THE TRAP OCCURS THEN THE
:RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
:COMPARED WITH FPSA IF THIS TOO IS CORRECT OVUNDT RETURNS CONTROL
:TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNDT
:REPORTS THIS FAILURE AND THEN RETURNS TO CONT. THE FEC IS TREATED
:IN THE SAME WAY. IF THE RESULT OF THE
:MULF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
:ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
:THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNDT
:WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE
:RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNDT WILL
:REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
:IF NO TRAP OCCURS CONTROL IS PASSED TO ERR1.
:NOTE THAT OVUNDT USES THE FLAG
:TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN
:UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).
    
```

```

OVUNDT: MOV      (SP)+,R1      ;GET A POINTER TO THE ARGUMENTS.
        MOV      #200,R0      ;SET FD MODE.
        LDFPS   R0
        MOV      R1,R0        ;LOAD ACO, OPERAND.
        LDD     (R0),ACO
        MOV      R1,R2        ;SAVE DATA PATTERNS IN CASE OF
        MOV      R2,$TMP3     ;ERROR.
        ADD     #10,R2
        MOV      R2,$TMP4
        ADD     #10,R2
        MOV      R2,$TMP5
        MOV      42(R1),$TMP10
        MOV      #OVDTT,$TMP6
        MOV      40(R1),R0     ;LOAD THE FPS.
        LDFPS   R0
        MOV      #1$, $TMP2
        MOV      #50$,FPVECT  ;SET UP THE FP TRAP VECTOR IN CASE
                                ;OF ERROR.
        MOV      R1,R0        ;COMPUTE THE ADDRESS OF FSRC.
        ADD     #10,R0
        1$:    MULD   (R0),ACO  ;TEST INSTRUCTION. SHOULD CAUSE TRAP.
        2$:    CFCC
    
```

```

4777 024114 000137 024344          JMP      25$          ;FAILURE, NO TRAP.
4778
4779 024120 011602          50$:  MOV      (SP),R2          ;TRAP TO HERE AND SEE IF THE PC OF THE
4780 024122 020227 024112          CMP      R2,#2$          ;TRAP WAS THAT OF THE MULF INSTRUCTION.
4781 024126 001402          BEQ      51$          ;BRANCH IF YES.
4782 024130 000137 037450          JMP      FPSPUR ;OTHERWISE REPORT SPURIOUS FP ERROR.
4783
4784 024134 022626          51$:  CMP      (SP)+,(SP)+      ;RESET THE STACK
4785 024136 170204          STFPS   R4          ;GET FPS.
4786 024140 170305          STST    R5          ;GET FEC.
4787 024142 012700 000200          MOV      #200,R0        ;SET FD MODE.
4788 024146 170100          LDFPS   R0
4789 024150 012700 024404          MOV      #OVDTT,R0      ;GET THE RESULT.
4790 024154 174010          STD     ACO,(R0)
4791 024156 010437 001250          MOV      R4,$TMP7
4792 024162 010537 001254          MOV      R5,$TMP11
4793
4794 024166 012700 024404          MOV      #OVDTT,R0      ;CHECK THE RESULT.
4795 024172 010102          MOV      R1,R2
4796 024174 062702 000020          ADD     #20,R2
4797 024200 012703 000004          MOV      #4,R3
4798 024204 022022          3$:  CMP      (R0)+,(R2)+      ;BRANCH IF INCORRECT.
4799 024206 001027          BNE     15$
4800 024210 077303          SOB     R3,3$
4801
4802 024212 026104 000042          CMP      42(R1),R4      ;WAS FPS CORRECT?
4803 024216 001014          BNE     10$          ;BRANCH IF FPS IS INCORRECT.
4804
4805 024220 026105 000044          CMP      44(R1),R5      ;IS FEC CORRECT?
4806 024224 001002          BNE     5$          ;IF INCORRECT BRANCH.
4807 024226 000161 000056          4$:  JMP      56(R1)        ;RETURN. TEST COMPLETED.
4808
4809          ;REPORT INCORRECT FEC.
4810 024232 005761 000046          5$:  TST      46(R1)        ;WAS THE RESULT OVERFLOW OR UNDERFLOW?
4811 024236 001002          BNE     7$          ;BRANCH IF UNDERFLOW.
4812
4813          ;REPORT BAD FEC ON EXPECTED OVERFLOW.
4814 024240 104151          6$:  ERROR   +151
4815 024242 000771          BR      4$
4816
4817 024244          7$:
4818 024244 104152          8$:  ERROR   +152
4819 024246 000767          BR      4$
4820
4821          ;REPORT INCORRECT FPS.
4822 024250 005761 000046          10$: TST      46(R1)        ;WAS THE RESULT OVER OR UNDER FLOW?
4823 024254 001002          BNE     12$          ;BRANCH IF UNDERFLOW.
4824
4825          ;REPORT FPS BAD AFTER OVERFLOW.
4826 024256 104153          11$: ERROR   +153
4827 024260 000762          BR      4$
4828
4829 024262          12$:
4830 024262 104154          13$: ERROR   +154
4831 024264 000760          BR      4$
4832
4833          ;RESULT INCORRECT.
    
```


TEST # 15 - SEE COMMENT ABOVE FOR TEST TITLE

```

4834 024266 012700 024404      15$:  MOV    #OVDTT,R0      ;SEE IF FAILURE IS ANTICIPATED
4835 024272 010102              MOV    R1,R2          ;FAILURE.
4836 024274 062702 000030      ADD    #30,R2
4837 024300 012703 000004      MOV    #4,R3
4838 024304 022022      16$:  CMP    (R0)+,(R2)+
4839 024306 001007          BNE    17$           ;BRANCH IF NOT ANTICIPATED.
4840 024310 077303          SOB    R3,16$
4841
4842 024312 010102              MOV    R1,R2          ;ERROR WAS ANTICIPATED SO RETURN
4843 024314 062702 000054      ADD    #54,R2        ;TO THE ERROR REPORT IN THE CALLING
4844 024320 010237 001236      MOV    R2,$TMP2     ;ROUTINE.
4845 024324 000112          JMP    (R2)
4846
4847 024326 005761 000046      17$:  TST    46(R1)     ;RESULT WAS NOT ANTICIPATED
4848                          ;SO ERROR MUST BE REPORTED HERE.
4849                          ;FIRST SEE IF ARGUMENTS SHOULD
4850                          ;HAVE RESULTED IN OVERFLOW OR UNDER
4851                          ;FLOW BY LOOKING AT THE FLAG.
4852 024332 001002          BNE    19$           ;BRANCH IF UNDERFLOW EXPECTED.
4853
4854                          ;REPORT RESULT INCORRECT, EXPECTING
4855 024334 104155      18$:  ERROR  +155        ;OVERFLOW.
4856 024336 000733          BR     4$
4857
4858 024340      19$:
4859 024340 104156      20$:  ERROR  +156        ;REPORT RESULT INCORRECT, EXPECTING
4860 024342 000731          BR     4$           ;UNDERFLOW.
4861
4862                          ;IF NO FP TRAP OCCURS COME HERE.
4863 024344 170204      25$:  STFPS  R4           ;GET FPS.
4864 024346 170305          STST  R5           ;GET FEC.
4865 024350 012700 000200      MOV    #200,R0       ;SET FD MODE.
4866 024354 170100          LDFPS R0
4867 024356 012700 024404      MOV    #OVDTT,R0     ;GET THE RESULT.
4868 024362 174010          STD   ACO,(R0)
4869 024364 010437 001250      MOV    R4,$TMP7
4870 024370 010537 001254      MOV    R5,$TMP11
4871 024374 010102          MOV    R1,R2
4872 024376 062702 000050      ADD    #50,R2
4873                          ;ERROR WAS ANTICIPATED SO
4874 024402 000112          JMP    (R2)         ;RETURN TO THE ERROR REPORT OF THE
4875                          ;CALLING ROUTINE.
4876 024404 000000 000000 000000 OVDTT: .WORD 0,0,0,0
4877
4878 024414      LLLDONE:
         024414 104412          RSETUP
                          ;GO INITIALIZE THE FPS AND STACK; AND
                          ;SEE IF THE USER HAS EXPRESSED
                          ;THE DESIRE TO CHANGE THE SOFTWARE
                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                          ;THE USER TYPED CONTRGL G?).

4879
4880
4881
4882
4890

```

4891

```
.SBTTL TEST # 16 - MODF TEST  
:*****  
:*TEST 16 MODF TEST  
:*  
:*THIS IS A TEST OF THE MODF INSTRUCTION, WHICH MAKES USE OF  
:*A SUBROUTINE TO SET UP THE OPERANDS, EXECUTE THE MODF INSTRUCTION  
:*AND CHECK THE RESULTS.  
:*  
:*****
```

4892 024416 000004
4893
4894 024420
4895 024422 104413 025504
4896 024426 004737 000000
4897 024432 000000 000000
4898 024436 000000 000000
4899 024442 000000 000000
4900 024446 177777 177777
4901 024452 177777 177777
4902 024456 000013
4903 024460 000004
4904 024462 104056
4905 024464 000401
4906 024466 104057
4907 024470
4908
4909

```
TST16: SCOPE  
:MODF WITH (FSRC=AC=0)  
GGG1:  
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
JSR PC,MODFSUB  
1$: .WORD 0,0 ;AC  
2$: .WORD 0,0 ;FSRC  
3$: .WORD 0,0 ;FRACTIONAL RES.  
4$: .WORD 0,0 ;INTEGER RES.  
5$: .WORD -1,-1 ;ERROR FRACTIONAL RES.  
6$: .WORD -1,-1 ;ERROR INTEGER RES.  
7$: 13 ;FPS BEFORE EXECUTION.  
4 ;FPS AFTER EXECUTION.  
8$: ERROR +56 ;STORE SINGLE ZERO BAD.  
BR 9$  
ERROR +57 ;AC V 1 <= ZERO FAILED.  
9$:
```

4910 024470
4911 024472 104413 025504
4912 024476 004737 076543
4913 024502 000000 000000
4914 024506 000000 000000
4915 024512 000000 000000
4916 024516 123456 076543
4917 024522 177777 177777
4918 024526 000000
4919 024530 000004
4920 024532 104056
4921 024534 000401
4922 024536 104057
4923 024540
4924
4925

```
:MODF TEST, WITH (FSRC=0)  
GGG2:  
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
JSR PC,MODFSUB  
1$: .WORD 123456,76543 ;AC  
2$: .WORD 0,0 ;FSRC  
3$: .WORD 0,0 ;FRACTIONAL RES.  
4$: .WORD 0,0 ;INTEGER RESULT.  
5$: .WORD 123456,76543 ;ERROR FRACTIONAL RES.  
6$: .WORD -1,-1 ;ERROR INTEGER RES.  
7$: 0 ;FPS BEFORE EXECUTION.  
4 ;FPS AFTER EXECUTION.  
8$: ERROR +56 ;STORE ZERO FAILURE.  
BR 9$  
ERROR +57  
9$:
```

4926 024540
4927 024542 104413 025504
4928 024546 004737 000000
4929 024552 076543 021234
4930 024556 000000 000000
4931 024562 000000 000000
4932 024566 000000 000000
4933 024572 177777 177777
4934 024576 000003
4935 024600 000004

```
:MODF TEST WITH (AC=0)  
GGG3:  
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
JSR PC,MODFSUB  
1$: .WORD 0,0 ;AC  
2$: .WORD 76543,21234 ;FSRC  
3$: .WORD 0,0 ;FRACTIONAL RES.  
4$: .WORD 0,0 ;INTEGER RES.  
5$: .WORD 0,0 ;ERROR FRACTIONAL RES.  
6$: .WORD -1,-1 ;ERROR INTEGER RES.  
7$: 3 ;FPS BEFORE EXECUTION.  
4 ;FPS AFTER EXECUTION.
```

```

4936 024602 104053      8$:      ERROR      +53      ;RES.BAD
4937 024604 000401      BR          9$
4938 024606 104057      ERROR      +57
4939 024610      9$:
4940
4941      ;MODF TEST WITH EXPONENT OF THE RESULT = 25
4942 024610      GGG4:      LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
           024610 104413      JSR          PC,MODFSUB
4943 024612 004737 025504      .WORD      46252,125252      ;AC
4944 024616 046252 125252      1$:      .WORD      40300,0      ;FSRC
4945 024622 040300 000000      2$:      .WORD      0,0      ;FRACTIONAL RES.
4946 024626 000000 000000      3$:      .WORD      46377,-1      ;INTEGER RES.
4947 024632 046377 177777      4$:      .WORD      46252,125252      ;ERROR FRACTIONAL RES.
4948 024636 046252 125252      5$:      .WORD      40300,0      ;ERROR INTEGER RES.
4949 024642 040300 000000      6$:      13      ;FPS BEFORE EXECUTION.
4950 024646 000013      7$:      4      ;FPS AFTER EXECUTION.
4951 024650 000004      8$:      ERROR      +53      ;ST 134
4952 024652 104053      BR          9$
4953 024654 000401      ERROR      +60
4954 024656 104060      9$:
4955 024660
4956
4957      ;MODF TEST WITH EXPONENT OF THE RESULT = 127
4958 024660      GGG5:      LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
           024660 104413      JSR          PC,MODFSUB
4959 024662 004737 025504      .WORD      77652,125252      ;AC
4960 024666 077652 125252      1$:      .WORD      40300,0      ;FSRC
4961 024672 040300 000000      2$:      .WORD      0,0      ;FRACTIONAL RES.
4962 024676 000000 000000      3$:      .WORD      77777,-1      ;INTEGER RES.
4963 024702 077777 177777      4$:      .WORD      77652,125252      ;ERROR FRACTIONAL RES.
4964 024706 077652 125252      5$:      .WORD      40300,0      ;ERROR INTEGER RES.
4965 024712 040300 000000      6$:      0      ;FPS BEFORE EXECUTION.
4966 024716 000000      7$:      4      ;FPS AFTER EXECUTION.
4967 024720 000004      8$:      ERROR      +53
4968 024722 104053      BR          9$
4969 024724 000401      ERROR      +60
4970 024726 104060      9$:
4971 024730
4972
4973      ;MODF TEST WITH EXPONENT OF RESULT = 25
4974 024730      GGG6:      LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
           024730 104413      JSR          PC,MODFSUB
4975 024732 004737 025504      .WORD      46200,1      ;AC
4976 024736 046200 000001      1$:      .WORD      40340,0      ;FSRC
4977 024742 040340 000000      2$:      .WORD      0,0      ;FRACTIONAL RES.
4978 024746 000000 000000      3$:      .WORD      46340,1      ;INTEGER RES.
4979 024752 046340 000001      4$:      .WORD      40000,0      ;ERROR FRACTIONAL RES.
4980 024756 040000 000000      5$:      .WORD      -1,-1      ;ERROR INTEGER RES.
4981 024762 177777 177777      6$:      13      ;FPS BEFORE EXECUTION.
4982 024766 000013      7$:      4      ;FPS AFTER EXECUTION.
4983 024770 000004      8$:      ERROR      +61      ;BAD CONSTANT (NOT 24),
4984 024772 104061      BR          9$      ;OR ST 525 TO 050 INTO 150.
4985      ERROR      +54
4986 024774 000401      9$:
4987 024776 104054
4988 025000
4989

```

```

4990          :MODF TEST WITH EXPONENT OF THE RESULT = 24
4991 025000   GGG7:
         025000   104413   LPERR
4992 025002   004737   025504   JSR PC,MODFSUB ;SET UP THE LOOP ON ERROR ADDRESS.
4993 025006   046000   000001   1$: .WORD 46000,1 ;AC
4994 025012   040340   000000   2$: .WORD 40340,0 ;FSRC
4995 025016   040100   000000   3$: .WORD 40100,0 ;FRACTIONAL RES.
4996 025022   046140   000001   4$: .WORD 46140,1 ;INTEGER RESULT.
4997 025026   000000   000000   5$: .WORD 0,0 ;ERROR FRACTIONAL RES.
4998 025032   177777   177777   6$: .WORD -1,-1 ;ERROR INTEGER RES.
4999 025036   000000   000000   7$: 0 ;FPS BEFORE EXECUTION.
5000 025040   000000   000000   8$: 0 ;FPS AFTER EXECUTION.
5001 025042   104062   8$: ERROR +62 ;BAD CONSTANT USED (NOT 24)
5002          BR 9$ ;OR ST 525 TO 150 INTO 050
5003 025044   000401   BR 9$
5004 025046   104054   ERROR +54
5005 025050   9$:
5006
5007          :MODF TEST WITH EXPONENT OF THE RESULT = 10
5008 025050   GGG8:
         025050   104413   LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
5009 025052   004737   025504   JSR PC,MODFSUB
5010 025056   042577   177777   1$: .WORD 42577,-1 ;AC
5011 025062   040200   000000   2$: .WORD 40200,0 ;FSRC
5012 025066   040177   176000   3$: .WORD 40177,176000 ;FRACTIONAL RES.
5013 025072   042577   140000   4$: .WORD 42577,140000 ;INTEGER RES.
5014 025076   177777   177777   5$: .WORD -1,-1 ;ERROR FRACTIONAL RES.
5015 025102   177777   177777   6$: .WORD -1,-1 ;ERROR INTEGER RES.
5016 025106   000000   000000   7$: 0 ;FPS BEFORE EXECUTION.
5017 025110   000000   000000   8$: 0 ;FPS AFTER EXECUTION.
5018 025112   104053   8$: ERROR +53
5019 025114   000401   BR 9$
5020 025116   104054   ERROR +54
5021 025120   9$:
5022
5023          :MODF TEST WITH THE EXPONENT OF THE RESULT = 10
5024 025120   GGG9:
         025120   104413   LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
5025 025122   004737   025504   JSR PC,MODFSUB
5026 025126   042577   140001   1$: .WORD 42577,140001 ;AC
5027 025132   040200   000000   2$: .WORD 40200,0 ;FSRC
5028 025136   034600   000000   3$: .WORD 34600,0 ;FRACTIONAL RES.
5029 025142   042577   140000   4$: .WORD 42577,140000 ;INTEGER RES.
5030 025146   000000   000000   5$: .WORD 0,0 ;ERROR FRACTIONAL RES.
5031 025152   177777   177777   6$: .WORD -1,-1 ;ERROR INTEGER RES.
5032 025156   000000   000000   7$: 0 ;FPS BEFORE EXECUTION.
5033 025160   000000   000000   8$: 0 ;FPS AFTER EXECUTION.
5034 025162   104063   8$: ERROR +63 ;ST 532 TO 122 INTO NORMALIZE.
5035 025164   000401   BR 9$
5036 025166   104054   ERROR +54
5037 025170   9$:
5038
5039          :MODF TEST WITH EXPONENT OF THE RESULT = 9
5040 025170   GGG10:
         025170   104413   LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
5041 025172   004737   025504   JSR PC,MODFSUB
5042 025176   042377   100000   1$: .WORD 42377,100000 ;AC

```

```

5043 025202 040200 000000 2$: .WORD 40200,0 ;FSRC
5044 025206 000000 000000 3$: .WORD 0,0 ;FRACTIONAL RES.
5045 025212 042377 100000 4$: .WORD 42377,100000 ;INTEGER RES.
5046 025216 177777 177777 5$: .WORD -1,-1 ;ERROR FRACTIONAL RES.
5047 025222 177777 177777 6$: .WORD -1,-1 ;ERROR INTEGER RES.
5048 025226 000013 7$: 13 ;FPS BEFORE EXECUTION.
5049 025230 000004 8$: 4 ;FPS AFTER EXECUTION.
5050 025232 104053 8$: ERROR +53
5051 025234 000401 BR 9$
5052 025236 104054 ERROR +54
5053 025240 9$:
5054
5055 ;MODF TEST WITH EXPONENT OF THE RESULT = 0
5056 025240 GGG11:
      025240 104413 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      004737 025504 JSR PC,MODFSUB
5057 025242 040177 177777 1$: .WORD 40177,-1 ;AC
5058 025246 040200 000000 2$: .WORD 40200,0 ;FSRC
5059 025252 040177 177777 3$: .WORD 40177,-1 ;FRACTIONAL RES.
5060 025256 000000 000000 4$: .WORD 0,0 ;INTEGER RES.
5061 025262 000000 000000 5$: .WORD 0,0 ;ERROR FRACTIONAL RES.
5062 025266 040177 177777 6$: .WORD 40177,-1 ;ERROR INTEGER RES.
5063 025272 000017 7$: 17 ;FPS BEFORE EXECUTION.
5064 025276 000000 8$: 0 ;FPS AFTER EXECUTION.
5065 025300 104064 8$: ERROR +64 ;ST 041 TO 046 INTO 246.
5066 025302 000401 BR 9$
5067 025304 104064 ERROR +64
5068 025306
5069 025310 9$:
5070
5071 ;MODF TEST WITH EXPONENT OF THE RESULT = -15
5072 025310 GGG12:
      025310 104413 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      004737 025504 JSR PC,MODFSUB
5073 025312 034377 177777 1$: .WORD 34377,-1 ;AC
5074 025316 040200 000000 2$: .WORD 40200,0 ;FSRC
5075 025322 034377 177777 3$: .WORD 34377,-1 ;FRACTIONAL RES.
5076 025326 000000 000000 4$: .WORD 0,0 ;INTEGER RES.
5077 025332 000000 000000 5$: .WORD 0,0 ;ERROR FRACTIONAL RES.
5078 025336 034377 177777 6$: .WORD 34377,-1 ;ERROR INTEGER RES.
5079 025342 000000 7$: 0 ;FPS BEFORE EXECUTION.
5080 025346 000000 8$: 0 ;FPS AFTER EXECUTION.
5081 025350 104064 8$: ERROR +64
5082 025352 000401 BR 9$
5083 025354 104064 ERROR +64
5084 025356
5085 025360 9$:
5086
5087 ;MODF TEST WITH EXPONENT OF RESULT = -64, IN ROUND MODE
5088 025360 GGG13:
      025360 104413 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      004737 025504 JSR PC,MODFSUB
5089 025362 020000 000001 1$: .WORD 20000,1 ;AC
5090 025366 040300 000000 2$: .WORD 40300,0 ;FSRC
5091 025372 020100 000002 3$: .WORD 20100,2 ;FRACTIONAL RES.
5092 025376 000000 000000 4$: .WORD 0,0 ;INTEGER RES.
5093 025402 020100 000001 5$: .WORD 20100,1 ;ERROR FRACTIONAL RES.
5094 025406 000000 000000 6$: .WORD 0,0 ;ERROR INTEGER RES.
5095 025412 000000 7$: 0 ;FPS BEFORE EXECUTION.
5096 025416 000000

```

5097 025420 000000
5098 025422 104065
5099 025424 000401
5100 025426 104054
5101 025430
5102
5103
5104 025430 104413
5105 025432 004737 025504
5106 025436 142777 170000
5107 025442 040200 000000
5108 025446 140000 000000
5109 025452 142777 160000
5110 025456 040000 000000
5111 025462 042777 160000
5112 025466 000007
5113 025470 000010
5114 025472 104066
5115 025474 000401
5116 025476 104067
5117 025500 000137 026072
5118
5119
5120
5121
5122
5123
5124
5125
5126
5127
5128
5129
5130
5131
5132
5133
5134
5135
5136
5137
5138
5139
5140
5141
5142
5143
5144
5145
5146
5147
5148
5149
5150
5151
5152

```

0                                     :FPS AFTER EXECUTION.
8$:  ERROR  +65                       :ROUND TRUNK, ST 126 INTO ROUND.
    BR      9$
    ERROR  +54
9$:
:MODF TEST WITH EXPONENT OF RESULT = 11
GGG14:
    LPERR                               :SET UP THE LOOP ON ERROR ADDRESS.
    JSR    PC,MODFSUB
1$:  .WORD 142777,170000                :AC
2$:  .WORD 40200,0                      :FSRC
3$:  .WORD 140000,0                    :FRACTIONAL RES.
4$:  .WORD 142777,160000                :INTEGER RES.
5$:  .WORD 40000,0                     :ERROR FRACTIONAL RES.
6$:  .WORD 42777,160000                :ERROR INTEGER RES.
7$:  7                                   :FPS BEFORE EXECUTION.
    10                                   :FPS AFTER EXECUTION.
8$:  ERROR  +66                       :SIGN OF FRACTION.
    BR      9$
    ERROR  +67
9$:  JMP    GGGDONE                     :SIGN OF INTEGER.
                                       :GO TO NEXT TEST.

```

```

:THIS SUBROUTINE, MODFSUB, IS CALLED TO SETUP THE
:OPERANDS, EXECUTE THE MODF INSTRUCTION AND CHECK THE RESULTS.
:IT IS CALLED THUS:

```

```

ACARG: .WORD X,X                       :AC OPERAND
FSRCARG: .WORD X,X                     :FSRC OPERAND
FRES: .WORD X,X                         :FRACTIONAL RESULT
INTRES: .WORD X,X                       :INTEGER RESULT
ERFRES: .WORD X,X                       :ERROR FRACTION RESULT
ERINTRES: .WORD X,X                     :ERROR INTEGER RESULT
FPSB: .WORD X                           :FPS BEFORE EXECUTION
FPSA: .WORD X                           :FPS AFTER EXECUTION
ERR1: ERROR +X                          :FRACTION ERROR
    BR CONT
ERR2: ERROR +X                          :INTEGER ERROR
CONT:                                     :RETURN ADDRESS

```

```

:THE OPERANDS ARE SET UP (USING ACO FOR THE AC ARGUMENT). THE MODF
:INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
:THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
:THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
:THEN THE FPS IS COMPARED WITH FPSA. AFTER EXECUTION IF NO ERRORS OCCURRED
:THEN MODFSUB WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
:IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
:THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH
:THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED
:FAILURE MATCHES THE TRUE RESULT THEN MODFSUB PASSES CONTROL TO THE
:ERROR CALL AT ERR1. LIKewise IF THE INTEGER PART OF THE RESULT IS
:NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER
:FAILURE. IF THIS DOESN'T MATCH THEN THE ERROR IS REPORTED HERE.
:IF A MATCH IS MADE HOWEVER, MODFSUB WILL RETURN CONTROL TO THE ERROR
:CALL AT ERR2.

```

```

5153 025504 012601          MODFSUB:  MOV      (SP)+,R1      ;GET A POINTER TO THE ARGUMENTS
5154 025506 012700 000200      MOV      #200,R0      ;SET FD MODE.
5155 025512 170100          LDFPS   R0
5156 025514 010100          MOV      R1,R0      ;SET UP ACO
5157 025516 172410          LDD     (R0),ACO
5158 025520 012700 026062      MOV      #MODP1,R0   ;PUT A BACKGROUND PATTERN INTO AC1.
5159 025524 172510          LDD     (R0),AC1
5160 025526 016100 000030      MOV      30(R1),R0   ;SET UP THE FPS.
5161 025532 170100          LDFPS   R0
5162 025534 012737 025550 001236  MOV      #1$,STMP2
5163 025542 010100          MOV      R1,R0      ;COMPUTE THE ADDRESS OF THE FSRC.
5164 025544 062700 000004      ADD     #4,R0
5165
5166 025550 171410          1$:    MODF      (R0),ACO      ;EXECUTE THE TEST INSTRUC ION.
5167
5168 025552 170204          STFPS   R4          ;GET THE FPS.
5169 025554 012700 000200      MOV      #200,R0      ;SET FD MODE.
5170 025560 170100          LDFPS   R0
5171 025562 012700 026042      MOV      #MODFT0,R0   ;GET THE FRACTIONAL RESULT.
5172 025566 174010          STD     ACO,(R0)
5173 025570 012700 026052      MOV      #MODFT1,R0   ;GET THE INTEGER RESULT.
5174 025574 174110          STD     AC1,(R0)
5175
5176 025576 010102          MOV      R1,R2      ;SAVE THE DATA IN CASE OF ERROR.
5177 025600 010237 001240      MOV      R2,STMP3
5178 025604 062702 000004      ADD     #4,R2
5179 025610 010237 001242      MOV      R2,STMP4
5180 025614 062702 000004      ADD     #4,R2
5181 025620 010237 001244      MOV      R2,STMP5
5182 025624 062702 000004      ADD     #4,R2
5183 025630 010237 001246      MOV      R2,STMP6
5184 025634 012737 026042 001250  MOV      #MODFT0,STMP7
5185 025642 012737 026052 001252  MOV      #MODFT1,STMP10
5186 025650 010437 001254      MOV      R4,STMP11
5187 025654 016137 000032 001256  MOV      32(R1),STMP12
5188
5189 025662 012702 026042      MOV      #MODFT0,R2   ;CHECK THE FRACTIONAL RESULT.
5190 025666 026112 000010      CMP     10(R1),(R2)
5191 025672 001022          BNE     10$          ;BRANCH IF INCORRECT.
5192 025674 026162 000012 000002  CMP     12(R1),2(R2)
5193 025702 001016          BNE     10$
5194
5195 025704 012702 026052      MOV      #MODFT1,R2   ;CHECK THE INTEGER RESULT.
5196 025710 026112 000014      CMP     14(R1),(R2)
5197 025714 001026          BNE     15$          ;BRANCH IF INCORRECT.
5198 025716 026162 000016 000002  CMP     16(R1),2(R2)
5199 025724 001022          BNE     15$
5200
5201 025726 026104 000032      CMP     32(R1),R4     ;CHECK THE FPS.
5202 025732 001034          BNE     20$          ;BRANCH IF INCORRECT.
5203
5204 025734 000161 000042          9$:    JMP      42(R1)      ;RETURN.
5205
5206          ;FRACTIONAL ERROR.
5207 025740 026112 000020          10$:   CMP     20(R1),(R2)   ;WAS THE ERROR ANTICIPATED?
5208 025744 001010          BNE     11$          ;BRANCH IF NOT ANTICIPATED.
5209 025746 026162 000022 000002  CMP     22(R1),2(R2)
    
```

5210	025754	001004				BNE	11\$	
5211	025756	010102				MOV	R1,R2	:THE ERROR WAS ANTICIPATED SO
5212	025760	062702	000034			ADD	#34,R2	:RETURN TO THE ERROR REPORT AT THE
5213								:CALLING ROUTINE.
5214	025764	000112				JMP	(R2)	
5215								
5216	025766				11\$:			:THE ERROR WAS NOT ANTICIPATED SO
5217	02576	104053			12\$:	ERROR	+53	:REPORT THE INCORRECT FRACTION HERE.
5218	02577	000761				BR	9\$	
5219								
5220								
5221	025772	026112	000024			:INTEGER ERROR.		
5222	025776	001010			15\$:	CMP	24(R1),(R2)	:WAS THIS ERROR ANTICIPATED?
5223	026000	026162	000026	0C0002		BNE	16\$:BRANCH IF NOT.
5224	026006	001004				CMP	26(R1),2(R2)	
5225	026010	010102				BNE	16\$	
5226	026012	062702	000040			MOV	R1,R2	:THE ERROR WAS ANTICIPATED SO RETURN
5227						ADD	#40,R2	:TO THE ERROR REPORT IN THE CALLING
5228	026016	000112				JMP	(R2)	:ROUTINE.
5229								
5230	026020				16\$:			:THE ERROR WAS NOT ANTICIPATED SO REPORT
5231	026020	104054			17\$:	ERROR	+54	:THE INTEGER FAILURE HERE.
5232	026022	000744				BR	9\$	
5233								
5234						:FPS INCORRECT.		
5235	026024	010437	001254		20\$:	MOV	R4,\$TMP11	:REPORT INCORRECT FPS.
5236	026030	016137	000032	001256		MOV	32(R1),\$TMP12	
5237	026036	104055			21\$:	ERROR	+55	
5238	026040	000735				BR	9\$	
5239								
5240	026042	000000	000000	000000	MODFT0:	.WORD	0,0,0,0	
5241								
5242	026052	000000	000000	000000	MODFT1:	.WORD	0,0,0,0	
5243								
5244	026062	177777	177777	177777	MODP1:	.WORD	-1,-1,-1,-1	
5245								
5246	026072				GGGDONE:			:GO INITIALIZE THE FPS AND STACK; AND
	026072	104412				RSETUP		:SEE IF THE USER HAS EXPRESSED
								:THE DESIRE TO CHANGE THE SOFTWARE
								:VIRTUAL CONSOLE SWITCH REGISTER (HAS
								:THE USER TYPED CONTROL G?).
5247								
5248								
5249								
5257								

5258

```
.SBTTL TEST # 17 - MODD TEST
:*****
:*TEST 17      MODD TEST
:*
:*THIS IS A TEST OF THE MODD INSTRUCTION. IT MAKES USE OF A SUBROUTINE
:*TO SET UP THE ARGUMENTS, EXECUTE THE INSTRUCTION AND CHECK THE
:*RESULTS.
:*
:*****
```

5259 026074 000004

TST17: SCOPE

5260

;MODD WITH (FSRC=AC=0)

5261

HHM1:

026076

LPEFR

;SET UP THE LOOP ON ERROR ADDRESS.

026076 104413

JSR PC,MODDSUB

5262 026100 004737 027602

1\$: .WORD 0,0,0,0

;AC

5263 026104 000000 000000 000000

2\$: .WORD 0,0,0,0

;FSRC

5264 026114 000000 000000 000000

3\$: .WORD 0,0,0,0

;FRACTIONAL RES.

5265 026124 000000 000000 000000

4\$: .WORD 0,0,0,0

;INTEGER RES.

5266 026134 000000 000000 000000

5\$: .WORD 0,0,0,0

;ERROR FRACTIONAL RES.

5267 026144 000000 000000 000000

6\$: .WORD 0,0,-1,-1

;ERROR INTEGER RES.

5268 026154 000000 000000 177777

7\$: 200

;FPS BEFORE EXECUTION.

5269 026164 000200

204

;FPS AFTER EXECUTION.

5270 026166 000204

8\$: ERROR +70

5271 026170 104070

BR 9\$

5272 026172 000401

ERROR +74

;ST 231 TO 142 INTO 143

5273 026174 104074

9\$:

5274 026176

;MODD TEST WITH FSRC=0

5275

HHM2:

5276

LPERR

;SET UP THE LOOP ON ERROR ADDRESS.

5277 026176 104413

JSR PC,MODDSUB

5278 026200 004737 027602

1\$: .WORD 012345,67012

;AC

5279 026204 012345 067012

2\$: .WORD 34567,012345

;FSRC

5280 026210 034567 012345

3\$: .WORD 0,0,0,0

;FRACTIONAL RES.

5281 026214 000000 000000 000000

4\$: .WORD 0,0,0,0

;INTEGER RES.

5282 026224 000000 000000 000000

5\$: .WORD 012345,67012

;ERROR FRACTIONAL RES.

5283 026234 000000 000000 000000

6\$: .WORD 34567,012345

;ERROR INTEGER RES.

5284 026244 012345 067012

7\$: .WORD -1,-1,-1,-1

;FPS BEFORE EXECUTION.

5285 026250 034567 012345

213

;FPS AFTER EXECUTION.

5286 026254 177777 177777 177777

204

;STORE DOUBLE ZERO

5287 026264 000213

8\$: ERROR +75

5288 026266 000204

BR 9\$

5289 026270 104075

ERROR +76

;AC V 1 <= ZERO ST 143

5290 026272 000401

9\$:

5291 026274 104076

5292 026276

;MODD TEST WITH (AC=0)

5293

HHM3:

5294

LPERR

;SET UP THE LOOP ON ERROR ADDRESS.

5295 026276 104413

JSR PC,MODDSUB

5296 026300 004737 027602

1\$: .WORD 0,0,0,0

;AC

5297 026304 000000 000000 000000

2\$: .WORD 72727,127272

;FSRC

5298 026314 072727 127272

3\$: .WORD 72727,127272

;FRACTIONAL RES.

5299 026320 072727 127272

4\$: .WORD 0,0,0,0

;INTEGER RES.

5300 026324 000000 000000 000000

5\$: .WORD 0,0,0,0

;ERROR FRACTIONAL RES.

5301 026334 000000 000000 000000

5\$: .WORD -1,-1,-1,-1

5302 026344 177777 177777 177777

5303	026354	177777	177777	177777	6\$:	.WORD	-1,-1,-1,-1		:ERROR INTEGER RES.
5304	026364	000213			7\$:	213			:FPS BEFORE EXECUTION.
5305	026366	000204				204			:FPS AFTER EXECUTION.
5306	026370	104070			8\$:	ERROR	+70		
5307	026372	000401				BR	9\$		
5308	026374	104071				ERROR	+71		
5309	026376				9\$:				
5310									
5311									
5312	026376								
	026376	104413			HHH4:	LPERR			:SET UP THE LOOP ON ERROR ADDRESS.
5313	026400	004737	027602			JSR	PC,MODDSUB		
5314	026404	056252	125252		1\$:	.WORD	56252,125252		:AC
5315	026410	125252	125250			.WORD	125252,125250		
5316	026414	040300	000000	000000	2\$:	.WORD	40300,0,0,0		:FSRC
5317	026424	000000	000000	000000	3\$:	.WORD	0,0,0,0		:FRACTIONAL RES.
5318	026434	056377	177777	177777	4\$:	.WORD	56377,-1,-1,-4		:INTEGER RES.
5319	026444	000000	000000		5\$:	.WORD	0,0		:ERROR FRACTIONAL RES.
5320	026450	125252	125252			.WORD	125252,125252		
5321	026454	056377	177777	177777	6\$:	.WORD	56377,-1,-1,-1		:ERROR INTEGER RES.
5322	026464	000213			7\$:	213			:FPS BEFORE EXECUTION.
5323	026466	000204				204			:FPS AFTER EXECUTION.
5324	026470	104077			8\$:	ERROR	+77		:ST 526 TO 134 INTO 135
5325	026472	000401				BR	9\$		
5326	026474	104077				ERROR	+77		
5327	026476				9\$:				
5328									
5329									
5330	026476								
	026476	104413			HHH5:	LPERR			:SET UP THE LOOP ON ERROR ADDRESS.
5331	026500	004737	027602			JSR	PC,MODDSUB		
5332	026504	140240	000000	000000	1\$:	.WORD	140240,0,0,0		:AC
5333	026514	063714	146314		2\$:	.WORD	63714,146314		:FSRC
5334	026520	133572	167737			.WORD	133572,167737		
5335	026524	000000	000000	000000	3\$:	.WORD	0,0,0,0		:FRACTIONAL RES.
5336	026534	163777	177777		4\$:	.WORD	163777,-1		:INTEGER RES.
5337	026540	162531	125726			.WORD	162531,125726		
5338	026544	177777	177777	177777	5\$:	.WORD	-1,-1,-1,-1		:ERROR FRACTIONAL RES.
5339	026554	063777	177777		6\$:	.WORD	63777,-1		:ERROR INTEGER RES.
5340	026560	162531	125726			.WORD	162531,125726		
5341	026564	000210			7\$:	210			:FPS BEFORE EXECUTION.
5342	026566	000204				204			:FPS AFTER EXECUTION.
5343	026570	104070			8\$:	ERROR	+70		
5344	026572	000401				BR	9\$		
5345	026574	104100				ERROR	+100		:ST 526 BAD SIGN
5346	026576				9\$:				
5347									
5348									
5349	026576								
	026576	104413			HHH6:	LPERR			:SET UP THE LOOP ON ERROR ADDRESS.
5350	026600	004737	027602			JSR	PC,MODDSUB		
5351	026604	056200	000000	000000	1\$:	.WORD	56200,0,0,1		:AC
5352	026614	040340	000000	000000	2\$:	.WORD	40340,0,0,0		:FSRC
5353	026624	000000	000000	000000	3\$:	.WORD	0,0,0,0		:FRACTIONAL RES.
5354	026634	056340	000000	000000	4\$:	.WORD	56340,0,0,1		:INTEGER RES.
5355	026644	040000	000000	000000	5\$:	.WORD	40000,0,0,0		:ERROR FRACTIONAL RES.
5356	026654	056340	000000	000000	6\$:	.WORD	56340,0,0,1		:ERROR INTEGER RES.

```

5357 026664 000213      7$:      213      :FPS BEFORE EXECUTION.
5358 026666 000204      :          204      :FPS AFTER EXECUTION.
5359 026670 104101      8$:      ERROR    +101   :CONSTANT BAD (NOT 56)
5360                               :          :          :OR ST 525 TO 050 INTO 150
5361 026672 000401      :          BR      9$
5362 026674 104101      :          ERROR    +101
5363 026676
5364
5365      :MODD TEST WITH EXPONENT OF THE RESULT = 56
5366 026676      HHH7:      LPERR      :SET UP THE LOOP ON ERROR ADDRESS.
           026676 104413      JSR      PC,MODDSUB
5367 026700 004737 027602      :          56000,0,0,1   :AC
5368 026704 056000 000000 000000 1$:      .WORD    40340,0,0,0   :FSRC
5369 026714 040340 000000 000000 2$:      .WORD    40100,0,0,0   :FRACTIONAL RES.
5370 026724 040100 000000 000000 3$:      .WORD    56140,0,0,1   :INTEGER RES.
5371 026734 056140 000000 000000 4$:      .WORD    0,0,0,0       :ERROR FRACTIONAL RES.
5372 026744 000000 000000 000000 5$:      .WORD    56140,0,0,1   :ERROR INTEGER RES.
5373 026754 056140 000000 000000 6$:      .WORD    213          :FPS BEFORE EXECUTION.
5374 026764 000213      :          200          :FPS AFTER EXECUTION.
5375 026766 000200      :          ERROR    +102   :BAD CONSTANT (NOT 56) OR
5376 026770 104102      8$:      ERROR    +102   :ST 525 TO 150 INTO 050
5377
5378 026772 000401      :          BR      9$
5379 026774 104102      :          ERROR    +102
5380 026776
5381
5382      :MODD TEST WITH EXPONENT OF THE RESULT = 36
5383 026776      HHH8:      LPERR      :SET UP THE LOOP ON ERROR ADDRESS.
           026776 104413      JSR      PC,MODDSUB
5384 027000 004737 027602      :          51177,-1,-1,-1 :AC
5385 027004 051177 177777 177777 1$:      .WORD    40200,0,0,0   :FSRC
5386 027014 040200 000000 000000 2$:      .WORD    40177,-20,0,0 :FRACTIONAL RES.
5387 027024 040177 177760 000000 3$:      .WORD    51177,-1,-20,0 :INTEGER RES.
5388 027034 051177 177777 177760 4$:      .WORD    -1,-1,-1,-1   :ERROR FRACTIONAL RES.
5389 027044 177777 177777 177777 5$:      .WORD    -1,-1,-1,-1   :ERROR INTEGER RES.
5390 027054 177777 177777 177777 6$:      .WORD    217          :FPS BEFORE EXECUTION.
5391 027064 000217      :          200          :FPS AFTER EXECUTION.
5392 027066 000200      :          ERROR    +70
5393 027070 104070      8$:      BR      9$
5394 027072 000401      :          ERROR    +71
5395 027074 104071
5396 027076
5397
5398      :MODD TEST WITH EXPONENT OF THE RESULT = 30
5399 027076      HHH9:      LPERR      :SET UP THE LOOP ON ERROR ADDRESS.
           027076 104413      JSR      PC,MODDSUB
5400 027100 004737 027602      :          40200,0,0,0   :AC
5401 027104 040200 000000 000000 1$:      .WORD    47577,-1     :FSRC
5402 027114 047577 177777      :          176000,1     :FRACTIONAL RES.
5403 027120 176000 000001      :          31600,0,0,0   :INTEGER RES.
5404 027124 031600 000000 000000 3$:      .WORD    47577,-1     :ERROR FRACTIONAL RES.
5405 027134 047577 177777      :          176000,0     :ERROR INTEGER RES.
5406 027140 176000 000000      :          0,0,0,0       :FPS BEFORE EXECUTION.
5407 027144 000000 000000 000000 5$:      .WORD    47577,-1,-1,-1 :FPS AFTER EXECUTION.
5408 027154 047577 177777 177777 6$:      .WORD    200          :FPS BEFORE EXECUTION.
5409 027164 000200      :          200          :FPS AFTER EXECUTION.
5410 027166 000200
    
```

```

5411 027170 104103      8$:      ERROR      +103      ;(NORMALIZE) ST 532 TO 122
5412                                     ;INTO NORM.
5413 027172 000401      BR          9$
5414 027174 104104      ERROR      +104      ;AC V 1 <= X14
5415                                     ;OR ST 733 TO 156 INTO 157.
5416 027176      9$:
5417
5418      ;MODD TEST WITH EXPONENT OF THE RESULT = 31
5419 027176      HHH10:
      027176 104413      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
5420 027200 004737 027602      JSR      PC,MODDSUB
      047777 177777      1$:      .WORD      47777,-1      ;AC
5421 027204 047777 177777      .WORD      177000,0
5422 027210 177000 000000      .WORD      40200,0,0,0      ;FSRC
5423 027214 040200 000000 000000 2$:      .WORD      0,0,0,0      ;FRACTIONAL RES.
5424 027224 000000 000000 000000 3$:      .WORD      47777,-1      ;INTEGER RES.
5425 027234 047777 177777      .WORD      177000,0
5426 027240 177000 000000      .WORD      0,0,177000,0      ;ERROR FRACTIONAL RES.
5427 027244 000000 000000 177000 5$:      .WORD      -1,-1,-1,-1      ;ERROR INTEGER RES.
5428 027254 177777 177777 177777 6$:      213      ;FPS BEFORE EXECUTION.
5429 027264 000213      7$:      204      ;FPS AFTER EXECUTION.
5430 027266 000204      8$:      ERROR      +105      ;(BUT FD) STORE X10
5431 027270 104105      BR          9$
5432 027272 000401      ERROR      +71
5433 027274 104071
5434 027276      9$:
5435
5436      ;MODD TEST WITH EXPONENT OF THE RESULT = 0
5437 027276      HHH11:
      027276 104413      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
5438 027300 004737 027602      JSR      PC,MODDSUB
5439 027304 040200 000000 000000 1$:      .WORD      40200,0,0,0      ;AC
5440 027314 040177 072727 072727 2$:      .WORD      40177,72727      ;FSRC
5441 027320 127272 072727      .WORD      127272,72727
5442 027324 040177 072727      .WORD      40177,72727      ;FRACTIONAL RES.
5443 027330 127272 072727      .WORD      127272,72727
5444 027334 000000 000000 000000 4$:      .WORD      0,0,0,0      ;INTEGER RES.
5445 027344 177777 177777 177777 5$:      .WORD      -1,-1,-1,-1      ;ERROR FRACTIONAL RES.
5446 027354 000000 000000 177777 6$:      .WORD      0,0,-1,-1      ;ERROR INTEGER RES.
5447 027364 000200      7$:      200      ;FPS BEFORE EXECUTION.
5448 027366 000200      200      ;FPS AFTER EXECUTION.
5449 027370 104070      8$:      ERROR      +70
5450 027372 000401      BR          9$
5451 027374 104106      ERROR      +106      ;ST 246 TO 126 INTO 127 (BUT FD)
5452 027376      9$:
5453
5454      ;MODD TEST WITH EXPONENT OF THE RESULT = -115
5455 027376      HHH12:
      027376 104413      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
5456 027400 004737 027602      JSR      PC,MODDSUB
5457 027404 003377 177777      1$:      .WORD      3377,-1      ;AC
5458 027410 177777 052525      .WORD      -1,52525
5459 027414 040200 000000 000000 2$:      .WORD      40200,0,0,0      ;FSRC
5460 027424 003377 177777      3$:      .WORD      3377,-1      ;FRACTIONAL RES.
5461 027430 177777 052525      .WORD      -1,52525
5462 027434 000000 000000 000000 4$:      .WORD      0,0,0,0      ;INTEGER RES.
5463 027444 177777 177777 177777 5$:      .WORD      -1,-1,-1,-1      ;ERROR FRACTIONAL RES.
5464 027454 000000 000000 177777 6$:      .WORD      0,0,-1,-1      ;ERROR INTEGER RES.
    
```

```

5465 027464 000200      7$:      200      :FPS BEFORE EXECUTION.
5466 027466 000200      200      :FPS AFTER EXECUTION.
5467 027470 104070      8$:      ERROR    +70
5468 027472 000401      BR        9$
5469 027474 104107      ERROR    +107      :ST 446 TO 126 INTO 127 (BUT FD)
5470 027476

```

```

5471
5472      :MODD TEST WITH EXPONENT OF THE RESULT = -63, IN ROUND MODE.
5473 HH13:

```

```

      LPERR      :SET UP THE LOOP ON ERROR ADDRESS.
      JSR        PC,MODDSUB
5474 027500 004737 027602      1$:      .WORD    40300,0,0,0      :AC
5475 027504 04030C 000000 000000      2$:      .WORD    20200,0,0,1      :FSRC
5476 027514 02020J 000000 000000      3$:      .WORD    20300,0,0,2      :FRACTIONAL RES.
5477 027524 02030J 000000 000000      4$:      .WORD    0,0,0,0      :INTEGER RES.
5478 027534 000000 000000 000000      5$:      .WORD    0,0,-1,-1      :ERROR FRACTIONAL RES.
5479 027544 000000 000000 177777      6$:      .WORD    -1,-1,-1,-1      :ERROR INTEGER RES.
5480 027554 177777 177777 177777      7$:      200      :FPS BEFORE EXECUTION.
5481 027564 000200      200      :FPS AFTER EXECUTION.
5482 027566 000200      8$:      ERROR    +110      :ST 127 INTO RND/TR
5483 027570 104110      BR        9$
5484 027572 000401      ERROR    +71
5485 027574 104071
5486 027576 000137 030200      9$:      JMP        HHDONE ;GO TO THE NEXT TEST.

```

```

5487
5488      :THIS SUBROUTINE, MODDSUB, IS CALLED TO SETUP THE
5489      :OPERANDS, EXECUTE THE MODD INSTRUCTION AND CHECK THE RESULTS.
5490      :IT IS CALLED THUS:

```

```

5491      :
5492      :
5493      :
5494      :
5495      :
5496      :
5497      :
5498      :
5499      :
5500      :
5501      :
5502      :
5503      :
5504      :
5505      :
5506      :
5507      :
5508      :
5509      :
5510      :
5511      :
5512      :
5513      :
5514      :
5515      :
5516      :
5517      :
5518      :
5519      :
5520      :

```

ACARG: .WORD	X,X,X,X	:AC OPERAND
FSRCARG: .WORD	X,X,X,X	:FSRC OPERAND
FRES: .WORD	X,X,X,X	:FRACTIONAL RESULT
INTRES: .WORD	X,X,X,X	:INTEGER RESULT
ERFRES: .WORD	X,X,X,X	:ERROR FRACTION RESULT
ERINTRES: .WORD	X,X,X,X	:ERROR INTEGER RESULT
FPSB: .WORD	X	:FPS BEFORE EXECUTION
FPSA: .WORD	X	:FPS AFTER EXECUTION
ERR1: ERROR	+X	:FRACTION ERROR
	BR	CONT
ERR2: ERROR	+X	:INTEGER ERROR
CONT:		:RETURN ADDRESS

```

      :THE OPERANDS ARE SET UP (USING ACO FOR THE AC ARGUMENT). THE MODD
      :INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
      :THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
      :THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
      :THEN THE FPS IS COMPARED WITH FPSA. AFTER EXECUTION IF NO ERRORS OCCURRED
      :THEN MODDSUB WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
      :IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
      :THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH
      :THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED
      :FAILURE MATCHES THE TRUE RESULT THEN MODDSUB PASSES CONTROL TO THE
      :ERROR CALL AT ERR1. LIKewise IF THE INTEGER PART OF THE RESULT IS
      :NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER
      :FAILURE. IF THIS DOESN'T MATCH THEN THE ERROR IS REPORTED HERE.
      :IF A MATCH IS MADE HOWEVER, MODDSUB WILL RETURN CONTROL TO THE ERROR
      :CALL AT ERR2.

```

```

5521 027602 012601          MODDSUB:  MOV      (SP)+,R1      ;GET A POINTER TO THE ARGUMENTS
5522 027604 012700 000200      MOV      #200,R0      ;SET FD MODE.
5523 027610 170100          LDFPS   R0
5524 027612 010100          MOV      R1,R0      ;SET UP ACO
5525 027614 172410          LDD     (R0),ACO
5526 027616 012700 026062      MOV      #MODP1,R0    ;PUT A BACKGROUND PATTERN INTO AC1.
5527 027622 172510          LDD     (R0),AC1
5528 027624 016100 000060      MOV      60(R1),R0    ;SET UP THE FPS.
5529 027630 170100          LDFPS   R0
5530 027632 012737 027646 001236  MOV      #1$,STMP2
5531 027640 015100          MOV      R1,R0      ;COMPUTE THE ADDRESS OF THE FSRC.
5532 027642 062700 000010      ADD      #10,R0
5533
5534 027646 171410          1$:   MODD     (R0),ACO      ;EXECUTE THE TEST INSTRUCTION.
5535
5536 027650 170204          STFPS   R4      ;GET THE FPS.
5537 027652 012700 000200      MOV      #200,R0      ;SET FD MODE.
5538 027656 170100          LDFPS   R0
5539 027660 012700 030160      MOV      #MODDT0,R0   ;GET THE FRACTIONAL RESULT.
5540 027664 174010          STD     AC0,(R0)
5541 027666 012700 030170      MOV      #MODDT1,R0   ;GET THE INTEGER RESULT.
5542 027672 174110          STD     AC1,(R0)
5543
5544 027674 010102          MOV      R1,R2      ;SAVE THE DATA IN CASE OF ERROR.
5545 027676 010237 001240      MOV      R2,STMP3
5546 027702 062702 000010      ADD      #10,R2
5547 027706 010237 001242      MOV      R2,STMP4
5548 027712 062702 000010      ADD      #10,R2
5549 027716 010237 001244      MOV      R2,STMP5
5550 027722 062702 000010      ADD      #10,R2
5551 027726 010237 001246      MOV      R2,STMP6
5552 027732 012737 030160 001250      MOV      #MODDT0,STMP7
5553 027740 012737 030170 001252      MOV      #MODDT1,STMP10
5554 027746 016137 000062 001256      MOV      62(R1),STMP12
5555 027754 010437 001254      MOV      R4,STMP11
5556
5557 027760 012702 030160      MOV      #MODDT0,R2   ;CHECK THE FRACTIONAL RESULT.
5558 027764 010103          MOV      R1,R3
5559 027766 062703 000020      ADD      #20,R3
5560 027772 012705 000004      MOV      #4,R5
5561 027776 022223          2$:   CMP      (R2)+,(R3)+
5562 030000 001020          BNE     10$      ;BRANCH IF INCORRECT.
5563 030002 077503          SOB     R5,2$
5564
5565 030004 012702 030170      MOV      #MODDT1,R2   ;CHECK THE INTEGER RESULT.
5566 030010 010103          MOV      R1,R3
5567 030012 062703 000030      ADD      #30,R3
5568 030016 012705 000004      MOV      #4,R5
5569 030022 022223          3$:   CMP      (R2)+,(R3)+
5570 030024 001026          BNE     15$      ;BRANCH IF INCORRECT.
5571 030026 077503          SOB     R5,3$
5572
5573
5574 030030 026104 000062          CMP      62(R1),R4    ;CHECK THE FPS.
5575 030034 001042          BNE     20$      ;BRANCH IF INCORRECT.
5576
5577 030036 000161 000072          9$:   JMP      72(R1)      ;RETURN.

```

```

5578
5579
5580 030042 012702 030160
5581 030046 010103
5582 030050 062703 000040
5583 030054 012705 000004
5584 030060 022223
5585 030062 001005
5586 030064 077503
5587 030066 010102
5588 030070 062702 000064
5589
5590 030074 000112
5591
5592 030076
5593 030076 104070
5594 030100 000756
5595
5596
5597 030102 012702 030170
5598 030106 010103
5599 030110 062703 000050
5600 030114 012705 000004
5601 030120 022223
5602 030122 001005
5603 030124 077503
5604 030126 010102
5605 030130 062702 000070
5606
5607 030134 000112
5608
5609 030136
5610 030136 104071
5611 030140 000736
5612
5613
5614 030142 010437 001254
5615 030146 016137 000062 001256
5616 030154 104072
5617 030156 000727
5618
5619 030160 000000 000000 000000
5620
5621 030170 000000 000000 000000
5622
5623 030200
030200 104412

: FRACTIONAL ERROR.
10$: MOV #MODDT0,R2 ; WAS THE FRACTIONAL ERROR ANTICIPATED?
MOV R1,R3
ADD #40,R3
MOV #4,R5
50$: CMP (R2)+,(R3)+ ; BRANCH IF NOT ANTICIPATED.
BNE 11$
SOB R5,50$
MOV R1,R2 ; THE ERROR WAS ANTICIPATED SO
ADD #64,R2 ; RETURN TO THE ERROR REPORT AT THE
; CALLING ROUTINE.
JMP (R2)

11$:
12$: ERROR +70 ; THE ERROR WAS NOT ANTICIPATED SO
BR 9$ ; REPORT THE INCORRECT FRACTION HERE.

: INTEGER ERROR.
15$: MOV #MODDT1,R2 ; WAS THE INTEGER ERROR ANTICIPATED?
MOV R1,R3
ADD #50,R3
MOV #4,R5
60$: CMP (R2)+,(R3)+ ; BRANCH IF NOT ANTICIPATED.
BNE 17$
SOB R5,60$
MOV R1,R2 ; THE ERROR WAS ANTICIPATED SO RETURN
ADD #70,R2 ; TO THE ERROR REPORT IN THE CALLING
; ROUTINE.
JMP (R2)

16$:
17$: ERROR +71 ; THE ERROR WAS NOT ANTICIPATED SO REPORT
BR 9$ ; THE INTEGER FAILURE HERE.

: FPS INCORRECT.
20$: MOV R4,$TMP11 ; REPORT INCORRECT FPS.
MOV 62(R1),$TMP12
21$: ERROR +72
BR 9$

MODDT0: .WORD 0,0,0,0
MODDT1: .WORD 0,0,0,0
HHHDONE:
RSETUP ; GO INITIALIZE THE FPS AND STACK; AND
; SEE IF THE USER HAS EXPRESSED
; THE DESIRE TO CHANGE THE SOFTWARE
; VIRTUAL CONSOLE SWITCH REGISTER (HAS
; THE USER TYPED CONTROL G?).

5624
5625
5626
5634
5635 ; TEST TITLE: UNDER/OVERFLOW, USING MODF WITH TRAPS DISABLED
    
```

5636

```

.SBTTL TEST # 20 - SEE COMMENT ABOVE FOR TEST TITLE
:*****
:*TEST 20 SEE COMMENT ABOVE FOR TEST TITLE
:*
:*THIS IS A TEST OF THE MODF OVERFLOW AND UNDERFLOW CONDITIONS. IT MAKES
:*USE OF A SUBROUTINE TO SETUP THE OPERANDS, EXECUTE THE MODF INSTRUCTION
:*AND CHECK THE RESULTS. TRAPS ARE DISABLED DURING THIS TEST.
:*
:*****

```

```

030202 000004
5637
5638
5639 030204
030204 104413
5640 030206 004737 030532
5641 030212 020123 045676
5642 030216 020200 000000
5643 030222 000123 045676
5644 030226 000000 000000
5645 030232 177777 177777
5646 030236 177777 177777
5647 030242 042000
5648 030244 142004
5649 030246 000012
5650 030250 104170
5651 030252 000401
5652 030254 104171
5653 030256
5654
5655
5656 030256
030256 104413
5657 030260 004737 030532
5658 030264 010200 000000
5659 030270 010000 000000
5660 030274 000000 000000
5661 030300 000000 000000
5662 030304 177777 177777
5663 030310 177777 177777
5664 030314 005013
5665 030316 005004
5666 030320 000012
5667 030322 000240
5668 030324 000401
5669 030326 104171
5670 030330
5671
5672
5673 030330
030330 104413
5674 030332 004737 030532
5675 030336 060052 125252
5676 030342 060200 000000
5677 030346 000000 000000
5678 030352 000052 125252
5679 030356 000000 000000
5680 030362 000000 000000

```

TST20: SCOPE

:UNDERFLOW TEST, WITH EXPONENT OF THE RESULT = -129, FIU = 1, FID = 1

```

MM1:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,MODFOV
1$: .WORD 20123,45676 ;AC
2$: .WORD 20200,0 ;FSRC
3$: .WORD 123,45676 ;FRACTIONAL RES.
4$: .WORD 0,0 ;INTEGER RES.
5$: .WORD -1,-1 ;ERROR FRACTIONAL RES.
6$: .WORD -1,-1 ;ERROR INTEGER RES.
7$: 42000 ;FPS BEFORE EXECUTION.
142004 ;FPS AFTER EXECUTION.
12 ;FEC
8$: ERROR +170 ;FEC INCORRECT, UNDERFLOW.
BR 9$
9$: ERROR +171 ;AC V 1 (2,3) <= ZERO, ST 126.

```

:UNDERFLOW EXP OF RESULT = -193, FIU = 0, FID = 1

```

MM2:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,MODFOV
1$: .WORD 10200,0 ;AC
2$: .WORD 10000,0 ;FSRC
3$: .WORD 0,0 ;FRACTIONAL RES.
4$: .WORD 0,0 ;INTEGER RES.
5$: .WORD -1,-1 ;ERROR FRACTIONAL RES.
6$: .WORD -1,-1 ;ERROR INTEGER RES.
7$: 5013 ;FPS BEFORE EXECUTION.
5004 ;FPS AFTER EXECUTION.
12 ;FEC
8$: NOP
BR 9$
9$: ERROR +171

```

:OVERFLOW TEST WITH EXPONENT OF THE RESULT = 128, FIV = 1, FID = 1

```

MM3:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,MODFOV
1$: .WORD 60052,125252 ;AC
2$: .WORD 60200,0 ;FSRC
3$: .WORD 0,0 ;FRACTIONAL RES.
4$: .WORD 52,125252 ;INTEGER RES.
5$: .WORD 0,0 ;ERROR FRACTIONAL RES.
6$: .WORD 0,0 ;ERROR INTEGER RES.

```



```

5681 030366 041000      7$:      41000      :FPS BEFORE EXECUTION.
5682 030370 141006      :FPS AFTER EXECUTION.
5683 030372 000010      :FEC
5684 030374 104172      8$:      ERROR      +172      :BAD FEC ON OVERFLOW.
5685 030376 000401      BR          9$
5686 030400 104173      ERROR      +173      :ST 520 TO STORE ZERO TWICE
5687
5688 030402      9$:
5689
5690      :OVERFLOW TEST WITH EXPONENT OF THE RESULT = 130, FIV = 0, FID = 1
5691 030402      MPM4:
5692 030404 104413      LPERR      :SET UP THE LOOP ON ERROR ADDRESS.
5693 030410 004737 030532      JSR      PC,MODFOV
5694 030414 060345 067654      1$:      .WORD      60345,67654      :AC
5695 030420 060200 000000      2$:      .WORD      60200,0      :FSRC
5696 030424 000000 000000      3$:      .WORD      0,0      :FRACTIONAL RES.
5697 030430 000000 000000      4$:      .WORD      0,0      :INTEGER RES.
5698 030434 000345 067654      5$:      .WORD      0,0      :ERROR FRACTIONAL RES.
5699 030440 006011      6$:      .WORD      345,67654      :ERROR INTEGER RES.
5700 030442 006006      7$:      6011      :FPS BEFORE EXECUTION.
5701 030444 000010      6006      :FPS AFTER EXECUTION.
5702 030446 000240      10      :FEC
5703 030450 000401      8$:      NOP
5704 030452 104174      BR          9$
5705 030454      ERROR      +174      :ST 520 TO 162 INTO STORE ZERO TWICE.
5706
5707      :OVERFLOW TEST WITH EXPONENT OF THE RESULT = 128, RESULT NEGATIVE
5708      :AND FIV = 1, FID = 1
5709 030454      MPM5:
5710 030454 104413      LPERR      :SET UP THE LOOP ON ERROR ADDRESS.
5711 030456 004737 030532      JSR      PC,MODFOV
5712 030462 160252 125252      1$:      .WORD      160252,125252      :AC
5713 030466 060000 000000      2$:      .WORD      60000,0      :FSRC
5714 030472 000000 000000      3$:      .WORD      0,0      :FRACTIONAL RES.
5715 030502 000000 000000      4$:      .WORD      100052,125252      :INTEGER RES.
5716 030506 000052 125252      5$:      .WORD      0,0      :ERROR FRACTIONAL RES.
5717 030512 041000      6$:      .WORD      52,125252      :ERROR INTEGER RES.
5718 030514 141006      7$:      41000      :FPS BEFORE EXECUTION.
5719 030516 141006      141006      :FPS AFTER EXECUTION.
5720 030520 104172      10      :FEC
5721 030522 000401      8$:      ERROR      +172
5722 030524 104175      BR          9$
5723 030526 000137 031126      ERROR      +175      :ST 517, BAD SIGN.
5724      JMP      MPM5DONE ;GO TO THE NEXT TEST.
5725
5726      :THIS SUBROUTINE, MODFOV, IS CALLED TO SETUP THE
5727      :OPERANDS, EXECUTE THE MODF INSTRUCTION AND CHECK THE RESULTS.
5728      :IT IS CALLED THUS:
5729      :
5730      :ACARG: .WORD X,X      :AC OPERAND
5731      :FSRCARG: .WORD X,X      :FSRC OPERAND
5732      :FRES: .WORD X,X      :FRACTIONAL RESULT
5733      :INTRES: .WORD X,X      :INTEGER RESULT
5734      :ERFRES: .WORD X,X      :ERROR FRACTION RESULT
5735      :ERINTRES: .WORD X,X      :ERROR INTEGER RESULT
5736      :FPSB: .WORD X      :FPS BEFORE EXECUTION
    
```

5736
5737
5738
5739
5740
5741
5742
5743
5744
5745
5746
5747
5748
5749
5750
5751
5752
5753
5754
5755
5756
5757
5758
5759
5760
5761
5762
5763
5764
5765
5766
5767
5768
5769
5770
5771
5772
5773
5774
5775
5776
5777
5778
5779
5780
5781
5782
5783
5784
5785
5786
5787
5788
5789
5790
5791
5792

030532 012601
030534 012700 000200
030540 170100
030542 010100
030544 172410
030546 012700 026062
030552 172510
030554 016100 000030
030560 170100
030562 012737 030576 001236
030570 010100
030572 062700 000004
030576 171410
030600 170204
030602 170305
030604 012700 000200
030610 170100
030612 012700 031106
030616 174010
030620 012700 031116
030624 174110
030626 010102
030630 010237 001240
030634 062702 000004
030640 010237 001242
030644 062702 000004
030650 010237 001244
030654 062702 000004
030660 010237 001246
030664 012737 031106 001250
030672 012737 031116 001252

```

FPSA: .WORD X ;FPS AFTER EXECUTION
FEC: .WORD X ;FEC
ERR1: ERROR +X ;FEC ERROR
      BR CONT
ERR2: ERROR +X ;INTEGER ERROR
CONT: ;RETURN ADDRESS
:THE OPERANDS ARE SET UP (USING ACO FOR THE AC ARGUMENT). THE MODF
:INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
:THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
:THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
:THEN THE FPS IS COMPARED WITH FPSA. AFTER EXECUTION IF NO ERRORS OCCURRED
:THEN MODFOV WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
:IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
:THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH
:THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED
:FAILURE MATCHES THE TRUE RESULT THEN MODFOV PASSES CONTROL TO THE
:ERROR CALL AT ERR1. LIKewise IF THE INTEGER PART OF THE RESULT IS
:NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER
:FAILURE. IF THIS DOESN'T MATCH THEN THE ERROR IS REPORTED HERE.
:IF A MATCH IS MADE HOWEVER, MODFOV WILL RETURN CONTROL TO THE ERROR
:CALL AT ERR2.
    
```

```

MODFOV: MOV (SP)+,R1 ;GET A POINTER TO THE ARGUMENTS
        MOV #200,R0 ;SET FD MODE.
        LDFPS R0
        MOV R1,R0 ;SET UP ACO
        LDD (R0),ACO
        MOV #MODP1,R0 ;PUT A BACKGROUND PATTERN INTO AC1.
        LDD (R0),AC1
        MOV 30(R1),R0 ;SET UP THE FPS.
        LDFPS R0
        MOV #1$,STMP2
        MOV R1,R0 ;COMPUTE THE ADDRESS OF THE FSRC.
        ADD #4,R0
1$: MODF (R0),ACO ;EXECUTE THE TEST INSTRUCTION.
        STFPS R4 ;GET THE FPS.
        STST R5 ;GET FEC.
        MOV #200,R0 ;SET FD MODE.
        LDFPS R0
        MOV #MODFDO,R0 ;GET THE FRACTIONAL RESULT.
        STD ACO,(R0)
        MOV #MODFD1,R0 ;GET THE INTEGER RESULT.
        STD AC1,(R0)
        MOV R1,R2 ;SAVE THE DATA IN CASE OF ERROR.
        MOV R2,STMP3
        ADD #4,R2
        MOV R2,STMP4
        ADD #4,R2
        MOV R2,STMP5
        ADD #4,R2
        MOV R2,STMP6
        MOV #MODFDO,STMP7
        MOV #MODFD1,STMP10
    
```

5793	030700	010437	001254		MOV	R4,\$TMP11	
5794	030704	016137	000032	001256	MOV	32(R1),\$TMP12	
5795	030712	010537	001260		MOV	R5,\$TMP13	
5796	030716	016137	000034	001262	MOV	34(R1),\$TMP14	
5797							
5798	030724	012702	031106		MOV	#MODFD0,R2	:CHECK THE FRACTIONAL RESULT.
5799	030730	026112	000010		CMP	10(R1),(R2)	
5800	030734	001025			BNE	10\$:BRANCH IF INCORRECT.
5801	030736	026162	000012	000002	CMP	12(R1),2(R2)	
5802	030744	001021			BNE	10\$	
5803							
5804	030746	012702	031116		MOV	#MODFD1,R2	:CHECK THE INTEGER RESULT.
5805	030752	026112	000014		CMP	14(R1),(R2)	
5806	030756	001016			BNE	15\$:BRANCH IF INCORRECT.
5807	030760	026162	000016	000002	CMP	16(R1),2(R2)	
5808	030766	001012			BNE	15\$	
5809							
5810	030770	026104	000032		CMP	32(R1),R4	:CHECK THE FPS.
5811	030774	001024			BNE	20\$:BRANCH IF INCORRECT.
5812							
5813	030776	026105	000034		CMP	34(R1),R5	:CHECK THE FEC.
5814	031002	001030			BNE	25\$:BRANCH IF INCORRECT.
5815							
5816	031004	000161	000044		9\$: JMP	44(R1)	:RETURN.
5817							
5818							:FRACTIONAL ERROR.
5819	031010				10\$:		:THE ERROR WAS NOT ANTICIPATED SO
5820	031010	104165			12\$: ERROR	+165	:REPORT THE INCORRECT FRACTION HERE.
5821	031012	000774			BR	9\$	
5822							
5823							:INTEGER ERROR.
5824	031014	026112	000024		15\$: CMP	24(R1),(R2)	:WAS THIS ERROR ANTICIPATED?
5825	031020	001010			BNE	16\$:BRANCH IF NOT.
5826	031022	026162	000026	000002	CMP	26(R1),2(R2)	
5827	031030	001004			BNE	16\$	
5828	031032	010102			MOV	R1,R2	:THE ERROR WAS ANTICIPATED SO RETURN
5829	031034	062702	000042		ADD	#42,R2	:TO THE ERROR REPORT IN THE CALLING
5830							:ROUTINE.
5831	031040	000112			JMP	(R2)	
5832							
5833	031042				16\$:		:THE ERROR WAS NOT ANTICIPATED SO REPORT
5834	031042	104166			17\$: ERROR	+166	:THE INTEGER FAILURE HERE.
5835	031044	000757			BR	9\$	
5836							
5837							:FPS INCORRECT.
5838	031046	010437	001254		20\$: MOV	R4,\$TMP11	:REPORT INCORRECT FPS.
5839	031052	016137	000032	001256	MOV	32(R1),\$TMP12	
5840	031060	104167			21\$: ERROR	+167	
5841	031062	000750			BR	9\$	
5842							
5843							:REPORT FEC ERROR.
5844	031064	010537	001260		25\$: MOV	R5,\$TMP13	
5845	031070	016137	000034	001262	MOV	34(R1),\$TMP14	
5846	031076	010102			MOV	R1,R2	
5847	031100	062702	000036		ADD	#36,R2	
5848	031104	000112			JMP	(R2)	
5849							

5850 031106 000000 000000 000000 MODFD0: .WORD 0,0,0,0
5851
5852 031116 000000 000000 000000 MODFD1: .WORD 0,0,0,0
5853
5854 031126
031126 104412

MMMDONE:
RSETUP

:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

5855
5856
5857
5865
5866

:TEST TITLE:UNDER/OVERFLOW, USING MODD WITH TRAPS DISABLED

5867

```
.SBTTL TEST # 21 - SEE COMMENT ABOVE FOR TEST TITLE
*****
*TEST 21 SEE COMMENT ABOVE FOR TEST TITLE
*
*THIS IS A TEST OF THE MODD INSTRUCTION'S OVER FLOW AND UNDER FLOW
*CONDITIONS. A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE
*MODD INSTRUCTION AND CHECK THE RESULTS.
*
*****
```

5868 031130 000004

TST21: SCOPE

5869

:UNDERFLOW TEST WITH EXPONENT OF THE RESULT = -129, FIU = 1, FID = 1

5870

NNN1:

```
031132 104413
5871 031134 004737 031546
5872 031140 020252 125252
5873 031144 125252 125252
5874 031150 020100 000000 000000
5875 031160 000177 177777 177777
5876 031170 000000 000000 000000
5877 031200 020252 125252
5878 031204 125252 125252
5879 031210 000000 000000 177777
5880 031220 042200
5881 031222 142204
5882 031224 000012
5883 031226 104201
5884 031230 000401
5885 031232 104202
5886 031234
```

```
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,MODDOV
1$: .WORD 20252,125252 ;AC
.WORD 125252,125252
2$: .WORD 20100,0,0,0 ;FSRC
3$: .WORD 177,-1,-1,-1 ;FRACTIONAL RES.
4$: .WORD 0,0,0,0 ;INTEGER RES.
5$: .WORD 20252,125252 ;ERROR FRACTIONAL RES.
.WORD 125252,125252
6$: .WORD 0,0,-1,-1 ;ERROR INTEGER RES.
7$: 42200 ;FPS BEFORE EXECUTION.
142204 ;FPS AFTER EXECUTION.
12 ;FEC
8$: ERROR +201 ;FEC INCORRECT ON UNDERFLOW.
BR 9$
ERROR +202 ;ST 155 (BUT FD)
9$:
```

5887

:UNDERFLOW TEST WITH EXPONENT OF THE RESULT = -193, FIU = 0, FID = 1

5888

NNN2:

```
031234
5889 031234 104413
5890 031236 004737 031546
5891 031242 010000 000000
5892 031246 12 000000
5893 031252 010200 000000 000000
5894 031262 000000 000000 000000
5895 031272 000000 000000 000000
5896 031302 000000 000000 000000
5897 031312 000000 000000
5898 031316 123456 000000
5899 031322 005213
5900 031324 005204
5901 031326 000012
5902 031330 000240
5903 031332 000401
5904 031334 104203
5905 031336
```

```
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,MODDOV
1$: .WORD 10000,0 ;AC
.WORD 123456,0
2$: .WORD 10200,0,0,0 ;FSRC
3$: .WORD 0,0,0,0 ;FRACTIONAL RES.
4$: .WORD 0,0,0,0 ;INTEGER RES.
5$: .WORD 0,0,0,0 ;ERROR FRACTIONAL RES.
6$: .WORD 0,0 ;ERROR INTEGER RES.
.WORD 123456,0
7$: 5213 ;FPS BEFORE EXECUTION.
5204 ;FPS AFTER EXECUTION.
12
8$: NOP
BR 9$
ERROR +203 ;ST 047 (BUT FD)
9$:
```

5906

:OVERFLOW TEST WITH EXPONENT OF THE RESULT = 128, FIV = 1, FID = 1

5907

NNN3:

```
031336
5908 031336 104413
5909 031340 004737 031546
5910 031344 060252 125252
5911 031350 125252 125252
```

```
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,MODDOV
1$: .WORD 60252,125252 ;AC
.WORD 125252,125252
```

```

5912 031354 060100 000000 000000 2$: .WORD 60100,0,0,0 :FSRC
5913 031364 000000 000000 000000 3$: .WORD 0,0,0,0 :FRACTIONAL RES.
5914 031374 000177 177777 177777 4$: .WORD 177,-1,-1,-1 :INTEGER RES.
5915 031404 000000 000000 000000 5$: .WORD 0,0,0,0 :ERROR FRACTIONAL RES.
5916 031414 000177 177777 177777 6$: .WORD 177,-1 :ERROR INTEGER RES.
5917 031420 125252 125252 .WORD 125252,125252
5918 031424 041200 7$: 41200 :FPS BEFORE EXECUTION.
5919 031426 141206 .WORD 141206 :FPS AFTER EXECUTION.
5920 031430 000010 .WORD 10 :FEC
5921 031432 104204 8$: ERROR +204 :FEC BAD ON OVERFLOW.
5922 031434 000401 BR 9$
5923 031436 104205 ERROR +205 :ST 520 TO 162 INTO 163 (BUT FD).
5924 031440 9$:

```

```

5925
5926 :OVERFLOW TEST WITH EXPONENT OF THE RESULT = 130, FIV = 0, FID = 1
5927 031440 NNN4:

```

```

031440 104413 LPERR :SET UP THE LOOP ON ERROR ADDRESS.
031442 004737 JSR PC,MODDOV
5928 031442 004737 031546 1$: .WORD 60200,0 :AC
5929 031446 060200 000000 .WORD 125252,0
5930 031452 125252 000000 2$: .WORD 60200,0,0,0 :FSRC
5931 031456 060200 000000 000000 3$: .WORD 0,0,0,0 :FRACTIONAL RES.
5932 031466 000000 000000 000000 4$: .WORD 0,0,0,0 :INTEGER RES.
5933 031476 000000 000000 000000 5$: .WORD 0,0,0,0 :ERROR FRACTIONAL RES.
5934 031506 000000 000000 000000 6$: .WORD 400,0 :ERROR INTEGER RES.
5935 031516 000400 000000 .WORD 125252,0
5936 031522 125252 000000 7$: 6211 :FPS BEFORE EXECUTION.
5937 031526 006211 .WORD 6206 :FPS AFTER EXECUTION.
5938 031530 006206 10 :FEC
5939 031532 000010 8$: NOP
5940 031534 000240 BR 9$
5941 031536 000401 ERROR +206 :ST 520 TO 162 INTO STORE ZERO TWICE.
5942 031540 104206 9$: JMP NNNDONE ;GO TO NEXT TEST.
5943 031542 000137 032154

```

```

5944 :THIS SUBROUTINE, MODDOV, IS CALLED TO SETUP THE
5945 :OPERANDS, EXECUTE THE MODD INSTRUCTION AND CHECK THE RESULTS.
5946 :IT IS CALLED THUS:
5947

```

```

5948 .....
5949 ACARG: .WORD X,X,X,X :AC OPERAND
5950 FSRCARG: .WORD X,X,X,X :FSRC OPERAND
5951 FRES: .WORD X,X,X,X :FRACTIONAL RESULT
5952 INTRES: .WORD X,X,X,X :INTEGER RESULT
5953 ERFRES: .WORD X,X,X,X :ERROR FRACTION RESULT
5954 ERINTRES: .WORD X,X,X,X :ERROR INTEGER RESULT
5955 FPSB: .WORD X :FPS BEFORE EXECUTION
5956 FPSA: .WORD X :FPS AFTER EXECUTION
5957 ERR1: ERROR +X :FRACTION ERROR
5958 BR CONT
5959 ERR2: ERROR +X :INTEGER ERROR
5960 CONT: :RETURN ADDRESS

```

```

5961 :THE OPERANDS ARE SET UP (USING ACO FOR THE AC ARGUMENT). THE MODD
5962 :INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
5963 :THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
5964 :THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
5965 :THEN THE FPS IS COMPARED WITH FPSA. AFTER EXECUTION IF NO ERRORS OCCURRED
5966 :THEN MODDOV WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
5967

```

```

5968 ;IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
5969 ;THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH
5970 ;THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED
5971 ;FAILURE MATCHES THE TRUE RESULT THEN MODDOV PASSES CONTROL TO THE
5972 ;ERROR CALL AT ERR1. LIKewise IF THE INTEGER PART OF THE RESULT IS
5973 ;NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER
5974 ;FAILURE. IF THIS DOESN'T MATCH THEN THE ERROR IS REPORTED HERE.
5975 ;IF A MATCH IS MADE HOWEVER, MODDOV WILL RETURN CONTROL TO THE ERROR
5976 ;CALL AT ERR2.
5977
5978 031546 012601 MODDOV: MOV (SP)+,R1 ;GET A POINTER TO THE ARGUMENTS
5979 031550 012700 000200 MOV #200,R0 ;SET FD MODE.
5980 031554 170100 LDFPS R0
5981 031556 010100 MOV R1,R0 ;SET UP ACO
5982 031560 172410 LDD (R0),ACO
5983 031562 012700 026062 MOV #MODP1,R0 ;PUT A BACKGROUND PATTERN INTO AC1.
5984 031566 172510 LDD (R0),AC1
5985 031570 016100 000060 MOV 60(R1),R0 ;SET UP THE FPS.
5986 031574 170100 LDFPS R0
5987 031576 012737 031612 001236 MOV #1$,STMP2
5988 031604 010100 MOV R1,R0 ;COMPUTE THE ADDRESS OF THE FSRC.
5989 031606 062700 000010 ADD #10,R0
5990
5991 031612 171410 1$: MODD (R0),ACO ;EXECUTE THE TEST INSTRUCTION.
5992
5993 031614 170305 STST R5 ;GET THE FPS.
5994 031616 170204 STFPS R4 ;GET THE FPS.
5995 031620 012700 000200 MOV #200,R0 ;SET FD MODE.
5996 031624 170100 LDFPS R0
5997 031626 012700 032134 MOV #MODDD0,R0 ;GET THE FRACTIONAL RESULT.
5998 031632 174010 STD ACO,(R0)
5999 031634 012700 032144 MOV #MODDD1,R0 ;GET THE INTEGER RESULT.
6000 031640 174110 STD AC1,(R0)
6001
6002 031642 010102 MOV R1,R2 ;SAVE THE DATA IN CASE OF ERROR.
6003 031644 010237 001240 MOV R2,$TMP3
6004 031650 062702 000010 ADD #10,R2
6005 031654 010237 001242 MOV R2,$TMP4
6006 031660 062702 000010 ADD #10,R2
6007 031664 010237 001244 MOV R2,$TMP5
6008 031670 062702 000010 ADD #10,R2
6009 031674 010237 001246 MOV R2,$TMP6
6010 031700 012737 032134 001250 MOV #MODDD0,$TMP7
6011 031706 012737 032144 001252 MOV #MODDD1,$TMP10
6012 031714 010437 001254 MOV R4,$TMP11
6013 031720 016137 000062 001256 MOV 62(R1),$TMP12
6014 031726 010537 001260 MOV R5,$TMP13
6015 031732 016137 000064 001262 MOV 64(R1),$TMP14
6016
6017 031740 012702 032134 MOV #MODDD0,R2 ;CHECK THE FRACTIONAL RESULT.
6018 031744 010103 MOV R1,R3
6019 031746 062703 000020 ADD #20,R3
6020 031752 012700 000004 MOV #4,R0
6021 031756 022223 2$: CMP (R2)+,(R3)+ ;BRANCH IF INCORRECT.
6022 031760 001023 BNE 10$
6023 031762 077003 SOB R0,2$
6024
    
```

6025	031764	012702	032144	MOV	#MODDD1,R2	;CHECK THE INTEGER RESULT.
6026	031770	010103		MOV	R1,R3	
6027	031772	062703	000030	ADD	#30,R3	
6028	031776	012700	000004	MOV	#4,R0	
6029	032002	022223		3\$: CMP	(R2)+,(R3)+	
6030	032004	001013		BNE	15\$;BRANCH IF INCORRECT.
6031	032006	077003		SOB	R0,3\$	


```

6033
6034
6035 032010 026104 000062          CMP    62(R1),R4      ;CHECK THE FPS.
6036 032014 001027          BNE    20$           ;BRANCH IF INCORRECT.
6037
6038 032016 026105 000064          CMP    64(R1),R5      ;CHECK THE FEC.
6039 032022 001033          BNE    25$
6040
6041 032024 000161 000074      9$:    JMP    74(R1)    ;RETURN.
6042
6043          ;FRACTIONAL ERROR.
6044 032030          10$:
6045 032030 104176          12$:    ERROR    +176    ;THE ERROR WAS NOT ANTICIPATED SO
6046 032032 000774          BR      9$           ;REPORT THE INCORRECT FRACTION HERE.
6047
6048          ;INTEGER ERROR.
6049 032034 012702 032144      15$:    MOV    #MODDD1,R2    ;WAS THE INTEGER ERROR ANTICIPATED?
6050 032040 010103          MOV    R1,R3
6051 032042 062703 000050          ADD    #50,R3
6052 032046 012705 000004          MOV    #4,R5
6053 032052 022223          60$:    CMP    (R2)+,(R3)+
6054 032054 001005          BNE    17$           ;BRANCH IF NOT ANTICIPATED.
6055 032056 077503          SOB    R5,60$
6056 032060 010102          MOV    R1,R2
6057 032062 062702 000072          ADD    #72,R2
6058          ;THE ERROR WAS ANTICIAPTED SO RETURN
6059 032066 000112          .JMP   (R2)         ;TO THE ERROR REPORT IN THE CALLING
6060          ;ROUTINE.
6061 032070          16$:
6062 032070 104267          17$:    ERROR    +267    ;THE ERROR WAS NOT ANTICIPATED SO REPORT
6063 032072 000754          BR      9$           ;THE INTEGER FAILURE HERE.
6064
6065          ;FPS INCORRECT.
6066 032074 010437 001254          20$:    MOV    R4,$TMP11    ;REPORT INCORRECT FPS.
6067 032100 016137 000062 001256          MOV    62(R1),$TMP12
6068 032106 104200          21$:    ERROR    +200
6069 032110 000745          BR      9$
6070
6071          ;REPORT FEC ERROR.
6072 032112 010537 001260          25$:    MOV    R5,$TMP13
6073 032116 016137 000064 001262          MOV    64(R1),$TMP14
6074 032124 010102          MOV    R1,R2
6075 032126 062702 000066          ADD    #66,R2
6076 032132 000112          JMP    (R2)
6077
6078 032134 000000 090000 000000      MODDD0: .WORD    0,0,0,0
6079
6080 032144 000000 000000 000000      MODDD1: .WORD    0,0,0,0
6081
6082 032154          NNWDONE:
        032154 104412          RSETUP
        ;GO INITIALIZE THE FPS AND STACK; AND
        ;SEE IF THE USER HAS EXPRESSED
        ;THE DESIRE TO CHANGE THE SOFTWARE
        ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
        ;THE USER TYPED CONTROL G?).
6083
6125
    
```

6126

```

.SBTTL TEST # 22 - INTERRUPT CORRECT FLOWS TEST
*****
*TEST 22          INTERRUPT CORRECT FLOWS TEST
*
*THIS IS A TEST OF THE 'CORRECT' FLOWS. THIS PART OF THE MICRO CODE
*HAS AS ITS PURPOSE INSURING THAT INTERRUPT REQUESTS MADE DURING
*CERTAIN LENGTHY FPP INSTRUCTIONS GET HONORED. THIS IS DONE
*IN A WAY SUCH THAT IF AN INTERRUPT REQUEST OCCURS DURING ONE
*OF THESE INSTRUCTIONS THE STATE OF THAT INSTRUCTION'S
*EXECUTION WILL BE THE SAME AS IF THAT INSTRUCTION HAD NEVER
*BEEN FETCHED AND ITS EXECUTION NEVER STARTED. THUS THE MICRO CODE
*WILL RESTORE ALL REGISTERS, BACK UP THE PC AND LEAVE THE
*FPS AND ACO THROUGH AC5 UNMODIFIED.
*THE INSTRUCTIONS FOR WHICH THIS IS NECESSARY ARE:
*
*   ADD (OR SUB)
*   DIV
*   MUL
*   MOD
*(BOTH DOUBLE AND FLOATING)
*ALL ADDRESSING MODES WILL BE TRIED WITH THE ADDD INSTRUCTION. THEN
*EACH OF THE OTHER INSTRUCTIONS WILL BE TRIED USING MODE 1
*NOTE THAT THIS TEST NEEDS A SPECIAL INTERRUPT MODULE,
*WHICH WILL PROBABLY ONLY BE PRESENT IN DEC'S MANUFACTURING ENVIRONMENT,
*TO RUN. THIS SPECIAL EQUIPMENT IS DESIGNED TO RAISE AN
*INTERRUPT REQUEST IN THE PROCESSOR IF A BIT IS SET IN ITS STATUS
*REGISTER AND ONLY WHEN AN FPP INSTRUCTION IS ENCOUNTERED.
*THEREFORE THIS TEST WILL BE RUN CONDITIONALLY (DEPENDENT UPON WHETHER
*OR NOT THE STATUS REGISTER OF THE TEST EQUIPMENT TIMES OUT WHEN REFERENCED).
*THIS TEST CAN ALSO BE DESELECTED BY TURNING SWITCH 7 OF THE
*SWITCH REGISTER (PHYSICAL OR VIRTUAL) ON.
*THE TEST ASSUMES THAT THE TEST EQUIPMENT'S STATUS REGISTER IS AT
*LOCATION 777774 (NOTE THAT ALL REFERENCES TO THIS LOCATION ARE
*MADE INDIRECT THROUGH THIS PROGRAMS LOCATION CORINT, SO THAT
*IF THE USER HAS MODIFIED THE TEST EQUIPMENT'S STATUS REGISTER TO
*RESPOND TO A DIFFERENT ADDRESS LOCATION CORINT MUST BE
*MADE TO CONTAIN THAT STATUS REGISTER'S NEW ADDRESS).
*THIS PROGRAM ASSUMES THAT THE TRAP VECTOR FOR THE TEST EQUIPMENT IS 110.
*AGAIN NOTE THAT ALL REFERENCES TO THIS TRAP VECTOR ARE INDIRECT, THROUGH
*THIS PROGRAM'S LOCATION CORTRP (IF THE TEST EQUIPMENT IS
*MADE TO TRAP TO A DIFFERENT VECTOR LOCATION CORTRP MUST CONTAIN THE
*ADDRESS OF THIS VECTOR).
*
*****

```

```

032156 00J004
6127
6128 032160 132737 000200 001337
6129 032166 001406
6130 032170 032777 000200 146742
6131
6132 032176 001022
6133 032200 000137 033336
6134
6135 032204 012737 032230 000004
6136 032212 012777 000000 001112
6137 032220 012737 037502 000004
6138 032226 000406
6139

```

```

TST22: SCOPE
        BITB   #200,$ENVM      ;SEE IF APT IS SELECTING TEST.
        BEQ    COR1           ;BRANCH TO AUTOSIZE IF NOT.
        BIT    #200,@SWR      ;SEE IF THE USER HAS SELECTED THIS
                               ;TEST USING THE SWITCH REGISTER.
        BNE    COR3           ;IF SO, PERFORM TEST.
        JMP    CORDONE ;ELSE DO NOT RUN TEST.

COR1:   MOV    #COR2,ERRVECT  ;SEE IF THE TEST EQUIPMENT'S STATUS
        MOV    #0,@CORINT    ;REGISTER TIMES OUT.
        MOV    #CPSPUR,ERRVECT
        BR     COR3          ;DIDN'T TIME OUT SO START TEST.

```

```

6140 032230 022626          COR2:  CMP      (SP)+,(SP)+      ;IF THE REFERENCE TIMES OUT DO
6141 032232 012737 037502 000004      MOV      #CPSPUR,ERRVECT
6142 032240 000137 033336          JMP      CORDONE ;NOT RUN TEST.
6143
6144          ;TEST ADDD MODE 0
6145 032244          COR3:
6146 032244 005227 177777          INC      #-1
6147 032250 001002          BNE     COR33
6148 032252 104401          TYPE
6149 032254 040455          .WORD   CORMES
6150 032256          COR33:
6151 032256 104413          LPERR           ;SET UP THE LOOP ON ERROR ADDRESS.
6152 032260 004737 033036          JSR      PC,CORSUB
6153 032264 040200 000100 000200 1$:  .WORD   40200,100,200,300      ;ACO
6154 032274 123456          2$:  .WORD   123456              ;RO
6155 032276 000200          3$:  200                  ;FPS
6156 032300 172000          4$:  ADDD   ACO,ACO          ;TEST INSTRUCTION.
6157 032302 000240          NOP
6158 032304 005037 033320          CLR     CORFLG ;RESET INTERRUPT FLAG
6159 032310 104252          ERROR  +252      ;NO INTERRUPT! TEST EQUIPMENT FAILED.
6160 032312 000401          BR      11$
6161 032314 104253          5$:  ERROR  +253      ;INCORRECT STATE AT INTERRUPT.
6162 032316
6163          ;TEST ADDD MODE 1
6164 032316          COR4:
6165 032316 104413          LPERR           ;SET UP THE LOOP ON ERROR ADDRESS.
6166 032320 004737 033036          JSR      PC,CORSUB
6167 032324 040201 000555 077007 1$:  .WORD   40201,555,77007,111111 ;ACO
6168 032334 032324          2$:  .WORD   1$              ;RO
6169 032336 000217          3$:  217                  ;FPS
6170 032340 172010          4$:  ADDD   (RO),ACO        ;TEST INSTRUCTION
6171 032342 000240          NOP
6172 032344 005037 033320          CLR     CORFLG ;RESET INTERRUPT FLAG
6173 032350 104252          ERROR  +252      ;REPORT FAILURE. NO INTERRUPT.
6174 032352 000401          BR      11$
6175 032354 104254          ERROR  +254
6176
6177          ;TEST ADDD MODE 2
6178 032356          COR5:
6179 032356 104413          LPERR           ;SET UP THE LOOP ON ERROR ADDRESS.
6180 032360 004737 033036          JSR      PC,CORSUB
6181 032364 040202 111333 052525 1$:  .WORD   40202,111333,52525,70707 ;ACO
6182 032374 032364          2$:  .WORD   1$              ;RO
6183 032376 000205          3$:  205                  ;FPS
6184 032400 172020          4$:  ADDD   (RO)+,ACO      ;TEST INSTRUCTION
6185 032402 000240          NOP
6186 032404 005037 033320          CLR     CORFLG ;RESET THE INTERRUPT FLAG
6187 032410 104252          ERROR  +252      ;REPORT FAILURE. NO INTERRUPT.
6188 032412 000401          BR      11$
6189 032414 104255          ERROR  +255      ;CORRECT FLOWS FAILED.
6190
6191          ;TEST ADDD MODE 3
6192 032416          COR6:
6193 032416 104413          LPERR           ;SET UP THE LOOP ON ERROR ADDRESS.
6193 032420 004737 033036          JSR      PC,CORSUB
    
```

```

6194 032424 040203 071735 072746 1$: .WORD 40203,71735,72746,1 ;ACO
6195 032434 032460 2$: .WORD 10$ ;RO
6196 032436 000206 3$: 206 ;FPS
6197 032440 172030 4$: ADD @ (RO)+,ACO ;TEST INSTRUCTION
6198 032442 060240 NOP
6199 032444 005037 033320 CLR CORFLG ;RESET THE INTERRUPT FLAG
6200 032450 104252 ERROR +252 ;REPORT FAILURE, NO INTERRUPT.
6201 032452 000403 BR 11$
6202 032454 104256 5$: ERROR +256 ;CORRECT FLOWS FAILED.
6203 032456 000401 BR 11$
6204 032460 032424 10$: .WORD 1$ ;USED FOR THE ADDRESSING OF THE OPERAND
6205 ;IN THIS MODE.
6206 032462 11$:
6207 ;TEST ADDD MODE 4
6208 032462 COR7:
        LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
6209 032464 104413 JSR PC,CORSUB
6210 032470 004737 033036 123456 070123 1$: .WORD 40204,123456,70123,45671 ;ACO
6211 032500 032500 2$: .WORD 1$+10 ;RO
6212 032502 000212 3$: 212 ;FPS
6213 032504 172040 4$: ADD -(RO),ACO ;TEST INSTRUCTION
6214 032506 000240 NOP
6215 032510 005037 033320 CLR CORFLG ;RESET THE INTERRUPT FLAG
6216 032514 104252 ERROR +252 ;REPORT FAILURE, NO INTERRUPT.
6217 032516 000401 BR 11$
6218 032520 104257 ERROR +257 ;CORRECT FLOWS FAILED
6219 032522 11$:
6220 ;TEST ADDD MODE 5
6221 COR8:
        LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
6222 032522 104413 JSR PC,CORSUB
6223 032524 004737 033036 1$: .WORD 40205,76543,21076,54321 ;ACO
6224 032530 040205 076543 021076 2$: .WORD 10$+2 ;RO
6225 032540 032566 3$: 213 ;FPS
6226 032542 000213 4$: ADD @-(RO),ACO ;TEST INSTRUCTION
6227 032544 172050 NOP
6228 032546 000240 CLR CORFLG ;RESET THE INTERRUPT FLAG
6229 032550 005037 033320 ERROR +252 ;REPORT ERROR, NO INTERRUPT.
6230 032554 104252 BR 11$
6231 032556 000403 5$: ERROR +260 ;CORRECT FLOWS FAILED.
6232 032560 104260 BR 11$
6233 032562 000401 10$: .WORD 1$
6234 032564 032530 11$:
6235 032566 ;TEST ADDD MODE 6
6236 COR9:
        LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
6237 032566 104413 JSR PC,CORSUB
6238 032570 004737 033036 063730 1$: .WORD 40206,34353,63730,31323 ;ACO
6239 032574 040206 034353 2$: .WORD 1$-1 ;RO
6240 032604 032573 3$: 214 ;FPS
6241 032606 000214 4$: ADD 1 (RO),ACO ;TEST INSTRUCTION
6242 032610 172060 000001 CLR CORFLG
6243 032614 005037 033320 ERROR +252 ;REPORT FAILURE NO TRAP.
6244 032620 104252 BR 11$
6245 032622 000401 5$: ERROR +261
6246 032624 104261
    
```

```

6248 032626          11$:
6249
6250                ;TEST ADDD MODE 7
6251 032626          COR10:
        032626 104413          LPERR                ;SET UP THE LOOP ON ERROR ADDRESS.
        032630 004737 033036          JSR          PC,CORSUB
        032634 040210 070107 062426 1$: .WORD 40210,70107,62426,55555 ;ACO
        032644 032667          2$: .WORD 10$-1          ;RO
        032646 000204          3$: 204          ;FPS
        032650 172070 000001          4$: ADDD @1(RO),ACO ;TEST INSTRUCTION
        032654 005037 033320          CLR          CORFLG
        032660 104252          ERROR +252          ;REPORT FAILURE NO TRAP
        032662 000403          11$
        032664 104262          5$: ERROR +262          ;CORRECT FLOWS FAILED.
        032666 000401          BR          11$
        032670 032634          10$: .WORD 1$
        032672          11$:

6264
6265                ;TEST DIVD MODE 1
6266 032672          COR11:
        032672 104413          LPERR                ;SET UP THE LOOP ON ERROR ADDRESS.
        032674 004737 033036          JSR          PC,CORSUB
        032700 040211 033445 056677 1$: .WORD 40211,33445,56677,001122 ;ACO
        032710 032700          2$: .WORD 1$          ;RO
        032712 000205          3$: 205          ;FPS
        032714 174410          4$: DIVD (RO),ACO ;TEST INSTRUCTION
        032716 000240          NOP
        032720 005037 033320          CLR          CORFLG
        032724 104252          ERROR +252          ;REPORT FAILURE, NO TRAP.
        032726 000401          BR          11$
        032730 104263          5$: ERROR +263          ;CORRECT FLOWS FAILED.
        032732          11$:

6278
6279                ;TEST MULD MODE 1
6280 032732          COR12:
        032732 104413          LPERR                ;SET UP THE LOOP ON ERROR ADDRESS.
        032734 004737 033036          JSR          PC,CORSUB
        032740 040212 165411 046252 1$: .WORD 40212,165411,46252,63650 ;ACO
        032750 032740          2$: .WORD 1$          ;RO
        032752 000210          3$: .WORD 210          ;FPS
        032754 171010          4$: MULD (RO),ACO ;TEST INSTRUCTION
        032756 000240          NOP
        032760 005037 033320          CLR          CORFLG
        032764 104252          ERROR +252          ;REPORT FAILURE, NO TRAP.
        032766 000401          BR          11$
        032770 104264          5$: ERROR +264          ;CORRECT FLOWS FAILED.
        032772          11$:

6292
6293                ;TEST MODD MODE 1
6294 032772          COR13:
        032772 104413          LPERR                ;SET UP THE LOOP ON ERROR ADDRESS.
        032774 004737 033036          JSR          PC,CORSUB
        033000 040213 045654 054542 1$: .WORD 40213,45654,54542,171623 ;ACO
        033010 033000          2$: .WORD 1$          ;RO
        033012 000412          3$: .WORD 412          ;FPS
        033014 171410          4$: MODD (RO),ACO ;TEST INSTRUCTION.
        033016 000240          NOP
    
```

6301 033020 005037 033320
 6302 033024 104252
 6303 033026 000401
 6304 033030 104265
 6305 033032 000137 033336
 6306
 6307
 6308
 6309
 6310
 6311
 6312
 6313
 6314
 6315
 6316
 6317
 6318
 6319
 6320
 6321
 6322
 6323
 6324
 6325
 6326
 6327
 6328
 6329
 6330
 6331
 6332
 6333
 6334
 6335
 6336 033036 005037 033320
 6337
 6338 033042 012601
 6339 033044 010102
 6340 033046 012700 000200
 6341 033052 170100
 6342 033054 172412
 6343 033056 016100 000012
 6344 033062 170100
 6345 033064 016100 000010
 6346 033070 010102
 6347 033072 062702 000014
 6348 033076 010237 001236
 6349
 6350 033102 005037 177776
 6351 033106 012777 033134 000220
 6352 033114 012737 177777 033320
 6353
 6354 033122 012777 177777 000202
 6355
 6356 033130 000161 000014
 6357

```

CLR      CORFLG      ;REPORT FAILURE NO TRAP.
ERROR    +252
BR       11$
5$:      ERROR    +265      ;CORRECT FLOWS FAILED.
11$:     JMP      CORDONE ;FINISHED TEST!

;THIS SUBROUTINE, CORSUB, IS CALLED TO SET UP THE OPERANDS
;AND CHECK THE RESULTS IN THIS TEST. IT IS CALLED THUS:

          JSR      PC,CORSUB
1$:      .WORD    X,X,X,X      ;ACO OPERAND
2$:      .WORD    X           ;RO
3$:      .WORD    X           ;FPS
4$:      INST          ;TEST INSTRUCTION TO BE
                          ;EXECUTED.
          ADR          ;AN ADDRESS OFFSET FOR
                          ;CERTAIN MODES OR NOP.
                          ;NO TRAP ERROR.
5$:      ERROR    +252
BR       11$
5$:      ERROR    +N          ;CORRECT FLOWS FAILURE.
BR       11$                ;OPTIONAL FOR CERTAIN MODES.
10$:     .WORD    ADDRESS     ;OPTIONAL FOR CERTAIN MODES.
11$:

;CORSUB WILL PICK UP A POINTER TO THE ARGUMENTS, IN R1, ACO, RO AND
;THE FPS WILL BE SET TO THE DESIGNATED VALUES. THEN THE TEST MODULE
;WILL BE SET UP TO INTERRUPT AND THE INSTRUCTION AT 4$ EXECUTED. IF
;NO TRAP OCCURS THEN THE TEST MODULE IS FAULTY. WHEN THE TRAP OCCURS
;THE PC ON THE STACK SHOULD BE 4$, AND ACO, RO AND THE FPS SHOULD NOT
;HAVE BEEN MODIFIED. IF EVERYTHING IS CORRECT CORSUB WILL RETURN TO
;5$ PLUS TWO. IF AN ERROR IS DETECTED THEN CORSUB WILL RETURN TO THE
;ERROR REPORT AT 5$.
;NOTE THAT A FLAG, CORFLG, IS SET TO -1 WHEN AN INTERRUPT IS PENDING.
;CORFLG IS ZERO OTHERWISE.

CORSUB:  CLR      CORFLG      ;SET FLAG TO INDICATE NO INTERRUPT
                          ;PENDING.
          MOV      (SP)+,R1    ;GET A POINTER TO THE ARGUMENTS.
          MOV      R1,R2      ;SET ACO.
          MOV      #200,R0
          LDFPS   R0
          LDD     (R2),ACO
          MOV     12(R1),R0    ;SET UP THE FPS.
          LDFPS   R0
          MOV     10(R1),R0    ;SET UP RO.
          MOV     R1,R2
          ADD     #14,R2
          MOV     R2,$TMP2    ;SAVE ADDRESS OF INSTRUCTION IN CASE
                          ;OF ERROR.
          CLR     PSW         ;CLEAR THE PRIORITY TO ALLOW INTERRUPTS.
          MOV     #CORTV,@CORTP ;SET UP THE INTERRUPT VECTOR.
          MOV     #-1,CORFLG  ;SET THE FLAG TO INDICATE
                          ;AN INTERRUPT IS PENDING.
          MOV     #-1,@CORINT ;ENABLE THE TEST EQUIPMENT'S
                          ;TRAP FUNCTION AND GO
          JMP     14(R1)      ;EXECUTE THE INSTRUCTION.
    
```


6415
 6416
 6417
 6418 033336 104412
 033336

CORDONE:
 RSETUP

:CONTENTS OF CORTRP MUST INDICATE THE
 :CHANGE.

:GO INITIALIZE THE FPS AND STACK; AND
 :SEE IF THE USER HAS EXPRESSED
 :THE DESIRE TO CHANGE THE SOFTWARE
 :VIRTUAL CONSOLE SWITCH REGISTER (HAS
 :THE USER TYPED CONTROL G?).

6419
 6420
 6421
 6422 033340
 6423
 6424
 6425
 6426

TST23:

.SBITL END OF PASS ROUTINE

::*****
 :*INCREMENT THE PASS NUMBER (\$PASS)
 :*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
 :*IF SW12=1 INHIBIT TRACE TRAP
 :*IF THERES A MONITOR GO TO IT
 :*IF THERE ISN'T JUMP TO LOOP
 \$EOP:

033340
 033340 000004
 033342 005037 001102
 033346 005037 001302
 033352 005237 001324
 033356 100004
 033360 005037 001324
 033364 005237 034106
 033370 005327
 033372 000001
 033374 003402
 033376 000137 034034
 033402 012737
 033404 000001
 033406 033372
 033410 005737 001112
 033414 001007
 033416 005737 034104
 033422 001120
 033424 032737 001777 001324
 033432 001114
 033434
 033434 104401 033442
 033440 000407
 033460
 033460 005737 034106
 033464 001440
 033466 013746 034106
 033472 104403
 033474 006
 033475 000

SCOPE
 CLR \$STNM ;:ZERO THE TEST NUMBER
 CLR \$TIMES ;:ZERO THE NUMBER OF ITERATIONS
 INC \$PASS ;:INCREMENT THE PASS NUMBER
 BPL 1000\$;BRANCH IF STILL PLUS ;DPM002
 CLR \$PASS ;CLEAR THE PASS COUNTER ;DPM002
 INC \$PASS2 ;INCREMENT OVERFLOW PASS COUNTER ;DPM002
 1000\$: DEC (PC)+ ;:LOOP?
 \$EOPCT: .WORD 1
 BLE 999\$;:NO ;DPM002
 JMP \$DOAGN ;:YES
 999\$: MOV (PC)+,2(PC)+ ;:RESTORE COUNTER
 \$ENDCT: .WORD 1
 \$EOPCT
 TST \$ERTTL ;:SEE IF ANY ERRORS THIS PASS ;DPM002
 BNE 5000\$;BRANCH IF SO TO PRINT THE EOP ;DPM002
 TST \$PENDS ;:SEE IF EOP MSGS ARE DISABLED ;DPM002
 BNE \$GET42 ;BRANCH IF SO ;DPM002
 BIT #1777,\$PASS ;PRINT EOP EVERY 2000TH PASS ;DPM002
 BNE \$GET42 ;BRANCH IF NOT MULTIPLE OF 1000 ;DPM002
 5000\$: TYPE ,65\$;:TYPE ASCIZ STRING
 BR ,64\$;:GET OVER THE ASCIZ
 ;:65\$: .ASCIZ <12><15>/END PASS # /
 ;:64\$:
 TST \$PASS2 ;:SEE IF OVERFLOW HAS NON-ZERO VALUE ;DPM002
 BEQ 4900\$;BRANCH IF ZERO ;DPM002
 MOV \$PASS2,-(SP) ;:SAVE \$PASS2 FOR TYPEOUT
 ;:TYPE OVERFLOW PASS NUMBER IN OCTAL ;DPM002
 TYPOS
 ;:GO TYPE--OCTAL ASCII
 .BYTE 6 ;:TYPE 6 DIGITS
 .BYTE 0 ;:SUPPRESS LEADING ZEROS


```

033476 005737 001324      TST      $PASS      ;SEE IF PASS COUNT IS ZERO      ;DPM002
033502 001007              BNE      3000$      ;BRANCH IF NOT                  ;DPM002
033504 104401 033512      TYPE    ,67$      ;:TYPE ASCIZ STRING
033510 000403              BR       66$      ;:GET OVER THE ASCIZ
      ;:67$: .ASCIZ  !00000!
033520              ;:66$:
033520 000426              BR       4910$     ;GO TEST $ERTTL                  ;DPM002
033522 012737 070000 001244 5000$: MOV     #70000,$TMP5 ;CHECK 5TH OCTAL DIGIT FIRST     ;DPM002
033530 033737 001244 001324 4000$: BIT     $TMP5,$PASS ;CHECK TO SEE IF OCTAL DIGIT IS ZERO ;DPM002
033536 001013              BNE     4900$     ;BRANCH OUT IF ZERO             ;DPM002
033540 104401 033546      TYPE    ,69$      ;:TYPE ASCIZ STRING
033544 000401              BR       68$      ;:GET OVER THE ASCIZ
      ;:69$: .ASCIZ  !0!
033550              ;:68$:
033550 006237 001244      ASR     $TMP5     ;SHIFT THE THREE BITS RIGHT 3 PLACES ;DPM002
033554 006237 001244      ASR     $TMP5     ;:
033560 006237 001244      ASR     $TMP5     ;:
033564 000761              BR       4000$     ;BRANCH BACK TO CHECK $PASS     ;DPM002
033566 013746 001324      MOV     $PASS,-(SP) ;:SAVE $PASS FOR TYPEOUT
      ;:TYPE PASS NUMBER IN OCTAL
033572 104403              TYPOS
033574 006              .BYTE  6          ;:GO TYPE--OCTAL ASCII
033575 000              .BYTE  0          ;:TYPE 6 DIGITS
033576 005737 001112      4910$: TST     $ERTTL ;SUPPRESS LEADING ZEROS
033602 001426              BEQ     5001$     ;SEE IF ANY ERRORS THIS PASS     ;DPM002
033604 104401 033612      TYPE    ,71$      ;BRANCH AROUND REPORT IF NONE    ;DPM002
033610 000415              BR       70$      ;:TYPE ASCIZ STRING
      ;:71$: .ASCIZ  / TOTAL ERRORS THIS PASS /
033644              ;:70$:
033644 013746 001112      MOV     $ERTTL,-(SP) ;:SAVE $ERTTL FOR TYPEOUT
      ;:TOTAL NUMBER OF ERRORS IN OCTAL
033650 104403              TYPOS
033652 006              .BYTE  6          ;:GO TYPE--OCTAL ASCII
033653 000              .BYTE  0          ;:TYPE 6 DIGITS
033654 005037 001112      CLR     $ERTTL   ;SUPPRESS LEADING ZEROS
033660 104401 001313      5001$: TYPE    ,$CRLF ;CLEAR ERROR TOTAL
033664 105777 145254      $GET42: TSTB    @$TKS ;TYPE CARRIAGE RETURN, LINE FEED
033670 100042              BPL     $GT42C   ;IS A CHARACTER WAITING?        ;DPM002
033672 013737 001146 001244  MOV     $TKB,$TMP5 ;BRANCH IF NOT                   ;DPM002
033700 005737 034104      TST     EPENDS   ;WASTE THE CHARACTER, CLEARING READY ;DPM002
033704 001017              BNE     $DISAB   ;SEE WHICH STATE ENABLE/DISABLE IS IN ;DPM002
033706 005237 034104      INC     EPENDS   ;BRANCH IF EOP'S DISABLED       ;DPM002
033712 104401 033720      TYPE    ,65$      ;SET FLAG DISABLING PRINTOUTS   ;DPM002
033716 000411              BR       64$      ;:TYPE ASCIZ STRING
      ;:65$: .ASCIZ  <CRLF>!EOP'S DISABLED!<CRLF>
033742              ;:64$:
033742 000415              BR       $GT42C   ;BRANCH OVER ENABLE ROUTINE     ;DPM002
033744 005037 034104      $DISAB: CLR     EPENDS ;CLEAR FLAG ENABLING PRINTOUTS   ;DPM002
033750 104401 033756      TYPE    ,65$      ;:TYPE ASCIZ STRING
033754 000410              BR       64$      ;:GET OVER THE ASCIZ
      ;:65$: .ASCIZ  <CRLF>!EOP'S ENABLED!<CRLF>
033776              ;:64$:
033776 013700 000042      $GT42C: MOV     @#42,R0 ;GET MONITOR ADDRESS
034002 001414              BEQ     $DOAGN   ;BRANCH IF NO MONITOR
034004 005046              CLR     -(SP)    ;INSURE THE 'T' BIT IS CLEAR
034006 012746 034014      MOV     #$CLR.T,-(SP) ;SETUP FOR AN RTI OR RTT

```

```

034012 000426          BR      $RTRN          ;;GO DO AN RTI OR RTT TO LOAD THE PSW
                                           ;;WITH A CLEARED 'T' BIT
034014 013700 000042  $CLR.T:  MOV      @#42,R0          ;;INSURE R0 CONTAINS THE MONITORS
034014 001405          BEQ      $DOAGN          ;;RETURN ADDRESS
034022 000005          RESET          ;;CLEAR THE WORLD
034024 004710          SENDAD: JSR     PC,(R0)        ;;GO TO MONITOR
034026 000240          NOP          ;;SAVE ROOM
034030 000240          NOP          ;;FOR
034032 000240          NOP          ;;ACT11
034034 104400          $DOAGN: TRAP          ;;PUSH OLD PSW AND PC ON STACK
034036 042716 000020  BIC      #20,(SP)        ;;CLEAR THE 'T' BIT
034042 032777 010000 145070  BIT      #BIT12,@SWR        ;;RUN WITH TRACE TRAP?
034050 001005          BNE      1$          ;;BR IF NO
034052 005137 034076  COM      $TBIT          ;;IS IT TIME FOR TRACE TRAP
034056 100402          BMI      1$          ;;BR IF NO
034060 052716 000020  BIS      #20,(SP)        ;;SET TRACE TRAP
034064 012746 034072  1$:      MOV      #SLOOP,-(SP)      ;;JUMP TO START OF TEST
034070 000002          $RTRN: RTI          ;;RETURN--THIS IS CHANGED TO
                                           ;;AN 'RTT' IF 'RTT' IS A LEGAL
                                           ;;INSTRUCTION

034072 000137          $LOOP:  JMP      @(PC)+          ;;RETURN
034074 005214          $RTNAD: .WORD    LOOP
034076 000000          $TBIT:  .WORD    0          ;;'T' BIT STATE INDICATOR
034100 377 377 000  $ENULL:  .BYTE   -1,-1,0        ;;NULL CHARACTER STRING
                                           .EVEN
034104 000000          EPENDS: .WORD    0          ;LOCATION FOR EOP PRINT FLAG ;DPM002
034106 000000          $PASS2: .WORD    0          ;LOCATION FOR PASS COUNT OVERFLOW ;DPM002

```

6427
6428

.SBTTL SCOPE HANDLER ROUTINE

```

;*****
;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;SW14=1      LOOP ON TEST
;SW11=1      INHIBIT ITERATIONS
;SW09=1      LOOP ON ERROR
;SW08=1      LOOP ON TEST IN SWR<7:0>
;CALL
;SCOPE      ;;SCOPE=IOT

```

```

034110 104406          $SCOPE:  CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
034110 032777 040000 145020  1$:      BIT      #BIT14,@SWR        ;;LOOP ON PRESENT TEST?
034112 001131          BNE      $OVER          ;;YES IF SW14=1
034122 000416          ;#####START OF CODE FOR THE XOR TESTER#####
          $XTSTR: BR      6$          ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
                                           ;;THIS INSTRUCTION TO A 'NOP' (NOP=240)
034124 013746 000004          MOV      @#ERRVEC,-(SP)      ;;SAVE THE CONTENTS OF THE ERROR VECTOR
034130 012737 034150 000004  MOV      #5$,@#ERRVEC          ;;SET FOR TIMEOUT
034136 005737 177060          TST      @#177060          ;;TIME OUT ON XOR?
034142 012637 000004          MOV      (SP)+,@#ERRVEC      ;;RESTORE THE ERROR VECTOR
034146 000500          BR      $$VLAD          ;;GO TO THE NEXT TEST

```

```

034150 022626          5$:    CMP      (SP)+,(SP)+      ;;CLEAR THE STACK AFTER A TIME OUT
034152 012637 000004    MOV      (SP)+,@#ERRVEC  ;;RESTORE THE ERROR VECTOR
034156 000440          BR       7$              ;;LOOP ON THE PRESENT TEST
034160 032777 000400 144752 6$:;#####END OF CODE FOR THE XOR TESTER#####
034166 001404          BIT      #BIT08,@SWR    ;;LOOP ON SPEC. TEST?
034170 127737 144744 001102    BEQ      2$              ;;BR IF NO
034176 001502          CMPB    @SWR,$STNM      ;;ON THE RIGHT TEST?   SWR<7:0>
034200 013737 177766 034422 2$:    MOV      177766,CPSAVE  ;;MOVE CPU ERR REG VALUE TO LOC FOR TST ;DPM001
034206 032737 000001 034422    BIT      #BIT00,CPSAVE  ;;SEE IF THE POWER MONITOR BIT IS ON  ;DPM001
034214 001406          BEQ      2000$          ;;BRANCH TO CONTINUE ROUTINE IF CLEAR ;DPM001
034216 042737 000001 177766    BIC      #BIT00,177766  ;;CLEAR THE BIT FOUND TO BE SET      ;DPM001
034224 104177          EMT      +177          ;;CALL SPECIAL POWER FAIL BIT ERROR CALL ;DPM001
034226 105037 001103          CLRB    $ERFLG        ;;CLEAR THE ERROR FLAG FOR NEXT TEST  ;DPM001
034232 105737 001103          2000$: TSTB    $ERFLG        ;;WAS THERE AN ERROR?
034236 001421          BEQ      3$              ;;BR IF NO
034240 123737 001115 001103    CMPB    $ERMAX,$ERFLG  ;;MAX. ERRORS FOR THIS TEST OCCURRED?
034246 101015          BHI      3$              ;;BR IF NO
034250 032777 001000 144662    BIT      #BIT09,@SWR    ;;LOOP ON ERROR?
034256 001404          BEQ      4$              ;;BR IF NO
034260 013737 001110 001106 7$:    MOV      $LPERR,$LPADR  ;;SET LOOP ADDRESS TO LAST SCOPE
034266 000446          BR       $OVER         ;;
034270 105037 001103          4$:    CLRB    $ERFLG        ;;ZERO THE ERROR FLAG
034274 005037 001302          CLR     $TIMES        ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
034300 000415          BR       1$              ;;ESCAPE TO THE NEXT TEST
034302 032777 004000 144630 3$:    BIT      #BIT11,@SWR    ;;INHIBIT ITERATIONS?
034310 001011          BNE     1$              ;;BR IF YES
034312 005737 001324          TST     $PASS        ;;IF FIRST PASS OF PROGRAM
034316 001406          BEQ     1$              ;;      INHIBIT ITERATIONS
034320 005237 001104          INC     $ICNT        ;;INCREMENT ITERATION COUNT
034324 023737 001302 001104    CMP     $TIMES,$ICNT   ;;CHECK THE NUMBER OF ITERATIONS MADE
034332 002024          BGE     $OVER         ;;BR IF MORE ITERATION REQUIRED
034334 012737 000001 001104 1$:    MOV     #1,$ICNT      ;;REINITIALIZE THE ITERATION COUNTER
034342 013737 034420 001302    MOV     $MXCNT,$TIMES  ;;SET NUMBER OF ITERATIONS TO DO
034350 105237 001102          $SVLAD: INCB    $STNM      ;;COUNT TEST NUMBERS
034354 113737 001102 001322    MOVB   $STNM,$STESTN  ;;SET TEST NUMBER IN APT MAILBOX
034362 011637 001106          MOV     (SP),$LPADR    ;;SAVE SCOPE LOOP ADDRESS
034366 011637 001110          MOV     (SP),$LPERR    ;;SAVE ERROR LOOP ADDRESS
034372 005037 001304          CLR     $ESCAPE      ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
034376 112737 000001 001115    MOVB   #1,$ERMAX      ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
034404 013777 001102 144530 $OVER: MOV     $STNM,@DISPLAY ;;DISPLAY TEST NUMBER
034412 013716 001106          MOV     $LPADR,(SP)   ;;FUDGE RETURN ADDRESS
034416 000002          RTI                    ;;FIXES PS
034420 000001          $MXCNT: 1              ;;MAX. NUMBER OF ITERATIONS
034422 000000          CPSAVE: .WORD 0      ;;LOCATION TO SAVE CPU ERR REG CONTENTS ;DPM001

```

6429
6430

.SBTTL ERROR HANDLER ROUTINE

```

;*****
;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
;*AND GO TO ERTYPE ON ERROR
;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;*SW15=1      HALT ON ERROR
;*SW13=1      INHIBIT ERROR TYPEOUTS
;*SW10=1      BELL ON ERROR
;*SW09=1      LOOP ON ERROR

```

```

      ;*CALL
      ;*
      IBSAVE: .WORD 0          ;:LOC'N TO HOLD $ERRPC DURING DUAL ERR ;DPM001
      $ERROR:
      CKSWR          ;:TEST FOR CHANGE IN SOFT-SWR
      7$: INCB $ERFLG          ;:SET THE ERROR FLAG
      BEQ 7$         ;:DON'T LET THE FLAG GO TO ZERO
      MOV $STNM,@DISPLAY ;:DISPLAY TEST NUMBER AND ERROR FLAG
      BIT #BIT10,@SWR ;:BELL ON ERROR?
      BEQ 1$         ;:NO - SKIP
      TYPE $BELL      ;:RING BELL
      1$: INC $ERTL      ;:COLNT THE NUMBER OF ERRORS
      MOV (SP),$ERRPC ;:GET ADDRESS OF ERROR INSTRUCTION
      SUB #2,$ERRPC
      MOVB @ERRPC,$ITEMB ;:STRIP AND SAVE THE ERROR ITEM CODE
      CMPB #177,$ITEMB ;:SEE IF THIS IS THE POWER FAIL CALL ;DPM001
      BEQ 1000$      ;:BRANCH AROUND ROUTINE IF IT IS ;DPM001
      MOV 177766,CPSAVE ;:MOVE CPU ERR REG TO CPSAVE FOR TEST ;DPM001
      BIT #BIT00,CPSAVE ;:SEE IF POWER MONITOR BIT IS SET ;DPM001
      BEQ 1000$      ;:BRANCH IF OK ;DPM001
      BIC #BIT00,177766 ;:CLEAR THE BIT FOUND SET ;DPM001
      MOV $ERRPC,IBSAVE ;:SAVE $ERRPC ;DPM001
      ERROR +177     ;:CALL SPECIAL POWER MON BIT ERROR ;DPM001
      MOV IBSAVE,$ERRPC ;:RESTORE $ERRPC
      1000$:
      BIT #BIT13,@SWR ;:SKIP TYPEOUT IF SET
      BNE 20$        ;:SKIP TYPEOUTS
      PC,ERTYPE      ;:GO TO USER ERROR ROUTINE
      ,SCRLF
      20$:
      CMPB #APTENV,$ENV ;:RUNNING IN APT MODE
      BNE 2$         ;:NO,SKIP APT ERROR REPORT
      MOVB $ITEMB,21$ ;:SET ITEM NUMBER AS ERROR NUMBER
      JSR PC,$ATY4   ;:REPORT FATAL ERROR TO APT
      21$: .BYTE 0
      .BYTE 0
      22$: BR 22$    ;:APT ERROR LOOP
      2$: TST IBSAVE ;:SEE IF POWER FAIL ERROR CALL ;DPM001
      BNE 3$         ;:BRANCH IF NOT - HALT NOT ALLOWED ;DPM001
      TST @SWR
      BPL 3$         ;:HALT ON ERROR
      HALT           ;:SKIP IF CONTINUE
      CKSWR          ;:HALT ON ERROR!
      3$: BIT #BIT09,@SWR ;:TEST FOR CHANGE IN SOFT-SWR
      BEQ 4$         ;:LOOP ON ERROR SWITCH SET?
      TST IBSAVE     ;:BR IF NO
      BNE 4$         ;:SEE IF THIS IS THE PWR MNTR BIT ERROR ;DPM001
      MOV $LPERR,(SP) ;:BRANCH IF SO - NO FUDGING ALLOWED ;DPM001
      4$: TST $ESCAPE ;:FUDGE RETURN FOR LOOPING
      BEQ 5$         ;:CHECK FOR AN ESCAPE ADDRESS
      TST IBSAVE     ;:BR IF NONE
      BNE 5$         ;:SEE IF THIS IS THE PWR MNTR BIT ERROR ;DPM001
      MOV $ESCAPE,(SP) ;:BRANCH IF SO - NO FUDGING ALLOWED ;DPM001
      ;:FUDGE RETURN ADDRESS FOR ESCAPE
      5$: CMP #SENDAD,42 ;:ACT-11 AUTO-ACCEPT?
      BNE 6$         ;:BRANCH IF NO
  
```

6431
6432

034716	000000		
034720			
034720	032777	001000	144212
034726	001013		
034730	011637	001162	
034734	062737	177776	001162
034742	122777	000377	144212
034750	001002		
034752	062716	000002	
034756	000002		

```

        HALT                ;;YES
6$:    BIT      #BIT09,@SWR
        BNE     ERM10
        MOV     (SP), $REGO      ;SEE IF ERROR #377
        ADD     #-2, $REGO
        CMPB   #377, @ $REGO
        BNE     ERM10
        ADD     #2, (SP)
ERM10: RTI

```

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES
:*****

```

;*SAVE R0-R5
;*CALL:
;*   SAVREG
;*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
;*
;*TOP---(+16)
;* +2---(+18)
;* +4---R5
;* +6---R4
;* +8---R3
;*+10---R2
;*+12---R1
;*+14---R0

```

034760			
034760	010046		
034762	010146		
034764	010246		
034766	010346		
034770	010446		
034772	010546		
034774	016646	000022	
035000	016646	000022	
035004	016646	000022	
035010	016646	000022	
035014	000002		

```

$SAVREG:
        MOV     R0, -(SP)      ;;PUSH R0 ON STACK
        MOV     R1, -(SP)      ;;PUSH R1 ON STACK
        MOV     R2, -(SP)      ;;PUSH R2 ON STACK
        MOV     R3, -(SP)      ;;PUSH R3 ON STACK
        MOV     R4, -(SP)      ;;PUSH R4 ON STACK
        MOV     R5, -(SP)      ;;PUSH R5 ON STACK
        MOV     22(SP), -(SP)   ;;SAVE PS OF MAIN FLOW
        MOV     22(SP), -(SP)   ;;SAVE PC OF MAIN FLOW
        MOV     22(SP), -(SP)   ;;SAVE PS OF CALL
        MOV     22(SP), -(SP)   ;;SAVE PC OF CALL
        RTI

```

```

;*RESTORE R0-R5
;*CALL:
;*   RESREG

```

035016			
035016	012666	000022	
035022	012666	000022	
035026	012666	000022	
035032	012666	000022	
035036	012605		
035040	012604		
035042	012603		
035044	012602		
035046	012601		
035050	012600		
035052	000002		

```

$RESREG:
        MOV     (SP)+, 22(SP)   ;;RESTORE PC OF CALL
        MOV     (SP)+, 22(SP)   ;;RESTORE PS OF CALL
        MOV     (SP)+, 22(SP)   ;;RESTORE PC OF MAIN FLOW
        MOV     (SP)+, 22(SP)   ;;RESTORE PS OF MAIN FLOW
        MOV     (SP)+, R5       ;;POP STACK INTO R5
        MOV     (SP)+, R4       ;;POP STACK INTO R4
        MOV     (SP)+, R3       ;;POP STACK INTO R3
        MOV     (SP)+, R2       ;;POP STACK INTO R2
        MOV     (SP)+, R1       ;;POP STACK INTO R1
        MOV     (SP)+, R0       ;;POP STACK INTO R0
        RTI

```

6433
6434

```

.SBTTL TYPE ROUTINE
:*****
;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.

```

```

: *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
: *NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
: *NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
: *NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
: *
: *CALL:
: *1) USING A TRAP INSTRUCTION
: *      TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
: *OR
: *      TYPE
: *      MESADR
: *
035054 105737 001157 $TYPE: TSTB $TPFLG      ;; IS THERE A TERMINAL?
035060 100002      BPL 1$      ;; BR IF YES
035062 000000      HALT      ;; HALT HERE IF NO TERMINAL
035064 000430      BR 3$      ;; LEAVE
035066 010046      1$: MOV RO,-(SP) ;; SAVE RO
035070 017600 000002 MOV @2(SP),RO ;; GET ADDRESS OF ASCIZ STRING
035074 122737 000001 001336 CMPB #APTENV,$ENV ;; RUNNING IN APT MODE
035102 001011      BNE 62$      ;; NO, GO CHECK FOR APT CONSOLE
035104 132737 000100 001337 BITB #APTPOOL,$ENVM ;; SPOOL MESSAGE TO APT
035112 001405      BEQ 62$      ;; NO, GO CHECK FOR CONSOLE
035114 010037 035124 MOV RO,61$      ;; SETUP MESSAGE ADDRESS FOR APT
035120 004737 035662 JSR PC,$ATY3    ;; SPOOL MESSAGE TO APT
035124 000000      61$: .WORD 0 ;; MESSAGE ADDRESS
035126 132737 000040 001337 62$: BITB #APTCSUP,$ENVM ;; APT CONSOLE SUPPRESSED
035134 001003      BNE 60$      ;; YES, SKIP TYPE OUT
035136 112046      2$: MOVB (RO)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
035140 001005      BNE 4$      ;; BR IF IT ISN'T THE TERMINATOR
035142 005726      TST (SP)+ ;; IF TERMINATOR POP IT OFF THE STACK
035144 012600      60$: MOV (SP)+,RO ;; RESTORE RO
035146 062716 000002 3$: ADD #2,(SP) ;; ADJUST RETURN PC
035152 000002      RTI      ;; RETURN
035154 122716 000011 4$: CMPB #HT,(SP) ;; BRANCH IF <HT>
035160 001430      BEQ 8$      ;; BRANCH IF NOT <CRLF>
035162 122716 000200 CMPB #CRLF,(SP)
035166 001006      BNE 5$      ;; POP <CR><LF> EQUIV
035170 005726      TST (SP)+ ;; TYPE A CR AND LF
035172 104401      TYPE
035174 001313 $CRLF
035176 105037 035414 CLRB $CHARCNT ;; CLEAR CHARACTER COUNT
035202 000755      BR 2$      ;; GET NEXT CHARACTER
035204 004737 035266 5$: JSR PC,$TYPEC ;; GO TYPE THIS CHARACTER
035210 123726 001156 6$: CMPB $FILLC,(SP)+ ;; IS IT TIME FOR FILLER CHARS.?
035214 001350      BNE 2$      ;; IF NO GO GET NEXT CHAR.
035216 013746 001154 MOV $NULL,-(SP) ;; GET # OF FILLER CHARS. NEEDED
;; AND THE NULL CHAR.
035222 105366 000001 7$: DECB 1(SP) ;; DOES A NULL NEED TO BE TYPED?
035226 002770      BLT 6$      ;; BR IF NO--GO POP THE NULL OFF OF STACK
035230 004737 035266 JSR PC,$TYPEC ;; GO TYPE A NULL
035234 105337 035414 DECB $CHARCNT ;; DO NOT COUNT AS A COUNT
035240 000770      BR 7$      ;; LOOP
: HORIZONTAL TAB PROCESSOR
035242 112716 000040 8$: MOVB #' ,(SP) ;; REPLACE TAB WITH SPACE
035246 004737 035266 9$: JSR PC,$TYPEC ;; TYPE A SPACE
035252 132737 000007 035414 BITB #7,$CHARCNT ;; BRANCH IF NOT AT
035260 001372      BNE 9$      ;; TAB STOP

```

```

035262 005726          TST      (SP)+      ;;POP SPACE OFF STACK
035264 000724          BR        2$          ;;GET NEXT CHARACTER
035266                    $TYPEC:
035266 105777 143652    TSTB     @STKS        ;;CHAR IN KYBD BUFFER?      :MJD001
035272 100022          BPL      10$          ;;BR IF NOT                :MJD001
035274 017746 143646    MOV      @STKB,-(SP)  ;;GET CHAR                  :MJD001
035300 042716 177600    RIC      #177600,(SP) ;;STRIP EXTRANEIOUS BITS   :MJD001
035304 122716 000023    CMPB     #SXOFF,(SP) ;;WAS CHAR XOFF            :MJD001
035310 001012          BNE      102$        ;;BR IF NOT                :MJD001
035312                    101$:
035312 105777 143626    TSTB     @STKS        ;;WAIT FOR CHAR            :MJD001
035316 100375          BPL      101$        ;;BR IF NOT                :MJD001
035320 117716 143622    MOVB     @STKB,(SP)  ;;GET CHAR                  :MJD001
035324 042716 177600    BIC      #177600,(SP) ;;STRIP IT                  :MJD001
035330 122716 000021    CMPB     #SXON,(SP)  ;;WAS IT XON?             :MJD001
035334 001366          BNE      101$        ;;BR IF NOT                :MJD001
035336                    102$:
035336 005726          TST      (SP)+      ;;FIX STACK                :MJD001
035340                    10$:
035340 105777 143604    TSTB     @STPS        ;;WAIT UNTIL PRINTER IS READY :MJD001
035344 100375          BPL      10$          ;;BR IF NOT                :MJD001
035346 126627 000002 000021  CMPB     2(SP),#$XON  ;;IS CHARACTER A RANDOM XON? :RAN001
035354 001420          BEQ      $TYPEX      ;;BRANCH IF YES           :RAN001
035356 116677 000002 143566  MOVB     2(SP),@STPB  ;;LOAD CHAR TO BE TYPED INTO DATA REG.
035364 122766 000015 000002  CMPB     #CR,2(SP)   ;;IS CHARACTER A CARRIAGE RETURN?
035372 001003          BNE      1$          ;;BRANCH IF NO
035374 105037 035414    CLRB     $CHARCNT    ;;YES--CLEAR CHARACTER COUNT
035400 000406          BR        $TYPEX      ;;EXIT
035402 122766 000012 000002  1$:    CMPB     #LF,2(SP)   ;;IS CHARACTER A LINE FEED?
035410 001402          BEQ      $TYPEX      ;;BRANCH IF YES
035412 105227          INCB     (PC)+      ;;COUNT THE CHARACTER
035414 000000          $CHARCNT: .WORD    0 ;;CHARACTER COUNT STORAGE
035416 000207          $TYPEX: RTS      PC

```

6435
6436

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOS    ;;CALL FOR TYPEOUT
*      .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*      .BYTE   M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*$STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPON    ;;CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED

```

BINARY TO OCTAL (ASCII) AND TYPE

```

: *      TYPOC      ::CALL FOR TYPEOUT
035420 017646 000000 $TYPOS: MOV @ (SP), -(SP) ::PICKUP THE MODE
035424 116637 000001 035651 MOVB 1 (SP), $OFILL ::LOAD ZERO FILL SWITCH
035432 112637 035653 MOVB (SP)+, $SOMODE+1 ::NUMBER OF DIGITS TO TYPE
035436 062716 000002 ADD #2, (SP) ::ADJUST RETURN ADDRESS
035442 000406 BR $TYPON
035444 112737 000001 035651 $TYPOC: MOVB #1, $OFILL ::SET THE ZERO FILL SWITCH
035452 112737 000006 035653 MOVB #6, $SOMODE+1 ::SET FOR SIX(6) DIGITS
035460 112737 000005 035650 $TYPON: MOVB #5, $SOCNT ::SET THE ITERATION COUNT
035466 010346 MOV R3, -(SP) ::SAVE R3
035470 010446 MOV R4, -(SP) ::SAVE R4
035472 010546 MOV R5, -(SP) ::SAVE R5
035474 113704 035653 MOVB $SOMODE+1, R4 ::GET THE NUMBER OF DIGITS TO TYPE
035500 005404 NEG R4
035502 062704 000006 ADD #6, R4 ::SUBTRACT IT FOR MAX. ALLOWED
035506 110437 035652 MOVB R4, $SOMODE ::SAVE IT FOR USE
035512 113704 035651 MOVB $OFILL, R4 ::GET THE ZERO FILL SWITCH
035516 016605 000012 MOV 12 (SP), R5 ::PICKUP THE INPUT NUMBER
035522 005003 CLR R3 ::CLEAR THE OUTPUT WORD
035524 006105 1$: ROL R5 ::ROTATE MSB INTO 'C'
035526 000404 BR 3$ ::GO DO MSB
035530 006105 2$: ROL R5 ::FORM THIS DIGIT
035532 006105 ROL R5
035534 006105 ROL R5
035536 010503 MOV R5, R3
035540 006103 3$: ROL R3 ::GET LSB OF THIS DIGIT
035542 105337 035652 DECB $SOCNT ::TYPE THIS DIGIT?
035546 100021 BPL 7$ ::BR IF NO
035550 042703 177770 BIC #177770, R3 ::GET RID OF JUNK
035554 001002 BNE 4$ ::TEST FOR 0
035556 005704 TST R4 ::SUPPRESS THIS 0?
035560 001403 BEQ 5$ ::BR IF YES
035562 005204 4$: INC R4 ::DON'T SUPPRESS ANYMORE 0'S
035564 052703 000060 BIS #'0, R3 ::MAKE THIS DIGIT ASCII
035570 052703 000040 5$: BIS #' , R3 ::MAKE ASCII IF NOT ALREADY
035574 122703 000040 CMPB #' , R3 ::IS THIS A SPACE CHARACTER?
035600 001404 BEQ 7$ ::BRANCH IF SO - DON'T TYPE
035602 110337 035646 MOVB R3, 8$ ::SAVE FOR TYPING
035606 104401 035646 TYPE 8$ ::GO TYPE THIS DIGIT
035612 105337 035650 7$: DECB $SOCNT ::COUNT BY 1
035616 003344 BGT 2$ ::BR IF MORE TO DO
035620 002402 BLT 6$ ::BR IF DONE
035622 005204 INC R4 ::INSURE LAST DIGIT ISN'T A BLANK
035624 000741 BR 2$ ::GO DO THE LAST DIGIT
035626 012605 6$: MOV (SP)+, R5 ::RESTORE R5
035630 012604 MOV (SP)+, R4 ::RESTORE R4
035632 012603 MOV (SP)+, R3 ::RESTORE R3
035634 016666 000002 000004 MOV 2 (SP), 4 (SP) ::SET THE STACK FOR RETURNING
035642 012616 MOV (SP)+, (SP)
035644 000002 RTI ::RETURN
035646 000 8$: .BYTE 0 ::STORAGE FOR ASCII DIGIT
035647 000 .BYTE 0 ::TERMINATOR FOR TYPE ROUTINE
035650 000 $SOCNT: .BYTE 0 ::OCTAL DIGIT COUNTER
035651 000 $OFILL: .BYTE 0 ::ZERO FILL SWITCH
035652 000000 $SOMODE: .WORD 0 ::NUMBER OF DIGITS TO TYPE

```

:DPM002
:DPM002

6438

```

.SBTTL APT COMMUNICATIONS ROUTINE
*****
035654 112737 000001 036120 $ATY1: MOV #1,$FFLG ::TO REPORT FATAL ERROR
035662 112737 000001 036116 $ATY3: MOV #1,$MFLG ::TO TYPE A MESSAGE
035670 000403 BR $ATYC
035672 112737 000001 036120 $ATY4: MOV #1,$FFLG ::TO ONLY REPORT FATAL ERROR
035700 $ATYC:
035700 010046 MOV R0,-(SP) ::PUSH R0 ON STACK
035702 010146 MOV R1,-(SP) ::PUSH R1 ON STACK
035704 105737 036116 TSTB $MFLG ::SHOULD TYPE A MESSAGE?
035710 001450 BEQ 5$ ::IF NOT: BR
035712 122737 000001 001336 CM?B #APTENV,$ENV ::OPERATING UNDER APT?
035720 001031 BNE 3$ ::IF NOT: BR
035722 132737 000100 001337 BITB #APTSPOOL,$ENVM ::SHOULD SPOOL MESSAGES?
035730 001425 BEQ 3$ ::IF NOT: BR
035732 017600 000004 MOV @4(SP),R0 ::GET MESSAGE ADDR.
035736 062766 000002 000004 ADD #2,4(SP) ::BUMP RETURN ADDR.
035744 005737 001316 1$: TST $MSGTYPE ::SEE IF DONE W/ LAST XMISSION?
035750 001375 BNE 1$ ::IF NOT: WAIT
035752 010037 001332 MOV R0,$MSGAD ::PUT ADDR IN MAILBOX
035756 105720 2$: TSTB (R0)+ ::FIND END OF MESSAGE
035760 001376 BNE 2$
035762 163700 001332 SUB $MSGAD,R0 ::SUB START OF MESSAGE
035766 006200 ASR R0 ::GET MESSAGE LNPTH IN WORDS
035770 010037 001334 MOV R0,$MSGGLT ::PUT LENGTH IN MAILBOX
035774 012737 000004 001316 MOV #4,$MSGTYPE ::TELL APT TO TAKE MSG.
036002 000413 BR 5$
036004 017637 000004 036030 3$: MOV @4(SP),4$ ::PUT MSG ADDR IN JSR LINKAGE
036012 062766 000002 000004 ADD #2,4(SP) ::BUMP RETURN ADDRESS
036020 013746 177776 MOV 177776,-(SP) ::PUSH 177776 ON STACK
036024 004737 035054 JSR PC,$TYPE ::CALL TYPE MACRO
036030 000000 4$: .WORD 0
036032 5$:
036032 105737 036120 10$: TSTB $FFLG ::SHOULD REPORT FATAL ERROR?
036036 001416 BEQ 12$ ::IF NOT: BR
036040 005737 001336 TST $ENV ::RUNNING UNDER APT?
036044 001413 BEQ 12$ ::IF NOT: BR
036046 005737 001316 11$: TST $MSGTYPE ::FINISHED LAST MESSAGE?
036052 001375 BNE 11$ ::IF NOT: WAIT
036054 017637 000004 001320 MOV @4(SP),$FATAL ::GET ERROR #
036062 062766 000002 000004 ADD #2,4(SP) ::BUMP RETURN ADDR.
036070 005237 001316 INC $MSGTYPE ::TELL APT TO TAKE ERROR
036074 105037 036120 12$: CLRB $FFLG ::CLEAR FATAL FLAG
036100 105037 036117 CLRB $LFLG ::CLEAR LOG FLAG
036104 105037 036116 CLRB $MFLG ::CLEAR MESSAGE FLAG
036110 012601 MOV (SP)+,R1 ::POP STACK INTO R1
036112 012600 MOV (SP)+,R0 ::POP STACK INTO R0
036114 000207 RTS PC ::RETURN
036116 000 $MFLG: .BYTE 0 ::MESSG. FLAG
036117 000 $LFLG: .BYTE 0 ::LOG FLAG
036120 000 $FFLG: .BYTE 0 ::FATAL FLAG
.EVEN
APTSIZE=200
APTENV=001
APTSPOOL=100
APTCSUP=040

```

6439

6440

```

.SBTTL TTY INPUT ROUTINE
:*****
:ENABL LSE
:*****
:*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
:*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
:*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
:*WHEN OPERATING IN TTY FLAG MODE.
036122 022737 000176 001140 $CKSWR: CMP #SWREG,SWR ;; IS THE SOFT-SWR SELECTED?
036130 001074 BNE 15$ ;; BRANCH IF NO
036132 105777 143006 TSTB @STKS ;; CHAR THERE?
036136 100071 BPL 15$ ;; IF NO, DON'T WAIT AROUND
036140 117746 143002 MOVB @STKB,-(SP) ;; SAVE THE CHAR
036144 042716 177600 BIC #^C177,(SP) ;; STRIP-OFF THE ASCII
036150 022726 000007 CMP #7,(SP)+ ;; IS IT A CONTROL G?
036154 001062 BNE 15$ ;; NO, RETURN TO USER
036156 123727 001134 000001 CMPB $AUTOB,#1 ;; ARE WE RUNNING IN AUTO-MODE?
036164 001456 BEQ 15$ ;; BRANCH IF YES
036166 104401 036541 TYPE ,SCNTLG ;; ECHO THE CONTROL-G (^G)
036172 104401 036546 $GTSWR: TYPE ,SMSWR ;; TYPE CURRENT CONTENTS
036176 013746 000176 MOV SWREG,-(SP) ;; SAVE SWREG FOR TYPEOUT
036202 104402 TYPOC ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
036204 104401 036557 TYPE ,SMNEW ;; PROMPT FOR NEW SWR
036210 005046 19$: CLR -(SP) ;; CLEAR COUNTER
036212 005046 CLR -(SP) ;; THE NEW SWR
036214 105777 142724 7$: TSTB @STKS ;; CHAR THERE?
036220 100375 BPL 7$ ;; IF NOT TRY AGAIN
036222 117746 142720 MOVB @STKB,-(SP) ;; PICK UP CHAR
036226 042716 177600 BIC #^C177,(SP) ;; MAKE IT 7-BIT ASCII
036232 021627 000025 9$: CMP (SP),#25 ;; IS IT A CONTROL-U?
036236 001005 BNE 10$ ;; BRANCH IF NOT
036240 104401 036534 TYPE ,SCNTLU ;; YES, ECHO CONTROL-U (^U)
036244 052706 000006 20$: ADD #6,SP ;; IGNORE PREVIOUS INPUT
036250 000757 BR 19$ ;; LET'S TRY IT AGAIN
036252 021627 000015 10$: CMP (SP),#15 ;; IS IT A <CR>?
036256 001022 BNE 16$ ;; BRANCH IF NO
036260 005766 000004 TST 4(SP) ;; YES, IS IT THE FIRST CHAR?
036264 001403 BEQ 11$ ;; BRANCH IF YES
036266 016677 000072 142644 MOV 2(SP),@SWR ;; SAVE NEW SWR
036274 062706 000006 11$: ADD #6,SP ;; CLEAR UP STACK
036300 104401 001313 14$: TYPE ,SCRLF ;; ECHO <CR> AND <LF>
036304 123727 001135 000001 CMPB $INTAG,#1 ;; RE-ENABLE TTY KBD INTERRUPTS?
036312 001003 BNE 15$ ;; BRANCH IF NOT
036314 012777 000100 142622 MOV #100,@STKS ;; RE-ENABLE TTY KBD INTERRUPTS
036322 000002 15$: RTI ;; RETURN
036324 004737 035266 16$: JSR PC,$TYPEC ;; ECHO CHAR
036330 021627 000060 CMP (SP),#60 ;; CHAR < 0?
036334 002420 BLT 18$ ;; BRANCH IF YES
036336 021627 000067 CMP (SP),#67 ;; CHAR > 7?
036342 003015 BGT 18$ ;; BRANCH IF YES
036344 042726 000060 BIC #60,(SP)+ ;; STRIP-OFF ASCII
036350 005766 000002 TST 2(SP) ;; IS THIS THE FIRST CHAR
036354 001403 BEQ 17$ ;; BRANCH IF YES
036356 006316 ASL (SP) ;; NO, SHIFT PRESENT
036360 006316 ASL (SP) ;; CHAR OVER TO MAKE
036362 006316 ASL (SP) ;; ROOM FOR NEW ONE.
036364 005266 000002 17$: INC 2(SP) ;; KEEP COUNT OF CHAR

```

036370 056616 177776
036374 000707
036376 104401 001312
036402 000720

BIS -2(SP),(SP) ;;SET IN NEW CHAR
BR 7\$;;GET THE NEXT ONE
18\$: TYPE \$QUES ;;TYPE ?<CR><LF>
BR 20\$;;SIMULATE CONTROL-U

.DSABL LSB

*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
*CALL:

* RDCHR ;;INPUT A SINGLE CHARACTER FROM THE TTY
* RETURN HERE ;;CHARACTER IS ON THE STACK
* ;;WITH PARITY BIT STRIPPED OFF

036404 011646
036406 016666 000004 000002
036414 105777 142524
036420 100375
036422 117766 142520 000004
036430 042766 177600 000004
036436 026627 000004 000023
036444 001013
036446 105777 142472
036452 100375
036454 117746 142466
036460 042716 177600
036464 022627 000021
036470 001366
036472 000750
036474 026627 000004 000021
036502 001744
036504 026627 000004 000140
036512 002407
036514 026627 000004 000175
036522 003003
036524 042766 000040 000004
036532 000002
036534 136 125 015
036541 136 107 015
036546 015 012 123
036557 040 040 116

\$RDCHR: MOV (SP),-(SP) ;;PUSH DOWN THE PC
MU. 4(SP),2(SP) ;;SAVE THE PS
1\$: TSTB @\$TKS ;;WAIT FOR
BPL 1\$;;A CHARACTER
MOVB @\$TKB,4(SP) ;;READ THE TTY
BIC #^C<177>,4(SP) ;;GET RID OF JUNK IF ANY
CMP 4(SP),#23 ;;IS IT A CONTROL-S?
BNE 3\$;;BRANCH IF NO
2\$: TSTB @\$TKS ;;WAIT FOR A CHARACTER
BPL 2\$;;LOOP UNTIL ITS THERE
MOVB @\$TKB,-(SP) ;;GET CHARACTER
BIC #^C177,(SP) ;;MAKE IT 7-BIT ASCII
CMP (SP)+,#21 ;;IS IT A CONTROL-Q?
BNE 2\$;;IF NOT DISCARD IT
BR 1\$;;YES, RESUME
3\$: CMP 4(SP),#\$XON ;;IS IT A RANDOM XON?
BEQ 1\$;;BRANCH IF YES
CMP 4(SP),#140 ;;IS IT UPPER CASE?
BLT 4\$;;BRANCH IF YES
CMP 4(SP),#175 ;;IS IT A SPECIAL CHAR?
BGT 4\$;;BRANCH IF YES
BIC #40,4(SP) ;;MAKE IT UPPER CASE
4\$: RTI ;;GO BACK TO USER
\$SCNTLU: .ASCIZ /^U/<15><12> ;;CONTROL 'U'
\$SCNTLG: .ASCIZ /^G/<15><12> ;;CONTROL 'G'
\$MSWR: .ASCIZ <15><12>/SWR = /
\$MNEW: .ASCIZ / NEW = /

:RAN001
:RAN001

6441
6442

.SBTTL TRAP DECODER

*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION
*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
*GO TO THAT ROUTINE.

036570 010046
036572 016600 000002
036576 005740
036600 111000
036602 006300
036604 016000 036624
036610 000200

\$TRAP: MOV RO,-(SP) ;;SAVE RO
MOV 2(SP),RO ;;GET TRAP ADDRESS
TST -(RO) ;;BACKUP BY 2
MOVB (RO),RO ;;GET RIGHT BYTE OF TRAP
ASL RO ;;POSITION FOR INDEXING
MOV \$TRPAD(RO),RO ;;INDEX TO TABLE
RTS RO ;;GO TO ROUTINE

036612 011646
036614 016666 000004 000002
036622 000002

;;THIS IS USE TO HANDLE THE 'GETPRI' MACRO
\$TRAP2: MOV (SP),-(SP) ;;MOVE THE PC DOWN
MOV 4(SP),2(SP) ;;MOVE THE PSW DOWN
RTI ;;RESTORE THE PSW

.SBTTL TRAP TABLE
*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
*BY THE 'TRAP' INSTRUCTION.

ROUTINE

036624	036612			\$TRPAD: .WORD	\$STRAP2		
036626	035054				STYPE	::CALL=TYPE	TRAP+1(104401) TTY TIMEOUT ROUTINE
036630	035444				STYPOC	::CALL=TYPOC	TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
036632	035420				STYPOS	::CALL=TYPOS	TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
036634	035460				STYPON	::CALL=TYPON	TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
036636	036172				\$GTSWR	::CALL=GTSWR	TRAP+5(104405) GET SOFT-SWR SETTING
036640	036122				\$CKSWR	::CALL=CKSWR	TRAP+6(104406) TEST FOR CHANGE IN SOFT-SWR
036642	036404				\$RDCHR	::CALL=RDCHR	TRAP+7(104407) TTY TYPEIN CHARACTER ROUTINE
036644	034760				\$SAVREG	::CALL=SAVREG	TRAP+10(104410) SAVE R0-R5 ROUTINE
036646	035016				\$RESREG	::CALL=RESREG	TRAP+11(104411) RESTORE R0-R5 ROUTINE
6443	036650	037544			.RSET	::CALL=RSETUP	TRAP+12(104412) ROUTINE TO INITIALIZE AFTER EVERY TEST
6444	036652	037536			.LPER	::CALL=LPER	TRAP+13(104413) ROUTINE TO SET LOOP ON ERROR ADDRESS
6445		000030					
6446							
6447							

\$TERM=-.\$STRPAD

.SBTTL POWER DOWN AND UP ROUTINES

POWER DOWN ROUTINE

036654	012737	037032	000024	\$PWRDN: MOV	#\$ILLUP,@#PWRVEC	::SET FOR FAST UP
036662	012737	000340	000026	MOV	#340,@#PWRVEC+2	::PRIO:7
036670	010046			MOV	R0,-(SP)	::PUSH R0 ON STACK
036672	010146			MOV	R1,-(SP)	::PUSH R1 ON STACK
036674	010246			MOV	R2,-(SP)	::PUSH R2 ON STACK
036676	010346			MOV	R3,-(SP)	::PUSH R3 ON STACK
036700	010446			MOV	R4,-(SP)	::PUSH R4 ON STACK
036702	010546			MOV	R5,-(SP)	::PUSH R5 ON STACK
036704	017746	142230		MOV	@SWR,-(SP)	::PUSH @SWR ON STACK
036710	010637	037036		MOV	SP,\$SAVR6	::SAVE SP
036714	012737	036726	000024	MOV	#\$PWRUP,@#PWRVEC	::SET UP VECTOR
036722	000000			HALT		
036724	000776			BR	.-2	::HANG UP

POWER UP ROUTINE

036726	012737	037032	000024	\$PWRUP: MOV	#\$ILLUP,@#PWRVEC	::SET FOR FAST DOWN
036734	013706	037036		MOV	\$SAVR6,SP	::GET SP
036740	005037	037036		CLR	\$SAVR6	::WAIT LOOP FOR THE TTY
036744	005237	037036		1\$: INC	\$SAVR6	::WAIT FOR THE INC
036750	001375			BNE	1\$::OF WORD
036752	012677	142162		MOV	(SP)+,@SWR	::POP STACK INTO @SWR
036756	012605			MOV	(SP)+,R5	::POP STACK INTO R5
036760	012604			MOV	(SP)+,R4	::POP STACK INTO R4
036762	012603			MOV	(SP)+,R3	::POP STACK INTO R3
036764	012602			MOV	(SP)+,R2	::POP STACK INTO R2
036766	012601			MOV	(SP)+,R1	::POP STACK INTO R1
036770	012600			MOV	(SP)+,R0	::POP STACK INTO R0
036772	012737	036654	000024	MOV	#\$PWRDN,@#PWRVEC	::SET UP THE POWER DOWN VECTOR
037000	012737	000340	000026	MOV	#340,@#PWRVEC+2	::PRIO:7
037006	104401			TYPE		::REPORT THE POWER FAILURE
037010	037740			\$PWRMG: .WORD	POWERM	::POWER FAIL MESSAGE POINTER
037012	012716			MOV	(PC)+,(SP)	::RESTART AT START
037014	004346			\$PWRAD: .WORD	START	::RESTART ADDRESS
037016	042766	000020	000002	BIC	#20,2(SP)	::CLEAR 'T' BIT
037024	005037	034076		CLR	\$TBIT	::CLEAR THE 'T' BIT FLAG

037030 000002
037032 000000
037034 000776
037036 000000

RTI
\$ILLUP: HALT
BR
\$SAVR6: 0

::THE POWER UP SEQUENCE WAS STARTED
:: BEFORE THE POWER DOWN WAS COMPLETE
::PUT THE SP HERE

6448
6449
6450
6451

.SBTTL ERROR TYPE OUT ROUTINE

*THIS ROUTINE IS CALLED TO TYPE AN ERROR MESSAGE WHICH IS INCLUDED
*IN THE ERROR MESSAGE DATA TABLE. IT IS CALLED BY THE \$ERROR ROUTINE
*OR BY FIRST SETTING \$ITEMB EQUAL TO THE ERROR TABLE ITEM TO BE PRINTED
*OUT AND THEN EXECUTING A:

6452
6453
6454
6455
6456
6457
6458
6459
6460
6461
6462
6463
6464
6465
6466
6467
6468
6469
6470
6471
6472
6473
6474
6475
6476
6477
6478
6479
6480
6481
6482
6483
6484
6485
6486
6487
6488
6489
6490
6491
6492
6493
6494
6495
6496
6497
6498
6499

104401 001313
113737 001102 001232
042737 177400 001232
013737 001116 001234
010046
113700 001114
042700 177400
001005
013746 001116
104402
000137 037410
022700 000377
001005
016600 000004
062700 000400
010037 001320
005300
006300
006300
006300
062700 001442
012037 037164
001404
104401
000000
104401 001313
012037 037202
001404
104401
000000
104401 001313
010146
010246
010346
012001
001503
011000
105710
001003
013146
104402

ERTYPE: TYPE ,\$CRLF ;TYPE A CRLF
 MOV \$TSTNM,\$TMP0 ;MOVE TEST NUMBER TO \$TMP0
 BIC #177400,\$TMP0 ;CLEAR THE UPPER BYTE
 MOV \$ERRPC,\$TMP1 ;GET PC OF CALL
 MOV R0,-(SP) ;SAVE R0
 MOV \$ITEMB,R0 ;GET THE ITEM NUMBER.
 BIC #177400,R0 ;CLEAR THE UPPER BYTE
 BNE 1\$;BRANCH IF ITEM IS ZERO
 MOV \$ERRPC,-(SP) ;MOVE THE ERROR PC TO THE STACK FOR PRINTING
 TYPOC ;PRINT THE PC
 JMP 22\$;JUMP TO EXIT - ALL DONE
1\$: CMP #377,R0 ;SEE IF ERROR # IS 377
 BNE 3\$;BRANCH IF NOT
 MOV 4(SP),R0 ;MOVE ITEM ADDRESS ON STACK TO R0
 MOV (R0),R0 ;MOVE ITEM TO R0
 ADD #400,R0 ;ADD 400 TO R0
3\$: MOV R0,\$FATAL ;SET ITEM NUMBER IN \$FATAL FOR APT ;DPM001
 DEC R0 ;DECREMENT R0 AND
 ASL R0 ;SHIFT THREE TIMES
 ASL R0 ;TO FORM AN INDEX
 ASL R0 ;FOR THE TABLE.
 ADD #\$ERRTB,R0 ;ADD ERROR TABLE START TO R0 - FORMS STARTING ADDRESS
4\$: MOV (R0)+,\$\$;PICK UP THE ADDRESS OF THE ERROR MESSAGE
 BEQ 6\$;BRANCH IF NONE
 TYPE ;TYPE THE MESSAGE
5\$: .WORD 0 ;LOCATION FOR ASCII MESSAGE ADDRESS
 TYPE ,\$CRLF ;TYPE A <CRLF>
6\$: MOV (R0)+,\$\$;GET THE DATA HEADER
 BEQ 8\$;BRANCH IF NO HEADER
 TYPE ;TYPE THE HEADER
7\$: .WORD 0 ;LOCATION FOR HEADER ADDRESS
 TYPE ,\$CRLF ;TYPE A <CRLF>
8\$: MOV R1,-(SP) ;SAVE R1
 MOV R2,-(SP) ;SAVE R2
 MOV R3,-(SP) ;SAVE R3
 MOV (R0)+,R1 ;GET THE ADDRESS OF THE DATA TABLE.
 BEQ 23\$;BRANCH TO RETURN IF NO DATA.
 MOV (R0),R0 ;GET A POINTER TO THE DATA FORMAT TABLE.
9\$: TSTB (R0) ;IS THE FORMAT ZERO?
 BNE 10\$;BRANCH TO CHECK FOR FORMAT 2 IF NOT
 MOV @ (R1)+,-(SP) ;FORMAT ZERO SO TYPE
 TYPOC ;AN OCTAL NUMBER.

ADDRESS	OPCODE	OPERANDS	COMMENT
6500	037234	000463	
6501	037236	122710	CJ0002
6502	037242	001005	
6503	037244	004737	037434
6504	037250	004737	037434
6505	037254	000453	
6506	037256	122710	000003
6507	037262	001006	
6508	037264	012703	000004
6509	037270	004737	037434
6510	037274	077303	
6511	037276	000442	
6512			
6513	037300	122710	000004
6514	037304	001004	
6515	037306	013146	
6516	037310	104403	
6517	037312	016	
6518	037313	000	
6519	037314	000433	
6520	037316	122710	000005
6521	037322	001005	
6522	037324	012137	037332
6523	037330	104401	
6524	037332	000000	
6525	037334	000425	
6526	037336	122710	000011
6527	037342	001005	
6528	037344	013137	J37352
6529	037350	104401	
6530	037352	000000	
6531	037354	000415	
6532	037356	122710	000012
6533	037362	001007	
6534	037364	013102	
6535	037366	012703	000006
6536	037372	004737	037434
6537	037376	077303	
6538	037400	000401	
6539	037402	000000	
6540	037404	104401	040005
6541			
6542	037410	005200	
6543	037412	005711	
6544	037414	001303	
6545	037416	104401	001313
6546	037422	012603	
6547	037424	012602	
6548	037426	012601	
6549	037430	012600	
6550	037432	000207	
6551			
6552	037434	013102	
6553	037436	012246	
6554	037440	104402	
6555	037442	104401	040007
6556	037446	000207	

```

10$: BR 21$ ;BRANCH TO PRINT A TAB CHARACTER AFTER TABLE ENTRY
CMPB #2,(R0) ;IS THE FORMAT TWO?
BNE 11$ ;BRANCH TO CHECK FOR FORMAT 3 IF NOT
JSR PC,TOCTNM ;TYPE 1ST OCTAL NUMBER
JSR PC,TOCTNM ;TYPE 2ND OCTAL NUMBER
BR 21$ ;BRANCH TO PRINT A TAB CHARACTER AFTER TABLE ENTRY
11$: CMPB #3,(R0) ;IS THE FORMAT THREE?
BNE 13$ ;BRANCH TO CHECK FOR FORMAT 4 IF NOT
MOV #4,R3 ;SET LOOP COUNTER TO TYPE 4 OCTAL NUMBERS
12$: JSR PC,TOCTNM ;TYPE AN OCTAL NUMBER
SOB R3,12$ ;SUBTRACT 1 AND BRANCH IF NOT DONE
BR 21$ ;BRANCH TO PRINT A TAB CHARACTER AFTER TABLE ENTRY
13$: CMPB #4,(R0) ;IS THE FORMAT FOUR?
BNE 14$ ;BRANCH TO CHECK FOR FORMAT 5 IF NOT
MOV @ (R1)+,-(SP) ;MOVE THE DATA TO THE STACK FOR TYPING
TYPOS ;GO TYPE AN OCTAL NUMBER
.BYTE 16 ;TYPE UP TO 16 DIGITS
.BYTE 0 ;SUPPRESSING LEADING ZEROES.
BR 21$ ;BRANCH TO PRINT A TAB CHARACTER AFTER TABLE ENTRY
14$: CMPB #5,(R0) ;IS THE FORMAT FIVE?
BNE 16$ ;BRANCH TO CHECK FOR FORMAT 11 IF NOT
MOV (R1)+,15$ ;PUT THE ADDRESS OF THE ASCII STRING IN THE LOCATION
TYPE ;TYPE THE ASCII STRING.
.WORD 0 ;LOCATION FOR THE ADDRESS OF THE ASCII STRING
BR 22$ ;BRANCH TO INCREMENT R0 AND CONTINUE
16$: CMPB #11,(R0) ;IS THE FORMAT ELEVEN?
BNE 18$ ;BRANCH TO CHECK FOR FORMAT 12 IF NOT
MOV @ (R1)+,17$ ;MOVE THE DATA TO THE STACK FOR TYPING
TYPE ;TYPE THE ASCII STRING.
.WORD 0 ;LOCATION FOR THE ADDRESS OF THE ASCII STRING
BR 22$ ;BRANCH TO INCREMENT R0 AND CONTINUE
18$: CMPB #12,(R0) ;IS THE FORMAT TWELVE?
BNE 20$ ;BRANCH TO HALT IF NOT - FORMAT NOT RECOGNIZED
MOV @ (R1)+,R2 ;MOVE THE DATA TO THE STACK FOR TYPING
MOV #6,R3 ;TYPE SIX OCTAL NUMBERS
19$: JSR PC,TOCTNM ;TYPE AN OCTAL NUMBER
SOB R3,19$ ;SUBTRACT 1 AND BRANCH IF NOT DONE YET
BR 21$ ;BRANCH TO PRINT A TAB CHARACTER AFTER TABLE ENTRY
20$: HALT ;UNDEFINED FORMAT FOR DATA????
21$: TYPE ,STAB ;PRINT A TAB AFTER TYPING A DATA TABLE ENTRY
;OF ALL FORMATS EXCEPT FORMATS 5 OR 11
22$: INC R0 ;POINT TO THE NEXT FORMAT
TST (R1) ;HAS THE END OF THE DATA TABLE BEEN REACHED?
BNE 9$ ;BRANCH BACK IF NOT
TYPE ,CRLF ;DONE.
MOV (SP)+,R3 ;RESTORE R1,R2 AND R3
MOV (SP)+,R2
MOV (SP)+,R1
23$: MOV (SP)+,R0 ;RESTORE R0.
RTS PC ;AND RETURN.
TOCTNM: MOV @ (R1)+,R2 ;FORMAT TWO SO TYPE TWO
MOV (R2)+,-(SP) ;OCTAL NUMBERS.
TYPOC ;TYPE THE OCTAL NUMBER
TYPE ,SPACE ;TYPE A SPACE CHARACTER
RTS PC ;EXIT

```

6557
6558

6559
6560
6561
6562
6563 037450 011637 001236
6564 037454 022626
6565 037456 170200
6566 037460 010037 001240
6567 037464 170300
6568 037466 010037 001242
6569 037472 104247
6570 037474 104412

```
.SBTTL FPP SPURIOUS TRAP TO 244 HANDLER
:*****
:*****
:THIS ROUTINE HANDLES UNEXPECTED TFAPS TO THE FPP TRAP VECTOR AT 244.
:THE LAST FPP INSTRUCTION EXECUTED AND ITS ADDRESS HAS BEEN RECORDED
:THESE ALONG WITH THE FEC, FPS AND PC OF TRAP ARE REPORTED.
:
FPPSPUR: MOV (SP), $TMP2 ;SAVE PC OF TRAP.
          CMP (SP)+, (SP)+ ;RESTORE SP.
          STFPS R0 ;GET FPS
          MOV R0, $TMP3
          STST R0 ;GET FEC
          MOV R0, $TMP4
1$:      ERROR +247
          RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
          ;SEE IF THE USER HAS EXPRESSED
          ;THE DESIRE TO CHANGE THE SOFTWARE
          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
          ;THE USER TYPED CONTROL G?).

          JMP $EOP
```

6571 037476 000137 033340
6572
6573
6574
6575

```
.SBTTL CPU SPURIOUS TRAP TO 4 HANDLER
:*****
:*****
:THIS ROUTINE REPORTS UNEXPECTED CPU TRAPS TO VECTOR 4.
:
CPSPUR: MOV (SP), $TMP2 ;SAVE PC OF TRAP.
          CMP (SP)+, (SP)+
1$:      ERROR +250
          RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
          ;SEE IF THE USER HAS EXPRESSED
          ;THE DESIRE TO CHANGE THE SOFTWARE
          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
          ;THE USER TYPED CONTROL G?).

          JMP $EOP
```

6582 037514 000137 033340
6583
6584
6585
6586

```
.SBTTL CPU SPURIOUS TRAP TO 10 HANDLER
:*****
:*****
:THIS ROUTINE REPORTS UNEXPECTED CPU TRAPS TO VECTOR 10.
:
CPTWO: MOV (SP), $TMP2 ;SAVE PC OF TRAP.
          CMP (SP)+, (SP)+
1$:      ERROR +251
          RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
          ;SEE IF THE USER HAS EXPRESSED
          ;THE DESIRE TO CHANGE THE SOFTWARE
          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
          ;THE USER TYPED CONTROL G?).

          JMP $EOP
```

6587
6588
6589 037520 011637 001236
6590 037524 022626
6591 037526 104251
6592 037530 104412

6593 037532 000137 033340
6594
6595
6596
6597
6598


```

6599          .SBTTL SET LOOP ON ERROR ADDRESS ROUTINE
6600          *****
6601          *****
6602 037536   011637   001110   .LPER:  MOV    (SP),.SLPERR
6603 037542   000002                RTI
6604
6605          .SBTTL FLAG RESET AND CONSOLE TEST ROUTINE
6606          *****
6607          *THIS ROUTINE WILL BE CALLED AT THE END OF EACH TEST TO
6608          *RESET THE STACK, CLEAR THE FPS AND SEE IF THE USER HAS TYPED
6609          * CONTROL G ON THE TERMINAL. IF THE USER HAS TYPED CONTROL G AND
6610          *THERE IS NO PHYSICAL CONSOLE SWITCH REGISTER THEN THE CONTENTS
6611          *OF THE SOFTWARE SWITCH REGISTER WILL BE TYPED IN OCTAL ON THE
6612          *TELETYPE AND THE USER CAN MODIFY IT.
6613          *
6614 037544   023727   001140   177570 .RSET:  CMP    SWR,#177570          ;SEE IF THERE IS A PHYSICAL
6615                                     ;CONSOLE SWITCH REGISTER.
6616 037552   001001                BNE    1$          ;BRANCH IF NO.
6617 037554   104406                CKSWR          ;OTHERWISE TYPE THE CONTENTS
6618                                     ;OF THE PROGRAM VIRTUAL SWITCH REGISTER
6619                                     ;AND GIVE THE USER A CHANCE TO
6620                                     ;MODIFY IT.
6621 037556   012737   037450   000244 1$:   MOV    #FPSPUR,FPVECT
6622 037564   012737   037502   000004    MOV    #CPSPUR,ERRVECT
6623 037572   012737   037520   000010    MOV    #CPTWO,10
6624 037600   011600                MOV    (SP),R0          ;SAVE RETURN ADDRESS.
6625 037602   012706   001100    MOV    #STACK,SP      ;RESET THE STACK POINTER.
6626 037606   005004                CLR    R4              ;CLEAR THE FPS.
6627 037610   170104                LDFPS  R4
6628 037612   000110                JMP    (R0)            ;RETURN.
6629
6630
6631
6632          .SBTTL SPECIAL MESSAGES
6633 037614           124           122           101 MSA1:  .ASCIZ  'TRAPPED AT:'<TAB><TAB>
6634 037632           105           130           120 MSA2:  .ASCIZ  'EXPECTED TRAP AT:'<TAB>
6635 037655           107           117           124 MSA3:  .ASCIZ  'GOT R0:'<TAB><TAB>
6636 037667           105           130           120 MSA4:  .ASCIZ  'EXPECTED R0:'<TAB>
6637 037705           107           117           124 MSA5:  .ASCIZ  'GOT ACO:'<TAB><TAB>
6638 037720           105           130           120 MSA6:  .ASCIZ  'EXPECTED ACO:'<TAB><TAB>
6639 037740           200           120           117 POWERM: .ASCIZ  <CRLF>'POWER FAILURE. PROGRAM RESTARTING.'<CRLF>
6640 040005           011           000                $TAB:  .ASCIZ  <TAB>
6641 040007           040           040           000 SPACE:  .ASCIZ  ' '
6642 040012           101           103           040 MS1:   .ASCIZ  'AC OPERAND:'<TAB><TAB>
6643 040030           106           123           122 MS2:   .ASCIZ  'FSRC OPERAND:'<TAB><TAB>
6644 040050           101           103           060 MS3:   .ASCIZ  'ACO BEFORE EXECUTION:'<TAB>
6645 040077           101           103           060 MS4:   .ASCIZ  'ACO AFTER EXECUTION:'<TAB>
6646 040125           105           130           120 MS5:   .ASCIZ  'EXPECTED RESULT:'<TAB>
6647 040147           107           117           124 MS6:   .ASCIZ  'GOT RESULT:'<TAB><TAB>
6648 040165           106           122           101 MS7:   .ASCIZ  'FRACTIONAL RESULT:'<TAB>
6649 040211           111           116           124 MS10:  .ASCIZ  'INTEGER RESULT:'<TAB>
6650 040233           105           130           120 MS11:  .ASCIZ  'EXPECTED FRACTION:'<TAB>
6651 040257           105           130           120 MS12:  .ASCIZ  'EXPECTED INTEGER:'<TAB>
6652 040302           114           117           101 MS37:  .ASCIZ  'LOADED DATA:'
6653 040320           122           105           101 MS40:  .ASCIZ  'READ DATA:'
  
```


6654	040334	105	130	120	MS415:	.ASCIZ	'EXPECTED DATA: '
6655	040354	104	101	124	MS41:	.ASCIZ	'DATA IN (RO) FSRC: '
6656	040400	104	101	124	MS42:	.ASCIZ	'DATA IN ACO: '
6657	040416	107	117	124	MS43:	.ASCIZ	'GOT RESULT: '
6658	040433	105	130	120	MS44:	.ASCIZ	'EXPECTED RESULT: '
6659	040455	200	124	105	CORMES:	.ASCIZ	<CRLF>'TEST 22, TESTING INTERRUPTS.'<CRLF>

Line No.	Code	Page	Line No.	Page	Code	Message
6660					.SBTTL	ERROR MESSAGES
6661	040514	106	120	123	EM1:	.ASCIZ 'FPS BAD AFTER CMPD (R),A.'
6662	040546	101	103	060	EM2:	.ASCIZ 'ACO MODIFIED BY CMPD (R),A.'
6666	040602				EM3:	
	040602	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6667	040626	050	102	125		.ASCIZ '(BUT ENBT) STATE 225 WENT TO 475 INSTEAD OF 075.'
6668	040707				EM4:	
	040707	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6669	040733	050	102	125		.ASCIZ '(BUT ENBT) STATE 225 WENT TO 075 INSTEAD OF 475.'
6670	041014				EM5:	
	041014	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6671	041040	050	102	125		.ASCIZ '(BUT ENBT) STATE 035 WENT TO 075 INSTEAD OF 475.'
6672	041121				EM6:	
	041121	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6673	041145	050	102	125		.ASCIZ '(BUT ENBT) STATE 035 WENT TO 475 INSTEAD OF 075.'
6674	041226				EM7:	
	041226	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6675	041252	050	102	125		.ASCIZ '(BUT ENBT Y8) STATE 777 SHOULD HAVE GONE TO 007.'
6676	041333				EM10:	
	041333	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6677	041357	050	102	125		.ASCIZ '(BUT ENBT Y8) STATE 777 SHOULD HAVE GONE TO 405.'
6678	041440				EM11:	
	041440	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6679	041464	050	102	125		.ASCIZ '(BUT NBIT ZBIT) STATE 456 SHOULD HAVE GONE TO 010.'
6680	041547				EM12:	
	041547	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6681	041573	050	102	125		.ASCIZ '(BUT NBIT ZBIT) STATE 456 SHOULD HAVE GONE TO 110.'
6682	041656				EM13:	
	041656	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6683	041702	104	111	104		.ASCIZ '/DIDN'T TAKE THE PATH: STATE 456, TO 012, TO 363 TO 120./
6684	041772				EM14:	
	041772	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6685	042016	050	102	125		.ASCIZ '(BUT XNBT XZBT) STATE 363 WENT TO 140 INSTEAD OF 100.'
6686	042104				EM15:	
	042104	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6687	042130	050	102	125		.ASCIZ '(BUT XNBT XZBT) STATE 363 WENT TO 100 INSTEAD OF 140.'
6688	042216				EM16:	
	042216	106	120	123		.ASCII 'FPS BAD AFTER CMPD.'<CRLF>
6689	042242	104	111	104		.ASCIZ '/DIDN'T TAKE THE PATH: STATE 777, TO 407./
6690	042313	104	111	126	EM17:	.ASCIZ 'DIVD (R),A TRAPPED TO 244. FSRC=0 AND FID=1.'
6691	042370	106	120	123	EM20:	.ASCIZ 'FPS BAD AFTER DIVD (R),A.'
6692	042422	106	105	103	EM21:	.ASCIZ 'FEC BAD AFTER DIVD (R),A.'
6693	042454	104	111	126	EM22:	.ASCIZ '/DIVD (R),A DIDN'T TRAP TO 244. FSRC=0 AND FID=0./
6694	042535	104	111	126	EM23:	.ASCIZ 'DIVF (R),A FAILED.'
6695	042560	106	120	123	EM32:	.ASCIZ 'FPS BAD AFTER DIVF (R),A.'
6699	042612				EM24:	
	042612	104	111	126		.ASCII 'DIVF (R),A FAILED.'
6700	042634	050	102	125		.ASCIZ '(BUT Y61) WENT TO STATE 006 INSTEAD OF 206.'
6701	042710				EM25:	
	042710	104	111	126		.ASCII 'DIVF (R),A FAILED.'
6702	042732	130	117	122		.ASCIZ 'XOR OF SIGN BITS FAILED STATE 470.'
6703	042775				EM26:	
	042775	104	111	126		.ASCII 'DIVF (R),A FAILED.'
6704	043017	050	102	125		.ASCIZ '(BUT Y61) WENT TO STATE 206 INSTEAD OF 006.'
6705	042710				EM27=EM25	
6706	043073	104	111	126	EM30:	.ASCII 'DIVF (R),A FAILED.'

6707	043115	124	122	125		.ASCIZ	'TRUNCATION ERROR. FT=1.'
6708	043145				EM31:		
	043145	104	111	126		.ASCII	'DIVF (R),A FAILED.'
6709	043167	122	117	125		.ASCIZ	'ROUND ERROR. FT=0.'
6710	043212	104	111	126	EM33:	.ASCIZ	'DIVD (R),A FAILED.'
6711	043235	106	120	123	EM34:	.ASCIZ	'FPS BAD AFTER DIVD (R),A.'
6715	043267				EM35:		
	043267	104	111	126		.ASCII	'DIVD (R),A FAILED.'<CRLF>
6716	043312	124	122	125		.ASCIZ	'TRUNCATION ERROR. FT=1.'
6717	043342				EM36:		
	043342	104	111	126		.ASCII	'DIVD (R),A FAILED.'<CRLF>
6718	043365	122	117	125		.ASCIZ	'ROUND ERROR. FT=0.'
6719	043410	115	125	114	EM37:	.ASCIZ	'MULF (R),A FAILED.'
6723	043433	106	120	123	EM40:	.ASCIZ	'FPS BAD AFTER MULF (R),A.'
6724	043465				EM41:		
	043465	115	125	114		.ASCII	'MULF (R),A FAILED.'<CRLF>
6725	043510	123	111	107		.ASCIZ	'SIGN BIT BAD STATE 511.'
6726	043540				EM42:		
	043540	115	125	114		.ASCII	'MULF (R),A FAILED.'<CRLF>
6727	043563	116	117	122		.ASCII	'NORMALIZATION FAILED.'<CRLF>
6728	043611	050	102	125		.ASCIZ	'(BUT Y62) STATE 252 WENT TO 044 INSTEAD OF 444.'
6729	043671				EM43:		
	043671	115	125	114		.ASCII	'MULF (R),A FAILED.'<CRLF>
6730	043714	116	117	122		.ASCII	'NORMALIZATION FAILED.'<CRLF>
6731	043742	050	102	125		.ASCIZ	'(BUT Y62) STATE 252 WENT TO 444 INSTEAD OF 044.'
6732	044022				EM44:		
	044022	115	125	114		.ASCII	'MULF (R),A FAILED.'<CRLF>
6733	044045	122	117	125		.ASCIZ	'ROUND ERROR. FT=0.'
6734	044070				EM45:		
	044070	115	125	114		.ASCII	'MULF (R),A FAILED.'<CRLF>
6735	044113	124	122	125		.ASCIZ	'TRUNCATION ERROR. FT=1.'
6736	044143	106	120	123	EM46:	.ASCIZ	'FPS BAD AFTER MULD (R),A.'
6740	044175	115	125	114	EM246:	.ASCIZ	'MULD (R),A FAILED.'
6741	044220				EM47:		
	044220	115	125	114		.ASCII	'MULD (R),A FAILED.'<CRLF>
6742	044243	102	101	104		.ASCII	'BAD CONSTANT USED IN THE MUL ALGORITHM.'
6743	044312	200	125	123		.ASCIZ	<CRLF>'USED 24 INSTEAD OF 56 STATE 020.'
6744	044354				EM50:		
	044354	115	125	114		.ASCII	'MULD (R),A FAILED.'<CRLF>
6745	044377	124	122	125		.ASCIZ	'TRUNCATION ERROR. FT=1.'
6746	044427				EM51:		
	044427	115	125	114		.ASCII	'MULD (R),A FAILED.'<CRLF>
6747	044452	122	117	125		.ASCIZ	'ROUND ERROR. FT=0.'
6748	044475				EM52:		
	044475	115	125	114		.ASCII	'MULD (R),A FAILED.'<CRLF>
6749	044520	102	101	104		.ASCIZ	'BAD CONSTANT USED IN ROUNDING. FT=0.'
6750	044565	106	120	123	EM111:	.ASCIZ	'FPS BAD AFTER MULF (R),A. EXPECTED OVERFLOW.'
6751	044642	106	120	123	EM112:	.ASCIZ	'FPS BAD AFTER MULF (R),A. EXPECTED UNDERFLOW.'
6752	044720				EM113:		
	044720	115	125	114		.ASCII	'MULF (R),A FAILED.'<CRLF>
6753	044743	105	130	120		.ASCIZ	'EXPECTING OVERFLOW, FIV=0.'
6754	044776				EM114:		
	044776	115	125	114		.ASCII	'MULF (R),A FAILED.'<CRLF>
6755	045021	105	130	120		.ASCIZ	'EXPECTING UNDERFLOW, FIU=0.'
6756	045055	115	125	114	EM115:	.ASCIZ	'MULF (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6757	045133	115	125	114	EM116:	.ASCIZ	'MULF (R),A TRAPPED TO 244 ON UNDERFLOW. FIU=0.'
6764	045212				EM117:		

6765	045212	115	125	114	.ASCII	'MULF (R),A TRAPPED TO 244 ON UNDERFLOW. FIV=0.'	
6766	045270	050	102	125	.ASCIIZ	'(BUT FIU) STATE 331 WENT TO 155 INSTEAD OF 115.'	
6767	045350	115	125	114	EM120:	.ASCII	'MULF (R),A TRAPPED TO 244 ON UNDERFLOW. FIV=0.'
6768	045426	050	102	125	.ASCIIZ	'(BUT FIU) STATE 137 WENT TO 155 INSTEAD OF 115.'	
6769	045506	115	125	114	EM121:	.ASCII	'MULF (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6770	045563	050	102	125	.ASCIIZ	'(BUT FIV) STATE 333 WENT TO 136 INSTEAD OF 116.'	
6771	045643	115	125	114	EM122:	.ASCII	'MULF (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6772	045720	050	102	125	.ASCIIZ	'(BUT FIV) STATE 133 WENT TO 136 INSTEAD OF 116.'	
6773	046000	106	120	123	EM123:	.ASCIIZ	'FPS BAD AFTER MULF (R),A. EXPECTING OVERFLOW.'
6774	046056	106	120	123	EM124:	.ASCIIZ	'FPS BAD AFTER MULF (R),A. EXPECTING UNDERFLOW.'
6775	046135	115	125	114	EM125:	.ASCII	'MULD (R),A FAILED.<CRLF>
6776	046160	105	130	120	.ASCIIZ	'EXPECTING OVERFLOW, FIV=0.'	
6777	046213	115	125	114	EM126:	.ASCII	'MULD (R),A FAILED.<CRLF>
6778	046236	105	130	120	.ASCIIZ	'EXPECTING UNDERFLOW, FIU=0.'	
6779	046272	115	125	114	EM127:	.ASCIIZ	'MULD (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6786	046350	115	125	114	EM130:	.ASCIIZ	'MULD (R),A TRAPPED TO 244 ON UNDERFLOW. FIU=0.'
6787	046427	115	125	114	EM131:	.ASCII	'MULF (R),A TRAPPED TO 244 ON UNDERFLOW. FIU=0.'
6788	046427	050	102	125	.ASCIIZ	'(BUT FIU) STATE 331 WENT TO 155 INSTEAD OF 115.'	
6789	046505	115	125	114	EM132:	.ASCII	'MULD (R),A FAILED.<CRLF>
6790	046565	105	130	120	.ASCII	'EXPECTING UNDERFLOW, FIU=0.'	
6791	046610	200	050	102	.ASCIIZ	<CRLF>'(BUT FD) STATE 115 WENT TO 424 INSTEAD OF 425.'	
6792	046643	115	125	114	EM133:	.ASCII	'MULF (R),A TRAPPED TO 244 ON UNDERFLOW. FIU=0.'
6793	046723	050	102	125	.ASCIIZ	'(BUT FIU) STATE 137 WENT TO 155 INSTEAD OF 115.'	
6794	047001	115	125	114	EM134:	.ASCII	'MULD (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6795	047061	050	102	125	.ASCIIZ	'(BUT FIV) STATE 333 WENT TO 136 INSTEAD OF 116.'	
6796	047061	115	125	114	EM135:	.ASCII	'MULD (R),A FAILED.<CRLF>
6797	047136	105	130	120	.ASCII	'EXPECTING OVERFLOW, FIV=0.'	
6798	047216	200	050	102	.ASCIIZ	<CRLF>'(BUT FD) STATE 116 WENT TO 424 INSTEAD OF 425.'	
6799	047241	115	125	114	EM136:	.ASCII	'MULD (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6800	047353	050	102	125	.ASCIIZ	'(BUT FIV) STATE 133 WENT TO 136 INSTEAD OF 116.'	
6801	047430	106	105	103	EM137:	.ASCIIZ	'FEC BAD AFTER MULF (R),A. EXPECTING OVERFLOW, FEC=10.'
6802	047510	106	105	103	EM140:	.ASCIIZ	'FEC BAD AFTER MULF (R),A. EXPECTING UNDERFLOW, FEC=12.'
6803	047576	044565			EM141=EM111		
6804	047665	044642			EM142=EM112		
6805	047665	115	125	114	EM143:	.ASCII	'MULF (R),A FAILED.<CRLF>
6806	047710	105	130	120	.ASCIIZ	'EXPECTING OVERFLOW, FIV=1.'	
6807	047743	115	125	114	EM144:	.ASCII	'MULF (R),A FAILED.<CRLF>
6814	047766	105	130	120	.ASCIIZ	'EXPECTING UNDERFLOW, FIU=1.'	
6815	050022	115	125	114	EM145:	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON UNDERFLOW. FIU=1.'
6816	050107	050	102	125	.ASCIIZ	'(BUT FIU) STATE 331 WENT TO 115 INSTEAD OF 155.'	
6817	050167	115	125	114	EM146:	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON UNDERFLOW. FIU=1.'
6817	050254	050	102	125	.ASCIIZ	'(BUT FIU) STATE 137 WENT TO 115 INSTEAD OF 155.'	

6818	050334				EM147:	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON OVERFLOW. FIV=1.'
	050334	115	125	114		.ASCIIZ	'(BUT FIV) STATE 333 WENT TO 116 INSTEAD OF 136.'
6819	050420	050	102	125			
6820	050500				EM150:	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON OVERFLOW. FIV=1.'
	050500	115	125	114		.ASCIIZ	'(BUT FIV) STATE 133 WENT TO 116 INSTEAD OF 136.'
6821	050564	050	102	125			
6822	050644	106	105	103	EM151:	.ASCIIZ	'FEC BAD AFTER MULF (R),A. EXPECTING OVERFLOW, FEC=10.'
6823	050732	106	105	103	EM152:	.ASCIIZ	'FEC BAD AFTER MULF (R),A. EXPECTING UNDERFLOW, FEC=12.'
6824		046000			EM153=EM123		
6825		046056			EM154=EM124		
6826	051021				EM155:	.ASCII	'MULF (R),A FAILED.<CRLF>
	051021	115	125	114		.ASCIIZ	'EXPECTING OVERFLOW, FIV=1.'
6827	051044	105	130	120			
6828	051077				EM156:	.ASCII	'MULF (R),A FAILED.<CRLF>
	051077	115	125	114		.ASCIIZ	'EXPECTING UNDERFLOW, FIU=1.'
6829	051122	105	130	120			
6836	051156				EM157:	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON UNDERFLOW. FIU=1.'
	051156	115	125	114		.ASCIIZ	'(BUT FIU) STATE 331 WENT TO 115 INSTEAD OF 155.'
6837	051243	050	102	125			
6838	051323				EM160:	.ASCII	'MULF (R),A FAILED.<CRLF>
	051323	115	125	114		.ASCII	'EXPECTING UNDERFLOW, FIU=1.'
6839	051346	105	130	120		.ASCIIZ	<CRLF>'(BUT FD) STATE 155 WENT TO 426 INSTEAD OF 427.'
6840	051401	200	050	102			
6841	051461				EM161:	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON UNDERFLOW. FIU=1.'
	051461	115	125	114		.ASCIIZ	'(BUT FIU) STATE 137 WENT TO 115 INSTEAD OF 155.'
6842	051546	050	102	125			
6843	051626				EM162:	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON OVERFLOW. FIV=1.'
	051626	115	125	114		.ASCIIZ	'(BUT FIV) STATE 333 WENT TO 116 INSTEAD OF 136.'
6844	051712	050	102	125			
6845	051772				EM163:	.ASCII	'MULF (R),A FAILED.<CRLF>
	051772	115	125	114		.ASCII	'EXPECTING OVERFLOW, FIV=1.'
6846	052015	105	130	120		.ASCIIZ	<CRLF>'(BUT FD) STATE 700 WENT TO 426 INSTEAD OF 427.'
6847	052047	200	050	102			
6848	052127				EM164:	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON OVERFLOW. FIV=1.'
	052127	115	125	114		.ASCIIZ	'(BUT FIV) STATE 133 WENT TO 116 INSTEAD OF 136.'
6849	052213	050	102	125			
6850	052273	106	120	123	EM55:	.ASCIIZ	'FPS BAD AFTER MODF (R),A.'
6851	052325	115	117	104	EM53:	.ASCIIZ	'MODF (R),A FRACTION BAD.'
6852	052356	115	117	104	EM54:	.ASCIIZ	'MODF (R),A INTEGER BAD.'
6859	052406				EM56:	.ASCII	'MODF (R),A FRACTION BAD.<CRLF>
	052406	115	117	104		.ASCIIZ	'ACO DID NOT GET 0 IN STATE 424.'
6860	052437	101	103	060			
6861	052477				EM57:	.ASCII	'MODF (R),A INTEGER BAD.<CRLF>
	052477	115	117	104		.ASCIIZ	'AC1 DID NOT GET 0 IN STATE 142.'
6862	052527	101	103	061			
6863	052567				EM60:	.ASCII	'MODF (R),A INTEGER BAD.<CRLF>
	052567	115	117	104		.ASCIIZ	'AC1 DID NOT GET THE INTEGER IN STATE 134.'
6864	052617	101	103	061			
6865	052671				EM61:	.ASCII	'MODF (R),A FRACTION BAD.<CRLF>
	052671	115	117	104		.ASCII	'A BAD CONSTANT WAS USED (NOT 24) IN STATE 046.'
6866	052722	101	040	102		.ASCIIZ	<CRLF>'OR (BUT NBIT) STATE 525 WENT TO 050 INSTEAD OF 150.'
6867	053000	200	117	122			
6868	053065				EM62:	.ASCII	'MODF (R),A FRACTION BAD.<CRLF>
	053065	115	117	104		.ASCII	'A BAD CONSTANT WAS USED (NOT 24) IN STATE 046.'
6869	053116	101	040	102		.ASCIIZ	<CRLF>'OR (BUT NBIT) STATE 525 WENT TO 150 INSTEAD OF 050.'
6870	053174	200	117	122			
6871	053261				EM63:		

6872	053261	115	117	104		.ASCII	'MODF (R),A FRACTION BAD.'	<CRLF>
6873	053312	050	102	125	EM64:	.ASCIIZ	'(BUT ZBT) STATE 532 WENT TO 102 INSTEAD OF 122.'	
6874	053372	115	117	104		.ASCII	'MODF (R),A FRACTION BAD.'	<CRLF>
6875	053423	050	102	125	EM65:	.ASCIIZ	'(BUT ENBT EZBT) STATE 041 WENT TO 046 INSTEAD OF 246.'	
6876	053511	115	117	104		.ASCII	'MODF (R),A FRACTION BAD.'	<CRLF>
6877	053542	050	102	125	EM66:	.ASCIIZ	'(BUT FT) STATE 126 SHOULD HAVE GONE TO 133. FT=0.'	
6878	053624	115	117	104		.ASCII	'MODF (R),A FRACTION BAD.'	<CRLF>
6879	053655	123	111	107	EM67:	.ASCIIZ	'SIGN BIT BAD.'	
6880	053673	115	117	104		.ASCII	'MODF (R),A FRACTION BAD.'	<CRLF>
6881	053723	123	111	107	EM70:	.ASCIIZ	'SIGN BIT BAD IN STATE 733.'	
6882	053756	115	117	104	EM71:	.ASCIIZ	'MODD (R),A FRACTION BAD.'	
6883	054007	115	117	104	EM72:	.ASCIIZ	'MODD (R),A INTEGER BAD.'	
6884	054037	106	120	123	EM73=EM72	.ASCIIZ	'FPS BAD AFTER MODD (R),A.'	
6891	054071	054037			EM74:			
6892	054071	115	117	104		.ASCII	'MODD (R),A INTEGER BAD.'	<CRLF>
6893	054121	050	102	125	EM75:	.ASCIIZ	'(BUT FC) STATE 231 WENT TO 142 INSTEAD OF 143.'	
6894	054200	115	117	104		.ASCII	'MODD (R),A FRACTION BAD.'	<CRLF>
6895	054231	101	103	060	EM76:	.ASCIIZ	'ACO GETS 0 IN STATE 425 FAILED.'	
6896	054271	115	117	104		.ASCII	'MODD (R),A INTEGER BAD.'	<CRLF>
6897	054321	101	103	061	EM77:	.ASCIIZ	'AC1 GETS 0 IN STATE 143 FAILED.'	
6898	054361	115	117	104		.ASCII	'MODD (R),A FRACTION BAD.'	<CRLF>
6899	054412	050	102	125	EM100:	.ASCIIZ	'(BUT FD) STATE 526 WENT TO 134 INSTEAD OF 135.'	
6900	054471	115	117	104		.ASCII	'MODD (R),A INTEGER BAD.'	<CRLF>
6901	054521	123	111	107	EM101:	.ASCIIZ	'SIGN BIT BAD IN STATE 526.'	
6902	054554	115	117	104		.ASCII	'MODD (R),A FRACTION BAD.'	<CRLF>
6903	054605	101	040	102	EM102:	.ASCII	'A BAD CONSTANT WAS USED (NOT 56) IN STATE 046.'	
6904	054663	200	117	122		.ASCIIZ	<CRLF>'OR (BUT NBIT) STATE 525 WENT TO 050 INSTEAD OF 151.'	
6905	054750	115	117	104		.ASCII	'MODD (R),A FRACTION BAD.'	<CRLF>
6906	055001	101	040	102	EM103:	.ASCII	'A BAD CONSTANT WAS USED (NOT 56) IN STATE 046.'	
6907	055057	200	117	122		.ASCIIZ	<CRLF>'OR (BUT NBIT) STATE 525 WENT TO 150 INSTEAD OF 050.'	
6908	055144	115	117	104		.ASCII	'MODD (R),A FRACTION BAD.'	<CRLF>
6909	055175	050	102	125	EM104:	.ASCIIZ	'(BUT ZBIT) STATE 532 WENT TO 122 INSTEAD OF 102.'	
6910	055256	115	117	104		.ASCII	'MODD (R),A INTEGER BAD.'	<CRLF>
6911	055306	123	105	124	EM105:	.ASCII	'SET INTEGER IN AC1 FAILED.'	
6912	055340	200	117	122		.ASCIIZ	<CRLF>'OR (BUT FD) STATE 733 WENT TO 156 INSTEAD OF 157.'	
6913	055423	115	117	104		.ASCII	'MODD (R),A INTEGER BAD.'	<CRLF>
6914	055453	050	102	125	EM106:	.ASCIIZ	'(BUT FD) STATE 122 WENT TO 424 INSTEAD OF 425.'	
6915	055532	115	117	104		.ASCII	'MODD (R),A INTEGER BAD.'	<CRLF>
6916	055562	050	102	125	EM107:	.ASCIIZ	'(BUT FD) STATE 246 WENT TO 126 INSTEAD OF 127.'	
6917	055641	115	117	104		.ASCII	'MODD (R),A INTEGER BAD.'	<CRLF>
6917	055671	050	102	125		.ASCIIZ	'(BUT FD) STATE 446 WENT TO 126 INSTEAD OF 127.'	

ERROR MESSAGES

6918	055750				EM110:	.ASCII 'MODD (R),A FRACTION BAD.<CRLF>
	055750	115	117	104		.ASCIZ '(BUT FT) STATE 127 WENT TO 313 INSTEAD OF 113.'
6919	056001	050	102	125		
6932	056060				EM165:	.ASCII /MODF (R),A FRACTION BAD. RESULT OVER OR UNDER FLOW./
	056060	115	117	104		.BYTE 0
6933	056143	000				
6934	056144				EM166:	.ASCII /MODF (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	056144	115	117	104		.BYTE 0
6935	056226	000				
6936	056227				EM167:	.ASCII /FPS BAD AFTER MODF (R),A./
	056227	106	120	123		.BYTE 0
6937	056260	000				
6938	056261				EM170:	.ASCII /FEC BAD AFTER MODF (R),A./
	056261	106	105	103		.ASCIZ 'EXPECTING UNDERFLOW, FEC=12.'
6939	056312	105	130	120		
6940	056347				EM171:	.ASCII /MODF (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	056347	115	117	104		.ASCIZ <CRLF>'AC1 GETS 0 IN STATE 126 FAILED.'
6941	056431	200	101	103		
6942	056472				EM172:	.ASCII /FEC BAD AFTER MODF (R),A./
	056472	106	105	103		.ASCIZ 'EXPECTING OVERFLOW, FEC=10.'
6943	056523	105	130	120		
6944	056557				EM173:	.ASCII /MODF (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	056557	115	117	104		.ASCIZ <CRLF>'(BUT FIV FD) STATE 520 WENT TO 142 INSTEAD OF 162.'
6945	056641	200	050	102		
6946	056725				EM174:	.ASCII /MODF (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	056725	115	117	104		.ASCIZ <CRLF>'(BUT FIV FD) STATE 520 WENT TO 162 INSTEAD OF 142.'
6947	057007	200	050	102		
6948	057073				EM175:	.ASCII /MODF (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	057073	115	117	104		.ASCIZ <CRLF>'SIGN BAD IN STATE 517.'
6949	057155	200	123	111		
6950	057205				EM176:	.ASCII /MODD (R),A FRACTION BAD. RESULT OVER OR UNDER FLOW./
	057205	115	117	104		.BYTE 0
6951	057270	000				
6952	057271	120	117	127	EM177:	.ASCIZ !POWER MONITOR BIT FOUND SET!
6953	057325				EM200:	.ASCII /FPS BAD AFTER MODD (R),A./
	057325	106	120	123		.BYTE 0
6954	057356	000				
6955	057357				EM201:	.ASCII /FEC BAD AFTER MODD (R),A./
	057357	106	105	103		.ASCIZ <CRLF>'EXPECTING UNDERFLOW, FEC=12.'
6956	057410	200	105	130		
6957	057446				EM202:	.ASCII /MODD (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	057446	115	117	104		.ASCIZ <CRLF>'(BUT FD) STATE 241 WENT TO 126 INSTEAD OF 127.'
6958	057530	200	050	102		
6959	057610				EM203:	.ASCII /MODD (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	057610	115	117	104		.ASCIZ <CRLF>'(BUT FD) STATE 047 WENT TO 126 INSTEAD OF 127.'
6960	057672	200	050	102		
6961	057752				EM204:	.ASCII /FEC BAD AFTER MODD (R),A./
	057752	106	105	103		.ASCIZ <CRLF>'EXPECTING OVERFLOW, FEC=10.'
6962	060003	200	105	130		
6963	060040				EM205:	.ASCII /MODD (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	060040	115	117	104		.ASCIZ <CRLF>'(BUT FIV FD) STATE 520 WENT TO 162 INSTEAD OF 163.'
6964	060122	200	050	102		
6965	060206				EM206:	.ASCII /MODD (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	060206	115	117	104		.ASCIZ <CRLF>'(BUT FIV FD) STATE 520 WENT TO 162 INSTEAD OF 143.'
6966	060270	200	050	102		
6967						
6968						

;*

Line	Code	Col 1	Col 2	Col 3	Col 4	Message
7061	060354					EM207: .ASCIZ /ADD (R),A PRODUCED A BAD RESULT./
	060354	101	104	104		
7062	060416					EM210: .ASCIZ /THE FPS WAS BAD AFTER ADD (R),A./
	060416	124	110	105		
7063	060460	101	104	104		EM211: .ASCII 'ADD (R),A FAILED IN THE ROUND\TRUNK FLOWS.'
7064	060533	200	127	105		.ASCII <CRLF>'WENT FROM STATE 663 TO 313,'<CRLF>
7065	060570	111	116	123		.ASCIZ 'INSTEAD OF FROM 663 TO 353.'
7090	060624					EM212: .ASCII 'ADD (R),A FAILED IN THE ROUND\TRUNK FLOWS.'
	060624	101	104	104		.ASCII <CRLF>'THE FPS WAS BAD.'<CRLF>
	060677	200	124	110		.ASCII 'DID NOT TAKE THE PATH:'<CRLF>
	060721	104	111	104		.ASCIZ /FROM STATE 664, TO 505, TO 251./
	060750	106	122	117		
7091	061010					EM213: .ASCII 'ADD (R),A FAILED IN THE ROUND\TRUNK FLOWS.'
	061010	101	104	104		.ASCII <CRLF>'THE FPS WAS BAD.'<CRLF>
	061063	200	124	110		.ASCII 'DID NOT TAKE THE PATH:'<CRLF>
	061105	104	111	104		.ASCIZ /FROM STATE 664, TO 505, TO 253./
	061134	106	122	117		
7092	061174					EM214: .ASCII 'ADD (R),A FAILED IN THE ROUND\TRUNK FLOWS.'
	061174	101	104	104		.ASCII <CRLF>'THE FPS WAS BAD.'<CRLF>
	061247	200	124	110		.ASCII 'DID NOT TAKE THE PATH:'<CRLF>
	061271	104	111	104		.ASCIZ /FROM STATE 664, TO 705, TO 735./
	061320	106	122	117		
7093	061360					EM215: .ASCII 'ADD (R),A FAILED IN THE ROUND\TRUNK FLOWS.'
	061360	101	104	104		.ASCII <CRLF>'THE FPS WAS BAD.'<CRLF>
	061433	200	124	110		.ASCII 'DID NOT TAKE THE PATH:'<CRLF>
	061455	104	111	104		.ASCIZ /FROM STATE 664, TO 705, TO 737./
	061504	106	122	117		
7094	061544	124	110	105		EM216: .ASCII 'THE (BUT FIU FORK IN THE OVER\UNDER FLOWS FAILED. FIU =1.'
7095	061635	200	127	105		.ASCII <CRLF>'WENT FROM STATE 331 TO 115.'<CRLF>
7096	061672	111	116	123		.ASCIZ 'INSTEAD OF FROM 331 TO 155.'
7097	061726	101	104	104		EM217: .ASCIZ 'ADD (R)A TRAPPED TO 244,.. FID=1.'
7098	061770					EM220: .ASCII /ADD (R),A TRAPPED TO 244./<CRLF>
	061770	101	104	104		.ASCII 'THE RESULT WAS AN OVERFLOW CONDITION BUT FIV= 0.'
	062023	124	110	105		.ASCIZ <CRLF>/(BUT FIV) STATE 133 WENT TO 136 INSTEAD OF 116./
	062103	200	050	102		.ASCIZ /INSTEAD OF FROM 133 TO 116./
	062164	111	116	123		
7099	062220					EM221: .ASCII /ADD (R),A FAILED TO TRAP TO 244./<CRLF>
	062220	101	104	104		.ASCII 'THE RESULT WAS A OVERFLOW CONDITION AND FIV=1.'<CRLF>
	062262	124	110	105		.ASCII /THE (BUT FIV) FORK FAILED./<CRLF>
	062341	124	110	105		.ASCII /WENT FROM STATE 133 TO 116./<CRLF>
	062374	127	105	116		.ASCIZ /INSTEAD OF FROM 133 TO 136./
	062430	111	116	123		
7100	062464					EM222: .ASCII /ADD (R),A TRAPPED TO 244./<CRLF>
	062464	101	104	104		.ASCII 'THE RESULT WAS AN UNDERFLOW CONDITION BUT FIU= 0.'
	062517	124	110	105		.ASCIZ <CRLF>/(BUT FIU) STATE 331 WENT TO 155 INSTEAD OF 115./
	062600	200	050	102		.ASCIZ /INSTEAD OF FROM 331 TO 115./
	062661	111	116	123		
7101	062715					EM223: .ASCII /ADD (R),A FAILED TO TRAP TO 244./<CRLF>
	062715	101	104	104		.ASCII 'THE RESULT WAS A UNDERFLOW CONDITION AND FIU=1.'<CRLF>
	062757	124	110	105		.ASCII /THE (BUT FIU) FORK FAILED./<CRLF>
	063037	124	110	105		.ASCII /WENT FROM STATE 331 TO 115./<CRLF>
	063072	127	105	116		.ASCIZ /INSTEAD OF FROM 331 TO 155./
	063126	111	116	123		
7102	063162					EM224: .ASCII /ADD (R),A TRAPPED TO 244./<CRLF>
	063162	101	104	104		.ASCII 'THE RESULT WAS AN UNDERFLOW CONDITION BUT FIU= 0.'
	063215	124	110	105		.ASCIZ <CRLF>/(BUT FIU) STATE 137 WENT TO 155 INSTEAD OF 115./
	063276	200	050	102		

ERROR MESSAGES

Line	Address	PC	PS	AS	Message
7103	063357	111	116	123	EM225: .ASCIZ /INSTEAD OF FROM 137 TO 115./
	063413				.ASCII /ADDD (R),A FAILED TO TRAP TO 244./<CRLF>
	063413	101	104	104	.ASCII 'THE RESULT WAS A UNDERFLOW CONDITION AND FIU=1.'<CRLF>
	063455	124	110	105	.ASCII /THE (BUT FIU) FORK FAILED./<CRLF>
	063535	124	110	105	.ASCII /WENT FROM STATE 137 TO 115./<CRLF>
	063570	127	105	116	.ASCII /INSTEAD OF FROM 137 TO 155./
7104	063624	111	116	123	EM226: .ASCII /ADDD (R),A TRAPPED TO 244./
	063660				.ASCII <CRLF>'BECAUSE OF AN EXPECTED OVERFLOW CONDITION,'<CRLF>
	063660	101	104	104	.ASCII 'BUT THE FEC WAS BAD.'
	063712	200	102	105	EM227: .ASCII /ADDD (R),A TRAPPED TO 244./
7105	063766	102	125	124	.ASCII <CRLF>'BECAUSE OF AN EXPECTED OVERFLOW CONDITION,'<CRLF>
	064013				.ASCII 'BUT THE FPS WAS BAD.'
	064013	101	104	104	EM230: .ASCII /ADDD (R),A TRAPPED TO 244./
	064045	200	102	105	.ASCII <CRLF>'BECAUSE OF AN EXPECTED UNDERFLOW CONDITION,'<CRLF>
	064121	102	125	124	.ASCII 'BUT THE FEC WAS BAD.'
7106	064146				EM231: .ASCII /ADDD (R),A TRAPPED TO 244./
	064146	101	104	104	.ASCII <CRLF>'BECAUSE OF AN EXPECTED UNDERFLOW CONDITION,'<CRLF>
	064200	200	102	105	.ASCII 'BUT THE FPS WAS BAD.'
	064255	102	125	124	EM232=EM210
7107	064302				.ASCII /ADDD (R),A TRAPPED TO 244./
	064302	101	104	104	.ASCII <CRLF>'BECAUSE OF AN EXPECTED UNDERFLOW CONDITION,'<CRLF>
	064334	200	102	105	.ASCII 'BUT THE FPS WAS BAD.'
	064411	102	125	124	
7108		060416			
7109					
7110					
7111					
7116					
7120					
7127					
7137					
7138	064436				EM233: .ASCIZ \LDCFD (R)+,A RESULT INCORRECT.\
	064436	114	104	103	EM234: .ASCII \RO BAD AFTER LDCFD (R)+,A.\
7139	064475				.ASCIZ <CRLF>'A BAD CONSTANT WAS USED.'
	064475	122	060	040	EM235: .ASCIZ \PC BAD AFTER LDCFD #NUM,A. TRAP TO 4.\
	064527	200	101	040	EM236: .ASCIZ \PC BAD AFTER LDCFD #NUM,A.\
7140	064561				.ASCIZ \RO BAD AFTER LDCDF (R)+,A.\
	064561	120	103	040	.ASCIZ <CRLF>'A BAD CONSTANT WAS USED.'
7141	064627				EM240: .ASCIZ \FPS BAD AFTER LDCFD (R)+,A.\
	064627	120	103	040	EM241: .ASCII \LDCFD (R)+,A FAILED.\
7142	064662				.ASCII <CRLF>'THE FD '
	064662	122	060	040	.ASCII 'BIT WAS NOT COMPLIMENTED '
	064714	200	101	040	.ASCIZ 'IN STATE 017.'
7143	064746				EM242: .ASCIZ \FPS BAD AFTER LDCDF (R)+,A.\
	064746	106	120	123	EM243: .ASCII \LDCDF (R)+,A FAILED.\
7144	065002				.ASCII <CRLF>'THE FD '
	065002	114	104	103	.ASCII 'BIT WAS NOT COMPLIMENTED '
	065026	200	124	110	.ASCIZ 'IN STATE 017.'
	065036	102	111	124	
	065067	111	116	040	
7145	065105				
	065105	106	120	123	
7146	065141				
	065141	114	104	103	
	065165	200	124	110	
	065175	102	111	124	
	065226	111	116	040	

7177						.SBTTL		ERROR DATA TABLE HEADERS	
7178									
7179	067106	040	040	124	DH1:	.ASCII	' TEST.'	<TAB>'CALL AT PC.'	<TAB>'ERROR AT PC.'
7180	067147	107	117	124		.ASCIIZ	'GOT FPS.'	<TAB>'EXPECTED FPS.'	
7181	067176	040	040	124	DH2:	.ASCIIZ	' TEST.'	<TAB>'CALL AT PC.'	<TAB>'ERROR AT PC.'
7182	067106				DH3=	DH1			
7183	067106				DH4=	DH1			
7184	067106				DH5=	DH1			
7185	067106				DH6=	DH1			
7186	067106				DH7=	DH1			
7187	067106				DH10=	DH1			
7188	067106				DH11=	DH1			
7189	067106				DH12=	DH1			
7190	067106				DH13=	DH1			
7191	067106				DH14=	DH1			
7192	067106				DH15=	DH1			
7193	067106				DH16=	DH1			
7194	067237	040	040	124	DH17:	.ASCIIZ	' TEST.'	<TAB>'PC OF CALL.'	<TAB>'PC OF ERROR.'
7195	067106				DH20=	DH1			<TAB>'FEC.'
7196	067312	040	040	124	DH21:	.ASCII	' TEST.'	<TAB>'PC OF CALL.'	<TAB>'PC OF ERROR.'
7197	067352	107	117	124		.ASCIIZ	'GOT FEC.'	<TAB>'EXPECTED FEC.'	
7198	067401	040	040	124	DH22:	.ASCIIZ	' TEST.'	<TAB>'PC OF CALL.'	<TAB>'PC OF ERROR.'
7199	067106				DH23=	DH1			<TAB>'FPS.'
7200	067106				DH32=	DH1			
7201	067106				DH24=	DH1			
7202	067106				DH25=	DH1			
7203	067106				DH26=	DH1			
7204	067106				DH27=	DH1			
7205	067106				DH30=	DH1			
7206	067106				DH31=	DH1			
7207	067106				DH33=	DH1			
7208	067106				DH34=	DH1			
7209	067106				DH35=	DH1			
7210	067106				DH36=	DH1			
7211	067106				DH37=	DH1			
7212	067106				DH40=	DH1			
7213	067106				DH41=	DH1			
7214	067106				DH42=	DH1			
7215	067106				DH43=	DH1			
7216	067106				DH44=	DH1			
7217	067106				DH45=	DH1			
7218	067106				DH246=	DH1			
7219	067106				DH46=	DH1			
7220	067106				DH47=	DH1			
7221	067106				DH50=	DH1			
7222	067106				DH51=	DH1			
7223	067106				DH52=	DH1			
7224	067106				DH111=	DH1			
7225	067106				DH112=	DH1			
7226	067106				DH113=	DH1			
7227	067106				DH114=	DH1			
7228	067447	040	040	124	DH115:	.ASCII	' TEST.'	<TAB>'PC OF CALL.'	<TAB>'PC OF ERROR.'
7229	067510	107	117	124		.ASCIIZ	'GOT FEC.'	'GOT FPS.'	'EXPECTED FPS.'
7230	067447				DH116=	DH115			
7231	067447				DH117=	DH115			
7232	067447				DH120=	DH115			
7233	067447				DH121=	DH115			

7234	067447	DH122=DH115
7235	067106	DH123=DH1
7236	067106	DH124=DH1
7237	067106	DH125=DH1
7238	067106	DH126=DH1
7239	067447	DH127=DH115
7240	067447	DH130=DH115
7241	067447	DH131=DH115
7242	067106	DH132=DH1
7243	067447	DH133=DH115
7244	067447	DH134=DH115
7245	067106	DH135=DH1
7246	067447	DH136=DH115
7247	067447	DH137=DH115
7248	067447	DH140=DH115
7249	067447	DH141=DH115
7250	067447	DH142=DH115
7251	067447	DH143=DH115
7252	067447	DH144=DH115
7253	067106	DH145=DH1
7254	067106	DH146=DH1
7255	067106	DH147=DH1
7256	067106	DH150=DH1
7257	067447	DH151=DH115
7258	067447	DH152=DH115
7259	067447	DH153=DH115
7260	067447	DH154=DH115
7261	067447	DH155=DH115
7262	067447	DH156=DH115
7263	067106	DH157=DH1
7264	067447	DH160=DH115
7265	067106	DH161=DH1
7266	067106	DH162=DH1
7267	067447	DH163=DH115
7268	067106	DH164=DH1
7269	067106	DH53=DH1
7270	067106	DH54=DH1
7271	067106	DH55=DH1
7272	067106	DH56=DH1
7273	067106	DH57=DH1
7274	067106	DH60=DH1
7275	067106	DH61=DH1
7276	067106	DH62=DH1
7277	067106	DH63=DH1
7278	067106	DH64=DH1
7279	067106	DH65=DH1
7280	067106	DH66=DH1
7281	067106	DH67=DH1
7282	067106	DH70=DH1
7283	067106	DH71=DH1
7284	067106	DH72=DH1
7285	067106	DH73=DH1
7286	067106	DH74=DH1
7287	067106	DH75=DH1
7288	067106	DH76=DH1
7289	067106	DH77=DH1
7290	067106	DH100=DH1

7291	067106				DH101=DH1	
7292	067106				DH102=DH1	
7293	067106				DH103=DH1	
7294	067106				DH104=DH1	
7295	067106				DH105=DH1	
7296	067106				DH106=DH1	
7297	067106				DH107=DH1	
7298	067106				DH110=DH1	
7299	067447				DH165=DH115	
7300	067447				DH166=DH115	
7301	067447				DH167=DH115	
7302	067447				DH170=DH115	
7303	067447				DH171=DH115	
7304	067447				DH172=DH115	
7305	067447				DH173=DH115	
7306	067447				DH174=DH115	
7307	067447				DH175=DH115	
7308	067447				DH176=DH115	
7309	067546	040	040	124	DH177: .ASCIZ	' TEST.<TAB>IERR PC<TAB>ICPU ERROR REGISTER'
7310	067447				DH200=DH115	
7311	067447				DH201=DH115	
7312	067447				DH202=DH115	
7313	067447				DH203=DH115	
7314	067447				DH204=DH115	
7315	067447				DH205=DH115	
7316	067447				DH206=DH115	
7317	067607	040	040	124	DH220: .ASCIZ	' TEST.<TAB>PC OF CALL.<TAB>PC OF TRAP.'
7318	067647	040	040	124	DH207: .ASCII	' TEST.<TAB>PC OF CALL.<TAB>PC OF ERROR.'
7319	067707	011	107	117	.ASCIZ	<TAB>'GOT FPS.<TAB>'EXPECTED FPS.'
7320	067737	040	040	124	DH210: .ASCIZ	' TEST.<TAB>PC OF CALL.<TAB>PC OF ERROR.'
7321	067737				DH211=DH210	
7322	067647				DH212=DH207	
7323	067647				DH213=DH207	
7324	067647				DH214=DH207	
7325	067647				DH215=DH207	
7326	067737				DH216=DH210	
7327	070000	040	040	124	DH217: .ASCII	' TEST.<TAB>PC OF CALL.<TAB>PC OF ERROR.'
7328	070040	011	106	120	.ASCIZ	<TAB>'FPS.<TAB>'FEC.'
7329	067737				DH221=DH210	
7330	067607				DH222=DH220	
7331	067737				DH223=DH210	
7332	067607				DH224=DH220	
7333	067737				DH225=DH210	
7334	070053	040	040	124	DH226: .ASCII	' TEST.<TAB>PC OF CALL.<TAB>PC OF TRAP.'
7335	070112	011	107	117	.ASCIZ	<TAB>'GOT FEC.<TAB>'EXPECTED FEC.'
7336	070142	040	040	124	DH227: .ASCII	' TEST.<TAB>PC OF CALL.<TAB>PC OF TRAP.'
7337	070201	011	107	117	.ASCIZ	<TAB>'GOT FPS.<TAB>'EXPECTED FPS.'
7338	070053				DH230=DH226	
7339	070142				DH231=DH227	
7340	070142				DH232=DH227	
7341						
7342						
7343	070231	040	040	124	DH233: .ASCIZ	' TEST.<TAB>PC OF CALL.<TAB>PC OF ERROR.'
7344						
7345	070272	040	040	124	DH234: .ASCII	' TEST.<TAB>PC OF CALL.<TAB>PC OF ERROR.'
7346	070332	011	107	117	.ASCIZ	<TAB>'GOT RO.<TAB>'EXPECTED RO.'
7347						

7348	070360	040	040	124	DH235:	.ASCII	' TEST.' <tab>'PC OF CALL.'<tab></tab></tab>
7349	070404	120	103	040		.ASCII	'PC OF TRAP.' <tab></tab>
7350							
7351	070420	040	040	124	DH236:	.ASCII	' TEST.' <tab>'PC OF CALL.'<tab></tab></tab>
7352	070444	120	103	040		.ASCII	'PC OF ERROR.' <tab>'GOT PC.'</tab>
7353	070470	011	105	130		.ASCIZ	<TAB>'EXPECTED PC.'
7354							
7355	070272						DH237=DH234
7356							
7357	070506	040	040	124	DH240:	.ASCII	' TEST.' <tab>'PC OF CALL.'<tab></tab></tab>
7358	070532	120	103	040		.ASCII	'PC OF ERROR.' <tab></tab>
7359	070547	107	117	124		.ASCIZ	'GOT FPS.' <tab>'EXPECTED FPS.'</tab>
7360							
7361	070231						DH241=DH233
7362	070506						DH242=DH240
7363	070231						DH243=DH233
7364	070231						DH244=DH233
7365	070231						DH245=DH233
7366	070576	040	040	124	DH247:	.ASCIZ	' TEST.' <tab>'PC OF CALL.'<tab>'PC OF TRAP.'<tab>'FEC.'</tab></tab></tab>
7367	070643	040	040	124	DH250:	.ASCIZ	' TEST.' <tab>'PC OF CALL.'<tab>'PC OF TRAP.'</tab></tab>
7368	070643						DH251=DH250
7369							
7370	067176						DH252=DH2
7371	067106						DH253=DH1
7372	067106						DH254=DH1
7373	067106						DH255=DH1
7374	067106						DH256=DH1
7375	067106						DH257=DH1
7376	067106						DH260=DH1
7377	067106						DH261=DH1
7378	067106						DH262=DH1
7379	067106						DH263=DH1
7380	067106						DH264=DH1
7381	067106						DH265=DH1
7382	070703	040	040	124	DH266:	.ASCIZ	' TEST.' <tab>'PC OF CALL.'<tab>'PC OF TRAP.'</tab></tab>
7383	067447						DH267=DH115

Line	Key	Code	Mode	DF	Type	Specifiers
7384					.SBTTL	DATA FORMAT SPECIFIERS
7385	070743	004	000	005	DF1:	.BYTE 4,0,5,0,5,0,5,0,5,5,3,5,5,3
7386	070761	004	000	005	DF2:	.BYTE 4,0,5,0,5,5,3,5,5,3
7387		070743			DF3=DF1	
7388		070743			DF4=DF1	
7389		070743			DF5=DF1	
7390		070743			DF6=DF1	
7391		070743			DF7=DF1	
7392		070743			DF10=DF1	
7393		070743			DF11=DF1	
7394		070743			DF12=DF1	
7395		070743			DF13=DF1	
7396		070743			DF14=DF1	
7397		070743			DF15=DF1	
7398		070743			DF16=DF1	
7399	070773	004	000	005	DF17:	.BYTE 4,0,5,0,5,0,0
7400	071002	004	000	005	DF20:	.BYTE 4,0,5,0,5,0,5,0
7401		071002			DF21=DF20	
7402		071002			DF22=DF20	
7403	071012	004	000	005	DF23:	.BYTE 4,0,5,0,5,0,5,0,5,5,2,5,5,2,5,5,2,5,5,2
7404		071012			DF24=DF23	
7405		071012			DF32=DF23	
7406		071012			DF25=DF23	
7407		071012			DF26=DF23	
7408		071012			DF27=DF23	
7409		071012			DF30=DF23	
7410		071012			DF31=DF23	
7411	071036	004	000	005	DF33:	.BYTE 4,0,5,0,5,0,5,0,5,5,3,5,5,3,5,5,3,5,5,3
7412		071036			DF34=DF33	
7413		071036			DF35=DF33	
7414		071036			DF36=DF33	
7415		071012			DF37=DF23	
7416		071012			DF40=DF23	
7417		071012			DF41=DF23	
7418		071012			DF42=DF23	
7419		071012			DF43=DF23	
7420		071012			DF44=DF23	
7421		071012			DF45=DF23	
7422		071036			DF246=DF33	
7423		071036			DF46=DF33	
7424		071036			DF47=DF33	
7425		071036			DF50=DF33	
7426		071036			DF51=DF33	
7427		071036			DF52=DF33	
7428		071012			DF111=DF23	
7429		071012			DF112=DF23	
7430		071012			DF113=DF23	
7431		071012			DF114=DF23	
7432	071062	004	000	005	DF115:	.BYTE 4,0,5,0,5,0,0,0,5,5,2,5,5,2,5,5,2,5,5,2
7433		071062			DF116=DF115	
7434		071062			DF117=DF115	
7435		071062			DF120=DF115	
7436		071062			DF121=DF115	
7437		071062			DF122=DF115	
7438		071036			DF123=DF33	
7439		071036			DF124=DF33	
7440		071036			DF125=DF33	

7441		071036			DF126=DF33	
7442	071106	004	000	005	DF127: .BYTE	4.0.5.0.5.0.0.0.5.5.3.5.5.3.5.5.3.5.5.3
7443		071106			DF130=DF127	
7444		071106			DF131=DF127	
7445		071036			DF132=DF33	
7446		071106			DF133=DF127	
7447		071106			DF134=DF127	
7448		071036			DF135=DF33	
7449		071106			DF136=DF127	
7450		071062			DF137=DF115	
7451		071062			DF140=DF115	
7452		071062			DF141=DF115	
7453		071062			DF142=DF115	
7454		071062			DF143=DF115	
7455		071062			DF144=DF115	
7456		071012			DF145=DF23	
7457		071012			DF146=DF23	
7458		071012			DF147=DF23	
7459		071012			DF150=DF23	
7460		071106			DF151=DF127	
7461		071106			DF152=DF127	
7462		071106			DF153=DF127	
7463		071106			DF154=DF127	
7464		071106			DF155=DF127	
7465		071106			DF156=DF127	
7466		071036			DF157=DF33	
7467		071106			DF160=DF127	
7468		071036			DF161=DF33	
7469		071036			DF162=DF33	
7470		071106			DF163=DF127	
7471		071036			DF164=DF33	
7472	071132	004	000	005	DF53: .BYTE	4.0.5.0.5.0.5.0.5.5.2.5.5.2.5.5.2.5.5.2.5.5.2
7473		071132			DF54=DF53	
7474		071132			DF55=DF53	
7475		071132			DF56=DF53	
7476		071132			DF57=DF53	
7477		071132			DF60=DF53	
7478		071132			DF61=DF53	
7479		071132			DF62=DF53	
7480		071132			DF63=DF53	
7481		071132			DF64=DF53	
7482		071132			DF65=DF53	
7483		071132			DF66=DF53	
7484		071132			DF67=DF53	
7485	071164	004	000	005	DF70: .BYTE	4.0.5.0.5.0.5.0.5.5.3.5.5.3.5.5.3.5.5.3.5.5.3
7486		071164			DF71=DF70	
7487		071164			DF72=DF70	
7488		071164			DF73=DF70	
7489		071164			DF74=DF70	
7490		071164			DF75=DF70	
7491		071164			DF76=DF70	
7492		071164			DF77=DF70	
7493		071164			DF100=DF70	
7494		071164			DF101=DF70	
7495		071164			DF102=DF70	
7496		071164			DF103=DF70	
7497		071164			DF104=DF70	

DATA FORMAT SPECIFIERS

7498		071164			DF105=DF70	
7499		071164			DF106=DF70	
7500		071164			DF107=DF70	
7501		071164			DF110=DF70	
7502	071216	004	000	005	DF165: .BYTE	4,0,5,0,5,0,0,0,5,5,2,5,5,2,5,5,2,5,5,2,5,5,2,5,5,2
7503		071216			DF166=DF165	
7504		071216			DF167=DF165	
7505		071216			DF170=DF165	
7506		071216			DF171=DF165	
7507		071216			DF172=DF165	
7508		071216			DF173=DF165	
7509		071216			DF174=DF165	
7510		071216			DF175=DF165	
7511	071250	004	000	005	DF176: .BYTE	4,0,5,0,5,0,0,0,5,5,3,5,5,3,5,5,3,5,5,3,5,5,3,5,5,3
7512	071302	004	000	000	DF177: .BYTE	4,0,0
7513		071250			DF200=DF176	
7514		071250			DF201=DF176	
7515		071250			DF202=DF176	
7516		071250			DF203=DF176	
7517		071250			DF204=DF176	
7518		071250			DF205=DF176	
7519		071250			DF206=DF176	
7520	071305	004	000	005	DF210: .BYTE	4,0,5,0,5,0,5,0
7521	071315	004	000	005	DF207: .BYTE	4,0,5,0,5,5,5,3,5,5,5,3,5,5,5,3,5,5,5,3
7522		071315			DF211=DF207	
7523	071341	004	000	005	DF212: .BYTE	4,0,5,0,5,0,5,0,5,5,5,3,5,5,5,3,5,5,5,3,5,5,5,3
7524		071341			DF213=DF212	
7525		071341			DF214=DF212	
7526		071341			DF215=DF212	
7527		071315			DF216=DF207	
7528	071371	004	000	005	DF217: .BYTE	4,0,5,0,5,0,0
7529		071315			DF220=DF207	
7530		071315			DF221=DF207	
7531		071315			DF222=DF207	
7532		071315			DF223=DF207	
7533		071315			DF224=DF207	
7534		071315			DF225=DF207	
7535		071341			DF226=DF212	
7536		071341			DF227=DF212	
7537		071341			DF230=DF212	
7538		071341			DF231=DF212	
7539		071341			DF232=DF212	
7540	071400	004	000	005	DF233: .BYTE	4,0,5,0,5,5,3,5,5,3,5,5,3
7541	071415	004	000	005	DF234: .BYTE	4,0,5,0,5,0,0
7542						
7543	071424	004	000	005	DF235: .BYTE	4,0,5,0
7544		071415			DF236=DF234	
7545		071415			DF237=DF234	
7546		071415			DF240=DF234	
7547		071400			DF241=DF233	
7548		071415			DF242=DF234	
7549		071400			DF243=DF233	
7550		071400			DF244=DF233	
7551		071400			DF245=DF233	
7552	071430	004	000	005	DF247: .BYTE	4,0,5,0,5,0
7553		071430			DF250=DF247	
7554		071430			DF251=DF247	

DATA FORMAT SPECIFIERS

7555							
7556	071436	004	000	005	DF252: .BYTE	4,0,5,0	
7557	071442	004	000	005	DF253: .BYTE	4,0,5,0,5,0,5,0,5,5,0,5,5,0,5,5,0,5,5,0,5,5,0,5,5,3,5,5,3	
7558		071442			DF254=DF253		
7559		071442			DF255=DF253		
7560		071442			DF256=DF253		
7561		071442			DF257=DF253		
7562		071442			DF260=DF253		
7563		071442			DF261=DF253		
7564		071442			DF262=DF253		
7565		071442			DF263=DF253		
7566		071442			DF264=DF253		
7567		071442			DF265=DF253		
7568		071436			DF266=DF252		
7569		071250			DF267=DF176		
7570					.EVEN		

Line	Code	Key	Key	Key	Key	Label	Content
7571						.SB/TL	ERROR DATA TABLES
7572	071474	001232	001234	040005	DT1:	.WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP5,\$TAB,\$TMP6
7573	071514	001313	040012	001240		.WORD	\$CRLF,MS1,\$TMP3,\$CRLF,MS2,\$TMP4,0
7574	071532	001232	001234	040005	DT2:	.WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$CRLF,MS3,\$TMP3,\$CRLF,MS4,\$TMP4,0
7575		071474			DT3=DT1		
7576		071474			DT4=DT1		
7577		071474			DT5=DT1		
7578		071474			DT6=DT1		
7579		071474			DT7=DT1		
7580		071474			DT10=DT1		
7581		071474			DT11=DT1		
7582		071474			DT12=DT1		
7583		071474			DT13=DT1		
7584		071474			DT14=DT1		
7585		071474			DT15=DT1		
7586		071474			DT16=DT1		
7587	071560	001232	001234	040005	DT17:	.WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP4,\$TMP5,0
7588	071600	001232	001234	040005	DT20:	.WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP4,\$TAB,\$TMP5,0
7589	071622	001232	001234	040005	DT21:	.WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP4,\$TAB,\$TMP3,0
7590	071644	001232	001234	040005	DT22:	.WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP5,0
7591	071662	001232	001234	040005	DT23:	.WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP7,\$TAB,\$TMP10,\$CRLF,MS1,\$TMP3,\$CRLF,MS2,\$TMP
7592	071716	001313	040125	001244		.WORD	\$CRLF,MS5,\$TMP5,\$CRLF,MS6,\$TMP6,0
7593		071662			DT32=DT23		
7594		071662			DT24=DT23		
7595		071662			DT25=DT23		
7596		071662			DT26=DT23		
7597		071662			DT27=DT23		
7598		071662			DT30=DT23		
7599		071662			DT31=DT23		
7600		071662			DT33=DT23		
7601		071662			DT34=DT23		
7602		071662			DT35=DT23		
7603		071662			DT36=DT23		
7604		071662			DT37=DT23		
7605		071662			DT40=DT23		
7606		071662			DT41=DT23		
7607		071662			DT42=DT23		
7608		071662			DT43=DT23		
7609		071662			DT44=DT23		
7610		071662			DT45=DT23		
7611		071662			DT46=DT23		
7612		071662			DT47=DT23		
7613		071662			DT50=DT23		
7614		071662			DT51=DT23		
7615		071662			DT52=DT23		
7616	071734	001232	001234	040005	DT53:	.WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP11,\$TAB,\$TMP12
7617	071754	001313	040012	001240		.WORD	\$CRLF,MS1,\$TMP3,\$CRLF,MS2,\$TMP4
7618	071770	001313	040233	001244		.WORD	\$CRLF,MS11,\$TMP5,\$CRLF,MS12,\$TMP6
7619	072004	001313	040165	001250		.WORD	\$CRLF,MS7,\$TMP7,\$CRLF,MS10,\$TMP10,0
7620		071734			DT54=DT53		
7621		071734			DT55=DT53		
7622		071734			DT56=DT53		
7623		071734			DT57=DT53		
7624		071734			DT60=DT53		
7625		071734			DT61=DT53		
7626		071734			DT62=DT53		
7627		071734			DT63=DT53		

7628	071734				DT64=DT53
7629	071734				DT65=DT53
7630	071734				DT66=DT53
7631	071734				DT67=DT53
7632	071734				DT70=DT53
7633	071734				DT71=DT53
7634	071734				DT72=DT53
7635	071734				DT73=DT53
7636	071734				DT74=DT53
7637	071734				DT75=DT53
7638	071734				DT76=DT53
7639	071734				DT77=DT53
7640	071734				DT100=DT53
7641	071734				DT101=DT53
7642	071734				DT102=DT53
7643	071734				DT103=DT53
7644	071734				DT104=DT53
7645	071734				DT105=DT53
7646	071734				DT106=DT53
7647	071734				DT107=DT53
7648	071734				DT110=DT53
7649	071662				DT111=DT23
7650	071662				DT112=DT23
7651	071662				DT113=DT23
7652	071662				DT114=DT23
7653	072022	001232	001234	040005	DT115: .WORD
7654	072044	001313	040012	001240	.WORD
7655	072060	001313	040125	001244	.WORD
7656	072022				DT116=DT115
7657	072022				DT117=DT115
7658	072022				DT120=DT115
7659	072022				DT121=DT115
7660	072022				DT122=DT115
7661	071662				DT123=DT23
7662	071662				DT124=DT23
7663	071662				DT125=DT23
7664	071662				DT126=DT23
7665	072022				DT127=DT115
7666	072022				DT130=DT115
7667	072022				DT131=DT115
7668	071662				DT132=DT23
7669	072022				DT133=DT115
7670	072022				DT134=DT115
7671	071662				DT135=DT23
7672	072022				DT136=DT115
7673	072022				DT137=DT115
7674	072022				DT140=DT115
7675	072022				DT141=DT115
7676	072022				DT142=DT115
7677	072022				DT143=DT115
7678	072022				DT144=DT115
7679	071662				DT145=DT23
7680	071662				DT146=DT23
7681	071662				DT147=DT23
7682	071662				DT150=DT23
7683	072022				DT151=DT115
7684	072022				DT152=DT115

STMP0,STMP1,STAB,STMP2,STAB,STMP11,STMP7,STAB,STMP10
\$CRLF,MS1,STMP3,\$CRLF,MS2,STMP4
\$CRLF,MS5,STMP5,\$CRLF,MS6,STMP6,0

7685		072022			DT153=DT115	
7686		072022			DT154=DT115	
7687		072022			DT155=DT115	
7688		072022			DT156=DT115	
7689		071662			DT157=DT23	
7690		072022			DT160=DT115	
7691		071662			DT161=DT23	
7692		071662			DT162=DT23	
7693		072022			DT163=DT115	
7694		071662			DT164=DT23	
7695	072076	001232	001234	040005	DT165: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP13,\$TMP11,\$TMP12
7696	072116	001313	040012	001240	.WORD	\$CRLF,\$MS1,\$TMP3,\$CRLF,\$MS2,\$TMP4
7697	072132	001313	040233	001244	.WORD	\$CRLF,\$MS11,\$TMP5,\$CRLF,\$MS12,\$TMP6
7698	072146	001313	040165	001250	.WORD	\$CRLF,\$MS7,\$TMP7,\$CRLF,\$MS10,\$TMP10,0
7699		072076			DT166=DT165	
7700		072076			DT167=DT165	
7701		072076			DT170=DT165	
7702		072076			DT171=DT165	
7703		072076			DT172=DT165	
7704		072076			DT173=DT165	
7705		072076			DT174=DT165	
7706		072076			DT175=DT165	
7707		072076			DT176=DT165	
7708	072164	001232	001234	034422	DT177: .WORD	\$TMP0,\$TMP1,\$CPSAVE,0
7709		072076			DT200=DT165	
7710		072076			DT201=DT165	
7711		072076			DT202=DT165	
7712		072076			DT203=DT165	
7713		072076			DT204=DT165	
7714		072076			DT205=DT165	
7715		072076			DT206=DT165	
7716	072174	001232	001234	040005	DT207: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$CRLF,\$MS41,\$CRLF,\$TMP3
7717	072214	001313	040400	001313	.WORD	\$CRLF,\$MS42,\$CRLF,\$TMP4,\$CRLF,\$MS43,\$CRLF,\$TMP5
7718	072234	001313	040433	001313	.WORD	\$CRLF,\$MS44,\$CRLF,\$TMP6,0
7719	072246	001232	001234	040005	DT210: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP3
7720	072262	040005	001242	000000	.WORD	\$TAB,\$TMP4,0
7721		072174			DT211=DT207	
7722	072270	001232	001234	040005	DT212: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP10,\$TAB,\$TMP11
7723	072310	001313	040354	001313	.WORD	\$CRLF,\$MS41,\$CRLF,\$TMP3,\$CRLF,\$MS42,\$CRLF,\$TMP4
7724	072330	001313	040416	001313	.WORD	\$CRLF,\$MS43,\$CRLF,\$TMP5,\$CRLF,\$MS44,\$CRLF,\$TMP6,0
7725		072270			DT213=DT212	
7726		072270			DT214=DT212	
7727		072270			DT215=DT212	
7728		072174			DT216=DT207	
7729	072352	001232	001234	040005	DT217: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP3,\$TMP4,0
7730		072174			DT220=DT207	
7731		072174			DT221=DT207	
7732		072174			DT222=DT207	
7733		072174			DT223=DT207	
7734		072174			DT224=DT207	
7735		072174			DT225=DT207	
7736		072270			DT226=DT212	
7737		072270			DT227=DT212	
7738		072270			DT230=DT212	
7739		072246			DT231=DT210	
7740		072174			DT232=DT207	
7741	072372	001232	001234	040005	DT233: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$CRLF

7742	072404	040302	001244	001313	.WORD	MS37,\$TMP5,\$CRLF,MS40,\$TMP6
7743	072416	001313	040354	001250	.WORD	\$CRLF,MS41,\$TMP7,0
7744	072426	001232	001234	040005	DT234: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP3,\$TMP4,0
7745	072446	001232	001234	040005	DT235: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,0
7746		072426			DT236=DT234	
7747		072426			DT237=DT234	
7748		072426			DT240=DT234	
7749		072372			DT241=DT233	
7750		072426			DT242=DT234	
7751		072372			DT243=DT233	
7752		072372			DT244=DT233	
7753		072372			DT245=DT233	
7754		071662			DT246=DT23	
7755	072460	001232	001234	040005	DT247: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP3,0
7756	072476	001232	001234	040005	DT250: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,0
7757		072476			DT251=DT250	
7758	072510	001232	001234	040005	DT252: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,0
7759	072522	001232	001234	040005	DT253: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP7,\$TAB,\$TMP1C
7760	072542	001313	037614	001254	.WORD	\$CRLF,MSA1,\$TMP11,\$CRLF,MSA2,\$TMP12
7761	072556	001313	037655	001244	.WORD	\$CRLF,MSA3,\$TMP5,\$CRLF,MSA4,\$TMP6
7762	072572	001313	037705	001240	.WORD	\$CRLF,MSA5,\$TMP3,\$CRLF,MSA6,\$TMP4,0
7763		072522			DT254=DT253	
7764		072522			DT255=DT253	
7765		072522			DT256=DT253	
7766		072522			DT257=DT253	
7767		072522			DT260=DT253	
7768		072522			DT261=DT253	
7769		072522			DT262=DT253	
7770		072522			DT263=DT253	
7771		072522			DT264=DT253	
7772		072522			DT265=DT253	
7773		072510			DT266=DT252	
7774		072076			DT267=DT165	
7775	072610	007070	007070		.WORD	7070,7070,7070,7070 ;KLUDGE FOR APT LOAD PROBLEM
7776		000001			.END	

SYMBOL TABLE

AAADON 014602	MSGTY= 000000	BPTVEC= 000014	DF1 = 070743	DF161 = 071036
AAA1 013600	AMTYP1= 000000	CCCCDON 016314	DF10 = 070743	DF162 = 071036
AAA10 014216	AMTYP2= 000000	CCC1 015310	DF100 = 071164	DF163 = 071106
AAA11 014254	AMTYP3= 000000	CCC10 015704	DF101 = 071164	DF164 = 071036
AAA12 014312	AMTYP4= 000000	CCC11 015740	DF102 = 071164	DF165 = 071216
AAA13 014350	APASS = 000000	CCC12 015774	DF103 = 071164	DF166 = 071216
AAA2 013636	APHIOR= 000000	CCC13 016030	DF104 = 071164	DF167 = 071216
AAA3 013674	APTC SU= 000040	CCC2 015344	DF105 = 071164	DF17 = 070773
AAA4 013732	APTE NV= 000001	CCC3 015400	DF106 = 071164	DF170 = 071216
AAA5 013770	APTSIZ= 000200	CCC4 015434	DF107 = 071164	DF171 = 071216
AAA6 014026	APTSPO= 000100	CCC5 015470	DF11 = 070743	DF172 = 071216
AAA7 014064	ASWREG= 000000	CCC6 015524	DF110 = 071164	DF173 = 071216
AAA8 014122	A TESTN= 000000	CCC7 015560	DF111 = 071012	DF174 = 071216
AAA9 014160	AUNIT = 000000	CCC8 015614	DF112 = 071012	DF175 = 071216
ABASE = 000000	AUSWR = 000000	CCC9 015650	DF113 = 071012	DF176 = 071250
ACDW1 = 000000	AVECT1= 000000	CKSWR = 104406	DF114 = 071012	DF177 = 071302
ACDW2 = 000000	AVECT2= 000000	CMPSUB 014412	DF115 = 071062	DF2 = 070761
ACPUOP= 000000	BBBDON 015304	CMPTMP 014572	DF116 = 071062	DF20 = 071002
AC0 = X000000	BBBER1 015060	CNT = 000270	DF117 = 071062	DF200 = 071250
AC1 = X000001	BBBER2 015144	CORDON 033336	DF12 = 070743	DF201 = 071250
AC2 = X000002	BBBER3 015172	CORFLG 033320	DF120 = 071062	DF202 = 071250
AC3 = X000003	BBBER4 015220	CORINT 033332	DF121 = 071062	DF203 = 071250
AC4 = X000004	BBBP1 015264	CORMES 040455	DF122 = 071062	DF204 = 071250
AC5 = X000005	BBBP2 015274	CORSUB 033036	DF123 = 071036	DF205 = 071250
AC6 = X000006	BBB0 014610	CORTMP 033322	DF124 = 071036	DF206 = 071250
AC7 = X000007	BBB1 014644	CORTRP 033334	DF125 = 071036	DF207 = 071315
ADDW0 = 000000	BBB2 014672	CORTV 033134	DF126 = 071036	DF21 = 071002
ADDW1 = 000000	BBB3 014722	CORTV0 033276	DF127 = 071106	DF210 = 071305
ADDW10= 000000	BBB4 014750	CORTV1 033302	DF13 = 070743	DF211 = 071315
ADDW11= 000000	BBB5 015006	COR1 032204	DF130 = 071106	DF212 = 071341
ADDW12= 000000	BBB6 015014	COR10 032626	DF131 = 071106	DF213 = 071341
ADDW13= 000000	BIT0 = 000001	COR11 032672	DF132 = 071036	DF214 = 071341
ADDW14= 000000	BIT00 = 000001	COR12 032732	DF133 = 071106	DF215 = 071341
ADDW15= 000000	BIT01 = 000002	COR13 032772	DF134 = 071106	DF216 = 071315
ADDW2 = 000000	BIT02 = 000004	COR2 032230	DF135 = 071036	DF217 = 071371
ADDW3 = 000000	BIT03 = 000010	COR3 032244	DF136 = 071106	DF22 = 071002
ADDW4 = 000000	BIT04 = 000020	COR33 032256	DF137 = 071062	DF220 = 071315
ADDW5 = 000000	BIT05 = 000040	COR4 032316	DF14 = 070743	DF221 = 071315
ADDW6 = 000000	BIT06 = 000100	COR5 032356	DF140 = 071062	DF222 = 071315
ADDW7 = 000000	BIT07 = 000200	COR6 032416	DF141 = 071062	DF223 = 071315
ADDW8 = 000000	BIT08 = 000400	COR7 032462	DF142 = 071062	DF224 = 071315
ADDW9 = 000000	BIT09 = 001000	COR8 032522	DF143 = 071062	DF225 = 071315
ADEVCT= 000000	BIT1 = 000002	COR9 032566	DF144 = 071062	DF226 = 071341
ADEVN = 000000	BIT10 = 002000	CPSAVE 034422	DF145 = 071012	DF227 = 071341
AENV = 000000	BIT11 = 004000	CPSPUR 037502	DF146 = 071012	DF23 = 071012
AENVN = 000000	BIT12 = 010000	CPTWO 037520	DF147 = 071012	DF230 = 071341
AFATAL= 000000	BIT13 = 020000	CR = 000015	DF15 = 070743	DF231 = 071341
AMADR1 000000	BIT14 = 040000	CRLF = 000200	DF150 = 071012	DF232 = 071341
AMADR2= 000000	BIT15 = 100000	DDDDON 017250	DF151 = 071106	DF233 = 071400
AMADR3= 000000	BIT2 = 000004	DDD1 016320	DF152 = 071106	DF234 = 071415
AMADR4= 000000	BIT3 = 000010	DDD2 016374	DF153 = 071106	DF235 = 071424
AMAMS1= 000000	BIT4 = 000020	DDD3 016450	DF154 = 071106	DF236 = 071415
AMAMS2= 000000	BIT5 = 000040	DDD4 016524	DF155 = 071106	DF237 = 071415
AMAMS3= 000000	BIT6 = 000100	DDD5 016600	DF156 = 071106	DF24 = 071012
AMAMS4= 000000	BIT7 = 000200	DDD6 016654	DF157 = 071036	DF240 = 071415
AMSGAD= 000000	BIT8 = 000400	DDD7 016730	DF16 = 070743	DF241 = 071400
AMSGLG= 000000	BIT9 = 001000	DDISP = 177570	DF160 = 071106	DF242 = 071415

DF243 = 071400
DF244 = 071400
DF245 = 071400
DF246 = 071036
DF247 = 071430
DF248 = 071012
DF250 = 071430
DF251 = 071430
DF252 = 071436
DF253 = 071442
DF254 = 071442
DF255 = 071442
DF256 = 071442
DF257 = 071442
DF26 = 071012
DF260 = 071442
DF261 = 071442
DF262 = 071442
DF263 = 071442
DF264 = 071442
DF265 = 071442
DF266 = 071436
DF267 = 071250
DF27 = 071012
DF3 = 070743
DF30 = 071012
DF31 = 071012
DF32 = 071012
DF33 = 071036
DF34 = 071036
DF35 = 071036
DF36 = 071036
DF37 = 071012
DF4 = 070743
DF40 = 071012
DF41 = 071012
DF42 = 071012
DF43 = 071012
DF44 = 071012
DF45 = 071012
DF46 = 071036
DF47 = 071036
DF5 = 070743
DF50 = 071036
DF51 = 071036
DF52 = 071036
DF53 = 071132
DF54 = 071132
DF55 = 071132
DF56 = 071132
DF57 = 071132
DF6 = 070743
DF60 = 071132
DF61 = 071132
DF62 = 071132
DF63 = 071132
DF64 = 071132

DF65 = 071132
DF66 = 071132
DF67 = 071132
DF7 = 070743
DF70 = 071164
DF71 = 071164
DF72 = 071164
DF73 = 071164
DF74 = 071164
DF75 = 071164
DF76 = 071164
DF77 = 071164
DH1 = 067106
DH10 = 067106
DH100 = 067106
DH101 = 067106
DH102 = 067106
DH103 = 067106
DH104 = 067106
DH105 = 067106
DH106 = 067106
DH107 = 067106
DH11 = 067106
DH110 = 067106
DH111 = 067106
DH112 = 067106
DH113 = 067106
DH114 = 067106
DH115 = 067447
DH116 = 067447
DH117 = 067447
DH12 = 067106
DH120 = 067447
DH121 = 067447
DH122 = 067447
DH123 = 067106
DH124 = 067106
DH125 = 067106
DH126 = 067106
DH127 = 067447
DH13 = 067106
DH130 = 067447
DH131 = 067447
DH132 = 067106
DH133 = 067447
DH134 = 067447
DH135 = 067106
DH136 = 067447
DH137 = 067447
DH14 = 067106
DH140 = 067447
DH141 = 067447
DH142 = 067447
DH143 = 067447
DH144 = 067447
DH145 = 067106
DH146 = 067106

DH147 = 067106
DH15 = 067106
DH150 = 067106
DH151 = 067447
DH152 = 067447
DH153 = 067447
DH154 = 067447
DH155 = 067447
DH156 = 067447
DH157 = 067106
DH16 = 067106
DH160 = 067447
DH161 = 067106
DH162 = 067106
DH163 = 067447
DH164 = 067106
DH165 = 067447
DH166 = 067447
DH167 = 067447
DH17 = 067237
DH170 = 067447
DH171 = 067447
DH172 = 067447
DH173 = 067447
DH174 = 067447
DH175 = 067447
DH176 = 067447
DH177 = 067546
DH2 = 067176
DH20 = 067106
DH200 = 067447
DH201 = 067447
DH202 = 067447
DH203 = 067447
DH204 = 067447
DH205 = 067447
DH206 = 067447
DH207 = 067647
DH21 = 067312
DH210 = 067737
DH211 = 067737
DH212 = 067647
DH213 = 067647
DH214 = 067647
DH215 = 067647
DH216 = 067737
DH217 = 070000
DH22 = 067401
DH220 = 067607
DH221 = 067737
DH222 = 067607
DH223 = 067737
DH224 = 067607
DH225 = 067737
DH226 = 070053
DH227 = 070142
DH23 = 067106

DH230 = 070053
DH231 = 070142
DH232 = 070142
DH233 = 070231
DH234 = 070272
DH235 = 070360
DH236 = 070420
DH237 = 070272
DH24 = 067106
DH240 = 070506
DH241 = 070231
DH242 = 070506
DH243 = 070231
DH244 = 070231
DH245 = 070231
DH246 = 067106
DH247 = 070576
DH25 = 067106
DH250 = 070643
DH251 = 070643
DH252 = 067176
DH253 = 067106
DH254 = 067106
DH255 = 067106
DH256 = 067106
DH257 = 067106
DH26 = 067106
DH260 = 067106
DH261 = 067106
DH262 = 067106
DH263 = 067106
DH264 = 067106
DH265 = 067106
DH266 = 070703
DH267 = 067447
DH27 = 067106
DH3 = 067106
DH30 = 067106
DH31 = 067106
DH32 = 067106
DH33 = 067106
DH34 = 067106
DH35 = 067106
DH36 = 067106
DH37 = 067106
DH4 = 067106
DH40 = 067106
DH41 = 067106
DH42 = 067106
DH43 = 067106
DH44 = 067106
DH45 = 067106
DH46 = 067106
DH47 = 067106
DH5 = 067106
DH50 = 067106
DH51 = 067106

DH52 = 067106
DH53 = 067106
DH54 = 067106
DH55 = 067106
DH56 = 057106
DH57 = 067106
DH6 = 067106
DH60 = 067106
DH61 = 067106
DH62 = 067106
DH63 = 067106
DH64 = 067106
DH65 = 067106
DH66 = 067106
DH67 = 067106
DH7 = 067106
DH70 = 067106
DH71 = 067106
DH72 = 067106
DH73 = 067106
DH74 = 067106
DH75 = 067106
DH76 = 067106
DH77 = 067106
DISPLA = 001142
DISPRE = 000174
DIVDSU = 017010
DIVDT = 017240
DIVFSU = 016070
DIVFT = 016304
DSWR = 177570
DT1 = 071474
DT10 = 071474
DT100 = 071734
DT101 = 071734
DT102 = 071734
DT103 = 071734
DT104 = 071734
DT105 = 071734
DT106 = 071734
DT107 = 071734
DT11 = 071474
DT110 = 071734
DT111 = 071662
DT112 = 071662
DT113 = 071662
DT114 = 071662
DT115 = 072022
DT116 = 072022
DT117 = 072022
DT12 = 071474
DT120 = 072022
DT121 = 072022
DT122 = 072022
DT123 = 071662
DT124 = 071662
DT125 = 071662

DT126 = 071662
 DT127 = 072022
 DT13 = 071474
 DT130 = 072022
 DT131 = 072022
 DT132 = 071662
 DT133 = 072022
 DT134 = 072022
 DT135 = 071662
 DT136 = 072022
 DT137 = 072022
 DT14 = 071474
 DT140 = 072022
 DT141 = 072022
 DT142 = 072022
 DT143 = 072022
 DT144 = 072022
 DT145 = 071662
 DT146 = 071662
 DT147 = 071662
 DT15 = 071474
 DT150 = 071662
 DT151 = 072022
 DT152 = 072022
 DT153 = 072022
 DT154 = 072022
 DT155 = 072022
 DT156 = 072022
 DT157 = 071662
 DT16 = 071474
 DT160 = 072022
 DT161 = 071662
 DT162 = 071662
 DT163 = 072022
 DT164 = 071662
 DT165 = 072076
 DT166 = 072076
 DT167 = 072076
 DT17 = 071560
 DT170 = 072076
 DT171 = 072076
 DT172 = 072076
 DT173 = 072076
 DT174 = 072076
 DT175 = 072076
 DT176 = 072076
 DT177 = 072164
 DT2 = 071532
 DT20 = 071600
 DT200 = 072076
 DT201 = 072076
 DT202 = 072076
 DT203 = 072076
 DT204 = 072076
 DT205 = 072076
 DT206 = 072076
 DT207 = 072174

DT21 = 071622
 DT210 = 072246
 DT211 = 072174
 DT212 = 072270
 DT213 = 072270
 DT214 = 072270
 DT215 = 072270
 DT216 = 072174
 DT217 = 072352
 DT22 = 071644
 DT220 = 072174
 DT221 = 072174
 DT222 = 072174
 DT223 = 072174
 DT224 = 072174
 DT225 = 072174
 DT226 = 072270
 DT227 = 072270
 DT23 = 071662
 DT230 = 072270
 DT231 = 072246
 DT232 = 072174
 DT233 = 072372
 DT234 = 072426
 DT235 = 072446
 DT236 = 072426
 DT237 = 072426
 DT24 = 071662
 DT240 = 072426
 DT241 = 072372
 DT242 = 072426
 DT243 = 072372
 DT244 = 072372
 DT245 = 072372
 DT246 = 071662
 DT247 = 072460
 DT25 = 071662
 DT250 = 072476
 DT251 = 072476
 DT252 = 072510
 DT253 = 072522
 DT254 = 072522
 DT255 = 072522
 DT256 = 072522
 DT257 = 072522
 DT26 = 071662
 DT260 = 072522
 DT261 = 072522
 DT262 = 072522
 DT263 = 072522
 DT264 = 072522
 DT265 = 072522
 DT266 = 072510
 DT267 = 072076
 DT27 = 071662
 DT3 = 071474
 DT30 = 071662

DT31 = 071662
 DT32 = 071662
 DT33 = 071662
 DT34 = 071662
 DT35 = 071662
 DT36 = 071662
 DT37 = 071662
 DT4 = 071474
 DT40 = 071662
 DT41 = 071662
 DT42 = 071662
 DT43 = 071662
 DT44 = 071662
 DT45 = 071662
 DT46 = 071662
 DT47 = 071662
 DT5 = 071474
 DT50 = 071662
 DT51 = 071662
 DT52 = 071662
 DT53 = 071734
 DT54 = 071734
 DT55 = 071734
 DT56 = 071734
 DT57 = 071734
 DT6 = 071474
 DT60 = 071734
 DT61 = 071734
 DT62 = 071734
 DT63 = 071734
 DT64 = 071734
 DT65 = 071734
 DT66 = 071734
 DT67 = 071734
 DT7 = 071474
 DT70 = 071734
 DT71 = 071734
 DT72 = 071734
 DT73 = 071734
 DT74 = 071734
 DT75 = 071734
 DT76 = 071734
 DT77 = 071734
 EEEDON = 020260
 EEE1 = 017254
 EEE10 = 017650
 EEE11 = 017704
 EEE12 = 017740
 EEE13 = 017774
 EEE2 = 017310
 EEE3 = 017344
 EEE4 = 017400
 EEE5 = 017434
 EEE6 = 017470
 EEE7 = 017524
 EEE8 = 017560
 EEE9 = 017614

EMTVEC = 000030
 EM1 = 040514
 EM10 = 041333
 EM100 = 054471
 EM101 = 054554
 EM102 = 054750
 EM103 = 055144
 EM104 = 055256
 EM105 = 055423
 EM106 = 055532
 EM107 = 055641
 EM11 = 041440
 EM110 = 055750
 EM111 = 044565
 EM112 = 044642
 EM113 = 044720
 EM114 = 044776
 EM115 = 045055
 EM116 = 045133
 EM117 = 045212
 EM12 = 041547
 EM120 = 045350
 EM121 = 045506
 EM122 = 045643
 EM123 = 046000
 EM124 = 046056
 EM125 = 046135
 EM126 = 046213
 EM127 = 046272
 EM13 = 041656
 EM130 = 046350
 EM131 = 046427
 EM132 = 046565
 EM133 = 046723
 EM134 = 047061
 EM135 = 047216
 EM136 = 047353
 EM137 = 047510
 EM14 = 041772
 EM140 = 047576
 EM141 = 044565
 EM142 = 044642
 EM143 = 047665
 EM144 = 047743
 EM145 = 050022
 EM146 = 050167
 EM147 = 050334
 EM15 = 042104
 EM150 = 050500
 EM151 = 050644
 EM152 = 050732
 EM153 = 046000
 EM154 = 046056
 EM155 = 051021
 EM156 = 051077
 EM157 = 051156
 EM16 = 042216

EM160 = 051323
 EM161 = 051461
 EM162 = 051626
 EM163 = 051772
 EM164 = 052127
 EM165 = 056060
 EM166 = 056144
 EM167 = 056227
 EM17 = 042313
 EM170 = 056261
 EM171 = 056347
 EM172 = 056472
 EM173 = 056557
 EM174 = 056725
 EM175 = 057073
 EM176 = 057205
 EM177 = 057271
 EM2 = 040546
 EM20 = 042370
 EM200 = 057325
 EM201 = 057357
 EM202 = 057446
 EM203 = 057610
 EM204 = 057752
 EM205 = 060040
 EM206 = 060206
 EM207 = 060354
 EM21 = 042422
 EM210 = 060416
 EM211 = 060460
 EM212 = 060624
 EM213 = 061010
 EM214 = 061174
 EM215 = 061360
 EM216 = 061544
 EM217 = 061726
 EM22 = 042454
 EM220 = 061770
 EM221 = 062220
 EM222 = 062464
 EM223 = 062715
 EM224 = 063162
 EM225 = 063413
 EM226 = 063660
 EM227 = 064013
 EM23 = 042535
 EM230 = 064146
 EM231 = 064302
 EM232 = 060416
 EM233 = 064436
 EM234 = 064475
 EM235 = 064561
 EM236 = 064627
 EM237 = 064662
 EM24 = 042612
 EM240 = 064746
 EM241 = 065002

EM242	065105	EM64	053372	GGG4	024610	HHER9	006602	HXER10	013342
EM243	065141	EM65	053511	GGG5	024660	HHPDON	030200	HXER11	013374
EM244	065244	EM66	053624	GGG6	024730	HHH1	026076	HXER12	013414
EM245	065303	EM67	053673	GGG7	025000	HHH10	027176	HXER13	013444
EM246	044175	EM7	041226	GGG8	025050	HHH11	027276	HXER2	013112
EM247	065365	EM70	053756	GGG9	025120	HHH12	027376	HXER22	013126
EM25	042710	EM71	054007	GGP1	011744	HHH13	027476	HXER3	013142
EM250	065421	EM72	054037	GGP2	011754	HHH2	026176	HXER33	013156
EM251	065453	EM73 =	054037	GGP3	011764	HHH3	026276	HXER4	013172
EM252	065506	EM74	054071	GGP4	011774	HHH4	026376	HXER5	013072
EM253	065577	EM75	054200	GGP5	012004	HHH5	026476	HXER6	013226
EM254	065663	EM76	054271	GGP6	012014	HHH6	026576	HXER66	013242
EM255	065750	EM77	054361	GGP7	012024	HHH7	026676	HXER7	013256
EM256	066036	EPENDS	034104	GGP8	012034	HHH8	026776	HXER8	013210
EM257	066125	ERM10	034756	GGP9	012044	HHH9	027076	HXER9	013306
EM26	042775	ERROR =	104000	GG1	007142	HHP0	006776	HXP1	013474
EM260	066213	ERRVEC =	000004	GG10	007436	HHP1	007006	HXP2	013504
EM261	066302	ERTYPE	037040	GG11	007474	HHP10	007116	HXP3	013514
EM262	066372	FFFDON	021010	GG12	007516	HHP11	007126	HXP4	013524
EM263	066463	FFF1	020264	GG13	007526	HHP2	007016	HXP5	013534
EM264	066550	FFF2	020340	GG14	007544	HHP3	007026	HXP6	013544
EM265	066635	FFF3	020414	GG15	007602	HHP4	007036	HXP7	013554
EM266	066722	FFF4	020470	GG16	007620	HHP5	007046	HXP8	013564
EM267	067023	FPSPUR	037450	GG17	007666	HHP6	007056	HX1	012060
EM27 =	042710	FPVECT =	000244	GG18	007676	HHP7	007066	HX10	012266
EM3	040602	GGDATO	011734	GG19	007732	HHP8	007076	HX11	012310
EM30	043073	GGDONE	012054	GG2	007200	HHP9	007106	HX12	012330
EM31	043145	GGERO	010232	GG20	007770	HHTRAP	006716	HX13	012340
EM32	042560	GGER1	010330	GG21	010012	HH1	005216	HX14	012346
EM33	43212	GGER10	011042	GG22	010022	HH10	005430	HX15	012364
EM34	043235	GGER11	011110	GG23	010040	HH11	005446	HX16	012412
EM35	043267	GGER12	011156	GG24	010076	HH12	005476	HX165	012416
EM36	043342	GGER13	011224	GG25	010114	HH13	005520	HX17	012444
EM37	043410	GGER14	011272	GG26	010162	HH14	005540	HX18	012502
EM4	040707	GGER15	011370	GG27	010172	HH15	005550	HX19	012522
EM40	043433	GGER16	011436	GG28	010226	HH16	005556	HX2	012110
EM41	043465	GGER17	011504	GG3	007222	HH17	005574	HX20	012532
EM42	043540	GGER18	011552	GG4	007232	HH18	005632	HX21	012534
EM43	043671	GGER19	011620	GG5	007250	HH19	005654	HX22	012564
EM44	044022	GGER2	010376	GG6	007306	HH2	005246	HX23	012604
EM45	044070	GGER20	011666	GG7	007324	HH20	005664	HX24	012624
EM46	044143	GGER3	010444	GG8	007372	HH21	005702	HX25	012634
EM47	044220	GGER4	010512	GG9	007402	HH22	005732	HX26	012642
EM5	041014	GGER5	010514	GTSWR =	104405	HH23	005754	HX27	012644
EM50	044354	GGER6	010562	HMDATO	006766	HH24	005764	HX28	012676
EM51	044427	GGER7	010630	HHDONE	007136	HH25	006002	HX29	012720
EM52	044475	GGER8	010726	HHER0	006006	HH3	005270	HX3	012124
EM53	052325	GGER9	010774	HHER00	006122	HH4	005310	HX30	012730
EM54	052356	GGGDON	026072	HHER1	006054	HH5	005320	HX31	012746
EM55	052273	GGG1	024420	HHER10	006650	HH6	005326	HX32	012776
EM56	052406	GGG10	025170	HHER2	006170	HH7	005340	HX33	013020
EM57	052477	GGG11	025240	HHER3	006236	HH8	005376	HX34	013030
EM6	041121	GGG12	025310	HHER4	006304	HH9	005420	HX35	013046
EM60	052567	GGG13	025360	HHER5	006352	HT =	000011	HX4	012144
EM61	052671	GGG14	025430	HHER6	006420	HXDATO	013464	HX5	012164
EM62	053065	GGG2	024470	HHER7	006466	HXDONE	013574	HX6	012174
EM63	053261	GGG3	024540	HHER8	006534	HXER1	013052	HX7	012202

HX8 012220
HX9 012252
IBSAVE 034424
I11DON 021650
I111 021014
I112 021060
I113 021124
I114 021170
IOTVEC= 000020
JJJDON 022610
JJJ1 021654
JJJ2 021740
JJJ3 022024
JJJ4 022110
KKKDON 023452
KKK1 022614
KKK3 022660
KKK4 022724
KKK5 022770
LF = 000012
LLLDON 024414
LLL1 023456
LLL2 023542
LLL3 023626
LLL4 023712
LOOP 005214
LPERR = 104413
MMMDON 031126
MMM1 030204
MMM2 030256
MMM3 030330
MMM4 030402
MMM5 030454
MMUMBE= 000267
MODDD0 032134
MODDD1 032144
MODDOV 031546
MODDSU 027602
MODDT0 030160
MODDT1 030170
MODFDO 031106
MODFD1 031116
MODFOV 030532
MODFSU 025504
MODFT0 026042
MODFT1 026052
MODP1 026062
MSA1 037614
MSA2 037632
MSA3 037655
MSA4 037667
MSA5 037705
MSA6 037720
MS1 040012
MS10 040211
MS11 040233
MS12 040257

MS2 040030
MS3 040050
MS37 040302
MS4 040077
MS40 040320
MS41 040354
MS415 040334
MS42 040400
MS43 040416
MS44 040433
MS5 040125
MS6 040147
MS7 040165
MULDSU 020550
MULDT 021000
MULFSU 020034
MULFT 020250
NNNDON 032154
NNN1 031132
NNN2 031234
NNN3 031336
NNN4 031440
OVDNTT 022600
OVDTT 024404
OVFNTT 021640
OVFTT 023442
OVUNDN 022200
OVUNDT 024002
OVUNFN 021240
OVUNFT 023040
PIRQ = 177772
PIRQVE= 000240
POWERM 037740
PROGNU= 000002
PRO = 000000
PR1 = 000040
PR2 = 000100
PR3 = 000140
PR4 = 000200
PR5 = 000240
PR6 = 000300
PR7 = 000340
PS = 177776
PSW = 177776
PWRVEC= 000024
RDCHR = 104407
RESREG= 104411
RESVEC= 000010
RSETUP= 104412
R6 = X000006
R7 = X000007
SAVREG= 104410
SCOPE = 000004
SPACE 040007
STACK = 001100
START 004346
STKLMT= 177774

SWR 001140
SWREG 000176
SW0 = 000001
SW00 = 000001
SW01 = 000002
SW02 = 000004
SW03 = 000010
SW04 = 000020
SW05 = 000040
SW06 = 000100
SW07 = 000200
SW08 = 000400
SW09 = 001000
SW1 = 000002
SW10 = 002000
SW11 = 004000
SW12 = 010000
SW13 = 020000
SW14 = 040000
SW15 = 100000
SW2 = 000004
SW3 = 000010
SW4 = 000020
SW5 = 000040
SW6 = 000100
SW7 = 000200
SW8 = 000400
SW9 = 001000
TAB = 000011
TBITVE= 000014
TKVEC = 000060
TOCTNM 037434
TPVEC = 000064
TRAPVE= 000034
TRTVEC= 000014
TST1 005214
TST10 017252
TST11 020262
TST12 021012
TST13 021652
TST14 022612
TST15 023454
TST16 024416
TST17 026074
TST2 007140
TST20 030202
TST21 031130
TST22 032156
TST23 033340
TST3 012056
TST4 013576
TST5 014604
TST6 015306
TST7 016316
TYPE = 104401
TYPOC = 104402
TYPON = 104404

TYPOS = 104403
\$APTHD 004332
\$ATYC 035700
\$ATY1 035654
\$ATY3 035662
\$ATY4 035672
\$AUTOB 001134
\$BASE 001372
\$BDADR 001122
\$BDDAT 001126
\$BELL 001306
\$CDW1 001376
\$CDW2 001400
\$CHARC 035414
\$CKSWR 036122
\$CLR.T 034014
\$CMTAG 001100
\$CM1 = 000024
\$CM2 = 000050
\$CM3 = 000024
\$CM4 = 000024
\$CNTLG 036541
\$CNTLU 036534
\$CPUOP 001344
\$CRLF 001313
\$DDW0 001402
\$DDW1 001404
\$DDW10 001426
\$DDW11 001430
\$DDW12 001432
\$DDW13 001434
\$DDW14 001436
\$DDW15 001440
\$DDW2 001406
\$DDW3 001410
\$DDW4 001412
\$DDW5 001414
\$DDW6 001416
\$DDW7 001420
\$DDW8 001422
\$DDW9 001424
\$DEVCT 001326
\$DEVN 001374
\$DISAB 033744
\$DOAGN 034034
\$ENDAD 034024
\$ENDCT 033404
\$ENULL 034100
\$ENV 001336
\$ENVN 001337
\$EOP 033340
\$EOPCT 033372
\$ERFLG 001103
\$ERMAX 001115
\$ERROR 034426
\$ERRPC 001116
\$ERPTB 001442

\$ERTTL 001112
\$ESCAP 001304
\$ETABL 001336
\$ETEND 001442
\$FATAL 001320
\$FFLG 036120
\$FILLC 001156
\$FILLS 001155
\$GDADR 001120
\$GDDAT 001124
\$GET42 033664
\$GTSWR 036172
\$GT42C 033776
\$HD = 000003
\$HIBTS 004332
\$ICNT 001104
\$ILLUP 037032
\$INTAG 001135
\$ITEMB 001114
\$LF 001314
\$LFLG 036117
\$LOOP 034072
\$LPADR 001106
\$LPERR 001110
\$MADR1 001350
\$MADR2 001354
\$MADR3 001360
\$MADR4 001364
\$MAIL 001316
\$MAMS1 001345
\$MAMS2 001352
\$MAMS3 001356
\$MAMS4 001362
\$MBADR 004334
\$MFLC 036116
\$MNEW 036557
\$MSGAD 001332
\$MSGLG 001334
\$MSGTY 001316
\$MSWR 036546
\$MTYP1 001347
\$MTYP2 001353
\$MTYP3 001357
\$MTYP4 001363
\$MXCNT 034420
\$NULL 001154
\$NWTST= 000001
\$OCNT 035650
\$OMODE 035652
\$OVER 034404
\$PASS 001324
\$PASS2 034106
\$PASTM 004340
\$PWRAD 037014
\$PWRDN 036654
\$PWRMG 037010
\$PWRUP 036726

SYMBOL TABLE

\$QUES	001312	\$REG3	001170	\$TAB	040005	\$TMP21	001274	\$TYPEC	035266
\$RDCHR	036404	\$REG4	001172	\$TRIT	034076	\$TMP22	001276	\$TYPEX	035416
\$RDSZ =	000001	\$REG5	001174	\$TERM =	000030	\$TMP23	001300	\$TYPDC	035444
\$REGAD	001160	\$REG6	001176	\$TESTN	001322	\$TMP3	001240	\$TYPON	035460
\$REGO	001162	\$REG7	001200	\$TIMES	001302	\$TMP4	001242	\$TYPOS	035420
\$REG1	001164	\$RESRE	035016	\$TKB	001146	\$TMP5	001244	\$UNIT	001330
\$REG10	001202	\$RTNAD	034074	\$TKS	001144	\$TMP6	001246	\$UNITM	004342
\$REG11	001204	\$RTRN	034070	\$TMP0	001232	\$TMP7	001250	\$USWR	001342
\$REG12	001206	\$\$AVRE	034760	\$TMP1	001234	\$TN =	000023	\$VECT1	001366
\$REG13	001210	\$\$AVR6	037036	\$TMP10	001252	\$TPB	001152	\$VECT2	001370
\$REG14	001212	\$\$SCOPE	034110	\$TMP11	001254	\$TPFLG	001157	\$XOFF =	000023
\$REG15	001214	\$\$SETUP=	000137	\$TMP12	001256	\$TPS	001150	\$XON =	000021
\$REG16	001216	\$\$STUP =	177777	\$TMP13	001260	\$TRAP	036570	\$XTSTR	034122
\$REG17	001220	\$\$SVLAD	034350	\$TMP14	001262	\$TRAP2	036612	\$\$GET4=	000001
\$REG2	001166	\$\$SVPC =	004332	\$TMP15	001264	\$TRP =	000014	\$OFILL	035651
\$REG20	001222	\$\$SWR =	177400	\$TMP16	001266	\$TRPAD	036624	.LPER	037536
\$REG21	001224	\$\$SWREG	001340	\$TMP17	001270	\$TSTM	004336	.RSET	037544
\$REG22	001226	\$\$SWRMK=	000000	\$TMP2	001236	\$TSTM	001102	.\$X =	004332
\$REG23	001230	\$\$SWRMS=	000200	\$TMP20	001272	\$TYPE	035054		

. ABS. 072620 000
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 60776 WORDS (238 PAGES)

DYNAMIC MEMORY: 20034 WORDS (77 PAGES)

ELAPSED TIME: 03:05:19

CKFPBC.BIN,CKFPBC/CR/-SP/NL:TOC=CKFPBC.MLB/ML,CKFPBC.P11