

DRV11-J

DIAG TST PRT 2
CVDRDBO

AH-F761B-MC
FICHE 1 OF 1

JUL 1982
COPYRIGHT © 79-82
MADE IN USA



IDENTIFICATION

PRODUCT CODE: AC-F759B-MC
PRODUCT NAME: CVDRDB0 DRV11J DIAG TST PRT2
DATE CREATED: 17-FEB-82
MAINTAINER: DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1979, 1982 DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	STORAGE
3.0	LOADING PROCEDURE
4.0	STARTING PROCEDURE
4.1	PROGRAM START
5.0	SOFTWARE SWITCH REGISTER
5.1	OPTIONS
5.2	CONTROL
6.0	ERROR REPORTING
6.1	ERROR COMMENT
6.2	ERROR DATA
7.0	MISCELLANEOUS
7.1	DRV11J BUS ADDRESS MODIFICATION
7.2	XXDP/APT NOTES
7.3	POWER FAIL
7.4	MULTIPLE DRV11J INTERFACE TESTING
7.5	RESTRICTIONS
8.0	EXECUTION TIME
9.0	PROGRAM TEST DESCRIPTIONS
10.0	LISTING

1.0 ABSTRACT

THE DRV11-J IS A GENERAL PURPOSE PARALLEL INTERFACE FOR THE LSI-11 BUS. IT HAS A BASIC CONFIGURATION OF 64 TRI-STATE IN/OUT LINES DIVIDED INTO FOUR GROUPS OF 16 BIT WORDS.

THERE ARE TWO 4K DIAGNOSTICS FOR THE DRV11-J OPTION. THE DRV11-J DIAGNOSTIC TEST PART 1 OF 2 CONTAINS A SERIES OF TESTS WITHOUT DRV11J INTERRUPTS DESIGNED TO TEST ALL LOGIC FUNCTIONS AND DATA PATHS MADE ACCESSIBLE WITH THE LOOPBACK CABLE INSERTED INTO THE DRV11-J I/O CONNECTORS.

THE DRV11-J DIAGNOSTIC PART 2 OF 2 IS A SERIES OF TESTS WITH DRV11J INTERRUPTS DESIGNED TO TEST ALL LOGIC AND DATA PATHS MADE ACCESSIBLE WITH THE LOOPBACK CABLE INSERTED INTO THE I/O CONNECTORS.

THE DRV11-J IS CONTAINED ON A DOUBLE HEIGHT MODULE. THE MODULE CONTAINS TWO 50 PIN CONNECTORS FOR INTERFACING TO EXTERNAL USER DEVICES.

FOR DIAGNOSTIC TESTING, THE DRV11-J CABLE (BC05W-02) MUST BE INSTALLED WITH 1/2 TWIST BETWEEN THE 50 PIN CONNECTORS.

```

*****
*
* NOTE: THIS DIAGNOSTIC HAS BEEN MODIFIED TO RUN IN KXT11 (SBC 11/21)
* BASED SYSTEMS. THE PROGRAM WILL AUTOMATICALLY ADJUST ITSELF TO RUN
* IN THE APPROPRIATE ENVIRONMENT AS FOLLOWS:
*
*
*          LSI-11, 11/2, AND 11/23          SBC 11/21
*          -----
* CSR RANGE:          160010 TO 177760          174000 TO 177760
* PROGRAMMABLE...
* ...VECTOR RANGE:   0000 TO 1774          000 TO 374
*
*
*****

```

2.0 REQUIREMENTS

2.1 EQUIPMENT

1. PDP11/03, 11/23 COMPUTER OR LSI-11 PROCESSOR WITH A MINIMUM OF 4K MEMORY.
2. SERIAL LINE INTERFACE AND CONSOLE TERMINAL
3. DRV11-J OPTION WITH A BC05W-02 CABLE

2.2 STORAGE

THE PROGRAM USES THE LOWER 4K OF MEMORY.

3.0 LOADING PROCEDURE

USE STANDARD PROCEDURE FOR PDP-11 ABSOLUTE

BINARY FORMATTED PAPERTAPES OR XXDP MEDIA
(FILES WITH .BIC OR .BIN EXTENSIONS ONLY).

4.0 STARTING PROCEDURE

1. MAKE SURE THE DRV11-J CABLE IS INSERTED WITH 1/2 A TWIST ON THE I/O CONNECTORS OF THE DRV11-J OPTION. THIS WILL CONNECT PORT A TO PORT C AND CONNECT PORT B TO PORT D.
2. MAKE SURE THE DEVICE BUS ADDRESSES AGREE WITH THE DEFAULT VALUES DEFINED IN SECTION 7.1. IF NOT, CHANGE LOCATION(S) AS DESIRED VIA THE 'ADDRESS/' ODT COMMAND.
3. THE PROGRAM SHOULD ALWAYS BE STARTED AT 200. STARTING AT 200(200G OR .R CVDRDB UNDER XXDP+), THE PROGRAM INITIALIZES ITSELF, PRINTS ITS ID(FIRST TIME ONLY) AND THEN PRINTS THAT THE DRV11-J CABLE IS REQUIRED(FIRST TIME ONLY) AND THEN PRINTS: SWR=XXXXXX NEW=

WHERE XXXXXX REPRESENTS THE CURRENT VALUE OF THE SOFTWARE SWITCH REGISTER. IF NO CHANGES ARE REQUIRED IN THE SWITCH REGISTER THEN JUST HIT CARRIAGE RETURN. IF CHANGES ARE REQUIRED, THEN A NEW VALUE MAY BE TYPED FOLLOWED BY A CARRIAGE RETURN. REFER TO SECTION 5.0 FOR SWITCH REGISTER OPTIONS.

5.0 SOFTWARE SWITCH REGISTER

5.1 OPTIONS

THE PROGRAM SWITCH DEFAULT MODE IS SWR = 000000
IF USING A VIDEO TERMINAL, BIT 15 = 1 (HALT ON ERROR),
MAY BE HELPFUL IN KEEPING THE ERROR ON THE SCREEN.

SWITCH	OCTAL	FUNCTION
-----	-----	-----
SW15=1	100000	HALT ON ERROR
SW14=1	040000	LOOP ON TEST
SW13=1	020000	INHIBIT ERROR TYPEOUTS
SW12=1	010000	INHIBIT ILLEGAL VECTOR RETURN ROUTINES
SW11=1	004000	INHIBIT ITERATIONS
SW09=1	001000	LOOP ON ERROR
SW08=1	C004XX	LOOP ON TEST IN SWR <7-0>

* SW12 EXPLANATION

SW12 = 1 WILL STORE THE REGULAR TRAP (PC+2, HALT) IN LOCATIONS 204-1774 FOR THE VECTOR TESTING. ON ILLEGAL VECTOR ERRORS, THIS WILL AID THE USER TO DETERMINE THE LOCATION OF THE ILLEGAL VECTOR. THE LOOPING CAPASILITIES THAT ARE NORMALLY PROVIDED BY ILLEGAL VECTOR SERVICE ROUTINES WHEN SW12=0 WILL NO LONGER BE AVAILABLE WHEN SW12 = 1.

IF USING SW12=1 TO TRACK DOWN THE ILLEGAL VECTOR, THE
USER SHOULD RESTART AT ADDRESS 200 WITH SW12=0 TO
OBTAIN LOOPING CAPABILITIES AFTER ERROR OCCURS.
VECTOR AREA 0-200 WILL ALWAYS HAVE ILLEGAL VECTOR ROUTINES
WHEN VECTOR TESTING (0-200) IN ORDER TO PRESERVE PROGRAM.

* WARNING:

PLEASE USE 'CTRL AND G' KEYS AND WAIT FOR THE 'CTRL G' TO BE ECHOED BEFORE ATTEMPTING TO HALT THE CPU OR TO STOP TESTING OR THE PROGRAM MAY NOT BE RESTARTABLE.

PROGRAM RELOCATION FOR LOCATIONS 0-200 TAKES PLACE DURING THE VECTOR TESTING OF 0-200. THE NORMAL CONTENTS OF 0-200 MAY NOT GET RESTORED IF THE CPU IS HALTED AND RELOAD OF THE PROGRAM MAY BE NECESSARY.

1. THE SOFTWARE SWITCH REGISTER 'SWREG' (LOC. 176) CAN BE CHANGED BY USING THE ODT FACILITIES.
2. THE SOFTWARE SWITCH REGISTER CAN BE CHANGED UNDER PROGRAM CONTROL BY TYPING THE 'CONTROL & G' KEYS. THIS KEYBOARD OPERATION WILL PRINT OUT THE CURRENT CONTENTS AND ACCEPT NEW OCTAL SWITCH REGISTER DATA TERMINATED WITH A CARRIAGE RETURN.
3. ONCE THE ODT MODE HAS BEEN ENTERED BECAUSE OF AN ERROR CONDITION WITH BIT15 SET (HALT ON ERROR), STEP #2 ABOVE IS OF NO VALUE, SO RESORT TO STEP #1 TO ALTER THE SOFTWARE SWITCH REGISTER IF DESIRED BEFORE TYPING 'P' (CONTINUE).

6.0 ERROR REPORTING

6.1 ERROR COMMENT

ALL ERRORS ARE ACCOMPANIED WITH AN ENGLISH LANGUAGE DESCRIPTIVE COMMENT AS TO THE TYPE OF FAILURE. FURTHER QUALIFICATION OF THE ERROR CAN BE OBTAINED IF NEEDED FROM THE COMMENT AT THE ERROR PC OR FROM THE TEST ITSELF.

6.2 ERROR DATA

6.2.1 ERROR TITLE TYPE A

1. REG READ/WRITE ER
2. IRR REG ER
3. ACR REG ER
4. IMR REG ER
5. ISR REG ER

6. CHIP STAT ER

7. MULTIPLE INTERRUPTS RECEIVED

8. INTERRUPT TEST ERROR

```
ERRPC  TSTNUM  BUSADR  VAM    ADDR  EXPCT  RCVD
XXXXXX XXXXXX XXXXXX XXXXXX XXXXXX XXXXXX XXXXXX
```

```
ERRPC      LISTING ADDRESS WHERE THE ERROR WAS DETECTED
TSTNUM     TEST NUMBER WHERE THE ERROR OCCURRED
BUSADR     DRV11J BUS REG ADDRESS OF CONCERNED OPERATION
VAM        VALUE STORED INTO VECTOR ADDRESS MEMORY
           INDICATING BYTE COUNT AND LEVEL.
ADDR       VECTOR ADDRESS
EXPCT      DATA THAT WAS EXPECTED
RCVD       DATA THAT WAS RECEIVED
```

6.2.2 ERROR TITLE TYPE B

1. ILLEGAL INTERRUPT RECEIVED

```
ERRPC  TSTNUM  BUSADR  VAM    ADDR
XXXXXX XXXXXX XXXXXX XXXXXX XXXXXX
```

```
ERRPC      ADDRESS WHERE THE ERROR WAS DETECTED
TSTNUM     TEST NUMBER WHERE THE ERROR OCCURRED
BUSADR     DRV11J BUS ADDRESS
VAM        VALUE OF VECTOR ADDRESS MEMORY
           AT TIME OF ILLEGAL INTERRUPT.
ADDR       VECTOR ADDRESS
```

6.2.3 ERROR TITLE TYPE C

1. ILLEGAL VECTOR MEM ADDR ER

```
ERRPC  TSTNUM  TESTPC  BUSADR  VAM    ADDR
XXXXXX XXXXXX XXXXXX XXXXXX XXXXXX XXXXXX
```

```
ERRPC      ADDRESS WHERE ERROR WAS DETECTED
TSTNUM     TEST NUMBER WHERE THE ERROR OCCURED
TESTPC     ADDRESS OF TEST THAT WAS RUNNING
           WHEN DRV11J VECTORED TO THE WRONG ADDRESS.
BUSADR     BUS ADDRESS OF CONCERNED OPERATION
VAM        VALUE OF VECTOR ADDRESS MEMORY
           BYTE COUNT AND LEVEL.
ADDR       CORRECT VECTOR ADDRESS
```

6.2.4 ERROR TYPE D

THIS ERROR IS ONLY FOUND WHEN RUNNING THE VECTOR ADDRESS UNIQUENESS TESTS. THE VECTOR MEMORY IS PRESET TO PERFORM 64 INTERRUPTS. INTERRUPT SERVICE ROUTINES ARE STORED FROM VECTORS 300 TO 674. THE ROUTINES WILL STORE THE VALUE OF THE VECTOR ADDRESS WHERE THEY CAME FROM IN A BUFFER TO COMPARE AFTER ALL INTERRUPTS TAKE PLACE. THE BUFFER SHOULD THEN HAVE ADDRESS VALUES IN CONSECUTIVE ORDER STARTING WITH VECTOR VALUE 300 AND ENDING WITH VECTOR VALUE 674.

1. VECT ADDR MEM ER
 ERRPC TSTNUM BUSADR EXPCT RCVD
 XXXXXX XXXXXX XXXXXX XXXXXX XXXXXX

ERRPC ADDRESS WHERE ERROR WAS DETECTED
 TSTNUM TEST NUMBER WHERE ERROR OCCURRED
 BUSADR STARTUP BUS ADDRESS BEFORE VECTOR UNIQUENESS
 EXPCT 'S IS THE EXPECTED VECTOR ADDRESS
 RCVD VECTOR ADDRESS VALUE STORED IN BUFFER

7.0 MISCELLANEOUS

7.1 DRV11-J BUS ADDRESS MODIFICATION

MODIFY LOCATION '\$BASE'(ADDR:2244) IF BASE BUS ADDRESS IS NOT 164160.

7.2 XXDP/APT NOTES

THIS DIAGNOSTIC DOES SUPPORT ACT AND APT ENVIRONMENTS.

7.3 POWER FAIL

A POWER FAILURE WILL CAUSE A RESTART MESSAGE ON POWER UP AT WHICH TIME THE PROGRAM IS RESTARTED (ONLY ON SYSTEMS WITH NON-VOLATILE MEMORY AND WITH APPROPRIATE HARDWARE).

7.4 MULTIPLE DRV11J INTERFACE TESTING

THIS PROGRAM DOES NOT 'AUTO-SIZE' THE NUMBER OF DRV11J'S CONNECTED. THIS DIAGNOSTIC WILL TEST SEQUENTIALLY UP TO 4 DRV11J INTERFACES WITH CONTIGUOUS BUS ADDRESSES. THIS IS ACCOMPLISHED BY THE USER SETTING UP LOCATION '\$DEVN' (ADDR:2246) WITH A BIT MAP INDICATING WHAT INTERFACES ARE TO BE TESTED.

I.E. BIT0= 1 SAYS TEST 1ST DRV11J,
 BIT1= 1 SAYS TEST 1ST DRV11J
 BIT2= 1 SAYS TEST 2ND DRV11J
 BIT3= 1 SAYS TEST 3RD DRV11J

1ST UNIT = STARTING CSRA	164160	\$DEVN = 1
2ND UNIT = STARTING CSRA	164140	\$DEVN = 3
3RD UNIT = STARTING CSRA	164120	\$DEVN = 7
4TH UNIT = STARTING CSRA	164100	\$DEVN = 17

7.5 RESTRICTIONS

ALWAYS TYPE 'CTRL G' AND WAIT FOR ECHO OF CHARACTERS BEFORE HALTING THE CPU OTHERWISE PORTIONS OF THE PROGRAM MAY NOT GET RESTORED. FOR MORE INFORMATION REFER TO SECTION 5.2.

8.0 EXECUTION TIME

EXECUTION TIME WILL BE LESS THAN 30 SECONDS PER DRV11J UNIT CONNECTED. AN 'END PASS' MESSAGE INDICATES ALL TESTS HAVE COMPLETED ON ALL SELECTED UNITS.

GENERAL

THIS DIAGNOSTIC CONTAINS A SERIES OF INDEPENDENT TESTS DESIGNED TO TEST LOGIC FUNCTIONS AND DATA PATHS OF THE DRV11J OPTION. TESTING IS ACCOMPLISHED WITH THE AID OF THE DRV11J LOOP BACK CABLE PROVIDED FOR DIAGNOSTIC TESTING. A COMPLETE LIST OF TESTS IS AVAILABLE IN THE TABLE OF CONTENTS AT THE BEGINNING OF THE LISTING. THE COMMENT FIELD WITHIN EACH TEST CAN BE BENEFICIAL IN TEST UNDERSTANDING.

REFERENCES ARE MADE IN THE LISTING TO THE TWO INTERRUPT CONTROL CHIPS USED ON THE DRV11J AS GROUP1 AND GROUP2.

GROUP1 CHIP CSRA = CONTROL FOR GROUP 1
 CSRB = DATA FOR GROUP1
GROUP2 CHIP CSRC = CONTROL FOR GROUP2
 CSRD = DATA FOR GROUP2

9.1 TEST 1 - TEST CHIP INTERRUPT, GROUP1, GROUP2

THIS TEST WILL CHECK THE ABILITY OF EACH INTERRUPT CONTROL CHIP TO INTERRUPT TO COMMON VECTOR 300. THIS TEST WILL ALSO CLEAR THE HIGHEST PRIORITY ISR BITS WITH TEST VARIATIONS OF IRR AND IMR BITS.

9.2 TEST 2 - TEST ACR/ISR INTERRUPT, GROUP 1, GROUP 2

THIS TEST WILL TEST THE ABILITY OF BOTH GROUPS TO INTERRUPT TO COMMON VECTOR 300 AND THE ABILITY OF THE ACR(AUTOCLEAR REGISTER TO CLEAR THE ISR AFTER BEING SET AND MASKED BY COMBINATIONS OF IRR BITS AND IMR BITS.

9.3 TEST 3 - TEST VECTOR ADDR MEM, LEV 0-7, BY0-3, (204-1774), GRPS 1,2

THIS TEST WILL CHECK BOTH GROUPS, ONE AT A TIME, TO VECTOR FROM ADDRESS 204 TO ADDRESS 1774 FOR LEVELS 0-7 AND FOR BYTE COUNTS 1-4. THE BYTE COUNT NUMBER WILL INDICATE THE NUMBER OF INTERRUPTS AT A GIVEN ADDRESS. THE IRR, IMR AND ACR REGISTERS WILL ALL BE EXERCISED AND CHECKED TO INSURE PROPER VECTORING.

9.4 TEST 4 - TEST VECTOR ADDR MEM, LEV 0-7, BY0-3, (0-200), GRPS 1,2

THIS TEST WILL CHECK BOTH GROUPS, ONE AT A TIME, TO VECTOR FROM ADDRESS 0-200 FOR LEVELS 0-7 AND FOR BYTE COUNTS 1-4. TESTS ARE DONE TO INSURE THAT INTERRUPTS ONLY TAKE PLACE WHEN EVERYTHING IS READY. THE CHIP BEING ARMED, INTERRUPT ENABLE IS SET AND THE PROPER IMR AND IRR BITS ARE SET. AFTER THE INTERRUPTS CHECK TO INSURE THAT THE INTERRUPTS GENERATED MATCH THE BYTE COUNT AND THAT THE PROPER ISR BITS WERE SET AND THE PROPER IRR BITS WERE CLEARED.

9.5 TEST 5 - TEST VECTOR ADDR UNIQUENESS IN FIXED MODE FOR GROUPS 1,2

THIS TEST WILL CHECK THE FIXED PRIORITY OF THE TWO INTERRUPT CONTROL CHIPS AS WELL AS THE ADDRESSING CAPABILITY OF THE VECTOR ADDRESS MEMORY. THE AUTOCLEAR REGISTER(ACR) IS USED TO CLEAR OUT THE ISR BITS AFTER 4 INTERRUPTS PER LEVEL HAS TAKEN PLACE. CLEARING THE ISR REGISTER WILL THEN ALLOW THE NEXT LEVEL OF PRIORITY TO INITIATE 4 INTERRUPTS. THE VECTOR MEMORY IS PRESET TO PERFORM 64 UNIQUE INTERRUPTS. INTERRUPT SERVICE ROUTINES ARE STORED FROM VECTORS 300-674. EACH INTERRUPT SERVICE ROUTINE UPON INTERRUPT ENTRY WILL STORE THE ADDRESS OF ITS VECTOR IN A BUFFER FOR A COMPARE AFTER 64 INTERRUPTS TAKE PLACE. THE BUFFER SHOULD THEN HAVE ADDRESS VALUES IN CONSECUTIVE ORDER STARTING WITH VECTOR VALUE 300 AND ENDING WITH VECTOR VALUE 674.

9.6 TEST 6 - TEST VECTOR ADDRESS UNIQUENESS,ROTATING PRIORITY FOR BOTH GROUPS 1,2

THIS TEST WILL CHECK THE ROTATING PRIORITY OF EACH OF THE TWO INTERRUPT CONTROL CHIPS AS WELL AS THE ADDRESSING CAPABILITY OF THE VECTOR ADDRESS MEMORY. THE VECTOR ADDRESS MEMORY IS PRESET FOR 64 UNIQUE INTERRUPTS. INTERRUPT SERVICE ROUTINES ARE STORED FROM VECTORS 300-674. ALL IRR BITS ARE SET AND ALL IMR BITS ARE CLEARED. AFTER THE FIRST FOUR INTERRUPTS FROM IRRO TAKES PLACE, THE ISRO BIT WILL SET AND IRRO BIT WILL CLEAR. TO PROVE ROTATION OF PRIORITY,THE ISRO BIT IS CLEARED AND THE IRRO BIT IS SET AGAIN IN ORDER TO PROVE THAT IRR1 WILL NOW BE CONSIDERED THE HIGHEST PRIORITY AND IRRO THE LOWEST PRIORITY. THIS FLOW IS REPEATED FOR ALL LEVELS OF GROUP 1(0-7). THEN GROUP 2 IS TESTED IN THE SAME MANNER FOR LEVELS 0-7. EACH INTERRUPT SERVICE ROUTINE UPON ACCESS FROM AN INTERRUPT WILL STORE THE ADDRESS OF THE VECTOR WHERE THE ROUTINE RESIDES IN A BUFFER. AFTER ALL 64 INTERRUPTS TAKE PLACE(4 AT A TIME FOR EACH LEVEL)THE BUFFER WILL BE CHECKED FOR CONSECUTIVE VECTOR VALUES OF 300-674. THIS WILL INSURE THAT PROPER VECTOR ADDRESSING AND ROTATION OF PRIORITIES WAS COMPLETED.

10.0 LISTING

```
(1)          000006      SP=      %6          ;;STACK POINTER
(1)          000007      PC=      %7          ;;PROGRAM COUNTER
(1)
(1)          ;*PRIORITY LEVEL DEFINITIONS
(1)          300000      PR0=      0          ;;PRIORITY LEVEL 0
(1)          000040      PR1=      40         ;;PRIORITY LEVEL 1
(1)          000100      PR2=      100        ;;PRIORITY LEVEL 2
(1)          000140      PR3=      140        ;;PRIORITY LEVEL 3
(1)          000200      PR4=      200        ;;PRIORITY LEVEL 4
(1)          000240      PR5=      240        ;;PRIORITY LEVEL 5
(1)          000300      PR6=      300        ;;PRIORITY LEVEL 6
(1)          000340      PR7=      340        ;;PRIORITY LEVEL 7
(1)
(1)          ;*'SWITCH REGISTER' SWITCH DEFINITIONS
(1)          100000      SW15=     100000
(1)          040000      SW14=     40000
(1)          020000      SW13=     20000
(1)          010000      SW12=     10000
(1)          004000      SW11=     4000
(1)          002000      SW10=     2000
(1)          001000      SW09=     1000
(1)          000400      SW08=     400
(1)          000200      SW07=     200
(1)          000100      SW06=     100
(1)          000040      SW05=     40
(1)          000020      SW04=     20
(1)          000010      SW03=     10
(1)          000004      SW02=     4
(1)          000002      SW01=     2
(1)          000001      SW00=     1
(1)          .EQUIV      SW09,SW9
(1)          .EQUIV      SW08,SW8
(1)          .EQUIV      SW07,SW7
(1)          .EQUIV      SW06,SW6
(1)          .EQUIV      SW05,SW5
(1)          .EQUIV      SW04,SW4
(1)          .EQUIV      SW03,SW3
(1)          .EQUIV      SW02,SW2
(1)          .EQUIV      SW01,SW1
(1)          .EQUIV      SW00,SW0
(1)
(1)          ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
(1)          100000      BIT15=    100000
(1)          040000      BIT14=    40000
(1)          020000      BIT13=    20000
(1)          010000      BIT12=    10000
(1)          004000      BIT11=    4000
(1)          002000      BIT10=    2000
(1)          001000      BIT09=    1000
(1)          000400      BIT08=    400
(1)          000200      BIT07=    200
(1)          000100      BIT06=    100
(1)          000040      BIT05=    40
(1)          000020      BIT04=    20
(1)          000010      BIT03=    10
(1)          000004      BIT02=    4
```



```

50          000250          MIRR= 250
51          000254          MACR= 254
52
53          ;CHIP WRITE PRESELECTION
54          000300          PACR= 300          ;PRESELECT AUTO CLEAR REG. FOR WRITING
55          000260          PIMR= 260          ;PRESELECT IMR REG. FOR WRITING
56          000340          PVMA= 340          ;PRESELECT VECTOR MEMORY ADDRESS
57
58          .SBTTL TRAP CATCHER
(1)
(1)          000000          .=0
(1)          ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
(1)          ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
(1)          ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
(1)          000174          .=174
(1) 000174 000000          DISPREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER
(1) 000176 000000          SWREG: .WORD 0          ;;SOFTWARE SWITCH REGISTER
(1)          .SBTTL STARTING ADDRESS(ES)
(1) 000200 000137 002476          JMP @START ;;JUMP TO STARTING ADDRESS OF PROGRAM
59          000100          .=100
60 000100 000104 000200 000002          .WORD 104,200,2          ;IF 'B EVENT' ON Q BUS IS CONNECTED
61          ;IGNORE IT'S INTERRUPT - JUST DO A RTI
  
```

63
(1)
(2)
(1)
(1)
(1) 000046
(1) 000052
(1)
(1) 64
(1) 65
(1) 66
(1) 67
(1) 68
(1)
(2)
(1)
(2)
(1) 000024
(1) 000044
(1)
(2)
(1)
(1)
(1) 002000
(1) 002002
(1) 002004
(1) 002006
(1) 002010
(1) 002012

```
.SBTTL ACT11 HOOKS

:*****
:HOOKS REQUIRED BY ACT11
  $VPC=      ;SAVE PC
  =46        ;;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
  $ENDAD     ;;2)SET LOC.52 TO ZERO
  =52        ;; RESTORE PC
  .WORD 0
  =$$VPC
  =2000

;LONGEST TEST TIME
;1ST PASS RUN TIME
;ADDITIONAL RUN TIME

.SBTT. APT PARAMETER BLOCK

:*****
:SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
:*****
  $X=        ;;SAVE CURRENT LOCATION
  =24        ;;SET POWER FAIL TO POINT TO START OF PROGRAM
  200        ;;FOR APT START UP
  =44        ;;POINT TO APT INDIRECT ADDRESS PNTR.
  $APTHDR    ;;POINT TO APT HEADER BLOCK
  =.$X       ;;RESET LOCATION COUNTER

:*****
:SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
:INTERFACE SPEC.

$APTHD:
$HIBTS: .WORD 0    ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBADR: .WORD $MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)
$TSTM:  .WORD 12   ;;RUN TIME OF LONGEST TEST
$PASTM: .WORD 30   ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
$UNITM: .WORD 30   ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
        .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
```


(2)	002210		SETABLE:		::: APT ENVIRONMENT TABLE
(2)	002210	000	SENV:	.BYTE	AENV ::: ENVIRONMENT BYTE
(2)	002211	000	SENVN:	.BYTE	AENVN ::: ENVIRONMENT MODE BITS
(2)	002212	000000	SSWREG:	.WORD	ASWREG ::: APT SWITCH REGISTER
(2)	002214	000000	SUSWR:	.WORD	AUSWR ::: USER SWITCHES
(2)	002216	000000	SCPUOP:	.WORD	ACPUOP ::: CPU TYPE, OPTIONS
(2)			*		BITS 15-11=CPU TYPE
(2)			*		11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
(2)			*		11/70=06,PDQ=07,Q=10
(2)			*		BIT 10=REAL TIME CLOCK
(2)			*		BIT 9=FLOATING POINT PROCESSOR
(2)			*		BIT 8=MEMORY MANAGEMENT
(2)	002220	000	SMAMS1:	.BYTE	AMAMS1 ::: HIGH ADDRESS, M.S. BYTE
(2)	002221	000	SMTYP1:	.BYTE	AMTYP1 ::: MEM. TYPE, BLK#1
(2)			*		MEM. TYPE BYTE -- (HIGH BYTE)
(2)			*		900 NSEC CORE=001
(2)			*		300 NSEC BIPOLAR=002
(2)			*		500 NSEC MOS=003
(2)	002222	000000	SMADR1:	.WORD	AMADR1 ::: HIGH ADDRESS, BLK#1
(2)			*		MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
(2)	002224	000	SMAMS2:	.BYTE	AMAMS2 ::: HIGH ADDRESS, M.S. BYTE
(2)	002225	000	SMTYP2:	.BYTE	AMTYP2 ::: MEM. TYPE, BLK#2
(2)	002226	000000	SMADR2:	.WORD	AMADR2 ::: MEM. LAST ADDRESS, BLK#2
(2)	002230	000	SMAMS3:	.BYTE	AMAMS3 ::: HIGH ADDRESS, M.S. BYTE
(2)	002231	000	SMTYP3:	.BYTE	AMTYP3 ::: MEM. TYPE, BLK#3
(2)	002232	000000	SMADR3:	.WORD	AMADR3 ::: MEM. LAST ADDRESS, BLK#3
(2)	002234	000	SMAMS4:	.BYTE	AMAMS4 ::: HIGH ADDRESS, M.S. BYTE
(2)	002235	000	SMTYP4:	.BYTE	AMTYP4 ::: MEM. TYPE, BLK#4
(2)	002236	000000	SMADR4:	.WORD	AMADR4 ::: MEM. LAST ADDRESS, BLK#4
(2)	002240	000000	SVECT1:	.WORD	AVECT1 ::: INTERRUPT VECTOR#1, BUS PRIORITY#1
(2)	002242	000000	SVECT2:	.WORD	AVECT2 ::: INTERRUPT VECTOR#2, BUS PRIORITY#2
(2)	002244	164160	SBASE:	.WORD	ABASE ::: BASE ADDRESS OF EQUIPMENT UNDER TEST
(2)	002246	000001	SDEVN:	.WORD	ADEVN ::: DEVICE MAP
(2)	002250	000000	SCDW1:	.WORD	ACDW1 ::: CONTROLLER DESCRIPTION WORD#1
(2)	002252		SETEND:		
(2)			.MEXIT		

(1)			.SBTTL	ERROR POINTER TABLE					
(1)			;	*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.					
(1)			;	*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN					
(1)			;	*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.					
(1)			;	*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).					
(1)			;	*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:					
(1)			;	*	EM		;	POINTS TO THE ERROR MESSAGE	
(1)			;	*	DH		;	POINTS TO THE DATA HEADER	
(1)			;	*	DT		;	POINTS TO THE DATA	
(1)			;	*	DF		;	POINTS TO THE DATA FORMAT	
(1)			\$ERRTB:						
70	002252		:ERROR	1					
71	002252	016101		EM1			:	REG TIMEOUT ER	
72	002254	016416		DH1			:	ERRPC TSTNUM	BUSADR EXPCT RCVD
73	002256	016666		DT1			:	\$ERRPC TSTNUM	\$BDADR \$GDDAT \$BDDAT
74	002260	000000		0					
76			:ERROR	2					
77	002262	016120		EM2			:	REG READ/WRITE ER	
78	002264	016463		DH2			:	ERRPC TSTNUM	BUSADR VAM ADDR EXPCT RCVD
79	002266	016702		DT2			:	\$ERRPC TSTNUM	\$BDADR VECVAL VECLOC \$GDDAT \$BDDAT
80	002270	000000		0					
82			:ERROR	3					
83	002272	016142		EM3			:	IRR REG ER	
84	002274	016463		DH2			:	ERRPC TSTNUM	BUSADR VAM ADDR EXPCT RCVD
85	002276	016702		DT2			:	\$ERRPC TSTNUM	\$BDADR VECVAL VECLOC \$GDDAT \$BDDAT
86	002300	000000		0					
88			:ERROR	4					
89	002302	016155		EM4			:	ACR REG ER	
90	002304	016463		DH2			:	ERRPC TSTNUM	BUSADR VAM ADDR EXPCT RCVD
91	002306	016702		DT2			:	\$ERRPC TSTNUM	\$BDADR VECVAL VECLOC \$GDDAT \$BDDAT
92	002310	000000		0					
94			:ERROR	5					
95	002312	016170		EM5			:	IMR REG ERROR	
96	002314	016463		DH2			:	ERRPC TSTNUM	BUSADR VAM ADDR EXPCT RCVD
97	002316	016702		DT2			:	\$ERRPC TSTNUM	\$BDADR VECVAL VECLOC \$GDDAT \$BDDAT
98	002320	000000		0					
100			:ERROR	6					
101	002322	016203		EM6			:	ISR REG ERROR	
102	002324	016463		DH2			:	ERRPC TSTNUM	BUSADR VAM ADDR EXPCT RCVD
103	002326	016702		DT2			:	\$ERRPC TSTNUM	\$BDADR VECVAL VECLOC \$GDDAT \$BDDAT
104	002330	000000		0					
106			:ERROR	7					
107	002332	016375		EM14			:	VECTOR ADDR MEM ER	
108	002334	016416		DH1			:	ERRPC TSTNUM	BUSADR EXPCT RCVD
109	002336	016666		DT1			:	\$ERRPC TSTNUM	\$BDADR \$GDDAT \$BDDAT
110	002340	000000		0					

```
111
112      :ERROR 10
113 002342 016251      EM10      :CHIP STAT ER
114 002344 016463      DH2      :ERRPC TSTNUM BUSADR VAM ADDR EXPCT RCVD
115 002346 016702      DT2      :SERRPC TSTNUM $BDADR VECVAL VECLOC $GDDAT $BDDAT
116 002350 000000      0
117
118      :ERROR 11
119 002352 016266      EM11      :ILLEGAL INTERRUPT RECEIVED
120 002354 016550      DH3      :ERRPC TSTNUM BUSADR VAM ADDR
121 002356 016722      DT3      :SERRPC TSTNUM $BDADR VECVAL VECLOC
122 002360 000000      0
123
124      :ERROR 12
125 002362 016316      EM12      :INTERRUPT TEST ERROR
126 002364 016463      DH2      :ERRPC TSTNUM BUSADR VAM ADDR EXPCT RCVD
127 002366 016702      DT2      :SERRPC TSTNUM $BDADR VECVAL VECLOC $GDDAT $BDDAT
128 002370 000000      0
129
130      :ERROR 13
131 002372 016343      EM13      :MULTIPLE INTERRUPTS RECEIVED
132 002374 016463      DH2      :MULTIPLE INTERRUPTS RECEIVED
133 002376 016702      DT2      :ERRPC TSTNUM BUSADR VAM ADDR EXPCT RCVD
134 002400 000000      0      :SERRPC TSTNUM $BDADR VECVAL VECLOC $GDDAT $BDDAT
135
136      :ERROR 14
137 002402 016216      EM7      :ILLEGAL VECTOR ADDR MEM ERROR
138 002404 016615      DH4      :ERRPC TSTNUM TESTPC BUSADR VAM ADDR
139 002406 016736      DT4      :SERRPC TSTNUM $GDADR $BDADR VECVAL VECLOC
140 002410 000000      0
141
142
143      ; BUS REGISTER ADDRESS POINTERS
144
145
146 DRCSA: ABASE
147 DRDBA: ABASE+2
148 DRCSB: ABASE+4
149 DRDBB: ABASE+6
150 DRDSC: ABASE+10
151 DRDBC: ABASE+12
152 DRDSD: ABASE+14
153 DRDBD: ABASE+16
154
155
156      ;COMMON PROGRAM LOCATION(S)
157
158 TSTNUM: 0      ;CONTAINS TEST NUMBER ON ERROR
159 DMAP: 1
160 INTFLG: .WORD 0
161 XXDP: .WORD 0
162 IMRLOC: .WORD 0
163 ISRLOC: .WORD 0
164 IRRLOC: .WORD 0
165 ACRLOC: .WORD 0
166 VECLOC: .WORD 0
```

167	002454	000000	VECPAT: .WORD	0
168	002456	000000	VECVL: .WORD	0
169	002460	000000	SWRSV: .WORD	0
170	002462	000000	GRPCNT: .WORD	0
171	002464	000000	BDSAV: .WORD	0
172	002466	000000	LVLCNT: .WORD	0
173	002470	000000	BYCNT: .WORD	0
174	002472	000000	BYNUM: .WORD	0
175	002474	000000	LVLSAV: .WORD	0

```

178          .SBTTL PROGRAM START
179 002476   START:
(1)          .SBTTL INITIALIZE THE COMMON TAGS
(1)          ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
(1) 002476 012706 002100   MOV    # $CMTAG,R6      ;;FIRST LOCATION TO BE CLEARED
(1) 002502 005026          CLR    (R6)+          ;;CLEAR MEMORY LOCATION
(1) 002504 022706 002140   CMP    #SWR,R6      ;;DONE?
(1) 002510 001374          BNE    -6           ;;LOOP BACK IF NO
(1) 002512 012706 002100   MOV    #2100,SP     ;;SETUP THE STACK POINTER
(1)          ;;INITIALIZE A FEW VECTORS
(1) 002516 012737 014462 000020   MOV    # $SCOPE,@#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
(1) 002524 012737 000340 000022   MOV    #340,@#IOTVEC+2 ;;LEVEL 7
(1) 002532 012737 014134 000030   MOV    # $ERROR,@#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
(1) 002540 012737 000340 000032   MOV    #340,@#EMTVEC+2 ;;LEVEL 7
(1) 002546 012737 015732 000034   MOV    # $TRAP,@#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
(1) 002554 012737 000340 000036   MOV    #340,@#TRAPVEC+2;LEVEL 7
(1) 002562 012737 015526 000024   MOV    # $PWRDN,@#PWRVEC ;;POWER FAILURE VECTOR
(1) 002570 012737 000340 000026   MOV    #340,@#PWRVEC+2 ;;LEVEL 7
(1) 002576 005037 002160          CLR    $TIMES      ;;INITIALIZE NUMBER OF ITERATIONS
(1) 002602 005037 002162          CLR    $ESCAPE     ;;CLEAR THE ESCAPE ON ERROR A.  SS
(1) 002606 112737 000001 002115   MOV    #1,$ERMAX   ;;ALLOW ONE ERROR PER TEST
(1) 002614 012737 002614 002106   MOV    #.,$SLPADR  ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
(1) 002622 012737 002622 002110   MOV    #.,$SLPERR  ;;SETUP THE ERROR LOOP ADDRESS
(2)          ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
(2)          ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
(2) 002630 013746 000004          MOV    @#ERRVEC,-(SP) ;;SAVE ERROR VECTOR
(2) 002634 012737 002670 000004   MOV    #64$,@#ERRVEC ;;SET UP ERROR VECTOR
(2) 002642 012737 177570 002140   MOV    #DSWR,SWR   ;;SETUP FOR A HARDWARE SWICH REGISTER
(2) 002650 012737 177570 002142   MOV    #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
(2) 002656 022777 177777 177254   CMP    #-1,@SWR   ;;TRY TO REFERENCE HARDWARE SWR
(2) 002664 001012          BNE    66$        ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
(2)          ;;AND THE HARDWARE SWR IS NOT = -1
(2) 002666 000403          BR    65$        ;;BRANCH IF NO TIMEOUT
(2) 002670 012716 002676 64$:     MOV    #65$, (SP)  ;;SET UP FOR TRAP RETURN
(2) 002674 000002          RTI
(2) 002676 012737 000176 002140 65$:     MOV    #SWREG,SWR  ;;POINT TO SOFTWARE SWR
(2) 002704 012737 000174 002142   MOV    #DISPREG,DISPLAY
(2) 002712 012637 000004 66$:     MOV    (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR
(1)          CLR    $PASS      ;;CLEAR PASS COUNT
(2) 002716 005037 002176          BITB  #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
(2) 002722 132737 000200 002211   BEQ    67$        ;;YES,USE NON-APT SWITCH
(2) 002730 001403          MOV    # $$SWREG,SWR ;;NO,USE APT SWITCH REGISTER
(2) 002732 012737 002212 002140 67$:
(2) 002740          CLR    $FATAL     ;;CLEAR ERROR NUMBER
180 002740 005037 002172          CLR    $MSGTYP    ;;CLEAR MESSAGE TYPE
181 002744 005037 002170          CLR    $TESTN    ;;CLEAR TEST NUMBER
182 002750 005037 002174          CALL  FALCON     ;; CHECK FOR FALCON (KXT11)      ;;GPA
183 002754 004737 017360          BEQ    1000$     ;; BR IF NOT KXT11 SYSTEM      ;;GPA
184 002760 001420          BIC    #40,@#22  ;; FALCON, LOWER IOT...      ;;GPA
185 002762 042737 000040 000022   BIC    #40,@#32  ;;...EAT...                  ;;GPA
186 002770 042737 000040 000032   BIC    #40,@#36  ;;...AND TRAP TO LEVEL 6.    ;;GPA
187 002776 042737 000040 000036   CMP    $BASE,#ABASE ;; IS $BASE VIRGIN ??      ;;GPA
188 003004 023727 002244 164160   BNE    1000$     ;; BR IF NOT.                ;;GPA
189 003012 001003          MOV    #174160,$BASE ;; YES, USE ENGINEERING DEFAULT ;;GPA
190 003014 012737 174160 002244 1000$:
191 003022

```



```
192                                     :CHECK OPERATING ENVIRONMENT
193 003022 005737 000042                TST    2#42                :ARE WE IN ACT/XXDP AUTO MODE?
194 003026 001410                        BEQ    1$                  :BRANCH IF NO
195 003030 023737 000042 000046        CMP    2#42,2#46          :IS IT ACT AUTO MODE?
196 003036 001410                        BEQ    2$                  :BRANCH IF YES
197 003040 012737 177777 002440        MOV    #-1,XXDP          :SET XXDP CHAIN MODE INDICATOR
198 003046 000404                        BR     2$
199 003050 123727 002210 000001 1$:    CMPB   $ENV,#1           :ARE WE IN APT AUTO MODE?
200 003056 001003                        BNE    3$                  :BRANCH IF NO
201 003060 112737 000001 002134 2$:    MOVB   #1,$AUTOB        :SET AUTO MODE INDICATOR
202
203                                     :PRINT TITLE IF NOT IN ACT OR APT AUTO MODE
204 003066 005227 177777                3$:    INC    #-1                :FIRST TIME?
205 003072 001014                        BNE    5$                  :SKIP TITLE IF NO
206 003074 004537 011354                JSR    R5,TOBUF          :STORE 0-202 INTO BUFFER AREA
207 003100 005737 002134                TST    $AUTOB            :ARE WE IN AUTO MODE?
208 003104 001403                        BEQ    4$                  :BRANCH TO TITLE TYPEOUT IF NOT
209 003106 005737 002440                TST    XXDP              :IS THE AUTO MODE UNDER XXDP?
210 003112 001404                        BEQ    5$                  :SKIP TITLE IF NOT
211 003114 104401 016012                4$:    TYPE   ,TITLED        :PRINT OUT THE TITLE
212 003120 104401 016054                TYPE   ,TLCABL          :PRINT DRV11J CABLE REQ'D
213
214                                     :GET THE VALUE IN THE SOFTWARE SWITCH REGISTER
215 003124 005737 002134                5$:    TST    $AUTOB        :ARE WE IN AUTOMATIC MODE?
216 003130 001001                        BNE    START1            :BRANCH IF YES
217 003132 104406                        GTSWR                    :ASK FOR SWR INPUT FROM CONSOLE
218 003134 005037 002202                START1: CLR   $UNIT        :CLEAR UNIT NUMBER
219 003140 013737 002246 002434        MOV    $DEVN,DMAP        :UP TO 4 DRV11J'S
220 003146 042737 177760 002434        BIC    #177760,DMAP      :POSITION OF DRV11J'S
221 003154 013701 002244                MOV    $BASE,R1         :GET BASE ADDRESS
222 003160 010137 002412                MOV    R1,DRCSA         :MAKE BUS REG.POINTER = BASE
223 003164 032737 000001 002434        BIT    #1,DMAP          :IS FIRST DRV11-J SELECTED
224 003172 001002                        BNE    NEXPAS            :YES
225 003174 000137 010636                JMP    NXDEV1            :NO,ADVANCE BASE DRV11J ADDRESS
226 003200 012700 002412                NEXPAS: MOV   #DRCSA,R0   :SET UP REGISTER ADDRESS POINTERS
227 003204 010120                NEXPA1: MOV   R1,(R0)+    :LOAD EM
228 003206 062701 000002                ADD    #2,R1
229 003212 022700 002432                CMP    #DRDBD+2,R0      :ALL DONE?
230 003216 001372                        BNE    NEXPA1            :BR IF NOT
231 003220 004537 011524                JSR    R5,TRPCAT        :EXTEND TRAP CATCHER 204-1774
232 003224 012706 002100                MOV    #2100,SP         :ALWAYS RESET STACK
233 003230 013737 002202 002200        MOV    $UNIT,$DEVCT     :LOAD APT COUNTER WITH UNIT #
234 003236 123727 002210 000001        CMPB   $ENV,#1         :ARE WE IN APT MODE?
235 003244 001401                        BEQ    NEXPA2            :BR IF YES,SKIP RESET
236 003246 000005                        RESET
237 003250 106427 000340                NEXPA2: MTPS   #PR7
238
```

```

240
241
(3)
(3)
(2) 003254 000004
242 003256 013700 002412
243 003262 013701 002416
244 003266 013702 002412
245 003272 012737 003344 002110
246 003300 012737 000002 002462
247 003306 004537 011014 120$:
248 003312 012703 012636
249 003316 012737 000050 002442
250 003324 004537 011074
251 003330 012737 011644 000300
252 003336 012737 060340 000302
253 003344 005037 002436 111$:
254 003350 012706 002100
255 003354 112710 000340
256 003360 112711 000060
257 003364 010037 002122
258 003370 112710 000060
259 003374 113710 002442
260 003400 112710 000202
261 003404 106427 000000
262 003410 112712 000241
263
264
265 003414 112710 000241
266 003420 005737 002436
267 003424 001401
268 003426 104011
269 003430 005037 002436 1$:
270 003434 112710 000120
271 003440 106427 000340
272 003444 005737 002436
273 003450 001401
274 003452 104011
275 003454 005037 002436 2$:
276 003460 106427 000000
277 003464 152762 000002 000001
278 003472 012737 000001 002124
279 003500 013737 002436 002126
280 003506 023737 002124 002126
281 003514 001401
282 003516 104012
283 003520 106427 000340 3$:
284 003524 012737 101710 002124
285 003532 010237 002122
286 003536 011237 002126
287 003542 042737 000007 002126
288 003550 023737 002124 002126
289 003556 001401
290 003560 104002
291 003562 010137 002122 4$:
292 003566 005037 002126
  
```

```

*****
*TEST 1 TEST CHIP INTERRUPT ,GROUP 1, GROUP 2
*****
TST1: SCOPE
MOV DRCSA,R0 ;START WITH GROUP 1
MOV DRCSB,R1
MOV DRCSA,R2 ;REGISTER IS COMMON FOR BOTH GROUPS
MOV #111$, $LPERR ;SET UP LOOP RETURN
MOV #2, GRPCNT ;COUNTER FOR BOTH GROUPS
120$: JSR R5, CLRCSR ;CLEAR ALL CSRS
MOV #BGCHP3, R3 ;EXPECTED GDDAT FOR ISR, IMR
MOV #CSIMR, IMRLOC ;STORE CLEAR SINGLE IMR CODE
JSR R5, CLRIRR ;CLEAR IRR REGS
MOV #INTSR1, 300 ;STORE VECTOR ROUTINE
MOV #340, 302 ;STORE PSW
111$: CLR INTFLG ;CLEAR INT. FLAG
MOV #2100, SP ;INIT STACK IN CASE OF ILLEGAL INT. LOOP
MOVB #PVMA, (R0) ;PRESELECT VECTOR MEM ADDR
MOVB #60, (R1) ;WRITE VECTOR 300, BY 0, LVO
MOV R0, $BDADR ;SAVE BUS ADDRESS
MOVB #SIMR, (R0) ;SET ALL IMR BITS
MOVB IMRLOC, (R0) ;CLEAR MASK ON SINGLE BIT
MOVB #202, (R0) ;LMD04 - COMMON VECTOR
MTPS #PRO
MOVB #241, (R2) ;USED IN TEST OF GROUP 2
;ARM GROUP 1 TO PASS
;ENABLE TO GROUP 2.
;LMD57 - ARM THE CHIP
;CHECK FOR INTERRUPTS
MOV #241, (R0)
TST INTFLG
BEQ 1$
ERROR 11 ;ERROR, ILLEGAL INTERRUPT
1$: CLR INTFLG ;RESET INT. COUNTER
MOVB #SIRR, (R0) ;SET ALL IRR BITS
MTPS #PR7
TST INTFLG ;CHECK FOR NO INTERRUPTS
BEQ 2$
ERROR 11 ;ILLEGAL INTERRUPTS
2$: CLR INTFLG ;CLEAR INT. COUNTER
MTPS #PRO
BISB #BIT1, 1(R2) ;SET I/E, EXPECT INTERRUPT
MOV #1, $GDDAT ;EXPECT ONE INTERRUPT
MOV INTFLG, $BDDAT ;SHOULD HAVE ONE INTERRUPT
CMP $GDDAT, $BDDAT
BEQ 3$
ERROR 12 ;INTERRUPT TEST ERROR
3$: MTPS #PR7
MOV #101710, $GDDAT ;RDY, DIR, I/E, CHIP - 31X
MOV R2, $BDADR ;CSRA ADDRESS
MOV (R2), $BDDAT
BIC #7, $BDDAT ;CLEAR UNDEFINED BITS
CMP $GDDAT, $BDDAT
BEQ 4$
ERROR 2 ;CSRA REG ERROR
4$: MOV R1, $BDADR ;READY TO READ ISR REG.
CLR $BDDAT ;SET UP FOR BYTE READS
  
```

293	003572	005037	002124		CLR	\$GDDAT	:SET UP FOR BYTE EXPECTED	
294	003576	111337	002124		MOVB	(R3), \$GDDAT	:EXPECTED DATA	
295	003602	112710	000240		MOVB	#MISR, (R0)	:LOAD MODE TO READ ISR	
296	003606	111137	002126		MOVB	(R1), \$BDDAT		
297	003612	023737	002124	002126	CMP	\$GDDAT, \$BDDAT		
298	003620	001401			BEQ	5\$		
299	003622	104006			ERROR	6	:ISR ERROR	
300	003624	116337	000001	002124	5\$:	MOVB	1(R3), \$GDDAT	:STORE EXPECTED
301	003632	112710	000244		MOVB	#MIMR, (R0)	:LOAD MODE FOR IMR	
302	003636	111137	002126		MOVB	(R1), \$BDDAT		
303	003642	023737	002124	002126	CMP	\$GDDAT, \$BDDAT		
304	003650	001401			BEQ	6\$		
305	003652	104005			ERROR	5	:IMR ERROR	
306	003654	116337	000001	002124	6\$:	MOVB	1(R3), \$GDDAT	:EXPECTED IRR
307	003662	112710	000250		MOVB	#MIRR, (R0)	:LOAD MODE BITS FOR IRR	
308	003666	111137	002126		MOVB	(R1), \$BDDAT		
309	003672	023737	002124	002126	CMP	\$GDDAT, \$BDDAT		
310	003700	001401			BEQ	7\$		
311	003702	104003			ERROR	3	:IRR ERROR	
312	003704	005037	002124	7\$:	CLR	\$GDDAT		
313	003710	112710	000254		MOVB	#MACR, (R0)		
314	003714	111137	002126		MOVB	(R1), \$BDDAT		
315	003720	023737	002124	002126	CMP	\$GDDAT, \$BDDAT		
316	003726	001401			BEQ	10\$		
317	003730	104004			ERROR	4	:ACR ERROR	
318	003732	005037	002124	10\$:	CLR	\$GDDAT		
319	003736	112710	000140		MOVB	#CHPISR, (R0)	:CLEAR HIGHEST PRIOR ISR	
320	003742	112710	000240		MOVB	#MISR, (R0)	:LOAD MODE TO READ ISR	
321	003746	111137	002126		MOVB	(R1), \$BDDAT		
322	003752	023737	002124	002126	CMP	\$GDDAT, \$BDDAT		
323	003760	001401			BEQ	11\$		
324	003762	104006			ERROR	6	:ISR REG ERROR	
325	003764	012737	101710	002124	11\$:	MOV	#101710, \$GDDAT	:RDY, DIR, I/E, CHIP - 31X
326	003772	010237	002122		MOV	R2, \$BDADR	:CSRA ADDRESS	
327	003776	011237	002126		MOV	(R2), \$BDDAT		
328	004002	042737	000007	002126	BIC	#7, \$BDDAT	:CLEAR UNDEFINED BITS	
329	004010	023737	002124	002126	CMP	\$GDDAT, \$BDDAT		
330	004016	001401			BEQ	12\$		
331	004020	104002			ERROR	2	:CSRA REG ERROR	
332	004022	012737	100710	002124	12\$:	MOV	#100710, \$GDDAT	:RDY, DIR, CHIP - 31X
333	004030	042712	001000		BIC	#BIT9, (R2)	:CLEAR I/E	
334	004034	011237	002126		MOV	(R2), \$BDDAT	:READ CSRA	
335	004040	042737	000007	002126	BIC	#7, \$BDDAT	:CLEAR UNDEFINED BITS	
336	004046	023737	002124	002126	CMP	\$GDDAT, \$BDDAT		
337	004054	001401			BEQ	13\$		
338	004056	104002			ERROR	2	:CSRA REG ERROR	
339	004060	005723		13\$:	TST	(R3)+	:GET NEXT ISR, IMR EXPECTED RESULTS	
340	004062	020327	012656		CMP	R3, #EDCHP3	:CHECK FOR END	
341	004066	001404			BEQ	14\$		
342	004070	005237	002442		INC	IMRLOC	:INCREMENT MASK BIT TO CLEAR	
343	004074	000137	003344		JMP	111\$:TEST NEXT ISR BIT	
344	004100	005337	002462	14\$:	DEC	GRPCNT	:TESTED BOTH GROUPS?	
345	004104	001406			BEQ	TST2	:BR IF DONE	
346	004106	013700	002422		MOV	DRCSC, R0	:SETUP FOR GROUP 2	
347	004112	013701	002426		MOV	DRCSD, R1	:CSRC = CONTROL GROUP 2	
348							:CSRD = DATA GROUP 2	

```

349 004116 000137 003306      JMP      120$      :DO GROUP 2
350
351
352      :*****
(3)      :*TEST 2      TEST ACR/ISR INTERRUPT ,GROUP 1,GROUP 2
(3)      :*****
(2) 004122 000004      TST2:  SCOPE
353 004124 013700 002412      MOV      DRCSA,R0
354 004130 013701 002416      MOV      DRCSB,R1
355 004134 013702 002412      MOV      DRCSA,R2
356 004140 012737 004212 002110  MOV      #111$, $LPERR      ;SET UP LOOP RETURN
357 004146 012737 000002 002462  MOV      #2, GRPCNT      ;DO TWO GROUPS
358 004154 004537 011014 120$:  JSR      R5, CLRCR      ;CLEAR ALL CSRS
359 004160 012703 012636      MOV      #BGCHP3, R3      ;EXPECTED GDDAT FOR ISR
360 004164 012737 000050 002442  MOV      #CSIMR, IMRLOC      ;STORE CLEAR SINGLE IMR CODE
361 004172 004537 011074      JSR      R5, CLRIRR      ;CLEAR IRR REGS
362 004176 012737 011644 000300  MCV      #INTSR1, 300      ;STORE VECTOR ROUTINE
363 004204 012737 000340 000302  MOV      #340, 302      ;STORE PSW
364 004212 005037 002436 111$:  CLR      INTFLG      ;CLEAR INT. FLAG
365 004216 012706 002100      MOV      #2100, SP      ;INIT STACK IN CASE OF ILLEGAL INT. LOOP
366 004222 042712 001000      BIC      #BIT9, (R2)      ;CLEAR INTERRUPT ENABLE
367 004226 112712 000242      MOVB     #242, (R2)      ;CLEAR MASTER MASK GP1
368 004232 112710 000242      MOVB     #242, (R0)      ;CLEAR MASTER MASK GP1, GP2
369 004236 112710 000300      MOVB     #PACR, (R0)      ;PRESELECT ACR FOR WRITING
370 004242 111311      MOVB     (R3), (R1)      ;NEXT BIT INTO ACR
371 004244 112710 000340      MOVB     #PVMA, (R0)      ;PRESELECT VECTOR MEM ADDR
372 004250 112711 000060      MOVB     #60, (R1)      ;WRITE VECTOR 300, BY0, LVO
373 004254 010037 002122      MOV      R0, $BDADR      ;STORE BUS ADDRESS
374 004260 112710 000060      MOVB     #SIMR, (R0)      ;SET ALL IMR BITS
375 004264 113710 002442      MOVB     IMRLOC, (R0)      ;CLEAR MASK ON SINGLE BIT
376 004270 112710 000202      MOVB     #202, (R0)      ;LMD04 - COMMON VECTOR
377 004274 106427 000000      MTPS     #PRO
378 004300 152762 000002 000001  BISB     #BIT1, 1(R2)      ;SET I/E, NO INTERRUPT
379 004306 005737 002436      TST      INTFLG      ;CHECK FOR INTERRUPTS
380 004312 001401      BEQ      1$
381 004314 104011      ERROR    11      ;ERROR, ILLEGAL INTERRUPT
382 004316 005037 002436 1$:  CLR      INTFLG      ;RESET INT. COUNTER
383 004322 112710 000120      MOVB     #SIRR, (R0)      ;SET ALL IRR BITS
384 004326 106427 000340      MTPS     #PR7
385 004332 005737 002436      TST      INTFLG      ;CHECK FOR NO INTERRUPTS
386 004336 001401      BEQ      2$
387 004340 104011      ERROR    11      ;ILLEGAL INTERRUPTS
388 004342 005037 002436 2$:  CLR      INTFLG      ;CLEAR INT. COUNTER
389 004346 106427 000000      MTPS     #PRO
390 004352 112712 000241      MOVB     #241, (R2)      ;USED IN TEST OF GROUP 2
391      ;ARM GROUP 1 CHIP TO PASS
392      ;ENABLE TO GROUP 2 CHIP.
393 004356 112710 000241      MOVB     #241, (R0)      ;ARM THE CHIP
394 004362 012737 000001 002124  MOV      #1, $GDDAT      ;EXPECT ONE INTERRUPT
395 004370 013737 002436 002126  MOV      INTFLG, $BDDAT      ;SHOULD HAVE ONE INTERRUPT
396 004376 023737 002124 002126  CMP      $GDDAT, $BDDAT
397 004404 001401      BEQ      3$
398 004406 104012      ERROR    12      ;INTERRUPT TEST ERROR
399 004410 106427 000340 3$:  MTPS     #PR7
400 004414 010137 002122 4$:  MOV      R1, $BDADR      ;READY TO READ ISR REG.
401 004420 005037 002126      CLR      $BDDAT      ;SET UP FOR BYTE READS
    
```

402	004424	005037	002124	CLR	\$GDDAT	:SET UP FOR BYTE EXPECTED
403	004430	112710	000240	MOVB	#MISR,(R0)	:LOAD MODE TO READ ISR
404	004434	111137	002126	MOVB	(R1), \$BDDAT	
405	004440	023737	002124	CMP	\$GDDAT,\$BDDAT	:ACR SHOULD CLEAR ISR
406	004446	001401		BEQ	5\$	
407	004450	104006		ERROR	6	:ISR ERROR
408	004452	116337	000001	MOV	1(R3), \$GDDAT	:STORE EXPECTED
409	004460	112710	000244	MOV	#MIMR,(R0)	:LOAD MODE FOR IMR
410	004464	111137	002126	MOVB	(R1), \$BDDAT	
411	004470	023737	002124	CMP	\$GDDAT,\$BDDAT	
412	004476	001401		BEQ	6\$	
413	004500	104005		ERROR	5	:IMR ERROR
414	004502	116337	000001	MOV	1(R3), \$GDDAT	:EXPECTED IRR
415	004510	112710	000250	MOV	#MIRR,(R0)	:LOAD MODE BITS FOR IRR
416	004514	111137	002126	MOVB	(R1), \$BDDAT	
417	004520	023737	002124	CMP	\$GDDAT,\$BDDAT	
418	004526	001401		BEQ	7\$	
419	004530	104003		ERROR	3	:IRR ERROR
420	004532	111337	002124	MOV	(R3), \$GDDAT	:EXPECTED ACR
421	004536	112710	000254	MOV	#MACR,(R0)	
422	004542	111137	002126	MOVB	(R1), \$BDDAT	
423	004546	023737	002124	CMP	\$GDDAT,\$BDDAT	
424	004554	01401		BEQ	10\$	
425	004556	104004		ERROR	4	:ACR ERROR
426	004560	005723		TST	(R3)+	:GET NEXT ISR,IMR,IRR EXPECTED RESULTS
427	004562	020327	012656	CMP	R3,#EDCHP3	:CHECK FOR END
428	004566	001404		BEQ	11\$:DONE WITH GROUP TEST
429	004570	005237	002442	INC	IMRLOC	:INCREMENT MASK BIT TO CLEAR
430	004574	000137	004212	JMP	111\$:TEST NEXT ISR BIT
431	004600	005337	002462	DEC	GRPCNT	:TESTED BOTH GROUPS?
432	004604	001406		BEQ	TST3	:BR IF DONE
433	004606	013700	002422	MOV	DRCSC,R0	:SETUP FOR GROUP 2
434	004612	013701	002426	MOV	DRCSD,R1	:CSRC = CONTROL GROUP 2
435						:CSRD = DATA GROUP 2
436	004616	000137	004154	JMP	120\$:DO GROUP 2

::*****
:*TEST 3 TEST VECTOR ADDR MEM,LEV 0-7,BY0-3,(204-1774),GRPS 1,2
:*****

(2)	004622	000004		TST3:	SCOPE	
441	004624	013700	002412	MOV	DRCSA,R0	
442	004630	013701	002416	MOV	DRCSE,R1	
443	004634	013702	002412	MOV	DRCSE,R2	
444	004640	012737	000002	MOV	#2,GRPCNT	:DO TWO GROUPS
445	004646	012737	000001	MOV	#1,BYNUM	:INIT FOR BYTE COUNT 0
446	004654	004537	011014	JSR	R5,CLRCR	:CLEAR ALL CSRS
447	004660	012737	000340	MOV	#PVMA,VECVL	:START VECTOR LEVEL 0,BYTE COUNT 0
448	004666	012704	012636	MOV	#BGCHP3,R4	:EXPECTED ISR,IMR PATTERN
449	004672	012737	000010	MOV	#8,LVLCNT	:COUNTER FOR 0-7 LEVELS
450	004700	012737	000050	MOV	#CSIMR,IMRLOC	:STORE SINGLE IMR CODE
451	004706	012737	000130	MOV	#SSIRR,IRRLOC	:STORE SINGLE IRR CODE
452	004714	012737	000170	MOV	#CSISR,ISRLOC	:STORE CLEAR SINGLE ISR CODE
453	004722	004537	011524	JSR	R5,TRPCAT	:RESTORE TRAP CATCHER
454	004726	012737	004742	MOV	#112\$, \$LPERR	:STORE SCOPE LOOP


```
455 004734 012737 000204 002452 111$: MOV #204,VECLOC ;START AT VECTOR 204
456 004742 106427 000340 112$: MTPS #340 ;
457 004746 012706 002100 MOV #2100,SP ;INIT STACK IN CASE OF ILLEGAL INT. LOOP
458 004752 042712 001000 BIC #BIT9,(R2) ;CLEAR INTERRUPT ENABLE
459 004756 004537 011074 JSR R5,CLRIRR ;CLEAR IRR REGS
460 004762 112712 000241 MOVB #241,(R2) ;USED IN TEST OF GROUP 2
461 ;ARM GROUP 1 CHIP TO PASS
462 ;ENABLE TO GROUP2
463 004766 013703 002452 MOV VECLOC,R3 ;GET VECTOR
464 004772 010337 002454 MOV R3,VECPAT
465 004776 006037 002454 ROR VECPAT ;ROTATE VECTOR ADDR TWO RIGHT
466 005002 006037 002454 ROR VECPAT ;TO WRITE VECTOR MEM ADDR.
467 005006 012713 011700 MOV #INTBY4,(R3) ;STORE VECTOR ROUTINE
468 005012 012763 000340 000002 MOV #340,2(R3) ;STORE PSW
469 005020 005037 002436 CLR INTFLG ;CLEAR INT. FLAG
470 005024 013737 002472 002470 MOV BYNUM,BYCNT ;BYTE COUNTS OF 0-3
471 005032 113710 002456 MOVB VECVAL,(R0) ;PRESELECT VECTOR MEM ADDR
472 005036 113711 002454 113$: MOVB VECPAT,(R1) ;WRITE VECTOR
473 005042 005337 002470 DEC BYCNT ;DONE WITH BYTE COUNT VALUE
474 005046 001373 BNE 113$ ;NO,LOAD VECTOR FOR NEXT BYTE COUNT
475 005050 010037 002122 MOV R0,$BDADR ;SAVE BUS ADDRESS
476 005054 112710 000060 MOVB #SIMR,(R0) ;SET ALL IMR BITS
477 005060 113710 002442 MOVB IMRLOC,(R0) ;CLEAR MASK ON SINGLE BIT
478 005064 106427 000000 MTPS #PRO
479 005070 112710 000241 MOVB #241,(R0) ;LMD57 - ARM THE CHIP
480 005074 005737 002436 TST INTFLG ;CHECK FOR INTERRUPTS
481 005100 001401 BEQ 1$
482 005102 104011 ERROR 11 ;ERROR,ILLEGAL INTERRUPT
483 005104 005037 002436 1$: CLR INTFLG ;RESET INT. COUNTER
484 005110 113710 002446 MOVB IRRLOC,(R0) ;SET SINGLE IRR BIT
485 005114 106427 000340 MTPS #PR7
486 005120 005737 002436 TST INTFLG ;CHECK FOR NO INTERRUPTS
487 005124 001401 BEQ 2$
488 005126 104011 ERROR 11 ;ILLEGAL INTERRUPTS
489 005130 005037 002436 2$: CLR INTFLG ;CLEAR INT. COUNTER
490 005134 106427 000000 MTPS #PRO
491 005140 152762 000002 000001 BISB #BIT1,1(R2) ;SET I/E,EXPECT INTERRUPT
492 005146 013737 002472 002124 MOV BYNUM,$GDDAT ;EXPECT 1 TO 4 INTERRUPTS
493 ;BASED ON BYTE COUNT VALUE
494 005154 013737 002436 002126 MOV INTFLG,$BDDAT ;SHOULD HAVE 1 TO 4 INTERRUPTS
495 ;BASED ON BYTE COUNT VALUE
496 005162 023737 002124 002126 CMP $GDDAT,$BDDAT
497 005170 001401 BEQ 3$
498 005172 104012 ERROR 12 ;INTERRUPT TEST ERROR
499 005174 106427 000340 3$: MTPS #PR7
500 005200 010137 002122 4$: MOV R1,$BDADR ;READY TO READ ISR REG.
501 005204 005037 002126 CLR $BDDAT ;SET UP FOR BYTE READS
502 005210 005037 002124 CLR $GDDAT ;SET UP FOR BYTE EXPECTED
503 005214 111437 002124 MOVB (R4),$GDDAT ;EXPECTED DATA
504 005220 112710 000240 MOVB #MISR,(R0) ;LOAD MODE TO READ ISP
505 005224 111137 002126 MOVB (R1),$BDDAT
506 005230 023737 002124 002126 CMP $GDDAT,$BDDAT
507 005236 001401 BEQ 5$
508 005240 104006 ERROR 6 ;ISR ERROR
509 005242 116437 000001 002124 5$: MOVB 1(R4),$GDDAT ;STORE EXPECTED
510 005250 112710 000244 MOVB #MIMR,(R0) ;LOAD MODE FOR IMR
```

```
511 005254 111137 002126      MOVB (R1), $BDDAT
512 005260 023737 002124 002126  CMP $GDDAT, $BDDAT
513 005266 001401      BEQ 6$
514 005270 104005      ERROR 5 ;IMR ERROR
515 005272 005037 002124 6$: CLR $GDDAT
516 005276 112710 000250      MOVB #MIRR, (R0) ;LOAD MODE BITS FOR IRR
517 005302 111137 002126      MOVB (R1), $BDDAT
518 005306 023737 002124 002126  CMP $GDDAT, $BDDAT
519 005314 001401      BEQ 7$
520 005316 104003      ERROR 3 ;IRR ERROR
521 005320 005037 002124 7$: CLR $GDDAT
522 005324 112710 000254      MOVB #MACR, (R0)
523 005330 111137 002126      MOVB (R1), $BDDAT
524 005334 023737 002124 002126  CMP $GDDAT, $BDDAT
525 005342 001401      BEQ 10$
526 005344 104004      ERROR 4 ;ACR ERROR
527 005346 005037 002124 10$: CLR $GDDAT
528 005352 113710 002444      MOVB ISRLOC, (R0) ;CLEAR SINGLE ISR BIT
529 005356 112710 000240      MOVB #MISR, (R0) ;LOAD MODE TO READ ISR
530 005362 111137 002126      MOVB (R1), $BDDAT
531 005366 023737 002124 002126  CMP $GDDAT, $BDDAT
532 005374 001401      BEQ 11$
533 005376 104006      ERROR 6 ;ISR REG ERROR
534 005400 004537 011432 11$: JSR R5, RESTRP ;RESTORE VECTOR JUST TESTED
535 005404 005737 017374      TST KXTFLAG ; KXT11 ?? ;:GPA
536 005410 001404      BEQ 100$ ; BR IF NOT ;:GPA
537 005412 022737 000400 002452  CMP #400, VECLOC ; YES, FINISHED 204-374 ?? ;:GPA
538 005420 000403      403 ; SKIP NEXT TO FIND OUT ;:GPA
539 005422      100$:
540 005422 022737 002000 002452  CMP #200, VECLOC ;FINISHED?
541 005430 001402      BEQ 12$ ;FINISHED VECTORS 204-1774?
542 005432 000137 004742      JMP 112$ ;TEST NEXT VECTOR ADDR
543 005436 005724      12$: TST (R4)+ ;INDEX EXPECTED ISR AND IMR PATTERN
544 005440 005237 002442      INC IMRLOC ;STORE CLEAR FOR NEXT MASK BIT
545 005444 005237 002446      INC IRRLOC ;STORE SET FOR NEXT IRR BIT
546 005450 005237 002444      INC ISRLOC ;STORE CLEAR FOR NEXT ISR BIT
547 005454 005237 002456      INC VECVAL ;SETUP TO TEST NEXT VECTOR LEVEL
548 005460 005337 002466      DEC LVL CNT ;FINISHED LEVELS 0-7
549 005464 001402      BEQ 13$ ;YES, CHECK BYTE COUNT END
550 005466 000137 004734      JMP 111$ ;NO, DO NEXT LEVEL
551 005472 005237 002472      13$: INC BYNUM ;INDEX BYTE COUNT
552 005476 104407      CKSWR ;LOOK FOR SWITCH CHANGE REQUEST
553 005500 022737 000400 002456  CMP #400, VECVAL ;FINISHED ALL BYTE COUNTS 0-3
554 005506 001402      BEQ 14$ ;FINISHED TWO GROUPS?
555 005510 000137 004666      JMP 121$ ;DO NEXT BYTE COUNT FOR
556      ;LEVELS 0-7
557 005514 005337 002462      14$: DEC GRPCNT ;FINISHED TWO GROUPS?
558 005520 001406      BEQ TST4 ;:BR IF DONE
559 005522 013700 002422      MOV DRCSC, R0 ;CSRC = CONTROL GROUP 2
560 005526 013701 002426      MOV DRCSD, R1 ;CSRD = DATA GROUP 2
561 005532 000137 004646      JMP 120$ ;DO GROUP 2 FOR BYTE COUNTS 0-3
562      ;AND LEVELS 0-7 FOR EACH BYTE COUNT.
563
564
565
(3) ;*****
; *TEST 4 TEST VECTOR ADDR MEM, LVLS 0-7, BY0-3, (0-200)GRPS 1,2
```

```
(3)
(2) 005536 000004
566 005540 013700 002412
567 005544 013701 002416
568 005550 013702 002412
569 005554 012737 000002 002462
570 005562 012737 000001 002472 120$:
571 005570 004537 011014
572 005574 012737 000340 002456
573 005602 012704 012636 121$:
574 005606 012737 000010 002466
575 005614 012737 000050 002442
576 005622 012737 000130 002446
577 005630 012737 005642 002110
578 005636 005037 002452 111$:
579 005642 106427 000340 112$:
580 005646 012706 002100
581 005652 042712 001000
582 005656 004537 011074
583 005662 112712 000241
584
585
586 005666 013703 002452
587 005672 004537 012024
588 005676 010337 002454
589 005702 006037 002454
590 005706 006037 002454
591 005712 012713 012124
592 005716 012763 000340 000002
593 005724 005037 002436
594 005730 013737 002472 002470
595
596 005736 113710 002456
597 005742 113711 002454 113$:
598 005746 005337 002470
599 005752 001373
600 005754 010037 002122
601 005760 112710 000060
602 005764 113710 002442
603 005770 106427 000000
604 005774 112710 000241
605 006000 005737 002436
606 006004 001405
607 006006 004537 011374
608 006012 104011
609 006014 004537 012024
610 006020 005037 002436 1$:
611 006024 113710 002446
612 006030 106427 000340
613 006034 005737 002436
614 006040 001405
615 006042 004537 011374
616 006046 104011
617 006050 004537 012024
618 006054 005037 002436 2$:
619 006060 106427 000000
```

TST4: SCOPE
MOV DRCSA,R0
MOV DRCSB,R1
MOV DRCSA,R2
MOV #2,GRPCNT ;DO TWO GROUPS
MOV #1,BYNUM ;INIT FOR FIRST BYTE COUNT
JSR R5,CLRCR ;CLEAR ALL CSRS
MOV #PMA,VECVL ;START VECTOR LEVEL 0,BYTE COUNT 0
MOV #BGCHP3,R4 ;ISR,IMR PATTERN
MOV #8.,LVL CNT ;START LEVEL COUNT 0-7
MOV #CSIMR,IMRLOC ;STORE CLEAR SINGLE IMR BIT CODE
MOV #SSIRR,IRRLOC ;STORE SET SINGLE IRR BIT CODE
MOV #112\$, \$LPERR ;LOOP RETURN
CLR VECLOC ;START AT VECTOR 0
MTPS #340
MOV #2100,SP ;INIT STACK IN CASE OF ILLEGAL INT. LOOP
BIC #BIT9,(R2) ;CLEAR INTERRUPT ENABLE
JSR R5,CLRIRR ;CLEAR IRR REGS
MOVB #241,(R2) ;USED IN TEST OF GROUP 2
;ARM GROUP 1 CHIP TO PASS
;ENABLE TO GROUP 2.
MOV VECLOC,R3 ;GET VECTOR
JSR R5,CAT200 ;STORE TRAP CATCHER FOR 0-200
MOV R3,VECPAT
ROR VECPAT ;ROTATE VECTOR ADDR TWO RIGHT
ROR VECPAT ;TO WRITE VECTOR MEM ADDR.
MOV #INTSR3,(R3) ;STORE VECTOR ROUTINE
MOV #340,2(R3) ;STORE PSW
CLR INTFLG ;CLEAR INT. FLAG
MOV BYNUM,BYCNT ;BYTE COUNT OF 0 TO 3
;FOR 1 TO 4 VECTORS.
MOVB VECVAL,(R0) ;PRESELECT VECTOR MEM ADDR
MOVB VECPAT,(R1) ;WRITE VECTOR
DEC BYCNT ;DO 1 TO 4 VECTORS
BNF 113\$;WRITE VECTORS BASED ON BYTE COUNT
MOV R0,\$BDADR ;SAVE BUS ADDRESS
MOVB #SIMR,(R0) ;SET ALL IMR BITS
MOVB IMRLOC,(R0) ;CLEAR MASK ON SINGLE BIT
MTPS #PRO
MOVB #241,(R0) ;LMD57 - ARM THE CHIP
TST INTFLG ;CHECK FOR INTERRUPTS
BEQ 1\$
JSR R5,FRMBUF ;RESTORE 0-202
ERROR 11 ;ERROR,ILLEGAL INTERRUPT
JSR R5,CAT200 ;RESTORE TRAP CATCHER
CLR INTFLG ;RESET INT. COUNTER
MOVB IRRLOC,(R0) ;SET SINGLE IRR BIT
MTPS #PR7
TST INTFLG ;CHECK FOR NO INTERRUPTS
BEQ 2\$
JSR R5,FRMBUF ;RESTORE 0-202
ERROR 11 ;ILLEGAL INTERRUPTS
JSR R5,CAT200 ;RESTORE TRAP CATCHER
CLR INTFLG ;CLEAR INT. COUNTER
MTPS #PRO

620	006064	152762	000002	000001		BISB	#BIT1,1(R2)	:SET I/E,EXPECT INTERRUPT
621	006072	013737	002472	002124		MOV	BYNUM,\$GDDAT	:EXPECT NUMBER OF INTERRUPTS
622								:EQUAL TO BYTE COUNT.
623	006100	013737	002436	002126		MOV	INTFLG,\$BDDAT	:SHOULD HAVE NUMBER OF INTERRUPTS
624								:EQUAL TO BYTE COUNT.
625	006106	023737	002124	002126		CMP	\$GDDAT,\$BDDAT	
626	006114	001405				BEQ	3\$	
627	006116	004537	011374			JSR	R5,FRMBUF	:RESTORE 0-202
628	006122	104012				ERROR	12	:INTERRUPT TEST ERROR
629	006124	004537	012024			JSR	R5,CAT200	:RESTORE TRAP CATCHER SUB
630	006130	106427	000340		3\$:	MTPS	#PR7	
631	006134	010137	002122		4\$:	MOV	R1,\$BDADR	:READY TO READ ISR REG.
632	006140	005037	002126			CLR	\$BDDAT	:SET UP FOR BYTE READS
633	006144	005037	002124			CLR	\$GDDAT	:SET UP FOR BYTE EXPECTED
634	006150	111437	002124			MOVB	(R4),\$GDDAT	:EXPECTED DATA
635	006154	112710	000240			MOVB	#MISR,(R0)	:LOAD MODE TO READ ISR
636	006160	111137	002126			MOVB	(R1),\$BDDAT	
637	006164	023737	002124	002126		CMP	\$GDDAT,\$BDDAT	
638	006172	001405				BEQ	5\$	
639	006174	004537	011374			JSR	R5,FRMBUF	:RESTORE 0-200
640	006200	104006				ERROR	6	:ISR ERROR
641	006202	004537	012024			JSR	R5,CAT200	:RESTORE TRAP CATCHER
642	006206	116437	000001	002124	5\$:	MOVB	1(R4),\$GDDAT	:STORE EXPECTED
643	006214	112710	000244			MOVB	#MIMR,(R0)	:LOAD MODE FOR IMR
644	006220	111137	002126			MOVB	(R1),\$BDDAT	
645	006224	023737	002124	002126		CMP	\$GDDAT,\$BDDAT	
646	006232	001405				BEQ	6\$	
647	006234	004537	011374			JSR	R5,FRMBUF	:RESTORE 0-202
648	006240	104005				ERROR	5	:IMR ERROR
649	006242	004537	012024			JSR	R5,CAT200	:RESTORE CATCHER
650	006246	005037	002124		6\$:	CLR	\$GDDAT	
651	006252	112710	000250			MOVB	#MIRR,(R0)	:LOAD MODE BITS FOR IRR
652	006256	111137	002126			MOVB	(R1),\$BDDAT	
653	006262	023737	002124	002126		CMP	\$GDDAT,\$BDDAT	
654	006270	001405				BEQ	7\$	
655	006272	004537	011374			JSR	R5,FRMBUF	:RESTORE 0-202
656	006276	104003				ERROR	3	:IRR ERROR
657	006300	004537	012024			JSR	R5,CAT200	:RESTORE TRAP CATCHER
658	006304	005037	002124		7\$:	CLR	\$GDDAT	
659	006310	112710	000254			MOVB	#MACR,(R0)	
660	006314	111137	002126			MOVB	(R1),\$BDDAT	
661	006320	023737	002124	002126		CMP	\$GDDAT,\$BDDAT	
662	006326	001405				BEQ	10\$	
663	006330	004537	011374			JSR	R5,FRMBUF	:RESTORE 0-202
664	006334	104004				ERROR	4	:ACR ERROR
665	006336	004537	012024			JSR	R5,CAT200	:RESTORE TRAP CATCHER
666	006342	005037	002124		10\$:	CLR	\$GDDAT	
667	006346	112710	000160			MOVB	#CISR,(R0)	:CLEAR ISR
668	006352	112710	000240			MOVB	#MISR,(R0)	:LOAD MODE TO READ ISR
669	006356	111137	002126			MOVB	(R1),\$BDDAT	
670	006362	023737	002124	002126		CMP	\$GDDAT,\$BDDAT	
671	006370	001405				BEQ	11\$	
672	006372	004537	011374			JSR	R5,FRMBUF	:RESTORE 0-202
673	006376	104006				ERROR	6	:ISR REG ERROR
674	006400	004537	012024			JSR	R5,CAT200	:RESTORE TRAP CATCHER
675	006404	004537	011762		11\$:	JSR	R5,RES200	:RESTORE VECTOR JUST TESTED

```
676 006410 004537 011374 JSR R5,FRMBUF ;RESTORE 0-200 TO SYSMAC CONTROL
677 006414 022737 000204 002452 CMP #204,VECLC ;FINISHED?
678 006422 001402 BEQ 12$
679 006424 000137 005642 JMP 112$ ;TEST NEXT VECTOR ADDR
680 006430 005724 12$: TST (R4)+ ;INDEX EXPECTED ISR AND IMR PATTERN
681 006432 005237 002442 INC IMRLOC ;STORE CLEAR NEXT IMR BIT
682 006436 005237 002446 INC IRRLOC ;STORE SET NEXT IRR BIT
683 006442 005237 002456 INC VECVAL ;SETUP TO TEST NEXT VECTOR LEVEL
684 006446 005337 002466 DEC LVL CNT ;FINISHED LEVELS 0-7?
685 006452 001402 BEQ 13$ ;YES,CHECK BYTE COUNT END
686 006454 000137 005636 JMP 111$ ;NO,DO NEXT LEVEL,SAME BYTE COUNT
687 006460 005237 002472 13$: INC BYNUM ;INDEX BYTE COUNT
688 006464 104407 CKSWR ;LOOK FOR SWITCH CHANGE
689 006466 022737 000400 002456 CMP #400,VECVAL ;FINISHED ALL FOUR BYTE COUNTS
690 006474 001402 BEQ 14$ ;YES,FINISHED GROUP
691 006476 000137 005602 JMP 121$ ;NO,DO NEXT BYTE COUNT WITH
692 ;LEVELS 0-7.
693 006502 005337 002462 14$: DEC GRPCNT ;FINISHED BOTH GROUP 1 AND GROUP 2?
694 006506 001406 BEQ 15$ ;YES,BOTH GROUPS TESTED
695 006510 013700 002422 MOV DRCSC,R0 ;NO,TEST GROUP 2
696 ;CSRC = CONTROL GROUP 2
697 006514 013701 002426 MOV DRCSD,R1 ;CSRD = DATA GROUP 2
698 006520 000137 005562 JMP 120$ ;RETURN AND TEST GROUP2
699 ;FOR BYTE COUNTS 0-3 AND
700 ;LEVELS 0-7 FOR EACH BYTE COUNT.
701 006524 004537 011374 15$: JSR R5,FRMBUF ;RESTORE 0-202,EXIT TEST
702
703
704
(3) ;*****
(3) ;*TEST 5 TEST VECTOR ADDR UNIQUENESS IN FIXED MODE FOR GRPS 1,2
(2) 006530 000004 ;*****
705 TST5: SCOPE ;BYTE COUNT = 4
706 ;LEVELS = 0-7
707 006532 004537 011014 JSR R5,CLRCSR ;CLEAR ALL CSRS
708 006536 004537 011334 JSR R5,CLRBF ;CLEAR VECTOR BUFFER AREA
709 006542 004537 011524 JSR R5,TRPCAT ;RESTORE TRAP CATCHER
710 006546 004537 011300 JSR R5,STRVEC ;STORE VECTOR AREA 300-674
711 ;WITH INT. SERV ROUTINES
712 006552 012737 000377 002456 MOV #377,VECVAL ;VECTOR MEM FINAL VALUE
713 006560 004537 011074 JSR R5,CLRIRR ;CLEAR IRR REGS
714 006564 012704 017160 MOV #VBUF,R4 ;VECTOR ADDRESS BUFFER
715 006570 004537 011132 JSR R5,VECFIL ;FILL VECTOR MEMORY FOR GROUPS 1,2
716 ;WITH VECTORS 300-674
717 006574 012705 012210 MOV #SETVEC,R5 ; R5 POINTS TO COMMON HANDLER ;:GPA
718 006600 013700 002412 MOV DRCSA,R0 ;GROUP 1 CSR
719 006604 013701 002422 MOV DRCSC,R1 ;GROUP 2 CSR
720 006610 013702 002416 MOV DRCSE,R2
721 006614 013703 002426 MOV DRCSD,R3
722 006620 010037 002122 MOV R0,$BDADR ;STORE BUS ADDRESS
723 006624 112710 000300 MOVB #PACR,(R0) ;PRESELECT GP1 ACR FOR WRITING
724 006630 112712 000377 MOVB #377,(R2) ;SET ALL ACR BITS GP1
725 006634 112710 000040 MOVB #CIMR,(R0) ;CLEAR ALL IMR BITS GP1
726 006640 005037 002436 CLR INTFLG ;CLEAR INT. FLAG
727 006644 106427 000000 MTPS #PRO
728 006650 112710 000120 MOVB #SIRR,(R0) ;SET ALL IRR BITS
```



```

785 007210 104003          ERROR 3          :IRR ERROR
786 007212 012737 000377 002124 10$:  MOV    #377,$GDDAT  :EXPECTED ACR
787 007220 112710 000254          MOVB  #MACR,(R0)   :READ ACR
788 007224 111237 002126          MOVB  (R2),$BDDAT
789 007230 023737 002124 002126  CMP    $GDDAT,$BDDAT
790 007236 001401          BEQ    11$
791 007240 104004          ERROR 4          :ACR ERROR
792 007242 005037 002124          CLR    $GDDAT
793 007246 005037 002126          CLR    $BDDAT
794 007252 010337 002122          MOV    R3,$BDADR   :CSRD ADDRESS
795 007256 112711 000240          MOVB  #MISR,(R1)   :READ ISR ,GP2
796 007262 111337 002126          MOVB  (R3),$BDDAT
797 007266 023737 002124 002126  CMP    $GDDAT,$BDDAT
798 007274 001401          BEQ    12$
799 007276 104006          ERROR 6          :ISR ERROR,GP1
800 007300 112711 00024, 002126 12$:  MOVB  #MIMR,(R1)   :READ IMR GP2
801 007304 111337 002126          MOVB  (R3),$BDDAT
802 007310 023737 002124 002126  CMP    $GDDAT,$BDDAT
803 007316 001401          BEQ    13$
804 007320 104005          ERROR 5          :IMR ERROR,GP2
805
806 007322 112711 000250          MOVB  #MIRR,(R1)   :READ IRR
807 007326 111337 002126          MOVB  (R3),$BDDAT
808 007332 023737 002124 002126  CMP    $GDDAT,$BDDAT
809 007340 001401          BEQ    14$
810 007342 104003          ERROR 3          :IRR ERROR,GP2
811 007344 112711 000254          MOVB  #MACR,(R1)   :READ ACR
812 007350 012737 000377 002124  MOV    #377,$GDDAT
813 007356 111337 002126          MOVB  (R3),$BDDAT
814 007362 023737 002124 002126  CMP    $GDDAT,$BDDAT
815 007370 001401          BEQ    15$
816 007372 104004          ERROR 4          :ACR ERROR,GP2
817 007374 012702 000100          MOV    #64,R2
818 007400 012704 017160          MOV    #VBUF,R4   :VECTOR BUFFER
819 007404 012737 000300 002124  MOV    #300,$GDDAT :START WITH FIRST VECTOR 300
820 007412 010437 002122          MOV    R4,$BDADR  :VECTOR BUFFER ADDRESS
821 007416 011437 002126          MOVB  (R4),$BDDAT
822 007422 023737 002124 002126  CMP    $GDDAT,$BDDAT
823 007430 001401          BEQ    17$
824 007432 104007          ERROR 7          :VECTORED PROPERLY
825 007434 062737 000004 002124 17$:  ADD    #4,$GDDAT   :VECTOR ADDR MEM ERROR
826 007442 005737 017374          TST    KXTFLAG    : KXT11 ??
827 007446 001407          BEQ    1000$      : BR IF NOT
828 007450 023727 002124 000400  CMP    $GDDAT,#400 : YES, REACHED VECTOR 400 ??
829 007456 103403          BLO    1000$      : NOT YET, CONTINUE
830 007460 012737 000300 002124 1000$: MOV    #300,$GDDAT : YES, RESET EXPECTED TO 300
831 007466
832 007466 062704 000002          ADD    #2,R4      :NEXT BUFFER ADDRESS
833 007472 005302          DEC    R2         :COMPLETED 64 BUFFER CHECKS?
834 007474 001346          BNE    16$       :CHECK NEXT VECTOR BUFFER LOCATION
835
836
837
838
(3)
(3)

```

```

*****
*TEST 6 TEST VECTOR ADDR UNIQUENESS IN ROTATING MODE FOR GRPS 1,2
*****

```

```
(2) 007476 000004 TST6: SCOPE
839 8
841 007500 004537 011014 JSR R5,CLRCR ;BYTE COUNT = 4
842 007504 004537 011334 JSR R5,CLRBF ;LEVELS = 0-7
843 007510 004537 011524 JSR R5,TRPCAT ;CLEAR ALL CSRS
844 007514 004537 011300 JSR R5,STRVEC ;CLEAR VECTOR BUFFER AREA
;RESTORE TRAP CATCHER
;STORE VECTOR AREA 300-674
;WITH INT. SERV ROUTINES
846 007520 012737 000377 002456 MOV #377,VECVL ;VECTOR MEM FINAL VALUE
847 007526 004537 011074 JSR R5,CLRIRR ;CLEAR IRR REGS
848 007532 012704 017160 MOV #VBUF,R4 ;VECTOR ADDRESS BUFFER
849 007536 004537 011132 JSR R5,VECFIL ;FILL VECTOR MEMORY FOR GROUPS 1,2
;WITH VECTORS 300-674
851 007542 012705 012210 MOV #SETVEC,R5 ; R5 POINTS TO COMMON HANDLER. ;;GPA
852 007546 013700 002412 MOV DRCSA,R0 ;GROUP 1 CSR
853 007552 013701 002422 MOV DRCSA,R1 ;GROUP 2 CSR
854 007556 013702 002416 MOV DRCSB,R2
855 007562 013703 002426 MOV DRCSB,R3
856 007566 010037 002122 MOV R0,$BDADR ;STORE BUS ADDRESS
857 007572 012737 000010 002474 MOV #8,LVLSAV ;COUNTER FOR 7 LEVELS
858 007600 112710 000201 MOVB #201,(R0) ;ROTATING PRIORITY GROUP 1
859 007604 112710 000040 MOVB #CIMR,(R0) ;CLEAR ALL IMR BITS GP1
860 007610 005037 002436 CLR INTFLG ;CLEAR INT. FLAG
861 007614 106427 000000 MTPS #PRO
862 007620 112710 000120 MOVB #SIRR,(R0) ;SET ALL IRR BITS
863 007624 112710 000241 MOVB #241,(R0) ;LMD57 - ARM THE CHIP
864 007630 106427 000340 MTPS #340
865 007634 005737 002436 TST INTFLG ;CHECK FOR NO INTERRUPTS
866 007640 001401 BEQ 1$
867 007642 104011 ERROR 11 ;ILLEGAL INTERRUPT
868 007644 005037 002436 1$: CLR INTFLG
869 007650 112711 000201 MOVB #201,(R1) ;ROTATING PRIORITY FOR GROUP 2
870 007654 112711 000040 MOVB #CIMR,(R1) ;CLEAR ALL IMR BITS GP2
871 007660 106427 000000 MTPS #PRO
872 007664 112711 000120 MOVB #SIRR,(R1) ;SET ALL IRR BITS
873 007670 112711 000241 MOVB #241,(R1) ;LMD57 - ARM THE CHIP
874 007674 106427 000340 MTPS #PR7
875 007700 005737 002436 TST INTFLG ;CHECK FOR NO INTERRUPTS
876 007704 001401 BEQ 2$
877 007706 104011 ERROR 11 ;ILLEGAL INTERRUPT
878 007710 005037 002436 2$: CLR INTFLG
879 007714 106427 000000 MTPS #PRO
880 007720 152760 000002 000001 BISB #BIT1.1,(R0) ;SET INT. ENABLE, EXPECT INTERRUPTS
881 007726 012737 000004 002124 MOV #4,$JDAT ;EXPECT 4 INTERRUPTS
882 007734 013737 002436 002126 MOV INTFLG,$BDDAT ;SHOULD HAVE 4 INTERRUPTS
883 007742 106427 000340 MTPS #PR7
884 007746 023737 002124 002126 CMP $GDDAT,$BDDAT
885 007754 001401 BEQ 100$
886 007756 104012 ERROR 12 ;INTERRUPT TEST ERROR
887 007760 112710 000140 100$: MOVB #CHPISR,(R0) ;CLEAR HIGHEST PRIORITY ISR
888 007764 112710 000120 MOVB #SIRR,(R0) ;SET ALL IRR BITS
889 007770 005337 002474 DEC LVLSAV ;DONE 8 LEVELS, GROUP 1
890 007774 001345 BNE 2$ ;DO NEXT LEVEL IN ROTATION
891 007776 112710 000100 MOVB #CIRR,(R0) ;CLEAR IRR BITS GROUP 1
892 010002 012737 000010 002474 MOV #8,LVLSAV ;DO 8 LEVELS, GROUP 2
893 010010 005037 002436 101$: CLR INTFLG ;CLEAR INT FLAG
```

Line	Address	Hex	Hex	Hex	Op	Op	Op	Op	Op	Op
894	010014	106427	000000		MTPS	#PRO				
895	010020	012737	000004	002124	MOV	#4,\$GDDAT				
896	010026	013737	002436	002126	MOV	INTFLG,\$BDDAT				:SHOULD HAVE FOUR INTERRUPTS
897	010034	106427	000340		MTPS	#PR7				
898	010040	023737	002124	002126	CMP	\$GDDAT,\$BDDAT				
899	010046	001401			BEQ	102\$				
900	010050	104012			ERROR	12				:INTERRUPT TEST ERROR
901	010052	112711	000140	102\$:	MOVB	#CHIPISR,(R1)				:CLEAR HIGHEST PRIORITY ISR
902	010056	112711	000120		MOVB	#SIRR,(R1)				:SET ALL IRR BITS
903	010062	005337	002474		DEC	LVL SAV				:DONE 8 LEVELS?
904	010066	001350			BNE	101\$:DO NEXT LEVEL IN ROTATION,GP2
905	010070	112711	000100		MOVB	#CIRR,(R1)				:CLEAR IRR BITS, GROUP 2
906	010074	012737	101750	002124	3\$:	MOV	#101750,\$GDDAT			:RDY,DIR,I/E,CHIP - 35X
907	010102	010037	002122		MOV	R0,\$BDADR				:CSRA
908	010106	011037	002126		MOV	(R0),\$BDDAT				
909	010112	042737	000007	002126	BIC	#7,\$BDDAT				:CLEAR UNDEFINED BITS
910	010120	023737	002124	002126	CMP	\$GDDAT,\$BDDAT				
911	010126	001401			BEQ	4\$				
912	010130	104002			ERROR	2				:CSRA REG ERROR
913	010132	012737	000350	002124	4\$:	MOV	#350,\$GDDAT			:STORE EXPECTED
914	010140	010137	002122		MOV	R1,\$BDADR				:CSRC
915	010144	011137	002126		MOV	(R1),\$BDDAT				
916	010150	042737	000007	002126	BIC	#7,\$BDDAT				:CLEAR UNDEFINED BITS
917	010156	023737	002124	002126	CMP	\$GDDAT,\$BDDAT				
918	010164	001401			BEQ	5\$				
919	010166	104002			ERROR	2				:CSRC ERROR
920	010170	010237	002122	5\$:	MOV	R2,\$BDADR				:CSRB ADDRESS
921	010174	005237	002126		CLR	\$BDDAT				
922	010200	005037	002124		CLR	\$GDDAT				
923	010204	112710	000240		MOVB	#MISR,(R0)				:READ ISR
924	010210	111237	002126		MOVB	(R2),\$BDDAT				
925	010214	023737	002124	002126	CMP	\$GDDAT,\$BDDAT				
926	010222	001401			BEQ	6\$				
927	010224	104006			ERROR	6				:ISR ERROR,GP1
928	010226	112710	000244	6\$:	MOVB	#MIMR,(R0)				:MODE BITS FOR IMR
929	010232	111237	002126		MOVB	(R2),\$BDDAT				
930	010236	023737	002124	002126	CMP	\$GDDAT,\$BDDAT				
931	010244	001401			BEQ	7\$				
932	010246	104005			ERROR	5				:IMR ERROR,GP1
933	010250	112710	000250	7\$:	MOVB	#MIRR,(R0)				:MODE BITS FOR IRR
934	010254	111237	002126		MOVB	(R2),\$BDDAT				
935	010260	023737	002124	002126	CMP	\$GDDAT,\$BDDAT				
936	010266	001401			BEQ	10\$				
937	010270	104003			ERROR	3				:IRR ERROR
938	010272	112710	000254	10\$:	MOVB	#MACR,(R0)				:READ ACR
939	010276	111237	002126		MOVB	(R2),\$BDDAT				
940	010302	023737	002124	002126	CMP	\$GDDAT,\$BDDAT				
941	010310	001401			BEQ	11\$				
942	010312	104004			ERROR	4				:ACR ERROR
943	010314	010337	002122	11\$:	MOV	R3,\$BDADR				:CSRD ADDRESS
944	010320	112711	000240		MOVB	#MISR,(R1)				:READ ISR,GP2
945	010324	111337	002126		MOVB	(R3),\$BDDAT				
946	010330	023737	002124	002126	CMP	\$GDDAT,\$BDDAT				
947	010336	001401			BEQ	12\$				
948	010340	104006			ERROR	6				:ISR ERROR,GP1
949	010342	112711	000244	12\$:	MOVB	#MIMR,(R1)				:READ IMR GP2

```
950 010346 111337 002126      MOVB      (R3), $BDDAT
951 010352 023737 002124 002126      CMP       $GDDAT, $BDDAT
952 010360 001401                BEQ       13$
953 010362 104005                ERROR     5           ;IMR ERROR, GP2
954
955 010364 112711 000250      13$:     MOVB      #MIRR, (R1)       ;READ IRR
956 010370 111337 002126      MOVB      (R3), $BDDAT
957 010374 023737 002124 002126      CMP       $GDDAT, $BDDAT
958 010402 001401                BEQ       14$
959 010404 104003                ERROR     3           ;IRR ERROR, GP2
960 010406 112711 000254      14$:     MOVB      #MACR, (R1)       ;READ ACR
961 010412 111337 002126      MOVB      (R3), $BDDAT
962 010416 023737 002124 002126      CMP       $GDDAT, $BDDAT
963 010424 001401                BEQ       200$
964 010426 104004                ERROR     4           ;ACR ERROR, GP2
965 010430 105010      200$:    CLRB      (R0)         ;INIT GROUP 1 MODE BITS
966 010432 105011                CLRB      (R1)         ;INIT GROUP 2 MODE BITS
967 010434 012737 101700 002124      MOV       #101700, $GDDAT ;EXPECTED CSRA
968 010442 010037 002122      MOV       R0, $BDADR    ;CSRA
969 010446 011037 002126      MOV       (R0), $BDDAT
970 010452 042737 000007 002126      BIC       #7, $BDDAT    ;CLEAR UNDEFINED BITS
971 010460 023737 002124 002126      CMP       $GDDAT, $BDDAT
972 010466 001401                BEQ       201$
973 010470 104002                ERROR     2           ;CSRA REG ERROR
974 010472 012737 000200 002124 201$:    MOV       #200, $GDDAT  ;STORE EXPECTED
975 010500 010137 002122      MOV       R1, $BDADR    ;CSRC
976 010504 011137 002126      MOV       (R1), $BDDAT
977 010510 042737 000007 002126      BIC       #7, $BDDAT    ;CLEAR UNDEFINED BITS
978 010516 023737 002124 002126      CMP       $GDDAT, $BDDAT
979 010524 001401                BEQ       15$
980 010526 104002                ERROR     2           ;CSRC ERROR
981 010530 012702 000100      15$:     MOV       #64, R2
982 010534 012704 017160      MOV       #VBUF, R4     ;VECTOR BUFFER
983 010540 012737 000300 002124      MOV       #300, $GDDAT  ;START WITH FIRST VECTOR 300
984 010546 010437 002122      16$:     MOV       R4, $BDADR    ;VECTOR BUFFER ADDRESS
985 010552 011437 002126      MOV       (R4), $BDDAT
986 010556 023737 002124 002126      CMP       $GDDAT, $BDDAT
987 010564 001401                BEQ       17$
988 010566 104007                ERROR     7           ;VECTORED PROPERLY
989 010570 062737 000004 002124 17$:     ADD       #4, $GDDAT    ;VECTOR ADDR MEM ERROR
990 010575 005737 017374      TST      KXTFLAG       ; KXT11 ??
991 010602 001407                BEQ       1000$        ; BR IF NOT
992 010604 023727 002124 000400      CMP       $GDDAT, #400 ; YES, REACHED VECTOR 400 ??
993 010612 103403                BLO       1000$        ; NOT YET, CONTINUE
994 010614 012737 000300 002124      MOV       #300, $GDDAT ; YES, RESET EXPECTED TO 300
995 010622                1000$:
996 010622 062704 000002      ADD       #2, R4        ;NEXT BUFFER ADDRESS
997 010626 005302                DEC       R2            ;COMPLETED 64 BUFFER CHECKS?
998 010630 001346                BNE      16$           ;CHECK NEXT VECTOR BUFFER LOCATION
999
1000
1001
1002
1003
1004 010632 013701 002412      ;DON'T REPORT 'END OF PASS' UNTIL ALL SELECTED DRV11J'S HAVE BEEN TESTED.
1005 010636 000241      NXDEV:  MOV      DRCSA, R1 ;INIT TO SETUP DRV11J ADDRESS
1005 010636 000241      NXDEV1: CLC           ;CLEAR CARRY FOR DEVICE MAP
```


1006	010640	006037	002434	ROR	DMAP	:LOOK FOR NEXT DRV11J
1007	010644	001412		BEQ	\$EOP	:BR IF ALL TESTED
1008	010646	162701	000020	SUB	#20,R1	:NEXT DRV11J STARTS -20 FROM PAST CSR
1009	010652	005237	002202	INC	\$UNIT	:UPDAT UNIT #
1010	010656	032737	000001	BIT	#1,DMAP	:IS UNIT SELECTED?
1011	010664	001764		BEQ	NXDEV1	:BR IF NOT
1012	010666	000137	003200	JMP	NEXPAS	:TEST NEXT DRV11J

1013
1014 .SBTTL END OF PASS ROUTINE
(1)
(2)
(1)
(1)
(1)
(1)
(1)
(1)

:INCREMENT THE PASS NUMBER (\$PASS)
:TYPE 'END PASS #XXXXX' (WHERE XXXXX IS A DECIMAL NUMBER)
:IF THERES A MONITOR GO TO IT
:IF THERE ISN'T JUMP TO START1

(1)	010672			\$EOP:	NOP			
(2)	010672	000240			CLR	\$STNM	::ZERO THE TEST NUMBER	
(1)	010674	005037	002102		CLR	\$TIMES	::ZERO THE NUMBER OF ITERATIONS	
(1)	010700	005037	002160		INC	\$PASS	::INCREMENT THE PASS NUMBER	
(1)	010704	005237	002176		BIC	#100000,\$PASS	::DON'T ALLOW A NEG. NUMBER	
(1)	010710	042737	000000	002176	DEC	(PC)+	::LOOP?	
(1)	010716	005327		\$FOPCT:	.WORD	1		
(1)	010720	000001			BGT	\$DOAGN	::YES	
(1)	010722	003022			MOV	(PC)+,@(PC)+	::RESTORE COUNTER	
(1)	010724	012737		\$ENDCT:	.WORD	1		
(1)	010726	000001			\$EOPCT			
(1)	010730	010720			TYPE	SENDMG	::TYPE 'END PASS #'	
(1)	010732	104401	010777		MOV	\$PASS,-(SP)	::SAVE \$PASS FOR TYPEOUT	
(2)	010736	013746	002176		TYPDS		::GO TYPE--DECIMAL ASCII WITH SIGN	
(2)	010742	104405			TYPE	\$ENULL	::TYPE A NULL CHARACTER	
(1)	010744	104401	010774		\$GET42:	MOV	@#42,R0	::GET MONITOR ADDRESS
(1)	010750	013700	000042		BEQ	\$DOAGN	::BRANCH IF NO MONITOR	
(1)	010754	001405			RESET		::CLEAR THE WORLD	
(1)	010756	000005		\$ENDAD:	JSR	PC,(R0)	::GO TO MONITOR	
(1)	010760	004710			NOP		::SAVE ROOM	
(1)	010762	000240			NOP		::FOR	
(1)	010764	000240			NOP		::ACT11	
(1)	010766	000240		\$DOAGN:				
(1)	010770				JMP	@(PC)+	::RETURN	
(1)	010770	000137						
(1)	010772	003134		\$RTNAD:	.WORD	START1		
(1)	010774	377	377	000	\$ENULL:	.BYTE	-1,-1,0	::NULL CHARACTER STRING
(1)	010777	015	042412	042116	SENDMG:	.ASCIZ	<15><12>/END PASS #/	

.SBTTL PROGRAM SUBROUTINES

1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071

011014 010046
011016 106427 000340
011022 012737 000340 002456
011030 012737 000300 002452
011036 013700 002412
011042 005037 002124
011046 005037 002126
011052 005010
011054 105060 000005
011060 005060 000010
011064 105060 000015
011070 2600
011072 00205

011074 010046
011076 013700 002412
011102 105060 000011
011106 112760 000001 000001
011114 005060 000002
011120 105010
011122 105060 000010
011126 012600
011130 000205

011132 013700 002412
011136 013701 002416
011142 012702 000002
011146 012737 000060 002454
011154 012737 000370 002456
011162 012737 000010 002466
011170 113710 002456
011174 012737 000004 002470
011202 113711 002454
011206 005237 002454
011212 005737 017374
011216 001407
011220 023727 002454 000100
011226 103403
011230 012737 000060 002454

011236
011236 005337 002470
011242 001357
011244 005337 002466

```
*****  
:CLEAR ALL CONTROL/STATUS REGISTERS  
*****  
CLRCSR: MOV R0, -(SP) ;SAVE R0  
MTPS #PR7 ;PSW = 340  
MOV #PVMA, VECVAL ;INIT VECTOR ADDR MEM = 340  
MOV #300, VECLOC ;INIT VECTOR ADDR TO 300  
MOV DRCSA, R0 ;START OF CSR ADDRESS  
CLR $GDDAT ;CLEAR EXPECTED  
CLR $BDDAT ;CLEAR REC'D  
CLR (R0) ;CLEAR CSRA; CHIP RESET GROUP 1  
CLRB 5(R0) ;CLEAR HIGH BYTE CSRB  
CLR 10(R0) ;CLEAR CSRC; CHIP RESET GROUP 2  
CLRB 15(R0) ;CLEAR HIGH BYTE CSRD  
MOV (SP)+, R0 ;RETURN R0  
RTS R5  
  
:CLEAR IRP REGISTERS, GROUP 1, GROUP 2 WITH CHIP RESET  
CLRIRR: MOV R0, -(SP)  
MOV DRCSA, R0 ;START OF CSR ADDRESS  
CLRB 11(R0) ;CSRC TO INPUT MODE  
MOVB #BIT0, 1(R0) ;CSRA TO OUTPUT MODE  
CLR 2(R0) ;CLEAR DBRA  
CLRB (R0) ;CHIP RESET OF GROUP1  
CLRB 10(R0) ;CHIP RESET OF GROUP 2  
MOV (SP)+, R0 ;RESTORE REGISTER  
RTS R5 ;EXIT  
  
:ROUTINE TO FILL VECTOR MEMORY FOR VECTOR UNIQUENESS TEST  
:300-474 GROUP 1  
:500-674 GROUP 2  
VECFIL: MOV DRCSA, R0 ;START GROUP 1  
MOV DRCSB, R1  
MOV #2, R2 ;TWO GROUPS  
MOV #60, VECPAT ;VECTOR START 300  
1$: MOV #370, VECVAL ;START VECTOR LEVEL 0, BY4  
MOV #8, LVL CNT ;LEVELS 0-7  
2$: MOVB VECVAL, (R0)  
3$: MOV #4, BYCNT ;DO FOUR BYTE COUNTS  
MOVB VECPAT, (R1) ;WRITE VECTOR  
INC VECPAT ;SETUP FOR NEXT VECTOR  
TST KXTFLAG ; KXT11 ?? ;:GPA  
BEQ 1000$ ; BR IF NOT ;:GPA  
CMP VECPAT, #100 ; YES, REACHED VECTOR 400 ?? ;:GPA  
BLO 1000$ ; NOT YET, CONTINUE ;:GPA  
MOV #60, VECPAT ; YES, WRAP-AROUND TO 300 AGAIN ;:GPA  
; WE'LL END UP WITH 300-374... ;:GPA  
; ...REPLICATED 4 TIMES. ;:GPA  
  
1000$: DEC BYCNT ;DONE FOUR BYTE COUNTS?  
3$: BNE 3$ ;DO NEXT VECTOR  
4$: DEC LVL CNT ;DONE ALL LEVELS IN GROUP?
```

```

1072 011250 001403          BEQ      5$
1073 011252 005237 002456  INC      VECVAL      ;INC NEXT LEVEL
1074 011256 000744          BR       2$           ;DO NEXT LEVEL
1075 011260 005302          5$: DEC      R2         ;DONE BOTH GROUPS?
1076 01:262 001405          BEQ      6$           ;DONE,EXIT
1077 011264 013700 002422  MOV      DRCSC,R0     ;DO GROUP 2
1078 011270 013701 002426  MOV      DRCSD,R1
1079 011274 000727          BR       1$
1080 011276 000205          6$: RTS      R5       ;EXIT
1081
1082          ;ROUTINE TO STORE VECTOR AREA 300-674 WITH INTERRUPT SERVICE
1083 011300 012700 000300  STRVEC: MOV      #300,R0      ;START AT VECTOR 300
1084 011304 012701 012236  MOV      #INT0,R1         ;FIRST SERVICE ROUTINE
1085 011310 012702 000100  MOV      #64,R2          ;STORE 64 SERVICE ROUTINES
1086 011314 010120          1$: MOV      R1,(R0)+
1087 011316 012720 000340  MOV      #340,(R0)+
1088          ;;GPA ADD      #6,R1      ;SETUP FOR NEXT VECTOR STORAGE
1089 011322 062701 000004  ADD      #4,R1           ; SETUP NEXT VETOR.      ;;GPA
1090 011326 005302          DEC      R2            ;DONE WITH 64 VECTOR ROUTINES?
1091 011330 001371          BNE      1$
1092 011332 000205          RTS      R5           ;EXIT
1093
1094          ;ROUTINE TO CLEAR VECTOR BUFFER
1095 011334 012700 017160  CLRBF: MOV      #VBUF,R0     ;VECTOR BUFFER START
1096 011340 012701 000100  MOV      #64,R1
1097 011344 005020          1$: CLR      (R0)+
1098 011346 005301          DEC      R1
1099 011350 001375          BNE      1$
1100 011352 000205          RTS      R5
1101
1102          ;ROUTINE TO STORE 0-202 INTO BUFFER AREA TO ALLOW
1103          ;VECTOR TESTS TO 0-200.
1104 011354 005000          TOBUF: CLR      R0
1105 011356 012701 016754  MOV      #DBUF,R1         ;BUFFER START
1106 011362 012021          1$: MOV      (R0)+,(R1)+    ;STORE 0-202 INTO BUFFER
1107 011364 022700 000204  CMP      #204,R0         ;FINISHED?
1108 011370 001374          BNE      1$           ;NO
1109 011372 000205          RTS      R5           ;RETURN
1110
1111          ;STORE BUFFER AREA INTO LOCATIONS 0-202
1112          ;AFTER VECTOR TESTS
1113 011374 010046          FRMBUF: MOV      R0,-(SP)    ;SAVE R0
1114 011376 010146          MOV      R1,-(SP)
1115 011400 005000          CLR      R0
1116 011402 012701 016754  1$: MOV      #DBUF,R1     ;BUFFER START
1117 011406 012120          MOV      (R1)+,(R0)+    ;STORE BUFFER INTO LOCS 0-202
1118 011410 022700 000204  CMP      #204,R0         ;FINISHED?
1119 011414 001374          BNE      1$           ;NO
1120 011416 013777 002460 170514  MOV      SWRSV,SWR      ;STORE LOCATION 176,SOFT SWR
1121 011424 012601          MOV      (SP)+,R1       ;RESTORE R1
1122 011426 012600          MOV      (SP)+,R0       ;RESTORE R0
1123 011430 000205          RTS      R5           ;RETURN
1124
1125          ;RESTORE VECTOR JUST TESTED TO ORIGINAL TRAP FOR 204-1774
1126 011432 022737 000001 002210  RESTRP: CMP      #1,SENV   ;CHECK FOR APT
1127 011440 001421          BEQ      1$           ;YES,BRANCH
  
```

```

1128 011442 032777 010000 170470      BIT      #SW12,@SWR      ;CHECK TYPE OF TRAP RETURN
1129 011450 001412                    BEQ      10$           ;RESTORE ILLEGAL VECTOR ROUTINE
1130 011452 062737 000002 002452      ADD      #2,VECLOC     ;RESTORE TRAP
1131 011460 013723 002452      MOV      VECLOC,(R3)+ ;TO VECTOR
1132 011464 005013                    CLR      (R3)         ;RESTORE HALT
1133 011466 062737 000002 002452      ADD      #2,VECLOC     ;SETUP FOR NEXT
1134 011474 000412                    BR       2$           ;RETURN
1135 011476 012723 011752      10$:    MOV      #TRPALL,(R3)+ ;RESTORE ILLEGAL TRAP ROUTINE
1136 011502 000402                    BR       11$          ;RESTORE PSW
1137 011504 012723 011734      1$:    MOV      #TRPOUT,(R3)+ ;RESTORE APT SUB TRAP
1138                                ;IF ON APT
1139 011510 012713 000340      11$:    MOV      #340,(R3)     ;RESTORE PSW SAVE
1140 011514 062737 000004 002452      ADD      #4,VECLOC     ;UPDATE FOR NEXT VECTOR
1141 011522 000205      2$:    RTS      R5       ;RETURN
1142
1143                                ;ROUTINE TO SET UP TRAP CATCHER 204-1774 IN STANDALONE MODE OR
1144                                ;A COMMON VECTOR ROUTINE SETUP UNDER APT.
1145                                ;VECTOR ROUTINE IS USED ONLY IN AN APT ENVIRONMENT AND WILL STORE
1146                                ;A COMMON SUBROUTINE IN VECTOR AREA 204-1774.
1147
1148 011524 010046      TRPCAT: MOV      R0,-(SP)   ;SAVE R0
1149 011526 010146      MOV      R1,-(SP)
1150 011530 022737 000001 002210      CMP      #1,$ENV      ;CHECK FOR APT
1151 011536 001426      BEQ      APTVEC       ;YES,SET UP TRAPS FOR APT
1152 011540 012700 000204      MOV      #204,R0      ;START CATCHER AT 204
1153 011544 032777 010000 170366      BIT      #SW12,@SWR   ;TEST IF SW12 IS SET
1154 011552 001010      BNE      1$           ;YES,BR AND STORE REGULAR TRAP
1155                                ;CATCHER(+2,HALT) IN LOCATIONS
1156                                ;204-1774
1157 011554 012720 011752      11$:    MOV      #TRPALL,(R0)+ ;NO,PLACE ILLEGAL VECTOR RETURN
1158 011560 012720 000340      MOV      #340,(R0)+   ;ROUTINES IN LOCATIONS 204-1774
1159 011564 022700 002000      CMP      #2000,R0     ;STORED ALL VECTORS?
1160 011570 001371      BNE      11$
1161 011572 000421      BR       ENDTRP      ;RETURN AFTER VECTOR STORAGE
1162 011574 010001      1$:    MOV      R0,R1     ;DRV11J CAN VECTOR 0-1774
1163 011576 005721      TST     (R1)+
1164 011600 010120      MOV      R1,(R0)+
1165 011602 005020      CLR     (R0)+
1166 011604 022701 001776      CMP     #1776,R1     ;CHECK FOR VECTOR END
1167 011610 001371      BNE     1$
1168 011612 000411      BR     ENDTRP      ;RETURN IN STAND ALONE MODE
1169 011614 012701 000204      APTVEC: MOV     #204,R1 ;STARTING VECTOR ADDRESS
1170 011620 012721 011734      1$:    MOV     #TRPOUT,(R1)+ ;ILL INTERRUPT ROUTINE
1171 011624 012721 000340      MOV     #340,(R1)+   ;PSW NEXT
1172 011630 022701 002000      CMP     #2000,R1     ;DONE?
1173 011634 001371      BNE     1$           ;DO NEXT VECTOR
1174 011636 012601      ENDTRP: MOV    (SP)+,R1
1175 011640 012600      MOV    (SP)+,R0
1176 011642 000205      RTS     R5           ;EXIT
1177
1178                                ;INTERRUPT SERVICE ROUTINE USED TO VERIFY INTERRUPTS 204-1774
1179 011644 005237 002436      INTSR1: INC    INTFLG  ;COUNT INTERRUPT
1180 011650 012737 000001 002124      MOV     #1,$GDDAT    ;STORE EXPECTED
1181 011656 013737 002436 002126      MOV     INTFLG,$BDDAT ;SAVE INT. COUNT
1182 011664 023737 002124 002126      CMP     $GDDAT,$BDDAT ;SHOULD BE ONE INTERRUPT
1183 011672 001401      BEQ     1$

```

```

1184 011674 104013          ERROR 13          :MULTIPLE INTERRUPTS RECEIVED
1185 011676 000002          1$: RTI          :RETURN FROM INT.
1186
1187          :INTERRUPT SERVICE ROUTINE USED TO VERIFY INTERRUPTS 204-1774
1188          :FOR A BYTE COUNT OF 1 TO 4 VECTORS IN VECTOR ADDR MEMORY.
1189 011700 005237 002436          INTBY4: INC INTFLG          :COUNT INTERRUPT
1190 011704 013737 002472 002124          MOV BYNUM,$GDDAT          :STORE EXPECTED
1191 011712 013737 002436 002126          MOV INTFLG,$BDDAT          :SAVE INT. COUNT
1192 011720 023737 002124 002126          CMP $GDDAT,$BDDAT          :INTERRUPTS SHOULD NOT EXCEED BYTE COUNT
1193 011726 002001          BGE 1$
1194 011730 104013          ERROR 13          :MULTIPLE INTERRUPTS RECEIVED
1195          :MORE INTERRUPTS THAN BYTE COUNT
1196 011732 000002          1$: RTI          :RETURN FROM INT.
1197
1198          :COMMON ILLEGAL VECTOR RETURN ROUTINE FOR APT MODE.
1199 011734 011637 002120          TRPOUT: MOV (SP),$GDADR          :SAVE ADDRESS OF TEST
1200 011740 004537 011374          JSR R5,FRMBUF          :RETURN LOCATIONS 0-202
1201 011744 104014          ERROR 14          :ILLEGAL VECTOR ADDR MEM ERROR
1202 011746 000000          HALT          :CANNOT CONTINUE
1203 011750 000000          HALT          :CANNOT CONTINUE
1204
1205          :COMMON ILLEGAL VECTOR RETURN ROUTINE FOR VECTOR AREA
1206          :204-1774
1207 011752 011637 002120          TRPALL: MOV (SP),$GDADR          :SAVE PC OF TEST
1208 011756 104014          ERROR 14          :ILLEGAL VECTOR ADDR MEM ERROR
1209 011760 000002          RTI          :RETURN
1210
1211          :RESTORE VECTOR JUST TESTED TO ERROR SUBROUTINE FOR 0-202
1212 011762 022737 000001 002210          RES200: CMP #1,$ENV          :CHECK FOR APT
1213 011770 001405          BEQ 1$          :YES,BRANCH
1214 011772 012723 012170          MOV #TRP200,(R3)+          :ERROR TRAP SUB. FOR 0-200
1215 011776 012713 000340          MOV #340,(R3)          :PSW
1216 012002 000404          BR 2$          :RETURN
1217 012004 012723 011734          1$: MOV #TRPOUT,(R3)+          :RESTORE APT SUB TRAP
1218          :IF ON APT
1219 012010 012713 000340          MOV #340,(R3)          :RESTORE PSW SAVE
1220 012014 062737 000004 002452          2$: ADD #4,VECLOC          :UPDATE FOR NEXT VECTOR
1221 012022 000205          RTS R5          :RETURN
1222
1223          :ROUTINE TO SET UP TRAP SUBROUTINE 0-200 IN STANDALONE MODE OR
1224          :A COMMON ERROR VECTOR ROUTINE SETUP UNDER APT.
1225
1226 012024 010046          CAT200: MOV R0,-(SP)          :SAVE R0
1227 012026 017737 170106 002460          MOV @SWR,SWRSV          :SAVE LOCATION 176,SOFT SWR
1228 012034 022737 000001 002210          CMP #1,$ENV          :CHECK FOR APT
1229 012042 001411          BEQ APT200          :YES,SET UP TRAPS FOR APT
1230 012044 005000          CLR R0          :START CATCHER SUB AT 0
1231 012046 012720 012170          1$: MOV #TRP200,(R0)+          :STORE VECTOR TRAP SUBROUTINE
1232 012052 012720 000340          MOV #340,(R0)+          :PSW
1233 012056 022700 000204          CMP #204,R0          :FINISHED 0-202
1234 012062 001371          BNE 1$
1235 012064 000410          BR END200          :RETURN IN STAND ALONE MODE
1236 012066 005000          APT200: CLR R0          :START AT VECTOR 0
1237 012070 012720 011734          1$: MOV #TRPOUT,(R0)+          :VECTOR ERROR ROUTINE
1238 012074 012720 000340          MOV #340,(R0)+          :PSW NEXT
1239 012100 022700 000204          CMP #204,R0          :DONE?

```

```

1240 012104 001371
1241 012106 012600
1242 012110 012713 012124
1243 012114 012763 000340 000002
1244 012122 000205
1245
1246
1247
1248
1249 012124 005237 002436
1250 012130 013737 002472 002124
1251 012136 013737 002436 002126
1252 012144 023737 002124 002126
1253 012152 002005
1254 012154 004537 011374
1255 012160 104013
1256
1257 012162 004537 012024
1258 012166 000002
1259
1260
1261 012170 011637 002120
1262 012174 004537 011374
1263 012200 104014
1264 012202 004537 012024
1265 012206 000002
1266
1267
1268
1269 012210 017624 000000
1270 012214 005726
1271 012216 005237 002436
1272 012222 022737 000100 002436
1273 012230 002001
1274 012232 104013
1275 012234 000002
1276
1277
1278
1279
1280
1281
1282 012236 004715
1283 012240 000300
1284 012242 004715
1285 012244 000304
1286 012246 004715
1287 012250 000310
1288 012252 004715
1289 012254 000314
1290 012256 004715
1291 012260 000320
1292 012262 004715
1293 012264 000324
1294 012266 004715
1295 012270 000330

END200: BNE 1$ ;DO NEXT VECTOR
MOV (SP)+,R0
MOV #INTSR3,(R3) ;STORE VECTOR ROUTINE
MOV #340,2(R3) ;STORE PSW
RTS R5 ;EXIT

;INTERRUPT SERVICE ROUTINE USED TO VERIFY INTERRUPTS 0-200,BYTE COUNT 0-3
;FOR BYTE COUNTS OF 1 TO 4 VECTORS IN VECTOR ADDRESS MEMORY.
INTSR3: INC INTFLG ;COUNT INTERRUPT
MOV BYNUM,$GDDAT ;STORE EXPECTED
MOV INTFLG,$BDDAT ;SAVE INT. COUNT
CMP $GDDAT,$BDDAT ;INTERRUPTS SHOULD NOT EXCEED BYTE COUNT
BGE 1$
JSR R5,FRMBUF ;RESTORE 0-202 BEFORE ERROR
ERROR 13 ;MULTIPLE INTERRUPTS RECEIVED
;MORE INTERRUPTS THAN BYTE COUNT
1$: JSR R5,CAT200 ;RESTORE VECTOR SUBROUTINES
RTI ;RETURN FROM INT.

;COMMON ILLEGAL VECTOR ERROR RETURN ROUTINE FOR 0-200
TRP200: MOV (SP),$GDADR ;SAVE PC OF TEST
JSR R5,FRMBUF ;RETURN LOC 0-200
ERROR 14 ;ILLEGAL VECTOR ADDR MEM ERROR
JSR R5,CAT200 ;RESTORE VECTOR SUBROUTINES FOR PROCEED
RTI ;RETURN

;VECTOR SERVICE ROUTINE FOR VECTOR UNIQUENESS TEST
SETVEC: MOV (R5)+,(R4)+ ;STORE VALUE IN BUFFER ;;GPA
SETVEC: MOV @ (SP),(R4)+ ;STORE VECTOR NUMBER IN BUFFER ;;GPA
TST (SP)+ ;RESTORE STACK FOR RTI
INC INTFLG ;COUNT INTERRUPT
CMP #64.,INTFLG
BGE 1$ ;64 EXPECTED INTERRUPTS?
ERROR 13 ;ERROR ,MORE THAN 64 INTERRUPTS
1$: RTI ;RETURN FOR NEXT INTERRUPT

;INTERRUPT SERVICE ROUTINES THAT ARE STORED FROM 300-674
;IN THE VECTOR UNIQUENESS TEST.
; R5 POINTS TO "SETVEC:" DURING TESTS 5 AND 6, AND CALLS ;;GPA
; CHANGED FROM "JSR R5,SETVEC" TO "JSR PC,(R5)" TO CONSERVE ;;GPA
; SPACE AND REMAIN UNDER 4KW TOTAL PROGRAM SIZE. ;;GPA
INT0: JSR PC,(R5) ;STORE 300 INTO VBUF,TO BE ;;GPA
300 ;CHECKED AFTER ALL INTERRUPTS.
INT1: JSR PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN ;;GPA
304
INT2: JSR PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN ;;GPA
310
INT3: JSR PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN ;;GPA
314
INT4: JSR PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN ;;GPA
320
INT5: JSR PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN ;;GPA
324
INT6: JSR PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN ;;GPA
330

```


1296	012272	004715	INT7:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1297	012274	000334		334		
1298	012276	004715	INT8:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1299	012300	000340		340		
1300	012302	004715	INT9:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1301	012304	000344		344		
1302	012306	004715	INT10:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1303	012310	000350		350		
1304	012312	004715	INT11:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1305	012314	000354		354		
1306	012316	004715	INT12:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1307	012320	000360		360		
1308	012322	004715	INT13:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1309	012324	000364		364		
1310	012326	004715	INT14:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1311	012330	000370		370		
1312	012332	004715	INT15:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1313	012334	000374		374		
1314	012336	004715	INT16:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1315	012340	000400		400		
1316	012342	004715	INT17:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1317	012344	000404		404		
1318	012346	004715	INT18:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1319	012350	000410		410		
1320	012352	004715	INT19:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1321	012354	000414		414		
1322	012356	004715	INT20:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1323	012360	000420		420		
1324	012362	004715	INT21:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1325	012364	000424		424		
1326	012366	004715	INT22:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1327	012370	000430		430		
1328	012372	004715	INT23:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1329	012374	000434		434		
1330	012376	004715	INT24:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1331	012400	000440		440		
1332	012402	004715	INT25:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1333	012404	000444		444		
1334	012406	004715	INT26:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1335	012410	000450		450		
1336	012412	004715	INT27:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1337	012414	000454		454		
1338	012416	004715	INT28:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1339	012420	000460		460		
1340	012422	004715	INT29:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1341	012424	000464		464		
1342	012426	004715	INT30:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1343	012430	000470		470		
1344	012432	004715	INT31:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1345	012434	000474		474		
1346	012436	004715	INT32:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1347	012440	000500		500		
1348	012442	004715	INT33:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1349	012444	000504		504		
1350	012446	004715	INT34:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1351	012450	000510		510		

1352	012452	004715	INT35:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1353	012454	000514		514		
1354	012456	004715	INT36:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1355	012460	000520		520		
1356	012462	004715	INT37:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1357	012464	000524		524		
1358	012466	004715	INT38:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1359	012470	000530		530		
1360	012472	004715	INT39:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1361	012474	000534		534		
1362	012476	004715	INT40:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1363	012500	000540		540		
1364	012502	004715	INT41:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1365	012504	000544		544		
1366	012506	004715	INT42:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1367	012510	000550		550		
1368	012512	004715	INT43:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1369	012514	000554		554		
1370	012516	004715	INT44:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1371	012520	000560		560		
1372	012522	004715	INT45:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1373	012524	000564		564		
1374	012526	004715	INT46:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1375	012530	000570		570		
1376	012532	004715	INT47:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1377	012534	000574		574		
1378	012536	004715	INT48:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1379	012540	000600		600		
1380	012542	004715	INT49:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1381	012544	000604		604		
1382	012546	004715	INT50:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1383	012550	000610		610		
1384	012552	004715	INT51:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1385	012554	000614		614		
1386	012556	004715	INT52:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1387	012560	000620		620		
1388	012562	004715	INT53:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1389	012564	000624		624		
1390	012566	004715	INT54:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1391	012570	000630		630		
1392	012572	004715	INT55:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1393	012574	000634		634		
1394	012576	004715	INT56:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1395	012600	000640		640		
1396	012602	004715	INT57:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1397	012604	000644		644		
1398	012606	004715	INT58:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1399	012610	000650		650		
1400	012612	004715	INT59:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1401	012614	000654		654		
1402	012616	004715	INT60:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1403	012620	000660		660		
1404	012622	004715	INT61:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1405	012624	000664		664		
1406	012626	004715	INT62:	JSR	PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN	::GPA
1407	012630	000670		670		

1408 012632 004715
1409 012634 000674
1410
1411
1412
1413
1414
1415
1416
1417
1418 012636 001 376
1419 012640 002 375
1420 012642 004 373
1421 012644 010 367
1422 012646 020 357
1423 012650 040 337
1424 012652 100 277
1425 012654 200 177
1426 012656 000000
1427
1428

INT63: JSR PC,(R5) ;VECTOR UNIQUENESS TEST, INT. SERV RTN ;:GPA
674

.SBTTL PATTERNS FOR REGISTER R/W

: PATTERNS USED FOR LOADING/READING REGISTERS

:ISR INTERRUPT SERVICE REGISTER

:IRR INTERRUPT REQUEST REGISTER

:IMR INTERRUPT MASK REGISTER

BGCHP3: .BYTE 1,376

.BYTE 2,375

.BYTE 4,373

.BYTE 10,367

.BYTE 20,357

.BYTE 40,337

.BYTE 100,277

.BYTE 200,177

EDCHP3: 000000

```
1430 .SBTTL SYSMAC ROUTINES
1431
1432 .SBTTL TYPE ROUTINE
(1) *****
(1) *ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
(1) *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
(1) *NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
(1) *NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
(1) *NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
(1) *
(1) *CALL:
(1) *1) USING A TRAP INSTRUCTION
(1) * TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
(1) *OR
(1) * TYPE
(1) * MESADR
(1) *
(1) $TYPE: TSTB $TPFLG ;;IS THERE A TERMINAL?
(1) 012660 105737 002157 BPL 1$ ;;BR IF YES
(1) 012664 100002 HALT ;;HALT HERE IF NO TERMINAL
(1) 012666 000000 BR 3$ ;;LEAVE
(1) 012670 000430 1$: MOV R0,-(SP) ;;SAVE R0
(1) 012672 010046 MOV @2(SP),R0 ;;GET ADDRESS OF ASCIZ STRING
(1) 012674 017600 000002 002210 CMPB #APTENV,$ENV ;;RUNNING IN APT MODE
(1) 012700 122737 000001 BNE 62$ ;;NO,GO CHECK FOR APT CONSOLE
(1) 012706 001011 BITB #APTPOOL,$ENVM ;;SPOOL MESSAGE TO APT
(1) 012710 132737 000100 002211 BEQ 62$ ;;NO,GO CHECK FOR CONSOLE
(1) 012716 001405 MOV R0,61$ ;;SETUP MESSAGE ADDRESS FOR APT
(1) 012720 010037 012730 JSR PC,$ATY3 ;;SPOOL MESSAGE TO APT
(1) 012724 004737 013222 61$: .WORD 0 ;;MESSAGE ADDRESS
(1) 012730 000000 62$: BITB #APTCSUP,$ENVM ;;APT CONSOLE SUPPRESSED
(1) 012732 132737 000040 002211 BNE 60$ ;;YES,SKIP TYPE OUT
(1) 012740 001003 2$: MOVB (R0)+,-(SP) ;;PUSH CHARACTER TO BE TYPED ONTO STACK
(1) 012742 112046 BNE 4$ ;;BR IF IT ISN'T THE TERMINATOR
(1) 012744 001005 TST (SP)+ ;;IF TERMINATOR POP IT OFF THE STACK
(1) 012746 005726 60$: MOV (SP)+,R0 ;;RESTORE R0
(1) 012750 012600 3$: ADD #2,(SP) ;;ADJUST RETURN PC
(1) 012752 062716 000002 RTI ;;RETURN
(1) 012756 000002 4$: CMPB #HT,(SP) ;;BRANCH IF <HT>
(1) 012760 122716 000011 BEQ 8$
(1) 012764 001430 000200 CMPB #CRLF,(SP) ;;BRANCH IF NOT <CRLF>
(1) 012766 122716 BNE 5$
(1) 012772 001006 TST (SP)+ ;;POP <CR><LF> EQUIV
(1) 012774 005726 TYPE ;;TYPE A CR AND LF
(1) 012776 104401 $CRLF
(1) 013000 002165 CLR B $CHARCNT ;;CLEAR CHARACTER COUNT
(1) 013002 105037 013210 BR 2$ ;;GET NEXT CHARACTER
(1) 013006 000755 5$: JSR PC,$TYPEC ;;GO TYPE THIS CHARACTER
(1) 013010 004737 013072 6$: CMPB $FILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?
(1) 013014 123726 002156 BNE 2$ ;;IF NO GO GET NEXT CHAR.
(1) 013020 001350 MOV $NULL,-(SP) ;;GET # OF FILLER CHARS. NEEDED
(1) 013022 013746 002154 AND THE NULL CHAR.
(1) 61) 013026 105366 000001 7$: DECB 1(SP) ;;DOES A NULL NEED TO BE TYPED?
(1) 013032 002770 BLT 6$ ;;BR IF NO--GO POP THE NULL OFF OF STACK
```

```
(1) 013034 004737 013072 JSR PC,$TYPEC ::GO TYPE A NULL
(1) 013040 105337 013210 DECB $CHARCNT ::DO NOT COUNT AS A COUNT
(1) 013044 000770 BR 7$ ::LOOP
(1)
(1) :HORIZONTAL TAB PROCESSOR
(1)
(1) 013046 112716 000040 8$: MOVB #' (SP) ::REPLACE TAB WITH SPACE
(1) 013052 004737 013072 9$: JSR PC,$TYPEC ::TYPE A SPACE
(1) 013056 132737 000007 013210 BITB #7,$CHARCNT ::BRANCH IF NOT AT
(1) 013064 001372 BNE 9$ ::TAB STOP
(1) 013066 005726 TST (SP)+ ::POP SPACE OFF STACK
(1) 013070 000724 BR 2$ ::GET NEXT CHARACTER
(1) 013072 105777 167046 $TYPEC: TSTB @STKS ::CHAR IN KYBD BUFFER? :MJD001
(1) 013076 100022 BPL 10$ ::BR IF NOT :MJD001
(1) 013100 017746 167042 MOV @STKB,-(SP) ::GET CHAR :MJD001
(1) 013104 042716 177600 BIC #177600,(SP) ::STRIP EXTRANEIOUS BITS :MJD001
(1) 013110 122716 000023 CMPB #$XOFF,(SP) ::WAS CHAR XOFF :MJD001
(1) 013114 001012 BNE 102$ ::BR IF NOT :MJD001
(1) 013116 105777 167022 101$: TSTB @STKS ::WAIT FOR CHAR :MJD001
(1) 013122 100375 BPL 101$ :MJD001
(1) 013124 117716 167016 MOVB @STKB,(SP) ::GET CHAR :MJD001
(1) 013130 042716 177600 BIC #177600,(SP) ::STRIP IT :MJD001
(1) 013134 122716 000021 CMPB #$XON,(SP) ::WAS IT XON? :MJD001
(1) 013140 001366 BNE 101$ ::BR IF NOT :MJD001
(1) 013142 005726 102$: TST (SP)+ ::FIX STACK :MJD001
(1) 013144 105777 167000 10$: TSTB @STPS ::WAIT UNTIL PRINTER IS READY :MJD001
(1) 013150 100375 BPL 10$ :MJD001
(1) 013152 116677 000002 166772 MOVB 2(SP),@STPB ::LOAD CHAR TO BE TYPED INTO DATA REG.
(1) 013160 122766 000015 000002 CMPB #CR,2(SP) ::IS CHARACTER A CARRIAGE RETURN?
(1) 013166 001003 BNE 1$ ::BRANCH IF NO
(1) 013170 105037 013210 CLRB $CHARCNT ::YES--CLEAR CHARACTER COUNT
(1) 013174 000406 BR $TYPEX ::EXIT
(1) 013176 122766 000012 000002 1$: CMPB #LF,2(SP) ::IS CHARACTER A LINE FEED?
(1) 013204 001402 BEQ $TYPEX ::BRANCH IF YES
(1) 013206 105227 INCB (PC)+ ::COUNT THE CHARACTER
(1) 013210 000000 $CHARCNT: WORD 0 ::CHARACTER COUNT STORAGE
(1) 013212 000207 $TYPEX: RTS PC
(1)
(1) .SBTTL APT COMMUNICATIONS ROUTINE
(2)
(1) 013214 112737 000001 013460 $ATY1: MOVB #1,$FFLG ::TO REPORT FATAL ERROR
(1) 013222 112737 000001 013456 $ATY3: MOVB #1,$MFLG ::TO TYPE A MESSAGE
(1) 013230 000403 BR $ATYC
(1) 013232 112737 000001 013460 $ATY4: MOVB #1,$FFLG ::TO ONLY REPORT FATAL ERROR
(1) 013240 $ATYC:
(3) 013240 010046 MOV R0,-(SP) ::PUSH R0 ON STACK
(3) 013242 010146 MOV R1,-(SP) ::PUSH R1 ON STACK
(1) 013244 105737 013456 TSTB $MFLG ::SHOULD TYPE A MESSAGE?
(1) 013250 001450 BEQ 5$ ::IF NOT: BR
(1) 013252 122737 000001 002210 CMPB #APTENV,$ENV ::OPERATING UNDER APT?
(1) 013260 001031 BNE 3$ ::IF NOT: BR
```

```

(1) 013262 132737 000100 002211 BITB #APTSPOOL,SENV :: SHOULD SPOOL MESSAGES?
(1) 013270 001425 BEQ 3$ :: IF NOT: BR
(1) 013272 017600 000004 MOV @4(SP),R0 :: GET MESSAGE ADDR.
(1) 013276 062766 000002 000004 ADD #2,4(SP) :: BUMP RETURN ADDR.
(1) 013304 005737 002170 1$: TST SMSGTYPE :: SEE IF DONE W/ LAST XMISSION?
(1) 013310 001375 BNE 1$ :: IF NOT: WAIT
(1) 013312 010037 002204 MOV R0,SMSGAD :: PUT ADDR IN MAILBOX
(1) 013316 105720 2$: TSTB (R0)+ :: FIND END OF MESSAGE
(1) 013320 001376 BNE 2$
(1) 013322 163700 002204 SUB SMSGAD,R0 :: SUB START OF MESSAGE
(1) 013326 006200 ASR R0 :: GET MESSAGE LGTH IN WORDS
(1) 013330 010037 002206 MOV R0,SMSGLGT :: PUT LENGTH IN MAILBOX
(1) 013334 012737 000004 002170 MOV #4,SMSGTYPE :: TELL APT TO TAKE MSG.
(1) 013342 000413 BR 5$
(1) 013344 017637 000004 013370 3$: MOV @4(SP),4$ :: PUT MSG ADDR IN JSR LINKAGE
(1) 013352 062766 000002 000004 ADD #2,4(SP) :: BUMP RETURN ADDRESS
(3) 013360 013746 177776 MOV 177776,-(SP) :: PUSH 177776 ON STACK
(1) 013364 004737 012660 JSR PC,$TYPE :: CALL TYPE MACRO
(1) 013370 000000 4$: .WORD 0
(1) 013372 5$:
(1) 013372 105737 013460 10$: TSTB $FFLG :: SHOULD REPORT FATAL ERROR?
(1) 013376 001416 BEQ 12$ :: IF NOT: BR
(1) 013400 005737 002210 TST $ENV :: RUNNING UNDER APT?
(1) 013404 001413 BEQ 12$ :: IF NOT: BR
(1) 013406 005737 002170 11$: TST SMSGTYPE :: FINISHED LAST MESSAGE?
(1) 013412 001375 BNE 11$ :: IF NOT: WAIT
(1) 013414 017637 000004 002172 MOV @4(SP),$FATAL :: GET ERROR #
(1) 013422 062766 000002 000004 ADD #2,4(SP) :: BUMP RETURN ADDR.
(1) 013430 005237 002170 INC SMSGTYPE :: TELL APT TO TAKE ERROR
(1) 013434 105037 013460 12$: CLRB $FFLG :: CLEAR FATAL FLAG
(1) 013440 105037 013457 CLRB $LFLG :: CLEAR LOG FLAG
(1) 013444 105037 013456 CLRB $MFLG :: CLEAR MESSAGE FLAG
(3) 013450 012601 MOV (SP)+,R1 :: POP STACK INTO R1
(3) 013452 012600 MOV (SP)+,R0 :: POP STACK INTO R0
(1) 013454 000207 RTS PC :: RETURN
(1) 013456 000 .BYTE 0 :: MESSG. FLAG
(1) 013457 000 .BYTE 0 :: LOG FLAG
(1) 013460 000 .BYTE 0 :: FATAL FLAG
(1) 013462 .EVEN
(1) 000200 APTSIZE=200
(1) 000001 APTENV=001
(1) 000100 APTSPOOL=100
(1) 000040 APTCSUP=040

```

1434

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

(1) *****
(2) *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
(1) *OCTAL (ASCII) NUMBER AND TYPE IT.
(1) *$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
(1) *CALL:
(1) * MOV NUM,-(SP) :: NUMBER TO BE TYPED
(1) * TYPOS :: CALL FOR TYPEOUT
(1) * .BYTE N :: N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
(1) * .BYTE M :: M=1 OR 0
(1) * :: 1=TYPE LEADING ZEROS
(1) * :: 0=SUPPRESS LEADING ZEROS

```



```
(1)          : *
(1)          : *STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
(1)          : *STYPOS OR STYPOC
(1)          : *CALL:
(1)          : *      MOV      NUM,-(SP)      ::NUMBER TO BE TYPED
(1)          : *      TYPON      ::CALL FOR TYPEOUT
(1)          : *
(1)          : *STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
(1)          : *CALL:
(1)          : *      MOV      NUM,-(SP)      ::NUMBER TO BE TYPED
(1)          : *      TYPOC     ::CALL FOR TYPEOUT
(1)          :
(1) 013462 017646 000000          STYPOS: MOV      @ (SP),-(SP)      ::PICKUP THE MODE
(1) 013466 116637 000001 013705 MOVB     1(SP), $OFILL  ::LOAD ZERO FILL SWITCH
(1) 013474 112637 013707          MOVB     (SP)+, $OCNT+1  ::NUMBER OF DIGITS TO TYPE
(1) 013500 062716 000002          ADD      #2, (SP)      ::ADJUST RETURN ADDRESS
(1) 013504 000406          BR      STYPON
(1) 013506 112737 000001 013705 STYPOC: MOVB     #1, $OFILL  ::SET THE ZERO FILL SWITCH
(1) 013514 112737 000006 013707 MOVB     #6, $OCNT+1    ::SET FOR SIX(6) DIGITS
(1) 013522 112737 000005 013704 STYPON: MOVB     #5, $OCNT  ::SET THE ITERATION COUNT
(1) 013530 010346          MOV      R3, -(SP)     ::SAVE R3
(1) 013532 010446          MOV      R4, -(SP)     ::SAVE R4
(1) 013534 010546          MOV      R5, -(SP)     ::SAVE R5
(1) 013536 113704 013707          MOVB     $OCNT+1, R4   ::GET THE NUMBER OF DIGITS TO TYPE
(1) 013542 005404          NEG      R4
(1) 013544 062704 000006          ADD      #6, R4        ::SUBTRACT IT FOR MAX. ALLOWED
(1) 013550 110437 013706          MOVB     R4, $OCNT     ::SAVE IT FOR USE
(1) 013554 113704 013705          MOVB     $OFILL, R4    ::GET THE ZERO FILL SWITCH
(1) 013560 016605 000012          MOV      12(SP), R5   ::PICKUP THE INPUT NUMBER
(1) 013564 005003          CLR      R3           ::CLEAR THE OUTPUT WORD
(1) 013566 006105          1$: ROL     R5         ::ROTATE MSB INTO 'C'
(1) 013570 000404          BR      3$
(1) 013572 006105          2$: ROL     R5         ::FORM THIS DIGIT
(1) 013574 006105          ROL     R5
(1) 013576 006105          ROL     R5
(1) 013600 010503          MOV      R5, R3
(1) 013602 006103          3$: ROL     R3         ::GET LSB OF THIS DIGIT
(1) 013604 105337 013706          DECB     $OCNT        ::TYPE THIS DIGIT?
(1) 013610 100016          BPL     7$           ::BR IF NO
(1) 013612 042703 177770          BIC     #177770, R3   ::GET RID OF JUNK
(1) 013616 001002          BNE     4$           ::TEST FOR 0
(1) 013620 005704          TST     R4           ::SUPPRESS THIS 0?
(1) 013622 001403          BEQ     5$           ::BR IF YES
(1) 013624 005204          4$: INC     R4         ::DON'T SUPPRESS ANYMORE 0'S
(1) 013626 052703 000060          BIS     #'0, R3      ::MAKE THIS DIGIT ASCII
(1) 013632 052703 000040          5$: BIS     #' , R3   ::MAKE ASCII IF NOT ALREADY
(1) 013636 110337 013702          MOVB     R3, 8$      ::SAVE FOR TYPING
(1) 013642 104401 013702          TYPE    8$          ::GO TYPE THIS DIGIT
(1) 013646 105337 013704          7$: DECB     $OCNT    ::COUNT BY 1
(1) 013652 003347          BGT     2$          ::BR IF MORE TO DO
(1) 013654 002402          BLT     6$          ::BR IF DONE
(1) 013656 005204          INC     R4          ::INSURE LAST DIGIT ISN'T A BLANK
(1) 013660 000744          BR      2$          ::GO DO THE LAST DIGIT
(1) 013662 012605          6$: MOV      (SP)+, R5  ::RESTORE R5
(1) 013664 012604          MOV      (SP)+, R4  ::RESTORE R4
(1) 013666 012603          MOV      (SP)+, R3  ::RESTORE R3
```



```
(1) 014254 000000 HALT ::HALT ON ERROR!  
(1) 014256 104407 CKSWR ::TEST FOR CHANGE IN SOFT-SWR  
(1) 014260 032777 001000 165652 3$: BIT #BIT09,@SWR ::LOOP ON ERROR SWITCH SET?  
(1) 014266 001402 BEQ 4$ ::BR IF NO  
(1) 014270 013716 002110 MOV $LPERR,(SP) ::FUDGE RETURN FOR LOOPING  
(1) 014274 005737 002162 4$: TST $ESCAPE ::CHECK FOR AN ESCAPE ADDRESS  
(1) 014300 001402 BEQ 5$ ::BR IF NONE  
(1) 014302 013716 002162 MOV $ESCAPE,(SP) ::FUDGE RETURN ADDRESS FOR ESCAPE  
(1) 014306 5$:  
(1) 014306 000002 RTI ::RETURN
```

```
1437 *****  
1438 :GO TYPE ERROR  
1439 :GO UPDATE SOFTWARE SWR IF 'CNTRL/G'  
1440 *****
```

```
1441 014310 113737 002102 002432 SWRCK: MOV $TSTNM,TSTNUM ;SET UP TEST # ON ER  
1442 014316 004737 014326 JSR PC,$ERRTYP ;GO TYPE ERROR  
1443 014322 104407 CKSWR ;GO LOOK FOR SWR CHANGE  
1444 014324 000207 RTS PC ;RETURN TO ERROR HANDLER  
1445 .SBTTL ERROR MESSAGE TIMEOUT ROUTINE
```

```
(1) *****  
(2) :*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH  
(1) :*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),  
(1) :*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.  
(1) *****
```

```
(1) 014326 $ERRTYP:  
(1) 014326 104401 002165 TYPE $SCRLF ;:'CARRIAGE RETURN' & 'LINE FEED'  
(1) 014332 010046 MOV R0,-(SP) ;SAVE R0  
(1) 014334 005000 CLR R0 ;PICKUP THE ITEM INDEX  
(1) 014336 153700 002114 BISB @#$ITEMB,R0  
(1) 014342 001004 BNE 1$ ;:IF ITEM NUMBER IS ZERO, JUST  
(1) ;:TYPE THE PC OF THE ERROR  
(2) 014344 013746 002116 MOV $ERRPC,-(SP) ;SAVE $ERRPC FOR TIMEOUT  
(2) ;:ERROR ADDRESS  
(2) 014350 104402 ^YPOC ;GO TYPE--OCTAL ASCII(ALL DIGITS)  
(1) 014352 000426 B1. 6$ ;GET OUT  
(1) 014354 005300 1$: DEC R0 ;:ADJUST THE INDEX SO THAT IT WILL  
(1) 014356 006300 ASL R0 ;: WORK FOR THE ERROR TABLE  
(1) 014360 006300 ASL R0  
(1) 014362 006300 ASL R0  
(1) 014364 062700 002252 ADD #$ERRTB,R0 ;:FORM TABLE POINTER  
(1) 014370 012037 014400 MOV (R0)+,2$ ;:PICKUP "ERROR MESSAGE" POINTER  
(1) 014374 001404 BEQ 3$ ;:SKIP TIMEOUT IF NO POINTER  
(1) 014376 104401 TYPE ;:TYPE THE "ERROR MESSAGE"  
(1) 014400 000000 2$: .WORD 0 ;:"ERROR MESSAGE" POINTER GOES HERE  
(1) 014402 104401 002165 TYPE $SCRLF ;:'CARRIAGE RETURN' & 'LINE FEED'  
(1) 014406 012037 014416 3$: MOV (R0)+,4$ ;:PICKUP "DATA HEADER" POINTER  
(1) 014412 001404 BEQ 5$ ;:SKIP TIMEOUT IF 0  
(1) 014414 104401 TYPE ;:TYPE THE "DATA HEADER"  
(1) 014416 000000 4$: .WORD 0 ;:"DATA HEADER" POINTER GOES HERE  
(1) 014420 104401 002165 TYPE $SCRLF ;:'CARRIAGE RETURN' & 'LINE FEED'  
(1) 014424 011000 5$: MOV (R0),R0 ;:PICKUP "DATA TABLE" POINTER  
(1) 014426 001004 BNE 7$ ;:GO TYPE THE DATA  
(1) 014430 012600 6$: MOV (SP)+,R0 ;:RESTORE R0  
(1) 014432 104401 002165 TYPE $SCRLF ;:'CARRIAGE RETURN' & 'LINE FEED'  
(1) 014436 000207 RTS PC ;:RETURN
```



```
(1) 014632 005737 002176          TST      $PASS          ;;IF FIRST PASS OF PROGRAM
(1) 014636 001406                   BEQ      1$              ;;      INHIBIT ITERATIONS
(1) 014640 005237 002104          INC      $ICNT           ;;      INCREMENT ITERATION COUNT
(1) 014644 023737 002160 002104  CMP      $TIMES,$ICNT    ;;      CHECK THE NUMBER OF ITERATIONS MADE
(1) 014652 002024                   BGE      $OVER           ;;      BR IF MORE ITERATION REQUIRED
(1) 014654 012737 000001 002104 1$:  MOV      #1,$ICNT        ;;      REINITIALIZE THE ITERATION COUNTER
(1) 014662 013737 014740 002160  MOV      $MXCNT,$TIMES  ;;      SET NUMBER OF ITERATIONS TO DO
(1) 014670 105237 002102                   $SVLAD: INCB     $STNM     ;;      COUNT TEST NUMBERS
(1) 014674 113737 002102 002174  MOVB    $STNM,$STESTN   ;;      SET TEST NUMBER IN APT MAILBOX
(1) 014702 011637 002106                   MOV      (SP),$LPADR     ;;      SAVE SCOPE LOOP ADDRESS
(1) 014706 011637 002110                   MOV      (SP),$LPERR     ;;      SAVE ERROR LOOP ADDRESS
(1) 014712 005037 002162                   CLR      $ESCAPE         ;;      CLEAR THE ESCAPE FROM ERROR ADDRESS
(1) 014716 112737 000001 002115  MOVB    #1,$ERMAX       ;;      ONLY ALLOW ONE(1) ERROR ON NEXT TEST
(1) 014724 013777 002102 165210 $OVER:  MOV      $STNM,@DISPLAY ;;      DISPLAY TEST NUMBER
(1) 014732 013716 002106                   MOV      $LPADR,(SP)    ;;      FUDGE RETURN ADDRESS
(1) 014736 000002                   RTI                      ;;      FIXES PS
(1) 014740 000001                   $MXCNT: 1.              ;;      MAX. NUMBER OF ITERATIONS
1447 .SBTTL  TTY INPUT ROUTINE
(1)
(2)  ;;*****
(1) .ENABL  LSB
(1)
(2)  ;;*****
(1) *SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
(1) *ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
(1) *SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
(1) *WHEN OPERATING IN TTY FLAG MODE.
(1) 014742 022737 000176 002140 $CKSWR: CMP      #5,$REG,SWR  ;;IS THE SOFT-SWR SELECTED?
(1) 014750 001074                   BNE      15$             ;;BRANCH IF NO
(1) 014752 105777 165166                   TSTB    @STKS           ;;CHAR THERE?
(1) 014756 100071                   BPL      15$             ;;IF NO, DON'T WAIT AROUND
(1) 014760 117746 165102                   MOVB    @STKB,-(SP)     ;;SAVE THE CHAR
(1) 014764 042716 177600                   BIC     #^C177,(SP)    ;;STRIP-OFF THE ASCII
(1) 014770 022726 000007                   CMP      #7,(SP)+      ;;IS IT A CONTROL G?
(1) 014774 001062                   BNE      15$             ;;NO, RETURN TO USER
(1) 014776 123727 002134 000001  CMPB    $AUTOB,#1      ;;ARE WE RUNNING IN AUTO-MODE?
(1) 015004 001456                   BEQ      15$             ;;BRANCH IF YES
(1)
(1) 015006 104401 015477          $GTSWR: TYPE     ,SCNTLG  ;;ECHO THE CONTROL-G (^G)
(1) 015012 104401 015504          TYPE     ,SMSWR        ;;TYPE CURRENT CONTENTS
(2) 015016 013746 000176          MOV      SWREG,-(SP)   ;;SAVE SWREG FOR TYPEOUT
(2) 015022 104402                   TYPOC   $MNEW          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
(1) 015024 104401 015515          TYPE     ,MNEW         ;;PROMPT FOR NEW SWR
(1) 015030 005046          19$:  CLR      -(SP)      ;;CLEAR COUNTER
(1) 015032 005046          CLR      -(SP)         ;;THE NEW SWR
(1) 015034 105777 165104          7$:  TSTB    @STKS       ;;CHAR THERE?
(1) 015040 100375                   BPL      7$             ;;IF NOT TRY AGAIN
(1)
(1) 015042 117746 165100          MOVB    @STKB,-(SP)   ;;PICK UP CHAR
(1) 015046 042716 177600          BIC     #^C177,(SP)  ;;MAKE IT 7-BIT ASCII
(1)
(1)
(1)
(1) 015052 021627 000025          9$:  CMP      (SP),#25    ;;IS IT A CONTROL-U?
(1) 015056 001005                   BNE      10$            ;;BRANCH IF NOT
(1) 015060 104401 015472          TYPE     ,SCNTLU      ;;YES, ECHO CONTROL-U (^U)
```


(1)	015064	062706	000006	20\$:	ADD	#6,SP	::IGNORE PREVIOUS INPUT	
(1)	015070	000757			BR	19\$::LET'S TRY IT AGAIN	
(1)								
(1)								
(1)	015072	021627	000015	10\$:	CMP	(SP),#15	::IS IT A <CR>?	
(1)	015076	001022			BNE	16\$::BRANCH IF NO	
(1)	015100	005766	000004		TST	4(SP)	::YES, IS IT THE FIRST CHAR?	
(1)	015104	001403			BEQ	11\$::BRANCH IF YES	
(1)	015106	016677	000002	165024	MOV	2(SP),@SWR	::SAVE NEW SWR	
(1)	015114	062706	000006	11\$:	ADD	#6,SP	::CLEAR UP STACK	
(1)	015120	104401	002165	14\$:	TYPE	,\$CRLF	::ECHO <CR> AND <LF>	
(1)	015124	123727	002135	000001	CMPB	,\$INTAG,#1	::RE-ENABLE TTY KBD INTERRUPTS?	
(1)	015132	001003			BNE	15\$::BRANCH IF NOT	
(1)	015134	012777	000100	165002	MOV	#100,@\$TKS	::RE-ENABLE TTY KBD INTERRUPTS	
(1)	015142	000002		15\$:	RTI		::RETURN	
(1)	015144	004737	013072	16\$:	JSR	PC,\$TYPEC	::ECHO CHAR	
(1)	015150	021627	000060		CMP	(SP),#60	::CHAR < 0?	
(1)	015154	002420			BLT	18\$::BRANCH IF YES	
(1)	015156	021627	000067		CMP	(SP),#67	::CHAR > 7?	
(1)	015162	003015			BGT	18\$::BRANCH IF YES	
(1)	015164	042726	000060		BIC	#60,(SP)+	::STRIP-OFF ASCII	
(1)	015170	005766	000002		TST	2(SP)	::IS THIS THE FIRST CHAR	
(1)	015174	001403			BEQ	17\$::BRANCH IF YES	
(1)	015176	006316			ASL	(SP)	::NO, SHIFT PRESENT	
(1)	015200	006316			ASL	(SP)	::CHAR OVER TO MAKE	
(1)	015202	006316			ASL	(SP)	::ROOM FOR NEW ONE.	
(1)	015204	005266	000002	17\$:	INC	2(SP)	::KEEP COUNT OF CHAR	
(1)	015210	056616	177776		BIS	-2(SP),(SP)	::SET IN NEW CHAR	
(1)	015214	000707			BR	7\$::GET THE NEXT ONE	
(1)	015216	104401	002164	18\$:	TYPE	,\$QUES	::TYPE ?<CR><LF>	
(1)	015222	000720			BR	20\$::SIMULATE CONTROL-U	
(1)					.DSABL	LSB		
(1)								
(1)								
(2)								
(1)							::*****	
(1)							::*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY	
(1)							::*CALL:	
(1)							::*	
(1)						RDCHR	::INPUT A SINGLE CHARACTER FROM THE TTY	
(1)						RETURN HERE	::CHARACTER IS ON THE STACK	
(1)							::WITH PARITY BIT STRIPPED OFF	
(1)							::*	
(1)							::*	
(1)							::*	
(1)	015224	011646			\$RDCHR:	MOV	(SP),-(SP)	::PUSH DOWN THE PC
(1)	015226	016666	000004	000002		MOV	4(SP),2(SP)	::SAVE THE PS
(1)	015234	105777	164704	1\$:	TSTB	@\$TKS	::WAIT FOR	
(1)	015240	100375			BPL	1\$::A CHARACTER	
(1)	015242	117766	164700	000004	MOV	@\$TKB,4(SP)	::READ THE TTY	
(1)	015250	042766	177600	000004	BIC	,\$^C<177>,4(SP)	::GET RID OF JUNK IF ANY	
(1)	015256	026627	000004	000023	CMP	4(SP),#23	::IS IT A CONTROL-S?	
(1)	015264	001013			BNE	3\$::BRANCH IF NO	
(1)	015266	105777	164652	2\$:	TSTB	@\$TKS	::WAIT FOR A CHARACTER	
(1)	015272	100375			BPL	2\$::LOOP UNTIL ITS THERE	
(1)	015274	117746	164646		MOV	@\$TKB,-(SP)	::GET CHARACTER	
(1)	015300	042716	177600		BIC	,\$^C<177>,(SP)	::MAKE IT 7-BIT ASCII	
(1)	015304	022627	000021		CMP	(SP)+,#21	::IS IT A CONTROL-Q?	
(1)	015310	001366			BNE	2\$::IF NOT DISCARD IT	

```
(1) 015312 000750 BR 1$ ::YES, RESUME
(1) 015314 026627 000004 000021 3$: CMP 4(SP),#$XON ::IS IT A RANDOM XON? ;RAN001
(1) 015322 001744 BEQ 1$ ::BRANCH IF YES ;RAN001
(1) 015324 026627 000004 000140 CMP 4(SP),#140 ::IS IT UPPER CASE?
(1) 015332 002407 BLT 4$ ::BRANCH IF YES
(1) 015334 026627 000004 000175 CMP 4(SP),#175 ::IS IT A SPECIAL CHAR?
(1) 015342 003003 BGT 4$ ::BRANCH IF YES
(1) 015344 042766 000040 000004 BIC #40,4(SP) ::MAKE IT UPPER CASE
(1) 015352 000002 4$: RTI ::GO BACK TO USER
(2) ::*****
(1) ::*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
(1) ::*CALL:
(1) ::* RDLIN ::INPUT A STRING FROM THE TTY
(1) ::* RETURN HERE ::ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
(1) ::* ::TERMINATOR WILL BE A BYTE OF ALL 0'S
(1) 015354 010346 $RDLIN: MOV R3,-(SP) ::SAVE R3
(1) 015356 012703 015462 1$: MOV #$TTYIN,R3 ::GET ADDRESS
(1) 015362 022703 015472 2$: CMP #$TTYIN+8.,R3 ::BUFFER FULL?
(1) 015366 101405 BLOS 4$ ::BR IF YES
(1) 015370 104410 RDCHR ::GO READ ONE CHARACTER FROM THE TTY
(1) 015372 112613 MOV (SP)+,(R3) ::GET CHARACTER
(1) 015374 122713 000177 10$: CMPB #177,(R3) ::IS IT A RUBOUT
(1) 015400 001003 BNE 3$ ::SKIP IF NOT
(1) 015402 104401 002164 4$: TYPE $QUES ::TYPE A '?'
(1) 015406 000763 BR 1$ ::CLEAR THE BUFFER AND LOOP
(1) 015410 111337 015460 3$: MOV (R3),9$ ::ECHO THE CHARACTER
(1) 015414 104401 015460 TYPE 9$
(1) 015420 122723 000015 CMPB #15,(R3)+ ::CHECK FOR RETURN
(1) 015424 001356 BNE 2$ ::LOOP IF NOT RETURN
(1) 015426 105063 177777 CLRB -1(R3) ::CLEAR RETURN (THE 15)
(1) 015432 104401 002166 TYPE $LF ::TYPE A LINE FEED
(1) 015436 012603 MOV (SP)+,R3 ::RESTORE R3
(1) 015440 011646 MOV (SP),-(SP) ::ADJUST THE STACK AND PUT ADDRESS OF THE
(1) 015442 016666 000004 000002 MOV 4(SP),2(SP) :: FIRST ASCII CHARACTER ON IT
(1) 015450 012766 015462 000004 MOV #$TTYIN,4(SP)
(1) 015456 000002 RTI ::RETURN
(1) 015460 000 9$: .BYTE 0 ::STORAGE FOR ASCII CHAR. TO TYPE
(1) 015461 000 .BYTE 0 ::TERMINATOR
(1) 015462 000010 $TTYIN: .BLKB 8. ::RESERVE 8 BYTES FOR TTY INPUT
(1) 015472 052536 005015 000 $CNTLU: .ASCIZ /^U/<15><12> ::CONTROL 'U'
(1) 015477 136 006507 000012 $CNTLG: .ASCIZ /^G/<15><12> ::CONTROL 'G'
(1) 015504 005015 053523 020122 $MSWR: .ASCIZ <15><12>/SWR = /
(1) 015515 040 047040 053505 $MNEW: .ASCIZ / NEW = /
1448 .SBTTL POWER DOWN AND UP ROUTINES
(1)
(2) ::*****
(1) ::POWER DOWN ROUTINE
(1) 015526 012737 015672 000024 $PWRDN: MOV #$ILLUP,@#PWRVEC ::SET FOR FAST UP
(1) 015534 012737 000340 000026 MOV #340,@#PWRVEC+2 ::PRIO:7
(3) 015542 010046 MOV R0,-(SP) ::PUSH R0 ON STACK
(3) 015544 010146 MOV R1,-(SP) ::PUSH R1 ON STACK
(3) 015546 010246 MOV R2,-(SP) ::PUSH R2 ON STACK
(3) 015550 010346 MOV R3,-(SP) ::PUSH R3 ON STACK
(3) 015552 010446 MOV R4,-(SP) ::PUSH R4 ON STACK
(3) 015554 010546 MOV R5,-(SP) ::PUSH R5 ON STACK
```

```
(3) 015556 017746 164356      MOV    @SWR,-(SP)      ;;PUSH @SWR ON STACK
(1) 015562 010637 015676      MOV    SP,$SAVR6     ;;SAVE SP
(1) 015566 012737 015600 000024  MOV    #SPWRUP,@PWRVEC ;;SET UP VECTOR
(1) 015574 000000      HALT
(1) 015576 000776      BR     -2            ;;HANG UP
(1)
(2)
(1)
(1) 015600 012737 015672 000024  $PWRUP: MOV    #SILLUP,@PWRVEC ;;SET FOR FAST DOWN
(1) 015606 013706 015676      MOV    $SAVR6,SP     ;;GET SP
(1) 015612 005037 015676      CLR    $SAVR6        ;;WAIT LOOP FOR THE TTY
(1) 015616 005237 015676      1$:   INC    $SAVR6    ;;WAIT FOR THE INC
(1) 015622 001375      BNE    1$            ;;OF WORD
(3) 015624 012677 164310      MOV    (SP)+,@SWR    ;;POP STACK INTO @SWR
(3) 015630 012605      MOV    (SP)+,R5     ;;POP STACK INTO R5
(3) 015632 012604      MOV    (SP)+,R4     ;;POP STACK INTO R4
(3) 015634 012603      MOV    (SP)+,R3     ;;POP STACK INTO R3
(3) 015636 012602      MOV    (SP)+,R2     ;;POP STACK INTO R2
(3) 015640 012601      MOV    (SP)+,R1     ;;POP STACK INTO R1
(3) 015642 012600      MOV    (SP)+,R0     ;;POP STACK INTO R0
(1) 015644 012737 015526 000024  MOV    #SPWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
(1) 015652 012737 000340 000026  MOV    #340,@PWRVEC+2 ;;PRIO:7
(1) 015660 104401      TYPE
(1) 015662 015700      SPWRMG: .WORD    PWRMSG    ;;REPORT THE POWER FAILURE
(1) 015664 012716      MOV    (PC)+,(SP)   ;;POWER FAIL MESSAGE POINTER
(1) 015666 003134      SPWRAD: .WORD    START1   ;;RESTART AT START1
(1) 015670 000002      RTI
(1) 015672 000000      SILLUP: HALT
(1) 015674 000776      BR     -2            ;;THE POWER UP SEQUENCE WAS STARTED
(1) 015676 000000      $SAVR6: 0           ;;BEFORE THE POWER DOWN WAS COMPLETE
1449 015700 005015 042522 052123  PWRMSG: .ASCIZ <15><12>/RESTARTED FROM PWR FAIL/
1450 .EVEN
1451 .SBTTL TRAP DECODER
(1)
(2)
(1)
(1)
(1)
(1)
(1)
(1)
(1) 015732 010046      STRAP: MOV    R0,-(SP)    ;;SAVE R0
(1) 015734 016600 000002      MOV    2(SP),R0     ;;GET TRAP ADDRESS
(1) 015740 005740      TST    -(R0)        ;;BACKUP BY 2
(1) 015742 111000      MOVB   (R0),R0     ;;GET RIGHT BYTE OF TRAP
(1) 015744 006300      ASL    R0           ;;POSITION FOR INDEXING
(1) 015746 016000 015766      MOV    $TRPAD(R0),R0 ;;INDEX TO TABLE
(1) 015752 000200      RTS    R0           ;;GO TO ROUTINE
(1)
(1)
(1)
(1)
(1)
(1)
(1)
(1)
(1) 015754 011646      STRAP2: MOV    (SP)-,(SP) ;;MOVE THE PC DOWN
(1) 015756 016666 000004 000002      MOV    4(SP),2(SP)  ;;MOVE THE PSW DOWN
(1) 015764 000002      RTI                ;;RESTORE THE PSW
(1)
(3) .SBTTL TRAP TABLE
```

```

(3)
(3)
(3)
(3)
(3)
(3)
(3) 015766 015754
(3) 015770 012660
(3) 015772 013506
(3) 015774 013462
(3) 015776 013522
(3) 016000 013710
(1)
(3) 016002 015012
(1)
(3) 016004 014742
(3) 016006 015224
(3) 016010 015354

```

: *THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
 : *BY THE 'TRAP' INSTRUCTION.

ROUTINE	STARTING ADDRESS	ROUTINE NAME	DESCRIPTION
\$TRPAD	015766	WORD \$TRAP2	TTY TYPEOUT ROUTINE
\$TYPE	015770	CALL=TYPE	TYPE OCTAL NUMBER (WITH LEADING ZEROS)
\$TYPOC	015772	CALL=TYPOC	TYPE OCTAL NUMBER (NO LEADING ZEROS)
\$TYPOS	015774	CALL=TYPOS	TYPE OCTAL NUMBER (AS PER LAST CALL)
\$TYPON	015776	CALL=TYPON	TYPE DECIMAL NUMBER (WITH SIGN)
\$TYPDS	016000	CALL=TYPDS	
\$GTSWR	016002	CALL=GTSWR	GET SOFT-SWR SETTING
\$CKSWR	016004	CALL=CKSWR	TEST FOR CHANGE IN SOFT-SWR
\$RDCHR	016006	CALL=RDCHR	TTY TYPEIN CHARACTER ROUTINE
\$RDLIN	016010	CALL=RDLIN	TTY TYPEIN STRING ROUTINE

```

1452
1453
1454
1455 016012 041600 042126 042122
1456
1457 016054 042200 053122 030461
1458
1459 016101 122 043505 052040
1460 016120 042522 020107 042522
1461 016142 051111 020122 042522
1462 016155 101 051103 051040
1463 016170 046511 020122 042522
1464 016203 111 051123 051040
1465 016216 046111 042514 040507
1466 016251 103 044510 020120
1467
1468 016266 046111 042514 040507
1469 016316 047111 042524 051122
1470
1471 016343 115 046125 044524
1472 016375 126 041505 020124
1473 016416 051105 050122 020103
1474 016463 105 051122 041520
1475 016550 051105 050122 020103
1476 016615 105 051122 041520
1477
1478
1479 016666 002116 002432 002122
1480 016702 002116 002432 002122
1481 016722 002116 002432 002122
1482 016736 002116 002432 002120
1483
1484
1485
1486
1487
1488
1489

```

.SBTTL ASCII MESSAGES
 : *GPA TITLED: .ASCIZ <15><12>/CVDRDA DRV11J DIAG TEST PART 2/<15><12>
 TITLED: .ASCIZ <200>/CVDRDB DRV11J DIAG TEST PART 2/<200> :GPA
 : *GPA TLCABL: .ASCIZ <15><12>/DRV11J CABLE REQ'D/<15><12>
 TLCABL: .ASCIZ <200>/DRV11J CABLE REQ'D/<200> :GPA

ROUTINE	STARTING ADDRESS	ROUTINE NAME	DESCRIPTION
EM1	016101	ASCIZ /REG TIMEOUT ER/	
EM2	016120	ASCIZ 'REG READ/WRITE ER'	
EM3	016142	ASCIZ /IRR REG ER/	
EM4	016155	ASCIZ /ACR REG ER/	
EM5	016170	ASCIZ /IMR REG ER/	
EM6	016203	ASCIZ /ISR REG ER/	
EM7	016216	ASCIZ /ILLEGAL VECTOR MEM ADDR ER/	
EM10	016251	ASCIZ /CHIP STAT ER/	
EM11	016266	ASCIZ /ILLEGAL INTERRUPT RECEIVED/	:GPA
EM12	016316	ASCIZ /INTERRUPT TEST ERROR/	
EM13	016343	ASCIZ /MULTIPLE INTERRUPTS RECEIVED/	:GPA
EM14	016375	ASCIZ /VECT ADDR MEM ER/	
DH1	016416	ASCIZ /ERRPC TSTNUM BUSADR EXPCT RCVD/	
DH2	016463	ASCIZ /ERRPC TSTNUM BUSADR VAM ADDR EXPCT RCVD/	
DH3	016550	ASCIZ /ERRPC TSTNUM BUSADR VAM ADDR/	
DH4	016615	ASCIZ /ERRPC TSTNUM TESTPC BUSADR VAM ADDR/	
DT1	016666	ASCIZ \$ERRPC, TSTNUM, SBDADR, \$GDDAT, SBDAT, 0	
DT2	016702	ASCIZ \$ERRPC, TSTNUM, SBDADR, VECVAL, VECLOC, \$GDDAT, SBDAT, 0	
DT3	016722	ASCIZ \$ERRPC, TSTNUM, SBDADR, VECVAL, VECLOC, 0	
DT4	016736	ASCIZ \$ERRPC, TSTNUM, SBDADR, SBDADR, VECVAL, VECLOC, 0	

```

: *****
: 'DBUF' IS THE STORAGE AREA FOR SYSMAC LOCATIONS 0-202
: PRESERVED IN ORDER TO TEST DRV11J VECTORING TO
: VECTOR SPACE 0-200.
: *****

```

CVDRDB DRV1IJ DJAG TST PRT2
CVDRDB.P11 10-AUG-81 10:52

MACY11 306(1063) 10-AUG-81 11:00 ^{H 5} PAGE 2-36
ASCII MESSAGES

SECT 0

1490 016754 000102
1491
1492
1493
1494
1495
1496 017160 000100
1497 017360

DBUF: .BLKW 66. ;1ST ADRS OF DATA STORAGE AREA

::*****
:VECTOR BUFFER USED FOR VECTOR UNIQUENESS TEST
:FOR 64 INTERRUPT VECTORS.
:*****
VBUF: .BLKW 64.
ENDBUF:

1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515 017360 005227 177777
1516 017364 001002
1517 017366 004737 000400
1518 017372 005727
1519 017374 000000
1520 017376 000207
1521
1522
1523
1524 000400 005037 017374
1525 000404 013746 000004
1526 000410 012737 000504 000004
1527 000416 012700 160010
1528 000422 005720
1529 000424 000240
1530 000426 020027 174000
1531 000432 103773
1532 000434 010037 017374
1533 000440 012700 000040
1534 000444 040037 000006
1535 000450 040037 000016
1536 000454 040037 000022
1537 000460 040037 000032
1538 000464 040037 000036
1539 000470 012737 170000 000140
1540 000476 012637 000004
1541 000502 000207
1542
1543 000504 012716 000512
1544 000510 000002
1545 000512 012637 000004
1546 000516 012700 000402
1547 000522 013701 000376
1548 000526 010602
1549 000530 012704 000570
1550 000534 014446
1551 000536 020427 000546
1552 000542 101374
1553 000544 010607

.SBTTL FALCON (KXT-11) UPGRADE ROUTINES. ::GPA
: THE FOLLOWING ROUTINES HAVE BEEN ADDED TO ALLOW DIAGNOSTIC(S)
: TO RUN ON A FALCON (KXT-11) BASED SYSTEM.
: TO DETERMINE WHETHER WE'RE A FALCON OR NOT, WE'LL SIZE THE 1ST 3/4 OF
: THE I/O PAGE (28K TO 31K). FALCON HAS 2KW LOCAL RAM AT 28K(+4) TO 30K
: AND A MACRO-ODT AT 30K TO 31K. CONSEQUENTLY, ALL I/O DEVICES MUST
: BE PLACED BETWEEN 174000 AND 177776. ADDITIONALLY, WE'LL STRAP THE
: EMT AND TRAP SERVICE LEVEL TO PRI6, AND SET THE HALT VECTOR SO THAT
: WE CAN STOP THE SUCKER !!
: TO MINIMIZE THE IMPACT OF THESE CHANGES ON FINAL PROGRAM SIZE, THE
: BULK OF THIS CODE IS PLACED IN THE FLOATING VECTOR SPACE (400-776).
: IF THE CPU AT HAND IS A FALCON (KXT11), IT STAYS THERE (NO HARM DONE).
: OTHERWISE, THE AREA IS RESTORED TO ITS ORIGINAL 'TRAP-CATCHER' STATE.
FALCON: INC #1 ; ONCE-ONLY !!! ::GPA
: BNE 1\$; ::GPA
: CALL KXTCHK ; EXECUTE FALCON CHECK ::GPA
1\$: TST (PC)+ ; TEST FALCON FLAG... ::GPA
KXTFLAG: 0 ;...NZ = FALCON... ::GPA
: RETURN ;...AND RETURN TO CALLER... ::GPA
: \$SVPC= ; ::GPA
: = 400 ; RESTORE FROM 374:376 AT END ::GPA
KXTCHK: CLR KXTFLAG ; ASSUME NOT FALCON. ::GPA
: MOV @#4,-(SP) ; SAVE ERROR VECTOR. ::GPA
: MOV #2\$,@#4 ; SET A TRAP CATCHER. ::GPA
: MOV #160010,R0 ; FALCON RAM STARTS AT 28K+4. ::GPA
1\$: TST (R0)+ ;
: 240 ;
: CMP R0,#174000 ; SIZE TO 31K. ::GPA
: BLO 1\$;
: MOV R0,KXTFLAG ; MUST BE FALCON, SET THE FLAG ::GPA
: MOV #40,R0 ; GET PRI6 BIT... ::GPA
: BIC R0,@#6 ;...AND LOWER BUS-ERROR... ::GPA
: BIC R0,@#16 ;...BPT... ::GPA
: BIC R0,@#22 ;...IOT... ::GPA
: BIC R0,@#32 ;...EMT... ::GPA
: BIC R0,@#36 ;...AND TRAP SERVICE TO PRI6 ::GPA
: MOV #170000,@#140 ; ENABLE 'BREAK' HALT. ::GPA
: MOV (SP)+,@#4 ; RESTORE ERROR VECTOR... ::GPA
: RETURN ;...AND RETURN ::GPA
2\$: MOV #3\$,(SP) ; TRAP -- NOT A FALCON... ::GPA
: RTI ;...CONTINUE. ::GPA
3\$: MOV (SP)+,@#4 ; RESET ERROR VECTOR ::GPA
: MOV #402,R0 ; SET-UP TO RESTORE FLOATING... ::GPA
: MOV @#376,R1 ;...VECTORS (400 - 776). ::GPA
: MOV SP,R2 ; SAVE STACK POINTER IN R2 ::GPA
: MOV #6\$,R4 ;
4\$: MOV -(R4),-(SP) ; PUSH THE RESTORE CODE... ::GPA
: CMP R4,#5\$;...ONTO THE STACK. ::GPA
: BHI 4\$; ::GPA
: MOV SP,PC ; AND EXECUTE IT. ::GPA


```
1555  
1556  
1557  
1558 000546 010060 177776  
1559 000552 010110  
1560 000554 022020  
1561 000556 020027 000776  
1562 000562 101771  
1563 000564 010206  
1564 000566 000207  
1565 000570  
1566  
1567  
1568  
1569  
1570  
1571 000104  
1575  
1576 017400  
1577 017400  
1578 000001
```

... THIS CODE IS RELOCATED TO AND EXECUTED IN THE STACK AREA.
5\$: MOV R0,-2(R0) : RESTORE +2... : :GPA
MOV R1,(R0) :...HALT (OR IOT). : :GPA
CMP (R0)+,(R0)+ : :GPA
CMP R0,#776 : :GPA
BLOS 5\$: LOOP 'TIL DONE : :GPA
MOV R2,SP : THEN RESTORE SP... : :GPA
RETURN :...AND RETURN TO CALLER : :GPA
6\$:
... IF FALCON, THIS AREA IS FREE FOR ANY PROGRAM UNIQUE
... CHANGES OR DATA STRUCTURES.
... IF USED, YOU'D BETTER PROTECT IT !!!
\$FREE= <1000-.>/2 : FREE WORDS LEFT. : :GPA
LASTAD= .=SSVPC : :GPA
 : :GPA
.END

ABASE = 164160	AVECT1= 000000	DH3 016550	INT13 012322	INT61 012622
ACDW1 = 000000	AVECT2= 000000	DH4 016615	INT14 012326	INT62 012626
ACDW2 = 000000	BDSAV 002464	DIR = 000400	INT15 012332	INT63 012632
ACPUOP= 000000	BGCHP3 012636	DISPLA 002142	INT16 012336	INT7 012272
ACRLOC 002450	BIT0 = 000001	DISPRE 000174	INT17 012342	INT8 012276
ADDW0 = 000000	BIT00 = 000001	DMAP 002434	INT18 012346	INT9 012302
ADDW1 = 000000	BIT01 = 000002	DRCSA 002412	INT19 012352	JOTVEC= 000020
ADDW10= 000000	BIT02 = 000004	DRCSB 002416	INT2 012246	IRRLOC 002446
ADDW11= 000000	BIT03 = 000010	DRCS 002422	INT20 012356	ISRLOC 002444
ADDW12= 000000	BIT04 = 000020	DRCS 002422	INT21 012362	KXTCHK 000400
ADDW13= 000000	BIT05 = 000040	DRDBA 002414	INT22 012366	KXTFLA C17374
ADDW14= 000000	BIT06 = 000100	DRDBB 002420	INT23 012372	LASTAD= 017400
ADDW15= 000000	BIT07 = 000200	DRDBC 002424	INT24 012376	LF = 000012
ADDW2 = 000000	BIT08 = 000400	DRDBD 002430	INT25 012402	LMD04 = 000200
ADDW3 = 000000	BIT09 = 001000	DSWR = 177570	INT26 012406	LMD57 = 000240
ADDW4 = 000000	BIT1 = 000002	DT1 016666	INT27 012412	LVLCNT 002466
ADDW5 = 000000	BIT10 = 002000	DT2 016702	INT28 012416	LVLSAV 002474
ADDW6 = 000000	BIT11 = 004000	DT3 016722	INT29 012422	MACR = 000254
ADDW7 = 000000	BIT12 = 010000	DT4 016736	INT3 012252	MIMR = 000244
ADDW8 = 000000	BIT13 = 020000	EDCHP3 012656	INT30 012426	MIRR = 000250
ADDW9 = 000000	BIT14 = 040000	EMTVEC= 000030	INT31 012432	MISR = 000240
ADEVCT= 000000	BIT15 = 100000	EM1 016101	INT32 012436	NEXPAS 003200
ADEVN = 000001	BIT2 = 000004	EM10 016251	INT33 012442	NEXPA1 003204
AENV = 000000	BIT3 = 000010	EM11 016266	INT34 012446	NEXPA2 003250
AENVN = 000000	BIT4 = 000020	EM12 016316	INT35 012452	NXDEL 010632
AFATAL= 000000	BIT5 = 000040	EM13 016343	INT36 012456	NXDE.1 010636
AMADR1= 000000	BIT6 = 000100	EM14 016375	INT37 012462	PACR = 000300
AMADR2= 000000	BIT7 = 000200	EM2 016120	INT38 012466	PIMR 000260
AMADR3= 000000	BIT8 = 000400	EM3 016142	INT39 012472	PIRQ = 177772
AMADR4= 000000	BIT9 = 001000	EM4 016155	INT4 012256	PIRQVE= 000240
AMAMS1= 000000	BPTVEC= 000014	EM5 016170	INT40 012476	PRO = 000000
AMAMS2= 000000	BYCNT 002470	EM6 016203	INT41 012502	PR1 = 000040
AMAMS3= 000000	BYNUM 002472	EM7 016216	INT42 012506	PR2 = 000100
AMAMS4= 000000	CAT200 012024	ENDBUF 017360	INT43 012512	PR3 = 000140
AMSGAD= 000000	CHPISR= 000140	ENDTRP 011636	INT44 012516	PR4 = 000200
AMSGLG= 000000	CIMR = 000040	END200 012106	INT45 012522	PR5 = 000240
AMSGTY= 000000	CIMR = 000020	ERRVEC= 000004	INT46 012526	PR6 = 000300
AMTYP1= 000000	CIRR = 000100	FALCON 017360	INT47 012532	PR7 = 000340
AMTYP2= 000000	CISR = 000160	FRMBUF 011374	INT48 012536	PS = 177776
AMTYP3= 000000	CKSWR = 104407	GRPCNT 002462	INT49 012542	PSW = 177776
AMTYP4= 000000	CLRBF 011334	GTSWR = 104406	INT5 012262	PVMA = 000340
APASS = 000000	CLRCR 011014	HT = 000011	INT50 012546	PWRMSG 015700
APRIOR= 000000	CLRIRR 011074	IE = 001000	INT51 012552	PWRVEC= 000024
APTCSU= 000040	CR = 000015	IRRLOC 002442	INT52 012556	RDCHR = 104410
APTENV= 000001	CRIF = 000200	INTBY4 011700	INT53 012562	RDLIN = 104411
APTSIZ= 000200	CSIMR = 000050	INTFLG 002436	INT54 012566	RDY = 100000
APTSPO= 000100	CSIMR= 000030	INTSR1 011644	INT55 012572	RESTRP 011432
APTVEC 011614	CSIRR = 000110	INTSR3 012124	INT56 012576	RESVEC= 000010
APT200 012066	CSISR = 000170	INTO 012236	INT57 012602	RES200 011762
ASWREG= 000000	DBUF 016754	INT1 012242	INT58 012606	R6 = 000006
ATESTN= 000000	DISP = 177570	INT10 012306	INT59 012612	R7 = 000007
AUNIT = 000000	DH1 016416	INT11 012312	INT6 012266	SETVEC 012210
AUSWR = 000000	DH2 016463	INT12 012316	INT60 012616	SIMR = 000060

SIRR = 000120	TOBUF 011354	SCPUOP 002216	SLPADR 002106	\$STUP = 177777
SSIMR = 000070	TPVEC = 000064	SCRLF 002105	SLPERR 002110	\$SVLAD 014670
SSIRR = 000130	TRAPVE= 000034	SDBLK 014124	SMADR1 002222	\$SVPC = 017400
STACK = 001100	TRPALL 011752	SDEVCT 002200	SMADR2 002226	\$SWR = 165400
START 002476	TRPCAT 011524	SDEVM 002246	SMADR3 002232	\$SWREG 002212
START1 003134	TRPOUT 011734	SDOAGN 010770	SMADR4 002236	\$SWRMK= 000000
STKLMT= 177774	TRP200 012170	\$DTBL 014114	SMAIL 002170	\$TESTN 002174
STRVEC 011300	TRTVEC= 000014	SENDAD 010760	SMAMS1 002220	\$TIMES 002160
SWR 002140	TSTNUM 002432	SENDCT 010726	SMAMS2 002224	\$TKB 002146
SWRCK 014310	TST1 003254	SENDMG 010777	SMAMS3 002230	\$IKS 002144
SWREG 000176	TST2 004122	SENULL 010774	SMAMS4 002234	\$TN = 000007
SWRSAV 002460	TST3 004622	SENV 002210	SHBADR 002002	\$TPB 002152
SWO = 000001	TST4 005536	SEVM 002211	SMFLG 013456	\$TPFLG 002157
SW00 = 000001	TST5 006530	SEOP 010672	SMNEW 015515	\$TPS 002150
SW01 = 000002	TST6 007476	SEOPCT 010720	SMSGAD 002204	\$TRAP 015732
SW02 = 000004	TYPDS = 104405	SERFLG 002103	SMSGLG 002206	\$TRAP2 015754
SW03 = 000010	TYPE = 104401	SERMAX 002115	SMSGTY 002170	\$TRP = 000012
SW04 = 000020	TYPDC = 104402	SERROR 014134	SMSWR 015504	\$TRPAD 015766
SW05 = 000040	TYPON = 104404	SERRPC 002116	SMTYP1 002221	\$TSTM 002004
SW06 = 000100	TYPOS = 104403	SERRTB 002252	SMTYP2 002225	\$TSTM 002102
SW07 = 000200	VBUF 017160	SERTY 014326	SMTYP3 002231	\$TTYIN 015462
SW08 = 000400	VECFIL 011132	SERTTL 002112	SMTYP4 002235	\$TYPDS 013710
SW09 = 001000	VECLOC 002452	SESCAP 002162	SMXCNT 014740	\$TYPE 012660
SW1 = 000002	VECPAT 002454	SETABL 002210	SNULL 002154	\$TYPEC 013072
SW10 = 002000	VECVAL 002456	SETEND 002252	\$NWTST= 000001	\$TYPEX 013112
SW11 = 004000	XXDP 002440	\$FATAL 002172	\$OCNT 013704	\$TYPOC 013506
SW12 = 010000	\$APTHD 002000	\$FFLG 013460	\$OMODE 013706	\$TYPON 013522
SW13 = 020000	\$ATYC 013240	\$FILLC 002156	\$OVER 014724	\$TYPOS 013462
SW14 = 040000	\$ATY1 013214	\$FILLS 002155	\$PASS 002176	\$UNIT 002202
SW15 = 100000	\$ATY3 013222	\$FREE = 000104	\$PASTM 002006	\$UNITM 002010
SW2 = 000004	\$ATY4 013232	\$GDADR 002120	\$PWAD 015666	\$USWR 002214
SW3 = 000010	\$AUTOB 002134	\$GDDAT 002124	\$PWADN 015526	\$VECT1 002240
SW4 = 000020	\$BASE 002244	\$GET42 010750	\$PWARMG 015662	\$VECT2 002242
SW5 = 000040	\$BDADR 002122	\$GTSWR 015012	\$PWUP 015600	\$XOFF = 000023
SW6 = 000100	\$BDDAT 002126	\$HD = 000003	\$QUES 002164	\$XON = 000021
SW7 = 000200	\$CDW1 002250	\$HIBTS 002000	\$RDCHR 015224	\$XTSTR 014474
SW8 = 000400	\$CHARC 013210	\$ICNT 002104	\$RDLIN 015354	\$GET4= 000000
SW9 = 001000	\$CKSWR 014742	\$ILLUP 015672	\$RDSZ = 000010	\$OFILL 013705
TBITVE= 000014	\$CMTAG 002100	\$INTAG 002135	\$RYNAD 010772	. = 017400
TITLED 016012	\$CM3 = 000000	\$ITEMB 002114	\$SAVR6 015676	.\$X = 002000
TKVEC = 000060	\$CNTLG 015477	\$L 002166	\$SCOPE 014462	
TI CABL 016054	\$CNTLU 015472	\$LFLG 013457	\$SETUP= 000117	

. ABS. 017400 000 CON RW ABS LCL I

ERRORS DETECTED: 0

CVDRDB, CVDRDB=CVDRDB
RUN-TIME: 19 7 .4 SECONDS
RUN-TIME RATIO: 76/27=2.8
CORE USED. 25K (49 PAGES)