

DZV11

DZV11 DIAG PRT 2  
CVDZBBO

AH-A939B-MC  
FICHE 1 OF 1

JUL 1982  
COPYRIGHT © 77-82  
MADE IN USA



.REM 2

IDENTIFICATION

PRODUCT CODE: AC-A9388-MC  
PRODUCT NAME: CVDZBB0 DZV11 DIAG PRT2  
DATE RELEASED: 17-FEB-82  
MAINTAINER: DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1977, 1982 DIGITAL EQUIPMENT CORPORATION

1. ABSTRACT

THE FUNCTION OF THE DZV11 DIAGNOSTICS IS TO VERIFY THE OPTION OPERATES ACCORDING TO SPECIFICATIONS. THE DIAGNOSTICS ALSO VERIFY THAT THE DZV11 OPERATES IN ITS ENVIRONMENT SUCH AS THE SYSTEM IN WHICH IT IS INSTALLED.

PARAMETERS MAY BE SUPPLIED TO THE PROGRAM BY EITHER 'AUTO SIZING' OR INPUT FROM THE USER ON THE CONSOLE BY HAVING SW00=1 AT START TIME. AUTO SIZING WILL BE DONE ONLY THE FIRST TIME THE PROGRAM IS STARTED AND SW07=0 AND SW00=0 AND SW03=0. THE AUTOSIZER IS DESIGNED TO DETECT DZV11 DEVICE ADDRESSES AND VECTORS ONLY. ALL REMAINING PARAMETERS WILL DEFAULT TO CERTAIN VALUES (SEE SEC.8.5). CONSOLE INPUT MAY BE CONTROLLED AT ANY START TIME THROUGH THE USE OF SW00, SW03, SW04, AND SW06 (SEE SEC. 4.1.1 FOR A DETAILED DESCRIPTION OF THESE SWITCHES).

CURRENTLY THERE ARE THREE STANDALONE DIAGNOSTICS (DVDZA, DVDZB, AND DVDZC) ONE SYSTEM MODULE FOR DEC X/11 (DZBA), AND AN OVERLAY FOR ITEP (DVDZD).

DVDZA TOGETHER WITH DVDZB WILL TEST ALL LOGICAL FUNCTIONS OF THE DZV11 INTERFACE MODULE.

DVDZC IS DESIGNED AS A NON-CHAINABLE STANDALONE DIAGNOSTIC PROVIDING THE OPERATOR WITH DIRECT CONTROL OVER THE TESTING OF ALL DZV11 EIA CABLES.

```

*****
*
* NOTE: THIS DIAGNOSTIC HAS BEEN MODIFIED TO RUN IN KXT11 (SBC 11/21)
* BASED SYSTEMS. THE PROGRAM WILL AUTOMATICALLY ADJUST ITSELF TO RUN
* IN THE APPROPRIATE ENVIRONMENT AS FOLLOWS:
*
*
*           LSI-11, 11/2, AND 11/23           SBC 11/21
*           -----           -----
* * CSR RANGE:           160010 TO 163770           174000 TO 177770
* * VECTOR RANGE:           300 TO 770           300 TO 370
* * AUTO-SIZING FOR...
* * ...CSR AND VECTOR:     ENABLED           DISABLED
*
*
*****

```

2. REQUIREMENTS

2.1 EQUIPMENT

AN LSI11 CPU WITH MINIMUM 4K OF MEMORY.  
ASR 33 (OR EQUIVALENT FOR CONSOLE)  
DZV11 INTERFACE MODULE  
H329 STAGGERED TURNAROUND CONNECTOR.  
H325 CABLE TURNAROUND CONNECTOR.

NOTE: A STAGGERED TURNAROUND CONNECTOR IS NEEDED IN ORDER TO TEST THE PARITY LOGIC.

2.2 STORAGE

PROGRAM WILL USE ALL 4K OF MEMORY EXCEPT WHERE ABL AND BOOTSTRAP LOADER RESIDE. LOCATION 1500 THRU 1740 ARE ESPECIALLY TO BE NOTED AND TO BE UNTOUCHED BY OPERATOR AFTER PARAMETERS HAVE BEEN INPUT FROM CONSOLE (SW00=1); OR AFTER THE 'AUTO SIZING' HAS BEEN DONE. THESE LOCATIONS MAY BE CHANGED IF THE USER UNDERSTANDS THEIR MEANING AND DIFFERENT PARAMETERS ARE REQUIRED.

3. LOADING PROCEEDURE

3.1 METHOD

ALL PROGRAMS ARE IN ABSOLUTE FORMAT AND ARE LOADED USING THE ABSOLUTE LOADER. NOTE: IF THE DIAGNOSTICS ARE ON A MEDIA SUCH AS DISK ,MAGTAPE,DECTAPE, OR CASSETTE; FOLLOW INSTRUCTIONS FOR THE MONITOR WHICH HAS BEEN PROVIDED ON THAT SPECIFIC MEDIA.

ABSOLUTE LOADER STARTING ADDRESS \*500

MEMORY \* SIZE

4K	17
8K	37
12K	57
16K	77
20K	117
24K	137
28K	157

3.1.1 STARTING THE PROCESSOR AT THE ABSOLUTE LOADER STARTING ADDRESS WILL LOAD THE DIAGNOSTIC INTO MEMORY.

4. STARTING PROCEDURE

- A. SET SWR TO ZERO FOR 'AUTO SIZING' OR SET SW00=1 FOR USER PARAMETER INPUT FROM CONSOLE TERMINAL. NOTE: LOC. 000176 IS USED AS A SOFTWARE SWITCH REGISTER IN ALL OF THE DZV11 DIAGNOSTICS. (SEE SEC. 4.1 ) ON THE FIRST STARTUP OF THE DIAGNOSTIC IF SW07=1 AND SW00=0 THE PROGRAM WILL ASSUME THAT THE STATUS TABLE HAS BEEN ALREADY BUILT FROM A PREVIOUS DZV11 DIAGNOSTIC RUN. NOTE: ANY DZV11 DIAGNOSTIC WILL OVERLAY THE STATUS TABLE WHEN LOADED TO PRESERVE ITS CONTENTS AND THUS WILL NOT ALTER A PREVIOUSLY BUILT TABLE.
- B. START THE DIAGNOSTIC AT LOC. 200(8). THE PROGRAM WILL TYPE MAINDEC AND PROGRAM NAMES (IF THIS WAS THE FIRST START UP OF THE PROGRAM) AND ALSO THE FOLLOWING: (ON THE FIRST PROGRAM RUN OR IF PARAMETERS WERE CHANGED)

```
'MAP OF DZV11 STATUS'  
1500 160100  
1502 000300  
1504 000017  
1506 017470  
1510 000000
```

THE ABOVE IS ONLY AN EXAMPLE! THIS WOULD INDICATE THE STATUS TABLE STARTING AT ADD. 1500 IN THE PROGRAM. THE STATUS TABLE MUST BE VERIFIED BY THE USER IF AUTO SIZING IS DONE. FOR INFORMATION OF STATUS TABLE SEE SECTION 8.4 FOR HELP.

THE PROGRAM WILL TYPE 'RUNNING' AND PROCEED TO RUN THE DIAGNOSTIC.

4.1 CONTROL SWITCH SETTINGS

NOTE: THIS PROGRAM UTILIZES A SOFTWARE SWITCH REGISTER WHICH MAY BE MODIFIED BY CHANGING LOC. 176 OR BY TYPING CONTROL 'G' (^G) ON THE CONSOLE TERMINAL WHILE THE PROGRAM IS RUNNING.

```
SW 15 SET: HALT ON ERROR  
SW 14 SET: LOOP ON CURRENT TEST  
SW 13 SET: INHIBIT ERROR PRINT OUT  
SW 12 SET: INHIBIT **ALL** TYPE OUT/BELL ON ERROR.  
SW 11 SET: INHIBIT ITERATIONS. (QUICK PASS)  
SW 10 SET: ESCAPE TO NEXT TEST  
SW 09 SET: LOOP WITH CURRENT DATA  
SW 08 SET: CATCH ERROR AND LOOP ON IT  
SW 07 SET: NO AUTO SIZE. IF 1ST START OF PROGRAM AFTER LOADING AND  
IF SW00=0 THEN THE PROGRAM WILL ASSUME THAT THE STATUS MAP  
HAS BEEN BUILT FROM A PREVIOUS DZV11 DIAGNOSTIC RUN.  
  
SW 06 SET: RESELECT DZV11'S DESIRED ACTIVE  
SW 05 SET: RESERVED  
SW 04 SET: SELECT DELAY PARAMETER (SEE SEC. 4.1.1)  
SW 03 SET: EXTRA PARAMETER INPUT (SEE SEC. 4.1.1)  
SW 02 SET: LOCK ON SELECTED TEST  
SW 01 SET: RESTART PROGRAM AT SELECTED TEST  
SW 00 SET: GET USERS PARAMETERS FROM CONSOLE
```

4.1.1 SWITCH REGISTER CONTROL OF PARAMETER INPUT FROM CONSOLE

SW 00 GET USERS PARAMETERS FROM CONSOLE. SETTING THIS SWITCH AT START UP TIME ALLOWS THE USER TO INPUT AT THE CONSOLE TERMINAL THE FOLLOWING PARAMETERS: BASE DEVICE ADDRESS, BASE VECTOR ADDRESS, MODE OF OPERATION (EXTERNAL, INTERNAL, OR STAGGERED), AND THE NUMBER OF DZV11'S THAT ARE RUNNING. USING THIS SWITCH ALONE WILL DEFAULT THE FOLLOWING PARAMETERS: ALL 4 LINES ARE SET TO BE TESTED ON EACH DZV11, THE DEFAULT BAUD RATE IS SET AT 19.2 KBAUD AND THE CHARACTER LENGTH FOR THE MAJORITY OF TESTING IS SET AT EIGHT BITS PER CHARACTER WITH TWO STOP BITS.

SW 03 EXTRA PARAMETER INPUT. SETTING THIS SWITCH AT START UP TIME PROVIDES THE USER WITH THE ABILITY TO SET THE LINES ACTIVE FOR TESTING AND TO SET THE DEFAULT BAUD RATE USED FOR THE MAJORITY OF THE DIAGNOSTIC TESTS. THE DELAY PARAMETER IS AUTOMATICALLY ADJUSTED TO THE BAUD RATE GIVEN BY THE USER.

SW 04 SELECT DELAY PARAMETER. THE DELAY PARAMETER THIS SWITCH CONTROLS DETERMINES THE LENGTH OF TIME THE PROGRAM STALLS WAITING FOR A CHARACTER TO BE COMPLETELY TRANSMITTED OR RECEIVED. THIS DELAY COUNT IS AUTOMATICALLY SET TO PROVIDE ENOUGH DELAY TIME FOR THE DEFAULT BAUD RATE SPECIFIED WHEN RUNNING THE PROGRAM ON AN LS111 WITH MOS MEMORY. WHEN RUNNING THIS PROGRAM ON A PROCESSOR WITH A FASTER MEMORY SPEED THIS DELAY COUNT SHOULD BE ADJUSTED PROPORTIONATELY HIGHER THAN THE FOLLOWING DEFAULTED VALUES:

2450	:TIME FOR	50 BAUD
1560	:TIME FOR	75 BAUD
1120	:TIME FOR	110 BAUD
0750	:TIME FOR	134 BAUD
0660	:TIME FOR	150 BAUD
0330	:TIME FOR	300 BAUD
0150	:TIME FOR	600 BAUD
0060	:TIME FOR	1200 BAUD
0040	:TIME FOR	1800 BAUD
0030	:TIME FOR	2000 BAUD
0020	:TIME FOR	2400 BAUD
0010	:TIME FOR	3600 BAUD
0001	:TIME FOR	4800 BAUD
0001	:TIME FOR	7200 BAUD
0001	:TIME FOR	9600 BAUD
0001	:TIME FOR	19.2 KBAUD

#### 4.1.2 SWITCH REGISTER RESTRICTIONS

- SW 06 RESELECT DZV11'S DESIRED ACTIVE. A MESSAGE IS TYPED OUT ON THE CONSOLE TERMINAL ASKING THE OPERATOR TO TYPE A BIT MAP OF THE DZV'S DESIRED ACTIVE. USING THIS SWITCH ALLOWS LOCATION DZVACTV TO BE ALTERED (SEE SEC. 8.3 FOR A DESCRIPTION OF THIS LOCATION).  
EXAMPLE:  
IF THE DEVICES CORRESPONDING TO THE DZV11'S NUMBERED ZERO, TWO, AND FOUR IN THE DZV11 STATUS MAP (LOC. 1500 THROUGH 1740) ARE TO BE TESTED, TYPE IN: 25  
THIS WILL SET BITS ZERO, TWO, AND FOUR IN LOCATION DZVACTV. ALL REMAINING DEVICES IN THE STATUS MAP WILL THEN NOT BE TESTED.
- SW 01 RESTART PROGRAM AT SELECTED TEST IT IS STRONGLY SUGGESTED THAT AT LEAST ONE PASS HAS BEEN MADE BEFORE TRYING TO SELECT A TEST THAT IS NOT IN THE ORDER OF SEQUENCE THE REASON BEING IS THAT THE PROGRAM HAS TO CLEAR AREAS AND SET UP PARAMETERS.  
NOTE: IF RUNNING MULTIPLE DZV11'S; THE DZV11 YOU DESIRE TO BE UNDER TEST MUST BE SELECTED BY THE USE OF SW06 BEFORE LOCKING ON THE TEST. IN OTHER WORDS; EACH TIME THE PROGRAM IS STARTED; THE FIRST DZV11 WILL BE SELECTED TO BE UNDER TEST UNLESS SW06 IS USED TO SELECT ONLY ONE.
- SW 09 LOOP ON CURRENT DATA: THIS SWITCH WILL ONLY WORK IF CALL 'SCOPI' IS IN THAT TEST. THE REASON BEING THAT MOST TESTS DEAL WITH BLOCKS OF DIFFERENT DATA TO BE SENT OR RECEIVED ALL AT ONCE THUS IN BLOCK DATA, ONE PATTERN CAN'T BE SINGLED OUT.  
THIS SWITCH IS DESIGNED TO PROVIDE AN AID FOR A TRAINED TROUBLESHOOTER TO SAMPLE VARIOUS SIGNALS ON THE MODULE AND IS NOT MEANT TO BE USED AS A GENERAL USER CONTROL SWITCH.
- SW 04 SELECT DELAY PARAMETER: THIS SWITCH SHOULD BE USED WITH CARE AS TOO SHORT A DELAY WILL CAUSE VALID TESTS TO FAIL.  
(SEE SEC. 4.1.1)

#### 4.1.3 SWITCH REGISTER PRIORITIES

##### ERROR SWITCHES

1. SW 12 DELETE PRINT OUT/BELL ON ERROR.
2. SW 13 DELETE ERROR PRINTOUT.
3. SW 15 HALT ON THE ERROR.
4. SW 08 GO TO BEGINNING OF THE TEST(ON ERROR).
5. SW 10 GOTO NEXT TEST(ON ERROR).

##### SCOPE SWITCHES

1. SW 09 (IF ENABLED BY 'SCOP1'). IF AN '\*' IS PRINTED IN FRONT OF THE TEST NO. ON AN ERROR REPORT (EX. \*TEST NO. 10) SW09 IS INCORPORATED IN THAT TEST AND THEREFORE SW09 IS \*USUALLY\* THE BEST SWITCH FOR THE SCOPE LOOP (SW14=0, SW10=0, SW09=1, SW08=0) IF THE PROGRAM USER IS TECHNICALLY TRAINED TO ELECTRONICALLY ISOLATE SIGNAL PROBLEMS ON THE DZV11 MODULE. IF SW09 IS NOT ENABLED; AND THERE IS A \*HARD\* ERROR (CONSTANT); SW08 IS BEST.
2. FOR INTERMITTENT ERRORS EITHER START THE PROGRAM WITH SW01 AND SW02 SET WHICH WILL ALLOW THE USER TO LOCK ON A SELECTED TEST, OR ELSE SET SW14 AS AN ERROR IS BEING TYPED OUT ON THE TERMINAL. SW14 WILL CONTINUE TO LOOP ON THAT TEST REGARDLESS OF WHETHER AN ERROR OCCURS.
3. SW 14 LOOP ON CURRENT TEST.

#### 4.2 STARTING ADDRESS

SA 200 - THE STARTING ADDRESS FOR ANY DZV11 DIAGNOSTIC IS LOC. 200

NOTE: IF ADDRESS 00042 IS NON-ZERO THE PROGRAM ASSUMES IT IS UNDER ACT11 OR XXDP CONTROL AND WILL ACT ACCORDINGLY. AFTER \*ALL\* AVAILABLE DZV11S ARE TESTED THE PROGRAM WILL RETURN TO 'XXDP' OR 'ACT-11'.

#### 5. OPERATING PROCEEDURE

WHEN THE PROGRAM IS INITIALLY STARTED, MESSAGES AS DESCRIBED IN SECTION FOUR WILL BE PRINTED AND THE DIAGNOSTIC WILL BEGIN RUNNING.



5.1 NORMAL START OF DIAGNOSTIC

ON THE FIRST START OF THE DIAGNOSTIC AT ADDRESS 200, IF SW00=1 THEN THE FOLLOWING QUESTIONS ARE ASKED AND MUST BE ANSWERED:

'1ST CSR ADDRESS (160000:163770): ''  
YOU MUST TYPE IN THE FIRST DZV11 CSR IN THE SYSTEM YOU WISH TESTING TO BEGIN AT. RANGE: 160000:163770

'1ST VECTOR ADDRESS (300:770): ''  
YOU MUST TYPE IN THE VECTOR OF THE FIRST DZV11 IN THE SYSTEM UNDER TEST. RANGE 300:770

'MAINTENANCE MODE  
[EXTERNAL <H325> (E)]  
[INTERNAL <DZCSR03=1>(I)]  
[STAGGERED <H329> (S)] :  
TYPE 'E' OR 'I' OR 'S' DEPENDING ON WHICH MODE YOU WISH TO RUN IN. IF RUNNING 'EXTERNAL'; ALL SELECTED LINES MUST BE TERMINATED BY AN H325 TEST CONNECTOR.

'# OF DZV11'S <IN OCTAL> (1:20): ''  
TYPE TOTAL NUMBER OF DZV11'S TO BE TESTED IN THE SYSTEM. RANGE IS 1 THRU 20 IN OCTAL.

\*\*\*\*\* IF SW03=1 THEN THE FOLLOWING WILL BE PRINTED \*\*\*\*\*

'LINES ACTIVE BY BIT <IN OCTAL> (001:017):''  
EACH BIT REPRESENTS A LINE AND ANY COMBINATION OF LINES MAY BE SELECTED (HOWEVER IN STAGGERED MODE TWO ADJACENT LINES MUST BE SELECTED (0-1, 2-3).

'DEFAULT BAUD RATE <IN OCTAL> (00:17): ''  
THIS GIVES THE USER A CHANCE TO CHANGE THE DEFAULT BAUD RATE USED IN APP. 90% OF THE TEST. BAUD RATE CHOICES ARE:  
'00'( 50 BAUD), '01'( 75 BAUD), '02'( 110 BAUD), '03'( 134 BAUD),  
'04'( 150 BAUD), '05'( 300 BAUD), '06'( 600 BAUD), '07'(1200 BAUD),  
'10'(1800 BAUD), '11'(2000 BAUD), '12'(2400 BAUD), '13'(3600 BAUD),  
'14'(4800 BAUD), '15'(7200 BAUD), '16'(9600 BAUD), '17'(19.2 KBAUD)  
LOW DEFAULT BAUD RATES ARE NOT SUGGESTED SINCE THEY LENGTHEN THE TIME TO COMPLETE A PROGRAM PASS DRAMATICALLY.

IT IS IMPORTANT TO NOTE THAT ALL DZV11'S IN THE SYSTEM MUST BE CONTIGIOUS FOR BOTH ADDRESS AND VECTORS. ALSO ALL THE EXTRA PARAMETERS OTHER THAN CSR AND VECTORS ARE GIVEN TO THE EXISTING DZV11'S IN THE SYSTEM.

IF THE MODE OF OPERATION IS DIFFERENT FOR EACH DZV11 THIS MUST BE PATCHED INTO THE CORRECT STATUS MAP ENTRY WHICH IS PRINTED AT START TIME. AN ALTERNATIVE IS TO PUT SW00=1 AT START TIME; ANSWER QUESTIONS ABOUT DZV11 UNDER TEST AND INDICATE ONE DZV11 IN THE SYSTEM. IF THE STATUS MAP IS TO BE 'PATCHED' IT MUST BE DONE AFTER THE QUESTIONS ARE ANSWERED OR AFTER THE AUTO SIZE.

## 5.2 PROGRAM AND/OR OPERATOR ACTION

THE VARIETY OF PROGRAM CONTROL SWITCHES PROVIDED IN THIS DIAGNOSTIC PACKAGE IS DESIGNED TO PROVIDE THE USER WITH A WIDE RANGE OF TROUBLE-SHOOTING TECHNIQUES. BEFORE THE USER ATTEMPTS TO RUN THIS DIAGNOSTIC HE SHOULD BECOME FAMILIAR WITH THE USE OF THESE CONTROL SWITCHES AND THEIR RESTRICTIONS. (SEE SEC. 4.1, 4.1.1, 4.1.2, 4.1.3)

WHEN THE PROGRAM DETECTS AN ERROR THE TEST NUMBER AND PC WILL BE TYPED OUT AND POSSIBLY AN ERROR MESSAGE (DEPENDING ON THE PARTICULAR ERROR). IF IT IS NECESSARY TO KNOW MORE INFORMATION CONCERNING THE ERROR REPORT THEN LOOK IN THE PROGRAM LISTING FOR THAT TEST NUMBER AND THEN NOTE THE PC OF THE ERROR REPORT. THE REASON FOR THE ERROR REPORT WILL BECOME CLEARER WHEN READING THE COMMENTS IN THE PROGRAM LISTING.

## 6. ERRORS

AS DESCRIBED PREVIOUSLY THERE WILL ALWAYS BE A TEST NUMBER AND PC TYPED OUT AT THE TIME OF AN ERROR (PROVIDING SW 13=0 AND SW 12=0). IN MOST CASES ADDITIONAL INFORMATION WILL BE SUPPLIED TO THE THE ERROR MESSAGE WHICH IS TO GIVE THE OPERATOR AN INDICATION OF THE ERRCR.

### 6.1 ERROR RECOVERY

IF FOR SOME REASON THE DZV11 SHOULD 'HANG THE BUS' (GAIN CONTROL OF BUS SO THAT CONSOLE MANUAL FUNCTIONS ARE INHIBITED) AN INIT OR POWER DOWN/UP IS NECESSARY FOR OPERATOR TO REGAIN CONTROL OF CPU. IF THIS SHOULD HAPPEN; LOOK IN LOCATION '\$STNM' (ADDRESS 1246) FOR THE NUMBER OF THE TEST THAT WAS RUNNING AT THE TIME OF THE CATASTROPHIC ERROR. IN THIS WAY THE OPERATOR WILL HAVE AN IDEA AS TO WHAT THE DZV11 WAS DOING AT THE TIME OF THE ERROR.

## 7. RESTRICTIONS

### 7.1 STARTING RESTRICTIONS

SEE SECTION 4.1.2  
THE STATUS TABLE SHOULD BE VERIFIED REGARDLESS OF HOW THE PROGRAM WAS STARTED. ALSO IT IS IMPORTANT TO USE THIS LISTING ALONG WITH THE INFORMATION PRINTED ON THE TTY TO COMPLETELY ISOLATE PROBLEMS.

7.2 OPERATING RESTRICTIONS

PARAMETER MUST BE INPUT FROM USER OR APT IF 'AUTO SIZING' IS NOT USED.

8. MISCELLANEOUS

8.1 EXECUTION TIME

ALL DZV11 DEVICE DIAGNOSTICS WILL GIVE AN 'END PASS' MESSAGE (PROVIDING NO ERRORS AND SW12=0) WITHIN 2 MIN. THIS IS ASSUMING SW11=1 (INHIBIT ITERATIONS) IS SET TO GIVE THE FASTEST POSSIBLE EXECUTION.

8.2 PASS COMPLETE

NOTE: \*EVERY\* TIME THE PROGRAM IS STARTED; THE TESTS WILL RUN AS IF SW11 (DELETE ITERATIONS) WAS UP (=1). THIS IS TO 'VERIFY NO \*HARD\* ERRORS' AS SOON AS POSSIBLE. THEREFORE THE FIRST PASS -EACH TIME PROGRAM IS STARTED- WILL BE A 'QUICK PASS' UNTIL ALL DZV11'S IN SYSTEM ARE TESTED. WHEN THE DIAGNOSTIC HAS COMPLETED A PASS THE FOLLOWING IS AN EXAMPLE OF THE PRINT OUT TO BE EXPECTED.

END PASS DVDZB-A CSR: 160100 VEC: 300 PASSES: 000001 ERRORS: 000000

NOTE: THE NUMBERS FOR CSR AND VEC ARE NOT NECESSARILY THE VALUES FOR THE DEVICE. THEY ARE ONLY FOR THIS EXAMPLE.

8.3 KEY LOCATIONS

SLPADR (1252) CONTAINS THE ADDRESS WHERE PROGRAM WILL RETURN WHEN ITERATION COUNT IS REACHED OR IF LOOP ON TEST IS ASSERTED.

NEXT (1362) CONTAINS THE ADDRESS OF THE NEXT TEST TO BE PERFORMED.

STSTNM (1246) CONTAINS THE NUMBER OF THE TEST NOW BEING PERFORMED.

RUN (1412) THE BIT IN 'RUN' ALWAYS POINTS ONE PAST THE DZV11 CURRENTLY BEING TESTED. EXAMPLE: (RUN) 1412/0000000001000000 MEANS THAT DZV11 NO.5 IS THE DZV11 NOW RUNNING.

STATUS MAP (1500)-(1740) THESE LOCATIONS CONTAIN THE INFORMATION NEEDED TO TEST UP TO 16 (DECIMAL) DZV11S SEQUENTIALY. THEY CONTAIN THE CSR,VECTOR AND STATUS CONCERNING THE CONFIGURATION OF EACH DZV11.

DZVACTV(1406) EACH BIT SET IN THIS LOCATION INDICATES THAT THE ASSOCIATED DZV11 WILL BE TESTED IN TURN. EXAMPLE: (DZVACTV) 1406/0000000000011111 MEANS THAT DZV11 NO. 00,01,02,03,04 WILL BE TESTED. EXAMPLE: (DZVACTV) 1406/0000000000010001 MEANS THAT DZV11 NO. 00,04 WILL BE TESTED.

\$BASE (1174) CONTAINS THE RECEIVER CSR OF THE CURRENT DZV11 UNDER TEST.

8.4 MORE ON THAT 'STATUS TABLE' (1500-1740)

'MAP OF DZV11 STATUS'  
1500 160100  
1502 000300  
1504 000017  
1506 017470  
1510 000000

THE ABOVE INFORMATION WILL BE REPEATED FOR EACH OF UP TO 16 DZV11'S IN THE SYSTEM (THESE WILL FOLLOW UNDER THIS TABLE). EXPLANATION:

1500 160100 THIS IS THE SYSTEM CONTROL REGISTER FOR THE 1ST DZV11 IN THE SYSTEM.  
1502 000300 THIS IS VECTOR 'A' FOR THE FIRST DZV11 IN THE SYSTEM.  
1504 000017 THIS IS THE BINARY REPRESENTATION OF WHAT LINES ARE TO BE TESTED.  
1506 017470 THIS IS THE PARAMETER LOCATION USED IN MOST OF THE TESTS. IT INDICATES PARAMETERS OF: RX ON, SPEED SELECT 17 (19.2K BAUD) EIGHT BITS PER CHAR, AND TWO STOP BITS. THE USER MAY ALTER THE STOP BITS AND THE SPEED, BUT THE REMAINING PARAMETERS SHOULD BE LEFT ALONE. THIS LOCATION IS USED TO LOAD THE DZV11 LINE PARAMETER REGISTER FOR EACH LINE. THE MEANING OF THE BITS SET IN THIS LOCATION IS THE SAME AS THE FUNCTION OF THE RELATED BITS IN THE DEVICE LINE PARAMETER REGISTER.  
1510 000000 THIS LOCATION WILL CONTAIN EITHER ALL ZEROS INDICATING THAT INTERNAL LOOP WAS SELECTED AS MODE OF OPERATION OR IT WILL CONTAIN 100000 INDICATING THAT "STAGGERED MODE" WAS SELECTED OR IT WILL CONTAIN 000200 INDICATING THAT "EXTERNAL" WAS THE MODE SELECTED.

THE ABOVE IS REPEATED FOR EACH DZV11 IN THE SYSTEM. THE TABLE IS FILLED BY AUTO SIZING OR BY THE MANUAL PARAMETER INPUT PROGRAM AS DESCRIBED PREVIOUSLY. ALSO IF DESIRED BY USER; THE LOCATIONS MAY BE ALTERED BY HAND TO SUIT THE SPECIFIC CONFIGURATION.

8.5 \*\*\* METHOD OF AUTO SIZING \*\*\*

8.5.1 FINDING THE CONTROL STATUS REGISTER.

THE PROGRAM WILL START AT ADDRESS 160000 AND START 'REFERENCING' THE ADDRESS IN THE POINTER. IF A NON-EX MEMORY TRAP OCCURS, THE PCINTER (HOLDING 160000) IS UPDATED BY 10 AND THE ABOVE IS REPEATED UNTIL ADDRESS 163770 IS REACHED. IF A 'BUS REPLY' RESPONSE WAS ISSUED BY THE DZV11 (OR ANY OTHER DEVICE) (NO NXM TRAP), 'MASTER SCAN ENABLE' IS ATTEMPTED TO BE SET AND THE TCR BITS FOR ALL FOUR LINES ARE SET. 'TRDY' IS THEN TESTED TO BE SET AND 'MASTER SCAN ENABLE' IS TESTED TO BE STILL SET. THE DIAGNOSTIC WILL THEN CHECK THAT AT LEAST ONE TCR BIT IS STILL SET. IF ALL OF THE ABOVE WORKED, THIS DEVICE IS ASSUMED TO BE A DZV11. IF ANY OF THE ABOVE FAILED, UPDATING OF THE POINTER IS DONE AND THE SEQUENCE IS REPEATED.  
NOTE: IF THE PROGRAM DOES NOT FIND YOUR DZV11, SOMETHING IS WRONG AND AUTO SIZING SHOULD NOT BE DONE.

8.5.2 FINDING THE VECTOR

THE VECTOR AREA (ADDRESS 300-776) IS FILLED WITH THE INSTRUCTION IOT AND '+2' (NEXT ADDRESS). BIT14 AND BIT5 (TX INTERRUPT ENABLE AND MS:SCAN ENABLE) ARE SET INTO THE DZVCSR. ALL TCR BITS ARE SET, A DELAY OCCURS, AND IF NO INTERRUPT OCCURS (BECAUSE OF A BAD DZV11) THE PROGRAM ASSUMES VECTOR ADDRESS 300 AND THE PROBLEM SHOULD BE FIXED IN THE DIAGNOSTIC. ONCE THE PROBLEM IS FIXED, THE PROGRAM SHOULD BE SETUP AGAIN TO SET THE CORRECT VECTOR. IF AN INTERRUPT OCCURRED, THE ADDRESS TO WHICH THE DZV11 INTERRUPTED TO IS PICKED UP AND REPORTED AS THE VECTOR. NOTE: IF THE VECTOR REPORTED IS NOT THE VECTOR SET UP BY YOU, THERE IS A PROBLEM AND AUTO SIZING SHOULD NOT BE DONE.

8.5.3 PARAMETER ASSUMPTIONS.

SINCE TOO MUCH HARDWARE WOULD NEED TO BE TURNED ON TO SIZE THE REST OF THE PARAMETERS; THE PROGRAM MUST ASSUME THE REMAINING VARIATIONS. THE RESULT IF NOT TO YOUR SPECIFIC CONFIGURATION MAY BE ALTERED BY HAND. IN THIS WAY 95% OF THE PARAMETER SETUP WAS DONE BY THE PROGRAM AND 5% BY YOU.

THEREFORE:

- 1) ALL FOUR LINES ARE ASSUMED TO BE TESTED.
- 2) DEFAULT BAUD RATE IS SET TO 17 (19.2 KBAUD).
- 3) MODE OF OPERATION IS "INTERNAL MODE".

FOR ALL PARAMETER ADJUSTMENTS PLEASE REFER TO SECTION 8.4 FOR GREATER DETAIL.

## 9.0 RUNNING THE DZV11 DIAGNOSTIC UNDER APT

### 9.1.1 THE APT INTERFACE

THE DZV DIAGNOSTICS HAVE BEEN DESIGNED TO BE COMPATIBLE WITH THE APT (AUTOMATED PRODUCT TEST) SYSTEM. THE DZV LOGIC TEST DIAGNOSTICS (DVDZA, AND DVDZB) CAN BE RUN AS STANDALONE DIAGNOSTICS OR IN EITHER OF THE APT MODES. DVDZC, HOWEVER IS DESIGNED AS A STANDALONE DIAGNOSTIC ONLY AND REQUIRES DIRECT OPERATOR PARTICIPATION.

### 9.1.2 SETTING UP THE DIAGNOSTIC USING APT

THE DIAGNOSTIC USES SEVERAL VARIABLES IN THE REGION SUBTITLED "APT MAILBOX-ETABLE". THESE VARIABLES ARE:

**\$SWREG** -(1142) USED AS THE SOFTWARE SWITCH REGISTER WHILE RUNNING UNDER APT.

**\$VECT1** -(1170) USED TO SPECIFY THE FIRST VECTOR ADDRESS

**\$BASE** -(1174) USED TO INDICATE BOTTOM ADDRESS OF DZV11 UNDER TEST

**\$DEVN** -(1176) A BIT MAP REPRESENTING WHICH DZV11'S WILL BE TESTED

**\$CDW1** -(1200) USED TO INDICATE WHICH LINES TO RUN ON ALL DZV11'S

**\$CDW2** -(1202) USED TO INDICATE THE DEFAULT TEST MODE. SET TO 0 FOR INTERNAL TESTING, 200 FOR EXTERNAL LOOP BACK (H325 INSTALLED), OR SET TO 10000 FOR STAGGERED LOOP BACK TESTING (H329 INSTALLED).

**\$DDWO** -(1204) EACH OF THE \$DDW WORDS DESCRIBES THE PARAMETERS (LPR) FOR A PARTICULAR DZV11, GOING UP TO 16 DZV11'S

### 9.1.3 RUNNING UNDER APT

ALL OF THE VARIABLES MENTIONED IN SECTION 9.1.2 SHOULD BE SET UP PRIOR TO RUNNING THE DIAGNOSTIC UNDER APT.

#### NOTE

BE SURE \$BASE POINTS TO THE FIRST DZV11 BEFORE RUNNING

BASED ON THESE VALUES, THE DIAGNOSTIC WILL SET UP THE STATUS TABLE. THE USER IS THEN FREE TO MONITOR UNDER APT AS NORMAL.

10.0

PROGRAM DESCRIPTION.

THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.

46 INITIAL ADDRESS OF THE STACK POINTER \*\*\* 1120 \*\*\*

51 MISCELLANEOUS DEFINITIONS

63 GENERAL PURPOSE REGISTER DEFINITIONS

75 PRIORITY LEVEL DEFINITIONS

85 'SWITCH REGISTER' SWITCH DEFINITIONS

113 DATA BIT DEFINITIONS (BIT00 TO BIT15)

141 BASIC 'CPU' TRAP VECTOR ADDRESSES

358 BITS 15-11=CPU TYPE  
11/04=01,11/05=02,11/20=03,11/40=04,11/45=05  
11/70=06,PDQ=07,Q=10  
BIT 10=REAL TIME CLOCK  
BIT 9=FLOATING POINT PROCESSOR  
BIT 8=MEMORY MANAGEMENT

366 MEM.TYPE BYTE -- (HIGH BYTE)  
900 NSEC CORE=001  
300 NSEC BIPOLAR=002  
500 NSEC MOS=003

371 MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABO

410 THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS USED IN THE PROGRAM.

462 THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR. THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

468 EM ::POINTS TO THE ERROR MESSAGE  
DH ::POINTS TO THE DATA HEADER  
DT ::POINTS TO THE DATA  
DF ::POINTS TO THE DATA FORMAT



1010 INCREMENT THE PASS NUMBER (\$PASS)  
IF THERES A MONITOR GO TO IT  
IF THERE ISN'T JUMP TO CYCLE

1072 THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT  
AND LOAD THE TEST NUMBER(\$TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)  
AND LOAD THE ERROR FLAG (\$ERFLG) INTO DISPLAY<15:08>  
THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:  
SW14=1 LOOP ON TEST  
SW11=1 INHIBIT ITERATIONS  
CALL  
    SCOPE                    ;;SCOPE=10T

1147 ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.  
THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.  
NOTE1: \$NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.  
NOTE2: \$FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.  
NOTE3: \$FILLC CONTAINS THE CHARACTER TO FILL AFTER.  
  
CALL:  
1) USING A TRAP INSTRUCTION  
    TYPE        ,MESADR            ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING  
OR  
    TYPE  
    MESADR

1931 ROUTINE USED TO SET UP THE DIAGNOSTIC VIA APT.  
IF BIT7 IN THE ENVIRONMENT MODE (\$ENVM) BYTE IS SET,  
THE PROGRAM WILL LOAD ITS PARAMETERS FROM THE ETABLÉ.

1963 ROUTINE USED TO 'AUTO SIZE' THE DZV11  
CSR AND VECTOR.  
NOTE: THE CSR MAY BE ANY WHERE IN THE FLOATING  
ADDRESS RANGE (160000:163770)  
AND THE VECTOR MAY BE ANY WHERE IN THE  
FLOATING VECTOR RANGE (300:770)

2071 \*\*\*\*\* TEST 1 \*\*\*\*\*  
THIS TEST VERIFIES OVERRUN AND SILO ALARM  
ONE LINE AT A TIME - BASED UPON VALID LINES  
AS EACH OF THE FIRST 16 CHARS ARE SENT; SILO ALARM IS  
TESTED TO BE CLEARED. ON THE 16TH CHAR THE PROGRAM THEN  
EXPECTS SILO ALARM TO SET. THEN THE ENTIRE  
SILO IS FILLED AND AN OVERRUN IS EXPECTED ON THE 65TH  
CHAR PULLED OUT OF THE SILO.  
ERROR PRINTOUTS WILL REPORT TRANSMITTING LINE NO.  
USING SWITCH NINE FOR THIS TEST SENDS 20. CHARACTERS  
ON DZV LINE PREVIOUSLY SELECTED CONTINUOUSLY WHILE SW09=1.  
USED TO SCOPE SILO ALARM PULSES, ETC.

- 2192 \*\*\*\*\* TEST 2 \*\*\*\*\*  
THIS TEST THAT 'SILO ENABLE' WILL INHIBIT  
RECEIVER INTERRUPTS AND THAT ON THE  
16TH CHAR THAT 'SILO ALARM' WILL CAUSE AN  
INTERRUPT WITH 'RIE' SET.  
THIS WILL DO ALL SELECTED LINES ONE AT A TIME.  
ERROR PRINTOUTS WILL REPORT TRANSMITTING LINE NO.
- 2264 \*\*\*\*\* TEST 3 \*\*\*\*\*  
THIS TEST RUNS ALL LINES FULL BORE  
BASED UPON QUALIFIED LINES  
..THIS IS AN INTERRUPT TEST ON THE RECEIVER AND  
TRANSMITTER
- 2597 \*\*\*\*\* TEST 4 \*\*\*\*\*  
DZV11 RELATIVE TIMING TEST.  
EACH SELECTED LINE WILL IN TURN RUN 16. CHARS  
AT ALL BAUD RATES AND THEN THE HIGHEST BAUD  
WITH ALL CHAR LENGTHS. EACH NEW PARAMETER SHOULD  
DECREASE IN TIME FROM THE PREVIOUS PARAMETERS SELECTED.  
THE TIME IS CHECKED AGAINST THE LAST PARAMETER USED  
AND A LOWER TIME IS EXPECTED ON THE CURRENT PARAMETER.  
PARAMETERS ARE:  
EIGHT BITS/PER/CHAR - TWO STOP BITS AT  
50, 75, 110, 134.5, 150, 300, 600, 1200, 1800, 2000  
2400, 3600, 4800, 7200, 9600 BAUD.  
19.2 K BAUD - TWO STOP BITS AT  
SEVEN, SIX, FIVE BITS/PER/CHAR.  
AFTER EACH LINE HAS FINISHED ALL THE ABOVE PARAMETERS  
THE NEXT SELECTED LINE IS THEN TESTED.  
WHEN RUNNING UNDER THE APT MANUFACTURING SYSTEM  
THIS TEST IS ONLY RUN THE FIRST PASS
- 2491 \*\*\*\*\* TEST 5 \*\*\*\*\*  
THE MAIN FUNCTION OF THIS TEST IS TO VERIFY  
THAT 'PE' (PARITY ERROR) CAN BE FLAGGED BY  
THE UARTS. THIS TEST WILL NOT BE DONE UNLESS  
YOU ARE IN 'STAGGERED' MODE.  
40(8) CHARS ARE USED FOR THIS TEST.  
ALL SELECTED LINES WILL BE ENABLED AT THE SAME TIME.  
THIS TEST FIRST CHECKS EVEN PARITY FOR ODD LINES AND  
ODD PARITY FOR EVEN LINES, THEN IT CHECKS THE REVERSE.

CVDZBB  
CVDZBB.P11 10-AUG-81 10:56

F 2  
::GPA MACY11 30G(1063) 10-AUG-81 11:11 PAGE 25

SEQ 0018

2727  
2728  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)  
(2)

000001

001120

000011  
000012  
000015

```
::GPA PRGFRT ^?MAINDEC-11-DVDZBA/<200>/FOUR LINE ASYNC MUX TESTS, PART 2 OF 2?,DVDZBA
::GPA .HEADER <MD-11-DVDZB-A>,1977
.TITLE CVDZB-B
.*COPYRIGHT (C) 1977,1981
.*DIGITAL EQUIPMENT CORP.
.*MAYNARD, MASS. 01754
.*
.*
.*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
.*PACKAGE (MAINDEC-11-DZQAC-C5), JAN, 1981.
.*
$TN=1
:STARTING PROCEDURE
:LOAD PROGRAM
:LOAD ADDRESS 000200
:PRESS START
:PROGRAM WILL TYPE
:"CVDZBB/<200>/FOUR LINE ASYNC MUX TESTS, PART 2 OF 2"
:PROGRAM WILL TYPE 'RUNNING' TO INDICATE THAT TESTING HAS STARTED
:AT THE END OF A PASS, PROGRAM WILL TYPE PASS COMPLETE MESSAGE
:AND THEN RESUME TESTING

.REM !
:SWITCH REGISTER OPTIONS
:-----

SW15=100000 :=1,HALT ON ERROR
SW14=40000 :=1,LOOP ON CURRENT TEST
SW13=20000 :=1,INHIBIT ERROR TYPEOUT
SW12=10000 :=1,DELETE TYPEOUT/BELL ON ERROR.
SW11=4000 :=1,INHIBIT ITERATIONS
SW10=2000 :=1,ESCAPE TO NEXT TEST ON ERROR
SW09=1000 :=1,LOOP WITH CURRENT DATA
SW08=400 :=1,LOOP ON ERROR
SW07=200 :=1, DO 'AUTO SIZING' ON INITIAL START UP.
SW06=100 :=1, DESELECT SPECIFIC DEVICES
:NOTE: THIS MUST NOT EXCEED ORIGINAL COUNT

SW05=40
SW04=20 :=1, SELECT DELAY PARAMETER
SW03=10 :=1, SELECT SPECIFIC PARAMETERS
SW02=4 :=1, LOCK ON TEST SELECT
SW01=2 :=1, RESTART PROGRAM AT SELECTED TEST
SW00=1 :=1, SELECT DEVICE ADDRESS, VECTOR, ETC.

!
.SBTTL BASIC DEFINITIONS

.*INITIAL ADDRESS OF THE STACK POINTER *** 1120 ***
STACK= 1120
.EQUIV EMT,ERROR ::BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE ::BASIC DEFINITION OF SCOPE CALL

.*MISCELLANEOUS DEFINITIONS
HT= 11 ::CODE FOR HORIZONTAL TAB
LF= 12 ::CODE FOR LINE FEED
CR= 15 ::CODE FOR CARRIAGE RETURN
```

```

(2)      000200      CRLF= 200           ;;CODE FOR CARRIAGE RETURN-LINE FEED
(2)      177776      PS= 177776        ;;PROCESSOR STATUS WORD
(2)      177774      .EQUIV PS,PSW
(2)      177772      STKLM= 177774     ;;STACK LIMIT REGISTER
(2)      177570      PIRQ= 177772     ;;PROGRAM INTERRUPT REQUEST REGISTER
(2)      177570      DSWR= 177570     ;;HARDWARE SWITCH REGISTER
(2)      177570      DDISP= 177570    ;;HARDWARE DISPLAY REGISTER

(2)      000000      ;*GENERAL PURPOSE REGISTER DEFINITIONS
(2)      000001      R0= 0            ;;GENERAL REGISTER
(2)      000002      R1= 1            ;;GENERAL REGISTER
(2)      000003      R2= 2            ;;GENERAL REGISTER
(2)      000004      R3= 3            ;;GENERAL REGISTER
(2)      000005      R4= 4            ;;GENERAL REGISTER
(2)      000006      R5= 5            ;;GENERAL REGISTER
(2)      000007      R6= 6            ;;GENERAL REGISTER
(2)      000006      R7= 7            ;;GENERAL REGISTER
(2)      000006      SP= 6           ;;STACK POINTER
(2)      000007      PC= 7           ;;PROGRAM COUNTER

(2)      000000      ;*PRIORITY LEVEL DEFINITIONS
(2)      000040      PR0= 0          ;;PRIORITY LEVEL 0
(2)      000100      PR1= 40         ;;PRIORITY LEVEL 1
(2)      000140      PR2= 100        ;;PRIORITY LEVEL 2
(2)      000200      PR3= 140        ;;PRIORITY LEVEL 3
(2)      000240      PR4= 200        ;;PRIORITY LEVEL 4
(2)      000300      PR5= 240        ;;PRIORITY LEVEL 5
(2)      000340      PR6= 300        ;;PRIORITY LEVEL 6
(2)      000340      PR7= 340        ;;PRIORITY LEVEL 7

(2)      100000      ;*'SWITCH REGISTER' SWITCH DEFINITIONS
(2)      040000      SW15= 100000
(2)      020000      SW14= 40000
(2)      010000      SW13= 20000
(2)      004000      SW12= 10000
(2)      002000      SW11= 4000
(2)      001000      SW10= 2000
(2)      000400      SW09= 1000
(2)      000200      SW08= 400
(2)      000100      SW07= 200
(2)      000040      SW06= 100
(2)      000020      SW05= 40
(2)      000010      SW04= 20
(2)      000004      SW03= 10
(2)      000002      SW02= 4
(2)      000001      SW01= 2
(2)      000001      SW00= 1
(2)      .EQUIV SW09,SW9
(2)      .EQUIV SW08,SW8
(2)      .EQUIV SW07,SW7
(2)      .EQUIV SW06,SW6
(2)      .EQUIV SW05,SW5
(2)      .EQUIV SW04,SW4
(2)      .EQUIV SW03,SW3
(2)      .EQUIV SW02,SW2
(2)      .EQUIV SW01,SW1
  
```

```

(2) .EQUIV SW00,SWC
(2)
(2) ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
(2) 100000 BIT15= 100000
(2) 040000 BIT14= 40000
(2) 020000 BIT13= 20000
(2) 010000 BIT12= 10000
(2) 004000 BIT11= 4000
(2) 002000 BIT10= 2000
(2) 001000 BIT09= 1000
(2) 000400 BIT08= 400
(2) 000200 BIT07= 200
(2) 000100 BIT06= 100
(2) 000040 BIT05= 40
(2) 000020 BIT04= 20
(2) 000010 BIT03= 10
(2) 000004 BIT02= 4
(2) 000002 BIT01= 2
(2) 000001 BIT00= 1
(2) .EQUIV BIT09,BIT9
(2) .EQUIV BIT08,BIT8
(2) .EQUIV BIT07,BIT7
(2) .EQUIV BIT06,BIT6
(2) .EQUIV BIT05,BIT5
(2) .EQUIV BIT04,BIT4
(2) .EQUIV BIT03,BIT3
(2) .EQUIV BIT02,BIT2
(2) .EQUIV BIT01,BIT1
(2) .EQUIV BIT00,BIT0
(2)
(2) ;*BASIC 'CPU' TRAP VECTOR ADDRESSES
(2) 000004 ERRVEC= 4 ;:TIME OUT AND OTHER ERRORS
(2) 000010 RESVEC= 10 ;:RESERVED AND ILLEGAL INSTRUCTIONS
(2) 000014 TBITVEC=14 ;: 'T' BIT
(2) 000014 TRTVEC= 14 ;:TRACE TRAP
(2) 000014 BPTVEC= 14 ;:BREAKPOINT TRAP (BPT)
(2) 000020 IOTVEC= 20 ;:INPUT/OUTPUT TRAP (IOT) **SCOPE**
(2) 000024 PWRVEC= 24 ;:POWER FAIL
(2) 000030 EMTVEC= 30 ;:EMULATOR TRAP (EMT) **ERROR**
(2) 000034 TRAPVEC=34 ;: 'TRAP' TRAP
(2) 000060 TKVEC= 60 ;:TTY KEYBOARD VECTOR
(2) 000064 TPVEC= 64 ;:TTY PRINTER VECTOR
(2) 000240 PIRQVEC=240 ;:PROGRAM INTERRUPT REQUEST VECTOR
(1)
(1) ;INSTRUCTION DEFINITIONS
(1) :-----
(1)
(1) 005746 PUSH1SP=5746 ;:DECREMENT PROCESSOR STACK 1 WORD
(1) 005726 POP1SP=5726 ;:INCREMENT PROCESSOR STACK 1 WORD
(1) 010046 PUSHRO=10046 ;:SAVE R0 ON STACK
(1) 012600 POPRO=12600 ;:RESTORE R0 FROM STACK
(1) 024646 PUSH2SP=24646 ;:DECREMENT STACK TWICE
(1) 022626 POP2SP=22626 ;:INCREMENT STACK TWICE
(1) 000200 MASK=BIT7 ;:SET INTERRUPT MASK (INHIBIT FURTHER INTERRUPTS)
(1) 000000 CLEAR=0 ;:ALLOW INTERRUPTS (CLEAR PROCESSOR STATUS)

```



(1)			
(1)	000100	PARITY=BIT6	:PARITY ENABLED
(1)	000200	ODDPAR=BIT7	:ODD PARITY ENABLED
(1)	000000	ONESTOP=0	:ONE STOP BIT ENABLED
(1)	000040	TWOSTOP=BIT5	:TWO STOP BITS ENABLED
(1)	000000	EVEPAR=0	:EVEN PARITY ENABLED
(1)	010000	RCVON=BIT12	:ENABLE RECEIVER (RECEIVER ON)

(1)	000000	S50=0	:SPEED 50 BAUD
(1)	000400	S75=BIT8	:SPEED 75 BAUD
(1)	001000	S110=BIT9	:SPEED 110 BAUD
(1)	001400	S134=BIT9!BIT8	:SPEED 134.5 BAUD
(1)	002000	S150=BIT10	:SPEED 150 BAUD
(1)	002400	S300=BIT10!BIT8	:SPEED 300 BAUD
(1)	003000	S600=BIT10!BIT9	:SPEED 600 BAUD
(1)	003400	S1200=BIT10!BIT9!BIT8	:SPEED 1200 BAUD
(1)	004000	S1800=BIT11	:SPEED 1800 BAUD
(1)	004400	S2000=BIT11!BIT8	:SPEED 2000 BAUD
(1)	005000	S2400=BIT11!BIT9	:SPEED 2400 BAUD
(1)	005400	S3600=BIT11!BIT9!BIT8	:SPEED 3600 BAUD
(1)	006000	S4800=BIT11!BIT10	:SPEED 4800 BAUD
(1)	006400	S7200=BIT11!BIT10!BIT8	:SPEED 7200 BAUD
(1)	007000	S9600=BIT11!BIT10!BIT9	:SPEED 9600 BAUD
(1)	007400	S19200=BIT11!BIT10!BIT9!BIT8	:SPEED 19200 BAUD

:DZVTCR BIT DEFINITIONS

(1)			
(1)	000001	TCR0=BIT0	:ENABLE TRANSMISSION ON LINE 0
(1)	000002	TCR1=BIT1	:ENABLE TRANSMISSION ON LINE 1
(1)	000004	TCR2=BIT2	:ENABLE TRANSMISSION ON LINE 2
(1)	000010	TCR3=BIT3	:ENABLE TRANSMISSION ON LINE 3
(1)	000400	DTR0=BIT8	:DATA TERMINAL READY FOR LINE 0
(1)	001000	DTR1=BIT9	:DATA TERMINAL READY FOR LINE 1
(1)	002000	DTR2=BIT10	:DATA TERMINAL READY FOR LINE 2
(1)	004000	DTR3=BIT11	:DATA TERMINAL READY FOR LINE 3

:DZVMSR BIT DEFINITIONS

(1)			
(1)	000001	RING0=BIT0	:RING INDICATED ON LINE 0
(1)	000002	RING1=BIT1	:RING INDICATED ON LINE 1
(1)	000004	RING2=BIT2	:RING INDICATED ON LINE 2
(1)	000010	RING3=BIT3	:RING INDICATED ON LINE 3
(1)	000400	C00=BIT8	:CARRIER PRESENT ON LINE 0
(1)	001000	C01=BIT9	:CARRIER PRESENT ON LINE 1
(1)	002000	C02=BIT10	:CARRIER PRESENT ON LINE 2
(1)	004000	C03=BIT11	:CARRIER PRESENT ON LINE 3

:DZVTDR BIT DEFINITIONS

(1)			
(1)	000400	BRK0=BIT8	:BREAK FOR LINE 0
(1)	001000	BRK1=BIT9	:BREAK FOR LINE 1
(1)	002000	BRK2=BIT10	:BREAK FOR LINE 2
(1)	004000	BRK3=BIT11	:BREAK FOR LINE 3

(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)

:TABLE OF LOOP AROUND FUNCTIONS (H325)

I	^
V	^
REC	TRANS
DATA	DATA
-----	
I	^
V	^
CO	RTS
-----	
I	^
V	^
RING	DTR





```

(3)          001120          . =1120
(4)          :*****
(4)          :SBTTL  APT MAILBOX-ETABLE
(4)          :*****
(5)          :EVEN
(4)          $MAIL:          ::APT MAILBOX
(4) 001120 000000 $MSGTY: .WORD  AMSGTY  ::MESSAGE TYPE CODE
(4) 001122 000000 $FATAL: .WORD  AFATAL  ::FATAL ERROR NUMBER
(4) 001124 000000 $TESTN: .WORD  ATESTN  ::TEST NUMBER
(4) 001126 000000 $PASS:  .WORD  APASS   ::PASS COUNT
(4) 001130 000000 $DEVCT: .WORD  ADEVCT  ::DEVICE COUNT
(4) 001132 000000 $UNIT:  .WORD  AUNIT   ::I/O UNIT NUMBER
(4) 001134 000000 $MSGAD: .WORD  AMSGAD  ::MESSAGE ADDRESS
(4) 001136 000000 $MSGLG: .WORD  AMSGLG  ::MESSAGE LENGTH
(4) 001140 $ETABLE:          ::APT ENVIRONMENT TABLE
(4) 001140 000 $ENV:  .BYTE  AENV   ::ENVIRONMENT BYTE
(4) 001141 000 $ENVM: .BYTE  AENVM  ::ENVIRONMENT MODE BITS
(4) 001142 000000 $SWREG: .WORD  ASWREG  ::APT SWITCH REGISTER
(4) 001144 000000 $USWR:  .WORD  AUSWR   ::USER SWITCHES
(4) 001146 000000 $CPUOP: .WORD  ACPUOP  ::CPU TYPE, OPTIONS
(4)          :*          BITS 15-11=CPU TYPE
(4)          :*          11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
(4)          :*          11/70=06,PDQ=07,Q=10
(4)          :*          BIT 10=REAL TIME CLOCK
(4)          :*          BIT 9=FLOATING POINT PROCESSOR
(4)          :*          BIT 8=MEMORY MANAGEMENT
(4) 001150 000 $MAMS1: .BYTE  AMAMS1  ::HIGH ADDRESS,M.S. BYTE
(4) 001151 000 $MTYP1: .BYTE  AMTYP1  ::MEM. TYPE,BLK#1
(4)          :*          MEM.TYPE BYTE  -- (HIGH BYTE)
(4)          :*          900 NSEC CORE=001
(4)          :*          300 NSEC BIPOLAR=002
(4)          :*          500 NSEC MOS=003
(4) 001152 000000 $MADR1: .WORD  AMADR1  ::HIGH ADDRESS,BLK#1
(4)          :*          MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE
(4) 001154 000 $MAMS2: .BYTE  AMAMS2  ::HIGH ADDRESS,M.S. BYTE
(4) 001155 000 $MTYP2: .BYTE  AMTYP2  ::MEM. TYPE,BLK#2
(4) 001156 000000 $MADR2: .WORD  AMADR2  ::MEM.LAST ADDRESS,BLK#2
(4) 001160 000 $MAMS3: .BYTE  AMAMS3  ::HIGH ADDRESS,M.S.BYTE
(4) 001161 000 $MTYP3: .BYTE  AMTYP3  ::MEM. TYPE,BLK#3
(4) 001162 000000 $MADR3: .WORD  AMADR3  ::MEM.LAST ADDRESS,BLK#3
(4) 001164 000 $MAMS4: .BYTE  AMAMS4  ::HIGH ADDRESS,M.S.BYTE
(4) 001165 000 $MTYP4: .BYTE  AMTYP4  ::MEM. TYPE,BLK#4
(4) 001166 000000 $MADR4: .WORD  AMADR4  ::MEM.LAST ADDRESS,BLK#4
(4) 001170 000300 $VECT1: .WORD  AVECT1  ::INTERRUPT VECTOR#1,BUS PRIORITY#1
(4) 001172 000000 $VECT2: .WORD  AVECT2  ::INTERRUPT VECTOR#2BUS PRIORITY#2
(4) 001174 160010 $BASE:  .WORD  ABASE   ::BASE ADDRESS OF EQUIPMENT UNDER TEST
(4) 001176 000001 $DEVN:  .WORD  ADEVN   ::DEVICE MAP
(4) 001200 000017 $CDW1:  .WORD  ACDW1   ::CONTROLLER DESCRIPTION WORD#1
(4) 001202 000000 $CDW2:  .WORD  ACDW2   ::CONTROLLER DESCRIPTION WORD#2
(4) 001204 017470 $DDW0:  .WORD  ADDW0   ::DEVICE DESCRIPTOR WORD#0
(4) 001206 017470 $DDW1:  .WORD  ADDW1   ::DEVICE DESCRIPTOR WORD#1
(4) 001210 017470 $DDW2:  .WORD  ADDW2   ::DEVICE DESCRIPTOR WORD#2
(4) 001212 017470 $DDW3:  .WORD  ADDW3   ::DEVICE DESCRIPTOR WORD#3
(4) 001214 017470 $DDW4:  .WORD  ADDW4   ::DEVICE DESCRIPTOR WORD#4
(4) 001216 017470 $DDW5:  .WORD  ADDW5   ::DEVICE DESCRIPTOR WORD#5

```

CVDZB-B MACY11 30G(1063) 10-AUG-81 11:11 PAGE 25-8  
CVDZBB.P11 10-AUG-81 10:56 APT MAILBOX-ETABLE

SEQ 0026

(4)	001220	017470	SDW6:	.WORD	ADDW6	::DEVICE	DESCRIPTOR	WORD#6
(4)	001222	017470	SDW7:	.WORD	ADDW7	::DEVICE	DESCRIPTOR	WORD#7
(4)	001224	017470	SDW8:	.WORD	ADDW8	::DEVICE	DESCRIPTOR	WORD#8
(4)	001226	017470	SDW9:	.WORD	ADDW9	::DEVICE	DESCRIPTOR	WORD#9
(4)	001230	017470	SDW10:	.WORD	ADDW10	::DEVICE	DESCRIPTOR	WORD#10
(4)	001232	017470	SDW11:	.WORD	ADDW11	::DEVICE	DESCRIPTOR	WORD#11
(4)	001234	017470	SDW12:	.WORD	ADDW12	::DEVICE	DESCRIPTOR	WORD#12
(4)	001236	017470	SDW13:	.WORD	ADDW13	::DEVICE	DESCRIPTOR	WORD#13
(4)	001240	017470	SDW14:	.WORD	ADDW14	::DEVICE	DESCRIPTOR	WORD#14
(4)	001242	017470	SDW15:	.WORD	ADDW15	::DEVICE	DESCRIPTOR	WORD#15
(4)								
(4)								
(4)	001244		SETEND:					
(4)								

(3)			.SBTTL COMMON TAGS		
(3)					
(4)			::*****		
(3)			::*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS		
(3)			::*USED IN THE PROGRAM.		
(3)					
(3)	001244		SCMTAG:		:::START OF COMMON TAGS
(3)	001244	000000	.WORD	0	
(3)	001246	000	\$TSTNM:	.BYTE	0
(3)	001247	000	\$ERFLG:	.BYTE	0
(3)	001250	000000	\$ICNT:	.WORD	0
(3)	001252	000000	\$LPADR:	.WORD	0
(3)	001254	000000	\$LPERR:	.WORD	0
(3)	001256	000000	\$ERTTL:	.WORD	0
(3)	001260	000	\$ITEMB:	.BYTE	0
(3)	001261	001	\$ERMAX:	.BYTE	1
(3)	001262	000000	\$ERRPC:	.WORD	0
(3)	001264	000000	\$GDADR:	.WORD	0
(3)	001266	000000	\$BDADR:	.WORD	0
(3)	001270	000000	\$GDDAT:	.WORD	0
(3)	001272	000000	\$BDDAT:	.WORD	0
(3)	001274	000000	.WORD	0	
(3)	001276	000000	.WORD	0	
(3)	001300	000	\$AUTOB:	.BYTE	0
(3)	001301	000	\$INTAG:	.BYTE	0
(3)	001302	000000	.WORD	0	
(3)	001304	177570	\$SWR:	.WORD	DSWR
(3)	001306	177570	\$DISPLAY:	.WORD	DDISP
(3)	001310	177560	\$TKS:	177560	
(3)	001312	177562	\$TKB:	177562	
(3)	001314	177564	\$TPS:	177564	
(3)	001316	177566	\$TPB:	177566	
(3)	001320	000	\$NULL:	.BYTE	0
(3)	001321	002	\$FILLS:	.BYTE	2
(3)	001322	012	\$FILLC:	.BYTE	12
(3)	001323	000	\$TPFLG:	.BYTE	0
(3)	001324	000000	\$REGAD:	.WORD	0
(3)					
(5)	001326	000000	\$REG0:	.WORD	0
(5)	001330	000000	\$REG1:	.WORD	0
(5)	001332	000000	\$REG2:	.WORD	0
(5)	001334	000000	\$REG3:	.WORD	0
(5)	001336	000000	\$REG4:	.WORD	0
(5)	001340	000000	\$REG5:	.WORD	0
(5)	001342	000000	\$TMP0:	.WORD	0
(5)	001344	000000	\$TMP1:	.WORD	0
(5)	001346	000000	\$TMP2:	.WORD	0
(5)	001350	000000	\$TMP3:	.WORD	0
(5)	001352	000000	\$TMP4:	.WORD	0
(3)	001354	000000	\$TIMES:	0	
(3)	001356	077	\$QUES:	.ASCII	/?/
(3)	001357	015	\$CRLF:	.ASCII	<15>
(3)	001360	000012	\$LF:	.ASCII	<12>
					:::CONTAINS THE TEST NUMBER
					:::CONTAINS ERROR FLAG
					:::CONTAINS SUBTEST ITERATION COUNT
					:::CONTAINS SCOPE LOOP ADDRESS
					:::CONTAINS SCOPE RETURN FOR ERRORS
					:::CONTAINS TOTAL ERRORS DETECTED
					:::CONTAINS ITEM CONTROL BYTE
					:::CONTAINS MAX. ERRORS PER TEST
					:::CONTAINS PC OF LAST ERROR INSTRUCTION
					:::CONTAINS ADDRESS OF 'GOOD' DATA
					:::CONTAINS ADDRESS OF 'BAD' DATA
					:::CONTAINS 'GOOD' DATA
					:::CONTAINS 'BAD' DATA
					:::RESERVED--NOT TO BE USED
					:::AUTOMATIC MODE INDICATOR
					:::INTERRUPT MODE INDICATOR
					:::ADDRESS OF SWITCH REGISTER
					:::ADDRESS OF DISPLAY REGISTER
					:::TTY KBD STATUS
					:::TTY KBD BUFFER
					:::TTY PRINTER STATUS REG. ADDRESS
					:::TTY PRINTER BUFFER REG. ADDRESS
					:::CONTAINS NULL CHARACTER FOR FILLS
					:::CONTAINS # OF FILLER CHARACTERS REQUIRED
					:::INSERT FILL CHARS. AFTER A 'LINE FEED'
					:::'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
					:::CONTAINS THE ADDRESS FROM
					:::WHICH (\$REG0) WAS OBTAINED
					:::CONTAINS ((\$REGAD)+0)
					:::CONTAINS ((\$REGAD)+2)
					:::CONTAINS ((\$REGAD)+4)
					:::CONTAINS ((\$REGAD)+6)
					:::CONTAINS ((\$REGAD)+10)
					:::CONTAINS ((\$REGAD)+12)
					:::USER DEFINED
					:::USER DEFINED
					:::USER DEFINED
					:::USER DEFINED
					:::USER DEFINED
					:::MAX. NUMBER OF ITERATIONS
					:::QUESTION MARK
					:::CARRIAGE RETURN
					:::LINE FEED

```

(3)          .SBTTL ERROR POINTER TABLE
(3)
(3)          ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
(3)          ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
(3)          ;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
(3)          ;*NOTE1:      IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
(3)          ;*NOTE2:      EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
(3)
(3)          ;*      EM          ;;POINTS TO THE ERROR MESSAGE
(3)          ;*      DH          ;;POINTS TO THE DATA HEADER
(3)          ;*      DT          ;;POINTS TO THE DATA
(3)          ;*      DF          ;;POINTS TO THE DATA FORMAT
(3)
(3)          $ERRTB:
(3)
(2)          ;PROGRAM CONTROL PARAMETERS
(2)          ;-----
(2)          001362    000000    NEXT: 0          ;ADDRESS OF NEXT TEST TO BE EXECUTED
(2)          001364    000000    LOCK: 0         ;ADDRESS FOR LOCK ON CURRENT TEST,TIGHT LOOP
(2)
(2)          ;PROGRAM VARIABLES
(2)          ;-----
(2)          001366    000017    LINE: 17        ;DEFAULT ALL FOUR LINES RUNNING
(2)          001370    017470    PAR: 17470     ;PARAMETERS: 8 BITS/CHAR,2 STOP BITS,19200 BAUD,NO PARIT
(2)          001372    000000    MODE: 0       ;DEFAULT MAINTENANCE MODE
(2)          001374    000000    SAVLIN: 0     ;LINE NUMBER
(2)          001376    000000    XMTLIN: 0     ;TRANSMISSION LINE NUMBER
(2)          001400    000000    XMTCNT: 0     ;COUNT OF WORDS IN A TRANSMISSION PATTERN
(2)          001402    000000    REGIST: 0     ;DEVICE ADDRESS STORAGE LOCATION
(2)          001404    000000    SAVPC: J      ;PROGRAM COUNTER STORAGE
(2)          001406    000001    DZVACTV: .BLKW 1 ;*DZV11'S SELECTED ACTIVE.
(2)          001410    000001    SAVACTV: .BLKW 1 ;*A BIT MAP OF DZV11'S IN THE SYSTEM
(2)          001412    000001    RUN: 1        ;*POINTER ONE PAST RUNNING DEVICE.
(2)          001414    000001    DZVNUM: .BLKB 1 ;*OCTAL NUMBER OF DZV11'S IN THE SYSTEM.
(2)          001415     001      SAVNUM: .BYTE 1 ;*WORKABLE NUMBER.
(2)          001416    000001    SAVNO: .BLKB 1 ;*OCTAL NUMBER OF DZV11'S BEING TESTED
(2)          001420    001420    .EVEN
(2)          001420    001500    ACTIVE: DZV.MAP ;TABLE POINTER.
  
```

```

(2)
(2)
(2)
(2)
(2) 001422 000
(2) 001423 000
(2) 001424 000
(2) 001425 000
(2)
(2) 001426 000000
(2) 001430 000000
(2) 001432 000000
(2) 001434 000000
(2) 001436 000000
(2) 001440 000000
(2) 001442 000000
(2) 001444 000000
(2) 001446
(2)
(2)
(3)
(2)
(3)
(2) 001446
(2) 000024 000024
(2) 000024 000200
(2) 000044 000044
(2) 000044 001446
(2) 001446
(3)
(2)
(2)
(2)
(2) 001446
(2) 001446 000000
(2) 001450 001120
(2) 001452 000132
(2) 001454 000137
(2) 001456 000000
(2) 001460 000052
(1)
(1)
(1)
(1) 001500 001500
(3)
(3) 001500 000001
(3) 001502 000001
(3) 001504 000001
(3) 001506 000001
(3) 001510 000001
(3)
(3) 001512 000001
(3) 001514 000001
(3) 001516 000001

```

```

:PROGRAM CONTROL FLAGS
:-----
INIFLG: .BYTE 0 :PROGRAM INITIALIZATION FLAG
HDRFLG: .BYTE 0 :PROGRAM INITIALIZATION FLAG FOR HEADER MAP
MNTFLG: .BYTE 0 :MAINTENANCE BIT SET FLAG
DONFLG: .BYTE 0 :TRANSMISSION COMPLETION FLAG
.EVEN
:DATA VARIABLES
TD0: .WORD 0
TD1: .WORD 0
TD2: .WORD 0
TD3: .WORD 0
TR0: .WORD 0
TR1: .WORD 0
TR2: .WORD 0
TR3: .WORD 0
STOP:
.SBTTL APT PARAMETER BLOCK
:*****
:SET LOCATIONS 24 AND 44 AS RQUIRED FOR APT
:*****
.SX= :SAVE CURRENT LOCATION
=24 :SET POWER FAIL TO POINT TO START OF PROGRAM
200 :FOR APT START UP
=44 :POINT TO APT INDIRECT ADDRESS PNTR.
$APTHDR :POINT TO APT HEADER BLOCK
=.SX :RESET LOCATION COUNTER
:*****
:SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
:INTERFACE SPEC.
$AP1HD:
$SHIBTS: .WORD 0 :TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBADR: .WORD $MAIL :ADDRESS OF APT MAILBOX (BITS 0-15)
$STMT: .WORD 90. :RUN TIM OF LONGEST TEST
$PASTM: .WORD 95. :RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
$UNITM: .WORD 0. :ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
.WORD $ETEND-$MAIL/2 :LENGTH MAILBOX-ETABLE(WORDS)
:DZV11 STATUS TABLE AND ADDRESS ASSIGNMENTS
:-----
.=1500
DZV.MAP:
DZCRO: .BLKW 1 :CONTROL STATUS REGISTER FOR DZV11 NUMBER 0
DZVCO: .BLKW 1 :RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 0
LINE0: .BLKW 1 :ALL LINES SELECTED
PAR0: .BLKW 1 :PARAMETERS
MANT0: .BLKW 1 :MAINTENANCE MODE FOR THIS DEVICE
DZCR1: .BLKW 1 :CONTROL STATUS REGISTER FOR DZV11 NUMBER 1
DZVC1: .BLKW 1 :RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 1
LINE1: .BLKW 1 :ALL LINES SELECTED

```

CVDZB-B MACY11 30G(1063) 10-AUG-81 11:11 PAGE 25-12  
 CVDZBB.P11 10-AUG-81 10:56 APT PARAMETER BLOCK

SEQ 0030

(3)	001520	000001	PAR1:	.BLKW	1	:PARAMETERS
(3)	001522	000001	MANT1:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)	001524	000001	DZCR2:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 2
(3)	001526	000001	DZVC2:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 2
(3)	001530	000001	LINE2:	.BLKW	1	:ALL LINES SELECTED
(3)	001532	000001	PAR2:	.BLKW	1	:PARAMETERS
(3)	001534	000001	MANT2:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)	001536	000001	DZCR3:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 3
(3)	001540	000001	DZVC3:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 3
(3)	001542	000001	LINE3:	.BLKW	1	:ALL LINES SELECTED
(3)	001544	000001	PAR3:	.BLKW	1	:PARAMETERS
(3)	001546	000001	MANT3:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)	001550	000001	DZCR4:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 4
(3)	001552	000001	DZVC4:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 4
(3)	001554	000001	LINE4:	.BLKW	1	:ALL LINES SELECTED
(3)	001556	000001	PAR4:	.BLKW	1	:PARAMETERS
(3)	001560	000001	MANT4:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)	001562	000001	DZCR5:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 5
(3)	001564	000001	DZVC5:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 5
(3)	001566	000001	LINE5:	.BLKW	1	:ALL LINES SELECTED
(3)	001570	000001	PAR5:	.BLKW	1	:PARAMETERS
(3)	001572	000001	MANT5:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)	001574	000001	DZCR6:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 6
(3)	001576	000001	DZVC6:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 6
(3)	001600	000001	LINE6:	.BLKW	1	:ALL LINES SELECTED
(3)	001602	000001	PAR6:	.BLKW	1	:PARAMETERS
(3)	001604	000001	MANT6:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)	001606	000001	DZCR7:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 7
(3)	001610	000001	DZVC7:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 7
(3)	001612	000001	LINE7:	.BLKW	1	:ALL LINES SELECTED
(3)	001614	000001	PAR7:	.BLKW	1	:PARAMETERS
(3)	001616	000001	MANT7:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)	001620	000001	DZCR10:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 10
(3)	001622	000001	DZVC10:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 10
(3)	001624	000001	LINE10:	.BLKW	1	:ALL LINES SELECTED
(3)	001626	000001	PAR10:	.BLKW	1	:PARAMETERS
(3)	001630	000001	MANT10:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)	001632	000001	DZCR11:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 11
(3)	001634	000001	DZVC11:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 11
(3)	001636	000001	LINE11:	.BLKW	1	:ALL LINES SELECTED
(3)	001640	000001	PAR11:	.BLKW	1	:PARAMETERS
(3)	001642	000001	MANT11:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)	001644	000001	DZCR12:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 12
(3)	001646	000001	DZVC12:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 12
(3)	001650	000001	LINE12:	.BLKW	1	:ALL LINES SELECTED
(3)	001652	000001	PAR12:	.BLKW	1	:PARAMETERS
(3)	001654	000001	MANT12:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE

(3)					
(3)	001656	000001	DZCR13: .BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 13
(3)	001660	000001	DZVC13: .BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 13
(3)	001662	000001	LINE13: .BLKW	1	:ALL LINES SELECTED
(3)	001664	000001	PAR13: .BLKW	1	:PARAMETERS
(3)	001666	000001	MANT13: .BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)					
(3)	001670	000001	DZCR14: .BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 14
(3)	001672	000001	DZVC14: .BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 14
(3)	001674	000001	LINE14: .BLKW	1	:ALL LINES SELECTED
(3)	001676	000001	PAR14: .BLKW	1	:PARAMETERS
(3)	001700	000001	MANT14: .BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)					
(3)	001702	000001	DZCR15: .BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 15
(3)	001704	000001	DZVC15: .BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 15
(3)	001706	000001	LINE15: .BLKW	1	:ALL LINES SELECTED
(3)	001710	000001	PAR15: .BLKW	1	:PARAMETERS
(3)	001712	000001	MANT15: .BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)					
(3)	001714	000001	DZCR16: .BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 16
(3)	001716	000001	DZVC16: .BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 16
(3)	001720	000001	LINE16: .BLKW	1	:ALL LINES SELECTED
(3)	001722	000001	PAR16: .BLKW	1	:PARAMETERS
(3)	001724	000001	MANT16: .BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(3)					
(3)	001726	000001	DZCR17: .BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 17
(3)	001730	000001	DZVC17: .BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 17
(3)	001732	000001	LINE17: .BLKW	1	:ALL LINES SELECTED
(3)	001734	000001	PAR17: .BLKW	1	:PARAMETERS
(3)	001736	000001	MANT17: .BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
(1)					
(1)	001740	177777	DZV.END:	177777	



```

(1)                                     ;DEFINITIONS FOR TRAP SUBROUTINE CALLS
(1)                                     ;POINTERS TO SUBROUTINES CAN BE FOUND
(1)                                     ;IN THE TABLE IMMEDIATELY FOLLOWING THE DEFINITIONS
(1)                                     ;:*****
(1)                                     ;:-----
(1) 001742                             ;.TRPTAB:
(3) 001742 104400                       ADVANCE=TRAP+0           ;CALL TO ADVANCE TO NEXT TEST( OR SCOPE THIS ONE)
(2) 001742 006366                       .ADVANCE
(3) 001742 104401                       SCOP1=TRAP+1           ;CALL TO LOOP ON CURRENT DATA HANDLER
(2) 001744 004626                       .SCOP1
(3) 001744 104402                       TYPE=TRAP+2           ;CALL TO TELETYPE OUTPUT ROUTINE
(2) 001746 004652                       .TYPE
(3) 001746 104403                       INSTR=TRAP+3          ;CALL TO ASCII STRING INPUT ROUTINE
(2) 001750 004472                       .INSTR
(3) 001750 104404                       INSTER=TRAP+4         ;CALL TO INPUT ERROR HANDLER
(2) 001752 005576                       .INSTER
(3) 001752 104405                       PARAM=TRAP+5          ;CALL TO NUMERICAL DATA INPUT ROUTINE
(2) 001754 005616                       .PARAM
(3) 001754 104406                       SETFLG=TRAP+6         ;CALL TO SET FLAG ROUTINE
(2) 001756 010230                       .SFTFLG
(3) 001756 104407                       SAVOS=TRAP+7          ;CALL TO REGISTER SAVE ROUTINE
(2) 001760 006016                       .SAVOS
(3) 001760 104410                       RESOS=TRAP+10         ;CALL TO REGISTER RESTORE ROUTINE
(2) 001762 006056                       .RESOS
(3) 001762 104411                       CONVRT=TRAP+11        ;CALL TO DATA OUTPUT ROUTINE
(2) 001764 006110                       .CONVRT
(3) 001764 104412                       CNVRT=TRAP+12         ;CALL TO DATA OUTPUT ROUTINE WITHOUT CR/LF.
(2) 001766 006114                       .CNVRT
(3) 001766 104413                       DEVICE.CLR=TRAP+13    ;CALL TO ISSUE A DEVICE CLEAR
(2) 001770 006314                       .DEVICE.CLR
(3) 001770 104414                       DELAY=TRAP+14         ;CALL TO DELAY FOR FAST CPU'S
(2) 001772 006346                       .DELAY
(3) 001772 104415                       PARMD=TRAP+15         ;CONVERT DECIMAL STRING TO OCTAL
(2) 001774 011234                       .PARMD
(3) 001774 104416                       PAWCH=TRAP+16         ;SET FLAG ECHO OR C LE
(2) 001776 010350                       .PAWCH
(3) 001776 104417                       DCLASM=TRAP+17        ;CLEAR DEVICE, SET MAINT. BIT IF I MODE
(2) 002000 006334                       .DCLASM
(3) 002000 104420                       SHIFT=TRAP+20         ;CALL TO ROTATE LINE POINTER
(2) 002002 006400                       .SHIFT
(3) 002002 104421                       LPRSET=TRAP+21        ;CALL TO SET UP LPR DEVICE REGISTER
(2) 002004 006416                       .LPRSET
(3) 002004 104422                       BUFSET=TRAP+22        ;CALL TO ZERO BUFFER AREA
(2) 002006 006456                       .BUFSET
(1)                                     ;:-----
(1)                                     ;:*****
(1)

```

```

(1)                                     :DZV11 VECTOR AND REGISTER INDIRECT POINTERS
(1)                                     :WORKING AREA
(1)
(1) 002010 160040 DZVCSR: 160040 :R/W
(1) 002012 160041 HDZVCSR:160041 :R/W
(1) 002014 160042 DZVRBUF:160042 :READ ONLY
(1) 002016 160043 HDZVRBUF:160043 :READ ONLY
(1) 002020 160042 DZVLPR: 160042 :WRITE ONLY
(1) 002022 160043 HDZVLPR:160043 :WRITE ONLY
(1) 002024 160044 DZVTCR: 160044 :R/W
(1) 002026 160045 HDZVTCR:160045 :R/W
(1) 002030 160046 DZVMSR: 160046 :READ ONLY
(1) 002032 160047 HDZVMSR:160047 :READ ONLY
(1) 002034 160046 DZVTDR: 160046 :WRITE ONLY
(1) 002036 160047 HDZVTDR:160047 :WRITE ONLY
(1)
(1)                                     :DEFAULT DZV VECTORS
(1)
(1) 002040 000300 DZVRIV: 300 :REC INTR VECTOR
(1) 002042 000302 DZVRIS: 302 :REC INTR STATUS
(1) 002044 000304 DZVTIV: 304 :XMIT INTR VECTOR
(1) 002046 000306 DZVTIS: 306 :XMIT INTR STATUS
(1)
(1)

```

(1)			
(1)			:TIME TABLE FOR RELATIVE TIMING TESTS
(1)			:-----
(1)			
(1)	002050		TMTBL:
(1)	002050	000000	T50: 0
(1)	002052	000000	T75: 0
(1)	002054	000000	T110: 0
(1)	002056	000000	T134: 0
(1)	002060	000000	T150: 0
(1)	002062	000000	T300: 0
(1)	002064	000000	T600: 0
(1)	002066	000000	T1200: 0
(1)	002070	000000	T1800: 0
(1)	002072	000000	T2000: 0
(1)	002074	000000	T2400: 0
(1)	002076	000000	T3600: 0
(1)	002100	000000	T4800: 0
(1)	002102	000000	T7200: 0
(1)	002104	000000	T9600: 0
(1)	002106	000000	TEIGHT:0
(1)	002110	000000	TSEVEN: 0
(1)	002112	000000	TSIX: 0
(1)	002114	000000	TFIVE: 0



```

(1)
(1)
(1) 002360 104403 :GET THE BASE ADDRESS OF THE DZV11'S
(2) 002360 104403 GETCSR= . : POINTER FOR FALCON TWEAKER. ;;GPA
(2) 002362 003052 INSTR :CALL THE STRING INPUT ROUTINE
(2) 002364 104405 91$ :POINTER TO MESSAGE TO BE PRINTED
(2) 002366 160000 PARAM :CALL THE OCTAL TO ASCII CONVERT ROUTINE
(2) 002370 163770 160000 :LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 002372 001500 163770 :HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 002374 007 DZCRO :POINTER TO MAP LOCATION TO BE FILLED
(2) 002375 001 .BYTE 7 :MASK OF INVALID BITS FOR THIS PARAMETER
(1) 002376 013737 001500 001174 .BYTE 1 :NUMBER OF PARAMETERS TO STORE
(1) MOV DZCRO,$BASE :COPY BASE ADDRESS TO ETABLE

(1)
(1)
(1) 002404 104403 :GET THE BASE VECTOR ADDRESS
(2) 002404 104403 GETVEC= . : POINTER FOR FALCON TWEAKER. ;;GPA
(2) 002406 003116 INSTR :CALL THE STRING INPUT ROUTINE
(2) 002410 104405 92$ :POINTER TO MESSAGE TO BE PRINTED
(2) 002412 000300 PARAM :CALL THE OCTAL TO ASCII CONVERT ROUTINE
(2) 002414 000776 300 :LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 002416 001502 776 :HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 002420 003 DZVCO :POINTER TO MAP LOCATION TO BE FILLED
(2) 002421 001 .BYTE 3 :MASK OF INVALID BITS FOR THIS PARAMETER
(1) 002422 013737 001502 001170 .BYTE 1 :NUMBER OF PARAMETERS TO STORE
(1) MOV DZVCO,$VECT1 :COPY VECTOR TO ETABLE

(1)
(1)
(2) 002430 104403 :GET THE MODE OF OPERATION (E,I,S)
(2) 002432 003345 INSTR :CALL THE STRING INPUT ROUTINE
(2) 002434 104406 96$ :POINTER TO THE MESSAGE TO BE PRINTED
(2) 002436 001510 SETFLG :CALL THE MAINTENANCE FLAG SETUP ROUTINE
(1) MANTO :THIS IS THE FLAG BEING SETUP

(1)
(1)
(2) 002440 104403 :GET THE NUMBER OF DZV11'S RUNNING
(2) 002442 003302 INSTR :CALL THE STRING INPUT ROUTINE
(2) 002444 104405 95$ :POINTER TO MESSAGE TO BE PRINTED
(2) 002446 000001 PARAM :CALL THE OCTAL TO ASCII CONVERT ROUTINE
(2) 002450 000020 1 :LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 002452 001344 16. :HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 002454 000 $TMP1 :POINTER TO MAP LOCATION TO BE FILLED
(2) 002455 001 .BYTE 0 :MASK OF INVALID BITS FOR THIS PARAMETER
(1) .BYTE 1 :NUMBER OF PARAMETERS TO STORE

(1) 002456 012737 000017 001504 MOV #17,LINEO :SET UP DEFAULT LINES
(1) 002464 012737 017470 001506 MOV #17470,PARO :SET UP DEFAULT LPR PARAMETER

(1)
(1) 002472 032777 000010 176604 BIT #SW03,@SWR :RECEIVER ON; 19.2 KBAUD; 2STOP BITS; 8 BIT/CHAR
(1) 002500 001402 BEQ 30$ :DO YOU WANT PARAMETERS?
(1) 002502 004737 002662 JSR PC,65$ :IF NO, SKIP THE PARAMETER CALL
(1) 002506 012737 000001 001410 30$: MOV #1,SAVACTV :GET PARAMETERS
(1) 002514 113737 001344 001414 MOV $TMP1,DZVNUM :INITIALIZE ACTIVE DEVICE SELECTION PARAMETER
(1) 002522 005337 001344 35$: MOV $TMP1 :COPY THE NUMBER OF DEVICES
(1) 002526 001404 BEQ 40$ :$TMP1 CONTAINS THE COUNT OF UNINITIALIZED
(1) 002530 000261 SEC :SELECTED DEVICES
(1) 002532 006137 001410 ROL SAVACTV :SET A BIT FLAG TO INDICATE AN ACTIVE DEVICE
(1) 002536 000771 BR 35$ :POINT TO THE NEXT DEVICE
(1) 002540 013737 001410 001346 40$: MOV SAVACTV,$TMP2 :GO DO THIS PROCEDURE AGAIN
(1) 002546 012700 001500 MOV #DZCRO,R0 :# OF TIMES
:SET A POINTER TO THE SPECIFIED INFORMATION
    
```

CVDZB-B MACY11 30G(1063) 10-AUG-81 11:11 PAGE 25-19  
 CVDZBB.P11 10-AUG-81 10:56 PROGRAM INITIALIZATION AND START UP.

SEQ 0037

```

(1) 002552 012701 001512      MOV      #DZCR1,R1      ;POINT R1 TO THE REST OF THE MAP TABLE
(1) 002556 012702 001204      MOV      #SDDW0,R2     ;POINT TO ETABLE'S DEVICE DESCRIPTOR WORDS
(1) 002562 000241              CLC                    ;INITIALIZE THE 'C' BIT FOR A ROTATION
(1) 002564 006037 001346      ROR      STMP2         ;SKIP MAPPING SETUP FOR DEVICE 0- IT'S DONE
(1) 002570 006237 001346      45$:    ASR      STMP2         ;ISOLATE A SELECTION FLAG IN THE 'C' BIT
(1) 002574 103404              BCS      50$           ;IS THIS DEVICE SELECTED? IF YES, GO LOAD TABLE
(1) 002576 012711 177777      MOV      #-1,(R1)     ;TERMINATE THE LIST
(1) 002602 000137 003550      JMP      100$         ;GO TO THE NEXT BLOCK
(1) 002606 012011 50$:      MOV      (R0)+,(R1)   ;ADDRESS
(1) 002610 062721 000010      ADD      #10,(R1)+   ;POINT TO THE NEXT DZV11 ADDRESS VALUE
(1) 002614 012011              MOV      (R0)+,(R1)   ;VECTOR
(1) 002616 062721 000010      ADD      #10,(R1)+   ;POINT TO THE NEXT VECTOR VALUE
(1) 002622 012021              MOV      (R0)+,(R1)+  ;LINES
(1) 002624 012021              MOV      (R0)+,(R1)+  ;PARAMETERS
(1) 002626 012021              MOV      (R0)+,(R1)+  ;MAINTENANCE MODE
(1) 002630 000757              BR       45$
(1) 002632 032777 000010 176444 55$:    BIT      #SW03,@SWR   ;ASK PARAMETERS ?
(1) 002640 001002              BNE      60$           ;IF NO, GO DO AUTO SIZING
(1) 002642 000137 003550      JMP      100$         ;GO SET UP FOR AUTO SIZING
(1) 002646 004737 002662      60$:    JSR      PC,65$     ;GO ASK PARAMETERS
(1) 002652 105337 001422      DECB    INIFLG        ;INSURE NO AUTO SIZE IF QUESTIONS ANSWERED
(1) 002656 000137 003606      JMP      105$         ;GO TO THE NEXT BLOCK
(1)
(1)
(1)
(1) 002662 65$:      INSTR    ;CALL THE STRING INPUT ROUTINE
(2) 002662 104403 93$      ;POINTER TO MESSAGE TO BE PRINTED
(2) 002664 003157 PARAM    ;CALL THE OCTAL TO ASCII CONVERT ROUTINE
(2) 002666 104405 1       ;LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 002670 000001 17      ;HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 002672 000017 LINE0   ;POINTER TO MAP LOCATION TO BE FILLED
(2) 002674 001504 .BYTE 360 ;MASK OF INVALID BITS FOR THIS PARAMETER
(2) 002676 360 .BYTE 1 ;NUMBER OF PARAMETERS TO STORE
(2) 002677 001 CLRB   HDRFLG ;MAKE SURE THE CHANGES ARE PRINTED
(1) 002700 105037 001423
(1)
(1)
(1)
(1)
(1)
(1)
(1)
(1) 002704 005737 001510      TST      MANT0        ;IS STAGGERED THE MODE OF OPERATION?
(1) 002710 100021 85$      ;IF NOT, SKIP THIS SEGMENT
(1) 002712 013703 001504      MOV      LINE0,R3     ;GET A SCRATCH COPY OF THE ACTIVE LINES
(1) 002716 006003 70$:    ROR      R3           ;GET A LINE SELECTION BIT(EVEN NUMBER LINE)
(1) 002720 103410 80$      ;IF IT IS SELECTED, CHECK TO SEE IF THE NEXT IS TOO
(1) 002722 001414 85$      BEQ      85$          ;IF ALL HAVE BEEN CHECKED, CONTINUE PROCESSING
(1) 002724 006203 75$:    ASR      R3           ;IF IT IS 0,CHECK TO SEE IF THE NEXT IS TOO
(1) 002726 103373 70$      BCC     70$          ;IF THIS ONE'S 0 TOO, GO CHECK THE NEXT PAIR
(1) 002730 104402 001356      TYPE    ,SQUES        ;THIS IS AN INCORRECT PARAMETER
(1) 002734 104402 010154      TYPE    ,MBADLN       ;LET THE USER KNOW ABOUT IT
(1) 002740 000750 80$:    BR       65$          ;GO GET THE CORRECT PARAMETER
(1) 002742 001772 75$      BEQ     75$          ;IF ANOTHER FLAG ISN'T SET, THERE'S AN ERROR
(1) 002744 006203 80$:    ASR     R3           ;GET THE NEXT FLAG
(1) 002746 103370 75$      BCC     75$          ;IF IT ISN'T SET, THERE'S AN ERROR
(1) 002750 000241 70$:    CLC                    ;INITIALIZE THE 'C' BIT FOR TESTING OF THE NEXT PAIR
(1) 002752 000761 70$:    BR       70$          ;GO TEST THE NEXT PAIR OF FLAGS

```

```

(1)                                     :GET THE LINE PARAMETER REGISTER ARGUMENT
(1)
(1) 002754                               85$: INSTR          :CALL THE STRING INPUT ROUTINE
(2) 002754 104403                        94$          :POINTER TO MESSAGE TO BE PRINTED
(2) 002756 003232                        PARAM        :CALL THE OCTAL TO ASCII CONVERT ROUTINE
(2) 002760 104405                        0            :LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 002762 000000                        17          :HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 002764 000017                        PARO        :POINTER TO MAP LOCATION TO BE FILLED
(2) 002766 001506                        .BYTE      0 :MASK OF INVALID BITS FOR THIS PARAMETER
(2) 002770 000          .BYTE          1 :NUMBER OF PARAMETERS TO STORE
(2) 002771 001          MOV          #LINE0,R2 :POINT TO THE LINE SELECTION PARAMETER
(1) 002772 012702 001504                 MOV          #PARO,R3 :POINT TO THE CHOSEN PARAMETERS
(1) 002776 012703 001506                 MOV          (R3),R4  :USE BAUD RATE AS AN INDEX IN DELAY TABLE
(1) 003002 011304                 ASL          R4       :ALIGN INDEX ON WORD BOUNDARY
(1) 003004 006304                 MOV          DLYTBL(R4),DLYCNT :SET THE DELAY COUNT FOR THIS BAUD RATE
(1) 003006 016437 017066 006364         SWAB        (R3)     :PLACE IN HIGH BYTE
(1) 003014 000313                 BIS          #10070,(R3) :PLACE EXTRA PARAMETERS INTO LOC
(1) 003016 052713 010070                 MOV          (R2),12(R2) :LOAD THE LINES
(1) 003022 011262 000012                 MOV          (R3),12(R3) :LOAD THE PARAMETERS
(1) 003026 011363 000012                 ADD          #12,R2     :POINT TO THE NEXT SET
(1) 003032 062702 000012                 ADD          #12,R3     :... OF BOTH PARAMETERS
(1) 003036 062703 000012                 CMP          R3,#PAR17 :HAVE THE TABLE BOUNDARIES BEEN EXCEEDED?
(1) 003042 020327 001734                 BNE          90$       :IF NOT, GO LOAD SOME MORE PARAMETERS
(1) 003046 001365                 RTS          PC       :RETURN TO CALLING BLOCK
(1) 003050 000207
(1) 003052 030600 052123 041440 91$: .ASCIZ <200>/1ST CSR ADDRESS (16000:163770): /
(1) 003116 030600 052123 053040 92$: .ASCIZ <200>/1ST VECTOR ADDRESS (300:770): /
(1) 003157 200 044514 042516 93$: .ASCIZ <200>/LINES ACTIVE BY BIT <IN OCTAL>(001:17): /
(1) 003232 042200 043105 052501 94$: .ASCIZ <200>/DEFAULT BAUD RATE <IN OCTAL>(00:17): /
(1) 003302 021600 047440 020106 95$: .ASCIZ <200>/# OF DZV11'S <IN OCTAL> (1:20): /
(1) 003345 200 040515 047111 96$: .ASCII <200>/MAINTENANCE MODE/
(1) 003366 020200 042533 052130 .ASCII <200>/ [EXTERNAL <H325> (E)]/
(1) 003422 020200 044533 052116 .ASCII <200>/ [INTERNAL <DZVCSR03=1>(I)]/
(1) 003457 200 055440 052123 .ASCIZ <200>/ [STAGGERED <H329> (S)]: /
(1) 003516 042600 052116 051105 97$: .ASCIZ <200>/ENTER DELAY PARAMETER: /
(1) .EVEN
(1) 003550 003550 100$:
(1) 003550 122737 000377 001422 CMPB        #377,INIFLG :ONLY DO AUTO SIZE ON 1ST START
(1) 003556 001013 BNE          105$
(1) 003560 032777 000200 175516 BIT          #BIT7,@SWR :BIT7=1??
(1) 003566 001007 BNE          105$ :BR IF NO AUTO SIZE
(1) 003570 005737 017142 TST          KXTFLAG : KXT11 ?? :GPA
(1) 003574 001402 BEQ          1001$ : SKIP NEXT IF NOT :GPA
(1) 003576 000137 002334 JMP          20$ : YES, DON'T AUTO-SIZE :GPA
(1) 003602 1001$:
(1) 003602 004737 011364 JSR          PC,AUTO.SIZE :GO DO THE AUTO SIZE
(1) 003606 105737 001423 105$: TSTB        HDRFLG :HAS THE TABLE BEEN TYPED YET?
(1) 003612 001021 BNE          120$ :IF SO, DON'T TYPE IT AGAIN
(1) 003614 105337 001423 DECB        HDRFLG :INDICATE THAT THE TABLE WILL BE TYPED
(1) 003620 104402 010126 TYPE        ,XHEAD :TYPE MAP HEADER
(1) 003624 012700 001500 MOV          #DZV.MAP,R0 :SET POINTER
(1) 003630 010037 001344 110$: MOV          R0,$TMP1 :POINT TO THE MAP LOCATION
(1) 003634 012037 001346 MOV          (R0)+,$TMP2 :SET DATA
(1) 003640 022737 177777 001346 CMP          #-1,$TMP2 :END OF LIST?
(1) 003646 001403 BEQ          120$ :BR IF YES
(1) 003650 104411 115$: CONVRT :CALL THE OCTAL TO ASCII CONVERSION ROUTINE

```

```

(1) 003652 010216 XSTATQ ;CONVERT THE DATA AT THIS ADDRESS
(1) 003654 000765 BR 110$ ;GO PRINT THE NEXT PARAMETER
(1) 003656 013737 001410 001406 120$: MOV SAVACTV,DZVACTV ;COPY BIT MAP OF ACTIVE DEVICES
(1) 003654 013737 001414 001416 MOVB DZVNUM,SAVNO ;COPY NO. OF DEVICES IN THE SYSTEM
(1) 003672 032777 000100 175404 BIT #SW06,@SWR ;DESELECT SPECIFIC DEVICES??
(1) 003700 001431 BEQ 135$ ;BR IF NO.
(1) 003702 121$: INSTR ;CALL THE STRING INPUT ROUTINE
(2) 003702 104403 MNEW ;POINTER TO MESSAGE TO BE PRINTED
(2) 003704 010044 PARAM ;CALL THE OCTAL TO ASCII CONVERT ROUTINE
(2) 003706 104405 1 ;LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 003710 000001 177777 ;HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 003712 177777 DZVACTV ;POINTER TO MAP LOCATION TO BE FILLED
(2) 003714 001406 .BYTE 0 ;MASK OF INVALID BITS FOR THIS PARAMETER
(2) 003716 000 .BYTE 1 ;NUMBER OF PARAMETERS TO STORE
(1) 003720 023737 001406 001410 CMP DZVACTV,SAVACTV ;IS VALUE VALID?
(1) 003726 101403 BLOS 122$ ;IF YES BRANCH
(1) 003730 104402 007716 TYPE ,MERR3 ;IF NOT TYPE ERROR
(1) 003734 000762 BR 121$ ;THEN REASK QUESTION
(1) 003736 105037 001416 001344 122$: CLR SAVNO ;INITIALIZE NO. OF ACTIVE DEVICES
(1) 003742 013737 001406 001344 MOV DZVACTV,$TMP1 ;COPY BIT MAP OF ACTIVE DEVICES
(1) 003750 006237 001344 126$: ASR $TMP1 ;ROTATE OUT AN ACTIVE BIT
(1) 003754 103002 BCC 127$ ;IF NOT ACTIVE SKIP RECORDING IT
(1) 003756 105237 001416 INCB SAVNO ;INCREMENT NO. OF ACTIVE DEVICES
(1) 003762 001372 BNE 127$ ;IF NOT DONE GO CONTINUE
(1) 003764 032777 000020 175312 135$: BIT #SW04,@SWR ;CHECK TO SEE IF DELAY COUNT CHANGES
(1) 003772 001407 BEQ 140$ ;IF NOT, GO CLEAR VECTOR AREA
(2) 003774 104403 INSTR ;CALL THE STRING INPUT ROUTINE
(2) 003776 003516 97$ ;POINTER TO MESSAGE TO BE PRINTED
(2) 004000 104405 PARAM ;CALL THE OCTAL TO ASCII CONVERT ROUTINE
(2) 004002 000001 1 ;LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 004004 177777 177777 ;HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
(2) 004006 006364 DLYCNT ;POINTER TO MAP LOCATION TO BE FILLED
(2) 004010 000 .BYTE 0 ;MASK OF INVALID BITS FOR THIS PARAMETER
(2) 004011 001 .BYTE 1 ;NUMBER OF PARAMETERS TO STORE
(1) 004012 012700 000300 140$: MOV #300,R0 ;PREPARE TO CLEAR THE FLOATING
(1) 004016 012701 000302 MOV #302,R1 ;VECTOR AREA. 300-776
(1) 004022 010120 145$: MOV R1,(R0)+ ;START PUTTING 'PC+2 - HALT'
(1) 004024 005021 CLR (R1)+ ;IN VECTOR AREA.
(1) 004026 022021 CMP (R0)+,(R1)+ ;POP POINTERS
(1) 004030 005737 017142 TST KXTFLAG ; IF FALCON... ::GPA
(1) 004034 001403 BEQ 1002$ ;:GPA
(1) 004036 020027 000400 CMP R0,#400 ;...QUIT AT 400. ;:GPA
(1) 004042 000402 402 ; SKJP NEXT ;:GPA
(1) 004044 1002$: CMP #1000,R0 ;ALL DONE??
(1) 004050 001364 BNE 145$ ;BR IF NO.
(1) ;
(1) ;TEST START AND RESTART
(1) ;-----
(1) ;
(1) .BEGIN: MOV #STACK,SP ;SET UP STACK
(1) 004052 012706 001120 MTPS #TASK ;CHECK OUT INTERRUPTS
(1) 004056 106427 000200 TST @42 ;IS PROGRAM UNDER MONITOR CONTROL
(1) 004062 005737 000042 BNE 2$ ;BR IF YES
(1) 004066 001015 2$ BIT #BIT2,@SW? ;CHECK FOR LOCK ON TEST
(1) 004070 032777 000004 175206
    
```



```

(1) 004076 001406          BEQ      1$          :BR IF NO LOCK DESIRED.
(1) 004100 104402 007742   TYPE     ,MLOCK     :TYPE LOCK SELECTED.
(1) 004104 012737 000240 004374   MOV     #NOP,TTST   :ADJUST SCOPE ROUTINE.
(1) 004112 000403          BR       2$          :CONTINUE ALONG.
(1) 004114 013737 004622 004374 1$:   MOV     BRW,TTST    :PREPARE NORMAL SCOPE ROUTINE
(1) 004122 012737 010530 001252 2$:   MOV     #CYCLE,$LPADR :START AT "CYCLE" FIND WHICH DEVICE TO TEST
(1) 004130 113737 001416 001415   MOVB   SAVNO,SAVNUM :COPY NO. OF ACTIVE DEVICES
(1) 004136 104402 007633   TYPE   ,MR         :TYPE "RUNNING"
(1) 004142 000177 175104   JMP    @SLPADR     :START TESTING
2729          ;;GPA  PRGEND DZV11,<END PASS DVDZB-A >,10.

```

```

2730
(2)
(2)
(2)
(2)
(3)
(3)
(4)
(3)
(3)
(3)
(3)
(5) 004146
(5) 004146 000004
(5) 004150 005037 001262
(5) 004154 105037 001247
(5) 004160 104402 007607
(5) 004164 104402 007771
(5) 004170 104412 004332
(5) 004174 104402 007777
(5) 004200 104412 004340
(5) 004204 005237 001126
(5) 004210 104402 010005
(5) 004214 104412 004346
(5) 004220 005337 001126
(5) 004224 104402 010016
(5) 004230 104412 004354
(5) 004234 005237 001130
(5) 004240 105377 001415
(5) 004244 0G10
(5) 004246 113737 001416 001415
(3) 004254 005037 001354
(3) 004260 005237 001126
(3) 004264 042737 100000 001126
(3) 004272 005327
(3) 004274 000001
(3) 004276 003013
(3) 004300 012737
(3) 004302 000001
(3) 004304 004274
(3) 004306 013700 000042
(3) 004312 001405
(3) 004314 000005
(3) 004316 004710
(3) 004320 000240
(3) 004322 000240
(3) 004324 000240
(3) 004326
(3) 004326 000137
(3) 004330 010530
(2)
(2) 004332 000001
(2) 004334 006 002
(2) 004336 002010
(2) 004340 000001
(2) 004342 003 002

```

```

:END OF PASS
:TYPE NAME OF TEST
:UPDATE PASS COUNT
:CHECK FOR EXIT TO ACT-11
:RESTART TEST
.SBTTL END OF PASS ROUTINE

:*****
:*INCREMENT THE PASS NUMBER ($PASS)
:*IF THERES A MONITOR GO TO IT
:*IF THERE ISN'T JUMP TO CYCLE

$EOP:
SCOPE
CLR $ERRPC ;CLEAR LAST ERROR PC
CLRB $ERFLG ;CLEAR ERROR FLAG
TYPE ,MEPASS ;TYPE END PASS
TYPE ,MCSRX ;TYPE CSR
CNVRT ,XCSR ;SHOW IT
TYPE ,MVECX ;TYPE VECTOR
CNVRT ,XVEC ;SHOW IT
INC $PASS ;RAISE PASS COUNT
TYPE ,MPASSX ;TYPE PASSES
CNVRT ,XPASS ;SHOW IT
DEC $PASS ;RESTORE PASS COUNT
TYPE ,MERRX ;TYPE ERRORS
CNVRT ,XERR ;SHOW IT
INC $DEVCT ;INC DEVCNT FOR APT
DECB SAVNUM ;ARE ALL DEVICES TESTED?
BNE $DOAGN ;BR IF NO.
MOVB SAVNO,SAVNUM ;RESTORE THE COUNT
CLR $TIMES ;ZERO THE NUMBER OF ITERATIONS
INC $PASS ;INCREMENT THE PASS NUMBER
BIC #10000,$PASS ;DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;LOOP?

$EOPCT: .WORD 1
BGT $DOAGN ;:YES
MOV (PC)+,a(PC)+ ;:RESTORE COUNTER

$ENDCT: .WORD 1

$GET42: MOV a#42,R0 ;:GET MONITOR ADDRESS
BEQ $DOAGN ;:BRANCH IF NO MONITOR
RESET ;:CLEAR THE WORLD
SENDAD: JSR PC,(R0) ;:GO TO MONITOR
NOP ;:SAVE ROOM
NOP ;:FOR
NOP ;:ACT11

$DOAGN:
SRTNAD: JMP a(PC)+ ;:RETURN
.WORD CYCLE

XCSR: 1
.BYTE 6,2
DZVCSR

XVEC: 1
.BYTE 3,2

```

(2) 004344 002040  
 (2) 004346 000001  
 (2) 004350 006 002  
 (2) 004352 001126  
 (2) 004354 000001  
 (2) 004356 006 002  
 (2) 004360 G01256

DZVRIV  
 XPASS: 1  
 .BYTE 6,2  
 \$PASS  
 XERR: 1  
 .BYTE 6,2  
 \$ERTTL

:SCOPE LOOP AND ITERATION HANDLER  
 :-----

.SBTTL SCOPE HANDLER ROUTINE

\*\*\*\*\*  
 \*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT  
 \*AND LOAD THE TEST NUMBER(\$TSTN) INTO THE DISPLAY REG.(DISPLAY<7:0>)  
 \*AND LOAD THE ERROR FLAG (\$ERFLG) INTO DISPLAY<15:08>  
 \*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:  
 \*SW14=1 LOOP ON TEST  
 \*SW11=1 INHIBIT ITERATIONS  
 \*CALL SCOPE ::SCOPE=IOT  
 \* SCOPE

(3) 004362  
 (5) 004362 005037 001262  
 (5) 004366 022716 012072  
 (5) 004372 001413  
 (5) 004374 000406  
 (5) 004376 105777 174706  
 (5) 004402 100067  
 (5) 004404 017766 174702 177776  
 (3) 004412 032777 040000 174664  
 (3) 004420 001060  
 (3) 004422 000416  
 (3) 004424 013746 000004  
 (3) 004430 012737 004450 000004  
 (3) 004436 005737 177060  
 (3) 004442 012637 000004  
 (3) 004446 000436  
 (3) 004450 022626  
 (3) 004452 012637 000004  
 (3) 004456 000441  
 (3) 004460  
 (3) 004460 105737 001247  
 (3) 004464 001404  
 (3) 004466 105037 001247  
 (3) 004472 005037 001354  
 (3) 004476 032777 004000 174600  
 (3) 004504 001011  
 (3) 004506 005737 001126  
 (3) 004512 001406  
 (3) 004514 005237 001250  
 (3) 004520 023737 001354 001250  
 (3) 004526 002015

\$SCOPE:  
 .SCOPE: CLR \$ERRPC ;CLEAR LAST ERROR PC.  
 CMP #TST1+2,(SP) ;IS THIS THE SCOPE AT THE BEGINNING OF TST1?  
 BEQ \$XTSTR ;IF SO, DON'T LOOP ON IT  
 TTST: BR 1\$ ;GOTO 1\$ (IF LOCK SW02=1; THIS LOC =240)  
 TSTB @STKS ;KEYBOARD DONE?  
 BPL \$OVER ;BR IF NO. (LOCK: HIT KEY TO GOTO NEXT TEST)  
 MOV @STKB,-2(SP) ;CLEAR DONE BIT  
 1\$: BIT #BIT14,@SWR ;LOOP ON PRESENT TEST?  
 BNE \$OVER ;YES IF SW14=1  
 ;\*\*\*\*\*START OF CODE FOR THE XOR TESTER\*\*\*\*\*  
 \$XTSTR: BR 6\$ ;IF RUNNING ON THE 'XOR' TESTER CHANGE  
 ; THIS INSTRUCTION TO A 'NOP' (NOP=240)  
 MOV @ERRVEC,-(SP) ;SAVE THE CONTENTS OF THE ERROR VECTOR  
 MOV #5,@ERRVEC ;SET FOR TIMEOUT  
 TST @#177060 ;TIME OUT ON XOR?  
 MOV (SP)+,@ERRVEC ;RESTORE THE ERROR VECTOR  
 BR \$SVLAD ;GO TO THE NEXT TEST  
 5\$: CMP (SP)+,(SP)+ ;CLEAR THE STACK AFTER A TIME OUT  
 MOV (SP)+,@ERRVEC ;RESTORE THE ERROR VECTOR  
 BR \$OVER ;LOOP ON THE PRESENT TEST  
 6\$;\*\*\*\*\*END OF CODE FOR THE XOR TESTER\*\*\*\*\*  
 2\$: TSTB \$ERFLG ;HAS AN ERROR OCCURRED?  
 BEQ 3\$ ;BR IF NO  
 4\$: CLRB \$ERFLG ;ZERO THE ERROR FLAG  
 CLR \$TIMES ;CLEAR THE NUMBER OF ITERATIONS TO MAKE  
 3\$: BIT #BIT11,@SWR ;INHIBIT ITERATIONS?  
 BNE 1\$ ;BR IF YES  
 TST \$PASS ;IF FIRST PASS OF PROGRAM  
 BEQ 1\$ ; INHIBIT ITERATIONS  
 INC \$ICNT ;INCREMENT ITERATION COUNT  
 CMP \$TIMES,\$ICNT ;CHECK THE NUMBER OF ITERATIONS MADE  
 BGE \$OVER ;BR IF MORE ITERATION REQUIRED

```

(3) 004530 012737 000001 001250 1$: MOV #1,$ICNT ;;REINITIALIZE THE ITERATION COUNTER
(3) 004536 013737 004624 001354 MOV $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
(3) 004544 105237 001246 $SVLAD: INCB $STNM ;;COUNT TEST NUMBERS
(3) 004550 113737 001246 001124 MOV $STNM,$TESTN ;;SET TEST NUMBER IN APT MAILBOX
(3) 004556 011637 001252 MOV (SP),$LPADR ;;SAVE SCOPE LOOP ADDRESS
(3) 004562 013777 001246 174516 $OVER: MOV $STNM,@DISPLAY ;;DISPLAY TEST NUMBER
(3) 004570 013716 001252 MOV $LPADR,(SP) ;;FUDGE RETURN ADDRESS
(5) 004574 004737 007126 JSR PC,$ERV.G ;;FIND OUT IF ^G WAS TYPED
(5) 004600 105037 001424 CLR $MNTFLG ;;CLEAR THE MAINTENANCE BIT SETTER AFTER EACH TEST
(5) 004604 005737 001372 TST MODE ;;HAS THE MODE BEEN CHANGED?
(5) 004610 001003 BNE 4$ ;;IF NOT INTERNAL, GO DO A TEST
(5) 004612 112737 000010 001424 MOV $MNTFLG ;;IF INTERNAL MODE NOW, SET THE MAINTENANCE BIT
(5) 004620 000002 4$: RTI ;;GO DO THE TEST
(5) 004622 000406 BRW: 406
(3) 004624 000005 $MXCNT: 5 ;;MAX. NUMBER OF ITERATIONS
(1)
(1) ;CHECK FOR FREEZE ON CURRENT DATA
(1) ;-----
(1)
(1) 004626 032777 001000 174450 .SCOPI: BIT #SW09,@SWR ;;IS SW09=1(SET)?
(1) 004634 001405 BEQ 1$ ;;BR IF NOT SET.
(1) 004636 005737 001364 TST LOCK ;;IS THERE A TIGHT LOOP SPECIFIED?
(1) 004642 001402 BEQ 1$ ;;IF NO, RETURN
(1) 004644 013716 001364 MOV LOCK,(SP) ;;IF YES, GOTO THE ADDRESS IN LOCK.
(1) 004650 000002 1$: RTI ;;GO BACK.
(1)
(1) 004652 032777 010000 174424 .TYPE: BIT #SW12,@SWR ;;INHIBIT ALL PRINTOUT??
(1) 004660 001403 BEQ $TYPE ;;IF NOT, GO TYPE
(1) 004662 062716 000002 ADD #2,(SP) ;;SKIP OVER MESSAGE POINTER
(1) 004666 000002 RTI ;;RETURN TO WHERE PROCEDURE WAS INVOKED
(2)
(2) .SBTTL TYPE ROUTINE
(2)
(2) ;*****
(2) ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
(2) ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
(2) ;*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
(2) ;*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
(2) ;*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
(2) ;*
(2) ;*CALL:
(2) ;*1) USING A TRAP INSTRUCTION
(2) ;* TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
(2) ;*OR
(2) ;* TYPE
(2) ;* MESADR
(2) ;*
(2)
(2) 004670 105737 001323 $TYPE: TSTB $TFPLG ;;IS THERE A TERMINAL?
(2) 004674 100002 BPL 1$ ;;BR IF YES
(2) 004676 000000 HALT ;;HALT HERE IF NO TERMINAL
(2) 004700 000430 BR 3$ ;;LEAVE
(2) 004702 010046 1$: MOV R0,-(SP) ;;SAVE R0
(2) 004704 017600 000002 MOV @2(SP),R0 ;;GET ADDRESS OF ASCIZ STRING
(2) 004710 122737 000001 001140 CMPB #APTENV,$ENV ;;RUNNING IN APT MODE
(2) 004711 001011 BNE 62$ ;;NO,GO CHECK FOR APT CONSOLE
(2) 004720 132737 000100 001141 BITB #APTPOOL,$ENVM ;;SPOOL MESSAGE TO APT

```



```

(2) 005154          10$:
(2) 005154 105777 174134      TSTB  @STPS          ;;WAIT UNTIL PRINTER IS READY      :MJD001
(2) 005160 111375          BPL  10$
(2) 005162 111677 000002 174126  MOVB  2(SP),@STPB    ;;LOAD CHAR TO BE TYPED INTO DATA REG.
(2) 005170 122766 000015 000002  CMPB  #CR,2(SP)     ;;IS CHARACTER A CARRIAGE RETURN?
(2) 005176 001003          BNE  1$             ;;BRANCH IF NO
(2) 005200 105037 005220      CLRB  $CHARCNT      ;;YES--CLEAR CHARACTER COUNT
(2) 005204 000406          BR   $TYPEX         ;;EXIT
(2) 005206 122766 000012 000002  1$:  CMPB  #LF,2(SP)     ;;IS CHARACTER A LINE FEED?
(2) 005214 001402          BEQ  $TYPEX         ;;BRANCH IF YES
(2) 005216 105227          INCB (PC)+         ;;COUNT THE CHARACTER
(2) 005220 000000          $CHARCNT: .WORD  0 ;;CHARACTER COUNT STORAGE
(2) 005222 000207          $TYPEX: RTS      PC

(2)
(2)
(2)
(3)
(2) 005224 112737 000001 005470  :*****
(2) 005232 112737 000001 005466  $ATY1: MOVB  #1,$FFLG  ;;TO REPORT FATAL ERROR
(2) 005240 000403          $ATY3: MOVB  #1,$MFLG  ;;TO TYPE A MESSAGE
(2) 005242 112737 000001 005470  BR   $ATYC
(2) 005250          $ATY4: MOVB  #1,$FFLG  ;;TO ONLY REPORT FATAL ERROR
(2) 005250 010046          $ATYC:
(4) 005250 010146          MOV  R0,-(SP)      ;;PUSH R0 ON STACK
(4) 005252 010146          MOV  R1,-(SP)      ;;PUSH R1 ON STACK
(2) 005254 105737 005466          TSTB $MFLG        ;;SHO'LD TYPE A MESSAGE?
(2) 005260 001450          BEQ  5$            ;;IF NOT: BR
(2) 005262 122737 000001 001140  CMPB  #APTENV,$ENV  ;;OPERATING UNDER APT?
(2) 005270 001031          BNE  3$            ;;IF NOT: BR
(2) 005272 132737 000100 001141  BITB  #APTPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
(2) 005300 001425          BEQ  3$            ;;IF NOT: BR
(2) 005302 017600 000004          MOV  @4(SP),R0     ;;GET MESSAGE ADDR.
(2) 005306 062766 000002 000004  ADD  #2,4(SP)      ;;BUMP RETURN ADDR.
(2) 005314 005737 001120          1$:  TST  $MSGTYPE     ;;SEE IF DONE W/ LAST XMISSION?
(2) 005320 001375          BNE  1$            ;;IF NOT: WAIT
(2) 005322 010037 001134          MOV  R0,$MSGAD     ;;PUT ADDR IN MAILBOX
(2) 005326 105720          2$:  TSTB (R0)+        ;;FIND END OF MESSAGE
(2) 005330 001376          BNE  2$
(2) 005332 163700 001134          SUB  $MSGAD,R0     ;;SUB START OF MESSAGE
(2) 005336 006200          ASR  R0            ;;GET MESSAGE LNGTH IN WORDS
(2) 005340 010037 001136          MOV  R0,$MSGGLT    ;;PUT LENGTH IN MAILBOX
(2) 005344 012737 000004 001120  MOV  #4,$MSGTYPE   ;;TELL APT TO TAKE MSG.
(2) 005352 000413          BR   5$
(2) 005354 017637 000004 005400  3$:  MOV  @4(SP),4$     ;;PUT MSG ADDR IN JSR LINKAGE
(2) 005362 062766 000002 000004  ADD  #2,4(SP)      ;;BUMP RETURN ADDRESS
(4) 005370 013746 177776          MOV  177776,-(SP) ;;PUSH 177776 ON STACK
(2) 005374 004737 004670          JSR  PC,$TYPE     ;;CALL TYPE MACRO
(2) 005400 000000          4$:  .WORD  0
(2) 005402          5$:
(2) 005402 105737 005470          10$: TSTB  $FFLG        ;;SHOULD REPORT FATAL ERROR?
(2) 005406 001416          BEQ  12$          ;;IF NOT: BR
(2) 005410 005737 001140          TST  $ENV         ;;RUNNING UNDER APT?
(2) 005414 001413          BEQ  12$          ;;IF NOT: BR
(2) 005416 005737 001120          11$: TST  $MSGTYPE     ;;FINISHED LAST MESSAGE?
(2) 005422 001375          BNE  11$         ;;IF NOT: WAIT
(2) 005424 017637 000004 001122  MOV  @4(SP),$FATAL ;;GET ERROR #
(2) 005432 062766 000002 000004  ADD  #2,4(SP)      ;;BUMP RETURN ADDR.

```

(2) 005440 005237 001120  
 (2) 005444 105037 005470  
 (2) 005450 105037 005467  
 (2) 005454 105037 005466  
 (4) 005460 012601  
 (4) 005462 012600  
 (2) 005464 000207  
 (2) 005466 000  
 (2) 005467 000  
 (2) 005470 000  
 (2) 005472  
 (2) 000200  
 (2) 000001  
 (2) 000100  
 (2) 000040

```

12$: INC      SMSGTYPE      ;; TELL APT TO TAKE ERROR
      CLRFB   $FFLG        ;; CLEAR FATAL FLAG
      CLRFB   $LFLG        ;; CLEAR LOG FLAG
      CLRFB   $MFLG        ;; CLEAR MESSAGE FLAG
      MOV     (SP)+,R1      ;; POP STACK INTO R1
      MOV     (SP)+,R0      ;; POP STACK INTO R0
      RTS     PC           ;; RETURN
$MFLG: .BYTE 0            ;; MESSG. FLAG
$LFLG:  .BYTE 0            ;; LOG FLAG
$FFLG:  .BYTE 0            ;; FATAL FLAG
      .EVEN
APTSIZE=200
APTENV=001
APTSPOOL=100
APTCSUP=040

```

:STRING INPUT ROUTINE

(1)  
 (1)  
 (1)  
 (1) 005472 010346  
 (1) 005474 010446  
 (1) 005476 017637 000004 005514  
 (1) 005504 062766 000002 000004  
 (1) 005512 104402  
 (1) 005514 000000  
 (1) 005516 012704 010424  
 (1) 005522 012703 000007  
 (1) 005526 105777 173556  
 (1) 005532 100375  
 (1) 005534 117714 173552  
 (1) 005540 142714 000200  
 (1) 005544 122427 000015  
 (1) 005550 001417  
 (1) 005552 105777 173536  
 (1) 005556 100375  
 (1) 005560 017777 173526 173530  
 (1) 005566 005303  
 (1) 005570 001356  
 (1) 005572 012604  
 (1) 005574 012603  
 (1) 005576 010346  
 (1) 005600 010446  
 (1) 005602 104402 001356  
 (1) 005606 000741  
 (1) 005610 012604  
 (1) 005612 012603  
 (1) 005614 000002

```

:-----
.INSTR: MOV     R3,-(SP)      ;SAVE R3 ON STACK
        MOV     R4,-(SP)      ;SAVE R4 ON STACK
        MOV     @4(SP),.MSG    ;GET THE ADDRESS OF THE MESSAGE TO BE PRINTED
        ADD     #2,4(SP)      ;POINT TO INSTRUCTION AFTER ADDRESS POINTER
.INST1: TYPE                                ;PRINT THE MESSAGE
.MSG:   0                                  ;MESSAGE IS POINTED TO FROM HERE
        MOV     #INBUF,R4      ;POINT R4 TO THE INPUT BUFFER
        MOV     #7,R3          ;SET THE MAXIMUM NUMBER OF CHARACTERS ALLOWED
1$:     TSTB    @$TKS          ;HAS A CHARACTER BEEN RECEIVED?
        RPL     1$            ;IF NO, KEEP WAITING FOR IT
        MOVB   @$TKB,(R4)     ;IF YES, SAVE IT IN THE INPUT BUFFER
        BICB   #200,(R4)     ;KEEP ONLY THE 7-BIT ASCII INFORMATION
        CMPB   (R4)+,#15     ;IS THIS CHARACTER A LINE FEED?
        BEQ    INSTR2        ;IF SO, TERMINATE THE INPUT SEQUENCE
2$:     TSTB    @$TPS          ;IF NOT, CHECK TO SEE IF THE CHARACTER CAN PRINT
        BPL     2$            ;IF WE CAN'T, WAIT UNTIL WE CAN
        MOV     @$TKB,@$TPB    ;ECHO THE CHARACTER BACK
        DEC     R3            ;REDUCE THE NUMBER OF CHARACTERS RECEIVED
        BNE    1$            ;IF WE DON'T HAVE 7, GO GET SOME MORE
        MOV     (SP)+,R4      ;IF WE HAVE 7, RESTORE R4
        MOV     (SP)+,R3      ;RESTORE R3
.INSTE: MOV     R3,-(SP)      ;SAVE R3 ON THE STACK
        MOV     R4,-(SP)      ;SAVE R4 ON THE STACK
        TYPE    .QUES        ;PRINT A QUESTION MARK... WHAT'S GOING ON?
        BR     .INST1        ;GO PRINT THE MESSAGE AGAIN
INSTR2: MOV     (SP)+,R4      ;RESTORE R4
        MOV     (SP)+,R3      ;RESTORE R3
        RTI                    ;RETURN TO THE MAIN PROCEDURE

```

:CONVERT ASCII STRING TO OCTAL

(1)  
 (1)  
 (1)  
 (1) 005616 010546  
 (1) 005620 010446  
 (1) 005622 016605 000004  
 (1) 005626 012537 006006  
 (1) 005632 012537 006010

```

.PARAM: MOV     R5,-(SP)      ;SAVE R5 ON THE STACK
        MOV     R4,-(SP)      ;SAVE R4 ON THE STACK
        MOV     4(SP),R5      ;GET THE SETUP INFORMATION POINTER
        MOV     (R5)+,LOLIM    ;SET THE LOW LIMIT FOR THE INPUT
        MOV     (R5)+,HILIM    ;SET THE HIGH LIMIT FOR THE INPUT

```

```

(1) 005636 012537 006012      MOV      (R5)+,DEVADR      ;SAVE THE ADDRESS WHERE THE RESULT WILL BE STORED
(1) 005642 112537 006014      MOVB     (R5)+,LOBITS     ;GET THE MASK OF THE INCORRECT BITS
(1) 005646 112537 006015      MOVB     (R5)+,ADRCNT     ;GET THE COUNT OF ITEMS TO BE STORED
(1) 005652 010566 000004      MOV      R5,4(SP)        ;POINT TO WHERE MAIN LINE PROGRAM WILL RESUME
(1) 005656 005005      PARAM1: CLR      R5        ;INITIALIZE THE ASCII TO OCTAL RESULT WORD
(1) 005660 012704 010424      MOV      #INBUF,R4       ;POINT TO THE INPUT BUFFER
(1) 005664 122714 000015      CMPB     #15,(R4)        ;IS THIS CHARACTER A CARRIAGE RETURN?
(1) 005670 001420      BEQ      PARERR          ;IF SO, PRINT THE MESSAGE AGAIN
(1) 005672 121427 000060      1$:      CMPB     (R4),#60     ;IS THIS CHARACTER BELOW THE NUMERIC RANGE?
(1) 005676 002415      BLT      PARERR          ;IF SO, GO PRINT THE MESSAGE AGAIN
(1) 005700 121427 000067      CMPB     (R4),#67     ;IS THIS CHARACTER ABOVE THE NUMERIC RANGE?
(1) 005704 003012      BGT      PARERR          ;IF SO, GO PRINT THE MESSAGE AGAIN
(1) 005706 142714 000060      BICB     #60,(R4)        ;ISOLATE THE NUMBER THE CHARACTER REPRESENTS
(1) 005712 152405      BISB     (R4)+,R5        ;CONCATENATE THESE BITS TO THE ALREADY EXISTING STRING
(1) 005714 122714 000015      CMPB     #15,(R4)        ;IS THE NEXT CHARACTER A CARRIAGE RETURN?
(1) 005720 001406      BEQ      LIMITS         ;IF SO, GO SEE IF NUMBER IS WITHIN LIMITS
(1) 005722 006305      ASL      R5              ;CLEAR BIT POSITION 0, MOVE EXISTING STRING TO LEFT
(1) 005724 006305      ASL      R5              ;CLEAR POSITION 1, MOVE STRING TO LEFT AGAIN
(1) 005726 006305      ASL      R5              ;MOVE THE STRING ONE MORE TIME TO MAKE ROOM FOR
(1)                                ;NEXT THREE BITS
(1) 005730 000760      BR       1$              ;GO GET THE NEXT CHARACTER
(1) 005732 104404      PARERR: INSTER          ;THERE WAS AN ERROR... GO PRINT MESSAGE AGAIN
(1) 005734 000750      BR       PARAM1         ;TRY GETTING THE PARAMETERS AGAIN
(1)                                ;TEST TO SEE IF NUMBER IS WITHIN LIMITS
(1)                                ;-----
(1) 005736 020537 006010      LIMITS: CMP      R5,HILIM ;DOES RESULT EXCEED ITS MAXIMUM CORRECT VALUE?
(1) 005742 101373      BHI      PARERR          ;IF YES, GO PRINT THE MESSAGE AGAIN
(1) 005744 020537 006006      CMP      R5,LOLIM        ;IS THE RESULT LOWER THAN ALLOWED?
(1) 005750 103770      BLO      PARERR          ;IF YES, GO PRINT THE MESSAGE AGAIN
(1) 005752 133705 006014      BITB     LOBITS,R5       ;ARE ANY INCORRECT BITS SET IN THE RESULT?
(1) 005756 001365      BNE      PARERR          ;IF SO, GO PRINT THE MESSAGE AGAIN
(1)                                ;STORE NUMBER AT SPECIFIED ADDRESS
(1) 005760 013704 006012      1$:      MOV      DEVADR,R4     ;POINT TO THE LOCATION WHERE THE RESULT WILL BE STORED
(1) 005764 010524      MOV      R5,(R4)+        ;STORE THE RESULT
(1) 005766 062705 000002      ADD      #2,R5           ;CALCULATE THE NEXT DATUM
(1) 005772 105337 006015      DECB     ADRCNT          ;REDUCE COUNT OF STORED RESULTS. IS IT EXCEEDED?
(1) 005776 001372      BNE      1$              ;IF NOT, GO STORE THE NEXT DATUM
(1) 006000 012604      MOV      (SP)+,R4        ;RESTORE R4
(1) 006002 012605      MOV      (SP)+,R5        ;RESTORE R5
(1) 006004 000002      RTI                     ;RETURN TO THE MAIN PROGRAM
(1) 006006 000000      LOLIM:  0                ;LOWEST ACCEPTABLE VALUE
(1) 006010 000000      HILIM:  0                ;HIGHEST ACCEPTABLE
(1) 006012 000000      DEVADR: 0                ;LOCATION WHERE RESULT WILL BE STORED
(1) 006014 000      LOBITS: .BYTE 0          ;INCORRECT BITS MASK
(1) 006015 000      ADRCNT: .BYTE 0          ;COUNT OF ITEMS TO BE STORED
(1)                                ;SAVE PC OF TEST THAT FAILED AND R0-R5
(1)                                ;-----
(1) 006016 016637 000004 001404 .SAV05: MOV      4(SP),SAVPC ;SAVE R7 (PC)

```



```

(1)                                     :SAVE R0-R5
(1)
(1) 006024 010537 001340      SV05:  MOV     R5,$REG5      :SAVE R5
(1) 006030 010437 001336      MOV     R4,$REG4      :SAVE R4
(1) 006034 010337 001334      MOV     R3,$REG3      :SAVE R3
(1) 006040 010237 001332      MOV     R2,$REG2      :SAVE R2
(1) 006044 010137 001330      MOV     R1,$REG1      :SAVE R1
(1) 006050 010037 001326      MOV     R0,$REG0      :SAVE R0
(1) 006054 000002              RTI                    :LEAVE.

(1)                                     :RESTORE R0-R5
(1)
(1) 006056 013700 001326      .RES05: MOV     $REG0,R0      :RESTORE R0
(1) 006062 013701 001330      MOV     $REG1,R1      :RESTORE R1
(1) 006066 013702 001332      MOV     $REG2,R2      :RESTORE R2
(1) 006072 013703 001334      MOV     $REG3,R3      :RESTORE R3
(1) 006076 013704 001336      MOV     $REG4,R4      :RESTORE R4
(1) 006102 013705 001340      MOV     $REG5,R5      :RESTORE R5
(1) 006106 000002              RTI                    :LEAVE

(1)                                     :CONVERT OCTAL NUMBER TO ASCII AND OUTPUT TO TELEPRINTER
(1) -----
(1)
(1) 006110 104402 001357      .CONVR: TYPE     , $CRLF      :PRINT A CARRIAGE RETURN
(1) 006114 010046      .CNVRT: MOV     R0,-(SP)      :SAVE R0
(1) 006116 010146      MOV     R1,-(SP)      :SAVE R1
(1) 006120 010346      MOV     R3,-(SP)      :SAVE R3
(1) 006122 010446      MOV     R4,-(SP)      :SAVE R4
(1) 006124 010546      MOV     R5,-(SP)      :SAVE R5
(1) 006126 017601 000012      MOV     @12(SP),R1     :PLACE THE ADDRESS OF THE ARGUMENTS IN R1
(1) 006132 062766 000002 000012      ADD     #2,12(SP)     :POINT TO WHERE MAIN PROGRAM WILL RESUME
(1) 006140 012137 006264      MOV     (R1)+,WORDCNT :GET NUMBER OF WORDS TO BE PRINTED
(1) 006144 112105      1$:  MOV     (R1)+,R5     :GET THE NUMBER OF CHARACTERS TO BE PRINTED
(1) 006146 112100      MOV     (R1)+,R0     :GET THE NUMBER OF SPACES TO PRINT
(1) 006150 013104      MOV     @ (R1)+,R4    :COPY THE WORD TO BE CONVERTED
(1) 006152 110537 006266      MOV     R5,CHRCNT    :COPY THE CHARACTER COUNT
(1) 006156 010403      3$:  MOV     R4,R3      :COPY THE ARGUMENT WORD AGAIN
(1) 006160 042703 177770      BIC     #^C<7>,R3    :ISOLATE THREE BITS TO BE TREATED AS A CHARACTER
(1) 006164 062703 000060      ADD     #060,R3     :MAKE AN ASCII CHARACTER OUT OF THEM
(1) 006170 110346      MOV     R3,-(SP)    :SAVE THAT CHARACTER
(1) 006172 006004      ROR     R4          :MOVE THE NEXT THREE BITS INTO PLACE
(1) 006174 006204      ASR     R4          :MOVE THEM AGAIN
(1) 006176 006204      ASR     R4          :AND FINALLY A THIRD TIME
(1) 006200 005305      DEC     R5          :REDUCE CHARACTER COUNT.ARE ALL CHARACTERS
(1)                                     :BUILT?
(1) 006202 001365      BNE     3$         :IF NO, GO BUILD THE NEXT ONE.
(1) 006204 012703 010466      MOV     #MDATA,R3   :NOW POINT TO WHERE NUMBER WILL BE PRINTED FROM
(1) 006210 112623      4$:  MOV     (SP)+,(R3)+ :STORE THE CHARACTER, STARTING WITH THE MOST
(1) 006212 105337 006266      DECB   CHRCNT      :REDUCE COUNT. ARE ALL CHARACTERS TRANSFERRED?
(1) 006216 001374      BNE     4$         :IF NO, GO TRANSFER ANOTHER
(1) 006220 105700      TSTB   R0          :ARE ANY SPACES TO BE PRINTED?
(1) 006222 001404      BEQ    6$         :IF NO, DON'T SET UP ANY
(1) 006224 112723 000040      5$:  MOV     #040,(R3)+ :ADD A SPACE TO THE OUTPUT BUFFER
(1) 006230 105300      DECB   R0          :REDUCE THE COUNT. SHOULD WE PRINT MORE?
(1) 006232 001374      BNE     5$         :IF YES, GO ADD ANOTHER SPACE
(1) 006234 105013      6$:  CLRB   (R3)      :TERMINATE THE OUTPUT BUFFER WITH A ZERO

```

```

(1) 006236 104402 010466      TYPE      ,MDATA      ;PRINT THE STRING WE JUST BUILT
(1) 006242 005337 006264      DEC      WRDCNT      ;REDUCE THE WORD COUNT. ARE ANY MORE WORDS LEFT?
(1) 006246 001336              BNE      1$          ;IF YES, GO CONVERT THEM
(1) 006250 012605              MOV      (SP)+,R5    ;RESTORE R5
(1) 006252 012604              MOV      (SP)+,R4    ;RESTORE R4
(1) 006254 012603              MOV      (SP)+,R3    ;RESTORE R3
(1) 006256 012601              MOV      (SP)+,R1    ;RESTORE R1
(1) 006260 012600              MOV      (SP)+,R0    ;RESTORE R0
(1) 006262 000002              RTI                       ;RETURN TO THE MAIN PROGRAM
(1) 006264 000000      WRDCNT: 0
(1) 006266      000          CHR CNT: .BYTE
(1) 006267      000          SPACNT: .BYTE 0      ;NUMBER OF CHARACTERS TO PRINT
(1)                                ;NUMBER OF SPACES TO PRINT
(1) 006270 000000      BINWRD: 0
(1)
(1)                                ;TRAP DISPATCH SERVICE
(1)                                ;ARGUMENT OF TRAP IS EXTRACTED
(1)                                ;AND USED AS OFFSET TO OBTAIN POINTER
(1)                                ;TO SELECTED SUBROUTINE
(1)
(1) 006272 010046      .TRPSR: MOV      R0,-(SP)      ;SAVE R0. USE R0 TO FIND TRAP ROUTINE
(1) 006274 016600 000002      MOV      2(SP),R0      ;GET TRAP ADDRESS
(1) 006300 005740              TST      -(R0)          ;GET TRAP
(1) 006302 111000              MOV      (R0),R0        ;GET RIGHT BYTE OF TRAP (TRAP OFFSET)
(1) 006304 006300              ASL      R0              ;POSITION OFFSET FOR TABLE INDEXING
(1) 006306 016000 001742      MOV      .TRPTAB(R0),R0 ;PLACE INDEXED ADDRESS OF TABLE IN R0
(1) 006312 000200              RTS      R0              ;TRANSFER TO THAT ADDRESS AND RESTORE OLD R0
(1)
(1)                                ;DEVICE CLEAR ROUTINE
(1)                                ;ISSUE A DEVICE CLEAR
(1)                                ;-----
(1) 006314 052777 000020 173466      .DEVICE.CLR: BIS      #DCLR,@DZVCSR      ;SET DCLR
(1) 006322 032777 000020 173460 1$: BIT      #DCLR,@DZVCSR      ;DID IT CLEAR?
(1) 006330 001374              BNE      1$              ;BR IF NO
(1) 006332 000002              RTI                       ;EXIT ROUTINE
(1)
(1)                                ;ROUTINE TO HANDLE MAINTENANCE BIT SETTING WITH DEVICE CLEAR
(1)                                ;-----
(1) 006334 104413      .DCLASM: DEVICE.CLR      ;ISSUE A DEVICE CLEAR
(1) 006336 153777 001424 173444      BISB     MNTFLG,@DZVCSR ;LOAD THE MAINTENANCE BIT IF IT IS I MODE
(1) 006344 000002              RTI                       ;RETURN TO CALLING ROUTINE
(1)
(1) 006346 010046      .DELAY: MOV      R0,-(SP)      ;SAVE R0
(1) 006346 013700 006364      MOV      DLYCNT,R0      ;SET COUNT
(1) 006350 005300 1$: DEC      R0              ;DELAY
(1) 006354 001376              BNE      1$              ;
(1) 006356 012600              MOV      (SP)+,R0      ;RESTORE R0
(1) 006360 000002              RTI                       ;LEAVE ROUTINE
(1) 006362 000001      DLYCNT: .WORD      1      ;PATCHABLE LOC FOR MORE TIME
(1)
(1)                                ;ADVANCE TO NEXT TEST HANDLER
(1)                                ;-----
(1)
(1)

```

```

(1) 006366 013716 001362 .ADVANCE:MOV NEXT,(SP) ;CRUNCH STACK WITH ADDRESS OF SCOPE CALL
(1) 006372 005037 001364 CLR LOCK ;RESET TIGHT LOOP ADDRESS
(1) 006376 000002 RTI ;CHECK TO SEE IF OLD TEST GETS REPEATED
(1)
(1) ;ROUTINE TO SHIFT LINE POINTER
(1) ;AND SWITCH TESTS IF NECESSARY
(1) -----
(1) 006400 106302 .SHIFT: ASLB R2 ;POINT TO THE NEXT LINE
(1) 006402 032702 000020 BIT #BIT4,R2 ;HAVE WE PASSED ALL LINE POINTERS?
(1) 006406 001402 BEQ 1$ ;IF NOT, RETURN TO THE TEST
(1) 006410 022626 POP2SP ;REMOVE THE TRAP CALL FROM THE STACK
(1) 006412 104400 ADVANCE ;GO TO THE NEXT TEST
(1) 006414 000002 1$: RTI ;RETURN TO THE PRESENT TEST
(1)

```

```

(1)                                     ;LINE PARAMETER REGISTER SETUP ROUTINE
(1)
(1) 006416 010146                       .LPRSET:MOV R1,-(SP)           ;SAVE CONTENTS OF R1
(1) 006420 010246                       MOV R2,-(SP)           ;SAVE CONTENTS OF R2
(1) 006422 013701 001370                 MOV PAR,R1             ;MOVE DEFAULT PARAM. INTO R1
(1) 006426 012702 000001                 MOV #1,R2             ;INIT. FOR LINE 1
(1) 006432 010177 173362                 1$: MOV R1,@DZVLPR     ;LOAD PARAM. REGISTER
(1) 006436 005201                       INC R1                 ;SET R1 FOR NEXT LINE
(1) 006440 106302                       ASLB R2                ;SET R2 FOR NEXT LINE
(1) 006442 032702 000020                 BIT #BIT4,R2          ;ALL LINES DONE?
(1) 006446 001771                       BEQ 1$                 ;IF NC LOAD NEXT LINE
(1) 006450 012602                       MOV (SP)+,R2          ;RELOAD R2
(1) 006452 012601                       MOV (SP)+,R1          ;RELOAD R1
(1) 006454 000002                       RTI                    ;RETURN
(1)
(1)                                     ;ROUTINE TO ZERO DATA BUFFER
(1)
(1) 006456 010046                       .BUFSET:MOV R0,-(SP)   ;SAVE CONTENTS OF R0
(1) 006460 012700 001426                 MOV #TDO,R0           ;SET R0 TO TOP OF BUFFER
(1) 006464 005020                       1$: CLR (R0)+          ;CLEAR BUFFER LOCATION
(1) 006466 022700 001446                 CMP #STOP,R0          ;IS BUFFER ALL CLEARED
(1) 006472 001374                       BNE 1$                 ;IF NOT CLEAR NEXT LOCATION
(1) 006474 012600                       MOV (SP)+,R0          ;RELOAD R0
(1) 006476 000002                       RTI                    ;RETURN
(1)
(1)                                     ;ERROR HANDLER
(1) -----
(1)
(1) 006500 004737 007126                 $ERROR: JSR PC,SERV.G   ;FIND OUT IF <^G> WAS HIT
(1) 006504 032777 010000 172572         BIT #SW12,@SWR        ;BELL ON ERROR?
(1) 006512 001406                       BEQ XBX                ;BR IF NO BELL
(1) 006514 105777 172574                 TSTB @STPS            ;TTY READY.
(1) 006520 100003                       BPL XBX                ;DON'T WAIT IF TTY NOT READY.
(1) 006522 112777 000207 172566         MOVB #207,@STPB       ;PUSH A BELL AT THE TTY.
(1) 006530 032777 020000 172546         XBX: BIT #SW13,@SWR   ;DELETE ERROR PRINT OUT?
(1) 006536 001113                       BNE HALTS              ;BR IF NO PRINT OUT WANTED.
(1) 006540 021637 001262                 CMP (SP),$ERRPC       ;WAS THIS ERROR FOUND LAST TIME?
(1) 006544 001404                       BEQ 1$                 ;BR IF YES
(1) 006546 011637 001262                 MOV (SP),$ERRPC       ;RECORD BEING HERE
(1) 006552 105037 001247                 CLRB $ERFLG           ;PREPARE HEADER
(1) 006556 104407                       1$: SAVO5              ;SAVE ALL PROC REGISTERS
(1) 006560 011605                       MOV (SP),R5            ;GET THE PC OF ERROR
(1) 006562 162705 000002                 SUB #2,R5              ;GET ADDRESS OF TRAP CALL
(1) 006566 011504                       MOV (R5),R4            ;GET ERROR INSTRUCTION
(1) 006570 110437 001260                 MOVB R4,$ITEMB        ;COPY TEST NUMBER FOR APT HANDLING
(1) 006574 006304                       ASL R4                 ;MULT BY TWO
(1) 006576 061504                       ADD (R5),R4            ;DOUBLE IT
(1) 006600 006304                       ASL R4                 ;MULT AGAIN
(1) 006602 042704 177001                 BIC #177001,R4        ;CLEAR JUNK
(1) 006606 062704 015216                 ADD #.ERRTAB,R4        ;GET POINTER
(1) 006612 012437 006736                 MOV (R4)+,ERRMSG      ;GET ERROR MESSAGE
(1) 006616 012437 006750                 MOV (R4)+,DATAHD      ;GET DATA HEADRER
(1) 006622 011437 006762                 MOV (R4),DATABP       ;GET DATA TABLE
(1) 006626 105737 001247                 TSTB $ERFLG           ;TYPE HEADER
(1) 006632 001403                       BEQ TYPMSG             ;BR IF YES
(1) 006634 005737 006762                 TST DATABP            ;DOES DATA TABLE EXIST?
    
```

```

(1) 006640 001044
(1) 006642 104402 001357
(1) 006646 104402 001357
(1) 006652 005737 001364
(1) 006656 001402
(1) 006660 104402 010041
(1) 006664 104402 010027
(1) 006670 104412 007120
(1) 006674 104402 010121
(1) 006700 104412 007112
(1) 006704 104402 007771
(1) 006710 104412 004332
(1) 006714 104402 001357
(1) 006720 112737 177777 001247
(1) 006726 005737 006736
(1) 006732 001402
(1) 006734 104402
(1) 006736 000000
(1) 006740
(1) 006740 005737 006750
(1) 006744 001402
(1) 006746 104402
(1) 006750 000000
(1) 006752 005737 006762
(1) 006756 001402
(1) 006760 104411
(1) 006762 000000
(1) 006764 104410
(1) 006766 122737 000001 001140
(1) 006774 001007
(1) 006776 113737 001260 007010
(1) 007004 004737 005242
(1) 007010 000000
(1) 007012 000777
(1) 007014 022737 004316 000042
(1) 007022 001403
(1) 007024 005777 172254
(1) 007030 100004
(1) 007032 016677 000002 172246
(1) 007040 000000
(1) 007042 005237 001256
(1) 007046 004737 007126
(1) 007052 032777 000400 172224
(1) 007060 001007
(1) 007062 032777 002000 172214
(1) 007070 001407
(1) 007072 013737 001362 001252
(1) 007100 012706 001120
(1) 007104 000177 172142
(1) 007110 000002
(1) 007112 000001
(1) 007114 006 002
(1) 007116 001404
(1) 007120 000001
(1) 007122 002 002
(1) 007124 001246

BNE TYPDAT :BR IF YES.
TYPMSG: TYPE ,SCRLF :TYPE A CARRIAGE RETURN
TYPE ,SCRLF :AND TYPE ANOTHER
TST LOCK
BEQ 1$
TYPE ,MASTEK
1$: TYPE ,MTSTN
CNVRT ,XTSTN :SHOW IT
TYPE ,MERRPC :TYPE PC.
CNVRT ,ERTABO :SHOW IT
TYPE ,MCSRX
CNVRT ,XCSR
TYPE ,SCRLF
MOV# -1, SERFLG :GIVE A CR/LF
TST ERRMSG :NO MORE HEADER UNLESS NO DATA TABLE.
BEQ WTBS.FM :IS THERE AN ERROR MESSAGE?
TYPE :BR IF NO.
ERRMSG: 0 :TYPE
WTBS.FM: : ERROR MESSAGE
TST DATAHD :DATA HEADER?
BEQ TYPDAT :BR IF NO
TYPE :TYPE
DATAHD: 0 : DATA HEADER
TYPDAT: TST DATABP :DATA TABLE?
BEQ RESREG :BR IF NO.
CONVRT :SHOW
DATABP: 0 : DATA TABLE
RESREG: RES05 :RESTORE PROC REGISTERS
HALTS: CMPB #APTENV,SENV :IS APT RUNNING?
BNE 15$ :SKIP APT CALL IF NOT
MOVB $ITEMB,5$ :COPY ERROR NUMBER
JSR PC,$ATY4 :CALL APT SERVICE
5$: .WORD 0 :ERROR NUMBER STUCK HERE
10$: BR 10$ :LOCK UP HERE
15$: CMP #SENDAD,@#42 :CHECK TO SEE IF IN ACT-11 MODE
BEQ 20$ :IF SO, HANDLE ACCORDINGLY
TST @SWR :HALT ON ERROR?
BPL EXITER :BR IF NO HALT ON ERROR
20$: MOV 2(SP),@DISPLAY :SHOW ERROR PC IN DATA DISPLAY
HALT :HALT
EXITER: INC SERTTL :UPDATE ERROR COUNT
JSR PC,SERV.G :FIND OUT IF ^G WAS TYPED
BIT #SW08,@SWR :GOTO TOP OF TEST?
BNE 1$ :BR IF YES
BIT #SW10,@SWR :GOTO NEXT TEST?
BEQ 2$ :BR IF NO
MOV NEXT,$LPADR :SET FOR NEXT TEST
1$: MOV #STACK,SP :RESET S?
JMP @SLPADR :GOTO SPECIFIED TEST
2$: RTI :RETURN
ERTABO: 1
.BYTE 6,2
XTSIN: 1
.BYTE 2,2
$TSTNM

```

```

(1) 007126 017746 172160 SERV.G: MOV @STKB,-(SP) :OTHERWISE, GET THE LAST CHARACTER TYPED
(1) 007132 042716 000200 BIC #BIT7,(SP) :STRIP PARITY(EIGHTH) BIT
(1) 007136 122726 000007 CMPB #7,(SP)+ :IS IT ^G?
(1) 007142 001076 BNE 6$ :IF NOT, IGNORE INPUT
(1) 007144 032777 004000 172136 BIT #4000,@STKS :RX BUSY?
(1) 007152 001365 BNE SERV.G :BR IF YES
(1) 007154 007154 GETSWR= :GPA
(1) 007154 017737 172124 007362 MOV @SWR,90$ :SAVE (SWR).
(1) 007162 104402 007342 1$: TYPE .89$ :TYPE HEADER FOR OLD SWITCH REGISTER
(1) 007166 104412 007354 CNVRT .88$ :TYPE THE NUMBER ITSELF
(1) 007172 104402 007364 TYPE .91$ :AFTER HAVING CONVERTED IT TO ASCII
(1) 007176 105037 007370 CLR 92$ :CLEAR SWR CHANGE FLAG
(1) 007202 005077 172076 CLR @SWR :CLEAR THE SOFTWARE SWITCH REGISTER
(1) 007206 105777 172076 3$: TSTB @STKS :WAIT FOR DONE.
(1) 007212 100375 BPL 3$ :CONTINUE WAITING FOR IT
(1) 007214 017746 172072 MOV @STKB,-(SP) :PUT THE CHARACTER ON THE STACK
(1) 007220 042716 000200 BIC #BIT7,(SP) :STRIP PARITY BIT
(1) 007224 122726 000015 CMPB #15,(SP)+ :IS IT THE CARRIAGE RETURN CHAR?
(1) 007230 001433 BEQ 4$ :IF SO, GO PRINT CRLF
(1) 007232 105777 172056 2$: TSTB @STPS :IS THE OUTPUT BUFFER AVAILABLE
(1) 007236 100375 BPL 2$ :IF NOT, WAIT FOR IT TO BE READY
(1) 007240 105237 007370 INCB 92$ :INDICATE THAT THE SWR WAS CHANGED
(1) 007244 014677 172046 MOV -(SP),@STPB :PLACE THE CHARACTER THERE(ECHO BACK)
(1) 007250 000241 CLC :GET READY TO ROTATE
(1) 007252 006177 172026 ROL @SWR :MOVE THE EXISTING BITS OVER
(1) 007256 006177 172022 ROL @SWR :TO MAKE ROOM FOR THE INCOMING
(1) 007262 006177 172016 ROL @SWR :THREE BITS FROM THIS CHARACTER
(1) 007266 103735 BCS 1$ :ERROR
(1) 007270 022627 000060 CMP (SP)+,#60 :IS IT LOWER THAN 0?
(1) 007274 002732 BLT 1$ :IF SO, GO ASK AGAIN
(1) 007276 026627 177776 000067 CMP -2(SP),#67 :IS IT HIGHER THAN 7?
(1) 007304 003326 BGT 1$ :IF SO, GO ASK AGAIN
(1) 007306 042746 177770 BIC #^C<7>,-(SP) :ISOLATE INFORMATION BITS
(1) 007312 052677 171766 BIS (SP)+,@SWR :ADD THEM TO THE SWITCH REGISTER
(1) 007316 000733 BR 3$ :GO CHECK FOR THE NEXT CHARACTER
(1) 007320 105737 007370 4$: TSTB 92$ :HAS THE SWR BEEN CHANGED?
(1) 007324 001003 BNE 5$ :IF YES GO TYPE CRLF
(1) 007326 013777 007362 171750 MOV 90$,@SWR :IF NOT RESTORE SWR
(1) 007334 104402 001357 5$: TYPE ,$CRLF :TYPE A CARRIAGE RETURN AND LINE FEED
(1) 007340 000207 6$: RTS PC :RETURN TO CALLING PROCEDURE
(1) 007342 020200 051450 051127 89$: .ASCIZ <200>? (SWR)=/?
(1) .EVEN
(1) 007354 000001 88$: 1
(1) 007360 006 000 .BYTE 6,0
(1) 007362 007362 90$: .WORD 0
(1) 007362 000000 91$: .ASCIZ ?/=/?
(1) 007364 036457 000057 92$: .BYTE 0
(1) 007370 000 .EVEN
(1) 007372 007372 .SBTTL POWER DOWN AND UP ROUTINES
(2)
(2)
(2)
(2) *****
(2) :POWER DOWN ROUTINE
(2) 007372 012737 007536 000024 $PWRDN: MOV #SILLUP,@PWRVEC ;;SET FOR FAST UP
(2) 007400 012737 000340 000026 MOV #340,@PWRVEC+2 ;;PRIO:7

```

```

(4) 007406 010046      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
(4) 007410 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
(4) 007412 010246      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
(4) 007414 010346      MOV      R3,-(SP)      ;;PUSH R3 ON STACK
(4) 007416 010446      MOV      R4,-(SP)      ;;PUSH R4 ON STACK
(4) 007420 010546      MOV      R5,-(SP)      ;;PUSH R5 ON STACK
(4) 007422 017746 171656  MOV      @SWR,-(SP)     ;;PUSH @SWR ON STACK
(2) 007426 010637 007542  MOV      SP,$SAVR6     ;;SAVE SP
(2) 007432 012737 007444 000024  MOV      #SPWRUP,@PWRVEC ;;SET UP VECTOR
(2) 007440 000000      HALT
(2) 007442 000776      BR       .-2          ;;HANG UP
(2)
(3)
(2)
(2) 007444 012737 007536 000024  $PWRUP: MOV      #SILLUP,@PWRVEC ;;SET FOR FAST DOWN
(2) 007452 013706 007542      MOV      $SAVR6,SP    ;;GET SP
(2) 007456 005037 007542      CLR      $SAVR6      ;;WAIT LOG? FOR THE TTY
(2) 007462 005237 007542 1$: INC      $SAVR6     ;;WAIT FOR THE INC
(2) 007466 001375      BNE     1$          ;;OF WORD
(4) 007470 012677 171610      MOV      (SP)+,@SWR   ;;POP STACK INTO @SWR
(4) 007474 012605      MOV      (SP)+,R5    ;;POP STACK INTO R5
(4) 007476 012604      MOV      (SP)+,R4    ;;POP STACK INTO R4
(4) 007500 012603      MOV      (SP)+,R3    ;;POP STACK INTO R3
(4) 007502 012602      MOV      (SP)+,R2    ;;POP STACK INTO R2
(4) 007504 012601      MOV      (SP)+,R1    ;;POP STACK INTO R1
(4) 007506 012600      MOV      (SP)+,R0    ;;POP STACK INTO R0
(2) 007510 012737 007372 000024  MOV      #SPWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
(2) 007516 012737 000340 000026  MOV      #340,@PWRVEC+2 ;;PRIO:7
(2) 007524 104402      TYPE
(2) 007526 007544  $PWRMG: .WORD  MPFAIL    ;;REPORT THE POWER FAILURE
(2) 007530 012716      MOV      (PC)+,(SP)  ;;POWER FAIL MESSAGE POINTER
(2) 007532 011070  $PWRAD: .WORD  RESTART   ;;RESTART AT RESTART
(2) 007534 000002      RTI
(2) 007536 000000  $SILLUP: HALT      ;;THE POWER UP SEQUENCE WAS STARTED
(2) 007540 000776      BR       .-2          ;; BEFORE THE POWER DOWN WAS COMPLETE
(2) 007542 000000      $SAVR6: 0            ;;PUT THE SP HERE
(2) 007544 050200 051127 043040  MPFAIL: .ASCIZ <200>/PWR FAILED. RESTART AT LAST TEST /
(2) 007607 200 047105 020104  MEPASS: .ASCIZ <200>/END PASS CVDZB-B /
(2) 007633 200 052522 047116  MR: .ASCIZ <200>/RUNNING /
(2) 007647 200 051120 043517  MERR2: .ASCIZ <200>/PROGRAM INDICATES NO DEVICES PRESENT./
(2) 007716 044600 051516 043125  MERR3: .ASCIZ <200>/INSUFFICIENT DATA!/
(2) 007742 046200 041517 020113  MLOCK: .ASCIZ <200>/LOCK ON SELECTED TEST/
(2) 007771 103 051123 020072  MCSR: .ASCIZ /CSR: /
(2) 007777 126 041505 020072  MVEC: .ASCIZ /VEC: /
(2) 010005 120 051501 042523  MPASSX: .ASCIZ /PASSES: /
(2) 010016 051105 047522 051522  MERRX: .ASCIZ /ERRORS: /
(2) 010027 124 051505 020124  MTSTN: .ASCIZ /TEST NO: /
(2) 010041 052 000040  MASTEK: .ASCIZ /* /
(2) 010044 052200 050131 020105  MNEW: .ASCIZ <200>/TYPE A BIT MAP OF DZV11'S DESIRED ACTIVE: /
(2) 010121 120 035103 000040  MERRPC: .ASCIZ /PC: /
(2) 010126 046600 050101 047440  XHEAD: .ASCIZ <200>/MAP OF DZV11 STATUS/<200>
(2) 010154 044600 046114 043505  MBADLN: .ASCIZ <200>/ILLEGAL ENTRY IN STAGGERED MODE/<200>
(2)
(2) 010216 000002  XSTATQ: 2
(2) 010220 006 003 .BYTE 6,3
(2) 010222 001344 $TMP1

```

```

(2) 010224 006 002 .BYTE 6,2
(2) 010226 001346 $TMP2
(1) .EVEN
(2) :THIS ROUTINE ESTABLISHES WHICH MAINTENANCE MODE THE DEVICE IS IN
(2) -----
(2) :E=EXTERNAL LOOP BACK
(2) :I=INTERNAL LOOP BACK
(2) :S=STAGGERED LOOP BACK
(2) 010230 017605 000000 .SETFLG:MOV @ (SP),R5 :PICK UP ADDRESS OF TAG
(2) 010234 042737 000040 010424 BIC #40,INBUF :STRIP LOWER CASE
(2) 010242 122737 000105 010424 CMPB #'E,INBUF :IS IT EXTERNAL LOOP BACK ?
(2) 010250 001005 BNE 4$ :NO
(2) 010252 013715 010342 MOV 1$, (R5) :YES STORE INFO
(2) 010256 105037 001424 CLRB MNTFLG :SET MAINT BIT =0
(2) 010262 000422 BR 7$ :GET OUT
(2) 010264 122737 000111 010424 4$: CMPB #'I,INBUF :IS IT INTERNAL LOOP BACK ?
(2) 010272 001006 BNE 5$ :NO
(2) 010274 013715 010344 MOV 2$, (R5) :YES STORE INFO
(2) 010300 112737 000010 001424 MOVB #MAINT,MNTFLG :SET UP THE MAINTENANCE FLAG LOADER
(2) 010306 000410 BR 7$ :GET OUT
(2) 010310 122737 000123 010424 5$: CMPB #'S,INBUF :IS IT STAGGERED LOOP BACK ?
(2) 010316 001007 BNE 6$ :WHAT ?
(2) 010320 013715 010346 MOV 3$, (R5) :YES STORE INFO
(2) 010324 105037 001424 CLRB MNTFLG :ZERO BITS
(2) 010330 062716 000002 7$: ADD #2,(SP) :POP AROUND
(2) 010334 000002 RTI
(2) 010336 104404 6$: INSTER :RETRY
(2) 010340 000733 BR .SETFLG :DITTO
(2) 010342 000200 1$: .WORD 200 :EXTERNAL = E
(2) 010344 000000 2$: .WORD 0 :INTERNAL = I
(2) 010346 100000 3$: .WORD 100000 :STAGGERED = S

```



```

(2) ;COMPARE THE FIRST CHARACTER IN THE TELETYPE INPUT
(2) ;BUFFER TO THE CHARACTERS 'E' AND 'C'.
(2) ;IF THE CHARACTER IS 'E' CLEAR THE FLAG
(2) ;IF THE CHARACTER IS 'C' SET THE FLAG

```

```

(2) 010350 017605 000000 .PAWCH:MOV @ (SP),R5
(2) 010354 142737 000040 010424 BICB #40,INBUF ;SET FOR LOWER CASE INPUT
(2) 010362 122737 000105 010424 CMPB #'E,INBUF ;IS IT 'E' ?
(2) 010370 001002 BNE 1$
(2) 010372 105015 CLRB (R5) ;000
(2) 010374 000406 BR 2$
(2) 010376 122737 000103 010424 1$: CMPB #'C,INBUF ;IS IT 'C' ?
(2) 010404 001005 BNE 3$
(2) 010406 112715 177777 MOVB #-1,(R5) ;3177
(2) 010412 062716 000002 2$: ADD #2,(SP)
(2) 010416 000002 RTI
(2) 010420 104404 3$: INSTER ;RETRY
(2) 010422 000752 BR .PAWCH

```

:BUFFERS FOR INPUT-OUTPUT

```

(2) 010424 000000 INBUF: 0
(2) 010466 .=. +40
(2) : TEMP: 0 ; TEMP AREA UNUSED. ;:GPA
(2) : .=. +40 ; DELETED TO CONSERVE SPACE. ;:GPA
(2) 010466 000000 MDATA: 0
(2) 010530 .=. +40

```

CVDZB-B MACY11 30G(1063) 10-AUG-81 11:11 PAGE 25-39  
 CVDZBB.P11 10-AUG-81 10:56 POWER DOWN AND UP ROUTINES

SEQ 0057

```

(2)
(2)
(2)
(2)
(2)
(2)
(2)
(2)
(2)
(2)
(2)
(2) 010530 005737 001406           CYCLE: TST       DZVACTV      ;ARE ANY DZV11'S TO BE TESTED?
(2) 010534 001004                   BNE         1$       ;BR IF OK.
(2) 010536 104402 007647           TYPE       ,MERR2    ;NO DZV11'S SELECTED!!
(2) 010542 000000                   HALT                        ;STOP THE SHOW.
(2) 010544 000776                   BR          -2        ;DISQUALIFY CONT. SW.
(2) 010546 013737 004624 001354 1$: MOV       $MXCNT,$TIMES ;RESTORE THE NUMBER OF ITERATIONS TO MAKE
(2) 010554 033737 001412 001406 PTT       RUN,DZVACTV ;IS THIS ONE 'ACTIVE'
(2) 010562 001017                   BNE         2$       ;BR IF GOOD ONE FOUND.
(2) 010564 006137 001412           ROL       RUN        ;UPDATE POINTER
(2) 010570 005537 001412           ADC       RUN        ;CATCH CARRY FROM RUN
(2) 010574 062737 000012 001420 ADD       #12,ACTIVE ;UPDATE ADDRESS POINTER.
(2) 010602 022737 001740 001420 CMP       #DZV.END,ACTIVE ;HAVE WE PASSED THE END OF THE MAP?
(2) 010610 001356                   BNE         1$       ;IF NO, KEEP GOING; NOT ALL TESTED FOR.
(2) 010612 012737 001500 001420 MOV       #DZV.MAP,ACTIVE ;RESET ADDRESS POINTER.
(2) 010620 000752                   BR          1$       ;KEEP LOOKING FOR ACTIVE DZV11
(2) 010622 006137 001412           ROL       RUN        ;UPDATE POINTER.
(2) 010626 005537 001412           ADC       RUN        ;CATCH CARRY.
(2) 010632 013700 001420           MOV       ACTIVE,R0  ;GET ADDRESS POINTER.
(2) 010636 062737 000012 001420 ADD       #12,ACTIVE ;UPDATE.
(2) 010644 022737 001740 001420 CMP       #DZV.END,ACTIVE
(2)
(2) 010652 001003                   BNE         3$       ;ALL DONE?
(2) 010654 012737 001500 001420 MOV       #DZV.MAP,ACTIVE ;BR IF NO.
(2) 010662 012037 001174           MOV       (R0)+,$BASE ;RESTORE POINTER.
(2) 010666 012037 002040           MOV       (R0)+,DZVRIV ;LOAD SYSTEM CTRL. REG
(2) 010672 012037 001366           MOV       (R0)+,LINE  ;LOAD VECTOR
(2) 010676 012037 001370           MOV       (R0)+,PAR   ;SET UP DZV LINES ACTIVE
(2) 010702 012037 001372           MOV       (R0)+,MODE  ;SET UP PARAMETERIZATION
(2) 010706 105037 001424           CLRB     MNTFLG ;RESET MAINT. FLAG IF
(2) 010712 005737 001372           TST      MODE       ;RUNNING TESTS
(2) 010716 001003                   BNE         9$       ;IN
(2) 010720 112737 000010 001424 MOVB     #MAINT,MNTFLG ;INTERNAL MAINT. MODE
(2) 010726 004737 011074           JSR      PC,DZVLEV  ;SET UP
(2) 010732 005737 000042           TST      @42        ;ARE WE UNDER MONITOR CONTROL?
(2) 010736 001051                   BNE         7$       ;IF YES, SKIP THIS SETUP
(2) 010740 032777 000002 170336 BIT       #SW01,@SWR ;IF SW01=1, GET STARTING TEST #
(2) 010746 001445                   BEQ       7$       ;BR IF NO TEST IS TO BE INPUTTED
(2) 010750 104402 001357           TYPE     ,SCRLF
(2) 010754 104403                   INSTR
(2) 010756 010027                   MTSTN
(2) 010760 104405                   PARAM
(2) 010762 000001                   1
(2) 010764 001000                   1000
(2) 010766 001246                   $STNM
(2) 010770          000                   .BYTE 0
(2) 010771          001                   .BYTE 1
(2) 010772 012700 012070           MOV      #TST1,R0
;CALL THE STRING INPUT ROUTINE
;POINTER TO MESSAGE TO BE PRINTED
;CALL THE OCTAL TO ASCII CONVERT ROUTINE
;LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
;HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
;POINTER TO MAP LOCATION TO BE FILLED
;MASK OF INVALID BITS FOR THIS PARAMETER
;NUMBER OF PARAMETERS TO STORE
;ROUTINE USED TO 'CYCLE' THROUGH UP TO SIXTEEN DZV11'S
;THIS ROUTINE SETS UP THE CONTROL ADDRESS FOR THE DIAGNOSTIC
;AND RUNS THE SPECIFIED DZV11'S. THIS ROUTINE *MUST*
;BE RUN FIRST BEFORE ENTERING THE DIAGNOSTIC FOR THE
;SETUP NECESSARY.
;
```

POWER DOWN AND UP ROUTINES

```

(2) 010776 022710 000004      5$:  CMP      #4,(R0)
(2) 011002 001020              BNE      6$
(2) 011004 022760 012737 000002  CMP      #12737,2(R0)
(2) 011012 001014              BNE      6$
(2) 011014 023760 001246 000004  CMP      $STNM,4(R0)      :IS THIS THE TEST ?
(2) 011022 001010              BNE      6$              :IF NOT, DON'T PROCESS NUMBER
(2) 011024 010037 001252              MOV      R0,$LPADR        :SAVE PC
(2) 011030 062737 000002 001252  ADD      #2,$LPADR        :POP OVER PREVIOUS SCOPE
(2) 011036 104402 001357              TYPE     ,$CRLF
(2) 011042 000412              BR       8$
(2) 011044 005720              6$:  TST      (R0)+
(2) 011046 020027 014222              CMP      R0,#TLAST+10
(2) 011052 001351              BNE      5$
(2) 011054 104402 001356              TYPE     ,SQUES
(2) 011060 000733              BR       4$
(2) 011062 012737 012070 001252  7$:  MOV      #TST1,$LPADR    :PREPARE TEST ADDRESS
(2) 011070              8$:
(2) 011070 006177 170156  RESTART:JMP  @,$LPADR      :GO START TESTING.***WARNING!***
(2)                               :THIS JUMP IS USED BY POWER UP ROUTINE!!!!
(2)
(2)                               :THIS UTILITY SETS UP CSR'S,SETS UP VECTORS.
(2) 011074 013700 002040  DZVLEV: MOV  DZVRIV,R0      :PLACE THE BASE VECTOR ADDRESS IN R0
(2) 011100 062700 000002      ADD      #2,R0            :CALCULATE THE RECEIVER INTERRUPT STATUS ADDR.
(2) 011104 010037 002042      MOV      R0,DZVRIS       :STORE IT HERE
(2) 011110 062700 000002      ADD      #2,R0            :CALCULATE THE TRANSMITTER INTERRUPT VECTOR
(2) 011114 010037 002044      MOV      R0,DZVTIV       :STORE IT HERE
(2) 011120 062700 000002      ADD      #2,R0            :CALCULATE THE TRANSMITTER VECTOR STATUS ADDRESS
(2) 011124 010037 002046      MOV      R0,DZVTIS       :STORE IT HERE
(2)
(2)                               :THIS SEGMENT SETS UP POINTERS FOR THE GIVEN DZV11. $BASE IS THE BASE ADDRESS
(2)                               :OF THE DEVICE
(2) 011130 013700 001174      MOV      $BASE,R0        :COPY THE ADDRESS BEING LOADED
(2) 011134 010037 002010      MOV      R0,DZVCSR       :XXX0
(2) 011140 005200              INC      R0
(2) 011142 010037 002012      MOV      R0,HDZVCSR      :XXX1
(2) 011146 005200              INC      R0
(2) 011150 010037 002014      MOV      R0,DZVRBUF      :XXX2
(2) 011154 010037 002020      MOV      R0,DZVLPR       :XXX2
(2) 011160 005200              INC      R0
(2) 011162 010037 002016      MOV      R0,HDZVRBUF     :XXX3
(2) 011166 010037 002022      MOV      R0,HDZVLPR      :XXX3
(2) 011172 005200              INC      R0
(2) 011174 010037 002024      MOV      R0,DZVTCR       :XXX4
(2) 011200 005200              INC      R0
(2) 011202 010037 002026      MOV      R0,HDZVTCR     :XXX5
(2) 011206 005200              INC      R0
(2) 011210 010037 002030      MOV      R0,DZVMSR       :XXX6
(2) 011214 010037 002034      MOV      R0,DZVTDR       :XXX6
(2) 011220 005200              INC      R0
(2) 011222 010037 002032      MOV      R0,HDZVMSR     :XXX7
(2) 011226 010037 002036      MOV      R0,HDZVTDR     :XXX7
(2) 011232 000207              RTS      PC

```



CVDZB-B MACY11 30G(1063) 10-AUG-81 11:11  
CVDZBB.P11 10-AUG-81 10:56

PAGE 25-42  
POWER DOWN AND UP ROUTINES

SEQ 0060

(2)

; END OF .PARMD DELETE RANGE

6

::GPA

```

(2)                                     ;*ROUTINE USED TO SET UP THE DIAGNOSTIC VIA APT.
(2)                                     ;*IF BIT7 IN THE ENVIRONMENT MODE ($ENVM) BYTE IS SET
(2)                                     ;*THE PROGRAM WILL LOAD ITS PARAMETERS FROM THE ETABLE.
(2)
(2) 011236 012700 001500 SETAPT: MOV #DZV.MAP,R0 ;POINT TO THE DEVICE MAP TABLE
(2) 011242 013701 001174 MOV $BASE,R1 ;BUILD DEVICE ADDRESSES IN R1
(2) 011246 013702 001170 MOV $VECT1,R2 ;BUILD DEVICE VECTORS IN R2
(2) 011252 042702 177007 BIC #^C<770>,R2 ;STRIP AWAY OTHER INFORMATION
(2) 011256 012704 001204 MOV #SDDW0,R4 ;POINT TO THE BEGINNING OF DEVICE PARAMETERS
(2) 011262 013705 001176 MOV $DEVN,R5 ;GET THE MAP OF ACTIVE DEVICES
(2) 011266 105037 001414 CLRB DZVNUM ;INITIALIZE THE NO. OF ACTIVE DEVICES
(2) 011272 005037 001410 CLR SAVACTV ;CLEAR THE ACTIVE BIT MAP
(2) 011276 006005 1$: ROR R5 ;GET A DEVICE SELECTION BIT
(2) 011300 103407 BCS 3$ ;IF IT IS SELECTED, GO SET UP A MAP
(2) 011302 001422 BEQ 5$ ;IF NO MORE ARE SELECTED, GET OUT OF SETUP
(2) 011304 005724 TST (R4)+ ;POINT TO NEXT DEVICE DESCRIPTOR
(2) 011306 062701 000010 2$: ADD #10,R1 ;SET UP THE NEXT ADDRESS
(2) 011312 062702 000010 ADD #10,R2 ;SET UP THE NEXT VECTOR GROUP
(2) 011316 000767 BR 1$ ;GO SEE IF MORE DEVICES REMAIN
(2) 011320 006137 001410 3$: ROL SAVACTV ;SET BIT IN ACTIVE DEVICE MAP
(2) 011324 105237 001414 INCB DZVNUM ;INCREMENT NO. OF ACTIVE DEVICES
(2) 011330 010120 MOV R1,(R0)+ ;LOAD DEVICE ADDRESS
(2) 011332 010220 MOV R2,(R0)+ ;LOAD THE VECTOR ADDRESS
(2) 011334 013720 001200 MOV $CDW1,(R0)+ ;GET THE NUMBER OF LINES IN OPERATION
(2) 011340 012420 MOV (R4)+,(R0)+ ;LOAD DEVICE PARAMETERS
(2) 011342 013720 001202 MOV $CDW2,(R0)+ ;LOAD DEFAULT TESTING MODE
(2) 011346 000757 BR 2$ ;GO BUILD THE NEXT ADDRESS
(2) 011350 012710 177777 5$: MOV #-1,(R0) ;TERMINATE THE DEVICE MAP
(2) 011354 012737 001142 001304 MOV #SSWREG,SWR ;SET TO SOFTWARE APT SWITCH REGISTER
(2) 011362 000207 RTS PC ;RETURN TO PRINT STATUS TABLE

```

```

(2)
(2)                                     ;*ROUTINE USED TO "AUTO SIZE" THE DZV11
(2)                                     ;*CSR AND VECTOR.
(2)                                     ;*NOTE: THE CSR MAY BE ANY WHERE IN THE FLOATING
(2)                                     ;* ADDRESS RANGE (160000:163770)
(2)                                     ;* AND THE VECTOR MAY BE ANY WHERE IN THE
(2)                                     ;* FLOATING VECTOR RANGE (300:770)
(2)                                     ;*

```

```

(2)
(2) 011364 AUTO.SIZE:
(2) 011364 000005 RESET ;INSURE A BUS INIT.
(2) 011366 105337 001422 DECB INIFLG ;SHOW THAT I WAS HERE
(2) 011372 012702 001500 CSRMAP: MOV #DZV.MAP,R2 ;LOAD MAP POINTER.
(2) 011376 012703 001204 MOV #SDDW0,R3 ;POINT TO ETABLE DEVICE DESCRIPTOR WORDS
(2) 011402 005022 1$: CLR (R2)+ ;ZERO ENTIRE MAP
(2) 011404 022702 001740 CMP #DZV.END,R2 ;ALL DONE?
(2) 011410 001374 BNE 1$ ;BR IF NO
(2) 011412 105037 001414 CLRB DZVNUM ;SET OCTAL NUMBER OF DZV11'S TO 0
(2) 011416 012702 001500 MOV #DZV.MAP,R2
(2) 011422 012701 160000 MOV #160000,R1 ;SET FOR FIRST ADDRESS TO BE TESTED
(2) 011426 012737 011672 000004 MOV #6$ @#4 ;SET FOR NON-EXISTENT DEVICE TIME OUT
(2) 011434 052711 000040 2$: BIS #BIT5,(R1) ;TRY TO SET MASTER SCAN ENABLE
(2) 011440 052761 000017 000004 BIS #17,4(R1) ;TRY TO TRANSMIT ON ANY LINE
(2) 011446 005000 CLR R0 ;USE R0 AS A COUNTER
(2) 011450 005711 7$: TST (R1) ;HAS TRANSMITTER READY COME UP?

```

```

(2) 011452 100403      BMI      8$      ;IF SO, GO GET A FINAL CHECK
(2) 011454 005300      DEC      R0      ;REDUCE COUNT. TIME UP?
(2) 011456 001374      BNE     7$      ;IF NOT, KEEP WAITING
(2) 011460 000437      BR      3$      ;ASSUME IT'S NOT A DZV11
(2) 011462 032761 000017 000004 8$: BIT    #17,4(R1) ;ARE ANY TCR BITS STILL SET? THEY SHOULD BE
(2) 011470 001433      BEQ     3$      ;IF IT'S NOT, ASSUME IT'S NOT A DZV11
(2) 011472 032711 000040      BIT    #BITS, (R1) ;IS MASTER SCAN ENABLE STILL SET?
(2) 011476 001430      BEQ     3$      ;IF NOT, ASSUME IT'S NOT A DZV11
(2) 011500 052711 000020      BIS    #20, (R1) ;SET DEVICE CLEAR
(2) 011504 000240      NOP
(2) 011506 032711 000040      BIT    #40, (R1) ;DID SCANNER CLFAR
(2) 011512 001022      BNE     3$      ;IF NOT ASSUME IT IS NOT DZV
(2) 011514 005061 000004      CLR    4(R1)    ;GET RID OF TCR BITS
(2) ;AT THIS POINT IT IS ASSUMED THAT R1 HOLDS A DZV11 CSR ADDRESS.
(2) 011520 010122      MOV    R1, (R2)+ ;STORE CSR IN CORE TABLE.
(2) 011522 005722      TST   (R2)+    ;POP OVER VECTOR STORE AREA
(2) 011524 012722 000017      MOV    #17, (R2)+ ;SET THE DEFAULT LINE SELECTION PARAMETER
(2) 011530 012712 017470      MOV    #17470, (R2) ;SET THE DEFAULT PARAMETERS
(2) 011534 012223      MOV    (R2)+, (R3)+ ;COPY PARAMETERS INTO ETABLE DESCRIPTOR
(2) 011536 005022      CLR   (R2)+    ;SET THE DEFAULT MODE OF OPERATION
(2) 011540 012712 177777      MOV    #-1, (R2) ;TERMINATE LIST
(2) 011544 105237 001414      INCB  DZVNUM    ;UPDATE DEVICE COUNTER
(2) 011550 122737 000020 001414      CMPB  #20, DZVNUM ;ARE MAX. NO. OF DEV FOUND?
(2) 011556 001405      BEQ   100$     ;YES DON'T LOOK FOR ANY MORE.
(2) 011560 062701 000010 3$: ADD   #10, R1   ;UPDATE CSR POINTER ADDRESS
(2) 011564 022701 164000      CMP   #164000, R1
(2) 011570 001321      BNE   2$      ;BR IF MORE ADDRESS TO CHECK.
(2) 011572 105737 001414 100$: TSTB  DZVNUM    ;WERE ANY DZV11'S FOUND AT ALL?
(2) 011576 001430      BEQ   5$      ;ERROR AUTO SIZER FOUND NO DZV11'S IN THIS SYS.
(2) 011600 113701 001414      MOVB  DZVNUM, R1
(2) 011604 012737 000001 001410      MOV   #1, SAVACTV ;CREATE A BIT MAP OF
(2) 011612 005301 4$: DEC   R1      ;THE DEVICES IN THE SYSTEM
(2) 011614 001404      BEQ   98$
(2) 011616 000261      SEC
(2) 011620 005137 001410      ROL   SAVACTV
(2) 011624 000772      BR    4$
(2) 011626 013737 001500 001174 98$: MOV   DZCRO, $BASE ;POINT TO THE ADDRESS OF FIRST DEVICE
(2) 011634 013737 001510 001202      MOV   MANTO, $CDW2 ;INDICATE TO ETABLE WHAT MODE IS BEING USED
(2) 011642 012737 000006 000004 99$: MOV   #6, #4      ;RESTORE TRAP VECTOR
(2) 011650 013737 001410 001176      MOV   SAVACTV, $DEVN ;SAVE ACTIVE REGISTER
(2) 011656 000410      BR    VECMAP   ;GO FIND THE VECTOR NOW.
(2) 011660 104402 007647 5$: TYPE  ,MERR2    ;NOTIFY OPR THAT NO DZV11'S FOUND.
(2) 011664 005000      CLR   R0      ;MAKE DATA DISPLAY ZERO
(2) 011666 000000      HALT
(2) 011670 000776      BR    -2      ;STOP THE SHOW
(2) 011672 012716 011560 6$: MOV   #-2, (R1) ;DISABLE CONT. SW.
(2) 011676 000002      RTI  #3$, (SP) ;ENTERED BY NON-EXISTENT TIME-OUT
(2) ;RETURN TO MAINSTREAM
(2) 011700 012737 000200 000022 VECMAP: MOV   #MASK, #22 ;SET IOT TRAP PRIORITY
(2) 011706 012737 012022 000020      MOV   #4$, #20 ;SET IOT TRAP VECTOR
(2) 011714 012702 001500      MOV   #DZV.MAP, R2 ;SET SOFTWARE POINTER
(2) 011720 012700 000300      MOV   #300, R0   ;FLOATING VECTORS START HERE.
(2) 011724 012701 000302      MOV   #302, R1   ;PC OF IOT INSTR.
(2) 011730 010120 1$: MOV   R1, (R0)+ ;START FILLING VECTOR AREA
(2) 011732 012721 000004      MOV   #4, (R1)+ ;WITH .+2; IOT

```

CVDZB-B MACY11 30G(1063) 10-AUG-81 11:11 PAGE 25-45  
 CVDZBB.P11 10-AUG-81 10:56 POWER DOWN AND UP ROUTINES

SEQ 0063

```

(2) 011736 022021          CMP      (R0)+,(R1)+      ;ADD 2 TO R0 +R1
(2) 011740 020127 001000  CMP      R1,#1000        ;HAS THE VECTOR AREA BEEN EXCEEDED?
(2) 011744 101771          BLOS     1$              ;BR IF MORE TO FILL
(2) 011746 013704 001410  MOV      SAVACTV,R4      ;STORE TEMPORARILY
(2) 011752 006004          ROR      R4              ;BRING OUT A BIT
(2) 011754 103036          BCC      5$              ;BR IF ALL DONE
(2) 011756 106427 000000  MTPS     #0              ;ZERO CPU PRIO
(2) 011762 012772 040040 000000  MOV      #BIT14+BIT5,@(R2) ;SET TIE AND MAS SCAN
(2) 011770 011201          MOV      (R2),R1         ;GET CSR
(2) 011772 112761 000017 000004  MOVB     #17,4(R1)       ;SET THE TCR BITS FOR ALL LINES
(2)                                ;ATTEMPT TO FORCE AN INTERRUPT
(2)                                ;STALL
(2) 012000 005200          INC      R0              ;
(2) 012002 001376          BNE      #-2             ;FOR TIME TO INTERRUPT
(2) 012004 012762 000300 000002  MOV      #300,2(R2)      ;NO INTERRUPT ASSUME 300 AND FIX DZV11 LATER
(2) 012012 000005          RESET                    ;INIT
(2) 012014 062702 000012          ADD      #12,R2          ;POP SOFTWARE POINTER
(2) 012020 000754          BR       2$              ;KEEP GOING
(2) 012022 011662 000002          MOV      (SP),2(R2)     ;GET VECTOR ADDRESS
(2) 012026 162762 000010 000002  SUB      #10,2(R2)       ;POINT BACK TO THE CORRECT VECTOR
(2) 012034 042762 000007 000002  BIC      #7,2(R2)        ;CLEAR JUNK
(2) 012042 022626          POP2SP                    ;POP IOT JUNK OFF STACK
(2) 012044 012716 012014          MOV      #3$, (SP)      ;SET FOR RETURN
(2) 012050 000002          RTI                       ;
(2) 012052 013737 001502 001170 5$: MOV      DZVCO,$VECT1    ;COPY VECTOR OF FIRST DEVICE INTO ETABLE
(2) 012060 012737 004362 000020  MOV      #.SCOPE,IOTVEC ;RESTORE THE SCOPE TRAP
(2) 012066 000207          RTS      PC              ;ALL DONE WITH 'AUTO SIZING'
(2)

```



2734  
2735  
2736  
2737  
2738  
2739  
2740  
2741  
2742  
2743  
2744  
2745  
2746  
2748  
(5)  
(4)  
(2)  
(2)  
2749  
2750  
2751  
2752  
2753  
2754  
2755  
2756  
2757  
2758  
2759  
2760  
2761  
2762  
2763  
2764  
2765  
2766  
2767  
2768  
2769  
2770  
2771  
2772  
2773  
2774  
2775  
2776  
2777  
2778  
2779  
2780  
2781  
2782  
2783  
2784  
2785  
2786

012070 000004  
012072 012737 000001 001246  
012100 012737 012532 001362  
012106 012737 012446 001364  
012114 104417  
012116 104421  
012120 005037 001374  
012124 104422  
012126 012702 000001  
012132 052777 010040 167650  
012140 030237 001366  
012144 001533  
012146 013700 001374  
012152 006300  
012154 010277 167644  
012160 105777 167624  
012164 100001  
012166 104020  
012170 005003  
012172 005004  
012174 005777 167610  
012200 100404  
012202 104414  
012204 005204  
012206 001372  
012210 104003  
012212 116077 001426 167614  
012220 005260 001426  
012224 020327 000017  
012230 105006  
012232 032777 020000 167550  
012240 001413  
012242 104013  
012244 000411  
012246 005004  
012250 032777 020000 167532  
012256 001004  
012260 104414  
012262 005204  
012264 001371

```
***** TEST 1 *****
*THIS TEST VERIFIES OVERRUN AND SILO ALARM
*ONE LINE AT A TIME - BASED UPON VALID LINES
*AS EACH OF THE FIRST 16 CHARS ARE SENT; SILO ALARM IS
*TESTED TO BE CLEARED. ON THE 16TH CHAR THE PROGRAM THEN
*EXPECTS SILO ALARM TO SET. THEN THE ENTIRE
*SILO IS FILLED AND AN OVERRUN IS EXPECTED ON THE 65TH
*CHAR PULLED OUT OF THE SILO.
*ERROR PRINTOUTS WILL REPORT TRANSMITTING LINE NO.
*USING SWITCH NINE FOR THIS TEST SENDS 20. CHARACTERS
*ON DZV LINE PREVIOUSLY SELECTED CONTINUOUSLY WHILE SW09=1.
*USED TO SCOPE SILO ALARM PULSES, ETC.

::* TEST 1
*****
TST1: SCOPE
MOV #1,STSTNM ;LOAD THE NUMBER OF THIS TEST
MOV #TST2,NEXT ;POINT TO THE START OF THE NEXT TEST
MOV #18$,LOCK ;SET FOR LOOP
DCLASM ;SET DCLR IN CSR AND SET MNTFLG
LPRSET ;LOAD LINE PARAMETERS
CLR SAVLIN ;INIT LINE INDICATOR
BUFSET ;ZERO DATA BUFFER
MOV #1,R2 ;LINE POINTER
BIS #MSENAB!SILOEN,@DZVCSR ;START SCANNER & SET SILO ENABLE
3$: BIT R2,LINE ;VALID LINE?
BEQ 21$ ;IF NOT GO TO NEXT LINE
MOV SAVLIN,R0 ;MAKE OFFSET
ASL R0 ;MAKE POWER OF TWO
MOV R2,@DZVTCR ;SET TCR BIT
4$: TSTB @DZVCSR ;REC DONE = 1 ?
BPL .+4
ERROR 20 ;REC DONE SHOULD NOT = 1
CLR R3 ;SET CHARACTER COUNT
5$: CLR R4
6$: TST @DZVCSR ;IS TRDY SET?
BMI 7$ ;IF YES, LOAD CHAR.
DELAY ;WAIT FOR TRDY TO SET
INC R4 ;INC DELAY COUNTER
7$: ERROR 3 ;*TRDY FAILED TO SET
MOVB TD0(R0),@DZVTDR ;LOAD A CHARACTER
INC TD0(R0) ;SET UP NEXT CHARACTER
CMP R3,#15. ;16 CHARACTERS ?
BHS 8$
BIT #SILOAL,@DZVCSR ;SILO ALARM = 0 ?
BEQ 10$ ;YES
ERROR 13 ;*SILO ALARM SHOULD NOT = 1
;UNTIL 16. DATA CHARACTERS
8$: BR 10$
9$: CLR R4
BIT #SILOAL,@DZVCSR
BNE 10$
DELAY
INC R4
BNE 9$
```

```

2787 012266 104014          ERROR 14          : *SILO ALARM FAILED TO SET!
2788                                     : SILO ALARM SHOULD =1 AFTER 16.
2789                                     : DATA CHARACTERS
2790 012270 005203          10$: INC R3          : INC CHAR COUNT
2791 012272 022703 000102  CMP #66.,R3      : FINISHED SENDING CHARACTERS ?
2792 012276 001335          BNE 5$          : NO
2793 012300 005004          CLR R4
2794 012302 104414          DELAY
2795 012304 105204          INCB R4
2796 012306 001375          BNE -4
2797                                     : NOW LETS READ THE SILO
2798 012310 013705 001374  MOV SAVLIN,R5    : MAKE EXPECTED LINE #
2799 012314 005737 001372  TST MODE        : IS THIS TEST IN STAGGERED MODE?
(1) 012320 100006          BPL 13$        : IF NOT, SKIP STAGGERED SETUP
(1)
(1)
(1)
(1) 012322 006205          ASR R5          : GET THE LAST BIT INTO THE CARRY BIT
(1) 012324 103402          BCS 11$        : IF IT IS SET, GO CLEAR IT
(1) 012326 000261          SEC          : IF IT IS CLEAR SET IT HERE
(1) 012330 000401          BR 12$        : SKIP THE CLEARING
(1) 012332 000241          11$: CLC          : CLEAR THE CARRY BIT (INVERSION OF LINE PARITY)
(1) 012334 006105          12$: ROL R5     : GET THE NEW BIT BACK INTO R5
2800 012336 000305          13$: SWAB R5     : PUT IN UPPER BYTE
2801 012340 052705 100000  BIS #DVALID,R5  : ADD DATA VALID
2802 012344 017704 167444  14$: MOV @DZVRBUF,R4 : ACTUAL
2803 012350 020405          CMP R4,R5      : ACTUAL VS. EXPECTED
2804 012352 001401          BEQ 15$       : YES
2805 012354 104006          ERROR 6       : *DATA/CONTENTS DID NOT COMPARE
2806 012356 032777 020000 167424 15$: BIT #SILOAL,@DZVCSR : SILO ALARM= 0 ?
2807 012364 001401          BEQ 16$       : YES
2808 012366 104016          ERROR 16      : READING DZVRBUF DID NOT CLEAR SILO ALARM
2809 012370 005205          16$: INC R5        : UP CHARACTER
2810 012372 120527 000077  CMPB R5,#63.    : LAST SILO CHAR ?....64TH CHAR
2811 012376 101762          BLOS 14$
2812 012400 005205          INC R5        : ADD 1 MORE FOR THE CLOBBED CHAR
2813 012402 052705 040000  BIS #OVRRUN,R5  : ADD OVERRUN TO EXPECTED
2814 012406 120527 000101  CMPB R5,#65.    : LAST CHARACTER ?
2815 012412 001754          BEQ 14$
2816 012414 017704 167374  MOV @DZVRBUF,R4 : FOR GOOD MEASURE
2817 012420 005704          TST R4        : DATA VALID SHOULD = 0
2818 012422 100001          BPL 17$       : YES
2819 012424 104017          ERROR 17      : DATA VALID SHOULD = 0
2820 012426 040277 167372  17$: BIC R2,@DZVTCR : CLR TCR BIT
2821 012432 104401          SCOP1        : LOOP?
2822 012434 005237 001374  21$: INC SAVLIN    : INC EXPECTED LINE
2823 012440 104420          SHIFT      : NEXT LINE
2824 012442 000137 012140  JMP 3$         : YES
2825
2826                                     : TIGHT SCOPE LOOP FOR THIS TEST. SENDS 20. CHARACTERS
2827                                     : ON DZV LINE PREVIOUSLY SELECTED CONTINUOUSLY WHILE SW09=1.
2828                                     : USED TO SCOPE SILO ALARM PULSES, ETC.
2829
2830 012446 052777 010040 167334 18$: BIS #MSENAB!SILOEN,@DZVCSR : SETUP DEVICE
2831 012454 012777 012522 167362  MOV #20$,@DZVTIV : SETUP TRANSMITTER VECTOR
2832 012462 012701 000024  MOV #20.,R1     : TEMPORARY COUNT OF CHARACTER BURST

```

```

2833 012466 050277 167332      BIS      R2,@DZVTCR      ;ENABLE LINE
2834 012472 052777 040000 167310  BIS      #TIE,@DZVCSR    ;ENABLE INTERRUPTS
2835 012500 106427 000000      MTPS     #0              ;LOWER PRIORITY
2836 012504 000001      19$:    WAIT            ;ALLOW INTERRUPTS
2837 012506 077102      SOB      R1,19$         ;RED E COUNT. ALL CHARACTERS SENT?
2838 012510 042777 050040 167272  BIC      #SILOEN!MSENAB!TIE,@DZVCSR ;RESET SILO COUNTER, CLEAR STROBE
2839 012516 104401      SCOP1    ;LOOP AGAIN?
2840 012520 000742      BR       17$           ;IF NOT, RETURN TO WHERE YOU LEFT OFF
2841 012522 112777 000252 167304 20$:    MOVB     #252,@DZVTDR    ;SEND A CHARACTER
2842 012530 000002      RTI      ;ALLOW MORE CHARACTERS TO COME
2843      ;***** TEST 2 *****
2844      ;*THIS TEST THAT "SILO ENABLE" WILL INHIBIT
2845      ;*RECEIVER INTERRUPTS AND THAT ON THE
2846      ;*16TH CHAR THAT "SILO ALARM" WILL CAUSE AN
2847      ;*INTERRUPT WITH "RIE" SET.
2848      ;*THIS WILL DO ALL SELECTED LINES ONE AT A TIME.
2849      ;*ERROR PRINTOUTS WILL REPORT TRANSMITTING LINE NO.
2851      ;** TEST 2
      ;*****
      TST2:  SCOPE
      MOV     #2,$STSTM      ;LOAD THE NUMBER OF THIS TEST
      MOV     #TST3,NEXT    ;POINT TO THE START OF THE NEXT TEST
      MOV     #3$,LOCK      ;SET FOR LOOP
      DCLASM  ;SET DCLR IN CSR AND SET MNTFLG
      LPRSET  ;LOAD LINE PARAMETERS
      CLR     SAVLIN        ;INIT LINE INDICATOR
      BUFSET  ;ZERO DATA BUFFER
      MOV     #1,R2         ;LINE POINTER
      MOV     #11$,@DZVRIV  ;SET FOR UNEXPECTED INTER.
      MOV     #MASK,@DZVRIS ;SET PRIO.
      BIS     #MSENAB!SILOEN!RIE,@DZVCSR ;START SCANNER & SET SILO ENABLE
      BIT     R2,LINE       ;VALID LINE?
      BEQ     18$           ;IF NOT GO TO NEXT LINE
      TST     @DZVRBUF      ;EMPTY THE SILO
      BMI     -4            ;BR IF DATA VALID IS SET!
      MTPS     #0           ;SET PROCESSOR PRIORITY TO 0
      MOV     SAVLIN,R0     ;MAKE OFFSET
      ASL     R0            ;MAKE POWER OF TWO
      MOV     R2,@DZVTCR    ;SET TCR BIT
      CLR     R4
      5$:    TST     @DZVCSR
      6$:    BMI     7$
      DELAY
      INC     R4
      BNE     6$
      ERROR   3
      7$:    MOVB     TD0(R0),@DZVTDR ;*TRDY FAILED TO SET
      INC     TD0(R0)        ;LOAD A CHARACTER
      CMP     #15.,TD0(R0)   ;SET UP NEXT CHARACTER
      BEQ     8$            ;15 CHARS YET?
      BIT     #SILOAL,@DZVCSR ;SILO ALARM = 0 ?
      BEQ     +4            ;YES
      ERROR   13           ;*SILO ALARM SHOULD NOT = 1
      BR     6$           ;UNTIL 16. DATA CHARACTERS
2852 012550 012737 012574 001364      MOV     #3$,LOCK
2853 012556 104417      DCLASM
2854 012560 104421      LPRSET
2855 012562 005037 001374      CLR     SAVLIN
2856 012566 104422      BUFSET
2857 012570 012702 000001      MOV     #1,R2
2858 012574 012777 013004 167236 3$:    MOV     #11$,@DZVRIV
2859 012602 012777 000200 167232      MOV     #MASK,@DZVRIS
2860 012610 052777 010140 167172      BIS     #MSENAB!SILOEN!RIE,@DZVCSR
2861      ;START SCANNER & SET SILO ENABLE
2862 012616 030237 001366      BIT     R2,LINE
2863 012622 001477      BEQ     18$
2864 012624 005777 167164      TST     @DZVRBUF
2865 012630 100775      BMI     -4
2866 012632 106427 000000      MTPS     #0
2867 012636 013700 001374      MOV     SAVLIN,R0
2868 012642 006300      ASL     R0
2869 012644 010277 167154      MOV     R2,@DZVTCR
2870 012650 005004      CLR     R4
2871 012652 005777 167132 5$:    TST     @DZVCSR
2872 012656 100404      BMI     7$
2873 012660 104414      DELAY
2874 012662 005204      INC     R4
2875 012664 001372      BNE     6$
2876 012666 104003      ERROR   3
2877 012670 116077 001426 167136 7$:    MOVB     TD0(R0),@DZVTDR
2878 012676 005260 001426      INC     TD0(R0)
2879 012702 022760 000017 001426      CMP     #15.,TD0(R0)
2880 012710 001406      BEQ     8$
2881 012712 032777 020000 167070      BIT     #SILOAL,@DZVCSR
2882 012720 001401      BEQ     +4
2883 012722 104013      ERROR   13
2884
2885 012724 000752      BR     6$

```

CVDZB-B MACY11 30G(1063) 10-AUG-81 11:11 PAGE 25-49  
 CVDZBB.P11 10-AUG-81 10:56

DZV11 DEVICE DIAGNOSTICS.

COPYRIGHT 1977 DIGITAL EQUIP. CORP.

SEQ 0067

```

2886 012726 012777 013012 167104 8$:  MOV    #12$,@DZVRIV    ;SET NEW VECTOR
2887 012734 005777 167050          TST    @DZVCSR      ;READY FOR 16TH CHAR
2888 012740 100375          BPL    .-4
2889 012742 016077 001426 167064    MOV    TD0(R0),@DZVTDR ;LOAD THE 16TH CHAR.
2890 012750 005004          CLR    R4
2891 012752 032777 020000 167030 9$:  BIT    #SILOAL,@DZVCSR
2892 012760 001005          BNE    10$
2893 012762 104414          DELAY
2894 012764 005204          INC    R4
2895 012766 001371          BNE    9$
2896 012770 104014          ERROR  14          ;*SILO ALARM FAILED TO SET!
2897 012772 000410          BR     17$          ;SILO ALARM SHOULD =1 AFTER 16.
2898                                     ;DATA CHARACTERS
2899                                     ;STALL
2899 012774 000240          10$:  NOP
2900 012776 000240          NOP
2901 013000 104027          ERROR  27          ;SILO ALARM NOT INTERRUPTING.
2902 013002 000404          BR     17$          ;CONTINUE TEST.
2903 013004 022626          11$:  POP2SP ;FAKE RTI
2904 013006 104012          ERROR  12          ;RX SHOULD NOT INTERRUPT
2905 013010 000401          BR     17$          ;CONTINUE
2906 013012 022626          12$:  POP2SP ;GOOD INTERRUPT TO HERE.
2907 013014 040277 167004 17$:  BIC    R2,@DZVTCR   ;CLR TCR BIT
2908 013020 104401          SCOP1 ;LJOP?
2909 013022 005237 001374 18$:  INC    SAVLIN      ;INC EXPECTED LINE
2910 013026 104420          SHIFT ;NEXT LINE
2911 013030 000661          BR     3$          ;YES

```

```

2913
2914
2915
2916
2917
2919
(5)
(4) 013032 000004
(2) 013034 012737 000003 001246
(2) 013042 012737 013574 001362
2920 013050 104417
2921 013052 013737 001366 013572
2922 013060 013737 001366 013312
2923 013066 104421
2924 013070 104422
2925 013072 012777 013314 166740
2926 013100 012777 000200 166734
2927 013106 012777 013200 166730
2928 013114 012777 000200 166724
2929 013122 052777 040140 166660
2930 013130 113777 001366 166666
2931 013136 106427 000000
2932
2933
2934 013142 005037 013176
2935 01314 104414
2936 013150 105737 013572
2937 013154 001002
2938 013156 000137 013520
2939 013162 005237 013176
2940 01316 001367
2941 013170 104007
2942 013172 104011
2943 013174 104400
2944 013176 000000
2945
2946
2947 013200 117703 166603
2948 013204 042703 177774
2949 013210 010304
2950 013212 010337 001374
2951 013216 005777 166566
2952 013222 100401
2953 013224 104003
2954 013226 012702 000001
2955 013232 105303
2956 013234 100402
2957 013236 006302
2958 013240 000774
2959 013242 030237 001366
2960 013246 001001
2961 013250 104015
2962 013252 030237 013312
2963 013256 001003
2964 013260 040277 166540
2965 013264 000411

```

```

***** TEST 3 *****
*THIS TEST RUNS ALL LINES FULL BORE
*BASED UPON QUALIFIED LINES
*..THIS IS AN INTERRUPT TEST ON THE RECEIVER AND
*TRANSMITTER
::* TEST 3
*****
TST3: SCOPE
MOV #3,$STNM ;LOAD THE NUMBER OF THIS TEST
MOV #TST4,NEXT ;POINT TO THE START OF THE NEXT TEST
DCLASM ;SET DCLR IN CSR AND SET MNTFLG
MOV LINE,RXTCR ;SET IMAGE OF TCR BITS
MOV LINE,XTXCR ;SET IMAGE OF TCR BITS
LPRSET ;LOAD LINE PARAMETERS
BUFSET ;ZERO DATA BUFFER
MOV #RXSVC,@DZVRIV ;SET UP REC INTR VECTOR
MOV #MASK,@DZVRIS ;STATUS
MOV #TXSVC,@DZVTIV ;SET UP TRANS INTR VECTOR
MOV #MASK,@DZVTIS ;STATUS
BIS #MSENAB!RIE!TIE,@DZVCSR ;SET MASTER SCAN ENABLE
MOVB LINE,@DZVTXCR ;SET TCR BITS
MTPS #CLEAR ;ALLOW INTERRUPTS

SNAP: CLR 4$ ;CLEAR DELAY COUNTER
2$: DELAY ;WAIT FOR RECEIVERS TO FINISH
TSTB RXTCR ;WAIT FOR ALL RECIEVERS TO FINISH
BNE 3$
JMP OUT
3$: INC 4$ ;INCREMENT DELAY COUNTER
BNE 2$ ;DELAY FINISHED?
ERROR 7 ;*TRANSMITTER FAILED TO INTERRUPT
ERROR 11 ;*RECEIVER FAILED TO INTERRUPT
ADVANCE ;LEAVE THIS TEST
4$: 0

;TRANS INTR SVC ROUTINE
TXSVC: MOVB @DZVCSR,R3 ;FIND LINE NO.
BIC #^C<3>,R3 ;ISOLATE LINE NO.
MOV R3,R4 ;SAVE LINE NO.
MOV R3,SAVLIN ;SAVE LINE NO.
TST @DZVCSR ;TRANS READY SET ?
BMI +4
ERROR 3 ;*TRANSMITTER FAILED
MOV #1,R2 ;SET UP POSITION POINTER
3$: DECB R3 ;IS IT THIS LINE ?
BMI 4$ ;YES
ASL R2 ;UP THE LINE #
BR 3$ ;GO 'ROUND AGAIN
4$: BIT R2,LINE ;VALID LINE?
BNE +4 ;YES
ERROR 15 ;NO,INVALID LINE!!!!
BIT R2,XTXCR ;DATA FINISHED?
BNE 6$ ;IF NOT SEND CHAR.
BIC R2,@DZVTXCR ;CLEAR TCR BIT
BR 5$ ;RETURN

```

CVDZB-B MACY11 30G(1063) 10-AUG-81 11:11 PAGE 26-1  
 CVDZBB.P11 10-AUG-81 10:56

DZV11 DEVICE DIAGNOSTICS.

COPYRIGHT 1977 DIGITAL EQUIP. CORP.

SEQ 0069

```

2966 013266 006304      6$:  ASL      R4      :MAKE POWER OF 2
2967 013270 116477 001426 166536  :MOV      TD0(R4),@DZVTDR :LOAD CHARACTER
2968 013276 105264 001426      :INCB     TD0(R4)      :SET UP NEXT CHARACTER
2969 013302 001002      :BNE     5$      :LAST CHARACTER ?
2970 013304 040237 013312      :BIC     R2,TXTCR  :INDICAT LINE FINISHED
2971 013310 000002      5$:  RTI
2972
2973 013312 000000      TXTCR: 0
2974
2975      :REC INTR SVC ROUTINE
2976 013314 105777 166470      RXSVC:  TSTB     @DZVCSR      :REC DONE ?
2977 013320 100401      :BMI     .+4      :YES
2978 013322 104004      :ERROR   4        :FALSE INTERRUPT
2979 013324 032777 020000 166456      :BIT     #SILOAL,@DZVCSR :SILO ALARM?
2980 013332 001401      :BEQ     .+4      :NO
2981 013334 104013      :ERROR   13       :SILO ALARM SHOULD NOT =1
2982 013336 017704 166452      :MOV     @DZVRBUF,R4 :SAVE IT
2983 013342 010403      :MOV     R4,R3
2984 013344 000303      :SWAB    R3
2985 013346 042703 177774      :BIC     #^C<3>,R3  :STRIP JUNK
2986 013352 010337 001374      :MOV     R3,SAVLIN  :SAVE LINE NUMBER
2987 013356 005704      :TST     R4        :DATA VALID?
2988 013360 100401      :BMI     4$        :IF YES SKIP ERROR PRINTOUT
2989 013362 104023      :ERROR   23       :YOU LOSE ...DATA VALID WAS'NT SET
2990 013364 032704 040000      4$:  :BIT     #OVERRUN,R4 :TEST FOR OVERRUN
2991 013370 001401      :BEQ     1$        :IF NO OVERRUN SKIP ERROR
2992 013372 104024      :ERROR   24       :DATA OVERRUN
2993 013374 032704 020000      1$:  :BIT     #FRMERR,R4 :DATA FRAMING ERROR
2994 013400 001401      :BEQ     2$        :IF NO FRAMING ERROR CONTINUE
2995 013402 104025      :ERROR   25       :FRAMING ERROR
2996 013404 032704 010000      2$:  :BIT     #PARER,R4  :TEST FOR PARITY ERROR
2997 013410 001401      :BEQ     3$        :BRANCH IF NO ERROR
2998 013412 104026      :ERROR   26       :TYPE OUT PARITY ERROR
2999 013414 012702 000001      3$:  :MOV     #1,R2     :SET UP POSITION POINTER
3000 013420 105303      5$:  :DECB    R3
3001 013422 10C402      :BMI     6$
3002 013424 006302      :ASL     R2        :RE POSITION POINTER
3003 013426 000774      :BR      5$        :GO 'ROUND AGAIN
3004 013430 030237 001366      6$:  :BIT     R2,LINE   :LINE VALID ?
3005 013434 001001      :BNE     .+4      :YES
3006 013436 104015      :ERROR   15       :INVALID LINE #
3007 013440 013703 001374      :MOV     SAVLIN,R3 :GET THE LINE NUMBER AGAIN
3008 013444 006303      :ASL     R3        :USE R3 AS A POINTER IN THE DATA TABLE
3009 013446 126304 001436      :CMPB   TRO(R3),R4 :DOES THE DATA CHARACTER COMPARE ?
3010 013452 001410      :BEQ     7$        :YES
3011 013454 013705 001374      :MOV     SAVLIN,R5 :MOVE LINE NO INTO EXPECTED
3012 013460 000305      :SWAB    R5        :ADJUST TO HIGH BYTE
3013 013462 052705 100000      :BIS     #DVALID,R5 :SET DVALID IN EXPECTED
3014 013466 056305 001436      :BIS     TRO(R3),R5 :SET DATA IN EXPECTED
3015 013472 104005      :ERROR   5        :*NO, DATA DOES NOT COMPARE
3016 013474 005263 001436      7$:  :INC     TRO(R3)   :SET UP FOR NEXT CHARACTER
3017 013500 105763 001436      :TSTB   TRO(R3)   :ALL CHARS DONE?
3018 013504 001002      :BNE     .+6
3019 013506 040237 013572      :BIC     R2,RXTCR  :ZERO LINE DONE INDICATOR.
3020 013512 012716 013142      :MOV     #SNAP,(SP) :RESET THE BACKGROUND TIMING LOOP
3021 013516 000002      :RTI

```

```

3022
3023
3024
3025 013520 106427 000200
3026 013524 104413
3027 013526 005003
3028 013530 005037 001374
3029 013534 012702 000001
3030 013540 030237 001366
3031 013544 001405
3032 013546 022763 000400 001436
3033 013554 001401
3034 013556 104030
3035
3036 013560 005237 001374
3037 013564 005723
3038 013566 104420
3039 013570 000763
3040 013572 000000

```

```

OUT: ;FINISH UP ROUTINE
MTPS #MASK ;STOP ALL INTERRUPTS
DEVICE.CLR ;CLEAR ALL INTERRUPTS AWAY
CLR R3
CLR SAVLIN
MOV #1,R2
1$: BIT R2,LINE ;VALID LINE ?
BEQ 2$ ;NO
CMP #400,TR0(R3) ;RECEIVED A BINARY COUNT PATTERN ?
BEQ +4 ;YES
ERROR 30 ;THE LINE FAILED TO RECEIVE A FULL
;BINARY COUNT PATTERN
2$: INC SAVLIN ;SET UP FOR NEXT LINE
TST (R3)+ ;ADD 2
SHIFT ;SET UP NEXT LINE POINTER
BR 1$ ;FINISHED ?
RXTCR: 0 ;RX IMAGE OF TCR BITS

```

```

***** TEST 4 *****
:*DZV11 RELATIVE TIMING TEST.
:*EACH SELECTED LINE WILL IN TURN RUN 16. CHARS
:*AT ALL BAUD RATES AND THEN THE HIGHEST BAUD
:*WITH ALL CHAR LENGTHS. EACH NEW PARAMETER SHOULD
:*DECREASE IN TIME FROM THE PREVIOUS PARAMETERS SELECTED.
:*THE TIME IS CHECKED AGAINST THE LAST PARAMETER USED
:* AND A LOWER TIME IS EXPECTED ON THE CURRENT PARAMETER.
:*PARAMETERS ARE:
:* EIGHT BITS/PER/CHAR - TWO STOP BITS AT
:* 50, 75, 110, 134.5, 150, 300, 600, 1200, 1800, 2000
:* 2400, 3600, 4800, 7200, 9600 BAUD.
:* 19.2 K BAUD - TWO STOP BITS AT
:* SEVEN, SIX, FIVE BIT/PER/CHAR.
:*AFTER EACH LINE HAS FINISHED ALL THE ABOVE PARAMETERS
:*THE NEXT SELECTED LINE IS THEN TESTED.
:*WHEN RUNNING UNDER THE APT MANUFACTURING SYSTEM
:*THIS TEST IS ONLY RUN THE FIRST PASS

```

::\* TEST 4

\*\*\*\*\*

```

(5)
(4) 013574 000004
(2) 013576 012737 000004 001246
(2) 013604 012737 014212 001362
(1) 013612 012737 013732 001364
3063 013620 132737 000001 001140
3064 013626 001405
3065 013630 005737 001126
3066 013634 001402
3067 013636 000177 165520
3068 013642 012737 000002 001354
3069 013650 005037 015214
3070 013654 005037 001374
3071 013660 005037 001376
3072 013664 012702 000001
3073 013670 012703 010070

```

```

TST4: SCOPE
MOV #4,$TSTNM ;LOAD THE NUMBER OF THIS TEST
MOV #TST5,NEXT ;POINT TO THE START OF THE NEXT TEST
MOV #3,$LOCK ;USE THIS ADDRESS IF A TIGHT SCOPE LOOP IS SELECTED
BITB #1,$ENV ;RUNNING UNDER APT?
BEQ 10$ ;IF NOT CONTINUE WITH TEST
TST $PASS ;IF YES IS THIS FIRST PASS
BEQ 10$ ;IF NOT 1ST PASS SKIP TEST
JMP @NEXT
30$: MOV #2,$TIMES ;SET UP FOR 2 ITERATIONS
CLR OFFSET ;RESET THIS VARIABLE
CLR SAVLIN ;RESET LINE NUMBER INDICATOR
CLR XMTLIN ;USE THIS WORD TO TELL WHAT LINE TRANSMITTED
MOV #1,R2 ;USE R2 AS A BIT POINTER
MOV #RCVON!$50!EIGHT!TWO$STOP,R3 ;BUILD TEMPORARY PARAMETERS

```

```

3074 013674 030237 001366 1$: BIT R2,LINE ;IS THIS LINE ACTIVE?
3075 013700 001014 BNE 3$ ;IF SO, GO GET STARTED
3076 013702 012703 010070 2$: MOV #RCVON!S50!EIGHT!TWO STOP,R3 ;LOAD PARAMETERS TEMPORARILY
3077 013706 005237 001376 INC XHTLIN ;POINT TO THE NEXT LINE TO TRANSMIT
3078 013712 042703 000007 BIC #7,R3 ;MAKE SURE TEMPORARY PARAMETERS POINT TO 0
3079 013716 053703 001376 BIS XHTLIN,R3 ;ADD DESIRED LINE NUMBER
3080 013722 005037 015214 CLR OFFSET
3081 013726 104420 SHIFT ;POINT TO THE NEXT LINE
3082 013730 000761 BR 1$ ;PROCESS THE NEXT LINE
3083 013732 3$: DCLASH ;CLEAR DEVICE AND SET MAINT BIT IF I MODE
(1) 013732 104417 BIC #RCVON,R3 ;ZERO PARAHTERS FOR TX LINE
3084 013734 042703 010000 MOV R3,ADZVLPR ;LOAD PARAHTERS FOR TX
3085 013740 010377 166054 TST MODE ;STAGGERED?
3086 013744 005737 001372 BPL 100$ ;BR IF NO
3087 013750 100007 CLC ;SET UP LINE
3088 013752 000241 ROR R3 ;
3089 013754 006003 BCC 98$ ;BR IF LINE WAS EVEN
3090 013756 103002 CLC ;PREPARE TO FIXE LINE EVEN
3091 013760 000241 BR 99$ ;CONTINUE
3092 013762 000401 98$: SEC ;PREPARE TO MAKE LINE ODD
3093 013764 000261 99$: ROL R3 ;SET ALTERED LINE
3094 013766 006103 100$: BIS #RCVON,R3 ;SET RX ON
3095 013770 052703 010000 MOV R3,ADZVLPR ;LOAD RX PARAMETERS
3096 013774 010377 166020 MOV R3,SAVLIN ;SET FOR RECEIV. LINE
3097 014000 010337 001374 BIC #C<3>,SAVLIN ;ISOLATE LINE NO.
3098 014004 042737 177774 001374 BIC #3,R3 ;CLEAR OLD LINE #
3099 014012 042703 000003 BIS XHTLIN,R3 ;SET LINE UP AGAIN
3100 014016 053703 001376 MOV R3,REGIST ;SAVE PARAMETERS FOR PRINTOUT
3101 014022 010337 001402 BUFSET ;ZERO DATA BUFFER
3102 014026 104422 CLR $TMP0 ;USE $TMP0 TO COUNT TOTAL NUMBER OF TRANSHISSIONS
3103 014030 005037 001342 CLR $TMP1 ;INITIALIZE THE TIMER
3104 014034 005037 001344 CLR $TMP3 ;INITIALIZE THESE BITS ALSO
3105 014040 005037 001350 MOV #20,XHTCNT ;SET HOW MANY CHARACTERS TO TRANSHIT
3106 014044 012737 000020 001400 MOV #XHTSRV,ADZVTIV
3107 014052 012777 014642 165764 MOV #RXISR1,ADZVRIV
3108 014060 012777 015012 165752 MOV #FASK,ADZVRIS
3109 014066 012777 000200 165746 MOV #FASK,ADZVTIS
3110 014074 012777 000200 165744 MOV R2,ADZVTCR ;START THE VALID LINE
3111 014102 110277 165716 MOVB #TIE!RIE!HSENAB,ADZVCSR
3112 014106 052777 040140 165674 BIS #0 ;LOWER THE PRIORITY TO ALLOW INTERRUPTS
3113 014114 106427 000000 HTPS #0 ;IS ROUTINE DONE?
3114 014120 032777 000100 165662 4$: BIT #RIE,ADZVCSR ;WHEN ALL IS DONE RX IE IS CLEARED IN ISR.
3115 014126 001407 BEQ 5$ ;INCREMENT TIMER
3116 014130 005237 001344 INC $TMP1 ;WHEN IT OVERFLOWS
3117 014134 001371 BNE 4$ ;CATCH CARRY
3118 014136 005237 001350 INC $TMP3 ;CONTINUE TEST
3119 014142 001366 BNE 4$ ;INTERRUPTS NOT FINISHED
3120 014144 104011 ERROR 11 ;<^G>?
3121 014146 004737 007126 5$: JSR PC,SERV.G ;LOOP?
3122 014152 104401 SCOP1
3123 014154 062737 000002 015214 ADD #2,OFFSET
3124 014162 022703 017400 CHP #17400,R3
3125 014166 003006 BGT 6$
3126 014170 032703 000030 BIT #BIT4+BIT3,R3 ;IS CHARACTER SIZE DONE?
3127 014174 001642 BEQ 2$
3128 014176 162703 000010 SUB #BIT3,R3

```



```

3129 014202 000653
3130 014204 062703 000400
3131 014210 000650
3132
(1)
(1)
(1)
(1)
(1)
(1)
(1)
(1)
(1)
(3)
(6)
(5) 014212 000004
(3) 014214 012737 000005 001246
(2) 014222 012737 004146 001362
(1) 014230 005737 001372
(1) 014234 100131
(1) 014236 105037 001425
(1) 014242 104413
(1) 014244 013701 001370
(1) 014250 042701 000200
(1) 014254 052701 000100
(1) 014260 012702 000001
(1) 014264 030237 001366
(1) 014270 001420
(1) 014272 105737 001425
(1) 014276 001004
(1) 014300 032701 000001
(1) 014304 001006
(1) 014306 000403
(1) 014310 032701 000001
(1) 014314 001402
(1) 014316 052701 000200
(1) 014322 010177 165472
(1) 014326 042701 000200
(1) 014332 005201
(1) 014334 006302
(1) 014336 032702 000020
(1) 014342 001750
(1) 014344 005037 001374
(1) 014350 005037 001342
(1) 014354 005003
(1) 014356 012737 000040 001400
(1) 014364 104422
(2) 014366 012777 014642 165450
(2) 014374 012777 014522 165436
(2) 014402 012777 000200 165432
(2) 014410 012777 000200 165430
(2) 014416 052777 040140 165364
(1) 014424 113777 001366 165372
(1) 014432 106427 000000
(1) 014436 005037 014514
(1) 014442 005037 014516
(1) 014446 032777 000100 165334

```

```

BR 3$
6$: ADD #400,R3
BR 3$
:***** TEST 5 *****
:*THE MAIN FUNCTION OF THIS TEST IS TO VERIFY
:*THAT 'PE' (PARITY ERROR) CAN BE FLAGGED BY
:*THE UARTS. THIS TEST WILL NOT BE DONE UNLESS
:*YOU ARE IN 'STAGGERED' MODE.
:*40(8) CHARS ARE USED FOR THIS TEST.
:*ALL SELECTED LINES WILL BE ENABLED AT THE SAME TIME.
:*THIS TEST FIRST CHECKS EVEN PARITY FOR ODD LINES AND
:*ODD PARITY FOR EVEN LINES, THEN IT CHECKS THE REVERSE.
::* TEST 5
:*****
TST5: SCOPE
MOV #5,$STNM ;LOAD THE NUMBER OF THIS TEST
MOV #SEOP,NEXT ;POINT TO THE END-OF-PASS HANDLER
TST MODE ;IS THIS STAGGERED MODE?
BPL 17$ ;IF NOT, DON'T DO THIS TEST
CLRB DONFLG ;SET UP FOR FIRST TEST PASS
14$: DEVICE.CLR ;SET DCLR IN CSR
MOV PAR,R1 ;USE R1 TO BUILD PARAMETERS TO BE LOADED
BIC #ODDPAR,R1 ;MAKE SURE ODD PARITY ISN'T SET
BIS #PARITY,R1 ;MAKE SURE PARITY IS TURNED ON
MOV #1,R2 ;USE R2 AS A LINE POINTER
1$: BIT R2,LINE ;IS THIS A VALID LINE?
BEQ 3$ ;IF NOT, SKIP TO THE NEXT LINE
TSTB DONFLG ;FIRST PASS THROUGH TEST?
BNE 15$ ;IF NO BRANCH
BIT #BIT0,R1 ;IS THIS LINE AN ODD LINE?
BNE 2$ ;IF IT'S ODD, USE EVEN PARITY
BR 16$ ;IF EVEN SET FOR ODD PARITY
15$: BIT #BIT0,R1 ;IF THE LINE IS EVEN SET FOR EVEN PAR.
BEQ 2$ ;GO LOAD PARAMETER
16$: BIS #ODDPAR,R1 ;IF IT'S ODD, USE ODD PARITY
2$: MOV R1,@ZVLPR ;LOAD THE LINE PARAMETER REGISTER
BIC #ODDPAR,R1 ;SET UP THE NEXT PARITY TO EVEN
3$: INC R1 ;POINT TO THE NEXT LINE
ASL R2
BIT #BIT4,R2 ;ALL LINES DONE?
BEQ 1$ ;IF NOT, GO CHECK THE NEXT LINE
CLR SAVLIN ;CLEAR THE LINE NUMBER INDICATOR
CLR $TMP0 ;USE $TMP0 TO COUNT TOTAL NUMBER OF TRANSMISSIONS
CLR R3 ;USE R3 TO COUNT TOTAL NUMBER OF RECEPTIONS
MOV #40,XMTCNT ;TRANSMIT A BINARY COUNT PATTERN(00-40)
BUFSET ;ZERO BUFFER AREA
MOV #XMTSRV,@ZVTIV ;SET UP THE TRANSMITTER INTERRUPT VECTOR
MOV #9$,@ZVRIV ;SET UP THE RECEIVER INTERRUPT VECTOR
MOV #MASK,@ZVRIS ;SET THE INTERRUPT VECTOR STATUS
MOV #MASK,@ZVTIS ;SET TRANSMITTER INTERRUPT PRIORITY
BIS #RIE,!IE,!MSENAB,@ZVCSR ;ENABLE THE DEVICE
MOVB LINE,@ZVTCR ;ENABLE ALL SELECTED LINES
MTPS #0 ;ALLOW INTERRUPTS
4$: CLR 7$
(1) CLR 8$
5$: BIT #RIE,@ZVCSR ;WHEN RX DONE: RIE WILL =0

```

```

(1) 014454 001407 BEQ 6$ :BR IF ALL DONE
(1) 014456 005237 014514 INC 7$
(1) 014462 001371 BNE 5$
(1) 014464 105237 014516 INCB 8$
(1) 014470 100366 BPL 5$
(1) 014472 104011 ERROR 11 :*RX FAILED TO FINISH (INTERRUPT)
(1) 014474 106427 000200 6$: MTPS #MASK :SHUT OFF INTERRUPTS
(1) 014500 105737 001425 TSTB DONFLG :IS THIS SECOND TEST PASS
(1) 014504 001005 BNE 17$ :IF SO GET OUT
(1) 014506 105237 001425 INCB DONFLG :INDICATE FIRST TEST PASS DONE
(1) 014512 000653 BR 14$ :START OVER
(1) 014514 000000 7$: 0
(1) 014516 000000 8$: 0
(1) 014520 104400 17$: ADVANCE
(1)
(1)
(1) :RECEIVER SERVICE ROUTINE
(1)
(1) 014522 017704 165266 9$: MOV @DZVRBUF,R4 :GET THE CHARACTER
(1) 014526 010401 MOV R4,R1 :COPY THE RECEIVED INFORMATION
(1) 014530 000301 SWAB R1 :GET THE LINE NUMBER IN THE LOWER BYTE
(1) 014532 042701 177774 BIC #C<3>,R1 :ISOLATE THE LINE NUMBER
(1) 014536 010137 001374 MOV R1,SAVLIN :SET LINE INDIC. TO RECEIVING LINE
(1) 014542 005704 TST R4 :IS DATA VALID SET?
(1) 014544 100401 BMI 10$ :IF YES DON'T PRINT ERROR
(1) 014546 104023 ERROR 23 :DATA VALID NOT SET
(1) 014550 010105 10$: MOV R1,R5 :BUILD LINE NO. FOR
(1) 014552 000305 SWAB R5 :EXPECTED DATA IN RECEIVER BUFFER
(1) 014554 006301 ASL R1 :ADJUST R1 FOR OFFSET
(1) 014556 156105 001436 BISB TR0(R1),R5 :LOAD CHARACTER IN EXPECTED
(1) 014562 052705 10000 BIS #DVALID!PARER,R5 :BUILD WHAT WAS EXPECTED
(1) 014566 020405 CMP R4,R5 :DOES RECEIVED=EXPECTED
(1) 014570 001401 BEQ 12$ :IF YES DON'T PRINT ERROR
(1) 014572 104006 ERROR 6 :*ERROR- DID NOT GET CORRECT INFOCMATION
(1) 014574 005261 001436 12$: INC TR0(R1) :SET UP THE NEXT CHARACTER
(1) 014600 005203 INC R3 :ADD TO THE TOTAL RECEIVED COUNT
(1) 014602 032777 040000 165200 BIT #TIE,@DZVCSR :ARE TRANSMISSIONS DONE?
(1) 014610 001011 BNE 13$ :IF NO, GO RECEIVE SOME MORE
(1) 014612 023703 001342 CMP $TMP0,R3 :ARE ALL CHARACTERS RECEIVED?
(1) 014616 001006 BNE 13$ :IF NO, GO RECEIVE SOME MORE
(1) 014620 042777 000100 165162 BIC #RIE,@DZVCSR :DISABLE RECEIVER INTERRUPTS
(1) 014626 012716 014474 MOV #6$, (SP) :CRUNCH THE STACK
(1) 014632 000002 RTI :RETURN AND FINISH
(1) 014634 012716 014436 13$: MOV #4$, (SP) :CRUNCH THE STACK
(1) 014640 000002 RTI :GO BACK TO RECEIVER WAIT LOOP

```

```

3134
3135
3136
3137
3138 014642 117701 165144 XMTSRV: MOVB @HDZVCSR,R1 ;GET THE LINE NUMBER.
3139 014646 042701 177774 BIC #^C<3>,R1 ;CLEAR JUNK
3140 014652 013705 001374 MOV SAVLIN,R5 ;SAVE REC. LINE NO.
3141 014656 010137 001374 MOV R1,SAVLIN ;LOAD TRANS LINE NO FOR ERROR PRINTOUT
3142 014662 006301 ASL R1 ;ADJUST R1 FOR OFFSET
3143 014664 023761 001400 001426 CMP XMTCNT,TDO(R1) ;HAVE ALL CHAR. BEEN SENT
3144 014672 003414 BLE 6$ ;IF YES GO CLEAR TCR
3145 014674 005777 165110 TST @DZVCSK ;TRDY SET?
3146 014700 100401 BMI 2$ ;IF YES GO LOAD CHAR.
3147 014702 104003 ERROR 3 ;*TRANSMITTER NOT READY- FALSE INTERRUPT
3148 014704 116177 001426 165122 2$: MOVB TDO(R1),@DZVTDR ;LOAD THE CURRENT CHARACTER FOR THIS LINE
3149 014712 005261 001426 INC TDO(R1) ;SET UP NEXT CHARACTER FOR THIS LINE
3150 014716 005237 001342 INC $TMP0 ;UP THE NUMBER OF TRANSMISSIONS
3151 014722 000415 BR 7$ ;GO RETURN
3152 014724 012700 000001 6$: MOV #1,R0 ;SET UP A DESELECTION POINTER
3153 014730 006201 ASR R1 ;GET LINE NO. AGAIN
3154 014732 005301 12$: DEC R1 ;REDUCE THE COUNT. WAS THIS THE LINE?
3155 014734 100402 BMI 3$ ;IF SO, GO DISABLE THE ENABLE BIT FOR IT
3156 014736 006300 ASL R0 ;MOVE THE POINTER TO THE NEXT LINE
3157 014740 00077' BR 12$ ;GO CHECK THE NEXT LINE
3158 014742 140077 165056 3$: BICB RC,@DZVTDR ;DISABLE THE LINE POINTED TO BY R0
3159 014746 001003 BNE 7$ ;IF MORE LINES ARE ACTIVE, GO CONTINUE TRANSMIT
3160 014750 042777 040000 165032 BIC #TIE,@DZVCSR ;IF NOT, DISABLE TRANSMITTER INTERRUPTS
3161 014756 010537 001374 7$: MOV R5,SAVLIN ;RESTORE RECEIV. LINE
3162 014762 000002 RTI ;RETURN TO THE TIMING LOOP
3163
3164 ; RELATIVE TIME BUILDING ROUTINE
3165 ; -----
3166
3167 014764 012737 000002 001346 BUILD: MOV #2,$TMP2 ;ROTATE 2 BITS BACK INTO $TMP1
3168 014772 006037 001350 1$: ROR $TMP3 ;GET THE BITS FROM $TMP3, THE HIGH BYTE
3169 014776 006037 001344 ROR $TMP1 ;OF THE RELATIVE TIME COUNTER. PUT THEM BACK
3170 015002 005337 001346 DEC $TMP2 ;INTO $TMP1 USING THE CARRY BIT WITH
3171 ;ROTATE INSTRUCTIONS
3172 015006 001371 BNE 1$ ;REDUCE COUNT. ALL BITS BACK? IF NOT, GET MORE
3173 015010 000207 RTS PC ;RETURN TO CALLING TEST
3174

```

```

3176                                     :RECEIVER SERVICE ROUTINE
3177
3178 015012 105777 164772      RXISR1: TSTB      @DZVCSR      ;IS THE RECEIVER REALLY READY?
3179 015016 100401              BMI      1$          ;IF SO, GO SERVICE IT
3180 015020 104004              ERROR    4           ;*ERROR- RECEIVER DONE FLAG ISN'T SET
3181 015022 017704 164766      1$:  MOV      @DZVRBUF,R4 ;SAVE THE RECEIVER INFORMATION
3182 015026 100401              BMI      2$          ;IF IT WAS VALID, GO PROCESS IT
3183 015030 104023              ERROR    23          ;ERROR- DATA VALID WASN'T SET
3184 015032 032704 040000      2$:  BIT      #OVRUN,R4 ;OVERRUN ERROR FLAG SET?
3185 015036 001401              BEQ      6$          ;IF NOT DON'T TYPE ERROR
3186 015040 104024              ERROR    24          ;OVERRUN ERROR
3187 015042 032704 020000      6$:  BIT      #FRMERR,R4 ;FRAMING ERROR FLAG SET?
3188 015046 001401              BEQ      9$          ;IF NOT DON'T TYPE ERROR
3189 015050 104025              ERROR    25          ;FRAMING ERROR
3190 015052 032704 010000      9$:  BIT      #PARER,R4 ;PARITY ERROR FLAG SET?
3191 015056 001401              BEQ      3$          ;IF NOT, GO CONTINUE PROCESSING
3192 015060 104026              ERROR    26          ;ERROR- RECEIVER ERROR FLAG SET
3193 015062 013701 001374      3$:  MOV      SAVLIN,R1 ;CALCULATE THE DATA OFFSET
3194 015066 006301              ASL      R1          ;ALIGN IT ON A WORD BOUNDARY
3195 015070 120461 001436      CMPB    R4,TR0(R1) ;IS THE CHARACTER WHAT IT SHOULD BE?
3196 015074 001407              BEQ      4$          ;IF SO,GO CONTINUE PROCESSING
3197 015076 116105 001436      MOVB    TR0(R1),R5 ;GET WHAT WAS EXPECTED FOR ERROR REPORTING
3198 015102 042705 177400      BIC     #'C<377>,R5 ;ELIMINATE PROPAGATED SIGN
3199 015106 042704 177400      BIC     #'C<377>,R4 ;ISOLATE THE ACTUAL CHARACTER
3200 015112 104005              ERROR    5           ;*DATA ERROR
3201 015114 005261 001436      4$:  INC      TR0(R1) ;SET UP THE NEXT EXPECTED CHARACTER
3202 015120 122761 000020 001436 CMPB    #20,TR0(R1) ;HAVE ALL CHARACTERS BEEN RECEIVED?
3203 015126 001031              BNE      8$          ;IF NOT RETURN
3204 015130 126137 001436 001342 CMPB    TR0(R1),$TMP0 ;ALL CHARAC. RECEIVED?
3205 015136 001025              BNE      8$          ;IF SO,GO DETERMINE THE TIMING
3206 015140 004737 014764      JSR     PC,BUILD ;GET THE RELATIVE TIME (SIGNIFICANT BITS)
3207 015144 013700 015214      MOV     OFFSET,R0 ;GET POINTER
3208 015150 013760 001344 002050 MOV     $TMP1,TMTBL(R0) ;SAVE THIS TEST'S TIME
3209 015156 065737 015214      TST     OFFSET ;FIRST TEST?
3210 015162 001410              BEQ      7$          ;IF NOT, GO CHECK THE TIME
3211 015164 005740              TST     -(R0) ;POINT TO THE PREVIOUS TIME TAKEN
3212 015166 026037 002050 001344 CMP     TMTBL(R0),$TMP1 ;IS THIS TIME WHAT IT SHOULD BE?
3213 015174 101003              BHI     7$          ;IF SO, GO TO THE NEXT TEST
3214 015176 016005 002050      MOV     TMTBL(R0),R5 ;PLACE WHAT WAS EXPECTED IN R5
3215 015202 104021              ERROR    21          ;TIMING ERROR
3216 015204 042777 000140 164576 7$:  BIC     #RIE!MSENAB,@DZVCSR ;DISABLE THE DEVICE
3217 015212 000002              8$:  RTI ;RETURN TO THE PROGRAM
3218 015214 000000      OFFSET: 0
    
```

Address	Code	Value	Label	Message
3220				
3221	015216	000000		
3222	015220	000000		
3223	015222	000000		
3224				
3225	015224	015444	EM1	:ERROR
3226	015226	016570	DH1	
3227	015230	016770	DT1	
3228				
3229	015232	015517	EM2	:ERROR 2
3230	015234	016614	DH2	
3231	015236	017002	DT2	
3232				
3233	015240	015545	EM3	:ERROR 3
3234	015242	016647	DH3	
3235	015244	017020	DT3	
3236				
3237	015246	015604	EM4	:ERROR 4
3238	015250	016647	DH3	
3239	015252	017020	DT3	
3240				
3241	015254	015633	EM5	:ERROR 5
3242	015256	016661	DH4	
3243	015260	017026	DT4	
3244				
3245	015262	015662	EM6	:ERROR 6
3246	015264	016661	DH4	
3247	015266	017026	DT4	
3248				
3249	015270	000000	0	
3250	015272	000000	0	
3251	015274	000000	0	
3252				
3253	015276	000000	0	
3254	015300	000000	0	
3255	015302	000000	0	
3256				
3257	015304	015721	EM11	:ERROR 11
3258	015306	016647	DH3	
3259	015310	017020	DT3	
3260				
3261	015312	000000	0	
3262	015314	000000	0	
3263	015316	000000	0	
3264				
3265	015320	015757	EM13	:ERROR 13
3266	015322	016647	DH3	
3267	015324	017020	DT3	
3268				
3269	015326	016010	EM14	:ERROR 14
3270	015330	016647	DH3	
3271	015332	017020	DT3	
3272				
3273	015334	016042	EM15	:ERROR 15
3274	015336	000000	0	
3275	015340	000000	0	

3276				
3277	015342	016104	EM16	
3278	015344	016647	DH3	
3279	015346	017020	DT3	
3280				
3281	015350	016156	EM17	:ERROR 17
3282	015352	016647	DH3	
3283	015354	017020	DT3	
3284				
3285	015356	016214	EM20	
3286	015360	016647	DH3	
3287	015362	017020	DT3	
3288				
3289	015364	016255	EM21	:ERROR 21
3290	015366	016710	DH5	
3291	015370	017044	DT5	
3292				
3293	015372	000000	0	
3294	015374	000000	0	
3295	015376	000000	0	
3296				
3297	015400	016305	EM23	:ERROR 23
3298	015402	016647	DH3	
3299	015404	017020	DT3	
3300				
3301	015406	016335	EM24	
3302	015410	016647	DH3	
3303	015412	017020	DT3	
3304				
3305	015414	016363	EM25	
3306	015416	016647	DH3	
3307	015420	017020	DT3	
3308				
3309	015422	016413	EM26	
3310	015424	016647	DH3	
3311	015426	017020	DT3	
3312				
3313	015430	016442	EM27	
3314	015432	016647	DH3	
3315	015434	017020	DT3	
3316				
3317	015436	016510	EM30	
3318	015440	016647	DH3	
3319	015442	017020	DT3	

```

3321                                     ;ERROR MESSAGES
3325 015444 047200 020117 052502 EM1: .ASCIZ <200>/NO BUS REPLY RESPONSE FROM DZV11 REGISTER/
3326 015517      200 042522 044507 EM2: .ASCIZ <200>/REGISTER R/W FAILURE?
3327 015545      200 051124 047101 EM3: .ASCIZ <200>/TRANSMIT READY (TRDY) NOT SET/
3328 015604 051200 041505 044505 EM4: .ASCIZ <200>/RECEIVER DONE NOT SET/
3329 015633      200 040504 040524 EM5: .ASCIZ <200>/DATA COMPARISON ERROR/
3330 015662 042200 053132 030461 EM6: .ASCIZ <200>/DZV11 *RECEIVER BUFFER* ERROR/
3331 015721      200 042522 042503 EM11: .ASCIZ <200>/RECEIVER FAILED TO INTERRUPT/
3332 015757      200 044523 047514 EM13: .ASCIZ <200>/SILO ALARM SET TOO SOON/
3333 016010 051600 046111 020117 EM14: .ASCIZ <200>/SILO ALARM FAILED TO SET/
3334 016042 040600 052103 047511 EM15: .ASCIZ <200>/ACTION DETECTED ON INVALID LINE./
3335 016104 051200 040505 044504 EM16: .ASCIZ <200>/READING DZVRBUF DID NOT CLEAR SILO ALARM/
3336 016156 042200 052101 020101 EM17: .ASCIZ <200>/DATA VALID SHOULD NOT BE SET/
3337 016214 051200 041505 044505 EM20: .ASCIZ <200>/RECEIVER DONE SHOULD NOT BE SET/
3338 016255      200 042522 040514 EM21: .ASCIZ <200>/RELATIVE TIMING ERROR./
3339 016305      200 040504 040524 EM23: .ASCIZ <200>/DATA VALID IS NOT SET!/
3340 016335      200 040504 040524 EM24: .ASCIZ <200>/DATA OVERRUN IS SET!/
3341 016363      200 051106 046501 EM25: .ASCIZ <200>/FRAMING ERROR OCCURRED/
3342 016413      200 040520 044522 EM26: .ASCIZ <200>/PARITY ERROR OCCURRED/
3343 016442 051600 046111 020117 EM27: .ASCIZ <200>/SILO ALARM FAILED TO CAUSE INTERRUPT/
3344 016510 046200 047111 020105 EM30: .ASCIZ <200>/LINE DID NOT RECEIVE FULL BINARY COUNT PATTERN/
3345
3346 016570 052200 040522 020120 DH1: .ASCIZ <200>/TRAP PC DZV11 REG/
3347 016614 042600 050130 041505 DH2: .ASCIZ <200>/EXPECTED FOUND REGISTER/
3348 016647      200 044514 042516 DH3: .ASCIZ <200>/LINE NO./
3349 016661      200 054105 042520 DH4: .ASCIZ <200>/EXPECTED FOUND LINE/
3350 016710 052200 020130 044514 DH5: .ASCIZ <200>/TX LINE PREVIOUS TIME ACTUAL TIME PARAMETER/
3351
3352      016770      .EVEN
3356                                     ;DATA TABLES FOR ERROR MESSAGES
3357 016770 000002      DT1: 2
3358 016772      006      003      .BYTE 6,3
3359 016774 001330      $REG1
3360 016776      006      001      .BYTE 6,1
3361 017000 001326      $REG0
3362
3363 017002 000003      DT2: 3
3364 017004      006      004      .BYTE 6,4
3365 017006      01340      $REG5
3366 017010      006      001      .BYTE 6,1
3367 017012 001336      $REG4
3368 017014      006      001      .BYTE 6,1
3369 017016 001326      $REG0
3370
3371 017020 000001      DT3: 1
3372 017022      003      001      .BYTE 3,1
3373 017024 001374      SAVLIN
3374
3375 017026 001003      DT4: 3
3376 017030      006      004      .BYTE 6,4
3377 017032 001340      $REG5
3378 017034      006      001      .BYTE 6,1
3379 017036 001336      $REG4
3380 017040      003      001      .BYTE 3,1
3381 017042 001374      SAVLIN
3382
    
```

3383 017044 000004  
 3384 017046 003 005  
 3385 017050 001374  
 3386 017052 006 011  
 3387 017054 001340  
 3388 017056 006 007  
 3389 017060 001344  
 3390 017062 006 001  
 3391 017064 001402  
 3398  
 3399  
 3400  
 3401 017066 002450  
 3402 017070 001560  
 3403 017072 001120  
 3404 017074 000750  
 3405 017076 000660  
 3406 017100 000330  
 3407 017102 000150  
 3408 017104 000060  
 3409 017106 000040  
 3410 017110 000030  
 3411 017112 000020  
 3412 017114 000010  
 3413 017116 000001  
 3414 017120 000001  
 3415 017122 000001  
 3416 017124 000001  
 3417  
 3418  
 3419

DT5: 4  
 .BYTE 3.5  
 SAVLIN  
 .BYTE 6.9.  
 \$REG5  
 .BYTE 6.7  
 \$TMP1  
 .BYTE 6.1  
 REGIST

:TABLE OF DELAY TIMES FOR INDIVIDUAL BAUD RATES  
 :-----

DLYTBL: 2450	:TIME FOR 50 BAUD
1560	:TIME FOR 75 BAUD
1120	:TIME FOR 110 BAUD
750	:TIME FOR 134 BAUD
660	:TIME FOR 150 BAUD
330	:TIME FOR 300 BAUD
150	:TIME FOR 600 BAUD
60	:TIME FOR 1200 BAUD
40	:TIME FOR 1800 BAUD
30	:TIME FOR 2000 BAUD
20	:TIME FOR 2400 BAUD
10	:TIME FOR 3600 BAUD
1	:TIME FOR 4800 BAUD
1	:TIME FOR 7200 BAUD
1	:TIME FOR 9600 BAUD
1	:TIME OF DELAY FOR 19200 BAUD

:DELAYS WERE COMPUTED TO ALLOW MAXIMUM TIME AT EACH BAUD RATE  
 :FOR ALL TESTS TO FUNCTION CORRECTLY ON A LSI11.



```

3421
3422
3423
3424
3425
3426
3427
3428
3429
3430
3431
3432
3433
3434
3435
3436
3437 017126 005227 177777
3438 017132 001002
3439 017134 004737 000400
3440 017140 005727
3441 017142 000000
3442 017144 000207
3443
3444
3445
3446 000400 005037 017142
3447 000404 013746 000004
3448 000410 012737 000504 000004
3449 000416 012700 160010
3450 000422 005720
3451 000424 000240
3452 000426 020027 174000
3453 000432 103773
3454 000434 010037 017142
3455 000440 012700 000040
3456 000444 040037 000006
3457 000450 040037 000016
3458 000454 040037 000022
3459 000460 040037 000032
3460 000464 040037 000036
3461 000470 012737 170000 000140
3462 000476 012637 000004
3463 000502 000207
3464
3465 000504 012716 000512
3466 000510 000002
3467 000512 012637 000004
3468 000516 012700 000402
3469 000522 013701 000376
3470 000526 010602
3471 000530 012704 000570
3472 000534 014446
3473 000536 020427 000546
3474 000542 101374
3475 000544 010607

```

```

.SBTTL FALCON (KXT-11) UPGRADE ROUTINES. :::GPA
:
: THE FOLLOWING ROUTINES HAVE BEEN ADDED TO ALLOW DIAGNOSTIC(S)
: TO RUN ON A FALCON (KXT-11) BASED SYSTEM.
: TO DETERMINE WHETHER WE'RE A FALCON OR NOT, WE'LL SIZE THE 1ST 3/4 OF
: THE I/O PAGE (28K TO 31K). FALCON HAS 2KW LOCAL RAM AT 28K(+4) TO 30K
: AND A MACRO-ODT AT 30K TO 31K. CONSEQUENTLY, ALL I/O DEVICES MUST
: BE PLACED BETWEEN 174000 AND 177776. ADDITIONALLY, WE'LL STRAP THE
: EMT AND TRAP SERVICE LEVEL TO PRI6, AND SET THE HALT VECTOR SO THAT
: WE CAN STOP THE SUCKER !!
:
: TO MINIMIZE THE IMPACT OF THESE CHANGES ON FINAL PROGRAM SIZE, THE
: BULK OF THIS CODE IS PLACED IN THE FLOATING VECTOR SPACE (400-776).
: IF THE CPU AT HAND IS A FALCON (KXT11), IT STAYS THERE (NO HARM DONE).
: OTHERWISE, THE AREA IS RESTORED TO ITS ORIGINAL "TRAP-CATCHER" STATE.
:
FALCON: INC #1 ; ONCE-ONLY !!! :::GPA
        BNE 1$ ; :::GPA
        CALL KXTCHK ; EXECUTE FALCON CHECK :::GPA
1$: TST (PC)+ ; TEST FALCON FLAG... :::GPA
KXTFLAG: 0 ; ...NZ = FALCON... :::GPA
        RETURN ; ...AND RETURN TO CALLER... :::GPA
:
        SSVPC= ; :::GPA
        = 400 ; RESTORE FROM 374:376 AT END :::GPA
KXTCHK: CLR KXTFLAG ; ASSUME NOT FALCON. :::GPA
        MOV @#4,-(SP) ; SAVE ERROR VECTOR. :::GPA
        MOV #2$,@#4 ; SET A TRAP CATCHER. :::GPA
        MOV #160010,R0 ; FALCON RAM STARTS AT 28K+4. :::GPA
1$: TST (R0)+ ; :::GPA
        240 ; :::GPA
        CMP R0,#174000 ; SIZE TO 31K. :::GPA
        BLO 1$ ; :::GPA
        MOV R0,KXTFLAG ; MUST BE FALCON, SET THE FLAG :::GPA
        MOV #40,R0 ; GET PRI1 BIT... :::GPA
        BIC R0,@#6 ; ...AND LOWER BUS-ERROR... :::GPA
        BIC R0,@#16 ; ...BPT... :::GPA
        BIC R0,@#22 ; ...IOT... :::GPA
        BIC R0,@#32 ; ...EMT... :::GPA
        BIC R0,@#36 ; ...AND TRAP SERVICE TO PRI6 :::GPA
        MOV #170000,@#140 ; ENABLE "BREAK" HALT. :::GPA
        MOV (SP)+,@#4 ; RESTORE ERROR VECTOR... :::GPA
        RETURN ; ...AND RETURN. :::GPA
:
2$: MOV #3$,(SP) ; TRAP -- NOT A FALCON... :::GPA
        RTI ; ...CONTINUE. :::GPA
3$: MOV (SF)+,@#4 ; RESET ERROR VECTOR :::GPA
        MOV #402,R0 ; SET-UP TO RESTORE FLOATING... :::GPA
        MOV @#376,R1 ; ...VECTORS (400 - 776). :::GPA
        MOV SP,R2 ; SAVE STACK POINTER IN R2 :::GPA
        MOV #6$,R4 ;
4$: MOV -(R4),-(SP) ; PUSH THE RESTORE CODE... :::GPA
        CMP R4,#5$ ; ...ONTO THE STACK. :::GPA
        BHI 4$ ; :::GPA
        MOV SP,PC ; AND EXECUTE IT. :::GPA

```

```

3477
3478
3479
3480 000546 010060 177776
3481 000552 010110
3482 000554 022020
3483 000556 020027 000776
3484 000562 101771
3485 000564 010206
3486 000566 000207
3487 000570
3488
3489
3490
3491
3492
3493
3494
3495
3496 000570 023727 001174 160010
3497 000576 001003
3498 000600 012737 174040 001174
3499 000606 023727 001170 000300
3500 000614 001003
3501 000616 012737 000370 001170
3502 000624 012737 000670 002362
3503 000632 012737 174000 002366
3504 000640 012737 177770 002370
3505 000646 012737 000732 002406
3506 000654 005037 002412
3507 000660 012737 000370 002414
3508 000666 000207
3509
3510 000670 030600 052123 041440
3511 000732 030600 052123 053040
3512
3513
3514 000002
3518
3519 017146
3520 017146
3524 000001

```

```

: THIS CODE IS RELOCATED TO AND EXECUTED IN THE STACK AREA.
5$:  MOV    R0,-2(R0)      : RESTORE +2...
      MOV    R1,(R0)      : ...HALT (OR IOT).
      CMP    (R0)+(R0)+   :
      CMP    R0,#776     :
      BLOS  5$           : LOOP 'TIL DONE
      MOV    R2,SP       : THEN RESTORE SP...
      RETURN            : ...AND RETURN TO CALLER
6$:
: IF FALCON, THIS AREA IS FREE FOR ANY PROGRAM UNIQUE
: CHANGES OR DATA STRUCTURES.
: BE SURE IT DOESN'T GET SCREWED UP !!
: INIT $BASE AND $VECT1 AND TWEAK THE '$GETPAR' CALLING
: SEQUENCE TO ACCEPT THE VALID FALCON RANGE.
FALCINI: CMP    $BASE,#ABASE : IS $BASE VIRGIN ??
      BNE    1$           : SKIP NEXT IF NOT
      MOV    #174040,$BASE : YES, SET ENGINEERING DEFAULT
1$:  CMP    $VECT1,#AVECT1 : IS $VECT1 VIRGIN ??
      BNE    2$           : SKIP NEXT IF NOT
      MOV    #370,$VECT1  : YES, SET ENGINEERING DEFAULT
2$:  MOV    #3$,GETCSR+2   : SUBSTITUTE CSR TEXT...
      MOV    #174000,GETCSR+6 :
      MOV    #177770,GETCSR+10 : ...AND VALID RANGE.
      MOV    #4$,GETVEC+2   : SUBSTITUTE VECTOR TEXT...
      CLR    GETVEC+6      :
      MOV    #370,GETVEC+10 : ...AND VALID RANGE.
      RETURN            : RETURN TO CALLER.
3$:  .ASCIZ <200>'1ST CSR ADDRESS (174000:177770) '
4$:  .ASCIZ <200>'1ST VECTOR ADDRESS (000:370) '
      .EVEN
$FREE= <1000-.>/2      : FREE WORDS LEFT.
      .=$SVPC
CORMAX:
.END

```

ABASE = 160010	AUTO.S = 011364	DCLASM= 104417	DZVC16 = 001716	FRMERR= 020000
ACDW1 = 000017	AVECT1= 000300	DCLR = 000020	DZVC17 = 001730	GETCSR= 002360
ACDW2 = 000000	AVECT2= 000000	DDISP = 177570	DZVC2 = 001526	GETSWR= 007154
ACPUOP= 000000	BINWRD = 006270	DELAY = 104414	DZVC3 = 001540	GETVEC= 002404
ACTIVE = 001420	BIT0 = 000001	DEVADR = 006012	DZVC4 = 001552	HALTS = 006766
ADDW0 = 017470	BIT00 = 000001	DEVICE= 104413	DZVC5 = 001564	HDRFLG = 001423
ADDW1 = 017470	BIT01 = 000002	DH1 = 016570	DZVC6 = 001576	HDZVCS = 002012
ADDW10= 017470	BIT02 = 000004	DH2 = 016614	DZVC7 = 001610	HDZVLP = 002022
ADDW11= 017470	BIT03 = 000010	DH3 = 016647	DZVLEV = 011074	HDZVMS = 002032
ADDW12= 017470	BIT04 = 000020	DH4 = 016661	DZVLPR = 002020	HDZVRB = 002016
ADDW13= 017470	BIT05 = 000040	DH5 = 016710	DZVMSR = 002030	HDZVTC = 002026
ADDW14= 017470	BIT06 = 000100	DISPLA = 001306	DZVMUM = 001414	HDZVTD = 002036
ADDW15= 017470	BIT07 = 000200	DISPRE = 000174	DZVRBU = 002014	HILIM = 006010
ADDW2 = 017470	BIT08 = 000400	DLYCNT = 006364	DZVRIS = 002042	HT = 000011
ADDW3 = 017470	BIT09 = 001000	DLYTBL = 017066	DZVRIV = 002040	INBUF = 010424
ADDW4 = 017470	BIT1 = 000002	DONFLG = 001425	DZVTCR = 002024	INIFLG = 001422
ADDW5 = 017470	BIT10 = 002000	DSWR = 177570	DZVTDR = 002034	INSTER= 104404
ADDW6 = 017470	BIT11 = 004000	DTR0 = 000400	DZVTIS = 002046	INSTR = 104403
ADDW7 = 017470	BIT12 = 010000	DTR1 = 001000	DZVTIV = 002044	INSTR2 = 005610
ADDW8 = 017470	BIT13 = 020000	DTR2 = 002000	DZV.EN = 001740	IOTVEC= 000020
ADDW9 = 017470	BIT14 = 040000	DTR3 = 004000	DZV.MA = 001500	KXTCHK = 000400
ADEVCT= 000000	BIT15 = 100000	DT1 = 016770	EIGHT = 000030	KXTFLA = 017142
ADEVN = 000001	BIT2 = 000004	DT2 = 017002	EIGHTS= 000070	LF = 000017
ADRCNT = 006015	BIT3 = 000010	DT3 = 017020	EMTVEC= 000030	LIMITS = 005736
ADVANC= 104400	BIT4 = 000020	DT4 = 017026	EM1 = 015444	LINE = 001366
AENV = 000000	BIT5 = 000040	DT5 = 017044	EM11 = 015721	LINE0 = 001504
AENVN = 000000	BIT6 = 000100	DVALID= 100000	EM13 = 015757	LINE1 = 001516
AFATAL= 000000	BIT7 = 000200	DZCR0 = 001500	EM14 = 016010	LINE10 = 001624
AMADR1= 000000	BIT8 = 000400	DZCR1 = 001512	EM15 = 016042	LINE11 = 001636
AMADR2= 000000	BIT9 = 001000	DZCR10 = 001620	EM16 = 016104	LINE12 = 001650
AMADR3= 000000	BPTVEC= 000014	DZCR11 = 001632	EM17 = 016156	LINE13 = 001662
AMADR4= 000000	BRK0 = 000400	DZCR12 = 001644	EM2 = 015517	LINE14 = 001674
AMAMS1= 000000	BRK1 = 001000	DZCR13 = 001656	EM20 = 016214	LINE15 = 001706
AMAMS2= 000000	BRK2 = 002000	DZCR14 = 001670	EM21 = 016255	LINE16 = 001720
AMAMS3= 000000	BRK3 = 004000	DZCR15 = 001702	EM23 = 016305	LINE17 = 001732
AMAMS4= 000000	BRW = 004622	DZCR16 = 001714	EM24 = 016335	LINE2 = 001530
AMSGAD= 000000	BUFSET= 104422	DZCR17 = 001726	EM25 = 016363	LINE3 = 001542
AMSGLG= 000000	BUILD = 014764	DZCR2 = 001524	EM26 = 016413	LINE4 = 001554
AMSGTY= 000000	CHRCNT = 006266	DZCR3 = 001536	EM27 = 016442	LINE5 = 001566
AMTYP1= 000000	CLEAR = 000000	DZCR4 = 001550	EM3 = 015545	LINE6 = 001600
AMTYP2= 000000	CNVRT = 104412	DZCR5 = 001562	EM30 = 016510	LINE7 = 001612
AMTYP3= 000000	CONVRT= 104411	DZCR6 = 001574	EM4 = 015604	LOBITS = 006014
AMTYP4= 000000	CORMAX = 017146	DZCR7 = 001606	EM5 = 015633	LOCK = 001364
APASS = 000000	CO0 = 000400	DZVACT = 001406	EM6 = 015662	LOLIM = 006006
APRIOR= 000000	CO1 = 001000	DZVCSR = 002010	ERRMSG = 006736	LPRSET= 104421
APTCSU= 000040	CO2 = 002000	DZVCO = 001502	ERRVEC= 000004	LP0 = 000000
APTENV= 000001	CO3 = 004000	DZVC1 = 001514	ERTABO = 007112	LP1 = 000001
APTSIZ= 000200	CR = 000015	DZVC10 = 001622	EVEPAR= 000000	LP2 = 000002
APTSPO= 000100	CRLF = 000200	DZVC11 = 001634	EXITER = 007042	LP3 = 000003
ASWREG= 000000	CSRMAP = 011372	DZVC12 = 001646	FALCIN = 000570	MAINT = 000010
ATESTN= 000000	CYCLE = 010530	DZVC13 = 001660	FALCON = 017126	MANT0 = 001510
AUNIT = 000000	DATABP = 006762	DZVC14 = 001672	FIVE = 000000	MANT1 = 001522
AUSWR = 000000	DATAHD = 006750	DZVC15 = 001704	FIVES = 000040	MANT10 = 001630

MANT11	001642	PAR14	001676	SAVLIN	001374	S150	= 002000	TYPMSG	006642
MANT12	001654	PAR15	001710	SAVNO	001416	S1800	= 004000	T110	002054
MANT13	001666	PAR16	001722	SAVNUM	001415	S19200	= 007400	T1200	002066
MANT14	001700	PAR17	001734	SAVPC	001404	S2000	= 004400	T134	002056
MANT15	001712	PAR2	001532	SAV05	= 104407	S2400	= 005000	T150	002060
MANT16	001724	PAR3	001544	SCOPI	= 104401	S300	= 002400	T1800	002070
MANT17	001736	PAR4	001556	SERV.G	007126	S3600	= 005400	T2000	002072
MANT2	001534	PAR5	001570	SETAPT	011236	S4800	= 006000	T2400	002074
MANT3	001546	PAR6	001602	SETFLG	= 104406	S50	= 000000	T300	002062
MANT4	001560	PAR7	001614	SEVEN	= 000020	S600	= 003000	T3600	002076
MANT5	001572	PAWCH	= 104416	SEVENS	= 000060	S7200	= 006400	T4800	002100
MANT6	001604	PIRQ	= 177772	SHIFT	= 104420	S75	= 000400	T50	002050
MANT7	001616	PIRQVE	= 000240	SILQAL	= 020000	S9600	= 007000	T600	002064
MASK	= 000200	POPPO	= 012600	SILOEN	= 010000	TBITVE	= 000014	T7200	002102
MASTEK	010041	POP1SP	= 005726	SIX	= 000010	TCRO	= 000001	T75	002052
MBADLN	010154	POP2SP	= 022626	SIXS	= 000050	TCR1	= 000002	T9600	002104
MCSRX	007771	PRO	= 000000	SNAP	013142	TCR2	= 000004	VECMAP	011700
MDATA	010466	PR1	= 000040	SPACNT	006267	TCR3	= 000010	WRDCNT	006264
MEPASS	007607	PR2	= 000100	STACK	= 001120	TD0	001426	WTBS.F	006740
MERRPC	010121	PR3	= 000140	STMT	= 177774	TD1	001430	XBX	006530
MERRX	010016	PR4	= 000200	STUF	001446	TD2	001432	XCSR	004332
MERR2	007647	PR5	= 000240	SV05	006024	TD3	001434	XERR	004354
MERR3	007716	PR6	= 000300	SWR	001304	TEIGHT	002106	XHEAD	010126
MLOCK	007742	PR7	= 000340	SWREG	000176	TFIVE	002114	XMTCNT	001400
MNEW	010044	PS	= 177776	SW0	= 000001	TIE	= 040000	XMTLIN	001376
MNTFLG	001424	PSW	= 177776	SW00	= 000001	TKVEC	= 000060	XMTRV	014642
MODE	001372	PUSHRO	= 010046	SW01	= 000002	TLAST	= 014212	XPASS	004346
MPASSX	010005	PUSH1S	= 005746	SW02	= 000004	TLO	= 000000	XSTATQ	010216
MPFAIL	007544	PUSH2S	= 024646	SW03	= 000010	TL1	= 000400	XTSTM	007120
MR	007633	PURVEC	= 000024	SW04	= 000020	TL2	= 001000	XVEC	004340
MSENA	= 000040	RCVON	= 010000	SW05	= 000040	TL3	= 001400	XX	= 160210
MTITLE	001000	RDONE	= 000200	SW06	= 000100	TMTBL	002050	YY	= 000500
MTSTN	010027	REGIST	001402	SW07	= 000200	TPVEC	= 000064	ZZ	= 000020
MVECX	007777	RESREG	006764	SW08	= 000400	TRAPVE	= 000034	\$APTHD	001446
NEXT	001362	RESTAR	011070	SW09	= 001000	TRDY	= 100000	\$ATYC	005250
ODDPAR	= 000200	RESVEC	= 000010	SW1	= 000002	TRTVEC	= 000014	\$ATY1	005224
OFFSET	015214	RES05	= 104410	SW10	= 002000	TRO	001436	\$ATY3	005232
ONESTO	= 000000	RIE	= 000100	SW11	= 004000	TR1	001440	\$ATY4	005242
OUT	013520	RING0	= 000001	SW12	= 010000	TR2	001442	\$AUTOB	001300
OVRRUN	= 040000	RING1	= 000002	SW13	= 020000	TR3	001444	\$BASE	001174
PAR	001370	RING2	= 000004	SW14	= 040000	TSEVEN	002110	\$BDADR	001266
PARAM	= 104405	RING3	= 000010	SW15	= 100000	TSIX	002112	\$BDDAT	001272
PARAM1	005656	RLO	= 000000	SW2	= 000004	TST1	012070	\$CDW1	001200
PARER	= 010000	RL1	= 000400	SW3	= 000010	TST2	012532	\$CDW2	001202
PARERR	005732	RL2	= 001000	SW4	= 000020	TST3	013032	\$CHARC	005220
PARITY	= 000100	RL3	= 001400	SW5	= 000040	TST4	013574	\$CMTAG	001244
PARMD	= 104415	RUN	001412	SW6	= 000100	TST5	014212	\$CM1	= 000006
PARO	001506	RXISR1	015012	SW7	= 000200	TTST	004374	\$CM2	= 000014
PAP1	001520	RXSVC	013314	SW8	= 000400	TWOSTO	= 000040	\$CM3	= 000006
PAR10	001626	RXTCR	013572	SW9	= 001000	TXSVC	013200	\$CM4	= 000005
PAR11	001640	R6	= 000006	S110	= 001000	TXTCR	013312	\$CPUOP	001146
PAR12	001652	R7	= 000007	S1200	= 003400	TYPDAT	006752	\$CRLF	001357
PAR13	001664	SAVACT	001410	S134	= 001400	TYPE	= 104402	\$DDWO	001204

\$DDW1	001206	SETABL	001140	\$HFLG	005466	\$SVLAD	004544	\$Y	=	000023	
\$DDW10	001230	SETEND	001244	\$MSGAD	001134	\$SVPC	=	017146	\$SGET4	=	000000
\$DDW11	001232	\$FATAL	001122	\$MSGLG	001136	\$SWR	=	164000		=	017146
\$DDW12	001234	\$FFLG	005470	\$MSGTY	001120	\$SWREG	001142	.ADVAN	006366		
\$DDW13	001236	\$FILLC	001322	\$MTP1	001151	\$SWRMK	=	000000	.BEGIN	004052	
\$DDW14	001240	\$FILLS	001321	\$MTP2	001155	\$TESTN	001124	.BUFSE	006456		
\$DDW15	001242	\$FLIP	=	\$MTP3	001161	\$TIMES	001354	.CNVRT	006114		
\$DDW2	001210	\$FREE	=	\$MTP4	001165	\$TKB	001312	.CONVR	006110		
\$DDW3	001212	\$GDADR	001264	\$MXCNT	004624	\$TKS	001310	.DCLAS	006334		
\$DDW4	001214	\$GDDAT	001270	\$N	=	\$TMP0	001342	.DELAY	006346		
\$DDW5	001216	\$GET42	004306	\$NULL	001320	\$TMP1	001344	.DEVIC	006314		
\$DDW6	001220	\$HD	=	\$NWTST	=	\$TMP2	001346	.ERRTA	015216		
\$DDW7	001222	\$HIBTS	001446	\$OVER	004562	\$TMP3	001350	.INSTE	005576		
\$DDW8	001224	\$ICNT	001250	\$PASS	001126	\$TMP4	001352	.INSTR	005472		
\$DDW9	001226	\$ILLUP	007536	\$PASTH	001454	\$TN	=	000006	.INST1	005512	
\$DEVCT	001130	\$INTAG	001301	\$PWRAD	007532	\$TPB	001316	.LPRSE	006416		
\$DEVH	001176	\$ITEFB	001260	\$PWRDN	007372	\$TPFLG	001323	.MSG	005514		
\$DOAGN	004326	\$LF	001360	\$PWRMG	007526	\$TPS	001314	.PARAM	005616		
\$E	=	\$LFLG	005467	\$PWRUP	007444	\$TSTH	001452	.PARFD	011234		
\$ENDAD	004316	\$LPADR	001252	\$QUES	001356	\$TSTNH	001246	.PAWCH	010350		
\$ENDCT	004302	\$LPERR	001254	\$REGAD	001324	\$TYPE	004670	.RES05	006056		
\$ENV	001140	\$SHADR1	001152	\$REG0	001326	\$TYPEC	005102	.SAV05	006016		
\$ENVH	001141	\$SHADR2	001156	\$REG1	001330	\$TYPEX	005222	.SCOPE	004362		
\$EOP	004146	\$SHADR3	001162	\$REG2	001332	\$UNIT	001132	.SCOPI	004626		
\$EOPCT	004274	\$SHADR4	001166	\$REG3	001334	\$UNITH	001456	.SETFL	010230		
\$ERFLG	001247	\$SHAIL	001120	\$REG4	001336	\$USWR	001144	.SHIFT	006400		
\$ERHAX	001261	\$SHAHS1	001150	\$REG5	001340	\$VECT1	001170	.START	002116		
\$ERROR	006500	\$SHAHS2	001154	\$RTNAD	004330	\$VECT2	001172	.TRPSR	006272		
\$ERRPC	001262	\$SHAHS3	001160	\$SAVR6	007542	\$XOFF	=	000023	.TRPTA	001742	
\$ERRTB	001362	\$SHAHS4	001164	\$SCCPE	004362	\$XON	=	000021	.TYPE	004652	
\$ERTTL	001256	\$FBADR	001450	\$SETUP	=	\$XTSTR	004422	\$.X	=	001446	

. ABS. 017146 000 OVR RW REL GBL I

ERRORS DETECTED: 0

CVDZBB,CVDZBB=CVDZBB  
RUN-TIME: 21 13 .7 SECONDS  
RUN-TIME RATIO: 195/35=5.5  
CORE USED: 37K (73 PAGES)