

VTV30-K

VTV30-K LOGIC TEST  
CVVTCA0

AH-S052A-MC  
FICHE 1 OF 1

MAY 1981  
COPYRIGHT © 1981  
MADE IN USA



The main body of the document contains a grid of approximately 15 columns and 15 rows of small, illegible text or diagrams. These elements are too faint to transcribe accurately but appear to be organized in a structured, tabular format, possibly representing test results or component specifications.

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41

000000

.REPT 0

IDENTIFICATION

PRODUCT CODE: AC-S051A-MC  
PRODUCT NAME: CVTCA0 VTV30-K LOGIC TEST  
PRODUCT DATE: 23-MAR-80  
MAINTAINER: COMPUTER SPECIAL SYSTEMS,  
DIGITAL EQUIPMENT CO. LTD.,  
READING, BERKSHIRE. U.K.

COPYRIGHT (C) 1981 BY  
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS

THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE  
USED AND COPIED ONLY IN ACCORDANCE WITH THE TERMS OF  
SUCH LICENSE AND WITH THE INCLUSION OF THE ABOVE  
COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER COPIES  
THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE  
TO ANY OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE  
SOFTWARE IS HEREBY TRANSFERRED.

THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE  
WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A  
COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR  
RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT  
SUPPLIED BY DIGITAL.

43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93

1. ABSTRACT

THIS DIAGNOSTIC HAS BEEN DESIGNED TO EXERCISE UP TO 20 (DECIMAL) VTV30-K, LSI BUS, VIDEO DISPLAY CONTROLLERS IN SEQUENCE. THE PROGRAM HAS SIX DEFAULT TESTS AND TWO OPTIONAL TESTS. THE PROGRAM ALSO HAS THE CAPABILITY TO RUN WITHOUT OPERATOR INTERVENTION, ONCE THE INITIAL PARAMETERS HAVE BEEN SET UP. IF MORE THAN ONE DEVICE IS BEING TESTED, THE OPERATOR MUST ENSURE THAT ALL THE DEVICES ARE SET UP IN ASCENDING ORDER AND THAT THEY ALL HAVE THE SAME NUMBER OF DISPLAY LINES AND CHARACTER SET TYPE. FOR EXAMPLE, THE DEVICE ADDRESSES RANGE THRU 174000, 174002, 174010, 174012, ETC., AND ALL ARE SET UP FOR 625-LINE OPERATION WITH A RAM BASED CHARACTER STORE. THE OPERATOR HAS THE FACILITY FOR HURRYING UP THE TESTS BY TYPING SPACE ON THE CONSOLE TERMINAL. THIS WILL ABORT AND PROGRAM CONTROLLED WAITS, AND PROCEED TO THE NEXT SECTION OF THE TEST. THIS FEATURE SHOULD NOT BE USED IN TEST 1.

2. REQUIREMENTS

2.1 EQUIPMENT

- A. PDP-11 COMPUTER WITH A Q-BUS ADAPTOR, OR LSI-11 COMPUTER
- B. CONSOLE TELETYPE
- C. UP TO 20 VTV30-K COLOUR DISPLAY CONTROLLERS
- D. DIAGNOSTIC TAPE AND LISTINGS

2.2 STORAGE

THIS PROGRAM REQUIRES A MINIMUM OF 8K WORDS OF MEMORY.

3. LOADING PROCEDURE

THE PROGRAM IS LOADED USING THE ABSOLUTE BINARY LOADER, OR USING THE NORMAL XXDP LOAD PROCEDURE AND IS IN ABSOLUTE BINARY FORMAT.

4. STARTING PROCEDURE

THE PROGRAM HAS A LOAD AND GO FEATURE WHICH AUTOMATICALLY STARTS THE PROGRAM AT ADDRESS 1000 UPON A SUCCESSFUL LOAD.

95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143

5. RESTARTING PROCEDURE

THE PROGRAM HAS A RESTART ADDRESS AT 1200 WHICH ALLOWS THE PROGRAM TO BE RESTARTED WITHOUT HAVING TO RE-ENTER THE BUS ADDRESSES. IF IT IS NECESSARY TO RESTART THE PROGRAM WITH NEW BUS ADDRESSES, THE ADDRESS 1000 SHOULD BE USED AS THE RESTART ADDRESS.

6. PROGRAM AND OPERATOR ACTION

THE FOLLOWING OPERATOR REQUESTS ARE MADE BY THE PROGRAM PRIOR TO THE COMMENCEMENT OF THE ACTUAL TESTS:-

M736?/M737?..

(THE OPERATOR MUST TYPE THE LAST DIGIT OF THE MODULE NUMBER-- 8,9,0,1 OR 2 -- TO SELECT THE DEVICE UNDER TEST

(IF A PROGRAMMABLE CHARACTER SET VERSION IS SELECTED, THE OPERATOR IS THEN ASKED....)

T.V.-ENCODED?(Y OR N)..

(..WHICH IS USED TO SELECT THE CHARACTER SETS LOADED INTO THE CHARACTER STORE.)

DECIMAL NUMBER OF UNITS (1)..

FIRST BUS ADDRESS =

(IF THE PROGRAM FOUND THAT ONE OF THE DEVICE REGISTERS SELECTED WAS NOT ON THE BUS, I.E. ITS ADDRESS WAS NON EXISTANT, THEN AN ERROR MESSAGE WILL BE PRINTED. FOR A CSR ADDRESS BEING NON EXISTANT, ERROR 77 IS REPORTED. FOR A DBUF ADDRESS, THE ERROR REPORTED IS ERROR 76. THE PARAMETER DATA CONTAINS THE ADDRESS FOUND TO BE NON EXISTANT. BY SELECTING TRAP+10, THE OPERATOR CAN LOOP ON THIS ADDRESS. IF THE FAULT IS NOT CORRECTED, THEN WHEN THE TESTS ARE RUN ON THAT DEVICE, THE PROGRAM WILL CRASH.)

THE OPERATOR SHOULD REPLY TO REQUESTS ABOVE, BY INPUTTING THE CORRECT DATA.

SELECT DESIRED SWITCH REGISTER SETTINGS, TYPE CNTRL-C TO CONTINUE OR SWR = 0.

145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196

IN REPLY TO THE REQUEST ABOVE THE OPERATOR SHOULD SELECT DESIRED SWITCH REGISTER OPTIONS AS SET OUT UNDER SWITCH OPTIONS BELOW.

7. SWITCH REGISTER OPTIONS

THIS PROGRAM IS DESIGNED TO RUN EQUALLY EASILY ON PDP-11 PROCESSORS WITH, OR WITHOUT, A HARDWARE SWITCH REGISTER. ON STARTING, A TEST IS DONE TO SEE IF A HARDWARE SWITCH REGISTER IS PRESENT. IF IT IS PRESENT, IT MAY BE USED IN THE NORMAL MANNER.

THE SWITCH REGISTER SETTINGS ARE:-

SWR15=1	INHIBIT ERROR HALT
SWR14=1	INHIBIT ERROR PRINT-OUT
SWR13=1	FAST ITERATION
SWR12=1	:
SWR11=1	:SCOPE LOOPS, SEE BELOW
SWR10=1	:FOR A DESCRIPTION, AND
SWR09=1	:APPENDIX A FOR EXAMPLES
SWR08=1	:OF THEIR USE
SWR07=1	NON INTERVENTION
SWR06=1	PRE-SELECTED TEST INDICATOR
SWR05=1	:
SWR04=1	:
SWR03=1	:TEST NOS.
SWR02=1	:
SWR01=1	:
SWR00=1	:

THE SETTING OF BITS 7, 8, 9, 10, 11, AND 12 IN THE SWITCH REGISTER ARE USED TO SELECT THE TRAP OPTIONS PRESENT IN THE PROGRAM. THE SELECTION IS MADE IN THE FOLLOWING MANNER:

BIT(S) SET	TRAP FUNCTION SELECTED
7	TRAP+2
8	TRAP+4
9	TRAP+10
10	TRAP+20
9 AND 10	TRAP+30
11	TRAP+40
9 AND 11	TRAP+50
10 AND 11	TRAP+60
9, 10 AND 11	TRAP+70
12	USES THE SWITCH REGISTER SETTING THAT WAS IN FORCE WHEN THE LAST TRAP INSTRUCTION WAS EXECUTED.

198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249

IF A HARDWARE SWITCH REGISTER IS NOT PRESENT, THE PROGRAM ASSIGNS A LOCATION IN MEMORY AS A SOFTWARE SWITCH REGISTER, THE OPTIONS REMAINING AS ABOVE. THIS MEANS THAT ALL MODIFICATIONS TO THE SWITCH REGISTER MAY BE MADE USING THE CONSOLE TELETYPE VIA A MONITOR ROUTINE. THIS MONITOR IS CALLED BY TYPING CTRL-G AT THE CONSOLE TELETYPE AND RESPONDS BY PRINTING THE CURRENT CONTENTS OF THE SOFTWARE SWITCH REGISTER, FOLLOWED BY A PROMPT CHARACTER (>). THE OPERATOR SHOULD THEN TYPE IN THE NEW SWITCH REGISTER SETTINGS AS AN OCTAL NUMBER, FOLLOWED BY A CARRIAGE RETURN. TYPING CARRIAGE RETURN ALONE WILL CAUSE THE SETTING TO REMAIN UNCHANGED. THE SWITCH REGISTER IS THEN LOADED WITH THE NEW VALUE AND PROGRAM EXECUTION CONTINUES. IF A SETTING IS ENTERED WHICH INCLUDES THE PRE-SELECTED TEST BIT (SWR06), THE TEST INDICATED BY SWR 00-05 WILL BE SELECTED IMMEDIATELY. THIS DOES NOT APPLY WHEN DEFAULTING ON AN EXISTING SETTING.

THE SWR MONITOR IS ALSO CALLED AUTOMATICALLY IF AN ERROR IS DETECTED AND SWR BIT 15 IS NOT SET. OCTAL EQUIVALENTS FOR THE SWITCHES ARE AS FOLLOWS:

SWR15 =	100000
SWR14 =	40000
SWR13 =	20000
SWR12 =	10000
SWR11 =	4000
SWR10 =	2000
SWR09 =	1000
SWR08 =	400
SWR07 =	200
SWR06 =	100
SWR05 =	40
SWR04 =	20
SWR03 =	10
SWR02 =	4
SWR01 =	2
SWR00 =	1

TO SET A COMBINATION OF THESE SWITCHES, SIMPLY ADD TOGETHER THE CORRESPONDING OCTAL NUMBERS AND ENTER THE TOTAL IN RESPONSE TO 'SWR= X>'. (LEADING ZEROS MAY BE IGNORED).

FOR WORST CASE TESTING, ALL SWITCHES SHOULD BE ZERO. IT IS POSSIBLE, WITH THESE SWITCH REGISTER OPTIONS, TO EXECUTE ONLY A PRE-SELECTED TEST WITH THE FACILITY TO LOOP ON THAT TEST OR TO START THE PROGRAM PASS OR FINISH THE PROGRAM PASS AT ANY PARTICULAR TEST.

251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273  
274  
275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300

## 8. ERROR REPORTS

THE FORMAT OF THE ERROR REPORTS IS AS FOLLOWS:-

E# AABB	AT PC:CCCC
GOOD: DDDD	BAD: EEEE
STATUS: FFFF	ADDRESS: GGGG
DATA: KKKK	CALLED FROM: HHHH
	ERROR COUNT = JJJJ

WHERE:

AA IS THE TEST NUMBER  
BB IS THE ERROR NUMBER  
CCCC IS THE ADDRESS WHERE THE ERROR REPORT OCCURS.  
DDDD IS THE DATA EXPECTED  
EEEE IS THE DATA RECEIVED  
FFFF GGGG AND KKKK ARE CONTENTS OF REGISTERS.  
HHHH IS THE ADDRESS IN THE MAINLINE CODE WHERE THE  
SUBROUTINE, WHERE THE ERROR REPORT IS  
GENERATED, IS CALLED FROM.  
JJJJ IS THE NUMBER OF ERRORS REPORTED TO DATE IN  
THIS SECTION.

## 9. ONLINE MODIFICATIONS

AVAILABLE TO THE USER IS A ROUTINE TO MODIFY PROGRAM  
LOCATIONS. IT IS ENTERED BY TYPING CNTRL-O DURING THE  
RUNNING OF THE TESTS. ON ENTRY, A PROMPT 'S' IS MADE  
FOR THE ADDRESS TO BE MODIFIED. IF NO ADDRESS IS GIVEN,  
IT IS ASSUMED THAT NO MODIFICATIONS ARE REQUIRED AND THE  
ROUTINE WILL COMPLETE. IF AN ADDRESS IS SPECIFIED, IT  
WILL BE CHECKED TO SEE IF IT IS EVEN AND IN EXISTANCE.  
ONCE IT HAS BEEN CHECKED, ITS CONTENTS ARE DISPLAYED AND  
A PROMPT '/' IS MADE FOR THE NEW CONTENTS. IF NO NEW  
VALUE IS GIVEN, THE EXISTING VALUE WILL BE LOADED.  
HAVING DEALT WITH THAT ADDRESS, THE ROUTINE WILL THEN  
EXAMINE THE TERMINATING CHARACTER TO DETERMINE THE NEXT  
OPERATION TO PERFORM.

TYPING <ESC> WILL COMPLETE THE MODIFICATIONS BEING  
DONE.  
<CR> WILL CAUSE A PROMPT FOR THE NEXT ADDRESS  
TO BE MODIFIED.  
<LF> WILL TAKE THE NEXT ADDRESS TO BE MODIFIED  
AS THE CURRENT ADDRESS+2.

302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333  
334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347

10. MISCELLANEOUS

IF THE OPERATOR WISHES TO SOAK TEST WITHOUT MANUAL INTERVENTION, THEN HE MUST SET SWR BITS 15, 14 AND 7. THIS WILL RUN THE TESTS WITHOUT DISPLAYING AND TEST OR ERROR MESSAGES. IF, AT THE END OF THE RUN, A SUMMARY ERROR REPORT IS REQUIRED, THEN TEST 10 SHOULD BE SELECTED AND RUN.

TO RUN THE TESTS WITH ERROR REPORTING, BUT WITH NO ERROR HALT, ONLY SWR BITS 15 AND 7 NEED TO BE SET.

ONCE ALL THE DEVICES HAVE BEEN TESTED, THE PROGRAM WILL ATTEMPT TO DETERMINE IF IT WAS CALLED FROM THE XXDP MONITOR. IF LOCATIONS 42/43 ARE NOT ZERO, THE PROGRAM WILL ISSUE A CALL TO THAT ADDRESS. IF THE OPERATOR DOES NOT WISH THIS RETURN TO OCCUR, THEN HE MUST EITHER RUN WITH SWR BIT 7 SET OR ENSURE THAT LOCATIONS 42/43 ARE CLEAR.

IF THE FIELD VIDEO SIGNAL HAS TOO MUCH NOISE ON IT FOR A STATISIZED READING, ONE OF TWO ERROR REPORTS MAY BE GENERATED. ERROR 70: AN INITIAL SAMPLY COULD NOT BE TAKEN. ERROR 67: THE SIGNAL DOES NOT CHANGE STATE.

11. PROGRAM DESCRIPTION

TEST 0

THIS TEST CHECKS THAT ALL THE READ/WRITE BITS IN THE CSR CAN BE SET AND CLEARED, AND THAT THE DATA BUFFER IS UNAFFECTED. THE PROGRAM LOADS A SLIDING ONES PATTERN INTO THE CSR, THEN READS IT BACK TO CHECK THAT THE PATTERN WAS LOADED. THE DBUFF IS ALSO CHECKED FOR ZERO. HAVING CHECKED A SLIDING ONES PATTERN, THE PROCESS IS THEN REPEATED FOR SLIDING ZEROS.

ERROR 1 BIT NOT SET IN CSR. GOOD = EXPECTED, BAD = RECEIVED, ADDRESS = CSR ADDRESS, DATA = PATTERN NUMBER. TRAP+10 TO LOOP.

ERROR 2 DBUFF AFFECTED BY SETTING CSR. STATUS = RECEIVED DATA, ADDRESS = DBUFF ADDRESS, DATA = PATTERN NUMBER. TRAP+20 TO LOOP.



349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403

ERROR 3 BIT NOT CLEAR IN CSR. GOOD = EXPECTED, BAD = RECEIVED, ADDRESS = CSR ADDRESS, DATA = PATTERN NUMBER. TRAP+30 TO LOOP.

ERROR 4 DBUFF AFFECTED BY CLEARING CSR. STATUS = RECEIVED DATA, ADDRESS = DBUFF ADDRESS, DATA = PATTERN NUMBER. TRAP+40 TO LOOP.

TEST 1

THIS TEST CHECKS THAT THE FIELD VIDEO SIGNAL TOGGLES, AND THAT THE PERIOD IS ROUGHLY 1/50TH OR 1/60TH OF A SECOND, DEPENDING UPON WHAT THE OPERATOR HAS SELECTED. THE PROGRAM FIRST CHECKS THAT THE FIELD VIDEO SIGNAL CAN GO THROUGH A HI-LOW-HI-LOW, AND A LOW-HI-LOW-HI TRANSITION. AS MENTIONED PREVIOUSLY, IF THE SIGNAL IS TOO NOISY TO GET A READING, ERROR 67 MAY BE GENERATED. IF THE SIGNAL DOES NOT WORK, ERROR 70 IS FLAGGED. IF THE TEST DOES NOT COMPLETE IN A REASONABLE AMOUNT OF TIME, IT CAN BE ASSUMED THAT THE SIGNAL HAS NOT TOGGLED. TO GET OUT OF THIS, THE OPERATOR MUST TYPE SPACE TO TERMINATE THIS SECTION.

HAVING VERIFIED THAT THE SIGNAL CAN TOGGLE, THE PROGRAM THEN USES THIS INFORMATION TO CREATE A WAIT LOOP OF ONE SECOND. THIS WAIT LOOP IS THEN USED TO TIME FIVE BY ONE SECOND INTERVALS. AT THE END OF EACH INTERVAL, THE CONSOLE TELETYPE BELL IS RUNG. THIS INFORMATION CAN BE USED TO JUDGE WHETHER THE FRAME TIME IS REASONABLE. SINCE THERE ARE MANY INSTRUCTIONS EXECUTED BETWEEN SAMPLING POINTS, THIS TIMING INFORMATION IS NOT ACCURATE AND MUST THEREFORE BE JUDGED ACCORDINGLY. SETTING TRAP+20 WILL LOOP ON RINGING THE BELL.

ERROR 1 NOISY SIGNAL OR ABORTED TEST. TRAP+10 TO LOOP.

TEST 2

THIS TEST CHECKS THAT ALL THE COLOURS CAN BE DISPLAYED. BY SELECTING CHARACTER CODE 0, AND THE SAME FOREGROUND AND BACKGROUND COLOURS, A FULL SCREEN OF THAT COLOUR IS DISPLAYED. THE SEQUENCE OF OPERATIONS IS AS FOLLOWS:-

F/B WHITE	NO VIDEO
F/B BLACK	VIDEO ON
F/B RED	VIDEO ON
F/B GREEN	VIDEO ON
F/B YELLOW	VIDEO ON
F/B BLUE	VIDEO ON
F/B MAGENTA	VIDEO ON
F/B CYAN	VIDEO ON
F/B WHITE	VIDEO ON

405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444

SETTING TRAP+10 WILL LOOP ON THE CURRENT COLOUR SELECTION.

TEST 3

THIS TEST CHECKS OUT THE X AND Y ADDRESSING OF THE DEVICE. THE SCREEN IS SET TO BLUE AND TWO DIAGONALS ARE DISPLAYED. ONE IS MADE OF MAGENTA BLOCKS, STARTING AT THE TOP RIGHT CORNER, AND THE OTHER IS IN WHITE, STARTING AT THE BOTTOM LEFT.

TEST 4

THIS TEST CHECKS OUT THE FOREGROUND/BACKGROUND COLOUR SELECTION WITH BLINK AND FLASH. CHARACTER CODE ZERO IS SELECTED, SINCE IT IS HALF FOREGROUND AND HALF BACKGROUND, DIVIDED VERTICALLY. THE WHOLE DISPLAY IS LOADED WITH THE COLOUR, BLINK AND FLASH INFORMATION IN THE FOLLOWING ORDER:-

BLACK ON WHITE  
BLINK WHITE ON BLACK  
FLASH WHITE ON BLACK  
FLASH AND BLINK

NOTE: THE FLASH WILL NORMALLY APPEAR TO 'HOP' SIDEWAYS.

SETTING TRAP+10 WILL LOOP ON THE CURRENT COLOUR/BLINK/-FLASH SELECTION.

TEST 5

THIS TEST CHECKS OUT THE CHARACTER STORE ADDRESSING OF THE DEVICE. THE DISPLAY IS SET TO BLACK, THEN THE ENTIRE CHARACTER SET IS DISPLAYED WITH RED ON BLUE.

446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500  
501

### ROM BASED CHARACTER SET

FOR THE ROM BASED CHARACTER SET, THE CHARACTER SET WILL DISPLAY AS RED ON BLUE IN AN AREA FROM Y = 18 THRU 21 TO X = 7 THRU 40. THE CHARACTER SET IS DISPLAYED AS CHARACTER STORE ADDRESSES INCREMENTING HORIZONTALLY. SETTING TRAP+10 WILL LOOP ON DISPLAYING THE CHARACTER SET.

### RAM BASED CHARACTER SET

FOR THE RAM BASED CHARACTER SET, THE DISPLAY AREA STARTS AT X = 7, Y = 18. THE CHARACTER CODES ARE DISPLAYED VERTICALLY IN COLUMNS FIVE CHARACTERS LONG, I.E. COLUMN 1 RUNS FROM CODE 0 TO CODE 4, COLUMN 2 FROM 5 TO 9, ETC.

THE CHARACTER SET IS FIRST SET TO ZERO, THEN A VERTICAL LINE IS MOVED THRU THE ENTIRE CHARACTER SET, FIVE CHARACTERS AT A TIME. THIS WILL APPEAR AS A VERTICAL LINE MOVING ACROSS THE DISPLAY AREA.

SETTING TRAP+20 WILL LOOP ON THE CURRENT CHARACTER CODE. IF TRAP+70 IS SET, THE OPERATOR CAN SELECT WHICH CHARACTER CODE HE WANTS TO TEST. HAVING SELECTED THE CODE, THE PROGRAM THEN ALLOWS THE OPERATOR TO CHANGE SWITCH REGISTER SETTINGS, SUCH AS SETTING TRAP+20. ONCE TRAP+70 HAS BEEN SET, IT IS THEN CLEARED, THE PROGRAM WILL CONTINUE TESTING FROM THE CHARACTER CODE TO OPERATOR SELECTED.

### TEST 6

THIS TEST CHECKS THE DATA INTEGRITY OF THE CHARACTER STORE ADDRESSES, HELD IN THE PICTURE STORE. THE CHARACTER STORE ADDRESS IS HELD IN TWO BY 4-BIT RAMS PER PICTURE LOCATION, WITH THE HIGH BIT OF THE TOP RAM UNUSED. A FIVE CHARACTER STORE ADDRESS PATTERN IS USED, SUCH THAT THE SAME BIT IN EACH RAM IS SET. THE ADDRESSES USED ARE 21, 42, 104, 10 AND 40. ALTHOUGH CHARACTER ADDRESS 40 DOES NOT SET BITS IN EACH RAM, IT IS USED TO MAKE THE SEQUENCE ODD SO THAT IF THERE IS A POWER OF TWO FAULT IN THE MEMORY, IT WILL GET PICKED UP. EACH NEW ROW STARTS WITH THE NEXT CHARACTER IN THE SEQUENCE, SO THAT THE CODES APPEAR TO BE DRAWN IN DIAGONAL LINES RUNNING TOP RIGHT TO BOTTOM LEFT. EACH TIME THE COMPLETE SCREEN IS UPDATED, THE CHARACTER CODES ARE MOVED ONE PLACE LEFT, GIVING THE EFFECT TO THE DIAGONAL LINES MOVING RIGHT TO LEFT. THE COLOURS USED ARE WHITE ON BLACK. SETTING TRAP+4 WILL LOOP ON THE TEST.

THE PATTERN IS.

DIAMOND  
DOUBLE QUOTES  
CAPITAL 'D'  
HEAVY PLUS (+) SIGN  
(SPACE)

503  
504  
505  
506  
507  
508  
509  
510  
511  
512  
513  
514  
515  
516  
517  
518  
519  
520  
521  
522  
523  
524  
525  
526  
527  
528  
529  
530  
531  
532  
533  
534  
535  
536  
537  
538  
539  
540  
541  
542  
543  
544  
545  
546

TEST 7

THIS IS AN EXERCISER TEST THAT DISPLAYS ALL CHARACTERS IN EVERY PICTURE LOCATION. CHARACTER CODES ARE DISPLAYED IN DIAGONAL ROWS, TOP RIGHT TO BOTTOM LEFT. THE DIAGONAL LINE WILL BE MOVED FROM BOTTOM RIGHT TO TOP LEFT. THE COLOURS ARE DISPLAYED IN VERTICAL BANDS, THE FOREGROUND COLOURS BEING RED, GREEN, THEN BLUE, AND THE BACKGROUND COLOURS BEING RED, GREEN, YELLOW, BLUE, MAGENTA, CYAN AND WHITE.

AS THE TEST PROGRESSES, IT WILL APPEAR THAT THE CHARACTER CODES ARE MOVING UP VERTICAL LINES, BUT OFFSET BY ONE PICTURE ROW, THUS GIVING THE EFFECT OF A MOVING DIAGONAL LINE.

TEST 10

THIS OPTIONALLY SELECTABLE TEST IS USED TO PRINT OUT THE ACCUMULATED ERRORS TO DATE. IT CAN BE USED AFTER RUNNING SOAK TESTING TO GIVE AN INDICATION OF THE NUMBER OF ERRORS THAT HAVE OCCURED.

THIS TEST PRINTS A MESSAGE 'ERROR COUNT = ', FOLLOWED BY THE CURRENT ERROR COUNT. THE PROGRAM THEN CLEARS THE ERROR COUNT.

TEST 11

THIS OPTIONALLY SELECTED TEST IS USED TO CHECK THE RESPONSE OF THE VIDEO ADAPTERS. THERE ARE 7 BLOCKS OF 4 ROWS EACH. EACH BLOCK IS A DIFFERENT COLOUR, IN THE SEQUENCE..

RED  
GREEN  
YELLOW  
BLUE  
MAGENTA  
CYAN  
WHITE

....EACH ROW HAS .5,1,2 AND 4 MHZ VERTICAL BARS TO TEST THE RESPONSE.

548  
549  
550  
551  
552  
553  
554  
555  
556  
557  
558  
559  
560  
561  
562  
563  
564  
565  
566  
567  
568  
569  
570  
571  
572  
573  
574  
575  
576  
577  
578  
579  
580  
581  
582  
583  
584  
585  
586  
587  
588  
589  
590  
591  
592  
593  
594  
595  
596  
597  
598  
599

## APPENDIX A

### PDP-11 DIAGNOSTIC LOOPING FACILITIES VIA SWITCH REGISTER OPTIONS

N.B.

THE INTENTION OF THIS APPENDIX IS TO EXPLAIN, IN GENERAL, THE SCOPE FACILITIES WITHIN PROGRAM CODING. THE USER MUST FIRST EXAMINE THE CODING ABOUT THE AREA HE WISHES TO USE SCOPING FACILITIES, TO ASCERTAIN THAT THE PARTICULAR FACILITY HE REQUIRES IS, IN FACT, AVAILABLE.

PROGRAM LOOPING CONTROL CAN BE SELECTED BY USING SWR 12 - 07. THE PROGRAM HANDLES THIS BY USE OF THE TRAPSV ROUTINE, WHICH IS ENTERED USING THE TRAP INSTRUCTION. BASICALLY, THE ROUTINE CHECKS EQUALITY BETWEEN BITS 05 - 00 OF THE TRAP INSTRUCTION AND SWR 12 - 07.

THERE ARE THREE DISTINCT FUNCTIONS CONTROLLED BY THE TRAP ROUTINE:-

- A) RUN - (TRAP + 2 INSTRUCTION AND SWR 07 SET)  
USUALLY USED TO INHIBIT TEST NUMBER PRINTOUT; USEFUL IN THE CASE OF NON-INTERVENTION TESTS. WHEN SWR 07 IS SET, ALL TEST NUMBER MESSAGES ARE SUPPRESSED.  
NOTE: IT DOES NOT SUPPRESS ERROR PRINTOUTS.
- B) LOOP ON A SUB-TEST - (TRAP + 4 INSTRUCTION AND SWR 08 SET)  
THIS IS GENERALLY USED TO ALLOW THE OPERATOR, BY SETTING SWR 08, TO CONTINUOUSLY LOOP ON ONE LOGICAL TEST OR GROUP OF TESTS.
- C) SCOPE ON A SUB-TEST - (TRAP + 10 - 70 INSTRUCTIONS AND SWR 09 - 11)  
THIS ALLOWS THE OPERATOR TO SELECT SEVEN LEVELS OF LOOPING FACILITY WITHIN A SELECTION OR TEST.

IT IS USED TYPICALLY WITHIN A TEST WHERE ONE SUB-TEST SETS A FLAG AND THE NEXT ONE CLEARS IT. BY USING SCOPE LEVEL 1 (SWR 09) - TRAP + 10), HE COULD LOOP ON THE FIRST SUB-TEST, SCOPE LEVEL 2 (SWR 10) - TRAP + 20), HE COULD LOOP ON THE SECOND SUB-TEST OR SCOPE LEVEL 3 (SWR 10 & 09 - TRAP + 30) TO LOOP CONSTANTLY THROUGH BOTH SUB-TESTS SEQUENTIALLY. THE SCOPE RETURN ADDRESS ALWAYS APPEARS AS THE ARGUMENT OR NEXT WORD AFTER THE TRAP INSTRUCTION.

601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619

TO ALLOW THE SCOPE LEVEL TO BE CHANGED WITHOUT STOPPING THE PROGRAM, E.G. TO CHANGE FROM LEVEL 1 TO 2, WHICH WOULD ALMOST CERTAINLY CAUSE LEVEL 3 OR 0 TO BE SEEN MOMENTARILY), A 'PRESERVE SCOPE' FACILITY IS PROVIDED WITH SWR12. WHEN THIS IS SELECTED, THE PROGRAM NO LONGER INSPECTS SWR 11 - 09 BUT USES THE SETTING MEMORISED FROM BEFORE SWR 12 WAS SELECTED. THE SCOPE LEVEL MAY NOW BE CHANGED WITH NO EFFECT UNTIL SWR 12 IS SET TO 0, WHEN THE NEW SCOPE SETTING APPLIES.

N.B. SETTING SWR 12 SHOULD ONLY BE USED TO PRESERVE AS EXISTING SCOPE LEVEL, AS PREVIOUSLY SET ON THE SWITCH REGISTER.

WHICH SCOPE LEVEL TO SELECT MAY BE DETERMINED THE LISTING; LEVELS 1 THROUGH 7 ARE CALLED BY TRAP + 10 (SWR 09) THROUGH TRAP + 70 (SWR 09, 10 AND 11).

621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631  
632  
633  
634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648  
649  
650  
651  
652  
653  
654  
655  
656  
657  
658  
659  
660  
661  
662  
663  
664  
665  
666  
667  
668  
669  
670  
671

EXAMPLE OF SCOPE LOOP FACILITIES WITHIN DIAGNOSTIC

```

:
TEST10: MOV      #40,COUNT      ;ITERATION COUNT.
T101:   BIS      #1,STATUS     ;SET GO BIT.
        BIT      #1,STATUS     ;IS GO BIT SET?
        BNE     T10SCP        ;YES, BRANCH.
        JSR     PC,ERROR      ;ERROR!!! GO NOT SET.
        10          ;ERROR NUMBER.
T10SCP: TRAP+10                ;SCOPE TEST 10 IF LEVEL 1 SELECTED.
        T101                ;RETURN LABEL FOR SCOPE.
TEST11: BIC      #1,STATUS     ;CLEAR GO BIT
        BIT      #1,STATUS     ;GO BIT CLEAR ?
        BEQ     T11SCP        ;GO BIT CLEAR BRANCH.
        JSR     PC,ERROR      ;NO. GO BIT FAILED TO CLEAR.
        11          ;ERROR!!! NO. 11.
T11SCP: TRAP+30                ;SCOPE TEST 11 IF LEVEL 3 SELECTED.
        TEST11               ;RETURN LABEL FOR SCOPE.
        TRAP+20              ;SCOPE TESTS 10 & 11.
        T101                ;RTURN LABEL.
TEST12: BIS      #100,STATUS   ;NO SCOPE SELECTED. CARRY ON.
        BIT      #100,STATUS   ;IS DONE BIT SET ?
        (ETC.)
        :
        :
T12SCR: TRAP+10                ;SCOPE INT. EN. SET, LEVEL 1.
        TEST 12              ;RETURN LABEL.
TEST13: BIC      #100,STATUS   ;CLEAR INT ENABLE BIT.
        BIT      #100,STATUS   ;IS BIT CLEAR?
        (ETC.)
        :
        :
T13SCP: TRAP+30                ;SCOPE INT CLEAR LEVEL 3.
        TEST13               ;RETURN LABEL.
        TRAP+20              ;SCOPE INT. SET AND CLEAR.
        TEST12               ;LEVEL 2.
        TRAP+4               ;SCOPE LOOP ON THIS SET OF TESTS.
        T101                ;RETURN LABEL.
        DEC      COUNT        ;DO 40 TIMES ANYWAY
        BGT     T101
TEST14: (ETC.)
        :
        :
:

```

673

.ENDR



675		.TITLE	VTV30K DIAGNOSTIC
676		.SBTTL	GENERAL DEFINITIONS
677			
678			
679	000000	R0=	X00
680	000001	R1=	X01
681	000002	R2=	X02
682	000003	R3=	X03
683	000004	R4=	X04
684	000005	R5=	X05
685	000006	SP=	X06
686	000007	PC=	X07
687	177776	PSW=	177776
688	177570	HSWR=	177570
689			
690			
691	100000	G=	100000
692	040000	D=	40000
693	020000	A=	20000
694	010000	S=	10000
695			
696			
697	177564	TPS=	177564
698	177566	TPB=	177566
699	177560	TKS=	177560
700	177562	TKB=	177562
701			
702			
703			
704			
705			
706		.ENABL	ABS
707		.ENABL	AMA
708			
709			
710			
711			
712			

```
714           .SBTTL MACROS
715           :
716           : SET PROCESSOR PRIORITY
717           :
718           :
719           :
720           .MACRO PSWSET $ARG,?LAB
721           MOV     $ARG,-(SP)      : SET UP NEW PSW AS $ARG
722           MOV     #LAB,-(SP)     : SET RETURN ADDRESS
723           RTI      : RTI TO SET PRIORITY
724 LAB:         NOP      : RETURN ADDRESS
725           .ENDM
726           :
727           : READ PROCESSOR PRIORITY
728           :
729           :
730           :
731           .MACRO PSWREA $ARG
732           EMT      : ISSUE EMT TO READ PSW
733           MOV     FSAVPW,$ARG    : READ PSW IN $ARG
734           .ENDM
735           :
736           :
```

```

738 .SBTTL INITIALISATION
739 .ASECT
740 .=0
741 .=42
742 000042 000000 ; XXDP HOOK INITIALIZATION.
743 000200 000200 .=200
744 000200 000137 001000 JMP @#START ; JMP TO START AT 200
745 001000 001000 .=1000
746
747
748 001000 012706 001000 START: MOV #,SP ; INITIALISE STACK POINTER
749 001004 PSWSET #340
750
751 001020 012737 012704 000004 MOV #SWRSET,4 ; TEST FOR HARDWARE SWR
752 001026 012737 000340 000006 MOV #340,6 ; TRAPS TO 4 IF IT
753 001034 012737 177570 007502 MOV #HSWR,SWR ; DOES NOT EXIST
754 001042 005777 006434 TST @SWR
755 001046 005037 007504 CLR SSWR ; INITIALISE SOFTWARE SWR
756 001052 004737 012640 JSR PC,SILLSI ; CHECK WHICH PROCESSOR WE ARE ON
757 001056 004737 012714 JSR PC,VECTOR ; FILL 0-774 WITH HALT TRAPS
758 001062 013737 007306 007436 MOV CSRO,DEVCSR ; ASSUME 1 DEVICE
759 001070 013737 007310 007440 MOV DBUF0,DEVBUF
760 001076 005037 007302 CLR DEVFLG
761 001102 004737 014734 JSR PC,TYPOUT
762 001106 006005 GOMSG ; DIAGNOSTIC
763 001110 004737 012162 JSR PC,SETDEV ; SET UP THE DEVICE
764 001114 004737 015776 JSR PC,SELBUS
765 001120 000137 001200 JMP RSTART ; THEN GOTO THE RESTART ADDRESS
766 001174 001174 .=1174
767 001174 000000 REACT: 0 ; EXTERNAL TEST-EQUIPMENT HOOK
768 001176 000425 XXDPGO: BR XXDP2
769
770 001200 012706 001000 RSTART: MOV #START,SP ; INITIALISE STACK POINTER
771 001204 PSWSET #340
772 001220 005037 007302 CLR DEVFLG
773 001224 013737 007306 007436 MOV CSRO,DEVCSR
774 001232 013737 007310 007440 MOV DBUF0,DEVBUF
775
776 001240 004737 014734 JSR PC,TYPOUT
777 001244 006317 WMSG ; SELECT DESIRED CONSOLE SWITCHES
778 001246 004737 013546 JSR PC,MONIT ; GO TO SWR MONITOR
779
780 001252 012706 001000 ; XXDP2: MOV #START,SP ; RESTORE THE STACK
781 001256 PSWSET #340
782 001272 005037 007444 CLR ERRFLG ; CLEAR ERROR FLAG
783 001276 005037 007574 CLR ERRDIS
784 001302 005037 007442 CLR ERRDI1
785 001306 013737 007306 007436 START1: MOV CSRO,DEVCSR ; START WITH THE FIRST CSR
786 001314 013737 007310 007440 MOV DBUF0,DEVBUF ;
787 001322 005037 007302 CLR DEVFLG
788
789 001326 012706 001000 START2: MOV #START,SP ; INITIALISE STACK POINTER
790 001332 PSWSET #340
791
792 001346 032777 000100 006126 BIT #100,@SWR ; CHECK FOR PRE-SELECTED TEST
793 001354 001002 BNE START3
  
```

```
794  
795 001356 000137 001450          JMP      TEST0      ;TO TEST 0  
796 001362 000137 001366          START3: JMP      TABLE ;TO LOOK-UP TABLE
```

```

798 001366 017700 006110      TABLE: MOV @SWR,RO      ;GET SELECTED TEST NO
799 001372 042700 177700      BIC #177700,RO
800 001376 022700 000011      CMP #11,RO      ;CHECK FOR VALID TEST NO
801 001402 002676      BLT RSTART
802
803 001404 006300      ASL RO
804 001406 000170 001412      JMP @TABLE1(RO) ;JUMP TO PRE-SELECTED TEST
805
806
807
808
809

```

```

810 001412 001450      TABLE1: TEST0
811 001414 002040      TEST1
812 001416 002174      TEST2
813 001420 002354      TEST3
814 001422 002616      TEST4
815 001424 003110      TEST5
816 001426 004234      TEST6
817 001430 004660      TEST7
818 001432 005264      TEST10
819 001434 005362      TEST11

```

: THE FOLLOWING TABLE HAS ONE ENTRY FOR EACH OF THE ABOVE  
 : IF ZERO, IT DISABLES THE STALL FACILITY IN 'WAITS' FOR  
 : THAT TEST.

```

820
821
822
823
824 001436      000      000      001      TABLE2: .BYTE 0,0,1,1,1,0,1,0,0,0
      001441      001      001      000
      001444      001      000      000
      001447      000
825
      .EVEN

```

```

      .SBTTL TEST0
      :
      : THIS TEST CHECKS THE READ/WRITE BITS OF THE CONTROL REGISTER
      : BY WRITING A SLIDING ONES PATTERN TO THE REGISTER, TO CHECK
      : THAT BITS CAN SET. THEN, BY WRITING A SLIDING ZEROES PATTERN
      : CHECK THAT THE BITS CAN CLEAR. AT EACH STAGE OF THE OPERATION
      : THE DATA BUFFER IS CHECKED TO SEE THAT THE SETTING/CLEARING
      : HAD NO EFFECT.
      :
      : TEST0: CLR      TESTNO      ; SET TEST NUMBER
      :          TRAP+2
      :          T0001
      :          JSR      PC,TESTR    ; PRINT TEST NUMBER
      :          JSR      PC,TYP0UT
      :          TS0MSG
      : T0001: MOV      #200,R4      ; SUGGEST AN ITERATION COUNT
      :          JSR      PC,FASTSW   ; IS FAST ITERATION SET
      :          MOV      R4,REPCNT   ; SET ACTUAL ITERATION COUNT
      :          T0002: MOV      #16,DATA ; GET LOOP COUNT
      :          T0003: MOV      #4,R3  ; SELECT SLIDING ONES
      :          JSR      PC,GENER     ; GET THE PATTERN
      :          BIC      #34000,GOOD  ; MASK READ ONLY BITS
      :          T0004: MOV      DEVCSR,ADDRESS ; GET CURRENT ADDRESS
      :          MOV      GOOD,@ADDRESS ; SET DATA IN CSR
      :          MOV      @ADDRESS,BAD  ; READ REPLY
      :          BIC      #34000,BAD   ; MASK UNWANTED
      :          CMP      GOOD,BAD     ; ARE THEY THE SAME
      :          BEQ      T0005        ; YES
      :          JSR      PC,ERROR     ; NO REPORT AN ERROR
      :          T0005: TRAP+10      ; LOOP ON THIS DATA
      :          T0004
      :          MOV      DEVBUF,ADDRESS ; SET DATA BUFFER ADDRESS
      :          MOV      @ADDRESS,STATUS ; THE DATA BUFFER SHOULD BE CLEAR
      :          TST      STATUS       ; IS IT
      :          BEQ      T0007        ; YES
      :
      : ERROR-
      : CHECK 'LEVA LOAD CAR H'
      :          'LEVA READ CAR L'
      :          +3VA ON E46-1 IF BAD=0
      :          RELEVANT BIT ON LEVB B8 (E25,E46)
      :          JSR      PC,ERROR
      :          T0007: TRAP+20      ; LOOP ON COMPLETE
      :          T0004
      :          DEC      DATA       ; ALL PATTERNS DONE
      :          BNE      T0003        ; NO
      :
      : NOW DO SLIDING ZEROES
      :
      : T0009: MOV      #16,DATA     ; GET LOOP COUNT
      :          MOV      #5,R3       ; SELECT SLIDING ZEROES
      :          JSR      PC,GENER     ; GET THE PATTERN
      :          BIC      #34000,GOOD  ; MASK READ ONLY BITS
      :          T0010: MOV      DEVCSR,ADDRESS ; GET CURRENT ADDRESS
      :          MOV      GOOD,@ADDRESS ; SET DATA IN CSR
  
```

```

883 001706 017737 005660 007564      MOV    @ADDRESS,BAD      ; READ REPLY
884 001714 042737 034000 007564      BIC    #34000,BAD      ; MASK UNWANTED
885 001722 023737 007562 007564      CMP    GOOD,BAD       ; ARE THEY THE SAME
886 001730 001403                BEQ    T0011           ; YES
887                                     ; ERROR-
888                                     ; REPLACE LEVB B8 E25 OR E46?
889 001732 004737 016666                JSR    PC,ERROR       ; NO REPORT AN ERROR
890 001736 160003                3+D+G+A
891 001740 104430                T0011: TRAP+30       ; LOOP ON THIS DATA
892 001742 001672                T0010
893 001744 013737 007440 007572      MOV    DEVBUF,ADDRESS ; SET DBUF ADDRESS
894 001752 017737 005614 007570      MOV    @ADDRESS,STATUS ; THE DATA BUFFER SHOULD BE CLEAR
895 001760 005737 007570                TST    STATUS         ; IS IT
896 001764 001403                BEQ    T0013           ; YES
897                                     ; ERROR-
898                                     ; REPLACE LEVB B8 E25 OR E46?
899 001766 004737 016666                JSR    PC,ERROR
900 001772 070004                4+A+S+D
901 001774 104440                T0013: TRAP+40
902 001776 001672                T0010                 ; LOOP ON COMPLETE
903 002000 005337 007566                DEC    DATA          ; ALL PATTERNS DONE
904 002004 001323                BNE    T0009          ; NO
905                                     ;
906                                     ; END OF TEST ?
907                                     ;
908                                     TRAP+4
909 002006 104404                T0003                 ; LOOP ON TEST ?
910 002010 001514                DEC    REPCNT         ; ITERATE TILL DONE
911 002012 005337 007506                BEQ    T0002
912 002016 001633                CLR    @DEVCSR        ; TIDY UP AFTER TEST.
913 002020 005077 005412                BIT    #100,@SWR      ; PRESELECT TEST ?
914 002024 032777 000100 005450      BEQ    TEST1          ; NO
915 002032 001402                BEQ    TEST1          ; NO
915 002034 000137 001326                JMP    START2         ; YES GO DO IT
  
```

L

```

917          .SBTTL TEST1
918
919          : THIS TEST CHECKS THE FIELD VIDEO TIMING BY ATTEMPTING
920          : TO RING THE BELL EVERY SECOND FOR 5 SECONDS
921          : IF THE BELL DOES NOT RING, TYPE CNTRL-X TO ABORT THE TEST
922
923
924 002040 012737 000001 007454 TEST1: MOV #1,TESTNO ; SET TEST NUMBER
925 002046 104402 TRAP+2
926 002050 002064 T0101
927 002052 004737 011624 JSR PC,TESTR ; PRINT TEST NUMBER
928 002056 004737 014734 JSR PC,TYPOUT
929 002062 006365 TS1MSG
930 002064
931 002064 012737 000100 007506 T0101: MOV #100,REPCNT ; SET ITERATION COUNT
932
933          : TRY TO SYNC UP
934
935 002072 004737 011644 T0102: JSR PC,SYNCUP ; SYNC UP
936 002076 000401 BR T0103 ; NO SYNC OR ABORT
937 002100 000403 BR T0104 ; GO A SYNC SIGNAL
938
939          : ERROR-
940          : CHECK 'LEVB CLOCK H' (8 MHZ)
941          : 'LEVB CLOCK L'
942          : 'LEVB VA02 H' (1 MHZ)
943          : 'LEVA VA02 L' (1 MHZ)
944          : 'LEVB VA17 H' (16.7 MILLISECS FOR 525, 20 FOR 625)
945 002102 004737 016666 T0103: JSR PC,ERROR ; ERROR
946 002106 000001 1
947 002110 104410 T0104: TRAP+10 ; LOOP
948 002112 002072 T0102 ; TO HERE
949 002114 005337 007506 DEC REPCNT ; REDUCE ITERATION
950 002120 001364 BNE T0102 ; KEEP GOING
951
952          : NOW RING THAT BELL
953
954 002122 012737 000005 007566 T0105: MOV #5,DATA ; FINE BELLS
955 002130 004737 012040 T0106: JSR PC,WAIT5 ; WAIT ONE SECOND
956 002134 000001 1
957 002136 004737 013166 JSR PC,BELL ; DING DONG !!
958 002142 005337 007566 DEC DATA
959 002146 001370 BNE T0106 ; KEEP GOING
960 002150 104420 TRAP+20
961 002152 002122 T0105 ; LOOP ?
962
963          :
964          :
965 002154 104404 TRAP+4 ; LOOP ON TEST
966 002156 002064 T0101
967 002160 032777 000100 005314 BIT #100,@54R ; PRESELECT TEST
968 002166 001402 BEQ TEST2
969 002170 000137 001326 JMP START2 ; YES- GO DO IT

```



969  
970  
971  
972  
973  
974  
975  
976  
977  
978  
979  
980  
981  
982  
983  
984  
985  
986  
987  
988  
989  
990  
991  
992  
993  
994  
995  
996  
997  
998  
999  
1000  
1001  
1002  
1003  
1004  
1005  
1006  
1007  
1008  
1009  
1010  
1011  
1012  
1013  
1014  
1015  
1016  
1017  
1018  
1019  
1020  
1021  
1022  
1023  
1024

.SBTTL TEST2

THE TEST CHECKS THE PICTURE BY WRITING TO EVERY LOCATION,  
 USING THE SAME FOREGROUND AND BACKGROUND COLOUR.

THE SEQUENCE OF OPERATIONS IS:

- F/B WHITE NO VIDEO
- F/B BLACK VIDEO ON
- F/B RED VIDEO ON
- F/B GREEN VIDEO ON
- F/B YELLOW VIDEO ON
- F/B BLUE VIDEO ON
- F/B MAGENTA VIDEO ON
- F/B CYAN VIDEO ON
- F/B WHITE VIDEO ON

CHARACTER STORE ERRORS ARE DELIBERATELY BYPASSED IN THIS TEST.  
 IF THE TEST WORKS, COLOUR INFORMATION CAN BE USED IN THE NEXT  
 TEST.

ERRORS-

CHECK LOW-ORDER BITS 0 PICTURE STORE (LEVC)

OUTPUT LATCH ON LEVD, E23.

OUTPUT MUX ON LEVD, E18.

STATICISERS E6 & E12, WITH STROBES 'LEVB STROBE A H', '-B H'

```

TEST2:  MOV    #2,TESTNO      ; SET TEST NUMBER
        TRAP+2
        T0201
        JSR    PC,TESTR      ; PRINT TEST NUMBER
        JSR    PC,TYPOUT
        TS2MSG
T0201:  MOV    #7,FORGND      ; SET F/B TO WHITE
        MOV    #7,BAKGND
        CLR    BLINK         ; NO BLINK
        CLR    FLASH        ; FLASH,
        CLR    VIDEON       ; OR VIDEO.
        CLR    CHAR         ; USE CHARACTER ZERO
        JSR    PC,LOADFS    ; LOAD THE DISPLAY
  
```

NOW WAIT AROUND

NOW LOAD THE REST OF THE PICTURES WITH VIDEO ON

```

        CLR    FORGND       ; START WITH BLACK
        CLR    BAKGND       ; ON BLACK
        MOV    #40000,VIDEON ; BUT WITH VIDEO ON
T0202:  JSR    PC,LOADFS    ; LOAD THE SCREEN
  
```

NOW WAIT AROUND

```

        JSR    PC,WAIT5     ; WAIT FOR 2 SECONDS
        2
        TRAP+10
  
```

000002 007454  
002174 012737  
002202 104402  
002204 002220  
002206 004737 011624  
002212 004737 014734  
002216 006411  
002220 012737 000007 007464  
002226 012737 000007 007466  
002234 005037 007470  
002240 005037 007472  
002244 005037 007450  
002250 005037 007550  
002254 004737 012410  
002260 005037 007464  
002264 005037 007466  
002270 012737 040000 007450  
002276 004737 012410  
002302 004737 012040  
002306 000002  
002310 104410

1025	002312	002276			T0202		; LOOP TO HERE
1026							
1027					...	NOW UPDATE THE COLOURS	
1028					...		
1029	002314	005237	007464		INC	FORGND	; NEW FORGROUND
1030	002320	005237	007466		INC	BAKGND	; AND BACKGROUND
1031	002324	023727	007464	000007	CMP	FORGND,#7	; ALL DONE
1032	002332	003761			BLE	T0202	; NO
1033					...		
1034					...	COMPLETE	
1035					...		
1036	002334	104404			TRAP+4		; LOOP ON TEST ?
1037	002336	002220			T0201		
1038	002340	032777	000100	005134	BIT	#100,@SWR	; PRESELECT TEST
1039	002346	001402			BEQ	TEST3	; NO
1040	002350	000137	001326		JMP	START2	; YES GO TO IT

```

1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055 002354 012737 000003 007454
1056 002362 104402
1057 002364 002400
1058 002366 004737 011624
1059 002372 004737 014734
1060 002376 006416
1061 002400 005037 007470
1062 002404 005037 007472
1063 002410 012737 040000 007450
1064 002416 005037 007550
1065 002422 012737 000004 007464
1066 002430 012737 000004 007466
1067 002436 004737 012410
1068
1069
1070
1071 002442 005037 007476
1072 002446 012737 000057 007474
1073 002454 012737 000005 007464
1074 002462 013737 007464 007466
1075
1076 002470 004737 012522
1077 002474 005237 007476
1078 002500 005337 007474
1079 002504 023727 007476 000040
1080 002512 001366
1081 002514 104410
1082 002516 002442
1083 002520 005037 007474
1084 002524 013737 007500 007476
1085 002532 012737 000007 007464
1086 002540 013737 007464 007466
1087
1088 002546 004737 012522
1089 002552 005237 007474
1090 002556 005337 007476
1091 002562 100371
1092 002564 104420
1093 002566 002520
1094
1095
1096 002570 004737 012040
1097 002574 000002

```

.SBTTL TEST3

```

: THIS TEST CHECKS THE CURSOR ADDRESSING FEATURES OF THE VTV30K.
: THE PICTURE IS FIRST SET TO BLUE ON BLUE.
: TWO DIAGONAL ROWS OF SQUARE CHARACTERS ARE PRODUCED. THE FIRST IN
: MAGENTA RUNS FROM THE TOP RIGHT CORNER TO THE BOTTOM OF THE SCREEN.
: THE SECOND IN WHITE RUNS FROM THE BOTTOM LEFT CORNER TO THE TOP.

```

```

: IF THIS TEST WORKS THE CAR AND THE PICTURE ADDRESSING IS OK.
: ERRORS-
: BROKEN, MISSING OR DUPLICATED DIAGONALS ARE CAUSED BY FAULTS
: ASSOCIATED WITH THE PICTURE ELEMENT SELECTOR ON LEVC.

```

```

TEST3: MOV #3,TESTNO ; SET TEST NUMBER
        TRAP+2
        T0301
        JSR PC,TESTR ; PRINT TEST NUMBER
        JSR PC,TYPOUT
        TS3MSG
T0301: CLR BLINK ; NO BLINK
        CLR FLASH ; NO FLASH
        MOV #40000,VIDEON ; ENABLE VIDEO
        CLR CHAR ; SELECT CHARACTER ZERO
        MOV #4,FORGND ; SELECT BLUE
        MOV #4,BAKGND ; ON BLUE
        JSR PC,LOADFS ; LOAD THE FULL SCREEN

```

: NOW DO X ADDRESS TESTING

```

T0303: CLR CARY ; START AT TOP OF SCREEN..
        MOV #47,CARX ; AT RIGHT.
        MOV #5,FORGND ; SET CHARACTERS TO CYAN
        MOV FORGND,BAKGND ; ...ALL OVER!

```

```

T0302: JSR PC,LOELEM ; LOAD ONE ELEMENT
        INC CARY ; NEXT LINE DOWN...
        DEC CARX ; SHIFT LEFT ONCE.
        CMP CARY,#32. ; OVER TOP?
        BNE T0302 ; NO, NEXT BLOCK
        TRAP+10 ; LOOP ON THIS BIT
        T0303

```

```

T0304: CLR CARX ; NOW START AT RIGHT
        MOV YMAX,CARY ; AT BOTTOM
        MOV #7,FORGND ; DISPLAY IN WHITE..
        MOV FORGND,BAKGND ; ALL OVER.

```

```

T0305: JSR PC,LOELEM ; LOAD ONE ELEMENT
        INC CARX ; SHIFT RIGHT
        DEC CARY ; SHIFT UP
        BPL T0305 ; PAST TOP OF SCREEN?
        TRAP+20 ; LOOP ON THIS
        T0304

```

: NOW WAIT AROUND

```

        JSR PC,WAIT5 ; WAIT FOR 2 SECONDS
        2

```

1098	002576	104404			TRAP+4		; LOOP ON TEST
1099	002600	002400			T0301		
1100	002602	032777	000100	004672	BIT	#100,ASWR	; PRESELECT TEST
1101	002610	001402			BEQ	TEST4	
1102	002612	000137	001326		JMP	START2	; YES- GO DO IT
1103							

1105  
1106  
1107  
1108  
1109  
1110  
1111  
1112  
1113  
1114  
1115  
1116  
1117  
1118  
1119  
1120  
1121  
1122  
1123  
1124  
1125  
1126  
1127  
1128  
1129  
1130  
1131  
1132  
1133  
1134  
1135  
1136  
1137  
1138  
1139  
1140  
1141  
1142  
1143  
1144  
1145  
1146  
1147  
1148  
1149  
1150  
1151  
1152  
1153  
1154  
1155  
1156  
1157  
1158  
1159  
1160

.SBTTL TEST4

: THIS TEST CHECKS OUT THE FOREGROUND BACKGROUND SELECTION, BY  
: DISPLAYING CHARACTER CODE ZERO IN ALL LOCATIONS. CHARACTER  
: ZERO IS DEFINED AS BEING HALF FOREGROUND AND HALF BACKGROUND,  
: IN A VERTICAL STRIPE (CHARACTER DATA 360). THE FOREGROUND  
: AND BACKGROUND COLOURS ARE THEN ALTERED AND THE WHOLE DISPLAY  
: IS REFRESHED. THE SEQUENCE BEING: BLACK ON WHITE,  
: BLINK SET, THEN BLINK CLEAR BUT FLASH SET. FINALLY BLINK AND  
: FLASH ARE SET TOGETHER, CAUSING A PICTURE THAT 'HOPS' SIDWAYS  
: WITH A BACKGROUND FLASHING.

: IF THIS TEST WORKS THE OUTPUT MUX (LEVB) IS FUNCTIONING.

ERRORS-

CHECK 'LEVB F/B SELECT H'  
'LEVB FLASH B H' IF BLINK OR FLASH DOES NOT WORK.

LEVA SIGNALS ON E4...  
'LEVB FLASH A'  
'LEVB FLASH B'  
'LEVD BLINK A'  
'LEVD BLINK B'  
'LEVD DATA'

002616	012737	000004	007454	TEST4:	MOV #4,TESTNO	: SET TESTNUMBER
002624	104402				TRAP+2	
002626	002642				T0401	
002630	004737	011624			JSR PC,TESTR	: PRINT TEST NUMBER
002634	004737	014734			JSR PC,TYPOUT	
002640	006426				TS4MSG	
002642	005037	007550		T0401:	CLR CHAR	: START WITH CHARACTER CODE 0
002646	005737	007462			TST PROM	: PROM CHARACTER SET ?
002652	001022				BNE T0403	: YES
002654	005001				CLR R1	: BUT THERE ARE 8 LINES TO IT
002656	013700	007550		T0402:	MOV CHAR,R0	: GET CHARACTER NUMBER
002662	006300				ASL R0	
002664	006300				ASL R0	: SET IT IN THE RIGHT PLACE
002666	006300				ASL R0	
002670	050100				BIS R1,R0	: ADD IN LINE NUMBER
002672	052700	100000			BIS #100000,R0	: SAY ITS SELECT CHSR
002676	010077	004534			MOV R0,@DEVCSR	: LOAD THE CSR
002702	012777	000360	004530		MOV #360,@DEVBUF	: LOAD THE DATA PATTERN
002710	005201				INC R1	: GET NEXT LINE
002712	020127	000007			CMP R1,#7	: ALL LINES DONE
002716	003757				BLE T0402	: NO YET
002720				T0403:	CLR FLASH	: NO FLASH
002720	005037	007472			CLR BLINK	: NO BLINK
002724	005037	007470			MOV #7,FORGND	: START WITH BLACK FOREGROUND
002730	012737	000007	007464		MOV #0,BAKGD	: AND IT COMPLEMENT BACKGROUND
002736	012737	000000	007466	T0406:	MOV #40000,VIDEON	: SET VIDEO ON
002744	012737	040000	007450		JSR PC,LOADFS	: FILL THE SCREEN
002752	004737	012410				
					WAIT AROUND	
002756	004737	012040			JSR PC,WAITS	: WAIT FOR 2 SECONDS

```

1161 002762 000002
1162 002764 104410
1163 002766 002736
1164
1165
1166
1167
1168
1169 002770 012737 000100 007470
1170 002776 004737 012410
1171 003002 004737 012040
1172 003006 000002
1173 003010 104420
1174 003012 002776
1175 003014 005037 007470
1176 003020 012737 000200 007472
1177 003026 004737 012410
1178 003032 004737 012040
1179 003036 000002
1180 003040 104430
1181 003042 003026
1182 003044 012737 000100 007470
1183 003052 004737 012410
1184 003056 004737 012040
1185 003062 000002
1186 003064 104440
1187 003066 003052
1188 003070 104404
1189 003072 002642
1190 003074 032777 000100 004400
1191 003102 001402
1192 003104 000137 001326

      2
      TRAP+10
      T0406
      ; LOOP ON THIS
      :
      : NOW UPDATE THE FOREGROUND COLOUR
      :
      : NOW CHANGE BLINK STATUS
      :
T0407: MOV #100,BLINK
      JSR PC,LOADFS ; LOAD DISPLAY
      JSR PC,WAITS ; WAIT 2 SECS
      2
      TRAP+20
      T0407
      ; LOOP ON PICTURE
      CLR BLINK ; RESET BLINK
      MOV #200,FLASH ; SET FLASH
T0409: JSR PC,LOADFS ; LOAD PICTURE
      JSR PC,WAITS ; WAIT 2 SECS
      2
      TRAP+30
      T0409
      ; LOOP ON PICTURE
T0410: MOV #100,BLINK ; NOW SET BLINK AND FLASH
      JSR PC,LOADFS ; FILL SCREEN
      JSR PC,WAITS ; STALL FOR A WHILE!
      2 ; 2 SECS
      TRAP+40
      T0410
      ; LOOP ON PICTURE
      TRAP+4
      T0401
      ; LOOP ON TEST
      BIT #100,@SWR ; PRESELECT TEST
      BEQ TEST5
      JMP START2 ; YES GO TO IT
  
```

1194  
 1195  
 1196  
 1197  
 1198  
 1199  
 1200  
 1201  
 1202  
 1203  
 1204  
 1205  
 1206  
 1207  
 1208  
 1209  
 1210  
 1211  
 1212  
 1213  
 1214  
 1215  
 1216  
 1217  
 1218  
 1219  
 1220  
 1221  
 1222  
 1223  
 1224  
 1225  
 1226  
 1227  
 1228  
 1229  
 1230  
 1231  
 1232  
 1233  
 1234  
 1235  
 1236  
 1237  
 1238  
 1239  
 1240  
 1241  
 1242  
 1243  
 1244  
 1245  
 1246  
 1247  
 1248  
 1249

.SBTTL TEST5

```

: THIS TEST CHECKS THE CHARACTER STORE FOR EITHER THE PROM
: OR RAM VERSIONS OF THE VTV30K. FOR THE PROM VERSION THE
: CHARACTER SET WILL BE DISPLAYED AS CYAN ON BLUE IN AN
: AREA FROM Y=10 ,X=3 THRU Y=12, X=45. THE CHARACTER SET
: IS DISPLAYED AS CHARACTER STORE ADDRESSES INCREMENTING
: HORIZONTALLY.
: FOR THE RAM CHARACTER SET, THE PICTURE IS LAYED OUT IN THE
: SAME WAY. A VERTICAL LINE IS THEN MOVED THROUGH THE CHARACTER
: STORE TO CHECK THE ACCESSABILITY OF THE MEMORY.
: NEXT A LINE IS ROTATED DOWN THE SCREEN TO CHECK THE LOW-ORDER
: BITS.
:
: THIS IS THE FIRST REAL TEST OF THE CHARACTER STORE. IF IT
: WORKS ALL CHARACTER STORE DATA AND ADDRESSING WORKS.
: ERRORS-
: CHECK HIGH-ORDER PICTURE STORE BITS (LEVB)
: PICTURE STORE STATICISER (LEVD)
: CHARACTER STORE ICS (LEVD)
: C.S. WRITE DATA,C.S. WRITE ADDRESS
: VERTICALLY CORRUPTED PROM CHARS, OR FAULTS IN HORIZONTAL
: LINES IN RAM VERSIONS, IMPLY FAULTS IN THE CHARACTER STORE
: LINE SELECTOR (LEVD)

```

```

TEST5: MOV #5,TESTNO ; SET TEST NUMBER
TRAP+2
T0501
JSR PC,TESTR
JSR PC,TYP0UT
TSSMSG
T0501: TST PROM ; IS THIS A PROM CHARACTER
BNE T0502 ; SET

```

: RAM CHARACTER SET PRESENT

```

TEST5A: CLR CHAR ; START WITH CHARACTER CODE ZERO
5$: CLR R1 ; THERE ARE 8 LINES PER CHAR
10$: MOV CHAR,R0 ; GET CHARACTER NUMBER
ASL R0 ; SET IN RIGHT PLACE
ASL R0
ASL R0
BIS R1,R0 ; ADD IN LINE NUMBER
BIS #100000,R0 ; SELECT CHSR
MOV R0,@DEVCSR ; SELECT CHARACTER TO ADDRESS
MOV #0,@DEVBUF ; LOAD ZEROES IN
INC R1 ; UPDATE LINE NUMBER
CMP R1,#7 ; ALL LINES DONE
BLE 10$ ; NO
INC CHAR ; SELECT NEXT CHAR
CMP CHAR,#177 ; ALL DONE
BLE 5$ ; NO

```

: NOW FILL THE SCREEN

```

1250 003226 005037 007472 T0502: CLR FLASH ; NO FLASH
1251 003232 005037 007470 CLR BLINK ; NO BLINK
1252 003236 012737 000000 007464 MOV #0, FORGND ; BLACK ON BLACK
1253 003244 012737 000000 007466 MOV #0, BAKGND
1254 003252 005037 007550 CLR CHAR ; CHARACTER CODE 0
1255 003256 012737 040000 007450 MOV #40000, VIDEON ; WITH VIDEO ON
1256 003264 004737 012410 JSR PC, LOADFS
1257 003270
1258 003270 012737 000003 007474 T0520: MOV #3, CARX ; START AT X=3
1259 003276 012737 000012 007476 MOV #10, CARY ; Y=10.
1260 003304 005037 007550 CLR CHAR ; CHARACTER CODE 0
1261 003310 012737 000006 007464 MOV #6, FORGND ; CYAN ON
1262 003316 012737 000004 007466 MOV #4, BAKGND ; BLUE
1263 003324 005037 007470 CLR BLINK
1264 003330 005037 007472 CLR FLASH ; NO FLASH OR BLINK
1265 003334 012737 040000 007450 MOV #40000, VIDEON ; VIDEO ON
1266 003342 004737 012522 T0518: JSR PC, LOELEM ; LOAD DATA OUT
1267 003346 005237 007474 INC CARX ; GET NEW COORD
1268 003352 023727 007474 000056 CMP CARX, #46. ; END OF DISPLAY
1269 003360 001005 BNE T0519 ; NO
1270 003362 012737 000003 007474 MOV #3, CARX ; YES START NEW LINE
1271 003370 005237 007476 INC CARY
1272 003374 005237 007550 T0519: INC CHAR ; SELECT NEXT CHARACTER
1273 003400 023727 007550 000177 CMP CHAR, #177 ; ALL DONE ?
1274 003406 003755 BLE T0518 ; NO
1275
1276 ;
1277 ; NOW INSERT LAST CHARACTER AS FILER...
1278
1279 ;
1280 ; TST PROM ; DIFFERENT FOR RAM...
1281 ; BEQ 2$ ; CONTINUE FOR RAM...
1282 ; MOV #', CHAR ; LOAD NEW CHARACTER
1283 ; JSR PC, LOELEM ; IN LAST SPACE AS SPACE.
1284 ; NOW WAIT AROUND
1285 ;
1286 ; JSR PC, WAITS ; WAIT A BIT
1287 ; 5 ; 5 SECONDS
1288 ; TRAP+10
1289 ; T0502
1290 ; JMP T05XIT
1291 ;
1292 ; 2$: MOV #85, CHAR ; FILL IN FINAL CHARACTER
1293 ; JSR PC, LOELEM
1294 ; JSR PC, WAITS ; SHOW PRIME PICTURE AS CUE.
1295 ; 1
1296 ;
1297 ; 5$: CLR R5 ; POINTS TO LINE POSITION
1298 ;
1299 ; 10$: TSTB TKS ; ANY ABORT?
1300 ; BPL 12$ ; NO..
1301 ; JSR PC, READ
1302 ; CMP R0, #' ; SPACE-HURRYUP?
1303 ; BEQ 30$ ; YES...
1304 ; CMP R0, #'G&37 ; BELL?
1305 ; BNE 12$ ; No...
1306 ; JSR PC, MONIT

```



```

1306 003522 004737 011644      12$: JSR    PC,SYNCUP      ; DELAY 2 PERIODS
1307 003526 000240                NOP
1308 003530 004737 011644      JSR    PC,SYNCUP
1309 003534 000240                NOP
1310 003536 010500                MOV    R5,R0      ; GET LINE POSITION..
1311 003540 042700 177770      BIC    #177770,R0 ; GET POS IN CHAR..
1312 003544 052700 000010      BIS    #10,R0
1313 003550 012704 100000      MOV    #100000,R4 ; PUT LINE IN INITIAL POS.
1314 003554 000241                CLC
1315 003556 005737 007622      TST    PAL      ; IF TV-ENCODED...
1316 003562 001401                BEQ    20$
1317 003564 000261                SEC      ; DOUBLE-UP LINE
1318
1319 003566 006004      20$: ROR    R4      ; SHIFT LINE TO POSN.
1320 003570 005300                DEC    R0
1321 003572 001375                BNE    20$
1322 003574 000304                SWAB   R4      ; SWITCH FOR CLEAN-UP TRAILER
1323 003576 010500                MOV    R5,R0      ; GET CURRENT CHAR..
1324 003600 042700 000007      BIC    #7,R0      ; WITHOUT LINE..
1325 003604 162700 000010      SUB    #10,R0     ; GET LAST CHAR...
1326 003610 100003                BPL    22$      ; VALID CHAR?
1327 003612 005000                CLR    R0      ; NO, START AT FIRST..
1328 003614 105004                CLRB  R4      ; CLEAR LINE
1329 003616 000304                SWAB   R4      ; SWAP LINES OVER..
1330
1331 003620 020027 000520      22$: CMP    R0,#42.*10 ; OVER TOP?
1332 003624 103402                BCS    23$      ; NO..
1333 003626 042704 177400      BIC    #177400,R4 ; ELSE CLEAR HIGH ORDER...
1334
1335 ; NOW WE HAVE 2 CHARACTERS TO LOAD. EACH CHANGE IN THE LINE
1336 ; INVOLVES LOADING 2 ADJACENT CHARACTERS.... THE ONE THE
1337 ; LINE IS/COULD BE SCROLLING OUT OF, AND THE ONE IT IS
1338 ; SCROLLING INTO.
1339
1340 003632 012702 000003      23$: MOV    #3,R2      ; 3 ROWS OF CHARACTERS.
1341
1342 003636 012703 000010      24$: MOV    #10,R3     ; 8 BYTES/CHARACTER
1343 003642 052700 140000      BIS    #140000,R0 ; CHAR STORE SEL,VIDEO-ON
1344 003646 010077 003564      MOV    R0,@DEVCSR
1345 003652 032777 002000 003556 BIT    #2000,@DEVCSR ; INHIBIT WRAP-ROUND
1346 003660 001034                BNE    29$
1347
1348 003662 010477 003552      26$: MOV    R4,@DEVBUF   ; LOAD DATUM
1349 003666 005277 003544      INC    @DEVCSR
1350 003672 005303                DEC    R3
1351 003674 001372                BNE    26$      ; FIRST CHARACTER DONE IN PAIR?
1352 003676 032777 002000 003532 BIT    #2000,@DEVCSR ; WRAP-ROUND?
1353 003704 001022                BNE    29$      ; YES...
1354 003706 000304                SWAB   R4      ; YES, GET NEXT DATUM
1355 003710 012703 000010      MOV    #10,R3
1356
1357 003714 010477 003520      27$: MOV    R4,@DEVBUF   ; LOAD DATUM
1358 003720 005277 003512      INC    @DEVCSR
1359 003724 005303                DEC    R3
1360 003726 001372                BNE    27$
1361 003730 000304                SWAB   R4      ; RESTORE ORIGINAL DATUM..

```

1362	003732	062700	000530		ADD	#43.*10,R0	:	UPDATE TO NEXT LINE..
1363	003736	032777	002000	003472	BIT	#2000,@DEVCSR	:	OVER TOP?
1364	003744	001002			BNE	29\$	:	YES...DONT WRAP AROUND!
1365	003746	005302			DEC	R2	:	ANY MORE...
1366	003750	001332			BNE	24\$	:	YES..
1367								
1368	003752	005205		29\$:	INC	R5	:	
1369	003754	020527	000530		CMP	R5,#43.*10	:	ALL DONE?
1370	003760	001243			BNE	10\$	:	YES...
1371								
1372	003762	104470		30\$:	TRAP+70		:	LOOP?
1373	003764	003466			5\$			
1374	003766	004737	012040		JSR	PC.WAITS	:	WAIT A SECOND...
1375	003772	000001			1			
1376								....THEN PROCEED TO VERTICAL-LINE...

```

1378 003774 005005          35$: CLR R5 ; POSITION MARKER FOR LINE.
1379 003776 012704 004000     MOV #4000,R4 ; ZERO CHSR
1380
1381 004002 010500          40$: MOV R5,R0 ; GET CHARACTER NUMBER
1382 004004 006300         ASL R0
1383 004006 006300         ASL R0
1384 004010 105000         CLR# R0 ; ZERO COLOUR+BLINK
1385 004012 052700 000047     BIS #47,R0 ; WHITE ON BLUE
1386 004016 010577 003414     MOV R5,@DEVCSR ; GET PICTURE ADDRESS
1387 004022 010077 003412     MOV R0,@DEVBUF ; LOAD ELEMENT
1388 004026 005205         INC R5 ; NEXT PICTURE CELL!
1389 004030 005304         DEC R4 ; ANY MORE PICTURE?
1390 004032 001363         BNE 40$ ; ..YES..
1391 004034 012705 002000     MOV #2000,R5 ; NOW CLEAR CHARACTER STRE
1392 004040 012777 100000 003370  MOV #100000,@DEVCSR
1393
1394 004046 005077 003366     45$: CLR @DEVBUF ; ZERO BYTE IN CHSR
1395 004052 005277 003360     INC @DEVCSR
1396 004056 005305         DEC R5 ; ANY MORE?
1397 004060 001372         BNE 45$ ; YES..
1398
1399 004062 105737 177560     50$: TSTB TKS ; ANY ABORT?
1400 004066 100012         BPL 52$ ; NO
1401 004070 004737 014206     JSR PC,READ
1402 004074 020027 000040     CMP R0,#' ; ABORT?
1403 004100 001440         BEQ 70$ ; ..YES...
1404 004102 020027 000007     CMP R0,#'G&37 ; BELL?
1405 004106 001002         BNE 52$ ; NO..
1406 004110 004737 013546     JSR PC,MONIT ; CALL MONITOR.
1407
1408 004114 004737 011644     52$: JSR PC,SYNCUP ; WAIT..
1409 004120 000240         NOP
1410 004122 004737 011644     JSR PC,SYNCUP
1411 004126 000240         NOP
1412 004130 010500         MOV R5,R0 ; GET CHARACTER..
1413 004132 005300         DEC R0 ; GET LAST FOR CLEARING
1414 004134 100406         BMI 53$
1415 004136 052700 140000     BIS #140000,R0 ; VIDEO ON, CHSR SELECT.
1416 004142 010077 003270     MOV R0,@DEVCSR ; GET ADDRESS..
1417 004146 005077 003266     CLR @DEVBUF ; ZERO CHARACTER BYTE.
1418
1419 004152 010500          53$: MOV R5,R0 ; GET CURRENT CHAR.
1420 004154 052700 140000     BIS #140000,R0
1421 004160 010077 003252     MOV R0,@DEVCSR ; LOAD ADDRESS
1422 004164 012777 000377 003246  MOV #377,@DEVBUF ; LIGHT LINE.
1423 004172 005205         INC R5 ; STEP TO NEXT LINE.
1424 004174 020527 000400     CMP R5,#400 ; NEXT LINE?
1425 004200 001330         BNE 50$ ; YES, LOOP
1426
1427 004202 104420          70$: TRAP+20
1428 004204 003774          35$
1429 004206 004737 012040     JSR PC,WAIT5 ; LOOP ON SUBTEST
1430 004212 000001          1
1431
1432
1433 ; END OF TEST..

```

1434								
1435	004214	104404						
1436	004216	003134						
1437	004220	032777	000100	003254				
1438	004226	001402						
1439	004230	000137	001326					

TEST5  
; LOOP ON TEST?  
; PRESELECTED TEST?

TRAP+4  
T0501  
BIT #100, @SWR  
BEQ TEST6  
JMP START2

L

```

1441          .SBTTL TEST6
1442          :
1443          : THIS TEST DISPLAYS A ROTATING CHARACTER PATTERN IN ALL PICTURE
1444          : LOCATIONS, WITH COLOUR WHITE ON BLACK.
1445          :
1446          : THIS CHECKS THE HIGH-ORDER PICTURE STORE BITS (THESE HOLD THE
1447          : SELECTED CHARACTER NUMBER)
1448          :
1449          : ERRORS-
1450          : HIGH ORDER PICTURE STORE BITS (LEVC)
1451          : PICTURE STORE STATICISER (LEVD)
1452          :
1453          004234 012737 000006 007454 TEST6: MOV      #6,TESTNO      ; SET TEST NUMBER
1454          004242 104402          TRAP+2
1455          004244 004260          T0601
1456          004246 004737 011624          JSR      PC,TESTR      ; PRINT TESTNUMBER
1457          004252 004737 014734          JSR      PC,TYP0UT
1458          004256 006441          TS6MSG
1459          004260 012737 000005 007506 T0601: MOV      #5,REPCNT
1460          004266 005737 007462          TST      PROM          ; IS THERE A PROM ON BOARD
1461          004272 001037          BNE      T0604          ; YES DON'T LOAD CHSR
1462          :
1463          : RAM CHARACTER SET NEEDS LOADING
1464          :
1465          004274 012700 007624          MOV      #P02CHR,R0    ; GET START OF DATA TO LOAD
1466          004300 005037 007550          CLR      CHAR          ; START AT CHARACTER ZERO
1467          004304 005001          T0602: CLR      R1          ; 8 LINES PER CHARACTER
1468          004306 013702 007550          T0603: MOV      CHAR,R2    ; GET CHAR CODE
1469          004312 006302          ASL      R2
1470          004314 006302          ASL      R2          ; SET IN RIGHT PLACE
1471          004316 006302          ASL      R2
1472          004320 050102          BIS      R1,R2          ; ADD IN LINE NUMBER
1473          004322 052702 100000          BIS      #100000,R2   ; SELECT CHSR
1474          004326 010277 003104          MOV      R2,@DEVCSR   ; LOAD CSR
1475          004332 112003          MOV      (R0)+,R3     ; GET DATA
1476          004334 000303          SWAB    R3
1477          004336 105003          CLRB    R3          ; ENSURE 8 BITS LOADED
1478          004340 000303          SWAB    R3
1479          004342 010377 003072          MOV      R3,@DEVBUF   ; LOAD DATA OUT
1480          004346 005201          INC      R1          ; UPDATE LINE NUMBER
1481          004350 020127 000007          CMP      R1,#7        ; ALL LINES DONE
1482          004354 003754          BLE     T0603          ; NO
1483          004356 005237 007550          INC      CHAR          ; UPDATE CHAR COUNT
1484          004362 023727 007550 000177          CMP      CHAR,#177    ; ALL DONE
1485          004370 003745          BLE     T0602          ; NOT YET
1486          :
1487          : NOW START PUTTING UP PICTURE
1488          :
1489          004372          T0604:
1490          004372 012737 040000 007450          MOV      #40000,VIDEON ; VIDEO ON
1491          004400 012737 000000 007466          MOV      #0,BAKGND    ; BLACK BACKGROUND
1492          004406 012737 000007 007464          MOV      #7,FORGND    ; WHITE FOREGROUND
1493          004414 005037 007470          CLR      BLINK
1494          004420 005037 007472          CLR      FLASH        ; NO BLINK OR FLASH
1495          004424 012700 007266          MOV      #CHXLST,R0   ; POINT TO START OF LIST
1496          004430 010001          T0605: MOV      R0,R1          ; GET PICTURE STARTER
  
```

```

1497 004432 005037 007476          CLR      CARY          ; START AT TOP LEFT
1498 004436 010102          T0606: MOV      R1,R2    ; GET LINE STARTER
1499 004440 005037 007474          CLR      CARX          ; START OF LINE
1500 004444 011237 007550          T0607: MOV      (R2),CHAR ; GET CHAR CODE
1501 004450 004737 012522          JSR      PC,LOELEM     ; DISPLAY THE CHARACTER
1502 004454 062702 000002          ADD      #2,R2         ; GET NEXT POINTER
1503 004460 021227 177777          CMP      (R2),#-1      ; END OF TABLE ?
1504 004464 001002          BNE      1$           ;
1505 004466 012702 007266          MOV      #CHXLST,R2    ; YES RESET IT
1506 004472 005237 007474          1$: INC      CARX       ; GET NEXT COORD
1507 004476 023737 007474 007446  CMP      CARX,XMAX     ; END OF ROW ?
1508 004504 003757          BLE      T0607        ; NOT YET
1509 004506 062701 000002          ADD      #2,R1         ; GET NEW LINE STARTER
1510 004512 021127 177777          CMP      (R1),#-1      ; END OF TABLE
1511 004516 001002          BNE      2$           ; NO
1512 004520 012701 007266          MOV      #CHXLST,R1    ; YES RESET IT
1513 004524 005237 007476          2$: INC      CARY       ; UPDATE ROW
1514 004530 023737 007476 007500  CMP      CARY,YMAX     ; END OF DISPLAY ?
1515 004536 003737          BLE      T0606        ; NOT YET
1516          ;
1517          ; WAIT AROUND
1518          ;
1519 004540 004737 012040          JSR      PC,WAITS      ; WAIT 2 SECONDS
1520 004544 000002          2
1521 004546 005337 007506          DEC      REPCNT        ; ALL DONE
1522 004552 001406          BEQ      T0615        ; YES
1523          ;
1524          ;
1525          ; UPDATE NEW PICTURE STARTER
1526          ;
1527 004554 062700 000002          ADD      #2,R0         ; NEW STARTER
1528 004560 021027 177777          CMP      (R0),#-1      ; ALL DONE ?
1529 004564 001321          BNE      T0605        ; NO
1530 004566 000701          BR       T0604        ; YES RESET TABLE MIXTURE
1531 004570 104404          T0615: TRAP+4
1532 004572 004372          T0604
1533 004574 032777 000100 002700  BIT      #100,BSWR     ; PRESELECT TEST
1534 004602 001402          BEQ      1$           ;
1535 004604 000137 001326          JMP      START2        ; YES GO DO IT
1536 004610          1$:
1537 004610 005237 007302          INC      DEVFLG        ; UPDATE UNIT COUNT
1538 004614 023737 007302 007304  CMP      DEVFLG,DEVcnt ; ALL UNITS DONE
1539 004622 002402          BLT      2$           ; NOT YET
1540 004624 000137 013062          JMP      ENDIT         ; YES, SIGNAL END OF PASS
1541 004630 013700 007302          2$: MOV      DEVFLG,R0    ; GET CURRENT UNIT
1542 004634 005200          INC      R0
1543 004636 006300          ASL      R0           ; AS A WORD OFFSET
1544 004640 016037 007306 007436  MOV      CSRO(R0),DEVCSR ; GET NEW CSR ADDRESS
1545 004646 016037 007310 007440  MOV      DBUFO(R0),DEVBUF ; AND DATA BUFFER
1546 004654 000137 001326          JMP      START2

```

```

1548 .SBTTL TEST7
1549
1550 : THIS TEST DISPLAYS A ROTATING CHARACTER PATTERN IN ALL PICTURE
1551 : LOCATIONS. IN ADDITION THE COLOUR, IS CHANGED FOR EACH COLUMN.
1552
1553 : THIS IS AN EXERCISER ONLY, NOT PART OF THE DIAGNOSTIC ROUTINES
1554
1555 004660 012737 000007 007454 TEST7: MOV #7,TESTNO ; SET TEST NUMBER
1556 004666 104402 TRAP+2
1557 004670 004704 T0701
1558 004672 004737 011624 JSR PC,TESTR ; PRINT TESTNUMBER
1559 004676 004737 014734 JSR PC,TYPOUT
1560 004702 006454 TS7MSG
1561 004704 012737 000200 007506 T0701: MOV #200,REFCNT
1562 004712 005737 007462 TST PROM ; IS THERE A PROM ON BOARD
1563 004716 001037 BNE T0704 ; YES DON'T LOAD CHSR
1564
1565 : RAM CHARACTER SET NEEDS LOADING
1566
1567 004720 012700 007624 MOV #D02CHR,R0 ; GET START OF DATA TO LOAD
1568 004724 005037 007550 CLR CHAR ; START AT CHARACTER ZERO
1569 004730 005001 T0702: CLR R1 ; 8 LINES PER CHARACTER
1570 004732 013702 007550 T0703: MOV CHAR,R2 ; GET CHAR CODE
1571 004736 006302 ASL R2
1572 004740 006302 ASL R2 ; SET IN RIGHT PLACE
1573 004742 006302 ASL R2
1574 004744 050102 BIS R1,R2 ; ADD IN LINE NUMBER
1575 004746 052702 100000 BIS #100000,R2 ; SELECT CHSR
1576 004752 010277 002460 MOV R2,@DEVCSR ; LOAD CSR
1577 004756 112003 MOVSB (R0)+,R3 ; GET DATA
1578 004760 000303 SWAB R3
1579 004762 105003 CLR R3 ; ENSURE 8 BITS LOADED
1580 004764 000303 SWAB R3
1581 004766 010377 002446 MOV R3,@DEVBUF ; LOAD DATA OUT
1582 004772 005201 INC R1 ; UPDATE LINE NUMBER
1583 004774 020127 000007 CMP R1,#7 ; ALL LINES DONE
1584 005000 003754 BLE T0703 ; NO
1585 005002 005237 007550 INC CHAR ; UPDATE CHAR COUNT
1586 005006 023727 007550 000177 CMP CHAR,#177 ; ALL DONE
1587 005014 003745 BLE T0702 ; NOT YET
1588
1589 : NOW START PUTTING UP PICTURE
1590
1591 005016 T0704:
1592 005016 012737 040000 007450 MOV #40000,VIDEON ; ENABLE VIDEO
1593 005024 012737 000000 007460 MOV #0,BASE1 ; START AT CHARACTER 0
1594 005032 005037 007476 T0705: CLR CARY ; START AT FIRST ROW
1595 005036 013737 007460 007456 MOV BASE1,BASE ; SET THIS PICTURE START
1596 005044 013737 007456 007550 T0706: MOV BASE,CHAR ; SET START FOR THIS ROW
1597 005052 005037 007474 CLR CARY ; START OF COLUMN
1598 005056 005037 007472 T0707: CLR FLASH ; NO FLASH
1599 005062 005037 007470 CLR BLINK ; NO BLINK
1600 005066 012737 000001 007466 MOV #1,BAKGN ; RED ON
1601 005074 012737 000001 007464 T0710: MOV #1,FORGND ; RED
1602 005102 004737 012522 T0711: JSR PC,LOELEM ; DISPLAY THE CHARACT.
1603 005106 005237 007550 INC CHAR ; SELECT NEXT ONE

```

1604	005112	042737	177600	007550	BIC	#177600,CHAR	: IN RANGE 0-177
1605	005120	005237	007474		INC	CARX	: GET NEXT COORD
1606	005124	023737	007474	007446	CMP	CARX,XMAX	: END OF ROW ?
1607	005132	003432			BLE	T0712	: NOT YET
1608	005134	005237	007456		INC	BASE	: ELSE SET NEW ROW STARTER
1609	005140	042737	177600	007456	BIC	#177600,BASE	: IN RANGE 0-177
1610	005146	005237	007476		INC	CARY	: UPDATE ROW
1611	005152	023737	007476	007500	CMP	CARY,YMAX	: END OF DISPLAY ?
1612	005160	003731			BLE	T0706	: NOT YET
1613	005162	005237	007460		INC	BASE1	: SET NEW PICTURE STARTER
1614	005166	042737	177600	007460	BIC	#177600,BASE1	: IN RANGE 0-177
1615							
1616					:	WAIT AROUND	
1617					:		
1618	005174	004737	012040		JSR	PC,WAITS	: WAIT 1 SECONDS
1619	005200	000001			1		
1620	005202	005337	007506		DEC	REPCNT	
1621	005206	001422			BEQ	T0715	
1622	005210	000137	005032		JMP	T0705	: YES
1623	005214	000137	005254		JMP	T0715	: NO EXIT TEST
1624					:		
1625	005220	006337	007464		T0712:	ASL	: GET NEW FOREGROUND
1626	005224	023727	007464	000004	CMP	FORGND,#4	: ALL DONE
1627	005232	003723			BLE	T0711	: NU
1628	005234	005237	007466		INC	BAKGND	: GET NEXT BACK GROUND
1629	005240	023727	007466	000007	CMP	BAKGND,#7	: ALL DONE
1630	005246	003712			BLE	T0710	: NO
1631	005250	000137	005056		JMP	T0707	: YES
1632	005254	104404			T0715:	TRAP+4	
1633	005256	004704			T0701		
1634	005260	000137	001326		JMP	START2	: YES GO DO IT



```

1636          .SBTTL TEST10
1637          :
1638          : THIS TEST PRINTS THE CURRENT ACCUMULATION OF ERRORS
1639          :
1640 005264 012737 000010 007454 TEST10: MOV #10,TESTNO ; SET TEST NUMBER
1641 005272 104402          TRAP+2
1642 005274 005310          T1001
1643 005276 004737 011624          JSR PC,TESTR ; PRINT TEST NUMBER
1644 005302 004737 014734          JSR PC,TYPOUT
1645 005306 006462          TS10MS
1646 005310 004737 014700          T1001: JSR PC,CRLF ; NEW LINE
1647 005314 004737 014734          JSR PC,TYPOUT ; SAY
1648 005320 007205          EMSG9 ; ERROR COUNT =
1649 005322 013700 007442          MOV ERRDI1,R0 ; PRINT HI WORD
1650 005326 004737 015024          JSR PC,PROCT
1651 005332 013700 007574          MOV ERRDIS,R0 ; AND LO WORD
1652 005336 004737 015024          JSR PC,PROCT
1653 005342 005037 007444          CLR ERRFLG
1654 005346 005037 007574          CLR ERRDIS
1655 005352 005037 007442          CLR ERRDI1
1656 005356 000137 001200          JMP RSTART ; RESTART
  
```

```
1658 .SBTTL TEST11
1659
1660 : THIS TEST DISPLAYS A PICTURE SUITABLE FOR TESTING ADAPTERS.
1661 : 7 BLOCKS OF 4 ROWS EACH OF THE FOLLOWING COLOURS, WITH 1,
1662 : 2, AND 4 MHZ BARS
1663
1664 005362 012737 000011 007454 TEST11: MOV #11,TESTNO ; SET TEST NUMBER
1665 005370 104402 TRAP+2
1666 005372 005400 SS
1667 005374 004737 011624 JSR PC,TESTR ; PRINT TEST NUMBER
1668
1669 005400 005005 5$: CLR R5 ; FIRST PICTURE ELEMENT
1670
1671 005402 010500 10$: MOV R5,R0 ; GET COLOUR
1672 005404 000300 SWAB R0
1673 005406 005200 INC R0 ; FIRST COLOUR RED, NOT BLACK
1674 005410 042700 177770 BIC #177770,R0 ; FOREGROUND
1675 005414 010501 MOV R5,R1 ; GET CHARACTER
1676 005416 042701 177700 BIC #177700,R1
1677 005422 010577 002010 MOV R5,@DEVCSR ; SET POSITION
1678 005426 020127 000014 CMP R1,#12. ; 1/2 MHZ?
1679 005432 103013 BCC 20$ ; NO..
1680 005434 042701 000076 BIC #76,R1 ; EVEN?
1681 005440 001406 BEQ 12$ ; YES...
1682 005442 010002 MOV R0,R2 ; SET F/B SAME..
1683 005444 006302 ASL R2 ; COPY TO BACKGROUND
1684 005446 006302 ASL R2
1685 005450 006302 ASL R2
1686 005452 050200 BIS R2,R0 ; COPY BACK..
1687 005454 000422 BR 77$
1688
1689 005456 005000 12$: CLR R0
1690 005460 000420 BR 77$ ; LOAD IT..
1691
1692 005462 020127 000030 20$: CMP R1,#24. ; 1 MHZ?
1693 005466 103001 BCC 40$ ; NO..
1694 005470 000414 BR 77$
1695
1696 005472 020127 000044 40$: CMP R1,#36. ; 2 MHZ?
1697 005476 103003 BCC 60$ ; NO..
1698 005500 052700 011400 BIS #19.*400,R0 ; LGAD 2 MHZ..
1699 005504 000406 BR 77$
1700
1701 005506 020127 000060 60$: CMP R1,#48. ; 4 MHZ?
1702 005512 103005 BCC 100$ ; NO, DISCARD..
1703 005514 052700 011000 BIS #18.*400,R0
1704 005520 000400 BR 77$
1705
1706 005522 010077 001712 77$: MOV R0,@DEVBUF ; LOAD CHARACTER
1707
1708 005526 005205 100$: INC R5
1709 005530 020527 004000 CMP R5,#4000 ; DONE?
1710 005534 001322 BNE 10$ ; NO..
1711
1712 005536 005737 007462 TST PROM ; LOAD CHSR?
1713 005542 001015 BNE 120$ ; NO..
```

```
1714  
1715 005544 012700 007624 ; MOV #P02CHR,R0 ; YAS...  
1716 005550 012701 002000 MOV #2000,R1  
1717 005554 012777 140000 001654 MOV #140000,@DEVCSR  
1718  
1719 005562 112077 001652 ;102$: MOVB (R0)+,@DEVBUF ; LOAD BYTE INTO CHSR  
1720 005566 005277 001644 INC @DEVCSR  
1721 005572 005301 DEC R1  
1722 005574 001372 BNE 102$  
1723  
1724 005576 012777 040000 001632 ;120$: MOV #40000,@DEVCSR ; TURN ON VIDEO...  
1725 005604 000137 001200 JMP RSTART
```

```
1727 .SBTTL ASCII STRINGS
1728
1729 .NLIST BEX
1730
1731 005610 046533 031467 037466 SET56: .ASCII $CM736?/M737?...a$
1732 005627 133 027124 027126 SETENC: .ASCII /[T.V. ENCODED?(Y OR N)...a/
1733 005660 042133 041505 046511 NUMDEV: .ASCII /[DECIMAL NUMBER OF UNITS(1)...a/
1734 005716 042533 052116 051105 CHRCOD: .ASCII /[CENTER IN OCTAL THE CHARACTER/
1735 005753 133 047503 042504 .ASCII /[CODE TO BE DISPLAYED....a/
1736 006005 133 052126 031526 GOMSG: .ASCII /[VTV30K DIAGNOSTIC/
1737 006027 133 052123 051101 .ASCII /[START ADDRESS 1000, RESTART 1200/
1738 006070 050133 042514 051501 .ASCII /[PLEASE READ THE LISTING BEFORE PROCEEDING!a/
1739 006144 052133 042510 042040 GOMS1: .ASCII /[THE DEVICES TO BE TESTED MUST/
1740 006202 044133 053101 020105 .ASCII /[HAVE THEIR ADDRESSES IN ASCENDING ORDER, AND/
1741 006257 133 040510 042526 .ASCII /[HAVE THE SAME CHARACTERISTICS@a/
1742 006317 133 042523 042514 WMSG: .ASCII /[SELECT SWITCH REGISTER OPTIONS@a/
1743 006360 041440 051123 100 TS0MSG: .ASCII / CSR@a/
1744 006365 040 046106 020104 TS1MSG: .ASCII / FLD VIDEO BELL TST@a/
1745 006411 040 047503 040114 TS2MSG: .ASCII / COL@a/
1746 006416 041440 051125 047523 TS3MSG: .ASCII / CURSOR@a/
1747 006426 043040 041055 100 TS4MSG: .ASCII / F-B@a/
1748 006433 040 044103 051123 TS5MSG: .ASCII / CHSR@a/
1749 006441 040 044520 020103 TS6MSG: .ASCII / PIC STORE@a/
1750 006454 042440 042530 040122 TS7MSG: .ASCII / EXER@a/
1751 006462 042533 051122 051440 TS10MS: .ASCII /[ERR SUM@a/
1752 006473 133 051524 040124 TESMSG: .ASCII /[TST@a/
1753 006500 042533 042116 047440 PASMSG: .ASCII /[END OF PASS@a/
1754 006516 052133 040522 020120 ILVMSG: .ASCII /[TRAP TO ILLEGAL VECTOR a/
1755 006550 043133 047522 020115 FRMSG: .ASCII /[FROM ADDRESS a/
1756 006570 052133 050131 020105 REDMES: .ASCII /[TYPE CNTRL-C TO CONTINUE a/
1757 006623 133 053523 020122 SWRMSG: .ASCII /[SWR = a/
1758 006635 133 020044 040040 MODADM: .ASCII /[$ a/
1759 006642 027440 040040 MODSPA: .ASCII ? / a?
1760 006646 025133 020040 100 MODPRM: .ASCII /[* a/
1761 006653 133 044506 051522 BMSG: .ASCII /[FIRST BUS ADDRESS IS .....a/
1762 006707 133 047111 040526 ODMSG: .ASCII /[INVALID ADDRESS a/
1763 006732 047133 047117 042440 NXMSG: .ASCII /[NON EXISTANT ADDRESS a/
1764 006762 042133 043105 052501 NODEFM: .ASCII /[DEFAULT SETTINGS ARE NOT ALLOWED/
1765 007023 133 046120 040505 .ASCII /[PLEASE RE-ENTER THE VALUE .....a/
1766 007064 042533 040043 EMSG1: .ASCII /[E@a/
1767 007070 020040 052101 050040 EMSG2: .ASCII / AT PC a/
1768 007102 043533 047517 020104 EMSG3: .ASCII /[GOOD : a/
1769 007113 040 020040 040502 EMSG4: .ASCII / BAD :a/
1770 007124 042133 052101 020101 EMSG5: .ASCII /[DATA : a/
1771 007135 040 020040 042101 EMSG6: .ASCII / ADDRESS :a/
1772 007153 133 052123 052101 EMSG7: .ASCII /[STATUS :a/
1773 007166 041533 046101 042514 EMSG8: .ASCII /[CALLED FROM :a/
1774 007205 040 020040 051105 EMSG9: .ASCII / ERROR COUNT = a/
1775 007230 .EVEN
1776 007230 000000 000000 000000 OCTNUM: .WORD 0,0,0
1777 007236 100 000 .BYTE 100,0
1778 007240 040502 042523 030061 BASE11: .ASCII /BASE10a/
1779 007250 .EVEN
1780 007250 000000 000000 000000 DECMMSG: .WORD 0,0,0
1781 007256 000000 000000 000000 OCTMSG: .WORD 0,0,0,0
1782 .EVEN
```

VTV30K DIAGNOSTIC MACY11 30A(1052) 08-JAN-81 10:58 PAGE 31-1<sup>F 4</sup>  
CVVICA.SRC 08-JAN-81 10:36 ASCII STRINGS

SEQ 0044

1783

.LIST BEX

```

1785          .SBTTL PROGRAM VARIABLES
1786
1787 007266 000021 000042 000104 CHXLST: .WORD 21,42,104,10,40,-1
      007274 000010 000040 177777
1788 007302 000000 DEVFLG: 0
1789 007304 000001 DEVCNT: 1
1790 007306 174000 CSR0: 174000
1791 007310 174002 DBUF0: 174002
1792 007312 000000 CSR1: 0
1793 007314 000000 DBUF1: 0
1794 007316 000000 CSR2: 0
1795 007320 000000 DBUF2: 0
1796 007322 000000 CSR3: 0
1797 007324 000000 DBUF3: 0
1798 007326 000000 CSR4: 0
1799 007330 000000 DBUF4: 0
1800 007332 000000 CSR5: 0
1801 007334 000000 DBUF5: 0
1802 007336 000000 CSR6: 0
1803 007340 000000 DBUF6: 0
1804 007342 000000 CSR7: 0
1805 007344 000000 DBUF7: 0
1806 007346 000000 CSR8: 0
1807 007350 000000 DBUF8: 0
1808 007352 000000 CSR9: 0
1809 007354 000000 DBUF9: 0
1810 007356 000000 CSR10: 0
1811 007360 000000 DBUF10: 0
1812 007362 000000 CSR11: 0
1813 007364 000000 DBUF11: 0
1814 007366 000000 CSR12: 0
1815 007370 000000 DBUF12: 0
1816 007372 000000 CSR13: 0
1817 007374 000000 DBUF13: 0
1818 007376 000000 CSR14: 0
1819 007400 000000 DBUF14: 0
1820 007402 000000 CSR15: 0
1821 007404 000000 DBUF15: 0
1822 007406 000000 CSR16: 0
1823 007410 000000 DBUF16: 0
1824 007412 000000 CSR17: 0
1825 007414 000000 DBUF17: 0
1826 007416 000000 CSR18: 0
1827 007420 000000 DBUF18: 0
1828 007422 000000 CSR19: 0
1829 007424 000000 DBUF19: 0
1830 007426 000000 CSR20: 0
1831 007430 000000 DBUF20: 0
1832 007432 000000 000000 .WORD 0,0
1833 007436 000000 DEVCSR: 0
1834 007440 000000 DEVBUF: 0
1835 007442 000000 ERRDI1: 0
1836 007444 000000 ERRFLG: 0
1837 007446 000000 XMAX: 0
1838 007450 000000 VIDEON: 0
1839 007452 000000 WAIT1: 0
  
```

1840	007454	000000		TESTNO:	0
1841	007456	000000		BASE:	0
1842	007460	000000		BASE1:	0
1843	007462	000000		PROM:	0
1844	007464	000000		FORGND:	0
1845	007466	000000		BAKGND:	0
1846	007470	000000		BLINK:	0
1847	007472	000000		FLASH:	0
1848	007474	000000		CARX:	0
1849	007476	000000		CARY:	0
1850	007500	000000		YMAX:	0
1851	007502	177570		SWR:	HSWR
1852	007504	000000		SSWR:	0
1853	007506	000000		REPCNT:	0
1854	007510	000137	001000	JM600:	JMP @#START
1855	007514	000001		FSTCNT:	1
1856	007516	000000		TRPARG:	0
1857	007520	000000		TRPSEL:	0
1858	007522	000000		TRPMEM:	0
1859	007524	000000		SAVPC:	0
1860	007526	000000		SAVPC1:	0
1861	007530	000000		TYPOTA:	0
1862	007532	000000		RAND:	0
1863	007534	000000		TYPD1:	0
1864	007536	000000		MODADR:	0
1865	007540	000000		MODSAV:	0
1866	007542	000000		BASADD:	0
1867	007544	000000		TRPERR:	0
1868	007546	000000		PARITY:	0
1869	007550	000000		CHAR:	0
1870	007552	052525		RANDN:	52525
1871	007554	000001		RANSEL:	1
1872	007556	000006		RANMTA:	6
1873	007560	052525		RANST:	52525
1874	007562	000000		GOOD:	0
1875	007564	000000		BAD:	0
1876	007566	000000		DATA:	0
1877	007570	000000		STATUS:	0
1878	007572	000000		ADDRES:	0
1879	007574	000000		ERRDIS:	0
1880	007576	000000		ERRARG:	0
1881	007600	000000		CALLPC:	0
1882	007602	000000		CNVFLG:	0
1883	007604	000000		STRADD:	0
1884	007606	000000		STRLEN:	0
1885	007610	000000		LOWCHR:	0
1886	007612	000000		UPPCHR:	0
1887	007614	000000		RUBFLG:	0
1888	007616	000000		RANDC:	0
1889	007620	000000		FSAVPW:	0
1890	007622	000000		PAL:	0

1892  
1893  
1894  
1895  
1896 007624  
1897 007624 360 360 360  
1898 007634 010 010 010  
1899 007644 030 030 030  
1900 007654 074 074 074  
1901 007664 000 000 000  
1902 007674 000 000 000  
1903 007704 000 000 377  
1904 007714 010 010 010  
1905 007724 030 030 030  
1906 007734 074 074 377  
1907 007744 001 002 004  
1908 007754 200 100 040  
1909 007764 000 014 022  
1910 007774 201 102 044  
1911 010004 074 176 377  
1912 010014 030 074 176  
1913 010024 010 010 024  
1914 010034 010 010 034  
1915 010044 252 252 252  
1916 010054 314 314 314  
1917 010064 377 000 377  
1918 010074 377 377 000  
1919 010104 377 203 205  
1920 010114 377 201 201  
1921 010124 377 376 374  
1922 010134 377 177 077  
1923 010144 200 300 340  
1924 010154 001 003 007  
1925 010164 003 007 016  
1926 010174 300 340 260  
1927 010204 303 347 176  
1928 010214 000 160 120  
1929 010224 000 000 000  
1930 010234 010 010 010  
1931 010244 024 024 024  
1932 010254 024 024 066  
1933 010264 010 036 040  
1934 010274 000 062 062  
1935 010304 000 020 050  
1936 010314 000 030 030  
1937 010324 000 010 020  
1938 010334 000 010 004  
1939 010344 000 052 034  
1940 010354 000 000 010  
1941 010364 000 000 000  
1942 010374 000 000 000  
1943 010404 000 000 000  
1944 010414 000 002 002  
1945 010424 000 034 042  
1946 010434 000 010 030  
1947 010444 000 034 042

.NLIST BEX

... THIS CHARACTER SET IS OVERLAYED BY THE RELEVANT CHARACTER SET  
... FOR ENCODED OR UNENCODED DEVICES.  
PO2CHR:

.BYTE 360,360,360,360,360,360,360,360  
.BYTE 010,010,010,010,010,010,010,010  
.BYTE 030,030,030,030,030,030,030,030  
.BYTE 074,074,074,074,074,074,074,074  
.BYTE 000,000,000,000,377,000,000,000  
.BYTE 000,000,000,000,377,377,000,000  
.BYTE 000,000,377,377,377,377,000,000  
.BYTE 010,010,010,010,377,010,010,010  
.BYTE 030,030,030,377,377,030,030,030 :10  
.BYTE 074,074,377,377,377,377,074,074  
.BYTE 001,002,004,010,020,040,100,200  
.BYTE 200,100,040,020,010,004,002,001  
.BYTE 000,014,022,040,170,040,100,176  
.BYTE 201,102,044,030,030,044,102,201  
.BYTE 074,176,377,377,377,377,176,074  
.BYTE 030,074,176,377,377,176,074,034  
.BYTE 010,010,024,042,301,042,024,010  
.BYTE 010,010,034,076,377,076,034,010  
.BYTE 252,252,252,252,252,252,252,252 :20  
.BYTE 314,314,314,314,314,314,314,314  
.BYTE 377,000,377,000,377,000,377,000  
.BYTE 377,377,000,000,377,377,000,000  
.BYTE 377,203,205,211,221,241,301,377  
.BYTE 377,201,201,201,201,201,201,377  
.BYTE 377,376,374,370,360,340,300,200  
.BYTE 377,177,077,037,017,007,003,001  
.BYTE 200,300,340,360,370,374,376,377  
.BYTE 001,003,007,017,037,077,177,377  
.BYTE 003,007,016,034,070,160,340,300 :30  
.BYTE 300,340,260,070,034,016,007,003  
.BYTE 303,347,176,074,074,176,347,303  
.BYTE 000,160,120,160,000,000,000,000  
.BYTE 000,000,000,000,000,000,000,000  
.BYTE 010,010,010,010,010,000,010,000  
.BYTE 024,024,024,000,000,000,000,000  
.BYTE 024,024,066,000,066,024,024,000  
.BYTE 010,036,040,034,002,074,010,000  
.BYTE 0, 62, 62, 4, 10, 20, 46, 46  
.BYTE 0, 20, 50, 50, 20, 52, 44, 32 :40(')  
.BYTE 0, 30, 30, 30, 0, 0, 0, 0  
.BYTE 0, 10, 20, 40, 40, 40, 20, 10  
.BYTE 0, 10, 4, 2, 2, 2, 4, 10  
.BYTE 0, 52, 34, 76, 34, 52, 0, 0  
.BYTE 0, 0, 10, 10, 76, 10, 10, 0  
.BYTE 0, 0, 0, 0, 30, 30, 10, 20  
.BYTE 0, 0, 0, 0, 76, 0, 0, 0  
.BYTE 0, 0, 0, 0, 0, 0, 30, 30  
.BYTE 0, 2, 2, 4, 10, 20, 40, 40  
.BYTE 000,034,042,046,052,062,042,034 :50(1)  
.BYTE 000,010,030,010,010,010,010,034  
.BYTE 000,034,042,002,034,040,040,076





2004	011354	370	370	370	.BYTE	370,370,370,370,370,370,370,370	
2005	011364	360	360	360	.BYTE	360,360,360,360,360,360,360,360	:110
2006	011374	340	340	340	.BYTE	340,340,340,340,340,340,340,340	
2007	011404	300	300	300	.BYTE	300,300,300,300,300,300,300,300	
2008	011414	200	200	200	.BYTE	200,200,200,200,200,200,200,200	
2009	011424	200	200	200	.BYTE	200,200,200,200,200,200,200,377	
2010	011434	377	001	001	.BYTE	377,001,001,001,001,001,001,001	
2011	011444	001	001	001	.BYTE	001,001,001,001,001,001,001,377	
2012	011454	200	200	200	.BYTE	200,200,200,200,200,200,200,377	
2013	011464	000	000	000	.BYTE	000,000,000,000,000,000,000,200	
2014	011474	200	000	000	.BYTE	200,000,000,000,000,000,000,000	
2015	011504	001	000	000	.BYTE	001,000,000,000,000,000,000,000	:120
2016	011514	000	000	000	.BYTE	000,000,000,000,000,000,000,001	
2017	011524	000	010	024	.BYTE	000,010,024,042,343,000,000,000	
2018	011534	010	010	030	.BYTE	010,010,030,040,100,040,030,010	
2019	011544	000	074	146	.BYTE	000,074,146,303,201,000,000,000	
2020	011554	030	060	140	.BYTE	030,060,140,100,100,140,060,030	
2021	011564	000	000	000	.BYTE	000,000,000,000,017,010,010,010	
2022	011574	010	010	010	.BYTE	010,010,010,010,370,000,000,000	
2023	011604	010	010	010	.BYTE	010,010,010,010,013,000,000,000	
2024	011614	000	000	000	.BYTE	000,000,000,000,370,010,010,010	
2025							

2027  
2028  
2029  
2030  
2031  
2032  
2033  
2034  
2035  
2036  
2037  
2038  
2039  
2040  
2041  
2042  
2043  
2044  
2045  
2046  
2047  
2048  
2049  
2050  
2051  
2052  
2053  
2054  
2055  
2056  
2057  
2058  
2059  
2060  
2061  
2062  
2063  
2064  
2065  
2066  
2067  
2068  
2069  
2070  
2071  
2072  
2073  
2074  
2075  
2076  
2077  
2078  
2079  
2080

```

.SBTTL PRINT TEST NUMBER

:
:
:
DESCRIPTION:
:
:
:
ROUTINE TO PRINT THE TEST NUMBER IN OCTAL

:
:
CALLING SEQUENCE:
:
:
JSR PC,TESTR

:
INPUT PARAMETERS:
:
:
TESTNO CONTAINS THE OCTAL TEST NUMBER TO BE
PRINTED

:
:
IMPLICIT INPUT PARAMETERS:
:
:
THE LABEL TESMSG IS THE START ADDRESS OF AN
ASCII STRING 'TEST NO'

:
:
OUTPUT PARAMETERS:
:
:
R0 WILL BE CORRUPTED

:
:
IMPLICIT OUTPUT PARAMETERS:
:
:
THE MESSAGE 'TEST NO N' WILL BE PRINTED ON THE
CONSOLE TERMINAL

:
:
COMPLETION CODES:
:
:
NONE

:
:
POSSIBLE ERROR CODES:
:
:
NONE

:
TESTR: JSR PC,TYPOUT
: TESMSG ;TEST NO
: MOV TESTNO,R0
: JSR PC,PROCT ;PRINT OCTAL TEST NO
: RTS PC ;EXIT
  
```

011624 004737 014734  
 011630 005473  
 011632 013700 007454  
 011636 004737 015024  
 011642 000207

2082  
2083  
2084  
2085  
2086  
2087  
2088  
2089  
2090  
2091  
2092  
2093  
2094  
2095  
2096  
2097  
2098  
2099  
2100  
2101  
2102  
2103  
2104  
2105  
2106  
2107  
2108  
2109  
2110  
2111  
2112  
2113  
2114  
2115  
2116  
2117  
2118  
2119  
2120  
2121  
2122  
2123  
2124  
2125  
2126  
2127  
2128  
2129  
2130  
2131  
2132  
2133  
2134  
2135  
2136  
2137

.SBTTL SYNC UP THE PROGRAM

DESCRIPTION:

THIS ROUTINE WILL ATTEMPT TO SYNC THE PROGRAM UP TO EITHER A HI-LO, OR LO-HI TRANSITION START OF THE FIELD VIDEO PERIOD. A HURRY UP FEATURE IS AVAILABLE, BY TYPING THE SPACE KEY ON THE CONSOLE TERMINAL. THIS CAUSES THE ROUTINE TO EXIT PREMATURELY, INDICATING THAT IT COULD NOT SYNC UP.

CALLING SEQUENCE:

JSR PC,SYNCUP  
A:  
B:

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

DEVCSR CONTAINS THE CURRENT CSR ADDRESS

OUTPUT PARAMETERS:

TWO POSSIBLE RETURN ADDRESSES CAN BE USED DEPENDING UPON THE SUCEES OF THE SYNC ATTEMPT.  
A: IMPOSSIBLE TO SYNC UP OR SPACE TYPED ON CONSOLE  
B: SYNCED UP

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

ERROR 70- CANNOT FIND AN INITIAL LEVEL  
ERROR 67- CANNOT CHANGE STATE

```

2138 011644 004737 013740 SYNCUP: JSR PC,SAVREG ; SAVE GOODIES
2139 011650 005005 CLR R5 ; SETS TO 1 WHEN HIGH LEVEL DETECTED
2140 011652 005004 CLR R4 ; SET SYNC INDETERMINATE
2141 011654 012703 037777 MOV #037777,R3 ; SETUP TIMEOUT
2142 ;
2143 011660 012702 000040 MOV #40,R2 ; SET FILTER TIME CONSTANT
2144 ;
2145 011664 017701 175546 10$: MOV @DEVCSR,R1 ; GET CONTENTS
2146 011670 042701 157777 BIC #157777,R1 ; ISOLATE VIDEO-ON
2147 011674 162701 010000 SUB #010000,R1 ; NORMALISE AROUND ZERO.
2148 011700 100405 BMI 20$ ; UP OR DOWN?
2149 011702 020427 040000 CMP R4,#040000 ; AT END STOP?
2150 011706 001406 BEQ 30$ ; YES..
2151 011710 060104 ADD R1,R4 ; ELSE, UPDATE.
2152 011712 000404 BR 30$
2153 ;
2154 011714 020427 140000 20$: CMP R4,#140000 ; AT END STOP?
2155 011720 001401 BEQ 30$ ; YES..
2156 011722 060104 ADD R1,R4
2157 ;
2158 011724 005704 30$: TST R4 ; SIGN?
2159 011726 100413 BMI 35$ ; ZERO...
2160 011730 020427 030000 CMP R4,#030000 ; VALID ONE?
2161 011734 103417 BCS 40$ ; NO...
2162 011736 012702 000040 MOV #40,R2 ; RESET TIME CONSTANT
2163 011742 020327 037764 CMP R3,#037764 ; READY TO TEST?
2164 011746 103012 BCC 40$ ; NO...
2165 011750 012705 000001 MOV #1,R5 ; SET FLAG..
2166 011754 000407 BR 40$
2167 ;
2168 011756 020427 160000 35$: CMP R4,#160000 ; VALID ZERO?
2169 011762 103004 BCC 40$ ; NO..
2170 011764 005705 TST R5 ; HIGH LEVEL YET?
2171 011766 001017 BNE 50$ ; YES, A-OK!
2172 011770 012702 000040 MOV #40,R2 ; RESET TIME CONSTANT
2173 ;
2174 011774 005302 40$: DEC R2 ; TIME CONSTANT TALLY..
2175 011776 001005 BNE 45$ ; OK SO FAR IF BRANCH..
2176 ;
2177 ; ERROR-
2178 ; CHECK 'LEVB CLOCK H' STABILITY
2179 ; 'LEVB VA17 H'
2179 012000 004737 016666 JSR PC,ERROR ; ELSE NOISY SYNC SIGNAL!
2180 012004 000070 70
2181 012006 000137 012032 JMP NOSYNC ; ERROR EXIT
2182 ;
2183 012012 005303 45$: DEC R3 ; TIMEOUT FOR SYNC?
2184 012014 001323 BNE 10$ ; NO....
2185 ;
2186 ; ERROR-
2187 ; CHECK 'LEVB CLOCK H' (8 MHZ)
2188 ; 'LEVB CLOCK L'
2189 ; 'LEVA VA02 L'
2189 ; 'LEVB VA17 H'
2190 012016 004737 016666 JSR PC,ERROR ; SYNC STOPPED'
2191 012022 000067 67
2192 012024 000402 BR NOSYNC ; ERROR RETURN
2193 ;
  
```

```
2194 012026 062716 000002      50$:  ADD      #2,(SP)      ; UPDATE TO GOOD RETURN
2195                                     ;
2196 012032 004737 013776      NOSYNC: JSR     PC,RSTREG   ; RECOVER REGISTERS.
2197 012036 000207                RTS      PC               ; ..AND EXIT
```

2199  
2200  
2201  
2202  
2203  
2204  
2205  
2206  
2207  
2208  
2209  
2210  
2211  
2212  
2213  
2214  
2215  
2216  
2217  
2218  
2219  
2220  
2221  
2222  
2223  
2224  
2225  
2226  
2227  
2228  
2229  
2230  
2231  
2232  
2233  
2234  
2235  
2236  
2237  
2238  
2239  
2240  
2241  
2242  
2243  
2244  
2245  
2246  
2247  
2248  
2249  
2250  
2251  
2252  
2253  
2254

.SBTTL WAIT A NUMBER OF SECONDS

DESCRIPTION:

ROUTINE TO WAIT A NUMBER OF UNITS (SECONDS), BASED  
UPON THE FIELD VIDEO PERIOD.

CALLING SEQUENCE:

JSR PC,WAITS  
XX

INPUT PARAMETERS:

XX IS THE NUMBER OF UNITS (SECONDS) TO WAIT

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

NONE

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

```

WAITS: JSR    PC,SAVREG    ; SAVE REGISTERS
        MOV    @ (SP),R1  ; GET SECOND COUNT
        ADD    #2,(SP)    ; PROTECT RETURN
        MOV    TESTNO,R2  ; GET TEST NUMBER
        TSTB  TABLE2(R2) ; IS IT STALL-ABLE?
        BEQ   1$          ; NO IF BRANCH
        TST   REACT       ; HAS USER OVERRIDDEN TIMER?
        BEQ   1$          ; NO.
        MOV   REACT,R1    ; ELSE RESET TIME.
        ;
1$:     MOV    WAIT1,R2   ; GET TIME FOR ONE SECOND.

```

```

2244 012040 004737 013740
2245 012044 017601 000000
2246 012050 062716 000002
2247 012054 013702 007454
2248 012060 105762 001436
2249 012064 001405
2250 012066 005737 001174
2251 012072 001402
2252 012074 013701 001174
2253
2254 012100 013702 007452

```

2255				.			
2256	012104	105737	177560	2s:	TSTB	TKS	: ANY CONSOLE INPUT?
2257	012110	100012			BPL	3s	: NO...
2258	012112	004737	014206		JSR	PC,READ	: ELSE GET CHARACTER..
2259	012116	020027	000040		CMP	RO,#'	: EXIT ON SPACE
2260	012122	001414			BEQ	7s	
2261	012124	020027	000007		CMP	RO,#'G&37	: 'BELL'?
2262	012130	001002			BNE	3s	: NO..
2263	012132	004737	013546		JSR	PC,MONIT	: ..ELSE CALL UP MONITOR.
2264				.			
2265	012136	004737	011644	3s:	JSR	PC,SYNCUP	: SYNC UP
2266	012142	000240			NOP		: IGNORE ERRORS
2267	012144	005302			DEC	R2	: ONE SECOND?
2268	012146	001356			BNE	2s	: NOT YET..
2269	012150	005301			DEC	R1	: MORE SECONDS?
2270	012152	001352			BNE	1s	: YES, KEEP LOOPING
2271				.			
2272	012154	004737	013776	7s:	JSR	PC,RSTREG	: EXIT AFTER RECOVERING REGS.
2273	012150	000207			RTS	PC	



2275  
2276  
2277  
2278  
2279  
2280  
2281  
2282  
2283  
2284  
2285  
2286  
2287  
2288  
2289  
2290  
2291  
2292  
2293  
2294  
2295  
2296  
2297  
2298  
2299  
2300  
2301  
2302  
2303  
2304  
2305  
2306  
2307  
2308  
2309  
2310  
2311  
2312  
2313  
2314  
2315  
2316  
2317  
2318  
2319  
2320  
2321  
2322  
2323  
2324  
2325  
2326  
2327  
2328  
2329  
2330

.SBTTL SELECT 525/625

DESCRIPTION:

THIS ROUTINE PROMPTS THE OPERATOR TO DETERMINE WHAT DEVICE(S) ARE BEING TESTED. THE ROUTINE PROMPTS 'VTV30-K?', AND LOOKS FOR A RESPONSE OF A,B,C,D OR G, TO SELECT THE APPROPRIATE DEVICE. HAVING FOUND WHICH DEVICE HAS BEEN SELECT, THE ROUTINE THEN SETS UP FLAGS AS TO THE SIZE OF THE DISPLAY AREA AND WHETHER IT HAS A ROM OR RAM CHARACTER STORE.

CALLING SEQUENCE:

JSR PC,SETDEV

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

PROM=0 FOR RAM CHSR  
PROM=1 FOR PROM CHSR

XMAX= MAXIMUM X ADDRESS  
YMAX= MAXIMUM Y ADDRESS

WAIT1= TIMER VALUE FOR 1 SECOND (?)

RELEVANT RAM CHARACTER SET

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

```

2331
2332 012162 004737 013740      SETDEV: JSR      PC,SAVREG      : SAVE OLD ENVIRONMENT
2333
2334 012166 004737 014734      1s:   JSR      PC,TYPOUT      : ASK MODULE TYPE?
2335 012172 005610
2336 012174 004737 014206      JSR      PC,READ      : READ REPLY...A/B/C/D/G
2337 012200 012701 012374      MOV      #DEVLIST,R1      : GET CHECK TABLE ADDRESS
2338
2339 012204 121100      3s:   CMPB     (R1),R0      : THIS MODULE?
2340 012206 001404      BEQ      10$              : YES...
2341 012210 005721      TST     (R1)+            : ELSE SKIP ON TO NEXT
2342 012212 005711      TST     (R1)             : END OF TABLE?
2343 012214 001373      BNE     3$               : NO, TRY NEXT
2344 012216 000763      BR      1$               : ELSE RESTART.
2345
2346 012220 005037 007622      10s:  CLR      PAL          : PRESET TO NON-TV-ENCODED.
2347 012224 032711 001000      BIT     #1000,(R1)       : IS IT 525?
2348 012230 001407      BEQ     12$              : NO IF BRANCH
2349 012232 012737 000033 007500      MOV     #27.,YMAX        : MAXIMUM ROW NO FOR 525
2350 012240 012737 000074 007452      MOV     #60.,WAIT1      : 60 FRAMES/SEC
2351 012246 000406      BR      13$
2352
2353 012250 012737 000037 007500      12s:  MOV     #31.,YMAX        : 32 ROWS IN 625
2354 012256 012737 000062 007452      MOV     #50.,WAIT1      : 50 FRAMES/SEC
2355
2356 012264 012737 000077 007446      13s:  MOV     #63.,XMAX        : 48 VISIBLE,16 INVISIBLE CELLS.
2357 012272 012737 000001 007462      MOV     #1,PROM          : PRESET TO PROM CHAR SET.
2358 012300 032711 000400      BIT     #400,(R1)       : PROM?
2359 012304 001030      BNE     20$              : YES...
2360 012306 005037 007462      CLR     PROM            : ELSE RESET TO RAM CHAR STORE.
2361 012312 004737 014734      JSR     PC,TYPOUT        : ASK IF ENCODED FOR TV!
2362 012316 005627      SETENC
2363 012320 004737 014206      JSR     PC,READ          : GET REPLY..
2364 012324 012701 017242      MOV     #NORCH,R1        : DEFAULT TO NORMAL CHARACTER SET
2365 012330 120027 000131      CMPB   R0,#'Y           : IF YES, THEN WE ARE ENCODED.
2366 012334 001005      BNE     15$
2367 012336 012737 000001 007622      MOV     #1,PAL          : SET ENCODED (ONLY RELEVANT FOR RAM)
2368 012344 012701 021242      MOV     #PALCH,R1        : GET THIS CHAR SET
2369
2370 012350 012700 007624      15s:  MOV     #PO2CHR,R0       : GET DESTINATION.
2371 012354 012702 001000      MOV     #1000,R2         : 512 WORDS=128 CHARS.
2372
2373 012360 012120      16s:  MOV     (R1)+,(R0)+      : TRANSFER 2 BYTES.
2374 012362 005302      DEC     R2
2375 012364 001375      BNE     16$              : ANY MORE?
2376
2377 012366 004737 013776      20s:  JSR     PC,RSTREG        : RECOVER REGISTERS.
2378 012372 000207      RTS     PC
2379
2380      : THE FOLLOWING TABLE HAS AN ASCII CHACK BYTE IN EACH WORD,
2381      : TOGETHER WITH 400 IF IT IS A PROM UNIT, AND 1000 FOR 525.
2382
2383 012374 000470      DEVLST: '8+400+0000      : INTERFACE, -KA
2384 012376 001471      '9+400+1000            : -KB
2385 012400 000060      '0+000+0000            : -KC
2386 012402 001061      '1+000+1000            : -KD
  
```

VTV30K DIAGNOSTIC MACY11 30A(1052) 08-JAN-81 10:58 PAGE 37-2<sup>G</sup> 5  
CVVTC.A.SRC 08-JAN-81 10:36 SELECT 525/625

SEQ 0058

2387 012404 000462 '2+400+0000 ; -KG  
2388 012406 000000 0

2390  
2391  
2392  
2393  
2394  
2395  
2396  
2397  
2398  
2399  
2400  
2401  
2402  
2403  
2404  
2405  
2406  
2407  
2408  
2409  
2410  
2411  
2412  
2413  
2414  
2415  
2416  
2417  
2418  
2419  
2420  
2421  
2422  
2423  
2424  
2425  
2426  
2427  
2428  
2429  
2430  
2431  
2432  
2433  
2434  
2435  
2436  
2437  
2438  
2439  
2440  
2441  
2442  
2443  
2444  
2445

.SBTTL LOAD A FULL PICTURE

DESCRIPTION:

ROUTINE TO LOAD A FULL PICTURE WITH A GIVEN CHARACTER CODE, COLOUR, BLINK AND FLASH SETTING

CALLING SEQUENCE:

JSR PC.LOADFS

INPUT PARAMETERS:

FLASH,BLINK,CHAR,FORGND,BAKGND, VIDEON ARE TO AS FLASH CODE, BLINK CODE, CHARACTER CODE, FOREGROUND COLOUR, BACKGROUND COLOUR, AND THE VIDEO ON ENABLE RESPECTIVELY.

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

CARX, AND CARY ARE DESTROYED

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

```
LOADFS: JSR    PC,SAVREG      ; CLEAR OUR Y COORD
        CLR    CARY          ; AND OUR X COORD
        CLR    CARX          ; PRESET THE PICT TO THIS CHAR
        MOV    CHAR,R2       ; HIGH ORDER BYTE
        SWAB   R2            ; LOAD BLINK AND FLASH BITS
        BIS    BLINK,R2
        BJS    FLASH,R2
```

```
012410 004737 013740
012414 005037 007476
012420 005037 007474
012424 013702 007550
012430 000302
012432 053702 007470
012436 053702 007472
```

```

2446 012442 053702 007464      BIS      FORGND,R2      ; LOAD FOREGROUND COLOUR
2447 012446 013701 007466      MOV      BAKGND,R1     ; GET BACKGROUND COLOUR
2448 012452 006301              ASL      R1            ; TO CORRECT BITS
2449 012454 006301              ASL      R1
2450 012456 006301              ASL      R1
2451 012460 050102              BIS      R1,R2         ; AND LOAD INTO DATUM WORD
2452 012462 013700 007436      MOV      DEVCSR,R0     ; GET THE CSR ADDRESS
2453 012466 013701 007440      MOV      DEVBUF,R1     ; ALSO THE DATA BUFFER
2454 012472 013703 007450      MOV      VIDEON,R3     ; GET THE VIDEO ON BIT..
2455 012476 012704 004000      MOV      #4000,R4      ; PICTURE STORE COUNT
2456
2457 012502 010310              ;
2458 012504 010211              2$: MOV      R3,(R0)    ; LOAD CSR WITH ADDRESS
2459 012506 005203              MOV      R2,(R1)      ; LOAD PICTURE ELEMENT
2460 012510 005304              INC      R3            ; NEXT PICTURE ELEMENT
2461 012512 001373              DEC      R4            ; ANY MORE?
2462 012514 004737 013776      BNE     2$             ; YES...
2463 012520 000207              JSR     PC,RSTREG      ; RESTORE THE REGISTERS
                                RTS      PC                ; AND EXIT.
  
```

2465  
2466  
2467  
2468  
2469  
2470  
2471  
2472  
2473  
2474  
2475  
2476  
2477  
2478  
2479  
2480  
2481  
2482  
2483  
2484  
2485  
2486  
2487  
2488  
2489  
2490  
2491  
2492  
2493  
2494  
2495  
2496  
2497  
2498  
2499  
2500  
2501  
2502  
2503  
2504  
2505  
2506  
2507  
2508  
2509  
2510  
2511  
2512  
2513  
2514  
2515  
2516  
2517  
2518  
2519  
2520

.SBTTL LOAD A PICTURE ELEMENT

DESCRIPTION:  
ROUTINE TO LOAD A SINGLE PICTURE ELEMENT

CALLING SEQUENCE:  
JSR PC,LOELEM

INPUT PARAMETERS:  
CARY= Y POS  
CARX= X POS  
CHAR= CHAR CODE  
FORGND= FOREGROUND COLOUR  
BAKGND= BACKGROUND COLOUR  
BLINK= BLINK STATUS  
FLASH= FLASH STATUS  
VIDEON= VIDEO ENABLE STATUS  
DEVCSR= ADDRESS OF CURRENT CSR  
DEVBUF= ADDRESS OF CURRENT DBUFF

IMPLICIT INPUT PARAMETERS:  
NONE

OUTPUT PARAMETERS:  
NONE

IMPLICIT OUTPUT PARAMETERS:  
NONE

COMPLETION CODES:  
NONE

POSSIBLE ERROR CODES:  
NONE

LOELEM: JSR PC, SAVREG ; SET UP OUR SAR REGISTER  
MOV CARX,R2  
MOV CARY,R1

2521	012536	000301		SWAB	R1		; GET Y ADDRESS IN TOP BYTE
2522	012540	105001		CLRB	R1		
2523	012542	006201		ASR	R1		
2524	012544	006201		ASR	R1		; SHIFT IT DOWN
2525	012546	042701	174000	BIC	#174000,R1		; CLEAR RUBBISH
2526	012552	053701	007450	BIS	VIDEON,R1		; SET VIDEO ON
2527	012556	050102		BIS	R1,R2		; THEN SET IT UP
2528	012560	010277	174652	MOV	R2,@DEVCSR		; SET OUR X AND Y ADDRESSES
2529	012564	013702	007464	MOV	FORGND,R2		; START WITH FOREGROUND
2530	012570	013701	007466	MOV	BAKGND,R1		; GET BACKGROUND COLOUR
2531	012574	006301		ASL	R1		
2532	012576	006301		ASL	R1		; SET IT IN CORRECT POSITION
2533	012600	006301		ASL	R1		
2534	012602	050102		BIS	R1,R2		; ADD TO COMPOSITE
2535	012604	053702	007470	BIS	BLINK,R2		; SET BLINK IF REQUIRED
2536	012610	053702	007472	BIS	FLASH,R2		; AND FLASH
2537	012614	013701	007550	MOV	CHAR,R1		; GET CHARACTER
2538	012620	000301		SWAB	R1		; THE SET IN THE CORRECT POSITION
2539	012622	105001		CLRB	R1		
2540	012624	050102		BIS	R1,R2		; ADD IT IN
2541	012626	010277	174606	MOV	R2,@DEVBUF		; OUT
2542	012632	004737	013776	JSR	PC,RSTREG		
2543	012636	000207		RTS	PC		

2545  
 2546  
 2547  
 2548  
 2549  
 2550  
 2551  
 2552  
 2553  
 2554  
 2555  
 2556  
 2557  
 2558  
 2559  
 2560  
 2561  
 2562  
 2563  
 2564  
 2565  
 2566  
 2567  
 2568  
 2569  
 2570  
 2571  
 2572  
 2573  
 2574  
 2575  
 2576  
 2577  
 2578  
 2579  
 2580  
 2581  
 2582  
 2583  
 2584  
 2585  
 2586  
 2587  
 2588  
 2589  
 2590  
 2591  
 2592  
 2593  
 2594  
 2595  
 2596  
 2597  
 2598  
 2599  
 2600

```

.SBTTL 'SILLSI' SUBROUTINE

DESCRIPTION:
    ROUTINE TO ESTABLISH WHETHER OR NOT THE
    DIAGNOSTIC IS RUNNING ON A PROCESSOR
    WHICH POSSESSES ONLY ONE INTERRUPT BUS
    PRIORITY LEVEL.

CALLING SEQUENCE:
    JSR    PC,SILLSI

INPUT PARAMTERS:
    NONE

IMPLICIT INPUT PARAMETERS:
    NONE

OUTPUT PARAMETERS:
    THE VARIABLE 'LSIFLG' WILL BE SET UP TO
    REFLECT WHETHER OR NOT THE PROCESSOR HAS
    A SINGLE INTERRUPT PRIORITY LEVEL.
    LSIFLG = 0 => MULTIPLE INT. PRIORITIES
            <> 0 => SINGLE INT. PRIORITY

IMPLICIT OUTPUT PARAMETERS:
    NONE

COMPLETION CODES:
    NONE

POSSIBLE ERROR CODES:
    NONE

SILLSI: CLR    LSIFLG        ;SET UP FLAG FOR NON-LSI
        MOV    #18,4      ;INSTALL TRAP THRU 4 VECTOR
        MOV    #340,6     ;AND CORRESPONDING PRIORITY
  
```

012640 005037 012702  
 012644 012737 012670 000004  
 012652 012737 000340 000006



```

2601
2602 012660 005737 177776      :      TST      PSW      ;TRY ADDRESSING THE PSW --
2603 012664 000240              :      NOP              ;IF NOT THERE, TRAP THRU 4
2604 012666 000404              :      BR       2$      ;WILL OCCUR, ELSE BRANCH.
2605
2606 012670 022626      1$:      CMP      (SP)+,(SP)+ ;PERFORM A DUMMY RTI
2607 012672 012737 177777 012702 :      MOV      #-1,LSIFLG ;PROCESSOR HAS ONE INT.LEVEL
2608
2609 012700 000207      2$:      RTS      PC      ;RETURN TO MAINLINE CALL.
2610
2611
2612
2613 012702 000000      LSIFLG: 0      ;0 => MULTIPLE INT.PRIORITIES
2614
2615
2616
2617

```

```

;-1=> SINGLE INT. PRIORITY

```

2619  
2620  
2621  
2622  
2623  
2624  
2625  
2626  
2627  
2628  
2629  
2630  
2631  
2632  
2633  
2634  
2635  
2636  
2637  
2638  
2639  
2640  
2641  
2642  
2643  
2644  
2645  
2646  
2647  
2648  
2649  
2650  
2651  
2652  
2653  
2654  
2655  
2656  
2657  
2658  
2659  
2660  
2661  
2662  
2663  
2664  
2665  
2666  
2667  
2668  
2669  
2670  
2671  
2672

.SBTTL NON EXISTANT SWR TRAP

DESCRIPTION:

THE TRAP WHEN TESTING FOR THE HARDWARE SWITCH REGISTER WILL OCCUR HERE  
THE LOCATION SWR WILL BE SET TO CONTAIN THE ADDRESS OF THE SOFTWARE SWITCH REGISTER SSWR

ENTRY POINT

SWRSET

INPUT PARAMETERS:

OCCURS IF A HARDWARE SWITCH REGISTER IS NOT PRESENT

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

THE LOCATION SWR WILL BE SET TO CONTAIN SSWR

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

AN RTI IS PERFORMED

POSSIBLE ERROR CODES:

NONE

012704 012737 007504 007502 SWRSET: MOV #SSWR,SWR  
012712 000002 RTI

2674  
2675  
2676  
2677  
2678  
2679  
2680  
2681  
2682  
2683  
2684  
2685  
2686  
2687  
2688  
2689  
2690  
2691  
2692  
2693  
2694  
2695  
2696  
2697  
2698  
2699  
2700  
2701  
2702  
2703  
2704  
2705  
2706  
2707  
2708  
2709  
2710  
2711  
2712  
2713  
2714  
2715  
2716  
2717  
2718  
2719  
2720  
2721  
2722  
2723  
2724  
2725  
2726  
2727  
2728  
2729

.SBTTL SET UP ILLEGAL VECTOR TRAPS

DESCRIPTION:

ROUTINE TO SET CATCHES FOR TRAPS TO ILLEGAL VECTORS IN THE RANGE 0 TO 772, DURING THE RUNNING OF THE TESTS.

THE CATCH IS TO FORCE THE EXECUTION OF AN IOT TRAP.

THE VECTOR 14 (ODT VECTOR) IS LEFT FREE, 34 (TRAP VECTOR) IS SET TO THE ADDRESS TRAPSV TO SERVICE THE TRAP INSTRUCTION. THE VECTOR 20 (IOT) IS SET TO ILLVEC TO SERVICE ILLEGAL VECTOR TRAPS, AND THE ADDRESSES 200 AND 202 ARE SET WITH A JUMP TO START, THUS ALLOWING THE BE BE RESTARTED FROM ADDRESS 200. LOCATIONS 30 AND 32 AND SET TO CATCH EMT CALLS AND HENCE READ THE PROCESSOR PRIORITY.

LOCATION 40 IS LEFT FREE TO CONTAIN THE LOAD MEDIUM INDICATORS, LOCATION IS LEFT FREE TO CONTAIN THE XXDP RETURN ADDRESS (IF PRESENT). LOCATION 46 IS SET TO CONTAIN A POINTER TO THE XXDP RETURN ADDRESS AND LOCATION 52 IS SET TO ZERO.

CALLING SEQUENCE:

JSR PC,VECTOR

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

R0 AND R1 WILL BE CORRUPTED

ADDRESSES 0 THRU TO 774 WILL BE SET WITH APPROPRIATE VALUES

IMPLICIT OUTPUT PARAMETERS:

NONE

```

2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2740
2741
2742
2743
2744 012714 005000
2745 012716 012701 000002
2746 012722 020027 000014
2747 012726 001002
2748 012730 022020
2749 012732 000410
2750 012734 020027 000040
2751 012740 001002
2752 012742 022020
2753 012744 000403
2754 012746 010120
2755 012750 012720 000004
2756 012754 062701 000004
2757 012760 020027 000774
2758 012764 002756
2759 012766 012737 013326 000034
2760 012774 012737 000340 000036
2761 013002 012737 013156 000030
2762 013010 012737 000340 000032
2763 013016 012737 013226 000020
2764 013024 012737 000340 000022
2765 013032 013737 007510 000200
2766 013040 013737 007512 000202
2767 013046 012737 013142 000046
2768 013054 005037 000052
2769 013060 000207

:
:
: COMPLETION CODES:
:
: NONE
:
: POSSIBLE ERROR CODES:
:
: NONE
:
: VECTOR: CLR R0 ;FILL 0-572 WITH IOT TRAPS
: MOV #2,R1
: FILL: CMP R0,#14 ;ODT TRAP?
: BNE 1$
: CMP (R0)+,(R0)+ ;YES BUMP R0
: BR FILL1
: 1$: CMP R0,#40 ;XXDP RETURN ADDRESS
: BNE 2$ ;NO
: CMP (R0)+,(R0)+ ;YES BUMP R0
: BR FILL1
: 2$: MOV R1,(R0)+ ;'+2'
: MOV #4,(R0)+ ;'IOT'
: FILL1: ADD #4,R1
: CMP R0,#774
: BLT FILL
: MOV #TRAPSV,34 ;TRAP (LOOP CONTROL)
: MOV #340,36
: MOV #FADR,30 ; PLUG EMT FOR READING
: MOV #340,32 ; THE PROCESSOR STATUS
: MOV #ILLVEC,20 ;PLUG 20 FOR IOTS
: MOV #340,22
: MOV JM600,200 ;SET UP JMP START IN LOC 200
: MOV JM600+2,202
: MOV #SENDAD,46 ;POINT TO RETURN TO XXDP
: CLR 52 ;CLEAR 52
: RTS PC ;THEN EXIT

```

2771  
2772  
2773  
2774  
2775  
2776  
2777  
2778  
2779  
2780  
2781  
2782  
2783  
2784  
2785  
2786  
2787  
2788  
2789  
2790  
2791  
2792  
2793  
2794  
2795  
2796  
2797  
2798  
2799  
2800  
2801  
2802  
2803  
2804  
2805  
2806  
2807  
2808  
2809  
2810  
2811  
2812  
2813  
2814  
2815  
2816  
2817  
2818  
2819  
2820  
2821  
2822  
2823  
2824  
2825  
2826

.SBTTL XXDP END OF PASS HOOKS

DESCRIPTION:

ROUTINE TO SIGNIFY END OF PASS, AND IF THE PROGRAM HAS BEEN LOADED USING AN XXDP MONITOR A CALL WILL BE MADE BACK TO THE MONITOR. THE LOCATIONS USED BY XXDP ARE 40, AND 41 FOR THE LOAD MEDIUM AND 42, 43 FOR THE RETURN ADDRESS. IF A PRESELECTED TEST IS IN OPERATION THE PROGRAM WILL GO AND SELECT THAT TEST.

ENTRY POINT:

ENDIT

INPUT PARAMETERS:

LOCATION 42/43 CONTAINS THE XXDP RETURN ADDRESS

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

NONE

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

IF LOCATIONS 42/43 ARE NON ZERO THEY ARE ASSUMED TO CONTAIN THE XXDP MONITOR RETURN ADDRESS

POSSIBLE ERROR CODES:

NONE

```

2827
2828
2829 013062 012706 001000      ENDIT:  MOV  #START,SP      ; RESET THE STACK
2830 013066                                PSWSET #340                ; AND PROCESSOR PRIORITY
2831 013102 032777 000100 174372  BIT   #100,@SWR          ; IS THERE A PRESELECT ON
2832 013110 001402                                BEQ   1$                  ; NO
2833 013112 000137 001326                                JMP   START2             ; YES GO SELECT THE TEST
2834
2835                                ; NO PRESELECT ON SO SIGNAL END OF PASS
2836
2837 013116 104402      1$:   TRAP+2                ; BYPASS MESSAGE
2838 013120 001306                                START1
2839 013122 004737 014734      2$:   JSR   PC.TYPOUT        ; END OF PASS
2840 013126 006500                                PASMSG
2841 013130 013700                                MOV   @#42,R0            ; GET RETURN ADDRESS TO XXDP
2842 013134 001002                                BNE   $ENDAD             ; IF IT IS ZERO THERE IS NO
2843 013136 000137 001306                                JMP   START1             ; MONITOR SO RESTART DIAG
2844
2845
2846                                ;
2847 013142 004710      $ENDAD: JSR   PC,(R0)          ; CALLED VIA XXDP SO RETURN
2848 013144 000240                                NOP                       ; THERE
2849 013146 000240                                NOP
2850 013150 000240                                NOP                       ; ALLOW A SLIGHT PAUSE
2851 013152 000137 001306                                JMP   START1             ; THEN RESTART THE DIAGNOSTIC
2852
2853
2854

```

```
2856 .SBTTL READ PROCESSOR PRIORITY
2857
2858
2859 : DESCRIPTION:
2860 :
2861 : THIS IS THE EMT HANDLER AND IS USED TO READ
2862 : THE PROCESSOR PRIORITY OFF THE STACK AND RETURNING
2863 : IT IN FSAVPW
2864
2865 : CALLING SEQUENCE:
2866 :
2867 : CALLED BY ISSUING AN EMT
2868
2869 : INPUT PARAMETERS:
2870 :
2871 : NONE
2872
2873 : IMPLICIT INPUT PARAMETERS:
2874 :
2875 : THE LOCATIONS 30 AND 32 MUST HAVE BEEN SET
2876 : UP TO POINT TO THIS ROUTINE
2877
2878 : OUTPUT PARAMETERS:
2879 :
2880 : THE CONTENTS OF THE PROCESSOR PRIORITY
2881 : ARE RETURNED IN THE LOCATION FSAVPW
2882
2883 : COMPLETION CODES:
2884 :
2885 : NONE
2886
2887 : POSSIBLE ERROR CODES:
2888 :
2889 : NONE
2890
2891 :
2892 :
2893 :
2894 013156 016637 000002 007620 FADR: MOV 2(SP),FSAVPW ; READ PRIORITY
2895 013164 000002 ; RTI ; RETURN TO CALLER
2896 :
```

2898  
2899  
2900  
2901  
2902  
2903  
2904  
2905  
2906  
2907  
2908  
2909  
2910  
2911  
2912  
2913  
2914  
2915  
2916  
2917  
2918  
2919  
2920  
2921  
2922  
2923  
2924  
2925  
2926  
2927  
2928  
2929  
2930  
2931  
2932  
2933  
2934  
2935  
2936  
2937  
2938  
2939  
2940  
2941  
2942  
2943  
2944  
2945  
2946  
2947  
2948  
2949  
2950  
2951  
2952  
2953

.SBTTL RING TTY BELL

DESCRIPTION:

ROUTINE TO RING THE BELL ON THE CONSOLE  
 TERMINAL, IF BIT 5 IS SET IN THE SWITCH  
 REGISTER.

CALLING SEQUENCE:

JSR PC,BELL

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

THE SWITCH REGISTER MUST HAVE BEEN  
 SET UP

OUTPUT PARAMETERS:

THE TELETYPE BELL WILL BE RUNG IF  
 APPROPRIATE

IMPLICIT OUTPUT PARAMETERS

NONE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

013166	032777	000040	174306	BELL:	BIT	#40,@SWR	
013174	001401				BEQ	BELL1	
013176	000207				RTS	PC	
013200	004737	013276		BELL1:	JSR	PC,TPREDY	;WAIT FOR PRINTER READY
013204	112737	000007	177566		MOVB	#7,TPB	
013212	004737	013276			JSR	PC,TPREDY	;WAIT FOR PRINTER READY



VTV30K DIAGNOSTIC MACY11 30A(1052) 08-JAN-81 10:58 PAGE 45-1 H 6  
CVTCA.SRC 08-JAN-81 10:36 RING TTY BELL

SEQ 0072

2954	013216	112737	000000	177566	MOVB	#0,TPB	:PRINT NULL
2955	013224	000207			RTS	PC	:GO OUT

2957  
2958  
2959  
2960  
2961  
2962  
2963  
2964  
2965  
2966  
2967  
2968  
2969  
2970  
2971  
2972  
2973  
2974  
2975  
2976  
2977  
2978  
2979  
2980  
2981  
2982  
2983  
2984  
2985  
2986  
2987  
2988  
2989  
2990  
2991  
2992  
2993  
2994  
2995  
2996  
2997  
2998  
2999  
3000  
3001  
3002  
3003  
3004  
3005  
3006  
3007  
3008  
3009  
3010  
3011  
3012

.SBTTL ILLEGAL VECTOR TRAP CATCH

DESCRIPTION:

TRAPS TO ILLEGAL VECTORS WILL BE REPORTED HERE. THE VECTOR TO WHICH THE TRAP OCCURRED WILL BE PRINTED AS WELL AS THE ADDRESS IN THE MAIN LINE CODE FROM WHICH THE TRAP OCCURRED. A PROGRAM RESTART IS THEN PERFORMED, UNLESS A NEW TEST HAS BEEN SELECTED WHILE RUNNING UNDER A SOFTWARE SWITCH REGISTER.

ENTRY POINT

ILLVEC

INPUT PARAMETERS:

ENTRY IS CAUSED BY AN ILLEGAL VECTOR TRAP

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

THE VECTOR AND MAINLINE ADDRESS WILL BE PRINTED

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

A PROGRAM RESTART OR A NEW TEST SELECTION .

POSSIBLE ERROR CODES:

NONE

```

3013
3014
3015
3016
3017
3018
3019 013226 004737 014734
3020 013232 006516
3021 013234 012600
3022 013236 162700 000004
3023 013242 004737 015024
3024 013246 004737 014734
3025 013252 006550
3026 013254 005726
3027 013256 012600
3028 013260 004737 015024
3029 013264 005726
3030 013266 004737 013546
3031 013272 000137 001200

```

```

;
;
;
;A TRAP TO AN UNRECOGNISED VECTOR WILL
;BE REPORTED FROM HERE.
;
ILLVEC: JSR PC, TYP0UT
          ILVMSG
          MOV (SP)+, R0
          SUB #4, R0
          JSR PC, PROCT ;PRINT VECTOR
          JSR PC, TYP0UT
          FRMSG ;PRINT MAINLINE ADDRES
          TST (SP)+
          MOV (SP)+, R0
          JSR PC, PROCT
          TST (SP)+
          JSR PC, MONIT
          JMP RSTART

```

3033  
 3034  
 3035  
 3036  
 3037  
 3038  
 3039  
 3040  
 3041  
 3042  
 3043  
 3044  
 3045  
 3046  
 3047  
 3048  
 3049  
 3050  
 3051  
 3052  
 3053  
 3054  
 3055  
 3056  
 3057  
 3058  
 3059  
 3060  
 3061  
 3062  
 3063  
 3064  
 3065  
 3066  
 3067  
 3068  
 3069  
 3070  
 3071  
 3072  
 3073  
 3074  
 3075  
 3076  
 3077  
 3078  
 3079  
 3080  
 3081  
 3082

013276 105737 177564  
 013302 100375  
 013304 000207

```

.SBTTL WAIT FOR PRINTER READY

DESCRIPTION:
    ROUTINE TO WAIT UNTIL THE PRINTER
    ON THE CONSOLE TERMINAL IS READY,
    IE: IT IS READY TO PRINT THE NEXT
    CHARACTER.

CALLING SEQUENCE:
    JSR    PC,TPREDY

INPUT PARAMETERS:
    NONE

IMPLICIT INPUT PARAMETERS:
    NONE

OUTPUT PARAMETERS:
    NONE

IMPLICIT OUTPUT PARAMETERS:
    NONE

COMPLETION CODES:
    NONE

POSSIBLE ERROR CODES:
    NONE

TPREDY: TSTB    TPS    ;ROUTINE TO WAIT FOR PRINTER READY
        BPL     TPREDY
        RTS PC
  
```

3084  
3085  
3086  
3087  
3088  
3089  
3090  
3091  
3092  
3093  
3094  
3095  
3096  
3097  
3098  
3099  
3100  
3101  
3102  
3103  
3104  
3105  
3106  
3107  
3108  
3109  
3110  
3111  
3112  
3113  
3114  
3115  
3116  
3117  
3118  
3119  
3120  
3121  
3122  
3123  
3124  
3125  
3126  
3127  
3128  
3129  
3130  
3131  
3132  
3133  
3134  
3135  
3136  
3137  
3138  
3139

.SBTTL SET ITERATION COUNT

DESCRIPTION:

ROUTINE TO SET UP THE TEST ITERATION  
COUNT. A PROPOSED COUNT IS SET IN R4  
THEN UNLESS BIT 13 IN THE SWITCH REGISTER  
IS SET, THE SAME VALUE IS RETURNED.  
IF BIT 13 IS SET THEN FAST ITERATION IS  
ASSUMED AND A VALUE OF 1 IS RETURNED IN  
R4

CALLING SEQUENCE:

JSR PC,FASTSW

INPUT PARAMETERS:

R4 CONTAINS THE PROPOSED ITERATION  
COUNT

IMPLICIT INPUT PARAMETERS:

SETTING BIT 13 IN THE SWR WILL INDICATE  
FAST ITERATION, AND A SINGLE PASS  
WILL BE REQUESTED

OUTPUT PARAMETERS:

R4 WILL CONTAIN THE ACTUAL ITERATION  
COUNT

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

013306 032777 020000 174166 FASTSW: BIT #20000,@SWR

3140	013314	001001			BNE	1\$
3141	013316	000207			RTS	PC
3142	013320	013704	007514	1\$:	MOV	FSTCNT,R4
3143	013324	000207			RTS	PC

3145  
3146  
3147  
3148  
3149  
3150  
3151  
3152  
3153  
3154  
3155  
3156  
3157  
3158  
3159  
3160  
3161  
3162  
3163  
3164  
3165  
3166  
3167  
3168  
3169  
3170  
3171  
3172  
3173  
3174  
3175  
3176  
3177  
3178  
3179  
3180  
3181  
3182  
3183  
3184  
3185  
3186  
3187  
3188  
3189  
3190  
3191  
3192  
3193  
3194  
3195  
3196  
3197  
3198  
3199  
3200

.SBTTL TRAP SERVICE ROUTINE

DESCRIPTION:

TRAP HANDLING ROUTINE. THE TRAP HANDLER IS ENTERED UPON THE EXECUTION OF ANY TRAP INSTRUCTION. IT COMPARES THE LOWER BYTE OF THE TRAP INSTRUCTION WITH THE CONTENTS ON THE SWITCH REGISTER, AND IF A MATCH IS FOUND TAKES THE CONTENTS OF THE ADDRESS FOLLOWING THE TRAP INSTRUCTION AS THE RETURN ADDRESS.

THE EXPECTED FORMAT IS:

TRAP+N  
ADDR

WHERE ADDR IS THE ADDRESS TO PROCEED TO IF N MATCHES THE SWITCH REGISTER SETTINGS. THE TRAP ARGUMENT IS RELATED TO THE SWITCH REGISTER SETTINGS THUS:

TRAP ARG	SWR SETTING
2	200
4	400
10	1000
20	2000
30	3000
40	4000
50	5000
60	6000
70	7000

THE SETTING OF SWR BIT 12, WILL FORCE THE TRAP HANDLER TO USE THE SWR SETTINGS THAT WERE IN FORCE WHEN THE LAST TRAP INSTRUCTION WAS EXECUTED.

IF A CNTRL-G IS OUTSTANDING ON THE CONSOLE TERMINAL WHEN THE TRAP WAS EXECUTED, THEN MONIT IS CALLED. IF CNTRL-O WAS OUTSTANDING, THEN MODIFY IS CALLED

ENTRY POINT

TRAPSV

INPUT PARAMETERS:

```

3201                                     : ON EXECUTION OF ANY TRAP INSTRUCTION
3202                                     :
3203                                     :
3204                                     :
3205                                     : IMPLICIT INPUT PARAMETERS:
3206                                     :
3207                                     : THE SWR HAS BEEN SET UP
3208                                     :
3209                                     :
3210                                     : OUTPUT PARAMETERS:
3211                                     :
3212                                     : EXIT TO THE CONTENTS OF THE ADDRESS FOLLOWING
3213                                     : THE TRAP INSTRUCTION IF A MATCH WAS FOUND, ELSE THE
3214                                     : PROGRAM WILL CONTINUE FROM THE ADDRESS AFTER THAT.
3215                                     :
3216                                     :
3217                                     : IMPLICIT OUTPUT PARAMETERS:
3218                                     :
3219                                     : NONE
3220                                     :
3221                                     :
3222                                     : COMPLETION CODES:
3223                                     :
3224                                     : NONE
3225                                     :
3226                                     :
3227                                     : POSSIBLE ERROR CODES:
3228                                     :
3229                                     : NONE
3230                                     :
3231                                     :
3232                                     :
3233 013326 004737 013740 TRAPSV: JSR PC,SAVREG ;SAVE REGS
3234 013332 011600 MOV (SP),R0
3235 013334 016037 177776 007516 MOV -2(R0),TRPARG ;GET TRAP CALL
3236 013342 105737 177560 TSTB TK5 ;LOOK FOR MONITOR CALL
3237 013346 100015 BPL 3$
3238 013350 004737 014206 JSR PC,READ
3239 013354 120027 000017 CMPB R0,#17 ;IS IT CNTRL-O ?
3240 013360 001003 BNE 1$ ;NO
3241 013362 004737 015450 JSR PC,MODIFY ;YES CALL MODIFIER ROUTINE
3242 013366 000405 BR 3$
3243 013370 120027 000007 1$: CMPB R0,#7 ;IS IT CTRL-G?
3244 013374 001002 BNE 3$
3245 013376 004737 013546 JSR PC,MONIT ;YES, GO TO SWR MONITOR
3246 013402 017737 174074 007520 3$: MOV @SWR,TRPSEL
3247 013410 132737 000020 007521 BITB #20,TRPSEL+1 ;IS IT PRESERVE SCOPE
3248 013416 001012 BNE TRPSCP ;YES
3249 013420 013737 007520 007522 MOV TRPSEL,TRPMEM ;NO SO SAVE SWITCH SETTING
3250 013426 042737 170777 007522 BIC #170777,TRPMEM ;GET IT SO WE CAN COMPARE
3251 013434 132737 000016 007521 BITB #16,TRPSEL+1 ;ANY SCOPE LEVELS SET
3252 013442 001412 BEQ TRPLP ;NO
3253 013444 013700 007516 TRPSCP: MOV TRPARG,R0 ;YES
3254 013450 006000 ROR R0 ;GET TO POSITION FOR COMPARE
3255 013452 006000 ROR R0 ;FOR 10 & ABOVE
3256 013454 000300 SWAB R0 ;ONLY FOR SCOPE BITS(9-11)

```



3257	013456	042700	170777		BIC	#170777,R0	:ARGUMENT SCOPE BITS
3258	013462	020037	007522		CMP	R0,TRPMEM	:AS SELECTED ?
3259	013466	001422			BEQ	TRPBAK	:YES, GO BACK
3260	013470	013700	007520	TRPLP:	MOV	TRPSEL,R0	:NO, TEST LOOP
3261	013474	006100			ROL	R0	:FOR BITS 7&8
3262	013476	006100			ROL	R0	
3263	013500	000300			SWAB	R0	
3264	013502	142700	000371		BICB	#371,R0	:CUT OUT SW06
3265	013506	142737	000370	007516	BICB	#370,TRPARG	:ONLY SWITCHES 7 OR 8 NOW
3266	013514	130037	007516		BITB	R0,TRPARG	:ANY SELECTED ?
3267	013520	001005			BNE	TRPBAK	:YES
3268	013522	004737	013776		JSR	PC,RSTREG	
3269	013526	062716	000002		ADD	#2,(SP)	:NO SCOPE OR LOOP,SO RUN
3270	013532	000002			RTI		:PAST ARGUMENT AND RETURN
3271	013534	004737	013776	TRPBAK:	JSR	PC,RSTREG	:RESTORE REGS
3272	013540	017616	000000		MOV	@(SP),(SP)	:RETURN ADDRESS TO STACK
3273	013544	000002			RTI		:EXIT, LOOPING

3275  
3276  
3277  
3278  
3279  
3280  
3281  
3282  
3283  
3284  
3285  
3286  
3287  
3288  
3289  
3290  
3291  
3292  
3293  
3294  
3295  
3296  
3297  
3298  
3299  
3300  
3301  
3302  
3303  
3304  
3305  
3306  
3307  
3308  
3309  
3310  
3311  
3312  
3313  
3314  
3315  
3316  
3317  
3318  
3319  
3320  
3321  
3322  
3323  
3324  
3325  
3326  
3327  
3328  
3329  
3330

.SBTTL SWITCH REGISTER MONITOR

DESCRIPTION:

SWITCH REGISTER MONITOR. CALLED BY AN ERROR WITH SWR BIT 15 CLEAR, OR BY TYPING CTRL-G ON THE CONSOLE TELETYPE. IF USING HARDWARE SWR, SIMPLY ASKS FOR CTRL-C TO CONTINUE. OTHERWISE, IT PRINTS THE CURRENT CONTENTS OF THE SOFTWARE SWITCH REGISTER, FOLLOWED BY A PROMPT (>). THE NEW SWITCH REGISTER SETTINGS SHOULD THEN BE ENTERED AS AN OCTAL NUMBER, TERMINATED BY CARRIAGE RETURN. TYPING CARRIAGE RETURN ALONE WILL CAUSE THE SWITCH REGISTER CONTENTS TO REMAIN UNCHANGED. IF THE SWITCH REGISTER IS UPDATED TO SELECT A TEST (BIT 6 SET) THE NEW TEST WILL BE ENTERED IMMEDIATELY.

CALLING SEQUENCE:

JSR PC,MONIT

INPUT PARAMETERS:

BY TYPING CNTRL-G DURING THE RUNNING OF THE TESTS.

IMPLICIT INPUT PARAMETERS:

THE SOFTWARE SWITCH REGISTER, IF BEING USED MUST HAVE BEEN SET UP.

OUTPUT PARAMETERS:

IF RUNNING UNDER SOFTWARE SWITCH REGISTER MODE A NEW SETTING OF THE SWR COULD HAVE BEEN SET UP.

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

```

3331
3332
3333
3334 013546 010046
3335 013550 023727 007502 177570
3336 013556 001430
3337 013560 004737 014734
3338 013564 006623
3339 013566 013700 007504
3340 013572 004737 015024
3341 013576 012700 000076
3342 013602 004737 015012
3343 013606 004737 014034
3344 013612 005737 007532
3345 013616 001413
3346 013620 010037 007504
3347 013624 032737 000100 007504
3348 013632 001405
3349 013634 000137 001326
3350 013640 004737 013656
3351 013644 000775
3352 013646 004737 014700
3353 013652 012600
3354 013654 000207

:
:
:
MONIT: MOV RO, -(SP) ;SAVE RO
        CMP SWR, #HSWR ;HARDWARE SWR?
        BEQ MONITA ;IF YES, GO TO END
        JSR PC, TYPCTC ;SWR=
        SWRMSG
        MOV SSWR, RO
        JSR PC, PROCT
        MOV #76, RO
        JSR PC, PCHR ;PRINT '>'
        JSR PC, OCTIN ;GET NEW SETTING
        TST RAND ;ANY INPUT?
        BEQ MONITX
        MOV RO, SSWR ;YES UPDATE SSWR
        BIT #100, SSWR ;TEST SELECTED?
        BEQ MONITX
        JMP START2 ;YES GO DO IT
MONITA: JSR PC, TYPCTC ;CTRL-C TO CONTINUE
        BR MONITA
MONITX: JSR PC, CRLF
        MOV (SP)+, RO ;RESTORE RO
        RTS PC
  
```

3356  
3357  
3358  
3359  
3360  
3361  
3362  
3363  
3364  
3365  
3366  
3367  
3368  
3369  
3370  
3371  
3372  
3373  
3374  
3375  
3376  
3377  
3378  
3379  
3380  
3381  
3382  
3383  
3384  
3385  
3386  
3387  
3388  
3389  
3390  
3391  
3392  
3393  
3394  
3395  
3396  
3397  
3398  
3399  
3400  
3401  
3402  
3403  
3404  
3405  
3406  
3407  
3408  
3409  
3410  
3411

.SBTTL WAIT FOR CNTRL-C

DESCRIPTION:

ROUTINE TO WAIT FOR THE USER TO TYPE  
CNTRL-C ON THE CONSOLE. IF CNTRL-O IS HIT MODIFY  
IS CALLED, AND IF CNTRL-G IS HIT MONIT IS CALLED.

IF NONE OF THESE ARE HIT, THE ROUTINE WILL RETURN  
TO THE NEXT LOCATION AFTER THE CALL. IF CNTRL-C WAS  
HIT THE ROUTINE WILL RETURN TO THE NEXT LOCATION+2.

CALLING SEQUENCE:

JSR PC,TYPCTC

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

INPUT IS REQUESTED FROM THE CONSOLE

OUTPUT PARAMETERS:

R0 IS CORRUPTED

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

A RETURN TO THE FIRST OR SECOND LOCATION AFTER  
THE CALL IS PERFORMED.

POSSIBLE ERROR CODES:

NONE

013656 004737 014734  
013662 006570  
013664 004737 014206  
013670 020027 000003  
013674 001005

TYPCTC: JSR PC,TYPOUT ;PRINTS TYPE CTRL/C WHEN READY  
REDMES  
JSR PC,READ ;CTRL/C ENTERED  
CMP R0,#3  
BNE QEXIT2 ;NO

3412	013676	004737	014700		JSR	PC,CRLF	
3413	013702	062716	000002		ADD	#2,(SP)	;YES SO JUMP OVER NO FIND RETURN
3414	013706	000207		QEXIT1:	RTS	PC	;GO BACK
3415	013710	020027	000017	QEXIT2:	CMP	RO,#17	;CNTRL-O ?
3416	013714	001003			BNE	QEXIT3	;NO
3417	013716	004737	015450		JSR	PC,MODIFY	;YES CALL MODIFY PROGRAM
3418	013722	000755			BR	TYPCTC	;THEN GO BACK TO START
3419	013724	020027	000007	QEXIT3:	CMP	RO,#7	;CTRL-G?
3420	013730	001366			BNE	QEXIT1	
3421	013732	004737	013546		JSR	PC,MONIT	;GO TO SWR MONITOR
3422	013736	000747			BR	TYPCTC	;LOOK FOR CTRL-C AGAIN
3423							
3424							

3426  
3427  
3428  
3429  
3430  
3431  
3432  
3433  
3434  
3435  
3436  
3437  
3438  
3439  
3440  
3441  
3442  
3443  
3444  
3445  
3446  
3447  
3448  
3449  
3450  
3451  
3452  
3453  
3454  
3455  
3456  
3457  
3458  
3459  
3460  
3461  
3462  
3463  
3464  
3465  
3466  
3467  
3468  
3469  
3470  
3471  
3472  
3473  
3474  
3475  
3476  
3477  
3478  
3479  
3480  
3481

.SBTTL SAVE REGISTERS

DESCRIPTION:

ROUTINE TO SAVE ALL THE GENERAL PURPOSE  
REGISTERS ON THE STACK, AND LEAVE THE ADDRESS OF THE  
CALLING ROUTINE ON THE STACK. THE ROUTINE WILL RUN AT  
PRIORITY 7 TO AVOID ANY INTERRUPTS

CALLING SEQUENCE:

JSR PC,SAVREG

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

REGISTERS 0 THRU 5 ARE SAVED ON THE STACK  
AND THE RETURN ADDRESS OF THE CALLING ROUTINE IS  
SET AS THE LAST ENTRY ON THE STACK

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

SAVREG: MOV (SP)+,SAVPC ;SAVE PC FOR RETURN FROM THIS ROUTINE  
MOV (SP)+,SAVPC1  
MOV R5,-(SP)  
MOV R4,-(SP)  
MOV R3,-(SP)

013740 012637 007524  
013744 012637 007526  
013750 010546  
013752 010446  
013754 010346

```
3482 013756 010246      MOV    R2,-(SP)
3483 013760 010146      MOV    R1,-(SP)
3484 013762 010046      MOV    R0,-(SP)
3485 013764 013746 007526  MOV    SAVPC,-(SP)
3486 013770 013746 007524  MOV    SAVPC,-(SP)      ;PUT PC READY FOR
3487 013774 000207      RTS    PC                ;RETURN
3488
3489
3490
```

3492  
3493  
3494  
3495  
3496  
3497  
3498  
3499  
3500  
3501  
3502  
3503  
3504  
3505  
3506  
3507  
3508  
3509  
3510  
3511  
3512  
3513  
3514  
3515  
3516  
3517  
3518  
3519  
3520  
3521  
3522  
3523  
3524  
3525  
3526  
3527  
3528  
3529  
3530  
3531  
3532  
3533  
3534  
3535  
3536  
3537  
3538  
3539  
3540  
3541  
3542  
3543  
3544  
3545  
3546  
3547

013776 012637 007524  
 014002 012637 007526  
 014006 012600  
 014010 012601  
 014012 012602  
 014014 012603  
 014016 012604  
 014020 012605  
 014022 013746 007526  
 014026 013746 007524

```

.SBTTL RESTORE REGISTERS

DESCRIPTION:
    RESTORE TO RESTORE THE GENERAL PURPOSE
    REGISTERS. THE STACK IS LEFT IN THE SAME STATE AS IT
    WAS WHEN SAVREG WAS CALLED.

CALLING SEQUENCE:
    JSR    PC,RSTREG

INPUT PARAMETERS:
    NONE

IMPLICIT INPUT PARAMETERS:
    NONE

OUTPUT PARAMETERS:
    R0 THRU R5 RESTORED

IMPLICIT OUTPUT PARAMETERS:
    NONE

COMPLETION CODES:
    NONE

POSSIBLE ERROR CODES:
    NONE

RSTREG: MOV    (SP)+,SAVPC
        MOV    (SP)+,SAVPC1
        MOV    (SP)+,R0
        MOV    (SP)+,R1
        MOV    (SP)+,R2
        MOV    (SP)+,R3
        MOV    (SP)+,R4
        MOV    (SP)+,R5
        MOV    SAVPC1,-(SP)
        MOV    SAVPC,-(SP)    ;PUT PC READY FOR
  
```



VTV30K DIAGNOSTIC  
CVVICA.SRC 08-JAN-81 10:36  
MACY11 30A(1052) 08-JAN-81 10:58  
RESTORE REGISTERS  
3548 014032 000207  
RTS PC ;RETURN

PAGE 53-1<sup>K 7</sup>

SEQ 0088

L

3550  
3551  
3552  
3553  
3554  
3555  
3556  
3557  
3558  
3559  
3560  
3561  
3562  
3563  
3564  
3565  
3566  
3567  
3568  
3569  
3570  
3571  
3572  
3573  
3574  
3575  
3576  
3577  
3578  
3579  
3580  
3581  
3582  
3583  
3584  
3585  
3586  
3587  
3588  
3589  
3590  
3591  
3592  
3593  
3594  
3595  
3596  
3597  
3598  
3599  
3600  
3601  
3602  
3603  
3604  
3605

.SBTTL ENTER AN OCTAL NUMBER

DESCRIPTION:

ROUTINE TO ENTER AN OCTAL NUMBER ON THE CONSOLE.  
THE NUMBER ENTERED IS RETURNED IN R0, AND THE VALUE RAND  
IS SET TO NON ZERO IF ANY CHARACTERS WERE ENTERED.  
TYPING CARRIAGE RETURN, LINE FEED OR ESCAPE WILL  
TERMINATE THE LINE BEING ENTERED.  
RUBOUT WILL DELETE THE LAST CHARACTER ENTERED,  
CNTRL-U WILL RUBOUT THE WHOLE LINE, AND CNTRL-R  
WILL TYPE OUT THE CHARACTERS SO FAR ENTERED.  
RAND WILL BE SET TO NON ZERO IF ANY CHARACTERS  
WERE HIT AND RANDC WILL CONTAIN THE TERMINATING  
CHARACTER.

A '!' WILL BE PRINTED IF AN OVERFLOW CONDITION IS  
DETECTED AND A '?' IF AN INVALID CHARACTER WAS  
ENTERED.

CALLING SEQUENCE:

JSR PC,OCTIN

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

R0 CONTAINS THE NUMBER ENTERED.  
RAND=0 IF NO CHARACTERS WERE ENTERED.

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

```

3606
3607
3608
3609 014034 004737 013740
3610 014040 005000
3611 014042 005037 007532
3612 014046 012737 007256 007604
3613 014054 012737 000006 007606
3614 014062 012737 000060 007610
3615 014070 012737 000067 007612
3616 014076 005037 007602
3617 014102 004737 014232
3618 014106 013701 007606
3619 014112 001420
3620 014114 012702 007256
3621 014120 112203
3622 014122 162703 000060
3623 014126 000241
3624 014130 006300
3625 014132 103417
3626 014134 006300
3627 014136 103415
3628 014140 006300
3629 014142 050300
3630 014144 005237 007532
3631 014150 005301
3632 014152 001362
3633 014154 010037 007530
3634 014160 004737 013776
3635 014164 013700 007530
3636 014170 000207
3637 014172 012700 000041
3638 014176 004737 015012
3639 014202 000137 014040
3640

```

```

:
:
:
OCTIN: JSR PC,SAVREG ;SAVE THE REGISTERS
TYPOTB: CLR R0 ;CLEAR R0
CLR RAND ;CLEAR FLAG WORD
MOV #OCTMSG,STRADD ; SET START ADDRESS OF STRING
MOV #6,STRLEN ; AND ITS SIZE
MOV #60,LOWCHR ; MINIMUM CHAR
MOV #67,UPPCHR ; MAXIMUM CHAR
CLR CNVFLG ; DON'T CONVERT TO UPPER CASE
JSR PC,GETSTR ; GET A STRING
MOV STRLEN,R1 ; ZERO LENGTH?
BEQ TYPOTD ; YES
MOV #OCTMSG,R2 ; NO GET START ADDRES OF STRING
TYPOTC: MOVB (R2)+,R3 ; GET A CHARACTER
SUB #60,R3 ; PUT IN RANGE
CLC
ASL R0 ; SHIFT OUT RESULT
BCS TYPOTE ; C BIT SET ERROR
ASL R0 ; TIMES 4
BCS TYPOTE ; C BIT ERROR
ASL R0 ; TIMES 8
BIS R3,R0 ; SET NEW BITS IN
INC RAND ; SET GOOD
DEC R1
BNE TYPOTC ; LOOP IF MORE TO COME
TYPOTD: MOV R0,TYPOTA ; SAVE FINAL NUMBER
JSR PC,RSTREG ; RESTORE REGISTERS
MOV TYPOTA,R0 ; GET RESULT
RTS PC
TYPOTE: MOV #41,R0 ; OVERFLOW
JSR PC,PCHR ; PRINT A !
JMP TYPOTB ; THEN GO AGAIN
:

```

3642  
 3643  
 3644  
 3645  
 3646  
 3647  
 3648  
 3649  
 3650  
 3651  
 3652  
 3653  
 3654  
 3655  
 3656  
 3657  
 3658  
 3659  
 3660  
 3661  
 3662  
 3663  
 3664  
 3665  
 3666  
 3667  
 3668  
 3669  
 3670  
 3671  
 3672  
 3673  
 3674  
 3675  
 3676  
 3677  
 3678  
 3679  
 3680  
 3681  
 3682  
 3683  
 3684  
 3685  
 3686  
 3687  
 3688  
 3689  
 3690  
 3691  
 3692  
 3693

014206 105737 177560  
 014212 100375  
 014214 013700 177562  
 014220 042700 177600  
 014224 004737 015012  
 014230 000207

.SBTTL READ A SINGLE CHARACTER

DESCRIPTION:

ROUTINE TO READ A SINGLE CHARACTER FROM THE CONSOLE. THE CHARACTER IS RETURN IN R0 AND HAS THE 200 BIT STRIPPED OFF.

CALLING SEQUENCE:

JSR PC,READ

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

R0 CONTAINS THE CHARACTER READ IN.

IMPLICIT OUTPUT PARAMETERS:

THE CHARACTER IS ECHOED ON THE TERMINAL

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

READ: TSTB TKS  
 BPL READ  
 MOV TKB,R0  
 BIC #177600,R0  
 JSR PC,PCHR  
 RTS PC

3695  
3696  
3697  
3698  
3699  
3700  
3701  
3702  
3703  
3704  
3705  
3706  
3707  
3708  
3709  
3710  
3711  
3712  
3713  
3714  
3715  
3716  
3717  
3718  
3719  
3720  
3721  
3722  
3723  
3724  
3725  
3726  
3727  
3728  
3729  
3730  
3731  
3732  
3733  
3734  
3735  
3736  
3737  
3738  
3739  
3740  
3741  
3742  
3743  
3744  
3745  
3746  
3747  
3748  
3749  
3750

.SBTTL ENTERING A CHARACTER STRING

DESCRIPTION:

ROUTINE TO ENTER A STRING OF CHARACTERS ON THE CONSOLE TERMINAL. VARIOUS CONTROL CODES ARE USED TO CONTROL HOW THE CHARACTERS ARE INTERPTED:

ESCAPE, CARRIAGE RETURN AND LINE FEED ARE USED TO TERMINATE THE STRING. RUBOUT WILL DELETE THE LAST CHARACTER ENTERED, CNTRL-U WILL DELETE THE ALL THE CHARACTERS ENTERED, AND CNTRL-R WILL ECHO THOSE CHARACTERS ALREADY ENTERED.

ON ENTRY THE FOLLOWING POINTERS ARE USED:  
STRADD TO INDICATE THE START OF THE CHARACTER STRING  
STLEN TO INDICATE ITS SIZE  
CNVFLG SET TO CONVERT LOWER CASE TO UPPER CASE  
UPPCHR TO INDICATE THE HIGHEST CHARACTER CODE  
LOWCHR TO INDICATE THE LOWEST CHARACTER CODE

ON EXIT THE LOCATION STLEN WILL INDICATE THE NUMBER OF CHARACTERS ENTERED AND RANDC WILL CONTAIN THE TERMINATING CHARACTER

IF AN INVALID CHARACTER WAS HIT A '?' IS PRINTED

CALLING SEQUENCE:

JSR PC,GETSTR

INPUT PARAMETERS:

STRADD THE START ADDRESS OF THE STRING  
STLEN THE NUMBER OF CHARACTERS TO READ  
UPPCHR THE HIGHEST CHARACTER CODE ALLOWED  
LOWCHR THE LOWEST CHARACTER CODE ALLOWED  
CNVFLG TO INDICATE LOWER TO UPPER CASE CONVERSION

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

STLEN THE NUMBERS OF CHARACTERS READ  
RANDC THE TERMINATING CHARACTER

```

3751
3752
3753
3754
3755
3756
3757
3758
3759
3760
3761
3762
3763
3764
3765
3766
3767
3768
3769
3770
3771 014232 004737 015740
3772 014236 005037 007614
3773 014242 013702 007604
3774 014246 005001
3775 014250 105737 177560
3776 014254 100375
3777 014256 013700 177562
3778 014262 042700 177600
3779
3780
3781
3782 014266 020027 000015
3783 014272 001002
3784 014274 000137 014656
3785 014300 020027 000012
3786 014304 001002
3787 014306 000137 014656
3788 014312 020027 000033
3789 014316 001002
3790 014320 000137 014656
3791 014324 020027 000177
3792 014330 001002
3793 014332 000137 014504
3794 014336 020027 000022
3795 014342 001002
3796 014344 000137 014602
3797 014350 020027 000025
3798 014354 001002
3799 014356 000137 014552
3800
3801
3802
3803
3804
3805 014362 020027 000140
3806 014366 002405

```

```

: IMPLICIT OUTPUT PARAMETERS:
:
: NONE
:
: COMPELETION CODES:
:
: NONE
:
: POSSIBLE ERROR CONDITIONS:
:
: A '?' IS PRINTED IF AN INVALID CHARACTER IS ENTERED
:
:
: GETSTR: JSR PC, SAVREG ; SAVE REGISTERS
: GETCH1: CLR RUBFLG ; CLEAR RUBOUT FLAG
: MOV STRADD, R2 ; GET STARTING POINTER
: CLR R1 ; SET INTITAL LENGTH
: GETCH2: TSTB TKS ; ANY TTY INPUT
: BPL GETCH2 ; NO WAIT FOR IT
: MOV TKB, R0 ; GET CHARACTER
: BIC #177600, R0 ; CLEAR RUBBISH
:
: CHECK FOR CONTROL CODES
:
: CMP R0, #15 ; WAS IT <CR> ?
: BNE 1$ ; NO
: JMP CHRFIN
: 1$: CMP R0, #12 ; WAS IT <LF>
: BNE 3$ ; NO
: JMP CHRFIN
: 3$: CMP R0, #33 ; WAS IT <ESC>
: BNE 5$ ; NO
: JMP CHRFIN
: 5$: CMP R0, #177 ; RUBOUT ?
: BNE 7$ ; NO
: JMP RUBCHR ; YES
: 7$: CMP R0, #22 ; CNTRL-R
: BNE 9$ ; NO
: JMP LINECH ; YES EXCO LINE
: 9$: CMP R0, #25 ; CNTRL-U
: BNE GETCH3 ; NO
: JMP LINDEL ; YES DELETE LINE
:
: IT WAS NOT A CONTROL CODE CHECK
: FOR LEGALITY ?
:
: GETCH3: CMP R0, #140 ; IS IT LOWER CASE
: BLT 3$ ; NO

```

```

3807 014370 005737 007602          TST      CNVFLG          ; YES DO WE CONVERT TO UPPER
3808 014374 001402                   BEQ      3$             ; NO
3809 014376 042700 000040          BIC      #40,R0         ; YES STRIP 40 OFF
3810 014402 020037 007610          3$:     CMP      R0,LOWCHR ; IS THE CHAR TOO SMALL
3811 014406 002002                   BGE      5$             ; NO
3812 014410 000137 014636          JMP      ILLCHR         ; YES
3813 014414 020037 007612          5$:     CMP      R0,UPPCHR ; IS THE CHAR TOO BIG ?
3814 014420 003402                   BLE      GETCH4         ; NO
3815 014422 000137 014636          JMP      ILLCHR         ; YES ITS ILLEGAL
3816                                     ;
3817                                     ; WE HAVE A LEGAL CHARACTER
3818                                     ;
3819 014426 010003                   GETCH4: MOV     R0,R3     ; SAVE CHAR
3820 014430 005737 007614          TST      RUBFLG        ; IS RUBOUT SET
3821 014434 001406                   BEQ      3$             ; NO
3822 014436 012700 000057          MOV      #57,R0        ; YES PRINT A '/'
3823 014442 004737 015012          JSR      PC,PCHR       ;
3824 014446 005037 007614          CLR      RUBFLG        ; CLEAR RUBOUT FLAG
3825 014452 005201                   3$:     INC      R1       ; UPDATE CHAR COUNT
3826 014454 020137 007606          CMP      R1,STLEN      ; END OF STRING SEEN
3827 014460 003403                   BLE      5$             ; NO
3828 014462 005000                   CLR      R0             ; YES, FORCE A NULL TERMINATOR
3829 014464 000137 014656          JMP      CHRFIN         ; AND COMPLETE
3830 014470 010300                   5$:     MOV      R3,R0   ; RESTORE CHAR
3831 014472 004737 015012          JSR      PC,PCHR       ; ECHO IT
3832 014476 110022                   MOVB    R0,(R2)+       ; SAVE IT IN BUFFER
3833 014500 000137 014250          JMP      GETCH2        ; NO GET NEXT ONE
3834                                     ;
3835                                     ; RUBOUT WAS HIT
3836                                     ;
3837 014504 005701                   RUBCHR: TST     R1       ; ANY CHARACTERS TO RUBOUT
3838 014506 001002                   BNE      3$             ; YES
3839 014510 000137 014572          JMP      LINDL1         ; NO
3840 014514 005737 007614          3$:     TST     RUBFLG   ; IS RUBOUT SET ALREADY ?
3841 014520 001006                   BNE      5$             ; YES
3842 014522 012700 000057          MOV      #57,R0        ; NO PRINT A '/'
3843 014526 004737 015012          JSR      PC,PCHR       ;
3844 014532 005237 007614          INC      RUBFLG        ; SET RUBOUT
3845 014536 114200                   5$:     MOVB    -(R2),R0 ; GET LAST CHAR ENTERED
3846 014540 004737 015012          JSR      PC,PCHR       ; PRINT IT
3847 014544 005301                   DEC      R1             ; REDUCE COUNT
3848 014546 000137 014250          JMP      GETCH2        ; GET ANOTHER CHAR
3849                                     ;
3850                                     ; RUBOUT LINE WAS HIT
3851                                     ;
3852 014552 012700 000136                   LINDEL: MOV     #136,R0  ; PRINT A ^
3853 014556 004737 015012          JSR      PC,PCHR       ;
3854 014562 012700 000125                   MOV      #125,R0       ; THEN U
3855 014566 004737 015012          JSR      PC,PCHR       ;
3856 014572 004737 014700                   LINDL1: JSR     PC,CRLF  ; START ON A NEWLINE
3857 014576 000137 014236          JMP      GETCH1        ; A GO BACK TO BEGINNING
3858                                     ;
3859                                     ; CNTRL-R WAS HIT
3860                                     ;
3861 014602 112712 000100                   LINECH: MOVB   #'@,(R2) ; PUT IN A TERMINATOR
3862 014606 004737 014700          JSR      PC,CRLF      ; START ON A NEW LINE

```

```

3863 014612 013737 007604 014630      MOV    STRADD,3$      ; SET START ADDRESS
3864 014620 005037 007614              CLR    RUBFLG        ; CLEAR RUBOUTS
3865 014624 004737 01473'             JSR    PC,TYPDUT     ; PRINT LINE
3866 014630 000000              3$:  0
3867 014632 000137 014250             JMP    GETCH2        ; AND GET ANOTHER CHAR
3868
3869      ; ILLEGAL CHARACTER ENTERED
3870
3871 014636 004737 015012             ILLCHR: JSR PC,PCHR   ; ECHO IT
3872 014642 012700 000077             MOV    #'?,R0       ; PRINT A ?
3873 014646 004737 015012             JSR    PC,PCHR
3874 014652 000137 014602             JMP    LINECH        ; THE ECHO LINE
3875
3876      ; A TERMINATOR WAS FOUND
3877
3878 014656 010037 007616             CHRFIN: MOV R0,RANDC ; SAVE TERMINATOR
3879 014662 163702 007604             SUB    STRADD,R2    ; CALCULATE BYTE COUNT
3880 014666 010237 007606             MOV    R2,STRLEN    ; SET IT FOR RETURN
3881 014672 004737 013776             JSR    PC,RSTREG    ; RESTORE REGISTERS
3882 014676 000207              RTS    PC            ; AND EXIT
  
```



3884  
3885  
3886  
3887  
3888  
3889  
3890  
3891  
3892  
3893  
3894  
3895  
3896  
3897  
3898  
3899  
3900  
3901  
3902  
3903  
3904  
3905  
3906  
3907  
3908  
3909  
3910  
3911  
3912  
3913  
3914  
3915  
3916  
3917  
3918  
3919  
3920  
3921  
3922  
3923  
3924  
3925  
3926  
3927  
3928  
3929  
3930  
3931  
3932  
3933  
3934  
3935  
3936  
3937  
3938  
3939

.SBTTL CARRIAGE RETURN LINE FEED

DESCRIPTION:

ROUTINE TO DO A <CR> <LF> ON THE  
CONSOLE TERMINAL

CALLING SEQUENCE:

JSR PC,CRLF

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

NONE

IMPLICIT OUTPUT PARAMETERS:

THE CARRIAGE WILL BE PLACED ON A NEW LINE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

```
CRLF:  MOV    R0,-(SP)
      MOV    #15,R0          ;PRINT A RETURN - LINE FEED
      JSR    PC,PCHR
      CLR    R0              ;DUMMY
      JSR    PC,PCHR
      MOV    #12,R0
      JSR    PC,PCHR
      MOV    (SP)+,R0
      RTS    PC
```

```
014700 010046
014702 012700 000015
014706 004737 015012
014712 005000
014714 004737 015012
014720 012700 000012
014724 004737 015012
014730 012600
014732 000207
```

VTV30K DIAGNOSTIC      MACY11 30A(1052) 08-JAN-81 10:58 PAGE 57-1<sup>G</sup> 8  
CVVTC.A.SRC      08-JAN-81 10:36      CARRIAGE RETURN LINE FEED

SEQ 0097

3940

3942  
3943  
3944  
3945  
3946  
3947  
3948  
3949  
3950  
3951  
3952  
3953  
3954  
3955  
3956  
3957  
3958  
3959  
3960  
3961  
3962  
3963  
3964  
3965  
3966  
3967  
3968  
3969  
3970  
3971  
3972  
3973  
3974  
3975  
3976  
3977  
3978  
3979  
3980  
3981  
3982  
3983  
3984  
3985  
3986  
3987  
3988  
3989  
3990  
3991  
3992  
3993  
3994  
3995  
3996  
3997

.SBTTL PRINT AN ASCII MESSAGE

DESCRIPTION:

ROUTINE TO PRINT A STRING OF ASCII  
CHARACTERS ON THE CONSOLE TERMINAL. CERTAIN  
CHARACTERS WITHIN THE STRING ARE INTERPRETED  
AS CONTROL CODES, THESE ARE:

133 (I) WILL GENERATE A <CR>,<LF>  
100 (a) WILL SIGNIFY END OF MESSAGE

THE ADDRESS OF THE MESSAGE STRING TO BE PRINTED  
WILL BE HELD IN THE LOCATION FOLLOWING THE CALL  
TO THE ROUTINE, IE:

JSR PC,TYPOUT  
ADDR

CALLING SEQUENCE:

JSR PC,TYPOUT

INPUT PARAMETERS:

THE ADDRESS OF THE MESSAGE STRING FOLLOWS  
THE SUBROUTINE CALL.

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

NONE

IMPLICIT OUTPUT PARAMETERS:

THE SPECIFIED MESSAGE WILL BE PRINTED

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

3998				:		
3999				:		
4000				:		
4001	014734	004737	013740	TYPOUT:	JSR	PC, SAVREG ;SAVE REGS
4002	014740	017601	000000		MOV	@(SP), R1 ;R1 POINTS AT STRING
4003	014744	062716	000002		ADD	#2, (SP) ;JUMPS OVER ARGUMENT
4004	014750	111100		PMSG1:	MOVB	@R1, R0 ;PRINT THE MESSAGE POINTED
4005	014752	022700	000100		CMP	#100, R0 ;TO BY R1 UNTIL @, WHICH IS END.
4006	014756	001412			BEQ	PMSG4 ;[ MEANS CR-LF
4007	014760	022700	000133		CMP	#133, R0
4008	014764	001003			BNE	PMSG2
4009	014766	004737	014700		JSR	PC, CRLF
4010	014772	000402			BR	PMSG3
4011	014774	004737	015012	PMSG2:	JSR	PC, PCHR
4012	015000	005201		PMSG3:	INC	R1
4013	015002	000762			BR	PMSG1
4014	015004	004737	013776	PMSG4:	JSR	PC, RSTREG ;RESTORE REGS
4015	015010	000207			RTS	PC

4017  
 4018  
 4019  
 4020  
 4021  
 4022  
 4023  
 4024  
 4025  
 4026  
 4027  
 4028  
 4029  
 4030  
 4031  
 4032  
 4033  
 4034  
 4035  
 4036  
 4037  
 4038  
 4039  
 4040  
 4041  
 4042  
 4043  
 4044  
 4045  
 4046  
 4047  
 4048  
 4049  
 4050  
 4051  
 4052  
 4053  
 4054  
 4055  
 4056  
 4057  
 4058  
 4059  
 4060  
 4061  
 4062  
 4063  
 4064

```

.SBTTL PRINT A CHARACTER

DESCRIPTION:
    ROUTINE TO PRINT A CHARACTER ON THE
    CONSOLE. R0 CONTAINS THE CHARACTER TO BE PRINTED

CALLING SEQUENCE:
    JSR    PC,PCHR

INPUT PARAMETERS:
    R0 CONTAINS THE CHARACTER TO BE PRINTED

IMPLICIT INPUT PARAMETERS:
    NONE

OUTPUT PARAMETERS:
    NONE

IMPLICIT OUTPUT PARAMETERS:
    THE CHARACTER SELECTED WILL BE PRINTED

COMPLETION CODES:
    NONE

POSSIBLE ERROR CODES:
    NONE

PCHR:  JSR    PC,TPREDY    ;PRINTER READY
        MOV    R0,TPB
        RTS    PC
  
```

015012 004737 013276  
 015016 010037 177566  
 015022 000207

4066  
4067  
4068  
4069  
4070  
4071  
4072  
4073  
4074  
4075  
4076  
4077  
4078  
4079  
4080  
4081  
4082  
4083  
4084  
4085  
4086  
4087  
4088  
4089  
4090  
4091  
4092  
4093  
4094  
4095  
4096  
4097  
4098  
4099  
4100  
4101  
4102  
4103  
4104  
4105  
4106  
4107  
4108  
4109  
4110  
4111  
4112  
4113  
4114  
4115  
4116  
4117  
4118  
4119  
4120  
4121

015024 004737 013740  
 015030 012701 007230  
 015034 112721 000040  
 015040 020127 007236  
 015044 001373  
 015046 000241  
 015050 010002  
 015052 042702 177770  
 015056 062702 000060

```

.SBTTL PRINT AN OCTAL NUMBER

DESCRIPTION:
    ROUTINE TO PRINT AN OCTAL NUMBER ON
    THE CONSOLE TERMINAL. R0 CONTAINS THE BINARY
    REPRESENTATION ON THE NUMBER THAT IS TO BE
    PRINTED.

CALLING SEQUENCE:
    JSR    PC,PROCT

INPUT PARAMETERS:
    R0 CONTAINS THE NUMBER THAT IS TO BE
    PRINTED

IMPLICIT INPUT PARAMETERS:
    NONE

OUTPUT PARAMETERS:
    NONE

IMPLICIT OUTPUT PARAMETERS:
    THE NUMBER SPECIFIED WILL BE PRINTED

COMPLETION CODES:
    NONE

POSSIBLE ERROR CODES:
    NONE

PROCT:  JSR    PC,SAVREG      ;SAVE REGS
        MOV    #OCTNUM,R1   ;POINTER TO MESSAGE
PROCT1: MOVB   #40,(R1)+    ;FILL WITH SPACES
        CMP   R1,#OCTNUM+6 ;ALL DONE
        BNE   PROCT1       ;NO
PROCT1A: CLC                ;CLEAR AT START
PROCT2: MOV   R0,R2        ;SAVE CHARA
        BIC   #177770,R2   ;CLEAR ALL BUT BOTTOM 3 BITS
        ADD   #60,R2       ;NOW ASCII
  
```



4146  
4147  
4148  
4149  
4150  
4151  
4152  
4153  
4154  
4155  
4156  
4157  
4158  
4159  
4160  
4161  
4162  
4163  
4164  
4165  
4166  
4167  
4168  
4169  
4170  
4171  
4172  
4173  
4174  
4175  
4176  
4177  
4178  
4179  
4180  
4181  
4182  
4183  
4184  
4185  
4186  
4187  
4188  
4189  
4190  
4191  
4192  
4193  
4194  
4195  
4196  
4197  
4198  
4199  
4200  
4201

015150 004737 013740  
015154 005000  
015156 005037 007532

.SBTTL ENTER A DECIMAL NUMBER

DESCRIPTION:

ROUTINE TO ENTER A DECIMAL NUMBER ON THE CONSOLE TERMINAL. R0 WILL CONTAIN THE NUMBER ENTERED AS A BINARY VALUE. RAND WILL BE NON ZERO IF ANY CHARACTERS WERE READ IN. THE INCOMING STRING CAN BE TERMINATED BY <CR>, <LF> OR <ESC>. TYPING CNTRL-U WILL DELETE ALL CHARACTERS ENTERED, CNTRL-R WILL ECHO THE CHARACTERS ENTERED AND RUBOUT WILL DELETE THE LAST CHARACTER ENTERED

CALLING SEQUENCE:

JSR PC,TYPDEC

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

R0 CONTAINS THE BINARY REPRESENTATION OF THE DECIMAL NUMBER ENTERED, AND RAND WILL INDICATE WHETHER ANY CHARACTERS HAVE BEEN ENTERED.

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

TYPDEC: JSR PC,SAVREG ;SAVE REGISTERS  
TPDEC1: CLR R0  
CLR RAND ;CLEAR INDICATOR



VTV30K DIAGNOSTIC  
CVV7CA.SRC 08-JAN-81

MACY11 30A(1052)  
10:36

08-JAN-81 10:58 PAGE 61-1  
ENTER A DECIMAL NUMBER

SEQ 0104

```

4202 015162 012737 007250 007604      MOV      #DECMSG,STRADD  : SET START ADDRESS
4203 015170 012737 000005 007606      MOV      #5,STRLEN      : ONLY 5 CHARS
4204 015176 012737 000060 007610      MOV      #60,LOWCHR     : MINIMUM CHAR
4205 015204 012737 000071 007612      MOV      #71,UPPCHR     : MAXIMUM CHAR
4206 015212 005037 007602          CLR      CNVFLG         : DON'T CONVERT TO UPPER
4207 015216 004737 014232          JSR      PC,GETSTR      : GET A STRING
4208 015222 013704 007606      MOV      STRLEN,R4      : GET LENGHT READ IN
4209 015226 001433          BEQ      TPDEC5         : ZERO MEANS COMLPETE
4210 015230 012702 007250      MOV      #DECMSG,R2     : POINT TO STRING
4211 015234 112201          TPDEC2: MOVB           (R2)+,R1      : GET A CHARACTER
4212 015236 000241          CLC                          :
4213 015240 006300          ASL      R0              : RESULT TIMES 2
4214 015242 103413          BCS      TPDEC3         : C BIT SET MEANS ERROR
4215 015244 010003          MOV      R0,R3          : ASVE IT
4216 015246 006300          ASL      R0              : TIMES 4
4217 015250 103410          BCS      TPDEC3         : C BIT MEANS ERROR
4218 015252 006300          ASL      R0              : TIMES 8
4219 015254 103406          BCS      TPDEC3         : C BIT MEANS OVERFLOW
4220 015256 060300          ADD      R3,R0          : ADD IN TO BE TIMES 12
4221 015260 103404          BCS      TPDEC3         : C BIT MEANS ERROR
4222 015262 042701 177760      BIC      #177760,R1     : CLEAR UNWANTED BITS
4223 015266 060100          ADD      R1,R0          : ADD IN NEW VALUE
4224 015270 103006          BCC      TPDEC4         : C BIT
4225 015272 012700 000041      TPDEC3: MOV      #41,R0  : OVERFLOW PRINT A !
4226 015276 004737 015012          JSR      PC,PCHR        :
4227 015302 000137 015154          JMP      TPDEC1         :
4228 015306 005237 007532          TPDEC4: INC      RAND    : AND GO BAK TO START
4229 015312 005304          DEC      R4              : SET CHAR SEEN
4230 015314 001347          BNE      TPDEC2         : REDUCE COUNT
4231 015316 010037 007534      TPDEC5: MOV      R0,TYPD1 : NON ZERO MEANS MORE
4232 015322 004737 013776          JSR      PC,RSTREG     : ALL DONE SAVE RESULT
4233 015326 013700 007534          MOV      TYPD1,R0      : RESTORE REGISTERS
4234 015332 000207          RTS      PC             : RESTORE RESULT
4235          :                      : AND EXIT

```

```

4237          .SBTTL PRINT A DECIMAL NUMBER
4238
4239
4240
4241          DESCRIPTION:
4242             ROUTINE TO PRINT A SIGNED OR UNSIGNED
4243             DECIMAL NUMBER ON THE CONSOLE. R0 HOLDS THE
4244             NUMBER TO BE PRINTED.
4245
4246          CALLING SEQUENCE:
4247             JSR      PC,BASE10      ; FOR UNSIGNED
4248             JSR      PC,BASM10     ; FOR SIGNED
4249
4250          INPUT PARAMETERS:
4251             R0 HOLDS THE NUMBER TO BE PRINTED
4252
4253          IMPLICIT INPUT PARAMETERS:
4254             NONE.
4255
4256          OUTPUT PARAMETERS:
4257             NONE
4258
4259          IMPLICIT OUTPUT PARAMETERS:
4260             THE NUMBER IN R0 IS PRINTED.
4261
4262          COMPLETION CODES:
4263             NONE
4264
4265          POSSIBLE ERROR CODES:
4266             NONE
4267
4268          015334 005700          BASM10: TST      R0          ; GET SIGN OF R0
4269          015336 100005          BPL      BASE10     ; POSITIVE..
4270          015340 005400          NEG      R0          ; IF MINUS,MAKE POSITIVE..
4271          015342 112737 000055 007240  MOVB    #55,BASE11 ; AND PRINT '-'
4272          015350 000403          BR       BAS10A     ; THEN CONTINUE..
4273
4274          015352 112737 000040 007240  BASE10: MOVB    #' ,BASE11 ; PRINT LEADING SPACE
4275
4276          015360 004737 013740          BAS10A: JSR      PC,SAVREG ; NOW SAVE OLD REGS..
4277          015364 012703 007241          MOV     #BASE11+1,R3 ; SETUP OUTPUT POINTER..
4278          015370 112723 000040          BASE1A: MOVB    #' ,(R3)+ ; PRELOAD STRING WITH SPACES.
4279          015374 022703 007246          CMP     #BASE11+6,R3 ; ALL DONE?
4280          015400 001373          BNE     BASE1A     ; NO..
4281
4282          015402 005001          BASE1D: CLR     R1          ; R1 IS RECEIVER...
4283
4284          015404 020027 000012          BASE1B: CMP     R0,#12     ; MORE THAN 10?
4285          015410 103404          BLO     BASE1C     ; YES IF BRANCH
4286          015412 162700 000012          SUB     #12,R0     ; DIV BY REPEAT SUB
4287          015416 005201          INC     R1          ; TALLY COUNT
4288          015420 000771          BR     BASE1B     ; DO NEXT
4289
4290          015422 062700 000060          BASE1C: ADD     #'0,R0     ; MAKE INTO NUMBER
4291          015426 110043          MOVB   R0,-(R3)    ; SAVE IN STRING
4292          015430 010100          MOV     R1,R0

```

4293	015432	001363		BNE	BASE1D	
4294	015434	004737	013776	JSR	PC,RSTREG	: RESTORE REGISTERS..
4295	015440	004737	014734	JSR	PC,TYPOUT	: TYPE MESSAGE
4296	015444	007240		BASE11		: THIS ONE...
4297	015446	000207		RTS	PC	: AND EXIT

4299  
4300  
4301  
4302  
4303  
4304  
4305  
4306  
4307  
4308  
4309  
4310  
4311  
4312  
4313  
4314  
4315  
4316  
4317  
4318  
4319  
4320  
4321  
4322  
4323  
4324  
4325  
4326  
4327  
4328  
4329  
4330  
4331  
4332  
4333  
4334  
4335  
4336  
4337  
4338  
4339  
4340  
4341  
4342  
4343  
4344  
4345  
4346  
4347  
4348  
4349  
4350  
4351  
4352  
4353  
4354

.SBTTL MODIFY THE PROGRAM

DESCRIPTION:

ROUTINE TO MODIFY A LOCATION IN MEMORY  
ENTERED BY TYPING CNTRL-O ON THE CONSOLE  
TERMINAL.

PROMPTS (\$) FOR AN ADDRESS TO EXAMINE  
AND PRINTS IT IN THE FORM

ADDR CONTENTS /

THEN A NEW VALUE CAN BE ENTERED

VIS:

ADDR CONTENTS / NEW VALUE

THE NEW VALUE CAN BE TERMINATED USING  
<CR>, <LF>, OR <ESC>

<LF> TO EXAMINE THE NEXT LOC  
<CR> TO SELECT ANOTHER ADDRESS  
<ESC> TO EXIT

CALLING SEQUENCE:

JSR PC,MODIFY

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

ENTERED BY TYPING CNTRL-O DURING  
THE RUNNING OF THE TESTS

OUTPUT PARAMETERS:

NONE

```

4355
4356
4357
4358
4359
4360
4361
4362
4363
4364
4365
4366
4367
4368
4369
4370
4371
4372 015450 004737 013740
4373 015454
4374 015464
4375 015500 004737 014734
4376 015504 006635
4377 015506 004737 014034
4378 015512 005737 007532
4379 015516 001506
4380 015520 010037 007536
4381 015524 032737 000C01 007536
4382 015532 001404
4383 015534 004737 014734
4384 015540 006707
4385 015542 000756
4386 015544 012737 016354 000004
4387 015552 012737 000340 000006
4388 015560 005037 007544
4389 015564 005777 171746
4390 015570 005737 007544
4391 015574 001341
4392 015576 004737 014700
4393 015602 013700 007536
4394 015606 004737 015024
4395 015612 012700 000040
4396 015616 004737 015012
4397 015622 017700 171710
4398 015626 004737 015024
4399 015632 004737 014734
4400 015636 006642
4401 015640 004737 014034
4402 015644 005737 007532
4403 015650 001402
4404 015652 010077 171660
4405 015656 013700 007616
4406 015662 001706
4407 015664 020027 000015
4408 015670 001703
4409 015672 020027 000012
4410 015676 001006

```

.....  
 IMPLICIT OUTPUT PARAMETERS:  
 THE LOCATIONS SPECIFIED WILL HAVE BEEN  
 MODIFIED  
 .....  
 COMPLETION CODES:  
 NONE  
 .....  
 POSSIBLE ERROR CODES:  
 NONE  
 .....

```

MODIFY: JSR PC,SAVREG ;SAVE REGISTERS
        PSWREA MODSAV
        PSWSET #340
MODI1: JSR PC,TYPOUT ;PROMPT $ FOR AN ADDRESS
        MODADM ;TO HAVE A LOOK AT
        JSR PC,OCTIN ;READ REPLY
        TST RAND ;ANYTHING READ ?
        BEQ MODXIT ;NO, SO EXIT
        MOV R0,MODADR ;ELSE SAVE OUR ADDRESS
007536 MODI2: BIT #1,MODADR ;IS IT EVEN ?
        BEQ MODI3 ;YES WE CAN USE IT
        JSR PC,TYPOUT ;ELSE SAY IT IS AN ODD
        ODAMSG ;ADDRESS, AND REPROMPT
        BR MODI1
000004 MODI3: MOV #NXTTRP,4 ;PLUG TRAP THRU 4
000006 MOV #340,6 ;FOR NDM TESTS
        CLR TRPERR ;CLEAR NDM FLAG
        TST @MODADR ;TEST OUR ADDRESS
        TST TRPERR ;DOES IT EXIST
        BNE MODI1 ;NO TRY AGAIN
        JSR PC,CRLF ;START ON A NEW LINE
        MOV MODADR,R0 ;PRINT OUR ADDRESS
        JSR PC,PROCT
        MOV #40,R0 ;THEN A SPACE
        JSR PC,PCHR ;AS A SEPARATOR
        MOV @MODADR,R0 ;THEN PRINT THE CONTENTS
        JSR PC,PROCT
        JSR PC,TYPOUT ;PROMPT FOR THE NEW
        MODSPA ;CONTENTS '/'
        JSR PC,OCTIN ;READ REPLY
        TST RAND ;ANY THING GIVEN
        BEQ MODI4 ;NO, DON'T UPDATE
        MOV R0,@MODADR ;ELSE SET NEW VALUE
MODI4: MOV RANDC,R0 ; GET TERMINATOR
        BEQ MODI1 ; NULL MEANS <CR>
        CMP R0,#15 ;WAS IT <CR> ?
        BEQ MODI1 ;YES GET NEXT ADDRESS
        CMP R0,#12 ;WAS IT <LF> ?
        BNE MODI5 ;NO

```

```

4411 015700 004737 014700          JSR    PC,CRLF          ; NEWLINE
4412 015704 062737 000002 007536  ADD    #2,MODADR       ; UPDATE THE ADDRESS BY 2
4413 015712 000704          BR     MOD12           ; THEN TRY THIS ADDRESS
4414 015714 020027 000033  MOD15: CMP    R0,#33        ; WAS IT EXIT ?
4415 015720 001405          BEQ   MODXIT          ; YES DISSAPPEAR
4416 015722 012700 000077          MOV   #77,R0         ; ELSE GIVE A ?
4417 015726 004737 015012          JSR   PC,PCHR        ; AS AN ERROR
4418 015732 000751          BR    MOD14          ; THEN TRY AGAIN
4419 015734 012737 000006 000004 MODXIT: MOV   #6,4       ; PLUG BACK TRAP THRU 4
4420 015742 012737 000004 000006  MOV   #4,6           ; WITH WHAT IS WAS
4421 015750 004737 014700          JSR   PC,CRLF        ; PUT OURSELVES ON A NEW LINE
4422 015754          PSWSET MODSAV
4423 015770 004737 013776          JSR   PC,RSTREG     ; RESTORE REGISTERS
4424 015774 000207          RTS    PC            ; AND GO AWAY
4425

```

4427  
4428  
4429  
4430  
4431  
4432  
4433  
4434  
4435  
4436  
4437  
4438  
4439  
4440  
4441  
4442  
4443  
4444  
4445  
4446  
4447  
4448  
4449  
4450  
4451  
4452  
4453  
4454  
4455  
4456  
4457  
4458  
4459  
4460  
4461  
4462  
4463  
4464  
4465  
4466  
4467  
4468  
4469  
4470  
4471  
4472  
4473  
4474  
4475  
4476  
4477  
4478  
4479  
4480  
4481  
4482

.SBTTL SELECT BUS ADDRESSES

DESCRIPTION:

THIS ROUTINE PROMPTS THE OPERATOR FOR THE BUS ADDRESS OF THE FIRST VTV30K ON THE SYSTEM, AND ALSO THE NUMBER OF DEVICES THAT ARE ON THE SYSTEM. THE PROGRAM WILL ALLOW UP TO TWENTY (DECIMAL) DEVICES TO BE SELECTED, HOWEVER THE DEVICES MUST BE CONFIGURED IN ASCENDING ORDER. FOR EXAMPLE: THE FIRST DEVICE WOULD BE AT 1XXX00, 1XXX02, THEN THE SECOND ONE WOULD BE AT 1XXX10, AND 1XXX12, ETC.

CALLING SEQUENCE:

JSR PC,SELBUS

INPUT PARAMETERS:

NONE

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

THE ADDRESSES OF THE CSR AND DATA BUFFERS SELECTED WILL BE LOADED INTO LOCATIONS FOLLOWING THE ADDRESS 'CSRO'. THE LOCATION 'DEVcnt' IS SET TO SAY HOW MANY DEVICES WERE SELECTED.

IMPLICIT OUTPUT PARAMETERS:

EACH OF THE ADDRESSES SELECTED ARE TESTED FOR NXM, AND AN ERROR REPORT IS GENERATED IF THE SELECTED ADDRESS REPORTS AS NXM. ERROR 77 FOR A NON EXISTANT CSR AND 76 FOR THE DATA BUFFER.

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

ERROR 77 WILL OCCUR IF A SELECTED CSR IS NOT ON THE BUS. ERROR 76 WILL OCCUR FOR A NON EXISTANT DATA BUFFER ADDRESS. SETTING TRAP+10 WILL LOOP ON THIS ADDRESS.

```

4483
4484 015776 005037 007454      SELBUS: CLR      TESTNO
4485 016002 004737 013740      JSR      PC,SAVREG      ; SAVE REGISTERS
4486 016006 012737 016354 000004  MOV      #NXTMRP,4      ; PLUG TRAP THRU 4
4487 016014 012737 000340 000006  MOV      #340,6
4488 016022 004737 014734      1$: JSR      PC,TYPOUT      ; ASK FOR NUMBER OF DEVICES
4489 016026 005660      NUMDEV
4490 016030 004737 015150      JSR      PC,TYPDEC      ; READ DECIMAL REPLY
4491 016034 005737 007532      TST      RAND          ; NULL REPLY MEANS 1
4492 016040 001002      BNE      2$
4493 016042 012700 000001      MOV      #1,R0
4494 016046 020027 000024      2$: CMP      R0,#20.      ; IS THE NUMBER TOO BIG ?
4495 016052 003363      BGT      1$            ; YES
4496 016054 005700      TST      R0            ; OR TOO SMALL
4497 016056 003761      BLE      1$            ; OOPS, REPROMPT
4498 016060 010037 007304      MOV      R0,DEV CNT    ; ELSE SAVE COUNT AWAY
4499 016064 023727 007304 000001  CMP      DEV CNT,#1    ; ONE DEVICE SELECTED
4500 016072 001406      BEQ      BUSSE1        ; YES
4501 016074 004737 014734      JSR      PC,TYPOUT
4502 016100 006144      GOMST
4503 016102 004737 013656      3$: JSR      PC,TYPCTC    ; NO- ALL DEVICES MUST BE
4504 016106 000775      BR       3$            ; SEQUENTIAL
4505
4506      ; NOW GET OUR FIRST ADDRESS
4507
4508 016110 004737 014734      BUSSE1: JSR      PC,TYPOUT      ; FIRST BUS ADDRESS =
4509 016114 006653      BMSG
4510 016116 004737 014034      1$: JSR      PC,OCTIN      ; READ OCTAL REPLY
4511 016122 005737 007532      TST      RAND          ; DON'T ALLOW DEFAULTS
4512 016126 001004      BNE      2$
4513 016130 004737 014734      JSR      PC,TYPOUT
4514 016134 006762      NODEFM
4515 016136 000767      BR       1$
4516 016140 032700 000005      2$: BIT      #5,R0        ; THESE BITS CLEAR
4517 016144 001406      BEQ      3$            ; YES
4518 016146 004737 014734      4$: JSR      PC,TYPOUT
4519 016152 006707      ODMSG
4520 016154 004737 015024      JSR      PC,PROCT
4521 016160 000753      BR       BUSSE1
4522 016162 032700 100000      3$: BIT      #100000,R0    ; IT MUST BE ON THE IO PAGE
4523 016166 001767      BEQ      4$
4524 016170 010037 007542      BUSSE2: MOV      R0,BASADD    ; SAVE START ADDRESS
4525 016174 013701 007304      MOV      DEV CNT,R1    ; GET DEVICE COUNT
4526 016200 012702 007306      MOV      #CSR0,R2     ; AND WHERE DATA GOES
4527 016204 013737 007542 007566  MOV      BASADD,DATA
4528 016212 005037 007544      1$: CLR      TRPERR      ; CLEAR NXM FLAG
4529 016216 005777 171344      TST      @DATA        ; CHECKIT
4530 016222 005737 007544      TST      TRPERR      ; OK ?
4531 016226 001411      BEQ      2$            ; YES
4532
4533      ; ERROR-
4534      ; CHECK 'LEVB CLOCK H'
4535      ; 'LEVB VA02 H'
4536      ; BUS CYCLE TIMING ON LEVA.
4537 016230 013737 007566 007572  MOV      DATA,ADDRES
4538 016236 004737 016666      JSR      PC,ERROR      ; NO- THIS IS NAUGHTY

```



```

4539 016242 020077          77+A
4540 016244 104410        TRAP+10
4541 016246 016212          1$
4542 016250 000717        BR      BUSSE
4543 016252 013722 007566 2$:  MOV    DATA,(R2)+      ; SAVE DATA AWAY
4544 016256 062737 000002 007566  ADD    #2,DATA          ; POINT TO DBUFF ADDRESS
4545 016264 005037 007544 3$:  CLR    TRPERR          ; CLEAR NXM FLAG
4546 016270 005777 171272  TST   @DATA            ; CHECK FOR NXM
4547 016274 005737 007544  TST   TRPERR           ; IS IT ?
4548 016300 001403        BEQ    4$                ; NO- ALL IS WELL
4549
4550      ; ERROR-
4551      ; CHECK E4 ON LEVA
4552      ; BUS CYCLE TIMING ON LEVA
4552 016302 004737 016666  JSR    PC,ERROR          ; OOPS- NAUGHTY
4553 016306 040076
4554 016310 104410        76+D
4554 016310 104410        4$:  TRAP+10          ; LOOP ON
4555 016312 016264          3$
4556 016314 013722 007566  MOV    DATA,(R2)+      ; SAVE DBUFF ADDRESS
4557 016320 062737 000006 007566  ADD    #6,DATA          ; POINT TO NEXT CSR
4558 016326 005301        DEC    R1                ; ALL CSRS DONE
4559 016330 001330        BNE   1$                ; NO
4560 016332 012737 000006 000004  MOV    #6,4             ; RESET TRAP POINTERS
4561 016340 012737 000004 000006  MOV    #4,6             ; WITH THE IOT TRAP
4562 016346 004737 013776  JSR    PC,RSTREG
4563 016352 000207        RTS    PC
4564

```

VTV30K DIAGNOSTIC MACY11 30A(1052) 08-JAN-61 10:58 PAGE 65<sup>J</sup> 9  
CVVTC.A.SRC 08-JAN-81 10:36 SELECT BUS ADDRESSES

SEQ 0113

4566	016354	004737	014734	NXMTRP: JSR	PC, TYP OUT
4567	016360	006732		NXMSG	
4568	016362	005237	007544	INC	TRPERR
4569	016366	000002		RTI	

4571  
4572  
4573  
4574  
4575  
4576  
4577  
4578  
4579  
4580  
4581  
4582  
4583  
4584  
4585  
4586  
4587  
4588  
4589  
4590  
4591  
4592  
4593  
4594  
4595  
4596  
4597  
4598  
4599  
4600  
4601  
4602  
4603  
4604  
4605  
4606  
4607  
4608  
4609  
4610  
4611  
4612  
4613  
4614  
4615  
4616  
4617  
4618  
4619  
4620  
4621  
4622  
4623  
4624  
4625  
4626

.SBTTL NUMBER GENERATOR

DESCRIPTION:

ROUTINE TO GENERATE DATA PATTERNS,  
THE TYPE OF PATTERN IS SELECTED BY R3, AND THE  
PATTERN GENERATED IS RETURNED IN R0 AND LOCATION  
GOOD.

CALLING SEQUENCE:

JSR PC,GENER

INPUT PARAMETERS:

R3 CONTAINS THE PATTERN NUMBER

R3=0	ALL ZEROES
1	ALL ONES
2	010101 ETC BIT PATTERN
3	101010 ETC BIT PATTERN
4	ROTATING 1 IN A ZERO WORD
5	ROTATING 0 IN AN ALL ONE WORD
6	PSEUDO RANDOM NUMBER
7	INCREMENTING DATA PATTERN, GOOD CONTAINS THE VALUE TO BE UPDATED

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

THE NUMBER GENERATED IS HELD IN  
R0 AND GOOD.

IMPLICIT OUTPUT PARAMETERS:

NONE

COMPLETION CODES:

NONE

POSSIBLE ERROR CODES:

NONE

```

4627
4628
4629
4630 016370 042703 177770
4631 016374 004737 013740
4632 016400 006303
4633 016402 000173 016406
4634 016406 016426
4635 016410 016432
4636 016412 016440
4637 016414 016446
4638 016416 016454
4639 016420 016464
4640 016422 016522
4641 016424 016642
4642 016426 005000
4643 016430 000507
4644 016432 005000
4645 016434 005100
4646 016436 000504
4647 016440 012700 052525
4648 016444 000501
4649 016446 012700 125252
4650 016452 000476
4651 016454 000241
4652 016456 004737 016476
4653 016462 000472
4654 016464 000241
4655 016466 004737 016476
4656 016472 005100
4657 016474 000465
4658 016476 006037 016520
4659 016502 001003
4660 016504 012737 100000 016520
4661 016512 013700 016520
4662 016516 000207
4663 016520 000001
4664 016522 012737 000005 007554
4665 016530 004737 016542
4666 016534 013700 007552
4667 016540 000443
4668 016542 013702 007552
4669 016546 001002
4670 016550 013702 007560
4671 016554 032737 000777 007554
4672 016562 001003
4673 016564 012737 000001 007554
4674 016572 013703 007554
4675 016576 013702 007552
4676 016602 033702 007556
4677 016606 001405
4678 016610 005102
4679 016612 033702 007556
4680 016616 001401
4681 016620 000402
4682 016622 000241

:
:
:
GENER: BIC #177770,R3
JSR PC,SAVRÉG
ASL R3
JMP @GENSEL(R3)
GENSEL: GEN0 ;ALL ZERO WORD
GEN1 ;ALL ONE WORD
GEN52 ;52 PATTERN
GEN25 ;25 PATTERN
GENR1 ;ROTATE '1' EACH CALL
GENRO ;ROTATE '0' EACH CALL
GENRAN ;RANDOM NUMBER
GENINC ;INCREMENTING COUNT
GENO: CLR R0 ;0>R0
BR GENEX
GEN1: CLR R0 ;NOT0>R0
COM R0
@R GENEX
GEN52: MOV #52525,R0 ;5252>R0
BR GENEX
GEN25: MOV #125252,R0 ;125252>R0
BR GENEX
GENR1: CLC
JSR PC,GENROT ;SHIFT 1 > R0
BR GENEX
GENRO: CLC
JSR PC,GENROT ;SHIFT 0 > R0
COM R0
BR GENEX
GENROT: ROR GENISH ;ROTATE 1 PATTERN
BNE GENER1 ;= 0?
MOV #100000,GENISH ;YES, SET MSB
MOV GENISH,R0 ;PUT 1 IN R0
RTS PC ;AND EXIT
GENISH: 1
GENRAN: MOV #5,RANSEL ;SET SELECT VALUE TO 5
JSR PC,RANGEN ;GENERATE RANDOM NUMBER IN R0
MOV RANDN,R0
BR GENEX
RANGEN: MOV RANDN,R2
BNE RAN1 ;IS RANDOM = 0
MOV RANST,R2 ;YES, PUT RANDOM START VALUE IN
BIT #777,RANSEL ;NO: IS RANSEL SELECT VALUE = 0
BNE RAN2 ;NO
MOV #1,RANSEL ;YES: SET RANSEL = 1
RAN2: MOV RANSEL,R3
MOV RANDN,R2
BIT RANSTA,R2 ;GET R2 <0 AND 1>
BEQ RANCLC
COM R2
BIT RANSTA,R2
BEQ RANCLC
BR RANSEC
RANCLC: CLC

```

4683	016624	000401		BR	RAN4	
4684	016626	000261		.ANSEC: SEC		
4685	016630	006037	007552	RAN4: ROR	RANDN	:ROTATE C TO B15
4686	016634	005303		DEC	R3	:IS THIS NUMBER REQUIRED?
4687	016636	001357		BNE	RAN2+4	:NO, GET ANOTHER
4688	016640	000207		RTS	PC	:YES, EXIT
4689	016642	013700	007562	GENINC: MOV	GOOD,R0	:INCREMENTS LOC. 'GOOD'
4690	016646	005200		INC	R0	
4691	016650	010037	007562	GENEX: MOV	R0,GOOD	
4692	016654	010066	000002	MOV	R0,2(SP)	:LOAD R0 MAINROUTINE
4693	016660	004737	013776	JSR	PC,RSTREG	
4694	016664	000207		RTS	PC	

4696  
4697  
4698  
4699  
4700  
4701  
4702  
4703  
4704  
4705  
4706  
4707  
4708  
4709  
4710  
4711  
4712  
4713  
4714  
4715  
4716  
4717  
4718  
4719  
4720  
4721  
4722  
4723  
4724  
4725  
4726  
4727  
4728  
4729  
4730  
4731  
4732  
4733  
4734  
4735  
4736  
4737  
4738  
4739  
4740  
4741  
4742  
4743  
4744  
4745  
4746  
4747  
4748  
4749  
4750  
4751

.SBTTL PRINT ERROR MESSAGES

DESCRIPTION:

ROUTINE TO PRINT ERROR MESSAGES  
 IF BIT 14 IN THE SWR IS SET NO MESSAGES WILL BE  
 PRINTED, IF BIT 15 IS SET THE PROGRAM WILL NO WAIT  
 AFTER AN ERROR HAS BEEN PRINTED. IT IS CALLED THUS:

JSR PC,ERROR  
 ARG

WHERE ARG CONTAINS THE ERROR CODE AND IS OF THE FORM  
 X+N, WHERE N IS THE ERROR NUMBER IN THE RANGE 0-177  
 AND X IS A COMBINATION OF FLAGS THAT INDICATE WHAT  
 VALUES ARE TO BE PRINTED. THESE VALUES SHOULD BE LOADED  
 BEFORE THE ERROR ROUTINE IS CALLED AND ARE DEFINED  
 AS FOLLOWS:

FLAG SETTING	NUMBER	LOCATION	MESSAGE
C	4000	CALLPC	CALLED FROM
S	10000	STATUS	STATUS
A	20000	ADDRES	ADDRESS
D	40000	DATA	DATA
G	100000	GOOD, BAD	GOOD= BAD =

IN ADDITION THE ERROR NUMBER WILL BE COMBINED WITH  
 THE TEST NUMBER TO INDICATE IN WHICH TEST THE ERROR  
 OCCURRED.  
 AN ERROR COUNT IS MAINTAINED AN ON EACH ERROR THE  
 COUNT IS UPDATED. IF RUNNING UNDER A SOFTWARE SWITCH  
 REGISTER, IT IS POSSIBLE TO SELECT NEW OPTIONS

CALLING SEQUENCE:

JSR PC,ERROR

INPUT PARAMETERS:

THE LOACTION FOLLOWING THE CALL  
 CONTAINS THE ERROR CODE AND FLAG SETTINGS

IMPLICIT INPUT PARAMETERS:

NONE

OUTPUT PARAMETERS:

4752  
4753  
4754  
4755  
4756  
4757  
4758  
4759  
4760  
4761  
4762  
4763  
4764  
4765  
4766  
4767  
4768  
4769  
4770  
4771  
4772  
4773  
4774  
4775  
4776  
4777  
4778  
4779  
4780  
4781  
4782  
4783  
4784  
4785  
4786  
4787  
4788  
4789  
4790  
4791  
4792  
4793  
4794  
4795  
4796  
4797  
4798  
4799  
4800  
4801  
4802  
4803  
4804  
4805  
4806  
4807

016666 004737 013740  
 016672 012737 000001 007444  
 016700 005237 007574  
 016704 001002  
 016706 005237 007442  
 016712 032777 040000 170562 1\$:  
 016720 001133  
 016722 017637 000000 007576  
 016730 004737 014734  
 016734 007064  
 016736 013700 007454  
 016742 000300  
 016744 006300  
 016746 153700 007576  
 016752 004737 015024  
 016756 004737 014734  
 016762 007070  
 016764 011600  
 016766 004737 015024  
 016772 132737 000200 007577  
 017000 001416  
 017002 004737 014734  
 017006 007102  
 017010 013700 007562  
 017014 004737 015024  
 017020 004737 014734  
 017024 007113  
 017026 013700 007564  
 017032 004737 015024  
 017036 132737 000100 007577 ERRSV1:  
 017044 001407  
 017046 004737 014734  
 017052 007124  
 017054 013700 007566  
 017060 004737 015024

NONE  
 .....  
 IMPLICIT OUTPUT PARAMETERS:  
 .....  
 THE APPROPRAITE ERROR MESSAGE WILL BE PRINTED  
 IF PERMITTED.  
 COMPLETION CODES:  
 NONE  
 POSSIBLE ERROR CODES:  
 NONE  
 .....  
 20-FEB-80  
 ERROR: JSR PC,SAVREG  
 MOV #1,ERRFLG ; SET ERROR FLAG  
 INC ERRDIS ; INC COUNT  
 BNE 1\$ ; CHECK FOR OVERFLOW  
 INC ERRDI1 ; THEN INC OVERFLOW COUNT  
 BIT #40000,@SWR ; SUPPRESS PRINTOUT  
 BNE ERHALT ; YES  
 MOV @(SP),ERRARG ; NO  
 JSR PC,TYPOUT ; TYPE MESSAGE  
 MSG1  
 MOV TESTNO,R0  
 SWAB R0  
 ASL R0  
 BISB ERRARG,R0  
 JSR PC,PROCT  
 JSR PC,TYPOUT  
 MSG2  
 MOV (SP),R0  
 JSR PC,PROCT ;PRINT 6 DIGITS  
 BITB #200,ERRARG+1  
 BEQ ERRSV1  
 JSR PC,TYPOUT  
 MSG3  
 MOV GOOD,R0  
 JSR PC,PROCT  
 JSR PC,TYPOUT  
 MSG4  
 MOV BAD,R0  
 JSR PC,PROCT  
 BITB #100,ERRARG+1 ;D SET ?  
 BEQ ERRSV2 ;NO  
 JSR PC,TYPOUT  
 MSG5  
 MOV DATA,R0  
 JSR PC,PROCT

4808	017064	132737	000040	007577	ERRSV2:	BITB	#40,ERRARG+1	:A SET ?
4809	017072	001407				BEQ	ERRSV3	:NO
4810	017074	004737	014734			JSR	PC,TYPOUT	
4811	017100	007135				EMSG6		
4812	017102	013700	007572			MOV	ADDRES,R0	
4813	017106	004737	015024			JSR	PC,PROCT	
4814	017112	132737	000020	007577	ERRSV3:	BITB	#20,ERRARG+1	:S SET ?
4815	017120	001407				BEQ	ERRSV4	:NO
4816	017122	004737	014734			JSR	PC,TYPOUT	
4817	017126	007153				EMSG7		
4818	017130	013700	007570			MOV	STATUS,R0	
4819	017134	004737	015024			JSR	PC,PROCT	
4820	017140	132737	000010	007577	ERRSV4:	BITB	#10,ERRARG+1	:C SET
4821	017146	001407				BEQ	ERRSV5	:NO
4822	017150	004737	014734			JSR	PC,TYPOUT	
4823	017154	007166				EMSG8		
4824	017156	013700	007600			MOV	CALLPC,R0	
4825	017162	004737	015024			JSR	PC,PROCT	
4826	017166	004737	014700		ERRSV5:	JSR	PC,CRLF	
4827	017172	004737	014734			JSR	PC,TYPOUT	
4828	017176	007205				EMSG9		
4829	017200	013700	007574			MOV	ERRDIS,R0	
4830	017204	004737	015352			JSR	PC,BASE10	
4831	017210	032777	100000	170264	ERHALT:	BIT	#100000,@SWR	
4832	017216	001004				BNE	NOHALT	
4833	017220	013700	007574			MOV	ERRDIS,R0	
4834	017224	004737	013546			JSR	PC,MONIT	: GO TO SWR
4835	017230	004737	013776		NOHALT:	JSR	PC,RSTREG	
4836	017234	062716	000002			ADD	#2,(SP)	
4837	017240	000207				RTS	PC	



4839  
4840  
4841  
4842  
4843  
4844  
4845 017242 360 360 360  
4846 017252 010 010 010  
4847 017262 030 030 030  
4848 017272 074 074 074  
4849 017302 000 000 000  
4850 017312 000 000 000  
4851 017322 000 000 377  
4852 017332 010 010 010  
4853 017342 030 030 030  
4854 017352 074 074 377  
4855 017362 001 002 004  
4856 017372 200 100 040  
4857 017402 000 014 022  
4858 017412 201 102 044  
4859 017422 074 176 377  
4860 017432 030 074 176  
4861 017442 010 010 024  
4862 017452 010 010 034  
4863 017462 252 252 252  
4864 017472 314 314 314  
4865 017502 377 000 377  
4866 017512 377 377 000  
4867 017522 377 203 205  
4868 017532 377 201 201  
4869 017542 377 376 374  
4870 017552 377 177 077  
4871 017562 200 300 340  
4872 017572 001 003 007  
4873 017602 003 007 016  
4874 017612 300 340 160  
4875 017622 303 347 176  
4876 017632 000 160 120  
4877 017642 000 000 000  
4878 017652 010 010 010  
4879 017662 024 024 024  
4880 017672 024 024 066  
4881 017702 010 036 040  
4882 017712 000 062 062  
4883 017722 000 020 050  
4884 017732 000 030 030  
4885 017742 000 010 020  
4886 017752 000 010 004  
4887 017762 000 052 034  
4888 017772 000 000 010  
4889 020002 000 000 000  
4890 020012 000 000 000  
4891 020022 000 000 000  
4892 020032 000 002 002  
4893 020042 000 034 042  
4894 020052 000 010 030

.SBTTL NORMAL CHARACTER SET.  
.NLIST BEX  
:THIS IS THE VTV30K CHARACTER SET IN ITS MAIN  
:VERSION, WITH A POUND SIGN AT ADDRESS 13, & A  
:DEGREE SIGN AT ADDRESS 32.  
NORCH: .BYTE 360,360,360,360,360,360,360,360  
.BYTE 010,010,010,010,010,010,010,010  
.BYTE 030,030,030,030,030,030,030,030  
.BYTE 074,074,074,074,074,074,074,074  
.BYTE 000,000,000,000,377,000,000,000  
.BYTE 000,000,000,000,377,377,000,000  
.BYTE 000,000,377,377,377,377,000,000  
.BYTE 010,010,010,010,377,010,010,010  
.BYTE 030,030,030,377,377,030,030,030  
.BYTE 074,074,377,377,377,377,074,074 ;10  
.BYTE 001,002,004,010,020,040,100,200  
.BYTE 200,100,040,020,010,004,002,001  
.BYTE 000,014,022,040,170,040,100,176  
.BYTE 201,102,044,030,030,044,102,201  
.BYTE 074,176,377,377,377,377,176,074  
.BYTE 030,074,176,377,377,176,074,030  
.BYTE 010,010,024,042,301,042,024,010  
.BYTE 010,010,034,076,377,076,034,010  
.BYTE 252,252,252,252,252,252,252,252  
.BYTE 314,314,314,314,314,314,314,314 ;20  
.BYTE 377,000,377,000,377,000,377,000  
.BYTE 377,377,000,000,377,377,000,000  
.BYTE 377,203,205,211,221,241,301,377  
.BYTE 377,201,201,201,201,201,201,377  
.BYTE 377,376,374,370,360,340,300,200  
.BYTE 377,177,077,037,017,007,003,001  
.BYTE 200,300,340,360,370,374,376,377  
.BYTE 001,003,007,017,037,077,177,377  
.BYTE 003,007,016,034,070,160,340,300  
.BYTE 300,340,160,070,034,016,007,003 ;30  
.BYTE 303,347,176,074,074,176,347,303  
.BYTE 000,160,120,160,000,000,000,000  
.BYTE 000,000,000,000,000,000,000,000  
.BYTE 010,010,010,010,010,000,010,000  
.BYTE 024,024,024,000,000,000,000,000  
.BYTE 024,024,066,000,066,024,024,000  
.BYTE 010,036,040,034,002,074,010,000  
.BYTE 0,62,62,4,10,20,46,46  
.BYTE 0,20,50,50,20,52,44,32 ;40(')  
.BYTE 0,30,30,30,0,0,0,0  
.BYTE 0,10,20,40,40,40,20,10  
.BYTE 0,10,2,2,2,4,10  
.BYTE 0,52,34,76,34,52,0,0  
.BYTE 0,0,10,10,76,10,10,0  
.BYTE 0,0,0,0,30,30,10,20  
.BYTE 0,0,0,0,76,0,0,0  
.BYTE 0,0,0,0,0,0,30,30  
.BYTE 0,2,2,4,10,20,40,40  
.BYTE 000,034,042,046,052,062,042,034 ;50(1)  
.BYTE 000,010,030,010,010,010,010,034

4895	00062	000	034	042	.BYTE	000,034,042,002,034,040,040,076	
4896	020072	000	034	042	.BYTE	000,034,042,002,014,002,042,034	
4897	020102	000	004	014	.BYTE	000,004,014,024,044,076,004,004	
4898	020112	000	076	040	.BYTE	0,76,40,74,2,2,42,34	
4899	020122	000	014	020	.BYTE	0,14,20,40,74,42,42,34	
4900	020132	000	076	002	.BYTE	0,76,2,4,10,20,20,20	
4901	020142	000	034	042	.BYTE	0,34,42,42,34,42,42,34	
4902	020152	000	034	042	.BYTE	0,34,42,42,36,2,4,30	
4903	020162	000	000	030	.BYTE	0,0,30,30,0,30,30,0	
4904	020172	000	030	030	.BYTE	0,30,30,0,30,30,10,20	:60(:)
4905	020202	000	004	010	.BYTE	0,4,10,20,40,20,10,4	
4906	020212	000	000	000	.BYTE	0,0,0,76,0,76,0,0	
4907	020222	000	020	010	.BYTE	0,20,10,4,2,4,10,20	
4908	020232	000	030	044	.BYTE	0,30,44,4,10,10,0,10	
4909	020242	000	074	102	.BYTE	0,74,102,132,132,104,40,0	
4910	020252	000	010	024	.BYTE	0,10,24,42,42,76,42,42	
4911	020262	000	074	022	.BYTE	0,74,22,22,34,22,22,74	
4912	020272	000	034	042	.BYTE	0,34,42,40,40,40,42,34	
4913	020302	000	074	022	.BYTE	0,74,22,22,22,22,22,74	
4914	020312	000	076	040	.BYTE	0,76,40,40,70,40,40,76	:70(E)
4915	020322	000	076	040	.BYTE	0,76,40,40,70,40,40,40	
4916	020332	000	036	040	.BYTE	0,36,40,40,46,42,42,36	
4917	020342	000	042	042	.BYTE	0,42,42,42,76,42,42,42	
4918	020352	000	034	010	.BYTE	0,34,10,10,10,10,10,34	
4919	020362	000	002	002	.BYTE	0,2,2,2,2,2,42,34	
4920	020372	000	042	044	.BYTE	0,42,44,50,60,50,44,42	
4921	020402	000	040	040	.BYTE	0,40,40,40,40,40,40,76	
4922	020412	000	042	066	.BYTE	0,42,66,52,42,42,42,42	
4923	020422	000	042	062	.BYTE	0,42,62,52,46,42,42,42	
4924	020432	000	034	042	.BYTE	0,34,42,42,42,42,42,34	:80(O)
4925	020442	000	074	042	.BYTE	0,74,42,42,74,40,40,40	
4926	020452	000	034	042	.BYTE	0,34,42,42,42,52,44,32	
4927	020462	000	074	042	.BYTE	0,74,42,42,74,50,44,42	
4928	020472	000	036	040	.BYTE	0,36,40,40,34,2,2,74	
4929	020502	000	076	010	.BYTE	0,76,10,10,10,10,10,10	
4930	020512	000	042	042	.BYTE	0,42,42,42,42,42,42,34	
4931	020522	000	042	042	.BYTE	0,42,42,42,24,24,10,10	
4932	020532	000	042	042	.BYTE	0,42,42,42,42,52,66,42	
4933	020542	000	042	042	.BYTE	0,42,42,24,10,24,42,42	
4934	020552	000	042	042	.BYTE	0,42,42,24,10,10,10,10	:90(Y)
4935	020562	000	076	002	.BYTE	0,76,2,4,10,20,40,76	
4936	020572	000	070	040	.BYTE	000,070,040,040,040,040,040,070	
4937	020602	000	040	040	.BYTE	000,040,040,020,010,004,002,002	
4938	020612	000	016	002	.BYTE	000,016,002,002,002,002,002,016	
4939	020622	030	074	176	.BYTE	030,074,176,377,030,030,030,030	
4940	020632	010	014	016	.BYTE	010,014,016,377,377,016,014,010	
4941	020642	030	030	030	.BYTE	030,030,030,030,377,176,074,030	
4942	020652	020	060	160	.BYTE	020,060,160,377,377,160,060,020	
4943	020662	000	377	377	.BYTE	000,377,377,377,377,377,377,377	
4944	020672	000	000	377	.BYTE	000,000,377,377,377,377,377,377	:100
4945	020702	000	000	000	.BYTE	000,000,000,377,377,377,377,377	
4946	020712	000	000	000	.BYTE	000,000,000,000,377,377,377,377	
4947	020722	000	000	000	.BYTE	000,000,000,000,000,377,377,377	
4948	020732	000	000	000	.BYTE	000,000,000,000,000,000,377,377	
4949	020742	000	000	000	.BYTE	000,000,000,000,000,000,000,377	
4950	020752	376	376	376	.BYTE	376,376,376,376,376,376,376,376	

VTV30K DIAGNOSTIC  
CVVTC.A.SRC 08-JAN-81

MACY11 30A(1052) 10:36

08-JAN-81 10:58 PAGE 68-2  
NORMAL CHARACTER SET.

SEQ 0122

4951	020762	374	374	374	.BYTE	374,374,374,374,374,374,374,374	
4952	020772	370	370	370	.BYTE	370,370,370,370,370,370,370,370	
4953	021002	360	360	360	.BYTE	360,360,360,360,360,360,360,360	
4954	021012	340	340	340	.BYTE	340,340,340,340,340,340,340,340	:110
4955	021022	300	300	300	.BYTE	300,300,300,300,300,300,300,300	
4956	021032	200	200	200	.BYTE	200,200,200,200,200,200,200,200	
4957	021042	200	200	200	.BYTE	200,200,200,200,200,200,200,377	
4958	021052	377	001	001	.BYTE	377,001,001,001,001,001,001,001	
4959	021062	001	001	001	.BYTE	001,001,001,001,001,001,001,377	
4960	021072	377	200	200	.BYTE	377,200,200,200,200,200,200,200	
4961	021102	000	000	000	.BYTE	000,000,000,000,000,000,000,200	
4962	021112	200	000	000	.BYTE	200,000,000,000,000,000,000,000	
4963	021122	001	000	000	.BYTE	001,000,000,000,000,000,000,000	
4964	021132	000	000	000	.BYTE	000,000,000,000,000,000,000,001	:120
4965	021142	000	010	024	.BYTE	000,010,024,042,343,000,000,000	
4966	021152	010	010	030	.BYTE	010,010,030,040,100,040,030,010	
4967	021162	000	074	146	.BYTE	000,074,146,303,201,000,000,000	
4968	021172	030	060	140	.BYTE	030,060,140,100,100,140,060,030	
4969	021202	000	000	000	.BYTE	000,000,000,000,017,010,010,010	
4970	021212	010	010	010	.BYTE	010,010,010,010,370,000,000,000	
4971	021222	010	010	010	.BYTE	010,010,010,010,017,000,000,000	
4972	021232	000	000	000	.BYTE	000,000,000,000,370,010,010,010	

4974  
4975  
4976  
4977  
4978 021242 360 360 360  
4979 021252 030 030 030  
4980 021262 030 030 030  
4981 021272 074 074 074  
4982 021302 000 000 000  
4983 021312 000 000 000  
4984 021322 000 000 377  
4985 021332 030 030 030  
4986 021342 030 030 030  
4987 021352 074 074 377  
4988 021362 003 006 014  
4989 021372 200 300 140  
4990 021402 000 034 062  
4991 021412 203 306 154  
4992 021422 074 176 377  
4993 021432 030 074 176  
4994 021442 030 030 074  
4995 021452 030 030 074  
4996 021462 146 146 146  
4997 021472 314 314 314  
4998 021502 377 000 377  
4999 021512 377 377 000  
5000 021522 377 303 307  
5001 021532 377 303 303  
5002 021542 377 376 374  
5003 021552 377 377 177  
5004 021562 200 300 340  
5005 021572 003 007 017  
5006 021602 003 007 016  
5007 021612 300 340 160  
5008 021622 303 347 176  
5009 021632 000 160 120  
5010 021642 000 000 000  
5011 021652 000 030 030  
5012 021662 000 066 066  
5013 021672 066 066 167  
5014 021702 030 076 140  
5015 021712 000 146 146  
5016 021722 000 060 154  
5017 021732 000 030 030  
5018 021742 000 030 060  
5019 021752 000 030 014  
5020 021762 000 066 034  
5021 021772 000 000 030  
5022 022002 000 000 000  
5023 022012 000 000 000  
5024 022022 000 000 000  
5025 022032 000 006 006  
5026 022042 000 074 146  
5027 022052 000 030 070  
5028 022062 000 074 146  
5029 022072 000 074 146

.SBTTL T.V.-ENCODED CHARACTER SET.  
: THIS CHARACTER SET IS SPECIALLY SELECTED TO REDUCE THE  
: BANDWIDTH REQUIREMENTS FOR PAL ENCODING PURPOSES.

PALCH: .BYTE 360,360,360,360,360,360,360,360  
.BYTE 030,030,030,030,030,030,030,030  
.BYTE 030,030,030,030,030,030,030,030  
.BYTE 074,074,074,074,074,074,074,074  
.BYTE 000,000,000,000,377,000,000,000  
.BYTE 000,000,000,000,377,377,000,000  
.BYTE 000,000,377,377,377,377,000,000  
.BYTE 030,030,030,030,377,030,030,030  
.BYTE 030,030,030,377,377,030,030,030  
.BYTE 074,074,377,377,377,377,074,074 : 9  
.BYTE 003,006,014,030,060,140,300,200  
.BYTE 200,300,140,060,030,014,006,003  
.BYTE 000,034,062,060,170,060,140,176  
.BYTE 203,306,154,070,070,154,306,203  
.BYTE 074,176,377,377,377,377,176,074  
.BYTE 030,074,176,377,377,176,074,030  
.BYTE 030,030,074,146,303,146,074,030  
.BYTE 030,030,074,176,377,176,074,030  
.BYTE 146,146,146,146,146,146,146,146  
.BYTE 314,314,314,314,314,314,314,314 : 20  
.BYTE 377,000,377,000,377,000,377,000  
.BYTE 377,377,000,000,377,377,000,000  
.BYTE 377,303,307,317,333,363,343,377  
.BYTE 377,303,303,303,303,303,303,377  
.BYTE 377,376,374,370,360,340,300,200  
.BYTE 377,377,177,077,037,017,007,003  
.BYTE 200,300,340,360,370,374,376,377  
.BYTE 003,007,017,037,077,177,377,377  
.BYTE 003,007,016,034,070,160,340,300  
.BYTE 300,340,160,070,034,016,007,003  
.BYTE 303,347,176,074,074,176,347,303  
.BYTE 000,160,120,160,000,000,000,000  
.BYTE 000,000,000,000,000,000,000,000  
.BYTE 000,030,030,030,030,030,000,030  
.BYTE 000,066,066,000,000,000,000,000  
.BYTE 066,066,167,000,167,066,066,000  
.BYTE 030,076,140,074,006,076,030,000  
.BYTE 000,146,146,014,030,060,146,146  
.BYTE 000,060,154,154,060,156,154,076  
.BYTE 000,030,030,030,000,000,000,000 : 40  
.BYTE 000,030,060,140,140,140,060,030  
.BYTE 000,030,014,006,006,006,014,030  
.BYTE 000,066,034,076,034,066,000,000  
.BYTE 000,000,030,030,076,030,030,000  
.BYTE 000,000,000,000,000,030,030,060  
.BYTE 000,000,000,000,076,000,000,000  
.BYTE 000,000,000,000,000,000,030,030  
.BYTE 000,006,006,014,030,060,140,140  
.BYTE 000,074,146,146,146,146,146,074  
.BYTE 000,030,070,030,030,030,030,074 : 50  
.BYTE 000,074,146,006,036,060,140,176  
.BYTE 000,074,146,006,030,006,146,074

5030	022102	000	014	034	.BYTE 000,014,034,074,154,176,014,014
5031	022112	000	176	140	.BYTE 000,176,140,174,006,006,146,074
5032	022122	000	034	060	.BYTE 000,034,060,140,174,146,146,074
5033	022132	000	176	006	.BYTE 000,176,006,014,030,060,060,060
5034	022142	000	074	146	.BYTE 000,074,146,146,030,146,146,074
5035	022152	000	074	146	.BYTE 000,074,146,146,036,006,014,070
5036	022162	000	000	030	.BYTE 000,000,030,030,000,030,030,000
5037	022172	000	000	030	.BYTE 000,000,030,030,000,030,030,060
5038	022202	000	014	030	.BYTE 000,014,030,060,140,060,030,014
5039	022212	000	000	000	.BYTE 000,000,000,076,000,076,000,000
5040	022222	000	060	030	.BYTE 000,060,030,014,006,014,030,060
5041	022232	000	074	146	.BYTE 000,074,146,006,034,030,000,030
5042	022242	000	030	146	.BYTE 000,030,146,156,156,146,060,000
5043	022252	000	030	066	.BYTE 000,030,066,146,146,176,146,146
5044	022262	000	174	146	.BYTE 000,174,146,146,170,146,146,174
5045	022272	000	074	146	.BYTE 000,074,146,140,140,140,146,074
5046	022302	000	174	146	.BYTE 000,174,146,146,146,146,146,174
5047	022312	000	176	140	.BYTE 000,176,140,140,170,140,140,176
5048	022322	000	176	140	.BYTE 000,176,140,140,170,140,140,140
5049	022332	000	076	140	.BYTE 000,076,140,140,156,146,146,076
5050	022342	000	146	146	.BYTE 000,146,146,146,176,146,146,146
5051	022352	000	074	030	.BYTE 000,074,030,030,030,030,030,074
5052	022362	000	006	006	.BYTE 000,006,006,006,006,006,146,074
5053	022372	000	146	154	.BYTE 000,146,154,170,160,170,154,146
5054	022402	000	140	140	.BYTE 000,140,140,140,140,140,140,176
5055	022412	000	146	176	.BYTE 000,146,176,176,146,146,146,146
5056	022422	000	146	146	.BYTE 000,146,146,166,156,146,146,146
5057	022432	000	074	146	.BYTE 000,074,146,146,146,146,146,074
5058	022442	000	174	146	.BYTE 000,174,146,146,174,140,140,140
5059	022452	000	074	146	.BYTE 000,074,146,146,146,156,156,166
5060	022462	000	174	146	.BYTE 000,174,146,146,174,170,154,146
5061	022472	000	076	140	.BYTE 000,076,140,140,074,006,006,174
5062	022502	000	176	030	.BYTE 000,176,030,030,030,030,030,030
5063	022512	000	146	146	.BYTE 000,146,146,146,146,146,146,074
5064	022522	000	146	146	.BYTE 000,146,146,146,146,074,074,030
5065	022532	000	146	146	.BYTE 000,146,146,146,146,176,176,146
5066	022542	000	146	146	.BYTE 000,146,146,074,030,074,146,146
5067	022552	000	146	146	.BYTE 000,146,146,074,030,030,030,030
5068	022562	000	176	006	.BYTE 000,176,006,014,030,060,140,176
5069	022572	000	170	140	.BYTE 000,170,140,140,140,140,140,170
5070	022602	000	140	140	.BYTE 000,140,140,060,030,014,006,006
5071	022612	000	036	006	.BYTE 000,036,006,006,006,006,006,036
5072	022622	030	074	176	.BYTE 030,074,176,377,030,030,030,030
5073	022632	030	034	036	.BYTE 030,034,036,377,377,036,034,030
5074	022642	030	030	030	.BYTE 030,030,030,030,377,176,074,030
5075	022652	030	070	170	.BYTE 030,070,170,377,377,170,070,030
5076	022662	000	377	377	.BYTE 000,377,377,377,377,377,377,377
5077	022672	000	000	377	.BYTE 000,000,377,377,377,377,377,377
5078	022702	000	000	000	.BYTE 000,000,000,377,377,377,377,377
5079	022712	000	000	000	.BYTE 000,000,000,000,377,377,377,377
5080	022722	000	000	000	.BYTE 000,000,000,000,000,377,377,377
5081	022732	000	000	000	.BYTE 000,000,000,000,000,000,377,377
5082	022742	000	000	000	.BYTE 000,000,000,000,000,000,000,377
5083	022752	374	374	374	.BYTE 374,374,374,374,374,374,374,374
5084	022762	374	374	374	.BYTE 374,374,374,374,374,374,374,374
5085	022772	370	370	370	.BYTE 370,370,370,370,370,370,370,370

: 60

: 70

5086	023002	360	360	360	.BYTE	360,360,360,360,360,360,360,360
5087	023012	340	340	340	.BYTE	340,340,340,340,340,340,340,340
5088	023022	300	300	300	.BYTE	300,300,300,300,300,300,300,300
5089	023032	300	300	300	.BYTE	300,300,300,300,300,300,300,300
5090	023042	300	300	300	.BYTE	300,300,300,300,300,300,300,377
5091	023052	377	003	003	.BYTE	377,003,003,003,003,003,003,003
5092	023062	003	003	003	.BYTE	003,003,003,003,003,003,003,377
5093	023072	377	300	300	.BYTE	377,300,300,300,300,300,300,300
5094	023102	000	000	000	.BYTE	000,000,000,000,000,000,000,300
5095	023112	300	000	000	.BYTE	300,000,000,000,000,000,000,000
5096	023122	003	000	000	.BYTE	003,000,000,000,000,000,000,000
5097	023132	000	000	000	.BYTE	000,000,000,000,000,000,000,003
5098	023142	000	030	074	.BYTE	000,030,074,146,347,000,000,000
5099	023152	030	030	070	.BYTE	030,030,070,060,140,060,070,030
5100	023162	000	074	146	.BYTE	000,074,146,303,303,000,000,000
5101	023172	030	070	160	.BYTE	030,070,160,140,140,160,070,030
5102	023202	000	000	000	.BYTE	000,000,000,000,037,030,030,030
5103	023212	030	030	030	.BYTE	030,030,030,030,370,000,000,000
5104	023222	030	030	030	.BYTE	030,030,030,030,037,000,000,000
5105	023232	000	000	000	.BYTE	000,000,000,000,370,030,030,030
5106	001000				.END	START

: 110

A	=	020000	DBUF0	007310	FORGND	007464	MONITX	013646	S	=	010000			
ADDRES		007572	DBUF1	007314	FRMSG	006550	NODEFM	006762	SAVPC		007524			
BAD		007564	DBUF10	007360	FSVPW	007620	NOHALT	017230	SAVPC1		007526			
BAKND		007466	DBUF11	007364	FSTCNT	007514	NORCH	017242	SAVREG		013740			
BAMSG		006653	DBUF12	007370	G	=	100000	NOSYNC	012032	SELBUS		015776		
BASADD		007542	DBUF13	007374	GENER	016370	NUMDEV	005660	SETDEV		012162			
BASE		007456	DBUF14	007400	GENER1	016512	NXMSG	006732	SETENC		005627			
BASE1		007460	DBUF15	007404	GENEX	016650	NXMTRP	016354	SET56		005610			
BASE1A		015370	DBUF16	007410	GENINC	016642	OCTIN	014034	SILLSI		012640			
BASE1B		015404	DBUF17	007414	GENISH	016520	OCTMSG	007256	SSWR		007504			
BASE1C		015422	DBUF18	007420	GENRAN	016522	OCTNUM	007230	START		001000			
BASE1D		015402	DBUF19	007424	GENROT	016475	ODAMSG	006707	START1		001306			
BASE10		015352	DBUF2	007320	GENRO	016464	PAL	007622	START2		001326			
BASE11		007240	DBUF20	007430	GENR1	016454	PALCH	021242	START3		001362			
BAS10		015334	DBUF3	007324	GENSEL	016406	PARITY	007546	STATUS		007570			
BAS10A		015360	DBUF4	007330	GENO	016426	PASMSG	006500	STRADD		007604			
BELL		013166	DBUF5	007334	GEN1	016432	PCHR	015012	STLEN		007606			
BELL1		013200	DBUF6	007340	GEN25	016446	PMSG1	014750	SWR		007502			
BLINK		007470	DBUF7	007344	GEN52	016440	PMSG2	014774	SWMSG		006623			
BUSSE1		016110	DBUF8	007350	GETCH1	014236	PMSG3	015000	SWSET		012704			
BUSSE2		016170	DBUF9	007354	GETCH2	014250	PMSG4	015004	SYNCP		011644			
CALLPC		007600	DECMG	007250	GETCH3	014362	PRCT1A	015046	TABLE		001366			
CARX		007474	DEVBUF	007440	GETCH4	014426	PRNT3	015116	TABLE1		001412			
CARY		007476	DEVCONT	007304	GETSTR	014232	PROCT	015024	TABLE2		001436			
CHAR		007550	DEVCSR	007436	GOMSG	006005	PROCT1	015034	TEST.G		006473			
CHRCOD		005716	DEVFLG	007302	GOMS1	006144	PROCT2	015050	TESTNO		007454			
CHRFIN		014656	DEVLST	012374	GOOD	007562	PROCT3	015102	TESTR		011624			
CHXLST		007266	EMSG1	007064	HSWR	=	177570	PROM		007462	TEST0	001450		
CMVFLG		007602	EMSG2	007070	ILLCHR	014636	ILLCHR	014636	PSW	=	177776	TEST1	002040	
CRLF		014700	EMSG3	007102	ILLVEC	013226	ILLVEC	013226	P02CHR		007624	TEST10	005264	
CSRO		007306	EMSG4	007113	ILVMSG	006516	JM600	007510	QEXIT1		013706	TEST11	005362	
CSR1		007312	EMSG5	007124	LINDEL	014552	LINDEL	014552	QEXIT2		013710	TEST2	002174	
CSR10		007356	EMSG6	007135	LINDL1	014572	LINECH	014602	QEXIT3		013724	TEST3	002354	
CSR11		007362	EMSG7	007153	LOADFS	012410	LOELEM	012522	RANCLC		016622	TEST4	002616	
CSR12		007366	EMSG8	007166	LOADFS	012410	LOWCHR	007610	RAND		007532	TEST5	003110	
CSR13		007372	EMSG9	007205	LSIFLG	012702	MODADM	006635	RANDC		007616	TEST5A	003142	
CSR14		007376	ENDIT	013062	MODADR	007536	MODIFY	015450	RANDN		007552	TEST6	004234	
CSR15		007402	ERRHALT	017210	MODI1	015500	RANRMTA	007556	RANGEN		016542	TEST7	004660	
CSR16		007406	ERRARG	007576	MODI2	015524	RANSEC	016626	RANMTA		007556	TKB	=	177562
CSR17		007412	ERRDIS	007574	MODI3	015544	RANSEL	007554	RANSEC		016626	TKS	=	177560
CSR18		007416	ERRD11	007442	MODI4	015656	RANST	007560	RANSEL		007554	TPB	=	177566
CSR19		007422	ERRFLG	007444	MODI5	015714	RANST	007560	RANST		007560	TPDEC1		015154
CSR2		007316	ERROR	016666	MODPRM	006646	RAN1	016554	RAN1		016554	TPDEC2		015234
CSR20		007426	ERRSV1	017036	MODSAV	007540	RAN2	016572	RAN2		016572	TPDEC3		015272
CSR3		007322	ERRSV2	017064	MODSPA	006642	RAN4	016630	RAN4		016630	TPDEC4		015306
CSR4		007326	ERRSV3	017112	MODXIT	015734	REACT	001174	REACT		001174	TPDEC5		015316
CSR5		007332	ERRSV4	017140	MONIT	013546	READ	014206	READ		014206	TPREDY		013276
CSR6		007336	ERRSV5	017166	MONITA	013640	REDMES	006570	REDMES		006570	TPS	=	177564
CSR7		007342	FADR	013156			REPNT	007506	REPNT		007506	TRAPSV		013326
CSR8		007346	FASTSW	013306			RSTART	001200	RSTART		001200	TRPARG		007516
CSR9		007352	FILL	012722			RSTREG	013776	RSTREG		013776	TRPBAK		013534
D	=	040000	FILL1	012754			RUBCHR	014504	RUBCHR		014504	TRPERR		007544
DATA		007566	FLASH	007472			RUBFLG	007614	RUBFLG		007614	TRPLP		013470

TRPMEM	007522	TYPOTD	014154	T0106	002130	T0518	003342	T0710	005074
TRPSCP	013444	TYPOTE	014172	T0201	002220	T0519	003374	T0711	005102
TRPSEL	007520	TYPOUT	014734	T0202	002276	T0520	003270	T0712	005220
TS0MSG	006360	T0001	001472	T0301	002400	T0601	004260	T0715	005254
TS1MSG	006365	T0002	001506	T0302	002470	T0602	004304	T1001	005310
TS10MS	006462	T0003	001514	T0303	002442	T0603	004306	UPPCHR	007612
TS2MSG	006411	T0004	001532	T0304	002520	T0604	004372	VECTOR	012714
TS3MSG	006415	T0005	001600	T0305	002546	T0605	004430	VIDEON	007450
TS4MSG	006426	T0007	001634	T0401	002642	T0606	004436	WAITS	012040
TS5MSG	006433	T0009	001654	T0402	002656	T0607	004444	WAIT1	007452
TS6MSG	006441	T0010	001672	T0403	002720	T0615	004570	WMSG	006317
TS7MSG	006454	T0011	001740	T0406	002736	T0701	004704	XMAX	007446
TYPCTC	013656	T0013	001774	T0407	002776	T0702	004730	XXDPGO	001176
TYPDEC	015150	T0101	002064	T0409	003026	T0703	004732	XXDP2	001252
TYPD1	007534	T0102	002072	T0410	003052	T0704	005016	YMAX	007500
TYPOTA	007530	T0103	002102	T05XIT	004214	T0705	005032	SENDAD	013142
TYPOTB	014040	T0104	002110	T0501	003134	T0706	005044	.	= 023242
TYPOTC	014120	T0105	002122	T0502	003226	T0707	005056		

. ABS. 023242 000

ERRORS DETECTED: 0

CVVTC.A.BIN, CVVTC.A.LPT/NL: TOC=CVVTC.A.SRC  
 RUN-TIME: 14 28 1 SECONDS  
 RUN-TIME RATIO: 85/44=1.  
 CORE USED: 13K (25 PAGES)