

RK611
RK06, RK07

UNIBUS RK6 DR-3
CZR6JF0

AH-9126F-MC
FICHE 1 OF 1

APR 1982
COPYRIGHT © 76-82
MADE IN USA



A large grid of 10 columns and 15 rows of technical data. Each cell contains a small table or diagram, likely representing a memory layout or hardware configuration. The data is organized into columns, with the first column containing headers and the subsequent columns containing numerical values and symbols. The text is small and difficult to read, but the overall structure is consistent across the grid.

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41

.REM %

IDENTIFICATION

PRODUCT CODE:	AC-9125F-MC
PRODUCT NAME:	CZR6JFO UNIBUS RK6 DR-3
DATE:	JANUARY 1982
MAINTAINER:	STORAGE SYSTEMS SOFTWARE TEST APPLICATION
AUTHOR:	B. T. LEBLANC

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1976,1982 BY DIGITAL EQUIPMENT CORPORATION

42
43
44

REVISION	CHANGES	DATE
CZR6JF0	IMPLEMENTED XXDP LOAD MEDIA OPTION	JAN 82

45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	HARDWARE
2.2	PRELIMINARY TESTING AND PROGRAMS
3.0	PROGRAM CONSIDERATIONS
3.1	PDP-11 FAMILY COMPATIBILITY
3.2	XXDP
3.3	ACT/APT
3.3.1	APT ETABLE DEFINITIONS
3.4	DUAL ACCESS
3.5	MEMORY MANAGEMENT
3.6	PARITY CHECK ENABLED
3.7	BAD SECTORS
3.8	EXECUTION TIME
3.9	FAULT ISOLATION
3.10	ERROR CORRECTION & FAILURE RATE ANALYSIS
3.11	DEFAULT UNIBUS ADDRESSES & VECTORS
4.0	OPERATING PROCEDURE & CONTROL FUNCTIONS
4.1	PROGRAM LOADING
4.2	STARTING LOCATIONS
4.3	CONSOLE SWITCH REGISTERS
4.4	SOFTWARE SWITCH REGISTER
4.5	INPUT DIALOGUE
4.6	PROGRAM EXAMPLE
4.7	HALTING THE PROGRAM
5.0	DRIVE DIAGNOSTIC FUNCTIONAL DESCRIPTION
5.1	GENERAL
5.2	TEST DESCRIPTIONS
6.0	ERROR REPORTING
6.1	ERROR INTERPRETATION
6.2	ERROR PRINTOUT EXAMPLE

91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146

1.0 ABSTRACT

THIS PROGRAM PERFORMS PART 3 OF THE DRIVE DIAGNOSTICS TO INSURE THAT THE DISK IS CAPABLE OF PROPERLY PERFORMING ALL OPERATOR INTERVENTION FUNCTIONS. ERROR DETECTION LOGIC IS CHECKED BY MANUAL & SOFTWARE ERROR FORCING.

AFTER A SUCCESSFUL RUN (WITH NO ERRORS) OF THIS PART, PRECEDED BY THE SUCCESSFUL RUN OF PARTS 1 & 2, IT CAN BE ASSERTED THAT THE RK06 DRIVE WILL WORK SUCCESSFULLY IN THE STAND-ALONE MODE. SYSTEMS INTERACTION, & ERROR RATE ANALYSIS ARE LEFT TO OTHER PROGRAMS.

TESTING IS BASED ON A HIERARCHY APPROACH STARTING WITH BASIC LOGIC TESTS AND PROCEEDING THRU DYNAMIC TESTING. THE TESTS WILL BE KEPT SMALL TO FACILITATE SCOPING LOOPS. THIS PROGRAM WILL TEST RK06 & RK07 WITHOUT NEED OF OPERATOR INPUTS.

*****CAUTION*****

HALTING THIS PROGRAM ANYWHERE BUT AT THE END OF A PASS, MAY LEAVE THE HEADERS IN THE DISK CARTRIDGE IN AN UNDETERMINED STATE.

2.0 REQUIREMENTS

2.1 HARDWARE

THE FOLLOWING HARDWARE IS REQUIRED TO RUN THE DISK DIAGNOSTIC:

PDP-11
CONSOLE TELETYPE
16K MEMORY
KW11-L OR KW11-P CLOCK
RK06 UNIBUS CONTROLLER (RK611)
1 TO 8 RK06/RK07 DRIVES

- NOTES:
1. IF NEITHER KW11-L OR P CLOCK IS USED, ALL TIMING TESTS WILL BE BYPASSED. A MESSAGE AT THE BEGINNING OF THE TESTS WILL CONFIRM THIS.
 2. THE PROGRAM CAN WORK OFF EITHER FORMATTED OR NON-FORMATTED PACKS.

2.2 PRELIMINARY TESTING & PROGRAMS

THE RK611 DISKLESS CONTROLLER DIAGNOSTICS (ALL PARTS) SHOULD FIRST RUN SUCCESSFU FOLLOWED BY THE RK06 DRIVE DIAGNOSTICS - PARTS 1 & 2.

3.0 PROGRAM CONSIDERATIONS

147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202

3.1 PDP-11 FAMILY COMPATIBILITY

THIS PROGRAM CAN BE USED BY THE PDP-11/04,05,10,20,
34,35,40,45,50, & 70.

IT IS COMPATABLE WITH THE LSI-11 INSTRUCTION SET AND CAN TEST
THE RK06 ONLY IF THE DRIVE CONTROLLER FOR THE LSI-11 IS
DESIGNED TO BE DIAGNOSTICALLY COMPATABLE WITH THE RK611.

3.2 XXDP

THIS PROGRAM SHOULD NOT BE CHAINED BY XXDP.

CHAIN MODE OPERATION (MONITOR)

BY DEFINITION, ANY PROGRAM THAT REQUIRES
OPERATOR INTERVENTION SHOULD NOT BE CHAINED.

DUMP MODE OPERATION (MANUAL)

1. INPUT DIALOGUE IF STARTED FROM 220.
2. DRIVE 0 CAN BE TESTED, BUT THE OPERATOR IS FIRST GIVEN
A MESSAGE TO REPLACE THE PACK IN DR0 WITH A SCRATCH
PACK & TYPE <CR> WHEN DONE.

3.3 ACT/APT

THIS PROGRAM IS ACT COMPATIBLE.
HOWEVER, IT SHOULD NOT BE RUN IN THE AUTO MODE.

AUTOMATIC MODE (MONITOR)

BY DEFINITION, ANY PROGRAM THAT REQUIRES
OPERATOR INTERVENTION SHOULD NOT BE
RUN IN THE AUTO MODE.

DUMP MODE (MANUAL): INPUT DIALOGUE IF STARTED FROM 220.

3.3.1 APT ETABLE DEFINITIONS

THE FOLLOWING DEFINITIONS ARE VALID FOR SPECIFYING APT ENVIRONMENTAL
TABLE (ETABLE) ENTRIES, VIA RUNNING THE APT UTILITY PROGRAM 'TSP':

1. SOFTWARE ENVIRONMENT:
=1 IF APT SCRIPT MODE
=0 IF STANDALONE MODE
2. ENVIRONMENT MODE:
BIT 7 = 1 ETABLE DOES SIZING
= 0 PROGRAM DOES SIZING
BIT 6 = 1 SPOOL MESSAGES TO APT IF SCRIPT MODE
= 0 DON'T SPOOL TO APT

203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258

BIT 5 = 1 SUPPRESS CONSOLE OUTPUT
= 0 ALLOW CONSOLE OUTPUT
BITS 4-0 NOT USED

3. SWITCH 1 (SOFTWARE SWITCH REGISTER)
IF ENVIRONMENT MODE BIT 7 (SIZING BIT) IS SET TO 1,
THE SOFTWARE SWITCH REGISTER WILL BE USED, INSTEAD
OF THE HARDWARE CONSOLE SWITCH REGISTER. REGARDLESS
OF WHICH ONE IS USED, ALL BITS DEFINED IN SECTIONS
4.3 & 4.4 (SWITCH REGISTER OPTIONS) MAY USED
WHEN RUNNING IN STANDALONE MODE. IN APT SCRIPT MODE,
HOWEVER, BIT 14 (LOOP ON TEST) MUST ALWAYS BE SET
TO 0.
4. SWITCH 2 (USER SWITCH REGISTER)
NOT USED
5. CPU OPTIONS:
NOT USED
6. MEMORY TYPES 1-4 AND MAX MEMORY ADDRESSES
NOT USED
7. INTERRUPT VECTOR 1:
USED WHEN ENVIRONMENT MODE BIT 7 = 1. DEFAULT = 210
8. BUS PRIORITY 1:
USED WHEN ENVIRONMENT MODE BIT 7 = 1. DEFAULT = 5
9. INTERRUPT VECTOR 2:
NOT USED
10. BUS PRIORITY 2:
NOT USED
11. BASE ADDRESS:
USED WHEN ENVIRONMENT MODE BIT 7 = 1. DEFAULT = 177440
12. DEVICE MAP:
USED WHEN ENVIRONMENT MODE BIT 7 = 1. EACH BIT
SET TO 1 IN BITS 0-7 WILL SELECT THE CORRESPONDING
DRIVE TO BE TESTED. BITS 8-15 ARE NOT USED.
13. CONTROLLER DESCRIPTOR WORDS:
NOT USED
14. DEVICE DESCRIPTOR CODES (IN WORDS):
NOT USED

3.4 DUAL ACCESS

THIS PROGRAM WILL NOT TEST OR SUPPORT DUAL-ACCESS. A DRIVE
EQUIPED WITH DUAL ACCESS MUST BE SWITCHED TO THE PORT UNDER
TEST TO PREVENT CONTENTION WITH THE OTHER PORT.

DUAL ACCESS TESTS WILL BE INCORPORATED IN A SEPARATE PROGRAM

259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314

AT A LATER DATE.

3.5 MEMORY MANAGEMENT

MEMORY MANAGEMENT NOT USED

3.6 PARITY CHECK ENABLED

IF THE MEMORY PARITY CHECK OPTION IS AVAILABLE ON THE SYSTEM,
THE PROGRAM WILL RUN WITH MEMORY CHECK ENABLED.

3.7 BAD SECTOR

THE PROGRAM WILL COMPARE DATA ERRORS WITH THE BAD SECTOR
INFORMATION CONTAINED ON CYLINDER 410, HEAD 2. PRINTOUTS
OF DATA ERRORS DUE TO BAD SECTORS/TRACKS WILL BE MASKED OUT.

3.8 EXECUTION TIME

TOTAL TIME: APPROX 5 MINUTES TO DO ALL THE TESTS
(BASED ON THE PDP 11/50)

3.9 FAULT ISOLATION

TO BE DETERMINED.

3.10 ERROR CORRECTION AND FAILURE RATE ANALYSIS

THIS PROGRAM WILL NOT DO ERROR CORRECTION OR FAILURE RATE
ANALYSIS.

3.11 DEFAULT UNIBUS ADDRESSES & VECTORS

THE FOLLOWING IS A LIST OF ALL DEFAULT ADDRESSES & VECTORS
OF ALL HARDWARE TO BE USED & THEIR MEMORY ADDRESSES
WHERE THEY CAN BE CHANGED.

	LOCATION	DEFAULT CONTENTS
RK06 BUS ADDRESS	1264	177440
CONTROLLER INTERRUPT VECTOR	1334	210
CONTROLLER PRIORITY	1336	240
P-CLOCK STATUS REG	1340	172540
P-CLOCK SET BUFFER	1342	172542
P-CLOCK READ BUFFER	1344	172544
L-CLOCK STATUS REG	1346	177546
L-CLOCK INTERRUPT VECTOR	1350	100
P-CLOCK INTERRUPT VECTOR	1352	104
TTY KB STATUS REG	1144	177560
TTY KB BUFFER	1146	177562

315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370

TTY PRINTER STATUS REG 1150 177564
TTY PRINTER BUFFER 1152 177566

4.0 OPERATING PROCEDURE & CONTROL FUNCTIONS

4.1 PROGRAM LOADING

THE PROGRAM CAN BE LOADED FROM PAPER TAPE USING STANDARD PROCEDURE FOR ABSOLUTE LOADER TAPES; OR FROM ANY MEDIA SUPPORTED BY XXDP.

4.1.1 LOAD THE STARTING ADDRESS (SEE SEC 4.2).

4.1.2 SET SWITCH REGISTERS AS DESIRED (SEE SEC 4.3).

4.1.3 SET DRIVES TO BE TESTED IN THE 'LOAD' CONDITION & WITH THE APPROPRIATE PORT SELECTED & WRITE LOCK DISABLED. DRIVES NOT TO BE TESTED MUST HAVE BOTH PORTS Deselected.

NOTE: THE DRIVE WILL NOT RESPOND TO THE 'START SPINDLE' COMMAND IF THE RUN/STOP SWITCH IS IN THE 'STOP' POSITION.

4.1.4 PRESS 'START'

THE PROGRAM WILL IDENTIFY ITSELF AND WILL BEGIN A DIALOGUE WITH THE OPERATOR TO DETERMINE DRIVES TO BE TESTED (SEE SEC 4.5).

THE PROGRAM BEGINS TESTING ONLY THOSE DRIVES SPECIFIED BY THE INPUT DIALOGUE. IF A SPECIFIED DRIVE CANNOT BE FOUND BY THE PROGRAM IT WILL BE FLAGGED AS AN ERROR THAT THE DRIVE WAS NOT AVAILABLE. THEN BEGINNING WITH THE LOWEST NUMERICAL DRIVE AND PROCEEDING IN SEQUENTIAL ORDER, ALL VALID DRIVES WILL BE TESTED. ONE PASS THROUGH THE TEST SEQUENCE WILL BE PERFORMED ON EACH DRIVE BEFORE MOVING TO THE NEXT DRIVE IN SEQUENCE. THE DRIVE TO BE TESTED WILL BE TYPED AT THE BEGINNING OF EACH PASS. 'END OF PASS' WILL BE TYPED AFTER TESTING ALL DRIVES.

4.2 STARTING LOCATIONS

LOCATION 200 - STARTING ADDRESS TO DEFAULT THE BUSS ADDRESS & THE CONTROLLER INTERRUPT VECTOR & TEST ALL DRIVES IN THE 'DRIVE PRESENT' CONDITION.

NOTE: THE DRIVE PRESENT CONDITION IS:

371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426

- A. HEADS MANUALLY LOADED
- B. CORRECT PORT SELECTED
- C. WRITE LOCK DISABLED
- D. DRIVE READY INDICATOR ON

LOCATION 220 - STARTING ADDRESS TO INPUT TESTING PARAMETERS VIA THE INPUT DIALOGUE. BUSS ADDRESS & CONT. INTERRUPT VECTOR INPUTTED ONLY ON 1ST PASS.

IMPORTANT: FOR VARIATIONS OF THE ABOVE, SEE XXDP, ACT/APT CONSIDERATIONS IN SECTIONS 3.2 & 3.3.

ALSO, THE PROGRAM WILL DETERMINE IF THE DRIVE IS AN RK06 OR RK07 WITHOUT OPERATOR INPUT.

4.3 SWITCH REGISTER

THE SWITCHES ARE USED TO PROVIDE CONTROL FUNCTIONS.

SWITCH	FUNCTION
15	HALT ON ERROR
14	LOOP ON TEST
13	INHIBIT ERROR TYPEOUT
12	BYPASS DRIVE AFTER 20 ERRORS
11	INHIBIT ITERATION
10	BELL ON ERROR
9	LOOP ON ERROR

4.3.1 SW<15>

THE PROGRAM HALTS ON ENCOUNTERING AN ERROR, AFTER TYPING OUT THE ERROR MESSAGE AND PERTINENT INFORMATION. PRESSING "CONTINUE" CONTINUES NORMAL OPERATION OF THE PROGRAM.

4.3.2 SW<14>

THE PROGRAM LOOPS ON THE TEST THAT IS BEING EXECUTED WHEN THE SWITCH IS PUT ON. THIS SWITCH IS NORMALLY USED ALONG WITH SW15.

4.3.3 SW<13>

THIS SWITCH INHIBITS ALL ERROR MESSAGES. NORMALLY USED WHEN LOOPING ON TEST (SW14) OR LOOPING ON ERROR (SW9).

4.3.4 SW<12>

427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482

THIS SWITCH BYPASSES A GIVEN DRIVE AFTER 20 ERRORS HAVE BEEN DETECTED.

4.3.5 SW<11>

EACH TEST WILL BE EXECUTED ONLY ONCE. NORMALLY AFTER THE FIRST PASS, EACH SUBTEST IS ITERATED A NUMBER OF TIMES (USUALLY 50, 5 IN SOME CASES). SETTING THIS SWITCH INHIBITS ITERATIONS, SO THAT QUICK PASSES CAN BE MADE.

4.3.6 SW<10>

RINGS A BELL ON ERROR. USEFUL WHEN ERROR TYPEOUT IS INHIBITED.

4.3.7 SW<09>

THIS SWITCH PROVIDES THE TIGHTEST POSSIBLE SCOPE LOOP FOR ERRORS. IF THE PROGRAM DETECTS AN ERROR, IT WILL LOOP BACK TO THE BEGINNING OF TEST.

4.4 'SOFTWARE' SWITCH REGISTER

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/04 OR 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM IS AT A HIGHER PRIORITY PROCESSING AN RK06 INTERRUPT. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

SWR = NNNNNN NEW =

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

4.5 INPUT DIALOGUE

THE DIALOGUE WILL BE DONE INTERACTIVELY. THE PROGRAM WILL REQUEST A PARAMETER BY CONSOLE TYPEOUT. THE PARAMETER MAY THEN BE ENTERED AS SPECIFIED BELOW OR ALLOWED TO DEFAULT

483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538

BY A CARRIAGE RETURN. UNRECOGNIZED OR ILLEGAL RESPONSES WILL BE ECHOED BACK FOLLOWED BY "?". THE PROPER RESPONSE MAY THEN BE ENTERED.

IMPORTANT: FOR VARIATIONS OF THE ABOVE, SEE XXDP, ACT/APT CONSIDERATIONS IN SECTIONS 3.2 & 3.4.

4.5.1 DRIVE SELECTION

THE REQUEST WILL BE:

DRIVES TO BE TESTED:

THE DEFAULT RESPONSE IS CARRIAGE RETURN TO TEST ALL DRIVES IN THE 'DRIVE PRESENT' CONDITION.

THE OPERATOR CAN ALSO TYPE IN THE SPECIFIC DRIVE NUMBERS TO BE TESTED, SEPARATED BY COMMAS & TERMINATED BY A CARRIAGE RETURN.

E.G. DRIVES TO BE TESTED: 1,2,4,6

IMPORTANT: FOR VARIATIONS OF THE ABOVE, SEE XXDP, ACT/APT CONSIDERATIONS IN SECTIONS 3.2 & 3.3.

4.5.2 BUS ADDRESS

THE REQUEST WILL BE:

TYPE IN BUSS ADDRESS IF NOT 177440

THE DEFAULT IS A CARRIAGE RETURN

4.5.3 CONTROLLER INTERRUPT VECTOR

THE REQUEST WILL BE:

TYPE IN CONTROLLER INTERRUPT VECTOR IF NOT 210

THE DEFAULT IS A CARRIAGE RETURN.

4.5.4 EXAMPLE OF PROGRAM DIALOGUE

THE EXAMPLE SHOWN IS FOR A PROGRAM STARTED AT ADDRESS 220. ALL OPERATOR RESPONSES ARE UNDERLINED.

CZR6JFO UNIBUSS RK6 DR-3

DRIVES TO BE TESTED: 1,3<CR>

TYPE IN BUSS ADDRESS IF NOT 177440 <CR>

539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594

TYPE IN CONTROLLER INTERRUPT VECTOR IF NOT 210 <CR>

WILL TEST DRIVES:

1
3

DRIVE 1

(THE REST IS IDENTICAL TO THE EXAMPLE SHOWN IN 4.6 BELOW)

4.6 PROGRAM EXAMPLE

THE FOLLOWING IS AN EXAMPLE OF A PROGRAM STARTED AT THE
DEFAULT ADDRESS (200) & WITH 2 DRIVES ON THE LINE.

CZR6JFO UNIBUSS RK6 DR-3

WILL TEST DRIVES:

0
1

DRIVE 0

DRIVE SERIAL NO. AAA
CARTRIDGE SERIAL NO. BBB

DRIVE 1

DRIVE SERIAL NO. CCC
CARTRIDGE SERIAL NO. DDD

END PASS #1

WILL TEST DRIVES:

0
1

DRIVE 0

DRIVE 1

END PASS # 2

(ETC)

THE ABOVE ASSUMES NO ERRORS DETECTED.
THE NUMBER OF PASSES IS DETERMINED BY ACT/APT/XXDP

IMPORTANT: FOR VARIATIONS OF THE ABOVE, SEE XXDP, ACT/APT
CONSIDERATIONS IN SECTIONS 3.2 & 3.3.

595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650

4.7 HALTING THE PROGRAM

THE PROGRAM PROVIDES A METHOD OF HALTING ITSELF SUCH THAT THE CARTRIDGE AND/OR DRIVE IS NOT LEFT IN ON UNDETERMINED STATE; IE: HEADS UNLOADED OR INVALID FORMAT.

TO PROPERLY HALT, TYPE CONTROL-C (^C) ON THE CONSOLE.

IF HEADS ARE LOADED & FORMATTING IS VALID, THE PROGRAM WILL:

1. ECHO ^C
2. TYPE "CPU HALTED"
3. HALT THE PROGRAM

IF HEADS ARE NOT LOADED AND/OR FORMATTING IS INVALID, THE PROGRAM WILL:

1. ECHO ^C
2. TYPE 'HALT PENDING, PLEASE WAIT'
3. DO THE TEST(S) THAT LOADS HEADS AND/OR FORMATS THE INVALID CYLINDERS
4. TYPE 'CPU HALTED'
5. HALT THE PROGRAM

NOTES:

1. THE ABOVE EXAMPLE IS FOR THE PROGRAM RUNNING IN DUMP MODE (MANUAL). IF THE PROGRAM IS RUNNING IN CHAIN/AUTO MODE VIA XXDP,ACT,APT; IT WILL FIRST LOAD HEADS AND/OR FORMAT CORRECTLY, IF REQ'D, THEN IT WILL JUMP ON TO THE MONITOR WHERE THE NEXT PROGRAM CAN BE CALLED IN.

THE TYPEOUTS WILL BE "ABORT PENDING - PLEASE WAIT"
& "PROGRAM ABORTING"

2. OPERATING THE 'CONTINUE' SWITCH ON THE CPU CONSOLE WILL RETURN THE PROGRAM TO TEST 1 WHERE TESTING WILL BEGIN WITH THE 1'ST DRIVE AGAIN.

5.0 DRIVE DIAGNOSTIC FUNCTIONAL DESCRIPTION

5.1 GENERAL

OPERATOR INTERVENTION TESTS

THESE TESTS CHECK OUT ALL THE DRIVE INTERLOCKS, FRONT PANEL SWITCHES AND LIGHTS.

THE OPERATOR IS INSTRUCTED TO PERFORM A TEST AND TYPE A SPACE WHEN FINISHED.

OPERATOR INTERVENTION TESTS CAN BE INDIVIDUALLY BYPASSED BY TYPING A CONTROL-E <^E>. ONLY AT THE BEGINNING OF EACH TEST, AS INSTRUCTED BY THE TYPEOUT.

651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706

IF THE PROGRAM DETERMINES IT WAS LOADED UNDER
ACT, APT, OPERATOR INTERVENTION TESTS WILL BE
BYPASSED UNLESS THE 'LOAD & DUMP MODE' IS BEING
USED.

THEY WILL BE BYPASSED IN 'MONITOR MODE' AS OPERATOR
INTERVENTION MAY NOT BE FEASIBLE IN OVER-NITE
TESTING.

5.2 TEST DESCRIPTIONS

BASIC CONTROLLER TESTS, SIZING & SETUP

TEST 1 REFERENCE ALL CONTROLLER REGISTERS

THIS TEST VERIFIES THAT ALL THE CONTROLLER REGISTERS
CAN BE ACCESSED. THE INABILITY TO BE ACCESSED WILL
RESULT IN A TIMEOUT TRAP WITH AN ERROR MESSAGE. ANY
ERROR IN THIS TEST WILL RESULT IN ABORTING ALL OTHER
TESTS AND JUMPING TO 'END OF PASS'

TEST 2 SIZE THE BUSS

THIS TEST IS ENTERED ONLY IF 'DRIVE SELECTION' IS DEFAULTED
EITHER BY RUNNING IN THE AUTO MODE OR A 200 START IN THE
MANUAL MODE.
EVERY DRIVE FROM 0 THRU 7 IS ADDRESSED.
CONTROLLER ERROR (CERR) IS EXAMINED AND IF NOT SET, THE
DRIVE WILL BE TESTED AS AN RK06. IF SET, THE PROGRAM WILL BYPASS
TESTING THAT DRIVE ONLY IF THE ERROR WAS A RESULT OF
MDS, UFE OR NED BEING SET; OR BOTH NED & DRA RESET IN-
DICATING THE OTHER PORT IS ACCESSED.

IF CERR DUE TO DTYE, THE DRIVE WILL BE TESTED AS
AN RK07.

TEST 3 VERIFY OPERATOR DRIVE SELECTIONS

THIS TEST IS ENTERED ONLY IF DRIVE SELECTION IS NOT
DEFAULTED. EVERY DRIVE FROM 0 TO 7 IS ADDRESSED &
CONTROLLER ERROR (CERR) IS EXAMINED. IF NOT SET, THE
PROGRAM WILL ASSUME THE DRIVE IS PRESENT AS AN RK06.
IF CERR WAS SET, THAT DRIVE WILL BE BYPASSED
ONLY IF THE ERROR WAS A RESULT OF MDS OR UFE SET OR BOTH
NED & DRA RESET (WRONG PORT). IF CERR IS A RESULT OF
NED ONLY, IT IS CHECKED AGAINST THE INPUTTED INFOR TO
VERIFY IT WAS NOT SPECIFIED.
IF CERR DUE TO DTYE, THE DRIVE WILL BE TESTED

707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762

AS AN RK07.

TEST 4 FIND NEXT DRIVE TO BE TESTED

THIS TEST FINDS THE NEXT DRIVE PRESENT & PUTS THAT ADDRESS IN 'DRVAD' & \$TMP4 IS SET TO CDT IF DRIVE DRIVE IS RK07. THROUGHOUT THE FOLLOWING TESTS, THE DRIVE TESTED IS THE DRIVE WHOSE ADDRESS IS IN 'DRVAD'.

TEST 5 PRINT DRIVE SERIAL NUMBER

THIS TEST READS & PRINTS THE DRIVE SERIAL # FROM MSG A, WORD 11 IN DECIMAL & IS PERFORMED ON THE 1ST PASS ONLY

TEST 6 SET VV WITH PACK COMMAND

IF VV IS RESET, THE PACK COMMAND IS USED TO SET IT.

TEST 7 UNLOAD DRIVE TO BE TESTED

THIS TEST UNLOADS THE DRIVE TO BE TESTED NEXT, WAITS FOR ATTN & VERIFIES IT CAME FROM THE CORRECT DRIVE.

OPERATOR INTERVENTION TESTS

TEST 10 INTERLOCKS TESTS

THIS TEST VERIFIES THAT THE DOOR & CARTRIDGE STATUS BITS ARE OPERATING PROPERLY IN MESSAGE A0 & THAT THE REMOVAL OF THE CARTRIDGE CLEARS VOLUME VALID. IT FURTHER VERIFIES ALL REMAINING STATUS BITS OF MESSAGE A & B, WORDS 0 & 1. THIS TEST ALSO CHECKS THAT THE SPINDLE CANNOT BE STARTED WHEN THE DOOR IS OPEN OR THE CARTRIDGE IS REMOVED. IT ALSO VERIFIES THAT LOSS OF VOLUME VALID RESETS SACK WHICH ASSERTS NON EXISTENT DRIVE IN RKCS2

TEST 11 UNIT SELECT PLUG TEST

THIS TEST VERIFIES THAT WHEN THE UNIT SELECT PLUG IS PULLED OUT, THE QUAL LOGIC RESETS ATTN & VOLUME VALID, THAT THE DRIVE DE-SELECTS & NON EXISTENT DRIVE ASSERTS. FURTHER, THE OPERATOR IS ASKED TO INSERT ANY NUMBER OF UNIT SELECT PLUGS. THE PROGRAM WILL RESPOND BY TYPING THE PLUG CODE NUMBER AS SOON AS IT IS INSERTED. THIS PORTION OF THE TEST IS TERMINATED AT ANY TIME BY A CONTROL-C

763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818

TEST 12 PORT SELECTION TESTS

THE OPERATOR IS ASKED TO SWITCH TO THE WRONG PORT
& THEN DESELECT BOTH PORTS.
IN BOTH CASES, NON EXISTENT DRIVE SHOULD ASSERT IN RKCS2

TEST 13 AC LOW DETECTION PART 1

A PRELIMINARY AC LOW TEST IS PERFORMED HERE WHILE HEADS ARE UNLOADED.
BATTERY RETRACT WILL BE TESTED LATER.
ACLO CANNOT BE TESTED DIRECTLY SINCE IT REQUIRES
SECTOR PULSES, I.E. HEADS LOADED.
THEREFORE THE INDICATOR CHECKED IS NON-EXISTENT
DRIVE (NED) ASSERTING IN RKCS2 AS A RESULT OF DCLO.
AFTER POWER UP, VOLUME VALID IS CHECKED TO BE CLEARED.

TEST 14 CHECK NXF LOGIC

THIS TEST VERIFIES NON-EXECUTABLE FUNCTION (NXF) IS DETECTED
AS A RESULT OF DOING A SEEK WITH VOLUME VALID RESET.

TEST 15 READ & SAVE BAD SECTOR INFO & TYPE PACK SERIAL #

THIS TEST VERIFIES THAT CYL 632 (1456 FOR RK07), TRACK 2 CAN BE READ.
THIS AREA CONTAINS BAD SECTOR INFOR WHICH IS WRITTEN BY THE
FACTORY DURING MANF. ALL BAD SECTOR INFOR (BSE) WILL BE STORED
AT THIS TIME TO MASK FUTURE READ HEADER OR DATA ERROR PRINTOUTS.
IF BSE INFO CANNOT BE READ, OR IF AFTER READING THE BSE INFO
IT IS DETERMINED THAT AN ALIGNMENT CARTRIDGE IS USED,
A MESSAGE WILL BE TYPED INDICATING THAT ALL
FUTURE FORMAT AND READ-WRITE TESTS WILL BE BYPASSED.
THIS IS DONE SO AS NOT TO DESTROY BSE INFOR OR AN ALIGNMENT PACK BY WRIT
THE PACK SERIAL # IS TYPED IN OCTAL & FOR THE FIRST PASS ONLY.

TEST 16 WRITE LOCK TEST

THIS TEST VERIFIES THAT DATA WRITTEN ON A SECTOR CANNOT BE
ALTERED ONCE THE WRITE LOCK SWITCH HAS BEEN ENABLED.
IT ALSO CHECKS THAT WRITE PROTECT TAKES EFFECT ONLY AT
SECTOR BOUNDRIES WHEN DOING CONTINUOUS WRITING ON CYL 0, HEAD 0

TEST 17 AC LOW DETECTION PART 2

THIS TEST VERIFIES THAT WHEN AC POWER IS LOST, THAT WRITING CEASES
AT SECTOR BOUNDRIES & THAT THE BATTERY RETRACT IS FUNCTIONAL.
THERE IS APPROX 4 MS BETWEEN AC LOW ASSERTING AND NED ASSERTING
WHEN THE INTERFACE SHUTS DOWN.

819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874

TEST 20 END OF PROGRAM

THIS IS NOT A TEST BUT A LINKAGE TO PERFORM ALL THE ABOVE TESTS FOR THE NEXT DRIVE PRESENT. THE NEXT TEST IS ENTERED ONLY AFTER ALL DRIVES PRESENT HAVE BEEN TESTED. DO NOT LOOP ON THIS 'TEST'.

TEST 21 MULTIPLE DRIVE DETECTION TEST

THIS TEST IS PERFORMED ONLY ONCE AT THE END OF PASS 1 AND IS BYPASSED IF ONLY ONE DRIVE IS PRESENT.

THE MULTIPLE DRIVE DETECTION LOGIC IS TESTED BY THE FOLLOWING METHOD:

- A. HEADS MUST BE LOADED (SECTOR PULSES REQ'D)
- B. THE OPERATOR IS INSTRUCTED TO INSERT THE SAME UNIT SELECT PLUG NUMBER (1 PAIR AT A TIME) ON ANY 2 DRIVES TO BE TESTED
- C. THE OPERATOR THEN DEPRESSES THE SPACE BAR TO CONTINUE THE TEST OR A CONTROL-C TO EXIT THE TEST

THE PROGRAM VERIFIES THAT MULTIPLE DRIVE SELECT & DRIVE UNSAFE BOTH SET & THAT THE DRIVE UNLOADS

THE OPERATOR IS ASKED TO VERIFY THAT HEADS UNLOAD FROM BOTH DRIVES

THE PROGRAM DOES NOT REQUIRE FORMATTED PACKS AS FORMATTING IS PERFORMED IN ANY CASE.

ANY TEST THAT MODIFIES STANDARD FORMATTING IS FOLLOWED BY A 'CLEAN UP' TEST TO PUT THOSE CYLINDERS BACK TO STANDARD FORMAT.

6.0 ERROR REPORTING

6.1 ERROR INTERPRETATION

WHENEVER AN ERROR MESSAGE IS PRINTED OUT, ALL REGISTERS AND OTHER DATA PERTAINING TO THE ERROR ARE ALSO GIVEN. MSG A(00), MSG B(01), RKER, RKBA...ETC, INDICATE THE CONTENTS OF THE CORRESPONDING REGISTERS AT THE TIME OF ERROR.

EVERY ERROR MESSAGE CONTAINS A PC. THIS PC INDICATES THE POSITION IN PROGRAM WHERE THE ERROR CALL IS LOCATED. THE

875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930

ERROR MESSAGE, BECAUSE OF PRACTICAL CONSIDERATIONS IS MADE SHORT AND MEANINGFUL. THE USER IS ADVISED TO LOOK UP THE PC IN THE PROGRAM LISTING, WHERE HE WILL FIND MORE INFORMATION ABOUT THE ERROR. IN MANY INSTANCES, A SINGLE FAULT WILL GIVE RISE TO MORE THAN ONE ERROR REPORT. A LITTLE DELIBERATION AND CAREFUL EXAMINATION OF THE DATA GIVEN WILL BE CERTAINLY VERY HELPFUL IN PINPOINTING THE FAULT. A BRIEF EXPLANATION OF WHAT IS BEING CHECKED IN THE TEST IS GIVEN AT THE BEGINNING OF EVERY TEST. ALL THE NUMBERS GIVEN WITH ERROR MESSAGES ARE IN OCTAL.

NOTE

NO ERROR LOGGING OR OPERATION HISTORY IS PROVIDED.

6.2 ERROR PRINTOUT EXAMPLE:

DEPRESS 'RUN-STOP' SWITCH TO 'RUN' WHILE DOOR OPEN
VERIFY SPINDLE DOES NOT START & HEADS DO NOT LOAD

DEPRESS SPACE BAR WHEN FINISHED

SPINDLE ON SET IN RKMR2
AFTER MANUALLY LOADING HEADS WITH DOOR OPEN

TEST NO.	PC					
000010	015700					
RKMR2	RKMR3	RKER	RKDS	RKCS1	RKCS2	RKASOF
050343	100000	000000	140301	040200	000103	004000

MESSAGE A0 ERROR
AFTER MANUALLY LOADING HEADS WITH DOOR OPEN

TEST NO.	PC					
000010	015736					
	EXPECT					
A0	B0	A1	B1	A2	B2	B3
100143	100000	000543	000001			
	ACTUAL					
050343	100000	001723	000001			
RKCS1	RKCS2	RKASOF	RKER	RKDS	RKDC	
040200	000103	004000	000000	140301	000000	

THE ABOVE EXAMPLE SHOWS EXPECTED & ACTUAL DATA FOR MESSAGE REGISTERS A0, B0, A1 & B1.

MESSAGES A2, B2 & B3 WILL BE TYPED OUT ONLY AS REQUIRED IF THE CYLINDER DIFFERENCE/OFFSET, CYLINDER ADDRESS & HEAD & SECTOR INFORMATION IS A VARIABLE PARAMETER OF THE TEST.

[END OF DOCUMENT]

z

931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975

167400
000001

```
**** PGM REV 036 ***  
.NLIST CND,MC,MD  
.LIST ME  
.ENABL ABS,AMA  
  
;DEFINE SYSMAC MACROS  
  
$SWR= 167400 ;DEFINE SWITCHES 15,14,13,11,10,9,8  
$TN= 1 ;SET FIRST TEST NO. TO 1  
  
.TITLE CZR6JFO UNIBUS RK6 DR-3  
;*COPYRIGHT (C) 1976,1982  
;*DIGITAL EQUIPMENT CORP.  
;*MAYNARD, MASS. 01754  
*  
;*PROGRAM BY GARY PAPIAZIAN  
*  
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC  
;*PACKAGE (MAINDEC-11-DZQAC-C5), JAN, 1981.  
*  
.SBTTL OPERATIONAL SWITCH SETTINGS  
*  
* SWITCH USE  
* -----  
* 15 HALT ON ERROR  
* 14 LOOP ON TEST  
* 13 INHIBIT ERROR TYPEOUTS  
* 12 ABORT DRIVE AFTER 20 ERRORS  
* 11 INHIBIT ITERATIONS  
* 10 BELL ON ERROR  
* 9 LOOP ON ERROR  
* 8 LOOP ON TEST IN SWR<7:0>  
  
.SBTTL SUMMARY OF STARTING LOCATIONS  
*  
* 200 DEFAULT PARAMETERS  
* 220 INPUT PARAMETERS  
* 240 ODT11  
*
```



```

976 .SBTTL BASIC DEFINITIONS
977
978 ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
979 001100 STACK= 1100
980 .EQUIV EMT,ERROR ;:BASIC DEFINITION OF ERROR CALL
981 .EQUIV IOT,SCOPE ;:BASIC DEFINITION OF SCOPE CALL
982
983 ;*MISCELLANEOUS DEFINITIONS
984 000011 HT= 11 ;:CODE FOR HORIZONTAL TAB
985 000012 LF= 12 ;:CODE FOR LINE FEED
986 000015 CR= 15 ;:CODE FOR CARRIAGE RETURN
987 000200 CRLF= 200 ;:CODE FOR CARRIAGE RETURN-LINE FEED
988 177776 PS= 177776 ;:PROCESSOR STATUS WORD
989 .EQUIV PS,PSW
990 177774 STKLMT= 177774 ;:STACK LIMIT REGISTER
991 177772 PIRQ= 177772 ;:PROGRAM INTERRUPT REQUEST REGISTER
992 177570 DSWR= 177570 ;:HARDWARE SWITCH REGISTER
993 177570 DDISP= 177570 ;:HARDWARE DISPLAY REGISTER
994
995 ;*GENERAL PURPOSE REGISTER DEFINITIONS
996 000000 R0= %0 ;:GENERAL REGISTER
997 000001 R1= %1 ;:GENERAL REGISTER
998 000002 R2= %2 ;:GENERAL REGISTER
999 000003 R3= %3 ;:GENERAL REGISTER
1000 000004 R4= %4 ;:GENERAL REGISTER
1001 000005 R5= %5 ;:GENERAL REGISTER
1002 000006 R6= %6 ;:GENERAL REGISTER
1003 000007 R7= %7 ;:GENERAL REGISTER
1004 000006 SP= %6 ;:STACK POINTER
1005 000007 PC= %7 ;:PROGRAM COUNTER
1006
1007 ;*PRIORITY LEVEL DEFINITIONS
1008 000000 PR0= 0 ;:PRIORITY LEVEL 0
1009 000040 PR1= 40 ;:PRIORITY LEVEL 1
1010 000100 PR2= 100 ;:PRIORITY LEVEL 2
1011 000140 PR3= 140 ;:PRIORITY LEVEL 3
1012 000200 PR4= 200 ;:PRIORITY LEVEL 4
1013 000240 PR5= 240 ;:PRIORITY LEVEL 5
1014 000300 PR6= 300 ;:PRIORITY LEVEL 6
1015 000340 PR7= 340 ;:PRIORITY LEVEL 7
1016
1017 ;*'SWITCH REGISTER' SWITCH DEFINITIONS
1018 100000 SW15= 100000
1019 040000 SW14= 40000
1020 020000 SW13= 20000
1021 010000 SW12= 10000
1022 004000 SW11= 4000
1023 002000 SW10= 2000
1024 001000 SW09= 1000
1025 000400 SW08= 400
1026 000200 SW07= 200
1027 000100 SW06= 100
1028 000040 SW05= 40
1029 000020 SW04= 20
1030 000010 SW03= 10
1031 000004 SW02= 4
    
```

```

1032      000002      SW01= 2
1033      000001      SW00= 1
1034      .EQUIV      SW09,SW9
1035      .EQUIV      SW08,SW8
1036      .EQUIV      SW07,SW7
1037      .EQUIV      SW06,SW6
1038      .EQUIV      SW05,SW5
1039      .EQUIV      SW04,SW4
1040      .EQUIV      SW03,SW3
1041      .EQUIV      SW02,SW2
1042      .EQUIV      SW01,SW1
1043      .EQUIV      SW00,SW0
  
```

```

1045      ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
1046      100000      BIT15= 100000
1047      040000      BIT14= 40000
1048      020000      BIT13= 20000
1049      010000      BIT12= 10000
1050      004000      BIT11= 4000
1051      002000      BIT10= 2000
1052      001000      BIT09= 1000
1053      000400      BIT08= 400
1054      000200      BIT07= 200
1055      000100      BIT06= 100
1056      000040      BIT05= 40
1057      000020      BIT04= 20
1058      000010      BIT03= 10
1059      000004      BIT02= 4
1060      000002      BIT01= 2
1061      000001      BIT00= 1
1062      .EQUIV      BIT09,BIT9
1063      .EQUIV      BIT08,BIT8
1064      .EQUIV      BIT07,BIT7
1065      .EQUIV      BIT06,BIT6
1066      .EQUIV      BIT05,BIT5
1067      .EQUIV      BIT04,BIT4
1068      .EQUIV      BIT03,BIT3
1069      .EQUIV      BIT02,BIT2
1070      .EQUIV      BIT01,BIT1
1071      .EQUIV      BIT00,BIT0
  
```

```

1073      ;*BASIC "CPU" TRAP VECTOR ADDRESSES
1074      000004      ERRVEC= 4          ;; TIME OUT AND OTHER ERRORS
1075      000010      RESVEC= 10         ;; RESERVED AND ILLEGAL INSTRUCTIONS
1076      000014      TBITVEC=14        ;; "T" BIT
1077      000014      TRTVEC= 14         ;; TRACE TRAP
1078      000014      BPTVEC= 14         ;; BREAKPOINT TRAP (BPT)
1079      000020      IOTVEC= 20         ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
1080      000024      PWRVEC= 24         ;; POWER FAIL
1081      000030      EMTVEC= 30         ;; EMULATOR TRAP (EMT) **ERROR**
1082      000034      TRAPVEC=34        ;; "TRAP" TRAP
1083      000060      TKVEC= 60          ;; TTY KEYBOARD VECTOR
1084      000064      TPVEC= 64          ;; TTY PRINTER VECTOR
1085      000240      PIRQVEC=240       ;; PROGRAM INTERRUPT REQUEST VECTOR
  
```

.SBTTL RK06 CONTROLLER REGISTER DEFINITION


```

1088
1089
1090
1091      000000      RKCS1= 0      ;CONTROL AND STATUS REGISTER 1
1092      000002      RKWC= 2      ;WORD COUNT REGISTER
1093      000004      RKBA= 4      ;BUS ADDRESS REGISTER
1094      000006      RKDA= 6      ;DESIRED TRACK SECTOR REGISTER
1095      000010      RKCS2= 10     ;CONTROL AND STATUS REGISTER 2
1096      000012      RKDS= 12     ;DRIVE STATUS REGISTER
1097      000014      RKER= 14     ;ERROR REGISTER
1098      000016      RKASOF= 16    ;ATTENTION SUMMARY AND OFFSET REGISTER
1099      000020      RKDC= 20     ;DESIRED CYLINDER REGISTER
1100      000024      RKDB= 24     ;DATA BUFFER
1101      000026      RKMR1= 26    ;MAINTENANCE REGISTER 1
1102      000034      RKMR2= 34    ;MAINTENANCE REGISTER 2 (MESSAGE LINE A)
1103      000036      RKMR3= 36    ;MAINTENANCE REGISTER 3 (MESSAGE LINE B)
1104      000030      RKECPS= 30   ;ECC POSITION INFORMATION
1105      000032      RKECPT= 32   ;ECC PATTERN INFORMATION
1106
1107      .SBTTL CONTROL AND STATUS REGISTER 1 BITS (RKCS1:0)
1108
1109      ; DRIVE COMMANDS
1110
1111      000001      SELDRV= 1      ;SELECT DRIVE (GET STATUS)
1112      000003      PACK= 3       ;PACK ACKNOWLEDGE
1113      000005      CLEAR= 5      ;DRIVE CLEAR
1114      000007      UNLOAD= 7     ;UNLOAD
1115      000011      SRTSPL= 11    ;START SPINDLE
1116      000013      RECAL= 13    ;RECALIBRATE
1117      000015      OFFSET= 15   ;OFFSET
1118      000017      SEEK= 17     ;SEEK
1119      000021      RDDATA= 21    ;READ DATA
1120      000023      WRDATA= 23    ;WRITE DATA
1121      000025      RDHEAD= 25   ;READ HEADER
1122      000027      WRHEAD= 27   ;WRITE HEADER AND DATA
1123      000031      WRTCHK= 31   ;WRITE CHECK
1124
1125      000001      GO= BIT0      ;GO BIT
1126      000100      IE= BIT6      ;INTERRUPT ENABLE
1127      000200      RDY= BIT7     ;CONTROLLER READY
1128      000400      BA16= BIT8    ;BUS ADDRESS BIT 16
1129      001000      BA17= BIT9    ;BUS ADDRESS BIT 17
1130      002000      CDT= BIT10   ;CONTROLLER DRIVE TYPE (0=RK06,1=RK07)
1131      004000      CTO= BIT11   ;CONTROLLER TIMEOUT
1132      010000      CFMT= BIT12  ;CONTROLLER DRIVE FORMAT (0=22 SECTOR, 1=20 SECTOR)
1133      020000      DCPAR= BIT13  ;SERCON PARITY ERROR DETECTED BY CONTROLLER
1134      040000      DI= BIT14    ;DRIVE INTERRUPT
1135      100000      CERR= BIT15   ;CONTROLLER ERROR
1136      100000      CCLR= BIT15   ;CONTROLLER CLEAR
1137
1138      .SBTTL CONTROL AND STATUS REGISTER 2 BITS (RKCS2:10)
1139
1140      000007      DRVMSK= 7      ;MASK FOR DRIVE SELECTION CODE
1141      000010      RLS= BIT3     ;DESELECT OR RELEASE DRIVE IN BITS 0-2
1142      000020      BAI= BIT4     ;BUS ADDRESS INCREMENT INHIBIT
1143      000040      SCLR= BIT5     ;SUBSYSTEM CLEAR CONTROLLER AND ALL DRIVES

```

1144	000100	IR=	BIT6	:INPUT READY
1145	000200	OR=	BIT7	:OUTPUT READY
1146	000400	UFE=	BIT8	:UNIT FIELD ERROR
1147	001000	MDS=	BIT9	:MULTIPLE DRIVE SELECT
1148	002000	PGE=	BIT10	:PROGRAMMING ERROR
1149	004000	NEM=	BIT11	:NON-EXISTENT MEMORY
1150	010000	NED=	BIT12	:NON-EXISTENT DRIVE
1151	020000	UPE=	BIT13	:UNIBUS PARITY ERROR
1152	040000	WCE=	BIT14	:WRITE CHECK ERROR
1153	100000	DLT=	BIT15	:DATA LATE ERROR
1154				
1155		.SBTTL	ERROR REGISTER BIT DEFINITION (RKER:14)	
1156				
1157	000001	ILF=	BIT0	:ILLEGAL FUNCTION CODE
1158	000002	SKI=	BIT1	:SEEK INCOMPLETE
1159	000004	NXF=	BIT2	:NON-EXECUTABLE FUNCTION
1160	000010	DRPAR=	BIT3	:DRIVE DETECTED SERCON PARITY ERROR
1161	000020	FMTE=	BIT4	:FORMAT ERROR
1162	000040	DTYPE=	BIT5	:DRIVE TYPE ERROR
1163	000100	ECH=	BIT6	:ECC HARD
1164	000200	BSE=	BIT7	:BAD SECTOR ERROR
1165	000400	HVRC=	BIT8	:HEADER VRC ERROR
1166	001000	COE=	BIT9	:CYLINDER ADDRESS OVERFLOW ERROR
1167	002000	IDAE=	BIT10	:INVALID DISK ADDRESS ERROR: HEAD/CYL
1168	004000	WLE=	BIT11	:WRITE LOCK ERROR
1169	010000	DTE=	BIT12	:DRIVE TIMING ERROR
1170	020000	OPI=	BIT13	:OPERATION (SEARCH) INCOMPLETE
1171	040000	UNS=	BIT14	:DRIVE UNSAFE

1172	100000	DCK= BIT15	:DATA CHECK
1173			
1174		.SBTTL STATUS REGISTER BIT DEFINITION (RKDS:12)	
1175			
1176	000001	DRA= BIT0	:DRIVE AVAILABLE (CONTROLLER IS SET IF : THIS BIT IS RESET)
1177			
1178	000004	OFST= BIT2	:DRIVE OFFSET
1179	000010	ACLO= BIT3	:AC LOW
1180	000020	DCLO= BIT4	:DC LOW
1181	000040	DROT= BIT5	:DRIVE OFF TRACK
1182	000100	VV= BIT6	:VOLUME VALID
1183	000200	DRDY= BIT7	:DRIVE READY
1184	000400	DDT= BIT8	:DRIVE TYPE (0=RK06,1=RK07)
1185	004000	WRL= BIT11	:WRITE LOCK
1186	020000	PIP= BIT13	:POSITIONING IN PROGRESS
1187	040000	DSC= BIT14	:DRIVE STATUS CHANGE
1188	100000	SVAL= BIT15	:STATUS VALID
1189			
1190		.SBTTL MAINTENANCE REGISTER 1 BIT DEFINITION (RKMR1:22)	
1191			
1192	000017	MESMSK= 17	:MESSAGE MASK
1193	000020	PAT= BIT4	:FORCE EVEN PARITY ON SERCON MESSAGE LINES
1194	000040	DMD= BIT5	:DIAGNOSTIC MODE
1195	000100	MSP= BIT6	:MAINTENANCE SECTOR PULSE
1196	000200	MIND= BIT7	:MAINTENANCE INDEX
1197	000400	MCLK= BIT8	:MAINTENANCE CLOCK
1198	001000	MERD= BIT9	:MAINTENANCE ENCODED READ DATA
1199	002000	MEWD= BIT10	:MAINTENANCE ENCODED WRITE DATA
1200	004000	PCA= BIT11	:PRECOMPENSATION ADVANCE
1201	010000	PCD= BIT12	:PRECOMPENSATION DELAY
1202	020000	ECCW= BIT13	:ECC WORD IS BEING READ OR WRITTEN
1203	040000	WRTGAT= BIT14	:WRITE GATE
1204	100000	RDGATE= BIT15	:READ GATE
1205			
1206		.SBTTL DEFINITION OF DRIVE STATUS BYTE 00 MESSAGE A (RKMR2:34)	
1207			
1208	000040	D.DRA= BIT5	:DRIVE AVAILABLE
1209	000100	D.VV= BIT6	:VOLUME VALID
1210	000200	D.DRDY= BIT7	:DRIVE READY
1211	000400	D.DDT= BIT8	:DRIVE TYPE (0=RK06,1=RK07)
1212	001000	D.FORM= BIT9	:DRIVE FORMAT
1213	002000	D.OFF= BIT10	:OFFSET ON
1214	004000	D.WRL= BIT11	:WRITE LOCK
1215	010000	D.SPIN= BIT12	:SPINDLE ON
1216	020000	D.PIP= BIT13	:POSITIONING IN PROGRESS
1217	040000	D.DSC= BIT14	:DRIVE STATUS CHANGE
1218			
1219		.SBTTL DEFINITION OF DRIVE STATUS BYTE 01 MESSAGE A (RKMR2:34)	
1220			
1221	000020	D.SSP= BIT4	:SERVO SIG PRESENT
1222	000040	D.HDHM= BIT5	:HEADS HOME
1223	000100	D.BRHM= BIT6	:BRUSHES HOME
1224	000200	D.DOOR= BIT7	:DOOR INTERLOCKED
1225	000400	D.CART= BIT8	:CARTRAGE INTERLOCK
1226	001000	D.SPOK= BIT9	:SPEED OK
1227	002000	D.FWD= BIT10	:FORWARD

1228	004000	D.REV= BIT11	:REVERSE
1229	010000	D.LOAD= BIT12	:HEADS LOADING
1230	020000	D.RTZ= BIT13	:RETURN TO ZERO
1231	040000	D.UNLD= BIT14	:HEADS UNLOADING
1232			
1233		.SBTTL DEFINITION OF DRIVE STATUS BYTE 00 MESSAGE B (RKMR3:36)	
1234			
1235	000040	D.IDAE= BIT5	:INVALID DISK ADDRESS ERROR:HEAD/CYL
1236	000100	D.ACLO= BIT6	:AC LOW
1237	000200	D.FLT= BIT7	:DRIVE FAULT
1238	000400	D.NXF= BIT8	:NON-EXECUTABLE FUNCTION CODE
1239	001000	D.PAR= BIT9	:DRIVE DETECTED SERCON PARITY ERROR
1240	002000	D.SKI= BIT10	:SEEK INCOMPLETE
1241	004000	D.WLE= BIT11	:WRITE LOCK ERROR
1242	010000	D.SPLS= BIT12	:SPEED LOSS
1243	020000	D.DROT= BIT13	:DRIVE OFF TRACK
1244	040000	D.UNS= BIT14	:R/W UNSAFE
1245			
1246		.SBTTL DEFINITION OF DRIVE STATUS BYTE 01 MESSAGE B (RKMR3:36)	
1247			
1248	000020	D.SECT= BIT4	:SECTOR ERROR
1249	000040	D.WCUR= BIT5	:WRITE CURRENT AND NO WRITE GATE
1250	000100	D.WGAT= BIT6	:WRITE GATE AND NO TRANSISTIONS
1251	000200	D.HDFL= BIT7	:HEAD FAULT
1252	000400	D.MHD= BIT8	:MULTIPLE HEAD SELECT
1253	001000	D.XERR= BIT9	:INDEX ERROR
1254	002000	D.TIB= BIT10	:TRIBIT ERROR
1255	004000	D.PLO= BIT11	:PLO ERROR
1256	010000	D.NMOV= BIT12	:SEEK AND NO MOTION
1257	020000	D.LIMD= BIT13	:LIMIT DETECT ON SEEK
1258	040000	D.SUNS= BIT14	:SERVO UNSAFE
1259			
1260		.SBTTL COMMON MASKS AND OTHER BITS: MESSAGE A (RKMR2:34)	
1261			
1262	000007	M.DRV= 7	:DRIVE CODE, ALL BYTES
1263	077770	M.SER= 77770	:DRIVE SERIAL #, BYTE 11
1264			
1265		.SBTTL COMMON MASKS AND OTHER BITS: MESSAGE B (RKMR3:36)	
1266			
1267	000003	M.ID= 3	:BYTE ID, ALL BYTES
1268	040000	M.ALGN= BIT14	:ALIGN SIGN, BYTE 10
1269	000760	M.SECT= 760	:SECTOR COUNT, BYTE 11
1270	007000	M.HEAD= 7000	:HEAD DECODE, BYTE 11
1271	100000	M.PAR= BIT15	:PARITY, MESS A/B, ALL BYTES


```
1272  
1273  
1274  
1275          000000  
1276  
1277  
1278  
1279          000174  
1280 000174 000000  
1281 000176 000000  
1282  
1283 000200 000137 010012  
1284          000220  
1285 000220 000137 010002  
1286  
1287          000240  
1288 000240 000137 055504  
1289  
1290  
1291  
1292  
1293  
1294          000244  
1295          000046  
1296 000046 024022  
1297          000052  
1298 000052 120000  
1299          000244  
1300          001000  
1301  
1302  
1303  
1304  
1305  
1306          001000  
1307          000024  
1308 000024 000200  
1309          000044  
1310 000044 001000  
1311          001000  
1312  
1313  
1314  
1315  
1316 001000  
1317 001000 000000  
1318 001002 001210  
1319 001004 000454  
1320 001006 001130  
1321 001010 001130  
1322 001012 000052  
1323  
1324  
1325  
1326  
1327
```

```
.SBTTL TRAP CATCHER  
      .=0  
      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"  
      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS  
      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS  
      .=174  
DISPREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER  
SWREG:   .WORD 0          ;;SOFTWARE SWITCH REGISTER  
.SBTTL STARTING ADDRESS(ES)  
      JMP @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM  
      .=220  
      JMP PARSRT          ;INPUT ALL PARAMETERS & START TESTING  
      .=240  
      JMP O.ODT           ;ENTER ODT11  
.SBTTL ACT11 HOOKS  
      ;*****  
      ;HOOKS REQUIRED BY ACT11  
      $SVPC=.             ;SAVE PC  
      .=46  
      $ENDAD              ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP  
      .=52  
      .WORD 120000        ;;2)SET LOC.52 TO 120000  
      .=$SVPC             ;; RESTORE PC  
      .=1000  
.SBTTL APT PARAMETER BLOCK  
      ;*****  
      ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT  
      ;*****  
      .SX=.              ;;SAVE CURRENT LOCATION  
      .=24               ;;SET POWER FAIL TO POINT TO START OF PROGRAM  
      200                ;;FOR APT START UP  
      .=44               ;;POINT TO APT INDIRECT ADDRESS PNTR.  
      $APTHDR            ;;POINT TO APT HEADER BLOCK  
      .=$X               ;;RESET LOCATION COUNTER  
      ;*****  
      ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC  
      ;INTERFACE SPEC.  
$APTHD:  
$HIBTS: .WORD 0          ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.  
$MBADR: .WORD $MAIL      ;;ADDRESS OF APT MAILBOX (BITS 0-15)  
$TSTM:  .WORD 300.       ;;RUN TIM OF LONGEST TEST  
$PASTM: .WORD 600.       ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)  
$UNITM: .WORD 600.       ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT  
      .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)  
.LIST MD  
;
```

1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383

```
:USE LOOP X TO OMIT SUBCLR
:
.MACRO LOOP A
      SCOP1
      MOV #STACK,SP ;RESTORE STK PTR
:
:IF B A
      JSR PC,SUBCLR
      ERROR 24 ;CERR AFTER SCLR
:
.ENDC
.ENDM LOOP

:
:THIS MACRO FILLS EXPECTED MSG A0, B0, A1, B1, A2, B2 & B3 WITH STANDARD
:BITS SEE A=D.DSC AFTER ATTN OR 0 AFTER DRIVE CLEAR OR ANY IMPLIED SEEKS
:NOTE: A CAN BE ANY BIT COMBINATION DESIRED.
:
.MACRO F.EAB A
      MOV #<A!D.SPIN!D.DRDY!D.VV!D.DRA>,E.A0 ;EXPECTED MSG A0
      CLR E.B0 ;EXPECTED MSG B0
      MOV #<D.SPOK!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1 ;EXPECTED A1
      MOV #1,E.B1 ;MSG ID FOR EXPECTED MSG B1
      CLR E.A2 ;EXPECTED MSG A2
      MOV #2,E.B2 ;MSG ID FOR EXPECTED MSG B2
      MOV #3,E.B3 ;MSG ID FOR EXPECTED MSG B3
.ENDM F.EAB

:
:THIS MACRO ASSUMES DRIVE MSG A0, B0, A1, B1 WILL ALWAYS BE TESTED
:USE A,C,D,E FOR MSG A0, B0, A1, B1 ERROR NUMBERS RESP.
:USE G=T.A2 TO READ MSG A2 & PUT INFO INTO 'CYLDIF'
: H=T.B2 TO READ MSG B2 & PUT INFO INTO 'CYLADD'
: I=T.B3 TO READ MSG B3 & PUT INFO INTO 'SECTOR' & 'HEAD'
:
:USE F=<ERROR DESCRIPTION>
:
.MACRO CHECK A,C,D,E,F,G,H,I
      JSR PC,CHKMSG ;CHECK MSGS A0, B0, A1, B1
      .WORD G!H!I ;& MSGS SPECIFIED HERE
      ERROR A ;MSG A0 ERROR F
      ERROR C ;MSG B0 ERROR
      ERROR D ;MSG A1 ERROR
      ERROR E ;MSG B1 ERROR
.ENDM CHECK

:
:A=CYL DIFF/OFFSET ERROR #
:B=CYL ADDR ERROR #
:C=<ERROR DESCRIPTION>
:
.MACRO CWD2 A,B,C,?D,?E
      MOV #2,RKMR1(R5) ;SELECT WD 2
```


1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439

```

      JSR      PC,GSTAT
      TST     CYLDIF      ;SEE IF MSG A2=0
      BEQ     D           ;BR IF YES
      ERROR   A           ;MSG A2 NOT CLEARED C
D:    TST     CYLADD      ;SEE IF MSG B2=0
      BEQ     E           ;BR IF YES
      ERROR   B           ;MSG B2 NOT CLEARED C
E:
.ENDM  CWD2

.MACRO DRCLR  ?A
      MOV     #CCLR,RKCS1(R5)
      MOV     $UNIT,RKCS2(R5) ;DRIVE#
      MOV     #CLEAR,HCS1
      JSR     PC,DOCMD      ;DO DRIVE CLEAR CMD & GET CONTR RDY
      ERROR   151          ;NO RDY AFTER DRIVE CLEAR CMD
      JSR     PC,TSTATN    ;TEST FOR ATTN
      BR      A
      ERROR   154          ;ATTN NOT CLEARED AFTER DRIVE CLEAR CMD
A:
.ENDM  DRCLR

.MACRO CALIB  ?A
      MOV     #CCLR,RKCS1(R5)
      MOV     $UNIT,RKCS2(R5)
      MOV     #RECAL,HCS1
      JSR     PC,DOCMD      ;DO RECAL CMD & GET CONTR RDY
      ERROR   124          ;RDY NOT SET AFTER RECAL CMD
      MOV     #1,RKMR1(R5) ;SELECT WORD 1
      JSR     PC,GSTAT
      BIT     #D.RTZ,HMR2
      BNE    A
      ERROR   214          ;RTZ NOT SET DURING RECAL CMD
A:    MOV     T10,TEMP2    ;SETUP TIMEOUT
      JSR     PC,FATT1     ;FIND ATTN
      ERROR   55          ;NO ATTN AFTER RECAL CMD
      DRCLR
.ENDM  CALIB

:
: A=WRHEAD/<CFMT!WRHEAD>
: USE WRHDR <A>,X TO OMIT CHECKING A0, B0, A1, B1
:
.MACRO WRHDR  A,C,?D
      MOV     #<A>,HCS1
      JSR     PC,DATCMD    ;DO DATA X FOR CMD & GET CONTR RDY
      ERROR   200          ;NO RDY AFTER WRITE HEADER CMD
      JSR     PC,GSTAT    ;GET FRESH STATUS
      BIT     #CERR,HCS1
  
```

1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495

```

      BEQ      D
      ERROR   201                ;CERR AFTER WRITE HEADER CMD
D:
  .IF B      C
      F.EAB   0
      CHECK   215,216,217,220,<AFTER WRITE HEADER CMD>,0,0,0
  .ENDC
  .ENDM     WRHDR

  :
  : A=RDHEAD/<CFMT!RDHEAD>
  : USE RDHDR <A>,X TO OMIT CHECKING A0, B0, A1, B1
  :
  .MACRO    RDHDR    A,C,?D,?E
      MOV     #RHTAB,R0
      MOV     #<A>,HCS1
      JSR    PC,DATCMD          ;DO DATA X FOR CMD & GET CONTR RDY
      ERROR  171                ;NO RDY AFTER READ HEADER CMD
      BIT    #CERR,HCS1
      BEQ    D
      ERROR  174                ;CERR AFTER READ HEADER CMD
      TYPE   ,MSG26            ;ABORTING DATA TESTS TO DO TIMING TESTS
      JMP    TIMING

D:      MOV    RKDB(R5),(R0)+    ;1'ST WORD FROM SILO TO RHTAB
      MOV    RKDB(R5),(R0)+    ;2'ND WORD
      MOV    RKDB(R5),(R0)+    ;3'RD WORD

      BIT    #DLT,RKCS2(R5)
      BEQ    E
      JSR    PC,GSTAT
      ERROR  173                ;DLT AFTER READ HEADER CMD
E:
  .IF      B      C
      NOP
  .ENDC
  .ENDM     RDHDR

  .MACRO    HDCHK3    ?A
      RDHDR   RDHEAD,X
      CMP     RHTAB,TOCYL      ;CHECK WORD 0 ONLY, CYL#
      BEQ    A                  ;BR IF SAME
      ERROR  51                ;WRONG CYL# ON HEADER
A:
  .ENDM     HDCHK3

  :
  : A=TOCYL/FRCYL , B=HEAD#, C = 0 FOR 22 SECTOR, 1 FOR 20 SECTOR
  :

```



```

1496 .MACRO HDTBL A,B,C
1497
1498     MOV A,CALADD      ;SETUP
1499     MOV #B,HEAD      ;TO FILL
1500     MOV #C,FORMAT     ;HEADER
1501     JSR PC,FHDTAB     ;TABLE
1502
1503 .ENDM HDTBL
1504
1505 ;
1506 ;QUICK SEEK. ENTER WITH CYL# IN RKDC
1507 ;
1508 .MACRO QKSEEK ?A
1509
1510     MOV #SEEK,HCS1
1511     JSR PC,DOCMD      ;DO SEEK CMD & GET CONTR READY
1512     ERROR 131         ;NO RDY AFTER SEEK CMD
1513
1514     MOV T50000,TEMP1 ;SETUP TIMEOUT
1515     JSR PC,FATT2      ;FIND ATTN
1516     ERROR 132         ;NO ATTN AFTER SEEK CMD
1517
1518     BIT #CERR,HCS1
1519     BEQ A
1520     ERROR 210         ;CERR AFTER SEEK CMD
1521
1522 A:
1523
1524 .ENDM QKSEEK
1525
1526 ;
1527 ;A=WRDATA/<CFMT!WRDATA>
1528 ;C=ADDR TO JMP TO ATTEMPT TO WRITE ON ANOTHER SECTOR
1529 ;D=ADDR TO JMP TO BYPASS TEST
1530 ;E: IF BLANK WILL CHECK A0, B0, A1 & B1 AT THE END OF WRITING
1531 ;E: IF NON BLANK WILL OMIT CHECKING A0 THRU B1
1532 ;
1533 ;
1534 ;
1535 .MACRO WDATA A,C,D,E,?F,?G,?H,?I
1536
1537     MOV #<A>,HCS1
1538     JSR PC,DATCMD     ;DO DATA X FOR CMD & GET CONTR RDY
1539     ERROR 11         ;NO RDY AFTER WRITE DATA CMD
1540     JSR PC,GSTAT      ;GET FRESH STATUS
1541     BIT #CERR,HCS1
1542     BEQ I             ;BR IF NO ERRORS
1543
1544     BIT #BSE,HER      ;SEE IF BAD SECTOR FLAG
1545     BEQ G             ;BR IF NO
1546     JSR PC,TRUERR     ;ELSE SEE IF SECTOR LISTED IN BSE TABLE
1547     BR H              ;RETURN HERE IF NO
1548
1549     INC SECTOR
1550     CMP SECTOR,#10.  ;RETURN HERE IF YES
1551     BNE F             ;ARE 10 CONSEC. SECTORS BAD
                     ;BR IF NO

```

```

1552          ERROR 40          ;ABORTING TEST DETECTED 10 BAD SECTORS
1553          JMP    D          ;BYPASS TEST
1554
1555 F:        MOV    #CCLR,RKCS1(R5) ;TRY ANOTHER SECTOR
1556          JMP    C
1557
1558 G:        ERROR 12          ;CERR WITH WRITE DATA CMD
1559          F.EAB 0
1560          CHECK 52,23,53,25,<AFTER WRITE DATA CMD>,T.A2,T.B2,0
1561          TYPE  ,MSG72      ;ABORTING BALANCE OF TESTS
1562          JMP    $EOP
1563 H:        ERROR 47          ;BAD SECTOR NOT LISTED IN TABLE
1564 I:
1565 .IF      B      E
1566          F.EAB 0
1567          CHECK 52,23,53,25,<AFTER WRITE DATA CMD>,T.A2,T.B2,0
1568 .ENDC
1569 .ENDM    WDATA
1570
1571
1572 ;
1573 ;A=RDDATA/<CFMT!RDDATA>
1574 ;USE RDATA <A>,X TO OMIT CKWD12
1575 ;
1576
1577 .MACRO   RDATA  A,C,?D,?E,?F,?G,?H
1578
1579          MOV    #<A>,HCS1
1580          JSR   PC,DATCMD      ;DO DATA X FOR CMD & GET CONTR RDY
1581          ERROR 13          ;NO RDY AFTER READ DATA CMD
1582          JSR   PC,GSTAT      ;GET FRESH STATUS
1583          BIT   #CERR,HCS1
1584          BEQ   G
1585          BIT   #BSE,HER      ;SEE IF BAD SECTOR
1586          BEQ   E
1587          ERROR 50          ;DETECTED BSE IN READ BUT NOT IN WRITE CMD.
1588          BR    H
1589 D:        TYPE  ,MSG72      ;ABORTING BALANCE OF TESTS
1590          JMP    $EOP
1591
1592 E:        BIT   #DCK,HER      ;SEE IF DATA CHECK ERROR
1593          BEQ   F
1594          ERROR 21          ;DATA CHECK ERROR AFTER READ CMD (ECC)
1595          BR    H
1596
1597 F:        ERROR 14          ;CERR AFTER READ DATA CMD.
1598
1599 H:        F.EAB 0
1600          CHECK 54,26,56,30,<AFTER READ DATA CMD>,T.A2,T.B2,0
1601          BR    D
1602
1603 G:
1604 .IF      B      C
1605          F.EAB 0
1606          CHECK 54,26,56,30,<AFTER READ DATA CMD>,T.A2,T.B2,0
1607 .ENDC
  
```


1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663

```
.ENDM RDATA

;
;A=WRTCHK/<CFMT!WRTCHK>
;C=16 FOR STD ERROR MSG
;C=134/135/136/137 FOR ERROR MSG USED IN 'SBOUND' ROUTINE
;USE WRCHK <A>,C,X TO OMIT CKWD12
;

.MACRO WRCHK A,C,D,?E,?F

    MOV #<A>,HCS1
    JSR PC,DATCMD ;DO DATA X FOR CMD & GET CONTR RDY
    ERROR 15 ;NO RDY AFTER WRITE CHECK CMD
    JSR PC,GSTAT ;GET FRESH STATUS
    BIT #CERR,HCS1
    BEQ F
    BIT #WCE,HCS2 ;SEE IF WRITE CHECK ERROR
    BEQ E
    MOV RKDB(R5),WD1 ;ACTUAL WORD FOR PRINTOUT
    ERROR C ;WCE AFTER WRITE CMD
    BR F

E:    ERROR 22 ;CERR AFTER WRITE CHECK CMD
    F.EAB 0
    CHECK 57,31,60,32,<AFTER WRITE CHECK CMD>,T.A2,T.B2,0
    TYPE ,MSG72 ;ABORTING BALANCE OF TESTS
    JMP ENDRV

F:
    .IF B D
    F.EAB 0
    CHECK 57,31,60,32,<AFTER WRITE CHECK CMD>,T.A2,T.B2,0

.ENDC
.ENDM WRCHK

;
;MACRO TO TEST THAT WRITE CHECK OCCURRED AT SECTOR BOUNDRY
;A&B=134,135 FOR WRITE PROTECT SW TEST
;A&B=136,137 FOR AC LOW TEST PART 2
;C=JUMP ADDR TO REPEAT TEST
;

.MACRO SBOUND A,B,C,?D,?E,?F,?G,?H,?I,?J,?K

    JSR PC,SUBCLR
    ERROR 24 ;CERR AFTER SCLR

    TST $TMP2
    BEQ K ;SEE IF TRK/SECTOR 0
    CMP $TMP2,#1023 ;REPEAT,NO NEW DATA XFER TOOK PLACE
    BEQ K ;SEE IF TRK 2,SECTOR 19
    BIT #BIT0,$TMP1 ;REPEAT,NO OLD DATA TO CHECK AGAINST
    BNE D ;BR IF WRITING 1'S WHEN WLE OCCURRED
    MOV #DATA1,RKBA(R5) ;WRITING 0'S:WLE SECTOR SHOULD HAVE ALL 1'S
    BR E
```

```

1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719

K:      JMP      C
D:      MOV      #DATA0,RKBA(R5) ;WRITING 1'S:WLE SECTOR SHOULD HAVE ALL 0'S
E:      BIS      #BAI,RKCS2(R5)
        MOV      #-256.,RKWC(R5)
        MOV      $TMP3,RKDA(R5) ;REFRESH RKDA
        MOV      @RKBA(R5),WD2 ;EXPECTED WORD FOR TRUERR TYPEOUT
        MOV      TOCYL,RKDC(R5)
        WRCHK    WRTCHK,A,X
        NOP
        NOP

F:      CMP      $TMP2,#400 ;SEE IF WRL AT TRK 1, SECTOR 0
        BNE      F ;BR IF NO
        MOV      #21.,RKDA(R5) ;ELSE SECTOR BEFORE WRL IS TRK 0, SEC 21
        BR      H
        CMP      $TMP2,#1000 ;SEE IF WRL AT TRK 2,SECTOR 0
        BNE      G ;BR IF NO
        MOV      #425,RKDA(R5) ;ELSE SECTOR BEFORE WRL IS TRK 1, SEC 21
        BR      H

G:      DEC      $TMP2 ;GET SECTOR BEFORE WRL
H:      MOV      $TMP2,RKDA(R5)
        MOV      RKDA(R5),$TMP3 ;FOR ERROR PRINTOUT
        BIT      #BIT0,$TMP1
        BNE      I ;BR IF WRITING 1'S WHEN WLE OCCURRED
        MOV      #DATA0,RKBA(R5) ;WRITING 0'S:WLE SECTOR -1 SHOULD HAVE ALL 0'S
        BR      J

I:      MOV      #DATA1,RKBA(R5) ;WRITING 1'S:WLE SECTOR -1 SHOULD HAVE ALL 1'S
J:      BIS      #BAI,RKCS2(R5)
        MOV      #-256.,RKWC(R5)
        MOV      @RKBA(R5),WD2 ;EXPECTED WORD FOR TRUERR TYPEOUT
        MOV      TOCYL,RKDC(R5)
        WRCHK    WRTCHK,B,X

.ENDM    SBOUND

:
:QUICK START SPINDLE
:
:MACRO   QKSRT   ?A
        JSR     PC,SUBCLR
        ERROR   24 ;CERR AFTER SCLR

        BIT     #D.SPIN,HMR2 ;SEE IF SPINDLE ALREADY ON
        BNE     A ;BR IF YES
        TYPE    ,MSG29 ;PLEASE WAIT, HEADS BEING LOADED

        MOV     #SRTSPL,HCS1
        JSR     PC,DOCMD ;DO START SPINDLE CMD & GET CONTR RDY
        ERROR   143 ;CONTR RDY NOT SET AFTER CMD

        MOV     T100,TEMP2
  
```


1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762

```
      JSR    PC,FATT1      ;FIND ATTN
      ERROR  144          ;NO ATTN AFTER CMD
      CLR    UNLD
A:    .ENDM  QKSRT
      ;
      ;ROUTINE TO ISSUE PACK COMMAND
      ;
      .MACRO QKPACK ?A
      MOV    #CCLR,RKCS1(R5)
      MOV    $UNIT,RKCS2(R5) ;DRIVE #
      MOV    #PACK,HCS1
      JSR    PC,DOCMD      ;DO PACK CMD & GET CONTR RDY
      ERROR  116          ;CONTR NOT RDY
      BIT    #D.VV,HMR2
      BNE   A
      ERROR  27          ;VOLUME VALID NOT SET AFTER PACK CMD
A:    .ENDM  QKPACK
      ;
      ;QUICK UNLOAD
      ;
      .MACRO QKUNLD
      JSR    PC,SUBCLR
      ERROR  24          ;CERR AFTER SCLR
      MOV    #UNLOAD,HCS1
      JSR    PC,DOCMD      ;DO UNLOAD CMD & GET CONTR READY
      ERROR  17          ;NO RDY AFTER UNLD CMD
      JSR    PC,TSTATN
      ERROR  20          ;NO ATTN AFTER UNLOAD CMD
      .ENDM  QKUNLD
      .NLIST MD
```


1819	001212	000000	\$FATAL: .WORD	AFATAL	::FATAL ERROR NUMBER
1820	001214	000000	\$TESTN: .WORD	ATESTN	::TEST NUMBER
1821	001216	000000	\$PASS: .WORD	APASS	::PASS COUNT
1822	001220	000000	\$DEVCT: .WORD	ADEVCT	::DEVICE COUNT
1823	001222	000000	\$UNIT: .WORD	AUNIT	::I/O UNIT NUMBER
1824	001224	000000	\$MSGAD: .WORD	AMSGAD	::MESSAGE ADDRESS
1825	001226	000000	\$MSGLG: .WORD	AMSGLG	::MESSAGE LENGTH
1826	001230		\$ETABLE:		::APT ENVIRONMENT TABLE
1827	001230	000	\$ENV: .BYTE	AENV	::ENVIRONMENT BYTE
1828	001231	000	\$ENVM: .BYTE	AENVM	::ENVIRONMENT MODE BITS
1829	001232	000000	\$SWREG: .WORD	ASWREG	::APT SWITCH REGISTER
1830	001234	000000	\$USWR: .WORD	AUSWR	::USER SWITCHES
1831	001236	000000	\$CPUOP: .WORD	ACPUOP	::CPU TYPE,OPTIONS
1832			::*		BITS 15-11=CPU TYPE
1833			::*		11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
1834			::*		11/70=06,PDQ=07,Q=10
1835			::*		BIT 10=REAL TIME CLOCK
1836			::*		BIT 9=FLOATING POINT PROCESSOR
1837			::*		BIT 8=MEMORY MANAGEMENT
1838	001240	000	\$MAMS1: .BYTE	AMAMS1	::HIGH ADDRESS,M.S. BYTE
1839	001241	000	\$MTYP1: .BYTE	AMTYP1	::MEM. TYPE,BLK#1
1840			::*		MEM.TYPE BYTE -- (HIGH BYTE)
1841			::*		900 NSEC CORE=001
1842			::*		300 NSEC BIPOLAR=002
1843			::*		500 NSEC MOS=003
1844	001242	000000	\$MADR1: .WORD	AMADR1	::HIGH ADDRESS,BLK#1
1845			::*		MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE
1846	001244	000	\$MAMS2: .BYTE	AMAMS2	::HIGH ADDRESS,M.S. BYTE
1847	001245	000	\$MTYP2: .BYTE	AMTYP2	::MEM. TYPE,BLK#2
1848	001246	000000	\$MADR2: .WORD	AMADR2	::MEM.LAST ADDRESS,BLK#2
1849	001250	000	\$MAMS3: .BYTE	AMAMS3	::HIGH ADDRESS,M.S.BYTE
1850	001251	000	\$MTYP3: .BYTE	AMTYP3	::MEM. TYPE,BLK#3
1851	001252	000000	\$MADR3: .WORD	AMADR3	::MEM.LAST ADDRESS,BLK#3
1852	001254	000	\$MAMS4: .BYTE	AMAMS4	::HIGH ADDRESS,M.S.BYTE
1853	001255	000	\$MTYP4: .BYTE	AMTYP4	::MEM. TYPE,BLK#4
1854	001256	000000	\$MADR4: .WORD	AMADR4	::MEM.LAST ADDRESS,BLK#4
1855	001260	000000	\$VECT1: .WORD	AVECT1	::INTERRUPT VECTOR#1,BUS PRIORITY#1
1856	001262	000000	\$VECT2: .WORD	AVECT2	::INTERRUPT VECTOR#2BUS PRIORITY#2
1857	001264	177440	\$BASE: .WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
1858	001266	000000	\$DEVN: .WORD	ADEVN	::DEVICE MAP
1859	001270	000000	\$CDW1: .WORD	ACDW1	::CONTROLLER DESCRIPTION WORD#1
1860	001272	000000	\$CDW2: .WORD	ACDW2	::CONTROLLER DESCRIPTION WORD#2
1861	001274	000000	\$DDW0: .WORD	ADDW0	::DEVICE DESCRIPTOR WORD#0
1862	001276	000000	\$DDW1: .WORD	ADDW1	::DEVICE DESCRIPTOR WORD#1
1863	001300	000000	\$DDW2: .WORD	ADDW2	::DEVICE DESCRIPTOR WORD#2
1864	001302	000000	\$DDW3: .WORD	ADDW3	::DEVICE DESCRIPTOR WORD#3
1865	001304	000000	\$DDW4: .WORD	ADDW4	::DEVICE DESCRIPTOR WORD#4
1866	001306	000000	\$DDW5: .WORD	ADDW5	::DEVICE DESCRIPTOR WORD#5
1867	001310	000000	\$DDW6: .WORD	ADDW6	::DEVICE DESCRIPTOR WORD#6
1868	001312	000000	\$DDW7: .WORD	ADDW7	::DEVICE DESCRIPTOR WORD#7
1869	001314	000000	\$DDW8: .WORD	ADDW8	::DEVICE DESCRIPTOR WORD#8
1870	001316	000000	\$DDW9: .WORD	ADDW9	::DEVICE DESCRIPTOR WORD#9
1871	001320	000000	\$DDW10: .WORD	ADDW10	::DEVICE DESCRIPTOR WORD#10
1872	001322	000000	\$DDW11: .WORD	ADDW11	::DEVICE DESCRIPTOR WORD#11
1873	001324	000000	\$DDW12: .WORD	ADDW12	::DEVICE DESCRIPTOR WORD#12
1874	001326	000000	\$DDW13: .WORD	ADDW13	::DEVICE DESCRIPTOR WORD#13

1875	001330	000000	\$DDW14: .WORD	ADDW14	::DEVICE DESCRIPTOR WORD#14
1876	001332	000000	\$DDW15: .WORD	ADDW15	::DEVICE DESCRIPTOR WORD#15
1877					
1878					
1879	001334		SETEND:		
1880					
1881		177440	ABASE=	177440	:DEFAULT BUSS ADDRESS
1882	001334	000210	RKVEC:	210	:DEFAULT CONTROLLER INTERRUPT VECTOR
1883	001336	000240	RKPRI:	PR5	:PRIORITY
1884	001340	172540	PKS:	172540	:P-CLOCK STATUS REG
1885	001342	172542	PKSB:	172542	:P-CLOCK SET BUFFER
1886	001344	172544	PKRB:	172544	:P-CLOCK READ BUFFER
1887	001346	177546	LKS:	177546	:L-CLOCK STATUS REG.
1888					
1889	001350	000100	LCVEC:	100	:L-CLOCK INTERRUPT VECTOR
1890	001352	000104	PCVEC:	104	:P-CLOCK INTERRUPT VECTOR.
1891					
1892		000114	MEMVEC=	114	:MEMORY PARITY VECTOR
1893		172100	MEMBAS=	172100	:MEMORY PARITY OPTION CSR START ADDR
1894					
1895	001354	000000	TRAPPC:	0	:PC FOR MEMORY PARITY ERROR TRAP
1896					
1897	001356	000000	PARAM:	0	:1 FOR 220 START, NO DEFAULT
1898	001360	000000	FTITLE:	0	:FLAG FOR PRINTING OUT 1ST PROGRAM TITLE
1899					
1900	001362	000000	DRVPTR:	0	:CONTAINS THE POINTER TO THE DRIVE FLAG
1901					: (DRIV0-DRIV7) OF THE DRIVE TO BE CHECKED NEXT.
1902					
1903		000040	SPBAR=	40	:SPACE BAR
1904	001364	000000	FRCYL:	0	:FROM CYLINDER
1905	001366	000000	TOCYL:	0	:TO CYLINDER
1906	001370	000000	CCYL:	0	:CURRENT CYL, USED IN N SQUARE TEST
1907	001372	000000	PCYL:	0	:PREV CYL., USED IN N SQUARE TEST
1908	001374	000000	CALDIF:	0	:CALC CYL DIFF USED IN N SQUARE TEST
1909	001376	000000	CYLDIF:	0	:CYL DIFF, RIGHT JUSTIFIED FROM RKMR3
1910	001400	000000	CYLADD:	0	:CYL ADDR, RIGHT JUSTIFIED FROM RKMR3
1911	001402	000000	CALADD:	0	:CYL ADDR USED IN FHDTAB ROUTINE
1912					
1913	001404	000074	HZ:	60.	:60 FOR 60 CPS
1914					:50 FOR 50 CPS
1915	001406	000000	COUNT:	0	:LOADED TO 50 OR 60 TO COUNT TO 1 SEC
1916					:OR ANY OTHER NUMBER TO COUNT OFF FRACTIONAL SECOND
1917	001410	000000	SEC:	0	:SECOND COUNTER
1918	001412	000000	TIMUP:	0	:FLAG TO INDICATE TIME IS UP
1919	001414	000000	SECNT:	0	:SECTOR COUNT
1920	001416	000000	PSEC:	0	:PREVIOUS SECTOR
1921	001420	000000	ESEC:	0	:EXPECTED SECTOR
1922	001422	000000	SECTOR:	0	:SECTOR COUNT, RIGHT JUSTIFIED FROM RKMR3
1923					
1924	001424	000012	T10:	10.	:TIMEOUT CONSTANTS
1925	001426	000144	T100:	100.	
1926	001430	011610	T5000:	5000.	
1927	001432	141520	T50000:	50000.	
1928					
1929					
1930	001434	000000	WD1:	0	:ACTUAL HEADER/DATA WORD

1931	001436	000000	WD2:	0	:EXPECTED DATA WORD
1932					
1933	001440	000000	OFFERR:	0	:SET WHEN WRITE CHECK ERROR ON OFFSET
1934					
1935					
1936	001442	000000	HEAD:	0	:HEAD NUMBER
1937	001444	000000	HEAD1:	0	:HEAD # FROM H.B3, RT. JUSTIFIED
1938	001446	000000	HD1:	0	:SHIFTED HEAD# FOR FORMATTER ROUTINE
1939	001450	000000	FORMAT:	0	:FORMAT TYPE
1940	001452	000000	FMT1:	0	:SHIFTED FORMAT FOR FORMATTER ROUTINE
1941	001454	000000	WDCNT:	0	:WORD COUNT
1942					
1943	001456	000000	DATA0:	0	:ALL 0'S
1944	001460	052525	DATA01:	52525	:0101 PATT
1945	001462	177777	DATA1:	177777	:ALL 1'S
1946	001464	133467	DPAT1:	133467	
1947	001466	070627	DPAT2:	70627	
1948					
1949	001470	000000	WORD:	0	:HEADER/DATA WORD
1950	001472	000000	HDWD:	0	:HEADER WORD FROM RKDB
1951					
1952	001474	000000	BSERR:	0	:CANNOT READ BSE INFO WHEN SET
1953	001476	000000	LIMERR:	0	:LIMIT DETECT ERROR FLAG
1954	001500	000000	MDSERR:	0	:MULT DRIVE SEL ERROR FLAG
1955	001502	000000	BYPCERR:	0	:SET TO 1 TO BYPASS CKERR IN 'GSTAT1'
1956	001504	000000	CHKFLG:	0	:WORDS TO BE TESTED
1957					
1958	001506	000102	HDTAB:	.BLKW 66.	:CALCULATED HEADER WORD TABLE
1959	001712	000102	RHTAB:	.BLKW 66.	:FILLED AFTER READ HEADER CMD
1960	002116	000102	SRTTAB:	.BLKW 66.	:ABOVE RHTAB SORTED STARTING FORM
1961					:SECTOR 0 BY SORT ROUTINE
1962	002322	000400	BSE22H:	.BLKW 256.	:22 SECTOR HARDWARE BSE INFO.
1963	003322	000400	BSE22S:	.BLKW 256.	:22 SECTOR SOFTWARE BSE INFO.
1964	004322	000400	RDTAB:	.BLKW 256.	:FILLED AFTER READ DATA CMD
1965					
1966	005322	000000	UNLD:	0	:SET TO 0 IF HEADS ARE LOADED
1967					:SET TO 1 IF HEADS UNLOADED
1968	005324	000000	BADHDR:	0	:SET TO 0 IF FORMATTING OK
1969					:SET TO 1 IF FORMATTING ALTERED
1970	005326	000000	HPEND:	0	:SET TO 0 IF HALT NOT PENDING
1971					:SET TO 1 IF HALT PENDING
1972					
1973					:THE ABOVE 3 FLAGS ARE USED
1974					:BY 'STOP' ROUTINE TO BRING
1975					:THE CPU TO A VALID HALT.
1976					
1977					
1978	005330	001	002	004	ATTN: .BYTE 1,2,4,10,20,40,100,200 ;ATN 0-7 RESP.
1979	005333	010	020	040	
1980	005336	100	200		
1981					.EVEN
1982					:
1983					:THE FOLLOWING ARE HOLDING REGISTERS FOR THE RK611 REGISTERS
1984					:THEY ARE LOADED AFTER RDY IS REC'D FROM WRDY ROUTINE.
1985					:
1986					:

1987	005340	000000	HCS1:	0	:HOLD RKCS1
1988	005342	000000	HCS2:	0	:HOLD RKCS2
1989	005344	000000	HWC:	0	:HOLD RKWC
1990	005346	000000	HBA:	0	:ETC.
1991	005350	000000	HDA:	0	
1992	005352	000000	HDS:	0	
1993	005354	000000	HER:	0	
1994	005356	000000	HASOF:	0	
1995	005360	000000	HDC:	0	
1996	005362	000000	HDB:	0	
1997	005364	000000	HMR1:	0	
1998	005366	000000	HMR2:	0	
1999	005370	000000	HMR3:	0	
2000	005372	000000	HPOS:	0	
2001	005374	000000	HPAT:	0	
2002					
2003	005376	000000	TEMP1:	0	:TEMPORARY STORAGE.
2004	005400	000000	TEMP2:	0	
2005	005402	000000	TEMP3:	0	
2006	005404	000000	TEMP4:	0	
2007	005406	000000	TEMP5:	0	
2008			:		
2009			:		:THE FOLLOWING ARE HOLDING REGISTERS FOR MSGA(0-3) & MSGB(0-3).
2010			:		
2011	005410	000000	H.A0:	0	
2012	005412	000000	H.B0:	0	
2013	005414	000000	H.A1:	0	
2014	005416	000000	H.B1:	0	
2015	005420	000000	H.A2:	0	
2016	005422	000000	H.B2:	0	
2017	005424	000000	H.A3:	0	
2018	005426	000000	H.B3:	0	
2019			:		
2020			:		:THE FOLLOWING ARE 'EXPECTED' REGISTER FOR THE ABOVE.
2021			:		
2022	005430	000000	E.A0:	0	
2023	005432	000000	E.B0:	0	
2024	005434	000000	E.A1:	0	
2025	005436	000000	E.B1:	0	
2026	005440	000000	E.A2:	0	
2027	005442	000000	E.B2:	0	
2028	005444	000000	E.A3:	0	
2029	005446	000000	E.B3:	0	
2030			:		
2031			:		:THE FOLLOWING ARE IDENTIFIERS FOR DRIVE MSG WORDS TO BE TESTED.
2032			:		
2033		000001	T.A2=BIT0		:TEST MSG A2 IF SET
2034		000002	T.B2=BIT1		
2035		000004	T.B3=BIT2		
2036			:		
2037			:		:ALL THE FLAGS BELOW ARE CLEARED INITIALLY BY THE CLRFLG ROUTINE.
2038			:		
2039			:		
2040					
2041	005450	000000	DDUMP:	0	:FLAG - SET WHEN IN DDP DUMP MODE
2042	005452	000000	DDPCH:	0	:FLAG - SET WHEN IN DDP CHAIN MODE

2043	005454	000000	ACT11: 0	:FLAG - SET WHEN IN ACT11 MODE OF OPERATION
2044	005456	000000	PPTP: 0	:FLAG - SET WHEN PROGRAM LOADED BY PAPER TAPE
2045	005460	000000	DRIVS: 0	:CONTAINS THE NUMBER OF DRIVES PRESENT
2046				
2047				
2048			:THE FLAGS BELOW ARE SET TO 1 TO INDICATE THAT A PARTICULAR DRIVE	
2049			:IS PRESENT AND IS TO BE TESTED.	
2050	005462	000000	DRIV0: 0	:FLAG SET TO 1 WHEN DRIVE 0 PRESENT
2051	005464	000000	DRIV1: 0	:FOR DRIVE 1
2052	005466	000000	DRIV2: 0	:FOR DRIVE 2
2053	005470	000000	DRIV3: 0	:FOR DRIVE 3
2054	005472	000000	DRIV4: 0	:FOR DRIVE 4
2055	005474	000000	DRIV5: 0	:FOR DRIVE 5
2056	005476	000000	DRIV6: 0	:FOR DRIVE 6
2057	005500	000000	DRIV7: 0	:FOR DRIVE 7
2058				
2059	005502	000000	LCLKF: 0	:L-CLOCK FLAG PRESENT FLAG
2060	005504	000000	PCLKF: 0	:P-CLOCK FLAG PRESENT FLAG
2061	005506	000000	DOTIM: 0	:SET IF EITHER CLOCK PRESENT FOR TIMING TESTS.
2062	005510	000000	SIZFLG: 0	:SET IF DEFAULT DO SIZING IN TEST 1

```
2063 .SBTTL ERROR POINTER TABLE
2064
2065 :*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
2066 :*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
2067 :*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
2068 :*NOTE1: IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
2069 :*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
2070
2071 :* EM ::POINTS TO THE ERROR MESSAGE
2072 :* DH ::POINTS TO THE DATA HEADER
2073 :* DT ::POINTS TO THE DATA
2074 :* DF ::POINTS TO THE DATA FORMAT
2075
2076
2077 005512 $ERRTB:
2078
2079 :ERROR 1
2080 005512 044456 EM2 ;DR # IN RKCS2 CANNOT BE READ BACK CORRECTLY IN RKMR2
2081 005514 051007 DH1
2082 005516 054126 DT1
2083 005520 054550 DF1
2084
2085 :ERROR 2
2086 005522 044675 EM5 ;DETECTED MDS
2087 005524 051007 DH1
2088 005526 054126 DT1
2089 005530 054550 DF1
2090
2091 :ERROR 3
2092 005532 044716 EM6 ;DETECTED UFE
2093 005534 051007 DH1
2094 005536 054126 DT1
2095 005540 054550 DF1
2096
2097 :ERROR 4
2098 005542 044737 EM7 ;DETECTED DRA & NED RESET (WRONG PORT SELECTED?)
2099 005544 051007 DH1
2100 005546 054126 DT1
2101 005550 054550 DF1
2102
2103 :ERROR 5
2104 005552 000000 0
2105 005554 000000 0
2106 005556 000000 0
2107 005560 000000 0
2108
2109 :ERROR 6
2110 005562 045102 EM9 ;DR NOT PRESENT BUT SPECIFIED BY OPERATOR
2111 005564 051007 DH1
2112 005566 054126 DT1
2113 005570 054550 DF1
2114
2115 :ERROR 7
2116 005572 045156 EM10 ;ABORT TEST, COULD NOT REFERENCE CONTROLLER REGISTER
2117 005574 051007 DH1
2118 005576 054126 DT1
2119 005600 054550 DF1
```


2119				
2120			:ERROR 10	
2121	005602	045241	EM11	:DRA & NED BOTH SET
2122	005604	051007	DH1	
2123	005606	054126	DT1	
2124	005610	054550	DF1	
2125			:ERR 11	
2126	005612	045305	EM12	:NO RDY
2127	005614	052074	DH27	:AFTER WRITE DATA CMD
2128	005616	054126	DT1	
2129	005620	054654	DF10	
2130			:ERR 12	
2131	005622	045575	EM21	:CERR SET
2132	005624	052074	DH27	
2133	005626	054126	DT1	
2134	005630	054654	DF10	
2135			:ERR 13	
2136	005632	045305	EM12	:NO RDY
2137	005634	052044	DH26	:AFTER READ DATA CMD
2138	005636	054126	DT1	
2139	005640	054654	DF10	
2140			:ERR 14	
2141	005642	045575	EM21	:CERR SET
2142	005644	052044	DH26	
2143	005646	054126	DT1	
2144	005650	054654	DF10	
2145			:ERR 15	
2146	005652	045305	EM12	:NO RDY
2147	005654	052303	DH32	:AFTER WRITE CHECK CMD
2148	005656	054126	DT1	
2149	005660	054654	DF10	
2150			:ERR 16	
2151	005662	050650	EM80	:WRITE CHECK ERROR SET
2152	005664	052303	DH32	:AFTER WRITE CHECK CMD
2153	005666	054126	DT1	
2154	005670	054654	DF10	
2155			:ERR 17	
2156	005672	045305	EM12	:CONTR NOT RDY
2157	005674	051604	DH18	:AFTER UNLD CMD
2158	005676	054126	DT1	
2159	005700	054654	DF10	
2160			:ERR 20	
2161	005702	045343	EM13	:NO ATTN
2162	005704	051604	DH18	
2163	005706	054126	DT1	
2164	005710	054654	DF10	
2165			:ERR 21	
2166	005712	050707	EM83	:DATA CHECK ERROR
2167	005714	052044	DH26	:AFTER READ DATA CMD
2168	005716	054126	DT1	
2169	005720	054654	DF10	
2170			:ERR 22	
2171	005722	045575	EM21	:CERR SET
2172	005724	052303	DH32	:AFTER WRITE CHECK CMD
2173	005726	054126	DT1	
2174	005730	054654	DF10	

2175					
2176	005732	045512			
2177	005734	052074			
2178	005736	054304			
2179	005740	055010			
2180					
2181	005742	045575			
2182	005744	051707			
2183	005746	054126			
2184	005750	054654			
2185					
2186	005752	045554			
2187					
2188					
2189					
2190					
2191					
2192	005754	052074			
2193	005756	054304			
2194	005760	055010			
2195					
2196	005762	045512			
2197	005764	052044			
2198	005766	054304			
2199	005770	055010			
2200					
2201					
2202	005772	045710			
2203	005774	051631			
2204	005776	054126			
2205	006000	054654			
2206					
2207	006002	045554			
2208	006004	052044			
2209	006006	054304			
2210	006010	055010			
2211					
2212	006012	045512			
2213	006014	052303			
2214	006016	054304			
2215	006020	055010			
2216					
2217	006022	045554			
2218	006024	052303			
2219	006026	054304			
2220	006030	055010			
2221					
2222	006032	046535			
2223	006034	051145			
2224	006036	054126			
2225	006040	054654			
2226					
2227	006042	050545			
2228	006044	051007			
2229	006046	054126			
2230	006050	054550			

:ERR 23

EM18
DH27
DT13
DF21

:MSG B0 ERROR
:AFTER WRITE DATA CMD

:ERROR 24

EM21
DH21
DT1
DF10

:CERR SET
:AFTER SCLR

:ERR 25

EM20

:MSG B1 ERROR

:ERR 26

DH27
DT13
DF21

:AFTER READ DATA CMD

:ERROR 27

EM24
DH19
DT1
DF10

:VOL VALID NOT SET
:AFTER PACK CMD

:ERR 30

EM20
DH26
DT13
DF21

:MSG B1 ERROR
:AFTER READ DATA CMD.

:ERR 31

EM18
DH32
DT13
DF21

:MSG B0 ERROR
:AFTER WRITE CHECK CMD

:ERR 32

EM20
DH32
DT13
DF21

:MSG B1 ERROR

:ERR 33

EM44
DH4
DT1
DF10

:VV NOT CLEARED
:AFTER PACK RE-INSERTED

:ERR 34

EM76
DH1
DT1
DF1

:NO DRIVES FOUND IN DEVICE MAP

2231			:ERR 35		
2232	006052	045471		EM17	:MSG A0 ERROR
2233	006054	051213		DH5	:AFTER AC SW OFF
2234	006056	054304		DT13	
2235	006060	055010		DF21	
2236			:ERR 36		
2237	006062	045533		EM19	:MSG A1 ERROR
2238	006064	051213		DH5	
2239	006066	054304		DT13	
2240	006070	055010		DF21	
2241			:ERR 37		
2242	006072	045554		EM20	:MSG A1 ERROR
2243	006074	051213		DH5	:AFTER OFFSET CMD
2244	006076	054304		DT13	
2245	006100	055010		DF21	
2246			:ERR 40		
2247	006102	050176		EM71	:DETECTED 10 BAD SECTORS
2248	006104	052074		DH27	:AFTER WRITE DATA CMD
2249	006106	054126		DT1	
2250	006110	054654		DF10	
2251			:ERR 41		
2252	006112	045365		EM14	:WRONG ATTN
2253	006114	051604		DH18	:AFTER UNLOAD CMD
2254					
2255	006116	054126		DT1	
2256	006120	054654		DF10	
2257			:ERR 42		
2258	006122	045412		EM15	:DRDY NOT CLEARED
2259	006124	051604		DH18	
2260					
2261	006126	054126		DT1	
2262	006130	054654		DF10	
2263			:ERR 43		
2264	006132	045444		EM16	:DSC NOT SET
2265	006134	051604		DH18	
2266	006136	054126		DT1	
2267	006140	054654		DF10	
2268			:ERR 44		
2269	006142	045617		EM22	:DOOR NOT CLEARED
2270	006144	051241		DH8	:AFTER DRIVE UNLOADED & DOOR OPENED
2271	006146	054126		DT1	
2272	006150	054654		DF10	
2273			:ERR 45		
2274	006152	045471		EM17	:MSG A0 ERROR
2275	006154	051241		DH8	
2276	006156	054304		DT13	
2277	006160	055010		DF21	
2278			:ERR 46		
2279	006162	045512		EM18	:MSG B0 ERROR
2280	006164	051241		DH8	
2281	006166	054304		DT13	
2282	006170	055010		DF21	
2283			:ERR 47		
2284	006172	050246		EM72	:BSE ERROR IN WRITE CMD NOT ON BSE TABLE
2285	006174	052074		DH27	:AFTER WRITE DATA CMD
2286	006176	054126		DT1	

2287	006200	054654	DF10	
2288				
2289				
2290	006202	050325	:ERR 50	
2291	006204	051007	EM73	:DETECTED BSE IN READ BUT NOT IN WRITE CMD.
2292	006206	054126	DH1	
2293	006210	054550	DT1	
2294			DF1	
2295	006212	050744	:ERR 51	
2296	006214	052021	EM93	:WRONG CYL# IN HEADER WORD
2297	006216	054240	DH25	:AFTER SEEK CMD
2298	006220	054764	DT9	
2299			DF20	
2300	006222	045471	:ERR 52	
2301	006224	052074	EM17	:MSG A0 ERROR
2302	006226	054304	DH27	:AFTER WRITE DATA CMD
2303	006230	055010	DT13	
2304			DF21	
2305	006232	045533	:ERR 53	
			EM19	:MSG A1 ERROR

2306	006234	052074	DH27	
2307	006236	054304	DT13	
2308	006240	055010	DF21	
2309				:ERR 54
2310	006242	045471	EM17	:MSG A0 ERROR
2311	006244	052044	DH26	:AFTER READ DATA CMD
2312	006246	054304	DT13	
2313	006250	055010	DF21	
2314				:ERROR 55
2315	006252	045343	EM13	:NO ATTN
2316	006254	051560	DH17	:AFTER RECAL CMD
2317	006256	054126	DT1	
2318	006260	054654	DF10	
2319				:ERR 56
2320	006262	045533	EM19	:MSG A1 ERROR
2321	006264	052044	DH26	
2322	006266	054304	DT13	
2323	006270	055010	DF21	
2324				:ERR 57
2325	006272	045471	EM17	:MSG A0 ERROR
2326	006274	052303	DH32	:AFTER WRITE CHECK CMD
2327	006276	054304	DT13	
2328	006300	055010	DF21	
2329				:ERR 60
2330	006302	045533	EM19	:MSG A1 ERROR
2331	006304	052303	DH32	
2332	006306	054304	DT13	
2333	006310	055010	DF21	
2334				:ERR 61
2335	006312	050007	EM69	:NO DRIVES PRESENT
2336	006314	051007	DH1	
2337	006316	054126	DT1	
2338	006320	054550	DF1	
2339				:ERR 62
2340	006322	050471	EM75	:FOUND 10 BAD CYL
2341	006324	052074	DH27	:AFTER WRITE DATA CMD
2342	006326	054126	DT1	
2343	006330	054654	DF10	
2344				:ERR 63
2345	006332	045533	EM19	:MSG A1 ERROR
2346	006334	051241	DH8	:AFTER DRIVE UNLOADED & DOOR OPENED
2347	006336	054304	DT13	
2348	006340	055010	DF21	
2349				:ERR 64
2350	006342	045554	EM20	:MSG B1 ERROR
2351	006344	051241	DH8	
2352	006346	054304	DT13	
2353	006350	055010	DF21	
2354				:ERR 65
2355	006352	045660	EM23	:SPIN SET
2356	006354	051304	DH11	:AFTER LOADING HEADS WITH DOOR OPEN
2357	006356	054126	DT1	
2358	006360	054654	DF10	
2359				:ERR 66
2360	006362	045471	EM17	:MSG A0 ERROR
2361	006364	051304	DH11	

2362	006366	054304		DT13	
2363	006370	055010		DF21	
2364			:ERR 67		
2365	006372	045512		EM18	:MSG B0 ERROR
2366	006374	051304		DH11	
2367	006376	054304		DT13	
2368	006400	055010		DF21	
2369			:ERR 70		
2370	006402	045533		EM19	:MSG A1 ERROR
2371	006404	051304		DH11	
2372	006406	054304		DT13	
2373	006410	055010		DF21	
2374			:ERR 71		
2375	006412	045554		EM20	:MSG B1 ERROR
2376	006414	051304		DH11	
2377	006416	054304		DT13	
2378	006420	055010		DF21	
2379			:ERR 72		
2380	006422	045746		EM25	:CARTRIDGE NOT CLEARED
2381	006424	051360		DH12	:AFTER DISK PACK REMOVED
2382	006426	054126		DT1	
2383	006430	054654		DF10	
2384			:ERR 73		
2385	006432	000000		0	
2386	006434	000000		0	
2387	006436	000000		0	
2388	006440	000000		0	
2389			:ERR 74		
2390	006442	045471		EM17	:MSG A0 ERROR
2391	006444	051145		DH4	:AFTER PACK RE-INSERTED & HDS LOADED
2392	006446	054304		DT13	
2393	006450	055010		DF21	
2394			:ERR 75		
2395	006452	045512		EM18	:MSG B0 ERROR
2396	006454	051145		DH4	
2397	006456	054304		DT13	
2398	006460	055010		DF21	
2399			:ERR 76		
2400	006462	045533		EM19	:MSG A1 ERROR
2401	006464	051145		DH4	
2402	006466	054304		DT13	
2403	006470	055010		DF21	
2404			:ERR 77		
2405	006472	045554		EM20	:MSG B1 ERROR
2406	006474	051145		DH4	
2407	006476	054304		DT13	
2408	006500	055010		DF21	
2409			:ERR 100		
2410	006502	045660		EM23	:SPIN SET
2411	006504	051410		DH13	:AFTER LOADING HEADS WITH CART. OUT
2412	006506	054126		DT1	
2413	006510	054654		DF10	
2414			:ERR 101		
2415	006512	000000		0	
2416	006514	000000		0	
2417	006516	000000		0	

2418	006520	000000		
2419			:ERR 102	0
2420	006522	000000		0
2421	006524	000000		0
2422	006526	000000		0
2423	006530	000000		0
2424			:ERR 103	0
2425	006532	000000		0
2426	006534	000000		0
2427	006536	000000		0
2428	006540	000000		0
2429			:ERR 104	0
2430	006542	000000		0
2431	006544	000000		0
2432	006546	000000		0
2433	006550	000000		0
2434			:ERR 105	
2435	006552	047204		EM52
2436	006554	053535		DH64
2437	006556	054126		DT1
2438	006560	054654		DF10
2439			:ERR 106	
2440	006562	046103		EM28
2441	006564	051474		DH15
2442	006566	054126		DT1
2443	006570	054654		DF10
2444			:ERR 107	
2445	006572	046135		EM29
2446	006574	053211		DH59
2447	006576	054126		DT1
2448	006600	054654		DF10
2449			:ERR 110	
2450	006602	046773		EM48
2451	006604	053016		DH48
2452	006606	054126		DT1
2453	006610	054654		DF10
2454			:ERR 111	
2455	006612	046162		EM30
2456	006614	051521		DH16
2457	006616	054126		DT1
2458	006620	054654		DF10
2459			:ERR 112	
2460	006622	046056		EM27
2461	006624	051521		DH16
2462	006626	054126		DT1
2463	006630	054654		DF10
2464			:ERR 113	
2465	006632	045343		EM13
2466	006634	053211		DH59
2467	006636	054126		DT1
2468	006640	054654		DF10
2469			:ERROR 114	
2470	006642	047456		EM58
2471	006644	053211		DH59
2472	006646	054126		DT1
2473	006650	054654		DF10

:UNS NOT SET
 :AFTER MDS FOUND

:VV SET
 :WITHOUT PACK CMD

:DSC NOT SET
 :AFTER EVEN PARITY ISSUED

:WRL NOT CLEARED
 :AFTER WRITE LOCK SWITCH DISABLED

:ATTN NOT CLEARED
 :AFTER UNIT SELECT PLUG REMOVED

:NED NOT SET

:ATTN NOT SET
 :AFTER EVEN PARITY ISSUED

:PARITY NOT SET

2474			:ERR 115		
2475	006652	047033		EM49	:WRL NOT SET
2476	006654	053057		DH49	:AFTER WRITE LOCK SW ENABLED
2477	006656	054126		DT1	
2478	006660	054654		DF10	
2479			:ERROR 116		
2480	006662	045305		EM12	:CONT NOT RDY
2481	006664	051637		DH19	:AFTER PACK CMD
2482	006666	054126		DT1	
2483	006670	054654		DF10	
2484			:ERROR 117		
2485	006672	045305		EM12	:CONT NOT RDY
2486	006674	051654		DH20	:AFTER SEL DR CMD
2487	006676	054126		DT1	
2488	006700	054654		DF10	
2489			:ERROR 120		
2490	006702	045305		EM12	
2491	006704	051707		DH21	:AFTER SUBSYS CLEAR
2492	006706	054126		DT1	
2493	006710	054654		DF10	
2494			:ERR 121		
2495	006712	047067		EM50	:WLE NOT SET
2496	006714	053117		DH50	:AFTER WRITING WITH WRITE LOCK SET
2497	006716	054126		DT1	
2498	006720	054654		DF10	
2499			:ERR 122		
2500	006722	046056		EM27	:NED NOT SET
2501	006724	051767		DH23	:AFTER WRONG PORT SELECTED
2502	006726	054126		DT1	
2503	006730	054654		DF10	
2504			:ERR 123		
2505	006732	045471		EM17	:MSG A0 ERROR
2506	006734	053117		DH50	:AFTER WRITING WITH WRITE LOCK ENABLED
2507	006736	054304		DT13	
2508	006740	055010		DF21	
2509			:ERROR 124		
2510	006742	045305		EM12	
2511	006744	051560		DH17	:AFTER RECAL CMD
2512	006746	054126		DT1	
2513	006750	054654		DF10	
2514			:ERR 125		
2515	006752	045512		EM18	:MSG B0 ERROR
2516	006754	053117		DH50	:AFTER WITING WITH WRL ENABLED
2517	006756	054304		DT13	
2518	006760	055010		DF21	
2519			:ERR 126		
2520	006762	045533		EM19	:MSG A1 ERROR
2521	006764	053117		DH50	
2522	006766	054304		DT13	
2523	006770	055010		DF21	
2524			:ERR 127		
2525	006772	045554		EM20	:MSG B1 ERROR
2526	006774	053117		DH50	
2527	006776	054304		DT13	
2528	007000	055010		DF21	
2529			:ERR 130		

2530	007002	046213	EM31	:NED NOT CLEARED
2531	007004	052161	DH29	:AFTER CORRECT PORT SELECTED
2532	007006	054126	DT1	
2533	007010	054654	DF10	
2534			:ERR 131	
2535	007012	045305	EM12	:NO RDY
2536	007014	052021	DH25	:AFTER SEEK CMD
2537	007016	054126	DT1	
2538	007020	054654	DF10	
2539			:ERR 132	
2540	007022	045343	EM13	:NO ATTN
2541	007024	052021	DH25	
2542	007026	054126	DT1	
2543	007030	054654	DF10	
2544			:ERR 133	
2545	007032	046056	EM27	:NED NOT SET
2546	007034	052125	DH28	:AFTER BOTH PORTS DESELECTED
2547	007036	054126	DT1	
2548	007040	054654	DF10	
2549			:ERR 134	
2550	007042	047131	EM51	:WRITE LOCK NOT SET SECTOR BOUNDRY
2551	007044	053117	DH50	:AFTER WRITING WITH WRL ENABLED
2552	007046	054166	DT3	
2553	007050	054564	DF3	
2554			:ERR 135	
2555	007052	047131	EM51	
2556	007054	053265	DH60	:AFTER WRITE LOCK ENABLED WHILE WRITING
2557	007056	054166	DT3	
2558	007060	054610	DF4	
2559			:ERR 136	
2560	007062	047131	EM51	
2561	007064	053464	DH63	:AFTER WRITE LOCK ENABLED FROM AC OFF
2562	007066	054166	DT3	
2563	007070	054564	DF3	
2564			:ERR 137	
2565	007072	047131	EM51	
2566	007074	053464	DH63	
2567	007076	054166	DT3	
2568	007100	054610	DF4	
2569			:ERR 140	
2570	007102	046244	EM32	:SPINDLE ON NOT SET
2571	007104	052247	DH31	:AFTER DRIVE MANUALLY LOADED
2572	007106	054126	DT1	
2573	007110	054654	DF10	
2574			:ERR 141	
2575	007112	046300	EM33	:DRIVE NOT READY
2576	007114	052456	DH38	:AFTER AC POWERED UP
2577	007116	054126	DT1	
2578	007120	054654	DF10	
2579			:ERR 142	
2580	007122	046331	EM34	
2581	007124	052247	DH31	
2582	007126	054126	DT1	
2583	007130	054654	DF10	
2584			:ERR 143	
2585	007132	045305	EM12	:CONT NOT READY

2586	007134	052335	DH34	:AFTER ST SPIN. CMD
2587	007136	054126	DT1	
2588	007140	054654	DF10	
2589			:ERR 144	
2590	007142	045343	EM13	:NO ATTN
2591	007144	052335	DH34	
2592	007146	054126	DT1	
2593	007150	054654	DF10	
2594			:ERR 145	
2595	007152	046372	EM35	:HEADS NOT HOME
2596	007154	052371	DH35	:AFTER MANUAL UNLOAD
2597	007156	054126	DT1	
2598	007160	054654	DF10	
2599			:ERR 146	
2600	007162	047430	EM57	:CERR NOT SET
2601	007164	052422	DH37	:AFTER TIMEOUT TO POWER DOWN
2602	007166	054126	DT1	
2603	007170	054654	DF10	
2604			:ERR 147	
2605	007172	046426	EM37	:AC LOW NOT SET
2606	007174	052422	DH37	
2607	007176	054126	DT1	
2608	007200	054654	DF10	
2609			:ERR 150	
2610	007202	046456	EM42	:NED NOT SET
2611	007204	052422	DH37	
2612	007206	054126	DT1	
2613	007210	054654	DF10	
2614			:ERROR 151	
2615	007212	045305	EM12	:NO RDY
2616	007214	051735	DH22	:AFTER CLEAR CMD
2617	007216	054126	DT1	
2618	007220	054654	DF10	
2619			:ERR 152	
2620	007222	046503	EM43	:AC LO NOT CLEARED
2621	007224	052456	DH38	:AFTER AC POWERED UP
2622	007226	054126	DT1	
2623	007230	054654	DF10	
2624			:ERR 153	
2625	007232	046535	EM44	:VV NOT CLEARED
2626	007234	052456	DH38	
2627	007236	054126	DT1	
2628	007240	054654	DF10	
2629			:ERROR 154	
2630	007242	047331	EM55	:ATTN NOT CLEARED
2631	007244	051735	DH22	
2632	007246	054126	DT1	
2633	007250	054654	DF10	
2634			:ERR 155	
2635	007252	046577	EM45	:VV SET AFTER HDS LOADED
2636	007254	051474	DH15	:WITHOUT 'PACK' CMD
2637	007256	054126	DT1	
2638	007260	054654	DF10	
2639			:ERR 156	
2640	007262	046654	EM46	:NXF=0
2641	007264	052712	DH45	:AFTER SEEK WITH VV=0

2642	007266	054126	DT1	
2643	007270	054654	DF10	
2644			:ERR 157	
2645	007272	046733	EM47	:CYL ADDR CHANGED FROM 0
2646	007274	052712	DH45	
2647	007276	054364	DT14	
2648	007300	055044	DF22	
2649			:ERR 160	
2650	007302	045471	EM17	:MSG A0 ERROR
2651	007304	052712	DH45	
2652	007306	054304	DT13	
2653	007310	055010	DF21	
2654			:ERR 161	
2655	007312	045512	EM18	:MSG B0 ERROR
2656	007314	052712	DH45	
2657	007316	054304	DT13	
2658	007320	055010	DF21	
2659			:ERR 162	
2660	007322	045533	EM19	:MSG A1 ERROR
2661	007324	052712	DH45	
2662	007326	054304	DT13	
2663	007330	055010	DF21	
2664			:ERR 163	
2665	007332	045554	EM20	:MSG B1 ERROR
2666	007334	052712	DH45	
2667	007336	054304	DT13	
2668	007340	055010	DF21	
2669			:ERR 164	
2670	007342	046654	EM46	:NXF NOT SET
2671	007344	052751	DH46	:AFTER WRITE DATA WITH VV=0
2672	007346	054126	DT1	
2673	007350	054654	DF10	
2674			:ERR 165	
2675	007352	047744	EM68	:CANNOT READ BSE INFO
2676	007354	052562	DH42	:ON SECTORS 0, 2, 4, 6, 8
2677	007356	054126	DT1	
2678	007360	054740	DF17	
2679			:ERR 166	
2680	007362	000000	0	
2681	007364	000000	0	
2682	007366	000000	0	
2683	007370	000000	0	
2684			:ERR 167	
2685	007372	047744	EM68	
2686	007374	054041	DH74	:ON SEC 10, 12....20
2687	007376	054126	DT1	
2688	007400	054740	DF17	
2689			:ERR 170	
2690	007402	000000	0	
2691	007404	000000	0	
2692	007406	000000	0	
2693	007410	000000	0	
2694			:ERROR 171	
2695	007412	045305	EM12	:NO RDY
2696	007414	052215	DH30	:AFTER READ HEADER CMD
2697	007416	054126	DT1	

2698	007420	054654		DF10	
2699			:ERROR 172	EM61	:NXF DID NOT SET FAULT
2700	007422	047527		DH45	:AFTER SEEK WITH VV=0
2701	007424	052712		DT1	
2702	007426	054126		DF10	
2703	007430	054654		DF10	
2704			:ERROR 173	EM63	:DLT SET
2705	007432	047555		DH30	
2706	007434	052215		DT1	
2707	007436	054126		DF15	
2708	007440	054720		DF15	
2709			:ERROR 174	EM21	:CERR SET
2710	007442	045575		DH30	
2711	007444	052215		DT1	
2712	007446	054126		DF15	
2713	007450	054720		DF15	
2714			:ERR 175	EM53	:UNLD NOT SET
2715	007452	047231		DH64	:AFTER MDS FOUND
2716	007454	053535		DT1	
2717	007456	054126		DF10	
2718	007460	054654		DF10	
2719			:ERR 176	EM54	:CANNOT FIND MDS
2720	007462	047261		DH65	:AFTER SEARCHING ALL DRIVES
2721	007464	053571		DT1	
2722	007466	054126		DF10	
2723	007470	054654		DF10	
2724			:ERROR 177	EM26	:VV NOT CLEARED
2725	007472	046014		DH16	:AFTER UNIT SEL PLUG REMOVED
2726	007474	051521		DT1	
2727	007476	054126		DF10	
2728	007500	054654		DF10	
2729			:ERROR 200	EM12	:NO RDY
2730	007502	045305		DH39	:AFTER WRITE HEADER CMD
2731	007504	052502		DT1	
2732	007506	054126		DF15	
2733	007510	054720		DF15	
2734			:ERROR 201	EM21	:CERR SET
2735	007512	045575		DH39	
2736	007514	052502		DT1	
2737	007516	054126		DF15	
2738	007520	054720		DF15	
2739			:ERROR 202	EM56	:UNEXP MEMORY PARITY ERROR
2740	007522	047364		DH66	:TEST #,PRAP PC
2741	007524	053634		DT6	
2742	007526	054234		DF5	
2743	007530	054634		DF5	
2744			:ERROR 203	EM18	:MSG B0 ERROR
2745	007532	045512		DH5	:AFTER AC SWITCHED OFF
2746	007534	051213		DT13	
2747	007536	054304		DF21	
2748	007540	055010		DF21	
2749			:ERR 204	EM57	:CERR NOT SET
2750	007542	047430		DH67	:AFTER TIMEOUT TO ENABLE WRL
2751	007544	053655		DT1	
2752	007546	054126		DF10	
2753	007550	054654		DF10	

2754			:ERR 205	
2755	007552	047067	EM50	:WRL NOT SET
2756	007554	053655	DH67	
2757	007556	054126	DT1	
2758	007560	054654	DF10	
2759			:ERROR 206	
2760	007562	047576	EM64	:WCE AT CYL 411,TRK 2, SEC 21
2761	007564	051007	DH1	
2762	007566	054126	DT1	
2763	007570	054640	DF7	
2764			:ERROR 207	
2765	007572	047430	EM57	:CERR NOT SET
2766	007574	053117	DH50	:AFTER WRITING WITH WRL ENABLED
2767	007576	054126	DT1	
2768	007600	054654	DF10	
2769			:ERROR 210	
2770	007602	045575	EM21	:CERR SET
2771	007604	052021	DH25	
2772	007606	054126	DT1	
2773	007610	054654	DF10	
2774			:ERR 211	
2775	007612	047506	EM59	:CTO SET
2776	007614	050105	EM70	:WHILE WAITING FOR OR REC'D CONTR RDY MSG A & B BAD
2777	007616	054126	DT1	
2778	007620	054674	DF12	
2779			:ERR 212	
2780	007622	047723	EM67	:NED SET
2781	007624	050105	EM70	
2782	007626	054126	DT1	
2783	007630	054674	DF12	
2784			:ERR 213	
2785	007632	044675	EM5	:MDS SET
2786	007634	050105	EM70	
2787	007636	054126	DT1	
2788	007640	054674	DF12	
2789			:ERR 214	
2790	007642	050444	EM74	:RTZ NOT SET
2791	007644	052535	DH41	:DURING RECD CMD
2792	007646	054126	DT1	
2793	007650	054654	DF10	
2794			:ERR 215	
2795	007652	045471	EM17	:MSG A0 ERROR
2796	007654	052502	DH39	:AFTER WRITE HEADER CMD.
2797	007656	054304	DT13	
2798	007660	055010	DF21	
2799			:ERR 216	
2800	007662	045512	EM18	:B0 ERROR
2801	007664	052502	DH39	
2802	007666	054304	DT13	
2803	007670	055010	DF21	
2804			:ERR 217	
2805	007672	045533	EM19	:A1 ERROR
2806	007674	052502	DH39	
2807	007676	054304	DT13	
2808	007700	055010	DF21	
2809			:ERR 220	

2810	007702	045554	EM20	
2811	007704	052502	DH39	
2812	007706	054304	DT13	
2813	007710	055010	DF21	
2814				
2815	007712	000000		
2816	007714	000000		
2817	007716	000000		
2818	007720	000000		
2819				
2820	007722	000000		
2821	007724	000000		
2822	007726	000000		
2823	007730	000000		
2824				
2825	007732	000000		
2826	007734	000000		
2827	007736	000000		
2828	007740	000000		
2829				
2830	007742	000000		
2831	007744	000000		
2832	007746	000000		
2833	007750	000000		
2834				
2835	007752	000000		
2836	007754	000000		
2837	007756	000000		
2838	007760	000000		
2839				
2840	007762	045305	EM12	
2841	007764	052044	DH26	
2842	007766	054126	DT1	
2843	007770	054654	DF10	
2844				
2845	007772	045575		
2846	007774	052044		
2847	007776	054126		
2848	010000	054720		

:B1 ERROR

:ERROR 221

:ERROR 222

:ERROR 223

:ERROR 224

:ERROR 225

:ERROR 226

:NO RDY
:AFTER READ DATA CMD

:ERROR 227

:CERR SET


```

2849
2850      .SBTTL PROGRAM SETUP
2851
2852 010002 012737 000001 001356 PARSRT: MOV #1,PARAM ;SET FLAG FOR 220 START
2853 010010 000402                BR PRGSRT ;START PROGRAM
2854
2855 010012 005037 001356 START: CLR PARAM ;CLEAR FOR 200 START
2856 010016 000005 PRGSRT: RESET ;CLEAR ALL INT ENABLE & INIT
2857 010020 012706 001100 MOV #STACK,SP ;SETUP STACK POINTER
2858 010024 012746 000000 MOV #PRO,-(SP) ;PSW LOADED TO BE
2859 010030 012746 010036 MOV #1$,-(SP) ;LSI-11 COMPATABLE
2860 010034 000002 RTI ;ENABLE ALL INTERRUPTS
2861
2862 010036 004737 033416 1$: JSR PC,$TKINT ;SETUP KB VECTOR ADDR, PRIORITY 4
2863 ;& TURN ON KB INTERRUPT
2864
2865
2866 ;*** CPU PRIORITY LEVEL NOW AT 0 ***
2867 ;*** ANY DEVICE WHICH SETS ITS ***
2868 ;*** INTERRUPT ENABLE BIT WILL ***
2869 ;*** SERVICED. ***
2870
2871 ;CLOCK INTERRUPTS WILL CHANGE CPU PRIORITY TO LEVEL 6 (IN 'ST5')
2872 ;RK06 CONTROLLER INTERRUPTS WILL CHANGE CPU PRIORITY TO LEVEL 5 IN 'SETINT')
2873 ;KEYBOARD INTERRUPTS WILL CHANGE CPU PRIORITY TO LEVEL 4 (SEE ABOVE)
2874
2875 ;ALL 'SYSMAC' TRAPS WILL CHANGE CPU PRIORITY TO LEVEL 7 (SEE BELOW)
2876
2877 ;SYSMAC 'SETUP'
2878      .SBTTL INITIALIZE THE COMMON TAGS
2879      ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
2880 010042 012706 001100 MOV #CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
2881 010046 005026 CLR (R6)+ ;;CLEAR MEMORY LOCATION
2882 010050 022706 001140 CMP #SWR,R6 ;;DONE?
2883 010054 001374 BNE -6 ;;LOOP BACK IF NO
2884 010056 012706 001100 MOV #STACK,SP ;;SETUP THE STACK POINTER
2885      ;;INITIALIZE A FEW VECTORS
2886 010062 012737 031452 000020 MOV #SCOPE,@IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
2887 010070 012737 000340 000022 MOV #340,@IOTVEC+2 ;;LEVEL 7
2888 010076 012737 031732 000030 MOV #ERROR,@EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
2889 010104 012737 000340 000032 MOV #340,@EMTVEC+2 ;;LEVEL 7
2890 010112 012737 035646 000034 MOV #STRAP,@TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
2891 010120 012737 000340 000036 MOV #340,@TRAPVEC+2 ;;LEVEL 7
2892 010126 012737 031206 000024 MOV #SPURDN,@PWRVEC ;;POWER FAILURE VECTOR
2893 010134 012737 000340 000026 MOV #340,@PWRVEC+2 ;;LEVEL 7
2894 010142 013737 023770 023762 MOV SENDCT,$EOPCT ;;SETUP END-OF-PROGRAM COUNTER
2895 010150 005037 001174 CLR $TIMES ;;INITIALIZE NUMBER OF ITERATIONS
2896 010154 005037 001176 CLR $ESCAPE ;;CLEAR THE ESCAPE ON ERROR ADDRESS
2897 010160 112737 000001 001115 MOVB #1,$ERMAX ;;ALLOW ONE ERROR PER TEST
2898 010166 012737 010166 001106 MOV #,$SLPADR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
2899 010174 012737 010174 001110 MOV #,$SLPERR ;;SETUP THE ERROR LOOP ADDRESS
2900      ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
2901      ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
2902 010202 013746 000004 MOV @ERRVEC,-(SP) ;;SAVE ERROR VECTOR
2903 010206 012737 010242 000004 MOV #64,$@ERRVEC ;;SET UP ERROR VECTOR
2904 010214 012737 177570 001140 MOV #DSWR,$SWR ;;SETUP FOR A HARDWARE SWICH REGISTER

```

```

2905 010222 012737 177570 001142      MOV    #DDISP,DISPLAY  ;;AND A HARDWARE DISPLAY REGISTER
2906 010230 022777 177777 170702      CMP    #-1,@SWR       ;;TRY TO REFERENCE HARDWARE SWR
2907 010236 001012                BNE    66$            ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
2908                                ;;AND THE HARDWARE SWR IS NOT = -1
2909 010240 000403                BR     65$           ;;BRANCH IF NO TIMEOUT
2910 010242 012716 010250      64$:  MOV    #65$, (SP)    ;;SET UP FOR TRAP RETURN
2911 010246 000002                RTI
2912 010250 012737 000176 001140 65$:  MOV    #SWREG,SWR     ;;POINT TO SOFTWARE SWR
2913 010256 012737 000174 001142      MOV    #DISPREG,DISPLAY
2914 010264 012637 000004      66$:  MOV    (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR
2915
2916 010270 005037 001216                CLR    $PASS         ;;CLEAR PASS COUNT
2917 010274 132737 000200 001231      BITB  #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
2918 010302 001403                BEQ   67$            ;;YES,USE NON-APT SWITCH
2919 010304 012737 001232 001140      MOV    #SSWREG,SWR   ;;NO,USE APT SWITCH REGISTER
2920 010312                67$:
2921
2922 010312 012737 010356 000004  MEMPAR: MOV    #1$,ERRVEC   ;TIMEOUT VECTOR
2923 010320 012737 000340 000006      MOV    #PR7,ERRVEC+2
2924
2925 010326 012701 172100                MOV    #MEMBAS,R1    ;ADDR OF MEM CSR
2926 010332 005011                CLR    (R1)          ;SEE IF CAN REFERENCE
2927 010334 012711 000001                MOV    #1,(R1)       ;SET ENABLE BIT IF YES
2928 010340 012737 031110 000114      MOV    #MEMERR,MEMVEC ;LD MEMORY CHK VECTOR IF DONT TIMEOUT
2929 010346 012737 000340 000116      MOV    #PR7,MEMVEC+2
2930 010354 000401                BR     2$
2931
2932 010356 022626                1$:  CMP    (SP)+,(SP)+   ;ADJ STACK
2933 010360 062701 000002      2$:  ADD    #2,R1         ;TRY NEXT CSR
2934 010364 020127 172140                CMP    R1,#MEMBAS+40 ;ALL TRIED?
2935 010370 001360                BNE   3$            ;BR IN NO
2936 010372 012737 000006 000004      MOV    #ERRVEC+2,ERRVEC ;RESTORE TRAP CATCHER
2937 010400 005037 000006                CLR    ERRVEC+2
2938
2939 010404 004737 024110                JSR   PC,CLRFLG     ;CLEAR DDUMP THRU SIZFLG
2940 010410 005037 001220                CLR   $DEVCT
2941 010414 005037 001222                CLR   $UNIT
2942
2943
2944                ;;FIND OUT IF XXDP, ACT, APT; CHAIN OR DUMP MODE
2945                ;;
2946
2947 010420 005737 000042      START1: TST    42
2948 010424 001015                BNE   1$            ;BR IF AUTO
2949 010426 004737 024130                JSR   PC,TITLE     ;MANUAL, TYPE PROG ID
2950 010432 123727 000041 000013      CMPB  41,#13       ;13=LOADED BY XXDP
2951 010440 001011                BNE   2$
2952 010442 005237 005450                INC   DDUMP        ;SET RK06 DUMP MODE FLAG
2953 010446 104401 036575                TYPE  .MSG2        ;REPLACE DR0 PACK W/SCRATCH & DO<CR>
2954 010452 000000                HALT               ;HALT
2955 010454 000137 010470                JMP   ST2
2956 010460 000137 010534      1$:  JMP   ST3
2957 010464 005237 005456      2$:  INC   PPTP        ;SET ACT/APT/PTP DUMP MODE FLAG
2958
2959                ;;
2960                ;;CHECK IF ALL PARAMETERS DEFAULTED. IF NOT, BEGIN INPUT DIALOGUE

```

CZ
CZ


```
2961 ;WITH OPERATOR. THE REPLY TO 'DRIVES TO BE TESTED' SHOULD BE
2962 ;DRIVE NOS. SEPERATED BY COMMAS & TERMINATED BY <CR>
2963 ; EX: DRIVES TO BE TESTED: 1,2,4<CR>
2964 ;
2965 ;
2966 010470 005737 001356 ST2: TST PARAM
2967 010474 001002 BNE 1$ ;BR IF 220 START
2968 010476 000137 010566 JMP ST4 ;200 START, DEFAULT & SIZE THE BUSS
2969 010502 104401 036656 1$: TYPE ,MSG3 ;DRIVES TO BE TESTED
2970 010506 004737 024210 JSR PC,GDRVS ;GET DR NOS.
2971 010512 104401 036710 TYPE ,MSG4 ;BUSS ADDR
2972 010516 004737 024350 JSR PC,GBA ;GET BA
2973 010522 104401 036755 TYPE ,MSG5 ;CONT INT VECTOR
2974 010526 004737 024376 JSR PC,GINT ;GET INT VECTOR
2975 010532 000427 BR ST5
2976 ;
2977 ;
2978 ;AUTO MODE
2979 ;CHECK IF LOADED BY XXDP OR OTHER. SET FLAGS & NO INPUT DIALOGUE.
2980 ;DEFAULT ALL PARAMETERS. TEST ONLY THOSE DRIVES THAT ARE READY
2981 ;ON THE BUSS
2982 ;
2983 ;
2984 010534 123727 000041 000013 ST3: CMPB 41,#13 ;13=LOADED BY XXDP
2985 010542 001007 BNE 1$
2986 010544 005237 005452 INC DDPCH ;SET RK06 CHAIN MODE FLAG
2987 010550 004737 024130 JSR PC,TITLE
2988 010554 104401 037072 TYPE ,MSG7 ;DRO NOT TSTD
2989 010560 000402 BR ST4
2990 010562 005237 005454 1$: INC ACT11 ;SET ACT AUTO FLAG.
2991 ;
2992 010566 012737 177440 001264 ST4: MOV #177440,$BASE ;DEFAULT VALUE
2993 010574 012737 000210 001334 MOV #210,RKVEC ;DEFAULT VALUE
2994 010602 004737 024430 JSR PC,SETINT
2995 010606 005237 005510 INC SIZFLG ;DO "SIZE THE BUSS" TEST
2996 ;
2997 010612 005037 005322 ST5: CLR UNLD ;INITIALIZE FLAGS
2998 010616 005037 005324 CLR BADHDR ;USED IN 'STOP' ROUTINE
2999 010622 005037 005326 CLR HPEND ;FOR VALID PROGRAM HALTS
3000 010626 005037 001176 CLR $ESCAPE
3001 010632 005037 001172 CLR $TMP5 ;CLEAR RK07 FLAG
3002 010636 012737 005462 001362 MOV #DRIVO,DRVPTR ;SETUP
3003 010644 005037 001220 CLR $DEVCT ;NO. OF DRVS DONE
3004 010650 005037 001222 CLR $UNIT ;CURRENT DRV UNDER TEST
3005 010654 012737 010722 000004 MOV #1$,ERRVEC ;SETUP TIMEOUT ERROR VECTOR
3006 010662 005777 170460 TST @LKS ;SEE IF L-CLOCK THERE
3007 010666 005237 005502 INC LCLKF ;PRESENT, SET FLAG.
3008 010672 013700 001350 MOV LCVEC,R0 ;VECTOR ADDR
3009 010676 012737 010764 000004 MOV #2$,ERRVEC
3010 010704 005777 170430 TST @PKS ;SEE IF P-CLOCK THERE
3011 010710 005237 005504 INC PCLKF ;PRESENT, SET FLAG
3012 010714 013700 001352 MOV PCVEC,R0 ;VECTOR ADDR
3013 010720 000412 BR 3$
3014 ;
3015 010722 022626 010770 000004 1$: CMP (SP)+,(SP)+ ;L-CLOCK NOT THERE, CLEAR STACK
3016 010724 012737 010770 000004 MOV #4$,ERRVEC
```

3017	010732	005777	170402		TST	@PKS		:SEE IF P-CLOCK THERE
3018	010736	005237	005504		INC	PCLKF		:PRESENT, SET FLAG
3019	010742	013700	001352		MOV	PCVEC,R0		:VECTOR ADDR
3020	010746	005237	005506	3\$:	INC	DOTIM		:INDICATES TIMING TESTS CAN BE DONE
3021	010752	012720	030230		MOV	#CLOCK,(R0)+		:SERVICE ROUTINE FOR CLOCKS
3022	010756	012710	000300		MOV	#PR6,(R0)		
3023	010762	000407			BR	TST1		::GO TO NEXT TEST
3024								
3025	010764	022626		2\$:	CMP	(SP)+,(SP)+		:P-CLOCK NOT THERE, CLEAR STACK
3026	010766	000767			BR	3\$		
3027								
3028	010770	022626		4\$:	CMP	(SP)+,(SP)+		:NEITHER CLOCK THERE, CLEAR STACK
3029	010772	005037	005506		CLR	DOTIM		:TIMING TESTS CANNOT BE DONE.
3030	010776	104401	037301		TYPE	,MSG13		:ALL TIMING TESTS BYPASSED
3031								
3032								

3033
3034
3035
3036
3037
3038
3039
3040
3041
3042
3043
3044
3045
3046
3047
3048
3049
3050
3051
3052
3053
3054
3055
3056
3057
3058
3059
3060
3061
3062
3063
3064
3065
3066
3067
3068
3069
3070
3071
3072
3073
3074
3075
3076
3077
3078
3079
3080
3081
3082
3083
3084
3085
3086
3087
3088

.SBTTL BASIC CONTROLLER TESTS, SIZING & SETUP

*TEST 1 REFERENCE ALL CONTROLLER REGISTERS

* THIS TEST VERIFIES THAT ALL THE CONTROLLER REGISTERS
* CAN BE ACCESSED. THE INABILITY TO BE ACCESSED WILL
* RESULT IN A TIMEOUT TRAP WITH AN ERROR MESSAGE. ANY
* ERROR IN THIS TEST WILL RESULT IN ABORTING ALL OTHER
* TESTS AND JUMPING TO 'END OF PASS'

```
TST1:  SCOPE
MOV    #1,$TIMES      ;;DO 1 ITERATION
MOV    #STACK,$SP    ;;RESTORE STK PTR

MOV    #PRO,-(SP)    ;RESET PSW TO PRIORITY 0
MOV    #5$,-(SP)    ;& MAKE IT LSI COMPATABLE
RTI

5$:

MOV    #1$,ERRVEC    ;SETUP TIMEOUT ERROR VECTOR
MOV    $BASE,R5      ;SETUP INDEX REG.
TST    RKCS1(R5)     ;REFERENCE ALL THE
TST    RKCS2(R5)     ;CONTROLLER REGISTERS
TST    RKWC(R5)
TST    RKBA(R5)
TST    RKDA(R5)
TST    RKDS(R5)     ;TIMEOUTS IN THIS SECTION
TST    RKER(R5)     ;INDICATE THAT THE CONTROLLER
TST    RKASOF(R5)   ;REGISTERS CANNOT BE READ.
TST    RKDC(R5)     ;TESTING SHOULD NOT PROCEED
TST    RKDB(R5)     ;UNTIL THIS IS REMEDIED.
TST    RKMR1(R5)
TST    RKMR2(R5)
TST    RKMR3(R5)
TST    RKECPS(R5)
TST    RKECPT(R5)

MOV    #BADTMO,ERRVEC ;SETUP TIMEOUT HANDLER
MOV    #PR7,ERRVEC+2
BR     TST2          ;;GO TO NEXT TEST

1$:  CMP    (SP)+,(SP)+ ;RESTORE STACK POINTER
      ERROR 7          ;ABORT-COULD NOT REFERENCE CONTROLLER REGISTER
      JMP   $EOP
```

*TEST 2 SIZE THE BUSS

* THIS TEST IS ENTERED ONLY IF 'DRIVE SELECTION' IS DEFAULTED
* EITHER BY RUNNING IN THE AUTO MODE OR A 200 START IN THE
* MANUAL MODE.
* EVERY DRIVE FROM 0 THRU 7 IS ADDRESSED.
* CONTROLLER ERROR (CERR) IS EXAMINED AND IF NOT SET, THE

```

3089          : * DRIVE WILL BE TESTED AS AN RK06. IF SET, THE PROGRAM WILL BYPASS
3090          : * TESTING THAT DRIVE ONLY IF THE ERROR WAS A RESULT OF
3091          : * MDS, UFE OR NED BEING SET; OR BOTH NED & DRA RESET IN-
3092          : * DICATING THE OTHER PORT IS ACCESSED.
3093          : * IF CERR DUE TO DTVE, DRIVE WILL BE TESTED AS AN RK07.
3094          : *
3095          : *****
3096 011164 000004          TST2: SCOPE
3097 011166 012737 000001 001174  MOV #1,$TIMES          ;;DO 1 ITERATION
3098 011174 012706 001100          MOV #STACK,SP          ;RESTORE STK PTR
3099
3100 011200 005237 001502          INC BYPCERR           ;DO NOT TEST CERR IN FRDY
3101
3102 011204 132737 000200 001231  BITB #BIT7,$ENVM      ;SEE IF USE APT SELECTED DRIVES
3103 011212 001002          BNE 14$              ;BR IF YES
3104 011214 000137 011334          JMP 12$              ;ELSE DO NORM SIZING OR VERIFY
3105
3106 011220 104401 037205          14$: TYPE ,MSG10      ;WILL TEST DRIVES
3107 011224 005037 005460          CLR DRIVS            ;# OF DRIVES PRESENT
3108 011230 005000          CLR R0              ;DRV ADDR
3109 011232 012701 005462          MOV #DRIVO,R1        ;DRV FLAG
3110 011236 013702 001266          MOV $DEVN,R2         ;APT DEVICE MAP
3111
3112 011242 032702 000001          15$: BIT #BIT0,R2    ;SEE IF DRV IN DEVICE MAP
3113 011246 001410          BEQ 16$              ;BR IF NO
3114 011250 005237 005460          INC DRIVS            ;ELSE INCR DRIVE COUNT
3115 011254 005211          INC (R1)             ;& SET DRIVE PRESENT FLAG
3116 011256 104401 001205          TYPE ,$CRLF
3117 011262 010046          MOV R0,-(SP)         ;;SAVE R0 FOR TYPEOUT
3118          ;;TYPE DRIVE #
3119 011264 104403          TYPOS
3120 011266 001          .BYTE 1            ;;GO TYPE--OCTAL ASCII
3121 011267 000          .BYTE 0            ;;TYPE 1 DIGIT(S)
3122          ;;SUPPRESS LEADING ZEROS
3123 011270 005721          16$: TST (R1)+       ;ADV POINTER TO NEXT FLAG
3124 011272 005200          INC R0              ;INC DRIVE #
3125 011274 022700 000010          CMP #8.,R0          ;ALL 8 TESTED?
3126 011300 001402          BEQ 17$              ;BR IF YES
3127
3128 011302 006002          ROR R2              ;ELSE GET NEXT BIT OFF DEVICE MAP
3129 011304 000756          BR 15$              ;& TRY AGAIN
3130
3131 011306 005737 005460          17$: TST DRIVS        ;SEE IF MORE DRIVES PRESENT
3132 011312 001402          BEQ 18$              ;BR IF NO
3133 011314 000137 012010          JMP VERIFY          ;ELSE EXIT TEST & SETUP FOR RK07'S.
3134
3135 011320 104034          18$: ERROR 34        ;NO DRIVES FOUND IN $DEVN
3136 011322 000000          HALT                ;SETUP CORRECTLY & PRESS 'CONTINUE'
3137 011324 000137 010612          JMP ST5              ;TO TRY AGAIN
3138 011330 000137 012010          20$: JMP VERIFY      ;DO NOT SIZE, GO THE NEXT TEST.
3139
3140 011334 012765 000040 000010  12$: MOV #SCLR,RKCS2(R5) ;SUBSYSTEM CLEAR
3141
3142
3143
3144
    
```



```

3145
3146 011342 013737 001424 005376      MOV    T10,TEMP1      ;SET TIMEOUT
3147 011350 004737 024542                JSR    PC,FRDY        ;FIND RDY
3148 011354 104120                ERROR  120            ;RDY NOT SET BY END OF SCLR
3149
3150 011356 005737 005510                TST    SIZFLG        ;SIZE BUS?
3151 011362 001762                BEQ    20$           ;BR IF NO
3152 011364 104401 037205                TYPE  ,MSG10        ;WILL TEST DRIVES
3153 011370 005037 005460                CLR    DRIVS        ;# OF DRIVES PRESENT
3154 011374 005000                CLR    R0           ;DRV ADDR
3155 011376 012701 005462                MOV    #DRIVO,R1    ;DRV FLAG
3156 011402
3157 011402 104415      1$:      SCOP1
3158 011404 012706 001100                MOV    #STACK,SP    ;RESTORE STK PTR
3159
3160 011410 012765 000040 000010      MOV    #SCLR,RKCS2(R5) ;SUBSYSTEM CLEAR
3161 011416 013737 001424 005376      MOV    T10,TEMP1    ;SET TIMEOUT
3162 011424 004737 024542                JSR    PC,FRDY        ;FIND RDY
3163 011430 104120                ERROR  120            ;RDY NOT SET BY END OF SCLR
3164 011432 010065 000010                MOV    R0,RKCS2(R5)  ;SELECT THE DRIVE ADDR
3165 011436 012737 000001 005340      MOV    #SELDRV,HCS1
3166 011444 053737 001170 005340      BIS    $TMP4,HCS1    ;ADD CDT IF RK07
3167 011452 013765 005340 000000      MOV    HCS1,RKCS1(R5) ;GET STATUS
3168 011460 013737 001432 005376      MOV    T50000,TEMP1
3169 011466 004737 025232                JSR    PC,DLY        ;DO DELAY TO CATCH MDS
3170 011472 013737 001424 005376      MOV    T10,TEMP1
3171 011500 004737 024542                JSR    PC,FRDY        ;FIND RDY
3172 011504 104117                ERROR  117            ;NO RDY AFTER SELECT DRIVE CMD.
3173 011506 032737 100000 005340      BIT    #CERR,HCS1
3174 011514 001052                BNE    2$           ;
3175 011516 013737 005366 005376      MOV    HMR2,TEMP1
3176 011524 042737 177770 005376      BIC    #^C<DRVMSK>,TEMP1
3177 011532 020037 005376                CMP    R0,TEMP1     ;S/B SAME
3178 011536 001020                BNE    3$           ;
3179 011540 005700                TST    R0
3180 011542 001003                BNE    4$           ;
3181 011544 005737 005452                TST    DDPCH        ;SEE IF XXDP CHAIN MODE
3182 011550 001016                BNE    5$           ;
3183 011552 005237 005460      4$:      INC    DRIVS        ;INC DRIVE COUNT.
3184 011556 005211                INC    (R1)         ;SET DRIVE PRESENT FLAG
3185 011560 053711 001170                BIS    $TMP4,(R1)   ;ADD CDT IF RK07
3186 011564 104401 001205                TYPE  ,SCRLF
3187 011570 010046                MOV    R0,-(SP)     ;;SAVE R0 FOR TYPEOUT
3188
3189 011572 104403                TYPOS
3190 011574 001                .BYTE 1            ;;TYPE DR #
3191 011575 000                .BYTE 0            ;;GO TYPE--OCTAL ASCII
3192 011576 000403                BR    5$           ;;TYPE 1 DIGIT(S)
3193
3194 011600 004737 025250      3$:      JSR    PC,BYP        ;TYPE BYPASS DR #
3195 011604 104001                ERROR  1            ;WRITTEN DR # DOES NOT MATCH RKMR2 DR #
3196
3197 011606 005721      5$:      TST    (R1)+        ;SHIFT PTR TO NEXT DR. FLAG
3198 011610 005200                INC    R0           ;INC DR #
3199 011612 005037 001170                CLR    $TMP4        ;CLEAR RK07 FLAG FOR NEXT DRIVE
3200 011616 022700 000010                CMP    #8.,R0
    
```

```

3201 011622 001267          BNE      1$          ;MORE LEFT.
3202 011624 005737 005460   TST     DRIVS
3203 011630 001065          BNE     10$
3204 011632 104061          ERROR   61          ;NO DRIVES SEEN
3205 011634 000000          HALT
3206 011636 000137 010612   JMP     ST5        ;SETUP & PRESS 'CONTINUE'
3207
3208 011642 032737 000040 005354 2$:   BIT     #DTYE,HER
3209 011650 001405          BEQ     13$
3210 011652 012737 002000 001170   MOV     #CDT,$TMP4 ;ADD CDT
3211 011660 000137 011402          JMP     1$          ;TRY AGAIN
3212 011664 032737 001000 005342 13$:  BIT     #MDS,HCS2
3213 011672 001015          BNE     6$
3214 011674 032737 000400 005342   BIT     #UFE,HCS2
3215 011702 001015          BNE     7$
3216 011704 032737 000001 005352   BIT     #DRA,HDS
3217 011712 001015          BNE     8$
3218 011714 032737 010000 005342   BIT     #NED,HCS2
3219 011722 001424          BEQ     9$
3220 011724 000730          BR      5$
3221
3222 011726 004737 025250          6$:   JSR     PC,BYP     ;TYPE BYP DR #
3223 011732 104002          ERROR   2          ;MDS DETECTED
3224 011734 000724          BR      5$
3225
3226 011736 004737 025250          7$:   JSR     PC,BYP
3227 011742 104003          ERROR   3          ;UFE DETECTED
3228 011744 000720          BR      5$
3229
3230 011746 032737 010000 005342 8$:   BIT     #NED,HCS2
3231 011754 001676          BEQ     4$
3232 011756 104401 037412   TYPE    ,MSG15     ;DRV#
3233 011762 010046          MOV     R0,-(SP)   ;:SAVE R0 FOR TYPEOUT
3234
3235 011764 104403          TYPOS
3236 011766 001          .BYTE  1          ;:TYPE DR#
3237 011767 000          .BYTE  0          ;:GO TYPE--OCTAL ASCII
3238 011770 104010          ERROR   10         ;:TYPE 1 DIGIT(S)
3239 011772 000705          BR      5$        ;:SUPPRESS LEADING ZEROS
3240
3241 011774 004737 025250          9$:   JSR     PC,BYP
3242 012000 104004          ERROR   4          ;NO DRA & NO NED = OTHER PORT SELECTED
3243 012002 000701          BR      5$
3244 012004 000137 012402   10$:  JMP     NUDRV
3245
3246 012010          VERIFY:
3247
3248
3249
3250
3251
3252
3253
3254
3255
3256
  
```

```

:*****
:*TEST 3          VERIFY OPERATOR DRIVE SELECTIONS
:*
:* THIS TEST IS ENTERED ONLY IF DRIVE SELECTION IS NOT
:* DEFAULTED. EVERY DRIVE FROM 0 TO 7 IS ADDRESSED &
:* CONTROLLER ERROR (CERR) IS EXAMINED. IF NOT SET, THE
:* PROGRAM WILL ASSUME THE DRIVE IS PRESENT AS AN RK06.
:* IF CERR WAS SET, THAT DRIVE WILL BE BYPASSED
  
```

CZ
CZ

VERIFY OPERATOR DRIVE SELECTIONS

SEQ 0064

```

3257
3258
3259
3260
3261
3262
3263
3264 012010 000004
3265 012012 012737 000001 001174
3266 012020 012706 001100
3267 012024 005000
3268 012026 012701 005462
3269 012032
3270 012032 104415
3271 012034 012706 001100
3272
3273 012040 012765 000040 000010
3274 012046 013737 001424 005376
3275 012054 004737 024542
3276 012060 104120
3277 012062 010065 000010
3278 012066 012737 000001 005340
3279 012074 053737 001170 005340
3280 012102 013765 005340 000000
3281 012110 013737 001432 005376
3282 012116 004737 025232
3283 012122 013737 001424 005376
3284 012130 004737 024542
3285 012134 104117
3286 012136 032737 100000 005340
3287 012144 001036
3288 012146 013737 005366 005376
3289 012154 042737 177770 005376
3290 012162 020037 005376
3291 012166 001014
3292 012170 005711
3293 012172 001402
3294 012174 053711 001170
3295 012200 005721
3296 012202 005200
3297 012204 005037 001170
3298 012210 022700 000010
3299 012214 001306
3300 012216 000475
3301
3302 012220 004737 025250
3303 012224 104001
3304 012226 005711
3305 012230 001763
3306 012232 005337 005460
3307 012236 005011
3308 012240 000757
3309 012242 032737 000040 005354
3310 012250 001405
3311 012252 012737 002000 001170
3312 012260 000137 012032

```

```

: * ONLY IF THE ERROR WAS A RESULT OF MDS OR UFE SET OR BOTH
: * NED & DRA RESET (WRONG PORT). IF CERR IS A RESULT OF
: * NED ONLY, IT IS CHECKED AGAINST THE INPUTTED INFOR TO
: * VERIFY IT WAS NOT SPECIFIED.
: * IF CERR DUE TO DTYE, DRIVE WILL BE TESTED AS RK07.
: *
: *****
TST3: SCOPE
MOV #1,STIMES ;;DO 1 ITERATION
MOV #STACK,SP ;RESTORE STK PTR
CLR R0 ;DRIVE ADDR
MOV #DRIVO,R1 ;DRIVE FLAG

1$: SCOP1
MOV #STACK,SP ;RESTORE STK PTR

MOV #SCLR,RKCS2(R5) ;SUBSYSTEM CLEAR
MOV T10,TEMP1 ;SET TIME OUT
JSR PC,FRDY ;FIND RDY
ERROR 120 ;NO RDY AFTER SCLR
MOV R0,RKCS2(R5) ;DRV ADDR
MOV #SELDRV,HCS1
BIS $TMP4,HCS1 ;ADD CDT IF RK07
MOV HCS1,RKCS1(R5) ;GET STATUS
MOV T50000,TEMP1
JSR PC,DLY ;DO DELAY TO CATCH MDS
MOV T10,TEMP1
JSR PC,FRDY ;FIND RDY
ERROR 117 ;NO RDY AFTER SELECT DRIVE CMD.
BIT #CERR,HCS1
BNE 2$
MOV HMR2,TEMP1
BIC #^C<DRVMSK>,TEMP1
CMP R0,TEMP1 ;S/B SAME
BNE 3$

11$: TST (R1)
BEQ 4$
BIS $TMP4,(R1) ;ADD CDT IF RK07
4$: TST (R1)+ ;SHIFT PTR TO NEXT DR FLAG
INC R0 ;INC DR#
CLR $TMP4 ;CLEAR RK07 FLAG FOR NEXT DRIVE
CMP #8.,R0
BNE 1$ ;MORE LEFT
BR TST4 ;GO TO NEXT TEST

3$: JSR PC,BYP ;TRY BYPASS DRIVE#
ERROR 1 ;WRITTEN DR# DOES NOT MATCH RKMR2 DR#
TST (R1)
BEQ 4$ ;BRANCH IF NOT SPEC BY INPUT
12$: DEC DRIVS ;DECREMENT TOTAL DRIVS
CLR (R1) ;CLEAR DRIVE FLAG
BR 4$

2$: BIT #DTYE,HER
BEQ 13$
MOV #CDT,$TMP4 ;ADD CDT
JMP 1$ ;TRY AGAIN

```

CZ
CZ

```

3313
3314
3315 012264 032737 001000 005342 13$: BIT #MDS,HCS2
3316 012272 001027 BNE 6$
3317 012274 032737 000400 005342 BIT #UFE,HCS2
3318 012302 001027 BNE 7$
3319 012304 032737 000001 005352 BIT #DRA,HDS
3320 012312 001005 BNE 8$
3321 012314 032737 010000 005342 BIT #NED,HCS2
3322 012322 001423 BEQ 9$
3323 012324 000404 BR 10$
3324 012326 032737 010000 005342 8$: BIT #NED,HCS2
3325 012334 001715 BEQ 11$
3326 012336 005711 10$: TST (R1)
3327 012340 001717 BEQ 4$
3328
3329 012342 004737 025250 JSR PC,BYP ;TYPE BYPASS DRIVE#
3330 012346 104006 ERROR 6
3331 012350 000730 BR 12$
3332
3333 012352 004737 025250 6$: JSR PC,BYP ;TYPE BYPASS DRIVE#
3334 012356 104002 ERROR 2 ;MDS DETECTED
3335 012360 000724 BR 12$
3336
3337 012362 004737 025250 7$: JSR PC,BYP
3338 012366 104003 ERROR 3 ;UFE DETECTED
3339 012370 000720 BR 12$
3340
3341 012372 004737 025250 9$: JSR PC,BYP
3342 012376 104004 ERROR 4 ;DRA & NED RESET - OTHER PORT SELECTED
3343 012400 000714 BR 12$
3344
3345
3346
3347
3348 ; THIS PART OF THE PROGRAM WILL BE REPEATED FOR EACH
3349 ; DRIVE PRESENT
3350
3351 ; '$UNIT' CONTAINS THE ADDRESS OF THE DRIVE CURRENTLY
3352 ; UNDER TEST
3353
3354 012402 005037 001502 NUDRV: CLR BYPCERR ;ENTER HERE FROM LAST TEST
3355 ;TEST CERR IN 'FRDY'
3356 012406 005037 001170 CLR $TMP4 ;RK07 FLAG
3357
  
```



```

3358
3359
3360
3361
3362
3363
3364
3365
3366
3367 012412 000004
3368 012414 012737 000001 001174
3369 012422 012706 001100
3370 012426 012737 000004 001214
3371 012434 012737 000004 001102
3372
3373 012442 005737 005460
3374 012446 001004
3375 012450 104401 037772
3376 012454 000137 023734
3377
3378 012460 013701 001362 4$: MOV DRVPTR,R1 ;ADDR OF NEXT DRIVE FLAG
3379 012464 005737 001220 TST $DEVCT ;IS FIRST DRIVE BEING CHECKED
3380 012470 001402 BEQ 2$ ;YES, BRANCH
3381 012472 005237 001222 1$: INC $UNIT ;INCR DRIVE ADDR TO NEXT DRIVE
3382 012476 005711 2$: TST (R1) ;IS DRIVE PRESENT?
3383 012500 001002 BNE 5$ ;BR IF YES
3384 012502 005721 TST (R1)+ ;ELSE FIND NEXT DRIVE
3385 012504 000772 BR 1$
3386 012506 005737 005452 5$: TST DDPCH ;DDP CHAIN MODE?
3387 012512 001405 BEQ 3$ ;BR IF NO
3388 012514 005737 001222 TST $UNIT ;ELSE SEE IF DRV 0
3389 012520 001002 BNE 3$ ;BR IF NO
3390 012522 005721 TST (R1)+ ;ELSE FIND NEXT DRIVE PRESENT
3391 012524 000762 BR 1$
3392
3393 012526 032721 002000 3$: BIT #CDT,(R1)+ ;SEE IF DRIVE UNDER TEST IS RK07
3394 012532 001403 BEQ 6$ ;BR IF NO
3395 012534 012737 002000 001170 MOV #CDT,$TMP4 ;ELSE SET RK07 FLAG
3396 012542 010137 001362 6$: MOV R1,DRVPTR ;STORE POINTER TO NEXT DR FLAG
3397 012546 104401 037412 TYPE ,MSG15 ;"DRIVE"
3398 012552 013700 001222 MOV $UNIT,R0
3399 012556 010046 MOV R0,-(SP) ;SAVE R0 FOR TYPEOUT
3400 ; ;DRIVE #
3401 012560 104403 TYPOS ;GO TYPE--OCTAL ASCII
3402 012562 001 .BYTE 1 ;TYPE 1 DIGIT(S)
3403 012563 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
3404
3405 ; TYPE ,SCRLF
3406
3407 012564 005737 001170 TST $TMP4 ;SEE IF RK07 UNDER TEST
3408 012570 001014 BNE 7$ ;BR IF YES
3409 012572 012737 000632 012654 MOV #632,LC ;ELSE LOAD RK06 PARAMETERS
3410 012600 005037 012662 CLR E,DDT
3411 012604 012737 000777 012656 MOV #777,MASK
3412 012612 012737 160017 012660 MOV #160017,MASK1
3413 012620 000421 BR TST5 ;GOTO NEXT TEST
    
```

```
3414  
3415 012622 012737 001456 012654 7S: MOV #1456,LC ;LOAD RK07 PARAMETERS  
3416 012630 012737 000400 012662 MOV #D.DDT,E.DDT  
3417 012636 012737 001777 012656 MOV #1777,MASK  
3418 012644 012737 140017 012660 MOV #140017,MASK1  
3419 012652 000404 BR TST5 ;;GOTO NEXT TEST  
3420  
3421 012654 000000 LC: 0 ;LAST CYL  
3422 012656 000000 MASK: 0  
3423 012660 000000 MASK1: 0  
3424 012662 000000 E.DDT: 0 ;EXPECTED DRIVE TYPE TO E.A0
```



```

3425
3426 012664
3427
3428
3429
3430
3431
3432
3433
3434 012664 000004
3435 012666 012737 000001 001174
3436 012674 012706 001100
3437
3438 012700 005737 001216
3439 012704 001042
3440 012706 004737 026436
3441 012712 104024
3442
3443 012714 104401 037424
3444 012720 012765 000003 000026
3445 012726 004737 026106
3446 012732 013701 005366
3447 012736 012704 035132
3448 012742 010446
3449 012744 012703 000003
3450 012750 006101
3451 012752 006101
3452 012754 006101 1$:
3453 012756 006101
3454 012760 006101
3455 012762 006101
3456 012764 010100
3457 012766 042700 177760
3458 012772 052700 000060
3459 012776 110024
3460 013000 005303
3461 013002 001364
3462 013004 105014
3463
3464 013006 004737 035400
3465
3466
3467
3468
3469
3470
3471
3472
3473
3474 013012 000004
3475 013014 012737 000001 001174
3476 013022 012706 001100
3477
3478 013026 004737 026436
3479 013032 104024
3480

PFSRT: ;ENTER HERE FOR POWER FAIL RESTART
:*****
:*TEST 5 PRINT DRIVE SERIAL NUMBER
:*
:* THIS TEST READS & PRINTS THE DRIVE SERIAL # FROM MSG A, WORD 11
:* IN BCD & IS PERFORMED ON THE 1ST PASS ONLY
:*****
TST5: SCOPE
MOV #1,$TIMES ;:DO 1 ITERATION
MOV #STACK,SP ;:RESTORE STK PTR

TST $PASS
BNE TST6 ;:GO TO NEXT IF NOT FIRST PASS
JSR PC,SUBCLR ;:DO SUBSYS CLEAR
ERROR 24 ;:CERR AFTER SCLR

TYPE ,MSG16 ;:DRIVE SERIAL NO.
MOV #3,RKMR1(R5) ;:SELECT BYTE 3
JSR PC,GSTAT ;:GET STATUS
MOV HMR2,R1 ;:GET SERIAL #
MOV #SOCTVL,R4 ;:GET ADDR CHAR BUFF
MOV R4,-(SP) ;:STORE ON STACK FOR $SUPRS
MOV #3,R3 ;:SETUP CHAR COUNT
ROL R1 ;:INITIALIZE BIT POSITIONS
ROL R1
ROL R1 1$: ;:GET NEXT 4 BITS
ROL R1
ROL R1
MOV R1,R0 ;:GET WORKING COPY
BIC #177760,R0 ;:CLEAR ALL BUT LOW 4 BITS
BIS #60,R0 ;:CONVERT TO ASCII DIGIT
MOVB R0,(R4)+ ;:PUT ASCII DIGIT INTO CHAR BUFF
DEC R3
BNE 1$ ;:BR IF ALL 3 CHARS NOT DONE
CLRB (R4) ;:ELSE INSERT NULL TERMINATOR

JSR PC,$SUPRS ;:TYPE
:
: TYPE ,SCLF
: TYPE ,SCLF

:*****
:*TEST 6 SET VV WITH PACK COMMAND
:*
:* IF VV IS RESET, THE PACK COMMAND IS USED TO SET IT.
:*****
TST6: SCOPE
MOV #1,$TIMES ;:DO 1 ITERATION
MOV #STACK,SP ;:RESTORE STK PTR

JSR PC,SUBCLR
ERROR 24 ;:CERR AFTER SCLR
    
```

```

3481 013034 032737 000100 005366 BIT #D.VV,HMR2
3482 013042 001021 BNE TST7 ;;GO TO NEXT TEST IF VV SET
3483 013044 012765 100000 000000 MOV #CCLR,RKCS1(R5)
3484 013052 013765 001222 000010 MOV $UNIT,RKCS2(R5) ;DRIVE #
3485 013060 012737 000003 005340 MOV #PACK,HCS1
3486 013066 004737 024446 JSR PC,DOCMD ;DO PACK CMD & GET CONTR RDY
3487 013072 104116 ERROR 116 ;CONTR NOT RDY
3488
3489 013074 032737 000100 005366 BIT #D.VV,HMR2
3490 013102 001001 BNE 64$
3491 013104 104027 ERROR 27 ;VOLUME VALID NOT SET AFTER PACK CMD
3492 013106
  
```

64\$:

```

*****
*TEST 7 UNLOAD DRIVE TO BE TESTED
*
* THIS TEST UNLOADS THE DRIVE TO BE TESTED NEXT,
* WAITS FOR ATTN & VERIFIES IT CAME FROM THE CORRECT DRIVE.
*
  
```

```

3501
3502 013106 000004 TST7: SCOPE
3503 013110 012737 000001 001174 MOV #1,$TIMES ;;DO 1 ITERATION
3504 013116 012706 001100 MOV #STACK,SP
3505
3506 013122 005237 005322 INC UNLD ;USED TO CHECK FOR VALID HALT
3507
3508 013126 004737 026436 JSR PC,SUBCLR
3509 013132 104024 ERROR 24 ;CERR AFTER SCLR
3510
3511 013134 012737 000007 005340 MOV #UNLOAD,HCS1
3512 013142 004737 024446 JSR PC,DOCMD ;DO UNLOAD CMD & GET CONTR READY
3513 013146 104017 ERROR 17 ;NO RDY AFTER UNLD CMD
3514 013150 004737 025024 JSR PC,TSTATN
3515 013154 104020 ERROR 20 ;NO ATTN AFTER UNLOAD CMD
  
```

.SBTTL OPERATOR INTERVENTION TESTS

```

*****
*TEST 10 INTERLOCKS TESTS
*
* THIS TEST VERIFIES THAT THE DOOR & CARTRIDGE STATUS BITS
* ARE OPERATING PROPERLY IN MESSAGE A0 & THAT THE REMOVAL
* OF THE CARTRIDGE CLEARS VOLUME VALID.
* IT FURTHER VERIFIES ALL REMAINING STATUS BITS OF
* MESSAGE A & B, WORDS 0 & 1.
* THIS TEST ALSO CHECKS THAT THE SPINDLE CANNOT BE STARTED
* WHEN THE DOOR IS OPEN OR THE CARTRIDGE IS REMOVED.
* IT ALSO VERIFIES THAT LOSS OF VOLUME VALID RESETS SACK WHICH
* ASSERTS NON EXISTENT DRIVE IN RKCS2
  
```

```

3533
3534 013156 000004 TST10: SCOPE
3535 013160 012737 000001 001174 MOV #1,$TIMES ;;DO 1 ITERATION
3536 013166 012706 001100 MOV #STACK,SP ;RESET STACK PTR
  
```



```

3537
3538 013172 004737 026436      JSR    PC,SUBCLR
3539 013176 104024                ERROR   24      ;CERR AFTER SCLR
3540
3541 013200 005237 001502      INC     BYPCERR      ;DONT DO CKCERR ROUTINE
3542
3543 013204 104401 037127      TYPE   ,MSG8        ;INTERLOCKS TEST
3544 013210 104401 042017      TYPE   ,MSG52       ;CONT-E TO EXIT OR SPACE TO CONTINUE
3545 013214 004737 030412      JSR    PC,CCSP      ;INPUT CONT-E OR SPACE
3546 013220 000137 014020      JMP     8$          ;RET HERE FOR CONT-E
3547
3548 013224 104401 041473      TYPE   ,MSG47       ;VERIFY DOOR CANNOT BE OPENED
3549 013230 104401 040625      TYPE   ,MSG37       ;DEPRESS SPACE WHEN DONE
3550 013234 004737 030452      JSR    PC,GETSP     ;GET SPACE
3551
3552 013240 104401 043464      TYPE   ,MSG65       ;DEPRESS RUN/STOP SW TO 'STOP'
3553 013244 104401 040130      TYPE   ,MSG30       ;OPEN DOOR & LEAVE IT OPEN
3554 013250 104401 040625      TYPE   ,MSG37       ;DEPRESS SPACE BAR WHEN DONE
3555 013254 004737 030452      JSR    PC,GETSP     ;INPUT SPACE
3556 013260 012765 000001 000026  MOV    #1,RKMR1(R5) ;SELECT WORD 1
3557 013266 004737 026106      JSR    PC,GSTAT
3558 013272 032737 000200 005366  BIT    #D.DOOR,HMR2
3559 013300 001401                BEQ    1$
3560 013302 104044                ERROR   44      ;DOOR STATUS BIT NOT CLEARED
3561
3562 013304 012737 000140 005430 1$:  MOV    #<D.DRA!D.VV>,E.A0 ;EXPECTED A0
3563 013312 005037 005432                CLR    E.B0
3564 013316 012737 000540 005434  MOV    #<D.HDHM!D.BRHM!D.CART>,E.A1
3565 013324 012737 000001 005436  MOV    #1,E.B1
3566
3567 013332 004737 025264      JSR    PC,CHKMSG    ;CHECK MSGS A0, B0, A1, B1
3568 013336 000000                .WORD  0!0!0      ;& MSGS SPECIFIED HERE
3569 013340 104045                ERROR   45      ;MSG A0 ERROR AFTER DRIVE UNLOADED & DOOR OPENED
3570 013342 104046                ERROR   46      ;MSH B0 ERROR
3571 013344 104063                ERROR   63      ;MSG A1 ERROR
3572 013346 104064                ERROR   64      ;MSG B1 ERROR
3573
3574 013350 004737 026436      JSR    PC,SUBCLR
3575 013354 104024                ERROR   24      ;CERR AFTER SCLR
3576
3577 013356 104401 040260      TYPE   ,MSG33       ;PRESS 'RUN-STOP' TO 'RUN'
3578 013362 104401 040345      TYPE   ,MSG34       ;VERIFY DOES NOT START
3579 013366 104401 040625      TYPE   ,MSG37
3580 013372 004737 030452      JSR    PC,GETSP     ;GET SPACE FROM TTY
3581
3582 013376 004737 026106      JSR    PC,GSTAT
3583 013402 032737 010000 005366  BIT    #D.SPIN,HMR2
3584 013410 001401                BEQ    2$
3585 013412 104065                ERROR   65      ;SPIN SET IN MSGA0
3586
3587 013414 012737 000140 005430 2$:  MOV    #<D.DRA!D.VV>,E.A0 ;EXPECTED MSG A0
3588 013422 005037 005432                CLR    E.B0
3589 013426 012737 000540 005434  MOV    #<D.HDHM!D.BRHM!D.CART>,E.A1
3590 013434 012737 000001 005436  MOV    #1,E.B1
3591
3592 013442 004737 025264      JSR    PC,CHKMSG    ;CHECK MSGS A0, B0, A1, B1
    
```

3593	013446	000000			.WORD	0!0!0		:& MSGS SPECIFIED HERE
3594	013450	104066			ERROR	66		:MSG A0 ERROR AFTER ATTEMPT TO START SPIN & DOOR OPEN
3595	013452	104067			ERROR	67		:MSH B0 ERROR
3596	013454	104070			ERROR	70		:MSG A1 ERROR
3597	013456	104071			ERROR	71		:MSG B1 ERROR
3598								
3599	013460	004737	026436		JSR	PC,SUBCLR		
3600	013464	104024			ERROR	24		:CERR AFTER SCLR
3601								
3602	013466	104401	043464		TYPE	,MSG65		:DEPRESS 'RUN-STOP' SW TO STOP
3603	013472	104401	040220		TYPE	,MSG32		:REMOVE PACK & CLOSE DOOR
3604	013476	104401	040625		TYPE	,MSG37		
3605	013502	004737	030452		JSR	PC,GETSP		:GET SPACE FROM TTY
3606								
3607	013506	012765	000001	000026	MOV	#1,RKMR1(R5)		:SELECT WORD 1
3608	013514	004737	026106		JSR	PC,GSTAT		
3609	013520	032737	000400	005366	BIT	#D.CART,HMR2		
3610	013526	001401			BEQ	5\$		
3611	013530	104072			ERROR	72		:CARTRIDGE STATUS BIT NOT RESET
3612								
3613								
3614	013532	004737	026436		3\$: JSR	PC,SUBCLR		
3615	013536	104024			ERROR	24		:CERR AFTER SCLR
3616								
3617	013540	104401	040433		TYPE	,MSG35		:PRESS 'RUN-STOP' TO 'RUN'
3618	013544	104401	040345		TYPE	,MSG34		:VERIFY DOES NOT START
3619	013550	104401	040625		TYPE	,MSG37		
3620	013554	004737	030452		JSR	PC,GETSP		:GET SPACE FROM TTY
3621								
3622	013560	004737	026106		JSR	PC,GSTAT		
3623	013564	032737	010000	005366	BIT	#D.SPIN,HMR2		
3624	013572	001401			BEQ	5\$		
3625	013574	104100			ERROR	100		:SPIN SET IN MSG A0
3626								
3627	013576	104401	043464		5\$: TYPE	,MSG65		:PRESS 'RUN-STOP' TO 'STOP'
3628	013602	104401	040530		TYPE	,MSG36		:INSERT CARTRIDGE, SET 'RUN' SW. & CLOSE DOOR
3629	013606	104401	043724		TYPE	,MSG70		:VERIFY HEADS LOAD
3630	013612	104401	043647		TYPE	,MSG69		:DEPRESS SPACE WHEN READY GOES ON
3631	013616	004737	030452		JSR	PC,GETSP		:GET SPACE FROM TTY
3632	013622	005037	005322		CLR	UNLD		:FOR VALID HALT
3633								
3634	013626	012765	100000	000000	MOV	#CCLR,RKCS1(R5)		
3635	013634	005065	000026		CLR	RKMR1(R5)		:SELECT WORD 0
3636	013640	004737	026106		JSR	PC,GSTAT		
3637	013644	032737	000100	005366	BIT	#D.VV,HMR2		
3638	013652	001401			BEQ	7\$		
3639	013654	104033			ERROR	33		:VV NOT CLEARED AFTER PACK RE-INSERTED
3640								
3641	013656	012737	050240	005430	7\$: MOV	#<D.DSC!D.SPIN!D.DRDY!D.DRA>,E.A0		:EXPECTED A0
3642	013664	005037	005432		CLR	E.B0		
3643	013670	012737	001720	005434	MOV	#<D.SPOK!D.CART!D.SSP!D.BRHM!D.DOOR>,E.A1		
3644	013676	012737	000001	005436	MOV	#1,E.B1		
3645								
3646	013704	004737	025264		JSR	PC,CHKMSG		:CHECK MSGS A0, B0, A1, B1
3647	013710	000000			.WORD	0!0!0		:& MSGS SPECIFIED HERE
3648	013712	104074			ERROR	74		:MSG A0 ERROR AFTER PACK REINSERTED & HEADS LOADED

CZ
CZ


```

3649 013714 104075          ERROR 75          :MSH B0 ERROR
3650 013716 104076          ERROR 76          :MSG A1 ERROR
3651 013720 104077          ERROR 77          :MSG B1 ERROR
3652
3653 013722 012765 100000 000000  MOV #CCLR,RKCS1(R5)
3654 013730 013765 001222 000010  MOV $UNIT,RKCS2(R5) :DRIVE #
3655 013736 012737 000003 005340  MOV #PACK,HCS1
3656 013744 004737 024446          JSR PC,DOCMD        :DO PACK CMD & GET CONTR RDY
3657 013750 104116          ERROR 116         :CONTR NOT RDY
3658
3659 013752 032737 000100 005366  BIT #D.VV,HMR2
3660 013760 001001          BNE 64$
3661 013762 104027          ERROR 27          :VOLUME VALID NOT SET AFTER PACK CMD
3662 013764          64$:
3663 013764 005237 005322          INC UNLD          :FOR VALID HALT
3664
3665 013770 004737 026436          JSR PC,SUBCLR
3666 013774 104024          ERROR 24          :CERR AFTER SCLR
3667
3668 013776 012737 000007 005340  MOV #UNLOAD,HCS1
3669 014004 004737 024446          JSR PC,DOCMD        :DO UNLOAD CMD & GET CONTR READY
3670 014010 104017          ERROR 17          :NO RDY AFTER UNLD CMD
3671 014012 004737 025024          JSR PC,TSTATN
3672 014016 104020          ERROR 20          :NO ATTN AFTER UNLOAD CMD
3673 014020          8$:
3674
3675
3676
3677
3678
3679
3680
3681
3682
3683
3684
3685
3686
3687 014020 000004          TST11: SCOPE
3688 014022 012737 000001 001174  MOV #1,$TIMES      ;;DO 1 ITERATION
3689 014030 012706 001100          MOV #STACK,SP      :RESTORE STACK PTR
3690
3691 014034 004737 026436          JSR PC,SUBCLR
3692 014040 104024          ERROR 24          :CERR AFTER SCLR
3693
3694 014042 104401 037500          TYPE ,MSG18        :UNIT SELECT PLUG TEST
3695 014046 104401 042017          TYPE ,MSG52        :CONT-E TO EXIT OR SPACE TO CONTINUE
3696 014052 004737 030412          JSR PC,CCSP        :INPUT CONT-E OR SPACE
3697 014056 000137 014652          JMP 12$            :RETURN HERE FOR CONT-E
3698
3699 014062 012765 000020 000026  MOV #PAT,RKMR1(R5) :EVEN PARITY TO GET DSC & ATTN
3700 014070 004737 026106          JSR PC,GSTAT
3701 014074 032737 001000 005370  BIT #D.PAR,HMR3   :SEE IF PARITY SET
3702 014102 001001          BNE 2$            :BR IF YES
3703 014104 104114          ERROR 114         :PARITY BIT NOT SET AFTER SEL DRIVE CMD
3704

```

```

3705 014106 032737 040000 005366 2$: BIT #D.DSC,HMR2 ;SEE IF DSC SET
3706 014114 001001 BNE 1$
3707 014116 104107 ERROR 107 ;DSC NOT SET AFTER SEL DRV WITH EVEN PARITY
3708
3709 014120 012765 100000 000000 1$: MOV #CCLR,RKCS1(R5)
3710 014126 004737 026106 JSR PC,GSTAT
3711 014132 004737 025024 JSR PC,TSTATN
3712 014136 104113 ERROR 113 ;NO ATTN AFTER SEL DRV WITH EVEN PARITY
3713
3714 014140 104401 037153 TYPE ,MSG9 ;REMOVE UNIT SELECT PLUG
3715 014144 104401 040625 TYPE ,MSG37 ;DEPRESS SPACE WHEN DONE
3716 014150 004737 030452 JSR PC,GETSP ;GET SPACE
3717
3718 014154 012765 100000 000000 MOV #CCLR,RKCS1(R5)
3719 014162 004737 026106 JSR PC,GSTAT
3720 014166 004737 025024 JSR PC,TSTATN ;RETURN HERE FOR SPACE
3721 014172 000401 BR 3$ ;NO ATTN
3722 014174 104111 ERROR 111 ;REMOVING UNIT SEL PLUG, DID NOT
3723 ;DISABLE ATTN.
3724 014176 012765 100000 000000 3$: MOV #CCLR,RKCS1(R5)
3725 014204 004737 026106 JSR PC,GSTAT
3726 014210 032765 010000 000010 BIT #NED,RKCS2(R5)
3727 014216 001001 BNE 4$
3728 014220 104112 ERROR 112 ;REMOVING UNIT SEL PLUG DID NOT
3729 ;ASSERT NON-EXISTENT DRIVE
3730
3731 014222 104401 043532 4$: TYPE ,MSG67 ;DESELECT ALL OTHER PORTS
3732 014226 104401 040625 TYPE ,MSG37 ;TYPE SPACE WHEN DONE
3733 014232 004737 030452 JSR PC,GETSP ;GET SPACE
3734
3735 014236 104401 040671 TYPE ,MSG38 ;INSERT UNIT SELECT PLUGS
3736 014242 104401 041027 TYPE ,MSG39 ;DEPRESS CONTROL-E WHEN FINISHED
3737 014246 104401 042300 TYPE ,MSG55 ;EXIT WITH CORRECT UNIT SELECT PLUG #
3738 014252 013746 001222 MOV $UNIT,-(SP) ;:SAVE $UNIT FOR TYPEOUT
3739 ;:TYPE CORRECT#
3740 014256 104403 TYPOS ;:GO TYPE--OCTAL ASCII
3741 014260 001 .BYTE 1 ;:TYPE 1 DIGIT(S)
3742 014261 000 .BYTE 0 ;:SUPPRESS LEADING ZEROS
3743 014262 104401 001205 TYPE ,$CRLF
3744
3745 014266 105037 033414 CLRB $TKQSRT ;CLEAR PREVIOUS INFO
3746 014272 005037 001160 CLR $TMP0
3747
3748 014276 004737 033416 5$: JSR PC,$TKINT
3749 014302 113737 033414 001160 MOV $TKQSRT,$TMP0 ;GET CHAR IF THERE
3750 014310 042737 177600 001160 BIC #^C<177>,$TMP0 ;GET RID OF JUNK, IF ANY
3751 014316 005737 001160 TST $TMP0
3752 014322 001422 BEQ 6$ ;BR IF NOTHING TYPED YET
3753 014324 023727 001160 000005 CMP $TMP0,#5 ;SEE IF CONT-E
3754 014332 001470 BEQ 9$ ;BR IF YES
3755 014334 023727 001160 000003 CMP $TMP0,#3 ;SEE IF CONT-C
3756 014342 001004 BNE 13$ ;BR IF NO
3757 014344 004737 033416 JSR PC,$TKINT ;ENABLE KB INT
3758 014350 000137 030502 JMP STOP1 ;ELSE DO VALID HALT
3759 014354 104401 040212 13$: TYPE ,MSG31 ;?
3760 014360 105037 033414 CLRB $TKQSRT
  
```



```

3761 014364 004737 033416 JSR PC,$TKINT
3762
3763 014370 005000 6$: CLR R0
3764 014372 012765 100000 000000 7$: MOV #CCLR,RKCS1(R5)
3765 014400 010065 000010 :DRIVE NO.
3766 014404 012737 000001 005340 MOV R0,RKCS2(R5)
3767 014412 004737 024446 JSR #SELDRV,HCS1
3768 014416 104117 JSR PC,DOCMD :DO SELDRV (STATUS) CMD & GET CONTR RDY
3769 ERROR 117 :CONTR RDY NOT SET
3770 014420 032765 010000 000010 BIT #NED,RKCS2(R5) :SEE IF UNIT SELECT PLUG INSERTED
3771 014426 001405 BEQ 8$ :& IF MATCH DRIVE NO IN CS2. BR IF YES
3772 014430 005200 INC R0
3773 014432 020027 000010 CMP R0,#8. :ALL 8 DRIVE NOS TRIED?
3774 014436 001355 BNE 7$ :BR IF NO
3775 014440 000716 BR 5$ :ELSE RETURN
3776
3777 014442 032737 000100 005366 8$: BIT #D.VV,HMR2
3778 014450 001312 BNE 5$ :TYPE SAME UNIT SELECT PLUG RDY ONCE
3779 014452 012765 100000 000000 MOV #CCLR,RKCS1(R5)
3780 014460 010065 000010 MOV R0,RKCS2(R5) :DRIVE ADDR
3781 014464 012737 000003 005340 MOV #PACK,HCS1
3782 014472 004737 024446 JSR PC,DOCMD :DO PACK CMD & GET CONTR RDY
3783 014476 104116 ERROR 116 :CONTR NOT RDY
3784 014500 010046 MOV R0,-(SP) ::SAVE R0 FOR TYPEOUT
3785 :TYPE UNIT SEL PLUG NO.
3786 014502 104403 TYPOS :GO TYPE--OCTAL ASCII
3787 014504 001 .BYTE 1 :TYPE 1 DIGIT(S)
3788 014505 000 .BYTE 0 :SUPPRESS LEADING ZEROS
3789 014506 104401 001205 TYPE $CRLF
3790 014512 000671 BR 5$
3791
3792 014514 004737 033416 9$: JSR PC,$TKINT :ENABLE KB INT
3793 014520 012765 100000 000000 MOV #CCLR,RKCS1(R5)
3794 014526 013765 001222 000010 MOV $UNIT,RKCS2(R5)
3795 014534 012737 000001 005340 MOV #SELDRV,HCS1
3796 014542 004737 024446 JSR PC,DOCMD :DO SELDRV (STATUS) CMD & GET CONTR RDY
3797 014546 104117 ERROR 117 :CONT NOT RDY AFTER SEL DRV CMD
3798
3799 014550 032765 010000 000010 BIT #NED,RKCS2(R5) :SEE IF CORRECT PLUG FOR EXIT
3800 014556 001411 BEQ 10$ :BR IF YES
3801 014560 104401 042300 TYPE $MSG55 :EXIT WITH CORRECT UNIT SELECT PLUG NO.
3802 014564 013746 001222 MOV $UNIT,-(SP) ::SAVE $UNIT FOR TYPEOUT
3803 :TYPE CORRECT UNIT SEL PLUG #
3804 014570 104403 TYPOS :GO TYPE--OCTAL ASCII
3805 014572 001 .BYTE 1 :TYPE 1 DIGIT(S)
3806 014573 000 .BYTE 0 :SUPPRESS LEADING ZEROS
3807 014574 104401 041027 TYPE $MSG39 :DEPRESS CONT-E WHEN DONE
3808 014600 000636 BR 5$
3809
3810 014602 004737 026436 10$: JSR PC,SUBCLR
3811 014606 104024 ERROR 24 :CERR AFTER SCLR
3812
3813 014610 004737 026106 JSR PC,GSTAT
3814 014614 032737 000100 005366 BIT #D.VV,HMR2
3815 014622 001005 BNE 11$
3816 014624 104401 041072 TYPE $MSG40 :VV NOT SET, INSERT UNIT SELECT PLUG

```

```

3817 014630 104401 041027          TYPE  ,MSG39          ;DEPRESS CONT-E TO EXIT TEST
3818 014630 000620                    BR      5$
3819
3820 014636 104401 043752          11$:  TYPE  ,MSG71          ;SELECT CORRECT PORT ON OTHER DRIVES
3821 014642 104401 040625          TYPE  ,MSG37          ;TYPE SPACE WHEN DONE
3822 014646 004737 030452          JSR    PC,GETSP       ;GET SPACE
3823 014652
3824
3825
3826
3827
3828
3829
3830
3831
3832
3833
3834 014652 000004                    TST12: SCOPE
3835 014654 012737 000001 001174  MOV    #1,$TIMES      ;;DO 1 ITERATION
3836 014662 012706 001100          MOV    #STACK,SP     ;RESTORE STACK PTR
3837
3838 014666 004737 026436          JSR    PC,SUBCLR     ;CERR AFTER SCLR
3839 014672 104024
3840
3841 014674 104401 037532          TYPE  ,MSG19          ;PORT SELECTION TESTS
3842 014700 104401 042017          TYPE  ,MSG52          ;DEPRESS CONT-E TO EXIT OR SPACE BAR TO CONTINUE
3843 014704 004737 030412          JSR    PC,CCSP       ;INPUT CONT-E OR SPACE
3844 014710 000137 015070          JMP    4$            ;RETURN HERE FOR CONT-E
3845
3846 014714 104401 041204          TYPE  ,MSG41          ;SWITCH TO OTHER PORT
3847 014720 104401 040625          TYPE  ,MSG37          ;DEPRESS SPACE WHEN DONE
3848 014724 004737 030452          JSR    PC,GETSP     ;GET SPACE
3849
3850 014730 004737 026106          JSR    PC,GSTAT
3851 014734 032765 010000 000010  BIT    #NED,RKCS2(R5)
3852 014742 001001
3853 014744 104122          BNE    1$            ;NED NOT SET AFTER WRONG PORT SELECTED
3854
3855
3856 014746 104401 041264          1$:  TYPE  ,MSG42          ;SELECT CORRECT PORT
3857 014752 104401 040625          TYPE  ,MSG37          ;DEPRESS SPACE BAR WHEN DONE
3858 014756 004737 030452          JSR    PC,GETSP     ;GET SPACE
3859
3860 014762 004737 026436          JSR    PC,SUBCLR     ;CERR AFTER SCLR
3861 014766 104024
3862
3863 014770 032765 010000 000010  BIT    #NED,RKCS2(R5)
3864 014776 001401
3865 015000 104130          BEQ    2$            ;NED NOT CLEARED AFTER CORRECT PORT SELECTED
3866
3867 015002 104401 041342          2$:  TYPE  ,MSG43          ;DESELECT BOTH PORTS
3868 015006 104401 040625          TYPE  ,MSG37          ;DEPRESS SPACE BAR WHEN DONE
3869 015012 004737 030452          JSR    PC,GETSP
3870 015016 004737 026106          JSR    PC,GSTAT
3871 015022 032765 010000 000010  BIT    #NED,RKCS2(R5)
3872 015030 001001          BNE    3$
    
```



```

3873 015032 104133          ERROR 133          ;NED NOT SET AFTER BOTH PORTS DESELECTED
3874
3875
3876 015034 104401 041372    3$:  TYPE      ,MSG44          ;SELECT CORRECT PORT
3877 015040 104401 040625    TYPE      ,MSG37          ;DEPRESS SPACE BAR WHEN DONE
3878 015044 004737 030452    JSR      PC,GETSP
3879
3880 015050 004737 026436    JSR      PC,SUBCLR
3881 015054 104024          ERROR 24          ;CERR AFTER SCLR
3882
3883 015056 032765 010000 000010  BIT      #NED,RKCS2(R5)
3884 015064 001421          BEQ      TST13          ;;GOTO NEXT TEST
3885 015066 104130          ERROR 130         ;NED NOT CLEARED AFTER CORRECT PORT SELECTED
3886
3887 015070 012765 100000 000000 4$:  MOV      #CCLR,RKCS1(R5)
3888 015076 004737 026106    JSR      PC,GSTAT
3889 015102 032765 010000 000010  BIT      #NED,RKCS2(R5)
3890 015110 001407          BEQ      TST13          ;;GOTO NEXT TEST
3891 015112 104401 041422    TYPE      ,MSG45         ;CORRECT PORT NOT SELECTED, TRY AGAIN
3892 015116 104401 040625    TYPE      ,MSG37         ;DEPRESS SPACE BAR WHEN DONE
3893 015122 004737 030452    JSR      PC,GETSP
3894 015126 000760          BR       4$
3895
3896
3897
3898
3899
3900
3901
3902
3903
3904
3905
3906
3907
3908

```

```

:*****
:*TEST 13          AC LOW DETECTION PART 1
:*
:*  A PRELIMINARY AC LOW TEST IS PERFORMED HERE WHILE HEADS ARE UNLOADED.
:*  BATTERY RETRACT WILL BE TESTED LATER.
:*  ACLO CANNOT BE TESTED DIRECTLY SINCE IT REQUIRES SECTOR PULSES
:*  I.E. HEADS LOADED.
:*  THEREFORE THE INDICATOR CHECKED IS NON-EXISTENT DRIVE (NED)
:*  ASSERTING IN RKCS2 AS A RESULT OF DCLO.
:*  AFTER POWER UP, VOLUME VALID IS CHECKED TO BE CLEARED.
:*
:*****

```

```

3909 015130 000004          TST13: SCOPE
3910 015132 012737 000001 001174  MOV      #1,$TIMES          ;;DO 1 ITERATION
3911 015140 012706 001100    MOV      #STACK,SP         ;RESTORE STK PTR
3912
3913 015144 004737 026436    JSR      PC,SUBCLR
3914 015150 104024          ERROR 24          ;CERR AFTER SCLR
3915
3916 015152 104401 037563    TYPE      ,MSG21          ;AC LOW TEST
3917 015156 104401 042017    TYPE      ,MSG52          ;CONT-E TO BYPASS TEST
3918
3919 015162 004737 030412    JSR      PC,CCSP          ;OR SPACE TO CONTINUE
3920 015166 000137 015442    JMP      10$             ;INPUT CONT-E OR SPACE
3921 015172 104401 041553    TYPE      ,MSG49          ;RETURN HERE IF CONT-E
3922
3923 015176 005037 005400          ;TURN OFF AC(RET HERE IF SPACE)
3924 015202 012737 177777 005376 12$:  CLR      TEMP2
3925 015210 004737 026106    MOV      #-1,TEMP1        ;SETUP TIMEOUT
3926 015214 032737 100000 005340 1$:  JSR      PC,GSTAT
3927 015222 001012          BIT      #CERR,HCS1
3928 015224 005337 005376    BNE     3$
                                DEC     TEMP1

```

```

3929 015230 001367          BNE      1$
3930 015232 005237 005400    INC      TEMP2
3931 015236 023727 005400 000002    CMP     TEMP2,#2      ;SEE IF GONE THRU 2 TIMES
3932 015244 001356          BNE      12$          ;BR IF NO
3933 015246 104146          ERROR    146          ;CERR NOT DETECTED BEFORE TIMEOUT
3934 015250 013737 001432 005376 3$:    MOV     T50000,TEMP1
3935 015256 012765 100000 000000 4$:    MOV     #CCLR,RKCS1(R5)
3936 015264 004737 026106          JSR     PC,GSTAT
3937 015270 032765 010000 000010    BIT     #NED,RKCS2(R5)
3938 015276 001004          BNE      5$
3939 015300 005337 005376          DEC     TEMP1
3940 015304 001364          BNE      4$
3941 015306 104150          ERROR    150          ;NED NOT SET BEFORE TIMEOUT
3942
3943 015310 104401 041626          5$:    TYPE   ,MSG50          ;SWITCH AC BACK ON
3944 015314 104401 043724          TYPE   ,MSG70          ;VERIFY HEADS LOAD
3945 015320 104401 043647          TYPE   ,MSG69          ;PRESS SPACE AFTER READY ON
3946 015324 004737 030452          JSR     PC,GETSP       ;GET SPACE
3947
3948 015330 004737 026436          JSR     PC,SUBCLR
3949 015334 104024          ERROR    24          ;CERR AFTER SCLR
3950
3951 015336 032737 000200 005366    BIT     #D.DRDY,HMR2   ;SEE IF LOADED
3952 015344 001001          BNE      6$          ;BR IN YES
3953 015346 104141          ERROR    141          ;DRV NOT RDY AFTER AC UP
3954
3955 015350 005037 005322          6$:    CLR     UNLD          ;FOR VALID HALT
3956 015354 032737 000100 005370    BIT     #D.ACLO,HMR3
3957 015362 001401          BEQ     7$
3958 015364 104152          ERROR    152          ;ACLO NOT RESET AFTER POWER UP
3959
3960 015366 032737 000100 005366 7$:    BIT     #D.VV,HMR2
3961 015374 001401          BEQ     8$
3962 015376 104153          ERROR    153          ;VV NOT RESET AFTER POWER UP
3963
3964 015400          8$:
3965 015400 012765 100000 000000    MOV     #CCLR,RKCS1(R5)
3966 015406 013765 001222 000010    MOV     $UNIT,RKCS2(R5) ;DRIVE #
3967 015414 012737 000003 005340    MOV     #PACK,HCS1
3968 015422 004737 024446          JSR     PC,DOCMD       ;DO PACK CMD & GET CONTR RDY
3969 015426 104116          ERROR    116          ;CONTR NOT RDY
3970
3971 015430 032737 000100 005366    BIT     #D.VV,HMR2
3972 015436 001001          BNE      64$
3973 015440 104027          ERROR    27          ;VOLUME VALID NOT SET AFTER PACK CMD
3974
3975 015442          64$:
3976          10$:
3977          ;*****
3978          ;*TEST 14      CHECK NXF LOGIC
3979          ;*
3980          ;*      THIS TEST VERIFIES NON-EXECUTABLE FUNCTION (NXF) IS DETECTED
3981          ;*      AS A RESULT OF DOING A SEEK WITH VOLUME VALID RESET.
3982          ;*
3983          ;*****
3984 015442 000004          TST14: SCOPE
  
```



```

3985 015444 012737 000001 001174      MOV      #1,STIMES      ;;DO 1 ITERATION
3986 015452 012706 001100              MOV      #STACK,SP    ;RESTORE STACK PTR
3987
3988 015456 004737 026436      JSR      PC,SUBCLR
3989 015462 104024              ERROR    24           ;CERR AFTER SCLR
3990
3991 015464 032737 010000 005366      BIT      #D.SPIN,HMR2  ;SEE IF SPINDLE ALREADY ON
3992 015472 001020              BNE      64$          ;BR IF YES
3993 015474 104401 040064      TYPE     ,MSG29       ;PLEASE WAIT, HEADS BEING LOADED
3994
3995 015500 012737 000011 005340      MOV      #SRTSPL,HCS1
3996 015506 004737 024446      JSR      PC,DOCMD     ;DO START SPINDLE CMD & GET CONTR RDY
3997 015512 104143      ERROR    143         ;CONTR RDY NOT SET AFTER CMD
3998
3999 015514 013737 001426 005400      MOV      T100,TEMP2
4000 015522 004737 025056      JSR      PC,FATT1     ;FIND ATTN
4001 015526 104144      ERROR    144         ;NO ATTN AFTER CMD
4002
4003 015530 005037 005322              CLR      UNLD
4004 015534              64$:
4005 015534 005037 005322              CLR      UNLD         ;FOR VALID HALT
4006
4007 015540 004737 026436      JSR      PC,SUBCLR
4008 015544 104024      ERROR    24           ;CERR AFTER SCLR
4009
4010 015546 104401 037624      TYPE     ,MSG22       ;NXF TEST
4011 015552 104401 042017      TYPE     ,MSG52       ;PRESS CONT-E TO EXIT OR SPACE TO CONTINUE
4012 015556 004737 030412      JSR      PC,CCSP
4013 015562 000137 016070      JMP      7$           ;RETURN HERE FOR CONT-E
4014
4015 015566 104401 041676      TYPE     ,MSG51       ;REMOVE UNIT SELECT PLUG TO CLEAR VV
4016 015572 104401 040625      TYPE     ,MSG37       ;PRESS SPACE WHEN DONE
4017 015576 004737 030452      JSR      PC,GETSP     ;GET SPACE
4018
4019 015602 004737 026106      JSR      PC,GSTAT
4020 015606 032737 000100 005366      BIT      #D.VV,HMR2
4021 015614 001403              BEQ      1$
4022 015616 104177      ERROR    177         ;VV NOT CLEARED AFTER UNIT SEL PLUG
4023 015620 000137 016070      JMP      7$           ;EXIT TEST
4024
4025 015624 032737 000100 005366 1$:
4026 015632 001406              BEQ      2$
4027 015634 104155      ERROR    155         ;VV SET AFTER HEADS LOADED
4028 015636 000137 016070      JMP      7$           ;EXIT TEST
4029
4030 015642 004737 026436      JSR      PC,SUBCLR
4031 015646 104024      ERROR    24           ;CERR AFTER SCLR
4032
4033 015650 012765 000001 000020 2$:
4034 015656 012737 000017 005340      MOV      #1,RKDC(R5)
4035 015664 004737 024446      MOV      #SEEK,HCS1
4036 015670 104131      JSR      PC,DOCMD     ;DO SEEK CMD & GET CONTR READY
4037
4038 015672 013737 001432 005376      ERROR    131         ;NO RDY AFTER SEEK CMD
4039 015700 004737 025152      MOV      T50000,TEMP1
4040 015704 104132      JSR      PC,FATT2     ;FIND ATTN
                                ERROR    132         ;NO ATTN AFTER SEEK CMD
    
```

```

4041
4042 015706 032737 000400 005370      BIT      #D.NXF,HMR3
4043 015714 001003                      BNE      3$
4044 015716 104156                      ERROR   156      ;NXF NOT SET AFTER SEEK WITH VV=0
4045 015720 000137 016070      JMP      7$      ;EXIT TEST
4046
4047 015724 032737 000200 005370 3$:   BIT      #D.FLT,HMR3
4048 015732 001003                      BNE      4$
4049 015734 104172                      ERROR   172      ;NXF DID NOT SET FAULT
4050 015736 000137 016070      JMP      7$      ;EXIT TEST
4051
4052 015742 012737 050240 005430 4$:   MOV      #<D.DSC!D.SPIN!D.DRDY!D.DRA>,E.A0 ;EXPECTED A0
4053 015750 012737 000600 005432      MOV      #<D.NXF!D.FLT>,E.B0
4054 015756 012737 001720 005434      MOV      #<D.SPOK!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1
4055 015764 012737 000001 005436      MOV      #1,E.B1
4056
4057 015772 004737 025264      JSR      PC,CHKMSG      ;CHECK MSGS A0, B0, A1, B1
4058 015776 000003                      .WORD   T.A2!T.B2!0      ;& MSGS SPECIFIED HERE
4059 016000 104160                      ERROR   160      ;MSG A0 ERROR AFTER SEEK WITH VV=0
4060 016002 104161                      ERROR   161      ;MSH B0 ERROR
4061 016004 104162                      ERROR   162      ;MSG A1 ERROR
4062 016006 104163                      ERROR   163      ;MSG B1 ERROR
4063 016010 005737 001400      TST      CYLADD
4064 016014 001401                      BEQ      5$
4065 016016 104157                      ERROR   157      ;HEADS MOVED WITH SEEK & DXF
4066
4067 016020 004737 026436      JSR      PC,SUBCLR      5$:
4068 016024 104024                      ERROR   24      ;CERR AFTER SCLR
4069
4070 016026 012765 100000 000000      MOV      #CCLR,RKCS1(R5)
4071 016034 013765 001222 000010      MOV      $UNIT,RKCS2(R5) ;DRIVE #
4072 016042 012737 000003 005340      MOV      #PACK,HCS1
4073 016050 004737 024446      JSR      PC,DOCMD      ;DO PACK CMD & GET CONTR RDY
4074 016054 104116                      ERROR   116      ;CONTR NOT RDY
4075
4076 016056 032737 000100 005366      BIT      #D.VV,HMR2
4077 016064 001001                      BNE      65$
4078 016066 104027                      ERROR   27      ;VOLUME VALID NOT SET AFTER PACK CMD
4079 016070      65$:
4080 016070      7$:

```

```

4081
4082 ::*****
4083 *TEST 15      READ & SAVE BAD SECTOR INFO & TYPE PACK SERIAL #
4084 *
4085 *      THIS TEST VERIFIES THAT CYL 632 (1456 FOR RK07), TRACK 2 CAN BE READ.
4086 *      THIS AREA CONTAINS BAD SECTOR INFOR WHICH IS WRITTEN BY THE
4087 *      FACTORY DURING MANF. ALL BAD SECTOR INFOR (BSE) WILL BE STORED
4088 *      AT THIS TIME TO MASK FUTURE READ HEADER OR DATA ERROR PRINTOUTS.
4089 *
4090 *      SECTORS 0,2,4,6,8 CONTAIN IDENTICAL INFO FOR 22 SECTOR HARDWARE DETECTED BAD SEC
4091 *      SECTORS 10,12,14,16,18,20 CONTAIN IDENTICAL INFO FOR 22 SECTOR SOFTWARE DETECTED
4092 *
4093 *      IF BSE INFO CANNOT BE READ, OR IF AFTER READING THE BSE INFO
4094 *      IT IS DETERMINED THAT AN ALIGNMENT CARTRIDGE IS USED,
4095 *      A MESSAGE WILL BE TYPED INDICATING THAT ALL
4096 *      FUTURE FORMAT AND READ-WRITE TESTS WILL BE BYPASSED.

```



```

4097
4098
4099
4100
4101
4102 016070 000004
4103 016072 012737 000001 001174
4104 016100 012706 001100
4105
4106 016104 004737 026436
4107 016110 104024
4108 016112 005037 005400
4109 016116 005037 005402
4110
4111
4112 016122 012737 002322 005404
4113 016130 013765 005404 000004
4114 016136 012737 001000 005406
4115 016144 013765 005406 000006
4116
4117 016152 013765 012654 000020 1$:
4118 016160 012765 177400 000002
4119 016166 012737 000021 005340
4120 016174 004737 024504
4121 016200 104226
4122 016202 004737 026106
4123 016206 032737 100000 005340
4124 016214 001470
4125 016216 104227
4126
4127 016220 012737 010340 005430
4128 016226 005037 005432
4129 016232 012737 001720 005434
4130 016240 012737 000001 005436
4131 016246 005037 005440
4132 016252 012737 000002 005442
4133 016260 012737 000003 005446
4134
4135 016266 004737 025264
4136 016272 000000
4137 016274 104054
4138 016276 104026
4139 016300 104056
4140 016302 104030
4141 016304 004737 026436
4142 016310 104024
4143 016312 005237 005400
4144 016316 023727 005400 000005
4145 016324 001007
4146 016326 005737 005402
4147 016332 001002
4148 016334 104165
4149 016336 000414
4150 016340 104167
4151 016342 000412
4152

```

```

: * THIS IS DONE SO AS NOT TO DESTROY BSE INFOR OR AN ALIGNMENT PACK BY WRITING
: *
: * THE PACK SERIAL # IS TYPED IN OCTAL & FOR THE FIRST PASS ONLY.
: *
: *****
TST15: SCOPE
MOV #1,$TIMES ;:DO 1 ITERATION
MOV #STACK,SP ;:RESTORE STK PTR
JSR PC,SUBCLR
ERROR 24 ;:CERR AFTER SCLR
CLR TEMP2 ;:SECTOR CTR
CLR TEMP3 ;:0=22 SECTOR HARDWARE DETECTED TABLE
;:1=22 SECTOR SOFTWARE DETECTED TABLE
;:2=DONE
MOV #BSE22H,TEMP4 ;:STORE 22 SECTOR HARDWARE BSE ADDR.
MOV TEMP4,RKBA(R5)
MOV #1000,TEMP5 ;:TRACK 2, SECTOR 0
MOV TEMP5,RKDA(R5)
1$: MOV LC,RKDC(R5) ;:LAST CYL
MOV #-256,RKWC(R5) ;:LOAD WORD CT
MOV #RDATA,HCS1
JSR PC,DATCMD ;:DO READ DATA CMD & GET CONTR RDY
ERROR 226 ;:NO RDY AFTER READ DATA CMD
JSR PC,GSTAT ;:GET FRESH DATA
BIT #CERR,HCS1
BEQ 8$
ERROR 227 ;:CERR AFTER READ DATA CMD
MOV #<0!D.SPIN!D.DRDY!D.VV!D.DRA>,E.A0 ;:EXPECTED MSG A0
CLR E.B0 ;:EXPECTED MSG B0
MOV #<D.SPOK!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1 ;:EXPECTED A1
MOV #1,E.B1 ;:MSG ID FOR EXPECTED MSG B1
CLR E.A2 ;:EXPECTED MSG A2
MOV #2,E.B2 ;:MSG ID FOR EXPECTED MSG B2
MOV #3,E.B3 ;:MSG ID FOR EXPECTED MSG B3
JSR PC,CHKMSG ;:CHECK MSGS A0, B0, A1, B1
WORD 0!0!0 ;:& MSGS SPECIFIED HERE
ERROR 54 ;:MSG A0 ERROR AFTER READ DATA CMD
ERROR 26 ;:MSH B0 ERROR
ERROR 56 ;:MSG A1 ERROR
ERROR 30 ;:MSG B1 ERROR
JSR PC,SUBCLR
ERROR 24 ;:CERR AFTER SUBCLR
INC TEMP2
CMP TEMP2,#5 ;:READ ALL 5 SECTORS?
BNE 5$
TST TEMP3
BNE 2$
ERROR 165 ;:CANT READ SECTORS 0,2,4,6,8
BR 3$
2$: ERROR 167 ;:CANT READ SECTORS 10,12,14,16,18,20
BR 3$

```

```

4153 016344 013765 005404 000004 5$: MOV TEMP4,RKBA(R5) ;RESTORE TABLE ADDR
4154 016352 062737 000002 005406 ADD #2,TEMP5 ;SETUP TO READ 2 SECTORS FROM LAST
4155 016360 013765 005406 000006 MOV TEMP5,RKDA(R5)
4156 016366 000671 BR 1$
4157
4158 016370 005237 001474 3$: INC BSERR ;SET BSE FLAG
4159 016374 000501 BR TST16 ;GO TO NEXT TEST
4160 016376 005737 002330 8$: TST BSE22H+6 ;TEST CARTRIDGE TYPE
4161 016402 001405 BEQ 9$ ;BRANCH IF DATA CARTRIDGE
4162 016404 104401 042360 TYPE ,MSG56 ;ALIGNMENT CARTRIDGE USED
4163 016410 005237 001474 INC BSERR ;SET BSE ERROR FLAG
4164 016414 000426 BR 10$
4165
4166 016416 005237 005402 9$: INC TEMP3
4167 016422 023727 005402 000001 CMP TEMP3,#1
4168 016430 001020 BNE 10$
4169 016432 005037 005400 CLR TEMP2
4170 016436 012737 003322 005404 MOV #BSE22S,TEMP4 ;STORE 22 SECTOR SOFTWARE BSE ADDR
4171 016444 013765 005404 000004 MOV TEMP4,RKBA(R5)
4172 016452 012737 001012 005406 MOV #1012,TEMP5 ;TRACK 2, SECTOR 12
4173 016460 013765 005406 000006 MOV TEMP5,RKDA(R5)
4174 016466 000137 016152 JMP 1$ ;REPEAT
4175
4176 016472 005737 001216 10$: TST $PASS
4177
4178
4179 016476 001014 BNE 13$ ;TYPE CART # ONLY ON 1'ST PASS
4180 016500 104401 037450 TYPE ,MSG17 ;CART SERIAL #
4181 016504 012746 002322 MOV #BSE22H,-(SP)
4182 016510 004737 035030 JSR PC,$DB20 ;CONVERT DBL BINARY WORD TO OCTAL
4183 016514 004737 035400 JSR PC,$SUPRS ;TYPE SERIAL #
4184 016520 104401 001205 TYPE ,SCLRF
4185 016524 104401 001205 TYPE ,SCLRF
4186
4187 016530 004737 026436 13$: JSR PC,SUBCLR
4188 016534 104024 ERROR 24 ;CERR AFTER SCLR
4189 ;RETURN TO CYL 0
4190
4191 016536 012737 000017 005340 MOV #SEEK,HCS1
4192 016544 004737 024446 JSR PC,DOCMD ;DO SEEK CMD & GET CONTR READY
4193 016550 104131 ERROR 131 ;NO RDY AFTER SEEK CMD
4194
4195 016552 013737 001432 005376 MOV T50000,TEMP1 ;SETUP TIMEOUT
4196 016560 004737 025152 JSR PC,FATT2 ;FIND ATTN
4197 016564 104132 ERROR 132 ;NO ATTN AFTER SEEK CMD
4198
4199 016566 032737 100000 005340 BIT #CERR,HCS1
4200 016574 001401 BEQ 64$
4201 016576 104210 ERROR 210 ;CERR AFTER SEEK CMD
4202
4203 016600 64$:
4204
4205
4206 ;*****
4207 ;*TEST 16 WRITE LOCK TEST
4208 ;*

```



```

4209      : *      THIS TEST VERIFIES THAT DATA WRITTEN ON A SECTOR CANNOT BE
4210      : *      ALTERED ONCE THE WRITE LOCK SWITCH HAS BEEN ENABLED.
4211      : *      IT ALSO CHECKS THAT WRITE PROTECT TAKES EFFECT ONLY AT
4212      : *      SECTOR BOUNDRIES WHEN DOING CONTINUOUS WRITING ON CYL 0, HEAD 0
4213      : *
4214      : *****
4215 016600 000004      TST16: SCOPE
4216 016602 012737 000001 001174  MOV      #1,$TIMES      ;;DO 1 ITERATION
4217 016610 012706 001100      MOV      #STACK,SP      ;RESTORE STACK PTR
4218 016614 005737 001474      TST      BSERR          ;SEE IF ALIGN CART
4219 016620 001402      BEQ      15$            ;BR IF NO
4220 016622 000137 021450      JMP      12$            ;ELSE EXIT TEST
4221
4222 016626 004737 026436      15$:   JSR      PC,SUBCLR      ;CERR AFTER SCLR
4223 016632 104024
4224
4225 016634 104401 037705      TYPE     ,MSG24         ;WRITE LOCK TEST
4226 016640 104401 042017      TYPE     ,MSG52         ;PRESS CONT-E TO EXIT OR SPACE TO CONTINUE
4227 016644 004737 030412      JSR      PC,CCSP        ;INPUT CONT-E OR SPACE
4228 016650 000137 021450      JMP      12$            ;RETURN HERE IF CONT-E
4229
4230 016654 004737 026106      JSR      PC,GSTAT
4231 016660 032737 004000 005366  BIT      #D.WRL,HMR2    ;SEE IF WRITE LOCK IS ON
4232 016666 001416      BEQ      2$            ;BR IF NO
4233 016670 104401 042120      1$:   TYPE     ,MSG53         ;DISABLE WRITE LOCK
4234 016674 104401 040625      TYPE     ,MSG37         ;TYPE SPACE WHEN DONE
4235 016700 004737 030452      JSR      PC,GETSP       ;GET SPACE
4236
4237 016704 004737 026106      JSR      PC,GSTAT
4238 016710 032737 004000 005366  BIT      #D.WRL,HMR2    ;SEE IF WRITE LOCK IS OFF
4239 016716 001402      BEQ      2$            ;WRITE LOCK NOT DISABLED
4240 016720 104110      ERROR   110
4241 016722 000762      BR       1$
4242
4243 016724 005037 001366      2$:   CLR      TOCYL        ;SETUP
4244 016730 005037 001402      CLR      CALADD        ;FOR
4245 016734 005037 001442      CLR      HEAD          ;FILL HEADER TABLE
4246 016740 005037 001450      CLR      FORMAT        ;ROUTINE
4247
4248 016744 004737 027420      16$:  JSR      PC,FHDTAB      ;BUILD STD 22 SECTOR HEADER TABLE
4249
4250 016750 012765 001506 000004  MOV      #HDTAB,RKBA(R5)
4251 016756 012765 177676 000002  MOV      #-66.,RKWC(R5)
4252 016764 000337 001442      SWAB     HEAD
4253 016770 013765 001442 000006  MOV      HEAD,RKDA(R5) ;HEAD ADDR
4254 016776 000337 001442      SWAB     HEAD
4255
4256
4257 017002 012737 000027 005340  MOV      #<WRHEAD>,HCS1
4258 017010 004737 024504      JSR      PC,DATCMD      ;DO DATA X FOR CMD & GET CONTR RDY
4259 017014 104200      ERROR   200            ;NO RDY AFTER WRITE HEADER CMD
4260 017016 004737 026106      JSR      PC,GSTAT      ;GET FRESH STATUS
4261 017022 032737 100000 005340  BIT      #CERR,HCS1
4262 017030 001401      BEQ      64$
4263 017032 104201      ERROR   201            ;CERR AFTER WRITE HEADER CMD
4264 017034
    
```

```

4265
4266
4267 017034 005237 001442          INC    HEAD
4268 017040 023727 001442 000003  CMP    HEAD,#3          ;SEE IF ALL HEADS DONE
4269 017046 001336          BNE    16$              ;BR IF NO
4270
4271 017050 004737 026436          JSR    PC,SUBCLR
4272 017054 104024          ERROR  24              ;CERR AFTER SCLR
4273
4274 017056 005037 001422          CLR    SECTOR
4275 017062 013765 001422 000006 14$:  MOV    SECTOR,RKDA(R5)
4276
4277 017070 012765 001456 000004  MOV    #DATA0,RKBA(R5) ;WRITE ALL 0'S
4278 017076 052765 000020 000010  BIS    #BAI,RKCS2(R5)
4279 017104 012765 177400 000002  MOV    #-256.,RKWC(R5) ;CYL 0, TRK 0, SECTOR 0
4280
4281 017112 012737 000023 005340  MOV    #<WRDATA>,HCS1
4282 017120 004737 024504          JSR    PC,DATCMD        ;DO DATA X FOR CMD & GET CONTR RDY
4283 017124 104011          ERROR  11              ;NO RDY AFTER WRITE DATA CMD
4284 017126 004737 026106          JSR    PC,GSTAT        ;GET FRESH STATUS
4285 017132 032737 100000 005340  BIT    #CERR,HCS1
4286 017140 001465          BEQ    68$              ;BR IF NO ERRORS
4287
4288 017142 032737 000200 005354  BIT    #BSE,HER        ;SEE IF BAD SECTOR FLAG
4289 017150 001421          BEQ    66$              ;BR IF NO
4290 017152 004737 030056          JSR    PC,TRUERR       ;ELSE SEE IF SECTOR LISTED IN BSE TABLE
4291 017156 000455          BR     67$              ;RETURN HERE IF NO
4292
4293 017160 005237 001422          INC    SECTOR          ;RETURN HERE IF YES
4294 017164 023727 001422 000012  CMP    SECTOR,#10.     ;ARE 10 CONSEC. SECTORS BAD
4295 017172 001003          BNE    65$              ;BR IF NO
4296 017174 104040          ERROR  40              ;ABORTING TEST DETECTED 10 BAD SECTORS
4297 017176 000137 021450          JMP    12$              ;BYPASS TEST
4298
4299 017202 012765 100000 000000 65$:  MOV    #CCLR,RKCS1(R5) ;TRY ANOTHER SECTOR
4300 017210 000137 017062          JMP    14$
4301
4302 017214 104012          66$:  ERROR  12              ;CERR WITH WRITE DATA CMD
4303
4304 017216 012737 010340 005430  MOV    #<0!D.SPIN!D.DRDY!D.VV!D.DRA>,E.A0 ;EXPECTED MSG A0
4305 017224 005037 005432          CLR    E.B0            ;EXPECTED MSG B0
4306 017230 012737 001720 005434  MOV    #<D.SPOK!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1 ;EXPECTED A1
4307 017236 012737 000001 005436  MOV    #1,E.B1         ;MSG ID FOR EXPECTED MSG B1
4308 017244 005037 005440          CLR    E.A2            ;EXPECTED MSG A2
4309 017250 012737 000002 005442  MOV    #2,E.B2         ;MSG ID FOR EXPECTED MSG B2
4310 017256 012737 000003 005446  MOV    #3,E.B3         ;MSG ID FOR EXPECTED MSG B3
4311
4312 017264 004737 025264          JSR    PC,CHKMSG       ;CHECK MSGS A0, B0, A1, B1
4313 017270 000003          .WORD T.A2!T.B2!0     ;& MSGS SPECIFIED HERE
4314 017272 104052          ERROR  52              ;MSG A0 ERROR AFTER WRITE DATA CMD
4315 017274 104023          ERROR  23              ;MSG B0 ERROR
4316 017276 104053          ERROR  53              ;MSG A1 ERROR
4317 017300 104025          ERROR  25              ;MSG B1 ERROR
4318 017302 104401 044035          TYPE  #MSG72
4319 017306 000137 023734          JMP    $EOP
4320 017312 104047          67$:  ERROR  47              ;BAD SECTOR NOT LISTED IN TABLE
    
```



```

4321 017314      68$:
4322
4323 017314 004737 026436      JSR    PC,SUBCLR
4324 017320 104024      ERROR  24      ;CERR AFTER SCLR
4325
4326 017322 012765 001456 000004      MOV    #DATA0,RKBA(R5)
4327 017330 052765 000020 000010      BIS    #BA1,RKCS2(R5)
4328 017336 012765 177400 000002      MOV    #-256.,RKWC(R5)
4329 017344 013737 001456 001436      MOV    DATA0,WD2      ;EXPECTED WORD FOR TRUERR TYPEOUT
4330 017352 013765 001422 000006      MOV    SECTOR,RKDA(R5)
4331
4332 017360 012737 000031 005340      MOV    #<WRTCHK>,HCS1
4333 017366 004737 024504      JSR    PC,DATCMD      ;DO DATA X FOR CMD & GET CONTR RDY
4334 017372 104015      ERROR  15      ;NO RDY AFTER WRITE CHECK CMD
4335 017374 004737 026106      JSR    PC,GSTAT      ;GET FRESH STATUS
4336 017400 032737 100000 005340      BIT    #CERR,HCS1
4337 017406 001450      BEQ    70$
4338 017410 032737 040000 005342      BIT    #WCE,HCS2      ;SEE IF WRITE CHECK ERROR
4339 017416 001405      BEQ    69$
4340 017420 016537 000024 001434      MOV    RKDB(R5),WD1   ;ACTUAL WORD FOR PRINTOUT
4341 017426 104016      ERROR  16      ;WCE AFTER WRITE CMD
4342 017430 000437      BR     70$
4343
4344 017432 104022      69$:  ERROR  22      ;CERR AFTER WRITE CHECK CMD
4345
4346 017434 012737 010340 005430      MOV    #<O!D.SPIN!D.DRDY!D.VV!D.DRA>,E.A0 ;EXPECTED MSG A0
4347 017442 005037 005432      CLR    E.B0          ;EXPECTED MSG B0
4348 017446 012737 001720 005434      MOV    #<D.SPOK!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1 ;EXPECTED A1
4349 017454 012737 000001 005436      MOV    #1,E.B1       ;MSG ID FOR EXPECTED MSG B1
4350 017462 005037 005440      CLR    E.A2          ;EXPECTED MSG A2
4351 017466 012737 000002 005442      MOV    #2,E.B2       ;MSG ID FOR EXPECTED MSG B2
4352 017474 012737 000003 005446      MOV    #3,E.B3       ;MSG ID FOR EXPECTED MSG B3
4353
4354 017502 004737 025264      JSR    PC,CHKMSG     ;CHECK MSGS A0, B0, A1, B1
4355 017506 000003      .WORD  T.A2!T.B2!0   ;& MSGS SPECIFIED HERE
4356 017510 104057      ERROR  57      ;MSG A0 ERROR AFTER WRITE CHECK CMD
4357 017512 104031      ERROR  31      ;MSG B0 ERROR
4358 017514 104060      ERROR  60      ;MSG A1 ERROR
4359 017516 104032      ERROR  32      ;MSG B1 ERROR
4360 017520 104401 044035      TYPE   ,MSG72       ;ABORTING BALANCE OF TESTS
4361 017524 000137 023374      JMP    ENDRV
4362
4363 017530      70$:
4364
4365 017530 004737 026436      3$:  JSR    PC,SUBCLR
4366 017534 104024      ERROR  24      ;CERR AFTER SCLR
4367
4368 017536 104401 042211      TYPE   ,MSG54       ;ENABLE WRITE LOCK
4369 017542 104401 040625      TYPE   ,MSG37       ;PRESS SPACE WHEN DONE
4370 017546 004737 030452      JSR    PC,GETSP      ;GET SPACE
4371
4372 017552 012765 100000 000000      MOV    #CLR,RKCS1(R5)
4373 017560 004737 026106      JSR    PC,GSTAT
4374 017564 032737 004000 005366      BIT    #D.WRL,HMR2   ;SEE IF WRITE LOCK IS ON
4375 017572 001002      BNE    4$
4376 017574 104115      ERROR  115      ;WRITE LOCK NOT ENABLED
  
```

CZ
CZ

```

4377 017576 000754 BR 3$
4378
4379 017600 012765 001462 000004 4$: MOV #DATA1,RKBA(R5) ;ATTEMPT TO WRITE ALL 1'S WITH WRITE LOCK SET
4380 017606 052765 000020 000010 BIS #BAI,RKCS2(R5)
4381 017614 012765 177400 000002 MOV #-256.,RKWC(R5) ; CYLINDER 0, HEAD 0
4382 017622 013765 001422 000006 MOV SECTOR,RKDA(R5)
4383 017630 012737 000023 005340 MOV #WRDATA,HCS1
4384 017636 004737 024504 JSR PC,DATCMD ;DO WRITE DATA CMD & GET CONTR RDY
4385 017642 104116 ERROR 116 ;CONTR NOT RDY
4386
4387 017644 004737 026106 JSR PC,GSTAT ;GET FRESH STATUS
4388 017650 032737 100000 005340 BIT #CERR,HCS1
4389 017656 001001 BNE 17$
4390 017660 104207 ERROR 207 ;CERR NOT SET AFTER WRITE WITH WRL SET
4391 017662 032737 004000 005370 17$: BIT #D.WLE,HMR3 ;CHECK WRITE LOCK ERROR SET
4392 017670 001001 BNE 5$ ;BR IF SET
4393 017672 104121 ERROR 121 ;WRITE LOCK ERROR NOT SET
4394 ;AFTER WRITE DATA WITH WRITE LOCK SET
4395 017674 012737 054340 005430 5$: MOV #<D.DSC!D.SPIN!D.WRL!D.DRDY!D.VV!D.DRA>,E.A0 ;EXP A0
4396 017702 012737 004200 005432 MOV #<D.WLE!D.FLT>,E.B0
4397 017710 012737 001720 005434 MOV #<D.SPOK!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1
4398 017716 012737 000001 005436 MOV #1,E.B1
4399
4400 017724 004737 025264 JSR PC,CHKMSG ;CHECK MSGS A0, B0, A1, B1
4401 017730 000000 .WORD 0!0!0 ;& MSGS SPECIFIED HERE
4402 017732 104123 ERROR 123 ;MSG A0 ERROR AFTER WRITE WITH WRITE LOCK SET
4403 017734 104125 ERROR 125 ;MSH B0 ERROR
4404 017736 104126 ERROR 126 ;MSG A1 ERROR
4405 017740 104127 ERROR 127 ;MSG B1 ERROR
4406
4407 017742 004737 026436 JSR PC,SUBCLR
4408 017746 104024 ERROR 24 ;CERR AFTER SCLR
4409
4410 017750 012765 001456 000004 MOV #DATA0,RKBA(R5) ;CHECK THAT NONE OF ORIG DATA
4411 017756 052765 000020 000010 BIS #BAI,RKCS2(R5) ;HAS CHANGED
4412 017764 012765 177400 000002 MOV #-256.,RKWC(R5) ;AS RESULT OF WRITE WITH WRITE LOCK SET
4413 017772 013737 001456 001436 MOV DATA0,WD2 ;EXPECTED WORD FOR TRUERR TYPEOUT
4414 020000 013765 001422 000006 MOV SECTOR,RKDA(R5)
4415
4416 020006 012737 000031 005340 MOV #<WRTCHK>,HCS1
4417 020014 004737 024504 JSR PC,DATCMD ;DO DATA X FOR CMD & GET CONTR RDY
4418 020020 104015 ERROR 15 ;NO RDY AFTER WRITE CHECK CMD
4419 020022 004737 026106 JSR PC,GSTAT ;GET FRESH STATUS
4420 020026 032737 100000 005340 BIT #CERR,HCS1
4421 020034 001450 BEQ 72$
4422 020036 032737 040000 005342 BIT #WCE,HCS2 ;SEE IF WRITE CHECK ERROR
4423 020044 001405 BEQ 71$
4424 020046 016537 000024 001434 MOV RKDB(R5),WD1 ;ACTUAL WORD FOR PRINTOUT
4425 020054 104016 ERROR 16 ;WCE AFTER WRITE CMD
4426 020056 000437 BR 72$
4427
4428 020060 104022 71$: ERROR 22 ;CERR AFTER WRITE CHECK CMD
4429
4430 020062 012737 010340 005430 MOV #<0!D.SPIN!D.DRDY!D.VV!D.DRA>,E.A0 ;EXPECTED MSG A0
4431 020070 005037 005432 CLR E.B0 ;EXPECTED MSG B0
4432 020074 012737 001720 005434 MOV #<D.SPOK!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1 ;EXPECTED A1
    
```



```

4433 020102 012737 000001 005436      MOV      #1,E.B1      :MSG ID FOR EXPECTED MSG B1
4434 020110 005037 005440              CLR      E.A2        :EXPECTED MSG A2
4435 020114 012737 000002 005442      MOV      #2,E.B2      :MSG ID FOR EXPECTED MSG B2
4436 020122 012737 000003 005446      MOV      #3,E.B3      :MSG ID FOR EXPECTED MSG B3
4437
4438 020130 004737 025264              JSR      PC,CHKMSG    :CHECK MSGS A0, B0, A1, B1
4439 020134 000003              .WORD    T.A2!T.B2!0  :& MSGS SPECIFIED HERE
4440 020136 104057              ERROR    57          :MSG A0 ERROR AFTER WRITE CHECK CMD
4441 020140 104031              ERROR    31          :MSG B0 ERROR
4442 020142 104060              ERROR    60          :MSG A1 ERROR
4443 020144 104032              ERROR    32          :MSG B1 ERROR
4444 020146 104401 044035              TYPE     ,MSG72      :ABORTING BALANCE OF TESTS
4445 020152 000137 023374              JMP      ENDRV
4446
4447 020156              72$:
4448
4449 020156 004737 026436              6$: JSR      PC,SUBCLR
4450 020162 104024              ERROR    24          :CERR AFTER SCLR
4451
4452 020164 104401 042120              TYPE     ,MSG53      :DISABLE WRITE LOCK
4453 020170 104401 040625              TYPE     ,MSG37      :SPACE BAR WHEN DONE
4454 020174 004737 030452              JSR      PC,GETSP     :GET SPACE
4455 020200 004737 026106              JSR      PC,GSTAT
4456 020204 032737 004000 005366      BIT      #D.WRL,HMR2 :SEE IF WRITE LOCK OFF
4457 020212 001361              BNE     6$
4458
4459
4460 020214 104401 042211              TYPE     ,MSG54      :TEST FOR WRITE LOCK AT SECTOR BOUNDRIES
4461 020220 013737 001430 001160      MOV      T5000,$TMP0 :FOR CONTINUOUS WRITING ON CYL 0, TRACK 0,1,2
4462 020226 005037 001162              CLR      $TMP1       :SET WRITE LOCK
4463 020232 005037 001366              CLR      TOCYL
4464
4465 020236 004737 026436              7$: JSR      PC,SUBCLR
4466 020242 104024              ERROR    24          :CERR AFTER SCLR
4467
4468 020244 032737 000001 001162      BIT      #BIT0,$TMP1
4469 020252 001004              BNE     8$          :BR IF WRITING 1'S
4470 020254 012765 001456 000004      MOV      #DATA0,RKBA(R5) :SETUP ALL 0'S
4471 020262 000403              BR      9$
4472
4473 020264 012765 001462 000004 8$: MOV      #DATA1,RKBA(R5) :SETUP ALL 1'S
4474 020272 052765 000020 000010 9$: BIS      #BAI,RKCS2(R5)
4475 020300 012765 140400 000002      MOV      #-63.*256.,RKWC(R5) :WRITE TRACK 0,1,2 63 SECTORS
4476 020306 005065 000006              CLR      RKDA(R5)    :BEGIN AT TRACK AND SEC 0
4477 020312 013765 001366 000020      MOV      TOCYL,RKDC(R5)
4478 020320 012737 000023 005340      MOV      #WRDATA,HCS1
4479 020326 004737 024504              JSR      PC,DATCMD   :DO WRITE DATA CMD & GET CONTR RDY
4480 020332 104011              ERROR    11          :CONTR NOT RDY
4481
4482 020334 032737 100000 005340      BIT      #CERR,HCS1
4483 020342 001017              BNE     13$
4484 020344 005337 001160              DEC      $TMP0
4485 020350 001011              BNE     10$
4486 020352 104204              ERROR    204        :CERR NOT SET BY TIMEOUT
4487 020354 104401 042120              TYPE     ,MSG53      :DISABLE WRITE LOCK
4488 020360 104401 040625              TYPE     ,MSG37      :PRESS SPACE WHEN DONE
    
```

4489	020364	004737	030452			JSR	PC,GETSP	:INPUT SPACE
4490	020370	000137	021450			JMP	12\$:EXIT TEST
4491								
4492	020374	005237	001162		10\$:	INC	\$TMP1	
4493	020400	000716				BR	7\$:GO WRITE OPPOSITE DATA
4494	020402	032737	000200	005354	13\$:	BIT	#BSE,HER	:SEE IF BAD SECTOR
4495	020410	001411				BEQ	21\$:BR IF NO
4496	020412	005237	001366			INC	TOCYL	:ELSE TRY ANOTHER CYL
4497	020416	023727	001366	000012		CMP	TOCYL,#10.	:SEE IF 10 CONSEC CYL BAD
4498	020424	001304				BNE	7\$:BR IF NO & DO AGAIN
4499	020426	104062				ERROR	62	:10 BAD CONSEC CYLINDERS
4500	020430	000137	021450			JMP	12\$:EXIT TEST
4501								
4502	020434	032737	004000	005370	21\$:	BIT	#D.WLE,HMR3	
4503	020442	001001				BNE	11\$	
4504	020444	104205				ERROR	205	:NO WRL BY TIMEOUT
4505								
4506	020446	104401	042120		11\$:	TYPE	,MSG53	:DISABLE WRITE LOCK
4507	020452	104401	040625			TYPE	,MSG37	:TYPE SPACE WHEN DONE
4508	020456	004737	030452			JSR	PC,GETSP	
4509								
4510	020462	013737	005350	001164		MOV	HDA,\$TMP2	:STORE RKDA OF ERROR
4511	020470	013737	005350	001166		MOV	HDA,\$TMP3	:STORE FOR ERROR TYPEOUT
4512								
4513	020476	023727	001164	000001		CMP	\$TMP2,#1	:SEE IF WRL ON TRK 0, SEC 1
4514	020504	001003				BNE	22\$:BR IF NO
4515	020506	104401	044233			TYPE	,MSG100	:ELSE WRL OCCURRED ON TRK 2, SEC 21
4516	020512	000621				BR	6\$:& NO NEW DATA XFER TOOK PLACE
4517								
4518	020514	005737	001164		22\$:	TST	\$TMP2	:SEE IF WRL ON TRK 0, SEC 0
4519	020520	001004				BNE	23\$:BR IN NO
4520	020522	104401	044233			TYPE	,MSG100	:ELSE WRL ON TRK 2, SEC 20
4521	020526	000137	020156			JMP	6\$:& NO NEW DATA XFER TOOK PLACE
4522								
4523	020532	023727	001164	001025	23\$:	CMP	\$TMP2,#1025	:SEE IF WRL ON TRK 2, SEC 21
4524	020540	001004				BNE	24\$:BE IF NO
4525	020542	104401	044233			TYPE	,MSG100	:ELSE WRL ON TRK 2, SEC 19
4526	020546	000137	020156			JMP	6\$:& NO NEW DATA XFER TOOK PLACE
4527								
4528	020552	023727	001164	001024	24\$:	CMP	\$TMP2,#1024	:SEE IF WRL ON TRK 2, SEC 20
4529	020560	001004				BNE	25\$:BR IF NO
4530	020562	104401	044233			TYPE	,MSG100	:ELSE WRL ON TRK 2, SEC 18
4531	020566	000137	020156			JMP	6\$:& NO OLD DATA TO CHECK AGAINST
4532								
4533	020572	023727	001164	000400	25\$:	CMP	\$TMP2,#400	:SEE IF WRL AT TRK 1, SEC 0
4534	020600	001004				BNE	18\$:BR IF NO
4535	020602	012765	000025	000006		MOV	#21.,RKDA(R5)	:ELSE SECTOR AT WRL IS TRK 0, SEC 21
4536	020610	000415				BR	20\$	
4537								
4538	020612	023727	001164	001000	18\$:	CMP	\$TMP2,#1000	:SEE IF WRL AT TRK 2, SEC 0
4539	020620	001004				BNE	19\$:BR IF NO
4540	020622	012765	000425	000006		MOV	#425,RKDA(R5)	:ELSE SECTOR AT WRL IS TRK 1, SEC 21
4541	020630	000405				BR	20\$	
4542								
4543	020632	005337	001164		19\$:	DEC	\$TMP2	:GET SECTOR AT WRL
4544	020636	013765	001164	000006		MOV	\$TMP2,RKDA(R5)	


```

4545
4546 020644 016537 000006 001166 20$: MOV RKDA(R5),STMP3 ;FOR ERROR PRINTOUT
4547
4548
4549
4550 020652 004737 026436 JSR PC,SUBCLR
4551 020656 104024 ERROR 24 ;CERR AFTER SCLR
4552
4553 020660 005737 001164 TST STMP2 ;SEE IF TRK/SECTOR 0
4554 020664 001414 BEQ 80$ ;REPEAT,NO NEW DATA XFER TOOK PLACE
4555 020666 023727 001164 001023 CMP STMP2,#1023 ;SEE IF TRK 2,SECTOR 19
4556 020674 001410 BEQ 80$ ;REPEAT,NO OLD DATA TO CHECK AGAINST
4557 020676 032737 000001 001162 BIT #BIT0,STMP1
4558 020704 001006 BNE 73$ ;BR IF WRITING 1'S WHEN WLE OCCURRED
4559 020706 012765 001462 000004 MOV #DATA1,RKBA(R5) ;WRITING 0'S:WLE SECTOR SHOULD HAVE ALL 1'S
4560 020714 000405 BR 74$
4561
4562 020716 000137 020156 80$: JMP 6$
4563
4564 020722 012765 001456 000004 73$: MOV #DATA0,RKBA(R5) ;WRITING 1'S:WLE SECTOR SHOULD HAVE ALL 0'S
4565 020730 052765 000020 000010 74$: BIS #BAI,RKCS2(R5)
4566 020736 012765 177400 000002 MOV #-256.,RKWC(R5)
4567 020744 013765 001166 000006 MOV STMP3,RKDA(R5) ;REFRESH RKDA
4568 020752 017537 000004 001436 MOV @RKBA(R5),WD2 ;EXPECTED WORD FOR TRUERR TYPEOUT
4569 020760 013765 001366 000020 MOV TOCYL,RKDC(R5)
4570
4571 020766 012737 000031 005340 MOV #<WRTCHK>,HCS1
4572 020774 004737 024504 JSR PC,DATCMD ;DO DATA X FOR CMD & GET CONTR RDY
4573 021000 104015 ERROR 15 ;NO RDY AFTER WRITE CHECK CMD
4574 021002 004737 026106 JSR PC,GSTAT ;GET FRESH STATUS
4575 021006 032737 100000 005340 BIT #CERR,HCS1
4576 021014 001450 BEQ 82$
4577 021016 032737 040000 005342 BIT #WCE,HCS2 ;SEE IF WRITE CHECK ERROR
4578 021024 001405 BEQ 81$
4579 021026 016537 000024 001434 MOV RKDB(R5),WD1 ;ACTUAL WORD FOR PRINTOUT
4580 021034 104134 ERROR 134 ;WCE AFTER WRITE CMD
4581 021036 000437 BR 82$
4582
4583 021040 104022 81$: ERROR 22 ;CERR AFTER WRITE CHECK CMD
4584
4585 021042 012737 010340 005430 MOV #<0!D.SPIN!D.DRDY!D.VV!D.DRA>,E.A0 ;EXPECTED MSG A0
4586 021050 005037 005432 CLR E.B0 ;EXPECTED MSG B0
4587 021054 012737 001720 005434 MOV #<D.SPOK!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1 ;EXPECTED A1
4588 021062 012737 000001 005436 MOV #1,E.B1 ;MSG ID FOR EXPECTED MSG B1
4589 021070 005037 005440 CLR E.A2 ;EXPECTED MSG A2
4590 021074 012737 000002 005442 MOV #2,E.B2 ;MSG ID FOR EXPECTED MSG B2
4591 021102 012737 000003 005446 MOV #3,E.B3 ;MSG ID FOR EXPECTED MSG B3
4592
4593 021110 004737 025264 JSR PC,CHKMSG ;CHECK MSGS A0, B0, A1, B1
4594 021114 000003 .WORD T.A2!T.B2!0 ;& MSGS SPECIFIED HERE
4595 021116 104057 ERROR 57 ;MSG A0 ERROR AFTER WRITE CHECK CMD
4596 021120 104031 ERROR 31 ;MSG B0 ERROR
4597 021122 104060 ERROR 60 ;MSG A1 ERROR
4598 021124 104032 ERROR 32 ;MSG B1 ERROR
4599 021126 104401 044035 TYPE ,MSG72 ;ABORTING BALANCE OF TESTS
4600 021132 000137 023374 JMP ENDRV
    
```

```

4601
4602 021136      82$:
4603 021136 000240      NOP
4604 021140 000240      NOP
4605
4606 021142 023727 001164 000400      CMP      $TMP2,#400      ;SEE IF WRL AT TRK 1, SECTOR 0
4607 021150 001004      BNE      75$            ;BR IF NO
4608 021152 012765 000025 000006      MOV      #21.,RKDA(R5) ;ELSE SECTOR BEFORE WRL IS TRK 0, SEC 21
4609 021160 000415      BR
4610 021162 023727 001164 001000 75$:      CMP      $TMP2,#1000   ;SEE IF WRL AT TRK 2,SECTOR 0
4611 021170 001004      BNE      76$            ;BR IF NO
4612 021172 012765 000425 000006      MOV      #425,RKDA(R5) ;ELSE SECTOR BEFORE WRL IS TRK 1, SEC 21
4613 021200 000405      BR
4614
4615 021202 005337 001164      76$:      DEC      $TMP2          ;GET SECTOR BEFORE WRL
4616 021206 013765 001164 000006      MOV      $TMP2,RKDA(R5)
4617 021214 016537 000006 001166 77$:      MOV      RKDA(R5),$TMP3 ;FOR ERROR PRINTOUT
4618 021222 032737 000001 001162      BIT      #BIT0,$TMP1
4619 021230 001004      BNF
4620 021232 012765 001456 000004      MOV      #DATA0,RKBA(R5) ;BR IF WRITING 1'S WHEN WLE OCCURRED
4621 021240 000403      BR
4622
4623 021242 012765 001462 000004 78$:      MOV      #DATA1,RKBA(R5) ;WRITING 1'S:WLE SECTOR -1 SHOULD HAVE ALL 1'S
4624 021250 052765 000020 000010 79$:      BIS      #BAI,RKCS2(R5)
4625 021256 012765 177400 000002      MOV      #-256.,RKWC(R5)
4626 021264 017537 000004 001436      MOV      @RKBA(R5),WD2 ;EXPECTED WORD FOR TRUERR TYPEOUT
4627 021272 013765 001366 000020      MOV      TOCYL,RKDC(R5)
4628
4629 021300 012737 000031 005340      MOV      #<WRTCHK>,HCS1
4630 021306 004737 024504      JSR      PC,DATCMD      ;DO DATA X FOR CMD & GET CONTR RDY
4631 021312 104015      ERROR   15            ;NO RDY AFTER WRITE CHECK CMD
4632 021314 004737 026106      JSR      PC,GSTAT      ;GET FRESH STATUS
4633 021320 032737 100000 005340      BIT      #CERR,HCS1
4634 021326 001450      BEQ      84$
4635 021330 032737 040000 005342      BIT      #WCE,HCS2      ;SEE IF WRITE CHECK ERROR
4636 021336 001405      BEQ      83$
4637 021340 016537 000024 001434      MOV      RKDB(R5),WD1 ;ACTUAL WORD FOR PRINTOUT
4638 021346 104135      ERROR   135          ;WCE AFTER WRITE CMD
4639 021350 000437      BR
4640
4641 021352 104022      83$:      ERROR   22            ;CERR AFTER WRITE CHECK CMD
4642
4643 021354 012737 010340 005430      MOV      #<0!D.SPIN!D.DRDY!D.VV!D.DRA>,E.A0 ;EXPECTED MSG A0
4644 021362 005037 005432      CLR      E.B0          ;EXPECTED MSG B0
4645 021366 012737 001720 005434      MOV      #<D.SPOK!D.CART!D.DOOR!D.BRM!D.SSP>,E.A1 ;EXPECTED A1
4646 021374 012737 000001 005436      MOV      #1,E.B1      ;MSG ID FOR EXPECTED MSG B1
4647 021402 005037 005440      CLR      E.A2          ;EXPECTED MSG A2
4648 021406 012737 000002 005442      MOV      #2,E.B2      ;MSG ID FOR EXPECTED MSG B2
4649 021414 012737 000003 005446      MOV      #3,E.B3      ;MSG ID FOR EXPECTED MSG B3
4650
4651 021422 004737 025264      JSR      PC,CHKMSG     ;CHECK MSGS A0, B0, A1, B1
4652 021426 000003      .WORD   T.A2!T.B2!0 ;& MSGS SPECIFIED HERE
4653 021430 104057      ERROR   57            ;MSG A0 ERROR AFTER WRITE CHECK CMD
4654 021432 104031      ERKOR   31            ;MSG B0 ERROR
4655 021434 104060      ERROR   60            ;MSG A1 ERROR
4656 021436 104032      ERROR   32            ;MSG B1 ERROR
    
```



```

4657 021440 104401 044035      TYPE      ,MSG72      ;ABORTING BALANCE OF TESTS
4658 021444 000137 023374      JMP        ENDRV
4659
4660 021450      84$:
4661
4662 021450      12$:
4663
4664      ::*****
4665      :*TEST 17      AC LOW DETECTION PART 2
4666      :*
4667      :*      THIS TEST VERIFIES THAT WHEN AC POWER IS LOST, THAT WRITING CEASES
4668      :*      AT SECTOR BOUNDRIES & THAT THE BATTERY RETRACT IS FUNCTIONAL.
4669      :*      THERE IS APPROX 4 MS BETWEEN AC LOW ASSERTING AND NED ASSERTING
4670      :*      WHEN THE INTERFACE SHUTS DOWN.
4671      :*
4672      ::*****
4673 021450 000004      TST17: SCOPE
4674 021452 012737 000001 001174      MOV      #1,$TIMES      ;;DO 1 ITERATION
4675 021460 012706 001100      MOV      #STACK,SP      ;RESTORE STK PTR
4676
4677 021464 004737 026436      JSR      PC,SUBCLR
4678 021470 104024      ERROR    24      ;CERR AFTER SCLR
4679
4680 021472 104401 037731      TYPE      ,MSG26      ;AC LOW-PART 2
4681 021476 104401 042017      TYPE      ,MSG52      ;CONT-E TO BYPASS TEST
4682      ;OR SPACE TO CONINUE
4683 021502 004737 030412      JSR      PC,CCSP
4684 021506 000137 023374      JMP      12$      ;INPUT CONT-E OR SPACE
4685      ;RETURN HERE FOR CONT-E
4686 021512 005737 001474      TST      BSERR
4687 021516 001402      BEQ      1$      ;RETURN HERE FOR SPACE
4688 021520 000137 022142      JMP      2$      ;TEST FOR ALIGN CARTRIDGE
4689      ;BR IF NOT ALIGN CART.
4690 021524 004737 026106      JSR      PC,GSTAT
4691 021530 032737 004000 005366      BIT      #D.WRL,HMR2
4692 021536 001417      BEQ      11$      ;SEE IF WRITE LOCK
4693      ;BR IF NO
4694 021540 104401 042120      TYPE      ,MSG53
4695 021544 104401 040625      TYPE      ,MSG37
4696 021550 004737 030452      JSR      PC,GETSP
4697      ;DISABLE WRITE LOCK
4698      ;PRESS SPACE WHEN DONE
4699      ;GET SPACE
4700 021560 032737 004000 005366      JSR      PC,GSTAT
4701 021566 001403      BIT      #D.WRL,HMR2
4702 021570 104110      BEQ      11$
4703 021572 000137 023374      ERROR    110
4704      ;SEE IF STILL WRITE LOCK
4705      ;BR IF NO
4706      ;WRITE LOCK NOT DISABLED
4707      ;EXIT TEST
4708      ;SETUP
4709      ;FOR
4710      ;FILL HEADER TABLE
4711      ;ROUTINE
4712 021622 012765 001506 000004      JSR      PC,FHDTAB      ;BUILD STD 22 SECTOR HEADER TABLE
4713 021630 012765 177676 000002      MOV      #HDTAB,RKBA(R5)
4714      MOV      #-66.,RKWC(R5)
    
```

CZ
CZ

4713	021636	000337	001442		SWAB	HEAD	
4714	021642	013765	001442	000006	MOV	HEAD,RKDA(R5)	:HEAD ADDR
4715	021650	000337	001442		SWAB	HEAD	
4716							
4717	021654	012737	000027	005340	MOV	#<WRHEAD>,HCS1	
4718	021662	004737	024504		JSR	PC,DATCMD	:DO DATA X FOR CMD & GET CONTR RDY
4719	021666	104200			ERROR	200	:NO RDY AFTER WRITE HEADER CMD
4720	021670	004737	026106		JSR	PC,GSTAT	:GET FRESH STATUS
4721	021674	032737	100000	005340	BIT	#CERR,HCS1	
4722	021702	001401			BEQ	64\$	
4723	021704	104201			ERROR	201	:CERR AFTER WRITE HEADER CMD
4724	021706						
4725							64\$:
4726	021706	005237	001442		INC	HEAD	
4727	021712	023727	001442	000003	CMP	HEAD,#3	:SEE IF ALL HEADS DONE
4728	021720	001336			BNE	13\$:BR IF NO
4729	021722	005037	001366		CLR	TOCYL	
4730							
4731	021726	004737	026436		JSR	PC,SUBCLR	
4732	021732	104024			ERROR	24	:CERR AFTER SCLR
4733							
4734	021734	012765	001462	000004	MOV	#DATA1,RKBA(R5)	:RETURN HERE FOR SPACE
4735	021742	052765	000020	000010	BIS	#BAI,RKCS2(R5)	:WRITE INITIAL BACKGROUND OF 1'S
4736	021750	012765	137000	000002	MOV	#-66.*256.,RKWC(R5)	:TRACK 0,1,2 ALL SECTORS
4737	021756	013765	001366	000020	MOV	TOCYL,RKDC(R5)	
4738	021764	012737	000023	005340	MOV	#WRDATA,HCS1	
4739	021772	004737	024504		JSR	PC,DATCMD	:DO WRITE DATA CMD & GET CONTR RDY
4740	021776	104011			ERROR	11	:NO RDY AFTER WRITE DATA CMD
4741	022000	004737	026106		JSR	PC,GSTAT	:GET FRESH STATUS
4742	022004	032737	100000	005340	BIT	#CERR,HCS1	
4743	022012	001453			BEQ	2\$	
4744	022014	032737	000200	005354	BIT	#BSE,HER	:SEE IF BAD SECTOR
4745	022022	001034			BNE	17\$	
4746							
4747	022024	012737	010340	005430	MOV	#<0!D.SPIN!D.DRDY!D.VV!D.DRA>,E.A0	:EXPECTED MSG A0
4748	022032	005037	005432		CLR	E.B0	:EXPECTED MSG B0
4749	022036	012737	001720	005434	MOV	#<D.SPOK!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1	:EXPECTED A1
4750	022044	012737	000001	005436	MOV	#1,E.B1	:MSG ID FOR EXPECTED MSG B1
4751	022052	005037	005440		CLR	E.A2	:EXPECTED MSG A2
4752	022056	012737	000002	005442	MOV	#2,E.B2	:MSG ID FOR EXPECTED MSG B2
4753	022064	012737	000003	005446	MOV	#3,E.B3	:MSG ID FOR EXPECTED MSG B3
4754							
4755	022072	004737	025264		JSR	PC,CHKMSG	:CHECK MSGS A0, B0, A1, B1
4756	022076	000003			.WORD	T.A2!T.B2!0	:& MSGS SPECIFIED HERE
4757	022100	104052			ERROR	52	:MSG A0 ERROR AFTER WRITE DATA CMD
4758	022102	104023			ERROR	23	:MSH B0 ERROR
4759	022104	104053			ERROR	53	:MSG A1 ERROR
4760	022106	104025			ERROR	25	:MSG B1 ERROR
4761	022110	000137	023374		JMP	12\$	
4762							
4763	022114	005237	001366		INC	TOCYL	
4764	022120	023727	001366	000012	CMP	TOCYL,#10.	:TRIED 10 CYLINDERS?
4765	022126	001003			BNE	18\$:BR IF NO
4766	022130	104062			ERROR	62	:CANNOT WRITE ON 10 CONSEC CYL
4767	022132	000137	023374		JMP	12\$	
4768							


```

4769 022136 000137 021726      18$:  JMP      16$
4770
4771 022142 004737 026436      2$:  JSR      PC,SUBCLR
4772 022146 104024                ERROR    24      ;CERR AFTER SCLR
4773
4774 022150 104401 041553                TYPE    ,MSG49      ;TURN OFF AC
4775 022154 104401 042564                TYPE    ,MSG57      ;VERIFY BATTERY RETRACT FUNCTIONAL
4776
4777 022160 005737 001474                TST     BSERR      ;SEE IF ALIGN CART USED
4778 022164 001405                BEQ     15$        ;BR IF NO
4779 022166 104401 040625                TYPE    ,MSG37      ;PRESS SPACE WHEN DONE
4780 022172 004737 030452                JSR     PC,GETSP    ;GET SPACE
4781 022176 000523                BR      8$        ;SKIP ALL WRITING
4782
4783 022200 013737 001432 001160 15$:  MOV     T50000,$TMP0
4784 022206 005037 001162                CLR     $TMP1      ;BIT0=0;WRITE 0'S; BIT0=1:WRITE 1'S
4785
4786 022212 004737 026436      4$:  JSR     PC,SUBCLR
4787 022216 104024                ERROR    24      ;CERR AFTER SCLR
4788
4789 022220 032737 000001 001162                BIT     #BIT0,$TMP1
4790 022226 001004                BNE     5$        ;BR IF WRITING 1'S
4791 022230 012765 001456 000004                MOV     #DATA0,RKBA(R5) ;SETUP ALL 0'S
4792 022236 000403                BR      6$
4793
4794 022240 012765 001462 000004 5$:  MOV     #DATA1,RKBA(R5) ;SETUP ALL 1'S
4795 022246 052765 000020 000010 6$:  BIS     #BAI,RKCS2(R5)
4796 022254 012765 140400 000002                MOV     #-63.*256.,RKWC(R5) ;TRACK 0,1,2 63 SECTORS
4797 022262 005065 000006                CLR     RKDA(R5)   ;BEGIN AT TRK AND SECTOR 0
4798 022266 013765 001366 000020                MOV     TOCYL,RKDC(R5)
4799 022274 012737 000023 005340                MOV     #WRDATA,HCS1
4800 022302 004737 024504                JSR     PC,DATCMD   ;DO WRITE DATA CMD & GET CONTR RDY
4801 022306 104011                ERROR    11      ;CONTR NOT RDY
4802
4803 022310 004737 026106                JSR     PC,GSTAT
4804 022314 032737 100000 005340                BIT     #CERR,HCS1
4805 022322 001017                BNE     3$
4806 022324 005337 001160                DEC     $TMP0
4807 022330 001011                BNE     7$
4808 022332 104146                ERROR    146     ;CERR NOT SET BY TIMEOUT
4809 022334 104401 041626                TYPE    ,MSG50     ;TURN AC BACK ON
4810 022340 104401 043647                TYPE    ,MSG69     ;DEPRESS SPACE AFTER 'READY' LIGHT ON
4811 022344 004737 030452                JSR     PC,GETSP    ;GET SPACE
4812 022350 000137 023374                JMP     12$        ;EXIT TEST
4813
4814 022354 005237 001162      7$:  INC     $TMP1
4815 022360 000714                BR      4$        ;GO WRITE OPPOSITE DATA
4816

```

4817	022362	032737	000100	005370	3\$:	BIT	#D.ACLO,HMR3	
4818	022370	001001				BNE	10\$	
4819	022372	104147				ERROR	147	;AC LOW NOT SET
4820								
4821	022374	005237	005322		10\$:	INC	UNLD	;FOR VALID HALT
4822	022400	012737	070140	005430		MOV	#<D.DSC!D.PIP!D.SPIN!D.VV!D.DRA>,E.A0	;EXPECTED MSG A0
4823	022406	012737	010300	005432		MOV	#<D.SPLS!D.ACLO!D.FLT>,E.B0	
4824	022414	012737	044720	005434		MOV	#<D.UNLD!D.REV!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1	
4825	022422	012737	000001	005436		MOV	#1,E.B1	
4826								
4827	022430	004737	025264			JSR	PC,CHKMSG	;CHECK MSGS A0, B0, A1, B1
4828	022434	000000				.WORD	0!0!0	;8 MSGS SPECIFIED HERE
4829	022436	104035				ERROR	35	;MSG A0 ERROR AFTER AC SWITCH OFF FROM HEADS LOADED
4830	022440	104203				ERROR	203	;MSH B0 ERROR
4831	022442	104036				ERROR	36	;MSG A1 ERROR
4832	022444	104037				ERROR	37	;MSG B1 ERROR
4833								
4834	022446	013737	005350	001164	8\$:	MOV	HDA,\$TMP2	;SAVE RKDA
4835	022454	013737	005350	001166		MOV	HDA,\$TMP3	;SAVE FOR TYPEOUT
4836								
4837	022462	104401	041626			TYPE	,MSG50	;TURN AC BACK ON
4838	022466	104401	043647			TYPE	,MSG69	;DEPRESS SPACE AFTER 'READY' LIGHT ON
4839	022472	004737	030452			JSR	PC,GETSP	;GET SPACE
4840								
4841	022476	004737	026436			JSR	PC,SUBCLR	
4842	022502	104024				ERROR	24	;CERR AFTER SCLR
4843								
4844	022504	032737	000100	005370		BIT	#D.ACLO,HMR3	
4845	022512	001401				BEQ	9\$	
4846	022514	104152				ERROR	152	;ACLO NOT RESET AFTER POWER UP
4847								
4848	022516	005037	005322		9\$:	CLR	UNLD	;FOR VALID HALT
4849	022522	012765	100000	000000		MOV	#CCLR,RKCS1(R5)	
4850	022530	013765	001222	000010		MOV	\$UNIT,RKCS2(R5)	;DRIVE #
4851	022536	012737	000003	005340		MOV	#PACK,HCS1	
4852	022544	004737	024446			JSR	PC,DOCMD	;DO PACK CMD & GET CONTR RDY
4853	022550	104116				ERROR	116	;CONTR NOT RDY
4854								
4855	022552	032737	000100	005366		BIT	#D.VV,HMR2	
4856	022560	001001				BNE	65\$	
4857	022562	104027				ERROR	27	;VOLUME VALID NOT SET AFTER PACK CMD
4858	022564				65\$:			
4859	022564	005737	001474			TST	BSERR	;SEE IF ALIGN CART USED
4860	022570	001402				BEQ	14\$;BR IF NO
4861	022572	000137	023374			JMP	12\$;ELSE EXIT TEST
4862								
4863	022576				14\$:			
4864								
4865	022576	004737	026436			JSR	PC,SUBCLR	
4866	022602	104024				ERROR	24	;CERR AFTER SCLR
4867								
4868	022604	005737	001164			TST	\$TMP2	;SEE IF TRK/SECTOR 0
4869	022610	001414				BEQ	73\$;REPEAT,NO NEW DATA XFER TOOK PLACE
4870	022612	023727	001164	001023		CMP	\$TMP2,#1023	;SEE IF TRK 2,SECTOR 19
4871	022620	001410				BEQ	73\$;REPEAT,NO OLD DATA TO CHECK AGAINST
4872	022622	032737	000001	001162		BIT	#BIT0,\$TMP1	

4873	022630	001006			BNE	66\$:BR IF WRITING 1'S WHEN WLE OCCURRED
4874	022632	012765	001462	000004	MOV	#DATA1,RKBA(R5)	:WRITING 0'S:WLE SECTOR SHOULD HAVE ALL 1'S
4875	022640	000405			BR	67\$	
4876							
4877	022642	000137	022142		73\$: JMP	2\$	
4878							
4879	022646	012765	001456	000004	66\$: MOV	#DATA0,RKBA(R5)	:WRITING 1'S:WLE SECTOR SHOULD HAVE ALL 0'S
4880	022654	052765	000020	000010	67\$: BIS	#BAI,RKCS2(R5)	
4881	022662	012765	177400	000002	MOV	#-256.,RKWC(R5)	
4882	022670	013765	001166	000006	MOV	\$TMP3,RKDA(R5)	:REFRESH RKDA
4883	022676	017537	000004	001436	MOV	@RKBA(R5),WD2	:EXPECTED WORD FOR TRUERR TYPEOUT
4884	022704	013765	001366	000020	MOV	TOCYL,RKDC(R5)	
4885							
4886	022712	012737	000031	005340	MOV	#<WRTCHK>,HCS1	
4887	022720	004737	024504		JSR	PC,DATCMD	:DO DATA X FOR CMD & GET CONTR RDY
4888	022724	104015			ERROR	15	:NO RDY AFTER WRITE CHECK CMD
4889	022726	004737	026106		JSR	PC,GSTAT	:GET FRESH STATUS
4890	022732	032737	100000	005340	BIT	#CERR,HCS1	
4891	022740	001450			BEQ	75\$	
4892	022742	032737	040000	005342	BIT	#WCE,HCS2	:SEE IF WRITE CHECK ERROR
4893	022750	001405			BEQ	74\$	
4894	022752	016537	000024	001434	MOV	RKDB(R5),WD1	:ACTUAL WORD FOR PRINTOUT
4895	022760	104136			ERROR	136	:WCE AFTER WRITE CMD
4896	022762	000437			BR	75\$	
4897							
4898	022764	104022			74\$: ERROR	22	:CERR AFTER WRITE CHECK CMD
4899							
4900	022766	012737	010340	005430	MOV	#<0!D.SPIN!D.DRDY!D.VV!D.DRA>,E.A0	:EXPECTED MSG A0
4901	022774	005037	005432		CLR	E.B0	:EXPECTED MSG B0
4902	023000	012737	001720	005434	MOV	#<D.SPOK!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1	:EXPECTED A1
4903	023006	012737	000001	005436	MOV	#1,E.B1	:MSG ID FOR EXPECTED MSG B1
4904	023014	005037	005440		CLR	E.A2	:EXPECTED MSG A2
4905	023020	012737	000002	005442	MOV	#2,E.B2	:MSG ID FOR EXPECTED MSG B2
4906	023026	012737	000003	005446	MOV	#3,E.B3	:MSG ID FOR EXPECTED MSG B3
4907							
4908	023034	004737	025264		JSR	PC,CHKMSG	:CHECK MSGS A0, B0, A1, B1
4909	023040	000003			.WORD	T.A2!T.B2!0	:& MSGS SPECIFIED HERE
4910	023042	104057			ERROR	57	:MSG A0 ERROR AFTER WRITE CHECK CMD
4911	023044	104031			ERROR	31	:MSH B0 ERROR
4912	023046	104060			ERROR	60	:MSG A1 ERROR
4913	023050	104032			ERROR	32	:MSG B1 ERROR
4914	023052	104401	044035		TYPE	,MSG72	:ABORTING BALANCE OF TESTS
4915	023056	000137	023374		JMP	ENDRV	
4916							
4917	023062				75\$: NOP		
4918	023062	000240			NOP		
4919	023064	000240			NOP		
4920							
4921	023066	023727	001164	000400	CMP	\$TMP2,#400	:SEE IF WRL AT TRK 1, SECTOR 0
4922	023074	001004			BNE	68\$:BR IF NO
4923	023076	012765	000025	000006	MOV	#21.,RKDA(R5)	:ELSE SECTOR BEFORE WRL IS TRK 0, SEC 21
4924	023104	000415			BR	70\$	
4925	023106	023727	001164	001000	68\$: CMP	\$TMP2,#1000	:SEE IF WRL AT TRK 2,SECTOR 0
4926	023114	001004			BNE	69\$:BR IF NO
4927	023116	012765	000425	000006	MOV	#425,RKDA(R5)	:ELSE SECTOR BEFORE WRL IS TRK 1, SEC 21
4928	023124	000405			BR	70\$	

```

4929
4930 023126 005337 001164 69$: DEC $TMP2 ;GET SECTOR BEFORE WRL
4931 023132 013765 001164 000006 MOV $TMP2,RKDA(R5)
4932 023140 016537 000006 001166 70$: MOV RKDA(R5),$TMP3 ;FOR ERROR PRINTOUT
4933 023146 032737 000001 001162 BIT #BIT0,$TMP1
4934 023154 001004 BNE 71$ ;BR IF WRITING 1'S WHEN WLE OCCURRED
4935 023156 012765 001456 000004 MOV #DATA0,RKBA(R5) ;WRITING 0'S:WLE SECTOR -1 SHOULD HAVE ALL 0'S
4936 023164 000403 BR 72$
4937
4938 023166 012765 001462 000004 71$: MOV #DATA1,RKBA(R5) ;WRITING 1'S:WLE SECTOR -1 SHOULD HAVE ALL 1'S
4939 023174 052765 000020 000010 72$: BIS #BA1,RKCS2(R5)
4940 023202 012765 177400 000002 MOV #-256,RKWC(R5)
4941 023210 017537 000004 001436 MOV @RKBA(R5),WD2 ;EXPECTED WORD FOR TRUERR TYPEOUT
4942 023216 013765 001366 000020 MOV TOCYL,RKDC(R5)
4943
4944 023224 012737 000031 005340 MOV #<WRTCHK>,HCS1
4945 023232 004737 024504 JSR PC,DATCMD ;DO DATA X FOR CMD & GET CONTR RDY
4946 023236 104015 ERROR 15 ;NO RDY AFTER WRITE CHECK CMD
4947 023240 004737 026106 JSR PC,GSTAT ;GET FRESH STATUS
4948 023244 032737 100000 005340 BIT #CERR,HCS1
4949 023252 001450 BEQ 77$
4950 023254 032737 040000 005342 BIT #WCE,HCS2 ;SEE IF WRITE CHECK ERROR
4951 023262 001405 BEQ 76$
4952 023264 016537 000024 001434 MOV RKDB(R5),WD1 ;ACTUAL WORD FOR PRINTOUT
4953 023272 104137 ERROR 137 ;WCE AFTER WRITE CMD
4954 023274 000437 BR 77$
4955
4956 023276 104022 76$: ERROR 22 ;CERR AFTER WRITE CHECK CMD
4957
4958 023300 012737 010340 005430 MOV #<0!D.SPIN!D.DRDY!D.VV!D.DRA>,E.A0 ;EXPECTED MSG A0
4959 023306 005037 005432 CLR E.B0 ;EXPECTED MSG B0
4960 023312 012737 001720 005434 MOV #<D.SPOK!D.CART!D.DOOR!D.BRHM!D.SSP>,E.A1 ;EXPECTED A1
4961 023320 012737 000001 005436 MOV #1,E.B1 ;MSG ID FOR EXPECTED MSG B1
4962 023326 005037 005440 CLR E.A2 ;EXPECTED MSG A2
4963 023332 012737 000002 005442 MOV #2,E.B2 ;MSG ID FOR EXPECTED MSG B2
4964 023340 012737 000003 005446 MOV #3,E.B3 ;MSG ID FOR EXPECTED MSG B3
4965
4966 023346 004737 025264 JSR PC,CHKMSG ;CHECK MSGS A0, B0, A1, B1
4967 023352 000003 .WORD T.A2!T.B2!0 ;& MSGS SPECIFIED HERE
4968 023354 104057 ERROR 57 ;MSG A0 ERROR AFTER WRITE CHECK CMD
4969 023356 104031 ERROR 31 ;MSG B0 ERROR
4970 023360 104060 ERROR 60 ;MSG A1 ERROR
4971 023362 104032 ERROR 32 ;MSG B1 ERROR
4972 023364 104401 044035 TYPE ,MSG72 ;ABORTING BALANCE OF TESTS
4973 023370 000137 023374 JMP ENDRV
4974
4975 023374 77$:
4976
4977 023374 12$:
4978
4979 023374 ENDRV:
4980
4981 *****
4982 *TEST 20 END OF PROGRAM
4983 *
4984 * THIS IS NOT A TEST BUT A LINKAGE TO PERFORM ALL THE

```



```

5041 023526 004737 030452 JSR PC,GETSP ;GET SPACE
5042
5043 023532 004737 026436 3$: JSR PC,SUBCLR
5044 023536 104024 ERROR 24 ;CERR AFTER SCLR
5045
5046 023540 104401 042714 TYPE ,MSG59 ;INSERT SAME UNIT SEL PLUG # IN 2 DRIVES
5047 023544 104401 040625 TYPE ,MSG37 ;DEPRESS SPACE BAR WHEN DONE
5048 023550 004737 030452 JSR PC,GETSP ;GET SPACE
5049
5050 023554 005000 CLR R0 ;DRIVE # COUNTER
5051
5052 023556 012765 100000 000000 6$: MOV #CCLR,RKCS1(R5)
5053 023564 010065 000010 MOV R0,RKCS2(R5) ;DRIVE #
5054 023570 012737 000001 005340 MOV #SELDRV,HCS1
5055 023576 053737 001170 005340 BIS $TMP4,HCS1 ;ADD CDT IF RK07
5056 023604 013765 005340 000000 MOV HCS1,RKCS1(R5) ;GET STATUS
5057 023612 013737 001432 005376 MOV T50000,TEMP1
5058 023620 004737 025232 JSR PC,DLY ;DO DELAY TO CATCH MDS
5059
5060 023624 032765 001000 000010 BIT #MDS,RKCS2(R5) ;SEE IF THAT DRIVE HAS MDS
5061 023632 001006 BNE 7$ ;BR IF YES
5062 023634 005200 INC R0 ;ELSE TRY ANOTHER DRIVE
5063 023636 020027 000010 CMP R0,#8. ;SEE IF ALL DRIVES TESTED
5064 023642 001345 BNE 6$ ;BR IF NO
5065 023644 104176 ERROR 176 ;CANNOT FIND MDS
5066 023646 000411 BR 10$ ;TRY AGAIN
5067
5068 023650 104401 043127 7$: TYPE ,MSG61 ;MULT DRIVES FOUND ON DRIVE #
5069 023654 010046 MOV R0,-(SP) ;;SAVE R0 FOR TYPEOUT
5070 ;;TYPE UNIT NO
5071 023656 104403 TYPOS ;;GO TYPE--OCTAL ASCII
5072 023660 001 .BYTE 1 ;;TYPE 1 DIGIT(S)
5073 023661 000 .BYTE 0 ;;SUPPRESS LEADING ZEROS
5074 023662 104401 043607 TYPE ,MSG68 ;VERIFY BOTH DRIVES UNLOADED
5075 023666 005237 005322 INC UNLD ;FOR VALID HALT
5076 023672 104401 043017 10$: TYPE ,MSG60 ;INSERT CORRECT UNIT SEL PLUG & LOAD HEADS
5077 023676 104401 043271 TYPE ,MSG63 ;DEPRESS CONT-E OR SPACE BAR WHEN DONE
5078 023702 004737 030412 JSR PC,CCSP ;INPUT CONT-E OR SPACE
5079 023706 000137 023722 JMP 11$ ;RETURN HERE FOR CONTROL-E (EXIT)
5080 023712 005037 005322 CLR UNLD ;RETURN HERE FOR SPACE (DO AGAIN)
5081 023716 000137 023532 JMP 3$
5082 023722 005037 005322 11$: CLR UNLD
5083
5084 023726 004737 026436 JSR PC,SUBCLR
5085 023732 104024 ERROR 24 ;CERR AFTER SCLR
    
```



```

5086
5087
5088
5089
5090
5091
5092
5093
5094 023734
5095 023734 000004
5096 023736 005037 001102
5097 023742 005037 001174
5098 023746 005237 001216
5099 023752 042737 100000 001216
5100 023760 005327
5101 023762 000001
5102 023764 003022
5103 023766 012737
5104 023770 000001
5105 023772 023762
5106 023774 104401 024041
5107 024000 013746 001216
5108 024004 104405
5109 024006 104401 024036
5110 024012 013700 000042
5111 024016 001405
5112 024020 000005
5113 024022 004710
5114 024024 000240
5115 024026 000240
5116 024030 000240
5117 024032
5118 024032 000137
5119 024034 024056
5120 024036 377 377 000
5121 024041 015 042412 042116
5122 024046 050040 051501 020123
5123 024054 000043
5124 024056 122737 000001 001230
5125 024064 001007
5126 024066 022737 000002 001216
5127 024074 101003
5128 024076 005237 001102
5129 024102 000775
5130 024104 000137 010612

```

```

.SBTTL END OF PASS ROUTINE
*****
*INCREMENT THE PASS NUMBER ($PASS)
*TYPE 'END PASS #XXXXX' (WHERE XXXXX IS A DECIMAL NUMBER)
*IF THERES A MONITOR GO TO IT
*IF THERE ISN'T JUMP TO ST5XY

$EOP:
SCOPE
CLR $STNM ::ZERO THE TEST NUMBER
CLR $TIMES ::ZERO THE NUMBER OF ITERATIONS
INC $PASS ::INCREMENT THE PASS NUMBER
BIC #100000,$PASS ::DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ::LOOP?
$EOPCT: .WORD 1
BGT $DOAGN ::YES
MOV (PC)+,@(PC)+ ::RESTORE COUNTER
$ENDCT: .WORD 1
TYPE $SENDMG ::TYPE 'END PASS #'
MOV $PASS,-(SP) ::SAVE $PASS FOR TYPEOUT
TYPDS ::GO TYPE--DECIMAL ASCII WITH SIGN
TYPE $ENULL ::TYPE A NULL CHARACTER
$GET42: MOV @#42,R0 ::GET MONITOR ADDRESS
BEQ $DOAGN ::BRANCH IF NO MONITOR
RESET ::CLEAR THE WORLD
$ENDAD: JSR PC,(R0) ::GO TO MONITOR
NOP ::SAVE ROOM
NOP ::FOR
NOP ::ACT11
$DOAGN: JMP @(PC)+ ::RETURN
$RTNAD: .WORD ST5XY
$ENULL: .BYTE -1,-1,0 ::NULL CHARACTER STRING
$ENDMG: .ASCIZ <15><12>/END PASS #/

ST5XY: CMPB #APTENV,$ENV ;RUN UNDER APT ?
BNE 2$ :BRANCH IF NOT
CMP #2,$PASS :TWO PASSES DONE ?
BHI 2$ :BRANCH IF NOT
INC $STNM :CHANGE THE TEST NUMBER
BR 1$ :LOOPING
JMP ST5 :EXIT

```

```

5131      .SBTTL SUBROUTINES
5132
5133      ;SUBROUTINE TO CLEAR ALL FLAGS FROM DDUMP THRU DOTIM
5134      ;
5135
5136      024110 012700 005450 CLRFLG: MOV      #DDUMP,R0
5137      024114 012701 177757      MOV      #-17.,R1
5138      024120 005020      1$:      CLR      (R0)+
5139      024122 005201      INC      R1
5140      024124 001375      BNE     1$
5141      024126 000207      RTS     PC
5142
5143
5144      ;TYPE PROGRAM ID IF FTITLE=0
5145      ;
5146
5147      024130 005737 001360 TITLE:  TST      FTITLE
5148      024134 001024      BNE     1$
5149      024136 005237 001360      INC      FTITLE
5150      024142 104401 035736      TYPE     ,MSG1      ;PROGRAM ID
5151      .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
5152      024146 005737 000042      TST     @#42      ;;ARE WE RUNNING UNDER XXDP/ACT?
5153      024152 001012      BNE     64$      ;;BRANCH IF YES
5154      024154 123727 001230 000001      CMPB    $ENV,#1    ;;ARE WE RUNNING UNDER APT?
5155      024162 001406      BEQ     64$      ;;BRANCH IF YES
5156      024164 023727 001140 000176      CMP     SWR,#SWREG ;;SOFTWARE SWITCH REG SELECTED?
5157      024172 001005      BNE     65$      ;;BRANCH IF NO
5158      024174 104406      GTSWR   ;;GET SOFT-SWR SETTINGS
5159      024176 000403      BR      65$
5160      024200 112737 000001 001134 64$:  MOVB    #1,$AUTOB  ;;SET AUTO-MODE INDICATOR
5161      024206      65$:
5162      024206 000207      1$:      RTS     PC
5163
5164
5165      ;ROUTINE TO INPUT DRIVE NOS. TYPED IN & SET
5166      ;DRIVS, DRIVO-DRIV7 REGISTERS APPROPRIATELY
5167      ;
5168
5169      024210 104411      GDRVS:  RDLIN
5170      024212 012600      MOV     (SP)+,R0      ;GET STARTING ADDR OF ASCII STRING
5171      024214 012701 177770      MOV     #-8.,R1      ;SET UP COUNT
5172      024220 112002      1$:     MOVB    (R0)+,R2      ;GET ASCII CHAR
5173      024222 042702 177400      BIC     #177400,R2    ;MASK HI BYTE
5174      024226 012703 005462      MOV     #DRIVO,R3    ;DRIVE FLAG ADDR
5175      024232 012704 000060      MOV     #60,R4
5176
5177      024236 020402      2$:     CMP     R4,R2      ;WAS TYPED CHAR 0 THRU 7?
5178      024240 001415      BEQ     3$      ;BRANCH IF YES
5179      024242 005723      TST     (R3)+      ;NO, INCREMENT DR FLAG ADDR
5180      024244 005204      INC     R4
5181      024246 020427 000070      CMP     R4,#70
5182      024252 001371      BNE     2$      ;S/B 0-7 OR TERMINATOR
5183      024254 005702      TST     R2
5184      024256 001022      BNE     4$
5185      024260 020127 177770      CMP     R1,#-8.
5186      024264 001426      BEQ     6$      ;DEFAULT ALL DRIVES

```



```

5187 024266 005037 005510 7$: CLR SIZFLG ;BYPASS TEST 1 (SIZING)
5188 024272 000207 RTS PC ;FOUND TERMINATOR, EXIT
5189
5190 024274 005213 3$: INC @R3 ;SET UP FLAG FOR THE DRIVE
5191 024276 005237 005460 INC DRIVS ;INCREMENT TOTAL # DRIVES TO BE TESTED
5192 024302 112002 MOV#B (R0)+,R2 ;GET NEXT ASCII CHAR.
5193 024304 042702 177400 BIC #177400,R2 ;MASK
5194 024310 022702 000054 CMP #54,R2 ;IS IT A COMMA?
5195 024314 001407 BEQ 5$ ;YES, GO TO NEXT WORD.
5196 024316 005702 TST R2 ;NO, IS IT A TERMINATOR?
5197 024320 001001 BNE 4$ ;IF NOT, SOMETHING WRONG.
5198 024322 000761 BR 7$ ;FOUND TERMINATOR, EXIT
5199
5200 024324 104401 044402 4$: TYPE ,EM1 ;ONLY 0-7 ALLOWED.
5201 024330 000137 010016 JMP PRGSRT ;START ALL OVER
5202
5203 024334 005201 5$: INC R1 ;S/B NO MORE THAN 8 DIFF
5204 024336 001330 BNE 1$ ;DRIVES TYPED IN.
5205 024340 000771 BR 4$ ;IF NORE, HAVE ERROR.
5206
5207 024342 005237 005510 6$: INC SIZFLG ;DO TEST 1 (SIZING)
5208 024346 000207 RTS PC ;EXIT.
5209
5210 ;ROUTINE TO INPUT RKBAS OR DEFAULT.
5211 ;
5212 ;
5213 ;
5214 024350 104412 GBA: RDOCT
5215 024352 012600 MOV (SP)+,R0 ;GET LOW ORDER FROM STACK
5216 024354 005700 TST R0
5217 024356 001403 BEQ 1$ ;BRANCH IF DEFAULT.
5218 024360 010037 001264 MOV R0,$BASE
5219 024364 000207 RTS PC
5220 024366 012737 177440 001264 1$: MOV #177440,$BASE ;DEFAULT VALUE
5221 024374 000207 RTS PC
5222
5223 ;ROUTINE TO INPUT RKVEC OR DEFAULT
5224 ;
5225 ;
5226 ;
5227 024376 104412 GINT: RDOCT
5228 024400 012600 MOV (SP)+,R0 ;GET LOW ORDER FROM STACK
5229 024402 005700 TST R0
5230 024404 001405 BEQ 1$ ;BRANCH IF DEFAULT
5231 024406 010037 001334 MOV R0,RKVEC
5232 024412 004737 024430 2$: JSR PC,SETINT
5233 024416 000207 RTS PC
5234 024420 012737 000210 001334 1$: MOV #210,RKVEC ;DEFAULT VALUE
5235 024426 000771 BR 2$
5236
5237 ;ROUTINE TO SETUP INTERRUPT VECTOR & PRIORITY
5238 ;
5239 ;
5240 ;
5241 024430 013700 001334 SETINT: MOV RKVEC,R0
5242 024434 012720 031152 MOV #INTER,(R0)+ ;INTER ADDR TO RKVEC

```

```
5243 024440 013710 001336      MOV    RKPRI,(R0)      ;PR5 TO RKVEC+2
5244 024444 000207              RTS    PC
5245
5246
5247
5248      ; THIS ROUTINE SETS CDT IN RKCS1 IF DRIVE UNDER TEST IS AN RK07.
5249      ; ENTER WITH COMMAND IN HCS1
5250
5251 024446 053737 001170 005340 DOCMD: BIS    $TMP4,HCS1      ;ADD CDT IF RK07
5252 024454 013765 005340 000000      MOV    HCS1,RKCS1(R5) ;DO COMMAND
5253 024462 013737 001424 005376      MOV    T10,TEMP1
5254 024470 004737 024542      JSR    PC,FRDY        ;FIND CONTR READY
5255 024474 000207              RTS    PC             ;SET HERE IF NOT RDY
5256 024476 062716 000002      ADD    #2,(SP)       ;ELSE SKIP OVER ERROR
5257 024502 000207              RTS    PC
5258
5259      ; THIS ROUTINE IS SIMILAR TO THE ABOVE BUT IS USED FOR DATA TRANSFERS
5260      ; & REQUIRES A LONGER TIMEOUT
5261
5262 024504 053737 001170 005340 DATCMD: BIS    $TMP4,HCS1      ;ADD CDT IF RK07
5263 024512 013765 005340 000000      MOV    HCS1,RKCS1(R5) ;DO CMD
5264 024520 013737 001432 005376      MOV    T5000,TEMP1
5265 024526 004737 024542      JSR    PC,FRDY        ;FIND CONTR RDY
5266 024532 000207              RTS    PC
5267 024534 062716 000002      ADD    #2,(SP)
5268 024540 000207              RTS    PC
5269
5270
5271      ; ROUTINE TO FIND CONTROLLER READY (RDY) DURING A DELAY
5272      ; ENTER WITH A COUNT IN TEMP1
5273      ; RETURN IF RDY NOT PRESENT (ERROR CONDITION)
5274      ; RETURN +2 IF RDY PRESENT (SKIP OVER ERROR)
5275      ; STATUS IS OBTAINED BEFORE THE RETURN FOR EITHER CASE
5276
5277 024542 032765 000200 000000 FRDY:  BIT    #RDY,RKCS1(R5)
5278 024550 001010      BNE    1$
5279 024552 005337 005376      DEC    TEMP1
5280 024556 001371      BNE    FRDY
5281 024560 004737 024676      JSR    PC,HOLD        ;STORE ALL RK611 REGS IN HOLDING REGS.
5282 024564 004737 026024      JSR    PC,CKCERR      ;CHECK FOR SPECIAL CERR
5283 024570 000207              RTS    PC             ;NO RDY, EXIT
5284 024572 062716 000002 1$:    ADD    #2,(SP)       ;SKIP OVER ERROR
5285 024576 004737 024676      JSR    PC,HOLD
5286 024602 004737 026024      JSR    PC,CKCERR      ;CHECK FOR SPECIAL CERR
5287 024606 000207              RTS    PC
5288
5289      ; ROUTINE TO FIND CONTROLLER READY AND STORE DRIVE REGS ONLY
5290
5291 024610 032765 000200 000000 FRDY1: BIT    #RDY,RKCS1(R5)
5292 024616 001014      BNE    1$
5293 024620 005337 005376      DEC    TEMP1
5294 024624 001371      BNE    FRDY1
5295 024626 016537 000034 005366      MOV    RKMR2(R5),HMR2
5296 024634 016537 000036 005370      MOV    RKMR3(R5),HMR3
5297 024642 004737 026024      JSR    PC,CKCERR      ;CHECK FOR SPECIAL CERR CONDITIONS
5298 024646 000207              RTS    PC             ;NO RDY, EXIT
```



```
5299 024650 062716 000002 1$: ADD #2,(SP) ;SKIP OVER ERROR
5300 024654 016537 000034 005366 MOV RKMR2(R5),HMR2
5301 024662 016537 000036 005370 MOV RKMR3(R5),HMR3
5302 024670 004737 026024 JSR PC,CKCERR ;CHECK FOR SPECIAL CERR CONDITIONS
5303 024674 000207 RTS PC
5304
5305
5306 ;STORE ALL RK611 REGISTERS IN HOLDING REGS
5307
5308
5309 024676 016537 000000 005340 HOLD: MOV RKCS1(R5),HCS1
5310 024704 016537 000010 005342 MOV RKCS2(R5),HCS2
5311 024712 016537 000002 005344 MOV RKWC(R5),HWC
5312 024720 016537 000004 005346 MOV RKBA(R5),HBA
5313 024726 016537 000006 005350 MOV RKDA(R5),HDA
5314 024734 016537 000012 005352 MOV RKDS(R5),HDS
5315 024742 016537 000014 005354 MOV RKER(R5),HER
5316 024750 016537 000016 005356 MOV RKASOF(R5),HASOF
5317 024756 016537 000020 005360 MOV RKDC(R5),HDC
5318 024764 016537 000026 005364 MOV RKMR1(R5),HMR1
5319 024772 016537 000034 005366 MOV RKMR2(R5),HMR2
5320 025000 016537 000036 005370 MOV RKMR3(R5),HMR3
5321 025006 016537 000030 005372 MOV RKECPS(R5),HPOS
5322 025014 016537 000032 005374 MOV RKECPT(R5),HPAT
5323 025022 000207 RTS PC
5324
5325
5326 ;ROUTINE TO CHECK FOR CORRECT ATTN
5327 ;RETURN IF ATTN NOT PRESENT (ERROR CONDITION)
5328 ;RETURN +2 IF ATTN PRESENT (SKIP OVER ERROR)
5329
5330 025024 010446 TSTATN: MOV R4,-(SP) ;SAV R4
5331 025026 013704 001222 MOV $UNIT,R4
5332 025032 136437 005330 005357 BITB ATTN(R4),HASOF+1
5333 025040 001404 BEQ 1$ ;BRANCH IF ATTN NOT PRESENT
5334 025042 012604 MOV (SP)+,R4 ;RESTOR R4
5335 025044 062716 000002 ADD #2,(SP) ;INCR RET ADDR TO JUMP OVER ERROR.
5336 025050 000207 RTS PC
5337 025052 012604 1$: MOV (SP)+,R4 ;RESTOR R4
5338 025054 000207 RTS PC
5339
5340
5341
5342 ;ROUTINE TO FIND ATTN WITHIN TIMES GREATER THAN 1 SEC
5343 ;ENTER WITH TIME IN SECONDS IN TEMP2
5344 ;RETURN IF NO ATTN (ERROR CONDITION)
5345 ;RETURN +2 IF ATTN FOUND
5346 ;STATUS IS OBTAINED BEFORE THE RETURN FOR EITHER CASE
5347
5348
5349 025056 010446 FATT1: MOV R4,-(SP) ;SAV R4
5350 025060 012737 177777 005376 3$: MOV #-1,TEMP1
5351 025066 013704 001222 MOV $UNIT,R4
5352 025072 136465 005330 000017 1$: BITB ATTN(R4),RKASOF+1(R5) ;FIND CORRECT ATTN
5353 025100 001014 BNE 2$
5354 025102 005337 005376 DEC TEMP1
```

```

5355 025106 001371          BNE      1$
5356 025110 005337 005400   DEC      TEMP2
5357 025114 001361          BNE      3$
5358 025116 005065 000026   CLR      RKMR1(R5)      ;SELECT WORD 0
5359 025122 004737 026106   JSR      PC,GSTAT      ;GET LATEST STATUS
5360 025126 012604          MOV      (SP)+,R4      ;RESTOR R4
5361 025130 000207          RTS      PC
5362
5363 025132 005065 000026   2$:    CLR      RKMR1(R5)
5364 025136 004737 026106   JSR      PC,GSTAT      ;GET STATUS AFTER ATTN SEEN
5365 025142 012604          MOV      (SP)+,R4      ;RESTOR R4
5366 025144 062716 000002   ADD      #2,(SP)      ;SKIP OVER ERROR
5367 025150 000207          RTS      PC
5368
5369
5370          ;
5371          ;ROUTINE TO FIND ATTN WITHIN 1 SEC
5372          ;ENTER WITH COUNT IN TEMP1
5373          ;RETURN IF NO ATTN (ERROR)
5374          ;RETURN +2 IF ATTN FOUND
5375          ;STATUS IS OBTAINED BEFORE THE RETURN FOR EITHER CASE
5376          ;
5377 025152 010446          FATT2:  MOV      R4,-(SP)      ;SAV R4
5378 025154 013704 001222   2$:    MOV      $UNIT,R4
5379 025160 136465 005330 000017  BITB    ATTN(R4),RKASOF+1(R5) ;FIND CORRECT ATTN
5380 025166 001011          BNE      1$
5381 025170 005337 005376   DEC      TEMP1
5382 025174 001367          BNE      2$
5383 025176 005065 000026   CLR      RKMR1(R5)      ;SELECT WORD 0
5384 025202 004737 026106   JSR      PC,GSTAT      ;GET LATEST STATUS.
5385 025206 012604          MOV      (SP)+,R4      ;RESTOR R4
5386 025210 000207          RTS      PC
5387 025212 005065 000026   1$:    CLR      RKMR1(R5)
5388 025216 004737 026106   JSR      PC,GSTAT
5389 025222 012604          MOV      (SP)+,R4      ;RESTOR R4
5390 025224 062716 000002   ADD      #2,(SP)      ;SKIP OVER ERROR
5391 025230 000207          RTS      PC
5392
5393          ;
5394          ;ENTER WITH A COUNT IN TEMP1
5395          ;THE DELAY IS APPROX 17 US/ITERATION + 12 US TO EXIT
5396          ;WHEN COUNT IS 0. BASED ON AN 11/05
5397 025232 005737 005376   DLY:   TST      TEMP1      ;5.6 US
5398 025236 001403          BEQ      1$            ;2.5 US
5399 025240 005337 005376   DEC      TEMP1          ;6.8 US
5400 025244 000772          BR       DLY            ;2.5 US
5401 025246 000207          1$:    RTS      PC        ;3.8 US
5402
5403          ;
5404          ;THIS ROUTINE TYPES BYPASSED DRIVE#. ENTER WITH DRIVE# IN R0
5405          ;
5406 025250 104401 037367   BYP:   TYPE    ,MSG14      ;BYPASS DRIVE
5407 025254 010046          MOV      R0,-(SP)      ;SAVE R0 FOR TYPEOUT
5408          ;TYPE DR#
5409 025256 104403          TYPOS    ;GO TYPE--OCTAL ASCII
5410 025260 001            .BYTE    1            ;TYPE 1 DIGIT(S)

```



```

5411 025261 000 .BYTE 0 ::SUPPRESS LEADING ZEROS
5412 025262 000207 RTS PC
5413
5414 : THIS ROUTINE READS ALL MSG A & B WORDS & CHECKS THEM AS REQ'D.
5415
5416 025264 017637 000000 001504 CHKMSG: MOV @ (SP),CHKFLG :PASS MSGS TO BE TESTED
5417 025272 062716 000002 ADD #2,(SP) :BUMP RETURN ADDR TO 1ST ERROR
5418 025276 004737 026142 JSR PC,GSTAT1 :GET ALL ACTUAL DRIVE & CONTR STATUS
5419
5420 025302 053737 001222 005430 BIS $UNIT,E.A0 :SET UNIT #
5421 025310 053737 001222 005434 BIS $UNIT,E.A1
5422 025316 053737 001222 005440 BIS $UNIT,E.A2
5423 025324 053737 001222 005444 BIS $UNIT,E.A3
5424
5425 025332 053737 012662 005430 BIS E.DDT,E.A0 :ADD DRIVE TYPE
5426
5427 025340 013746 005376 MOV TEMP1,-(SP) :SAVE TEMP1
5428
5429 025344 013737 005430 005376 MOV E.A0,TEMP1
5430 025352 004737 030306 JSR PC,SBPAR :GET PARITY FOR MSG A0
5431 025356 013737 005376 005430 MOV TEMP1,E.A0
5432
5433 025364 013737 005434 005376 MOV E.A1,TEMP1
5434 025372 004737 030306 JSR PC,SBPAR :GET PARITY FOR MSG A1
5435 025376 013737 005376 005434 MOV TEMP1,E.A1
5436
5437 025404 013737 005440 005376 MOV E.A2,TEMP1
5438 025412 004737 030306 JSR PC,SBPAR :GET PARITY FOR MSG A2
5439 025416 013737 005376 005440 MOV TEMP1,E.A2
5440
5441 025424 013737 005432 005376 MOV E.B0,TEMP1
5442 025432 004737 030306 JSR PC,SBPAR :GET PARITY FOR MSG B0
5443 025436 013737 005376 005432 MOV TEMP1,E.B0
5444
5445 025444 013737 005436 005376 MOV E.B1,TEMP1
5446 025452 004737 030306 JSR PC,SBPAR :GET PARITY FOR MSG B1
5447 025456 013737 005376 005436 MOV TEMP1,E.B1
5448
5449 025464 013737 005442 005376 MOV E.B2,TEMP1
5450 025472 004737 030306 JSR PC,SBPAR :GET PARITY FOR MSG B2
5451 025476 013737 005376 005442 MOV TEMP1,E.B2
5452
5453 025504 013737 005446 005376 MOV E.B3,TEMP1
5454 025512 004737 030306 JSR PC,SBPAR :GET PARITY FOR MSG B3
5455 025516 013737 005376 005446 MOV TEMP1,E.B3
5456
5457 025524 012637 005376 MOV (SP)+,TEMP1 :RESTORE TEMP1
5458 025530 013737 001176 001172 MOV $ESCAPE,$TMP5 :SAVE ESCAPE
5459
5460 025536 023737 005410 005430 CMP H.A0,E.A0 :TEST MSG A0
5461 025544 001411 BEQ 2$ :BR IF OK
5462 025546 012737 025560 001176 MOV #1$,$ESCAPE :ELSE SETUP ESCAPE
5463 025554 011646 MOV (SP),-(SP) :COPY RET ADDR.
5464 025556 000207 RTS PC :& RETURN TO MAINLINE ERROR
5465
5466 025560 032777 001000 153352 1$: BIT #SW9,@SWR :RET HERE FROM MAINLINE ERROR
  
```

```

5467 025566 001107          BNE      20$          :& BR IF LOOP ON ERROR
5468 025570 062716 000002 2$:      ADD      #2,(SP)      :BUMP RET ADDR TO NEXT ERROR
5469
5470 025574 023737 005412 005432          CMP      H.B0,E.B0      :TEST MSG B0
5471 025602 001411          BEQ      5$              :BR IF OK
5472 025604 012737 025616 001176          MOV      #4$, $ESCAPE   :ELSE SETUP ESCAPE
5473 025612 011646          MOV      (SP),-(SP)     :COPY RET ADDR
5474 025614 000207          RTS      PC              :& RETURN TO MAINLINE ERROR
5475
5476 025616 032777 001000 153314 4$:      BIT      #SW9,@SWR     :RETURN HERE FROM MAINLINE ERROR
5477 025624 001070          BNE      20$          :& BR IF LOOP ON ERROR
5478 025626 062716 000002 5$:      ADD      #2,(SP)      :BUMP RET ADDR TO NEXT ERROR
5479
5480 025632 023737 005414 005434          CMP      H.A1,E.A1      :TEST MSG A1
5481 025640 001411          BEQ      8$              :BR IF OK
5482 025642 012737 025654 001176          MOV      #7$, $ESCAPE   :
5483 025650 011646          MOV      (SP),-(SP)     :
5484 025652 000207          RTS      PC              :
5485
5486 025654 032777 001000 153256 7$:      BIT      #SW9,@SWR     :
5487 025662 001051          BNE      20$          :
5488 025664 062716 000002 8$:      ADD      #2,(SP)      :
5489
5490 025670 023737 005416 005436          CMP      H.B1,E.B1      :TEST MSG B1
5491 025676 001411          BEQ      11$             :BR IF OK
5492 025700 012737 025712 001176          MOV      #10$, $ESCAPE  :
5493 025706 011646          MOV      (SP),-(SP)     :
5494 025710 000207          RTS      PC              :
5495
5496 025712 032777 001000 153220 10$:     BIT      #SW9,@SWR     :
5497 025720 001032          BNE      20$          :
5498 025722 062716 000002 11$:     ADD      #2,(SP)      :
5499
5500 025726 032737 000001 001504 12$:     BIT      #T.A2,CHKFLG   :TEST MSG A2?
5501 025734 001402          BEQ      13$             :BR IF NO
5502 025736 004737 026722          JSR      PC,RCYLD       :PUT INFO CYLDIF, DO NOT CHECK
5503 025742 032737 000002 001504 13$:     BIT      #T.B2,CHKFLG   :TEST MSG B2?
5504 025750 001402          BEQ      14$             :BR IF NO
5505 025752 004737 026774          JSR      PC,RCYLA       :PUT INFO IN CYLADD, DO NOT CHECK
5506
5507 025756 032737 000004 001504 14$:     BIT      #T.B3,CHKFLG   :TEST MSG B3?
5508 025764 001404          BEQ      15$             :
5509 025766 004737 027032          JSR      PC,RSEC        :PUT INFO IN SECTOR, DO NOT CHECK
5510 025772 004737 027070          JSR      PC,RHEAD       :PUT INFO IN HEADA, DO NOT CHECK
5511
5512 025776 013737 001172 001176 15$:     MOV      $TMP5,$ESCAPE  :RESTORE ESCAPE
5513 026004 000207          RTS      PC              :
5514
5515 026006 012706 001100          MOV      #STACK,SP      :RESET STACK PTR
5516 026012 013737 001172 001176          MOV      $TMP5,$ESCAPE  :RESTORE ESCAPE
5517 026020 000177 153064          JMP      @SLPERR        :
5518
5519          :THIS ROUTINE CHECKS FOR CERTAIN ERROR CONDITIONS ONLY
5520          :I.E.: IF NED, CTO OR MDS SET MESSAGE A & B ARE INVALID
5521          :
5522 026024 005737 001502          CKCERR: TST      BYPCERR
  
```



```

5523 026030 001025          BNE      4$
5524 026032 032737 100000 005340  BIT      #CERR,HCS1
5525 026040 001001          BNE      1$          ;BR IF CERR
5526 026042 000207          RTS      PC
5527
5528 026044 032737 004000 005340 1$:  BIT      #CTO,HCS1
5529 026052 001402          BEQ      2$          ;BR IF NOT CTO
5530 026054 104211          ERROR    211        ;CTO ERROR, MSG A & B INVALID
5531 026056 000207          RTS      PC
5532
5533 026060 032737 010000 005342 2$:  BIT      #NED,HCS2
5534 026066 001401          BEQ      3$          ;BR IF NOT NED
5535 026070 104212          ERROR    212        ;NED ERROR, MSG A & B INVALID
5536
5537 026072 032737 001000 005342 3$:  BIT      #MDS,HCS2
5538 026100 001401          BEQ      4$
5539 026102 104213          ERROR    213        ;MDS ERROR, MSG A & B INVALID
5540
5541 026104 000207          4$:  RTS      PC
5542
5543
5544      ; THIS ROUTINE DOES THE SELECT DRIVE COMMAND TO GET STATUS
5545      ; IT THEN WAITS FOR CONTROLLER READY
5546
5547      ; IF RDY NOT RECEIVED BY THE TIMEOUT, AN ERROR IS FLAGGED
5548      ;
5549
5550 026106 013746 005376          GSTAT:  MOV     TEMP1,-(SP)      ;SAVE TEMP1
5551 026112 013765 001222 000010  MOV     $UNIT,RKCS2(R5)      ;CURRENT DRIVE #
5552 026120 012737 000001 005340  MOV     #SELDRV,HCS1
5553 026126 004737 024446          JSR     PC,DOCMD            ;DO SELDRV (STATUS) CMD & GET CONTR RDY
5554 026132 104117          ERROR    117              ;RDY NOT SET BY END OF SELECT DRIVE CMD
5555 026134 012637 005376          MOV     (SP)+,TEMP1          ;RESTOR TEMP1.
5556 026140 000207          RTS      PC
5557
5558      ; THIS ROUTINE GETS STATUS OF ALL DRIVE REGISTERS (MSG A0-A3, B0-B3)
5559      ; & ALL CONTROLLER REGISTERS.
5560
5561 026142 013746 005376          GSTAT1: MOV     TEMP1,-(SP)      ;SAVE TEMP1
5562 026146 004737 024676          JSR     PC,HOLD            ;GET ALL CONTR REG
5563 026152 012765 100000 000000  MOV     #CCLR,RKCS1(R5)      ;CLEAR CONTR
5564 026160 013765 001222 000010  MOV     $UNIT,RKCS2(R5)      ;CURRENT DRIVE #
5565 026166 012765 000003 000026  MOV     #3,RKMR1(R5)         ;SELECT WORD 3
5566 026174 004737 026372          JSR     PC,GSTAT2
5567 026200 104117          ERROR    117              ;RDY NOT SET BY END OF SELECT DRV CMD
5568 026202 013737 005366 005424  MOV     HMR2,H.A3           ;STORE MSG A3
5569 026210 013737 005370 005426  MOV     HMR3,H.B3           ;STORE MSG B3
5570
5571 026216 012765 100000 000000  MOV     #CCLR,RKCS1(R5)
5572 026224 013765 001222 000010  MOV     $UNIT,RKCS2(R5)
5573 026232 012765 000002 000026  MOV     #2,RKMR1(R5)         ;SELECT WORD 2
5574 026240 004737 026372          JSR     PC,GSTAT2
5575 026244 104117          ERROR    117              ;RDY NOT SET BY END OF SELECT DRV CMD
5576 026246 013737 005366 005420  MOV     HMR2,H.A2           ;STORE MSG A2
5577 026254 013737 005370 005422  MOV     HMR3,H.B2           ;STORE MSG B2
5578

```

```

5579 026262 012765 100000 000000 MOV #CCLR,RKCS1(R5)
5580 026270 013765 001222 000010 MOV $UNIT,RKCS2(R5)
5581 026276 012765 000001 000026 MOV #1,RKMR1(R5) ;SELECT WORD 1
5582 026304 004737 026372 JSR PC,GSTAT2
5583 026310 104117 ERROR 117 ;RDY NOT SET BY END OF SELECT DRV CMD
5584 026312 013737 005366 005414 MOV HMR2,H.A1 ;STORE MSG A1
5585 026320 013737 005370 005416 MOV HMR3,H.B1 ;STORE MSG B1
5586
5587 026326 012765 100000 000000 MOV #CCLR,RKCS1(R5)
5588 026334 013765 001222 000010 MOV $UNIT,RKCS2(R5)
5589 026342 004737 026372 JSR PC,GSTAT2
5590 026346 104117 ERROR 117 ;RDY NOT SET BY END OF SEL DRV CMD
5591 026350 013737 005366 005410 MOV HMR2,H.A0 ;STORE MSG A0
5592 026356 013737 005370 005412 MOV HMR3,H.B0 ;STORE MSG B0
5593
5594 026364 012637 005376 MOV (SP)+,TEMP1 ;RESTORE TEMP1
5595 026370 000207 RTS PC
5596
5597
5598 026372 012737 000001 005340 GSTAT2: MOV #SELDRV,HCS1
5599 026400 053737 001170 005340 BIS $TMP4,HCS1 ;ADD CDT IF RK07
5600 026406 013765 005340 000000 MOV HCS1,RKCS1(R5) ;GET STATUS
5601 026414 013737 001424 005376 MOV T10,TEMP1
5602 026422 004737 024610 JSR PC,FRDY1 ;FIND CONTR RDY & STORE DRIVE REGS ONLY
5603 026426 000207 RTS PC ;RET HERE IF NOT RDY
5604 026430 062716 000002 ADD #2,(SP) ;RET HERE IF OK
5605 026434 000207 RTS PC
5606
5607 ;THIS ROUTINE DOES A SUBSYSTEM CLEAR & WAITS FOR CONTROLLER READY
5608 ;IF RDY IS NOT RECEIVED BY THE END OF THE TIMEOUT, AN ERROR IS FLAGGED.
5609 ;THE ROUTINE THEN GETS CURRENT STATUS & CHECKS FOR CONTROLLER ERROR (CERR)
5610 ;RETURN IF CERR SET
5611 ;RETURN +2 IF CERR CLEAR
5612
5613 026436 012765 000040 000010 SUBCLR: MOV #SCLR,RKCS2(R5) ;SUBSYS CLEAR
5614 026444 013737 001424 005376 MOV T10,TEMP1
5615 026452 004737 024542 JSR PC,FRDY ;FIND RDY
5616 026456 104120 ERROR 120 ;RDY NOT SET BY END OF SCLR
5617 026460 013765 001222 000010 MOV $UNIT,RKCS2(R5) ;CURRENT DRIVE #
5618 026466 005065 000026 CLR RKMR1(R5) ;SELECT WORD 0
5619 026472 004737 026106 JSR PC,GSTAT ;GET STATUS
5620 026476 032737 100000 005340 BIT #CERR,HCS1 ;CHECK FOR CONT ERROR
5621 026504 001401 BEQ 1$
5622 026506 000207 RTS PC
5623 026510 062716 000002 1$: ADD #2,(SP) ;SKIP OVER ERROR
5624 026514 000207 RTS PC
5625
5626
5627 ;READ THE SECTOR COUNT IN RKMR3, RIGHT JUSTIFY IT & STORE IT IN 'SECTOR'
5628
5629 026516 012765 000003 000026 RDSEC: MOV #3,RKMR1(R5) ;WORD 3
5630 026524 004737 026106 JSR PC,GSTAT
5631 026530 013737 005370 001422 MOV HMR3,SECTOR
5632 026536 042737 177017 001422 BIC #C<M.SECT>,SECTOR
5633 026544 006237 001422 ASR SECTOR ;RIGHT JUSTIFY
5634 026550 006237 001422 ASR SECTOR ;SECTOR
    
```



```

5635 026554 006237 001422          ASR          SECTOR          :INFO
5636 026560 006237 001422          ASR          SECTOR
5637 026564 000207                    RTS          PC
5638
5639          ;:READ THE CYL DIFF/OFFSET IN RKMR2, RIGHT JUSTIFY IT & STORE IT IN 'CYLDIF'
5640
5641 026566 012765 000002 000026 RDCYLD: MOV      #2,RKMR1(R5)  ;WORD 2
5642 026574 004737 026106          JSR          PC,GSTAT
5643 026600 013737 005366 001376          MOV          HMR2,CYLDIF
5644
5645 026606 043737 012660 001376          BIC          MASK1,CYLDIF
5646 026614 006237 001376          ASR          CYLDIF          ;RIGHT JUSTIFY
5647 026620 006237 001376          ASR          CYLDIF          ;CYL DIFF/OFFSET
5648 026624 006237 001376          ASR          CYLDIF          ;INFO
5649 026630 006237 001376          ASR          CYLDIF
5650 026634 023737 001376 012656          CMP          CYLDIF,MASK      ;CHK TO SEE IF RET IN COMPL. FORM
5651 026642 001002                    BNE          1$              ;BR IF NOT
5652 026644 005037 001376          CLR          CYLDIF          ;CLR IF YES
5653 026650 000207          1$:      RTS          PC
5654
5655          ;:READ THE CYL ADDR IN RKMR3, RIGHT JUSTIFY IT & STORE IT IN 'CYLADD'
5656
5657 026652 012765 000002 000026 RDCYLA: MOV      #2,RKMR1(R5)  ;WORD 2
5658 026660 004737 026106          JSR          PC,GSTAT
5659 026664 013737 005370 001400          MOV          HMR3,CYLADD
5660 026672 043737 012660 001400          BIC          MASK1,CYLADD
5661 026700 006237 001400          ASR          CYLADD          ;RIGHT JUSTIFY
5662 026704 006237 001400          ASR          CYLADD          ;CYL ADDR
5663 026710 006237 001400          ASR          CYLADD          ;INFO
5664 026714 006237 001400          ASR          CYLADD
5665 026720 000207          RTS          PC
5666
5667          ;:READ THE CYL DIFF/OFFSET IN H.A2, RIGHT JUSTIFY IT & STORE IT IN 'CYLDIF'
5668
5669 026722 013737 005420 001376 RCYLD:  MOV      H.A2,CYLDIF
5670 026730 043737 012660 001376          BIC          MASK1,CYLDIF ;CLEAR UNWANTED INFO
5671 026736 006237 001376          ASR          CYLDIF ;RIGHT JUSTIFY
5672 026742 006237 001376          ASR          CYLDIF
5673 026746 006237 001376          ASR          CYLDIF
5674 026752 006237 001376          ASR          CYLDIF
5675 026756 023737 001376 012656          CMP          CYLDIF,MASK      ;CHK TO SEE IF RET IN COMPL. FORM
5676 026764 001002                    BNE          1$              ;BR IF NO
5677 026766 005037 001376          CLR          CYLDIF          ;ELSE CLEAR
5678 026772 000207          1$:      RTS          PC
5679
5680          ;:READ THE CYL ADDR IN H.B2, RIGHT JUSTIFY IT & STORE IT IN 'CYLADD'
5681
5682 026774 013737 005422 001400 RCYLA:  MOV      H.B2,CYLADD
5683 027002 043737 012660 001400          BIC          MASK1,CYLADD ;CLEAR UNWANTED INFO
5684 027010 006237 001400          ASR          CYLADD          ;RIGHT JUSTIFY
5685 027014 006237 001400          ASR          CYLADD
5686 027020 006237 001400          ASR          CYLADD
5687 027024 006237 001400          ASR          CYLADD
5688 027030 000207          RTS          PC
5689
5690          ;:READ THE SECTOR COUNT IN H.B3, RIGHT JUSTIFY IT & STORE IT IN 'SECTOR'
    
```

```

5691
5692 027032 013737 005426 001422 RSEC:  MOV   H.B3,SECTOR
5693 027040 042737 177017 001422      BIC   #^C<M.SECT>,SECTOR ;CLEAR UNWANTED INFO
5694 027046 006237 001422      ASR   SECTOR             ;RIGHT JUSTIFY
5695 027052 006237 001422      ASR   SECTOR
5696 027056 006237 001422      ASR   SECTOR
5697 027062 006237 001422      ASR   SECTOR
5698 027066 000207      RTS   PC
5699
5700      ;:READ THE HEAD ADDR IN H.B3, RIGHT IT & STORE IT IN 'HEADA'
5701
5702 027070 013737 005426 001444 RHEAD: MOV   H.B3,HEADA
5703 027076 042737 170777 001444      BIC   #^C<M.HEAD>,HEADA ;CLEAR UNWANTED INFO
5704 027104 006237 001444      ASR   HEADA             ;RIGHT JUSTIFY IT
5705 027110 000337 001444      SWAB  HEADA
5706 027114 000207      RTS   PC
5707
5708      ;:FIND SECTOR 17
5709      ;:RETURN IF NOT FOUND
5710      ;:RETURN +4 IF FOUND
5711
5712 027116 013737 001430 005376 FSEC17: MOV   T5000,TEMP1 ;SETUP TIMEOUT
5713 027124 004737 026516      1$:  JSR   PC,RDSEC        ;READ SECTOR
5714 027130 023727 001422 000021      CMP   SECTOR,#17.      ;TEST FOR SECTOR 17
5715 027136 001014      BNE   2$                ;BR IF NOT 17
5716
5717 027140 004737 026516      JSR   PC,RDSEC
5718 027144 023727 001422 000021      CMP   SECTOR,#17.
5719 027152 001412      BEQ   3$                ;BR IF READ SAME TWICE
5720 027154 004737 026516      JSR   PC,RDSEC        ;ELSE TRY 1 MORE TIME
5721 027160 023727 001422 000021      CMP   SECTOR,#17.
5722 027166 001404      BEQ   3$                ;BR IF 17
5723
5724 027170 005337 005376      2$:  DEC   TEMP1
5725 027174 001353      BNE   1$                ;TRY AGAIN
5726 027176 000207      RTS   PC
5727
5728 027200 062716 000004      3$:  ADD   #4,(SP)          ;SKIP OVER ERROR
5729 027204 000207      RTS   PC
5730
5731      ;:FIND DESIRED CYL DIFF
5732      ;:RETURN IF NOT FOUND
5733      ;:RETURN+6 IF FOUND
5734
5735
5736 027206 013737 001430 005376 FCYL:  MOV   T5000,TEMP1 ;SETUP TIMEOUT
5737 027214 004737 026566      1$:  JSR   PC,RDCYLD
5738 027220 023737 001376 005400      CMP   CYLDIF,TEMP2    ;TEST FOR CYL DIFF
5739 027226 001014      BNE   2$                ;BR IF NOT FOUND
5740
5741 027230 004737 026566      JSR   PC,RDCYLD
5742 027234 023737 001376 005400      CMP   CYLDIF,TEMP2
5743 027242 001412      BEQ   3$                ;BR IF READ SAME TWICE
5744 027244 004737 026566      JSR   PC,RDCYLD        ;ELSE TRY 1 MORE TIME
5745 027250 023737 001376 005400      CMP   CYLDIF,TEMP2
5746 027256 001404      BEQ   3$

```



```

5747
5748 027260 005337 005376      2$:  DEC    TEMP1
5749 027264 001353              BNE    1$          ;TRY AGAIN
5750 027266 000207              RTS    PC
5751
5752 027270 062716 000006      3$:  ADD    #6,(SP)   ;SKIP OVER ERROR
5753 027274 000207              RTS    PC
5754
5755
5756      ;ROUTINE TO FIND HEADS HOME IN RKMR2 WORD 1 BEFORE SPECIFIED DELAY
5757      ;ENTER WITH TIME IN SECONDS IN TEMP2
5758      ;RETURN IF NOT FOUND
5759      ;RETURN+2 IF FOUND - SKIP OVER ERROR
5760
5761 027276 012737 177777 005376  FHDHM: MOV    #-1,TEMP1      ;ALL 1'S
5762 027304 012765 000001 000026      MOV    #1,RKMR1(R5)    ;WORD 1
5763 027312 004737 026106              JSR    PC,GSTAT
5764 027316 032737 000040 005366      BIT    #D.HDHM,HMR2
5765 027324 001007              BNE    2$
5766 027326 005337 005376      DEC    TEMP1
5767 027332 001367              BNE    1$
5768
5769 027334 005337 005400              DEC    TEMP2
5770 027340 001356              BNE    FHDHM
5771 027342 000207              RTS    PC
5772 027344 062716 000002      2$:  ADD    #2,(SP)   ;SKIP OVER ERROR
5773 027350 000207              RTS    PC
5774
5775      ;ROUTINE TO FIND LOAD HEADS IN RKMR2 WORD 1 BEFORE 5MS
5776      ;RETURN IF NOT FOUND
5777      ;RETURN+2 IF FOUND: SKIP OVER ERROR
5778
5779 027352 012737 000372 005376  FLOAD: MOV    #250,TEMP1
5780 027360 012765 000001 000026      MOV    #1,RKMR1(R5)    ;WORD 1
5781 027366 004737 026106              JSR    PC,GSTAT
5782 027372 032737 010000 005366      BIT    #D.LOAD,HMR2
5783 027400 001004              BNE    2$
5784 027402 005337 005376      DEC    TEMP1
5785 027406 001367              BNE    1$
5786 027410 000207              RTS    PC
5787 027412 062716 000002      2$:  ADD    #2,(SP)   ;SKIP OVER ERROR
5788 027416 000207              RTS    PC
5789
5790      ;FILL HEADER TABLE WITH 66 WORDS OF VALID HEADERS
5791      ;ENTER WITH CYL # IN 'CALADD'
5792      ;ENTER WITH HEAD # IN 'HEAD'
5793      ;ENTER WITH FORMAT IN 'FORMAT'
5794
5795 027420 010046      FHDTAB: MOV    R0,-(SP)      ;SAV R0
5796 027422 010146      MOV    R1,-(SP)      ;SAV R1
5797 027424 012700 001506      MOV    #HDTAB,R0      ;HEADER WORD TABLE ADDR
5798 027430 005001              CLR    R1              ;SECTOR COUNTER
5799 027432 013737 001442 001446      MOV    HEAD,HD1
5800 027440 006337 001446      ASL   HD1
5801 027444 006337 001446      ASL   HD1
5802 027450 006337 001446      ASL   HD1
    
```

```

5803 027454 006337 001446      ASL    HD1
5804 027460 006337 001446      ASL    HD1                ;SETUP HEAD # FOR WORD 2 OF HEADER
5805 027464 013737 001450 001452  MOV    FORMAT,FMT1
5806 027472 000337 001452      SWAB   FMT1
5807 027476 006337 001452      ASL    FMT1                ;SETUP FORMAT FOR WORD 2 OF HEADER
5808
5809 027502 013720 001402 1$:   MOV    CALADD,(R0)+        ;HEADER WORD 1-CYL ADDR
5810 027506 010110      MOV    R1,(R0)            ;HEADER WORD 2-SECTOR NO
5811 027510 053710 001446      BIS    HD1,(R0)           ;
5812 027514 053710 001452      BIS    FMT1,(R0)         ;
5813 027520 004737 027600      JSR    PC,SECFLG         ;GET SECTOR FLAGS
5814
5815 027524 013737 001402 005376  MOV    CALADD,TEMP1
5816 027532 011037 005400      MOV    (R0),TEMP2
5817 027536 043737 001402 005400  BIC    CALADD,TEMP2
5818 027544 042037 005376      BIC    (R0)+,TEMP1
5819 027550 053737 005376 005400  BIS    TEMP1,TEMP2
5820 027556 013720 005400      MOV    TEMP2,(R0)+        ;HEADER WORD 3-HEADER CHECK
5821
5822 027562 005201      INC    R1                ;SECTOR CTR
5823 027564 020127 000026      CMP    R1,#22.           ;ALL 22 SECTORS DONE? (66 WORDS)
5824 027570 001344      BNE    1$                ;BR IF NO
5825
5826 027572 012601      MOV    (SP)+,R1          ;RESTOR R1
5827 027574 012600      MOV    (SP)+,R0          ;RESTOR R0
5828 027576 00C207      RTS    PC
5829

```

```

; THIS ROUTINE GETS INFORMATION FROM THE BAD SECTOR TABLE FILLED BY A PREVIOUS
; TEST & SETS BITS 14 & 15 APPROPRIATLY.

```

```

5830
5831
5832
5833 027600 010246      SECFLG: MOV    R2,-(SP)        ;SAVE R2
5834 027602 005737 001450      TST    FORMAT
5835 027606 001016      BNE    1$                ;BR IF 20 SECTOR FORMAT
5836 027610 012702 002332      MOV    #BSE22H+8.,R2
5837 027614 004737 027650      JSR    PC,FLGTST        ;GET HARDWARE DETECTED FLAG
5838 027620 052710 100000      BIS    #BIT15,(R0)      ;RETURN HERE IF GOOD SECTOR
5839
5840 027624 012702 003332      MOV    #BSE22S+8.,R2   ;ELSE RETURN HERE
5841 027630 004737 027650      JSR    PC,FLGTST        ;GET SOFTWARE DETECTED FLAG
5842 027634 052710 040000      BIS    #BIT14,(R0)     ;RETURN HERE IF GOOD SECTOR
5843
5844 027640 012602      MOV    (SP)+,R2        ;ELSE RETURN HERE
5845 027642 000207      RTS    PC
5846
5847 027644 012602 1$:   MOV    (SP)+,R2        ;RESTORE R2
5848 027646 000207      RTS    PC
5849

```

```

; THIS ROUTINE DOES THE ACTUAL SCANNING OF THE BAD SECTOR TABLES.
; ENTER WITH THE ADDRESS OF TABLE (BSE22H, BSE22S, ETC.) IN TEMP1
; RETURN IF NO COMPARE
; RETURN+4 IF COMPARE

```

```

5850
5851
5852
5853
5854
5855
5856 027650 010346      FLGTST: MOV    R3,-(SP)   ;SAVE R3
5857
5858 027652 021227 177777 1$:   CMP    (R2),#-1        ;SEE IF ALL 1'S

```



```
5859 027656 001002      BNE      2$      :BR IF NO
5860 027660 012603      MOV      (SP)+,R3 :RESTORE R3
5861 027662 000207      RTS      PC
5862
5863 027664 022237 001402  2$:      CMP      (R2)+,CALADD :SEE IF=CYL # & ADR PTR TO TRK/SECTOR WORD
5864 027670 001403      BEQ      3$
5865 027672 062702 000002      ADD      #2,R2    :GO TO NEXT CYL WORD IN TABLE
5866 027676 000765      BR       1$
5867
5868 027700 013703 001442  3$:      MOV      HEAD,R3   :GET HEAD # FROM FHDTAB ROUTINE
5869 027704 000303      SWAB    R3
5870 027706 050103      BIS     R1,R3    :ADD SECTOR # FROM FHDTAB ROUTINE
5871 027710 022203      CMP     (R2)+,R3 :SEE IF SECTOR/HEAD COMPARE
5872                          :& INCR PTR TO NEXT CYL WORD
5873 027712 001401      BEQ     4$      :BR IF COMPARE
5874 027714 000756      BR      1$      :ELSE TRY NEXT CYL
5875
5876 027716 012603 000004  4$:      MOV      (SP)+,R3 :RESTORE R3
5877 027720 062716      ADD     #4,(SP)  :INCREMENT RET ADDR
5878 027724 000207      RTS      PC
5879
5880
5881      :
5882      :THIS ROUTINE SORTS THE RHTAB TABLE FROM WHATEVER SECTOR IT BEGINS
5883      :WITH AND RE-WRITES THE INFO IN SRTTAB TABLE TO BEGIN WITH SECTOR 0
5884
5884 027726 010046      SORT:    MOV     R0,-(SP) :SAVE R0
5885 027730 010146      MOV     R1,-(SP) :SAVE R1
5886 027732 004737 026516      JSR     PC,RDSEC
5887 027736 062737 000001 001422      ADD     #1,SECTOR
5888 027744 004737 030034      JSR     PC,MULT6   :MULT SECTOR BY 6
5889
5890 027750 012700 000204      MOV     #132,R0
5891 027754 163700 001422      SUB     SECTOR,R0 :R0-SECTOR TO R0 = INDEX
5892 027760 010037 001422      MOV     R0,SECTOR
5893 027764 062737 001712 001422      ADD     #RHTAB,SECTOR :SAVE INDEX
5894
5895 027772 062700 001712      ADD     #RHTAB,R0  :INDEX TO BOT HALF OF RHTAB
5896 027776 012701 002116      MOV     #SRTTAB,R1 :INDEX TO TOP HALF OF SRTTAB
5897
5898
5899 030002 012021 002116  1$:      MOV     (R0)+,(R1)+ :PUT BOTTOM OF RHTAB TO TOP OF SRTTAB
5900 030004 020027      CMP     R0,#RHTAB+132.
5901 030010 001374      BNE     1$
5902
5903 030012 012700 001712  2$:      MOV     #RHTAB,R0 :PUT TOP OF RHTAB TO BOT OF SRTTAB
5904 030016 012021      MOV     (R0)+,(R1)+
5905 030020 020037 001422      CMP     R0,SECTOR
5906 030024 001374      BNE     2$
5907
5908 030026 012601      MOV     (SP)+,R1   :RESTOR R1
5909 030030 012600      MOV     (SP)+,R0   :RESTOR R0
5910 030032 000207      RTS      PC
5911
5912      :
5913      :MULT BY 6. ENTER WITH DESIRED # IN 'SECTOR'
5914      :
```

5915 030034 006337 001422
 5916 030040 013746 001422
 5917 030044 006337 001422
 5918 030050 062637 001422
 5919 030054 000207

MULT6: ASL SECTOR ;2 X SECTOR
 MOV SECTOR,-(SP)
 ASL SECTOR ;4 X SECTOR
 ADD (SP)+,SECTOR ;(4 X S)+(2 X S) = 6 X SECTOR
 RTS PC

: THIS ROUTINE IS ENTERED ONLY IF THERE IS A BSE ERROR AFTER A WRITE DATA
 : CMD. IT VERIFIES THAT THE BAD SECTOR IS LISTED IN THE BSE INFORMATION
 : CYLINDER AT CYL 410, TRACK 2.
 : RETURN IF SECTOR NOT LISTED IN BSE TABLE, ERROR CONDITION.
 : RETURN+2 IF LISTED, SKIP OVER ERROR

5929 030056 010446
 5931 030060 032737 010000 005340
 5932 030066 001014

TRUERR: MOV R4,-(SP) ;SAVE R4
 BIT #CFMT,HCS1 ;CHECK FORMAT
 BNE 3\$;BR FOR 20 SECTOR FORMAT
 ;NOTE, 20 SECTOR FORMAT NOT
 ;DONE IN THIS PROGRAM

5936 030070 012704 002332
 5937 030074 004737 030130
 5938 030100 000407
 5940 030102 012704 003332
 5941 030106 004737 030130
 5942 030112 000402

MOV #BSE22H+8.,R4
 JSR PC,TERR1 ;SEE IF ON HARDWARE DETECTED TABLE
 BR 3\$;RETURN HERE IF YES
 MOV #BSE22S+8.,R4 ;ELSE RETURN HERE
 JSR PC,TERR1 ;& SEE IF ON SOFTWARE DETECTED TABLE
 BR 3\$;RETURN HERE IF YES

5944 030114 012604
 5945 030116 000207
 5948 030120 012604
 5949 030122 062716 000002
 5950 030126 000207

1\$: MOV (SP)+,R4 ;RESTORE R4
 RTS PC ;RETURN WITHOUT JUMPING OVER ERROR
 3\$: MOV (SP)+,R4 ;RESTORE R4
 ADD #2,(SP) ;SKIP OVER ERROR ON RETURN
 RTS PC

: THIS ROUTINE DOES THE ACTUAL COMPARING OF CYLINDER, HEAD & TRACK AGAINST
 : THE BSE TABLE FOR THE ABOVE SUBROUTINE.
 : RETURN IF FOUND ON TABLE
 : RETURN+2 IF NOT FOUND

5958 030130 021427 177777
 5959 030134 001405
 5960 030136 022437 005360
 5961 030142 001405
 5962 030144 005724
 5963 030146 000770
 5965 030150 062716 000002
 5966 030154 000207
 5968 030156 022437 005350
 5969 030162 001401
 5970 030164 000761

TERR1: CMP (R4),#-1 ;SEE IF ALL 1'S
 BEQ 1\$;BR IF YES, NOT ON TABLE
 CMP (R4)+,HDC ;SEE IF CYL MATCH
 BEQ 2\$;BR IF YES
 TST (R4)+ ;ELSE ADV TO NEXT CYL WORD
 BR TERR1 ;& TRY AGAIN.
 1\$: ADD #2,(SP)
 RTS PC
 2\$: CMP (R4)+,HDA ;SEE IF SECTOR & TRACK MATCH
 BEQ 3\$;BR IF YES
 BR TERR1 ;OR TRY AGAIN


```

5971
5972 030166 000207          3$:   RTS   PC
5973
5974
5975
5976
5977
5978
5979
5980
5981 030170 005037 001412    :ROUTINE TO TURN L OR P CLOCK INTERRUPT ON
5982 030174 005737 005504    :
5983 030200 001004          :
5984 030202 012777 000100 151136 :CLKON: CLR    TIMUP
5985 030210 000207          :      TST    PCLKF
5986 030212 012777 177777 151122 1$:   BNE    1$      :BRANCH IF P-CLOCK PRESENT
5987 030220 012777 000135 151112 :      MOV    #100,@LKS  :L-CLOCK, ENABLE INT
5988 030226 000207          :      RTS    PC
5989
5990
5991
5992 030230 005037 001412    :KW11-L & KW11-P INTERRUPT HANDLER
5993 030234 005337 001406    :
5994 030240 001010          :
5995 030242 013737 001404 001406 :CLK:  CLR    TIMUP
5996 030250 005337 001410    :      DEC    COUNT
5997 030254 001002          :      BNE    1$
5998 030256 005237 001412    :      MOV    HZ,COUNT
5999 030262 000002          :      DEC    SEC
6000
6001
6002
6003 030264 005737 005504    :      BNE    1$      :SORRY, TIME IS UP
6004 030270 001003          :      INC    TIMUP
6005 030272 005077 151050    :      RTI
6006 030276 000207          :ROUTINE TO TURN L OR P CLOCK INTERRUPT OFF
6007 030300 005077 151034    :
6008
6009
6010
6011
6012
6013
6014
6015
6016
6017
6018
6019
6020
6021
6022
6023
6024
6025
6026
6027
6028
6029
6030
6031
6032
6033
6034
6035
6036
6037
6038
6039
6040
6041
6042
6043
6044
6045
6046
6047
6048
6049
6050
6051
6052
6053
6054
6055
6056
6057
6058
6059
6060
6061
6062
6063
6064
6065
6066
6067
6068
6069
6070
6071
6072
6073
6074
6075
6076
6077
6078
6079
6080
6081
6082
6083
6084
6085
6086
6087
6088
6089
6090
6091
6092
6093
6094
6095
6096
6097
6098
6099
6100
6101
6102
6103
6104
6105
6106
6107
6108
6109
6110
6111
6112
6113
6114
6115
6116
6117
6118
6119
6120
6121
6122
6123
6124
6125
6126
6127
6128
6129
6130
6131
6132
6133
6134
6135
6136
6137
6138
6139
6140
6141
6142
6143
6144
6145
6146
6147
6148
6149
6150
6151
6152
6153
6154
6155
6156
6157
6158
6159
6160
6161
6162
6163
6164
6165
6166
6167
6168
6169
6170
6171
6172
6173
6174
6175
6176
6177
6178
6179
6180
6181
6182
6183
6184
6185
6186
6187
6188
6189
6190
6191
6192
6193
6194
6195
6196
6197
6198
6199
6200
6201
6202
6203
6204
6205
6206
6207
6208
6209
6210
6211
6212
6213
6214
6215
6216
6217
6218
6219
6220
6221
6222
6223
6224
6225
6226
6227
6228
6229
6230
6231
6232
6233
6234
6235
6236
6237
6238
6239
6240
6241
6242
6243
6244
6245
6246
6247
6248
6249
6250
6251
6252
6253
6254
6255
6256
6257
6258
6259
6260
6261
6262
6263
6264
6265
6266
6267
6268
6269
6270
6271
6272
6273
6274
6275
6276
6277
6278
6279
6280
6281
6282
6283
6284
6285
6286
6287
6288
6289
6290
6291
6292
6293
6294
6295
6296
6297
6298
6299
6300
6301
6302
6303
6304
6305
6306
6307
6308
6309
6310
6311
6312
6313
6314
6315
6316
6317
6318
6319
6320
6321
6322
6323
6324
6325
6326
6327
6328
6329
6330
6331
6332
6333
6334
6335
6336
6337
6338
6339
6340
6341
6342
6343
6344
6345
6346
6347
6348
6349
6350
6351
6352
6353
6354
6355
6356
6357
6358
6359
6360
6361
6362
6363
6364
6365
6366
6367
6368
6369
6370
6371
6372
6373
6374
6375
6376
6377
6378
6379
6380
6381
6382
6383
6384
6385
6386
6387
6388
6389
6390
6391
6392
6393
6394
6395
6396
6397
6398
6399
6400
6401
6402
6403
6404
6405
6406
6407
6408
6409
6410
6411
6412
6413
6414
6415
6416
6417
6418
6419
6420
6421
6422
6423
6424
6425
6426
6427
6428
6429
6430
6431
6432
6433
6434
6435
6436
6437
6438
6439
6440
6441
6442
6443
6444
6445
6446
6447
6448
6449
6450
6451
6452
6453
6454
6455
6456
6457
6458
6459
6460
6461
6462
6463
6464
6465
6466
6467
6468
6469
6470
6471
6472
6473
6474
6475
6476
6477
6478
6479
6480
6481
6482
6483
6484
6485
6486
6487
6488
6489
6490
6491
6492
6493
6494
6495
6496
6497
6498
6499
6500
6501
6502
6503
6504
6505
6506
6507
6508
6509
6510
6511
6512
6513
6514
6515
6516
6517
6518
6519
6520
6521
6522
6523
6524
6525
6526
6527
6528
6529
6530
6531
6532
6533
6534
6535
6536
6537
6538
6539
6540
6541
6542
6543
6544
6545
6546
6547
6548
6549
6550
6551
6552
6553
6554
6555
6556
6557
6558
6559
6560
6561
6562
6563
6564
6565
6566
6567
6568
6569
6570
6571
6572
6573
6574
6575
6576
6577
6578
6579
6580
6581
6582
6583
6584
6585
6586
6587
6588
6589
6590
6591
6592
6593
6594
6595
6596
6597
6598
6599
6600
6601
6602
6603
6604
6605
6606
6607
6608
6609
6610
6611
6612
6613
6614
6615
6616
6617
6618
6619
6620
6621
6622
6623
6624
6625
6626
6627
6628
6629
6630
6631
6632
6633
6634
6635
6636
6637
6638
6639
6640
6641
6642
6643
6644
6645
6646
6647
6648
6649
6650
6651
6652
6653
6654
6655
6656
6657
6658
6659
6660
6661
6662
6663
6664
6665
6666
6667
6668
6669
6670
6671
6672
6673
6674
6675
6676
6677
6678
6679
6680
6681
6682
6683
6684
6685
6686
6687
6688
6689
6690
6691
6692
6693
6694
6695
6696
6697
6698
6699
6700
6701
6702
6703
6704
6705
6706
6707
6708
6709
6710
6711
6712
6713
6714
6715
6716
6717
6718
6719
6720
6721
6722
6723
6724
6725
6726
6727
6728
6729
6730
6731
6732
6733
6734
6735
6736
6737
6738
6739
6740
6741
6742
6743
6744
6745
6746
6747
6748
6749
6750
6751
6752
6753
6754
6755
6756
6757
6758
6759
6760
6761
6762
6763
6764
6765
6766
6767
6768
6769
6770
6771
6772
6773
6774
6775
6776
6777
6778
6779
6780
6781
6782
6783
6784
6785
6786
6787
6788
6789
6790
6791
6792
6793
6794
6795
6796
6797
6798
6799
6800
6801
6802
6803
6804
6805
6806
6807
6808
6809
6810
6811
6812
6813
6814
6815
6816
6817
6818
6819
6820
6821
6822
6823
6824
6825
6826
6827
6828
6829
6830
6831
6832
6833
6834
6835
6836
6837
6838
6839
6840
6841
6842
6843
6844
6845
6846
6847
6848
6849
6850
6851
6852
6853
6854
6855
6856
6857
6858
6859
6860
6861
6862
6863
6864
6865
6866
6867
6868
6869
6870
6871
6872
6873
6874
6875
6876
6877
6878
6879
6880
6881
6882
6883
6884
6885
6886
6887
6888
6889
6890
6891
6892
6893
6894
6895
6896
6897
6898
6899
6900
6901
6902
6903
6904
6905
6906
6907
6908
6909
6910
6911
6912
6913
6914
6915
6916
6917
6918
6919
6920
6921
6922
6923
6924
6925
6926
6927
6928
6929
6930
6931
6932
6933
6934
6935
6936
6937
6938
6939
6940
6941
6942
6943
6944
6945
6946
6947
6948
6949
6950
6951
6952
6953
6954
6955
6956
6957
6958
6959
6960
6961
6962
6963
6964
6965
6966
6967
6968
6969
6970
6971
6972
6973
6974
6975
6976
6977
6978
6979
6980
6981
6982
6983
6984
6985
6986
6987
6988
6989
6990
6991
6992
6993
6994
6995
6996
6997
6998
6999
7000
7001
7002
7003
7004
7005
7006
7007
7008
7009
7010
7011
7012
7013
7014
7015
7016
7017
7018
7019
7020
7021
7022
7023
7024
7025
7026
7027
7028
7029
7030
7031
7032
7033
7034
7035
7036
7037
7038
7039
7040
7041
7042
7043
7044
7045
7046
7047
7048
7049
7050
7051
7052
7053
7054
7055
7056
7057
7058
7059
7060
7061
7062
7063
7064
7065
7066
7067
7068
7069
7070
7071
7072
7073
7074
7075
7076
7077
7078
7079
7080
7081
7082
7083
7084
7085
7086
7087
7088
7089
7090
7091
7092
7093
7094
7095
7096
7097
7098
7099
7100
7101
7102
7103
7104
7105
7106
7107
7108
7109
7110
7111
7112
7113
7114
7115
7116
7117
7118
7119
7120
7121
7122
7123
7124
7125
7126
7127
7128
7129
7130
7131
7132
7133
7134
7135
7136
7137
7138
7139
7140
7141
7142
7143
7144
7145
7146
7147
7148
7149
7150
7151
7152
7153
7154
7155
7156
7157
7158
7159
7160
7161
7162
7163
7164
7165
7166
7167
7168
7169
7170
7171
7172
7173
7174
7175
7176
7177
7178
7179
7180
7181
7182
7183
7184
7185
7186
7187
7188
7189
7190
7191
7192
7193
7194
7195
7196
7197
7198
7199
7200
7201
7202
7203
7204
7205
7206
7207
7208
7209
7210
7211
7212
7213
7214
7215
7216
7217
7218
7219
7220
7221
7222
7223
7224
7225
7226
7227
7228
7229
7230
7231
7232
7233
7234
7235
7236
7237
7238
7239
7240
7241
7242
7243
7244
7245
7246
7247
7248
7249
7250
7251
7252
7253
7254
7255
7256
7257
7258
7259
7260
7261
7262
7263
7264
7265
7266
7267
7268
7269
7270
7271
7272
7273
7274
7275
7276
7277
7278
7279
7280
7281
7282
7283
7284
7285
7286
7287
7288
7289
7290
7291
7292
7293
7294
7295
7296
7297
7298
7299
7300
7301
7302
7303
7304
7305
7306
7307
7308
7309
7310
7311
7312
7313
7314
7315
7316
7317
7318
7319
7320
7321
7322
7323
7324
7325
7326
7327
7328
7329
7330
7331
7332
7333
7334
7335
7336
7337
7338
7339
7340
7341
7342
7343
7344
7345
7346
7347
7348
7349
7350
7351
7352
7353
7354
7355
7356
7357
7358
7359
7360
7361
7362
7363
7364
7365
7366
7367
7368
7369
7370
7371
7372
7373
7374
7375
7376
7377
7378
7379
7380
7381
7382
7383
7384
7385
7386
7387
7388
7389
7390
7391
7392
7393
7394
7395
7396
7397
7398
7399
7400
7401
7402
7403
7404
7405
7406
7407
7408
7409
7410
7411
7412
7413
7414
7415
7416
7417
7418
7419
7420
7421
7422
7423
7424
7425
7426
7427
7428
7429
7430
7431
7432
7433
7434
7435
7436
7437
7438
7439
7440
7441
7442
7443
7444
7445
7446
7447
7448
7449
7450
7451
7452
7453
7454
7455
7456
7457
7458
7459
7460
7461
7462
7463
7464
7465
7466
7467
7468
7469
7470
7471
7472
7473
7474
7475
7476
7477
7478
7479
7480
7481
7482
7483
7484
7485
7486
7487
7488
7489
7490
7491
7492
7493
7494
7495
7496
7497
7498
7499
7500
7501
7502
7503
7504
7505
7506
7507
7508
7509
7510
7511
7512
7513
7514
7515
7516
7517
7518
7519
7520
7521
7522
7523
7524
7525
7526
7527
7528
7529
7530
7531
7532
7533
7534
7535
7536
7537
7538
7539
7540
7541
7542
7543
7544
7545
7546
7547
7548
7549
7550
7551
7552
7553
7554
7555
7556
7557
7558
7559
7560
7561
7562
7563
7564
7565
7566
7567
7568
7569
7570
7571
7572
7573
7574
7575
7576
7577
7578
7579
7580
7581
7582
7583
7584
7585
7586
7587
7588
7589
7590
7591
7592
7593
7594
7595
7596
7597
7598
7599
7600
7601
7602
7603
7604
7605
7606
7607
7608
7609
7610
7611
7612
7613
7614
7615
7616
7617
7618
7619
7620
7621
7622
7623
7624
7625
7626
7627
7628
7629
7630
7631
7632
7633
7634
7635
7636
7637
7638
7639
7640
7641
7642
7643
7644
7645
7646
7647
7648
7649
7650
7651
7652
7653
7654
7655
7656
7657
7658
7659
7660
7661
7662
7663
7664
7665
7666
7667
7668
7669
7670
7671
7672
7673
7674
7675
7676
7677
7678
7679
7680
7681
7682
7683
7684
7685
7686
7687
7688
7689
7690
7691
7692
7693
7694
7695
7696
7697
7698
7699
7700
7701
7702
7703
7704
7705
7706
7707
7708
7709
7710
7711
7712
7713
7714
7715
7716
7717
7718
7719
7720
7721
7722
7723
7724
7725
7726
7727
7728
7729
7730
7731
7732
7733
7734
7735
7736
7737
7738
7739
7740
7741
7742
7743
7744
7745
7746
7747
7748
7749
7750
7751
7752
7753
7754
7755
7756
7757
7758
7759
7760
7761
7762
7763
7764
7765
7766
7767
7768
7769
7770
7771
7772
7773
7774
7775
7776
7777
7778
7779
7780
7781
7782
7783
7784
7785
7786
7787
7788
7789
7790
7791
7792
7793
7794
7795
7796
7797
7798
7799
7800
7801
7802
7803
7804
7805
7806
7807
7808
7809
7810
7811
7812
7813
7814
7815
7816
7817
7818
7819
7820
7821
7822
7823
7824
7825
7826
7827
7828
7829
7830
7831
7832
7833
7834
7835
7836
7837
7838
7839
7840
7841
7842
7843
7844
7845
7846
7847
7848
7849
7850
7851
7852
7853
7854
7855
7856
7857
7858
7859
7860
7861
7862
7863
7864
7865
7866
7867
7868
7869
7870
7871
7872
7873
7874
7875
7876
7877
7878
7879
7880
7881
7882
7883
7884
7885
7886
7887
7888
7889
7890
7891
7892
7893
7894
7895
7896
7897
7898
7899
7900
7901
7902
7903
7904
7905
7906
7907
7908
7909
7910
7911
7912
7913
7914
7915
7916
7917
7918
7919
7920
7921
7922
7923
7924
7925
7926
7927
7928
7929
7930
7931
7932
7933
7934
7935
7936
7937
7938
7939
7940
7941
7942
7943
7944
7945
7946
7947
7948
7949
7950
7951
7952
7953
7954
7955
7956
7957
7958
7959
7960
7961
7962
7963
7964
7965
7966
7967
7968
7969
7970
7971
7972
7973
7974
7975
7976
7977
7978
7979
7980
7981
7982
7983
7984
7985
7986
7987
7988
7989
7990
7991
7992
7993
7994
7995
7996
7997
7998
7999
8000
8001
8002
8003
8004
8005
8006
8007
8008
8009
8010
8011
8012
8013
8014
8015
8016
8017
8018
8019
8020
8021
8022
8023
8024
8025
8026
8027
8028
8029
8030
8031
8032
8033
8034
8035
8036
8037
8038
8039
8040
8041
8042
8043
8044
8045
8046
8047
8048
8049
8050
8051
8052
8053
8054
8055
8056
8057
8058
8059
8060
8061
8062
8063
8064
8065
8066
8067
8068
8069
8070
8071
8072
8073
8074
8075
8076
8077
8078
8079
8080
8081
8082
8083
8084
8085
8086
8087
8088
8089
8090
8091
8092
8093
8094
8095
8096
8097
8098
8099
8100
8101
8102
8103
8104
8105
8106
8107
8108
8109
8110
8111
8112
8113
8114
8115
8116
8117
8118
8119
8120
8121
8122
8123
8124
8125
8126
8127
8128
8129
8130
8131
8132
8133
8134
8135
8136
8137
8138
8139
8140
8141
8142
8143
8144
8145
8146
8147
8148
8149
8150
8151
8152
8153
8154
8155
8156
8157
8158
8159
8160
8161
8162
8163
8164
8165
8166
8167
8168
8169
8170
8171
8172
8173
8174
8175
8176
8177
8178
8179
8180
8181
8182
8183
8184
8185
8186
8187
8188
8189
8190
8191
8192
8193
8194
8195
8196
8197
8198
8199
8200
8201
8202
8203
8204
8205
8206
8207
8208
8209
8210
8211
8212
8213
8214
8215
8216
8217
8218
8219
8220
8221
8222
8223
8224
8225
8226
8227
8228
8229
8230
8231
8232
8233
8234
8235
8236
8237
8238
8239
8240
8241
8242
8243
8244
8245
8246
8247
8248
8249
8250
8251
8252
8253
8254
8255
8256
8257
8258
8259
8260
8261
8262
8263
8264
8265
8266
8267
8268
8269
8270
8271
8272
8273
8274
8275
8276
8277
8278
```

```

6008 030304 000207          RTS    PC
6009
6010
6011      ; THIS ROUTINE GENERATES PARITY FOR THE EXPECTED MESSAGES
6012      ; ENTER WITH THE EXPECTED WORD IN TEMP1
6013      ; TEMP1 IS ROTATED LEFT 17 TIMES. EACH TIME THE CARRY BIT IS SET,
6014      ; R1 IS INCREMENTED. AT THE END OF 17 ROTATES ( TEMP1 BACK TO ORIG),
6015      ; R1 BIT 0 IS EXAMINED. IF IT IS SET, INDICATING AN ODD # OF 1'S,
6016      ; THE PARITY BIT IS NOT SET IN B
6017      ; IF IT IS NOT SET, INDICATING AN EVEN # OF 1'S ,THE PARITY BIT IS
6018      ; SET IN TEMP1
6019
6020 030306 010046          SBPAR:  MOV    R0,-(SP)      ;SAVE R0
6021 030310 010146          MOV    R1,-(SP)      ;SAVE R1
6022 030312 012700 000021  MOV    #17,R0       ;SHIFT COUNTER
6023 030316 005001          CLR    R1             ;COUNT # OF 1'S IN TEMP1
6024 030320 000241          CLC                    ;CLEAR CARRY
6025
6026 030322 006137 005376  1$:    ROL    TEMP1
6027 030326 103001          BCC    2$           ;BR IF CARRY CLEAR
6028 030330 005201          INC    R1             ;COUNT # OF 1'S
6029 030332 005300          2$:    DEC    R0             ;SHIFT COUNTER
6030 030334 001372          BNE    1$
6031
6032 030336 032701 000001  BIT    #BIT0,R1
6033 030342 001003          BNE    3$           ;BR IF ODD # IN R0

```



```

6034 030344 052737 100000 005376      BIS      #M.PAR,TEMP1    ;SET PARITY BIT
6035 030352 012601      3$:     MOV      (SP)+,R1    ;RESTORE R1
6036 030354 012600      MOV      (SP)+,R0    ;RESTORE R0
6037 030356 000207      RTS      PC
6038
6039
6040      ;ROUTINE TO ENABLE LOOPING ON INTERMITTANT ERRORS
6041      ;WHEN $LPERR SET BY OTHER THAN SCOPE ROUTINE
6042      ; IE: MY LOOP MACRO
6043
6044 030360 032777 001000 150552  SCOP1$: BIT      #SW9,@SWR    ;LOOP ON ERROR?
6045 030366 001406      BEQ      1$          ;BR IF NO
6046 030370 105737 001103      TSTB    $ERFLG      ;HAD ERROR?
6047 030374 001403      BEQ      1$          ;BR IF NO
6048 030376 013716 001110      MOV      $LPERR,(SP)
6049 030402 000002      RTI
6050
6051 030404 011637 001110      1$:     MOV      (SP),$LPERR ;SET LOOP ADDR FOR TIGHT SCOPE LOOP
6052 030410 000002      RTI
6053
6054
6055      ;ROUTINE TO INPUT A 'SPACE' OR 'CONTROL-E' FROM TTY
6056      ;RETURN IF CONTROL-E
6057      ;RETURN +4 IF SPACE
6058
6059
6060
6061 030412 005777 150530  CCSP:   TST      @STKB      ;CLEAR DONE FLAG
6062 030416 104410      RDCHR    ;READ CHAR FROM TTY
6063 030420 012600      MOV      (SP)+,R0    ;GET CHAR OFF STACK
6064 030422 020027 000040      CMP      R0,#SPBAR  ;SEE IF SPACE
6065 030426 001406      BEQ      1$          ;BR IF YES.
6066
6067      CMP      R0,#5      ;SEE IF CONTROL-E
6068 030434 001405      BEQ      2$          ;BR IF YES
6069 030436 104401 040212      TYPE    ,MSG31      ;?
6070 030442 000763      BR      CCSP        ;TRY AGAIN
6071
6072 030444 062716 000004      1$:     ADD      #4,(SP)
6073 030450 000207      2$:     RTS      PC
6074
6075
6076      ;ROUTINE TO INPUT A 'SPACE' FROM TTY
6077
6078 030452 005777 150470  GETSP:  TST      @STKB      ;CLEAR DONE FLAG
6079 030456 104410      RDCHR    ;READ CHAR OFF TTY
6080 030460 012600      MOV      (SP)+,R0    ;GET CHAR OFF STACK
6081 030462 020027 000040      CMP      R0,#SPBAR  ;SEE IF SPACE
6082 030466 001403      BEQ      1$          ;EXIT IF YES
6083 030470 104401 040212      TYPE    ,MSG31      ;?
6084 030474 000766      BR      GETSP      ;TRY AGAIN
6085 030476 000207      1$:     RTS      PC
6086
6087
6088      ;THIS ROUTINE IS ENTERED BY TYPING A CONTROL-C.
6089      ;IT IS USED TO ALLOW THE OPERATOR TO HALT THE CPU WHILE INSURING

```

```

6090 ;THAT HEADS ARE LOADED & FORMATTING IS VALID BEFORE ACTUALLY HALTING
6091 ;THE CPU.
6092 ;
6093 030500 022626 STOP: CMP (SP)+,(SP)+ ;RESTORE STACK FROM INTERRUPT
6094 ;
6095 030502 004737 026436 STOP1: JSR PC,SUBCLR
6096 030506 104024 ERROR 24 ;CERR AFTER
6097 ;
6098 030510 005737 005322 TST UNLD ;SEE IF HEADS UNLOADED
6099 030514 001437 BEQ 3$ ;BR IF NO
6100 030516 005737 000042 TST 42 ;SEE IF MANUAL OR AUTO MODE
6101 030522 001403 BEQ 1$ ;BR IF MANUAL MODE
6102 030524 104401 044071 TYPE ,MSG74 ;PGM ABORT PENDING
6103 030530 000402 BR 2$
6104 030532 104401 044137 1$: TYPE ,MSG75 ;HALT PENDING
6105 030536 2$:
6106 ;
6107 030536 004737 026436 JSR PC,SUBCLR
6108 030542 104024 ERROR 24 ;CERR AFTER SCLR
6109 ;
6110 030544 032737 010000 005366 BIT #D.SPIN,HMR2 ;SEE IF SPINDLE ALREADY ON
6111 030552 001020 BNE 64$ ;BR IF YES
6112 030554 104401 040064 TYPE ,MSG29 ;PLEASE WAIT, HEADS BEING LOADED
6113 ;
6114 030560 012737 000011 005340 MOV #SRTSPL,HCS1
6115 030566 004737 024446 JSR PC,DOCMD ;DO START SPINDLE CMD & GET CONTR RDY
6116 030572 104143 ERROR 143 ;CONTR RDY NOT SET AFTER CMD
6117 ;
6118 030574 013737 001426 005400 MOV T100,TEMP2
6119 030602 004737 025056 JSR PC,FATT1 ;FIND ATTN
6120 030606 104144 ERROR 144 ;NO ATTN AFTER CMD
6121 ;
6122 030610 005037 005322 CLR UNLD
6123 030614 64$:
6124 ;
6125 030614 005737 005324 3$: TST BADHDR ;SEE IF HEADERS VALID
6126 030620 001460 BEQ 4$ ;BR IF YES
6127 030622 005237 005326 INC HPEND
6128 030626 012765 100000 000000 MOV #CCLR,RKCS1(R5)
6129 030634 013765 001222 000010 MOV $UNIT,RKCS2(R5)
6130 030642 012737 000013 005340 MOV #RECAL,HCS1
6131 030650 004737 024446 JSR PC,DOCMD ;DO RECAL CMD & GET CONTR RDY
6132 030654 104124 ERROR 124 ;RDY NOT SET AFTER RECAL CMD
6133 ;
6134 030656 012765 000001 000026 MOV #1,RKMR1(R5) ;SELECT WORD 1
6135 030664 004737 026106 JSR PC,GSTAT
6136 030670 032737 020000 005366 BIT #D.RTZ,HMR2
6137 030676 001001 BNE 65$
6138 030700 104214 ERROR 214 ;RTZ NOT SET DURING RECAL CMD
6139 030702 013737 001424 005400 65$: MOV T10,TEMP2 ;SETUP TIMEOUT
6140 030710 004737 025056 JSR PC,FATT1 ;FIND ATTN
6141 030714 104055 ERROR 55 ;NO ATTN AFTER RECAL CMD
6142 ;
6143 030716 012765 100000 000000 MOV #CCLR,RKCS1(R5)
6144 030724 013765 001222 000010 MOV $UNIT,RKCS2(R5) ;DRIVE#
6145 030732 012737 000005 005340 MOV #CLEAR,HCS1

```



```

6146 030740 004737 024446      JSR    PC,DOCMD      ;DO DRIVE CLEAR CMD & GET CONTR RDY
6147 030744 104151              ERROR  151          ;NO RDY AFTER DRIVE CLEAR CMD
6148 030746 004737 025024      JSR    PC,TSTATN    ;TEST FOR ATTN
6149 030752 000401              BR     66$          ;
6150 030754 104154              ERROR  154          ;ATTN NOT CLEARED AFTER DRIVE CLEAR CMD
6151 030756                      66$:
6152
6153
6154 030756 000137 031022      JMP    FORM          ;WRITE VALID FORMATS
6155
6156 030762 005737 000042      4$:  TST    42          ;SEE IF MANUAL OR AUTO MODE
6157 030766 001410              BEQ    5$            ;BR IF MANUAL MODE
6158 030770 104401 044174      TYPE   ,MSG76        ;PGM ABORTED
6159 030774 005037 023762      CLR    $EOPCT        ;SET UP EOP TO EXIT TO MONITOR
6160 031000 005037 001176      CLR    $ESCAPE
6161 031004 000137 023734      JMP    $EOP          ;ABORT PROGRAM
6162
6163 031010 104401 044216      5$:  TYPE   ,MSG77        ;CPU HALTED
6164 031014 000000              HALT
6165 031016 000137 010612      JMP    ST5           ;START OVER IF CONTINUE PRESSED
6166
6167 031022
6168
6169
6170
6171
6172
6173
6174
6175
6176
6177 031022 011600      BADTMO: MOV    (SP),R0      ;SAVE PC WHERE TIMEOUT OCCURRED.
6178 031024 005740      TST    -(R0)          ;GET PC BEFORE UPDATE
6179 031026 032777 020000 150104  BIT    #SW13,@SWR     ;INHIBIT ERR TYP0UT?
6180 031034 001005      BNE    1$            ;YES, DON'T TYPE
6181 031036 104401 044546      TYPE   ,EM3          ;ABORT TESTS,UNEXP T.O. @ PC=
6182 031042 010046      MOV    R0,-(SP)      ;SAVE R0 FOR TYPEOUT
6183
6184 031044 104403      TYPOS
6185 031046 006          .BYTE  6            ;GO TYPE--OCTAL ASCII
6186 031047 000          .BYTE  0            ;TYPE 6 DIGIT(S)
6187 031050 032777 001000 150062 1$:  BIT    #SW9,@SWR     ;SUPPRESS LEADING ZEROS
6188 031056 001403      BEQ    2$            ;LOOP ON ERROR?
6189 031060 022626      CMP    (SP)+,(SP)+  ;NO, BRANCH
6190 031062 000177 150020      JMP    @SLPADR       ;YES, RESTORE STACK
6191
6192 031066 032777 040000 150044 2$:  BIT    #SW14,@SWR   ;GO TO STARTING ADDR OF TEST
6193 031074 001401      BEQ    3$            ;THAT GAVE BAD TIMEOUT
6194 031076 000002      RTI                    ;LOOP ON TEST?
6195
6196 031100 000000      3$:  HALT                ;NO BRANCH
6197
6198
6199
6200
6201

```

FORM:
 .SBTTL UNEXPECTED TIMEOUT HANDLER

```

: THIS ROUTINE IS ENTERED IF THERE IS
: A. NON EXISTANT MEMORY (NO SSYN)
: B. BOUNDRY ERROR
: C. STACK OVERFLOW
:

```

```

;SAVE PC WHERE TIMEOUT OCCURRED.
;GET PC BEFORE UPDATE
;INHIBIT ERR TYP0UT?
;YES, DON'T TYPE
;ABORT TESTS,UNEXP T.O. @ PC=
;SAVE R0 FOR TYPEOUT
;TYPE PC
;GO TYPE--OCTAL ASCII
;TYPE 6 DIGIT(S)
;SUPPRESS LEADING ZEROS
;LOOP ON ERROR?
;NO, BRANCH
;YES, RESTORE STACK
;GO TO STARTING ADDR OF TEST
;THAT GAVE BAD TIMEOUT
;LOOP ON TEST?
;NO BRANCH
;YES
;UNEXPECTED TIME OUT OCCURRED
;AS INDICATED, YOU CAN LOOP ON
;ERROR, LOOP ON TEST OR INHIBIT
;ERROR TYPEOUT BY SETTING THOSE
;SWITCHES.
:

```

```

6202 031102 022626          CMP      (SP)+,(SP)+      ;RESTORE STACK
6203 031104 000137 023734  JMP      $EOP             ;ABORT TESTS
6204
6205          .SBTTL MEMORY CHECK ENABLE TRAP
6206
6207 031110 012737 031124 001176 MEMERR: MOV      #1$,$ESCAPE
6208 031116 011637 001354          MOV      (SP),TRAPPC    ;STORE PC
6209 031122 104202          ERROR 202             ;UNEXP MEM PARITY ERROR
6210
6211 031124 005037 001176 15:      CLR      $ESCAPE
6212 031130 032777 001000 150002 BIT      #SW9,@SWR      ;CHECK IF LOOP ON ERROR
6213 031136 001001          BNE     2$              ;YES, FORCE STACK AND TRY AGAIN
6214 031140 000002          RTI                    ;ELSE RETURN
6215
6216 031142 012706 001100 2$:      MOV      #STACK,SP    ;INIT STACK
6217 031146 000177 147736          JMP      @SLPERR
6218
6219          .SBTTL RK06 INTERRUPT HANDLER
6220
6221 031152 000240          INTER: NOP
6222 031154 000240          NOP
6223 031156 000240          NOP
6224 031160 011600          MOV      (SP),R0      ;SAVE PC WHERE INT OCCURRED.
6225 031162 005740          TST     -(R0)         ;GET PC BEFORE UPDATE.
6226 031164 104401 037036          TYPE   ,MSG6         ;INT AT PC=
6227 031170 010046          MOV      R0,-(SP)    ;SAVE R0 FOR TYPEOUT
6228          ;TYPE PC
6229 031172 104403          TYPOS  ;GO TYPE--OCTAL ASCII
6230 031174          006          .BYTE 6              ;TYPE 6 DIGIT(S)
6231 031175          000          .BYTE 0              ;SUPPRESS LEADING ZEROS
6232 031176 000000          HALT
6233 031200 000240          NOP
6234 031202 000240          NOP
6235 031204 000002          RTI
6236
6237          .SBTTL POWER DOWN AND UP ROUTINES
6238
6239          ;POWER DOWN ROUTINE
6240
6241 031206 012737 031220 000024 $PWRDN: MOV      #SPWRUP,PWRVEC ;SET UP VECTOR
6242 031214 000000          HALT
6243 031216 000776          BR     .-2           ;HANG UP.
6244
6245          ;POWER UP ROUTINE
6246
6247 031220 005037 031272 $PWRUP: CLR      $PWRCT    ;WAIT LOOP FOR TTY
6248 031224 005237 031272 1$:      INC      $PWRCT      ;WAIT FOR THE INCR
6249 031230 001375          BNE     1$           ;OF WORD
6250 031232 012737 031206 000024 MOV      #SPWRDN,PWRVEC ;SET POWER DOWN VECTOR
6251 031240 012737 000340 000026 MOV      #PR7,PWRVEC+2 ;PRIORITY 7
6252 031246 012737 000340 000036 MOV      #PR7,TRAPVEC+2 ;LOCKOUT ALL INTERRUPTS FOR TRAPS
6253 031254 012706 001100          MOV      #STACK,SP   ;INITIALIZE STACK
6254 031260 104401 037232          TYPE   ,MSG11       ;REPORT POWER FAIL
6255 031264 000005          RESET
6256 031266 000137 012664          JMP      PFSRT
6257
  
```



```

6258 031272 000000      SPWRCT: 0                      ;WAIT COUNT FOR TTY
6259
6260
6261      ;DIVISION UTILITY ROUTINE
6262
6263      ;R0-R1-R2-R3=DIVIDEND
6264      ;R4-R5=DIVISOR
6265      ;R0-R1=REMAINDER AFTER DIVISION
6266      ;R2-R3=QUOTIENT AFTER DIVISION
6267      ;ENTER WITH JSR PC,M.DPID
6268
6269 031274 012746 000040  M.DPID: MOV      #40,-(SP)      ;COUNTER FOR DIVISION CYCLES
6270 031300 010446          MOV      R4,-(SP)      ;HI ORDER
6271 031302 010546          MOV      R5,-(SP)      ;LO ORDER TO THE STACK
6272 031304 005466 000002  NEG      2(SP)         ;FORM NEGATIVE
6273 031310 005416          NEG      @SP           ;VERSION OF DIVISCR
6274 031312 005666 000002  SBC      2(SP)
6275 031316 061601          ADD      @SP,R1
6276 031320 005500          ADC      R0           ;PERFORM INIT SUBT.
6277 031322 066600 000002  ADD      2(SP),R0
6278 031326 103445          BCS     M.DP50        ;IF CARRY THEN OVERFLOW HAS OCCURRED
6279 031330 005046          CLR     -(SP)        ;THIS IS A LONGER LASTING CARRY BIT
6280 031332 006103  M.DP40: ROL      R3
6281 031334 006102          ROL      R2
6282 031336 006101          ROL      R1
6283 031340 006100          ROL      R0
6284 031342 005716          TST     @SP           ;TEST CARRY INDICATOR
6285 031344 001410          BEQ     M.DP41        ;IF TO CARRY THEN ADD, ELSE SUBT.
6286 031346 005016          CLR     @SP           ;CLEAR UP FOR NEXT TIME
6287 031350 066601 000002  ADD      2(SP),R1
6288 031354 005500          ADC      R0           ;ADD -(DIVISOR)
6289 031356 005516          ADC     @SP           ;SET CARRY
6290 031360 066600 000004  ADD      4(SP),R0
6291 031364 000404          BR      M.DP42
6292
6293 031366 060501  M.DP41: ADD      R5,R1
6294 031370 005500          ADC      R0           ;ADD +(DIVISOR)
6295 031372 005516          ADC     @SP           ;SET CARRY
6296 031374 060400  M.DP42: ADD      R4,R0
6297 031376 005516          ADC     @SP           ;SET CARRY
6298 031400 005716          TST     @SP           ;TEST THE UPDATE INDICATOR
6299 031402 001401          BEQ     .+4           ;IF 0, FORGET IT
6300 031404 005203          INC     R3           ;NO CARRY POSSIBLE HERE
6301 031406 005366 000006  DEC     6(SP)         ;DECREMENT CTR
6302 031412 003347          BGT     M.DP40        ;BR IF MORE TO DO
6303 031414 006003          ROR     R3
6304 031416 103404          BCS     M.DP44
6305 031420 060501          ADD     R5,R1
6306 031422 005500          ADC     R0
6307 031424 060400          ADD     R4,R0
6308 031426 000241          CLC
6309
6310 031430 006103  M.DP44: ROL      R3
6311 031432 062706 000010  ADD     #10,SP        ;ADJUST STACK BY 4 WORDS
6312 031436 000242          CLV
6313 031440 000207          RTS     PC
  
```

6314
6315 031442 062706 000006
6316 031446 000262
6317 031450 000207
6318

M.DP50: ADD #6,SP
SEV
RTS PC


```
6319 .SBTTL SCOPE HANDLER ROUTINE
6320
6321 ;*****
6322 ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
6323 ;*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
6324 ;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
6325 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
6326 ;*SW14=1 LOOP ON TEST
6327 ;*SW11=1 INHIBIT ITERATIONS
6328 ;*SW09=1 LOOP ON ERROR
6329 ;*SW08=1 LOOP ON TEST IN SWR<7:0>
6330 ;*CALL
6331 ;* SCOPE ;:SCOPE=IOT
6332
6333 $SCOPE:
6334 031452 104407 040000 147456 1$: CKSWR ;:TEST FOR CHANGE IN SOFT-SWR
6335 031454 032777 040000 147456 1$: BIT #BIT14,@SWR ;:LOOP ON PRESENT TEST?
6336 031462 001114 040000 147456 1$: BNE $OVER ;:YES IF SW14=1
6337 ;*****START OF CODE FOR THE XOR TESTER*****
6338 031464 000416 040000 147456 1$: $XTSTR: BR 6$ ;:IF RUNNING ON THE "XOR" TESTER CHANGE
6339 ;:THIS INSTRUCTION TO A "NOP" (NOP=240)
6340 031466 013746 000004 000004 1$: MOV @WERRVEC,-(SP) ;:SAVE THE CONTENTS OF THE ERROR VECTOR
6341 031472 012737 031512 000004 1$: MOV #5,@WERRVEC ;:SET FOR TIMEOUT
6342 031500 005737 177060 000004 1$: TST @#177060 ;:TIME OUT ON XOR?
6343 031504 012637 000004 000004 1$: MOV (SP)+,@WERRVEC ;:RESTORE THE ERROR VECTOR
6344 031510 000463 000004 000004 1$: BR $SVLAD ;:GO TO THE NEXT TEST
6345 031512 022626 000004 000004 5$: CMP (SP)+,(SP)+ ;:CLEAR THE STACK AFTER A TIME OUT
6346 031514 012637 000004 000004 5$: MOV (SP)+,@WERRVEC ;:RESTORE THE ERROR VECTOR
6347 031520 000423 000004 000004 5$: BR 7$ ;:LOOP ON THE PRESENT TEST
6348 031522 000423 000004 000004 6$: ;*****END OF CODE FOR THE XOR TESTER*****
6349 031522 032777 000400 147410 6$: BIT #BIT08,@SWR ;:LOOP ON SPEC. TEST?
6350 031530 001404 000400 147410 6$: BEQ 2$ ;:BR IF NO
6351 031532 127737 147402 001102 6$: CMPB @SWR,$TSTNM ;:ON THE RIGHT TEST? SWR<7:0>
6352 031540 001465 147402 001102 6$: $OVER ;:BR IF YES
6353 031542 105737 001103 001103 2$: TSTB $ERFLG ;:HAS AN ERROR OCCURRED?
6354 031546 001421 001103 001103 2$: BEQ 3$ ;:BR IF NO
6355 031550 123737 001115 001103 2$: CMPB $ERMAX,$ERFLG ;:MAX. ERRORS FOR THIS TEST OCCURRED?
6356 031556 101015 001115 001103 2$: BHI 3$ ;:BR IF NO
6357 031560 032777 001000 147352 7$: BIT #BIT09,@SWR ;:LOOP ON ERROR?
6358 031566 001404 001000 147352 7$: BEQ 4$ ;:BR IF NO
6359 031570 013737 001110 001106 7$: MOV $LPERR,$LPADR ;:SET LOOP ADDRESS TO LAST SCOPE
6360 031576 000446 001110 001106 7$: BR $OVER
6361 031600 105037 001103 001106 4$: CLRB $ERFLG ;:ZERO THE ERROR FLAG
6362 031604 005037 001174 001106 4$: CLR $TIMES ;:CLEAR THE NUMBER OF ITERATIONS TO MAKE
6363 031610 000415 001174 001106 4$: BR 1$ ;:ESCAPE TO THE NEXT TEST
6364 031612 032777 004000 147320 3$: BIT #BIT11,@SWR ;:INHIBIT ITERATIONS?
6365 031620 001011 004000 147320 3$: BNE 1$ ;:BR IF YES
6366 031622 005737 001216 001214 3$: TST $PASS ;:IF FIRST PASS OF PROGRAM
6367 031626 001406 001216 001214 3$: BEQ 1$ ;: INHIBIT ITERATIONS
6368 031630 005237 001104 001214 3$: INC $ICNT ;:INCREMENT ITERATION COUNT
6369 031634 023737 001174 001104 3$: CMP $TIMES,$ICNT ;:CHECK THE NUMBER OF ITERATIONS MADE
6370 031642 002024 001174 001104 3$: BGE $OVER ;:BR IF MORE ITERATION REQUIRED
6371 031644 012737 000001 001104 1$: MOV #1,$ICNT ;:REINITIALIZE THE ITERATION COUNTER
6372 031652 013737 031730 001174 1$: MOV $MXCNT,$TIMES ;:SET NUMBER OF ITERATIONS TO DO
6373 031660 105237 001102 001174 1$: $SVLAD: INCB $TSTNM ;:COUNT TEST NUMBERS
6374 031664 113737 001102 001214 1$: MOVB $TSTNM,$TESTN ;:SET TEST NUMBER IN APT MAILBOX
```

```

6375 031672 011637 001106      MOV      (SP), $LPADR      ;;SAVE SCOPE LOOP ADDRESS
6376 031676 011637 001110      MOV      (SP), $LPERR     ;;SAVE ERROR LOOP ADDRESS
6377 031702 005037 001176      CLR      $ESCAPE         ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
6378 031706 112737 000001 001115  MOVB     #1, $ERMAX       ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
6379 031714 013777 001102 147220 $OVER:   MOV      $TSTNM, @DISPLAY ;;DISPLAY TEST NUMBER
6380 031722 013716 001106      MOV      $LPADR, (SP)    ;;FUDGE RETURN ADDRESS
6381 031726 000002                RTI                      ;;FIXES PS
6382 031730 003720                SMXCNT: 2000.           ;;MAX. NUMBER OF ITERATIONS
6383                .SBTTL  ERROR HANDLER ROUTINE
6384
6385                ;*****
6386                ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
6387                ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
6388                ;*AND GO TO TYPERR ON ERROR
6389                ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
6390                ;*SW15=1      HALT ON ERROR
6391                ;*SW13=1      INHIBIT ERROR TYPEOUTS
6392                ;*SW10=1     BELL ON ERROR
6393                ;*SW09=1     LOOP ON ERROR
6394                ;*CALL
6395                ;*      ERROR      N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
6396
6397 031732                $ERROR:
6398 031732 104407                CKSWR
6399 031734 105237 001103      7$:     INCB      $ERFLG      ;;TEST FOR CHANGE IN SOFT-SWR
6400 031740 001775                BEQ      7$              ;;SET THE ERROR FLAG
6401 031742 013777 001102 147172  MOV      $TSTNM, @DISPLAY ;;DON'T LET THE FLAG GO TO ZERO
6402 031750 032777 002000 147162  BIT      #BIT10, @SWR    ;;DISPLAY TEST NUMBER AND ERROR FLAG
6403 031756 001402                BEQ      1$              ;;BELL ON ERROR?
6404 031760 104401 001200                TYPE     $BELL          ;;NO - SKIP
6405 031764 005237 001112      1$:     INC      $ERTTL    ;;RING BELL
6406 031770 011637 001116      MOV      (SP), $ERRPC    ;;COUNT THE NUMBER OF ERRORS
6407 031774 162737 000002 001116  SUB      #2, $ERRPC      ;;GET ADDRESS OF ERROR INSTRUCTION
6408 032002 117737 147110 001114  MOVB    @ $ERRPC, $ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
6409 032010 032777 020000 147122  BIT      #BIT13, @SWR    ;;SKIP TYPEOUT IF SET
6410 032016 001004                BNE     20$             ;;SKIP TYPEOUTS
6411 032020 004737 055134      JSR     PC, TYPERR      ;;GO TO USER ERROR ROUTINE
6412 032024 104401 001205      TYPE    $CRLF
6413 032030
6414 032030 122737 000001 001230      20$:   CMPB    #APTENV, $ENV  ;;RUNNING IN APT MODE
6415 032036 001007                BNE     2$              ;;NO, SKIP APT ERROR REPORT
6416 032040 113737 001114 032052  MOVB    $ITEMB, 21$     ;;SET ITEM NUMBER AS ERROR NUMBER
6417 032046 004737 032730      JSR     PC, $ATY4      ;;REPORT FATAL ERROR TO APT
6418 032052 000                21$:   .BYTE  0
6419 032053 000                .BYTE  0
6420 032054 000777                22$:   BR      22$           ;;APT ERROR LOOP
6421 032056 005777 147056      2$:     TST      @SWR        ;;HALT ON ERROR
6422 032062 100002                BPL     3$              ;;SKIP IF CONTINUE
6423 032064 000000                HALT
6424 032066 104407                CKSWR
6425 032070 032777 001000 147042  3$:     BIT      #BIT09, @SWR  ;;TEST FOR CHANGE IN SOFT-SWR
6426 032076 001402                BEQ     4$              ;;LOOP ON ERROR SWITCH SET?
6427 032100 013716 001110      MOV     $LPERR, (SP)    ;;BR IF NO
6428 032104 005737 001176      TST    $ESCAPE         ;;FUDGE RETURN FOR LOOPING
6429 032110 001402                BEQ     5$              ;;CHECK FOR AN ESCAPE ADDRESS
6430 032112 013716 001176      MOV     $ESCAPE, (SP)  ;;BR IF NONE
6430                FUDGE  $ESCAPE, (SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE

```



```

6431 032116
6432 032116 022737 024022 000042 5$:      CMP      #SENDAD,@#42      ::ACT-11 AUTO-ACCEPT?
6433 032124 001001                                BNE      6$              ::BRANCH IF NO
6434 032126 000000                                HALT                                     ::YES
6435 032130
6436 032130 000002 6$:      RTI              ::RETURN
6437
6438 .SBTTL  TYPE ROUTINE
6439
6440 ::*****
6441 ::*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
6442 ::*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
6443 ::*NOTE1:      $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
6444 ::*NOTE2:      $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
6445 ::*NOTE3:      $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
6446 ::*
6447 ::*CALL:
6448 ::*1) USING A TRAP INSTRUCTION
6449 ::*      TYPE      ,MESADR      ::MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
6450 ::*OR
6451 ::*      TYPE
6452 ::*      MESADR
6453 ::*
6454 032132 105737 001157 $TYPE:  TSTB      $TPFLG      ::IS THERE A TERMINAL?
6455 032136 100002                                BPL      1$              ::BR IF YES
6456 032140 000000                                HALT                                     ::HALT HERE IF NO TERMINAL
6457 032142 000430                                BR       3$              ::LEAVE
6458 032144 010046 1$:      MOV      R0,-(SP)      ::SAVE R0
6459 032146 017600 000002 001230  MOV      @2(SP),R0      ::GET ADDRESS OF ASCIZ STRING
6460 032152 122737 000001 001230  CMPB     #APTENV,$ENV   ::RUNNING IN APT MODE
6461 032160 001011                                BNE      62$             ::NO,GO CHECK FOR APT CONSOLE
6462 032162 132737 000100 001231  BITB     #APTSPOOL,$ENVM  ::SPOOL MESSAGE TO APT
6463 032170 001405                                BEQ      62$             ::NO,GO CHECK FOR CONSOLE
6464 032172 010037 032202                                MOV      R0,61$          ::SETUP MESSAGE ADDRESS FOR APT
6465 032176 004737 032720 61$:     JSR      PC,$ATY3      ::SPOOL MESSAGE TO APT
6466 032202 000000                                .WORD    0               ::MESSAGE ADDRESS
6467 032204 132737 000040 001231 62$:     BITB     #APTCSUP,$ENVM  ::APT CONSOLE SUPPRESSED
6468 032212 001003                                BNE      60$             ::YES,SKIP TYPE OUT
6469 032214 112046 2$:      MOVB     (R0)+,-(SP)      ::PUSH CHARACTER TO BE TYPED ONTO STACK
6470 032216 001005                                BNE      4$              ::BR IF IT ISN'T THE TERMINATOR
6471 032220 005726                                TST     (SP)+            ::IF TERMINATOR POP IT OFF THE STACK
6472 032222 012600 60$:     MOV      (SP)+,R0      ::RESTORE R0
6473 032224 062716 000002 3$:      ADD      #2,(SP)        ::ADJUST RETURN PC
6474 032230 000002                                RTI                                     ::RETURN
6475 032232 122716 000011 4$:      CMPB     #HT,(SP)       ::BRANCH IF <HT>
6476 032236 001430                                BEQ      8$              ::BRANCH IF NOT <CRLF>
6477 032240 122716 000200  CMPB     #CRLF,(SP)
6478 032244 001006                                BNE      5$              ::POP <CR><LF> EQUIV
6479 032246 005726                                TST     (SP)+            ::TYPE A CR AND LF
6480 032250 104401                                TYPE
6481 032252 001205                                $CRLF
6482 032254 105037 032462  CLRB     $CHARCNT      ::CLEAR CHARACTER COUNT
6483 032260 000755                                BR       2$              ::GET NEXT CHARACTER
6484 032262 004737 032344 5$:      JSR      PC,$TYPEC      ::GO TYPE THIS CHARACTER
6485 032266 123726 001156 6$:      CMPB     $FILLC,(SP)+  ::IS IT TIME FOR FILLER CHARS.?
6486 032272 001350                                BNE      2$              ::IF NO GO GET NEXT CHAR.

```

```

6487 032274 013746 001154      MOV      $NULL,-(SP)      ;;GET # OF FILLER CHARS. NEEDED
6488                                ;;AND THE NULL CHAR.
6489 032300 105366 000001      7$:  DECB      1(SP)      ;;DOES A NULL NEED TO BE TYPED?
6490 032304 002770                BLT      6$              ;;BR IF NO--GO POP THE NULL OFF OF STACK
6491 032306 004737 032344      JSR      PC,$TYPEC      ;;GO TYPE A NULL
6492 032312 105337 032462      DECB      $CHARCNT      ;;DO NOT COUNT AS A COUNT
6493 032316 000770                BR       7$              ;;LOOP
6494
6495                                ;HORIZONTAL TAB PROCESSOR
6496
6497 032320 112716 000040      8$:  MOVB      #' ,(SP)      ;;REPLACE TAB WITH SPACE
6498 032324 004737 032344      9$:  JSR      PC,$TYPEC      ;;TYPE A SPACE
6499 032330 132737 000007 032462  BITB      #7,$CHARCNT      ;;BRANCH IF NOT AT
6500 032336 001372                BNE      9$              ;;TAB STOP
6501 032340 005726                TST      (SP)+           ;;POP SPACE OFF STACK
6502 032342 000724                BR       2$              ;;GET NEXT CHARACTER
6503 032344
6504 032344 105777 146574      $TYPEC: TSTB      @STKS          ;  ;;CHAR IN KYBD BUFFER?      :MJD001
6505 032350 100022                BPL      10$             ;;BR IF NOT      :MJD001
6506 032352 017746 146570      MOV      @STKB,-(SP)      ;;GET CHAR      :MJD001
6507 032356 042716 177600      BIC      #177600,(SP)     ;;STRIP EXTRANEIOUS BITS :MJD001
6508 032362 122716 000023      CMPB      #$XOFF,(SP)     ;;WAS CHAR XOFF    :MJD001
6509 032366 001012                BNE      102$           ;;BR IF NOT      :MJD001
6510 032370
6511 032370 105777 146550      101$: TSTB      @STKS          ;;WAIT FOR CHAR  :MJD001
6512 032374 100375                BPL      101$           :MJD001
6513 032376 117716 146544      MOVB      @STKB,(SP)      ;;GET CHAR      :MJD001
6514 032402 042716 177600      BIC      #177600,(SP)     ;;STRIP IT      :MJD001
6515 032406 122716 000021      CMPB      #$XON,(SP)     ;;WAS IT XON?    :MJD001
6516 032412 001366                BNE      101$           ;;BR IF NOT      :MJD001
6517 032414
6518 032414 005726      102$: TST      (SP)+           ;;FIX STACK      :MJD001
6519 032416
6520 032416 105777 146526      10$:  TSTB      @STPS          ;;WAIT UNTIL PRINTER IS READY :MJD001
6521 032422 100375                BPL      10$              :MJD001
6522 032424 116677 000002 146520  MOVB      2(SP),@STPB      ;;LOAD CHAR TO BE TYPED INTO DATA REG.
6523 032432 122766 000015 000002  CMPB      #CR,2(SP)        ;;IS CHARACTER A CARRIAGE RETURN?
6524 032440 001003                BNE      1$              ;;BRANCH IF NO
6525 032442 105037 032462      CLRB      $CHARCNT        ;;YES--CLEAR CHARACTER COUNT
6526 032446 000406                BR       $TYPEX          ;;EXIT
6527 032450 122766 000012 000002  1$:  CMPB      #LF,2(SP)     ;;IS CHARACTER A LINE FEED?
6528 032456 001402                BEQ      $TYPEX          ;;BRANCH IF YES
6529 032460 105227                INCB      (PC)+          ;;COUNT THE CHARACTER
6530 032462 000000      $CHARCNT: .WORD      0      ;;CHARACTER COUNT STORAGE
6531 032464 000207      $TYPEX:  RTS      PC
6532
6533                                .SBTTL  CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
6534
6535                                ;*****
6536                                ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
6537                                ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
6538                                ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
6539                                ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
6540                                ;*REPLACED WITH SPACES.
6541                                ;*CALL:
6542                                ;*  MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
    
```



```

6543          :*      TYPDS          ;;GO TO THE ROUTINE
6544
6545 032466          $TYPDS:
6546 032466 010046      MOV      R0,-(SP)          ;;PUSH R0 ON STACK
6547 032470 010146      MOV      R1,-(SP)          ;;PUSH R1 ON STACK
6548 032472 010246      MOV      R2,-(SP)          ;;PUSH R2 ON STACK
6549 032474 010346      MOV      R3,-(SP)          ;;PUSH R3 ON STACK
6550 032476 010546      MOV      R5,-(SP)          ;;PUSH R5 ON STACK
6551 032500 012746 020200  MOV      #20200,-(SP)        ;;SET BLANK SWITCH AND SIGN
6552 032504 016605 000020  MOV      20(SP),R5          ;;GET THE INPUT NUMBER
6553 032510 100004      BPL      1$              ;;BR IF INPUT IS POS.
6554 032512 005405      NEG      R5              ;;MAKE THE BINARY NUMBER POS.
6555 032514 112766 000055 000001  MOVVB   #'-,1(SP)          ;;MAKE THE ASCII NUMBER NEG.
6556 032522 005000      1$:    CLR      R0              ;;ZERO THE CONSTANTS INDEX
6557 032524 012703 032702  MOV      #SDBLK,R3          ;;SETUP THE OUTPUT POINTER
6558 032530 112723 000040  MOVVB   #' ,(R3)+          ;;SET THE FIRST CHARACTER TO A BLANK
6559 032534 005002      2$:    CLR      R2              ;;CLEAR THE BCD NUMBER
6560 032536 016001 032672  MOV      $DTBL(R0),R1        ;;GET THE CONSTANT
6561 032542 160105      3$:    SUB      R1,R5          ;;FORM THIS BCD DIGIT
6562 032544 002402      BLT      4$              ;;BR IF DONE
6563 032546 005202      INC      R2              ;;INCREASE THE BCD DIGIT BY 1
6564 032550 000774      BR       3$
6565 032552 060105      4$:    ADD      R1,R5          ;;ADD BACK THE CONSTANT
6566 032554 005702      TST      R2              ;;CHECK IF BCD DIGIT=0
6567 032556 001002      BNE      5$              ;;FALL THROUGH IF 0
6568 032560 105716      TSTB    (SP)              ;;STILL DOING LEADING 0'S?
6569 032562 100407      BMI      7$              ;;BR IF YES
6570 032564 106316      5$:    ASLB    (SP)          ;;MSD?
6571 032566 103003      BCC      6$              ;;BR IF NO
6572 032570 116663 000001 177777  MOVVB   1(SP),-1(R3)        ;;YES--SET THE SIGN
6573 032576 052702 000060 6$:    BIS      #'0,R2          ;;MAKE THE BCD DIGIT ASCII
6574 032602 052702 000040 7$:    BIS      #' ,R2          ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
6575 032606 110223      MOVVB   R2,(R3)+          ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
6576 032610 005720      TST      (R0)+          ;;JUST INCREMENTING
6577 032612 020027 000010  CMP      R0,#10          ;;CHECK THE TABLE INDEX
6578 032616 002746      BLT      2$              ;;GO DO THE NEXT DIGIT
6579 032620 003002      BGT      8$              ;;GO TO EXIT
6580 032622 010502      MOV      R5,R2          ;;GET THE LSD
6581 032624 000764      BR       6$              ;;GO CHANGE TO ASCII
6582 032626 105726      8$:    TSTB    (SP)+          ;;WAS THE LSD THE FIRST NON-ZERO?
6583 032630 100003      BPL      9$              ;;BR IF NO
6584 032632 116663 177777 177776  MOVVB   -1(SP),-2(R3)        ;;YES--SET THE SIGN FOR TYPING
6585 032640 105013      9$:    CLRB    (R3)          ;;SET THE TERMINATOR
6586 032642 012605      MOV      (SP)+,R5          ;;POP STACK INTO R5
6587 032644 012603      MOV      (SP)+,R3          ;;POP STACK INTO R3
6588 032646 012602      MOV      (SP)+,R2          ;;POP STACK INTO R2
6589 032650 012601      MOV      (SP)+,R1          ;;POP STACK INTO R1
6590 032652 012600      MOV      (SP)+,R0          ;;POP STACK INTO R0
6591 032654 104401 032702  TYPE      $SDBLK          ;;NOW TYPE THE NUMBER
6592 032660 016666 000002 000004  MOV      2(SP),4(SP)        ;;ADJUST THE STACK
6593 032666 012616      MOV      (SP)+,(SP)
6594 032670 000002      RTI                      ;;RETURN TO USER
6595 032672 023420      $DTBL: 10000.
6596 032674 001750      1000.
6597 032676 000144      100.
6598 032700 000012      10.
    
```

```
6599 032702 000004 $DBLK: .BLKW 4
6600 .SBTTL APT COMMUNICATIONS ROUTINE
6601
6602 *****
6603 032712 112737 000001 033156 $ATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
6604 032720 112737 000001 033154 $ATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
6605 032726 000403 BR $ATYC
6606 032730 112737 000001 033156 $ATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
6607 032736 $ATYC:
6608 032736 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
6609 032740 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
6610 032742 105737 033154 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
6611 032746 001450 BEQ 5$ ;;IF NOT: BR
6612 032750 122737 000001 001230 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
6613 032756 001031 BNE 3$ ;;IF NOT: BR
6614 032760 132737 000100 001231 BITB #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
6615 032766 001425 BEQ 3$ ;;IF NOT: BR
6616 032770 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
6617 032774 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
6618 033002 005737 001210 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
6619 033006 001375 BNE 1$ ;;IF NOT: WAIT
6620 033010 010037 001224 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
6621 033014 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
6622 033016 001376 BNE 2$
6623 033020 163700 001224 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
6624 033024 006200 ASR R0 ;;GET MESSAGE LNTH IN WORDS
6625 033026 010037 001226 MOV R0,$MSGGLT ;;PUT LENGTH IN MAILBOX
6626 033032 012737 000004 001210 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
6627 033040 000413 BR 5$
6628 033042 017637 000004 033066 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
6629 033050 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
6630 033056 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
6631 033062 004737 032132 JSR PC,$TYPE ;;CALL TYPE MACRO
6632 033066 000000 4$: .WORD 0
6633 033070 5$:
6634 033070 105737 033156 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
6635 033074 001416 BEQ 12$ ;;IF NOT: BR
6636 033076 005737 001230 TST $ENV ;;RUNNING UNDER APT?
6637 033102 001413 BEQ 12$ ;;IF NOT: BR
6638 033104 005737 001210 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
6639 033110 001375 BNE 11$ ;;IF NOT: WAIT
6640 033112 017637 000004 001212 MOV @4(SP),$FATAL ;;GET ERROR #
6641 033120 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
6642 033126 005237 001210 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
6643 033132 105037 033156 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
6644 033136 105037 033155 CLRB $LFLG ;;CLEAR LOG FLAG
6645 033142 105037 033154 CLRB $MFLG ;;CLEAR MESSAGE FLAG
6646 033146 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
6647 033150 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
6648 033152 000207 RTS PC ;;RETURN
6649 033154 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
6650 033155 000 $LFLG: .BYTE 0 ;;LOG FLAG
6651 033156 000 $FFLG: .BYTE 0 ;;FATAL FLAG
6652 033160 .EVEN
6653 000200 APTSIZE=200
6654 000001 APTENV=001
```


6655 000100
 6656 000040
 6657
 6658
 6659
 6660
 6661
 6662
 6663
 6664
 6665
 6666
 6667
 6668
 6669
 6670
 6671
 6672
 6673
 6674
 6675
 6676
 6677
 6678
 6679
 6680
 6681
 6682 033160 017646 000000
 6683 033164 116637 000001 033403
 6684 033172 112637 033405
 6685 033176 062716 000002
 6686 033202 000406
 6687 033204 112737 000001 033403
 6688 033212 112737 000006 033405
 6689 033220 112737 000005 033402
 6690 033226 010346
 6691 033230 010446
 6692 033232 010546
 6693 033234 113704 033405
 6694 033240 005404
 6695 033242 062704 000006
 6696 033246 110437 033404
 6697 033252 113704 033403
 6698 033256 016605 000012
 6699 033262 005003
 6700 033264 006105
 6701 033266 000404
 6702 033270 006105
 6703 033272 006105
 6704 033274 006105
 6705 033276 010503
 6706 033300 006103
 6707 033302 105337 033404
 6708 033306 100016
 6709 033310 042703 177770
 6710 033314 001002

```

APTSPool=100
APTCSUP=040
.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV     NUM,-(SP)      ::NUMBER TO BE TYPED
*   TYPOS   ::CALL FOR TYPEOUT
*   .BYTE  N              ::N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE  M              ::M=1 OR 0
*                               ::1=TYPE LEADING ZEROS
*                               ::0=SUPPRESS LEADING ZEROS
*$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*   MOV     NUM,-(SP)      ::NUMBER TO BE TYPED
*   TYPON   ::CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV     NUM,-(SP)      ::NUMBER TO BE TYPED
*   TYPOC   ::CALL FOR TYPEOUT
$TYPOS: MOV     @ (SP),-(SP)  ::PICKUP THE MODE
        MOV     1(SP), $OFILL ::LOAD ZERO FILL SWITCH
        MOV     (SP)+, $OMODE+1 ::NUMBER OF DIGITS TO TYPE
        ADD     #2, (SP)      ::ADJUST RETURN ADDRESS
        BR     $TYPON
$TYPOC: MOV     #1, $OFILL   ::SET THE ZERO FILL SWITCH
        MOV     #6, $OMODE+1 ::SET FOR SIX(6) DIGITS
$TYPON: MOV     #5, $OCNT    ::SET THE ITERATION COUNT
        MOV     R3, -(SP)    ::SAVE R3
        MOV     R4, -(SP)    ::SAVE R4
        MOV     R5, -(SP)    ::SAVE R5
        MOV     $OMODE+1, R4 ::GET THE NUMBER OF DIGITS TO TYPE
        NEG     R4
        ADD     #6, R4       ::SUBTRACT IT FOR MAX. ALLOWED
        MOV     R4, $OMODE   ::SAVE IT FOR USE
        MOV     $OFILL, R4   ::GET THE ZERO FILL SWITCH
        MOV     12(SP), R5   ::PICKUP THE INPUT NUMBER
        CLR     R3          ::CLEAR THE OUTPUT WORD
1$:    ROL     R5           ::ROTATE MSB INTO 'C'
        BR     3$          ::GO DO MSB
2$:    ROL     R5           ::FORM THIS DIGIT
        ROL     R5
        ROL     R5
        MOV     R5, R3
3$:    ROL     R3           ::GET LSB OF THIS DIGIT
        DECB   $OMODE       ::TYPE THIS DIGIT?
        BPL    7$          ::BR IF NO
        BIC   #177770, R3  ::GET RID OF JUNK
        BNE   4$          ::TEST FOR 0
    
```

```

6711 033316 005704          TST      R4          ::SUPPRESS THIS 0?
6712 033320 001403          BEQ      5$          ::BR IF YES
6713 033322 005204          4$: INC      R4          ::DON'T SUPPRESS ANYMORE 0'S
6714 033324 052703 000060    BIS      #'0,R3      ::MAKE THIS DIGIT ASCII
6715 033330 052703 000040    5$: BIS      #' ,R3      ::MAKE ASCII IF NOT ALREADY
6716 033334 110337 033400    MOVB     R3,8$       ::SAVE FOR TYPING
6717 033340 104401 033400    TYPE     8$          ::GO TYPE THIS DIGIT
6718 033344 105337 033402    7$: DECB    $OCNT     ::COUNT BY 1
6719 033350 003347          BGT      2$          ::BR IF MORE TO DO
6720 033352 002402          BLT      6$          ::BR IF DONE
6721 033354 005204          INC      R4          ::INSURE LAST DIGIT ISN'T A BLANK
6722 033356 000744          BR       2$          ::GO DO THE LAST DIGIT
6723 033360 012605          6$: MOV      (SP)+,R5  ::RESTORE R5
6724 033362 012604          MOV      (SP)+,R4  ::RESTORE R4
6725 033364 012603          MOV      (SP)+,R3  ::RESTORE R3
6726 033366 016666 000002 000004  MOV      2(SP),4(SP) ::SET THE STACK FOR RETURNING
6727 033374 012616          MOV      (SP)+,(SP)
6728 033376 000002          RTI          ::RETURN
6729 033400          8$: .BYTE    0          ::STORAGE FOR ASCII DIGIT
6730 033401          .BYTE    0          ::TERMINATOR FOR TYPE ROUTINE
6731 033402          .BYTE    0          ::OCTAL DIGIT COUNTER
6732 033403          .BYTE    0          ::ZERO FILL SWITCH
6733 033404 000000          $OCNT: .WORD   0      ::NUMBER OF DIGITS TO TYPE
6734          $OFILL: .BYTE   0
6735          $OMODE: .WORD   0
6736          .SBTTL  TTY INPUT ROUTINE
6737          ::*****
6738 033406 000000          .ENABL  LSB
6739 033410 000000          $TKCNT: .WORD   0      ::NUMBER OF ITEMS IN QUEUE
6740 033412 000000          $TKQIN: .WORD   0      ::INPUT POINTER
6741 033414 000001          $TKQOUT: .WORD   0     ::OUTPUT POINTER
6742          033415          $TKQSRT: .BLKB   1     ::TTY KEYBOARD QUEUE
6743          033416          $TKQEND=.
6744          .EVEN
6745          :*TK INITIALIZE ROUTINE
6746          :*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
6747          :*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
6748          :
6749          :*CALL:
6750          :*
6751          JSR      PC,$TKINT
6752          RETURN
6753 033416 005037 033406          $TKINT: CLR      $TKCNT  ::CLEAR COUNT OF ITEMS IN QUEUE
6754 033422 012737 033414 033410  MOV      #$TKQSRT,$TKQIN ::MOVE THE STARTING ADDRESS OF THE
6755 033430 013737 033410 033412  MOV      $TKQIN,$TKQOUT  ::QUEUE INTO THE INPUT & OUTPUT POINTERS.
6756 033436 012737 033466 000060  MOV      #$TKSRV,@#TKVEC ::INITIALIZE THE KEYBOARD VECTOR
6757 033444 012737 000200 000062  MOV      #200,@#TKVEC+2  ::'BR' LEVEL 4
6758 033452 005777 145470          TST      @#TKB         ::CLEAR DONE FLAG
6759 033456 012777 000100 145460  MOV      #100,@#TKS     ::ENABLE TTY KEYBOARD INTERRUPT
6760 033464 000207          RTS      PC           ::RETURN TO CALLER
6761
6762          :*TK SERVICE ROUTINE
6763          :*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
6764          :*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
6765          :*IT IN THE QUEUE.
6766          :*IF THE CHARACTER IS A "CONTROL-C" (^C) $TKINT IS CALLED AND
    
```



```

6767 ;*UPON RETURN EXIT IS MADE TO THE "CONTROL-C" RESTART ADDRESS (STOP)
6768
6769 033466 117746 145454 $TKSRV: MOVB @STKB,-(SP) ;;PICKUP THE CHARACTER
6770 033472 042716 177600 BIC #^C177,(SP) ;;STRIP THE JUNK
6771 033476 021627 000021 CMP (SP),#$XON ;;IS IT A RANDOM XON? ;RAN001
6772 033502 001002 BNE 30$ ;;BRANCH IF NO ;RAN001
6773 033504 005726 TST (SP)+ ;;CLEAN RANDOM XON OFF STACK ;RAN001
6774 033506 000002 RTI ;;RETURN ;RAN001
6775 033510
6776 033510 021627 000003 30$: CMP (SP),#3 ;;IS IT A CONTROL C?
6777 033514 001007 BNE 1$ ;;BRANCH IF NO
6778 033516 104401 034626 TYPE ,SCNTLC ;;TYPE A CONTROL-C (^C)
6779 033522 004737 033414 JSR PC,STKINT ;;INIT THE KEYBOARD
6780 033526 005726 TST (SP)+ ;;CLEAN UP STACK
6781 033530 000137 030500 JMP STOP ;;CONTROL C RESTART
6782 033534 021627 000007 1$: CMP (SP),#7 ;;IS IT A CONTROL G?
6783 033540 001004 BNE 2$ ;;BRANCH IF NO
6784 033542 022737 000176 001140 CMP #SWREG,SWR ;;IS SOFT-SWR SELECTED?
6785 033550 001500 BEQ 6$ ;;GO TO SWR CHANGE
6786
6787 033552
6788 033552 022737 000001 033406 2$: CMP #1,$TKCNT ;;IS THE QUEUE FULL?
6789 033560 001004 BNE 3$ ;;BRANCH IF NO
6790 033562 104401 001200 TYPE ,SBELL ;;RING THE TTY BELL
6791 033566 005726 TST (SP)+ ;;CLEAN CHARACTER OFF OF STACK
6792 033570 000451 BR 5$ ;;EXIT
6793 033572 021627 000023 3$: CMP (SP),#23 ;;IS IT A CONTROL-S?
6794 033576 001021 BNE 32$ ;;BRANCH IF NO
6795 033600 005077 145340 CLR @STKS ;;DISABLE TTY KEYBOARD INTERRUPTS
6796 033604 005726 TST (SP)+ ;;CLEAN CHAR OFF STACK
6797 033606 105777 145332 31$: TSTB @STKS ;;WAIT FOR A CHAR
6798 033612 100375 BPL 31$ ;;LOOP UNTIL ITS THERE
6799 033614 117746 145326 MOVB @STKB,-(SP) ;;GET THE CHARACTER
6800 033620 042716 177600 BIC #^C177,(SP) ;;MAKE IT 7-BIT ASCII
6801 033624 022627 000021 CMP (SP)+,#21 ;;IS IT A CONTROL-Q?
6802 033630 001366 BNE 31$ ;;BRANCH IF NO
6803 033632 012777 000100 145304 MOV #100,@STKS ;;REENABLE TTY KEYBOARD INTERRUPTS
6804 033640 000002 RTI ;;RETURN
6805 033642 005237 033406 32$: INC $TKCNT ;;COUNT THIS CHARACTER
6806 033646 021627 000140 CMP (SP),#140 ;;IS IT UPPER CASE?
6807 033652 002405 BLT 4$ ;;BRANCH IF YES
6808 033654 021627 000175 CMP (SP),#175 ;;IS IT A SPECIAL CHAR?
6809 033660 003002 BGT 4$ ;;BRANCH IF YES
6810 033662 042716 000040 BIC #40,(SP) ;;MAKE IT UPPER CASE
6811 033666 112677 177516 4$: MOVB (SP)+,@STKQIN ;;AND PUT IT IN QUEUE
6812 033672 005237 033410 INC $TKQIN ;;UPDATE THE POINTER
6813 033676 023727 033410 033415 CMP $TKQIN,$STKQEND ;;GO OFF THE END?
6814 033704 001003 BNE 5$ ;;BRANCH IF NO
6815 033706 012737 033414 033410 MOV #STKQSRST,$TKQIN ;;RESET THE POINTER
6816 033714 000002 5$: RTI ;;RETURN
6817
6818
6819
6820
6821
6822

```

```

;*****
;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
;*CALL WHEN OPERATING IN TTY INTERRUPT MODE.

```



```

6823 033716 022737 000176 001140 $CKSWR: CMP #SWREG,SWR ::IS THE SOFT-SWR SELECTED
6824 033724 001124 BNE 15$ ::EXIT IF NOT
6825 033726 105777 145212 TSTB @STKS ::IS A CHAR WAITING?
6826 033732 100121 BPL 15$ ::IF NOT, EXIT
6827 033734 117746 145206 MOVB @STKB,-(SP) ::YES
6828 033740 042716 177600 BIC #^C177,(SP) ::MAKE IT 7-BIT ASCII
6829 033744 021627 000007 CMP (SP),#7 ::IS IT A CONTROL-G?
6830 033750 001300 BNE 2$ ::IF NOT, PUT IT IN THE TTY QUEUE
6831 ::AND EXIT
6832
6833 ::*****
6834 ::*CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
6835 ::*ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
6836 ::*CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.
6837 033752 123727 001134 000001 6$: CMPB $AUTOB,#1 ::ARE WE RUNNING IN AUTO-MODE?
6838 033760 001674 BEQ 2$ ::BRANCH IF YES
6839 033762 005726 TST (SP)+ ::CLEAR CONTROL-G OFF STACK
6840 033764 004737 033416 JSR PC,$TKINT ::FLUSH THE TTY INPUT QUEUE
6841 033770 005077 145150 CLR @STKS ::DISABLE TTY KEYBOARD INTERRUPTS
6842 033774 112737 000001 001135 MOVB #1,$INTAG ::SET INTERRUPT MODE INDICATOR
6843
6844 034002 104401 034640 $GTSWR: TYPE ,SCNTLG ::ECHO THE CONTROL-G (^G)
6845 034006 104401 034645 TYPE ,SMSWR ::TYPE CURRENT CONTENTS
6846 034012 013746 000176 MOV SWREG,-(SP) ::SAVE SWREG FOR TYPEOUT
6847 034016 104402 TYPOC ::GO TYPE--OCTAL ASCII(ALL DIGITS)
6848 034020 104401 034656 TYPE ,SMNEW ::PROMPT FOR NEW SWR
6849 034024 005046 19$: CLR -(SP) ::CLEAR COUNTER
6850 034026 005046 CLR -(SP) ::THE NEW SWR
6851 034030 105777 145110 7$: TSTB @STKS ::CHAR THERE?
6852 034034 100375 BPL 7$ ::IF NOT TRY AGAIN
6853
6854 034036 117746 145104 MOVB @STKB,-(SP) ::PICK UP CHAR
6855 034042 042716 177600 BIC #^C177,(SP) ::MAKE IT 7-BIT ASCII
6856
6857 034046 021627 000003 CMP (SP),#3 ::IS IT A CONTROL-C?
6858 034052 001015 BNE 9$ ::BRANCH IF NOT
6859 034054 104401 034626 TYPE ,SCNTLC ::YES, ECHO CONTROL-C (^C)
6860 034060 062706 000006 ADD #6,SP ::CLEAN UP STACK
6861 034064 123727 001135 000001 CMPB $INTAG,#1 ::REENABLE TTY KEYBOARD INTERRUPTS?
6862 034072 001003 BNE 8$ ::BRANCH IF NO
6863 034074 012777 000100 145042 8$: MOV #100,@STKS ::ALLOW TTY KEYBOARD INTERRUPTS
6864 034102 000137 030500 JMP STOP ::CONTROL-C RESTART
6865
6866
6867 034106 021627 000025 9$: CMP (SP),#25 ::IS IT A CONTROL-U?
6868 034112 001005 BNE 10$ ::BRANCH IF NOT
6869 034114 104401 034633 TYPE ,SCNTLU ::YES, ECHO CONTROL-U (^U)
6870 034120 062706 000006 20$: ADD #6,SP ::IGNORE PREVIOUS INPUT
6871 034124 000737 BR 19$ ::LET'S TRY IT AGAIN
6872
6873
6874 034126 021627 000015 10$: CMP (SP),#15 ::IS IT A <CR>?
6875 034132 001022 BNE 16$ ::BRANCH IF NO
6876 034134 005766 000004 TST 4(SP) ::YES, IS IT THE FIRST CHAR?
6877 034140 001403 BEQ 11$ ::BRANCH IF YES
6878 034142 016677 000002 144770 MOV 2(SP),@SWR ::SAVE NEW SWR
    
```



```

6879 034150 062706 000006      11$:  ADD      #6,SP          ;;CLEAR UP STACK
6880 034154 104401 001205      14$:  TYPE     ,SCRLF        ;;ECHO <CR> AND <LF>
6881 034160 123727 001135      000001  CMPB    $INTAG,#1        ;;RE-ENABLE TTY KBD INTERRUPTS?
6882 034166 001003          BNE     15$              ;;BRANCH IF NOT
6883 034170 012777 000100      144746  MOV     #100,@$TKS      ;;RE-ENABLE TTY KBD INTERRUPTS
6884 034176 000002          15$:  RTI                    ;;RETURN
6885 034200 004737 032344      16$:  JSR     PC,$TYPEC      ;;ECHO CHAR
6886 034204 021627 000060          CMP     (SP),#60        ;;CHAR < 0?
6887 034210 002420          BLT    18$              ;;BRANCH IF YES
6888 034212 021627 000067          CMP     (SP),#67        ;;CHAR > 7?
6889 034216 003015          BGT    18$              ;;BRANCH IF YES
6890 034220 042726 000060          BIC     #60,(SP)+      ;;STRIP-OFF ASCII
6891 034224 005766 000002          TST    2(SP)           ;;IS THIS THE FIRST CHAR
6892 034230 001403          BEQ    17$              ;;BRANCH IF YES
6893 034232 006316          ASL    (SP)            ;;NO, SHIFT PRESENT
6894 034234 006316          ASL    (SP)            ;;CHAR OVER TO MAKE
6895 034236 006316          ASL    (SP)            ;;ROOM FOR NEW ONE.
6896 034240 005266 000002      17$:  INC     2(SP)           ;;KEEP COUNT OF CHAR
6897 034244 056616 177776          BIS    -2(SP),(SP)     ;;SET IN NEW CHAR
6898 034250 000667          BR     7$              ;;GET THE NEXT ONE
6899 034252 104401 001204      18$:  TYPE     ,SQUES        ;;TYPE ?<CR><LF>
6900 034256 000720          BR     20$             ;;SIMULATE CONTROL-U
6901
6902
6903
6904
6905
6906
6907
6908
6909
6910
6911
6912 034260 011646          $RDCHR: MOV    (SP),-(SP)  ;;PUSH DOWN THE PC AND
6913 034262 016666 000004      000002  MOV    4(SP),2(SP)     ;;THE PS
6914 034270 005066 000004          CLR    4(SP)           ;;GET READY FOR A CHARACTER
6915 034274 005046          CLR    -(SP)          ;;PUT NEW PS ON STACK
6916 034276 012746 034304          MOV    #64$,-(SP)     ;;PUT NEW PC ON STACK
6917 034302 000002          RTI                    ;;POP NEW PC AND PS
6918 034304
6919 034304 005737 033406      64$:  TST     $TKCNT         ;;WAIT ON A CHARACTER
6920 034310 001775          1$:  BEQ     1$              ;;
6921 034312 005337 033406          DEC    $TKCNT         ;;DECREMENT THE COUNTER
6922 034316 117766 177070      000004  MOVB   @$TKQOUT,4(SP)  ;;GET ONE CHARACTER
6923 034324 005237 033412          INC    $TKQOUT        ;;UPDATE THE POINTER
6924 034330 023727 033412      033415  CMP    $TKQOUT,#$TKQEND ;;DID IT GO OFF OF THE END?
6925 034336 001003          BNE    2$              ;;BRANCH IF NO
6926 034340 012737 033414      033412  MOV    #1,$TKQOUT     ;;RESET THE POINTER
6927 034346 000002          2$:  RTI                    ;;RETURN
6928
6929
6930
6931
6932
6933
6934

```

```

*****
*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
*CALL:
*   RDCHR          ;;GET A CHARACTER FROM THE QUEUE
*   RETURN HERE    ;;CHARACTER IS ON THE STACK
*                  ;;WITH PARITY BIT STRIPPED OFF
*****

```

```

*****
*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
*CALL:
*   RDLIN          ;;INPUT A STRING FROM THE TTY
*   RETURN HERE    ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
*                  ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
*****

```

6935	034350	010346			SRDLIN: MOV	R3,-(SP)	::SAVE R3
6936	034352	005046			CLR	-(SP)	::CLEAR THE RUBOUT KEY
6937	034354	012703	034604		1\$: MOV	#\$TTYIN,R3	::GET ADDRESS
6938	034360	022703	034626		2\$: CMP	#\$TTYIN+22,R3	::BUFFER FULL?
6939	034364	101456			BLOS	4\$::BR IF YES
6940	034366	104410			RDCHR		::GO READ ONE CHARACTER FROM THE TTY
6941	034370	112613			MOV	(SP)+,(R3)	::GET CHARACTER
6942	034372	122713	000177		10\$: CMPB	#177,(R3)	::IS IT A RUBOUT
6943	034376	001022			BNE	5\$::BR IF NO
6944	034400	005716			TST	(SP)	::IS THIS THE FIRST RUBOUT?
6945	034402	001007			BNE	6\$::BR IF NO
6946	034404	112737	000134	034602	MOV	#'\,9\$::TYPE A BACK SLASH
6947	034412	104401	034602		TYPE	,9\$	
6948	034416	012716	177777		MOV	#-1,(SP)	::SET THE RUBOUT KEY
6949	034422	005303			6\$: DEC	R3	::BACKUP BY ONE
6950	034424	020327	034604		CMP	R3,\$\$TTYIN	::STACK EMPTY?
6951	034430	103434			BLO	4\$::BR IF YES
6952	034432	111337	034602		MOV	(R3),9\$::SETUP TO TYPEOUT THE DELETED CHAR.
6953	034436	104401	034602		TYPE	,9\$::GO TYPE
6954	034442	000746			BR	2\$::GO READ ANOTHER CHAR.
6955	034444	005716			5\$: TST	(SP)	::RUBOUT KEY SET?
6956	034446	001406			BEQ	7\$::BR IF NO
6957	034450	112737	000134	034602	MOV	#'\,9\$::TYPE A BACK SLASH
6958	034456	104401	034602		TYPE	,9\$	
6959	034462	005016			CLR	(SP)	::CLEAR THE RUBOUT KEY
6960	034464	122713	000025		7\$: CMPB	#25,(R3)	::IS CHARACTER A CTRL U?
6961	034470	001003			BNE	8\$::BR IF NO
6962	034472	104401	034633		TYPE	,SCNTLU	::TYPE A CONTROL 'U'
6963	034476	000726			BR	1\$::GO START OVER
6964	034500	122713	000022		8\$: CMPB	#22,(R3)	::IS CHARACTER A 'R'?
6965	034504	001011			BNE	3\$::BRANCH IF NO
6966	034506	105013			CLRB	(R3)	::CLEAR THE CHARACTER
6967	034510	104401	001205		TYPE	,\$CRLF	::TYPE A 'CR' & 'LF'
6968	034514	104401	034604		TYPE	,\$TTYIN	::TYPE THE INPUT STRING
6969	034520	000717			BR	2\$::GO PICKUP ANOTHER CHARACTER
6970	034522	104401	001204		4\$: TYPE	,\$QUES	::TYPE A '?'
6971	034526	000712			BR	1\$::CLEAR THE BUFFER AND LOOP
6972	034530	111337	034602		3\$: MOV	(R3),9\$::ECHO THE CHARACTER
6973	034534	104401	034602		TYPE	,9\$	
6974	034540	122723	000015		CMPB	#15,(R3)+	::CHECK FOR RETURN
6975	034544	001305			BNE	2\$::LOOP IF NOT RETURN
6976	034546	105063	177777		CLRB	-1(R3)	::CLEAR RETURN (THE 15)
6977	034552	104401	001206		TYPE	,\$LF	::TYPE A LINE FEED
6978	034556	005726			TST	(SP)+	::CLEAN RUBOUT KEY FROM THE STACK
6979	034560	012603			MOV	(SP)+,R3	::RESTORE R3
6980	034562	011646			MOV	(SP)-,(SP)	::ADJUST THE STACK AND PUT ADDRESS OF THE
6981	034564	016666	000004	000002	MOV	4(SP),2(SP)	::FIRST ASCII CHARACTER ON IT
6982	034572	012766	034604	000004	MOV	#\$TTYIN,4(SP)	
6983	034600	000002			RTI		::RETURN
6984	034602	000			9\$: .BYTE	0	::STORAGE FOR ASCII CHAR. TO TYPE
6985	034603	000			.BYTE	0	::TERMINATOR
6986	034604	000022			STTYIN: .BLKB	22	::RESERVE 22 BYTES FOR TTY INPUT
6987	034626	041536	005015	000	SCNTLC: .ASCIZ	/'^C/<15><12>	::CONTROL 'C'
6988	034633	136	006525	000012	SCNTLU: .ASCIZ	/'^U/<15><12>	::CONTROL 'U'
6989	034640	043536	005015	000	SCNTLG: .ASCIZ	/'^G/<15><12>	::CONTROL 'G'
6990	034645	015	051412	051127	\$MSWR: .ASCIZ	<15><12>/SWR = /	


```

6991 034652 036440 000040
6992 034656 020040 042516 020127 $MNEW: .ASCIZ / NEW = /
6993 034664 020075 000
6994 034670
6995
6996
6997
6998
6999
7000
7001
7002
7003
7004
7005
7006
7007
7008
7009 034670 011646 000004 000002 $RDOCT: MOV (SP),-(SP) ;;PROVIDE SPACE FOR THE
7010 034672 016666 MOV 4(SP),2(SP) ;;INPUT NUMBER
7011 034700 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
7012 034702 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
7013 034704 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
7014 034706 104411 1$: RDLIN ;;READ AN ASCIZ LINE
7015 034710 012600 MOV (SP)+,R0 ;;GET ADDRESS OF 1ST CHARACTER
7016 034712 010037 035016 MOV R0,5$ ;;AND SAVE IT
7017 034716 005001 CLR R1 ;;CLEAR DATA WORD
7018 034720 005002 CLR R2
7019 034722 112046 2$: MOV (R0)+,-(SP) ;;PICKUP THIS CHARACTER
7020 034724 001420 BEQ 3$ ;;IF ZERO GET OUT
7021 034726 122716 000060 CMPB #'0,(SP) ;;MAKE SURE THIS CHARACTER
7022 034732 003026 BGT 4$ ;;IS AN OCTAL DIGIT
7023 034734 122716 000067 CMPB #'7,(SP)
7024 034740 002423 BLT 4$
7025 034742 006301 ASL R1 ;;*2
7026 034744 006102 ROL R2
7027 034746 006301 ASL R1 ;;*4
7028 034750 006102 ROL R2
7029 034752 006301 ASL R1 ;;*8
7030 034754 006102 ROL R2
7031 034756 042716 177770 BIC #'C7,(SP) ;;STRIP THE ASCII JUNK
7032 034762 062601 ADD (SP)+,R1 ;;ADD IN THIS DIGIT
7033 034764 000756 BR 2$ ;;LOOP
7034 034766 005726 3$: TST (SP)+ ;;CLEAN TERMINATOR FROM STACK
7035 034770 010166 000012 MOV R1,12(SP) ;;SAVE THE RESULT
7036 034774 010237 035026 MOV R2,$HI OCT
7037 035000 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
7038 035002 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
7039 035004 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
7040 035006 000002 RTI ;;RETURN
7041 035010 005726 4$: TST (SP)+ ;;CLEAN PARTIAL FROM STACK
7042 035012 105010 CLRB (R0) ;;SET A TERMINATOR
7043 035014 104401 TYPE ;;TYPE UP THRU THE BAD CHAR.
7044 035016 000000 5$: .WORD 0
7045 035020 104401 001204 TYPE $QUES ;;'"' 'CR' & 'LF'
7046 035024 000730 BR 1$ ;;TRY AGAIN
    
```

7047 035026 000000
7048
7049
7050
7051
7052
7053
7054
7055
7056
7057
7058
7059 035030 104413
7060 035032 016601 000002
7061 035036 012705 035147
7062 035042 012704 000014
7063 035046 012703 177770
7064 035052 012100
7065 035054 012101
7066 035056 005002
7067 035060 110245
7068 035062 010002
7069 035064 005304
7070 035066 003007
7071 035070 001405
7072 035072 005205
7073 035074 010566 000002
7074 035100 104414
7075 035102 000207
7076 035104 006203
7077 035106 006001
7078 035110 006000
7079 035112 006001
7080 035114 006000
7081 035116 006001
7082 035120 006000
7083 035122 040302
7084 035124 062702 000060
7085 035130 000753
7086 035132 000016
7087
7088
7089
7090
7091
7092
7093
7094
7095
7096
7097
7098
7099
7100 035150 104413
7101 035152 016602 000002
7102 035156 012700 035330

```
$HI OCT: .WORD 0 ;;HIGH ORDER BITS GO HERE
.SBTTL DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE

*****
*THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
*UNSIGNED OCTAL ASCII NUMBER.
*CALL
*   MOV    #PNTR,-(SP)    ;;POINTER TO LOW WORD OF BINARY NUMBER
*   JSR    PC,@#$DB20    ;;CALL THE ROUTINE
*   RETURN                ;;THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK

$DB20: SAVREG                ;;SAVE ALL REGISTERS
MOV     2(SP),R1           ;;PICKUP THE POINTER TO LOW WORD
MOV     #SOCTVL+13.,R5    ;;POINTER TO DATA TABLE
MOV     #12.,R4           ;;DO ELEVEN CHARACTERS
MOV     #^C7,R3          ;;MASK
MOV     (R1)+,R0         ;;LOWER WORD
MOV     (R1)+,R1         ;;HIGH WORD
CLR     R2               ;;TERMINATOR
1$:     MOVB   R2,-(R5)    ;;PUT CHARACTER IN DATA TABLE
MOV     R0,R2           ;;GET THIS DIGIT
DEC     R4              ;;COUNT THIS CHARACTER
BGT     3$             ;;BR IF NOT THE LAST DIGIT
BEQ     2$             ;;BR IF IT IS THE LAST DIGIT
INC     R5              ;;ALL DIGITS DONE-ADJUST POINTER FOR FIRST
MOV     R5,2(SP)        ;;ASCII CHAR. & PUT IT ON THE STACK
RESREG                ;;RESTORE ALL REGISTERS
RTS     PC              ;;RETURN TO USER
2$:     ASR     R3          ;;POSITION THE MASK FOR THE LAST DIGIT
3$:     ROR     R1          ;;POSITION THE BINARY NUMBER FOR
;;           THE NEXT OCTAL DIGIT

SOCTVL: .BLKB 14.        ;;RESERVE DATA TABLE
.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

*****
*THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
*DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
*POSITIVE.
*CALL
*   MOV    #PNTR,-(SP)    ;;POINTER TO LOW WORD OF BINARY NUMBER
*   JSR    PC,@#$DB20    ;;CALL THE ROUTINE
*   RETURN                ;;THE FIRST ADDRESS OF ASCII
;;           IS ON THE STACK

$DB2D: SAVREG                ;;SAVE REGISTERS
MOV     2(SP),R2         ;;PICKUP THE DATA POINTER
MOV     #$DECVL,R0      ;;GET ADDRESS OF '$DECVL' STRING
```



```

7103 035162 010066 000002          MOV     R0,2(SP)      ;;PUT ADDRESS OF ASCIZ STRING ON STACK
7104 035166 012201          MOV     (R2)+,R1     ;;PICKUP THE BINARY NUMBER
7105 035170 012202          MOV     (R2)+,R2
7106 035172 012737 000012 035246  MOV     #10,4$      ;;SET UP TO DO 10 CONVERSIONS
7107 035200 012704 035260  MOV     #$STNPWR,R4  ;;ADDRESS OF TEN POWER
7108 035204 012705 035262  MOV     #$STNPWR+2,R5
7109 035210 005003          1$: CLR     R3        ;;CLEAR PARTIAL
7110 035212 161401          2$: SUB     (R4),R1    ;;SUBTRACT TEN POWER
7111 035214 005602          SBC     R2
7112 035216 161502          SUB     (R5),R2
7113 035220 002402          BLT     3$          ;;BR IF TEN POWER TO LARGE
7114 035222 005203          INC     R3        ;;ADD 1 TO PARTIAL
7115 035224 000772          BR      2$        ;;LOOP
7116 035226 062401          3$: ADD     (R4)+,R1  ;;RESTORE SUBTRACTED VALUE
7117 035230 005502          ADC     R2
7118 035232 062402          ADD     (R4)+,R2
7119 035234 022525          CMP     (R5)+,(R5)+ ;;MOVE TO NEXT TEN POWER
7120 035236 052703 000060  BIS     #'0,R3     ;;CHANGE PARTIAL TO ASCII
7121 035242 110320          MOVB   R3,(R0)+   ;;SAVE IT
7122 035244 005327          DEC     (PC)+     ;;DONE?
7123 035246 000000          4$: .WORD 0
7124 035250 001357          BNE    1$        ;;BR IF NO
7125 035252 105020          CLRB   (R0)+     ;;TERMINATOR
7126 035254 104414          RESREG ;;RESTORE REGISTERS
7127 035256 000207          RTS    PC        ;;RETURN
7128 035260 145000          $STNPWR: 145000   ;;1.0E09
7129 035262 035632          35632
7130 035264 160400          160400          ;;1.0E08
7131 035266 002765          2765
7132 035270 113200          113200          ;;1.0E07
7133 035272 000230          230
7134 035274 041100          041100          ;;1.0E06
7135 035276 000017          17
7136 035300 103240          103240          ;;1.0E05
7137 035302 000001          1
7138 035304 023420          23420          ;;1.0E04
7139 035306 000000          0
7140 035310 001750          1750          ;;1.0E03
7141 035312 000000          0
7142 035314 000144          144          ;;1.0E02
7143 035316 000000          0
7144 035320 000012          12          ;;1.0E01
7145 035322 000000          0
7146 035324 000001          1          ;;1.0E00
7147 035326 000000          0
7148 035330 000014          $DECVL: .BLKB 12. ;;RESERVE STORAGE FOR ASCIZ STRING
7149          .SBTTL SINGLE LENGTH BINARY TO DECIMAL ASCII ROUTINE
7150
7151          ;;*****
7152          ;;THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
7153          ;;UNSIGNED DECIMAL ASCII NUMBER.
7154          ;;CALL
7155          ;;      MOV     NUMBER,-(SP)  ;;PUT BINARY NUMBER ON THE STACK
7156          ;;      JSR     PC,@#$SB2D  ;;CALL
7157          ;;      RETURN                ;;ADDRESS OF THE 1ST ASCII CHAR.IS ON THE STACK
7158
    
```

```

7159
7160 035344 016637 000002 035374 $SB2D: MOV 2(SP),1$      ;;SAVE BINARY NUMBER
7161 035352 012746 035374      MOV #1$,-(SP)      ;;SET POINTER
7162 035356 004737 035150      JSR PC,@#$DB2D    ;;CALL DOUBLE LENGTH CONVERT
7163 035362 062716 000005      ADD #5,(SP)       ;;ONLY ALLOW FIVE CHARACTERS
7164 035366 012666 000002      MOV (SP)+,2(SP)   ;;PICKUP POINTER
7165 035372 000207                RTS PC            ;;RETURN
7166 035374 000000 000000      1$: .WORD 0,0
7167      .SBTTL TYPE NUMERICAL ASCIZ STRING SUPPRESS LEADING ZEROS
7168
7169      ;*****
7170      ;*THIS ROUTINE IS USED TO TYPE AN ASCIZ NUMBER SUPPRESSING THE
7171      ;*LEADING NUMBERS.*
7172      ;*CALL
7173      ;*   MOV #NUMADR,-(SP)      ;;FIRST ADDRESS OF ASCIZ STRING
7174      ;*   JSR PC,@#$SUPRS
7175
7176
7177 035400 010046                $SUPRS: MOV R0,-(SP)      ;;SAVE R0
7178 035402 016600 000004      MOV 4(SP),R0      ;;PICKUP THE POINTER
7179 035406 105710                1$: TSTB (R0)         ;;TERMINATEOR?
7180 035410 001403                BEQ 2$            ;;BR IF YES
7181 035412 122720 000060      CMPB #'0,(R0)+    ;;IS THIS AN ASCII '0' ?
7182 035416 001773                BEQ 1$            ;;BR IF YES
7183 035420 005300                2$: DEC R0         ;;BACKUP BY '1'
7184 035422 010037 035430      MOV R0,3$         ;;SAVE FOR TYPING
7185 035426 104401                TYPE            ;;GO TYPE
7186 035430 000000                3$: .WORD 0       ;;ASCIZ POINTER GOES HERE
7187 035432 012600                MOV (SP)+,R0      ;;RESTORE R0
7188 035434 012616                MOV (SP)+,(SP)    ;;RESTORE THE STACK
7189 035436 000207                RTS PC            ;;RETURN
7190      .SBTTL INTEGER MULTIPLY ROUTINE
7191
7192      ;*****
7193      ;*CALL
7194      ;*   MOV MULTIPLER,-(SP)
7195      ;*   MOV MULTIPLICAND,-(SP)
7196      ;*   JSR PC,@#$MULT
7197      ;*   RETURN ;;PRODUCT IS ON THE STACK
7198
7199      ;*   STACK PRODUCT
7200      ;*   -----
7201      ;*   TOP      LSB'S
7202      ;*   +2      MSB'S
7203
7204 035440                $MULT:
7205 035440 010046                MOV R0,-(SP)      ;;PUSH R0 ON STACK
7206 035442 010146                MOV R1,-(SP)      ;;PUSH R1 ON STACK
7207 035444 010246                MOV R2,-(SP)      ;;PUSH R2 ON STACK
7208 035446 005046                CLR -(SP)         ;;CLEAR THE SIGN KEY
7209 035450 016601 000012      MOV 12(SP),R1     ;;GET THE MULTIPLICAND
7210 035454 100002                BPL 1$            ;;BR IF PLUS
7211 035456 005216                INC (SP)          ;;SET THE SIGN KEY
7212 035460 005401                NEG R1            ;;MAKE THE MULTIPLICAND POSTIVE
7213 035462 016602 000014      1$: MOV 14(SP),R2    ;;GET THE MULTIPLIER
7214 035466 100002                BPL 2$            ;;BR IF PLUS
    
```



```

7215 035470 005316          DEC      (SP)          ;;UPDATE THE SIGN KEY
7216 035472 005402          NEG      R2            ;;MAKE THE MULTIPLIER POSTIVE
7217 035474 012746 000021  2$:      MOV      #17,-(SP)  ;;SET THE LOOP COUNT
7218 035500 005000          CLR      R0            ;;SETUP FOR THE MULTIPLY LOOP
7219 035502 103001          3$:      BCC      4$      ;;DON'T ADD IF MULTIPLICAND = 0
7220 035504 060200          ADD      R2,R0
7221 035506 006000          4$:      ROR      R0
7222 035510 006001          ROR      R1            ;;POSITION THE PARITIAL PRODUCT AND
7223 035512 005316          DEC      (SP)          ;;THE MULTIPLICAND
7224 035514 001372          BNE      3$           ;;HAS ALL BITS OF THE MULTIPLICAND BEEN DONE?
7225 035516 022616          CMP      (SP)+,(SP)   ;;BR IF NO
7226 035520 001403          BEQ      5$           ;;SHOULD PRODUCT BE NEGATIVE?
7227 035522 005400          NEG      R0            ;;GO TO EXIT IF NO
7228 035524 005401          NEG      R1            ;;YES--SO MAKE IT SO
7229 035526 005600          SBC      R0
7230 035530 005726          5$:      TST      (SP)+      ;;CLEAR SIGN INFO. OFF OF STACK
7231 035532 010066 000012  MOV      R0,12(SP)    ;;PUT THE PRODUCT ON THE STACK (MSB'S)
7232 035536 010166 000010  MOV      R1,10(SP)    ;;LSB'S
7233 035542 012602          MOV      (SP)+,R2     ;;POP STACK INTO R2
7234 035544 012601          MOV      (SP)+,R1     ;;POP STACK INTO R1
7235 035546 012600          MOV      (SP)+,R0     ;;POP STACK INTO R0
7236 035550 000207          RTS      PC
    
```

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES

```

;*SAVE R0-R5
;*CALL:
;* SAVREG
;*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
;*
;*TOP---(+16)
;* +2---(+18)
;* +4---R5
;* +6---R4
;* +8---R3
;*+10---R2
;*+12---R1
;*+14---R0
    
```

```

$SAVREG:
MOV      R0,-(SP)      ;;PUSH R0 ON STACK
MOV      R1,-(SP)      ;;PUSH R1 ON STACK
MOV      R2,-(SP)      ;;PUSH R2 ON STACK
MOV      R3,-(SP)      ;;PUSH R3 ON STACK
MOV      R4,-(SP)      ;;PUSH R4 ON STACK
MOV      R5,-(SP)      ;;PUSH R5 ON STACK
MOV      22(SP),-(SP)  ;;SAVE PS OF MAIN FLOW
MOV      22(SP),-(SP)  ;;SAVE PC OF MAIN FLOW
MOV      22(SP),-(SP)  ;;SAVE PS OF CALL
MOV      22(SP),-(SP)  ;;SAVE PC OF CALL
RTI
    
```

```

;*RESTORE R0-R5
;*CALL:
;* RESREG
$RESREG:
    
```

```

7254 035552          010046
7255 035552 010046
7256 035554 010146
7257 035556 010246
7258 035560 010346
7259 035562 010446
7260 035564 010546
7261 035566 016646 000022
7262 035572 016646 000022
7263 035576 016646 000022
7264 035602 016646 000022
7265 035606 000002
7266
7267
7268
7269
7270 035610
    
```

```

7271 035610 012666 000022      MOV      (SP)+,22(SP)      ;;RESTORE PC OF CALL
7272 035614 012666 000022      MOV      (SP)+,22(SP)      ;;RESTORE PS OF CALL
7273 035620 012666 000022      MOV      (SP)+,22(SP)      ;;RESTORE PC OF MAIN FLOW
7274 035624 012666 000022      MOV      (SP)+,22(SP)      ;;RESTORE PS OF MAIN FLOW
7275 035630 012605                MOV      (SP)+,R5          ;;POP STACK INTO R5
7276 035632 012604                MOV      (SP)+,R4          ;;POP STACK INTO R4
7277 035634 012603                MOV      (SP)+,R3          ;;POP STACK INTO R3
7278 035636 012602                MOV      (SP)+,R2          ;;POP STACK INTO R2
7279 035640 012601                MOV      (SP)+,R1          ;;POP STACK INTO R1
7280 035642 012600                MOV      (SP)+,R0          ;;POP STACK INTO R0
7281 035644 000002                RTI
    
```

.SBTTL TRAP DECODER

```

*****
*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
*GO TO THAT ROUTINE.
    
```

```

7290 035646 010046                $TRAP:  MOV      R0,-(SP)      ;;SAVE R0
7291 035650 016600 000002        MOV      2(SP),R0          ;;GET TRAP ADDRESS
7292 035654 005740                TST      -(R0)            ;;BACKUP BY 2
7293 035656 111000                MOV      (R0),R0          ;;GET RIGHT BYTE OF TRAP
7294 035660 006300                ASL      R0                ;;POSITION FOR INDEXING
7295 035662 016000 035702        MOV      $TRPAD(R0),R0     ;;INDEX TO TABLE
7296 035666 000200                RTS      R0                ;;GO TO ROUTINE
    
```

;;THIS IS USE TO HANDLE THE "GETPRI" MACRO

```

7301 035670 011646                $TRAP2: MOV      (SP),-(SP)   ;;MOVE THE PC DOWN
7302 035672 016666 000004 000002  MOV      4(SP),2(SP)       ;;MOVE THE PSW DOWN
7303 035700 000002                RTI                        ;;RESTORE THE PSW
    
```

.SBTTL TRAP TABLE

```

*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
*BY THE "TRAP" INSTRUCTION.
    
```

```

:      ROUTINE
:      -----
7312 035702 035670                $TRPAD: .WORD   $TRAP2
7313 035704 032132                $TYPE   ;;CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
7314 035706 033204                $TYPOC  ;;CALL=TYPOC      TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
7315 035710 033160                $TYPOS  ;;CALL=TYPOS      TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
7316 035712 033220                $TYPON  ;;CALL=TYPON        TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
7317 035714 032466                $TYPDS  ;;CALL=TYPDS        TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)
7318
7319 035716 034006                $GTSWR  ;;CALL=GTSWR        TRAP+6(104406)  GET SOFT-SWR SETTING
7320
7321 035720 033716                $CKSWR  ;;CALL=CKSWR        TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
7322 035722 034260                $RDCHR  ;;CALL=RDCHR        TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
7323 035724 034350                $RDLIN  ;;CALL=RDLIN         TRAP+11(104411) TTY TYPEIN STRING ROUTINE
7324 035726 034670                $RDOCT  ;;CALL=RDOCT        TRAP+12(104412) READ AN OCTAL NUMBER FROM TTY
7325 035730 035552                $SAVREG ;;CALL=SAVREG        TRAP+13(104413) SAVE R0-R5 ROUTINE
7326 035732 035610                $RESREG ;;CALL=RESREG        TRAP+14(104414) RESTORE R0-R5 ROUTINE
    
```


CZR6JFO UNIBUS RK6 DR-3 MACY11 30(1046) 04-JAN-82 13:06 PAGE 141^{K 11}
CZR6JF.P11 04-JAN-82 12:48 TRAP TABLE

SEQ 0140

7327 035734 030360
7328

SCOP1\$;:CALL=SCOP1 TRAP+15(104415) INTERNAL LOOP ON ERROR

7329					
7330					.SBTTL SERVICE MESSAGES
7331					
7332					
7333	035736	005015	047125	041111	MSG1: .ASCII <CR><LF>/UNIBUS RK6 DR-3/
7334	035744	051525	051040	033113	
7335	035752	042040	026522	063	
7336	035757	015	041412	051132	.ASCII <CR><LF>/CZR6JFO/<CR><LF>
7337	035764	045066	030106	005015	
7338	035772	005015	025011	025052	.ASCII <CR><LF>/ ***** CAUTION *****/<CR><LF>
7339	036000	025052	041440	052501	
7340	036006	044524	047117	025040	
7341	036014	025052	025052	005015	
7342	036022	005015	044124	051511	.ASCII <CR><LF>/THIS PROGRAM SHOULD BE HALTED ONLY BY TYPING CONTROL-C/
7343	036030	050040	047522	051107	
7344	036036	046501	051440	047510	
7345	036044	046125	020104	041040	
7346	036052	020105	040510	052114	
7347	036060	042105	047440	046116	
7348	036066	020131	054502	052040	
7349	036074	050131	047111	020107	
7350	036102	047503	052116	047522	
7351	036110	026514	103		
7352	036113	015	047412	044124	.ASCII <CR><LF>/OTHERWISE CARTRIDGE FORMATTING AND, OR THE DEVICE/
7353	036120	051105	044527	042523	
7354	036126	041440	051101	051124	
7355	036134	042111	042507	043040	
7356	036142	051117	040515	052124	
7357	036150	047111	020107	047101	
7358	036156	026104	047440	020122	
7359	036164	044124	020105	042504	
7360	036172	044526	042503		
7361	036176	005015	040515	020131	.ASCII <CR><LF>/MAY BE LEFT IN AN UNDETERMINED STATE/<CR><LF>
7362	036204	042502	046040	043105	
7363	036212	020124	047111	040440	
7364	036220	020116	047125	042504	
7365	036226	042524	046522	047111	
7366	036234	042105	051440	040524	
7367	036242	042524	005015		
7368	036246	005015	047111	052111	.ASCII <CR><LF>/INITIALLY, DRIVES TO BE TESTED SHOULD HAVE: /<CR><LF>
7369	036254	040511	046114	026131	
7370	036262	042040	044522	042526	
7371	036270	020123	047524	041040	
7372	036276	020105	042524	052123	
7373	036304	042105	051440	047510	
7374	036312	046125	020104	040510	
7375	036320	042526	006472	012	
7376	036325	015	040412	020056	.ASCII <CR><LF>/A. HEADS MANUALLY LOADED/
7377	036332	042510	042101	020123	
7378	036340	040515	052516	046101	
7379	036346	054514	046040	040517	
7380	036354	042504	104		
7381	036357	015	041012	020056	.ASCII <CR><LF>/B. CORRECT PORT SELECTED/
7382	036364	047503	051122	041505	
7383	036372	020124	047520	052122	
7384	036400	051440	046105	041505	

7385	036406	042524	104		
7386	036411	015	041412	020056	.ASCII <CR><LF>/C. WRITE LOCK DISABLED/
7387	036416	051127	052111	020105	
7388	036424	047514	045503	042040	
7389	036432	051511	041101	042514	
7390	036440	104			
7391	036441	015	042012	020056	.ASCII <CR><LF>/D. DRIVE READY INDICATOR ON/<CR><LF>
7392	036446	051104	053111	020105	
7393	036454	042522	042101	020131	
7394	036462	047111	044504	040503	
7395	036470	047524	020122	047117	
7396	036476	005015			
7397	036500	005015	051104	053111	.ASCII <CR><LF>/DRIVES NOT TO BE TESTED MUST HAVE/
7398	036506	051505	047040	052117	
7399	036514	052040	020117	042502	
7400	036522	052040	051505	042524	
7401	036530	020104	052515	052123	
7402	036536	044040	053101	105	
7403	036543	015	041012	052117	.ASCIZ <CR><LF>/BOTH PORTS DESELECTED/<CR><LF>
7404	036550	020110	047520	052122	
7405	036556	020123	042504	042523	
7406	036564	042514	052103	042105	
7407	036572	005015	000		
7408					
7409	036575	015	041412	040510	MSG2: .ASCII <CR><LF>/CHANGE XXDP PACK/
7410	036602	043516	020105	054130	
7411	036610	050104	050040	041501	
7412	036616	113			
7413	036617	015	041412	042514	.ASCIZ <CR><LF>/CLEAR LOC 40,RESTART PROGRAM/
7414	036624	051101	046040	041517	
7415	036632	032040	026060	042522	
7416	036640	052123	051101	020124	
7417	036646	051120	043517	040522	
7418	036654	000115			
7419	036656	005015	051104	053111	MSG3: .ASCIZ <CR><LF>/DRIVE(S) TO BE TESTED: /
7420	036664	024105	024523	052040	
7421	036672	020117	042502	052040	
7422	036700	051505	042524	035104	
7423	036706	000040			
7424	036710	005015	054524	042520	MSG4: .ASCIZ <CR><LF>/TYPE BUSS ADDRESS IF NOT 177440: /
7425	036716	041040	051525	020123	
7426	036724	042101	051104	051505	
7427	036732	020123	043111	047040	
7428	036740	052117	030440	033467	
7429	036746	032064	035060	020040	
7430	036754	000			
7431	036755	015	052012	050131	MSG5: .ASCIZ <CR><LF>/TYPE CONTROLLER INTERRUPT VECTOR IF NOT 210: /
7432	036762	020105	047503	052116	
7433	036770	047522	046114	051105	
7434	036776	044440	052116	051105	
7435	037004	052522	052120	053040	
7436	037012	041505	047524	020122	
7437	037020	043111	047040	052117	
7438	037026	031040	030061	020072	
7439	037034	000040			
7440	037036	005015	047111	042524	MSG6: .ASCIZ <CR><LF>/INTERRJPT OCCURRED AT PC=/

7441	037044	051122	050125	020124	
7442	037052	041517	052503	051122	
7443	037060	042105	040440	020124	
7444	037066	041520	000075		
7445	037072	005015	051104	053111	MSG7: .ASCIZ <CR><LF>/DRIVE 0 WILL NOT BE TESTED/
7446	037100	020105	020060	044527	
7447	037106	046114	047040	052117	
7448	037114	041040	020105	042524	
7449	037122	052123	042105	000	
7450	037127	015	044412	052116	MSG8: .ASCIZ <CR><LF>/INTERLOCKS TEST/<CR><LF>
7451	037134	051105	047514	045503	
7452	037142	020123	042524	052123	
7453	037150	005015	000		
7454	037153	015	051012	046505	MSG9: .ASCIZ <CR><LF>/REMOVE UNIT SELECT PLUG/
7455	037160	053117	020105	047125	
7456	037166	052111	051440	046105	
7457	037174	041505	020124	046120	
7458	037202	043525	000		
7459	037205	015	005012	044527	MSG10: .ASCIZ <CR><LF><LF>/WILL TEST DRIVES:/
7460	037212	046114	052040	051505	
7461	037220	020124	051104	053111	
7462	037226	051505	000072		
7463	037232	005015	050012	053517	MSG11: .ASCIZ <CR><LF><LF>/POWER UP RESTART TO TEST 1/<CR><LF>
7464	037240	051105	052440	020120	
7465	037246	042522	052123	051101	
7466	037254	020124	047524	052040	
7467	037262	051505	020124	006461	
7468	037270	000012			
7469	037272	047516	042516	005015	MSG12: .ASCIZ /NONE/<CR><LF>
7470	037300	000			
7471	037301	015	047012	020117	MSG13: .ASCII <CR><LF>/NO L OR P CLOCKS PRESENT/
7472	037306	020114	051117	050040	
7473	037314	041440	047514	045503	
7474	037322	020123	051120	051505	
7475	037330	047105	124		
7476	037333	015	040412	046114	.ASCIZ <CR><LF>/ALL TIMING TESTS BYPASSED/
7477	037340	052040	046511	047111	
7478	037346	020107	042524	052123	
7479	037354	020123	054502	040520	
7480	037362	051523	042105	000	
7481	037367	015	041012	050131	MSG14: .ASCIZ <CR><LF>/BYPASSING DRIVE /
7482	037374	051501	044523	043516	
7483	037402	042040	044522	042526	
7484	037410	000040			
7485	037412	005015	042012	044522	MSG15: .ASCIZ <CR><LF><LF>/DRIVE /
7486	037420	042526	000040		
7487	037424	005015	051104	053111	MSG16: .ASCIZ <CR><LF>/DRIVE SERIAL NO. /
7488	037432	020105	042523	044522	
7489	037440	046101	047040	027117	
7490	037446	000040			
7491	037450	005015	040503	052122	MSG17: .ASCIZ <CR><LF>/CARTRIDGE SERIAL NO. /
7492	037456	044522	043504	020105	
7493	037464	042523	044522	046101	
7494	037472	047040	027117	000040	
7495	037500	005015	047125	052111	MSG18: .ASCIZ <CR><LF>/UNIT SELECT PLUG TEST/<CR><LF>
7496	037506	051440	046105	041505	

7497	037514	020124	046120	043525	
7498	037522	052040	051505	006524	
7499	037530	000012			
7500	037532	005015	047520	052122	MSG19: .ASCIZ <CR><LF>/PORT SELECTION TESTS/<CR><LF>
7501	037540	051440	046105	041505	
7502	037546	044524	047117	052040	
7503	037554	051505	051524	005015	
7504	037562	000			
7505	037563	015	040412	020103	MSG21: .ASCIZ <CR><LF>/AC LOW DETECTION TEST-PART 1/<CR><LF>
7506	037570	047514	020127	042504	
7507	037576	042524	052103	047511	
7508	037604	020116	042524	052123	
7509	037612	050055	051101	020124	
7510	037620	006461	000012		
7511	037624	005015	047516	026516	MSG22: .ASCIZ <CR><LF>/NON-EXECUTABLE FUNCTION (NXF) DETECTION TEST/<CR><LF>
7512	037632	054105	041505	052125	
7513	037640	041101	042514	043040	
7514	037646	047125	052103	047511	
7515	037654	020116	047050	043130	
7516	037662	020051	042504	042524	
7517	037670	052103	047511	020116	
7518	037676	042524	052123	005015	
7519	037704	000			
7520	037705	015	053412	044522	MSG24: .ASCIZ <CR><LF>/WRITE LOCK TEST/<CR><LF>
7521	037712	042524	046040	041517	
7522	037720	020113	042524	052123	
7523	037726	005015	000		
7524	037731	015	040412	020103	MSG26: .ASCIZ <CR><LF>/AC LOW DETECTION TEST-PART 2/<CR><LF>
7525	037736	047514	020127	042504	
7526	037744	042524	052103	047511	
7527	037752	020116	042524	052123	
7528	037760	050055	051101	020124	
7529	037766	006462	000012		
7530	037772	005015	040412	046114	MSG27: .ASCIZ <CR><LF><LF>/ALL DRIVES TESTED/<CR><LF><LF>
7531	040000	042040	044522	042526	
7532	040006	020123	042524	052123	
7533	040014	042105	005015	000012	
7534	040022	005015	052515	052114	MSG28: .ASCIZ <CR><LF>/MULTIPLE DRIVE DETECTION TEST/<CR><LF>
7535	040030	050111	042514	042040	
7536	040036	044522	042526	042040	
7537	040044	052105	041505	044524	
7538	040052	047117	052040	051505	
7539	040060	006524	000012		
7540	040064	005015	046120	040505	MSG29: .ASCIZ <CR><LF>/PLEASE WAIT, HEADS BEING LOADED/<CR><LF>
7541	040072	042523	053440	044501	
7542	040100	026124	044040	040505	
7543	040106	051504	041040	044505	
7544	040114	043516	046040	040517	
7545	040122	042504	006504	000012	
7546	040130	005015	042526	044522	MSG30: .ASCIZ <CR><LF>/VERIFY DOOR CAN NOW BE OPENED & LEAVE IT OPEN/<CR><LF>
7547	040136	054506	042040	047517	
7548	040144	020122	040503	020116	
7549	040152	047516	020127	042502	
7550	040160	047440	042520	042516	
7551	040166	020104	020046	042514	
7552	040174	053101	020105	052111	

7553	040202	047440	042520	006516	
7554	040210	000012			
7555	040212	005015	006477	000012	MSG31: .ASCIZ <CR><LF>/?/<CR><LF>
7556	040220	005015	042522	047515	MSG32: .ASCIZ <CR><LF>/REMOVE DISK PACK & CLOSE DOOR/
7557	040226	042526	042040	051511	
7558	040234	020113	040520	045503	
7559	040242	023040	041440	047514	
7560	040250	042523	042040	047517	
7561	040256	000122			
7562	040260	005015	042504	051120	MSG33: .ASCIZ <CR><LF>/DEPRESS 'RUN-STOP' SWITCH TO 'RUN' WHILE DOOR OPEN/
7563	040266	051505	020123	051047	
7564	040274	047125	051455	047524	
7565	040302	023520	051440	044527	
7566	040310	041524	020110	047524	
7567	040316	023440	052522	023516	
7568	040324	053440	044510	042514	
7569	040332	042040	047517	020122	
7570	040340	050117	047105	000	
7571	040345	015	053012	051105	MSG34: .ASCIZ <CR><LF>/VERIFY SPINDLE DOES NOT START & HEADS DO NOT LOAD/<CR><LF>
7572	040352	043111	020131	050123	
7573	040360	047111	046104	020105	
7574	040366	047504	051505	047040	
7575	040374	052117	051440	040524	
7576	040402	052122	023040	044040	
7577	040410	040505	051504	042040	
7578	040416	020117	047516	020124	
7579	040424	047514	042101	005015	
7580	040432	000			
7581	040433	015	042012	050105	MSG35: .ASCIZ <CR><LF>/DEPRESS 'RUN-STOP' SWITCH TO 'RUN' WHILE CARTRIDGE REMOVED/
7582	040440	042522	051523	023440	
7583	040446	052522	026516	052123	
7584	040454	050117	020047	053523	
7585	040462	052111	044103	052040	
7586	040470	020117	051047	047125	
7587	040476	020047	044127	046111	
7588	040504	020105	040503	052122	
7589	040512	044522	043504	020105	
7590	040520	042522	047515	042526	
7591	040526	000104			
7592	040530	005015	047111	042523	MSG36: .ASCIZ <CR><LF>/INSERT DISK PACK, DEPRESS 'RUN-STOP' TO 'RUN' & CLOSE DOOR/
7593	040536	052122	042040	051511	
7594	040544	020113	040520	045503	
7595	040552	020054	042504	051120	
7596	040560	051505	020123	051047	
7597	040566	047125	051455	047524	
7598	040574	023520	052040	020117	
7599	040602	051047	047125	020047	
7600	040610	020046	046103	051517	
7601	040616	020105	047504	051117	
7602	040624	000			
7603	040625	015	042012	050105	MSG37: .ASCIZ <CR><LF>/DEPRESS SPACE BAR WHEN FINISHED/<CR><LF>
7604	040632	042522	051523	051440	
7605	040640	040520	042503	041040	
7606	040646	051101	053440	042510	
7607	040654	020116	044506	044516	
7608	040662	044123	042105	005015	

7609	040670	000			
7610	040671	015	044412	051516	MSG38: .ASCII <CR><LF>/INSERT UNIT SELECT PLUGS, IN ANY ORDER/
7611	040676	051105	020124	047125	
7612	040704	052111	051440	046105	
7613	040712	041505	020124	046120	
7614	040720	043525	026123	044440	
7615	040726	020116	047101	020131	
7616	040734	051117	042504	122	
7617	040741	015	052012	042510	.ASCIZ <CR><LF>/THE PROGRAM WILL ECHO THE UNIT SELECT PLUG NUMBER/<CR><LF>
7618	040746	050040	047522	051107	
7619	040754	046501	053440	046111	
7620	040762	020114	041505	047510	
7621	040770	052040	042510	052440	
7622	040776	044516	020124	042523	
7623	041004	042514	052103	050040	
7624	041012	052514	020107	052516	
7625	041020	041115	051105	005015	
7626	041026	000			
7627	041027	015	042012	050105	MSG39: .ASCIZ <CR><LF>/DEPRESS CONTROL-E TO EXIT TEST/<CR><LF>
7628	041034	042522	051523	041440	
7629	041042	047117	051124	046117	
7630	041050	042455	052040	020117	
7631	041056	054105	052111	052040	
7632	041064	051505	006524	000012	
7633	041072	005015	047526	052514	MSG40: .ASCII <CR><LF>/VOLUME VALID NOT SET/
7634	041100	042515	053040	046101	
7635	041106	042111	047040	052117	
7636	041114	051440	052105		
7637	041120	005015	040515	042513	.ASCIZ <CR><LF>/MAKE SURE ORIGINAL UNIT SELECT PLUG IS INSERTED/<CR><LF>
7638	041126	051440	051125	020105	
7639	041134	051117	043511	047111	
7640	041142	046101	052440	044516	
7641	041150	020124	042523	042514	
7642	041156	052103	050040	052514	
7643	041164	020107	051511	044440	
7644	041172	051516	051105	042524	
7645	041200	006504	000012		
7646	041204	005015	042504	042523	MSG41: .ASCIZ <CR><LF>/DESELECT PORT IN USE & SELECT OPPOSITE PORT/<CR><LF>
7647	041212	042514	052103	050040	
7648	041220	051117	020124	047111	
7649	041226	052440	042523	023040	
7650	041234	051440	046105	041505	
7651	041242	020124	050117	047520	
7652	041250	044523	042524	050040	
7653	041256	051117	006524	000012	
7654	041264	005015	042504	042523	MSG42: .ASCIZ <CR><LF>/DESELECT WRONG PORT & SELECT CORRECT PORT/<CR><LF>
7655	041272	042514	052103	053440	
7656	041300	047522	043516	050040	
7657	041306	051117	020124	020046	
7658	041314	042523	042514	052103	
7659	041322	041440	051117	042522	
7660	041330	052103	050040	051117	
7661	041336	006524	000012		
7662	041342	005015	042504	042523	MSG43: .ASCIZ <CR><LF>/DESELECT BOTH PORTS/<CR><LF>
7663	041350	042514	052103	041040	
7664	041356	052117	020110	047520	

7665	041364	052122	006523	000012	
7666	041372	005015	042523	042514	MSG44: .ASCIZ <CR><LF>/SELECT CORRECT PORT/<CR><LF>
7667	041400	052103	041440	051117	
7668	041406	042522	052103	050040	
7669	041414	051117	006524	000012	
7670	041422	005015	047503	051122	MSG45: .ASCIZ <CR><LF>/CORRECT PORT NOT SELECTED, TRY AGAIN/<CR><LF>
7671	041430	041505	020124	047520	
7672	041436	052122	047040	052117	
7673	041444	051440	046105	041505	
7674	041452	042524	026104	052040	
7675	041460	054522	040440	040507	
7676	041466	047111	005015	000	
7677	041473	015	053012	051105	MSG47: .ASCIZ <CR><LF>/VERIFY DOOR CANNOT BE OPENED (DO NOT FORCE)/<CR><LF>
7678	041500	043111	020131	047504	
7679	041506	051117	041440	047101	
7680	041514	047516	020124	042502	
7681	041522	047440	042520	042516	
7682	041530	020104	042050	020117	
7683	041536	047516	020124	047506	
7684	041544	041522	024505	005015	
7685	041552	000			
7686	041553	015	052012	051125	MSG49: .ASCIZ <CR><LF>/TURN OFF AC POWER FROM BEHIND THE RK06/<CR><LF>
7687	041560	020116	043117	020106	
7688	041566	041501	050040	053517	
7689	041574	051105	043040	047522	
7690	041602	020115	042502	044510	
7691	041610	042116	052040	042510	
7692	041616	051040	030113	006466	
7693	041624	000012			
7694	041626	005015	040527	052111	MSG50: .ASCIZ <CR><LF>/WAIT 30 SEC & SWITCH AC POWER BACK ON/
7695	041634	031440	020060	042523	
7696	041642	020103	020046	053523	
7697	041650	052111	044103	040440	
7698	041656	020103	047520	042527	
7699	041664	020122	040502	045503	
7700	041672	047440	000116		
7701	041676	005015	047515	042515	MSG51: .ASCII <CR><LF>/MOMENTARILY REMOVE & INSERT THE SAME UNIT SELECT PLUG/
7702	041704	052116	051101	046111	
7703	041712	020131	042522	047515	
7704	041720	042526	023040	044440	
7705	041726	051516	051105	020124	
7706	041734	044124	020105	040523	
7707	041742	042515	052440	044516	
7708	041750	020124	042523	042514	
7709	041756	052103	050040	052514	
7710	041764	107			
7711	041765	015	052012	020117	.ASCIZ <CR><LF>/TO RESET VOLUME VALID/<CR><LF>
7712	041772	042522	042523	020124	
7713	042000	047526	052514	042515	
7714	042006	053040	046101	042111	
7715	042014	005015	000		
7716	042017	015	042012	050105	MSG52: .ASCII <CR><LF>/DEPRESS SPACE TO DO TEST/
7717	042024	042522	051523	051440	
7718	042032	040520	042503	052040	
7719	042040	020117	047504	052040	
7720	042046	051505	124		

7721	042051	015	047412	020122	
7722	042056	047503	052116	047522	.ASCIZ <CR><LF>/OR CONTROL-E TO BYPASS ENTIRE TEST/<CR><LF>
7723	042064	026514	020105	047524	
7724	042072	041040	050131	051501	
7725	042100	020123	047105	044524	
7726	042106	042522	052040	051505	
7727	042114	006524	000012		
7728	042120	005015	044504	040523	MSG53: .ASCIZ <CR><LF>/DISABLE THE WRITE LOCK SWITCH, VERIFY LIGHT GOES OFF/<CR><LF>
7729	042126	046102	020105	044124	
7730	042134	020105	051127	052111	
7731	042142	020105	047514	045503	
7732	042150	051440	044527	041524	
7733	042156	026110	053040	051105	
7734	042164	043111	020131	044514	
7735	042172	044107	020124	047507	
7736	042200	051505	047440	043106	
7737	042206	005015	000		
7738	042211	015	042412	040516	MSG54: .ASCIZ <CR><LF>/ENABLE THE WRITE LOCK SWITCH, VERIFY LIGHT GOES ON/<CR><LF>
7739	042216	046102	020105	044124	
7740	042224	020105	051127	052111	
7741	042232	020105	047514	045503	
7742	042240	051440	044527	041524	
7743	042246	026110	053040	051105	
7744	042254	043111	020131	044514	
7745	042262	044107	020124	047507	
7746	042270	051505	047440	006516	
7747	042276	000012			
7748	042300	005015	054105	052111	MSG55: .ASCIZ <CR><LF>/EXIT TEST WITH ORIGINAL UNIT SELECT PLUG NO. /
7749	042306	052040	051505	020124	
7750	042314	044527	044124	047440	
7751	042322	044522	044507	040516	
7752	042330	020114	047125	052111	
7753	042336	051440	046105	041505	
7754	042344	020124	046120	043525	
7755	042352	047040	027117	000040	
7756	042360	005015	046101	043511	MSG56: .ASCII <CR><LF>/ALIGNMENT CARTRIDGE USED/
7757	042366	046516	047105	020124	
7758	042374	040503	052122	044522	
7759	042402	043504	020105	051525	
7760	042410	042105			
7761	042412	005015	051120	043517	.ASCII <CR><LF>/PROGRAM WILL BYPASS THE WRITE LOCK TEST/
7762	042420	040522	020115	044527	
7763	042426	046114	041040	050131	
7764	042434	051501	020123	044124	
7765	042442	020105	051127	052111	
7766	042450	020105	047514	045503	
7767	042456	052040	051505	124	
7768	042463	015	040412	042116	.ASCIZ <CR><LF>/AND READ-WRITE DATA PORTION OF AC LOW DETECTION TEST-PART 2/<CR>
7769	042470	051040	040505	026504	
7770	042476	051127	052111	020105	
7771	042504	040504	040524	050040	
7772	042512	051117	044524	047117	
7773	042520	047440	020106	041501	
7774	042526	046040	053517	042040	
7775	042534	052105	041505	044524	
7776	042542	047117	052040	051505	

7777	042550	026524	040520	052122	
7778	042556	031040	005015	000012	
7779	042564	005015	042526	044522	MSG57: .ASCIZ <CR><LF>/VERIFY BATTERY RETRACT FUNCTIONAL/<CR><LF>
7780	042572	054506	041040	052101	
7781	042600	042524	054522	051040	
7782	042606	052105	040522	052103	
7783	042614	043040	047125	052103	
7784	042622	047511	040516	006514	
7785	042630	000012			
7786	042632	005015	047514	042101	MSG58: .ASCIZ <CR><LF>/LOAD HEADS ON ALL DRIVES TO BE TESTED FOR MDS/<CR><LF>
7787	042640	044040	040505	051504	
7788	042646	047440	020116	046101	
7789	042654	020114	051104	053111	
7790	042662	051505	052040	020117	
7791	042670	042502	052040	051505	
7792	042676	042524	020104	047506	
7793	042704	020122	042115	006523	
7794	042712	000012			
7795	042714	005015	047111	042523	MSG59: .ASCIZ <CR><LF>/INSERT SAME UNIT SELECT PLUG NUMBER IN ANY 2 DRIVES TO BE TESTE
7796	042722	052122	051440	046501	
7797	042730	020105	047125	052111	
7798	042736	051440	046105	041505	
7799	042744	020124	046120	043525	
7800	042752	047040	046525	042502	
7801	042760	020122	047111	040440	
7802	042766	054516	031040	042040	
7803	042774	044522	042526	020123	
7804	043002	047524	041040	020105	
7805	043010	042524	052123	042105	
7806	043016	000			
7807	043017	015	044412	051516	MSG60: .ASCII <CR><LF>/INSERT CORRECT UNIT SELECT PLUGS & LOAD HEADS/
7808	043024	051105	020124	047503	
7809	043032	051122	041505	020124	
7810	043040	047125	052111	051440	
7811	043046	046105	041505	020124	
7812	043054	046120	043525	020123	
7813	043062	020046	047514	042101	
7814	043070	044040	040505	051504	
7815	043076	005015	047117	050040	.ASCIZ <CR><LF>/ON PREVIOUS 2 DRIVES/<CR><LF>
7816	043104	042522	044526	052517	
7817	043112	020123	020062	051104	
7818	043120	053111	051505	005015	
7819	043126	000			
7820	043127	015	046412	046125	MSG61: .ASCIZ <CR><LF>/MULTIPLE DRIVES FOUND ON DRIVE NO. /
7821	043134	044524	046120	020105	
7822	043142	051104	053111	051505	
7823	043150	043040	052517	042116	
7824	043156	047440	020116	051104	
7825	043164	053111	020105	047516	
7826	043172	020056	000		
7827	043175	015	041012	050131	MSG62: .ASCII <CR><LF>/BYPASSING MULT. DRIVE SELECT TEST/
7828	043202	051501	044523	043516	
7829	043210	046440	046125	027124	
7830	043216	042040	044522	042526	
7831	043224	051440	046105	041505	
7832	043232	020124	042524	052123	

7833	043240	005015	047117	054514		.ASCIZ <CR><LF>/ONLY 1 DRIVE PRESENT/<CR><LF>
7834	043246	030440	042040	044522		
7835	043254	042526	050040	042522		
7836	043262	042523	052116	005015		
7837	043270	000				
7838	043271	015	042012	050105	MSG63:	.ASCII <CR><LF>/DEPRESS SPACE BAR TO DO ANOTHER 2 DRIVES/
7839	043276	042522	051523	051440		
7840	043304	040520	042503	041040		
7841	043312	051101	052040	020117		
7842	043320	047504	040440	047516		
7843	043326	044124	051105	031040		
7844	043334	042040	044522	042526		
7845	043342	123				
7846	043343	015	047412	020122		.ASCII <CR><LF>/OR CONTROL-E TO EXIT TEST/
7847	043350	047503	052116	047522		
7848	043356	026514	020105	047524		
7849	043364	042440	044530	020124		
7850	043372	042524	052123			
7851	043376	005015	044450	051516		.ASCIZ <CR><LF>/((INSERT CORRECT UNIT SELECT PLUGS BEFORE EXITING))<CR><LF>
7852	043404	051105	020124	047503		
7853	043412	051122	041505	020124		
7854	043420	047125	052111	051440		
7855	043426	046105	041505	020124		
7856	043434	046120	043525	020123		
7857	043442	042502	047506	042522		
7858	043450	042440	044530	044524		
7859	043456	043516	006451	000012		
7860	043464	005015	042504	051120	MSG65:	.ASCIZ <CR><LF>/DEPRESS 'RUN-STOP' SWITCH TO 'STOP'/'
7861	043472	051505	020123	051047		
7862	043500	047125	051455	047524		
7863	043506	023520	051440	044527		
7864	043514	041524	020110	047524		
7865	043522	023440	052123	050117		
7866	043530	000047				
7867	043532	005015	042504	042523	MSG67:	.ASCIZ <CR><LF>/DESELECT PORT SWITCH ON ALL OTHER DRIVES/<CR><LF>
7868	043540	042514	052103	050040		
7869	043546	051117	020124	053523		
7870	043554	052111	044103	047440		
7871	043562	020116	046101	020114		
7872	043570	052117	042510	020122		
7873	043576	051104	053111	051505		
7874	043604	005015	000			
7875	043607	015	053012	051105	MSG68:	.ASCIZ <CR><LF>/VERIFY BOTH DRIVES UNLOADED/<CR><LF>
7876	043614	043111	020131	047502		
7877	043622	044124	042040	044522		
7878	043630	042526	020123	047125		
7879	043636	047514	042101	042105		
7880	043644	005015	000			
7881	043647	015	042012	050105	MSG69:	.ASCIZ <CR><LF>/DEPRESS SPACE WHEN 'READY' LIGHT GOES ON/<CR><LF>
7882	043654	042522	051523	051440		
7883	043662	040520	042503	053440		
7884	043670	042510	020116	051047		
7885	043676	040505	054504	020047		
7886	043704	044514	044107	020124		
7887	043712	047507	051505	047440		
7888	043720	006516	000012			

7889	043724	005015	042526	044522	MSG70: .ASCIZ <CR><LF>/VERIFY HEADS LOAD/<CR><LF>
7890	043732	054506	044040	040505	
7891	043740	051504	046040	040517	
7892	043746	006504	000012		
7893	043752	005015	042523	042514	MSG71: .ASCIZ <CR><LF>/SELECT CORRECT PORT SWITCH ON ALL OTHER DRIVES/<CR><LF>
7894	043760	052103	041440	051117	
7895	043766	042522	052103	050040	
7896	043774	051117	020124	053523	
7897	044002	052111	044103	047440	
7898	044010	020116	046101	020114	
7899	044016	052117	042510	020122	
7900	044024	051104	053111	051505	
7901	044032	005015	000		
7902	044035	015	040412	047502	MSG72: .ASCIZ <CR><LF>/ABORTING BALANCE OF TESTS/
7903	044042	052122	047111	020107	
7904	044050	040502	040514	041516	
7905	044056	020105	043117	052040	
7906	044064	051505	051524	000	
7907					
7908	044071	015	050012	047522	MSG74: .ASCIZ <CR><LF>/PROGRAM ABORT PENDING...PLEASE WAIT/
7909	044076	051107	046501	040440	
7910	044104	047502	052122	050040	
7911	044112	047105	044504	043516	
7912	044120	027056	050056	042514	
7913	044126	051501	020105	040527	
7914	044134	052111	000		
7915	044137	015	044012	046101	MSG75: .ASCIZ <CR><LF>/HALT PENDING...PLEASE WAIT/
7916	044144	020124	042520	042116	
7917	044152	047111	027107	027056	
7918	044160	046120	040505	042523	
7919	044166	053440	044501	000124	
7920	044174	005015	051120	043517	MSG76: .ASCIZ <CR><LF>/PROGRAM ABORTED/
7921	044202	040522	020115	041101	
7922	044210	051117	042524	000104	
7923	044216	005015	050103	020125	MSG77: .ASCIZ <CR><LF>/CPU HALTED/
7924	044224	040510	052114	042105	
7925	044232	000			
7926	044233	015	051412	051117	MSG100: .ASCII <CR><LF>/SORRY, WRITE LOCK SHOULD NOT BE DEPRESSED/
7927	044240	054522	020054	051127	
7928	044246	052111	020105	047514	
7929	044254	045503	051440	047510	
7930	044262	046125	020104	047516	
7931	044270	020124	042502	042040	
7932	044276	050105	042522	051523	
7933	044304	042105			
7934	044306	005015	044127	046111	.ASCII <CR><LF>/WHILE ON TRACK 2 SECTORS 19, 20 OR 21/
7935	044314	020105	047117	052040	
7936	044322	040522	045503	031040	
7937	044330	051440	041505	047524	
7938	044336	051522	030440	026071	
7939	044344	031040	020060	051117	
7940	044352	031040	061		
7941	044355	015	050012	042514	.ASCIZ <CR><LF>/PLEASE TRY AGAIN/<CR><LF>
7942	044362	051501	020105	051124	
7943	044370	020131	043501	044501	
7944	044376	006516	000012		

7945					
7946					.SBTTL ERROR MESSAGES
7947					
7948	044402	005015	051105	047522	EM1: .ASCIZ <CR><LF>/ERROR, ONLY 0 THRU 7 ALLOWED, TRY AGAIN/<CR><LF>
7949	044410	026122	047440	046116	
7950	044416	020131	020060	044124	
7951	044424	052522	033440	040440	
7952	044432	046114	053517	042105	
7953	044440	020054	051124	020131	
7954	044446	043501	044501	006516	
7955	044454	000012			
7956	044456	051104	053111	020105	EM2: .ASCIZ /DRIVE # IN RKCS2 CANNOT BE READ BACK CORRECTLY IN RKMR2/
7957	044464	020043	047111	051040	
7958	044472	041513	031123	041440	
7959	044500	047101	047516	020124	
7960	044506	042502	051040	040505	
7961	044514	020104	040502	045503	
7962	044522	041440	051117	042522	
7963	044530	052103	054514	044440	
7964	044536	020116	045522	051115	
7965	044544	000062			
7966	044546	005015	041101	051117	EM3: .ASCIZ <CR><LF>/ABORT TESTS...UNEXPECTED TIME OUT AT PC=/ /
7967	044554	020124	042524	052123	
7968	044562	027123	027056	047125	
7969	044570	054105	042520	052103	
7970	044576	042105	052040	046511	
7971	044604	020105	052517	020124	
7972	044612	052101	050040	036503	
7973	044620	000			
7974	044621	015	040412	047502	EM4: .ASCIZ <CR><LF>/ABORT TESTS...UNEXPECTED INTERRUPT AT PC=/ /
7975	044626	052122	052040	051505	
7976	044634	051524	027056	052456	
7977	044642	042516	050130	041505	
7978	044650	042524	020104	047111	
7979	044656	042524	051122	050125	
7980	044664	020124	052101	050040	
7981	044672	036503	000		
7982	044675	115	051504	051440	EM5: .ASCIZ /MDS SET IN RKCS2/
7983	044702	052105	044440	020116	
7984	044710	045522	051503	000062	
7985	044716	043125	020105	042523	EM6: .ASCIZ /UFE SET IN RKCS2/
7986	044724	020124	047111	051040	
7987	044732	041513	031123	000	
7988	044737	104	040522	044440	EM7: .ASCIZ /DRA IN RKDS & NED IN RKCS2 RESET; WRONG PORT SELECTED?/ /
7989	044744	020116	045522	051504	
7990	044752	023040	047040	042105	
7991	044760	044440	020116	045522	
7992	044766	051503	020062	042522	
7993	044774	042523	035524	053440	
7994	045002	047522	043516	050040	
7995	045010	051117	020124	042523	
7996	045016	042514	052103	042105	
7997	045024	000077			
7998	045026	051104	053111	020105	EM8: .ASCIZ /DRIVE PRESENT BUT NOT SPECIFIED BY OPERATOR/
7999	045034	051120	051505	047105	
8000	045042	020124	052502	020124	

8001	045050	047516	020124	050123	
8002	045056	041505	043111	042511	
8003	045064	020104	054502	047440	
8004	045072	042520	040522	047524	
8005	045100	000122			
8006	045102	051104	053111	020105	EM9: .ASCIZ /DRIVE NOT PRESENT BUT SPECIFIED BY OPERATOR/
8007	045110	047516	020124	051120	
8008	045116	051505	047105	020124	
8009	045124	052502	020124	050123	
8010	045132	041505	043111	042511	
8011	045140	020104	054502	047440	
8012	045146	042520	040522	047524	
8013	045154	000122			
8014	045156	041101	051117	020124	EM10: .ASCIZ /ABORT TESTS...CANNOT REFERENCE CONTROLLER REGISTER/
8015	045164	042524	052123	027123	
8016	045172	027056	040503	047116	
8017	045200	052117	051040	043105	
8018	045206	051105	047105	042503	
8019	045214	041440	047117	051124	
8020	045222	046117	042514	020122	
8021	045230	042522	044507	052123	
8022	045236	051105	000		
8023	045241	104	040522	044440	EM11: .ASCIZ /DRA IN RKDS & NED IN RKCS2 BOTH SET/
8024	045246	020116	045522	051504	
8025	045254	023040	047040	042105	
8026	045262	044440	020116	045522	
8027	045270	051503	020062	047502	
8028	045276	044124	051440	052105	
8029	045304	000			
8030	045305	103	047117	051124	EM12: .ASCIZ /CONTROLLER NOT READY IN RKCS1/
8031	045312	046117	042514	020122	
8032	045320	047516	020124	042522	
8033	045326	042101	020131	047111	
8034	045334	051040	041513	030523	
8035	045342	000			
8036	045343	116	020117	052101	EM13: .ASCIZ /NO ATTN IN RKASOF/
8037	045350	047124	044440	020116	
8038	045356	045522	051501	043117	
8039	045364	000			
8040	045365	127	047522	043516	EM14: .ASCIZ /WRONG ATTN IN RKASOF/
8041	045372	040440	052124	020116	
8042	045400	047111	051040	040513	
8043	045406	047523	000106		
8044	045412	051104	054504	047040	EM15: .ASCIZ /DRDY NOT CLEARED IN RKMR2/
8045	045420	052117	041440	042514	
8046	045426	051101	042105	044440	
8047	045434	020116	045522	051115	
8048	045442	000062			
8049	045444	051504	020103	047516	EM16: .ASCIZ /DSC NOT SET IN RKMR2/
8050	045452	020124	042523	020124	
8051	045460	047111	051040	046513	
8052	045466	031122	000		
8053	045471	115	051505	040523	EM17: .ASCIZ /MESSAGE A0 ERROR/
8054	045476	042507	040440	020060	
8055	045504	051105	047522	000122	
8056	045512	042515	051523	043501	EM18: .ASCIZ /MESSAGE B0 ERROR/

8057	045520	020105	030102	042440	
8058	045526	051122	051117	000	
8059	045533	115	051505	040523	EM19: .ASCIZ /MESSAGE A1 ERROR/
8060	045540	042507	040440	020061	
8061	045546	051105	047522	000122	
8062	045554	042515	051523	043501	EM20: .ASCIZ /MESSAGE B1 ERROR/
8063	045562	020105	030502	042440	
8064	045570	051122	051117	000	
8065	045575	103	051105	020122	EM21: .ASCIZ /CERR SET IN RKCS1/
8066	045602	042523	020124	047111	
8067	045610	051040	041513	030523	
8068	045616	000			
8069	045617	104	047517	020122	EM22: .ASCIZ /DOOR STATUS IN RKMR2 NOT CLEARED/
8070	045624	052123	052101	051525	
8071	045632	044440	020116	045522	
8072	045640	051115	020062	047516	
8073	045646	020124	046103	040505	
8074	045654	042522	000104		
8075	045660	050123	047111	046104	EM23: .ASCIZ /SPINDLE ON SET IN RKMR2/
8076	045666	020105	047117	051440	
8077	045674	052105	044440	020116	
8078	045702	045522	051115	000062	
8079	045710	047526	052514	042515	EM24: .ASCIZ /VOLUME VALID NOT SET IN RKMR2/
8080	045716	053040	046101	042111	
8081	045724	047040	052117	051440	
8082	045732	052105	044440	020116	
8083	045740	045522	051115	000062	
8084	045746	040503	052122	044522	EM25: .ASCIZ /CARTRIDGE STATUS IN RKMR2 NOT CLEARED/
8085	045754	043504	020105	052123	
8086	045762	052101	051525	044440	
8087	045770	020116	045522	051115	
8088	045776	020062	047516	020124	
8089	046004	046103	040505	042522	
8090	046012	000104			
8091	046014	047526	052514	042515	EM26: .ASCIZ /VOLUME VALID NOT CLEARED IN RKMR2/
8092	046022	053040	046101	042111	
8093	046030	047040	052117	041440	
8094	046036	042514	051101	042105	
8095	046044	044440	020116	045522	
8096	046052	051115	000062		
8097	046056	042516	020104	047516	EM27: .ASCIZ /NED NOT SET IN RKCS2/
8098	046064	020124	042523	020124	
8099	046072	047111	051040	041513	
8100	046100	031123	000		
8101	046103	126	046117	046525	EM28: .ASCIZ /VOLUME VALID SET IN RKMR2/
8102	046110	020105	040526	044514	
8103	046116	020104	042523	020124	
8104	046124	047111	051040	046513	
8105	046132	031122	000		
8106	046135	104	041523	047040	EM29: .ASCIZ /DSC NOT SET IN RKMR2/
8107	046142	052117	051440	052105	
8108	046150	044440	020116	045522	
8109	046156	051115	000062		
8110	046162	052101	047124	047040	EM30: .ASCIZ /ATTN NOT RESET IN RKASOF/
8111	046170	052117	051040	051505	
8112	046176	052105	044440	020116	

8113	046204	045522	051501	043117	
8114	046212	000			
8115	046213	116	042105	047040	EM31: .ASCIZ /NED NOT CLEARED IN RKCS2/
8116	046220	052117	041440	042514	
8117	046226	051101	042105	044440	
8118	046234	020116	045522	051503	
8119	046242	000062			
8120	046244	050123	047111	046104	EM32: .ASCIZ /SPINDLE ON NOT SET IN RKMR2/
8121	046252	020105	047117	047040	
8122	046260	052117	051440	052105	
8123	046266	044440	020116	045522	
8124	046274	051115	000062		
8125	046300	051104	053111	020105	EM33: .ASCIZ /DRIVE NOT READY IN RKMR2/
8126	046306	047516	020124	042522	
8127	046314	042101	020131	047111	
8128	046322	051040	046513	031122	
8129	046330	000			
8130	046331	104	047517	020122	EM34: .ASCIZ /DOOR STATUS BIT NOT SET IN RKMR2/
8131	046336	052123	052101	051525	
8132	046344	041040	052111	047040	
8133	046352	052117	051440	052105	
8134	046360	044440	020116	045522	
8135	046366	051115	000062		
8136	046372	042510	042101	020123	EM35: .ASCIZ /HEADS HOME NOT SET IN RKMR2/
8137	046400	047510	042515	047040	
8138	046406	052117	051440	052105	
8139	046414	044440	020116	045522	
8140	046422	051115	000062		
8141	046426	041501	046040	053517	EM37: .ASCIZ /AC LOW NOT SET IN RKMR3/
8142	046434	047040	052117	051440	
8143	046442	052105	044440	020116	
8144	046450	045522	051115	000063	
8145	046456	042516	020104	047516	EM42: .ASCIZ /NED NOT SET IN RKCS2/
8146	046464	020124	042523	020124	
8147	046472	047111	051040	041513	
8148	046500	031123	000		
8149	046503	101	046103	020117	EM43: .ASCIZ /ACLO NOT CLEARED IN RKMR3/
8150	046510	047516	020124	046103	
8151	046516	040505	042522	020104	
8152	046524	047111	051040	046513	
8153	046532	031522	000		
8154	046535	126	046117	046525	EM44: .ASCIZ /VOLUME VALID NOT CLEARED IN RKMR2/
8155	046542	020105	040526	044514	
8156	046550	020104	047516	020124	
8157	046556	046103	040505	042522	
8158	046564	020104	047111	051040	
8159	046572	046513	031122	000	
8160	046577	126	046117	046525	EM45: .ASCIZ /VOLUME VALID SET IN RKMR2 AFTER HEADS LOADED/
8161	046604	020105	040526	044514	
8162	046612	020104	042523	020124	
8163	046620	047111	051040	046513	
8164	046626	031122	040440	052106	
8165	046634	051105	044040	040505	
8166	046642	051504	046040	040517	
8167	046650	042504	000104		
8168	046654	047516	026516	054105	EM46: .ASCIZ /NON-EXECUTABLE FUNCTION (NXF) NOT SET IN RKMR3/

8169	046662	041505	052125	041101	
8170	046670	042514	043040	047125	
8171	046676	052103	047511	020116	
8172	046704	047050	043130	020051	
8173	046712	047516	020124	042523	
8174	046720	020124	047111	051040	
8175	046726	046513	031522	000	
8176	046733	103	046131	047111	EM47: .ASCIZ /CYLINDER ADDRESS CHANGED FROM 0/
8177	046740	042504	020122	042101	
8178	046746	051104	051505	020123	
8179	046754	044103	047101	042507	
8180	046762	020104	051106	046517	
8181	046770	030040	000		
8182	046773	127	044522	042524	EM48: .ASCIZ /WRITE LOCK IN RKMR2 NOT CLEARED/
8183	047000	046040	041517	020113	
8184	047006	047111	051040	046513	
8185	047014	031122	047040	052117	
8186	047022	041440	042514	051101	
8187	047030	042105	000		
8188	047033	127	044522	042524	EM49: .ASCIZ /WRITE LOCK IN RKMR2 NOT SET/
8189	047040	046040	041517	020113	
8190	047046	047111	051040	046513	
8191	047054	031122	047040	052117	
8192	047062	051440	052105	000	
8193	047067	127	044522	042524	EM50: .ASCIZ /WRITE LOCK ERROR IN RKMR3 NOT SET/
8194	047074	046040	041517	020113	
8195	047102	051105	047522	020122	
8196	047110	047111	051040	046513	
8197	047116	031522	047040	052117	
8198	047124	051440	052105	000	
8199	047131	127	044522	042524	EM51: .ASCIZ /WRITE LOCK DID NOT OCCUR AT SECTOR BOUNDRY/
8200	047136	046040	041517	020113	
8201	047144	044504	020104	047516	
8202	047152	020124	041517	052503	
8203	047160	020122	052101	051440	
8204	047166	041505	047524	020122	
8205	047174	047502	047125	051104	
8206	047202	000131			
8207	047204	047125	020123	047516	EM52: .ASCIZ /UNS NOT SET IN RKMR3/
8208	047212	020124	042523	020124	
8209	047220	047111	051040	046513	
8210	047226	031522	000		
8211					
8212	047231	125	046116	040517	EM53: .ASCIZ /UNLOAD NOT SET IN RKMR2/
8213	047236	020104	047516	020124	
8214	047244	042523	020124	047111	
8215	047252	051040	046513	031122	
8216	047260	000			
8217	047261	103	047101	047516	EM54: .ASCIZ /CANNOT FIND MULT. DRIVE SELECT IN RKCS2/
8218	047266	020124	044506	042116	
8219	047274	046440	046125	027124	
8220	047302	042040	044522	042526	
8221	047310	051440	046105	041505	
8222	047316	020124	047111	051040	
8223	047324	041513	031123	000	
8224	047331	101	052124	020116	EM55: .ASCIZ /ATTN NOT CLEARED IN RKASOF/

8225	047336	047516	020124	046103	
8226	047344	040505	042522	020104	
8227	047352	047111	051040	040513	
8228	047360	047523	000106		
8229	047364	047125	054105	042520	EM56: .ASCIZ /UNEXPECTED MEMORY PARITY ERROR TRAP/
8230	047372	052103	042105	046440	
8231	047400	046505	051117	020131	
8232	047406	040520	044522	054524	
8233	047414	042440	051122	051117	
8234	047422	052040	040522	000120	
8235	047430	042503	051122	044440	EM57: .ASCIZ /CERR IN RKCS1 NOT SET/
8236	047436	020116	045522	051503	
8237	047444	020061	047516	020124	
8238	047452	042523	000124		
8239	047456	040520	044522	054524	EM58: .ASCIZ /PARITY NOT SET IN RKMR3/
8240	047464	047040	052117	051440	
8241	047472	052105	044440	020116	
8242	047500	045522	051115	000063	
8243	047506	052103	020117	042523	EM59: .ASCIZ /CTO SET IN RKCS1/
8244	047514	020124	047111	051040	
8245	047522	041513	030523	000	
8246	047527	116	043130	042040	EM61: .ASCIZ /NXF DID NOT SET FAULT/
8247	047534	042111	047040	052117	
8248	047542	051440	052105	043040	
8249	047550	052501	052114	000	
8250	047555	104	052114	051440	EM63: .ASCIZ /DLT SET IN RKCS2/
8251	047562	052105	044440	020116	
8252	047570	045522	051503	000062	
8253	047576	045522	041504	023040	EM64: .ASCII /RKDC & RKDA INDICATE THAT WRITE CHECK ERROR/
8254	047604	051040	042113	020101	
8255	047612	047111	044504	040503	
8256	047620	042524	052040	040510	
8257	047626	020124	051127	052111	
8258	047634	020105	044103	041505	
8259	047642	020113	051105	047522	
8260	047650	122			
8261	047651	015	047412	041503	.ASCIZ <CR><LF>/OCCURRED AT CYL 411, TRACK 2, SECTOR 21/
8262	047656	051125	042522	020104	
8263	047664	052101	041440	046131	
8264	047672	032040	030461	020054	
8265	047700	051124	041501	020113	
8266	047706	026062	051440	041505	
8267	047714	047524	020122	030462	
8268	047722	000			
8269	047723	116	042105	051440	EM67: .ASCIZ /NED SET IN RKCS2/
8270	047730	052105	044440	020116	
8271	047736	045522	051503	000062	
8272	047744	040503	047116	052117	EM68: .ASCIZ /CANNOT READ BAD SECTOR INFORMATION/
8273	047752	051040	040505	020104	
8274	047760	040502	020104	042523	
8275	047766	052103	051117	044440	
8276	047774	043116	051117	040515	
8277	050002	044524	047117	000	
8278	050007	116	020117	051104	EM69: .ASCII /NO DRIVES FOUND ON BUSS/
8279	050014	053111	051505	043040	
8280	050022	052517	042116	047440	

8281	050030	020116	052502	051523	
8282	050036	005015	042523	052524	.ASCIZ <CR><LF>/SETUP CORRECTLY & PRESS 'CONTINUE'/<CR><LF>
8283	050044	020120	047503	051122	
8284	050052	041505	046124	020131	
8285	050060	020046	051120	051505	
8286	050066	020123	041447	047117	
8287	050074	044524	052516	023505	
8288	050102	005015	000		
8289	050105	127	044510	042514	EM70: .ASCIZ /WHILE WAITING FOR CONTR READY OR AFTER CONTR READY REC'D/
8290	050112	053440	044501	044524	
8291	050120	043516	043040	051117	
8292	050126	041440	047117	051124	
8293	050134	051040	040505	054504	
8294	050142	047440	020122	043101	
8295	050150	042524	020122	047503	
8296	050156	052116	020122	042522	
8297	050164	042101	020131	042522	
8298	050172	023503	000104		
8299	050176	042504	042524	052103	EM71: .ASCIZ /DETECTED 10 BAD SECTORS...ABORTING TEST/
8300	050204	042105	030440	020060	
8301	050212	040502	020104	042523	
8302	050220	052103	051117	027123	
8303	050226	027056	041101	051117	
8304	050234	044524	043516	052040	
8305	050242	051505	000124		
8306	050246	042504	042524	052103	EM72: .ASCIZ /DETECTED BSE BUT NOT LISTED IN BAD SECTOR FILE/
8307	050254	042105	041040	042523	
8308	050262	041040	052125	047040	
8309	050270	052117	046040	051511	
8310	050276	042524	020104	047111	
8311	050304	041040	042101	051440	
8312	050312	041505	047524	020122	
8313	050320	044506	042514	000	
8314	050325	104	052105	041505	EM73: .ASCII /DETECTED BSE IN READ COMMAND/
8315	050332	042524	020104	051502	
8316	050340	020105	047111	051040	
8317	050346	040505	020104	047503	
8318	050354	046515	047101	104	
8319	050361	015	041012	052125	.ASCIZ <CR><LF>/BUT NOT IN PREVIOUS WRITE COMMAND TO SAME SECTOR/
8320	050366	047040	052117	044440	
8321	050374	020116	051120	053105	
8322	050402	047511	051525	053440	
8323	050410	044522	042524	041440	
8324	050416	046517	040515	042116	
8325	050424	052040	020117	040523	
8326	050432	042515	051440	041505	
8327	050440	047524	000122		
8328	050444	052122	020132	047516	EM74: .ASCIZ /RTZ NOT SET IN RKMR2/
8329	050452	020124	042523	020124	
8330	050460	047111	051040	046513	
8331	050466	031122	000		
8332	050471	015	042012	052105	EM75: .ASCIZ <CR><LF>/DETECTED 10 BAD CYLINDERS...ABORTING TEST/
8333	050476	041505	042524	020104	
8334	050504	030061	041040	042101	
8335	050512	041440	046131	047111	
8336	050520	042504	051522	027056	

8337	050526	040456	047502	052122	
8338	050534	047111	020107	042524	
8339	050542	052123	000		
8340	050545	116	020117	051104	EM76: .ASCII /NO DRIVES FOUND IN DEVICE MAP (\$DEVN)/
8341	050552	053111	051505	043040	
8342	050560	052517	042116	044440	
8343	050566	020116	042504	044526	
8344	050574	042503	046440	050101	
8345	050602	024040	042044	053105	
8346	050610	024515			
8347	050612	005015	042523	052524	.ASCIIZ <CR><LF>/SETUP CORRECTLY & RESTART/<CR><LF>
8348	050620	020120	047503	051122	
8349	050626	041505	046124	020131	
8350	050634	020046	042522	052123	
8351	050642	051101	006524	000012	
8352	050650	051127	052111	020105	EM80: .ASCIIZ /WRITE CHECK ERROR SET IN RKCS2/
8353	050656	044103	041505	020113	
8354	050664	051105	047522	020122	
8355	050672	042523	020124	047111	
8356	050700	051040	041513	031123	
8357	050706	000			
8358	050707	104	052101	020101	EM83: .ASCIIZ /DATA CHECK ERROR SET IN RKER/
8359	050714	044103	041505	020113	
8360	050722	051105	047522	020122	
8361	050730	042523	020124	047111	
8362	050736	051040	042513	000122	
8363	050744	042522	042101	047111	EM93: .ASCIIZ /READING WRONG CYLINDER # IN HEADER/
8364	050752	020107	051127	047117	
8365	050760	020107	054503	044514	
8366	050766	042116	051105	021440	
8367	050774	044440	020116	042510	
8368	051002	042101	051105	000	
8369					
8370					.SBTTL DATA HEADERS
8371					
8372	051007	124	051505	020124	DH1: .ASCIIZ /TEST NO. PC/
8373	051014	047516	020056	050040	
8374	051022	000103			
8375	051024	045522	051115	004461	DH2: .ASCIIZ /RKMR1 RKMR2 RKMR3 RKER RKDS RKCS1 RKCS2/
8376	051032	045522	051115	004462	
8377	051040	045522	051115	004463	
8378	051046	045522	051105	051011	
8379	051054	042113	004523	045522	
8380	051062	051503	004461	045522	
8381	051070	051503	000062		
8382	051074	045522	041527	051011	DH3: .ASCIIZ /RKWC RKBA RKDA RKASOF RKDC RKECPS RKECPT/
8383	051102	041113	004501	045522	
8384	051110	040504	051011	040513	
8385	051116	047523	004506	045522	
8386	051124	041504	051011	042513	
8387	051132	050103	004523	045522	
8388	051140	041505	052120	000	
8389	051145	101	052106	051105	DH4: .ASCIIZ /AFTER PACK RE-INSERTED & HEADS LOADED/
8390	051152	050040	041501	020113	
8391	051160	042522	044455	051516	
8392	051166	051105	042524	020104	

8393	051174	020046	042510	042101	
8394	051202	020123	047514	042101	
8395	051210	042105	000		
8396	051213	101	052106	051105	DH5: .ASCIZ /AFTER AC SWITCHED OFF/
8397	051220	040440	020103	053523	
8398	051226	052111	044103	042105	
8399	051234	047440	043106	000	
8400	051241	101	052106	051105	DH8: .ASCIZ /AFTER DRIVE UNLOADED & DOOR OPENED/
8401	051246	042040	044522	042526	
8402	051254	052440	046116	040517	
8403	051262	042504	020104	020046	
8404	051270	047504	051117	047440	
8405	051276	042520	042516	000104	
8406	051304	043101	042524	020122	DH11: .ASCIZ /AFTER MANUALLY LOADING HEADS WITH DOOR OPEN/
8407	051312	040515	052516	046101	
8408	051320	054514	046040	040517	
8409	051326	044504	043516	044040	
8410	051334	040505	051504	053440	
8411	051342	052111	020110	047504	
8412	051350	051117	047440	042520	
8413	051356	000116			
8414	051360	043101	042524	020122	DH12: .ASCIZ /AFTER DISK PACK REMOVED/
8415	051366	044504	045523	050040	
8416	051374	041501	020113	042522	
8417	051402	047515	042526	000104	
8418	051410	043101	042524	020122	DH13: .ASCIZ /AFTER MANUALLY LOADING HEADS WITH DISK PACK REMOVED/
8419	051416	040515	052516	046101	
8420	051424	054514	046040	040517	
8421	051432	044504	043516	044040	
8422	051440	040505	051504	053440	
8423	051446	052111	020110	044504	
8424	051454	045523	050040	041501	
8425	051462	020113	042522	047515	
8426	051470	042526	000104		
8427	051474	044527	044124	052517	DH15: .ASCIZ /WITHOUT PACK COMMAND/
8428	051502	020124	040520	045503	
8429	051510	041440	046517	040515	
8430	051516	042116	000		
8431	051521	101	052106	051105	DH16: .ASCIZ /AFTER UNIT SELECT PLUG REMOVED/
8432	051526	052440	044516	020124	
8433	051534	042523	042514	052103	
8434	051542	050040	052514	020107	
8435	051550	042522	047515	042526	
8436	051556	000104			
8437	051560	043101	042524	020122	DH17: .ASCIZ /AFTER RECAL COMMAND/
8438	051566	042522	040503	020114	
8439	051574	047503	046515	047101	
8440	051602	000104			
8441	051604	043101	042524	020122	DH18: .ASCIZ /AFTER UNLOAD COMMAND/
8442	051612	047125	047514	042101	
8443	051620	041440	046517	040515	
8444	051626	042116	000		
8445	051631	101	052106	051105	DH19: .ASCIZ /AFTER PACK COMMAND/
8446	051636	050040	041501	020113	
8447	051644	047503	046515	047101	
8448	051652	000104			

8449	051654	043101	042524	020122	DH20:	.ASCIZ	/AFTER SELECT DRIVE COMMAND/
8450	051662	042523	042514	052103			
8451	051670	042040	044522	042526			
8452	051676	041440	046517	040515			
8453	051704	042116	000				
8454	051707	101	052106	051105	DH21:	.ASCIZ	/AFTER SUBSYSTEM CLEAR/
8455	051714	051440	041125	054523			
8456	051722	052123	046505	041440			
8457	051730	042514	051101	000			
8458	051735	101	052106	051105	DH22:	.ASCIZ	/AFTER DRIVE CLEAR COMMAND/
8459	051742	042040	044522	042526			
8460	051750	041440	042514	051101			
8461	051756	041440	046517	040515			
8462	051764	042116	000				
8463	051767	101	052106	051105	DH23:	.ASCIZ	/AFTER WRONG PORT SELECTED/
8464	051774	053440	047522	043516			
8465	052002	050040	051117	020124			
8466	052010	042523	042514	052103			
8467	052016	042105	000				
8468	052021	101	052106	051105	DH25:	.ASCIZ	/AFTER SEEK COMMAND/
8469	052026	051440	042505	020113			
8470	052034	047503	046515	047101			
8471	052042	000104					
8472	052044	043101	042524	020122	DH26:	.ASCIZ	/AFTER READ DATA COMMAND/
8473	052052	042522	042101	042040			
8474	052060	052101	020101	047503			
8475	052066	046515	047101	000104			
8476	052074	043101	042524	020122	DH27:	.ASCIZ	/AFTER WRITE DATA COMMAND/
8477	052102	051127	052111	020105			
8478	052110	040504	040524	041440			
8479	052116	046517	040515	042116			
8480	052124	000					
8481	052125	101	052106	051105	DH28:	.ASCIZ	/AFTER BOTH PORTS DESELECTED/
8482	052132	041040	052117	020110			
8483	052140	047520	052122	020123			
8484	052146	042504	042523	042514			
8485	052154	052103	042105	000			
8486	052161	101	052106	051105	DH29:	.ASCIZ	/AFTER CORRECT PORT SELECTED/
8487	052166	041440	051117	042522			
8488	052174	052103	050040	051117			
8489	052202	020124	042523	042514			
8490	052210	052103	042105	000			
8491	052215	101	052106	051105	DH30:	.ASCIZ	/AFTER READ HEADER COMMAND/
8492	052222	051040	040505	020104			
8493	052230	042510	042101	051105			
8494	052236	041440	046517	040515			
8495	052244	042116	000				
8496	052247	101	052106	051105	DH31:	.ASCIZ	/AFTER DRIVE MANUALLY LOADED/
8497	052254	042040	044522	042526			
8498	052262	046440	047101	040525			
8499	052270	046114	020131	047514			
8500	052276	042101	042105	000			
8501	052303	101	052106	051105	DH32:	.ASCIZ	/AFTER WRITE CHECK COMMAND/
8502	052310	053440	044522	042524			
8503	052316	041440	042510	045503			
8504	052324	041440	046517	040515			

8505	052332	042116	000		
8506	052335	101	052106	051105	DH34: .ASCIZ /AFTER START SPINDLE COMMAND/
8507	052342	051440	040524	052122	
8508	052350	051440	044520	042116	
8509	052356	042514	041440	046517	
8510	052364	040515	042116	000	
8511	052371	101	052106	051105	DH35: .ASCIZ /AFTER MANUALLY UNLOADING/
8512	052376	046440	047101	040525	
8513	052404	046114	020131	047125	
8514	052412	047514	042101	047111	
8515	052420	000107			
8516	052422	043101	042524	020122	DH37: .ASCIZ /AFTER TIMEOUT TO POWER DOWN/
8517	052430	044524	042515	052517	
8518	052436	020124	047524	050040	
8519	052444	053517	051105	042040	
8520	052452	053517	000116		
8521	052456	043101	042524	020122	DH38: .ASCIZ /AFTER AC POWERED UP/
8522	052464	041501	050040	053517	
8523	052472	051105	042105	052440	
8524	052500	000120			
8525	052502	043101	042524	020122	DH39: .ASCIZ /AFTER WRITE HEADER COMMAND/
8526	052510	051127	052111	020105	
8527	052516	042510	042101	051105	
8528	052524	041440	046517	040515	
8529	052532	042116	000		
8530	052535	104	051125	047111	DH41: .ASCIZ /DURING RECAL COMMAND/
8531	052542	020107	042522	040503	
8532	052550	020114	047503	046515	
8533	052556	047101	000104		
8534	052562	047117	051440	041505	DH42: .ASCIZ /ON SECTORS 0,2,4,6 OR 8 CYL 410 TRACK 2/
8535	052570	047524	051522	030040	
8536	052576	031054	032054	033054	
8537	052604	047440	020122	020070	
8538	052612	041440	046131	032040	
8539	052620	030061	052040	040522	
8540	052626	045503	031040	000	
8541	052633	106	051117	040515	DH44: .ASCIZ /FORMAT & ALL READ-WRITE TESTS WILL BE BYPASSED/
8542	052640	020124	020046	046101	
8543	052646	020114	042522	042101	
8544	052654	053455	044522	042524	
8545	052662	052040	051505	051524	
8546	052670	053440	046111	020114	
8547	052676	042502	041040	050131	
8548	052704	051501	042523	000104	
8549	052712	043101	042524	020122	DH45: .ASCIZ /AFTER SEEK WITH VOLUME VALID=0/
8550	052720	042523	045505	053440	
8551	052726	052111	020110	047526	
8552	052734	052514	042515	053040	
8553	052742	046101	042111	030075	
8554	052750	000			
8555	052751	101	052106	051105	DH46: .ASCIZ /AFTER WRITE DATA WITH VOLUME VALID=0/
8556	052756	053440	044522	042524	
8557	052764	042040	052101	020101	
8558	052772	044527	044124	053040	
8559	053000	046117	046525	020105	
8560	053006	040526	044514	036504	

8561	053014	000060				
8562	053016	043101	042524	020122	DH48:	.ASCIZ /AFTER WRITE LOCK SWITCH DISABLED/
8563	053024	051127	052111	020105		
8564	053032	047514	045503	051440		
8565	053040	044527	041524	020110		
8566	053046	044504	040523	046102		
8567	053054	042105	000			
8568	053057	101	052106	051105	DH49:	.ASCIZ /AFTER WRITE LOCK SWITCH ENABLED/
8569	053064	053440	044522	042524		
8570	053072	046040	041517	020113		
8571	053100	053523	052111	044103		
8572	053106	042440	040516	046102		
8573	053114	042105	000			
8574	053117	101	052106	051105	DH50:	.ASCIZ /AFTER WRITING WITH WRITE LOCK ENABLED/
8575	053124	053440	044522	044524		
8576	053132	043516	053440	052111		
8577	053140	020110	051127	052111		
8578	053146	020105	047514	045503		
8579	053154	042440	040516	046102		
8580	053162	042105	000			
8581	053165	103	046131	021440	DH56:	.ASCIZ /CYL # HEADER WORD 0/
8582	053172	044011	040505	042504		
8583	053200	020122	047527	042122		
8584	053206	030040	000			
8585	053211	101	052106	051105	DH59:	.ASCIZ /AFTER DRIVE SELECT COMMAND WITH EVEN PARITY/
8586	053216	042040	044522	042526		
8587	053224	051440	046105	041505		
8588	053232	020124	047503	046515		
8589	053240	047101	020104	044527		
8590	053246	044124	042440	042526		
8591	053254	020116	040520	044522		
8592	053262	054524	000			
8593	053265	101	052106	051105	DH60:	.ASCIZ /AFTER WRITE LOCK ENABLED DURING CONTINUOUS WRITING/
8594	053272	053440	044522	042524		
8595	053300	046040	041517	020113		
8596	053306	047105	041101	042514		
8597	053314	020104	052504	044522		
8598	053322	043516	041440	047117		
8599	053330	044524	052516	052517		
8600	053336	020123	051127	052111		
8601	053344	047111	000107			
8602	053350	045522	040504	053411	DH61:	.ASCII /RKDA WORD EXPECTED/
8603	053356	051117	004504	054105		
8604	053364	042520	052103	042105		
8605	053372	005015	020100	051127		.ASCIZ <CR><LF>/@ WRL WAS WORD/
8606	053400	004514	040527	004523		
8607	053406	047527	042122	000		
8608	053413	122	042113	004501	DH62:	.ASCII /RKDA WORD EXPECTED/
8609	053420	047527	042122	042411		
8610	053426	050130	041505	042524		
8611	053434	104				
8612	053435	015	041012	043105		.ASCII <CR><LF>/BEFORE WAS WORD/
8613	053442	051117	004505	040527		
8614	053450	004523	047527	042122		
8615	053456	005015	051127	000114		.ASCIZ <CR><LF>/WRL/
8616	053464	043101	042524	020122	DH63:	.ASCIZ /AFTER WRITE LOCK ENABLED FROM AC FAILURE/

8673	054132	005364	005366	005370		HMR1,HMR2,HMR3,HER,HDS,HCS1,HCS2
8674	054140	005354	005352	005340		
8675	054146	005342				
8676	054150	005344	005346	005350		HWC,HBA,HDA,HASOF,HDC,HPOS,HPAT
8677	054156	005356	005360	005372		
8678	054164	005374				
8679	054166	001214	001116	001166	DT3:	\$TESTN,\$ERRPC,\$TMP3,WD1,WD2
8680	054174	001434	001436			
8681	054200	005364	005366	005370		HMR1,HMR2,HMR3,HER,HDS,HCS1,HCS2
8682	054206	005354	005352	005340		
8683	054214	005342				
8684	054216	005344	005346	005350		HWC,HBA,HDA,HASOF,HDC,HPOS,HPAT
8685	054224	005356	005360	005372		
8686	054232	005374				
8687	054234	001214	001354		DT6:	\$TESTN,TRAPPC
8688	054240	001214	001116	001366	DT9:	\$TESTN,\$ERRPC,TOCYL,RHTAB
8689	054246	001712				
8690	054250	005364	005366	005370		HMR1,HMR2,HMR3,HER,HDS,HCS1,HCS2
8691	054256	005354	005352	005340		
8692	054264	005342				
8693	054266	005344	005346	005350		HWC,HBA,HDA,HASOF,HDC,HPOS,HPAT
8694	054274	005356	005360	005372		
8695	054302	005374				
8696	054304	001214	001116	005430	DT13:	\$TESTN,\$ERRPC,E.A0,E.B0,E.A1,E.B1,H.A0,H.B0,H.A1,H.B1
8697	054312	005432	005434	005436		
8698	054320	005410	005412	005414		
8699	054326	005416				
8700	054330	005364	005366	005370		HMR1,HMR2,HMR3,HER,HDS,HCS1,HCS2
8701	054336	005354	005352	005340		
8702	054344	005342				
8703	054346	005344	005346	005350		HWC,HBA,HDA,HASOF,HDC,HPOS,HPAT
8704	054354	005356	005360	005372		
8705	054362	005374				
8706						
8707	054364	001214	001116	005430	DT14:	\$TESTN,\$ERRPC,E.A0,E.B0,E.A1,E.B1,E.A2,E.B2
8708	054372	005432	005434	005436		
8709	054400	005440	005442			
8710	054404	005410	005412	005414		H.A0,H.B0,H.A1,H.B1,H.A2,H.B2
8711	054412	005416	005420	005422		
8712	054420	005364	005366	005370		HMR1,HMR2,HMR3,HER,HDS,HCS1,HCS2
8713	054426	005354	005352	005340		
8714	054434	005342				
8715	054436	005344	005346	005350		HWC,HBA,HDA,HASOF,HDC,HPOS,HPAT
8716	054444	005356	005360	005372		
8717	054452	005374				
8718						
8719	054454	001214	001116	005430	DT15:	\$TESTN,\$ERRPC,E.A0,E.B0,E.A1,E.B1,E.A2,E.B2,E.B3
8720	054462	005432	005434	005436		
8721	054470	005440	005442	005446		
8722	054476	005410	005412	005414		H.A0,H.B0,H.A1,H.B1,H.A2,H.B2,H.B3
8723	054504	005416	005420	005422		
8724	054512	005426				
8725	054514	005364	005366	005370		HMR1,HMR2,HMR3,HER,HDS,HCS1,HCS2
8726	054522	005354	005352	005340		
8727	054530	005342				
8728	054532	005344	005346	005350		HWC,HBA,HDA,HASOF,HDC,HPOS,HPAT

Line	Account	Code	Amount	Code	Description
8729	054540	005356	005360	005372	
8730	054546	005374			
8731					
8732					.SBTTL ERROR DATA FORMATS
8733					
8734	054550	000003			DF1: 3
8735	054552	002	000		.BYTE 2.0
8736	054554	051024			DH2
8737	054556	007	000		.BYTE 7.0
8738	054560	051074			DH3
8739	054562	007	000		.BYTE 7.0
8740					
8741					
8742	054564	000005			DF3: 5
8743	054566	000	000		.BYTE 0.0
8744	054570	051007			DH1
8745	054572	002	000		.BYTE 2.0
8746	054574	053350			DH61
8747	054576	003	000		.BYTE 3.0
8748	054600	051024			DH2
8749	054602	007	000		.BYTE 7.0
8750	054604	051074			DH3
8751	054606	007	000		.BYTE 7.0
8752					
8753	054610	000005			DF4: 5
8754	054612	000	000		.BYTE 0.0
8755	054614	051007			DH1
8756	054616	002	000		.BYTE 2.0
8757	054620	053413			DH62
8758	054622	003	000		.BYTE 3.0
8759	054624	051024			DH2
8760	054626	007	000		.BYTE 7.0
8761	054630	051074			DH3
8762	054632	007	000		.BYTE 7.0
8763					
8764	054634	000001			DF5: 1
8765	054636	002	000		.BYTE 2.0
8766					
8767	054640	000003			DF7: 3
8768	054642	002	000		.BYTE 2.0
8769	054644	051024			DH2
8770	054646	007	000		.BYTE 7.0
8771	054650	051074			DH3
8772	054652	007	000		.BYTE 7.0
8773	054654	000004			DF10: 4
8774	054656	000	000		.BYTE 0.0
8775	054660	051007			DH1
8776	054662	002	000		.BYTE 2.0
8777	054664	051024			DH2
8778	054666	007	000		.BYTE 7.0
8779	054670	051074			DH3
8780	054672	007	000		.BYTE 7.0
8781					
8782	054674	000005			DF12: 5
8783	054676	000	000		.BYTE 0.0
8784	054700	053765			DH73

8785	054702	000	000		.BYTE	0.0
8786	054704	051007			DH1	
8787	054706	002	000		.BYTE	2.0
8788	054710	051024			DH2	
8789	054712	007	000		.BYTE	7.0
8790	054714	051074			DH3	
8791	054716	007	000		.BYTE	7.0
8792						
8793						
8794	054720	000004		DF15:	4	
8795	054722	000	000		.BYTE	0.0
8796	054724	051007			DH1	
8797	054726	002	000		.BYTE	2.0
8798	054730	051024			DH2	
8799	054732	007	000		.BYTE	7.0
8800	054734	051074			DH3	
8801	054736	007	000		.BYTE	7.0
8802						
8803						
8804	054740	000005		DF17:	5	
8805	054742	000	000		.BYTE	0.0
8806	054744	052633			DH44	
8807	054746	000	000		.BYTE	0.0
8808	054750	051007			DH1	
8809	054752	002	000		.BYTE	2.0
8810	054754	051024			DH2	
8811	054756	007	000		.BYTE	7.0
8812	054760	051074			DH3	
8813	054762	007	000		.BYTE	7.0
8814	054764	000005		DF20:	5	
8815	054766	000	000		.BYTE	0.0
8816	054770	051007			DH1	
8817	054772	002	000		.BYTE	2.0
8818	054774	053165			DH56	
8819	054776	002	000		.BYTE	2.0
8820	055000	051024			DH2	
8821	055002	007	000		.BYTE	7.0
8822	055004	051074			DH3	
8823	055006	007	000		.BYTE	7.0
8824						
8825	055010	000007		DF21:	7	
8826	055012	000	000		.BYTE	0.0
8827	055014	051007			DH1	
8828	055016	002	000		.BYTE	2.0
8829	055020	053720			DH69	
8830	055022	000	000		.BYTE	0.0
8831	055024	053740			DH71	
8832	055026	004	000		.BYTE	4.0
8833	055030	053730			DH70	
8834	055032	004	000		.BYTE	4.0
8835	055034	051024			DH2	
8836	055036	007	000		.BYTE	7.0
8837	055040	051074			DH3	
8838	055042	007	000		.BYTE	7.0
8839						
8840	055044	000007		DF22:	7	

8841	055046	000	000
8842	055050	051007	
8843	055052	002	000
8844	055054	053720	
8845	055056	000	000
8846	055060	053740	
8847	055062	006	000
8848	055064	053730	
8849	055066	006	000
8850	055070	051024	
8851	055072	007	000
8852	055074	051074	
8853	055076	007	000
8854			
8855	055100	000007	
8856	055102	000	000
8857	055104	051007	
8858	055106	002	000
8859	055110	053720	
8860	055112	000	000
8861	055114	053740	
8862	055116	007	000
8863	055120	053730	
8864	055122	007	000
8865	055124	051024	
8866	055126	007	000
8867	055130	051074	
8868	055132	007	000
8869			
8870			
8871			
8872			
8873			
8874			
8875			
8876			
8877			
8878			
8879	055134	104413	
8880	055136	032777	020000 123774
8881	055144	001107	
8882	055146	113700	001114
8883	055152	042700	177400
8884	055156	005300	
8885	055160	006300	
8886	055162	006300	
8887	055164	006300	
8888	055166	062700	005512
8889	055172	012037	055206
8890	055176	001404	
8891	055200	104401	001205
8892	055204	104401	
8893	055206	000000	
8894	055210	012037	055224
8895	055214	001404	
8896	055216	104401	001205

```

.BYTE 0,0
DH1
.BYTE 2,0
DH69
.BYTE 0,0
DH71
.BYTE 6,0
DH70
.BYTE 6,0
DH2
.BYTE 7,0
DH3
.BYTE 7,0
DF23: 7
.BYTE 0,0
DH1
.BYTE 2,0
DH69
.BYTE 0,0
DH71
.BYTE 7,0
DH70
.BYTE 7,0
DH2
.BYTE 7,0
DH3
.BYTE 7,0
:*****
:SBTTL TYPE ERROR ROUTINE
:*ENTRY JSR PC,TYP ERR
:*RETURN RTS PC
:*
:*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
:*ERROR IS TO BE REPORTED. IT THEN USES THE "ERROR TABLE" ($ERRTB)
:*ENTRY TO DEFINE WHAT INFORMATION IS TO BE REPORTED CONCERNING
:*THE ERROR.
:*****
TYPERR: SAVREG
BIT #SW13,@SWR ;INHIBIT ERROR TYPEOUTS?
BNE 20$ ;YES-BRANCH
MOVB $ITEMB,R0 ;ENTER ERROR NUMBER
BIC #177400,R0 ;CLEAR SIGN EXTENSION
DEC R0 ;FORM INDEX FOR ERROR TABLE
ASL R0
ASL R0
ASL R0
1$: ADD #$ERRTB,R0 ;FORM ADDRESS OF ERROR ENTRY
MOV (R0)+,2$ ;GET EM POINTER
BEQ 3$ ;BRANCH IF THERE ISN'T ONE
TYPE .$CRLF ;TYPE CARRIAGE RETURN LINE FEED
TYPE ;TYPE ERROR MESSAGE (EM)
2$: .WORD 0 ;EM POINTER GOES HERE
3$: MOV (R0)+,4$ ;GET DH POINTER
BEQ 5$ ;BRANCH IF THERE ISN'T ONE
TYPE .$CRLF ;TYPE CR-LF
    
```

CZ
CZ
AB
AC
AC
AC
AC
AD
AD
AD
AD
AD
AD
AD
AD
AD
AD
AD
AD
AE
AE
AF
AM
AM
AM
AM
AM
AM
AM
AM
AM
AM
AM
AM
AP
AP
AP
AP
AS
AT
AT
AU
AU
AV
AV
BA


```

9009 055600 000403          BR      0.45
9010 055602 012737 000002 056572 0.45:  MOV    #RTI,O.RTIT      ;SET TO RTI IF 11/20 OR /05
9011 055610 105037 057511          CLR    O.P              ;DISALLOW PROCEED
9012 055614 012737 000340 000016  MOV    #O.STM,O.TVEC+2  ;STATUS WORD TO TRT VECTOR + 2
9013 055622 012737 056652 000014  MOV    #O.BRK,O.TVEC    ;PC TO TRT VECTOR
9014 055630 000447          BR      O.RALL          ;CLEAR BREAKPOINT TABLES
9015
9016      ;
9017      ; SPECIAL NAME HANDLER
9018      ; DEPENDS UPON THE EXPLICIT ORDER OF THE TWO TABLES O.TL AND O.URO
9019 055632 004537 057312 0. REGT: JSR    5,O.GET      ;SPECIAL NAME, GET ONE MORE CHARACTER
9020 055636 012704 057535          MOV    #O.TL,R4        ;TABLE START ADDRESS
9021 055642 120024 0. RSP:  CMPB   R0,(R4)+    ;IS THIS THE CORRECT CHARACTER?
9022 055644 001413          BEQ    O.SP            ;JUMP IF YES
9023 055646 022704 057543          CMP    #O.TL+O.LG,R4  ;IS THE SEARCH DONE?
9024 055652 101373          BHI    O.RSP          ;BRANCH IF NOT
9025 055654 042700 177770          BIC    #177770,R0     ;MASK OFF OCTAL
9026 055660 010004          MOV    R0,R4
9027 055662 006304 0. SP1:  ASL    R4
9028 055664 062704 055444          ADD    #O.URO,R4      ;GENERATE ADDRESS
9029 055670 005202          INC    R2             ;SET FOUND FLAG
9030 055672 000444          BR     O.SCAN         ;GO FIND NEXT CHARACTER
9031 055674 162704 057526 0. SP:  SUB    #O.TL-7,R4    ;CORRECT CONSTANT
9032 055700 000770          BR     O.SP1
9033
9034      ;
9035      ; _ HANDLER - OPEN INDEXED ON THE PC
9036 055702 004737 057436 0. ORPC: JSR    PC,O.TCLS
9037 055706 010502          MOV    R5,R2          ;CURRENT ADDRESS IN R2
9038 055710 061202          ADD    @R2,R2         ;COMPUTE
9039 055712 006202          ASR    R2             ;MOVE ONE BIT TO CARRY
9040 055714 103421          BCS    O.ERR         ;ERROR IF ODD NUMBER
9041 055716 006302          ASL    R2             ;RESTORE WORD
9042 055720 005722          TST   (R2)+          ; AND INCREMENT BY TWO
9043 055722 010205          MOV    R2,R5         ;UPDATE CAD
9044 055724 000137 056176          JMP   O.OP2          ;GO FINISH UP
9045
9046      ;
9047      ; B HANDLER - SET AND REMOVE BREAKPOINTS
9048 055730 005702 0. BKPT: TST    R2          ;IF NO NUMBER TYPED
9049 055732 001406          BEQ   O.RALL         ; REMOVE BREAKPOINT
9050 055734 006204          ASR   R4             ;CHECK IF ODD
9051 055736 103410          BCS   O.ERR         ;JUMP IF ODD
9052 055740 006304          ASL   R4             ;RESTORE ONE BIT
9053 055742 010437 055476          MOV   R4,O.ADR1     ;SET A BREAKPOINT
9054
9055          BR     O.DCD
9056
9057
9058
9059 055750 012737 057552 055476 0. RALL: MOV    #O.TRTC,O.ADR1 ;CLEAR BREAKPOINT
9060 055756 000406          BR     O.DCD
9061
9062      ;
9063      ; COMMAND DECODER - ODT11
9064      ;
          ; REGISTERS R0-R4 MAY BE USED,
    
```



```

9065      ; REGISTER R5 WILL BE CONSIDERED SAFE
9066      ;
9067 055760 052705 000001  O.ERR: BIS #1,R5 ;CLOSE EVERYTHING
9068 055764 012700 000077  MOV #?,R0 ; ? TO BE TYPED
9069 055770 004537 057370  JSR 5,O.FTYP ; OUTPUT ?
9070 055774 004537 057470  O.DCD: JSR 5,O.CRLS ;TYPE <CR><LF>*
9071 056000 005004  O.DCD1: CLR R4 ; R4 CONTAINS THE CONVERTED OCTAL
9072 056002 005002  CLR R2 ; R2 IS THE NUMBER FOUND FLAG
9073 056004 004537 057312  O.SCAN: JSR 5,O.GET ;GET A CHAR, RETURN IN R0
9074 056010 022700 000060  CMP #0,R0 ;COMPARE WITH ASCII 0
9075 056014 101013  BHI 0,CLGL ;CHECK LEGALITY IF NON-NUMERIC
9076 056016 022700 000067  CMP #7,R0 ;COMPARE WITH ASCII 7
9077 056022 103410  BLO 0,CLGL ;CHECK LEGALITY IF NOT OCTAL
9078 056024 042700 177770  BIC #177770,R0 ;CONVERT TO BCD
9079 056030 006304  ASL R4 ; MAKE ROOM
9080 056032 006304  ASL R4 ; IN
9081 056034 006304  ASL R4 ; R4
9082 056036 060004  ADD R0,R4 ;PACK THREE BITS IN R4
9083 056040 005202  INC R2 ;R2 HAS NUMERIC FLAG
9084 056042 000760  BR O.SCAN ; AND TRY AGAIN
9085 056044 005001  O.CLGL: CLR R1 ;CLEAR INDEX
9086 056046 120061 057521  O.LGL1: CMPB R0,O.LGCH(R1) ;DO THE CODES MATCH?
9087 056052 001405  BEQ O.LGL2 ;JUMP IF YES
9088 056054 005201  INC R1 ; SET INDEX FOR NEXT SEARCH
9089 056056 020127 000014  CMP R1,#O.CLGT ;IS THE SEARCH DONE?
9090 056062 103336  BHIS O.ERR ; OOPS!
9091 056064 000770  BR O.LGL1 ;RE-LOOP
9092 056066 006301  O.LGL2: ASL R1 ;MULTIPLY BY TWO
9093 056070 000171 056074  JMP @O.LGDR(R1) ;GO TO PROPER ROUTINE
9094
9095
9096 056074 056124  O.LGDR: O.WRD ; / OPEN WORD
9097 056076 056156  O.CRET ; CARRIAGE RETURN CLOSE
9098 056100 055632  O.REGT ; $ REGISTER OPS
9099 056102 056466  O.GO ; G GO TO ADDRESS K
9100 056104 056170  O.OP1 ; <LF> MODIFY, CLOSE, OPEN NEXT
9101 056106 055702  O.ORPC ; * OPEN RELATED, INDEX - PC
9102 056110 056222  O.BACK ; * OPEN PREVIOUS
9103 056112 056232  O.OFST ; O OFFSET
9104 056114 056310  O.WSCH ; W SEARCH WORD
9105 056116 056304  O.EFF ; E SEARCH EFFECTIVE ADDRESS
9106 056120 055730  O.BKPT ; B BREAKPOINTS
9107 056122 056574  O.PROC ; F PROCEED
9108 000030
9109
9110 ; PROCESS / - OPEN WORD
9111
9112 056124 005702  O.WRD: TST R2 ;GET VALUE IF R2 IS NON-ZERO
9113 056126 001410  BEQ O.WRDA ;SKIP OTHERWISE
9114 056130 010405  MOV R4,R5 ; PUT VALUE IN CAD
9115 056132 006205  O.WRD1: ASR R5 ;MOVE ONE BIT TO CARRY
9116 056134 103711  O.ERR2: BCS O.ERR ;JUMP IF ODD ADDRESS
9117 056136 006305  ASL R5 ;RESTORE THE CARRY BIT
9118 056140 011500  MOV @R5,R0 ;GET CONTENTS OF WORD
9119 056142 004537 057226  JSR 5,O.CADV ;GO GET AND TYPE OUT @CAD
9120 056146 000714  BR O.DCD1 ;GO BACK TO DECODER
    
```


9177	056312	005702		O.WDS:	TST	R2		:CHECK FOR OBJECT FOUND
9178	056314	001621		O.ERR1:	BEQ	O.ERR		:ERROR IF NO OBJECT
9179	056316	013702	055472		MOV	O.MSK+2,R2		:SET ORIGIN
9180	056322	013705	055470		MOV	O.MSK,R5		:SET MASK
9181	056326	005105			COM	R5		:AND COMPLEMENT IT
9182	056330	020237	055474	O.WDS2:	CMP	R2,O.MSK+4		: IS THE SEARCH ALL DONE?
9183	056334	101217			BHI	O.DCD		: YES
9184	056336	011200			MOV	@R2,R0		: GET OBJECT
9185	056340	005701			TST	R1		:NO
9186	056342	001027			BNE	O.EFF1		:BRANCH IF EFFECTIVE SEARCH
9187	056344	010046			MOV	R0,-(SP)		
9188	056346	010403			MOV	R4,R3		:EXCLUSIVE OR
9189	056350	040400			BIC	R4,R0		: IS DONE
9190	056352	042603			BIC	(SP)+,R3		: IN A VERY
9191	056354	050003			BIS	R0,R3		: FANCY MANNER HERE
9192	056356	040503			BIC	R5,R3		:AND RESULT WITH MASK
9193	056360	001016		O.WDS3:	BNE	O.WDS4		:RE-LOOP IF NO MATCH
9194	056362	010446			MOV	R4,-(SP)		:REGISTERS R2,R4, AND R5 ARE SAFE
9195	056364	004537	057462		JSR	5,O.CRLF		:TYPE <CR,LF>
9196	056370	010200			MOV	R2,R0		:GET READY TO TYPE
9197	056372	004537	057226		JSR	5,O.CADV		: TYPE ADDRESS
9198	056376	012700	000057		MOV	#1,R0		:SLASH TO R0
9199	056402	004537	057370		JSR	5,O.FTYP		:TYPE IT
9200	056406	011200			MOV	@R2,R0		:GET CONTENTS
9201	056410	004537	057226		JSR	5,O.CADV		:TYPE CONTENTS
9202	056414	012604			MOV	(SP)+,R4		: RESTORE R4
9203	056416	005722		O.WDS4:	TST	(R2)+		:INCREMENT TO NEXT CELL AND
9204	056420	000743			BR	O.WDS2		: RETURN
9205	056422	020004		O.EFF1:	CMP	R0,R4		: IS (X)=K?
9206	056424	001755			BEQ	O.WDS3		:TYPE IF EQUAL
9207	056426	010003			MOV	R0,R3		:(X) TO R3
9208	056430	060203			ADD	R2,R3		:(X)+X
9209	056432	005203			INC	R3		
9210	056434	005203			INC	R3		:(X)+X+2

```

9211 056436 020304      CMP      R3,R4      :IS (X)+X+2=K?
9212 056440 001747      BEQ      0.WDS3     :BRANCH IF EQUAL
9213 056442 042700 177400  BIC      #177400,R0 :WIPE OUT EXTRANEIOUS BITS
9214 056446 110000      MOV      R0,R0     :EXTEND SIGN
9215 056450 000257      CCC
9216 056452 006300      ASL      R0        :MULTIPLY BY TWO
9217 056454 005200      INC      R0        :ADD TWO
9218 056456 005200      INC      R0
9219 056460 060200      ADD      R2,R0     :ADD PC
9220 056462 020004      CMP      R0,R4     :IS THE RESULT A PROPER REL. BRANCH?
9221 056464 000735      BR      0.WDS3
9222
9223      : PROCESS G - GO
9224
9225 056466 105037 057511  0.GO:  CLR      0.P      :DISALLOW PROCEED
9226 056472 006204      ASR      R4        :CHECK LOW ORDER BIT
9227 056474 103617      BCS      0.ERR2    :ERROR IF ODD NUMBER
9228 056476 006304      ASL      R4        :RESTORE WORD
9229 056500 010437 055462  MOV      R4,0.UPC  :SET UP NEW PC
9230 056504 112737 000340 177776  MOV      #0.STM,ST :SET HIGH PRIORITY
9231 056512 004537 057160  JSR      5,0.RSTT  :RESTORE TELETYPE
9232 056516 105037 057510  0.TBIT: CLR      0.T      :CLEAR BOTH
9233 056522 042737 000020 055464  BIC      #0.TBT,0.UST : T-BIT FLAGS
9234 056530 017737 176742 055502  MOV      @0.ADR1,0.UIN :SAVE INSTRUCTION
9235 056536 013777 057552 176732  MOV      0.TRTC,@0.ADR1 :REPLACE WITH TRAP
9236 056544 012600  0.G02: MOV      (SP)+,R0   :RESTORE
9237 056546 012601      MOV      (SP)+,R1   : R0
9238 056550 012602      MOV      (SP)+,R2   : THRU
9239 056552 012603      MOV      (SP)+,R3
9240 056554 012604      MOV      (SP)+,R4
9241 056556 012605      MOV      (SP)+,R5
9242 056560 012606      MOV      (SP)+,SP   : R5
9243 056562 013746 055464  MOV      0.UST,-(SP) : AND SP
9244 056566 013746 055462  MOV      0.UPC,-(SP) : AND STATUS
9245 056572 000006  0.RTIT: RTT      : AND PC
9246      : CHANGED TO RTI FOR 11/20 AND /05
9247
9248      : PROCESS P - PROCEED
9249      : ONLY ALLOWED AFTER A BREAKPOINT
9250 056574 105737 057511  0.PROC: TST      0.P      :CHECK LEGALITY OF PROCEED
9251 056600 001645      BEQ      0.ERR1    :NOT LEGAL
9252 056602 105037 057511  CLR      0.P      :CLEAR PROCEED FLAG
9253 056606 005702      TST      R2        :WAS COUNT SPECIFIED?
9254 056610 001402      BEQ      0.PR1     :NO
9255 056612 010437 055500  MOV      R4,0.CT   :YES, PUT AWAY COUNT
9256 056616 112737 000340 177776  0.PR1: MOV      #0.STM,ST :FORCE HIGH PRIORITY
9257 056624 004537 057160  JSR      5,0.RSTT  :RESTORE TTY
9258 056630 112737 000340 177776  0.C1:  MOV      #0.STM,ST :SET HIGH PRIORITY
9259 056636 105237 057510  INCB     0.T        :SET T-BIT FLAG
9260 056642 052737 000020 055464  BIS      #0.TBT,0.UST :SET T-BIT
9261 056650 000735      BR      0.G02
9262
9263      : BREAKPOINT HANDLER
9264      : A TRT BREAKPOINT CAUSES 0.BRK TO BE ENTERED, WHICH SAVES
9265      : VARIOUS ODDS AND ENDS, FINDS OUT IF THE BREAKPOINT WAS LEGAL,
9266      : AND GIVES CONTROL TO THE COMMAND DECODER

```



```

9267
9268 056652 012637 055462      0.BRK:  MOV      (SP)+,0.UPC      ;PRIORITY IS 7 UPON ENTRY
9269 056656 012637 055464      MOV      (SP)+,0.UST      ;SAVE STATUS AND PC
9270 056662 004037 057070      0.BK1:  JSR      0,0.SVR      ;SAVE VARIOUS REGISTERS
9271 056666 105737 057510      TSTB    0,T              ;CHECK FOR T-BIT SET
9272 056672 001311              BNE     0,TBIT           ;JUMP IF SET
9273 056674 013777 055502 176574  MOV     0,UIN,00.ADR1    ;REMOVE BREAKPOINTS
9274 056702 105737 055466      TSTB    0,PRI           ;CHECK IF PRIORITY
9275 056706 100C33              BPL     0,BK2           ;IS AS SAME AS USER PGM
9276 056710 113705 055464      MOV     0,UST,R5        ;PICK UP USER UST IF SO
9277 056714 000407              BR      0,BK3           ;AND DON'T COMPUTE THE PRIORITY
9278 056716 113705 055466      0.BK2:  MOV     0,PRI,R5    ;OTHERWISE PICK UP ACTUAL PRIORITY
9279 056722 000257              CCC     ;CLEAR CARRY
9280 056724 106005              RORB   R5               ;SHIFT LOW ORDER BITS
9281 056726 106005              RORB   R5               ;INTO
9282 056730 106005              RORB   R5               ;HIGH ORDER
9283 056732 106005              RORB   R5               ;POSITION
9284 056734 110537 177776      0.BK3:  MOV     R5,ST         ;PUT THE STATUS AWAY WHERE IT BELONGS
9285 056740 013705 055462      MOV     0,UPC,R5        ;GET PC, IT POINTS TO THE TRT
9286 056744 005745              TST    -(R5)           ;SUBTRACT TWO
9287 056746 010537 055462      MOV     R5,0.UPC        ;FROM THE USER'S PC
9288 056752 020537 055476      CMP     R5,0.ADR1       ;COMPARE WITH LIST
9289 056756 001417              BEQ    0,B2            ;JUMP IF FOUND
9290 056760 004537 057126      JSR    5,0.SVTT         ;SAVE TELETYPE STATUS
9291 056764 004537 057462      JSR    5,0.CRLF        ;
9292 056770 012704 057514      MOV     #0,BD,R4        ;ERROR, NOTHING FOUND
9293 056774 012703 057515      MOV     #0,BD+1,R3     ;
9294 057000 004537 057354      JSR    5,0.TYPE        ;OUTPUT 'BE' FOR BAD ENTRY
9295 057004 010500              MOV     R5,R0          ;
9296 057006 042737 000020 055464  BIC     #0,TBT,0.UST    ;CLEAR OUT ANY POSSIBLE FAKE T-BIT
9297 057014 000420              BR     0,B3            ;AND CONTINUE
9298 057016 005337 055500      0.B2:  DEC     0,CT          ;
9299 057022 003302              BGT    0,C1            ;JUMP IF REPEAT
9300 057024 012737 000001 055500  MOV     #1,0.CT        ;RESET COUNT TO 1
9301 057032 105237 057511      INCB   0,P             ;ALLOW PROCEED
9302 057036 004537 057126      JSR    5,0.SVTT         ;SAVE TELETYPE STATUS, R4 IS SAFE
9303 057042 012700 000102      MOV     #1B,R0         ;
9304 057046 004537 057370      JSR    5,0.FTYP        ;TYPE 'B'
9305 057052 013700 055476      MOV     0,ADR1,R0      ;GET ADDRESS OF BREAK
9306 057056 004537 057226      0.B3:  JSR    5,0.CADV      ;TYPE ADDRESS
9307 057062 005005              CLR    R5              ;CLEAR CAD
9308 057064 000137 055774      JMP    0,DCD           ;GO TO DECODER
9309
9310      ; SAVE REGISTERS R0-R6 IN INTERNAL STACK
9311
9312 057070 012637 057506      0.SVR:  MOV     (SP)+,0.XXX    ;PICK REGISTER FROM STACK AND SAVE
9313 057074 010637 055460      MOV     SP,0.USR        ;SAVE USER STACK ADDRESS
9314 057100 012706 055460      MOV     #0,USR,SP      ;SET TO INTERNAL STACK
9315 057104 010546              MOV     R5,-(SP)       ;SAVE
9316 057106 010446              MOV     R4,-(SP)       ;REGISTERS
9317 057110 010346              MOV     R3,-(SP)       ;1
9318 057112 010246              MOV     R2,-(SP)       ;THRU
9319 057114 010146              MOV     R1,-(SP)       ;5
9320 057116 013746 057506      MOV     0,XXX,-(SP)    ;PUT SAVED REGISTER ON STACK
9321 057122 005746              TST    -(SP)
9322 057124 000200              RTS     R0
  
```

CZ
 CZ
 HC
 HD
 HD
 HD
 HD
 HD
 HD
 HE
 HE
 HM
 HM
 HO
 HP
 HP
 HT
 HV
 HW
 HZ
 H.
 H.
 H.
 H.
 H.
 H.
 ID
 IE
 IL
 IN
 IO
 IR
 LC
 LC
 LF
 LI
 LK

ESEC	001420	1921#													
E.A0	005430	2022#	3562*	3587*	3641*	4052*	4127*	4304*	4346*	4395*	4430*	4585*	4643*	4747*	
		4822*	4900*	4958*	5420*	5425*	5429	5431*	5460	8696	8707	8719			
E.A1	005434	2024#	3564*	3589*	3643*	4054*	4129*	4306*	4348*	4397*	4432*	4587*	4645*	4749*	
		4824*	4902*	4960*	5421*	5433	5435*	5480	8696	8707	8719				
E.A2	005440	2026#	4131*	4308*	4350*	4434*	4589*	4647*	4751*	4904*	4962*	5422*	5437	5439*	
		8707	8719												
E.A3	005444	2028#	5423*												
E.B0	005432	2023#	3563*	3588*	3642*	4053*	4128*	4305*	4347*	4396*	4431*	4586*	4644*	4748*	
		4823*	4901*	4959*	5441	5443*	5470	8696	8707	8719					
E.B1	005436	2025#	3565*	3590*	3644*	4055*	4130*	4307*	4349*	4398*	4433*	4588*	4646*	4750*	
		4825*	4903*	4961*	5445	5447*	5490	8696	8707	8719					
E.B2	005442	2027#	4132*	4309*	4351*	4435*	4590*	4648*	4752*	4905*	4963*	5449	5451*	8707	
		8719													
E.B3	005446	2029#	4133*	4310*	4352*	4436*	4591*	4649*	4753*	4906*	4964*	5453	5455*	8719	
E.DDT	012662	3410*	3416*	3424#	5425										
FATT1	025056	4000	5349#	6119	6140										
FATT2	025152	4039	4196	5377#											
FCYL	027206	5736#													
FHDHM	027276	5761#	5770												
FHDTAB	027420	4248	4709	5795#											
FLGTST	027650	5837	5841	5856#											
FLOAD	027352	5779#													
FMTE =	000020	1161#													
FMT1	001452	1940#	5805*	5806*	5807*	5812									
FORM	031022	6154	6167#												
FORMAT	001450	1939#	4246*	4707*	5805	5834									
FRCYL	001364	1904#													
FRDY	024542	3147	3162	3171	3275	3284	5254	5265	5277#	5280	5615				
FRDY1	024610	5291#	5294	5602											
FSEC17	027116	5712#													
FTITLE	001360	1898#	5147	5149*											
GBA	024350	2972	5214#												
GDRVS	024210	2970	5169#												
GETSP	030452	3550	3555	3580	3605	3620	3631	3716	3733	3822	3848	3858	3869	3878	
		3893	3946	4017	4235	4370	4454	4489	4508	4696	4780	4811	4839	5041	
		5048	6078#	6084											
GINT	024376	2974	5227#												
GNS =	***** U	1279	7313	7314	7315	7316	7317	7319	7321	7322	7323	7324	7325	7326	
		7327													
GO =	000001	1125#													
GSTAT	026106	3445	3557	3582	3608	3622	3636	3700	3710	3719	3725	3813	3850	3870	
		3888	3925	3936	4019	4122	4230	4237	4260	4284	4335	4373	4387	4419	
		4455	4574	4632	4690	4698	4720	4741	4803	4889	4947	5359	5364	5384	
		5388	5550#	5619	5630	5642	5658	5763	5781	6135					
		5418	5561#												
GSTAT1	026142	5566	5574	5582	5589	5598#									
GSTAT2	026372	5158	7319#												
GTSWR =	104406	1994#	5316*	5332	8676	8684	8693	8703	8715	8728					
HASOF	005356	1990#	5312*	8676	8684	8693	8703	8715	8728						
HBA	005346	1987#	3165*	3166*	3167	3173	3278*	3279*	3280	3286	3485*	3511*	3655*	3668*	
HCS1	005340	3766*	3781*	3795*	3926	3967*	3995*	4034*	4072*	4119*	4123	4191*	4199	4257*	
		4261	4281*	4285	4332*	4336	4383*	4388	4416*	4420	4478*	4482	4571*	4575	
		4629*	4633	4717*	4721	4738*	4742	4799*	4804	4851*	4886*	4890	4944*	4948	
		5054*	5055*	5056	5251*	5252	5262*	5263	5309*	5524	5528	5552*	5598*	5599*	
		5600	5620	5931	6114*	6130*	6145*	8673	8681	8690	8700	8712	8725		

O.BKPT	055730	9048#	9106						
O.BK1	056662	8996	9270#						
O.BK2	056716	9275	9278#						
O.BK3	056734	9277	9284#						
O.BRK	056652	9013	9268#						
O.BUF	057543	9350	9359	9364	9469#				
O.B2	057016	9289	9298#						
O.B3	057056	9297	9306#						
O.CADV	057226	9119	9136	9159	9163	9197	9201	9306	9349#
O.CLGL	056044	9075	9077	9085#					
O.CLGT=	000014	9089	9459#						
O.CLS1	057452	9417	9419#						
O.CR	057516	9426	9428	9429	9443#				
O.CRET	056156	9097	9126#						
O.CRLF	057462	9134	9195	9291	9330	9335	9426#		
O.CRLS	057470	9070	9428#						
O.CRS	057474	9427	9429#						
O.CSR1	057512	9326*	9342	9437#					
O.CSR2	057513	9327*	9343	9438#					
O.CT	055500	9255*	9298*	9300*	9497#				
O.C1	056630	9258#	9299						
O.DCD	055774	9055	9060	9070#	9128	9183	9308		
O.DCD1	056000	9071#	9120	9164					
O.EFF	056304	9105	9174#						
O.EFF1	056422	9186	9205#						
O.ENTR	055510	8993#							
O.ERR	055760	9040	9051	9067#	9090	9116	9178	9421	
O.ERR1	056314	9178#	9251						
O.ERR2	056134	9116#	9150	9227					
O.FTYP	057370	9069	9138	9153	9199	9304	9375	9391	9396#
O.GET	057312	9019	9073	9372#	9377	9379	9381		
O.GO	056466	9099	9225#						
O.GO2	056544	9236#	9261						
O.LG =	000006	9023	9467#						
O.LGCH	057521	9086	9447#	9459					
O.LGDR	056074	9093	9096#	9108					
O.LGL =	000030	9108#							
O.LGL1	056046	9086#	9091						
O.LGL2	056066	9087	9092#						
O.MSK	055470	9179	9180	9182	9489#				
O.ODT	055504	1288	8991#	9478					
O.OFST	056232	9103	9149#						
O.OF1	056300	9162	9164#						
O.OP1	056170	9100	9132#						
O.OP2	056176	9044	9134#	9145					
O.ORPC	055702	9036#	9101						
O.P	057511	9011*	9225*	9250	9252*	9301*	9435#		
O.PRI	055466	9003	9274	9278	9488#				
O.PROC	056574	9107	9250#						
O.PR1	056616	9254	9256#						
O.RALL	055750	9014	9049	9059#					
O.RCSR=	177560	8978#	9326	9328*	9338	9340	9342*	9372	
O.RDB =	177562	8977#	9374						
O.REGT	055632	9019#	9098						
O.RSE1	057210	9339	9342#						
O.RSP	055642	9021#	9024						

O.RST	055546	8992	9001#							
O.RSTT	057160	9231	9257	9335#						
O.RST1	055576	9000	9008#							
O.RTIT	056572	9010*	9245#							
O.SCAN	056004	9030	9073#	9084						
O.SP	055674	9022	9031#							
O.SPC	057240	9352#	9360							
O.SP1	055662	9027#	9032							
O.STM =	000340	8967#	9012	9230	9256	9258				
O.STRT	055534	8991	8998#							
O.SVR	057070	9001	9270	9312#						
O.SVTT	057126	9290	9302	9326#						
O.T	057510	9232*	9259*	9271	9434#					
O.TBIT	056516	9232#	9272							
O.TBT =	000020	8968#	9233	9260	9296					
O.TC	057454	9414	9420#							
O.TCLS	057436	9036	9126	9132	9143	9413#				
O.TCSR=	177564	8980#	9327	9329*	9336	9343*	9396	9402		
O.TDB =	177566	8979#	9398*	9404*						
O.TL	057535	9020	9023	9031	9461#	9467				
O.TRTC	057552	9059	9235	9474#						
O.TVEC=	000014	8966#	8994	9012*	9013*					
O.TYPE	057354	9294	9365	9388#	9392	9430				
O.TYP1	057434	9389	9400	9409#						
O.TYP2	057414	9402#	9403	9406						
O.UIN	055502	9002	9234*	9273	9498#					
O.UPC	055462	8995*	9229*	9244	9268*	9285	9287*	9486#		
O.URO	055444	8998	9028	9479#						
O.USP	055460	8999*	9313*	9314	9485#					
O.UST	055464	8993*	9233*	9243	9260*	9269*	9276	9296*	9487#	
O.WDS	056312	9175	9177#							
O.WDS2	056330	9182#	9204							
O.WDS3	056360	9193#	9206	9212	9221					
O.WDS4	056416	9193	9203#							
O.WRD	056124	9096	9112#							
O.WRDA	056150	9113	9121#							
O.WRD1	056132	9115#	9122	9139						
O.WSCH	056310	9104	9176#							
O.XXX	057506	9312*	9320	9433#						
O.45	055610	9009	9011#							
PACK =	000003	1112#	3485	3655	3781	3967	4072	4851		
PARAM	001356	1897#	2852*	2855*	2966					
PARSRT	010002	1285	2852#							
PAT =	000020	1193#	3699							
PCA =	004000	1200#								
PCD =	010000	1201#								
PCLKF	005504	2060#	3011*	3018*	5982	6003				
PCVEC	001352	1890#	3012	3019						
PCYL	001372	1907#								
PFSRT	012664	3426#	6256							
PGE =	002000	1148#								
PIP =	020000	1186#								
PIRQ =	177772	991#								
PIRQVE=	000240	1085#								
PKRB	001344	1886#								
PKS	001340	1884#	3010	3017	5987*	6007*				

RKMR3 = 000036	1103#	3068	5296	5301	5320									
RKPRI 001336	1883#	5243												
RKVEC 001334	1882#	2993*	5231*	5234*	5241									
RKWC = 000002	1092#	3058	4118*	4251*	4279*	4328*	4381*	4412*	4475*	4566*	4625*	4712*	4736*	
	4796*	4881*	4940*	5311										
RLS = 000010	1141#													
RSEC 027032	5509	5692#												
RTT = 000006	8970#													
SAVREG= 104413	7059	7100	7325#	8879										
SBPAR 030306	5430	5434	5438	5442	5446	5450	5454	6020#						
SCLR = 000040	1143#	3140	3160	3273	5613									
SCOP1 = 104415	3157	3270	7327#											
SCOP1\$ 030360	6044#	7327												
SEC 001410	1917#	5996*												
SECFLG 027600	5813	5833#												
SECNT 001414	1919#													
SECTOR 001422	1922#	4274*	4275	4293*	4294	4330	4382	4414	5631*	5632*	5633*	5634*	5635*	
	5636*	5692*	5693*	5694*	5695*	5696*	5697*	5714	5718	5721	5887*	5891	5892*	
	5893*	5905	5915*	5916	5917*	5918*								
SEEK = 000017	1118#	4034	4191											
SELDRV= 000001	1111#	3165	3278	3766	3795	5054	5552	5598						
SETINT 024430	2994	5232	5241#											
SIZFLG 005510	2062#	2995*	3150	5187*	5207*									
SKI = 000002	1158#													
SORT 027726	5884#													
SPACE2 055420	8915	8924	8935	8945#										
SPBAR = 000040	1903#	6064	6081											
SRTSPL= 000011	1115#	3995	6114											
SRTTAB 002116	1960#	5896												
ST = 177776	8964#	8993	8994*	9007*	9230*	9256*	9258*	9284*						
STACK = 001100	979#	2857	2884	3047	3098	3158	3266	3271	3369	3436	3476	3504	3536	
	3689	3836	3911	3986	4104	4217	4675	4993	5023	5515	6216	6253	8942	
START 010012	1283	2855#												
START1 010420	2947#													
STKLMT= 177774	990#													
STOP 030500	6093#	6781	6864											
STOP1 030502	3758	6095#												
ST2 010470	2955	2966#												
ST3 010534	2956	2984#												
ST4 010566	2968	2989	2992#											
ST5 010612	2975	2997#	3137	3206	5130	6165								
ST5XY 024056	5119	5124#												
SUBCLR 026436	3440	3478	3508	3538	3574	3599	3614	3665	3691	3810	3838	3860	3880	
	3913	3948	3988	4007	4030	4067	4106	4141	4187	4222	4271	4323	4365	
	4407	4449	4465	4550	4677	4731	4771	4786	4841	4865	5043	5084	5613#	
	6095	6107												
SVAL = 100000	1188#													
SWR 001140	1790#	2882	2904*	2906	2912*	2919*	5156	5466	5476	5486	5496	6044	6179	
	6187	6192	6212	6335	6349	6351	6357	6364	6402	6409	6421	6425	6784	
	6823	6878*	8880	8938										
SWREG 000176	1281#	2912	5156	6784	6823	6846								
SW0 = 000001	1043#													
SW00 = 000001	1033#	1043												
SW01 = 000002	1032#	1042												
SW02 = 000004	1031#	1041												
SW03 = 000010	1030#	1040												

ABCDEFGHIJKLMN O P Q R S T U V W X Y Z

CALIB	1409#	6128														
CHECK	1366#	3566	3591	3645	4056	4134	4311	4353	4399	4437	4592	4650	4754	4826	4907	
	4965															
COMMEN	1#	1086#														
CWD2	1381#															
DRCLR	1394#	6142														
ENDCOM	1#	1086#														
ERROR	980#	3077	3135	3148	3163	3172	3195	3204	3223	3227	3238	3242	3276	3285	3303	
	3330	3334	3338	3342	3441	3479	3487	3491	3509	3513	3515	3539	3560	3569	3570	
	3571	3572	3575	3585	3594	3595	3596	3597	3600	3611	3615	3625	3639	3648	3649	
	3650	3651	3657	3661	3666	3670	3672	3692	3703	3707	3712	3722	3728	3768	3783	
	3797	3811	3839	3853	3861	3865	3873	3881	3885	3914	3933	3941	3949	3953	3958	
	3962	3969	3973	3989	3997	4001	4008	4022	4027	4031	4036	4040	4044	4049	4059	
	4060	4061	4062	4065	4068	4074	4078	4107	4121	4125	4137	4138	4139	4140	4142	
	4148	4150	4188	4193	4197	4201	4223	4240	4259	4263	4272	4283	4296	4302	4314	
	4315	4316	4317	4320	4324	4334	4341	4344	4356	4357	4358	4359	4366	4376	4385	
	4390	4393	4402	4403	4404	4405	4408	4418	4425	4428	4440	4441	4442	4443	4450	
	4466	4480	4486	4499	4504	4551	4573	4580	4583	4595	4596	4597	4598	4631	4638	
	4641	4653	4654	4655	4656	4678	4701	4719	4723	4732	4740	4757	4758	4759	4760	
	4766	4772	4787	4801	4808	4819	4829	4830	4831	4832	4842	4846	4853	4857	4866	
	4888	4895	4898	4910	4911	4912	4913	4946	4953	4956	4968	4969	4970	4971	5044	
	5065	5085	5530	5535	5539	5554	5567	5575	5583	5590	5616	6096	6108	6116	6120	
	6132	6138	6141	6147	6150	6209										
ESCAPE	1#	1086#														
F.EAB	1346#	4126	4303	4345	4429	4584	4642	4746	4899	4957						
GETPRI	1#	1086#														
GETSWR	1#	1086#	5151													
HDCHK3	1483#															
HDTBL	1496#															
LOOP	1330#	3156	3269													
MSG	3035#	3037	3081#	3083	3249#	3251	3358#	3360	3427#	3429	3468#	3470	3495#	3497	3520#	
	3522	3675#	3677	3826#	3828	3897#	3899	3977#	3979	4082#	4084	4206#	4208	4664#	4666	
	4981#	4983	5000#	5002												
MULT	1#	1086#														
NEWST	1#	1086#	3035	3081	3249	3358	3427	3468	3495	3520	3675	3826	3897	3977	4082	
	4206	4664	4981	5000												
OWNTAG	1324#	1881														
POP	1#	1086#	6586	6646	6647	7037	7233	7275								
PUSH	1#	1086#	6545	6607	6609	6630	7011	7204	7255							
QKPACK	1730#	3483	3653	3964	4070	4849										
QKSEEK	1508#	4190														
QKSRT	1706#	3987	6105													
QKUNLD	1746#	3507	3664													
RDATA	1577#															
RDHDR	1454#															
REPORT	1#	1086#														
SBOUND	1651#	4549	4863													
SCOPE	981#	3045	3096	3264	3367	3434	3474	3502	3534	3687	3834	3909	3984	4102	4215	
	4673	4991	5021	5095												
SETPRI	1#	1086#	6915													
SETTRA	7305#	7314	7315	7316	7317	7319	7321	7322	7323	7324	7325	7326	7327			
SETUP	1#	1086#	2878													
SKIP	1#	1086#	3023	3074	3300	3413	3419	3439	3482	3884	3890	4159	4997			
SLASH	1#	1086#														
SPACE	1086#															
STARS	1#	1086#	1292	1303	1305	1312	1765	1812	1815	3035	3044	3081	3095	3249	3263	

.STRAP	1#	941#	7282
.STYPB	1#		
.STYPD	1#	941#	6533
.STYPE	1#	941#	6437
.STYPO	1#	941#	6657
.S4OCA	1#		
.1170	1#		

. ABS. 057554 000

ERRORS DETECTED: 0

CZR6JF,CZR6JF.LST/SOL/CRF/NL:TOC=SYSMAC.SML,CZR6JF.P11
RUN-TIME: 20 24 2 SECONDS
RUN-TIME RATIO: 178/47=3.7
CORE USED: 43K (86 PAGES)