

RK611/RK06

SUBSYSTEM VERIFICATION 2
CZR6ND0

AH-9142D-MC

COPYRIGHT © 76-78

FICHE 1 OF 2

MAR 1978

digital

MADE IN USA




RK611/RK06

SUBSYSTEM VERIFICATION 2
CZR6ND0

AH-9142D-MC
COPYRIGHT © 76-78
FICHE 2 OF 2

MAR 1978
digital
MADE IN USA



96
97
98
99
100

8.2.3.5
8.2.3.6

CONTROL Z (IZ) FUNCTION
CONTROL C (IC) FUNCTION

TABLE OF CONTENTS (CONT'D)

101		
102		
103		
104		
105		
106		
107		
108		
109		
110	8.2.4	SPECIAL PARAMETER SPECIFICATIONS
111	8.2.4.1	PT - DATA PATTERN SELECT WORD
112	8.2.4.2	CS - CONTROL SWITCH WORD
113	8.3	DATA PATTERNS
114		
115	9.0	DESCRIPTION OF TESTS
116	9.1	TEST 1 - OFFSET-TO-FAILURE MEASUREMENT
117	9.2	NPR/MAIN MEMORY TESTS
118	9.2.1	TEST 2 - NPR/MEMORY WORD ADDRESSING TEST
119	9.2.2	TEST 3 - NPR/MEMORY BLOCK ADDRESSING TEST
120	9.2.3	TEST 4 - NPR/MEMORY DATA PATTERN TEST
121	9.3	TEST 5 - UNIBUS CONTENTION TEST
122	9.4	TEST 6 - MULTI-DRIVE INTERFERENCE TEST
123		
124	10.0	ERROR REPORTING
125	10.1	COMMON ERRORS
126	10.2	ERROR HANDLING
127	10.3	ERROR PRINTOUT EXAMPLES
128		
129	11.0	RK06-07 HEAD ALIGNMENT AID
130	11.1	HARDWARE REQUIREMENTS
131	11.2	OPERATIONAL MODES
132	11.2.1	MANUAL SELECT MODE
133	11.2.1.1	MANUAL SELECT ALIGNMENT
134	11.2.1.2	MANUAL SELECT VERIFY
135	11.2.1.3	MANUAL SELECT EXERCISE
136	11.2.2	AUTO SELECT MODE
137	11.2.2.1	AUTO SELECT ALIGNMENT
138	11.2.2.2	AUTO SELECT VERIFY
139	11.2.2.3	AUTO SELECT EXERCISE
140	11.3	ALIGNMENT AID ERROR MESSAGES
141		
142	APPENDIX A	SAMPLE ADDRESS 200 DEFAULT RUN
143	APPENDIX B	SAMPLE ADDRESS 204 RUN
144		
145	APPENDIX C	SAMPLE MANUAL MODE HEAD ALIGNMENT AID RUN
146		
147	APPENDIX D	SAMPLE AUTO MODE HEAD ALIGNMENT AID RUN
148		

149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204

1.0 ABSTRACT

THIS PROGRAM PERFORMS PART 2 OF THE RK611/RK06-RK07 SUBSYSTEM VERIFICATION TESTS, WHICH PROVIDE A FUNCTIONAL SHAKEDOWN OF THE ENTIRE SUBSYSTEM INCLUDING THE UNIBUS INTERFACE AND ACCESS TO MAIN MEMORY. THE TESTING IN PART 2 EMPLOYS WORST-CASE SITUATIONS INVOLVING HEAD OFFSETTING, MEMORY ADDRESSING AND DATA TRANSFER, UNIBUS CYCLE CONTENTION, AND MULTIPLE DRIVE OPERATIONS. ADDITIONALLY, AN RK06-07 HEAD ALIGNMENT AID IS PROVIDED TO FACILITATE ON-LINE ALIGNMENT OF DRIVE HEADS.

WITHIN THE VARIOUS SUBSYSTEM TESTS, EMPHASIS IS GIVEN TO USEFUL SCOPE LOOPS AND OPERATOR SPECIFICATION OF TEST PARAMETER VALUES. AT THE BEGINNING OF TESTING, THE FOLLOWING OPTIONS MAY BE SPECIFIED BY THE USER:

- RK611 REGISTER ADDRESS
- RK06-07 VECTOR ADDRESS
- RK06-07 PRIORITY LEVEL
- DRIVE (S) TO BE TESTED
- TEST (S) TO BE RUN
- NUMBER OF TEST ITERATIONS
- INITIAL DISK ADDRESS ON TRANSFERS
- DATA PATTERNS USED
- STALL TIME BETWEEN OPERATIONS

IN ADDITION, STANDARD SWITCH REGISTER OPTIONS ARE PROVIDED, FOR A VARIETY OF PROGRAM LOOPING, RUNNING, AND REPORTING MODES.

ERRORS WILL BE REPORTED AS THEY OCCUR. THE REPORT WILL INCLUDE A TEST NUMBER AND DESCRIPTION, CURRENT AND PREVIOUS OPERATIONS, GOOD AND BAD TEST DATA, AND APPLICABLE DEVICE REGISTER CONTENTS.

2.0 HARDWARE REQUIREMENTS

2.1 REQUIREMENTS FOR SUBSYSTEM TESTS

THE FOLLOWING HARDWARE IS REQUIRED TO RUN PART 2 OF THE SUBSYSTEM VERIFICATION TESTS:

- PDP-11/04 (05, 10 MFG. ONLY), 20, 34, 35, 40, 45, 50, 70 OR PDQ
- 16 K MEMORY
- CONSOLE TELETYPE
- RK06-07 UNIBUS CONTROLLER (RK611)
- 1 TO 8 RK06/07 DRIVES
- 1 TO 8 RK06/07 DISK CARTRIDGES (FORMATTED IN 20 OR 22 SECTOR FORMAT)

2.2 REQUIREMENTS FOR HEAD ALIGNMENT AID

205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260

ADDITIONAL HARDWARE IS REQUIRED BY THE RK06 HEAD ALIGNMENT AID:

RK06 FIELD TEST BOX (OR ALIGNMENT SECTION THEREOF)
RK06 ALIGNMENT CARTRIDGE
RK06 HEAD ALIGNMENT TOOL

3.0 PRELIMINARY PROGRAM REQUIREMENTS

BEFORE RUNNING THE SUBSYSTEM VERIFICATION PROGRAM, THE RK611 CONTROLLER DIAGNOSTIC (MAINDEC-11-CZR6A THRU CZR6E AND CZR6K) AND RK06 DRIVE DIAGNOSTIC (MAINDEC-11-CZR6H THRU CZR6J) SHOULD FIRST BE RUN, TO RESOLVE BASIC, SOLID HARDWARE FAULTS.

4.0 GENERAL PROGRAM CONSIDERATIONS

4.1 SYSMAC

THIS PROGRAM USES PORTIONS OF THE SYSMAC DIAGNOSTIC SYSTEM MACRO PACKAGE.

4.2 XXDP

THIS PROGRAM MAY BE LOADED UNDER XXDP. SUBSYSTEM TESTS 1-6 MAY BE RUN IN CHAIN OR DUMP MODE, BUT THE ALIGNMENT AID MAY ONLY BE RUN IN DUMP MODE.

4.2.1 CHAIN MODE

THIS PROGRAM IS DESIGNED TO BE RUN IN THE DEFAULT MODE WHEN CHAINED UNDER XXDP. THUS, INPUT DIALOGUE IS BYPASSED, AND RK06 UNIBUS ADDRESS AND INTERRUPT VECTOR ARE DEFAULTED TO STANDARD VALUES. ALL DRIVES PRESENT AND READY WILL BE TESTED WITH THE EXCEPTION OF DRIVE 0, IF THE RK06 CONTAINS THE XXDP MEDIUM.

4.2.2 DUMP MODE

THE PROGRAM CAN BE RUN IN DUMP MODE, WITH OR WITHOUT DEFAULT PARAMETERS. DRIVE 0 MAY BE TESTED, BUT IF IT CONTAINS THE XXDP MEDIUM, THE OPERATOR MUST REPLACE THE XXDP PACK WITH A FORMATTED SCRATCH PACK PRIOR TO TESTING (OR AN ALIGNMENT CARTRIDGE IF ALIGNMENT IS TO BE DONE ON DRIVE 0). A MESSAGE WILL INFORM THE OPERATOR WHEN

261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316

THIS IS NECESSARY.

4.3 ACT/APT

THE PROGRAM IS COMPATIBLE WITH ACT/APT CONVENTIONS. SUBSYSTEM TESTS 1-6 MAY BE RUN IN AUTOMATIC OR DUMP MODE, AND THE HEAD ALIGNMENT AID MAY ONLY BE RUN IN DUMP MODE.

4.3.1 AUTOMATIC MODE

THE PROGRAM PROVIDES FOR AUTOMATIC APT/ACT OPERATION. IN THIS MODE, PARAMETERS REVERT TO DEFAULT VALUES, AND ALL DRIVES WHICH ARE PRESENT AND READY ARE TESTED.

4.3.2 DUMP MODE

IN DUMP MODE, PARAMETERS MAY BE INPUT, OR DEFAULTED, AND SUBSYSTEM TESTS 1-6 OR HEAD ALIGNMENT AID MAY BE RUN.

4.3.3 APT ETABLE DEFINITIONS

THE FOLLOWING DEFINITIONS ARE VALID FOR SPECIFYING APT ENVIRONMENTAL TABLE (ETABLE) ENTRIES, VIA THE APT UTILITY PROGRAM :

1. SOFTWARE ENVIRONMENT
 - =1 IF APT SCRIPT MODE
 - =0 IF STANDALONE MODE
2. ENVIRONMENT MODE BYTE
 - BIT 7 = 1 ETABLE DOES SIZING
 - = 0 PROGRAM DOES SIZING
 - BIT 6 = 1 SPOOL MESSAGES TO APT IF SCRIPT MODE
 - = 0 DON'T SPOOL TO APT
 - BIT 5 = 1 SUPPRESS CONSOLE OUTPUT
 - = 0 ALLOW CONSOLE OUTPUT
 - BITS 4-0 NOT USED
3. SWITCH 1 (SOFTWARE SWITCH REGISTER)

IF ENVIRONMENT MODE BIT 7 (SIZING BIT) IS SET TO 1, THE SOFTWARE SWITCH REGISTER WILL BE USED, INSTEAD OF THE HARDWARE CONSOLE SWITCH REGISTER. REGARDLESS OF WHICH ONE IS USED, ALL BITS DEFINED IN SECTION 6.2 (SWITCH REGISTER OPTIONS) MAY USED WHEN RUNNING IN STANDALONE MODE.

IN APT SCRIPT MODE, HOWEVER, BIT 14 (LOOP ON TEST) MUST ALWAYS BE SET TO 0.

317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372

- 4. SWITCH 2 (USER SWITCH REGISTER)
NOT USED
- 5. MEMORY TYPES 1-4 AND MAX MEMORY ADDRESSES
NOT USED
- 6. INTERRUPT VECTOR 1
USED WHEN ENVIRONMENT MODE BIT 7 = 1. DEFAULT = 210
- 7. BUS PRIORITY 1
USED WHEN ENVIRONMENT MODE BIT 7 = 1. DEFAULT = 5
- 8. INTERRUPT VECTOR 2
NOT USED
- 9. BUS PRIORITY 2
NOT USED
- 10. BASE ADDRESS
USED WHEN ENVIRONMENT MODE BIT 7 = 1. DEFAULT = 177440
- 11. DEVICE MAP
USED WHEN ENVIRONMENT MODE BIT 7 = 1. EACH BIT SET TO 1 IN BITS
0-7 WILL SELECT THE CORRESPONDING DRIVE TO BE TESTED.
BITS 8-15 ARE NOT USED.

4.4 DUAL-ACCESS

THIS PROGRAM DOES NOT UTILIZE DUAL-ACCESS. FOR THE PURPOSES OF ALL TESTS (1-6), AND THE HEAD ALIGNMENT AID (SECTION 11), THE OPERATOR MUST GUARANTEE THAT THERE IS NO INTERFERENCE FROM THE UNUSED PORT. IF FAILURES ARE ENCOUNTERED IN TESTS 1-6 DUE TO INTERFERENCE FROM THE OTHER PORT, THE OPERATOR IS ADVISED TO SWITCH THAT PORT OFF-LINE AND RE-RUN THE TESTS.

4.5 MEMORY MANAGEMENT

THIS PROGRAM SUPPORTS MEMORY MANAGEMENT OPTIONS KT11C.D AND PDP11/70, FOR THE PURPOSES OF TESTS 2-4 ONLY. IN THESE TESTS (SEE SECTION 9.7) DIRECT ACCESS TO ALL OF PHYSICAL MEMORY ABOVE THE PROGRAM IS EXERCISED. FOR THE DURATION OF THESE 3 TESTS, MEMORY MANAGEMENT IS ENABLED. IN ALL OTHER TESTS, AND DURING THE USE OF THE HEAD ALIGNMENT AID, MEMORY MANAGEMENT IS DISABLED.

4.6 MEMORY PARITY CHECK

IF THE MEMORY PARITY CHECK OPTION IS AVAILABLE ON THE SYSTEM, ALL

373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428

TESTING IS DONE WITH PARITY CHECK ENABLED. PARITY ERRORS ARE REPORTED, AND TESTING IS ABORTED, UNLESS THE BYTE LABELED MEMABT WAS PREVIOUSLY LOADED WITH A NON-ZERO VALUE.

4.7 BAD SECTORS

ACCORDING TO A CONTROL SWITCH OPTION (SEE SECTION 8.2.4.2) THE BAD SECTOR FILE ON EACH DRIVE TO BE TESTED IS TYPED AT THE CONSOLE PRIOR TO TESTING. ALL DATA ERRORS OCCURRING IN THE PROGRAM ARE MASKED OUT IF THEY OCCUR ON SECTORS DESIGNATED AS BAD, (BY EITHER FACTORY OR SOFTWARE).

4.8 EXECUTION TIME

EXECUTION TIME IS DEPENDENT UPON PARAMETERS INPUT BY THE OPERATOR (SUCH AS STALL TIME OR ITERATION COUNT), AND TO A GREAT DEGREE, UPON THE AMOUNT OF MEMORY. HOWEVER, THE "AVERAGE TIME" REQUIRED TO RUN A QUICK VERIFICATION (FIRST PASS) IS 2 MINUTES (FOR A 64K SYSTEM). A SUBSEQUENT PASS WITH PARAMETERS DEFAULTED REQUIRES 3 MINUTES PER DRIVE (ON A 64-K SYSTEM).

NOTE: TIMES ARE APPROX DOUBLED FOR RK07 TESTING.

5.0 PROGRAM LOADING

THE PROGRAM CAN BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR FROM ANY MEDIA SUPPORTED BY XXDP.

6.0 STARTING PROCEDURE

6.1 STARTING ADDRESSES

200 NORMAL STARTING ADDRESS OF TESTS 1-6 (PARAMETERS DEFAULTED)
204 SELECT OPERATING PARAMETERS, RK06/07 UNIBUS ADDR. AND INTERRUPT VECTOR FOR TESTS 1-6
224 HEAD ALIGNMENT AID START ADDRESS

NOTE

FOR HEAD ALIGNMENT AID OPERATING INFORMATION PLEASE SKIP TO SECTION 11. THE SECTIONS WHICH IMMEDIATELY FOLLOW APPLY ONLY TO THE SUBSYSTEM TESTS (1-6).

429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484

6.2 SWITCH REGISTER OPTIONS USED

THIS PROGRAM IS DESIGNED TO ALLOW THE USE OF THE HARDWARE SWITCH REGISTER IF PRESENT, OR THE SYSMAC-SUPPORTED SOFTWARE SWITCH REGISTER (IF HARDWARE SWR IS NOT PRESENT OR IS SET TO ALL ONES). IN EITHER CASE, THE FOLLOWING OPTIONS ARE IMPLEMENTED WHEN THE APPROPRIATE BITS ARE SET TO 1:

BIT	OPTION
---	-----
15	HALT ON ERROR
14	LOOP ON TEST
13	INHIBIT ERROR REPORTS
12	REPORT DESCRIPTION ONLY, ON ERRORS
11	INHIBIT ITERATIONS
10	BELL ON ERROR
09	LOOP ON ERROR
08	APPLY RANDOM STALL BETWEEN OPERATIONS
06	REPORT ONE ERROR PER TRANSFER IN TESTS 2-4
01	INHIBIT WRITES IN TEST 1
00	REPORT ALL SOFTWARE COMPARE ERRORS IN TESTS 2-4.

NOTE

FOR ADDITIONAL PROGRAM CONTROL OPTIONS,
SEE DESCRIPTION OF CONTROL SWITCH WORD
(CS), SECTION 8.2.4.2 .

7.0 OPERATOR ACTION

1. LOAD PROGRAM INTO MEMORY (SEE SECTION 5.0)
2. LOAD A FORMATTED PACK ON EACH DRIVE TO BE TESTED.
3. BRING DRIVE (S) TO ONLINE STATE, WRITE ENABLED, AND LOCKED ON PORT.
4. LOAD THE DESIRED STARTING ADDRESS (SEE SECTION 6.1)
5. SET SWITCHES IF DESIRED (SEE SECTION 6.2)
6. PRESS START OR GIVE APPROPRIATE MONITOR START COMMAND.

8.0 PROGRAM ACTION

8.1 DESCRIPTION OF OPERATING PARAMETERS

AFTER THE PROGRAM IS STARTED, IT TYPES ITS IDENTIFICATION AS FOLLOWS:
"CZR6NDD RK11/RK06-RK07 SUBSYSTEM VERIFICATION:PART 2" FOLLOWED BY:
"LAST PHYS MEM ADRS=XXXXXXXX". THEN, EITHER THE TESTS BEGIN EXECUTION

485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539

WITH DEFAULT PARAMETERS, OR AN OPERATOR INTERACTIVE MODE IS ENTERED (SEE STARTING ADDRESSES, SECTION 6.1). IN THIS MODE OPERATING PARAMETERS MAY BE LISTED OR ALTERED BY VARIOUS MEANS. ALL PARAMETERS ARE TREATED AS OCTAL NUMBERS, AND THE PARAMETER LIST IS SHARED AMONG THE TESTS.

THE FOLLOWING IS THE LIST OF OPERATING PARAMETERS, (WHICH APPLY TO THE CURRENT SELECTION OF DRIVES AND TESTS). AFTER EACH, IS INDICATED THE VALID RANGE OF VALUES FOR THAT PARAMETER (IN OCTAL), AND ITS DEFAULT VALUE. ALL PARAMETERS ARE ENTERED AS OCTAL NUMBERS, AND THE PARAMETER MNEMONICS SHOWN ARE THOSE USED BY THE PROGRAM.

FC	FIRST CYLINDER ADDRESS IN TESTS WHICH ARE DONE OVER A RANGE OF CYLINDERS, FC=0-631, DEFAULT=0
LC	LAST CYLINDER ADDRESS IN TESTS WHICH ARE DONE OVER A RANGE OF CYLINDERS, LC=0-632, DEFAULT=632
FT	FIRST TRACK ADDRESS IN TESTS WHICH ARE DONE OVER A RANGE OF TRACKS, FT=0-2, DEFAULT=0
LT	LAST TRACK ADDRESS IN TESTS WHICH ARE DONE OVER A RANGE OF TRACKS, LT=0-2, DEFAULT=2
SO	FIRST SECTOR ADDRESS IN TESTS WHICH ARE DONE OVER A RANGE OF SECTORS USED ON ANY DRIVE WHICH HAS A 20-SECTOR FORMAT CARTRIDGE. SO=0-23, DEFAULT=0.
S1	LAST SECTOR ADDRESS IN TESTS WHICH ARE DONE OVER A RANGE OF SECTORS USED ON ANY DRIVE WHICH HAS A 20-SECTOR FORMAT CARTRIDGE. S1=0-23, DEFAULT=23.
S2	FIRST SECTOR ADDRESS IN TESTS WHICH ARE DONE OVER A RANGE OF SECTORS, USED ON ANY DRIVE WHICH HAS A 22-SECTOR FORMATTED CARTRIDGE, S2=0-25, DEFAULT=0.
S3	LAST SECTOR ADDRESS IN TESTS WHICH ARE DONE OVER A RANGE OF SECTORS, USED ON ANY DRIVE WHICH HAS A 22-SECTOR FORMATTED CARTRIDGE. S3=0-25, DEFAULT = 25.
PT	DATA PATTERN SELECT WORD (SEE SECTION 8.2.4.1 FOR DETAILS) PT=0-177777, DEFAULT=0
CS	CONTROL SWITCH WORD (SEE SECTION 8.2.4.2 FOR DETAILS) CS=0-000062, DEFAULT=0
ST	NUMBER OF UNIT STALL TIMES WITH WHICH TO STALL (DELAY) BETWEEN RKO6 COMMANDS

8.2 SELECTION OF OPERATING PARAMETERS (ADDRESS 204 START)

540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595

8.2.1 DRIVE SELECTION

AFTER AN ADDRESS 204 START, THE PROGRAM INDICATES INPUT MODE BY TYPING "PARAMETER INPUT MODE". THEN, THE RK611 REGISTER ADDRESS, RK06/07 VECTOR ADDRESS AND RK06 PRIORITY ARE OPENED FOR POSSIBLE MODIFICATION AS FOLLOWS:

```
RK06-07 BUS ADR = 177440 NEW=(TYPE NEW VALUE HERE)
RK06-07 VEC ADR = 210 NEW=(TYPE NEW VALUE HERE)
RK06-07 PRIORITY= 5 NEW=(TYPE NEW VALUE HERE)
```

NEXT THE PROGRAM TYPES THE NUMBER(S) OF THE CURRENT DRIVES UNDER TEST FOLLOWED BY A (*) ON THE NEXT LINE TO REQUEST NEW DRIVE NUMBERS. FOR EXAMPLE:

PARAMETER INPUT MODE

```
DRIVE(S)=0,1,2,4,7
* (INPUT, IF ANY, GOES HERE)
```

THE OPERATOR TYPES THE NEW NUMBERS (SEPARATED BY COMMAS) PLUS <CR> OR SIMPLY <CR> TO LEAVE THEM UNCHANGED. IF HE ENTERS DRIVE NUMBERS, THESE DRIVES ARE THEN CHECKED FOR VALID STATUS BY THE PROGRAM, AND ALL THOSE TYPED WHICH ARE ACCEPTABLE WILL NOW BE LISTED AS BEFORE. THE OPERATOR MAY MANUALLY RECONFIGURE THE DRIVES AND TYPE IN NEW DRIVE NUMBERS, AND THESE WILL BE CHECKED AND TYPED, UNTIL THE OPERATOR FINALLY TYPES JUST <CR>.

ON INITIAL ENTRY FROM ADDRESS 204, THE DRIVES WHICH ARE LISTED ARE ALL THOSE ON THE SUBSYSTEM WHICH ARE ON-LINE, READY, WRITE-ENABLED, AND LOADED WITH A CARTRIDGE OTHER THAN AN ALIGNMENT PACK. (THIS IS THE DEFAULT DRIVE SELECTION FOR ADDRESS 200 START). ON ALL OTHER ENTRIES TO THE DRIVE SELECTION ROUTINE (VIA <↑C> AS DESCRIBED IN SECTIONS 8.2.2.5 AND 8.2.3.6) THE PROGRAM FIRST TYPES :

```
TO TEST ALL DRIVES TYPE "A" <CR>, ELSE <CR>
* (CHARACTER GOES HERE)
```

NEXT, THE DRIVES ARE LISTED AS SHOWN ABOVE. IF (A) IS TYPED, ALL AVAILABLE DRIVES WILL BE LISTED, AND IF NOT, THE PREVIOUS SELECTION OF DRIVES WILL BE LISTED.

8.2.2 TEST SELECTION

WHEN THE OPERATOR FINALLY TYPES JUST <CR> IN RESPONSE TO THE DRIVE REQUEST, THE PROGRAM ENTERS THE TEST INPUT ROUTINE. THE FOLLOWING INSTRUCTIVE LINES ARE TYPED :

```
L = LIST TESTS
C = CHANGE TESTS
I = INPUT PARAMETERS AND RUN TESTS
```

596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651

THEN, THE FOLLOWING REQUEST IS MADE :

ENTER L,C, OR I
* (CHARACTER GOES HERE)

THE OPERATOR TYPES THE DESIRED CHARACTER PLUS <CR>.

8.2.2.1 LIST TESTS, (L)

IF (L) IS TYPED, THE PROGRAM TYPES THE CURRENT DESIRED TEST LIST, AS FOLLOWS :

TEST	ITERATIONS
1	0
2	177777
3	400
4	25
ETC.	

THE ITERATION NUMBER IS THE NUMBER OF TIMES THE TEST WILL BE RUN ON THIS PASS, AND IT MUST BE BETWEEN 0 AND 177777. IF IT IS ZERO, THAT TEST WILL NOT BE RUN. ON THE FIRST TIME THROUGH, ALL TESTS ARE LISTED WITH DEFAULT ITERATIONS (YET TO BE DETERMINED).

WHEN THE LIST IS COMPLETED, THE PROGRAM RETURNS TO TYPE : "ENTER L,C, OR I" AGAIN.

8.2.2.2 CHANGE TESTS, (C)

IF (C) IS TYPED, THE PROGRAM THEN ASKS: "TO DEFAULT TESTS TYPE D<CR>, ELSE <CR>". IF JUST <CR> IS TYPED, THE PROGRAM SEQUENTIALLY OPENS EACH TEST FOR POSSIBLE ALTERATION OF THE ITERATION NUMBER. EACH TEST IS OPENED AND A NEW LINE IS TYPED, GIVING THE TEST NO. AND ITER. NO. IN OCTAL, FOLLOWED BY (*) ON THE SAME LINE. FOR EXAMPLE :

TEST	ITERATIONS
0	0 * (INPUT, IF ANY, GOES HERE)

THE OPERATOR THEN TYPES THE NEW VALUE PLUS <CR>, OR JUST <CR> TO LEAVE IT UNCHANGED. IF THE OPERATOR TYPES A NUMBER FOLLOWED BY (!) (EXCLAMATION POINT), THE NUMBER JUST ENTERED WILL BE LOADED INTO THE ITERATION TABLE FOR ALL REMAINING TESTS. AFTER ALL TESTS HAVE BEEN OPENED, THE PROGRAM RETURNS TO TYPE : "ENTER L,C, OR I" AGAIN.

8.2.2.3 INPUT PARAMETERS AND RUN TESTS, (I)

IF (I) IS TYPED, THE PROGRAM ENTERS THE PARAMETER LIST ALTERATION

652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707

ROUTINE, DESCRIBED IN SECTION 8.2.3, IN WHICH OPERATING PARAMETERS MAY BE INPUT, AND TESTING BEGUN.

8.2.2.4 CONTROL Z (↑Z) FUNCTION

IF THE OPERATOR WISHES TO EXIT AT ANY TIME FROM L OR C MODE, AND RETURN TO SELECT A NEW MODE (L, C, OR I), CONTROL Z (↑Z) MAY BE TYPED.

8.2.2.5 CONTROL C (↑C) FUNCTION

IF THE OPERATOR WISHES TO TERMINATE L, C, OR I MODE, AND RETURN TO REQUEST NEW DRIVES AND TESTS, CONTROL C (↑C) MAY BE TYPED.

8.2.3 PARAMETER LIST ALTERATION

THE PROGRAM NEXT TYPES THE FOLLOWING INSTRUCTIVE LINES:

```
T = TYPE LIST
O = OPEN LIST
S = SET INDIVIDUAL PARAM.
R = RUN TESTS
ENTER T O S OR R
* (CHARACTER GOES HERE)
```

THE OPERATOR TYPES THE DESIRED CHARACTER PLUS <CR>.

8.2.3.1 TYPE LIST, (T)

IF (T) IS TYPED, THE PROGRAM TYPES THE CURRENT PARAMETER LIST, AS FOLLOWS:

```
FC = XXXXXX
LC = XXXXXX
ETC.
```

WHEN THE LIST IS COMPLETED, THE PROGRAM RETURNS TO TYPE "ENTER T,O,S, OR R" AGAIN.

8.2.3.2 OPEN LIST, (O)

IF (O) IS TYPED THE PROGRAM THEN ASKS: "TO DEFAULT ALL PARAMETERS TYPE D<CR>, ELSE <CR>". IF JUST <CR> IS TYPED, THE PROGRAM SEQUENTIALLY OPENS EACH OPERATING PARAMETER IN THE LIST FOR ALTERATION

708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762

(IN THE ORDER SHOWN IN SECTION 8.1). EACH PARAMETER IS OPENED AND A NEW LINE IS TYPED, GIVING THE PARAMETER AND ITS CURRENT VALUE (IN OCTAL), FOLLOWED BY (*) ON THE SAME LINE. FOR EXAMPLE:

IC=3 * (INPUT, IF ANY, GOES HERE)

THE OPERATOR THEN TYPES THE NEW VALUE PLUS A <CR> OR JUST <CR> TO LEAVE THAT PARAMETER UNCHANGED. AFTER ALL PARAMETERS HAVE BEEN OPENED FOR ALTERATION, THE PROGRAM RETURNS TO TYPE "ENTER T,O,S, OR R" AGAIN.

8.2.3.3 SET INDIVIDUAL PARAMETER, (S)

IF (S) IS TYPED, THE PROGRAM TYPES THE PROMPTER (>) ON THE NEXT LINE, AND WAITS FOR THE OPERATOR TO SET THE VALUE OF ANY INDIVIDUAL PARAMETER:

ENTER T,O,S, OR R

*S

> (ENTER PARAMETER AND VALUE HERE)

THE OPERATOR TYPES THE PARAMETER AND ITS NEW VALUE FOLLOWED BY <CR>, AND THE PROGRAM GIVES THE PROMPTER (>) AGAIN AS IN THE FOLLOWING EXAMPLE:

> FC = 600
> FS = 12
> IT = 1
> ETC.

TO TERMINATE INDIVIDUAL SETTING MODE, THE OPERATOR TYPES CONTROL Z (↑Z), AND THE PROGRAM RETURNS TO TYPE "ENTER T,O, S, OR R" AGAIN.

8.2.3.4 RUN TESTS, (R)

IF THE OPERATOR TYPES (R), EXECUTION OF TESTS BEGINS, USING ALL THE CURRENT PARAMETERS.

8.2.3.5 CONTROL Z (↑Z) FUNCTION

IF THE OPERATOR WISHES TO EXIT AT ANY TIME FROM T, O, S, OR R MODE (RUNNING TESTS), AND RETURN TO SELECT A NEW MODE (T,O,S, OR R), CONTROL Z (↑Z) MAY BE TYPED.

8.2.3.6 CONTROL C (↑C) FUNCTION

763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817

IF THE OPERATOR WISHES TO TERMINATE T, O, OR S MODE, OR STOP TEST EXECUTION (R MODE), CONTROL C (↑C) MAY BE TYPED, AND THE PROGRAM WILL RETURN TO REQUEST NEW DRIVE SELECTION (SEE SECTION 8.2.1). (ON AN ADDRESS 200 DEFAULT RUN, TYPING CONTROL C CAUSES THE PROGRAM TO HALT AFTER COMPLETING ANY DATA TRANSFER).

8.2.4 SPECIAL PARAMETER SPECIFICATIONS

8.2.4.1 PT-DATA PATTERN SELECT WORD

THE OPERATOR SPECIFIES A WORD OF SIXTEEN BITS (6 OCT. DIGITS), TO SELECT UP TO ALL SIXTEEN OF THE PATTERNS, LISTED IN SECTION 9.5.1. THE NO. OF ANY BIT SET IN PT CORRESPONDS TO THE NO. OF A PATTERN CHOSEN. IF THE HIGH BIT OF PT (BIT 15) IS SET, THE USER WILL BE ASKED TO TYPE UP TO SIXTEEN DATA WORDS WHICH WILL BE LOADED INTO THE BUFFER FOR PATTERN 15. THE PROGRAM TYPES:

"SELECT USER DEFINED PATTERN 15"

NEXT, EACH OF UP TO 16 WORDS ARE REQUESTED BY THE PROGRAM IN THE SAME MANNER IN WHICH THE OPERATING PARAMETERS ARE OPENED FOR ALTERATION (SEE SECT. 8.2.3.2):

WORD 0 = (OLD VALUE) * (NEW VALUE GOES HERE)
WORD 1 = (OLD VALUE) * (NEW VALUE GOES HERE)
ETC.

FOR EACH WORD, THE USER TYPES THE NEW VALUE PLUS <CR>, OR JUST <CR>, (TO LEAVE IT UNCHANGED). TO INPUT LESS THAN 16 WORDS FOR PATTERN 15, THE OPERATOR MAY TYPE (!) (EXCLAMATION POINT) AND THE PROGRAM WILL FILL UP THE REST OF THE PATTERN 15 BUFFER WITH THE LAST WORD SPECIFIED. NEXT, THE PROGRAM WILL CONTINUE, IN THE PROPER PARAMETER INPUT MODE (O OR S).

8.2.4.2 CS- CONTROL SWITCH WORD

IN ADDITION TO THE OPTIONS PROVIDED BY THE SWITCH REGISTER (HARDWARE OR SOFTWARE), A CONTROL SWITCH WORD (CS) MAY BE SPECIFIED AMONG THE OPERATING PARAMETERS TO PROVIDE THE FOLLOWING OPTIONS:

BIT	OPTION
---	-----
05	DROP DRIVE IF 20 (DEC) ERRORS EXCEEDED
04	TYPE BAD SECTOR FILES (BSF'S) ON FIRST PASS)
01	INHIBIT OFFSET REPORTS IN TEST 1

818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841

NOTE
OTHER BITS UNUSED

8.3 DATA PATTERNS

THIS SECTION DESCRIBES THE DATA PATTERNS AVAILABLE FOR USE IN THE TESTS. EACH DATA PATTERN IS COMPRISED OF 16 WORDS. PATTERNS ARE REPEATED AS NECESSARY TO OBTAIN THE DESIRED WORD COUNT ON THE WRITE DATA COMMANDS. THE MAXIMUM ALLOWABLE WORD COUNT IS DETERMINED BY THE AMOUNT OF AVAILABLE BUFFER SPACE AT THE END OF THE PROGRAM, AND COULD BE AS LARGE AS 65,536 (DEC) WORDS. DATA SPIRALING AND TRACK SWITCHING IS THUS POSSIBLE DURING THE DATA TESTS.

THE FOLLOWING IS THE LIST OF 16 SELECTABLE DATA PATTERNS (IN OCTAL), WITH NOTABLE FEATURES DESCRIBED:

842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890

0	1	2	3
HIGH-LOW FREQUENCY MIX	HIGH FREQUENCY PHASE MIX	LOW FREQUENCY PHASE MIX	MAXIMUM PRECOMPENSATION PHASE MIX
-----	-----	-----	-----
177777	000000	052525	133333
177777	000000	052525	066666
177777	000000	052525	155555
052525	177777	125252	155555
052525	177777	125252	133333
052525	177777	125252	066666
177777	000000	052525	066666
177777	000000	052525	155555
052525	177777	125252	155555
052525	177777	125252	133333
177777	000000	052525	133333
052525	177777	125252	133333
177252	000000	052525	133333
177252	177777	125252	133333
172765	000000	052525	133333
172765	177777	125252	133333
4	5	6	7
ROTATING BOUNDARY PULSE PRECOMPENSATION	ROTATING CELL PULSE PRECOMPENSATION	ALL ZEROS	ALL ONES
-----	-----	-----	-----
121105	026455	000000	177777
150442	113226	000000	177777
064221	045513	000000	177777
132110	122645	000000	177777
055044	151322	000000	177777
026422	064551	000000	177777
013211	132264	000000	177777
105504	055132	000000	177777
042642	026455	000000	177777
021321	113226	000000	177777
110550	045513	000000	177777
044264	122645	000000	177777
022132	151322	000000	177777
011055	064551	000000	177777
104426	132264	000000	177777
042213	055132	000000	177777

891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937

8 SHIFTED 1 IN FIELD OF 0'S	9 SHIFTED 0 IN FIELD OF 1'S	10 ALTERNATING 0-1	11 ALTERNATING 1-0
000001	177776	052525	125252
000002	177775	052525	125252
000004	177773	052525	125252
000010	177767	052525	125252
000020	177757	052525	125252
000040	177737	052525	125252
000100	177677	052525	125252
000200	177577	052525	125252
000400	177377	052525	125252
001000	176777	052525	125252
002000	175777	052525	125252
004000	173777	052525	125252
010000	167777	052525	125252
020000	157777	052525	125252
040000	137777	052525	125252
100000	077777	052525	125252

12 SHIFTING 0'S AND 1'S	13 COMPOSITE ROTATING	14 PSEUDO- RANDOM	15 USER- DEFINED
000001	072307		
000003	135143		
000007	156461		
000017	167230		
000037	073514		
000077	035646		
000177	016723		
000377	107351		
000777	143564		
001777	061672		
003777	030735		
007777	114356		
017777	046167		
037777	123073		
077777	151453		
177777	164616		

938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993

9.0 DESCRIPTION OF TESTS

9.1 TEST 1 - OFFSET-TO-FAILURE MEASUREMENT

IN THIS TEST A REPEATED PATTERN 072307(OCT) IS WRITTEN INTO ALL WORDS OF SECTORS FS AND LS ON TRACKS 0-2 OF CYLINDERS FC AND LC. THE SAME SECTORS ON ADJACENT CYLINDERS ARE THEN WRITTEN WITH 167230(OCT) (TO ESTABLISH A KNOWN PATTERN), BUT THEY ARE NOT TESTED. THEN, EACH DESIRED SECTOR IS WRITE CHECKED WITH INCREASING POSITIVE OFFSETS, UNTIL EITHER A "DATA TYPE" ERROR OCCURS, OR THE FULL RANGE OF POSITIVE OFFSETS HAVE BEEN APPLIED. THEN, THE SAME SECTOR IS WRITE CHECKED WITH INCREASING NEGATIVE HEAD OFFSETS, UNTIL FAILURE OR MAXIMUM NEGATIVE OFFSET IS APPLIED. THIS IS DONE FOR ALL THE SECTORS ORIGINALLY WRITTEN, IN THE FOLLOWING ORDER: SECTORS FS AND LS ON CYLINDERS FC AND LC FOR TRACK 0, THEN FOR TRACK 1, AND FINALLY FOR TRACK 2. THE OFFSET-TO-FAILURE RESULTS ARE REPORTED IN ORDER OF INCREASING TRACKS, AS FOLLOWS:

OFFSET-TO-FAILURE MEASUREMENTS:

TRACK	CYLN	SECT	-OFST (UIN)	-OFST (UIN)
X	XXX	XX	XXXX	XXXX
X	XXX	XX	XXXX	XXXX
X	XXX	XX	XXXX	XXXX

ETC.

NOTE

IN AN ADRS 200 DEFAULT RUN, FS DEFAULTS TO 0, AND LS DEFAULTS TO 12(OCT), FOR THIS TEST.

9.2 NPR / MAIN MEMORY TESTS

THIS GROUP OF TESTS EXERCISES ALL MEMORY ABOVE THE PROGRAM, VIA READ/WRITE NPR TRANSFERS WITH THE RK06. THE TESTS ARE DESIGNED TO DIAGNOSE MEMORY TRANSFER FAILURES DURING HEAVY NPR ACTIVITY, IN SYSTEMS PROVIDED WITH MEMORY MANAGEMENT (KT 11 C, D OR PDP 11/70), ALTHOUGH MEMORY MANAGEMENT IS NOT REQUIRED.

NOTE

THERE IS NO PROGRAM RELOCATION (EXCEPT FOR THE XXDP OR ABSOLUTE LOADER, IF

994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048

PRESENT). HENCE, MEMORY IN WHICH THE PROGRAM RESIDES IS NOT TESTED. ALSO, THE UNIBUS I/O ADDRESSES ARE NOT TESTED. IF IT IS DESIRED THAT THE LOADER BE DESTROYED, SO THAT ADDITIONAL MEMORY MAY BE TESTED, LOCATION 170 (KILLDR:) MAY MANUALLY BE SET TO A NON-ZERO VALUE.

THERE ARE 3 MEMORY TESTS PROVIDED. TESTS 2 AND 3 ARE TESTS OF MEMORY ADDRESSING CAPABILITY DURING DISK NPR'S, AND TEST 4 IS AN NPR/MEMORY DATA PATTERN TEST. DURING TESTING, MEMORY MANAGEMENT WILL BE ENABLED IF INSTALLED, AND ALL OPERATIONS WILL BE PERFORMED IN KERNAL MODE, WITH ADDRESS RELOCATION BEING DONE THROUGH MANIPULATION OF KERNAL I PAGE ADDRESS REGISTERS.

9.2.1 TEST 2 - NPR/MEMORY WORD ADDRESSING TEST

STARTING AT THE FIRST ADDRESS OF THE NEXT 1 K MEMORY BLOCK BEYOND THE END OF THE READ/WRITE DATA BUFFER (RWBUF), WRITE UNIQUE NUMBERS (STARTING WITH 1) INTO EACH OF UP TO 64K WORDS (DEPENDING ON THE AMOUNT OF PHYSICAL MEMORY). THESE NUMBERS REFLECT UNIQUE ADDRESSES WITHIN THE 64K BLOCK. NEXT WRITE THE 64K WORDS (MAX) ONTO DISK AT FC, FS, FT (SCALED, IF NECESSARY, TO AVOID PACK OVERFLOW). THEN ZERO THE ENTIRE 64K BLOCK IN MEMORY, AND READ THE DATA BACK FROM THE DISK, AT THE SAME PHYSICAL ADDRESSES. COMPARE THE DATA READ TO THE DATA WRITTEN. TYPE THE FAILING VIRTUAL (IF MEM. MANAGEMENT) AND PHYSICAL ADDRESSES, AS WELL AS THE GOOD AND BAD DATA, FOR UP TO THE FIRST 10 (DECIMAL) FAILING LOCATIONS.

IF MEMORY MANAGEMENT IS PROVIDED AND THERE IS ADDITIONAL MEMORY TO TEST, REPEAT THE ABOVE ADDRESSING TEST FOR EACH OF THE REMAINING 64K PHYSICAL MEMORY BLOCKS.

9.2.2 TEST 3 - NPR/MEMORY BLOCK ADDRESSING TEST

IN THIS TEST, MEMORY BLOCK ADDRESSING CAPABILITY DURING RK06 NPR'S IS TESTED.

THE TEST BEGINS BY WRITING A SINGLE NUMBER INTO ALL LOCATIONS OF EACH MEMORY BLOCK OF UP TO 64K WORDS. THIS NUMBER UNIQUELY DEFINES EACH BLOCK. THEN WRITE EACH BLOCK ONTO DISK AT ADDRESS FC, FS, FT (SCALED, IF NECESSARY TO AVOID PACK OVERFLOW OR DESTRUCTION OF THE BAD SECTOR FILE). ZERO THE BLOCK IN MEMORY, AND THEN READ THE DATA BACK INTO THE PROPER PHYSICAL ADDRESSES, DO THIS FOR ALL 64K BLOCKS, AND THEN COMPARE THE CONTENTS OF ALL THE MEMORY TO EXPECTED VALUES. TYPE FAILURES AS DESCRIBED ABOVE FOR THE FIRST 10(DEC) FAILING LOCATIONS IN EACH 64K MEMORY BLOCK.

1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104

9.2.3 TEST 4 - NPR/MEMORY DATA PATTERN TEST

IN THIS TEST, ALL PHYSICAL MEMORY LOCATIONS ABOVE THE PROGRAM (NOT INCLUDING UPPER UNIBUS DEVICE ADDRESSES) ARE EXERCISED WITH UP TO 15 DATA PATTERNS, AS CHOSEN FROM THE FIRST 14 PATTERNS DESCRIBED IN SECTION 8.3, PLUS PATTERN 15 (USER DEFINED PATTERN). THE DATA PATTERNS DESIRED FOR THIS TEST ARE CHOSEN SEPARATELY, HOWEVER, AND THEY DEFAULT TO PATTERNS 8, 9, 10, AND 11.

MEMORY IS TESTED IN BLOCKS OF 64K, STARTING AT THE FIRST ADDRESS OF THE NEXT 1K MEMORY BLOCK BEYOND THE PROGRAM. EACH BLOCK OF UP TO 64K IS LOADED WITH DATA, WRITTEN ONTO DISK AT FC, FS, FT, LOADED WITH ZEROS, AND READ BACK AND COMPARED. THIS IS DONE FOR EACH OF THE DATA PATTERNS CHOSEN, INCLUDING AN OPTIONAL PATTERN CHOSEN BY THE USER.

9.3 TEST 5 - UNIBUS CONTENTION TEST

THE PURPOSE OF THIS TEST IS TO EXERCISE THE NPR CONTROL LOGIC WITHIN THE CONTROLLER IN SUCH A MANNER THAT A CONTENTION FOR MEMORY CYCLES ARISES BETWEEN THE PROCESSOR AND THE RK06.

FIRST, A WRITE DATA IS BEGUN ON CYLINDER FC, (SCALED TO AVOID PACK OVERFLOW) AT SECTOR 0, WITH THE BUS ADDRESS INCREMENT INHIBIT BIT SET IN THE CONTROLLER. USING A WORD COUNT OF 12000(OCT) OR 13000(OCT) (DEPENDING ON THE FORMAT), THE ENTIRE TRACK IS WRITTEN WITH THE FIRST WORD OF USER DEFINED PATTERN 15 (IF SELECTED) OR THE FIRST WORD OF PATTERN 13 (BY DEFAULT). THEN, AN INSTRUCTION LOOP IS ENTERED IN WHICH A NON-EXISTENT UNIBUS DEVICE ADDRESS IS REFERENCED ONCE PER PASS. THIS WILL RESULT IN A PROCESSOR SEIZURE OF THE UNIBUS, FOR 5-20 MICRO-SEC (DEPENDING ON THE PROCESSOR), FOLLOWED BY A NON-EXISTENT MEMORY PROCESSOR TRAP, ONCE PER PASS. THUS, FOR EACH PASS THROUGH THE INSTRUCTION LOOP, THE CONTROLLER IS FORCED TO LOSE FROM ONE TO FOUR NPR BUS CYCLES. THE EXECUTION TIME OF THE LOOP DETERMINES THE REPITITION RATE OF THE NON-EXISTENT MEMORY REFERENCES, AND THIS IS CHOSEN TO ALLOW ENOUGH NPR'S SO THAT THERE SHOULD BE NO DATA LATE ERRORS IN A FAULT-FREE CONTROLLER. THE DATA IS THEN WRITE CHECKED FOR VERIFICATION, AND THE ABOVE TEST IS REPEATED USING A READ DATA COMMAND. NO ERRORS ARE EXPECTED.

THE ABOVE OPERATIONS ARE REPEATED 15 MORE TIMES, USING THE NEXT WORD OF THE PROPER PATTERN (13 OR 15) EACH TIME, TO WRITE AND READ THE ENTIRE TRACK.

9.4 TEST 6 - MULTI-DRIVE INTERFERENCE TEST

THIS TEST PERFORMS MULTI-DRIVE POSITIONING OPERATIONS, WHILE A LARGE DATA TRANSFER IS IN PROGRESS ON THE DRIVE UNDER TEST, FOR THE PURPOSE OF DETECTING PROBLEMS OF CONCURRENT DRIVE OPERATION. THE TEST IS RUN ONLY IF THERE IS MORE THAN ONE DRIVE ON THE SUBSYSTEM.

1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160

THE TEST PROCEEDS AS FOLLOWS: IT IS FIRST DETERMINED WHICH DRIVE(S) (BESIDE THE ONE UNDER TEST) EXIST AND ARE OPERATIONAL. THESE DRIVES ARE THEN CLEARED AND A SEEK TO CYL 0 IS DONE ON EACH. NEXT, A SEEK IS DONE TO CYLINDER FC (SCALED, IF NECESSARY) ON THE DRIVE UNDER TEST. A SEEK IS NOW BEGUN ON EACH OF THE OTHER DRIVES, EACH TO A DIFFERENT PSEUDO-RANDOM CYLINDER ADDRESS. THIS SHOULD REQUIRE FROM 10-67 MILLI-SEC TO COMPLETE. AS SOON AS THESE SEEKS ARE BEGUN, A WRITE DATA IS BEGUN ON THE DRIVE UNDER TEST, AT THE CURRENT CYLINDER (FC), SECTOR 0, TRACK 0, WITH THE BUS ADDRESS INCREMENT INHIBIT BIT SET IN THE CONTROLLER, AND WITH A WORD COUNT OF 15,616 (DEC) WORDS IF 20 SECTOR FORMAT, OR 17,152 (DEC) WORDS IF 22 SECTOR FORMAT. THIS WORD COUNT AMOUNTS TO A FULL CYLINDER + 1 SECTOR OF DATA. THIS TRANSFER REQUIRES FROM 101-126 MILLI-SEC TO COMPLETE, AND IN THAT TIME, ALL THE OTHER DRIVES SHOULD HAVE COMPLETED POSITIONING. NEXT, A WRITE CHECK IS DONE TO VERIFY THE DATA WRITTEN ON THE DRIVE UNDER TEST, AND A CHECK IS MADE TO INSURE THAT ALL OTHER DRIVES WHICH PERFORMED SEEKS WERE ABLE TO COMPLETE THEM SUCCESSFULLY, BY CHECKING ATTENTION BITS AND COMPARING DRIVE CYLINDER ADDRESSES TO EXPECTED VALUES.

10.0 ERROR REPORTING

10.1 COMMON ERRORS

THE FOLLOWING IS A LIST OF COMMON ERROR MESSAGES WHICH ACCOMPANY ERROR TYPEOUTS FROM THE SUBSYSTEM VERIFICATION PROGRAM. THE ERRORS ARE SELF-EXPLANATORY.

1. UNIBUS PARITY ERROR
2. NON-EXISTANT MEMORY ERROR
3. NON-EXISTANT DRIVE ERROR
4. UNIT FIELD ERROR
5. SUBSYSTEM TIMEOUT
6. SERCON PARITY ERROR
7. DRIVE DETECTED PARITY ERROR
8. AC LOW
9. SPEED LOSS
10. ILLEGAL FUNCTION ERROR
11. PROGRAMMING ERROR
12. NON-EXECUTABLE FUNCTION ERROR
13. DRIVE TYPE ERROR
14. FORMAT ERROR
15. WRITE LOCK ERROR
16. DRIVE UNSAFE ERROR
17. SEEK INCOMPLETE ERROR
18. CYLINDER OVERFLOW ERROR
19. ILLEGAL CYLINDER ADDRESS ERROR
20. DRIVE OFF TRACK
21. DRIVE TIMING ERROR
22. DATA LATE ERROR

1161	
1162	
1163	
1164	
1165	
1166	
1167	
1168	
1169	
1170	
1171	
1172	
1173	
1174	
1175	
1176	
1177	
1178	
1179	
1180	
1181	
1182	
1183	
1184	
1185	
1186	
1187	
1188	
1189	
1190	
1191	
1192	
1193	
1194	
1195	
1196	
1197	
1198	
1199	
1200	
1201	
1202	
1203	
1204	
1205	
1206	
1207	
1208	
1209	
1210	
1211	
1212	
1213	
1214	
1215	
1216	

23. CONTROLLER TIMEOUT ERROR
 24. OPERATION INCOMPLETE ERROR
 25. HEADER VRC ERROR
 26. DATA CHECK ERROR
 27. WRITE CHECK ERROR
 28. DATA MISCOMPARE
 29. NO DRIVE RESPONSE - UFE AND NXD
 30. DRIVE ERROR WILL NOT CLEAR
 31. DRIVE STATUS CHANGE WILL NOT CLEAR
 32. ATTENTION BUT NO STATUS CHANGE OR FAULT
 33. ATTENTION BUT DRIVE NOT AVAILABLE
 34. ERROR WHILE GATHERING DRIVE STATUS
 35. MULTIPLE DRIVE SELECT
 36. HEADER COMPARE ERROR
 37. ERROR IN RECALIBRATE FOR RECOVERY
 38. CLEAR CONTROLLER DID NOT CLEAR ERROR
 39. NO ATTENTION IN ATTENTION SUMMARY REGISTER
 40. UNSOLICITED ATTENTION
 41. UNEXPECTED DATA TYPE ERROR
 42. ATTENTION DID NOT RESET WITH CLEAR
 43. SUBSYSTEM CLEAR DID NOT CLEAR DRIVE ATTENTION
 44. DATA LATE WHEN UNLOADING HEADER
 45. CONTROLLER ERROR WHEN DRIVER SERVICING
 46. RETRY UNSUCCESSFUL
 47. BAD SECTOR ERROR ON SECTOR NOT LISTED BAD

10.2 ERROR HANDLING

ERRORS REPORTED BY THE PROGRAM CONSIST OF COMMON FAILURES RESULTING FROM ATTEMPTED SUBSYSTEM FUNCTIONS, AS WELL AS CERTAIN ERRORS UNIQUE TO PARTICULAR TESTS. EACH ERROR PRINTOUT CONSISTS OF AN ERROR DESCRIPTION AND TEST NUMBER, POSSIBLY FOLLOWED BY HEADER LINES, COLUMN HEADINGS, AND COLUMNS OF REGISTER CONTENTS IN OCTAL. AS MUCH MEANINGFUL REGISTER DATA AS POSSIBLE (FOR EXAMPLE, RK611 REGISTERS) ARE REPORTED IN A GIVEN ERROR. IN THE CASE OF A DATA MISCOMPARE, FOR INSTANCE, THE NUMBER GOOD DATA WORD, BAD DATA WORD, PHYSICAL MEMORY ADDRESS, VIRTUAL ADDRESS, AND MEMORY MANAGEMENT REGISTER CONTENTS (IF PRESENT) ARE REPORTED. OTHER ERROR REPORTS MAY CONSIST OF A SINGLE DESCRIPTIVE LINE.

10.3 ERROR PRINTOUT EXAMPLES

EXAMPLE 1:

** WRITE CHECK ERROR
 TEST 2

PREVIOUS COMMAND:

DRIVE	CMND	CYLNR	TRACK	SECTOR	WD CNT
000000	000121	000016	000001	000000	175000

1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272

```

HI BA  LO BA
000000 061566

CURRENT COMMAND:
ERR PC  DRIVE  CMND  CYLNDR  TRACK  SECTOR  WD CNT
041154  000000  000131  000016  000001  000006  175000
HI BA  LO BA
000000  061566

```

```

PACK ADDRESS OF ERROR(S):
CYLNDR  TRACK  SECTOR
000016  000001  000006

```

EXAMPLE 2:

** DATA MISCOMPARE
TEST 2

```

PREVIOUS COMMAND:
DRIVE  CMND  CYLNDR  TRACK  SECTOR  WD CNT
000000  000131  000016  000001  000000  175000
HI BA  LO BA
000000  074000

```

```

CURRENT COMMAND:
ERR PC  DRIVE  CMND  CYLNDR  TRACK  SECTOR  WD CNT
033156  000000  000121  000016  000001  000000  175000
HI BA  LO BA
000000  074000

```

```

PACK ADDRESS OF ERROR(S):
CYLNDR  TRACK  SECTOR
000016  000001  000000

```

WD #	GOOD	BAD	HI PHY	LO.PHY	VRT AD	KIPAR6
000400	000401	125252	000000	075000	155000	000600
000401	000402	125252	000000	075002	155002	000600
000402	000403	125252	000000	075004	155004	000600
000403	000404	125252	000000	075006	155006	000600
000404	000405	125252	000000	075010	155010	000600
000405	000406	125252	000000	075012	155012	000600
000406	000407	125252	000000	075014	155014	000600
000407	000410	125252	000000	075016	155016	000600
000410	000411	125252	000000	075020	155020	000600
000411	000412	125252	000000	075022	155022	000600

11.0 RK06 HEAD ALIGNMENT AID

THIS PROGRAM IS PROVIDED AS A SOFTWARE AID TO HEAD ALIGNMENT OF THE

1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327

RK06 DRIVE, TO BE USED IN CONJUNCTION WITH THE RK06 FIELD TEST BOX, OR OTHER SUITABLE INDICATOR OF HEAD ALIGNMENT. THE PROGRAM OPERATES IN TWO MODES. THE FIRST IS MANUAL SELECT MODE, WHICH SELECTS A SPECIFIC DRIVE AND HEAD TO BE ALIGNED BY TTY INPUT AT THE CONSOLE. THE SECOND MODE IS AUTO-SELECT MODE, WHICH ALLOWS REMOTE DRIVE AND HEAD SELECTION THROUGH OPERATION OF DRIVE DUAL-PORT SELECT SWITCHES. IN EITHER MODE THE OPERATOR HAS THE OPTION TO EITHER PERFORM HEAD ALIGNMENT, VERIFY ALIGNMENT, OR REQUEST UP TO FIVE MINUTES OF RANDOM SEEK EXERCISES TO BE PERFORMED ON THE SPECIFIED DRIVE (S).

11.1 HARDWARE REQUIREMENTS

TO PERFORM HEAD ALIGNMENT, THE ALIGNMENT INDICATING DEVICE MUST BE CONNECTED TO THE DRIVE VIA THE ALIGNMENT CABLE WHICH ATTACHES TO THE RK06 READ/WRITE MODULE. THE ALIGNMENT INFORMATION FROM THE DRIVE MUST BE DISPLAYED ON A METER OR OTHER INDICATOR. EACH DRIVE TO BE ALIGNED MUST BE LOADED WITH AN RK06 ALIGNMENT CARTRIDGE, AND MUST BE WRITE-PROTECTED. UP TO EIGHT DRIVES PER CONTROLLER MAY BE ALIGNED, AND EACH DRIVE MAY BE OPERATED IN SINGLE-PORT MODE ONLY. FOR THE PURPOSE OF THE HEAD ALIGNMENT AND ALL SWITCH REGISTER BITS (HARDWARE OR SOFTWARE) ARE IGNORED.

11.2 OPERATIONAL MODES

THE PROGRAM COMMUNICATES WITH THE OPERATOR DOING THE ALIGNMENT THROUGH CONSOLE DIALOGUE. WHEN THE PROGRAM IS STARTED AT ADDRESS 224(OCTAL), IT TYPES IDENTIFICATION:

" *** RK06-07 HEAD ALIGNMENT AID ***
TYPE H(CR) FOR INFORMATION- OTHERWISE, TYPE (CR) "

NEXT, THE PROGRAM REQUESTS THE DESIRED MODE OF OPERATION:

" MANUAL OR AUTO MODE (M OR A) ? "

THE OPERATOR MAKES THE SELECTION, AND ENTERS ONE OF THE FOLLOWING MODES.

11.2.1 MANUAL SELECT MODE

IN THIS MODE, THE DRIVE(S) TO BE ALIGNED AND THE HEAD(S) TO BE SELECTED ARE SPECIFIED BY TTY INPUT. THIS MODE IS USEFUL FOR SYSTEMS WITH FEW DRIVES, WHICH ARE IN CLOSE PROXIMITY TO THE CONSOLE, AS IN TYPICAL FIELD INSTALLATIONS.

THE PROGRAM FIRST ECHOS THE MODE:

1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381

"* MANUAL SELECT MODE *"
AND TYPES "ENTER DRIVE NO. (0-7):".

THE OPERATOR TYPES THE DRIVE NUMBER, THE PROGRAM TYPES THE DRIVE SERIAL NUMBER, AND THEN ASKS "ALIGN, VERIFY, OR EXERCISE (A, V, OR E) ?". THE OPERATOR RESPONDS, AND THE PROGRAM ENTERS THE APPROPRIATE SUB-MODE.

11.2.1.1 MANUAL SELECT ALIGNMENT

ALIGNMENT IN MANUAL MODE PROCEEDS AS FOLLOWS. THE PROGRAM TYPES:

"* MANUAL SELECT ALIGNMENT *," FOLLOWED BY
" ENTER HEAD NO. (0-2):"

THE OPERATOR TYPES THE DESIRED HEAD NUMBER, AND THE PROGRAM UNLOADS THE HEADS ON THE DRIVE, IN ANTICIPATION OF OPERATOR MOUNTING OF THE HEAD ALIGNMENT TOOL. THE PROGRAM TYPES "TYPE<R> WHEN READY:". AFTER THE TOOL HAS BEEN MOUNTED THE OPERATOR TYPES <R>, AND THE PROGRAM LOADS HEADS AND RESPONDS WITH:

"HEADS POSITIONED AT CYLINDER 365(OCT)"
AND "HEAD X SELECTED"

THE POSITIONING TO CYLINDER 365 IS DONE IN SINGLE INCREMENT SEEKS, TO AVOID EXCESSIVE MOMENTUM ON THE POSITIONER, WHILE THE ALIGNMENT TOOL IS INSTALLED. THE OPERATOR MAY NOW PROCEED TO ALIGN THIS HEAD, AND THE PROGRAM LOOPS BACK TO ASK FOR ANOTHER HEAD NUMBER ON THIS DRIVE. IF THE OPERATOR TYPES CONTROL Z (↑Z) THE PROGRAM WILL LOOP BACK TO ASK FOR "ALIGN OR EXERCISE ?" (STILL IN THE SAME MODE). IF CONTROL C (↑C) IS TYPED, THE PROGRAM LOOPS FURTHER BACK TO ASK FOR A NEW DRIVE NUMBER (STILL IN THE SAME MODE). IF CONTROL R (↑R) IS TYPED, THE PROGRAM EXITS FROM THE CURRENT MODE, AND DOES A COMPLETE RESTART.

11.2.1.2 MANUAL SELECT VERIFY

VERIFY MODE IDENTIFIES ITSELF AS FOLLOWS :

"* MANUAL SELECT VERIFY *", FOLLOWED BY
"ENTER HEAD NO. (0-2) :"

THE VERIFY MODE IS IDENTICAL TO THE ALIGNMENT MODE, EXCEPT THAT UNLOADING AND LOADING OF HEADS IS NOT DONE BETWEEN HEAD SELECTIONS. THEREFORE, IN THIS MODE, THE OPERATOR MAY SELECT HEADS FOR QUICK ALIGNMENT VERIFICATION (USING THE ALIGNMENT METER), WITHOUT THE DELAYS OF UNLOADING AND LOADING HEADS. IN THIS MODE, THE OPERATOR WILL NOT BE ASKED TO "TYPE <R> WHEN READY".

1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437

11.2.1.3 MANUAL SELECT EXERCISE

WHEN THE EXERCISE SUB-MODE OF MANUAL SELECT MODE IS ENTERED, THE PROGRAM UNLOADS HEADS ON THE SELECTED DRIVE, AND TYPES "TYPE <R> WHEN READY". THE OPERATOR MUST THEN REMOVE THE ALIGNMENT TOOL PRIOR TO THE RANDOM SEEKS WHICH FOLLOW, AND ALLOW EXERCISES TO PROCEED BY TYPING <R>. THE PROGRAM THEN LOADS HEADS, AND RESPONDS WITH:

"* SEEK EXERCISES IN PROGRESS ON DRIVE X *".

AT THIS POINT, 7500 RANDOM SEEKS ARE BEGUN ON THE DRIVE, WHICH LASTS FOR ABOUT FIVE MINUTES. UPON COMPLETION OF THESE EXERCISES, THE PROGRAM RETURNS TO ASK FOR "ALIGN OR EXERCISE ?" (STILL IN MANUAL MODE) ON THIS DRIVE. WHILE IN EXERCISE SUB-MODE, THE CHARACTERS (↑Z), (↑C), AND (↑R) PERFORM THE SAME FUNCTIONS AS DESCRIBED IN SECTION 11.2.1.1.

11.2.2 AUTO SELECT MODE

IN THIS MODE, ALL SELECTION OF DRIVES AND HEADS FOR ALIGNMENT IS DONE BY SEQUENTIAL OPERATION OF DRIVE PORT SELECT SWITCHES. THIS ALLOWS COMMUNICATION WITH THE PROGRAM TO BE REMOTE FROM THE CONSOLE. THIS AUTO SELECT MODE IS WELL SUITED TO THE MANUFACTURING TEST ENVIRONMENT, OR TO A FIELD INSTALLATION, WHICH HAS A NUMBER OF REMOTE DRIVES. THE PROGRAM FIRST ECHOS THE MODE:

" * AUTO SELECT MODE * ", AND ASKS
"ALIGN OR EXERCISE (A OR E) ?".

THE OPERATOR RESPONDS, AND THE PROGRAM ENTERS THE APPROPRIATE SUB-MODE.

11.2.2.1 AUTO SELECT ALIGNMENT

ALIGNMENT IN AUTO SELECT MODE PROCEEDS AS FOLLOWS. THE PROGRAM TYPES:

" * AUTO SELECT ALIGNMENT * ".

THE PROGRAM CONSTANTLY SCANS ALL DRIVES 0-7 TO DETERMINE THE EXISTENCE OF EACH. WHENEVER A DRIVE IS DESELECTED BY THE OPERATION OF ITS PORT SELECT SWITCH, THE PROGRAM RECEIVES A NON-EXISTENT DRIVE INDICATION WHEN IT SELECTS THAT DRIVE. THEN, WHEN THE PROGRAM DETERMINES THAT A DRIVE WHICH WAS PREVIOUSLY OFF-LINE (DESELECTED) HAS JUST BECOME ON-LINE (SELECTED), IT PREPARES FOR ALIGNMENT ON THAT DRIVE. IN SUMMARY, THE OPERATOR SELECTS A DRIVE FOR ALIGNMENT BY DEPRESSING AND THEN RELEASING THE PORT SELECT SWITCH (FOR THE PORT IN USE) ON THAT DRIVE.

THE PROGRAM RECOGNIZES THE DRIVE SELECTED, AND CHECKS IT TO BE SURE

1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493

THAT IT IS WRITE-LOCKED. THE PROGRAM THEN TYPES:

"DRIVE X SELECTED"

AND THEN IT UNLOADS THE HEADS ON THAT DRIVE, SO THAT THE OPERATOR CAN MOUNT THE HEAD ALIGNMENT TOOL. WHEN IT IS MOUNTED THE OPERATOR MUST DEPRESS AND RELEASE THE PORT SWITCH AGAIN, AND THE PROGRAM LOADS HEADS, SEEKS IN SINGLE INCREMENTS OUT TO THE ALIGNMENT CYLINDER (365 OCT.), AND TYPES:

"HEADS POSITIONED AT CYLINDER 365(OCT.)
HEAD 0 SELECTED".

AFTER THE OPERATOR ALIGNS HEAD 0, HE MAY PROCEED TO HEAD 1, BY DEPRESSING AND RELEASING THE PORT SELECT SWITCH. WHEN HE DOES, THE HEADS WILL BE UNLOADED AGAIN, AND THE OPERATOR MAY MOVE THE ALIGNMENT TOOL TO HEAD 1, AND UPON DEPRESSING AND RELEASING THE PORT SWITCH AGAIN, THE HEADS WILL BE LOADED, THE PROGRAM WILL SEEK TO CYLINDER 365(OCT), AND TYPE:

"HEADS POSITIONED AT CYLINDER 365(OCT)
HEAD 1 SELECTED".

THIS PROCESS MAY BE CONTINUED WITH HEADS BEING SELECTED IN THE ORDER 0, 1, 2, 0, 1, 2, 0, ETC. UNTIL THE OPERATOR HAS COMPLETED THE ALIGNMENT.

WHEN THE OPERATOR COMPLETES ALIGNMENT ON THIS DRIVE, HE SHOULD REMOVE THE ALIGNMENT TOOL, AND SWITCH THE DRIVE ON-LINE. IF HE THEN WISHES TO SELECT ANOTHER DRIVE, HE MUST SWITCH THE DESIRED DRIVE OFF-LINE AND THEN ON-LINE AGAIN TO INITIATE SELECTION. WHEN ALL DESIRED DRIVES HAVE BEEN ALIGNED THE OPERATOR TYPES ↑Z OR ↑R, AS DESCRIBED IN SECTION 11.2.1.1. BEFORE LEAVING ALIGNMENT MODE AND PROCEEDING TO DO SEEK EXERCISES, THE OPERATOR MUST BE SURE TO REMOVE THE ALIGNMENT TOOL(S) FROM ALL DRIVE(S).

NOTE

THE ↑C FUNCTION DOES NOT APPLY IN AUTO MODE.

11.2.2.2 AUTO SELECT VERIFY

VERIFY MODE IDENTIFIES ITSELF AS FOLLOWS :

"* AUTO SELECT VERIFY *"

THE AUTO SELECT VERIFY MODE IS IDENTICAL TO THE AUTO ALIGNMENT MODE,

1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549

EXCEPT THAT UNLOADING AND LOADING OF HEADS IS NOT DONE BETWEEN HEAD SELECTIONS. THEREFORE, IN THIS MODE, THE OPERATOR MAY SELECT HEADS FOR QUICK ALIGNMENT VERIFICATION (USING THE ALIGNMENT METER), WITHOUT THE DELAY OF UNLOADING AND LOADING HEADS.

11.2.2.3 AUTO SELECT EXERCISE

IN AUTO SELECT EXERCISE SUB MODE, RANDOM SEEK EXERCISES ARE PERFORMED UPON ALL DRIVES WHICH ARE ON-LINE. DRIVES ARE EXERCISED SEQUENTIALLY, STARTING WITH DRIVE 0. THE OPERATOR SPECIFIES EITHER LONG EXERCISES (7500 SEEKS- 5 MINUTES) OR SHORT EXERCISES (1500 SEEKS- 1 MINUTE) TO BE PERFORMED UPON EACH DRIVE.

AUTO SELECT EXERCISE MODE IDENTIFIES ITSELF AS FOLLOWS:

" * AUTO SELECT EXERCISES * "
FOLLOWED BY "SHORT OR LONG (S OR L) ?".

THE OPERATOR TYPES HIS RESPONSE, AND THE SELECTED SEEK EXERCISES ARE PERFORMED ON EACH DRIVE. UPON COMPLETION OF THESE EXERCISES, THE PROGRAM RETURNS TO ASK FOR "ALIGN OR EXERCISE?" (STILL IN AUTO MODE). WHILE IN EXERCISE SUB-MODE THE CHARACTERS ↑Z AND ↑R PERFORM THE SAME FUNCTIONS AS DESCRIBED IN SECTION 11.2.1.1.

NOTE

BEFORE REQUESTING AUTO-EXERCISE MODE, THE OPERATOR MUST REMOVE THE ALIGNMENT TOOL (WHILE STILL IN AUTO-ALIGNMENT MODE) WHILE THE HEADS ARE UNLOADED.

11.3 ALIGNMENT AID ERROR MESSAGES

1. "DRIVE X NOT READY! PLEASE START IF DESIRED, THEN PRESS 'CONT' ON CPU WHEN READY." - THIS INDICATES THAT A DRIVE SELECTED FOR ALIGNMENT WAS FOUND NOT READY.

2. "DRIVE X NOT WRITE-LOCKED! PLEASE SET WRITE LOCK SWITCH. PRESS 'CONT' ON CPU WHEN READY." - THIS INDICATES THAT A DRIVE SELECTED FOR ALIGNMENT WAS FOUND NOT TO BE WRITE-PROTECTED.

3. "PLEASE LOAD ALIGNMENT CARTRIDGE ON DRIVE X! PRESS 'CONT' ON

1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573

CPU WHEN READY." - THIS INDICATES THAT A DRIVE SELECTED FOR ALIGNMENT WAS NOT LOADED WITH AN ALIGNMENT CARTRIDGE.

4. "MULTIPLE DRIVES AUTO-SELECTED! PRESS 'CONT' TO RESTART."
- THIS INDICATES THAT IN AUTO ALIGNMENT MODE MORE THAN ONE OF THE DRIVES WERE SELECTED FOR ALIGNMENT SIMULTANEOUSELY.

5. "CANNOT READ BAD SECTOR FILE ON DRIVE X! PRESS 'CONT' ON CPU TO RESTART". - THIS INDICATES THAT A READ ERROR WAS ENCOUNTERED WHILE THE PROGRAM WAS ATTEMPTING TO IDENTIFY THE CARTRIDGE ON DRIVE X AS AN ALIGNMENT CARTRIDGE.

6. "? X" - THIS IS TYPED BY THE PROGRAM IN RESPONSE TO THE INPUT OF AN INVALID PARAMETER, SHOWN HERE AS X. THE OPERATOR SHOULD NOW ENTER THE PROPER VALUE.

APPENDIX A

SAMPLE ADDRESS 200 DEFAULT RUN

THE FOLLOWING PRINTOUT WAS THE RESULT OF RUNNING SUBSYSTEM VERIFICATION, PART 2, ON A SINGLE DRIVE (DRIVE 0), FOR THE FIRST PASS OF THE PROGRAM (QUICK-VERIFY PASS). IN THIS MODE, ALL MESSAGES APPEARING HERE WERE OUTPUTS--NO OPERATOR INPUTS ARE PROVIDED ON AN ADDRESS 200 RUN.

CZR6NDO - RK611/RK06-RK07 SUBSYSTEM VERIFICATION : PART 2

LAST PHYS MEM ADR = 377776

DRIVE 1 NON-EXISTENT
DRIVE 2 NON-EXISTENT
DRIVE 3 NON-EXISTENT
DRIVE 4 NON-EXISTENT
DRIVE 5 NON-EXISTENT
DRIVE 6 NON-EXISTENT
DRIVE 7 NON-EXISTENT

DRIVE(S) = 0

TESTING DRIVE 0
DRIVE SER. NO. 8
CART. SER. NO. 334

OFFSET-TO-FAILURE MEASUREMENTS:

TRACK	CYLN	SECT	+OFST (UIN)	-OFST (UIN)
0	0	0	NONE	NONE
0	0	12	NONE	1175
0	631	0	NONE	NONE
0	631	12	NONE	NONE
1	0	0	1050	NONE
1	0	12	NONE	1200
1	631	0	NONE	NONE
1	631	12	NONE	NONE
2	0	0	NONE	NONE
2	0	12	NONE	NONE
2	631	0	NONE	NONE
2	631	12	NONE	NONE

END PASS # 1

1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628

1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684

APPENDIX B
SAMPLE ADDRESS 204 RUN

THE FOLLOWING PRINTOUT WAS THE RESULT OF RUNNING SUBSYSTEM VERIFICATION, PART 2, ON A SINGLE DRIVE (DRIVE 0), WITH PARTICULAR TESTS SELECTED TO BE RUN FOR SPECIFIED NUMBERS OF TIMES, WITH SPECIFIED PARAMETERS, AND A SPECIFIED NO. OF PROGRAM PASSES. SPECIFICALLY, IT WAS DESIRED THAT TEST 1 BE RUN ONCE, TEST 4 ONCE, AND TEST 6 ONCE. THESE TESTS WERE SPECIFIED TO RUN FOR 1 PROGRAM PASS, USING PARAMETERS SPECIFIED BY THE OPERATOR. IN THIS CASE, SECTOR ADDRESS LIMITS (S2 AND S3) AND DATA PATTERN (PT) WERE SPECIFIED AS NON-DEFAULT VALUES.

CZR6ND0 - RK611/RK06-RK07 SUBSYSTEM VERIFICATION:PART 2

LAST PHYS MEM ADR=377776

PARAMETER INPUT MODE

RK06-07 BUS ADR = 177440 NEW =
RK06-07 VEC ADR = 210 NEW =
RK06-07 PRIORITY = 5 NEW =

DRIVE(S) = 0

*

L = LIST TESTS
C = CHANGE TESTS
I = INPUT PARAMETERS AND RUN TESTS

ENTER L,C, OR I

* C
TO DEFAULT TESTS TYPE D <CR>, ELSE <CR>
*

TEST	ITERATIONS
1	2 * 1
2	2 * 0
3	2 * 0
4	2 * 0\0\1

1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740

5 2 * 0
6 100 * 1

ENTER L,C, OR I
* L

TEST	ITERATIONS
1	1
2	0
3	0
4	1
5	0
6	1

ENTER L,C, OR I
* I

T = TYPE PARAMETER LIST
O = OPEN PARAMETER LIST
S = SET INDIVIDUAL PARAM
R = RUN TESTS

ENTER T,O,S, OR R
* T

FC=0
LC=632
FT=0
LT=2
SO=0
S1=23
S2=0
S3=25
PT=0
CS=0
ST=0

ENTER T,O,S, OR R
* S

> S2=4
> SV=20
SV=20?
> S3=20
> PT=100000
TO MODIFY PATTERN 15, TYPE M <CR>, ELSE <CR>
* M

MODIFY USER-DEFINED PATTERN 15:
WORD 00 = 072307 * 123456!
> ↑Z

ENTER T,O,S, OR R
* T
FC=0

1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796

LC=632
FT=0
LT=2
SO=0
S1=23
S2=4
S3=20
PT=100000
CS=0
ST=0

USER-DEFINED PATTERN 15:

WORD 00 = 123456
WORD 01 = 123456
WORD 02 = 123456
WORD 03 = 123456
WORD 04 = 123456
WORD 05 = 123456
WORD 06 = 123456
WORD 07 = 123456
WORD 10 = 123456
WORD 11 = 123456
WORD 12 = 123456
WORD 13 = 123456
WORD 14+Z
= 123456

ENTER T,O,S, OR R
* R

ENTER NO. OF PASSES (1-77777) :
* 1

TESTING DRIVE 0
DRIVE SER. NO. 8
CART. SER. NO. 334

OFFSET-TO-FAILURE			MEASUREMENTS:	
TRACK	CYLN	SECT	+OFST (UIN)	-OFST (UIN)
0	0	4	NONE	NONE
00	0	20	NONE	NONE
000	631	4	NONE	NONE
0000	631	20	NONE	NONE
00000	0	4	NONE	NONE
000000	0	20	NONE	NONE
0000000	631	4	NONE	NONE
00000000	631	20	NONE	NONE
000000000	0	4	NONE	NONE
0000000000	0	20	NONE	NONE
00000000000	631	4	NONE	NONE
000000000000	631	20	NONE	NONE

K03

CZR6NDD RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 37

SEQ 0036

1797
1798
1799
1800
1801
1802
1803

END PASS # 1
TO TEST ALL DRIVES TYPE "A" <CR>, ELSE <CR>
*

APPENDIX C

SAMPLE MANUAL MODE HEAD ALIGNMENT AID RUN

THE FOLLOWING PRINTOUT WAS THE RESULT OF RUNNING THE HEAD ALIGNMENT AID, PROVIDED IN SUBSYSTEM VERIFICATION PART 2 (ADDRESS 224 START). MANUAL MODE WAS REQUESTED, AND THE OPERATOR SELECTED DRIVE 0 FOR ALIGNMENT. IN THIS CASE, THE OPERATOR SELECTED HEADS 1, 0, AND 2, IN THAT ORDER, AND THEN REQUESTED RANDOM SEEK EXERCISES TO BE RUN ON THE DRIVE (AFTER REMOVAL OF THE HEAD ALIGNMENT TOOL). THE EXERCISES WOULD HAVE NORMALLY RUN FOR 5 MINUTES BUT THEY WERE PREMATURELY TERMINATED BY THE OPERATOR, BY TYPING (↑Z), IN THIS PARTICULAR RUN. FINALLY, VERIFY MODE WAS REQUESTED, AND HEAD 2 WAS SELECTED BY THE OPERATOR.

CZR6NDD - RK611/RK06-RK07 SUBSYSTEM VERIFICATION : PART 2

*** RK06-07 HEAD ALIGNMENT AID ***
FOR HELP TYPE H, ELSE <CR>

MANUAL OR AUTO MODE (M OR A)?
M

* MANUAL SELECT MODE *

ENTER DRIVE NO. (0-7):

0
DRIVE SER. NO. 8

ALIGN, VERIFY, OR EXERCISE (A, V, OR E)?
A

* MANUAL SELECT ALIGNMENT *

ENTER HEAD NO. (0-2):

1
TYPE <R> WHEN READY:

R
HEADS POSITIONED AT CYLINDER 365 (OCT)
HEAD 1 SELECTED

ENTER HEAD NO. (0-2):

1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859

1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902

0
TYPE <R> WHEN READY:
R
HEADS POSITIONED AT CYLINDER 365 (OCT)
HEAD 0 SELECTED

ENTER HEAD NO. (0-2):
2
TYPE <R> WHEN READY:
R
HEADS POSITIONED AT CYLINDER 365 (OCT)
HEAD 2 SELECTED

ENTER HEAD NO. (0-2):
↑Z

ALIGN, VERIFY, OR EXERCISE (A, V, OR E) ?
E
TYPE <R> WHEN READY:
R

RANDOM SEEK EXERCISES IN PROGRESS ON DRIVE 0
↑Z

ALIGN, VERIFY, OR EXERCISE (A, V, OR E) ?
V

* MANUAL SELECT VERIFY *

ENTER HEAD NO. (0-2) :
2
HEADS POSITIONED AT CYLINDER 365 (OCT)
HEAD 2 SELECTED

ENTER HEAD NO. (0-2) :
↑Z

ALIGN, VERIFY, OR EXERCISE (A, V, OR E) ?

1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958

APPENDIX D

SAMPLE AUTO MODE HEAD ALIGNMENT AID RUN

THE FOLLOWING PRINTOUT WAS THE RESULT OF RUNNING THE HEAD ALIGNMENT AID PROVIDED IN SUBSYSTEM VERIFICATION PART 2 (ADDRESS 224 START). AUTO MODE WAS REQUESTED, AND THE OPERATOR SELECTED DRIVE 0 FOR ALIGNMENT. IN THIS CASE, HEADS 0,1,2, AND 0 (AGAIN) WERE SELECTED FOR ALIGNMENT (IN AUTO MODE, THE HEADS ARE ALWAYS SELECTED IN THE ORDER 0,1,2,0,1,2, ETC.). BETWEEN HEAD SELECTIONS, THE HEADS WERE UNLOADED TO ALLOW REMOVAL OR INSTALLATION OF THE HEAD ALIGNMENT TOOL. NOTE THAT ALL DRIVE AND HEAD SELECTION (IN AUTO MODE) IS DONE BY THE OPERATOR, AT THE DRIVES, BY OPERATION OF PORT SELECT SWITCHES. AFTER ALIGNING HEADS, THE OPERATOR REQUESTED RANDOM SEEK EXERCISES TO BE RUN (ON ALL DRIVES, IN THIS CASE DRIVE 0). SHORT EXERCISES WERE REQUESTED, WHICH RUN FOR 1 MINUTE PER DRIVE. FINALLY, AUTO SELECT VERIFY WAS REQUESTED, AND HEADS 0,1, AND 2 WERE SELECTED SEQUENTIALLY.

CZR6NDO - RK611/RK06-RK07 SUBSYSTEM VERIFICATION : PART 2

*** RK06-07 HEAD ALIGNMENT AID ***
FOR HELP TYPE H, ELSE <CR>

MANUAL OR AUTO MODE (M OR A)?
A

* AUTO SELECT MODE *
ALIGN, VERIFY, OR EXERCISE (A, V, OR E) ?
A

* AUTO SELECT ALIGNMENT *
DRIVE 0 SELECTED
HEADS POSITIONED AT CYLINDER 365 (OCT)
HEAD 0 SELECTED
HEADS POSITIONED AT CYLINDER 365 (OCT)
HEAD 1 SELECTED
HEADS POSITIONED AT CYLINDER 365 (OCT)
HEAD 2 SELECTED

1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999

HEADS POSITIONED AT CYLINDER 365 (OCT)
HEAD 0 SELECTED
↑Z

* AUTO SELECT MODE *

ALIGN, VERIFY, OR EXERCISE (A, V, OR E) ?
E

* AUTO SELECT EXERCISES *

SHORT OR LONG (S OR L) ?
S
EXERCISING DRIVE 0

* AUTO SELECT MODE *

ALIGN, VERIFY, OR EXERCISE (A, V, OR E)?
V

* AUTO SELECT VERIFY *

DRIVE 0 SELECTED

HEADS POSITIONED AT CYLINDER 365 (OCT)
HEAD 0 SELECTED
HEADS POSITIONED AT CYLINDER 365 (OCT)
HEAD 1 SELECTED
HEADS POSITIONED AT CYLINDER 365 (OCT)
HEAD 2 SELECTED
↑Z

ALIGN, VERIFY, OR EXERCISE (A, V, OR E) ?
a

2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055

000001

167000

000001

001100

```

PART=1
;*** IF "PART" IS DEFINED = 0, PART 1 WILL BE ASSEMBLED. ***
;*** IF "PART" IS DEFINED NOT = 0, PART 2 WILL BE ASSEMBLED. ***
;*** REV 006 ***
      .NLIST MC,MD,CND
      .LIST ME
      ENABL ABS,AMA
      $SWR= 167000
;*****
.SBTTL STARTING ADDRESSES
;
;      200      DEFAULT PARAMETERS FOR TESTS 1-6
;      204      SELECT PARAMETERS FOR TESTS 1-6
;      224      HEAD ALIGNMENT AID
;*****
$TN=1
.TITLE CZR6NDO RK611/06 SS VERIF 2
;*COPYRIGHT (C) 1976,1977
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;
;*PROGRAM BY DAVE HOFFMAN
;
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
.SBTTL OPERATIONAL SWITCH SETTINGS
;
;      SWITCH      USE
;      -----
;      15          HALT ON ERROR
;      14          LOOP ON TEST
;      13          INHIBIT ERROR TYPEOUTS
;      12          REPORT DESCRIPTION ONLY, ON ERRORS
;      11          INHIBIT ITERATIONS
;      10          BELL ON ERROR
;      9           LOOP ON ERROR
;      8           APPLY RANDOM STALL BETWEEN OPERATIONS
;      6           REPORT 1 ERROR PER TRANSFER IN TESTS 2-4
;      1           INHIBIT WRITES IN TEST 1
;      0           REPORT ALL SOFTWARE COMPARE ERRORS IN TESTS 2-4
.SBTTL CONTROL SWITCH SETTINGS (PARAMETER CS)
;
;      SWITCH      USE
;      -----
;      05          DROP DRIVE IF 20(DEC) ERRORS EXCEEDED
;      04          TYPE BAD SECTOR FILES (BSF'S) ON FIRST PASS
;      01          INHIBIT OFFSET REPORTS IN TEST 1
.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100

```

```

2056 .EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
2057 .EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL
2058
2059 ;*MISCELLANEOUS DEFINITIONS
2060 000011 HT= 11 ;;CODE FOR HORIZONTAL TAB
2061 000012 LF= 12 ;;CODE FOR LINE FEED
2062 000015 CR= 15 ;;CODE FOR CARRIAGE RETURN
2063 000200 CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
2064 177776 PS= 177776 ;;PROCESSOR STATUS WORD
2065 .EQUIV PS,PSW
2066 177774 STKLM= 177774 ;;STACK LIMIT REGISTER
2067 177772 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
2068 177570 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
2069 177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
2070
2071 ;*GENERAL PURPOSE REGISTER DEFINITIONS
2072 000000 R0= %0 ;;GENERAL REGISTER
2073 000001 R1= %1 ;;GENERAL REGISTER
2074 000002 R2= %2 ;;GENERAL REGISTER
2075 000003 R3= %3 ;;GENERAL REGISTER
2076 000004 R4= %4 ;;GENERAL REGISTER
2077 000005 R5= %5 ;;GENERAL REGISTER
2078 000006 R6= %6 ;;GENERAL REGISTER
2079 000007 R7= %7 ;;GENERAL REGISTER
2080 000006 SP= %6 ;;STACK POINTER
2081 000007 PC= %7 ;;PROGRAM COUNTER
2082
2083 ;*PRIORITY LEVEL DEFINITIONS
2084 000000 PR0= 0 ;;PRIORITY LEVEL 0
2085 000040 PR1= 40 ;;PRIORITY LEVEL 1
2086 000100 PR2= 100 ;;PRIORITY LEVEL 2
2087 000140 PR3= 140 ;;PRIORITY LEVEL 3
2088 000200 PR4= 200 ;;PRIORITY LEVEL 4
2089 000240 PR5= 240 ;;PRIORITY LEVEL 5
2090 000300 PR6= 300 ;;PRIORITY LEVEL 6
2091 000340 PR7= 340 ;;PRIORITY LEVEL 7
2092
2093 ;*"SWITCH REGISTER" SWITCH DEFINITIONS
2094 100000 SW15= 100000
2095 040000 SW14= 40000
2096 020000 SW13= 20000
2097 010000 SW12= 10000
2098 004000 SW11= 4000
2099 002000 SW10= 2000
2100 001000 SW09= 1000
2101 000400 SW08= 400
2102 000200 SW07= 200
2103 000100 SW06= 100
2104 000040 SW05= 40
2105 000020 SW04= 20
2106 000010 SW03= 10
2107 000004 SW02= 4
2108 000002 SW01= 2
2109 000001 SW00= 1
2110 .EQUIV SW09,SW9
2111 .EQUIV SW08,SW8

```

2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167

100000
040000
020000
010000
004000
002000
001000
000400
000200
000100
000040
000020
000010
000004
000002
000001

.EQUIV SW07,SW7
.EQUIV SW06,SW6
.EQUIV SW05,SW5
.EQUIV SW04,SW4
.EQUIV SW03,SW3
.EQUIV SW02,SW2
.EQUIV SW01,SW1
.EQUIV SW00,SW0

.*DATA BIT DEFINITIONS (BIT00 TO BIT15)

BIT15= 100000
BIT14= 40000
BIT13= 20000
BIT12= 10000
BIT11= 4000
BIT10= 2000
BIT09= 1000
BIT08= 400
BIT07= 200
BIT06= 100
BIT05= 40
BIT04= 20
BIT03= 10
BIT02= 4
BIT01= 2
BIT00= 1

.EQUIV BIT09,BIT9
.EQUIV BIT08,BIT8
.EQUIV BIT07,BIT7
.EQUIV BIT06,BIT6
.EQUIV BIT05,BIT5
.EQUIV BIT04,BIT4
.EQUIV BIT03,BIT3
.EQUIV BIT02,BIT2
.EQUIV BIT01,BIT1
.EQUIV BIT00,BIT0

.*BASIC "CPU" TRAP VECTOR ADDRESSES

ERRVEC= 4 ; TIME OUT AND OTHER ERRORS
RESVEC= 10 ; RESERVED AND ILLEGAL INSTRUCTIONS
TBITVEC= 14 ; "T" BIT
TRTVEC= 14 ; TRACE TRAP
BPTVEC= 14 ; BREAKPOINT TRAP (BPT)
IOTVEC= 20 ; INPUT/OUTPUT TRAP (IOT) **SCOPE**
PWRVEC= 24 ; POWER FAIL
EMTVEC= 30 ; EMULATOR TRAP (EMT) **ERROR**
TRAPVEC= 34 ; "TRAP" TRAP
TKVEC= 60 ; TTY KEYBOARD VECTOR
TPVEC= 64 ; TTY PRINTER VECTOR
PIRQVEC= 240 ; PROGRAM INTERRUPT REQUEST VECTOR

.SBTTL MEMORY MANAGEMENT DEFINITIONS

.*KT11 VECTOR ADDRESS

MMVEC= 250

000250

```

2168 ;*KT11 STATUS REGISTER ADDRESSES
2169
2170 177572 SR0= 177572
2171 177574 SR1= 177574
2172 177576 SR2= 177576
2173 172516 SR3= 172516
2174
2175 ;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
2176
2177 172300 KIPDR0= 172300
2178 172302 KIPDR1= 172302
2179 172304 KIPDR2= 172304
2180 172306 KIPDR3= 172306
2181 172310 KIPDR4= 172310
2182 172312 KIPDR5= 172312
2183 172314 KIPDR6= 172314
2184 172316 KIPDR7= 172316
2185
2186 ;*KERNEL "I" PAGE ADDRESS REGISTERS
2187
2188 172340 KIPAR0= 172340
2189 172342 KIPAR1= 172342
2190 172344 KIPAR2= 172344
2191 172346 KIPAR3= 172346
2192 172350 KIPAR4= 172350
2193 172352 KIPAR5= 172352
2194 172354 KIPAR6= 172354
2195 172356 KIPAR7= 172356
2196
2197 170200 MAPL00=170200
2198 170202 MAPH00=170202
2199 172100 MEMCSR=172100 ; MEMORY CSR REG START ADRS
2200 177740 LOERAD=177740 ; 11/70 MEM LO ERROR ADRS REG
2201 177742 HIERAD=177742 ; 11/70 MEM HI ERROR ADRS REG
2202 177744 MEMSYS=177744 ; 11/70 MEM SYSTEM REG
2203
2204 .SBTTL TRAP CATCHER
2205
2206 .=0
2207 ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
2208 ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
2209 ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
2210 000174 000174 .=174
2211 000176 000000 DISPREG: .WORD 0 ; SOFTWARE DISPLAY REGISTER
2212 000000 SWREG: .WORD 0 ; SOFTWARE SWITCH REGISTER
2213 000200 000137 013342 .SBTTL STARTING ADDRESS(ES)
2214 000170 000170 JMP @#DFSTRT ; JUMP TO STARTING ADDRESS OF PROGRAM
2215 000170 000000 KILLDR: .WORD 0 ; IF NOT = 0, IT IS OK TO OVERLAY LOADER
2216 000204 000204 .=204
2217 000204 000137 013376 JMP @#PSTART
2218 000224 000224 .=224
2219 000224 000137 024134 JMP @#ASTART
2220 000230 000700 ..LOW: .WORD 700
2221 000232 001100 ..HIGH: .WORD 1100
2222 .SBTTL ACT11 HOOKS
2223

```

```

2224      ;*****
2225      ;HOOKS REQUIRED BY ACT11
2226      $SVPC=.          ;SAVE PC
2227      .=46
2228 000046 $ENDAD      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
2229      .=52
2230 000052 .WORD 140000 ;;2)SET LOC.52 TO 140000
2231      .=$SVPC      ;; RESTORE PC
2232      .=1000
2233      .SBTTL  APT PARAMETER BLOCK
2234
2235      ;*****
2236      ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
2237      ;*****
2238      .SX=.          ;SAVE CURRENT LOCATION
2239      .=24          ;SET POWER FAIL TO POINT TO START OF PROGRAM
2240 000024 200        ;FOR APT START UP
2241      .=44          ;POINT TO APT INDIRECT ADDRESS PNTR.
2242 000044 $APTHDR    ;POINT TO APT HEADER BLOCK
2243      .=$X          ;RESET LOCATION COUNTER
2244      ;*****
2245      ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
2246      ;INTERFACE SPEC.
2247
2248 001000 $APTHD:
2249 001000 $SHIBTS: .WORD 0          ;; TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
2250 001002 $SMBADR: .WORD $MAIL    ;; ADDRESS OF APT MAILBOX (BITS 0-15)
2251 001004 $TSTM: .WORD 1130      ;; RUN TIM OF LONGEST TEST
2252 001006 $PASTM: .WORD 3410     ;; RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
2253 001010 $UNITM: .WORD 3410     ;; ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
2254 001012 .WORD $ETEND-$MAIL/2  ;; LENGTH MAILBOX-ETABLE(WORDS)
2255      120210      ;RKVEC=210, RKPRI=5
2256      177440      ;RKBAS ADRS
2257      000377      ;SET DEVICES 0-7 IN MAP

```

2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313

001100
001100
001102
001103
001104
001106
001110
001112
001114
001115
001116
001120
001122
001124
001126
001130
001132
001134
001135
001136
001140
001142
001144
001146
001150
001152
001154
001155
001156
001157
001160
001162
001164
001166
001170
001172
001174
001176
001200
001202
001204
001206
001210
001212
001214
001216
001220
001222

.SBTTL COMMON TAGS

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.

SCMTAG: . =1100

.WORD 0
\$STNM: .BYTE 0
\$ERFLG: .BYTE 0
\$ICNT: .WORD 0
\$LPADR: .WORD 0
\$LPERR: .WORD 0
\$ERTTL: .WORD 0
\$ITEMB: .BYTE 0
\$ERMAX: .BYTE 1
\$ERRPC: .WORD 0
\$GDADR: .WORD 0
\$BDADR: .WORD 0
\$GDDAT: .WORD 0
\$BDDAT: .WORD 0
\$AUTOB: .BYTE 0
\$INTAG: .BYTE 0
\$SWR: .WORD DSWR
\$DISPLAY: .WORD DDISP
\$TKS: 177560
\$TKB: 177562
\$TPS: 177564
\$TPB: 177566
\$NULL: .BYTE 0
\$FILLS: .BYTE 2
\$FILLC: .BYTE 12
\$STPFLG: .BYTE 0
\$REGAD: .WORD 0
\$REG0: .WORD 0
\$REG1: .WORD 0
\$REG2: .WORD 0
\$REG3: .WORD 0
\$REG4: .WORD 0
\$REG5: .WORD 0
\$REG6: .WORD 0
\$REG7: .WORD 0
\$REG10: .WORD 0
\$REG11: .WORD 0
\$REG12: .WORD 0
\$REG13: .WORD 0
\$REG14: .WORD 0
\$REG15: .WORD 0
\$REG16: .WORD 0
\$REG17: .WORD 0
\$REG20: .WORD 0

;; START OF COMMON TAGS

;; CONTAINS THE TEST NUMBER
;; CONTAINS ERROR FLAG
;; CONTAINS SUBTEST ITERATION COUNT
;; CONTAINS SCOPE LOOP ADDRESS
;; CONTAINS SCOPE RETURN FOR ERRORS
;; CONTAINS TOTAL ERRORS DETECTED
;; CONTAINS ITEM CONTROL BYTE
;; CONTAINS MAX. ERRORS PER TEST
;; CONTAINS PC OF LAST ERROR INSTRUCTION
;; CONTAINS ADDRESS OF 'GOOD' DATA
;; CONTAINS ADDRESS OF 'BAD' DATA
;; CONTAINS 'GOOD' DATA
;; CONTAINS 'BAD' DATA
;; RESERVED--NOT TO BE USED
;; AUTOMATIC MODE INDICATOR
;; INTERRUPT MODE INDICATOR
;; ADDRESS OF SWITCH REGISTER
;; ADDRESS OF DISPLAY REGISTER
;; TTY KBD STATUS
;; TTY KBD BUFFER
;; TTY PRINTER STATUS REG. ADDRESS
;; TTY PRINTER BUFFER REG. ADDRESS
;; CONTAINS NULL CHARACTER FOR FILLS
;; CONTAINS # OF FILLER CHARACTERS REQUIRED
;; INSERT FILL CHARS. AFTER A "LINE FEED"
;; "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
;; CONTAINS THE ADDRESS FROM
;; WHICH (\$REG0) WAS OBTAINED
;; CONTAINS ((\$REGAD)+0)
;; CONTAINS ((\$REGAD)+2)
;; CONTAINS ((\$REGAD)+4)
;; CONTAINS ((\$REGAD)+6)
;; CONTAINS ((\$REGAD)+10)
;; CONTAINS ((\$REGAD)+12)
;; CONTAINS ((\$REGAD)+14)
;; CONTAINS ((\$REGAD)+16)
;; CONTAINS ((\$REGAD)+20)
;; CONTAINS ((\$REGAD)+22)
;; CONTAINS ((\$REGAD)+24)
;; CONTAINS ((\$REGAD)+26)
;; CONTAINS ((\$REGAD)+30)
;; CONTAINS ((\$REGAD)+32)
;; CONTAINS ((\$REGAD)+34)
;; CONTAINS ((\$REGAD)+36)
;; CONTAINS ((\$REGAD)+40)


```

2314 001224 000000 $REG21: .WORD 0 :: CONTAINS (($REGAD)+42)
2315 001226 000000 $REG22: .WORD 0 :: CONTAINS (($REGAD)+44)
2316 001230 000000 $REG23: .WORD 0 :: CONTAINS (($REGAD)+46)
2317 001232 000000 $REG24: .WORD 0 :: CONTAINS (($REGAD)+50)
2318 001234 000000 $REG25: .WORD 0 :: CONTAINS (($REGAD)+52)
2319 001236 000000 $REG26: .WORD 0 :: CONTAINS (($REGAD)+54)
2320 001240 000000 $REG27: .WORD 0 :: CONTAINS (($REGAD)+56)
2321 001242 000000 $REG28: .WORD 0 :: CONTAINS (($REGAD)+60)
2322 001244 000000 $REG31: .WORD 0 :: CONTAINS (($REGAD)+62)
2323 001246 000000 $REG32: .WORD 0 :: CONTAINS (($REGAD)+64)
2324 001250 000000 $REG33: .WORD 0 :: CONTAINS (($REGAD)+66)
2325 001252 000000 $REG34: .WORD 0 :: CONTAINS (($REGAD)+70)
2326 001254 000000 $REG35: .WORD 0 :: CONTAINS (($REGAD)+72)
2327 001256 000000 $REG36: .WORD 0 :: CONTAINS (($REGAD)+74)
2328 001260 000000 $REG37: .WORD 0 :: CONTAINS (($REGAD)+76)
2329 001262 000000 $TMP0: .WORD 0 :: USER DEFINED
2330 001264 000000 $TMP1: .WORD 0 :: USER DEFINED
2331 001266 000000 $TMP2: .WORD 0 :: USER DEFINED
2332 001270 000000 $TMP3: .WORD 0 :: USER DEFINED
2333 001272 000000 $TMP4: .WORD 0 :: USER DEFINED
2334 001274 000000 $TMP5: .WORD 0 :: USER DEFINED
2335 001276 000000 $TMP6: .WORD 0 :: USER DEFINED
2336 001300 000000 $TMP7: .WORD 0 :: USER DEFINED
2337 001302 000000 $TMP10: .WORD 0 :: USER DEFINED
2338 001304 000000 $TIMES: 0 :: MAX. NUMBER OF ITERATIONS
2339 001306 000000 $ESCAPE: 0 :: ESCAPE ON ERROR ADDRESS
2340 001310 177607 000377 $BELL: .ASCIZ <207><377><377> :: CODE FOR BELL
2341 001314 077 $QUES: .ASCII /?/ :: QUESTION MARK
2342 001315 015 $CRLF: .ASCII <15> :: CARRIAGE RETURN
2343 001316 000012 $LF: .ASCIZ <12> :: LINE FEED
2344 :: *****
2345 .SBTTL APT MAILBOX-ETABLE
2346 :: *****
2347
2348 .EVEN
2349 $MAIL:
2350 001320 000000 $MSGTY: .WORD AMSGTY :: APT MAILBOX
2351 001322 000000 $FATAL: .WORD AFATAL :: MESSAGE TYPE CODE
2352 001324 000000 $TESTN: .WORD ATESTN :: FATAL ERROR NUMBER
2353 001326 000000 $PASS: .WORD APASS :: TEST NUMBER
2354 001330 000000 $DEVCT: .WORD ADEVCT :: PASS COUNT
2355 001332 000000 $UNIT: .WORD AUNIT :: DEVICE COUNT
2356 001334 000000 $MSGAD: .WORD AMSGAD :: I/O UNIT NUMBER
2357 001336 000000 $MSGLG: .WORD AMSGLG :: MESSAGE ADDRESS
2358 001340 $ETABLE: :: MESSAGE LENGTH
2359 001340 000 $ENV: .BYTE AENV :: APT ENVIRONMENT TABLE
2360 001341 000 $ENVM: .BYTE AENVM :: ENVIRONMENT BYTE
2361 001342 000000 $SWREG: .WORD ASWREG :: ENVIRONMENT MODE BITS
2362 001344 000000 $USWR: .WORD AUSWR :: APT SWITCH REGISTER
2363 001346 000000 $CPUOP: .WORD ACPUOP :: USER SWITCHES
2364 :: CPU TYPE, OPTIONS
2365 :: BIT 15-11=CPU TYPE
2366 :: 11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
2367 :: 11/70=06, PDQ=07, Q=10
2368 :: BIT 10=REAL TIME CLOCK
2369 :: BIT 9=FLOATING POINT PROCESSOR
:: BIT 8=MEMORY MANAGEMENT

```

2370	001350	000	\$MAMS1: .BYTE	AMAMS1	::HIGH ADDRESS,M.S. BYTE
2371	001351	000	\$MTYP1: .BYTE	AMTYP1	::MEM. TYPE,BLK#1
2372			.*		MEM. TYPE BYTE -- (HIGH BYTE)
2373			.*		900 NSEC CORE=001
2374			.*		300 NSEC BIPOLAR=002
2375			.*		500 NSEC MOS=003
2376	001352	000000	\$MADR1: .WORD	AMADR1	::HIGH ADDRESS,BLK#1
2377			.*		MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE
2378	001354	000	\$MAMS2: .BYTE	AMAMS2	::HIGH ADDRESS,M.S. BYTE
2379	001355	000	\$MTYP2: .BYTE	AMTYP2	::MEM. TYPE,BLK#2
2380	001356	000000	\$MADR2: .WORD	AMADR2	::MEM.LAST ADDRESS,BLK#2
2381	001360	000	\$MAMS3: .BYTE	AMAMS3	::HIGH ADDRESS,M.S.BYTE
2382	001361	000	\$MTYP3: .BYTE	AMTYP3	::MEM. TYPE,BLK#3
2383	001362	000000	\$MADR3: .WORD	AMADR3	::MEM.LAST ADDRESS,BLK#3
2384	001364	000	\$MAMS4: .BYTE	AMAMS4	::HIGH ADDRESS,M.S.BYTE
2385	001365	000	\$MTYP4: .BYTE	AMTYP4	::MEM. TYPE,BLK#4
2386	001366	000000	\$MADR4: .WORD	AMADR4	::MEM.LAST ADDRESS,BLK#4
2387	001370	120210	\$VECT1: .WORD	AVECT1	::INTERRUPT VECTOR#1,BUS PRIORITY#1
2388	001372	000000	\$VECT2: .WORD	AVECT2	::INTERRUPT VECTOR#2BUS PRIORITY#2
2389	001374	177440	\$BASE: .WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
2390	001376	000377	\$DEV: .WORD	ADEV	::DEVICE MAP
2391	001400		\$ETEND:		
2392			.MEXIT		

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;:POINTS TO THE ERROR MESSAGE
;* DH ;:POINTS TO THE DATA HEADER
;* DT ;:POINTS TO THE DATA
;* DF ;:POINTS TO THE DATA FORMAT

\$ERRTB:

Index	EM	DH	DT	DF	Description
2393					
2394					
2395					
2396					
2397					
2398					
2399					
2400					
2401					
2402					
2403					
2404					
2405					
2406					
2407	001400				
2408					
2409					
2410	001400	060375			:ERROR 1 ;UNIBUS PARITY ERROR
2411	001402	063072			EM1
2412	001404	064610			DH100
2413	001406	064724			DT100
2414					DF01
2415					
2416	001410	060414			:ERROR 2 ;NON-EXISTANT MEMORY
2417	001412	063072			EM2
2418	001414	064610			DH100
2419	001416	064724			DT100
2420					DF01
2421					
2422	001420	060432			:ERROR 3 ;NON-EXISTANT DRIVE
2423	001422	063072			EM3
2424	001424	064610			DH100
2425	001426	064724			DT100
2426					DF01
2427					
2428	001430	060450			:ERROR 4 ;UNIT FIELD ERROR
2429	001432	063072			EM4
2430	001434	064610			DH100
2431	001436	064724			DT100
2432					DF01
2433					
2434	001440	060467			:ERROR 5 ;SUBSYSTEM TIMEOUT
2435	001442	063072			EM5
2436	001444	064610			DH100
2437	001446	064754			DT100
2438					DF02
2439					
2440	001450	060506			:ERROR 6 ;D TO C PARITY ERROR
2441	001452	063072			EM6
2442	001454	064610			DH100
2443	001456	065010			DT100
2444					DF03
2445					
2446	001460	060525			:ERROR 7 ;DRIVE DETECTED PARITY ERROR
2447	001462	063072			EM7
2448	001464	064610			DH100
					DT100

2449	001466	065010	DF03	
2450				
2451			: ERROR 10	
2452	001470	060544	EM10	; AC LOW
2453	001472	063072	DH100	
2454	001474	064610	DT100	
2455	001476	064754	DF02	
2456				
2457			: ERROR 11	
2458	001500	060553	EM11	; SPEED LOSS
2459	001502	063072	DH100	
2460	001504	064610	DT100	
2461	001506	064754	DF02	
2462				
2463			: ERROR 12	
2464	001510	060566	EM12	; ILLEGAL FUNCTION
2465	001512	063072	DH100	
2466	001514	064610	DT100	
2467	001516	064754	DF02	
2468				
2469			: ERROR 13	
2470	001520	060600	EM13	; PROGRAMMING ERROR
2471	001522	063072	DH100	
2472	001524	064610	DT100	
2473	001526	064724	DF01	
2474				
2475			: ERROR 14	
2476	001530	060611	EM14	; NON-EXISTANT FUNCTION
2477	001532	063072	DH100	
2478	001534	064610	DT100	
2479	001536	064754	DF02	
2480				
2481			: ERROR 15	
2482	001540	060631	EM15	; DRIVE TYPE ERROR
2483	001542	063072	DH100	
2484	001544	064610	DT100	
2485	001546	064754	DF02	
2486				
2487			: ERROR 16	
2488	001550	060645	EM16	; FORMAT ERROR
2489	001552	063072	DH100	
2490	001554	064610	DT100	
2491	001556	064754	DF02	
2492				
2493			: ERROR 17	
2494	001560	060656	EM17	; WRITE LOCK ERROR
2495	001562	063072	DH100	
2496	001564	064610	DT100	
2497	001566	064754	DF02	
2498				
2499			: ERROR 20	
2500	001570	060673	EM20	; DRIVE UNSAFE
2501	001572	063072	DH100	
2502	001574	064610	DT100	
2503	001576	064754	DF02	
2504				

2505			.ERROR 21	
2506	001600	060706	EM21	;SEEK INCOMPLETE
2507	001602	063072	DH100	
2508	001604	064610	DT100	
2509	001606	064754	DF02	
2510			.ERROR 22	
2511			EM22	;CYLINDER OVERFLOW
2512	001610	060722	DH100	
2513	001612	063072	DT100	
2514	001614	064610	DF02	
2515	001616	064754		
2516			.ERROR 23	
2517			EM23	;ILLEGAL CYLINDER
2518	001620	060735	DH100	
2519	001622	063072	DT100	
2520	001624	064610	DF02	
2521	001626	064754		
2522			.ERROR 24	
2523			EM24	;DRIVE OFF TRACK
2524	001630	060752	DH100	
2525	001632	063072	DT100	
2526	001634	064610	DF02	
2527	001636	064754		
2528			.ERROR 25	
2529			EM25	;DRIVE TIMING ERROR
2530	001640	060770	DH100	
2531	001642	063072	DT100	
2532	001644	064610	DF02	
2533	001646	064754		
2534			.ERROR 26	
2535			EM26	;DATA LATE
2536	001650	061007	DH100	
2537	001652	063072	DT100	
2538	001654	064610	DF02	
2539	001656	064754		
2540			.ERROR 27	
2541			EM27	;CONTROLLER TIMEOUT
2542	001660	061021	DH100	
2543	001662	063072	DT100	
2544	001664	064610	DF02	
2545	001666	064754		
2546			.ERROR 30	
2547			EM30	;OPERATION INCOMPLETE
2548	001670	061037	DH100	
2549	001672	063072	DT100	
2550	001674	064610	DF05	
2551	001676	065064		
2552			.ERROR 31	
2553			EM31	;HEADER VRC ERROR
2554	001700	061060	DH100	
2555	001702	063072	DT100	
2556	001704	064610	DF05	
2557	001706	065064		
2558			.ERROR 32	
2559			EM32	;DATA CHECK ERROR
2560	001710	061077		

2561	001712	063072	DH100	
2562	001714	064610	DT100	
2563	001716	065120	DF07	
2564				
2565			: ERROR 33	
2566	001720	061116	EM33	;WRITE CHECK ERROR
2567	001722	063072	DH100	
2568	001724	064610	DT100	
2569	001726	065154	DF10	
2570				
2571			: ERROR 34	
2572	001730	061132	EM34	;DATA MISCOMPARE(S)
2573	001732	063072	DH100	
2574	001734	064610	DT100	
2575	001736	065050	DF04	
2576				
2577			: ERROR 35	
2578	001740	061152	EM35	;NO DRIVE RESPONSE-UFE & NXD
2579	001742	063072	DH100	
2580	001744	064610	DT100	
2581	001746	064724	DF01	
2582				
2583			: ERROR 36	
2584	001750	061204	EM36	;DRIVE ERROR WILL NOT CLEAR
2585	001752	000000	0	
2586	001754	000000	0	
2587	001756	000000	0	
2588				
2589			: ERROR 37	
2590	001760	061233	EM37	;DRIVE STATUS CHANGE WILL NOT CLEAR
2591	001762	000000	0	
2592	001764	000000	0	
2593	001766	000000	0	
2594				
2595			: ERROR 40	
2596	001770	061274	EM40	;ATTENTION BUT NO STATUS CHANGE OR FAULT
2597	001772	063072	DH100	
2598	001774	064610	DT100	
2599	001776	064754	DF02	
2600				
2601			: ERROR 41	
2602	002000	061340	EM41	;ATTENTION BUT DRIVE NOT AVAILABLE
2603	002002	063072	DH100	
2604	002004	064610	DT100	
2605	002006	064754	DF02	
2606				
2607			: ERROR 42	
2608	002010	061370	EM42	;ATTENTION WHEN NOT EXPECTED
2609	002012	063072	DH100	
2610	002014	064610	DT100	
2611	002016	064754	DF02	
2612				
2613			: ERROR 43	
2614	002020	061420	EM43	;ERROR WHILE GATHERING DRIVE STATUS
2615	002022	063072	DH100	
2616	002024	064610	DT100	

2617	002026	065220	DF12	
2618				
2619			:ERROR 44	
2620	002030	061631	EM63	;CLEAR CONTROLLER DID NOT CLEAR ERROR
2621	002032	063072	DH100	
2622	002034	064610	DT100	
2623	002036	065220	DF12	
2624				
2625			:ERROR 45	
2626	002040	061667	EM64	;NO ATTENTION IN ATTENTION SUMMARY REG
2627	002042	063072	DH100	
2628	002044	064610	DT100	
2629	002046	065220	DF12	
2630				
2631			:ERROR 46	
2632	002050	061715	EM65	;UNSOLICITED ATTENTION
2633	002052	063072	DH100	
2634	002054	064610	DT100	
2635	002056	065220	DF12	
2636				
2637			:ERROR 47	
2638	002060	061737	EM66	;UNEXPECTED DATA TYPE ERROR
2639	002062	063072	DH100	
2640	002064	064610	DT100	
2641	002066	065220	DF12	
2642				
2643			:ERROR 50	
2644	002070	061763	EM67	;ATTENTION DID NOT RESET WITH CLEAR
2645	002072	063072	DH100	
2646	002074	064610	DT100	
2647	002076	065220	DF12	
2648				
2649			:ERROR 51	
2650	002100	062022	EM70	;SUBSYSTEM CLEAR DID NOT CLEAR DRIVE ATTENTION
2651	002102	063072	DH100	
2652	002104	064610	DT100	
2653	002106	065220	DF12	
2654				
2655			:ERROR 52	
2656	002110	061451	EM52	;MULTIPLE DRIVE SELECT
2657	002112	063072	DH100	
2658	002114	064610	DT100	
2659	002116	065220	DF12	
2660				
2661			:ERROR 53	
2662	002120	061466	EM53	;ABREVIATED HCE ERROR
2663	002122	063072	DH100	
2664	002124	064610	DT100	
2665	002126	065250	DF13	
2666				
2667			:ERROR 54	
2668	002130	061037	EM30	;OPERATION INCOMPLETE ERROR
2669	002132	063072	DH100	
2670	002134	064610	DT100	
2671	002136	065300	DF14	
2672				

2673			:ERROR 55	
2674	002140	061060	EM31	;ABREVIATED HVRC ERROR
2675	002142	063072	DH100	
2676	002144	064610	DT100	
2677	002146	065250	DF13	
2678			:ERROR 56	
2679			EM56	;2 TIMEOUT ERROR
2680	002150	061511	DH100	
2681	002152	063072	DT100	
2682	002154	064610	DF15	
2683	002156	065330		
2684			:ERROR 57	;2ND LEVEL IN SUBSYSTEM TIMEOUT
2685			EM56	
2686	002160	061511	DH100	
2687	002162	063072	DT100	
2688	002164	064610	DF16	
2689	002166	065374		
2690			:ERROR 60	
2691			EM60	;ERROR IN RECAL FOR RECOVERY
2692	002170	061530	0	
2693	002172	000000	0	
2694	002174	000000	0	
2695	002176	000000		
2696			:ERROR 61	
2697			EM61	;ABORT MESSAGE
2698	002200	061562	0	
2699	002202	000000	0	
2700	002204	000000	0	
2701	002206	000000		
2702			:ERROR 62	
2703			EM62	;CYLINDER MISCOMPARE
2704	002210	061615	DH100	
2705	002212	063072	DT100	
2706	002214	064610	DF17	
2707	002216	065440		
2708			:ERROR 63	;DATA ERROR WORDS
2709			0	
2710	002220	000000	0	
2711	002222	000000	DT602	
2712	002224	064702	DF25	
2713	002226	065550		
2714			:ERROR 64	
2715			EM63	;CLEAR CONTROLLER DID NOT CLEAR ERROR
2716	002230	061631	DH100	
2717	002232	063072	DT100	
2718	002234	064610	DF02	
2719	002236	064754		
2720			:ERROR 65	
2721			EM64	;NO ATTENTION IN ATTENTION SUMMARY REG
2722	002240	061667	DH100	
2723	002242	063072	DT100	
2724	002244	064610	DF02	
2725	002246	064754		
2726			:ERROR 66	
2727			EM65	;UNSOLICITED ATTENTION
2728	002250	061715		

2729	002252	063072	DH100	
2730	002254	064610	DT100	
2731	002256	064754	DF02	
2732				
2733			: ERROR 67	
2734	002260	061737	EM66	; UNEXPECTED DATA TYPE ERROR
2735	002262	063072	DH100	
2736	002264	064610	DT100	
2737	002266	064754	DF02	
2738				
2739			: ERROR 70	
2740	002270	061763	EM67	; ATTENTION DID NOT RESET WITH CLEAR
2741	002272	063072	DH100	
2742	002274	064610	DT100	
2743	002276	064754	DF02	
2744				
2745			: ERROR 71	
2746	002300	062022	EM70	; SUBSYSTEM CLEAR DID NOT CLEAR ATT
2747	002302	063072	DH100	
2748	002304	064610	DT100	
2749	002306	064754	DF02	
2750				
2751			: ERROR 72	
2752	002310	062067	EM71	; DATA LATE WHEN UNLOADING HEADER
2753	002312	063072	DH100	
2754	002314	064610	DT100	
2755	002316	064754	DF02	
2756				
2757			: ERROR 73	
2758	002320	062127	EM72	; CONTROLLER ERROR DURING DRIVER SERVICE
2759	002322	063072	DH100	
2760	002324	064610	DT100	
2761	002326	064754	DF02	
2762				
2763			: ERROR 74	
2764	002330	062162	EM73	; DRIVE DETECTED PARITY ERROR
2765	002332	063072	DH100	
2766	002334	064610	DT100	
2767	002336	064754	DF02	
2768				
2769			: ERROR 75	
2770	002340	062202	EM74	; UNDEFINED ERROR
2771	002342	063072	DH100	
2772	002344	064610	DT100	
2773	002346	064754	DF02	
2774				
2775			: ERROR 76	
2776	002350	062214	EM75	; MARKING SECTOR BAD MESSAGE
2777	002352	000000	0	
2778	002354	000000	0	
2779	002356	000000	0	
2780				
2781			: ERROR 77	
2782	002360	062244	EM76	; BAD DATA VERIFICATION WITH READ
2783	002362	064010	DH605	
2784	002364	064674	DT601	

2785	002366	065474	DF21	
2786				
2787			: ERROR 100	
2788	002370	062326	EM77	;RETRY SUCCESSFUL MESSAGE
2789	002372	000000	0	
2790	002374	064674	DT601	
2791	002376	065534	DF23	
2792				
2793			: ERROR 101	
2794	002400	062326	EM77	;ANOTHER RETRY SUCCESSFUL MESSAGE
2795	002402	000000	0	
2796	002404	064674	DT601	
2797	002406	065534	DF23	
2798				
2799			: ERROR 102	
2800	002410	062347	EM100	;RETRY UNSUCCESSFUL MESSAGE
2801	002412	000000	0	
2802	002414	064674	DT601	
2803	002416	065534	DF23	
2804				
2805			: ERROR 103	
2806	002420	062372	EM101	;NO VALID HEADERS IN TRACK JUST READ
2807	002422	063772	DH6042	
2808	002424	064674	DT601	
2809	002426	065544	DF24	
2810				
2811			: ERROR 104	
2812	002430	062450	EM102	;BSE ERROR ON SECTOR NOT LISTED AS BAD
2813	002432	063072	DH100	
2814	002434	064610	DT100	
2815	002436	064754	DF02	
2816				
2817			: ERROR 105	
2818	002440	062514	EM103	;TIMED-OUT ON READ HEADER
2819	002442	063072	DH100	
2820	002444	064610	DT100	
2821	002446	065010	DF03	
2822				
2823			: ERROR 106	
2824	002450	062542	EM104	;TIMED-OUT ON SEEK
2825	002452	063072	DH100	
2826	002454	064610	DT100	
2827	002456	065010	DF03	
2828				
2829			: ERROR 107	
2830	002460	062564	EM105	;DRIVE SIEZED BY OTHER PORT
2831	002462	063072	DH100	
2832	002464	064610	DT100	
2833	002466	064754	DF02	
2834				
2835			: ERROR 110	
2836	002470	062615	EM106	; "DATA MISCMPR WHILE BAI SET"
2837	002472	063072	DH100	
2838	002474	064610	DT100	
2839	002476	065564	DF27	
2840				

2841			.ERROR	111	
2842	002500	062650	EM107		; "NO NEM WHEN EXPECTED"
2843	002502	000000	0		
2844	002504	000000	0		
2845	002506	000000	0		
2846					
2847			.ERROR	112	
2848	002510	062713	EM110		; "INTRPT WHEN CNTRLR NOT READY"
2849	002512	063072	DH100		
2850	002514	064610	DT100		
2851	002516	064724	DF01		
2852					
2853			.ERROR	113	
2854	002520	062746	EM111		; "NO ATT'N ON SEEK"
2855	002522	063072	DH100		
2856	002524	064610	DT100		
2857	002526	064754	DF02		
2858					
2859			.ERROR	114	
2860	002530	062767	EM112		; DRIVE'S CYLINDER INCORRECT
2861	002532	064217	DH702		
2862	002534	064650	DT202		
2863	002536	065554	DF26		
2864					
2865			.ERROR	115	
2866	002540	000000	0		; TYPE ADRS OF DATA MISCOMPARE(S)
2867	002542	000000	0		
2868	002544	064674	DT601		
2869	002546	065200	DF11		
2870					
2871			.ERROR	116	
2872	002550	061132	EM34		; DATA MISCOMPARE (11/70)
2873	002552	063350	DH103		
2874	002554	064720	DT103		
2875	002556	065464	DF20		
2876					
2877			.ERROR	117	
2878	002560	000000	0		; PART OF DATA MISCOMPARE
2879	002562	000000	0		
2880	002564	064610	DT100		
2881	002566	065504	DF22		
2882					
2883			.ERROR	120	
2884	002570	063013	EM113		; ABORT- CAN'T READ BSF
2885	002572	063072	DH100		
2886	002574	064610	DT100		
2887	002576	064724	DF01		
2888					
2889			.ERROR	121	
2890	002600	063041	EM114		; KT11 FAILURE
2891	002602	063072	DH100		
2892	002604	064610	DT100		
2893	002606	065610	DF30		
2894					
2895			.ERROR	122	
2896	002610	063056	EM115		; MEM PARITY ERROR

G05

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78
ERROR POINTER TABLE

12:02 PAGE 59

SEQ 0058

2897 002612 063072
2898 002614 064610
2899 002616 065634
2900
2901 002620 060432
2902 002622 000000
2903 002624 000000
2904 002626 000000
2905
2906
2907
2908
2909
2910

DH100
DT100
DF31
:ERROR 123
EM3
0
0
0

;NED IN SIZING UNDER APT

I05

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 61
BIT ASSIGNMENTS IN THE RK611 REGISTERS

SEQ 0060

2965
2966
2967
2968
2969
2970
2971
2972
2973
2974
2975
2976
2977
2978
2979
2980
2981
2982
2983
2984
2985
2986
2987
2988
2989
2990
2991
2992
2993
2994
2995
2996
2997
2998
2999
3000
3001
3002
3003
3004
3005
3006
3007
3008
3009
3010
3011
3012
3013
3014
3015

RKDB (DATA BUFFER)							
15	14	13	12	11	10	9	8
DB15	DB14	DB13	DB12	DB11	DB10	DB9	DB8
READ/WRITE							
7	6	5	4	3	2	1	0
DB7	DB6	DB5	DB4	DB3	DB2	DB1	DB0
READ/WRITE							
RKASOF (ATTENTION SUMMARY AND OFFSET)							
15	14	13	12	11	10	9	8
ATN7	ATN6	ATN5	ATN4	ATN3	ATN2	ATN1	ATN0
READ ONLY							
7	6	5	4	3	2	1	0
UN	OF6	OF5	OF4	OF3	OF2	OF1	OF0
?	READ/WRITE						
RKWC (WORD COUNT)							
15	14	13	12	11	10	9	8
WC15	WC14	WC13	WC12	WC11	WC10	WC9	WC8
READ/WRITE							
7	6	5	4	3	2	1	0
WC7	WC6	WC5	WC4	WC3	WC2	WC1	WC0
READ/WRITE							
RKBA (BUS ADDRESS)							
15	14	13	12	11	10	9	8
BA15	BA14	BA13	BA12	BA11	BA10	BA9	BA8
READ/WRITE							
7	6	5	4	3	2	1	0
BA7	BA6	BA5	BA4	BA3	BA2	BA1	BA0
READ/WRITE							ALWYSO

J05

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 62
BIT ASSIGNMENTS IN THE RK611 REGISTERS

SEQ 0061

3016
3017
3018
3019
3020
3021
3022
3023
3024
3025
3026
3027
3028
3029
3030
3031
3032
3033
3034
3035
3036
3037
3038
3039
3040
3041
3042
3043
3044
3045
3046
3047
3048
3049
3050
3051
3052
3053
3054

RKER (ERROR REGISTER)															
15	14	13	12	11	10	9	8								
DCK	!	UNS	!	OPI	!	DTE	!	WLE	!	IDAE	!	COE	!	HVRC	!
READ ONLY															
7	6	5	4	3	2	1	0								
BSE	!	ECH	!	DTYPE	!	FMTE	!	DRPAR	!	ILF	!	SKI	!	ILC	!
READ ONLY															
RKDS (DRIVE STATUS)															
15	14	13	12	11	10	9	8								
SVAL	!	DSC	!	PIP	!	SPON	!	WRL	!	UN	!	UN	!	DTP	!
READ ONLY															
7	6	5	4	3	2	1	0								
DRDY	!	VV	!	DROT	!	SPLS	!	ACLO	!	OFFSET	!	UN	!	DRA	!
READ ONLY															
RKMRI (MAINTENANCE REG 1)															
15	14	13	12	11	10	9	8								
RD	!	WRT	!	ECCW	!	PCD	!	PCA	!	MEWD	!	MERD	!	MCLK	!
GATE	!	GATE	!	READ ONLY				READ/WRITE							
7	6	5	4	3	2	1	0								
MIND	!	MSP	!	DMD	!	PAT	!	MS3	!	MS2	!	MS1	!	MS0	!
READ/WRITE															

K05

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 63
BIT ASSIGNMENTS IN THE RK611 REGISTERS

SEQ 0062

3055
3056
3057
3058
3059
3060
3061
3062
3063
3064
3065
3066
3067
3068
3069
3070
3071
3072
3073
3074
3075
3076
3077
3078
3079
3080
3081
3082
3083
3084
3085
3086
3087
3088
3089
3090
3091
3092

```
;RKECC/PAT
 15 14 13 12 11 10 9 8
-----
UN ! UN ! UN ! UN ! UN ! EPA10! EPA9 ! EPA8 !
      READ ONLY
-----

 7 6 5 4 3 2 1 0
-----
EPA7 ! EPA6 ! EPA5 ! EPA4 ! EPA3 ! EPA2 ! EPA1 ! EPA0 !
      READ ONLY
-----

;RKECC/POS
 15 14 13 12 11 10 9 8
-----
UN ! UN ! UN ! EP012! EP011! EP010! EP09 ! EP08 !
      READ ONLY
-----

 7 6 5 4 3 2 1 0
-----
EP07 ! EP06 ! EP05 ! EP04 ! EP03 ! EP02 ! EP01 ! EP00 !
      READ ONLY
-----

;DRIVE STATUS INFORMATION

;LINE A MESSAGE DD
 15 14 13 12 11 10 9 8
-----
PAR ! DSC ! PIP ! SPON ! WRLK ! OFFON! FMT ! DRTP !
-----

 7 6 5 4 3 2 1 0
-----
DRDY ! VV ! DRA ! NU ! NU ! DRIVE SELECT CODE !
-----
```


L05

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 64
BIT ASSIGNMENTS IN THE RK611 REGISTERS

SEQ 0063

3093
3094
3095
3096
3097
3098
3099
3100
3101
3102
3103
3104
3105
3106
3107
3108
3109
3110
3111
3112
3113
3114
3115
3116
3117
3118
3119
3120
3121
3122
3123
3124
3125
3126
3127
3128
3129
3130

LINE B MESSAGE 00							
15	14	13	12	11	10	9	8
PAR	UNS	DROT	DCLO	WLE	SKI	PERR	ILF
7	6	5	4	3	2	1	0
FLT	ACLO	IVDA	UN	UN	UN	0	0
LINE A MESSAGE 01							
15	14	13	12	11	10	9	8
PAR	UNLDG	RTZ	LDG	REV	FWD	SPEED	CART
	HDS		HDS			OK	PRES
7	6	5	4	3	2	1	0
DOOR	BRUSH	HEADS	TRK	UN	DRIVE SELECT CODE		
LTCH	HOME	HOME	FOLOW				
			OK				
LINE B MESSAGE 01							
15	14	13	12	11	10	9	8
PAR	SERVO	LIMIT	SEEK	PLO	DIBIT	INDEX	MULTI
	BRAKE	ON SK	NO MO	ERR	ERR	ERR	HD SEL
7	6	5	4	3	2	1	0
HEAD	WR GTE	WR CUR	SEC	NU	NU	0	1
FAULT	AND NO	AND NO	ERR				
	XISTON	WR GTE					

M05

CZR6NDD RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 65
BIT ASSIGNMENTS IN THE RK611 REGISTERS

SEQ 0064

3131
3132
3133
3134
3135
3136
3137
3138
3139
3140
3141
3142
3143
3144
3145
3146
3147
3148
3149
3150
3151
3152
3153
3154
3155
3156
3157
3158
3159
3160
3161
3162
3163
3164
3165
3166
3167
3168
3169
3170
3171
3172
3173
3174
3175
3176
3177
3178
3179
3180
3181
3182
3183
3184
3185
3186

: LINE A MESSAGE 10							
15	14	13	12	11	10	9	8
:-----: PAR ! NU ! NU ! CYLINDER DIFF/OFFSET VALUE !							
7	6	5	4	3	2	1	0
:-----: CYLINDER DIFF/OFFSET VALUE! NU ! DRIVE SELECT CODE !							
: LINE B MESSAGE 10							
15	14	13	12	11	10	9	8
:-----: PAR ! ALIGN! NU ! CYLINDER ADDRESS !							
:-----: SIGN !							
7	6	5	4	3	2	1	0
:-----: CYLINDER ADDRESS ! UN ! UN ! 1 ! 0 !							
: LINE A MESSAGE 11							
15	14	13	12	11	10	9	8
:-----: PAR ! DRIVE SERIAL NUMBER !							
7	6	5	4	3	2	1	0
:-----: DRIVE SERIAL NUMBER ! DRIVE SELECT CODE !							
: LINE B MESSAGE 11							
15	14	13	12	11	10	9	8
:-----: PAR ! NU ! NU ! DECODED HEAD ! SECTOR!							
:-----: ADDRESS ! COUNT !							
7	6	5	4	3	2	1	0
:-----: SECTOR COUNT ! UN ! UN ! 1 ! 1 !							

.SBTTL RK06 CONTROLLER REGISTER DEFINITION

000000
000002
000004
000006
000010

RKCS1=	0	:	CONTROL AND STATUS REGISTER 1
RKWC=	2	:	WORD COUNT REGISTER
RKBA=	4	:	BUS ADDRESS REGISTER
RKDA=	6	:	DESIRED TRACK SECTOR REGISTER
RKCS2=	10	:	CONTROL AND STATUS REGISTER 2

N05

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 66
RK06 CONTROLLER REGISTER DEFINITION

SEQ 0065

```

3187      000012      RKDS= 12      ;DRIVE STATUS REGISTER
3188      000014      RKER= 14      ;ERROR REGISTER
3189      000016      RKASOF= 16     ;ATTENTION SUMMARY AND OFFSET REGISTER
3190      000020      RKDC= 20      ;DESIRED CYLINDER REGISTER
3191      000020      RKDCYL= 20     ;DESIRED CYLINDER REGISTER
3192      000024      RKDB= 24      ;DATA BUFFER
3193      000026      RKMR1= 26     ;MAINTENANCE REGISTER 1
3194      000034      RKMR2= 34     ;MAINTENANCE REGISTER 2
3195      000036      RKMR3= 36     ;MAINTENANCE REGISTER 3
3196      000030      RKPOS= 30     ;ECC POSITION INFORMATION
3197      000030      RKECPS= 30   ;ECC POSITION INFORMATION
3198      000032      RKPAT= 32   ;ECC PATTERN INFORMATION
3199      000032      RKECPT= 32  ;ECC PATTERN INFORMATION
3200
3201      .SBTTL  DRIVE COMMANDS
3202
3203      000101      SELDRV= 101    ;SELECT DRIVE
3204      000103      PACK= 103    ;PACK ACKNOWLEDGE
3205      000105      CLEAR= 105   ;DRIVE CLEAR
3206      000107      UNLOAD= 107   ;UNLOAD
3207      000111      SRTSPL= 111   ;START SPINDLE
3208      000113      RECAL= 113   ;RECALIBRATE
3209      000115      OFFSET= 115  ;OFFSET
3210      000117      SEEK= 117    ;SEEK
3211      000121      RDDATA= 121   ;READ DATA
3212      000123      WRDATA= 123   ;WRITE DATA
3213      000125      RDHEAC= 125   ;READ HEADER
3214      000127      WRHEAD= 127   ;WRITE HEADER AND DATA
3215      000131      WRTCHK= 131   ;WRITE CHECK
3216
3217      ;          THE FOLLOWING ARE NOT DRIVE COMMANDS BUT ARE USED BY THE DRIVER
3218      ;          TO SIMULATE A SPECIFIC DESIRED OPERATION
3219
3220      000140      RELEAS= 140   ;RELEASE DRIVE
3221      000141      RDSTAT= 141   ;GET ALL STATUS FROM DRIVE
3222      000164      RDALHD= 164   ;READ ALL HEADERS
3223      000176      CONCLR= 176   ;CONTROLLER CLEAR (BIT 15 OF CS1)
3224      000177      SUBCLR= 177   ;SUBSYSTEM CLEAR (BIT 5 OF CS2)
3225      000300      INTR= 300    ;GENERATE INTERRUPT TO CPU
3226
3227      ;          DRIVER ISSUED SERVICE COMMANDS
3228
3229      000001      DR.SEL= 001    ;DRIVE SELECT
3230      000005      DR.CLR= 005    ;DRIVE CLEAR
3231
3232      .SBTTL  CONTROL AND STATUS REGISTER 1 BITS
3233
3234      000001      GO= BIT0      ;GO BIT
3235      000100      IE= BIT6      ;INTERRUPT ENABLE
3236      000200      RDY= BIT7      ;CONTROLLER READY
3237      000400      BA16= BIT8      ;BUS ADDRESS BIT 16
3238      001000      BA17= BIT9      ;BUS ADDRESS BIT 17
3239      002000      CDT= BIT10     ;CONTROLLER DRIVE TYPE (0=RK06,1=RK07)
3240      004000      CTO= BIT11     ;CONTROLLER TIMED OUT WAITING FOR
3241      ;          DRIVE RESPONSE
3242      010000      CFMT= BIT12     ;CONTROLLER DRIVE FORMAT (0=22 SECTOR, 1=20 SECTOR)

```

```

3243      020000      SPAR=  BIT13      ;DRIVE BUS PARITY ERROR DETECTED BY CONTROLLER
3244      040000      DI=    BIT14      ;DRIVE INTERRUPT
3245      100000      CERR=  BIT15      ;CONTROLLER ERROR
3246      100000      CCLR=  BIT15      ;CONTROLLER CLEAR
3247
3248      ;           ; THESE BIT DEFINITIONS ARE USED FOR ADDRESS
3249      ;           ; THE HIGH BYTE OF RKCS1
3250
3251      000001      B.BA16= BIT0      ;BUS ADDRESS BIT 16
3252      000002      B.BA17= BIT1      ;BUS ADDRESS BIT 17
3253      000004      B.CDT=  BIT2      ;CONTROLLER DRIVE TYPE (0=RK06,1=RK07)
3254      000020      B.CFMT= BIT4      ;CONTROLLER DRIVE FORMAT (0=22 SECTOR, 1=20 SECTOR)
3255
3256      .SBTTL CONTROL AND STATUS REGISTER 2 BITS
3257
3258      000007      DRVMSK= 7           ;MASK FOR DRIVE SELECTION CODE
3259      000010      DESL=  BIT3      ;DESELECT OR RELEASE DRIVE IN BITS 0-2
3260      000010      RLS=  BIT3      ;DESELECT OR RELEASE DRIVE IN BITS 0-2
3261      000020      BAI=  BIT4      ;BUS ADDRESS INCREMENT INHIBIT
3262      000040      CLR=  BIT5      ;CLEAR CONTROLLER AND ALL DRIVES
3263      000040      SCLR= BIT5      ;CLEAR CONTROLLER AND ALL DRIVES
3264      000100      IR=    BIT6      ;INPUT READY
3265      000200      OR=    BIT7      ;OUTPUT READY
3266      000400      UFE=  BIT8      ;UNIT FIELD ERROR
3267      001000      MDS=  BIT9      ;MULTIPLE DRIVE SELECT
3268      002000      PGE=  BIT10     ;PROGRAMMING ERROR
3269      004000      NEM=  BIT11     ;NON-EXISTENT MEMORY
3270      010000      NED=  BIT12     ;NON-EXISTENT DRIVE
3271      020000      UPE=  BIT13     ;UNIBUS PARITY ERROR
3272      040000      WCE=  BIT14     ;WRITE CHECK ERROR
3273      100000      DLT=  BIT15     ;DATA LATE ERROR
3274
3275      .SBTTL ERROR REGISTER BIT DEFINITION
3276
3277      000001      ILC=  BIT0      ;ILLEGAL FUNCTION CODE
3278      ;*ILF=  BIT0      ;ILLEGAL FUNCTION CODE
3279      000002      SKI=  BIT1      ;SEEK INCOMPLETE
3280      000004      ILF=  BIT2      ;ILLEGAL DRIVE FUNCTION
3281      000004      NXF=  BIT2      ;ILLEGAL DRIVE FUNCTION
3282      000010      DRPAR= BIT3      ;DRIVE DETECTED DRIVE BUS PARITY ERROR
3283      000020      FMTE= BIT4      ;FORMAT ERROR
3284      000040      DTYE= BIT5      ;DRIVE TYPE ERROR
3285      000100      ECH=  BIT6      ;ECC HARD
3286      000200      BSE=  BIT7      ;BAD SECTOR ERROR
3287      000400      HCRC= BIT8      ;HEADER CRC ERROR
3288      000400      HVRC= BIT8      ;HEADER VRC ERROR
3289      001000      COE=  BIT9      ;CYLINDER ADDRESS OVERFLOW ERROR
3290      002000      IDAE= BIT10     ;INVALID DISK ADDRESS ERROR
3291      004000      WLE=  BIT11     ;WRITE LOCK ERROR
3292      010000      DTE=  BIT12     ;DRIVE TIMING ERROR
3293      020000      OPI=  BIT13     ;OPERATION (SEARCH) INCOMPLETE
3294      040000      UNS=  BIT14     ;DRIVE UNSAFE
3295      100000      DCK=  BIT15     ;DATA CHECK
3296
3297      .SBTTL STATUS REGISTER BIT DEFINITION
3298

```

```

3299      000001      DRA=      BIT0      ;DRIVE AVAILABLE (CONTROLLER IS SET IF
3300                                     ; THIS BIT IS RESET)
3301      000004      OFST=      BIT2      ;DRIVE OFFSET
3302      000010      ACLO=      BIT3      ;AC LOW
3303      000020      SPDLSS=     BIT4      ;SPEED LOSS
3304      000020      DCLO=      BIT4      ;DC LOW
3305      000040      DROT=      BIT5      ;DRIVE OFF TRACK
3306      000100      VV=        BIT6      ;VOLUME VALID
3307      000200      DRY=        BIT7      ;DRIVE READY
3308      000200      DRDY=      BIT7      ;DRIVE READY
3309      000400      DDT=        BIT8      ;DRIVE TYPE (0=RK06, 1=RK07)
3310      004000      WRL=        BIT11     ;WRITE LOCK
3311      020000      PIP=        BIT13     ;POSITIONING IN PROGRESS
3312      040000      DSC=        BIT14     ;DRIVE STATUS CHANGE
3313      100000      SVAL=      BIT15     ;STATUS VALID
3314
3315      .SBTTL      MAINTENANCE REGISTER 1 BIT DEFINITION
3316
3317      000017      MESMSK=     17      ;MESSAGE MASK
3318
3319      000020      PAT=        BIT4      ;FORCE EVEN PARITY ON DRIVE BUS MESSAGE LINES
3320      000040      DMD=        BIT5      ;DIAGNOSTIC MODE
3321      000100      MSP=        BIT6      ;MAINTENANCE SECTOR PULSE
3322      000200      MIND=      BIT7      ;MAINTENANCE INDEX
3323      000400      MCLK=      BIT8      ;MAINTENANCE CLOCK
3324      001000      MERD=      BIT9      ;MAINTENANCE ENCODED READ DATA
3325      002000      MEWD=      BIT10     ;MAINTENANCE ENCODED WRITE DATA
3326      004000      PCA=        BIT11     ;PRECOMPENSATION ADVANCE
3327      010000      PCD=        BIT12     ;PRECOMPENSATION DELAY
3328      020000      ECCW=      BIT13     ;ECC WORD IS BEING READ OR WRITTEN
3329      040000      WRTGAT=    BIT14     ;WRITE GATE
3330      100000      RDGATE=    BIT15     ;READ GATE
3331
3332      .SBTTL      DEFINITION OF DRIVE STATUS BYTE 00 MESSAGE A
3333
3334      000040      S.DRA=      BIT5      ;DRIVE AVAILIABLE
3335      000100      S.VV=       BIT6      ;VOLUME VALID
3336      000200      S.DRY=      BIT7      ;DRIVE READY
3337      000400      S.TYPE=     BIT8      ;DRIVE TYPE
3338      001000      S.FORM=     BIT9      ;DRIVE FORMAT
3339      002000      S.OFF=     BIT10     ;OFFSET
3340      004000      S.WRL=     BIT11     ;WRITE LOCK
3341      010000      S.SPIN=    BIT12     ;SPINDLE ON
3342      020000      S.PIP=     BIT13     ;POSITIONING IN PROGRESS
3343      040000      S.DSC=     BIT14     ;DRIVE STATUS CHANGE
3344
3345      .SBTTL      DEFINITION OF DRIVE STATUS BYTE 00 MESSAGE B
3346
3347      000040      S.ICYL=     BIT5      ;ILLEGAL CYLINDER ADDRESS
3348      000100      S.ACLO=     BIT6      ;AC LOW
3349      000200      S.FLT=     BIT7      ;DRIVE FAULT
3350      000400      S.ILF=     BIT8      ;ILLEGAL FUNCTION
3351      001000      S.PAR=     BIT9      ;DRIVE DETECTED DRIVE BUS PARITY ERROR
3352      002000      S.SKI=     BIT10     ;SEEK INCOMPLETE
3353      004000      S.WLE=     BIT11     ;WRITE LOCK ERROR
3354      010000      S.SPLS=    BIT12     ;SPEED LOSS

```

3355 010000
3356 020000
3357 040000

S.DCLO= BIT12 ;DC LOW
S.DROT= BIT13 ;DRIVE OFF TRACK
S.UNS= BIT14 ;DRIVE UNSAFE

.SBTTL DEFINITION OF DRIVE STATUS BYTE 01 MESSAGE A

3361 000020
3362 000040
3363 000100
3364 000200
3365 000400
3366 001000
3367 002000
3368 004000
3369 010000
3370 020000
3371 040000

S.XDOK= BIT4 ;TRANSDUCER OK
S.HDHM= BIT5 ;HEADS HOME
S.BRHM= BIT6 ;BRUSHES HOME
S.DOOR= BIT7 ;DOOR INTERLOCKED
S.CART= BIT8 ;CARTRAGE INTERLOCK
S.SPOK= BIT9 ;SPEED OK
S.FWD= BIT10 ;FORWARD
S.REV= BIT11 ;REVERSE
S.LOAD= BIT12 ;HEADS LOADING
S.RTZ= BIT13 ;RETURN TO ZERO
S.UNLD= BIT14 ;HEADS UNLOADING

.SBTTL DEFINITION OF DRIVE STATUS BYTE 01 MESSAGE B

3375 000020
3376 000040
3377 000100
3378 000200
3379 000400
3380 001000
3381 002000
3382 004000
3383 010000
3384 020000
3385 040000

S.SECT= BIT4 ;SECTOR ERROR
S.WCLK= BIT5 ;WRITE CLOCK AND NO WRITE GATE
S.WGAT= BIT6 ;WRITE GATE AND NO TRANSISTIONS
S.HDFL= BIT7 ;HEAD FAULT
S.MHD= BIT8 ;MULTIPLE HEAD SELECT
S.XERR= BIT9 ;INDEX ERROR
S.DIB= BIT10 ;DIBIT ERROR
S.PLO= BIT11 ;PLO ERROR
S.NMOV= BIT12 ;SEEK AND NO MOTION
S.LIND= BIT13 ;LIMIT DETECT ON SEEK
S.BRKE= BIT14 ;SERVO-BRAKE

.SBTTL COMMON MASKS

3389 000007
3390 100000
3391 000003
3392 017760
3393 017760
3394 077770
3395 000760
3396 007000

M.DRV= 7 ;DRIVE CODE
M.PAR= BIT15 ;PARITY
M.ID= 3 ;BYTE ID
M.CDIF= 17760 ;CYLINDER DIFFERENCE/OFFSET
M.CADD= 17760 ;CYLINDER ADDRESS
M.SER= 77770 ;DRIVE SERIAL NUMBER
M.SECT= 760 ;SECTOR COUNT
M.HEAD= 7000 ;HEAD DECODE



3397
3398
3399
3400
3401
3402
3403
3404
3405
3406
3407
3408
3409
3410
3411
3412
3413
3414
3415
3416
3417
3418
3419
3420
3421
3422
3423
3424
3425
3426
3427
3428
3429
3430
3431
3432
3433
3434
3435
3436
3437
3438
3439
3440
3441
3442
3443
3444
3445
3446
3447
3448
3449
3450
3451
3452

.SBTTL PARAMETER BLOCK ALLOCATION

```

*****
* 1  COMMAND ! DRIVE NO.
* 2  CYLINDER ADDRESS
* 3  TRACK ! SECTOR
* 4  BA16-17, FORMAT, DRV TYPE ! OFFSET
* 5  11  BUS ADDRESS (LOW 16 BITS)
* 6  13  WORD COUNT (2'S COMPLEMENT)
* 7  15  PROGRAM DRIVE STATUS INFORMATION
* 8  17  COMMAND AND STATUS REGISTER 1
* 9  21  COMMAND AND STATUS REGISTER 2
*10  23  WORD COUNT REGISTER
*11  25  BUS ADDRESS REGISTER
*12  27  DESIRED TRACK AND SECTOR
*13  31  DESIRED CYLINDER
*14  33  ATTENTION SUMMARY AND DRIVE OFFSET
*15  35  ERROR REGISTER
*16  37  STATUS REGISTER
*17  41  MESSAGE LINE A STATUS BYTE 00
*18  43  MESSAGE LINE B STATUS BYTE 00
*19  45  MESSAGE LINE A STATUS BYTE 01
*20  47  MESSAGE LINE B STATUS BYTE 01
*21  51  MESSAGE LINE A STATUS BYTE 10
*22  53  MESSAGE LINE B STATUS BYTE 10
*23  55  MESSAGE LINE A STATUS BYTE 11
*24  57  MESSAGE LINE B STATUS BYTE 11
*25  61  ECC POSITION INFORMATION
*26  63  ECC PATTERN INFORMATION
*****

```

104
120
144
160
200
224
240
260
300
324
344
400
424
444
460
500
524
544
560
600

.SBTTL PARAMETERS PASSED TO THE DRIVER

THE FOLLOWING DEFINITIONS ARE USED TO PASS PARAMETERS TO THE RK06/RK07 DRIVER

```

000000 P.DRVN= 0 ;DRIVE NUMBER
000001 P.CMND= 1 ;COMMAND
000002 P.CYLN= 2 ;CYLINDER ADDRESS
000004 P.SECT= 4 ;SECTOR
000005 P.TRCK= 5 ;TRACK
000006 P.OFST= 6 ;OFFSET
000007 P.CSIH= 7 ;RKCSI BITS 8-15
000007 P.BAHI= 7 ;BUS ADDRESS (BITS 16 AND 17)
000010 P.BALO= 10 ;BUS ADDRESS (BITS 0-15)
000012 P.WC= 12 ;WORD COUNT (2'S COMPLEMENT)
000014 P.PRST= 14 ;PROGRAM DRIVE STATUS INFORMATION

```

.SBTTL PROGRAM DEVICE STATUS REGISTER DEFINITION

```

000001 DRVUSE= BIT0 ;DRIVE IN USE
000002 DRVPOS= BIT1 ;DRIVE POSITIONING
000004 DRVPDT= BIT2 ;DRIVE POSITIONED FOR DATA TRANSFER
000010 UEXATT= BIT3 ;UNEXPECTED ATTENTION
000020 DRVHRD= BIT4 ;DRIVE HAS HARD ERROR
000040 DRVDSC= BITS ;DRIVE STATUS CHANGE DID NOT CLEAR

```

```

3453      000100      CMDT0= BIT6      ; NO TERMINATION TO COMMAND FOR AT
3454      ;           ;           ;           ;           ;           ;           ;
3455      000200      W.WCK= BIT7      ; WRITE FOR WRITE WRITE CHECK
3456      000400      NOCHK= BIT8      ; NO CHECK, DO NOT SET INTERRUPT ENABLE
3457      001000      PBSVAL= BIT9      ; PARAMETER STATUS WORDS VALID
3458      ;           ;           ;           ;           ;           ;           ;
3459      ;           ;           ;           ;           ;           ;           ;
3460      002000      DRPDRV= BIT10     ; DROP DRIVE FROM TEST SEQUENCE
3461      004000      NODSC= BIT11     ; ATTENTION SET BUT DCS AND FAULT RESET
3462      010000      DRVSZD= BIT12     ; DRIVE SEIZED BY OTHER PORT
3463      020000      E.UNLD= BIT13     ; DRIVE UNLOADED DUE TO ERROR
3464      040000      Q.INIT= BIT14     ; PARAMETER BLOCK ENQUEUED IN INITIATION QUEUE
3465      100000      DTBAII= BIT15     ; INHIBIT BUS ADDRESS INCREMENT
3466
3467      .SBTTL  PARAMETERS PASSED FROM DRIVER TO PROGRAM
3468
3469      ;           ;           ;           ;           ;           ;           ;
3470      ;           ;           ;           ;           ;           ;           ;
3471      ;           ;           ;           ;           ;           ;           ;
3472      000016      P.CS1= 16          ; COMMAND AND STATUS REGISTER 1
3473      000020      P.CS2= 20          ; COMMAND AND STATUS REGISTER 2
3474      000022      P.WCR= 22          ; WORD COUNT REGISTER
3475      000024      P.BAR= 24          ; BUS ADDRESS REGISTER
3476      000026      P.DTS= 26          ; DESIRED TRACK SECTOR REGISTER
3477      000030      P.DCYL= 30         ; DESIRED CYLINDER REGISTER
3478      000032      P.ASOF= 32         ; ATTENTION SUMMARY/OFFSET REGISTER
3479      000034      P.ER= 34           ; ERROR REGISTER
3480      000036      P.DS= 36           ; STATUS REGISTER
3481      000040      P.A00= 40          ; MESSAGE A STATUS BYTE 00
3482      000042      P.B00= 42          ; MESSAGE B STATUS BYTE 00
3483      000044      P.A01= 44          ; MESSAGE A STATUS BYTE 01
3484      000046      P.B01= 46          ; MESSAGE B STATUS BYTE 01
3485      000050      P.A10= 50          ; MESSAGE A STATUS BYTE 10
3486      000052      P.B10= 52          ; MESSAGE B STATUS BYTE 10
3487      000054      P.A11= 54          ; MESSAGE A STATUS BYTE 11
3488      000056      P.B11= 56          ; MESSAGE B STATUS BYTE 11
3489      000060      P.EPOS= 60         ; ECC POSITION INFORMATION
3490      000062      P.EPAT= 62        ; ECC PATTERN INFORMATION
3491
3492      .SBTTL  PARAMETER BLOCK 0 FOR DRIVE
3493
3494      002630      000      PARMO: .BYTE 0      ; DRIVE NUMBER
3495      002631      000      .BYTE 0      ; COMMAND
3496      002632      000000   .WORD 0      ; CYLINDER ADDRESS
3497      002634      000      .BYTE 0      ; SECTOR ADDRESS
3498      002635      000      .BYTE 0      ; TRACK ADDRESS
3499      002636      000      .BYTE 0      ; OFFSET VALUE
3500      002637      000      .BYTE 0      ; BUS ADDRESS (BITS 16 AND 17)
3501      002640      000000   .WORD 0      ; BUS ADDRESS (BITS 0 - 15)
3502      002642      000000   .WORD 0      ; WORD COUNT (2'S COMPLEMENT)
3503      002644      000000   .WORD 0      ; PROGRAM DRIVE STATUS INFORMATION
3504      002646      000000   .WORD 0      ; COMMAND AND STATUS REGISTER 1
3505      002650      000000   .WORD 0      ; COMMAND AND STATUS REGISTER 2
3506      002652      000000   .WORD 0      ; WORD COUNT REGISTER
3507      002654      000000   .WORD 0      ; BUS ADDRESS REGISTER
3508      002656      000000   .WORD 0      ; DESIRED TRACK AND SECTOR REGISTER

```


3509	002660	000000	.WORD	0	: DESIRED CYLINDER REGISTER
3510	002662	000000	.WORD	0	: ATTENTION SUMMARY/OFFSET REGISTER
3511	002664	000000	.WORD	0	: ERROR REGISTER
3512	002666	000000	.WORD	0	: STATUS REGISTER
3513	002670	000000	.WORD	0	: MESSAGE LINE A STATUS BYTE 00
3514	002672	000000	.WORD	0	: MESSAGE LINE B STATUS BYTE 00
3515	002674	000000	.WORD	0	: MESSAGE LINE A STATUS BYTE 01
3516	002676	000000	.WORD	0	: MESSAGE LINE B STATUS BYTE 01
3517	002700	000000	.WORD	0	: MESSAGE LINE A STATUS BYTE 10
3518	002702	000000	.WORD	0	: MESSAGE LINE B STATUS BYTE 10
3519	002704	000000	.WORD	0	: MESSAGE LINE A STATUS BYTE 11
3520	002706	000000	.WORD	0	: MESSAGE LINE B STATUS BYTE 11
3521	002710	000000	.WORD	0	: ECC POSITION INFORMATION
3522	002712	000000	.WORD	0	: ECC PATTERN INFORMATION

.SBTTL PARAMETER BLOCK 1 FOR DRIVE

3526	002714	000	PARM1: .BYTE	0	: DRIVE NUMBER
3527	002715	000	.BYTE	0	: COMMAND
3528	002716	000000	.WORD	0	: CYLINDER ADDRESS
3529	002720	000	.BYTE	0	: SECTOR ADDRESS
3530	002721	000	.BYTE	0	: TRACK ADDRESS
3531	002722	000	.BYTE	0	: OFFSET VALUE
3532	002723	000	.BYTE	0	: BUS ADDRESS (BITS 16 AND 17)
3533	002724	000000	.WORD	0	: BUS ADDRESS (BITS 0 - 15)
3534	002726	000000	.WORD	0	: WORD COUNT (2'S COMPLEMENT)
3535	002730	000000	.WORD	0	: PROGRAM DRIVE STATUS INFORMATION
3536	002732	000000	.WORD	0	: COMMAND AND STATUS REGISTER 1
3537	002734	000000	.WORD	0	: COMMAND AND STATUS REGISTER 2
3538	002736	000000	.WORD	0	: WORD COUNT REGISTER
3539	002740	000000	.WORD	0	: BUS ADDRESS REGISTER
3540	002742	000000	.WORD	0	: DESIRED TRACK AND SECTOR REGISTER
3541	002744	000000	.WORD	0	: DESIRED CYLINDER REGISTER
3542	002746	000000	.WORD	0	: ATTENTION SUMMARY/OFFSET REGISTER
3543	002750	000000	.WORD	0	: ERROR REGISTER
3544	002752	000000	.WORD	0	: STATUS REGISTER
3545	002754	000000	.WORD	0	: MESSAGE LINE A STATUS BYTE 00
3546	002756	000000	.WORD	0	: MESSAGE LINE B STATUS BYTE 00
3547	002760	000000	.WORD	0	: MESSAGE LINE A STATUS BYTE 01
3548	002762	000000	.WORD	0	: MESSAGE LINE B STATUS BYTE 01
3549	002764	000000	.WORD	0	: MESSAGE LINE A STATUS BYTE 10
3550	002766	000000	.WORD	0	: MESSAGE LINE B STATUS BYTE 10
3551	002770	000000	.WORD	0	: MESSAGE LINE A STATUS BYTE 11
3552	002772	000000	.WORD	0	: MESSAGE LINE B STATUS BYTE 11
3553	002774	000000	.WORD	0	: ECC POSITION INFORMATION
3554	002776	000000	.WORD	0	: ECC PATTERN INFORMATION

.SBTTL TEMPORARY CONTROLLER REGISTER STORAGE

3558	003000	000000	T.CS1: .WORD	0	: TEMPORARY STORAGE FOR COMMAND AND STATUS REGISTER 1
3559					
3560	003002	000000	T.CS2: .WORD	0	: TEMPORARY STORAGE FOR COMMAND AND STATUS REGISTER 2
3561					
3562	003004	000000	T.WCR: .WORD	0	: TEMPORARY STORAGE FOR WORD COUNT REGISTER
3563	003006	000000	T.BA: .WORD	0	: TEMPORARY STORAGE FOR BUS ADDRESS REGISTER
3564	003010	000000	T.DA: .WORD	0	: TEMPORARY STORAGE FOR DISK TRACK AND SECTOR

3565	003012	000000	T.DC:	.WORD	0	:	TEMPORARY STORAGE FOR DRIVE CYLINDER
3566	003014	000000	T.ASOF:	.WORD	0	:	TEMPORARY STORAGE FOR ATTENTION SUMMARY
3567						:	AND OFFSET
3568	003016	000000	T.ER:	.WORD	0	:	TEMPORARY STORAGE FOR ERROR REGISTER
3569	003020	000000	T.DS:	.WORD	0	:	TEMPORARY STORAGE FOR DRIVE STATUS REGISTER
3570	003022	000000	T.MR1:	.WORD	0	:	TEMPORARY STORAGE FOR MAINTENANCE REGISTER 1
3571	003024	000000	T.MR2:	.WORD	0	:	TEMPORARY STORAGE FOR MAINTENANCE REGISTER 2
3572	003026	000000	T.MR3:	.WORD	0	:	TEMPORARY STORAGE FOR MAINTENANCE REGISTER 3
3573	003030	000000	T.POS:	.WORD	0	:	TEMPORARY STORAGE FOR ECC POSITION
3574	003032	000000	T.PAT:	.WORD	0	:	TEMPORARY STORAGE FOR ECC PATTERN
3575	003034	000000	T.DB:	.WORD	0	:	TEMPORARY STORAGE FOR DATA BUFFER REGISTER
3576						:	
3577			.SBTTL	DRIVER	PARAMETERS	:	
3578						:	
3579	003036	177440	RKBAS:	.WORD	177440	:	ADDRESS OF RK611 UNIBUS ADDRESS BLOCK
3580	003040	000210	RKVEC:	.WORD	210	:	ADDRESS OF R611 VECTOR
3581	003042	000240	RKPRI:	.WORD	PRS	:	RK611 INTERRUPT PRIORITY
3582	003044	042732	A.NORM:	ERRFRE		:	ADDRESS OF NORMAL RETURN FROM DRIVER
3583	003046	044200	A.ABNL:	ERRHDL		:	ADDRESS OF ABNORMAL RETURN FROM DRIVER
3584	003050	043474	A.CONT:	CONERR		:	ADDRESS OF CONTROLLER ERROR RETURN
3585	003052	000000	E.CONT:	.WORD	0	:	CONTROLLER ERROR STATUS
3586						:	THIS LOCATION IS CLEARED WHEN EVERY COMMAND
3587						:	IS INITIATED. IF A CONTROLLER ERROR
3588						:	OCCURS THE FOLLOWING BIT ASSIGNMENT IS
3589						:	USED:
3590						:	
3591		000001	E.CCLR=	BIT0		:	CLEAR CONTROLLER DID NOT CLEAR ERROR
3592		000002	E.NOAT=	BIT1		:	NO ATTENTION IN ATTENTION SUMMARY REG
3593		000004	E.UATT=	BIT2		:	UNSOLICATED ATTENTION (SEQUENTIAL ONLY)
3594		000010	E.UDAT=	BIT3		:	UNEXPECTED DATA TYPE ERROR
3595		000020	E.CLAT=	BIT4		:	ATTENTION DID NOT RESET WITH CLEAR
3596		000040	E.SCLR=	BIT5		:	SUBSYSTEM CLEAR DID NOT CLEAR DRIVE
3597						:	ATTENTION
3598		000100	E.ILLD=	BIT6		:	ILLEGAL DRIVER COMMAND
3599		000400	E.DLT=	BIT8		:	DATA LATE WHEN UNLOADING HEADER
3600		001000	E.CERR=	BIT9		:	CONTROLLER ERROR DURING DRIVER SERVICING
3601		002000	E.DPAR=	BIT10		:	DRIVE DETECTED PARITY ERROR
3602		040000	E.CMTO=	BIT14		:	CONTROLLER COMMAND TIME OUT (QUEUED ONLY)
3603		100000	E.MDS=	BIT15		:	MULTIPLE DRIVE SELECT
3604						:	
3605	003054	000000	O.WAIT:	.WORD	0	:	PARAMETER BLOCK OF THE DRIVE
3606						:	WAITING FOR COMMAND COMPLETION
3607	003056	000400	W.MTIM:	.WORD	400	:	LOOP COUNTER FOR MILLISECOND SCAN OF DRIVE
3608	003060	000400	W.MILI:	.WORD	400	:	16 MILLISECOND TIME FOR PROGRAM
3609						:	
3610						:	
3611						:	
3612						:	
3613						:	
3614						:	
3615						:	
3616						:	
3617						:	
3618						:	
3619						:	
3620						:	

CPU	VALUE
---	-----
11/05	100
11/10	
11/20	
11/34	
11/40	
11/45	400
11/50	
11/70	

```

3621 003062 000300          W.SEC: .WORD 300          ;SECOND COUNT COUNT FOR ALL COMMANDS
3622                                     ; EXCEPT START SPINDLE
3623 003064 003000          W.8SEC: .WORD 3000       ;8 SECOND FOR DRIVE CYCLE DOWN
3624 003066 030000          W.MIN: .WORD 30000      ;MINUTE TIME FOR START SPINDLE
3625 003070 000000          HDR.AD: .WORD 0         ;ADDRESS USED FOR READ ALL HEADERS
3626 003072 000000          HDR.CT: .WORD 0         ;NUMBER OF HEADERS LEFT TO READ FOR READ
3627                                     ; ALL HEADERS
3628 003074 000          I.ISRL: .BYTE 0         ;INTERRUPT OR RELEASED COMMAND ISSUED
3629 003075 002          004 010 H.HEAD: .BYTE 2,4,10 ;HEAD DECODES
3630 003100 000          W.TIME: .BYTE 0         ;DRIVES BEING WATCH-DOG TIMED
3631                                     ;
3632          .SBTTL INTERRUPT MASKS
3633
3634 003101 000          INTMSK: .BYTE 0         ;INTERRUPT MASKS FOR DRIVE IN PARAMETER BLOCK
3635                                     ;
3636          ; INTERRUPT MASK TABLE
3637
3638 003102 001          I.DRV: .BYTE 1         ;INTERRUPT MASK FOR DRIVE 0
3639 003103 002          ;.BYTE 2         ;INTERRUPT MASK FOR DRIVE 1
3640 003104 004          ;.BYTE 4         ;INTERRUPT MASK FOR DRIVE 2
3641 003105 010          ;.BYTE 10        ;INTERRUPT MASK FOR DRIVE 3
3642 003106 020          ;.BYTE 20        ;INTERRUPT MASK FOR DRIVE 4
3643 003107 040          ;.BYTE 40        ;INTERRUPT MASK FOR DRIVE 5
3644 003110 100          ;.BYTE 100       ;INTERRUPT MASK FOR DRIVE 6
3645 003111 200          ;.BYTE 200       ;INTERRUPT MASK FOR DRIVE 7
3646                                     ;
3647          .SBTTL PARAMETER BLOCK TABLE
3648
3649 003112 002630          PBLKT:  PARM0         ;ADDRESS OF PARAMETER BLOCK GIVEN WITH
3650                                     ;DRIVE CALL. MUST BE LOADED INTO PBLKT
3651                                     ;
3652                                     ;
3653          .SBTTL TIME FOR WATCH-DOG TIMER
3654
3655 003114 000000          W.DRV: .WORD 0         ;TIME FOR INSTRUCTION IN PARAMETER BLOCK
3656          .SBTTL PROGRAM SPECIFIC RESERVED LOCATIONS
3657 003116 000          MDFLAG: .BYTE 0         ;FLAG TO INDIC. DEFLT OR PARAM MODE
3658 003117 000          XXDPCH: .BYTE 0         ;XXDP CHAIN MODE FLAG
3659 003120 000          TSTING: .BYTE 0         ;CURRENTLY RUNNING TESTS IF = 1
3660 003121 000          DERCNT: .BYTE 0         ;DATA ERROR COUNT
3661 003122 000          OPCOMP: .BYTE 0         ;OPERATION COMPLETE FLAG
3662 003123 000          DONE: .BYTE 0         ;DONE SWITCH
3663 003124 000          TYPFMT: .BYTE 0         ;DRIVE TYPE & FORMAT CONTROL
3664 003125 000          FORMAT: .BYTE 0         ;DRIVE FORMAT IN BIT 4 OF BYTE
3665 003126 000          ERRCNT: .BYTE 0         ;ERROR COUNT
3666 003127 004          ERRLM: .BYTE 4         ;ERROR LIMIT
3667 003130 000          DRVERS: .BYTE 0         ;ERROR COUNT FOR CURRENT DRIVE
3668 003131 000          OPCONT: .BYTE 0         ;OPERATION CONTROL SWITCHES
3669 003132 000          PCLKF: .BYTE 0         ;IF BYTE=1, KW11-P CLOCK IS PRESENT
3670 003133 000          XOVLAD: .BYTE 0         ;FLAG = 1 IF XXDP IS POSSIBLY OVERLAID
3671 003134 000          XDPSVD: .BYTE 0         ;FLAG = 1 IF XXDP IS SAVED
3672 003135 000          DULACS: .BYTE 0         ;FLAG=1 IF DUAL ACCESS TEST
3673 003136 000          DRNAFG: .BYTE 0         ;=1 INDICATES DRIVE SIEZED BY OTHER PORT
3674 003137 000          REISSU: .BYTE 0         ;DUAL-ACC FLAG TO RE-ISSUE COMMAND
3675 003140 000          WCEFLG: .BYTE 0         ;WRITE CHECK ERROR FLAG
3676 003141 000          DLTFLG: .BYTE 0         ;DATA LATE ERROR FLAG

```

JOB

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 75
PROGRAM SPECIFIC RESERVED LOCATIONS

SEQ 0074

3677	003142	000	NORTRY: .BYTE	0	;	"NO-RETRY" FLAG
3678	003143	000	UBMPRS: .BYTE	0	;	UNIBUS MAP PRESENT IF = 1
3679	003144	000	MEMABT: .BYTE	0	;	SET BYTE = 1 FOR NO ABORT
3680					;	ON MEMORY PARITY ERRORS
3681	003145	000	HLPOVL: .BYTE	0	;	HELP FILE OVERLAID INDICATOR
3682	003146	000	NOTYPE: .BYTE	0	;	INDICATES PROGRAM JUST LOADED IF 0
3683		000001	WHDSW=BIT0		;	WRITE HEADER & DATA SWITCH
3684		000002	VFHDSW=BIT1		;	VERIFY HEADERS SWITCH
3685		000004	WCDASW=BIT2		;	WRITE CHECK DATA SWITCH
3686		000010	RCDASW=BIT3		;	READ CHECK DATA SWITCH
3687		000020	OREQSW=BIT4		;	OFFSET REQUIRED SWITCH
3688		003150				
3689	003150	000000	AUTOFG: .EVEN	0	;	SPECIAL FLAG
3690						
3691	003152	177546	LKS: .WORD	177546	;	KW11-L CLOCK STATUS REGISTER
3692	003154	172540	PKS: .WORD	172540	;	KW11-P CONTROL AND STATUS REGISTER
3693	003156	172542	PKSB: .WORD	172542	;	KW11-P COUNT SET BUFFER REGISTER
3694	003160	172544	PKRB: .WORD	172544	;	KW11-P COUNTER REGISTER
3695	003162	000100	LCVEC: .WORD	100	;	KW11-L VECTOR STORAGE
3696	003164	000104	PCVEC: .WORD	104	;	KW11-P VECTOR STORAGE
3697		000114	MEMVEC=114		;	MEMORY PARITY TRAP VECTOR

3698	003166	000000			TCNLO: .WORD	0	;LO BITS OF CALIBRATION TIME CONSTANT
3699	003170	000000			TCONHI: .WORD	0	;HI BITS OF CALIB TIME CONST
3700	003172	000000			SUMLO1: .WORD	0	;LO BITS OF FORWARD TIME SUM
3701	003174	000000			SUMHI1: .WORD	0	;HI BITS OF FORWARD TIME SUM
3702	003176	000000			SAVPAR: .WORD	0	;SAVE WORD FOR PAR CONSTANT
3703	003200	000000			SAVWRD: .WORD	0	;SCRATCH WORD
3704	003202	000000			CYL: .WORD	0	;STARTING CYL FOR MULTI-DRV TEST
3705	003204	000010			CYLLST: .BLKW	↑D8	;LIST OF PSEUDO-RAND CYL ADDRESSES
3706	003224	000400			BSSOFT: .BLKW	↑D256	;RECORD OF BAD SECTORS FROM SOFTWARE
3707	004224	000400			BSFACT: .BLKW	↑D256	;RECORD OF BAD SECTORS FROM FACTORY
3708	005224	000000	000000	000000	PRVCMO: .WORD	0,0,0,0,0,0	;PREVIOUS COMMAND STORAGE
3709	005232	000000	000000	000000			
3710	005240	000000	000000	000000	COMSTR: .WORD	0,0,0,0,0,0	;CURRENT COMMAND STORAGE
3711	005246	000000	000000	000000			
3712	005254	000000			PRMPLO: .WORD	0	;PREV. U.B. MAP REG 0
3713	005256	000000			PRMPHO: .WORD	0	
3714	005260	000000			CRMPLO: .WORD	0	;CURRENT U.B. MAP REG 0
3715	005262	000000			CRMPHO: .WORD	0	
3716	005264	000102			BUFFO: .BLKW	↑D66	;OUTPUT BUFFER 1
3717	005470	000000			LOWOCT: .WORD	0	;LOW 16 BITS OF CONVERTED BINARY NUMBER
3718	005472	000000			HIGOCT: .WORD	0	;HIGH BITS OF CONVERTED BINARY NO.
3719	005474	000000			RECODE: .WORD	0	;RECOVERY CODE WORD
3720	005476	000000			ERRCOM: .WORD	0	;ERROR COMMAND
3721	005500	000000			DRIVE: .WORD	0	;NO. OF DRIVE IN USE
3722	005502	000000			STALLS: .WORD	0	;CURRENT NO. OF UNIT STALLS TO APPLY
3723	005504	000000			CYLNRD: .WORD	0	;CURRENT CYLINDER NUMBER
3724	005506	000000			FS: .WORD	0	;FIRST SECTOR LIMIT
3725	005510	000000			LS: .WORD	0	;LAST SECTOR LIMIT
3726	005512	000000			NCYL1: .WORD	0	;NEXT CYL SCRATCH WORD
3727	005514	000000			NCYL2: .WORD	0	;NEXT CYL SCRATCH WORD
3728	005516	000000			OFINUS: .WORD	0	;OFFSET IN USE
3729	005520	000000			TRACK: .WORD	0	;TRACK IN USE
3730	005522	000000			INTCHR: .WORD	0	;TTY INTERRUPT INPUT WORD
3731	005524	000000			SELECT: .WORD	0	;ANY BIT SET IN LOW BYTE GIVES AUTO-SELECTED DRIVE NO.
3732	005526	000000			ONLINE: .WORD	0	;ANY BIT SET IN LOW BYTE INDICATES A DRIVE WAS ON-LINE
3733	005530	000000			NEWON: .WORD	0	;NEW LOOK AT ONLINE DRIVES
3734	005532	000000			HDALI: .WORD	0	;TAG USED FOR INTERNAL USE
3735	005534	000000			SCRACH: .WORD	0	;ALL-PURPOSE SCRATCH WORD
3736	005536	000000			PATRN: .WORD	0	;DATA PATTERN LIST WORD
3737	005540	000000			XXDPAD: .WORD	0	;STARTING ADDRESS OF XXDP LOADER
3738	005542	000002			XDPSAV: .BLKW	2	;XXDP PHYSICAL SAVE ADDRESS
3739	005546	000000			PLOFST: .WORD	0	;(+) OFFSET VALUE
3740	005550	000000			NGOFST: .WORD	0	;(-) OFFSET VALUE
3741	005552	000005			SAVPRS: .BLKW	5	;SAVE INITIAL PARAMS FOR XFER
3742	005564	000000			WDSXFR: .WORD	0	;NO. OF WORDS ACTUALLY XFERRED
3743	005566	000000			FINCYL: .WORD	0	;FINAL CYLINDER ADRS
3744	005570	000			FINTRK: .BYTE	0	;FINAL TRACK ADRS
3745	005571	000			FINSEC: .BYTE	0	;FINAL SECTOR ADRS
3746	005572	000000			LASTWC: .WORD	0	;ACTUAL FINAL WC
3747	005574	157776			MAHILM: .WORD	157776	;MA UPPER LIMIT
3748	005576	000077				77	
3749	005600	065660			MA: .WORD	RWBUF	;LO BITS OF PHYS MEM ADRS
3750	005602	000000				0	;HI BITS OF PHYS MEM ADRS
3751	005604	000002			PMA: .BLKW	2	;PARTIAL TRANSFER MEMORY START ADRS
3752							
3753							

3754
3755
3756 005610
3757 005610 001
3758 005611 001
3759 005612 001
3760 005613 001
3761 005614 001
3762 005615 001
3763 005616 001
3764 005617 001
3765
3766 005620
3767 005620 000
3768 005621 000
3769 005622 000
3770 005623 000
3771 005624 000
3772 005625 000
3773 005626 000
3774 005627 000
3775
3776
3777
3778
3779
3780
3781 005630
3782 005630 000002
3783 005632 000002
3784 005634 000002
3785 005636 000002
3786 005640 000002
3787 005642 000100
3788
3789
3790
3791
3792 005644
3793 005644 000002
3794 005646 000002
3795 005650 000002
3796 005652 000002
3797 005654 000002
3798 005656 000100
3799
3800
3801 000006
3802
3803
3804
3805 005660
3806 005660 000000
3807 005662 000000
3808 005664 000000
3809 005666 000002

;LIST OF DESIRED DRIVES TO TEST (IF BYTE=0, DON'T TEST DRIVE)
DRVLIST:

```
.BYTE 1 ;DRIVE 0
.BYTE 1 ;DRIVE 1
.BYTE 1 ;DRIVE 2
.BYTE 1 ;DRIVE 3
.BYTE 1 ;DRIVE 4
.BYTE 1 ;DRIVE 5
.BYTE 1 ;DRIVE 6
.BYTE 1 ;DRIVE 7
```

;LIST OF DRIVE TYPES, 0=RK06, NON 0=RK07
DTYLIST:

```
.BYTE 0 ;DRV 0
.BYTE 0 ;DRV 1
.BYTE 0 ;DRV 2
.BYTE 0 ;DRV 3
.BYTE 0 ;DRV 4
.BYTE 0 ;DRV 5
.BYTE 0 ;DRV 6
.BYTE 0 ;DRV 7
```

;LIST OF ITERATION COUNTS FOR DESIRED TESTS (IF=0, TEST NOT RUN)
;MAXIMUM ALLOWABLE NUMBER OF ITERATIONS = 77776 (OCT)
TSTLIST:

```
.WORD 2 ;TEST 1
.WORD 2 ;TEST 2
.WORD 2 ;TEST 3
.WORD 2 ;TEST 4
.WORD 2 ;TEST 5
.WORD 100 ;TEST 6
```

;LIST OF DEFAULT ITERATION COUNTS FOR ALL TESTS
DFLTST:

```
.WORD 2 ;TEST 1
.WORD 2 ;TEST 2
.WORD 2 ;TEST 3
.WORD 2 ;TEST 4
.WORD 2 ;TEST 5
.WORD 100 ;TEST 6
```

NMTSTS=<DFLTST-TSTLIST>/2 ;TOTAL NO. OF AUTOMATIC TESTS

;OPERATING PARAMETER LIST
PRMLST:

```
FC: .WORD 0 ;FIRST CYLINDER
LC: .WORD 0 ;LAST CYLINDER
FT: .WORD 0 ;FIRST TRACK
LT: .WORD 2 ;LAST TRACK
```

3810 005670 000000
3811 005672 000023
3812 005674 000000
3813 005676 000025
3814 005700 000000
3815 005702 000000
3816 005704 000000

SO: .WORD 0 ;FIRST SECTOR IF 20(DEC) SECTOR FMT
S1: .WORD 23 ;LAST SECTOR IF 20(DEC) SECTOR FMT
S2: .WORD 0 ;FIRST SECTOR IF 22(DEC) SECTOR FMT
S3: .WORD 25 ;LAST SECTOR IF 22(DEC) SECTOR FMT
PT: .WORD 0 ;DATA PATTERN SELECT WORD
CS: .WORD 0 ;CONTROL SWITCH WORD
ST: .WORD 0 ;NUMBER OF UNIT STALLS

:DEFAULT OPERATING PARAMETER VALUES

3817
3818
3819
3820 005706
3821 005706 000000
3822 005710 000000
3823 005712 000000
3824 005714 000002
3825 005716 000000
3826 005720 000023
3827 005722 000000
3828 005724 000025
3829 005726 000000
3830 005730 000000
3831 005732 000000

PRDFLT: .WORD 0 ;FC DEFAULT
.WORD 0 ;LC DEFAULT
.WORD 0 ;FT DEFAULT
.WORD 2 ;LT DEFAULT
.WORD 0 ;SO DEFAULT
.WORD 23 ;S1 DEFAULT
.WORD 25 ;S2 DEFAULT
.WORD 0 ;S3 DEFAULT
.WORD 0 ;PT DEFAULT
.WORD 0 ;CS DEFAULT
.WORD 0 ;ST DEFAULT

:OPERATING PARAMETER VALUE LOW AND HIGH LIMITS

3832
3833
3834
3835
3836 005734
3837 005734 000000
3838 005736 000000
3839 005740 000000
3840 005742 000000
3841 005744 000000
3842 005746 000002
3843 005750 000000
3844 005752 000002
3845 005754 000000
3846 005756 000023
3847 005760 000000
3848 005762 000023
3849 005764 000000
3850 005766 000025
3851 005770 000000
3852 005772 000025
3853 005774 000000
3854 005776 177777
3855 006000 000000
3856 006002 000062
3857 006004 000000
3858 006006 177777

PRMLIM: .WORD 0 ;FC LIMITS
.WORD 0 ;LC LIMITS
.WORD 0 ;FT LIMITS
.WORD 2 ;LT LIMITS
.WORD 0 ;SO LIMITS
.WORD 23 ;S1 LIMITS
.WORD 23 ;S2 LIMITS
.WORD 25 ;S3 LIMITS
.WORD 0 ;PT LIMITS
.WORD 177777 ;CS LIMITS
.WORD 0 ;ST LIMITS
.WORD 000062
.WORD 177777

:ASCII PARAMETER MNEMONICS

3859
3860
3861
3862
3863 006010
3864 006010 041506
3865 006012 041514

PRMNEM: .ASCII /FC/
.ASCII /LC/

3866	006014	052106	.ASCII	/FT/
3867	006016	052114	.ASCII	/LT/
3868	006020	030123	.ASCII	/SQ/
3869	006022	030523	.ASCII	/S1/
3870	006024	031123	.ASCII	/S2/
3871	006026	031523	.ASCII	/S3/
3872	006030	052120	.ASCII	/PT/
3873	006032	051503	.ASCII	/CS/
3874	006034	052123	.ASCII	/ST/

3875
3876
3877
3878
3879
3880
3881
3882
3883
3884
3885
3886
3887
3888
3889
3890
3891
3892
3893
3894
3895
3896
3897
3898
3899
3900

```

;DATA PATTERN 00
:
PAT00: HI-LO FREQ. MIX

```

006036	177777	177777
006036	177777	177777
006040	177777	177777
006042	177777	177777
006044	052525	052525
006046	052525	052525
006050	052525	052525
006052	177777	177777
006054	177777	177777
006056	052525	052525
006060	052525	052525
006062	177777	177777
006064	052525	052525
006066	177252	177252
006070	177252	177252
006072	172765	172765
006074	172765	172765

3901
3902
3903
3904
3905
3906
3907
3908
3909
3910
3911
3912
3913
3914
3915
3916
3917
3918
3919
3920
3921

```

;DATA PATTERN 01
:
PAT01: HI FREQ. PHASE MIX

```

006076	000000	000000
006076	000000	000000
006100	000000	000000
006102	000000	000000
006104	177777	177777
006106	177777	177777
006110	177777	177777
006112	000000	000000
006114	000000	000000
006116	177777	177777
006120	177777	177777
006122	000000	000000
006124	177777	177777
006126	000000	000000
006130	177777	177777
006132	000000	000000
006134	177777	177777

3922		
3923		
3924	006136	
3925	006136	052525
3926	006140	052525
3927	006142	052525
3928	006144	125252
3929	006146	125252
3930	006150	125252
3931	006152	052525
3932	006154	052525
3933	006156	125252
3934	006160	125252
3935	006162	052525
3936	006164	125252
3937	006166	052525
3938	006170	125252
3939	006172	052525
3940	006174	125252
3941		
3942		
3943		
3944		
3945		
3946	006176	
3947	006176	133333
3948	006200	066666
3949	006202	155555
3950	006204	155555
3951	006206	133333
3952	006210	066666
3953	006212	066666
3954	006214	155555
3955	006216	155555
3956	006220	133333
3957	006222	133333
3958	006224	133333
3959	006226	133333
3960	006230	133333
3961	006232	133333
3962	006234	133333
3963		
3964		
3965		
3966		
3967		
3968	006236	
3969	006236	121105
3970	006240	150442
3971	006242	064221
3972	006244	132110
3973	006246	055044
3974	006250	026422
3975	006252	013211
3976	006254	105504
3977	006256	042642

;DATA PATTERN 02
LO FREQ. PHASE MIX

PAT02:
052525
052525
052525
125252
125252
125252
052525
052525
125252
125252
052525
125252
052525
125252
052525
125252
052525
125252

;DATA PATTERN 03
MAX. PRECOMP. PHASE MIX

PAT03:
133333
066666
155555
155555
133333
066666
066666
155555
155555
133333
133333
133333
133333
133333
133333
133333
133333

;DATA PATTERN 04
ROTATING BOUNDARY PULSE PRECOMP.

PAT04:
121105
150442
064221
132110
055044
026422
013211
105504
042642

3978	006260	021321	021321
3979	006262	110550	110550
3980	006264	044264	044264
3981	006266	022132	022132
3982	006270	011055	011055
3983	006272	104426	104426
3984	006274	042213	042213

3985
3986
3987

;DATA PATTERN 05
; ROTATING CELL PULSE PRECOMP.

3988			
3989			
3990	006276		
3991	006276	026455	026455
3992	006300	113226	113226
3993	006302	045513	045513
3994	006304	122645	122645
3995	006306	151322	151322
3996	006310	064551	064551
3997	006312	132264	132264
3998	006314	055132	055132
3999	006316	026455	026455
4000	006320	113226	113226
4001	006322	045513	045513
4002	006324	122645	122645
4003	006326	151322	151322
4004	006330	064551	064551
4005	006332	132264	132264
4006	006334	055132	055132

4007
4008
4009
4010

;DATA PATTERN 06
; ALL ZEROS

4011	006336		
4012	006336	000000	000000
4013	006340	000000	000000
4014	006342	000000	000000
4015	006344	000000	000000
4016	006346	000000	000000
4017	006350	000000	000000
4018	006352	000000	000000
4019	006354	000000	000000
4020	006356	000000	000000
4021	006360	000000	000000
4022	006362	000000	000000
4023	006364	000000	000000
4024	006366	000000	000000
4025	006370	000000	000000
4026	006372	000000	000000
4027	006374	000000	000000

4028
4029
4030

;DATA PATTERN 07
; ALL ONES

4031
4032
4033 006376

4034	006376	177777	177777
4035	006400	177777	177777
4036	006402	177777	177777
4037	006404	177777	177777
4038	006406	177777	177777
4039	006410	177777	177777
4040	006412	177777	177777
4041	006414	177777	177777
4042	006416	177777	177777
4043	006420	177777	177777
4044	006422	177777	177777
4045	006424	177777	177777
4046	006426	177777	177777
4047	006430	177777	177777
4048	006432	177777	177777
4049	006434	177777	177777

;DATA PATTERN 08
SHIFTED 1 IN FIELD OF ZEROS

4054	006436		
4055	006436	000001	000001
4056	006440	000002	000002
4057	006442	000004	000004
4058	006444	000010	000010
4059	006446	000020	000020
4060	006450	000040	000040
4061	006452	000100	000100
4062	006454	000200	000200
4063	006456	000400	000400
4064	006460	001000	001000
4065	006462	002000	002000
4066	006464	004000	004000
4067	006466	010000	010000
4068	006470	020000	020000
4069	006472	040000	040000
4070	006474	100000	100000

;DATA PATTERN 09
SHIFTED 0 IN FIELD OF ONES

4076	006476		
4077	006476	177776	177776
4078	006500	177775	177775
4079	006502	177773	177773
4080	006504	177767	177767
4081	006506	177757	177757
4082	006510	177737	177737
4083	006512	177677	177677
4084	006514	177577	177577
4085	006516	177377	177377
4086	006520	176777	176777
4087	006522	175777	175777
4088	006524	173777	173777
4089	006526	167777	167777

4090	006530	157777	157777
4091	006532	137777	137777
4092	006534	077777	077777

4093
4094
4095
4096
4097

;DATA PATTERN 10
ALTERNATING 0-1

4098	006536		
4099	006536	052525	052525
4100	006540	052525	052525
4101	006542	052525	052525
4102	006544	052525	052525
4103	006546	052525	052525
4104	006550	052525	052525
4105	006552	052525	052525
4106	006554	052525	052525
4107	006556	052525	052525
4108	006560	052525	052525
4109	006562	052525	052525
4110	006564	052525	052525
4111	006566	052525	052525
4112	006570	052525	052525
4113	006572	052525	052525
4114	006574	052525	052525

4115
4116
4117
4118
4119

;DATA PATTERN 11
ALTERNATING 1-0

4120	006576		
4121	006576	125252	125252
4122	006600	125252	125252
4123	006602	125252	125252
4124	006604	125252	125252
4125	006606	125252	125252
4126	006610	125252	125252
4127	006612	125252	125252
4128	006614	125252	125252
4129	006616	125252	125252
4130	006620	125252	125252
4131	006622	125252	125252
4132	006624	125252	125252
4133	006626	125252	125252
4134	006630	125252	125252
4135	006632	125252	125252
4136	006634	125252	125252

4137
4138
4139
4140
4141

;DATA PATTERN 12
SHIFTING ZEROS AND ONES

4142	006636		
4143	006636	000001	000001
4144	006640	000003	000003
4145	006642	000007	000007


```

4202 006774 000000 .WORD
4203
4204
4205 .USER-DEFINED DATA PATTERN 15
4206 PAT15:
4207 006776 072307 072307 :WORD 00
4208 007000 135143 135143 :WORD 01
4209 007002 156461 156461 :WORD 02
4210 007004 167230 167230 :WORD 03
4211 007006 073514 073514 :WORD 04
4212 007010 035646 035646 :WORD 05
4213 007012 016723 016723 :WORD 06
4214 007014 107351 107351 :WORD 07
4215 007016 143564 143564 :WORD 10
4216 007020 061672 061672 :WORD 11
4217 007022 030735 030735 :WORD 12
4218 007024 114356 114356 :WORD 13
4219 007026 046167 046167 :WORD 14
4220 007030 123073 123073 :WORD 15
4221 007032 151453 151453 :WORD 16
4222 007034 164616 164616 :WORD 17
4223
4224
4225

```

```

4226 057467 MINLO1=1D24375 :LO BITS OF SPEC'D MIN ROT. LATENCY
4227 000000 MINHI1=0 :HI BITS OF SPEC'D MIN ROT. LATENCY
4228 062031 MAXLO1=1D25625 :LO BITS OF SPEC'D MAX ROT. LATENCY
4229 000000 MAXHI1=0 :HI BITS OF SPEC'D MAX ROT. LATENCY
4230 017500 MAXLO2=1D8000 :LO BITS OF SPEC'D MAX 1 CYL SEEK TIME
4231 000000 MAXHI2=0 :HI BITS OF SPEC'D MAX 1 CYL SEEK TIME
4232 112160 MAXLO3=1D38000 :LO BITS OF SPEC'D MAX AVG SEEK TIME
4233 000000 MAXHI3=0 :HI BITS OF SPEC'D MAX AVG SEEK TIME
4234 022370 MAXLO4=1D9464 :LO BITS OF SPEC'D MAX 410 CYL SEEK TIME
4235 000001 MAXHI4=1 :HI BITS OF SPEC'D MAX 410 CYL SEEK TIME
4236 002734 RNDSHI=1D1500 :SHORT RANDOM SEEKS = 1500(10)
4237 016514 RNDLNG=1D7500 :LONG RANDOM SEEKS = 7500(10)
4238 000002 LSTRK=2 :LAST TRACK = 2
4239 000365 ALNCYL=365 :ALIGNMENT CYLINDER =245(10)
4240 000002 BSERR=BIT1 :BSE ERROR
4241 000004 HVRCER=BIT2 :HVRC ERROR
4242 000010 OPIERR=BIT3 :OPI ERROR
4243 000020 DCKERR=BIT4 :DATA CHECK ERROR
4244 000040 ECCNC=BIT5 :ECC NON-CORRECTABLE
4245 000100 WCERR=BIT6 :WRITE CHECK ERROR
4246 000200 ABORT=BIT7 :ABORT
4247 000400 LEV2ER=BIT8 :LEVEL TWO ERROR
4248 001000 BADSEC=BIT9 :BAD SECTOR FLAG
4249 002000 TWOTOS=BIT10 :TWO TIME OUTS
4250 004000 RCLREQ=BIT11 :RECALIBRATE REQUIRED
4251 010000 DRNAVL=BIT12 :DRIVE NOT RELSD BY OTHER PORT
4252 100000 ANYDER=BIT15 :ANY ERROR DETECTED FLAG
4253

```

```

4254 007036 005015 055103 033122 DZR6N: .ASCIZ <15><12>/CZR6ND0/
4255 007044 042116 000060
4256 007050 026440 051040 033113 SUBVER: .ASCIZ & - RK611/RK06-RK07 SUBSYSTEM VERIFICATION : PART &
4257 007056 030461 051057 030113

```

4258	007064	026466	045522	033460
4259	007072	051440	041125	054523
4260	007100	052123	046505	053040
4261	007106	051105	043111	041511
4262	007114	052101	047511	020116
4263	007122	020072	040520	052122
4264	007130	000040		
4265	007132	006461	000012	
4266	007136	006462	000012	
4267	007142	005015	046012	051501
4268	007150	020124	044120	051531
4269	007156	046440	046505	040440
4270	007164	051104	036440	000040
4271	007172	053117	051105	040514
4272	007200	020131	047514	042101
4273	007206	051105	037440	024040
4274	007214	020131	051117	047040
4275	007222	020051	020052	000
4276	007227	122	046505	053117
4277	007234	020105	054130	050104
4278	007242	050040	041501	020113
4279	007250	051106	046517	042040
4280	007256	044522	042526	020054
4281	007264	047111	052123	046101
4282	007272	020114	041523	040522
4283	007300	041524	020110	005015
4284	007306	377		
4285	007307	120	041501	026113
4286	007314	040440	042116	044040
4287	007322	052111	041440	047117
4288	007330	044524	052516	020105
4289	007336	047524	050040	047522
4290	007344	042503	042105	000056
4291	007352	005015	040520	040522
4292	007360	020115	047111	052520
4293	007366	020124	047515	042504
4294	007374	005015	000012	
4295	007400	045522	033060	030055
4296	007406	020067	052502	020123
4297	007414	042101	020122	020075
4298	007422	000		
4299	007423	122	030113	026466
4300	007430	033460	053040	041505
4301	007436	040440	051104	036440
4302	007444	000040		
4303	007446	045522	033060	030055
4304	007454	020067	051120	047511
4305	007462	020122	000075	
4306	007466	053523	020122	020075
4307	007474	000		
4308	007475	040	047040	053505
4309	007502	036440	000040	
4310	007506	005015	051104	024126
4311	007514	024523	036440	000040
4312	007522	051104	053111	020105
4313	007530	020040	000	

PART1: .ASCIZ /1/<15><12>
PART2: .ASCIZ /2/<15><12>
LSTMEM: .ASCIZ <15><12><12>/LAST PHYS MEM ADR = /

OVLODR: .ASCIZ /OVERLAY LOADER ? (Y OR N) * /

XXDPME: .ASCII /REMOVE XXDP PACK FROM DRIVE, INSTALL SCRATCH /<15><12><377>

.ASCIZ /PACK, AND HIT CONTINUE TO PROCEED./

PRMINP: .ASCIZ <15><12>/PARAM INPUT MODE/<15><12><12>

RKBADR: .ASCIZ /RK06-07 BUS ADR = /

RKVADR: .ASCIZ /RK06-07 VEC ADR = /

RKPRTY: .ASCIZ /RK06-07 PRIOR = /

SWRMSG: .ASCIZ /SWR = /

NEWMSG: .ASCIZ / NEW = /

DRVSEQ: .ASCIZ <15><12>/DRV(S) = /

BADDRV: .ASCIZ /DRIVE /

4314	007533	116	047117	042455	NXDRIV: .ASCIZ /NON-EXIST/<15><12>
4315	007540	044530	052123	005015	
4316	007546	000			
4317	007547	116	052117	051040	NTREDY: .ASCIZ /NOT RDY/<15><12>
4318	007554	054504	005015	000	
4319	007561	127	052122	046055	WRTLOK: .ASCIZ /WRT-LOCK/<15><12>
4320	007566	041517	006513	000012	
4321	007574	047514	042101	042105	ALNPAK: .ASCIZ /LOADED WITH ALIGN PACK/<15><12>
4322	007602	053440	052111	020110	
4323	007610	046101	043511	020116	
4324	007616	040520	045503	005015	
4325	007624	000			
4326	007625	015	005012	025052	NODRTS: .ASCII <15><12><12>/** NO DRVS TO TEST/<15><12>
4327	007632	047040	020117	051104	
4328	007640	051526	052040	020117	
4329	007646	042524	052123	005015	
4330	007654	051120	051505	020123	CNTRDY: .ASCIZ /PRESS "CONT" WHEN RDY/<15><12>
4331	007662	041442	047117	021124	
4332	007670	053440	042510	020116	
4333	007676	042122	006531	000012	
4334	007704	040510	052114	051040	HLTRQD: .ASCIZ /HALT REQ/<15><12>
4335	007712	050505	005015	000	
4336	007717	015	005012	047524	ALDRVS: .ASCIZ <15><12><12>/TO TEST ALL DRVS TYPE "A" <CR>, ELSE <CR>/<15><12>/** /
4337	007724	052040	051505	020124	
4338	007732	046101	020114	051104	
4339	007740	051526	052040	050131	
4340	007746	020105	040442	020042	
4341	007754	041474	037122	020054	
4342	007762	046105	042523	036040	
4343	007770	051103	006476	025012	
4344	007776	000040			
4345	010000	005015	020114	020075	TSTMDS: .ASCII <15><12>/L = LIST TESTS/<15><12>
4346	010006	044514	052123	052040	
4347	010014	051505	051524	005015	
4348	010022	020103	020075	044103	.ASCII /C = CHANGE TESTS/<15><12>
4349	010030	047101	042507	052040	
4350	010036	051505	051524	005015	
4351	010044	020111	020075	047111	.ASCIZ /I = INPUT PARAMS, RUN TESTS/<15><12>
4352	010052	052520	020124	040520	
4353	010060	040522	051515	020054	
4354	010066	052522	020116	042524	
4355	010074	052123	006523	000012	
4356	010102	005015	047105	042524	ENTLCI: .ASCIZ <15><12>/ENTER L,C, OR I/<15><12>/** /
4357	010110	020122	026114	026103	
4358	010116	047440	020122	006511	
4359	010124	025012	000040		
4360	010130	047524	042040	043105	DFTEST: .ASCIZ /TO DEFAULT TESTS TYPE D <CR>, ELSE <CR>/<15><12>/** /
4361	010136	052501	052114	052040	
4362	010144	051505	051524	052040	
4363	010152	050131	020105	020104	
4364	010160	041474	037122	020054	
4365	010166	046105	042523	036040	
4366	010174	051103	006476	025012	
4367	010202	000040			
4368	010204	005015	042524	052123	TLSTHD: .ASCIZ <15><12>/TEST ITERATIONS/<15><12>
4369	010212	020040	020040	044440	

4370	010220	042524	040522	044524	
4371	010226	047117	006523	000012	
4372	010234	005015	020124	020075	EXPLAN: .ASCII <15><12>/T = TYPE PARAM LIST/<15><12>
4373	010242	054524	042520	050040	
4374	010250	051101	046501	046040	
4375	010256	051511	006524	012	
4376	010263	117	036440	047440	.ASCII /O = OPEN PARAM LIST/<15><12>
4377	010270	042520	020116	040520	
4378	010276	040522	020115	044514	
4379	010304	052123	005015		
4380	010310	020123	020075	042523	.ASCII /S = SET INDIVIDUAL PARAM/<15><12>
4381	010316	020124	047111	044504	
4382	010324	044526	052504	046101	
4383	010332	050040	051101	046501	
4384	010340	005015			
4385	010342	020122	020075	052522	.ASCIZ /R = RUN TESTS/<15><12>
4386	010350	020116	042524	052123	
4387	010356	006523	000012		
4388	010362	005015	047105	042524	PARMDE: .ASCIZ <15><12>/ENTER T,O,S, OR R/<15><12>
4389	010370	020122	026124	026117	
4390	010376	026123	047440	020122	
4391	010404	006522	000012		
4392	010410	005015	020052	052504	DUACES: .ASCIZ <15><12> /* DUAL-ACCESS DATA TEST */<15><12>
4393	010416	046101	040455	041503	
4394	010424	051505	020123	040504	
4395	010432	040524	052040	051505	
4396	010440	020124	006452	000012	
4397	010446	040515	020130	047527	MAWRDC: .ASCIZ /MAX WORD COUNT = /
4398	010454	042122	041440	052517	
4399	010462	052116	036440	000040	
4400	010470	025052	020040	030123	SECNL1: .ASCII /** S0>S1/
4401	010476	051476	061		
4402	010501	040	047516	020124	NOTALD: .ASCIZ / NOT ALLOWED/<15><12>
4403	010506	046101	047514	042527	
4404	010514	006504	000012		
4405	010520	025052	020040	031123	SECNL2: .ASCIZ /** S2>S3/
4406	010526	051476	000063		
4407	010532	025052	020040	052106	TRKNLW: .ASCIZ /** FT>LT/
4408	010540	046076	000124		
4409	010544	025052	020040	041527	WC2BIG: .ASCIZ /** WC OR MA TOO LARGE/<15><12>
4410	010552	047440	020122	040515	
4411	010560	052040	047517	046040	
4412	010566	051101	042507	005015	
4413	010574	000			
4414	010575	124	020117	042504	DFQUES: .ASCIZ /TO DEFAULT ALL PARAMS, TYPE D <CR>, ELSE <CR> /* /
4415	010602	040506	046125	020124	
4416	010610	046101	020114	040520	
4417	010616	040522	051515	020054	
4418	010624	054524	042520	042040	
4419	010632	036040	051103	026076	
4420	010640	042440	051514	020105	
4421	010646	041474	037122	005015	
4422	010654	020052	000		
4423	010657	015	052412	042523	PFIFTN: .ASCIZ <15><12>/USER-DEF PATT 15 :/<15><12>
4424	010664	026522	042504	020106	
4425	010672	040520	052124	030440	

4426	010700	020065	006472	000012	
4427	010706	005015	047515	020104	SELP15: .ASCIZ <15><12>/MOD PATT 15 :/<15><12>
4428	010714	040520	052124	030440	
4429	010722	020065	006472	000012	
4430	010730	047524	046440	042117	MDFY15: .ASCIZ /TO MOD PATT 15, TYPE M <CR>, ELSE <CR>/<15><12> /* /
4431	010736	050040	052101	020124	
4432	010744	032461	020054	054524	
4433	010752	042520	046440	036040	
4434	010760	051103	026076	042440	
4435	010766	051514	020105	041474	
4436	010774	037122	005015	020052	
4437	011002	000			
4438	011003	015	042412	052116	ENTPAS: .ASCIZ <15><12>/ENTER NO. OF PASSES (1-77777) :/<15><12> /* /
4439	011010	051105	047040	027117	
4440	011016	047440	020106	040520	
4441	011024	051523	051505	024040	
4442	011032	026461	033467	033467	
4443	011040	024467	035040	005015	
4444	011046	020052	000		
4445	011051	015	025012	020052	DROPDR: .ASCIZ <15><12>/** DROPPING DRV - 20 ERRORS/<15><12>
4446	011056	042040	047522	050120	
4447	011064	047111	020107	051104	
4448	011072	020126	020055	030062	
4449	011100	042440	051122	051117	
4450	011106	006523	000012		
4451	011112	005015	052012	051505	TSTDRN: .ASCII <15><12><12>/TESTING DRV /
4452	011120	044524	043516	042040	
4453	011126	053122	040		
4454	011131	040	005015	000	DRVNO: .ASCIZ /<15><12>
4455	011135	104	053122	000040	DRIV: .ASCIZ /DRV /
4456	011142	040503	052122	020056	CART: .ASCIZ /CART. /
4457	011150	000			
4458	011151	123	051105	020056	SERNM: .ASCIZ /SER. NO. /
4459	011156	047516	020056	000040	
4460	011164	005015	040506	052103	FACTBS: .ASCIZ <15><12>/FACTORY /
4461	011172	051117	020131	000	
4462	011177	012	047523	052106	SOFTBS: .ASCII <12>/SOFTWARE /
4463	011204	040527	042522	040	
4464	011211	102	042101	051440	BDSECT: .ASCIZ /BAD SECTORS :/<15><12>
4465	011216	041505	047524	051522	
4466	011224	035040	005015	000	
4467	011231	040	047040	047117	NOFALS: .ASCIZ / NONE/
4468	011236	000105			
4469					
4470					
4471					
4472	011240	005015	047412	043106	:MESSAGES USED IN OFFSET-TO-FAILURE TEST
4473	011246	042523	026524	047524	OFSHED: .ASCII <15><12><12>/OFFSET-TO-FAILURE MEAS :/<15><12><12>
4474	011254	043055	044501	052514	
4475	011262	042522	046440	040505	
4476	011270	020123	006472	005012	
4477	011276	051124	041501	020113	.ASCII /TRACK CYLN SECT +OFST -OFST/<15><12>
4478	011304	041440	046131	020116	
4479	011312	051440	041505	020124	
4480	011320	025440	043117	052123	
4481	011326	020040	047455	051506	

```

4482 011334 006524 012
4483 011337 011 020011 020040 .ASCIZ <011><011>/ (UIN) (UIN)/<15><12>
4484 011344 052450 047111 020051
4485 011352 024040 044525 024516
4486 011360 005015 000
4487
4488
4489 011363 000 UNLOD: .BYTE 0 ;DRIVE UNLOADED INDICATOR
4490 011364 000 VERIFY: .BYTE 0 ;VERIFY MODE FLAG
4491 011365 015 005012 025052 IDENT: .ASCIZ <15><12><12>/*** RK06-07 HEAD ALIGN AID ***/<15><12>
4492 011372 020052 045522 033060
4493 011400 030055 020067 042510
4494 011406 042101 040440 044514
4495 011414 047107 040440 042111
4496 011422 025040 025052 005015
4497 011430 000
4498 011431 106 051117 044040 FORHLP: .ASCIZ /FOR HELP TYPE H, ELSE <CR>/<15><12>
4499 011436 046105 020120 054524
4500 011444 042520 044040 020054
4501 011452 046105 042523 036040
4502 011460 051103 006476 000012
4503 011466 046412 047101 040525 TYPMOD: .ASCIZ <12>/MANUAL OR AUTO MODE (M OR A)?/<15><12>
4504 011474 020114 051117 040440
4505 011502 052125 020117 047515
4506 011510 042504 024040 020115
4507 011516 051117 040440 037451
4508 011524 005015 000
4509 011527 012 025012 046440 TYPMAN: .ASCIZ <12><12>/* MANUAL SELECT MODE */<15><12>
4510 011534 047101 040525 020114
4511 011542 042523 042514 052103
4512 011550 046440 042117 020105
4513 011556 006452 000012
4514 011562 042412 052116 051105 ENTDRV: .ASCIZ <12>/ENTER DRV NO. (0-7):/<15><12>
4515 011570 042040 053122 047040
4516 011576 027117 024040 026460
4517 011604 024467 006472 000012
4518 011612 025052 020040 051104 NOTRDY: .ASCII /** DRV /
4519 011620 020126
4520 011622 020040 047516 020124 DRNRDY: .ASCII / NOT RDY ! START DRV IF NECESSARY./<15><12>
4521 011630 042122 020131 020041
4522 011636 051440 040524 052122
4523 011644 042040 053122 044440
4524 011652 020106 042516 042503
4525 011660 051523 051101 027131
4526 011666 005015
4527 011670 020040 020040 044127 .ASCIZ / WHEN DRV IS RDY, PRESS "CONT" ON CPU./<15><12>
4528 011676 047105 042040 053122
4529 011704 044440 020123 042122
4530 011712 026131 050040 042522
4531 011720 051523 021040 047503
4532 011726 052116 020042 047117
4533 011734 041440 052520 006456
4534 011742 000012
4535 011744 025052 020040 051104 NONEXD: .ASCII /** DRV /
4536 011752 020126
4537 011754 020040 047516 026516 DRVNED: .ASCIZ / NON-EXIST OR OFF-LINE ! PRESS "CONT" TO RESTART./<15><12>

```

4538 011762 054105 051511 020124
 4539 011770 051117 047440 043106
 4540 011776 046055 047111 020105
 4541 012004 020041 051120 051505
 4542 012012 020123 041442 047117
 4543 012020 021124 052040 020117
 4544 012026 042522 052123 051101
 4545 012034 027124 005015 000
 4546 012041 052 020052 042040
 4547 012046 053122 040
 4548 012051 040 047040 052117
 4549 012056 053440 052122 046055
 4550 012064 041517 020113 020041
 4551 012072 046120 040505 042523
 4552 012100 051440 052105 053440
 4553 012106 052122 046055 041517
 4554 012114 051440 020127 006456
 4555 012122 012
 4556 012123 040 020040 052040
 4557 012130 042510 020116 051120
 4558 012136 051505 020123 041442
 4559 012144 047117 021124 047440
 4560 012152 020116 050103 027125
 4561 012160 005015 000
 4562 012163 052 020052 046440
 4563 012170 046125 020124 051104
 4564 012176 020126 052501 047524
 4565 012204 051455 046105 041505
 4566 012212 042524 020104 020041
 4567 012220 051120 051505 020123
 4568 012226 041447 047117 023524
 4569 012234 052040 020117 042522
 4570 012242 052123 051101 027124
 4571 012250 005015 000
 4572 012253 012 046101 043511
 4573 012260 026116 042526 044522
 4574 012266 054506 020054 051117
 4575 012274 042440 042530 041522
 4576 012302 051511 020105 04C450
 4577 012310 053054 020054 051117
 4578 012316 042440 020051 006477
 4579 012324 000012
 4580 012326 005012 020052 040522
 4581 012334 042116 046517 051440
 4582 012342 042505 020113 054105
 4583 012350 051105 044503 042523
 4584 012356 020123 047111 050040
 4585 012364 047522 051107 051505
 4586 012372 020123
 4587 012374 047117 042040 044522
 4588 012402 042526 040
 4589 012405 040 025040 005015
 4590 012412 000
 4591 012413 012 025012 046440
 4592 012420 047101 040525 020114
 4593 012426 042523 042514 052103

NOTLOK: .ASCII /** DRV /
 NODRLK: .ASCII / NOT WRT-LOCK ! PLEASE SET WRT-LOC SW ./<15><12>
 .ASCIZ / THEN PRESS "CONT" ON CPU./<15><12>
 MULSEL: .ASCIZ /** MULT DRV AUTO-SELECTED ! PRESS 'CONT' TO RESTART./<15><12>
 ENTMOD: .ASCIZ <12>/ALIGN,VERIFY, OR EXERCISE (A,V, OR E) ?/<15><12>
 MANEXR: .ASCII <12><12>/** RANDOM SEEK EXERCISES IN PROGRESS /
 .ASCII /ON DRIVE /
 DRIEXR: .ASCIZ / */<15><12>
 MANALN: .ASCIZ <12><12>/** MANUAL SELECT ALIGNMENT */<15><12>

4594	012434	040440	044514	047107	
4595	012442	042515	052116	025040	
4596	012450	005015	000		
4597	012453	012	025012	046440	MANVRF: .ASCIZ <12><12> /* MANUAL SELECT VERIFY */ <15><12>
4598	012460	047101	040525	020114	
4599	012466	042523	042514	052103	
4600	012474	053040	051105	043111	
4601	012502	020131	006452	000012	
4602	012510	042510	042101	020123	HEDPOS: .ASCIZ /HEADS AT CYL 365 (OCT) (760 RK07) <15><12>
4603	012516	052101	041440	046131	
4604	012524	031440	032466	024040	
4605	012532	041517	024524	024040	
4606	012540	033067	020060	045522	
4607	012546	033460	006451	000012	
4608	012554	047105	042524	020122	DTYMSG: .ASCIZ /ENTER DRIVE TYPE /
4609	012562	051104	053111	020105	
4610	012570	054524	042520	000040	
4611	012576	020040	020040	035040	SOR7: .ASCIZ / : <6> OR <7> /
4612	012604	036040	037066	047440	
4613	012612	020122	033474	000076	
4614	012620	042412	052116	051105	ENTHED: .ASCIZ <12> /ENTER HEAD NO. (0-2) : <15><12>
4615	012626	044040	040505	020104	
4616	012634	047516	020056	030050	
4617	012642	031055	035051	005015	
4618	012650	000			
4619	012651	124	050131	020105	RWNRDY: .ASCIZ /TYPE <R> WHEN RDY : <15><12>
4620	012656	051074	020076	044127	
4621	012664	047105	051040	054504	
4622	012672	035040	005015	000	
4623	012677	110	040505	020104	HEDSEL: .ASCII /HEAD /
4624	012704	020040	042523	042514	HEADNO: .ASCIZ / SELECTED <15><12>
4625	012712	052103	042105	005015	
4626	012720	000			
4627	012721	012	025012	040440	TYPAUT: .ASCIZ <12><12> /* AUTO SELECT MODE */ <15><12>
4628	012726	052125	020117	042523	
4629	012734	042514	052103	046440	
4630	012742	042117	020105	006452	
4631	012750	000012			
4632	012752	005012	020052	052501	AUTALN: .ASCIZ <12><12> /* AUTO SELECT ALIGNMENT */ <15><12>
4633	012760	047524	051440	046105	
4634	012766	041505	020124	046101	
4635	012774	043511	046516	047105	
4636	013002	020124	006452	000012	
4637	013010	005012	020052	052501	AUTVRF: .ASCIZ <12><12> /* AUTO SELECT VERIFY */ <15><12>
4638	013016	047524	051440	046105	
4639	013024	041505	020124	042526	
4640	013032	044522	054506	025040	
4641	013040	005015	000		
4642	013043	012	051104	020126	DRISEL: .ASCII <12> /DRV /
4643	013050	020040	042523	042514	DRVSEL: .ASCIZ / SELECTED <15><12><12>
4644	013056	052103	042105	005015	
4645	013064	000012			
4646	013066	005012	020052	052501	AUTEXR: .ASCII <12><12> /* AUTO SELECT EXERCISES */ <15><12>
4647	013074	047524	051440	046105	
4648	013102	041505	020124	054105	
4649	013110	051105	044503	042523	

4650	013116	020123	006452	012			
4651	013123	012	044123	051117		.ASCIZ	<12>/SHORT OR LONG (S OR L) ?/<15><12>
4652	013130	020124	051117	046040			
4653	013136	047117	020107	051450			
4654	013144	047440	020122	024514			
4655	013152	037440	005015	000			
4656	013157	105	042530	041522	AUTOEX:	.ASCII	/EXERCISING DRV /
4657	013164	051511	047111	020107			
4658	013172	051104	020126				
4659	013176	006440	000012		AUTODR:	.ASCIZ	/ /<15><12>
4660							
4661	013202	025052	020040	040503	BAD632:	.ASCIZ	/** CANNOT READ BAD SECTOR TRACK!/<15><12>
4662	013210	047116	052117	051040			
4663	013216	040505	020104	040502			
4664	013224	020104	042523	052103			
4665	013232	051117	052040	040522			
4666	013240	045503	006441	000012			
4667	013246	041536	005015	000	CNTRLC:	.ASCIZ	/↑C/<15><12>
4668	013253	136	006532	000012	CNTRLZ:	.ASCIZ	/↑Z/<15><12>
4669	013260	051136	005015	000	CNTRLR:	.ASCIZ	/↑R/<15><12>
4670	013265	136	006525	000012	CNTRLU:	.ASCIZ	/↑U/<15><12>
4671	013272	043536	005015	000	CNTRLG:	.ASCIZ	/↑G/<15><12>
4672	013277	015	005012	000	CR2LF:	.ASCIZ	<15><12><12>
4673	013303	134	000		BKSLSH:	.ASCIZ	/\
4674	013305	054	000		COMMA:	.ASCIZ	/,
4675	013307	040	040		SPACE6:	.ASCII	/ /
4676	013311	040			SPACE4:	.ASCII	/ /
4677	013312	040			SPACE3:	.ASCII	/ /
4678	013313	040			SPACE2:	.ASCII	/ /
4679	013314	000040			SPACE1:	.ASCIZ	/ /
4680							
4681	013316	020040	000075		PRMBUF:	.ASCIZ	/ = /
4682	013322	047527	042122	000040	WORDSP:	.ASCIZ	/WORD /
4683	013330	036440	000040		EQUALS:	.ASCIZ	/ = /
4684	013334	020052	000		PROMPT:	.ASCIZ	/* /
4685	013337	076	000040		PRMPSP:	.ASCIZ	/> /
4686							
4687						.EVEN	
4688							
4689							
4690							
4691							
4692	013342	105037	003116		DFSTRT:	CLRB	MDFLAG ; SET FLAG FOR DEFAULT MODE
4693	013346	105037	003135			CLRB	DULACS ; CLEAR DUAL-ACCESS FLAG
4694	013352	105037	003126			CLRB	ERRCNT ; CLEAR ERROR COUNT FOR RESTARTS
4695	013356	022737	014434	000042		CMP	#DRVTST, @#42 ; SEE IF EOP RETURN ADRS = DRVTST
4696	013364	001003				BNE	4\$; BR IF NOT DRVTST
4697	013366	012737	017320	000042		MOV	#NEWPAS, @#42 ; SET RETURN ADRS = NEWPAS
4698	013374	000405			4\$:	BR	CMSTRT ; PROCEED
4699							
4700							
4701	013376	112737	000001	003116	PSTART:	MOVB	#1, MDFLAG ; SET FLAG FOR PARAMETER MODE
4702	013404	105037	003135			CLRB	DULACS ; CLEAR DUAL-ACCESS TEST FLAG
4703							
4704	013410	012737	000340	177776	CMSTRT:	MOV	#PR7, @#PS ; BLOCK ALL INTERRUPTS
4705					.SBTTL		INITIALIZE THE COMMON TAGS

```

4706      ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
4707      MOV      #SCMTAG,R6      ;;FIRST LOCATION TO BE CLEARED
4708      CLR      (R6)+          ;;CLEAR MEMORY LOCATION
4709      CMP      #SWR,R6      ;;DONE?
4710      BNE      -6            ;;LOOP BACK IF NO
4711      MOV      #STACK,SP      ;;SETUP THE STACK POINTER
4712      ;;INITIALIZE A FEW VECTORS
4713      MOV      #SSCOPE,@#IOTVEC  ;;IOT VECTOR FOR SCOPE ROUTINE
4714      MOV      #340,@#IOTVEC+2  ;;LEVEL 7
4715      MOV      #SEERROR,@#EMTVEC  ;;EMT VECTOR FOR ERROR ROUTINE
4716      MOV      #340,@#EMTVEC+2  ;;LEVEL 7
4717      MOV      #STRAP,@#TRAPVEC  ;;TRAP VECTOR FOR TRAP CALLS
4718      MOV      #340,@#TRAPVEC+2  ;;LEVEL 7
4719      MOV      #SPWRDN,@#PWRVEC  ;;POWER FAILURE VECTOR
4720      MOV      #340,@#PWRVEC+2  ;;LEVEL 7
4721      MOV      SENDCT,SEOPCT    ;;SETUP END-OF-PROGRAM COUNTER
4722      CLR      $TIMES          ;;INITIALIZE NUMBER OF ITERATIONS
4723      CLR      $ESCAPE        ;;CLEAR THE ESCAPE ON ERROR ADDRESS
4724      MOVB   #1,$SERMAX       ;;ALLOW ONE ERROR PER TEST
4725      MOV      #,$SLPADR      ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
4726      MOV      #,$SLPERR      ;;SETUP THE ERROR LOOP ADDRESS
4727      ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
4728      ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
4729      MOV      @#ERRVEC,-(SP)    ;;SAVE ERROR VECTOR
4730      MOV      #64$,@#ERRVEC    ;;SET UP ERROR VECTOR
4731      MOV      #DSWR,SWR        ;;SETUP FOR A HARDWARE SWICH REGISTER
4732      MOV      #DDISP,DISPLAY   ;;AND A HARDWARE DISPLAY REGISTER
4733      CMP      #-1,@SWR        ;;TRY TO REFERENCE HARDWARE SWR
4734      BNE      66$            ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
4735      AND     THE HARDWARE SWR IS NOT = -1
4736      BR      65$            ;;BRANCH IF NO TIMEOUT
4737      MOV      #65$,(SP)        ;;SET UP FOR TRAP RETURN
4738      RTI
4739      MOV      #SWREG,SWR      ;;POINT TO SOFTWARE SWR
4740      MOV      #DISPR$G,DISPLAY
4741      MOV      (SP)+,@#ERRVEC  ;;RESTORE ERROR VECTOR
4742
4743      CLR      $PASS           ;;CLEAR PASS COUNT
4744      BITB   #APTSIZE,$ENVM    ;;TEST USER SIZE UNDER APT
4745      BEQ    67$            ;;YES,USE NON-APT SWITCH
4746      MOV      #SSWREG,SWR    ;;NO,USE APT SWITCH REGISTER
4747      67$:
4748      CLR      AUTOFG         ;;CLEAR THE SPECIAL FLAG
4749      RESET
4750      MOV      #6,@#ERRVEC    ;;CLEAR THE UNIBUS
4751      CLR      @#ERRVEC+2     ;;SET TIME-OUT VECTOR
4752      MOV      #MPERHD,@#MEMVEC  ;;SET MEM PARITY TRAP VECTOR
4753      MOV      #PR7,@#MEMVEC+2  ;;SET TRAP PRIORITY = 7
4754      JSR    PC,ENBCSR        ;;ENABLE MEMORY PARITY CHECK
4755      MOVB   #100,$SERMAX     ;;SET MAX ERROR CNT TO 100 FOR $SCOPE
4756      CLRB   DRVER$          ;;CLEAR ERROR COUNT FOR CURRENT DRIVE
4757      MOVB   #1,HLPVOL        ;;SET HLP FILE OVLD INDICTR
4758      TYPE   ,DZR6N          ;;TYPE PROGRAM I.D. FOR PART 2
4759      TYPE   ,SUBVER
4760      TYPE   ,PART2
4761      TSTB  NOTYPE           ;;SEE IF OPERATOR NOTE SHOULD BE TYPED

```

```

4762 013766 001004          BNE      39$          ;BR IF NOT
4763 013770 104401 065660   TYPE     ,NOTMSG     ;TYPE OPERATOR NOTE
4764 013774 105237 003146   INCB    ,NOTYPE     ;SET FLAG FOR NEXT TIME
4765 014000 105737 003135   39$:    TSTB    DULACS     ;SEE IF DUAL-ACCESS DATA TEST
4766 014004 001402          BEQ      40$          ;BR IF NOT
4767 014006 104401 010410   TYPE     ,DUACES     ;TYPE "* DUAL-ACCESS DATA TEST *"
4768 014012 012737 030436 000060 40$:    MOV     ,#KBDHDL ,#TKVEC ;LOAD VECTOR FOR TTY KBD
4769 014020 012737 000200 000062   MOV     ,#PR4 ,#TKVEC+2 ;SET KBD PRIORITY = 4
4770 014026 013701 003040   MOV     ,RKVEC ,R1     ;ADDR. OF RK06 VECTOR STORAGE
4771 014032 012721 047304   MOV     ,#I. INTR, (R1)+ ;SET IT TO RK06 HANDLER
4772 014036 013711 003042   MOV     ,RKPRI, (R1)    ;SET RK06 PRIORITY
4773 014042 012737 031246 000250   MOV     ,#KTERAD, #MMVEC ;VECT FOR KT11 FAILURE
4774 014050 012737 000340 000252   MOV     ,#PR7, #MMVEC+2 ;SET PRIOR. = 7 FOR HNDLER
4775 014056 105037 003120   CLRB    ,TSTING      ;CLEAR "RUNNING TESTS" FLAG
4776 014062 012737 000000 177776   MOV     ,#PR0, #PS     ;ALLOW ALL INTERRUPTS AGAIN
4777 014070 012701 005224   MOV     ,#PRVCM, R1    ;ZERO OUT PREVIOUS COMMAND
4778 014074 012700 000006   MOV     ,#6, RO       ;SET COUNTER
4779 014100 005021          CLR     ,(R1)+        ;ZERO A WORD
4780 014102 005300          DEC     ,RO           ;
4781 014104 001375          BNE     ,42$         ;BR IF NOT DONE YET
4782 014106 005037 005502   CLR     ,STALLS      ;DON'T ALLOW STALLS YET
4783 014112 023727 000042 017320   CMP     ,#42, #NEWPAS ;SEE IF CHAIN MODE
4784 014120 101002          BHI     ,44$         ;BR IF YES
4785 014122 004737 031126   JSR    ,PC, GTSWRG   ;OPEN SOFTWARE SWR FOR MODIFICATION
4786 014126 012737 176543 054732 44$:    MOV     ,#176543, $HINUM ;INIT. PSEUDO-RANDOM NOS.
4787 014134 012737 123456 054734   MOV     ,#123456, $LONUM ;
4788 014142 004737 030630   JSR    ,PC, SIZMEM   ;SIZE MEMORY, FIX MA LIMIT IN PRMLIM
4789 014146 105737 003134   TSTB   ,XDPSVD       ;SEE IF XDP, PREVIOUSLY SAVED
4790 014152 001404          BEQ     ,9$          ;BR IF NOT
4791 014154 004737 032050   JSR    ,PC, GETXDP   ;RESTORE SAVED XDP
4792 014160 105037 003134   CLRB   ,XDPSVD       ;CLEAR THE FLAG
4793 014164 105737 003116   9$:    TSTB   ,MDFLAG      ;SEE IF DEFAULT MODE
4794 014170 001031          BNE     ,10$         ;BR IF NOT DEFAULT MODE
4795 014172 013700 001370   MOV     ,SVECT1, RO   ;GET APT RK06 VECTOR AND PRTY
4796 014176 013737 001374 003036   MOV     ,SBASE, RKBAS ;GET APT RK06 BASE ADDRESS
4797 014204 132737 000200 001341   BITB   ,#BIT7, $ENVM ;SEE IF NO SIZING
4798 014212 001005          BNE     ,18$         ;BR IF NO SIZING
4799 014214 012700 120210   MOV     ,SVECT1, RO   ;GET DEFAULT VECTOR AND PRIORITY
4800 014220 012737 177440 003036   MOV     ,SABASE, RKBAS ;GET DEFAULT BASE ADDRESS
4801 014226 110037 003040 18$:    MOVVB  ,RO, RKVEC     ;STORE VECTOR
4802 014232 105037 003041   CLRB   ,RKVEC+1     ;CLEAR HI BYTE
4803 014236 000300          SWAB   ,RO           ;GET PRTY INTO BITS 5-7
4804 014240 042700 177437   BIC    ,#177437, RO  ;CLEAR OTHER BITS
4805 014244 010037 003042   MOV     ,RO, RKPRI    ;STORE RK06 PRIORITY
4806 014250 000137 015120   JMP     ,ALLDRV      ;GO CHECK ALL DRIVES
4807
4808
4809
4810          ;BEGIN PARAMETER INPUT MODE
4811 014254 104401 007352 10$:    TYPE     ,PRMINP     ;TYPE "PARAMETER INPUT MODE"
4812
4813          ;OPEN RK06 UNIBUS ADDRESS FOR MODIFICATION
4814 014260 013746 003036   MOV     ,RKBAS, -(SP) ;PUT OLD VALUE ON STACK
4815 014264 104401 007400   TYPE     ,RKBADR     ;TYPE "RK06 BUS ADR ="
4816 014270 004737 031016   JSR    ,PC, GETPRM   ;TYPE OLD, GET NEW RKBAS VALUE
4817 014274 012637 003036   MOV     ,(SP)+, RKBAS ;STORE NEW VALUE

```



```

4818
4819 014300 013746 003040
4820 014304 104401 007423
4821 014310 004737 031016
4822 014314 012637 003040
4823
4824 014320 013746 003042
4825 014324 006316
4826 014326 006316
4827 014330 006316
4828 014332 000316
4829 014334 104401 007446
4830 014340 004737 031016
4831 014344 012600
4832 014346 020027 000004
4833 014352 002414
4834 014354 020027 000007
4835 014360 003011
4836 014362 000300
4837 014364 006200
4838 014366 006200
4839 014370 006200
4840 014372 010037 003042
4841 014376 104401 001315
4842 014402 000405
4843 014404 104401 005264
4844 014410 104401 001314
4845 014414 000741
4846

;OPEN RK06 VECTOR ADDRESS FOR MODIFICATION
MOV RKVEC, -(SP) ;PUT OLD VALUE ON STACK
TYPE RKVADR ;TYPE "RK06 VEC ADR = "
JSR PC, GETPRM ;TYPE OLD, GET NEW RKVEC VALUE
MOV (SP)+, RKVEC ;STORE NEW VALUE
;OPEN RK06 INTERRUPT HANDLER PRIORITY LEVEL FOR MODIFICATION
11$: MOV RKPRI, -(SP) ;GET OLD VALUE OF PRIORITY
ASL (SP) ;GET IT INTO BITS 0-2
ASL (SP)
ASL (SP)
SWAB (SP)
TYPE RKPRTY ;TYPE "RK06 PRIORITY = "
JSR PC, GETPRM ;TYPE OLD, GET NEW RKPRI VALUE
MOV (SP)+, RO
CMP RO, #4 ;SEE IF AT LEAST LEVEL 4
BLT 12$ ;BR IF NEW VALUE TOO SMALL
CMP RO, #7 ;SEE IF LEVEL 7 OR LESS
BGT 12$ ;BR IF NEW VALUE TOO LARGE
SWAB RO ;GET PRIORITY INTO BITS 5-7
ASR RO
ASR RO
ASR RO
MOV RO, RKPRI ;STORE NEW VALUE
TYPE $CRLF
BR 16$
12$: TYPE ,BUFF0 ;ECHO BAD INPUT
TYPE ,SQUES
BR 11$ ;GO ASK AGAIN

```

F08

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 97
INITIALIZE THE COMMON TAGS

SEQ 0096

4847 014416 105037 003126

16S: CLR8 ERRCNT

;CLEAR ERROR CNT FOR RESTARTS

G08

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 98
INITIALIZE THE COMMON TAGS

SEQ 0097

4848	014422	012737	014434	000042	MOV	#DRVTST,2#42	;SET UP DUMP MODE RETURN FROM SEOP
4849							;UPON COMPLETION OF REQUESTED PASSES
4850	014430	000137	015176		JMP	CHKLST	;GO CHECK STATUS OF MARKED DRIVES
4851							
4852							
4853							

```

4854
4855
4856
4857
4858
4859
4860
4861
4862
4863
4864 014434
4865 014434 012706 001100
4866 014440 005037 005502
4867 014444 004737 031342
4868 014450 104401 007717
4869 014454 004737 034034
4870 014460 014434
4871 014462 014434
4872 014464 014434
4873 014466 005700
4874 014470 001413
4875 014472 022737 000101 005264
4876 014500 001002
4877 014502 000137 015120
4878 014506 104401 005264
4879 014512 104401 001314
4880 014516 000746
4881
4882 014520 104401 007506
4883 014524 005001
4884 014526 005000
4885 014530 012703 000001
4886 014534 105761 005610
4887 014540 001414
4888 014542 005700
4889 014544 001402
4890 014546 104401 013305
4891 014552 010137 005534
4892 014556 052737 000060 005534
4893 014564 104401 005534
4894 014570 005200
4895 014572 005201
4896 014574 006303
4897 014576 022701 000010
4898 014602 001354
4899 014604 005700
4900 014606 001016
4901 014610 104401 011231
4902 014614 104401 007625
4903
4904 014620 012703 000401
4905 014624 012701 005610
4906 014630 010321
4907 014632 010321
4908 014634 010321
4909 014636 010311

```

```

;*****
;SBTTL TO - DESIRED DRIVE INPUT ROUTINE
;THIS ROUTINE TYPES THE CURRENT LIST OF DRIVES TO TEST,
;WITH DRIVE NUMBERS SEPARATED BY COMMAS. THEN, A NEW
;CHOICE OF DRIVES IS REQUESTED BY TTY INPUT, AND THESE
;DRIVES ARE CHECKED FOR VALIDITY AND PROPER STATUS,
;AND IF THEY ARE VALID, THEY ARE LOADED INTO THE DRIVE
;LIST (DRVLST).
;*****

```

```

DRVTST:
MOV #STACK, SP ;RESET THE STACK
CLR STALLS ;INHIBIT STALL BETWEEN OPERATIONS
JSR PC,ENBCSR ;ENABLE MEMORY PARITY CHECK
TYPE ALDRVS ;ASK IF ALL DRIVES DESIRED
JSR PC,RDCHRS ;READ RESPONSE
DRVTST ;(↑C) RETURN ADDRESS
DRVTST ;(↑Z) RETURN ADDRESS
DRVTST ;(↑U) OR ERROR RETURN ADDRESS
TST RO ;SEE IF NULL INPUT
BEQ TELDRV ;BR IF NULL INPUT
CMP #'A,BUFFO ;SEE IF ALL DRIVES REQUESTED
BNE 4$ ;BR IF NOT ALL DRIVES
JMP ALLDRV ;CHECK ALL DRIVES
4$: TYPE ,BUFFO ;ECHO BAD INPUT
TYPE ,SQUES ;TYPE <?> AND <CR>, <LF>
BR DRVTST ;GO ASK AGAIN

;TYPE CURRENT DRIVE LIST
↑TELDRV: TYPE ,DRVSEQ ;TYPE "DRIVE(S) = "
CLR R1 ;INITIALIZE DRIVE NUMBER
CLR RO ;INIT. COUNT OF LISTED DRIVES
MOV #BIT0,R3 ;INIT BIT POINTER
4$: TSTB DRVLST(R1) ;SEE IF THIS DRIVE IS LISTED
BEQ 8$ ;BR IF DRIVE NOT LISTED
TST RO ;SEE IF FIRST TIME HERE
BEQ 6$ ;BR IF FIRST TIME HERE
TYPE ,COMMA ;TYPE A COMMA
MOV R1,SCRACH ;USE SCRACH FOR BUFFER
BIS #'0,SCRACH ;CONVERT DRIVE NO. TO ASCII
TYPE ,SCRACH ;TYPE DRIVE NO.
INC RO ;INCREMENT NO. OF LISTED DRIVES
8$: INC R1 ;INCREMENT DRIVE NO.
ASL R3 ;SHIFT BIT POINTER
CMP #10,R1 ;SEE IF DONE YET
BNE 4$ ;BR IF NOT DONE
TST RO ;SEE IF ANY DRIVES WERE LISTED
BNE 26$ ;BR IF YES
TYPE ,NONE ;TYPE " NONE"
TYPE ,**NO DRIVES TO TEST ;TYPE "** NO DRIVES TO TEST"
TYPE ,PRESS 'CONT' WHEN RDY ;"PRESS 'CONT' WHEN RDY"
MOV #401,R3 ;PATTERN TO MARK DRIVES
MOV #DRVLST,R1 ;DRIVE LIST ADDRESS
MOV R3,(R1)+ ;MARK ALL DRIVES IN LIST
MOV R3,(R1)+
MOV R3,(R1)+
MOV R3,(R1)

```

4910	014640	000137	046150			JMP	HLTPRG	:HALT PROGRAM
4911	014644	104401	001315			TYPE	, \$CRLF	:TYPE <CR>, <LF>
4912	014650	122737	000013	000041	26\$:	CMPB	#13, #41	:DID DRIVE LOAD XXDP??
4913	014656	001003				BNE	28\$:NO, SO SKIP NEXT
4914	014660	104401	007227			TYPE	, XXDPME	:INFORM USER TO REMOVE XXDP PACK
4915	014664	000000				HALT		:AND FORCE OPERATOR INTERVENTION
4916	014666	105037	000041		28\$:	CLRB	#41	:OPERATOR HIT CONT. CLR THE LD PTR
4917	014672	105737	003116			TSTB	MDFLAG	:SEE IF DEFAULT MODE
4918	014676	001012				BNE	19\$:BR IF NOT DEFAULT MODE
4919	014700	000137	015536			JMP	LODFLS	:GO LOAD DEFLT ITER. COUNTS
4920	014704	001007				BNE	19\$:BR IF NOT
4921	014706	105737	005610			TSTB	DRVLST	:SEE IF DRIVE 0 LISTED TO TEST
4922	014712	001404				BEQ	19\$:BR IF NOT
4923	014714	004737	032310			JSR	PC, INITSS	:INIT THE SUB-SYS
4924	014720	000137	015176			JMP	CHKLST	:GO CHECK STATUS OF LISTED DRIVES
4925	014724	104401	013334		19\$:	TYPE	, PROMPT	:TYPE ASTERISK AND SPACE
4926						;READ AND CHECK	NEW DRIVE NUMBERS	
4927	014730	004737	034034			JSR	PC, RDRCHRS	:READ IN INPUT STRING
4928	014734	014434				DRVTST		:(<C> RETURN ADDRESS
4929	014736	014434				DRVTST		:(<Z> RETURN ADDRESS
4930	014740	014520				TELDRV		:(<U> OR ERROR RETURN ADDRESS
4931	014742	005700				TST	RO	:SEE IF NULL INPUT
4932	014744	001007				BNE	9\$:BR IF NEW DRIVES WILL BE SELECTED
4933	014746	105737	003135			TSTB	DULACS	:SEE IF DUAL-ACCESS FLAG SET
4934	014752	001002				BNE	22\$:BR IF YES
4935	014754	000137	015250			JMP	ASKTST	:JUMP TO THE TEST INPUT ROUTINE
4936	014760	000137	016014		22\$:	JMP	INPUTP	:GO ASK FOR INPUT PARAMETERS
4937	014764	022700	000017		9\$:	CMP	#15., RO	:SEE IF TOO MANY CHARACTERS TYPED
4938	014770	002005				BGE	12\$:BR IF NOT TOO MANY
4939	014772	104401	005264		10\$:	TYPE	, BUFFO	:ECHO BAD INPUT
4940	014776	104401	001314			TYPE	, \$QUES	:TYPE <?> AND <CR>, <LF>
4941	015002	000646				BR	↑TELDRV	:GO TYPE DRIVES AND ASK AGAIN
4942	015004	005001			12\$:	CLR	R1	:CLEAR CHAR. POINTER
4943	015006	126127	005264	000060	14\$:	CMPB	BUFFO(R1), #'0	:SEE IF DRIVE NO. < 0
4944	015014	002766				BLT	10\$:BR TO ECHO BAD INPUT
4945	015016	126127	005264	000067		CMPB	BUFFO(R1), #'7	:SEE IF > 7
4946	015024	003362				BGT	10\$:BR TO ECHO BAD INPUT
4947	015026	005201				INC	R1	:INCREMENT CHAR POINTER
4948	015030	020100				CMP	R1, RO	:SEE IF MORE CHARS TO CHECK
4949	015032	001406				BEQ	16\$:BR IF ALL CHARS CHECKED
4950	015034	126127	005264	000054		CMPB	BUFFO(R1), #',	:SEE IF THIS IS COMMA
4951	015042	001353				BNE	10\$:BR IF NOT COMMA
4952	015044	005201				INC	R1	:INCREMENT CHAR POINTER
4953	015046	000757				BR	14\$:BR TO CONTINUE CHECKING CHARS
4954						;GET NEW DRIVE NUMBERS INTO LIST		
4955	015050	012701	005610		16\$:	MOV	#DRVLST, R1	:GET DRIVE LIST ADDRESS
4956	015054	005021				CLR	(R1)+	:CLEAR OUT THE DRIVE LIST
4957	015056	005021				CLR	(R1)+	
4958	015060	005021				CLR	(R1)+	
4959	015062	005011				CLR	(R1)	
4960	015064	005000				CLR	RO	:CLEAR BUFFER POINTER
4961	015066	116001	005264		18\$:	MOVB	BUFFO(RO), R1	:GET A DRIVE NUMBER
4962	015072	042701	000060			BIC	#'0, R1	:STRIP ASCII BITS
4963	015076	112761	000001	005610		MOVB	#1, DRVLST(R1)	:MARK THIS DRIVE IN DRIVE LIST
4964	015104	062700	000002			ADD	#2, RO	:POINT TO NEXT DRIVE NUMBER
4965	015110	105760	005263			TSTB	BUFFO-1(RO)	:SEE IF NULL CHAR YET

```

4966 015114 J01364          BNE      18$          ;BR IF NOT DONE YET
4967 015116 000427          BR       CHKLST      ;GO CHECK NEW DRIVES FOR VALID STATUS
4968                                     ;COME HERE IF ALL DRIVES REQUESTED
4969 015120 005000          ALLDRV: CLR      RO          ;CLEAR DRIVE NUMBER
4970 015122 013703 001376   MOV      $DEVN,R3     ;GET APT DEVICE MAP
4971 015126 132737 000200 001341 BITB     #BIT7,$ENVN  ;SEE IF NO SIZING
4972 015134 001002          BNE      1$          ;BR IF NO SIZING
4973 015136 012703 000377   MOV      #377,R3     ;SET UP FOR SIZING
4974 015142 012701 000001   1$:     MOV      #BIT0,R1 ;SET BIT POINTER
4975 015146 105060 005610   2$:     CLRB     DRVLST(RO) ;INITIALIZE DRIVE ENTRY
4976 015152 030103          BIT      R1,R3       ;SEE IF THIS DRIVE IS REQUESTED
4977 015154 001403          BEQ      4$          ;BR IF NOT
4978 015156 112760 000001 005610   MOVB    #1,DRVLST(RO) ;MARK THIS DRIVE IN DRIVE LIST
4979 015164 006301          ASL     R1           ;SHIFT BIT POINTER
4980 015166 005200          INC     RO           ;INCREMENT DRIVE NUMBER
4981 015170 022700 000010   CMP     #10,RO      ;SEE IF DONE MARKING ALL DRIVES
4982 015174 001364          BNE     2$          ;BR IF NOT DONE YET
4983                                     ;CHECK ALL DRIVES MARKED IN DRIVE LIST FOR PROPER STATUS
4984 015176 005000          CHKLST: CLR     RO    ;CLEAR DRIVE NUMBER
4985 015200 105760 005610   2$:     TSTB    DRVLST(RO) ;SEE IF THIS DRIVE IS MARKED IN LIST
4986 015204 001410          BEQ     4$          ;BR IF NOT MARKED
4987 015206 010037 005500   MOV     RO,DRIVE    ;SET DRIVE NUMBER FOR SCNDRV
4988 015212 004737 032436   JSR     PC,SCNDRV   ;CHECK STATUS OF THIS DRIVE
4989                                     ;IF NOT VALID, TYPE MESSAGE
4990                                     ;AND REMOVE IT FROM DRIVE LIST
4991 015216 015242          6$:     MOVB    TYPFMT,DTYLST(RO) ;ERROR RETURN ADDRESS FOR SCNDRV
4992 015220 113760 003124 005620   4$:     INC     RO          ;SET DRV TYP, 0=RK06, 4=RK07
4993 015226 005200          CMP     #10,RO      ;RETURN HERE IF DRIVE IS USEABLE
4994 015230 022700 000010   BNE     2$          ;SEE IF DONE CHECKING LIST
4995 015234 001361          BNE     2$          ;BR IF NOT DONE YET
4996 015236 000137 014520   JMP     TELDRV      ;GO BACK TO LIST SELECTED DRIVES
4997 015242 105060 005610   6$:     CLRB    DRVLST(RO) ;REMOVE INVALID DRIVE FROM LIST
4998 015246 000767          BR      4$          ;CONTINUE CHECKING THE LIST

```

```

5000
5001 ;*****
5002 ;SBTTL TO - DESIRED TEST INPUT ROUTINE
5003 ;*THIS ROUTINE ALLOWS INPUT OF DESIRED TESTS AND ITERATION
5004 ;*COUNT FOR EACH TEST. THE INPUT IS CHECKED FOR VALIDITY,
5005 ;*AND IF VALID, THE ITERATION COUNTS ARE LOADED INTO THE
5006 ;*TEST LIST (TSTLST). AN ITERATION VALUE OF 0 INDICATES
5007 ;*THAT THE TEST IS NOT TO BE RUN.
5008 ;*THIS ROUTINE REQUESTS "ENTER L,C, OR I". TYPING (L)
5009 ;*CAUSES THE CURRENT LIST OF TESTS AND ITERATIONS TO BE
5010 ;*TYPED, (C) ALLOWS TESTS AND ITERATIONS TO BE CHANGED,
5011 ;*AND (I) ALLOWS THE OPERATOR TO PROCEED WITH SELECTION
5012 ;*OF OPERATING PARAMETERS, AND RUN TESTS.
5013 ;*TYPING (↑C) CAUSES IMMEDIATE RETURN TO DRVTST. TYPING
5014 ;* (↑Z) CAUSES RETURN TO ASKTMD.
5015 ;*****

```

```

5017 ;DETERMINE L,C, OR I MODE
5018 015250 104401 010000   ASKTST: TYPE     ,TSTMDS ;ASK FOR TEST INPUT MODE
5019 015254 104401 010102   ASKTMD: TYPE     ,ENTLCI ;TYPE "ENTER L,C, OR I"
5020 015260 004737 034034   JSR     PC,RDCHRS ;READ RESPONSE
5021 015264 014434          DRVTST ;(↑C) RETURN ADDRESS

```

```

5022 015266 015254 ASKTMD ;(↑Z) RETURN ADDRESS
5023 015270 015254 ASKTMD ;(↑U) OR ERROR RETURN ADDRESS
5024 015272 005700 TST RO ;SEE IF ANY INPUT
5025 015274 001005 BNE 4$ ;BR IF ANY INPUT
5026 015276 104401 005264 2$: TYPE ,BUFFO ;ECHO BAD INPUT
5027 015302 104401 001314 TYPE $QUES ;TYPE <?> AND <CR>,<LF>
5028 015306 000762 BR ASKTMD ;GO ASK AGAIN
5029 015310 022737 000114 005264 4$: CMP #'L,BUFFO ;SEE IF (L) TYPED
5030 015316 001002 BNE 6$ ;BR IF NOT (L)
5031 015320 000137 015354 JMP LSTTST ;JUMP TO LIST TESTS
5032 015324 022737 000103 005264 6$: CMP #'C,BUFFO ;SEE IF (C) TYPED
5033 015332 001002 BNE 8$ ;BR IF NOT (C)
5034 015334 000137 015472 JMP CHGTST ;JUMP TO CHANGE TESTS
5035 015340 022737 000111 005264 8$: CMP #'I,BUFFO ;SEE IF (I) TYPED
5036 015346 001353 BNE 2$ ;BR IF NOT (I), TO ECHO BAD INPUT
5037 015350 000137 016014 JMP INPUTP ;GO INPUT PARAMS AND RUN TESTS
5038
5039 ;LIST CURRENT TESTS AND ITERATION COUNTS
5040 015354 104401 010204 LSTTST: TYPE TLSTHD ;TYPE HEADING "TEST ITERATIONS"
5041 015360 005001 CLR R1 ;INITIALIZE TEST INDEX
5042 015362 004737 030576 2$: JSR PC,PREPKB ;PREPARE FOR POSSIBLE KBD INPUT
5043 015366 004737 034346 JSR PC,TYPTST ;TYPE CURRENT TEST AND ITERATION NUMBER
5044 015372 104401 001315 TYPE $CRLF ;TYPE <CR>,<LF>
5045 015376 005737 005522 TST INTCHR ;SEE IF ANY INPUT
5046 015402 001416 BEQ 8$ ;BR IF NO INPUT
5047 015404 122737 000003 005522 CMPB #003,INTCHR ;SEE IF (↑C) TYPED
5048 015412 001002 BNE 4$ ;BR IF NOT (↑C)
5049 015414 000137 014434 JMP DRVTST ;JUMP TO ASK FOR DRIVES AGAIN
5050 015420 122737 000032 005522 4$: CMPB #032,INTCHR ;SEE IF (↑Z) TYPED
5051 015426 001002 BNE 6$ ;BR IF NOT (↑Z)
5052 015430 000137 015254 JMP ASKTMD ;JUMP TO ASK FOR NEW TEST INPUT MODE
5053 015434 004737 030616 6$: JSR PC,ECOBAD ;ECHO BAD INPUT
5054 015440 062701 000002 8$: ADD #2,R1 ;INCREMENT TEST INDEX
5055 015444 010102 MOV R1,R2 ;GET COPY OF INDEX
5056 015446 062702 005630 ADD #TSTLST,R2 ;GET POSITION IN LIST
5057 015452 022702 005644 CMP #DFLTST,R2 ;SEE IF DONE WITH LIST
5058 015456 001341 BNE 2$ ;BR IF NOT DONE YET
5059 015460 042777 000100 163456 BIC #BIT6,@$TKS ;DISABLE KBD INTERRUPT
5060 015466 000137 015254 JMP ASKTMD ;GO ASK FOR NEW TEST INPUT MODE
5061
5062 ;CHANGE CURRENT TESTS AND ITERATION COUNTS
5063 015472 104401 010130 CHGTST: TYPE DFTEST ;ASK IF TESTS SHOULD BE DEFAULTED
5064 015476 004737 034034 JSR PC,RDCHRS ;READ RESPONSE
5065 015502 014434 DRVTST ;(↑C) RETURN ADDRESS
5066 015504 015254 ASKTMD ;(↑Z) RETURN ADDRESS
5067 015506 015472 CHGTST ;(↑U) OR ERROR RETURN ADDRESS
5068 015510 005700 TST RO ;SEE IF NULL INPUT
5069 015512 001426 BEQ NULINP ;BR IF NULL INPUT
5070 015514 022737 000104 005264 CMP #'D,BUFFO ;SEE IF (D) TYPED
5071 015522 001405 BEQ LODFLS ;BR IF DEFAULTS REQUESTED
5072 015524 104401 005264 TYPE ,BUFFO ;ECHO BAD INPUT
5073 015530 104401 001314 TYPE $QUES ;TYPE <?> AND <CR>,<LF>
5074 015534 000756 BR CHGTST ;GO ASK AGAIN
5075 ;LOAD DEFAULT ITERATION COUNTS INTO TEST LIST
5076 015536 012700 005644 LODFLS: MOV #DFLTST,R0 ;LOAD DEFAULT LIST ADDRESS
5077 015542 012702 005630 MOV #TSTLST,R2 ;LOAD TEST LIST ADDRESS

```

```

5078 015546 012022          4$:  MOV      (R0)+(R2)+      ;LOAD A DEFAULT VALUE
5079 015550 022702 005644    CMP      #DFLTST,R2      ;SEE IF DONE YET
5080 015554 001374          BNE      4$              ;BR IF NOT DONE YET
5081 015556 105737 003116    TSTB    MDFLAG          ;SEE IF DEFAULT MODE
5082 015562 001234          BNE      ASKTMD         ;BR IF NOT DEFAULT MODE
5083 015564 000137 016550    JMP      LODFPT         ;GO LOAD DEFAULT PARAMETERS
5084 015570 005001          NULINP: CLR     R1        ;INITIALIZE TEST INDEX
5085 015572 104401 010204    TYPE    TLSTHD         ;TYPE HEADING "TEST  ITERATIONS"
5086                                     ;TYPE CURRENT TEST AND ITERATION NUMBER
5087 015576 004737 034346    8$:  JSR      PC,TYPTST   ;TYPE A TEST NO. AND ITERATION NO.
5088 015602 104401 013314    TYPE    ,SPACE1       ;TYPE A SPACE
5089 015606 104401 013334    TYPE    ,PROMPT       ;TYPE ASTERISK AND SPACE
5090                                     ;READ AND CHECK INPUT IF ANY
5091 015612 004737 034034    JSR      PC,RDCHRS     ;READ OCTAL DIGITS TYPED
5092 015616 014434          DRVTST                ;(+C) RETURN ADDRESS
5093 015620 015254          ASKTMD                ;(+Z) RETURN ADDRESS
5094 015622 015576          8$                    ;(+U) OR ERROR RETURN ADDRESS
5095 015624 005700          TST      RO           ;SEE IF ANY INPUT
5096 015626 001012          BNE      12$          ;BR IF ANY INPUT
5097 015630 062701 000002    10$:  ADD      #2,R1       ;INCREMENT INDEX
5098 015634 010102          MOV      R1,R2        ;COPY INDEX
5099 015636 062702 005630    ADD      #TSTLST,R2   ;GET POSITION IN LIST
5100 015642 022702 005644    CMP      #DFLTST,R2   ;SEE IF DONE WITH LIST
5101 015646 001353          BNE      8$           ;BR IF NOT DONE YET
5102 015650 000137 015254    JMP      ASKTMD        ;GO ASK FOR NEW TEST INPUT MODE
5103 015654 022737 000041 005264 12$:  CMP      #'!,BUFFO    ;SEE IF (!) TYPED
5104 015662 001431          BEQ      16$          ;BR TO PROPAGATE CURRENT ITER. NO.
5105 015664 005002          CLR      R2           ;INITIALIZE (!) INDICATOR
5106 015666 122760 000041 005263  CMPB    #'!,BUFFO-1(R0) ;SEE IF LAST CHAR IN BUF IS (!)
5107 015674 001004          BNE      14$          ;BR IF NOT (!)
5108 015676 105060 005263    CLRB    BUFFO-1(R0)   ;INSERT TERMINATOR BYTE
5109 015702 005300          DEC      RO           ;DECREMENT CHAR COUNT
5110 015704 005202          INC      R2           ;SET (!) INDICATOR
5111 015706 022700 000005    14$:  CMP      #5,RO       ;SEE HOW MANY CHARS NOW
5112 015712 002433          BLT     20$          ;BR IF TOO MANY (MAX ITER. NO. = 77776)
5113 015714 012746 005264    MOV      #BUFFO, -(SP) ;GET BUF ADDR. ON STACK FOR OCTBIN
5114 015720 004737 054500    JSR      PC,OCTBIN    ;CHECK DIGITS AND CONVERT TO BINARY
5115 015724 016002          20$:  MOV      (SP)+,RO     ;ERROR RETURN ADDRESS FOR OCTBIN
5116 015726 012600          MOV      (SP)+,RO     ;GET ITERATION NUMBER
5117 015730 020027 077776    CMP      RO,#77776    ;SEE IF > 77776
5118 015734 101022          BHI     20$          ;BR IF TOO BIG
5119 015736 010061 005630    MOV      RO,TSTLST(R1) ;PUT ITERATION NUMBER INTO TEST LIST
5120 015742 005702          TST     R2            ;SEE IF (!) WAS TYPED
5121 015744 001731          BEQ     10$          ;BR IF NOT (!)
5122                                     ;PROPAGATE CURRENT ITERATION NO.
5123 015746 010102          16$:  MOV      R1,R2        ;TO THE END OF TSTLST
5124 015750 062702 005630    ADD      #TSTLST,R2   ;COPY INDEX
5125 015754 022702 005642    CMP      #DFLTST-2,R2 ;GET POSITION IN LIST
5126 015760 001002          BNE     17$          ;SEE IF AT END OF LIST
5127 015762 000137 015254    JMP      ASKTMD        ;BR IF NOT DONE
5128 015766 016161 005630 005632 17$:  MOV      TSTLST(R1),TSTLST+2(R1) ;GO ASK FOR NEW TEST INPUT MODE
5129 015774 062701 000002    ADD      #2,R1        ;PROPAGATE TO NEXT WORD
5130 016000 000762          BR      16$          ;INCREMENT INDEX
5131 016002 104401 005264    BR      16$          ;BR TO CONTINUE
5132 016006 104401 001314    TYPE    ,BUFFO        ;ECHO BAD INPUT
5133 016012 000671          TYPE    ,QUES         ;TYPE <?> AND <CR>, <LF>
BR      8$                    ;GO ASK AGAIN

```



```

S134
S135
S136 016014 104401 010234 ;ASK FOR DESIRED OPERATIONAL PARAMETER INPUT MODE
S137 016020 005037 005502 INPUTP: TYPE ,EXPLAN ;EXPLAIN INPUT MODES
S138 016024 004737 031342 ASKMDE: CLR ,STALLS ;INHIBIT STALL BETWEEN OPERATIONS
S139 016030 104401 010362 JSR PC,ENBCSR ;ENABLE MEMORY PARITY CHECK
S140 016034 104401 013334 TYPE ,PARMDE ;ASK FOR DESIRED INPUT MODE
S141 016040 004737 034034 JSR PC,RDCHRS ;TYPE "*"
S142 016044 014434 DRVTST ;READ RESPONSE TO MODE QUESTION
S143 016046 016020 ASKMDE ;(↑C) RETURN ADDRESS
S144 016050 016020 ASKMDE ;(↑Z) RETURN ADDRESS
S145 016052 005700 TST RO ;(↑U) OR ERROR RETURN ADDRESS
S146 016054 001005 BNE 4$ ;SEE IF NULL INPUT
S147 016056 104401 005264 2$: TYPE ,BUFFO ;BR IF ANY INPUT
S148 016062 104401 001314 TYPE ,SQUES ;ECHO BAD INPUT
S149 016066 000754 BR ASKMDE ;TYPE <?> AND <CR>, <LF>
S150 016070 022737 000124 005264 4$: CMP #'T,BUFFO ;GO ASK AGAIN
S151 016076 001002 BNE 6$ ;SEE IF (T) TYPED
S152 016100 000137 016232 JMP TYPLST ;BR IF NOT (T)
S153 016104 022737 000117 005264 6$: CMP #'O,BUFFO ;JUMP TO THE TYPE LIST ROUTINE
S154 016112 001002 BNE 8$ ;SEE IF (O) TYPED
S155 016114 000137 016504 JMP OPNLST ;BR IF NOT (O)
S156 016120 022737 000123 005264 8$: CMP #'S,BUFFO ;JUMP TO THE OPEN LIST ROUTINE
S157 016126 001002 BNE 10$ ;SEE IF (S) TYPED
S158 016130 000137 016770 JMP SETPRM ;BR IF NOT (S)
S159 016134 022737 000122 005264 10$: CMP #'R,BUFFO ;JUMP TO THE SET INDIV. PARAM. ROUTINE
S160 016142 001345 BNE 2$ ;SEE IF (R) TYPED
S161 016144 023737 005670 005672 CMP SO,S1 ;BR IF NOT (R) TO ECHO BAD INPUT
S162 016152 003403 BLE 12$ ;COMPARE 20(DEC) SECTOR LIMITS
S163 016154 104401 010470 TYPE ,SECNL1 ;BR IF SO NOT > S1
S164 016160 000717 BR ASKMDE ;TYPE "SO>S1 NOT ALLOWED"
S165 016162 023737 005674 005676 12$: CMP S2,S3 ;GO ASK AGAIN FOR PARAMETERS
S166 016170 003405 BLE 14$ ;COMPARE 22(DEC) SECTOR LIMITS
S167 016172 104401 010520 TYPE ,SECNL2 ;BR IF S2 NOT > S3
S168 016176 104401 010501 TYPE ,NOTALD ;TYPE "S2>S3"
S169 016202 000706 BR ASKMDE ;TYPE "NOT ALLOWED"
S170 016204 023737 005664 005666 14$: CMP FT,LT ;GO ASK AGAIN FOR PARAMETERS
S171 016212 003405 BLE 20$ ;COMPARE CHOSEN TRACK LIMITS
S172 016214 104401 010532 TYPE ,TRKNLW ;BR IF FT NOT > LT
S173 016220 104401 010501 TYPE ,NOTALD ;TYPE "FT>LT"
S174 016224 000675 BR ASKMDE ;TYPE "NOT ALLOWED"
S175 016226 000137 017224 20$: JMP RUNTST ;GO ASK AGAIN FOR PARAMETERS
S176
S177
S178
S179
S180 ;.SBTTL TO - TYPE (T) LIST ROUTINE
S181 ;*THIS ROUTINE TYPES THE ENTIRE PARAMETER LIST ON THE
S182 ;*CONSOLE, LINE BY LINE. EACH LINE HAS THE FOLLOWING
S183 ;*FORMAT: XX=YYYYYY WHERE XX IS A PARAMETER MNEMONIC
S184 ;*AND YYYYYY IS THE VALUE OF THE PARAMETER IN OCTAL.
S185 ;*TYPING (↑C) CAUSES IMMEDIATE RETURN TO DRVTST,
S186 ;*AND (↑Z) CAUSES RETURN TO ASKMDE.
S187 016232 TYPLST:
S188 016232 005C01 CLR R1 ;INITIALIZE INDEX
S189 016234 004737 030576 JSR PC,PREPKB ;PREPARE FOR POSSIBLE KBD INPUT

```

```

5190 016240 004737 034402 1$: JSR PC,TYPPRM ;TYPE CURRENT PARAMETER AND VALUE
5191 016244 104401 001315 TYPE ,SCLF ;TYPE <CR>,<LF>
5192 016250 005737 005522 TST INTCHR ;SEE IF ANY INPUT AT KBD
5193 016254 001420 BEQ 8$ ;BR IF NO INPUT
5194 016256 122737 000003 005522 CMPB #003,INTCHR ;SEE IF (↑C) TYPED
5195 016264 001002 BNE 4$ ;BR IF NOT (↑C)
5196 016266 000137 014434 JMP DRVTST ;JUMP TO ASK FOR DRIVE(S) AGAIN
5197 016272 122737 000032 005522 4$: CMPB #032,INTCHR ;SEE IF (↑Z) TYPED
5198 016300 001002 BNE 6$ ;BR IF NOT (↑Z)
5199 016302 000137 016020 JMP ASKMDE ;JUMP TO ASK FOR NEW MODE
5200 016306 004737 030616 6$: JSR PC,ECOBAD ;ECHO BAD INPUT
5201 016312 004737 030576 JSR PC,PREPKB ;PREPARE FOR POSSIBLE KBD INPUT
5202 016316 022761 040515 006010 8$: CMP #MA,PRMNEM(R1) ;SEE IF PARAM. IS (MA)
5203 016324 001002 BNE 10$ ;BR IF NOT (MA)
5204 016326 062701 000002 ADD #2,R1 ;INCREMENT PARAMETER INDEX
5205 016332 062701 000002 10$: ADD #2,R1 ;INCREMENT PARAMETER INDEX
5206 016336 010102 MOV R1,R2 ;GET COPY OF INDEX
5207 016340 062702 005660 ADD #PRMLST,R2 ;COMPUTE POSITION IN LIST
5208 016344 022702 005706 CMP #PRDFLT,R2 ;SEE IF DONE WITH LIST
5209 016350 001333 BNE 1$ ;BR IF NOT DONE YET
5210 016352 032737 100000 005700 BIT #BIT15,PT ;SEE IF PATTERN 15 SPECIFIED
5211 016360 001005 BNE 12$ ;BR IF PATTERN SPECIFIED
5212 016362 042777 000100 162554 BIC #BIT6,STKS ;DISABLE KBD INTERRUPT
5213 016370 000137 016020 JMP ASKMDE ;JUMP TO ASK FOR NEW MODE
5214
5215 016374 104401 010657 12$: TYPE OUT USER-DEFINED PATTERN 15 ;TYPE "USER-DEFINED PATTERN 15 : "
5216 016400 005001 CLR R1 ;INITIALIZE WORD INDEX
5217 016402 005737 005522 14$: TST INTCHR ;SEE IF ANY INPUT
5218 016406 001420 BEQ 20$ ;BR IF NO INPUT
5219 016410 122737 000003 005522 CMPB #003,INTCHR ;SEE IF (↑C) TYPED
5220 016416 001002 BNE 16$ ;BR IF NOT (↑C)
5221 016420 000137 014434 JMP DRVTST ;JUMP TO ASK FOR DRIVE(S) AGAIN
5222 016424 122737 000032 005522 16$: CMPB #032,INTCHR ;SEE IF (↑Z) TYPED
5223 016432 001002 BNE 18$ ;BR IF NOT (↑Z)
5224 016434 000137 016020 JMP ASKMDE ;JUMP TO ASK FOR NEW MODE
5225 016440 004737 030616 18$: JSR PC,ECOBAD ;ECHO BAD INPUT
5226 016444 004737 030576 JSR PC,PREPKB ;PREPARE FOR POSSIBLE KBD INPUT
5227 016450 004737 034462 20$: JSR PC,TYPPAT ;TYPE WORD XX = YYYYYY
5228 016454 104401 001315 TYPE ,SCLF ;TYPE <CR>,<LF>
5229 016460 062701 000002 ADD #2,R1 ;INCREMENT INDEX
5230 016464 022701 000040 CMP #32.,R1 ;SEE IF 16 WORDS TYPED
5231 016470 001344 BNE 14$ ;BR IF NOT DONE YET
5232 016472 042777 000100 162444 BIC #BIT6,STKS ;DISABLE KBD INTERRUPT
5233 016500 000137 016020 JMP ASKMDE ;JUMP TO ASK FOR NEW MODE
5234
5235
5236
5237
5238
5239
5240
5241
5242
5243
5244
5245 016504 OPNLST:

```

```

.SBTTL TO - OPEN (O) LIST ROUTINE
;THIS ROUTINE IS USED TO EITHER REQUEST LOADING OF ALL
;DEFAULT PARAMETERS INTO THE PARAMETER LIST, OR TO
;SEQUENTIALLY OPEN EACH PARAMETER FOR ALTERATION BY
;TTY INPUT. TYPING (↑C) CAUSES IMMEDIATE RETURN TO
;DRVTST, AND (↑Z) CAUSES RETURN TO ASKMDE.

```

```

5246 016504 104401 010575          TYPE      DFQUES      ;ASK IF ALL DEFAULT VALUES DESIRED
5247 016510 004737 034034          JSR        PC,RDCHRS  ;READ RESPONSE TO DEFAULT QUESTION
5248 016514 014434          DRVTST    ;(↑C) RETURN ADDRESS
5249 016516 016020          ASKMDE    ;(↑Z) RETURN ADDRESS
5250 016520 016504          OPNLST    ;(↑U) OR ERROR RETURN ADDRESS
5251 016522 005700          TST       RO          ;SEE IF NULL INPUT
5252 016524 001433          BEQ       NOTDFT     ;BR IF DEFAULTS NOT REQUESTED
5253 016526 022737 000104 005264    CMP       #'D,BUFFO   ;SEE IF (D) TYPED
5254 016534 001405          BEQ       LODFPT     ;BR IF DEFAULTS DESIRED
5255 016536 104401 005264          TYPE     ,BUFFO     ;ECHO BAD INPUT
5256 016542 104401 001314          TYPE     ,SQUES
5257 016546 000756          BR        OPNLST     ;GO ASK AGAIN
5258                                ;LOAD ALL DEFAULT VALUES INTO PARAMETER LIST
5259 016550 012700 005706    LODFPT:  MOV     #PRDFLT,RO ;LOAD DEFAULT LIST ADDRESS
5260 016554 012702 005660          MOV     #PRMLST,R2   ;LOAD PARAMETER LIST ADDRESS
5261 016560 012022          4$:     MOV     (RO)+,(R2)+ ;LOAD A DEFAULT VALUE
5262 016562 022702 005706          CMP     #PRDFLT,R2   ;SEE IF DONE YET
5263 016566 001374          BNE      4$          ;BR IF MORE VALUES TO LOAD YET
5264 016570 105737 003116          TSTB    MDFLAG       ;SEE IF DEFAULT MODE
5265 016574 001005          BNE      6$          ;BR IF NOT DEFAULT MODE
5266 016576 012737 000001 024006    MOV     #1,SEOPCT    ;SET PASS COUNT = 1
5267 016604 000137 017306          JMP     STPASS       ;GO RUN DFLT TESTS
5268 016610 000137 016020          JMP     ASKMDE       ;JUMP TO ASK FOR NEW MODE
5269 016614 005001          NOTDFT: CLR    R1     ;INITIALIZE INDEX
5270                                ;TYPE CURRENT PARAMETER AND VALUE
5271 016616 004737 034402    8$:     JSR     PC,TYPRM   ;TYPE PARAMETER AND VALUE
5272 016622 104401 013314          TYPE     ,SPACE1    ;TYPE A SPACE
5273 016626 104401 013334          TYPE     ,PROMPT    ;TYPE ASTERISK AND SPACE
5274                                ;READ AND CHECK INPUT, IF ANY
5275 016632 004737 034034          JSR     PC,RDCHRS   ;READ OCTAL DIGITS TYPED
5276 016636 014434          DRVTST    ;(↑C) RETURN ADDRESS FOR RDCHRS
5277 016640 016020          ASKMDE    ;(↑Z) RETURN ADDRESS FOR RDCHRS
5278 016642 016616          8$:     ;(↑U) OR ERROR RETURN ADDR. FOR RDCHRS
5279 016644 005700          TST       RO          ;SEE IF ANY INPUT
5280 016646 001007          BNE      10$         ;BR IF ANY INPUT
5281 016650 022761 040515 006010    CMP     #'MA,PRMNM(R1) ;SEE IF (MA) JUST DEFAULTED
5282 016656 001023          BNE      12$         ;BR IF NOT (MA)
5283 016660 062701 000002          ADD     #2,R1        ;INCREMENT INDEX
5284 016664 000420          BR       12$         ;BR TO MOVE ON TO NEXT PARAMETER
5285 016666 022700 000010    10$:   CMP     #10,RO       ;SEE IF 8 CHARACTERS TYPED
5286 016672 002431          BLT     14$          ;BR IF MORE THAN 8 TYPED
5287 016674 012746 005264          MOV     #BUFFO,-(SP) ;PUT BUFFER ADDR. ON STACK FOR OCTBIN
5288 016700 004737 054500          JSR     PC,OCTBIN   ;CHECK DIGITS AND CONVERT TO BINARY
5289 016704 016756          14$:   ;ERROR RETURN ADDRESS FOR OCTBIN
5290 016706 012637 005470          MOV     (SP)+,LOWOCT ;GET LOW BINARY BITS
5291 016712 013737 054632 005472    MOV     #HIOCT,HIGOCT ;GET HIGH BINARY BITS
5292                                ;CHECK PARAMETER VALUE AND PUT INTO LIST
5293 016720 004737 035040          JSR     PC,CHKPRM   ;CHECK VALIDITY OF PARAM VALUE
5294 016724 016756          14$:   ;ERROR RETURN ADDR. FOR CHKPRM
5295                                ;OPEN USER-DEFINED PATTERN 15 FOR MODIFICATION, IF NECESSARY
5296 016726 004737 034514    12$:   JSR     PC,MODP15
5297                                ;MOVE ON TO NEXT PARAMETER
5298 016732 062701 000002          ADD     #2,R1        ;INCREMENT THE PARAMETER INDEX
5299 016736 010102          MOV     R1,R2        ;GET COPY OF INDEX
5300 016740 062702 005660          ADD     #PRMLST,R2   ;COMPUTE POSITION IN LIST
5301 016744 022702 005706          CMP     #PRDFLT,R2   ;SEE IF DONE WITH LIST

```

5302	016750	001322	
5303	016752	000137	016020
5304	016756	104401	005264
5305	016762	104401	001314
5306	016766	000713	

```

BNE 8$ ;BR IF NOT DONE YET
JMP ASKMDE ;JUMP TO ASK FOR NEW MODE
14$: TYPE ,BUFFO ;ECHO BAD INPUT
TYPE ,SQUES ;TYPE (?) AND <CR>, <LF>
BR 8$ ;BR TO ASK AGAIN

```

5307
5308
5309
5310
5311
5312
5313
5314
5315
5316
5317
5318
5319
5320
5321
5322
5323
5324
5325
5326
5327
5328
5329
5330
5331
5332
5333
5334
5335
5336
5337
5338
5339
5340
5341
5342
5343
5344
5345
5346
5347
5348
5349
5350
5351
5352
5353
5354
5355
5356
5357

016770			
016770	104401	013337	
016774	004737	034034	
017000	014434		
017002	016020		
017004	016770		
017006	020027	000004	
017012	002005		
017014	104401	005264	
017020	104401	001314	
017024	000761		
017026	020027	000013	
017032	003370		
017034	005001		
017036	023761	005264	006010
017044	001411		
017046	062701	000002	
017052	010102		
017054	062702	005660	
017060	022702	005706	
017064	001364		
017066	000752		
017070	012702	000002	
017074	122762	000075	005264
017102	001411		
017104	122762	000040	005264
017112	001340		
017114	005202		
017116	122762	000075	005264
017124	001333		
017126	005202		
017130	020200		
017132	002330		
017134	122762	000040	005264

```

.SBTTL TO - SET (S) INDIVIDUAL PARAM ROUTINE
;THIS ROUTINE IS USED TO ALLOW SETTING OF ANY INDIVIDUAL
;PARAMETER VALUE BY TTY INPUT. A PROMPTER ( ) IS
;TYPED AND THE ROUTINE WAITS FOR INPUT OF THE FORM
;* XX=YYYYYY, WHERE XX IS THE MNEMONIC FOR ANY VALID
;PARAMETER IN THE LIST, AND YYYYYY IS THE DESIRED PARAMETER
;VALUE IN OCTAL DIGITS. THE PROGRAM THEN ASKS FOR ANOTHER
;PARAMETER BY TYPING ">" AGAIN. TYPING (↑) CAUSES
;IMMEDIATE RETURN TO DRVTST, AND (↑Z) CAUSES RETURN TO
;ASKMDE.

```

```

SETPRM:
;READ AND CHECK INPUT, IF ANY
TYPE PRMPSP ;TYPE ">" PROMPTER
JSR PC, RDCHRS ;READ INPUT LINE
;DRVTST ;(↑) RETURN ADDRESS FOR RDCHRS
;ASKMDE ;(↑Z) RETURN ADDRESS FOR RDCHRS
;SETPRM ;(↑U) OR ERROR RETURN ADDR. FOR RDCHRS
CMP RO, #4 ;SEE IF AT LEAST 4 CHARACTERS TYPED
BGE 6$ ;BR IF AT LEAST 4 TYPED
4$: TYPE ,BUFFO ;ECHO BAD INPUT
TYPE ,SQUES ;TYPE (?) AND <CR>, <LF>
BR SETPRM ;BR TO ASK FOR INPUT AGAIN
6$: CMP RO, #11. ;SEE IF ELEVEN OR LESS CHARS TYPED
BGT 4$ ;BR IF MORE THAN ELEVEN TYPED
;SEE IF THIS MNEMONIC RESIDES IN PARAM MNEMONIC TABLE
CLR R1 ;INITIALIZE PARAMETER INDEX
8$: CMP BUFFO, PRMNEM(R1) ;TRY TO MATCH 2-CHAR MNEMONIC
BEQ 10$ ;BR IF PARAMETER FOUND IN TABLE
ADD #2, R1 ;INCREMENT INDEX
MOV R1, R2 ;GET COPY OF INDEX
ADD #PRMLST, R2 ;SEE IF ALL ENTRIES HAVE BEEN CHECKED
CMP #PRDFLT, R2
BNE 8$ ;BR IF MORE TO CHECK YET
BR 4$ ;BR TO ECHO BAD INPUT
;CHECK FOR VALID LINE FORMAT
10$: MOV #2, R2 ;INITIALIZE BUFFER POINTER
CMPB #'=, BUFFO(R2) ;SEE IF NEXT CHAR IS "="
BEQ 12$ ;BR IF IT IS "="
CMPB #040, BUFFO(R2) ;SEE IF NEXT CHAR IS A SPACE
BNE 4$ ;BR TO ECHO BAD INPUT
INC R2 ;INCREMENT BUFFER POINTER
CMPB #'=, BUFFO(R2) ;SEE IF NEXT CHAR IS "="
BNE 4$ ;BR TO ECHO INVALID INPUT
12$: INC R2 ;INCREMENT BUFFER POINTER
CMP R2, RO ;SEE IF MORE CHARS LEFT IN BUFFER
BGE 4$ ;BR TO ECHO INVALID INPUT
CMPB #040, BUFFO(R2) ;SEE IF NEXT CHARACTER IS SPACE

```

```

5358 017142 001003      BNE 14$      ;BR IF NOT A SPACE
5359 017144 005202      INC R2      ;INCREMENT BUFFER POINTER
5360 017146 020200      CMP R2,R0  ;SEE IF MORE CHARS LEFT IN BUFFER
5361 017150 002321      BGE 4$      ;BR IF NONE LEFT
5362 017152 160200      14$: SUB R2,R0 ;SUBTRACT POINTER FROM CHAR COUNT
5363 017154 020027 000010  CMP R0,#10 ;SEE HOW MANY CHARS LEFT
5364 017160 003315      BGT 4$      ;BR IF TOO MANY LEFT
5365                      ;CHECK FOR LEGAL PARAMETER VALUE
5366 017162 062702 005264  ADD #BUFF0,R2 ;GET ADDRESS OF DIGITS
5367 017166 010246      MOV R2,-(SP) ;PUT IT ON STACK FOR OCTBIN
5368 017170 004737 054500  JSR PC,OCTBIN ;CHECK DIGITS AND CONVERT TO BINARY
5369 017174 017014      4$          ;ERROR RETURN ADDR. FOR OCTBIN
5370 017176 012637 005470  MOV (SP)+,LOWOCT ;GET LOW BINARY BITS
5371 017202 013737 054632 005472  MOV $HIOCT,HIGOCT ;GET HIGH BINARY BITS
5372 017210 004737 035040  JSR PC,CHKPRM ;CHECK VALIDITY OF PARAMETER VALUE
5373 017214 017014      4$          ;ERROR RETURN ADDR. FOR CHKPRM
5374                      ;OPEN USER-DEFINED PATTERN 15 FOR MODIFICATION, IF NECESSARY
5375 017216 004737 034514  JSR PC,MODP15
5376 017222 000662      BR SETPRM   ;RETURN TO ASK FOR ANOTHER PARAMETER
5377
5378
5379
5380                      ;SBTTL TO - RUN (R) TESTS ROUTINE
5381                      ;*THIS ROUTINE IS ENTERED TO SET UP THE RUNNING OF TESTS,
5382                      ;*WHOSE PARAMETERS HAVE BEEN DETERMINED. IT FIRST ASKS
5383                      ;*FOR THE DESIRED NUMBER OF PROGRAM PASSES, AND STORES
5384                      ;*THIS IN $EOPCT FOR THE END OF PASS ROUTINE. THEN, THE
5385                      ;*DRIVE LIST IS SCANNED FOR THE FIRST DESIRED DRIVE, AND
5386                      ;*THE HEADER ON SECTOR 0 IS READ TO GET THE FORMAT FOR THIS
5387                      ;*DRIVE. THIS IS STORED IN THE FORMAT BYTE, AND A JUMP IS
5388                      ;*MADE TO THE FIRST TEST.
5389                      ;*THE END OF PASS ROUTINE RETURNS TO "NEWDRV" TO SELECT
5390                      ;*EACH SUCCESSIVE DRIVE FOR TESTING, UNTIL THE ENTIRE PASS
5391                      ;* (ALL DRIVES) IS COMPLETED.
5392
5393 017224
5394
5395 017224 104401 011003  RUNTST:
5396 017230 004737 034034  ;INPUT THE DESIRED NUMBER OF PROGRAM PASSES
5397 017234 014434      4$: TYPE ENTPAS ;ASK FOR NUMBER OF PASSES
5398 017236 016020      JSR PC,RDCHRS ;READ RESPONSE
5399 017240 017224      DRVTST ;($C) RETURN ADDRESS
5400 017242 005700      ASKMDE ;($Z) RETURN ADDRESS
5401 017244 001403      4$          ;($U) OR ERROR RETURN ADDRESS
5402 017246 022700 000005  TST R0      ;SEE IF NULL INPUT
5403 017252 002005      BEQ 6$      ;GO ASK AGAIN
5404 017254 104401 005264  CMP #5,R0   ;SEE HOW MANY CHARS TYPED
5405 017260 104401 001314  BGE 8$      ;BR IF 5 OR LESS
5406 017264 000757      BR 4$       ;ECHO BAD INPUT
5407 017266 012746 005264  6$: TYPE ,BUFF0 ;GO ASK AGAIN
5408 017272 004737 054500  TYPE $QUES  ;GET BUF ADDR ON STACK FOR OCTBIN
5409 017276 017254      BR 4$       ;CHECK DIGITS AND CONVERT TO BINARY
5410 017300 012637 024006  8$: MOV #BUFF0,-(SP) ;ERROR RETURN ADDRESS FOR OCTBIN
5411 017304 001763      JSR PC,OCTBIN ;SET DESIRED NO. OF PASSES (1-77777)
5412                      6$          ;BR IF 0, TO ASK AGAIN
5413 017306 005037 001326  ;THIS IS THE ACTUAL START OF A RUN WITH X PASSES
                    STPASS: CLR $PASS ;INIT. THE PASS NUMBER

```

```

5414 017312 112737 000001 003120      MOV      #1,TSTING      ;SET "RUNNING TESTS" FLAG
5415 017320 012737 177777 005500 NEWPAS:  MOV      #177777,DRIVE  ;INITIALIZE DRIVE NO. TO -1
5416 017326 005037 001330      CLR      $DEVCT        ;INIT APT DEVICE COUNT TO 0
5417      ;CHECK DRIVE LIST FOR MORE DRIVES TO TEST ON THIS PASS
5418 017332 012737 000000 177776 NEWDRV:  MOV      #PRO,2#PS      ;RE-ESTABLISH PRIORITY 0
5419 017340 012706 001100      MOV      #STACK,SP     ;RESTORE THE STACK
5420 017344 105037 003130      CLRB    DRVERS        ;CLEAR ERROR COUNT FOR CURRENT DRIVE
5421 017350 005037 005522      CLR      INTCHR        ;CLEAR TTY INPUT BUFFER WORD
5422 017354 005237 005500      INC      DRIVE         ;INCREMENT DRIVE NUMBER
5423 017360 022737 000010 005500      CMP      #10,DRIVE     ;SEE IF DONE WITH THIS PASS
5424 017366 001002      BNE     2$            ;PR IF NOT DONE CHECKING LIST
5425 017370 000137 023754      JMP      DUNPAS        ;JMP IF DONE WITH THIS PASS
5426 017374 013700 005500 2$:      MOV      DRIVE,RO      ;GET NEW DRIVE NUMBER
5427 017400 105760 005610      TSTB   DRVLS1(RO)     ;SEE IF THIS DRIVE IS MARKED IN LIST
5428 017404 001752      BEQ     NEWDRV        ;BR IF NOT MARKED, TO CHECK ANOTHER
5429 017406 105037 001102      CLRB    $TSTNM        ;INIT TEST NUMBER TO 0
5430 017412 005037 001304      CLR      $TIMES        ;INIT ITERATION COUNT
5431 017416 105760 005620 TYPED:  TSTB   DTYLST(RO)     ;SEE IF RK07
5432 017422 001036      BNE     1$            ;BR IF YES
5433 017424 105037 003124      CLRB    TYPFMT        ;ELSE LOAD ALL RK06 PARAM
5434 017430 012737 000624 020036      MOV      #624,LCM6
5435 017436 012737 000631 005736      MOV      #631,PRMLIM+2
5436 017444 012737 000632 005662      MOV      #632,LC
5437 017452 012737 000632 020040      MOV      #632,LSTCYL
5438 017460 012737 000632 005710      MOV      #632,PRDFLT+2
5439 017466 012737 000632 005742      MOV      #632,PRMLIM+6
5440 017474 012737 000400 020042      MOV      #400,HOLD1
5441 017502 012737 000025 020044      MOV      #25,HOLD3
5442 017510 012737 010025 020046      MOV      #10025,HOLD4
5443 017516 000436      BR      3$
5444
5445 017520 152737 000004 003124 1$:      BISB   #B.CDT,TYPFMT ;LOAD RK07 PARAMETERS
5446 017526 012737 001450 020036      MOV      #1450,LCM6
5447 017534 012737 001455 005736      MOV      #1455,PRMLIM+2
5448 017542 012737 001456 005662      MOV      #1456,LC
5449 017550 012737 001456 020040      MOV      #1456,LSTCYL
5450 017556 012737 001456 005710      MOV      #1456,PRDFLT+2
5451 017564 012737 001456 005742      MOV      #1456,PRMLIM+6
5452 017572 012737 001000 020042      MOV      #1000,HOLD1
5453 017600 012737 002025 020044      MOV      #2025,HOLD3
5454 017606 012737 012025 020046      MOV      #12025,HOLD4
5455
5456 017614 3$:      TSTB   HDALI          ;ARE WE DOING JUST HEAD-ALIGNMENT?
5457      BEQ     13$         ;YES, SKIP NEXT
5458      TSTB   HDALI+1    ;WHICH RETURN
5459      BMI     29$       ;SECOND RETURN
5460      JMP     2#INTGO   ;GO TO ALIGNMENT CODE
5461      JMP     2#INTGON  ;GO TO AUTO ALIGNMENT CODE
5462 017614 010037 001332 29$:     JMP     RD,$UNIT      ;SET DRV NO FOR APT
5463      13$:     ;READ THE HEADER ON SECTOR 0, TRACK 0, CYL 0, AND GET THE DRIVE FORMAT
5464      JSR     PC,INITSS ;INIT. DRIVER PARAMS AND S.S.
5465      MOV     #RDHEAD.P.CMND(R5) ;SET READ HEADER COMMAND
5466      JSR     PC,DRVCAL ;DO READ HEADER
5467      MOV     HOLD3,(R2) ;ISSUE RD HDR WITH FMT BIT = 0
5468      MOV     #BIT7,(R2) ;CHECK FOR C. READY IN CS1
5469

```

5470	017646	001775		BEQ	4\$;BR IF NOT RDY YET
5471	017650	013712	020046	MOV	HOLD4,(R2)		;ISSUE RD HDR WITH FMT BIT = 1
5472	017654	032712	000200	BIT	#BIT7,(R2)		;CHECK FOR C. READY IN CS1
5473	017660	001775		BEQ	6\$;BR IF NOT RDY YET
5474	017662	105037	003125	CLRB	FORMAT		;INITIALIZE FORMAT BYTE TO 0
5475	017666	013737	005674	MOV	S2,FS	005506	;INIT SECTOR LIMITS FOR 22(DEC) SECTOR FMT
5476	017674	013737	005676	MOV	S3,LS	005510	
5477	017702	005762	000024	TST	RKDB(R2)		;POP SILO ONE TIME
5478	017706	032762	001000	BIT	#BIT9,RKDB(R2)	000024	;TEST FORMAT BIT IN HEADER WORD 2
5479	017714	001411		BEQ	8\$;BR IF 22 SECTOR FORMAT
5480	017716	152737	000020	BISB	#B.CFMT,FORMAT	003125	;SET 20 SECTOR FORMAT FOR THIS DRIVE
5481	017724	013737	005670	MOV	S0,FS	005506	;INIT SECTOR LIMITS FOR 20(DEC) SECTOR FMT
5482	017732	013737	005672	MOV	S1,LS	005510	
5483	017740	013737	005704	MOV	ST,STALLS	005502	;SET NUMBER OF UNIT STALLS DESIRED
5484	017746	004737	032310	PC,INITSS			;INIT THE S.S.
5485	017752	004737	041120	JSR	PC,REDBSF		;READ BAD SECTOR FILE FOR THIS DRIVE
5486	017756	113737	005500	MOVB	DRIVE,DRVNO	011131	;GET DRIVE NO.
5487	017764	152737	000060	BISB	#'0,DRVNO	011131	;CONVERT TO ASCII
5488	017772	104401	011112	TYPE	TSTDRN		;TYPE "TESTING DRIVE X"
5489	017776	005737	001326	TST	\$PASS		;SEE IF THIS IS FIRST PASS
5490	020002	001012		BNE	10\$;BR IF NOT FIRST PASS
5491	020004	004737	035344	JSR	PC,DRVSER		;TYPE "DRIVE SER. NO. XXX"
5492	020010	004737	035464	JSR	PC,CRTSER		;TYPE "CART. SER. NO. XXXXXXXXXXXX"
5493	020014	032737	000020	BIT	#BIT4,CS	005702	;SEE IF BAD SECTORS SHOULD BE TYPED
5494	020022	001402		BEQ	10\$;BR IF NOT
5495	020024	004737	041410	JSR	PC,TYPBSF		;TYPE BAD SECTOR FILES
5496	020030	005037	005522	CLR	INTCHR		;INIT. TTY INPUT CHAR BUFFER
5497	020034	000405		BR	TST1		;GO TO FIRST TEST
5498							
5499	020036	000000		LCM6:	0		
5500	020040	000000		LSTCYL:	0		
5501	020042	000000		HOLD1:	0		
5502	020044	000000		HOLD3:	0		
5503	020046	000000		HOLD4:	0		
5504							
5505							
5506							
5507							

5508
5509
5510
5511
5512
5513
5514
5515
5516
5517
5518
5519
5520
5521
5522
5523
5524
5525
5526
5527
5528
5529
5530
5531
5532
5533
5534
5535
5536
5537
5538
5539
5540
5541
5542
5543
5544
5545
5546
5547
5548
5549
5550
5551
5552
5553
5554
5555
5556
5557
5558
5559
5560
5561
5562
5563

```
*****
*TEST 1      OFFSET-TO-FAILURE MEASUREMENTS
*IN THIS TEST A REPEATED PATTERN 072307(OCT) IS WRITTEN INTO ALL
*WORDS OF SECTORS FS AND LS ON TRACKS 0-2 OF CYLINDERS FC AND LC.
*THE SAME SECTORS ON ADJACENT CYLINDERS ARE THEN WRITTEN WITH
* 167230(OCT) (TO ESTABLISH A KNOWN PATTERN) , BUT THEY ARE NOT TESTED.
*THEN, EACH DESIRED SECTOR IS WRITE CHECKED WITH INCREASING POSITIVE
*OFFSETS, UNTIL EITHER A "DATA TYPE" ERROR OCCURS, OR THE FULL RANGE
*OF POSITIVE OFFSETS HAVE BEEN APPLIED. THEN, THE SAME SECTOR IS WRITE
*CHECKED WITH INCREASING NEGATIVE HEAD OFFSETS, UNTIL FAILURE OR
*MAXIMUM NEGATIVE OFFSET IS APPLIED. THIS IS DONE FOR ALL THE SECTORS
*ORIGINALLY WRITTEN, IN THE FOLLOWING ORDER : SECTORS FS AND LS ON
*CYLINDERS FC AND LC FOR TRACK 0, THEN FOR TRACK 1, AND FINALLY FOR
*TRACK 2. THE OFFSET-TO-FAILURE RESULTS ARE REPORTED IN ORDER OF
*INCREASING TRACKS, AS FOLLOWS :
```

```
* OFFSET-TO-FAILURE MEASUREMENTS :
*
* TRACK  CYLN  SECT  +OFST  -OFST
*                (UIN)  (UIN)
*   X     XXX   XX   XXXX   XXXX
*   X     XXX   XX   XXXX   XXXX
*   X     XXX   XX   XXXX   XXXX
*
*                ETC.
```

```
*NOTE: IN AN ADRS 200 DEFAULT RUN, FS DEFAULTS TO 0, AND LS DEFAULTS
*TO 10(DEC), FOR THIS TEST.
```

```
*****
TST1:  SCOPE
      MOV      #1,$TESTN      ;SET TEST NUMBER IN APT MAIL BOX
      JSR      PC,SETUP      ;SET UP FOR LOOP ON ERROR
      JSR      PC,CHKITR     ;SEE IF ITER. NO. = 0 FOR THIS TEST
      JMP      TST2         ;JUMP TO NEXT TEST
;RETURN HERE FROM CHKITR IF TEST SHOULD BE RUN
      JSR      PC,INITSS     ;INITIALIZE DRIVER PARAMS AND SUB-SYS
      JSR      PC,PREPKB     ;PREPARE FOR POSSIBLE KBD INPUT
;INITIALIZE PARAMETERS, WRITE THE SECTORS, AND WRITE CHECK THEM
      TSTB     MDFLAG       ;SEE IF ADRS 200 DEFAULT RUN
      BNE     3$           ;BR IF NOT
      CLR     FS           ;SET FS = 0
      MOV     #10,LS       ;SET LS = 10(DEC)
      MOV     FC,P.CYLN(R5) ;SET CYL = FC
      MOV     FS,P.SECT(R5) ;SET SECTOR = FS
      CLRB    P.TRCK(R5)   ;SET TRACK = 0
      MOV     LC,CYLNDR
      CMP     LSTCYL,LC    ;SEE IF LC = 632/1456
      BNE     4$           ;BR IF NOT 632/1456
      DEC     CYLNDR       ;MAKE IT 631 (PRESERVE BSF)
      MOV     #72307,R3    ;GET DATA PATTERN
      JSR     PC,WRTSEC     ;DO WRITE AND WRITE CHECK
      MOV     #167230,R3   ;DATA FOR AJACENT CYLS
      DEC     P.CYLN(R5)   ;NEXT LOWER CYL
      BMI     6$           ;BR IF CYL NEGATIVE
      JSR     PC,WRTSEC     ;DO WRITE AND WRITE CHECK
      ADD     #2,P.CYLN(R5) ;NEXT HIGHER CYL
      CMP     LSTCYL,P.CYLN(R5) ;SEE IF CYL = 632/1456
```

```
020050 000004
020052 012737 000001 001324
020060 004737 033672
020064 004737 033740
020070 000137 021176
020074 004737 032310
020100 004737 030576
020104 105737 003116
020110 001005
020112 005037 005506
020116 012737 000012 005510
020124 013765 005660 000002 3$:
020132 113765 005506 000004
020140 105065 000005
020144 013737 005662 005504
020152 023737 020040 005662
020160 001002
020162 005337 005504
020166 012703 072307 4$:
020172 004737 037614
020176 012703 167230
020202 005365 000002
020206 100402
020210 004737 037614
020214 062765 000002 6$:
020222 023765 020040 000002
```



```

5564 020230 001004          BNE      8$          ;BR IF NOT
5565 020232 122765 000002 000005  CMPB    #2,P.TRCK(R5) ;SEE IF BSF
5566 020240 001402          BEQ     10$         ;BR IF YES, TO PROTECT IT
5567 020242 004737 037614      8$:     JSR     PC,WRTSEC   ;DO WRITE AND WRITE CHECK
5568 020246 005365 000002      10$:    DEC     P.CYLN(R5) ;RESTORE CYL NO.
5569 020252 105265 000005          INCB    P.TRCK(R5)   ;INCR TRACK
5570 020256 122765 000003 000005  CMPB    #3,P.TRCK(R5) ;TRACK = 3 YET ?
5571 020264 001340          BNE     4$          ;BR IF NOT YET
5572 020266 126537 000004 005510  CMPB    P.SECT(R5),LS ;SEE IF SECTOR = LS
5573 020274 001406          BEQ     14$         ;BR IF YES
5574 020276 113765 005510 000004  MOVB    LS,P.SECT(R5) ;SET SECTOR = LS
5575 020304 105065 000005      12$:    CLRB   P.TRCK(R5)   ;SET TRACK = 0
5576 020310 000726          BR      4$          ;BR TO CONTINUE WRITING
5577 020312 026537 000002 005504  14$:    CMP     P.CYLN(R5),CYLNDR ;SEE IF CYL = LC
5578 020320 001407          BEQ     16$         ;BR IF YES
5579 020322 013765 005504 000002  MOV     CYLNDR,P.CYLN(R5) ;SET CYL = LC
5580 020330 113765 005506 000004  MOVB    FS,P.SECT(R5)   ;SET SECTOR = FS AGAIN
5581 020336 000762          BR      12$        ;BR TO CONTINUE WRITING
5582                                ;INITIALIZE PARAMETERS FOR OFFSET MEASUREMENTS
5583 020340 032737 000002 005702  16$:    BIT     #BIT1,CS   ;SEE IF REPORTS ARE INHIBITED
5584 020346 001002          BNE     18$         ;BR IF INHIBITED
5585 020350 104401 011240          TYPE   OFSHED       ;TYPE HEADINGS
5586 020354 113765 005664 000005  18$:    MOVB    FT,P.TRCK(R5) ;SET TRACK = FT
5587 020362 013765 005660 000002  MOV     FC,P.CYLN(R5)   ;SET CYLINDER = FC
5588 020370 113765 005506 000004  MOVB    FS,P.SECT(R5)   ;SET SECTOR = FS
5589                                ;LOAD THE R/W BUFFER FOR WRITE CHECKS
5590 020376 012700 065660          MOV     #RWBUR,RO     ;SET BUFFER ADDRESS
5591 020402 012701 000400          MOV     #400,R1       ;PREPARE TO LOAD 400(OCT) WORDS
5592 020406 012720 072307      19$:    MOV     #072307,(R0)+ ;LOAD A WORD INTO BUFFER
5593 020412 005301          DEC     R1            ;DECR COUNTER
5594 020414 001374          BNE     19$         ;BR IF NOT DONE YET
5595 020416 005004          CLR     R4           ;INIT (+) OFFSET VALUE
5596 020420 005000          CLR     RO           ;INIT OFFSET NUMBER TO 0
5597 020422 012737 177777 005546  MOV     #-1,PLOFST    ;INITIALIZE CURRENT FAILING (+) OFFSET
5598 020430 012737 177777 005550  MOV     #-1,NGOFST   ;INITIALIZE CURRENT FAILING (-) OFFSET
5599                                ;PERFORM OFFSETS AND WRITE CHECKS
5600 020436 112765 000117 000001  22$:    MOVB    #SEEK,P.CMND(R5) ;SET SEEK COMMAND
5601 020444 004737 042542          JSR     PC,DRVCAL    ;PERFORM SEEK
5602 020450 110065 000006          MOVB    RO,P.OFST(R5) ;SET CURRENT OFFSET
5603 020454 112765 000115 000001  MOVB    #OFFSET,P.CMND(R5) ;SET OFFSET COMMAND
5604 020462 004737 042542          JSR     PC,DRVCAL    ;PERFORM OFFSET
5605 020466 112765 000131 000001  MOVB    #WRTCHK,P.CMND(R5) ;SET WRITE CHECK COMMAND
5606 020474 012737 021142 003046  MOV     #WRCKHD,A.ABNL ;SET SPECIAL ERROR HANDLER ADDRESS
5607 020502 105037 003140          CLRB   WCEFLG       ;CLEAR WRITE CHECK ERROR FLAG
5608 020506 004737 042542          JSR     PC,DRVCAL    ;PERFORM A WRITE CHECK
5609 020512 012737 044200 003046  MOV     #ERRHDL,A.ABNL ;RESTORE ERROR HANDLER ADDRESS
5610 020520 112765 000177 000001  MOVB    #SUBCLR,P.CMND(R5) ;SET SUBSYS CLEAR CMND
5611 020526 004737 042542          JSR     PC,DRVCAL    ;CLEAR THE SUBSYSTEM
5612 020532 112765 000115 000001  MOVB    #OFFSET,P.CMND(R5) ;SET OFFSET CMND
5613 020540 105065 000006          CLRB   P.OFST(R5)   ;SET OFFSET = 0
5614 020544 004737 042542          JSR     PC,DRVCAL    ;OFFSET BACK TO 0
5615 020550 105737 003140          TSTB   WCEFLG       ;SEE IF A WRITE CHECK ERROR OCCURRED
5616 020554 001020          BNE     26$         ;BR IF AN ERROR OCCURRED
5617 020556 010001          MOV     RO,R1       ;GET A COPY OF CURRENT OFFSET
5618 020560 005200          INC     RO           ;INCREMENT OFFSET
5619 020562 062704 000031          ADD     #25.,R4     ;INCR OFFSET VALUE BY 25(DEC) UIN

```

```

5620 020566 042701 177700      BIC      #177700,R1      ;MASK FOR MAGNITUDE BITS
5621 020572 022701 000060      CMP      #60,R1      ;SEE IF MAX OFFSET APPLIED IN THIS DIRECTION
5622 020576 001317                BNE      22$         ;BR IF NOT YET
5623 020600 032700 000200      BIT      #BIT7,RO     ;SEE IF NEG OFFSETS DONE YET
5624 020604 001015                BNE      32$         ;BR IF YES, TO PRINT CURRENT SECTOR RESULT
5625 020606 012700 000200      24$:    MOV      #200,RO  ;INIT FOR NEG OFFSETS
5626 020612 005004                CLR      R4          ;INIT (-) OFFSET VALUE TO 0
5627 020614 000710                BR       22$         ;BR TO APPLY NEG OFFSETS
5628 020616 032700 000200      26$:    BIT      #BIT7,RO     ;SEE IF NEG OFFSETS DONE YET
5629 020622 001403                BEQ      28$         ;BR IF NOT YET
5630 020624 010437 005550      MOV      R4,NGOFST   ;SAVE THIS FAILING (-) OFFSET VALUE
5631 020630 000403                BR       32$         ;BR TO PRINT CURRENT SECTOR RESULT
5632 020632 010437 005546      28$:    MOV      R4,PLOFST  ;SAVE THIS FAILING (+) OFFSET VALUE
5633 020636 000763                BR       24$         ;BR TO APPLY NEGATIVE OFFSETS
5634 020640 032737 000002      005702 32$:    BIT      #BIT1,CS     ;SEE IF REPORTS INHIBITED
5635 020646 001051                BNE      43$         ;BR IF INHIBITED
5636                                ;TYPE OFFSET RESULTS FOR THIS SECTOR
5637 020650 116501 000005      MOV      P.TRCK(R5),R1 ;GET TRACK NO.
5638 020654 010146                MOV      R1,-(SP)    ;PUT IT ON STACK
5639 020656 104403                TYPDS    ;TYPE IT
5640 020660 003                .BYTE    3          ;3 DIGITS
5641 020661 000                .BYTE    0          ;SUPPRESS
5642 020662 104401 013312      TYPE     SPACE3      ;
5643 020666 016546 000002      MOV      P.CYLN(R5),-(SP) ;PUT CYL ON STACK
5644 020672 104403                TYPDS    ;TYPE IT
5645 020674 004                .BYTE    4          ;4 DIGITS
5646 020675 000                .BYTE    0          ;SUPPRESS
5647 020676 104401 013313      TYPE     SPACE2      ;
5648 020702 116501 000004      MOV      P.SECT(R5),R1 ;GET SECTOR
5649 020706 010146                MOV      R1,-(SP)    ;PUT IT ON STACK
5650 020710 104404                TYPON    ;TYPE SECTOR
5651 020712 104401 013314      TYPE     SPACE1      ;
5652 020716 005737 005546      TST      PLOFST      ;SEE IF THERE WAS A FAILING (+) OFFSET
5653 020722 100003                BPL      36$         ;BR IF THERE WAS
5654 020724 104401 011231      TYPE     NOFALS      ;TYPE " NONE"
5655 020730 000403                BR       38$         ;CONTINUE
5656 020732 013746 005546      36$:    MOV      PLOFST,-(SP) ;PUT (+) OFFSET VALUE ON STACK
5657 020736 104405                TYPDS    ;TYPE IT IN DECIMAL
5658 020740 104401 013314      38$:    TYPE     SPACE1      ;
5659 020744 005737 005550      TST      NGOFST      ;SEE IF THERE WAS A FAILING (-) OFFSET
5660 020750 100003                BPL      40$         ;BR IF THERE WAS
5661 020752 104401 011231      TYPE     NOFALS      ;TYPE " NONE"
5662 020756 000403                BR       42$         ;CONTINUE
5663 020760 013746 005550      40$:    MOV      NGOFST,-(SP) ;PUT (-) OFFSET VALUE ON STACK
5664 020764 104405                TYPDS    ;TYPE IT IN DECIMAL
5665 020766 104401 001315      42$:    TYPE     ,SCLF     ;TYPE <CR>,<LF>
5666                                ;SET UP TO TEST NEXT SECTOR
5667 020772 126537 000004      005510 43$:    CMP      P.SECT(R5),LS ;SEE IF SECTOR = LS
5668 021000 001404                BEQ      44$         ;BR IF YES
5669 021002 113765 005510 000004      MOV      LS,P.SECT(R5) ;SET SECTOR = LS
5670 021010 000602                BR       20$         ;GO TEST THIS SECTOR
5671 021012 026537 000002      005504 44$:    CMP      P.CYLN(R5),CYLNDR ;SEE IF CYL = LC
5672 021020 001410                BEQ      48$         ;BR IF YES
5673 021022 013765 005504 000002      MOV      CYLNDR,P.CYLN(R5) ;SET CYL = LC
5674 021030 113765 005506 000004      46$:    MOV      FS,P.SECT(R5) ;SET SECTOR = FS
5675 021036 000137 020416                JMP      20$         ;GO TEST THIS SECTOR

```

```

5676 021042 105265 000005          48$: INCB      P.TRCK(R5)      ; INCREMENT TRACK
5677 021046 122765 000003 000005  CMPB      #3,P.TRCK(R5)    ; SEE IF TRACK = 3
5678 021054 001404          BEQ       50$      ; BR IF YES
5679 021056 013765 005660 000002  MOV      FC,P.CYLN(R5) ; SET CYL = FC
5680 021064 000761          BR       46$      ; GO TEST THIS SECTOR
5681 021066 112765 000113 000001 50$: MOVB     #RECAL,P.CMND(R5) ; SET RECAL COMMAND
5682 021074 004737 042542          JSR      PC,DRVCL  ; DO CLEANUP RECALIBRATE
5683 021100 013737 005674 005506  MOV      S2,FS     ; RESTORE FS,LS FOR 22 SECTORS
5684 021106 013737 005676 005510  MOV      S3,LS
5685 021114 105737 003125          TSTB     FORMAT    ; SEE IF 22 SECTORS
5686 021120 001406          BEQ     54$      ; BR IF YES
5687 021122 013737 005670 005506  MOV      S0,FS     ; RESTORE FS,LS FOR 20 SECTORS
5688 021130 013737 005672 005510  MOV      S1,LS
5689 021136          54$:
5690 021136 000137 021176          JMP      TST2     ; JUMP TO NEXT TEST
5691
5692          ; *THIS IS THE ABNORMAL RETURN FROM THE DRIVER, USED WHEN A
5693          ; * "DATA TYPE" ERROR IS EXPECTED (AND VALID).
5694 021142 032765 040000 000020 WRCKHD: BIT  #WCE,P.CS2(R5) ; SEE IF WRITE CHECK ERROR OCCURRED
5695 021150 001006          BNE     4$       ; BR IF WCE
5696          ; CHECK FOR OTHER "DATA TYPE" ERROR
5697 021152 032765 130400 000034 BIT  #HVRC!DTE!OPI!DCK,P.ER(R5)
5698 021160 001002          BNE     4$       ; BR IF A DATA ERROR OCCURRED
5699 021162 000137 044200          JMP     ERRHDL   ; GO HANDLE OTHER ERROR
5700 021166 105237 003140          4$: INCB     WCEFLG   ; SET WRITE CHECK ERROR FLAG
5701 021172 000137 046356          JMP     RETNML   ; TAKE NORMAL RETURN
5702
5703
5704
5705
5706          ; *****
5707          ; *TEST 2      NPR/MEMORY WORD ADDRESSING TEST
5708          ; *IN THIS TEST, MEMORY WORD ADDRESSING CAPABILITY DURING RK06 NPR'S,
5709          ; *IS TESTED.
5710          ; *BEFORE TESTING BEGINS, THE XXDP LOADER IS SAVED, IF PRESENT, AT ADRS RWBUF.
5711          ; *THEN, STARTING AT THE FIRST ADDRESS OF THE NEXT 1K MEMORY BLOCK
5712          ; *BEYOND ADDRESS RWBUF+6000(OCTAL), WRITE UNIQUE NUMBERS
5713          ; *(STARTING WITH 1), INTO EACH OF UP TO 64K WORDS (DEPENDING UPON THE
5714          ; *AMOUNT OF PHYSICAL MEMORY). THESE NUMBERS REFLECT UNIQUE ADDRESSES
5715          ; *WITHIN THE 64K BLOCK. NEXT, WRITE THE 64K WORDS (MAX) ONTO THE DISK
5716          ; *AT ADDRESS FC,FT,FS (SCALED, IF NECESSARY, TO AVOID PACK OVERFLOW
5717          ; *OR DESTRUCTION OF THE BAD SECTOR FILE). THEN ZERO THE ENTIRE BLOCK
5718          ; *IN MEMORY, AND READ THE DATA BACK FROM THE DISK, AT THE SAME PHYSICAL
5719          ; *ADDRESSES. COMPARE THE DATA READ TO THE DATA WRITTEN. TYPE THE FAILING
5720          ; *VIRTUAL (IF MEM. MGT.) AS WELL AS PHYSICAL ADDRESSES, AND THE GOOD
5721          ; *AND BAD DATA, FOR UP TO THE FIRST 10(DEC) FAILING LOCATIONS.
5722          ; * IF MEMORY MANAGEMENT IS INSTALLED AND THERE IS ADDITIONAL MEMORY TO
5723          ; *EXERCISE, REPEAT THE ABOVE WORD ADDRESSING TEST, FOR EACH OF THE
5724          ; *REMAINING 64K MEMORY BLOCKS.
5725          ; *****
5726 021176 000004          †ST2: SCOPE
5727 021200 012737 000002 001324  MOV     #2,$TESTN ; SET TEST NUMBER IN APT MAIL BOX
5728 021206 004737 033672          JSR     PC,SETUP  ; SET UP FOR LOOP ON ERROR
5729 021212 004737 033740          JSR     PC,CHKITR ; SEE IF ITER. NO. = 0 FOR THIS TEST
5730 021216 000137 021506          JMP     TST3     ; JUMP TO NEXT TEST
5731          ; RETURN HERE FROM CHKITR IF TEST SHOULD BE RUN
5731 021222 004737 032310          JSR     PC,INITSS ; INITIALIZE DRIVER PARAMS AND SUB-SYS

```

```

5732 021226 004737 030576          JSR    PC,PREPKB          ;PREPARE FOR POSSIBLE KBD INPUT
5733                                ;SAVE XXDP LOADER, IF PRESENT
5734 021232 004737 031770          JSR    PC,FNDXDP          ;COMPUTE STARTING ADR OF XXDP
5735 021236 012737 065660 005542  MOV    #RWBUFF,XDPSAV    ;SET XXDP SAVE AREA ADR
5736 021244 005037 005544          CLR    XDPSAV+2
5737 021250 004737 032042          JSR    PC,SAVXDP          ;GO SAVE XXDP LOADER
5738 021254 112737 000001 003133  MOVB   #1,XOVLAD         ;SET INDICATORS
5739 021262 112737 000001 003134  MOVB   #1,XDPSVD
5740 021270 012737 177777 005536  MOV    #-1,PATRN         ;SET FLAG FOR SVPRMS
5741                                ;INIT PARAMETERS, BEGIN TESTING
5742 021276 004737 040644          JSR    PC,SETUPM         ;INIT PARAMS
5743 021302 004737 035270 4$:      JSR    PC,MXWRDC         ;COMPUTE MAX WORD COUNT FOR THIS MA
5744 021306 005701 000000          TST    R1                ;SEE IF ALL MEMORY TESTED YET
5745 021310 100467 000000          BMI    50$               ;BR IF ALL DONE
5746 021312 005065 000012          CLR    P.WC(R5)         ;INIT WORD COUNT TO 65,536(DEC)
5747 021316 005701 000000          TST    R1                ;SEE IF WRD CNT SHOULD BE 65,536
5748 021320 001003 000000          BNE    6$                ;BR IF YES
5749 021322 005400 000000          NEG    R0
5750 021324 010065 000012          MOV    R0,P.WC(R5)      ;SET WORD COUNT
5751 021330 013765 005600 000010 6$:      MOV    MA,P.BALO(R5)    ;SET BA BITS 0-15
5752 021336 013701 005602          MOV    MA+2,R1          ;GET MA BITS 16-21
5753 021342 042701 177774          BIC    #177774,R1      ;MASK FOR LO 2 BITS
5754 021346 150165 000007          BISB   R1,P.BAHI(R5)   ;SET BA BITS 16,17
5755 021352 005737 057732          TST    $K11             ;SEE IF MEM MGT PRESENT
5756 021356 100010 000000          BPL    14$              ;BR IF NOT
5757                                ;SET UP MEM MGT
5758 021360 013737 005600 005604  MOV    MA,PMA           ;SET BUFFER ADDRESS
5759 021366 013737 005602 005606  MOV    MA+2,PMA+2
5760 021374 004737 031646          JSR    PC,PREPAR        ;PREPARE MEM MGT REG'S AND UNIBUS MAP
5761                                ;PERFORM THE TESTS
5762 021400 012737 021400 001110 14$:     MOV    #,$LPERR         ;SET NEW LOOP ON ERROR ADRS
5763 021406 004737 033672          JSR    PC,SETUP         ;SET UP FOR LOOP ON ERROR
5764 021412 004737 042052          JSR    PC,SVPRMS        ;SAVE PARAMS FOR THIS XFER
5765 021416 004737 037710          JSR    PC,LDMEM1        ;LOAD THIS MEM BLK WITH INCREMENTING DATA
5766 021422 112765 000123 000001  MOVB   #WRDATA,P.CMND(R5) ;SET WRITE DATA COMMAND
5767 021430 004737 042164          JSR    PC,TRANSFR       ;WRITE THE DATA
5768 021434 005003 000000          CLR    R3               ;SET DATA WORD = 0
5769 021436 004737 037722          JSR    PC,LDMEM2        ;LOAD MEM BLK WITH ALL ZEROS
5770 021442 112765 000121 000001  MOVB   #RDDATA,P.CMND(R5) ;SET READ COMMAND
5771 021450 004737 042164          JSR    PC,TRANSFR       ;READ THE DATA FROM DISK
5772 021454 004737 040054          JSR    PC,CKMEM1        ;PERFORM SOFTWARE COMPARE OF DATA
5773 021460 104411 000000          SCOPER                  ;CHECK FOR INTERNAL LOOP ON ERROR
5774                                ;GET NEW MA FOR NEXT TRANSFER
5775 021462 004737 041052          JSR    PC,INCRMA        ;COMPUTE NEXT MA
5776 021466 000705 000000          BR     4$               ;GO SEE IF MORE MEMORY TO TEST
5777 021470 004737 032050 50$:      JSR    PC,GETXDP        ;RESTORE XXDP LOADER
5778 021474 105737 003143          TSTB   UBMPRS          ;SEE IF UNIBUS MAP PRESENT
5779 021500 001402 000000          BEQ    54$              ;BR IF NOT
5780 021502 005037 172516          CLR    @#SR3           ;DISABLE UNIBUS MAP
5781 021506
5782
5783
5784
5785
5786
5787

```

```

*****
; *TEST 3      NPR/MEMORY BLOCK ADDRESSING TEST
; *IN THIS TEST, MEMORY BLOCK ADDRESSING CAPABILITY DURING RK06

```

5788
5789
5790
5791
5792
5793
5794
5795
5796
5797
5798
5799
5800
5801
5802
5803
5804
5805
5806
5807
5808
5809
5810
5811
5812
5813
5814
5815
5816
5817
5818
5819
5820
5821
5822
5823
5824
5825
5826
5827
5828
5829
5830
5831
5832
5833
5834
5835
5836
5837
5838
5839
5840
5841
5842
5843

021506 000004
021510 012737 000003 001324
021516 004737 033672
021522 004737 033740
021526 000137 022046

021532 004737 032310
021536 004737 030576

021542 004737 031770
021546 012737 065660 005542
021554 005037 005544
021560 004737 032042
021564 112737 000001 003133
021572 112737 000001 003134
021600 012737 177777 005536

021606 005037 005524
021612 004737 040644
021616 012704 000001
021622 004737 035270
021626 005701
021630 100473
021632 005065 000012
021636 005701
021640 001003
021642 005400
021644 010065 000012
021650 013765 005600 000010
021656 013701 005602
021662 042701 177774
021666 150165 000007
021672 005737 057732
021676 100010

021700 013737 005600 005604
021706 013737 005602 005606
021714 004737 031646
021720 005737 005524
021724 001026

021726 004737 042052

```

; *NPR'S IS TESTED.
; *BEFORE TESTING BEGINS, THE XXDP LOADER IS SAVED, IF PRESENT, AT ADRS RWBUF.
; *MEMORY WILL BE TESTED STARTING AT THE FIRST ADRS OF THE NEXT 1K
; *BLOCK BEYOND RWBUF+6000(OCTAL).
; *THE TEST BEGINS BY WRITING A SINGLE NUMBER INTO ALL LOCATIONS OF
; *EACH MEMORY BLOCK OF UP TO 64K WORDS. THIS NUMBER UNIQUELY DEFINES
; *EACH BLOCK. THEN WRITE EACH BLOCK ONTO DISK AT ADDRESS FC,FS,FT
; *(SCALED, IF NECESSARY TO AVOID PACK OVERFLOW OR DESTRUCTION OF THE BAD
; *SECTOR FILE). ZERO THE BLOCK IN MEMORY, AND THEN READ THE DATA
; *BACK INTO THE PROPER PHYSICAL ADDRESSES. DO THIS FOR ALL 64K BLOCKS,
; *AND THEN COMPARE THE CONTENTS OF ALL THE MEMORY TO EXPECTED VALUES.
; *TYPE FAILURES AS DESCRIBED ABOVE FOR THE FIRST 10(DEC) FAILING
; *LOCATIONS IN EACH 64K MEMORY BLOCK.
; *****
TST3: SCOPE
      MOV      #3,$TESTN      ; SET TEST NUMBER IN APT MAIL BOX
      JSR     PC,SETUP        ; SET UP FOR LOOP ON ERROR
      JSR     PC,CHKITR       ; SEE IF ITER. NO. = 0 FOR THIS TEST
      JMP     TST4            ; JUMP TO NEXT TEST
; RETURN HERE FROM CHKITR IF TEST SHOULD BE RUN
      JSR     PC,INITSS       ; INITIALIZE DRIVER PARAMS AND SUB-SYS
      JSR     PC,PREPKB       ; PREPARE FOR POSSIBLE KBD INPUT
; SAVE XXDP LOADER, IF PRESENT
      JSR     PC,FNDXDP        ; COMPUTE STARTING ADRS OF XXDP
      MOV     #RWBUF,XDPSAV    ; SET XXDP SAVE AREA ADDRESS
      CLR     XDPSAV+2
      JSR     PC,SAVXDP        ; GO SAVE XXDP LOADER
      MOV     #1,XOVLAD        ; SET INDICATORS
      MOV     #1,XDPSVD
      MOV     #-1,PATRN        ; SET FLAG FOR SVPRMS
; INIT PARAMETERS, WRITE AND READ BACK ALL MEMORY BLOCKS
      CLR     SELECT          ; INIT COMPARE FLAG
2$:   JSR     PC,SETUPM        ; INIT PARAMS
      MOV     #1,R4           ; INIT DATA WORD
4$:   JSR     PC,MXWRDC        ; COMPUTE MAX WRD CNT FOR THIS MA
      TST     R1              ; SEE IF ALL MEMORY TESTED YET
      BMI     30$             ; BR IF DONE WRITING AND READING
      CLR     P.WC(R5)        ; INIT WRD CNT TO 65,536(DEC)
      TST     R1              ; SEE IF WRD CNT SHOULD BE 65536
      BNE     6$              ; BR IF YES
      NEG     R0
      MOV     R0,P.WC(R5)     ; SET WORD COUNT
6$:   MOV     MA,P.BALO(R5)   ; SET BA BITS 0-15
      MOV     MA+2,R1         ; GET MA BITS 16-21
      BIC     #177774,R1     ; MASK FOR LO 2 BITS
      BISB   R1,P.BAHI(R5)   ; SET BA BITS 16,17
      TST     $KT11          ; SEE IF MEM MGT PRESENT
      BPL     14$            ; BR IF NO
; SET UP MEMORY MANAGEMENT
      MOV     MA,PMA          ; SET BUFFER ADDRESS
      MOV     MA+2,PMA+2
      JSR     PC,PREPAR       ; PREPARE MEM MGT REG'S AND UNIBUS MAP
14$:  TST     SELECT          ; SEE IF COMPARES SHOULD BE DONE YET
      BNE     20$            ; BR IF YES
; WRITE AND READ THIS MEM BLK ON RK06
16$:  JSR     PC,SVPRMS       ; SAVE PARAMS FOR THIS XFER

```

```

5844 021732 010403      MOV      R4,R3          ;GET DATA WORD
5845 021734 004737 037722 JSR      PC,LDMEM2     ;LOAD MEMORY BLK WITH THIS WORD
5846 021740 112765 000123 000001 MOVB    #WRDATA,P.CMND(R5) ;SET WRITE COMMAND
5847 021746 004737 042164 JSR      PC,TRNSFR     ;WRITE THE DATA
5848 021752 005003      CLR      R3
5849 021754 004737 037722 JSR      PC,LDMEM2     ;ZERO THE BLK IN MEMORY
5850 021760 112765 000121 000001 MOVB    #RDATA,P.CMND(R5) ;SET READ COMMAND
5851 021766 004737 042164 JSR      PC,TRNSFR     ;READ THIS DATA BACK
5852 021772 005204      INC      R4           ;INCREMENT THE DATA WORD
5853 021774 004737 041052 JSR      PC,INCRMA     ;COMPUTE NEW MA TO TRY
5854 022000 000710      BR      4$           ;GO WRITE AND READ NEXT BLK
5855                                     ;PERFORM SOFTWARE COMPARES OF ALL MEMORY BLOCKS
5856 022002 010403      MOV      R4,R3          ;GET DATA WORD
5857 022004 004737 040066 JSR      PC,CKMEM2     ;COMPARE THIS BLK TO GOOD DATA WORD
5858 022010 005204      INC      R4           ;INCREMENT THE DATA WORD
5859 022012 004737 041052 JSR      PC,INCRMA     ;GET NEW MA TO TRY
5860 022016 000701      BR      4$           ;GO COMPARE NEXT MEM BLK
5861
5862 022020 005137 005524 30$:    COM      SELECT     ;COMPLEMENT THE FLAG
5863 022024 001401      BEQ     50$          ;BR IF ALL DONE NOW
5864 022026 000671      BR      2$           ;BR IF COMPARES SHOULD BE DONE NOW
5865 022030 004737 032050 50$:    JSR      PC,GETXDP     ;RESTORE SAVED XXDP
5866 022034 105737 003143 TSTB    UBMPRS        ;SEE IF UNIBUS MAP PRESENT
5867 022040 001402      BEQ     54$          ;BR IF NOT
5868 022042 005037 172516 CLR      2#SR3        ;DISABLE UNIBUS MAP
5869 022046
5870
5871
5872
5873
5874
5875
5876
5877
5878
5879
5880
5881
5882
5883
5884
5885
5886
5887
5888
5889
5890 022046 000004      ST4:    SCOPE
5891 022050 012737 000004 001324 MOV      #4,$TESTN     ;SET TEST NUMBER IN APT MAIL BOX
5892 022056 004737 033672 JSR      PC,SETUP      ;SET UP FOR LOOP ON ERROR
5893 022062 004737 033740 JSR      PC,CHKITR     ;SEE IF ITER. NO. = 0 FOR THIS TEST
5894 022066 000137 022416 JMP      TST5          ;JUMP TO NEXT TEST
5895                                     ;RETURN HERE FROM CHKITR IF TEST SHOULD BE RUN
5896 022072 004737 032310 JSR      PC,INITSS     ;INITIALIZE DRIVER PARAMS AND SUB-SYS
5897 022076 004737 030576 JSR      PC,PREPKB     ;PREPARE FOR POSSIBLE KBD INPUT
5898
5899 022102 004737 031770 JSR      PC,FNDXDP     ;COMPUTE STARTING ADR OF XXDP

```

```

*****
; *TEST 4      NPR/MEMORY DATA PATTERN TEST
; *BEFORE TESTING, THE XXDP LOADER IS SAVED, IF PRESENT, AT ADRS
; *RWBUFF. THEN, ALL PHYSICAL MEMORY LOCATIONS, STARTING AT THE
; *FIRST ADRS OF THE NEXT 1K MEMORY BLOCK BEYOND RWBUF+6000(OCT),
; * ARE EXERCISED WITH UP TO 16 DATA PATTERNS
; * CHOSEN IN PARAMETER PT. (THESE ARE THE SAME PATTERNS
; * PROVIDED FOR USE IN THE READ/WRITE DATA TEST). IF PT = 0, THE
; *DATA PATTERNS WILL DEFAULT TO PATS 08,09,10, AND 11.
; *MEMORY IS EXERCISED IN BLOCKS OF UP TO 64K WORDS, STARTING AT
; *THE FIRST ADDRESS OF THE NEXT 1K MEMORY BLOCK BEYOND THE BUFFER.
; *EACH BLOCK IS LOADED WITH DATA, AND WRITTEN ONTO DISK AT ADDRESS
; *FC,FT,FS (SCALED TO AVOID PACK OVERFLOW OR DESTRUCTION OF THE BAD
; *SECTOR FILE). THEN THE MEMORY BLOCK IS ZEROED AND READ BACK AND
; *COMPARED. THIS IS DONE FOR EACH OF THE DATA PATTERNS CHOSEN,
; *POSSIBLY INCLUDING THE USER-DEFINED PATTERN 15, IF SPECIFIED.
*****

```

```

5900 022106 012737 065660 005542      MOV      #RWBUFF,XDPSAV      ;SET XXDP SAVE AREA ADR
5901 022114 005037 005544      CLR      XDPSAV+2
5902 022120 004737 032042      JSR      PC,SAVXDP          ;GO SAVE XXDP LOADER
5903 022124 112737 000001 003133      MOVVB   #1,XOVLAD          ;SET INDICATORS
5904 022132 112737 000001 003134      MOVVB   #1,XDPSVD
5905 022140 004737 036034      JSR      PC,LODP14         ;GENERATE PSEUDO-RAND PAT 14
5906 022144 013737 005700 005536      MOV      PT,PATRN          ;GET A COPY OF PT
5907 022152 001003          BNE      2$                ;BR IF PT NON-ZERO
5908 022154 012737 007400 005536      MOV      #7400,PATRN       ;SET DEFLT PATRNS = PAT 8,9,10,11
5909          ;INIT PARAMETERS, BEGIN TESTING
5910 022162 004737 040644      2$:      JSR      PC,SETUPM   ;INIT PARAMS
5911 022166 004737 035270      4$:      JSR      PC,MXWRDC   ;COMPUTE MAX WORD COUNT FOR THIS MA
5912 022172 005701          TST      R1                ;SEE IF ALL MEMORY TESTED YET
5913 022174 100501          BMI      50$              ;BR IF ALL DONE
5914 022176 005065 000012      CLR      P.WC(R5)         ;INIT WORD COUNT TO 65,536(DEC)
5915 022202 005701          TST      R1                ;SEE IF WRD CNT SHOULD BE 65,536
5916 022204 001003          BNE      6$                ;BR IF YES
5917 022206 005400          NEG      R0
5918 022210 010065 000012      MOV      R0,P.WC(R5)      ;SET WORD COUNT
5919 022214 013765 005600 000010 6$:      MOV      MA,P.BALO(R5)    ;SET BA BITS 0-15
5920 022222 013701 005602          MOV      MA+2,R1          ;GET MA BITS 16-21
5921 022226 042701 177774          BIC      #177774,R1       ;MASK FOR LO 2 BITS
5922 022232 150165 000007          BISB    R1,P.BAHI(R5)    ;SET BA BITS 16,17
5923 022236 005737 057732          TST      $K+11           ;SEE IF MEM MGT PRESENT
5924 022242 100010          BPL      14$              ;BR IF NOT
5925          ;SET UP MEM MGT

```

```

5926 022244 013737 005600 005604      MOV      MA,PMA      ;SET BUFFER ADDRESS
5927 022252 013737 005602 005606      MOV      MA+2,PMA+2
5928 022260 004737 031646      JSR      PC,PREPAR   ;PREPARE MEM MGT REG'S AND UNIBUS MAP
5929 022264 012704 000001      14$:    MOV      #1,R4   ;SET PATTERN BIT POINTER
5930 022270 030437 005536      16$:    BIT      R4,PATRN ;SEE IF THIS PATTERN IS CHOSEN
5931 022274 001003      BNE      20$         ;BR IF YES
5932 022276 006304      18$:    ASL      R4     ;SHIFT TO POINT TO NEXT PATTERN
5933 022300 001434      BEQ      24$         ;BR IF NO MORE LEFT TO CHECK
5934 022302 000772      BR       16$         ;GO CHECK FOR ANOTHER PATTERN
5935 022304 010401      20$:    MOV      R4,R1   ;GET A COPY OF BIT POINTER
5936      :PERFORM THE TESTS
5937 022306 012737 022306 001110      22$:    MOV      #,$LPERR ;SET NEW LOOP ON ERROR ADRS
5938 022314 004737 033672      JSR      PC,SETUP    ;SET UP FOR LOOP ON ERROR
5939 022320 004737 042052      JSR      PC,SVPRMS   ;SAVE THE PARAMS FOR THIS XFER
5940 022324 004737 036250      JSR      PC,LODBUF   ;LOAD THIS MEM BLK WITH SELECTED DATA
5941 022330 112765 000123 000001      MOVVB   #WRDATA,P.COMND(R5) ;SET WRITE DATA COMMAND
5942 022336 004737 042164      JSR      PC,TRANSFR ;WRITE THE DATA
5943 022342 005003      CLR      R3         ;SET DATA WORD = 0
5944 022344 004737 037722      JSR      PC,LDMEM2  ;LOAD MEM BLK WITH ALL ZEROS
5945 022350 112765 000121 000001      MOVVB   #RDATA,P.COMND(R5) ;SET READ COMMAND
5946 022356 004737 042164      JSR      PC,TRANSFR ;READ THE DATA FROM DISK
5947 022362 004737 036476      JSR      PC,CMPBUF  ;PERFORM SOFTWARE COMPARE OF DATA
5948 022366 104411      SCOPER   ;CHECK FOR INTERNAL LOOP ON ERROR
5949 022370 000742      BR       18$         ;CHECK FOR NEXT PATTERN
5950      :GET NEW MA FOR NEXT TRANSFER
5951 022372 004737 041052      24$:    JSR      PC,INCRMA ;COMPUTE NEXT MA
5952 022376 000673      BR       4$         ;GO SEE IF MORE MEMORY TO TEST
5953 022400 004737 032050      50$:    JSR      PC,GETXDP ;RESTORE XXDP LOADER
5954 022404 105737 003143      TSTB    UBMPRS     ;SEE IF UNIBUS MAP PRESENT
5955 022410 001402      BEQ      54$         ;BR IF NOT PRESENT
5956 022412 005037 172516      CLR     2#SR3     ;DISABLE UNIBUS MAP
5957 54$:

```

5958
5959
5960
5961
5962
5963
5964
5965
5966
5967
5968
5969
5970
5971
5972
5973
5974
5975
5976
5977
5978
5979
5980
5981

```

:*****
: *TEST 5 UNIBUS CONTENTION TEST
: *THE PURPOSE OF THIS TEST IS TO EXERCISE THE NPR CONTROL LOGIC
: *WITHIN THE CONTROLLER IN SUCH A MANNER THAT A CONTENTION FOR
: *UNIBUS CYCLES ARISES BETWEEN THE PROCESSOR AND THE RK06.
: *
: *FIRST, A WRITE DATA IS BEGUN AT ADDRESS FC,FT,SECTOR 0, WITH
: *THE BUS ADDRESS INCREMENT INHIBIT BIT (BAI) SET IN THE CONTROLLER.
: *USING A WORD COUNT OF 12000(OCT) OR 13000(OCT) (DEPENDING ON THE
: *FORMAT), THE ENTIRE TRACK IS WRITTEN WITH THE FIRST WORD OF PATTERN
: *15 (IF SELECTED) OR THE FIRST WORD OF PAT 13 (BY DEFAULT).
: * THEN, AN INSTRUCTION LOOP IS ENTERED IN WHICH A NON-
: *EXISTENT UNIBUS DEVICE ADDRESS IS REFERENCED ONCE PER PASS. THIS
: *WILL RESULT IN A PROCESSOR SIEZURE OF THE UNIBUS, FOR 5-20 USEC,
: *(DEPENDING ON THE PROCESSOR), FOLLOWED BY A NON-EXISTENT MEMORY
: *PROCESSOR TRAP, ONCE PER PASS. THUS, FOR EACH PASS THROUGH THE
: *INSTRUCTION LOOP THE CONTROLLER IS FORCED TO LOSE FROM ONE
: *TO FOUR NPR BUS CYCLES. THE EXECUTION TIME OF THE LOOP DETERMINES THE
: *REPETITION RATE OF THE NON-EXISTENT MEMORY REFERENCES, AND THIS
: *IS CHOSEN TO ALLOW ENOUGH NPR'S SO THAT THERE SHOULD BE NO
: *DATA LATE ERRORS IN A FAULT-FREE CONTROLLER.

```



```

5982
5983
5984
5985
5986
5987
5988
5989
5990
5991 022416 000004
5992 022420 012737 000005 001324
5993 022426 004737 033672
5994 022432 004737 033740
5995 022436 000137 022722
5996
5997 022442 004737 032310
5998 022446 004737 030576
5999
6000 022452 013765 005660 000002
6001 022460 113765 005664 000005
6002 022466 105065 000004
6003 022472 012765 165000 000012
6004 022500 105737 003125
6005 022504 001403
6006 022506 012765 166000 000012
6007 022514 052765 100000 000014
6008
6009 022522 012700 006776
6010 022526 005737 005700
6011 022532 100402
6012 022534 012700 006676
6013 022540 012701 000020 14$:
6014 022544 012703 000070
6015 022550 010065 000010 16$:
6016 022554 105037 003141
6017 022560 112737 000001 003142
6018 022566 112765 000123 000001
6019 022574 004737 040750
6020 022600 105737 003141
6021 022604 001011
6022 022606 032737 000002 005474
6023 022614 001042
6024 022616 112765 000131 000001
6025 022624 004737 042542
6026
6027 022630 012765 065660 000010
6028 022636 005037 065660
6029 022642 112765 000121 000001
6030 022650 004737 040750
6031 022654 105737 003141
6032 022660 001014
6033 022662 022037 065660
6034 022666 001411
6035 022670 004737 043720
6036 022674 016037 177776 001174
6037 022702 013737 065660 001176

```

```

; *THE DATA IS THEN WRITE CHECKED FOR VERIFICATION, AND THE ABOVE
; *TEST IS REPEATED USING A READ DATA COMMAND. NO ERRORS ARE EXPECTED.
; *
; *THE ABOVE OPERATIONS ARE REPEATED 15 MORE TIMES, USING THE NEXT WORD
; *OF THE PROPER PATTERN (13 OR 15) EACH TIME, TO WRITE AND READ
; *THE ENTIRE TRACK. IF A DATA LATE ERROR OCCURS ON A GIVEN TRANSFER,
; *THAT DATA IS NOT WRITE-CHECKED OR COMPARED.

```

```

; *****
; TSTS: SCOPE
; MOV #5, $TESTN ; SET TEST NUMBER IN APT MAIL BOX
; JSR PC, SETUP ; SET UP FOR LOOP ON ERROR
; JSR PC, CHKITR ; SEE IF ITER. NO. = 0 FOR THIS TEST
; JMP TST6 ; JUMP TO NEXT TEST
; RETURN HERE FROM CHKITR IF TEST SHOULD BE RUN
; JSR PC, INITSS ; INITIALIZE DRIVER PARAMS AND SUB-SYS
; JSR PC, PREPKB ; PREPARE FOR POSSIBLE KBD INPUT
; INITIALIZE PARAMETERS
; MOV FC, P.CYLN(R5) ; SET CYL = FC
; MOV FT, P.TRCK(R5) ; SET TRACK = FT
; CLRB P.SECT(R5) ; SET SECTOR = 0
; MOV #-13000, P.WC(R5) ; INIT WORD COUNT FOR FULL TRACK
; TSTB FORMAT ; DETERMINE THE FORMAT
; BEQ 4$ ; BR IF 22 SECTORS
; MOV #-12000, P.WC(R5) ; SET WORD COUNT FOR FULL TRACK
; BIS #DTBARI, P.PRST(R5) ; SET BUS ADDRESS INCREMENT INHIBIT
; WRITE DATA WITH ALLOWABLE UNIBUS CONTENTION, AND WRITE CHECK IT
; MOV #PAT15, R0 ; SET DATA PATTERN ADDRESS
; TST PT ; SEE IF USER-DEFINED PATTERN 15 SELECTED
; BMI 14$ ; BR IF YES
; MOV #PAT13, R0 ; SET DATA PATTERN 13 ADDRESS
; MOV #16, R1 ; SET COUNTER = 16
; MOV #70, R3 ; SET NON-EXISTENT MEMORY TIMER
; MOV R0, P.BALO(R5) ; SET BA BITS
; CLRB DLFLG ; CLEAR DATA LATE FLAG
; MOVB #1, NORTRY ; SET "NO-RETRY" FLAG
; MOVB #WRDATA, P.CMND(R5) ; SET WRITE DATA COMMAND
; JSR PC, REFNEM ; WRITE DATA DURING NEM REF.
; TSTB DLFLG ; SEE IF DATA LATE ERROR OCCURRED
; BNE 18$ ; BR IF NOT
; BIT #BSERR, RECODE ; SEE IF BAD SECTOR ERROR
; BNE 24$ ; BR IF YES
; MOVB #WRTCHK, P.CMND(R5) ; SET WRITE CHECK COMMAND
; JSR PC, DRVCAL ; DO WRITE CHECK
; READ DATA WITH ALLOWABLE UNIBUS CONTENTION, AND COMPARE LAST WORD
; MOV #RWBUFF, P.BALO(R5) ; SET BA = RWBUF ADDRESS
; CLR RWBUF ; CLEAR THE BUFFER WORD
; MOVB #RDATA, P.CMND(R5) ; SET READ COMMAND
; JSR PC, REFNEM ; READ DATA DURING NEM REF.
; TSTB DLFLG ; SEE IF DATA LATE ERROR OCCURRED
; BNE 20$ ; BR IF YES
; CMP (R0)+, RWBUF ; COMPARE LAST DATA WORD
; BEQ 20$ ; BR IF EQUAL
; JSR PC, REPSUP ; GATHER STATUS FOR PRINTOUT
; MOV -2(R0), $REG5 ; GOOD DATA WORD
; MOV RWBUF, $REG6 ; BAD DATA WORD

```

```

6038 022710 104110
6039
6040 022712 005301
6041 022714 001402
6042 022716 000137 022550
6043 022722
6044
6045
6046
6047
6048
6049
6050
6051
6052
6053
6054
6055
6056
6057
6058
6059
6060
6061
6062
6063
6064
6065
6066
6067
6068
6069
6070
6071
6072
6073
6074 022722 000004
6075 022724 012737 000006 001324
6076 022732 004737 033672
6077 022736 004737 033740
6078 022742 000137 023742
6079
6080 022746 004737 032310
6081 022752 004737 030576
6082
6083 022756 013703 005660
6084 022762 005004
6085 022764 012700 003234
6086 022770 020310
6087 022772 001006
6088 022774 005203
6089 022776 020337 020040
6090 023002 103767
6091 023004 000137 023742
6092 023010 062700 000004
6093 023014 020027 004224

```

```

ERROR 110 ;"READ ERROR WHILE BAI SET"
;SET UP FOR NEXT PASS THROUGH LOOP
20$: DEC R1 ;SEE IF ALL DONE YET
BEQ 24$ ;BR IF YES
JMP 16$ ;JUMP TO CONTINUE TESTING
24$:

```

```

*****
;TEST 6 MULTI-DRIVE INTERFERENCE TEST
;THIS TEST PERFORMS MULTI-DRIVE POSITIONING OPERATIONS, WHILE A
;LARGE DATA TRANSFER IS IN PROGRESS ON THE DRIVE UNDER TEST, FOR
;THE PURPOSE OF DETECTING PROBLEMS OF CONCURRENT DRIVE OPERATION.
;THE TEST IS RUN ONLY IF THERE IS MORE THAN 1 DRIVE ON THE SUBSYSTEM.
;
;THE TEST PROCEEDS AS FOLLOWS : IT IS FIRST DETERMINED WHICH DRIVE(S)
;(BESIDE THE ONE UNDER TEST) EXIST AND ARE OPERATIONAL. THESE DRIVES
;ARE THEN CLEARED AND A SEEK TO CYL 0 IS DONE ON EACH. NEXT, A SEEK IS
;DONE TO CYLINDER FC (SCALED, IF NECESSARY) ON THE DRIVE UNDER
;TEST. A SEEK IS NOW BEGUN ON EACH OF THE OTHER DRIVES, EACH
;TO A DIFFERENT PSEUDO-RANDOM CYLINDER ADDRESS, THIS SHOULD REQUIRE
;FROM 10-67 MILLI-SEC TO COMPLETE. AS SOON AS THESE SEEKS ARE BEGUN,
;A WRITE DATA COMMAND IS BEGUN ON THE DRIVE UNDER TEST AT THE CURRENT
;CYLINDER (FC), SECTOR 0, TRACK 0, WITH THE BUS ADDRESS INCREMENT
;INHIBIT BIT SET IN THE CONTROLLER, AND WITH A WORD COUNT OF 15,616
;(DEC) WORDS IF 20 SECTOR FORMAT OR 17,152(DEC) WORDS IF 22 SECTOR
;FORMAT. THIS WORD COUNT AMOUNTS TO A FULL CYLINDER + 1 SECTOR OF DATA.
;THIS TRANSFER REQUIRES FROM 101-126 MILLI-SEC TO COMPLETE, AND IN
;THAT TIME, ALL THE OTHER DRIVES SHOULD HAVE COMPLETED POSITIONING.
;NEXT, A WRITE CHECK IS DONE TO VERIFY THE DATA WRITTEN ON THE DRIVE
;UNDER TEST, AND A CHECK IS MADE TO INSURE THAT ALL OTHER DRIVES WHICH
;PERFORMED SEEKS WERE ABLE TO COMPLETE THEM SUCCESSFULLY, BY CHECKING
;ATTENTION BITS AND COMPARING DRIVE CYLINDER ADDRESSES TO EXPECTED
;VALUES.
*****

```

```

;*****
;TST6: SCOPE
MOV #6, $TESTN ;:SET TEST NUMBER IN APT MAIL BOX
JSR PC, SETUP ;:SET UP FOR LOOP ON ERROR
JSR PC, CHKTR ;:SEE IF ITER. NO. = 0 FOR THIS TEST
JMP SEOP ;:JUMP TO END-OF-PASS ROUTINE
;RETURN HERE FROM CHKTR IF TEST SHOULD BE RUN
JSR PC, INITSS ;:INITIALIZE DRIVER PARAMS AND SUB-SYS
JSR PC, PREPKB ;:PREPARE FOR POSSIBLE KBD INPUT
;SEARCH BAD SECTOR FILES FOR 2 ADJACENT ERROR-FREE CYLS TO USE
MOV FC, R3 ;:GET FC
40$: CLR R4
42$: MOV #BSSOFT+10, R0 ;:POINTER TO SOFTWARE BSF
52$: CMP R3, (R0) ;:SEE IF THIS CYL LISTED
BNE 44$ ;:BR IF NOT
INC R3 ;:INCR CYL
CMP R3, LSTCYL ;:SEE IF CYL < 632/1456
BLO 40$ ;:BR IF YES
JMP MULT1 ;:GO SKIP THIS TEST
44$: ADD #4, R0 ;:INCR BSF POINTER
CMP R0, #BSFACT ;:SEE IF STILL IN SOFTWARE BSF

```

```

6094 023020 001002          BNE      46$          ;BR IF YES
6095 023022 062700 000010  ADD      #10,R0      ;INCR POINTER FOR FACTORY BSF
6096 023026 020027 005224  46$:    CMP      R0,#BSFACT+512. ;SEE IF END OF FACTORY BSF REACHED
6097 023032 001356          BNE      52$          ;BR IF NOT YET
6098 023034 005704          TST      R4          ;SEE IF CAME HERE BEFORE
6099 023036 001003          BNE      50$          ;BR IF YES
6100 023040 005204          INC      R4          ;
6101 023042 005203          INC      R3          ;INC CYL
6102 023044 000747          BR       42$          ;CONTINUE LOOKING
6103 023046 005303          50$:    DEC      R3          ;DECR CYL
6104 023050 010337 003202  MOV      R3,CYL      ;GET CYL TO USE
6105          ;CHECK DRVLST FOR OTHER AVAILABLE DRIVES, AND RECALIBRATE THEM
6106 023054 112765 000117 000001  MOVB    #SEEK,P.CMND(R5) ;SET SEEK COMMAND
6107 023062 005001          CLR      R1          ;INIT MULTIPLE-DRIVES FLAG
6108 023064 005000          CLR      R0          ;INIT DRIVE NO. TO 0
6109 023066 005065 000002          CLR      P.CYLN(R5) ;SET CYL = 0
6110 023072 022700 000010  4$:    CMP      #10,R0      ;SEE IF ALL DRIVES CHECKED YET
6111 023076 001415          BEQ      8$          ;BR IF ALL DONE
6112 023100 105760 005610          TSTB    DRVLST(R0)   ;SEE IF THIS DRIVE IS MARKED IN LIST
6113 023104 001410          BEQ      6$          ;BR IF NOT MARKED
6114 023106 120037 005500          CMPB    R0,DRIVE     ;SEE IF MARKED DRIVE IS DRIVE UNDER TEST
6115 023112 001405          BEQ      6$          ;BR IF YES
6116 023114 110065 000000          MOVB    R0,P.DRVN(R5) ;SET DRIVE NO. PARAMETER
6117 023120 004737 023624          JSR     PC,TSTTYP    ;SEEK TO CYL 0 ON CURRENT DRIVE
6118 023124 005201          INC      R1          ;SET FLAG TO INDICATE MORE THAN 1 DRIVE
6119 023126 005200          6$:    INC      R0          ;INCR DRIVE NO.
6120 023130 000760          BR       4$          ;KEEP CHECKING DRIVES
6121 023132 005701          8$:    TST      R1          ;SEE IF MORE THAN 1 DRIVE PRESENT
6122 023134 001002          BNE      9$          ;BR IF YES, TO RUN TEST
6123 023136 000137 023742          JMP     MULTII       ;NO SKIP TEST
6124          ;SEEK TO CYLINDER CYL ON DRIVE UNDER TEST, SET PARAMS FOR DATA XFER
6125 023142 004737 032310  9$:    JSR     PC,INITSS  ;INIT S.S.
6126 023146 013765 003202 000002  MOV      CYL,P.CYLN(R5) ;SET CYLNR = CYL
6127 023154 005065 000004          CLR      P.SECT(R5)  ;SET TRACK AND SECTOR = 0
6128 023160 012765 136400 000012  MOV      #-17152.,P.WC(R5) ;SET WC FOR 67(DEC) SECTORS
6129 023166 105737 003125          TSTB    FORMAT      ;CHECK THE FORMAT
6130 023172 001403          BEQ      12$         ;BR IF 22-SECTOR FORMAT
6131 023174 012765 141400 000012  MOV      #-15616.,P.WC(R5) ;SET WC FOR 61(DEC) SECTORS
6132 023202 012765 006676 000010  12$:   MOV      #PAT13,P.BALO(R5) ;SET BA BITS
6133 023210 052765 100000 000014  BIS      #DTBAIL,P.PRST(R5) ;SET BUS ADDRESS INCREMENT INHIBIT
6134 023216 112765 000117 000001  MOVB    #SEEK,P.CMND(R5) ;SET SEEK COMMAND
6135 023224 004737 042542          JSR     PC,DRVCAL    ;SEEK TO CYL ON DRIVE UNDER TEST
6136          ;DO PSEUDO-RANDOM SEEKS ON ALL OTHER DRIVES
6137 023230 105037 003120          CLRB    TSTING      ;INHIBIT ↑C, ↑Z ESCAPE
6138 023234 012701 000007          MOV      #7,R1      ;SET LOOP COUNTER
6139 023240 012700 003204          MOV      #CYLLST,R0 ;ADRS OF RAND CYL LIST
6140 023244 004737 035666          JSR     PC,RNDADR    ;GENERATE A PSEUDO-RANDOM CYL NO.
6141 023250 042737 177145 005504  BIC      #177145,CYLNR ;ALWAYS KEEP UNDER 632
6142 023256 013720 005504          MOV      CYLNR,(R0)+ ;SET CYL NO. IN TABLE
6143 023262 001002          BNE      16$         ;BR IF NOT 0
6144 023264 005260 177776          INC      -2(R0)     ;MAKE IT NON-ZERO
6145 023270 005301          16$:   DEC      R1          ;DECREMENT LOOP COUNTER
6146 023272 001364          BNE      15$         ;BR IF NOT DONE LOADING LIST YET
6147 023274 012701 003204          MOV      #CYLLST,R1 ;GET ADRS OF RAND CYL TABLE
6148 023300 010537 023372          MOV      R5,19$     ;SET PARAM BLK ADRS FOR DRIVER
6149 023304 005000          CLR      R0          ;INIT DRIVE NO. TO 0

```

```

6150 023306 022700 000010      18$:  CMP      #10,R0      ;SEE IF ALL DRIVES CHECKED YET
6151 023312 001432              BEQ      22$      ;BR IF YES
6152 023314 105760 005610      TSTB    DRVLST(R0) ;SEE IF THIS DRIVE PRESENT
6153 023320 001425              BEQ      20$      ;BR IF NO
6154 023322 120037 005500      CMPB    R0,DRIVE  ;SEE IF THIS IS DRIVE UNDER TEST
6155 023326 001422              BEQ      20$      ;BR IF YES
6156 023330 110065 000000      MOVB    R0,P.DRVN(R5) ;SET DRIVE NO. PARAMETER
6157 023334 012165 000002      MOV     (R1)+,P.CYLN(R5) ;SET CYLINDER NO.
6158 023340 004737 042622      JSR     PC,STACMD  ;STORE PREV AND CURRENT CMNDS
6159 023344 105760 005620      TSTB    DTYLST(R0) ;SEE IF RK06
6160 023350 001404              BEQ      1$      ;BR IF YES
6161 023352 152765 000004 000007  BISB    #B.CDT,P.CS1H(R5) ;ELSE SET FOR RK07
6162 023360 000402              BR      2$      ;
6163 023362 105065 000007      1$:  CLRB    P.CS1H(R5)
6164 023366 004737 052604      2$:  JSR     PC,C.INIT ;GO START SEEK ON THIS DRIVE
6165 023372 000000              19$:  .WORD   ;P.B. ADRS GOES HERE
6166 023374 005200              20$:  INC     R0      ;INCR DRIVE NO.
6167 023376 000743              BR      18$     ;BR TO SEEK ON NEXT DRIVE
6168                                ;WRITE DATA ON DRIVE UNDER TEST WITH BAI SET
6169 023400 112765 000123 000001  22$:  MOVB    #WRDATA,P.CMND(R5) ;SET WRITE DATA COMMAND
6170 023406 113765 005500 000000      MOVB    DRIVE,P.DRVN(R5) ;SET DRIVE NO.
6171 023414 013765 003202 000002      MOV     CYL,P.CYLN(R5) ;SET CYL NO.
6172 023422 012737 023654 003044      MOV     #MULHDL,A.NORM ;SET SPECIAL DRIVER RETURN ADDRESS
6173 023430 113700 005500      MOVB    DRIVE,R0
6174 023434 004737 023624      JSR     PC,TSTTYP ;WRITE 1 CYL + 1 SECTOR AT CYL FC
6175 023440 032737 000002 005474      BIT     #BSERR,RECODE ;SEE IF BSE ERROR
6176 023446 001135              BNE     MULT11   ;BR IF YES
6177 023450 112765 000131 000001      MOVB    #WRTCHK,P.CMND(R5) ;SET WRITE CHECK COMMAND
6178 023456 004737 042542      JSR     PC,DRVCAL ;WRITE CHECK THE DATA WRITTEN
6179                                ;CHECK ATTENTIONS AND CHECK CYLINDER ADDRESSES FROM ALL OTHER DRIVES
6180 023462 112737 000001 003120      MOVB    #1,TSTING ;ALLOW ↑C, ↑Z ESCAPE
6181 023470 112765 000141 000001      MOVB    #R0STAT,P.CMND(R5) ;SET READ DRIVE STATUS COMMAND
6182 023476 012701 003204              MOV     #CYLLST,R1 ;ADRS OF RAND CYL LIST
6183 023502 005000              CLR     R0      ;INIT DRIVE NO.
6184 023504 022700 000010      26$:  CMP     #10,R0   ;SEE IF ALL DRIVES CHECKED YET
6185 023510 001514              BEQ     MULT11   ;BR IF YES
6186 023512 105760 005610      TSTB    DRVLST(R0) ;SEE IF THIS DRIVE MARKED IN LIST
6187 023516 001440              BEQ     32$      ;BR IF NOT
6188 023520 120037 005500      CMPB    R0,DRIVE  ;SEE IF THIS IS DRIVE UNDER TEST
6189 023524 001435              BEQ     32$      ;BR IF YES
6190 023526 136037 003102 003200      BITB    I.DRV(R0),SAVWRD ;SEE IF GOT ATT'N FROM THIS DRIVE
6191 023534 001003              BNE     28$      ;BR IF YES
6192 023536 004737 043720      JSR     PC,REPSUP ;PREPARE STATUS FOR PRINTOUT
6193 023542 104113              ERROR   113     ;"NO ATTENTION ON SEEK"
6194 023544 110065 000000      28$:  MOVB    R0,P.DRVN(R5) ;SET THIS DRIVE NO.
6195 023550 004737 023624      JSR     PC,TSTTYP ;READ STATUS OF THIS DRIVE
6196 023554 016503 000052      MOV     P.B10(R5),R3 ;GET STATUS BYTE B10
6197 023560 006003              ROR     R3      ;GET CYL ADRS RIGHT-JUSTIFIED
6198 023562 006003              ROR     R3
6199 023564 006003              ROR     R3
6200 023566 006003              ROR     R3
6201 023570 042703 177000      BIC     #177000,R3 ;CLEAR OFF UNUSED BITS
6202 023574 022103              CMP     (R1)+,R3 ;COMPARE TO EXPECTED CYLINDER
6203 023576 001410              BEQ     32$      ;BR IF EQUAL
6204 023600 016137 177776 001212      MOV     -2(R1),SREG14 ;GOOD CYL NO.
6205 023606 010337 001214      MOV     R3,SREG15 ;BAD CYL NO.

```

6206 023612 004737 043720
6207 023616 104114
6208 023620 005200
6209 023622 000730
6210
6211
6212
6213 023624 105760 005620
6214 023630 001404
6215 023632 152765 000004 000007
6216 023640 000402
6217 023642 105065 000007
6218 023646 004737 042542
6219 023652 000207
6220
6221
6222
6223
6224 023654 032737 000200 003000
6225 023662 001010
6226 023664 004737 052204
6227 023670 013765 003000 000016
6228 023676 004737 043720
6229 023702 104112
6230 023704 013737 003014 003200
6231 023712 000337 003200
6232 023716 112765 000177 000001
6233 023724 012737 042732 003044
6234 023732 004737 042542
6235 023736 000137 042732
6236
6237 023742
6238
6239
6240
6241
6242
6243
6244
6245
6246
6247
6248
6249 023742
6250 023742 000004
6251 023744 005237 001330
6252 023750 000137 017332
6253 023754
6254 023754 042777 000100 155162
6255 023762 005037 001102
6256 023766 005037 001304
6257 023772 005237 001326
6258 023776 042737 100000 001326
6259 024004 005327
6260 024006 000001
6261 024010 003022

```

JSR PC,REPSUP ;GATHER STATUS FOR PRINTOUT
ERROR 114 ;"DRIVE'S CYLINDER INCORRECT"
32$: INC RD ;INCREMENT DRIVE NO.
BR 26$ ;BR IF NOT DONE WITH ALL DRIVES YET

;THIS ROUTINE TESTS FOR THE DRIVE TYPE AND SETS P.CS1H ACCORDINGLY

TSTTYP: TSTB DTYLST(RD) ;SEE IF RK06
BEQ 1$ ;BR IF YES
BISB #B.CDT,P.CS1H(R5) ;ELSE SETUP FOR RK07
BR 2$
1$: CLR P.CS1H(R5) ;SETUP FOR RK06
2$: JSR PC,DRVCAL
RTS PC

;THIS IS THE NORMAL RETURN FROM THE DRIVER WHICH IS USED TO CHECK
;THE RESULTS OF MULTI-DRIVE OPERATIONS.
MULHDL: BIT #RDY,T.CS1 ;SEE IF CNTRLR RDY IS SET
BNE 6$ ;BR IF RDY SET
JSR PC,I.CSTS ;READ CONTROLLER REGISTERS
MOV T.CS1,P.CS1(R5) ;GET CS1 BITS
JSR PC,REPSUP ;PREPARE STATUS FOR PRINTOUT
ERROR 112 ;"INTRPT WHEN CNTRLR NOT RDY"
6$: MOV T,ASOF,SAVWRD ;SAVE ATT'N SUMMARY
SWAB SAVWRD ;GET ATT'N BITS IN BITS 0-7
MOVB #SUBCLR,P.CMND(R5) ;SET SUBSYSTEM CLEAR COMMAND
MOV #ERRFRE,A.NORM ;RESTORE NORMAL DRIVER RETURN ADDRESS
JSR PC,DRVCAL ;CLEAR SUB-SYS
JMP ERRFRE ;TAKE NORMAL RETURN

```

MULTI1:

.SBTTL END OF PASS ROUTINE

```

;*****
;*INCREMENT THE PASS NUMBER ($PASS)
;*TYPE "END PASS #XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
;*IF THERES A MONITOR GO TO IT
;*IF THERE ISN'T JUMP TO APTPAS

```

\$EOP:

```

SCOPE
INC $DEVCT ;INCREMENT DEVICE COUNT FOR APT
JMP NEWDRV ;GO SEE IF MORE DRIVES TO TEST ON THIS PASS
DUNPAS: ;THIS IS TRULY THE END OF A PASS
BIC #BIT6,$STKS ;DISABLE TTY KBD INTERRUPT
CLR $STNM ;ZERO THE TEST NUMBER
CLR $TIMES ;ZERO THE NUMBER OF ITERATIONS
INC $PASS ;INCREMENT THE PASS NUMBER
BIC #100000,$PASS ;DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;LOOP?
$EOPCT: .WORD 1
BGT $DOAGN ;;YES

```



```

6292 024134 012737 000340 177776 ASTART: MOV #PR7, @#PS
6293 .SBTTL INITIALIZE THE COMMON TAGS
6294 ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
6295 024142 012706 001100 MOV #SCMTAG, R6 ;;FIRST LOCATION TO BE CLEARED
6296 024146 005026 001100 CLR (R6)+ ;;CLEAR MEMORY LOCATION
6297 024150 022706 001140 CMP #SWR, R6 ;;DONE?
6298 024154 001374 001100 BNE -6 ;;LOOP BACK IF NO
6299 024156 012706 001100 MOV #STACK, SP ;;SETUP THE STACK POINTER
6300 ;;INITIALIZE A FEW VECTORS
6301 024162 012737 057170 000020 MOV #SSCOPE, @#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
6302 024170 012737 000340 000022 MOV #340, @#IOTVEC+2 ;;LEVEL 7
6303 024176 012737 056464 000030 MOV #SEAROR, @#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
6304 024204 012737 000340 000032 MOV #340, @#EMTVEC+2 ;;LEVEL 7
6305 024212 012737 060276 000034 MOV #STRAP, @#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
6306 024220 012737 000340 000036 MOV #340, @#TRAPVEC+2 ;;LEVEL 7
6307 024226 012737 057034 000024 MOV #SPWRDN, @#PWRVEC ;;POWER FAILURE VECTOR
6308 024234 012737 000340 000026 MOV #340, @#PWRVEC+2 ;;LEVEL 7
6309 024242 013737 024014 024006 MOV SENDCT, SEOPCT ;;SETUP END-OF-PROGRAM COUNTER
6310 024250 005037 001304 CLR $TIMES ;;INITIALIZE NUMBER OF ITERATIONS
6311 024254 005037 001306 CLR $ESCAPE ;;CLEAR THE ESCAPE ON ERROR ADDRESS
6312 024260 112737 000001 001115 MOV #1, $ERMAX ;;ALLOW ONE ERROR PER TEST
6313 024266 012737 024266 001106 MOV #., $LPADR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
6314 024274 012737 024274 001110 MOV #., $LPERR ;;SETUP THE ERROR LOOP ADDRESS
6315 ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
6316 ;;EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
6317 024302 013746 000004 MOV @#ERRVEC, -(SP) ;;SAVE ERROR VECTOR
6318 024306 012737 024342 000004 MOV #64$, @#ERRVEC ;;SET UP ERROR VECTOR
6319 024314 012737 177570 001140 MOV #DSWR, SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
6320 024322 012737 177570 001142 MOV #DDISP, DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
6321 024330 022777 177777 154602 CMP #-1, @SWR ;;TRY TO REFERENCE HARDWARE SWR
6322 024336 001012 BNE 66$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
6323 ;;AND THE HARDWARE SWR IS NOT = -1
6324 024340 000403 BR 65$ ;;BRANCH IF NO TIMEOUT
6325 024342 012716 024350 64$: MOV #65$, (SP) ;;SET UP FOR TRAP RETURN
6326 024346 000002 RTI
6327 024350 012737 000176 001140 65$: MOV #SWREG, SWR ;;POINT TO SOFTWARE SWR
6328 024356 012737 000174 001142 MOV #DISPREG, DISPLAY
6329 024364 012637 000004 66$: MOV (SP)+, @#ERRVEC ;;RESTORE ERROR VECTOR
6330
6331 024370 005037 001326 CLR $PASS ;;CLEAR PASS COUNT
6332 024374 132737 000200 001341 BITB #APTSIZE, $ENVM ;;TEST USER SIZE UNDER APT
6333 024402 001403 BEQ 67$ ;;YES, USE NON-APT SWITCH
6334 024404 012737 001342 001140 MOV #SSWREG, SWR ;;NO, USE APT SWITCH REGISTER
6335 024412 67$:
6336 024412 005037 003150 CLR AUTOFG ;;CLEAR THE SPECIAL FLAG
6337 .SBTTL RK06 HEAD ALIGNMENT AID
6338 024416 000005 RESET ;;RESET UNIBUS
6339 024420 104401 007036 TYPE , DZR6N ;;TYPE PROGRAM I.D. FOR PART 2
6340 024424 104401 007050 TYPE , SUBVER
6341 024430 104401 007136 TYPE , PART2
6342 024434 012737 000176 001140 MOV #SWREG, SWR ;;ADRS OF SOFTWARE SWR
6343 024442 005077 154472 CLR @SWR ;;MAKE SWR BITS ALL 0
6344 024446 012737 030436 000060 MOV #KBDHDL, @#TKVEC ;;LOAD VECTOR FOR TTY KBD
6345 024454 012737 000200 000062 MOV #PR4, @#TKVEC+2 ;;SET KBD PRIORITY = 4
6346 024462 013701 003040 MOV RKVEC, R1 ;;GET ADDRESS OF VECTOR STORAGE
6347 024466 012721 047304 MOV #I. INTR, (R1)+ ;;SET IT TO INTERRUPT HNDLR

```

```

6348 024472 012711 000340          MOV      #PR7,(R1)          ;SET INTERRUPT HANDLER PR7
6349 024476 012737 000000 177776  MOV      #PRO,@#PS        ;ALLOW ALL INTERRUPTS
6350 024504 012737 000000 005660  MOV      #0,FC            ;SET FIRST CYL = 0
6351
6352 024512                                GIVEID:
6353 024512 012737 176543 054732  MOV      #176543,$HINUM    ;INITIALIZE PSEUDO-RANDOM NUMBERS
6354 024520 012737 123456 054734  MOV      #123456,$LONUM
6355 024526 105037 003116          CLR      MDFLAG           ;CLEAR PARAM INP FLAG
6356 024532 105037 003120          CLR      TSTING          ;CLEAR "RUNNING TESTS" FLAG
6357 024536 005037 005502          CLR      STALLS          ;DON'T STALL ON OPERATIONS
6358 024542 012701 005224          MOV      #PRVCM,D,R1     ;ZERO OUT PREV COMMAND
6359 024546 012700 000006          MOV      #6,R0
6360 024552 005021          42$:  CLR      (R1)+
6361 024554 005300          DEC      R0
6362 024556 001375          BNE     42$
6363 024560 105037 003126          CLR      ERRCNT          ;CLEAR ERROR COUNT FOR RESTARTS
6364 024564 104401 011365          TYPE    ,IDENT          ;TYPE PROGRAM IDENTIFICATION
6365 024570 105737 003145          TSTB   HLPOVL           ;SEE IF HELP FILE OVERLAID
6366                                ; BR IF YES
6367 024574 001011          BNE     ASKMOD           ;ASK FOR ALL DRIVE TYPES
6368 024576 104401 011431          BNE     ASKTYP           ;ASK IF HELP DESIRED
6369 024602 104406          TYPE    ,FORHLP         ;READ RESPONSE
6370 024604 112601          RDCHR   (SP)+,R1        ;GET CHARACTER
6371 024606 122701 000015          CMPB   #015,R1         ;SEE IF <CR> TYPED
6372                                ; BR IF NO HELP NEEDED
6373 024612 001402          BEQ     ASKMOD           ;ASK FOR ALL DRIVE TYPES
6374 024614 104401 066277          BEQ     ASKTYP           ;HELP REQUESTED- TYPE INFO.
6375                                ;TYPE ,HLPFIL
6376 024620 104401 001315          ASKTYP: TYPE ,SCRLF      ;TO ENTER ALL DRIVE TYPES
6377 024624 104401 012554          TYPE   ,DTYMSG          ;MESSAGE TO ENTER DRIVE TYPE
6378 024630 005000          CLR      R0             ;START FROM DRIVE 0
6379 024632 104401 001315          1$:  TYPE   ,SCRLF      ;CR-LF
6380 024636 105037 007530          CLR      BADDRV+6      ;CLEAR THE LOC 6 FOR TYPE
6381 024642 104401 007522          TYPE   ,BADDRV        ;DRIVE
6382 024646 010046          MOV      R0,-(SP)      ;DRIVE NUMBER ON STACK
6383 024650 104402          TPOC   ;TYPE THE DRIVE NUMBER
6384 024652 104401 012576          TYPE   ,SOR7           ;ENTER 6 OR 7
6385 024656 004737 030576          JSR     PC,PREPKB      ;READ THE NUMBER
6386 024662 005737 005522          2$:  TST     INTCHR       ;ANY THING READ IN YET ?
6387 024666 001775          BEQ     2$             ;BRANCH IF NOT
6388 024670 105060 005620          CLR      DTYLST(R0)    ;ASSUME IT'S A RK06
6389 024674 013701 005522          MOV     INTCHR,R1      ;READ THE CH
6390 024700 022701 000067          CMP     #'7,R1         ;IT'S A RK07 ?
6391 024704 001003          BNE     3$             ;BRANCH IF NOT
6392 024706 112760 000004 005620  MOV     #B.CDT,DTYLST(R0) ;SET RK07 FLAG
6393 024714 005200          3$:  INC     R0             ;TO NEXT DRIVE
6394 024716 022700 000007          CMP     #7,R0          ;ALL 8 DRIVES ARE SET UP YET ?
6395 024722 103343          BHIS   1$             ;BRANCH IF NOT
6396
6397                                ;DETERMINE DESIRED OPERATIONAL MODE
6398 024724 104401 011466          ASKMOD: TYPE ,TYPMOD    ;ASK FOR DESIRED OPERATIONAL MODE
6399 024730 004737 030576          JSR     PC,PREPKB      ;PREPARE FOR KBD INPUT
6400 024734 005737 005522          1$:  TST     INTCHR       ;CHECK FOR TTY INPUT
6401 024740 001775          BEQ     1$             ;BR IF NO INPUT YET
6402 024742 013701 005522          MOV     INTCHR,R1      ;GET INPUT CHAR INTO R1
6403 024746 022701 000022          CMP     #022,R1        ;SEE IF (↑R) TYPED

```


6404	024752	001657			BEQ	GIVEID		;BR IF (↑R), TO RESTART
6405	024754	022701	000115		CMP	#'M,R1		;IS IT MANUAL MODE ?
6406	024760	001002			BNE	2\$;BR IF NOT MANUAL
6407	024762	000137	025006		JMP	MANUAL		;JUMP TO MANUAL MODE ROUTINE
6408	024766	022701	000101		2\$:	CMP	#'A,R1	;IS IT AUTO MODE ?
6409	024772	001002			BNE	3\$;BR IF NOT AUTO
6410	024774	000137	026144		JMP	AUTO		;JUMP TO AUTO MODE ROUTINE
6411	025000	004737	030616		3\$:	JSR	PC,ECOBAD	;ECHO BAD INPUT
6412	025004	000747			BR	ASKMOD		;BR TO ASK FOR MODE AGAIN
6413								
6414								
6415								
6416								
6417	025006							
6418	025006	005037	003150					
6419	025012	104401	011527		MANUAL:	CLR	AUTOFG	;CLEAR SPECIAL FLAG
6420	025016	104401	011562		ASKDRV:	TYPE	,TYPMAN	;TYPE "MANUAL SELECT MODE"
6421	025022	004737	030576		JSR	PC,PREPKB		;ASK FOR DRIVE NUMBER
6422	025026	005737	005522		1\$:	TST	INTCHR	;PREPARE FOR KBD INPUT
6423	025032	001775			BEQ	1\$;SEE IF ANY INPUT
6424	025034	013701	005522		MOV	INTCHR,R1		;BR IF NONE TO CHECK AGAIN
6425	025040	020127	000022		CMP	R1,#022		;GET CHARACTER INTO R1
6426	025044	001622			BEQ	GIVEID		;TEST FOR (↑R) TYPED
6427	025046	020127	000060		CMP	R1,#'0		;BR IF (↑R) TO RESTART
6428	025052	002512			BLT	BAIFLU		;COMPARE TO ASCII 0
6429	025054	020127	000067		CMP	R1,#'7		;BR IF <0 (BAD INPUT)
6430	025060	003107			BGT	BAIFLU		;COMPARE TO ASCII 7
6431	025062	042701	000060		BIC	#'0,R1		;BR IF >7 (BAD INPUT)
6432	025066	010137	005500		MOV	R1,DRIVE		;STRIP ASCII BITS
6433	025072	013700	005500		MOV	DRIVE,RO		;STORE DRIVE NUMBER
6434	025076	116037	005620	003124	MOVB	DTYLS(RO),TYPFMT		;AND SET UP TO SIZE DRIVE
6435	025104	012737	000624	020036	MOV	#624,LCM6		;LOAD THE FLAG FOR 6 OR 7
6436	025112	012737	000631	005736	MOV	#631,PRMLIM+2		
6437	025120	012737	000632	005662	MOV	#632,LC		
6438	025126	012737	000632	005710	MOV	#632,PRDFLT+2		
6439	025134	012737	000632	005742	MOV	#632,PRMLIM+6		
6440	025142	012737	000400	020042	MOV	#400,HOLD1		
6441	025150	012737	000025	020044	MOV	#25,HOLD3		
6442	025156	012737	010025	020046	MOV	#10025,HOLD4		
6443	025164	012737	000632	020040	MOV	#632,LSTCYL		;LOAD THE LAST CYLINDER NUMBER
6444	025172	105737	003124		TSTB	TYPFMT		;IS AN RK07 ?
6445	025176	001433			BEQ	9\$;BRANCH IF NOT
6446	025200	012737	001450	020036	MOV	#1450,LCM6		
6447	025206	012737	001455	005736	MOV	#1455,PRMLIM+2		
6448	025214	012737	001456	005662	MOV	#1456,LC		
6449	025222	012737	001456	005710	MOV	#1456,PRDFLT+2		
6450	025230	012737	001456	005742	MOV	#1456,PRMLIM+6		
6451	025236	012737	002025	020044	MOV	#2025,HOLD3		
6452	025244	012737	012025	020046	MOV	#12025,HOLD4		
6453	025252	012737	001000	020042	MOV	#1000,HOLD1		
6454	025260	012737	001456	020040	MOV	#1456,LSTCYL		;OTHERWISE SET UP THE LAST CYLINDER
6455	025266	000240			9\$:	NOP		
6456					MOV	#-1,HDALI		;SET PROGRAM STATUS FLAG
6457					JMP	2#TYPED		;GET DRIVE STATISTICS
6458					INTGO:	CLR	HDALI	;HOUSEKEEP
6459	025270	013737	020040	005662	MOV	LSTCYL,LC		;AND SETUP MAX CYLINDER CNT

6460	025276	000403			BR	BAIA		: PROCEED WITH DESIRED DRIVE
6461	025300	004737	030616		BAIFLU: JSR	PC, ECOBAD		: ECHO BAD INPUT
6462	025304	000644			BR	ASKDRV		: GO BACK TO ASK AGAIN
6463	025306	004737	032310		BAIA: JSR	PC, INITSS		: INITIALIZE SUBSYSTEM
6464					; CHECK DESIRED DRIVE FOR PROPER STATUS			
6465	025312	004737	033252		JSR	PC, CHKDRV		: CHECK DRIVE FOR ON-LINE, READY, WRITE LOCK
6466	025316	025016			ASKDRV			: ADDRESS OF ERROR RETURN FOR CHKDRV
6467	025320	004737	035344		JSR	PC, DRVSR		: TYPE "DRIVE SER. NO. XXX"
6468					: SET UP DESIRED SUB-MODE OF OPERATION			
6469	025324				SUBMOD:			
6470	025324	105037	011364		CLRB	VERIFY		: CLEAR VERIFY MODE FLAG
6471	025330	104401	012253		TYPE	ENTMOD		: ASK FOR ALIGN OR EXERCISE SUB-MODE
6472	025334	004737	030576		JSR	PC, PREPKB		: PREPARE FOR KBD INPUT
6473	025340	005737	005522		1\$: TST	INTCHR		: SEE IF ANY INPUT
6474	025344	001775			BEQ	1\$: BR IF NONE TO CHECK AGAIN
6475	025346	013701	005522		MOV	INTCHR, R1		: GET CHAR INTO R1
6476	025352	020127	000022		CMP	R1, #022		: SEE IF (↑R) TYPED
6477	025356	001002			BNE	2\$: BR IF NOT (↑R)
6478	025360	000137	024512		JMP	GIVEID		: JUMP TO RESTART
6479	025364	020127	000003		2\$: CMP	R1, #003		: SEE IF (↑C) TYPED
6480	025370	001002			BNE	3\$: BR IF NOT (↑C)
6481	025372	000137	025016		JMP	ASKDRV		: JUMP TO ASK FOR DRIVE AGAIN
6482	025376	020127	000101		3\$: CMP	R1, #'A		: SEE IF ALIGNMENT REQUESTED
6483	025402	001415			BEQ	MANAL		: BR IF MANUAL ALIGNMENT REQUESTED
6484	025404	020127	000105		CMP	R1, #'E		: SEE IF EXERCISES REQUESTED
6485	025410	001002			BNE	4\$: BR IF NOT EXERCISES
6486	025412	000137	025710		JMP	MANEX		: JUMP TO DO MANUAL EXERCISES
6487	025416	020127	000126		4\$: CMP	R1, #'V		: SEE IF VERIFY REQUESTED
6488	025422	001002			BNE	6\$: BR IF NOT VERIFY
6489	025424	000137	025672		JMP	MANVR		: JUMP TO VERIFY MODE
6490	025430	004737	030616		6\$: JSR	PC, ECOBAD		: ECHO BAD INPUT
6491	025434	000733			BR	SUBMOD		: ASK FOR SUB-MODE AGAIN

6492					: MANUAL ALIGNMENT MODE			
6493					MANAL:			
6494					: REQUEST AND CHECK DESIRED HEAD			
6495					TYPE	MANALN		: REPORT MANUAL ALIGNMENT MODE
6496	025436				ASKHED: TYPE	ENTHED		: ASK FOR DESIRED HEAD
6497	025436	104401	012413		JSR	PC, PREPKB		: PREPARE FOR KBD INPUT
6498					1\$: TST	INTCHR		: SEE IF ANY INPUT
6499	025442	104401	012620		REQ	1\$: BR IF NONE TO CHECK AGAIN
6500	025446	004737	030576		MOV	INTCHR, R1		: GET CHAR INTO R1
6501	025452	005737	005522		CMP	R1, #022		: SEE IF (↑R)
6502	025456	001775			BNE	2\$: BR IF NOT (↑R)
6503	025460	013701	005522		MOVB	#RECAL, P. CMND(R5)		: SET RECALIBRATE COMMAND
6504	025464	020127	000022		JSR	PC, DRVCAL		: RECALIBRATE DRIVE
6505	025470	001007			JMP	GIVEID		: JUMP TO RESTART
6506	025472	112765	000113	000001	2\$: CMP	R1, #003		: SEE IF (↑C)
6507	025500	004737	042542		BNE	3\$: BR IF NOT (↑C)
6508	025504	000137	024512		MOVB	#RECAL, P. CMND(R5)		: SET RECALIBRATE COMMAND
6509	025510	020127	000003		JSR	PC, DRVCAL		: RECALIBRATE DRIVE
6510	025514	001007			JMP	ASKDRV		: JUMP TO ASK FOR DRIVE AGAIN
6511	025516	112765	000113	000001	3\$: CMP	R1, #032		: SEE IF (↑Z)
6512	025524	004737	042542		BNE	4\$: BR IF NOT (↑Z)
6513	025530	000137	025016					
6514	025534	020127	000032					
6515	025540	001007						

```

6516 025542 112765 000113 000001      MOVB      #RECAL,P.CMND(R5) ;SET RECALIBRATE COMMAND
6517 025550 004737 042542      JSR      PC,DRVCL          ;RECALIBRATE DRIVE
6518 025554 000137 025324      JMP      SUBMOD           ;JUMP TO ASK FOR NEW MANUAL SUB-MODE
6519 025560 020127 000060      4$:      CMP      R1,#'0      ;COMPARE TRACK TO ASCII 0
6520 025564 002410      BLT      5$              ;BR IF <0 (BAD INPUT)
6521 025566 020127 000062      CMP      R1,#'2          ;COMPARE TRACK TO ASCII 2
6522 025572 003005      BGT      5$              ;BR IF >2 (BAD INPUT)
6523 025574 042701 000060      BIC      #'0,R1         ;STRIP ASCII BITS
6524 025600 010137 005520      MOV      R1,TRACK        ;STORE TRACK (HEAD) NUMBER
6525 025604 000404      BR       6$              ;GO SELECT HEAD
6526 025606 004737 030616      5$:      JSR      PC,ECOBAD       ;ECHO BAD INPUT
6527 025612 000137 025442      JMP      ASKHED          ;ASK AGAIN FOR HEAD NUMBER
6528                                     ;UNLOAD HEADS, AND WHEN READY, START SPINDLE AND SEEK TO ALN CYL
6529 025616 105737 011364      6$:      TSTB     VERIFY         ;SEE IF VERIFY MODE
6530 025622 001002      BNE      8$              ;BR IF VERIFY
6531 025624 004737 033566      JSR      PC,WAIT4R       ;UNLOAD HEADS, WAIT FOR <R> TYPED, LOAD
6532 025630 113765 005520      000005 8$:      MOVB     TRACK,P.TRCK(R5) ;SET DESIRED HEAD NUMBER
6533 025636 004737 033512      JSR      PC,ALNSEK       ;SEEK TO ALIGNMENT CYLINDER
6534 025642 104401 012510      TYPE     HEDPOS          ;TYPE HEADS POSITIONED MSG
6535 025646 013701 005520      MOV      TRACK,R1        ;GET BINARY TRACK NO.
6536 025652 152701 000060      BISB     #'0,R1         ;CONVERT TO ASCII
6537 025656 110137 012704      MOVB     R1,HEADNO       ;GET HEAD NO. INTO MSG BUFF.
6538 025662 104401 012677      TYPE     HEDSEL          ;TYPE HEAD SELECTED MSG
6539 025666 000137 025442      JMP      ASKHED          ;GO BACK TO ASK FOR NEW HEAD SELECT
6540
6541
6542
6543                                     ;MANUAL SELECT VERIFY MODE
6544 025672 112737 000001 011364  MANVR:  MOVB     #'1,VERIFY      ;SET VERIFY MODE FLAG
6545 025700 104401 012453      TYPE     MANVRF          ;REPORT MANUAL VERIFY MODE
6546 025704 000137 025442      JMP      ASKHED          ;GO ASK FOR DESIRED HEAD
6547
6548
6549                                     ;MANUAL RANDOM SEEK EXERCISE ROUTINE
6550  MANEX:
6551 025710      JSR      PC,WAIT4R       ;UNLOAD HEADS, WAIT FOR <R> TYPED, LOAD
6552 025710 004737 033566      MOV      DRIVE,R1        ;GET DRIVE NUMBER
6553 025714 013701 005500      BISB     #'0,R1         ;CONVERT TO ASCII
6554 025720 052701 000060      MOVB     R1,DRIEXR       ;PUT DRIVE NUMBER INTO OUTPUT BUFFER
6555 025724 110137 012405      TYPE     MANEXR          ;TYPE RANDOM SEEKS MSG
6556 025730 104401 012326      MOV      #RNDLNG,RO      ;INITIALIZE RANDOM SEEK COUNTER
6557 025734 012700 016514      MOVB     #SEEK,P.CMND(R5) ;SET SEEK COMMAND
6558 025740 112765 000117 000001 1$:      JSR      PC,PREPKB       ;PREPARE FOR KBD INPUT
6559 025746 004737 030576      2$:      JSR      PC,RNDADR       ;SELECT RANDOM CYLINDER ADDRESS
6560 025752 004737 035666      000002  MOV      CYLNR,P.CYLN(R5) ;SET RANDOM CYLINDER ADDRESS
6561 025756 013765 005504      JSR      PC,DRVCL        ;DO A RANDOM SEEK
6562 025764 004737 042542      ;CHECK FOR TTY INPUT DURING EXERCISES
6563      TST     INTCHR         ;SEE IF ANY INPUT
6564 025770 005737 005522      BNE      3$              ;BR IF A CHAR WAS TYPED
6565 025774 001016      DEC      RO              ;DECREMENT SEEK COUNTER
6566 025776 005300      BNE      2$              ;BR IF NOT DONE SEEKING YET
6567 026000 001364      BIC      #BIT6,@STKS     ;DISABLE KBD INTERRUPT
6568 026002 042777 000100 153134  MOVB     #RECAL,P.CMND(R5) ;SET RECALIBRATE COMMAND
6569 026010 112765 000113 000001  JSR      PC,DRVCL        ;RECALIBRATE DRIVE
6570 026016 004737 042542      TYPE     ,SBELL          ;RING BELL TO SIGNIFY END OF EXERCISES
6571 026022 104401 001310

```

```

6572 026026 000137 025324      JMP      SUBMOD      ;GO ASK FOR NEW MANUAL SUB-MODE
6573 026032 013701 005522      3$:    MOV      INTCHR,R1 ;GET CHARACTER INTO R1
6574 026036 020127 000022      CMP      R1,#022    ;SEE IF (↑R)
6575 026042 001007          BNE      4$         ;BR IF NOT (↑R)
6576 026044 112765 000113 000001  MOVB    #RECAL,P.CMND(R5) ;SET RECALIBRATE COMMAND
6577 026052 004737 042542      JSR      PC,DRVCL   ;RECALIBRATE DRIVE
6578 026056 000137 024512      JMP      GIVEID     ;JUMP TO RESTART
6579 026062 020127 000003      4$:    CMP      R1,#003  ;SEE IF (↑C)
6580 026066 001007          BNE      5$         ;BR IF NOT (↑C)
6581 026070 112765 000113 000001  MOVB    #RECAL,P.CMND(R5) ;SET RECALIBRATE COMMAND
6582 026076 004737 042542      JSR      PC,DRVCL   ;RECALIBRATE DRIVE
6583 026102 000137 025016      JMP      ASKDRV     ;JUMP TO ASK FOR NEW DRIVE NUMBER
6584 026106 020127 000032      5$:    CMP      R1,#032  ;SEE IF (↑Z)
6585 026112 001007          BNE      6$         ;BR IF NOT (↑Z)
6586 026114 112765 000113 000001  MOVB    #RECAL,P.CMND(R5) ;SET RECALIBRATE COMMAND
6587 026122 004737 042542      JSR      PC,DRVCL   ;RECALIBRATE DRIVE
6588 026126 000137 025324      JMP      SUBMOD     ;JUMP TO ASK FOR NEW MANUAL SUB-MODE
6589 026132 004737 030616      6$:    JSR      PC,ECOBAD ;ECHO BAD INPUT
6590 026136 104401 012326      TYPE    MANEXR     ;VERIFY STILL IN MANUAL EXERCISES
6591 026142 000701          BR      1$         ;BR TO CONTINUE EXERCISES

```

```

6592
6593
6594
6595      ;AUTO SELECT MODE ROUTINE
6596      AUTO:
6597 026144 012737 177777 003150  MOV      #-1,AUTOFG  ;SET SPECIAL FLAG
6598 026152 004737 032310      JSR      PC,INITSS  ;INITIALIZE SUBSYSTEM
6599 026156 104401 012721      TYPE    TYPAUT     ;TYPE "AUTO SELECT MODE"
6600 026162 105037 011364      1$:    CLRB    VERIFY    ;CLEAR VERIFY MODE FLAG
6601 026166 104401 012253      TYPE    ENTMOD     ;ASK FOR ALIGN,VERIFY, OR EXERCISE
6602 026172 004737 030576      JSR      PC,PREPKB  ;PREPARE FOR KEYBOARD INPUT
6603 026176 005737 005522      2$:    TST     INTCHR   ;SEE IF ANY INPUT
6604 026202 001775          BEQ     2$         ;BR IF NONE, TO CHECK AGAIN
6605 026204 013701 005522      MOV      INTCHR,R1  ;GET CHAR INTO R1
6606 026210 020127 000022      CMP      R1,#022    ;SEE IF (↑R) TYPED
6607 026214 001002          BNE      3$         ;BR IF NOT (↑R)
6608 026216 000137 024512      JMP      GIVEID     ;JUMP TO RESTART
6609 026222 020127 000101      3$:    CMP      R1,#'A   ;SEE IF AUTO ALIGNMENT REQUESTED
6610 026226 001417          BEQ     AUTAL      ;BR IF AUTO ALIGNMENT REQUESTED
6611 026230 020127 000105      CMP      R1,#'E   ;SEE IF AUTO EXERCISES REQUESTED
6612 026234 001002          BNE      4$         ;BR IF EXERCISES NOT REQUESTED
6613 026236 000137 027520      JMP      AUTEX     ;JUMP TO DO AUTO EXERCISES
6614 026242 020127 000126      4$:    CMP      R1,#'V  ;SEE IF VERIFY REQUESTED
6615 026246 001004          BNE      6$         ;BR IF NOT VERIFY
6616 026250 112737 000001 011364  MOVB    #1,VERIFY   ;SET VERIFY MODE FLAG
6617 026256 000403          BR      AUTAL     ;PROCEED IN VERIFY MODE
6618 026260 004737 030616      6$:    JSR      PC,ECOBAD ;ECHO BAD INPUT
6619 026264 000736          BR      1$         ;BR TO ASK FOR A OR E AGAIN

```

```

6620
6621
6622
6623      ;AUTO ALIGNMENT MODE
6624      AUTAL:
6625 026266 105737 011364      TSTB   VERIFY     ;SEE IF AUTO VERIFY MODE
6626 026272 001403          BEQ     3$         ;BR IF NOT
6627 026274 104401 013010      TYPE    ,AUTVRF   ;REPORT AUTO VERIFY MODE

```

6628	026300	000402				BR	4\$		
6629	026302	104401	012752		3\$:	TYPE	AUTALN	:	TYPE ALIGNMENT MESSAGE
6630	026306	004737	030576		4\$:	JSR	PC,PREPKB	:	PREPARE FOR POSSIBLE KBD INPUT
6631	026312	005037	003024			CLR	T,MR2	:	CLEAR MR2 STORAGE WORD
6632	026316	005037	005524			CLR	SELECT	:	INITIALIZE AUTO-SELECTED DRIVE INDICATOR
6633	026322	012737	000377	005526		MOV	#377,ONLINE	:	INIT. OLD ONLINE DRIVE INDICATOR
6634	026330	012737	000377	005530		MOV	#377,NEWON	:	INIT. NEW ONLINE DRIVE INDICATOR
6635	026336	012737	000377	005534		MOV	#377,SCRACH	:	INITIALIZE LAST DRIVE INDICATOR
6636	026344	005737	005522		DRVLUP:	TST	INTCHR	:	SEE IF ANY KBD INPUT
6637	026350	001423				BEQ	6\$:	BR IF NO INPUT
6638	026352	113765	005534	000000		MOVB	SCRACH,P.DRVN(R5)	:	DRIVE NO. FOR POSSIBLE RECALIBRATE
6639	026360	123727	005522	000032		CMPB	INTCHR,#032	:	SEE IF (↑Z) TYPED
6640	026366	001002				BNE	2\$:	BR IF NOT (↑Z)
6641						CMP	#377,SCRACH	:	SEE IF ANY DRIVE SELECTED YET
6642						BEQ	1\$:	BR IF NONE
6643						MOVB	#RECAL,P.CMND(R5)	:	SET RECALIBRATE COMMAND
6644						JSR	PC,DRVCL	:	RECALIBRATE DRIVE
6645	026370	000137	026144		1\$:	JMP	AUTO	:	RESTART AUTO MODE
6646	026374	123727	005522	000022	2\$:	CMPB	INTCHR,#022	:	SEE IF (↑R) TYPED
6647	026402	001002				BNE	4\$:	BR IF NOT (↑R)
6648						CMP	#377,SCRACH	:	SEE IF ANY DRIVE SELECTED YET
6649						BEQ	3\$:	BR IF NONE
6650						MOVB	#RECAL,P.CMND(R5)	:	SET RECALIBRATE COMMAND
6651						JSR	PC,DRVCL	:	RECALIBRATE DRIVE
6652	026404	000137	024512		3\$:	JMP	GIVEID	:	RESTART ALIGNMENT AID
6653	026410	004737	030616		4\$:	JSR	PC,ECOBAD	:	ECHO BAD INPUT
6654	026414	004737	030576			JSR	PC,PREPKB	:	PREPARE FOR POSSIBLE KBD INPUT
6655	026420	005037	005500		6\$:	CLR	DRIVE	:	ZERO THE DRIVE NUMBER
6656	026424	012700	000001			MOV	#1,RO	:	INITIALIZE DRIVE BIT MASK
6657	026430	012737	030360	003046	INTG:	MOV	#NEDHDL,A.ABNL	:	SET NED ABNORMAL RETURN ADDRESS
6658	026436	050037	005530			BIS	RO,NEWON	:	SET ON-LINE BIT FOR THIS DRIVE
6659						;SELECT	CURRENT DRIVE, CHECK FOR	:	NON-EXISTENT DRIVE (NED) INDICATION
6660	026442	013701	005500			MOV	DRIVE,R1	:	LOAD DRIVE NUMBER
6661	026446	116137	005620	003124		MOVB	DYLS↑(R1),TYPFMT	:	LOAD THE RK06-RK07 FLAG
6662	026454	012737	000624	020036		MOV	#624,LCM6		
6663	026462	012737	000631	005736		MOV	#631,PRMLIM+2		
6664	026470	012737	000632	005662		MOV	#632,LC		
6665	026476	012737	000632	020040		MOV	#632,LSTCYL		
6666	026504	012737	000632	005710		MOV	#632,PROFLT+2		
6667	026512	012737	000632	005742		MOV	#632,PRMLIM+6		
6668	026520	012737	000400	020042		MOV	#400,HOLD1		
6669	026526	012737	000025	020044		MOV	#25,HOLD3		
6670	026534	012737	010025	020046		MOV	#10025,HOLD4		
6671	026542	105737	003124			TSTB	TYPFMT	:	IS AN RK07 ?
6672	026546	001433				BEQ	9\$:	BRANCH IF NOT
6673	026550	012737	001450	020036		MOV	#1450,LCM6		
6674	026556	012737	001455	005736		MOV	#1455,PRMLIM+2		
6675	026564	012737	001456	005662		MOV	#1456,LC		
6676	026572	012737	001456	020040		MOV	#1456,LSTCYL		
6677	026600	012737	001456	005710		MOV	#1456,PROFLT+2		
6678	026606	012737	001456	005742		MOV	#1456,PRMLIM+6		
6679	026614	012737	001000	020042		MOV	#1000,HOLD1		
6680	026622	012737	002025	020044		MOV	#2025,HOLD3		
6681	026630	012737	012025	020046		MOV	#12025,HOLD4		
6682	026636	000240			9\$:	NOP		:	EXIT
6683	026640	004737	032436			JSR	PC,SCNDRV	:	CHECK THE SELECTED DRIVE

```

6684 026644 026706          99$          ;ERROR EXIT
6685 026646 000240          NOP
6686 026650 000240          NOP
6687 026652 000240          NOP
6688 026654 113765 005500 000000  MOVB    DRIVE P.DRVN(R5) ;SET DRIVE NUMBER
6689 026662 112765 000101 000001  MOVB    #SELDV,P.CMND(R5) ;SET SELECT DRIVE COMMAND
6690 026670 000137 027150          JMP     23$ ;BRANCH TO EXECUTE THE DRIVE
6691          ;
6692          ;
6693          ;
6694          ;
6695 026674 013737 020040 005662  MOV     DRIVE RO ;GET THE SPECIFIED DRIVE
6696 026702 004737 042542          JSR     #-1,HDALI ;SET UP FOR PROGRAM MARKER
6697 026706 022737 000007 005500 99$:    JMP     #TYPED ;LOAD THE DEVICE TABLE
6698 026714 001405          CLR     HDALI ;CLEAR THIS STATUS
6699 026716 005237 005500          MOV     LSTCYL,LC ;GET THE MAX CYLINDER SIZE FOR THIS DEVICE
6700 026722 000241          JSR     PC,DRVCAL ;SELECT THIS DRIVE
6701 026724 006100          CMP     #7,DRIVE ;SEE IF WE JUST CHECKED DRIVE 7
6702 026726 000640          BEQ     10$ ;BR IF IT WAS DRIVE 7
6703 026730 013701 005530          INC     DRIVE ;ADD 1 TO DRIVE NUMBER
6704          CLC ;CLEAR CARRY BEFORE ROTATE
6705 026734 023737 005530 005526  ROL     RO ;SHIFT BIT POINTER
6706 026742 001002          BR     INTG ;BR TO SELECT NEXT DRIVE
6707 026744 000137 026344          MOV     NEWON,R1
6708 026750          ;***** TO BE REMOVED *****
6709          ;
6710 026750 012703 000001          CMP     NEWON,ONLINE
6711          BNE  93$
6712          JMP  DRVLUP
6713          ;
6714          ;
6715          ;
6716          ;
6717          ;
6718 026754 043701 005526 005526  BEQ     DRVLUP ;NUMBER OF 200 MILLI-SEC STALLS
6719 026760 013737 005530          MOV     #1,R3
6720 026766 005701          ;LOOP1: MOV   #177777,RO
6721          ;LOOP2: DEC   RO
6722          ;
6723          ;
6724          ;
6725          ;
6726          ;
6727          ;
6728          ;
6729          ;
6730          ;
6731          ;
6732          ;
6733          ;
6734          ;
6735          ;
6736          ;
6737          ;
6738          ;
6739 027036 104401 012163          ;*****
          BIC   ONLINE,R1 ;GET CHANGED ONLINE BITS
          MOV   NEWON,ONLINE ;UPDATE ONLINE DRIVE BITS
          TST   R1 ;SEE IF ANY DRIVE JUST WENT ON-LINE
          BNE  97$
          JMP  DRVLUP
97$:    BEQ   DRVLUP ;BR IF NO DRIVE JUST WENT ONLINE
;SERVICE THE DRIVE WHICH WAS JUST SELECTED
MOV   #ERRHDL,A.ABNL ;RESTORE USUAL ERROR HANDLER ADDRESS
CLR   DRIVE ;INITIALIZE DRIVE NO.
MOV   R1,R3 ;COPY NEW SELECTED DRIVE BITS
MOV   #1,RO ;INITIALIZE BIT POINTER
12$:   BIT   RO,R3 ;SEE IF THIS BIT IS SET
      BNE  14$ ;BR IF THIS BIT SET
      INC  DRIVE ;INCREMENT DRIVE NO.
      CLC ;CLEAR CARRY BEFORE ROTATE
      ROL  RO ;SHIFT BIT POINTER
      BR   12$ ;TRY AGAIN
14$:   BIC   RO,R3 ;CLEAR OUT THIS BIT
      BEQ  16$ ;BR IF ONLY ONE DRIVE SELECTED
;ERROR - MORE THAN ONE DRIVE SELECTED SIMULTANEOUSLY
      TYPE ,MULSEL ;REPORT ERROR

```

```

6740 027042 042762 000100 000000      BIC      #IE,RKCS1(R2) ;INHIBIT RK06 INTERRUPT
6741 027050 000000      HALT      ;HALT FOR MANUAL INTERVENTION
6742                                     ;PRESS 'CONT' TO PROCEED
6743 027052 112765 000177 000001      MOVB     #SUBCLR,P.CMND(R5) ;SET SUBSYSTEM CLEAR COMMAND
6744 027060 004737 042542      JSR      PC,DRVCAL ;CLEAR THE SUBSYSTEM
6745 027064 000137 026266      JMP      AUTAL ;RESTART AUTO ALIGNMENT
6746                                     ;CONTINUE WITH SELECTED DRIVE
6747 027070 020137 005524 16$:    CMP     R1,SELECT ;SEE IF STILL ALIGNING SAME DRIVE
6748 027074 001505      BEQ     26$ ;BR IF SAME DRIVE
6749                                     ;PROCEED WITH NEWLY-SELECTED DRIVE
6750 027076 022737 000377 005534      CMP     #377,SCRACH ;SEE IF THIS IS FIRST DRIVE SELECTED
6751 027104 001421      BEQ     23$ ;BR IF FIRST DRIVE
6752 027106 113765 005534 000000      MOVB     SCRACH,P.DRVN(R5) ;GET LAST DRIVE NUMBER
6753 027114 112765 000141 000001      MOVB     #RDSTAT,P.CMND(R5) ;SET READ STATUS COMMAND
6754 027122 004737 042542      JSR      PC,DRVCAL ;READ STATUS OF PREVIOUS DRIVE
6755 027126 032765 000040 000044      BIT     #S.HDMM,P.A01(R5) ;SEE IF HEADS ARE UNLOADED
6756 027134 001405      BEQ     23$ ;BR IF HEADS NOT UNLOADED
6757 027136 112765 000111 000001      MOVB     #SRTSPL,P.CMND(R5) ;SET START SPINDLE COMMAND
6758 027144 004737 042542      JSR      PC,DRVCAL ;START SPINDLE ON PREVIOUS DRIVE
6759 027150 113737 005500 005534 23$:    MOVB     DRIVE,SCRACH ;STORE DRIVE NO. FOR LATER CLEANUP
6760 027156 010137 005524      MOV      R1,SELECT ;UPDATE SELECTED DRIVE NUMBER
6761 027162 013701 005500      MOV      DRIVE,R1 ;GET DRIVE NUMBER
6762 027166 052701 000060      BIS     #'0,R1 ;CONVERT TO ASCII
6763 027172 110137 013050      MOVB     R1,DRVSEL ;GET DRIVE NUMBER INTO OUTPUT BUFFER
6764 027176 104401 013043      TYPE    DRSEL ;TYPE "DRIVE X SELECTED"
6765 027202 004737 033252      JSR      PC,CHKDRV ;CHECK DRIVE FOR RDY, WRITE PROT.
6766 027206 026266      AUTAL    ;ERROR RETURN ADDRESS
6767 027210 112737 000377 011363      MOVB     #377,UNLOD ;SET DRIVE UNLOADED INDICATOR
6768 027216 012737 000000 005520      MOV      #0,TRACK ;SET TO TRACK 0
6769                                     ;
6770 027224 113765 005500 000000      MOV      #2,TRACK ;SET TRACK = 2
6771 027232 000421      MOVB     DRIVE,P.DRVN(R5) ;SET DRIVE NUMBER
6772 027234 105737 011364      BR      32$ ;SKIP THE REST PROGRAM FLOW
6773 027240 001016      TSTB    VERIFY ;SEE IF AUTO VERIFY
6774 027242 112765 000107 000001      BNE     32$ ;SKIP UNLOAD IF VERIFY
6775 027250 004737 042542      MOVB     #UNLOAD,P.CMND(R5) ;SET UNLOAD COMMAND
6776 027254 112765 000141 000001      JSR      PC,DRVCAL ;UNLOAD THE DRIVE
6777 027262 004737 042542      MOVB     #RDSTAT,P.CMND(R5) ;SET READ STATUS COMMAND
6778 027266 032765 000040 000044 25$:    JSR      PC,DRVCAL ;READ STATUS OF DRIVE
6779 027274 001772      BIT     #S.HDMM,P.A01(R5) ;SEE IF HEADS ARE UNLOADED YET
6780 027276 112765 000177 000001 25$:    BEQ     25$ ;BR IF NOT YET
6781 027304 004737 042542      MOVB     #SUBCLR,P.CMND(R5) ;SET SUBSYSTEM CLEAR COMMAND
6782                                     JSR      PC,DRVCAL ;CLEAR THE S.S.
6783                                     JMP      DRVLUP ;GO BACK TO SCAN DRIVES AGAIN
6784                                     ;PROCEED WITH SAME DRIVE
6784 027310 113765 005500 000000 26$:    MOVB     DRIVE,P.DRVN(R5) ;SET DRIVE NO.
6785 027316 105137 011363      COMB    UNLOD ;COMPLEMENT UNLOAD INDICATOR
6786                                     ;
6787 027322 105737 011364      BNE     24$ ;BR IF DRIVE SHOULD BE UNLOADED
6788 027326 001005      TSTB    VERIFY ;SEE IF AUTO VERIFY
6789 027330 112765 000113 000001      BNE     33$ ;SKIP START SPL IF VERIFY
6790                                     ;
6791 027336 004737 042542      MOVB     #RECAL,P.CMND(R5) ;SET RECAL COMMAND
6792 027342 022737 000002 005520 33$:    MOVB     #SRTSPL,P.CMND(R5) ;SET START SPINDLE COMMAND
6793 027350 103005      JSR      PC,DRVCAL ;START SPINDLE ON THIS DRIVE
6794                                     ;
6795 027352 005037 005520      CMP     #2,TRACK ;SEE IF LAST TRACK WAS 2
                                     ;
                                     ;NOT EXCEEDS HEAD 2
                                     ;BR IF IT WAS NOT 2
                                     ;
                                     ;SET TRACK = 0

```

```

6796 027356 000402          BR      30$      ;GO SEEK TO ALIGNMENT CYLINDER
6797 027360 005237 005520    INC      TRACK      ;INCREMENT TRACK NUMBER
6798 027364 113765 005520    000005 30$:     MOVB     TRACK,P.TRCK(R5) ;SET TRACK NO.
6799 027372 004737 033512    JSR     PC,ALNSEK    ;SEEK IN INCREMENTS TO ALIGN. CYL
6800 027376 104401 012510    TYPE    HEDPOS      ;TYPE HEADS POSITIONED MSG
6801 027402 013701 005520    MOV     ↑TRACK,R1    ;GET CURRENT TRACK NO.
6802 027406 152701 000060    BISB   #'0,R1      ;CONVERT TO ASCII
6803 027412 110137 012704    MOVB   R1,HEADNO    ;GET TRACK INTO MSG BUFFER
6804 027416 104401 012677    TYPE    HEDSEL      ;TYPE "HEAD X SELECTED"
6805 027422 005237 005520    INC     ↑TRACK      ;INCREMENT THE TRACK NUMBER
6806 027426 022737 000003 005520    CMP     #3,TRACK    ;ALL TRACK ARE DONE?
6807 027434 101353          BHI     30$         ;BRANCH IF NOT
6808 027436 004737 030576    46$:     JSR     PC,PREPKB  ;READ THE KEYBOARD
6809 027442 005737 005522    47$:     TST     INTCHR     ;READ ANY THING YET ?
6810 027446 001775          BEQ     47$        ;BRANCH IF NOT
6811 027450 123727 005522 000032    CMPB   INTCHR,#032  ;Z ?
6812 027456 001002          BNE     48$        ;BRANCH IF NOT
6813 027460 000137 026144    JMP     AUTO        ;
6814 027464 123727 005522 000022 48$:     CMPB   INTCHR,#022  ;R ?
6815 027472 001002          BNE     49$        ;
6816 027474 000137 026144    JMP     AUTO        ;
6817 027500 123727 005522 000003 49$:     CMPB   INTCHR,#003  ;C ?
6818 027506 001353          BNE     46$        ;WAIT
6819 027510 000137 026144    JMP     AUTO        ;TO NEXT DRIVE
6820 027514 000137 026344    JMP     DRVLUP     ;GO BACK TO SCAN DRIVES AGAIN
6821
6822
6823          ;AUTO RANDOM SEEK EXERCISE ROUTINE
6824 AUTEX:
6825 027520 004737 032310    JSR     PC,INITSS   ;INITIALIZE SUBSYSTEM
6826 027524 004737 030576    JSR     PC,PREPKB  ;PREPARE FOR KBD INPUT
6827 027530 104401 013066    TYPE    AUTEXR     ;ASK FOR SHORT OR LONG SEEK EXERCISES
6828 027534 005737 005522    1$:     TST     INTCHR     ;SEE IF ANY INPUT
6829 027540 001775          BEQ     1$         ;BR IF NO INPUT
6830 027542 023727 005522 000022    CMP     INTCHR,#022 ;SEE IF (↑R) TYPED
6831 027550 001002          BNE     2$         ;BR IF NOT (↑R)
6832 027552 000137 024512    JMP     GIVEID      ;JUMP TO RESTART ALIGNMENT AID
6833 027556 023727 005522 000032 2$:     CMP     INTCHR,#032 ;SEE IF (↑Z) TYPED
6834 027564 001002          BNE     3$         ;BR IF NOT (↑Z)
6835 027566 000137 026144    JMP     AUTO        ;JUMP TO RESTART AUTO MODE
6836 027572 023727 005522 000123 3$:     CMP     INTCHR,#'S  ;SEE IF SHORT EXERCISES DESIRED
6837 027600 001004          BNE     4$         ;BR IF NOT SHORT
6838 027602 012737 002734 005534    MOV     #RND SHT,SCRACH ;SET 1 MINUTE SEEK COUNT
6839 027610 000413          BR      6$         ;PROCEED WITH SHORT EXERCISES
6840 027612 023727 005522 000114 4$:     CMP     INTCHR,#'L  ;SEE IF LONG EXERCISES DESIRED
6841 027620 001004          BNE     5$         ;BR IF NOT LONG
6842 027622 012737 016514 005534    MOV     #RND LNG,SCRACH ;SET 5 MINUTE SEEK COUNT
6843 027630 000403          BR      6$         ;PROCEED WITH LONG EXERCISES
6844 027632 004737 030616    5$:     JSR     PC,ECOBAD   ;ECHO BAD INPUT
6845 027636 000730          BR      AUTEX      ;BR TO ASK AGAIN
6846 027640 005037 005500    6$:     CLR     DRIVE     ;SET DRIVE = 0
6847          ;SELECT CURRENT DRIVE AND CHECK FOR NON-EXISTENT DRIVE INDICATION
6848 027644 012737 030360 003046 8$:     MOV     #NEDHOL,A,ABNL ;SET NED ABNORMAL RETURN ADDRESS
6849 027652 113765 005500 000000    MOVB   DRIVE,P.DRVN(R5) ;SET DRIVE NUMBER
6850 027660 013701 005500    MOV     DRIVE,R1    ;LOAD THE DRIVE NUMBER
6851 027664 116137 005620 003124    MOVB   DTYLST(R1),TYPFMT ;LOAD THE RK06-RK07 FLAG

```



```

6852 027672 012737 000624 020036      MOV      #624,LCM6
6853 027700 012737 000631 005736      MOV      #631,PRMLIM+2
6854 027706 012737 000632 005662      MOV      #632,LC
6855 027714 012737 000632 020040      MOV      #632,LSTCYL
6856 027722 012737 000632 005710      MOV      #632,PRDFLT+2
6857 027730 012737 000632 005742      MOV      #632,PRMLIM+6
6858 027736 012737 000400 020042      MOV      #400,HOLD1
6859 027744 012737 000025 020044      MOV      #25,HOLD3
6860 027752 012737 010025 020046      MOV      #10025,HOLD4
6861 027760 105737 003124      TSTB     TYPFMT      ; IS AN RK07 ?
6862 027764 001433          BEQ      9$          ; BRANCH IF NOT
6863 027766 012737 001450 020036      MOV      #1450,LCM6
6864 027774 012737 001455 005736      MOV      #1455,PRMLIM+2
6865 030002 012737 001456 005662      MOV      #1456,LC
6866 030010 012737 001456 020040      MOV      #1456,LSTCYL
6867 030016 012737 001456 005710      MOV      #1456,PRDFLT+2
6868 030024 012737 001456 005742      MOV      #1456,PRMLIM+6
6869 030032 012737 001000 020042      MOV      #1000,HOLD1
6870 030040 012737 002025 020044      MOV      #2025,HOLD3
6871 030046 012737 012025 020046      MOV      #12025,HOLD4
6872 030054 000240          9$:      NOP
6873 030056 004737 032436      JSR      PC,SCNDRV ; EXIT
6874 030062 030322          18$
6875 030064 000240          NOP
6876 030066 000240          NOP
6877 030070 000240          NOP
6878 030072 112765 000101 000001      MOVB     #SELDIV,P.CMND(R5) ; SET SELECT DRIVE COMMAND
6879 030100 012737 000377 005530      MOV      #377,NEWON ; INITIALIZE ON-LINE INDICATOR
6880 030106 004737 042542      JSR      PC,DRVCAL ; SELECT THIS DRIVE
6881 030112 012737 044200 003046      MOV      #ERRHDL,A.ABNL ; RESTORE ABNORMAL DRIVER RETURN ADDRESS
6882 030120 022737 000377 005530      CMP      #377,NEWON ; SEE IF NED INDICATION ON THIS DRIVE
6883 030126 001075          BNE      18$        ; BR IF NED, TO SKIP THIS DRIVE
6884          ; CHECK DRIVE FOR RDY, WRITE PROTECT
6885 030130 004737 033252      JSR      PC,CHKDRV ; CHECK THIS DRIVE
6886 030134 027520          AUTEX ; ERROR RETURN ADDRESS FOR CHKDRV
6887          ; PROCEED WITH SEEK EXERCISES ON THIS DRIVE
6888 030136 013701 005500      MOV      DRIVE R1 ; GET DRIVE NUMBER
6889 030142 052701 000060      BIS      #'0,R1 ; CONVERT TO ASCII
6890 030146 110137 013176      MOVB     R1,AUTODR ; GET DRIVE NUMBER INTO OUTPUT BUFFER
6891 030152 104401 013157      TYPE     AUTOEX ; TYPE "EXERCISING DRIVE X"
6892 030156 112765 000117 000001      MOVB     #SEEK,P.CMND(R5) ; SET SEEK COMMAND
6893 030164 013700 005534      MOV      SCRACH RD ; SEEK COUNT
6894 030170 004737 030576          10$:    JSR      PC,PREPKB ; PREPARE FOR POSSIBLE KBD INPUT
6895 030174 004737 035666          JSR      PC,RNDADR ; SELECT RANDOM CYLINDER ADDRESS
6896 030200 013765 005504 000002      MOV      CYLNDR,P.CYLN(R5) ; SET RANDOM CYLINDER ADDRESS
6897 030206 004737 042542          JSR      PC,DRVCAL ; DO A RANDOM SEEK
6898 030212 005737 005522          TST     INTCHR ; SEE IF ANY KBD INPUT
6899 030216 001432          BEQ     16$        ; BR IF NO INPUT
6900 030220 023727 005522 000022      CMP      INTCHR,#022 ; SEE IF (↑R) TYPED
6901 030226 001007          BNE     12$        ; BR IF NOT (↑R)
6902 030230 112765 000113 000001      MOVB     #RECAL,P.CMND(R5) ; SET RECALIBRATE COMMAND
6903 030236 004737 042542          JSR      PC,DRVCAL ; RECALIBRATE DRIVE
6904 030242 000137 024512          JMP     GIVEID ; JUMP TO RESTART ALIGNMENT AID
6905 030246 023727 005522 000032      CMP      INTCHR,#032 ; SEE IF (↑Z) TYPED
6906 030254 001007          BNE     14$        ; BR IF NOT (↑Z)
6907 030256 112765 000113 000001      MOVB     #RECAL,P.CMND(R5) ; SET RECALIBRATE COMMAND

```

```

6908 030264 004737 042542 JSR PC,DRVCL ;RECALIBRATE DRIVE
6909 030270 000137 026144 JMP AUTO ;JUMP TO RESTART AUTO MODE
6910 030274 004737 030616 14$: JSR PC,ECOBAD ;ECHO BAD INPUT
6911 030300 004737 030576 JSR PC,PREPKB ;ENABLE KBD INPUT AGAIN
6912 030304 005300 16$: DEC RO ;DECREMENT SEEK COUNT
6913 030306 001330 BNE 10$ ;BR IF NOT DONE WITH THIS DRIVE
6914 030310 112765 000113 000001 MOVB #RECAL,P.CMND(R5) ;SET RECALIBRATE COMMAND
6915 030316 004737 042542 JSR PC,DRVCL ;RECALIBRATE DRIVE
6916 030322 005237 005500 18$: INC DRIVE ;INCREMENT DRIVE NUMBER
6917 030326 022737 000010 005500 CMP #10,DRIVE ;SEE IF DONE WITH ALL DRIVES
6918 030334 001402 BEQ 99$
6919 030336 000137 027644 JMP 8$
6920 030342 99$:
6921 ; BNE 8$ ;BR IF MORE DRIVES TO EXERCISE YET
6922 030342 042777 000100 150574 BIC #BIT6,STKS ;DISABLE KBD INTERRUPT
6923 030350 104401 001310 TYPE $BELL ;RING BELL AT END OF AUTO-EXERCISES
6924 030354 000137 026144 JMP AUTO ;RESTART AUTO MODE
6925
6926
6927 ;THIS IS THE ABNORMAL RETURN FROM THE DRIVER,
6928 ; WHICH IS USED WHEN NED INDICATION IS EXPECTED (AND VALID).
6929 ; (NED = NON-EXISTENT DRIVE)
6930 030360 032765 010000 000020 NEDHDL: BIT #NED,P.CS2(R5) ;SEE IF NED ON DRIVE SELECT
6931 030366 001002 BNE 1$ ;BR IF NED SET
6932 030370 000137 044200 JMP ERRHDL ;GO HANDLE OTHER ERROR
6933 030374 010046 1$: MOV RO,-(SP) ;SAVE RO,R1
6934 030376 010146 MOV R1,-(SP)
6935 030400 012700 000001 MOV #1,RO ;SET BIT POINTER
6936 030404 005001 CLR R1 ;CLEAR COUNTER
6937 030406 120137 005500 2$: CMPB R1,DRIVE ;SEE IF R1 = CURRENT DRIVE NUMBER
6938 030412 001403 BEQ 3$ ;BR IF =
6939 030414 005201 INC R1 ;INCREMENT COUNTER
6940 030416 006300 ASL RO ;SHIFT BIT POINTER
6941 030420 000772 BR 2$ ;TRY AGAIN
6942 030422 040037 005530 3$: BIC RO,NEWON ;CLEAR ONLINE BIT FOR THIS DRIVE
6943 030426 012601 MOV (SP)+,R1 ;RESTORE RO,R1
6944 030430 012600 MOV (SP)+,RO
6945 030432 000137 046356 JMP RETNML ;TAKE NORMAL RETURN
6946
6947
6948 ;*****
6949 ;SBTTL KBDHDL - TTY KEYBOARD INTERRUPT HANDLER
6950 ;*****
6951
6952 030436 010146 KBDHDL: MOV R1,-(SP) ;SAVE R1 ON STACK
6953 030440 017701 150502 MOV $STKB,R1 ;READ A CHAR FROM KBD BUFFER
6954 030444 042701 177600 BIC #177600,R1 ;MASK OUT UNUSED BITS
6955 030450 120127 000172 CMPB R1,#172 ;SEE IF LOWER CASE TYPED
6956 030454 003005 BGT 20$ ;BR IF NOT
6957 030456 120127 000141 CMPB R1,#141
6958 030462 002402 BLT 20$ ;BR IF NOT
6959 030464 042701 000040 BIC #BIT5,R1 ;MAKE IT UPPER CASE
6960 030470 010137 005522 20$: MOV R1,INTCHR ;SAVE INPUT CHARACTER
6961 030474 122701 000003 CMPB #003,R1 ;SEE IF (↑) TYPED
6962 030500 001007 BNE 2$ ;BR IF NOT (↑)
6963 030502 104401 013246 TYPE ,CNTRLC ;ECHO (↑)

```

```

6964 030506 042777 000100 150430 1$: BIC #BIT6,2$TKS ;CLEAR KBD INTERRUPT ENABLE BIT
6965 030514 012601 ;MOV (SP)+,R1 ;RESTORE R1
6966 030516 000002 ;RTI ;RETURN
6967 030520 122701 000032 2$: CMPB #032,R1 ;SEE IF (↑Z) TYPED
6968 030524 001003 ;BNE 3$ ;BR IF NOT (↑Z)
6969 030526 104401 013253 ;TYPE CNTRLZ ;ECHO (↑Z)
6970 030532 000765 ;BR 1$ ;RETURN
6971 030534 122701 000022 3$: CMPB #022,R1 ;SEE IF (↑R) TYPED
6972 030540 001003 ;BNE 4$ ;BR IF NOT (↑R)
6973 030542 104401 013260 ;TYPE CNTRLR ;ECHO (↑R)
6974 030546 000757 ;BR 1$ ;RETURN
6975 030550 122701 000007 4$: CMPB #007,R1 ;SEE IF (↑G) TYPED
6976 030554 001003 ;BNE 5$ ;BR IF NOT (↑G)
6977 030556 104401 013272 ;TYPE CNTRLG ;ECHO (↑G)
6978 030562 000751 ;BR 1$ ;RETURN
6979 030564 104401 005522 5$: TYPE ,INTCHR ;ECHO INPUT
6980 030570 104401 001315 ;TYPE $CRLF ;DO <CR> AND <LF>
6981 030574 000744 ;BR 1$ ;RETURN

```

```

6982
6983
6984
6985 ;*****
6986 ;SBTTL PREPKB - PREPARE FOR KEYBOARD INPUT
6987 ;*THIS SUBROUTINE CLEARS THE KEYBOARD BUFFER AND THE
6988 ;*DONE BIT, AND CLEARS THE TTY INTERRUPT INPUT WORD
6989 ;*INTCHR, IN PREPARATION FOR NEW TTY INPUT. IT ALSO
6990 ;*ENABLES KBD INTERRUPT.
6991 ;* CALL:
6992 ;* JSR PC,PREPKB
6993 ;*****
6994

```

```

6995 030576 005077 150344 PREPKB: CLR 2$TKB ;CLEAR KBD BUFFER AND DONE BIT
6996 030602 005037 005522 CLR INTCHR ;CLEAR TTY INPUT WORD
6997 030606 052777 000100 150330 BIS #BIT6,2$TKS ;ENABLE KBD INTERRUPT
6998 030614 000207 RTS PC ;RETURN
6999

```

```

7000
7001
7002 ;*****
7003 ;SBTTL ECOBAD - ECHO BAD TTY INPUT
7004 ;*THIS SUBROUTINE ECHOS A CHARACTER WHICH HAD BEEN
7005 ;*TYPED IN AND WAS DETERMINED TO BE INVALID FOR SOME
7006 ;*REASON, FOLLOWED BY A QUESTION MARK (?). THEN, A <CR>
7007 ;*AND <LF> ARE DONE.
7008 ;* CALL - JSR PC,ECOBAD
7009 ;*****
7010

```

```

7011 030616 104401 005522 ECOBAD: TYPE ,INTCHR ;ECHO BAD CHARACTER
7012 030622 104401 001314 TYPE $QUES ;TYPE <?> AND <CR>, <LF>
7013 030626 000207 RTS PC ;RETURN
7014

```

```

7015
7016 ;*****
7017 ;*SIZMEM - SIZE MEMORY, SET LIMITS
7018 ;*THIS SUBROUTINE SIZES MEMORY BY CALLING SUBROUTINE $SIZE, AND
7019

```

```

7020
7021
7022
7023
7024 030630 104407
7025 030632 012737 000200 057732
7026 030640 004737 057674
7027 030644 005737 057732
7028 030650 100406
7029 030652 013737 060176 005574
7030 030660 005037 005576
7031 030664 000436
7032
7033 030666 013700 060200
7034 030672 005001
7035 030674 012702 000006
7036 030700 000241
7037 030702 006100
7038 030704 006101
7039 030706 005302
7040 030710 001373
7041
7042 030712 063700 060176
7043 030716 005501
7044 030720 010037 005574
7045 030724 010137 005576
7046 030730 000241
7047 030732 006100
7048 030734 006101
7049 030736 006100
7050 030740 006101
7051 030742 006100
7052 030744 006101
7053 030746 020127 000037
7054 030752 103403
7055 030754 112737 000001 003143
7056
7057 030762 104401 007142
7058 030766 012746 005574
7059 030772 004737 055436
7060 030776 004737 055752
7061 031002 104401 001315
7062 031006 104401 001315
7063 031012 104410
7064 031014 000207
7065
7066
7067
7068
7069
7070
7071
7072
7073
7074 031016 016646 000002
7075 031022 104403

```

```

; *IT USES THE VALUES RETURNED, TO SET THE LIMITS ON PARAMETER MA.
; *IT ALSO TYPES "LAST PHYS MEM ADR = XXXXXXXX" (LEAD ZEROS SUPRS'D),
; *AND SETS THE FLAG UBMPRS = 1 IF 22-BIT ADDRESSES ARE USED (11/70).
; *****
SIZMEM: SAVREG ;SAVE R0-R5
MOV #200,$KT11 ;SET MEM MGT KEY FOR $SIZE
JSR PC,$SIZE ;SIZE MEMORY
TST $KT11 ;SEE IF MEM MGT PRESENT
BMI $S ;BR IF MEM MGT PRESENT
MOV $LSTAD,MAHILM ;SET MEM LIMIT LO BITS
CLR MAHILM+2 ;CLEAR MEM LIMIT HI BITS
BR 16$ ;GO TYPE LAST ADDRESS
;SHIFT SAF LEFT 6, AND PUT IN R1-R0
8$: MOV $LSTBK,R0 ;LO BITS
CLR R1 ;HI BITS
MOV #6,R2 ;SET LOOP COUNT = 6
12$: CLC ;ROTATE LOOP
ROL R0
ROL R1
DEC R2
BNE 12$
;ADD VIRTUAL ADDRESS TO SHIFTED SAF TO GET PHYSICAL ADDRESS
ADD $LSTAD,R0 ;ADD LO BITS
ADC R1 ;HI BITS
MOV R0,MAHILM ;SET LO BITS OF MEM LIMIT
MOV R1,MAHILM+2 ;SET HI BITS OF MEM LIMIT
CLC
ROL R0
ROL R1
ROL R0
ROL R1
ROL R0
ROL R1
CMP R1,#37
BLO 16$
MOVB #1,UBMPRS ;SET "UNIBUS MAP PRESENT" FLAG
;TYPE "LAST PHYS MEM ADR = XXXXXXXX"
16$: TYPE LSTMEM ;TYPE "LAST PHYS MEM ADR ="
MOV #MAHILM,-(SP) ;PUT POINTER ON STACK
JSR PC,@#$DB20 ;CONVERT BINARY TO OCTAL ASCII
JSR PC,@#$SUPRS ;TYPE "XXXXXXX"
TYPE ,$CRLF ;TYPE <CR>,<LF>
TYPE , $CRLF
RESREG ;RESTORE R0-R5
RTS PC ;RETURN
; *****
; * GETPRM - INPUT A SIX-DIGIT OCTAL NO. ON TTY KBD
; * ENTER SUBROUTINE WITH OLD PARAMETER VALUE ON STACK. SUBROUTINE
; * TYPES OLD VALUE, AND INPUTS NEW VALUE, RETURNING NEW VALUE ON
; * TOP OF STACK.
; *****
GETPRM: MOV 2(SP),-(SP) ;GET OLD VALUE
TYPOS ;TYPE IT

```

```

7076 031024 006 .BYTE 6 ;SIX DIGITS
7077 031025 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
7078 031026 104401 007475 TYPE NEWMSG ;TYPE "NEW ="
7079 031032 004737 034034 JSR PC,ROCHRS ;READ NEW VALUE FROM KBD
7080 031036 031070 7$ ;(↑C) RETURN ADDRESS
7081 031040 031070 7$ ;(↑Z) RETURN ADDRESS
7082 031042 031070 7$ ;(↑U) OR ERROR RETURN ADDRESS
7083 031044 005700 TST RO ;SEE IF ANY CHARS TYPED
7084 031046 001001 BNE 4$ ;BR IF YES
7085 031050 000207 RTS PC ;RETURN - OLD VALUE UNCHANGED
7086 031052 020027 000006 4$: CMP RO,#6 ;SEE IF > 6 CHARS TYPED
7087 031056 003407 BLE 8$ ;BR IF NOT BAD
7088 031060 104401 005264 6$: TYPE ,BUFF0 ;ECHO BAD INPUT
7089 031064 104401 001314 TYPE ,SQUES
7090 031070 162716 000010 7$: SUB #10,(SP) ;FIX ERROR RETURN PC
7091 031074 000207 RTS PC ;ERROR RETURN
7092 031076 012746 005264 8$: MOV #BUFF0,-(SP) ;PUT POINTER TO CHARS ON STACK
7093 031102 004737 054500 JSR PC,OCTBIN ;CONVERT DIGITS TO BINARY
7094 031106 031060 6$ ;ERROR RETURN ADDRESS
7095 031110 012600 MOV (SP)+,RO ;GET NEW BINARY VALUE
7096 031112 005737 054632 TST $HI0CT ;SEE IF HI BITS ARE 0
7097 031116 001360 BNE 6$ ;BR IF NOT
7098 031120 010066 000002 MOV RO,2(SP) ;PUT NEW VALUE ON STACK
7099 031124 000207 RTS PC ;RETURN

```

```

7100
7101
7102
7103 ;*****
7104 ;SBTTL GTSWRG - OPEN SOFTWARE SWITCH REGISTER FOR MODIFICATION
7105 ;THIS SUBROUTINE ALLOWS THE CONTENTS OF THE SOFTWARE SWITCH
7106 ;REGISTER TO BE MODIFIED BY TTY INPUT. THE SUBROUTINE TYPES
7107 ;* "SWR = XXXXXX NEW = " AND WAITS FOR A NEW OCTAL VALUE
7108 ;*OF UP TO SIX DIGITS TO BE TYPED.
7109 ;*****

```

```

7110 031126 022737 000176 001140 GTSWRG: CMP #SWREG,SWR ;SEE IF SOFTWARE SWR SELECTED
7111 031134 001010 BNE 6$ ;BR IF NOT
7112 031136 013746 000176 MOV SWREG,-(SP) ;PUT OLD VALUE ON STACK
7113 031142 104401 007466 TYPE SWRMSG ;TYPE "SWR ="
7114 031146 004737 031016 JSR PC,GETPRM ;TYPE OLD, GET NEW SWREG VALUE
7115 031152 012637 000176 MOV (SP)+,SWREG ;STORE NEW VALUE
7116 031156 000207 6$: RTS PC ;RETURN

```

```

7117
7118 ;*****
7119 ;INITMM - INITIALIZE MEMORY MANAGEMENT REGISTERS
7120 ;THIS SUBROUTINE INITIALIZES KIPAR'S AND KIPDR'S, FOR
7121 ;CONTIGUOUS 4K PAGES, STARTING AT PHYSICAL ADDRESS 0.
7122 ;KIPAR7 IS LOADED WITH 177600, TO PRESERVE THE I/O PAGE.
7123 ;*22-BIT MODE AND THE UNIBUS MAP ARE ENABLED, IF PRESENT.
7124 ;*BUT MEM MGT IS NOT TURNED ON IN THIS SUBROUTINE. HOWEVER,
7125 ;*MEM MGT TRAPS ARE ENABLED.
7126
7127
7128
7129 ;*****

```

```

7130 031160 104407 INITMM: SAVREG ;SAVE R0-R5
7131 031162 005001 CLR R1 ;INIT FOR PAR LOADING

```

7132	031164	012702	172340			MOV	#KIPAR0,R2	; ADDR OF FIRST PAR
7133	031170	012703	000010			MOV	#8,R3	; LOAD 8 PAR'S AND 8 PDR'S
7134	031174	012762	077406	177740	4\$:	MOV	#77406,-40(R2)	; PDR = 4K UP,READ/WRITE
7135	031202	010122				MOV	R1,(R2)+	; LOAD A PAR
7136	031204	062701	000200			ADD	#200,R1	; UPDATE FOR NEXT PAR
7137	031210	005303				DEC	R3	; DECREMENT LOOP COUNTER
7138	031212	001370				BNE	4\$; LOOP UNTIL ALL 8 ARE LOADED
7139	031214	012742	177600			MOV	#177600,-(R2)	; SET UP KIPAR7 FOR I/O PAGE
7140	031220	105737	003143			TSTB	UBMPRS	; SEE IF 22-BIT ADDRESSES
7141	031224	001403				BEQ	10\$; BR IF NOT
7142	031226	012737	000060	172516		MOV	#60,@#SR3	; ENABLE 22-BIT MODE,AND UNIBUS MAP
7143	031234	012737	001000	177572	10\$:	MOV	#BIT9,@#SR0	; ENABLE KT.1 TRAPS
7144	031242	104410				RESREG		; RESTORE R0-R5
7145	031244	000207				RTS	PC	; RETURN

7146
7147
7148
7149
7150
7151

*SERVICE ROUTINE FOR MEM MGT TRAPS

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 142
GTSWRG - OPEN SOFTWARE SWITCH REGISTER FOR MODIFICATION

SEQ 0141

7152	031246	004737	043720		KTERHD: JSR	PC, REPSUP	:GATHER STATUS FOR PRINTOUT
7153	031252	013737	177572	001174	MOV	@#SRO, \$REG5	:GET SRO
7154	031260	013737	177574	001176	MOV	@#SR1, \$REG6	:GET SR1
7155	031266	013737	177576	001200	MOV	@#SR2, \$REG7	:GET SR2
7156	031274	012737	031320	000004	MOV	#8\$, @#ERRVEC	:SET TIME-OUT VECTOR

M11

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 143
GTSWRG - OPEN SOFTWARE SWITCH REGISTER FOR MODIFICATION

SEQ 0142

7157	031302	012737	000340	000006		MOV	#PR7, @#ERRVEC+2	
7158	031310	013737	172516	001202		MOV	@#SR3, \$REG10	;GET SR3
7159	031316	000406				BR	10\$	
7160	031320	022626			8\$:	CMP	(SP)+, (SP)+	;CLEAN UP STACK

7161 031322 112737 000003
7162 031330 105037 064272
7163 031334 104121
7164 031336 000137 046150
7165
7166
7167
7168
7169
7170

065632 MOVB #3,DF30+18. ;FIX PRINTOUT FOR NO SR3
 CLRB DH704+11.
10\$: ERROR 121 ;KT11 FAILURE
 JMP HLTPRG ;ABORT !!!

7171 031342 010146
7172 031344 013746 000004
7173 031350 013746 000006
7174 031354 012737 031376 000004
7175 031362 012701 172100
7176 031366 005011
7177 031370 012711 000001
7178 031374 000401
7179 031376 022626
7180 031400 062701 000002
7181 031404 020127 172140
7182 031410 001366
7183 031412 012637 000006
7184 031416 012637 000004
7185 031422 012601
7186 031424 000207
7187
7188
7189
7190
7191
7192

```

;*****
;*ENBCSR - ENABLE MEMORY CSR'S FOR PARITY ERRORS
;*****
ENBCSR: MOV    R1, -(SP)            ;SAVE R1
         MOV    @#ERRVEC, -(SP)   ;SAVE OLD VECTORS
         MOV    @#ERRVEC+2, -(SP)
         MOV    @#ERRVEC        ;SET TIME-OUT VECTOR
         MOV    #MEMCSR, R1      ;ADRS OF MEMORY CSR'S
4$:        CLR    (R1)            ;ZERO THIS CSR
             MOV    #BIT0, (R1)   ;SET ENABLE IN THIS CSR
             BR     10$
8$:        CMP    (SP)+, (SP)+    ;CLEAN UP THE STACK
10$:        ADD    #2, R1        ;INCREMENT TO NEXT CSR ADRS
             CMP    R1, #MEMCSR+40 ;SEE IF DONE CHECKING YET
             BNE    4$           ;BR IF NOT
             MOV    (SP)+, @#ERRVEC+2 ;RESTORE OLD VECTORS
             MOV    (SP)+, @#ERRVEC
             MOV    (SP)+, R1     ;RESTORE R1
             RTS    PC           ;RETURN
    
```

7193 031426 010146
7194 031430 013746 000004
7195 031434 013746 000006
7196 031440 004737 043720
7197 031444 016637 000006 001174
7198 031452 012737 031576 000004
7199 031460 012737 000340 000006
7200
7201 031466 013737 177740 001176
7202 031474 013737 177742 001200
7203 031502 013737 177744 001202
7204 031510 012737 064326 065654
7205 031516 112737 000004 065656
7206 031524 104122
7207 031526 005737 001200
7208 031532 001011
7209 031534 023727 001176 073660
7210 031542 103005
7211 031544 105737 003144
7212 031550 001002
7213 031552 000137 046150
7214 031556 012637 000006
7215 031562 012637 000004
7216 031566 012601

```

;*****
;*SERVICE ROUTINE FOR MEM PARITY ERRORS
;*****
MPERHD: MOV    R1, -(SP)            ;SAVE R1
         MOV    @#ERRVEC, -(SP)   ;SAVE OLD VECTORS
         MOV    @#ERRVEC+2, -(SP)
         JSR    PC, REPSUP        ;GATHER STATUS FOR PRINTOUT
         MOV    6(SP), $REG5      ;GET PC OF ERROR
         MOV    #10$, @#ERRVEC    ;SET T.O. VECTOR
         MOV    #PR7, @#ERRVEC+2
;HANDLE 11/70 MEMORY PARITY ERROR
         MOV    @#LOERAD, $REG6   ;LOW ERROR ADRS REG
         MOV    @#HIERAD, $REG7   ;HI ERROR ADRS REG
         MOV    @#MEMSYS, $REG10   ;MEMORY SYSTEM REG
         MOV    #DH707, DF31+16. ;FIX ERROR MSG FOR 11/70
         MOVB   #4, DF31+18.
         ERROR    122            ;11/70 MEM PARITY ERROR
         TST    $REG7            ;SEE IF BAD MEMORY IS IN PROGRAM AREA
         BNE    6$               ;BR IF NOT
         CMP    $REG6, #RWBUF+6000 ;SEE IF BAD MEM IS IN PROG. AREA
         BNE    6$               ;BR IF NOT
4$:        BHS    6$               ;BR IF NOT
             TSTB   MEMABT       ;SEE IF ABORT DESIRED
             BNE    6$            ;BR IF NOT
             JMP    HLTPRG       ;ABORT !!!
6$:        MOV    (SP)+, @#ERRVEC+2 ;RESTORE T.O. VECTOR
             MOV    (SP)+, @#ERRVEC
             MOV    (SP)+, R1     ;RESTORE R1
    
```

```

7217 031570 004737 031342      JSR      PC,ENBCSR      ;GO CLEAR AND ENABLE CSR'S
7218 031574 000002              RTI                    ;RETURN
7219                                ;HANDLE ALL OTHER MEMORY PARITY ERRORS (NON-11/70)
7220 031576 022626              10$: CMP      (SP)+,(SP)+ ;CLEAN UP THE STACK
7221 031600 012737 031630 000004 MOV      #14$,J#ERRVEC ;SET T.O. VECTOR
7222 031606 012701 172100      MOV      #MEMCSR,R1    ;GET FIRST CSR ADDRESS
7223 031612 011137 001200      12$: MOV      (R1),SREG7 ;CHECK FOR A MEMORY CSR
7224 031616 100005              BPL      16$           ;BR IF NO ERROR SET HERE
7225 031620 010137 001176      MOV      R1,SREG6     ;GET CSR ADDRESS
7226 031624 104122              ERROR   12$          ;MEMORY PARITY ERROR (NON-11/70)
7227 031626 000746              BR       4$           ;GO SEE IF SHOULD ABORT
7228 031630 022626              14$: CMP      (SP)+,(SP)+ ;CLEAN UP STACK
7229 031632 062701 000002      16$: ADD      #2,R1     ;INCR R1 TO POINT TO NEXT CSR
7230 031636 020127 172140      CMP      R1,#MEMCSR+40 ;SEE IF DONE CHECKING
7231 031642 103763              BLO     12$          ;BR IF NOT
7232 031644 000744              BR       6$           ;RETURN

```

```

7233
7234
7235
7236
7237
7238
7239
7240
7241
7242
7243
7244
7245
7246
7247
7248
7249
7250
7251
7252
7253
7254
7255
7256
7257
7258
7259

```

```

;*****
;PREPAR - PREPARE MEM MGT FOR RELOCATION
;THIS SUBROUTINE CALLS INITMM, AND THEN SETS UP CONSTANT
;FOR KIPAR6 IN SAVPAR, AND LOADS THE UNIBUS MAP REGISTERS,
;IF PRESENT.
;*****

```

```

7242 031646 104407              PREPAR: SAVREG        ;SAVE R0-R5
7243 031650 004737 031160      JSR      PC,INITMM    ;INIT MEM MGT REGISTERS
7244 031654 013700 005604      MOV      PMA,R0       ;LO BITS OF MA
7245 031660 042700 017777      BIC      #17777,R0    ;MASK FOR BITS 13-15
7246 031664 013701 005606      MOV      PMA+2,R1     ;HI BITS OF MA
7247 031670 010003              MOV      R0,R3        ;SAVE THESE BITS
7248 031672 010104              MOV      R1,R4
7249 031674 006100              ROL     R0            ;GET MA BITS 13-21 INTO R1 BITS 7-15
7250 031676 006101              ROL     R1
7251 031700 006100              ROL     R0
7252 031702 006101              ROL     R1
7253 031704 000301              SWAB   R1
7254 031706 006100              ROL     R0
7255 031710 106001              RORB   R1
7256 031712 010137 003176      MOV      R1,SAVPAR    ;CONSTANT FOR LOADING PAR6 LATER
7257 031716 105737 003143      TSTB   UBMPRS        ;SEE IF UNIBUS MAP ENABLED
7258 031722 001420              BEQ    9$            ;BR IF NOT (NO UNIBUS MAPPING)
7259                                ;PREPARE FOR 22-BIT ADDRESSING - LOAD UNIBUS MAP REGISTERS
7260 031724 012700 170200      MOV      #MAPLOD,R0   ;STARTING ADDR OF MAP REGISTERS
7261 031730 012701 000037      MOV      #31,R1       ;SET REGISTER COUNTER
7262 031734 010320 000000      4$: MOV      R3,(R0)+  ;LOAD A MAP REGISTER
7263 031736 010420              MOV      R4,(R0)+
7264 031740 062703 020000      ADD     #20000,R3     ;ADD 4K WORDS
7265 031744 005504              ADC     R4
7266 031746 077106              SOB    R1,4$         ;LOOP UNTIL 31(DEC) ARE LOADED
7267 031750 042765 160000 000010 BIC     #160000,P.BALO(R5) ;CLEAR BA BITS 13-17
7268 031756 142765 000003 000007 BIC     #3,P.BAHI(R5)
7269 031764 104410              9$: RESREG          ;RESTORE R0-R5
7270 031766 000207              RTS     PC            ;RETURN
7271
7272

```

```

7273
7274
7275
7276
7277
7278 031770 005737 005576
7279 031774 001404
7280 031776 012737 160000 005540
7281 032004 000412
7282 032006 023727 005574 157776
7283 032014 103370
7284 032016 013737 005574 005540
7285 032024 062737 000002 005540
7286 032032 162737 006000 005540
7287 032040 000207
7288
7289
7290
7291
7292
7293
7294
7295
7296
7297
7298
7299
7300
7301
7302 032042 104407
7303 032044 005004
7304 032046 000410
7305 032050 104407
7306 032052 105037 003133
7307 032056 105737 003134
7308 032062 001425
7309 032064 012704 000001
7310 032070 005737 000170
7311 032074 001020
7312 032076 012702 003000
7313 032102 013703 005540
7314 032106 013700 005542
7315 032112 013701 005544
7316 032116 005737 057732
7317 032122 100417
7318 032124 005704
7319 032126 001005
7320 032130 012320
7321 032132 005302
7322 032134 001375
7323 032136 104410
7324 032140 000207
7325 032142 062700 006000
7326 032146 062703 006000
7327 032152 014043
7328 032154 005302

```

```

*****
* FNDXDP - FIND STARTING ADR OF XXDP LOADER , AND STORE IT
* IN XXDPAD.
*****
FNDXDP: TST MAHILM+2 ;TEST HI BITS OF UPPER MEMORY LIMIT
        BEQ 6$ ;BR IF HI BITS ARE 0
4$: MOV #160000,XXDPAD ;START OF 28K IS END OF XXDP
    BR 8$
6$: CMP MAHILM,#157776 ;SEE IF MEM LIMIT > OR = 157776
    BHIS 4$ ;BR IF YES
    MOV MAHILM,XXDPAD ;HI MEM LIMIT IS END OF XXDP
    ADD #2,XXDPAD ;ADD 2 BYTES
8$: SUB #6000,XXDPAD ;COMPUTE START OF XXDP
    RTS PC ;RETURN

```

```

*****
* SAVXDP - SAVE THE XXDP LOADER IN HI MEMORY
* THIS SUBROUTINE MOVES THE XXDP LOADER, WHICH RESIDES AT THE
* PHYSICAL ADDRESS STORED IN XXDPAD, TO THE PHYSICAL ADDRESS
* STORED IN XDPSAV AND XDPSAV+2. A TOTAL OF 1536(DEC) WORDS ARE MOVED.
*
* GETXDP - RESTORE THE XXDP LOADER TO ORIGINAL LOCATION
* THIS SUBROUTINE MOVES THE RELOCATED XXDP LOADER FROM THE ADDRESS
* STORED IN XDPSAV, XDPSAV+2, BACK TO LOCATION XXDPAD (ITS ORIGINAL
* ADDRESS).
*****
SAVXDP: SAVREG ;SAVE R0-R5
        CLR R4 ;SET INDICATOR TO SAVE XXDP
        BR XDP1
GETXDP: SAVREG ;SAVE R0-R5
        CLR XOVLD ;CLEAR XXDP OVERLAID INDICATOR
        TST XDPSVD ;SEE IF XXDP WAS SAVED
        BEQ XDP2 ;BR IF NOT SAVED
        MOV #1,R4 ;SET INDICATOR TO GET XXDP
XDP1: TST KILLDR ;SEE IF OK TO OVERLAY LOADER
        BNE XDP2 ;BR IF YES, TO EXIT
        MOV #1536.,R2 ;GET SET TO MOVE 1536(DEC) WORDS
        MOV XXDPAD,R3 ;GET ORIG ADR OF START OF XXDP
        MOV XDPSAV,R0 ;GET SAVE ADR LO BITS
        MOV XDPSAV+2,R1 ;HI BITS
        TST SKT11 ;SEE IF MEM MGT PRESENT
        BMI XDP3 ;BR IF PRESENT
        TST R4 ;SEE IF WANT TO SAVE OR GET XXDP
        BNE XDP4 ;BR IF WANT TO GET XXDP
6$: MOV (R3)+,(R0)+ ;SAVE A WORD
        DEC R2 ;SEE IF 1536(DEC) WORDS YET
        BNE 6$ ;BR IF NOT YET
XDP2: RESREG ;RESTORE R0-R5
        RTS PC ;RETURN
XDP4: ADD #6000,R0 ;POINT TO END OF SAVE AREA
        ADD #6000,R3 ;POINT TO END OF XXDP LOADER AREA
8$: MOV -(R0),-(R3) ;GET A WORD
        DEC R2 ;SEE IF 1536(DEC) WORDS YET

```

```

7329 032156 001375      BNE      8$          ;BR IF NOT YET
7330 032160 000766      BR       XDP2       ;GO EXIT
7331                                     ;COME HERE IF MEM MGT
7332 032162 004737 031160 XDP3: JSR      PC,INITMM ;INIT MEM MGT REGISTERS
7333 032166 006100      ROL      R0          ;GET ADR BITS 13-21 INTO R1 BITS 7-15
7334 032170 006101      ROL      R1
7335 032172 006100      ROL      R0
7336 032174 006101      ROL      R1
7337 032176 000301      SWAB     R1
7338 032200 006100      ROL      R0
7339 032202 106001      RORB     R1
7340 032204 010137 172354 MOV      R1,#KIPAR6 ;SET UP PAR6
7341 032210 013701 005542 MOV      XDP5AV,R1 ;GET LO ADRS BITS
7342 032214 042701 160000 BIC      #160000,R1 ;FIX UP R1 TO REFERENCE PAR6
7343 032220 052701 140000 BIS      #140000,R1
7344 032224 005704      TST      R4          ;SEE IF WANT TO SAVE OR GET XXDP
7345 032226 001007      BNE      18$        ;BR IF WANT TO GET XXDP
7346 032230 012305      MOV      (R3)+,R5 ;SAVE A WORD
7347 032232 005237 177572 INC      @#SRO ;TURN ON MEMORY MANAGEMENT
7348 032236 010521      MOV      R5,(R1)+
7349 032240 005337 177572 DEC      @#SRO ;TURN OFF MEMORY MANAGEMENT
7350 032244 000406      BR       20$
7351 032246 005237 177572 18$: INC      @#SRO ;TURN ON MEMORY MANAGEMENT
7352 032252 012105      MOV      (R1)+,R5 ;GET A WORD
7353 032254 005337 177572 DEC      @#SRO ;TURN OFF MEMORY MANAGEMENT
7354 032260 010523      MOV      R5,(R3)+
7355 032262 032701 020000 20$: BIT      #BIT13,R1 ;SEE IF OVERFLOW TO PAGE 7
7356 032266 001405      BEQ      22$        ;BR IF NOT
7357 032270 042701 020000 BIC      #BIT13,R1 ;SET PAGE = 6 AGAIN
7358 032274 062737 000200 172354 ADD      #200,@#KIPAR6 ;UPDATE PAR BY 4K
7359 032302 005302      DEC      R2          ;SEE IF 1536 WORDS YET
7360 032304 001347      BNE      16$        ;BR IF NOT YET
7361 032306 000713      BR       XDP2       ;BR TO RETURN

```

```

7362
7363
7364
7365 ;*****
7366 ;SBTTL INITSS - INITIALIZE SUBSYSTEM
7367 ;*
7368 ;*THIS SUBROUTINE INITIALIZES THE DRIVER AND ITS PARAMETERS
7369 ;*AND DOES A SUBSYSTEM CLEAR.
7370 ;* USES - R2,R5
7371 ;* CALL:
7372 ;* JSR PC,INITSS
7373 ;*****
7374
7375 032310 012737 044200 003046 INITSS: MOV      #ERRHDL,A.ABNL ;SET UP ABNORMAL ERROR RETURN ADDRESS
7376 032316 012737 042732 003044 MOV      #ERRFRE,A.NORM ;SET UP NORMAL RETURN ADDRESS
7377 032324 013702 003036      MOV      RKBAS,R2 ;GET ADDRESS OF RK611 REGISTERS
7378 032330 012705 002630      MOV      #PARM0,R5 ;GET ADDRESS OF PARAMETER BLOCK
7379 032334 105037 003142      CLRB     NORTRY ;CLEAR "NO-RETRY" FLAG
7380 032340 004737 032410      JSR      PC,CLPRM ;CLEAR DRIVER INPUT PARAMETERS
7381 032344 112765 000177 000001 MOVB     #SUBCLR,P.CMND(R5) ;SET SUBSYSTEM CLEAR COMMAND
7382 032352 004737 042542      JSR      PC,DRVCAL ;DO SUBSYSTEM CLEAR
7383 032356 113765 005500 000000 MOVB     DRIVE,P.DRVN(R5) ;SET CURRENT DRIVE NO.
7384 032364 113737 005500 002714 MOVB     DRIVE,PARM1 ;SET DRIVE NO. IN ALTERNATE P.B.

```

```

7385 032372 113765 003125 000007      MOVB   FORMAT,P.CS1H(R5) ;SET CURRENT DRIVE FORMAT
7386 032400 153765 003124 000007      BISB   TYPFMT,P.CS1H(R5) ;SET DRV TYP
7387 032406 000207                RTS    PC                ;SUBROUTINE EXIT

```

7388
7389
7390
7391
7392
7393
7394
7395
7396
7397

```

;*****
;SBTTL CLRPRM - CLEAR DRIVER INPUT PARAMETERS
;THIS SUBROUTINE ZEROS THE FIRST 14 BYTES IN THE DRIVER
;PARAMETER BLOCK (WHOSE ADDRESS IS IN R5).
;CALL - JSR PC,CLRPRM
;*****

```

```

7398 032410 010046
7399 032412 010546
7400 032414 010500
7401 032416 062705 000016
7402 032422 005020
7403 032424 020005
7404 032426 001375
7405 032430 012605
7406 032432 012600
7407 032434 000207

```

```

CLRPRM: MOV    RO,-(SP)      ;SAVE RO
        MOV    R5,-(SP)   ;SAVE R5
        MOV    R5,RO      ;GET PARAMETER BLOCK ADDRESS
        ADD    #P.CS1,R5  ;COMPUTE LIMIT ADDRESS
1$:     CLR    (RO)+      ;CLEAR A WORD IN PARAMETER BLOCK
        CMP    RO,R5      ;SEE IF DONE YET
        BNE   1$         ;BR IF NOT DONE YET
        MOV    (SP)+,R5   ;RESTORE R5
        MOV    (SP)+,RO   ;RESTORE RO
        RTS    PC        ;RETURN

```

7408
7409
7410
7411
7412
7413
7414
7415
7416
7417
7418
7419
7420
7421
7422
7423
7424
7425
7426
7427

```

;*****
;SBTTL SCNDRV - SCAN DRIVE FOR STATUS
;THIS SUBROUTINE SCANS THE SELECTED DRIVE TO INSURE
;THAT THE DRIVE IS ON-LINE, READY, NOT WRITE-LOCKED,
;AND NOT LOADED WITH AN ALIGNMENT CARTRIDGE. IF ANY
;OF THESE CONDITIONS ARE NOT MET, AN APPROPRIATE
;MESSAGE IS TYPED, RK06 INTERRUPT IS DISABLED, AND
;A RETURN IS MADE TO THE ADDRESS LISTED IMMEDIATELY
;AFTER THE CALL TO SCNDRV. THE REQUESTED DRIVE NO.
;MUST BE PASSED TO THE SUBROUTINE IN WORD "DRIVE".
;ALSO, IF RUNNING FROM ADRS 200 AND RK06 IS LOAD MEDIUM,
;DRIVE 0 WILL BE REJECTED FOR USE.
;CALL - JSR PC,SCNDRV
;      <ERROR RETURN ADDRESS>
;*****

```

```

7428 032436 105037 003124
7429 032442 004737 032310
7430 032446 113765 005500 000000
7431 032454 042712 000100
7432 032460 113762 005500 000010
7433 032466 105737 003124
7434 032472 001003
7435 032474 012712 000001
7436 032500 000402
7437 032502 012712 002001
7438 032506 005037 005534
7439 032512 005237 005534
7440 032516 001375

```

```

SCNDRV: CLRB   TYPFMT      ;ASSUME RK06 TO START
        JSR   PC,INITSS   ;INITIALIZE DRIVER AND CLEAR SUBSYSTEM
        MOVB  DRIVE,P.DRVN(R5) ;GET DRIVE NUMBER
        BIC   #IE,(R2)    ;DISABLE RK06 INTERRUPT
        MOVB  DRIVE,RKCS2(R2) ;SET DRIVE NO. IN RKCS2
        TSTB  TYPFMT      ;SEE IF RK07
        BNE   5$         ;BR IF YES
        MOV   #GO,(R2)    ;ELSE SET GO BIT IN CS1 FOR RK06
        BR   7$
5$:     MOV   #<CDT!GO>,(R2)
7$:     CLR   SCRACH      ;CLEAR STALL COUNTER
14$:    INC   SCRACH      ;INCREMENT STALL COUNTER
        BNE  14$        ;STALL FOR SEVERAL MILLI-SEC

```

```

7441 032520 032762 001000 000010 BIT #MDS,RKCS2(R2) ;SEE IF MDS ERROR
7442 032526 001417 BEQ 18$ ;BR IF NOT
7443 032530 112765 000101 000001 MOV #SELDRV,P.CMND(R5) ;SET COMMAND FOR ERROR REPORT
7444 032536 011265 000016 MOV (R2),P.CSI(R5) ;GET RKCS1
7445 032542 004737 052226 JSR PC,I.CST1 ;GET OTHER RK611 REGS FOR REPORT
7446 032546 004737 043720 JSR PC,REPSUP ;SET UP ERROR REPORT
7447 032552 104052 ERROR 52 ;REPORT MDS ERROR
7448 032554 052737 000200 005474 BIS #ABORT,RECODE ;SET ABORT FLAG
7449 032562 000137 045774 JMP ALLTRM ;GO ABORT TESTING
7450 032566 032762 000040 000014 18$: BIT #DTYE,RKER(R2) ;SEE IF DRV TYP ERR
7451 032574 001403 BEQ 20$ ;BR IF NO=RK06
7452 032576 152737 000004 003124 BISB #B.CDT,TYPFMT ;ELSE SET FOR RK07
7453 032604 004737 032310 20$: JSR PC,INITSS ;INIT THE SUBSYSTEM
7454 032610 112765 000141 000001 MOV #R0STAT,P.CMND(R5) ;SET READ DRIVE STATUS COMMAND
7455 032616 012737 030360 003046 MOV #NEDHDL,A.ABNL ;SET NED ABNORMAL RETURN ADDRESS
7456 032624 012737 000377 005530 MOV #377,NEWON ;INIT. ON-LINE INDICATOR
7457 032632 004737 042542 JSR PC,DRVCAL ;READ ALL DRIVE STATUS
7458 ;SEE IF THIS DRIVE EXISTS AND IS ON-LINE
7459 032636 012737 044200 003046 MOV #ERRHDL,A.ABNL ;RESTORE ABNL RETURN ADDRESS
7460 032644 022737 000377 005530 CMP #377,NEWON ;SEE IF NED INDICATION ON THIS DRIVE
7461 032652 001430 BEQ 4$ ;BR IF NED NOT SET
7462 032654 005737 003150 TST AUTOFG ;FORM AUTO MODE ?
7463 032660 001017 BNE 2$
7464 032662 113737 005500 007530 MOVB DRIVE,BADDRV+6 ;GET DRIVE NO. INTO BUF
7465 032670 152737 000060 007530 BISB #'0,BADDRV+6 ;CONVERT TO ASCII
7466 032676 104401 007522 TYPE ,BADDRV ;TYPE "DRIVE X"
7467 032702 104401 007533 TYPE ,NXDRV ;TYPE "NON-EXISTENT"
7468 032706 132737 000200 001341 BITB #BIT7,SENVN ;SEE IF APT
7469 032714 001401 BEQ 2$ ;BR IF NO
7470 032716 104123 ERROR 123 ;NED UNDER APT SIZING
7471 ;SERVICE ERRORS HERE
7472 032720 042762 000100 000000 2$: BIC #IE,RKCS1(R2) ;DISABLE RK06 INTERRUPT
7473 032726 017616 000000 MOV @ (SP), (SP) ;SET UP ERROR RETURN ADDRESS
7474 032732 000207 RTS ;ERROR RETURN
7475 ;SEE IF DRIVE IS READY
7476 032734 032765 000200 000040 4$: BIT #S.DRY,P.A00(R5) ;TEST FOR DRIVE READY
7477 032742 001016 BNE 6$ ;BR IF DRIVE IS READY
7478 032744 005737 003150 TST AUTOFG
7479 032750 001363 BNE 2$ ;SKIP IF FROM AUTO MODE
7480 032752 113737 005500 007530 MOVB DRIVE,BADDRV+6 ;GET DRIVE NO. INTO BUF
7481 032760 152737 000060 007530 BISB #'0,BADDRV+6 ;CONVERT TO ASCII
7482 032766 104401 007522 TYPE ,BADDRV ;TYPE "DRIVE X"
7483 032772 104401 007547 TYPE ,NTREDY ;TYPE "NOT READY"
7484 032776 000750 BR 2$ ;TAKE ERROR EXIT
7485 ;SEE IF DRIVE IS WRITE ENABLED
7486 033000 032765 004000 000040 6$: BIT #S.WRL,P.A00(R5) ;SEE IF WRITE LOCK SET
7487 033006 001416 BEQ 8$ ;BR IF WRITE LOCK NOT SET
7488 033010 005737 003150 TST AUTOFG
7489 033014 001013 BNE 8$ ;FROM THE AUTO MODE
7490 033016 113737 005500 007530 MOVB DRIVE,BADDRV+6 ;GET DRIVE NO.
7491 033024 152737 000060 007530 BISB #'0,BADDRV+6 ;CONVERT TO ASCII
7492 033032 104401 007522 TYPE ,BADDRV ;TYPE "DRIVE X"
7493 033036 104401 007561 TYPE ,WRTLOK ;TYPE "WRITE-LOCKED"
7494 033042 000726 BR 2$ ;TAKE ERROR EXIT
7495 ;SEE IF DRIVE NOT LOADED WITH ALIGNMENT CARTRIDGE
7496 033044 112765 000103 000001 8$: MOVB #PACK,P.CMND(R5) ;SET PACK ACKNOWLEDGE COMMAND

```

```

7497 033052 004737 042542 JSR PC,DRVCAL ;SET VOLUME VALID
7498 033056 112765 000113 000001 MOVB #RECAL,P.CMND(R5) ;SET RECAL COMMAND
7499 033064 004737 042542 JSR PC,DRVCAL ;RECALIBRATE THE DRIVE
7500 033070 112765 000121 000001 MOVB #RDATA,P.CMND(R5) ;SET READ COMMAND
7501 033076 105737 003124 TSTB TYPFMT ;SEE IF RK07
7502 033102 001004 BNE 25$ ;BR IF YES
7503 033104 012765 000632 000002 MOV #632,P.CYLN(R5)
7504 033112 000403 BR 27$
7505 033114 012765 001456 000002 25$: MOV #1456,P.CYLN(R5)
7506 033122 112765 000002 000005 27$: MOVB #LSTTRK,P.TRCK(R5) ;SET TRACK = 2
7507 033130 012765 065660 000010 MOV #RWBUF,P.BALO(R5) ;BUS ADDRESS
7508 033136 012765 177774 000012 MOV #-4,P.WC(R5) ;READ 4 WORDS
7509 033144 142765 000020 000007 BICB #B.CFMT,P.CS1H(R5) ;SET 22 SECTOR FORMAT
7510 033152 153765 003124 000007 BISB TYPFMT,P.CS1H(R5)
7511 033160 005737 003150 TST AUTOFG ;SEE IF FROM AUTO MODE
7512 033164 001027 BNE 12$ ;EXIT IF SO
7513 033166 004737 042542 JSR PC,DRVCAL ;READ 4 WORDS OF BAD SECTOR FILE
7514 033172 032737 100000 005474 BIT #ANYDER,RECODE ;SEE IF DATA ERROR
7515 033200 001402 BEQ 10$ ;BR IF OK
7516 033202 104401 013202 TYPE ,BAD632 ;TYPE READ ERROR MESSAGE
7517 033206 022737 177777 065666 10$: CMP #177777,RWBUF+6 ;SEE IF ALL 1'S IN I.D. WORD 3
7518 033214 001013 BNE 12$ ;BR IF NOT ALL 1'S
7519 033216 113737 005500 007530 MOVB DRIVE,BADDRV+6 ;GET DRIVE NO.
7520 033224 152737 000060 007530 BISB #'0,BADDRV+6 ;CONVERT TO ASCII
7521 033232 104401 007522 TYPE ,BADDRV ;TYPE "DRIVE X"
7522 033236 104401 007574 TYPE ,ALNPAK ;TYPE "LOADED WITH ALIGN PACK"
7523 033242 000626 BR 25$ ;TAKE ERROR EXIT
7524 :ERROR FREE RETURN
7525 033244 062716 000002 12$: ADD #2,(SP) ;FIX UP RETURN PC
7526 033250 000207 RTS PC ;RETURN

```

```

7527
7528
7529
7530 ;*****
7531 ;SBTTL CHKDRV - CHECK STATUS OF DRIVE
7532 ;*THIS SUBROUTINE CHECKS THE DESIRED DRIVE TO DETERMINE
7533 ;*IF THE DRIVE IS ON-LINE,READY,WRITE-PROTECTED. IF NOT, THE
7534 ;*APPROPRIATE ERROR MESSAGE IS TYPED,AND THE CPU HALTS
7535 ;*WHILE MANUAL INTERVENTION TAKES PLACE TO CORRECT THE
7536 ;*PROBLEM. THE OPERATOR THEN DEPRESSES 'CONT' TO PROCEED,
7537 ;*AND A RETURN IS MADE TO THE ADDRESS LISTED IMMEDIATELY
7538 ;*AFTER THE CALL. IF THERE ARE NO PROBLEMS WITH THIS
7539 ;*DRIVE, A NORMAL RETURN IS MADE.
7540 ;*R5 MUST CONTAIN THE ADDRESS OF THE PARAMETER BLOCK,
7541 ;*AND R2 MUST CONTAIN THE RK06 REGISTER BASE ADDRESS.
7542 ;*
7543 ;* CALL:
7544 ;* JSR PC,CHKDRV
7545 ;* ERROR ADDRESS
7546 ;*****
7547

```

```

7548 033252 113765 005500 000000 CHKDRV: MOVB DRIVE,P.DRVN(R5) ;SET DESIRED DRIVE NUMBER
7549 033260 112765 000141 000001 MOVB #RSTAT,P.CMND(R5) ;SET READ DRIVE STATUS COMMAND
7550 033266 012737 030360 003046 MOV #NEDHDL,A.ABNL ;SET NED ABNORMAL RETURN ADDRESS
7551 033274 012737 000377 005530 MOV #377,NEWON ;INITIALIZE ON-LINE INDICATOR
7552 033302 004737 042542 JSR PC,DRVCAL ;READ ALL DRIVE STATUS

```

```

7553 ;SEE IF THIS DRIVE EXISTS AND IS ON-LINE
7554 033306 012737 044200 003046 MOV #ERRHDL,A,ABNL ;RESTORE ABNORMAL DRIVER RETURN ADDRESS
7555 033314 022737 000377 005530 CMP #377,NEWON ;SEE IF NED INDICATION ON THIS DRIVE
7556 033322 001411 BEQ 1$ ;BR IF NED NOT SET
7557 033324 113701 005500 MOVB DRIVE,R1 ;GET DRIVE NUMBER
7558 033330 152701 000060 BISB #'D,R1 ;CONVERT TO ASCII
7559 033334 110137 011754 MOVB R1,DRVND ;PUT DRIVE NO. INTO MSG BUFFER
7560 033340 104401 011744 TYPE NONEXD ;TYPE NON-EXISTENT DRIVE MESSAGE
7561 033344 000414 BR 3$ ;SERVICE THE ERROR
7562 ;SEE IF DESIRED DRIVE IS READY
7563 033346 032765 000200 000040 1$: BIT #S.DRY,P.ADD(R5) ;TEST FOR DRIVE READY
7564 033354 001024 BNE 4$ ;BR IF DRIVE READY
7565 033356 113701 005500 MOVB DRIVE,R1 ;GET DRIVE NUMBER
7566 033362 152701 000060 BISB #'D,R1 ;CONVERT TO ASCII
7567 033366 110137 011622 MOVB R1,DRNRDY ;PUT DRIVE NUMBER IN MESSAGE BUFFER
7568 033372 104401 011612 TYPE NOTRDY ;TYPE DRIVE NOT READY MESSAGE
7569 ;SERVICE ALL ERRORS HERE
7570 033376 042762 000100 000000 3$: BIC #IE,RKCS1(R2) ;CLEAR RK06 INTERRUPT ENABLE BIT
7571 033404 000000 HALT ;HALT IS NECESSARY DURING MANUAL
7572 ; INTERVENTIONS, TO CHANGE PACK,
7573 ; WRITE LOCK, START DRIVE, ETC.
7574 ; PRESS 'CONT' TO PROCEED !
7575 033406 112765 000177 000001 MOVB #SUBCLR,P.CMND(R5) ;SET SUBSYSTEM CLEAR COMMAND
7576 033414 004737 042542 JSR PC,DRVCAL ;CLEAR THE SUBSYSTEM
7577 033420 017616 000000 MOV 2(SP),(SP) ;SET UP ERROR RETURN ADDRESS
7578 033424 000207 RTS PC ;ERROR RETURN
7579 ;SEE IF DRIVE IS WRITE-LOCKED
7580 033426 032765 004000 000040 4$: BIT #S.WRL,P.ADD(R5) ;SEE IF WRITE LOCK SET
7581 033434 001011 BNE 5$ ;BR IF WRITE-PROTECTED
7582 033436 113701 005500 MOVB DRIVE,R1 ;GET DRIVE NUMBER
7583 033442 152701 000060 BISB #'D,R1 ;CONVERT TO ASCII
7584 033446 110137 012051 MOVB R1,NOTDLK ;PUT DRIVE NUMBER IN MSG BUFFER
7585 033452 104401 012041 TYPE NOTLOK ;TYPE "DRIVE NOT WRITE-LOCKED"
7586 033456 000747 BR 3$ ;SERVICE THE ERROR
7587 ;RECALIBRATE DESIRED DRIVE, SET VOLUME VALID
7588 033460 112765 000113 000001 5$: MOVB #RECAL,P.CMND(R5) ;SET RECALIBRATE COMMAND
7589 033466 004737 042542 JSR PC,DRVCAL ;RECALIBRATE DRIVE
7590 033472 112765 000103 000001 MOVB #PACK,P.CMND(R5) ;SET PACK ACKNOWLEDGE COMMAND
7591 033500 004737 JSR PC,DRVCAL ;DO PACK ACK. (SETS VOLUME VALID)
7592 ;RETURN HERE
7593 033504 062716 000002 7$: ADD #2,(SP) ;FIX UP RETURN ADDRESS ON STACK
7594 033510 000207 RTS PC ;ERROR-FREE RETURN
7595
7596
7597
7598 ;*****
7599 ;* ALNSEK - SEEK IN SINGLE INCREMENTS FROM CYL 0 TO ALIGNMENT CYL (365 OCT).
7600 ;*****
7601 033512 112765 000117 000001 ALNSEK: MOVB #SEEK,P.CMND(R5) ;SET SEEK COMMAND
7602 033520 005065 000002 CLR P.CYLN(R5) ;INIT CYL TO 0
7603 033524 004737 042542 JSR PC,DRVCAL ;SEEK TO THIS CYL
7604 033530 005265 000002 INC P.CYLN(R5) ;INCR CYL NO.
7605 033534 105737 003124 TSTB TYPFMT ;CURRENT DRIVE IS AN RK07 ?
7606 033540 001005 BNE 3$ ;BRANCH IF IT IS
7607 033542 022765 000366 000002 CMP #ALNCYL+1,P.CYLN(R5) ;SEE IF 365 REACHED YET
7608 033550 001365 BNE 2$ ;BR IF NOT YET

```



```

7609 033552 000207          RTS      PC      ;RETURN
7610 033554 022765 000761 000002 3$:  CMP      #761,P.CYLN(R5) ;REACH THE CYLINDER 760 FOR RK07
7611 033562 001360          BNE     2$      ;CONTINUE
7612 033564 000207          RTS      PC      ;EXIT

```

```

7613
7614
7615
7616
7617
7618
7619
7620
7621
7622
7623
7624
7625
7626
7627
7628
7629
7630
7631
7632
7633
7634
7635
7636
7637
7638
7639
7640
7641
7642
7643
7644

```

```

;*****
;* WAIT4R - THIS SUBROUTINE UNLOADS HEADS ON THE CURRENT DRIVE, TYPES
;* "TYPE <R> WHEN READY", AND THEN LOADS THE HEADS WHEN <R> IS TYPED.
;*****

```

```

WAIT4R: MOVB   #UNLOAD,P.CMND(R5) ;SET UNLOAD COMMAND
        JSR   PC,DRVCAL          ;UNLOAD HEADS ON THIS DRIVE
        MOVB   #RDSTAT,P.CMND(R5) ;SET READ STATUS COMMAND
1$:     JSR   PC,DRVCAL          ;READ STATUS OF DRIVE
        BIT   #S.HDHM,P.A01(R5) ;SEE IF HEADS UNLOADED YET
        BEQ   1$                ;BR IF NOT YET
2$:     TYPE  R,RWNRDY          ;TYPE "TYPE <R> WHEN READY"
        JSR   PC,PREPKB        ;PREPARE FOR KBD INPUT
        TST   INTCHR           ;SEE IF ANY INPUT YET
4$:     BEQ   4$                ;BR IF NOT YET
        CMP   #'R,INTCHR       ;SEE IF <R> TYPED
        BEQ   6$                ;BR IF <R> TYPED
        JSR   PC,ECOBAD        ;ECHO BAD INPUT
        BR    2$                ;GO ASK AGAIN
6$:     MOVB   #SRTSPL,P.CMND(R5) ;SET START SPINDLE COMMAND
        JSR   PC,DRVCAL        ;START SPINDLE AND LOAD HEADS
        RTS   PC                ;RETURN

```

```

;*****
;*SETUP - SET UP FOR LOOP ON ERROR
;*THIS SUBROUTINE CANNOT BE CALLED BY ANY OTHER
;*SUBROUTINE --- ONLY MAIN-LINE CODE !!!!
;*****

```

```

SETUP:  MOV   (SP),#STACK-2 ;MOVE RETURN PC ON STACK
        MOV   #STACK-2,SP  ;RE-INIT THE STACK POINTER
        CLR   RECODE       ;CLEAR ERROR RECOVERY FLAGS
        CLRB  ERRCNT       ;CLEAR RETRY ERROR COUNT
        MOV   #PARAM,R5    ;SET PARAM BLK ADRS
        MOVB  #SUBCLR,P.CMND(R5) ;SET SUBSYSTEM CLEAR CMND
        JSR   PC,DRVCAL    ;CLEAR THE SUBSYSTEM
        MOV   #PR0,#PS     ;RE-ESTABLISH PRIORITY 0
        RTS   PC           ;RETURN

```

```

;*****
;SBTTL CHKITR - CHECK CURRENT TEST ITERATION NUMBER
;*THIS SUBROUTINE LOADS THE ITERATION NUMBER FOR THE CURRENT
;*TEST INTO $TIMES, AND CHECKS IT TO DETERMINE IF THIS TEST
;*SHOULD BE RUN. IF ITERATION NO. = 0, THE SUBROUTINE RETURNS
;*TO THE STORED PC (AND THE TEST WILL BE SKIPPED). IF IT IS
;*NOT 0, THE RETURN IS MADE TO PC+2, AND THE TEST WILL
;*BE RUN. HOWEVER, ON THE FIRST PASS (QUICK VERIFY) OF A RUN

```

```

7645 033672 011637 001076
7646 033676 012706 001076
7647 033702 005037 005474
7648 033706 105037 003126
7649 033712 012705 002630
7650 033716 112765 000177 000001
7651 033724 004737 042542
7652 033730 012737 000000 177776
7653 033736 000207
7654
7655
7656
7657
7658
7659
7660
7661
7662
7663
7664

```

; *WHICH STARTED AT ADRS 200, ALL TESTS WILL BE RUN ONCE.

```

7665
7666
7667 033740 010146
7668 033742 112737 000144 001115
7669 033750 105737 003135
7670 033754 001006
7671 033756 105737 003116
7672 033762 001007
7673 033764 005737 001326
7674 033770 001004
7675 033772 012737 000001 001304 3$:
7676 034000 000410
7677 034002 113701 001102 4$:
7678 034006 005301
7679 034010 006301
7680 034012 016137 005630 001304
7681 034020 001403
7682 034022 062766 000004 000002 1$:
7683 034030 012601 2$:
7684 034032 000207
7685
7686
7687
7688
7689
7690
7691
7692
7693
7694
7695
7696
7697
7698
7699
7700
7701
7702
7703
7704
7705
7706
7707
7708
7709
7710
7711
7712
7713
7714
7715
7716
7717
7718
7719
7720

```

```

CHKITR: MOV R1, -(SP) ;SAVE R1
MOV #100, $ERMAX ;SET MAX ERROR CNT TO 100 FOR $SCOPE
TSTB DULACS ;SEE IF DUAL-ACCESS FLAG SET
BNE 3$ ;BR IF YES
TSTB MDFLAG ;SEE IF 200 START
BNE 4$ ;BR IF NOT
TST $PASS ;SEE IF FIRST PASS
BNE 4$ ;BR IF NOT
MOV #1, $TIMES ;SET UP FOR 1 ITERATION
BR 1$ ;GO RUN DUAL-ACCESS TEST
MOV $STNM, R1 ;GET CURRENT TEST NUMBER
DEC R1 ;DECREMENT BY 1
ASL R1 ;DOUBLE IT, TO GET TEST LIST INDEX
MOV TSTLST(R1), $TIMES ;LOAD ITERATION NUMBER
BEQ 2$ ;BR IF TEST SHOULD BE SKIPPED
ADD #4, 2(SP) ;ADJUST RETURN PC TO RUN THIS TEST
MOV (SP)+, R1 ;RESTORE R1
RTS PC ;RETURN

```

```

; *****
; SBTTL RDCHRS - READ A STRING OF KBD INPUT CHARS
; *THIS SUBROUTINE READS A STRING OF UP TO EIGHTY INPUT
; *CHARACTERS AT THE KBD, TERMINATED BY <CR>, AND PLACES
; *THEM IN BUFF0, TERMINATED BY A NULL (0) BYTE.
; *RUB-OUT AND (↑) FEATURES ARE PROVIDED.
; *IMMEDIATELY FOLLOWING THE SUBROUTINE CALL, THREE SPECIAL
; *RETURN ADDRESSES MUST BE LISTED: THE FIRST RETURN IS
; *TAKEN IF (↑C) IS TYPED, THE SECOND IS TAKEN IF (↑Z) IS
; *TYPED, AND THE THIRD IS TAKEN IF (↑U) OR INVALID INPUT IS TYPED.
; *IF (↑G) IS TYPED, THE SOFTWARE SWITCH REGISTER IS OPENED
; *FOR MODIFICATION, IF SELECTED, AND THEN THE (↑G) RETURN
; *IS TAKEN.
; *THE NUMBER OF INPUT CHARACTERS IN THE BUFFER IS RETURNED
; *IN R0.
; *
; * CALL - JSR PC, RDCHRS
; * <CONTROL-C RETURN ADDRESS>
; * <CONTROL-Z RETURN ADDRESS>
; * <CONTROL-U OR ERROR RETURN ADDRESS>
; *
; * RETURN
; *****

```

```

RDCHRS:
MOV R1, -(SP) ;SAVE R1
MOV R2, -(SP) ;SAVE R2
CLR R0 ;INITIALIZE CHARACTER COUNT
CLR R1 ;INITIALIZE RUB-OUT INDICATOR
; READ A CHARACTER
2$: RDCHR ;READ A CHARACTER
MOV (SP)+, R2 ;GET CHARACTER INTO R2
; CHECK FOR (↑C)
CMPB #003, R2 ;SEE IF (↑C) TYPED

```

7721	034054	001006			BNE	4\$;BR IF NOT (↑C)
7722	034056	104401	013246		TYPE	,CNTRLC		;ECHO (↑C)
7723	034062	017666	000004	000004	MOV	4(SP),4(SP)		;PUT RETURN ADDRESS ON STACK
7724	034070	000523			BR	24\$;BR TO TAKE EXIT
7725					;CHECK FOR (↑Z)			
7726	034072	122702	000032		4\$:	CMPB	#032,R2	;SEE IF (↑Z) TYPED
7727	034076	001006				BNE	6\$;BR IF NOT (↑Z)
7728	034100	104401	013253		TYPE	,CNTRLZ		;ECHO (↑Z)
7729	034104	062766	000002	000004	ADD	2,4(SP)		;MAKE OLD PC POINT TO NEXT RETURN ADR.
7730	034112	000763			BR	3\$;BR TO TAKE (↑Z) EXIT
7731					;CHECK FOR (↑U)			
7732	034114	122702	000025		6\$:	CMPB	#025,R2	;SEE IF (↑U) TYPED
7733	034120	001006				BNE	8\$;BR IF NOT (↑U)
7734	034122	104401	013265		TYPE	,CNTRLU		;ECHO (↑U)
7735	034126	062766	000004	000004	7\$:	ADD	4,4(SP)	;MAKE OLD PC POINT TO NEXT RETURN ADDR.
7736	034134	000752			BR	3\$;BR TO TAKE (↑U) EXIT
7737					;CHECK FOR (↑G)			
7738	034136	122702	000007		8\$:	CMPB	#007,R2	;SEE IF (↑G) TYPED
7739	034142	001005				BNE	9\$;BR IF NOT (↑G)
7740	034144	104401	013272		TYPE	,CNTRLG		;ECHO (↑G)
7741	034150	004737	031126		JSR	PC,GTSWRG		;OPEN SOFTWARE SWITCH REG. FOR CHANGE
7742	034154	000764			BR	7\$;TAKE (↑U) RETURN
7743					;CHECK FOR RUB-OUT (DELETE)			
7744	034156	122702	000177		9\$:	CMPB	#177,R2	;SEE IF RUB-OUT (DEL) TYPED
7745	034162	001020				BNE	14\$;BR IF NOT RUB-OUT
7746	034164	005700			TST	R0		;CHECK THE CHARACTER COUNT
7747	034166	001726			BEQ	2\$;BR IF COUNT = 0
7748	034170	005701			TST	R1		;CHECK THE RUB-OUT INDICATOR
7749	034172	001003			BNE	11\$;BR IF WE HAD A PREVIOUS RUB-OUT
7750	034174	005201			INC	R1		;SET RUB-OUT INDICATOR
7751	034176	104401	013303		TYPE	,BKSLSH		;TYPE A BACK-SLASH (\)
7752	034202	005037	005534		11\$:	CLR	SCRACH	;USE SCRATCH WORD FOR TEMP. BUFFER
7753	034206	005300			DEC	R0		;DECREMENT COUNT
7754	034210	116037	005264	005534	MOV	BUFFO(R0),SCRACH		;GET LAST CHAR. INTO BUFFER
7755	034216	104401	005534		TYPE	,SCRACH		;ECHO CHARACTER TO BE DELETED
7756	034222	000710			BR	2\$;GO READ ANOTHER CHARACTER
7757	034224	005701			14\$:	TST	R1	;CHECK THE RUB-OUT INDICATOR
7758	034226	001403			BEQ	15\$;BR IF INDICATOR IS NOT SET
7759	034230	104401	013303		TYPE	,BKSLSH		;TYPE A BACK-SLASH
7760	034234	005001			CLR	R1		;CLEAR THE RUB-OUT INDICATOR
7761					;CHECK FOR CARRIAGE RETURN			
7762	034236	122702	000015		16\$:	CMPB	#015,R2	;SEE IF <CR> TYPED
7763	034242	001426			BEQ	19\$;BR IF <CR>
7764					;HANDLE POSSIBLE DIGIT			
7765	034244	005037	005534		CLR	SCRACH		;USE SCRATCH WORD FOR TEMP. BUFFER
7766	034250	110237	005534		MOV	R2,SCRACH		;GET THIS CHARACTER INTO BUFFER
7767	034254	104401	005534		TYPE	,SCRACH		;ECHO THE CHARACTER TYPED
7768	034260	110260	005264		MOV	R2,BUFFO(R0)		;PUT CHARACTER INTO BUFFER
7769	034264	005200			INC	R0		;INCREMENT CHARACTER COUNTER
7770	034266	022700	000120		CMP	#80.,R0		;SEE IF TOO MANY CHARACTERS TYPED
7771	034272	001264			BNE	2\$;BR IF NOT TOO MANY
7772	034274	104401	001315		TYPE	,\$CRLF		;TYPE <CR> AND <LF>
7773	034300	112760	000000	005264	MOV	0,BUFFO(R0)		;PUT TERMINATING NULL INTO BUFFER
7774	034306	104401	005264		TYPE	,BUFFO		;ECHO INPUT STRING
7775	034312	104401	001314		TYPE	,\$QUES		;TYPE <?> <CR> <LF>
7776	034316	000703			BR	7\$;TAKE ERROR EXIT FROM RDCHRS

7777 034320 104401 001315
7778 034324 112760 000000
7779 034332 062766 000006
7780 034340 012602
7781 034342 012601
7782 034344 000207
7783
7784
7785
7786
7787
7788
7789
7790
7791
7792
7793
7794
7795
7796 034346 104401 013314
7797 034352 010146
7798 034354 006216
7799 034356 005216
7800 034360 104403
7801 034362 002
7802 034363 000
7803 034364 104401 013307
7804 034370 016146 005630
7805 034374 104403
7806 034376 006
7807 034377 000
7808 034400 000207
7809
7810
7811
7812
7813
7814
7815
7816
7817
7818
7819
7820
7821
7822 034402 016137 006010 013316
7823 034410 104401 013316
7824 034414 016137 005660 005470
7825 034422 005037 005472
7826 034426 022761 040515 006010
7827 034434 001003
7828 034436 016137 005662 005472
7829 034444 012746 005470
7830 034450 004737 055436
7831 034454 004737 055752
7832 034460 000207

19\$: TYPE \$CRLF ;TYPE <CR>,<LF>
MOV #0,BUFF0(R0) ;PUT TERMINATING NULL INTO BUFFER
ADD #6,4(SP) ;FIX UP RETURN ADDRESS
24\$: MOV (SP)+,R2 ;RESTORE R2
MOV (SP)+,R1 ;RESTORE R1
RTS PC ;SUBROUTINE EXIT

;SBTTL TYPTST - TYPE CURRENT TEST AND ITERATION NUMBER
;THIS SUBROUTINE TYPES : "XX YYYYYY" WITH NO <CR>
;OR <LF>. XX IS THE NUMBER OF THE CURRENT TEST AND
;YYYYYY IS THE NUMBER OF ITERATIONS FOR THAT TEST.
;R1 MUST CONTAIN THE INDEX INTO THE TEST LIST FOR
;THE CURRENT TEST.
;CALL - JSR PC, TYPTST

TYPTST: TYPE SPACE1 ;TYPE A SPACE
MOV R1, -(SP) ;PUT INDEX ONTO STACK
ASR (SP) ;DIVIDE BY 2
INC (SP) ;INCREMENT TO GET TEST NO.
TYPOS ;TYPE TEST NO. IN OCTAL
.BYTE 2 ;TYPE 2 DIGITS
.BYTE 0 ;SUPPRESS LEADING ZEROS
TYPE SPACE6 ;TYPE 6 SPACES
MOV #STLST(R1), -(SP) ;PUT CURRENT ITERATION NO. ONTO STACK
TYPOS ;TYPE ITERATION NO. IN OCTAL
.BYTE 6 ;TYPE 6 DIGITS
.BYTE 0 ;SUPPRESS LEADING ZEROS
RTS PC ;RETURN

;SBTTL TYPRM - TYPE CURRENT PARAMETER
;THIS SUBROUTINE TYPES THE LINE : XX=YYYYYYYY
;WHERE XX IS THE CURRENT PARAMETER MNEMONIC, AND
;YYYYYYYY IS ITS VALUE IN OCTAL DIGITS, WITH LEADING
;ZEROS SUPPRESSED. NOTE: <CR> AND <LF> ARE NOT DONE.
;ON ENTRY, R1 MUST CONTAIN THE INDEX INTO THE
;PARAMETER TABLES, FOR THE CURRENT PARAMETER.
;CALL - JSR PC, TYPRM

TYPRM: MOV PRMNEM(R1), PRMBUF ;PUT MNEMONIC INTO OUTPUT BUFFER
TYPE PRMBUF ;TYPE "XX="
MOV PRMLST(R1), LOWOCT ;PUT LOW BITS OF PARAM. INTO LOWOCT
CLR HIGOCT ;CLEAR HIGH BINARY BITS
CMP #MA, PRMNEM(R1) ;SEE IF PARAMETER IS (MA)
BNE 1\$;BR IF NOT (MA)
MOV PRMLST+2(R1), HIGOCT ;PUT HI BITS OF PARAM. INTO HIGOCT
1\$: MOV #LOWOCT, -(SP) ;PUT ADDRESS OF BINARY VALUE ON STACK
JSR PC, @#\$DB20 ;CONVERT BINARY TO OCTAL ASCII
JSR PC, @#\$SUPRS ;TYPE YYYYYYYY, SUPPRESSING LEADING 0'S
RTS PC ;RETURN

```

7833
7834
7835
7836
7837
7838
7839
7840
7841
7842
7843
7844
7845
7846
7847 034462
7848 034462 104401 013322
7849 034466 010146
7850 034470 006216
7851 034472 104403
7852 034474 002
7853 034475 001
7854 034476 104401 013330
7855 034502 016146 006776
7856 034506 104403
7857 034510 006
7858 034511 001
7859 034512 000207
7860
7861
7862
7863
7864
7865
7866
7867
7868
7869
7870
7871
7872
7873
7874
7875
7876
7877 034514
7878 034514 010046
7879 034516 010146
7880 034520 010246
7881
7882 034522 022761 052120 006010
7883 034530 001127
7884
7885 034532 032737 100000 005700
7886 034540 001523
7887
7888 034542 104401 010730

```

```

;*****
;SBTTL TYPFRM - TYPE CURRENT WORD OF DATA PATTERN 15
;THIS SUBROUTINE TYPES THE LINE : WORD XX = YYYYYY,
;WHERE XX IS THE NUMBER OF THE CURRENT WORD OF
;USER-DEFINED PATTERN 15, AND YYYYYY IS ITS 16-BIT
;VALUE, IN OCTAL DIGITS. <CR> AND <LF> ARE NOT TYPED.
;ON ENTRY, R1 MUST CONTAIN THE INDEX OF THE CURRENT
;WORD IN THE PATTERN 15 TABLE.
;CALL - JSR PC,TYPFRM
;*****

```

```

TYPFRM:
      TYPE      WORDSP      ;TYPE "WORD "
      MOV       R1,-(SP)    ;PUT INDEX ONTO STACK
      ASR       (SP)       ;DIVIDE BY TWO FOR WORD NO.
      TYPOS     ;GO TYPE WORD NUMBER
      .BYTE     2           ;DIGIT COUNT = 2 FOR TYPOC
      .BYTE     1           ;TELL TYPOS TO TYPE LEADING ZEROS
      TYPE      EQUALS     ;TYPE " = "
      MOV       PAT15(R1),-(SP) ;GET BINARY VALUE OF THIS WORD
      TYPOS     ;TYPE VALUE IN OCTAL
      .BYTE     6           ;TYPE 6 DIGITS
      .BYTE     1           ;TYPE LEADING ZEROS
      RTS      PC          ;RETURN

```

```

;*****
;SBTTL MODP15 - MODIFY USER-DEFINED PATTERN 15
;THIS SUBROUTINE DETERMINES WHETHER OR NOT USER-DEFINED
;DATA PATTERN 15 SHOULD BE OPENED FOR MODIFICATION, AND
;IF SO, IT REQUESTS THE NEW VALUES AND CONTROLS THEIR
;INPUT ON THE TTY. IT CHECKS VALUES FOR VALIDITY, AND
;LOADS THE 16 WORDS INTO THE PATTERN 15 TABLE (PAT15).
;IF THE OPERATOR ANSWERS THE REQUEST FOR A PATTERN WORD
;WITH EXCLAMATION POINT (!) (CR), THE SUBROUTINE
;PROPAGATES THE LAST WORD TYPED INTO ALL REMAINING
;WORDS OF THE PATTERN 15 TABLE.
;CALL - JSR PC,MODP15
;*****

```

```

MODP15:
      MOV       R0,-(SP)    ;SAVE R0
      MOV       R1,-(SP)    ;SAVE R1
      MOV       R2,-(SP)    ;SAVE R2
;SEE IF PARAMETER IS PT
      CMP       #PT,PRMNM(R1) ;SEE IF CURRENT PARAMETER IS (PT)
      BNE      22$         ;BR IF NOT (PT)
;SEE IF PATTERN 15 IS SPECIFIED
      BIT       #BIT15,PT   ;SEE IF PATTERN 15 SPECIFIED
      BEQ      22$         ;BR IF NOT SPECIFIED
;SEE IF PATTERN 15 SHOULD BE MODIFIED
4$:   TYPE      ,MDFY15    ;ASK WHETHER PATTERN 15 SHOULD BE MODIFIED

```

```

7889 034546 004737 034034      JSR      PC, RDCHRS      ; READ RESPONSE
7890 034552 035020      24$      ; (↑C) RETURN ADDRESS
7891 034554 035030      26$      ; (↑Z) RETURN ADDRESS
7892 034556 034614      8$       ; (↑U) OR ERROR RETURN ADDRESS
7893 034560 005700      TST      RO             ; SEE IF NULL INPUT
7894 034562 001512      BEQ      22$           ; BR IF MODIFICATION NOT REQUESTED
7895 034564 022737 000115 005264  CMP      #'M, BUFFO     ; SEE IF (M) TYPED
7896 034572 001405      BEQ      6$           ; BR IF MODIFICATION REQUESTED
7897 034574 104401 005264  TYPE     , BUFFO       ; ECHO BAD INPUT
7898 034600 104401 001314  TYPE     , $QUES
7899 034604 000756      BR       4$           ; GO ASK AGAIN
7900                                ; MODIFY PATTERN 15
7901 034606 104401 010706 6$:      TYPE     , SELP15     ; TYPE "MODIFY PATTERN 15"
7902 034612 005001      CLR      R1           ; INITIALIZE WORD INDEX
7903 034614 004737 034462 8$:      JSR      PC, TYPPAT   ; TYPE CURRENT WORD AND VALUE
7904 034620 104401 013314  TYPE     , SPACE1     ; TYPE A SPACE
7905 034624 104401 013334  TYPE     , PROMPT     ; TYPE ASTERISK AND SPACE
7906                                ; READ AND CHECK INPUT, IF ANY
7907 034630 004737 034034      JSR      PC, RDCHRS   ; READ NEW DATA PATTERN WORD
7908 034634 035020      24$      ; (↑C) RETURN ADDRESS FOR RDCHRS
7909 034636 035030      26$      ; (↑Z) RETURN ADDRESS FOR RDCHRS
7910 034640 034614      8$       ; (↑U) OR ERROR RETURN ADDR. FOR RDCHRS
7911 034642 005700      TST      RO             ; SEE IF ANY INPUT
7912 034644 001006      BNE     12$           ; BR IF ANY INPUT
7913 034646 062701 000002 10$:     ADD      #2, R1        ; INCREMENT WORD INDEX
7914 034652 022701 000040  CMP      #32., R1     ; SEE IF ALL DONE
7915 034656 001454      BEQ     22$           ; BR IF DONE, TO RETURN
7916 034660 000755      BR      8$           ; CONTINUE WITH NEXT WORD
7917 034662 022737 000041 005264 12$:     CMP      #'!, BUFFO   ; SEE IF (!) TYPED
7918 034670 001431      BEQ     16$           ; BR TO PROPAGATE CURRENT VALUE
7919 034672 005002      CLR      R2           ; INIT. (!) INDICATOR
7920 034674 122760 000041 005263  CMPB    #'!, BUFFO-1(RO) ; SEE IF LAST CHAR IN BUF IS (!)
7921 034702 001004      BNE     14$           ; BR IF NOT (!)
7922 034704 105060 005263  CLRB    BUFFO-1(RO)   ; INSERT TERMINATOR BYTE
7923 034710 005300      DEC     R0            ; DECREMENT CHAR COUNT
7924 034712 005202      INC     R2            ; SET (!) INDICATOR
7925 034714 022700 000006 14$:     CMP      #6, RO        ; SEE HOW MANY CHARS NOW
7926 034720 002426      BLT    20$           ; BR IF TOO MANY
7927 034722 012746 005264  MOV     #BUFFO, -(SP) ; GET BUF. ADDR. ON STACK FOR OCTBIN
7928 034726 004737 054500  JSR     PC, OCTBIN    ; CHECK DIGITS AND CONVERT TO BINARY
7929 034732 034776      20$      ; ERROR RETURN ADDRESS FOR OCTBIN
7930 034734 012600      MOV     (SP)+, RO     ; GET BINARY VALUE
7931 034736 005737 054632  TST     $HI OCT      ; SEE IF VALUE EXCEEDS 16 BITS
7932 034742 001015      BNE     20$           ; BR TO ECHO BAD INPUT
7933 034744 010061 006776  MOV     R0, PAT15(R1) ; PUT NEW WORD VALUE INTO TABLE
7934 034750 005702      TST     R2            ; SEE IF (!) WAS TYPED
7935 034752 001735      BEQ     10$           ; BR IF (!) WAS NOT TYPED
7936                                ; PROPAGATE CURRENT WORD TO END OF PATTERN 15 TABLE
7937 034754 022701 000036 16$:     CMP      #30., R1     ; SEE IF ALL DONE YET
7938 034760 001413      BEQ     22$           ; BR IF DONE
7939 034762 016161 006776 007000  MOV     PAT15(R1), PAT15+2(R1) ; PROPAGATE TO NEXT WORD
7940 034770 062701 000002  ADD     #2, R1        ; INCREMENT WORD INDEX
7941 034774 000767      BR      16$          ; LOOP UNTIL DONE
7942                                ; ECHO BAD INPUT
7943 034776 104401 005264 20$:     TYPE     , BUFFO     ; ECHO BAD INPUT
7944 035002 104401 001314  TYPE     , $QUES      ; TYPE <?> AND <CR>, <LF>

```

```

7945 035006 000702
7946
7947 035010 012602
7948 035012 012601
7949 035014 012600
7950 035016 000207
7951
7952 035020 012766 014434 000006
7953 035026 000770
7954
7955 035030 012766 016020 000006
7956 035036 000764
7957
7958
7959
7960
7961
7962
7963
7964
7965
7966
7967
7968
7969
7970
7971
7972
7973
7974
7975
7976 035040 104407
7977 035042 010102
7978 035044 006302
7979 035046 022761 040515 006010
7980 035054 001422
7981 035056 005737 005472
7982 035062 001403
7983 035064 017616 000000
7984 035070 000475
7985
7986 035072 023762 005470 005734
7987 035100 103771
7988 035102 023762 005470 005736
7989 035110 101365
7990
7991 035112 013761 005470 005660
7992 035120 000457
7993
7994 035122 032737 000001 005470
7995 035130 001355
7996 035132 023762 005472 005736
7997 035140 103751
7998 035142 001004
7999 035144 023762 005470 005734
8000 035152 103744

```

```

;NORMAL RETURN
22$: BR 8$ ;BR TO ASK AGAIN
MOV (SP)+,R2 ;RESTORE R2
MOV (SP)+,R1 ;RESTORE R1
MOV (SP)+,R0 ;RESTORE R0
RTS PC ;RETURN
; (↑C) RETURN
24$: MOV #DRVTST,6(SP) ;PC FOR (↑C) RETURN
BR 22$ ;BR TO RETURN
; (↑Z) RETURN
26$: MOV #ASKMDE,6(SP) ;PC FOR (↑Z) RETURN
BR 22$ ;BR TO RETURN

;*****
;SBTTL CHKPRM - CHECK VALUE OF INPUT PARAMETER
;THIS SUBROUTINE CHECKS THE CONTENTS OF LOWOCT AND
;HIGOCT (IF 32-BIT VALUE) AGAINST LOWER AND UPPER
;LIMITS FOR THE CURRENT PARAMETER. THE PARAMETER TABLE
;INDEX FOR THE CURRENT PARAMETER MUST BE PASSED
;TO CHKPRM IN R1 ON ENTRY. IF THE PARAMETER VALUE
;IS LEGAL, IT IS ENTERED INTO THE PARAMETER TABLE
;(PRMLST). IF NOT, A RETURN IS MADE TO THE ADDR. FOLLOWING
;THE CALL TO CHKPRM. IF THE PARAMETER HAS A 2-WORD
;VALUE (32 BITS) R1 IS INCREMENTED BY 2 BEFORE RETURN.
;CALL - JSR PC,CHKPRM
; <ERROR RETURN ADDRESS>
;RETURN
;*****

CHKPRM: SAVREG ;SAVE R0-R5
MOV R1,R2 ;GET COPY OF INDEX
ASL R2 ;DOUBLE IT
CMP #MA,PRMNEM(R1) ;SEE IF PARAMETER IS (MA)
BEQ 20$ ;BR IF (MA)
TST HIGOCT ;SEE IF HIGH BITS = 0
BEQ 18$ ;BR IF ZERO
16$: MOV 2(SP),(SP) ;GET ERROR RETURN PC
BR 30$ ;GO TO RETURN
;CHECK VALIDITY OF 16-BIT PARAMETER VALUE
18$: CMP LOWOCT,PRMLIM(R2) ;SEE IF INPUT VALUE IS TOO SMALL
BLO 16$ ;BR IF INPUT VALUE TOO SMALL
CMP LOWOCT,PRMLIM+2(R2) ;SEE IF INPUT VALUE IS TOO LARGE
BHI 16$ ;BR IF INPUT VALUE IS TOO LARGE
;UPDATE 16-BIT PARAMETER VALUE IN LIST
MOV LOWOCT,PRMLST(R1) ;PUT NEW PARAMETER VALUE INTO LIST
BR 28$ ;BR TO RETURN
;CHECK VALIDITY OF 32-BIT PARAMETER VALUE
20$: BIT #BIT0,LOWOCT ;SEE IF MA IS ODD
BNE 16$ ;BR IF MA IS ODD
CMP HIGOCT,PRMLIM+2(R2) ;SEE IF HIGH WORD TOO SMALL
BLO 16$ ;BR IF HIGH WORD IS TOO SMALL
BNE 24$ ;BR IF HIGH WORD NOT EQUAL TO LOW LIMIT
CMP LOWOCT,PRMLIM(R2) ;SEE IF LOW WORD IS TOO SMALL
BLO 16$ ;BR IF LOW WORD IS TOO SMALL

```

```

8001 035154 023762 005472 005742 24$: CMP HIGOCT,PRMLIM+6(R2) ;SEE IF HIGH WORD IS TOO BIG
8002 035162 101340 BHI 16$ ;BR IF HIGH WORD TOO BIG
8003 035164 001004 BNE 26$ ;BR IF HI WORD NOT EQUAL TO UPPER LIMIT
8004 035166 023762 005470 005740 CMP LOWOCT,PRMLIM+4(R2) ;SEE IF LOW WORD IS TOO LARGE
8005 035174 101333 BHI 16$ ;BR IF LOW WORD IS TOO LARGE
8006 ;UPDATE 32-BIT PARAMETER VALUE IN LIST
8007 035176 013761 005470 005660 26$: MOV LOWOCT,PRMLST(R1) ;PUT LOW WORD INTO LIST
8008 035204 013761 005472 005662 MOV HIGOCT,PRMLST+2(R1) ;PUT HIGH WORD INTO LIST
8009 ;COMPUTE AND TYPE MAX ALLOWABLE WORD COUNT FOR THIS MA
8010 035212 004737 035270 JSR PC,MXWRDC ;GET WORD COUNT IN R1-RO
8011 035216 104401 010446 TYPE MAWRDC ;TYPE "MAX WORD COUNT = "
8012 035222 010037 003172 MOV RO,SUMLO1
8013 035226 010137 003174 MOV R1,SUMHI1
8014 035232 012746 003172 MOV #SUMLO1, -(SP) ;PUT POINTER ON STACK
8015 035236 004737 055436 JSR PC,$DB20 ;CONVERT TO OCTAL
8016 035242 004737 055752 JSR PC,$SUPRS ;TYPE IT
8017 035246 104401 001315 TYPE $CRLF ;TYPE <CR>,<LF>
8018 035252 062766 000002 000014 ADD #2,14(SP) ;INCREMENT R1 INDEX
8019 035260 062716 000002 28$: ADD #2,(SP) ;GET NORMAL RETURN PC
8020 035264 104410 30$: RESREG ;RESTORE RO-R5
8021 035266 000207 RTS PC ;RETURN

```

```

;*****
; *MXWRDC - GET MAX WORD COUNT FOR CURRENT MEM LIMITS AND CURRENT MA,
; *AND LEAVE THE WORD COUNT IN R1-RO. NO REGISTERS ARE SAVED.
;*****

```

```

8028 MXWRDC: MOV MAHILM,RO ;GET LO BITS OF MEM LIM
8029 035270 013700 005574 MOV MAHILM+2,R1 ;HI BITS OF MEM LIM
8030 035274 013701 005576 SUB MA,RO ;SUBTRACT MA FROM MAHILM
8031 035300 163700 005600 SBC R1
8032 035304 005601 SUB MA+2,R1
8033 035306 163701 005602 BMI 27$ ;IF NEGATIVE, RETURN
8034 035312 100413 CLC ;DIVIDE BY 2 TO GET WORDS
8035 035314 000241 ROR R1
8036 035316 006001 ROR RO
8037 035320 006000 ROR #1,RO ;INCREMENT BY 1 WORD
8038 035322 062700 000001 ADD R1
8039 035326 005501 ADC R1
8040 035330 005701 TST R1
8041 035332 001403 BEQ 27$ ;BR IF WORD COUNT < 65,536 DEC
8042 035334 005000 CLR RO ;MAKE WORD COUNT = 65,536
8043 035336 012701 000001 MOV #1,R1
8044 035342 000207 27$: RTS PC ;RETURN

```

```

;*****
; *SBTTL DRVSER - TYPE DRIVE SERIAL NUMBER (LOW 3 DIGITS)
; *THIS SUBROUTINE TYPES "DRIVE SER. NO. XXX" (IN DECIMAL), WITH LEADING
; *ZEROS SUPPRESSED.
;*****

```

```

8052 DRVSER: SAVREG ;SAVE RO-R5
8053 035344 104407 JSR PC,INITSS ;CLEAR S.S. AND PARAMETERS
8054 035346 004737 032310 000001 MOV #ROSTAT,P.CMND(R5) ;SET READ STATUS COMMAND
8055 035352 112765 000141 JSR PC,DRVCAL ;READ STATUS OF THIS DRIVE
8056 035360 004737 042542

```


CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 160
DRVSR - TYPE DRIVE SERIAL NUMBER (LOW 3 DIGITS)

SEQ 0159

8057	035364	104401	011135	TYPE	,DRIV	;TYPE "DRIVE"
8058	035370	104401	011151	TYPE	,SERNM	;TYPE "SER. NO. "
8059	035374	016501	000054	MOV	P,R1(R5),R1	;GET "A" STATUS BYTE 11
8060	035400	012704	055540	MOV	,\$OCTL,R4	;GET ADDR OF CHAR BUFFER
8061	035404	010446		MOV	R4,-(SP)	;STORE IT ON STACK FOR \$SUPRS
8062	035406	012703	000003	MOV	#3,R3	;INIT CHAR COUNT
8063	035412	006101		ROL	R1	;INITIALIZE BIT POSITIONS
8064	035414	006101		ROL	R1	
8065	035416	006101		ROL	R1	;GET NEXT 4 BITS
8066	035420	006101		ROL	R1	
8067	035422	006101		ROL	R1	
8068	035424	006101		ROL	R1	
8069	035426	010100		MOV	R1,R0	;GET A WORKING COPY
8070	035430	042700	177760	BIC	#177760,R0	;CLEAR ALL BUT LOW 4 BITS
8071	035434	052700	000060	BIS	#'0,R0	;CONVERT A DIGIT TO ASCII
8072	035440	110024		MOVB	R0,(R4)+	;PUT ASCII DIGIT INTO CHAR BUFFER
8073	035442	005303		DEC	R3	;DECREMENT CHAR COUNT
8074	035444	001364		BNE	4\$;BR IF NOT 3 CHARS YET
8075	035446	105014		CLRB	(R4)	;INSERT NULL TERMINATOR
8076	035450	004737	055752	JSR	PC,2#\$SUPRS	;TYPE DRIVE SER. NUMBER
8077	035454	104401	001315	TYPE	,SCLF	;TYPE <CR> AND <LF>
8078	035460	104410		RESREG		;RESTORE R0-R5
8079	035462	000207		RTS	PC	;RETURN
8080						
8081						
8082						

```

8083
8084
8085
8086
8087
8088 035464 004737 032310
8089 035470 142765 000020 000007
8090 035476 105737 003125
8091 035502 001402
8092 035504 105265 000004
8093 035510 112765 000121 000001 4$:
8094 035516 013765 020040 000002
8095 035524 112765 000002 000005
8096 035532 012765 065660 000010
8097 035540 012765 177776 000012
8098 035546 004737 042542
8099 035552 104401 011142
8100 035556 104401 011151
8101 035562 012746 065660
8102 035566 004737 055436
8103 035572 004737 055752
8104 035576 104401 001315
8105 035602 000207
8106
8107
8108
8109
8110
8111
8112
8113
8114
8115
8116
8117 035604 010046
8118 035606 010146
8119 035610 032777 000400 143322
8120 035616 001407
8121 035620 004737 054634
8122 035624 013700 054734
8123 035630 006200
8124 035632 006200
8125 035634 000403
8126 035636 013700 005502 1$:
8127 035642 001406
8128 035644 012701 000016 2$:
8129 035650 005301 4$:
8130 035652 001376
8131 035654 005300
8132 035656 001372
8133 035660 012601 6$:
8134 035662 012600
8135 035664 000207
8136
8137
8138

```

```

;*****
;SBTTL CRTSER - TYPE CARTRIDGE SERIAL NUMBER
;THIS SUBROUTINE TYPES "CART. SER. NO. XXXXXXXXXX" (IN OCTAL),
;WITH LEADING ZEROS SUPPRESSED.
;*****
CRTSER: JSR PC,INITSS ;CLEAR S.S. AND PARAMETERS
        BICB #B.CFMT,P.CS1H(R5) ;SET 22 SECTOR FORMAT
        TSTB FORMAT ;CHECK THE ACTUAL FORMAT
        BEQ 4$ ;BR IF 22 SECTORS
        INCB P.SECT(R5) ;IF 20 SECTORS, READ SECTOR 1
        MOV #RDATA,P.CMND(R5) ;SET READ COMMAND
        MOV LSTCYL,P.CYLN(R5) ;SET CYL = 632(OCT)/1456
        MOV #LSTTRK,P.TRCK(R5) ;SET TRACK = 2
        MOV #RWBUF,P.BALO(R5) ;SET READ BUFFER ADDRESS
        MOV #-2,P.WC(R5) ;SET WORD COUNT TO READ 2 WORDS
        JSR PC,DRVCAL ;READ SERIAL NO. IN BSF
        TYPE 'CART' ;TYPE "CART."
        TYPE 'SERNM' ;TYPE "SER. NO."
        MOV #RWBUF,-(SP) ;GET POINTER FOR $DB20
        JSR PC,@#$DB20 ;CONVERT BINARY TO OCTAL
        JSR PC,@#$SUPRS ;TYPE CART. SERIAL NO. IN OCTAL
        TYPE $CRLF ;TYPE <CR> AND <LF>
        RTS PC ;RETURN

```

```

;*****
;SBTTL STALL - STALL FOR ST UNIT STALL TIMES
;IF SWR BIT 8 = 0, THIS SUBROUTINE STALLS FOR ST STALL TIMES,
;WHERE A STALL TIME = 40 US, FOR AN "AVERAGE" CPU. IF BIT 8
;IS EQUAL TO 1, A RANDOM STALL IS APPLIED.
;CALL - JSR PC,STALL
;*****

```

```

STALL: MOV R0,-(SP) ;SAVE R0
        MOV R1,-(SP) ;SAVE R1
        BIT #BIT08,@SWR ;APPLY RANDOM STALL ?
        BEQ 1$ ;BR IF NOT RANDOM
        JSR PC,$RAND ;GENERATE PSEUDO-RANDOM NUMBER
        MOV $LONUM,R0 ;GET IT INTO R0
        ASR R0 ;SCALE IT DOWN
        BR 2$
        MOV STALLS,R0 ;GO STALL WITH RANDOM NO.
        BEQ 6$ ;GET REQUESTED NO. OF STALLS
        MOV #14.,R1 ;RETURN IF NO STALL REQUIRED
        DEC R1 ;SET CONSTANT FOR 40 US
        BNE 4$ ;INNER LOOP COUNTER
        DEC R0 ;INNER LOOP BR
        BNE 2$ ;OUTER LOOP COUNTER
        MOV (SP)+,R1 ;OUTER LOOP BR
        MOV (SP)+,R0 ;RESTORE R1
        RTS PC ;RESTORE R0
        ;RETURN

```

```

8139
8140
8141
8142
8143
8144
8145
8146 035666 004737 054634
8147 035672 013737 054734 005504
8148 035700 042737 177000 005504
8149 035706 023737 020040 005504
8150 035714 002003
8151 035716 043737 020042 005504
8152 035724 000207
8153
8154
8155
8156
8157
8158
8159
8160 035726 104407
8161 035730 012701 065660
8162 035734 010021
8163 035736 020127 066660
8164 035742 001374
8165 035744 104410
8166 035746 000207
8167
8168
8169
8170
8171
8172
8173
8174
8175
8176 035750 104407
8177 035752 016546 000004
8178 035756 105065 000005
8179
8180 035762 116500 000005
8181 035766 062700 000100
8182 035772 004737 035726
8183 035776 112765 000131 000001
8184 036004 004737 042542
8185 036010 105265 000005
8186 036014 122765 000003 000005
8187 036022 001357
8188 036024 012665 000004
8189 036030 104410
8190 036032 000207
8191
8192
8193
8194

```

```

;*****
;SBTTL RNDADR - RANDOM CYLINDER ADDRESS GENERATOR
;THIS SUBROUTINE GENERATES A PSEUDO-RANDOM 9-BIT CYLINDER
;ADDRESS, AND LEAVES IT IN "CYLNR". IT REQUIRES THE SYSMAC
;SUBROUTINE $RAND.
;CALL - JSR PC,RNDADR
;*****
RNDADR: JSR PC,$RAND ;GENERATE 2 16-BIT RANDOM NUMBERS
MOV $LONUM,CYLNR ;GET A RANDOM NUMBER
BIC #177000,CYLNR ;SCALE IT TO 9 BITS
CMP LSTCYL,CYLNR ;SEE IF CYL IS TOO BIG
BGE 2$ ;BR IF CYL IS OK
BIC HOLD1,CYLNR ;SCALE DOWN TO A VALID CYLINDER
PC ;RETURN
2$:

```

```

;*****
;LODSEC - THIS SUBROUTINE LOADS THE CONTENTS OF RO INTO ALL
;256(DEC) WORDS OF THE DATA BUFFER (RWBUFF).
;*****
LODSEC: SAVREG ;SAVE RO-R5
MOV #RWBUFF,R1 ;GET ADDRESS OF DATA BUF INTO R1
2$: MOV RO,(R1)+ ;PUT WORD INTO BUFFER
CMP R1,#RWBUFF+512. ;SEE IF 256 WORDS WRITTEN YET
BNE 2$ ;BR IF NOT DONE YET
RESREG ;RESTORE RO-R5
RTS PC ;RETURN

```

```

;*****
;TRKCHK - THIS SUBROUTINE DOES A WRITE-CHECK OF SECTOR FS ON CYL
;FC FOR EACH OF TRACKS 0, 1, AND 2. THE DATA IS COMPARED TO THE
;TRACK NUMBER + 100(OCT) FOR THAT PARTICULAR BLOCK OF DATA WRITTEN.
;THE PARAMETER BLOCK MUST BE PRE-LOADED WITH THE PROPER PARAMETERS.
;*****
TRKCHK: SAVREG ;SAVE RO-R5
MOV P.SECT(R5),-(SP) ;SAVE TRACK AND SECTOR PARAMETERS
CLRB P.TRCK(R5) ;CLEAR THE TRACK NO.
;LOAD THE DATA BUFFER WITH THE CURRENT TRACK NO.
2$: MOV P.TRCK(R5),RO ;GET TRACK NO. INTO RO
ADD #100,RO ;ADD 100(OCT) TO TRACK NO.
JSR PC,LODSEC ;LOAD DATA BUF WITH TRACK NO. + 100(OCT)
MOV #WATCH,P.CMND(R5) ;SET WRITE CHECK COMMAND
JSR PC,DRVCAL ;PERFORM THE WRITE CHECK
INCB P.TRCK(R5) ;INCREMENT THE TRACK NO.
CMPB #3,P.TRCK(R5) ;SEE IF DONE WITH ALL TRACKS
BNE 2$ ;BR IF NOT DONE YET
MOV (SP)+,P.SECT(R5) ;RESTORE TRACK AND SECTOR PARAMETERS
RESREG ;RESTORE RO-R5
RTS PC ;RETURN

```

```

;*****

```

```

8195
8196
8197
8198 036034 104407
8199 036036 012701 000010
8200 036042 012700 006736
8201 036046 004737 054634
8202 036052 013720 054734
8203 036056 013720 054732
8204 036062 005301
8205 036064 001370
8206 036066 104410
8207 036070 000207
8208
8209
8210
8211
8212
8213
8214
8215
8216
8217
8218
8219
8220
8221 036072 104407
8222 036074 013746 005572
8223 036100 005416
8224 036102 005046
8225 036104 116616 000003
8226 036110 005066 000002
8227 036114 116566 000004 000002
8228 036122 066616 000002
8229 036126 005066 000002
8230 036132 012700 000026
8231 036136 105737 003125
8232 036142 001402
8233 036144 012700 000024
8234 036150 020016
8235 036152 101004
8236 036154 160016
8237 036156 005266 000002
8238 036162 000772
8239 036164 112637 005571
8240 036170 005046
8241 036172 116516 000005
8242 036176 066616 000002
8243 036202 005066 000002
8244 036206 122716 000003
8245 036212 101005
8246 036214 162716 000003
8247 036220 005266 000002
8248 036224 000770
8249 036226 112637 005570
8250 036232 066516 000002

```

```

;*LODP14 - GENERATE SIXTEEN PSEUDO-RANDOM NUMBERS AND LOAD THEM
;*INTO THE PATTERN 14 TABLE.
;*****
LODP14: SAVREG ;SAVE R0-R5
MOV #8, R1 ;INIT LOOP COUNTER TO 8.
MOV #PAT14, R0 ;GET ADDRESS OF PATTERN 14 BUFFER
4$: JSR PC, SRAND ;GENERATE 2 16-BIT RANDOM NUMBERS
MOV $LONUM, (R0)+ ;PUT ONE NUMBER INTO PATTERN
MOV $SHINUM, (R0)+ ;PUT OTHER NO. INTO PATTERN
DEC R1 ;SEE IF 16 WORDS LOADED YET
BNE 4$ ;BR IF NOT YET
RESREG ;RESTORE R0-R5
RTS PC ;RETURN

```

```

;*****
;SPTTL FINADR - COMPUTE FINAL PACK ADDRESS
;THIS SUBROUTINE IS USED AFTER A DATA TRANSFER HAS COMPLETED, TO
;COMPUTE THE FINAL PACK ADDRESS AT TERMINATION. THE 2'S COMP. OF THE
;WORD NO. AT THE POINT OF INTEREST IS PASSED IN LASTWC. THIS IS USED WITH
;P.CYLN(R5), P.TRCK(R5), AND P.SECT(R5) TO COMPUTE THE CORRESPONDING
;PACK ADDRESS, WHICH IS RETURNED IN FINCYL, FINTRK, AND FINSEC.
;THE SUBROUTINE IS USED TO DETERMINE THE PACK ADDRESS OF A SOFTWARE
;DATA MISCOMPARE.
;*****
FINADR: SAVREG ;SAVE R0-R5
MOV LASTWC, -(SP) ;STORE WORD COUNT
NEG (SP) ;MAKE IT POSITIVE
18$: CLR -(SP) ;MAKE ROOM ON STACK
MOV 3(SP), (SP) ;STORE NO. OF SECTORS TRANSFERRED
CLR 2(SP) ;CLEAR LOCATION ON STACK
MOV P.SECT(R5), 2(SP) ;STORE STARTING SECTOR
ADD 2(SP), (SP) ;DETERMINE FINAL SECTOR ADDRESS
CLR 2(SP) ;CLEAR NO. OF TRACKS TRANSFERRED
MOV #22, R0 ;SET FOR 22 SECTORS
TSTB FORMAT ;DETERMINE THE FORMAT
BEQ 19$ ;BR IF 22 SECTORS
MOV #20, R0 ;SET FOR 20 SECTORS
19$: CMP R0, (SP) ;CHECK FOR SECTOR OVERFLOW
BHI 20$ ;NO, CHECK IF SECTOR CORRECT
SUB R0, (SP) ;DECREMENT SECTOR COUNT BY 20 OR 22
INC 2(SP) ;INCREMENT TRACKS TRANSFERRED
BR 19$ ;CHECK FOR SECTOR OVERFLOW
20$: MOV (SP)+, FINSEC ;STORE FINAL SECTOR
CLR -(SP) ;MAKE ROOM FOR TRACKS TRANSFERRED
MOV P.TRCK(R5), (SP) ;STORE STARTING TRACK
ADD 2(SP), (SP) ;DETERMINE FINAL TRACK ADDRESS
CLR 2(SP) ;CLEAR FINAL CYLINDER
21$: CMPB #3, (SP) ;CHECK FOR TRACK OVERFLOW
BHI 22$ ;NO, CHECK FINAL TRACK
SUB #3, (SP) ;DECREMENT TRACK COUNT BY 3
INC 2(SP) ;INCR CYL COUNT
BR 21$ ;CHECK FOR TRACK OVERFLOW
22$: MOV (SP)+, FINTRK ;STORE FINAL TRACK
ADD P.CYLN(R5), (SP) ;CALCULATE FINAL CYLINDER

```

8251	036236	011637	005566	
8252	036242	005726		
8253	036244	104410		
8254	036246	000207		
8255				
8256				
8257				
8258				
8259				
8260				
8261				
8262				
8263				
8264				
8265				
8266				
8267				
8268				
8269	036250	104407		
8270	036252	013702	005564	
8271	036256	005737	005536	
8272	036262	001007		
8273	036264	012700	006036	
8274	036270	012746	000400	
8275	036274	012701	065660	
8276	036300	000463		
8277	036302	005000		
8278	036304	032701	000001	
8279	036310	001003		
8280	036312	005200		
8281	036314	006201		
8282	036316	000772		
8283	036320	006300		
8284	036322	006300		
8285	036324	006300		
8286	036326	006300		
8287	036330	006300		
8288	036332	062700	006036	
8289	036336	012746	000020	
8290	036342	013701	005604	
8291	036346	005737	057732	
8292	036352	100036		
8293				
8294	036354	013737	003176	172354
8295	036362	052737	000001	177572
8296	036370	042701	160000	
8297	036374	052701	140000	
8298	036400	010003		
8299	036402	011604		
8300	036404	012321		
8301	036406	032701	020000	
8302	036412	001405		
8303	036414	062737	000200	172354
8304	036422	042701	020000	
8305	036426	005302		
8306	036430	001403		

```

MOV (SP),FNCYL ;STORE FINAL CYLINDER
TST (SP)+ ;CLEAN OFF STACK
RESREG ;RESTORE RO-R5
RTS PC ;RETURN

```

```

;*****
;SRTL LOdbuf - LOAD THE READ/WRITE DATA BUFFER
;THIS SUBROUTINE LOADS THE READ/WRITE DATA BUFFER (POINTED TO BY
;* PMA AND PMA+2) WITH THE APPROPRIATE REPEATING DATA PATTERN. IF
;* PARAMETER PATRN = 0 ON ENTRY, THE DATA WHICH IS LOADED IS COMPRISED
;* OF ALL THE PATTERNS 00-15 (QUICK VERIFY DEFAULT DATA TEST).
;* IF PATRN IS NOT 0, THE NO. OF WORDS IN THE WORD WDSXFR
;* OF THE PATTERN IDENTIFIED BY THE NO. OF THE BIT SET IN R1 ON
;* ENTRY, ARE LOADED INTO THE BUFFER.
;*****

```

```

LODBUF: SAVREG ;SAVE RO-R5
MOV WDSXFR,R2 ;GET NO. OF WORDS
TST PATRN ;SEE IF QUICK VERIFY DATA TEST DESIRED
BNE 3$ ;BR IF NOT QUICK VERIFY
MOV #PAT00,R0 ;SET DATA PATTERN STARTING ADDRESS
MOV #256,-(SP) ;SET PATTERN WORD COUNT
MOV #RWBUF,R1 ;SET BUFFER ADDRESS
BR 30$ ;PROCEED
3$: CLR RO ;INIT PATTERN NUMBER
4$: BIT #BIT0,R1 ;SEE IF THIS BIT IS SET
BNE 6$ ;BR IF THIS BIT IS SET
INC R0 ;INCREMENT PATTERN NO.
ASR R1 ;SHIFT TO EXAMINE NEXT BIT
BR 4$ ;BR TO CHECK NEXT BIT
6$: ASL RO ;MULTIPLY PATTERN NO. BY 32(DEC)
ASL RO
ASL RO
ASL RO
ADD #PAT00,R0 ;GET ADDRESS OF DESIRED PATTERN
MOV #16,-(SP) ;SET PATTERN WORD COUNT
MOV PMA,R1 ;SET BUFFER ADDRESS
TST $KTI1 ;SEE IF MEM MGT PRESENT
BPL 30$ ;BR IF NOT PRESENT
;BUFFER LOAD LOOP FOR MEM MGT STARTS HERE
MOV SAVPAR,#KIPAR6 ;SET UP WORKING PAR
BIS #BIT0,#SRO ;TURN ON MEMORY MANAGEMENT
BIC #160000,R1 ;FORCE RELOCATION THRU KIPAR6
BIS #140000,R1
22$: MOV RO,R3 ;GET A COPY OF PATTERN ADDRESS
MOV (SP),R4 ;INIT PATTERN WORD COUNT
24$: MOV (R3)+,(R1)+ ;LOAD A DATA WORD INTO BUFFER
BIT #BIT13,R1 ;SEE IF OVERFLOW TO NEXT PAGE
BEQ 26$ ;BR IF NO OVERFLOW
ADD #200,#KIPAR6 ;INCREMENT PAR BY 4K FOR NEW PAGE
BIC #BIT13,R1 ;SET PAGE = 6 AGAIN
26$: DEC R2 ;DECREMENT WORD COUNTER
BEQ 28$ ;BR IF ALL DONE

```

8307	036432	005304				DEC	R4	; DECREMENT PATTERN WORD COUNT
8308	036434	001363				BNE	24\$; BR IF NOT DONE WITH PATTERN YET
8309	036436	000760				BR	22\$; BR TO REPEAT THE PATTERN
8310	036440	042737	000001	177572	28\$:	BIC	#BIT0, 2#SR0	; DISABLE MEMORY MANAGEMENT
8311	036446	000410				BR	44\$; GO TO RETURN
8312						; BUFFER LOAD LOOP FOR NO MEM MGT STARTS HERE		
8313	036450	010003			30\$:	MOV	RO, R3	; GET A COPY OF PATTERN ADDRESS
8314	036452	011604				MOV	(SP), R4	; INIT PATTERN WORD COUNT
8315	036454	012321			34\$:	MOV	(R3)+, (R1)+	; LOAD A DATA WORD INTO BUFFER
8316	036456	005302				DEC	R2	; DECREMENT WORD COUNTER
8317	036460	001403				BEQ	44\$; BR IF ALL DONE
8318	036462	005304				DEC	R4	; DECREMENT PATTERN WORD COUNT
8319	036464	001373				BNE	34\$; BR IF NOT DONE WITH PATTERN YET
8320	036466	000770				BR	30\$; BR TO REPEAT THE PATTERN
8321	036470	005726			44\$:	TST	(SP)+	; POP THE STACK
8322	036472	104410				RESREG		; RESTORE RO-R5
8323	036474	000207				RTS	PC	; RETURN

8324						;*****		
8325						;SBTTL CMPBUF - SOFTWARE COMPARE DATA		
8326						;THIS SUBROUTINE PERFORMS A SOFTWARE COMPARE OF THE R/W DATA BUFFER (POINTED		
8327						;TO BY PMA AND PMA+2) TO THE APPROPRIATE REPEATING DATA PATTERN. IF		
8328						;PARAMETER PATRN = 0 ON ENTRY, THE DATA IS COMPRISED OF ALL THE PATRNS		
8329						;00-15 (QUICK VERIFY DEFAULT DATA TEST).		
8330						;IF PATRN IS NOT 0, THE NO. OF THE BIT SET IN R1 ON ENTRY IDENTIFIES THE		
8331						;REPEATING DATA PATTERN TO COMPARE AGAINST.		
8332						;*****		
8333						CMPBUF: SAVREG ;SAVE RO-R5		
8334						MOV	#40, DH701+38.	;RESTORE ERROR MSG PARAMS
8335	036476	104407				MOV	#7, DF25+2	
8336	036500	112737	000040	064176		MOV	WDSXFR, R2	;SET NO. OF WORDS
8337	036506	012737	000007	065552		CLR	SCRACH	;CLEAR COMPARE ERROR COUNT
8338	036514	013702	005564			JSR	PC, REPSUP	;STORE PREV CMND FOR POSS. PRINT
8339	036520	005037	005534			TST	PATRN	;SEE IF THIS IS QUICK VERIFY DEFAULT DATA TEST
8340	036524	004737	043720			BNE	3\$;BR IF NOT
8341	036530	005737	005536			MOV	#PAT00, RO	;GET DATA PATTERN STARTING ADDR
8342	036534	001007				MOV	#256, -(SP)	;SET PATTERN WORD COUNT
8343	036536	012700	006036			MOV	#RWBUF, R1	;SET BUFFER ADDRESS
8344	036542	012746	000400			BR	30\$;PROCEED
8345	036546	012701	065660			CLR	RO	;INIT PATTERN NO.
8346	036552	000466			3\$:	BIT	#BIT0, R1	;SEE IF THIS BIT IS SET
8347	036554	005000			4\$:	BNE	6\$;BR IF THIS BIT IS SET
8348	036556	032701	000001			INC	RO	;INCREMENT PATTERN NUMBER
8349	036562	001003				ASR	R1	;SHIFT TO EXAMINE NEXT BIT
8350	036564	005200				BR	4\$;BR TO CHECK NEXT BIT
8351	036566	006201			6\$:	ASL	RO	;MULTIPLY PATTERN NO. BY 32(DEC)
8352	036570	000772				ASL	RO	
8353	036572	006300				ASL	RO	
8354	036574	006300				ASL	RO	
8355	036576	006300				ASL	RO	
8356	036600	006300				ASL	RO	
8357	036602	006300				ADD	#PAT00, RO	;GET ADDRESS OF DESIRED PATTERN
8358	036604	062700	006036			MOV	#16, -(SP)	;PATTERN WORD COUNT
8359	036610	012746	000020			MOV	PMA, R1	;SET BUFFER ADDRESS
8360	036614	013701	005604			TST	\$K11	;SEE IF MEM MGT PRESENT
8361	036620	005737	057732					

```

8363 036624 100041          BPL 30$ ;BR IF NOT PRESENT
8364          ;COMPARE LOOP FOR MEM MGT STARTS HERE
8365 036626 013737 003176 172354 MOV SAVPAR,2#KIPAR6 ;SET UP WORKING PAR
8366 036634 052737 000001 177572 BIS #BIT0,2#SRO ;TURN ON MEM MGT
8367 036642 042701 160000 BIC #160000,R1 ;FORCE RELOCATION THRU KIPAR6
8368 036646 052701 140000 BIS #140000,R1
8369 036652 010003 22$: MOV RO,R3 ;GET A COPY OF PATTERN ADDRESS
8370 036654 011604 MOV (SP),R4 ;INIT PATTERN WORD COUNT
8371 036656 022321 24$: CMP (R3)+,(R1)+ ;COMPARE DATA WORD TO PATTERN WORD
8372 036660 001404 BEQ 25$ ;BR IF NO ERROR
8373 036662 013737 172354 001216 MOV 2#KIPAR6,$REG16 ;SET PAR FOR PRINTOUT
8374 036670 000432 BR 35$ ;GO HANDLE ERROR
8375 036672 032701 020000 25$: BIT #BIT13,R1 ;SEE IF OVERFLOW TO NEXT PAGE
8376 036676 001405 BEQ 26$ ;BR IF NO OVERFLOW
8377 036700 062737 000200 172354 ADD #200,2#KIPAR6 ;INCR PAR BY 4K FOR NEW PAGE
8378 036706 042701 020000 BIC #BIT13,R1 ;SET PAGE = 6 AGAIN
8379 036712 005302 26$: DEC R2 ;DECREMENT WORD COUNTER
8380 036714 001002 BNE 27$ ;BR IF NOT ALL DONE YET
8381 036716 000137 037362 JMP 54$ ;ALL DONE - GET OUT
8382 036722 005304 27$: DEC R4 ;DECREMENT PATTERN WORD COUNT
8383 036724 001354 BNE 24$ ;BR IF NOT DONE WITH PATTERN YET
8384 036726 000751 BR 22$ ;BR TO REPEAT THE PATTERN
8385          ;COMPARE LOOP FOR NO MEM MGT STARTS HERE
8386 036730 010003 30$: MOV RO,R3 ;GET COPY OF PATTERN ADDRESS
8387 036732 011604 MOV (SP),R4 ;INIT PATTERN WORD COUNT
8388 036734 022321 34$: CMP (R3)+,(R1)+ ;COMPARE DATA WORD TO PATTERN WORD
8389 036736 001002 BNE 31$ ;BR IF COMPARE ERROR
8390 036740 000137 037342 JMP 40$ ;JUMP IF DATA COMPARES OK
8391 036744 105037 064176 31$: CLRB DH701+38. ;ADJUST DATA HEADER FOR MSG
8392 036750 012737 000005 065552 MOV #5,DF25+2 ;ADJUST ERROR DATA WORD COUNT
8393          ;COMMON COMPARE ERROR HANDLER
8394 036756 010237 001202 35$: MOV R2,$REG10 ;GET WORD NO.
8395 036762 163737 005564 001202 SUB WDSXFR,$REG10 ;GET 2'S COMP OF WORD NO.
8396 036770 013737 001202 005572 MOV $REG10,LASTWC ;COMPUTE ACTUAL PACK ADRS
8397 036776 004737 036072 JSR PC,FINADR ;SAVE RO-R5
8398 037002 104407 SAVREG ;GET CYL
8399 037004 013700 005566 MOV FINCYL,RO ;GET TRACK
8400 037010 113701 005570 MOV#B FINTRK,R1 ;GET SECTOR
8401 037014 113702 005571 MOV#B FINSEC,R2 ;SEE IF THIS SECTOR LISTED BAD
8402 037020 004737 042436 JSR PC,BDSACK ;RESTORE RO-R5
8403 037024 104410 RESREG
8404 037026 032737 001000 005474 BIT #BADSEC,RECODE
8405 037034 001132 BNE 50$ ;BR IF LISTED- DON'T REPORT ERROR
8406 037036 005737 005534 TST SCRACH ;CHECK THE ERROR COUNT
8407 037042 001024 BNE 36$ ;BR IF THIS IS NOT FIRST ERROR
8408 037044 105737 003143 TSTB UBMPRS ;SEE IF UNIBUS MAP PRESENT
8409 037050 001411 BEQ 46$ ;BR IF NOT
8410 037052 013737 005262 001174 MOV CRMPHQ,$REG5 ;GET CURRENT MAP REG 0
8411 037060 013737 005260 001176 MOV CRMPLO,$REG6
8412 037066 104116 ERROR 116 ;DATA MISCOMPARE (11/70)
8413 037070 104117 ERROR 117
8414 037072 000401 BR 48$
8415 037074 104034 46$: ERROR 34 ;TYPE HEADING FOR ERROR MSG
8416 037076 012737 177777 001174 48$: MOV #-1,$REG5 ;INIT CYL NO.
8417 037104 005037 001176 CLR $REG6
8418 037110 005037 001200 CLR $REG7

```

8419	037114	005237	005534		36\$:	INC	SCRACH	; INCREMENT THE ERROR COUNT
8420	037120	032777	000001	142012		BIT	#BIT0, @SWR	; SEE IF ALL ERRORS SHOULD BE REPORTED
8421	037126	001004				BNE	38\$; BR TO REPORT ALL ERRORS
8422	037130	022737	000012	005534		CMP	#10., SCRACH	; SEE IF 10(DEC) ERRORS YET
8423	037136	002511				BLT	54\$; BR IF ERROR LIMIT EXCEEDED
8424	037140	023737	001174	005566	38\$:	CMP	\$REG5, FINCYL	; SEE IF DIFFERENT CYL
8425	037146	001010				BNE	42\$; BR IF YES
8426	037150	123737	001176	005570		CMPB	\$REG6, FINTRK	; SEE IF DIFFERENT TRACK
8427	037156	001004				BNE	42\$; BR IF YES
8428	037160	123737	001200	005571		CMPB	\$REG7, FINSEC	; SEE IF DIFFERENT SECTOR
8429	037166	001412				BEQ	44\$; BR IF SAME PACK ADDRESS
8430	037170	013737	005566	001174	42\$:	MOV	FINCYL, \$REG5	; SET NEW PACK ADRS FOR PRINTOUT
8431	037176	113737	005570	001176		MOVB	FINTRK, \$REG6	
8432	037204	113737	005571	001200		MOVB	FINSEC, \$REG7	
8433	037212	104115				ERROR	115	; TYPE NEW PACK ADDRESS
8434	037214	005437	001202		44\$:	NEG	\$REG10	; GET WORD NO.
8435	037220	016337	177776	001204		MOV	-2(R3), \$REG11	; GET GOOD DATA
8436	037226	016137	177776	001206		MOV	-2(R1), \$REG12	; GET BAD DATA
8437	037234	013737	001202	001212		MOV	\$REG10, \$REG14	; COMPUTE PHYSICAL ADDRESS
8438	037242	005037	001210			CLR	\$REG13	
8439	037246	006137	001212			ROL	\$REG14	
8440	037252	006137	001210			ROL	\$REG13	
8441	037256	063737	005604	001212		ADD	PMA, \$REG14	
8442	037264	005537	001210			ADC	\$REG13	
8443	037270	063737	005606	001210		ADD	PMA+2, \$REG13	
8444	037276	010137	001214			MOV	R1, \$REG15	; GET VIRT. ADRS FOR PRINTOUT
8445	037302	162737	000002	001214		SUB	#2, \$REG15	
8446	037310	104063				ERROR	63	; TYPE GOOD AND BAD DATA, MEM. ADRS.
8447	037312	032777	000100	141620		BIT	#BIT6, @SWR	; SEE IF JUST 1 ERROR SHOULD BE REPORTED
8448	037320	001020				BNE	54\$; BR IF JUST 1 ERROR SHOULD BE REPORTED
8449	037322	005737	005536		50\$:	TST	PATRN	; SEE IF DEFAULT DATA TEST
8450	037326	001405				BEQ	40\$; BR IF YES
8451	037330	005737	057732			TST	\$KT11	; SEE IF MEM MGT PRESENT
8452	037334	100002				BPL	40\$; BR IF NOT PRESENT
8453	037336	000137	036672			JMP	25\$; GO HANDLE MEM MGT
8454	037342	005302			40\$:	DEC	R2	; DECREMENT WORD COUNTER
8455	037344	001406				BEQ	54\$; BR IF ALL DONE
8456	037346	005304				DEC	R4	; DECREMENT PATTERN WORD COUNT
8457	037350	001002				BNE	53\$; BR IF NOT DONE WITH PATTERN YET
8458	037352	000137	036730			JMP	30\$; JUMP TO REPEAT THE PATTERN
8459	037356	000137	036734		53\$:	JMP	34\$	
8460	037362	005737	057732		54\$:	TST	\$KT11	; SEE IF MEM MGT PRESENT
8461	037366	100003				BPL	56\$; BR IF NOT PRESENT
8462	037370	042737	000001	177572		BIC	#BIT0, @#SRO	; DISABLE MEM MGT
8463	037376	005726			56\$:	TST	(SP)+	; POP THE STACK
8464	037400	104410				RESREG		; RESTORE RO-R5
8465	037402	000207				RTS	PC	; RETURN

8466
8467
8468
8469
8470
8471
8472
8473
8474

```

*****
* CTLOUT - THIS SUBROUTINE CHECKS FOR (↑C) OR (↑Z) TTY INPUT.
* IF (↑C) WAS TYPED, THE SUBROUTINE RETURNS TO DRVTST. IF (↑Z)
* WAS TYPED, THE SUBROUTINE RETURNS TO INPUTP. IN EITHER CASE,
* A RESET INSTRUCTION IS EXECUTED, AND THE STACK IS RE-INIT-
* IALIZED. IF THERE IS NO INPUT, OR INPUT OTHER THAN (↑C) OR (↑Z),

```



```

8475 ;*NO ACTION IS TAKEN.
8476 ;* CALL - JSR PC,CTLOUT
8477 ;* OR - CKEXIT
8478 ;*****
8479 037404 122737 000001 003120 CTLOUT: CMPB #1,TSTING ;SEE IF CURRENTLY RUNNING TESTS
8480 037412 001077 BNE 10$ ;BR IF NOT RUNNING TESTS
8481 037414 005737 005522 TST INTCHR ;SEE IF ANY TTY INPUT
8482 037420 001474 BEQ 10$ ;BR IF NO INPUT
8483 037422 105737 003116 TSTB MDFLAG ;SEE IF DEFAULT MODE RUN
8484 037426 001446 BEQ 12$ ;BR IF YES
8485 037430 122737 000003 005522 CMPB #003,INTCHR ;SEE IF (↑C) TYPED
8486 037436 001033 BNE 4$ ;BR IF NOT (↑C)
8487 037440 012700 014434 MOV #DRVST,RO ;SET RETURN ADDR = DRVST
8488 037444 105737 003133 2$: TSTB XOVLD ;SEE IF XXDP CURRENTLY OVERLAID
8489 037450 001402 BEQ 6$ ;BR IF NOT
8490 037452 004737 032050 JSR PC,GETXDP ;RESTORE SAVED XXDP, IF NECESSARY
8491 037456 000005 6$: RESET ;RESET ALL DEVICES
8492 037460 005037 005522 CLR INTCHR ;CLEAR TTY CHAR BUFFER WORD
8493 037464 005037 001304 CLR $TIMES ;CLEAR THE ITER. COUNT
8494 037470 105037 003134 CLRB XDPSVD ;CLEAR THE XXDP SAVED FLAG
8495 037474 012737 044200 003046 MOV #ERRHDL,A.ABNL ;RESTORE ERROR HANDLER ADDRESS
8496 037502 012706 001100 MOV #STACK,SP ;RESET THE STACK
8497 037506 112765 000113 000001 MOVB #RECAL,P.CMND(R5) ;SET RECAL COMMAND
8498 037514 004737 042542 JSR PC,DRVCAL ;DO CLEANUP RECALIBRATE
8499 037520 005037 001102 CLR $STNM ;CLEAR THE TEST NO.
8500 037524 000110 JMP $RO ;EXIT FROM TESTS
8501 037526 122737 000032 005522 4$: CMPB #032,INTCHR ;SEE IF (↑Z) TYPED
8502 037534 001016 BNE 7$ ;BR IF NOT (↑Z)
8503 037536 012700 016014 MOV #INPUTP,RO ;SET RETURN ADDR = INPUTP
8504 037542 000740 BR 2$ ;TAKE EXIT
8505 037544 122737 000003 005522 12$: CMPB #003,INTCHR ;SEE IF (↑C) TYPED
8506 037552 001007 BNE 7$ ;BR IF NOT
8507 037554 104401 007704 TYPE ,HLTRQD ;TYPE "HALT REQUESTED"
8508 037560 104401 007654 TYPE ,CNTRDY ;TYPE "PRESS CONT WHEN RDY"
8509 037564 012700 046150 MOV #HLTPRG,RO ;SET HALT ADDRESS
8510 037570 000725 BR 2$ ;TAKE EXIT
8511 037572 122737 000007 005522 7$: CMPB #007,INTCHR ;SEE IF (↑G) TYPED
8512 037600 001002 BNE 8$ ;BR IF NOT (↑G)
8513 037602 004737 031126 JSR PC,GTSWRG ;OPEN SOFTWARE SWR FOR MODIFICATION
8514 037606 004737 030576 8$: JSR PC,PREPKB ;ENABLE KBD INPUT AGAIN
8515 037612 000207 10$: RTS PC ;RETURN

```

```

8516
8517
8518
8519 ;*****
8520 ;*WRTSEC - WRITE A BLOCK OF 400(OCT) WORDS ONTO DISK AND PERFORM
8521 ;*A WRITE CHECK. PARAMETER BLOCK MUST BE PRE-LOADED WITH PACK
8522 ;*ADDRESS. DATA WORD IS PASSED IN R3 ON ENTRY. RWBUF IS THE BUFFER
8523 ;*USED.
8524 ;*****
8525 037614 104407 WRTSEC: SAVREG ;SAVE R0-R5
8526 ;LOAD THE R/W BUFFER WITH DATA
8527 037616 012700 065660 MOV #RWBUF,RO ;BUFFER ADDRESS
8528 037622 012701 000400 MOV #400,R1 ;400(OCT) WORDS
8529 037626 010320 4$: MOV R3,(R0)+ ;LOAD A BUFFER WORD

```



```

8586
8587
8588
8589
8590
8591
8592
8593
8594
8595
8596 040054 104407
8597 040056 005004
8598 040060 012703 000001
8599 040064 000403
8600 040066 104407
8601 040070 012704 177777
8602 040074 013702 005564
8603 040100 013701 005604
8604 040104 005037 005534
8605 040110 112737 000040 064176
8606 040116 012737 000007 065552
8607 040124 004737 043720
8608 040130 005737 057732
8609 040134 100012
8610 040136 042701 160000
8611 040142 052701 140000
8612 040146 013737 003176 172354
8613 040154 052737 000001 177572
8614 040162 020321
8615 040164 001575
8616
8617 040166 010237 001202
8618 040172 163737 005564 001202
8619 040200 013737 001202 005572
8620 040206 004737 036072
8621 040212 104407
8622 040214 013700 005566
8623 040220 113701 005570
8624 040224 113702 005571
8625 040230 004737 042436
8626 040234 104410
8627 040236 032737 001000 005474
8628 040244 001145
8629 040246 005737 057732
8630 040252 100406
8631 040254 105037 064176
8632 040260 012737 000005 065552
8633 040266 000403
8634 040270 013737 172354 001216
8635 040276 005737 005534
8636 040302 001024
8637 040304 105737 003143
8638 040310 001411
8639 040312 013737 005262 001174
8640 040320 013737 005260 001176
8641 040326 104116

```

```

*****
*CKMEM1 - PERFORM SOFTWARE COMPARE OF MEMORY, WITH INCREASING
*NUMBERS, STARTING WITH 1.
*CKMEM2 - PERFORM SOFTWARE COMPARE OF MEMORY, WITH REPEATED DATA WORD
*IN R3 ON ENTRY.
*BOTH SUBROUTINES REQUIRE MEM ADRS IN PMA, PMA+2, AND WORD COUNT MUST BE
*IN WDSXFR.
*****
CKMEM1: SAVREG          ;SAVE R0-R5
          CLR          R4          ;R4=0 INDICATES CKMEM1
          MOV          #1,R3      ;INIT DATA TO 1
          BR          CKM0        ;PROCEED
          SAVREG        ;SAVE R0-R5
          MOV          #-1,R4     ;R4=177777 INDICATES CKMEM2
          WDSXFR,R2          ;GET NO. OF WORDS
          MOV          PMA,R1     ;GET MEM ADRS
          CLR          SCRACH
          MOV          #40,DH701+38. ;RESTORE ERROR MSG PARAMS
          MOV          #7,DF25+2
          JSR          PC,REPSUP  ;STORE PREV CMND FOR POSS. PRINT
          TST          $KT11     ;SEE IF MEM MGT
          BPL          6$        ;BR IF NOT
          BIC          #160000,R1 ;FORCE RELOCATION THRU PAR6
          BIS          #140000,R1
          MOV          SAVPAR,2#KIPAR6 ;INIT PAR6
          BIS          #BIT0,2#SRO ;TURN ON MEM MGT
6$:      CMP          R3,(R1)+    ;COMPARE A DATA WORD
          BEQ          16$        ;BR IF DATA COMPARES OK
          ;COMPARE ERROR HANDLER
          MOV          R2,$REG10  ;GET WORD NO.
          SUB          WDSXFR,$REG10
          MOV          $REG10,LASTWC ;GET 2'S COMP OF WORD NO.
          JSR          PC,FINADR  ;COMPUTE ACTUAL PACK ADRS
          SAVREG        ;SAVE R0-R5
          MOV          FINCYL,R0  ;GET CYL
          MOV          FINTRK,R1  ;GET TRACK
          MOV          FINSEC,R2  ;GET SECTOR
          JSR          PC,BDSRCK  ;SEE IF THIS SECTOR LISTED BAD
          RESREG        ;RESTORE R0-R5
          BIT          #BADSEC,RECODE
          BNE          16$        ;BR IF LISTED- DON'T REPORT ERROR
          TST          $KT11     ;SEE IF MEM MGT
          BMI          8$        ;BR IF YES
          CLRB        DH701+38.  ;ADJUST DATA HEADER FOR MSG
          MOV          #5,DF25+2 ;ADJ. ERROR DATA WORD COUNT
          BR          9$
8$:      MOV          2#KIPAR6,$REG16 ;SET PAR FOR PRINTOUT
9$:      TST          SCRACH     ;SEE IF FIRST ERROR IN THIS BLOCK
          BNE          10$      ;BR IF NOT FIRST ERROR
          TSTB       UBMPRS     ;SEE IF UNIBUS MAP PRESENT
          BEQ          17$      ;BR IF NOT
          MOV          CRMPHD,$REG5 ;CURRENT UB MAP REG 0
          MOV          CRMPLO,$REG6
          ERROR       116      ;DATA MISCOMPARE (11/70)

```



```

8698
8699
8700
8701
8702 040644 013765 005660 000002
8703 040652 113765 005506 000004
8704 040660 113765 005664 000005
8705 040666 023737 005660 020036
8706 040674 003403
8707 040676 013765 020036 000002
8708 040704 012737 065660 005600 2S:
8709 040712 005737 000170
8710 040716 001003
8711 040720 062737 006000 005600
8712 040726 042737 003777 005600 4S:
8713 040734 062737 004000 005600
8714 040742 005037 005602
8715 040746 000207
8716
8717
8718
8719
8720
8721
8722
8723
8724
8725
8726
8727
8728
8729 040750
8730 040750 004737 037404
8731 040754 105037 003123
8732 040760 004737 042622
8733 040764 010537 041002
8734 040770 012737 041036 000004
8735 040776 004737 052604
8736 041002 000000
8737 041004 004737 047154 4S:
8738 041010 105737 003123 6S:
8739 041014 001012
8740 041016 010304
8741 041020 001402
8742 041022 005304 10S:
8743 041024 001376 10S:
8744 041026 005737 160000 12S:
8745 041032 104111
8746 041034 000401
8747 041036 022626 20S:
8748 041040 000761 22S:
8749 041042 012737 000006 000004 26S:
8750 041050 000207
8751
8752
8753

```

```

*****
; * SETUPM - SUBROUTINE TO INIT PARAMS FOR NPR/MEMORY TESTS.
*****
SETUPM: MOV FC,P.CYLN(R5) ;SET CYL
        MOVB FS,P.SECT(R5) ;SET SECTOR
        MOVB FT,P.TRCK(R5) ;SET TRACK
        CMP FC,LCM6 ;SEE IF CYL SHOULD BE SCALED DOWN
        BLE 2S ;BR IF NOT
        MOV LCM6,P.CYLN(R5) ;SCALE DOWN THE CYLINDER
        MOV #RWBUF,MA ;GET MEMORY ADDRESS
        TST KILLDR ;SEE IF LOADER CAN BE OVERLAYED
        BNE 4S ;BR IF YES
        ADD #6000,MA ;LEAVE ROOM TO SAVE LOADER
        BIC #3777,MA
        ADD #4000,MA
        CLR MA+2
        RTS PC ;RETURN

```

```

*****
; * REFNEM - THIS SUBROUTINE PERFORMS A SUBSYSTEM COMMAND, WHILE
; * REPEATEDLY REFERENCING A NON-EXISTENT MEMORY LOCATION (760000). THIS
; * IS DONE FOR THE PURPOSE OF CAUSING UNIBUS CONTENTION DURING DISK
; * NPR'S, SINCE THE BUS IS SIEZED FOR 5-20 USEC AT EACH NEM TIME-OUT.
; * ALL DRIVER PARAMETERS (INCLUDING THE COMMAND) MUST BE SET IN THE
; * PARAMETER BLOCK ON ENTRY, AND R3 MUST CONTAIN THE TIMING CONSTANT
; * WHICH REGULATES THE FREQUENCY OF NEM REFERENCES, WHILE WAITING FOR
; * COMMAND COMPLETION.
*****
REFNEM: JSR PC,CTLOUT ;CHECK FOR (↑C) OR (↑Z) KBD INPUT
        CLRB DONE ;CLEAR THE DONE FLAG
        JSR PC,STRCMD ;STORE PREV AND CURRENT COMMANDS
        MOV R5,4S ;SET PARAM BLK ADDRESS
        MOV #20S,@#ERRVEC ;SET TIME-OUT VECTOR ADDRESS
        JSR PC,C.INIT ;CALL DRIVER
        .WORD 4S:
        JSR PC,W.WTCH ;CALL WATCH DOG
        TSTB DONE ;DONE SET ?
        BNE 26S ;BR IF YES
        MOV R3,R4 ;GET COPY OF R3
        BEQ 12S ;BR IF TIMER = 0
        DEC R4 ;DECREMENT TIMER
        BNE 10S ;BR IF NOT DONE TIMING
        TST @#160000 ;REFERENCE NON-EXISTENT MEMORY
        ERROR 111 ;"NO NEM WHEN EXPECTED"
        BR 22S
        CMP (SP)+,(SP)+ ;RESTORE THE STACK
        BR 6S ;KEEP WAITING FOR COMMAND COMPLETION
        MOV #6,@#ERRVEC ;RESTORE TIME-OUT VECTOR
        RTS PC ;RETURN

```

```

*****

```

```

8754
8755
8756 041052 104407
8757 041054 005001
8758 041056 016500 000012
8759 041062 001002
8760 041064 005201
8761 041066 000401
8762 041070 005400
8763 041072 000241
8764 041074 006100
8765 041076 006101
8766 041100 060037 005600
8767 041104 005537 005602
8768 041110 060137 005602
8769 041114 104410
8770 041116 000207
8771
8772
8773
8774
8775
8776
8777
8778 041120
8779 041120 004737 032310
8780 041124 142765 000020 000007
8781 041132 112765 000121 000001
8782 041140 013765 020040 000002
8783 041146 112765 000002 000005
8784 041154 012703 000012
8785 041160 105737 003125
8786 041164 001403
8787 041166 105265 000004
8788 041172 005203
8789 041174 012765 177400 000012 6S:
8790 041202 012765 004224 000010
8791 041210 012737 041364 003046 8S:
8792 041216 105037 003140
8793 041222 004737 042542
8794 041226 105737 003140
8795 041232 001413
8796 041234 062765 000002 000004
8797 041242 126503 000004
8798 041246 001360
8799 041250 004737 043720 10S:
8800 041254 104120
8801 041256 000137 046150
8802 041262 012765 003224 000010 12S:
8803 041270 110365 000004
8804 041274 012703 000026
8805 041300 105737 003125
8806 041304 001402
8807 041306 012703 000023
8808 041312 012737 041364 003046 14S:
8809 041320 105037 003140

```

```

;*INCRMA - INCREMENT MA BY WORD COUNT IN P.WC(R5).
*****
INCRMA: SAVREG ;SAVE R0-R5
        CLR      R1
        MOV      P.WC(R5),R0 ;GET WORD COUNT
        BNE     4$ ;BR IF NOT 65,536(DEC)
        INC     R1 ;SET HI BIT
        BR      6$ ;CONTINUE
4$:     NEG     R0 ;GET TRUE WORD COUNT
6$:     CLC     ;DOUBLE THE WORD COUNT TO GET BYTES
        ROL     R0
        ROL     R1
        ADD     R0,MA ;ADD IT TO COMPUTE NEW MA
        ADC     MA+2
        ADD     R1,MA+2
        RESREG ;RESTORE R0-R5
        RTS     PC ;RETURN

```

```

*****
;*REDBSF - READ FACTORY BSF INTO BSFACT, AND READ SOFTWARE BSF
;*INTO BSSOFT.
*****
REDBSF: JSR      PC,INITSS ;INIT THE S.S.
        BICB    #8,CFMT,P.CS1H(R5) ;SET 22 SECTOR FMT
        MOV     #RDATA,P.CMND(R5) ;SET READ DATA COMMAND
        MOV     LSTCYL,P.CYLN(R5) ;SET CYL = 632/1456
        MOV     #2,P.TRACK(R5) ;SET TRACK = 2
        MOV     #10,R3 ;SET FACTORY BSF SECTOR LIMIT
        TSTB   FORMAT
        BEQ     6$ ;BR IF 22 SECTORS
        INCB   P.SECT(R5) ;SET STARTING FACTORY BSF SECTOR NO.
        INC    R3
        MOV     #-400,P.WC(R5) ;SET WORD COUNT FOR 1 SECTOR
6$:     MOV     #BSFACT,P.BALO(R5) ;SET BA FOR FACTORY BSF
8$:     MOV     #BDSCHD,A.ABNL ;SET ERROR HANDLER FOR BSF READ
        CLRB   WCEFLG ;INIT THE ERROR FLAG
        JSR    PC,DRVCAL ;READ THE FACTORY BSF
        TSTB   WCEFLG ;SEE IF ANY ERRORS
        BEQ     12$ ;BR IF NOT
        ADD    #2,P.SECT(R5) ;CHECK NEXT SECTOR
        CMPB   P.SECT(R5),R3 ;SEE IF LIMIT EXCEEDED YET
        BNE   8$ ;BR IF NOT YET
10$:    JSR    PC,REPSUP ;GATHER STATUS FOR PRINTOUT
        ERROR  120 ;ABORTING- BAD BSF READ
        JMP    HLTPRG ;HALT- CAN'T PROCEED
12$:    MOV     #BSSOFT,P.BALO(R5) ;SET BA FOR SOFTWARE RECORD
        MOV     R3,P.SECT(R5) ;SET STARTING SECTOR NO.
        MOV     #22,R3 ;SET 22 SECTOR LIMIT
        TSTB   FORMAT ;SEE IF 22 SECTOR FORMAT
        BEQ     14$ ;BR IF YES
        MOV     #19,R3 ;SET 20 SECTOR LIMIT
14$:    MOV     #BDSCHD,A.ABNL ;SET ERROR HANDLER FOR BSF READ
        CLRB   WCEFLG ;INIT THE ERROR FLAG

```

```

8810 041324 004737 042542 JSR PC,DRVCAL ;READ THE SOFTWARE BSF
8811 041330 105737 003140 TSTB WCEFLG ;SEE IF ANY ERRORS
8812 041334 001407 BEQ 16$ ;BR IF NOT
8813 041336 062765 000002 000004 ADD #2,P,SECT(R5) ;CHECK NEXT SECTOR
8814 041344 126503 000004 CMPB P,SECT(R5),R3 ;SEE IF LIMIT EXCEEDED YET
8815 041350 003760 BLE 14$ ;BR IF NOT YET
8816 041352 000736 BR 10$ ;REPORT ERROR AND ABORT
8817 041354 012737 044200 003046 16$: MOV #ERRHDL,A,ABNL ;RESTORE ERROR HANDLER ADRS
8818 041362 000207 RTS PC ;RETURN
8819
8820 ;*THIS IS THE ABNORMAL DRIVER RETURN WHICH IS USED TO HANDLE
8821 ;*POSSIBLE ERRORS IN READING BAD SECTORS.
8822 041364 032765 130600 000034 BDSCHD: BIT #BSE!HVRC!DTE!OPI!DCK,P,ER(R5) ;SEE IF ANY READ ERRORS
8823 041372 001002 BNE 4$ ;BR IF A READ ERROR OCCURRED
8824 041374 000137 044200 JMP ERRHDL ;GO HANDLE OTHER ERROR
8825 041400 105237 003140 4$: INCB WCEFLG ;SET ERROR FLAG
8826 041404 000137 046356 JMP RETNML ;TAKE NORMAL DRIVER RETURN
8827
8828
8829
8830
8831 ;*****
8832 ;*TYPBSF - TYPE FACTORY AND SOFTWARE BAD SECTOR FILES (BSF'S)
8833 ;*WITH THE CYLINDER, TRACK, AND SECTOR NO. OF EACH BAD SECTOR
8834 ;*LISTED SEPARATELY, IN A TABLE OF OCTAL VALUES, FOR EACH OF THE
8835 ;*2 BSF'S.
8836 ;*****
8836 041410 104407 †TYPBSF: SAVREG ;SAVE R0-R5
8837 041412 005004 CLR R4 ;INIT BSF FILE INDICATOR
8838 041414 012700 004234 MOV #BSFACT+10,R0 ;ADRS OF DATA IN FACTORY BSF
8839 041420 104401 011164 TYPE ,FACTBS ;TYPE "FACTORY"
8840 041424 104401 011211 TYPE ,BDSECT ;TYPE "BAD SECTORS"
8841 041430 104401 063743 3$: TYPE ,DH6041 ;TYPE "CYLNR TRACK SECTOR"
8842 041434 104401 001315 TYPE ,$CRLF
8843 041440 005001 CLR R1 ;INIT LIMIT COUNTER
8844 041442 005710 4$: TST (R0) ;SEE IF A SECTOR LISTED HERE
8845 041444 100007 BPL 8$ ;BR IF YES
8846 041446 005701 TST R1 ;SEE IF FILE IS EMPTY
8847 041450 001032 BNE 14$ ;BR IF NOT EMPTY
8848 041452 104401 011231 TYPE ,NOFALS ;TYPE "NONE"
8849 041456 104401 001315 TYPE , $CRLF ;TYPE <CR>,<LF>
8850 041462 000425 BR 14$
8851 041464 012046 8$: MOV (R0)+,-(SP) ;GET A CYL NO.
8852 041466 104402 TYPOC ;TYPE IT
8853 041470 104401 013313 TYPE ,SPACE2 ;TYPE SEPARATORS
8854 041474 011003 MOV (R0),R3 ;GET TRACK AND SECTOR
8855 041476 105003 CLRB R3
8856 041500 000303 SWAB R3 ;GET THE TRACK NO.
8857 041502 010346 MOV R3,-(SP)
8858 041504 104402 TYPOC ;TYPE IT
8859 041506 104401 013313 TYPE ,SPACE2 ;TYPE SEPARATORS
8860 041512 111003 MOVB (R0),R3 ;GET SECTOR NO.
8861 041514 010346 MOV R3,-(SP)
8862 041516 104402 TYPOC ;TYPE IT
8863 041520 104401 001315 TYPE , $CRLF
8864 041524 005720 TST (R0)+ ;INCR THE POINTER
8865 041526 005201 INC R1 ;INCR THE COUNTER

```

8866 041530 020127 000176
 8867 041534 002742
 8868 041536 005704
 8869 041540 001006
 8870 041542 005204
 8871 041544 012700 003234
 8872 041550 104401 011177
 8873 041554 000725
 8874 041556 104410
 8875 041560 000207

```

CMP      R1,#126.      ;SEE IF LIMIT REACHED IN THIS FILE
BLT      4$           ;BR IF NOT YET
14$:    TST      R4     ;SEE IF BOTH FILES TYPED YET
        BNE      18$   ;BR IF YES
        INC      R4     ;SET INDICATOR FOR SOFT. FILE
        MOV      #BSSOFT+10,R0 ;ADRS OF DATA IN SOFTWARE BSF
        TYPE     SOFTBS ;TYPE "SOFTWARE BAD SECTORS :"  

18$:    BR       3$     ;GO TYPE SOFT. BSF
        RESREG   PC     ;RESTORE RO-R5
        RTS      PC     ;RETURN
  
```

8876
8877
8878
8879
8880
8881
8882

```

*****
;FINMEM - COMPUTE NO. OF WORDS XFERRED ON PARTIAL XFER
;(TERMINATED BY BSE ERROR), AND STORE IT IN WDSXFR.
*****
FINMEM: SAVREG      ;SAVE RO-R5
  
```

8883 041562 104407
 8884 041564 016500 000002
 8885 041570 116501 000005
 8886 041574 116502 000004
 8887 041600 005003
 8888 041602 026500 000030
 8889 041606 001006
 8890 041610 126501 000027
 8891 041614 001003
 8892 041616 126502 000026
 8893 041622 001404
 8894 041624 005203
 8895 041626 004737 041646
 8896 041632 000763
 8897 041634 000303
 8898 041636 010337 005564
 8899 041642 104410
 8900 041644 000207

```

MOV      P.CYLN(R5),R0 ;GET ORIG. CYL NO.
MOV      P.TRCK(R5),R1 ;GET TRACK NO.
MOV      P.SECT(R5),R2 ;SECTOR NO.
CLR      R3            ;INIT SECTOR COUNT TO 0
6$:    CMP      P.DCYL(R5),R0 ;COMPARE ORIG. AND CURRENT CYLS
        BNE      8$     ;BR IF NOT EQUAL
        CMP      P.DTS+1(R5),R1 ;COMPARE TRACKS
        BNE      8$     ;BR IF NOT EQUAL
        CMP      P.DTS(R5),R2  ;COMPARE SECTORS
8$:    BEQ      12$     ;BR IF ADRS ARE EQUAL
        INC      R3      ;INCR SECTOR COUNT
        JSR      PC,INCRSC ;INCR PACK ADRS BY 1 SECTOR
        BR       6$     ;GO COMPARE ADDRESSES
12$:   SWAB     R3      ;COMPUTE NO. OF WORDS XFERRED
        MOV      R3,WDSXFR ;STORE IT
        RESREG   PC     ;RESTORE RO-R5
        RTS      PC     ;RETURN
  
```

8901
8902
8903
8904
8905
8906
8907
8908

```

*****
;INCRSC - INCREMENT PACK ADDRESS TO NEXT SECTOR
;THE CYLINDER IS PASSED AND RETURNED IN R0, TRACK IN R1, AND SECTOR
;IN R2.
*****
INCRSC: MOV      #21.,R4 ;SET SECTOR LIMIT
  
```

8909 041646 012704 000025
 8910 041652 105737 003125
 8911 041656 001402
 8912 041660 012704 000023
 8913 041664 005202
 8914 041666 020204
 8915 041670 003407
 8916 041672 005002
 8917 041674 005201
 8918 041676 020127 000002
 8919 041702 003402
 8920 041704 005001
 8921 041706 005200

```

TSTB     FORMAT      ;SEE IF 22 SECTOR FORMAT
BEQ      4$         ;BR IF YES
MOV      #19.,R4    ;SET SECTOR LIMIT
4$:    INC      R2     ;INCR. SECTOR NO.
        CMP      R2,R4 ;SEE IF SECTOR LIMIT EXCEEDED
        BLE     6$     ;BR IF NOT
        CLR     R2     ;SET SECTOR = 0
        INC     R1     ;INCR. TRACK NO.
        CMP     R1,#2 ;SEE IF TRACK LIMIT EXCEEDED
        BLE     6$     ;BR IF NOT
        CLR     R1     ;SET TRACK = 0
        INC     R0     ;INCR. CYLINDER NO.
  
```



```

8922 041710 000207
8923
8924
8925
8926
8927
8928
8929
8930
8931
8932 041712 104407
8933 041714 004737 041562
8934 041720 016500 000030
8935 041724 116501 000027
8936 041730 116502 000026
8937 041734 004737 041646
8938 041740 010065 000002
8939 041744 110165 000005
8940 041750 110265 000004
8941 041754 013703 005564
8942 041760 062703 000400
8943 041764 060365 000012
8944 041770 005004
8945 041772 006103
8946 041774 006104
8947 041776 060337 005604
8948 042002 005537 005606
8949 042006 060437 005606
8950 042012 013765 005604 000010
8951 042020 013700 005606
8952 042024 042700 177774
8953 042030 150065 000007
8954 042034 005737 057732
8955 042040 100002
8956 042042 004737 031646
8957 042046 104410
8958 042050 000207

```

```

6$:   RTS   PC           ;RETURN

;*****
;MIDXFR - MID-TRANSFER PARAMETER UPDATE SUBROUTINE
;THIS SUBROUTINE UPDATES PMA,PMA+2 MEM MGT REGS UNIBUS MAP,P.BALO(R5),
;P.BAHI(R5), AND P.WC(R5), IN PREPARATION TO RESUME A TRANSFER
;TERMINATED BY A BAD SECTOR ERROR (BSE).
;*****
MIDXFR: SAVREG           ;SAVE R0-R5
        JSR   PC,FINMEM  ;COMPUTE NO. OF WORDS XFERRED
        MOV   P.DCYL(R5),R0 ;GET CYL NO.
        MOVB P.DTS+1(R5),R1 ;GET TRACK NO.
        MOVB P.DTS(R5),R2  ;GET SECTOR NO.
        JSR   PC,INCRSC  ;INCREMENT PACK ADRS TO NEXT SECTOR
        MOV   R0,P.CYLN(R5) ;UPDATE CYLINDER
        MOVB R1,P.TRCK(R5) ;UPDATE TRACK
        MOVB R2,P.SECT(R5) ;UPDATE SECTOR
        MOV   WDSXFR,R3   ;GET NO. OF WORDS XFERRED
        ADD  #400,R3     ;SKIP BAD SECTOR
        ADD  R3,P.WC(R5) ;UPDATE P.WC(R5)
        CLR  R4         ;GET BYTES XFERRED
        ROL  R3
        ROL  R4
        ADD  R3,PMA     ;UPDATE PMA,PMA+2
        ADC  PMA+2
        ADD  R4,PMA+2
        MOV  PMA,P.BALO(R5) ;UPDATE P.BALO(R5)
        MOV  PMA+2,R0
        BIC  #177774,R0
        BISB R0,P.BAHI(R5) ;UPDATE P.BAHI(R5)
        TST  $K11       ;SEE IF MEM MGT
        BPL  16$
        JSR  PC,PREPAR  ;UPDATE MEM MGT AND UNIBUS MAP
        RESREG          ;RESTORE R0-R5
        RTS   PC       ;RETURN
16$:

```

```

8959
8960
8961
8962
8963
8964
8965
8966 042052 104407
8967 042054 012700 002632
8968 042060 012701 005552
8969 042064 016537 000012 005564
8970 042072 005437 005564
8971 042076 012737 065660 005604
8972 042104 005037 005606
8973 042110 005737 005536
8974 042114 001414
8975 042116 013737 005600 005604
8976 042124 013737 005602 005606
8977 042132 000405

```

```

;*****
;SVPRMS - SAVE INITIAL PARAMETERS FOR TRANSFER
;GTPRMS - RESTORE SAVED TRANSFER PARAMETERS
;*****
SVPRMS: SAVREG           ;SAVE R0-R5
        MOV   #PARMO+2,R0 ;ADRS OF PARAMS
        MOV   #SAVPRS,R1  ;ADRS OF SAVE AREA
        MOV   P.WC(R5),WDSXFR ;GET WORD COUNT
        NEG   WDSXFR      ;MAKE IT POSITIVE
        MOV   #RWBUF,PMA  ;INIT PMA TO RWBUF
        CLR  PMA+2       ;INIT PMA+2 TO 0
        TST  PATRN       ;SEE IF DEFAULT DATA TEST
        BEQ  GTO         ;BR IF YES
        MOV  MA,PMA      ;SET PMA=MA
        MOV  MA+2,PMA+2  ;SET PMA+2=MA+2
        BR   GTO

```

8978	042134	104407	
8979	042136	012700	005552
8980	042142	012701	002632
8981	042146	012702	000005
8982	042152	012021	
8983	042154	005302	
8984	042156	001375	
8985	042160	104410	
8986	042162	000207	

```

GTPRMS: SAVREG          ;SAVE R0-R5
          MOV           #SAVPRS,R0 ;ADRS OF SAVE AREA
          MOV           #PARMO+2,R1 ;ADRS OF PARAMS
GTO:     MOV           #5,R2      ;SET FOR 5 WORDS
6$:      MOV           (R0)+,(R1)+ ;MOVE A WORD
          DEC          R2         ;SEE IF DONE YET
          BNE          6$        ;BR IF NOT YET
          RESREG         ;RESTORE R0-R5
          RTS           PC       ;RETURN
  
```

8987			
8988			
8989			
8990			
8991			
8992			
8993			
8994			

```

*****
*TRANSFR - PERFORM A DATA TRANSFER, AND HANDLE BAD SECTORS, IF
*ENCOUNTERED. THE COMMAND MUST BE SET IN THE PARAM BLK, THIS SUB-
*ROUTINE IS SUBSTITUTED FOR DRVCAL WHEN BAD SECTORS MUST BE HANDLED.
*****
  
```

8995	042164	010446	
8996	042166	005004	
8997	042170	105037	003140
8998	042174	004737	042542
8999	042200	032737	000100 005474
9000	042206	001403	
9001	042210	112737	000001 003140
9002	042216	032737	000002 005474
9003	042224	001406	
9004	042226	005204	
9005	042230	004737	041712
9006	042234	005765	000012
9007	042240	001355	
9008	042242	005704	
9009	042244	001411	
9010	042246	004737	042134
9011	042252	004737	042052
9012	042256	005737	057732
9013	042262	100002	
9014	042264	004737	031646
9015	042270	012604	
9016	042272	000207	

```

TRANSFR: MOV           R4,-(SP)   ;SAVE R4 ON STACK
          CLR          R4        ;CLEAR BSE ERROR INDICATOR
          CLRB         WCEFLG    ;INIT WCE ERROR FLAG TO 0
4$:      JSR          PC,DRVCAL  ;PERFORM THE S.S. FUNCTION
          BIT          #WCERR,RECODE ;SEE IF WCE ERROR OCCURRED
          BEQ          5$        ;BR IF NOT
          MOVB         #1,WCEFLG ;SET WCE ERROR FLAG
5$:      BIT          #BSEERR,RECODE ;SEE IF BSE ERROR OCCURRED
          BEQ          6$        ;BR IF NOT
          INC          R4        ;INCR BSE ERROR INDICATOR
          JSR          PC,MIDXFR  ;UPDATE PARAMS TO RESUME XFER
          TST          P,WC(R5)  ;SEE IF ENTIRE XFER IS COMPLETED
          BNE          4$        ;BR IF NOT
6$:      TST          R4        ;SEE IF ANY BSE ERRORS OCCURRED
          BEQ          8$        ;BR IF NOT
          JSR          PC,GTPRMS ;RESTORE ORIGINAL PARAMS OF XFER
          JSR          PC,SVPRMS ;RESTORE WDSXFR,PMA,PMA+2
          TST          $K11      ;SEE IF MEM MGT PRESENT
          BPL          8$        ;BR IF NOT
          JSR          PC,PREPAR ;PREPARE MEM MGT AND U.M.
8$:      MOV          (SP)+,R4   ;RESTORE R4
          RTS           PC       ;RETURN
  
```

9017			
9018			
9019			
9020			
9021			
9022			
9023			
9024			
9025			
9026			
9027			
9028			
9029			
9030			

```

*****
*SBTTL SEARCH BAD SECTOR TABLES ROUTINE
*THIS ROUTINE RETURNS A LIST OF BAD SECTORS FOUND IN
*THE SPECIFIC TABLE (BAD SECTOR SOFTWARE OR BAD SECTOR FACTORY)
*FOR THE SPECIFIC CYLINDER AND TRACK DESIRED. R0 AND R1 MUST
*CONTAIN THE CYLINDER AND TRACK, RESPECTIVELY.
*
*THE LIST OF BAD SECTORS IS FOUND ON THE STACK WHEN THE ROUTINE
*RETURNS TO THE CALLER. THE FIRST ENTRY ON THE STACK WILL BE THE
*NUMBER OF BAD SECTORS FOUND FOR THIS CYLINDER AND TRACK.
*****
  
```

9031	042274	010237	001266
9032	042300	010337	001270
9033	042304	012637	001272

```

SRHTBS: MOV           R2,$TMP2
          MOV           R3,$TMP3
          MOV           (SP)+,$TMP4 ;STORE RETURN CONTENTS OF R4
  
```

```

9034 042310 011402          MOV      (R4),R2 ;GET ADDRESS OF BAD SECTOR TABLE TO SEARCH
9035 042312 012437 001264  MOV      (R4)+,$TMP1 ;SETUP FOR LENGTH OF BAD SECTOR TABLE
9036 042316 062737 001000 001264  ADD      #1000,$TMP1
9037 042324 005003          CLR      R3 ;CLEAR R3 FOR COUNT
9038 042326 062702 000010  ADD      #10,R2 ;SET R2 FOR POINTER TO CYLINDER ENTRY
9039 042332 005712          1$:     TST      (R2) ;TEST IF ALL ONES
9040 042334 100430          BMI      5$ ;YES-DONE
9041 042336 020012          CMP      R0,(R2) ;TEST IF BAD SECTOR IN PRESENT CYL
9042 042340 001406          BEQ      3$ ;YES-GO CHECK TRACK
9043 042342 062702 000004  ADD      #4,R2 ;ELSE BUMP POINTER
9044 042346 020237 001264  CMP      R2,$TMP1 ;TEST IF OUT OF TABLE
9045 042352 002021          BGE      5$ ;YES-EXIT
9046 042354 000766          BR       1$ ;LOOP
9047 042356 005722          3$:     TST      (R2)+ ;TRACK CHECK - PUT POINTER AT TRK/SEC BYTE
9048 042360 011237 001302  MOV      (R2),$TMP10 ;GET TRK/SEC WORD
9049 042364 042737 174377 001302  BIC      #174377,$TMP10 ;CLEAR ALL BUT TRACK
9050 042372 123701 001303  CMPB    $TMP10+1,R1 ;CHECK IF BAD SECTOR IN THIS TRACK
9051 042376 001402          BEQ      4$ ;YES - GO PUT SECTOR NUMBER ON STACK
9052 042400 005722          TST      (R2)+ ;ELSE BUMP POINTER TO NEXT CYL WORD
9053 042402 000753          BR       1$ ;GO TEST NEXT CYL
9054 042404 005203          4$:     INC      R3 ;BUMP BAD SECTOR COUNT
9055 042406 012246          MOV      (R2)+,-(SP) ;PUT TRK/SEC WORD ON STACK
9056 042410 042716 177700  BIC      #177700,(SP) ;CLEAR ALL BUT SECTOR NUMBER
9057 042414 000746          BR       1$ ;GO CHECK REST OF FILE
9058 042416 010346          5$:     MOV      R3,-(SP) ;EXIT - PUT NUMBER OF BAD
9059 042420 013702 001266  MOV      $TMP2,R2 ;SECTORS ON STACK-RESTORE
9060 042424 013703 001270  MOV      $TMP3,R3 ;REGISTERS
9061 042430 013746 001272  MOV      $TMP4,-(SP) ;PUT RETURN ON STACK
9062 042434 000204          RTS      R4 ;RETURN
9063
9064 ;*****
9065 ;SBTTL BAD SECTOR CHECK ROUTINE
9066 ;*THIS ROUTINE WILL SEARCH BOTH TABLES TO DETERMINE IF A
9067 ;*SPECIFIC SECTOR IS LISTED AS BAD. IF THE SECTOR IS LISTED IN THE
9068 ;*TABLES THE ROUTINE SETS THE "BADSEC" FLAG AND RETURNS. IF THE SECTOR
9069 ;*IS NOT LISTED THE FLAG IS RESET.
9070 ;*****
9070 042436 104407          BDSRCK: SAVREG
9071 042440 012737 004224 042452  MOV      #BSFACT,1$ ;SET TABLE TO SEARCH
9072 042446 004437 042274  2$:     JSR      R4,SRHTBS ;GO SEARCH IT
9073 042452 000000          1$:     .WORD
9074 042454 012603          MOV      (SP)+,R3 ;TABLE ADDRESS GOES HERE
9075 042456 001015          BNE      6$ ;GET NUMBER OF BAD SECTORS, IF ANY
9076 042460 023727 042452 003224  7$:     CMP      1$,#BSSOFT ;IF ANY, GO TEST WHICH ONES
9077 042466 001404          BEQ      3$ ;ELSE TEST IF OTHER TABLE ALREADY SEARCHED
9078 042470 012737 003224 042452  MOV      #BSSOFT,1$ ;IF YES-EXIT
9079 042476 000763          BR       2$ ;SET OTHER TABLE FOR SEARCH
9080 042500 042737 001000 005474  3$:     BIC      #BADSEC,RECODE ;GO SEARCH IT
9081 042506 104410          4$:     RESREG ;CLEAR BAD SECTOR BIT
9082 042510 000207          RTS      PC ;RETURN
9083 042512 022602          6$:     CMP      (SP)+,R2 ;THIS SECTOR IN TABLE?
9084 042514 001403          BEQ      8$ ;YES-GO SET BIT & EXIT
9085 042516 005303          DEC      R3 ;DECREMENT BAD SECTOR COUNT
9086 042520 001374          BNE      6$ ;IF NOT ZERO-CHECK NEXT ENTRY
9087 042522 000756          BR       7$ ;ELSE GO SEARCH OTHER TABLE
9088 042524 052737 001000 005474  8$:     BIS      #BADSEC,RECODE ;SET BAD SECTOR BIT
9089 042532 005303          9$:     DEC      R3 ;CLEAR STACK OF OTHER BAD SECTOR

```

9090	042534	001764	BEQ	4\$;NUMBER
9091	042536	005726	TST	(SP)+	
9092	042540	000774	BR	9\$;EXIT

9093
9094
9095
9096
9097
9098
9099
9100
9101
9102
9103
9104
9105
9106
9107
9108
9109
9110
9111
9112

```
*****  
;SBTTL CALL DRIVER ROUTINE  
;ENTRY JSR PC,DRVCAL  
; WITH R5 POINTING TO PARAMETER BLOCK  
;RETURN RTS PC  
; THIS ROUTINE IS USED TO INITIATE A SUBSYSTEM OPERATION BY  
; CALLING THE DRIVER. THE PARAMETER BLOCK MUST BE SET UP  
; BY THE CALLER AND R5 MUST POINT TO THE PARAMETER  
; BLOCK WHEN THE ROUTINE IS CALLED.  
; THIS ROUTINE WAITS FOR THE OPERATION TO BE COMPLETED.  
; WHILE WAITING THE WATCHDOG TIMER IS CALLED TO PREVENT  
; SILENT DEATH IN CASE THE SUBSYSTEM DOES NOT PROVIDE AN  
; INTERRUPT. THE TERMINATION HANDLER ROUTINES WILL SET THE DONE  
; FLAG WHICH KEYS THE ROUTINE TO RETURN TO THE CALLER.  
*****
```

9113	042542			
9114	042542	104407		
9115	042544	004737	035604	
9116	042550	004737	037404	
9117	042554	105037	003123	
9118	042560	105037	003136	
9119	042564	004737	042622	
9120				
9121				
9122				
9123				
9124	042570	000240		
9125	042572	010537	042602	
9126	042576	004737	052604	
9127	042602	000000		
9128	042604	004737	047154	
9129	042610	105737	003123	
9130	042614	001773		
9131	042616	104410		
9132	042620	000207		

```
DRVCAL: SAVREG ;SAVE R0-R5  
JSR PC,STALL ;PERFORM A STALL IF REQUIRED  
JSR PC,CTLOUT ;CHECK FOR (↑C) OR (↑Z) KBD INPUT  
CLRB DONE ;CLEAR DONE FLAG  
CLRB DRNAFG ;CLEAR DRIVE SIEZED BY OTHER PORT FLAG  
JSR PC,STRCMD ;STORE PREV AND CURRENT COMMANDS  
BICB #B.CDT,P.CS1H(R5) ;CLEAR THE RK07 DRIVE TYPE BIT  
TSTB TYPFMT ;CURRENT DRIVE IS AN RK07 ?  
BEQ 9$ ;BRANCH IF NOT  
BISB #B.CDT,P.CS1H(R5) ;SET THE RK07 DRIVE TYPE BIT  
9$: NOP  
MOV R5,4$ ;GET PARAM BLOCK ADDRESS  
JSR PC,C.INIT ;CALL DRIVER  
4$: .WORD ;P.B. ADDRESS GOES HERE  
6$: JSR PC,W.WTCH ;CALL WATCH DOG  
TSTB DONE ;DONE SET?  
BEQ 6$ ;NO-LOOP  
12$: RESREG ;RESTORE R0-R5  
RTS PC ;YES-RETURN
```

9133
9134
9135
9136
9137
9138
9139
9140
9141
9142
9143
9144
9145

```
*****  
;STRCMD - STORE PREVIOUS AND CURRENT SUBSYSTEM COMMANDS  
*****  
STRCMD: SAVREG ;SAVE R0-R5  
MOV #PRVCMD,R1 ;ADDR OF PREV COMMAND STORAGE  
MOV #COMSTR,R0 ;ADDR OF CURRENT COMMAND STORAGE  
;STORE PREVIOUS COMMAND  
MOV (R0)+,(R1)+  
MOV (R0)+,(R1)+  
MOV (R0)+,(R1)+
```

```

9146 042642 012021      MOV      (R0)+,(R1)+
9147 042644 012021      MOV      (R0)+,(R1)+
9148 042646 012021      MOV      (R0)+,(R1)+
9149 042650 105737 003143  TSTB    UBMPRS      ;SEE IF UNIBUS MAP PRESENT
9150 042654 001414      BEQ     4$          ;BR IF NOT
9151 042656 013737 005262 005256  MOV     CRMPHO,PRMPHO ;STORE PREV U.B. MAP REG 0
9152 042664 013737 005260 005254  MOV     CRMPLO,PRMPLO
9153 042672 013737 170202 005262  MOV     2#MAPH00,CRMPHO ;STORE CURRENT U.B. MAP REG 0
9154 042700 013737 170200 005260  MOV     2#MAPL00,CRMPLO
9155      ;STORE CURRENT COMMAND
9156 042706 012701 005240 4$:      MOV     #COMSTR,R1
9157 042712 012521      MOV     (R5)+,(R1)+ ;R5 POINTS TO DRIVER PARAM BLK
9158 042714 012521      MOV     (R5)+,(R1)+
9159 042716 012521      MOV     (R5)+,(R1)+
9160 042720 012521      MOV     (R5)+,(R1)+
9161 042722 012521      MOV     (R5)+,(R1)+
9162 042724 012521      MOV     (R5)+,(R1)+
9163 042726 104410      RESREG      ;RESTORE R0-R5
9164 042730 000207      RTS       PC       ;RETURN
9165
9166
9167
9168      ;*****
9169      ;SBTTL DRIVE ERROR FREE RETURN ROUTINE
9170      ;*THIS ROUTINE IS CALLED BY THE DRIVER WHEN NO ERROR
9171      ;*HAS BEEN DETECTED IN THE OPERATION. THE ROUTINE SETS THE
9172      ;*DONE FLAG THAT IS TESTED IN THE DRIVER CALLING
9173      ;*ROUTINE.
9174      ;*****
9175 042732 152737 000377 003123  ERRFRE: BISB    #377,DONE ;SET THE DONE FLAG
9176 042740 032737 100000 005474  BIT     #ANYDER,RECODE ;TEST IF ANY DATA ERROR
9177 042746 001403      BEQ     2$          ;IF NO - DO ERROR RECOVERY PRINT TEST
9178 042750 105037 003126      CLRB   ERRCNT      ;CLEAR ERROR COUNT
9179 042754 000413      BR     1$          ;EXIT
9180 042756 105737 003126 2$:      TSTB   ERRCNT      ;CHECK IF ANY ERRORS HAVE OCCURRED
9181 042762 001410      BEQ     1$          ;NO - SKIP TO EXIT
9182 042764 005037 001174      CLR    $REGS
9183 042770 113737 003126 001174  MOVB   ERRCNT,$REGS ;GET RETRY COUNT
9184 042776 104101      ERROR  101         ;PRINT RETRY SUCCESSFUL MESSAGE
9185 043000 105037 003126      CLRB   ERRCNT      ;CLEAR ERROR COUNT
9186 043004 005037 005474 1$:      CLR    RECODE      ;CLEAR RECOVERY FLAGS
9187 043010 000207      RTS     PC         ;RETURN
9188      ;*****
9189      ;SBTTL TYPE ERROR ROUTINE
9190      ;*ENTRY -      JSR    PC,TYPERR
9191      ;*RETURN -     RTS    PC
9192      ;*
9193      ;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
9194      ;*ERROR IS TO BE REPORTED. IT THEN USES THE "ERROR TABLE" ($ERRTB)
9195      ;*ENTRY TO DEFINE WHAT INFORMATION IS TO BE REPORTED CONCERNING
9196      ;*THE ERROR.
9197      ;*****
9198 043012 104407      TYPERR: SAVREG
9199 043014 105237 003130      INCB   DRVERS      ;INCR ERROR COUNT FOR THIS DRIVE
9200 043020 032737 000040 005702  BIT     #BITS,CS    ;SEE IF DRIVE SHOULD BE DROPPED
9201      ; IF ERROR LIMIT EXCEEDED

```

9202	043026	001412			BEQ	9\$;BR IF NOT
9203	043030	123727	003130	000024	CMPB	DRVERS, #20.		;SEE IF 20(DEC) ERRORS EXCEEDED
9204	043036	002406			BLT	9\$;BR IF NOT
9205	043040	105037	003130		CLRB	DRVERS		;CLEAR DRIVE ERROR COUNT
9206	043044	104401	011051		TYPE	, DROPDR		;TYPE "DROPPING DRIVE"
9207	043050	000137	017332		JMP	NEWDRV		;PROCEED TO TEST NEXT DRIVE
9208	043054	032777	020000	136056	BIT	#SW13, JSWR	9\$:	;INHIBIT ERROR TYPEOUTS?
9209	043062	001402			BEQ	6\$;BR IF NO
9210	043064	000137	043470		JMP	20\$		
9211	043070	005000			CLR	RO	6\$:	;CLR RO FOR ERROR NUMBER
9212	043072	005005			CLR	R5		;INIT INDENT INDICATOR
9213	043074	005105			COM	R5		
9214	043076	113700	001114		MOVB	\$ITEMB, RO		;ENTER ERROR NUMBER
9215	043102	005300			DEC	RO		;FORM INDEX FOR ERROR TABLE
9216	043104	006300			RO			
9217	043106	006300			ASL	RO		
9218	043110	006300			ASL	RO		
9219	043112	062700	001400		ADD	#\$ERRTB, RO	1\$:	;FORM ADDRESS OF ERROR ENTRY
9220	043116	012037	043136		MOV	(RO)+, 2\$;GET EM POINTER
9221	043122	001406			BEQ	3\$;BRANCH IF THERE ISN'T ONE
9222	043124	104401	013277		TYPE	, CR2LF		
9223	043130	104401	060370		TYPE	, AS2SP2		;TYPE "*** "
9224	043134	104401			TYPE			;TYPE ERROR MESSAGE (EM)
9225	043136	000000			.WORD	0	2\$:	;EM POINTER GOES HERE
9226	043140	012037	043314		MOV	(RO)+, 4\$	3\$:	;GET DH POINTER
9227	043144	001467			BEQ	5\$;BR IF THERE ISN'T ONE
9228	043146	104401	001315		TYPE	, \$CRLF		
9229	043152	104401	060356		TYPE	, TSTMSG		;TYPE " TEST "
9230	043156	013746	001102		MOV	\$(TSTNM, -(SP)		;GET TEST NO. ON STACK
9231	043162	104403			TYPOS			;TYPE IT
9232	043164	002			.BYTE	2		;2 DIGITS
9233	043165	000			.BYTE	0		;SUPPRESS LEADING ZEROS
9234	043166	104401	013277		TYPE	, CR2LF		
9235	043172	032777	010000	135740	BIT	\$(BIT12, JSWR		;REPORT DESCRIPTION ONLY ?
9236	043200	001133			BNE	20\$;BR IF YES
9237	043202	104401	063110		TYPE	, DH105		;TYPE "PREVIOUS COMMAND :"
9238	043206	104401	001315		TYPE	, \$CRLF		
9239	043212	104401	063253		TYPE	, DH101+10		;TYPE PREV COMMAND HEADER
9240	043216	104401	001315		TYPE	, \$CRLF		
9241	043222	012701	000006		MOV	\$(R1		;SIX COMMAND VALUES
9242	043226	012702	001236		MOV	\$(R26, R2		;STARTING ADDR OF PREV CMND VALUES
9243	043232	012246			MOV	(R2)+, -(SP)	30\$:	;PUT A WORD ON STACK
9244	043234	104402			TYPOC			;TYPE IT
9245	043236	104401	013313		TYPE	, SPACE2		;TYPE SEPARATORS
9246	043242	005301			DEC	R1		;SEE IF 7 VALUES TYPED YET
9247	043244	001372			BNE	30\$;BR IF NOT
9248	043246	104401	001315		TYPE	, \$CRLF		
9249	043252	104401	013313		TYPE	, SPACE2		;INDENT
9250	043256	104401	063332		TYPE	, DH102		;TYPE HDR FOR BA DATA
9251	043262	104401	001315		TYPE	, \$CRLF		
9252	043266	104401	013313		TYPE	, SPACE2		;INDENT
9253	043272	012246			MOV	(R2)+, -(SP)		
9254	043274	104402			TYPOC			;TYPE PREV. HI BA BITS
9255	043276	104401	013313		TYPE	, SPACE2		
9256	043302	011246			MOV	(R2), -(SP)		
9257	043304	104402			TYPOC			;TYPE PREV. LO BA BITS

```

9258 043306 104401 013277          TYPE      ,CR2LF
9259 043312 104401          TYPE
9260 043314 000000          4$:      .WORD      0          ;TYPE DATA HEADER
9261 043316 104401 001315          TYPE      ,SCRLF          ;DH POINTER GOES HERE
9262 043322 005005          CLR      R5          ;INIT INDENT INDICATOR
9263 043324 032777 010000 135606 5$:      #BIT12,@SWR          ;REPORT DESCRIPTION ONLY ?
9264 043332 001056          BNE     20$          ;BR IF YES
9265 043334 012001          MOV     (R0)+,R1          ;GET DT POINTER
9266 043336 001454          BEQ     20$          ;BRANCH IF THERE ARE NONE
9267 043340 012000          MOV     (R0)+,R0          ;GET DF POINTER
9268 043342 012002          MOV     (R0)+,R2          ;STORE NUMBER OF DH'S
9269 043344 112003          MOV     (R0)+,R3          ;GET & STORE NUMBER OF DATA WORDS
9270 043346 105720          TSTB   (R0)+          ;BUMP PAST FORMAT WORD
9271 043350 005703          TST    R3          ;TEST IF ANY DATA FOR THIS HEADER
9272 043352 001417          BEQ     14$          ;NO - SKIP DATA PRINT
9273 043354 005705          TST    R5          ;SEE IF SHOULD INDENT
9274 043356 001002          BNE     11$          ;BR IF NOT
9275 043360 104401 013313          TYPE      ,SPACE2          ;INDENT
9276 043364 013146          MOV     @ (R1)+,-(SP)          ;PUT FIRST DATA WORD ON STACK
9277 043366 104402          TYPOC          ;TYPE IT
9278 043370 005303          DEC     R3          ;MORE DATA WORDS
9279 043372 001403          BEQ     12$          ;NO-BRANCH
9280 043374 104401 013313          TYPE      ,SPACE2          ;TYPE SEPARATORS
9281 043400 000771          BR      11$          ;LOOP
9282 043402 005702          TST    R2          ;SEE IF <CR>,<LF> NEEDED
9283 043404 001402          BEQ     14$          ;BR IF NOT
9284 043406 104401 001315          TYPE      ,SCRLF          ;TYPE IT
9285 043412 005302          DEC     R2          ;MORE DH'S?
9286 043414 003425          BLE     20$          ;NO-BRANCH
9287 043416 012037 043450          MOV     (R0)+,16$          ;GET NEXT DH POINTER
9288 043422 105710          TSTB   (R0)          ;SEE IF ANY DATA FOR HDR
9289 043424 001004          BNE     34$          ;BR IF YES
9290 043426 104401 001315          TYPE      ,SCRLF          ;SKIP EXTRA LINE
9291 043432 005005          CLR     R5          ;RE-INIT INDENT INDICATOR
9292 043434 000404          BR      36$          ;
9293 043436 005105          COM     R5          ;COMPLEMENT INDENT INDICATOR
9294 043440 001002          BNE     36$          ;BR IF NO INDENT REQUIRED
9295 043442 104401 013313          TYPE      ,SPACE2          ;INDENT
9296 043446 104401          36$:      TYPE      ,DH          ;TYPE DH
9297 043450 000000          16$:      .WORD      0          ;DH POINTER GOES HERE
9298 043452 104401 001315          TYPE      ,SCRLF          ;
9299 043456 105710          TSTB   (R0)          ;TYPE A DT?
9300 043460 001331          BNE     10$          ;YES-BRANCH
9301 043462 062700 000002          ADD     #2,R0          ;INCREMENT DF POINTER
9302 043466 000751          BR      14$          ;SEE IF END OF DF BLOCK
9303 043470 104410          20$:      RESREG          ;
9304 043472 000207          RTS     PC          ;
9305          ;*****
9306          ;SBTTL CONTROLLER ERROR REPORTER ROUTINE
9307          ;*ENTRY:      JSR PC, CONERR
9308          ;*RETURN:     RTS PC
9309          ;*
9310          ;*THIS ROUTINE DECODES THE CONTROLLER ERROR WORD AND
9311          ;*REPORTS THE APPROPRIATE MESSAGE. THE RK611 REGISTERS ARE
9312          ;*RETRIEVED FROM THE RK611 AND PLACED IN THE PARAMETER
9313          ;*BLOCK. THIS IS DONE BECAUSE PARM 0 MAY NOT BE VALID

```

```

9314 ;*AT THIS TIME.
9315 ;*****
9316 043474 104407 CONERR: SAVREG ;SAVE RD-RS
9317 043476 152737 000377 003123 BISR #377,DONE ;SET DONE FLAG
9318 043504 105237 003126 INCB ERRCNT ;INCREMENT ERROR COUNT
9319 043510 004737 046366 JSR PC,TOPROC ;LOAD RK REGS INTO $REGS
9320 043514 032737 000001 003052 BIT #BIT0,E.CONT ;ERROR 0?
9321 043522 001402 BEQ 1$ ;NO-BRANCH
9322 043524 104064 ERROR 64 ;CLEAR CONT DID NOT CLEAR ERROR
9323 043526 000470 BR 7$
9324 043530 032737 000002 003052 1$: BIT #BIT1,E.CONT ;ERROR 1?
9325 043536 001402 BEQ 2$ ;NO-BRANCH
9326 043540 104065 ERROR 65 ;NO ATTENTION IN ATTENTION SUM REG
9327 043542 000462 BR 7$
9328 043544 032737 000004 003052 2$: BIT #BIT2,E.CONT ;ERROR 2?
9329 043552 001407 BEQ 3$ ;NO-BRANCH
9330 043554 105737 003136 TSTB DRNAFG ;SEE IF DRIVE WAS SIEZED BY OTHER PORT
9331 043560 001402 BEQ 15$ ;BR IF NOT
9332 043562 105237 003137 INCB REISSU ;SET FLAG TO RE-ISSUE COMMAND
9333 043566 104066 15$: ERROR 66 ;UNSOLICITED ATTENTION
9334 043570 000447 BR 7$
9335 043572 032737 000010 003052 3$: BIT #BIT3,E.CONT ;ERROR 3?
9336 043600 001402 BEQ 4$ ;NO-BRANCH
9337 043602 104067 ERROR 67 ;UNEXPECTED DATA TYPE ERROR
9338 043604 000441 BR 7$
9339 043606 032737 000020 003052 4$: BIT #BIT4,E.CONT ;ERROR 4?
9340 043614 001402 BEQ 5$ ;NO-BRANCH
9341 043616 104070 ERROR 70 ;ATTENTION DID NOT RESET WITH CLEAR
9342 043620 000433 BR 7$
9343 043622 032737 000040 003052 5$: BIT #BIT5,E.CONT ;ERROR 5?
9344 043630 001402 BEQ 6$ ;NO-BRANCH
9345 043632 104071 ERROR 71 ;SUBSYS CLEAR DIDN'T CLEAR DRIVE ATTENTION
9346 043634 000425 BR 7$
9347 043636 032737 000400 003052 6$: BIT #BIT8,E.CONT
9348 043644 001401 BEQ 8$ ;DATA LATE WHEN UNLOADING HEADER
9349 043646 104072 ERROR 72
9350 043650 032737 001000 003052 8$: BIT #BIT9,E.CONT
9351 043656 001401 BEQ 9$ ;CONTROLLER ERROR DURING DRIVER SERVICE
9352 043660 104073 ERROR 73
9353 043662 032737 002000 003052 9$: BIT #BIT10,E.CONT
9354 043670 001401 BEQ 10$ ;DRIVE DETECTED PARITY ERROR
9355 043672 104074 ERROR 74
9356 043674 032737 100000 003052 10$: BIT #BIT15,E.CONT
9357 043702 001401 BEQ 11$ ;MULTIPLE DRIVE SELECT
9358 043704 104052 ERROR 52 ;UNDEFINED ERROR
9359 043706 104075 11$: ERROR 75 ;CLEAR CONTROLLER ERROR WORD
9360 043710 005037 003052 7$: CLR E.CONT ;GO DO RETRY
9361 043714 000137 046166 JMP BGNRTY
9362 ;*****
9363 ;SBTTL REPORT SUPPORT ROUTINE
9364 ;*THIS ROUTINE LOADS ALL THE PARAMETER BLOCK DATA TO BE REPORTED
9365 ;*INTO THE PROPER TEMPORARY REGISTERS FOR REPORTING. ALL THESE MAY
9366 ;*NOT BE INCLUDED IN THE REPORT, BUT THEY ARE LOADED ANYWAY.
9367 043720 REPSUP: SAVREG
9368 043720 104407 CLR ERRCOM ;CLEAR ERROR COMMAND STORE
9369 043722 005037 005476

```



```

9370 043726 116537 000001 005476      MOV      P.CMND(R5),ERRCOM ;STORE COMMAND START VALUES
9371 043734 012700 001162      MOV      #SREG0,R0 ;FOR REPORTING
9372 043740 016520 000002      MOV      P.CYLN(R5),(R0)+
9373 043744 116520 000005      MOV      P.TRCK(R5),(R0)+
9374 043750 105020      CLR      (R0)+
9375 043752 116520 000004      MOV      P.SECT(R5),(R0)+
9376 043756 105020      CLR      (R0)+
9377 043760 016520 000012      MOV      P.WC(R5),(R0)+
9378 043764 012700 001174      MOV      #SREG5,R0
9379 043770 116503 000007      MOV      P.BAHI(R5),R3
9380 043774 042703 177774      BIC      #177774,R3
9381 044000 010337 001256      MOV      R3,SREG36 ;HI BA BITS
9382 044004 016537 000010 001260      MOV      P.BALO(R5),SREG37 ;LO BA BITS
9383 044012 016520 000016      MOV      P.CS1(R5),(R0)+ ;GET ALL THE VALUES FROM THE
9384 044016 016520 000020      MOV      P.CS2(R5),(R0)+ ;PARAMETER BLOCK AND LOAD
9385 044022 016520 000030      MOV      P.DCYL(R5),(R0)+ ;THE TEMPORARY REGISTERS
9386 044026 016520 000026      MOV      P.DTS(R5),(R0)+ ;FOR REPORTING. ALL THIS
9387 044032 016520 000022      MOV      P.WCR(R5),(R0)+ ;DATA MAY NOT BE VALID
9388                                     ;FOR ALL REPORTS (TO BE
9389 044036 016520 000024      MOV      P.BAR(R5),(R0)+ ;DETERMINED LATER) BUT IT IS
9390 044042 016520 000032      MOV      P.ASOF(R5),(R0)+ ;STORED ANY WAY.
9391 044046 016520 000036      MOV      P.DS(R5),(R0)+
9392 044052 016520 000034      MOV      P.ER(R5),(R0)+
9393 044056 016520 000040      MOV      P.A00(R5),(R0)+
9394 044062 016520 000042      MOV      P.B00(R5),(R0)+
9395 044066 016520 000044      MOV      P.A01(R5),(R0)+
9396 044072 016520 000046      MOV      P.B01(R5),(R0)+
9397 044076 016520 000050      MOV      P.A10(R5),(R0)+
9398 044102 016520 000052      MOV      P.B10(R5),(R0)+
9399 044106 016520 000054      MOV      P.A11(R5),(R0)+
9400 044112 016520 000056      MOV      P.B11(R5),(R0)+
9401                                     ;STORE PREVIOUS COMMAND FOR PRINTOUT
9402 044116 012701 001236      MOV      #SREG26,R1 ;ADRS OF PRINT BUF AREA
9403 044122 012700 005224      MOV      #PRVCMD,R0 ;ADRS OF PREV CMND STORAGE
9404 044126 112021      MOV      (R0)+,(R1)+ ;DRIVE NO.
9405 044130 105021      CLR      (R1)+
9406 044132 112021      MOV      (R0)+,(R1)+ ;COMMAND
9407 044134 105021      CLR      (R1)+
9408 044136 012021      MOV      (R0)+,(R1)+ ;CYL ADDRESS
9409 044140 116021 000001      MOV      1(R0),(R1)+ ;TRACK
9410 044144 105021      CLR      (R1)+
9411 044146 111021      MOV      (R0),(R1)+ ;SECTOR
9412 044150 105021      CLR      (R1)+
9413 044152 016021 000006      MOV      6(R0),(R1)+ ;WORD COUNT
9414 044156 116003 000003      MOV      3(R0),R3 ;HI BA BITS
9415 044162 042703 177774      BIC      #177774,R3
9416 044166 010321      MOV      R3,(R1)+
9417 044170 016011 000004      MOV      4(R0),(R1) ;LO BA BITS
9418 044174 104410      RESREG
9419 044176 000207      RTS      PC
9420                                     ;*****
9421 .SBTTL REPORT ERROR ROUTINE
9422 ;* ENTRY JSR PC,ERRHDL
9423 ;*RETURN RTS PC
9424 ;*
9425 ;*THIS ROUTINE IS CALLED BY THE DRIVER WHEN AN ERROR IS DETECTED

```


9459	044266	001406				BEQ	1\$;REPORT ERROR
9460	044270	104001				ERROR	1		
9461	044272	052737	000200	005474		BIS	#ABORT,RECODE		
9462	044300	000137	045674			JMP	37\$		
9463	044304	032765	004000	000020	1\$:	BIT	#NEM,P.CS2(R5)		;TEST NON-EXISTANT MEMORY
9464	044312	001406				BEQ	2\$		
9465	044314	104002				ERROR	2		
9466	044316	052737	000200	005474		BIS	#ABORT,RECODE		
9467	044324	000137	045674			JMP	37\$		
9468	044330	032765	010000	000020	2\$:	BIT	#NED,P.CS2(R5)		;TEST NON-EXISTANT DRIVE
9469	044336	001412				BEQ	3\$		
9470	044340	032765	000400	000020		BIT	#UFE,P.CS2(R5)		;TEST IF NED & UFE BOTH SET
9471	044346	001403				BEQ	38\$		
9472	044350	104035				ERROR	35		;NED & UFE BOTH SET ERROR
9473	044352	000137	045674			JMP	37\$		
9474	044356	104003			38\$:	ERROR	3		;NED ONLY
9475	044360	000137	045674			JMP	37\$		
9476	044364	032765	000400	000020	3\$:	BIT	#UFE,P.CS2(R5)		;TEST UNIT FIELD ERROR
9477	044372	001412				BEQ	4\$		
9478	044374	032765	010000	000020		BIT	#NED,P.CS2(R5)		;TEST IF UFE & NED BOTH SET
9479	044402	001403				BEQ	39\$;NO-SKIP
9480	044404	104035				ERROR	35		;REPORT NED & UFE BOTH SET
9481	044406	000137	045674			JMP	37\$		
9482	044412	104004			39\$:	ERROR	4		;REPORT UFE ONLY
9483	044414	000137	045674			JMP	37\$		
9484	044420	032765	000100	000014	4\$:	BIT	#CMDTO,P.PRST(R5)		
9485	044426	001423				BEQ	5\$		
9486	044430	004737	046366			JSR	PC, TOPROC		;GO PROCESS TIMEOUT
9487	044434	032737	002000	005474		BIT	#TWOTOS,RECODE		;2ND TIMEOUT IN TIMEOUT PROC?
9488	044442	001007				BNE	40\$;YES - SKIP TO ERROR 56
9489	044444	032737	000400	005474		BIT	#LEV2ER,RECODE		;TEST IF LEVEL 2 ERROR
9490	044452	001006				BNE	41\$;YES - SKIP TO ERROR 57
9491	044454	104005				ERROR	5		;ELSE MAKE FULL TIMEOUT REPORT
9492	044456	000137	045674			JMP	37\$		
9493	044462	104056			40\$:	ERROR	56		;TWO TIMEOUTS ERROR REPORT
9494	044464	000137	045674			JMP	37\$		
9495	044470	104057			41\$:	ERROR	57		;2ND LEVEL ERROR REPORT
9496	044472	000137	044220			JMP	ER2ENT		;GO BUILD AND MAKE 2ND REPORT
9497	044476	032765	010000	000014	5\$:	BIT	#DRVSZD,P.PRST(R5)		;SEE IF DRIVE SIEZED BY OTHER PORT
9498	044504	001403				BEQ	65\$;BR IF DRIVE IS AVAILABLE
9499	044506	104107				ERROR	107		;DRIVE SIEZED BY OTHER PORT
9500	044510	000137	045674			JMP	37\$		
9501	044514	032765	020000	000016	65\$:	BIT	#SPAR,P.CS1(R5)		;TEST D TO C PARITY ERROR
9502	044522	001406				BEQ	6\$		
9503	044524	104006				ERROR	6		
9504	044526	052737	004000	005474		BIS	#RCLREQ,RECODE		
9505	044534	000137	045674			JMP	37\$		
9506	044540	032704	000010		6\$:	BIT	#DRPAR,R4		;TEST DRIVE DETECTED PARITY ERROR
9507	044544	001406				BEQ	7\$		
9508	044546	104007				ERROR	7		
9509	044550	052737	004000	005474		BIS	#RCLREQ,RECODE		
9510	044556	000137	045674			JMP	37\$		
9511	044562	032765	000010	000036	7\$:	BIT	#ACLO,P.DS(R5)		;TEST AC LOW
9512	044570	001403				BEQ	8\$		
9513	044572	104010				ERROR	10		
9514	044574	000137	045674			JMP	37\$		

9515	044600	032765	000020	000036	8\$:	BIT	#SPDLSS,P.DS(R5)	;TEST SPEED LOSS
9516	044606	001403				BEQ	24\$	
9517	044610	104011				ERROR	11	
9518	044612	000137	045674			JMP	37\$	
9519	044616	032765	004000	000016	24\$:	BIT	#CTO,P.CS1(R5)	;TEST FOR CONTROLLER TIMEOUT
9520	044624	001401				BEQ	25\$	
9521	044626	104027				ERROR	27	
9522	044630	032704	000001		25\$:	BIT	#ILC,R4	;TEST ILLEGAL FUNCTION CODE
9523	044634	001403				BEQ	10\$	
9524	044636	104012				ERROR	12	
9525	044640	000137	045674			JMP	37\$	
9526	044644	032765	002000	000020	10\$:	BIT	#PGE,P.CS2(R5)	;TEST PROGRAMMING ERROR
9527	044652	001403				BEQ	11\$	
9528	044654	104013				ERROR	13	
9529	044656	000137	045674			JMP	37\$	
9530	044662	032704	000004		11\$:	BIT	#ILF,R4	;TEST ILLEGAL DRIVE FUNCTION
9531	044666	001403				BEQ	12\$	
9532	044670	104014				ERROR	14	
9533	044672	000137	045674			JMP	37\$	
9534	044676	032704	000040		12\$:	BIT	#DTYE,R4	;TEST DRIVE TYPE ERROR
9535	044702	001403				BEQ	13\$	
9536	044704	104015				ERROR	15	
9537	044706	000137	045674			JMP	37\$	
9538	044712	032704	000020		13\$:	BIT	#FMTE,R4	;TEST FORMAT ERROR
9539	044716	001403				BEQ	14\$	
9540	044720	104016				ERROR	16	
9541	044722	000137	045674			JMP	37\$	
9542	044726	032704	004000		14\$:	BIT	#WLE,R4	;TEST WRITE LOCK ERROR
9543	044732	001403				BEQ	15\$	
9544	044734	104017				ERROR	17	
9545	044736	000137	045674			JMP	37\$	
9546	044742	032704	040000		15\$:	BIT	#UNS,R4	;TEST DRIVE UNSAFE
9547	044746	001406				BEQ	16\$	
9548	044750	104020				ERROR	20	
9549	044752	052737	000200	005474		BIS	#ABORT,RECODE	
9550	044760	000137	045774			JMP	ALLTRM	
9551	044764	032704	000002		16\$:	BIT	#SKI,R4	;TEST SEEK INCOMPLETE
9552	044770	001406				BEQ	17\$	
9553	044772	104021				ERROR	21	
9554	044774	052737	004000	005474		BIS	#RCLREQ,RECODE	
9555	045002	000137	045674			JMP	37\$	
9556	045006	032704	001000		17\$:	BIT	#COE,R4	;TEST CYLINDER OVERFLOW
9557	045012	001406				BEQ	18\$	
9558	045014	104022				ERROR	22	
9559	045016	052737	004000	005474		BIS	#RCLREQ,RECODE	
9560	045024	000137	045674			JMP	37\$	
9561	045030	032704	002000		18\$:	BIT	#IDAE,R4	;TEST ILLEGAL CYLINDER
9562	045034	001406				BEQ	19\$	
9563	045036	104023				ERROR	23	
9564	045040	052737	004000	005474		BIS	#RCLREQ,RECODE	
9565	045046	000137	045674			JMP	37\$	
9566	045052	032765	000040	000036	19\$:	BIT	#DROT,P.DS(R5)	;TEST DRIVE OFF TRACK
9567	045060	001406				BEQ	20\$	
9568	045062	104024				ERROR	24	
9569	045064	052737	004000	005474		BIS	#RCLREQ,RECODE	
9570	045072	000137	045674			JMP	37\$	

9571	045076	032704	010000		20\$:	BIT	#DTE,R4		;TEST DRIVE TIMING ERROR
9572	045102	001406				BEQ	21\$		
9573	045104	104025				ERROR	25		
9574	045106	052737	000200	005474		BIS	#ABORT,RECODE		
9575	045114	000137	045674			JMP	37\$		
9576	045120	032765	100000	000020	21\$:	BIT	#DLT,P.CS2(R5)		;TEST DATA LATE
9577	045126	001403				BEQ	22\$		
9578	045130	104026				ERROR	26		
9579	045132	000137	045674			JMP	37\$		
9580	045136	032704	020000		22\$:	BIT	#OPI,R4		;TEST IF OPI ERROR
9581	045142	001457				BEQ	29\$		
9582	045144	052737	000010	005474		BIS	#OPIERR,RECODE		
9583	045152	105737	003121			TSTB	DERCNT		;TEST IF FIRST ERROR
9584	045156	001402				BEQ	50\$		
9585	045160	000137	045674			JMP	37\$;NO - SKIP REPORT
9586	045164	032737	000400	005474	50\$:	BIT	#LEV2ER,RECODE		;TEST IF A SECOND LEVEL 2 ERROR
9587	045172	001403				BEQ	26\$;HAS ALREADY OCCURRED
9588	045174	104054			27\$:	ERROR	54		
9589	045176	000137	045674			JMP	37\$;GET OUT OF ERROR REPORT
9590	045202	004737	047026		26\$:	JSR	PC,BLDEXH		;GO BUILD EXPECTED HEADER
9591	045206	004737	046536			JSR	PC,RDHDO		;GET HEADER OF SECTOR 0
9592	045212	032737	000400	005474		BIT	#LEV2ER,RECODE		;TEST IF ERROR GETTING HDR
9593	045220	001025				BNE	28\$;IF YES-GO MAKE ABBREVIATED REPORT
9594	045222	013702	003036			MOV	RKBAS,R2		;STORE HEADER 0 INTO REGISTERS
9595	045226	042762	000100	000000		BIC	#IE,RKCS1(R2)		;RESET INTERRUPT ENABLE
9596	045234	016237	000024	001202		MOV	RKDB(R2),\$REG10		;FOR REPORTING
9597	045242	016237	000024	001204		MOV	RKDB(R2),\$REG11		
9598	045250	016237	000024	001206		MOV	RKDB(R2),\$REG12		
9599	045256	032762	100000	000000		BIT	#CERR,RKCS1(R2)		;TEST IF ERROR DURING STORAGE
9600	045264	001343				BNE	27\$		
9601	045266	104030				ERROR	30		;MAKE OPI REPORT
9602	045270	000137	045674			JMP	37\$		
9603	045274	104054			28\$:	ERROR	54		
9604	045276	000137	044220			JMP	ER2ENT		;GO MAKE 2ND LEVEL REPORT
9605	045302	032704	000400		29\$:	BIT	#HVRC,R4		;TEST IF HVRC ERROR
9606	045306	001457				BEQ	23\$		
9607	045310	052737	000004	005474		BIS	#HVR CER,RECODE		
9608	045316	105737	003121			TSTB	DERCNT		;TEST IF FIRST ERROR
9609	045322	001402				BEQ	30\$;YES - REPORT
9610	045324	000137	045674			JMP	37\$;JUMP TO RETURN
9611	045330	032737	000400	005474	30\$:	BIT	#LEV2ER,RECODE		;TEST IF A 2ND LEVEL ERROR HAS ALREADY
9612	045336	001403				BEQ	31\$;OCCURRED. NO-SKIP EXIT
9613	045340	104055			51\$:	ERROR	55		
9614	045342	000137	045674			JMP	37\$;GET OUT OF ERROR REPORT
9615	045346	004737	047026		31\$:	JSR	PC,BLDEXH		;GO BUILD EXPECTED HEADER
9616	045352	004737	046536			JSR	PC,RDHDO		;GO GET HDR 0
9617	045356	032737	000400	005474		BIT	#LEV2ER,RECODE		;TEST IF ERROR IN GETTING HDR
9618	045364	001025				BNE	32\$;IF YES-GO MAKE ABBREVIATED REPORT
9619	045366	013702	003036			MOV	RKBAS,R2		;GET RK611 BASE ADDRESS
9620	045372	042762	000100	000000		BIC	#IE,RKCS1(R2)		;CLEAR INTERRUPT ENABLE
9621	045400	016237	000024	001202		MOV	RKDB(R2),\$REG10		;STORE OFF HEADER
9622	045406	016237	000024	001204		MOV	RKDB(R2),\$REG11		
9623	045414	016237	000024	001206		MOV	RKDB(R2),\$REG12		
9624	045422	032762	100000	000000		BIT	#CERR,RKCS1(R2)		;TEST IN ANY ERROR IN UNLOAD
9625	045430	001343				BNE	51\$;IF YES - GO MAKE SHORT REPORT
9626	045432	104031				ERROR	31		;MAKE FULL REPORT

9627	045434	000137	045674		JMP	37\$	
9628	045440	104055		32\$:	ERROR	55	; ABREVIATED HVRC ERROR RPORT
9629	045442	000137	044220		JMP	ER2ENT	; GO REPORT 2ND LEVEL ERROR
9630	045446	032704	000200	23\$:	BIT	#BSE,R4	; TEST FOR BAD SECTOR ERROR
9631	045452	001430			BEQ	33\$; NO - SKIP
9632	045454	052737	000002	005474	BIS	#BSERR,RECODE	; SET ERROR FLAG
9633	045462	016500	000030		MOV	P.DCYL(R5),R0	; GET CYL NO.
9634	045466	116501	000027		MOVB	P.DTS+1(R5),R1	; GET TRACK NO.
9635	045472	042701	177774		BIC	#177774,R1	; CLEAR ALL BITS EXCEPT TRACK
9636	045476	016502	000026		MOV	P.DTS(R5),R2	; GET SECTOR IN ERROR
9637	045502	042702	177740		BIC	#177740,R2	; CLEAR ALL BITS EXCEPT SECTOR
9638	045506	004737	042436		JSR	PC,BDSRCK	; GO SEE IF THIS SECTOR LISTED
9639	045512	032737	001000	005474	BIT	#BADSEC,RECODE	; TEST RESULT
9640	045520	001065			BNE	37\$; YES - EXIT, NO ERROR OR REPORT
9641	045522	104104			ERROR	104	; ELSE REPORT BAD BSE
9642	045524	042737	000002	005474	BIC	#BSERR,RECODE	; RESET BSE ERROR FLAG
9643	045532	000460			BR	37\$; GO EXIT
9644	045534	032704	100000	33\$:	BIT	#DCK,R4	; TEST IF DATA CHECK
9645	045540	001435			BEQ	36\$	
9646	045542	052737	000020	005474	BIS	#DCKERR,RECODE	; SET DATA CHECK ERROR IN RECOVERY CODE
9647	045550	032704	000100		BIT	#ECH,R4	; TEST IF ECC IS HARD. IF
9648	045554	001406			BEQ	34\$; YES SET UNCORRECTABLE IN
9649	045556	052737	000040	005474	BIS	#ECCNC,RECODE	; RECOVERY FLAG AND A 0 IN
9650	045564	005037	001206		CLR	\$REG12	; REG12 TO INDICATE UNCORRECTABLE,
9651	045570	000403			BR	35\$; A 1 IN REG 12 FOR CORRECTABLE
9652	045572	012737	000001	001206	34\$:	MOV	#1,\$REG12
9653	045600	105737	003121	35\$:	TSTB	DERCNT	; TEST IF FIRST ERROR
9654	045604	001033			BNE	37\$; NO SKIP REPORT
9655	045606	004737	046702		JSR	PC,GTPKAD	; GO GET PACK ADDRESS OF ERROR
9656	045612	016537	000060	001202	MOV	P.EPOS(R5),\$REG10	; STORE ECC POSITION &
9657	045620	016537	000062	001204	MOV	P.EPAT(R5),\$REG11	; PATTERN
9658	045626	104032			ERROR	32	; REPORT DCK ERROR
9659	045630	000137	045674		JMP	37\$	
9660	045634	032765	040000	000020	36\$:	BIT	#WCE,P.CS2(R5) ; TEST WRITE CHECK ERROR
9661	045642	001414			BEQ	37\$	
9662	045644	042737	000200	005474	BIC	#ABORT,RECODE	; CLEAR ABORT & SET WRITE
9663	045652	052737	000100	005474	BIS	#WCERR,RECODE	; CHECK ERROR IN RECODE
9664	045660	105737	003121		TSTB	DERCNT	; TEST IF FIRST ERROR
9665	045664	001003			BNE	37\$; NO - SKIP
9666	045666	004737	046702		JSR	PC,GTPKAD	; GO GET ADDRESS OF ERROR
9667	045672	104033			ERROR	33	; REPORT WCE
9668							
9669	045674	032765	000020	000014	37\$:	BIT	#DRVHRD,P.PRST(R5) ; TEST HARD ERROR
9670	045702	001404			BEQ	43\$	
9671	045704	104036			ERROR	36	
9672	045706	052737	000200	005474	BIS	#ABORT,RECODE	
9673							
9674	045714	032765	000040	000014	43\$:	BIT	#DRVDSC,P.PRST(R5) ; TEST STATUS CHANGE NOT CLEARED
9675	045722	001404			BEQ	44\$	
9676	045724	104037			ERROR	37	
9677	045726	052737	000200	005474	BIS	#ABORT,RECODE	
9678							
9679	045734	032765	004000	000014	44\$:	BIT	#NODSC,P.PRST(R5) ; IFST ATTENTION BUT NO FAULT OR DSC
9680	045742	001404			BEQ	46\$	
9681	045744	104040			ERROR	40	
9682	045746	052737	000200	005474	BIS	#ABORT,RECODE	

```

9683
9684 045754 032765 000010 000014 46$: BIT #UEXATT,P.PRST(R5) ;TEST UNEXPECTED ATTENTION
9685 045762 001404 BEQ ALLTRM
9686 045764 104042 ERROR 42
9687 045766 052737 000200 005474 BIS #ABORT,RECODE
9688
9689
9690 ;ALL ERRORS MUST EXIT THROUGH THIS POINT
9691
9692 045774 012705 002630 ALLTRM: MOV #PARMO,R5 ;RESTORE PARAMETER BLOCK SELECTION
9693 046000 012737 044200 003046 MOV #ERRHDL,A.ABNL ;RESTORE INTERRUPT VECTORS FOR RETRY
9694 046006 012737 042732 003044 MOV #ERRFRE,A.NORM ;DRIVER OPERATIONS, IF ANY
9695 046014 032737 000200 005474 BIT #ABORT,RECODE ;IF ABORT IS NOT SET AND
9696 046022 001043 BNE 48$ ;THE DRIVE IS READY (HAS NOT
9697 ;CYCLED DOWN)
9698 046024 012702 003036 MOV RKBAS,R2 ;GET BASE ADDRESS
9699 046030 032762 000200 000012 BIT #RDY,AKDS(R2) ;TEST IF DRIVE READY SET
9700 046036 001004 BNE 47$ ;RECALIBRATE REQUIRED BIT IS SET
9701 046040 052737 000200 005474 BIS #ABORT,RECODE ;ELSE ABORT WITH ABORT MESSAGE
9702 046046 000431 BR 48$
9703 046050 032737 004000 005474 47$: BIT #RCLREQ,RECODE ;IF RECALIBRATE IS REQUIRED
9704 046056 001443 BEQ BGNRTY ;FOR RETRY SET UP PARAM
9705 046060 112737 000113 000001 MOVB #RECAL,P.CMND ;BLOCK TO DO IT.
9706 046066 012737 046340 003046 MOV #RETANL,A.ABNL
9707 046074 004737 042542 JSR PC,DRVCAL
9708 046100 012737 044200 003046 MOV #ERRHDL,A.ABNL ;RESTORE ERROR RETURN
9709 046106 032737 000400 005474 BIT #LEV2ER,RECODE ;IF AN ERROR OCCURRED IN THE
9710 046114 001424 BEQ BGNRTY ;RECAL ATTEMP SET ABORT
9711 046116 052737 000200 005474 BIS #ABORT,RECODE ;PRINT THE RECAL ERROR MESSAGE, AND
9712 046124 104060 ERROR 60 ;GO REPORT DETAILS
9713 046126 000137 044220 JMP ERZENT
9714 046132 104061 48$: ERROR 61 ;REPORT ABORT-RETRY FAILED
9715 046134 105037 003130 CLRB DRVERS ;CLR DRV ERR CNT
9716 046140 105037 003126 CLRB ERRCNT
9717 046144 000137 017332 JMP NEWDRV ;TEST NEXT DRV
9718
9719 ;THE PROGRAM WILL HALT HERE IF THE ABORT FLAG HAS BEEN SET OR
9720 ;IF THE DRIVE READY BIT IS RESET.
9721
9722 046150 000005 HLTPRG: RESET ;DISABLE ALL DEVICES
9723 046152 000000 HALT ;HALT THE CPU
9724 046154 105037 003126 CLRB ERRCNT ;CLEAR ERROR COUNT
9725 046160 000005 RESET ;RESET ALL DEVICES
9726 046162 000137 013410 JMP CMSTRT
9727
9728
9729 ;THE FOLLOWING CODE WILL DETERMINE IF AND DATA TYPE ERROR
9730 ;HAS OCCURRED. IF YES, THE RETRY IS NOT DONE HERE BUT RETURNS TO
9731 ;THE INITIATING ROUTINE FOR RETRY. ANY OTHER ERROR IS TO BE
9732 ;RETRIED HERE. IF RETRY IS UNSUCCESSFUL AFTER 4 ATTEMPTS, THE ABORT
9733 ;FLAG IS SET AND PROGRAM HALTS.
9734
9735 046166 032737 000136 005474 BGNRTY: BIT #BSERR!HVR CER!OPIERR!DCKERR!WCERR,RECODE ;TEST IF ANY DATA ERROR
9736 046174 001404 BEQ 3$
9737 046176 052737 100000 005474 9$: BIS #ANYDER,RECODE
9738 046204 000453 BR 2$

```

```

9739 046206 105737 003142 3$: TSTB NORTRY ;SEE IF "NO-RETRY" FLAG SET
9740 046206 001371 BNE 9$ ;BR IF YES
9741 046212 032737 001000 005474 BIT #BADSEC,RECODE ;TEST IF BAD SECTOR FLAG SET
9742 046214 001044 BNE 2$ ;IF YES-EXIT TO CALLER
9743 046222 123737 003126 003127 CMPB EPRCNT,ERRLMT ;BEGIN RETRY IF ERROR COUNT HAS
9744 046224 001012 BNE 1$ ;NOT BEEN EXCEEDED
9745 046232 005037 001174 CLR $REG5
9746 046234 113737 003126 001174 MOVB ERRCNT,$REG5 ;GET ERROR RETRY COUNT
9747 046240 104102 ERROR 102 ;REPORT RETRY UNSUCCESSFUL
9748 046246 052737 000200 005474 BIS #ABORT,RECODE ;SET ABORT & QUIT
9749 046250 000734 BR HLTPRG
9750 046256 013702 003036 1$: MOV RKBAS,R2 ;GET RK BASE ADDRESS
9751 046260 112765 000177 000001 MOVB #SUBCLR,P.CMND(R5) ;SET UP TO CLEAR SUBSYSTEM
9752 046264 004737 042542 JSR PC,DRVCAL ;GO DO IT
9753 046272 012700 005240 MOV #COMSTR,R0 ;GO AND REESTABLISH THE COMMAND
9754 046276 012025 MOV (R0)+,(R5)+ ;AS IT WAS ENTERED INTO THE
9755 046302 012025 MOV (R0)+,(R5)+ ;PARAMETER BLOCK
9756 046304 012025 MOV (R0)+,(R5)+
9757 046306 012025 MOV (R0)+,(R5)+
9758 046310 012025 MOV (R0)+,(R5)+
9759 046312 012025 MOV (R0)+,(R5)+
9760 046314 012025 MOV (R0)+,(R5)+
9761 046316 012705 002630 MOV #PARMO,R5
9762 046322 012737 000000 177776 JSR #PRO,PSW ;LOWER PRIORITY TO ALLOW INTERRUPT
9763 046330 004737 042542 JSR PC,DRVCAL ;CALL DRIVER
9764 046334 104410 2$: RESREG ;IF RETURN GETS HERE, NO ERROR
9765 046336 000207 RTS PC ;OCCURRED, RECOVERY WAS SUCCESSFUL

```

```

9766
9767
9768 046340 152737 000377 003123 RETANL: BISB #377,DONE ;SET DONE
9769 046346 052737 000400 005474 BIS #LEV2ER,RECODE ;SET LEVEL TWO ERROR
9770 046354 000207 RTS PC
9771 046356 152737 000377 003123 RETNML: BISB #377,DONE ;SET DONE
9772 046364 000207 RTS PC

```

```

;*****
;SBTTL TIME OUT PROCESSOR ROUTINE
;THIS ROUTINE SUPPORTS THE ERROR HANDLER BY PROCESSING TIME OUT STATUS
;GATHERING DUTIES.
;*****

```

```

9773
9774
9775
9776
9777
9778
9779
9780 046366 104407 003036 †OPROC: SAVREG
9781 046366 013702 001174 MOV RKBAS,R2
9782 046370 012701 000000 MOV #SREG5,R1 ;SET UP R1 FOR RK REGISTER STORAGE
9783 046374 016221 000010 MOV RKCS1(R2),(R1)+ ;STORE ALL VALID RK611
9784 046400 016221 000010 MOV RKCS2(R2),(R1)+ ;REGISTERS
9785 046404 016221 000020 MOV RKDC(R2),(R1)+
9786 046410 016221 000006 MOV RKDA(R2),(R1)+
9787 046414 016221 000002 MOV RKWC(R2),(R1)+
9788 046420 016221 000004 MOV RKBA(R2),(R1)+
9789 046424 016221 000016 MOV RKASOF(R2),(R1)+
9790 046430 016221 000012 MOV RKDS(R2),(R1)+
9791 046434 016221 000014 MOV RKER(R2),(R1)+
9792 046440 005000 CLR R0 ;THIS CODE WILL ATTEMPT TO
9793 046444
9794

```



```

9795                                     ;DRIVE.
9796 046446 012705 002714                MOV    #PARI, R5                ;SET UP TO USE PARI
9797 046452 112765 000141 000001        MOVB   #RDSTAT, P.CMND(R5) ;DO READ DRIVE STATUS COMMAND
9798 046460 004737 042542                JSR    PC, DRVCAL              ;CALL DRIVER
9799 046464 032765 000100 000014        BIT    #CMDTO, P.PRST(R5) ;TEST FOR TIMEOUT
9800 046472 001403 1$                    BEQ    1$                       ;NO - SKIP
9801 046474 052737 002000 005474        BIS    #TWGTOS, RECODE        ;SET TWO TIMEOUTS FLAG
9802 046502 062705 000040                ADD    #P.ADD, R5             ;BUMP R5 TO POINT TO DRIVE STATUS
9803 046506 012521 1$                    MOV    (R5)+, (R1)+           ;MOVE ALL THE DRIVE STATUS INTO THE
9804 046510 012521                        MOV    (R5)+, (R1)+           ;TEMP REGS FOR REPORTING.
9805 046512 012521                        MOV    (R5)+, (R1)+
9806 046514 012521                        MOV    (R5)+, (R1)+
9807 046516 012521                        MOV    (R5)+, (R1)+
9808 046520 012521                        MOV    (R5)+, (R1)+
9809 046522 012521                        MOV    (R5)+, (R1)+
9810 046524 012521                        MOV    (R5)+, (R1)+
9811
9812 046526 012705 002630                MOV    #PARMO, R5             ;RESTORE PARI 0
9813 046532 104410                        RESREG
9814 046534 000207                        RTS    PC
9815
9816
9817
9818                                     ;:*****
9819                                     ;:SBTTL READ HEADER 0 ROUTINE
9820                                     ;:*****
9821 046536                                     RDHDO:
9822 046536 104407                        SAVREG
9823 046540 016501 000026                MOV    P.DTS(R5), R1          ;STORE TRACK AND SECTOR
9824 046544 016500 000052                MOV    P.B10(R5), R0         ;GET THE CYLINDER ADRS
9825 046550 042700 160017                BIC    #160017, R0           ;FROM THE DRIVE STATUS. CLEAR
9826 046554 006200                        ASR    R0                     ;OFF UNUSED BITS AND POSITION
9827 046556 006200                        ASR    R0                     ;FOR USE AS THE DESIRED
9828 046560 006200                        ASR    R0                     ;CYLINDER IN THE READ
9829 046562 006200                        ASR    R0                     ;HEADER COMMAND.
9830 046564 012705 002714                MOV    #PARI, R5             ;SET UP TO USE P.B. 1
9831 046570 010165 000004                MOV    R1, P.SECT(R5)        ;INSERT TRK, SECT FOR READ HDR
9832 046574 010065 000002                MOV    R0, P.CYLN(R5)       ;SET CYL NO.
9833 046600 112765 000177 000001        MOVB   #SUBCLR, P.CMND(R5) ;SET S.S. CLEAR CMND
9834 046606 012737 000000 177776        MOV    #PRO, #PSW           ;ALLOW INTERRUPTS
9835 046614 004737 042542                JSR    PC, DRVCAL           ;CLEAR THE S.S.
9836 046620 112765 000125 000001        MOVB   #RDHEAD, P.CMND(R5) ;SET READ HEADER COMMAND
9837 046626 004737 042542                JSR    PC, DRVCAL           ;DO READ HEADER
9838 046632 012712 000025                MOV    #25, (R2)            ;ISSUE RD HDR WITH FMT BIT = 0
9839 046636 032712 000200 4$           BIT    #BIT7, (R2)          ;CHECK FOR C. READY IN CS1
9840 046642 001775 4$                    BEQ    4$                     ;BR IF NOT RDY YET
9841 046644 012712 010025                MOV    #10025, (R2)         ;ISSUE RD HDR WITH FMT BIT = 1
9842 046650 032712 000200 6$           BIT    #BIT7, (R2)          ;CHECK FOR C. READY IN CS1
9843 046654 001775 6$                    BEQ    6$                     ;BR IF NOT RDY YET
9844 046656 142765 000020 000007        BICB   #B.CFMT, P.CS1H(R5) ;CLEAR THE FORMAT BIT
9845 046664 153765 003125 000007        BISB   FORMAT, P.CS1H(R5) ;RESTORE TYPE AND FMT IN USE
9846 046672 012705 002630                MOV    #PARMO, R5             ;RESTORE P.B. 0 ADDRESS
9847 046676 104410                        RESREG                        ;RESTORE R0-R5
9848 046700 000207                        RTS    PC                     ;RETURN
9849
9850

```

```

9851
9852 ;*****
9853 ;SBTTL GET PACK ADDRESS ROUTINE
9854 ;*****
9855 046702 016537 000030 001174 GTPKAD: MOV P.DCYL(R5),SREG5 ;GET CYLINDER NUMBER
9856 046710 005037 001176 CLR $REG6 ;CLEAR REGISTERS FOR
9857 046714 005037 001200 CLR $REG7 ;TRACK & SECTOR STORAGE
9858 046720 116537 000026 001200 MOV B P.DTS(R5),SREG7 ;STORE THE TRACK AND SECTOR
9859 046726 116537 000027 001176 MOV B P.DTS+1(R5),SREG6
9860 046734 005737 001200 TST $REG7 ;ADJUST THE ADDRESS CONTAINED IN
9861 ;THE RK REGISTERS FOR THE AUTOMATIC
9862 046740 001403 BEQ 1$ ;INCREMENT
9863 046742 005337 001200 DEC $REG7
9864 046746 000426 BR 5$
9865 046750 032765 010000 000016 1$: BIT #CFMT,P.CS1(R5)
9866 046756 001404 BEQ 2$
9867 046760 012737 000023 001200 MOV #19.,$REG7
9868 046766 000403 BR 3$
9869 046770 012737 000025 001200 2$: MOV #21.,$REG7
9870 046776 005737 001176 3$: TST $REG6
9871 047002 001403 BEQ 4$
9872 047004 005337 001176 DEC $REG6
9873 047010 000405 BR 5$
9874 047012 012737 000002 001176 4$: MOV #2,$REG6
9875 047020 005337 001174 DEC $REG5
9876 047024 000207 5$: RTS PC
9877
9878
9879
9880 ;*****
9881 ;SBTTL BUILD EXPECTED HEADER
9882 ;*USES DESIRED CYLINDER, TRACK AND SECTOR REGISTERS TO DETERMINE
9883 ;*WHICH HEADER WAS EXPECTED. LOADS EXPECTED VALUES IN $REG5, 6, AND
9884 ;*7 FOR REPORTING.
9885 ;*****
9886 047026 104407 BLDEXH: SAVREG
9887 047030 016537 000030 001174 MOV P.DCYL(R5),SREG5 ;CONSTRUCT EXPECTED HDR
9888 047036 016501 000026 MOV P.DTS(R5),R1 ;DESIRED CYLINDER & DESIRED TRACK
9889 047042 042701 174377 BIC #174377,R1 ;CLEAR ALL BUT TRACK BITS
9890 047046 006201 ASR R1 ;AND SECTOR. SHIFT THE TRACK
9891 047050 006201 ASR R1 ;OVER TO CONFORM TO HEADER FORMAT
9892 047052 006201 ASR R1 ;CHECK THE FORMAT BIT AND
9893 ;IF SET, SET THE HEADER FORMAT
9894 047054 016537 000026 001176 MOV P.DTS(R5),SREG6 ;BIT
9895 047062 042737 177740 001176 BIC #177740,$REG6 ;CLEAR ALL BUT SECTOR
9896 047070 060137 001176 ADD R1,$REG6 ;ADD TRACK AND SECTOR TOGETHER
9897 047074 052737 140000 001176 BIS #140000,$REG6 ;INSERT BSE BITS
9898 047102 032765 010000 000016 BIT #CFMT,P.CS1(R5)
9899 047110 001403 BEQ 23$
9900 047112 052737 001000 001176 BIS #1000,$REG6
9901 047120 013737 001174 001200 23$: MOV $REG5,$REG7 ;COMPUTE THE HEADER VRC
9902 047126 013701 001176 MOV $REG6,R1
9903 047132 043737 001176 001200 BIC $REG6,$REG7
9904 047140 043701 001174 BIC $REG5,R1
9905 047144 050137 001200 BIS R1,$REG7
9906 047150 104410 RESREG

```

L15

CZR6NDO RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 194
BUILD EXPECTED HEADER

SEQ 0193

9907 047152 000207
9908

RTS PC

9909
9910
9911
9912
9913
9914
9915
9916
9917
9918
9919
9920
9921
9922
9923
9924
9925
9926
9927
9928
9929
9930
9931
9932
9933
9934
9935
9936
9937
9938
9939
9940
9941
9942
9943
9944
9945
9946
9947
9948
9949
9950

.SBTTL RK611/RK06-RK07 UNIBUS DRIVER FOR SEQUENTIAL OPERATIONS (REV. 0.10)

;*COPYRIGHT (C) 1975,1976,1977
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MA. 01754
;*AUTHOR: ROY SPITZER

.SBTTL *WATCH-DOG TIMER

THE WATCH-DOG TIMER DOES A PSEUDO-TIMING OF RK06-RK07 UNIBUS
SUBSYSTEM COMMAND. SINCE ONE CAN NOT GUARANTEE THAT A
REAL-TIME CLOCK (KW11-P OR KW11-L) IS ON THE SYSTEM
THE RK06-RK07 DRIVER WILL USE THE LOCATION W.MTIM FOR
MILLI-SECOND TIMING. WHEN W.MTIM REACHES ZERO THE
WATCH-DOG TIMER WILL SCAN THE DRIVES IN USE AS
DETERMINED BY THE LOCATION W.TIME. THE TIMER COUNTS
(ONE FOR EACH DRIVE) ARE KEPT IN THE TABLE W.DRV.
IF ANY COUNT IN THE TABLE W.DRV REACHES ZERO A COMMAND
TIME-OUT WILL BE DESIGNATED IN THE PROGRAM DEVICE STATUS
REGISTER OF THAT DRIVE'S PARAMETER BLOCK.

THE DRIVER WILL USE THE LOCATION W.MIN AS THE NUMBER
OF MILLISECONDS FOR AN UNLOAD OR START SPINDLE COMMAND.
THE DRIVER WILL USE THE LOCATION W.SEC AS THE TIME
LIMIT FOR ALL OTHER COMMANDS.

FOR QUEUED OPERATIONS THE WATCH-DOG TIMER WILL
WATCH UP TO 8 OPERATIONS SIMULTEOUSLY. FOR SEQUENTIAL
OPERATIONS ONLY ONE OPERATION WILL BE WATCHED.

*CALL JSR PC,W.WTCH
*RETURN IF NO DRIVE ORDER EXCEEDED ITS TIME LIMIT

OTHERWISE AN ABNORMAL RETURN TO THE ROUTINE ADDRESS
BY LOCATION A.ABNL WILL OCCUR AND THE CMDTO FLAG
IN THE PROGRAM DEVICE STATUS REGISTER OF THE
APPROPRIATE PARAMETER BLOCK WILL BE SET.

9951 047154 010546
9952 047156 010446
9953 047160 010346
9954 047162 010246
9955 047164 013746 177776
9956 047170 005337 003056
9957 047174 001034
9958 047176 013737 003060 003056
9959 047204 105737 003100
9960 047210 001426
9961 047212 013737 003042 177776
9962 047220 013702 003036
9963 047224 005337 003114
9964 047230 001016

W.WTCH: MOV R5,-(SP) ;SAVE R5 ON THE STACK
MOV R4,-(SP) ;SAVE R4 ON THE STACK
MOV R3,-(SP) ;SAVE R3 ON THE STACK
MOV R2,-(SP) ;SAVE R2 ON STACK
MOV PS,-(SP) ;SAVE PROGRAM STATUS WORD ON STACK
DEC W.MTIM ;DECREMENT MILLISECOND TIMER
BNE 20\$;IF NOT ZERO RETURN
MOV W.MILI,W.MTIM ;REINITIALIZE MILLISECOND TIMER
TSTB W.TIME ;CHECK IF DRIVE IS BEING TIMED
BEQ 20\$;NO, RETURN
MOV RKPRI,PS ;LOCK OUT RK06-RK07 INTERRUPTS
MOV RKBAS,R2 ;LOAD BASE OF RK06-RK07 REGISTERS
DEC W.DRV ;DECREMENT COMMAND TIMER
BNE 20\$;RETURN IF NO TIME OUT

9965	047232	105037	003100		CLRB	W.TIME	;RESET TIMING INDICATOR
9966	047236	013705	003112		MOV	PBLKT,R5	;LOAD ADDRESS OF PARAMETER BLOCK
9967							TABLE FOR INDEXING
9968	047242	052765	000100	000014	BIS	#CMDTO,P.PRST(R5)	;SET COMMAND TIME OUT
9969	047250	020537	003054		CMP	R5,O.WAIT	;CHECK IF DRIVER IS WAITING FOR
9970							COMMAND COMPLETION
9971	047254	001002			BNE	5\$;NO, DO NOT ALTER WAITING FOR
9972							COMMAND COMPLETION
9973	047256	005037	003054		CLR	O.WAIT	;CLEAR WAIT FOR COMMAND COMPLETION
9974	047262	004737	052536	5\$:	JSR	PC,R.ABNL	;BRANCH TO ERROR ROUTINE
9975	047266	012637	177776	20\$:	MOV	(SP)+,PS	;RESTORE PSW
9976	047272	012602			MOV	(SP)+,R2	;RESTORE R2
9977	047274	012603			MOV	(SP)+,R3	;RESTORE R3
9978	047276	012604			MOV	(SP)+,R4	;RESTORE R4
9979	047300	012605			MOV	(SP)+,R5	;RESTORE R5
9980	047302	000207			RTS	PC	;RETURN

.SBTTL *RK06 INTERRUPT SERVICE ROUTINE

9981
9982
9983
9984
9985
9986
9987
9988
9989
9990
9991
9992
9993
9994
9995
9996
9997
9998
9999
10000
10001
10002
10003
10004
10005
10006
10007
10008
10009
10010
10011
10012
10013
10014
10015
10016
10017
10018
10019
10020
10021
10022
10023
10024
10025
10026
10027
10028
10029
10030
10031
10032
10033
10034
10035
10036

```

*****
THIS ROUTINE WILL SERVICE ALL RK06 INTERRUPTS.
UPON RECEIVING AN INTERRUPT, THIS ROUTINE WILL
PERFORM ONE OF THE FOLLOWING SERVICES:
1.) SERVICE PORT WAS SEIZED BY OTHER PORT
2.) SERVICE DRIVER IS WAIT FOR COMMAND COMPLETION
3.) SERVICE POSITIONING COMPLETION
4.) REQUEUE COMMAND IF DRIVE WAS RELEASED
   FOR THE QUEUED RK06 DRIVER.
5.) IF NO SERVICE IS REQUIRED, THE COMMAND WILL BE ISSUED
   FOR THE QUEUED RK06 DRIVER.

THREE LINKS ARE PROVIDED TO THE DRIVING PROGRAM.
THEY ARE:
1.) A.NORM ADDRESS OF NORMAL RETURN (SUCESSFUL COMPLETION OF COMMAND)
2.) A.ABNL ADDRESS OF ABNORMAL RETURN (UNSUCESSFUL COMPLETION OF COMMAND)
3.) A.CONT ADDRESS OF CONTROL ERROR RETURN

FOR NORMAL AND ABNORMAL RETURNS, THE ADDRESS OF THE APPROPRIATE
PARAMETER BLOCK WILL BE IN R5.

FOR THE CONTROLLER ERROR RETURN, THE LOCATION E.CONT CONTAINS
THE REASON FOR THE CONTROLLER ERROR.

ROUTINES USED:
   C.OPT (QUEUED ONLY)
   Q.PUSH (QUEUED ONLY)
   Q.RMOV (QUEUED ONLY)
   R.CONT (SEQUENTIAL ONLY)
   R.NORM (SEQUENTIAL ONLY)
   R.ABNL (SEQUENTIAL ONLY)
   I.CSTS
   I.STAT
   I.ISSU
   I.CCLR
*****

```

```

047304 010546
047306 010446
047310 010346
047312 010246
047314 010146
047316 010046
047320 013702 003036
047324 016237 000010 003002
047332 032737 001000 003002
047340 001407
047342 052737 100000 003052
047350 004737 052562

```

```

I.INTR: MOV R5, -(SP) ;STORE R5 ON THE STACK
        MOV R4, -(SP) ;STORE R4 ON THE STACK
        MOV R3, -(SP) ;STORE R3 ON THE STACK
        MOV R2, -(SP) ;STORE R2 ON THE STACK
        MOV R1, -(SP) ;STORE R1 ON THE STACK
        MOV R0, -(SP) ;STORE R0 ON THE STACK
        MOV RKBAS, R2 ;LOAD R2 TO ADDRESS RK06 REGISTER
        MOV RKCS2(R2), T.CS2 ;STORE CS2
        BIT #MDS, T.CS2 ;CHECK IF MULTIPLE DRIVE SELECT
        BEQ 1$ ;NO, CONTINUE PROCESSING
        BIS #E.MDS, E.CONT ;SET MULTIPLE DRIVE SELECT
        JSR PC, R.CONT ;REPORT ERROR

```

```

10037 047354 000137 051534          JMP      I.RTRN          ;RETURN
10038
10039 047360 105737 003074          1$:    TSTB      I.ISRL          ;CHECK IF INTERRUPT OR RELEASE
10040 047364 001410                2EQ    6$                ;NO, CHECK IF DRIVE AVAILABLE
10041 047366 100403                BMI     5$                ;CHECK IF RELEASE COMMAND
10042 047370 105037 003074          CLRB   I.ISRL          ;YES, CLEAR FLAG
10043 047374 000473                BR     I.ICO             ;CONTINUE PROCESSING INTERRUPT
10044
10045 047376 105037 003074          5$:    CLRB   I.ISRL          ;CLEAR FLAG
10046 047402 000137 050516          JMP     I.ATTN          ;GO PROCESS DRIVE ATTENTIONS
10047
10048 047406 032737 010400 003002 6$:    BIT     #NED!UFE,T.CS2    ;CHECK FOR NON-EXISTENT DRIVE OR
10049                                UNIT FIELD ERROR
10050 047414 001413                BEQ    7$                ;NO, WAIT FOR DUAL ACCESS INTERRUPT
10051 047416 013704 003002          MOV    T.CS2,R4        ;LOAD R4 FOR DRIVE NUMBER
10052 047422 042704 177770          BIC    #1C<DRVMSK>,R4  ;KEEP DRIVE BITS
10053 047426 013705 003112          MOV    PBLKT,R5        ;STORE PARAMETER BLOCK ADDRESS
10054 047432 016237 000000 003000    MOV    RKCS1(R2),T.CS1 ;LOAD TEMPORARY CS1 FOR STATUS REPORT
10055 047440 000137 047726          JMP     I.ERRC          ;REPORT ERROR
10056
10057 047444 016237 000012 003020 7$:    MOV    RKDS(R2),T.D5    ;STORE STATUS REGISTER FOR COMPARISON
10058 047452 032737 000001 003020    BIT    #DRA,T.D5        ;CHECK IF DRIVE SEIZED BY OTHER
10059                                PORT
10060 047460 001041                BNE    I.I00            ;NO, CONTINUE PROCESSING INTERRUPT
10061
10062                                ;CHECK IF ANY DATA TRANSFER ERROR EXISTS
10063 047462 032737 164000 003002    BIT    #DLT!WCE!UPE!NEM,T.CS2
10064
10065 047470 001007                BNE    10$              ;INDICATE ERROR
10066 047472 016237 000014 003016    MOV    RKER(R2),T.ER    ;STORE ERROR REGISTER
10067
10068                                ;CHECK FOR DATA TRANSFER ERROR TYPE ERROR
10069 047500 032737 125700 003016    BIT    #DCK!OPI!WLE!COE!HVRC!BSE!ECH,T.ER
10070
10071 047506 001407                BEQ    11$              ;NO, WAIT FOR RELEASE OF RK06 DRIVE
10072
10073 047510 052737 000010 003052 10$:   BIS    #E.UDAT,E.CONT    ;SET UNEXPECTED DATA TYPE ERROR
10074 047516 004737 052562          JSR    PC.R.CONT        ;REPORT ERROR
10075 047522 000137 051534          JMP    I.RTRN          ;RESTORE REGISTERS
10076
10077 047526 105037 003100          11$:   CLRB   W.TIME          ;RESET TIMING ON THIS DRIVE
10078 047532 005037 003114          CLR    W.DRV           ;CLEAR TIMING COUNT FOR THIS DRIVE
10079 047536 013705 003112          MOV    PBLKT,R5        ;LOAD R5 WITH PARAMETER BLOCK
10080                                ADDRESS
10081 047542 052765 010000 000014    BIS    #DRVSZD,P.PRST(R5) ;SET DRIVE SEIZED IN THE
10082                                PROGRAM DRIVE STATUS REGISTER
10083 047550 005037 003054          CLR    0.WAIT          ;CLEAR WAIT FOR COMMAND COMPLETION
10084 047554 004737 052536          JSR    PC.R.ABNL        ;INDICATE ABNORMAL TERMINATION
10085 047560 000137 051534          JMP    I.RTRN          ;GO RESTORE REGISTERS
10086
10087 047564 013705 003054          I.I00: MOV    0.WAIT,R5        ;LOAD PARAMETER BLOCK ADDRESS INTO R5
10088 047570 001002                BNE    2$                ;IS COMMAND WAITING PROCESSING
10089                                YES, DO PROCESSING
10090 047572 000137 050516          JMP    I.ATTN          ;NO, PROCESS ATTENTION
10091
10092 047576 013704 003002          2$:    MOV    T.CS2,R4        ;STORE RKCS2 FOR DRIVE NUMBER

```

10093	047602	042704	177770			BIC	#↑C<DRVMSK>,R4	;MASK OUT UNNECESSARY BITS
10094								
10095								
10096	047606	126504	000000			CMPB	P.DRVN(R5),R4	;CHECK IF DRIVE NUMBER IS EXPECTED
10097	047612	001401				BEQ	3\$;YES, CONTINUE
10098	047614	000000				HALT		;NO, DRIVER ERROR
10099	047616	122765	000164	000001	3\$:	CMPB	#RDALHD,P.CMND(R5)	;CHECK IF READ ALL HEADERS
10100	047624	001002				BNE	10\$;NO, EXECUTE NORMAL DATA TRANSFER
10101	047626	000137	050164			JMP	I.HDAL	;GO EXECUTE SPECIAL HEADER SEQUENCE
10102								
10103	047632	005037	003054		10\$:	CLR	O.WAIT	;CLEAR WAIT FOR COMMAND COMPLETION
10104	047636	005037	003114			CLR	W.DRV	;CLEAR WATCH-DOG TIME
10105	047642	105037	003100			CLRB	W.TIME	;RESET TIMING ON THIS DRIVE
10106	047646	016237	000000	003000		MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REGISTER 1
10107	047654	032737	100000	003000		BIT	#CERR,T.CS1	;CHECK IF CONTROLLER ERROR
10108	047662	001021				BNE	I.ERRC	;YES, PROCESS ERROR
10109	047664	016237	000016	003014		MOV	RKASOF(R2),T.ASOF	;STORE ATTENTION SUMMARY
10110	047672	133737	003101	003015		BITB	INTMSK,T.ASOF+1	;CHECK IF DRIVE ATTENTION SET
10111	047700	001004				BNE	15\$;YES, REPORT ERROR
10112	047702	004737	052550			JSR	PC.R.NORM	;INDICATE NORMAL RETURN
10113	047706	000137	051534			JMP	I.RTRN	;RESTORE REGISTERS
10114								
10115	047712	052765	000010	000014	15\$:	BIS	#UEXATT,P.PRST(R5)	;SET UNEXPECTED ATTENTION
10116								
10117	047720	004737	052204		I.ERRA:	JSR	PC.I.CST5	;STORE CONTROLLER STATUS
10118	047724	000405				BR	I.ERR	;STORE PATTERN AND POSITION INFORMATION
10119								
10120	047726	013765	003000	000016	I.ERRC:	MOV	T.CS1,P.CS1(R5)	;GET ERROR RKCS1
10121	047734	004737	052226			JSR	PC.I.CST1	;GET REST OF CONTROLLER STATUS
10122	047740	016265	000032	000062	I.ERR:	MOV	RKECPT(R2),P.EPAT(R5)	;STORE ECC PATTERN
10123	047746	016265	000030	000060		MOV	RKECPS(R2),P.EPOS(R5)	;STORE ECC POSITION
10124	047754	004037	051552			JSR	RD,I.CCLR	;CLEAR CONTROLLER
10125	047760	051534				I.RTRN		;ERROR RETURN
10126	047762	032765	010400	000020		BIT	#NED!UFE,P.CS2(R5)	;CHECK IF IT WAS NON-EXISTENT DRIVE OR
10127								;UNIT FIELD ERROR
10128	047770	001046				BNE	5\$;YES, REPORT ERROR
10129	047772	004037	052310			JSR	RD,I.STAT	;GATHER DRIVE STATUS
10130	047776	051534				I.RTRN		;ERROR RETURN
10131	050000	112737	000005	003000		MOVB	#DR.CLR,T.CS1	;LOAD COMMAND
10132	050006	004037	051634			JSR	RD,I.ISSU	;ISSUE DRIVE CLEAR
10133	050012	051534				I.RTRN		;ERROR RETURN
10134	050014	133737	003101	003015		BITB	INTMSK,T.ASOF+1	;CHECK IF ATTENTION RESET
10135	050022	001407				BEQ	2\$;NO, INDICATE DRIVE ERROR
10136	050024	052737	000020	003052		BIS	#E.CLAT,E.CONT	;SET ATTENTION DID NOT RESET
10137								;WITH CLEAR
10138	050032	004737	052562			JSR	PC.R.CONT	;REPORT CONTROLLER ERROR
10139	050036	000137	051534			JMP	I.RTRN	;GO RESTORE REGISTERS
10140								
10141	050042	032737	040000	003024	2\$:	BIT	#S.DSC,T.MR2	;CHECK IF DRIVE STATUS CHANGE CLEARED
10142	050050	001403				BEQ	3\$;YES, CHECK FAULT
10143	050052	052765	000040	000014		BIS	#DRVDSC,P.PRST(R5)	;SET DSC DID NOT CLEAR
10144	050060	032737	001000	003026	3\$:	BIT	#S.PAR,T.MR3	;CHECK IF DRIVE PARITY ERROR
10145	050066	001407				BEQ	5\$;NO, INDICATE ABNORMAL TERMINATION
10146	050070	052737	002000	003052		BIS	#E.DPAR,E.CONT	;SET DRIVE PARITY ERROR
10147	050076	004737	052562			JSR	PC.R.CONT	;INDICATE CONTROLLER ERROR
10148	050102	000137	051534			JMP	I.RTRN	;RETURN


```

10149
10150 050106 032765 000020 000014 5$: BIT #DRVHRD,P.PRST(R5) ;CHECK IF HARD DRIVE ERROR
10151 050114 001017 BNE 10$ ;YES, GO REPORT ERROR
10152 050116 032737 020000 003024 BIT #S.PIP,T.MR2 ;CHECK IF DRIVE IS CYCLING DOWN
10153 050124 001413 BEQ 10$ ;NO, REPORT ERROR
10154 050126 052765 020000 000014 BIS #E.UNLD,P.PRST(R5) ;SET DRIVE UNLOADING
10155 050134 113737 003101 003100 MOVB INTMSK,W.TIME ;SET UP 8 SECONDS FOR DRIVE TO CYCLE UP
10156 050142 013737 003064 003114 MOV W.8SEC,W.DRV
10157 050150 000137 051534 JMP I.RTRN ;GO RESTORE REGISTERS
10158
10159 050154 004737 052536 10$: JSR PC,R.ABNL ;GO REPORT ERROR
10160 050160 000137 051534 JMP I.RTRN ;GO RESTORE REGISTERS
10161
10162 .SBTTL *READ ALL HEADERS INTERRUPT SEQUENCE
10163
10164 050164 016237 000000 003000 I.HDAL: MOV RKCS1(R2),T.CS1 ;STORE CS1 TO CHECK CONTROLLER
10165 ; ERROR
10166 050172 032737 100000 003000 BIT #CERR,T.CS1 ;CHECK IF CONTROLLER ERROR
10167 050200 001422 BEQ 5$ ;NO, CHECK FOR ATTENTION
10168
10169 050202 005037 003054 CLR O.WAIT ;CLEAR WAITING FOR COMMAND COMPLETE
10170 050206 105037 003100 CLR W.TIME ;RESET TIMING ON DRIVE
10171 050212 005037 003114 CLR W.DRV ;CLEAR TIME OUT COUNT
10172 050216 013765 003000 000016 MOV T.CS1,P.CS1(R5) ;STORE ERROR RKCS1
10173 050224 004737 052226 JSR PC,I.CST1 ;STORE CONTROLLER REGISTERS
10174 050230 004037 051552 JSR RO,I.CCLR ;CLEAR CONTROLLER
10175 050234 051534 I.RTRN ;ERROR RETURN
10176 050236 004737 052536 JSR PC,R.ABNL ;INDICATE ERROR RETURN
10177 050242 000137 051534 JMP I.RTRN ;RESTORE REGISTERS
10178
10179 050246 016237 000016 003014 5$: MOV RKASOF(R2),T.ASOF ;STORE ATTENTION SUMMARY
10180 050254 133737 003101 003015 BITB INTMSK,T.ASOF+1 ;CHECK IF DRIVE ATTENTION IS SET
10181 050262 001410 BEQ 7$ ;NO, CHECK IF READ ALL HEADERS
10182 050264 005037 003054 CLR O.WAIT ;CLEAR WAITING FOR COMMAND COMPLETION
10183 050270 105037 003100 CLR W.TIME ;RESET TIMING ON DRIVE
10184 050274 005037 003114 CLR W.DRV ;CLEAR TIME OUT COUNT
10185 050300 000137 047720 JMP I.ERRA ;GO REPORT ERROR
10186
10187 050304 013701 003070 7$: MOV HDR.AD,R1 ;GET MAIN MEMORY ADDRESS
10188 050310 016221 000024 MOV RKDB(R2),(R1)+ ;GET FIRST WORD OF HEADER
10189 050314 016221 000024 MOV RKDB(R2),(R1)+ ;GET SECOND WORD OF HEADER
10190 050320 016221 000024 MOV RKDB(R2),(R1)+ ;GET THIRD WORD OF HEADER
10191 050324 010137 003070 MOV R1,HDR.AD ;STORE ADDRESS FOR NEXT HEADER
10192 050330 016237 000010 003002 MOV RKCS2(R2),T.CS2 ;STORE CS2 TO CHECK FOR DATA LATE
10193 050336 032737 100000 003002 BIT #DLT,T.CS2 ;CHECK FOR DATA LATE
10194 050344 001055 BNE 35$ ;YES, REPORT ERROR
10195 050346 005337 003072 DEC HDR.CT ;DECREMENT NUMBER OF HEADER YET TO READ
10196 050352 001026 BNE 25$ ;IF NON-ZERO, GO ISSUE NEXT READ HEADER
10197 050354 005037 003054 CLR O.WAIT ;CLEAR DRIVER WAITING FOR COMMAND COMPLETION
10198 050360 005037 003114 CLR W.DRV ;CLEAR TIME OUT COUNT FOR THIS DRIVE
10199 050364 105037 003100 CLR W.TIME ;CLEAR WATCH DOG TIME ON THIS DRIVE
10200 050370 012762 000003 000026 MOV #3,RKMR1(R2) ;LOAD MAINTENANCE REGISTER FOR SECTOR COUNT
10201 050376 112737 000001 003000 MOVB #DR.SEL,T.CS1 ;LOAD SELECT COMMAND
10202 050404 004037 051634 JSR RO,I.ISSU ;GET SECTOR COUNT
10203 050410 051534 I.RTRN ;ERROR RETURN
10204 050412 013765 003026 000056 MOV T.MR3,P.B11(R5) ;LOAD SECTOR COUNT

```

```

10205 050420 004737 052550      JSR    PC.R.NORM      ;INDICATE NORMAL TERMINATION
10206 050424 000137 051534      JMP    I.RTRN        ;RESTORE REGISTERS
10207
10208 050430 016562 000002 000020 25$:  MOV    P.CYLN(R5),RKDCYL(R2) ;LOAD CYLINDER ADDRESS REGISTER
10209 050436 016562 000004 000006      MOV    P.SECT(R5),RKDA(R2) ;LOAD SECTOR AND TRACK
10210 050444 116565 000007 000017      MOVVB  P.CS1H(R5),P.CS1+1(R5) ;STORE BITS 8-15 OF CS1
10211 050452 042765 165777 000016      BIC    #↑C<CDT!CFMT>,P.CS1(R5) ;CLEAR ALL BITS EXCEPT FORMAT AND
10212                                     ; DRIVE TYPE
10213 050460 112765 000125 000016      MOVVB  #RDHEAD,P.CS1(R5) ;STORE COMMAND ISSUED
10214 050466 016562 000016 000000      MOV    P.CS1(R5),RKCS1(R2) ;ISSUE READ HEADER
10215 050474 000137 051534      JMP    I.RTRN        ;RESTORE REGISTERS
10216
10217 050500 052737 000400 003052 35$:  BIS    #E.DLT,E.CONT    ;SET DATA LATE WHILE UNLOADING HEADER
10218 050506 004737 052562      JSR    PC.R.CONT      ;REPORT ERROR
10219 050512 000137 051534      JMP    I.RTRN        ;RESTORE REGISTERS
10220
10221                                     .SBTTL  *DRIVE ATTENTION SCANNER
10222
10223 050516 016237 000000 003000  I.ATTN: MOV    RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS
10224                                     ; REGISTER 1 FOR COMPARISON
10225 050524 032737 100000 003000      BIT    #CERR,T.CS1    ;CHECK IF CONTROLLER ERROR OCCURRED
10226 050532 001441                                     BEQ    5$             ;NO, CHECK IF ATTENTION
10227                                     ;CHECK IF ANY DATA TRANSFER TYPE ERROR EXISTS
10228                                     BIT    #DLT!WCE!UPE!NEM,T.CS2
10229 050534 032737 164000 003002
10230
10231 050542 001007                                     BNE    1$             ;INDICATE ERROR
10232 050544 016237 000014 003016      MOV    RKER(R2),T.ER  ;STORE ERROR REGISTER
10233
10234                                     ; CHECK FOR DATA TRANSFER ERROR TYPE
10235 050552 032737 125700 003016      BIT    #DCK!OPI!WLE!COE!HVRC!BSE!ECH,T.ER
10236
10237 050560 001407                                     BEQ    2$             ;NO DATA TRANSFER ERROR
10238
10239 050562 052737 000010 003052 1$:  BIS    #E.UDAT,E.CONT  ;SET UNEXPECTED DATA TYPE ERROR
10240 050570 004737 052562      JSR    PC.R.CONT      ;REPORT ERROR
10241 050574 000137 051534      JMP    I.RTRN        ;RESTORE REGISTERS
10242
10243 050600 013704 003002 2$:  MOV    T.CS2,R4       ;SAVE CS2 FOR REGISTER NUMBER
10244 050604 042704 177770      BIC    #↑C<DRVMSK>,R4 ;STRIP OFF JUNK
10245 050610 105037 003100      CLR    W.TIME        ;CLEAR WATCH DOG TIMER
10246 050614 005037 003114      CLR    W.DRV         ;RESET TIMER VALUE
10247 050620 013705 003112      MOV    PBLKT,R5      ;STORE PARAMETER BLOCK ADDRESS IN R5
10248
10249                                     ; CLEAR DRIVE POSITIONING AND DRIVE POSITIONED FOR DATA TRANSFER
10250                                     ; IN PROGRAM DEVICE STATUS REGISTER
10251 050624 042765 000006 000014      BIC    #DRVPOS!DRVPDT,P.PRST(R5)
10252
10253 050632 000137 047726      JMP    I.ERRC        ;GO REPORT ERROR
10254
10255 050636 032737 040000 003000 5$:  BIT    #DI,T.CS1     ;CHECK IF ANY DRIVE ATTENTION
10256 050644 001002                                     BNE    6$             ;YES, PROCESS INTERRUPT
10257 050646 000137 051534      JMP    I.RTRN        ;RESTORE REGISTERS
10258
10259 050652 016237 000016 003014 6$:  MOV    RKASOF(R2),T.ASOF ;STORE ATTENTION SUMMARY
10260 050660 105737 003015      TSTB   T.ASOF+1      ;CHECK IF ANY ATTENTIONS SET

```



```

10317 .SBTTL *ATTENTION ERROR HANDLER
10318
10319 051166 042765 000004 000014 I.AERR: BIC #DRV PDT,P.PRST(R5) ;RESET POSITIONING IN PROGRESS BECAUSE
10320 ; OF DATA TRANSFER
10321 051174 105037 003100 CLR W.TIME ;CLEAR TIMING FOR THIS DRIVE
10322 051200 005037 003114 CLR W.DRV ;RESET WATCH-DOG TIME
10323 051204 042765 177741 000016 BIC #177741,P.CS1(R5) ;KEEP COMMAND ISSUED
10324 051212 042737 000036 003000 BIC #36,T.CS1 ;KEEP CURRENT CONTRGLR STATUS
10325 051220 053765 003000 000016 BIS T.CS1,P.CS1(R5) ;MAKE GOOD MESSAGE
10326 051226 013765 003002 000020 MOV T.CS2,P.CS2(R5) ;STORE CONTROLLER REGISTERS
10327 051234 013765 003004 000022 MOV T.WCR,P.WCR(R5)
10328 051242 013765 003006 000024 MOV T.BA,P.BAR(R5)
10329 051250 013765 003010 000026 MOV T.DA,P.DTS(R5)
10330 051256 013765 003012 000030 MOV T.DC,P.DCYL(R5)
10331 051264 013765 003014 000032 MOV T.ASOF,P.ASOF(R5)
10332 051272 013765 003016 000034 MOV T.ER,P.ER(R5)
10333 051300 013765 003020 000036 MOV T.DS,P.DS(R5)
10334 051306 004037 052310 JSR RO,I.STAT ;GATHER DRIVE STATUS
10335 051312 051534 I.RTRN ;ERROR RETURN
10336 051314 112737 000005 003000 MOVB #DR.CLR,T.CS1 ;LOAD COMMAND
10337 051322 004037 051634 JSR RO,I.ISSU ;CLEAR DRIVE ERRORS
10338 051326 051534 I.RTRN ;ERROR RETURN
10339 051330 133737 003101 003015 BITB INTMSK,T.ASOF+1 ;CHECK IF ATTENTION RESET
10340 051336 001407 BEQ 2$ ;YES, FLAG DRIVE ERROR
10341 051340 052737 000020 003052 BIS #E.CLAT,E.CONT ;SET ATTENTION DID NOT RESET
10342 051346 004737 052562 JSR PC.R.CONT ;REPORT ERROR
10343 051352 000137 051534 JMP I.RTRN ;RESTORE REGISTERS
10344
10345 051356 032765 000020 000014 2$: BIT #DRVHRD,P.PRST(R5) ;CHECK IF AHARD DRIVE ERROR
10346 051364 001017 BNE 10$ ;YES, REPORT ERROR
10347 051366 032737 020000 003024 BIT #S.PIP,T.MR2 ;CHECK IF DRIVE IS UNLOADING
10348 051374 001413 BEQ 10$ ;NO, REPORT ERROR
10349 051376 052765 020000 000014 BIS #E.UNLD,P.PRST(R5) ;SET DRIVE UNLOADING DUE TO ERROR
10350 051404 113737 003101 003100 MOVB INTMSK,W.TIME ;SET TIMING ON THIS DRIVE
10351 051412 013737 003064 003114 MOV W.BSEC,W.DRV ;LOAD 8 SECONDS FOR CYCLE UP TIME
10352 051420 000137 051534 JMP I.RTRN ;RESTORE REGISTERS
10353
10354 051424 004737 052536 10$: JSR PC.R.ABNL ;REPORT ERROR
10355 051430 000137 051534 JMP I.RTRN ;RESTORE REGISTERS
10356
10357 .SBTTL *ERROR CAUSING DRIVE TO UNLOAD
10358
10359 051434 052765 020000 000014 I.UNLD: BIS #E.UNLD,P.PRST(R5) ;CLEAR DRIVE UNLOADING BECAUSE OF ERROR
10360 051442 112737 000005 003000 MOVB #DR.CLR,T.CS1 ;LOAD IN DRIVE CLEAR
10361 051450 004037 051634 JSR RO,I.ISSU ;GO ISSUE DRIVE CLEAR
10362 051454 051534 I.RTRN ;ERROR RETURN
10363 051456 136437 003101 003015 BITB INTMSK(R4),T.ASOF+1 ;CHECK IF ATTENTION CLEARED
10364 051464 001406 BEQ 15$ ;YES, CONTINUE
10365 051466 012737 000020 003052 MOV #E.CLAT,E.CONT ;SET ATTENTION DID NOT RESET
10366 051474 004737 052562 JSR PC.R.CONT ;REPORT ERROR
10367 051500 000415 BR I.RTRN ;RESTORE REGISTERS
10368
10369 051502 032737 040000 003024 15$: BIT #S.DSC,T.MR2 ;CHECK IF DRIVE STAUUS CHANGE RESET
10370 051510 001403 BEQ 20$ ;YES, CONTINUE
10371 051512 052765 000040 000014 BIS #DRVDSC,P.PRST(R5) ;SET DRIVE STAUUS CHANGE DID NOT CLEAR
10372 051520 105037 003100 20$: CLRB W.TIME ;RESET TIMING ON THIS DRIVE

```

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 204
*ERROR CAUSING DRIVE TO UNLOAD

SEQ 0203

10373	051524	005037	003114	CLR	W.DRV	;CLEAR TIME COUNT
10374	051530	004737	052536	JSR	PC,R.ABNL	;REPORT ERROR
10375						
10376	051534	012600		I.RTRN: MOV	(SP)+,R0	;RESTORE R0
10377	051536	012601		MOV	(SP)+,R1	;RESTORE R1
10378	051540	012602		MOV	(SP)+,R2	;RESTORE R2
10379	051542	012603		MOV	(SP)+,R3	;RESTORE R3
10380	051544	012604		MOV	(SP)+,R4	;RESTORE R4
10381	051546	012605		MOV	(SP)+,R5	;RESTORE R5
10382	051550	000002		RTI		;RETURN
10383						

.SBTTL *CONTROLLER CLEAR ROUTINE

```

*****
*
* THIS ROUTINE WILL BE USED BY THE DRIVER TO CLEAR THE CONTROLLER
* AND CHECK IF THE CONTROLLER ERRORS ARE RESET. IF THE ERROR IS NOT
* CLEARED, THE ROUTINE AS SPECIFIED IN A.CONT WILL BE CALLED WITH
* E.CCLR SET IN E.CONT.
*
* REGISTER      USE
* -----      ---
*
* R2            ADDRESS OF RK06 REGISTERS
* R5            ADDRESS OF PARAMETER BLOCK
*
*CALL JSR      RD,I.CCLR
* <ADDRESS OF ERROR RETURN>
* RETURN
*****

```

```

10384
10385
10386
10387
10388
10389
10390
10391
10392
10393
10394
10395
10396
10397
10398
10399
10400
10401
10402
10403
10404
10405 051552 012762 100000 000000
10406 051560 016237 000000 003000
10407 051566 032737 100000 003000
10408
10409 051574 001407
10410 051576 052737 000001 003052
10411 051604 004737 052562
10412 051610 011000
10413 051612 000200
10414
10415 051614 012762 000100 000000
10416 051622 112737 177777 003074
10417 051630 005720
10418 051632 000200

```

```

I.CCLR: MOV #CCLR,RKCS1(R2) ;CLEAR CONTROLLER
MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REGISTER 1
BIT #CERR,T.CS1 ;CHECK IF CONTROLLER CLEAR DID
; CLEAR ERROR
BEQ SS ;YES, RETURN TO DRIVER PROCESSING
BIS #E.CCLR,E.CONT ;SET CLEAR CONTROLLER DID NOT CLEAR ERROR
JSR PC,R.CONT ;REPORT CONTROLLER ERROR
MOV (R0),R0 ;SET UP ERROR RETURN
RTS R0 ;RETURN

SS: MOV #IE,RKCS1(R2) ;SET INTERRUPT ENABLE
MOVB #-1,I.ISRL ;SET INTERRUPT ENABLE ISSUED
TST (R0)+ ;ADJUST FOR NORMAL RETURN
RTS R0 ;RETURN

```

.SBTTL *COMMAND ISSUED BY DRIVER SERVICE ROUTINE

```

*****
THIS ROUTINE WILL ISSUE THE COMMAND AS SPECIFIED IN T.CS1
AND CHECK IF A CONTROLLER ERROR OCCURRED. IF A CONTROLLER
ERROR OCCURRED, E.CERR WILL BE SET IN E.CONT AND
CONTROL WILL BE TURN OVER TO THE ROUTINE SPECIFIED BY THE
ADDRESS IN A.CONT.

REGISTER      USE
-----      ---

R2             ADDRESS OF RK06 REGISTERS
R5             ADDRESS OF PARAMETER BLOCK

*CALL JSR      RO,I.ISSU
      <ADDRESS OF ERROR RETURN>
      RETURN

ROUTINES USED:
-----

      I.CCLR
      I.STOR
*****

```

10419
10420
10421
10422
10423
10424
10425
10426
10427
10428
10429
10430
10431
10432
10433
10434
10435
10436
10437
10438
10439
10440
10441
10442
10443
10444
10445
10446
10447
10448
10449
10450
10451
10452
10453
10454
10455
10456
10457
10458
10459
10460
10461
10462
10463
10464
10465
10466
10467
10468
10469
10470
10471
10472
10473
10474

```

051634 013746 003000
051640 005037 003002
051644 116537 000000 003002
051652 013762 003002 000010
051660 116537 000007 003001
051666 142737 177753 003001

051674 013762 003000 000000
051702 105762 000000
051706 100375
051710 004737 052056
051714 032737 100000 003000
051722 001437
051724 032737 001000 003002
051732 001406
051734 052737 100000 003052
051742 004737 052562
051746 000440

051750 032737 024000 003000 2$:
051756 001027
051760 032737 176400 003002
051766 001023
051770 032737 131761 003016
051776 001017

052000 122716 000005

```

```

I.ISSU: MOV      T.CS1,-(SP)      ;STORE COMMAND ISSUED
        CLR      T.CS2          ;CLEAR TEMPORARY CS2
        MOVB     P.DRVN(R5),T.CS2 ;LOAD IN DRIVE NUMBER
        MOV      T.CS2,RKCS2(R2) ;LOAD DRIVE NUMBER FOR COMMAND
        MOVB     P.CS1H(R5),T.CS1+1 ;STORE BITS 8-15 OF CS1
        BICB     #↑C<B.CDT!B.CFMT>,T.CS1+1 ;CLEAR ALL BITS EXCEPT
        ;FORMAT AND DRIVE TYPE
1$:     MOV      T.CS1,RKCS1(R2) ;ISSUE COMMAND
        TSTB     RKCS1(R2)      ;WAIT FOR READY
        BPL     1$
        JSR      PC,I.STOR      ;GO STORE REGISTERS
        BIT      #CERR,T.CS1    ;CHECK IF CONTROLLER ERROR OCCURED
        BEQ     5$              ;NO, RETURN
        BIT      #MDS,T.CS2     ;CHECK IF MULTIPLE DRIVE SELECT
        BEQ     2$              ;NO, CHECK FOR OTHER CONTROLLER ERRORS
        BIS      #E.MDS,E.CONT  ;SET MULTIPLE DRIVE SELECT FLAG
        JSR      PC,R.CONT      ;REPORT CONTROLLER ERROR
        BR      10$            ;RETURN

;CHECK IF ANY CONTROLLER ERROR IS SET
2$:     BIT      #CTO!SPAR,T.CS1
        BNE     7$
        BIT      #UFE!PGE!NEM!NED!UPE!WCE!DLT,T.CS2
        BNE     7$
        BIT      #ILC!DTYE!FMTE!ECH!BSE!HVRC!COE!DTE!OPI!DCK,T.ER
        BNE     7$

CMPB     #DR.CLR,(SP) ;CHECK IF CLEAR DRIVE

```

CZR6NDO RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 207
*COMMAND ISSUED BY DRIVER SERVICE ROUTINE

SEQ 0206

10475	052004	001003				BNE	3\$:NO, DO NOT SET DRIVE HARD ERROR
10476	052006	052765	000020	000014		BIS	#DRVHDD,P.PRST(R5)	;SET HARD DRIVE ERROR
10477	052014	004037	051552		3\$:	JSR	RO,I.CCLR	;GO ISSUE A CONTROLLER CLEAR
10478	052020	052050				10\$;ERROR RETURN
10479	052022	012762	000100	000000	5\$:	MOV	#IE,RKCSI(R2)	;SET INTERRUPT ENABLE
10480	052030	005726				TST	(SP)+	;ADJUST STACK
10481	052032	005720				TST	(RO)+	;ADJUST RO FOR NORMAL RETURN
10482	052034	000200				RTS	RO	;RETURN
10483								
10484	052036	052737	001000	003052	7\$:	BIS	#E.CERR,E.CONT	;SET CONTROLLER ERROR DURING
10485								;DRIVER SERVICING
10486	052044	004737	052562			JSR	PC,R.CONT	;REPORT ERROR
10487	052050	005726			10\$:	TST	(SP)+	;ADJUST STACK
10488	052052	011000				MOV	(RO),RO	;ADJUST RO FOR ERROR RETURN
10489	052054	000200				RTS	RO	;RETURN

.SBTTL *STORE RK611 UNIBUS REGISTERS

```

*****
*
* THIS SUBROUTINE IS CALLED BY THE RK06 DRIVER TO STORE ALL
* RK611 REGISTER IN TEMPORARY LOCATIONS.
*
*CALL JSR PC,I.STOR
* RETURN
*
* REGISTER USE
* -----
*
* R2 ADDRESS OF RK611 REGISTERS
*
*****

```

```

10490
10491
10492
10493
10494
10495
10496
10497
10498
10499
10500
10501
10502
10503
10504
10505
10506
10507 052056 016237 000000 003000
10508 052064 016237 000010 003002
10509 052072 016237 000002 003004
10510 052100 016237 000004 003006
10511 052106 016237 000006 003010
10512 052114 016237 000012 003020
10513 052122 016237 000014 003016
10514 052130 016237 000016 003014
10515 052136 016237 000020 003012
10516 052144 016237 000026 003022
10517 052152 016237 000034 003024
10518 052160 016237 000036 003026
10519 052166 016237 000030 003030
10520 052174 016237 000032 003032
10521 052202 000207

```

```

I.STOR: MOV RKCS1(R2),T.CS1 ;STORE ALL CONTROLLER REGISTERS
        MOV RKCS2(R2),T.CS2 ; EXCEPT DATA BUFFER
        MOV RKWC(R2),T.WCR
        MOV RKBA(R2),T.BA
        MOV RKDA(R2),T.DA
        MOV RKDS(R2),T.DS
        MOV RKER(R2),T.ER
        MOV RKASOF(R2),T.ASOF
        MOV RKDCYL(R2),T.DC
        MOV RKMR1(R2),T.MR1
        MOV RKMR2(R2),T.MR2
        MOV RKMR3(R2),T.MR3
        MOV RKECPS(R2),T.POS
        MOV RKECPT(R2),T.PAT
        RTS PC ;RETURN

```

10522
10523
10524
10525
10526
10527
10528
10529
10530
10531
10532
10533
10534
10535
10536
10537
10538
10539
10540
10541
10542
10543
10544
10545
10546
10547
10548
10549
10550
10551
10552
10553
10554
10555
10556
10557
10558
10559
10560
10561
10562
10563
10564
10565
10566

.SBTTL *STORE CONTROLLER STATUS

THIS SUBROUTINE IS CALLED BY THE RK06 DRIVER AT PRIORITY 7.
THE FOLLOWING REGISTERS WILL BE STORED:

- COMMAND AND STATUS REGISTER 2
- WORD COUNT REGISTER
- BUS ADDRESS REGISTER
- DESIRED TRACK AND SECTOR
- STATUS REGISTER
- ERROR REGISTER
- ATTENTION SUMMARY/OFFSET REGISTER
- CYLINDER ADDRESS REGISTER

*CALL JSR PC, I.CSTS
*RETURN

THIS ROUTINE ASSUMES THE FOLLOWING REGISTERS CONTAIN:

REGISTER	CONTENTS
R2	RK06 BASE ADDRESS
R5	ADDRESS OF PARAMETER BLOCK

```

10552 052204 042765 177741 000016 I.CSTS: BIC #177741,P.CS1(R5) ;CLEAR ALL BITS EXCEPT FUNCTION
10553                                     ;OF LAST COMMAND ISSUED
10554 052212 042737 000036 003000 I.CST1: BIC #36,T.CS1 ;CLEAR FUNCTION OF CS1 STATUS
10555 052220 053765 003000 000016 BIS T.CS1,P.CS1(R5) ;GENERATE CS1 STATUS INFORMATION
10556 052226 016265 000010 000020 I.CST1: MOV RKCS2(R2),P.CS2(R5) ;STORE COMMAND AND STATUS REGISTER 2
10557 052234 016265 000002 000022 MOV RKWC(R2),P.WCR(R5) ;STORE WORD COUNT REGISTER
10558 052242 016265 000004 000024 MOV RKBA(R2),P.BAR(R5) ;STORE BUS ADDRESS REGISTER
10559 052250 016265 000006 000026 MOV RKDA(R2),P.DTS(R5) ;STORE DESIRED TRACK AND SECTOR
10560 052256 016265 000012 000036 MOV RKDS(R2),P.DS(R5) ;STORE DRIVE STATUS REGISTER
10561 052264 016265 000014 000034 MOV RKER(R2),P.ER(R5) ;STORE ERROR REGISTER
10562 052272 016265 000016 000032 MOV RKASOF(R2),P.ASOF(R5) ;STORE ATTENTION SUMMARY AND
10563                                     ;OFFSET
10564 052300 016265 000020 000030 MOV RKDCYL(R2),P.DCYL(R5) ;STORE CYLINDER ADDRESS
10565 052306 000207 000000 000000 RTS PC ;RETURN
10566

```

.SBTTL *GATHER DRIVE STATUS

THIS SUBROUTINE WILL BE USED TO GATHER DRIVE STATUS
BYTE 01, 10, AND 11. IT IS ASSUMED THAT THE DRIVE
HAS PREVIOUSLY BEEN SEIZED. IT RUNS AT PRIORITY 7.

*CALL JSR RO,I,STAT
<ADDRESS OF ERROR RETURN>
RETURN

THIS ROUTINE ASSUMES THE FOLLOWING REGISTERS CONTAIN:

REGISTER	CONTENTS
R2	RK06 BASE ADDRESS
R5	ADDRESS OF PARAMETER BLOCK

ROUTINES USED:
I.ISSU

10567
10568
10569
10570
10571
10572
10573
10574
10575
10576
10577
10578
10579
10580
10581
10582
10583
10584
10585
10586
10587
10588
10589
10590
10591
10592
10593
10594
10595
10596
10597
10598
10599
10600
10601
10602
10603
10604
10605
10606
10607
10608
10609
10610
10611
10612
10613
10614
10615
10616
10617
10618
10619
10620
10621
10622

052310	012762	000001	000026
052316	112737	000001	003000
052324	004037	051634	
052330	052520		
052332	013765	003024	000044
052340	013765	003026	000046
052346	012762	000002	000026
052354	112737	000001	003000
052362	004037	051634	
052366	052520		
052370	013765	003024	000050
052376	013765	003026	000052
052404	012762	000003	000026
052412	112737	000001	003000
052420	004037	051634	
052424	052520		
052426	013765	003024	000054
052434	013765	003026	000056
052442	005062	000026	
052446	112737	000001	003000
052454	004037	051634	
052460	052520		
052462	013765	003024	000040
052470	013765	003026	000042
052476	032737	001000	003026
052504	001407		

```

I. STAT: MOV #1,RKMR1(R2) ;LOAD MAINTENANCE REGISTER 1
; FOR STATUS BYTE 01
MOV #DR.SEL.T.CS1 ;LOAD COMMAND
JSR RO,I.ISSU ;GET STATUS BYTES 01
3$ ;ERROR RETURN
MOV T.MR2,P.A01(R5) ;STORE STATUS BYTE 01 MESS A
MOV T.MR3,P.B01(R5) ;STORE STATUS BYTE 01 MESS B
MOV #2,RKMR1(R2) ;LOAD MAINTENANCE REGISTER 1
; FOR STATUS BYTE 10
MOV #DR.SEL.T.CS1 ;LOAD COMMAND
JSR RO,I.ISSU ;GET STATUS BYTES 10
3$ ;ERROR RETURN
MOV T.MR2,P.A10(R5) ;STORE STATUS BYTE 10 MESS A
MOV T.MR3,P.B10(R5) ;STORE STATUS BYTE 10 MESS B
MOV #3,RKMR1(R2) ;LOAD MAINTENANCE REGISTER 1
; FOR STATUS BYTE 11
MOV #DR.SEL.T.CS1 ;LOAD COMMAND
JSR RO,I.ISSU ;GET STATUS BYTES 11
3$ ;ERROR RETURN
MOV T.MR2,P.A11(R5) ;STORE STATUS BYTE 11 MESS A
MOV T.MR3,P.B11(R5) ;STORE STATUS BYTE 11 MESS B
CLR RKMR1(R2) ;LOAD MAINTENANCE REGISTER 1
; FOR STATUS BYTE 00
MOV #DR.SEL.T.CS1 ;LOAD COMMAND
JSR RO,I.ISSU ;GET STATUS BYTES 00
3$ ;ERROR RETURN
MOV T.MR2,P.A00(R5) ;STORE STATUS BYTE 00 MESS A
MOV T.MR3,P.B00(R5) ;STORE STATUS BYTE 00 MESS B
BIT #S.PAR,T.MR3 ;CHECK IF BAD PARITY DETECTED BY DRIVE
BEQ 5$ ;NO, RETURN NORMALLY

```

10623	052506	052737	002000	003052		BIS	#E.DPAR,E.CONT	;INDICATE BAD PARITY DETECTED BY DRIVE
10624	052514	004737	052562			JSR	PC,R.CONT	;REPORT ERROR
10625	052520	011000			3\$:	MOV	(R0),R0	;LOAD R0 FOR ERROR RETURN
10626	052522	000200				RTS	R0	;RETURN
10627								
10628	052524	052765	001000	000014	5\$:	BIS	#PBSVAL,P.PRST(R5)	;SET PARAMETER BLOCK STATUS VALID
10629	052532	005720				TST	(R0)+	;ADJUST R0 FOR NORMAL RETURN
10630	052534	000200				RTS	R0	;RETURN
10631								

E01

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 212
*COMMON DRIVER RETURNS

SEQ 0211

				.SBTTL *COMMON DRIVER RETURNS			
10632				R.ABNL:	CLRB	INTMSK	;INHIBIT FUTURE DRIVE INTERRUPT REPORTING
10633					JSR	PC,QA.ABNL	;INDICATE ABNORMAL RETURN
10634	052536	105037	003101		RTS	PC	;RETURN
10635	052542	004777	130300				
10636	052546	000207					
10637							
10638	052550	105037	003101	R.NORM:	CLRB	INTMSK	;INHIBIT FUTURE DRIVE INTERRUPT REPORTING
10639	052554	004777	130264		JSR	PC,QA.NORM	;INDICATE NORMAL RETURN
10640	052560	000207			RTS	PC	;RETURN
10641							
10642	052562	105037	003101	R.CONT:	CLRB	INTMSK	;INHIBIT FUTURE DRIVE INTERRUPT REPORTING
10643	052566	105037	003100		CLRB	W.TIME	;RESET WATCH DOG TIMING ON THIS DRIVE
10644	052572	005037	003114		CLR	W.DRV	;CLEAR TIMING COUNT FOR THIS DRIVE
10645	052576	004777	130246		JSR	PC,QA.CONT	;INDICATE CONTROLLER ERROR RETURN
10646	052602	000207			RTS	PC	;RETURN

10647
10648
10649
10650
10651
10652
10653
10654
10655
10656
10657
10658
10659
10660
10661
10662
10663
10664
10665
10666
10667
10668
10669
10670
10671
10672
10673
10674
10675
10676
10677
10678
10679
10680
10681
10682
10683
10684
10685
10686
10687
10688
10689
10690
10691
10692
10693
10694
10695
10696
10697
10698
10699
10700
10701
10702

.SBTTL *COMMAND INITATOR

THIS SUBROUTINE WILL INITIATE ALL COMMANDS AS SPECIFIED
BY THE COMMAND FIELD OF THE PARAMETER BLOCK. THE FOLLOWING
SPECIAL COMMAND ARE ALSO EXECUTED:

RELEASE
CONROLLER CLEAR
SUBSYSTEM CLEAR
READ ALL DRIVE STATUS
READ SPECIFIED HEADER

THE ABOVE COMMANDS ARE TRANSLATED INTO A SEQUENCE OF COMMANDS

*CALL JSR PC.C.INIT
<ADDRESS OF PARAMETER BLOCK>
RETURN

FOR THE SEQUENTIAL OPERATIONS, THE DRIVER WILL LOAD THE
LOCATIONS, PBLKT AND INTMSK.

ROUTINES USED:
W.WTCH
I.CSTS
I.STAT
I.CCLR

C.INIT: MOV R5,-(SP) ;STORE R5 ON STACK
MOV R4,-(SP) ;STORE R4 ON STACK
MOV R3,-(SP) ;STORE R3 ON STACK
MOV R2,-(SP) ;STORE R2 ON STACK
MOV R1,-(SP) ;STORE R1 ON STACK
MOV R0,-(SP) ;STORE R0 ON STACK
MOV PS,-(SP) ;STORE PSW ON STACK
MOV RKPRI,PS ;LOCK OUT RK06 INTERRUPTS
MOV @16(SP),R5 ;STORE PARAMETER BLOCK ADDRESS
ADD #2,16(SP) ;ADJUST RETURN
MOV P.DRVN(R5),R4 ;STORE DRIVE NUMBER
BIC #1C<DRVMSK>,R4 ;MASK OUT JUNK
MOV R5,PBLKT ;LOAD PARAMETER BLOCK TABLE
MOVB I.DRV(R4),INTMSK ;LOAD INTERRUPT MASK
MOVB I.DRV(R4),W.TIME ;SET WATCH-DOG TIMER FLAG
MOV W.SEC,W.DRV ;LOAD WATCH-DOG TIME

052604 010546
052606 010446
052610 010346
052612 010246
052614 010146
052616 010046
052620 013746 177776
052624 013737 003042 177776
052632 017605 000016
052636 062766 000002 000016
052644 016504 000000
052650 042704 177770
052654 010537 003112
052660 116437 003102 003101
052666 116437 003102 003100
052674 013737 003062 003114
052702 013702 003036

MOV RKBAS,R2 ;LOAD R2 WITH RK06 ADDRESS BASE
; RESET ALL BITS IN PROGRAM DEVICE STATUS REGISTER EXCEPT
; DRIVE IN USE
; WRITE FOR WRITE CHECK
; NO CHECK
; DROP DRIVE FROM TEST SEQUENCE
; INHIBIT BUS ADDRESS INCREMENT

HO1

CZR6NDO RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 215
*COMMAND INITATOR

SEQ 0214

10759	053130	013737	003064	003114		MOV	W.BSEC,W.DRV	:LOAD RECAL TIME FOR 8 SECONDS
10760	053136	116565	000007	000017	8\$:	MOV	P.CS1H(R5),P.CS1+1(R5)	:STORE BITS 8-15 OF CS1
10761	053144	042765	165777	000016		BIC	#†C<CFMT!CDT>,P.CS1(R5)	:CLEAR ALL BITS EXCEPT FORMAT
10762								:AND DRIVE TYPE
10763	053152	116565	000001	000016		MOV	P.CMND(R5),P.CS1(R5)	:MOVE COMMAND INTO CS1
10764	053160	042765	000200	000014		BIC	#W.WCK,P.PRST(R5)	:RESET WRITE FOR WRITE CHECK
10765	053166	032765	000400	000014		BIT	#NOCHK,P.PRST(R5)	:CHECK IN NO CHECK MODE
10766	053174	001533				BEQ	30\$:NO SKIP CLEAR OF INTERRUPT ENABLE
10767	053176	042765	000100	000016		BIC	#IE,P.CS1(R5)	:CLEAR INTERRUPT ENABLE
10768	053204	016562	000016	000000		MOV	P.CS1(R5),RKCS1(R2)	:ISSUE COMMAND
10769	053212	004737	047154		10\$:	JSR	PC.W.WTCH	:CALL WATCH DOG TIMER
10770	053216	016237	000000	003000		MOV	RKCS1(R2),T.CS1	:STORE COMMAND AND STATUS REGISTER 1
10771	053224	032737	000200	003000		BIT	#RDY,T.CS1	:WAIT FOR READY
10772	053232	001767				BEQ	10\$	
10773	053234	032737	100000	003000		BIT	#CERR,T.CS1	:CHECK FOR ERROR
10774	053242	001011				BNE	15\$:YES, GIVE NORMAL RETURN
10775	053244	004737	047154		11\$:	JSR	PC.W.WTCH	:CALL WATCH DOG TIMER
10776	053250	016237	000016	003014		MOV	RKASOF(R2),T.ASOF	:STORE ATTENTION SUMMARY
10777	053256	133737	003101	003015		BIT	INTMSK,T.ASOF+1	:CHECK IF INTERRUPT HAS OCCURRED
10778	053264	001767				BEQ	11\$:WAIT FOR DRIVE INTERRUPT
10779	053266	105037	003100		15\$:	CLRB	W.TIME	:RESET TIMING ON THIS DRIVE
10780	053272	005037	003114			CLR	W.DRV	:CLEAR DRIVE TIMING COUNT
10781	053276	004737	052550			JSR	PC.R.NORM	:INDICATE COMMAND IS FINISHED
10782	053302	000137	054456			JMP	C.ATRN	:RESTORE REGISTERS
10783								
10784	053306	016562	000010	000004	20\$:	MOV	P.BALO(R5),RKBA(R2)	:LOAD BUS ADDRESS REGISTER
10785	053314	016562	000012	000002		MOV	P.WC(R5),RKWC(R2)	:LOAD WORD COUNT REGISTER
10786	053322	016562	000002	000020		MOV	P.CYLN(R5),RKDCYL(R2)	:LOAD CYLINDER ADDRESS REGISTER
10787	053330	016562	000004	000006		MOV	P.SECT(R5),RKDA(R2)	:LOAD SECTOR AND TRACK NUMBER
10788	053336	122765	000131	000001		CMPB	#WRTCHK,P.CMND(R5)	:CHECK IF WRITE CHECK COMMAND
10789	053344	001010				BNE	25\$:NO, GO ISSUE THE COMMAND
10790	053346	032765	000200	000014		BIT	#W.WCK,P.PRST(R5)	:CHECK IF WRITE COMMAND SHOULD BE ISSUED
10791	053354	001404				BEQ	25\$:NO, GO ISSUE THE COMMAND
10792	053356	012765	000123	000016		MOV	#WRDATA,P.CS1(R5)	:ISSUE WRITE COMMAND
10793	053364	000406				BR	26\$:GO ISSUE COMMAND
10794								
10795	053366	116565	000001	000016	25\$:	MOV	P.CMND(R5),P.CS1(R5)	:MOVE COMMAND INTO CS1
10796	053374	042765	000200	000014		BIC	#W.WCK,P.PRST(R5)	:RESET WRITE FOR WRITE CHECK
10797	053402	116565	000007	000017	26\$:	MOV	P.CS1H(R5),P.CS1+1(R5)	:STORE BITS 8-15 OF CS1
10798	053410	142765	177750	000017		BICB	#†C<B.CFMT!B.CDT!B.BA16!B.BA17>,P.CS1+1(R5)	:CLEAR ALL BITS EXCEPT
10799								:FORMAT, DRIVE TYPE, AND BUS ADDRESS
10800								:BITS 16-17
10801	053416	010537	003054			MOV	R5.0.WAIT	:LOAD WAITING FOR COMMAND
10802	053422	032765	100000	000014		BIT	#DIBAI,P.PRST(R5)	:CHECK IF INHIBIT BUS ADDRESS INCREMENT
10803	053430	001403				BEQ	27\$:NO, LOAD CS2
10804	053432	052765	000020	000020		BIS	#BAI,P.CS2(R5)	:SET INHIBIT BUS ADDRESS INCREMENT
10805	053440	016562	000020	000010	27\$:	MOV	P.CS2(R5),RKCS2(R2)	:LOAD CS2
10806	053446	032765	000400	000014		BIT	#NOCHK,P.PRST(R5)	:CHECK IN NO CHECK MODE
10807	053454	001403				BEQ	30\$:NO SKIP CLEAR OF INTERRUPT ENABLE
10808	053456	042765	000100	000016		BIC	#IE,P.CS1(R5)	:CLEAR INTERRUPT ENABLE
10809	053464	016562	000016	000000	30\$:	MOV	P.CS1(R5),RKCS1(R2)	:ISSUE COMMAND
10810	053472	000137	054456			JMP	C.ATRN	:RESTORE REGISTERS
10811								
10812						.SBTTL	*SPECIAL COMMAND PROCESSING	
10813								
10814	053476	122765	000141	000001	C.SPEC:	CMPB	#RDSTAT,P.CMND(R5)	:CHECK IF READ DRIVE STATUS

I01

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 216
*SPECIAL COMMAND PROCESSING

SEQ 0215

10815	053504	001132				BNE	10\$:NO, PROCESS OTHER COMMANDS
10816	053506	016562	000020	000010		MOV	P.CS2(R5),RKCS2(R2)	:LOAD CS2 FOR COMMAND
10817	053514	116565	000007	000017		MOVB	P.CS1H(R5),P.CS1+1(R5)	:STORE BITS 8-15 OF CS1
10818	053522	042765	165777	000016		BIC	#t<CFMT!CDT>,P.CS1(R5)	:CLEAR ALL BITS EXCEPT FORMAT
10819								: AND DRIVE TYPE
10820	053530	112765	000001	000016		MOVB	#DR.SEL,P.CS1(R5)	:STORE COMMAND
10821	053536	016562	000016	000000		MOV	P.CS1(R5),RKCS1(R2)	:ISSUE COMMAND
10822	053544	004737	047154		2\$:	JSR	PC,W.WTCH	:CALL WATCH-DOG TIMER
10823	053550	016265	000000	000016		MOV	RKCS1(R2),P.CS1(R5)	:STORE COMMAND AND STATUS REG. 1
10824	053556	032765	000200	000016		BIT	#RDY,P.CS1(R5)	:WAIT FOR READY
10825	053564	001767				BEQ	2\$	
10826	053566	004737	052226			JSR	PC,I.CST1	:STORE CONTROLLER REGISTERS
10827	053572	016265	000034	000040		MOV	RKMR2(R2),P.A00(R5)	:STORE STATUS BYTE 00 MESSAGE A
10828	053600	016265	000036	000042		MOV	RKMR3(R2),P.B00(R5)	:STORE STATUS BYTE 00 MESSAGE B
10829	053606	032765	100000	000016		BIT	#CERR,P.CS1(R5)	:CHECK IF CONTROLLER ERROR
10830	053614	001436				BEQ	6\$:NO, GATHER DRIVE STATUS
10831	053616	105037	003100			CLRB	W.TIME	:RESET WATCH DOG TIMING ON THIS DRIVE
10832	053622	005037	003114			CLR	W.DRV	:CLEAR WATCH DOG COUNT
10833	053626	032765	000400	000014		BIT	#NOCHK,P.PRST(R5)	:CHECK IF NO CHECK MODE
10834	053634	001043				BNE	8\$:YES, INDICATE NORMAL RETURN
10835	053636	032765	001000	000020		BIT	#MDS,P.CS2(R5)	:CHECK IF MULTIPLE DRIVE SELECT
10836	053644	001043				BNE	9\$:YES, INDICATE CONTROLLER ERROR
10837	053646	004037	051552			JSR	RO,I.CCLR	:CLEAR ERROR
10838	053652	054456				C.RTRN		:ERROR RETURN
10839	053654	032765	010400	000020		BIT	#NED!UFE,P.CS2(R5)	:CHECK IF NON-EXISTENT DRIVE OR UNIT FIELD ERROR
10840	053662	001007				BNE	5\$:REPORT ERROR
10841	053664	032765	000001	000036		BIT	#DRA,P.DS(R5)	:CHECK IF DRIVE AVAILIABLE
10842	053672	001003				BNE	5\$:YES, REPORT ERROR
10843	053674	052765	010000	000014		BIS	#DRVSZD,P.PRST(R5)	:INDICATE DRIVE IS SEIZED BY OTHER PORT
10844	053702	004737	052536		5\$:	JSR	PC,R.ABNL	:INDICATE ABNORMAL RETURN
10845	053706	000137	054456			JMP	C.RTRN	:RESTORE REGISTERS
10846								
10847	053712	004037	052310		6\$:	JSR	RO,I.STAT	:GATHER DRIVE STATUS
10848	053716	054456				C.RTRN		:ERROR RETURN
10849	053720	105037	003100			CLRB	W.TIME	:STOP WATCH-DOG TIMING ON DRIVE
10850	053724	005037	003114			CLR	W.DRV	:RESET WATCH-DOG TIME
10851	053730	032765	000400	000014		BIT	#NOCHK,P.PRST(R5)	:CHECK IF NO CHECK MODE
10852	053736	001402				BEQ	8\$:NO, REPORT ERROR
10853	053740	005062	000000			CLR	RKCS1(R2)	:CLEAR INTERRUPT ENABLE
10854	053744	004737	052550		8\$:	JSR	PC,R.NORM	:REPORT COMMAND COMPLETE
10855	053750	000137	054456			JMP	C.RTRN	:RESTORE REGISTERS
10856								
10857	053754	052737	100000	003052	9\$:	BIS	#E.MDS,E.CONT	:SET MULTIPLE DRIVE SELECT
10858	053762	004737	052562			JSR	PC,R.CONT	:INDICATE CONTROLLER ERROR
10859	053766	000137	054456			JMP	C.RTRN	
10860								
10861	053772	122765	000140	000001	10\$:	CMPB	#RELEAS,P.CMND(R5)	:CHECK IF RELEASE COMMAND
10862	054000	001040				BNE	13\$:NO, CHECK IF READ ALL HEADERS
10863	054002	010537	003054			MOV	R5,O.WAIT	:STORE PARAMETER BLOCK ADDRESS IN
10864								: WAIT FOR COMMAND
10865	054006	052765	000010	000020		BIS	#RLS,P.CS2(R5)	:SET RELEASE BIT
10866	054014	016562	000020	000010		MOV	P.CS2(R5),RKCS2(R2)	:LOAD CS2 FOR DESELECT
10867	054022	112737	000001	003074		MOVB	#1,I.ISRL	:SET FLAG FOR RELEASE COMMAND
10868	054030	116565	000007	000017		MOVB	P.CS1H(R5),P.CS1+1(R5)	:STORE BITS 8-15 OF CS1
10869	054036	042765	165777	000016		BIC	#t<CFMT!CDT>,P.CS1(R5)	:CLEAR ALL BITS EXCEPT FORMAT
10870								: AND DRIVE TYPE

10871	054044	112765	000101	000016		MOVB	#SELDIV,P.CS1(R5)	;STORE COMMAND
10872	054052	032765	000400	000014		BIT	#NOCHK,P.PRST(R5)	;CHECK IF NO CHECK MODE
10873	054060	001403				BEQ	11\$;NO, DO NOT RESET INTERRUPT ENABLE
10874	054062	042765	000100	000016		BIC	#IE,P.CS1(R5)	;RESET INTERRUPT ENABLE
10875	054070	016562	000016	000000	11\$:	MOV	P.CS1(R5),RKCS1(R2)	;ISSUE COMMAND
10876	054076	000137	054456			JMP	C.RTRN	;RESTORE REGISTERS
10877								
10878	054102	122765	000164	000001	13\$:	CMPB	#RDALHD,P.CMND(R5)	;CHECK IF READ ALL HEADERS
10879	054110	001053				BNE	30\$;NO, CHECK IF CONTROLLER CLEAR
10880	054112	010537	003054			MOV	R5,0.WAIT	;SET WAITING FOR COMMAND COMPLETION
10881	054116	016537	000010	003070		MOV	P.BALO(R5),HDR.AD	;LOAD HEADER ADDRESS
10882	054124	132765	000020	000007		BITB	#B.CFMT,P.CS1H(R5)	;CHECK IF 22 SECTOR FORMANT
10883	054132	001404				BEQ	14\$;YES, LOAD 22 IN HEADER COUNT
10884	054134	012737	000024	003072		MOV	#20.,HDR.CT	;LOAD 20 IN SECTOR COUNT
10885	054142	000403				BR	22\$;GO ISSUE READ HEADER COMMAND
10886								
10887	054144	012737	000026	003072	14\$:	MOV	#22.,HDR.CT	;LOAD 22 IN SECTOR COUNT
10888	054152	016562	000002	000020	22\$:	MOV	P.CYLN(R5),RKDCYL(R2)	;LOAD CYLINDER ADDRESS
10889	054160	016562	000004	000006		MOV	P.SECT(R5),RKDA(R2)	;LOAD TRACK NUMBER
10890	054166	016562	000020	000010		MOV	P.CS2(R5),RKCS2(R2)	;LOAD DRIVE NUMBER
10891	054174	116565	000007	000017		MOVB	P.CS1H(R5),P.CS1+1(R5)	;STORE BITS 8-15 OF CS1
10892	054202	042765	165777	000016		BIC	#1C<CFMT!CDT>,P.CS1(R5)	;CLEAR ALL BITS EXCEPT DRIVE TYPE
10893								;AND FORMAT
10894	054210	112765	000125	000016		MOVB	#RDHEAD,P.CS1(R5)	;STORE READ HEADER COMMAND
10895	054216	032765	000400	000014		BIT	#NOCHK,P.PRST(R5)	;CHECK IF NO CHECK MODE
10896	054224	001027				BNE	34\$;YES, INDICATE ILLEGAL DRIVER COMMAND
10897	054226	016562	000016	000000		MOV	P.CS1(R5),RKCS1(R2)	;ISSUE READ HEADER
10898	054234	000137	054456			JMP	C.RTRN	;RESTORE REGISTERS
10899								
10900	054240	122765	000176	000001	30\$:	CMPB	#CONCLR,P.CMND(R5)	;CHECK IF CONTROLLER CLEAR
10901	054246	001012				BNE	32\$;NO, CHECK IF SUBSYSTEM CLEAR
10902	054250	004037	051552			JSR	RD,I.CCLR	;CLEAR CONTROLLER
10903	054254	054456				C.RTRN		;ERROR RETURN
10904	054256	032765	000400	000014		BIT	#NOCHK,P.PRST(R5)	;CHECK IF NO CHECK MODE
10905	054264	001472				BEQ	40\$;NO, INDICATE NORMAL RETURN
10906	054266	005062	000000			CLR	RKCS1(R2)	;RESET INTERRUPT ENABLE
10907	054272	000467				BR	40\$;INDICATE NORMAL RETURN
10908								
10909	054274	122765	000177	000001	32\$:	CMPB	#SUBCLR,P.CMND(R5)	;CHECK IF SUBSYSTEM CLEAR
10910	054302	001406				BEQ	36\$;YES, CLEAR SUBSYSTEM
10911	054304	052737	000100	003052	34\$:	BIS	#E.ILLD,E.CONT	;SET ILLEGAL DRIVER COMMAND
10912	054312	004737	052562			JSR	PC,R.CONT	;REPORT ERROR
10913	054316	000457				BR	C.RTRN	;RESTORE REGISTERS
10914								
10915	054320	012762	000040	000010	36\$:	MOV	#SCLR,RKCS2(R2)	;ISSUE SUBSYSTEM CLEAR
10916	054326	016265	000000	000016		MOV	RKCS1(R2),P.CS1(R5)	;STORE COMMAND AND STATUS REGISTER 1
10917	054334	032765	100000	000016		BIT	#CERR,P.CS1(R5)	;CLEAR IF CONTROLLER ERROR RESET
10918	054342	001406				BEQ	37\$;NO, FINISH COMMAND
10919	054344	052737	000001	003052		BIS	#BIT0,E.CONT	;SET CLEAR SUBSYSTEM DID NOT CLEAR
10920								;CONTROLLER ERROR
10921	054352	004737	052562			JSR	PC,R.CONT	;REPORT ERROR
10922	054356	000437				BR	C.RTRN	;RESTORE REGISTERS
10923								
10924	054360	013746	003060		37\$:	MOV	W.MILI,-(SP)	;LOAD 16 MILI-SECOND COUNT FOR ATTENTION
10925								;TO DISAPPEAR
10926	054364	016265	000000	000016	38\$:	MOV	RKCS1(R2),P.CS1(R5)	;STORE CS1

```

10927 054372 032765 040000 000016 BIT #DI,P.CS1(R5) ;CHECK IF ATTENTIONS CLEARED
10928 054400 001411 BEQ 39$ ;YES, FINISH COMMAND
10929 054402 005316 DEC (SP) ;DECREMENT 16 MILLISECOND COUNT
10930 054404 001367 BNE 38$ ;CHECK DRIVE INTERRUPT AGAIN
10931 054406 005726 TST (SP)+ ;ADJUST STACK
10932 054410 052737 000040 003052 BIS #E.SCLR,E.CONT ;SET SUBSYSTEM CLEAR DID NOT CLEAR
10933 ;DRIVE ATTENTIONS
10934 054416 004737 052562 JSR PC,R.CONT ;REPORT ERROR
10935 054422 000415 BR C.RTRN ;RESTORE REGISTER
10936
10937 054424 005726 39$: TST (SP)+ ;ADJUST STACK
10938 054426 032765 000400 000014 BIT #NOCHK,P.PRST(R5) ;CHECK IF NO CHECK MODE
10939 054434 001010 C.RTRN ;YES, RESTORE REGISTERS
10940 054436 112737 177777 003074 MOVB #-1,I.ISRL ;SET INTERRUPT ENABLE SET
10941 054444 012762 000100 000000 MOV #IE,RKCS1(R2) ;SET INTERRUPT ENABLE
10942 054452 004737 052550 40$: JSR PC,R.NORM ;INDICATE NORMAL TERMINATION
10943
10944 054456 012637 177776 C.RTRN: MOV (SP)+,PS ;RESTORE PSW
10945 054462 012600 MOV (SP)+,R0 ;RESTORE R0
10946 054464 012601 MOV (SP)+,R1 ;RESTORE R1
10947 054466 012602 MOV (SP)+,R2 ;RESTORE R2
10948 054470 012603 MOV (SP)+,R3 ;RESTORE R3
10949 054472 012604 MOV (SP)+,R4 ;RESTORE R4
10950 054474 012605 MOV (SP)+,R5 ;RESTORE R5
10951 054476 000207 RTS PC ;RETURN
10952
10953 .SBTTL OCTAL TO BINARY CONVERSION ROUTINE
10954
10955 ;*****
10956 ; THIS ROUTINE WILL CHECK A STRING OF ASCII CHARACTERS TERMINATED
10957 ; WITH A NULL <000> OR COMMA. IF THE CHARACTERS ARE LEGAL
10958 ; IT WILL GENERATE TWO BINARY WORDS PLACING THE LOW 16 BITS
10959 ; ON THE STACK AND THE HIGH 16 BITS IN LOCATION $HI0CT.
10960 ;*****
10961 ;CALL
10962 ; MOV <ADDRESS OF ASCII STRING>,-(SP)
10963 ; JSR PC,OCTBIN
10964 ; <ADDRESS OF ERROR RETURN>
10965 ; RETURN
10966 ;*****
10967
10968
10969 054500 010046 OCTBIN: MOV R0,-(SP) ;SAVE R0
10970 054502 010146 MOV R1,-(SP) ;SAVE R1
10971 054504 010246 MOV R2,-(SP) ;SAVE R2
10972 054506 016600 000010 MOV 10(SP),R0 ;GET ADDRESS OF ASCII STRING
10973 054512 005001 CLR R1 ;CLEAR DATA WORDS
10974 054514 005002 CLR R2
10975 054516 112046 2$: MOV (R0)+,-(SP) ;PICK THIS CHARACTER
10976 054520 001423 BEQ 3$ ;IF ZERO GET OUT
10977 054522 121627 000054 CMPB (SP),#', ;CHECK IF COMMA
10978 054526 001420 BEQ 3$ ;IF COMMA GET OUT
10979 054530 122716 000060 CMPB #'0,(SP) ;MAKE SURE THIS CHARACTER IS
10980 054534 003030 BGT 4$ ; AN OCTAL DIGIT
10981 054536 122716 000067 CMPB #'7,(SP)
10982 054542 002425 BLT 4$

```

L01

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 219
OCTAL TO BINARY CONVERSION ROUTINE

SEQ 0218

```

10983 054544 006301          ASL      R1          ; *2
10984 054546 006102          ROL      R2
10985 054550 006301          ASL      R1          ; *4
10986 054552 006102          ROL      R2
10987 054554 006301          ASL      R1          ; *8
10988 054556 006102          ROL      R2
10989 054560 042716 177770    BIC      #1C7,(SP)    ;STRIP THE ASCII JUNK
10990 054564 062601          ADD      (SP)+,R1    ;ADD THIS DIGIT
10991 054566 000753          BR       2$          ;LOOP
10992 054570 005726          3$:     TST      (SP)+    ;CLEAN PARTIAL FROM STACK
10993 054572 010166 000010    MOV      R1,10(SP)  ;SAVE RESULT
10994 054576 010237 054632    MOV      R2,$HIQCT
10995 054602 012602          MOV      (SP)+,R2    ;RESTORE R2
10996 054604 012601          MOV      (SP)+,R1    ;RESTORE R1
10997 054606 012600          MOV      (SP)+,R0    ;RESTORE R0
10998 054610 062716 000002    ADD      #2,(SP)    ;ADJUST RETURN
10999 054614 000207          RTS      PC          ;RETURN
11000
11001 054616 005726          4$:     TST      (SP)+    ;CLEAN UP PARTIAL FROM STACK
11002 054620 012602          MOV      (SP)+,R2    ;RESTORE R2
11003 054622 012601          MOV      (SP)+,R1    ;RESTORE R1
11004 054624 012600          MOV      (SP)+,R0    ;RESTORE R0
11005 054626 013616          MOV      @($P)+,$(SP) ;PUT ADDRESS OF ERROR ROUTINE ON STACK
11006 054630 000207          RTS      PC          ;GO PROCESS ERROR
11007 054632 000000          $HIQCT: .WORD      0    ;HIGH ORDER BITS GO HERE
11008
11009          .SBTTL  RANDOM NUMBER GENERATOR ROUTINE
11010
11011          ;*****
11012          ;*THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
11013          ;*WITH A RANGE OF 0 TO 2(+33)-1.
11014          ;*CALL:
11015          ;*      JSR      PC,$RAND          ;:CALL THE ROUTINE
11016          ;*      RETURN                    ;:RETURN HERE THE RANDOM
11017          ;*                               ;:NUMBER WILL BE IN
11018          ;*                               ;:$HINUM,$LONUM
11019
11019 054634          $RAND:
11020 054634 010046          MOV      RO,-(SP)    ;:PUSH RO ON STACK
11021 054636 010146          MOV      R1,-(SP)    ;:PUSH R1 ON STACK
11022 054640 010246          MOV      R2,-(SP)    ;:PUSH R2 ON STACK
11023 054642 013700 054734    MOV      $LONUM,R0    ;:SET RO WITH LOW
11024 054646 013701 054732    MOV      $HINUM,R1    ;:SET R1 WITH HIGH
11025 054652 012702 177771    MOV      #-7,R2      ;:SET SHIFT COUNT
11026 054656 006300          1$:     ASL      R0          ;:SHIFT RO LEFT AND
11027 054660 006101          ROL      R1          ;:ROTATE CARRY INTO R1 AND
11028 054662 005202          INC      R2          ;:CHECK FOR DONE
11029 054664 001374          BNE     1$          ;:CONTINUE SHIFT LOOP
11030 054666 063700 054734    ADD      $LONUM,R0    ;:ADD NUMBER TO MAKE X 129
11031 054672 005501          ADC      R1          ;:PROPOGATE CARRY
11032 054674 063701 054732    ADD      $HINUM,R1    ;:ADD NUMBER TO MAKE X 129
11033 054700 062700 001057    ADD      #1057,R0    ;:ADD LOW CONSTANT
11034 054704 005501          ADC      R1          ;:PROPOGATE CARRY
11035 054706 062701 047401    ADD      #47401,R1    ;:ADD HIGH CONSTANT
11036 054712 010037 054734    MOV      R0,$LONUM    ;:SAVE RO
11037 054716 010137 054732    MOV      R1,$HINUM    ;:SAVE R1
11038 054722 012602          MOV      (SP)+,R2    ;:POP STACK INTO R2

```

MO1

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 220
RANDOM NUMBER GENERATOR ROUTINE

SEQ 0219

```

11039 054724 012601      MOV      (SP)+,R1      ;; POP STACK INTO R1
11040 054726 012600      MOV      (SP)+,R0      ;; POP STACK INTO R0
11041 054730 000207      RTS      PC            ;; RETURN
11042 054732 176543      $HINUM: .WORD 176543
11043 054734 123456      $LONUM: .WORD 123456
11044                                     .SBTTL  TYPE ROUTINE
11045
11046                                     ;*****
11047                                     ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
11048                                     ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
11049                                     ;*NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
11050                                     ;*NOTE2:          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
11051                                     ;*NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
11052                                     ;*
11053                                     ;*CALL:
11054                                     ;*1) USING A TRAP INSTRUCTION
11055                                     ;*      TYPE      ,MESADR      ;; MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
11056                                     ;*OR
11057                                     ;*      TYPE
11058                                     ;*      MESADR
11059                                     ;*
11060
11061 054736 105737 001157      $TYPE:  TSTB      $TFPLG      ;; IS THERE A TERMINAL?
11062 054742 100002      BPL      1$           ;; BR IF YES
11063 054744 000000      HALT     1$           ;; HALT HERE IF NO TERMINAL
11064 054746 000430      BR       3$           ;; LEAVE
11065 054750 010046      1$:      MOV      RO,-(SP)      ;; SAVE RO
11066 054752 017600 000002      MOV      22(SP),RO      ;; GET ADDRESS OF ASCIZ STRING
11067 054756 122737 000001 001340      CMPB     #APTENV,$ENV    ;; RUNNING IN APT MODE
11068 054764 001011      BNE     62$          ;; NO GO CHECK FOR APT CONSOLE
11069 054766 132737 000100 001341      BITB     #APTSPool,$ENVM ;; SPOOL MESSAGE TO APT
11070 054774 001405      BEQ     62$          ;; NO GO CHECK FOR CONSOLE
11071 054776 010037 055006      MOV      RO,61$       ;; SETUP MESSAGE ADDRESS FOR APT
11072 055002 004737 057434      JSR     PC,$ATY3      ;; SPOOL MESSAGE TO APT
11073 055006 000000      61$:    .WORD 0          ;; MESSAGE ADDRESS
11074 055010 132737 000040 001341      62$:    BITB     #APTCSUP,$ENVM ;; APT CONSOLE SUPPRESSED
11075 055016 001003      BNE     60$          ;; YES, SKIP TYPE OUT
11076 055020 112046      2$:      MOV      (RO)+,-(SP)    ;; PUSH CHARACTER TO BE TYPED ONTO STACK
11077 055022 001005      BNE     4$           ;; BR IF IT ISN'T THE TERMINATOR
11078 055024 005726      TST     (SP)+         ;; IF TERMINATOR POP IT OFF THE STACK
11079 055026 012600      60$:    MOV      (SP)+,RO    ;; RESTORE RO
11080 055030 062716 000002      3$:      ADD      #2,(SP)        ;; ADJUST RETURN PC
11081 055034 000002      RTI
11082 055036 122716 000011      4$:      CMPB     #HT,(SP)      ;; BRANCH IF <HT>
11083 055042 001430      BEQ     8$           ;;
11084 055044 122716 000200      CMPB     #CRLF,(SP)    ;; BRANCH IF NOT <CRLF>
11085 055050 001006      BNE     5$           ;;
11086 055052 005726      TST     (SP)+         ;; POP <CR><LF> EQUIV
11087 055054 104401      TYPE
11088 055056 001315      $CRLF
11089 055060 105037 055214      CLR      $CHARCNT     ;; CLEAR CHARACTER COUNT
11090 055064 000755      BR      2$           ;; GET NEXT CHARACTER
11091 055066 004737 055150      5$:      JSR      PC,$TYPEC     ;; GO TYPE THIS CHARACTER
11092 055072 123726 001156      6$:      CMPB     $FILLC,(SP)+  ;; IS IT TIME FOR FILLER CHARS.?
11093 055076 001350      BNE     2$           ;; IF NO GO GET NEXT CHAR.
11094 055100 013746 001154      MOV      $NULL,-(SP)  ;; GET # OF FILLER CHARS. NEEDED

```

```

11095
11096 055104 105366 000001      7$:   DECB   1(SP)           ;; AND THE NULL CHAR.
11097 055110 002770                BLT    6$                   ;; DOES A NULL NEED TO BE TYPED?
11098 055112 004737 055150        JSR    PC,$TYPEC          ;; BR IF NO--GO POP THE NULL OFF OF STACK
11099 055116 105337 055214        DECB   $CHARCNT          ;; GO TYPE A NULL
11100 055122 000770                BR     7$                   ;; DO NOT COUNT AS A COUNT
11101
11102                                ;HORIZONTAL TAB PROCESSOR
11103
11104 055124 112716 000040      8$:   MOVB   #' (SP)           ;; REPLACE TAB WITH SPACE
11105 055130 004737 055150      9$:   JSR    PC,$TYPEC          ;; TYPE A SPACE
11106 055134 132737 000007 055214 BITB   #7,$CHARCNT        ;; BRANCH IF NOT AT
11107 055142 001372                BNE    9$                   ;; TAB STOP
11108 055144 005726                TST    (SP)+              ;; POP SPACE OFF STACK
11109 055146 000724                BR     2$                   ;; GET NEXT CHARACTER
11110 055150 105777 123774      $TYPEC: TSTB   @STPS          ;; WAIT UNTIL PRINTER IS READY
11111 055154 100375                BPL    $TYPEC
11112 055156 116677 000002 123766 MOVB   2(SP),@STPB        ;; LOAD CHAR TO BE TYPED INTO DATA REG.
11113 055164 122766 000015 000002 CMPB   #CR,2(SP)         ;; IS CHARACTER A CARRIAGE RETURN?
11114 055172 001003                BNE    1$                   ;; BRANCH IF NO
11115 055174 105037 055214        CLRB   $CHARCNT          ;; YES--CLEAR CHARACTER COUNT
11116 055200 000406                BR     $TYPEX              ;; EXIT
11117 055202 122766 000012 000002 1$:   CMPB   #LF,2(SP)         ;; IS CHARACTER A LINE FEED?
11118 055210 001402                BEQ    $TYPEX              ;; BRANCH IF YES
11119 055212 105227                INCB   (PC)+              ;; COUNT THE CHARACTER
11120 055214 000000        $CHARCNT: .WORD 0        ;; CHARACTER COUNT STORAGE
11121 055216 000207        $TYPEX: RTS    PC
11122
11123
11124
11125
11126
11127                                ;*****
11128                                ;SBTTL DOUBLE-PRECISION MULTIPLY SUBROUTINE
11129                                ;SUBROUTINE TO MULTIPLY TWO DOUBLE PRECISION INTEGERS
11130                                ;USES ALL REGISTERS (R0-R5)
11131                                ;
11132                                ;ENTER WITH JSR PC,M.DPIM
11133                                ;MULTIPLIER IN R2-R3
11134                                ;MULTIPLICAND IN R4-R5
11135                                ;PRODUCT RETURNED IN R0-R1-R2-R3
11136                                ;*****
11137 055220 005000        M.DPIM: CLR    R0           ;CLEAR HI ORDER WORDS
11138 055222 005001                CLR    R1
11139 055224 012746 000041        MOV    #41,-(SP)         ;MOVE 33 (DEC) TO COUNTER
11140 055230 006000        M.DP01: ROR    R0
11141 055232 006001                ROR    R1
11142 055234 006002                ROR    R2           ;SHIFT TO ADD
11143 055236 006003                ROR    R3
11144 055240 103003        BCC    M.DP02           ;NO CARRY NO ADD
11145 055242 060501        ADD    R5,R1
11146 055244 005500        ADC    R0              ;ADD DOUBLE PRECISION TO OBTAIN NEW PARTIAL
11147 055246 060400        ADD    R4,R0           ;PRODUCT
11148 055250 005316        M.DP02: DEC    @SP          ;DECREMENT COUNTER
11149 055252 001366                BNE    M.DP01
11150 055254 005726                TST    (SP)+           ;REMOVE THE COUNTER

```

```

11151 055256 000207
11152
11153
11154
11155
11156
11157
11158
11159
11160
11161
11162
11163
11164
11165
11166 055260 012746 000040
11167 055264 010446
11168 055266 010546
11169 055270 005466 000002
11170 055274 005416
11171 055276 005666 000002
11172 055302 061601
11173 055304 005500
11174 055306 066600 000002
11175 055312 103445
11176 055314 005046
11177 055316 006103
11178 055320 006102
11179 055322 006101
11180 055324 006100
11181 055326 005716
11182 055330 001410
11183 055332 005016
11184 055334 066601 000002
11185 055340 005500
11186 055342 005516
11187 055344 066600 000004
11188 055350 000404
11189 055352 060501
11190 055354 005500
11191 055356 005516
11192 055360 060400
11193 055362 005516
11194 055364 005716
11195 055366 001401
11196 055370 005203
11197 055372 005366 000006
11198 055376 003347
11199 055400 006003
11200 055402 103404
11201 055404 060501
11202 055406 005500
11203 055410 060400
11204 055412 000241
11205 055414 006103
11206 055416 062706 000010

```

RTS PC

```

;*****
;SBTTL DOUBLE-PRECISION DIVIDE SUBROUTINE
;SUBROUTINE TO PERFORM DOUBLE-PRECISION INTEGER DIVISION
;USES ALL REGISTERS (R0-R5)
;
;ENTER WITH JSR PC,M.DPID
;DIVIDEND IN R0-R1-R2-R3
;DIVISOR IN R4-R5
;REMAINDER RETURNED IN R0-R1
;QUOTIENT RETURNED IN R2-R3
;*****
M.DPID: MOV #40,-(SP) ;COUNTER FOR DIVISION CYCLES
MOV R4,-(SP) ;HI ORDER
MOV R5,-(SP) ;LO ORDER DIVISOR TO THE STACK
NEG 2(SP) ;FORM NEGATIVE
NEG @SP ; VERSION OF THE DIVISOR
SBC 2(SP)
ADD @SP,R1 ;PERFORM THE INITIAL SUBTRACTION
ADC R0
ADD 2(SP),R0 ;IF CARRY THEN OVERFLOW HAS OCCURRED
BCS M.DP50 ;THIS IS A LONGER LASTING CARRY BIT
M.DP40: CLR -(SP)
ROL R3
ROL R2
ROL R1
ROL R0
TST @SP ;TEST "CARRY INDICATOR"
BEQ M.DP41 ;IF NO "CARRY" THEN ADD ELSE SUBTRACT
CLR @SP ;CLEAR UP FOR NEXT TIME
ADD 2(SP),R1 ;ADD -(DIVISOR)
ADC R0 ;SET "CARRY"
ADC @SP ; I
ADD 4(SP),R0 ;<
BR M.DP42
M.DP41: ADD R5,R1 ;ADD +(DIVISOR)
ADC R0 ;SET "CARRY"
ADC @SP ; I
ADD R4,R0 ;<
M.DP42: ADC @SP ;SET "CARRY"
TST @SP ;TEST THE UPDATE INDICATOR
BEQ .+4 ;> ;IF ZERO FORGET IT
INC R3 ;> ;NO CARRY POSSIBLE HERE
DEC 6(SP) ;< ;DECREMENT COUNTER
BGT M.DP40 ;< ;BR IF MORE TO DO
ROR R3
BCS M.DP44
ADD R5,R1
ADC R0
ADD R4,R0
M.DP44: CLC
ROL R3
ADD #10,SP ;ADJUST STACK BY 4 WORDS

```

11207 055422 000242
11208 055424 000207
11209 055426 062706 000006
11210 055432 000262
11211 055434 000207

CLV
RTS PC
M.DP50: ADD #6,SP
SEV
RTS PC

.SBTTL DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE

*THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
*UNSIGNED OCTAL ASCII NUMBER.

*CALL
* MOV #PNTR, -(SP) ;; POINTER TO LOW WORD OF BINARY NUMBER
* JSR PC, @#\$DB20 ;; CALL THE ROUTINE
* RETURN ;; THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK

11225
11226 055436 104407
11227 055440 016601 000002
11228 055444 012705 055555
11229 055450 012704 000014
11230 055454 012703 177770
11231 055460 012100
11232 055462 012101
11233 055464 005002
11234 055466 110245
11235 055470 010002
11236 055472 005304
11237 055474 003007
11238 055476 001405
11239 055500 005205
11240 055502 010566 000002
11241 055506 104410
11242 055510 000207
11243 055512 006203
11244 055514 006001
11245 055516 006000
11246 055520 006001
11247 055522 006000
11248 055524 006001
11249 055526 006000
11250 055530 040302
11251 055532 062702 000060
11252 055536 000753
11253 055540 000016

\$DB20: SAVREG ;; SAVE ALL REGISTERS
MOV 2(SP), R1 ;; PICKUP THE POINTER TO LOW WORD
MOV #SOCTVL+13., R5 ;; POINTER TO DATA TABLE
MOV #12., R4 ;; DO ELEVEN CHARACTERS
MOV #1C7, R3 ;; MASK
MOV (R1)+, R0 ;; LOWER WORD
MOV (R1)+, R1 ;; HIGH WORD
CLR R2 ;; TERMINATOR
1\$: MOVB R2, -(R5) ;; PUT CHARACTER IN DATA TABLE
MOV R0, R2 ;; GET THIS DIGIT
DEC R4 ;; COUNT THIS CHARACTER
BGT 3\$;; BR IF NOT THE LAST DIGIT
BEQ 2\$;; BR IF IT IS THE LAST DIGIT
INC R5 ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
MOV R5, 2(SP) ;; ASCII CHAR. & PUT IT ON THE STACK
RESREG ;; RESTORE ALL REGISTERS
RTS PC ;; RETURN TO USER
2\$: ASR R3 ;; POSITION THE MASK FOR THE LAST DIGIT
3\$: ROR R1 ;; POSITION THE BINARY NUMBER FOR
ROR R0 ;; THE NEXT OCTAL DIGIT
ROR R1
ROR R0
BIC R3, R2 ;; MASK OUT ALL JUNK
ADD #0, R2 ;; MAKE THIS CHAR. ASCII
BR 1\$;; GO PUT IT IN THE DATA TABLE
\$OCTVL: .BLKB 14. ;; RESERVE DATA TABLE
.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

*THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
*DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
*POSITIVE.

*CALL
* MOV #PNTR, -(SP) ;; POINTER TO LOW WORD OF BINARY NUMBER
* JSR PC, @#\$DB20

11254
11255
11256
11257
11258
11259
11260
11261
11262


```

11263 ;* RETURN ;: THE FIRST ADDRESS OF ASCIZ
11264 ;: IS ON THE STACK
11265
11266
11267 $DB2D: SAVREG ;: SAVE REGISTERS
11268 MOV 2(SP),R2 ;: PICKUP THE DATA POINTER
11269 MOV #SDECVL,R0 ;: GET ADDRESS OF "SDECVL" STRING
11270 MOV R0,2(SP) ;: PUT ADDRESS OF ASCIZ STRING ON STACK
11271 MOV (R2)+,R1 ;: PICKUP THE BINARY NUMBER
11272 MOV (R2)+,R2
11273 MOV #10.,4$ ;: SET UP TO DO 10 CONVERSIONS
11274 MOV #STNPWR,R4 ;: ADDRESS OF TEN POWER
11275 MOV #STNPWR+2,R5
11276 1$: CLR R3 ;: CLEAR PARTIAL
11277 2$: SUB (R4),R1 ;: SUBTRACT TEN POWER
11278 SBC R2
11279 SUB (R5),R2
11280 BLT 3$ ;: BR IF TEN POWER TO LARGE
11281 INC R3 ;: ADD 1 TO PARTIAL
11282 BR 2$ ;: LOOP
11283 3$: ADD (R4)+,R1 ;: RESTORE SUBTRACTED VALUE
11284 ADC R2
11285 ADD (R4)+,R2
11286 CMP (R5)+,(R5)+ ;: MOVE TO NEXT TEN POWER
11287 BIS #'0,R3 ;: CHANGE PARTIAL TO ASCII
11288 MOV R3,(R0)+ ;: SAVE IT
11289 DEC (PC)+ ;: DONE?
11290 4$: .WORD 0
11291 BNE 1$ ;: BR IF NO
11292 CLRB (R0)+ ;: TERMINATOR
11293 RESREG ;: RESTORE REGISTERS
11294 RTS PC ;: RETURN
11295 $TNPWR: 145000 ;: 1.0E09
11296 35632
11297 160400 ;: 1.0E08
11298 2765
11299 113200 ;: 1.0E07
11300 230
11301 041100 ;: 1.0E06
11302 17
11303 103240 ;: 1.0E05
11304 1
11305 23420 ;: 1.0E04
11306 0
11307 1750 ;: 1.0E03
11308 0
11309 144 ;: 1.0E02
11310 0
11311 12 ;: 1.0E01
11312 0
11313 1 ;: 1.0E00
11314 0
11315 $DECVL: .BLKB 12. ;: RESERVE STORAGE FOR ASCIZ STRING
11316 .SBTTL TYPE NUMERICAL ASCIZ STRING SUPPRESS LEADING ZEROS
11317
11318 ;:*****

```

```

11319 ;*THIS ROUTINE IS USED TO TYPE AN ASCIZ NUMBER SUPPRESSING THE
11320 ;*LEADING NUMBERS.
11321 ;*CALL
11322 ;*      MOV      #NUMADR,-(SP)      ;;FIRST ADDRESS OF ASCIZ STRING
11323 ;*      JSR      PC,@#$$SUPRS
11324
11325
11326 055752 010046          $$SUPRS: MOV      RO,-(SP)      ;;SAVE RO
11327 055754 016600 000004 1$:      MOV      4(SP),RO      ;;PICKUP THE POINTER
11328 055760 105710          TSTB      (RO)      ;;TERMINATEOR?
11329 055762 001403          BEQ      2$      ;;BR IF YES
11330 055764 122720 000060 2$:      CMPB      #'0,(RO)+      ;;IS THIS AN ASCII "0" ?
11331 055770 001773          BEQ      1$      ;;BR IF YES
11332 055772 005300          DEC      RO      ;;BACKUP BY "1"
11333 055774 010037 056002 3$:      MOV      RO,3$      ;;SAVE FOR TYPING
11334 056000 104401          TYPE      ;;GO TYPE
11335 056002 000000          .WORD      0      ;;ASCIZ POINTER GOES HERE
11336 056004 012600          MOV      (SP)+,RO      ;;RESTORE RO
11337 056006 012616          MOV      (SP)+,(SP)      ;;RESTORE THE STACK
11338 056010 000207          RTS      PC      ;;RETURN
11339
11340 .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
11341
11342 ;*****
11343 ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
11344 ;*OCTAL (ASCII) NUMBER AND TYPE IT.
11345 ;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
11346 ;*CALL:
11347 ;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
11348 ;*      TYPOS      ;;CALL FOR TYPEOUT
11349 ;*      .BYTE      N      ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
11350 ;*      .BYTE      M      ;;M=1 OR 0
11351 ;*      ;;1=TYPE LEADING ZEROS
11352 ;*      ;;0=SUPPRESS LEADING ZEROS
11353 ;*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
11354 ;*$TYPOS OR $TYPOC
11355 ;*CALL:
11356 ;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
11357 ;*      TYPON      ;;CALL FOR TYPEOUT
11358 ;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
11359 ;*CALL:
11360 ;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
11361 ;*      TYPOC      ;;CALL FOR TYPEOUT
11362
11363 056012 017646 000000 056235 $TYPOS: MOV      @2(SP),-(SP)      ;;PICKUP THE MODE
11364 056016 116637 000001 1$:      MOV      1(SP),SOFILL      ;;LOAD ZERO FILL SWITCH
11365 056024 112637 056237 2$:      MOV      (SP)+,SOMODE+1      ;;NUMBER OF DIGITS TO TYPE
11366 056030 062716 000002 3$:      ADD      #2,(SP)      ;;ADJUST RETURN ADDRESS
11367 056034 000406          BR      $TYPON
11368 056036 112737 000001 056235 $TYPOC: MOV      #1,SOFILL      ;;SET THE ZERO FILL SWITCH
11369 056044 112737 000006 056237 4$:      MOV      #6,SOMODE+1      ;;SET FOR SIX(6) DIGITS
11370 056052 112737 000005 056234 $TYPON: MOV      #5,SOCNT      ;;SET THE ITERATION COUNT
11371 056060 010346          MOV      R3,-(SP)      ;;SAVE R3
11372 056062 010446          MOV      R4,-(SP)      ;;SAVE R4
11373 056064 010546          MOV      R5,-(SP)      ;;SAVE R5
11374

```

```

11375 056066 113704 056237          MOVB    $OMODE+1,R4      ;;GET THE NUMBER OF DIGITS TO TYPE
11376 056072 005404          NEG     R4
11377 056074 062704 000006          ADD     #6,R4           ;;SUBTRACT IT FOR MAX. ALLOWED
11378 056100 110437 056236          MOVB    R4,$OMODE       ;;SAVE IT FOR USE
11379 056104 113704 056235          MOVB    $OFILL,R4       ;;GET THE ZERO FILL SWITCH
11380 056110 016605 000012          MOV     12(SP),R5       ;;PICKUP THE INPUT NUMBER
11381 056114 005003          CLR     R3              ;;CLEAR THE OUTPUT WORD
11382 056116 006105          1$:    ROL     R5         ;;ROTATE MSB INTO "C"
11383 056120 000404          BR     3$              ;;GO DO MSB
11384 056122 006105          2$:    ROL     R5         ;;FORM THIS DIGIT
11385 056124 006105          ROL     R5
11386 056126 006105          ROL     R5
11387 056130 010503          MOV     R5,R3
11388 056132 006103          3$:    ROL     R3         ;;GET LSB OF THIS DIGIT
11389 056134 105337 056236          DECB   $OMODE          ;;TYPE THIS DIGIT?
11390 056140 100016          BPL    7$              ;;BR IF NO
11391 056142 042703 177770          BIC    #177770,R3     ;;GET RID OF JUNK
11392 056146 001002          BNE    4$              ;;TEST FOR 0
11393 056150 005704          TST    R4              ;;SUPPRESS THIS 0?
11394 056152 001403          BEQ    5$              ;;BR IF YES
11395 056154 005204          4$:    INC     R4         ;;DON'T SUPPRESS ANYMORE 0'S
11396 056156 052703 000060          BIS    #'0,R3         ;;MAKE THIS DIGIT ASCII
11397 056162 052703 000040          5$:    BIS    #' ,R3     ;;MAKE ASCII IF NOT ALREADY
11398 056166 110337 056232          MOVB   R3,$$          ;;SAVE FOR TYPING
11399 056172 104401 056232          TYPE   8$              ;;GO TYPE THIS DIGIT
11400 056176 105337 056234          7$:    DECB   $OCNT     ;;COUNT BY 1
11401 056202 003347          BGT    2$              ;;BR IF MORE TO DO
11402 056204 002402          BLT    6$              ;;BR IF DONE
11403 056206 005204          INC    R4              ;;INSURE LAST DIGIT ISN'T A BLANK
11404 056210 000744          BR     2$              ;;GO DO THE LAST DIGIT
11405 056212 012605          6$:    MOV     (SP)+,R5  ;;RESTORE R5
11406 056214 012604          MOV     (SP)+,R4       ;;RESTORE R4
11407 056216 012603          MOV     (SP)+,R3       ;;RESTORE R3
11408 056220 016666 000002 000004          MOV     2(SP),4(SP)    ;;SET THE STACK FOR RETURNING
11409 056226 012616          MOV     (SP)+,(SP)
11410 056230 000002          RTI
11411 056232 000          8$:    .BYTE   0         ;;RETURN
11412 056233 000          .BYTE   0         ;;STORAGE FOR ASCII DIGIT
11413 056234 000          $OCNT: .BYTE   0         ;;TERMINATOR FOR TYPE ROUTINE
11414 056235 000          $OFILL: .BYTE   0         ;;OCTAL DIGIT COUNTER
11415 056236 000000          $OMODE: .WORD   0         ;;ZERO FILL SWITCH
11416          .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
11417          ;;*****
11418          ;;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
11419          ;;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
11420          ;;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
11421          ;;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
11422          ;;*REPLACED WITH SPACES.
11423          ;;*CALL:
11424          ;;*
11425          ;;*      MOV     NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
11426          ;;*      TYPDS          ;;GO TO THE ROUTINE
11427          ;;*
11428 056240          $TYPDS: MOV     R0,-(SP)    ;;PUSH R0 ON STACK
11429 056240 010046          MOV     R1,-(SP)    ;;PUSH R1 ON STACK
11430 056242 010146

```

11431	056244	010246			MOV	R2,-(SP)	::	PUSH R2 ON STACK
11432	056246	010346			MOV	R3,-(SP)	::	PUSH R3 ON STACK
11433	056250	010546			MOV	R5,-(SP)	::	PUSH R5 ON STACK
11434	056252	012746	020200		MOV	#20200,-(SP)	::	SET BLANK SWITCH AND SIGN
11435	056256	016605	000020		MOV	20(SP),R5	::	GET THE INPUT NUMBER
11436	056262	100004			BPL	1\$::	BR IF INPUT IS POS.
11437	056264	005405			NEG	R5	::	MAKE THE BINARY NUMBER POS.
11438	056266	112766	000055	000001	MOV	#'-,1(SP)	::	MAKE THE ASCII NUMBER NEG.
11439	056274	005000			CLR	RO	::	ZERO THE CONSTANTS INDEX
11440	056276	012703	056454		MOV	#\$DBLK,R3	::	SETUP THE OUTPUT POINTER
11441	056302	112723	000040		MOV	#',(R3)+	::	SET THE FIRST CHARACTER TO A BLANK
11442	056306	005002			CLR	R2	::	CLEAR THE BCD NUMBER
11443	056310	016001	056444		MOV	\$DTBL(RO),R1	::	GET THE CONSTANT
11444	056314	160105			SUB	R1,R5	::	FORM THIS BCD DIGIT
11445	056316	002402			BLT	4\$::	BR IF DONE
11446	056320	005202			INC	R2	::	INCREASE THE BCD DIGIT BY 1
11447	056322	000774			BR	3\$::	
11448	056324	060105			ADD	R1,R5	::	ADD BACK THE CONSTANT
11449	056326	005702			TST	R2	::	CHECK IF BCD DIGIT=0
11450	056330	001002			BNE	5\$::	FALL THROUGH IF 0
11451	056332	105716			TSTB	(SP)	::	STILL DOING LEADING 0'S?
11452	056334	100407			BMI	7\$::	BR IF YES
11453	056336	106316			ASLB	(SP)	::	MSD?
11454	056340	103003			BCC	6\$::	BR IF NO
11455	056342	116663	000001	177777	MOV	1(SP),-1(R3)	::	YES--SET THE SIGN
11456	056350	052702	000060		BIS	#'0,R2	::	MAKE THE BCD DIGIT ASCII
11457	056354	052702	000040		BIS	#',R2	::	MAKE IT A SPACE IF NOT ALREADY A DIGIT
11458	056360	110223			MOV	R2,(R3)+	::	PUT THIS CHARACTER IN THE OUTPUT BUFFER
11459	056362	005720			TST	(R0)+	::	JUST INCREMENTING
11460	056364	020027	000010		CMP	RO,#10	::	CHECK THE TABLE INDEX
11461	056370	002746			BLT	2\$::	GO DO THE NEXT DIGIT
11462	056372	003002			BGT	8\$::	GO TO EXIT
11463	056374	010502			MOV	R5,R2	::	GET THE LSD
11464	056376	000764			BR	6\$::	GO CHANGE TO ASCII
11465	056400	105726			TSTB	(SP)+	::	WAS THE LSD THE FIRST NON-ZERO?
11466	056402	100003			BPL	9\$::	BR IF NO
11467	056404	116663	177777	177776	MOV	-1(SP),-2(R3)	::	YES--SET THE SIGN FOR TYPING
11468	056412	105013			CLRB	(R3)	::	SET THE TERMINATOR
11469	056414	012605			MOV	(SP)+,R5	::	POP STACK INTO R5
11470	056416	012603			MOV	(SP)+,R3	::	POP STACK INTO R3
11471	056420	012602			MOV	(SP)+,R2	::	POP STACK INTO R2
11472	056422	012601			MOV	(SP)+,R1	::	POP STACK INTO R1
11473	056424	012600			MOV	(SP)+,R0	::	POP STACK INTO R0
11474	056426	104401	056454		TYPE	\$DBLK	::	NOW TYPE THE NUMBER
11475	056432	016666	000002	000004	MOV	2(SP),4(SP)	::	ADJUST THE STACK
11476	056440	012616			MOV	(SP)+,(SP)	::	
11477	056442	000002			RTI		::	RETURN TO USER
11478	056444	023420			\$DTBL:	10000.		
11479	056446	001750				1000.		
11480	056450	000144				100.		
11481	056452	000012				10.		
11482	056454	000004			\$DBLK:	.BLKW 4		
11483					.SBTTL	ERROR HANDLER ROUTINE		
11484								
11485								
11486								

*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,

```

11487 ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
11488 ;*AND GO TO TYPERR ON ERROR
11489 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
11490 ;*SW15=1 HALT ON ERROR
11491 ;*SW13=1 INHIBIT ERROR TYPEOUTS
11492 ;*SW10=1 BELL ON ERROR
11493 ;*SW09=1 LOOF ON ERROR
11494 ;*CALL
11495 ;* ERROR N ;;ERROR=EMT AND N=ERROR ITEM NUMBER
11496
11497 $ERROR:
11498 056464 105237 001103 7$: INCB $ERFLG ;; SET THE ERROR FLAG
11499 056470 001775 BEQ 7$ ;; DON'T LET THE FLAG GO TO ZERO
11500 056472 013777 001102 122442 MOV $STNM,@DISPLAY ;; DISPLAY TEST NUMBER AND ERROR FLAG
11501 056500 032777 002000 122432 BIT #BIT10,@SWR ;; BELL ON ERROR?
11502 056506 001402 BEQ 1$ ;; NO - SKIP
11503 056510 104401 001310 TYPE $BELL ;; RING BELL
11504 056514 005237 001112 1$: INC $ERTTL ;; COUNT THE NUMBER OF ERRORS
11505 056520 011637 001116 MOV (SP), $ERRPC ;; GET ADDRESS OF ERROR INSTRUCTION
11506 056524 162737 000002 001116 SUB #2, $ERRPC
11507 056532 117737 122360 001114 MOVB @ $ERRPC, $ITEMB ;; STRIP AND SAVE THE ERROR ITEM CODE
11508 056540 032777 020000 122372 BIT #BIT13,@SWR ;; SKIP TYPEOUT IF SET
11509 056546 001004 BNE 20$ ;; SKIP TYPEOUTS
11510 056550 004737 043012 JSR PC, TYPERR ;; GO TO USER ERROR ROUTINE
11511 056554 104401 001315 TYPE , $CRLF
11512 056560
11513 056560 122737 000001 001340 20$: CMPB #APTENV, $ENV ;; RUNNING IN APT MODE
11514 056566 001007 BNE 2$ ;; NO SKIP APT ERROR REPORT
11515 056570 113737 001114 056602 MOVB $ITEMB, 21$ ;; SET ITEM NUMBER AS ERROR NUMBER
11516 056576 004737 057444 JSR PC, $ATY4 ;; REPORT FATAL ERROR TO APT
11517 056602 000 21$: .BYTE 0
11518 056603 000 .BYTE 0
11519 056604 000777 22$: BR 22$ ;; APT ERROR LOOP
11520 056606 005777 122326 2$: TST @SWR ;; HALT ON ERROR
11521 056612 100001 BPL 3$ ;; SKIP IF CONTINUE
11522 056614 000000 HALT ;; HALT ON ERROR!
11523 056616 032777 001000 122314 3$: BIT #BIT09,@SWR ;; LOOP ON ERROR SWITCH SET?
11524 056624 001402 BEQ 4$ ;; BR IF NO
11525 056626 013716 001110 MOV $LPERR, (SP) ;; FUDGE RETURN FOR LOOPING
11526 056632 005737 001306 4$: TST $ESCAPE ;; CHECK FOR AN ESCAPE ADDRESS
11527 056636 001402 BEQ 5$ ;; BR IF NONE
11528 056640 013716 001306 5$: MOV $ESCAPE, (SP) ;; FUDGE RETURN ADDRESS FOR ESCAPE
11529 056644
11530 056644 022737 024046 000042 CMP #SENDAD, @#42 ;; ACT-11 AUTO-ACCEPT?
11531 056652 001001 BNE 6$ ;; BRANCH IF NO
11532 056654 000000 HALT ;; YES
11533 056656
11534 056656 000002 6$: RTI ;; RETURN
11535 .SBTTL TTY INPUT ROUTINE
11536
11537 ;*****
11538 .ENABL LSB
11539
11540 .DSABL LSB
11541
11542

```

```

11543 ;:*****
11544 ;:THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
11545 ;:CALL:
11546 ;:RDCHR ;:INPUT A SINGLE CHARACTER FROM THE TTY
11547 ;:RETURN HERE ;:CHARACTER IS ON THE STACK
11548 ;: ;:WITH PARITY BIT STRIPPED OFF
11549 ;:
11550 ;:
11551 056660 011646 000004 000002 $RDCHR: MOV (SP), -(SP) ;: PUSH DOWN THE PC
11552 056662 016666 000004 000002 MOV 4(SP), 2(SP) ;: SAVE THE PS
11553 056670 105777 122250 1$: TSTB @STKS ;: WAIT FOR
11554 056674 100375 BPL 1$ ;: A CHARACTER
11555 056676 117766 122244 000004 MOVB @STKB, 4(SP) ;: READ THE TTY
11556 056704 042766 177600 000004 BIC #C<177>, 4(SP) ;: GET RID OF JUNK IF ANY
11557 056712 026627 000004 000023 CMP 4(SP), #23 ;: IS IT A CONTROL-S?
11558 056720 001013 BNE 3$ ;: BRANCH IF NO
11559 056722 105777 122216 2$: TSTB @STKS ;: WAIT FOR A CHARACTER
11560 056726 100375 BPL 2$ ;: LOOP UNTIL ITS THERE
11561 056730 117746 122212 MOVB @STKB, -(SP) ;: GET CHARACTER
11562 056734 042716 177600 BIC #C177, (SP) ;: MAKE IT 7-BIT ASCII
11563 056740 022627 000021 CMP (SP)+, #21 ;: IS IT A CONTROL-Q?
11564 056744 001366 BNE 2$ ;: IF NOT DISCARD IT
11565 056746 000750 BR 1$ ;: YES, RESUME
11566 056750 026627 000004 000140 3$: CMP 4(SP), #140 ;: IS IT UPPER CASE?
11567 056756 002407 BLT 4$ ;: BRANCH IF YES
11568 056760 026627 000004 000175 CMP 4(SP), #175 ;: IS IT A SPECIAL CHAR?
11569 056766 003003 BGT 4$ ;: BRANCH IF YES
11570 056770 042766 000040 000004 BIC #40, 4(SP) ;: MAKE IT UPPER CASE
11571 056776 000002 4$: RTI ;: GO BACK TO USER
11572 057000 052536 005015 000 $CNTLU: .ASCIZ /#U/<15><12> ;: CONTROL "U"
11573 057005 136 006507 000012 $CNTLG: .ASCIZ /#G/<15><12> ;: CONTROL "G"
11574 057012 005015 053523 020122 $MSWR: .ASCIZ <15><12>/SWR = /
11575 057020 020075 000
11576 057023 040 047040 053505 $MNEW: .ASCIZ / NEW = /
11577 057030 036440 000040
11578
11579
11580
11581 .SBTTL POWER DOWN AND UP ROUTINES
11582
11583 :POWER DOWN ROUTINE
11584 057034 012737 057046 000024 $PWRDN: MOV #SPWRUP, PWRVEC ;: SET VECTOR FOR POWER UP
11585 057042 000000 HALT ;: HANG UP
11586 057044 000776 BR .-2
11587
11588 :POWER UP ROUTINE
11589 057046 005037 057120 $PWRUP: CLR $PWRCT ;: WAIT LOOP FOR TTY TO COME UP
11590 057052 005237 057120 4$: INC $PWRCT
11591 057056 001375 BNE 4$
11592 057060 012737 057034 000024 MOV #SPWRDN, PWRVEC ;: SET VECTOR FOR POWER DOWN
11593 057066 012737 000340 000026 MOV #PR7, PWRVEC+2 ;: RE-ESTABLISH POWER AND TRAP PRIORITIES
11594 057074 012737 000340 000036 MOV #PR7, TRAPVEC+2
11595 057102 012706 001100 MOV #STACK, SP ;: RE-INITIALIZE THE STACK
11596 057106 104401 057122 TYPE ,PWRMSG ;: TYPE "POWER FAILED"
11597 057112 000005 RESET ;: CLEAR THE UNIBUS
11598 057114 000177 121766 JMP @SLPADR ;: RESTART THE CURRENT TEST

```

```

11599 057120 000000
11600 057122 005015 047520 042527
11601 057130 020122 040506 046111
11602 057136 042105 005015 000
11603 057144
11604
11605
11606
11607
11608
11609
11610
11611 057144 105737 001103
11612 057150 001406
11613 057152 032777 001000 121760
11614 057160 001402
11615 057162 013716 001110
11616 057166 000002
11617
11618
11619
11620
11621
11622
11623
11624
11625
11626
11627
11628
11629
11630
11631
11632
11633 057170
11634 057170 005737 001304
11635 057174 001404
11636 057176 032777 040000 121734
11637 057204 001101
11638
11639 057206 000416
11640
11641 057210 013746 000004
11642 057214 012737 057234 000004
11643 057222 005737 177060
11644 057226 012637 000004
11645 057232 000450
11646 057234 022626
11647 057236 012637 000004
11648 057242 000413
11649 057244
11650 057244 105737 001103
11651 057250 001421
11652 057252 123737 001115 001103
11653 057260 101015
11654 057262 032777 001000 121650

```

```

$PWRCT: .WORD 0
PWRMSG: .ASCIZ <15><12>/POWER FAILED/<15><12>
.EVEN

```

```

;*****
;* SCOPE1 - INTERNAL SCOPE ON ERROR ROUTINE
;* CALLED BY "SCOPER"
;*****
SCOPE1: TSTB $ERFLG ;SEE IF AN ERROR HAS OCCURRED
        BEQ 6$ ;BR IF NOT
        BIT #BIT9,$SWR ;SEE IF LOOP ON ERROR DESIRED
        BEQ 6$ ;BR IF NOT
        MOV $LPERR,(SP) ;SET ERROR LOOP ADDRESS ON STACK
6$: RTI ;RETURN

```

.SBTTL SCOPE HANDLER ROUTINE

```

;*****
;* THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;* AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;* AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;* THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;* SW14=1 LOOP ON TEST
;* SW11=1 INHIBIT ITERATIONS
;* SW09=1 LOOP ON ERROR
;* CALL SCOPE ;;SCOPE=IOT

```

```

$SCOPE:
        TST $TIMES ;CHECK CURRENT ITERATION NUMBER
        BEQ $XTSTR ;BR IF 0, TO SKIP CHECK OF SWR BIT 14
1$: BIT #BIT14,$SWR ;LOOP ON PRESENT TEST?
        BNE $OVER ;YES IF SW14=1
;*****START OF CODE FOR THE XOR TESTER*****
$XTSTR: BR 6$ ;IF RUNNING ON THE "XOR" TESTER CHANGE
        ;THIS INSTRUCTION TO A "NOP" (NOP=240)
        MOV @#ERRVEC, -(SP) ;SAVE THE CONTENTS OF THE ERROR VECTOR
        MOV #5,$@#ERRVEC ;SET FOR TIMEOUT
        TST @#177060 ;TIME OUT ON XOR?
        MOV (SP)+, @#ERRVEC ;RESTORE THE ERROR VECTOR
        BR $SVLAD ;GO TO THE NEXT TEST
5$: CMP (SP)+, (SP)+ ;CLEAR THE STACK AFTER A TIME OUT
        MOV (SP)+, @#ERRVEC ;RESTORE THE ERROR VECTOR
        BR 7$ ;LOOP ON THE PRESENT TEST
6$; *****END OF CODE FOR THE XOR TESTER*****
2$: TSTB $ERFLG ;HAS AN ERROR OCCURRED?
        BEQ 3$ ;BR IF NO
        CMPB $ERMAX,$ERFLG ;MAX. ERRORS FOR THIS TEST OCCURRED?
        BHI 3$ ;BR IF NO
        BIT #BIT09,$SWR ;LOOP ON ERROR?

```

```

11655 057270 001404          BEQ      4$          ;; BR IF NO
11656 057272 013737 001110 001106 7$:      MOV      $LPERR,$LPADR ;; SET LOOP ADDRESS TO LAST SCOPE
11657 057300 000443          BR       $OVER      ;;
11658 057302 105037 001103 4$:      CLR     $ERFLG      ;; ZERO THE ERROR FLAG
11659 057306 005037 001304          CLR     $TIMES      ;; CLEAR THE NUMBER OF ITERATIONS TO MAKE
11660 057312 000412          BR       1$          ;; ESCAPE TO THE NEXT TEST
11661 057314 032777 004000 121616 3$:      BIT     #BIT11,$SWR  ;; INHIBIT ITERATIONS?
11662 057322 001006          BNE     1$          ;; BR IF YES
11663 057324 005237 001104          INC     $ICNT       ;; INCREMENT ITERATION COUNT
11664 057330 023737 001304 001104          CMP     $TIMES,$ICNT ;; CHECK THE NUMBER OF ITERATIONS MADE
11665 057336 002024          BGE     $OVER      ;; BR IF MORE ITERATION REQUIRED
11666 057340 012737 000001 001104 1$:      MOV     #1,$ICNT    ;; REINITIALIZE THE ITERATION COUNTER
11667 057346 013737 057424 001304          MOV     $MXCNT,$TIMES ;; SET NUMBER OF ITERATIONS TO DO
11668 057354 105237 001102          $SVLAD: INCB    $STNM      ;; COUNT TEST NUMBERS
11669 057360 113737 001102 001324          MOV     $STNM,$STNM ;; SET TEST NUMBER IN APT MAILBOX
11670 057366 011637 001106          MOV     (SP),$LPADR ;; SAVE SCOPE LOOP ADDRESS
11671 057372 011637 001110          MOV     (SP),$LPERR ;; SAVE ERROR LOOP ADDRESS
11672 057376 005037 001306          CLR     $ESCAPE     ;; CLEAR THE ESCAPE FROM ERROR ADDRESS
11673 057402 112737 000001 001115          MOV     #1,$ERMAX   ;; ONLY ALLOW ONE(1) ERROR ON NEXT TEST
11674 057410 013777 001102 121524 $OVER:  MOV     $STNM,$DISPLAY ;; DISPLAY TEST NUMBER
11675 057416 013716 001106          MOV     $LPADR,(SP) ;; FUDGE RETURN ADDRESS
11676 057422 000002          RTI                    ;; FIXES PS
11677 057424 003720          $MXCNT: 2000          ;; MAX. NUMBER OF ITERATIONS
11678          .SBTTL  APT COMMUNICATIONS ROUTINE
11679
11680          ..*****
11681 057426 112737 000001 057672 $ATY1:  MOV     #1,$FFLG    ;; TO REPORT FATAL ERROR
11682 057434 112737 000001 057670 $ATY3:  MOV     #1,$MFLG    ;; TO TYPE A MESSAGE
11683 057442 000403          BR       $ATYC      ;;
11684 057444 112737 000001 057672 $ATY4:  MOV     #1,$FFLG    ;; TO ONLY REPORT FATAL ERROR
11685 057452          $ATYC:
11686 057452 010046          MOV     R0,-(SP)    ;; PUSH R0 ON STACK
11687 057454 010146          MOV     R1,-(SP)    ;; PUSH R1 ON STACK
11688 057456 105737 057670          TST     $MFLG      ;; SHOULD TYPE A MESSAGE?
11689 057462 001450          BEQ     5$          ;; IF NOT: BR
11690 057464 122737 000001 001340          CMP     #APTENV,$ENV ;; OPERATING UNDER APT?
11691 057472 001031          BNE     3$          ;; IF NOT: BR
11692 057474 132737 000100 001341          BIT     #APTSPOOL,$ENVM ;; SHOULD SPOOL MESSAGES?
11693 057502 001425          BEQ     3$          ;; IF NOT: BR
11694 057504 017600 000004          MOV     @4(SP),R0   ;; GET MESSAGE ADDR.
11695 057510 062766 000002 000004          ADD     #2,4(SP)    ;; BUMP RETURN ADDR.
11696 057516 005737 001320 1$:      TST     $MSGTYPE    ;; SEE IF DONE W/ LAST XMISSION?
11697 057522 001375          BNE     1$          ;; IF NOT: WAIT
11698 057524 010037 001334          MOV     R0,$MSGAD  ;; PUT ADDR IN MAILBOX
11699 057530 105720 2$:      TST     (R0)+       ;; FIND END OF MESSAGE
11700 057532 001376          BNE     2$          ;;
11701 057534 163700 001334          SUB     $MSGAD,R0   ;; SUB START OF MESSAGE
11702 057540 006200          ASR     R0          ;; GET MESSAGE LNTH IN WORDS
11703 057542 010037 001336          MOV     R0,$MSGGLT ;; PUT LENGTH IN MAILBOX
11704 057546 012737 000004 001320          MOV     #4,$MSGTYPE ;; TELL APT TO TAKE MSG.
11705 057554 000413          BR       5$          ;;
11706 057556 017637 000004 057602 3$:      MOV     @4(SP),4$    ;; PUT MSG ADDR IN JSR LINKAGE
11707 057564 062766 000002 000004          ADD     #2,4(SP)    ;; BUMP RETURN ADDRESS
11708 057572 013746 177776          MOV     177776,-(SP) ;; PUSH 177776 ON STACK
11709 057576 004737 054736          JSR     PC,$TYPE    ;; CALL TYPE MACRO
11710 057602 000000          4$:      .WORD  0

```



```

11711 057604
11712 057604 105737 057672
11713 057610 001416
11714 057612 005737 001340
11715 057616 001413
11716 057620 005737 001320
11717 057624 001375
11718 057626 017637 000004 001322
11719 057634 062766 000002 000004
11720 057642 005237 001320
11721 057646 105037 057672
11722 057652 105037 057671
11723 057656 105037 057670
11724 057662 012601
11725 057664 012600
11726 057666 000207
11727 057670 000
11728 057671 000
11729 057672 000
11730 057674
11731 000200
11732 000001
11733 000100
11734 000040
11735
11736
11737
11738
11739
11740
11741
11742
11743
11744
11745
11746
11747
11748
11749
11750
11751 057674 010046
11752 057676 010146
11753 057700 010246
11754 057702 010346
11755 057704 013746 000004
11756 057710 013746 000006
11757 057714 010600
11758
11759 057716 104400
11760 057720 012637 000006
11761 057724 012701 003776
11762 057730 105727
11763 057732 000200
11764 057734 100062
11765 057736 012737 060074 000004
11766 057744 005737 177572

```

```

SS:
10$: TSTB $FFLG ;; SHOULD REPORT FATAL ERROR?
      BEQ 12$ ;; IF NOT: BR
      TST $ENV ;; RUNNING UNDER APT?
      BEQ 12$ ;; IF NOT: BR
11$: TST $MSGTYPE ;; FINISHED LAST MESSAGE?
      BNE 11$ ;; IF NOT: WAIT
      MOV @4(SP), $FATAL ;; GET ERROR #
      ADD #2, 4(SP) ;; BUMP RETURN ADDR.
      INC $MSGTYPE ;; TELL APT TO TAKE ERROR
12$: CLRB $FFLG ;; CLEAR FATAL FLAG
      CLRB $LFLG ;; CLEAR LOG FLAG
      CLRB $MFLG ;; CLEAR MESSAGE FLAG
      MOV (SP)+, R1 ;; POP STACK INTO R1
      MOV (SP)+, R0 ;; POP STACK INTO R0
      RTS PC ;; RETURN
$MFLG: .BYTE 0 ;; MESSG. FLAG
$LFLG: .BYTE 0 ;; LOG FLAG
$FFLG: .BYTE 0 ;; FATAL FLAG
      .EVEN

```

```

APTSIZE=200
APTENV=001
APTPOOL=100
APTCSUP=040
.SBTTL ROUTINE TO SIZE MEMORY

```

```

*****
*CALL:
* JSR PC, $SIZE
* RETURN
*$LSTAD WILL CONTAIN:
* WITH KT11 OPTION -- LAST VIRTUAL ADDRESS OF THE LAST BANK
* WITHOUT KT11 OPTION -- LAST ABSOLUTE ADDRESS OF AVAILABLE MEMORY
*$LSTBK WILL CONTAIN THE LAST BANK AS A SAF
*$KT11 IS THE MEMORY MANAGEMENT KEY
*$BIT07 = 0 DON'T USE MEMORY MANAGEMENT
* MUST BE SETUP BEFORE THE CALL
*$BIT15 = 0 DON'T HAVE MEMORY MANAGEMENT OPTION
* DETERMINED BY ROUTINE

```

```

$SIZE: MOV R0, -(SP) ;; SAVE R0 ON THE STACK
      MOV R1, -(SP) ;; SAVE R1 ON THE STACK
      MOV R2, -(SP) ;; SAVE R2 ON THE STACK
      MOV R3, -(SP) ;; SAVE R3 ON THE STACK
      MOV @#ERRVEC, -(SP) ;; SAVE PRESENT ERROR VECTOR PS & PC
      MOV @#ERRVEC+2, -(SP)
      MOV SP, R0 ;; SAVE THE STACK POINTER
;; SET THE ERRVEC PS TO THE PRESENT PS
      TRAP ;; PUSH OLD PSW AND PC ON STACK
      MOV (SP)+, @#ERRVEC+2 ;; SAVE THE PSW IN @#ERRVEC+2
      MOV #3776, R1 ;; SETUP ADDRESS
      TSTB (PC)+ ;; USE MEMORY MANAGEMENT?
$KT11: .WORD 200 ;; SET TO USE MEMORY MANAGEMENT
      BPL $SCORE ;; BR IF NO
      MOV # $KTNEX, @#ERRVEC ;; SET FOR TIMEOUT
      TST @#SR0 ;; KT11 ARE YOU THERE?

```

```

11767 057750 052737 100000 057732 BIS #100000,$KT11 ;;YES--SET KT11 KEY
11768 057756 005046 CLR -(SP) ;;INITIALIZE FOR "PAR" LOADING
11769 057760 012702 172340 MOV #KIPAR0,R2 ;;ADDRESS OF FIRST "PAR"
11770 057764 012703 000010 MOV #↑DB,R3 ;;LOAD EIGHT "PAR.'S" AND EIGHT "PDR.'S"
11771 057770 012762 077406 177740 1$: MOV #77406,-40(R2) ;;PDR = 4K UP, READ/WRITE
11772 057776 011622 MOV (SP),(R2)+ ;;LOAD "PAR"
11773 060000 062716 000200 ADD #200,(SP) ;;UPDATE FOR NEXT "PAR"
11774 060004 077307 SOB R3,1$ ;;LOOP UNTIL ALL EIGHT ARE LOADED
11775 060006 012742 177600 MOV #177600,-(R2) ;;SETUP KIPAR7 FOR I/O
11776 060012 005042 CLR -(R2) ;;SETUP KIPAR6 FOR TESTING
11777 060014 012737 060032 000004 MOV #2$,@#ERRVEC ;;CATCH TIMEOUT IF NO SR3
11778 060022 012737 000020 172516 MOV #20,@#SR3 ;;ENABLE 22 BIT MODE
11779 060030 000401 BR 3$ ;;THIS PDP-11 HAS A SR3 REGISTER
11780 060032 022626 2$: CMP (SP)+,(SP)+ ;;CLEAN OFF THE STACK--NO SR3
11781 060034 005237 177572 3$: INC @#SR0 ;;TURN ON MEMORY MANAGEMENT
11782 060040 012737 060064 000004 MOV #SKTOUT,@#ERRVEC ;;SET FOR TIME OUT
11783 060046 005737 143776 4$: TST @#143776 ;;TRAP ON NON-EX-MEM
11784 060052 062712 000040 ADD #40,(R2) ;;MAKE A 1K STEP
11785 060056 023712 172356 CMP @#KIPAR7,(R2) ;;LAST ONE?
11786 060062 101371 BHI 4$ ;;NO--TRY IT
11787 060064 011202 SKTOUT: MOV (R2),R2 ;;GET LAST BANK+1
11788 060066 005037 177572 CLR @#SR0 ;;TURN OFF MEMORY MANAGEMENT
11789 060072 000421 BR $SIZEX
11790 060074 042737 100000 057732 SKTNEX: BIC #100000,$KT11 ;;KT11 NON-EXISTENT
11791 060102 012737 060132 000004 SCORE: MOV #SCROUT,@#ERRVEC ;;SET FOR TIMEOUT
11792 060110 005002 CLR R2 ;;SET UP BANK
11793 060112 062701 004000 1$: ADD #4000,R1 ;;INCREMENT BY 1K
11794 060116 062702 000040 ADD #40,R2 ;;1K STEP
11795 060122 005711 TST (R1) ;;TRAP ON TIME OUT
11796 060124 022701 177776 CMP #177776,R1 ;;LAST ONE
11797 060130 001370 BNE 1$ ;;NO--TRY AGAIN
11798 060132 162701 004000 SKROUT: SUB #4000,R1
11799 060136 162702 000040 $SIZEX: SUB #40,R2 ;;DROP BACK
11800 060142 010006 MOV RO,SP ;;RESTORE THE STACK
11801 060144 012637 000006 MOV (SP)+,@#ERRVEC+2 ;;RESTORE ERROR VECTOR
11802 060150 012637 000004 MOV (SP)+,@#ERRVEC
11803 060154 010137 060176 MOV R1,$LSTAD ;;LAST ADDRESS
11804 060160 010237 060200 MOV R2,$LSTBK ;;LAST BANK
11805 060164 012603 MOV (SP)+,R3 ;;RESTORE R3
11806 060166 012602 MOV (SP)+,R2 ;;RESTORE R2
11807 060170 012601 MOV (SP)+,R1 ;;RESTORE R1
11808 060172 012600 MOV (SP)+,RO ;;RESTORE RO
11809 060174 000207 RTS PC
11810 060176 000000 $LSTAD: .WORD 0 ;;CONTAINS THE LAST ADDRESS
11811 060200 000000 $LSTBK: .WORD 0 ;;CONTAINS THE LAST BANK
11812 .SBTTL SAVE AND RESTORE RO-R5 ROUTINES
11813
11814 ;*****
11815 ;*SAVE RO-R5
11816 ;*CALL:
11817 ;* SAVREG
11818 ;*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
11819 ;*
11820 ;*TOP---(+16)
11821 ;* +2---(+18)
11822 ;* +4---R5

```

11823
11824
11825
11826
11827
11828
11829 060202
11830 060202 010046
11831 060204 010146
11832 060206 010246
11833 060210 010346
11834 060212 010446
11835 060214 010546
11836 060216 016646 000022
11837 060222 016646 000022
11838 060226 016646 000022
11839 060232 016646 000022
11840 060236 000002

```

;* +5---R4
;* +8---R3
;* +10---R2
;* +12---R1
;* +14---R0

$SAVREG:
MOV RO,-(SP)      ;; PUSH R0 ON STACK
MOV R1,-(SP)      ;; PUSH R1 ON STACK
MOV R2,-(SP)      ;; PUSH R2 ON STACK
MOV R3,-(SP)      ;; PUSH R3 ON STACK
MOV R4,-(SP)      ;; PUSH R4 ON STACK
MOV R5,-(SP)      ;; PUSH R5 ON STACK
MOV 22(SP),-(SP)  ;; SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP)  ;; SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP)  ;; SAVE PS OF CALL
MOV 22(SP),-(SP)  ;; SAVE PC OF CALL
RTI

```

11841
11842
11843
11844
11845 060240
11846 060240 012666 000022
11847 060244 012666 000022
11848 060250 012666 000022
11849 060254 012666 000022
11850 060260 012605
11851 060262 012604
11852 060264 012603
11853 060266 012602
11854 060270 012601
11855 060272 012600
11856 060274 000002

```

;*RESTORE RO-R5
;*CALL:
;* RESREG
$RESREG:
MOV (SP)+,22(SP)  ;; RESTORE PC OF CALL
MOV (SP)+,22(SP)  ;; RESTORE PS OF CALL
MOV (SP)+,22(SP)  ;; RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP)  ;; RESTORE PS OF MAIN FLOW
MOV (SP)+,R5      ;; POP STACK INTO R5
MOV (SP)+,R4      ;; POP STACK INTO R4
MOV (SP)+,R3      ;; POP STACK INTO R3
MOV (SP)+,R2      ;; POP STACK INTO R2
MOV (SP)+,R1      ;; POP STACK INTO R1
MOV (SP)+,R0      ;; POP STACK INTO R0
RTI

```

.SBTTL TRAP DECODER

11857
11858
11859
11860
11861
11862
11863
11864
11865 060276 010046
11866 060300 016600 000002
11867 060304 005740
11868 060306 111000
11869 060310 006300
11870 060312 016000 060332
11871 060316 000200

```

*****
;THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
;AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
;OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
;GO TO THAT ROUTINE.
$TRAP:
MOV RO,-(SP)      ;; SAVE RO
MOV 2(SP),RO      ;; GET TRAP ADDRESS
TST -(RO)         ;; BACKUP BY 2
MOVB (RO),RO      ;; GET RIGHT BYTE OF TRAP
ASL RO            ;; POSITION FOR INDEXING
MOV $TRPAD(RO),RO ;; INDEX TO TABLE
RTS RO            ;; GO TO ROUTINE

```

;;THIS IS USE TO HANDLE THE "GETPRI" MACRO

11872
11873
11874
11875
11876 060320 011646
11877 060322 016666 000004 000002
11878 060330 000002

```

$TRAP2:
MOV (SP),-(SP)    ;; MOVE THE PC DOWN
MOV 4(SP),2(SP)  ;; MOVE THE PSW DOWN
RTI               ;; RESTORE THE PSW

```

11879
11880
11881
11882
11883
11884
11885
11886
11887 060332 060320
11888 060334 054736
11889 060336 056036
11890 060340 056012
11891 060342 056052
11892 060344 056240
11893
11894
11895 060346 056660
11896 060350 060202
11897 060352 060240
11898 060354 057144
11899
11900 060356 020040 020040 042524
11901 060364 052123 000040
11902 060370 025052 020040 000
11903 060375 125 044516 052502
11904 060402 020123 040520 020122
11905 060410 051105 000122
11906 060414 047516 026516 054105
11907 060422 051511 020124 042515
11908 060430 000115
11909 060432 047516 026516 054105
11910 060440 051511 020124 051104
11911 060446 000126
11912 060450 047125 052111 043040
11913 060456 042511 042114 042440
11914 060464 051122 000
11915 060467 123 041125 054523
11916 060474 020123 044524 042515
11917 060502 052517 000124
11918 060506 020104 047524 041440
11919 060514 050040 051101 042440
11920 060522 051122 000
11921 060525 103 052040 020117
11922 060532 020104 040520 020122
11923 060540 051105 000122
11924 060544 041501 046040 053517
11925 060552 000
11926 060553 123 042520 042105
11927 060560 046040 051517 000123
11928 060566 046111 020114 052506
11929 060574 041516 000124
11930 060600 051120 043517 042440
11931 060606 051122 000
11932 060611 116 047117 042455
11933 060616 044530 052123 043040
11934 060624 047125 052103 000

.SBTTL TRAP TABLE

;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
;*BY THE "TRAP" INSTRUCTION.

ROUTINE

;\$TRPAD: .WORD \$STRAP2
 \$TYPE ::CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
 \$TYPOC ::CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
 \$TYPOS ::CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
 \$TYPON ::CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
 \$TYPDS ::CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)

 \$RDCHR ::CALL=RDCHR TRAP+6(104406) TTY TYPEIN CHARACTER ROUTINE
 \$SAVREG ::CALL=SAVREG TRAP+7(104407) SAVE R0-R5 ROUTINE
 \$RESREG ::CALL=RESREG TRAP+10(104410) RESTORE R0-R5 ROUTINE
 SCOPEI ::CALL=SCOPEI TRAP+11(104411) INTERNAL LOOP ON ERROR ROUTINE

TSTMSG: .ASCIZ / TEST /
 AS2SP2: .ASCIZ /** /
 EM1: .ASCIZ /UNIBUS PAR ERR/

 EM2: .ASCIZ /NON-EXIST MEM/

 EM3: .ASCIZ /NON-EXIST DRV/

 EM4: .ASCIZ /UNIT FIELD ERR/

 EM5: .ASCIZ /SUBSYS TIMEOUT/

 EM6: .ASCIZ /D TO C PAR ERR/

 EM7: .ASCIZ /C TO D PAR ERR/

 EM10: .ASCIZ /AC LOW/

 EM11: .ASCIZ /SPEED LOSS/

 EM12: .ASCIZ /ILL FUNCT/

 EM13: .ASCIZ /PROG ERR/

 EM14: .ASCIZ /NON-EXIST FUNCT/

11935	060631	104	053122	052040	EM15:	.ASCIZ	/DRV TYP ERR/
11936	060636	050131	042440	051122			
11937	060644	000					
11938	060645	106	040515	020124	EM16:	.ASCIZ	/FMAT ERR/
11939	060652	051105	000122				
11940	060656	051127	020124	047514	EM17:	.ASCIZ	/WRT LOCK ERR/
11941	060664	045503	042440	051122			
11942	060672	000					
11943	060673	104	053122	052440	EM20:	.ASCIZ	/DRV UNSAFE/
11944	060700	051516	043101	000105			
11945	060706	042523	045505	044440	EM21:	.ASCIZ	/SEEK INCOMP/
11946	060714	041516	046517	000120			
11947	060722	054503	020114	053117	EM22:	.ASCIZ	/CYL OVRFLO/
11948	060730	043122	047514	000			
11949	060735	111	046114	041440	EM23:	.ASCIZ	/ILL CYL ADDR/
11950	060742	046131	040440	042104			
11951	060750	000122					
11952	060752	051104	020126	043117	EM24:	.ASCIZ	/DRV OFF TRACK/
11953	060760	020106	051124	041501			
11954	060766	000113					
11955	060770	051104	020126	044524	EM25:	.ASCIZ	/DRV TIMING ERR/
11956	060776	044515	043516	042440			
11957	061004	051122	000				
11958	061007	104	052101	020101	EM26:	.ASCIZ	/DATA LATE/
11959	061014	040514	042524	000			
11960	061021	103	047117	051124	EM27:	.ASCIZ	/CONTR TIMEOUT/
11961	061026	052040	046511	047505			
11962	061034	052125	000				
11963	061037	117	042520	040522	EM30:	.ASCIZ	/OPERATION INCOMP/
11964	061044	044524	047117	044440			
11965	061052	041516	046517	000120			
11966	061060	042510	042101	051105	EM31:	.ASCIZ	/HEADER VRC ERR/
11967	061066	053040	041522	042440			
11968	061074	051122	000				
11969	061077	104	052101	020101	EM32:	.ASCIZ	/DATA CHECK ERR/
11970	061104	044103	041505	020113			
11971	061112	051105	000122				
11972	061116	051127	020124	044103	EM33:	.ASCIZ	/WRT CHK ERR/
11973	061124	020113	051105	000122			
11974	061132	040504	040524	046440	EM34:	.ASCIZ	/DATA MISCOMPARE/
11975	061140	051511	047503	050115			
11976	061146	051101	000105				
11977	061152	047516	042040	053122	EM35:	.ASCIZ	/NO DRV RESPONSE-UFE & NXD/
11978	061160	051040	051505	047520			
11979	061166	051516	026505	043125			
11980	061174	020105	020046	054116			
11981	061202	000104					
11982	061204	051104	020126	051105	EM36:	.ASCIZ	/DRV ERR WILL NOT CLEAR/
11983	061212	020122	044527	046114			
11984	061220	047040	052117	041440			
11985	061226	042514	051101	000			
11986	061233	104	053122	051440	EM37:	.ASCIZ	/DRV STATUS CHANGE WILL NOT CLEAR/
11987	061240	040524	052524	020123			
11988	061246	044103	047101	042507			
11989	061254	053440	046111	020114			
11990	061262	047516	020124	046103			

11991	061270	040505	000122				
11992	061274	052101	023524	020116	EM40:	.ASCIZ	/ATT'N BUT NO STATUS CHANGE OR FAULT/
11993	061302	052502	020124	047516			
11994	061310	051440	040524	052524			
11995	061316	020123	044103	047101			
11996	061324	042507	047440	020122			
11997	061332	040506	046125	000124			
11998	061340	052101	023524	020116	EM41:	.ASCIZ	/ATT'N BUT DRV NOT AVAIL/
11999	061346	052502	020124	051104			
12000	061354	020126	047516	020124			
12001	061362	053101	044501	000114			
12002	061370	052101	023524	020116	EM42:	.ASCIZ	/ATT'N WHEN NOT EXPECTED/
12003	061376	044127	047105	047040			
12004	061404	052117	042440	050130			
12005	061412	041505	042524	000104			
12006	061420	051105	020122	040507	EM43:	.ASCIZ	/ERR GATHERING DRV STATUS/
12007	061426	044124	051105	047111			
12008	061434	020107	051104	020126			
12009	061442	052123	052101	051525			
12010	061450	000					
12011	061451	115	046125	020124	EM52:	.ASCIZ	/MULT DRV SEL/
12012	061456	051104	020126	042523			
12013	061464	000114					
12014	061466	042510	042101	051105	EM53:	.ASCIZ	/HEADER COMPARE ERR/
12015	061474	041440	046517	040520			
12016	061502	042522	042440	051122			
12017	061510	000					
12018	061511	123	041125	054523	EM56:	.ASCIZ	/SUBSYS TIMEOUT/
12019	061516	020123	044524	042515			
12020	061524	052517	000124				
12021	061530	051105	020122	047111	EM60:	.ASCIZ	/ERR IN RECAL FOR RECOVERY/
12022	061536	051040	041505	046101			
12023	061544	043040	051117	051040			
12024	061552	041505	053117	051105			
12025	061560	000131					
12026	061562	051104	050117	044520	EM61:	.ASCIZ	/DROPPING DRIVE FATAL ERROR/
12027	061570	043516	042040	044522			
12028	061576	042526	043040	052101			
12029	061604	046101	042440	051122			
12030	061612	051117	000				
12031	061615	103	046131	046440	EM62:	.ASCIZ	/CYL MISCMP/
12032	061622	051511	047503	050115			
12033	061630	000					
12034	061631	103	042514	051101	EM63:	.ASCIZ	/CLEAR CONTR DID NOT CLEAR ERR/
12035	061636	041440	047117	051124			
12036	061644	042040	042111	047040			
12037	061652	052117	041440	042514			
12038	061660	051101	042440	051122			
12039	061666	000					
12040	061667	116	020117	052101	EM64:	.ASCIZ	/NO ATT'N IN ATT'N REG/
12041	061674	023524	020116	047111			
12042	061702	040440	052124	047047			
12043	061710	051040	043505	000			
12044	061715	125	051516	046117	EM65:	.ASCIZ	/UNSOLICITED ATT'N/
12045	061722	041511	052111	042105			
12046	061730	040440	052124	047047			

E03

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05MACY11 30A(1052) 10-JAN-78 12:02 PAGE 238
TRAP TABLE

SEQ 0237

12047	061736	000				
12048	061737	125	042516	050130	EM66:	.ASCIZ /UNEXPECTED DATA ERR/
12049	061744	041505	042524	020104		
12050	061752	040504	040524	042440		
12051	061760	051122	000			
12052	061763	101	052124	047047	EM67:	.ASCIZ /ATT'N DID NOT RESET WITH CLEAR/
12053	061770	042040	042111	047040		
12054	061776	052117	051040	051505		
12055	062004	052105	053440	052111		
12056	062012	020110	046103	040505		
12057	062020	000122				
12058	062022	052523	051502	051531	EM70:	.ASCIZ /SUBSYS CLEAR DID NOT CLEAR DRV ATT'N/
12059	062030	041440	042514	051101		
12060	062036	042040	042111	047040		
12061	062044	052117	041440	042514		
12062	062052	051101	042040	053122		
12063	062060	040440	052124	047047		
12064	062066	000				
12065	062067	104	052101	020101	EM71:	.ASCIZ /DATA LATE WHEN UNLOADING HEADER/
12066	062074	040514	042524	053440		
12067	062102	042510	020116	047125		
12068	062110	047514	042101	047111		
12069	062116	020107	042510	042101		
12070	062124	051105	000			
12071	062127	103	047117	051124	EM72:	.ASCIZ /CONTR ERR WHEN DRIVER SERV/
12072	062134	042440	051122	053440		
12073	062142	042510	020116	051104		
12074	062150	053111	051105	051440		
12075	062156	051105	000126			
12076	062162	051104	020126	042504	EM73:	.ASCIZ /DRV DET PAR ERR/
12077	062170	020124	040520	020122		
12078	062176	051105	000122			
12079	062202	047125	042504	020106	EM74:	.ASCIZ /UNDEF ERR/
12080	062210	051105	000122			
12081	062214	040515	045522	047111	EM75:	.ASCIZ /MARKING THIS SECTOR BAD/
12082	062222	020107	044124	051511		
12083	062230	051440	041505	047524		
12084	062236	020122	040502	000104		
12085	062244	040502	020104	040504	EM76:	.ASCIZ /BAD DATA VERIF'N WITH READ. ECC OF LAST RETRY IS:/
12086	062252	040524	053040	051105		
12087	062260	043111	047047	053440		
12088	062266	052111	020110	042522		
12089	062274	042101	020056	041505		
12090	062302	020103	043117	046040		
12091	062310	051501	020124	042522		
12092	062316	051124	020131	051511		
12093	062324	000072				
12094	062326	042522	051124	020131	EM77:	.ASCIZ /RETRY SUCCESSFUL/
12095	062334	052523	041503	051505		
12096	062342	043123	046125	000		
12097	062347	122	052105	054522	EM100:	.ASCIZ /RETRY UNSUCCESSFUL/
12098	062354	052440	051516	041525		
12099	062362	042503	051523	052506		
12100	062370	000114				
12101	062372	040503	047116	052117	EM101:	.ASCIZ /CANNOT FIND A VALID HEADER IN TRACK JUST READ/
12102	062400	043040	047111	020104		

12103	062406	020101	040526	044514	
12104	062414	020104	042510	042101	
12105	062422	051105	044440	020116	
12106	062430	051124	041501	020113	
12107	062436	052512	052123	051040	
12108	062444	040505	000104		
12109	062450	040502	020104	042523	EM102: .ASCIZ /BAD SECT ERR ON SECT NOT LISTED BAD/
12110	062456	052103	042440	051122	
12111	062464	047440	020116	042523	
12112	062472	052103	047040	052117	
12113	062500	046040	051511	042524	
12114	062506	020104	040502	000104	
12115	062514	044524	042515	026504	EM103: .ASCIZ /TIMED-OUT ON READ HDR/
12116	062522	052517	020124	047117	
12117	062530	051040	040505	020104	
12118	062536	042110	000122		
12119	062542	044524	042515	026504	EM104: .ASCIZ /TIMED-OUT ON SEEK/
12120	062550	052517	020124	047117	
12121	062556	051440	042505	000113	
12122	062564	051104	020126	044523	EM105: .ASCIZ /DRV SIEZED BY OTHER PORT/
12123	062572	055105	042105	041040	
12124	062600	020131	052117	042510	
12125	062606	020122	047520	052122	
12126	062614	000			
12127	062615	104	052101	020101	EM106: .ASCIZ /DATA MISCMPR WHILE BAI SET/
12128	062622	044515	041523	050115	
12129	062630	020122	044127	046111	
12130	062636	020105	040502	020111	
12131	062644	042523	000124		
12132	062650	047516	047040	046505	EM107: .ASCIZ /NO NEM ERR WHEN REF'ING LOC 760000/
12133	062656	042440	051122	053440	
12134	062664	042510	020116	042522	
12135	062672	023506	047111	020107	
12136	062700	047514	020103	033067	
12137	062706	030060	030060	000	
12138	062713	111	052116	050122	EM110: .ASCIZ /INTRPT WHEN CNTRLR NOT RDY/
12139	062720	020124	044127	047105	
12140	062726	041440	052116	046122	
12141	062734	020122	047516	020124	
12142	062742	042122	000131		
12143	062746	047516	040440	052124	EM111: .ASCIZ /NO ATT'N ON SEEK/
12144	062754	047047	047440	020116	
12145	062762	042523	045505	000	
12146	062767	104	053122	051447	EM112: .ASCIZ /DRV'S CYL INCORRECT/
12147	062774	041440	046131	044440	
12148	063002	041516	051117	042522	
12149	063010	052103	000		
12150	063013	101	047502	052122	EM113: .ASCIZ /ABORT- CAN'T READ BSF/
12151	063020	020055	040503	023516	
12152	063026	020124	042522	042101	
12153	063034	041040	043123	000	
12154	063041	113	030524	020061	EM114: .ASCIZ /KT11 FAILURE/
12155	063046	040506	046111	051125	
12156	063054	000105			
12157	063056	042515	020115	040520	EM115: .ASCIZ /MEM PAR ERR/
12158	063064	020122	051105	000122	

12327	064640	001202	001204	001206					
12328	064646	001210							
12329	064650	001212	001214		DT202:	.WORD	\$REG14,\$REG15		
12330	064654	001216	001220	001222	DT203:	.WORD	\$REG16,\$REG17,\$REG20,\$REG21,\$REG22,\$REG23,\$REG24,\$REG25		
12331	064662	001224	001226	001230					
12332	064670	001232	001234						
12333	064674	001174	001176	001200	DT601:	.WORD	\$REG5,\$REG6,\$REG7		
12334	064702	001202	001204	001206	DT602:	.WORD	\$REG10,\$REG11,\$REG12,\$REG13,\$REG14,\$REG15,\$REG16		
12335	064710	001210	001212	001214					
12336	064716	001216							
12337	064720	005256	005254		DT103:	.WORD	PRMPHO,PRMPLO		
12338									
12339	064724	000006			DF01:	.WORD	6		;NUMBER OF HEADER LINES
12340	064726	000				.BYTE	0		;NUMBER OF COL FOR FIRST HDR
12341	064727	000				.BYTE	0		;ALL CHARACTERS OCTAL
12342	064730	063243				.WORD	DH101		;SECOND HDR LINE
12343	064732	007	000			.BYTE	7,0		;NUM OF COL-ALL OCTAL
12344	064734	063332				.WORD	DH102		
12345	064736	002	000			.BYTE	2,0		
12346	064740	063123				.WORD	DH200		
12347	064742	000	000			.BYTE	0,0		
12348	064744	063435				.WORD	DH201		
12349	064746	007	000			.BYTE	7,0		
12350	064750	063140				.WORD	DH500		
12351	064752	000	000			.BYTE	0,0		
12352									
12353	064754	000007			DF02:	.WORD	7		
12354	064756	000	000			.BYTE	0,0		
12355	064760	063243				.WORD	DH101		
12356	064762	007	000			.BYTE	7,0		
12357	064764	063332				.WORD	DH102		
12358	064766	002	000			.BYTE	2,0		
12359	064770	063123				.WORD	DH200		
12360	064772	000	000			.BYTE	0,0		
12361	064774	063435				.WORD	DH201		
12362	064776	007	000			.BYTE	7,0		
12363	065000	063524				.WORD	DH202		
12364	065002	002	000			.BYTE	2,0		
12365	065004	063541				.WORD	DH203		
12366	065006	010	000			.BYTE	10,0		
12367									
12368	065010	000010			DF03:	.WORD	10		
12369	065012	000	000			.BYTE	0,0		
12370	065014	063243				.WORD	DH101		
12371	065016	007	000			.BYTE	7,0		
12372	065020	063332				.WORD	DH102		
12373	065022	002	000			.BYTE	2,0		
12374	065024	063123				.WORD	DH200		
12375	065026	000	000			.BYTE	0,0		
12376	065030	063435				.WORD	DH201		
12377	065032	007	000			.BYTE	7,0		
12378	065034	063171				.WORD	DH501		
12379	065036	000	000			.BYTE	0,0		
12380	065040	063524				.WORD	DH202		
12381	065042	002	000			.BYTE	2,0		
12382	065044	063541				.WORD	DH203		

;"THE FOLLOWING REG DATA MB INCORRECT"

12383	065046	010	000		.BYTE	10,0	
12384							
12385	065050	000003		DF04:	.WORD	3	
12386	065052	000	000		.BYTE	0,0	
12387	065054	063243			.WORD	DH101	
12388	065056	007	000		.BYTE	7,0	
12389	065060	063332			.WORD	DH102	
12390	065062	002	000		.BYTE	2,0	
12391							
12392	065064	000007		DF05:	.WORD	7	;OPI, HVRC
12393	065066	000	000		.BYTE	0,0	
12394	065070	063243			.WORD	DH101	
12395	065072	007	000		.BYTE	7,0	
12396	065074	063332			.WORD	DH102	
12397	065076	002	000		.BYTE	2,0	
12398	065100	063635			.WORD	DH601	
12399	065102	000	000		.BYTE	0,0	
12400	065104	064062			.WORD	DH606	
12401	065106	003	000		.BYTE	3,0	
12402	065110	063637			.WORD	DH602	
12403	065112	000	000		.BYTE	0,0	
12404	065114	064062			.WORD	DH606	
12405	065116	003	000		.BYTE	3,0	
12406							
12407	065120	000007		DF07:	.WORD	7	
12408	065122	000	000		.BYTE	0,0	
12409	065124	063243			.WORD	DH101	
12410	065126	007	000		.BYTE	7,0	
12411	065130	063332			.WORD	DH102	
12412	065132	002	000		.BYTE	2,0	
12413	065134	063715			.WORD	DH604	
12414	065136	000	000		.BYTE	0,0	
12415	065140	063743			.WORD	DH6041	
12416	065142	003	000		.BYTE	3,0	
12417	065144	064010			.WORD	DH605	
12418	065146	000	000		.BYTE	0,0	
12419	065150	064025			.WORD	DH6051	
12420	065152	003	000		.BYTE	3,0	
12421							
12422	065154	000005		DF10:	.WORD	5	
12423	065156	000	000		.BYTE	0,0	
12424	065160	063243			.WORD	DH101	
12425	065162	007	000		.BYTE	7,0	
12426	065164	063332			.WORD	DH102	
12427	065166	002	000		.BYTE	2,0	
12428	065170	063715			.WORD	DH604	
12429	065172	000	000		.BYTE	0,0	
12430	065174	063743			.WORD	DH6041	
12431	065176	003	000		.BYTE	3,0	
12432							
12433	065200	000004		DF11:	.WORD	4	
12434	065202	000	000		.BYTE	0,0	
12435	065204	063715			.WORD	DH604	
12436	065206	000	000		.BYTE	0,0	
12437	065210	063743			.WORD	DH6041	
12438	065212	003	000		.BYTE	3,0	

12439	065214	064130		.WORD	DH701
12440	065216	000	000	.BYTE	0,0
12441					
12442	065220	000006		DF12: .WORD	6
12443	065222	000	000	.BYTE	0,0
12444	065224	063243		.WORD	DH101
12445	065226	007	000	.BYTE	7,0
12446	065230	063332		.WORD	DH102
12447	065232	002	000	.BYTE	2,0
12448	065234	063123		.WORD	DH200
12449	065236	000	000	.BYTE	0,0
12450	065240	063435		.WORD	DH201
12451	065242	007	000	.BYTE	7,0
12452	065244	064410		.WORD	DH204
12453	065246	004	000	.BYTE	4,0
12454					
12455	065250	000006		DF13: .WORD	6
12456	065252	000	000	.BYTE	0,0
12457	065254	063243		.WORD	DH101
12458	065256	007	000	.BYTE	7,0
12459	065260	063332		.WORD	DH102
12460	065262	002	000	.BYTE	2,0
12461	065264	063635		.WORD	DH601
12462	065266	000	000	.BYTE	0,0
12463	065270	064062		.WORD	DH606
12464	065272	003	000	.BYTE	3,0
12465	065274	064446		.WORD	DH502
12466	065276	000	000	.BYTE	0,0
12467					
12468	065300	000006		DF14: .WORD	6
12469	065302	000	000	.BYTE	0,0
12470	065304	063243		.WORD	DH101
12471	065306	007	000	.BYTE	7,0
12472	065310	063332		.WORD	DH102
12473	065312	002	000	.BYTE	2,0
12474	065314	063635		.WORD	DH601
12475	065316	000	000	.BYTE	0,0
12476	065320	064062		.WORD	DH606
12477	065322	003	000	.BYTE	3,0
12478	065324	064446		.WORD	DH502
12479	065326	000	000	.BYTE	0,0
12480					
12481	065330	000011		DF15: .WORD	11
12482	065332	000	000	.BYTE	0,0
12483	065334	063243		.WORD	DH101
12484	065336	007	000	.BYTE	7,0
12485	065340	063332		.WORD	DH102
12486	065342	002	000	.BYTE	2,0
12487	065344	063123		.WORD	DH200
12488	065346	000	000	.BYTE	0,0
12489	065350	063435		.WORD	DH201
12490	065352	007	000	.BYTE	7,0
12491	065354	063524		.WORD	DH202
12492	065356	002	000	.BYTE	2,0
12493	065360	064507		.WORD	DH503
12494	065362	000	000	.BYTE	0,0

;FORMAT FOR 2ND LEVEL ERROR
;IN HEADER COMPARE ERROR
;AND 2ND LEVEL HEADER
;VRC ERROR

;FORMAT FOR 2ND LEVEL ERROR
;IN OPERATION INCOMPLETE ERROR

12495	065364	063171			.WORD	DH501
12496	065366	000	000		.BYTE	0,0
12497	065370	063541			.WORD	DH203
12498	065372	010	000		.BYTE	10,0
12499						
12500	065374	000011		DF16:	.WORD	11
12501	065376	000	000		.BYTE	0,0
12502	065400	063243			.WORD	DH101
12503	065402	007	000		.BYTE	7,0
12504	065404	063332			.WORD	DH102
12505	065406	002	000		.BYTE	2,0
12506	065410	063123			.WORD	DH200
12507	065412	000	000		.BYTE	0,0
12508	065414	063435			.WORD	DH201
12509	065416	007	000		.BYTE	7,0
12510	065420	063524			.WORD	DH202
12511	065422	002	000		.BYTE	2,0
12512	065424	064446			.WORD	DH502
12513	065426	000	000		.BYTE	0,0
12514	065430	063171			.WORD	DH501
12515	065432	000	000		.BYTE	0,0
12516	065434	063541			.WORD	DH203
12517	065436	010	000		.BYTE	10,0
12518						
12519	065440	000005		DF17:	.WORD	5
12520	065442	000	000		.BYTE	0,0
12521	065444	063243			.WORD	DH101
12522	065446	007	000		.BYTE	7,0
12523	065450	063332			.WORD	DH102
12524	065452	002	000		.BYTE	2,0
12525	065454	064374			.WORD	DH711
12526	065456	000	000		.BYTE	0,0
12527	065460	064217			.WORD	DH702
12528	065462	002	000		.BYTE	2,0
12529						
12530	065464	000002		DF20:	.WORD	2
12531	065466	000	000		.BYTE	0,0
12532	065470	063373			.WORD	DH104
12533	065472	002	000		.BYTE	2,0
12534						
12535	065474	000002		DF21:	.WORD	2
12536	065476	000	000		.BYTE	0,0
12537	065500	064025			.WORD	DH6051
12538	065502	003	000		.BYTE	3,0
12539						
12540	065504	000006		DF22:	.WORD	6
12541	065506	000	000		.BYTE	0,0
12542	065510	063072			.WORD	DH100
12543	065512	000	000		.BYTE	0,0
12544	065514	063243			.WORD	DH101
12545	065516	007	000		.BYTE	7,0
12546	065520	063332			.WORD	DH102
12547	065522	002	000		.BYTE	2,0
12548	065524	063412			.WORD	DH106
12549	065526	000	000		.BYTE	0,0
12550	065530	063373			.WORD	DH104

12551	065532	002	000		.BYTE	2,0
12552						
12553	065534	000002		DF23:	.WORD	2
12554	065536	000	000		.BYTE	0,0
12555	065540	064564			.WORD	DH200
12556	065542	001	000		.BYTE	1,0
12557						
12558	065544	000001		DF24:	.WORD	1
12559	065546	002	000		.BYTE	2,0
12560						
12561	065550	000000		DF25:	.WORD	0
12562	065552	007	000		.BYTE	7,0
12563						
12564	065554	000002		DF26:	.WORD	2
12565	065556	002	000		.BYTE	2,0
12566	065560	063541			.WORD	DH203
12567	065562	010	000		.BYTE	10,0
12568						
12569	065564	000005		DF27:	.WORD	5
12570	065566	000	000		.BYTE	0,0
12571	065570	063243			.WORD	DH101
12572	065572	007	000		.BYTE	7,0
12573	065574	063332			.WORD	DH102
12574	065576	002	000		.BYTE	2,0
12575	065600	064233			.WORD	DH703
12576	065602	000	000		.BYTE	0,0
12577	065604	064217			.WORD	DH702
12578	065606	002	000		.BYTE	2,0
12579						
12580	065610	000005		DF30:	.WORD	5
12581	065612	000	000		.BYTE	0,0
12582	065614	063243			.WORD	DH101
12583	065616	007	000		.BYTE	7,0
12584	065620	063332			.WORD	DH102
12585	065622	002	000		.BYTE	2,0
12586	065624	064277			.WORD	DH705
12587	065626	000	000		.BYTE	0,0
12588	065630	064257			.WORD	DH704
12589	065632	004	000		.BYTE	4,0
12590						
12591	065634	000005		DF31:	.WORD	5
12592	065636	000	000		.BYTE	0,0
12593	065640	063243			.WORD	DH101
12594	065642	007	000		.BYTE	7,0
12595	065644	063332			.WORD	DH102
12596	065646	002	000		.BYTE	2,0
12597	065650	064313			.WORD	DH706
12598	065652	000	000		.BYTE	0,0
12599	065654	064356			.WORD	DH710
12600	065656	003	000		.BYTE	3,0
12601						
12602	065660			RWBUF:		
12603						
12604	065660	005015	020040	020040	NOTMSG: .ASCII	<15><12>/
12605	065666	020040	020040	020040		
12606	065674	025052	020052	047516		

:READ/WRITE DATA BUF <AT LEAST 512(0) WORDS>

*** NOTE ***/<15><12><12>

12607	065702	042524	025040	025052	
12608	065710	005015	012		
12609	065713	101	046114	042040	.ASCII /ALL DRIVES TO BE TESTED MUST HAVE :/<15><12><12>
12610	065720	044522	042526	020123	
12611	065726	047524	041040	020105	
12612	065734	042524	052123	042105	
12613	065742	046440	051525	020124	
12614	065750	040510	042526	035040	
12615	065756	005015	012		
12616	065761	061	020056	020101	.ASCII /1. A 20 OR 22 SECTOR FORMATTED CARTRIDGE/<15><12>
12617	065766	030062	047440	020122	
12618	065774	031062	051440	041505	
12619	066002	047524	020122	047506	
12620	066010	046522	052101	042524	
12621	066016	020104	040503	052122	
12622	066024	044522	043504	006505	
12623	066032	012			
12624	066033	062	020056	042510	.ASCII /2. HEADS MANUALLY LOADED/<15><12>
12625	066040	042101	020123	040515	
12626	066046	052516	046101	054514	
12627	066054	046040	040517	042504	
12628	066062	006504	012		
12629	066065	063	020056	042504	.ASCII /3. DESIRED PORT SELECTED/<15><12>
12630	066072	044523	042522	020104	
12631	066100	047520	052122	051440	
12632	066106	046105	041505	042524	
12633	066114	006504	012		
12634	066117	064	020056	051127	.ASCII /4. WRITE LOCK DISABLED/<15><12>
12635	066124	052111	020105	047514	
12636	066132	045503	042040	051511	
12637	066140	041101	042514	006504	
12638	066146	012			
12639	066147	065	020056	051104	.ASCII /5. DRIVE READY LIGHT ON/<15><12><12>
12640	066154	053111	020105	042522	
12641	066162	042101	020131	044514	
12642	066170	044107	020124	047117	
12643	066176	005015	012		
12644	066201	104	044522	042526	.ASCII /DRIVES NOT TO BE TESTED MUST HAVE BOTH/<15><12>
12645	066206	020123	047516	020124	
12646	066214	047524	041040	020105	
12647	066222	042524	052123	042105	
12648	066230	046440	051525	020124	
12649	066236	040510	042526	041040	
12650	066244	052117	006510	012	

12651	066251	120	051117	051524
12652	066256	042040	026505	042523
12653	066264	042514	052103	042105
12654	066272	006456	005012	000
12655				
12656	066277	015	044412	051516
12657	066304	051124	041525	044524
12658	066312	047117	020123	047506
12659	066320	020122	051525	047111
12660	066326	020107	045522	033060
12661	066334	051055	030113	020067
12662	066342	042510	042101	040440
12663	066350	044514	047107	042515
12664	066356	052116	040440	042111
12665	066364	035040	005015	
12666	066370	025052	025052	025052
12667	066376	025052	025052	025052
12668	066404	025052	025052	025052
12669	066412	025052	025052	025052
12670	066420	025052	025052	025052
12671	066426	025052	025052	025052
12672	066434	025052	025052	025052
12673	066442	025052	025052	005015
12674	066450	047515	047125	020124
12675	066456	047101	051040	030113
12676	066464	020066	046101	043511
12677	066472	046516	047105	020124
12678	066500	040503	052122	044522
12679	066506	043504	020105	047117
12680	066514	052040	042510	042040
12681	066522	051505	051111	042105
12682	066530	006440	012	
12683	066533	104	044522	042526
12684	066540	020054	047101	020104
12685	066546	047111	052523	042522
12686	066554	052040	040510	020124
12687	066562	044124	020105	051104
12688	066570	053111	020105	051511
12689	066576	053440	044522	042524
12690	066604	046055	041517	042513
12691	066612	027104	006440	012
12692	066617	103	047117	042516
12693	066624	052103	052040	042510
12694	066632	040440	044514	047107
12695	066640	042515	052116	044440
12696	066646	042116	041511	052101
12697	066654	051117	052040	020117
12698	066662	044124	020105	042504
12699	066670	044523	042522	020104
12700	066676	051104	053111	026105
12701	066704	005015		
12702	066706	044526	020101	044124
12703	066714	020105	042510	042101
12704	066722	040440	044514	047107
12705	066730	042515	052116	041440
12706	066736	041101	042514	047440

.ASCIZ /PORTS DE-SELECTED./<15><12><12>

HLPFIL: .ASCII <15><12>/INSTRUCTIONS FOR USING RK06-RK07 HEAD ALIGNMENT AID :/<15><12>

.ASCII /*****<15><12>

.ASCII /MOUNT AN RK06 ALIGNMENT CARTRIDGE ON THE DESIRED /<15><12>

.ASCII /DRIVE, AND INSURE THAT THE DRIVE IS WRITE-LOCKED. /<15><12>

.ASCII /CONNECT THE ALIGNMENT INDICATOR TO THE DESIRED DRIVE,/<15><12>

.ASCII /VIA THE HEAD ALIGNMENT CABLE ONLY, AND CYCLE UP THE/<15><12>

12707	066744	046116	026131	040440	
12708	066752	042116	041440	041531	
12709	066760	042514	052440	020120	
12710	066766	044124	006505	012	
12711	066773	104	044522	042526	.ASCII /DRIVE. AFTER MOUNTING THE PACK ON THE DRIVE, /<15><12>
12712	067000	020056	043101	042524	
12713	067006	020122	047515	047125	
12714	067014	044524	043516	052040	
12715	067022	042510	050040	041501	
12716	067030	020113	047117	052040	
12717	067036	042510	042040	044522	
12718	067044	042526	020054	005015	
12719	067052	044124	020105	050117	.ASCII /THE OPERATOR SHOULD WAIT 30 MINUTES FOR THE DRIVE/<15><12>
12720	067060	051105	052101	051117	
12721	067066	051440	047510	046125	
12722	067074	020104	040527	052111	
12723	067102	031440	020060	044515	
12724	067110	052516	042524	020123	
12725	067116	047506	020122	044124	
12726	067124	020105	051104	053111	
12727	067132	006505	012		
12728	067135	124	046505	042520	.ASCII /TEMPERATURE TO STABILIZE, BEFORE PROCEEDING WITH /<15><12>
12729	067142	040522	052524	042522	
12730	067150	052040	020117	052123	
12731	067156	041101	046111	055111	
12732	067164	026105	041040	043105	
12733	067172	051117	020105	051120	
12734	067200	041517	042505	044504	
12735	067206	043516	053440	052111	
12736	067214	020110	005015		
12737	067220	046101	043511	046516	.ASCII /ALIGNMENT./<15><12><12>
12738	067226	047105	027124	005015	
12739	067234	012			
12740	067235	122	051505	047520	.ASCII /RESPOND TO ALL REQUESTS FOR PARAMETERS, BY ENTERING /<15><12>
12741	067242	042116	052040	020117	
12742	067250	046101	020114	042522	
12743	067256	052521	051505	051524	
12744	067264	043040	051117	050040	
12745	067272	051101	046501	052105	
12746	067300	051105	026123	041040	
12747	067306	020131	047105	042524	
12748	067314	044522	043516	006440	
12749	067322	012			
12750	067323	124	042510	042040	.ASCII /THE DESIRED PARAMETER VALUE (NO <CR> NEEDED)./<15><12>
12751	067330	051505	051111	042105	
12752	067336	050040	051101	046501	
12753	067344	052105	051105	053040	
12754	067352	046101	042525	024040	
12755	067360	047516	036040	051103	
12756	067366	020076	042516	042105	
12757	067374	042105	027051	005015	
12758	067402	044124	051105	020105	.ASCII /THERE ARE TWO MODES OF OPERATION : MANUAL MODE /<15><12>
12759	067410	051101	020105	053524	
12760	067416	020117	047515	042504	
12761	067424	020123	043117	047440	
12762	067432	042520	040522	044524	

12763	067440	047117	035040	020040	
12764	067446	040515	052516	046101	
12765	067454	046440	042117	020105	
12766	067462	005015			
12767	067464	046101	047514	051527	.ASCII /ALLOWS SELECTION OF DRIVES AND HEADS BY TTY INPUT, /<<15><12>
12768	067472	051440	046105	041505	
12769	067500	044524	047117	047440	
12770	067506	020106	051104	053111	
12771	067514	051505	040440	042116	
12772	067522	044040	040505	051504	
12773	067530	041040	020131	052124	
12774	067536	020131	047111	052520	
12775	067544	026124	005015		
12776	067550	047101	020104	052501	.ASCII /AND AUTO MODE ALLOWS DRIVES AND HEADS TO BE SELECTED /<<15><12>
12777	067556	047524	046440	042117	
12778	067564	020105	046101	047514	
12779	067572	051527	042040	044522	
12780	067600	042526	020123	047101	
12781	067606	020104	042510	042101	
12782	067614	020123	047524	041040	
12783	067622	020105	042523	042514	
12784	067630	052103	042105	005015	
12785	067636	054502	047440	043106	.ASCII /BY OFF-ON OPERATION OF DRIVE PORT SELECT SWITCHES. /<<15><12>
12786	067644	047455	020116	050117	
12787	067652	051105	052101	047511	
12788	067660	020116	043117	042040	
12789	067666	044522	042526	050040	
12790	067674	051117	020124	042523	
12791	067702	042514	052103	051440	
12792	067710	044527	041524	042510	
12793	067716	027123	005015		
12794	067722	047111	042440	052111	.ASCII /IN EITHER MODE, UP TO 5 MINUTES OF SEEK EXERCISES /<<15><12>
12795	067730	042510	020122	047515	
12796	067736	042504	020054	050125	
12797	067744	052040	020117	020065	
12798	067752	044515	052516	042524	
12799	067760	020123	043117	051440	
12800	067766	042505	020113	054105	
12801	067774	051105	044503	042523	
12802	070002	006523	012		
12803	070005	115	054501	041040	.ASCII /MAY BE REQUESTED FOR EACH DRIVE. /<<15><12>
12804	070012	020105	042522	052521	
12805	070020	051505	042524	020104	
12806	070026	047506	020122	040505	
12807	070034	044103	042040	044522	
12808	070042	042526	020056	005015	
12809	070050	046101	047523	044440	.ASCII /ALSO IN EITHER MODE, A VERIFY OPTION ALLOWS HEAD /<<15><12>
12810	070056	020116	044505	044124	
12811	070064	051105	046440	042117	
12812	070072	026105	040440	053040	
12813	070100	051105	043111	020131	
12814	070106	050117	044524	047117	
12815	070114	040440	046114	053517	
12816	070122	020123	042510	042101	
12817	070130	005015			
12818	070132	042523	042514	052103	.ASCII /SELECTION WITHOUT THE UNLOADING AND LOADING OF /<<15><12>

12819	070140	047511	020116	044527	
12820	070146	044124	052517	020124	
12821	070154	044124	020105	047125	
12822	070162	047514	042101	047111	
12823	070170	020107	047101	020104	
12824	070176	047514	042101	047111	
12825	070204	020107	043117	006440	
12826	070212	012			
12827	070213	124	042510	042040	.ASCII /THE DRIVE BY THE PROGRAM, WHICH OTHERWISE OCCURS/<15><12>
12828	070220	044522	042526	041040	
12829	070226	020131	044124	020105	
12830	070234	051120	043517	040522	
12831	070242	026115	053440	044510	
12832	070250	044103	047440	044124	
12833	070256	051105	044527	042523	
12834	070264	047440	041503	051125	
12835	070272	006523	012		
12836	070275	124	020117	046101	.ASCII /TO ALLOW MANIPULATION OF THE ALIGNMENT TOOL./<15><12>
12837	070302	047514	020127	040515	
12838	070310	044516	052520	040514	
12839	070316	044524	047117	047440	
12840	070324	020106	044124	020105	
12841	070332	046101	043511	046516	
12842	070340	047105	020124	047524	
12843	070346	046117	006456	012	
12844	070353	124	020117	042522	.ASCII /TO RESTART EITHER MODE, TYPE <↑Z>./<15><12>
12845	070360	052123	051101	020124	
12846	070366	044505	044124	051105	
12847	070374	046440	042117	026105	
12848	070402	052040	050131	020105	
12849	070410	057074	037132	006456	
12850	070416	012			
12851	070417	124	020117	042522	.ASCII /TO RESTART ALIGNMENT AID, TYPE <↑R>./<15><12>
12852	070424	052123	051101	020124	
12853	070432	046101	043511	046516	
12854	070440	047105	020124	044501	
12855	070446	026104	052040	050131	
12856	070454	020105	057074	037122	
12857	070462	006456	012		
12858	070465	124	020117	042523	.ASCII /TO SELECT NEW DRIVES IN MANUAL MODE, TYPE <↑C>./<15><12><12>
12859	070472	042514	052103	047040	
12860	070500	053505	042040	044522	
12861	070506	042526	020123	047111	
12862	070514	046440	047101	040525	
12863	070522	020114	047515	042504	
12864	070530	020054	054524	042520	
12865	070536	036040	041536	027076	
12866	070544	005015	012		
12867	070547	106	051117	044040	.ASCII /FOR HEAD ALIGNMENT PROCEDURE, REFER TO FIELD /<15><12>
12868	070554	040505	020104	046101	
12869	070562	043511	046516	047105	
12870	070570	020124	051120	041517	
12871	070576	042105	051125	026105	
12872	070604	051040	043105	051105	
12873	070612	052040	020117	044506	
12874	070620	046105	020104	005015	

G04

CZR6ND0 RK611/06 SS VERIF 2
CZR6ND.P11 10-JAN-78 10:05

MACY11 30A(1052) 10-JAN-78 12:02 PAGE 253
TRAP TABLE

SEQ 0252

12875	070626	042524	052123	041040
12876	070634	054117	024040	045522
12877	070642	033060	030055	052067
12878	070650	026101	051040	030113
12879	070656	026466	033460	041124
12880	070664	020051	050117	051105
12881	070672	052101	051117	051447
12882	070700	046440	047101	040525
12883	070706	027114	005015	000
12884				
12885				
12886				
12887				

.ASCIZ /TEST BOX (RK06-07TA, RK06-07TB) OPERATOR'S MANUAL./<15><12>

000001

.END

APTSP0=	000100	11069	11692	11733#															
ASKDRV	025016	6420#	6462	6466	6481	6513	6583												
ASKHED	025442	6499#	6527	6539	6546														
ASKMDE	016020	5137#	5143	5144	5149	5164	5169	5174	5199	5213	5224	5233	5249	5268					
		5277	5303	5326	5398	7955													
ASKMOD	024724	6398#	6412																
ASKTMD	015254	5019#	5022		5023	5028	5052	5060	5066	5082	5093	5102	5127						
ASKTST	015250	4935	5018#																
ASKTYP	024620	6367	6373	6376#															
ASTART	024134	2219	6292#																
ASWREG=	000000	2348	2361																
AS2SP2	060370	9223	11902#																
AESTN=	000000	2348	2352																
AUNIT =	000000	2348	2355																
AUSWR =	000000	2348	2362																
AUTAL	026266	6610	6617	6624#	6745	6766													
AUTALN	012752	4632#	6629																
AUTEX	027520	6613	6824#	6845	6886														
AUTEXR	013066	4646#	6827																
AUTO	026144	6410	6596#	6645	6813	6816	6819	6835	6909	6924									
AUTODR	013176	4659#	6890#																
AUTOEX	013157	4656#	6891																
AUTOFG	003150	3689#	4748#	6336*	6418*	6597*	7462	7478	7488	7511									
AUTVRF	013010	4637#	6627																
AVECT1=	120210	2255#	2348	2387	4799														
AVECT2=	000000	2348	2388																
A.ABNL	003046	3583#	5606*	5609*	6657*	6726*	6848*	6881*	7375*	7455*	7459*	7550*	7554*	8495*					
		8791*	8808*	8817*	9437*	9693*	9706*	9708*	10635										
A.CONT	003050	3584#	10645																
A.NORM	003044	3582#	6172*	6233*	7376*	9438*	9694*	10639											
BADDRV	007522	4312#	6380*	6381	7464*	7465*	7466	7480*	7481*	7482	7490*	7491*	7492	7519*					
		7520*	7521																
BADSEC=	001000	4248#	8404	8627	9080	9088	9639	9742											
BAD632	013202	4661#	7516																
BAI =	000020	3261#	10804																
BAIA	025306	6460	6463#																
BAIFLU	025300	6428	6430	6461#															
BA16 =	000400	3237#																	
BA17 =	001000	3238#																	
BDSCHD	041364	8791	8808	8822#															
BDSECT	011211	4464#	8840																
BDSRCK	042436	8402	8625	9070#	9638														
BGNRTY	046166	9361	9704	9710	9735#														
BITO =	000001	2147#	3234	3251	3277	3299	3447	3591	3683	4885	4974	7177	7994	8278					
		8295	8310	8349	8366	8420	8462	8567	8582	8613	8649	8693	9320	10919					
BIT00 =	000001	2137#	2147																
BIT01 =	000002	2136#	2146																
BIT02 =	000004	2135#	2145																
BIT03 =	000010	2134#	2144																
BIT04 =	000020	2133#	2143																
BIT05 =	000040	2132#	2142																
BIT06 =	000100	2131#	2141																
BIT07 =	000200	2130#	2140																
BIT08 =	000400	2129#	2139																
BIT09 =	001000	2128#	2138	8119															
BIT1 =	000002	2146#	3252	11523	11654														
				3279	3448	3592	3684	4240	5583	5634	8537	9324							

P.CS1 = 000016

P.CS1H= 000007

P.CS2 = 000020

P.CYLN= 000002

P.DCYL= 000030

P.DRVN= 000000

P.DS = 000036

P.DTS = 000026

P.EPAT= 000062

P.EPOS= 000060

P.ER = 000034

P.OFST= 000006

P.PRST= 000014

P.SECT= 000004

P.TRCK= 000005

P.WC = 000012

P.WCR = 000022

QNEWSW= 000000

Q.INIT= 040000

RCDASW= 000010

RCLREQ= 004000

RDALHD= 000164

RDCHR = 104406

RDCHRS 034034

RDDATA= 000121

RDGATE= 100000

RDHDO 046536

RDHEAD= 000125

RDSTAT= 000141

RDY = 000200

RECAL = 000113

RECODE 005474

6878*	6892*	6902*	6907*	6914*	7381*	7443*	7454*	7496*	7498*	7500*	7549*	7575*
7588*	7590*	7601*	7620*	7622*	7634*	7650*	8055*	8093*	8183*	8497*	8536*	8541*
8781*	9370	9705*	9752*	9797*	9833*	9836*	10099	10716	10720	10732	10742	10748
10754	10757	10763	10788	10795	10814	10861	10878	10900	10909			
3472*	6227*	7401	7444*	9383	9501	9519	9865	9898	10120*	10172*	10210*	10211*
10213*	10214	10323*	10325*	10552*	10555*	10706	10760*	10761*	10763*	10767*	10768	10792*
10795*	10797*	10798*	10808*	10809	10817*	10818*	10820*	10821	10823*	10824	10829	10868*
10869*	10871*	10874*	10875	10891*	10892*	10894*	10897	10916*	10917	10926*	10927	
3439*	6161*	6163*	6215*	6217*	7385*	7386*	7509*	7510*	8089*	8780*	9844*	9845*
10210	10451	10760	10797	10817	10868	10882	10891					
3473*	5694	6930	9384	9458	9463	9468	9470	9476	9478	9526	9576	9660
10126	10326*	10556*	10714*	10739	10804*	10805	10816	10835	10839	10865*	10866	10890
3435*	5549*	5559*	5562*	5563	5568*	5577	5579*	5587*	5643	5671	5673*	5679*
6000*	6109*	6126*	6157*	6171*	6561*	6896*	7503*	7505*	7602*	7604*	7607	7610
8094*	8250	8702*	8707*	8782*	8884	8938*	9372	9832*	10208	10744	10786	10888
3477*	8888	8934	9385	9633	9855	9887	10330*	10564*				
3433*	6116*	6156*	6170*	6194*	6638*	6688*	6752*	6770*	6784*	6849*	7383*	7430*
7548*	10096	10273	10449	10688								
3480*	9391	9511	9515	9566	10333*	10560*	10841					
3476*	8890	8892	8935	8936	9386	9634	9636	9823	9858	9859	9888	9894
10329*	10559*											
3490*	9657	10122*	10708									
3489*	9656	10123*										
3479*	5697	8822	9392	9457	10332*	10561*						
3438*	5602*	5613*	10750									
3443*	6007*	6133*	9484	9497	9669	9674	9679	9684	9799	9968*	10081*	10115*
10143*	10150	10154*	10251*	10274	10278*	10291*	10309*	10319*	10345	10349*	10359*	10371*
10476*	10628*	10703*	10740*	10764*	10765	10790	10796*	10802	10806	10833	10843*	10851
10872	10895	10904	10938									
3436*	5550*	5572	5574*	5580*	5588*	5648	5667	5669*	5674*	6002*	6127*	8092*
8177	8188*	8227	8703*	8787*	8796*	8797	8803*	8813*	8814	8886	8940*	9375
9831*	10209	10745	10787	10889								
3437*	5551*	5565	5569*	5570*	5575*	5586*	5637	5676*	5677	6001*	6532*	6798*
7506*	8095*	8178*	8180	8185*	8186	8241	8704*	8783*	8885	8939*	9373	
3442*	5746*	5750*	5825*	5829*	5914*	5918*	6003*	6006*	6128*	6131*	7508*	8097*
8534*	8758	8789*	8943*	8969	9006	9377	10785					
3474*	9387	10327*	10557*									
3193												
3464*												
3686*												
4250*	9504	9509	9554	9559	9564	9569	9703					
3222*	10099	10878										
6369	7717	11895*										
4869	4927	5020	5064	5091	5141	5247	5275	5324	5396	7079	7711*	7889
7907												
3211*	5770	5850	5945	6029	7500	8093	8781					
3330*												
9591	9616	9821*										
3213*	5466	9836	10213	10894								
3221*	6181	6753	6776	7454	7549	7622	8055	9797	10814			
3236*	6224	9699	10771	10824								
3208*	5681	6506	6511	6516	6569	6576	6581	6586	6789	6902	6907	6914
7498	7588	8497	9705	10757								
3719*	6022	6175	7448*	7514	7647*	8404	8627	8999	9002	9080*	9088*	9176
9186*	9433*	9434	9461*	9466*	9487	9489	9504*	9509*	9549*	9554*	9559*	9564*
9569*	9574*	9582*	9586	9592	9607*	9611	9617	9632*	9639	9642*	9646*	9649*

	9662*	9663*	9672*	9677*	9682*	9687*	9695	9701*	9703	9709	9711*	9735	9737*
	9742	9749*	9769*	9801*									
REDBSF 041120	5485	8778*											
REFNEM 040750	6019	6030	8729*										
REISSU 003137	3674*	9332*											
RELEAS= 000140	3220*	10861											
REPSUP 043720	6035	6192	6206	6228	7152	7196	7446	8341	8607	8799	9367*	9439	
RESREG= 104410	7063	7144	7269	7323	8020	8078	8165	8189	8206	8253	8322	8403	8464
	8543	8583	8626	8694	8769	8874	8899	8957	8985	9081	9131	9163	9303
	9418	9764	9813	9847	9906	11241	11293	11897*					
RESVEC= 000010	2151*												
RETANL 046340	9437	9706	9768*										
RETNML 046356	5701	6945	8826	9438	9771*								
RKASOF= 000016	3189*	9790	10109	10179	10259	10514	10562	10751*	10776				
RKBA = 000004	3184*	9789	10510	10558	10784*								
RKBADR 007400	4295*	4815											
RKBAS 003036	3579*	4796*	4800*	4814	4817*	7377	9594	9619	9698	9751	9782	9962	10031
RKCS1 = 000000	10695												
	3182*	6740*	7472*	7570*	9595*	9599	9620*	9624	9784	10054	10106	10164	10214*
	10223	10405*	10406	10415*	10454*	10455	10479*	10507	10768*	10770	10809*	10821*	10823
	10853*	10875*	10897*	10906*	10916	10926	10941*						
RKCS2 = 000010	3186*	7432*	7441	9785	10032	10192	10450*	10508	10556	10739*	10805*	10816*	10866*
	10890*	10915*											
RKDA = 000006	3185*	9787	10209*	10511	10559	10745*	10787*	10889*					
RKDB = 000024	3192*	5477	5478	9596	9597	9598	9621	9622	9623	10188	10189	10190	
RKDC = 000020	3190*	9786											
RKDCYL= 000020	3191*	10208*	10515	10564	10744*	10786*	10888*						
RKDS = 000012	3187*	9699	9791	10057	10512	10560							
RKECPS= 000030	3197*	10123	10519										
RKECPT= 000032	3199*	10122	10520										
RKER = 000014	3188*	7450	9792	10066	10232	10513	10561						
RKMR1 = 000026	3193*	10200*	10279*	10516	10593*	10600*	10607*	10614*	10715*				
RKMR2 = 000034	3194*	10517	10827										
RKMR3 = 000036	3195*	10518	10828										
RKPAT = 000032	3198*												
RKPOS = 000030	3196*												
RKPRI 003042	3581*	4772	4805*	4824	4840*	9961	10685						
RKPRTY 007446	4303*	4829											
RKVADR 007423	4299*	4820											
RKVEC 003040	3580*	4770	4801*	4802*	4819	4822*	6346						
RKWC = 000002	3183*	9788	10509	10557	10785*								
RLS = 000010	3260*	10865											
RNDADR 035666	6140	6560	6895	8146*									
RNDLNG= 016514	4237*	6557	6842										
RNDGHT= 002734	4236*	6838											
RUNTST 017224	5175	5393*											
RWBUF 065660	3749	5590	5735	5812	5900	6027	6028*	6033	6037	7209	7507	7517	8096
	8101	8161	8163	8275	8346	8527	8533	8708	8971	12602*			
RWNRDY 012651	4619*	7626											
R.ABNL 052536	9974	10084	10159	10176	10354	10374	10634*	10844					
R.CONT 052562	10036	10074	10138	10147	10218	10240	10263	10269	10302	10342	10366	10411	10463
	10486	10624	10642*	10858	10912	10921	10934						
R.NORM 052550	10112	10205	10314	10638*	10781	10854	10942						
SAVPAR 003176	3702*	7256*	8294	8365	8566	8612							
SAVPRS 005552	3741*	8968	8979										
SAVREG= 104407	7024	7130	7242	7302	7305	7976	8053	8160	8176	8198	8221	8269	8336

SWREG	000176	2211#	4739	6327	6342	7110	7112	7115*
SWMSG	007466	4306#	7113					
SW0	= 000001	2119#						
SW00	= 000001	2109#	2119					
SW01	= 000002	2108#	2118					
SW02	= 000004	2107#	2117					
SW03	= 000010	2106#	2116					
SW04	= 000020	2105#	2115					
SW05	= 000040	2104#	2114					
SW06	= 000100	2103#	2113					
SW07	= 000200	2102#	2112					
SW08	= 000400	2101#	2111					
SW09	= 001000	2100#	2110					
SW1	= 000002	2118#						
SW10	= 002000	2099#						
SW11	= 004000	2098#						
SW12	= 010000	2097#						
SW13	= 020000	2096#	9208					
SW14	= 040000	2095#						
SW15	= 100000	2094#						
SW2	= 000004	2117#						
SW3	= 000010	2116#						
SW4	= 000020	2115#						
SW5	= 000040	2114#						
SW6	= 000100	2113#						
SW7	= 000200	2112#						
SW8	= 000400	2111#						
SW9	= 001000	2110#						
S.ACLO	= 000100	3348#						
S.BRHM	= 000100	3363#						
S.BRKE	= 040000	3385#						
S.CART	= 000400	3365#						
S.DCLO	= 010000	3355#						
S.DIB	= 002000	3381#						
S.DOOR	= 000200	3364#						
S.DRA	= 000040	3334#						
S.DROT	= 020000	3356#						
S.DRY	= 000200	3336#	7476	7563				
S.DSC	= 040000	3343#	10141	10289	10306	10369		
S.FLT	= 000200	3349#	10284					
S.FORM	= 001000	3338#						
S.FWD	= 002000	3367#						
S.HDFL	= 000200	3378#						
S.HDHM	= 000040	3362#	6755	6778	7624			
S.ICYL	= 000040	3347#						
S.ILF	= 000400	3350#						
S.LIMD	= 020000	3384#						
S.LOAD	= 010000	3369#						
S.MHD	= 000400	3379#						
S.NMOV	= 010000	3383#						
S.OFF	= 002000	3339#						
S.PAR	= 001000	3351#	10144	10621				
S.PIP	= 020000	3342#	10152	10347				
S.PLO	= 004000	3382#						
S.REV	= 004000	3368#						
S.RTZ	= 020000	3370#						

SLPADR	001106	2270#	4725*	6313*	11598	11656*	11670*	11675	11677												
SLPERR	001110	2271#	4726*	5762*	5937*	6314*	11525	11615	11656	11671*	11677										
SLSTAD	060176	7029	7042	11803*	11810#																
SLSTBK	060200	7033	11804*	11811#																	
SMADR1	001352	2376#																			
SMADR2	001356	2380#																			
SMADR3	001362	2383#																			
SMADR4	001366	2386#																			
SMAIL	001320	2250	2254	2349#	4743	5537	5726	5803	5891	5992	6075	6331	11067	11513							
		11669																			
SMAMS1	001350	2370#																			
SMAMS2	001354	2378#																			
SMAMS3	001360	2381#																			
SMAMS4	001364	2384#																			
SMBADR	001002	2250#																			
SMFLG	057670	11682*	11688	11723*	11727#																
SMNEW	057023	11576#																			
SMSGAD	001334	2356#	11698*	11701																	
SMSGLG	001336	2357#	11703*																		
SMSGTY	001320	2350#	11696	11704*	11716	11720*															
SMSWR	057012	11574#																			
SMTYP1	001351	2371#																			
SMTYP2	001355	2379#																			
SMTYP3	001361	2382#																			
SMTYP4	001365	2385#																			
SMXCNT	057424	11667	11677#																		
SNUL	001154	2291#	11094	11123																	
SNWTST=	000001	5508#	5510	5705#	5707	5785#	5787	5873#	5875	5961#	5963	6047#	6049								
SOCNT	056234	11371#	11400*	11413#																	
SOCTVL	055540	8060	11228	11253#																	
SOMODE	056236	11366#	11370*	11375	11378*	11389*	11415#														
SOVER	057410	11637	11657	11665	11674#																
SPASS	001326	2353#	4743*	5413*	5489	6257*	6258*	6266	6279	6285	6331*	7673									
SPASTM	001006	2252#																			
SPWRCT	057120	11589#	11590*	11599#																	
SPWRDN	057034	4719	6307	11584#	11592																
SPWRUP	057046	11584	11589#																		
SQUES	001314	2341#	4844	4879	4940	5027	5073	5132	5148	5256	5305	5331	5405	7012							
		7089	7775	7898	7944	11123	11535														
		8121	8146	8201	11019#																
SRAND	054634	8121	8146	8201	11019#																
SRDCHR	056660	11551#	11895																		
SRDDEC=	*****	11896																			
SRDLIN=	*****	11896																			
SRDOCT=	*****	11896																			
SRDSZ =	000000	11572#																			
SREGAD	001160	2295#																			
SREGO	001162	2297#	9371	12322																	
SREG1	001164	2298#	12322																		
SREG10	001202	2305#	7158*	7203*	8394*	8395*	8396	8434*	8437	8617*	8618*	8619	8663*	8666							
		9596#	9621*	9656*	12326	12334															
SREG11	001204	2306#	8435*	8664*	9597*	9622*	9657*	12326	12334												
SREG12	001206	2307#	8436*	8665*	9598*	9623*	9650*	9652*	12326	12334											
SREG13	001210	2308#	8438*	8440*	8442*	8443*	8667*	8669*	8671*	8672*	12326	12334									
SREG14	001212	2309#	6204*	8437*	8439*	8441*	8666*	8668*	8670*	12329	12334										
SREG15	001214	2310#	6205*	8444*	8445*	8673*	8674*	12329	12334												
SREG16	001216	2311#	8373*	8634*	12330	12334															

U
U
U

TYPNUM	2162#														
TYPOCS	2162#														
TYPOCT	2162#														
TYPTXT	2162#														
\$DECBN	1#														
\$OCTBN	1#	10952													
\$SCMRE	2258#	2297	2298	2299	2300	2301	2302	2303	2304	2305	2306	2307	2308	2309	2310
	2311	2312	2313	2314	2315	2316	2317	2318	2319	2320	2321	2322	2323	2324	2325
	2326	2327	2328												
\$SCMTM	2258#	2329	2330	2331	2332	2333	2334	2335	2336	2337					
\$SESCA	2162#														
\$SNEW	2162#	5508	5705	5785	5873	5961	6047								
\$SSET	11880#	11889	11890	11891	11892	11895	11896	11897	11898						
\$SSETM	4743#	6331#													
\$SSKIP	2162#	5497													
.EQUAT	2009#	2052													
.HEADE	2009#	2019													
.KT11	2009#	2162													
.SETUP	2009#	4688													
.SWRHI	2009#	2029													
.SWRLO	2009#	2041#	2042	2043											
.SACT1	2009#	2222													
.SAPT8	2345#														
.SAPTH	2009#	2233													
.SAPTY	2009#	11678													
.SCATC	2009#	2203													
.SCMTA	2009#	2258													
.SDB2D	2009#	11254													
.SDB2O	2009#	11215													
.SEOP	2009#	6241													
.SERRO	2009#	11483													
.SPOWE	2009#														
.SRAND	2009#	11008													
.SREAD	2009#	11535													
.SSAVE	2009#	11812													
.SSCOP	2009#	11620													
.SSIZE	2009#	11735													
.SSUPR	2009#	11316													
.STRAP	2009#	11857													
.STYPD	2009#	11416													
.STYPE	2009#	11044													
.STYPO	2009#	11339													

. ABS. 070713 000

ERRORS DETECTED: 0

DSKZ:CZR6ND, DSKZ:CZR6ND, SEQ/SOL/CRF/NL:TOC/EQ:QNEWSW/DOC=DSKM:DRIV10.P11, DSKM:CZR6ND.P11

RUN-TIME: 46 40 3 SECONDS

RUN-TIME RATIO: 460/90=5.1

CORE USED: 49K (97 PAGES)

DOCUMENT PAGES: 279