

# RK11/RK05

RK11 UTILITY PACKAGE  
CZRKIFO

AH-9238F-MC

COPYRIGHT © 74-78

FICHE 1 OF 1

JUN 1978

**digital**

MADE IN USA

This microfiche card contains a grid of frames. The first column on the left contains frames with text, likely labels or titles. The subsequent columns contain frames with data, which appears to be organized in a table format with multiple rows and columns. The data is too small to read clearly but follows a structured layout.

100-100000-0000

PRODUCT CODE: AC-9236F-MC  
PRODUCT NAME: CZRKIFD RK11 UTILITY PACKAGE  
DATE CREATED: MARCH, 1978  
MAINTAINER: DIAGNOSTIC GROUP  
AUTHOR: BOB COLLINS  
REVISED BY: JIM KAPADIA  
TOM SAWYER  
CHUCK HESS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1974, 1978 BY DIGITAL EQUIPMENT CORPORATION

## TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	STORAGE
2.3	PRELIMINARY PROGRAMS
3.0	LOADING PROCEDURE
4.0	STARTING PROCEDURE
5.0	OPERATING PROCEDURE
6.0	ERRORS
7.0	RESTRICTIONS
8.0	EXECUTION TIME
9.0	PROGRAM DESCRIPTION
9.1	PROGRAM INDEX
9.2	COMPATIBILITY PACKAGE
9.3	OSCILLATING SEEK PACKAGE
9.4	FORMATTER SURFACE VERIFIER
9.5	RK05 CONTROL PANEL TEST
9.6	RK05 CONTROL PANEL TEST # 2
9.7	HEAD ALIGNMENT ROUTINE
9.8	(DISK) POWER FAILURE TEST
9.9	SECTION SPECIAL
9.10	COMPATIBILITY ERROR RECOVERY

## 1. ABSTRACT

- 1.1 THIS PACKAGE CONTAINS 4 INDIVIDUAL UTILITY PROGRAMS FOR THE RKXX PLUS A MINI-MONITOR WHICH ALLOWS TEST SELECTION AND PARAMETER INPUT VIA THE CONSOLE DEVICE. ALL UTILITY PACKAGES ARE EXPLAINED IN DETAIL IN PARAGRAPH 9.

## 2. REQUIREMENTS

- 2.1 EQUIPMENT  
PDP-11 PROCESSOR  
BK MEMORY  
RK11 OR RKV11 CONTROLLER  
1-8 RK05 OR RK05F DISK DRIVES (DRIVE TYPES MAY BE MIXED)
- 2.2 STORAGE  
THIS PROGRAM REQUIRES BK
- 2.3 PRELIMINARY PROGRAMS  
THIS IS NOT A DIAGNOSTIC PACKAGE IT IS ASSUMED THAT ALL EQUIPMENT IS FUNCTIONAL

## 3. LOADING PROCEDURE

- 3.1 METHOD  
PROCEDURE FOR NORMAL BINARY TAPES SHOULD BE FOLLOWED
- ABSOLUTE LOADER MUST BE IN MEMORY.
  - PLACE BINARY TAPE IN READER.
  - LOAD ADDRESS, \*7500 (\*DETERMINED BY LOCATION OF LOADER).
  - PRESS "START" PROGRAM WILL LOAD.

## 4. STARTING PROCEDURE

- 4.1 CONTROL SWITCH SETTINGS  
NONE
- 4.2 STARTING ADDRESS  
200 MINI MONITOR
- 4.3 PROGRAM AND/OR OPERATOR ACTION  
LOAD PROGRAM INTO MEMORY  
SET SWITCH REGISTER TO STARTING ADDRESS (200)  
LOAD ADDRESS  
PRESS START

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 175 (B). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' whenever the program enters the scope routine or begins a new test. the 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL L' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

PROGRAM WILL TYPE MINI MONITOR ROUTINE

## 5. OPERATING PROCEDURE

- 5.1 OPERATIONAL SWITCH SETTINGS  
SEE SEC. 9.0 FOR SWITCHES APPLICABLE TO INDIVIDUAL ROUTINES.
- 5.2 SUBROUTINE ABSTRACTS  
NOT APPLICABLE
- 5.3 PROGRAM AND/OR OPERATOR ACTOR  
SEE INDIVIDUAL PACKAGE DESCRIPTION (PARAGRAPH 9)

## 6. ERRORS

- 6.1 ERROR HALTS AND DESCRIPTION  
IF HALTED A MAJOR PROBLEM EXIST CHECK CODE AT HALT PC TO DETERMINE WHAT OCCURRED.
- 6.2 ERROR RECOVERY  
EXPLAINED IN DETAIL IN INDIVIDUAL PACKAGE DESCRIPTION (PARAGRAPH 9)

## 7. RESTRICTIONS

- 7.1 STARTING RESTRICTIONS  
IT IS NOT RECOMMENDED THAT YOU START AT AN ADDRESS OTHER THAN 200. (REASON EXPLAINED IN PARAGRAPH 9.1) UNLESS DIRECTED TO BY THE PROGRAM.
- 7.2 OPERATIONAL RESTRICTIONS  
EXPLAINED IN DETAIL IN INDIVIDUAL PACKAGE DESCRIPTIONS (PARAGRAPH. 9)

## 8. EXECUTION TIME

VARIES WITH SELECTED ROUTINE, NUMBER OF DRIVES, ETC.

## 9. PROGRAM DESCRIPTION

THE RK11 UTILITY PACKAGE IS DIVIDED INTO EIGHT SECTIONS WHICH ALLOW COMPATABILITY TESTING, OSCILLATING SEEKS FOR SERVO ADJUSTMENT AND SEEK LOGIC WAVEFORM ANALYSIS, PACK FORMATTING AND SURFACE VERIFICATION, AND FRONT PANEL TESTING (INDICATOR LAMPS, SWITCHES, INTERLOCKS, ETC) AND VERIFICATION. THE PACKAGE IS DIVIDED INTO FIVE SECTIONS

SECTION	NAME
0	INDEX
1	COMPATIBILITY TEST
2	OSCILLATING SEEK PACKAGE
3	FORMATTER SURFACE VERIFIER
4	FRONT PANEL TEST
5	RK05 CONTROL PANEL TEST #2
6	HEAD ALIGNMENT ROUTINE
7	POWER FAILURE (DURING WRITE) TEST

NOTE: NORMAL LINKAGE TO ANY OF THESE PACKAGES IS THRU SECTION 0 (SEE PARAGRAPH 9.1)

9.1 SECTION 0 INDEX

PURPOSE: TO ALLOW THE USER TO SELECT AND RUN TESTS VIA THE CONSOLE DEVICE IN AN EFFORT TO FREE HIM FROM REMEMBERING VARIOUS SWITCH SETTINGS.

DESCRIPTION: LOAD START ADDRESS 200, A TABLE IS PRODUCED WHICH TELLS THE USER THE NAME AND TYPE OF THE TEST. (TYPE IS AN OCTAL CODE BY WHICH THE USER SELECTS THE TEST). AFTER THE TABLE IS TYPED, THE QUESTION "TYPE =" IS ASKED, THE USER THEN TYPES THE NUMERAL 0-4 TO SELECT A TEST.

USE: THIS IS EXAMPLE OF THE ACTUAL OUTPUT:

```

RK11 UTILITY PACKAGE

NAME                                TYPE
INDEX                                0
COMPATIBILITY PACKAGE                1
OSCILLATING SEEK PACKAGE              2
FORMATTER-SURFACE VERIFIER            3
RK05 CONTROL PANEL TEST               4
RK05 CONTROL PANEL TEST #2           5
HEAD ALIGNMENT ROUTINE                6
POWER FAILURE (WRITE) .EST           7
    
```

TYPE=X  
 WHERE "X" IS THE RESPONSE (0-7) BY THE USER

ERROR INFO: ANY ILLEGAL INPUT IS HANDLED, A QUESTION MARK IS TYPED AND THE QUESTION "TYPE =" IS RE-ASKED.

9.2 SECTION 1 COMPATIBILITY PACKAGE

PURPOSE: TO CONFIRM THE FACT THAT A GROUP OF DRIVES (A MAXIMUM OF EIGHT) ARE TRULY COMPATIBLE. THIS PACKAGE DOES NOT APPLY TO RK-05F DRIVES.

DESCRIPTION: THIS PACKAGE ALLOWS A USER TO AUTOMATICALLY TEST

# GO1

SEQ 0006

COMPATIBILITY OF UP TO EIGHT (8) DRIVES SIMPLY BY STATING THE DRIVE NUMBERS TO BE TESTED. THE TEST DOES THE REST, INSTRUCTING THE USER WHERE TO PLACE THE PACK. THE LIMITATIONS OF TESTING ARE IF THERE ARE (2) TWO PROCESSORS, FROM ONE (1) TO SEVEN (7) DRIVES MAY BE ON SYSTEM ONE, AND ONLY ONE (1) DRIVE (ANY DRIVE NUMBER) MAY BE ON SYSTEM TWO. COMPATIBILITY-A DEFINITION, COMPATIBILITY INFERS MORE THAN THE FACT THAT INFORMATION WHICH WAS WRITTEN ON ONE DRIVE CAN BE READ ON ANOTHER. FOR DRIVES TO BE CONSIDERED TRULY COMPATIBLE ANY DRIVE SHOULD BE ABLE TO READ WHAT WAS WRITTEN BY ANY OTHER DRIVE AND ALSO MUST BE ABLE TO OVERWRITE A PORTION OF INFORMATION WRITTEN BY ANOTHER DRIVE, WITH NEW INFORMATION, AND READ IT BACK. THIS IS A VERY BROAD DEFINITION BUT IS THE BASIC PREMISE OF TRUE COMPATIBILITY. THE BELOW IS AN EXAMPLE OF ACTUAL OUTPUT. THE USER WANTS TO RUN SINGLE PROCESSOR MODE AND TEST COMPATIBILITY ON THREE (3) DRIVES WHOSE UNIT NUMBERS ARE 0,1,3.....

USE:

\*\*\*\*\*

## EXAMPLE 1

INDEX	NAME	TYPE
	COMPATIBILITY PACKAGE	0
	OSCILLATING SEEK PACKAGE	1
	FORMATTER-SURFACE VERIFIER	2
	RK05 CONTROL PANEL TEST	3
	RK05 CONTROL PANEL TEST #2	4
	HEAD ALIGNMENT ROUTINE	5
	POWER FAILURE (WRITE) TEST	6
		7

TYPE=1  
DRIVE NUMBERS ON SYSTEM 1=0,1,3.

IS THERE A SECOND SYSTEM?N  
MOUNT PACK ON DRIVE #0  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
MOUNT PACK ON DRIVE #1  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
MOUNT PACK ON DRIVE #3  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
MOUNT PACK ON DRIVE #0  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
MOUNT PACK ON DRIVE #1  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
MOUNT PACK ON DRIVE #3  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
DONE!

INDEX	NAME	TYPE
	COMPATIBILITY PACKAGE	0
		1
		*****

THE USER SELECTED TYPE ONE (1) AND RECEIVED THE MESSAGE RKXX COMPATIBILITY PACKAGE AND WAS THEN ASKED FOR SYSTEM 1 DRIVES HE TYPES EACH SELECTED DRIVE NUMBER SEPARATED BY COMMAS HE TERMINATES THE STRING WITH A PERIOD THEN A CARRIAGE RETURN HE IS ASKED IF THERE IS A SECOND SYSTEM, HE TYPES N FOR NO. HE NOW RECEIVES A STRING OF MOVE DIRECTIVES TELLING HIM EXACTLY WHERE TO MOVE THE TEST PACK AND WHAT TO DO. FINALLY THE USER RECEIVES THE MESSAGE "DONE!" INDICATING A SUCCESSFUL PASS. AT THIS POINT ANY DRIVE WHICH HAS NOT BEEN DECLARED DOWN AND DID NOT RECEIVE AN ERROR\* MESSAGE IS COMPATIBLE WITH ANY OTHER SELECTED DRIVE MEETING THE SAME CONDITIONS. FINALLY THE INDEX ROUTINE IS AUTOMATICALLY RE-ENTERED AND USER IS READY TO MAKE ANOTHER SELECTION. \*SEE ERROR INFO TO DETERMINE THE TYPE OF ERROR WHICH CONSTITUTES INCOMPATABILITY.

\*\*\*\*\*

EXAMPLE 2

THE USER NOW DESIRES TO TEST COMPATIBILITY ON TWO SYSTEMS HE HAS UNITS 0,1 ON SYSTEM ONE AND UNIT 0 ON SYSTEM 2, IT GOES LIKE THIS....  
RK11 UTILITY PACKAGE

INDEX	NAME	TYPE
	COMPATIBILITY PACKAGE	0
	OSCILLATING SEEK PACKAGE	1
	FORMATTER-SURFACE VERIFIER	2
	RK05 CONTROL PANEL TEST	3
	RK05 CONTROL PANEL TEST #2	4
	HEAD ALIGNMENT ROUTINE	5
	POWER FAILURE (WRITE) TEST	6
		7

TYPE=1  
DRIVE NUMBERS ON SYSTEM 1=1,0

IS THERE A SECOND SYSTEM? Y  
DRIVE # =0  
MOUNT PACK ON DRIVE #1  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
MOUNT PACK ON DRIVE #0  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
LOAD AND START ADDRESS 210 ON SYSTEM #2  
AND TYPE THE BELOW WHEN ASKED ON SYSTEM #2

AND TYPE THE BELOW WHEN ASKED FOR IT.  
 WORD 1=000002  
 WORD 2=000200

\*\*\*\*\*  
 ...THE ONLY DIFFERENCE BETWEEN THIS AND SINGLE  
 SYSTEM IS THE NEW DIRECTIVE TO LOAD START 210  
 ETC. THE USER NOW LOADS AND STARTS SYSTEM TWO  
 AND THE BELOW IS TYPED...  
 \*\*\*\*\*

COMPATIBILITY-SYSTEM#2  
 WORD 1=000002  
 WORD 2=000200

MOUNT PACK ON DRIVE #0  
 MAKE PACK WRITE ENABLE  
 PRESS CONTINUE WHEN DRIVE RDY  
 DONE SYSTEM ? RESTART SYSTEM !, TYPE WORD 000077

\*\*\*\*\*  
 THE USER RESPONSE TO THE QUESTION WORD 1 =  
 BY TYPING WORD 1 FROM PROCESSOR ONE AND  
 WORD 2 =, BY TYPING WORD TWO FROM PROCESSOR 1  
 HE RECEIVES THE MOUNT COMMAND MOVES THE TEST PACK  
 TO SYSTEM TWO, DRIVE NUMBER (0), AND PRESSES  
 CONTINUE. NOW THE MESSAGE TO RETURN TO SYSTEM  
 ONE\*

\*SYSTEM ONE HAS BEEN IN A HALT STATE AND  
 SHOULD BE LEFT THAT WAY UNTIL THE RETURN FROM  
 SYSTEM TWO SO THAT TABLES, ETC. BUILT FOR THE  
 TEST WILL NOT BE DISTURBED.

\*\*\*\*\*

WORD=000077

MOUNT PACK ON DRIVE #1  
 MAKE PACK WRITE ENABLE  
 PRESS CONTINUE WHEN DRIVE RDY  
 MOUNT PACK ON DRIVE #0  
 MAKE PACK WRITE ENABLE  
 PRESS CONTINUE WHEN DRIVE RDY  
 DONE!

RK11 UTILITY PACKAGE

INDEX	NAME	TYPE
	COMPATIBILITY PACKAGE	0
	OSCILLATING SEEK PACKAGE	1
	FORMATTER-SURFACE VERIFIER	2
	RKUS CONTROL PANEL TEST	3
	RK05 CONTROL PANEL TEST #2	4
	HEAD ALIGNMENT ROUTINE	5
	POWER FAILURE (WRITE) TEST	6
		7

TYPE=

\*\*\*\*\*

THE USER NOW PRESSES CONTINUE ON PROCESSOR ONE AND IN RESPONSE TO THE QUESTION, WORD = TYPES THE WORD GIVEN TO HIM FROM PROCESSOR TWO THEN EVERYTHING BECOMES THE SAME AS A SINGLE SYSTEM. THE USER NEARLY FOLLOWS DIRECTIONS. ERROR INFO: SEE PARAGRAPH 9.6 SPECIAL SECTION

### 9.3 SECTION 2 OSCILLATING SEEK PACKAGE

**PURPOSE:** TO ALLOW THE USER TO MAKE SERVO ADJUSTMENTS AND/OR SEEK LOGIC CHECKOUT BY PERFORMING SEEKS BETWEEN USER SPECIFIED ADDRESS

**DESCRIPTION:** SELECT TYPE 2, THE USER THEN INSERTS THE DRIVES TO BE TESTED IN SW0 TO SW7 OF THE SWITCH REGISTER. A SWITCH IS SET FOR EACH DRIVE (E.G. SW2 TO TEST DRIVE 2). THE USER THEN INSERTS THE ADDRESS TO SEEK IN THE SWR. IF BOTH ADDRESS ARE LEGAL, 50 CYCLES (100 SEEKS) WILL BE MADE BETWEEN THE SPECIFIED ADDRESS THEN THE PROGRAM WILL LOOK AT THE SWR FOR POSSIBLE CHANGES THIS SHOULD ALLOW FOR GOOD STABLE TRACES ON AN OSCILLISCOPE. IT SHOULD BE NOTED THAT THE OSCILLATING SEEKS BETWEEN THE SPECIFIED CYLINDERS ARE DONE ON ALL AVAILABLE DRIVES. THE ONLY WAY TO EXIT IS HALT!, LOAD ADDRESS 200, HIT START.

**USE:** SELECT TYPE 2, RESPOND TO QUESTION WITH UNIT NUMBER..  
TYPE=2  
OSCILLATING SEEK PACKAGE  
SET SW0 TO SW7 TO SELECT THE DRIVES TO TEST AND CONTINUE. IF ALL SWITCHES ARE RESET, ALL AVAILABLE DRIVES WILL BE TESTED. TOGGLE THE "FIRST CYLINDER ADDRESS" (OUTER LIMIT) INTO THE LOW BYTE (BIT0-7) OF THE SWITCH REGISTER AND THE "LAST CYLINDER ADDRESS" (INNER LIMIT) INTO THE HIGH BYTE (BIT8-15). THEN PRESS CONTINUE  
...FOLLOW INSTRUCTIONS TYPED

**ERROR INFO:** IF AN ILLEGAL ADDRESS IS SELECTED A MESSAGE IS TYPED AND USER NEARLY SELECTS LEGAL ADDRESS AND DEPRESSES CONTINUE  
EXAMPLE TYPEOUT  
INVALID ADDRESS IN SWITCH REGISTER TRY AGAIN  
INVALID ADDRESS IN SWITCH REGISTER TRY AGAIN  
INVALID ADDRESS IN SWITCH REGISTER TRY AGAIN

**\*\*NOTE:\*\*** BOTH DRIVES OF AN RK-05F SHOULD NOT BE SELECTED FOR TESTING AT THE SAME TIME.

### 9.4 SECTION 3 FORMATTER-SURFACE VERIFIER

**PURPOSE:** TO FORMAT VIRGIN PACKS OR REFORMAT AN OLDER PACK AND VERIFY ITS SURFACE

**DESCRIPTION:** SELECT TYPE 3, RESPOND TO THE QUESTION BY SETTING SWITCHES CORRESPONDING TO DRIVE NUMBERS TO BE FORMATTED. THUS IF DRIVES 0,1,2 ARE TO BE FORMATTED SET SWITCHES 0,1,2. THE DRIVES ARE FORMATTED ONE AFTER ANOTHER AT COMPLETION PACK GOOD

USE: MESSAGE IS TYPED AND PACK IS FORMATTED.  
SELECT TYPE 3, RESPOND TO QUESTION WITH  
SETTING OF SWITCH REGISTER.  
\*\*\*\*\*

RK11 UTILITY PACKAGE

INDEX	NAME	TYPE
	COMPATIBILITY PACKAGE	0 1
	OSCILLATING SEEK PACKAGE	2
	FORMATTER-SURFACE VERIFIER	3
	RK05 CONTROL PANEL TEST	4
	RK05 CONTROL PANEL TEST #2	5
	HEAD ALIGNMENT ROUTINE	6
	POWER FAILURE (WRITE) TEST	7

TYPE=3  
FORMATTER-SURFACE VERIFIER, SET SW REG WITH DRIVE #'S

PACK GOOD.

RK11 UTILITY PACKAGE

INDEX	NAME	TYPE
	COMPATIBILITY PACKAGE	0 1

\*\*\*\*\*  
AFTER THE PACK IS FORMATTED A GOOD MESSAGE IS  
GIVEN AND A CHECK IS MADE TO SEE IF THERE ARE  
ANY MORE PACKS TO BE FORMATTED. IF THERE ARE  
NONE CONTROL IS TRANSFERRED TO THE MINI-MONITOR  
ERROR INFO: DRIVE PROBLEM, IF THE MESSAGE....  
SYSTEM ERROR  
.... IS TYPED IT INDICATES A FAULTY DRIVE OR  
CONTROLLER. RUN DIAGNOSTICS, THE PROCESSOR WILL HALT  
PRESS CONTINUE TO RETURN TO MINI MONITOR.  
BAD SPOT, OR SURFACE PROBLEM, ETC.

PACK FAILED AT (IN OCTAL) CYLINDER SECTOR SURFACE

9.5 SECTION 4 RK05 CONTROL PANEL TEST

PURPOSE: TO INSURE ALL SWITCHES INDICATOR LAMPS, AND INTERLOCKS  
ARE FUNCTIONAL IN THE RK05  
DESCRIPTION: SELECT TYPE 4, RESPOND TO QUESTION WITH UNIT NUMBER, FOLLOW  
DIRECTIONS GIVEN. AT COMPLETION MESSAGE "DONE!" IS GIVEN  
USE SELECT TYPE 4, RESPOND TO QUESTION WITH THE UNIT NUMBER....

\*\*\*\*\*

INDEX	NAME	TYPE
	COMPATABILITY PACKAGE	0 1
	OSCILLATING SEEK PACKAGE	2
	FORMATTER-SURFACE VERIFIER	3
	RK05 CONTROL PANEL TEST	4
	RK05 CONTROL PANEL TEST #2	5
	HEAD ALIGNMENT ROUTINE	6
	POWER FAILURE (WRITE) TEST	7

TYPE=4

RK05 CONTROL PANEL TEST, WHICH DRIVE?0  
 MOUNT PACK ON DRIVE#0  
 PLACE DRIVE IN RUN; SHOULD SEE THE RUN,  
 POWER, AND ON CYLINDER LAMPS LIGHT.  
 MAKE DRIVE WRITE ENABLE PRESS CONTINUE

WRITE PROTECT THE DRIVE THEN PRESS CONTINUE

CLEAR WRITE PROTECT THEN PRESS CONTINUE

CAUTION! TRY TO OPEN THE DOOR, NOT FORCE:  
 DOOR SHOULD NOT OPEN!  
 PRESS CONTINUE WHEN FINISHED

PUT DRIVE IN LOAD, WAIT FOR LOAD LIGHT  
 PRESS CONTINUE WHEN FINISHED

OPEN THE DOOR, PUT DRIVE IN RUN  
 CAUTION! IF RUN LIGHT ON ERROR! DEPRESS  
 LOAD IMMEDIATELY, CONTINUE WHEN FINISHED

REMOVE THE PACK, CLOSE THE DOOR  
 PUT DRIVE IN RUN, DRIVE SHOULD NOT  
 RUN...INTERLOCKS HAVE BEEN CHECKED  
 DONE!

#### RK11 UTILITY PACKAGE

NAME	TYPE
INDEX	0
COMPATABILITY PACKAGE	1
OSCILLATING SEEK PACKAGE	2
FORMATTER-SURFACE VERIFIER	3
RK05 CONTROL PANEL TEST	4
RK05 CONTROL PANEL TEST #2	5
HEAD ALIGNMENT ROUTINE	6
POWER FAILURE (WRITE TEST	7

TYPE=

\*\*\*\*\*

#### 9.6 SECTION 5 'RK05 CONTROL PANEL TEST #2

PURPOSE: TO GIVE A CONTINUOUS MONITORING AND  
 CHECKING CAPABILITY FOR THE FOLLOWING  
 CONDITIONS ON THE VARIOUS DRIVES:  
 OFF LINE (RDY CLR)/ON LINE (RDY SET)  
 WRITE PROTECTED/WRITE ENABLED  
 POWER LOW/POWER UP  
 SEEK INCOMPLETE/SEEK OK

DESCRIPTION: SELECT TYPE 5, PUT ALL THE DRIVES THAT  
 ARE TO BE MONITORED AND CHECKED ON 'RUN'.  
 NOTE THAT THIS IS IMPORTANT BECAUSE THE  
 PROGRAM HAS TO KNOW WHICH DRIVES ARE TO  
 BE CHECKED.

USE: AFTER HAVING SELECTED TYPE 5 AND PUTTING  
 THE DRIVES THAT ARE TO BE MONITORED ON  
 'RUN' THE PROGRAM PRINTS OUT ALL THE  
 DRIVES THAT ARE 'ON LINE'.

DRIVE 0 ON LINE  
 DRIVE 1 ON LINE  
 DRIVE 2 ON LINE

THE PROGRAM, THEN STARTS SCANNING ALL DRIVES, ONE AFTER THE OTHER. CHECKS IF THE DRIVE IS ON LINE OR OFF LINE (DRY SET OR CLEAR). THEN IT CHECKS IF THE DRIVE IS WRITE ENABLED OR WRITE PROTECTED. THEN A SEEK (TO CYLINDER 1) IS DONE AND 'DPL' BIT IS CHECKED TO SEE IF DRIVE POWER IS LOW OR OK. IF THE DRIVE IS POWERED, IT IS CHECKED IF THE SEEK IS DONE OR SEEK INCOMPLETE OCCURS. WHEN EVER ANY CHANGE IN THE STATUS IS FOUND, IT IS REPORTED. IF THE DRIVES PUT ON 'LOAD' AND BACK TO 'RUN', THE PROGRAM CHECKS IF THE DRIVE COMES ON LINE IN THE WRITE ENABLED MODE. IF NOT, AN ERROR MESSAGE (ERROR, NOT WRITE ENABLED) IS REPORTED. THEN THE DRIVE IS WRITE PROTECTED.  
 EX: IN A SYSTEM UNDER TEST, IF A DRIVE IS PUT ON 'LOAD' BY THE USER IT GETS REPORTED, IF THE USER SET 'WRITE PROT' IT GETS REPORTED. THE MESSAGES APPEAR AS FOLLOWING:

DRIVE 0 OFF LINE  
 DRIVE 1 WRITE PROTECTED  
 DRIVE 2 SIN  
 DRIVE 1 WRITE ENABLED  
 DRIVE 0 POWER LC  
 DRIVE 2 SEEK OK  
 DRIVE 0 POWER OK

NOTE THAT ONLY CHANGES IN STATUS ARE REPORTED. THESE CHANGES HAVE TO BE AFFECTED BY THE USER. IF ANY CHANGE IN STATUS IS NOT DETECTED AND REPORTED BY THE PROGRAM IT MIGHT IMPLY AN ERROR CONDITION.

#### 9.7 SECTION 6 HEAD ALIGNMENT ROUTINE

PURPOSE: TO PROVIDE A FACILITY FOR HEAD ALIGNMENT, WITH DYNAMIC SELECTION OF THE UPPER OR LOWER HEAD.

DESCRIPTION: WHEN THE ROUTINE IS SELECTED THE FOLLOWING MESSAGE APPEARS:  
 SET SW0=0 FOR SURFACE 0, SW0=1 FOR SURFACE 1.  
 SET SW1=1 TO TEST CYL 64, SET SW1=0 TO TEST CYLINDER 105.  
 SW2-15=0  
 PUT ANY SW FROM 2-15 HI TO SELECT NEW DRIVE

THEN THE FOLLOWING QUESTION IS ASKED:  
 DRIVE? THE USER  
 SHOULD TYPE IN THE DRIVE NUMBER THAT HE WANTS TO SELECT. THE DRIVE NUMBER IS SUFFIXED WITH AN 'F' TO TEST RK-05F TYPE DRIVES.

TYPE=6  
DRIVE=0 (CR)

THE UPPER OR THE LOWER HEAD CAN BE SELECTED BY SWITCH 0. IF SURFACE 0 IS TO BE SELECTED, PUT SW 0 TO 0. IF SURFACE 1 IS TO BE SELECTED PUT SW 0 ON 1. THE HEADS MAY BE POSITIONED AT CYLINDER 64 OR CYLINDER 105. SET SW1=0 FOR CYLINDER 105, SW1=1 FOR CYLINDER 64. THE PROGRAM POSITIONES THE HEADS ON THE SELECTED CYLINDER AND CONTINUOUSLY READS FROM THE SURFACE SELECTED. IF THE USER WISHES TO SELECT THE OTHER HEAD OR CYLINDER IT CAN BE DYNAMICALLY DONE BY FLIPPING SW 0 OR SW 1. IF SOME OTHER DRIVE IS TO BE SELECTED, ANY SWITCH BETWEEN SW 2 AND SW 15 SHOULD BE PUT UP. THE QUESTION - DRIVE? IS ASKED AGAIN. THIS IS A CONTINUOUS ROUTINE, HENCE TO EXIT A HALT HAS TO BE DONE.

\*\*\* NOTE \*\*\* ALIGNMENT IS DONE WITH AN RK-05J CARTRIDGE SO IF AN F TYPE DRIVE IS SELECTED, CYLINDER 14 OF THE RK-05J IS CYLINDER 130 OF THE F DRIVE (EVEN DRIVE). CYLINDER 105 BECOMES CYLINDER 5 OF THE 000 DRIVE ON THE RK-05F.

SECTION 7 (DISK) POWER FAILURE (DURING WRITE) TEST  
PURPOSE THIS TEST CHECKS THAT DATA WRITTEN ON THE DISK IS NOT DESTROYED WHEN THE DISK SENSES A LOSS OF POWER (POWER FAILS) WHILE DOING A WRITE.  
DESCRIPTION: UPON SELECTING THIS TEST, THE PROGRAM FINDS OUT THE FIRST AVAILABLE DRIVE AND INDICATES IT TO THE USER BY TYPING A MESSAGE:  
DRIVE X X=DRIVE NUMBER 0,1...7  
THEN IT PROCEEDS TO TO WRITE UNIQUE PATTERNS ON CYLINDERS 0 TO 15 (DECIMAL) OF THAT DRIVE. THE HEADS ARE THEN POSITIONED ON CYLINDER 10 AND THE USER IS ASKED TO DROP POWER ON THAT DRIVE:  
DROP POWER  
MEANWHILE WRITE IS BEING DONE ON CYLINDER 10. ON GETTING THE ABOVE MESSAGE THE USER SHOULD DROP THE POWER ON THAT DRIVE. ON SENSING A LOSS OF POWER, THE PROGRAM WILL ASK THE USER TO PUT THE POWER ON AGAIN:  
POWER ON  
ON RECEIVING THE ABOVE MESSAGE THE USER SHOULD PUT THE POWER ON. ON DETECTING POWER UP THE PROGRAM PROCEEDS TO CHECK THAT THE DATA WRITTEN ON CYLINDERS 0 TO 15 WAS INTACT. IF A WRITE CHECKS ERROR OCCURS (POSSIBLY MEANING THAT SOME OF THE DATA WAS DESTROYED DURING THE LOSS OF POWER) IT IS REPORTED AS FOLLOWING:  
ERROR, ON POWER-UP, RKDA=XXXX  
\*\*\* IS THE CONTENTS OF RKDA AT THE TIME OF ERROR

THE PROGRAM DOES THE ABOVE POWER FAIL TEST

ON ALL DRIVES THAT ARE PRESENT, ONE AFTER THE OTHER IN A ROUND BOBBIN FASHION. EXIT IS THROUGH HALT.

9.9 SECTION SPECIAL

FOR THE BELOW EXAMPLES THE FOLLOWING FORMAT WILL BE USED.  
 THE ACTUAL TYPEOUT AND RESPONSE : COMMENTS ON WHAT OCCURRED OR WHAT TO DO  
 \*NOTES IF NECESSARY FOR CLARITY

ERROR EXAMPLE 1

```

FORMATTER-SURFACE VERIFIER      3
RK05 CONTROL PANEL TEST        4

TYPE=1                          :TYPE 1 SELECTION
DRIVE NUMBERS ON SYTEM 1=0.     :DRIVE #0 SELECTED

IS THERE A SECOND SYSTEM?N     :NO SECOND SYSTEM
MOUNT PACK ON DRIVE #0         :CONTINUE PRESSED BUT
MAKE PACK WRITE ENABLE         :WRITE PROTECT ON
PRESS CONTINUE WHEN DRIVE RDY  :CLEAR WRITE PROTECT SWITCH
DRIVE WRITE PROTECTED.         :NOW RUNS TO FINISH
DRIVE WRITE PROTECTED          :THIS DOES NOT EFFECT
DONE!                           :OUTCOME OF TEST

      RK11 UTILITY PACKAGE

      NAME          TYPE
INDEX          0
COMPATIBILITY PACKAGE 1
OSCILLATING SEEK PACKAGE 2
    
```

ERROR EXAMPLE 2

```

      RK11 UTILITY PACKAGE

      NAME          TYPE
INDEX          0
COMPATIBILITY PACKAGE 1
OSCILLATING SEEK PACKAGE 2
FORMATTER-SURFACE VERIFIER 3
RK05 CONTROL PANEL TEST 4
RK05 CONTROL PANEL TEST #2 5
HEAD ALIGNMENT ROUTINE 6
POWER FAILURE (WRITE) TEST 7

TYPE=1
DRIVE NUMBERS ON SYTEM 1=0.

IS THERE A SECOND SYSTEM?N
MOUNT PACK ON DRIVE #0
MAKE PACK WRITE ENABLE
PRESS CONTINUE WHEN DRIVE
DRIVE NOT READY
DRIVE NOT READY
DRIVE NOT READY
DRIVE NOT READY
DRIVE NOT READY
DRIVE NOT READY

:CONTINUE PRESSED BUT
:DRIVE NOT READY. IF UP
:TO SPEED ETC. AND MESSAGE
:OCCURRING - STATIC SHOULD BE
    
```



DRIVE NUMBERS ON SYTEM 1=0.

```
IS THERE A SECOND SYSTEM?N      ;SAME AS ABOVE BUT FUNCTION
MOUNT PACK ON DRIVE #0          ;WAS A CONTROL RESET
MAKE PACK WRITE ENABLE
PRESS CONTINUE WHEN DRIVE RDY   ;ALL COMMENTS ARE THE SAME
CONTROL RESET TIMED OUT         ;AS FYAMPLE 3
CONTROL RESET TIMED OUT
CONTROL RESET TIMED OUT
CONTROL RESET TIMED OUT
```

\*A SINGULAR OCCURANCE AS ABOVE IS NOT A PROBLEM  
AND WILL NOT EFFECT COMPATABILITY

#### ERROR EXAMPLE 5

THE BELOW ERRORS DO, ALWAYS, EFFECT COMPATABILITY.  
IN THE FIRST TYPE THE DRIVE IS DOWN  
INDICATING THAT (5) FIVE HARD OR SOFT  
ERRORS OCCURRED. THE TEST WILL CONTINUE  
AGAINST THE OTHER DRIVES BUT THERE IS A  
PROBLEM IN THIS DRIVE AND IT SHOULD BE  
CONSIDERED NON EXISTENT AS FAR AS COMPATABILITY  
GOES. THAT IS TO SAY IT IS NOT TESTED, THEREFORE  
NOT NECESSARILY COMPATABLE OR INCOMPATABLE.

RK11 UTILITY PACKAGE

INDEX	NAME	TYPE
	COMPATIBILITY PACKAGE	0
	OSCILLATING SEEK PACKAGE	1
	FORMATTER-SURFACE VERIFIER	2
	RK05 CONTROL PANEL TEST	3
	RK05 CONTROL PANEL TEST #2	4
	HEAD ALIGNMENT ROUTINE	5
	POWER FAILURE (WRITE) TEST	6
		7

TYPE=1  
DRIVE NUMBERS ON SYTEM 1=0.

```
IS THERE A SECOND SYSTEM?N
MOUNT PACK ON DRIVE #0
MAKE PACK WRITE ENABLE
PRESS CONTINUE WHEN DRIVE RDY
5 ERRORS OCCURRED DRIVE DECLARED DOWN!! NOT TESTED !
DONE!
```

RK11 UTILITY PACKAGE

INDEX	NAME	TYPE
	COMPATIBILITY PACKAGE	0
		1

\*IN THE ABOVE CASE THE MESSAGE "3 SEEK INCOMPLETE  
ERRORS OCCURRED DRIVE DECLARED DOWN!! NOT TESTED!"  
MAY OCCUR IT IS THE SAME ERROR AS DESCRIBED ABOVE  
EXCEPT THAT IT IS CAUSED BY 3 SEEK ERRORS OCCURRING  
ON ONE DRIVE.

#### ERROR EXAMPLE 6

## RK11 UTILITY PACKAGE

NAME	TYPE
INDEX	0
COMPATABILITY PACKAGE	1
OSCILLATING SEEK PACKAGE	2
FORMATTER-SURFACE VERIFIER	3
RK05 CONTROL PANEL TEST	4
RK05 CONTROL PANEL TEST ROUTINE	5
HEAD ALIGNMENT ROUTINE	6
POWER FAILURE (WRITE) TEST	7

TYPE=1  
DRIVE NUMBERS ON SYSTEM 1=0.

IS THERE A SECOND SYSTEM?Y  
DRIVE # =1  
MOUNT PACK ON DRIVE #0  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
LOAD AND START ADDRESS 210 ON SYSTEM #2  
AND TYPE THE BELOW WHEN ASKED FOR IT.  
WORD 1=101000  
WORD=000177

MOUNT PACK ON DRIVE #0  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
ERROR! DATA WRITTEN BY DRIVE 1 CANNOT BE READ.  
ADDR=002764 EXPCTD=077400 RECVD=177000  
ADDR=002764 EXPCTD=077400 RECVD=077600  
ADDR=002764 EXPCTD=077400 RECVD=037600  
ADDR=002764 EXPCTD=077400 RECVD=037600  
ADDR=002764 EXPCTD=077400 RECVD=037600  
ERROR! DATA WRITTEN BY DRIVE 1 CANNOT BE READ.  
ADDR=007624 EXPCTD=077400 RECVD=177000  
ERROR! DATA WRITTEN BY DRIVE 1 CANNOT BE READ.  
ADDR=007633 EXPCTD=077400 RECVD=177000  
ADDR=007633 EXPCTD=077400 RECVD=177000  
DONE!

## RK11 UTILITY PACKAGE

NAME	TYPE
INDEX	0
COMPATABILITY PACKAGE	1
OSCILLATING SEEK PACKAGE	2
FORMATTER-SURFACE VERIFIER	3
RK05 CONTROL PANEL TEST	4
RK05 CONTROL PANEL TEST #2	5
HEAD ALIGNMENT ROUTINE	6
POWER FAILURE (WRITE) TEST	7

TYPE=  
THE ABOVE ERROR MESSAGE SHOWS A COMPATABILITY  
PROBLEM. ALL ERRORS OCCURRED ON HEAD ONE OF  
DRIVE 0 TRYING TO READ INFORMATION WRITTEN BY  
DRIVE 1.

ERROR EXAMPLE 7

```

MOUNT PACK ON DRIVE #0
MAKE PACK WRITE ENABLE
PRESS CONTINUE WHEN DRIVE RDY
ERROR! DATA WRITTEN BY DRIVE 1 CANNOT BE READ.
ADDR=000367 EXPCTD=077400 RECVD=077600
ADDR=000367 EXPCTD=077400 RECVD=037600
ADDR=000367 EXPCTD=077400 RECVD=037600
ADDR=000367 EXPCTD=077400 RECVD=037600
ADDR=000367 EXPCTD=077400 RECVD=037600
ERROR! DATA WRITTEN BY DRIVE 1 CANNOT BE READ.
ADDR=002564 EXPCTD=077400 RECVD=077600
ADDR=002564 EXPCTD=077400 RECVD=037600
ADDR=002564 EXPCTD=077400 RECVD=037600
ADDR=002564 EXPCTD=077400 RECVD=037600
ADDR=002564 EXPCTD=077400 RECVD=037600
ERROR! DATA WRITTEN BY DRIVE 1 CANNOT BE READ.
ADDR=002764 EXPCTD=077400 RECVD=077600
ADDR=002764 EXPCTD=077400 RECVD=037600
ADDR=002764 EXPCTD=077400 RECVD=037600
ADDR=002764 EXPCTD=077400 RECVD=037600
ADDR=002764 EXPCTD=077400 RECVD=037600
ERROR! DATA WRITTEN BY DRIVE 1 CANNOT BE READ.
ADDR=002767 EXPCTD=077400 RECVD=177000
5 ERRORS OCCURRED DRIVE DECLARED DOWN!! NOT TESTED!
DONE!

```

IN THE ABOVE EXAMPLE THE PROBLEM IS EXTREME. THE DRIVE WAS DECLARED DOWN DO TO CHECKSUM ERRORS. (TO SEE HOW THIS WAS DETERMINED SEE PARAGRAPH 9.7). NOTICE ALSO THE PROBLEM DID NOT START APPEARING UNTIL CYLINDER 7, AND WAS NOT FATAL UNTIL CYLINDER 57, AGAIN HEAD #1 WAS A COMMON FACTOR.

\*\*\*\*\*

#### 9.10 COMPATIBILITY ERROR RECOVERY

ALTHOUGH A UTILITY PACKAGE IS NOT A TRUE DIAGNOSTIC IT IS OF BENEFIT TO THE USER TO AT TIMES, BE ABLE TO MODIFY THE PROGRAM TO RECIEVE MORE INFORMATION OR CONTROL PARAMETERS

1. THERE ARE TWO STRATEGICALLY PLACED NO-OPS WHICH IF CHANGED TO HALTS, MAY BE OF HELP TO THE USER. ONE IS IN THE 'EXECUTE' ROUTINE WHICH ALLOWS THE USER TO EXAMINE THE DISK ADDRESS, BUS ADDRESS, WORD COUNT AND CONTROL REGISTERS IN TEMPORARY LOCATIONS JUST PRIOR TO LOADING AND EXECUTION. THE SECOND IS IN THE 'ERRCHK' ROUTINE WHICH ALLOW THE USER TO EXAMINE THE RKR REGISTER BEFORE THE PROGRAM CORRECTS ANY ERRORS WHICH WHICH MAY HAVE OCCURRED.
2. IF PLAGED BY CHECKSUM ERRORS AND THE USER WISHES MORE ERROR MAPING THEN HE MAY MODIFY THE MASK WORD AT LOCATION 'ERRCHK+2' TO ONLY RECOGNIZE HARD ERRORS.
3. TO INCREASE OR DECREASE THE NUMBER OF RETRYS ALLOWED

BEFORE A DRIVE IS DECLARED DOWN, GO TO THE  
'MOUNT' ROUTINE, MODIFY THE SETUP OF LOCATIONS  
'ECNT' AND 'CNTSIN' AND YOU HAVE IT!

4. IF THE USER DECIDES, SAY BECAUSE OF A  
LARGE NUMBER OF FAILURES, TO ALTER THE NUMBER  
OF PRINTOUTS PER SECTOR ON FAILURES (THE TYPE IN  
ERROR EXAMPLE 6 AND 7) HE MAY MODIFY THE SETUP  
OF 'CHKCNT' IN THE 'RDCHK' ROUTINE.

A FINAL LOOK: THE FOLLOWING SECTION SHOWS ALL PACKAGES  
CALLED IN SEQUENCE, NONE WITH ERRORS.  
RK11 UTILITY PACKAGE

NAME	TYPE
INDEX	0
COMPATABILITY PACKAGE	1
OSCILLATING SEEK PACKAGE	2
FORMATTER-SURFACE VERIFIER	3
RKDS CONTROL PANEL TEST	4
RKDS CONTROL PANEL TEST #2	5
HEAD ALIGNMENT ROUTINE	6
POWER FAILURE (WRITE) TEST	7

TYPE=0

RK11 UTILITY PACKAGE

NAME	TYPE
INDEX	0
COMPATABILITY PACKAGE	1
OSCILLATING SEEK PACKAGE	2
FORMATTER-SURFACE VERIFIER	3
RKDS CONTROL PANEL TEST	4
RKDS CONTROL PANEL TEST #2	5
HEAD ALIGNMENT ROUTINE	6
POWER FAILURE (WRITE) TEST	7

TYPE=1

DRIVE NUMBERS ON SYSTEM 1=0,1,3.

IS THERE A SECOND SYSTEM?N  
MOUNT PACK ON DRIVE #0  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
MOUNT PACK ON DRIVE #1  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
MOUNT PACK ON DRIVE #3  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
MOUNT PACK ON DRIVE #0  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
MOUNT PACK ON DRIVE #1  
MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
MOUNT PACK ON DRIVE #3

MAKE PACK WRITE ENABLE  
PRESS CONTINUE WHEN DRIVE RDY  
DONE!

## RK11 UTILITY PACKAGE

INDEX	NAME	TYPE
0	COMPATABILITY PACKAGE	0
1	OSCILLATING SEEK PACKAGE	1
2	FORMATTER-SURFACE VERIFIER	2
3	RK05 CONTROL PANEL TEST	3
4	RK05 CONTROL PANEL TEST #2	4
5	HEAD ALIGNMENT ROUTINE	5
6	POWER FAILURE (WRITE) TEST	6
7		7

TYPE=2  
OSCILLATING SEEK PACKAGE, WHICH DRIVE?0  
TOGGLE THE "FIRST CYLINDER ADDRESS" (OUTER LIMIT)  
INTO THE LOW BYTE (BIT0-7) OF THE SWITCH REGISTER AND THE "LAST  
CYLINDER ADDRESS" (INNER LIMIT) INTO THE HIGH  
BYTE (BIT8-15), THEN PRESS CONTINUE.

## RK11 UTILITY PACKAGE

INDEX	NAME	TYPE
0	COMPATABILITY PACKAGE	0
1	OSCILLATING SEEK PACKAGE	1
2	FORMATTER-SURFACE VERIFIER	2
3	RK05 CONTROL PANEL TEST	3
4	RK05 CONTROL PANEL TEST #2	4
5	HEAD ALIGNMENT ROUTINE	5
6	POWER FAILURE (WRITE) TEST	6
7		7

TYPE=3  
FORMATTER-SURFACE VERIFIER, WHICH DRIVE?0  
PACK GOOD.

## RK11 UTILITY PACKAGE

INDEX	NAME	TYPE
0	COMPATABILITY PACKAGE	0
1	OSCILLATING SEEK PACKAGE	1
2	FORMATTER-SURFACE VERIFIER	2
3	RK05 CONTROL PANEL TEST	3
4	RK05 CONTROL PANEL TEST #2	4
5	HEAD ALIGNMENT ROUTINE	5
6	POWER FAILURE (WRITE) TEST	6
7		7

TYPE=4  
RK05 CONTROL PANEL TEST, WHICH DRIVE?0  
MOUNT PACK ON DRIVE #0  
PLACE DRIVE IN RLY ; SHOULD SEE THE RUN,  
POWER, AND ON CYLINDER LAMPS LIGHT.  
MAKE DRIVE WRITE ENABLE PRESS CONTINUE  
WRITE PROTECT THE DRIVE THEN PRESS CONTINUE



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55

```

.TITLE MAINDEC-11-DZRKI-E
.*COPYRIGHT (C) 1974,1977
.*DIGITAL EQUIPMENT CORP.
.*MAYNARD, MASS. 01754
.*
.*PROGRAM BY BOB COLLINS
.*
.*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
.*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
.*
$TN=1
$SWR=160000      ;;HALT ON ERROR, LOOP ON TEST, INHIBIT ERROR TYP0UT

.*REVISD BY JIM KAPADIA
.*REVISD BY TOM SAWYER FEB 27, 1976
.*REVISD BY CHUCK HESS AUGUST, 1976

.SBTL BASIC DEFINITIONS

.*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
.EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL

.*MISCELLANEOUS DEFINITIONS
HT= 11                ;;CODE FOR HORIZONTAL TAB
LF= 12                ;;CODE FOR LINE FEED
CR= 15                ;;CODE FOR CARRIAGE RETURN
CRLF= 200            ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776           ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLM= 177774         ;;STACK LIMIT REGISTER
PIRQ= 177772          ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570          ;;HARDWARE SWITCH REGISTER
DDISP= 177570         ;;HARDWARE DISPLAY REGISTER

.*GENERAL PURPOSE REGISTER DEFINITIONS
R0= %0                ;;GENERAL REGISTER
R1= %1                ;;GENERAL REGISTER
R2= %2                ;;GENERAL REGISTER
R3= %3                ;;GENERAL REGISTER
R4= %4                ;;GENERAL REGISTER
R5= %5                ;;GENERAL REGISTER
R6= %6                ;;GENERAL REGISTER
R7= %7                ;;GENERAL REGISTER
SP= %6                ;;STACK POINTER
PC= %7                ;;PROGRAM COUNTER

.*PRIORITY LEVEL DEFINITIONS
PR0= 0                ;;PRIORITY LEVEL 0
PR1= 40               ;;PRIORITY LEVEL 1
PR2= 100              ;;PRIORITY LEVEL 2
PR3= 140              ;;PRIORITY LEVEL 3
PR4= 200              ;;PRIORITY LEVEL 4

000001
160000

001100

000011
000012
000015
000200
177776

177774
177772
177570
177570

000000
000001
000002
000003
000004
000005
000006
000007
000006
000007

000000
000040
000100
000140
000200

```

57 000300  
58 000340  
59  
60  
61 100000  
62 040000  
63 020000  
64 010000  
65 004000  
66 002000  
67 001000  
68 000400  
69 000200  
70 000100  
71 000040  
72 000020  
73 000010  
74 000004  
75 000002  
76 000001  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89 100000  
90 040000  
91 020000  
92 010000  
93 004000  
94 002000  
95 001000  
96 000400  
97 000200  
98 000100  
99 000040  
100 000020  
101 000010  
102 000004  
103 000002  
104 000001  
105  
106  
107  
108  
109  
110  
111

PR6= 300 ;: PRIORITY LEVEL 6  
PR7= 340 ;: PRIORITY LEVEL 7

.\*"SWITCH REGISTER" SWITCH DEFINITIONS

SW15= 100000  
SW14= 40000  
SW13= 20000  
SW12= 10000  
SW11= 4000  
SW10= 2000  
SW09= 1000  
SW08= 400  
SW07= 200  
SW06= 100  
SW05= 40  
SW04= 20  
SW03= 10  
SW02= 4  
SW01= 2  
SW00= 1  
.EQUIV SW09,SW9  
.EQUIV SW08,SW8  
.EQUIV SW07,SW7  
.EQUIV SW06,SW6  
.EQUIV SW05,SW5  
.EQUIV SW04,SW4  
.EQUIV SW03,SW3  
.EQUIV SW02,SW2  
.EQUIV SW01,SW1  
.EQUIV SW00,SW0

..DATA BIT DEFINITIONS (BIT00 TO BIT15)

BIT15= 100000  
BIT14= 40000  
BIT13= 20000  
BIT12= 10000  
BIT11= 4000  
BIT10= 2000  
BIT09= 1000  
BIT08= 400  
BIT07= 200  
BIT06= 100  
BIT05= 40  
BIT04= 20  
BIT03= 10  
BIT02= 4  
BIT01= 2  
BIT00= 1  
.EQUIV BIT09,BIT9  
.EQUIV BIT08,BIT8  
.EQUIV BIT07,BIT7  
.EQUIV BIT06,BIT6  
.EQUIV BIT05,BIT5  
.EQUIV BIT04,BIT4  
.EQUIV BIT03,BIT3

```

113 .EQUIV BIT01,BIT1
114 .EQUIV BIT00,BIT0
115
116 .*BASIC "CPU" TRAP VECTOR ADDRESSES
117 000004 ERRVEC= 4 ;: TIME OUT AND OTHER ERRORS
118 000010 RESVEC= 10 ;: RESERVED AND ILLEGAL INSTRUCTIONS
119 000014 TBITVEC=14 ;: "T" BIT
120 000014 TRTVEC= 14 ;: TRACE TRAP
121 000014 BPTVEC= 14 ;: BREAKPOINT TRAP (BPT)
122 000020 IOTVEC= 20 ;: INPUT/OUTPUT TRAP (IOT) **SCOPE**
123 000024 PWRVEC= 24 ;: POWER FAIL
124 000030 EMTVEC= 30 ;: EMULATOR TRAP (EMT) **ERROR**
125 000034 TRAPVEC=34 ;: "TRAP" TRAP
126 000060 TKVEC= 60 ;: TTY KEYBOARD VECTOR
127 000064 TPVEC= 64 ;: TTY PRINTER VECTOR
128 000240 PIRQVEC=240 ;: PROGRAM INTERRUPT REQUEST VECTOR
129
130 .SBTTL TRAP CATCHER
131 000000 .=0
132 ;: *ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ". +2,HALT"
133 ;: *SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
134 ;: *LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
135 000174 .=174
136 000174 000000 DISPREG: .WORD 0 ;: SOFTWARE DISPLAY REGISTER
137 000176 000000 SWREG: .WORD 0 ;: SOFTWARE SWITCH REGISTER
138
139 000200 000137 001434 .SBTTL STARTING ADDRESS(ES) ;: JUMP TO STARTING ADDRESS OF PROGRAM
140 000210 000210 JMP #STARTR
141 000210 112737 000377 001312 .=210 MOVB #377,#MODE
142 000216 000137 001440 JMP #START
143 .SBTTL ACT11 HOOKS
144
145 ;: *****
146 ;: HOOKS REQUIRED BY ACT11
147 000222 $SVPC=. ;: SAVE PC
148 000046 000046 .=46
149 000046 001400 $ENDAD ;: 1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
150 000052 000052 . 52
151 000052 000000 .WJRD 0 ;: 2)SET LOC.52 TO ZERO

```

153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207

001100  
001100  
001102  
001103  
001104  
001106  
001110  
001112  
001114  
001115  
001116  
001120  
001122  
001124  
001126  
001130  
001132  
001134  
001135  
001136  
001140  
001142  
001144  
001146  
001150  
001152  
001154  
001155  
001156  
001157  
001160  
001161  
001162  
001164  
001166  
001206  
001210  
001212  
001214  
001216  
001220  
001222  
001224  
001226

000000  
000000  
000  
000  
000000  
000000  
000000  
000000  
000  
001  
000000  
000000  
000000  
000000  
000000  
000000  
000  
000  
000000  
177570  
177570  
177560  
177562  
177564  
177566  
000  
002  
012  
000  
077  
015  
000012  
000000  
000010  
152525  
077777  
000000  
012345  
125252  
000001  
177777  
154320  
000010

.SBTTL COMMON TAGS  
\*\*\*\*\*  
: THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS  
: USED IN THE PROGRAM.  
.=1100  
\$CMTAG: .WORD 0  
\$PASS: .WORD 0  
\$STNM: .BYTE 00  
\$ERFLG: .BYTE 00  
\$ICNT: .WORD 00  
\$LPADR: .WORD 00  
\$LPERR: .WORD 00  
\$ERTTL: .WORD 00  
\$ITEMB: .BYTE 00  
\$ERMAX: .BYTE 1  
\$ERRPC: .WORD 00  
\$GDADR: .WORD 00  
\$BDADR: .WORD 00  
\$GDDAT: .WORD 00  
\$BDDAT: .WORD 00  
\$AUTOB: .BYTE 00  
\$INTAG: .BYTE 00  
\$SWR: .WORD 0  
\$DISP: .WORD 0  
\$TKS: 177560  
\$TKB: 177562  
\$TPS: 177564  
\$TPB: 177566  
\$NULL: .BYTE 0  
\$FILLS: .BYTE 2  
\$FILLC: .BYTE 12  
\$TPFLG: .BYTE 0  
\$QUES: .ASCII /?  
\$CRLF: .ASCII <15>  
\$LF: .ASCII <12>  
\*\*\*\*\*  
\$DRACTV: .WORD 0  
LOGA: .BLKW 10  
DRVO: .WORD 152525  
.WORD 077777  
.WORD 000000  
.WORD 012345  
.WORD 125252  
.WORD 000001  
.WORD 177777  
.WORD 154320  
RDTBL: .BLKW 10

START OF COMMON TAGS  
CONTAINS PASS COUNT  
CONTAINS THE TEST NUMBER  
CONTAINS ERROR FLAG  
CONTAINS SUBTEST ITERATION COUNT  
CONTAINS SCOPE LOOP ADDRESS  
CONTAINS SCOPE RETURN FOR ERRORS  
CONTAINS TOTAL ERRORS DETECTED  
CONTAINS ITEM CONTROL BYTE  
CONTAINS MAX. ERRORS PER TEST  
CONTAINS PC OF LAST ERROR INSTRUCTION  
CONTAINS ADDRESS OF 'GOOD' DATA  
CONTAINS ADDRESS OF 'BAD' DATA  
CONTAINS 'GOOD' DATA  
CONTAINS 'BAD' DATA  
RESERVED--NOT TO BE USED  
AUTOMATIC MODE INDICATOR  
INTERRUPT MODE INDICATOR  
ADDRESS OF SWITCH REGISTER  
ADDRESS OF DISPLAY REGISTER  
TTY KBD STATUS  
TTY KBD BUFFER  
TTY PRINTER STATUS REG. ADDRESS  
TTY PRINTER BUFFER REG. ADDRESS  
CONTAINS NULL CHARACTER FOR FILLS  
CONTAINS # OF FILLER CHARACTERS REQUIRED  
INSERT FILL CHARS. AFTER A "LINE FEED"  
"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)  
QUESTION MARK  
CARRIAGE RETURN  
LINE FEED  
\*\*\*\*\*  
ACTIVE DRIVE WORD  
TABLE OF ACTIVE DRIVE WORDS  
TABLE OF PATTERN = TO DRIVE #'S  
TABLE OF READ ADDRESS

209					
210	001256	377	MSKTBL: .BYTE	377	: TABLE OF CYLINDER BASE FOR AUTO MODE
211	001257	177	.BYTE	177	
212	001260	077	.BYTE	077	
213	001261	037	.BYTE	037	
214	001262	017	.BYTE	017	
215	001263	007	.BYTE	007	
216	001264	003	.BYTE	003	
217	001265	001	.BYTE	001	
218					
219	001266	000	BASE: .BYTE	0	: CYL 0 BASE CYLINDER ADDRESS
220	001267	050	.BYTE	50	: CYL 40 BASE CYLINDER ADDRESS
221	001270	120	.BYTE	120	: CYL 80 BASE CYLINDER ADDRESS
222	001271	170	.BYTE	170	: CYL 120 BASE CYLINDER ADDRESS
223	001272	240	.BYTE	240	: CYL 160 BASE CYLINDER ADDRESS
224	001273	303	.BYTE	303	: CYL 195 BASE CYLINDER ADDRESS
225					
226	001274	000011	CYLtbl: BLKB	11	: TABLE SELECTED BASES
227					
228	001305	000	SECTBL: .BYTE	0	: SECTOR 0
229	001306	004	.BYTE	4	: SECTOR 4
230	001307	007	.BYTE	7	: SECTOR 7
231	001310	013	.BYTE	13	: SECTOR 12
232					
233	001311	000	DRCNT1: .BYTE	0	: COUNT OF NUMBER OF DRIVES ON SYS. 1
234	001312	000	MODE: .BYTE	0	: IF -1 START 210 SELECTED
235	001313	000	PRNUM: .BYTE	0	: IF 0 1 PROCESSOR SELECTED
236	001314	000	DRIVE: .BYTE	0	: DRIVE # UNDER TEST (MAN+AUTO MODE)
237	001315	000	CYLBAS: .BYTE	0	: BASE SELECTED (MANUAL MODE)
238	001316	000	COMND: .BYTE	0	: IF 0 WRITE COMMAND
239	001317	000	WRITBY: .BYTE	0	: DRIVE WHICH DID WRITE (READ OPERATION)
240	001320	000	HDRFLG: .BYTE	0	: FLAG FOR ONE HEADER PRINTOUT
241	001321	000	ECNT: .BYTE	0	: ERROR COUNTER
242	001322	000	CNTSIN: .BYTE	0	: SEEK INCOM. COUNTER
243	001323	000	TMR2: .BYTE	0	: SECOND PASS TIMER
244	001324	000	IDEX: .BYTE	0	: CURRENT INDEX #
245	001325	000	STFLG: .BYTE	0	
246	001326	000	OSPFLG: .BYTE	0	
247					
248		001330			
249			.EVEN		
250	001330	000000	KYTEMP: .WORD	0	: TEMP. KEYBOARD BUFFER
251	001332	000000	CONTRL: .WORD	0	: TEMP. CONTROL+STATUS WORD
252	001334	000000	DSKADR: .WORD	0	: TEMP. DISK ADDRESS WORD
253	001336	000000	BUSADR: .WORD	0	: TEMP. BUS ADDRESS WORD
254	001340	000000	WRDCNT: .WORD	0	: TEMP. WORD COUNT
255	001342	172000	CYLCNT: .WORD	-6000	: WORD COUNT OF 1 CYLINDER
256	001344	177400	SECCNT: .WORD	-400	: WORD COUNT OF 1 SECTOR
257	001346	000000	TMR: .WORD	0	: TIMER FOR OPERATIONS
258	001350	000000	CHKCNT: .WORD	0	: NUMBER OF ERROR PRINTOUTS
259	001352	000000	DSKTMP: .WORD	0	: SAVE OF CURRENT DISK #
260	001354	004003	WRITCS: .WORD	4003	: IBA+WRITE+GO
261	001356	000000	READCS: .WORD	5	: READ+GO
262	001360	000000	ERRFLG: .WORD	0	: ERROR FLAG INHIBIT ADDRESS CHANGE
263	001362	000000	PATRN: .WORD	0	: DATA PATTERN

265	001366	177402	RKER:	.WORD	177402
266	001370	177404	RKCS:	.WORD	177404
267	001372	177406	RKWC:	.WORD	177406
268	001374	177410	RKBA:	.WORD	177410
269	001376	177412	RKDA:	.WORD	177412
270	001400	000000	SENDAD:	.WORD	0
271	001402	000000	SEEKI:	.WORD	0
272	001404	000000	SEEKO:	.WORD	0
273					
274		105212	LFLF*	105212	
275	001406	013700	BA:	BUFF	
276	001410	000000	DA:	.WORD	0
277	001412	000000	LC:	.WORD	0
278	001414	013702	RBA:	RBUFF	
279	001416	000000	RWC:	.WORD	0
280	001420	000000	EXTR:	.WORD	0
281	001422	000000	ERRWF:	.WORD	0
282	001424	000000	ERRRF:	.WORD	0
283	001426	000000	ERRRFC:	.WORD	0
284	001430	000000	ERRWCH:	.WORD	0
285	001432	000000	ERRWCS:	.WORD	0
286					
287			;BIT DEFINITIONS		
288					
289		010000	DPL=	BIT12	
290		000100	RWS=	BIT6	
291		000040	WPS=	BITS	

293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312

001434

.SBTTL ERROR POINTER TABLE

;\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
;\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
;\*LOCATION SITE#B. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
;\*NOTE: IF SITE#B IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
;\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;\* EM ::POINTS TO THE ERROR MESSAGE  
;\* DH ::POINTS TO THE DATA HEADER  
;\* DT ::POINTS TO THE DATA  
;\* DF ::POINTS TO THE DATA FORMAT

\$ERRTB:  
;\*\*\*\*\*  
;THE ERROR TABLE IS UNUSED IN THIS PROGRAM  
;\*\*\*\*\*

```

314 001434 105037 001312 STARTR: CLRB 2#MODE
315 001440 000005 START: RESET ;CLEAR THE BUS
316 001442 012706 001100 MOV #STACK,SP
317 001446 012746 000000 MOV #0,-(SP) ;SET UP STACK FOR PSW=0
318 001452 012746 001460 MOV #2$,-(SP) ;RETURN FOR RTI
319 001456 000002 RTI
320 001460 000240 2$: NOP
321 .SBTTL INITIALIZE THE COMMON TAGS
322 ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
323 001462 012706 001100 MOV #SCMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
324 001466 005026 001100 CLR (R6)+ ;;CLEAR MEMORY LOCATION
325 001470 022706 001140 CMP #SWR,R6 ;;DONE?
326 001474 001374 001140 BNE -6 ;;LOOP BACK IF NO
327 001476 012706 001100 MOV #STACK,SP ;;SETUP THE STACK POINTER
328 ;;INITIALIZE A FEW VECTORS
329 001502 012737 024230 000034 MOV #TRAP,2#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
330 001510 012737 000340 000036 MOV #340,2#TRAPVEC ;;LEVEL 7
331 001516 012737 024310 000024 MOV #SPWRON,2#PWAVEC ;;POWER FAILURE VECTOR
332 001524 012737 000340 000026 MOV #340,2#PWAVEC+2 ;;LEVEL 7
333 ;;SIZE FOR A HARDWARE SWITCH REGISTER, IF NOT FOUND OR IT IS
334 ;;EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
335 001532 013746 000004 MOV 2#ERRVEC,-(SP) ;;SAVE ERROR VECTOR
336 001536 012737 001572 000004 MOV #64$,2#ERRVEC ;;SET UP ERROR VECTOR
337 001544 012737 177570 001140 MOV #DSWR,SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
338 001552 012737 177570 001142 MOV #0015$,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
339 001560 022777 177777 177352 CMP #-1,2#SWR ;;TRY TO REFERENCE HARDWARE SWR
340 001566 001012 BNE 66$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
341 AND THE HARDWARE SWR IS NOT = -1
342 BR 65$ ;;BRANCH IF NO TIMEOUT
343 001570 000403 BR 65$
344 001572 012716 001600 64$: MOV #65$, (SP) ;;SET UP FOR TRAP RETURN
345 001576 000002 RTI
346 001600 012737 000176 001140 65$: MOV #SWREG,SWR ;;POINT TO SOFTWARE SWR
347 001606 012737 000174 001142 MOV #DISPREG,DISPLAY
348 001614 012637 000004 66$: MOV (SP)+,2#ERRVEC ;;RESTORE ERROR VECTOR
349 001620 004737 022746 JSR PC,$TKINT ;INITIALIZE THE TTY INTERRUPT HANDLER
350 .SBTTL TYPE PROGRAM NAME
351 ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
352 001624 005227 177777 INC #-1 ;;FIRST TIME?
353 001630 001045 BNE 67$ ;;BRANCH IF NO
354 001632 104401 001670 TYPE 68$ ;;TYPE ASCIZ STRING
355 .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
356 001636 005737 000042 TST 2#42 ;;ARE WE RUNNING UNDER XXDP/ACT?
357 001642 001006 BNE 69$ ;;BRANCH IF YES
358 001644 023727 001140 000176 CMP SWR,#SWPEG ;;SOFTWARE SWITCH REG SELECTED?
359 001652 001005 BNE 70$ ;;BRANCH IF NO
360 001654 104405 GTSWR ;;GET SOFT-SWR SETTINGS
361 001656 000403 BR 70$
362 001660 112737 000001 001134 69$: MOVB #1,$AUTOB ;;SET AUTO-MODE INDICATOR
363 001666 70$: BR 67$
364 001666 000426 BR 67$
365 ;;68$: .ASCIZ <CRLF>/RK11 UTILITY PACKAGE/<15><12>/MAINDEC-11-DZRKI-E/<CRLF>
366 001744 67$:
367 001744 105737 001312 TSTR 2#MODE
368 001750 100002 BPL 1$

```

E03

MAINDEC-11-DZRKI-E  
DZRKIF.P11 24-MAR-78

MACY11 30A(1052) 09:20

24-MAR-78 07.23 PAGE 10  
GET VALUE FOR SOFTWARE SWITCH REGISTER

SEQ 0030

```

370 001756 105737 001325 15: TSTB STFLG ;PRINT ONLY THE FIRST TIME
371 001762 001402 8EQ 10$
372 001764 000137 002554 JMP TABLTY
373 001770 105237 001325 10$: INCB STFLG
374 001774 105037 001326 STRT1: CLAB OSPFLG
375 002000 104401 002006 TYPE 65$ ;:TYPE ASCIZ STRING
376 002004 000423 BR 64$ ;:GET OVER THE ASCIZ
377 ;:65$: .ASCIZ <15><12><15><12>/ NAME TYPE /
378 002054 64$: TYPE 67$ ;:TYPE ASCIZ STRING
379 002054 104401 002062 BR 66$ ;:GET OVER THE ASCIZ
380 002060 000421 ;:67$: .ASCIZ <15><12>/INDEX 0/
381 66$: TYPE 69$ ;:TYPE ASCIZ STRING
382 002124 68$: BR 68$ ;:GET OVER THE ASCIZ
383 002124 104401 002132 ;:69$: .ASCIZ <15><12>/COMPATIBILITY PACKAGE 1/
384 002130 000421 68$: TYPE 71$ ;:TYPE ASCIZ STRING
385 002174 70$: BR 70$ ;:GET OVER THE ASCIZ
386 002174 104401 002202 ;:71$: .ASCIZ <15><12>/OSCILLATING SEEK PACKAGE 2/
387 002200 000421 70$: TYPE 73$ ;:TYPE ASCIZ STRING
388 002244 72$: BR 72$ ;:GET OVER THE ASCIZ
389 002244 104401 002252 ;:73$: .ASCIZ <15><12>/FORMATTER-SURFACE VERIFIER 3/
390 002250 000421 72$: TYPE 75$ ;:TYPE ASCIZ STRING
391 002314 74$: BR 74$ ;:GET OVER THE ASCIZ
392 002314 104401 002322 ;:75$: .ASCIZ <15><12>/RK05 CONTROL PANEL TEST 4/
393 002320 000421 74$: TYPE 77$ ;:TYPE ASCIZ STRING
394 002364 76$: BR 76$ ;:GET OVER THE ASCIZ
395 002364 104401 002372 ;:77$: .ASCIZ <15><12>/RK05 CONTROL PANEL TEST #2 5/
396 002370 000421 76$: TYPE 79$ ;:TYPE ASCIZ STRING
397 002434 78$: BR 78$ ;:GET OVER THE ASCIZ
398 002434 104401 002442 ;:79$: .ASCIZ <15><12>/HEAD ALIGNMENT ROUTINE 6/
399 002440 000421 78$: TYPE 81$ ;:TYPE ASCIZ STRING
400 002504 80$: BR 80$ ;:GET OVER THE ASCIZ
401 002504 104401 002512 ;:81$: .ASCIZ <15><12>/POWER FAILURE (WRITE) TEST 7/
402 002510 000421 80$: ;:81$:
403 002554 80$: TABLTY: TYPE 65$ ;:TYPE ASCIZ STRING
404 002554 104401 002562 BR 64$ ;:GET OVER THE ASCIZ
405 002560 000405 ;:65$: .ASCIZ <15><12><15><12>/TYPE=/
406 002574 64$: RDOCT ;GET THE TEST NUMBER FROM THE OPERATOR
407 002574 104411 MOV (SP)+,R0 ;STORE IT IN R0
408 002576 012600 CMP #10,R0 ;VALID NUMBER ?
409 002600 022700 000010 BLE NG ;BR IF NOT
410 002604 003403 ROL R0 ;ALIGN THE NUMBER FOR DISPATCHING
411 002606 006100 JMP @BEGIN(F') ;GO TO THE SELECTED TEST
412 002610 000170 002622 NG: TYPE $QUES ;'?'
413 002614 104401 001160 BR TABLTY
414 002620 000755
424

```

```

426
427 002622 001774          BEGIN:  STRT1
428 002624 002642          SECT.3
429 002626 010370          SECT.2
430 002630 012002          SECT.1
431 002632 013772          SECT.0
432 002634 017300          SECT.4
433 002636 020634          SECT.5
434 002640 021544          SECT.6
435
436
437
438
439
440
441
442 002642 000240          SECT.3: NOP                ;NO-OP
443 002644
444 002644 104401 002652    AUTSL2:
445 002650 000415          TYPE      65$              ;:TYPE ASCIZ STRING
                                BR      64$              ;:GET OVER THE ASCIZ
446
447 002704
448 002704 104401 002712    ;:65$: .ASCIZ <15><12>/TERMINATE WITH '<CR>'/
449 002710 000417          ;:64$:
                                TYPE      67$              ;:TYPE ASCIZ STRING
                                BR      66$              ;:GET OVER THE ASCIZ
450
451 002750
452 002750 104410          ;:67$: .ASCIZ <15><12>/DRIVE NUMBERS ON SYSTEM 1=/
453 002752 012600          ;:66$:
                                RDLIN
                                MOV      (SP)+,R0          ;:PICK UP THE ADDRESS OF THE INPUT BUFFER
                                MOV      #LOGA,R1          ;:GET THE ADDRESS OF THE LOGICAL UNIT TBL.
454 002754 012701 001166    CLR      #DRCNT1          ;:CLEAR THE DRIVE COUNTER
455 002760 105037 001311    1$: CLR      #KYTEMP          ;:CLEAR TEMP
456 002764 005037 001330    MOV      (R0)+,#KYTEMP    ;:GET THE FIRST DRIVE #
457 002770 112037 001330    CMP      #54,#KYTEMP      ;:IS IT A COMMA THAT WAS TYPED?
458 002774 122737 000054 001330 BEQ      1$                ;:IF YES GO BACK
459 003002 001770          SUB      #60,#KYTEMP      ;:MAKE ASCII A DRIVE #
460 003004 162737 000060 001330 BMI      2$                ;:IF RESULT NEGATIVE BRANCH
461 003012 100403          JSR      PC,STORE         ;:IF RESULT POSITIVE JUMP
462 003014 004737 004072    BR      1$                ;:AFTER STORING GET NEXT #
463 003020 000761          CMP      #56,-(R0)        ;:WAS NEGATIVE RESULT A TERMINATOR?
464 003022 122740 000056    2$: BEQ      3$            ;:IF YES BRANCH
465 003026 001402          JSR      PC,ILEGAL        ;:IF NO BAD CHARACTER JUMP
466 003030 004737 004142    3$: CMP      #DAVD,R1       ;:IS THE TABLE FULL
467 003034 022701 001206    BEQ      SECSYS           ;:IF YES BRANCH
468 003040 001403          MOV      #10000,(R1)+     ;:IF NO FILL TABLE WITH DOWN INDICATOR.
469 003042 012721 100000    BR      3$                ;:GO BACK AND CHECK
470 003046 000772
471
472
473
474
475
476 003050
477 003050 104401 003056    ;:ROUTINE TO DETERMINE IF THERE IS A SECOND
478 003054 000416          ;:SYSTEM AND IF SO TO GET THE NUMBER OF THE
479
480 003112          ;:DRIVE ON THIS SYSTEM
                                SECSYS:
                                TYPE      65$              ;:TYPE ASCIZ STRING
                                BR      64$              ;:GET OVER THE ASCIZ
                                ;:65$: .ASCIZ <15><12>/IS THERE A SECOND SYSTEM?/
                                ;:64$:
    
```

```

482 003114 104407          RDCHR          : READ A CHARACTER
483 003116 012637 001330  MOV      (SP)+,2#KYTEMP : GET THE RESPONSE
484 003122 104401 001330  TYPE      KYTEMP        : ECHO
485 003126 022737 000131 001330  CMP      #131,2#KYTEMP   : WAS IT A "Y" (FOR YES)?
486 003134 001411          BEQ      PRO2           : IF YES BRANCH TO PROCESSOR 2
487 003136 022737 000116 001330  CMP      #116,2#KYTEMP   : WAS RESPONSE LEGAL (N FOR NO)?
488 003144 001460          BEQ      PRO1           : IF LEGAL BRANCH
489 003146 104401 003154  TYPE      67$          : TYPE ASCIZ STRING
490 003152 000401          BR       66$          : GET OVER THE ASCIZ
491          ;:67$: .ASCIZ  /?/
492          66$:
493 003156          BR       SECSYS        : GO BACK ASK AGAIN
494 003160 152737 000377 001313  PRO2:  BISB      #377,2#PRONUM : SET FLAG TWO PROCESSORS
495 003166 000240          NOP
496 003170 104401 003176  TYPE      65$          : TYPE ASCIZ STRING
497 003174 000406          BR       64$          : GET OVER THE ASCIZ
498          ;:65$: .ASCIZ <15><12>/DRIVE # =/
499          64$:
500 003212 104407          RDCHR          : READ A CHARACTER
501 003214 012637 001330  MOV      (SP)+,2#KYTEMP : PICK UP THE RESPONSE
502 003220 104401 001330  TYPE      KYTEMP        : ECHO
503 003224 162737 000060 001330  SUB      660,2#KYTEMP    : MAKE IT A NUMBER
504 003232 100420          BMI     BADINP        : IF NOT A NUMBER, BRANCH
505 003234 022737 000010 001330  CMP      #10,2#KYTEMP   : IS IT A LEGAL #?
506 003242 003414          BLE     BADINP        : IF NO BRANCH
507 003244 000337 001330  SWAB     2#KYTEMP       : GET THE DRIVE # TO THE HIGH BYTE
508 003250 052737 040000 001330  BIS      #BIT14,2#KYTEMP : SET THE SECOND SYSTEM BIT
509 003256 113705 001311  MOV      2#DRCNT1,RS    : GET THE DRIVE COUNT
510 003262 006105          ROL     RS             : MAKE IT AN INDEX
511 003264 017765 001330 001166  MOV      2#KYTEMP,LOGR(RS) : STORE THE SYSTEM #2 WORD
512 003272 000407          BR       GO           : GO DO THE TEST
513 003274          BADINP:
514 003274 104401 003302  TYPE      65$          : TYPE ASCIZ STRING
515 003300 000401          BR       64$          : GET OVER THE ASCIZ
516          ;:65$: .ASCIZ  /?/
517          64$:
518 003304          BR       PRO2        : GO BACK ASK AGAIN
519 003306 105037 001313  PRO1:  CLRB     2#PRONUM    : CLEAR THE FLAG ONE PROCESSOR
520
521          ; THIS IS THE ACTUAL PROGRAM
522
523 003312 012700 001166  GO:     MOV      #LOGA,RO  : GET THE TABLE ADDRESS TO RO
524 003316 105037 001324  CLRB     2#INDEX        : CLRB THE INDEX
525 003322 000405          BR       GO2          : BRANCH AROUND INCREMENT ROUTINE
526
527 003324 062700 000002  GO1:   ADD      #2,RO       : INDEX THRU THE TABLE
528 003330 022700 001206  CMP      #DRVD,RO       : DONE?
529 003334 001414          BEQ     EXIT          : IF YES GET OUT
530 003336 005710  GO2:   TST      (RO)       : IS THE DRIVE ACTIVE
531 003340 100001          BPL     GO3           : IF YES BRANCH
532 003342 000770          BR     GO1           : NO TRY THE NEXT ONE
533 003344 011037 001164  GO3:   MOV      (RO),2#DRACTV : PICK UP THE ACTIVE DRIVE WORD
534 003350 004737 004174  JSR     PC,CYCLE        : CALL CYCLE (PICK UP DRIVE #, CYL BASE, AND CALL MOUNT)
535 003354 004737 005104  JSR     PC,WRLINK       : CALL WRITE LINK TO LOAD REGISTERS FOR WRITE
536 003360 004737 005632  JSR     PC,ROLINK       : CALL READ LINK TO LOAD REGISTERS FOR READ

```

538 003366 012700 001166  
539 003372 022700 001206  
540 003376 001414  
541 003400 032710 040000  
542 003404 001011  
543 003406 005720  
544 003410 100770  
545 003412 014001  
546 003414 004737 004250  
547 003420 004737 005632  
548 003424 005720  
549 003426 000761  
550 003430  
551 003430 104401 003436  
552 003434 000404  
553  
554 003446  
555 003446 000137 001440  
556  
557  
558  
559  
560 003452  
561 003452 104401 003460  
562 003456 000415  
563  
564 003512  
565 003512 012704 000200  
566 003516 012703 000001  
567 003522 012702 001166  
568 003526  
569 003526 104401 003534  
570 003532 000405  
571  
572 003546  
573 003546 000240  
574 003550 010346  
575 003552 104403  
576 003554 006  
577 003555 000  
578 003556 104401 003564  
579 003562 000401  
580  
581 003566  
582 003566 104411  
583 003570 012600  
584 003572 110001  
585 003574 000300  
586 003576 042700 177400  
587 003602 042701 177400  
588 003606 006000  
589 003610 103003  
590 003612 052700 000200  
591 003616 000241  
592 003620 006001

```

EXIT:  MOV    #LOGA,R0
EXTFR2: CMP    #DRVD,R0
        BEQ    EXITX
        BIT    #BIT14,(R0)
        BNE    EXITX
        TST   (R0)+
        BMI   EXTFR2
        MOV   -(R0),R1
        JSR   PC,DO2
        JSR   PC,RDLINK
        TST   (R0)+
        BR    EXTFR2

EXITX:  TYPE   65$           ;;TYPE ASCIZ STRING
        BR    64$           ;;GET OVER THE ASCIZ
;;65$:  .ASCIZ <15><12>/DONE!/
64$:   JMP    @#START       ;RESTART

;THIS IS PROCESSOR #2 CODE. THIS ROUTINE ASKS FOR AND UNPACKS THE CONTROL
;WORDS FROM THE FIRST PROCESSOR.

SECOND. TYPE   65$           ;;TYPE ASCIZ STRING
        BR    64$           ;;GET OVER THE ASCIZ
;;65$:  .ASCIZ <15><12>/COMPATIBILITY-SYSTEM#2/
64$:   MOV    #200,R4       ;SET UP MASK BIT IN R4
        MOV   #1,R3        ;SET UP WORD COUNTER IN R3
        MOV   #LOGA,R2     ;GET THE TABLE ADDRESS

INSYS2: TYPE   65$           ;;TYPE ASCIZ STRING
        BR    64$           ;;GET OVER THE ASCIZ
;;65$:  .ASCIZ <15><12>/WORD /
64$:   NOP
        MOV   R3,-(SP)     ;LET READY TO TYPE WORD COUNTER
        TYPOS
        .BYTE 6
        .BYTE 0
        TYPE  67$           ;;TYPE ASCIZ STRING
        BR    66$           ;;GET OVER THE ASCIZ
;;67$:  .ASCIZ /=/
66$:   RDOCT
        MOV   (SP)+,R0     ;PICK UP THE OCTAL WORD
        MOVB R0,R1        ;GET THE FIRST DRIVE TO R1
        SWAB R0           ;GET THE SECOND DRIVE TO R0 LOW BYTE
        BIC   #177400,R0  ;CLEAR THE UNUSED BITS
        BIC   #177400,R1  ;CLEAR THE UNUSED BITS
        ROR   R0          ;ROTATE RIGHT R0
        BCC   2$         ;IF CARRY IS CLEAR BRANCH
        BIS   #BIT7,R0    ;SET DOWN BIT IF CARRY SET
        CLC
        ROR   R1          ;AND CLEAR THE CARRY BIT
        ;NOW DO THE SAME FOR R1
2$:

```

```

594 003624 052701 000200          BIS      #BIT7,R1      ; IF ERROR SET THE BIT
595 003630 110162 000001 3$:      MOVVB   R1,1(R2)      ; SET DRIVE FIRST IN TABLE
596 003634 004737 004030          JSR     PC,MASKER    ; CALL THE MASK CONTROL SUBROUTINE
597 003640 110062 000001          MOVVB   R0,1(R2)      ; SET DRIVE SECOND IN TABLE (NEXT WORD)
598 003644 004737 004030          JSR     PC,MASKER    ; CALL THE MASK CONTROL SUBROUTINE
599 003650 005203          INC     R3           ; INCREMENT THE WORD COUNTER
600 003652 000725          BR     INSYS2       ; GO BACK AND GET NEXT WORD
601 003654 050412          EXITA:  BIS      R4,(R2) ; FILL THE TABLE (LAST WORD)
602 003656 006004          ROR     R4           ; WITH ALL BITS SET
603 003660 103375          BCC     EXITA       ; GO BACK IF NOT DONE
604 003662 042712 174000          EXITB:  BIC     #174000,(R2) ; CLEAR DOWN AND SECOND SYSTEM BITS AT TABLE
605 003666 010200          MOV     R2,R0       ; GET ADDRESS TO R0 (CURRENT TABLE)
606 003670 005722          TST     (R2)+       ; ADD 2 TO THE POINTER
607 003672 022702 001206          FIL.DN: CMP     #DRVD,R2 ; TABLE FULL?
608 003676 001403          BEQ     2$         ; IF YES BRANCH
609 003700 012722 100000          MOV     #BIT15,(R2)+ ; FILL THE TABLE
610 003704 000772          BR     FIL.DN      ; GO BACK TRY AGAIN
611 003706 011001          2$:      MOV     (R0),R1 ; GET THE WORD TO R1
612 003710 110102          MOVVB   R1,R2
613 003712 004737 005234          JSR     PC,MASK     ; FORM DRIVE # FOR MOUNT
614 003716 004737 004250          JSR     PC,DO2     ; WRITE NEW INFO
615 003722 004737 005104          JSR     PC,WRLINK  ; READ SAMPLE (ALL DRIVES)
616 003726 004737 005632          JSR     PC,RDLINK  ; TYPE ASCIZ STRING
617 003732 104401 003740          TYPE   65$        ; GET OVER THE ASCIZ
618 003736 000427          BR     64$        ;
619          ;:65$: .ASCIZ <15><12>/DONE SYSTEM 2 RESTART SYSTEM 1, TYPE WORD /
620          64$:
621 004016 011046          MOV     (R0),-(SP) ; GET WORD FOR SYSTEM 1 AND TYPE
622 004020 104403          TYPOS
623 004022 006          .BYTE 6
624 004023 001          .BYTE 1
625 004024 000000          1$:      HALT      ; HALT (FINISHED SYSTEM #2)
626 004026 000776          BR     1$         ; GO BACK TO HALT
627
628          ; THIS ROUTINE SETS UP THE MASK BITS IN THE LOG TABLE FOR
629          ; SYSTEM #2. IF A DRIVE IS DOWN NO BIT IS SET BUT THE MASK
630          ; IS SHIFTED.
631
632 004030 005712          MASKER: TST     (R2)      ; IS THE DRIVE UP
633 004032 100401          BMT     RETRN4     ; IF NO, BRANCH
634 004034 110412          MOVVB   R4,(R2)    ; MOVE THE MASK BIT IN THE TABLE
635 004036 006004          RETRN4: ROR     R4     ; ROTATE THE MASK
636 004040 103003          BCC     1$         ; DONE? IF NO BRANCH
637 004042 012716 003662          MOV     #EXITB,(SP) ; SET UP FOR RETURN
638 004046 000207          RTS     PC
639 004050 032712 040000          1$:      BIT     #BIT14,(R2) ; IS THIS SYSTEM # 2'S DRIVE?
640 004054 001403          BEQ     2$         ; IF NO BRANCH
641 004056 012716 003654          MOV     #EXITA,(SP) ; SET UP FOR RETURN
642 004062 000207          RTS     PC
643 004064 062702 000002          2$:      ADD     #2,R2     ; INDEX THRU LOGA TABLE
644 004070 000207          RTS     PC         ; RETURN
645
646          ; ROUTINE TO BUILD THE ACTIVE LOGICAL UNIT TABLE
647
648 004072 022737 000010 00133U          STORE: CMP     #10,#KYTEMP ; IS INPUT A LEGAL NUMBER?
    
```

```

650 004102 003417          BLE      ILEGAL          ; IF NOT BRANCH
651 004104 000337 001330 SWAB     @#KYTEMP        ; ALIGN DRIVE # FOR TABLE
652 004110 013721 001330 MOV      @#KYTEMP,(R1)+ ; PUT THE WORD IN THE TABLE
653 004114 005037 001330 CLR      @#KYTFMP        ; CLEAR THE TEMP WORD
654 004120 105237 001311 INCB    @#DRCNT1        ; INCREMENT THE COUNTER
655 004124 022701 001206 CMP      @#DRVD,R1       ; IS THE TABLE FULL?
656 004130 001401          BEQ      TBLFJL          ; IF YES BRANCH
657 004132 000207          RTS      PC              ; IF NO RETURN
658 004134 012716 003050 TBLFUL: MOV    @#SECSYS,(SP) ; IF TABLE FULL SET UP FOR SYSTEM #2
659 004140 000207          RTS      PC              ; RETURN
660 004142 012716 002644 ILEGAL: MOV    @#AUTSL2,(SP) ; IF ILLEGAL RESPONSE, GO BACK
661 004146 104401 004154 TYPE     65$            ; TYPE ASCIZ STRING
662 004152 000407          BR       64$            ; GET OVER THE ASCIZ
663                                     ; 65$: .ASCIZ /ILLEGAL INPUT/
664 004172                                     64$:
665 004172 000207          RTS      PC              ; RETURN
666
667                                     ; THIS ROUTINE GETS A DRIVE # AND BUILDS A TABLE OF
668                                     ; CYLINDER ADDRESS FOR USE BY WRITE, (R0)=ADDRESS OF ACTIVE
669                                     ; WORD IN LOGICAL TABLE, IT ALSO SETS AND CLEARS THE MASK BITS
670                                     ; OF THE TABLE AS OPERATIONS INDICATE
671
672 004174 011001          CYCLE: MOV    (R0),R1      ; GET THE LOGICAL UNIT ACTIVE WORD TO R1
673 004176 032701 040000 BIT      @BIT14,R1      ; IS IT ON SYSTEM #2
674 004202 001402          BEQ      CYCL2          ; IF NO BRANCH
675 004204 000137 006752 JMP      @#SECONE       ; GO TO SYSTEM #2
676 004210 113703 001324 CYCL2: MOV    @#INDEX,R3 ; GET THE INDEX VALUE
677 004214 116302 001256 MOV    MSKTBL(R3),R2    ; GET THE MASK TO R2
678 004220 004737 005234 CYCLE2: JSR   PC,MASK    ; CALL THE MASK SUBROUTINE
679 004224 012703 001166 LDFLG: MOV   @#LOGA,R3  ; GET TABLE ADDRESS TO R3
680 004230 020003          2$: CMP     R0,R3         ; IS ACTIVE ADDRESS=TO FIRST ADDRESS
681 004232 001302          BNE     3$            ; IF NO BRANCH
682 004234 050223          CTS     R2,(R3)+      ; IF YES SET BITS TO SHOW WRITE
683 004236 000401          BR      4$            ; BRANCH TO SEE IF DONE
684 004240 040223          3$: BIC     R2,(R3)+      ; CLEAR BITS TO SHOW OVER-WRITE
685 004242 022703 001206 4$: CMP     @#DRVD,R3    ; DONE
686 004246 001370          BNE     2$            ; IF NO GO BACK
687 004250 000301          D02: SWAB   R1         ; GET DRIVE # TO LOW BYTE
688 004252 000240          NOP
689 004254 110102          MOV    R1,R2          ; GET IT TO R2
690 004256 042702 000370 BIC     @370,R2        ; CLEAR THE UNUSED BITS
691 004262 110237 001314 MOV    R2,@#DRIVE     ; GET THE DRIVE #
692 004266 006102          ROL    R2             ; SHIFT THE DRIVE # TO
693 004270 006102          ROL    R2             ; ALIGN IT FOR THE DRIVE ADDR.
694 004272 006102          ROL    R2             ; KEEP IT MOVING!
695 004274 006102          ROL    R2             ; A LITTLE MORE!
696 004276 006102          ROL    R2             ; THERE IT IS
697 004300 110237 001353 MOV    R2,@#DSKTMP+1  ; GET IT TO DISK ADDR. TEMP.
698 004304 110237 001335 MOV    R2,@#DSKADR+1  ; CALL MOUNT
699 004310 004737 004316 JSR    PC,MOUNT
700 004314 000207          RTS      PC              ; RETURN
701
702 004316 105237 001324 MOUNT: INCB   @#INDEX    ; INCREMENT THE INDEX
703 004322 000240          NOP
704 004324 112737 000005 001321 MOV    @5,@#ECNT      ; SET ERROR CNTR TO 5
    
```

```

706 004340 104401 004346      TYPE      65$      ;; TYPE ASCIZ STRING
707 004344 000414              BR      64$      ;; GET OVER THE ASCIZ
708                               ;;65$: .ASCIZ <15><12>/MOUNT PACK ON DRIVE #/
709 004376 013746 001314      64$: MOV      DRIVE,-(SP)      ;; SAVE DRIVE FOR TYPEOUT
710 004376 104403 001314      TYPOS      ;; GO TYPE--OCTAL ASCII
711 004402 001314 001314      .BYTE      1      ;; TYPE 1 DIGIT(S)
712 004404 001314 001314      .BYTE      0      ;; SUPPRESS LEADING ZEROS
713 004405 000414 004414      TYPE      67$      ;; TYPE ASCIZ STRING
714 004406 104401 004414      BR      66$      ;; GET OVER THE ASCIZ
715 004412 000415              ;;67$: .ASCIZ <15><12>/MAKE PACK WRITE ENABLE/
716                               66$: TYPE      69$      ;; TYPE ASCIZ STRING
717 004446 104401 004454      BR      68$      ;; GET OVER THE ASCIZ
718 004446 000420              ;;69$: .ASCIZ <15><12>/PRESS CONTINUE WHEN DRIVE RDY/
719 004452 000420              68$: HALT
720                               JSR      PC,INITIL      ;; CALL INITIALIZER
721 004514 000000              RTS      PC      ;; RETURN
722 004514 000000
723 004516 004737 004524
724 004522 000207
725
726                               ; THIS ROUTINE INITIALIZES A DRIVE AND INSURES THAT IT IS READY AND
727                               ; WRITE ENABLED, IT IS ENTERED FROM MOUNT OR FROM EXECUTE IF OPERATION FAILS
728
729 004524 010046 001334      INITIL: MOV      RO,-(SP)      ;; SAVE RO
730 004526 013700 001334      MOV      2#OSKADR,RO      ;; GET THE DRIVE # TO RO
731 004532 042700 001777      BIC      #1777,RO      ;; CLEAR THE UNUSED BITS
732 004536 005037 001346      INITI2: CLR      2#TIMR      ;; CLEAR THE TIMER
733 004542 105037 001323      CLR      2#TIMR2
734 004546 000240              NOP
735 004550 010077 174622      MOV      RO,2#RKDA      ;; GET DRIVE # TO 'DA' REGISTER
736 004554 012777 000001 174606      MOV      #1,2#RKCS      ;; ISSUE CONTROL RESET + GO
737 004562 004737 005614      JSR      PC,SMTME
738 004566 105777 174576      1$: TSTB      2#RKCS      ;; DID CONTROL READY SET
739 004572 100423              BMI      2$      ;; IF YES BRANCH
740 004574 005237 001346      INC      2#TIMR      ;; IF NO INCREMENT THE TIMER
741 004600 001372              BNE      1$      ;; IF TIMER NOT ZERO BRANCH
742 004602 104401 004610      TYPE      65$      ;; TYPE ASCIZ STRING
743 004606 000415              BR      64$      ;; GET OVER THE ASCIZ
744                               ;;65$: .ASCIZ <15><12>/CONTROL RESET TIME OUT/
745                               64$:
746 004642 010077 174530      2$: MOV      RO,2#RKDA      ;; DRIVE NUMBER TO 'DA' REG.
747 004646 105777 174512      TSTB      2#RKDS      ;; IS DRIVE READY
748 004652 100415              BMI      3$      ;; IF YES BRANCH
749 004654 104401 004662      TYPE      67$      ;; TYPE ASCIZ STRING
750 004660 000411              BR      66$      ;; GET OVER THE ASCIZ
751                               ;;67$: .ASCIZ <15><12>/DRIVE NOT READY/
752                               66$:
753 004704 000714              BR      INITI2      ;; GO BACK TRY AGAIN
754 004706 032777 000040 174450      3$: BIT      #BITS,2#RKDS      ;; IS DRIVE WRITE LOCKED?
755 004714 001420              BEQ      4$      ;; IF NO, BRANCH
756 004716 104401 004724      TYPE      69$      ;; TYPE ASCIZ STRING
757 004722 000414              BR      68$      ;; GET OVER THE ASCIZ
758                               ;;69$: .ASCIZ <15><12>/DRIVE WRITE PROTECTED/
759                               68$:
760 004754 000670              BR      INITI2      ;; YES, GO BACK TRY AGAIN

```

```

762 004762 010077 174410          MOV    RD,DRKDA      ;GET THE DRIVE # TO 'DA' REGISTER
763 004766 012777 000015 174374  MOV    #15,DRKCS    ;ISSUE DRIVE RESET + GO
764 004774 004737 005614          JSR    PC,SMTME
765 005000 105777 174364          5$:   TSTB   DRKCS
766 005004 100375          BPL    5$
767 005006 032777 000100 174350  BIT    #100,DRKDS    ;READ/WRITE/SEEK READY BIT SET?
768 005014 001031          BNE    6$           ;IF YES, BRANCH
769 005016 005237 001346          INC    @TIMR        ;NO, INCREMENT THE TIMER
770 005022 001356          BNE    5$           ;GO BACK AND CHECK IF TIMER NOT 0
771 005024 105737 001323          TSTB   @TIMR2
772 005030 001003          BNE    7$
773 005032 105237 001323          INCB   @TIMR2
774 005036 000760          BR     5$
775 005040          7$:
776 005040 104401 005046          TYPE   71$         ;;TYPE ASCIZ STRING
777 005044 000414          BR     70$         ;;GET OVER THE ASCIZ
778          71$: .ASCIZ <15><12>/DRIVE RESET TIMED OUT/
779 005076          70$:
780 005076 000727          BR     4$         ;GO BACK, TRY AGAIN
781 005100 012600          6$:   MOV    (SP)+,RO    ;RESTORE RO
782 005102 000207          RTS    PC          ;RETURN TO CALLER
783
784          ;THIS ROUTINE TAKES CARE OF ALL LINKAGES FOR THE
785          ;EXECUTE ROUTINE. IT FORMS THE ADDRESS AND SETS UP ALL THE
786          ;REGISTERS FOR THE WRITE OPERATION
787
788 005104 105037 001316  WRLINK: CLRB   @COMND    ;INDICATE WRITE OPERATION
789 005110 000240          NOP
790 005112 113701 001314          MOVB   @DRIVE,R1    ;PICK UP THE DRIVE #
791 005116 006101          ROL    R1           ;MAKE IT A WORD INDEX
792 005120 016137 001206 001362  1$:   MOV    DRVD(R1),@PATRN ;PICK UP THE DATA PATTERN
793 005126 004737 005302          JSR    PC,CYLADR    ;CALL CYLINDER ADDRESS
794 005132 000401          BR     2$           ;RETURN HERE IF NOT LAST BASE
795 005134 000207          RTS    PC          ;RETURN HERE IF LAST BASE
796 005136 012737 001362 001336  2$:   MOV    @PATRN,@BUSADR ;SET THE ADDRESS OF THE OUTPUT
797 005144 013737 001342 001340          MOV    @CYLCNT,@WRDCNT ;GET THE WORD COUNT
798 005152 013737 001354 001332          MOV    @WRITCS,@CONTRL ;GET THE CONTROL + STATUS WORD
799 005160 004737 005402          JSR    PC,EXECUT    ;CALL EXECUTE
800 005164 032737 000020 001334          BIT    #BIT4,@DSKADR ;WAS THIS WRITE SURFACE "1"?
801 005172 001006          BNE    3$           ;IF YES BRANCH
802 005174 052737 000020 001334          BIS    #BIT4,@DSKADR ;SET SURFACE ONE BIT
803 005202 105137 001362          COMB   @PATRN      ;MAKE IT SURFACE ONE DATA
804 005206 000753          BR     2$           ;RELOAD REGISTERS AND EXECUTE
805 005210 042737 000020 001334  3$:   BIC    #BIT4,@DSKADR ;SET UP FOR SURFACE "0"
806 005216 105137 001362          COMB   @PATRN      ;MAKE IT SURFACE 0 DATA
807 005222 005202          INC    R2           ;INC. THRU SELECTED CYL. OFFSET TABLE
808 005224 004737 005312          JSR    PC,CYLOFF    ;GET THE CYLINDER VALUE
809 005230 000742          BR     2$           ;RETURN HERE IF MORE TO READ
810 005232 000207          RTS    PC          ;RETURN HERE IF FINISHED
811
812          ;THIS ROUTINE EXPECTS TO FIND A MASK IN R2, AND FROM THIS MASK
813          ;BUILDS A TABLE (AT CYLTBL) OF CYLINDER ADDRESS OFFSETS; THE TABLE
814          ;IS TERMINATED BY A #377
815
816 005234 010546  MASK:  MOV    R5,-(SP)    ;SAVE R5

```

```

818 005242 000240      NOP
819 005244 012703 000200  MOV    #200,R3      ;SET UP THE COMPARE MASK
820 005250 005004      CLR    R4           ;CLR THE INDEX COUNTER
821 005252 012705 001274  MOV    #CYLTBL,R5   ;GET THE CYLINDER TABLE ADDRESS
822 005254 030203      1$: BIT   R2,R3      ;IS THE MASK BIT SELECTED IN BASE
823 005256 001401      BEQ   2$,           ;IF NO BRANCH
824 005262 110425      MOVB  R4,(R5)+      ;MOVE THE CYLINDER BASE TO THE TABLE
825 005264 105204      2$: INCB R4         ;INCREMENT THE BASE
826 005266 006003      ROR   R3           ;ROTATE THE COMPARE MASK
827 005270 103372      BCC   1$,          ;IF NOT DONE GO BACK
828 005272 112715 000377  MOVB  #377,(R5)     ;IF DONE LOOP FINISH FLAG
829 005276 012605      MOV   (SP)+,R5     ;RESTORE R5
830 005300 000207      RTS    PC          ;RETURN TO CALLER
831
832 ;THIS ROUTINE FORMS A CYLINDER ADDRESS FOR BOTH THE READ AND WRITE ROUTINES
833 ;WHEN THE BASE TABLE IS FULLY INDEXED IT RETURNS TO PC+2 OF CALLER
834
835 005302 012703 001266  CYLADR: MOV    #BASE,R3      ;GET THE CYLINDER TABLE ADDRESS
836 005306 012702 001274  CYLADR2: MOV   #CYLTBL,R2   ;GET THE SELECTED CYL BASE ADDR.
837 005312 111204      CYLOFF: MOVB  (R2),R4      ;GET THE SELECTED CYL VALUE TO R4
838 005314 030240      NOP
839 005316 122704 000377  CMPB  #377,R4       ;IS IT THE TABLE TERMINATOR?
840 005322 001416      BEQ   BASINC        ;IF YES BRANCH
841 005324 005046      CLR   -(SP)         ;INSURE CLEAN WORD
842 005326 111316      MOVB  (R3),(SP)     ;GET THE CYL ADDRESS ON THE STACK
843 005330 062604      ADD   (SP)+,R4     ;AND IT TO THE SELECTED OFFSET
844 005332 006104      ROL   R4           ;SHIFT THIS RESULT
845 005334 006104      ROL   R4           ;TO ALIGN THE NEWLY FORMED
846 005336 006104      ROL   R4           ;CYLINDER ADDRESS WITH BITS
847 005340 006104      ROL   R4           ;5 THRU 12 OF R4 AND
848 005342 006104      ROL   R4           ;STORE THIS IN DSKADR
849 005344 042737 017777 001334  BIC   #017777,D#DSKADR ;CLEAR ALL BUT DRIVE NUMBER
850 005352 050437 001334  BIS   R4,D#DSKADR   ;PUT IT IN DSKADR
851 005356 000207      RTS    PC
852 005360 005203      BASINC: INC   R3     ;PICK UP ADDRESS OF NEXT BASE CYL.
853 005362 000240      NOP
854 005364 022703 001274  CMP   #CYLTBL,R3   ;ARE YOU FINISHED?
855 005370 001401      BEQ   RETRN3       ;IF YES BRANCH
856 005372 000745      BR    CYLADR2      ;NO GO BACK
857 005374 062716 000002  RETRN3: ADD   #2,(SP)  ;SET-UP FOR PC+2
858 005400 000207      RTS    PC          ;RETURN
859
860 ;ROUTINE TO PERFORM INDICATED FUNCTION AND CHECK FOR
861 ;DONE AND ERRORS
862
863 005402 005037 001346  EXECUT: CLR   D#TIME    ;CLEAR THE TIMER
864 005406 000240      NOP
865 005410 105037 001323  CLRB  D#TIMER2      ;HALT HERE TO CHECK COMMAND ABOUT TO BE EXECUTED
866 005414 013777 001334 173754  MOV   D#DSKADR,D#RKDA ;CLEAR SECOND TIME
867 005422 013777 001336 173744  MOV   D#BUSADR,D#RKBA ;LOAD THE DISK ADDRESS REGISTER
868 005430 013777 001340 173734  MOV   D#WORDCNT,D#RKWC ;LOAD THE BUS ADDRESS REGISTER
869 005436 013777 001332 173724  MOV   D#CONTRL,D#RKCS ;LOAD THE WORD COUNT REGISTER
870 005444 004737 005614      JSR   PC,SMTIME     ;LOAD THE CONTROL REGISTER
871 005450 105777 173714  CHECK1: TSTB D#RKCS   ;KILL TIME FOR RK11-C
872 005454 100011      BPL   TIME         ;IS CONTROL READY SET
                        ;IF NO BRANCH

```

```

874 005462 005737 001360      TST      J#ERRFLG      ;ERROR?
875 005463 001403      BEQ      IS           ;IF NO BRANCH
876 005470 005037 001360      CLR      J#ERRFLG     ;CLEAR THE FLAG
877 005474 000742      BR       EXECUT       ;TRY AGAIN
878 005476 000207      IS:     RTS          PC
879 005510 005237 001346      TIME:   INC          J#TIMR
880 005501 000240      NOP                               ;***
881 005506 001360      BNE     CHECK1       ;SECOND TIMEOUT?
882 005510 105737 001323      TSTB    J#TIMR2      ;IF YES BRANCH
883 005514 C71003      BNE     IS           ;INDICATE SECOND TIMEOUT
884 005516 105237 001323      INCB    J#TIMR2      ;GO BACK
885 005522 000752      BR      CHECK1
886 005524 004737 004524      IS:     JSR          PC,INITIL
887 005530 104401 005536      TYPE   655          ;:TYPE ASCIZ STRING
888 005534 000426      BR      645          ;:GET OVER THE ASCIZ
889      ;:655: .ASCIZ <15><12>/TIMED OUT ON OPERATION RETRY IN PROGRESS/
890      ;:645:
891 005612 000673      BR      EXECUT
892 005614 012737 000500 001346      SMTME: MOV          #500,J#TIMR
893 005622 005337 001346      IS:     DEC          J#TIMR
894 005626 001375      BNE     IS
895 005630 000207      RTS          PC
896
897      ; THIS ROUTINE CHECKS TO SEE IF A DRIVE IS ACTIVE FROM A
898      ; WRITE OPERATION. IT GETS THE READ MASK TO R3, AND THE
899      ; EXPECTED DATA PATTERN TO "PATTERN", AND THEN CALLS ADDRESS
900      ; CONTROL.
901
902 005632 010046      RDLINK: MOV         RO,-(SP)      ;SAVE RO
903 005634 000240      NOP                               ;***
904 005636 152737 000377 001316      BISB    #377,J#COMND ;INDICATE READ OPERATION
905 005644 012701 001166      MOV     #LOGA,R1      ;GET THE TABLE ADDRESS TO R1
906 005650 012705 001305      MOV     #SECTBL,R5    ;GET THE SECTOR TABLE ADDRESS
907 005654 000405      BR      RD2          ;SKIP OVER THE INDEX, FIRST PASS
908 005656 062701 000002      RD1:   ADD          #2,R1      ;ADD 2 TO THE ADDRESS
909 005662 022701 001206      CMP     #DRVD,R1     ;ARE YOU THRU THE ENTIRE TABLE
910 005666 001503      BEQ     EXIT2        ;IF YES EXIT
911 005670 005711      RD2:   TST          (R1)      ;IS THE DRIVE ACTIVE
912 005672 100001      BPL     RD3          ;IF YES BRANCH
913 005674 000770      BR      RD1          ;IF NO GET NEXT WORD
914 005676 011100      RD3:   MOV          (R1),RO    ;GET THE ACTIVE WORD TO RO
915 005700 010002      MOV     RO,R2        ;COPY THE WORD
916 005702 000300      SWAB   RO           ;GET THE DRIVE # TO THE LOW BYTE
917 005704 042700 177770      BIC     #177770,RO   ;CLR ALL BUT THE DRIVE #
918 005710 110037 001317      MOVB   RO,J#RTNBY   ;SAVE THE DRIVE #
919 005714 006100      ROL     RO           ;MAKE IT AN INDEX
920 005716 016037 001206 001362      MOV     DRVD(RO),J#PATTRN ;PICK UP THE DATA PATTERN
921 005724 004737 005234      JSR     PC,MASK      ;CALL THE MASK SUBROUTINE
922 005730 004737 005302      JSR     PC,CYLADR    ;GO FORM A CYLINDER ADDRESS
923 005734 000401      BR      RD4          ;RETURN HERE IF NOT LAST BASE ADDR.
924 005736 000747      BR      RD1          ;IF LAST BASE ADDRESS, RETURN HERE
925 005740 053737 001352 001334      RD4:   BIS          J#DSKTMP,J#DSKADR ;SET THE DRIVE # BITS IN DISK ADDR.
926 005746 152537 001334      RD5:   BISB   (R5),J#DSKADR ;SET THE SECTOR BITS IN DISK ADDR.
927 005752 012737 007356 001336      RD6:   MOV     #RUBUFF,J#BUSADR ;GET THE BUFFER ADDR.
928 005760 000240      NOP                               ;***

```

```

930 005770 013737 001356 001332      MOV      @RREADCS,@CONTRL ;GET THE READ CONTROL WORD
931 005776 004737 005402      JSR      PC,EXECUT        ;DO THE READ
932 006006 004737 006450      JSR      PC,ROCHK        ;CHECK THE DATA
933 006006 042737 000017 001334      BIC      @17,@OSKADR     ;CLR THE SECTOR BITS IN DISK ADDR.
934 006014 022705 001311      CMP      @RCONT1,RS     ;WAS THIS THE LAST SECTOR?
935 006014 001311      BNE      RDS            ;IF NO GO BACK
936 006014 012705 001305      MOV      @SECTBL,RS     ;IF YES RESET SECTOR POINTER
937 006014 032737 000020      BIT      @BIT4,@OSKADR  ;WAS IT SURFACE "1" THAT WAS READ?
938 006014 001006      BNE      RD7           ;IF YES, BRANCH
939 006014 052737 000020 001334      BIS      @BIT4,@OSKADR  ;NO, SET SURFACE "1" BIT
940 006014 105137 001362      COMB    @PATTN        ;MAKE HEAD "1" PATTERN
941 006014 000736      BR      RDS           ;GO BACK AND EXECUTE
942 006014 042737 000020 001334 RD7:      BIC      @BIT4,@OSKADR  ;CLEAR THE SURFACE BIT
943 006014 105137 001362      COMB    @PATTN        ;MAKE IT SURFACE 0 DATA
944 006064 003202      INC     R2            ;INCREMENT THE SELECTED CYL TABLE POINTER
945 006066 004737 005312      JSR      PC,CYLOFF     ;GO FORN NEXT ADDRESS
946 006072 000722      BR      R04          ;IF HERE IT IS NOT THE LAST BASE ADDR
947 006074 000670      BR      R01          ;IF HERE GET NEXT WORD-DRIVE FINISHED

948 006076 012600      EXIT2:  MOV      (SP)+,R0 ;RESTORE R0
949 006100 000207      RTS     PC           ;RETURN TO MAIN LINE CODE

;THE ERROR CHECK ROUTINE CHECKS IF AN ERROR OCCURRED
;ON WRITING OR READING.

955 006102 032777 140000 173260 ERRCHK: BIT      @140000,@RCKS ;HARD ERROR OR ERROR SET?
956 006110 000240      NOP                    ;HALT HERE TO EXAMINE ERROR REG.,ECT.
957 006112 001420      BEQ     TSTSN1        ;IF NO, GO TEST 'SIN' BIT
958 006114 012777 000001 173246      MOV     @1,@RCKS     ;IF YES, ISSUE CNTROL RESET + GO
959 006122 004737 005614      JSR    PC,SMTME
960 006126 012777 177777 173224      MOV     @-1,@ERRFLG ;FLAG AN ERROR (PREVENT UPDATE OF ADDR)
961 006134 105777 173230      IS:    TSTB @RCKS    ;CNTROL READY BIT SET (FROM CNTROL RESET)
962 006140 100375      BPL    IS            ;IF NO WAIT, (IF HUNG HERE RUN STATIC)
963 006142 105337 001321      DECB   @#ECNT        ;DECREMENT ERR/A COUNTER
964 006146 001002      BNE    TSTSN1        ;HAVE ERROR BITS SET 5 TIMES?
965 006150 000137 006232      JMP    @RESTRT       ;IF HERE 5 ERRORS HAVE OCCURRED
966 006154 032777 001000 173202 TSTSN1: BIT     @1000,@RCKS ;SEEK INCOMPLETE SET?
967 006162 000240      NOP                    ;***
968 006164 001530      BEQ    RETRN2        ;BRANCH IF NO
969 006166 012777 000015 173174      MOV     @15,@RCKS   ;IF YES, ISSUE DRIVE RESET, GO
970 006174 012777 177777 173156      MOV     @-1,@ERRFLG ;FLAG AN ERROR (PREVENT UPDATE OF ADDR)
971 006202 004737 005614      JSR    PC,SMTME
972 006206 105777 173156      2$:    TSTB @RCKS
973 006212 100375      BPL    2$
974 006214 032777 000100 173142      BIT     @100,@RCKS ;"R/W/S READY" BIT SET?
975 006222 001771      BEQ    2$            ;IF NO WAIT! (IF HUNG HERE RUN STATIC)
976 006224 105337 001322      DECB   @#CNTSIN      ;DECREMENT SEEK INCOMPLETE COUNTER
977 006230 001106      BNE    RETRN2        ;IF 3 'SIN' ERRORS FALL THROUGH
978 006232 105737 001321      RESTRT: TSTB @#ECNT
979 006236 000240      NOP                    ;***
980 006240 001421      BEQ    1$
981 006242 104401 006250      TYPE   65$          ;:TYPE ASCIZ STRING
982 006246 000415      BR     64$          ;:GET OVER THE ASCIZ
983 65$: .ASCIZ <15><12>/3 'SIN' ERRORS OCCURRED/
984 006302      64$:

```

```

986 006304
987 006304 104401 006312
988 006310 000412
989
990 006336
991 006336
992 006336 104401 006344
993 006342 000422
994
995 006410
996 006410 105737 001316
997 006414 100006
998 006416 062706 000004
999 006422 012600
1000 006424 052710 100000
1001 006430 000207
1002 006432 052710 100000
1003 006436 012706 001100
1004 006442 000137 003324
1005 006446 000207
1006
1007
1008
1009
1010 006450 010446
1011 006452 010546
1012 006454 105037 001320
1013 006460 000240
1014 006462 012737 000005 001350
1015 006470 012704 007356
1016 006474 013705 001362
1017 006500 020524
1018 006502 001515
1019 006504 105737 001320
1020 006510 001046
1021 006512 104401 006520
1022 006516 000420
1023
1024 006560
1025 006560 152737 000377 001320
1026 006566 113746 001317
1027 006572 104403
1028 006574 001
1029 006575 000
1030 006576 104401 006604
1031 006602 000411
1032
1033 006626
1034 006626
1035 006626 104401 006634
1036 006632 000405
1037
1038 006646
1039 006646 013746 001334
1040 006652 104403

```

```

15:
TYPE 67$           ;;TYPE ASCIZ STRING
BR 66$            ;;GET OVER THE ASCIZ
;;67$: .ASCIZ <15><12>/5 ERRORS OCCURRED/
66$:
2$:
TYPE 69$           ;;TYPE ASCIZ STRING
BR 68$            ;;GET OVER THE ASCIZ
;;69$: .ASCIZ / DRIVE DECLARED DOWN!! NOT TESTED !/
68$:
TSTB 2#COMND      ;TEST THE COMMAND
BPL 3$            ;IF WRITE, BRANCH
ADD 4,SP          ;POINT TO SAVE RD
MOV (SP)+,R0      ;GET RD BACK
BIS 15,(R0)       ;SET THE DOWN BIT
RTS PC            ;RETURN TO MAIN CODE
3$:
BIS 15,(R0)       ;SET THE DOWN BIT
MOV 8STACK,SP    ;RESTORE THE STACK
JMP 2#G01
RETRN2: RTS PC

;THIS ROUTINE CHECKS A SECTORS WORTH OF DATA ON A READ OPERATION
;IT ALLOWS 5 ERROR PRINTOUTS PER SECTOR
RDCHK: MOV R4,-(SP) ;SAVE R4
MOV R5,-(SP)      ;SAVE R5 FOR RDLINK
CLRB 2#HDRFLG    ;CLEAR THE PRINT HEADER FLAG
NOP              ;***
MOV 5,2#CHKCNT   ;PUT ERROR COUNT IN CHECK COUNT
MOV 8ROBUFF,R4  ;GET THE TABLE ADDRESS TO R4
MOV 2#PTRN,R5   ;GET THE EXPECTED DATA TO R5
1$: CMP R5,(R4)+ ;ARE THEY THE SAME
BEQ 3$           ;IF YES BRANCH
TSTB 2#HDRFLG   ;IS THE HEADER FLAG CLEAR
BNE 2$          ;IF NO BRANCH
TYPE 65$        ;TYPE ASCIZ STRING
BR 64$          ;GET OVER THE ASCIZ
;;65$: .ASCIZ <15><12>/ERROR! DATA WRITTEN BY DRIVE /
64$:
BISB 377,2#HDRFLG ;SET THE HEADER FLAG
MOVB 2#WRNBY,-(SP) ;PICK UP THE DRIVE # THAT WROTE
TYPOS .BYTE 1
.BYTE 0
TYPE 67$        ;TYPE ASCIZ STRING
BR 66$          ;GET OVER THE ASCIZ
;;67$: .ASCIZ / CANNOT BE READ./
66$:
2$:
TYPE 69$        ;TYPE ASCIZ STRING
BR 68$          ;GET OVER THE ASCIZ
;;69$: .ASCIZ <15><12>/ ADDR=/
68$:
MOV 2#DSKADR,-(SP) ;PICK UP THE ADDRESS THAT FAILED
TYPOS

```

```

1042 006655 001          BYTE 1
1043 006656 104401 006664  TYPE 71$          ;;TYPE ASCIZ STRING
1044 006662 000405          BR 70$           ;;GET OVER THE ASCIZ
1045          ;;71$: .ASCIZ / EXPCTD=/
1046 006676          70$: MOV R5,-(SP)      ;PICK UP THE EXPECTED DATA (GOOD)
1047 006676 010546          TYPON
1048 006700 104404          TYPE 73$          ;;TYPE ASCIZ STRING
1049 006702 104401 006710          BR 72$           ;;GET OVER THE ASCIZ
1050 006706 000405          ;;73$: .ASCIZ / RECVD=/
1051          72$: MOV R5,-2(R4),-(SP) ;PICK UP THE RECEIVED DATA (BAD)
1052 006722          TYPON
1053 006722 016446 177776          DEC 2#CHKCNT      ;DECREMENT THE CHECK COUNT
1054 006726 104404          BEQ 4$           ;IF ZERO, BRANCH
1055 006730 005337 001350          CMP #MANSEL,R4   ;DONE ALL CHECKS?
1056 006734 001403          BNE 1$           ;IF NO, GO BACK
1057 006736 022704 010356          3$: MOV (SP)+,R5 ;RESTORE R5
1058 006742 001256          4$: MOV (SP)+,R4 ;RESTORE R4
1059 006744 012605          RTS PC           ;RETURN TO CALLER
1060 006746 012604
1061 006750 000207
1062
1063          ;THIS ROUTINE BUILDS A TABLE OF PARAMETERS TO PASS TO THE SECOND SYSTEM
1064          ;IT PACKS THE INFO FOR TWO DRIVES INTO ONE WORD
1065
1066 006752 005003          SECONE: CLR R3           ;CLEAR THE WORD COUNTER
1067 006754 000240          NOP              ;***
1068 006756 012702 001256          MOV #MSKTBL,R2
1069 006762 005042          6$: CLR -(R2)
1070 006764 022702 001246          CMP #PASTBL,R2
1071 006770 001374          BNE 6$
1072 006772 012700 001166          MOV #LOGA,R0     ;GET THE ACTIVE TABLE ADDRESS
1073 006776 012001          1$: MOV (R0)+,R1   ;PICK UP THE WORD
1074 007000 000301          SWAB R1          ;GET THE DRIVE # TO THE LOW BYTE
1075 007002 042701 177400          BIC #177400,R1  ;CLEAR THE UNWANTED BITS
1076 007006 106101          ROLB R1          ;ROTATE THE BYTE, WAS DOWN SET?
1077 007010 103002          BCC 2$           ;IF NO BRANCH
1078 007012 052701 000001          BIS #BIT0,R1    ;SHOW THE DRIVE AS DOWN IN THE TABLE
1079 007016 105701          2$: TSTB R1      ;IS THIS THE SYSTEM #2 DRIVE?
1080 007020 100404          BMI 3$           ;BRANCH IF YES
1081 007022 142701 000360          BICB #360,R1    ;CLEAR THE UNUSED BITS
1082 007026 110122          MOVB R1,(R2)+   ;GET THIS # TO THE PASS TABLE
1083 007030 000762          BR 1$           ;GET THE NEXT WORD FROM ACTIVE TABLE
1084 007032 110112          3$: MOVB R1,(R2)  ;GET THE LAST DRIVE TO THE PASS TABLE
1085 007034 012702 001246          MOV #PASTBL,R2  ;RESTORE THE TABLE POINTER
1086 007040 104401 007046          TYPE 65$        ;TYPE ASCIZ STRING
1087 007044 000425          BR 64$          ;GET OVER THE ASCIZ
1088          ;;65$: .ASCIZ <15><12>/LOAD AND START ADDRESS 210 ON SYSTEM #2/
1089 007120          64$: TYPE 67$   ;TYPE ASCIZ STRING
1090 007120 104401 007126          BR 66$          ;GET OVER THE ASCIZ
1091 007124 000424          ;;67$: .ASCIZ <15><12>/AND TYPE THE BELOW WHEN ASKED FOR IT./
1092          66$:
1093 007176          4$: INC R3        ;INCREMENT THE WORD COUNTER
1094 007176 005203          TYPE 69$        ;TYPE ASCIZ STRING
1095 007200 104401 007206          BR 68$          ;GET OVER THE ASCIZ
1096 007204 000405          68$:

```

```

1098 007220          62%:  MOV      R3,-(SP)      ;GET THE WORD COUNT ON THE STACK
1099 007220 010346  TYPOS
1100 007222 104403  .BYTE    6
1101 007224      006  .BYTE    0
1102 007225      000  .BYTE    0
1103 007226 104401 007234  TYPE     71%      ;;TYPE ASCIZ STRING
1104 007232 000401  BR       70%      ;;GET OVER THE ASCIZ
1105          ;;71%:  .ASCIZ  /=/
1106 007236 70%:  MOV      (R2)+,-(SP)  ;GET THE FIRST TO THE STACK
1107 007236 012246  TYPOS
1108 007240 104403  .BYTE    6
1109 007242      006  .BYTE    1
1110 007243      001  .BYTE    1
1111 007244 032762 100000 177776  BIT      #BIT15,-2(R2) ;WAS THIS THE TABLE TERMINATOR
1112 007252 001004  BNE      5%      ;BRANCH IF YES
1113 007254 032762 000200 177776  BIT      #BIT7,-2(R2) ;TERMINATOR?
1114 007262 001745  BEQ      4%      ;IF NO BRANCH
1115 007264 005740 5%:  TST      -(R0)
1116 007266 000000  HALT
1117
1118 007270          RETFR2:
1119 007270 104401 007276  TYPE     65%      ;;TYPE ASCIZ STRING
1120 007274 000404  BR       64%      ;;GET OVER THE ASCIZ
1121          ;;65%:  .ASCIZ  <15><12>/WORD=/
1122 007306 64%:
1123 007306 104411  RDOCT
1124 007310 012602  MOV      (SP)+,R2      ;GET THE WORD FROM SYSTEM 2 TO TABLE
1125 007312 042702 177400  BIC      #177400,R2
1126 007316 012704 001166  MOV      #LOGA,R4      ;SET POINTER LOOK FOR FIRST "UP" DRIVE
1127 007322 005724 1%:  TST      (R4)+        ;DRIVE UP?
1128 007324 100776  BMI      1%      ;IF NO BRANCH
1129 007326 010437 001100  MOV      R4,#$PASS
1130 007332 014401  MOV      -(R4),R1
1131 007334 000240  NOP
1132 007336 004737 004224  JSR      PC,LDPLG      ;CALL D02+
1133 007342 004737 005632  JSR      PC,ROLINK     ;CALL READ CHECK
1134 007346 013700 001100  MOV      #,$PASS,R0
1135 007352 000137 003372  JMP      #EXTFR2      ;GO TO END OF TEST
1136
1137 007356 000400  RDBUFF: .BLKW 400
1138
1139 010356 000240  MANSEL: NOP          ;TABLE TERMINATOR
1140
1141
1142
1143
1144
1145 010360          BADONE:
1146 010360 104401 010366  TYPE     65%      ;;TYPE ASCIZ STRING
1147 010364 000401  BR       64%      ;;GET OVER THE ASCIZ
1148          ;;65%:  .ASCIZ  /=/
1149 010370 64%:
1150
1151
1152          .SBTTL  OSCILLATING SEEK ROUTINE

```

```

1154 010370          SECT.2:
1155 010370 104401 010376      TYPE      65$          ;;TYPE ASCIZ STRING
1156 010374 000416          BR        64$          ;;GET OVER THE ASCIZ
1157          ;;65$: .ASCIZ <15><12>/OSCILLATING SEEK PACKAGE/
1158 010432          64$:
1159
1160 010432 012700 020614      MOV      #DRIVO,R0      ;FIND OUT WHICH DRIVES ARE
1161 010436 005001          CLR      R1             ;PRESENT AND PUT THE
1162 010440 010177 170732      1$: MOV    R1,DRKDA      ;DRIVE #'S IN A TABLE STARTING
1163 010444 105777 170714      TSTB   DRKDS           ;AT 'DRIVO'. BITS 15-13 CONTAINS
1164 010450 100001          BPL     2$             ;THE DRIVE #
1165 010452 010120          MOV    R1,(R0)+
1166 010454 062701 020000      2$: ADD    #20000,R1
1167 010460 001367          BNE    1$
1168 010462 012710 177777      MOV    #-1,(R0)        ;SET THE TERMINATOR TO THE TABLE
1169
1170 010466 013702 001376          INIT.2: MOV   RKDA,R2
1171 010472 012777 000001 170670      MOV   #1,DRKCS        ;ISSUE CONTROL RESET + GO !
1172 010500 004737 005614          JSR   PC,SMTME
1173 010504 105777 170660      1$: TSTB DRKCS         ;DID CONTROL READY SET?
1174 010510 100375          BPL    1$             ;IF NO WAIT! (IF HUNG RUN STATIC)
1175 010512 012700 020614      MOV   #DRIVO,R0
1176 010516 012077 170654      3$: MOV   (R0)+,DRKDA
1177 010522 012777 000015 170640      MOV   #15,DRKCS      ;ISSUE DRIVE RESET + GO!
1178 010530 004737 005614          JSR   PC,SMTME
1179 010534 105777 170630      2$: TSTB DRKCS
1180 010540 100375          BPL    2$
1181 010542 022710 177777      CMP   #-1,(R0)
1182 010546 001363          BNE    3$
1183 010550 104401 010556      TYPE   65$          ;;TYPE ASCIZ STRING
1184 010554 000432          BR     64$          ;;GET OVER THE ASCIZ
1185          ;;65$: .ASCIZ <15><12>/SET SW0 TO SW7 TO SELECT DRIVES FOR TEST AND CONT/
1186 010642          64$:
1187 010642 104401 010650      TYPE   67$          ;;TYPE ASCIZ STRING
1188 010646 000426          BR     66$          ;;GET OVER THE ASCIZ
1189          ;;67$: .ASCIZ <15><12>/RESET SW0 TO SW7 TO TEST ALL AVAIL DRIVES/
1190 010724          66$:
1191 010724 022737 000176 001140      7$: CMP   #SWREG,SWR    ;SOFTWARE SWITCH REGISTER IN USE ?
1192 010732 001002          BNE    9$
1193 010734 104405          GTSWR          ;BR IF NOT
1194 010736 000401          BR     8$          ;REQUEST NEW CONTENTS FOR SWITCH REG
1195 010740 000000          HALT                    ;CONTINUE
1196 010742 117704 170172      9$: MOV   #SWR,R4      ;WAIT FOR OPERATOR TO ENTER NEW SWR VALUE
1197 010746 001413          BEQ   4$             ;SW0 TO SW7 TO R4
1198 010750 012700 020614      MOV   #DRIVO,R0      ;NONE SET, SO TEST ALL
1199 010754 005001          CLR   R1             ;TABLE TO STORE DRIVE ADDRS
1200 010756 006004          ROR   R4             ;ADDR OF DRIVE
1201 010760 103001          BCC   5$            ;NEXT SWITCH TO CARRY
1202 010762 010120          MOV   R1,(R0)+      ;SWITCH NOT SET
1203 010764 062701 020000      5$: ADD    #20000,R1    ;SWITCH SET, SO MOVE ADDR TO TABLE
1204 010770 001372          BNE    6$
1205 010772 012720 177777      MOV   #-1,(R0)+      ;ADDR OF NEXT DRIVE
1206 010776 105737 001326      4$: TSTB OSPFLG      ;ALL DONE WHEN ZERO
1207 011002 001165          BNE   RWSRDY        ;TABLE TERMINATOR
1208 011004 104401 011012      TYPE   ,69$          ;TYPED ONCE?
                        ;IF YES, DON'T RETYPE
                        ;;TYPE ASCIZ STRING

```



```

1266 011626 004737 005614      JSR      PC,SMTME
1267 011632 105777 167532      TSTB    JAKCS
1268 011636 100375          BPL     3$
1269
1270 011640 022710 177777      CMP     #-1,(RO)      ;ALL DRIVES DONE?
1271 011644 001361          BNE     5$           ;NO
1272 011646 012700 020614      MOV     #DRIVO,RO
1273 011652 012077 167520      MOV     (RO)+,JAKDA
1274 011656 032777 000100 167500 6$:      BIT     #RWS,JAKDS   ;ADRES THE DRIVE
7$:      ;SEEK DONE?
1275 011664 001774          BEQ     7$           ;NO, WAIT
1276 011666 022710 177777      CMP     #-1,(RO)      ;ALL DRIVES DONE?
1277 011672 001367          BNE     6$           ;NO
1278
1279 011674 012700 020614      MOV     #DRIVO,RO
1280 011700 010577 167472      MOV     R5,JAKDA    ;SET OUTER CYL ADRES
1281 011704 052077 167466      BIS     (RO)+,JAKDA ;SET DRIVE ADRES
1282 011710 012777 000011 167452      MOV     #11,JAKCS   ;ISSUE SEEK+GO! (FOR OUTER LIMIT)
1283 011716 004737 005614      JSR     PC,SMTME
1284 011722 105777 167442      TSTB    JAKCS
1285 011726 100375          BPL     9$
1286
1287 011730 022710 177777      CMP     #-1,(RO)      ;ALL DONE?
1288 011734 001361          BNE     8$           ;NO
1289
1290 011736 012700 020614      MOV     #DRIVO,RO
1291 011742 012077 167430      MOV     (RO)+,JAKDA ;SET DRIVE ADRES
1292 011746 032777 000100 167410 10$:     BIT     #RWS,JAKDS   ;SEEK DONE?
11$:
1293 011754 001774          BEQ     11$
1294 011756 022710 177777      CMP     #-1,(RO)      ;ALL DONE?
1295 011762 001367          BNE     10$
1296 011764 005303          DEC     R3           ;DONE 50 SEEK CYCLES (100 SEEKS)
1297 011766 001306          BNE     LDSEEK      ;IF NO BRANCH (KEEP CYCLING)
1298 011770 000605          BR     CONTIN      ;CHECK SWR FOR CHANGE AND CONTINUE
1299
1300
1301
1302
1303
1304
1305

```

.SBTTL FORMATTER-SURFACE VERIFIER

```

1306 011772          BAD.IN:
1307 011772 104401 012000      TYPE    65$          ;;TYPE ASCIZ STRING
1308 011776 000401          BR     64$          ;;GET OVER THE ASCIZ
1309
1310          ;;65$: .ASCIZ  /?/
1311          64$:
1312 012002 104401 012010      SECT.1: TYPE    65$          ;;TYPE ASCIZ STRING
1313 012006 000441          BR     64$          ;;GET OVER THE ASCIZ
1314          ;;65$: .ASCIZ <15><12>/FORMATTER-SURFACE VERIFIER,SET SW REG FOR DRV #'S. PRESS CONT./
1315          64$:
1316 012112 022737 000176 001140      CMP     #SWREG,SWR   ;SOFTWARE SWITCH REGISTER IN USE ?
1317 012120 001002          BNE     1$          ;BR IF NOT
1318 012122 104405          GTSWR          ;GET SWITCH REGISTER VALUE
1319 012124 000401          BR     2$          ;CONTINUE
1320 012126 000000          BR     1$          ;WAIT FOR 'CONTINUE'

```

1322	012136	005037	020446			CLR	DRVCNT	; CLEAR DRIVE COUNT
1323	012142	033777	020444	166770	S13:	BIT	SHFCNT, JSWR	; IS THIS SW SET?
1324	012150	001011				BNE	S10	; YES FORMAT THIS DRIVE
1325	012152	005337	020444		S11:	ASL	SHFCNT	
1326	012156	005237	020446			INC	DRVCNT	
1327	012162	022737	000010	020446		CMP	#10, DRVCNT	; ALL DONE?
1328	012170	001561				BEQ	GO1	
1329	012172	000763				BR	S13	
1330	012174	013700	020446		10:	MOV	DRVCNT, RO	
1331	012200	104401	001161			TYPE	, SCRLF	; TYPE 'DRIVE'
1332	012204	104401	020450			TYPE	, EM1	; TYPE DRIVE #
1333	012210	010046				MOV	RO, -(SP)	
1334	012212	104402				TYPOC		
1335	012214	000300				SWAB	RO	
1336	012216	006100				ROL	RO	
1337	012220	006100				ROL	RO	
1338	012222	006100				ROL	RO	
1339	012224	006100				ROL	RO	
1340	012226	006100				ROL	RO	
1341	012230	010037	001352			MOV	RO, #DSKTN.	
1342	012234	012737	000000	001422		MOV	#0, ERRWF	
1343	012242	012737	000000	001424		MOV	#0, ERRRF	; CLEAR OUT ERROR COUNTS.
1344	012250	012737	000000	001426		MOV	#0, ERRRFC	
1345	012256	012737	000000	001430		MOV	#0, ERRWCH	
1346	012264	012737	000000	001432		MOV	#0, ERRWCS	
1347	012272	012737	177750	001416	S12:	MOV	#-24, RWC	; SET WORD COUNT FOR READ FORMAT.
1348	012300	012737	164000	001412		MOV	#-6144, WC	; SET UP WORD COUNT FOR WRITES.
1349	012306	012737	000000	001420		MOV	#0, EXTR	; CLEAR EXTRA BIT FOR 12 SECTOR PACK.
1350	012314	012701	177772		COMMON:	MOV	#-6, R1	; SET UP LOOP COUNT FOR THE CLEANER.
1351	012320	012777	014500	167050	COM:	MOV	#14500, JAKDA	; SET UP FOR A SEEK TO 202.
1352	012326	053777	001352	167042		BIS	#DSKTMP, JAKDA	
1353	012334	105777	167030		1\$:	TSTB	JAKCS	; IS THE CONTROLLER READY?
1354	012340	100375				BPL	1\$	; NO SO WAIT.
1355	012342	012777	000011	167020		MOV	#11, JAKCS	; DO THE SEEK.
1356	012350	032777	000100	167006	2\$:	BIT	#BIT6, JAKDS	; IS THE SEEK DONE?
1357	012356	001774				BEQ	2\$	; NO SO WAIT.
1358	012360	105777	167004		3\$:	TSTB	JAKCS	; IS CONTROLLER READY?
1359	012364	100375				BPL	3\$	; NO
1360	012366	012777	000015	166774		MOV	#15, JAKCS	; DO A DRIVE RESET.
1361	012374	032777	000100	166762	4\$:	BIT	#BIT6, JAKDS	; IS DRIVE RESET DONE.
1362	012402	001774				BEQ	4\$	; NO
1363	012404	005201				INC	R1	; COUNT THE CLEANER LOOP.
1364	012406	001344				BNE	COM	; MORE TO GO.
1365	012410	012737	000000	001410		MOV	#0, DA	; START OUT AT CYL. 0.
1366	012416	012777	177777	166762	NEXT:	MOV	#177777, JBA	; PUT ALL ONE'S IN BUFFER.
1367	012424	004137	012540			JSR	R1, IO	; GO DO THE DISK THING.
1368	012430	012777	000000	166750		MOV	#0, JBA	; PUT ALL ZERO'S IN BUFFER.
1369	012436	004137	012540			JSR	R1, IO	; GO DO IT AGAIN.
1370	012442	012777	125252	166736		MOV	#125252, JBA	; PUT A ALT. PATTERN IN BUFFER.
1371	012450	004137	012540			JSR	R1, IO	; ONCE MORE.
1372	012454	005177	166726			COM	JBA	; COMPLEMENT THE LAST PATTERN.
1373	012460	004137	012540			JSR	R1, IO	; AND AGAIN.
1374	012464	062737	000040	001410		ADD	#40, DA	; INCREMENT TO THE NEXT CYL.
1375	012472	022737	014540	001410		CMP	#14540, DA	; ARE WE DONE WITH THIS ONE?
1376	012500	001346				BNE	NEXT	; NO SO DO THE NEXT CYL.

```

1378 012502 104401 012510
1379 012506 000411
1380
1381 012532
1382 012532 000607
1383 012534 000137 001440
1384
1385
1386
1387
1388
1389
1390 012540 013777 001412 166624
1391 012546 013777 001410 166622
1392 012554 053777 001352 166614
1393 012562 013777 001406 166604
1394 012570 012777 000000 166572
1395 012576 052777 006000 166564
1396 012604 052777 000002 166556
1397 012612 053777 001420 166550
1398 012620 052777 000001 166542
1399 012626 105777 166536
1400 012632 100375
1401 012634 005777 166530
1402 012640 100541
1403 012642 012737 000000 001422
1404
1405
1406
1407 012650 013777 001416 166514
1408 012656 013777 001410 166512
1409 012664 053777 001352 166504
1410 012672 013777 001414 166474
1411 012700 012777 000000 166462
1412 012706 052777 002000 166454
1413 012714 052777 000004 166446
1414 012722 053777 001420 166440
1415 012730 052777 000001 166432
1416 012736 105777 166426
1417 012742 100375
1418 012744 032777 040000 166416
1419 012752 001134
1420 012754 012737 000000 001424
1421
1422
1423
1424 012762 013777 001412 166402
1425 012770 013777 001410 166400
1426 012776 053777 001352 166372
1427 013004 013777 001406 166362
1428 013012 012777 000000 166350
1429 013020 052777 004400 166342
1430 013026 053777 001420 166334
1431 013034 052777 000006 166326
1432 013042 052777 000001 166320

      TYPE      655      ;:TYPE ASCIZ STRING
      BR        645      ;:GET OVER THE ASCIZ
;:655: .ASCIZ <CR><LF>/PACK GOOD /
645:
GDI:  BR        S11
      JMP      @#START ;RESTART

;DISK I/O SUBROUTINE.

;SET UP FOR A WRITE/FORMAT.
10:  MOV      WC,@RKWC ;:SET UP THE WORD COUNT REG.
      MOV      DA,@RKDA ;:SET UP THE DISK ADDRESS.
      BIS      @#OSKTMP,@RKDA ;:SET THE UNIT NUMBER UP.
      MOV      BA,@RKBA ;:SET UP THE BUSS ADDRESS.
      MOV      @0,@RKCS ;:CLEAR THE CONTROL REG. FOR SET UP.
      BIS      @BIT10+BIT11,@RKCS ;:SET FORMAT&INHIBT INC. BITS.
      BIS      @BIT1,@RKCS ;:SET UP WRITE FUN.
      BIS      EXTR,@RKCS ;:SET UP 12OR16 SECTOR PACK.
      BIS      @BIT0,@RKCS ;:GO DO THE WRITE FORMAT.
15:  TSTB     @RKCS ;:IS WRITE FORMAT DONE?
      BPL     @0 ;:NO SO WAIT.
      TST     @RKCS ;:WAS THERE A ERROR?
      BMI     @WFERR ;:YES GO SERVICE IT.
      MOV     @0,@ERRWF ;:CLEAR OUT THE ERROR COUNTER.

;SET UP FOR A READ/FORMAT
      MOV      RWC,@RKWC ;:SET UP WORD COUNT REG.
      MOV      DA,@RKDA ;:SET UP DISK ADDRESS.
      BIS      @#OSKTMP,@RKDA ;:SET THE UNIT NUMBER
      MOV      RBA,@RKBA ;:SET UP THE BUSS ADDRESS.
      MOV      @0,@RKCS ;:CLEAR THE CONTROL RE
      BIS      @BIT10,@RKCS ;:SET THE FORMAT BIT.
      BIS      @BIT2,@RKCS ;:SET UP READ FUN.
      BIS      EXTR,@RKCS ;:SET UP 12 OR 16 SECTOR PACK.
      BIS      @BIT0,@RKCS ;:GO DO THE READ FORMAT.
25:  TSTB     @RKCS ;:IS THE READ FORMAT DONE?
      EPL     @0 ;:NO SO WAIT.
      BIT     @BIT14,@RKCS ;:WAS TRERE A ERROR?
      BNE     @RERR ;:YES GO SERVICE IT.
      MOV     @0,@ERRRF ;:CLEAR OUT THE ERROR COUNT.

;SET UP FOR A WRITE CHECK.
      MOV      WC,@RKWC ;:SET UP WORD COUNT REG.
      MOV      DA,@RKDA ;:SET UP DISK ADDRESS.
      BIS      @#OSKTMP,@RKDA ;:SET UP THE UNIT NUMBER
      MOV      BA,@RKBA ;:SET UP BUSS ADDRESS.
      MOV      @0,@RKCS ;:CLEAR THE CONTROL REG.
      BIS      @BIT11+BIT8,@RKCS ;:SET INHIBIT INCR.&STOP ON SOFT ERROR BITS.
      BIS      EXTR,@RKCS ;:SET 12 OR 16 SECTOR PACK.
      BIS      @BIT1+BIT2,@RKCS ;:SET UP WRITE CHECK FUN.
      BIS      @BIT0,@RKCS ;:GO DO THE WRITE CHECK.

```

```

1434 ;CHECK HEADERS READ BY THE READ/FORMAT.
1435 ;
1436 013050 013703 001416      MOV      RWC,R3      ;PUT NUMBER OF WORDS TO
1437 013054 005403              NEG      R3          ;CHECK IN REG 3.
1438 013056 063703 001414      ADD      RBA,R3     ;SET REG 3 TO THE LAST WORD TO BE CHECKED.
1439 013062 013702 001414      MOV      RBA,R2     ;SET REG 2 TO STARTING ADD. OF BUFF.
1440 013066 023722 001410      MORE:    CMP      DA,(2)+ ;CHECK THAT HEADER IS RIGHT.
1441 013072 001073              BNE     RFCERR      ;THIS HEADER WAS WRONG GO SERVICE IT.
1442 013074 020302              CMP      R3,R2     ;ARE WE DONE?
1443 013076 001373              BNE     MORE       ;NO GO CHECK THE NEXT ONE.
1444 013100 012737 000000 001426  NOV      #0,ERRRFC   ;CLEAR OUT THE ERROR COUNT.
1445 ;
1446 ;LETS CHECK ON THE WRITE CHECK WE STARTED.
1447 ;
1448 013106 105777 166256      IS:      TSTB     DRKCS ;THE CONTROLER IS STILL BUSY.
1449 013112 100375              BPL     IS         ;WAS THERE A ERROR?
1450 013114 005777 166250      TST     DRKCS      ;YES GO SERVICE IT.
1451 013120 100407              BMI     WCERRR     ;YES GO SERVICE IT.
1452 013122 012737 000000 001430  MOV      #0,ERRWCH  ;CLEAR OUT THE
1453 013130 012737 000000 001432  MOV      #0,ERRWCS ;ERROR COUNTERS.
1454 013136 000201              RTS     R1         ;RETURN TO THE MAIN LINE.
1455 013140 000137 013624      WCFRRR: JMP      WCERR
1456 ;
1457 ;ERRORS FOR WRITE FORMAT.
1458 ;
1459 013144 005237 001422      WFERR:  INC      .RRWF ;ADD ONE TO THE ERROR COUNT.
1460 013150 022737 000004 001422  CMP      #4,ERRWF  ;HAS IT HAPPEND 4 TIMES ON THIS CYL.
1461 013156 001016              BNE     RETRY     ;NO.
1462 ;
1463 013160 104401 013166      SYSER:  TYPE     65$   ;TYPE ASCIZ STRING
1464 013164 000410              BR      #4$       ;GET OVER THE ASCIZ
1465 ;65$: .ASCIZ 15<12>/SYSTEM ERROR/
1466 ;4$:
1467 013206 000000              HALT
1468 013210 000137 001440      JMP     START     ;LET THE TECH. BREATH.
1469 013214 012777 000000 166146  RETRY:  MOV      #0,DRKCS ;RESTART THE TEST.
1470 013222 012777 000015 166140  MOV      #15,DRKCS ;CLEAR OUT THE CONTROL REG
1471 013230 032777 000100 166126  IS:     BIT      #BIT6,DRKDS ;DO A DRIVE RESET.
1472 013236 001774              BEQ     IS        ;IS IT DONE.
1473 013240 000137 012540      JMP     IO        ;NO SO WAIT.
1474 ;
1475 ;ERRORS FOR READ/FORMAT.
1476 ;
1477 013244 005237 001424      RFERR:  INC      ERRRF ;ADDONE TO ERROR COUNT.
1478 013250 022737 000004 001424  CMP      #4,ERRRF  ;HAS IT HAPPEND 4 TIMES ON THIS CYL?
1479 013256 001356              BNE     RETRY     ;NO DO IT AGAIN.
1480 013260 000737              BR      SYSER     ;YES SO TELL HIM SO.
1481 ;
1482 ;READ/FORMAT ERRORS FOUND BY SOFTWARE CHECKS.
1483 ;
1484 013262 005237 001426      RFCERR: INC      ERRRFC ;ADD ONE TO ERROR COUNT.
1485 013266 105777 166076      IS:     TSTB     DRKCS ;WAIT FOR THE WRITE CHECK.
1486 013272 100375              BPL     IS
1487 013274 022737 000004 001426  CMP      #4,ERRRFC ;IS IT 4?
1488 013302 001401              BEQ     FAILED   ;PUT OUT FAILED MESSAGE.

```

```

1490 013306 042777 000037 166062 FAILED: BIC #37,ARKDA ;PUT WHICH SECTORS HEADER
1491 013314 042702 177740 BIC #177740,R2 ;
1492 013320 060277 166052 ADD R2,ARKDA ;FAILED IN RKDA FOR THE MESSAGE.
1493 013324 FAIL:
1494 013324 104401 013332 TYPE 65$ ;;TYPE ASCIZ STRING
1495 013330 000417 BR 64$ ;;GET OVER THE ASCIZ
1496 ;;65$: .ASCIZ <15><12>/PACK FAILED AT (IN OCTAL) /
1497 64$:
1498 013370 017701 166002 MOV ARKDA,R1 ;GENERAT THE CYL,SECTOR,SURFACE
1499 013374 010102 MOV R1,R2 ;MESSAGE FROM RKDA
1500 013376 042702 BIC #177770,R2
1501 013402 062702 ADD #260,R2
1502 013406 110237 MOVB R2,SEC+1
1503 013412 004337 JSR R3,SHF3
1504 013416 042702 BIC #177776,R2
1505 013422 062702 ADD #260,R2
1506 013426 110237 MOVB R2,SEC
1507 013432 004337 JSR R3,SHF1
1508 013436 042702 BIC #177776,R2
1509 013442 062702 ADD #260,R2
1510 013446 110237 MOVB R2,SUR
1511 013452 004337 JSR R3,SHF1
1512 013456 042702 BIC #177770,R2
1513 013462 062702 ADD #260,R2
1514 013466 110237 MOVB R2,CYL+2
1515 013472 004337 JSR R3,SHF3
1516 013476 042702 BIC #177770,R2
1517 013502 062702 ADD #260,R2
1518 013506 110237 MOVB R2,CYL+1
1519 013512 004337 JSR R3,SHF3
1520 013516 042702 BIC #177774,R2
1521 013522 062702 ADD #260,R2
1522 013526 110237 MOVB R2,CYL
1523 013532 104401 TYPE 1$ ;TYPE OUT THE GENERATED MESSAGE
1524 013536 000137 JMP STOP ;BYPASS THE INLINE MESSAGE
1525 013542 013015 054503 027114 1$: .ASCII <15><12>/CYL.
1526 013550 020040
1527 013552 030060 020060 CYL: .ASCII /000 /
1528 013556 042723 027103 020040 SEC: .ASCII /SEC /
1529 013564 030150 040 SEC: .ASCII /00 /
1530 013567 123 051125 027106 .ASCII /SURF. /
1531 013574 020040
1532 013576 020060 005015 000 SUR: .ASCIZ /0 /<15><12>
1533 013604 .EVEN
1534 013674 000000 STOP: HALT ;LET OPER DO THIS THING.
1535 013606 000137 001440 JMP START ;RESTART THE TEST.
1536
1537 ;SHIFT SUBROUTINES.
1538
1539 013612 006201 SHF3: ASR R1 ;HERE FOR A SHIFT OF 3.
1540 013614 006201 SHF2: ASR R1 ;HERE FOR A SHIFT OF 2.
1541 013616 006201 SHF1: ASR R1 ;HERE FOR A SHIFT OF 1.
1542 013620 010102 MOV R1,R2 ;PUT RESULTES IN THE WORKING REG.
1543 013622 000203 RTS R3
1544 ;

```

```

1546
1547 013624 032777 040000 165536 WCERR: BIT #BIT14,DRKCS ;WAS IT A HARD ERROR.
1548 013632 001010 BNE WCHERR ;YES GO PROSSES IT.
1549 013634 005237 001432 INC ERRWCS ;ADD 1 TO THE SOFT ERROR COUNT.
1550 013640 022737 000004 001432 CMP #4,ERRWCS ;HAS THERE BEEN 4 OF THEM?
1551 013646 001626 BEQ FAIL ;YES PUT OUT FAILED MESSAGE.
1552 013650 000137 012540 JMP IO ;NO SO TRY AGAIN.
1553 013654 005237 001430 WCHERR: INC ERRWCH ;ADD 1 TO THE HARD ERROR COUNT.
1554 013660 022737 000004 001430 CMP #4,ERRWCH ;HAS THERE BEEN 4 OF THEM?
1555 013666 001402 BEQ SYSERR ;YES PUT OUT SYSTEM ERROR MESSAGE.
1556 013670 000137 013214 JMP RETRY ;NO SO TRY AGAIN.
1557 013674 000137 013160 SYSERR: JMP SYSER
1558
1559 ;BUFFERS.
1560
1561 013700 000000 BUFF: .WORD 0
1562 013702 000030 RBUFF: .BLKW 30
1563
1564
1565
1566
1567
1568 .SBTTL RK05 CONTROL PANEL TEST
1569
1570 013762 BAD.ON:
1571 013762 104401 013770 TYPE 65$ ;:TYPE ASCIZ STRING
1572 013766 000401 BR 64$ ;:GET OVER THE ASCIZ
1573 ;:65$: .ASCIZ /?/
1574 013772 64$:
1575 013772 SECT.0:
1576 013772 104401 014000 TYPE 65$ ;:TYPE ASCIZ STRING
1577 013776 000424 BR 64$ ;:GET OVER THE ASCIZ
1578 ;:65$: .ASCIZ <15><12>/RK05 CONTROL PANEL TEST, WHICH DRIVE?/
1579 64$:
1580 014050 RDCHR
1581 014052 011600 MOV (SP),RO
1582 014054 104403 TYPOS
1583 014056 001 .BYTE 1
1584 014057 000 .BYTE 0
1585 014060 162700 000060 SUB #60,RO
1586 014064 100736 BMI BAD.ON
1587 014066 022700 000010 CMP #10,RO
1588 014072 003733 BLE BAD.ON
1589 014074 110037 001314 MOVB RO,DRIVE
1590 014100 000300 SWAB RO
1591 014102 006100 ROL RO
1592 014104 006100 ROL RO
1593 014106 006100 ROL RO
1594 014110 006100 ROL RO
1595 014112 006100 ROL RO
1596 014114 010037 001352 MOV RO,DSKTMP
1597 014120 104401 014126 TYPE 67$ ;:TYPE ASCIZ STRING
1598 014124 000414 BR 66$ ;:GET OVER THE ASCIZ
1599 ;:67$: .ASCIZ <15><12>/MOUNT PACK ON DRIVE#/
1600 66$:
01415_

```

```

1602 014162 104403          TYPOS          ;;GO TYPE--OCTAL ASCII
1603 014164      001        .BYTE 1          ;;TYPE 1 DIGIT(S)
1604 014165      000        .BYTE 0          ;;SUPPRESS LEADING ZEROS
1605 014166 104401 014174   TYPE 69$       ;;TYPE ASCIZ STRING
1606 014172 000425        BR 68$         ;;GET OVER THE ASCIZ
1607          ;;69$: .ASCIZ <15><12>/PLACE DRIVE IN RUN ;SHOULD SEE THE RUN,/
1608          68$:
1608 014246          TYPE 71$       ;;TYPE ASCIZ STRING
1609 014246 104401 014254   BR 70$         ;;GET OVER THE ASCIZ
1610 014252 000423        .ASCIZ <15><12>/POWER, AND ON CYLINDER LAMPS LIGHT./
1611          ;;71$:
1612 014322          TYPE 73$       ;;TYPE ASCIZ STRING
1613 014322 104401 014330   BR 72$         ;;GET OVER THE ASCIZ
1614 014326 000425        .ASCIZ <15><12>/MAKE DRIVE WRITE ENABLE PRESS CONTINUE/
1615          ;;73$:
1616 014402          HALT
1617 014402 000000        JSR PC,WRDCK    ;;GO WRITE 0'S, RD 0'S, CHECK
1618 014404 004737 016260   TYPE 75$       ;;TYPE ASCIZ STRING
1619 014410 104401 014416   BR 74$         ;;GET OVER THE ASCIZ
1620 014414 000430        .ASCIZ <15><12><15><12>/WRITE PROTECT THE DRIVE THEN PRESS CONTINUE/
1621          ;;75$:
1622 014476          HALT
1623 014476 000000        JSR PC,WRPRO    ;;GO TRY OVERWRITE
1624 014500 004737 016470   TYPE 77$       ;;TYPE ASCIZ STRING
1625 014504 104401 014512   BR 76$         ;;GET OVER THE ASCIZ
1626 014510 000426        .ASCIZ <15><12><15><12>/CLEAN WRITE PROTECT THEN PRESS CONTINUE/
1627          ;;77$:
1628 014556          HALT
1629 014566 000000        JSR PC,WRDCK    ;;GO WRITE 0'S, RD 0'S, CHECK
1630 014570 004737 016260   MOV 200SKTMP,2RKDA ;;SET UP DRIVE
1631 014574 013777 001352 164574   MOV 217,2RKCS    ;;FUNCTION WRITE PROTECT
1632 014602 012777 000017 164560   JSR PC,SMTME     ;;GO WAIT TIME FOR RK11-C
1633 014610 004737 005614   TSTB 2RKCS      ;;IS CONTROL READY SET
1634 014614 105777 164550   BPL 1$          ;;IF NO, BRANCH
1635 014620 100375        JSR PC,WRPRO    ;;GO TRY OVERWRITE OF IERO'S
1636 014622 004737 016470   PRTTWO:
1637 014626          TYPE 65$       ;;TYPE ASCIZ STRING
1638 014626 104401 014634   BR 64$         ;;GET OVER THE ASCIZ
1639 014632 000431        .ASCIZ <15><12><15><12>/CAUTION! TRY TO OPEN THE DOOR, DO NOT FORCE:/
1640          ;;65$:
1641 014716          TYPE 67$       ;;TYPE ASCIZ STRING
1642 014716 104401 014724   BR 66$         ;;GET OVER THE ASCIZ
1643 014722 000414        .ASCIZ <15><12>/DOOR SHOULD NOT OPEN!/
1644          ;;67$:
1645 014754          TYPE 69$       ;;TYPE ASCIZ STRING
1646 014754 104401 014762   BR 68$         ;;GET OVER THE ASCIZ
1647 014760 000420        .ASCIZ <15><12>/PRESS CONTINUE WHEN FINISHED/
1648          ;;69$:
1649 015022          HALT
1650 015022 000000        TYPE 71$       ;;TYPE ASCIZ STRING
1651 015024 104401 015032   BR 70$         ;;GET OVER THE ASCIZ
1652 015030 000426        .ASCIZ <15><12><15><12>/PUT DRIVE IN LOAD, WAIT FOR LOAD LIGHT.
1653          ;;71$:
1654 015106          TYPE 73$       ;;TYPE ASCIZ S'RING
1655 015106 104401 015114   BR 72$         ;;GET OVER THE ASCIZ
1656 015112 000420
    
```

```

1658 015154          72S: HALT
1659 015154          MOV      2#DSKTMP,DRKDA      ;SET UP DISK ADDRESS
1660 015156 015170 001352 164212      MOV      #15,DRKCS          ;ISSUE A DRIVE RESET
1661 015164 012777 000015 164176      JSR      PC,SMTIME          ;KILL TIME FOR RK11-C
1662 015172 004737 005614          TSTB    DRKCS              ;CONTROL READY SET?
1663 015176 105777 164166          BPL     1S                  ;IF NO, BRANCH
1664 015200 100375          BIT     #100200,DRKER      ;DRE SET
1665 015204 032777 100200 164154      BNE     2S                  ;IF YES BRANCH
1666 015212 001057          TYPE    75S                ;TYPE ASCIZ STRING
1667 015214 104401 015222          BR      74S                ;GET OVER THE ASCIZ
1668 015220 000427          ;:75S: .ASCIZ <15><12>/DRE=BIT15 OF RKER DID NOT SET IF AN RK11-C/
1669          74S:
1670 015300          TYPE    77S                ;:TYPE ASCIZ STRING
1671 015300 104401 015306          BR      76S                ;:GET OVER THE ASCIZ
1672 015304 000422          ;:77S: .ASCIZ <15><12>/OR BIT0 DID NOT SET IF AN RK11-D/
1673          76S:
1674 015352          BIT     #140000,DRKCS      ;DID HARD ERROR ON ERROR SET
1675 015352 032777 140000 164010      BNE     3S                  ;BRANCH IF YES
1676 015360 001015          TYPE    79S                ;:TYPE ASCIZ STRING
1677 015362 104401 015370          BR      78S                ;:GET OVER THE ASCIZ
1678 015366 000412          ;:79S: .ASCIZ <15><12>/ERROR DID NOT SET/
1679          78S:
1680 015414          MOV     #1,DRKCS           ;ISSUE A CONTROL RESET
1681 015414 012777 000001 163746      JSR     PC,SMTIME          ;WAST TIME
1682 015422 004737 005614          TSTB    DRKCS              ;CONTROL READY SET
1683 015426 105777 163736          BPL     4S                  ;IF NO, BRANCH
1684 015432 100375          BIT     #BIT15,DRKER      ;DRE CLEAR
1685 015434 032777 100000 163724      BEQ     5S                  ;IF YES BRANCH
1686 015442 001425          TYPE    81S                ;:TYPE ASCIZ STRING
1687 015444 104401 015452          BR      80S                ;:GET OVER THE ASCIZ
1688 015450 000422          ;:81S: .ASCIZ <15><12>/CONTROL RESET DID NOT CLEAR 'DRE'/
1689          80S:
1690 015516          BIT     #140000,DRKCS      ;ERROR BITS CLEAR
1691 015516 032777 140000 163644      BEQ     X                    ;IF YES BRANCH
1692 015524 001431          TYPE    83S                ;:TYPE ASCIZ STRING
1693 015526 104401 015534          BR      82S                ;:GET OVER THE ASCIZ
1694 015532 000426          ;:83S: .ASCIZ <15><12>/CONTROL RESET DID NOT CLEAR 'ERROR', RKCS/
1695          82S:
1696 015610          X:
1697 015610          TYPE    65S                ;:TYPE ASCIZ STRING
1698 015610 104401 015616          BR      64S                ;:GET OVER THE ASCIZ
1699 015614 000422          ;:65S: .ASCIZ <15><12><15><12>/OPEN THE DOOR, PUT DRIVE IN RUN/
1700          64S:
1701 015662          TYPE    67S                ;:TYPE ASCIZ STRING
1702 015662 104401 015670          BR      66S                ;:GET OVER THE ASCIZ
1703 015666 000425          ;:67S: .ASCIZ <15><12>/CAUTION! IF RUN LIGHT ON ERROR! DEPRESS/
1704          66S:
1705 015742          TYPE    69S                ;:TYPE ASCIZ STRING
1706 015742 104401 015750          BR      68S                ;:GET OVER THE ASCIZ
1707 015746 000426          ;:69S: .ASCIZ <15><12>/LOAD IMMEDIATELY, CONTINUE WHEN FINISHED/
1708          68S:
1709 016024          XX: HALT
1710 016024 000000          TYPE    65S                ;:TYPE ASCIZ STRING
1711 016026 104401 016034          BR      64S                ;:GET OVER THE ASCIZ
1712 016032 000422

```

```

1714 016100
1715 016100 104401 016106
1716 016104 000423
1717
1718 016154
1719 016154 104401 016162
1720 016160 000423
1721
1722 016230
1723 016230 104401 016236
1724 016234 000407
1725
1726 016254
1727 016254 000137 001440
1728 016260 005037 001362
1729 016264 013777 001352 163104
1730 016272 012777 000001 163070
1731 016300 004737 005614
1732 016304 105777 163060
1733 016310 100375
1734 016312 013777 001352 163056
1735 016320 012777 001362 163046
1736 016326 013777 001344 163036
1737 016334 013777 001354 163026
1738 016342 004737 005614
1739 016346 105777 163016
1740 016352 100375
1741 016354 013777 001352 163014
1742 016362 012777 007356 163004
1743 016370 013777 001344 162774
1744 016376 013777 001356 162764
1745 016404 004737 005614
1746 016410 105777 162754
1747 016414 100375
1748 016416 012704 007356
1749 016422 005005
1750 016424 020524
1751 016426 001414
1752 016430 104401 016436
1753 016434 000410
1754
1755 016456
1756 016456 000700
1757 016460 022704 010356
1758 016464 001357
1759 016466 000207
1760 016470 032777 000040 162666
1761 016476 001021
1762 016500 104401 016506
1763 016504 000416
1764
1765 016542
1766 016542 012737 177777 001362
1767 016550 013777 001352 162620
1768 016556 012777 001362 162610

64S:
TYPE 67S ;:TYPE ASCIZ STRING
BR 66S ;:GET OVER THE ASCIZ
;:67S: .ASCIZ <15><12>/PUT DRIVE IN RUN, DRIVE SHOULD NOT/
66S:
TYPE 69S ;:TYPE ASCIZ STRING
BR 68S ;:GET OVER THE ASCIZ
;:69S: .ASCIZ <15><12>/RUN...INTERLOCKS HAVE BEEN CHECKED/
68S:
TYPE 71S ;:TYPE ASCIZ STRING
BR 70S ;:GET OVER THE ASCIZ
;:71S: .ASCIZ <15><12>/DONE!
70S:
WRRDCK: JMP 2#START
CLR 2#PATTRN ;:MAKE A PATTERN OF ZERO'S
MOV 2#DSKTMP,2#RKDA ;:SET UP DRIVE ADDRESS
MOV #1,2#RKCS ;:ISSUE A CONTROL RESET
JSR PC,SMTME
5S: TSTB 2#RKCS ;:CONTROL READY SET
BPL 5S ;:IF NO BRANCH
MOV 2#DSKTMP,2#RKDA ;:SET UP DRIVE ADDRESS
MOV #PATTRN,2#RKBA ;:GET BUSS ADDRESS
MOV 2#SECCNT,2#RKWC ;:WORD COUNT 1 SECTOR
MOV 2#WAITCS,2#RKCS ;:IBA + WRITE + GO
JSR PC,SMTME ;:KILL TIME FOR RK11-C
1S: TSTB 2#RKCS ;:CONTROL READY SET
BPL 1S ;:IF NO BRANCH
MOV 2#DSKTMP,2#RKDA ;:SET UP RK REGISTERS
MOV #RDBUFF,2#RKBA ;:TO READ ONE SECTOR
MOV 2#SECCNT,2#RKWC ;:TO THE READ BUFFER
MOV 2#READCS,2#RKCS
JSR PC,SMTME ;:KILL TIME FOR RK11-C
2S: TSTB 2#RKCS ;:CONTROL READY SET
BPL 2S ;:IF NO BRANCH
MOV #RDBUFF,R4 ;:GET BUFFER TO R4
CLR R5 ;:SET UP TO COMPARE
3S: CMP R5,(R4)+ ;:FOR ZERO'S
BEQ 4S ;:IF OK, BRANCH
TYPE 65S ;:TYPE ASCIZ STRING
BR 64S ;:GET OVER THE ASCIZ
;:65S: .ASCIZ <15><12>/WRITE FAILED/
64S:
BR WRRDCK ;:GO BACK TRY AGAIN
4S: CMP #MANSEL,R4 ;:DONE ALL CHECKS
BNE 3S ;:IF NO BRANCH
RTS PC ;:IF YES, RETURN
WRPRO: BIT #BITS,2#RKDS ;:BIT 5 ON
BNE 1S ;:IF YES, BRANCH
TYPE 65S ;:TYPE ASCIZ STRING
BR 64S ;:GET OVER THE ASCIZ
;:65S: .ASCIZ <15><12>/WPS=BITS OF RKDS NOT SET/
64S:
1S: MOV #177777,2#PATTRN ;:GO LOAD ALL
MOV 2#DSKTMP,2#RKDA ;:RK REGISTERS
MOV #PATTRN,2#RKBA ;:TO WRITE

```

```

1770 016572 013777 001354 162570      MOV      2#WRITCS,2RKCS  :OVER THE ZERO'S
1771 016600 004737 005614      JSR      PC,SMTME      :KILL TIME FOR RK11-C
1772 016604 105777 162560      2S:     TSTB     2RKCS    :CONTROL READY SET?
1773 016610 100375      BPL     2S             :IF NO BRANCH
1774 016612 032777 020000 162546      BIT     #BIT13,2RKER   :WLO BIT SET
1775 016620 001032      BNE     3S             :IF YES BRANCH
1776 016622 104401 016630      TYPE   67S           :TYPE ASCIZ STRING
1777 016626 000427      BR      66S           :GET OVER THE ASCIZ
1778      :67S: .ASCIZ <15><12>/EXPECTED WLO=BIT13 OF RKER BUT DID NOT SET/
1779 016706 66S:
1780 016706 012777 000001 162454      3S:     MOV      #1,2RKCS  :DO A CONTROL RESET
1781 016714 004737 005614      JSR      PC,SMTME      :KILL TIME FOR RK11-C
1782 016720 105777 162444      4S:     TSTB     2RKCS    :CONTROL READY SET?
1783 016724 100375      BPL     4S             :IF NO BRANCH
1784 016726 032777 020000 162432      BIT     #BIT13,2RKER   :WLO BIT CLEAR
1785 016734 001431      BEQ     RDCHKD        :IF YES BRANCH
1786 016736 104401 016744      TYPE   69S           :TYPE ASCIZ STRING
1787 016742 000426      BR      68S           :GET OVER THE ASCIZ
1788      :69S: .ASCIZ <15><12>/CONTROL RESET DID NOT CLEAR 'WLO' OF RKER/
1789 017020 68S:
1790 017020 013777 001352 162350      RDCHKD: MOV      2#DSKTMP,2RKDA  :SET UP RK REGISTERS
1791 017026 012777 007356 162340      MOV      #ROBUFF,2RKBA  :TO READ SECTOR 0,
1792 017034 013777 001344 162330      MOV      2#SECCNT,2RKWC  :CYLINDER 0, HEAD 0
1793 017042 013777 001356 162320      MOV      2#REACCS,2RKCS  :TO ENSURE NO WRITE TOOK PLACE
1794 017050 004737 005614      JSR      PC,SMTME      :KILL TIME
1795 017054 105777 162310      3S:     TSTB     2RKCS    :
1796 017060 100375      BPL     3S             :
1797 017062 012703 000005      MOV      #5,R3          :CHECK TO INSURE NO WRITE
1798 017066 012704 007356      MOV      #ROBUFF,R4     :TOOK PLACE
1799 017072 005005      CLR     R5              :WITH WRITE LOCK
1800 017074 020524      1S:     CMP     R5,(R4)+      :
1801 017076 001474      BEQ     2S              :
1802 017100 005303      DEC     R3              :DEC THE ERROR COUNT
1803 017102 001475      BEQ     4S              :IF ZERO BRANCH
1804 017104 104401 017112      TYPE   65S           :TYPE ASCIZ STRING
1805 017110 000422      BR      64S           :GET OVER THE ASCIZ
1806      :65S: .ASCIZ <15><12>/WRITE OCCURRED WITH WRITE PROTECT/
1807 017156 64S:
1808 017156 005744      TST     -(R4)           :
1809 017160 104401 017166      TYPE   67S           :TYPE ASCIZ STRING
1810 017164 000410      BR      66S           :GET OVER THE ASCIZ
1811      :67S: .ASCIZ <15><12>/BUFFER ADDR=/
1812 017206 66S:
1813 017206 010446      MOV     R4,-(SP)        :
1814 017210 104403      TYPOS   6              :
1815 017212 006      .BYTE  1              :
1816 017213 001      .BYTE  1              :
1817 017214 104401 017222      TYPE   69S           :TYPE ASCIZ S'RING
1818 017220 000406      BR      68S           :GET OVER THE ASCIZ
1819      :69S: .ASCIZ / EXPCTD=/
1820 017236 68S:
1821 017236 010546      MOV     R5,-(SP)        :
1822 017240 104404      TYPOS   7              :
1823 017242 104401 017250      TYPE   71S           :TYPE ASCIZ STRING
1824 017246 000406      BR      70S           :GET OVER THE ASCIZ

```

1826 017264  
1827 017264 012446  
1828 017266 104404  
1829 017270 022704 010356  
1830 017274 001277  
1831 017276 000207  
1832  
1833  
1834

705: MOV (R4)+, -(SP)  
TYPON  
25: CMP #MANSEL, R4 ;FINISHED ALL CHECKS  
BNE IS ;IF NO BRANCH  
45: RTS PC ;RETURN

;THE FOLLOWING REVISION WAS MADE BY JIM KAPADIA

.SBTTL CONTROL PANEL TEST # 2

;THIS IS THE ENTRY POINT INTO CONTROL PANEL TEST #2. ALL  
 ;THE DRIVES THAT ARE PRESENT AND IN 'RDY' CONDITION ARE  
 ;REPORTED (ON LINE).

```

1836
1837
1838
1839
1840
1841
1842
1843
1844 017300 000240
1845 017302 012777 000001 162060
1846 017310 105777 162054
1847 017314 100375
1848 017316 012700 020614
1849 017322 005001
1850 017324 005002
1851
1852 017326 010210
1853 017330 010277 162042
1854 017334 105777 162024
1855 017340 100021
1856
1857 017342 104401 020450
1858 017346 010146
1859 017350 104402
1860 017352 104401 020461
1861 017356 052710 000300
1862
1863
1864 017362 012777 000015 162000
1865 017370 004737 005614
1866 017374 032777 000100 161762
1867 017402 001774
1868
1869 017404 005720
1870 017406 005201
1871 017410 062702 020000
1872 017414 001344
1873
1874 017416 104401 001161
1875
1876
1877
1878
1879
1880
1881 017422 012700 020614
1882 017426 005001
1883
1884 017430 011077 161742
1885 017434 042777 017777 161734
1886 017442 105777 161716
1887 017446 100044
1888
1889 017450 105710
1890 017452 100454
    
```

```

SECT. 4: NOP
          MOV      #1, DRKCS
3$:      TSTB     DRKCS
          BPL      3$
          MOV      #DRIVO, R0
          CLR      R1
          CLR      R2

1$:      MOV      R2, (R0)          ;SET UP ADDRESS TABLE
          MOV      R2, DRKDA       ;ADDRESS THE DRIVE
          TSTB     DRKDS           ;IS IT PRESENT?
          BPL      2$             ;NO

          TYPE     EM1             ;TYPE 'DRIVE'
          MOV      R1, -(SP)       ;TYPE OUT DRIVE #
          TYPOC
          TYPE     EM2             ;TYPE 'ON LINE'
          BIS      #BIT6+BIT7, (R0);SET BITS INDICATING THIS
          ;DRIVE PRESENT

          MOV      #15, DRKCS      ;ISSUE A DRIVE RESET
          JSR      PC, SMTME       ;ALLOW SOME TIME
4$:      BIT      #RWS, DRKDS     ;WAIT FOR RWS RDY
          BEQ     4$

2$:      TST      (R0)+
          INC      R1
          ADD      #20000, R2      ;NXT DRIVE
          BNE     1$             ;ALL DONE?

          TYPE     , $CRLF

;THIS CODE CHECKS THE CONDITION OF 'DRY' BIT IN RKDS FOR EVERY
;DRIVE. IF 'DRY' IS SET DRIVE IS SAID TO BE 'ON LINE', OTHERWISE IT
;IS OFFLINE. IF THE 'DRY' BIT HAS CHANGED FROM LAST TIME, THEN
;IT IS REPORTED. IF THERE IS NO CHANGE NOTHING IS REPORTED.

BEGCT:   MOV      #DRIVO, R0      ;INITIALIZE POINTERS
          CLR      R1

BEGCT1:  MOV      (R0), DRKDA      ;ADDRESS A DRIVE
          BIC      #17777, DRKDA  ;MASK OUT NON DR# BITS
          TSTB     DRKDS           ;IS THIS DRIVE ON LINE?
          BPL      1$             ;NO
          ;YES
          TSTB     (R0)           ;WAS IT 'ON LINE' LAST TIME?
          BMI     NXT1           ;YES, NO MESSAGE TO REPORT
    
```

```

1892 017460 104401 020450          TYPE      EM1          ;LINE, REPORT MESSAGE
1893 017464 010146          MOV        R1,-(SP)
1894 017466 104402          TYPOC
1895 017470 104401 020461          TYPE      EM2          ;TYPE 'ON LINE'
1896 017474 032777 000040 161662          BIT        #WPS,DRKDS  ;WRITE ENABLED?
1897 017502 001417          BEQ        2$          ;YES, OK
1898 017504 104401 017512          TYPE      65$         ;TYPE ASCIZ STRING
1899 017510 000414          BR         64$         ;GET OVER THE ASCIZ
1900                                ;65$: .ASCIZ <15><12>/EROR,NOT WRT ENABLED/
1901 017542                                ;64$:
1902 017542 012777 000017 161620          MOV        #17,DRKCS  ;WRITE PROT THE DISK
1903 017550 105777 161614          TSTB      DRKCS
1904 017554 100375          BPL        3$
1905 017556 000412          BR         NXT1
1906
1907 017560 105710          1$: TSTB      (R0)      ;WAS THIS DRIVE OFF LINE LAST
1908 017562 100010          BPL        NXT1      ;TIME? BRANCH IF YES
1909 017564 104401 020450          TYPE      EM1          ;IF NOT, REPORT THE CHANGE
1910 017570 010146          MOV        R1,-(SP)  ;TYPE DRIVE #
1911 017572 104402          TYPOC
1912 017574 104401 020473          TYPE      EM3          ;TYPE 'OFF LINE'
1913 017600 042710 000200          BIC        #BIT7,(R0) ;CLEAR BIT TO INDICATE THIS
1914                                ;DRIVE 'OFF LINE'
1915
1916                                ;THIS CODE CHECKS 'WPS' BIT FOR EVERY DRIVE THAT IS IN 'DRY'
1917                                ;CONDITION (ON LINE). IT REPORTS ANY CHANGE IN THE CONDITION OF
1918                                ;THE 'WPS' BIT. IF THERE WAS NO CHANGE FROM LAST TIME NOTHING
1919                                ;IS REPORTED. AT THE TIME OF ENTRY R0 POINTS TO DRIVE FLAG.
1920
1921 017604 105777 161554          NXT1: TSTB      DRKDS  ;IS THIS DRIVE PRESENT?
1922                                ;RKDA CONTAINS THE DRV #
1923 017610 100033          BPL        NXT2      ;NO, SKIP CHECKING
1924
1925 017612 032777 000040 161544          BIT        #WPS,DRKDS ;WPS BIT SET?
1926 017620 001014          BNE        1$        ;YES
1927                                ;WPS BIT CLEAR
1928 017622 032710 000004          BIT        #BIT2,(R0) ;WAS IT CLR LAST TIME ALSO?
1929 017626 001424          BEQ        NXT2      ;YES, NOTHING TO REPORT.
1930                                ;WPS CHANGED FROM 'SET'
1931 017630 104401 020450          TYPE      EM1          ;TO 'CLR', REPORT IT
1932 017634 010146          MOV        R1,-(SP)  ;TYPE DRIVE #
1933 017636 104402          TYPOC
1934 017640 042710 000004          BIC        #BIT2,(R0) ;INDICATE THAT 'WPS' IS CLEAR
1935 017644 104401 020521          TYPE      EM5          ;TYPE 'WPS CLEAR'
1936 017650 000413          BR         NXT2
1937                                ;WPS BIT IS SET
1938 017652 032710 000004          1$: BIT        #BIT2,(R0) ;WAS IT SET LAST TIME ALSO?
1939 017656 001010          BNE        NXT2      ;YES, NOTHING TO REPORT.
1940                                ;WPS CHANGED FROM 'CLR' TO
1941                                ;'SET', REPORT THIS CHANGE
1942 017660 104401 020450          TYPE      EM1          ;TYPE 'DRIVE'
1943 017664 010146          MOV        R1,-(SP)  ;TYPE DRIVE #
1944 017666 104402          TYPOC
1945 017670 104401 020506          TYPE      EM4          ;TYPE 'WPS SET'
1946 017674 052710 000004          BIS        #BIT2,(R0) ;SET FLAG BIT INDICATING WPS SET
    
```

```

1948      ; THIS CODE PERFORMS A SEEK FUNCTION ON A DRIVE AND CHECKS IF
1949      ; THE 'DPL' BIT SET AS A RESULT, (IF THE POWER WAS CUT OFF
1950      ; FROM THE DRIVE). NOTE THAT ONLY THOSE DRIVES ARE
1951      ; CHECKED WHICH WERE FOUND TO BE PRESENT AT BEGINNING (WHEN
1952      ; THIS TEST WAS ENTERED). SEEK IS DONE TO CYLINDER 1.
1953      ; AT THE TIME OF ENTRY RD POINTS TO THE DRIVE FLAG.
1954
1955 017700 032710 000100      NXT2:  BIT      #BIT6,(RD)      ; WAS THIS DRIVE PRESENT AT BEGNG
1956 017704 001403              BEQ      4$              ; NO
1957 017706 105777 161452      TSTB    DRKDS           ; IS IT PRESENT NOW?
1958 017712 100402              BMI      3$              ; YES
1959 017714 000137 020352      4$:    JMP      DN1DRV    ; IF NOT SKIP THIS CHECK
1960
1961 017720 052777 000040 161450 3$:    BIS      #40,DRKDA    ; RKDA ALREADY HAS THE DRV #
1962                                ; SET CYL 1 ADDRESS
1963 017726 012777 000011 161434  MOV      #11,DRKCS     ; SEEK, GO
1964
1965 017734 105777 161430      1$:    TSTB    DRKCS     ; WAIT FOR CONTROL RDY?
1966 017740 100375              BPL      1$              ; SOMETHING WRONG IF CNTAL RDY
1967                                ; DOES NOT COME BACK
1968 017742 032777 010000 161414  BIT      #DPL,DRKDS    ; DPL BIT SET?
1969 017750 001414              BEQ      2$              ; NO
1970                                ; YES, DPL SET
1971 017752 032710 000001      BIT      #BIT0,(RD)    ; WAS 'DPL' SET LAST TIME ALSO?
1972 017756 001167              BNE      CLRDPCL        ; YES, NOTHING TO REPORT.
1973                                ; DPL CHANGED, GOT SET THIS
1974 017760 104401 020450      TYPE    EM1            ; TIME, REPORT IT
1975 017764 010146              MOV      R1,-(SP)
1976 017766 104402              TYPOC
1977 017770 104401 020537      TYPE    EM6            ; TYPE 'POWER LO'
1978 017774 052710 000001      BIS      #BIT0,(RD)    ; SET FLAG BIT INDICATING THAT
1979                                ; DPL SET THIS TIME
1980 020000 000556              BR       CLRDPCL
1981
1982 020002 032710 000001      2$:    BIT      #BIT0,(RD) ; 'DPL' BIT IS CLEAR
1983 020006 001410              BEQ      WATSK          ; WAS 'DPL' CLEAR LAST TIME ALSO?
1984                                ; YES, NOTHING TO REPORT
1985 020010 104401 020450      TYPE    EM1            ; REPORT THAT 'DPL' BIT CHANGED,
1986 020014 010146              MOV      R1,-(SP)      ; FROM SET TO CLEAR
1987 020016 104402              TYPOC
1988 020020 104401 020560      TYPE    EM7            ; TYPE 'POWER UP'
1989 020024 042710 000001      BIC      #BIT0,(RD)    ; SET FLAG BIT INDICATING THAT DPL
1990                                ; IS CLEAR THIS TIME
1991
1992      ; THIS CODE WAITS FOR THE SEEK (DONE ABOVE) TO FINISH. WAITING
1993      ; TIME IS APPROX. 50 MS (FOR THE WORST CASE). IF R/W/S RDY
1994      ; DOES NOT SET WITHIN 50 MS, THEN IT IS ASSUMED THAT A 'SIN'
1995      ; IS POSSIBLE AND THE PROGRAM WAITS FOR 1450 MS MORE, SO THAT
1996      ; THE 'SIN' CAN SET. IF 'SIN' DOES NOT SET WITHIN THIS
1997      ; TIME AN ERROR IS REPORTED:
1998      ; SIN DIDN'T OCCUR
1999      ; IF R/W/S RDY SETS WITHIN 50 MS THE PROGRAM PROCEEDS TO
2000      ; CHECK THE NEXT DRIVE.
2001
2002 020030 012705 164220      WATSK: MOV      #-6000.,R5 ; SET COUNT TO WAIT FOR

```

```

2004 020034 032777 000100 161322 1$: BIT #RWS,ARKDS ;R/W/S. RDY SET?
2005 020042 001042 BNE 3$ ;YES
2006 020044 005205 INC R5 ;WAIT
2007 020046 001372 BNE 1$
2008 ;50 MS OVER, R/W/S RDY
2009 ;DIDN'T SET. WAIT FOR
2010 ;SIN TO SET.
2011 020050 005004 CLR R4
2012 020052 012705 177777 MOV #177777,R5 ;SET UP COUNT
2013 020056 032777 001000 161300 2$: BIT #SIN,ARKDS ;SIN SET?
2014 020064 001045 BNE SIN$ ;YES
2015 020066 005305 DEC R5 ;WAIT
2016 020070 001372 BNE 2$
2017 020072 005704 TST R4
2018 020074 001002 BNE 4$
2019 020076 005204 INC R4
2020 020100 000766 BR 2$
2021 ;1500 MS ELAPSED, BUT SIN
2022 ;DIDN'T SET. ERROR!
2023 020102 4$:
2024 020102 104401 020110 TYPE 65$ ;TYPE ASCIZ STRING
2025 020106 000415 BR 64$ ;GET OVER THE ASCIZ
2026 ;65$: .ASCIZ <15><12>/SIN DIDN'T OCCUR, DRIVE/
2027 64$:
2028 020142 MOV R1,-(SP) ;TYPE DRIVE #
2029 020144 104402 TYPOC
2030 020146 000501 BR DN1DRV
2031 020150 032710 000002 3$: BIT #BIT1,(R0) ;DID R/W/S RDY SET LAST TIME?
2032 020154 001476 BEQ DN1DRV ;YES
2033 020156 042710 000002 BIC #BIT1,(R0) ;CLR FLAG INDICATING THAT SEEK IS OK
2034 020162 104401 020450 TYPE EM1 ;REPORT THAT SEEK IS OK
2035 020166 010146 MOV R1,-(SP)
2036 020170 104402 TYPOC
2037 020172 104401 020601 TYPE EM9
2038 020176 000465 BR DN1DRV
2039
2040 ;IF SIN SET, DO DRIVE RESET AND CLEAR IT
2041
2042 020200 032710 000002 SIN$: BIT #BIT1,(R0) ;DID 'SIN' SET LAST TIME ALSO?
2043 020204 001010 BNE 4$ ;YES, NOTHING TO REPORT
2044 020206 052710 000002 BIS #BIT1,(R0) ;SET FLAG INDICATING THAT
2045 020212 104401 020450 TYPE EM1 ;'SIN' SET, AND REPORT THE CHANGE
2046 020216 010146 MOV R1,-(SP)
2047 020220 104402 TYPOC
2048 020222 104401 020573 TYPE ,EMB ;TYPE 'SIN'
2049
2050 020226 017705 161144 4$: MOV ARKDA,R5 ;SAVE ARKDA
2051 020232 012777 000001 161130 MOV #1,ARKCS ;DO CONTROL RESET
2052 020240 105777 161124 1$: TSTB ARKCS ;WAIT FOR CONTROL RDY
2053 020244 100375 BPL 1$
2054 020246 010577 161124 MOV R5,ARKDA
2055 020252 012777 000015 161110 MOV #15,ARKCS ;DO DRIVE RESET. ARKDA
2056 ;ALREADY HAS THE DRIVE #
2057 020260 105777 161104 2$: TSTB ARKCS ;WAIT FOR CNTRL RDY
2058 020264 100375 BPL 2$

```

```

2060 020270 032777 000100 161066 3$: BIT #RWS,DRKDS ;R/W/S SET?
2061 020276 001C25 BNE DNIDRV ;YES
2062 020300 005205 INC R5
2063 020302 001372 BNE 3$ ;WAIT FOR R/W/S RDY
2064 ;REPORT ERROR. R/W/S RDY CLR
2065 020304 104401 020312 TYPE 65$ ;TYPE ASCIZ STRING
2066 020310 000411 BR 64$ ;GET OVER THE ASCIZ
2067 ;65$: .ASCIZ <15><12>/RWS RDY NOT SET/
2068 64$:
2069
2070 020334 000406 BR DNIDRV
2071
2072 ;IF DPL SET CLEAR THE ERROR BY DOING CONTROL RESET.
2073
2074 020336 012777 000001 161024 CLRDPL: MOV #1,DRKCS ;CONTROL RESET
2075 020344 105777 161020 1$: TSTB DRKCS ;WAIT FOR CNTRL RDY
2076 7350 100375 BPL 1$
2077 ;AT THIS STAGE THE DRIVE (# IN RKDA) HAS BEEN CHECKED
2078 ;FOR DRY, WPS, DPL, & SIN. THE POINTERS ARE INCREMENTED
2079 ;AND THE SAME CHECKS WILL BE DONE ON THE NEXT
2080 ;DRIVE & THEN THE NEXT ONE & SO ON. NOTE THAT
2081 ;THIS SUB-PROGRAM KEEPS ON CYCLING THROUGH
2082 ;ALL THE DRIVES. AT THE TIME OF ENTRY (HERE)
2083 ;RD POINTS TO THE FLAG FOR THE DRIVE THAT WAS
2084 ;JUST CHECKED. BEFORE GOING ON TO THE NEXT
2085 ;DRIVE THE H DS ARE BROUGHT BACK TO CYLINDER
2086 ;0 (FOR THE NEXT CYCLE).
2087
2088 020352 011077 161020 DNIDRV: MOV (RD),DRKDA ;GET DRIVE #
2089 020356 105777 161002 TSTB DRKDS ;DRIVE PRESENT?
2090 020362 100017 BPL 3$ ;NO
2091 020364 042777 017777 161004 BIC #1777,DRKDA ;CYL ADRES = 0
2092 020372 012777 000011 160770 MOV #11,DRKCS ;GO, SEEK
2093
2094 020400 105777 160764 1$: TSTB DRKCS ;WAIT FOR CNTRL RDY
2095 020404 100375 BPL 1$
2096
2097 020406 004737 005614 JSR PC,SMTME
2098 020412 032777 000100 160744 4$: BIT #RWS,DRKDS
2099 020420 001774 BEQ 4$
2100
2101 020422 005720 3$: TST (RD)+ ;INCREMENT POINTERS TO
2102 020424 005201 INC R1 ;NEXT DRIVE
2103 020426 020127 000010 CMP R1,#10 ;ALL DONE, THIS CYCLE?
2104 020432 001402 BEQ 2$ ;YES
2105 020434 000137 017430 JMP BEGCT1 ;GO DO NEXT DRIVE
2106 020440 000137 017422 2$: JMP BEGCT ;RESTART THE CYCLE OVER
2107 ;AGAIN
2108
2109
2110
2111 020444 000000 SHFCNT: .WORD 0
2112 020446 000000 DRVCNT: .WORD 0
2113 ;MESSAGES
2114 020450 005015 051104 053111 1$: .ASCIZ <15><12>/DRIVE /

```

2116	020461	040	047440	020116	EM2:	.ASCIZ / ON LINE/
2117	020466	044514	042516	000		
2118	020473	040	047440	043106	EM3:	.ASCIZ / OFF LINE/
2119	020500	046040	047111	000105		
2120	020506	020040	051127	020124	EM4:	ASCIZ / WRT PROT/
2121	020514	051120	052117	000		
2122	020521	040	053440	052122	EM5:	.ASCIZ / WRT ENABLED/
2123	020526	042440	040516	046102		
2124	020534	042105	000			
2125	020537	040	042040	044522	EM6:	.ASCIZ / DRIVE POWER LO/
2126	020544	042526	050040	053517		
2127	020552	051105	046040	000117		
2128	020560	020040	047520	042527	EM7:	.ASCIZ / POWER UP/
2129	020566	020122	050125	000		
2130	020573	040	051440	047111	EM8:	.ASCIZ / SIN/
2131	020600	000				
2132	020601	040	051440	042505	EM9:	.ASCIZ / SEEK OK/
2133	020606	020113	045517	000		

```

;DRIVE FLAGS FOR CONTROL PANEL TEST #2
;BITS 15,14,13 GIVE THE DRIVE NO (EX: 0,1,2,---)
;BIT 7 IS SET WHEN 'DRY' BIT IS SET FOR THE DRIVE (ON LINE)
;BIT 7 IS CLEAR WHEN 'DRY' IS CLEAR (WHEN DRIVE IS IN LOAD/OFF LINE,
;DRIVE POWER IS CUT OFF)
;BIT 6 IS SET IF A DRIVE IS FOUND TO BE PRESENT (DRY) AT
;THE BEGINING. UNLIKE BIT 7 THIS BIT DOES NOT GET SET OR
;CLEARED AS THE DRIVE CONDITIONS CHANGE. IT JUST INDICATES
;THAT THE DRIVE IS AVAILABLE FOR CHECKING.
;BIT 0 IS SET IF 'DPL' BIT GETS SET, IE: DRIVE POWER OFF
;BIT 0 IS CLEARED WHEN DRIVE POWER IS ON.
;BIT 1 IS SET WHEN SEEK INCOMPLETE 'SIN' OCCURS.
;BIT 1 IS CLEAR WHEN SEEK IS OK.
;BIT 2 IS SET WHEN WRT PROT IS SET FROM CONSOLE.
;BIT 2 IS CLEARED WHEN DRIVE IS WRITE ENABLED.

```

2151		020614			.EVEN	
2152	020614	000000		DRIV0:	.WORD	0
2153	020616	000000		DRIV1:	.WORD	0
2154	020620	000000		DRIV2:	.WORD	0
2155	020622	000000		DRIV3:	.WORD	0
2156	020624	000000		DRIV4:	.WORD	0
2157	020626	000000		DRIV5:	.WORD	0
2158	020630	000000		DRIV6:	.WORD	0
2159	020632	000000		DRIV7:	.WORD	0
2160						

;DRIVE FLAGS

.SBTTL HEAD ALIGNMENT ROUTINE

2162  
2163  
2164  
2165  
2166  
2167  
2168  
2169  
2170  
2171  
2172  
2173  
2174  
2175  
2176  
2177  
2178  
2179  
2180  
2181  
2182  
2183  
2184  
2185  
2186  
2187  
2188  
2189  
2190  
2191  
2192  
2193  
2194  
2195  
2196  
2197  
2198  
2199  
2200  
2201  
2202  
2203  
2204  
2205  
2206  
2207  
2208  
2209  
2210  
2211  
2212  
2213  
2214  
2215  
2216

020634 000240  
020636 104401 020644  
020642 000426  
020720  
020720 104401 020726  
020724 000432  
021012  
021012 104401 021020  
021016 000427  
021076  
021076 104401 021532  
021102 005037 021526  
021106 104410  
021110 012601  
021112 112100  
021114 162700 000060  
021120 002766  
021122 022700 000067  
021126 002763  
021130 000241  
021132 006000  
021134 006000  
021136 006000  
021140 006000  
021142 010037 020614  
021146 112100  
021150 001412  
021152 020027 000106  
021156 001347  
021160 105711  
021162 001345  
021164 042737 020000 020614  
021172 005237 021526

```

:HEAD ALIGNMENT ROUTINE
:THIS MAINTAINANCE ROUTINE IS HELPFUL IN HEAD ALIGNMENT. UPON ENTRY
:THE QUESTION - DRIVE? - IS ASKED. THE USER SHOULD REPLY WITH THE
:DRIVE NUMBER THAT IS TO BE ALIGNED. IF THE DRIVE IS AN RK-05F
:THE LETTER 'F' IS ADDED AS A SUFFIX. FOR SELECTING SURFACE 0
:PUT SW0=0, FOR SELECTING SURFACE 1 PUT SW0=1. SET SW1 =1 TO SELECT
:CYLINDER 64. SET SW1=0 TO SELECT CYLINDER 105.
:IF THE DRIVE IS AN RK-05F, CYLINDER 64 BECOMES CYLINDER 130
:OF THE EVEN DRIVE, AND CYLINDER 105 BECOMES CYLINDER 5 OF THE ODD DRIVE
:THE HEADS ARE PLACED ON THE SELECTED CYLINDER AND DATA IS READ
:CONTINUOUSLY FROM THE CYLINDER (SECTOR 0)
:THE UPPER OR LOWER HEAD AND CYLINDER CAN BE SELECTED
:DYNAMICALLY, IE. THE PROGRAM DOES NOT HAVE TO BE STOPPED TO SELECT THE
:UPPER OR LOWER HEAD OR CYLINDER.
:IN ORDER TO SELECT ANOTHER DRIVE, PUT ANY SWITCH FROM SW2 TO SW15 UP AND
:THE PROGRAM WILL AGAIN ASK THE QUESTION (DRIVE?).

SECT.5: NOP
        TYPE      65$          ;;TYPE ASCIZ STRING
        BR        64$          ;;GET OVER THE ASCIZ
;;65$: .ASCIZ <15><12>/SET SW0=0 FOR SURFACE 0, SW0=1 FOR SUR 1./
64$:   TYPE      67$          ;;TYPE ASCIZ STRING
        BR        66$          ;;GET OVER THE ASCIZ
;;67$: .ASCIZ <15><12>/SET SW1=0 FOR CYLINDER 105, SW1=1 FOR CYLINDER 64/
66$:   TYPE      69$          ;;TYPE ASCIZ STRING
        BR        68$          ;;GET OVER THE ASCIZ
;;69$: .ASCIZ <15><12>/PUT ANY SW FROM 2-15 HI TO SELECT NEW DRIVE/
68$:   HDALGN:  TYPE      EM10          ;ASK FOR DRIVE #
        CLR      FFLAG          ;FLAG FOR RK-05F
        RDLIN          ;GET OPR INPUT
        MOV      (SP)+,R1        ;ADDR OF COMMAND STRING
        MOV      (R1)+,R0        ;FIRST CHAR
        SUB      #60,R0          ;0 TO 7
        BLT     HDALGN          ;TOO SMALL
        C:MP     #67,R0          ;MUST BE 7 OR LESS
        BLT     HDALGN          ;TOO BIG
        CLC
        ROR     R0
        ROR     R0
        ROR     R0
        ROR     R0
        MOV     R0,DRIVO        ;ADDRESS OF DRIVE
        MOV     (R1)+,R0        ;NEXT INPUT CHAR
        BEQ     $$              ;ALL DONE IF C.R.
        CMP     R0,#'F          ;IS IT F?
        BNE     HDALGN          ;NO, SO ERROR
        TSTB   (R1)            ;NEXT CHAR MUST BE C.R.
        BNE     HDALGN          ;ELSE ERROR
        BIC    #BIT13,DRIVO     ;USE EVEN DRIVE IF R' 05F
        INC    FFLAG          ;SHOW F TYPE DRIVE
    
```

2218	021202	022737	000176	001140	CMP	#SWREG,SWR	:SOFTWARE SWITCH REGISTER IN USE?
2219	021210	001002			BNE	15\$	:BR IF NOT
2220	021212	104405			GTSWR		:REQUEST NEW CONTENTS FOR SWITCH REG
2221	021214	000401			BR	16\$	:CONTINUE
2222	021216	000000			HALT		:WAIT FOR OPERATOR TO ENTER NEW SWR VALUE
2223	021220	017737	157714	021530	16\$:	MOV	:#SWR,SWTCH
2224	021226	042737	177775	021530	16\$:	BIC	:#177775,SWTCH
2225	021234	001005			BNE	7\$	:WANT SWI ONLY
2226	021236	005737	021526		TST	FFLAG	:SWI SET, SO LOW CYLINDER
2227	021242	001402			BEQ	7\$	:F DRIVE?
2228	021244	052700	020000		BIS	#BIT13,RO	:NO
2229	021250	10077	160122		7\$:	MOV	:#ODD DRIVE IF HIGH TRACK OF F
2230	021254	102777	000017	160106	7\$:	MOV	:RO,#ARKDA
2231	021262	105777	160102		8\$:	TSTB	:#17,ARKCS
2232	021266	100375			BPL	8\$	:WRITE PROTECT
2233	021270	012777	000001	160072		MOV	:#1,ARKCS
2234	021276	105777	160016		9\$:	TSTB	:ARKCS
2235	021302	100375			BPL	9\$	:WAIT FOR DRIVE READY
2236	021304	005737	021526		TST	FFLAG	:RESET CONTROLLER
2237	021310	001410			BEQ	13\$	:F DRIVE?
2238	021312	012701	000240		MOV	#5,*40,R1	:NO
2239	021316	005737	021530		TST	SWTCH	:TRACK 5 OF HIGH
2240	021322	001412			BEQ	10\$	:SWI SET?
2241	021324	062701	010100		ADD	#130,*40,R1	:YES SO TEST TRACK 8 OF DRIVE HIGH
2242	021330	000407			BR	10\$	:TRACK 130. IF SWI SET
2243	021332	012701	004000		10\$:	MOV	:#64,*40,R1
2244	021336	005737	021530		TST	SWTCH	:CYLINDER 64 IF NOT F
2245	021342	001002			BNE	10\$	:SWI SET?
2246	021344	062701	002440		ADD	#41,*40,R1	:YES, SO CYLINDER 64
2247	021350	005777	160014		10\$:	TST	:CYLINDER 105
2248	021354	100006			BPL	11\$	:ANY ERROR?
2249	021356	012777	000001	160004	10\$:	MOV	:NO, CONTINUE
2250	021364	105777	160000		12\$:	TSTB	:RESET
2251	021370	100375			BPL	12\$	:WAIT FOR READY
2252	021372	017702	157542		11\$:	MOV	:SWR,R2
2253	021376	042702	177775		BIC	#77775,R2	:SWITCH REG TO R2
2254	021402	020237	021530		CMP	R2,SWTCH	:SWI ONLY
2255	021406	001273			BNE	5\$	:ANY CHANGE SINCE LAST?
2256	021410	010077	157762		6\$:	MOV	:YES, GO SET-UP ADDR AGAIN
2257	021414	012777	000017	157746	6\$:	MOV	:RO,ARKDA
2258	021422	105777	157742		MOV	#17,ARKCS	:ADDRESS THE DRIVE
2259	021426	100375			TSTB	ARKCS	:WRITE PROTECT THE DRIVE
2260	021430	042700	000020		BPL	-4	:WAIT FOR CONTROL RDY
2261	021434	032777	000001	157476	4\$:	BIC	:#20,RO
2262	021442	001402			BIT	#1,SWR	:CLEAR TRACK ADDR
2263	021444	02700	000020		BEQ	2\$	:SWI SET?
2264	021450	042700	017740		2\$:	BIS	:NO TEST TRACK 0
2265	021454	050100			BIS	#20,RO	:TEST TRACK 1
2266	021456	010077	157714		BIC	#17740,RO	:CLEAR CYLINDER ADDR
2267	021462	012777	177400	157702	MOV	R1,RO	:PUT CYLINDER ADDR IN ADDR
2268	021470	012777	007356	157676	MOV	RO,ARKDA	:ADRES THE DRIVE
2269	021476	012777	000005	157664	MOV	#-400,ARKWC	:READ 1 SECTOR
2270					MOV	#RDBUFF,ARKBA	:INTO THIS BUFFER
2271	021504	105777	157660		3\$:	TSTB	:ARKCS
2272	021510	100375			BPL	3\$	:READ, GO
							:DONE?
							:NO

```

2274 021512 032777 177774 157420 BIT #177774,DSWR ;EXIT OUT?
2275 021520 001713 BEQ 10$ ;NO, CONTINUE ON THIS DRIVE
2276 021522 000137 021076 JMP HDALGN ;YES, GET NEW DRIVE
2277
2278 021526 000000 FFLAG: 0
2279 021530 000000 SWITCH: 0
2280 021532 005015 051104 053111 EM10: .ASCIZ <15><12>/DRIVE?/
2281 021540 037505 000
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328

```

.SBTTL DISK POWER FAILURE TEST

```

;(DISK)POWER FAILURE (DURING DISK WRITE) TEST
;THIS TEST CHECKS THAT THE INFORMATION WRITTEN ON THE DISK IS
;NOT DESTROYED WHEN THE DISK SENSES A LOSS OF POWER WHILE DOING A WRITE
;AND RETRACTS THE HEADS. UPON ENTRY THE PROGRAM FINDS OUT THE
;FIRST AVAILABLE DRIVE INDICATES IT (DRIVE XX) AND PROCEEDS TO TEST.
;CYLINDERS 0 TO 15 ARE WRITTEN WITH UNIQUE PATTERNS, THEN THE HEADS
;ARE POSITIONED ON CYLINDER 10 (DECIMAL) AND A MESSAGE (DROP
;POWER) IS GIVEN. AFTER RECEIVING THIS MESSAGE THE USER SHOULD
;DROP POWER FROM THE DRIVE. ON SENSING A LOSS OF POWER, THE
;PROGRAM ASKS THE USER TO PUT BACK THE POWER. THE ERRORS (DPL)
;ARE CLEARED AND A WRITE-CHECK IS PERFORMED TO CHECK IF THE
;UNIQUE PATTERNS ON THE DISK (CYLINDERS 0-9 AND 11-15) ARE STILL
;THERE. IF NOT A WRITE CHECK ERROR IS REPORTED.
.EVEN

```

```

2300 021544
2301
2302 021544 005000 SECT.6: CLR R0 ;INITIALIZE DRIVE #
2303 021546 005037 020614 CLR DRIVO
2304 021552 010077 157620 8$: MOV R0,DRKDA ;IS IT PRESENT?
2305 021556 105777 157602 TSTB DRKDS ;IF NOT SKIP
2306 021562 100406 BMI 12$
2307 021564 005237 020614 10$: INC DRIVO
2308 021570 062700 020000 ADD #20000,R0
2309 021574 001366 BNE 8$
2310 021576 000762 BR SECT.6
2311 021600 013746 020614 12$: MOV DRIVO,-(SP) ;GET DRIVE #
2312 021604 032777 000040 157552 BIT #40,DRKDS
2313 021612 001406 BEQ 9$
2314 021614 104401 022234 TYPE ,EM11
2315 021620 104402 TYPOC
2316 021622 104401 022244 TYPE EM12
2317 021626 000756 BR 10$
2318 021630 104401 020450 9$: TYPE EM1
2319 021634 013746 020614 MOV DRIVO,-(SP)
2320 021640 104402 TYPOC
2321 021642 012777 000001 157520 MOV #1,DRKCS ;CONTROL RESET
2322 021650 105777 157514 TSTB DRKCS
2323 021654 100375 BPL -4
2324 021656 005005 CLR R5 ;INITIALIZE PATTERN TO BE WRITTEN
2325 ;0 ON CYL 0, 1 ON CYL 1, ETC
2326 021660 013701 001376 MOV RKDA,R1
2327 021664 013702 001372 MOV RKWC,R2
2328 021670 013703 001374 MOV RKBA,R3

```

```

2330 021700 010011          MOV    R0,DR1
2331 021702 010537 022232 15:  MOV    R5,BUFR          ;FILL THE PATER IN DATA BUFFER.
2332 021706 012713 022232  MOV    #BUFR,DR3        ;BUS ADRES
2333 021712 012712 164000  MOV    #-14000,DR2     ;WRITE 1 CYL (256X12X2 WORDS)
2334 021716 012714 004003  MOV    #4003,DR4        ;WRITE GO, IBA SET
2335 021722 105714          TSTB   DR4              ;WAIT FOR CONTROL READY
2336 021724 100376          BPL    -2
2337
2338 021726 005205          INC    R5
2339 021730 020527 000020  CMP    R5,#20          ;WRITTEN ALL 15 CYLINDERS?
2340 021734 001362          BNE
2341
2342 021736 010005          MOV    R0,R5
2343 021740 052705 000500  BIS    #500,R5         ;DRIVE #
2344 021744 012737 000012 022232  MOV    #12,BUFR        ;CYL 10
2345 021752 010511          MOV    R5,DR1          ;PATERN TO BE WRITTEN
2346 021754 012712 164000  MOV    #-14000,DR2     ;ADRES THE DISK
2347 021760 012713 022232  MOV    #1,DR3          ;WORD COUNT= 1 CYLINDER
2348 021764 012714 004003  MOV    #4,DR4          ;BUS ADRES
2349 021770 032777 000100 157366 25:  BIT    #R0,DRKDS       ;WRITE GO, IBA
2350 021776 001774          BEQ    25              ;WAIT FOR THE HEADS TO SETTLE
2351 022000 104401 022006          TYPE   65$           ;ON CYL 10
2352 022004 000406          BR     64$           ;TYPE ASCIZ STRING
2353
2354 022022          ;:65$: .ASCIZ /DROP POWER/
2355          64$:
2356 022022 000407          BR     55
2357 022024 010511          MOV    R5,DR1
2358 022026 012712 164000  MOV    #-14000,DR2     ;ADRES THE DISK
2359 022032 012713 022232  MOV    #BUFR,DR3        ;WORD COUNT= 1 CYLINDER
2360 022036 012714 004003  MOV    #4003,DR4        ;BUS ADRES
2361 022042 105714          TSTB   DR4              ;WRITE GO, IBA
2362 022044 100376          BPL    -2              ;WAIT FOR CONTROL READY
2363 022046 005714          TST    DR4
2364
2365 022050 100365          BPL    35
2366
2367          ;IF DRIVE POWER LOSS WAS SENSED,
2368 022052 104401 022060  TYPE   67$           ;ASK TO PUT POWER ON.
2369 022056 000406          BR     66$           ;TYPE ASCIZ STRING
2370          ;:67$: .ASCIZ <15><12>/POWER ON/
2371 022074          66$:
2372 022074 105777 157264  TSTB   DRKDS          ;WAIT FOR DRIVE READY
2373 022100 100375          BPL    -4
2374 022102 012714 000001  MOV    #1,DR4          ;CONTROL RESET, CLEAR ERROR
2375 022106 105714          TSTB   DR4
2376 022110 100376          BPL    -2
2377 022112 010077 157260  MOV    R0,DRKDA
2378 022116 005005          CLR    R5
2379 022120 010537 022232 65:  MOV    R5,BUFR          ;INITIALIZE PATTERN
2380 022124 012713 022232  MOV    #BUFR,DR3
2381 022130 012712 164000  MOV    #-14000,DR2
2382 022134 012714 004007  MOV    #4007,DR4        ;WRITE CHECK, GO, IBA
2383 022140 105714          TSTB   DR4
2384 022142 100376          BPL    -2

```

```

022144 005714
022146 100023
022150 104401 022156
022154 000416
022212
022212 011146
022214 104402
022216 005203
022220 020527 000020
022224 001335
022226 000137 021564
022232 000000
022234 051104 053111 020105.
022236 000040
022240 051511 053440 044522
022244 042524 050040 047522
022260 052103 052105
022266 000040

```

```

TST BR4 ;ANY ERROR?
BPL 7$ ;NO
TYPE 69$ ;TYPE ASCIZ STRING
BR 68$ ;GET OVER THE ASCIZ
;69$: .ASCIZ <15><12>/ERROR, ON PWR-UP, RKDA=/
68$:
MOV BR1,-(SP)
TYPOC
7$: INC R5
CMP R5,#20
BNE 6$
JMP 10$

```

```

BUFR: .WORD 0
EM11: .ASCIZ /DRIVE /
EM12: .ASCIZ /IS WRITE PROTECTED /

```

.SBTTL TYPE ROUTINE

```

*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: SNUL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: SFILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: SFILLC CONTAINS THE CHARACTER TO FILL AFTER.

```

```

*CALL:
*1) USING A TRAP INSTRUCTION
* TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
* TYPE
* MESADR
*

```

```

$TYPE: TSTB $TPFLG ;IS THERE A TERMINAL?
BPL 1$ ;BR IF YES
HALT ;HALT HERE IF NO TERMINAL
BR 3$ ;LEAVE
1$: MOV RO,-(SP) ;SAVE RO
MOV 22(SP),RO ;GET ADDRESS OF ASCIZ STRING
2$: MOVB (RO)+,-(SP) ;PUSH CHARACTER TO BE TYPED ONTO STACK
BNE 4$ ;BR IF IT ISN'T THE TERMINATOR
TST (SP)+ ;IF TERMINATOR POP IT OFF THE STACK
60$: MOV (SP)+,RO ;RESTORE RO
3$: ADD #2,(SP) ;ADJUST RETURN PC
RTI ;RETURN
4$: CMPB #HT,(SP) ;BRANCH IF <HT>
BEQ 8$ ;
CMPB #CRLF,(SP) ;;BRANCH IF NOT <CRLF>

```

```

2492 022342 005726          TST      (SP)+          ;; POP <CR><LF> EQUIV
2493 022344 104401          TYPE                    ;; TYPE A CR AND LF
2494 022346 001161          SCRLF                    ;;
2495 022347 105037 022504        CLRB      $CHARCNT      ;; CLEAR CHARACTER COUNT
2496 022348 000755          BR          25          ;; GET NEXT CHARACTER
2497 022349 004737 022440        55:     JSR      PC,$TYPEC  ;; GO TYPE THIS CHARACTER
2498 022350 123726 001156        65:     CMPB    $FILLC,(SP)+  ;; IS IT TIME FOR FILLER CHARS.?
2499 022351 001350          BNE      25          ;; IF NO GO GET NEXT CHAR.
2500 022370 013746 001154        MOV      $NULL,-(SP)    ;; GET # OF FILLER CHARS. NEEDED
2501 022371 105366 000001        75:     DECIB   1(SP)     ;; AND THE NULL CHAR.
2502 022372 002770          BLT      65          ;; DOES A NULL NEED TO BE TYPED?
2503 022373 004737 022440        JSR      PC,$TYPEC  ;; BR IF NO--GO POP THE NULL OFF OF STACK
2504 022374 105337 022504        DECIB   $CHARCNT      ;; GO TYPE A NULL
2505 022375 000770          BR          75          ;; DO N T COUNT AS A COUNT
2506 022376 000770          BR          75          ;; LOOP

```

;HORIZONTAL TAB PROCESSOR

```

2507 022414 112716 000040        85:     MOVVB   #' (SP)     ;; REPLACE TAB WITH SPACE
2508 022420 004737 022440        95:     JSR      PC,$TYPEC  ;; TYPE A SPACE
2509 022421 132737 000007 022504        BITB    #'7,$CHARCNT  ;; BRANCH IF NOT AT
2510 022432 001372          BNE      95          ;; TAB STOP
2511 022433 005726          TST      (SP)+          ;; POP SPACE OFF STACK
2512 022434 000724          BR          25          ;; GET NEXT CHARACTER
2513 022436 000724          BR          25          ;; WAIT UNTIL PRINTER IS READY
2514 022440 105777 156504        $TYPEC: TSTB    2$TPS     ;;
2515 022441 100375          BPL     $TYPEC        ;;
2516 022446 116677 000002 156476        MOVVB   2(SP),2$TPB    ;; LOAD CHAR TO BE TYPED INTO DATA REG.
2517 022454 122766 000015 000002        CMPB    $CR,2(SP)     ;; IS CHARACTER A CARRIAGE RETURN?
2518 022462 001003          BNE      15          ;; BRANCH IF NO
2519 022464 105037 022504        CLRB    $CHARCNT      ;; YES--CLEAR CHARACTER COUNT
2520 022470 000406          BR      $TYPEX        ;; EXIT
2521 022472 122766 000012 000002 15:     CMPB    $LF,2(SP)     ;; IS CHARACTER A LINE FEED?
2522 022474 001402          BEQ     $TYPEX        ;; BRANCH IF YES
2523 022502 105227          INCB   (PC)+          ;; COUNT THE CHARACTER
2524 022504 000000        $CHARCNT: WORD 0      ;; CHARACTER COUNT STORAGE
2525 022506 000207        $TYPEX: RTS          PC

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

2526 022507 000000        ;; *****
2527 022508 000000        ;; *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
2528 022509 000000        ;; *OCTAL (ASCII) NUMBER AND TYPE IT.
2529 022510 000000        ;; *STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
2530 022511 000000        ;; *CALL:
2531 022512 000000        ;; *      MOV      NUM,-(SP)      ;; NUMBER TO BE TYPED
2532 022513 000000        ;; *      TYPOS                    ;; CALL FOR TYPEOUT
2533 022514 000000        ;; *      .BYTE   N                ;; N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
2534 022515 000000        ;; *      .BYTE   M                ;; M=1 OR 0
2535 022516 000000        ;; *                                ;; ;1=TYPE LEADING ZEROS
2536 022517 000000        ;; *                                ;; ;0=SUPPRESS LEADING ZEROS
2537 022518 000000        ;; *
2538 022519 000000        ;; *
2539 022520 000000        ;; *$STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
2540 022521 000000        ;; *$TYPOS OR $TYPOC
2541 022522 000000        ;; *CALL:
2542 022523 000000        ;; *      MOV      NUM,-(SP)      ;; NUMBER TO BE TYPED

```

```

2498
2499
2500
2501
2502
2503
2504 022510 017646 000000
2505 022514 116637 000001 022733
2506 022522 112637 022735
2507 022526 062716 000002
2508 022532 000406
2509 022534 112737 000001 022733
2510 022542 112737 000006 022735
2511 022550 112737 000005 022732
2512 022556 010346
2513 022560 010446
2514 022562 010546
2515 022564 113704 022735
2516 022570 005404
2517 022572 062704 000006
2518 022576 110437 022734
2519 022602 113704 022733
2520 022606 016605 000012
2521 022612 005003
2522 022614 006105
2523 022616 000404
2524 022620 006105
2525 022622 006105
2526 022624 006105
2527 022626 010503
2528 022630 006103
2529 022632 105337 022734
2530 022636 100016
2531 022640 042703 177770
2532 022644 001002
2533 022646 005704
2534 022650 001403
2535 022652 005204
2536 022654 052703 000060
2537 022660 052703 000040
2538 022664 110337 022730
2539 022670 104401 022730
2540 022674 105337 022732
2541 022700 003347
2542 022702 002402
2543 022704 005204
2544 022706 000744
2545 022710 012605
2546 022712 012604
2547 022714 012603
2548 022716 016666 000002 000004
2549 022724 012616
2550 022726 000002
2551 022730 000
2552 022731 000

```

```

: *
: *$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
: *CALL:
: *      MOV      NUM,-(SP)      ;; NUMBER TO BE TYPED
: *      TYPOC      ;; CALL FOR TYPEOUT
: *
$TYPOS: MOV      2(SP),-(SP)      ;; PICKUP THE MODE
        MOVVB    1(SP), $OFILL    ;; LOAD ZERO FILL SWITCH
        MOVVB    (SP)+, $OMODE+1  ;; NUMBER OF DIGITS TO TYPE
        ADD      #2, (SP)        ;; ADJUST RETURN ADDRESS
        BR       $TYPON
$TYPOC: MOVVB    #1, $OFILL      ;; SET THE ZERO FILL SWITCH
        MOVVB    #6, $OMODE+1    ;; SET FOR SIX(6) DIGITS
$TYPON: MOVVB    #5, $OCNT      ;; SET THE ITERATION COUNT
        MOV      R3, -(SP)       ;; SAVE R3
        MOV      R4, -(SP)       ;; SAVE R4
        MOV      R5, -(SP)       ;; SAVE R5
        MOVVB    $OMODE+1, R4    ;; GET THE NUMBER OF DIGITS TO TYPE
        NEG      R4
        ADD      #6, R4          ;; SUBTRACT IT FOR MAX. ALLOWED
        MOVVB    R4, $OMODE      ;; SAVE IT FOR USE
        MOVVB    $OFILL, R4     ;; GET THE ZERO FILL SWITCH
        MOV      12(SP), R5     ;; PICKUP THE INPUT NUMBER
        CLR      R3             ;; CLEAR THE OUTPUT WORD
        ROL     R5              ;; ROTATE MSB INTO "C"
        BR       3$            ;; GO DO MSB
2$: ROL     R5              ;; FORM THIS DIGIT
        ROL     R5
        ROL     R5
        MOV     R5, R3
3$: ROL     R3              ;; GET LSB OF THIS DIGIT
        DECB    $OMODE          ;; TYPE THIS DIGIT?
        BPL     7$             ;; BR IF NO
        BIC     #177770, R3    ;; GET RID OF JUNK
        BNE     4$            ;; TEST FOR 0
        TST     R4             ;; SUPPRESS THIS 0?
        BEQ     5$            ;; BR IF YES
        INC     R4             ;; DON'T SUPPRESS ANYMORE 0'S
        BIS     #'0, R3        ;; MAKE THIS DIGIT ASCII
        BIS     #' , R3        ;; MAKE ASCII IF NOT ALREADY
        MOVVB   R3, #5         ;; SAVE FOR TYPING
        TYPE    #5            ;; GO TYPE THIS DIGIT
        DECB    $OCNT          ;; COUNT BY 1
        BGT     2$            ;; BR IF MORE TO DO
        BLT     6$            ;; BR IF DONE
        INC     R4             ;; INSURE LAST DIGIT ISN'T A BLANK
        BR     2$            ;; GO DO THE LAST DIGIT
6$: MOV     (SP)+, R5          ;; RESTORE R5
        MOV     (SP)+, R4      ;; RESTORE R4
        MOV     (SP)+, R3      ;; RESTORE R3
        MOV     2(SP), 4(SP)   ;; SET THE STACK FOR RETURNING
        MOV     (SP)+, (SP)
        RTI
8$: .BYTE   0
        .BYTE   0

```

```

2554 022733 000 $OFILL: BYTE 0 ;; ZERO FILL SWITCH
2555 022734 000000 $OMODE: WORD 0 ;; NUMBER OF DIGITS TO TYPE
2556 .SBTTL TTY INPUT ROUTINE
2557
2558 ;*****
2559 .ENABL LSB
2560 022736 000000 $TKCNT: WORD 0 ;; NUMBER OF ITEMS IN QUEUE
2561 022740 000000 $TKQIN: WORD 0 ;; INPUT POINTER
2562 022742 000000 $TKQOUT: WORD 0 ;; OUTPUT POINTER
2563 022744 000001 $TKQSRT: BLKB 1 ;; TTY KEYBOARD QUEUE
2564 022745 $TKQEND=.
2565 022746 .EVEN
2566
2567 ;*TK INITIALIZE ROUTINE
2568 ;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
2569 ;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
2570
2571 ;*CALL:
2572 ;* JSR PC,$TKINT
2573 ;* RETURN
2574
2575 022746 C05037 022736 $TKINT: CLR $TKCNT ;; CLEAR COUNT OF ITEMS IN QUEUE
2576 022752 012737 022744 MOV $TKQSRT,$TKQIN ;; MOVE THE STARTING ADDRESS OF THE
2577 022760 013737 022740 MOV $TKQIN,$TKQOUT ;; QUEUE INTO THE INPUT & OUTPUT POINTERS.
2578 022766 012737 023016 000060 MOV $TKSRV,$TKVEC ;; INITIALIZE THE KEYBOARD VECTOR
2579 022774 012737 000200 000062 MOV #200,$TKVEC+2 ;; "BR" LEVEL 4
2580 023002 005777 156140 TST $TKB ;; CLEAR DONE FLAG
2581 023006 012777 000100 156130 MOV #100,$TKS ;; ENABLE TTY KEYBOARD INTERRUPT
2582 023014 000207 PC RTS ;; RETURN TO CALLER
2583
2584 ;*TK SERVICE ROUTINE
2585 ;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
2586 ;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
2587 ;*IT IN THE QUEUE.
2588
2589 023016 117746 15612" $TKSRV: MOVB $TKB,-(SP) ;; PICKUP THE CHARACTER
2590 023022 042716 177600 BIC #1C177,(SP) ;; STRIP THE JUNK
2591 023026 021627 000007 1$: CMP (SP),#7 ;; IS IT A CONTROL G?
2592 023032 001004 BNE 2$ ;; BRANCH IF NO
2593 023034 022737 000176 001140 CMP #SWREG,SWR ;; IS SOFT-SWR SELECTED?
2594 023042 001500 BEQ 6$ ;; GO TO SWR CHANGE
2595
2596 023044 2$: CMP #1,$TKCNT ;; IS THE QUEUE FULL?
2597 023044 022737 000001 022736 BNE 3$ ;; BRANCH IF NO
2598 023052 001004 TYPE $BELL ;; RING THE TTY BELL
2599 023054 104401 024066 TST (SP)+ ;; CLEAN CHARACTER OFF OF STACK
2600 023060 005726 5$ BR 5$ ;; EXIT
2601 023062 000451 3$: CMP (SP),#23 ;; IS IT A CONTROL-S?
2602 023064 021627 000023 BNE 32$ ;; BRANCH IF NO
2603 023070 001021 CLR $TKS ;; DISABLE TTY KEYBOARD INTERRUPTS
2604 023072 005077 156046 TST (SP)+ ;; CLEAN CHAR OFF STACK
2605 023076 005726 156040 31$: TSTB $TKS ;; WAIT FOR A CHAR
2606 023100 105777 156040 BPL 31$ ;; LOOP UNTIL ITS THERE
2607 023104 100375 31$ BPL 31$
2608 023106 117746 156034 MOVB $TKB,-(SP) ;; GET THE CHARACTER

```

```

2610 023116 022627 000021      CMP      (SP)+,#21      ;; IS IT A CONTROL-Q?
2611 023122 001366          BNE      31$          ;; BRANCH IF NO
2612 023124 012777 000100 156012  MOV      #100,$STKS   ;; REENABLE TTY KEYBOARD INTERRUPTS
2613 023132 000002          RTI          ;; RETURN
2614 023134 005237 022735 32$:  INC      $STCNT      ;; COUNT THIS CHARACTER
2615 023140 021627 000140      CMP      (SP),#140   ;; IS IT UPPER CASE?
2616 023144 002405          BLT      4$          ;; BRANCH IF YES
2617 023146 021627 000175      CMP      (SP),#175   ;; IS IT A SPECIAL CHAR?
2618 023152 003002          BGT      4$          ;; BRANCH IF YES
2619 023154 042716 000040      BIC      #40,(SP)    ;; MAKE IT UPPER CASE
2620 023160 112677 177554 4$:  MOVB    (SP)+,$STKQIN ;; AND PUT IT IN QUEUE
2621 023164 005237 022740      INC      $STKQIN    ;; UPDATE THE POINTER
2622 023170 023727 022740 022745  CMP      $STKQIN,$STKQEND ;; GO OFF THE END?
2623 023176 001003          BNE      5$          ;; BRANCH IF NO
2624 023200 012737 022744 022740  MOV      #STKQSR,$STKQIN ;; RESET THE POINTER
2625 023206 000002          RTI          ;; RETURN

```

```

*****
*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
*CALL WHEN OPERATING IN TTY INTERRUPT MODE.

```

```

2632 023210 022737 000176 001140 $CKSWR: CMP      #SWREG,$SWR   ;; IS THE SOFT-SWR SELECTED
2633 023216 001104          BNE      15$        ;; EXIT IF NOT
2634 023220 105777 155720      TSTB    $STKS      ;; IS A CHAR WAITING?
2635 023224 100101          BPL      15$        ;; IF NOT, EXIT
2636 023226 117746 155714      MOVB    $STKB,-(SP) ;; YES
2637 023232 042716 177600      BIC     #1C17,$(SP) ;; MAKE IT 7-BIT ASCII
2638 023236 021627 000007      CMP     (SP),#7    ;; IS IT A CONTROL-G?
2639 023242 001300          BNE     2$          ;; IF NOT, PUT IT IN THE TTY QUEUE
2640                                AND     EXIT

```

```

*****
*CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
*ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
*CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.

```

```

2646 023244 123727 001134 000001 6$:  CMPB    $AUTOB,#1   ;; ARE WE RUNNING IN AUTO-MODE?
2647 023252 001674          BEQ     2$          ;; BRANCH IF YES
2648 023254 005726          TST     (SP)+      ;; CLEAR CONTROL-G OFF STACK
2649 023256 004737 022746      JSR     PC,$TKINT  ;; FLUSH THE TTY INPUT QUEUE
2650 023262 005077 155656      CLR     $STKS     ;; DISABLE TTY KEYBOARD INTERRUPTS
2651 023266 112737 000001 001135  MOVB    #1,$INTAG  ;; SET INTERRUPT MODE INDICATOR
2653 023274 104401 024077      TYPE    , $CNTLG  ;; ECHO THE CONTROL-G (↑G)
2654 023300 104401 024104  $GTSWR: TYPE    $MSWR  ;; TYPE CURRENT CONTENTS
2655 023304 013746 000176      MOV     $SWREG,-(SP) ;; SAVE SWREG FOR TYPEOUT
2656 023310 104402          TYP0C  ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
2657 023312 104401 024115      TYPE    , $MNEW   ;; PROMPT FOR NEW SWR
2658 023316 005046 19$:  CLR     -(SP)      ;; CLEAR COUNTER
2659 023320 005046          CLR     -(SP)     ;; THE NEW SWR
2660 023322 105777 155616 7$:  TSTB    $STKS     ;; CHAR THERE?
2661 023326 100375          BPL     7$        ;; IF NOT TRY AGAIN
2663 023330 117746 155612      MOVB    $STKB,-(SP) ;; PICK UP CHAR
2664 023334 042716 177600      BIC     #1C17,$(SP) ;; MAKE IT 7-BIT ASCII

```

```

2666
2667
2668 023340 021627 000025      9$:  CMP      (SP),#25      ;; IS IT A CONTROL-U?
2669 023344 001005                BNE      10$           ;; BRANCH IF NOT
2670 023346 104401 024072                TYPE    $CNTLU        ;; YES, ECHO CONTROL-U (↑U)
2671 023352 062706 000006      20$:  ADD      #6,SP        ;; IGNORE PREVIOUS INPUT
2672 023356 000757                BR       19$           ;; LET'S TRY IT AGAIN
2673
2674
2675 023360 021627 000015      10$:  CMP      (SP),#15      ;; IS IT A <CR>?
2676 023364 001022                BNE      16$           ;; BRANCH IF NO
2677 023366 005766 000004                TST     4(SP)         ;; YES, IS IT THE FIRST CHAR?
2678 023372 001403                BEQ     11$           ;; BRANCH IF YES
2679 023374 016677 000002 155536                MOV     2(SP),2SWR    ;; SAVE NEW SWR
2680 023402 062706 000006      11$:  ADD      #6,SP        ;; CLEAR UP STACK
2681 023406 104401 001161      14$:  TYPE    $CALF        ;; ECHO <CR> AND <LF>
2682 023412 123727 001135 000001                CMPB   $INTAG,#1     ;; RE-ENABLE TTY KBD INTERRUPTS?
2683 023420 001003                BNE     15$           ;; BRANCH IF NOT
2684 023422 012777 000100 155514                MOV     #100,2$TKS   ;; RE-ENABLE TTY KBD INTERRUPTS
2685 023430 003002      15$:  RTI                    ;; RETURN
2686 023432 004737 022440      16$:  JSR     PC,$TYPEPC   ;; ECHO CHAR
2687 023436 021627 000060                CMP     (SP),#60     ;; CHAR < 0?
2688 023442 002420                BLT     18$           ;; BRANCH IF YES
2689 023444 021627 000067                CMP     (SP),#67     ;; CHAR > ?
2690 023450 003015                BGT     18$           ;; BRANCH IF YES
2691 023452 042726 000060                BIC     #60,(SP)+    ;; STRIP-OFF ASCII
2692 023456 005766 000002                TST     2(SP)        ;; IS THIS THE FIRST CHAR
2693 023462 001403                BEQ     17$           ;; BRANCH IF YES
2694 023464 006316                ASL     (SP)         ;; NO, SHIFT PRESENT
2695 023466 006316                ASL     (SP)         ;; CHAR OVER TO MAKE
2696 023470 006316                ASL     (SP)         ;; ROOM FOR NEW ONE.
2697 023472 005266 000002      17$:  INC     2(SP)        ;; KEEP COUNT OF CHAR
2698 023476 056616 177776                BIS     -2(SP),(SP)  ;; SET IN NEW CHAR
2699 023502 000707                BR      7$           ;; GET THE NEXT ONE
2700 023504 104401 001160      18$:  TYPE    $QUES        ;; TYPE ?<CR><LF>
2701 023510 000720                BR      20$         ;; SIMULATE CONTROL-U
2702 .DSABL  LSB
2703
2704
2705
2706 *****
2707 *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
2708 *CALL:
2709 *      RDCHR
2710 *      RETURN HERE
2711 *
2712
2713 $RDCHR: MOV     (SP),-(SP)      ;; PUSH DOWN THE PC AND
2714         MOV     4(SP),2(SP)   ;; THE PS
2715         CLR     4(SP)         ;; GET READY FOR A CHARACTER
2716         CLR     -(SP)        ;; PUT NEW PS ON STACK
2717         MOV     #64$,-(SP)    ;; PUT NEW PC ON STACK
2718         RTI                    ;; POP NEW PC AND PS
2719
2720      64$: TST     $TKCNT      ;; WAIT ON A CHARACTER
      1$:

```

```

2722 023544 005337 022736          DEC      STKCNT          ;; DECREMENT THE COUNTER
2723 023550 117766 177166 000004          MOV      #STKQOUT,4(SP) ;; GET ONE CHARACTER
2724 023556 005237 022742          INC      STKQOUT        ;; UPDATE THE POINTER
2725 023562 023727 022742 022745          CMP      STKQOUT,#STKQEND ;; DID IT GO OFF OF THE END?
2726 023570 001003          BNE      2$            ;; BRANCH IF NO
2727 023572 012737 022744 022742          MOV      #STKQSRRT,STKQOUT ;; RESET THE POINTER
2728 023600 000002          RTI                    ;; RETURN
2729
2730 *****
2731 *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
2732 *CALL:
2733 *      RDLIN                ;; INPUT A STRING FROM THE TTY
2734 *      RETURN HERE          ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
2735 *                          ;; TERMINATOR WILL BE A BYTE OF ALL 0'S
2736
2737 $RDLIN: MOV      R3,-(SP)          ;; SAVE R3
2738          CLR      -(SP)          ;; CLEAR THE RUBOUT KEY
2739 1$:      MOV      #STTYIN,R3      ;; GET ADDRESS
2740 2$:      CMP      #STTYIN+30,R3   ;; BUFFER FULL?
2741          BLOS     4$            ;; BR IF YES
2742          RDCHR          ;; GO READ ONE CHARACTER FROM THE TTY
2743          MOV      (SP)+,(R3)      ;; GET CHARACTER
2744 10$:     CMP      #177,(R3)      ;; IS IT A RUBOUT
2745          BNE      5$            ;; BR IF NO
2746          TST      (SP)          ;; IS THIS THE FIRST RUBOUT?
2747          BNE      6$            ;; BR IF NO
2748          MOV      #' \,9$        ;; TYPE A BACK SLASH
2749          TYPE     9$
2750          MOV      #-1,(SP)       ;; SET THE RUBOUT KEY
2751 6$:      DEC      R3            ;; BACKUP BY ONE
2752          CMP      R3,#STTYIN     ;; STACK EMPTY?
2753          BLOS     4$            ;; BR IF YES
2754          MOV      (R3),9$        ;; SETUP TO TYPE OUT THE DELETED CHAR.
2755          TYPE     9$
2756          BR      2$            ;; GO READ ANOTHER CHAR.
2757 5$:      TST      (SP)          ;; RUBOUT KEY SET?
2758          BEQ      7$            ;; BR IF NO
2759          MOV      #' \,9$        ;; TYPE A BACK SLASH
2760          TYPE     9$
2761          CLR      (SP)          ;; CLEAR THE RUBOUT KEY
2762 7$:      CMP      #25,(R3)      ;; IS CHARACTER A CTRL U?
2763          BNE      8$            ;; BR IF NO
2764          TYPE     %CNTLU        ;; TYPE A CONTROL "U"
2765          BR      1$            ;; GO START OVER
2766 8$:      CMP      #22,(R3)      ;; IS CHARACTER A "+R"?
2767          BNE      3$            ;; BRANCH IF NO
2768          CLRB    (R3)          ;; CLEAR THE CHARACTER
2769          TYPE     %SCRLF        ;; TYPE A "CR" & "LF"
2770          TYPE     #STTYIN      ;; TYPE THE INPUT STRING
2771          BR      2$            ;; GO PICKUP ANOTHER CHARACTER
2772 4$:      TYPE     %SQUES        ;; TYPE A ','
2773          BR      1$            ;; CLEAR THE BUFFER AND LOOP
2774 3$:      MOV      (R3),9$        ;; ECHO THE CHARACTER
2775          TYPE     9$
2776          CMP      #15,(R3)+     ;; CHECK FOR RETURN
2777          BNE      2$            ;; LOOP IF NOT RETURN

```

```

2778 024004 104401 001162          TYPE      SLF          ;; TYPE A LINE FEED
2779 024010 005726          TST        (SP)+      ;; CLEAN RUBOUT KEY FROM THE STACK
2780 024012 012603          MOV        (SP)+,R3   ;; RESTORE R3
2781 024014 011646          MOV        (SP)-,(SP) ;; ADJUST THE STACK AND PUT ADDRESS OF THE
2782 024016 016666 000004 000002          MOV        4(SP),2(SP) ;; FIRST ASCII CHARACTER ON IT
2783 024024 012766 024036 000004          MOV        #STTYIN,4(SP)
2784 024032 000002          RTI                ;; RETURN
2785 024034 000          9$: .BYTE      0          ;; STORAGE FOR ASCII CHAR. TO TYPE
2786 024035 000          .BYTE      0          ;; TERMINATOR
2787 024036 000030          $TTYIN: .BLKB     30      ;; RESERVE 30 BYTES FOR TTY INPUT
2788 024066 177607 000377          $BELL: .ASCIZ    <207><377><377> ;; CODE FOR BELL
2789 024072 052536 005015 000          $CNTLU: .ASCIZ    /↑U/<15><12>    ;; CONTROL "U"
2790 024077 136 006507 000012          $CNTLG: .ASCIZ    /↑G/<15><12>    ;; CONTROL "G"
2791 024104 005015 053523 020122          $MSWR: .ASCIZ    <15><12>/SWR = /
2792 024112 020075 000          $MNEW: .ASCIZ    / NEW = /
2793 024115 040 047040 053505          $MNEW: .ASCIZ    / NEW = /
2794 024122 036440 000040          .SBTTL  READ AN OCTAL NUMBER FROM THE TTY
2795
2796
2797
2798
2799
2800
2801
2802
2803
2804
2805 024126 011646          $RDOCT: MOV        (SP)-,(SP)    ;; PROVIDE SPACE FOR THE
2806 024130 016666 000004 000002          MOV        4(SP),2(SP)    ;; INPUT NUMBER
2807 024136 010046          MOV        R0,-(SP)      ;; PUSH R0 ON STACK
2808 024140 010146          MOV        R1,-(SP)      ;; PUSH R1 ON STACK
2809 024142 010246          MOV        R2,-(SP)      ;; PUSH R2 ON STACK
2810 024144 104410          1$: RDLIN          ;; READ AN ASCII LINE
2811 024146 012600          MOV        (SP)+,R0      ;; GET ADDRESS OF 1ST CHARACTER
2812 024150 005001          CLR        R1            ;; CLEAR DATA WORD
2813 024152 005002          CLR        R2
2814 024154 112046          2$: MOVB       (R0)+,-(SP)    ;; PICKUP THIS CHARACTER
2815 024156 001412          BEQ        3$            ;; IF ZERO GET OUT
2816 024160 006301          ASL        R1            ;; *2
2817 024162 006102          ROL        R2
2818 024164 006301          ASL        R1            ;; *4
2819 024166 006102          ROL        R2
2820 024170 006301          ASL        R1            ;; *8
2821 024172 006102          ROL        R2
2822 024174 042716 177770          BIC        #↑C7,(SP)      ;; STRIP THE ASCII JUNK
2823 024200 062601          ADD        (SP)+,R1      ;; ADD IN THIS DIGIT
2824 024202 000764          BR         2$            ;; LOOP
2825 024204 005726          3$: TST        (SP)+      ;; CLEAN TERMINATOR FROM STACK
2826 024206 010166 000012          MOV        R1,12(SP)     ;; SAVE THE RESULT
2827 024212 010237 024226          MOV        R2,$HIOCT
2828 024216 012602          MOV        (SP)+,R2     ;; POP STACK INTO R2
2829 024220 012601          MOV        (SP)+,R1     ;; POP STACK INTO R1
2830 024222 012600          MOV        (SP)+,R0     ;; POP STACK INTO R0
2831 024224 000002          RTI                ;; RETURN
2832 024226 000000          $HIOCT: .WORD      0          ;; HIGH ORDER BITS GO HERE

```

```

2834
2835
2836
2837
2838
2839
2840
2841 024230 010046
2842 024232 016600 000002
2843 024236 005740
2844 024240 111000
2845 024242 006300
2846 024244 016000 024264
2847 024250 000200
2848
2849
2850
2851
2852 024252 011646
2853 024254 016666 000004 000002
2854 024262 000002
2855
2856
2857
2858
2859
2860
2861
2862
2863 024264 024252
2864 024266 022270
2865 024270 022534
2866 024272 022510
2867 024274 022550
2868
2869 024276 023300
2870
2871 024300 023210
2872 024302 023512
2873 024304 023602
2874 024306 024126
2875
2876
2877
2878
2879 024310 012737 024450 000024
2880 024316 012737 000340 000026
2881 024324 010046
2882 024326 010146
2883 024330 010246
2884 024332 010346
2885 024334 010446
2886 024336 010546
2887 024340 017746 154574
2888 024344 010637 024454

```

```

*****
*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
*GO TO THAT ROUTINE.
$TRAP:  MOV    RO, -(SP)           ;; SAVE RO
        MOV    2(SP), RO         ;; GET TRAP ADDRESS
        TST    -(RO)             ;; BACKUP BY 2
        MOVB   (RO), RO          ;; GET RIGHT BYTE OF TRAP
        ASL    RO                ;; POSITION FOR INDEXING
        MOV    $TRPAD(RO), RO    ;; INDEX TO TABLE
        RTS    RO                ;; GO TO ROUTINE

;; THIS IS USE TO HANDLE THE "GETPRI" MACRO
$TRAP2: MOV    (SP), -(SP)       ;; MOVE THE PC DOWN
        MOV    4(SP), 2(SP)     ;; MOVE THE PSW DOWN
        RTI                    ;; RESTORE THE PSW

.SBTTL  TRAP TABLE
*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
*BY THE "TRAP" INSTRUCTION.
:
: ROUTINE
:-----
$TRPAD: .WORD   $TRAP2
        $TYPE   ;; CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
        $TYPOC  ;; CALL=TYPOC    TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
        $TYPOS  ;; CALL=TYPOS    TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
        $TYPON  ;; CALL=TYPON    TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)

        $GTSWR  ;; CALL=GTSWR    TRAP+5(104405)  GET SOFT-SWR SETTING

        $CKSWR  ;; CALL=CKSWR    TRAP+6(104406)  TEST FOR CHANGE IN SOFT-SWR
        $RDCHR  ;; CALL=RDCHR    TRAP+7(104407)  TTY TYPEIN CHARACTER ROUTINE
        $RDLIN  ;; CALL=RDLIN    TRAP+10(104410) TTY TYPEIN STRING ROUTINE
        $RDOCT  ;; CALL=RDOCT    TRAP+11(104411) READ AN OCTAL NUMBER FROM TTY

.SBTTL  POWER DOWN AND UP ROUTINES
*****
: POWER DOWN ROUTINE
$PWRDN: MOV    $SILLUP, @PWRVEC  ;; SET FOR FAST UP
        MOV    #340, @PWRVEC+2  ;; PRIO:7
        MOV    RO, -(SP)        ;; PUSH RO ON STACK
        MOV    R1, -(SP)        ;; PUSH R1 ON STACK
        MOV    R2, -(SP)        ;; PUSH R2 ON STACK
        MOV    R3, -(SP)        ;; PUSH R3 ON STACK
        MOV    R4, -(SP)        ;; PUSH R4 ON STACK
        MOV    R5, -(SP)        ;; PUSH R5 ON STACK
        MOV    @SWR, -(SP)      ;; PUSH @SWR ON STACK
        MOV    SP, $SAVR6      ;; SAVE SP

```

```

2890 024356 000000          HALT
2891 024360 000776          BR          .-2          ;; HANG UP
2892
2893
2894          ;;*****
2895          :POWER UP ROUTINE
2896 024362 012737 024450 000024 $PWRUP: MOV    $SILLUP, @PWRVEC ;; SET FOR FAST DOWN
2897 024370 013706 024454          MOV    $SAVR6, SP      ;; GET SP
2898 024374 005037 024454          CLR    $SAVR6          ;; WAIT LOOP FOR THE TTY
2899 024400 005237 024454          1$:  INC    $SAVR6      ;; WAIT FOR THE INC
2900 024404 001375          BNE    1$              ;; OF WORD
2901 024412 012677 154526          MOV    (SP)+, @SWR     ;; POP STACK INTO @SWR
2902 024414 012605          MOV    (SP)+, R5       ;; POP STACK INTO R5
2903 024416 012604          MOV    (SP)+, R4       ;; POP STACK INTO R4
2904 024420 012603          MOV    (SP)+, R3       ;; POP STACK INTO R3
2905 024422 012602          MOV    (SP)+, R2       ;; POP STACK INTO R2
2906 024424 012601          MOV    (SP)+, R1       ;; POP STACK INTO R1
2907 024426 012737 024310 000024 MOV    $SPWRDN, @PWRVEC ;; SET UP THE POWER DOWN VECTOR
2908 024434 012737 000340 000026 MOV    @340, @PWRVEC+2 ;; PRIO:7
2909 024442 104401          TYPE          ;; REPORT THE POWER FAILURE
2910 024444 024456          $PWRMG: .WORD $POWER ;; POWER FAIL MESSAGE POINTER
2911 024446 000002          RTI
2912 024450 000000          $SILLUP: HALT          ;; THE POWER UP SEQUENCE WAS STARTED
2913 024452 000776          BR          .-2          ;; BEFORE THE POWER DOWN WAS COMPLETE
2914 024454 000000          $SAVR6: 0              ;; PUT THE SP HERE
2915 024456 005015 047520 042527 $POWER: .ASCIZ <15><12>"POWER"
2916 024464 000122
2917          .EVEN

```













WCERRR	013140	1451	1455#						
WCHERR	013654	1548	1553#						
WFERR	013144	1402	1459#						
WPS	= 000040	291#	1896	1925					
WROCNT	001340	254#	797*	868	929*				
WRITCS	001354	260#	798	1737	1770				
WRLINK	005104	535	615	788#					
WRPRO	016470	1624	1636	1760#					
WRDCK	016260	1618	1630	1728#	1756				
WRTNBY	001317	239#	918*	1026					
X	015610	1692	1697#						
XX	016024	1710#							
\$AUTOB	001134	177#	362*	2646	2795				
\$BOADR	001122	172#							
\$BOOAT	001126	174#							
\$BELL	024066	2599	2788#						
\$CHARC	022504	2445*	2455*	2462	2471*	2476#			
\$CKSWR	023210	2632#	2871						
\$CNTAG	001100	160#	322	323					
\$CM3	= 000000	190#							
\$CNTLG	024077	2653	2790#						
\$CNTLU	024072	2670	2763	2789#					
\$CRLF	001161	191#	1331	1874	2444	2479	2681	2768	2788
\$ENDAD	001400	149	270#						
\$ERFLG	001103	163#							
\$ERMAX	001115	169#							
\$ERRPC	001116	170#							
\$ERRTB	001434	307#							
\$ERTTL	001112	167#							
\$FILLC	001156	188#	2448	2479					
\$FILLS	001155	187#	2479						
\$GOADR	001120	171#							
\$GOOAT	001124	173#							
\$GTSWR	023300	2654#	2869						
\$HD	= 000003	11	12						
\$HIOCT	024226	2827*	2832#						
\$ICNT	001104	164#							
\$ILLUP	024450	2879	2895	2912#					
\$INTAG	001135	178#	2651*	2682	2795				
\$ITEMB	001114	168#							
\$LF	001162	192#	2479	2778	2788				
\$LPADR	001106	165#							
\$LPERR	001110	166#							
\$MAIL	= ***** U	349	358	2432					
\$MNEW	024115	2657	2793#						
\$MSWR	024104	2654	2791#						
\$NULL	001154	186#	2450	2479					
\$OCNT	022732	2511*	2540*	2553#					
\$OMODE	022734	2506*	2510*	2515	2518*	2529*	2555#		
\$PASS	001100	161#	1129*	1134					
\$POWER	024456	2910	2915#						
\$PWRON	024310	331	2879#	2907					
\$PWRMG	024444	2910#							
\$PWRUP	024362	2889	2895#						
\$QUES	001160	190#	422	2479	2700	2771	2788		





.SDIV	1#	
.SEOP	1#	
.SERR0	1#	
.SERRT	1#	
.SMULT	1#	
.SPOWE	1#	2875
.SRAND	1#	
.SRODE	1#	
.SRDOC	1#	2795
.SREAD	1#	2556
.SR2AZ	1#	
.SSAVE	1#	
.SSB20	1#	
.SSB20	1#	
.SSCOP	1#	
.SSIZE	1#	
.SSUPR	1#	
.STRAP	1#	2833
.STYPB	1#	
.STYPD	1#	
.STYPE	1#	2409
.STYPO	1#	2479
.S4OCA	1#	
.1170	1#	

. ABS. 024466 000

ERRORS DETECTED: 0

DZRKIF.BIN,DZRKIF.LST/CRF/SOL=DZRKKE.SML,DZRKIF.P11  
 RUN-TIME: 12 16 1 SECONDS  
 RUN-TIME RATIO: 102/31=3.3  
 CORE USED: 33K (65 PAGES)

J07