

RK11/05F/J

BASIC LOGIC TESTS
CZRKKF0

AH-9246F-MC


COPYRIGHT © 75-78

FICHE 1 OF 1

JUL 1978

digital

MADE IN USA



.REM %

IDENTIFICATION

PRODUCT CODE: AC-9244F-MC
PRODUCT NAME: CZRKKFO RK11 BASIC LOGIC TEST 2
DATE CREATED: JUNE 1978
MAINTAINER: DIAGNOSTIC GROUP
AUTHOR: JIM KAPADIA
REVISED BY: PERVEZ ZAKI
TOM SAWYER
CHUCK HESS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1975, 1978 BY DIGITAL EQUIPMENT CORPORATION

QUICK LOOK-UP OPERATING INSTRUCTIONS
FOR A QUICK REFERENCE, LOOK UP THE FOLLOWING SECTIONS:
1.0 ABSTRACT
2.0 REQUIREMENTS
4.1 LOADING AND OPERATOR ACTION
7.0 SWITCH OPTIONS
FOR A MORE COMPLETE EXPLANATION REFER TO THE TABLE OF
CONTENTS BELOW AND THE FOLLOWING DOCUMENT.

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	PRELIMINARY PROGRAMS
2.3	EXECUTION TIME
3.0	STARTING ADDRESS
4.0	PROGRAM CONTROL MODES & OPERATOR ACTION
4.1	PAPER TAPE
4.2	RKDP DUMP MODE
4.3	RKDP CHAIN MODE
4.4	ACT11
5.0	DRIVE SELECTION
6.0	DRIVE-LESS TEST
7.0	SWITCH OPTIONS
8.0	SCOPE LOOPS
9.0	PROGRAM STRUCTURE
9.1	SET-UP PHASE
9.2	DRIVE DEPENDENT CONTROLLER TESTS
10.0	ERROR REPORTING
11.0	ERROR INTERPRETATION
12.0	HANDLERS AND COMMON ROUTINES
12.1	TRAP HANDLER
12.2	SCOPE HANDLER
12.3	ERROR HANDLER
12.4	CONTROL RESET ROUTINE
12.5	CONTROL READY ROUTINE
12.6	DRIVE RESET ROUTINE
12.7	TIME DELAY ROUTINE
12.8	WAIT FOR INTERRUPT ROUTINE
12.9	OTHER ROUTINES
	TTY HANDLER (I/O), ERROR TYPEOUT ROUTINE
	POWER DOWN/POWER UP ROUTINE
13.0	UNEXPECTED TIMEOUTS & RK11 INTERRUPTS
14.0	QUICK VERIFYING MODE

1.0 ABSTRACT

THE RK11 LOGIC TESTS CONSIST OF A SERIES OF TESTS AIMED AT CHECKING THE BASIC LOGIC OF THE RK11 CONTROLLER. THIS PROGRAM IS THE SECOND PART OF THE TWO-PART RK11 LOGIC TESTS. IT SHOULD BE NOTED THAT LOGIC TEST I AND LOGIC TEST II TOGETHER CONSTITUTE A COMPLETE PROGRAM AND BOTH OF THEM SHOULD BE RUN.

WHEN USED IN CONJUNCTION WITH A DRIVE IT IS CAPABLE OF DETECTING FAULTS IN THE DRIVE ALSO.

USED CORRECTLY THIS PROGRAM CAN BE AN EFFECTIVE ANALYTIC AND DIAGNOSTIC TOOL.

2.0 REQUIREMENTS

2.1 EQUIPMENT

- A. PDP11 WITH CONSOLE TELETYPE.
- B. 8K OF MEMORY
- C. RK11 OR RKV11 CONTROLLER
- D. 1-8 RK05 OR RK05F DRIVES OR THE RK05 SIMULATOR (DRIVE TYPES MAY BE MIXED)

2.2 PRELIMINARY PROGRAMS

RK11 BASIC LOGIC TEST I (MD-11-DZRKJ)

2.3 EXECUTION TIME

ERROR FREE FIRST PASS ON PDP11/20 WITH CORE MEMORY TAKES APPROXIMATELY TWO MINUTES. CONSIDERABLY LESS FOR FASTER MACHINES OR MEMORIES.

3.0 STARTING ADDRESS

200 FOR ANY MODE OF OPERATION. NORMAL START UP WITH ALL SWITCHES DOWN.

4.0 PROGRAM CONTROL MODES & OPERATOR ACTION

PAPER TAPE LOADING
RKDP DUMP MODE
RKDP CHAIN MODE
ACT11

- 4.1 PAPER TAPE LOADING
 - 4.1.1 LOAD PROGRAM INTO MEMORY USING STANDARD PROCEDURE FOR .ABS TAPES.
 - 4.1.2 MAKE SURE THAT THE DRIVES TO BE CHECKED ARE LOADED WITH DISKS AND ARE IN 'RUN'. 'WRT ENABLE' THEM. CHECK THAT 'WRT PROT' LIGHT ON THESE DRIVES IS OFF. PUT DRIVES THAT ARE NOT TO BE TESTED ON 'LOAD'.
 - 4.1.3 LOAD ADDRESS 200
 - 4.1.4 SET SWITCHES IF DESIRED (SEE SEC 7.0) IF TESTING ON SIMULATOR PUT SW<10> UP.

PRESS START.

- 4.1.5 THE PROGRAM IDENTIFIES ITSELF (NAME,MAINDEC NO), THEN THE FOLLOWING QUESTION IS ASKED:

DRIVES TO BE TESTED?

THE USER SHOULD TYPE IN THE DRIVE NUMBERS THAT ARE IN 'RUN' AND TO BE TESTED. CARRIAGE RETURN SHOULD TERMINATE THE STRING. IF AN RK-05F IS TO BE TESTED, TYPE THE SUFFIX 'F' WITH THE FIRST DRIVE OF THE PAIR. FOR EXAMPLE, IF DRIVES 2 AND 3 ARE ON AN RK-05F, TYPE ONLY 2F.

EXMP: DRIVES TO BE TESTED? 0,1,2<CR>

THE DRIVES DO NOT HAVE TO BE IN LOGICAL ORDER.

EXMP: DRIVES TO BE TESTED? 2,4<CR>

IF ANY ONE DRIVE IS TO BE TESTED, TYPE IN THAT NUMBER. IT DOES NOT HAVE TO BE DRIVE 0.

THUS A NORMAL SEQUENCE WITH DRIVES 0,1 WOULD BE:

RK11 BASIC LOGIC TEST 2
MAINDEC-11-CZRKKF
DRIVES TO BE TESTED? 0,1<CR>

- 4.1.6 THERE IS A 'RUBOUT' FEATURE WHICH ALLOWS RUBBING OUT ANY NUMBER OF CHARACTERS THAT WERE TYPED IN WRONG. THE RUBBED OUT CHARACTERS ARE ECHOED BACK WITHIN SLASHES.

" U" DELETES THE ENTIRE LINE

- 4.1.7 IF REPLY TO ANY OF THE ABOVE QUESTION IS IN A WRONG FORMAT (EX: 012<CR>;0,8<CR>; 0,A<CR>; M<CR> ETC), IT IS AUTOMATICALLY REJECTED, A "??" IS PRINTED OUT;

THE CORRECT ANSWER CAN NOW BE RETYPED AGAIN.

- 4.1.8 THE DRIVE NUMBER BEING TESTED OUT IS PRINTED:

DRIVE N ;N=0,1...7
IF THE DRIVE IS AN RK-05F, AN F IS APPENDED

AT THE END OF A PASS THE FOLLOWING TYPE-OUT OCCURS

END PASS # X

WHERE X= PASS NUMBER (1,2,3---), CONTROL IS PASSED TO THE BEGINNING OF THE PROGRAM AND RE-EXECUTION BEGINS. NO QUESTIONS ARE TO BE ANSWERED AGAIN.

- 4.1.9 ERROR FREE PASSES OF THE PROGRAM APPEAR AS SHOWN BELOW.

```
RK11 BASIC LOGIC TEST 2
MAINDEC-11-CZRKKF
DRIVES TO BE TESTED?
0,1<CR>
DRIVE 0
DRIVE 1
END PASS # 1
0
DRIVE 1
END PASS # 2
...
...
```

- 4.2 RKDP DUMP MODE

- 4.2.1 THE PROGRAM IS LOADED INTO THE MEMORY BY THE RKDP MONITOR

- 4.2.2 START AS NORMALLY USING SA 200

- 4.2.3 THE PROGRAM IDENTIFIES ITSELF (NAME,MAINDEC NO.). ON FINDING OUT THAT THE LOADING WAS BY RKDP (DUMP MODE), THE FOLLOWING MESSAGE APPEARS:

'TO TEST DRIVE 'N' HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM'

IF DRIVE 'N' IS TO BE TESTED, THE RKDP PACK ON THAT

DRIVE SHOULD BE REPLACED BY ANOTHER PACK, THE DRIVE SHOULD BE PUT ON 'WRT ENABL' (BECAUSE RKDP WRITE PROTECTS THE DRIVE).

IF DRIVE 'N' IS NOT TO BE CHECKED, THEN THE MESSAGE SHOULD BE IGNORED.

AFTER THIS, THE SEQUENCE OF QUESTIONING IS AS EXPLAINED IN SEC 4.1.5.

4.3 RKDP CHAIN MODE

THE PROGRAM IS CHAIN-LOADED FROM THE RKDP PACK ON DRIVE 'N'. AFTER THE PROGRAM IDENTIFIES ITSELF THE FOLLOWING PRINTOUT OCCURS.

'DRIVE 'N' NOT TESTED'

THERE IS NO OPERATOR INTERVENTION REQUIRED. THE PROGRAM FINDS OUT THE NUMBER OF DRIVES PRESENT.

4.4 ACT11 MODE

THE PROGRAM IS LOADED BY THE ACT11 MONITOR. ON STARTING, IDENTIFIES ITSELF, ASCERTAINS THE NUMBER OF DRIVES AND PROCEEDS WITH THE EXECUTION OF THE TESTS AS BEFORE.

5.0 DRIVE SELECTION

IF ANY PARTICULAR DRIVE IS TO BE SELECTED FOR TESTING, PUT THAT DRIVE ON 'RUN', 'WRITE ENABLE'; PUT REST OF THE DRIVES ON 'LOAD', 'WRITE LOCK' AND IN REPLY TO THE QUESTIONS (TO BE TESTED?) TYPE IN THE DRIVE NUMBER FOLLOWED BY CR. SEE SEC 4.1.5.

6.0 DRIVE-LESS TEST

USE RK11 BASIC LOGIC TEST I, WHICH IS ACTUALLY THE FIRST PART OF THE TWO-PART RK11 BASIC LOGIC TESTS. SEE SEC 1.0, 2.2.

7.0 SWITCH OPTIONS

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' WHENEVER THE PROGRAM ENTERS

THE SCOPE ROUTINE OR BEGINS A NEW TEST. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED., 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

SW<15>=1	HALT ON ERROR
SW<14>=1	LOOP ON TEST
SW<13>=1	INHIBIT ERROR PRINTOUTS
SW<12>=1	CYCLE ON ERROR TO THE PREVIOUS 'SCOPE' STATEMENT
SW<11>=1	INHIBIT ITERATIONS
SW<10>=1	TESTING ON SIMULATOR
SW<09>=1	LOOP ON SPECIFIC ERROR
SW<08>=1	LOOP ON TEST AS PER SW<07:00>
SW<06>=1	DROP THE DRIVE AFTER MAXIMUM ALLOWABLE NUMBER OF ERRORS OCCUR

7.1 SW<15>

THE PROGRAM HALTS ON ENCOUNTERING AN ERROR, AFTER TYPING OUT THE ERROR MESSAGE AND PERTINENT INFORMATION. PRESSING "CONTINUE" RESTORES NORMAL OPERATION OF THE PROGRAM.

7.2 SW<14>

THE PROGRAM LOOPS ON THE SUBTEST THAT IS BEING EXECUTED WHEN THE SWITCH IS PUT ON. THIS SWITCH IS USED NORMALLY ALONG SW 15. SEE SEC 8.0.

7.3 SW <13>

THIS SWITCH INHIBITS ALL ERROR MESSAGES. NORMALLY USED WHEN LOOPING ON TEST (SW 14) OR LOOPING ON ERROR (SW 9).

7.4 SW <12>

THIS SWITCH ALLOWS THE PORGRAM TO CYCLE FROM THE POINT OF ERROR TO THE PREVIOUS SCOPE STATEMENT. NOTE THAT IN DOING SO ANY INITIALIZATION BEING DONE AT THE BEGINING OF THE SUBTEST WILL BE DONE AGAIN AND AGAIN. SEE SEC 8.0 FOR DIFFERENT SCOPE LOOPS

AVAILABLE.

7.5 SW <11>

EACH SUBTEST WILL BE EXECUTED ONLY ONCE. NORMALLY AFTER THE FIRST PASS, EACH SUBTEST IS ITERATED A NUMBER OF TIMES (USUALLY 50, 5 IN SOME CASES). SETTING THIS SWITCH INHIBITS ITERATIONS, SO THAT QUICK PASSES CAN BE MADE.

7.6 SW <10>

THIS SWITCH WHEN SET INDICATES THAT TESTING IS BEING DONE ON A SIMULATOR. THE SWITCH SHOULD BE PUT UP BEFORE STARTING THE PROGRAM. NOTE THAT RK11C IS NOT COMPATIBLE WITH THE SIMULATOR.

7.7 SW <09>

THIS SWITCH PROVIDES THE TIGHTEST POSSIBLE SCOPE LOOP. NOTE THAT THE SW12 THE INITIALIZATION OF PARAMETERS AT THE BEGINNING OF THE SUBTEST MAY NOT BE DONE IN THIS CASE. THIS SWITCH IS HELPFUL WHEN A PARTICULAR PART OF A SUBTEST IS BEING REPEATED USING DIFFERENT PARAMETERS AND YOU WANT TO SCOPE ON THE PARAMETER IN ERROR. (EXAMPLE: RKDA IS BEING WRITTEN AND READ BACK WITH COUNT PATTERNS FROM 1 TO 177777. PATTERN 561 IS GIVING ERROR, YOU MIGHT NOT WANT TO GO THROUGH THE 560 PATTERNS BEFORE HITTING ERROR ON THE 561TH PATTERN. IN THIS CASE SW 9 WILL GIVE YOU A SCOPE LOOP ON THE 561TH PATTERN ONLY

7.8 SW <08>

THIS SWITCH IS USED TO SELECT A PARTICULAR TEST (AS PER SW<00-07>) FOR EXECUTION AND SUBSEQUENT LOOPING. THUS IF TEST 15 IS TO BE SELECTED THE SWITCH SETTING WOULD BE 000415. IT SHOULD BE NOTED THAT BEFORE SELECTING TEST 15, ALL THE PREVIOUS TESTS (1-14) WILL BE EXECUTED.

7.9 SW<06>

THIS SWITCH ALLOWS THE PROGRAM TO DROP A DRIVE FROM THE SELECTION LIST AND TESTING AFTER MAXIMUM ALLOWABLE ERROR COUNT (TOTAL NUMBER OF ERRORS) ON THAT DRIVE IS EXCEEDED. THE MAXIMUM ALLOWABLE ERROR COUNT IS 5, AFTER 5 ERRORS HAVE OCCURED DRIVE IS DROPPED AND A MESSAGE (DRIVE # XXX DROPPED) IS PRINTED.

8.0 SCOPE LOOPS

THERE ARE THREE KINDS OF SCOPE LOOPS AVAILABLE

1. SW14: LOOPING IS DONE FOR THE ENTIRE SUB-TEST
2. SW12: LOOPING IS DONE FROM THE POINT OF ERROR BACK TO THE PREVIOUS 'SCOPE' STATEMENT.
3. SW09: PROVIDE THE TIGHTEST POSSIBLE SCOPE LOOP SEE SEC. 7.7

EXAMPLE:

TST1: SCOPE
:

INITIALIZATION

:
ERROR 1

:
ERROR 2

:
ERROR 3

:
ERROR 4

:
TST2: SCOPE

THE SEQUENCE OF LOOPING FOR DIFFERENT CASES IS EXPLAINED BELOW. NOTE THAT 'TST1' AND 'TST2' ARE TAGS WHICH DEFINE THE BOUNDARY OF A TEST, (IN THIS CASE TEST 1). TEST 1 STARTS AT 'TST1' AND ENDS JUST BEFORE 'TST2'.

IN THE ILLUSTRATION BELOW --> INDICATES THE POINT FROM WHERE RETURN IS MADE AND LOOPING IS DONE.

1. ERROR 2 OCCURS, SW 14 SET.

TST1..ERROR 2..TST2-->TST1..ERROR 2..TST2-->TST1...

2. ERROR 2 OCCURS, SW 12 SET.

TST1...ERROR 2-->TST1...ERROR2-->TST1...

3. ERROR 2,3; SW 14 SET.

TST1..ERROR 2..ERROR 3..TST2-->TST1..ERROR 2..ERROR 3..TST2-->TST1...

4. ERROR 2,3; SW 12 SET.

TST1...ERROR 2-->TST1...ERROR 2-->TST1....

NOTE THAT LOOPING IS DONE FROM THE VERY FIRST ERROR ENCOUNTERED. THE MORE BASIC AND EARLIER IT OCCURS AND IS DETECTED AND SHOULD BE FIXED.

IN THE ABOVE EXAMPLE NO PART OF THE SUB-TEST IS BEING REPEASING DIFFERENT PARAMETERS, HENCE IT SO HAPPENS THAT SW 9 AND 12 GIVE THE SAME KIND OF LOOPS. THE EXAMPLE BELOW WILL DEMONSTRATE THE DIFFERENCE BETWEEN SW 9 AND 12.

TST1: SCOPE
 :

```

INITIALIZATION
:
ERROR 1
:
MOV    #1$, $LPERR    ; '$LPERR' CONTAINS
                    ; THE ADDRESS TO LOOP
                    ; BACK ON ERROR- SW 9
1$:    :
        :
        ER            I  N REPETITIONS
        :
TST2:  SCOPE
        :
    
```

1. SW 12 SET, ERROR 2 OCCURS DURING K.TH REPETITIONS

TST1..1,2...K.ERROR 2-->TST1..1,2...K.ERROR 2-->TST1..

2. SW 9 SET, ERROR 2 OCCURS DURING K.TH REPETITION

1\$..K..ERROR 2-->1\$..K..ERROR 2-->1\$...

9.0 PROGRAM STRUCTURE

THERE ARE THREE DISTINCT PARTS OF THE PROGRAM.

SET-UP PHASE
 DRIVE-DEPENDENT CONTROLLER TESTS

9.1 SET-UP PHASE

SETTING UP OF INITIAL POINTERS, VECTORS, TABLES IS DONE IN THIS PART. IN THIS SECTION THE DECISION IS MADE ABOUT THE PROGRAM MODE-PAPER TAPE, RKDP DUMP, CHAIN OR ACT11. IF IN A NON-INTERVENTION MODE (CHAIN, ACT11) NUMBER OF DRIVES AND THE TYPE OF CONTROLLER IS FOUND OUT. FLAGS ARE SET TO INDICATE

WHICH DRIVES ARE TO BE TESTED, ETC.

9.2 DRIVE DEPENDENT CONTROLLER TESTS

THIS SECTION FORMS A MAJOR PART OF THE PROGRAM WHEREIN MOST OF THE CONTROLLER IS CHECKED.

JUST BEFORE ENTERING THIS SECTION THE PROGRAM FINDS OUT WHICH DRIVE IS TO BE CHECKED. IF IN RKDP CHAIN MODE, DRIVE 'N' IF PRESENT, IS SKIPPED AND THE NEXT AVAILABLE DRIVE IS SELECTED.

THE DRIVE NUMBER BEING TESTED IS PRINTED OUT:

DRIVE N ;N=0,1,2...7

THE TESTING IS DONE IN A LOGICAL HIERCHY, SIMPLER THINGS FIRST, THEN MORE COMPLEX AND SO ON.

IN ONE OF THE TESTS THE ENTIRE DISK PACK IS FORMATTED, CHECKS ARE MADE FOR ERROR CONDITIONS. THE FIRST WORD OF EVERY SECTOR IS WRITTEN AS A PSUEDO-HEADER, REFLECTING THE ABSOLUTE ADDRESS OF THAT SECTOR (DRIVE #, CYLINDER #, SURFACE #, SECTOR #). EXAMPLE: THE PSUEDO-HEADER FOR SECTOR 5, SURFACE 0, CYLINDER 20, DRIVE 0 WOULD BE 001005.

IN THE NEXT TEST THE HEADERS FROM THE ENTIRE PACK ARE READ AND CHECKED FOR CORRECTNESS. IN A SUBSEQUENT TEST ALL THE PSUEDO-HEADERS ARE READ AND VERIFIED.

ALL THE FUNCTIONS ARE CHECKED OUT. 'SEEK' IS CHECKED IN THE THREE DIFFERENT VELOCITY MODES (HIGH, MEDIUM, LOW). VARIOUS ERRORS LIKE 'NXD', 'NXC', ETC. ARE SIMULATED AND CHECKED.

HARDWARE POGIC IS CHECKED USING ALL THE DRIVES THAT HAVE BEEN INDICATED.

AT THE END OF THIS SECTION, A CHECK IS MADE IF ALL INDICATED DRIVES HAVE BEEN TESTED. IF NOT, CONTROL IS TRANSFERRED TO THE BEGINNING OF THIS SECTION.

THUS ONE PASS OF THE PROGRAM INVOLVES DOING

1. SUBTEST #1 ONCE
2. DRIVE-DEPENDENT TESTS FOR ALL THE SELECTED DRIVES.

10.0 ERROR REPORTING

THE ERROR TABLE STARTING AT \$ERRTB CONTAINS INFORMATION PERTAINING TO EVERY ERROR THAT CAN OCCUR. EACH ITEM IN THE TABLE CONSISTS OF FOUR

ENTRIES.

- A. EM - THIS IS A POINTER TO THE ERROR MESSAGE TO BE TYPED OUT WHEN THE ERROR OCCURS.
- B. DH - THIS IS A POINTER TO THE DATA HEADER TO BE TYPED OUT.
- C. DT - THIS IS A POINTER TO THE DATA WHICH IS TO BE TYPED TYPED OUT UNDER THE HEADERS.
- D. 0 - THIS IS A TERMINATOR SIGNIFYING THE END OF THE ITEM.

THE ERROR CALL IS AN EMT INSTRUCTION WITH ITS LOWER BYTE ENCODED TO INDICATE THE ERROR NUMBER. THUS OR 1" WOULD BE (EMT+1) IE 104001.

EVERY ERROR CORRESPONDS TO AN ITEM IN THE ERROR TABLE. THUS "ERROR 14" WOULD CORRESPOND TO ITEM 14. AS FAR AS POSSIBLE, THE ERROR MESSAGES HAVE BEEN KEPT SHORT, BUT CLARITY IS NOT SACRIFICED FOR BREVITY. INSPITE OF THIS, IF THE USER FINDS A NEED, HE CAN LOOK UP THE ENTIRE ERROR MESSAGE IN THE ERROR ITEMS TABLE FOUND IN THE BEGINNING OF THE LISTINGS. THUS FOR "ERROR 14", "ITEM 14" IN THE ITEM TABLE CAN BE LOOKED UP. WHEN THE ERROR INSTRUCTION IS EXECUTED A TRAP OCCURS TO THE ERROR HA LOCATED AT \$ERROR WHICH PROCESSES THE ERROR CALL. SEE SEC 12.3

11.0 ERROR INTERPRETATION

WHENEVER AN ERROR MESSAGE IS PRINTED OUT, ALL REGISTERS AND OTHER DATA PERTAINING TO THE ERROR ARE ALSO GIVEN. RKDS, RKER...RKBA INDICATE THE CONTENTS OF THE CORRESPONDING REGISTERS AT THE TIME OF ERROR.

EVERY ERROR MESSAGE CONTAINS A PC. THIS PC INDICATES THE POSITION IN PROGRAM WHERE THE ERROR CALL IS LOCATED. THE ERROR MESSAGE, BECAUSE OF PRACTICAL CONSIDERATIONS IS MADE SHORT AND MEANINGFUL. THE USER IS ADVTO LOOK UP THE PC IN THE PROGRAM LISTING, WHERE HE WILL FIND MORE INFORMATION ABOUT THE ERROR. IN MANY INSTANCES, A SINGLE FAULT WILL GIVE RISE TO MORE THAN ONE ERROR REPORT. A LITTLE DELIBERATION AND CAREFUL EXAMINATION OF THE DATA GIVEN WILL BE CERTAINLY VERY HELPFUL IN PINPOINTING THE FAULT. A BRIEF EXPLANATION OF WHAT IS BEING CHECKED IN THE SUBTEST IS GIVEN AT THE BEGINNING OF EVERY SUBTEST. ALL THE NUMBERS GIVEN WITH ERROR MESSAGES ARE IN OCTAL.

12.0 HANDLERS AND COMMON ROUTINES

THE COMPOSED ROUTINES USED IN THE PROGRAM ARE CALLED IN TWO WAYS.

- A. AS A SUBROUTINE THROUGH 'JSR' CALL
- B. THROUGH A 'TRAP' HANDLER

12.1 TRAP HANDLER

MANY COMMONLY USED ROUTINES IN THE PROGRAM ARE CALLED USING THE TRAP INSTRUCTION AND THE 'TRAP' HANDLER. THE LOWER BYTE OF THE TRAP INSTRUCTION IS ENCODED DIFFERENTLY FOR DIFFERENT ROUTINES. THE TRAP HANDLER IS LOCATED AT '\$TRAP'. WHEN A CALL FOR A ROUTINE IS EXECUTED, A TRAP OCCURS TO THE HANDLER 'ARAP'. THE HANDLER PICKS UP THE LOWER BYTE OF THE "CALL INSTRUCTION" AND USES IT TO FORM THE STARTING ADDRESS OF THE ROUTINE TO GO TO FOR SERVICE.

12.2 SCOPE HANDLER

THE 'IOT' TRAP IS USED BY THE 'SCOPE' STATEMENT. WHEN 'SCOPE' IS EXECUTED, AN IOT TRAP OCCURS TO MEMORY LOCATION '\$SCOPE'. THE SCOPE HANDLER STARTS AT '\$SCOPE'. DEPENDING ON THE SWITCH SETTINGS THE HANDLER DECIDES TO LOOP ON TEXT, INHIBIT ITERATIONS ETC. THERE ARE CERTAIN POINTERS AND FLAGS WHICH ARE ADJUSTED. THUS, IT IS NOT ADVISABLE START THE PROGRAM AT ANY GIVEN LOCATION SINCE THE VARIOUS POINTERS AND FLAGS MAY NOT BE CORRECTLY ADJUSTED.

12.3 ERROR HANDLER

AN EMT TRAP INSTRUCTION IS USED BY THE ERROR CALL. THE LOWER BYTE IS ENCODED TO GIVE DIFFERENT ERROR CALLS. (EX: ERROR 1 = 104000+1; ERROR 16 = 104000+16). WHEN THE ERROR STATEMENT IS EXECUTED, A TRAP OCCURS TO MEMORY LOCATION '\$ERROR'. THE ERROR HANDLER IS LOCATED AT '\$ERROR'. THE HANDLER FORMS THE POINTER TO ERROR TABLE, WHICH IS USED IF AN ERROR MESSAGE IS TO BE TYPED DEPENDING ON THE SWITCH SETTINGS, A DECISION ABOUT HALTING ON ERROR, INHIBITING TYPEOUT, LOOPING ON ERROR ETC. IS MADE. IF AN ERROR MESSAGE IS TO BE TYPED OUT AN EXIT IS MADE TO THE ERROR MESSAGE TYPEOUT ROUTINE LOCATED AT '\$ERRTYP'.

12.4 CONTROL RESET ROUTINE

THE CALL FOR THIS ROUTINE IS "CNT.RESET" AND IS AN ENCODED 'TRAP' INSTRUCTION. WHEN "CNT.RESET" IS EXECUTED THE CONTROL RESET ROUTINE STARTING AT

"CN.RST" IS ENTERED. A CONTROL RESET IS ISSUED THE PROGRAM WAITS TILL THE CONTROL READY SETS, ON WHICH THE ROUTINE IS EXITED. IF CONTROL READY DOES NOT SET WITHIN A CERTAIN TIME AN ERROR IS REPORTED. THE PC TYPED OUT IS THE LOCATION WHERE THE "CNT.RESET" CALL IS LOCATED. THE WAITING TIME IS 2.8 MS FOR 11/20 AND 560 US FOR 11/45 WITH BIPOLAR MEMORY.

12.5 CONTROL READY ROUTINE

THIS ROUTINE IS CALLED BY "CNT.RDY" (AN ENCODED 'TRAP' INSTRUCTION) AND IS LOCATED AT "CN.RDY". THE ROUTINE WAITS FOR THE CONTROL READY TO SET AND WHEN IT DOES, EXITS IF CONTROL READY DOES NOT SET WITHIN A SPECIFIED TIME AN ERROR MESSAGE IS GIVEN

CNTRL RDY DIDN'T SET
PC = XXXXXX RKCS = rYYYYY

THE PC IS THE LOCATION AT WHICH THE "CNT.RDY" CALL IS LOCATED. THE WAITING TIME IS 949 MS FOR 11/20 AND 189 MS FOR 11/45 WITH BIPOLAR MEMORY.

12.6 DRIVE RESET ROUTINE

THE DRIVE - RESET ROUTINE IS LOCATED AT "DRESET" AND IS CALLED BY A "JSR". IT ISSUES A DRIVE RESET AND WAITS FOR THE R/W/S RDY TO SET, ON WHICH THE ROUTINE IS EXITED. THE WAITING TIME IS 4959 MS FOR 11/20 AND 991 MS FOR 11/45 WITH BIPOLAR MEMORY.

12.7 TIME DELAY ROUTINE

THIS ROUTINE PROVIDES A VARIABLE TIME DELAY. THE CALL IS DELAY .N WHERE N=1 TO 177777 (OCTAL) TIME DELAY PROVIDED= 7.5 TIMES(X) N MICRO SECS FOR 11/20, 1.5N US FOR 11/45 (N CONVERTED TO DECIMAL BEFORE COMPUTING DELAY) IF THE USER WANTS TO CHANGE THE DELAY AT ANY POINT IT CAN BE DONE BY SIMPLY CHANGING VARIABLE 'N'.

12.8 WAIT FOR INTERRUPT ROUTINE

THIS ROUTINE PROVIDES A VARIABLE TIME LIMIT DURING WHICH RK11 INTERRUPT MAY OCCUR. THE IS
WAT.INT .N N=1 TO 1777777 (OCTAL)
WAITING TIME=7.5 TIMES(X) N US FOR 11/20, 1.5N US

FOR 11/45 UPON ENTERING THE ROUTINE CPU PRIORITY IS DROPPED SO THAT RK11 CAN INTERRUPT.

12.9 OTHER ROUTINES

THERE ARE OTHER COMMONLY USED ROUTINES AS LISTED BELOW.

\$TYPE:
TYPE ROUTINE FOR TYPING OUT ASCII STRINGS.
LOCATED AT "\$TYPE"
CALLED BY "TYPE"

\$TYPOC:
ROUTINE FOR TYPING OUT OCTAL NUMBERS.
LOCATED AT "\$TYPOC"
CALLED BY "TYPOC"

\$TYPDS:
ROUTINE FOR TYPING OUT DECIMAL NUMBERS.
LOCATED AT "\$TYPDS"
CALLED BY "TYPDS"

\$RDLIN:
ROUTINE FOR INPUTTING ASCII STRINGS FROM TTY.
LOCATED AT "\$RDLIN"
CALLED BY "RDLIN"

\$ERRTYP:
ROUTINE FOR TYPING OUT ERROR MESSAGES.
LOCATED AT \$ERRTYP
CALLED BY "JSR \$ERRTYP"

\$PWDRN:
ROUTINE FOR HANDLING POWER FAILURE.
LOCATED AT \$PWDRN
CALLED WHEN THERE IS A POWER FAILURE.

\$PWRUP:
ROUTINE FOR HANDLING POWER UP AFTER A POWER FAIL.
LOCATED AT \$PWRUP
CALLED WHEN POWER RETURNS AFTER HAVING GONE DOWN.

13.0 UNEXPECTED TIMEOUTS AND RK11 INTERRUPTS

WHEN AN UNEXPECTED TIMEOUT OCCURS, THE PC AT WHICH TIME OUT OCCURED IS TYPED OUT AND THE PROGRAM HALTS. IF IT IS INTACT, IT CAN BE RESTARTED BY PRESSING CONTINUE.

IF AN UNEXPECTED RK11 INTERRUPT OCCURS THE PROGRAM TYPES OUT THE PC AT WHICH THE INTERRUPT CAME IN AND THEN HALTS. PRESSING CONTINUE WOULD RESTART THE PROGRAM FROM BEGINING. SW 9- LOOPING CAITY IS PROVIDED AS A TROUBLE SHOOTING AID.

14.0 QUICK VERIFYING MODE

THE FIRST PASS OF THE PROGRAM IS A QUICK VERIFYING MODE. ALL THE TESTS ARE DONE ONLY ONCE, ON SUBSEQUENT PASSES THE TESTS ARE ITERATED (NORMALLY 50 TIMES, 5 IN SOME CASES). THUS THE FIRST PASS TAKES A SHORTER TIME TO COMPLETE, WHEREAS SUBSEQUENT PASSES TAKE MORE TIME.

z

852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893

```
.TITLE MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2
;*COPYRIGHT (C) 1974,1977
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*PROGRAM BY JIM KAPADIA
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
;*
;*PROGRAM REVISED BY TOM SAWYER, MARCH, 1976
;*REVISED BY CHUCK HESS, AUGUST, 1976
.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;*      SWITCH      USE
;*      -----      -----
;*      15          HALT ON ERROR
;*      14          LOOP ON TEST
;*      13          INHIBIT ERROR TYPEOUTS
;*      12          CYCLE ON ERROR TO PREVIOUS 'SCOPE' STATEMENT
;*      11          INHIBIT ITERATIONS
;*      10          TESTING ON SIMULATOR
;*      9           LOOP ON ERROR
;*      8           LOOP ON TEST IN SWR<7:0>
;*      6           DROP THE DRIVE IF MORE THAN 5 ERRORS
;*
;*****
;YOU ARE ADVISED TO READ THE DOCUMENT BEFORE USING THIS PROGRAM.
;ON GETTING AN ERROR REFER TO THE LISTINGS AT THE PC POINTED
```

```
894 ;OUT IN THE ERROR MESSAGE. ADJACENT ERROR MESSAGES IF FOLLOWED
895 ;CAREFULLY COULD LEAD TO AN EASY PINPOINTING OF THE FAULT
896
897 ;*****
898 .SBTTL BASIC DEFINITIONS
899
900 ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
901 001100 STACK= 1100
902 .EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
903 .EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL
904
905 ;*MISCELLANEOUS DEFINITIONS
906 000011 HT= 11 ;;CODE FOR HORIZONTAL TAB
907 000012 LF= 12 ;;CODE FOR LINE FEED
908 000015 CR= 15 ;;CODE FOR CARRIAGE RETURN
909 000200 CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
910 177776 PS= 177776 ;;PROCESSOR STATUS WORD
911 .EQUIV PS,PSW
912 177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
913 177772 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
914 177570 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
915 177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
916
917 ;*GENERAL PURPOSE REGISTER DEFINITIONS
918 000000 R0= X0 ;;GENERAL REGISTER
919 000001 R1= X1 ;;GENERAL REGISTER
920 000002 R2= X2 ;;GENERAL REGISTER
921 000003 R3= X3 ;;GENERAL REGISTER
922 000004 R4= X4 ;;GENERAL REGISTER
923 000005 R5= X5 ;;GENERAL REGISTER
924 000006 R6= X6 ;;GENERAL REGISTER
925 000007 R7= X7 ;;GENERAL REGISTER
926 000006 SP= X6 ;;STACK POINTER
927 000007 PC= X7 ;;PROGRAM COUNTER
928
929 ;*PRIORITY LEVEL DEFINITIONS
930 000000 PR0= 0 ;;PRIORITY LEVEL 0
931 000040 PR1= 40 ;;PRIORITY LEVEL 1
932 000100 PR2= 100 ;;PRIORITY LEVEL 2
933 000140 PR3= 140 ;;PRIORITY LEVEL 3
934 000200 PR4= 200 ;;PRIORITY LEVEL 4
935 000240 PR5= 240 ;;PRIORITY LEVEL 5
936 000300 PR6= 300 ;;PRIORITY LEVEL 6
937 000340 PR7= 340 ;;PRIORITY LEVEL 7
938
939 ;*'SWITCH REGISTER' SWITCH DEFINITIONS
940 100000 SW15= 100000
941 040000 SW14= 40000
942 020000 SW13= 20000
943 010000 SW12= 10000
944 004000 SW11= 4000
945 002000 SW10= 2000
946 001000 SW09= 1000
947 000400 SW08= 400
948 000200 SW07= 200
949 000100 SW06= 100
```



```
950      000040      SW05= 40
951      000020      SW04= 20
952      000010      SW03= 10
953      000004      SW02= 4
954      000002      SW01= 2
955      000001      SW00= 1
956      .EQUIV SW09,SW9
957      .EQUIV SW08,SW8
958      .EQUIV SW07,SW7
959      .EQUIV SW06,SW6
960      .EQUIV SW05,SW5
961      .EQUIV SW04,SW4
962      .EQUIV SW03,SW3
963      .EQUIV SW02,SW2
964      .EQUIV SW01,SW1
965      .EQUIV SW00,SW0
966
967      ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
968      100000      BIT15= 100000
969      040000      BIT14= 40000
970      020000      BIT13= 20000
971      010000      BIT12= 10000
972      004000      BIT11= 4000
973      002000      BIT10= 2000
974      001000      BIT09= 1000
975      000400      BIT08= 400
976      000200      BIT07= 200
977      000100      BIT06= 100
978      000040      BIT05= 40
979      000020      BIT04= 20
980      000010      BIT03= 10
981      000004      BIT02= 4
982      000002      BIT01= 2
983      000001      BIT00= 1
984      .EQUIV BIT09,BIT9
985      .EQUIV BIT08,BIT8
986      .EQUIV BIT07,BIT7
987      .EQUIV BIT06,BIT6
988      .EQUIV BIT05,BIT5
989      .EQUIV BIT04,BIT4
990      .EQUIV BIT03,BIT3
991      .EQUIV BIT02,BIT2
992      .EQUIV BIT01,BIT1
993      .EQUIV BIT00,BIT0
994
995      ;*BASIC "CPU" TRAP VECTOR ADDRESSES
996      000004      ERRVEC= 4          ;;TIME OUT AND OTHER ERRORS
997      000010      RESVEC= 10         ;;RESERVED AND ILLEGAL INSTRUCTIONS
998      000014      TBITVEC=14        ;; "T" BIT
999      000014      TRTVEC= 14         ;;TRACE TRAP
1000     000014      BPTVEC= 14         ;;BREAKPOINT TRAP (BPT)
1001     000020      IOTVEC= 20         ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
1002     000024      PWRVEC= 24         ;;POWER FAIL
1003     000030      EMTVEC= 30         ;;EMULATOR TRAP (EMT) **ERROR**
1004     000034      TRAPVEC=34        ;; "TRAP" TRAP
1005     000060      TKVEC= 60          ;;TTY KEYBOARD VECTOR
```

```

1006      000064      TPVEC= 64          ;;TTY PRINTER VECTOR
1007      000240      PIRQVEC=240       ;;PROGRAM INTERRUPT REQUEST VECTOR
1008
1009      .SBTTL TRAP CATCHER
1010
1011      .=0
1012      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
1013      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
1014      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
1015      000174      000174      .=174
1016      000176      000000      DISPREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER
1017      000176      000000      SWREG: .WORD 0          ;;SOFTWARE SWITCH REGISTER
1018      000200      000137      002636 .SBTTL STARTING ADDRESS(ES)
1019      .SBTTL JMP @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM
1020      .SBTTL ACT11 HOOKS
1021
1022      ;*****
1023      ;HOOKS REQUIRED BY ACT11
1024      $SVPC=.          ;SAVE PC
1025      .=46
1026      $ENDAD          ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
1027      .=52
1028      .WORD 0          ;;2)SET LOC.52 TO ZERO
          .=$SVPC          ;; RESTORE PC
  
```


1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084

001100
001100 000000
001102 000
001103 000
001104 000000
001106 000000
001110 000000
001112 000000
001114 000
001115 001
001116 000000
001120 000000
001122 000000
001124 000000
001126 000000
001130 000000
001132 000000
001134 000
001135 000
001136 000000
001140 177570
001142 177570
001144 177560
001146 177562
001150 177564
001152 177566
001154 000
001155 002
001156 012
001157 000
001160 000000
001162 000000
001164 000000
001166 000000
001170 000000
001172 000000
001174 000000
001176 000000
001200 000000
001202 000000
001204 000000
001206 000000
001210 000000
001212 077
001213 015
001214 000012
001216 005015 051104 053111

.SBTTL COMMON TAGS

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.
.=1100
SCMTAG: .WORD 0
SPASS: .WORD 0
STSTNM: .BYTE 0
SERFLG: .BYTE 0
SICNT: .WORD 0
SLPADR: .WORD 0
SLPERR: .WORD 0
SERTTL: .WORD 0
SITEMB: .BYTE 0
SERMAX: .BYTE 1
SERRPC: .WORD 0
SGDADR: .WORD 0
\$BDADR: .WORD 0
\$GDDAT: .WORD 0
\$BDDAT: .WORD 0
SAUTOB: .BYTE 0
\$INTAG: .BYTE 0
SWR: .WORD DSWR
DISPLAY: .WORD DDISP
\$TKS: 177560
\$TKB: 177562
\$TPS: 177564
\$TPB: 177566
\$NULL: .BYTE 0
\$FILLS: .BYTE 2
\$FILLC: .BYTE 12
\$TPFLG: .BYTE 0
\$REGAD: .WORD 0
\$REG0: .WORD 0
\$REG1: .WORD 0
\$REG2: .WORD 0
\$REG3: .WORD 0
\$REG4: .WORD 0
\$REG5: .WORD 0
\$REG6: .WORD 0
\$REG7: .WORD 0
\$REG10: .WORD 0
\$REG11: .WORD 0
\$TIMES: 0
\$ESCAPE: 0
\$QUES: .ASCII /?/
\$CRLF: .ASCII <15>
\$LF: .ASCII <12>

MSG1: .ASCII <15><12>/DRIVE PRESNT/

:: START OF COMMON TAGS
:: CONTAINS PASS COUNT
:: CONTAINS THE TEST NUMBER
:: CONTAINS ERROR FLAG
:: CONTAINS SUBTEST ITERATION COUNT
:: CONTAINS SCOPE LOOP ADDRESS
:: CONTAINS SCOPE RETURN FOR ERRORS
:: CONTAINS TOTAL ERRORS DETECTED
:: CONTAINS ITEM CONTROL BYTE
:: CONTAINS MAX. ERRORS PER TEST
:: CONTAINS PC OF LAST ERROR INSTRUCTION
:: CONTAINS ADDRESS OF 'GOOD' DATA
:: CONTAINS ADDRESS OF 'BAD' DATA
:: CONTAINS 'GOOD' DATA
:: CONTAINS 'BAD' DATA
:: RESERVED--NOT TO BE USED
:: AUTOMATIC MODE INDICATOR
:: INTERRUPT MODE INDICATOR
:: ADDRESS OF SWITCH REGISTER
:: ADDRESS OF DISPLAY REGISTER
:: TTY KBD STATUS
:: TTY KBD BUFFER
:: TTY PRINTER STATUS REG. ADDRESS
:: TTY PRINTER BUFFER REG. ADDRESS
:: CONTAINS NULL CHARACTER FOR FILLS
:: CONTAINS # OF FILLER CHARACTERS REQUIRED
:: INSERT FILL CHARS. AFTER A 'LINE FEED'
:: "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
:: CONTAINS THE ADDRESS FROM
:: WHICH (\$REG0) WAS OBTAINED
:: CONTAINS ((\$REGAD)+0)
:: CONTAINS ((\$REGAD)+2)
:: CONTAINS ((\$REGAD)+4)
:: CONTAINS ((\$REGAD)+6)
:: CONTAINS ((\$REGAD)+10)
:: CONTAINS ((\$REGAD)+12)
:: CONTAINS ((\$REGAD)+14)
:: CONTAINS ((\$REGAD)+16)
:: CONTAINS ((\$REGAD)+20)
:: CONTAINS ((\$REGAD)+22)
:: MAX. NUMBER OF ITERATIONS
:: ESCAPE ON ERROR ADDRESS
:: QUESTION MARK
:: CARRIAGE RETURN
:: LINE FEED

```

1085 001224 020105 051120 051505
1086 001232 052116 000
1087 001236
1088 001236 005015 047516 042516 MSG2: .EVEN
      001244 000 .ASCIZ <15><12>/NONE/
1090
1091 001245 015 041412 052116 MSG3: .ASCIZ <15><12>/CNT RDY DIDN'T SET/
1092 001252 051040 054504 042040
1093 001260 042111 023516 020124
1094 001266 042523 000124
1095
1096 001272 005015 051104 053111 MSG4: .ASCIZ <15><12>/DRIVE /
1097 001300 020105 000
1098
1099 001303 015 040412 046114 MSG5: .ASCII <15><12>/ALL DRVS/
1100 001310 042040 053122 123
1101
1102 001315 040 051104 050117 MSG6: .ASCIZ / DROPD/<15><12>
1103 001322 006504 000012
1104 .EVEN
1105
1106 :RK11 REGISTERS
1107 :IF FOR ANY REASON THE REGISTER ADDRESSES ARE DIFFERENT FROM THESE
1108 :(GIVEN BELOW), THE CONTENTS OF THE APPROPRIATE POINTERS SHOULD BE
1109 :MODIFIED SO THAT THE CORRECT ADDRESS IS USED.
1110 :
1111 :
1112 001326 177400 RKDS: .EVEN 177400
1113 001330 177402 RKER: 177402
1114 001332 177404 RKCS: 177404
1115 001334 177406 RKWC: 177406
1116 001336 177410 RKBA: 177410
1117 001340 177412 RKDA: 177412
1118 001342 177416 RKDB: 177416
1119
1120
1121 :TAGS AND GENERAL DATA AREA
1122 :
1123 :
1124 :
1125 001344 000000 SIMUL: 0 ;FLAG TO BE SET TO 1 WHEN ON SIMULATOR
1126 001346 000000 FTITLE: 0 ;FLAG FOR PRINTING PROGRAM TITLE
1127 001350 000000 DRIVAD: 0 ;CONTAINS ADDRESS OF THE DRIVE UNDER TEST
1128 001352 000000 DRVDON: 0 ;CONTAINS THE NUMBER OF DRIVES CHECKED.
1129 ;IT IS INCREMENTED EACH TIME THE TESTS FOR
1130 ;A DRIVE IS COMPLETED.
1131 001354 000000 DRVPTR: 0 ;CONTAINS THE POINTER TO THE DRIVE FLAG (DRIVED
1132 ;-DRIVE7) OF THE DRIVE TO BE CHECKED NEXT.
1133 001356 000000 INDX1: 0 ;GENERAL INDEX FOR KEEPING COUNT
1134 001360 000000 INDX2: 0 ;GENERAL INDEX
1135 001362 000000 COUNT: 0 ;GENERAL COUNT REGISTER
1136 001364 000000 COUNT1: 0 ;COUNT REGISTER USED FOR 'DRESET' SUBROUTINE
1137 001366 000000 TIMER: 0 ;TIMER REGISTER
1138 001370 000000 EFLG1: 0 ;SET, TO INDICATE A PARTICULAR
1139 ;ERROR CONDITION
1140

```


1141	001372	000100	SEEK0:	100	:CONTAINS ADDRESS OF CYLINDER 2
1142	001374	001000	SEEK1:	1000	:CONTAINS ADDRESS OF CYLINDER 20
1143	001376	014500	SEEK2:	14500	:CONTAINS ADDRESS OF CYLINDER 312
1144	001400	000200	RKPRI:	200	:CONTAINS THE CPU LEVEL AT WHICH
1145					:RK11 NORMALLY INTERRUPTS. THIS WORD
1146					:SHOULD BE CHANGED IF RK11 IS DESINGATED
1147					:A BR LEVEL OTHER THAN 5. E.G. IF IT IS CHANGED
1148					:TO 6, THIS WORD SHOULD BE CHANGED TO 240.
1149	001402	000220	RKVEC:	220	:CONTAINS THE NORMAL VECTOR ADDRESS TO WHICH
1150					:RK11 INTERRUPTS. IF THIS IS NOT SO, CHANGE
1151					:THIS WORD TO CONTAIN MODIFIED VECTOR ADDRESS.
1152	001404	000000	FFLAG:	0	
1153	001406	000000	ODDEVN:	0	:USED TO DETERMINE WHICH OF RK-05F DRIVES ACTIVE
1154					:0 IF EVEN DRIVE
1155					:-1 IF ODD DRIVE
1156	001410	000000	DDPCH:	0	:IF PROGRAM LOADED FROM RK05, CONTAINS
1157					:ADDRESS OF DRIVE WITH RKDP PACK
1158	001412	000000	DRIVS:	0	:CONTAINS THE NUMBER OF DRIVES PRESENT
1159					
1160					
1161					
1162					
1163					:THE FLAGS BELOW (BIT 0) ARE SET TO 1 TO INDICATE THAT A PARTICULAR DRIVE
1164					:IS PRESENT AND IS TO BE TESTED. BIT 12, IF SET, INDICATES THAT THE DRIVE
1165					:WAS DROPPED AFTER MAXIMUM ALLOWABLE NUMBER OF ERRORS OCCURED ON THAT
1166					:DRIVE (SW 6 SET).
1167					:IF MORE THAN 5 ERRORS OCCUR IN THE HARDWARE POLLING TEST (LAST)
1168					:THEN ALL DRIVES ARE DROPPED. BUT BIT 12 IS NOT SET.
1169					
1170	001414	000000	DRIV0:	0	:FLAG SET TO 1 WHEN DRIVE 0 PRESENT
1171	001416	000000	DRIV1:	0	:FOR DRIVE 1
1172	001420	000000	DRIV2:	0	:FOR DRIVE 2
1173	001422	000000	DRIV3:	0	:FOR DRIVE 3
1174	001424	000000	DRIV4:	0	:FOR DRIVE 4
1175	001426	000000	DRIV5:	0	:FOR DRIVE 5
1176	001430	000000	DRIV6:	0	:FOR DRIVE 6
1177	001432	000000	DRIV7:	0	:FOR DRIVE 7
1178					
1179	001434	000000	T56FLG:	0	
1180	001436	000000	PHYDRV:	0	
1181	001440	000000	SIZYET:	0	

1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237

001442

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;;POINTS TO THE ERROR MESSAGE
;* DH ;;POINTS TO THE DATA HEADER
;* DT ;;POINTS TO THE DATA
;* DF ;;POINTS TO THE DATA FORMAT

\$ERRTB:

THE ERROR ITEMS TABLE CONSISTS OF ALL THE POSSIBLE ERROR MESSAGES
USED IN THIS PROGRAM. AN ERROR CALL IN THE PROGRAM CORRESPONDS TO
THE ITEM NUMBER IN THE ERROR TABLE. THUS 'ERROR 1' IN THE
PROGRAM CORRESPONDS TO 'ITEM 1' IN THE ERROR TABLE.
'EM###' IS THE POINTER TO THE ERROR MESSAGE WHICH WILL BE TYPED
OUT IN CASE THAT ERROR WERE TO OCCUR. THUS FOR 'ERROR 1' THE ERROR
MESSAGE TYPE OUT WILL BE 'TIME OUT ON RK11 REG'.
'DH###' IS THE POINTER TO THE HEADER BLOCK WHICH WILL BE TYPED OUT
IMMEDIATELY AFTER THE ERROR MESSAGE.
'DT###' SERVES AS A POINTER TO THE MEMORY LOCATIONS WHERE
THE INFORMATION RELEVANT TO THE ERROR TYPE OUTS (LIKE PC, CONTENTS
OF RKCS ETC.) WILL BE PICKED UP FROM.
THE LAST ROW CONTAINING '0' SERVES AS A TERMINATOR.
EXAMPLE:
IF ON RUNNING THIS PROGRAM A TIMEOUT WERE TO OCCUR ON ADDRESSING RKDS
(177400), BECAUSE OF SOME FAULT, THE FOLOWING TYPEOUT WOULD
OCCUR ON THE TELETYPE.

```
TIME OUT ON RK11 REG
PC      REG
##### 177400
```

NOTE THAT ##### WOULD BE THE ACTUAL PC WHERE 'ERROR 1' IS LOCATED.

THE ERROR HANDLER IS LOCATED AT '\$ERROR'. THE ERROR CALL IS AN 'EMT'
INSTRUCTION WITH ITS LOWER BYTE ENCODED TO PROVIDE INDEXING TO THE
ITEMS IN THE ERROR TABLE.
THUS 'ERROR 1' IS 104001
'ERROR 103' IS 104126 ETC.

;ERROR ITEMS TABLE


```
1406      ;ITEM 31
1407
1408 001742 026452      EM54  ;'CNTRL RDY' DIDN'T SET ON DOING WRITE/FMT STARTING
1409      ;FROM <DSK-ADRES>
1410 001744 032374      DH54  ;PC      RKCS      RKER      RKDS      RKDA
1411      ;DRV#    CYL    <DSK-ADRES>      SUR      SECTR
1412 001746 031774      DT54  ;$ERRPC $REG0    $REG1    $REG2    $REG3
1413      ;$REG4 $REG5    $REG6    $REG>
1414 001750 000000      0
1415
1416      ;ITEM 32
1417
1418 001752 026544      EM55  ;'HE' OR 'ERR' ON WRITE/FMT STARTING FROM
1419      ;<DSK-ADRES>
1420 001754 032374      DH54  ;PC      RKCS      RKER      RKDS      RKDA
1421      ;DRV#    CYL    <DSK-ADRES>      SUR      SECTR
1422 001756 031774      DT54  ;$ERRPC $REG0    $REG1    $REG2    $REG3
1423      ;$REG4 $REG5    $REG6    $REG7
1424 001760 000000      0
1425
1426      ;ITEM 33
1427
1428 001762 026623      EM56  ;RKDA INCREMENTED WRONG ON WRITE OR WRITE FORMAT
1429 001764 032503      DH56  ;PC      EXPCT:  DRV#    CYL      SUR      SECTR
1430      ;RECV:  DRV#    CYL      SUR      SECTR
1431 001766 031774      DT54  ;$ERRPC $REG0    $REG1    $REG2    $REG3
1432      ;$REG4 $REG5    $REG6    $REG7
1433 001770 000000      0
1434
1435      ;ITEM 34
1436
1437 001772 026662      EM57  ;RKWC DIDN'T OVERFLOW ON WRITE OR WRITE FORMAT
1438 001774 032075      DH5   ;PC      RECV
1439 001776 031724      DT1   ;$ERRPC $REG0
1440 002000 000000      0
1441
1442      ;ITEM 35
1443
1444 002002 026720      EM60  ;RKBA INCREMENTED WRONG ON WRITE OR WRITE FORMAT
1445 002004 032047      DH4   ;PC      EXPCT  RECV
1446 002006 031732      DT2   ;$ERRPC $REG0    $REG1
1447 002010 000000      0
1448
1449      ;ITEM 36
1450
1451 002012 026757      EM61  ;RKER SET, ON WRITE/READ/FORMAT
1452 002014 032155      DH30  ;PC      RKCS      RKER      RKDS
1453 002016 031762      DT26  ;$ERRPC $REG0    $REG1    $REG2
1454 002020 000000      0
1455
1456      ;ITEM 37
1457
1458 002022 027014      EM62  ;RKDB ERROR
1459 002024 032047      DH4   ;PC      EXPCT  RECV
1460 002026 031732      DT2   ;$ERRPC $REG0    $REG1
1461 002030 000000      0
```


1462									
1463			:ITEM	40					
1464									
1465	002032	027026		EM63	:RKDA INCREMENTED WRONG ON READ OR READ FORMAT				
1466	002034	032503		DH56	:PC EXPCT: DRV# CYL SUR SECTR				
1467					:RECV: DRV# CYL SUR SECTR				
1468	002036	031774		DT54	:\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3				
1469					:\$REG4 \$REG5 \$REG6 \$REG7				
1470	002040	000000		0					
1471									
1472			:ITEM	41					
1473									
1474	002042	027072		EM64	:RKWC DID NOT OVERFLOW ON READ OR READ FORMAT				
1475	002044	032610		DH64	:PC RKWC RKDA				
1476	002046	031732		DT2	:\$ERRPC \$REG0 \$REG1				
1477	002050	000000		0					
1478									
1479			:ITEM	42					
1480									
1481	002052	027135		EM65	:RKBA INCREMENTED WRONG ON READ OR READ FORMAT				
1482	002054	032047		DH4	:PC EXPCT RECV				
1483	002056	031732		DT2	:\$ERRPC \$REG0 \$REG1				
1484	002060	000000		0					
1485									
1486			:ITEM	43					
1487									
1488	002062	027201		EM66	:INCORRECT HEADER FROM 'SECTOR'				
1489	002064	032634		DH66	:PC SECTR EXPCT RECV				
1490	002066	031762		DT26	:\$ERRPC \$REG0 \$REG1 \$REG2.				
1491	002070	000000		0					
1492									
1493			:ITEM	44					
1494									
1495	002072	027240		EM67	:DATA ERROR				
1496	002074	032672		DH67	:PC EXPCT RECV DSK-ADRES				
1497	002076	031762		DT26	:\$ERRPC \$REG0 \$REG1 \$REG2				
1498	002100	000000		0					
1499									
1500			:ITEM	45					
1501									
1502	002102	027253		EM70	: 'CNTRL RDY' DIDN'T SET ON DOING READ/FMT STARTING				
1503					: FROM <DSK-ADRES>				
1504	002104	032374		DH54	:PC RKCS RKER RKDS RKDA				
1505					:DRV# CYL <DSK-ADRES> SUR SECTR				
1506	002106	031774		DT54	:\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3				
1507					:\$REG4 \$REG5 \$REG6 \$REG7				
1508	002110	000000		0					
1509									
1510			:ITEM	46					
1511									
1512	002112	027344		EM71	: 'HE' OR 'ERR' BIT SET ON READ/FMT STARTING				
1513					: FROM <DSK-ADRES>				
1514	002114	032374		DH54	:PC RKCS RKER RKDS RKDA				
1515					:DRV# CYL <DSK-ADRES> SUR SECTR				
1516	002116	031774		DT54	:\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3				
1517					:\$REG4 \$REG5 \$REG6 \$REG7				

1518	002120	000000	0						
1519									
1520			:ITEM	47					
1521									
1522	002122	027422	EM72		:WRONG DRIVE ID IN RKDS AFTER SEEK				
1523	002124	032047	DH4		:PC EXPCT RECVD				
1524	002126	031732	DT2		:SERRPC \$REG0 \$REG1				
1525	002130	000000	0						
1526									
1527			:ITEM	50					
1528									
1529	002132	027464	EM73		:HARDWARE POLL, DRIVE ID BITS(13-15) SHOULD BE CLEAR				
1530	002134	032213	DH34		:PC RKDS				
1531	002136	031732	DT2		:SERRPC \$REG0				
1532	002140	000000	0						
1533									
1534			:ITEM	51					
1535									
1536	002142	027536	EM74		:HARDWARE POLL, INTERRUPTING DRIVE # NOT PRESENT				
1537	002144	032732	DH74		:PC DRIVE #				
1538	002146	031724	DT1		:SERRPC \$REG0				
1539	002150	000000	0						
1540									
1541			:ITEM	52					
1542									
1543	002152	027606	EM75		: 'DRIVE #' DID NOT INTERRUPT DURING HARDWARE POLL				
1544	002154	032732	DH74		:PC DRIVE #				
1545	002156	031724	DT1		:SERRPC \$REG0				
1546	002160	000000	0						
1547									
1548			:ITEM	53					
1549									
1550	002162	027656	EM76		:SCP DID NOT SET AFTER WAS DONE				
1551	002164	033106	DH117		:PC RKCS				
1552	002166	031724	DT1		:SERRPC \$REG0				
1553	002170	000000	0						
1554									
1555			:ITEM	54					
1556									
1557	002172	027721	EM77		:RKDA CHANGED AFTER 'DRIVE RESET'				
1558	002174	032047	DH4		:PC EXPCT RECVD				
1559	002176	031732	DT2		:SERRPC \$REG0 \$REG1				
1560	002200	000000	0						
1561									
1562			:ITEM	55					
1563									
1564	002202	027756	EM100		:DATA ERROR AT WORD#				
1565	002204	032753	DH100		:PC WORD# EXPCT RECVD				
1566	002206	031762	DT26		:SERRPC \$REG0 \$REG1 \$REG2				
1567	002210	000000	0						
1568									
1569			:ITEM	56					
1570									
1571	002212	030001	EM101		:CNTRL RDY DID NOT SET AFTER READ CHECK				
1572	002214	032327	DH44		:PC RKCS RKER RKDS RKDA				
1573	002216	031742	DT20		:SERRPC \$REG0 \$REG1 \$REG2 \$REG3				

1574	002220	000000	0		
1575					
1576			:ITEM	57	
1577					
1578	002222	030043	EM102	:	'ERR' OF 'HE' SET ON READ CHECK
1579	002224	032155	DH30	:	PC RKCS RKER RKDS
1580	002226	031762	DT26	:	\$ERRPC \$REG0 \$REG1 \$REG2
1581	002230	000000	0		
1582					
1583			:ITEM	60	
1584					
1585	002232	030067	EM103	:	'CSE' ON READ CHECK
1586	002234	033010	DH103	:	PC RKER
1587	002236	031724	DT1	:	\$ERRPC \$REG0
1588	002240	000000	0		
1589					
1590			:ITEM	61	
1591					
1592	002242	030105	EM104	:	RKWC DID NOT OVERFLOW ON READ CHECK OR WRITE CHECK
1593	002244	033024	DH104	:	PC RECVD RKCS
1594	002246	031732	DT2	:	\$ERRPC \$REG0 \$REG1
1595	002250	000000	0		
1596					
1597			:ITEM	62	
1598					
1599	002252	030156	EM105	:	RKDA INCREMENTED WRONG ON READ CHECK
1600	002254	032047	DH4	:	PC EXPCT RECVD
1601	002256	031732	DT2	:	\$ERRPC \$REG0 \$REG1
1602	002260	000000	0		
1603					
1604			:ITEM	63	
1605					
1606	002262	030214	EM106	:	RKBA CHANGED AFTER READ CHECK
1607	002264	032047	DH4	:	PC EXPCT RECVD
1608	002266	031732	DT2	:	\$ERRPC \$REG0 \$REG1
1609	002270	000000	0		
1610					
1611			:ITEM	64	
1612					
1613	002272	030245	EM107	:	MEMORY WORD CHANGED AFTER READ CHECK
1614	002274	033050	DH107	:	PC LOC EXPCT RECVD
1615	002276	031762	DT26	:	\$ERRPC \$REG0 \$REG1 \$REG2
1616	002300	000000	0		
1617					
1618			:ITEM	65	
1619					
1620	002302	030306	EM110	:	CNTRL RDY DID NOT SET AFTER WRITE CHECK
1621	002304	032327	DH44	:	PC RKCS RKER RKDS RKDA
1622	002306	031742	DT20	:	\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
1623	002310	000000	0		
1624					
1625			:ITEM	66	
1626					
1627	002312	030351	EM111	:	HE OR ERR BIT SET AFTER DOING WRITE CHECK
1628	002314	032155	DH30	:	PC RKCS RKER RKDS
1629	002316	031762	DT26	:	\$ERRPC \$REG0 \$REG1 \$REG2

1630	002320	000000	0		
1631					
1632			:ITEM	67	
1633					
1634	002322	030376	EM112	;WRITE CHECK ERROR	
1635	002324	032155	DH30	:PC	RKCS RKER RKDS
1636	002326	031762	DT26	;\$ERRPC \$REG0	\$REG1 \$REG2
1637	002330	000000	0		
1638					
1639			:ITEM	70	
1640					
1641	002332	030417	EM113	;RKDA INCREMENTED WRONG ON WRITE CHECK	
1642	002334	032047	DH4	:PC	EXPCT RECVD
1643	002336	031732	DT2	;\$ERRPC \$REG0	\$REG1
1644	002340	000000	0		
1645					
1646			:ITEM	71	
1647					
1648	002342	030456	EM114	;RKBA INCREMENTED WRONG ON WRITE CHECK	
1649	002344	032047	DH4	:PC	EXPCT RECVD
1650	002346	031732	DT2	;\$ERRPC \$REG0	\$REG1
1651	002350	000000	0		
1652					
1653			:ITEM	72	
1654					
1655	002352	030515	EM115	;RKBA INCREMENTED WITH IBA SET	
1656	002354	032047	DH4	:PC	EXPCT RECVD
1657	002356	031732	DT2	;\$ERRPC \$REG0	\$REG1
1658	002350	000000	0		
1659					
1660			:ITEM	73	
1661					
1662	002362	030551	EM116	;WRONG MEMORY LOCATION CHANGED WITH IBA SET	
1663	002364	032753	DH100	:PC	WORD# EXPCT RECVD
1664	002366	031762	DT26	;\$ERRPC \$REG0	\$REG1 \$REG2
1665	002370	000000	0		
1666					
1667			:ITEM	74	
1668					
1669	002372	030624	EM117	;RK11 DID NOT INTERRUPT WHEN IDE WAS SET	
1670	002374	033106	DH117	:PC	RKCS
1671	002376	031724	DT1	;\$ERRPC \$REG0	
1672	002400	000000	0		
1673					
1674			:ITEM	75	
1675					
1676	002402	030671	EM120	;RK11 DID NOT INTERRUPT AFTER SEEK WAS INITIATED	
1677	002404	033106	DH117	:PC	RKCS
1678	002406	031724	DT1	;\$ERRPC \$REG0	
1679	002410	000000	0		
1680					
1681			:ITEM	76	
1682					
1683	002412	030744	EM121	;SCP SET BEFORE SEEK COMPLETED	
1684	002414	033106	DH117	:PC	RKCS
1685	002416	031724	DT1	;\$ERRPC \$REG0	

1686	002420	000000	0	
1687				
1688			:ITEM	77
1689				
1690	002422	031002	EM122	:RK11 DID NOT INTERRUPT AFTER SEEK COMPLETED
1691	002424	032155	DH30	:PC RKCS RKER RKDS
1692	002426	031762	DT26	:\$ERRPC \$REG0 \$REG1 \$REG2
1693	002430	000000	0	
1694				
1695			:ITEM	100
1696				
1697	002432	031051	EM123	:CNTRL RESET DID NOT CLEAR 'SCP' BIT
1698	002434	033106	DH117	:PC RKCS
1699	002436	031724	DT1	:\$ERRPC \$REG0
1700	002440	000000	0	
1701				
1702			:ITEM	101
1703				
1704	002442	031110	EM124	:RK11 DID NOT INTERRUPT AFTER READ WAS DONE
1705	002444	033106	DH117	:PC RKCS
1706	002446	031724	DT1	:\$ERRPC \$REG0
1707	002450	000000	0	
1708				
1709			:ITEM	102
1710				
1711	002452	031152	EM125	:CNTRL RESET DID NOT CLEAR REGISTER
1712	002454	032020	DH2	:PC REGADD RECVD
1713	002456	031732	DT2	:\$ERRPC \$REG0 \$REG1
1714	002460	000000	0	
1715				
1716			:ITEM	103
1717				
1718	002462	031211	EM126	:RK11 DID NOT INTERRUPT AT CPU LEVEL
1719	002464	033122	DH126	:PC LEVEL RKCS
1720	002466	031732	DT2	:\$ERRPC \$REG0 \$REG1
1721	002470	000000	0	
1722				
1723			:ITEM	104
1724				
1725	002472	031252	EM127	:RK11 INTERRUPTED AT WRONG CPU LEVEL
1726	002474	033122	DH126	:PC LEVEL RKCS
1727	002476	031732	DT2	:\$ERRPC \$REG0 \$REG1
1728	002500	000000	0	
1729				
1730			:ITEM	105
1731				
1732	002502	031314	EM130	: 'ERR BIT' DID NOT SET IN RKER
1733	002504	033150	DH130	:PC RKCS RKER ERR BIT
1734	002506	031762	DT26	:\$ERRPC \$REG0 \$REG1 \$REG2
1735	002510	000000	0	
1736				
1737				
1738			:ITEM	106
1739				
1740	002512	031351	EM131	:HE OR ERR DID NOT SET
1741	002514	033207	DH131	:PC RKCS RKER

1798	002614	032732	DH74	:PC	DRIVE #	
1799	002616	031724	DT1	;\$ERRPC	\$REGO	
1800	002620	000000	0			
1801						
1802			:ITEM	117		
1803						
1804	002622	025370	EM11	:RKWC	ERROR	
1805	002624	032047	DH4	:PC	EXPCT	RECVD
1806	002626	031732	DT2	;\$ERRPC	\$REGO	\$REG1
1807	002630	000000	0			
1808			:ITEM	120		
1809	002632	031662	EM142			
1810	002634	000000	0			
1811						
1812						
1813						

```

1814 002636 000005 START: RESET ;CLEAR THE BUS
1815 ;:GIVE DRIVES TIME TO LOAD HEADS IN CASE OF AN APT START.
1816 002640 023737 000042 000046 CMP @#42,@#46 ;ARE WE IN ACT11 AUTOMATIC MODE?
1817 002646 001016 BNE STARTA ;NO, SKIP DELAY
1818 002650 005077 176464 CLR @RKDA ;SELECT UNIT 0
1819 002654 012700 000250 MOV #250,R0 ;WAIT FOR..
1820 002660 032777 000200 176440 20$: BIT #200,@RKDS ;DRIVE READY..
1821 002666 001006 BNE STARTA ;IN CASE..
1822 002670 005001 CLR R1 ;OF APT..
1823 002672 005301 DEC R1 ;START, BUT..
1824 002674 001376 BNE -2 ;DON'T WAIT..
1825 002676 005300 DEC R0 ;FOREVER.
1826 002700 001367 BNE 20$
1827 002702 000000 HALT ;RKDS BIT 7 (DRIVE READY) NEVER SET
1828 002704
1829 STARTA:
1830 .SBTTL INITIALIZE THE COMMON TAGS
1831 ;:CLEAR THE COMMON TAGS ($CMTAG) AREA
1832 002704 012706 001100 MOV #$CMTAG,R6 ;:FIRST LOCATION TO BE CLEARED
1833 002710 005026 CLR (R6)+ ;:CLEAR MEMORY LOCATION
1834 002712 022706 001140 CMP #SWR,R6 ;:DONE?
1835 002716 001374 BNE -6 ;:LOOP BACK IF NO
1836 002720 012706 001100 MOV #STACK,SP ;:SETUP THE STACK POINTER
1837 ;:INITIALIZE A FEW VECTORS
1838 002724 012737 022140 000020 MOV $$SCOPE,@#IOTVEC ;:IOT VECTOR FOR SCOPE ROUTINE
1839 002732 012737 000340 000022 MOV #340,@#IOTVEC+2 ;:LEVEL 7
1840 002740 012737 022412 000030 MOV #ERROR,@#EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
1841 002746 012737 000340 000032 MOV #340,@#EMTVEC+2 ;:LEVEL 7
1842 002754 012737 024676 000034 MOV #STRAP,@#TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
1843 002762 012737 000340 000036 MOV #340,@#TRAPVEC+2 ;:LEVEL 7
1844 002770 012737 024776 000024 MOV #SPURDN,@#PWRVEC ;:POWER FAILURE VECTOR
1845 002776 012737 000340 000026 MOV #340,@#PWRVEC+2 ;:LEVEL 7
1846 003004 005037 001206 CLR $TIMES ;:INITIALIZE NUMBER OF ITERATIONS
1847 003010 005037 001210 CLR $ESCAPE ;:CLEAR THE ESCAPE ON ERROR ADDRESS
1848 003014 112737 000001 001115 MOVB #1,$ERMAX ;:ALLOW ONE ERROR PER TEST
1849 003022 012737 003022 001106 MOV #.,$LPADR ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
1850 003030 012737 003030 001110 MOV #.,$LPERR ;:SETUP THE ERROR LOOP ADDRESS
1851 ;:SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1852 ;:EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
1853 003036 013746 000004 MOV @#ERRVEC,-(SP) ;:SAVE ERROR VECTOR
1854 003042 012737 003076 000004 MOV #64$,@#ERRVEC ;:SET UP ERROR VECTOR
1855 003050 012737 177570 001140 MOV #DSWR,SWR ;:SETUP FOR A HARDWARE SWICH REGISTER
1856 003056 012737 177570 001142 MOV #DDISP,DISPLAY ;:AND A HARDWARE DISPLAY REGISTER
1857 003064 022777 177777 176046 CMP #-1,@SWR ;:TRY TO REFERENCE HARDWARE SWR
1858 BNE 66$ ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
1859 ;:AND THE HARDWARE SWR IS NOT = -1
1860 003074 000403 BR 65$ ;:BRANCH IF NO TIMEOUT
1861 003076 012716 003104 64$: MOV #65$, (SP) ;:SET UP FOR TRAP RETURN
1862 003102 000002 RTI
1863 003104 012737 000176 001140 65$: MOV #SWREG,SWR ;:POINT TO SOFTWARE SWR
1864 003112 012737 000174 001142 MOV #DISPREG,DISPLAY
1865 003120 012637 000004 66$: MOV (SP)+,@#ERRVEC ;:RESTORE ERROR VECTOR
1866 003124 023737 000042 000046 CMP @#42,@#46 ;ARE WE IN ACT11 AUTOMATIC MODE?
1867 003132 001416 BEQ 69$ ;YES, SKIP TITLE
1868 .SBTTL TYPE PROGRAM NAME
1869 ;:TYPE THE NAME OF THE PROGRAM IF FIRST PASS

```



```

1870 003134 005227 177777      INC      #-1      ;;FIRST TIME?
1871 003140 001043      BNE      67$      ;;BRANCH IF NO
1872 003142 104401 003200      TYPE     ,68$     ;;TYPE ASCIZ STRING
1873      .SBTTL  GET VALUE FOR SOFTWARE SWITCH REGISTER
1874 003146 005737 000042      TST     @#42     ;;ARE WE RUNNING UNDER XXDP/ACT?
1875 003152 001006      BNE      69$      ;;BRANCH IF YES
1876 003154 023727 001140 000176      CMP     SWR,#SWREG ;;SOFTWARE SWITCH REG SELECTED?
1877 003162 001005      BNE      70$      ;;BRANCH IF NO
1878 003164 104406      GTSWR                    ;;GET SOFT-SWR SETTINGS
1879 003166 000403      BR      70$
1880 003170 112737 000001 001134 69$:  MOVB    #1,$AUTOB  ;;SET AUTO-MODE INDICATOR
1881 003176 70$:
1882 003176 000424      BR      67$      ;;GET OVER THE ASCIZ
1883      ;;68$: .ASCIZ <CRLF>/RK11 LOGIC TEST 2/<15><12>/MAINDEC-11-CZRKKF/<CRLF>
1884      67$:
1885 003250 012700 001410      MOV     #DDPCH,R0
1886 003254 012701 177764      MOV     #-14,R1
1887 003260 005020      1$:    CLR     (R0)+
1888 003262 005201      INC     R1
1889 003264 001375      BNE     1$
1890 003266 005227 177777      INC     #-1      ;FIRST START ?
1891 003272 001020      BNE     START1    ;BR IF NOT
1892 003274 013746 000004      MOV     ERRVEC,-(SP) ;SAVE ERROR VECTOR ADDRESS
1893 003300 012737 003314 000004      MOV     #2$,ERRVEC ;NEW VECTOR ADDRESS
1894 003306 005737 177776      TST     PS        ;SEE IF PROGRAM CAN REFERENCE THE
1895      ;PROCESSOR STATUS WORD
1896 003312 000406      BR      3$        ;BR IF REFERENCE DIDN'T CAUSE TRAP
1897 003314 012737 000140 001400 2$:  MOV     #140,RKPRI ;SETUP INTERRUPTING PRIORITY TO VALUE
1898      ;WHICH WILL ALLOW INTERRUPT ON AN LSI-11
1899 003322 012716 003330      MOV     #3$, (SP) ;SETUP RETURN ADDRESS
1900 003326 000002      RTI                    ;RETURN
1901 003330 012637 000004      3$:    MOV     (SP)+,ERRVEC ;RESTORE THE ERROR VECTOR
1902      ;
1903      ;FIND OUT IF ACT11, 'XXDP' CHAIN OR DUMP MODE
1904      ;
1905 003334 012700 001410      START1: MOV    #DDPCH,R0
1906 003340 012701 177766      MOV    #-12,R1      ;CLEAR OUT DRIVE TABLE AREA
1907 003344 005020      1$:    CLR    (R0)+
1908 003346 005201      INC    R1
1909 003350 001375      BNE    1$
1910 003352 122737 000002 000041      CMPB   #2,41      ;LOADED FROM AN RK05 ?
1911 003360 001166      BNE    ST2        ;BR IF NOT
1912 003362 013737 000040 001410      MOV    40,DDPCH   ;GET DEVICE INDICATOR AND DRIVE ADDRESS OF
1913      ;LOADING RK05
1914 003370 122737 000010 001410      CMPB   #10,DDPCH  ;VALID DRIVE NUMBER IN BYTE 40 ?
1915 003376 101002      BHI    2$        ;BR IF YES
1916 003400 105037 001410      CLRB   DDPCH     ;MUST BE DRIVE ZERO WHICH LOADED
1917      ;THIS PROGRAM
1918 003404 005737 000042      2$:    TST    42      ;CHAIN MODE OR ACT11 AUTO ACCEPT ?
1919 003410 001432      BEQ    4$        ;BR IF NEITHER
1920 003412 005737 001410      TST    DDPCH     ;RUNNING FROM AN RK05 ?
1921 003416 001002      BNE    3$        ;BR IF YES
1922 003420 000137 004262      JMP    ST3       ;FIND OUT NUMBER OF DRIVES
1923 003424 3$:
1924 003424 104401 003432      TYPE   ,65$     ;;TYPE ASCIZ STRING
1925 003430 000413      BR     64$     ;;GET OVER THE ASCIZ
    
```

```

1926
1927 003460
1928 003460 005046
1929 003462 113716 001410
1930 003466 104403
1931 003470 001
1932 003471 000
1933 003472 000137 004262
1934 003476 005227 177777
1935 003502 001115
1936 003504 104401 003512
1937 003510 000411
1938
1939 003534
1940 003534 005046
1941 003536 113716 001410
1942 003542 104403
1943 003544 001
1944 003545 000
1945 003546 104401 003554
1946 003552 000431
1947
1948 003636
1949 003636 104401 003644
1950 003642 000435
1951
1952 003736
1953
1954
1955
1956
1957
1958
1959 003736 012700 001412
1960 003742 012701 177765
1961 003746 005020
1962 003750 005201
1963 003752 001375
1964 003754 104401 003762
1965 003760 000415
1966
1967 004014
1968 004014 104411
1969 004016 012600
1970 004020 012701 177770
1971 004024 112002
1972 004026 042702 177400
1973 004032 012703 001414
1974 004036 012704 177770
1975 004042 012705 000060
1976 004046 020502
1977
1978 004050 001414
1979 004052 005205
1980 004054 005723
1981 004056 005204
    
```

```

::65$: .ASCIZ <15><12>/NOT TESTING DRIVE /
64$:
    CLR -(SP) ;CLEAR WORD ON STACK
    MOV DDPCH,(SP) ;GET DRIVE ADDRESS
    TYPOS ;TYPE THE ADDRESS
    .BYTE 1 ;ONLY 1 CHARACTER
    .BYTE 0 ;SUPRESS LEADING ZEROS
    JMP ST3 ;GET NUMBER OF DRIVES
4$: INC #-1 ;FIRST TIME THROUGH HERE ?
    BNE ST2 ;BR IF NOT
    TYPE ,67$ ;;TYPE ASCIZ STRING
    BR 66$ ;;GET OVER THE ASCIZ
::67$: .ASCIZ <15><12>/TO TEST DRIVE /
66$:
    CLR -(SP) ;CLEAR WORD ON THE STACK
    MOV DDPCH,(SP) ;GET DRIVE ADDRESS
    TYPOS ;TYPE THE DRIVE ADDRESS
    .BYTE 1 ;ONLY 1 CHARACTER
    .BYTE 0 ;SUPRESS LEADING ZEROS
    TYPE ,69$ ;;TYPE ASCIZ STRING
    BR 68$ ;;GET OVER THE ASCIZ
::69$: .ASCIZ / HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT/<15><12>
68$:
    TYPE ,71$ ;;TYPE ASCIZ STRING
    BR 70$ ;;GET OVER THE ASCIZ
::71$: .ASCIZ /WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM/
70$:

:FIND OUT FROM USER WHICH DRIVES (LOGICAL ADDRESSES) ARE TO BE
:TESTED (DRIVES TO BE TESTED ?). IN REPLY THE USER SHOULD TYPE IN THE
:LOGICAL ADDRESSES SEPERATED BY COMMAS. THUS IF 2 DRIVES 0,1 ARE PRESENT:
: 'DRIVS TO B TSTD?'
: '0,1<CR>' A CAR. RET. SHOULD BE TYPED TO TERMINATE THE LIST.
ST2: MOV #DRIVS,R0
    MOV #-13,R1
13$: CLR (R0)+
    INC R1
    BNE 13$
    TYPE ,65$ ;;TYPE ASCIZ STRING
    BR 64$ ;;GET OVER THE ASCIZ
::65$: .ASCIZ <15><12>/DRIVES TO BE TESTED ?/<15><12>
64$:
    RDLIN
    MOV (SP)+,R0 ;GET STARTING ADRES OF ASCII STRING
    MOV #-10,R1 ;SET UP COUNT
1$: MOV (R0)+,R2 ;GET ASCII CHARACTER
    BIC #177400,R2 ;MASK UNWANTED BITS
    MOV #DRIV0,R3
    MOV #-10,R4
    MOV #60,R5
2$: CMP R5,R2 ;WAS THE TYPED IN CHARACTER
    ;A NUMBER BETWEEN 0-7?
    BEQ 3$ ;YES, BRANCH
    INC R5 ;NO, INCREMENT
    TST (R3)+ ;INCREMENT POINTER TO DRV FLAG
    INC R4 ;CHARACTER THAT WAS INPUT
    
```



```

1982 004060 001372          BNE      2$           ;SHOULD BE 0-7, IF ANY OTHER
1983                                ;TYPE ?? & AGAIN ASK FOR
1984                                ;DRIVS TO BE TSTD?
1985 004062 005702          TST      R2           ;IS IT A TERMINATOR?
1986 004064 001461          BEQ      6$           ;YES, EXIT. NO DRIVES INDICATED.
1987 004066                4$:
1988 004066 104401 004074    TYPE     ,67$        ;;TYPE ASCIZ STRING
1989 004072 000402          BR       66$        ;;GET OVER THE ASCIZ
1990                                ;;67$: .ASCIZ /??/
1991 004100                66$:
1992 004100 000716          BR       ST2         ;GO, AGAIN ASK QUESTION
1993 004102 005713          TST     @R3         ;SEE IF ALL READY SELECTED
1994 004104 001370          BNE     4$          ;ERROR IF SELECTED ALL READY
1995 004106 005213          INC     @R3         ;SET UP FLAG FOR THE DRIVE
1996 004110 005237 001412    INC     DRIVS       ;INCREMENT TOTAL NO OF DRIVES PRESENT
1997 004114 111002          MOV     @R0,R2      ;GET NEXT CHAR
1998 004116 042702 177400    BIC     #177400,R2 ;CHARACTER ONLY
1999 004122 022702 000106    CMP     #'F,R2      ;IS IT F?
2000 004126 001026          BNE     8$          ;NO, GO ON
2001 004130 052713 100000    BIS     #BIT15,@R3 ;SET BIT 15 TO SHOW RK05F
2002 004134 032705 000001    BIT     #BIT0,R5    ;EVEN DRIVE?
2003 004140 001407          BEQ     9$          ;EVEN DRIVE SO BRANCH
2004 004142 005763 177776    TST     -2(R3)      ;CHECK EVEN DRIVE
2005 004146 001347          BNE     4$          ;EVEN ALL READY SELECTED
2006 004150 012763 100001 177776  MOV     #BIT15!BIT0,-2(R3) ;SELECT EVEN DRIVE
2007 004156 000406          BR      10$         ;CONTINUE
2008 004160 005763 000002          TST     2(R3)       ;CHECK ODD DRIVE
2009 004164 001340          BNE     4$          ;ERROR IF SELECTED BEFORE
2010 004166 012763 100001 000002  MOV     #BIT15!BIT0,2(R3) ;SELECT ODD DRIVE
2011 004174 005237 001412          INC     DRIVS       ;COUNT DRIVES SELECTED
2012 004200 105720          TST     (R0)+       ;POINT TO NEXT CHAR
2013 004202 000744          BR      11$         ;CHECK FOR COMMA
2014 004204 022702 000054          CMP     #54,R2      ;IS IT A 'COMMA'?
2015 004210 001403          BEQ     5$          ;YES, GO PROCESS NXT WORD
2016 004212 005702          TST     R2          ;NO, IS IT A TERMINATOR?
2017 004214 001324          BNE     4$          ;IF NOT, SOMETHING WRONG
2018                                ;GO ASK QUESTION AGAIN
2019 004216 000404          BR      6$          ;EXIT, IF A TERMINATOR
2020 004220 105720          5$: TST     (R0)+       ;INCREMENT PTR TO NXT BYTE
2021                                ;IN INPUT BUFFER
2022 004222 005201          INC     R1          ;THERE SHOULD BE NO MORE THAN
2023 004224 001277          BNE     1$          ;8 DRIVES, HENCE IF MORE
2024 004226 000717          BR      4$          ;THAN 8 DIFFERENT NOS. TYPED IN, ERROR!
2025                                ;GO AGAIN ASK THE QUESTION
2026
2027 004230 005037 001440          6$: CLR     SIZYET      ;NO SIZING NEEDED
2028 004234 032777 002000 174676  BIT     #SW10,@SWR  ;TESTING ON SIMULATOR?
2029 004242 001003          BNE     7$          ;YES, BRANCH
2030 004244 005037 001344          CLR     SIMUL       ;NO, CLR FLAG
2031 004250 000502          BR      ST4
2032
2033 004252 012737 000001 001344  7$: MOV     #1,SIMUL   ;SET FLAG TO INDICATE SIMULATOR
2034 004260 000476          BR      ST4
2035
2036
2037

```

```

2038                                     :CHECK NUMBER OF DRIVES
2039 004262 012737 177777 001440 ST3:  MOV #-1,SIZYET      ;CHECK FOR RK05F LATER
2040 004270 012737 004442 000004      MOV #5$,@#4      ;SET UP ADRES FOR TIME-OUT VECTOR
2041 004276 005777 175024              TST @RKDS        ;REFERENCE RKDS
2042 004302 005777 175032              TST @RKDA        ;REFERENCE RKDA
2043 004306 012737 004534 000004      MOV #BADTMO,@#4
2044 004314 104401                      TYPE
2045 004316 001216                      MSG1
2046 004320 012700 177770              MOV #-10,R0      ;INITIALIZE COUNT FOR THE 8 DRIVES
2047 004324 005037 001412              CLR DRIVS        ;INITIALIZE # OF DRIVES PRESENT TO 0
2048 004330 005001                      CLR R1           ;INITIALIZE ADDRESS TO DRIVE 0
2049 004332 005004                      CLR R4
2050 004334 012702 001414              MOV #DRIVO,R2
2051 004340 010177 174774              1$:  MOV R1,@RKDA   ;ADDRESS THE DRIVE
2052 004344 020177 174770              CMP R1,@RKDA    ;CHECK, WAS IT ADDRESSED?
2053 004350 001405                      BEQ 3$          ;YES
2054 004352 012703 004356              MOV #2$,R3
2055 004356 004737 021026              2$:  JSR PC,TYERM ;WHILE CHECKING NUMBER OF DRIVE
2056                                     ;UNDER NON-MANUAL MODE :-
2057                                     ;RKDA HAD TO BE ADRESED BUT
2058                                     ;IT WAS FOUND THAT THE DRIVE NO
2059                                     ;THAT WAS WRITTEN COULD NOT BE READ BACK
2060                                     ;CORRECTLY.
2061
2062 004362 000413                      BR 4$
2063 004364 032777 000200 174734 3$:  BIT #200,@RKDS  ;CHECK IF 'DRY' BIT IS SET, IF SET DRIVE IS
2064                                     ;PRESENT
2065                                     ;
2065 004372 001407                      BEQ 4$
2066 004374 104401                      TYPE
2067 004376 001213                      $CRLF
2068 004400 005237 001412              INC DRIVS        ;IF PRESENT, INCREMENT # OF DRIVES
2069 004404 005212                      INC (R2)         ;SET UP FLAG INDICATING THIS DRIVE PRESENT
2070 004406 010446                      MOV R4,-(SP)
2071 004410 104402                      TYPOC
2072 004412 005722                      4$:  TST (R2)+     ;SHIFT POINTER TO NXT DRIVE INDICATOR
2073 004414 062701 020000              ADD #20000,R1   ;SET UP ADDRESS FOR THE NEXT DRIVE
2074 004420 005204                      INC R4           ;HAVE U CHECKED FOR ALL 8 DRIVES
2075 004422 005200                      INC R0
2076 004424 001345                      BNE 1$
2077 004426 005737 001412              TST DRIVS
2078 004432 001011                      BNE ST4
2079 004434 104401                      TYPE
2080 004436 001236                      MSG2
2081 004440 000406                      BR ST4          ;GO CHECK THE DRIVE INDEPENDENT
2082                                     ;CONTROLLER LOGIC
2083 004442 011603                      5$:  MOV (SP),R3   ;GET PC WHERE TIMEOUT OCCURED
2084 004444 022626                      CMP (SP)+,(SP)+ ;RESTORE STACK
2085 004446 062703 177776              ADD #-2,R3
2086 004452 004737 021026              JSR PC,TYERM    ;GO TYPE ERROR MESSAGE
2087                                     ;WHILE CHECKING FOR THE NUMBER OF
2088                                     ;DRIVES IN NON-MANUAL MODE:-
2089                                     ;RKDS AND RKDA HAD TO BE REFERENCED, TIMEOUT
2090                                     ;OCCURED ON REFERENCING.PC IN THE ERROR
2091                                     ;MESSAGE INDICATES WHERE THE TIMEOUT OCCURED.
2092
2093

```



```

2094
2095
2096 004456 005037 001434      ST4:  CLR      T56FLG
2097 004462 005737 001412      TST      DRIVS
2098 004466 001004              BNE      1$
2099 004470 004737 021742      JSR      PC,WATIME
2100 004474 000137 020652      JMP      $EOP
2101 004500 012737 001414 001354 1$:  MOV      #DRIVO,DRVPT
2102 004506 005037 001352      CLR      DRVDON      ;INITIALIZE THE NO. OF DRIVES
2103                                ;THAT HAVE BEEN CHECKED
2104 004512 005037 001350      CLR      DRIVAD      ;INITIALIZE DRIVE ADDRESS TO
2105                                ;THE FIRST DRIVE
2106 004516 012737 004534 000004  MOV      #BADTMO,@#4  ;SET TIME OUT VECTOR FOR UNEXPECTED
2107                                ;TIME OUTS
2108 004524 012777 004600 174650  MOV      #BADINT,@RKVEC ;SET UP RK11 INTERRUPT VECTOR FOR
2109                                ;UNEXPECTED INTERRUPTS FROM RK11
2110 004532 000465              BR       TST1        ;GO TO TEST 1
2111
2112
2113
2114
2115
2116

```

;THIS ROUTINE HANDLES UNEXPECTED TIME OUTS

```

2117 004534 011600      BADTMO: MOV      (SP),RO ;SAVE PC WHERE TIME OUT OCCURED
2118 004536 005740      TST      -(RO)
2119 004540 022626      CMP      (SP)+,(SP)+ ;RESTORE STACK POINTER
2120 004542 104401 004550  TYPE      ,65$      ;;TYPE ASCIZ STRING
2121 004546 000407      BR       64$      ;;GET OVER THE ASCIZ
2122      ;;65$: .ASCIZ <15><12>/TIMOUT,PC=/
2123      64$:
2124 004566 010046      MOV      RO,-(SP)   ;SET UP FOR TYPING OUT PC
2125 004570 104402      TYPOC    ;GO TYPE OUT OCTAL PC
2126 004572 000000      HALT
2127 004574 000137 002636  JMP      @#START
2128
2129
2130

```

;THIS ROUTINE HANDLES UNEXPECTED INTERRUPTS FROM RK11
;SW 9 AND 10 FOR LOOPING ON ERROR
;AND LOOPING ON TEST IN WHICH TIMEOUT
;OCCURRED, ARE PROVIDED.

```

2131
2132
2133
2134
2135
2136 004600 011600      BADINT: MOV      (SP),RO ;SAVE PC WHERE INTERRUPT OCCURED
2137 004602 005740      TST      -(RO)
2138 004604 032777 020000 174326  BIT      #20000,@SWR ;INHIBIT ERROR TYPEOUT?
2139 004612 001014      BNE      1$        ;YES, DON'T TYPE OUT
2140 004614 104401      TYPE
2141 004616 001213      $CRLF
2142 004620 104401      TYPE
2143 004622 026004      EM43              ;TYPE 'UNEXPEXED RK11 INTERRUPT'
2144                                ;TYPE ' AT PC='
2145 004624 104401 004632      TYPE      ,65$      ;;TYPE ASCIZ STRING
2146 004630 000403      BR       64$      ;;GET OVER THE ASCIZ
2147      ;;65$: .ASCIZ /,PC=/
2148      64$:
2149 004640 010046      MOV      RO,-(SP)   ;SET UP FOR TYPING OUT PC

```

```
2150 004642 104402          TYPOC          ;GO TYPE OCTAL PC WHERE BAD
2151                          ;INTERUPT OCCURED
2152 004644 032777 001000 174266 1$:  BIT    #1000,@SWR    ;LOOP ON ERROR?
2153 004652 001403          BEQ    2$          ;NO, BRANCH
2154 004654 022626          CMP    (SP)+,(SP)+ ;YES, REPOSITION STACK
2155 004656 000177 174224          JMP    @SLPADR     ;GO TO THE STARTING ADDRESS OF
2156                          ;THE TEST THAT GAVE UNEXPECTED INTERRUPT
2157 004662 032777 040000 174250 2$:  BIT    #40000,@SWR  ;LOOP ON TEST?
2158 004670 001401          BEQ    3$          ;NO, BRANCH
2159 004672 000002          RTI                    ;YES, LOOP. GO BACK WHER U INTERRUPTED FROM.
2160 004674 000000          3$:  HALT                ;UNEXPECTED INTERRUPT OCCURED AS
2161                          ;INDICATED IN THE TYPE OUT.U CAN LOOP
2162                          ;ON ERROR, TEST,OR INHIBIT TYPEOUT BY
2163                          ;SETTING APPROPRIATE SWITCHES.
2164 004676 000137 002636          JMP    @#START     ;GO BACK TO THE START OF THE
2165                          ;PROGRAM. THUS PRESSING CONTINUE
2166                          ;AFTER THE ABOVE HALT WILL
2167                          ;RESTART THE PROGRAM
2168
2169
2170
2171                          ;RESTART AFTER POWER FAIL
2172                          ;THE PROGRAM WOULD RESTART HERE IF POWER CAME BACK AFTER A FALIURE.
2173
2174 004702 004737 021742          PFSTRT: JSR    PC,WATIME ;KILL TIME
2175
2176
2177
2178                          ;:*****
2179                          ;*TEST 1      CHECK THAT THE DRIVES THAT ARE NOT SPECIFIED ARE NOT FOUND TO BE PRESENT
2180                          ;*THIS TEST CHECKS THAT THE DRIVES THAT ARE NOT SPECIFIED
2181                          ;*(IN RESPONSE TO "DRIVS TO BE TSTD?") ARE NOT FOUND TO BE PRESENT.
2182                          ;*EVERY DRIVE FROM 0 TO 7 IS ADDRESSED. IF A PARTICULAR DRIVE
2183                          ;*GIVES 'DRY' (IN RKDS), IT IS CHECKED THAT THIS DRIVE
2184                          ;*WAS SPECIFIED BY THE USER, IF IT WAS NOT AN ERROR IS
2185                          ;*REPORTED, GIVING THE DRIVE NUMBER. IT IS LIKELY THAT THE USER
2186                          ;*MAY HAVE FORGOTTEN TO PUT THE DRIVE (THAT IS NOT SPECIFIED) ON
2187                          ;*'LOAD'. IF THIS IS THE CASE THEN PUT THIS DRIVE ON 'LOAD'.
2188                          ;*IF THIS IS NOT THE CASE, THERE IS A GENUINE ERROR. (TWO DIFFERENT
2189                          ;*DRIVE ADDRESSES MAY BE RESULTING IN THE SELECTION OF THE SAME
2190                          ;*PHYSICAL DRIVE.)
2191                          ;:*****
2192 004706 000004          TST1:  SCOPE
2193
2194 004710 01270C 001414          MOV    #DRIVO,RO   ;INITIALIZE POINTER
2195 004714 005001          CLR    R1          ;INITIALIZE DRIVE ADRES 0
2196 004716 005002          CLR    R2          ;INITIALIZE DRIVE # 0
2197 004720 005737 001410          1$:  TST    DDPCH    ;LOADED FROM AN RK05 ?
2198 004724 001403          BEQ    2$          ;B IF NOT
2199 004726 120237 001410          CMPB  R2,DDPCH    ;LOADED FROM THIS DRIVE ?
2200 004732 001435          BEQ    4$          ;BR IF YES
2201 004734 010177 174400          2$:  MOV    R1,@RKDA ;ADRES THE DRIVE
2202 004740 105777 174362          TSTB  @RKDS       ;DRIVE READY?
2203 004744 100005          BPL    3$          ;NO, THIS DRIVE NOT PRESENT
2204                          ;YES, THIS DRIVE SELECTED
2205 004746 005710          TST    @RO        ;WAS THIS DRIVE SPECIFIED BY
```



```
2206                                     ;THE USER?
2207 004750 001026                       BNE      4$      ;YES, OK
2208                                     ;NO, THIS DRIVE # WAS NOT SPECIFIED
2209                                     ;BY THE USER, BUT STILL IS GIVING
2210                                     ;'DRY' WHEN ADRESED. REPORT EROR.
2211 004752 010237 001162               MOV      R2,$REGO ;GET DRIVE #
2212 004756 104116                       ERROR    116     ;THIS DRIVE # WAS NOT SPECIFIED BY
2213                                     ;THE USER, BUT WHEN ADRESED GAVE
2214                                     ;'DRY'. CHECK THAT THIS DRIVE # IF
2215                                     ;PHYSICALLY PRESENT IS ON 'LOAD'. IF
2216                                     ;THIS IS NOT THE CASE, THEN ONE DRIVE
2217                                     ;MAY BE GETTING SELECTED BY TWO DIFFERENT
2218                                     ;LOGICAL ADDRESSES.
2219 004760 005710                       3$:   TST      @R0  ;CHECK THAT THIS DRIVE WAS NOT INDICATED
2220 004762 001421                       BEQ      4$      ;IF IT WAS, & IT IS NOT FOUND TO BE
2221                                     ;PRESENT (DRY CLEAR), REPORT ERROR.
2222 004764 004737 020774               JSR      PC,GT4RG ;GET RKCS, ER, DS, DA
2223 004770 104010                       ERROR    10     ;DRIVE # (AS IN RKDA) WAS INDICATED BY
2224                                     ;THE USER, BUT WAS NOT FOUND TO BE PRESENT.
2225                                     ;CHECK THAT THE ROTARY DRIVE SELECTION
2226                                     ;SWITCH ON THE MODULE IS SET TO THE RIGHT
2227                                     ;DRIVE #.
2228
2229 004772 005010                       CLR      @R0  ;THIS DRIVE IS NOT FOUND TO BE PRESENT
2230                                     ;HENCE DROP IT FROM THE SELECTION TABLE.
2231 004774 010003                       MOV      R0,R3 ;DRIVE ADDR
2232 004776 162703 001414               SUB      #DRIV0,R3 ;MINUS OFFSET FOR TABLE
2233 005002 042703 000003               BIC      #3,R3   ;EVEN DRIVE OF PAIR
2234 005006 062703 001414               ADD      #DRIV0,R3 ;POINT TO EVEN OF PAIR IF RK05 F
2235 005012 042723 100000               BIC      #100000,(R3)+ ;NOT SPECIFIED AS F MODEL
2236 005016 042713 100000               BIC      #100000,(R3) ;SAME
2237 005022 005337 001412               DEC      DRIVS  ;DECREMENT DRIVE COUNT
2238 005026 005202                       4$:   INC      R2   ;INCRMNT DRIVE #
2239 005030 005720                       TST      (R0)+  ;INCRMNT POINTER
2240 005032 062701 020000               ADD      #20000,R1 ;INCRMNT ADRES TO NXT DRIVE
2241 005036 001330                       BNE      1$     ;LUP BAK IF NOT DONE
2242
2243
2244                                     ;THIS PART OF THE PROGRAM IS GOING TO BE REPEATED FOR
2245                                     ;EACH DRIVE PRESENT
2246                                     ;
2247                                     ;'DRIVAD' CONTAINS IN BITS 15,14,13 THE ADDRESS OF THE
2248                                     ;DRIVE BEING CURRENTLY CHECKED.
2249                                     ;
2250 005040                       NUDRV:
2251
2252
2253                                     ;*****
2254                                     ;*TEST 2      FIND OUT NEXT DRIVE TO BE CHECKED
2255                                     ;THIS CODE FINDS OUT THE NEXT DRIVE THAT IS PRESENT AND THEN SETS UP
2256                                     ;THE ADDRESS IN DRIVAD (BITS 13,14,15). THUS THROUGHOUT THE FOLLOWING TESTS
2257                                     ;THE DRIVE TESTED IS THE DRIVE WHOOSE ADDRESS IS IN 'DRIVAD'.
2258                                     ;*****
2259 005040 000004                       TST2:  SCOPE
2260 005042 012737 000001 001206         MOV      #1,$TIMES ;DO 1 ITERATION
2261 005050 012737 000002 001102         MOV      #2,$TSTNM ;RESET POINTER TO THIS TEST
```

```
2262 ;NO. CHANGE THIS (2) IN CASE THE
2263 ;TEST NO. CHANGES
2264 005056 005037 001112 CLR $ERTTL ;CLEAR TOTAL ERROR COUNT
2265 005062 005737 001412 TST DRIVS ;R THERE ANY DRIVES PRESENT?
2266 005066 001002 BNE .+6 ;YES, BRANCH
2267 005070 000137 020652 4$: JMP $EOP ;NO, JMP TO THE END
2268 005074 013701 001354 MOV DRVPTR,R1 ;GET THAT POINTER TO THE NEXT
2269 ;DRIVE FLAG
2270 005100 032721 000001 2$: BIT #BIT0,(R1)+ ;IS THIS DRIVE PRESENT?
2271 005104 001005 BNE 1$ ;YES
2272 005106 062737 020000 001350 6$: ADD #20000,DRIVAD ;FORM NXT DRIVE ADRES
2273 005114 001371 BNE 2$
2274 005116 000764 BR 4$
2275 005120 005737 001410 1$: TST DDPCH ;PROGRAM LOADED FROM AN RK05 ?
2276 005124 001413 BEQ 3$ ;NO, BRANCH
2277 005126 013746 001350 MOV DRIVAD,-(SP) ;PUT TEST DRIVE ADDRESS ON THE STACK
2278 005132 000316 SWAB (SP) ;SETUP TO RIGHT JUSTIFY THE ADDRESS
2279 005134 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS
2280 005136 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS
2281 005140 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS
2282 005142 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS
2283 005144 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS
2284 005146 122637 001410 CMPB (SP)+,DDPCH ;PROGRAM LOADED FROM THIS DRIVE ?
2285 005152 001755 BEQ 6$ ;BR IF YES, DON'T TEST THE DRIVE
2286 005154 010137 001354 3$: MOV R1,DRVPTR ;STORE POINTER TO THE NEXT
2287 ;DRIVE FLAG
2288 005160 104401 001272 TYPE ,MSG4
2289 005164 013746 001350 MOV DRIVAD,-(R6) ;GET THE DRIVE ADDRESS
2290 005170 004737 021200 JSR PC,SHFTRT ;GO SHIFT IT TO THE RIGHT
2291 005174 005037 001404 CLR FFLAG
2292 005200 011600 MOV (R6),R0 ;DRIVE NUMBER
2293 005202 104403 TYPOS ;GO TYPE THE OCTAL # FOR THE
2294 ;DRIVE THAT IS BEING CHECKED
2295 005204 001 000 .BYTE 1,0
2296 005206 006300 ASL R0 ;INDEX TO TABLE
2297 005210 005760 001414 TST DRIV0(R0) ;SEE IF F
2298 005214 100006 BPL 5$ ;NO
2299 005216 104401 005224 TYPE ,65$ ;:TYPE ASCIZ STRING
2300 005222 000401 BR 64$ ;:GET OVER THE ASCIZ
2301 ;:65$: .ASCIZ /F/
2302 64$:
2303 005226 005237 001404 INC FFLAG ;SET F FLAG
2304 005232 104401 5$: TYPE
2305 005234 001213 $CRLF ;TYPE CR, LF
2306 ;:*****
2307 ;*TEST 3 CHECK THAT DRIVE IS SUPPLIED WITH POWER-DPL BIT
2308 ;:*****
2309 005236 000004 TST3: SCOPE
2310 005240 104413 CNT.RESET ;GO, DO CONTROL RESET
2311 ;THIS IS A CALL FOR THE 'CNTRL-
2312 ;RESET' ROUTINE. A CONTROL RESET IS
2313 ;ISSUED AND AFTER A CERTAIN TIME
2314 ;IF THE 'CNTRL RDY' DOES NOT SET
2315 ;AN ERROR IS REPORTED. NOTE THAT
2316 ;THE PC IN ERROR MESSAGE IS THE
2317 ;PC WHERE 'CNT.RESET' IS LOCATED.
```



```

2318 ;THIS IS A VERY BASIC ERR& IF IT
2319 ;OCCURS GO BACK TO TEST 10
2320 005242 013700 001326 MOV RKDS,RO
2321 005246 013777 001350 174064 MOV DRIVAD,@RKDA ;ADDRESS THE DRIVE UNDER TEST
2322 005254 005710 TST @RO ;CHECK IF ANY BIT OF RKDS IS SET?
2323 005256 001003 BNE 1$ ;IF SET, BRANCH
2324 005260 011037 001162 MOV @RO,$REGO ;GET RKDS
2325 005264 104004 ERROR 4 ;RKDS ERROR! RKDS IF ADDRESSED
2326 ;CORRECTLY SHOULD BE NON-ZERO
2327 005266 012777 000015 174036 1$: MOV #15,@RKCS ;ISSUE A DRV RESET, IF DRIVE
2328 ;POWER IS LO, DPL WILL SET
2329 005274 005001 CLR R1
2330 005276 032710 010000 2$: BIT #10000,@RO ;IS 'DPL' BIT SET?
2331 005302 001003 BNE 3$ ;DPL IS SET, BRANCH
2332 005304 005201 INC R1 ;WAIT FOR SOME TIME TO
2333 005306 001373 BNE 2$ ;SEE IF DPL WOULD SET
2334 005310 000403 BR 4$-2 ;OK, DPL NOT SET
2335 005312 004737 021002 3$: JSR PC,GT3RG ;GO, GET RKCS, ER, DS
2336 005316 104005 ERROR 5 ;DPL BIT OF RKDS IS SET, CHECK DRIVE POWER
2337
2338
2339 005320 005001 CLR R1
2340 005322 032710 000100 4$: BIT #100,@RO ;DID R/W/S RDY BIT SET?
2341 005326 001010 BNE TST4 ;:YES, EXIT
2342 005330 104417 000011 DELAY ,11 ;TIME DELAY
2343 005334 005201 INC R1 ;WAIT FOR R/W/S RDY
2344 005336 001371 BNE 4$
2345 005340 017737 173762 001162 MOV @RKDS,$REGO ;GET RKDS
2346 005346 104016 ERROR 16 ;R/W/S RDY DID NOT SET AFTER
2347 ;DRIVE RESET. DRIVE RESET WAS DONE
2348 ;TO CHECK 'DPL'BIT . THIS TEST
2349 ;IS NOT FOR CHECKING DRIVE RESET.
2350 ;U MIGHT WANT TO USE THE TEST PROVIDED
2351 ;FOR CHECKING DRIVE RESET.
2352
2353
2354 ;:*****
2355 ;*TEST 4 CHECK THAT 'DRIVE UNSAFE' IS CLEAR, 'HDEN' IS SET, 'WPS' IS CLEAR
2356 ;:*****
2356 005350 000004 TST4: SCOPE
2357 005352 104413 CNT.RESET ;GO, DO CONTROL RESET
2358 ;THIS IS A CALL FOR THE 'CNTRL-
2359 ;RESET' ROUTINE. A CONTROL RESET IS
2360 ;ISSUED AND AFTER A CERTAIN TIME
2361 ;IF THE 'CNTRL RDY' DOES NOT SET
2362 ;AN ERROR IS REPORTED. NOTE THAT
2363 ;THE PC IN ERROR MESSAGE IS THE
2364 ;PC WHERE 'CNT.RESET' IS LOCATED.
2365 ;THIS IS A VERY BASIC ERR & IF IT
2366 ;OCCURS GO BACK TO TEST 10
2367 005354 013777 001350 173756 MOV DRIVAD,@RKDA ;SET DRIVE ADDRESS
2368 005362 017700 173740 MOV @RKDS,RO ;GET RKDS
2369 005366 032700 002000 BIT #2000,RO ;IS 'DRU' BIT OF RKDS SET?
2370 005372 001403 BEQ 1$ ;NO
2371 005374 004737 021002 JSR PC,GT3RG ;GO, GET RKCS, ER, DS
2372 005400 104006 ERROR 6 ;'DRU' BIT OF RKDS IS SET, CHECK
2373 ;DRIV BY PUTTING RUN/LOAD SW TO LOAD
    
```

```

2374
2375 005402 032700 004000 1$: BIT #4000,R0 ;THEN BACK TO RUN
2376 005406 001004 BNE 2$ ;IS 'HDEN' BIT SET?
2377 005410 017737 173712 001162 MOV @RKDS,$REGO ;YES, BRANCH
2378 005416 104007 ERROR 7 ;GET RKDS
2379 ;ERROR, 'RKOS' BIT IS NOT SET
2380 005420 032777 000040 173700 2$: BIT #40,@RKDS ;IS 'WPS' CLEAR?
2381 005426 001403 BEQ TST5 ;:YES, EXIT
2382 005430 004737 020774 JSR PC,GT4RG ;GET RKCS, ER, DS, DA
2383 005434 104114 ERROR 114 ;'WPS'-WRITE PROTECT STATUS- BIT OF
2384 ;OF RKDS SHOULD BE CLEAR, IF THIS DRIVE
2385 ;IS WRITE ENABLED. CHECK & SEE IF THIS
2386 ;DRIVE IS WRITE ENABLED, IF IT IS NOT,
2387 ;WRITE ENABLE IT.
2388
2389
2390
2391
2392
2393 005436 000004
2394 005440 104413
2395
2396
2397
2398
2399
2400
2401
2402
2403
2404 005442 013777 001350 173670 MOV DRIVAD,@RKDA ;ADDRS THE DRIVE
2405 005450 105777 173652 TSTB @RKDS ;IS 'DRY' SET?
2406 005454 100403 BMI TST6 ;:YES, OK
2407 005456 004737 020774 JSR PC,GT4RG ;GO, GET RKCS, ER, DS, DA
2408 005462 104010 ERROR 10 ;'DRY' NOT SET
2409
2410
2411
2412
2413
2414
2415 005464 000004
2416 005466 013777 001350 173644 MOV DRIVAD,@RKDA ;ADDRS THE DRIVE
2417 005474 005001 CLR R1 ;INITIALIZE COUNT FOR TIMING WAIT LOOP
2418 005476 032777 000400 173622 1$: BIT #400,@RKDS ;IS SOK SET?
2419 005504 001006 BNE TST7 ;:EXIT
2420 005506 005201 INC R1 ;NO, WAIT
2421 005510 001372 BNE 1$ ;WAITED LONG?
2422 005512 017737 173610 001162 MOV @RKDS,$REGO ;GET RKDS
2423 005520 104011 ERROR 11 ;WAITED LONG BUT 'SEC OK' BIT DID NOT
2424 ;SET
2425
2426
2427
2428
2429
    
```

```

*****
;*TEST 5 CHECK THAT 'DRIVE READY' IS SET IN RKDS
*****
    
```

```

TST5: SCOPE
      CNT.RESET ;GO, DO CONTROL RESET
              ;THIS IS A CALL FOR THE 'CNTRL-
              ;RESET' ROUTINE. A CONTROL RESET IS
              ;ISSUED AND AFTER A CERTAIN TIME
              ;IF THE 'CNTRL RDY' DOES NOT SET
              ;AN ERROR IS REPORTED. NOTE THAT
              ;THE PC IN ERROR MESSAGE IS THE
              ;PC WHERE 'CNT.RESET' IS LOCATED.
              ;THIS IS A VERY BASIC ERR & IF IT
              ;OCCURS GO BACK TO TEST 10
    
```

```

*****
;*TEST 6 CHECK THAT 'SOK' BIT CAN SET
;* THIS TEST CHECKS THAT WITHIN A CERTAIN TIME
;* 'SOK' BIT CAN SET, IF IT DOES NOT AN ERROR IS REPORTED
*****
    
```

```

TST6: SCOPE
      MOV DRIVAD,@RKDA ;ADDRS THE DRIVE
      CLR R1 ;INITIALIZE COUNT FOR TIMING WAIT LOOP
2418 005476 032777 000400 173622 1$: BIT #400,@RKDS ;IS SOK SET?
2419 005504 001006 BNE TST7 ;:EXIT
2420 005506 005201 INC R1 ;NO, WAIT
2421 005510 001372 BNE 1$ ;WAITED LONG?
2422 005512 017737 173610 001162 MOV @RKDS,$REGO ;GET RKDS
2423 005520 104011 ERROR 11 ;WAITED LONG BUT 'SEC OK' BIT DID NOT
2424 ;SET
    
```

```

*****
;*TEST 7 CHECK THAT 'SECTOR COUNTER' CAN COUNT FROM 0-13
*****
    
```


2430 : * THIS TEST CHECKS THAT THE SECTOR COUNTER CAN COUNT FROM
 2431 : * 0-13
 2432 : * 1) FIRST, FOR INITIALIZING PURPOSES THERE IS A TIMED LOOP
 2433 : * DURING WHICH SECTOR COUNTER SHOULD COUNT DOWN TO 0. IF THIS
 2434 : * IS NOT DONE AN ERROR IS REPORTED
 2435 : * 2) AFTER A COUNT OF 0 IS REACHED, THE PROGRAM WAITS
 2436 : * FOR A CERTAIN TIME, DURING WHICH THE SEC COUNTER
 2437 : * IS SAMPLED. IF THE COUNTER DOES NOT CHANGE WITHIN THIS
 2438 : * TIME PERIOD AN ERROR IS REPORTED.
 2439 : * 3) UPON FINDING THAT THE COUNTER HAS CHANGED, IT IS CHECKED
 2440 : * IF IT INCREMENTED CORRECTLY. IF IT DID NOT AN ERROR IS REPORTED
 2441 : * 4) IF IT INCREMENTED CORRECTLY, THE PROGRAM AGAIN WAITS IN A
 2442 : * LOOP TILL THE COUNTER CHANGES. (STEPS 2,3,4 ARE REPEATED
 2443 : * TILL THE COUNTER COUNTS UP TO 13)

```

2444 :*****
2445 005522 000004 TST7: SCOPE
2446 005524 104413 CNT.RESET
2447
2448
2449
2450
2451
2452
2453
2454
2455
2456 005526 013777 001350 173604 MOV DRIVAD,@RKDA
2457 005534 013700 001326 MOV RKDS,R0
2458 005540 005037 001356 CLR INDX1
2459 005544 005005 CLR R5
2460
2461 005546 012704 177764 MOV #-14,R4
2462 005552 012703 000001 MOV #1,R3
2463
2464
2465 005556 005037 001360 1$: CLR INDX2
2466
2467 005562 005237 001356 INC INDX1
2468 005566 001440 BEQ 6$
2469 005570 005237 001360 2$: INC INDX2
2470 005574 001441 BEQ 7$
2471
2472 005576 011001 MOV @R0,R1
2473 005600 032701 000400 BIT #400,R1
2474 005604 001771 BEQ 2$
2475 005606 021001 CMP @R0,R1
2476 005610 001362 BNE 1$
2477 005612 042701 177760 BIC #177760,R1
2478 005616 001357 BNE 1$
2479
2480 005620 005204 3$: INC R4
2481 005622 001447 BEQ TST10
2482 005624 005205 4$: INC R5
2483 005626 001431 BEQ 8$
2484 005630 011002 MOV @R0,R2
2485 005632 032702 000400 BIT #400,R2
    
```

```

:GO, DO CONTROL RESET
:THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE. A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME
:IF THE 'CNTRL RDY' DOES NOT SET
:AN ERROR IS REPORTED. NOTE THAT
:THE PC IN ERROR MESSAGE IS THE
:PC WHERE 'CNT.RESET' IS LOCATED.
:THIS IS A VERY BASIC ERR & IF IT
:OCCURS GO BACK TO TEST 10

:INITIALIZE
:'COUNT' - TO TIME 'ERROR 35'
:INITIALIZE 'COUNT' - TO TIME
:'ERROR 36' (WAIT LOOP)
:INITIALIZE 'COUNT' - FOR THE 12 SECTORS.
:R3 CONTAINS THE 'NEXT' COUNT OF SEC-CNTR
:R1 CONTAINS THE 'PREVIOUS' COUNT OF SEC-CNTR
:R2 CONTAINS THE 'PRESENT' COUNT OF SEC-CNTR
:INITIALIZE 'COUNT' - TO TIME
:(WAIT LOOP) 'ERROR 34'
:KEEP TIMING FOR 'ERROR 35'
:BRANCH & REPORT ERROR IF WAITED LONG?
:KEEP TIMING FOR 'ERROR 34'
:BRANCH & REPORT ERROR IF WAITED LONG?

:GET RKDS
:IS 'SOK' SET?
:NO, WAIT FOR IT TO SET
:MAKE SURE THAT 2 CONSECUTIVE
:READINGS OF SEC-CNTR ARE SAME
:YES, MASK OUT NON-SEC CNTR BITS
:IS IT SECTOR 0, IF NOT LOOP BACK &
:WAIT FOR SECTOR 0
:KEEP TRACK OF SECTORS CHECKED
:EXIT, IF ALL SECTORS CHKD
:KEEP TIMING FOR 'ERROR 36'
:BR & REPORT ERROR IF WAITED LONG
:GET RKDS
:IS SOK SET?
    
```

```
2486 005636 001772 BEQ 4$ ;NO, WAIT FOR SOK
2487 005640 021002 CMP @R0,R2 ;MAKE SURE THAT 2 CONSECUTIVE
2488 005642 001370 BNE 4$ ;READINGS OF SEC-CNTR ARE SAME
2489 005644 042702 177760 BIC #177760,R2 ;MASK NON-SEC-CNTR BITS
2490 005650 020201 CMP R2,R1 ;HAS SEC CNTR INCREMENTED?
2491 005652 001764 BEQ 4$ ;NO, WAIT FOR IT TO CHANGE
2492 005654 020203 CMP R2,R3 ;YES, DID IT INCREMENT CORRECTLY?
2493 005656 001023 BNE 9$ ;NO - REPORT ERROR
2494
2495 005660 005203 5$: INC R3 ;INCREMENT 'NEXT COUNT'
2496 005662 005201 INC R1 ;INCREMENT 'PREVIOUS COUNT'
2497 005664 005005 CLR R5 ;INITIALIZE AGAIN FOR TIMING 'ERROR 36'
2498 005666 000754 BR 3$ ;GO & CHECK THE NEXT SECTOR COUNT
2499
2500 005670 010137 001162 6$: MOV R1,$REGO ;GET 'SEC CNTR'
2501 005674 104012 ERROR 12 ;WAITED LONG, BUT SECTOR COUNTER
2502 ;DID NOT COUNT TO 0
2503 005676 000421 BR TST10 ;EXIT
2504
2505 005700 017737 173422 001162 7$: MOV @RKDS,$REGO ;GET RKDS
2506 005706 104011 ERROR 11 ;WAITED LONG, BUT 'SOK' BIT DID
2507 ;NOT SET
2508 005710 000414 BR TST10 ;EXIT
2509
2510 005712 010237 001162 8$: MOV R2,$REGO ;GET SEC CNTR (PRESENT COUNT)
2511 005716 010337 001164 MOV R3,$REG1 ;GET 'NEXT COUNT'
2512 005722 104013 ERROR 13 ;WAITED LONG, BUT THE SECTOR
2513 ;COUNTER DID NOT INCREMENT FROM
2514 ;THE PRESENT COUNT TO THE NEXT COUNT
2515 005724 000406 BR TST10 ;EXIT
2516
2517 005726 010337 001162 9$: MOV R3,$REGO ;GET 'NEXT COUNT' (SEC CNTR SHOULD BE THIS)
2518 005732 010237 001164 MOV R2,$REG1 ;GET PRESENT COUNT (WHAT SEC CNTR WAS)
2519 005736 104014 ERROR 14 ;SEC CNTR INCREMENTED WRONG, DID
2520 ;NOT INCREMENT FROM PRESENT COUNT
2521 ;TO NEXT COUNT
2522 005740 000747 BR 5$
2523 ;
2524
2525 ;*****
2526 ;*TEST 10 CHECK THAT SC=SA CAN BE GENERATED
2527 ;* THIS TEST CHECKS THAT SC=SA CAN BE GFNERATED FOR
2528 ;* EVERY SECTOR
2529 ;*****
2530 005742 000004 TST10: SCOPE
2531 005744 104413 CNT.RESET ;GO, DO CONTROL RESET
2532 ;THIS IS A CALL FOR THE 'CNTRL-
2533 ;RESET' ROUTINE. A CONTROL RESET IS
2534 ;ISSUED AND AFTER A CERTAIN TIME
2535 ;IF THE 'CNTRL RDY' DOES NOT SET
2536 ;AN ERROR IS REPORTED. NOTE THAT
2537 ;THE PC IN ERROR MESSAGE IS THE
2538 ;PC WHERE 'CNT.RESET' IS LOCATED.
2539 ;THIS IS A VERY BASIC ERR & IF IT
2540 ;OCCURS GO BACK TO TEST 10
2541 005746 013704 001350 MOV DRIVAD,R4
```



```
2542 005752 013700 001326      MOV      RKDS,R0
2543 005756 012703 177764      MOV      #-14,R3      ;INITIALIZE COUNT FOR # OF SECTORS
2544 005762 010477 173352      MOV      R4,@RKDA    ;ADDRESS THE DRIVE
2545 005766 005005              CLR      R5          ;INITIALIZE COUNT - FOR TIMING ERROR
2546 005770 005205      2$:      INC      R5          ;KEEP TIMING FOR ERROR
2547 005772 001410      BEQ     3$          ;REPORT ERROR IF WAITED LONG
2548 005774 011001      MOV     @R0,R1      ;GET RKDS
2549 005776 032701 000020      BIT     #20,R1      ;IS SC=SA SET?
2550 006002 001772      BEQ     2$          ;NO, WAIT FOR IT
2551 006004 005204      4$:      INC     R4          ;ADDRS THE NEXT SECTOR
2552 006006 005203      INC     R3          ;ARE ALL SECTORS CHECKED FOR SC=SA
2553 006010 001364      BNE     1$          ;NO, GO & CHECK NEXT
2554 006012 000406      BR      TST11      ;;YES, EXIT
2555
2556 006014 110437 001162      3$:      MOV     R4,$REGO    ;GET SECTOR ADDRESS
2557 006020 010137 001164      MOV     R1,$REG1    ;GET RKDS
2558 006024 104015      ERROR   15          ;COULD NOT GET SC=SA FOR THIS
2559                                ;'SECTOR ADDRESS'
2560 006026 000766      BR      4$          ;GO CHK FOR THE REST
2561
2562                                ;
2563                                ;*****
2564                                ;*TEST 11      CHECK THAT 'R/W/S RDY' IS SET & 'SIN' IS CLEAR
2565                                ;*****
2565 006030 000004      TST11:  SCOPE
2566 006032 104413      CNT.RESET          ;GO, DO CONTROL RESET
2567 006034 013777 001350 173276      MOV     DRIVAD,@RKDA ;ADDRESS THE DRIVE
2568 006042 005001      CLR     R1
2569 006044 017700 173256      1$:      MOV     @RKDS,R0    ;GET RKDS
2570 006050 032700 000100      BIT     #100,R0     ;IS R/W/S RDY SET?
2571 006054 001007      BNE     2$          ;YES, BRANCH
2572 006056 005201      3$:      INC     R1          ;INCREASE LOOP TIME
2573 006060 001376      BNE     3$          ;FOR DRIVE RESET OF HEADS
2574 006062 005201      INC     R1          ;WAITED LONG ENOUGH?
2575 006064 001367      BNE     1$          ;IF NOT LUP BAK & WAIT
2576 006066 010037 001162      MOV     R0,$REGO    ;GET RKDS
2577 006072 104016      ERROR   16          ;R/W/S RDY SHOULD BE SET
2578 006074 032700 001000      2$:      BIT     #1000,R0    ;IS SIN CLEAR?
2579 006100 001403      BEQ     TST12      ;;YES, EXIT
2580 006102 004737 020774      JSR     PC,GT4RG    ;GET RKCS,ER,DS,DA
2581 006106 104001      ERROR   1          ;'SIN' SHOULD HAVE BEEN CLEAR
2582                                ;IT WAS NOT CLEAR
2583                                ;NEXT TEST IS GOING TO CHECK
2584                                ;DRIVE RESET, SIN SHOULD BE
2585                                ;CLEARED THEN. IT WILL BE CHECKED
2586                                ;THERE.
2587
2588                                ;*****
2589                                ;*TEST 12      CHECK 'DRIVE RESET'
2590                                ;*THIS TEST CHECKS THE VERY BASIC DRIVE RESET LOGIC.
2591                                ;*SINCE THE HEADS ARE AT CYLINDER 0 (GOING INTO THIS
2592                                ;*TEST) DRIVE RESET RETRACTS THEM BACK BEYOND CYLINDER 0,
2593                                ;*AFTER WHICH THEY ARE PUSHED FORWARD TO CYLINDER 0 AGAIN.
2594                                ;*IN THE LATER PART OF THIS PROGRAM THERE IS A DRIVE RESET
2595                                ;*TEST WHICH DOES THE RESET FROM LAST CYLINDER.
2596                                ;*****
2597 006110 000004      TST12:  SCOPE
```

```

2598 006112 104413          CNT.RESET          ;GO, DO CONTROL RESET
2599                                     ;THIS IS A CALL FOR THE 'CNTRL-
2600                                     ;RESET' ROUTINE. A CONTROL RESET IS
2601                                     ;ISSUED AND AFTER A CERTAIN TIME
2602                                     ;IF THE 'CNTRL RDY' DOES NOT SET
2603                                     ;AN ERROR IS REPORTED. NOTE THAT
2604                                     ;THE PC IN ERROR MESSAGE IS THE
2605                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
2606                                     ;THIS IS A VERY BASIC ERR & IF IT
2607                                     ;OCCURS GO BACK TO TEST 10
2608 006114 013700 001332      MOV      RKCS,R0
2609 006120 005004              CLR      R4          ;INITIALIZ COUNT - TO TIME ERROR
2610 006122 013777 001350 173210 MOV      DRIVAD,@RKDA ;ADDRESS THE DRIVE
2611 006130 012710 000015      MOV      #15,@R0    ;'DRIVE RESET', GO
2612 006134 104412              CHKCRDY          ;GO CHECK IF CONTROL RDY IS SET
2613                                     ;IF SO, SKIP THE EROR MESSAGE.
2614 006136 104021              ERROR   21          ;CNTRL RDY DID NOT SET AFTER
2615                                     ;SENDING CYL ADDR TO THE DRIV.
2616                                     ;'ADD ACK' SHOULD HAVE COME BACK
2617                                     ;FROM DRIVE, THEREUPON SETTING 'CN RDY'
2618 006140 012705 177776      MOV      #-2,R5      ;SET UP DELAY COUNTER
2619 006144 032777 000100 173154 6$: BIT      #100,@RKDS    ;CHECK FOR R/W/S READY
2620 006152 001402              BEQ      .+6
2621 006154 000137 006176      JMP      3$
2622 006160 005204              INC      R4
2623 006162 001370              BNE     6$
2624 006164 005205              INC      R5
2625 006166 001366              BNE     6$
2626 006170 004737 020774      JSR     PC,GT4RG    ;GO, GET RKCS, ER, DS, DA
2627 006174 104026              ERROR   26          ;R/W/S RDY DID NOT SET AFTER
2628                                     ;DRIVE RESET
2629
2630 006176 032777 001000 173122 3$: BIT      #1000,@RKDS  ;DID SIN SET?
2631 006204 001403              BEQ     5$          ;NO, BRANCH
2632 006206 004737 020774      JSR     PC,GT4RG    ;GO, GET RKCS,ER,DS,DA
2633 006212 104001              ERROR   1          ;SIN SET, AFTER A
2634                                     ;DRIVE RESET.
2635 006214 032710 140000      5$: BIT      #140000,@R0 ;WAS 'ERR' BIT OR 'HE' BIT SET?
2636 006220 001403              BEQ     4$          ;NC
2637 006222 004737 020774      JSR     PC,GT4RG    ;GO, GET RKCS, ER, DS, DA
2638 006226 104022              ERROR   22          ;'ERR' OR 'HE' BIT SET WHILE DOING
2639                                     ;DRIVE RESET
2640 006230 022710 000214      4$: CMP     #214,@R0 ;DOES RKCS STILL CONTAIN THE
2641                                     ;'DRIV RES' BITS
2642 006234 001406              BEQ     TST13       ;:YES, EXIT
2643 006236 012737 000214 001162 MOV      #214,$REG0  ;GET EXPCTD RKCS
2644 006244 011037 001164      MOV     @R0,$REG1   ;GET RKCS, RECD
2645 006250 104024              ERROR   24          ;NO - RKCS SHOULD CONTAIN THE 'DRIV RES'
2646                                     ;FUNCTION, ERROR IF DIFFERENT.
2647
2648
2649
2650
2651
2652
2653

```

```

*****
;*TEST 13      CHECK 'SEEK' TO CYLINDER 0
;* THIS TEST CHECKS THE SEEK LOGIC DOING SEEK TO CYLINDER 0.
;* NOTE THAT SINCE THE HEADS ARE ALREADY ON CYLINDER 0, NO
;* HEAD MOVEMENT IS INVOLVEDN AND THE STRESS IS ON THE BASIC SEEK
;* LOGIC.

```



```
2654  
2655 006252 000004  
2656 006254 104413  
2657  
2658  
2659  
2660  
2661  
2662  
2663  
2664  
2665  
2666 006256 104421  
2667  
2668 006260 013700 001332  
2669 006264 013777 001350 173046  
2670  
2671 006272 012710 000011  
2672 006276 104412  
2673  
2674 006300 104021  
2675  
2676  
2677  
2678 006302 005005  
2679 006304 032777 000100 173014 2$:  
2680 006312 001005  
2681 006314 005205  
2682 006316 001372  
2683 006320 004737 020774  
2684 006324 104026  
2685 006326 032777 001000 172772 3$:  
2686 006334 001403  
2687 006336 004737 020774  
2688 006342 104001  
2689  
2690  
2691  
2692  
2693 006344 032710 140000 6$:  
2694 006350 001403  
2695  
2696 006352 004737 020774  
2697 006356 104022  
2698  
2699 006360 005777 172744 4$:  
2700 006364 001403  
2701 006366 004737 021002  
2702 006372 104023  
2703  
2704 006374 022710 000210 5$:  
2705 006400 001406  
2706 006402 012737 000210 001162  
2707 006410 011037 001164  
2708 006414 104024  
2709
```

TST13: SCOPE
CNT.RESET

TST.SIN

MOV RKCS,RO
MOV DRIVAD,@RKDA

MOV #11,@RO
CHKCRDY

ERROR 21

2\$: CLR R5
BIT #100,@RKDS
BNE 3\$
INC R5
BNE 2\$+2
JSR PC,GT4RG
ERROR 26

3\$: BIT #1000,@RKDS
BEQ 6\$
JSR PC,GT4RG
ERROR 1

6\$: BIT #140000,@RO
BEQ 4\$

4\$: TST @RKER
BEQ 5\$
JSR PC,GT3RG
ERROR 23

5\$: CMP #210,@RO
BEQ TST14
MOV #210,\$REG0
MOV @RO,\$REG1
ERROR 24

;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
;GO CHECK IF SIN SET. IF SET
;A DO DRIVE RESET TO CLEAR IT

;ADDRESS THE DRIVE

;'SEEK' GO
;GO CHECK IF CONTROL RDY IS SET
;IF SO, SKIP THE EROR MESSAGE.
;'CNTRL RDY' DID NOT SET AFTER SENDING
;CYL ADDR TO THE DRIVE, 'ADD ACK'
;SHOULD HAVE COME BACK FROM THE
;DRIVE, THEREUPON SETTING 'CNTRL RDY'

;DID R/W/S RDY BIT SET?
;YES, BRANCH
;WAITED LONG ENOUGH?
;IF NOT, LUP BAK & WAIT
;GO, GET RKCS, ER, DS, DA
;R/W/S RDY DID NOT SET AFTER SEEK
;DID SIN SET?
;NO, BRANCH
;GO, GET RKCS,ER,DS,DA
;SIN SET ON DOING SEEK
;TO CYL 0 NOTE THIS IS THE
;FIRST TIME THE HEADS HAVE
;BEEN MOVED

;WAS 'ERR' OR 'HE' BIT SET?

;GO, GET RKCS, ER, DS, DA
;'ERR' OR 'HE' BIT SET WHILE DOING 'SEEK'

;WAS ANY BIT IN RKER SET?
;NO
;GO, GET RKCS, ER, DS
;RKER SHOWS AN ERROR BIT, CHECK

;DOES RKCS STILL CONTAIN 'SEEK' FUNCTION
;:YES, EXIT
;GET EXPCTD RKCS
;GET RKCS RECVD
;NO, RKCS SHOULD BE STILL CONTAINING
;'SEEK' FUNCTION ERROR - IF IT CHANGED

2710
2711
2712
2713
2714
2715
2716
2717
2718
2719
2720
2721
2722
2723
2724
2725
2726
2727
2728
2729
2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2750
2751
2752
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765

006416 000004
006420 104413

006422 104421

006424 004737 021504
006430 104026

006432 005005
006434 013777 001350 172676
006442 052777 000100 172670
006450 013701 001326
006454 012777 000011 172650
006462 032711 000100
006466 001405
006470 005205
006472 100373
006474 004737 021002
006500 104025

006502 004737 021436
006506 104016

```
*****  
:TEST 14 CHECK R/W/S RDY IS CLEAR WHEN HEADS ARE IN MOTION  
: *THIS TEST CHECKS THAT R/W/S DOES GET CLEARED  
: *WHEN THE HEADS ARE IN MOTION. SINCE 'MOVE L' ON  
: *M7700 (RK05) GENERATES THIS SIGNAL, ABSENCE OF  
: *R/W/S RDY-CLEAR COULD MEAN A FAULT ON M7702  
: *WHERE 'MOVE L' IS GENERATED.  
: *NOTE THIS IS THE FIRST TIME HEADS ARE MADE TO MOVE BY SEEKING  
: *TO CYLINDER 2.  
*****
```

TST14: SCOPE
CNT.RESET

```
:GO, DO CONTROL RESET  
:THIS IS A CALL FOR THE 'CNTRL-  
:RESET' ROUTINE. A CONTROL RESET IS  
:ISSUED AND AFTER A CERTAIN TIME  
:IF THE 'CNTRL RDY' DOES NOT SET  
:AN ERROR IS REPORTED. NOTE THAT  
:THE PC IN ERROR MESSAGE IS THE  
:PC WHERE 'CNT.RESET' IS LOCATED.  
:THIS IS A VERY BASIC ERR & IF IT  
:OCCURS GO BACK TO TEST 10  
:GO CHECK IF SIN IS SET  
:IF SET DO DRV-RESET TO CLR IT  
:MAKE SURE HEADS R ON CYL 0  
:R/W/S RDY DIDN'T SET  
:AFTER THE ABOVE DRV RESET
```

TST.SIN

```
JSR PC,DRESET  
ERROR 26  
  
CLR R5  
MOV DRIVAD,@RKDA  
BIS #100,@RKDA  
MOV RKDS,R1  
MOV #11,@RKCS  
1$: BIT #100,@R1  
BEQ 2$  
INC R5  
BPL 1$  
JSR PC,GT3RG  
ERROR 25
```

:SEEK CYLINDER 2

```
:SEEK, GO  
:DID R/W/S RDY CLR?  
:YES, BRANCH
```

```
:R/W/S RDY WAS NOT CLEAR WHEN HEADS  
:WERE SEEKING TO CYLINDER 2
```

2\$: JSR PC,TSTRWS
ERROR 16

```
:GO, WAIT FOR R/W/S RDY TO SET  
:R/W/S RDY DID NOT SET AFTER SEEK  
:WAS TRIED TO CYLINDER 2 (ABOVE).  
:NOTE THIS WAS THE FIRST TIME A SEEK  
:WAS TRIED TO A CYLINDER OTHER THAN  
:0.
```

```
*****  
:TEST 15 CHECK 'WRITE' FORMAT FUNCTION-CYLINDER 0, SECTOR 0  
: *THIS TEST CHECKS THE LOGIC INVOLVED IN THE WRITE FMT  
: *FUNCTION. ON ISSUING A WRT FMT, THE FOLLOWING IS CHECKED  
: *1) CNTRL RDY WAS CLEARED AS GO WAS SET.  
: *2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION OF FUNCTION
```



```
2766 ;*3) IF 'HE' OR 'ERR' BIT SET?
2767 ;*4) IF RKDA INCREMENTED CORRECTLY FROM 0 TO 1?
2768 ;*5) IF RKWC OVERFLOWED CORRECTLY TO 0?
2769 ;*6) IF RKBA INCREMENTED CORRECTLY BY 2?
2770 ;*7) IF ANY BIT IN RKER SET?
2771 ;*8) IF THE 'WRT FMT' FUNCTION BITS ARE STILL IN THE RKCS?
2772 ;*NOTE THAT ONE WORD '125252' WAS WRITTEN ON SECTOR
2773 ;*0 & IT WILL BE CHECKED IN THE NEXT TESTS.
2774 ::*****
2775 006510 000004 TST15: SCOPE
2776 006512 104413 CNT.RESET
2777
2778 ;GO, DO CONTROL RESET
2779 ;THIS IS A CALL FOR THE 'CNTRL-
2780 ;RESET' ROUTINE. A CONTROL RESET IS
2781 ;ISSUED AND AFTER A CERTAIN TIME
2782 ;IF THE 'CNTRL RDY' DOES NOT SET
2783 ;AN ERROR IS REPORTED. NOTE THAT
2784 ;THE PC IN ERROR MESSAGE IS THE
2785 ;PC WHERE 'CNT.RESET' IS LOCATED.
2786 006514 104421 TST.SIN
2787
2788 006516 012703 033342 MOV #OUTBUF,R3
2789
2790 ;THIS CODE SETS UP A 256 WORD BUFFER
2791 ;WHICH WILL BE USED TO WRITE 1 SECTOR
2792 ;ON THE DISK
2793 ;1ST WORD 000001
2794 ;2ND WORD 177777 2'S COMPLEMENT
2795 ;3RD WORD 000002 OF ABOVE
2796 ;4TH WORD 177776
2797
2798 ;253RD WORD 000177
2799 ;254TH WORD 177601
2800 ;255TH WORD 000000
2801 ;256TH WORD 125252
2802 006522 012700 000001 MOV #1,R0 ;SET COUNT
2803
2804 006526 010023 9$: MOV R0,(R3)+ ;SET UP DATA WORDS
2805 006530 010013 MOV R0,(R3)
2806 006532 005423 NEG (R3)+
2807 006534 005200 INC R0
2808 006536 022700 000200 CMP #200,R0 ;DONE?
2809 006542 001371 BNE 9$
2810 006544 005023 CLR (R3)+ ;SET 255TH WORD TO 0
2811 006546 012713 125252 MOV #125252,@R3 ;SET 256TH WORD
2812
2813 006552 012703 033342 MOV #OUTBUF,R3 ;RESET POINTER TO OUTBUF
2814 006556 013701 001332 MOV RKCS,R1
2815 006562 013702 001336 MOV RKBA,R2
2816 006566 010312 MOV R3,@R2 ;FROM HERE-SET UP CURRENT ADDRESS
2817 006570 012777 177400 172536 MOV #-400,@RKWC ;SET UP WORD COUNT 400 WORDS
2818 006576 013777 001350 172534 MOV DRIVAD,@RKDA ;SET UP DISK ADDR, SECTOR 0, CYLINDER 0
2819 006604 012711 002003 MOV #2003,@R1 ;WRITE FORMAT, GO
2820
2821 006610 105711 1$: TSTB @R1 ;WAS 'CNTRL RDY' CLEARED AS GO WAS SET?
```

```

2822 006612 100003          BPL      2$          :YES, BRANCH
2823 006614 004737 021002 JSR      PC,GT3RG    :GO, GET RKCS, ER, DS
2824 006620 104030          ERROR    30          : 'CNTRL RDY' DIDN'T CLEAR AS GO
2825                                     : WAS SET TO 'WRITE FORMAT'
2826 006622 005000          2$: CLR      R0          :
2827 006624 105711          TSTB    @R1          : WAS 'CNTRL RDY' SET ON COMPLETION OF WRITE?
2828 006626 100411          BMI     3$          :YES, BRANCH
2829 006630 005200          INC     R0          :NO, HAVE U WAITED LONG ENOUGH?
2830 006632 001374          BNE     2$+2        :IF NOT, LOOP BACK & WAIT
2831                                     :IF YES, REPORT ERROR
2832 006634 004737 020774 JSR      PC,GT4RG    :GO, GET RKCS, ER, DS,DA
2833 006640 013737 001350 001202 MOV      DRIVAD,$REG10
2834 006646 104416          BRKDA4
2835                                     :GO TO 'BDA4' & BREAK CONTENTS OF
2836 006650 104031          ERROR    31          :$REG10 INTO DR #,CYL,SUR,SEC BITS
2837                                     : 'CNTRL RDY' DIDN'T SET ON COMPLETION
2838                                     : OF WRITE FORMAT
2839                                     : WRT FMT WAS DONE STARTING AT <DSK-ADRES>
2840 006652 004737 021234          3$: JSR      PC,CHKHE
2841                                     : INDICATED IN EROR MSGE.
2842                                     : GO CHECK IF 'HE' OR 'ERR' BIT SET,
2843 006656 104032          ERROR    32          : IF YES, SAVE RKCS, ER, DS, DA.
2844                                     : RETURN HERE IF ERROR.
2845                                     : 'HE' OR 'ERR' BIT SET WHILE DOING
2846                                     : A WRITE FORMAT
2847 006660 004737 021262          4$: JSR      PC,CHKDA
2848                                     : WRT FMT WAS DONE STARTING AT <DSK-ADRES>
2849 006664 104033          ERROR    33          : INDICATED IN EROR MSGE.
2850                                     : GO CHECK IF RKDA INCREMENTED CORRECTLY
2851 006666 004737 021316          5$: JSR      PC,CHKWC
2852                                     : IF NOT, RETURN HERE.
2853 006672 104034          ERROR    34          : RKDA SHOULD HAVE INCREMENTED BY
2854                                     : 1 SECTOR, IT DID NOT
2855 006674 022712 034342          6$: CMP      #OUTBUF+1000,@R2
2856 006700 001406          BEQ     7$          : DID RKBA INCREMENT CORRECTLY?
2857 006702 012737 034342 001162 MOV      #OUTBUF+1000,$REG0
2858 006710 011237 001164          MOV     @R2,$REG1   : YES, BRANCH
2859 006714 104035          ERROR    35          : GET EXPCTD RKBA
2860                                     : GET ACTUAL RKBA
2861 006716 004737 021342          7$: JSR      PC,CHKER
2862                                     : RKBA DIDN'T INCREMENT BY 1000 AFTER
2863 006722 104036          ERROR    36          : WRITE FORMAT OF 400 WORDS
2864                                     : CHECK IOF ANY BIT IN RKER SET,
2865 006724 022711 002202          8$: CMP      #2202,@R1
2866 006730 001406          BEQ     TST16        : IF YES RETURN HERE.
2867 006732 012737 002202 001162 MOV      #2202,$REG0
2868 006740 011137 001164          MOV     @R1,$REG1   : RKER BIT SET ON DOING 1 WORD
2869 006744 104024          ERROR    24          : WRITE FORMAT
2870                                     : DOES RKCS STILL HAVE 'WRT FMT' BITS?
2871                                     : :YES, EXIT
2872                                     : GET EXPCTD RKCS
2873                                     : GET ACTUAL RKCS
2874                                     : RKCS DIDN'T CONTAIN 'WRT FMT' BITS
2875                                     : AFTER THE FUNCTION WAS COMPLETED
2876                                     ;
2877                                     ;

```

```

*****
*TEST 16 CHECK 'READ FORMAT' FUNCTION-CYLINDER 0, SECTOR 0
*THIS TEST CHECKS THE LOGIC INVOLVED IN THE WRITE FMT
*FUNCTION. ON ISSUING A WRT FMT, THE FOLLOWING IS CHECKED
*1) CNTRL RDY WAS CLEARED AS GO WAS SET.
*2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION OF FUNCTION

```


2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893 006746 000004
2894 006750 005000
2895 006752 104413
2896
2897
2898
2899
2900
2901
2902
2903
2904
2905 006754 104421
2906
2907 006756 013701 001332
2908 006762 013702 001336
2909 006766 012703 033342
2910 006772 010312
2911
2912 006774 012777 177777 172332
2913 007002 013777 001350 172330
2914 007010 012711 002005
2915
2916 007014 105711
2917 007016 100003
2918 007020 004737 021002
2919 007024 104030
2920
2921 007026 005000
2922 007030 105711
2923
2924 007032 100411
2925 007034 005200
2926 007036 001374
2927
2928 007040 004737 020774
2929 007044 013737 001350 001202
2930 007052 104416
2931
2932 007054 104045
2933

;*3) IF 'HE' OR 'ERR' BIT SET?
;*4) IF RKDA INCREMENTED CORRECTLY FROM 0 TO 1?
;*5) IF RKWC OVERFLOWED CORRECTLY TO 0?
;*6) IF RKBA INCREMENTED CORRECTLY BY 2?
;*7) IF ANY BIT IN RKER SET?
;*8) IF THE CORRECT HEADER WAS RECEIVED?
;*9) FOR RK11C, AFTER RD FMT RKDB CONTAINS THE CHECKSUM
;*FOR THAT SECTOR. (125252 IN THIS CASE, BECAUSE THE
;*FIRST WORD IN SEC 0 WAS WRITTEN AS 125252 IN
;*THE PREVIOUS TEST)
;*10) FOR RK11D, AFTER RD FMT RKDB SHOULD CONTAIN
;*A ZERO
;*11) IF THE RD FMT FUNCTION BITS ARE STILL IN
;*THE RKCS?

::*****

TST16: SCOPE
CLR RO
CNT.RESET

;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
;GO CHECK IF SIN IS SET
;IF SET, DO DRIVE RESET TO CLR IT

TST.SIN

MOV RKCS,R1
MOV RKBA,R2
MOV #OUTBUF,R3
MOV R3,@R2
MOV #-1,@RKWC
MOV DRIVAD,@RKDA
MOV #2005,@R1

;SETUP ADRS WHERE HEADER WORD IS TO BE
;X-FERRED
;SET UP WORD COUNT
;SET UP DISK ADRS, SECTOR 0, CYLINDER 0
;READ FORMAT, GO

1\$: TSTB @R1
BPL 2\$
JSR PC,GT3RG
ERROR 30

;WAS 'CNTRL RDY' CLEARED AS GO WAS SET?
;YES, BRANCH
;GO, GET RKCS, RKER
;CNTRL RDY DIDN'T CLEAR AS GO WAS
;SET TO 'READ FORMAT'

2\$: CLR RO
TSTB @R1

;WAS 'CNTRL RDY' SET ON COMPLETION OF
;TRANSFER
;YES, BRANCH
;NO, HAVE U WAITED LONG ENOUGH?
;IF NOT, LOOP BACK & WAIT
;IF YES, REPORT ERROR
;GO, GET RKCS, ER, DS,DA

BMI 3\$
INC RO
BNE 2\$+2
JSR PC,GT4RG
MOV DRIVAD,\$REG10
BRKDA4

;GO TO 'BDA4' & BREAK CONTENTS OF
;\$REG10 INTO DR #,CYL,SUR,SEC BITS
;'CNTRL RDY' DIDN'T SET ON COMPLETION
;OF READ FORMAT

ERROR 45

```

2934                                     ;READ FMT WAS DONE STARTING AT <DSK-ADRES>
2935                                     ;INDICATED IN EROR MESGE
2936 007056 004737 021234 3$: JSR PC,CHKHE ;CHECK IF 'ERR' OR 'HE' BIT SET, IF
2937                                     ;YES RETURN HERE.
2938 007062 104046 ERROR 46 ;'HE' OR 'ERR' BIT SET WHILE
2939                                     ;DOING A 'READ FORMAT'
2940                                     ;READ FMT WAS DONE STARTING AT <DSK-ADRES>
2941                                     ;INDICATED IN EROR MESGE
2942 007064 004737 021262 4$: JSR PC,CHKDA ;CHECK IF RKDA INCREMENTED CORRECTLY
2943                                     ;IF NOT, RETURN HERE.
2944 007070 104040 ERROR 40 ;RKDA SHOULD HAVE INCREMENTED
2945                                     ;BY 1 SECTOR, IT DID NOT
2946
2947 007072 004737 021316 5$: JSR PC,CHKWC ;CHECK IF RKWC OVERFLOWED TO 0, IF
2948                                     ;NOT RETURN HERE.
2949 007076 104041 ERROR 41 ;RKWC DID NOT OVERFLOW TO 0
2950                                     ;AFTER XFER ON READ FORMAT
2951 007100 022712 033344 6$: CMP #OUTBUF+2,@R2 ;DID RKBA INCREMENT TO NXT WORD ADDRS?
2952 007104 001406 BEQ 7$ ;YES, BRANCH
2953 007106 012737 033344 001162 MOV #OUTBUF+2,$REG0 ;GET EXPCTD RKBA
2954 007114 011237 001164 MOV @R2,$REG1 ;GET ACTUAL RKBA
2955 007120 104042 ERROR 42 ;RKBA DIDN'T INCREMENT BY 2 AFTER
2956                                     ;'READ FORMAT' OF 1 WORD
2957 007122 004737 021342 7$: JSR PC,CHKER ;CHECK IF ANY BIT IN RKER SET, IF
2958                                     ;YES RETURN HERE.
2959 007126 104036 ERROR 36 ;RKER BIT SET ON DOING
2960                                     ;1 WORD READ FORMAT
2961 007130 005713 8$: TST @R3 ;DOES OUTBUF CONTAIN THE HEADER
2962                                     ;WORD-0
2963 007132 001407 BEQ 9$ ;YES, BRANCH
2964 007134 005037 001162 CLR $REG0 ;GET SECTOR NO.
2965 007140 005037 001164 CLR $REG1 ;EXPCTD HEADER
2966 007144 011337 001166 MOV @R3,$REG2 ;GET HEADER RECVD
2967 007150 104043 ERROR 43 ;CORRECT HEADER WORD-0-WAS
2968                                     ;NOT RECEIVED ON READ FORMAT
2969 007152 022711 002204 9$: CMP #2204,@R1 ;DOES RKCS HAVE THE 'RDFMT' BITS?
2970 007156 001406 BEQ TST17 ;YES, BRANCH
2971 007160 012737 002204 001162 MOV #2204,$REG0 ;GET EXPCTD RKCS
2972 007166 011137 001164 MOV @R1,$REG1 ;GET ACTUAL RKCS
2973 007172 104024 ERROR 24 ;RKCS DIDN'T CONTAIN 'RD FMT'
2974                                     ;BITS AFTER FUNCTION WAS
2975                                     ;COMPLETED
2976
2977
2978
2979

```

```

;*****
;*TEST 17 CHECK 'READ' FUNCTION-CYLINDER 0,SECTOR 0
; *THIS IS THE FIRST TIME A PURE READ IS PREFORMED IN THIS
; *TEST SEQUENCE. THE FOLLOWING IS CHECKED
; *1) CNTRL RDY CLEARS AS GO IS SET
; *2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
; *OF FUNCTION
; *3) IF 'HE' OR 'ERR' BIT SET?
; *4) IF RKDA INCREMENTED CORRECTLY?
; *5) IF RKWC OVERFLOWED TO 0?
; *6) IF RKBA INCREMENTED CORRECTLY?

```

```

2974
2975
2976
2977
2978
2979
2980
2981
2982
2983
2984
2985
2986
2987
2988
2989

```



```

3046                                     ;IF NOT RETURN HERE.
3047 007316 104040                       ERROR 40                       ;RKDA DID NOT INCREMENT
3048                                     ;BY 1 (SECTOR)
3049 007320 004737 021316                 5$: JSR PC,CHKWC                   ;CHECK IF RKWC OVERFLOWED TO 0,
3050                                     ;IF NOT RETURN HERE.
3051 007324 104041                       ERROR 41                       ;RKWC DID NOT OVERFLOW TO 0,
3052                                     ;AFTER X-FER ON READ
3053 007326 022712 034342                 6$: CMP #OUTBUF+1000,@R2           ;DID RKBA INCREMENT CORRECTLY?
3054 007332 001406                       BEQ 7$                          ;YES, BRANCH
3055 007334 012737 034342 001162         MOV #OUTBUF+1000,$REG0           ;GET EXPCTD RKBA
3056 007342 011237 001164                 MOV @R2,$REG1                   ;GET ACTUAL RKBA
3057 007346 104042                       ERROR 42                       ;RKBA DID NOT INCREMENT BY 2
3058                                     ;AFTER 'READ' OF 1 WORD
3059 007350 004737 021342                 7$: JSR PC,CHKER                   ;CHECK IF ANY BIT IN RKER SET,
3060                                     ;IF YES RETURN HERE.
3061 007354 104036                       ERROR 36                       ;RKER BIT SET ON DOING 1
3062                                     ;WORD 'READ'
3063 007356 022713 000001                 8$: CMP #1,@R3                   ;DOES OUTBUF CONTAIN THE RIGHT
3064                                     ;DATA WORD
3065 007362 001411                       BEQ 9$                          ;YES BRANCH
3066 007364 012737 000001 001162         MOV #1,$REG0                    ;GET EXPCTD DATA WORD
3067 007372 011337 001164                 MOV (R3),$REG1                  ;GET RECD DATA WORD
3068 007376 013737 001350 001166         MOV DRIVAD,$REG2                ;GET DISK ADRS FROM WHICH READ WAS DONE
3069 007404 104044                       ERROR 44                       ;DID NOT READ THE CORRECT
3070                                     ;DATA WORD--FROM DISK ADRES,
3071                                     ;
3072                                     ;SEC 0, CYL 0, SUR 0
3073                                     ;
3074                                     ;AFTER 1 SECTOR READ RKDB CONTAINS
3075                                     ;FOR RK11C
3076                                     ;THE CHECKSUM FOR THAT SECTOR
3077                                     ;FOR RK11D
3078                                     ;THE LAST WORD TRANSFERRED TO MEMORY
3079                                     ;
3080                                     ;IT SO HAPPENS THAT WITH THE SECTOR
3081                                     ;THAT WAS READ, RKDB CONTAINS THE
3082                                     ;SAME INFORMATION FOR BOTH RK11C
3083                                     ;AND RK11D
3084 007406 022777 125252 171726 9$: CMP #125252,@RKDB                ;DOES RKDB CONTAIN THE EXPCTD WORD?
3085 007414 001407                       BEQ 10$                          ;YES, BRANCH
3086 007416 012737 125252 001162         MOV #125252,$REG0               ;GET EXPCTD RKDB
3087 007424 017737 171712 001164         MOV @RKDB,$REG1                 ;GET RECD RKDB
3088 007432 104037                       ERROR 37                       ;RKDB DOES NOT CONTAIN THE
3089                                     ;EXPCTD WORD AFTER A READ OF SEC 0
3090                                     ;CYL 0
3091 007434 022711 000204                 10$: CMP #204,@R1                ;DOES RKCS HAVE THE 'READ' BITS?
3092 007440 001406                       BEQ 11$                          ;YES, BRANCH
3093 007442 012737 000204 001162         MOV #204,$REG0                  ;GET EXPCTD RKCS
3094 007450 011137 001164                 MOV @R1,$REG1                   ;GET RECD RKCS
3095 007454 104024                       ERROR 24                       ;RKCS DID NOT CONTAIN 'READ'
3096                                     ;FUNCTION BITS AFTER OPERATION
3097                                     ;WAS COMPLETED
3098 007456 104413                       11$: CNT.RESET                   ;GO DO CONTROL RESET
3099 007460 005777 171656                 TST @RKDB                       ;DID CONTROL RESET CLEAR RKDB?
3100 007464 001407                       BEQ TST20                        ;YES, EXIT
3101 007466 013737 001342 001164         MOV RKDB,$REG1                  ;GET ADRES OF RKDB

```


3102 007474 017737 171642 001164
3103 007502 104102
3104
3105
3106
3107
3108
3109
3110
3111
3112
3113
3114
3115
3116
3117
3118
3119 007504 000004
3120 007506 013703 001332
3121 007512 012702 177764
3122 007516 013704 001340
3123 007522 013701 001350
3124 007526 010105
3125 007530 005205
3126 007532 012737 007540 001110
3127
3128 007540 104413
3129
3130
3131
3132
3133
3134
3135
3136
3137
3138 007542 104421
3139
3140 007544 005000
3141 007546 010137 033342
3142
3143
3144
3145
3146 007552 012777 033342 171556
3147
3148 007560 012777 177777 171546
3149 007566 010114
3150 007570 012713 002003
3151
3152 007574 105777 171532
3153 007600 100410
3154 007602 005200
3155 007604 001373
3156
3157 007606 004737 020774

MOV @RKDB,\$REG1 ;GET CONTENTS OF RKDB
ERROR 102 ;CONTROL RESET DIDN'T CLR RKDB
:*****
:*TEST 20 CHECK 'WRITE FORMAT' -CYLINDER 0, SECTOR 0-13
:*THIS TEST GOES ONE STEP FURTHER & PERFORMS A WRT
:*FMT ON CYLINDER 0 & CHECKS THE FOLLOWING
:*1) IF CNTRL RDY SET WITHIN A CERTAIN TIME ON COMPLETION
:*OF THE FUNCTION
:*2) IF 'HE' OR 'ERR' BIT SET?
:*3) IF THE RKDA INCREMENTS CORRECTLY?
:*4) IF THE RKDB IS CLEAR?
:*WRT FMT IS DONE ONE SECTOR AT A TIME
:*THE FIRST WORD OF EVERY SECTOR IS WRITTEN AS A
:*PSUEDO-HEADER CONSISTING OF DRIVE #, CYLINDER #, SURFACE
:*& SECTOR #. THIS WILL BE READ & CHECKED IN THE FOLLOWING TEST.
:*****
TST20: SCOPE
MOV RKCS,R3
MOV #-14,R2 ;SET UP COUNT FOR 12 SECTORS
MOV RKDA,R4
MOV DRIVAD,R1 ;GET DRIVE ADDRESS
MOV R1,R5 ;STORE IT
INC R5
MOV #1\$,\$LPERR ;SET RETURN ADRES FOR LUPING
;ON ERROR (SW 9)
1\$: CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
TST.SIN ;GO CHECK IF SIN IS SET
;IF SET, DO DRIVE RESET TO CLR IT
CLR R0
MOV R1,OUTBUF ;THIS WORD TO BE X-FERRED. FIRST
;WORD OF EACH SECTOR WILL BE THE
;ACTUAL DRIVE-ADDRS CONSISTING OF
;DRIVE NO, CYL ADDR, SURFACE
;SECTOR NO.
MOV #OUTBUF,@RKBA ;ADRS FROM WHICH DATA WORD IS TO
;X-FERRED
MOV #-1,@RKWC ;SET UP WORD COUNT
MOV R1,@R4 ;ADDRS THE DRIVE, CYL 0, & CORRECT SECTOR
MOV #2003,@R3 ;WRITE FORMAT, GO
2\$: TSTB @RKCS ;DID 'CNTRL RDY' SET?
BMI 3\$;YES, BRANCH
INC R0 ;NO, HAVE U WAITED LONG?
BNE 2\$;IF NOT, LOOP BACK & WAIT
;IF YES, REPORT ERROR
JSR PC,GT4RG ;GO, GET RKCS, ER, DS,DA

```

3158 007612 010137 001202      MOV      R1,$REG10      ;GET DISK ADRS (UNIT,CYL,SUR,SEC) TO WHICH
3159                                ;WRITE FORMAT WAS DONE
3160 007616 104416      BRKDA4      ;GO TO 'BDA4' & BREAK CONTENTS OF
3161                                ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3162 007620 104031      ERROR 31      ;'CNTRL RDY' DID NOT SET ON COMPLETION
3163                                ;OF 'WRITE FORMAT'
3164                                ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
3165                                ;INDICATED IN EROR MSGE.
3166 007622 004737 021226      3$: JSR      PC,CHKHE1    ;CHECK IF 'ERR' OR 'HE' BIT IS SET,
3167                                ;IF YES RETURN HERE.
3168 007626 104032      ERROR 32      ;'HE' OR 'ERR' BIT SET WHILE DOING
3169                                ;WRITE FORMAT ON CYLINDER 0,
3170                                ;SECTOR IN ERROR IS AS SHOWN IN
3171                                ;DISK-ADRES BITS 0-3
3172                                ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
3173                                ;INDICATED IN EROR MSGE.
3174
3175 007630 004737 021270      4$: JSR      PC,CHKDA1    ;CHECK IF RKDA INCREMENTED CORRECTLY?
3176                                ;
3177 007634 104033      ERROR 33      ;RKDA DID NOT INCREMENT CORRECT
3178                                ;AFTER 1 WORD 'WRITE FORMAT' ON
3179                                ;CYLINDER 0, SECTOR IN ERROR IS 1
3180                                ;LESS THAN THAT SHOWN IN EXPCTD RKDA
3181 007636 005777 171500      5$: TST      @RKDB      ;CHECK THAT RKDB DOES CONTAIN A 0
3182                                ;AFTER WRT BECAUSE LAST WORD WRITTEN
3183                                ;WAS SERIALLY SHIFTED OUT TO THE DISK
3184                                ;YES, BRANCH
3185 007642 001406      BEQ      6$
3186 007644 005037 001162      CLR      $REG0
3187 007650 017737 171466      MOV      @RKDB,$REG1
3188 007656 104037      ERROR 37      ;THIS IS WHAT RKDB SHOULD CONTAIN
3189                                ;GET RKDB
3190                                ;RKDB SHOULD BE 0 AFTER WRT SINCE THE
3191                                ;LAST WORD WRITTEN WAS SERIALLY SHIFTED
3192                                ;OUT OF RKDB
3193                                ;INCREMENT DRIVE ADRES TO NXT SECTOR
3194 007660 005201      6$: INC      R1
3195 007662 005205      INC      R5
3196 007664 122705 000014      CMPB    #14,R5
3197 007670 001002      BNE     .+6
3198 007672 062705 000004      ADD     #4,R5
3199                                ;R U GOING TO CHECK THE LAST SECTOR?
3200                                ;IF NOT,BRANCH
3201                                ;IF YES,INCREMENT R5 CORRECTLY TO 'EXPCTD RKDA'
3202                                ;AFTER HAVING CHECKED THE LAST SECTOR
3203                                ;HAVE U FORMATTED ALL 12 SECTORS?
3204                                ;IF NOT, BRANCH BACK & LOOP
3205                                ;IF YES, EXIT
3206
3207
3208
3209
3210
3211
3212
3213

```

```

*****
;*TEST 21      CHECK 'READ FORMAT'-CYLINDER 0, SECTOR 0-13
;*THIS TEST PERFORMS A RD FMT ON THE 12 SECTORS OF CYLINDER 0
;*THE FOLLOWING IS CHECKED
;*1) IF CNTRL RDY SET WITHIN A CERTAIN TIME ON COMPLETION
;*OF THE FUNCTION
;*2) IF 'HE' OR 'ERR' BIT SET?
;*3) IF THE RKDA INCREMENTS CORRECTLY?
;*4) RKBA INCREMENTED CORRECTLY BY 30 (OCTAL)
;*5) RKWC OVERFLOWED TO 0 FROM -14 (OCTAL)
;:6) CORRECT HEADER WAS RECEIVED FROM ALL 12 SECTORS.
;*7) RKCS STILL CONTAINS THE 'RD FMT' FUNCTION BITS.
;*IF THERE IS A READ ERROR IN THIS TEST OR ANY
;*OTHER TESTS THE USER SHOULD MAKE SURE THAT

```


3214
3215
3216
3217
3218
3219 007702 000004
3220 007704 005005
3221 007706 104413
3222
3223
3224
3225
3226
3227
3228
3229
3230
3231 007710 104421
3232
3233 007712 013701 001332
3234 007716 012700 177764
3235 007722 013702 001340
3236 007726 013712 001350
3237 007732 012704 033342
3238 007736 010477 171374
3239 007742 012777 177764 171364
3240 007750 012777 002005 171354
3241
3242 007756 105777 171350
3243 007762 100411
3244 007764 005205
3245 007766 001373
3246
3247 007770 004737 020774
3248 007774 013737 001350 001202
3249 010002 104416
3250
3251 010004 104045
3252
3253
3254
3255
3256 010006 004737 021234
3257
3258 010012 104046
3259
3260
3261
3262 010014 013705 001350
3263 010020 062705 000020
3264
3265 010024 004737 021270
3266
3267 010030 104040
3268
3269

;*IT IS AN IRRECOVERABLE ERROR AND NOT A TRANSIENT
;*ONE. THIS CAN BE DONE BY LOOPING ON THE TEST
;*IN QUESTION. USUALLY A TRANSIENT ERROR
;*DISAPPEARS ON RETRIES, WHEREAS A LOGIC ERROR DOES NOT.
:*****
TST21: SCOPE
CLR R5
CNT.RESET
:GO, DO CONTROL RESET
:THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE. A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME
:IF THE 'CNTRL RDY' DOES NOT SET
:AN ERROR IS REPORTED. NOTE THAT
:THE PC IN ERROR MESSAGE IS THE
:PC WHERE 'CNT.RESET' IS LOCATED.
:THIS IS A VERY BASIC ERR & IF IT
:OCCURS GO BACK TO TEST 10
:GO CHECK IF SIN IS SET
:IS SET, DO DRIVE RESET TO CLR IT
:SET UP COUNT FOR 12 SECTORS
:ADDRESS THE DRIVE
:ADRS TO WHICH X-FER DATA FROM DSK
:SET UP WORD COUNT FOR 12 HEADERS TO BREAD
:READ FORMAT, GO
:DID CNTRL RDY SET ON COMPLETION?
:YES, BRANCH
:NO, WAIT FOR IT TO SET
:IF WAITED LONG ENOUGH REPORT
:ERROR, OTHERWISE LOOP BACK & WAIT
:GO, GET RKCS, ER, DS,DA
:GO TO 'BDA4' & BREAK CONTENTS OF
:\$REG10 INTO DR#,CYL,SUR,SEC BITS
:CNTRL RDY DID NOT SET ON COMPLETION
:OF READ FORMAT-OF CYLINDER 0,
:SECTORS 0-13
:READ FMT WAS DONE STARTING AT <DSK-ADRES>
:INDICATED IN EROR MESGE
:CHECK IF 'ERR' OR 'HE' BIT IS SET,
:IF YES RETURN HERE.
:'ERR' OR 'HE' BIT SET ON DOING
:READ FMT-OF CYLINDER 0, SEC 0-13
:READ FMT WAS DONE STARTING AT <DSK-ADRES>
:INDICATED IN EROR MESGE
:RKDA SHOULD HAVE INCREMENTD TO (R2)
:CHECK IF RKDA INCREMENTED CORRECTLY,
:IF NOT, RETURN HERE.
:RKDA DID NOT INCREMENT BY 12
:AFTER A 'RD FMT' OF 12 HEADERS OF
:CYLINDER 0, SECTORS 0-13

```
3270 ;RKBA SHOULD INCREMENT BY 24 BYTES
3271 ;AT THE END OF X-FER
3272 010032 022777 033372 171276 4$: CMP #OUTBUF+30,@RKBA ;DID RKBA INCREMENT CORRECTLY?
3273 010040 001407 BEQ 5$ ;YES, BRANCH
3274 010042 012737 033372 001162 MOV #OUTBUF+30,$REG0 ;GET EXPCTD RKBA
3275 010050 017737 171262 001164 MOV @RKBA,$REG1 ;GET ACTUAL RKBA
3276 010056 104042 ERROR 42 ;RKBA DID NOT INCREMENT CORRECTLY
3277 ;AFTER READ FORMAT OF 12 HEADERS
3278 010060 004737 021316 5$: JSR PC,CHKWC ;GO CHECK IF RKWC OVERFLOWED TO 0
3279 ;IF NOT RETURN HERE.
3280 010064 104041 ERROR 41 ;RKWC DID NOT OVERFLOW TO 0
3281 ;AFTER 'RD FMT' OF 12 HEADERS
3282 ;OF CYLINDER 0
3283 010066 005724 6$: TST (R4)+ ;WAS THE CORRECT HEADER RECIEVED?
3284 010070 001413 BEQ 7$ ;YES, BRANCH
3285 010072 010037 001162 MOV R0,$REG0 ;GET SECTOR FOR WHICH THE HEADER
3286 010076 062737 000014 001162 ADD #14,$REG0 ;COULD NOT BE READ CORRECT
3287 010104 005037 001164 CLR $REG1 ;EXPCTD HEADER=0, FOR CYL 0
3288 010110 014437 001166 MOV -(R4),$REG2 ;GET WRONG HEADER RECVD
3289 010114 104043 ERROR 43 ;HEADER WAS NOT READ RIGHT FOR
3290 ;SECTOR (AS IN ER MSGE), & CYL 0
3291 010116 005724 TST (R4)+ ;WAS THE CORRECT HEADER RECVD?
3292 010120 005200 7$: INC R0 ;YES, HAVE U CHECKED FOR ALL 12 SECTORS?
3293 010122 001361 BNE 6$ ;IF NOT, LOOP BACK & CHK HDR FRM NXT SECTR
3294
3295 010124 004737 021342 JSR PC,CHKER ;CHECK IF ANY BIT IN RKER IS SET,
3296 ;IF YES, RETURN HERE.
3297 010130 104036 ERROR 36 ;RKER BIT SET ON DOING RD FMT
3298 ;OF CYL 0, SECTORS 0-13
3299 010132 022711 002204 8$: CMP #2204,@R1 ;DOES RKCS STILL CONTAIN FUNCTION BITS?
3300 010136 001406 BEQ TST22 ;:YES, EXIT
3301 010140 012737 002204 001162 MOV #2204,$REG0 ;GET EXPCTD RKCS
3302 010146 011137 001164 MOV @R1,$REG1 ;GET ACTUAL RKCS
3303 010152 104024 ERROR 24 ;RKCS DID NOT CONTAIN 'RD FMT'
3304 ;FUNCTION BITS ON COMPEITION OF
3305 ;THE FUNCTION
3306
3307
3308
3309
3310 ;*****
3311 ;*TEST 22 CHECK 'READ',CYLINDER 0, SECTORS 0 TO 13
3312 ;*THIS TEST PERFORMS A READ OF ALL THE SECTORS OF CYLINDER 0
3313 ;*& CHECKS THE FOLLOWING
3314 ;*1) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3315 ;*OF THE FUNCTION
3316 ;*2) IF 'HE' OR 'ERR' BIT SET?
3317 ;*3) IF THE CORRECT PSUEDO-HEADER (FIRST WORD OF EVERY)
3318 ;*SECTOR, WRITTEN IN A PREVIOUS TEST) WAS RECEIVED.
3319 ;*4) IF RKDS CONTAINS THE CORRECT WORD.
3320 ;*4) IF RKDA INCREMENTED CORRECTLY.
3321 ;*5) IF REST OF THE (377) WORDS IN EACH SECTOR ARE '0' , NOTE
3322 ;*PREVIOUSLY ONE WORD WAS WRITTEN PER SECTOR.
3323 ;*6) IF RKCS STILL CONTAINS THE 'READ' FUNCTION BITS
3324 ;*7) IF CONTROL RESET CLEARS RKDB.
3325 ;* IF TESTING IS BEING DONE ON A SIMULATOR ONLY LAST SECTOR(13)
3325 ;*IS READ BECAUSE THE SIMULATOR CAN STORE ONLY 1 SECTOR (256 WORDS).
```



```
3326                                     ;*HENCE ONLY THE DATA WRITTEN LAST CAN BE READ BACK.
3327                                     ;*****
3328 010154 000004                                TST22: SCOPE
3329 010156 012737 010230 001110                MOV    #1$, $LPERR          ;SET RETURN ADRES FOR LUPING
3330                                           ;ON      ERROR (SW 9)
3331 010164 013703 001332                        MOV    RKCS, R3
3332 010170 013701 001350                        MOV    DRIVAD, R1
3333 010174 010105                                MOV    R1, R5
3334 010176 012704 033342                        MOV    #OUTBUF, R4
3335 010202 005737 001344                        TST    SIMUL                ;TESTING ON SIMULATOR?
3336 010206 001405                                BEQ    9$                    ;NO, BRANCH
3337                                           ;IF TESTING ON SIMULATOR READ
3338                                           ;SECTOR 13 ONLY
3339 010210 052701 000013                        BIS    #13, R1              ;SET BITS FOR SEC 13
3340 010214 052705 000020                        BIS    #20, R5              ;RKDA SHOULD INCRMNT TO THIS AFTER READ
3341 010220 000403                                BR     1$
3342 010222 012702 177764                        9$:  MOV    #-14, R2          ;SET COUNT FOR 12 SECTORS
3343 010226 005205                                INC    R5                    ;RKDA SHOULD INCREMENT TO
3344                                           ;THIS AFTER 1 SECTOR READ
3345 010230 104413                        1$:  CNT.RESET              ;GO, DO CONTROL RESET
3346                                           ;THIS IS A CALL FOR THE 'CNTRL-
3347                                           ;RESET' ROUTINE. A CONTROL RESET IS
3348                                           ;ISSUED AND AFTER A CERTAIN TIME
3349                                           ;IF THE 'CNTRL RDY' DOES NOT SET
3350                                           ;AN ERROR IS REPORTED. NOTE THAT
3351                                           ;THE PC IN ERROR MESSAGE IS THE
3352                                           ;PC WHERE 'CNT.RESET' IS LOCATED.
3353                                           ;THIS IS A VERY BASIC ERR & IF IT
3354                                           ;OCCURS GO BACK TO TEST 10
3355 010232 104421                                TST.SIN                      ;GO CHECK IF SIN IS SET
3356                                           ;IF SET, DO DRIVE RESET TO CLR IT
3357 010234 010177 171100                        MOV    R1, @RKDA            ;ADDRESS THE DRIVE
3358 010240 010477 171072                        MOV    R4, @RKBA            ;ADRS TO WHICH X-FER DATA FROM DISK
3359 010244 012777 177400 171062                MOV    #-400, @RKWC         ;SETUP WORD COUNT
3360 010252 012713 000005                        MOV    #5, @R3              ;READ, GO
3361                                           ;DID CNTRL RDY SET ON COMPETION?
3362 010256 005000                                CLR    R0                    ;YES, BRANCH
3363 010260 105713                        2$:  TSTB   @R3                ;NO, WAIT FOR IT TO SET
3364 010262 100410                        BMI    3$                    ;IF WAITED LONG ENOUGH, REPORT
3365 010264 005200                        INC    R0                    ;ERROR, OTHERWISE LOOP BAK & WAIT
3366 010266 001374                        BNE   2$                    ;GO, GET RKCS, ER, DS, DA
3367                                           ;GET SECTOR ADRES WHERE ERROR OCCURED
3368 010270 004737 020774                        JSR    PC, GT4RG            ;GO TO 'BDA4' & BREAK CONTENTS OF
3369 010274 010137 001202                        MOV    R1, $REG10           ;$REG10 INTO DR #, CYL, SUR, SEC BITS
3370 010300 104416                        BRKDA4                       ;CNTRL RDY DID NOT SET ON COMPLETION
3371                                           ;OF READ OF CYLINDER 0, SECTOR
3372 010302 104045                        ERROR 45                    ;AS SHOWN IN <DSK-ADRES>
3373                                           ;READ WAS DONE STARTING AT <DSK-ADRES>
3374                                           ;INDICATED IN EROR MESGE
3375                                           ;CHECK IF 'ERR' OR 'HE' BIT IS SET,
3376                                           ;IF YES RETURN HERE.
3377 010304 004737 021226                        3$:  JSR    PC, CHKHE1        ;HE OR ERR BIT SET
3378                                           ;ON 'READ' OF CYLINDER 0, SECTOR
3379 010310 104046                        ERROR 46                    ;AS SHOWN IN <DSK-ADRES>
3380
3381
```

```

3382
3383
3384 010312 020114      4$:  CMP      R1,(R4)
3385
3386
3387
3388 010314 001407      BEQ      5$
3389 010316 010137 001162  MOV      R1,$REG0
3390 010322 011437 001164  MOV      (R4),$REG1
3391 010326 010137 001166  MOV      R1,$REG2
3392 010332 104044      ERROR    44
3393
3394
3395 010334 004737 021270      5$:  JSR      PC,CHKDA1
3396
3397 010340 104040      ERROR    40
3398
3399
3400
3401
3402
3403
3404
3405
3406
3407
3408 010342 012737 177775 001370  MOV      #-3,EFLG1
3409 010350 012700 033344      MOV      #OUTBUF+2,R0
3410 010354 012737 177401 001362  MOV      #-377,COUNT
3411 010362 005710      11$:  TST      @R0
3412 010364 001005      BNE      12$
3413 010366 005720      TST      (R0)+
3414 010370 005237 001362  INC      COUNT
3415 010374 001372      BNE      11$
3416 010376 000412      BR       7$
3417 010400 005037 001162      12$:  CLR      $REG0
3418 010404 012037 001164  MOV      (R0)+,$REG1
3419 010410 010137 001166  MOV      R1,$REG2
3420
3421 010414 104044      ERROR    44
3422
3423
3424
3425
3426
3427
3428
3429 010416 005237 001370  INC      EFLG1
3430 010422 001357      BNE      11$
3431
3432
3433 010424 005737 001344      7$:  TST      SIMUL
3434 010430 001011      BNE      10$
3435
3436
3437 010432 005201      INC      R1

```

```

;READ WAS DONE STARTING AT <DSK-ADRES>
;INDICATED IN EROR MESGE
;WAS THE DATA WORD RECVD, CORRECT?
;THE FIRST DATA WORD OF EACH SECTOR
;IS AN ADRS WORD COMPRISING OF DRIVE NO,
;CYLINDER ADRS, SUR, SECTOR ADRS

;GET EXPCTD DATA WORD FROM DISK
;GET THE DATA WORD RECVD
;GET DISK ADRES
;DID NOT RECIEVE CORRECT DATA WORD ON
;READ, OF CYLINDER 0, SECTOR AS SHOWN IN 'DSK
;ADRES' OF EXPCTD DATA WORD
;CHECK IF RKDA INCREMENTED CORRECTLY,
;IF NOT RETURN HERE.
;RKDA DID NOT INCREMENT CORRECTLY
;AFTER READ OF 1 WORD, FROM CYL 0
;SEC IN ERROR IS 1 LESS THAN THAT
;SHOWN IN EXPCTD RKDA

;AS A RESULT OF 'WRT FMT' IN A PREVIOUS TEST
;FIRST WORD OF EVERY SECTOR IS NON-
;ZERO (PSUEDO-HDR), REST 377 WORDS
;ARE ALL 0'S.
;CHECK IF THE REST OF THE 377
;WORDS ARE ALL 0'S
;ALLOW ONLY 3 ERRORS
;INITIALIZE PTR TO 2ND WRD IN BUFR
;CHECK 377 WORDS IN THE BUFFER
;IS THIS WRD 0?
;NO, ERROR
;INCRMNT PTR TO NXT WRD
;CHKD ALL 377 WRDS?

;YES, BRANCH
;GET EXPCTD WORD
;GET WORD RECVD
;GET DISK ADRES, ERROR IN THIS
;SECTOR
;DATA ERROR, THE LAST 377 WORDS
;READ FROM EACH SECTOR SHOULD BE 0
;IN A PREVIOUS TEST, FIRST WORD OF
;EVERY SEC (CYL 0) WAS WRITTEN AS A
;PSUEDO-HDR, REST OF THE WORDS IN THE
;SECTR ARE AUTOMATICALLY WRITTEN AS
;0'S. THIS ERROR MAY MEAN THAT IT
;DIDN'T HAPPEN SO
;ALLOW ONLY 3 DATA ERORS OF THIS KIND

;TESTING ON SIMULATOR?
;YES BRANCH
;IF NOT TESTING ON SIMULATOR GO AHEAD
; & READ ALL 12 SECTORS ON CYL 0
;INCREMENT DRIV-ADRES TO NXT SECTOR

```


3438	010434	005205			INC	R5			; INCREMENT 'EXPCTD DRIV-ADRES'
3439	010436	122705	000014		CMPB	#14,R5			; R U GOING TO READ THE LAST SECTOR?
3440	010442	001002			BNE	.+6			; IF NOT, BRANCH
3441	010444	062705	000004		ADD	#4,R5			; IF YES, INCREMENT 'EXPCTD RKDA'
3442									; CORRECTLY
3443	010450	005202			INC	R2			; HAVE U READ ALL 12 SECTORS?
3444	010452	001266			BNE	1\$; IF NOT LOOP BACK & READ THE
3445									; NXT SECTOR
3446	010454	022713	000204	10\$:	CMP	#204,@R3			; DOES RKCS, STILL HAVE THE 'READ' FUNCTION
3447	010460	001406			BEQ	8\$; YES, BRANCH
3448	010462	012737	000204	001162	MOV	#204,\$REG0			; GET EXPCTD RKCS
3449	010470	011337	001164		MOV	@R3,\$REG1			; GET RKCS RECD
3450	010474	104024			ERROR	24			; RKCS SHOULD STILL CONTAIN THE 'READ'
3451									; FUNCTION BITS
3452	010476	104413		8\$:	CNT.RESET				; GO ,DO CONTROL RESET
3453									; THIS IS A CALL FOR THE 'CNTRL-
3454									; RESET' ROUTINE. A CONTROL RESET IS
3455									; ISSUED AND AFTER A CERTAIN TIME
3456									; IF THE 'CNTRL RDY' DOES NOT SET
3457									; AN ERROR IS REPORTED. NOTE THAT
3458									; THE PC IN ERROR MESSAGE IS THE
3459									; PC WHERE 'CNT.RESET' IS LOCATED.
3460									; THIS IS A VERY BASIC ERR & IF IT
3461									; OCCURS GO BACK TO TEST 10
3462	010500	005777	170636		TST	@RKDB			; DID CNTRL RESET CLEAR RKDB?
3463	010504	001407			BEQ	TST23			; YES, EXIT
3464	010506	013737	001342	001162	MOV	RKDB,\$REG0			; GET ADRES OF RKDB
3465	010514	017737	170622	001164	MOV	@RKDB,\$REG1			; GET CONTENTS OF RKDB
3466	010522	104102			ERROR	102			; CONTROL RESET DID NOT
3467									; CLEAR RKDB

3470 ;:*****
3471 ;*TEST 23 CHECK 'WRITE FORMAT' OF THE DISK
3472 ;*THIS TEST WRITE FORMATS THE ENTIRE DISK. THE FIRST
3473 ;*WORD OF EVERY SECTOR IS WRITTEN TO BE A PSUEDO-HEADER
3474 ;*CONSISTING OF THE DRIVE #, CYLINDER #, SURFACE & SECTOR #.
3475 ;*1 SECTOR IS WRITTEN AT A TIME. THE WRITING IS DONE
3476 ;*IN THIS ORDER: CYL 0-SUR 0; CYL 0-SUR 1; CYL 1-SUR 0
3477 ;*CYL 1-SUR 1; CYL 2-SUR 0; CYL 2-SUR 1----- CYL 312-SUR 1.
3478 ;*IMPORTANCE OF THIS TEST SHOULD BE REALIZED, THIS IS
3479 ;*THE FIRST TIME EACH & EVERY SECTOR ON THE DISK IS
3480 ;*ACCESSED & WRITTEN ON. THIS IS THE FIRST TIME RKDA
3481 ;*IS BEING MADE TO INCREMENT OVER THE ENTIRE DISK (FROM
3482 ;*000000 TO 014520) IF A 'SIN' OCCURS AT ANY POINT
3483 ;*A DRIVE RESET IS DONE BEFORE DOING WRT FMT FOR THE NEXT
3484 ;*SECTOR. ANY OTHER ERROR IS CLEARED THROUGH A CONTROL RESET.
3485 ;*THE FOLLOWING CHECKING IS DONE AFTER WRITING EACH
3486 ;*CYLINDER.
3487 ;*1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3488 ;*OF THE FUNCTION.
3489 ;*2. IF 'SIN' OCCURRED?
3490 ;*3. IF 'HE' OR 'ERR' BIT SET?
3491 ;*4. IF RKDA INCREMENTED CORRECTLY, INCLUDING BOUNDARY
3492 ;*CONDITIONS (SECTOR COUNTER BITS OVERFLOWING INTO SURFACE,
3493 ;*SURFACE BIT OVERFLOWING INTO CYLINDER BITS) AT THE END

```

3494                                     ;*OF THIS POINTERS ARE INCREMENTED ADJUSTED, ETC.
3495                                     ;*8 'WRT FMT' ON THE NEXT SECTOR IS DONE.
3496                                     ;:*****
3497 010524 000004 TST23: SCOPE
3498 010526 012737 000001 001206 MOV #1,$TIMES ;;DO 1 ITERATION
3499 010534 012737 010564 001110 MOV #1$,$LPERR ;SET RETURN ADRES FOR LUPING
3500                                     ;ON ERROR (SW 9)
3501 010542 005003 CLR R3 ;(R3)=0, SURFACE 0 BEING WRITTEN
3502                                     ;(R3)-1, SURFACE 1 BEING WRITTEN
3503 010544 012704 177465 MOV #-313,R4 ;SET UP COUNT FOR 203 CYLINDERS
3504 010550 012702 177764 MOV #-14,R2 ;SET UP COUNT FOR 12 SECTORS
3505 010554 013701 001350 MOV DRIVAD,R1 ;GET DRIVE ADRES
3506 010560 010105 MOV R1,R5 ;STORE IT
3507 010562 005205 INC R5
3508 010564 104413 1$: CNT.RESET ;GO, DO CONTROL RESET
3509                                     ;THIS IS A CALL FOR THE 'CNTRL-
3510                                     ;RESET' ROUTINE. A CONTROL RESET IS
3511                                     ;ISSUED AND AFTER A CERTAIN TIME
3512                                     ;IF THE 'CNTRL RDY' DOES NOT SET
3513                                     ;AN ERROR IS REPORTED. NOTE THAT
3514                                     ;THE PC IN ERROR MESSAGE IS THE
3515                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
3516                                     ;THIS IS A VERY BASIC ERR & IF IT
3517                                     ;OCCURS GO BACK TO TEST 10
3518 010566 104421 TST.SIN ;GO CHECK IF SIN IS SET
3519                                     ;IF SET, DO DRIVE RESET TO CLR IT
3520 010570 005037 001362 7$: CLR COUNT
3521 010574 010137 033342 MOV R1,OUTBUF ;THIS WORD TO BE WRITTEN. THE FIRST
3522                                     ;WORD OF EACH SECTOR WILL BE THE ACTUAL
3523                                     ;DISK-ADRES, CONSISTING OF THE DRIVE NO,
3524                                     ;CYL ADRES, SURFACE BIT SECTOR ADRES
3525 010600 012777 033342 170530 MOV #OUTBUF,@RKBA ;ADRES FROM WHICH WORD IS TO B X-FERRED
3526 010606 012777 177777 170520 MOV #-1,@RKWC ;SET UP WORD COUNT
3527 010614 010177 170520 MOV R1,@RKDA ;ADRES THE DRIVE, WITH CORRECT CYL
3528                                     ;& SECTOR ADRES
3529 010620 012777 002003 170504 MOV #2003,@RKCS ;WRITE FORMAT, GO
3530
3531 010626 105777 170500 2$: TSTB @RKCS ;DID CNTRL RDY SET
3532 010632 100411 BMI 3$ ;YES, BRANCH
3533 010634 005237 001362 INC COUNT ;NO, HAVE U WAITED LONG ENOUGH?
3534 010640 001372 BNE 2$ ;IF NOT, LOOP BACK & WAIT
3535                                     ;IF YES, REPORT ERROR
3536 010642 004737 020774 JSR PC,GT4RG ;GO, GET RKCS, ER, DS,DA
3537 010646 010137 001202 MOV R1,$REG10 ;GET DISK ADRES, WHERE ERROR OCCURED
3538 010652 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
3539                                     ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3540 010654 104031 ERROR 31 ;CNTRL RDY DID NOT SET ON COMPLETION
3541                                     ;OF 'WRITE FORMAT', ON SECTOR AS
3542                                     ;SHOWN IN <DSK-ADRES>
3543                                     ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
3544                                     ;INDICATED IN EROR MSGE.
3545 010656 032777 001000 170442 3$: BIT #1000,@RKDS ;DID SIN BIT SET?
3546 010664 001405 BEQ 4$ ;NO, BRANCH
3547 010666 004737 021002 JSR PC,GT3RG ;GO, GET RKCS, ER, DS
3548 010672 010137 001170 MOV R1,$REG3 ;GET, DISK-ADRES WHERE ERROR OCCURED
3549 010676 104001 ERROR 1 ;SIN SET WHILE DOING WRT FMT

```



```

3550                                     ;TO DISK-ADRES (AS IN $REG3)
3551
3552 010700 004737 021226      4$:   JSR     PC,CHKHE1      ;CHECK IF 'ERR' OR 'HE' BIT IS SET
3553                                     ;IF YES, RETURN HERE.
3554 010704 104032              ERROR 32      ;HE OR ERR SET WHILE DOING WRITE
3555                                     ;FORMAT ON SECTOR AS INDICATED IN
3556                                     ;<DSK-ADRES>
3557                                     ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
3558                                     ;INDICATED IN EROR MSGE.
3559 010706 004737 021270      5$:   JSR     PC,CHKDA1      ;CHECK IF RKDA INCREMENTED CORRECTLY,
3560                                     ;IF NOT, RETURN HERE.
3561 010712 104033              ERROR 33      ;RKDA DID NOT INCREMENT CORRECTLY
3562                                     ;AFTER 'WRITE FORMAT' WAS DONE
3563                                     ;TO THE SECTOR PREVIOUS TO THAT
3564                                     ;INDICATED IN 'EXPCTD' RKDA
3565 010714 005201              6$:   INC     R1          ;INCREMENT TO THE NXT SECTOR
3566 010716 005205              INC     R5          ;INCREMENT R5, TO WHAT RKDA WILL INCREMENT
3567 010720 022702 177776      CMP     #-2,R2      ;R U GOING TO FORMAT THE LAST SECTOR
3568                                     ;IN THE CYLINDER ?
3569 010724 001002              BNE     .+6         ;IF NOT, BRANCH
3570 010726 062705 000004      ADD     #4,R5       ;INCREMENT R5 CORRECTLY TO 'EXPCTD RKDA'
3571 010732 005202              INC     R2          ;HAVE U FORMATTED ALL 12 SECTORS
3572                                     ;ON THIS CYLINDER
3573 010734 001313              BNE     1$         ;IF NOT, LOOP BACK & FORMAT THE
3574                                     ;NEXT SECTOR
3575                                     ;YES
3576 010736 012702 177764      MOV     #-14,R2     ;RESET THE COUNT FOR 12 SECTORS
3577 010742 042701 000037      BIC     #37,R1      ;CLEAR THE SEC ADRES BITS
3578 010746 005703              TST     R3          ;SURFACE 1?
3579 010750 001006              BNE     8$         ;YES, BRANCH
3580 010752 005203              INC     R3          ;NO, SET FLAG
3581 010754 062701 000020      ADD     #20,R1      ;INCREMENT TO THE NXT SURFACE
3582 010760 010105              MOV     R1,R5       ;THIS IS WHAT RKDA SHOULD
3583 010762 005205              INC     R5          ;INCREMENT TO.
3584 010764 000677              BR      1$         ;GO, DO NXT SURFACE
3585 010766 062701 000040      8$:   ADD     #40,R1     ;INCREMENT TO NXT CYL
3586 010772 010105              MOV     R1,R5       ;POSITION FOR
3587 010774 005205              INC     R5          ;EXPCTD RKDA
3588 010776 005003              CLR     R3          ;
3589 011000 005204              INC     R4          ;HAVE U FORMATTED ALL 203 CYLINDERS
3590 011002 001270              BNE     1$         ;IF NOT, LOOP BACK & FORMAT THE
3591                                     ;NEXT CYLINDER
3592
3593
3594
3595
3596                                     ;*****
3597                                     ;*TEST 24      CHECK 'READ FORMAT' FOR THE ENTIRE DISK
3598                                     ;*THIS TEST READ FORMATS THE ENTIRE DISK, WHICH WAS WRT
3599                                     ;*FORMATTED IN THE PREVIOUS TEST.  THE FOLLOWING CHECKING
3600                                     ;*IS DONE
3601                                     ;*1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3602                                     ;*OF FUNCTION
3603                                     ;*2. IF 'SIN' OCCURRED?
3604                                     ;*3. IF 'HE' OR 'ERR' OCCURRED?
3605                                     ;*4. RKDA INCREMENTED CORRECTLY.
3606                                     ;*5. IF THE CORRECT HEADER WAS READ.
    
```

3606
3607
3608
3609
3610
3611
3612
3613
3614 011004 000004
3615 011006 012737 000001 001206
3616 011014 012737 011100 001110
3617
3618 011022 005037 001356
3619
3620 011026 013701 001350
3621 011032 010102
3622 011034 005737 001344
3623 011040 001410
3624 011042 052701 014533
3625
3626
3627 011046 052702 014540
3628
3629 011052 012737 177777 001370
3630
3631 011060 000407
3632 011062 012705 177465
3633 011066 012737 177764 001370
3634
3635 011074 062702 000020
3636
3637 011100 104413
3638
3639
3640
3641
3642
3643
3644
3645
3646
3647
3648 011102 104421
3649
3650
3651 011104 012703 033342
3652 011110 005037 001360
3653 011114 010377 170216
3654
3655 011120 013777 001370 170206
3656
3657
3658 011126 010177 170206
3659
3660 011132 012777 002005 170172
3661

```
;*6. IF RKWC OVERFLOWED CORRECTLY.  
;*12 SECTORS (1 CYLINDER) ARE READ AT A TIME. IF 'SIN'  
;*OCCURS A DRIVE RESET IS DONE BEFORE READING THE NEXT  
;*SECTOR. READING IS DONE IN THIS ORDER CYL 0-SUR 0;  
;*CYL 0-SUR 1; CYL 1-SUR 0; CYL 1-SUR 1; CYL 2-SUR 0;  
;*CYL 2-SUR 1;-----CYL 312-SUR 1. IF TESTING ON SIMULATOR, ONLY  
;*THE LAST CYLINDER (312), LAST SECTOR (13), SURFACE 1 IS READ.  
:*****  
TST24: SCOPE  
MOV #1,$TIMES ;:DO 1 ITERATION  
MOV #1$,$LPERR ;:SET RETURN ADRES FOR LUPING  
;ON ERROR (SW 9)  
CLR INDX1 ;:INDX1=0, SURFACE 0 BEING READ  
;INDX1=1, SURFACE 1 BEING READ  
MOV DRIVAD,R1 ;:GET DRIVE ADRES  
MOV R1,R2  
TST SIMUL ;:TESTING ON SIMULATOR?  
BEQ 12$ ;:NO, BRANCH  
BIS #14533,R1 ;:SET BITS FOR CYL 312, SEC 13, SUR 1  
;ON SIMULATOR, CHECK ONLY CYL 312,  
;SECTOR 13, SURFACE 1  
BIS #14540,R2 ;:RKDA SHOULD INCRMNT TO THIS AFTR  
;RD FMT OF 1 SECTOR  
MOV #-1,EFLG1 ;:SET COUNT FOR READING HDR  
;FROM 1 SECTOR ONLY  
BR 1$  
12$: MOV #-313,R5 ;:SET UP COUNT FOR 203 CYLINDERS  
MOV #-14,EFLG1 ;:SET COUNT FOR 12 HDRS TO BE  
;READ FROM EACH CYLINDER  
ADD #20,R2 ;:THIS IS WHAT RKDA SHOULD INCREMENT  
;BY, AFTER 'RD FMT' OF EACH CYLINDER  
1$: CNT.RESET ;:GO, DO CONTROL RESET  
;THIS IS A CALL FOR THE 'CNTRL-  
;RESET' ROUTINE. A CONTROL RESET IS  
;ISSUED AND AFTER A CERTAIN TIME  
;IF THE 'CNTRL RDY' DOES NOT SET  
;AN ERROR IS REPORTED. NOTE THAT  
;THE PC IN ERROR MESSAGE IS THE  
;PC WHERE 'CNT.RESET' IS LOCATED.  
;THIS IS A VERY BASIC ERR & IF IT  
;OCCURS GO BACK TO TEST 10  
TST.SIN ;:CHECK IF SIN IS SET  
;IF SET DO DRV-RESET TO CLR IT  
11$: MOV #OUTBUF,R3 ;:STORE ADRES OF BUFFER  
CLR INDX2 ;:ADRES TO WHICH DATA IS TO BE X-FERRED  
MOV R3,@RKBA ;:FROM THE DISK  
MOV EFLG1,@RKWC ;:SET UP WORD COUNT FOR 12 HEADERS  
;TO BE READ OFF EACH CYLINDER  
; (ONLY 1 FOR SIMULATOR)  
MOV R1,@RKDA ;:ADRES THE DRIVE WITH CORRECT  
;CYLINDER & SECTOR ADRES  
MOV #2005,@RKCS ;:READ FORMAT, GO
```


MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2		MACY11 30A(1052) 21-FEB-78		D 6		08:58 PAGE 69	
CZRKKF.P11 21-FEB-78 08:51		T24		CHECK 'READ FORMAT' FOR THE ENTIRE DISK			
				SEQ 0068			
3662	011140	105777	170166	2\$:	TSTB	@RKCS	:DID CNTR1 RDY SET?
3663	011144	100411			BMI	3\$:YES, BRANCH
3664	011146	005237	001360		INC	INDX2	:NO, HAVE U WAITED LONG ENOUGH?
3665	011152	001372			BNE	2\$:IF NOT, LOOP BACK & WAIT FOR IT
3666							:IF YES, REPORT ERROR
3667	011154	004737	020774		JSR	PC,GT4RG	:GO, GET RKCS, ER, DS,DA
3668	011160	010137	001202		MOV	R1,\$REG10	:GET DRIV-ADRES STARTING WHICH
3669							: 'READ FORMAT' WAS DONE
3670	011164	104416			BRKDA4		:GO TO 'BDA4' & BREAK CONTENTS OF
3671							:\$REG10 INTO DR #,CYL,SUR,SEC BITS
3672	011166	104045			ERROR	45	:CNTRL RDY DID NOT SET AFTER
3673							:READ FORMAT. 'RKDA' IN EROR MSGE
3674							:GIVES THE CONTENTS OF RKDA AT THE
3675							:TIME OF ERROR.
3676							:READ FMT WAS DONE STARTING AT <DSK-ADRES>
3677							:INDICATED IN EROR MSGE.
3678							
3679	011170	032777	001000 170130	3\$:	BIT	#1000,@RKDS	:DID 'SIN' SET?
3680	011176	001405			BEQ	4\$:NO, BRANCH
3681	011200	004737	021002		JSR	PC,GT3RG	:GO, GET RKCS, ER, DS
3682	011204	010137	001170		MOV	R1,\$REG3	:GET DISK-ADRES WHERE 'SIN'
3683							:OCCURED
3684	011210	104001			ERROR	1	:SIN ERROR ON DOING RD FMT
3685							:TO CYL INDICATED IN \$REG3
3686							
3687	011212	004737	021226	4\$:	JSR	PC,CHKHE1	:CHECK IF 'ERR' OR 'HE' BIT IS SET,
3688							:IF YES, RETURN HERE.
3689	011216	104046			ERROR	46	:HE OR ERR WHILE DOING A READ
3690							:FORMAT. 'RKDA' IN EROR MSGE GIVES
3691							:THE CONTENTS OF RKDA AT THE TIME OF ERROR
3692							:READ FMT WAS DONE STARTING AT <DSK-ADRES>
3693							:INDICATED IN EROR MESGE
3694	011220	020277	170114	5\$:	CMP	R2,@RKDA	:DID RKDA INCREMENT CORRECTLY BY 12 SEC
3695	011224	001410			BEQ	6\$	
3696	011226	010237	001202		MOV	R2,\$REG10	:GET EXPCTD RKDA
3697	011232	104415			BRKDAO		:GO TO 'BDAO' & BREAK CONTENTS OF
3698							:\$REG10 INTO DR #,CYL,SUR,SEC BITS
3699	011234	017737	170100 001202		MOV	@RKDA,\$REG10	:GET RECVD RDKA
3700	011242	104416			BRKDA4		:GO TO 'BDA4' & BREAK CONTENTS OF
3701							:\$REG10 INTO DR #,CYL,SUR,SEC BITS
3702	011244	104040			ERROR	40	:RKDA DID NOT INCREMENT BY 12 SECTORS
3703							:AFTER RD FMT WAS DONE. ADRES
3704							:OF CYLINDER IN ERROR CAN BE OBTAINED
3705							:FROM 'EXPCTD' RDDA
3706	011246	013700	001370	6\$:	MOV	EFLG1,R0	:SET UP COUNT FOR 12 HEADERS TO B CHKD
3707							:(ONLY 1, IF SIMULATOR)
3708	011252	010104			MOV	R1,R4	:GET DRIV-ADRES FROM WHERE RDFMT WAS DONE
3709	011254	042704	160037		BIC	#160037,R4	:GET THE CYLINDER ADRES ONLY. (HEADER)
3710	011260	020413		7\$:	CMP	R4,(R3)	:IS THE RECVD HEADER SAME AS EXPCTD?
3711	011262	001412			BEQ	8\$	
3712	011264	010437	001164		MOV	R4,\$REG1	:GET EXPCTD HEADER WORD
3713	011270	011337	001166		MOV	(R3),\$REG2	:GET HEADER WORD RECVD
3714	011274	010037	001162		MOV	R0,\$REG0	
3715	011300	062737	000014 001162		ADD	#14,\$REG0	:GET THE SECTOR (OCTAL NO) WHICH DID
3716							:NOT GIVE THE CORRECT HEADER
3717	011306	104043			ERROR	43	:DID NOT RECIEVE THE CORRECT HEADER

3718
3719
3720 011310 005723
3721
3722 011312 005200
3723 011314 001361
3724
3725
3726 011316 004737 021316
3727
3728 011322 104041
3729
3730
3731
3732 011324 005737 001344
3733 011330 001031
3734
3735 011332 005737 001356
3736 011336 001011
3737 011340 005237 001356
3738 011344 062701 000020
3739 011350 010102
3740 011352 062702 000020
3741
3742 011356 000137 011100
3743 011362 005037 001356
3744 011366 042701 000037
3745 011372 062701 000040
3746 011376 010102
3747 011400 062702 000020
3748 011404 005205
3749 011406 001402
3750 011410 000137 011100
3751
3752
3753
3754
3755
3756
3757
3758
3759
3760
3761
3762
3763
3764
3765
3766
3767
3768
3769
3770
3771
3772
3773

```

8$:   TST   (R3)+
      INC   R0
      BNE   7$
      JSR   PC,CHKWC
      ERROR 41

9$:   TST   SIMUL
      BNE   TST25

10$:  JMP   1$
      CLR   INDX1
      BIC   #37,R1
      ADD   #40,R1
      MOV   R1,R2
      ADD   #20,R2
      JMP   1$

;WORD FROM 'SECTOR' AS INDICATED
;(NOTE SECTOR # IS OCTAL)
;INCREMENT POINTER TO THE NXT WORD
;IN MEMORY WHERE THE RECVD HDR IS STORED
;HAVE U CHECKED ALL 12 HEADERS?
;IF NOT, LOOP BACK & CHK THE NXT.
;YES, ALL HEADERS FOR THIS CYLINDER
;CHECKED.
;CHECK IF RKWC OVERFLOWED TO 0, IF
;NOT RETURN HERE.
;RKWC DID NOT OVERFLOW AFTER DOING
;RDFMT OF 12 SECTORS ON THE CYLINDER
;NOTE THAT 'RKDA' IS THE INCREMENTED
;RKDA AFTER THE RDFMT
;TSTING ON SIMULATOR?
;;IF YES, EXIT
;NO
;DOING SURFACE 1
;YES, BRANCH
;NO
;INCREMENT DRV ADRES TO THE NXT SURFACE
;THIS IS WHAT RKDA SHOULD INCREMENT
;TO, AFTER READ FMT OF THE CYLINDER
;GO RD FMT THE NXT SURFACE
;CLR SEC, SURFACE BITS
;INCREMENT TO NXT CYL
;THIS IS WHAT RKDA SHOULD BE
;AFTER RD FMT OF CYLINDER
;HAVE U DONE ALL CYLINDERS?
;;EXIT
;IF NOT, LOOP BACK & READ FMT FROM
;THE NXT CYLINDER
    
```

```

;*****
;*TEST 25    CHECK 'READ' OF THE ENTIRE DISK
;*READ OF THE ENTIRE DISK (ONE WORD PER SECTOR) IS DONE
;*IN THIS TEST.  IN A PREVIOUS TEST THE FIRST WORD OF
;*EVERY SECTOR WAS WRITTEN LIKE A PSUEDO-HEADER (DRIVE #,
;*CYLINDER #, SURFACE & SECTOR #).  THESE PSUEDO HEADERS
;*WILL BE READ & CHECKED IN THIS TEST, PROVING THAT ANY
;*SECTOR CAN BE ACCESSED AND READ.
;*THE FOLLOWING CHECKING IS DONE
;*1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
;*OF FUNCTION.
;*2. IF 'SIN' OCCURRED?
;*3. IF 'HE' OR 'ERR' OCCURRED?
;*4. THE CORRECT FIRST WORD FROM EVERY SECTOR
;*WAS RECEIVED.  THIS WORD REFLECTS THE ABSOLUTE
;*DISK ADDRESS (DRV #, CYL #, SUR, SEC#) OF THAT SECTOR.
;*5. IF RKDB CONTAINED THE CORRECT WORD.
;*IF 'SIN' OCCURS DRIVE RESET IS DONE BEFORE READING
;*THE NEXT SECTOR.  READ IS DONE IN THIS ORDER SEC 0-11
;*CYL 0 SUR 0 -> SEC 0-11 CYL 0 SUR 1 -> SEC 0-11 CYL 1,.....
    
```



```

3774                                     ;*IF TESTING ON SIMULATOR ONLY LAST CYLINDER (312), LAST
3775                                     ;*SECTOR (13), SURFACE 1 IS READ.
3776                                     ;*****
3777 011414 000004 TST25: SCOPE
3778 011416 012737 000001 001206 MOV #1,$TIMES ;;DO 1 ITERATION
3779 011424 012737 011470 001110 MOV #1$,$LPERR ;SET RETURN ADRES FOR
3780                                     ;LOOPING ON ERROR (SW9)
3781 011432 012703 033342 MOV #OUTBUF,R3
3782 011436 005004 CLR R4 ;FLAG, CLEAR WHEN READING SURFACE 0
3783                                     ;SET WHEN READING SURFACE 1
3784 011440 013701 001350 MOV DRIVAD,R1 ;GET DRIVE ADDRESS
3785 011444 005737 001344 TST SIMUL ;TSTING ON SIMULATOR?
3786 011450 001403 BEQ 10$ ;IF NOT BRANCH
3787 011452 052701 014533 BIS #14533,R1 ;SET ADRES BITS FOR LAST CYL (312)
3788 011456 000404 BR 1$ ;LAST SECTOR (13), SURFACE 1
3789 011460 012700 177764 10$: MOV #-14,R0 ;SET COUNT FOR 12 SECTORS
3790 011464 012705 177465 MOV #-313,R5 ;SET UP COUNT FOR 203 CYLINDERS
3791
3792 011470 104413 1$: CNT.RESET ;GO, DO CONTROL RESET
3793                                     ;THIS IS A CALL FOR THE 'CNTRL-
3794                                     ;RESET' ROUTINE. A CONTROL RESET IS
3795                                     ;ISSUED AND AFTER A CERTAIN TIME
3796                                     ;IF THE 'CNTRL RDY' DOES NOT SET
3797                                     ;AN ERROR IS REPORTED. NOTE THAT
3798                                     ;THE PC IN ERROR MESSAGE IS THE
3799                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
3800                                     ;THIS IS A VERY BASIC ERR & IF IT
3801                                     ;OCCURS GO BACK TO TEST 10
3802 011472 104421 TST.SIN ;GO CHECK SIN, IF SET DO
3803                                     ;DRIVE RESET TO CLR IT
3804 011474 005037 001356 8$: CLR INDX1
3805 011500 010377 167632 MOV R3,@RKBA ;ADRES TO WHICH DATA IS TO B X-FERRED
3806                                     ;FROM THE DISK
3807 011504 012777 177777 167622 MOV #-1,@RKWC ;SET UP WORD COUNT
3808 011512 010177 167622 MOV R1,@RKDA ;ADRES THE DRIVE WITH CORRECT
3809                                     ;CYLINDER & SECTOR ADRES
3810 011516 012777 000005 167606 MOV #5,@RKCS ;READ, GO
3811
3812 011524 105777 167602 2$: TSTB @RKCS ;DID CNTRL RDY SET?
3813 011530 100411 BMI 3$ ;YES, BRANCH
3814 011532 005237 001356 INC INDX1 ;NO, HAVE U WAITED LONG ENOUGH
3815 011536 001372 BNE 2$ ;IF NOT, LOOP BACK & WAIT FOR IT
3816                                     ;IF YES, REPORT ERROR
3817 011540 004737 020774 JSR PC,GT4RG ;GO, GET RKCS, ER, DS,DA
3818 011544 010137 001202 MOV R1,$REG10 ;GET DISK-ADRES WHERE ERROR OCCURED
3819 011550 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
3820                                     ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3821 011552 104045 ERROR 45 ;CNTRL RDY DID NOT SET AFTER DOING
3822                                     ;A 1 WORD READ FROM ADRES AS
3823                                     ;INDICATED IN <DISK-ADRES>
3824                                     ;'RKDA' IN EROR MSGE GIVES THE
3825                                     ;CONTENTS OF RKDA AT THE TIME OF ERROR
3826
3827 011554 032777 001000 167544 3$: BIT #1000,@RKDS ;DID 'SIN' SET?
3828 011562 001405 BEQ 4$ ;NO, BRANCH
3829 011564 004737 021002 JSR PC,GT3RG ;GO, GET RKCS, ER, DS

```

3830	011570	010137	001170		MOV	R1,\$REG3		;GET DISK-ADRES WHERE SIN OCCURED3
3831	011574	104001			ERROR	1		;'SIN' ERROR ON DOING READ FROM
3832								;DISK-ADRES INDICATED IN \$REG3
3833	011576	004737	021226	4\$:	JSR	PC,CHKHE1		;CHECK IF 'ERR' OR 'HE' BIT IS SET,
3834								;IF YES, RETURN HERE.
3835	011602	104046			ERROR	46		;'HE' OR 'ERR' ON DOING A READ OF
3836								;1 WORD FROM ADRES AS INDICATED
3837								;IN <DISK-ADRES>
3838								;'RKDA' IN EROR MSGE GIVES THE
3839								;CONTENTS OF RKDA AT THE TIME OF EROR
3840	011604	020113		5\$:	CMP	R1,(R3)		;WAS THE CORRECT DATA WORD RECVD?
3841	011606	001407			BEQ	6\$		
3842	011610	010137	001162		MOV	R1,\$REG0		;GET EXPCTD DATA WORD
3843	011614	011337	001164		MOV	(R3),\$REG1		;GET DATA WORD RECVD
3844	011620	010137	001166		MOV	R1,\$REG2		;GET DISK-ADRES
3845	011624	104044			ERROR	44		;DID NOT RECIEVE THE CORRECT
3846								;DATA WORD FROM DISK ON DOING
3847								;1 WORD READ FROM 'DISK-ADRES'
3848								;AS INDICATED BY 'EXPCTD' DATA WORD
3849								;NOTE THAT IN A PREVIOUS TEST THE
3850								;FIRST WORD OF EACH SECTOR IS UNIQUELY
3851								;WRITTEN WITH A WORD GIVING THE
3852								;ABSOLUTE ADDRESS OF THAT SECTOR IN
3853								;TERMS OF, DRIV #, CYL ADRES, SUR, SEC ADRS.
3854	011626	020177	167510	6\$:	CMP	R1,@RKDB		;DOES RKDB CONTAIN CORRECT WORD
3855	011632	001406			BEQ	7\$;YES, BRANCH
3856	011634	010137	001162		MOV	R1,\$REG0		;NO, GET EXPCTD RKDB
3857	011640	017737	167476	001164	MOV	@RKDB,\$REG1		;GET RKDB RECVD
3858	011646	104037			ERROR	37		;RKDB ERROR ON READ.
3859								;FOR RK11C, AFTER A READ RKDB
3860								;CONTAINS CHECKSUM FOR THE SECTOR
3861								;READ.
3862								;WHEREAS FOR RK11D, AFTER READ
3863								;RKDB CONTAINS THE LAST WORD
3864								;READ FROM THAT SECTOR &
3865								;X-FERRED TO MEMORY
3866	011650	005737	001344	7\$:	TST	SIMUL		;TESTING ON SIMULATOR?
3867	011654	001022			BNE	TST26		;:IF YES, EXIT
3868	011656	005201			INC	R1		;INCREMENT TO ADRES NEXT SECTOR
3869	011660	005200			INC	R0		;HAVE U CHKD ALL 12 SECTORS?
3870	011662	001302			BNE	1\$;IF NOT, LUP BAK & CHK THE NXT
3871								;IF YES...
3872	011664	012700	177764		MOV	#-14,R0		;RESET THE COUNT FOR 12 SECTORS
3873	011670	042701	000037		BIC	#37,R1		;CLEAR SECTOR, SURFACE BITS
3874	011674	005704			TST	R4		;DOING SURFACE 1?
3875	011676	001004			BNE	9\$;YES, BRANCH
3876	011700	005204			INC	R4		;NO
3877	011702	062701	000020		ADD	#20,R1		;INCREMENT THE ADRES TO NXT SURFACE
3878	011706	000670			BR	1\$;GO READ SURFACE 1
3879	011710	005004		9\$:	CLR	R4		
3880	011712	062701	000040		ADD	#40,R1		;INCREMENT TO NXT CYL
3881	011716	005205			INC	R5		;HAVE U CHKD ALL 203 CYLINDERS
3882	011720	001263			BNE	1\$;IF NOT, LOOP BACK & CHK THE NXT CYLINDER
3883								;YES
3884								
3885								


```
3886  
3887  
3888  
3889  
3890  
3891  
3892  
3893  
3894 011722 000004  
3895 011724 012737 000005 001206  
3896 011732 012703 001372  
3897  
3898 011736 005037 001356  
3899  
3900 011742 013700 001332  
3901 011746 013701 001326  
3902 011752 013702 001330  
3903 011756 012737 011764 001110  
3904  
3905 011764 000240 1$: NOP  
3906 011766 104413 2$: CNT.RESET  
3907  
3908  
3909  
3910  
3911  
3912  
3913  
3914  
3915  
3916 011770 104421 TST.SIN  
3917  
3918  
3919  
3920 011772 013704 001350  
3921 011776 051304  
3922 012000 010477 167334  
3923 012004 012710 000011  
3924  
3925 012010 104412  
3926  
3927 012012 104021  
3928  
3929  
3930  
3931 012014 005005 4$: CLR R5  
3932 012016 032711 000100 5$: BIT #100,@R1  
3933 012022 001005 BNE 6$  
3934 012024 005205 INC R5  
3935 012026 001373 BNE 5$  
3936 012030 004737 020774 JSR PC,GT4RG  
3937 012034 104026 ERROR 26  
3938  
3939 012036 032711 001000 6$: BIT #1000,@R1  
3940 012042 001403 BEQ 7$  
3941 012044 004737 020774 JSR PC,GT4RG
```

: *TEST 26 CHECK 'SEEK' FUNCTION, WITH DIFFERENT VELOCITY MODES
: * THIS TEST CHECKS SEEK IN DIFFERENT VELOCITY MODES (DIFF <3,
: * 3 < DIFF < 31, DIFF > 31). FOR THESE 3 BASIC VELOCITIES SEEK IS DONE BOTH
: * IN FWD AND REV DIRECTION TO CHECK THE ADDER & DIFFERENCE LOGIC. IF
: * WHILE DOING A SEEK 'SIN' OCCURS, A DRIVE RESET IS DONE TO INITIALIZE
: * THE POSITIONING LOGIC

TST26: SCOPE
MOV #5,\$TIMES ;:DO 5 ITERATIONS
MOV #SEEK0,R3 ;:INITIALIZE POINTER TO THE FIRST
;:SEEK ADDRESS
CLR INDX1 ;:INDX1, WHEN 0 INDICATES SEEK IN FWD DIRECTION
;: WHEN 1 INDICATES SEEK IN REV DIRECTION
MOV RKCS,R0
MOV RKDS,R1
MOV RKER,R2
MOV #1\$,\$LPERR ;:SET RETURN ADRES FOR LUPING ON
;:EROR (SW 9)
1\$: NOP
2\$: CNT.RESET ;:GO, DO CONTROL RESET
;:THIS IS A CALL FOR THE 'CNTRL-
;:RESET' ROUTINE. A CONTROL RESET IS
;:ISSUED AND AFTER A CERTAIN TIME
;:IF THE 'CNTRL RDY' DOES NOT SET
;:AN ERROR IS REPORTED. NOTE THAT
;:THE PC IN ERROR MESSAGE IS THE
;:PC WHERE 'CNT.RESET' IS LOCATED.
;:THIS IS A VERY BASIC ERR & IF IT
;:OCCURS GO BACK TO TEST 10
;:GO, CHECK IF SIN IS SET, IF SET
;:DO DRV-RESET TO CLEAR IT
MOV DRIVAD,R4 ;:GET DRIV-ADRES
BIS (R3),R4 ;:SET CYLINDER BITS
MOV R4,@RKDA ;:ADDRS THE DRIVE
MOV #11,@R0 ;:SET 'SEEK', 'GO'
CHKCRDY ;:GO CHECK IF CONTROL RDY IS SET
;:IF SO, SKIP THE EROR MESSAGE.
ERROR 21 ;:'CNTRL RDY' DID NOT SET AFTER
;:SENDING CYL ADD TO THE DRIV, 'ADD ACK'
;:FROM DRIVE SHLD HAVE COME BACK
;:THEREUPON SETTING 'CNTRL RDY'
4\$: CLR R5
5\$: BIT #100,@R1 ;:DID R/W/S RDY SET?
BNE 6\$;:YES, BRANCH
INC R5 ;:NO, WAIT
BNE 5\$;:WAITED LONG?
JSR PC,GT4RG ;:GO, GET RKCS, ER, DS, DA
ERROR 26 ;:R/W/S RDY DID NOT SET ON
;:COMPLETION OF SEEK
6\$: BIT #1000,@R1 ;:DID SIN SET?
BEQ 7\$;:NO, BRANCH
JSR PC,GT4RG ;:GO, GET RKCS, ER, DS, DA

```
3942 012050 104001          ERROR 1          ;SIN SET ON DOING SEEK
3943 012052 032710 140000 7$: BIT #140000,@R0 ;DID 'HE' OR 'ERR' SET?
3944 012056 001403          BEQ 8$          ;YES
3945 012060 004737 020774 JSR PC,GT4RG    ;GO, GET RKCS, ER, DS, DA
3946 012064 104022          ERROR 22        ;'ERR OF 'HE' BIT SET WHEN
3947                                     ;SEEKING TO CYL AS INDICATED
3948                                     ;IN RKDA
3949
3950 012066 022710 000210 8$: CMP #210,@R0   ;DOES RKCS STILL CONTAIN THE 'SEEK' FNCTION
3951 012072 001406          BEQ 9$          ;YES - EXIT
3952 012074 011037 001164 MOV @R0,$REG1   ;NO, GET RKCS RECVD
3953 012100 012737 000210 001162 MOV #210,$REG0 ;GET EXPCTD RKCS
3954 012106 104024          ERROR 24          ;RKCS SHOULD CONTAIN THE 'SEEK' BITS
3955                                     ;IF NOT, ERROR
3956
3957 012110 020477 167224 9$: CMP R4,@RKDA   ;DID RKDA CHANGE?
3958 012114 001406          BEQ 10$         ;NO
3959 012116 010437 001164 MOV R4,$REG0    ;YES, GET EXPCTD?
3960 012122 017737 167212 001164 MOV @RKDA,$REG1 ;GET RKDA
3961 012130 104027          ERROR 27          ;RKDA CHANGED AFTER DOING SEEK
3962
3963 012132 010477 167202 10$: MOV R4,@RKDA   ;ADRES THE DRIVE, SEC 0
3964 012136 012777 033342 167172 MOV #OUTBUF,@RKBA ;READ ONE HEADER INTO THIS
3965 012144 012777 177777 167162 MOV #-1,@RKWC   ;BUS ADRES
3966 012152 012710 002005 MOV #2005,@R0   ;GO, READ FORMAT
3967 012156 104414          CNT.RDY        ;WAIT FOR CNTRL RDY
3968 012160 021337 033342 CMP (R3),OUTBUF ;WAS THE CORRECT READE4R READ (FROM
3969 012164 001410          BEQ 11$         ;CYLINDER TO WHICH SEEK WAS DONE BEFORE)
3970 012166 005037 001162 CLR $REG0       ;STORE SEC # FROME WHERE HDR WAS RD (0)
3971 012172 011337 001164 MOV (R3),$REG1  ;GET EXPCTD HEADER
3972 012176 013737 033342 001166 MOV OUTBUF,$REG2 ;GET HDR RECVD
3973 012204 104043          ERROR 43          ;WRONG HDR WAS RECVD FROM CYLINDER (ADRES
3974                                     ;IN ER MSGE). NOTE THAT A PURE SEEK WAS
3975                                     ;DONE TO THIS CYL BEFORE READING HDR
3976                                     ;USING READ FORMAT
3977 012206 005737 001356 11$: TST INDX1       ;SEEK IN REVRSE DIRECTION?
3978 012212 001007          BNE 12$         ;YES, BRANCH
3979 012214 005723          TST (R3)+       ;NO, INCREMENT PTR TO NXT SEEK ADRES
3980 012216 022703 001400 CMP #SEEK2+2,R3 ;DONE WITH ALL SKS IN FWD DIR?
3981 012222 001260          BNE 1$          ;NO, GO & DO NXT ONE
3982 012224 005237 001356 INC INDX1       ;SET FLAG INDICATING SK IN REVRSE
3983 012230 005743          TST -(R3)      ;
3984 012232 005743          TST -(R3)      ;POSITION PTR TO NXT SK IN REV
3985 012234 022703 001370 12$: CMP #SEEK0-2,R3 ;DONE WITH ALL?
3986 012240 001251          BNE 1$          ;IF NOT, DO NXT ONE
```

```
3987
3988
3989
3990 ;:*****
3991 ;*TEST 27 CHECK DRIVE RESET FROM LAST CYLINDER
3992 ;*THE HEADS ARE POSITIONED ON THE LAST CYLINDER (DOING
3993 ;*AN IMPLIED SEEK-READ). THEN A DRIVE RESET IS ISSUED.
3994 ;*IT'S CHECKED IF THE HEADS WERE BROUGHT BACK TO 0 BY
3995 ;*DOING A 1 WORD READ & CHECKING THAT THE CORRECT WORD
3996 ;*WAS RECEIVED. IF TESTING ON SIMULATOR THIS TEST IS SKIPPED.
3997 ;:*****
```



```

3998 012242 000004
3999 012244 012737 000005 001206
4000 012252 005737 001344
4001 012256 001124
4002 012260 013701 001332
4003 012264 104413
4004
4005
4006
4007
4008
4009
4010
4011
4012
4013 012266 005000
4014 012270 012703 033342
4015 012274 013704 001350
4016 012300 010405
4017 012302 052705 014500
4018 012306 010577 167026
4019 012312 012777 177777 167014
4020 012320 010377 167012
4021
4022 012324 012711 000005
4023
4024 012330 005000
4025 012332 104414
4026
4027
4028
4029
4030
4031
4032 012334 020513
4033 012336 001407
4034 012340 010537 001162
4035 012344 011337 001164
4036 012350 010537 001166
4037 012354 104044
4038
4039
4040
4041
4042 012356 012711 000015
4043 012362 104414
4044
4045
4046
4047
4048
4049
4050 012364 005000
4051 012366 032777 000100 166732
4052 012374 001011
4053 012376 012702 177763
    
```

TST27: SCOPE

```

MOV #5,$TIMES ;:DO 5 ITERATIONS
TST SIMUL ;:R U ON A SIMULATOR?
BNE TST30 ;:YES, EXIT
MOV RKCS,R1
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10

CLR R0
MOV #OUTBUF,R3 ;ADRES WHERE DATA WILL BE READ INTO
MOV DRIVAD,R4
MOV R4,R5
BIS #14500,R5 ;SET CYL ADRES=312 (OCTAL)
MOV R5,@RKDA ;ADRES THE DRIVE, LAST CYLINDER
MOV #-1,@RKWC ;READ 1 WORD
MOV R3,@RKBA ;INTO THIS MEMORY ADRES

MOV #5,@R1 ;READ, GO

1$: CLR R0
CNT.RDY ;THIS IS A CALL FOR CN.RDY ROUTINE
;WHICH WAITS FOR CNTRL RDY TO SET.
;A RETURN IS MADE AFTER CNTRL RDY
;SETS. IF WITHIN A CERTAIN TIME
;CNTRL RDY DOESN'T SET AN ERROR
;MESSAGE IS GIVEN. WAITING TIME
;883 MS FOR 11/20, 175 MS FOR 11/45
;WAS THE CORRECT WORD READ?
;YES, SEEK TO 312 WAS DONE CORRECTLY5,a

2$: CMP R5,@R3
BEQ 3$ ;GET EXPCTD WORD
MOV R5,$REG0 ;GET WORD RECVD
MOV @R3,$REG1 ;GET DSK-ADRES FROM WHERE WORD WAS READ
MOV R5,$REG2 ;DID NOT READ BACK CORRECT WORD FROM
ERROR 44 ;LAST CYL, SEC 0. IF TEST 45 & 46
;WERE SUCCESSFULLY DONE THIS
;ERROR MEANS THAT IMPLIED SEEK
;TO CYL 312 COULD NOT B DONE

3$: MOV #15,@R1 ;DRIVE RESET, GO
CNT.RDY ;THIS IS A CALL FOR CN.RDY ROUTINE
;WHICH WAITS FOR CNTRL RDY TO SET.
;A RETURN IS MADE AFTER CNTRL RDY
;SETS. IF WITHIN A CERTAIN TIME
;CNTRL RDY DOESN'T SET AN ERROR
;MESSAGE IS GIVEN. WAITING TIME
;883 MS FOR 11/20, 175 MS FOR 11/45

4$: CLR R0
BIT #100,@RKDS ;DID R/W/S RDY SET?
BNE 5$ ;YES, BRANCH
MOV #-15,R2 ;IF U R ON A SLOWER MACHINE
    
```


4110
4111
4112
4113
4114
4115
4116
4117
4118
4119 012530 000004
4120 012532 104413
4121
4122
4123
4124
4125
4126
4127
4128
4129
4130 012534 104421
4131
4132 012536 013704 001332
4133
4134
4135
4136
4137
4138
4139
4140
4141
4142
4143
4144
4145
4146
4147 012542 012700 033342
4148 012546 012701 177401
4149 012552 012702 177400
4150 012556 012703 177400
4151
4152 012562 010320
4153 012564 005202
4154 012566 060103
4155 012570 010320
4156 012572 005202
4157 012574 001374
4158
4159 012576 012777 177400 166530
4160 012604 012777 033342 166524
4161 012612 013777 001350 166520
4162
4163 012620 012714 000003
4164
4165 012624 105714

```
*****  
*TEST 30 'WRITE' - 256 WORD BLOCK ON SECTOR 0, CYLINDER 0  
:THE TEST BELOW SHOULD BE CONSIDERED AS A SET UP PHASE FOR  
:THE FOLLOWING TEST. IT WRITES A BLOCK OF 256 WORDS IN  
:SECTOR 0, CYLINDER 0 WITH A SPECIFIC PATTERN AND THIS WRITTEN  
:BLOCK WILL BE MADE USE OF IN THE NEXT TEST TO CHECK  
:OUT 'WRITE-CHECK' AND 'READ CHECK' FUNCTIONS.  
*****  
TST30: SCOPE  
CNT.RESET  
;GO, DO CONTROL RESET  
;THIS IS A CALL FOR THE 'CNTRL-  
;RESET' ROUTINE. A CONTROL RESET IS  
;ISSUED AND AFTER A CERTAIN TIME  
;IF THE 'CNTRL RDY' DOES NOT SET  
;AN ERROR IS REPORTED. NOTE THAT  
;THE PC IN ERROR MESSAGE IS THE  
;PC WHERE 'CNT.RESET' IS LOCATED.  
;THIS IS A VERY BASIC ERR& IF IT  
;OCCURS GO BACK TO TEST 10  
;CHECK IF SIN IS SET, IF SET  
;DO DRIVE RESET TO CLEAR IT  
  
TST.SIN  
MOV RKCS,R4  
;THE FOLLOWING CODE IS FOR SETTING  
;UP THE I/O BUFFER IN MEMORY (STARTING AT  
;OUTBUF), WITH A PARTICULAR 256 WORD PATTERN.  
;STARTING FROM THE FIRST WORD IN THE BUFFER  
;THE LO BYTE WILL BE A COUNT PATTERN  
;FROM 0 TO 255 (DECIMAL), WHEREAS THE  
;HI-BYTE WILL BE THE COMPLEMENT OF LO BYTE,  
;A DECREASING COUNT PATTERN FROM 255 TO 0.  
;I.E.THE BUFFER WILL LOOK LIKE:  
;OUTBUF (1 111 111 1 00 000 000)  
;OUTBUF+2 (1 111 111 0 00 000 001)  
;:  
;LAST WORD (0 000 000 0 11 111 111)  
  
MOV #OUTBUF,R0  
MOV #177401,R1 ;PATTERN GENERATING NUMBER  
MOV #-400,R2 ;SET UP COUNT FOR 256 WORDS  
MOV #177400,R3 ;SET UP THE FIRST PATTERN TO B WRITTEN  
  
MOV R3,(R0)+ ;SET UP FIRST WORD IN I/O BUFFER  
INC R2 ;INCREMENT COUNT  
1$: ADD R1,R3 ;SET UP NEXT WORD PATTERN  
MOV R3,(R0)+ ;WRITE IT IN NXT I/O BUFFER WORD  
INC R2 ;HAVE U WRITTEN ALL 256 WORDS  
BNE 1$ ;IF NOT GO & WRITE NEXT PATTERN  
  
MOV #-400,@RKWC ;WRITE 256 WORDS  
MOV #OUTBUF,@RKBA ;STARTING FROM THIS BUS ADRES  
MOV DRIVAD,@RKDA ;TO THIS DISK ADRES, CYL 0, SEC 0  
  
MOV #3,@R4 ;WRITE, GO  
2$: TSTB @R4 ;WAS CNTRL RDY CLEARED AS GO WAS SET?
```



```

4222
4223
4224
4225
4226
4227
4228
4229
4230
4231
4232
4233 012764 000004
4234 012766 104413
4235
4236
4237
4238
4239
4240
4241
4242
4243
4244 012770 104421
4245
4246 012772 012700 177400
4247 012776 012701 033342
4248 013002 005021
4249 013004 005200
4250 013006 001375
4251 013010 005000
4252 013012 012777 177400 166314
4253 013020 012777 033342 166310
4254 013026 013777 001350 166304
4255
4256 013034 012777 000005 166270
4257
4258 013042 105777 166264
4259 013046 100411
4260 013050 005200
4261 013052 001373
4262
4263 013054 004737 020774
4264 013060 013737 001350 001202
4265 013066 104416
4266
4267 013070 104045
4268
4269
4270
4271
4272
4273 013072 032777 001000 166226
4274 013100 001033
4275 013102 012701 177400
4276 013106 012702 177777
4277 013112 012703 033342

```

```

*****
;*TEST 31 CHECK THAT WRITE WAS DONE CORRECTLY
;*THIS TEST CHECKS IF THE 'WRITE' OF 256 WORDS DONE IN PREVIOUS
;*TEST IS GOOD. THE SEQUENCE OF OPERATIONS IS AS FOLLOWING:
;*1) DO A READ OF 256 WORDS FROM SECTOR 0, CYLINDER 0
;* INTO A BUFFER STARTING AT 'OUTBUF'.
;*2) COMPARE & CHECK THE DATA THAT IS READ (STARTING AT 'OUTBUF')
;* WITH THE DATA THAT WAS GENERATED PREVIOUSLY
;*3) REPORT AN ERROR IF THE DATA READ BACK FROM DISK DOES
;* NOT COMPARE WITH DATA THAT WAS SUPPOSE TO HAVE BEEN WRITTEN
*****

```

```

TST31: SCOPE
CNT.RESET
;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;CHECK IF SIN IS SET, IF SET
;DO DRIVE RESET TO CLEAR IT
;SET COUNT FOR 400 WORDS
;TO BE CLEARED IN THE BUFFER
;CLR THE 400 WORD BUFFER
;STARTING AT 'OUTBUF'

TST.SIN
8$: MOV #-400,R0
MOV #OUTBUF,R1
CLR (R1)+
INC R0
BNE 8$
CLR R0
MOV #-400,@RKWC ;READ 256 WORDS
MOV #OUTBUF,@RKBA ;INTO THIS ADRES
MOV DRIVAD,@RKDA ;STARTING FROM THIS DISK ADRES

MOV #5,@RKCS ;READ, GO

1$: TSTB @RKCS ;DID CNTRL RDY SET?
BMI 2$ ;YES, BRANCH
INC R0 ;WAITED LONG ENOUGH?
BNE 1$ ;IF NOT, LUP BAK & WAIT
;ERROR, IF YES
JSR PC,GT4RG ;GO, GET RKCD, ER, DS, DA
MOV DRIVAD,$REG10 ;GET THE STARTING ADRES
BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
; $REG10 INTO DRV #, CYL, SUR, SEC BITS
ERROR 45 ;CNTRL RDY DID NOT SET AFTER READ
;OF 400 WORDS FROM CYL 0, SEC 0
;'RKDA' IN EROR MSGE GIVES THE
;CONTENTS OF RKDA AT THE TIME OF EROR
;READ WAS DONE STARTING AT <DSK-ADRES>
;INDICATED IN EROR MESGE

2$: BIT #1000,@RKDS ;IS SIN SET?
BNE TST32 ;;IF YES, EXIT

5$: MOV #-400,R1
MOV #177777,R2
MOV #OUTBUF,R3

```

```
4278 013116 012705 177773
4279 013122 062702 177401
4280 013126 020213
4281
4282 013130 001414
4283
4284 013132 010137 001162
4285 013136 062737 000401 001162
4286 013144 010237 001164
4287
4288 013150 011337 001166
4289 013154 104055
4290
4291
4292
4293 013156 005205
4294 013160 001403
4295 013162 005723
4296
4297 013164 005201
4298 013166 001355
4299
4300
4301
4302
4303
4304
4305
4306
4307 013170 000004
4308 013172 104413
4309
4310
4311
4312
4313
4314
4315
4316
4317
4318 013174 104421
4319
4320 013176 013701 001332
4321 013202 013702 001334
4322 013206 013703 001340
4323 013212 013704 001336
4324 013216 012737 052525 033342
4325 013224 012712 177400
4326 013230 013713 001350
4327 013234 012714 033342
4328 013240 012711 000013
4329
4330 013244 105711
4331 013246 100003
4332 013250 004737 021002
4333 013254 104030

6$: MOV #-5,R5
ADD #177401,R2
CMP R2,(R3); WAS THE READ WORD SAME AS THE WORD
; THAT WAS SUPPOSE TO BE WRITTEN
; YES, BRANCH
; NO, ERROR
; GET THE # OF WORD
; THAT IS IN ERROR (EXAMPLE=1,2--376,377,400)
; GET EXPCTD WORD (THAT WAS SUPPOSED TO
; BE WRITTEN)
; GET WORD RECVD (THAT WAS READ BAK)
; DID NOT READ BACK WORD THAT WAS SUPPOSED
; TO HAVE BEEN WRITTEN PREVIOUSLY. POSITION
; OF WORD IN ERROR IS AS INDICATED BY
; WORD # ($REG0), SEC 0, CYL 0

7$: INC R5
BEQ TST32
TST (R3)+
;:EXIT
; INCREMENT POINTER TO NXT WORD (THAT
; WAS READ BACK)
; HAVE U CHKD ALL 256 WORDS?
; IF NOT, LUP BAK & CHK THE NXT WORD
; IF YES, EXIT

;:*****
;*TEST 32 CHECK 'READ CHECK' FUNCTION - CYLINDER 0, SECTOR 0
;*THIS TEST CHECKS OUT THE BASIC 'READ CHECK' LOGIC, USING THE DATA BLOCK
;*CYLINDER, SECTOR 0) WRITTEN IN A PREVIOUS TEST. HENCE THE TEST WHICH
;*WRITES THE DATA BLOCK SHOULD BE DONE PRIOR TO THIS TEST.
;:*****
TST32: SCOPE
CNT.RESET
; GO, DO CONTROL RESET
; THIS IS A CALL FOR THE 'CNTRL-
; RESET' ROUTINE. A CONTROL RESET IS
; ISSUED AND AFTER A CERTAIN TIME
; IF THE 'CNTRL RDY' DOES NOT SET
; AN ERROR IS REPORTED. NOTE THAT
; THE PC IN ERROR MESSAGE IS THE
; PC WHERE 'CNT.RESET' IS LOCATED.
; THIS IS A VERY BASIC ERR& IF IT
; OCCURS GO BACK TO TEST 10
; CHECK IF SIN IS SET, IF SET
; DO DRIVE RESET TO CLEAR IT

TST.SIN

MOV RKCS,R1
MOV RKWC,R2
MOV RKDA,R3
MOV RKBA,R4
MOV #52525,OUTBUF
MOV #-400,@R2
MOV DRIVAD,@R3
MOV #OUTBUF,@R4
MOV #13,@R1
; READ CHECK 256 WORDS
; STARTING FROM CYL 0, SECTOR 0
; READ CHECK, GO

1$: TSTB @R1
BPL 2$
JSR PC,GT3RG
ERROR 30
; DID CNTRL RDY GET CLEARED AS GO WAS SET?
; YES, BRANCH
; GET RKCS, ER, DS
; CNTRL RDY DID NOT CLEAR AS GO
```



```

4334 013256 104412      2$:  CHKCRDY      ;GO CHECK IF CONTROL RDY IS SET
4335                                     ;IF SO, SKIP THE EROR MESSAGE.
4336                                     ;WAS SET TO 'READ CHECK'
4337 013260 104056      ERROR 56      ;CNTRL RDY DID NOT SET ON DOING
4338                                     ;'READ CHECK' FROM CYL 0, SEC 0
4339 013262 032711 140000 3$:  BIT #140000,@R1 ;DID 'ERR' OR 'HE' BIT SET?
4340 013266 001403      BEQ 4$      ;NO, BRANCH
4341 013270 004737 021002 JSR PC,GT3RG ;GO, GET RKCS,ER,DS FOR ERROR MESSAGE
4342 013274 104057      ERROR 57      ;'ERR' OR 'HE' BIT SET ON DOING
4343                                     ;'READ CHECK' ON CYLINDER 0, SEC 0
4344 013276 032777 000002 166024 4$:  BIT #2,@RKER ;DID 'CSE' BIT SET IN RKER?
4345 013304 001404      BEQ 5$      ;NO, BRANCH
4346 013306 017737 166016 001162 MOV @RKER,$REG0 ;GET RKER
4347 013314 104060      ERROR 60      ;SOFT ERROR - CSE - ON DOING 'READ
4348                                     ;CHECK' ON CYLINDER 0, SECTOR 0
4349                                     ;U SHOULD HAVE GOT ERROR 102 ALSO
4350 013316 005712      5$:  TST @R2      ;DID WORD COUNT OVERFLOW TO 0?
4351 013320 001405      BEQ 6$      ;YES, BRANCH
4352 013322 011237 001162 MOV @R2,$REG0 ;GET RKWC
4353 013326 011137 001164 MOV @R1,$REG1 ;GET RKCS
4354 013332 104061      ERROR 61      ;WORD COUNT DID NOT OVERFLOW
4355                                     ;ON DOING 'READ CHK' ON CYL 0, SEC 0
4356 013334 013702 001350 6$:  MOV DRIVAD,R2 ;RKDA SHOULD INCREMENT
4357 013340 005202      INC R2      ;TO THIS AFTER 'RD CHK' IS DONE
4358 013342 020213      CMP R2,@R3 ;DID RKDA INCREMENT CORRECTLY?
4359 013344 001405      BEQ 7$      ;GET EXPCTD RKDA
4360 013346 010237 001162 MOV R2,$REG0 ;GET RKDA RECVD
4361 013352 011337 001164 MOV @R3,$REG1 ;RKDA DID NOT INCREMENT CORRECTLY
4362 013356 104062      ERROR 62      ;(BY 1) ON DOING 'READ CHK' ON
4363                                     ;CYL 0, SEC 0
4364                                     ;DID RKBA GET CHANGED?
4365 013360 022714 033342 7$:  CMP #OUTBUF,@R4 ;NO, BRANCH (RKBA WON'T CHANGE, NO NPR'S)
4366 013364 001406      BEQ 8$      ;GET EXPCTD RKBA
4367 013366 012737 033342 001162 MOV #OUTBUF,$REG0 ;GET RKBA RECVD
4368 013374 011437 001164 MOV @R4,$REG1 ;RKBA CHANGED AFTER DOING 'READ CHK'
4369 013400 104063      ERROR 63      ;ON CYLINDER 0, SECTOR 0. SHOULD
4370                                     ;NOT CHANGE, FOR, NO NPR'S.
4371                                     ;'OUTBUF' SHOULD STILL CONTAIN THE
4372 013402 022737 052525 033342 8$:  CMP #52525,OUTBUF ;SAME WORD AS IT DID BEFORE 'RD CHK'
4373                                     ;NOTE THAT AT THE BEGINING OF THIS TEST
4374                                     ;52525 WAS WRITTEN INTO 'OUTBUF'
4375                                     ;:YES, EXIT
4376 013410 001412      BEQ TST33    ;REPORT ERROR IF 'OUTBUF' CHANGED
4377                                     ;GET ADRES OF OUTBUF
4378 013412 012737 033342 001162 MOV #OUTBUF,$REG0 ;GET EXPCTD WORD IN 'OUTBUF'
4379 013420 012737 052525 001164 MOV #52525,$REG1 ;GET WORD FOUND IN 'OUTBUF'
4380 013426 013737 033342 001166 MOV OUTBUF,$REG2 ;AS MENTIONED ABOVE, IF 'WRITE' OF
4381 013434 104064      ERROR 64      ;256 WORD DATA BLOCK WAS DONE
4382                                     ;CORRECTLY BEFORE, THEN THIS ERROR
4383                                     ;COULD MEAN THAT AN NPR WAS DONE
4384                                     ;ON 'READ CHECK'.
4385
4386
4387
4388
4389

```

```

;*****
;*TEST 33      CHECK THE 'WRITE CHECK' FUNCTION - ON CYLINDER 0, SECTOR 0
; *THIS TEST CHECKS OUT THE BASIC 'WRITE CHECK' LOGIC, USING THE 256

```

4390
4391
4392
4393
4394
4395
4396 013436 000004
4397 013440 104413
4398
4399
4400
4401
4402
4403
4404
4405
4406
4407 013442 104421
4408
4409 013444 013701 001332
4410 013450 012700 177400
4411 013454 012702 033342
4412 013460 012703 177777
4413 013464 062703 177401
4414 013470 010322
4415 013472 005200
4416 013474 001373
4417 013476 012777 177400 165630
4418 013504 012777 033342 165624
4419 013512 013777 001350 165620
4420 013520 012711 000007
4421
4422 013524 005000
4423 013526 105711
4424 013530 100003
4425 013532 004737 021002
4426 013536 104030
4427
4428 013540 104412
4429
4430 013542 104065
4431
4432
4433 013544 032711 140000
4434 013550 001403
4435 013552 004737 021002
4436 013556 104066
4437
4438 013560 032777 000001 165542
4439 013566 001403
4440 013570 004737 021002
4441 013574 104067
4442
4443
4444
4445

```

;*WORD DATA BLOCK (SECTOR 0, CYLINDER 0) WRITTEN IN A PREVIOUS
;*TEST. THE BUFFER IN MEMORY, USED FOR COMPARISON OF DATA, IS THE
;*ONE STARTING AT 'OUTBUF'. HENCE THE TEST WHICH WRITES THE
;*256 WORD BLOCK ON THE DISK (AS WELL AS CREATING THE 256
;*256 WORD MEMORY BUFFER) SHOULD BE DONE BEFORE THIS TEST.
:*****
TST33: SCOPE
CNT.RESET

```

```

;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;CHECK IF SIN IS SET, IF SET
;DO DRIVE RESET TO CLEAR IT

TST.SIN
MOV RKCS,R1
MOV #-400,R0
MOV #OUTBUF,R2
MOV #177777,R3
1$: ADD #177401,R3
MOV R3,(R2)+
INC R0
BNE 1$
MOV #-400,@RKWC ;WRITE CHECK 256 WORDS
MOV #OUTBUF,@RKBA ;STARTING AT THIS BUS ADRES
MOV DRIVAD,@RKDA ;WITH THIS DISK DATA BLOCK (CYL 0, SEC 0)
MOV #7,@R1 ;WRITE CHECK, GO

CLR R0 ;GIVE SOME TIME
2$: TSTB @R1 ;DID CNTRL RDY CLEAR AS GO WAS SET?
BPL 3$ ;YES BRANCH
JSR PC,GT3RG ;GET RKCS, ER, DS
ERROR 30 ;CNTRL RDY DID NOT CLEAR AS GO WAS
;SET TO DO WRITE CHECK
3$: CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
;IF SO, SKIP THE EROR MESSAGE.
ERROR 65 ;CNTRL RDY DID NOT SET AFTER
;COMPLETING WRITE CHECK ON
;CYLINDER 0, SECTOR 0
4$: BIT #140000,@R1 ;DID HE OR ERR BIT SET
BEQ 5$ ;NO, BRANCH
JSR PC,GT3RG ;GO GET RKCS ER DS FOR ERROR MESSAGE
ERROR 66 ;HE OR ERR BIT SET ON DOING WRITE
;CHK ON CYLINDER 0, SEC 0
5$: BIT #1,@RKER ;DID WCE SET IN RKER?
BEQ 6$ ;NO, BRANCH
JSR PC,GT3RG ;YES GET RKCS, ER, DS
ERROR 67 ;WCE ON WRITE CHECK OF CYL 0, SEC 0
;NOTE THAT IF A PREVIOUS TEST
;& THEN COMPARED WITH MEMORY BUFFER
;TO SEE IF IT WAS WRITTEN CORRECT WAS
;DONE RIGHT BEFORE, THIS ERROR SHOULD NOT

```



```

4446                                     ;HAPPEN UNLESS THERE IS A FAULT IN THE
4447                                     ;COMPARING LOGIC OF 'WRT CHK'
4448 013576 005777 165532 6$: TST @RKWC ;DID RKWC OVERFLOW?
4449 013602 001406 BEQ 7$ ;YES, BRANCH
4450 013604 017737 165524 001162 MOV @RKWC,$REG0 ;NO, GET RKWC
4451 013612 011137 001164 MOV @R1,$REG1 ;GET RKCS
4452 013616 104061 ERROR 61 ;RKWC DID NOT OVERFLOW AFTER
4453                                     ;WRITE CHECK ON CYL 0, SEC 0
4454 013620 013704 001350 7$: MOV DRIVAD, R4 ;RKDA SHOULD INCREMENT
4455 013624 005204 INC R4 ;TO THIS AFTER WRT CHK
4456 013626 020477 165506 CMP R4,@RKDA ;DID RKDA INCREMENT CORRECTLY?
4457 013632 001406 BEQ 8$ ;YES, BRANCH
4458 013634 010437 001162 MOV R4,$REG0 ;NO, GET EXPCTD RKDA
4459 013640 017737 165474 001164 MOV @RKDA,$REG1 ;GET RKDA RECVD
4460 013646 104070 ERROR 70 ;RKDA DID NOT INCREMENT CORRECTLY
4461                                     ;(BY 1 SECTOR) AFTER WAT CHK ON SEC 0, CYL 0
4462 013650 022777 034342 165460 8$: CMP #OUTBUF+1000,@RKBA ;DID RKBA INCREMENT CORRECTLY?
4463 013656 001407 BEQ 9$ ;YES, EXIT
4464 013660 012737 034342 001162 MOV #OUTBUF+1000,$REG0 ;GET EPCTD RKBA
4465 013666 017737 165444 001164 MOV @RKBA,$REG1 ;GET RKBA RECVD
4466 013674 104071 ERROR 71 ;RKBA DID NOT INCREMENT CORRECTLY
4467                                     ;(BY 1000 BYTES) AFTER A WRT CHK
4468                                     ;OF 256 WORDS ON CYL 0, SEC 0
4469 013676 022711 000206 9$: CMP #206,@R1 ;DOES RKCS STILL CONTAIN THE WRT CHK BITS?
4470 013702 001406 BEQ TST34 ;YES, BRANCH
4471 013704 012737 000206 001162 MOV #206,$REG0 ;NO, GET EXPCTD RKCS
4472 013712 011137 001164 MOV @R1,$REG1 ;GET RKCS RECVD
4473 013716 104024 ERROR 24 ;RKCS BITS CHANGED AFTER WRT CHK
4474                                     ;WAS DONE
4475 ;*****
4476 ;*TEST 34 CHECK THAT IBA INHIBITS INCREMENTING OF RKBA
4477 ;*THIS TEST CHECKS THAT THE BUS ADDRESS DOES NOT INCREMENT WHEN
4478 ;*THE IBA BIT IS SET. SEQUENCE OF OPERATIONS:
4479 ;*1) CLEAR OUT 256 WORD BUFFER IN MEMORY (OUTBUF)
4480 ;*2) READ FROM SECTOR 0, CYLINDER 0 THE 256 WORD BLOCK THAT WAS
4481 ;*WRITTEN IN A PREVIOUS TEST (NOTE: THAT TEST SHOULD HAVE BEEN
4482 ;*DONE BEFORE THIS). IBA BIT IS SET DURING READ BACK.
4483 ;*3) CHECK THAT RKBA DID NOT INCREMENT
4484 ;*4) CHECK THAT THE ENTIRE BLOCK WAS READ INTO THE SAME MEMORY
4485 ;*WORD (OUTBUF) & THE REST OF THE WORDS IN THAT BUFFER ARE 0
4486 ;*AS PREVIOUSLY CLEARED OUT.
4487 ;*****
4488 013720 000004 TST34: SCOPE
4489 013722 104413 CNT.RESET ;GO, DO CONTROL RESET
4490                                     ;THIS IS A CALL FOR THE 'CNTRL-
4491                                     ;RESET' ROUTINE. A CONTROL RESET IS
4492                                     ;ISSUED AND AFTER A CERTAIN TIME
4493                                     ;IF THE 'CNTRL RDY' DOES NOT SET
4494                                     ;AN ERROR IS REPORTED. NOTE THAT
4495                                     ;THE PC IN ERROR MESSAGE IS THE
4496                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
4497                                     ;THIS IS A VERY BASIC ERR& IF IT
4498                                     ;OCCURS GO BACK TO TEST 10
4499 013724 104421 TST.SIN ;CHECK IF SIN IS SET, IF SET
4500                                     ;DO DRIVE RESET TO CLEAR IT
4501 013726 013701 001332 MOV RKCS,R1
    
```

MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2		MACY11 30A(1052) 21-FEB-78 08:58 PAGE 84		F 7		
CZRKKF.P11 21-FEB-78 08:51		T34		CHECK THAT IBA INHIBITS INCREMENTING OF RKBA		SEQ 0083
4502	013732	012700	177400	MOV	#-400,R0	:SET UP COUNT FOR 256 WORDS
4503	013736	012702	033342	MOV	#OUTBUF,R2	
4504	013742	010203		MOV	R2,R3	
4505						
4506	013744	005023		1\$: CLR	(R3)+	:CLEAR OUT THE 256
4507	013746	005200		INC	R0	:WORD MEMORY BUFFER STARTING
4508	013750	001375		BNE	1\$:AT 'OUTBUF'
4509	013752	012777	177400	MOV	#-400,@RKWC	:READ BACK 256 WORDS
4510	013760	010277	165352	MOV	R2,@RKBA	:INTO THIS BUS ADRES (IBA WILL B SET)
4511	013764	013777	001350	MOV	DRIVAD,@RKDA	:FROM THIS DSK ADRES (SEC 0, CYL 0)
4512						:NOTE: SEC 0 HAS BEEN WRITTEN IN A
4513						:PREVIOUS TEST WITH A UNIQUE PATTERN
4514	013772	012711	004005	MOV	#4005,@R1	:READ, GO, IBA SET
4515						
4516	013776	005037	001362	CLR	COUNT	
4517	014002	105711		2\$: TSTB	@R1	:DID CNTRL RDY SET?
4518	014004	100412		BMI	3\$:YES, BRANCH
4519	014006	005237	001362	INC	COUNT	:WAITED LONG ENOUGH?
4520	014012	001373		BNE	2\$:IF NOT, LUP BAK & WAIT
4521	014014	004737	020774	JSR	PC,GT4RG	:GO, GET RKCS, ER, DS, DA
4522	014020	013737	001350	MOV	DRIVAD,\$REG10	:GET THE STARTING ADRES
4523	014026	104416		BRKDA4		:BREAK CONTENTS OF \$REG10
4524						:INTO DR #, CYL, SUR, SEC
4525	014030	104045		ERROR	45	:CNTRL RDY DID NOT SET AFTER DOING
4526						:READ
4527	014032	004737	021234	3\$: JSR	PC,CHKHE	:CHECK IF 'ERR' OR 'HE' BIT IS SET,
4528						:IF YES, RETURN HERE.
4529	014036	104046		ERROR	46	:ERR BIT SET ON DOING READ FROM SEC 0,
4530						:CYL 0 (INDICATED IN <DSK-ADRES>)
4531						: 'RKDA' IN EROR MSGE GIVES THE
4532						: CONTENTS OF RKDA AT THE TIME OF EROR
4533						
4534	014040	020277	165272	4\$: CMP	R2,@RKBA	:DID RKBA INCREMENT?
4535	014044	001406		BEQ	5\$:OK IF NOT, BRANCH
4536	014046	010237	001162	MOV	R2,\$REG0	:GET EXPCTD RKBA
4537	014052	017737	165260	MOV	@RKBA,\$REG1	:GET RKBA RECVD
4538	014060	104072		ERROR	72	:RKBA INCREMNTED WHEN IBA BIT WAS
4539						:SET, SHOULD NOT HAVE
4540	014062	032777	001000	5\$: BIT	#1000,@RKDS	:IS SIN SET?
4541	014070	001042		BNE	TST35	::IF YES, EXIT
4542	014072	012700	177400	MOV	#-400,R0	
4543	014076	022712	000377	CMP	#377,@R2	:CHECK THAT THE FIRST WORD IN
4544						: 'OUTBUF' IS 377 (LAST WORD OF SEC 0,
4545						:CYL 0). NOTE THAT READ WAS DONE
4546	014102	001411		BEQ	6\$:INTO THIS SAME WRD WITH IBA SET
4547	014104	012737	000377	MOV	#377,\$REG0	:GET EXPCTD WORD (LAST WORD OF THE BUFFER
4548	014112	011237	001164	MOV	(R2),\$REG1	:GET WORD RECVD (LAST WRD FROM SEC 0)
4549	014116	013737	001350	MOV	DRIVAD,\$REG2	:DISK ADRES WHERE ERROR OCCURED
4550						: (SEC 0, CYL 0 LAST WORD)
4551						:DATA ERROR
4552	014124	104044		ERROR	44	:THE FIRST WORD IN MEM BUFFER (OUTBUF)
4553						:SHOULD BE NON-ZERO & SHOULD CONTAIN
4554						:THE LAST WORD READ BACK FROM SEC 0
4555						:CYL 0,THIS DID NOT HAPPEN IF THE ERROR OCCURS
4556	014126	005722		6\$: TST	(R2)+	:INCREMENT POINTER TO THE NXT WORD
4557	014130	012705	177773	MOV	#-5,R5	:ALLOW ONLY 5 MESAGES FOR ERR 116


```

4558 014134 005200
4559 014136 001417
4560 014140 005722
4561 014142 001774
4562 014144 005037 001164
4563 014150 014237 001166
4564 014154 010004
4565 014156 062704 000401
4566 014162 010437 001162
4567
4568 014166 104073
4569
4570
4571
4572
4573
4574
4575
4576
4577
4578
4579
4580
4581
4582
4583 014170 005205
4584 014172 001401
4585 014174 000757
4586
4587
4588
4589
4590
4591
4592
4593
4594
4595 014176 000004
4596 014200 104413
4597
4598
4599
4600
4601
4602
4603
4604
4605
4606 014202 104421
4607
4608 014204 012746 000340
4609 014210 012746 014216
4610 014214 000002
4611 014216
4612 014216 013701 001332
4613 014222 013700 001402

7$: INC R0 ;CHKD ALL 256 WORDS IN THE BUFFER?
    BEQ TST35 ;:YES, EXIT
    TST (R2)+ ;IS THIS WORD 0?
    BEQ 7$ ;YES, LUP BAK & CHK THE NXT WORD?
    CLR $REG1 ;ERROR. GET EXPCTED WORD - 0
    MOV -(R2), $REG2 ;GET WORD THAT WAS FOUND IN THE BUFFER
    MOV R0, R4
    ADD #401, R4
    MOV R4, $REG0 ;THIS 'WORD #' IN MEMORY BUFFER
                    ;SHOULD HAVE BEEN ZERO
                    ;THE 256 WORD BUFER (STARTING AT
                    ;OUTBUF) WAS CLEARED BEFORE READING
                    ;BAK SEC 0 INTO IT. SINCE THE IBA
                    ;BIT WAS SET DURING THE READ, ONLY
                    ;THE FIRST WORD OF (OUTBUF) SHOULD
                    ;HAVE CHANGED, THE REST OF THE WORDS
                    ;SHOULD BE STILL 0. IF THIS ERROR
                    ;OCCURS, 'WORD #' (OF THE BUFFER) AS
                    ;INDICATED IN THE EROR MESAGE) GOT
                    ;CHANGED WHEN READ WAS DONE FROM
                    ;THE DISK, INDICATING THAT WITH IBA
                    ;SET X-FER WAS NOT DONE INTO THE
                    ;SAME MEMORY LOCATION. 'WORD #'
                    ;IS OCTAL & SPECIFIES THE POSITION
                    ;IN THE BUFFER (FIRST WORD IS 'WORD #' 1)
                    ;:EXIT
    INC R5
    BEQ TST35
    BR 7$

:*****
:*TEST 35 CHECK THAT RK11 INTERRUPTS WHEN IDE IS SET
:*THIS TEST CHECKS IF RK11 INTERRUPTS TO ITS DESIGNATED VECTOR
:*ADDRESS WHEN IDE BIT IS SET, WITH CONTROL READY SET & GO CLEAR.
:* IT IS NORMALLY 220, UNLESS IT HAS BEEN CHANGED. IF IT HAS BEEN
:*CHANGED RK11 WILL INTERRUPT TO 'RKVEC'. NOTE 'RKVEC' HAS
:*TO BE SET UP BY THE USER.
:*****
TST35: SCOPE
        CNT.RESET ;GO, DO CONTROL RESET
                    ;THIS IS A CALL FOR THE 'CNTRL-
                    ;RESET' ROUTINE. A CONTROL RESET IS
                    ;ISSUED AND AFTER A CERTAIN TIME
                    ;IF THE 'CNTRL RDY' DOES NOT SET
                    ;AN ERROR IS REPORTED. NOTE THAT
                    ;THE PC IN ERROR MESSAGE IS THE
                    ;PC WHERE 'CNT.RESET' IS LOCATED.
                    ;THIS IS A VERY BASIC ERR& IF IT
                    ;OCCURS GO BACK TO TEST 10
                    ;CHECK IF SIN IS SET, IF SET
                    ;DO DRIVE RESET TO CLEAR IT

        TST.SIN

64$: MOV #340, -(SP)
    MOV #64$, -(SP)
    RTI

    MOV RKCS, R1
    MOV RKVEC, R0 ;GET POINTER TO RK VECTOR ADRES
```



```

4782 014662 013700 001332      MOV      RKCS,R0
4783 014666 013702 001340      MOV      RKDA,R2
4784 014672 013704 001336      MOV      RKBA,R4
4785 014676 013701 001350      MOV      DRIVAD,R1
4786 014702 052701 000013      BIS      #13,R1          ;SET BITS FOR SEC 13
4787 014706 012777 177600 164420  MOV      #-200,@RKWC      ;READ 200 (OCTAL WORDS)
4788 014714 010112              MOV      R1,@R2          ;FROM THIS DISK ADRES (CYL 0, SEC 13)
4789 014716 012714 033342      MOV      #OUTBUF,@R4     ;INTO THIS BUS ADRES
4790 014722 013705 001402      MOV      RKVEC,R5
4791 014726 012725 014764      MOV      #1$, (R5)+      ;SET UP VECTOR ADRES FOR RK11 TO INTRUPT
4792 014732 012715 000340      MOV      #340, (R5)      ;SET PSW ON INTERUPT
4793 014736 012710 000105      MOV      #105,@R0        ;READ, GO, IDE SET
4794 014742 104420 127710      WAT.INT ,127710         ;WAIT FOR RK11 TO INTERRUPT ON
4795                                ;COMPLETION OF READ
4796                                ;WAITING TIME= 337 MS FOR 11/20
4797                                ;67 MS FOR 11/45
4798 014746 012777 004600 164426  MOV      #BADINT,@RKVEC  ;RESTORE UNEXPTED INTERRUPT VECTOR ADRES
4799 014754 011037 001162      MOV      @R0,$REG0       ;GET RKCS
4800 014760 104101              ERROR    101             ;RK11 DID NOT INTERRUPT AFTER READ
4801                                ;WAS DONE, IDE BIT SET.
4802 014762 000404              BR       1$+10
4803 014764 022626 1$:      CMP      (SP)+,(SP)+     ;OK, IF RK11 INTERRUPTED TO THIS
4804                                ;RESTORE STACK POINTER (FROM RK11 INTERRUPT)
4805 014766 022626              CMP      (SP)+,(SP)+     ;RESTORE STACK POINTER (FROM WAT.INT)
4806 014770 012777 004600 164404  MOV      #BADINT,@RKVEC  ;RESTORE UNEXPECTED RK11 INTERRUPT
4807                                ;VECTOR ADRES
4808 014776 004737 021342      JSR      PC,CHKER        ;CHECK IF ANY BIT IN RKER IS SET,
4809                                ;IF YES, RETURN HERE.
4810 015002 104036              ERROR    36             ;RKER SET ON DOING READ FROM SEC 0,
4811                                ; CYL 13 IN INTERRUPT MODE
4812 015004 062701 000005 4$:      ADD      #5,R1           ;RKDA SHOULD HAVE INCREMENTED TO THIS
4813 015010 020112              CMP      R1,@R2          ;DID RKDA INCREMENT CORRECTLY?
4814 015012 001405              BEQ      2$              ;YES BRANCH
4815 015014 010137 001162      MOV      R1,$REG0        ;GET EXPCTD RTDA
4816 015020 011237 001164      MOV      @R2,$REG1       ;GET RKDA RECVD
4817 015024 104040              ERROR    40             ;RKDA INCREMENTED WRONG ON DOING
4818                                ;A READ ON CYL 0, SEC 13
4819 015026 004737 021316 2$:      JSR      PC,CHKWC        ;CHECK THAT RKWC OVERFLOWED TO 0,
4820                                ;IF NOT RETURN HERE.
4821 015032 104041              ERROR    41             ;RKWC DIDN'T OUFLO AFTER
4822                                ;A READ OF 200 WORDS
4823
4824 015034 3$:
4825 015034 012746 000340      MOV      #340,-(SP)
4826 015040 012746 015046      MOV      #64$,-(SP)
4827 015044 000002              RTI
4828 015046 64$:
4829 015046 022714 033742      CMP      #OUTBUF+400,@R4 ;DID RKBA INCREMENT CORRECTLY?
4830 015052 001406              BEQ      TST40           ;:YES, EXIT
4831 015054 012737 033742 001162  MOV      #OUTBUF+400,$REG0 ;GET EXPCT RKBA
4832 015062 011437 001164      MOV      @R4,$REG1       ;GET RKBA RECVD
4833 015066 104042              ERROR    42             ;RKBA DID NOT INCREMENT CORRECTLY
4834                                ;AFTER A READ OF 200 WORDS
4835
4836 ;:*****
4837 ;*TEST 40      CHECK THAT RK11 INTERRUPTS AT BR5 ONLY

```

4838
4839
4840
4841
4842
4843
4844
4845
4846 015070 000004
4847 015072 104413
4848
4849
4850
4851
4852
4853
4854
4855
4856
4857 015074 104421
4858
4859 015076 012737 015132 001110
4860
4861 015104 013700 001332
4862 015110 013777 001350 164222
4863 015116 012701 000007
4864 015122 012702 000340
4865 015126 013703 001400
4866
4867
4868
4869 015132 013704 001402
4870 015136 012724 015244
4871 015142 012714 000340
4872 015146 010246
4873 015150 012746 015156
4874 015154 000002
4875 015156
4876 015156 012710 000100
4877 015162 012705 177760
4878 015166 005205
4879 015170 001376
4880 015172 020203
4881 015174 003005
4882
4883
4884 015176 010137 001162
4885 015202 011037 001164
4886 015206 104103
4887
4888
4889 015210 005010
4890 015212 062702 177740
4891
4892 015216 005301
4893 015220 001344

;*THIS TEST CHECKS THAT RK11 CAN INTERRUPT AT BR5 ONLY. IF IT
;*INTERRUPTS AT A LEVEL HIGHER THAN BR5 AN ERROR IS INDICATED.
;*IF IT DOES NOT INTERRUPT AT BR5 OR LOWER THEN ALSO AN
;*ERROR IS INDICATED. IF FOR SOME REASON THE INTERRUPT
;*LEVEL IS CHANGED FROM BR5, THEN CONTENTS OF RKPRI WILL
;*HAVE TO BE CHANGED ACCORDINGLY AND STILL TEXT WILL
;*CHECK FOR THIS BR LEVEL.
:*****
TST40: SCOPE
CNT.RESET
TST.SIN
MOV #1\$, \$LPERR
MOV RKCS, R0
MOV DRIVAD, @RKDA
MOV #7, R1
MOV #340, R2
MOV RKPRI, R3
1\$: MOV RKVEC, R4
MOV #3\$, (R4)+
MOV #340, (R4)
MOV R2, -(SP)
MOV #4\$, -(SP)
RTI
4\$: MOV #100, @R0
MOV #-20, R5
INC R5
BNE .-2
CMP R2, R3
BGT 2\$
MOV R1, \$REG0
MOV @R0, \$REG1
ERROR 103
2\$: CLR @R0
ADD #-40, R2
DEC R1
BNE 1\$

;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;CHECK IF SIN IS SET, IF SET
;DO DRIVE RESET TO CLEAR IT
;SET RETURN ADRES FOR LUPING
;ON ERROR (SW 9)
;PRIORITY LEVEL 7
;BR LEVEL 7 FOR PSW
;NOTE, IF RK11 INTERRUPT LEVEL IS
;CHANGED FROM 5 TO ANY OTHER LEVEL
;THEN CHANGE CONTENTS OF 'RKPRI'
; ACCORDINGLY
;SET UP ADRES FOR RK11 TO INTERUPT
;SET UP PSW ON INTERUPT
;SET PROCESSOR PRIORITY LEVEL AS
;INDICATED BY R2
;SET THE IDE BIT
;WAIT FOR THE RK11 INTERRUPT
;WAITING TIME=78 US FOR 11/20
;13 US FOR 11/45
;WAS THE CPU PRIORITY LEVEL LESS THAN
;THE RK11 LEVEL? IF YES, RK11
;SHOULD HAVE INTERRUPTED. ERROR,
;IF IT DID NOT
;GET CPU BR LEVEL
;GET RKCS
;THOUGH CPU LEVEL WAS LESS THAN
;THE RK11 LEVEL (5), RK11 DID NOT
;INTERRUPT
;CLEAR RKCS
;DECREASE THE PRIORITY LEVEL (FOR
;CPU) BY 1
;CPU WILL B AT THIS LEVEL
;LUP BAK & CHK FOR THIS BR LEVEL.


```
4894  
4895 015222 012777 004600 164152      MOV    #BADINT,@RKVEC    ;DONE WITH CHKING FOR ALL LEVELS.  
4896                                     ;RESTORE UNEXPECTED RK11 INTERRUPT  
4897 015230 012746 000340             MOV    #340,-(SP)        ;VECTOR  
4898 015234 012746 015242             MOV    #64$,-(SP)  
4899 015240 000002                     RTI  
4900 015242                               64$:  
4901 015242 000414                     BR     TST41              ;;EXIT,TO NXT TST  
4902  
4903 015244 022626                               3$:  
4904 015246 012777 004600 164126      CMP    (SP)+,(SP)+      ;RESTORE STACK POINTER  
4905                                     MOV    #BADINT,@RKVEC    ;RESTORE UNEXPECTED RK11 INTERRUPT  
4906 015254 020203                               ;VECTOR  
4907 015256 003754                               ;IF THIS INTERRUPT OCCURED WHEN  
4908                                     CMP    R2,R3             ;CPU LEVEL WAS LESS THAN THE  
4909                                     BLE    2$                ;RK11 PRIORITY LEVEL (5) THEN IT IS  
4910 015260 010137 001162             MOV    R1,$REG0         ;OK. IF NOT SO, ERROR  
4911 015264 011037 001164             MOV    @R0,$REG1        ;GET CPU BR LEVEL  
4912 015270 104104                     ERROR 104              ;GET RKCS  
4913                                     ;RK11 INTERRUPTED WHEN THE CPU  
4914                                     ;LEVEL (AS POINTED BY R1) WAS  
4915                                     ;HIGHER OR SAME AS THE RK11  
4916 015272 000746                     BR     2$                ;LEVEL (5)  
4917                                     ;GO BACK & CHK THE NXT LEVEL  
4918  
4919 ;:*****  
4920 ;*TEST 41      SIMULATE & CHECK 'OVR' ERROR  
4921 ;*THIS TEST SIMULATES OVERRUN ERROR AND CHECKS IF THE OVR  
4922 ;*BIT IN RKER GETS SET. THEN IT IS CLEARED USING CNTRL RESET  
4923 ;*& CHECKED THAT IT WAS CLEARED. OVR CONDITION IS SIMULATED  
4924 ;*BY TRYING TO READ 401(OCTAL) WORDS FROM LAST CYLINDER(312),  
4925 ;*LAST SECTOR (13), SURFACE 1.  
4926 015274 000004                               ;:*****  
4927 015276 104413      TST41:  SCOPE  
4928                                     CNT.RESET              ;GO, DO CONTROL RESET  
4929                                     ;THIS IS A CALL FOR THE 'CNTRL-  
4930                                     ;RESET' ROUTINE. A CONTROL RESET IS  
4931                                     ;ISSUED AND AFTER A CERTAIN TIME  
4932                                     ;IF THE 'CNTRL RDY' DOES NOT SET  
4933                                     ;AN ERROR IS REPORTED. NOTE THAT  
4934                                     ;THE PC IN ERROR MESSAGE IS THE  
4935                                     ;PC WHERE 'CNT.RESET' IS LOCATED.  
4936                                     ;THIS IS A VERY BASIC ERR& IF IT  
4937 015300 104421      TST.SIN          ;OCCURS GO BACK TO TEST 10  
4938                                     ;CHECK IF SIN IS SET, IF  
4939 015302 013701 001350             MOV    DRIVAD,R1        ;SET, DO DRIVE RESET TO CLR IT  
4940 015306 052701 014533             BIS    #14533,R1       ;GET ADRES OF DRIVE  
4941                                     ;SET BITS FOR LAST CYLINDER (312),  
4942 015312 012777 177377 164014      MOV    #-401,@RKWC     ;SUR 1, LAST SECTOR (13)  
4943 015320 012777 033342 164010      MOV    #OUTBUF,@RKBA   ;READ 401 WORDS  
4944 015326 010177 164006             MOV    R1,@RKDA        ;INTO THIS MEMORY BUFFER  
4945                                     ;FROM THIS DSK ADRES, LAST CYL.  
4946 015332 012777 000005 163772      MOV    #5,@RKCS        ;LAST SEC, SURFACE 1  
4947                                     ;READ, GO  
4948 015340 005002                               CLR    R2  
4949 015342 105777 163764                               1$:  TSTB  @RKCS          ;DID CNTRL RDY SET?
```

4950	015346	100410				BMI	2\$:YES, BRANCH
4951	015350	005202				INC	R2		:NO, WAIT FOR IT
4952	015352	001373				BNE	1\$:IF WAITED LONG, REPORT ERROR MESSAGE BECAUSE
4953									:OVR SHOULD HAVE SET HE CAUSING
4954									:CNTRL RDY TO SET BY NOW
4955	015354	017737	163754	001166		MOV	@RKWC,\$REG2		
4956	015362	004737	021010			JSR	PC,GT2RG		:GO, GET RKCS, ER
4957	015366	104002				ERROR	2		:CNTRL RDY DID NOT SET AFTER DOING
4958									:AN OVR READ. HE SHOULD HAVE OCCURED
4959									:SETTING CNTRL RDY (HE BECAUSE OF
4960									:OVR CONDITIONS)
4961	015370	032777	040000	163732	2\$:	BIT	#40000,@RKER		:DID OVR BIT SET IN RKER?
4962	015376	001006				BNE	3\$		
4963	015400	004737	021010			JSR	PC,GT2RG		:GET RKCS, ER
4964	015404	012737	040000	001166		MOV	#40000,\$REG2		:THIS BIT (OVR) DID NOT SET.
4965	015412	104105				ERROR	105		:OVR ERROR BIT DID NOT SET IN RKER
4966									:ON SIMULATING OVR CONDITIONS
4967	015414,	022777	140204	163710	3\$:	CMP	#140204,@RKCS		:DID HE & ERR SET WHEN OVR SET IN RKER?
4968	015422	001403				BEQ	4\$:YES, BRANCH
4969	015424	004737	021010			JSR	PC,GT2RG		:GET RKCS, ER
4970	015430	104106				ERROR	106		:HE OR ERR BIT DID NOT SET IN RKCS WHEN
4971									:AN OVR ERROR WAS SIMULATED
4972									:CLEAR OVER, ERR, HE BITS
4973	015432	104413			4\$:	CNT.RESET			:GO, DO CONTROL RESET
4974									:THIS IS A CALL FOR THE 'CNTRL-
4975									:RESET' ROUTINE. A CONTROL RESET IS
4976									:ISSUED AND AFTER A CERTAIN TIME
4977									:IF THE 'CNTRL RDY' DOES NOT SET
4978									:AN ERROR IS REPORTED. NOTE THAT
4979									:THE PC IN ERROR MESSAGE IS THE
4980									:PC WHERE 'CNT.RESET' IS LOCATED.
4981									:THIS IS A VERY BASIC ERR& IF IT
4982									:OCCURS GO BACK TO TEST 10
4983	015434	004737	021356			JSR	PC,CHKECLR		:CHECK IF 'OVR' BIT WAS CLEARED BY
4984									:CON.RESET, IF NOT RETURN HERE.
4985	015440	104102				ERROR	102		:CNTRL RESET DID NOT CLEAR OVR
4986									:BIT IN RKER
4987	015442	004737	021402		5\$:	JSR	PC,CHKCCLR		:CHECK IF 'ERR' & 'HE' BIT GOT CLEARED BY
4988									:CON.RESET, IF NOT RETURN HERE.
4989	015446	104102				ERROR	102		:CNTRL RESET DID NOT CLEAR
4990									:HE OR ERR BIT IN RKCS.
4991	015450	004737	021504		6\$:	JSR	PC,DRESET		:GO DO DRIVE RESET
4992	015454	104026				ERROR	26		:R/W/S RDY DIDN'T SET
4993									:AFTER THE ABOVE DRIVE RESET,
4994									
4995									
4996									
4997									
4998									
4999									
5000									
5001									
5002									
5003	015456	000004							
5004	015460	104413							
5005									

```
::*****  
;*TEST 42 SIMULATE & CHECK PGE ERROR  
;*THIS TEST SIMULATES 'PROGRAMMING ERROR' & CHECKS IF IT IS  
;*DETECTED BY PGE BIT IN RKER. THEN A CNTRL RESET IS DONE &  
;*IT IS CHECKED IF PGE BIT WAS CLEARED. IT IS ALSO CHECKED IF  
;*THE SETTING & CLEARING OF PGE BIT SETS & CLEARS HE, ERR  
;*BITS IN RKCS.  
:*****
```

```
TST42: SCOPE  
CNT.RESET ;GO, DO CONTROL RESET  
;THIS IS A CALL FOR THE 'CNTRL-
```



```
5006 ;RESET' ROUTINE. A CONTROL RESET IS
5007 ;ISSUED AND AFTER A CERTAIN TIME
5008 ;IF THE 'CNTRL RDY' DOES NOT SET
5009 ;AN ERROR IS REPORTED. NOTE THAT
5010 ;THE PC IN ERROR MESSAGE IS THE
5011 ;PC WHERE 'CNT.RESET' IS LOCATED.
5012 ;THIS IS A VERY BASIC ERR& IF IT
5013 ;OCCURS GO BACK TO TEST 10
5014 015462 104421 TST.SIN ;GO CHECK IF SIN IS SET, IF
5015 ;SET DO DRIVE RESET TO CLR IT
5016 015464 013701 001330 MOV RKER,R1
5017 015470 013777 001350 163642 MOV DRIVAD,@RKDA ;ADRES THE DRIVE, CYLINDER 0
5018
5019 015476 012777 002011 163626 MOV #2011,@RKCS ;SEEK, GO WITH FMT SET
5020 CNT.RDY ;THIS IS A PGE SIMULATION
5021 015504 104414 ;THIS IS A CALL FOR 'CN.RDY'
5022 ;ROUTINE WHICH WAITS FOR CNT
5023 ;RDY TO SET. IF CNTRL RDY DOES
5024 ;NOT SET WITHIN 883 MS/ 11-20
5025 ;(176 MS FOR 11-45 WITH BIPOLAR)
5026 ;AN ERROR IS REPORTED
5027 015506 032711 004000 BIT #4000,@R1 ;DID PGE BIT IN RKER SET?
5028 015512 001006 BNE 1$ ;YES, BRANCH
5029 015514 012737 004000 001166 MOV #4000,$REG2 ;THIS BIT IN RKER (PGE) DID NOT SET
5030 015522 004737 021010 JSR PC,GT2RG ;GO GET RKCS, ER FOR MESSAGE
5031 015526 104105 ERROR 105 ;PGE BIT DID NOT SET IN RKER
5032 ;ON SIMULATION OF PGE CONDITION
5033 ;$REG2 CONTAINS THE RKER BIT (PGE)
5034 ;THAT SHOULD HAVE SET.
5035 015530 022777 142210 163574 1$: CMP #142210,@RKCS ;DID HE & ERR BITS SET?
5036 015536 001403 BEQ 2$ ;YES, BRANCH
5037 015540 004737 021010 JSR PC,GT2RG ;GO, GET RKCS, ER
5038 015544 104106 ERROR 106 ;HE OR ERR BIT DID NOT SET WHEN
5039 ;PGE SET IN RKER.
5040 ;CLEAR PGE, HE, ERR BITS
5041 015546 104413 2$: CNT.RESET ;GO, DO CONTROL RESET
5042 ;THIS IS A CALL FOR THE 'CNTRL-
5043 ;RESET' ROUTINE. A CONTROL RESET IS
5044 ;ISSUED AND AFTER A CERTAIN TIME
5045 ;IF THE 'CNTRL RDY' DOES NOT SET
5046 ;AN ERROR IS REPORTED. NOTE THAT
5047 ;THE PC IN ERROR MESSAGE IS THE
5048 ;PC WHERE 'CNT.RESET' IS LOCATED.
5049 ;THIS IS A VERY BASIC ERR& IF IT
5050 ;OCCURS GO BACK TO TEST 10
5051 015550 004737 021356 JSR PC,CHKECLR ;CHECK IF 'PGE' BIT GOT CLEARED BY
5052 ;CONTROL RESET, IF NOT RETURN HERE.
5053 015554 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5054 ;PGE BIT IN RKER
5055 015556 004737 021402 3$: JSR PC,CHKCCLR ;CHECK IF 'ERR' BITGOT CLEARED BY
5056 ;CON.RESET, IF NOT RETURN HERE.
5057 015562 104102 ERROR 102 ;RKCS BITS HE OR ERR DID NOT
5058 ;GET CLEARED BY CNTRL RESET
5059
5060 ;*****
5061 ;*TEST 43 SIMULATE & CHECK NXM ERROR
```

5062
5063
5064
5065
5066
5067
5068
5069 015564 000004
5070 015566 104413
5071
5072
5073
5074
5075
5076
5077
5078
5079
5080 015570 104421
5081
5082 015572 005002
5083 015574 013700 001332
5084 015600 012777 177777 163526
5085 015606 012777 160000 163522
5086 015614 013777 001350 163516
5087 015622 012710 000067
5088 015626 105777 163500 1\$:
5089 015632 100410
5090 015634 005202
5091 015636 001373
5092 015640 004737 021010
5093 015644 017737 163464 001166
5094 015652 104113
5095
5096
5097
5098 015654 032777 002000 163446 2\$:
5099 015662 001006
5100 015664 004737 021010
5101 015670 012737 002000 001166
5102 015676 104105
5103
5104 015700 022710 140266 3\$:
5105 015704 001403
5106 015706 004737 021010
5107 015712 104106
5108
5109
5110 015714 104413 4\$:
5111
5112
5113
5114
5115
5116
5117

;*THIS TEST SIMULATES A NON-EXISTENT MEMORY ERROR (NXM) AND
;*CHECKS IF IT IS DETECTED BY NXM BIT OR RKER.LOCATION 760000
;*IS REFERENCED & IT HAPPENS TO BE A NON EXISTENT LOCATION
;*(FOR DIAGNOSTIC PURPOSES LIKE THIS). IT IS ALSO CHECKED
;*IF HE & ERR BITS ALSO SET AND ALL 3 BITS CAN BE CLEARED
;* BY CONTROL RESET.
:*****
TST43: SCOPE
CNT.RESET
;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;GO CHECK IF SIN IS SET
;IF SET DO DRIVE RESET TO CLR IT
TST.SIN
CLR R2
MOV RKCS,RO
MOV #-1,@RKWC ;WRITE CHECK 1 WORD
MOV #160000,@RKBA ;AT THIS BUS ADRES
MOV DRIVAD,@RKDA ;WITH THIS DISK ADRES (CYL 0, SEC 0)
MOV #67,@RO ;WRT CHK, GO, MEX BITS SET
1\$: TSTB @RKCS ;DID CNTRL RDY SET AS A RESULT OF HE?
BMI 2\$;YES, BRANCH
INC R2 ;WAITED LONG ENOUGH?
BNE 1\$;IF NOT LUP BAK & WAIT
JSR PC,GT2RG ;GET RKCS, ER
MOV @RKWC,\$REG2 ;GET RKWC
ERROR 113 ;CNTRL RDY DID NOT SET ON DOING
;A WRT CHK WITH A NXM LOCATION.
;THIS HE SHOULD HAVE SET THE
;CNTRL RDY BIT IN RKCS
2\$: BIT #2000,@RKER ;DID NXM BIT IN RKER SET?
BNE 3\$;YES, BRANCH
JSR PC,GT2RG ;GO GET RKCS, RKER
MOV #2000,\$REG2 ;THIS BIT (NXM) DID NOT SET IN RKER
ERROR 105 ;NXM BIT DID NOT SET IN RKER ON
;SIMULATING NXM CONDITION.
3\$: CMP #140266,@RO ;DID HE & ERR BIT SET?
BEQ 4\$;YES, BRANCH
JSR PC,GT2RG ;GO, GET RKCS, RKER
ERROR 106 ;HE OR ERR BIT DID NOT SET WHEN
;NXM ERROR WAS SIMULATED
4\$: CNT.RESET ;CLEAR NXM, HE, ERR BITS
;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.

5174
5175
5176
5177
5178
5179
5180
5181
5182
5183
5184 016036 022710 140214
5185 016042 001403
5186 016044 004737 021010
5187 016050 104106
5188
5189 016052 104413
5190
5191
5192
5193
5194
5195
5196
5197
5198
5199 016054 004737 021356
5200
5201 016060 104102
5202
5203 016062 004737 021402
5204
5205 016066 104102
5206
5207 016070 004737 021436
5208
5209 016074 104016
5210
5211
5212
5213
5214
5215
5216
5217
5218
5219 016076 000004
5220 016100 013700 001332
5221 016104 012737 177773 001362
5222 016112 013702 001350
5223 016116 052702 014540
5224 016122 012737 016130 001110
5225
5226 016130 104413
5227
5228
5229

3\$: CMP #140214,ARO
BEQ 4\$
JSR PC,GT2RG
ERROR 106
4\$: CNT.RESET
JSR PC,CHKECLR
ERROR 102
5\$: JSR PC,CHKCCLR
ERROR 102
JSR PC,TSTRWS
ERROR 16

:NON-EXISTENT DRIVE
:CHECK THAT THE JUMPER CARD CONTAINING
:JUMPERS FOR DRIVES PRESENT IS PROPERLY
:CONNECTED
:NOTE THAT ON RK11C IF A DRIVE
:IS OFFLINE BUT PHYSICALLY PRESENT
:(IE. DRY IS CLR FOR THAT DRIVE)
:& A FUNCTION IS INITIATED ON THAT
:DRIVE NXD WON'T SET, BUT U WILL
:GET ONLY A DRE,HE & ERR.
:DID HE & ERR SET WHEN NXD SET?
:YES BRANCH
:HE OR ERR BIT DID NOT SET
:WHEN NXD WAS SIMULATED
:CLEAR NXD, HE, ERR BITS
:GO, DO CONTROL RESET
:THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE. A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME
:IF THE 'CNTRL RDY' DOES NOT SET
:AN ERROR IS REPORTED. NOTE THAT
:THE PC IN ERROR MESSAGE IS THE
:PC WHERE 'CNT.RESET' IS LOCATED.
:THIS IS A VERY BASIC ERR& IF IT
:OCCURS GO BACK TO TEST 10
:CHECK IF 'NXD' BIT WAS CLEARED BY
:CON.RESET. IF NOT, RETURN HERE.
:CNTRL RESET DID NOT CLEAR
:NXD BIT IN RKER
:CHECK IF 'HE' & 'ERR' BITS WERE CLEARED
:BY CON.RESET. IF NOT RETURN HERE.
:CNTRL RESET DID NOT CLEAR
:HE OR ERR BIT IN RKCS
:GO CHECK & WAIT FOR R/W/S RDY
:TO SET. IF SET SKIP ERROR
:R/W/S SHOULD BE SET, IT'S
:NOT

::*****
:*TEST 45 SIMULATE & CHECK NXC ERROR
:*THIS TEST SIMULATES THE NON-EXISTENT CYLINDER ERROR & CHECKS
:*IF IT IS DETECTED BY THE NXC BIT OF RKER, HE & ERR BITS
:*OF RKCS. IT IS CHECKED IF THEY CAN BE CLEARED BY CONTROL
:*RESET

::*****
TST45: SCOPE
MOV RKCS,RO
2\$: MOV #-5,COUNT ;ALLOW 'ERROR 133' ONLY 5 TIMES
MOV DRIVAD,R2 ;GET ADRES OF DRIVE
BIS #14540,R2 ;SET BITS FOR CYL 313
MOV #3\$,\$LPERR ;SET RETURN ADRES FOR
;LUPING ON EROR (SW9)
3\$: CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE. A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME


```

5286 016256 004737 021356          JSR    PC,CHKECLR          ;CHECK IF 'NXC' BIT WAS CLEARED BY
5287                                     ;CON.RESET. IF NOT, RETURN HERE.
5288 016262 104102          ERROR  102                ;CNTRL RESET DID NOT CLEAR
5289                                     ;NXC BIT IN RKER.
5290 016264 032710 140000      7$:   BIT    #140000,@R0      ;DID HE & ERR BITS GET CLEARED?
5291 016270 001405          BEQ    TST46              ;:YES, EXIT
5292 016272 010037 001162      MOV    R0,$REG0          ;GET ADRES OF RKCS
5293 016276 011037 001164      MOV    @R0,$REG1        ;GET RKCS CONTENTS
5294 016302 104102          ERROR  102                ;CNTRL RESET DID NOT CLEAR
5295                                     ;HE OR ERR BIT IN RKCS
5296
5297
5298
5299
5300
5301
5302
5303
5304 016304 000004          TST46: SCOPE
5305 016306 104413          CNT.RESET
5306
5307
5308
5309
5310
5311
5312
5313
5314
5315 016310 013700 001332      MOV    RKCS,R0
5316 016314 013777 001350 163016  MOV    DRIVAD,@RKDA      ;GET ADRES OF DRIVE
5317 016322 052777 000014 163010  BIS    #14,@RKDA        ;SET BITS FOR SECTOR 12 (DECIMAL)
5318 016330 012777 177777 162776  MOV    #-1,@RKWC        ;READ 1 WORD
5319 016336 012777 033342 162772  MOV    #OUTBUF,@RKBA    ;INTO THIS BUS ADRES
5320 016344 012710 000005      MOV    #5,@R0           ;READ, GO (FROM NX SECTOR)
5321 016350 104414          CNT.RDY                 ;THIS IS A CALL FOR 'CN.RDY'
5322                                     ;ROUTINE WHICH WAITS FOR CNT
5323                                     ;RDY TO SET. IF CNTRL RDY DOES
5324                                     ;NOT SET WITHIN 883 MS/ 11-20
5325                                     ;(176 MS FOR 11-45 WITH BIPOLAR)
5326                                     ;AN ERROR IS REPORTED
5327                                     ;NXS ERROR SHOULD OCCUR NOW
5328 016352 017702 162752      MOV    @RKER,R2
5329 016356 032702 000040      BIT    #40,R2           ;DID NXS BIT SET IN RKER?
5330 016362 001006          BNE    1$                ;YES, BRANCH
5331 016364 004737 021010      JSR    PC,GT2RG         ;GO GET RKCS, RKER
5332 016370 012737 000040 001166  MOV    #40,$REG2        ;THIS BIT (NXS) IN RKER DID NOT SET
5333 016376 104105          ERROR  105                ;NXS BIT DID NOT SET ON SIMULATING
5334                                     ;NXS ERROR
5335 016400 042702 000040      1$:   BIC    #40,R2         ;MASK NXS BIT
5336 016404 001407          BEQ    2$                ;CHECK IF ANY OTHER
5337                                     ;RKER BIT SET
5338 016406 012737 000040 001162  MOV    #40,$REG0        ;GET EXPCTD RKER
5339 016414 017737 162710 001164  MOV    @RKER,$REG1     ;GET RKER RECVD
5340 016422 104107          ERROR  107                ;ONLY 'NXS' SHOULD BE SET
5341                                     ;IN RKER, ANOTHER RKER BIT
    
```

```

:*****
:*TEST 46          SIMULATE & CHECK NXS ERROR
;*THIS TEST SIMULATES NON-EXISTENT SECTOR ERROR & CHECKS THAT
;*IT IS DETECTED BY NXS BIT OF RKER. IT IS CHECKED THAT
;*WHEN NXS SETS HE & ERR OF RKER ALSO SETS, AND ALL THREE
;*CAN BE CLEARED BY CONTROL RESET.
:*****
    
```

```

;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
    
```



```
5342                                     ;WAS SET. (NOTE 'NXS' WAS
5343                                     ;SIMULATED)
5344 016424 022710 140204                2$:   CMP      #140204,@R0      ;DID HE & ERR BITS SET?
5345 016430 001403                        BEQ      3$                ;YES, BRANCH
5346 016432 004737 021010                JSR      PC,GT2RG         ;GO GET RKCS, RKER
5347 016436 104106                        ERROR    106              ;HE OR ERR BIT DID NOT SET WHEN
5348                                     ;NXS ERROR OCCURED
5349                                     ;CLEAR NXS, HE, ERR BITS
5350 016440 104413                        3$:   CNT.RESET          ;GO, DO CONTROL RESET
5351                                     ;THIS IS A CALL FOR THE 'CNTRL-
5352                                     ;RESET' ROUTINE. A CONTROL RESET IS
5353                                     ;ISSUED AND AFTER A CERTAIN TIME
5354                                     ;IF THE 'CNTRL RDY' DOES NOT SET
5355                                     ;AN ERROR IS REPORTED. NOTE THAT
5356                                     ;THE PC IN ERROR MESSAGE IS THE
5357                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
5358                                     ;THIS IS A VERY BASIC ERR& IF IT
5359                                     ;OCCURS GO BACK TO TEST 10
5360 016442 004737 021356                JSR      PC,CHKECLR       ;CHECK IF 'NXS' BIT WAS CLEARED BY
5361                                     ;CON.RESET. IF NOT, RETURN HERE.
5362 016446 104102                        ERROR    102              ;CNTRL RESET DID NOT CLEAR
5363                                     ;NXS BIT IN RKER
5364 016450 004737 021402                4$:   JSR      PC,CHKCCLR   ;CHECL IF 'HE' & 'ERR' BITS WERE CLEARED
5365                                     ;BY CON.RESET. IF NOT, RETURN HERE.
5366 016454 104102                        ERROR    102              ;RKCS BITS ERR OR HE WERE NOT
5367                                     ;CLEARED BY CNTRL RESET
5368
5369                                     ;:*****
5370                                     ;*TEST 47      SIMULATE & CHECK WCE
5371                                     ;*THIS TEST SIMULATES A WRITE CHECK ERROR AND CHECKS THAT IT
5372                                     ;*IS DETECTED BY WCE BIT OF RKER. FOR COMPARISON IT USES
5373                                     ;*THE 256 WORDS DATA BLOCK WRITTEN ON SECTOR 0, CYLINDER 0
5374                                     ;*IN A PREVIOUS TEST. THIS BLOCK IS COMPARED WITH THE 256 WORDS
5375                                     ;*MEMORY BUFFER STARTING AT 'OUTBUF'. WCE IS SIMULATED BY
5376                                     ;*DROPPING A BIT FROM ONE OF THE WORDS IN THE MEMORY BUFFER.
5377                                     ;:*****
5378 016456 000004                        TST47: SCOPE
5379 016460 013700 001332                MOV      RKCS,R0
5380 016464 104413                        CNT.RESET
5381                                     ;GO, DO CONTROL RESET
5382                                     ;THIS IS A CALL FOR THE 'CNTRL-
5383                                     ;RESET' ROUTINE. A CONTROL RESET IS
5384                                     ;ISSUED AND AFTER A CERTAIN TIME
5385                                     ;IF THE 'CNTRL RDY' DOES NOT SET
5386                                     ;AN ERROR IS REPORTED. NOTE THAT
5387                                     ;THE PC IN ERROR MESSAGE IS THE
5388                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
5389                                     ;THIS IS A VERY BASIC ERR& IF IT
5390 016466 104421                        TST.SIN          ;OCCURS GO BACK TO TEST 10
5391                                     ;CHECK IF SIN IS SET, IF
5392 016470 012701 033342                MOV      #OUTBUF,R1      ;SET DO DRV-RESET TO CLR IT
5393 016474 012702 177400                MOV      #-400,R2        ;THIS CODE SETS UP A MEMORY
5394 016500 012703 177777                MOV      #177777,R3      ;BUFFER OF 256 WORDS STARTING
5395                                     ;AT OUTBUF
5396                                     ;FIRST WORD 177400
5397 016504 062703 177401                1$:   ADD      #177401,R3 ;SECOND 177001
```



```
5454 ;THE PC IN ERROR MESSAGE IS THE
5455 ;PC WHERE 'CNT.RESET' IS LOCATED.
5456 ;THIS IS A VERY BASIC ERR& IF IT
5457 ;OCCURS GO BACK TO TEST 10
5458 016640 104421 TST.SIN ;CHECK IF SIN IS SET, IF
5459 ;SET DO DRIVE RESET TO CLR IT
5460 016642 013700 001332 MOV RKCS,R0
5461 016646 012737 170007 033360 MOV #170007,OUTBUF+16 ;WCE IS SIMULATED BY DROPPING A BIT
5462 ;IN THE EIGHTH WORD (WHICH IS ACTUALLY
5463 ;174007). NOTE THAT 256 WORD MEMORY
5464 ;BUFFER IS CREATED IN THE PREVIOUS TEST.
5465 016654 013701 001350 MOV DRIVAD,R1
5466 016660 012777 177000 162446 MOV #-1000,@RKWC ;WRT CHK 1000 (OCTAL) WORDS, 2 SECTORS
5467 016666 012777 033342 162442 MOV #OUTBUF,@RKBA ;FROM THIS BUS ADRES
5468 016674 010177 162440 MOV R1,@RKDA ;WITH THIS DISK ADRES, SEC 0, CYL 0
5469 016700 012710 000407 MOV #407,@R0 ;WRT CHK, GO, SSE
5470 016704 104412 CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
5471 ;IF SO, SKIP THE EROR MESSAGE.
5472 016706 104065 ERROR 65 ;CNTRL RDY DID NOT SET AFTER WRT
5473 ;CHK. A SOFT ERROR (WCE) IN
5474 ;SECTOR 0 SHOULD HAVE STOPPED
5475 ;ALL CONTROL ACTION.
5476 016710 022777 000001 162412 2$: CMP #1,@RKER ;CHECK ONLY 'WCE' BIT SHOULD
5477 ;BE SET?
5478 016716 001407 BEQ 3$ ;YES, BRANCH
5479 016720 012737 000001 001162 MOV #1,$REG0 ;GET EXPCTD RKER
5480 016726 017737 162376 001164 MOV @RKER,$REG1 ;GET RKER RECVD
5481 016734 104107 ERROR 107 ;ONLY BIT 'WCE' OF RKER
5482 ;SHOULD BE SET (WCE WAS
5483 ;SIMULATED ABOVE). ERROR
5484 ;IF IT'S NOT
5485 016736 005201 3$: INC R1 ;CHECK THAT RKDA INCREMENTED BY
5486 016740 020177 162374 CMP R1,@RKDA ;1 SECTOR ONLY IMPLYING THAT
5487 ;CNTRL ACTION DID STOP AFTER
5488 ;SOFT ERROR IN SECTOR 0
5489 016744 001406 BEQ TST51 ;:YES, EXIT
5490 016746 010137 001162 MOV R1,$REG0 ;GET EXPCTD RKDA
5491 016752 017737 162362 001164 MOV @RKDA,$REG1 ;GET RKDA RECVD
5492 016760 104070 ERROR 70 ;RKDA SHOULD HAVE INCRMNTD
5493 ;BY 1 SECTOR ONLY, IT DIDN'T.
5494 ;WCE WAS SIMULATED IN THE
5495 ;FIRST SECTOR & A WRT CHK
5496 ;OF 2 SECTORS WAS ISSUED.
5497 ;CONTROLLER SHOULD STOP AFTER
5498 ;DETECTING WCE IN THE FIRST
5499 ;SECTOR. HENCE RKDA SHOULD
5500 ;INCREMENT BY 1 SECTOR ONLY
5501
5502
5503 ;*****
5504 ;*TEST 51 CHECK THAT RK11 INTERRUPTS ON SOFT ERROR WHEN SSE & IDE ARE SET
5505 ;*THIS TEST CHECKS WHEN SSE BIT IS SET WITH IDE SET AND A SOFT
5506 ;*ERROR OCCURS, THEN ALL CONTROL ACTION WILL STOP AND A BUS
5507 ;*REQUEST (INTERRUPT) WILL OCCUR AT THE END OF THE CURRENT
5508 ;*SECTOR. SOFT ERROR IS SIMULATED BY WCE AS IN PREVIOUS
5509 ;*TEST. PREREQUISITES FOR THIS TEST ARE THE SAME AS THOSE
```

```

5510                                     ;*FOR THE PREVIOUS TEST.
5511                                     ;*****
5512 016762 000004 TST51: SCOPE
5513 016764 104413 CNT.RESET
5514                                     ;GO, DO CONTROL RESET
5515                                     ;THIS IS A CALL FOR THE 'CNTRL-
5516                                     ;RESET' ROUTINE. A CONTROL RESET IS
5517                                     ;ISSUED AND AFTER A CERTAIN TIME
5518                                     ;IF THE 'CNTRL RDY' DOES NOT SET
5519                                     ;AN ERROR IS REPORTED. NOTE THAT
5520                                     ;THE PC IN ERROR MESSAGE IS THE
5521                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
5522                                     ;THIS IS A VERY BASIC ERR& IF IT
5523 016766 104421 TST.SIN ;OCCURS GO BACK TO TEST 10
5524                                     ;CHECK IF SIN IS SET, IF
5525 016770 012737 170007 033360 MOV #170007,OUTBUF+16 ;SET DO DRIVE RESET TO CLR IT
5526                                     ;WCE IS SIMULATED BY DROPPING A BIT
5527                                     ;IN THE EIGHTH WORD (WHICH IS 174007)
5528                                     ;NOTE THAT THE 256 WORD MEMORY
5529                                     ;BUFFER (STARTING AT OUTBUF) IS
5530                                     ;CREATED IN A PREVIOUS TEST.
5531 017002 012777 177000 162324 MOV DRIVAD,R1
5532 017010 012777 033342 162320 MOV #-1000,@RKWC ;WRT CHK 1000 (OCTAL) WORDS, 2 SECTORS
5533 017016 010177 162316 MOV #OUTBUF,@RKBA ;FROM THIS BUS ADRES
5534 017022 013700 001402 MOV R1,@RKDA ;WITH THIS DISK ADRES, SEC 0, CYL 0
5535 017026 012720 017060 MOV RKVEC,R0
5536 017032 012710 000340 MOV #1$, (R0)+ ;SET UP INTERRUPT VECTOR FOR RK11
5537 017036 012777 000507 162266 MOV #340,@R0 ;SET PSW ON INTERRUPT
5538 017044 104420 177777 WAT.INT,177777 ;WRT CHK, GO. SSE, IDE SET
5539                                     ;WAIT FOR INTERRUPT FROM RK11
5540                                     ;TIME=485 MS FOR 11/20,
5541 017050 004737 021010 JSR PC,GT2RG ;97 MS FOR 11/45
5542 017054 104111 ERROR 111 ;11/05
5543                                     ;RK11 DID NOT INTERRUPT AFTER A SOFT
5544 017056 000417 BR 2$ ;ERROR (SIMULATED) IN SECTOR 0
5545
5546 017060 022626 1$: CMP (SP)+,(SP)+ ;RESTORE STACK POINTER (FROM RK11 INTRUPT)
5547 017062 022626 CMP (SP)+,(SP)+ ;POP STACK (FROM WAT.INT)
5548 017064 012777 004600 162310 MOV #BADINT,@RKVEC ;RESTORE RK11 INTERRUPT VECTOR
5549                                     ;ADRES FOR UNEXPECTED INTERRUPTS
5550 017072 005201 INC R1
5551 017074 020177 162240 CMP R1,@RKDA ;CHECK THAT RKDA INCREMENTED
5552                                     ;BY ONLY 1 SECTOR BEFORE INTERRUPT
5553                                     ;OCCURRED
5554 017100 001406 BEQ 2$
5555 017102 010137 001162 MOV R1,$REG0 ;GET EXPCTD RKDA
5556 017106 017737 162226 001164 MOV @RKDA,$REG1 ;GET RKDA RECVD
5557 017114 104003 ERROR 3 ;RKDA SHOULD HAVE INCREMENTED BY
5558                                     ;1 SECTOR ONLY, IF ALL CNTRL ACTION
5559                                     ;HAD STOPPED AFTER SOFT ERROR
5560                                     ;(SIMULATED) IN SECTOR 0. IT DID NOT.
5561 017116 2$:
5562 017116 012746 000340 MOV #340,-(SP)
5563 017122 012746 017130 MOV #64$,-(SP)
5564 017126 000002 RTI
5565 017130 64$:

```


5566 017130 005077 162176
5567
5568
5569
5570
5571
5572
5573
5574
5575
5576
5577
5578 017134 000004
5579 017136 013700 001332
5580 017142 012701 177774
5581 017146 005002
5582 017150 012737 017156 001110
5583
5584 017156 104417 000142
5585 017162 004737 021436
5586 017166 104016
5587 017170 104413
5588
5589
5590
5591
5592
5593
5594
5595
5596
5597 017172 010210
5598 017174 012777 177777 162132
5599 017202 013777 001350 162130
5600 017210 012777 177776 162120
5601
5602 017216 052710 000007
5603
5604
5605
5606 017222 104412
5607
5608 017224 104065
5609 017226 010205
5610 017230 062705 000020
5611 017234 042705 000100
5612 017240 011004
5613 017242 042704 177717
5614 017246 020504
5615 017250 001405
5616 017252 010537 001162
5617 017256 010437 001164
5618 017262 104112
5619
5620
5621

CLR @RKCS ;CLEAR THE IDE BIT

: *TEST 52 CHECK THE MEX BITS IN RKCS
: *THIS TEST CHECKS OUT THE EXTENDED MEMORY BITS OF THE RKCS.
: *THE RKBA IS SET TO 177776 AND A ONE WORD WRITE CHECK IS TRIED.
: *THIS COULD GIVE RISE TO NXM ERROR, BUT EVEN THEN THE RKBA
: *SHOULD OVERFLOW INTO THE MEX BITS. SIMILIARLY IT IS CHECKED
: *THAT THE OVERFLOWING BIT CAN MAKE THE MEX BITS COUNT
: *01,10,11,00.

TST52: SCOPE
MOV RKCS,R0
MOV #-4,R1 ;SET UP THE COUNT
CLR R2 ;INITIALIZE MEX BITS TO B SET IN RKCS
MOV #1\$, \$LPERR ;SET RETURN ADRES FOR
;LUPING ON EROR (SW9)

1\$: DELAY ,142 ;TIME DELAY
JSR PC,TSTRWS ;WAIT FOR R/W/S RDY
ERROR 16 ;R/W/S RDY IS NOT SET
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10

MOV R2,@R0 ;SET MEX BITS (AS IN R2) IN RKCS
MOV #-1,@RKWC ;WRT CHK 1 WORD
MOV DRIVAD,@RKDA ;THIS DISK ADRES, SEC 0, CYL 0
MOV #177776,@RKBA ;THIS BUS ADRES. NOTE THIS BA
;IN CONJUCTION WITH MEX BITS OF RKCS

BIS #7,@R0 ;WRT CHK, GO
;THERE MAY BE A NXM OR WCE BUT
;WHATEVER THE CASE RKBA SHOULD
;OVERFLOW MAKING THE MEX BITS COUNT

CHKCRDY
GO CHECK IF CONTROL RDY IS SET
;IF SO, SKIP THE EROR MESSAGE.
;CNTRL RDY DID NOT SET AFTER WRT CHK

3\$: MOV R2,R5 ;MEX BITS SHOULD INCREMENT BY 1 TO THIS
ADD #20,R5 ;MASK OUT IDE BIT POSITION, IF SET
BIC #100,R5 ;GET RKCS
MOV @R0,R4 ;MASK OUT ALL BITS EXCEPT MEX
BIC #177717,R4 ;DID MEX BITS INCREMENT CORRECTLY?
CMP R5,R4 ;YES, BRANCH
BEQ 4\$;GET EXPCTD MEX BITS
MOV R5,\$REGO ;GET MEX BITS RECVD
MOV R4,\$REG1 ;MEX BITS DID NOT INCREMENT AS
ERROR 112 ;'EXPCTD' WHEN RKBA OVERFLOWED.
;NOTE THAT BIT POSITION 4 & 5
;REFLECT MEX BITS 0 & 1 IN THE

```
5622                                     :ERROR MESSAGE.  
5623 017264 017703 162040          4$:  MOV    @RKER,R3          :GET RKER  
5624 017270 010305                                     :  
5625 017272 042703 003001          BIC    #3001,R3          :MASK WCE,DLT,NXM BIT, IF SET  
5626 017276 001410          BEQ    5$                :BRANCH IF REST OF RKER CLR  
5627 017300 042705 177776          BIC    #177776,R5       :MASK NON-WCE BITS  
5628 017304 010537 001162          MOV    R5,$REGO        :THIS IS THE EXPCTD RKER  
5629 017310 017737 162014 001164  MOV    @RKER,$REG1     :GET RKER RECVD  
5630 017316 104107          ERROR  107            :ERROR IN RKER. IT SHOULD  
5631                                     :BE AS EXPECTED IN  
5632                                     :ERROR MESSAGE  
5633 017320 062702 000020          5$:  ADD    #20,R2        :INCREMENT TO NXT MEX BIT  
5634 017324 005201          INC    R1              :HAVE U CHKD THE MEX BITS 4 TIMES?  
5635 017326 001313          BNE   1$              :IF NOT, LUP BACK  
5636  
5637  
5638  
5639  
5640  
5641  
5642  
5643  
5644  
5645  
5646  
5647 017330 000004  
5648 017332 012737 000001 001206  :*****  
5649                                     :*TEST 53      TRANSFER FROM DISK TO TTY  
5650                                     :* THIS TEST CHECKS THE HIGH ORDER BITS OF THE ADDRESS  
5651                                     :* LINES. FIRST A ONE WORD (100) IS WRITTEN ON SECTOR,  
5652                                     :* 2, CYL 0. THEN IT IS READ BACK, BUT THE NPR IS DONE  
5653                                     :* NOT TO THE MEMORY, BUT THE TELETYPE BUFFER (TKS 177560)  
5654                                     :* AND IT CHECKED THAT THE WORD WAS RECIEVED CORRECTLY.  
5655                                     :*IF IT IS NOT, AN ERROR IS REPORTED. THIS TEST IS  
5656                                     :*SKIPPED ON AN 11/05.  
5657  
5658  
5659  
5660  
5661  
5662  
5663  
5664  
5665  
5666  
5667  
5668  
5669  
5670  
5671  
5672  
5673  
5674  
5675  
5676  
5677 017412 012701 033342          TST53: SCOPE  
                                     MOV    #1,$TIMES        ;;DO 1 ITERATION  
                                     :THIS CODE FINDS OUT IF THE CPU  
                                     :IS AN 11/05 OR ELSE.  
                                     :ON AN 11/05, R0 (177700) CAN BE  
                                     :ADDRESSED AS A MEMORY LOCATION, BUT  
                                     :ON ANY OTHER CPU IF 177700 IS REFERENCED  
                                     :A TIME OUT WILL OCCUR.  
5655 017340 012737 017362 000004  MOV    #5$,a#4        :SET UP TIME OUT VECTOR  
5656 017346 005737 177700          TST    a#177700       :REFERENCE R0  
5657 017352 012737 004534 000004  MOV    #BADTMO,a#4    :R0 WAS REFERENCED W/O TIMEOUT  
5658                                     :HENCE 11/05  
5659 017360 000520          BR     TST54          ;;SKIP THIS TEST  
5660 017362 022626          5$:  CMP    (SP)+,(SP)+  :RESTORE STACK POINTER  
5661 017364 012737 004534 000004  MOV    #BADTMO,a#4    :RESTORE TIMEOUT VECTOR  
5662 017372 012746 000340          MOV    #340,-(SP)  
5663 017376 012746 017404          MOV    #64$,-(SP)  
5664 017402 000002          RTI  
5665 017404          64$:  
5666 017404 013700 001332          MOV    RKCS,R0  
5667 017410 104413          CNT.RESET  
5668                                     :GO, DO CONTROL RESET  
5669                                     :THIS IS A CALL FOR THE 'CNTRL-  
5670                                     :RESET' ROUTINE. A CONTROL RESET IS  
5671                                     :ISSUED AND AFTER A CERTAIN TIME  
5672                                     :IF THE 'CNTRL RDY' DOES NOT SET  
5673                                     :AN ERROR IS REPORTED. NOTE THAT  
5674                                     :THE PC IN ERROR MESSAGE IS THE  
5675                                     :PC WHERE 'CNT.RESET' IS LOCATED.  
5676                                     :THIS IS A VERY BASIC ERR& IF IT  
5677                                     :OCCURS GO BACK TO TEST 10  
MOV    #OUTBUF,R1
```



```

5678 017416 013704 001336      MOV      RKBA,R4
5679 017422 012711 000100      MOV      #100,@R1      ;WRITE THIS WORD
5680 017426 012777 177777 161700  MOV      #-1,@RKWC     ;WRITE 1 WORD
5681 017434 013702 001350      MOV      DRIVAD,R2
5682 017440 052702 000002      BIS      #2,R2         ;ON CYL 0, SEC 2
5683 017444 010277 161670      MOV      R2,@RKDA
5684 017450 010114      MOV      R1,@R4        ;FROM THIS MEMORY LOC
5685 017452 012710 000003      MOV      #3,@R0        ;WRITE, GO
5686 017456 005003      CLR      R3
5687 017460 105710 1$:      TSTB    @R0
5688 017462 100410      BMI     2$
5689 017464 005203      INC     R3
5690 017466 001374      BNE     1$
5691 017470 004737 020774      JSR     PC,GT4RG       ;GET RKCS, ER, DS
5692 017474 010237 001202      MOV     R2,$REG10     ;GET THE STARTING ADRES
5693 017500 104416      BRKDA4 ;BREAK IT INTO DRV #, CYL, SUR, SEC #
5694 017502 104031      ERROR  31            ;CNTRL RDY DID NOT SET AFTER
5695                                     ;WRITE OF 1 WORD ON CYL 0, SEC 2
5696 017504 012777 177777 161622 2$:      MOV     #-1,@RKWC     ;READ 1 WORD
5697 017512 010277 161622      MOV     R2,@RKDA      ;FROM SEC 2, CYL 0
5698 017516 013714 001144      MOV     $TKS,@R4      ;INTO TTY STAU$ REGISTER
5699 017522 005077 161416      CLR     @$TKS         ;CLEAR TTY KEY BRD STATUS REG
5700
5701 017526 012710 000065      MOV     #65,@R0       ;READ, MEX BITS SET
5702 017532 005003      CLR     R3
5703 017534 105710 3$:      TSTB    @R0
5704 017536 100410      BMI     4$
5705 017540 005203      INC     R3
5706 017542 001374      BNE     3$
5707 017544 004737 020774      JSR     PC,GT4RG
5708 017550 010237 001202      MOV     R2,$REG10     ;GET THE STARTING ADRES
5709 017554 104416      BRKDA4 ;BREAK IT INTO DR#, CYL, SUR, SEC#
5710 017556 104045      ERROR  45            ;CNTRL RDY DIDN'T SET AFTER
5711                                     ;READ OF 1 WORD FROM CYL 0, SEC 2.
5712                                     ;IN EROR MSGE, <DSK-ADRES> GIVES
5713                                     ;ADRES WHERE READ BEGAN. 'RKDA'
5714                                     ;GIVES CONTENTS OF RKDA AT TIME OF EROR
5715 017560 032737 000100 001144 4$:      BIT.    #100,$TKS     ;WAS THE CORRECT WORD READ INTO
5716                                     ;THE TTY STATUS REGISTER?
5717 017566 001015      BNE     TST54         ;:YES, EXIT
5718 017570 017705 161350      MOV     @$TKS,R5      ;GET THE WORD RECVD FROM DISK
5719 017574 010537 001164      MOV     R5,$REG1
5720 017600 052705 000100      BIS     #100,R5       ;THIS WORD WAS EXPCTD
5721 017604 010537 001162      MOV     R5,$REG0     ;STORE EXPCTD WORD
5722 017610 011437 001166      MOV     @R4,$REG2    ;GET RKBA
5723 017614 011037 001170      MOV     @R0,$REG3    ;GET RKCS
5724 017620 104115      ERROR  115          ;DATA ERROR. A ONE WORD (100)
5725                                     ;NPR WAS TRIED FROM DISK TO
5726                                     ;TTY KEYBOARD STATUS REGISTER
5727                                     ;(17756) . BIT 6 SHOULD HAVE BEEN
5728                                     ;SET AS RESULT OF THIS
5729                                     ;BUT IT WAS NOT
5730
5731
5732
5733
;*****
;*TEST 54      CHECK THAT RKBA CAN COUNT CORRECTLY
    
```

```
5734                                     ;*THIS TEST CHECKS THAT RKBA CAN COUNT CORRECTLY. IT IS SET
5735                                     ;*TO THE DESIRED INITIAL VALUE. THEN A ONE WORD WRITE CHECK
5736                                     ;*IS TRIED, WITH MEX (MEMORY EXTENSION) BITS SET. IF THERE IS
5737                                     ;*NO MEMORY PRESENT (FOR CERTAIN BUS ADDRESSES), THERE
5738                                     ;*WILL BE AN NXM ERROR STOPPING CONTROLLER ACTION. BUT RKBA
5739                                     ;*SHOULD HAVE INCREMENTED BY 1 FROM ITS INITIAL VALUE. IF IT
5740                                     ;*HAS NOT, AN ERROR IS REPORTED.
5741                                     ;*****
5742 017622 000004 TST54: SCOPE
5743 017624 012737 000005 001206 MOV #5,$TIMES ;DO 5 ITERATIONS
5744 017632 104421 TST.SIN ;CHECK IF SIN SET, IF SET DRV RESET
5745 017634 005001 CLR R1 ;INITIALIZE (VALUE OF RKBA)
5746 017636 012702 000002 MOV #2,R2 ;INITIALIZE (INCMNTD VALUE OF RKBA)
5747
5748 017642 012737 017654 001110 MOV #1$,$LPERR ;SET RETURN ADRES FOR LUPING
5749 ;ON EROR
5750
5751 017650 013705 001336 MOV RKBA,R5
5752 017654 004737 021436 1$: JSR PC,TSTRWS ;WAIT FOR R/W/S RDY
5753 017660 104016 ERROR 16 ;R/W/S RDY IS NOT SET
5754 017662 104413 CNT.RESET ;DO CONTROL RESET
5755 017664 012777 177777 161442 MOV #-1,@RKWC ;WRITE CHK 1 WORD
5756 017672 010115 MOV R1,@R5 ;THIS BUS ADRES
5757 017674 013777 001350 161436 MOV DRIVAD,@RKDA ;SET DISK ADRES
5758 017702 012777 000067 161422 MOV #67,@RKCS ;WRITE CHECK, GO, MEX BITS SET
5759 017710 104412 CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
5760 ;IF SO, SKIP THE EROR MESSAGE.
5761 017712 104065 ERROR 65 ;CNTRL RDY DID NOT SET AFTER
5762 ;WRT CHK WAS TRIED TO NXM LOC
5763 ;U MIGHT WANT TO USE TESTS
5764 ;CHECKING MEX BITS & NXM.
5765 017714 005237 001356 INC INDX1 ;ALLOW ONLY 5 ERRORS OF ABOVE KIND
5766 017720 001417 BEQ 5$
5767
5768 017722 020215 3$: CMP R2,@R5 ;DID RKBA INCREMENT BY 1 FROM
5769 ;ITS INITIAL VALUE?
5770 017724 001410 BEQ 4$ ;YES, BRANCH
5771 017726 010137 001162 MOV R1,$REGO ;GET EXPCTD RKBA
5772 017732 011537 001164 MOV @R5,$REG1 ;GET RKBA RECVD
5773 017736 104017 ERROR 17 ;RKBA DID NOT INCREMENT BY
5774 ;1 FROM ITS INITIAL VALUE.
5775 ;ONE WORD WRT CHK WAS TRIED
5776 ;TO A NXM LOCATION. THERE
5777 ;WILL BE AN NXM ERROR,
5778 ;BUT STILL RKBA SHOULD
5779 ;INCREMENT BY 1 FROM ITS
5780 ;INITIAL VALUE.
5781 017740 005237 001360 INC INDX2 ;ALLOW ONLY 5 ERRORS OF
5782 017744 001405 BEQ 5$ ;THE ABOVE KIND
5783 017746 060201 4$: ADD R2,R1 ;SET NXT VALUE OF RKBA
5784 017750 010102 MOV R1,R2
5785 017752 062702 000002 ADD #2,R2 ;SET EXPCTD VALUE OF RKBA
5786 017756 001336 BNE 1$ ;ALL DONE?
5787
5788 017760 5$: ;DUMMY EXIT POINT
5789
```


5790
5791
5792
5793
5794
5795
5796
5797 017760 000004
5798 017762 012737 000001 001206
5799 017770 005737 001404
5800 017774 001403
5801 017776 004537 025160
5802 020002 104120
5803
5804 020004
5805
5806
5807
5808
5809
5810
5811
5812
5813
5814 020004 000004
5815 020006 012737 000001 001206
5816 020014 005237 001352
5817
5818 020020 004737 021504
5819 020024 104026
5820 020026 023737 001412 001352
5821
5822 020034 001405
5823 020036 062737 020000 001350
5824 020044 000137 005040
5825
5826 020050 005037 001112
5827
5828
5829
5830
5831
5832
5833
5834
5835
5836
5837
5838
5839
5840
5841
5842
5843
5844
5845 020054 000004

*TEST 55 CHECK FOR RK-05F
;*THIS TEST CHECKS RK-05F TYPE DRIVES
;*TO INSURE THAT IF SEEKS ARE ISSUED ON ONE
;*DRIVE, THE OTHER DRIVE BECOMES BUSY

TST55: SCOPE
MOV #1,\$TIMES ;;DO 1 ITERATION
TST FFLAG ;SEE IF RK-05F
BEQ 1\$;NOT F
JSR R5,FCHECK ;SEE IF OTHER GOES BUSY
ERROR 120

1\$:

*TEST 56 END OF PROGRAM
;*THIS IS NOT A TEST, BUT A LINKAGE PROVIDED TO PERFORM
;*THE ABOVE SUB-TESTS FOR ALL DRIVES THAT ARE PRESENT.
;*NOTE THAT THE NEXT TEST- HARDWARE POLLING LOGIC-
;*IS DONE USING ALL THE DRIVES THAT ARE INDICATED PRESENT.
;*DO NOT LOOP ON THIS 'TEST'.

TST56: SCOPE
MOV #1,\$TIMES ;;DO 1 ITERATION
INC DRVDON ;INCREMENT THE COUNT FOR THE NUMBER
;OF DRIVES THAT ARE CHECKED
JSR PC,DRESET ;RESET THE DRIVE
ERROR 26 ;R/W/S DIDN'T SET AFTER DRIVE RESET
BTEOP: CMP DRIVS,DRVDON ;HAVE U TESTED ALL THE DRIVES
;THAT ARE PRESENT?
BEQ 1\$;IF YES, EXIT
ADD #20000,DRIVAD ;ADRES THE NXT POSSIBLE DRIVE
JMP NUDRV ;GO BACK AND TEST THE NEXT
;DRIVE PRESENT
1\$: CLR \$ERTTL

*TEST 57 CHECK HARDWARE POLLING LOGIC
;*THIS TEST CHECKS THE HARDWARE POLL LOGIC, USING ALL THE DRIVES
;*PRESENT ON THE RK11. ATLEAST TWO DRIVES SHOULD BE PRESENT
;*TO DO A MEANINGFUL HARDWARE POLL. SEQUENCE OF OPERATIONS IS
;*AS FOLLOWING:
;*1) NUMBER OF DRIVES ON THE RK11 IS ASCERTAINED.
;*2) HAVING LOCKED OUT ALL INTERRUPTS (CPU PR 7), SEEK IS INITIATED
;*FOR ONE DRIVE AT A TIME, ONLY WHEN 'CNTRL RDY' IS SET.
;*3) CPU PRIORITY IS DROPPED TO 4 SO THAT RK11 CAN INTERRUPT, THE INCOMING
;*INTERRUPT IS PROCESSED TO CHECK IF IT WAS DUE TO 'SEEK DONE' BY
;*ONE OF THE DRIVES.
;*4) IF BY THE END OF THE SET TIME A DRIVE HAS NOT INTERRUPTED
;*AN ERROR MESSAGE IS GIVEN INDICATING WHICH DRIVE DID NOT
;*INTERRUPT AFTER SEEK WAS DONE.

TST57: SCOPE

```

5846 020056 012737 000005 001206      MOV      #5,$TIMES      ;;DO 5 ITERATIONS
5847 020064 005237 001440      INC      SIZYET        ;FOUNR RK05F YET?
5848 020070 001002                BNE      25$           ;YES
5849 020072 004737 025304      JSR      PC,SIZEF      ;FIND WHICH ARE RK-05F
5850 020076 005037 001436      25$:    CLR      PHYDRV    ;NUMBER OF ACTUAL DRIVES
5851 020102 012700 001414      MOV      #DRIVO,R0     ;TABLE
5852 020106 005710      23$:    TST      (R0)        ;DRIVE HERE+?
5853 020110 001405                BEQ      22$           ;NO
5854 020112 005237 001436      INC      PHYDRV        ;COUNT DRIVE
5855 020116 005710      TST      (R0)          ;RK05F?
5856 020120 100001                BPL      22$           ;NO
5857 020122 005720      TST      (R0)+         ;DONT COUNT F TWICE
5858 020124 005720      22$:    TST      (R0)+ ;NEXT DRIVE
5859 020126 020027 001433      CMP      R0,#DRIV7+1   ;ALL YET
5860 020132 002765      BLT      23$           ;NO
5861 020134 005037 001406      CLR      ODDEVN        ;EVEN DRIVES FIRST IF F
5862 020140 005737 001412      156$:   TST      DRIVS      ;ANY DRIVES PRESENT?
5863 020144 001002                BNE      20$           ;YES
5864 020146 000137 020652      JMP      $EOP          ;NO
5865 020152 005237 001434      20$:    INC      T56FLG
5866 020156 013700 001332      MOV      RKCS,R0
5867 020162 005037 001356      CLR      INDX1        ;FLAG TO INDICATE:
5868                                ;(INDX1)=0 POLLING DONE AFTER ALL
5869                                ;DRIVES SEEK TO CYL 0
5870                                ;(INDX1)=1 POLLING DONE AFTER ALL
5871                                ;DRIVES SEEK TO CYL 4
5872 020166 005037 001360      15$:    CLR      INDX2    ;FLAG INDICATING TYPE OF INTERRUPT
5873                                ;SET TO NON-ZERO TO INDICATE
5874                                ;THAT THE INTERRUPT IS DUE TO
5875                                ;SEEK DONE
5876 020172 104413      CNT.RESET ;GO, DO CONTROL RESET
5877                                ;THIS IS A CALL FOR THE 'CNTRL-
5878                                ;RESET' ROUTINE. A CONTROL RESET IS
5879                                ;ISSUED AND AFTER A CERTAIN TIME
5880                                ;IF THE 'CNTRL RDY' DOES NOT SET
5881                                ;AN ERROR IS REPORTED. NOTE THAT
5882                                ;THE PC IN ERROR MESSAGE IS THE
5883                                ;PC WHERE 'CNT.RESET' IS LOCATED.
5884                                ;THIS IS A VERY BASIC ERR& IF IT
5885                                ;OCCURS GO BACK TO TEST 10
5886 020174 005737 001356      TST      INDX1        ;PERFORMING SEEKS TO CYL 4
5887 020200 001002      BNE      .+6           ;YES, BRANCH
5888 020202 005002      CLR      R2           ;NO
5889 020204 000402      BR       .+6
5890 020206 012702 000200      MOV      #200,R2      ;SET ADRES FOR FOURTH CYLINDER
5891 020212 012701 001414      MOV      #DRIVO,R1    ;INITIALIZE POINTER
5892 020216 012703 177770      MOV      #-10,R3      ;SET COUNT FOR 8 DRIVES
5893 020222 012705 033342      MOV      #OUTBUF,R5   ;INITIALIZE POINTER TO INDICATOR AREA
5894 020226 005025      CLR      (R5)+        ;CLEAR OUT THE 8-WORD INDICATOR
5895 020230 005203      INC      R3           ;AREA WHICH IS USED FOR DOING
5896 020232 001375      BNE      .-4          ;SOFTWARE POLLING LATER ON
5897 020234 012703 177770      MOV      #-10,R3      ;SET COUNT FOR 8 POSSIBLE DRIVES
5898 020240 012705 033342      MOV      #OUTBUF,R5   ;INITIALIZE POINTER TO INDICATOR AREA
5899 020244      1$:
5900 020244 012746 000340      MOV      #340,-(SP)
5901 020250 012746 020256      MOV      #64$,-(SP)
    
```


5902	020254	000002			RTI		
5903	020256			64\$:			
5904	020256	032711	000001		BIT	#BIT0,(R1)	; IS THIS DRIVE PRESENT?
5905	020262	001433			BEQ	4\$; IF NOT, BRANCH
5906	020264	005711			TST	(R1)	; RK06F?
5907	020266	100012			BPL	17\$; NO, CONTINUE
5908	020270	032702	020000		BIT	#BIT13,R2	; DRIVE EVEN?
5909	020274	001404			BEQ	16\$; YES
5910	020276	005737	001406		TST	ODDEVN	; DO WE WANT ODD?
5911	020302	001423			BEQ	4\$; NO, SO DO NOT TEST
5912	020304	000403			BR	17\$; ADD THIS DRIVE TO LIST
5913	020306	005737	001406	16\$:	TST	ODDEVN	; DO WE WANT EVEN?
5914	020312	001017			BNE	4\$; NO, SO SKIP
5915	020314	010215		17\$:	MOV	R2,(R5)	; SET UP THIS WORD IN THE
5916							; INDICATOR AREA SHOWING THAT THIS
5917							; DRIVE (AS IN BITS 13-15 OF R2)
5918							; IS PRESENT
5919	020316	042725	017777		BIC	#17777,(R5)+	; MASK OUT UNWANTED BITS (CYL,SUR,SEC BITS)
5920	020322	005004			CLR	R4	
5921	020324	105710		2\$:	TSTB	@R0	; IS CNTRL RDY SET?
5922	020326	100405			BMI	3\$; YES, BRANCH
5923	020330	005204			INC	R4	; NO, WAIT FOR IT
5924	020332	001374			BNE	2\$; IF WAITED LONG REPORT ERROR
5925	020334	004737	020774		JSR	PC,GT4RG	; GO, GET RKCS,ER,DS,DA
5926	020340	104021			ERROR	21	; CNTRL RDY DID NOT SET AFTER ACCEPTING
5927							; ADRES FROM PREVIOUS SEEK
5928	020342	010277	160772	3\$:	MOV	R2,@RKDA	; ADRES THIS DRIVE, CYL 0 OR CYL 4
5929							; (WHICHEVER THE CASE MAY BE)
5930	020346	012710	000111		MOV	#111,@R0	; SEEK,GO,IDE SET
5931	020352	005721		4\$:	TST	(R1)+	; NEXT DRIVE DATA
5932	020354	062702	020000		ADD	#20000,R2	; INCREMENT DRIVE ADRES (BITS 15,14,13)
5933	020360	005203			INC	R3	; TO NEXT ONE
5934	020362	001330			BNE	1\$; BRANCH BACK IF ALL DRIVES ARE
5935							; NOT CHECKED TO SEE IF THE NEXT
5936							; DRIVE IS PRESENT (& IF SO ISSUE A
5937							; SEEK TO IT)
5938							; BY NOW SEEKS HAVE BEEN ISSUED
5939							; TO ALL DRIVES PRESENT & POLLING
5940							; HAS BEGUN
5941	020364	005004			CLR	R4	
5942	020366	013702	001402	5\$:	MOV	RKVEC,R2	
5943	020372	012722	020424		MOV	#6\$,(R2)+	; SET ADRES FOR RK11 TO INTERUPT
5944	020376	012712	000340		MOV	#340,(R2)	; SET PSW ON INTERUPT
5945	020402	013746	001400		MOV	RKPRI,-(SP)	; DROP CPU PRIORITY TO 4 SO THAT
5946	020406	012746	020414		MOV	#18\$,-(SP)	; RK11 CAN INTERUPT
5947	020412	000002			RTI		
5948	020414	000240		18\$:	NOP		; THIS IS A TIME LOOP DURING
5949	020416	005204			INC	R4	; WHICH ALL DRIVES PRESENT SHOULD
5950	020420	001375			BNE	18\$; INTERRUPT
5951	020422	000452			BR	11\$; BRANCH AND CHECK IF ALL AVAILABLE
5952							; DRIVES INTERRUPTED CORRECTLY
5953	020424	022626		6\$:	CMP	(SP)+,(SP)+	; RESTORE STACK POINTER
5954	020426	005737	001360		TST	INDX2	; WAS THIS FIRST INTERRUPT
5955							; DUE TO 'ADRES ACK' AFTER INITIATION
5956							; OF SEEK?
5957	020432	001021			BNE	9\$; IF YES, CHECK THE FOLLOWING

```

5958
5959 020434 032710 020000          BIT    #20000,@R0      ;CHECK THAT SCP IS NOT SET
5960 020440 001403                   BEQ    7$              ;BRANCH IF SCP CLEAR
5961 020442 011037 001162          MOV    @R0,$REGO      ;GET RKCS
5962 020446 104076                   ERROR  76              ;AFTER THE FIRST INTERRUPT WHICH
5963                                     ;IS DUE TO INITIATION OF SEEK, SCP
5964                                     ;SHOULD NOT HAVE SET. IT DID
5965 020450 017701 160652          7$:  MOV    @RKDS,R1
5966 020454 032701 160000          BIT    #160000,R1    ;RKDS BITS 15-13 SHLOULD BE CLR
5967 020460 001403                   BEQ    8$
5968 020462 010137 001162          MOV    R1,$REGO      ;GET RKDS
5969 020466 104050                   ERROR  50              ;SEEK, WITH IDE SET WAS ISSUED TO
5970                                     ;ALL AVAILABLE DRIVES. THE FIRST
5971                                     ;INTERUPT IS DUE TO SEEK INITIATED
5972                                     ;BY FRST DRV. DRV ID BITS 13-15
5973                                     ;SHOULD BE CLR AFTR THIS FRST INRUPT.
5974                                     ;THEY WERE NOT IF THIS ERROR OCCURS.
5975 020470 005237 001360          8$:  INC    INDX2
5976                                     ;SET UP FLAG INDICATING
5977                                     ;THAT THE FIRST INTERRUPT DUE
5978                                     ;TO INITIATION OF SEEK WAS
5979                                     ;PROCESSED
5979 020474 000734                   BR     5$              ;GO BACK TO THE WAIT LOOP & WAIT
5980                                     ;FOR NEXT INTERRUPT FROM RK11
5981 020476 013703 001436          9$:  MOV    PHYDRV,R3   ;SET COUNT OF # OF DRIVES PRESENT
5982 020502 012705 033342          MOV    #OUTBUF,R5    ;INITIALIZE POINTER
5983 020506 017701 160614          MOV    @RKDS,R1      ;GET RKDS
5984 020512 042701 017777          BIC    #17777,R1     ;MASK BITS 0-12
5985                                     ;THE FOLLOWING CODE IS A SOFTWARE
5986                                     ;POLL WHICH FINDS OUT WHICH DRIVE
5987                                     ;CAUSED THE PRESENT INTERRUPT
5988                                     ;AND SETS UP A FLAG BIT FOR
5989                                     ;THE DRIVE #, INDICATING THAT
5990                                     ;THIS DRIVE # INTERRUPTED
5991 020516 020125                   CMP    R1,(R5)+
5992 020520 001411                   BEQ    10$            ;BRANCH IF INTERRUPTING DRIVE WAS FOUND
5993 020522 005303                   DEC    R3              ;HAVE U CHKD ALL DRIVS PRESENT?
5994 020524 001374                   BNE    -6              ;IF NOT LUP BAK & CHK
5995                                     ;REPORT ERROR IF THE INTERRUPTING
5996                                     ;DRIVE # (AS IN RKDS 13-15) WAS NOT
5997                                     ;ANY ONE OF THOSE THAT ARE PRESENT
5998 020526 010146                   MOV    R1,-(R6)
5999 020530 004737 021200          JSR    PC,SHFTRT     ;GET WORD TO B SHFTD RT
6000 020534 012637 001162          MOV    (R6)+,$REGO   ;GO SHIFT IT
6001                                     ;THIS DRIVE # WAS RECVD IN RKDS AS
6002                                     ;THE INTERRUPTING DRIVE, BUT THIS
6003 020540 104051                   ERROR  51              ;DRIVE IS NOT PHYSICALY PRESENT
6004                                     ;RKDS INDICATES AN INTERRUPTING
6005                                     ;DRIVE # (DURING H'WARE POLL) BUT
6006                                     ;THAT DRIVE IS ACTUALLY NOT PRESENT
6006 020542 000401                   BR     10$+2
6007 020544 005245          10$: INC    -(R5)
6008                                     ;SET UP FLAG INDICATING THAT
6009                                     ;THE INTERRUPT FOR THIS DRIVE
6010                                     ;(AFTER IT HAD COMPLETED ITS SEEK)
6011                                     ;WAS PROCESSED
6011 020546 000707                   BR     5$              ;GO BAK & WAIT FOR FURTHER INTRUPTS
6012 020550 013703 001436          11$: MOV    PHYDRV,R3   ;GET # OF DRIVES
6013 020554 012705 033342          MOV    #OUTBUF,R5    ;INITIALIZE POINTER
    
```



```
6014
6015 020560 105715
6016 020562 001006
6017 020564 011546
6018 020566 004737 021200
6019 020572 012637 001162
6020
6021 020576 104052
6022
6023 020600 062705 000002
6024 020604 005303
6025 020606 001364
6026
6027 020610 005737 001356
6028 020614 001004
6029 020616 005237 001356
6030 020622 000137 020166
6031
6032
6033
6034
6035
6036
6037
6038
6039
6040
6041
6042
6043
6044
6045
6046
6047
6048
6049
6050
6051
6052
6053
6054
6055 020626 005237 001406
6056 020632 022737 000002 001406
6057 020640 001402
6058 020642 000137 020140
6059 020646 005037 001434
6060
6061
6062
6063
6064
6065
6066
6067
6068
6069

14$: TSTB (R5) ;DID THIS DRIVE INTERRUPT?
      BNE 13$ ;YES, BRANCH
      MOV (R5),-(R6) ;GET THIS DRIVE #
      JSR PC,SHFTRT ;SHIFT IT TO THE RIGHT
      MOV (R6)+,$REGO ;THIS DRIVE # DID NOT INTERRUPT
                                ;DURING H'WARE POLL
                                ;DRIVE # (AS IN $REGO) DID NOT
                                ;INTERRUPT DURING HARDWARE POLL
13$: ADD #2,R5 ;INCREMENT POINTER TO THE NEXT FLAG
      DEC R3 ;CHKD FOR ALL DRIVES?
      BNE 14$ ;IF NOT LUP BACK

      TST INDX1 ;DONE POLLING FOR SEEKS TO CYL 312?
      BNE TSTEND ;IF YES, EXIT
      INC INDX1 ;IF NOT, INCREMENT FLAG
      JMP 15$ ;GO DO IT

;INDICATOR TABLE
;THE 8-WORD INDICATOR TABLE USED IN
;THE FORMER PART OF THIS SUB-TEST
;IS LOCATED STARTING AT 'OUTBUF'.
;WORDS ARE SET UP TO INDICATE
;PRESENCE OF A DRIVE EG: IF
;DRIVES 0,1,2 ARE PRESENT, IT WILL
;LOOK LIKE
;OUTBUF: 000000 BITS 13,14,15
;         020000 CONTAIN THE
;         040000 DRIVE NO.
;         000000 REST 0'S
;WHEN A DRIVE INTERRUPTS AFTER SEEK
;IS DONE BIT 0 OF THE CORRESPONDING
;INDICATOR WORD IS SET. THUS FOR THE
;ABOVE EXAMPLE IF ALL DRIVES INTERRUPTED
;CORRECTLY THEN IT WILL LOOK LIKE:
;         12$: 000001 BIT 0 SET
;         020001 TO INDICATE
;         040001 DR INTERRUPTED
;         000000 REST 0'S

TSTEND: INC ODDEVN ;NOW ODD IF RK05F
        CMP #2,ODDEVN ;SEE IF DONE
        BEQ 21$ ;ALL DONE
        JMP T56 ;TEST AGAIN
21$: CLR T56FLG

.SBTTL END OF PASS ROUTINE

;*****
;*INCREMENT THE PASS NUMBER ($PASS)
;*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
;*TYPE 'END PASS #XXXXX' (WHERE XXXXX IS A DECIMAL NUMBER)
;*IF THERES A MONITOR GO TO IT
;*IF THERE ISN'T JUMP TO ST4
```

6070
 6071 020652
 6072 020652 000004
 6073 020654 005037 001102
 6074 020660 005037 001206
 6075 020664 005237 001100
 6076 020670 042737 100000 001100
 6077 020676 005327
 6078 020700 000001
 6079 020702 003022
 6080 020704 012737
 6081 020706 000001
 6082 020710 020700
 6083 020712 104401 020757
 6084 020716 013746 001100
 6085 020722 104405
 6086 020724 104401 020754
 6087 020730 013700 000042
 6088 020734 001405
 6089 020736 000005
 6090 020740 004710
 6091 020742 000240
 6092 020744 000240
 6093 020746 000240
 6094 020750
 6095 020750 000137
 6096 020752 004456
 6097 020754 377 377 000
 6098 020757 015 042412 042116
 6099 020764 050040 051501 020123
 6100 020772 000043

```

$EOP:
    CLR $STSTNM      ;;ZERO THE TEST NUMBER
    CLR $STIMES      ;;ZERO THE NUMBER OF ITERATIONS
    INC $PASS        ;;INCREMENT THE PASS NUMBER
    BIC #100000,$PASS ;;DON'T ALLOW A NEG. NUMBER
    DEC (PC)+        ;;LOOP?
$EOPCT: .WORD 1
    BGT $DOAGN       ;;YES
    MOV (PC)+,@(PC)+ ;;RESTORE COUNTER
$ENDCT: .WORD 1
    $EOPCT
    TYPE , $SENDMG   ;;TYPE 'END PASS #'
    MOV $PASS,-(SP)  ;;SAVE $PASS FOR TYPEOUT
    TYPDS            ;;GO TYPE--DECIMAL ASCII WITH SIGN
    TYPE , $ENULL    ;;TYPE A NULL CHARACTER
$GET42: MOV @#42,R0  ;;GET MONITOR ADDRESS
    BEQ $DOAGN       ;;BRANCH IF NO MONITOR
    RESET           ;;CLEAR THE WORLD
$ENDAD: JSR PC,(R0)  ;;GO TO MONITOR
    NOP             ;;SAVE ROOM
    NOP            ;;FOR
    NOP            ;;ACT11
$DOAGN: JMP @(PC)+   ;;RETURN
$RTNAD: .WORD ST4
$ENULL: .BYTE -1,-1,0 ;;NULL CHARACTER STRING
$SENDMG: .ASCIZ <15><12>/END PASS #/
    
```

```

6101
6102
6103
6104
6105
6106
6107
6108      .SBTTL GT2RG: ROUTINE FOR GETTING RKCS,RKER
6109
6110      ;SUBROUTINE FOR TRANSFERRING THE CONTENTS OF RKCS, RKER
6111      ;TO $REG0, $REG1 RESPECTIVELY BEFORE TYPING OUT AN ERROR MESSAGE.
6112      ;CALL: JSR PC,GT2RG
6113
6114      .SBTTL GT3RG: ROUTINE FOR GETTING RKCS, RKER, RKDS
6115
6116      ;GT3RG
6117      ;SUBROUTINE FOR TRANSFERRING THE CONTENTS OF RKCS, RKER, RKDS
6118      ;TO $REG0, $REG1, $REG2 RESPECTIVELY BEFORE TYPING OUT AN
6119      ;ERROR MESSAGE.
6120      ;CALL: JSR PC,GT3RG
6121
6122      .SBTTL GT4RG: ROUTINE FOR GETTING RKCS, RKER, RKDS, RkDA
6123
6124      ;GT4RG
6125      ;SUBROUTINE FOR TRANSFERRING CONTENTS OF RKCS, RKER, RKDS
    
```



```
6126 ;RKDA TO $REG0, $REG1, $REG2, $REG3 RESPECTIVELY BEFORE
6127 ;TYPING OUT AN ERROR MESSAGE.
6128 ;CALL: JSR PC,GT4RG
6129
6130 020774 017737 160340 001170 GT4RG: MOV @RKDA,$REG3 ;GET RKDA
6131 021002 017737 160320 001166 GT3RG: MOV @RKDS,$REG2 ;GET RKDS
6132 021010 017737 160314 001164 GT2RG: MOV @RKER,$REG1 ;GET RKER
6133 021016 017737 160310 001162 MOV @RKCS,$REG0
6134 021024 000207 RTS PC
```

.SBTTL TYERM: SPECIAL ERROR MESSAGE ROUTINE

```
6140
6141
6142 ;TYERM
6143 ;THIS ROUTINE TYPES OUT 'EROR AT PC=X'
6144 ;X IS THE PC WHERE THE EXPLANATION AS TO WHAT HAPPENED IS GIVEN. THIS ROUTINE
6145 ;IS USED ONLY FOR NON-MANUAL MODE OF THE PROGRAM.
6146 ;CALL: JSR TYERM
6147
6148 021026 TYERM:
6149 021026 104401 021034 TYPE ,65$ ;;TYPE ASCIZ STRING
6150 021032 000406 BR 64$ ;;GET OVER THE ASCIZ
6151 ;;65$: .ASCIZ <15><12>/EROR,PC=/
6152 021050 64$:
6153 021050 010346 MOV R3,-(SP)
6154 021052 104402 TYPOC
6155 021054 000207 RTS PC
```

.SBTTL BDAO, BDA4: BREAK DISK ADDRESS INTO SEC, SUR, CYL, DRIVE

```
6162 ;BDAO, BDA4
6163
6164 ;THIS ROUTINE BREAKS A DISK ADDRESS (BITS 0-15) INTO DRIVE #,
6165 ;CYLINDER #, SURFACE, SECTOR #. THE ROUTINE IS CALLED BY USING EITHER
6166 ;BRKDAO OR BRKDA4, BOTH BEING 'TRAP' INSTRUCTIOS WITH THEIR LOWER BYTES
6167 ;ENCODED TO PROVIDE INDEXING TO 'BDAO' OR 'BDA4'. BEFORE CALLING
6168 ;THE ROUTINE THE DISK ADDRESS WHICH IS TO BE BROKEN AS ABOVE
6169 ;IS DEPOSITED IN $REG10.
6170 ;'BRKDAO' PUTS THE
6171 ;DRIVE # INTO $REG0
6172 ;CYLINDER # INTO $REG1
6173 ;SURFACE # INTO $REG2
6174 ;SECTOR # INTO $REG3
6175 ;CALL: BRKDAO
6176 BRKDA4 PUTS THE
6177 ;DRIVE # INTO $REG4
6178 ;CYLINDER # INTO $REG5
6179 ;SURFACE # INTO $REG6
6180 ;SECTOR # INTO $REG7
6181 ;CALL: BRKDA4
6180 021056 010046 BDAO: MOV R0,-(SP) ;PUSH R0 ONTO THE STACK
6181 021060 012700 001172 MOV # $REG3+2,R0 ;SET UP POINTER
```

```

6182 021064 000403          BR      BDAR
6183
6184 021066 010046          BDA4:  MOV    R0,-(SP)      ;PUSH R0 ONTO THE STACK
6185 021070 012700 001202    MOV    #REG7+2,R0      ;SET UP POINTER
6186
6187 021074 032777 020000 160036 BDAR:  BIT    #20000,@SWR      ;INHIBIT TYPEOUT?
6188 021102 001034          BNE    2$              ;YES, BRANCH TO EXIT POINT
6189
6190 021104 010146          MOV    R1,-(SP)      ;PUSH R1 ON STACK
6191 021106 010246          MOV    R2,-(SP)      ;PUSH R2 ON STACK
6192 021110 013701 001202    MOV    $REG10,R1     ;GET THE ADDRESS WHICH
6193                          ;HAS TO BE BROKEN
6194 021114 042701 177760    BIC    #177760,R1     ;EXTRACT SECTOR BITS 0-3
6195 021120 010140          MOV    R1,-(R0)      ;MOVE SECTOR BITS TO $REG3 OR $REG7
6196 021122 013701 001202    MOV    $REG10,R1     ;GET THE DSK-ADRES TO BE BROKEN
6197 021126 006201          ASR    R1              ;SHIFT RIGHT 4 TIMES
6198 021130 006201          ASR    R1
6199 021132 006201          ASR    R1
6200 021134 006201          ASR    R1
6201 021136 010102          MOV    R1,R2          ;STORE THIS
6202 021140 042702 177776    BIC    #177776,R2     ;EXTRACT THE SURFACE BIT
6203 021144 010240          MOV    R2,-(R0)      ;MOVE SURFACE BIT TO $REG3 OR $REG6
6204 021146 006201          ASR    R1
6205 021150 010102          MOV    R1,R2          ;STORE IT
6206 021152 042702 177400    BIC    #177400,R2     ;EXTRACT THE CYLINDER BITS
6207 021156 010240          MOV    R2,-(R0)      ;MOVE CYLINDER BITS TO $REG1 OR $REG5
6208 021160 000301          SWAB   R1              ;SWAB HI-LO BYTES
6209 021162 042701 177770    BIC    #177770,R1     ;EXTRACT THE DRIVE #
6210 021166 010140          MOV    R1,-(R0)      ;MOVE DRIVE # TO $REG0 OR $REG4
6211
6212 021170 012602          MOV    (SP)+,R2      ;RESTORE R2
6213 021172 012601          MOV    (SP)+,R1      ;RESTORE R1
6214 021174 012600          2$:   MOV    (SP)+,R0      ;RESTORE R0 FROM THE STACK
6215 021176 000002          RTI                    ;RETURN FROM INTERRUPT, EXIT THIS
6216                          ;ROUTINE
6217
6218
6219
6220
6221
6222
6223
6224
6225
6226
6227
6228 021200 012737 177763 021224 SHFTRT: MOV    #-15,2$      ;SET UP A COUNT OF 13
6229 021206 000241          CLC                    ;CLEAR THE C BIT
6230 021210 006066 000002    1$:   ROR    2(R6)      ;ROTATE RIGHT THE WORD TO B SHFTD
6231 021214 005237 021224    INC    2$              ;SHIFTED 13 TIMES?
6232 021220 001373          BNE    1$              ;IF NOT LUP BAK & SHIFT
6233 021222 000207          RTS    PC              ;EXIT FROM THIS SUBROUTINE
6234 021224 000000          2$:   0
6235
6236
6237
    
```

.SBTTL SHFTRT: SHIFT RIGHT ROUTINE

```

;SHFTRT
;THIS ROUTINE SHIFTS A WORD TO THE RIGHT 13 TIMES. THE WORD TO BE SHIFTED
;IS PUT ON THE STACK BEFORE ENTERING THIS ROUTINE AND IT IS POPPED UP
;FROM THE STACK AFTER THE SHIFT HAS BEEN DONE.
;CALL: JSR    PC,SHFTRT
    
```



```

6238
6239
6240           .SBTTL  CHKHE:  CHECK FOR 'ERR'OR
6241           .SBTTL  CHKHE1: CHECK FOR 'ERR'OR
6242
6243           ;;CHKHE
6244           ;THIS ROUTINE CHECKS IF 'HE' OR 'ERR' BITS IN RKCS ARE SET. IF ANY OF THE
6245           ;TWO BITS ARE SET, THE CONTENTS OF RKCS, ER, DS, AND DA ARE SAVED AND A
6246           ;RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
6247           ;AT THE TIME OF ENTRY 'DRIVAD' CONTAINS THE DISK ADDRESS WHICH IS TO
6248           ;BE BROKEN DOWN INTO DRIVE #, CYLINDER, SURFACE AND SECTOR #. THIS INFORMATION
6249           ;IS SAVED TO BE USED LATER FOR ERROR REPORTING. IF THE BITS ARE NOT SET,
6250           ;RETURN IS MADE TO SKIP THE ERROR MESSAGE.
6251
6252           ;CHKHE1
6253           ;THIS ROUTINE CHECKS IF 'HE' OR 'ERR' BITS IN RKCS ARE SET. IF ANY OF THE
6254           ;TWO BITS ARE SET, THE CONTENTS OF RKCS, ER, DS, AND DA ARE SAVED AND A
6255           ;RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
6256           ;AT THE TIME OF ENTRY R1 CONTAINS THE DISK ADDRESS WHICH IS TO BE BROKEN
6257           ;DOWN INTO DRIVE #, CYLINDER, SURFACE AND SECTOR #. THIS INFORMATION IS
6258           ;SAVED TO BE USED LATER FOR ERROR REPORTING. IF THE BITS ARE NOT SET,
6259           ;RETURN IS MADE TO SKIP THE ERROR MESSAGE.
6260
6261 021226 010137 001202      CHKHE1: MOV    R1,$REG10      ;SAVE THE DISK ADRES
6262 021232 000403           BR      CHE1
6263
6264 021234 013737 001350 001202  CHKHE:  MOV    DRIVAD,$REG10  ;SAVE THE DISK ADRES
6265 021242 032777 140000 160062  CHE1:  BIT    #140000,@RKCS  ;IS 'HE' OR 'ERR' BIT SET?
6266 021250 001467           BEQ    CRETRN      ;NO
6267 021252 004737 020774      JSR    PC,GT4RG      ;GET RKCS,ER,DS, DA
6268 021256 104416           BRKDA4  ;GO TO 'BDA4' & BREAK CONTENTS O
6269           ;$REG10 INTO DR#, CYL, SUR, SEC BITS
6270 021260 000207           RTS     PC      ;RETURN TO THE ERROR MESSAGE
6271
6272
6273
6274           .SBTTL  CHKDA:  CHECK IF RKDA INCREMENTED CORRECTLY
6275
6276           ;CHKDA
6277           ;THIS ROUTINE CHECKS IF RKDA INCREMENTED CORRECTLY. IF RKDA INCREMENTED
6278           ;CORRECTLY RETURN IS MADE TO SKIP THE ERROR MESSAGE.
6279           ;IF RKDA DID NOT INCREMENT CORRECTLY, THE EXPECTED AND RECIEVED VALUES
6280           ;OF RKDA ARE SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE
6281           ;'JSR' CALL.
6282 021262 013705 001350      CHKDA:  MOV    DRIVAD,R5      ;RKDA SHOULD INCREMENT TO THIS
6283 021266 005205           INC    R5      ;AFTER DATA TRANSFER IS DONE
6284 021270 020577 160044      CHKDA1: CMP    R5,@RKDA    ;DID RKDA INCREMENT CORRECTLY?
6285 021274 001455           BEQ    CRETRN      ;IF YES, BRANCH
6286           ;IF NOT, REPORT ERROR
6287 021276 010537 001202      MOV    R5,$REG10  ;GET EXPCTD RKDA
6288 021302 104415           BRKDA0  ;GO TO 'BDA0' & BREAK CONTENTS OF
6289           ;$REG10 INTO DR #,CYL,SUR,SEC BITS
6290 021304 017737 160030 001202  MOV    @RKDA,$REG10 ;GET ACTUAL RKDA
6291 021312 104416           BRKDA4  ;GO TO 'BDA4' & BREAK CONTENTS OF
6292           ;$REG10 INTO DR #,CYL,SUR,SEC BITS
6293 021314 000207           RTS     PC      ;RETURN TO THE ERROR MESSAGE

```

6294
6295
6296
6297
6298
6299
6300
6301
6302 021316 005777 160012
6303 021322 001442
6304
6305 021324 017737 160004 001162
6306 021332 017737 160002 001164
6307 021340 000207
6308
6309
6310
6311
6312
6313
6314
6315
6316 021342 005777 157762
6317 021346 001430
6318
6319 021350 004737 021002
6320
6321 021354 000207
6322
6323
6324
6325
6326
6327
6328
6329 021356 005777 157746
6330 021362 001422
6331 021364 013737 001330 001162
6332 021372 017737 157732 001164
6333 021400 000207
6334
6335
6336
6337
6338
6339
6340 021402 022777 000200 157722
6341 021410 001407
6342 021412 013737 001332 001162
6343 021420 017737 157706 001164
6344 021426 000207
6345
6346 021430 062716 000002
6347 021434 000207
6348
6349

.SBTTL CHKWC: CHECK IF RKWC OVERFLOWED

```

;CHKWC
;THIS ROUTINE CHECKS IF RKWC OVERFLOWED TO 0. IF IT DID A RETURN IS MADE
;TO SKIP THE ERROR MESSAGE. IF NOT, THE CONTENTS OF RKWC AND RKDA ARE SAVED
;AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
CHKWC: TST @RKWC ;DID WORD COUNT OVERFLOW TO 0?
        BEQ CRETRN ;IF YES, BRANCH
        ;IF NOT, ERROR
        MOV @RKWC,$REGO ;GET RKWC
        MOV @RKDA,$REG1 ;GET RKDA
        RTS PC ;RETURN TO THE ERROR MESSAGE
    
```

.SBTTL CHKER: CHECK RKER CONTENTS

```

;CHKER
;THIS ROUTINE CHECKS IF ANY BIT IN RKER SET. IF NOT RETURN IS MADE TO SKIP
;THE ERROR MESSAGE. IF ANY BIT IS SET THE CONTENTS OF RKCS, RKER, RKDS ARE
;SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE.
CHKER: TST @RKER ;DID ANY BIT IN RKER SET?
        BEQ CRETRN ;NO, BRANCH
        ;YES, ERROR
        JSR PC,GT3RG ;GO, GET RKCS, ER, DS
        RTS PC ;RETURN TO THE ERROR MESSAGE
    
```

```

;CHKECLR
;THIS ROUTINE CHECKS THAT RKER IS CLEAR. IF NOT, THE CONTENTS OF RKER
;ARE SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE "JSR"
;CALL. IF RKER IS CLEAR THE ERROR MESSAGE IS SKIPPED ON RETURN.
    
```

```

CHKECLR: TST @RKER ;ANY BIT IN RKER SET?
          BEQ CRETRN ;NO
          MOV RKER,$REGO ;GET ADRES OF RKER
          MOV @RKER,$REG1 ;GET CONTENTS OF RKER
          RTS PC ;RETURN TO THE ERROR MESSAGE
    
```

```

;CHKCCLR
;THIS ROUTINE CHECKS THAT RKCS IS CLEAR. IF NOT, THE CONTENTS OF RKCS ARE
;SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE. IF RKCS IS CLEAR THE
;ERROR MESSAGE IS SKIPPED ON RETURN.
    
```

```

CHKCCLR: CMP #200,@RKCS ;IS RKCS CLEAR?
          BEQ CRETRN ;YES
          MOV RKCS,$REGO ;SAVE ADRES OF RKCS
          MOV @RKCS,$REG1 ;SAVE THE CONTENT OF RKCS
          RTS PC ;RETURN TO THE ERROR MESSAGE
    
```

```

CRETRN: ADD #2,(SP) ;SKIP ERROR MESSAGE ON
         RTS PC ;RETURN
    
```



```

6350          .SBTTL TSTRWS: WAIT FOR R/W/S RDY ROUTINE
6351
6352          :TSTRWS
6353          :THIS ROUTINE WAITS FOR R/W/S RDY TO SET. WHEN IT SETS, THE RETURN PC
6354          :IS INCREMENTED SO THAT ON RETURN (TO THE MAIN PROGRAM) THE ERROR
6355          :MESSAGE FOLLOWING THE 'JSR' CALL IS SKIPPED. IF R/W/S RDY DOES NOT SET
6356          :THEN A RETURN IS MADE TO THE ERROR MESSAGE (FOLLOWING THE 'JSR' CALL).
6357          :WAITING TIME IS APPROX. 1040 MS FOR 11/20, APPROX. 208 MS FOR 11/45
6358          :CALL: JSR TSTRWS
6359
6360 021436 013777 001350 157674 TSTRWS: MOV DRIVAD,@RKDA ;ADRES THE DRIVE
6361 021444 005037 001366          CLR TIMER ;INITIALIZE COUNT
6362 021450 032777 000100 157650 1$: BIT #100,@RKDS ;DID R/W/S RDY SET?
6363 021456 001007          BNE 2$ ;YES, BRANCH
6364 021460 005237 001366          INC TIMER ;WAIT FOR R/W/S RDY
6365 021464 001371          BNE 1$ ;ERROR IF IT'S NOT SET BY NOW
6366 021466 017737 157634 001162 MOV @RKDS,$REGO ;GET RKDS
6367 021474 000207          RTS PC ;EXIT (TO ERROR FOOLOWING 'JSR TSTRWS')
6368
6369 021476 062716 000002          2$: ADD #2,(SP) ;ADJUST RETURN ADRES TO SKIP OVER
6370          ;ERROR (FOLLOWING 'JSR TSTRWS')
6371 021502 000207          RTS PC ;EXIT
6372
6373
6374
6375
6376
6377
6378
6379

```

.SBTTL DRESET: DRIVE RESET ROUTINE

```

6380          :DRESET
6381          :THIS ROUTINE DOES A DRIVE RESET ON THE DRIVE WHOOSE ADDRESS IS IN
6382          :RKDA. MULTIPLE RETURN ADDRESSES FOR THIS ROUTINE ARE PROVIDED.
6383          :IF THERE IS NO ERROR (R/W/S RDY SETS WITHIN CERTAIN TIME) , THEN BEFORE
6384          :EXITNG FROM THIS ROUTINE THE RETURN ADDRESS IS INCREMENTED BY 2, TO SKIP
6385          :THE ERROR MESSAGE ON RETURN. IF THERE IS AN ERROR, THE 3 REGISTERS (CS,ER,DS)
6386          :ARE STORED AND THEN A NORMAL EXIT IS MADE FROM THIS ROUTINE TO THE
6387          :ERROR MESSAGE FOLLOWING THE CALL FOR THIS ROUTINE.
6388          :CALL: JSR PC,DRESET
6389
6390 021504 005037 001364          DRESET: CLR COUNT1 ;INITIALIZE THE COUNT
6391 021510 013777 001350 157622 MOV DRIVAD,@RKDA ;ADRES THE DRIVE
6392 021516 012777 000015 157606 MOV #15,@RKCS ;DRIVE RESET, GO
6393 021524 104414          CNT.RDY ;THIS IS A CALL FOR 'CN.RDY'
6394          ;ROUTINE WHICH WAITS FOR CNT
6395          ;RDY TO SET. IF CNTRL RDY DOES
6396          ;NOT SET WITHIN 883 MS/ 11-20
6397          ;(176 MS FOR 11-45 WITH BIPOLAR)
6398          ;AN ERROR IS REPORTED
6399 021526 032777 000100 157572 1$: BIT #100,@RKDS ;DID R/W/S RDY SET?
6400 021534 001013          BNE 2$
6401 021536 012746 177770          MOV #-10,-(SP) ;PUSH COUNT ON SP
6402 021542 005216          INC (SP) ;COUNT IT DOWN
6403 021544 001376          BNE .-2
6404 021546 005726          TST (SP)+ ;POP UP $P
6405 021550 005237 001364          INC COUNT1 ;IF NOT WAIT

```

6406 021554 001364
6407 021556 004737 020774
6408 021562 000402
6409 021564 062716 000002
6410 021570 000207

BNE 1\$;WAITED LONG?
JSR PC,GT4RG
BR 2\$+4
2\$: ADD #2,@R6
RTS PC

6411
6412
6413
6414

.SBTTL TSTSIN: CHECK 'SIN' ROUTINE

6415
6416
6417

:TSTSIN
:THIS ROUTINE CHECKS IF 'SIN' IS SET, IF IT IS SET A
:DRIVE RESET IS DONE TO CLEAR 'SIN' AND INITIALIZE POSITIONER.
:CALL: TST.SIN
:IF ON DOING DRIVE RESET R/W/S RDY DOES NOT SET A MESSAGE
: ERROR PC=XXXXXX IS GIVEN.
:XXXXXX=PC IN THE MAIN PROGRAM WHERE 'TST.SIN' CALL IS LOCATED.

6418
6419
6420
6421

6422
6423
6424

6425 021572 013777 001350 157540
6426 021600 032777 001000 157520
6427 021606 001403

TSTSIN: MOV DRIVAD,@RKDA ;ADRES THE DRIVE
BIT #1000,@RKDS ;IS SIN SET?
BEQ 1\$
JSR PC,DRESET ;GO DO DRIVE RESET, SIN SET
BR 2\$;REPORT ERROR
1\$: RTI
2\$: BIT #SW13,@SWR ;INHIBIT TYPEOUT?
BNE 1\$;IF YES, SKIP TYPEOUT
TYPE ,65\$;;TYPE ASCIZ STRING
BR 64\$;;GET OVER THE ASCIZ
::65\$: .ASCIZ /ERROR PC= /
64\$: MOV (SP),-(SP)
ADD #-2,(SP) ;GET THE PC WHERE 'TST.SIN' IS LOCATED
TYPOC ;GO TYPE OUT PC
BR 1\$

6428 021610 004737 021504
6429 021614 000401
6430 021616 000002

6431 021620 032777 020000 157312
6432 021626 001373
6433 021630 104401 021636
6434 021634 000406

6435
6436 021652
6437 021652 011646

6438 021654 062716 177776
6439 021660 104402
6440 021662 000755

6441
6442
6443
6444

.SBTTL DELAY: TIME DELAY ROUTINE

6445
6446
6447

:DELAY
:THIS ROUTINE PROVIDES A VARIABLE TIME DELAY. THE CALL FOR THIS
:ROUTINE IS AN ENCODED 'TRAP' INSTRUCTION.
:CALL: DELAY ,N N IS ANY OCTAL NO. FROM 1 TO 177777
:THE DELAY PROVIDED IS 7.5N US (CONVERT N TO DECIMAL) FOR 11/20
:1.5N US FOR 11/45
:IF THE USER WANTS TO CHANGE THE DELAY TIME (EXMP: SHORTER DELAY TO
:GET A TIGHTER SCOPE LOOP) THE VARIABLE 'N' FOLLOWING 'DELAY' SHOULD
:BE CHANGED TO SUIT THE INDIVIDUAL NEED.

6448
6449
6450
6451

6452
6453
6454
6455

6456 021664 017637 000000 001366
6457 021672 062716 000002

DELA.Y: MOV @(SP),TIMER ;GET 'AMOUNT' (N) FOR WHICH
ADD #2,(SP) ;DELAY IS TO BE PROVIDED
;ADJUST STACK POINTER TO SKIP OVER 'N'
1\$: DEC TIMER ;COUNT DOWN TO 0
BNE 1\$

6458
6459 021676 005337 001366
6460 021702 001375

6461


```
6462 021704 000002          RTI          ;RETURN TO MAIN PROGRAM
6463
6464
6465
6466
6467          .SBTTL  WAT.INT:          WAIT FOR INTERRUPT ROUTINE
6468
6469          ;WAT.INT
6470          ;THIS ROUTINE PROVIDES A VARIABLE TIME WAIT LOOP DURING WHICH AN INTERRUPT
6471          ;FROM RK11 CAN OCCUR. THE CALL IS AN ENCODED 'TRAP' INSTRUCTION.
6472
6473          ;CALL:          WAT.INT ,N          N IS ANY OCTAL NO. FROM 1 TO 177777
6474
6475          ;WAIT LOOP TIME= APPROX. 7.5N US (CONVERT N TO DECIMAL) FOR 11/20
6476          ;APPROX. 1.5N US FOR 11/45
6477          ;UPON ENTERING THE ROUTINE THE CPU PRIORITY IS DROPPED SO THAT
6478          ;RK11 CAN INTERRUPT. NOTE THAT WHEN RK11 INTERRUPTS THIS ROUTINE
6479          ;IS EXITED WITHOUT POPPING THE STACK, THIS POPPING IS DONE AFTER GETTING
6480          ;TO RK11 INTERRUPT HANDLER.
6481          ;IF FOR ANY REASON THE WAIT LOOP TIME HAS TO BE CHANGED IT CAN BE DONE
6482          ;BY SIMPLY CHANGING THE VARIABLE 'N' FOLLOWING THE 'WAT.INT'.
6483
6484 021706 017637 000000 001366 WATINT: MOV      @ (SP),TIMER      ;GET 'AMOUNT' (N) FOR WHICH
6485 021714 062716 000002          ADD      #2,(SP)          ;WAITING IS TO BE DONE
6486          ;ADJUST STACK POINTER FOR CORRECT RETURN
6487 021720 013746 001400          MOV      RKPRI,-(SP)      ;DROP CPU PRIORITY SO THAT RK11 CAN
6488 021724 012746 021732          MOV      #1$,-(SP)      ; INTERRUPT
6489 021730 000002          RTI
6490 021732 005337 001366 1$:      DEC      TIMER          ;WAIT FOR RK11 TO INTERRUPT
6491 021736 001375          BNE      1$
6492          ;IF INTERRUPT HAS NOT OCCURED BY NOW
6493          ;RETURN AND REPORT ERROR
6494 021740 000002          RTI          ;EXIT
6495
6496
6497
6498          ;WATIME
6499
6500 021742 005000 WATIME: CLR      R0
6501 021744 005001          CLR      R1
6502 021746 005200 1$:      INC      R0
6503 021750 001376          BNE      1$
6504 021752 105201          INCB    R1
6505 021754 001374          BNE      1$
6506 021756 000207          RTS      PC
6507
6508
6509          .SBTTL  CHKCRDY:          CHECK CONTROL READY
6510
6511          ;;CH.CRDY
6512          ;THIS ROUTINE WAITS FOR THE CONTROL READY TO SET. IF THE CONTROL READY BIT
6513          ;DOES NOT SET WITHIN A CERTAIN TIME, THEN THE CONTENTS OF RKCS, RKER, RKDS
6514          ;AND RKDA ARE SAVED AND AN EXIT MADE TO THE ERROR MESSAGE FOLLOWING THE
6515          ;'JSR' CALL FOR THIS ROUTINE.
6516          ;IF CONTROL READY SETS THEN THE RETURN ADDRESS IS ADJUSTED TO SKIP THE
6517          ;ERROR MESSAGE ON RETURN.
```

6518
6519
6520
6521
6522 021760 005037 001366
6523 021764 105777 157342
6524 021770 100406
6525 021772 005237 001366
6526 021776 001372
6527 022000 004737 020774
6528 022004 000002
6529
6530 022006 062716 000002
6531 022012 000002
6532
6533
6534
6535
6536
6537
6538
6539
6540
6541
6542
6543
6544
6545
6546
6547
6548
6549
6550
6551
6552
6553
6554
6555
6556
6557
6558
6559 022014 012777 000001 157310
6560 022022 012737 177500 001170
6561 022030 000402
6562 022032 005037 001170
6563 022036 105777 157270
6564 022042 100435
6565 022044 005237 001170
6566 022050 001372
6567 022052 032777 020000 157060
6568 022060 001026
6569 022062 104401
6570 022064 001245
6571 022066 104401 022074
6572 022072 000403
6573

```
;CALL: CHKCRDY  
;      ERROR      ;RETURN HERE IF ERROR  
;      ---        ;RETURN HERE IF NO ERROR  
  
CH.CRDY: CLR TIMER  
1$:      TSTB      @RKCS      ;CNTRL RDY SET?  
          BMI      2$          ;YES  
          INC      TIMER  
          BNE      1$          ;NO, WAIT  
          JSR      PC,GT4RG    ;SAVE RKCS, ER, DS, DA  
          RTI  
  
2$:      ADD      #2,(SP)      ;ADJUST RETURN ADDRESS TO  
          RTI                  ;SKIP ERROR MESSAGE ON RETURN  
  
          .SBTTL  CON.RESET:    CONTROL REST ROUTINE  
  
;CON.RESET  
;THIS ROUTINE ISSUES A CONTROL RESET AND WAITS FOR  
;THE 'CNTRL RDY' FLAG TO SET. WHEN THE FLAG SETS  
;AN EXIT IS MADE OUT OF THE ROUTINE. IF 'CNTRL-RDY'  
;DOES NOT SET WITHIN A CERTAIN TIME AN ERROR MESSAGE  
;      CNT RDY DIDN'T SET  
;      PC=XXXXXX RKCS=YYYYYY  
;IS GIVEN. NOTE THAT XXXXXX IS THE PC WHERE 'CNT.RESET' OR 'CNT.RDY'  
;IS CALLED.  
  
;CALL: CNT.RESET  
  
          .SBTTL  CNT.RDY:     WAIT FOR CONTROL READY ROUTINE  
  
;CN.RDY  
;THIS ROUTINE WAITS FOR THE CONTROL READY BIT TO SET AND WHEN IT  
;SETS EXITS OUT. IF WITHIN A CERTAIN TIME CNTRL RDY DOES  
;NOT SET AN ERROR IS REPORTED. WAITING TIME IS 883 MS FOR 11/20  
;175 MS FOR 11/45 WITH BIPOLAR MEMORY.  
;CALL: CNT.RDY  
CN.RST:  MOV      #1,@RKCS      ;ISSUE A CONTROL RESET  
          MOV      #-300,$REG3   ;SET UP COUNT  
          BR       CN.RDY+4      ;SKIP OVER CN.RDY  
  
CN.RDY:  CLR      $REG3  
1$:      TSTB      @RKCS      ;DID CNTRL-RDY SET?  
          BMI      3$          ;YES, EXIT  
          INC      $REG3        ;WAITED LONG?  
          BNE      1$          ;IF NOT, GO BAK & WAIT  
2$:      BIT      #SW13,@SWR    ;INHIBIT TYPEOUT?  
          BNE      3$          ;IF YES, SKIP TYPEOUT  
          TYPE  
          MSG3  
          TYPE      ,65$        ;;TYPE ASCIZ STRING  
          BR       64$          ;;GET OVER THE ASCIZ  
;;65$:  .ASCIZ  <15><12>/PC=/
```


6574 022102
6575 022102 011646
6576 022104 162716 000002
6577 022110 104402
6578
6579 022112 104401 022120
6580 022116 000404
6581
6582 022130
6583 022130 017746 157176
6584 022134 104402
6585
6586 022136 000002
6587
6588
6589
6590
6591
6592
6593
6594
6595
6596
6597
6598
6599
6600
6601
6602
6603
6604
6605
6606
6607
6608
6609 022140
6610 022140 104407
6611 022142 032777 040000 156770
6612 022150 001111
6613
6614 022152 000416
6615
6616 022154 013746 000004
6617 022160 012737 022200 000004
6618 022166 005737 177060
6619 022172 012637 000004
6620 022176 000463
6621 022200 022626
6622 022202 012637 000004
6623 022206 000423
6624 022210
6625 022210 032777 000400 156722
6626 022216 001404
6627 022220 127737 156714 001102
6628 022226 001462
6629 022230 105737 001103

```
64$:  MOV    (SP),-(SP)
      SUB    #2,(SP)
      TYPOC                ;GO TYPE PC IN THE MAIN PROGRAM,
                          ; WHERE ERROR OCCURRED
      TYPE    ,67$        ;;TYPE ASCIZ STRING
      BR     66$          ;;GET OVER THE ASCIZ
;;67$: .ASCIZ / RKCS=/
66$:  MOV    @RKCS,-(SP)   ;GET RKCS
      TYPOC                ;GO TYPE IT
3$:   RTI                  ;RETURN FROM THIS
                          ;ROUTINE TO THE MAIN
                          ;PROGRAM

;THIS PART OF THE PROGRAM CONTAINS THE COMMON ROUTINES CALLED
;FROM THE SYSMAC.SML PACKAGE
;
.SBTTL  SCOPE HANDLER ROUTINE

;*****
;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;*SW14=1      LOOP ON TEST
;*SW11=1      INHIBIT ITERATIONS
;*SW09=1      LOOP ON ERROR
;*SW08=1      LOOP ON TEST IN SWR<7:0>
;*CALL
;*          SCOPE          ;;SCOPE=IOT

$SCOPE:
1$:   CKSWR                ;;TEST FOR CHANGE IN SOFT-SWR
      BIT    #BIT14,@SWR   ;;LOOP ON PRESENT TEST?
      BNE    $OVER        ;;YES IF SW14=1
;#####START OF CODE FOR THE XOR TESTER#####
$XTSTR: BR    6$          ;;IF RUNNING ON THE "XOR" TESTER CHANGE
                          ;;THIS INSTRUCTION TO A "NOP" (NOP=240)
                          ;;SAVE THE CONTENTS OF THE ERROR VECTOR
      MOV    @#ERRVEC,-(SP) ;;SET FOR TIMEOUT
      MOV    #5$,@#ERRVEC  ;;TIME OUT ON XOR?
      TST   @#177060       ;;RESTORE THE ERROR VECTOR
      MOV    (SP)+,@#ERRVEC ;;GO TO THE NEXT TEST
      BR    $$VLAD         ;;CLEAR THE STACK AFTER A TIME OUT
5$:   CMP    (SP)+,(SP)+   ;;RESTORE THE ERROR VECTOR
      MOV    (SP)+,@#ERRVEC ;;LOOP ON THE PRESENT TEST
      BR    7$            ;#####END OF CODE FOR THE XOR TESTER#####
6$:   BIT    #BIT08,@SWR   ;;LOOP ON SPEC. TEST?
      BEQ    2$           ;;BR IF NO
      CMPB  @SWR,$STNM    ;;ON THE RIGHT TEST? SWR<7:0>
      BEQ    $OVER        ;;BR IF YES
2$:   TSTB   $ERFLG       ;;HAS AN ERROR OCCURRED?
```

```

6630 022234 001421          BEQ      3$          ;;BR IF NO
6631 022236 123737 001115 001103  CMPB    $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?
6632 022244 101015          BHI     3$          ;;BR IF NO
6633 022246 032777 001000 156664  BIT     #BIT09,@SWR   ;;LOOP ON ERROR?
6634 022254 001404          BEQ     4$          ;;BR IF NO
6635 022256 013737 001110 001106 7$:    MOV     $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
6636 022264 000443          BR      $OVER
6637 022266 105037 001103          4$:    CLRB   $ERFLG      ;;ZERO THE ERROR FLAG
6638 022272 005037 001206          CLR     $TIMES      ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
6639 022276 000415          BR      1$          ;;ESCAPE TO THE NEXT TEST
6640 022300 032777 004000 156632 3$:    BIT     #BIT11,@SWR  ;;INHIBIT ITERATIONS?
6641 022306 001011          BNE     1$          ;;BR IF YES
6642 022310 005737 001100          TST     $PASS       ;;IF FIRST PASS OF PROGRAM
6643 022314 001406          BEQ     1$          ;;      INHIBIT ITERATIONS
6644 022316 005237 001104          INC     $ICNT       ;;INCREMENT ITERATION COUNT
6645 022322 023737 001206 001104  CMP     $TIMES,$ICNT ;;CHECK THE NUMBER OF ITERATIONS MADE
6646 022330 002021          BGE     $OVER       ;;BR IF MORE ITERATION REQUIRED
6647 022332 012737 000001 001104 1$:    MOV     #1,$ICNT    ;;REINITIALIZE THE ITERATION COUNTER
6648 022340 013737 022410 001206  MOV     $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
6649 022346 105237 001102          $SVLAD: INCB   $TSTNM    ;;COUNT TEST NUMBERS
6650 022352 011637 001106          MOV     (SP),$LPADR ;;SAVE SCOPE LOOP ADDRESS
6651 022356 011637 001110          MOV     (SP),$LPERR ;;SAVE ERROR LOOP ADDRESS
6652 022362 005037 001210          CLR     $ESCAPE     ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
6653 022366 112737 000001 001115  MOVB    #1,$ERMAX    ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
6654 022374 013777 001102 156540 $OVER: MOV     $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER
6655 022402 013716 001106          MOV     $LPADR,(SP) ;;FUDGE RETURN ADDRESS
6656 022406 000002          RTI
6657 022410 000050          $MXCNT: 50          ;;MAX. NUMBER OF ITERATIONS
6658
6659
6660      ;;*****
6661
6662      .SBTTL  ERROR HANDLER ROUTINE
6663
6664      ;*SW15=1      HALT ON ERROR
6665      ;*SW13=1      INHIBIT ERROR TYPEOUTS
6666      ;*SW10=1      TESTING ON SIMULATOR
6667      ;*SW09=1      LOOP ON ERROR
6668      ;*SW12=1      CYCLE ON ERROR TO PREVIOUS 'SCOPE'
6669      ;*SW06=1      DROP DRIVE AFTER MAXIMUM (ALLOWABLE) ERRORS ON THE DRIVE
6670      ;*GO TO $ERRTYP ON ERROR
6671
6672 022412 104407          $ERROR: CKSWR      ;CHECK FOR SOFTWARE SWITCH REGISTER REQUEST
6673 022414 105237 001103 7$:    INCB   $ERFLG      ;SET THE ERROR FLAG
6674 022420 001775          BEQ     7$          ;DON'T LET THE FLAG GO TO ZERO
6675 022422 013777 001102 156512  MOV     $TSTNM,@DISPLAY ;DISPLAY TEST NUMBER AND ERROR FLAG
6676 022430 005237 001112 1$:    INC     $ERTTL     ;COUNT THE NUMBER OF ERRORS
6677
6678 022434 032777 000100 156476  BIT     #BIT6,@SWR   ;DESELECT DRIVE SW SET?
6679 022442 001404          BEQ     6$          ;NO
6680 022444 023727 001112 000005  CMP     $ERTTL,#5    ;MORE THAN 5 ERRORS ON THIS DRIVE?
6681 022452 101053          BHI     8$          ;YES, DESELCT THE DRIVE
6682
6683 022454 011637 001116 6$:    MOV     (SP),$ERRPC ;GET ADDRESS OF ERROR INSTRUCTION
6684 022460 162737 000002 001116  SUB     #2,$ERRPC
6685 022466 117737 156424 001114  MOVB   @ $ERRPC,$ITEMB ;STRIP AND SAVE THE ERROR ITEM CODE
    
```



```

6686 022474 032777 020000 156436 BIT #SW13,@SWR ;SKIP TYPEOUT IF SET
6687 022502 001004 BNE 2$ ;SKIP TYPEOUTS
6688 022504 004737 022734 JSR PC,@$ERRRYP ;GO TO USER ERROR ROUTINE
6689 022510 104401 001213 TYPE ,SCRLF
6690 022514 023737 000042 000046 2$: CMP @#42,@#46 ;ARE WE IN ACT11 AUTO MODE?
6691 022522 001403 BEQ .+10 ;YES, HALT ON ERROR
6692 022524 005777 156410 TST @SWR ;HALT ON ERROR?
6693 022530 100002 BPL 3$ ;SKIP IF CONTINUE
6694 022532 000000 HALT ;HALT ON ERROR!
6695 022534 104407 CKSWR ;CHECK FOR SOFTWARE SWITCH REGIATER REQUEST
6696 022536 032777 010000 156374 3$: BIT #SW12,@SWR ;SW 12 SET?
6697 022544 001402 BEQ .+6 ;NO, BRANCH
6698 022546 013716 001106 MOV $LPADR,(SP) ;ADJUST RETURN ADRES FOR SW12
6699 022552 032777 001000 156360 BIT #SW09,@SWR ;LOOP ON ERROR SWITCH SET?
6700 022560 001402 BEQ 4$ ;BR IF NO
6701 022562 013716 001110 MOV $LPERR,(SP) ;FUDGE RETURN FOR LOOPING
6702 022566 005737 001210 4$: TST $ESCAPE ;CHECK FOR AN ESCAPE ADDRESS
6703 022572 001402 BEQ 5$ ;BR IF NONE
6704 022574 013716 001210 MOV $ESCAPE,(SP) ;FUDGE RETURN ADDRESS FOR ESCAPE
6705 022600 000002 5$: RTI ;RETURN
6706
6707 022602 005737 001434 8$: TST T56FLG ;IF EROR WAS IN LAST TEST (POLL)
6708 ;DROP ALL THE DRIVES
6709 022606 001407 BEQ 10$
6710 022610 104401 001303 TYPE ,MSG5
6711 022614 005037 001412 CLR DRIVS
6712 022620 022626 CMP (SP)+,(SP)+
6713 022622 000137 020652 JMP $EOP
6714 022626 013746 001354 10$: MOV DRVPTR,-(SP) ;DROP THE DRIVE FROM THE
6715 022632 162716 000002 SUB #2,(SP) ;SELECTION LIST
6716 022636 013746 001350 MOV DRIVAD,-(SP) ;DRIVE ADDR TO STACK
6717 022642 004737 021200 JSR PC,$HFTRT ;RIGHT JUSTIFY
6718 022646 042716 000001 BIC #1,(R6) ;MAKE EVEN
6719 022652 062716 001414 ADD #DRIV0,(SP) ;POINTS TO TABLE FOR EVEN DRIVE
6720 022656 042776 100000 000000 BIC #BIT15,@(R6) ;TEST REMAINING DRIVE AS RK05E
6721 022664 062716 000002 ADD #2,(R6) ;POINT TO ODD
6722 022670 042736 100000 BIC #BIT15,@(SP)+ ;TEST AS RK-05E
6723 022674 012736 010000 MOV #BIT12,@(SP)+ ;INDICATE THIS DRIVE DROPPED
6724 022700 104401 001272 TYPE ,MSG4
6725 022704 013746 001350 MOV DRIVAD,-(R6) ;PUSH DRIVE # ON STACK
6726 022710 004737 021200 JSR PC,$HFTRT ;SHIFT IT BEFORE TYPING
6727 022714 104402 TYPOC ;TYPE OUT DRIVE #
6728 022716 104401 001315 TYPE ,MSG6
6729 022722 005337 001412 DEC DRIVS ;DECREMENT # OF DRIVES PRESNT
6730 022726 022626 9$: CMP (SP)+,(SP)+ ;RESTORE STACK
6731 022730 000137 020026 JMP BTEOP ;GO BACK TO THE END OF PROGRM
6732 ;LINKAGE.
6733
6734 .SBTTL ERROR MESSAGE TYPEOUT ROUTINE
6735
6736 ;*****
6737 ;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
6738 ;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
6739 ;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
6740
6741 $ERRRYP:
    
```

6742	022734	104401	001213		TYPE	,\$CR LF	::"CARRIAGE RETURN" & "LINE FEED"
6743	022740	010046			MOV	RO,-(SP)	::SAVE RO
6744	022742	005000			CLR	RO	::PICKUP THE ITEM INDEX
6745	022744	153700	001114		BISB	@#\$ITEMB,RO	
6746	022750	001004			BNE	1\$::IF ITEM NUMBER IS ZERO, JUST
6747							::TYPE THE PC OF THE ERROR
6748	022752	013746	001116		MOV	\$ERRPC,-(SP)	::SAVE \$ERRPC FOR TYPEOUT
6749							::ERROR ADDRESS
6750	022756	104402			TYP0C		::GO TYPE--OCTAL ASCII(ALL DIGITS)
6751	022760	000426			BR	6\$::GET OUT
6752	022762	005300		1\$:	DEC	RO	::ADJUST THE INDEX SO THAT IT WILL
6753	022764	006300			ASL	RO	::
6754	022766	006300			ASL	RO	WORK FOR THE ERROR TABLE
6755	022770	006300			ASL	RO	
6756	022772	062700	001442		ADD	#\$ERRTB,RO	::FORM TABLE POINTER
6757	022776	012037	023006		MOV	(RO)+,2\$::PICKUP "ERROR MESSAGE" POINTER
6758	023002	001404			BEQ	3\$::SKIP TYPEOUT IF NO POINTER
6759	023004	104401			TYPE		::TYPE THE "ERROR MESSAGE"
6760	023006	000000		2\$:	.WORD	0	::"ERROR MESSAGE" POINTER GOES HERE
6761	023010	104401	001213		TYPE	,\$CR LF	::"CARRIAGE RETURN" & "LINE FEED"
6762	023014	012037	023024	3\$:	MOV	(RO)+,4\$::PICKUP "DATA HEADER" POINTER
6763	023020	001404			BEQ	5\$::SKIP TYPEOUT IF 0
6764	023022	104401			TYPE		::TYPE THE "DATA HEADER"
6765	023024	000000		4\$:	.WORD	0	::"DATA HEADER" POINTER GOES HERE
6766	023026	104401	001213		TYPE	,\$CR LF	::"CARRIAGE RETURN" & "LINE FEED"
6767	023032	011000		5\$:	MOV	(RO),RO	::PICKUP "DATA TABLE" POINTER
6768	023034	001004			BNE	7\$::GO TYPE THE DATA
6769	023036	012600		6\$:	MOV	(SP)+,RO	::RESTORE RO
6770	023040	104401	001213		TYPE	,\$CR LF	::"CARRIAGE RETURN" & "LINE FEED"
6771	023044	000207			RTS	PC	::RETURN
6772	023046			7\$:			
6773	023046	013046			MOV	@(RO)+,-(SP)	::SAVE @(RO)+ FOR TYPEOUT
6774	023050	104402			TYP0C		::GO TYPE--OCTAL ASCII(ALL DIGITS)
6775	023052	005710			TST	(RO)	::IS THERE ANOTHER NUMBER?
6776	023054	001770			BEQ	6\$::BR IF NO
6777	023056	104401	023064		TYPE	,8\$::TYPE TWO(2) SPACES
6778	023062	000771			BR	7\$::LOOP
6779	023064	020040	000	8\$:	.ASCIZ	/ /	::TWO(2) SPACES
6780		023070			.EVEN		

.SBTTL TYPE ROUTINE

```

*****
;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
;*NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
;*NOTE2:          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
;*NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
;*
;*CALL:
;*1) USING A TRAP INSTRUCTION
;*   TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
;*OR
;*   TYPE
;*   MESADR
;*
```



```

6798
6799 023070 105737 001157 $TYPE: TSTB $TPFLG ;; IS THERE A TERMINAL?
6800 023074 100002 BPL 1$ ;; BR IF YES
6801 023076 000000 HALT ;; HALT HERE IF NO TERMINAL
6802 023100 000407 BR 3$ ;; LEAVE
6803 023102 010046 1$: MOV R0,-(SP) ;; SAVE R0
6804 023104 017600 000002 MOV @2(SP),R0 ;; GET ADDRESS OF ASCIZ STRING
6805 023110 112046 2$: MOVB (R0)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
6806 023112 001005 BNE 4$ ;; BR IF IT ISN'T THE TERMINATOR
6807 023114 005726 TST (SP)+ ;; IF TERMINATOR POP IT OFF THE STACK
6808 023116 012600 60$: MOV (SP)+,R0 ;; RESTORE R0
6809 023120 062716 000002 3$: ADD #2,(SP) ;; ADJUST RETURN PC
6810 023124 000002 RTI ;; RETURN
6811 023126 122716 000011 4$: CMPB #HT,(SP) ;; BRANCH IF <HT>
6812 023132 001430 BEQ 8$
6813 023134 122716 000200 CMPB #CRLF,(SP) ;; BRANCH IF NOT <CRLF>
6814 023140 001006 BNE 5$
6815 023142 005726 TST (SP)+ ;; POP <CR><LF> EQUIV
6816 023144 104401 TYPE ;; TYPE A CR AND LF
6817 023146 001213 $CRLF
6818 023150 105037 023304 CLRB $CHARCNT ;; CLEAR CHARACTER COUNT
6819 023154 000755 BR 2$ ;; GET NEXT CHARACTER
6820 023156 004737 023240 5$: JSR PC,$TYPEC ;; GO TYPE THIS CHARACTER
6821 023162 123726 001156 6$: CMPB $FILLC,(SP)+ ;; IS IT TIME FOR FILLER CHARS.?
6822 023166 001350 BNE 2$ ;; IF NO GO GET NEXT CHAR.
6823 023170 013746 001154 MOV $NULL,-(SP) ;; GET # OF FILLER CHARS. NEEDED
6824 ;; AND THE NULL CHAR.
6825 023174 105366 000001 7$: DECB 1(SP) ;; DOES A NULL NEED TO BE TYPED?
6826 023200 002770 BLT 6$ ;; BR IF NO--GO POP THE NULL OFF OF STACK
6827 023202 004737 023240 JSR PC,$TYPEC ;; GO TYPE A NULL
6828 023206 105337 023304 DECB $CHARCNT ;; DO NOT COUNT AS A COUNT
6829 023212 000770 BR 7$ ;; LOOP
    
```

;HORIZONTAL TAB PROCESSOR

```

6830
6831
6832
6833 023214 112716 000040 8$: MOVB #' ,(SP) ;; REPLACE TAB WITH SPACE
6834 023220 004737 023240 9$: JSR PC,$TYPEC ;; TYPE A SPACE
6835 023224 132737 000007 023304 BITB #7,$CHARCNT ;; BRANCH IF NOT AT
6836 023232 001372 BNE 9$ ;; TAB STOP
6837 023234 005726 TST (SP)+ ;; POP SPACE OFF STACK
6838 023236 000724 BR 2$ ;; GET NEXT CHARACTER
6839 023240 105777 155704 $TYPEC: TSTB @STPS ;; WAIT UNTIL PRINTER IS READY
6840 023244 100375 BPL $TYPEC
6841 023246 116677 000002 155676 MOVB 2(SP),@STPB ;; LOAD CHAR TO BE TYPED INTO DATA REG.
6842 023254 122766 000015 000002 CMPB #CR,2(SP) ;; IS CHARACTER A CARRIAGE RETURN?
6843 023262 001003 BNE 1$ ;; BRANCH IF NO
6844 023264 105037 023304 CLRB $CHARCNT ;; YES--CLEAR CHARACTER COUNT
6845 023270 000406 BR $TYPEX ;; EXIT
6846 023272 122766 000012 000002 1$: CMPB #LF,2(SP) ;; IS CHARACTER A LINE FEED?
6847 023300 001402 BEQ $TYPEX ;; BRANCH IF YES
6848 023302 105227 INCB (PC)+ ;; COUNT THE CHARACTER
6849 023304 000000 $CHARCNT: .WORD 0 ;; CHARACTER COUNT STORAGE
6850 023306 000207 $TYPEX: RTS PC
    
```

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

6851
6852
6853

```

6854
6855
6856
6857
6858
6859
6860
6861
6862
6863
6864
6865 023310
6866 023310 010046
6867 023312 010146
6868 023314 010246
6869 023316 010346
6870 023320 010546
6871 023322 012746 020200
6872 023326 016605 000020
6873 023332 100004
6874 023334 005405
6875 023336 112766 000055 000001
6876 023344 005000
6877 023346 012703 023524
6878 023352 112723 000040
6879 023356 005002
6880 023360 016001 023514
6881 023364 160105
6882 023366 002402
6883 023370 005202
6884 023372 000774
6885 023374 060105
6886 023376 005702
6887 023400 001002
6888 023402 105716
6889 023404 100407
6890 023406 106316
6891 023410 103003
6892 023412 116663 000001 177777
6893 023420 052702 000060
6894 023424 052702 000040
6895 023430 110223
6896 023432 005720
6897 023434 020027 000010
6898 023440 002746
6899 023442 003002
6900 023444 010502
6901 023446 000764
6902 023450 105726
6903 023452 100003
6904 023454 116663 177777 177776
6905 023462 105013
6906 023464 012605
6907 023466 012603
6908 023470 012602
6909 023472 012601

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
*REPLACED WITH SPACES.
*CALL:
*      MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
*      TYPDS                    ;;GO TO THE ROUTINE

$TYPDS:
MOV      R0,-(SP)      ;;PUSH R0 ON STACK
MOV      R1,-(SP)      ;;PUSH R1 ON STACK
MOV      R2,-(SP)      ;;PUSH R2 ON STACK
MOV      R3,-(SP)      ;;PUSH R3 ON STACK
MOV      R5,-(SP)      ;;PUSH R5 ON STACK
MOV      #20200,-(SP)   ;;SET BLANK SWITCH AND SIGN
MOV      20(SP),R5     ;;GET THE INPUT NUMBER
BPL      1$            ;;BR IF INPUT IS POS.
NEG      R5            ;;MAKE THE BINARY NUMBER POS.
MOVB    #'-,1(SP)     ;;MAKE THE ASCII NUMBER NEG.
1$:      CLR      R0            ;;ZERO THE CONSTANTS INDEX
MOV      #SDBLK,R3     ;;SETUP THE OUTPUT POINTER
MOVB    #' ,(R3)+     ;;SET THE FIRST CHARACTER TO A BLANK
2$:      CLR      R2            ;;CLEAR THE BCD NUMBER
MOV      $DTBL(R0),R1  ;;GET THE CONSTANT
3$:      SUB      R1,R5         ;;FORM THIS BCD DIGIT
BLT     4$            ;;BR IF DONE
INC     R2            ;;INCREASE THE BCD DIGIT BY 1
BR      3$
4$:      ADD      R1,R5         ;;ADD BACK THE CONSTANT
TST     R2            ;;CHECK IF BCD DIGIT=0
BNE     5$            ;;FALL THROUGH IF 0
TSTB   (SP)          ;;STILL DOING LEADING 0'S?
BMI     7$            ;;BR IF YES
5$:      ASLB    (SP)          ;;MSD?
BCC     6$            ;;BR IF NO
MOVB   1(SP),-1(R3)   ;;YES--SET THE SIGN
6$:      BIS     #'0,R2        ;;MAKE THE BCD DIGIT ASCII
7$:      BIS     #' ,R2        ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB   R2,(R3)+     ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST    (R0)+        ;;JUST INCREMENTING
CMP    R0,#10       ;;CHECK THE TABLE INDEX
BLT    2$            ;;GO DO THE NEXT DIGIT
BGT    8$            ;;GO TO EXIT
MOV    R5,R2        ;;GET THE LSD
BR     6$            ;;GO CHANGE TO ASCII
8$:      TSTB   (SP)+        ;;WAS THE LSD THE FIRST NON-ZERO?
BPL    9$            ;;BR IF NO
MOVB   -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
9$:      CLRB   (R3)          ;;SET THE TERMINATOR
MOV    (SP)+,R5     ;;POP STACK INTO R5
MOV    (SP)+,R3     ;;POP STACK INTO R3
MOV    (SP)+,R2     ;;POP STACK INTO R2
MOV    (SP)+,R1     ;;POP STACK INTO R1

```


6910 023474 012600
 6911 023476 104401 023524
 6912 023502 016666 000002 000004
 6913 023510 012616
 6914 023512 000002
 6915 023514 023420
 6916 023516 001750
 6917 023520 000144
 6918 023522 000012
 6919 023524 000004
 6920
 6921
 6922
 6923
 6924
 6925
 6926
 6927
 6928
 6929
 6930
 6931
 6932
 6933
 6934
 6935
 6936
 6937
 6938
 6939
 6940
 6941
 6942
 6943
 6944
 6945
 6946 023534 017646 000000
 6947 023540 116637 000001 023757
 6948 023546 112637 023761
 6949 023552 062716 000002
 6950 023556 000406
 6951 023560 112737 000001 023757
 6952 023566 112737 000006 023761
 6953 023574 112737 000005 023756
 6954 023602 010346
 6955 023604 010446
 6956 023606 010546
 6957 023610 113704 023761
 6958 023614 005404
 6959 023616 062704 000006
 6960 023622 110437 023760
 6961 023626 113704 023757
 6962 023632 016605 000012
 6963 023636 005003
 6964 023640 006105
 6965 023642 000404

```

MOV (SP)+,R0      ;;POP STACK INTO R0
TYPE $DBLK        ;;NOW TYPE THE NUMBER
MOV 2(SP),4(SP)  ;;ADJUST THE STACK
MOV (SP)+,(SP)
RTI              ;;RETURN TO USER

$DTBL: 10000.
       1000.
       100.
       10.

$DBLK: .BLKW 4

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS              ;;CALL FOR TYPEOUT
*   .BYTE N            ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE M            ;;M=1 OR 0
*                       ;;1=TYPE LEADING ZEROS
*                       ;;0=SUPPRESS LEADING ZEROS
*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*   MOV NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON              ;;CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC              ;;CALL FOR TYPEOUT

$TYPOS: MOV @ (SP),-(SP) ;;PICKUP THE MODE
        MOV 1(SP),$OFILL ;;LOAD ZERO FILL SWITCH
        MOV (SP)+,$SOMODE+1 ;;NUMBER OF DIGITS TO TYPE
        ADD #2,(SP)      ;;ADJUST RETURN ADDRESS
        BR $TYPON

$TYPOC: MOV #1,$OFILL   ;;SET THE ZERO FILL SWITCH
        MOV #6,$SOMODE+1 ;;SET FOR SIX(6) DIGITS
$TYPON: MOV #5,$OCNT    ;;SET THE ITERATION COUNT
        MOV R3,-(SP)    ;;SAVE R3
        MOV R4,-(SP)    ;;SAVE R4
        MOV R5,-(SP)    ;;SAVE R5
        MOV $SOMODE+1,R4 ;;GET THE NUMBER OF DIGITS TO TYPE
        NEG R4
        ADD #6,R4       ;;SUBTRACT IT FOR MAX. ALLOWED
        MOV R4,$SOMODE  ;;SAVE IT FOR USE
        MOV $OFILL,R4   ;;GET THE ZERO FILL SWITCH
        MOV 12(SP),R5   ;;PICKUP THE INPUT NUMBER
        CLR R3          ;;CLEAR THE OUTPUT WORD
        ROL R5          ;;ROTATE MSB INTO 'C'
        BR 3$          ;;GO DO MSB
    
```

6966	023644	006105			2\$:	ROL	R5	::FORM THIS DIGIT
6967	023646	006105				ROL	R5	
6968	023650	006105				ROL	R5	
6969	023652	010503				MOV	R5,R3	
6970	023654	006103			3\$:	ROL	R3	::GET LSB OF THIS DIGIT
6971	023656	105337	023760			DECB	\$OMODE	::TYPE THIS DIGIT?
6972	023662	100016				BPL	7\$::BR IF NO
6973	023664	042703	177770			BIC	#177770,R3	::GET RID OF JUNK
6974	023670	001002				BNE	4\$::TEST FOR 0
6975	023672	005704				TST	R4	::SUPPRESS THIS 0?
6976	023674	001403				BEQ	5\$::BR IF YES
6977	023676	005204			4\$:	INC	R4	::DON'T SUPPRESS ANYMORE 0'S
6978	023700	052703	000060			BIS	#'0,R3	::MAKE THIS DIGIT ASCII
6979	023704	052703	000040		5\$:	BIS	#',R3	::MAKE ASCII IF NOT ALREADY
6980	023710	110337	023754			MOVB	R3,8\$::SAVE FOR TYPING
6981	023714	104401	023754			TYPE	,8\$::GO TYPE THIS DIGIT
6982	023720	105337	023756		7\$:	DECB	\$OCNT	::COUNT BY 1
6983	023724	003347				BGT	2\$::BR IF MORE TO DO
6984	023726	002402				BLT	6\$::BR IF DONE
6985	023730	005204				INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
6986	023732	000744				BR	2\$::GO DO THE LAST DIGIT
6987	023734	012605			6\$:	MOV	(SP)+,R5	::RESTORE R5
6988	023736	012604				MOV	(SP)+,R4	::RESTORE R4
6989	023740	012603				MOV	(SP)+,R3	::RESTORE R3
6990	023742	016666	000002	000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
6991	023750	012616				MOV	(SP)+,(SP)	
6992	023752	000002				RTI		::RETURN
6993	023754	000			8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
6994	023755	000				.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
6995	023756	000			\$OCNT:	.BYTE	0	::OCTAL DIGIT COUNTER
6996	023757	000			\$OFILL:	.BYTE	0	::ZERO FILL SWITCH
6997	023760	000000			\$OMODE:	.WORD	0	::NUMBER OF DIGITS TO TYPE
6998								
6999								
7000								
7001								
7002								
7003								
7004								
7005								
7006								
7007								
7008								
7009	023762	022737	000176	001140	\$CKSWR:	CMP	#SWREG,SWR	::IS THE SOFT-SWR SELECTED?
7010	023770	001074				BNE	15\$::BRANCH IF NO
7011	023772	105777	155146			TSTB	@\$TKS	::CHAR THERE?
7012	023776	100071				BPL	15\$::IF NO, DON'T WAIT AROUND
7013	024000	117746	155142			MOVB	@\$TKB,-(SP)	::SAVE THE CHAR
7014	024004	042716	177600			BIC	#C177,(SP)	::STRIP-OFF THE ASCII
7015	024010	022726	000007			CMP	#7,(SP)+	::IS IT A CONTROL G?
7016	024014	001062				BNE	15\$::NO, RETURN TO USER
7017	024016	123727	001134	000001		CMPB	\$AUTOB,#1	::ARE WE RUNNING IN AUTO-MODE?
7018	024024	001456				BEQ	15\$::BRANCH IF YES
7019								
7020	024026	104401	024647			TYPE	,\$CNTLG	::ECHO THE CONTROL-G (G)
7021	024032	104401	024654		\$GTSWR:	TYPE	,\$MSWR	::TYPE CURRENT CONTENTS

.SBTTL TTY INPUT ROUTINE

::*****

.ENABL LSB

::*****

::*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.

::*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL

::*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL

::*WHEN OPERATING IN TTY FLAG MODE.


```

7022 024036 013746 000176          MOV    SWREG,-(SP)      ;;SAVE SWREG FOR TYPEOUT
7023 024042 104402                   TYP0C                   ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
7024 024044 104401 024665          TYPE    ,SMNEW         ;;PROMPT FOR NEW SWR
7025 024050 005046                   19$: CLR    -(SP)      ;;CLEAR COUNTER
7026 024052 005046                   CLR    -(SP)          ;;THE NEW SWR
7027 024054 105777 155064          7$:  TSTB  @STKS      ;;CHAR THERE?
7028 024060 100375                   BPL    7$             ;;IF NOT TRY AGAIN
7029
7030 024062 117746 155060          MOVB   @STKB,-(SP)    ;;PICK UP CHAR
7031 024066 042716 177600          BIC    # C177,(SP)   ;;MAKE IT 7-BIT ASCII
7032
7033
7034
7035 024072 021627 000025          9$:  CMP    (SP),#25   ;;IS IT A CONTROL-U?
7036 024076 001005                   BNE    10$           ;;BRANCH IF NOT
7037 024100 104401 024642          TYPE    ,SCNTLU      ;;YES, ECHO CONTROL-U ( U)
7038 024104 062706 000006          20$: ADD    #6,SP     ;;IGNORE PREVIOUS INPUT
7039 024110 000757                   BR     19$           ;;LET'S TRY IT AGAIN
7040
7041
7042 024112 021627 000015          10$: CMP    (SP),#15  ;;IS IT A <CR>?
7043 024116 001022                   BNE    16$           ;;BRANCH IF NO
7044 024120 005766 000004          TST    4(SP)         ;;YES, IS IT THE FIRST CHAR?
7045 024124 001403                   BEQ    11$           ;;BRANCH IF YES
7046 024126 016677 000002 155004  MOV    2(SP),@SWR     ;;SAVE NEW SWR
7047 024134 062706 000006          11$: ADD    #6,SP     ;;CLEAR UP STACK
7048 024140 104401 001213          14$: * TYPE    ,SCLF  ;;ECHO <CR> AND <LF>
7049 024144 123727 001135 000001  CMPB   $INTAG,#1     ;;RE-ENABLE TTY KBD INTERRUPTS?
7050 024152 001003                   BNE    15$           ;;BRANCH IF NOT
7051 024154 012777 000100 154762  MOV    #100,@STKS    ;;RE-ENABLE TTY KBD INTERRUPTS
7052 024162 000002                   15$: RTI                    ;;RETURN
7053 024164 004737 023240          16$: JSR    PC,$TYPEC   ;;ECHO CHAR
7054 024170 021627 000060          CMP    (SP),#60     ;;CHAR < 0?
7055 024174 002420                   BLT    18$           ;;BRANCH IF YES
7056 024176 021627 000067          CMP    (SP),#67     ;;CHAR > 7?
7057 024202 003015                   BGT    18$           ;;BRANCH IF YES
7058 024204 042726 000060          BIC    #60,(SP)+    ;;STRIP-OFF ASCII
7059 024210 005766 000002          TST    2(SP)        ;;IS THIS THE FIRST CHAR
7060 024214 001403                   BEQ    17$           ;;BRANCH IF YES
7061 024216 006316                   ASL    (SP)         ;;NO, SHIFT PRESENT
7062 024220 006316                   ASL    (SP)         ;; CHAR OVER TO MAKE
7063 024222 006316                   ASL    (SP)         ;; ROOM FOR NEW ONE.
7064 024224 005266 000002          17$: INC    2(SP)     ;;KEEP COUNT OF CHAR
7065 024230 056616 177776          BIS    -2(SP),(SP)  ;;SET IN NEW CHAR
7066 024234 000707                   BR     7$           ;;GET THE NEXT ONE
7067 024236 104401 001212          18$: TYPE    ,SQUES   ;;TYPE ?<CR><LF>
7068 024242 000720                   BR     20$         ;;SIMULATE CONTROL-U
7069 .DSABL  LSB
7070
7071
7072 *****
7073 ;*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
7074 ;*CALL:
7075 ;*   RDCHR          ;;INPUT A SINGLE CHARACTER FROM THE TTY
7076 ;*   RETURN HERE   ;;CHARACTER IS ON THE STACK
7077 ;*                ;;WITH PARITY BIT STRIPPED OFF
    
```

```

7078 ;
7079 ;
7080 024244 011646 $RDCHR: MOV (SP),-(SP) ;;PUSH DOWN THE PC
7081 024246 016666 000004 000002 MOV 4(SP),2(SP) ;;SAVE THE PS
7082 024254 105777 154664 1$: TSTB @STKS ;;WAIT FOR
7083 024260 100375 BPL 1$ ;;A CHARACTER
7084 024262 117766 154660 000004 MOVB @STKB,4(SP) ;;READ THE TTY
7085 024270 042766 177600 000004 BIC # C<177>,4(SP) ;;GET RID OF JUNK IF ANY
7086 024276 026627 000004 000023 CMP 4(SP),#23 ;;IS IT A CONTROL-S?
7087 024304 001013 BNE 3$ ;;BRANCH IF NO
7088 024306 105777 154632 2$: TSTB @STKS ;;WAIT FOR A CHARACTER
7089 024312 100375 BPL 2$ ;;LOOP UNTIL ITS THERE
7090 024314 117746 154626 MOVB @STKB,-(SP) ;;GET CHARACTER
7091 024320 042716 177600 BIC # C177,(SP) ;;MAKE IT 7-BIT ASCII
7092 024324 022627 000021 CMP (SP)+,#21 ;;IS IT A CONTROL-Q?
7093 024330 001366 BNE 2$ ;;IF NOT DISCARD IT
7094 024332 000750 BR 1$ ;;YES, RESUME
7095 024334 026627 000004 000140 3$: CMP 4(SP),#140 ;;IS IT UPPER CASE?
7096 024342 002407 BLT 4$ ;;BRANCH IF YES
7097 024344 026627 000004 000175 CMP 4(SP),#175 ;;IS IT A SPECIAL CHAR?
7098 024352 003003 BGT 4$ ;;BRANCH IF YES
7099 024354 042766 000040 000004 BIC #40,4(SP) ;;MAKE IT UPPER CASE
7100 024362 000002 4$: RTI ;;GO BACK TO USER
7101 ;*****
7102 ;*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
7103 ;*CALL:
7104 ;* RDLIN ;;INPUT A STRING FROM THE TTY
7105 ;* RETURN HERE ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
7106 ;* ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
7107
7108 024364 010346 $RDLIN: MOV R3,-(SP) ;;SAVE R3
7109 024366 005046 CLR -(SP) ;;CLEAR THE RUBOUT KEY
7110 024370 012703 024620 1$: MOV #STTYIN,R3 ;;GET ADDRESS
7111 024374 022703 024642 2$: CMP #STTYIN+22,R3 ;;BUFFER FULL?
7112 024400 101456 BLOS 4$ ;;BR IF YES
7113 024402 104410 RDCHR ;;GO READ ONE CHARACTER FROM THE TTY
7114 024404 112613 MOVB (SP)+,(R3) ;;GET CHARACTER
7115 024406 122713 000177 10$: CMPB #177,(R3) ;;IS IT A RUBOUT
7116 024412 001022 BNE 5$ ;;BR IF NO
7117 024414 005716 TST (SP) ;;IS THIS THE FIRST RUBOUT?
7118 024416 001007 BNE 6$ ;;BR IF NO
7119 024420 112737 000134 024616 MOVB #' ,9$ ;;TYPE A BACK SLASH
7120 024426 104401 024616 TYPE ,9$
7121 024432 012716 177777 MOV #-1,(SP) ;;SET THE RUBOUT KEY
7122 024436 005303 6$: DEC R3 ;;BACKUP BY ONE
7123 024440 020327 024620 CMP R3,#STTYIN ;;STACK EMPTY?
7124 024444 103434 BLO 4$ ;;BR IF YES
7125 024446 111337 024616 MOVB (R3),9$ ;;SETUP TO TYPEOUT THE DELETED CHAR.
7126 024452 104401 024616 TYPE ,9$ ;;GO TYPE
7127 024456 000746 BR 2$ ;;GO READ ANOTHER CHAR.
7128 024460 005716 5$: TST (SP) ;;RUBOUT KEY SET?
7129 024462 001406 BEQ 7$ ;;BR IF NO
7130 024464 112737 000134 024616 MOVB #' ,9$ ;;TYPE A BACK SLASH
7131 024472 104401 024616 TYPE ,9$
7132 024476 005016 CLR (SP) ;;CLEAR THE RUBOUT KEY
7133 024500 122713 000025 7$: CMPB #25,(R3) ;;IS CHARACTER A CTRL U?
    
```



```

7134 024504 001003          BNE      8$          ;;BR IF NO
7135 024506 104401 024642   TYPE     ,SCNTLU    ;;TYPE A CONTROL "U"
7136 024512 000726          BR       1$          ;;GO START OVER
7137 024514 122713 000022   8$:     CMPB     #22,(R3) ;;IS CHARACTER A " R"?
7138 024520 001011          BNE      3$          ;;BRANCH IF NO
7139 024522 105013          CLRB     (R3)        ;;CLEAR THE CHARACTER
7140 024524 104401 001213   TYPE     ,SCRLF     ;;TYPE A "CR" & "LF"
7141 024530 104401 024620   TYPE     ,STTYIN    ;;TYPE THE INPUT STRING
7142 024534 000717          BR       2$          ;;GO PICKUP ANOTHER CHACTER
7143 024536 104401 001212   4$:     TYPE     ,SQUES  ;;TYPE A '?'
7144 024542 000712          BR       1$          ;;CLEAR THE BUFFER AND LOOP
7145 024544 111337 024616   3$:     MOVB     (R3),9$ ;;ECHO THE CHARACTER
7146 024550 104401 024616   TYPE     ,9$
7147 024554 122723 000015   CMPB     #15,(R3)+  ;;CHECK FOR RETURN
7148 024560 001305          BNE      2$          ;;LOOP IF NOT RETURN
7149 024562 105063 177777   CLRB     -1(R3)     ;;CLEAR RETURN (THE 15)
7150 024566 104401 001214   TYPE     ,SLF       ;;TYPE A LINE FEED
7151 024572 005726          TST     (SP)+       ;;CLEAN RUBOUT KEY FROM THE STACK
7152 024574 012603          MOV     (SP)+,R3    ;;RESTORE R3
7153 024576 011646          MOV     (SP),-(SP)  ;;ADJUST THE STACK AND PUT ADDRESS OF THE
7154 024600 016666 000004 000002   MOV     4(SP),2(SP) ;; FIRST ASCII CHARACTER ON IT
7155 024606 012766 024620 000004   MOV     #STTYIN,4(SP)
7156 024614 000002          RTI              ;;RETURN
7157 024616 000          9$:     .BYTE    0          ;;STORAGE FOR ASCII CHAR. TO TYPE
7158 024617 000          .BYTE    0          ;;TERMINATOR
7159 024620 000022          $TTYIN: .BLKB    22      ;;RESERVE 22 BYTES FOR TTY INPUT
7160 024642 052536 005015 000   $CNTLU: .ASCIZ  / U/<15><12> ;;CONTROL "U"
7161 024647 136 006507 000012   $CNTLG: .ASCIZ  / G/<15><12> ;;CONTROL "G"
7162 024654 005015 053523 020122   $MSWR:  .ASCIZ  <15><12>/SWR = /
7163 024662 020075 000
7164 024665 040 047040 053505   $MNEW:  .ASCIZ  / NEW = /
7165 024672 036440 000040
7166                                     ;CONTROL U, RUBOUT CAPABILITY
7167   .SBTTL  TRAP DECODER
7168
7169   ;*****
7170   ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
7171   ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
7172   ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
7173   ;*GO TO THAT ROUTINE.
7174
7175 024676 010046          $TRAP:  MOV     R0,-(SP) ;;SAVE R0
7176 024700 016600 000002   MOV     2(SP),R0     ;;GET TRAP ADDRESS
7177 024704 005740          TST     -(R0)        ;;BACKUP BY 2
7178 024706 111000          MOVB    (R0),R0     ;;GET RIGHT BYTE OF TRAP
7179 024710 006300          ASL     R0           ;;POSITION FOR INDEXING
7180 024712 016000 024732   MOV     $TRPAD(R0),R0 ;;INDEX TO TABLE
7181 024716 000200          RTS     R0          ;;GO TO ROUTINE
7182
7183
7184   ;THIS IS USE TO HANDLE THE "GETPRI" MACRO
7185
7186 024720 011646          $TRAP2: MOV     (SP),-(SP) ;;MOVE THE PC DOWN
7187 024722 016666 000004 000002   MOV     4(SP),2(SP)  ;;MOVE THE PSW DOWN
7188 024730 000002          RTI              ;;RESTORE THE PSW
7189

```

7190
7191
7192
7193
7194
7195
7196
7197 024732 024720
7198 024734 023070
7199 024736 023560
7200 024740 023534
7201 024742 023574
7202 024744 023310
7203
7204 024746 024032
7205
7206 024750 023762
7207 024752 024244
7208 024754 024364
7209
7210 024756 021760
7211
7212 024760 022014
7213
7214 024762 022032
7215
7216 024764 021056
7217
7218 024766 021066
7219
7220 024770 021664
7221
7222 024772 021706
7223
7224 024774 021572
7225
7226
7227
7228
7229
7230
7231 024776 012737 025142 000024
7232 025004 012737 000340 000026
7233 025012 010046
7234 025014 010146
7235 025016 010246
7236 025020 010346
7237 025022 010446
7238 025024 010546
7239 025026 017746 154106
7240 025032 010637 025146
7241 025036 012737 025050 000024
7242 025044 000000
7243 025046 000776
7244
7245

.SBTTL TRAP TABLE

;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
;*BY THE "TRAP" INSTRUCTION.

```
ROUTINE
-----
$TRPAD: .WORD $TRAP2
$TYPE    ;;CALL=TYPE    TRAP+1(104401)  TTY TYPEOUT ROUTINE
$TYPOC   ;;CALL=TYPOC   TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
$TYPOS   ;;CALL=TYPOS   TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
$TYPON   ;;CALL=TYPON   TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
$TYPDS   ;;CALL=TYPDS   TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)

$GTSWR   ;;CALL=GTSWR   TRAP+6(104406)  GET SOFT-SWR SETTING

$CKSWR   ;;CALL=CKSWR   TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
$RDCHR   ;;CALL=RDCHR   TRAP+10(104410)  TTY TYPEIN CHARACTER ROUTINE
$RDLIN   ;;CALL=RDLIN   TRAP+11(104411)  TTY TYPEIN STRING ROUTINE

CH.CRDY  ;;CALL=CHKCRDY TRAP+12(104412)  CHECK CONTROL READY

CN.RST   ;;CALL=CNTR.RESET TRAP+13(104413)  CONTROL RESET ROUTINE

CN.RDY   ;;CALL=CNTR.RDY  TRAP+14(104414)  WAIT FOR CNTRL RDY TO SET

BDA0     ;;CALL=BRKDA0    TRAP+15(104415)  BREAK RKDA INTO DR #,CYL,SUR,SEC BITS

BDA4     ;;CALL=BRKDA4    TRAP+16(104416)  BREAK RKDA INTO DR #,CYL,SUR,SEC BITS

DELA.Y   ;;CALL=DELAY     TRAP+17(104417)  TIME DELAY ROUTINE

WATINT   ;;CALL=WAT.INT   TRAP+20(104420)  WAIT FOR RK11 INTERRUPT ROUTINE

TSTSIN   ;;CALL=TST.SIN   TRAP+21(104421)  TEST SIN ROUTINE
```

.SBTTL POWER DOWN AND UP ROUTINES

```
*****
:POWER DOWN ROUTINE
$PWRDN: MOV    #$ILLUP,@#PWRVEC ;;SET FOR FAST UP
        MOV    #340,@#PWRVEC+2 ;;PRIO:7
        MOV    R0,-(SP)        ;;PUSH R0 ON STACK
        MOV    R1,-(SP)        ;;PUSH R1 ON STACK
        MOV    R2,-(SP)        ;;PUSH R2 ON STACK
        MOV    R3,-(SP)        ;;PUSH R3 ON STACK
        MOV    R4,-(SP)        ;;PUSH R4 ON STACK
        MOV    R5,-(SP)        ;;PUSH R5 ON STACK
        MOV    @SWR,-(SP)       ;;PUSH @SWR ON STACK
        MOV    SP,$SAVR6       ;;SAVE SP
        MOV    #$PWRUP,@#PWRVEC ;;SET UP VECTOR
        HALT
        BR     .-2             ;;HANG UP
*****
```



```

7246      ;POWER UP ROUTINE
7247 025050 012737 025142 000024 $PWRUP: MOV    #$ILLUP,@#PWRVEC ;;SET FOR FAST DOWN
7248 025056 013706 025146          MOV    $$SAVR6,SP      ;;GET SP
7249 025062 005037 025146          CLR    $$SAVR6        ;;WAIT LOOP FOR THE TTY
7250 025066 005237 025146          1$:  INC    $$SAVR6        ;;WAIT FOR THE INC
7251 025072 001375          BNE    1$            ;;OF WORD
7252 025074 012677 154040          MOV    (SP)+,@SWR    ;;POP STACK INTO @SWR
7253 025100 012605          MOV    (SP)+,R5     ;;POP STACK INTO R5
7254 025102 012604          MOV    (SP)+,R4     ;;POP STACK INTO R4
7255 025104 012603          MOV    (SP)+,R3     ;;POP STACK INTO R3
7256 025106 012602          MOV    (SP)+,R2     ;;POP STACK INTO R2
7257 025110 012601          MOV    (SP)+,R1     ;;POP STACK INTO R1
7258 025112 012600          MOV    (SP)+,R0     ;;POP STACK INTO R0
7259 025114 012737 024776 000024 MOV    #$PWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
7260 025122 012737 000340 000026 MOV    #340,@#PWRVEC+2 ;;PRIO:7
7261 025130 104401          TYPE                                ;REPORT THE POWER FAILURE
7262 025132 025150          $PWRMG: .WORD $POWER ;;POWER FAIL MESSAGE POINTER
7263 025134 012716          MOV    (PC)+,(SP)  ;;RESTART AT PFSTRT
7264 025136 004702          $PWRAD: .WORD PFSTRT ;;RESTART ADDRESS
7265 025140 000002          RTI
7266 025142 000000          $ILLUP: HALT      ;;THE POWER UP SEQUENCE WAS STARTED
7267 025144 000776          BR     .-2        ;; BEFORE THE POWER DOWN WAS COMPLETE
7268 025146 000000          $$SAVR6: 0        ;;PUT THE SP HERE
7269 025150 005015 047520 042527 $POWER: .ASCIZ <15><12>'POWER'
7270 025156 000122          .EVEN
7271
7272
7273 025160 004737 021504          FCHECK: JSR    PC,DRESET ;RESETB DRIVE
7274 025164 104026          ERROR 26
7275 025166 104413          CNT.RESET
7276 025170 013737 001350 025302 MOV    DRIVAD,DRHOLD ;SAVE DRIVE ADRR
7277 025176 032737 020000 001350 BIT    #20000,DRIVAD ;SEE IF ODD
7278 025204 001404          BEQ    1$
7279 025206 042737 020000 001350 BIC    #20000,DRIVAD ;MAKE EVEN
7280 025214 000403          BR     2$
7281 025216 052737 020000 001350 1$:  BIS    #20000,DRIVAD ;MAKE ODD
7282 025224 013777 001350 154106 2$:  MOV    DRIVAD,@RKDA ;DRIVE ADDR
7283 025232 012777 000011 154072 MOV    #11,@RKCS ;DRIVE SEEK
7284 025240 104414          CNT.RDY
7285 025242 013777 025302 154070 MOV    DRHOLD,@RKDA ;OTHER DRIVE
7286 025250 104414          CNT.RDY
7287 025252 032777 000100 154046 BIT    #100,@RKDS ;HEAEDS IN MOTIONN?
7288 025260 001001          BNE    3$          ;NO SO RK-05J
7289 025262 005725          TST    (R5)+      ;YES RK-05F
7290 025264 013737 025302 001350 3$:  MOV    DRHOLD,DRIVAD ;RESTORE ADDR
7291 025272 004737 021504          JSR    PC,DRESET ;WAIT FOR RESET
7292 025276 104026          ERROR 26
7293 025300 000205          RTS    R5
7294 025302 000000          DRHOLD: 0
7295 025304 005037 001350          SIZEF: CLR    DRIVAD ;START AT DRO
7296 025310 012700 001414          MOV    #DRIVO,R0 ;TABLE OF AVAIL DRIVES
7297 025314 005710          4$:  TST    (R0)      ;THIS DRIVE HERE?
7298 025316 001413          BEQ    2$          ;NO
7299 025320 005760 000002          TST    2(R0)     ;COMPLEMENT HERE?
7300 025324 001410          BEQ    2$          ;NO
7301 025326 004537 025160          JSR    R5,FCHECK ;SEE IF F MODEL

```


7358	025623	123	041505	041455	EM36:	.ASCIZ /SEC-CNTR DIDN'T INCRMNT/
7359	025630	052116	020122	044504		
7360	025636	047104	052047	044440		
7361	025644	041516	046522	052116		
7362	025652	000				
7363						
7364	025653	123	041505	041455	EM37:	.ASCIZ /SEC-COUNTR INCRMENTED WRONG/
7365	025660	052517	052116	020122		
7366	025666	047111	051103	042515		
7367	025674	052116	042105	053440		
7368	025702	047522	043516	000		
7369						
7370	025707	104	042111	023516	EM40:	.ASCIZ /DIDN'T GET SC=SA FOR THIS SECTR/
7371	025714	020124	042507	020124		
7372	025722	041523	051475	020101		
7373	025730	047506	020122	044124		
7374	025736	051511	051440	041505		
7375	025744	051124	000			
7376						
7377	025747	105	047522	026522	EM41:	.ASCIZ "EROR-R/W/S RDY SHOULD BE SET"
7378	025754	027522	027527	020123		
7379	025762	042122	020131	044123		
7380	025770	052517	042114	041040		
7381	025776	020105	042523	000124		
7382						
7383	026004	047125	054105	042520	EM43:	.ASCIZ /UNEXPECTED RK11 INTERRUPT/
7384	026012	052103	042105	051040		
7385	026020	030513	020061	047111		
7386	026026	042524	051122	050125		
7387	026034	000124				
7388						
7389	026036	047103	051124	020114	EM44:	.ASCIZ /CNTRL RDY DIDN'T SET AFTER SEEK OR DR RESET/
7390	026044	042122	020131	044504		
7391	026052	047104	052047	051440		
7392	026060	052105	040440	052106		
7393	026066	051105	051440	042505		
7394	026074	020113	051117	042040		
7395	026102	020122	042522	042523		
7396	026110	000124				
7397						
7398	026112	051105	020122	051117	EM45:	.ASCIZ /FRR OR HE BIT SET ON SEEK OR DR RESET/
7399	026120	044040	020105	044502		
7400	026126	020124	042523	020124		
7401	026134	047117	051440	042505		
7402	026142	020113	051117	042040		
7403	026150	020122	042522	042523		
7404	026156	000124				
7405						
7406	026160	045522	051105	041040	EM46:	.ASCIZ /RKER BIT, ON SEEK OR DR RESET/
7407	026166	052111	020054	047117		
7408	026174	051440	042505	020113		
7409	026202	051117	042040	020122		
7410	026210	042522	042523	000124		
7411						
7412	026216	045522	051503	041440	EM47:	.ASCIZ /RKCS CHNGD AFTR FUNCTION WAS DONE/
7413	026224	047110	042107	040440		

7414	026232	052106	020122	052506	
7415	026240	041516	044524	047117	
7416	026246	053440	051501	042040	
7417	026254	047117	000105		
7418					
7419	026260	027522	027527	020123	EM50: .ASCIZ 'R/W/S RDY DIDN'T CLEAR''
7420	026266	042122	020131	044504	
7421	026274	047104	052047	041440	
7422	026302	042514	051101	000	
7423					
7424	026307	122	053457	051457	EM51: .ASCIZ 'R/W/S RDY DIDN'T SET AFTR SEEK OR DR RESET''
7425	026314	051040	054504	042040	
7426	026322	042111	023516	020124	
7427	026330	042523	020124	043101	
7428	026336	051124	051440	042505	
7429	026344	020113	051117	042040	
7430	026352	020122	042522	042523	
7431	026360	000124			
7432					
7433	026362	045522	040504	041440	EM52: .ASCIZ /RKDA CHNGD AFTR SEEK/
7434	026370	047110	042107	040440	
7435	026376	052106	020122	042523	
7436	026404	045505	000		
7437					
7438	026407	103	052116	046122	EM53: .ASCIZ /CNTRL RDY DIDN'T CLR AS GO WAS SET/
7439	026414	051040	054504	042040	
7440	026422	042111	023516	021124	
7441	026430	046103	020122	051501	
7442	026436	043440	020117	040527	
7443	026444	020123	042523	000124	
7444					
7445	026452	047103	051124	020114	EM54: .ASCIZ 'CNTRL RDY DIDN'T SET ON WRT/FMT STARTING FROM <DSK-ADRES>''
7446	026460	042122	020131	044504	
7447	026466	047104	052047	051440	
7448	026474	052105	047440	020116	
7449	026502	051127	027524	046506	
7450	026510	020124	052123	051101	
7451	026516	044524	043516	043040	
7452	026524	047522	020115	042074	
7453	026532	045523	040455	051104	
7454	026540	051505	000076		
7455					
7456	026544	042510	047440	020122	EM55: .ASCIZ 'HE OR ERR ON WRT/FMT STARTING FROM <DSK-ADRES>''
7457	026552	051105	020122	047117	
7458	026560	053440	052122	043057	
7459	026566	052115	051440	040524	
7460	026574	052122	047111	020107	
7461	026602	051106	046517	036040	
7462	026610	051504	026513	042101	
7463	026616	042522	037123	000	
7464					
7465	026623	122	042113	020101	EM56: .ASCIZ /RKDA INCRMNTD WRONG ON WRT-FMT/
7466	026630	047111	051103	047115	
7467	026636	042124	053440	047522	
7468	026644	043516	047440	020116	
7469	026652	051127	026524	046506	

7470	026660	000124			
7471					
7472	026662	045522	041527	042040	EM57: .ASCIZ /RKWC DIDN'T OVRFLO ON WRT FMT/
7473	026670	042111	023516	020124	
7474	026676	053117	043122	047514	
7475	026704	047440	020116	051127	
7476	026712	020124	046506	000124	
7477					
7478	026720	045522	040502	044440	EM60: .ASCIZ /RKBA INCRMNTD WRONG ON WRT FMT/
7479	026726	041516	046522	052116	
7480	026734	020104	051127	047117	
7481	026742	020107	047117	053440	
7482	026750	052122	043040	052115	
7483	026756	000			
7484					
7485	026757	122	042513	020122	EM61: .ASCIZ /RKER SET,ON WRT OR RD OR FMT/
7486	026764	042523	026124	047117	
7487	026772	053440	052122	047440	
7488	027000	020122	042122	047440	
7489	027006	020122	046506	000124	
7490					
7491	027014	045522	041104	042440	EM62: .ASCIZ /RKDB EROR/
7492	027022	047522	000122		
7493					

7494	027026	045522	040504	044440	EM63:	.ASCIZ /RKDA INCRMNTD WRONG ON RD OR RD FMT/
7495	027034	041516	046522	052116		
7496	027042	020104	051127	047117		
7497	027050	020107	047117	051040		
7498	027056	020104	051117	051040		
7499	027064	020104	046506	000124		
7500						
7501	027072	045522	041527	042040	EM64:	.ASCIZ /RKWC DIDN'T OVRFLO ON RD OR RD FMT/
7502	027100	042111	023516	020124		
7503	027106	053117	043122	047514		
7504	027114	047440	020116	042122		
7505	027122	047440	020122	042122		
7506	027130	043040	052115	000		
7507						
7508	027135	122	041113	020101	EM65:	.ASCIZ /RKBA INCRMNTD WRONG ON RD OR RD FMT/
7509	027142	047111	051103	047115		
7510	027150	042124	053440	047522		
7511	027156	043516	047440	020116		
7512	027164	042122	047440	020122		
7513	027172	042122	043040	052115		
7514	027200	000				
7515						
7516	027201	111	041516	051117	EM66:	.ASCIZ /INCORRECT HEADER FROM 'SECTOR'/
7517	027206	042522	052103	044040		
7518	027214	040505	042504	020122		
7519	027222	051106	046517	023440		
7520	027230	042523	052103	051117		
7521	027236	000047				
7522						
7523	027240	040504	040524	042440	EM67:	.ASCIZ /DATA ERROR/
7524	027246	051122	051117	000		
7525						
7526	027253	103	052116	046122	EM70:	.ASCIZ "CNTRL RDY DIDN'T SET ON RD/FMT STARTING FROM <DSK-ADRES>"
7527	027260	051040	054504	042040		
7528	027266	042111	023516	020124		
7529	027274	042523	020124	047117		
7530	027302	051040	027504	046506		
7531	027310	020124	052123	051101		
7532	027316	044524	043516	043040		
7533	027324	047522	020115	042074		
7534	027332	045523	040455	051104		
7535	027340	051505	000076			
7536						
7537	027344	042510	047440	020122	EM71:	.ASCIZ 'HE OR ERR ON RD/FMT STARTING FROM <DSK-ADRES>'
7538	027352	051105	020122	047117		
7539	027360	051040	027504	046506		
7540	027366	020124	052123	051101		
7541	027374	044524	043516	043040		
7542	027402	047522	020115	042074		
7543	027410	045523	040455	051104		
7544	027416	051505	000076			
7545						
7546	027422	051127	047117	020107	EM72:	.ASCIZ /WRONG DRIVE ID IN RKDS AFTER SEEK/
7547	027430	051104	053111	020105		
7548	027436	042111	044440	020116		
7549	027444	045522	051504	040440		

7550	027452	052106	051105	051440	
7551	027460	042505	000113		
7552					
7553	027464	051110	053504	042522	EM73: .ASCIZ /HRDWRE POLL-DRV ID BITS(13-15) SHLD BE CLR/
7554	027472	050040	046117	026514	
7555	027500	051104	020126	042111	
7556	027506	041040	052111	024123	
7557	027514	031461	030455	024465	
7558	027522	051440	046110	041104	
7559	027530	020105	046103	000122	
7560					
7561	027536	051110	053504	042522	EM74: .ASCIZ /HRDWRE POLL-INTRUPTING DRIV # NOT PRSNT/
7562	027544	050040	046117	026514	
7563	027552	047111	051124	050125	
7564	027560	044524	043516	042040	
7565	027566	044522	020126	020043	
7566	027574	047516	020124	051120	
7567	027602	047123	000124		
7568					
7569	027606	051104	053111	021440	EM75: .ASCIZ /DRIV # DIDN'T INTRUPT AFTER HRDWRE POLL/
7570	027614	042040	042111	023516	
7571	027622	020124	047111	051124	
7572	027630	050125	020124	043101	
7573	027636	042524	020122	051110	
7574	027644	053504	042522	050040	
7575	027652	046117	000114		
7576					
7577	027656	041523	020120	044504	EM76: .ASCIZ /SCP DIDN'T SET AFTER SEEK WAS DONE/
7578	027664	047104	052047	051440	
7579	027672	052105	040440	052106	
7580	027700	051105	051440	042505	
7581	027706	020113	040527	020123	
7582	027714	047504	042516	000	
7583					
7584	027721	122	042113	020101	EM77: .ASCIZ /RKDA CHANGD AFTER DRIV RESET/
7585	027726	044103	047101	042107	
7586	027734	040440	052106	051105	
7587	027742	042040	044522	020126	
7588	027750	042522	042523	000124	
7589					
7590	027756	040504	040524	042440	EM100: .ASCIZ /DATA EROR AT WORD#/
7591	027764	047522	020122	052101	
7592	027772	053440	051117	021504	
7593	030000	000			
7594					
7595	030001	103	052116	046122	EM101: .ASCIZ /CNTRL RDY DIDN'T SET AFTER RD CHK/
7596	030006	051040	054504	042040	
7597	030014	042111	023516	020124	
7598	030022	042523	020124	043101	
7599	030030	042524	020122	042122	
7600	030036	041440	045510	000	
7601					
7602	030043	105	051122	047440	EM102: .ASCIZ /ERR OR HE ON RD CHK/
7603	030050	020122	042510	047440	
7604	030056	020116	042122	041440	
7605	030064	045510	000		

7606					
7607	030067	103	042523	047440	EM103: .ASCIZ /CSE ON RD CHK/
7608	030074	020116	042122	041440	
7609	030102	045510	000		
7610					
7611	030105	122	053513	020103	EM104: .ASCIZ /RKWC DIDN'T OVERFLO ON RD CHK OR WRT CHK/
7612	030112	044504	047104	052047	
7613	030120	047440	042526	043122	
7614	030126	047514	047440	020116	
7615	030134	042122	041440	045510	
7616	030142	047440	020122	051127	
7617	030150	020124	044103	000113	
7618					
7619	030156	045522	040504	044440	EM105: .ASCIZ /RKDA INCRMNTD WRONG ON RD CHK/
7620	030164	041516	046522	052116	
7621	030172	020104	051127	047117	
7622	030200	020107	047117	051040	
7623	030206	020104	044103	000113	
7624					
7625	030214	045522	040502	041440	EM106: .ASCIZ /RKBA CHANGD AFTER RD CHK/
7626	030222	040510	043516	020104	
7627	030230	043101	042524	020122	
7628	030236	042122	041440	045510	
7629	030244	000			
7630					
7631	030245	115	046505	051117	EM107: .ASCIZ /MEMORY WORD CHANGED AFTER RD CHK/
7632	030252	020131	047527	042122	
7633	030260	041440	040510	043516	
7634	030266	042105	040440	052106	
7635	030274	051105	051040	020104	
7636	030302	044103	000113		
7637					
7638	030306	047103	051124	020114	EM110: .ASCIZ /CNTRL RDY DIDN'T SET AFTER WRT CHK/
7639	030314	042122	020131	044504	
7640	030322	047104	052047	051440	
7641	030330	052105	040440	052106	
7642	030336	051105	053440	052122	
7643	030344	041440	045510	000	
7644					
7645	030351	110	020105	051117	EM111: .ASCIZ /HE OR ERR ON WRT CHK/
7646	030356	042440	051122	047440	
7647	030364	020116	051127	020124	
7648	030372	044103	000113		
7649					
7650	030376	051127	052111	020105	EM112: .ASCIZ /WRITE CHECK EROR/
7651	030404	044103	041505	020113	
7652	030412	051105	051117	000	
7653					
7654	030417	122	042113	020101	EM113: .ASCIZ /RKDA INCRMNTD WRONG ON WRT CHK/
7655	030424	047111	051103	047115	
7656	030432	042124	053440	047522	
7657	030440	043516	047440	020116	
7658	030446	051127	020124	044103	
7659	030454	000113			
7660					
7661	030456	045522	040502	044440	EM114: .ASCIZ /RKBA INCRMNTD WRONG ON WRT CHK/

7662	030464	041516	046522	052116	
7663	030472	020104	051127	047117	
7664	030500	020107	047117	053440	
7665	030506	052122	041440	045510	
7666	030514	000			
7667					
7668	030515	122	041113	020101	EM115: .ASCIZ /RKBA INCRMNTD, WITH IBA SET/
7669	030522	047111	051103	047115	
7670	030530	042124	020054	044527	
7671	030536	044124	044440	040502	
7672	030544	051440	052105	000	
7673					
7674	030551	127	047522	043516	EM116: .ASCIZ /WRONG MEMORY LOCATION CHANGED WITH IBA SET/
7675	030556	046440	046505	051117	
7676	030564	020131	047514	040503	
7677	030572	044524	047117	041440	
7678	030600	040510	043516	042105	
7679	030606	053440	052111	020110	
7680	030614	041111	020101	042523	
7681	030622	000124			
7682					
7683	030624	045522	030461	042040	EM117: .ASCIZ /RK11 DIDN'T INTRUPT WHEN IDE WAS SET/
7684	030632	042111	023516	020124	
7685	030640	047111	051124	050125	
7686	030646	020124	044127	047105	
7687	030654	044440	042504	053440	
7688	030662	051501	051440	052105	
7689	030670	000			
7690					
7691	030671	122	030513	020061	EM120: .ASCIZ /RK11 DIDN'T INTRUPT AFTER SK WAS INITIATED/
7692	030676	044504	047104	052047	
7693	030704	044440	052116	052522	
7694	030712	052120	040440	052106	
7695	030720	051105	051440	020113	
7696	030726	040527	020123	047111	
7697	030734	052111	040511	042524	
7698	030742	000104			
7699					
7700	030744	041523	020120	042523	EM121: .ASCIZ /SCP SET BEFORE SEEK COMPLETED/
7701	030752	020124	042502	047506	
7702	030760	042522	051440	042505	
7703	030766	020113	047503	050115	
7704	030774	042514	042524	000104	
7705					
7706	031002	045522	030461	042040	EM122: .ASCIZ /RK11 DIDN'T INTRUPT AFTER SK COMPLETED/
7707	031010	042111	023516	020124	
7708	031016	047111	051124	050125	
7709	031024	020124	043101	042524	
7710	031032	020122	045523	041440	
7711	031040	046517	046120	052105	
7712	031046	042105	000		
7713					
7714	031051	103	052116	046122	EM123: .ASCIZ /CNTRL RESET DIDN'T CLEAR 'SCP'/
7715	031056	051040	051505	052105	
7716	031064	042040	042111	023516	
7717	031072	020124	046103	040505	

7718	031100	020122	051447	050103	
7719	031106	000047			
7720					
7721	031110	045522	030461	042040	EM124: .ASCIZ /RK11 DIDN'T INTRUPT AFTER RD DONE/
7722	031116	042111	023516	020124	
7723	031124	047111	051124	050125	
7724	031132	020124	043101	042524	
7725	031140	020122	042122	042040	
7726	031146	047117	000105		
7727					
7728	031152	047103	051124	020114	EM125: .ASCIZ /CNTRL RESET DIDN'T CLR REGISTR/
7729	031160	042522	042523	020124	
7730	031166	044504	047104	052047	
7731	031174	041440	051114	051040	
7732	031202	043505	051511	051124	
7733	031210	000			
7734					
7735	031211	122	030513	020061	EM126: .ASCIZ /RK11 DIDN'T INTRUPT AT CPU LEVEL/
7736	031216	044504	047104	052047	
7737	031224	044440	052116	052522	
7738	031232	052120	040440	020124	
7739	031240	050103	020125	042514	
7740	031246	042526	000114		
7741					
7742	031252	045522	030461	044440	EM127: .ASCIZ /RK11 INTRUPTED AT WRONG CPU LEVEL/
7743	031260	052116	052522	052120	
7744	031266	042105	040440	020124	
7745	031274	051127	047117	020107	
7746	031302	050103	020125	042514	
7747	031310	042526	000114		
7748					
7749	031314	042447	051122	041040	EM130: .ASCIZ /'ERR BIT' DIDN'T SET IN RKER/
7750	031322	052111	020047	044504	
7751	031330	047104	052047	051440	
7752	031336	052105	044440	020116	
7753	031344	045522	051105	000	
7754					
7755	031351	110	020105	051117	EM131: .ASCIZ /HE OR ERR DIDN'T SET/
7756	031356	042440	051122	042040	
7757	031364	042111	023516	020124	
7758	031372	042523	000124		
7759					
7760	031376	045522	051105	042440	EM132: .ASCIZ /RKER EROR/
7761	031404	047522	000122		
7762					
7763	031410	054116	020103	044502	EM133: .ASCIZ /NXC BIT DIDN'T SET/
7764	031416	020124	044504	047104	
7765	031424	052047	051440	052105	
7766	031432	000			
7767					
7768	031433	122	030513	020061	EM134: .ASCIZ /RK11 DIDN'T INTRUPT ON SOFT EROR/
7769	031440	044504	047104	052047	
7770	031446	044440	052116	052522	
7771	031454	052120	047440	020116	
7772	031462	047523	052106	042440	
7773	031470	047522	000122		


```

7774
7775 031474 042515 020130 044502 EM135: .ASCIZ /MEX BITS INCRMNTD WRONG-RKCS/
7776 031502 051524 044440 041516
7777 031510 046522 052116 020104
7778 031516 051127 047117 026507
7779 031524 045522 051503 000
7780
7781 031531 127 051520 047040 EM137: .ASCIZ /WPS NOT CLEAR/
7782 031536 052117 041440 042514
7783 031544 051101 000
7784
7785 031547 104 052101 020101 EM140: .ASCIZ /DATA EROR ON TRANSFER FROM DISK TO TTY/
7786 031554 051105 051117 047440
7787 031562 020116 051124 047101
7788 031570 043123 051105 043040
7789 031576 047522 020115 044504
7790 031604 045523 052040 020117
7791 031612 052124 000131
7792
7793 031616 042047 044522 020126 EM141: .ASCIZ /'DRIV #' PRESENT, BUT NOT INDICATED/
7794 031624 023443 050040 042522
7795 031632 042523 052116 020054
7796 031640 052502 020124 047516
7797 031646 020124 047111 044504
7798 031654 040503 042524 000104
7799 031662 047040 020117 052502 EM142: .ASCIZ / NO BUSY ON OTHER HALF OF RK-05F/
7800 031670 054523 047440 020116
7801 031676 052117 042510 020122
7802 031704 040510 043114 047440
7803 031712 020106 045522 030055
7804 031720 043065 000
7805
7806
7807
7808
7809
7810 031724 .EVEN
7811
7812 .SBTTL ERROR DATA POINTERS
7813
7814 031724 001116 001162 000000 DT1: .WORD $ERRPC,$REG0,0
7815
7816 031732 001116 001162 001164 DT2: .WORD $ERRPC,$REG0,$REG1,0
7817 031740 000000
7818
7819 031742 001116 001162 001164 DT20: .WORD $ERRPC,$REG0,$REG1,$REG2,$REG3,0
7820 031750 001166 001170 000000
7821
7822 031756 001116 000000 DT21: .WORD $ERRPC,0
7823
7824 031762 001116 001162 001164 DT26: .WORD $ERRPC,$REG0,$REG1,$REG2,0
7825 031770 001166 000000
7826
7827 031774 001116 001162 001164 DT54: .WORD $ERRPC,$REG0,$REG1,$REG2,$REG3,$REG4,$REG5,$REG6,$REG7,0
7828 032002 001166 001170 001172
7829 032010 001174 001176 001200
  
```

Line	Code	Address	Value	Label	Header	Field	Field	Field	Field
7830	032016	000000							
7831									
7832									
7833									
7834									
7835					.SBTTL	ERROR	HEADERS		
7836									
7837	032020	020040	041520	020040	DH2:	.ASCIZ	/	PC	REGADD RECVD/
7838	032026	051040	043505	042101					
7839	032034	020104	020040	051040					
7840	032042	041505	042126	000					
7841									
7842	032047	040	050040	020103	DH4:	.ASCIZ	/	PC	EXPCT RECVD/
7843	032054	020040	042440	050130					
7844	032062	052103	020040	051040					
7845	032070	041505	042126	000					
7846									
7847	032075	040	050040	020103	DH5:	.ASCIZ	/	PC	RECVD/
7848	032102	020040	051040	041505					
7849	032110	042126	000						
7850									
7851	032113	040	050040	020103	DH14:	.ASCIZ	/	PC	RKCS RKER RKWC/
7852	032120	020040	051040	041513					
7853	032126	020123	020040	051040					
7854	032134	042513	020122	020040					
7855	032142	051040	053513	000103					
7856									
7857	032150	020040	041520	000	DH21:	.ASCIZ	/	PC/	
7858									
7859	032155	040	050040	020103	DH30:	.ASCIZ	/	PC	RKCS RKER RKDS/
7860	032162	020040	020040	045522					
7861	032170	051503	020040	020040					
7862	032176	045522	051105	020040					
7863	032204	020040	045522	051504					
7864	032212	000							
7865									
7866	032213	040	050040	020103	DH34:	.ASCIZ	/	PC	RKDS/
7867	032220	020040	020040	045522					
7868	032226	051504	000						
7869									
7870	032231	040	050040	020103	DH35:	.ASCIZ	/	PC	SEC-CNTR/
7871	032236	020040	042523	026503					
7872	032244	047103	051124	000					
7873									
7874	032251	040	050040	020103	DH36:	.ASCIZ	/	PC	PRSNT NXT-CNT/
7875	032256	020040	020040	051120					
7876	032264	047123	020124	047040					
7877	032272	052130	041455	052116					
7878	032300	000							
7879									
7880	032301	040	050040	020103	DH40:	.ASCIZ	/	PC	SECTOR RKDS/
7881	032306	020040	051440	041505					
7882	032314	047524	020122	020040					
7883	032322	045522	051504	000					
7884									
7885	032327	040	050040	020103	DH44:	.ASCIZ	/	PC	RKCS RKER RKDS RKDA/

7942	032760	053440	051117	020104																
7943	032766	020043	020040	054105																
7944	032774	041520	020124	020040																
7945	033002	042522	053103	000104																
7946																				
7947	033010	020040	041520	020040	DH103:	.ASCIZ	/	PC	RKER/											
7948	033016	051040	042513	000122																
7949																				
7950	033024	020040	041520	020040	DH104:	.ASCIZ	/	PC	RECVD	RKCS/										
7951	033032	051040	041505	042126																
7952	033040	020040	051040	041513																
7953	033046	000123																		
7954																				
7955	033050	020040	041520	020040	DH107:	.ASCIZ	/	PC	LOC	EXPCT	RECVD/									
7956	033056	020040	046040	041517																
7957	033064	020040	020040	054105																
7958	033072	041520	020124	020040																
7959	033100	042522	053103	000104																
7960																				
7961	033106	020040	041520	020040	DH117:	.ASCIZ	/	PC	RKCS/											
7962	033114	051040	041513	000123																
7963																				
7964	033122	020040	041520	020040	DH126:	.ASCIZ	/	PC	LEVEL	RKCS/										
7965	033130	020040	042514	042526																
7966	033136	020114	020040	051040																
7967	033144	041513	000123																	
7968																				
7969	033150	020040	041520	020040	DH130:	.ASCIZ	/	PC	RKCS	RKER	ERR BIT/									
7970	033156	020040	051040	041513																
7971	033164	020123	020040	051040																
7972	033172	042513	020122	042440																
7973	033200	051122	041040	052111																
7974	033206	000																		
7975																				
7976	033207	040	050040	020103	DH131:	.ASCIZ	/	PC	RKCS	RKER/										
7977	033214	020040	020040	045522																
7978	033222	051503	020040	020040																
7979	033230	045522	051105	000																
7980																				
7981	033235	040	050040	020103	DH133:	.ASCIZ	/	PC	RKCS	RKER	RKDA/									
7982	033242	020040	020040	045522																
7983	033250	051503	020040	020040																
7984	033256	045522	051105	020040																
7985	033264	020040	045522	040504																
7986	033272	000																		
7987																				
7988	033273	040	050040	020103	DH140:	.ASCIZ	/	PC	EXPCT	RECVD	RKBA	RKCS/								
7989	033300	020040	042440	050130																
7990	033306	052103	020040	051040																
7991	033314	041505	042126	020040																
7992	033322	020040	045522	040502																
7993	033330	020040	020040	045522																
7994	033336	051503	000																	
7995																				
7996																				
7997		033342																		

.EVEN

MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2
CZRKKF.P11 21-FEB-78 08:51

D 12
MACY11 30A(1052) 21-FEB-78 08:58 PAGE 147
ERROR HEADERS

SEQ 0146

7998
7999
8000 033342 000400
8001
8002
8003
8004 000001

;DATA BUFFER
OUTBUF: .BLKW 256. ;THIS 256 WORD BUFFER IS FOR
;DATA TRANSFERS FROM AND
;TO THE DISK.
.END

TSTEND	020626	6028	6055#															
TSTRWS	021436	2750	5128	5207	5236	5256	5585	5752	6360#									
TSTSIN	021572	6425#	7224															
TST.Si=	104421	2666	2732	2786	2905	3006	3138	3231	3355	3518	3648	3802	3916	4130				
		4244	4318	4407	4499	4606	4779	4857	4937	5014	5080	5149	5239	5390				
		5458	5523	5744	7224#													
TST1	004706	2110	2192#															
TST10	005742	2481	2503	2508	2515	2530#												
TST11	006030	2554	2565#															
TST12	006110	2579	2597#															
TST13	006252	2642	2655#															
TST14	006416	2705	2721#															
TST15	006510	2775#																
TST16	006746	2866	2893#															
TST17	007174	2970	2995#															
TST2	005040	2259#																
TST20	007504	3100	3119#															
TST21	007702	3219#																
TST22	010154	3300	3328#															
TST23	010524	3463	3497#															
TST24	011004	3614#																
TST25	011414	3733	3749	3777#														
TST26	011722	3867	3894#															
TST27	012242	3998#																
TST3	005236	2309#																
TST30	012530	4001	4100	4119#														
TST31	012764	4215	4233#															
TST32	013170	4274	4294	4307#														
TST33	013436	4376	4396#															
TST34	013720	4470	4488#															
TST35	014176	4541	4559	4584	4595#													
TST36	014330	4660#																
TST37	014654	4758	4768#															
TST4	005350	2341	2356#															
TST40	015070	4830	4846#															
TST41	015274	4901	4926#															
TST42	015456	5003#																
TST43	015564	5069#																
TST44	015740	5138#																
TST45	016076	5163	5219#															
TST46	016304	5291	5304#															
TST47	016456	5378#																
TST5	005436	2381	2393#															
TST50	016634	5447#																
TST51	016762	5489	5512#															
TST52	017134	5578#																
TST53	017330	5647#																
TST54	017622	5659	5717	5742#														
TST55	017760	5797#																
TST56	020004	5814#																
TST57	020054	5845#																
TST6	005464	2406	2415#															
TST7	005522	2419	2445#															
TYERM	021026	2055	2086	6148#														
TYPDS =	104405	6085	7202#															
TYPE =	104401	1872	1924	1936	1945	1949	1964	1988	2044	2066	2079	2120	2140	2142				

	2145	2288	2299	2304	6083	6086	6149	6433	6569	6571	6579	6689	6710
	6724	6728	6742	6759	6761	6764	6766	6770	6777	6816	6911	6981	7020
	7021	7024	7037	7048	7067	7120	7126	7131	7135	7140	7141	7143	7146
	7150	7198#	7261										
TYPOC = 104402	2071	2125	2150	6154	6439	6577	6584	6727	6750	6774	7023	7199#	
TYPON = 104404	7201#												
TYPOS = 104403	1930	1942	2293	7200#									
T56 020140	5862#	6058											
T56FLG 001434	1179#	2096*	5865*	6059*	6707								
WATIME 021742	2099	2174	6500#										
WATINT 021706	6484#	7222											
WAT.IN= 104420	4619	4633	4682	4703	4794	5538	7222#						
\$AUTOB 001134	1053#	1880*	7017	7166									
\$BDADR 001122	1048#												
\$BDDAT 001126	1050#												
\$CHARC 023304	6818*	6828*	6835	6844*	6849#								
\$CKSWR 023762	7009#	7206											
\$CMTAG 001100	1036#	1830	1831	1839	1845	1846							
\$CM1 = 000012	1068#	1069#	1070#	1071#	1072#	1073#	1074#	1075#	1076#	1077#	1078#		
\$CM2 = 000024	1068#	1069#	1070#	1071#	1072#	1073#	1074#	1075#	1076#	1077#	1078#		
\$CM3 = 000012	1066#	1068											
\$CNTLG 024647	7020	7161#											
\$CNTLU 024642	7037	7135	7160#										
\$CRLF 001213	1081#	2067	2141	2305	6689	6742	6761	6766	6770	6817	6852	7048	7140
	7160												
\$DBLK 023524	6877	6911	6919#										
\$DOAGN 020750	6079	6088	6094#										
\$DTBL 023514	6880	6915#											
\$ENDAD 020740	1025	6090#											
\$ENDCT 020706	6081#												
\$ENDMG 020757	6083	6098#											
\$ENULL 020754	6086	6097#											
\$EOP 020652	2100	2267	5864	6071#	6713								
\$EOPCT 020700	6078#	6082											
\$ERFLG 001103	1039#	6600	6629	6631	6637*	6658	6673*						
\$ERMAX 001115	1045#	1847*	6631	6653*	6658								
\$ERROR 022412	1839	6672#											
\$ERRPC 001116	1046#	6683*	6684*	6685	6748	7814	7816	7819	7822	7824	7827		
\$ERRTB 001442	1196#	6756											
\$ERRTY 022734	6688	6741#											
\$ERTTL 001112	1043#	2264*	5826*	6676*	6680								
\$ESCAP 001210	1079#	1846*	6652*	6702	6704								
\$FILLC 001156	1064#	6821	6852										
\$FILLS 001155	1063#	6852											
\$GDADR 001120	1047#												
\$GDDAT 001124	1049#												
\$GET42 020730	6087#												
\$GTSWR 024032	7021#	7204											
\$HD = 000000	871												
\$ICNT 001104	1040#	6644*	6645	6647*	6657								
\$ILLUP 025142	7231	7247	7266#										
\$INTAG 001135	1054#	7049	7166										
\$ITEMB 001114	1044#	6685*	6745										
\$LF 001214	1082#	6852	7150	7160									
\$LPADR 001106	1041#	1848*	2155	6635*	6650*	6655	6657	6698					
\$LPERR 001110	1042#	1849*	3126*	3329*	3499*	3616*	3779*	3903*	4859*	5224*	5582*	5748*	6635

\$SAVRE= ***** U	7209													
\$SAVR6 025146	7240*	7248	7249*	7250*	7268#									
\$SCOPE 022140	1837	6609#												
\$SETUP= 000117	1814#	1836	1837	1839	1841	1843	1845	1846	1848	1872,	1873	6073	6610	
	7004	7166												
\$STUP = 177777	1814#													
\$SVLAD 022346	6620	6649#												
\$SVPC = 000204	1023#	1028												
\$SWR = 165400	852#	871	877	878	879	880	881	882	883	884	1078	1079	1080	
	1845	1846	1848	1849	2193	2260	2310	2357	2394	2416	2446	2531	2566	
	2598	2656	2722	2776	2894	2996	3120	3220	3329	3498	3615	3778	3895	
	3999	4120	4234	4308	4397	4489	4596	4661	4769	4847	4927	5004	5070	
	5139	5220	5305	5379	5448	5513	5579	5648	5743	5798	5815	5846	6068	
	6074	6089	6095	6097	6601	6602	6603	6604	6605	6611	6623	6625	6626	
	6629	6630	6631	6638	6639	6640	6651	6654	6657	7265				
\$SWRMK= 000000	884	885	6605	6606	6627									
\$TIMES 001206	1078#	1845*	2260*	3498*	3615*	3778*	3895*	3999*	4661*	5648*	5743*	5798*	5815*	
	5846*	6074*	6638*	6645	6648*	6657								
\$TKB 001146	1059#	7002	7013	7030	7084	7090								
\$TKS 001144	1058#	5698	5699*	5715	5718	7002	7011	7027	7051*	7082	7088			
\$TN = 000060	852#	871	2178	2193#	2253	2260#	2306	2310#	2341	2353	2357#	2381	2390	
	2394#	2406	2410	2416#	2419	2428	2446#	2481	2503	2508	2515	2525	2531#	
	2554	2562	2566#	2579	2588	2598#	2642	2648	2656#	2705	2711	2722#	2760	
	2776#	2866	2872	2894#	2970	2979	2996#	3100	3105	3120#	3200	3220#	3300	
	3309	3329#	3463	3470	3498#	3595	3615#	3733	3749	3754	3778#	3867	3886	
	3895#	3990	3999#	4001	4100	4111	4120#	4215	4222	4234#	4274	4294	4301	
	4308#	4376	4387	4397#	4470	4475	4489#	4541	4559	4584	4587	4596#	4651	
	4661#	4758	4762	4769#	4830	4836	4847#	4901	4918	4927#	4995	5004#	5060	
	5070#	5132	5139#	5163	5212	5220#	5291	5297	5305#	5369	5379#	5435	5448#	
	5489	5503	5513#	5569	5579#	5637	5648#	5659	5717	5732	5743#	5791	5798#	
	5806	5815#	5829	5846#										
\$TPB 001152	1061#	6841*	6852											
\$TPFLG 001157	1065#	6799	6852											
\$TPS 001150	1060#	6839	6852											
\$TRAP 024676	1841	7175#												
\$TRAP2 024720	7186#	7197												
\$TRP = 000022	7190#	7199#	7200#	7201#	7202#	7203#	7204	7205#	7206	7207#	7208#	7209#	7210	
	7211#	7212	7213#	7214	7215#	7216	7217#	7218	7219#	7220	7221#	7222	7223#	
	7224	7225#												
\$TRPAD 024732	7180	7197#												
\$TSTNM 001102	1038#	2261*	6073*	6600	6627	6649*	6654	6658	6675					
\$TTYIN 024620	7110	7111	7123	7141	7155	7159#								
\$TYPBN= ***** U	7203													
\$TYPDS 023310	6865#	7202												
\$TYPE 023070	6799#	7190	7198											
\$TYPEC 023240	6820	6827	6834	6839#	6840	7053								
\$TYPEX 023306	6845	6847	6850#											
\$TYPOC 023560	6951#	7199												
\$TYPON 023574	6950	6953#	7201											
\$TYPOS 023534	6946#	7200												
\$XTSTR 022152	6614#													
\$GET4= 000000	6089#													
\$OFILL 023757	6947*	6951*	6961	6996#										
\$40CAT= ***** U	6611													
	1010#	1014#	1023	1024#	1026#	1028#	1035#	1083	1087#	1824	1834	1848	1849	
	1884#	1927#	1939#	1948#	1952#	1991#	2123#	2148#	2266	2620	3193	3440	3569	

COMMEN	1#	1008#															
ENDCOM	1#	1008#															
ERROR	902#	2212	2223	2325	2336	2346	2372	2378	2383	2408	2423	2501	2506	2512	2519		
	2558	2577	2581	2614	2627	2633	2638	2645	2674	2684	2688	2697	2702	2708	2735		
	2747	2751	2824	2836	2843	2849	2853	2859	2863	2869	2919	2932	2938	2944	2949		
	2955	2959	2967	2973	3021	3034	3041	3047	3051	3057	3061	3069	3088	3095	3103		
	3162	3168	3177	3187	3251	3258	3267	3276	3280	3289	3297	3303	3372	3379	3392		
	3397	3421	3450	3466	3540	3549	3554	3561	3672	3684	3689	3702	3717	3728	3821		
	3831	3835	3845	3858	3927	3937	3942	3946	3954	3961	3973	4037	4069	4075	4082		
	4104	4168	4181	4189	4199	4204	4208	4212	4218	4267	4289	4333	4337	4342	4347		
	4354	4362	4369	4381	4426	4430	4436	4441	4452	4460	4466	4473	4525	4529	4538		
	4552	4568	4622	4640	4675	4690	4701	4710	4723	4736	4753	4760	4800	4810	4817		
	4821	4833	4886	4912	4957	4965	4970	4985	4989	4992	5031	5038	5053	5057	5094		
	5102	5107	5122	5126	5130	5172	5187	5201	5205	5209	5238	5245	5253	5258	5261		
	5273	5288	5294	5333	5340	5347	5362	5366	5412	5418	5423	5428	5432	5472	5481		
	5492	5542	5557	5586	5608	5618	5630	5694	5710	5724	5753	5761	5773	5802	5819		
	5926	5962	5969	6003	6021	7274	7292										
ESCAPE	1#	1008#															
GETPRI	1#	1008#															
GETSWR	1#	852#	1008#	1873#													
MESSAGE	2177#	2180	2253#	2255	2410#	2412	2427#	2430	2524#	2527	2588#	2590	2648#	2650	2711#		
	2713	2760#	2762	2872#	2874	2978#	2981	3105#	3107	3200#	3202	3308#	3311	3470#	3472		
	3594#	3597	3753#	3756	3885#	3888	3989#	3992	4110#	4113	4221#	4224	4300#	4303	4387#		
	4389	4475#	4477	4587#	4589	4651#	4653	4762#	4764	4836#	4838	4918#	4920	4995#	4997		
	5060#	5062	5132#	5134	5212#	5214	5297#	5299	5369#	5371	5435#	5437	5502#	5505	5568#		
	5571	5637#	5639	5731#	5734	5791#	5793	5806#	5808	5828#	5831						
MORETA	1029#	1084															
MULT	1#	1008#															
NEWTST	1#	1008#	2178	2253	2306	2353	2390	2410	2428	2525	2562	2588	2648	2711	2760		
	2872	2979	3105	3200	3309	3470	3595	3754	3886	3990	4111	4222	4301	4387	4475		
	4587	4651	4762	4836	4918	4995	5060	5132	5212	5297	5369	5435	5503	5569	5637		
	5732	5791	5806	5829													
POP	1#	1008#	6906	7252	7253												
PRIOR7	1198#	4608	4645	4743	4824	4897	5561	5662	5899								
PUSH	1#	1008#	6865	7233	7239												
REPORT	1#	1008#															
SCOPE	903#	2192	2259	2309	2356	2393	2415	2445	2530	2565	2597	2655	2721	2775	2893		
	2995	3119	3219	3328	3497	3614	3777	3894	3998	4119	4233	4307	4396	4488	4595		
	4660	4768	4846	4926	5003	5069	5138	5219	5304	5378	5447	5512	5578	5647	5742		
	5797	5814	5845	6072													
SETPRI	1#	1008#															
SETTRA	7190#	7199	7200	7201	7202	7204	7206	7207	7208	7210	7212	7214	7216	7218	7220		
	7222	7224															
SETUP	1#	1008#	1828														
SKIP	1#	1008#	2341	2381	2406	2419	2481	2503	2508	2515	2554	2579	2642	2705	2866		
	2970	3100	3300	3463	3733	3749	3867	4001	4100	4215	4274	4294	4376	4470	4541		
	4559	4584	4758	4830	4901	5163	5291	5489	5659	5717							
SLASH	1#	1008#															
SPACE	1008#																
STARS	1#	1008#	1021	1031	1083	2178	2191	2253	2258	2306	2308	2353	2355	2390	2392		
	2410	2414	2428	2444	2525	2529	2562	2564	2588	2596	2648	2654	2711	2720	2760		
	2774	2872	2892	2979	2994	3105	3118	3200	3218	3309	3327	3470	3496	3595	3613		
	3754	3776	3886	3893	3990	3997	4111	4118	4222	4232	4301	4306	4387	4395	4475		
	4487	4587	4594	4651	4659	4762	4767	4836	4845	4918	4925	4995	5002	5060	5068		
	5132	5137	5212	5218	5297	5303	5369	5377	5435	5446	5503	5511	5569	5577	5637		
	5646	5732	5741	5791	5796	5806	5813	5829	5844	6064	6597	6736	6784	6855	6923		

MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2
CZRKKF.P11 21-FEB-78 08:51

MACY11 30A(1052) 21-FEB-78 08:58 PAGE 163
CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0160

.\$TYPD	1#	852#	6853
.\$TYPE	1#	852#	6782
.\$TYPO	1#	852#	6921
.\$40CA	1#		
.1170	1#		

. ABS. 034342 000

ERRORS DETECTED: 0

CZRKKF,CZRKKF.LST/CRF/SOL=CZRKKF.SML,CZRKKF.P11
RUN-TIME: 22 31 1 SECONDS
RUN-TIME RATIO: 392/55=7.0
CORE USED: 34K (67 PAGES)