

RM80

FCTNL TEST PT 3
CZRNFAO

AH-T115A-MC
FICHE 1 OF 2

JUL 1982
COPYRIGHT © 1982
MADE IN USA



A large grid of approximately 15 columns and 25 rows of small, illegible data tables. Each cell in the grid contains a small table with multiple columns and rows of text, which appears to be test results or performance metrics. The text is too small to be read accurately, but the layout is consistent across the entire page.

RM80

FCTNL TEST PT 3
CZRNFA0

AH-T115A-MC
FICHE 2 OF 2

JUL 1982
COPYRIGHT © 1982
MADE IN USA



Microfiche grid containing multiple frames of data, including text and vertical bar patterns.



1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43

.REM \

IDENTIFICATION

PRODUCT CODE: AC-T114A-MC
PRODUCT NAME: CZRNFA0 RM80 FCTNL PT 3
PRODUCT DATE: APRIL 1, 1982
MAINTAINER: CX DIAGNOSTIC GROUP
AUTHOR: MIKE LEAVITT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1982 DIGITAL EQUIPMENT CORPORATION

CONTENTS1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43

1. INTRODUCTION
 1. ABSTRACT
 2. UNIT UNDER TEST
2. OPERATING REQUIREMENTS
 1. HARDWARE REQUIREMENTS
 2. MEDIA REQUIREMENTS
 3. PREREQUISITE DIAGNOSTIC PROGRAMS
3. OPERATING PROCEDURE
 1. LOADING
 2. SWITCH OPTIONS
 3. STARTING
 4. HALTING
 5. RESTARTING
4. OPERATOR INTERFACE
 1. PROGRAM I.D.
 2. CONSOLE DIALOGUE
 3. PROGRESS REPORTS
 4. PERFORMANCE REPORTS
 5. PROGRAM HALTS
 6. ERROR REPORTS
 7. EXECUTION TIME
5. ENVIRONMENTAL SUPPORT
 1. PROCESSOR COMPATIBILITY
 2. DUAL PORT CONFIGURATIONS
 3. MEMORY PARITY HARDWARE
 4. MEMORY MANAGEMENT HARDWARE
 5. ACT, APT COMPATIBILITY
 6. XXDP COMPATIBILITY
 7. OPERATING SYSTEM COMPATIBILITY
6. TEST DESCRIPTION

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

1.0 INTRODUCTION

1.1 ABSTRACT

THE RM80 SUBSYSTEM FUNCTIONAL TEST IS A STAND ALONE PROGRAM WHICH USES FUNCTIONAL MEANS TO VERIFY THE OPERABILITY OF THE RM80 DISK SUBSYSTEM. IN PARTICULAR, THE PROGRAM SERVES THE FOLLOWING PURPOSES:

TO EXPLICITLY ESTABLISH CONFIDENCE IN THE BASIC OPERATIONS OF THE DISK DRIVE, INCLUDING MECHANICAL POSITIONING AND DATA TRANSFER OPERATIONS;

TO IMPLICITLY ESTABLISH CONFIDENCE IN THE DRIVE/ADAPTER ELECTRICAL INTERFACE;

TO VERIFY THE FUNCTIONALITY OF THE RM80 SUBSYSTEM, INCLUDING THE MASSBUS CONTROLLER, MASSBUS ADAPTER AND THE DISK DRIVE.

THE TEST IS COMPRISED OF 4 PARTS, WHICH WOULD NORMALLY BE RUN IN SEQUENCE, STARTING WITH PART 1. BRIEFLY, PART 1 TESTS HOUSEKEEPING AND MECHANICAL POSITIONING OPERATIONS; PART 2 TESTS WRITE, READ AND WRITE CHECK OPERATIONS USING HEADER AND DATA; PART 3 TESTS WRITE, READ AND WRITE CHECK OPERATIONS USING DATA; PART 4 TESTS MECHANICAL POSITIONING OPERATIONS AND VARIOUS TIMING PARAMETERS OF THE RM80 DISK DRIVE.

1.2 UNIT UNDER TEST

THE UNIT UNDER TEST (UUT) IS THE RM80 DISK SUBSYSTEM WHICH CONSISTS OF THE RH70 MASSBUS CONTROLLER, THE RM80 MASSBUS ADAPTER, AND THE STORAGE MODULE DISK DRIVE. NOTE THAT A DISK IS REQUIRED FOR TESTING AND IS CONSIDERED AN INTEGRAL OF THE STORAGE MODULE DISK DRIVE.

2.0 OPERATING REQUIREMENTS

2.1 HARDWARE REQUIREMENTS

THE FOLLOWING MINIMUM HARDWARE CONFIGURATION, ASSUMED TO BE OPERATIONAL, IS REQUIRED TO LOAD AND EXECUTE THE RM80 SUBSYSTEM FUNCTIONAL TEST:

PDP-11 PROCESSOR
20K MEMORY
KW11-L OR KW11-P CLOCK
PROGRAM LOADING DEVICE
TERMINAL
RH70 CONTROLLER
1 TO 8 RM80 DISK DRIVES

2.2 MEDIA REQUIREMENTS

58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114

EACH UNIT BEING TESTED MUST BE LOADED WITH A DISK BEFORE TESTING BEGINS ON THAT UNIT. THE DRIVE MUST HAVE A FORMATTED DISK AND CONTAIN A READABLE COPY OF THE MFG(DEC144), USR(DEC144) AND SSF BAD SECTOR FILES.

NOTE: TO ENSURE THAT ALL CUSTOMER DATA IS PRESERVED ON THE DISK, ALL DATA TRANSFERS WILL BE PERFORMED ON THE FE CYLINDERS ONLY.

2.3 PREREQUISITE DIAGNOSTIC PROGRAMS

RM80 DISKLESS TEST, PART 1 & 2

RM80 FUNCTIONAL TEST, PART 1 & 2

3.0 OPERATING PROCEDURE

3.1 LOADING

THE PROGRAM MAY BE LOADED BY EITHER OF THE FOLLOWING MEDIA:

.PAPER TAPE, USING THE STANDARD PAPER TAPE LOADING PROCEDURE.
.XXDP MEDIA, USING THE APPROPRIATE LOADING DEVICE.

3.2 SWITCH OPTIONS

THE FOLLOWING SWITCH OPTIONS ARE PROVIDED TO ENHANCE THE UTILITY OF THE PROGRAM.

SW15 HALT ON ERROR
SW14 LOOP ON TEST (CURRENTLY BEING EXECUTED)
SW13 INHIBIT ERROR TYPEOUTS
SW12 UNUSED
SW11 INHIBIT TEST ITERATIONS
SW10 BELL ON ERROR
SW09 LOOP ON ERROR
SW08 LOOP ON TEST IN SW07-00

THE LOW ORDER 8 SWITCHES (SW07-SW00), ARE USED IN CONJUNCTION WITH SW08 TO SPECIFY THE OCTAL NUMBER OF THE TEST WHICH THE PROGRAM WILL LOOP ON.

3.3 STARTING

THE PROGRAM MAY BE STARTED AT LOCATION 200 OR 204. STARTING AT 200 WILL BE THE NORMAL STARTING ADDRESS. STARTING AT 204 WILL ENABLE THE RH/RM BASE ADDRESS TO BE CHANGED.

115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171

3.4 HALTING

THE PROGRAM SHOULD BE HALTED BY TYPING CONTROL C FROM THE CONSOLE.

NOTE: IF THE PROGRAM IS HALTED BY ANY OTHER MEANS, BAD HEADER INFORMATION MAY BE LEFT ON THE DISK. THIS OF COURSE, DEPENDS ON WHICH TEST WAS BEING PERFORMED AT THE TIME THE PROGRAM WAS HALTED. ALSO, THIS ONLY APPLIES TO A NORMAL (ERROR FREE) OPERATION OF THE PROGRAM.

3.5 RESTARTING

THE PROGRAM CAN BE RESTARTED AT ADDRESS 200 OR 204. (SEE SECTION 3.3)

4.0 OPERATOR INTERFACE

4.1 PROGRAM ID

THE PROGRAM TYPES ITS TITLE AND MAINDEC NUMBER THE FIRST TIME IT IS STARTED AFTER BEING LOADED. ALSO, A WARNING MESSAGE IS TYPED, NOTIFYING THE OPERATOR OF POSSIBLE HEADER CORRUPTION IF THE PROGRAM IS HALTED IMPROPERLY. THE PROGRAM IDENTIFICATION AND THE WARNING DO NOT OCCUR IF THE PROGRAM IS RESTARTED.

4.2 CONSOLE DIALOGUE

WHEN THE PROGRAM IS RUNNING IN STAND ALONE MODE, IT ENTERS A CONSOLE DIALOGUE SEQUENCE AFTER TYPING THE PROGRAM I.D. AND WARNING MESSAGE. (SEE SECTION 4.1)

THE FIRST QUESTION TYPED OUT IS: "TYPE HELP TEXT (L) N ?". IF THE OPERATOR RESPONDS WITH A 'Y', THE PROGRAM WILL TYPE A BRIEF HELP MESSAGE WHICH WILL LIST SWITCH OPTIONS, ETC. ANY OTHER RESPONSE TO THE QUESTION IS CONSIDERED A 'N' AND NO HELP TEXT IS TYPED. THIS QUESTION IS ONLY ASKED ON THE INITIAL PROGRAM START AND NOT ON SUBSEQUENT START-UP'S.

ON THE PROGRAM INITIAL START AND WHEN RESTARTING AT LOCATION 204, THE OPERATOR MAY CHANGE THE RH/RM BASE ADDRESSES WITH THE FOLLOWING DIALOGUE.

EXAMPLE 1

```
RMCS1=176700 <CR>      ;NO CHANGE IN ADDRESS
RMVEC=000254 <CR>      ;NO CHANGE IN ADDRESS
```

EXAMPLE 2

```
RMCS1=176700 177200<CR> ;CHANGE BASE ADDRESS TO 177200
RMVEC=000254 260<CR>    ;CHANGE VECTOR ADDRESS TO 260
```

172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228

ON THE INITIAL START, THE NEXT QUESTION TYPED IS, 'TYPE 'A' TO TEST ALL DRIVES, OR TYPE DRIVE NUMBER(S) AND TERMINATE INPUT WITH A 'CARRIAGE RETURN'. THEN, 'DRIVE(S):' IS TYPED AND WAITS FOR THE OPERATOR TO TYPE AN 'A' TO TEST ALL POSSIBLE DRIVES OR TYPE ANY STRING OF DRIVE NUMBER(S) TO BE TESTED AND TERMINATE THE INPUT WITH A 'CARRIAGE RETURN'. NO COMMAS OR ANY OTHER SEPARATORS ARE NEEDED WHEN ENTERING THE DRIVE NUMBERS AS A STRING. THE PROGRAM ENTERS THE COMMA SEPARATOR AUTOMATICALLY AFTER TYPING EACH NUMBER. ON ALL SUBSEQUENT STARTS, ONLY THE 'DRIVE(S):' PROMPT IS TYPED.

THE DIAGNOSTIC THEN INITIALIZES AND REPORTS THE STATUS OF THE DRIVES WHICH WERE PREVIOUSLY SPECIFIED FOR TESTING. THE FOLLOWING IS AN EXAMPLE PRINTOUT:

```
'UNIT STATUS:
0   ONLINE   RM80
1   LOAD DEVICE
2   OFFLINE  RM80
3   NOT PRESENT
4   NOT PRESENT
5   NOT AN RM80
6   NOT PRESENT
7   NOT PRESENT'
```

THE ABOVE UNIT STATUS SHOWS THAT DRIVE 0 WILL BE TESTED, WHILE DRIVES 1 - 7 WILL NOT BE TESTED.

THE DIAGNOSTIC THEN TYPES THE FOLLOWING MESSAGE, BASED ON THE STATUS OF THE DRIVE:

```
'DRIVE(S) TO BE TESTED, 0'
```

IF NO DRIVES ARE AVAILABLE FOR TESTING, THE FOLLOWING MESSAGE WILL BE TYPED TO THE OPERATOR:

```
'DRIVE(S) TO BE TESTED, NONE'
```

THE PROGRAM WILL THEN, EITHER START TESTING THE DRIVES AVAILABLE FOR TESTING OR RETURN TO THE BEGINNING OF THE PROGRAM AND WAIT.

ONCE THE DRIVES START TESTING, THE FOLLOWING MESSAGE WILL OCCUR AS EACH DRIVE BEGINS TO BE TESTED:

```
'DRIVE 0'
```

AFTER ALL THE DRIVES ARE COMPLETELY TESTED, THE END OF PASS MESSAGE WILL BE TYPED (SEE SECTION 4.3) AND THE PROGRAM WILL START TESTING ALL THE DRIVES AGAIN. THIS WILL CONTINUE UNTIL THE PROGRAM IS HALTED BY THE OPERATOR.

NOTE: THE LETTER LOCATED WITHIN THE BRACKETS () INDICATES THE TYPE OF RESPONSE REQUIRED BY THE USER, D=DECIMAL, O=OCTAL AND L=LETTER.

4.3 PROGRESS REPORTS

229 AN END OF PASS REPORT OCCURS EACH TIME THE PROGRAM IS EXECUTED
 230 FOR ALL DEVICES IN THE TEST QUEUE. THE END OF PASS REPORT IS AS FOLLOWS.
 231

232 'END OF PASS 1'
 233

234 THE FOLLOWING MESSAGE WILL ALSO OCCUR IF THERE WERE ERRORS SINCE
 235 THE LAST END OF PASS REPORT.
 236

237 'TOTAL ERRORS SINCE LAST REPORT 0'
 238
 239

240 4.4 PERFORMANCE REPORT

241 NO PERFORMANCE REPORTS ARE GIVEN DURING THE EXECUTION OF THE
 242 PROGRAM.
 243

244 4.5 PROGRAM HALTS

245 THERE ARE NO SCHEDULED HALTS DURING THE EXECUTION OF THE PROGRAM.
 246 PROCESSOR HALTS ARE DUE TO THE TRAP CATCHER.
 247

248 4.6 ERROR REPORTS

249 THE FIRST LINE OF THE ERROR REPORT CONTAINS THE NUMBER OF THE
 250 UNIT (DRIVE) BEING TESTED, THE DRIVE TYPE, THE TEST NUMBER, THE ERROR
 251 NUMBER AND THE VALUE OF THE PROGRAM COUNTER WHERE THE ERROR WAS CALLED.
 252 THIS LINE IS FOLLOWED BY THE ERROR MESSAGE: ONE OR MORE LINES OF TEXT
 253 WHICH GIVE A BRIEF, YET COMPREHENSIVE DESCRIPTION OF THE ERROR. THE
 254 ERROR MESSAGE IS NORMALLY FOLLOWED BY ONE OR MORE PAIRS OF LINES
 255 CONTAINING DATA HEADERS AND DATA PERTINENT TO THE ERROR, INCLUDING
 256 EXPECTED AND ACTUAL TEST RESULTS.
 257

258 THE FOLLOWING PRINTOUT SHOWS A TYPICAL ERROR MESSAGE FOR THIS PROGRAM:
 259

```

260 DRV# 0 - RM80, TEST# 14, ERR# 326, PC=016654
261 MASSBUS DATA BUS PARITY ERROR 'MDPE' (RMCS2, BIT 8) DETECTED
262 DURING WRITE COMMAND
263 EXPECTD   RECEVD
264 040300   040700
265 RMCS1     RMCS2   RMD5   RMER1   RMER2   RMAS
266 144252   040700  010700  000000  000000  000000
267 RMWC      RMB8A   RMDA   RMOF   RMDC    RMEC1   RMEC2
268 177403   104604  000002  010000  000000  004066  000000
269 RMMR1     RMMR2   RMDT   RMSN
270 000010   011777  024026  177777
  
```

271 4.7 EXECUTION TIME

272 PASS 1 OF THE PROGRAM TAKES ABOUT 20 SECONDS. PASS 2 AND
 273 SUBSEQUENT PASSES TAKE 50 SECONDS.
 274
 275
 276
 277
 278
 279
 280
 281
 282
 283
 284
 285

286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342

5.0 ENVIRONMENTAL SUPPORT

5.1 PROCESSOR COMPATIBILITY

THE RM80 SUBSYSTEM FUNCTIONAL TEST IS EXECUTABLE ON A PDP-11/70 PROCESSOR, PROVIDING PREVIOUSLY MENTIONED HARDWARE REQUIREMENTS ARE MET, AND PROVIDING THAT DATA THROUGHPUT ON THE SYSTEM IS SUFFICIENT TO SUSTAIN DATA TRANSFER OPERATIONS.

5.2 DUAL PORT CONFIGURATIONS

THE RM80 SUBSYSTEM FUNCTIONAL TEST DOES NOT SPECIFICALLY TEST DUAL PORT LOGIC IN THE RM80 ADAPTER BUT IS EXECUTABLE ON RM80 SUBSYSTEMS HAVING THE DUAL PORT OPTION PROVIDING THE DUAL PORT SWITCH IS SET TO THE APPROPRIATE PORT (A OR B).

5.3 MEMORY PARITY HARDWARE

MEMORY PARITY HARDWARE IS NOT USED DURING THE EXECUTION OF THE RM80 SUBSYSTEM FUNCTIONAL TEST.

5.4 MEMORY MANAGEMENT HARDWARE

MEMORY MANAGEMENT HARDWARE IS NOT USED DURING THE RM80 SUBSYSTEM FUNCTIONAL TEST.

5.5 ACT11, APT11 COMPATIBILITY

THE RM80 SUBSYSTEM FUNCTIONAL TEST IS COMPATIBLE WITH ACT11 AND APT11 IN BOTH DUMP AND AUTOMATIC MODES. FURTHER, THE PROGRAM WILL EXECUTE A QUICK PASS DURING THE FIRST PASS IN SUPPORT OF QUICK VERIFY MODE.

5.6 XXDP COMPATIBILITY

THE RM80 SUBSYSTEM FUNCTIONAL TEST IS COMPATIBLE WITH XXDP IN DUMP AND CHAIN MODES, AND PROVIDES MEDIA PROTECTION IN THE CASE WHERE THE RM80 IS THE XXDP LOADING DEVICE.

5.7 OPERATING SYSTEM COMPATIBILITY

THE PROGRAM IS NOT COMPATIBLE WITH ANY SOFTWARE OPERATING SYSTEM.

343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399

6.0 TEST DESCRIPTION

TEST 1 CONTROLLER ACCESS TEST

PURPOSE:

TO VERIFY THAT THE UNIBUS ADDRESS OF THE RM80 SUBSYSTEM IS CORRECT, AS DEFINED AT LOCATION \$BASE.

PROCEDURE:

THE TEST TRIES TO ACCESS ALL MASSBUS CONTROLLER REGISTERS USING THE \$BASE ADDRESS. REGISTER CONTENTS ARE IGNORED DURING THE TEST, AND THE TEST FAILS IF A BUS TIMEOUT OCCURS FOR ANY REGISTER TRANSFER.

IF THE TEST FAILS AND THE PROGRAM IS RUNNING IN A STAND ALONE ENVIRONMENT, I.E., LOCATION 42 IS 0, THE PROGRAM WILL JUMP TO LOCATION 204 WHICH ALLOWS THE OPERATOR TO CHANGE THE \$BASE ADDRESS VIA CONSOLE DIALOGUE. OTHERWISE, THE PROGRAM ESCAPES TO THE END OF PASS HANDLER.

TEST 2 - 22 WRITE/READ DATA TESTS

PURPOSE:

TO TEST WRITE DATA AND READ DATA FUNCTIONALITY OF THE RM80 SUBSYSTEM USING A SET OF VARIABLES WHICH INCLUDE WORD COUNT, HEAD MOTION, HEAD SWITCHING AND ERROR CONDITIONS.

PROCEDURE:

ALTHOUGH EACH TEST EXERCISES A DIFFERENT VARIABLE, THE GENERAL PROCEDURE OF EACH TEST IS THE SAME. THE DRIVE IS INITIALIZED AND RECALIBRATED IF 'PIP' OR 'SKI' ARE ACTIVE SO THAT THERE ARE NO ERRORS WHEN A TEST BEGINS. THEN, THE TEST FORMATS THE SECTOR BEING USED, WHICH MAY VARY FROM THE PROGRAM LISTING, BECAUSE SECTORS ARE SUBSTITUTED DURING RUN TIME IF THE SELECTED SECTOR IS LISTED IN THE BAD BLOCK TABLE OF THE LAST TRACK. FOLLOWING THAT, THE TEST PERFORMS ANY EXPLICIT SEEKS REQUIRED FOR THE CONDITIONS OF THE TEST. REGISTERS ARE PRESET AND THE WRITE DATA COMMAND IS EXECUTED. WHEN THE WRITE COMMAND IS COMPLETE, THE TEST STORES ALL SUBSYSTEM STATUS AND CHECKS FOR PRIMARY ERRORS WHICH PRECLUDE OTHER STATUS CHECKS. IF THERE ARE NO PRIMARY ERRORS, THE TEST VERIFIES THE RESULTS OF THE WRITE COMMAND AND THEN CHECKS FOR SECONDARY ERRORS. LOOP ADDRESSES ARE

400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456

MODIFIED FOLLOWING THE SUCCESSFUL COMPLETION OF THE WRITE COMMAND IN ORDER TO SHORTEN EXECUTION TIMES AND ENHANCE SCOPING LOOPS, THEN THE PROGRAM EXECUTES THE READ DATA PORTION OF THE TEST, VERIFYING THE SAME TYPE OF ERRORS AS IN THE WRITE COMMAND.

NOTE: THE SECTOR USED DURING A TEST MAY DIFFER FROM THE PROGRAM LISTING BECAUSE THE PROGRAM SUBSTITUTES A GOOD SECTOR, IF THE ONE SELECTED IS LISTED IN THE BAD BLOCK TABLE.

TEST 2 WRITE, READ ZEROS TEST

THE TEST WRITES AND READS AN ALL ZEROS DATA FIELD, CAUSING THE DRIVE TO USE NORMAL WRITE GATE THROUGHOUT THE WRITE PROCESS.

TEST 3 WRITE, WRITE CHECK ZEROS TEST

THE TEST WRITES AND WRITE CHECKS AN ALL ZEROS DATA FIELD, VERIFYING THAT THERE ARE NO ERRORS.

TEST 4 WRITE, WRITE CHECK ZEROS W/ WCE ERROR TEST

THE TEST WRITES AN ALL ZEROS DATA FIELD, THEN COMPLEMENTS EACH BIT IN THE LAST WORD OF THE WRITE BUFFER. A WRITE CHECK COMMAND IS EXECUTED AND THE TEST VERIFIES THAT THE CORRECT WRITE CHECK ERROR IS DETECTED.

TEST 5 WRITE, READ ONES TEST

THE TEST WRITES AND READS AN ALL ONES DATA FIELD, CAUSING THE DRIVE TO USE NORMAL WRITE GATE THROUGHOUT THE WRITE PROCESS.

TEST 6 WRITE, WRITE CHECK ONES TEST

THE TEST WRITES AND WRITE CHECKS AN ALL ONES DATA FIELD.

457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513

TEST 7 WRITE, WRITE CHECK ONES W/ WCE ERROR TEST

THE TEST WRITES AN ALL ONES DATA FIELD, THEN PERFORMS A WRITE CHECK DATA COMMAND AFTER COMPLEMENTING EACH BIT IN THE LAST WORD OF THE WRITE BUFFER. THE TEST VERIFIES THAT THE CORRECT WRITE CHECK ERROR IS DETECTED.

TEST 10 WRITE, WRITE CHECK MULTIPLE SECTORS TEST

THE TEST SEEKS TO CYLINDER 559. TO INSURE THERE IS NO HEAD MOTION DURING DATA TRANSFER. THE WRITE DATA COMMAND FOLLOWS, WITH THE WORD COUNT EQUAL TO MULTIPLE SECTORS. THE SAME SECTORS ARE VERIFIED WITH A WRITE CHECK DATA COMMAND. THE TEST IS REPEATED FOR 16 BIT FORMAT WITH SSEI BIT SET.

TEST 11 WRITE, READ W/ IMPLIED SEEK TEST

THIS TEST SEEKS TO THE FIRST CYLINDER PRIOR TO WRITING DATA ON CYLINDER 559., TRACK 2 AND SECTOR 0. THE EXPLICIT SEEK INSURES THAT THERE WILL BE MAXIMUM HEAD MOTION DURING THE IMPLIED SEEK OF THE WRITE COMMAND. THE SAME OPERATION, INCLUDING THE EXPLICIT SEEK IS REPEATED FOR READ DATA.

TEST 12 READ, WRITE CHECK W/ HEAD SWITCHING TEST

THE TEST SEEKS TO CYLINDER 559. TO INSURE THERE IS NO HEAD MOTION DURING DATA TRANSFER. THE READ DATA COMMAND STARTS WITH CYLINDER 559., TRACK 2, SECTOR 30. THE WORD COUNT IS EQUAL TO MULTIPLE SECTORS WHICH CAUSES THE SUBSYSTEM TO SWITCH FROM TRACK 2 TO TRACK 3 AFTER THE FIRST SECTOR IS WRITTEN. THE SAME SECTORS ARE VERIFIED WITH A WRITE CHECK DATA COMMAND, USING THE SAME WORD COUNT AND STARTING SECTOR. IF THE 'SSE' BIT IS SET AFTER EXECUTING A DATA COMMAND, THE 16 BIT MODE WILL BE TERMINATED AND THE TEST IS REPEATED FOR 16 BIT FORMAT WITH THE SSEI BIT SET, WHERE SECTOR 31. IS THE LAST SECTOR. IF NO 'SSE' WAS SET, THEN BOTH FORMAT MODES WILL BE EXECUTED.

TEST 13 READ, WRITE CHECK W/ MID-TRANSFER SEEK TEST

514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570

THIS TEST READS MULTIPLE SECTORS STARTING WITH CYLINDER 559, LAST TRACK AND SECTOR 30, CAUSING A MID-TRANSFER SEEK AFTER THE FIRST OF THE MULTIPLE SECTORS ARE WRITTEN. THE SAME SECTORS ARE VERIFIED WITH A WRITE CHECK DATA COMMAND. IF THE 'SSE' BIT IS SET AFTER EXECUTING A DATA COMMAND, THE 16 BIT MODE WILL BE TERMINATED AND THE TEST IS REPEATED FOR 16 BIT FORMAT WITH THE SSEI BIT SET, WHERE SECTOR 31. IS THE LAST SECTOR. IF NO 'SSE' WAS SET, THEN BOTH FORMAT MODES WILL BE EXECUTED.

TEST 14 WRITE, READ W/ HCE ERROR TEST

A SECTOR IS FORMATTED WITH AN INCORRECT HEADER, THEN THE TEST WRITES AND READS DATA FROM THE SECTOR AND VERIFIES THAT THE CORRECT ERROR IS DETECTED. EACH BIT POSITION OF BOTH HEADER WORDS IS TESTED IN THIS MANNER.

TEST 15 WRITE, READ W/ HCI & SSEI TEST

A SECTOR IS FORMATTED WITH AN INCORRECT HEADER, THEN WRITTEN AND READ WITH HEADER COMPARE AND SKIP SECTOR ERROR INHIBITED. THE TEST VERIFIES THAT NO ERROR IS DETECTED.

TEST 16 WRITE, READ W/ IVC ERROR TEST

VOLUME VALID IS RESET BY SETTING AND RESETTING DIAGNOSTIC MODE. THE TEST THEN EXECUTES A WRITE DATA COMMAND AND VERIFIES THAT INVALID COMMAND STATUS SETS. THE TEST IS REPEATED FOR READ DATA COMMAND.

TEST 17 WRITE, READ W/ ABORT TEST

THE TEST SETS AN ERROR IN THE ERROR REGISTER AND EXECUTES A WRITE DATA COMMAND VERIFYING THAT 'PIP' REMAINS INACTIVE. THE SAME PROCEDURE IS USED FOR READ DATA COMMAND.

TEST 20 WRITE, READ EARLY PEAK SHIFT TEST

571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609

THIS TEST WRITES AND READS A SINGLE SECTOR USING A DATA PATTERN DESIGNED TO INTRODUCE EARLY PEAK SHIFT.

TEST 21 WRITE, READ EACH TRACK W/ MIXED PEAK SHIFT TEST

THE TEST WRITES AND READS WITH EACH TRACK USING A MIX OF EARLY, NORMAL AND LATE PEAK SHIFTS.

TEST 22 READ MULTIPLE SECTORS IN OFFSET MODE TEST

THE TEST EXECUTES READ DATA AND WRITE CHECK DATA COMMANDS IN OFFSET MODE IN BOTH OFFSET DIRECTIONS WITH THE TRANSFER SIZE OF TWO SECTORS AT A TIME.

TEST 23 FORMAT FE CYLINDERS

THIS TEST FORMATS BOTH FE CYLINDERS TO RE-ESTABLISH THE CORRECT FORMAT ON THE SECTORS THAT WERE WRITTEN UPON BY PREVIOUS TESTS. THE TEST IS DONE IN 16 BI1 FORMAT WITH THE SSEI BIT SET TO ALLOW ALL 32 SECTORS ON EACH TRACK TO BE FORMATTED.

1
487
488

```

:*LAST REVISION 08-OCT-81
.TITLE CZRNFAO RM80 FCTNL PT3
:*COPYRIGHT (C) 1982
:*DIGITAL EQUIPMENT CORPORATION
:*COLORADO SPGS., CO. 80919
:*
:*PROGRAM BY MIKE LEAVITT
:*
:*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
:*PACKAGE (MAINDEC-11-DZQAC-C5), 18-MAR-81

```

489

```

.SBTTL OPERATIONAL SWITCH SETTINGS
:*
:*      SWITCH      USE
:*      -----      -----
:*      15          HALT ON ERROR
:*      14          LOOP ON TEST
:*      13          INHIBIT ERRGR TYPEOUTS
:*      12          UNUSED
:*      11          INHIBIT ITERATIONS
:*      10          BELL ON ERROR
:*      9           LOOP ON ERROR
:*      8           LOOP ON TEST IN SWR<7:0>
490  *      7          TN128
:*      6          TN64
:*      5          TN32
:*      4          TN16
:*      3          TN8
:*      2          TN4
:*      1          TN2
491  *      0          TN1
492

```

.SBTTL BASIC DEFINITIONS

```

001100  :*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
104000  STACK = 1100
000004  ERROR = EMT          ;;BASIC DEFINITION OF ERROR CALL
        SCOPE = IOT       ;;BASIC DEFINITION OF SCOPE CALL

```

:*MISCELLANEOUS DEFINITIONS

```

000011  HT = 11          ;;CODE FOR HORIZONTAL TAB
000012  LF = 12          ;;CODE FOR LINE FEED
000015  CR = 15          ;;CODE FOR CARRIAGE RETURN
000200  CRLF = 200       ;;CODE FOR CARRIAGE RETURN-LINE FEED
177776  PS = 177776     ;;PROCESSOR STATUS WORD
177776  PSW=PS
177774  STKLMT = 177774  ;;STACK LIMIT REGISTER
177772  PIRQ = 177772   ;;PROGRAM INTERRUPT REQUEST REGISTER
177570  DSWR = 177570   ;;HARDWARE SWITCH REGISTER
177570  DDISP = 177570  ;;HARDWARE DISPLAY REGISTER

```

:*GENERAL PURPOSE REGISTER DEFINITIONS

```

000000  R0 = %0          ;;GENERAL REGISTER
000001  R1 = %1          ;;GENERAL REGISTER
000002  R2 = %2          ;;GENERAL REGISTER
000003  R3 = %3          ;;GENERAL REGISTER

```


000004	R4	=	%4	:: GENERAL REGISTER
000005	R5	=	%5	:: GENERAL REGISTER
000006	R6	=	%6	:: GENERAL REGISTER
000007	R7	=	%7	:: GENERAL REGISTER
000006	SP	=	%6	:: STACK POINTER
000007	PC	=	%7	:: PROGRAM COUNTER

.*PRIORITY LEVEL DEFINITIONS

000000	PR0	=	0	:: PRIORITY LEVEL 0
000040	PR1	=	40	:: PRIORITY LEVEL 1
000100	PR2	=	100	:: PRIORITY LEVEL 2
000140	PR3	=	140	:: PRIORITY LEVEL 3
000200	PR4	=	200	:: PRIORITY LEVEL 4
000240	PR5	=	240	:: PRIORITY LEVEL 5
000300	PR6	=	300	:: PRIORITY LEVEL 6
000340	PR7	=	340	:: PRIORITY LEVEL 7

.*"SWITCH REGISTER" SWITCH DEFINITIONS

100000	SW15	=	100000
040000	SW14	=	40000
020000	SW13	=	20000
010000	SW12	=	10000
004000	SW11	=	4000
002000	SW10	=	2000
001000	SW09	=	1000
000400	SW08	=	400
000200	SW07	=	200
000100	SW06	=	100
000040	SW05	=	40
000020	SW04	=	20
000010	SW03	=	10
000004	SW02	=	4
000002	SW01	=	2
000001	SW00	=	1
001000	SW9=SW09		
000400	SW8=SW08		
000200	SW7=SW07		
000100	SW6=SW06		
000040	SW5=SW05		
000020	SW4=SW04		
000010	SW3=SW03		
000004	SW2=SW02		
000002	SW1=SW01		
000001	SW0=SW00		

.*DATA BIT DEFINITIONS (BIT00 TO BIT15)

100000	BIT15	=	100000
040000	BIT14	=	40000
020000	BIT13	=	20000
010000	BIT12	=	10000
004000	BIT11	=	4000
002000	BIT10	=	2000
001000	BIT09	=	1000
000400	BIT08	=	400
000200	BIT07	=	200
000100	BIT06	=	100
000040	BIT05	=	40

```

000020 BIT04 = 20
000010 BIT03 = 10
000004 BIT02 = 4
000002 BIT01 = 2
000001 BIT00 = 1
001000 BIT9=BIT09
000400 BIT8=BIT08
000200 BIT7=BIT07
000100 BIT6=BIT06
000040 BIT5=BIT05
000020 BIT4=BIT04
000010 BIT3=BIT03
000004 BIT2=BIT02
000002 BIT1=BIT01
000001 BIT0=BIT00
    
```

```

;*BASIC "CPU" TRAP VECTOR ADDRESSES
000004 ERRVEC = 4          ;;TIME OUT AND OTHER ERRORS
000010 RESVEC = 10       ;;RESERVED AND ILLEGAL INSTRUCTIONS
000014 TBITVEC = 14      ;;'T' BIT
000014 TRTVEC = 14       ;;TRACE TRAP
000014 BPTVEC = 14       ;;BREAKPOINT TRAP (BPT)
000020 IOTVEC = 20       ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024 PWRVEC = 24       ;;POWER FAIL
000030 EMTVEC = 30       ;;EMULATOR TRAP (EMT) **ERROR**
000034 TRAPVEC = 34      ;;"TRAP" TRAP
000060 TKVEC = 60        ;;TTY KEYBOARD VECTOR
000064 TPVEC = 64        ;;TTY PRINTER VECTOR
000240 PIRQVEC = 240     ;;PROGRAM INTERRUPT REQUEST VECTOR
    
```

493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520

.SBTTL RM80 REGISTER BIT DEFINITIONS

;*RMCS1 CONTROL STATUS REGISTER

```

004000 DVA = BIT11          ;;DEVICE AVAILABLE-READ ONLY
000040 F4 = BIT05       ;;FUNCTION CODE
000020 F3 = BIT04       ;;FUNCTION CODE
000010 F2 = BIT03       ;;FUNCTION CODE
000004 F1 = BIT02       ;;FUNCTION CODE
000002 F0 = BIT01       ;;FUNCTION CODE
000001 GO = BIT00       ;;GO BIT
000077 FNCMSK = 000077 ;;FUNCTION CODE MASK
    
```

;;FUNCTION CODES (BITS 01-05 OF RMCS1)

```

000000 NOP = 000000     ;;NOP COMMAND
000002 ILF02 = 000002  ;;ILLEGAL COMMAND
000004 SEEK = 000004   ;;SEEK COMMAND
000006 RECAL = 000006  ;;RECALIBRATE COMMAND
000010 DRVCLR = 000010 ;;DRIVE CLEAR COMMAND
000012 RELEASE = 000012 ;;RELEASE COMMAND
000014 OFFSET = 000014 ;;OFFSET COMMAND
000016 RTC = 000016   ;;RETURN TO CENTERLINE COMMAND
000020 RIP = 000020   ;;READ IN PRESET COMMAND
000022 PAKACK = 000022 ;;PACK ACKNOWLEDGE COMMAND
000022 PACACK = PAKACK
000024 ILF24 = 000024  ;;ILLEGAL COMMAND
000026 ILF26 = 000026  ;;ILLEGAL COMMAND
    
```

521	000030	SEARCH	= 000030	:SEARCH COMMAND
524	000030	ILF30	= 000030	:ILLEGAL COMMAND
	000032	ILF32	= 000032	:ILLEGAL COMMAND
	000034	ILF34	= 000034	:ILLEGAL COMMAND
	000036	ILF36	= 000036	:ILLEGAL COMMAND
	000040	ILF40	= 000040	:ILLEGAL COMMAND
	000042	ILF42	= 000042	:ILLEGAL COMMAND
	000044	ILF44	= 000044	:ILLEGAL COMMAND
	000046	ILF46	= 000046	:ILLEGAL COMMAND
525	000050	WCD	= 000050	:WRITE CHECK DATA COMMAND
526	000052	WCH	= 000052	:WRITE CHECK HEADER AND DATA
527	000054	ILF54	= 000054	:ILLEGAL COMMAND
528	000056	ILF56	= 000056	:ILLEGAL COMMAND
529	000060	WD	= 000060	:WRITE DATA COMMAND
530	000062	WH	= 000062	:WRITE HEADER AND DATA COMMAND
531	000064	ILF64	= 000064	:ILLEGAL COMMAND
532	000066	ILF66	= 000066	:ILLEGAL COMMAND
533	000070	RD	= 000070	:READ DATA COMMAND
534	000072	RH	= 000072	:READ HEADER AND DATA COMMAND
535	000074	ILF74	= 000074	:ILLEGAL COMMAND
536	000076	ILF76	= 000076	:ILLEGAL COMMAND
537				
538		:*RMDA DISK ADDRESS REGISTER		
539				
540		:TRACK ADDRESS DEFINITIONS		
541	004000	TA8	= BIT11	:TRACK ADDRESS 8.
542	002000	TA4	= BIT10	:TRACK ADDRESS 4
543	001000	TA2	= BIT09	:TRACK ADDRESS 2
544	000400	TA1	= BIT08	:TRACK ADDRESS 1
545				
546		:SECTOR ADDRESS DEFINITIONS		
547	000020	SA16	= BIT04	:SECTOR ADDRESS 16.
548	000010	SA8	= BIT03	:SECTOR ADDRESS 8.
549	000004	SA4	= BIT02	:SECTOR ADDRESS 4
550	000002	SA2	= BIT01	:SECTOR ADDRESS 2
551	000001	SA1	= BIT00	:SECTOR ADDRESS 1
552				
553		:TRACK & SECTOR MASKS		
554	177400	TADMSK	= 177400	:TRACK ADDRESS MASK
555	000377	SADMSK	= 000377	:SECTOR ADDRESS MASK
556				
557		:*RMDS DRIVE STATUS REGISTER		
558				
559	100000	ATA	= BIT15	:ATTENTION ACTIVE
560	040000	ERR	= BIT14	:COMPOSITE ERROR
561	020000	PIP	= BIT13	:POSITIONING IN PROGRESS
562	010000	MOL	= BIT12	:MEDIUM ON LINE
563	004000	WRL	= BIT11	:WRITE LOCK
564	002000	LBT	= BIT10	:LAST BLOCK TRANSFERRED
565	001000	PGM	= BIT09	:PROGRAMMABLE
566	000400	DPR	= BIT08	:DRIVE PRESENT
567	000200	DRY	= BIT07	:DRIVE READY
568	000100	VV	= BIT06	:VOLUME VALID
569	000001	OM	= BIT00	:OFFSET MODE ACTIVE
570				
571		:*RMER1 ERROR REGISTER #1		
572				

573	100000	DCK	= BIT15	;DATA CHECK ERROR
574	040000	UNS	= BIT14	;DRIVE UNSAFE
575	020000	OPI	= BIT13	;OPERATION INCOMPLETE
576	010000	DTE	= BIT12	;DRIVE TIMING ERROR
577	004000	WLE	= BIT11	;WRITE LOCK ERROR
578	002000	IAE	= BIT10	;INVALID ADDRESS ERROR
579	001000	AOE	= BIT09	;ADDRESS OVERFLOW ERROR
580	000400	HCRC	= BIT08	;HEADER CRC ERROR
581	000200	HCE	= BIT07	;HEADER COMPARE ERROR
582	000100	ECH	= BIT06	;ECC 'HARD' ERROR
583	000040	WCF	= BIT05	;WRITE CLOCK FAILURE
584	000020	FER	= BIT04	;FORMAT ERROR
585	000010	PA:	= BIT03	;PARITY ERROR
586	000004	RMR	= BIT02	;REGISTER MODIFICATION REFUSED
587	000002	ILR	= BIT01	;ILLEGAL REGISTER
588	000001	ILF	= BIT00	;ILLEGAL FUNCTION
589				
590	115760	NDTMSK	= DCK!DTE!WLE!AOE!HCRC!HCE!ECH!WCF!FER	
591			;'NDTMSK' IS USED TO MASK ERROR REGISTER 1 DURING NON - DATA	
592			;COMMANDS, I.E., HOUSEKEEPING AND POSITIONING COMMANDS	
593				
594			;*RMAS ATTENTION SUMMARY REGISTER	
595				
596	000377	ATNMSK	= 377	;MASK FOR ATTENTION BITS
597				
598			;*RMLA LOOK AHEAD REGISTER	
599				
600	002000	SC4	= BIT10	;SECTOR COUNT = 16
601	001000	SC3	= BIT09	;SECTOR COUNT = 8
602	000400	SC2	= BIT08	;SECTOR COUNT = 4
603	000200	SC1	= BIT07	;SECTOR COUNT = 2
604	000100	SC0	= BIT06	;SECTOR COUNT = 1
605				
606	003700	SCTMSK	= 003700	;SECTOR COUNT MASK
607				
608			;*RMR1 MAINTENANCE REGISTER #1	
609				
610			;WRITE ONLY BITS	
611	100000	DBCK	= BIT15	;DEBUG CLOCK
612	040000	DBEN	= BIT14	;DEBUG CLOCK ENABLE
613	020000	DEBL	= BIT13	;DIAGNOSTIC END OF BLOCK
614	010000	DTO	= BIT12	;DIAGNOSTIC TIMEOUT
615	004000	MCLK	= BIT11	;MAINTENANCE CLOCK
616	002000	MRD	= BIT10	;READ DATA
617	001000	MUR	= BIT09	;UNIT READY
618	000400	MOC	= BIT08	;ON CYLINDER
619	000200	MSER	= BIT07	;SEEK ERROR
620	000100	MDF	= BIT06	;DRIVE FAULT
621	000040	MS	= BIT05	;SECTOR PULSE
622	000010	MWP	= BIT03	;WRITE PROTECT
623	000004	MI	= BIT02	;INDEX PULSE
624	000002	MSC	= BIT01	;SECTOR COMPARE
625	000001	DMD	= BIT00	;DIAGNOSTIC MODE
626				
627			;READ ONLY BITS	
628	100000	OCC	= BIT15	;OCCUPIED
629	040000	RG	= BIT14	;RUN AND GO

630	020000	EBL	= BIT13	:END OF BLOCK
631	010000	REX	= BIT12	:EXCEPTION
632	004000	ESRC	= BIT11	:ENABLE SEARCH
633	002000	PLFS	= BIT10	:LOOKING FOR SYNC
634	001000	ECRC	= BIT09	:ENABLE CRC OUT
635	000400	PDA	= BIT08	:DATA AREA
636	000200	PHA	= BIT07	:HEADER AREA
637	000100	CONT	= BIT06	:CONTINUE
638	000040	WC	= BIT05	:WORD CLOCK
639	000020	EECC	= BIT04	:ENABLE ECC OUT
640	000010	MWD	= BIT03	:WRITE DATA BIT
641	000004	LS	= BIT02	:LAST SECTOR
642	000002	LST	= BIT01	:LAST SECTOR AND TRACK
643	000001	DMD	= BIT00	:DIAGNOSTIC MODE
644				
645		;*RMDT DRIVE TYPE REGISTER		
646				
647	100000	NSA	= BIT15	:NOT SECTOR ADDRESSED = 0
648	040000	TAP	= BIT14	:TAPE DRIVE = 0
649	020000	MOH	= BIT13	:MOVING HEAD = 1
650	004000	DRQ	= BIT11	:DRIVE REQUEST REQUIRED
651				
652	020026	SNGPRT	= 020026	:SINGLE PORT DRIVE TYPE
653	024026	DULPRT	= 024026	:DUAL PORT DRIVE TYPE
654				
655		;*RMOF OFFSET REGISTER		
656				
657	010000	FMT16	= BIT12	:16 BIT WORD FORMAT
658	004000	ECI	= BIT11	:ECC INHIBIT
659	002000	HCI	= BIT10	:HEADER COMPARE INHIBIT
660	001000	SSEI	= BIT09	:SKIP SECTOR ERROR INHIBIT
661	000200	OFD	= BIT07	:OFFSET FORWARD
662				
663		;*RMDC DESIRED CYLINDER ADDRESS REGISTER		
664				
665	001777	CYLMASK	= 001777	:MASK FOR CYLINDER ADDRESS
666				
667		;*RMMR2 MAINTENANCE REGISTER #2		
668				
669		:READ ONLY BITS		
670	100000	RQA	= BIT15	:PORT A REQUEST
671	040000	RQB	= BIT14	:PORT B REQUEST
672	020000	TAG	= BIT13	:TAG CONTROL
673	010000	TST	= BIT12	:COMMAND SEQUENCE TEST BIT
674	004000	CC	= BIT11	:CONTROL OR CYLINDER TAG
675	002000	CH	= BIT10	:CONTROL OR HEAD TAG
676	001000	BB09	= BIT09	:TAG BUS
677	000400	BB08	= BIT08	:TAG BUS
678	000200	BB07	= BIT07	:TAG BUS
	000100	BB06	= BIT06	:TAG BUS
	000040	BB05	= BIT05	:TAG BUS
	000020	BB04	= BIT04	:TAG BUS
	000010	BB03	= BIT03	:TAG BUS
	000004	BB02	= BIT02	:TAG BUS
	000002	BB01	= BIT01	:TAG BUS
	000001	BB00	= BIT00	:TAG BUS
679				

```

680          ;*RMER2 ERROR REGISTER 2
681
682          100000      BSE      = BIT15      ;BAD SECTOR ERROR
683          040000      SKI      = BIT14      ;SEEK INCOMPLETE
684          020000      OPE      = BIT13      ;OPERATOR PLUG ERROR
685          0100C0      IVC      = BIT12      ;INVALID COMMAND ERROR
686          004000      LSC      = BIT11      ;LOSS OF SYSTEM CLOCK
687          002000      LBC      = BIT10      ;LOSS OF BIT CLOCK
688          000200      DVC      = BIT07      ;DEVICE CHECK
689          000040      SSE      = BIT05      ;SKIP SECTOR ERROR
690          000010      DPE      = BIT03      ;DATA PARITY ERROR
691
692          .SBTTL  PROGRAM MNEMONICS
693
694          100000      MSE      = BIT15      ;MANUFACTURING DETECTED SECTOR ERROR
695          040000      USE      = BIT14      ;USER DETECTED SECTOR ERROR
696          020000      SSF      = BIT13      ;SKIP SECTOR FAILURE
697
698          .SBTTL  RM80 REGISTER INDEX VALUES
699
700          000000      RMCS1    = 00        ;CONTROL STATUS REGISTER #1
701          000006      RMDA     = 06        ;DISK ADDRESS REGISTER
702          000012      RMDS     = 12        ;DRIVE STATUS REGISTER
703          000014      RMER1    = 14        ;ERROR REGISTER #1
704          000016      RMAS     = 16        ;ATTENTION SUMMARY REGISTER
705          000020      RMLA     = 20        ;LOOK AHEAD REGISTER
706          000024      RMMR1    = 24        ;MAINTENANCE REGISTER
707          000026      RMDT     = 26        ;DRIVE TYPE REGISTER
708          000030      RMSN     = 30        ;SERIAL NUMBER REGISTER
709          000032      RMOF     = 32        ;OFFSET REGISTER
710          000034      RMDC     = 34        ;DESIRED CYLINDER REGISTER
711          000036      RMR      = 36        ;HOLDING REGISTER
712          000040      RMMR2    = 40        ;MAINTENANCE REGISTER #2
713          000042      RMER2    = 42        ;ERROR REGISTER #2
714          000044      RMEC1    = 44        ;ECC POSITION REGISTER
715          000046      RMEC2    = 46        ;ECC PATTERN REGISTER
716          000050      ILRG50    = 50        ;ILLEGAL REGISTER 50
717          000052      ILRG52    = 52        ;ILLEGAL REGISTER 52
718          000054      ILRG54    = 54        ;ILLEGAL REGISTER 54
719          000056      ILRG56    = 56        ;ILLEGAL REGISTER 56
720          000060      ILRG60    = 60        ;ILLEGAL REGISTER 60
721          000062      ILRG62    = 62        ;ILLEGAL REGISTER 62
722          000064      ILRG64    = 64        ;ILLEGAL REGISTER 64
723          000066      ILRG66    = 66        ;ILLEGAL REGISTER 66
724          000070      ILRG70    = 70        ;ILLEGAL REGISTER 70
725          000072      ILRG72    = 72        ;ILLEGAL REGISTER 72
726          000074      ILRG74    = 74        ;ILLEGAL REGISTER 74
727          000076      ILRG76    = 76        ;ILLEGAL REGISTER 76
728
729          000077      IDXMSK    = 77        ;MASK FOR REGISTER INDEX NUMBER
730
731          .SBTTL  RH CONTROLLER REGISTER BIT DEFINITIONS
732
733          ;*RMCS1 CONTROL STATUS REGISTER #1
734
735          100000      SC        = BIT15      ;SPECIAL CONDITION-READ ONLY
736          040000      TRE        = BIT14      ;TRANSFER ERROR
  
```

728	020000	MCPE	= BIT13	:MASSBUS CONTROL BUS PARITY ERROR-READ ONLY
729	002000	PSEL	= BIT10	:PORT B SELECT
730	001000	A17	= BIT09	:ADDRESS EXTENSION
731	000400	A16	= BIT08	:ADDRESS EXTENSION
732	000200	RDY	= BIT07	:READY-READ ONLY
733	000100	IE	= BIT06	:INTERRUPT ENABLE
734				
735		:*RMCS2 RH CONTROL STATUS REGISTER #2		
736				
737	100000	DLT	= BIT15	:DATA LATE-READ ONLY
738	040000	WCE	= BIT14	:WRITE CHECK ERROR-READ ONLY
739	020000	UPE	= BIT13	:UNIBUS PARITY ERROR
740	010000	NED	= BIT12	:NONEXISTANT DRIVE-READ ONLY
741	004000	NEM	= BIT11	:NONEXISTANT MEMORY-READ ONLY
742	002000	PGE	= BIT10	:PROGRAM ERROR-READ ONLY
743	001000	MXF	= BIT09	:MISSED TRANSFER
744	000400	MDPE	= BIT08	:MASSBUS DATA BUS PARITY ERROR-READ ONLY
745	000200	OR	= BIT07	:OUTPUT READY-READ ONLY
746	000100	IR	= BIT06	:INPUT READY-READ ONLY
747	000040	CLR	= BIT05	:CONTROLLER CLEAR
748	000020	PAT	= BIT04	:PARITY TEST
749	000010	BAI	= BIT03	:UNIBUS ADDRESS INCREMENT INHIBIT
752	000004	U2	= BIT02	:UNIT SELECT
	000002	U1	= BIT01	:UNIT SELECT
	000001	U0	= BIT00	:UNIT SELECT
753				
754		:UNIT SELECT MASK		
755				
756	000007	UNTMSK	= 7	:UNIT SELECT MASK
757				
758		:*RMCS3 RH70 CONTROL STATUS REGISTER #3		
759				
760	100000	APE	= BIT15	:ADDRESS PARITY ERROR
761	040000	DPEHI	= BIT14	:DATA PARITY ERROR HIGH WORD
762	020000	DPELO	= BIT13	:DATA PARITY ERROR LOW WORD
763	010000	WCEHI	= BIT12	:WRITE CHECK ERROR HIGH WORD
764	004000	WCELO	= BIT11	:WRITE CHECK ERROR LOW WORD
765	002000	DBL	= BIT10	:DOUBLE WORD TRANSFER
766	000100	IE	= BIT06	:INTERRUPT ENABLE
767	000010	IPCK3	= BIT03	:INVERT PARITY CHECK
768	000004	IPCK2	= BIT02	:INVERT PARITY CHECK
769	000002	IPCK1	= BIT01	:INVERT PARITY CHECK
770	000001	IPCK0	= BIT00	:INVERT PARITY CHECK
771				
772		.SBTTL RH CONTROLLER REGISTER INDEX VALUES		
773				
774	000000	RMCS1	= 00	:CONTROL, STATUS REGISTER #1
775	000002	RMWC	= 02	:WORD COUNT REGISTER
776	000004	RMBA	= 04	:BUS ADDRESS REGISTER
777	000010	RMCS2	= 10	:CONTROL, STATUS REGISTER #2
778	000022	RMDB	= 22	:DATA BUFFER
779	000050	RMBAE	= 50	:BUS ADDRESS EXTENSION
780	000052	RMCS3	= 52	:CONTROL, STATUS REGISTER #3
781				
782	176700	ABASE	= 176700	:UNIBUS ADDRESS
783	120254	AVECT1	= 120254	:UNIBUS VECTOR ADDRESS AND PRIORITY
784				

1
2
3
4
5
6
7
8
9

000000
000174 000174
000176 000000
000176 000000

000200 000137 005434
000204 000137 005424

000046 000210
000052 000046
000052 033756
000052 000052
000052 000000
000052 000210

001100

000024 001100
000024 000024
000024 000200
000044 000044
000044 001100
001100 001100
001100 000000
001102 001222
001104 000024
001106 000024
001110 000024
001112 000042
001112 001114

```
.SBTTL TRAP CATCHER
      .=0
      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
DISPREG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
SWREG:   .WORD 0      ;;SOFTWARE SWITCH REGISTER

.SBTTL STARTING ADDRESS(ES)
      JMP @#START      ;;JUMP TO STARTING ADDRESS OF PROGRAM
      JMP @#START1     ;;CHANGE RH/RM BUS ADDRESS

.SBTTL ACT11 HOOKS
      ;*****
      ;HOOKS REQUIRED BY ACT11
      $SVPC=.          ;;SAVE PC
      .=46             ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
      $ENDAD
      .=52             ;;2)SET LOC.52 TO ZERO
      .WORD 0          ;;RESTORE PC
      .=$SVPC

      .=1100
.SBTTL APT PARAMETER BLOCK
      ;*****
      ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
      ;*****
      .SX=.            ;;SAVE CURRENT LOCATION
      .=24             ;;SET POWER FAIL TO POINT TO START OF PROGRAM
      200              ;;FOR APT START UP
      .=44             ;;POINT TO APT INDIRECT ADDRESS PNTR.
      $APTHDR          ;;POINT TO APT HEADER BLOCK
      .=$SX            ;;RESET LOCATION COUNTER
      ;*****
      ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
      ;INTERFACE SPEC.

      $APTHD:
      $HIBTS: .WORD 0   ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
      $MADR:  .WORD $MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)
      $STMT:  .WORD 20.  ;;RUN TIME OF LONGEST TEST
      $PASTM: .WORD 20.  ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
      $UNITM: .WORD 20.  ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDED UNIT
      .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)

      TAGADR=.
```


0

.SBTTL COMMON TAGS

 : *THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
 : *USED IN THE PROGRAM.

001114 001114
 001114 000000
 001116 000
 001117 000
 001120 000000
 001122 000000
 001124 000000
 001126 000000
 001130 000
 001131 001
 001132 000000
 001134 000000
 001136 000000
 001140 000000
 001142 000000
 001144 000000
 001146 000000
 001150 000
 001151 000
 001152 000000
 001154 177570
 001156 177570
 001160 177560
 001162 177562
 001164 177564
 001166 177566
 001170 000
 001171 002
 001172 012
 001173 000
 001174 000000
 001176 000000
 001200 000000
 001202 000000
 001204 000000
 001206 000000
 001210 000000
 001212 207
 001216 077
 001217 015
 001220 012

377 377
 000

.=TAGADR

SCMTAG: .WORD 0
 STSTNM: .BYTE 0
 SERFLG: .BYTE 0
 SICNT: .WORD 0
 \$LPADR: .WORD 0
 \$LPERR: .WORD 0
 \$ERTTL: .WORD 0
 \$ITEMB: .BYTE 0
 \$ERMAX: .BYTE 1
 \$ERRPC: .WORD 0
 \$GDADR: .WORD 0
 \$BDADR: .WORD 0
 \$GDDAT: .WORD 0
 \$BDDAT: .WORD 0
 SAUTOB: .BYTE 0
 \$INTAG: .BYTE 0
 SWR: .WORD DSWR
 DISPLAY: .WORD DDISP
 \$TKS: 177560
 \$TKB: 177562
 \$TPS: 177564
 \$TPB: 177566
 \$NULL: .BYTE 0
 \$FILLS: .BYTE 2
 \$FILLC: .BYTE 12
 \$TPFLG: .BYTE 0
 \$TMP0: .WORD 0
 \$TMP1: .WORD 0
 \$TMP2: .WORD 0
 \$TMP3: .WORD 0
 \$TMP4: .WORD 0
 \$TIMES: 0
 \$ESCAPE: 0
 \$BELL: .ASCIZ <207><377><377>
 \$QUES: .ASCII /?/
 \$CRLF: .ASCII <15>
 \$LF: .ASCIZ <12>

:::START OF COMMON TAGS
 :::CONTAINS THE TEST NUMBER
 :::CONTAINS ERROR FLAG
 :::CONTAINS SUBTEST ITERATION COUNT
 :::CONTAINS SCOPE LOOP ADDRESS
 :::CONTAINS SCOPE RETURN FOR ERRORS
 :::CONTAINS TOTAL ERRORS DETECTED
 :::CONTAINS ITEM CONTROL BYTE
 :::CONTAINS MAX. ERRORS PER TEST
 :::CONTAINS PC OF LAST ERROR INSTRUCTION
 :::CONTAINS ADDRESS OF 'GOOD' DATA
 :::CONTAINS ADDRESS OF 'BAD' DATA
 :::CONTAINS 'GOOD' DATA
 :::CONTAINS 'BAD' DATA
 :::RESERVED--NOT TO BE USED
 :::AUTOMATIC MODE INDICATOR
 :::INTERRUPT MODE INDICATOR
 :::ADDRESS OF SWITCH REGISTER
 :::ADDRESS OF DISPLAY REGISTER
 :::TTY KBD STATUS
 :::TTY KBD BUFFER
 :::TTY PRINTER STATUS REG. ADDRESS
 :::TTY PRINTER BUFFER REG. ADDRESS
 :::CONTAINS NULL CHARACTER FOR FILLS
 :::CONTAINS # OF FILLER CHARACTERS REQUIRED
 :::INSERT FILL CHARS. AFTER A 'LINE FEED'
 :::'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
 :::USER DEFINED
 :::USER DEFINED
 :::USER DEFINED
 :::USER DEFINED
 :::USER DEFINED
 :::MAX. NUMBER OF ITERATIONS
 :::ESCAPE ON ERROR ADDRESS
 :::CODE FOR BELL
 :::QUESTION MARK
 :::CARRIAGE RETURN
 :::LINE FEED

 .SBTTL APT MAILBOX-ETABLE

001222
 001222 000000
 001224 000000
 001226 000000

:::*****
 .EVEN
 \$MAIL: .WORD .WORD .WORD
 \$MSGTY: .WORD AMSGTY :::APT MAILBOX
 \$FATAL: .WORD AFATAL :::MESSAGE TYPE CODE
 \$TESTN: .WORD ATESTN :::FATAL ERROR NUMBER
 :::TEST NUMBER

001230	000000	\$PASS:	.WORD	APASS	::PASS COUNT
001232	000000	\$DEVCT:	.WORD	ADEVCT	::DEVICE COUNT
001234	000000	\$UNIT:	.WORD	AUNIT	::I/O UNIT NUMBER
001236	000000	\$MSGAD:	.WORD	AMSGAD	::MESSAGE ADDRESS
001240	000000	\$MSGLG:	.WORD	AMSGLG	::MESSAGE LENGTH
001242		\$ETABLE:			::APT ENVIRONMENT TABLE
001242	000	\$ENV:	.BYTE	AENV	::ENVIRONMENT BYTE
001243	000	\$ENVM:	.BYTE	AENVM	::ENVIRONMENT MODE BITS
001244	000000	\$SWREG:	.WORD	ASWREG	::APT SWITCH REGISTER
001246	000000	\$USWR:	.WORD	AUSWR	::USER SWITCHES
001250	000000	\$CPUOP:	.WORD	ACPUOP	::CPU TYPE,OPTIONS
		*			BITS 15-11=CPU TYPE
		*			11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
		*			11/70=06,PDQ=07,0=10
		*			BIT 10=REAL TIME CLOCK
		*			BIT 9=FLOATING POINT PROCESSOR
		*			BIT 8=MEMORY MANAGEMENT
001252	000	\$MAMS1:	.BYTE	AMAMS1	::HIGH ADDRESS,M.S. BYTE
001253	000	\$MTYP1:	.BYTE	AMTYP1	::MEM. TYPE,BLK#1
		*			MEM.TYPE BYTE -- (HIGH BYTE)
		*			900 NSEC CORE=001
		*			300 NSEC BIPOLAR=002
		*			500 NSEC MOS=003
001254	000000	\$MADR1:	.WORD	AMADR1	::HIGH ADDRESS,BLK#1
		*			MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
001256	000	\$MAMS2:	.BYTE	AMAMS2	::HIGH ADDRESS,M.S. BYTE
001257	000	\$MTYP2:	.BYTE	AMTYP2	::MEM. TYPE,BLK#2
001260	000000	\$MADR2:	.WORD	AMADR2	::MEM.LAST ADDRESS,BLK#2
001262	000	\$MAMS3:	.BYTE	AMAMS3	::HIGH ADDRESS,M.S.BYTE
001263	000	\$MTYP3:	.BYTE	AMTYP3	::MEM. TYPE,BLK#3
001264	000000	\$MADR3:	.WORD	AMADR3	::MEM.LAST ADDRESS,BLK#3
001266	000	\$MAMS4:	.BYTE	AMAMS4	::HIGH ADDRESS,M.S.BYTE
001267	000	\$MTYP4:	.BYTE	AMTYP4	::MEM. TYPE,BLK#4
001270	000000	\$MADR4:	.WORD	AMADR4	::MEM.LAST ADDRESS,BLK#4
001272	120254	\$VECT1:	.WORD	AVECT1	::INTERRUPT VECTOR#1,BUS PRIORITY#1
001274	000000	\$VECT2:	.WORD	AVECT2	::INTERRUPT VECTOR#2BUS PRIORITY#2
001276	176700	\$BASE:	.WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
001300	000000	\$DEVW:	.WORD	ADEVW	::DEVICE MAP
001302	000000	\$CDW1:	.WORD	ACDW1	::CONTROLLER DESCRIPTION WORD#1
001304	000000	\$CDW2:	.WORD	ACDW2	::CONTROLLER DESCRIPTION WORD#2
001306	000000	\$DDW0:	.WORD	ADDW0	::DEVICE DESCRIPTOR WORD#0
001310	000000	\$DDW1:	.WORD	ADDW1	::DEVICE DESCRIPTOR WORD#1
001312	000000	\$DDW2:	.WORD	ADDW2	::DEVICE DESCRIPTOR WORD#2
001314	000000	\$DDW3:	.WORD	ADDW3	::DEVICE DESCRIPTOR WORD#3
001316	000000	\$DDW4:	.WORD	ADDW4	::DEVICE DESCRIPTOR WORD#4
001320	000000	\$DDW5:	.WORD	ADDW5	::DEVICE DESCRIPTOR WORD#5
001322	000000	\$DDW6:	.WORD	ADDW6	::DEVICE DESCRIPTOR WORD#6
001324	000000	\$DDW7:	.WORD	ADDW7	::DEVICE DESCRIPTOR WORD#7
001326		\$ETEND:			
		.MEXIT			

.SBTTL USER DEFINED TAGS

001326	000000	CTLFG:	.WORD	0	:CONTAINS CONTROL-C FLAG
001330	000000	CHGADR:	.WORD	0	:CHANGE RH/RM BUS ADDRESS = -1, NO CHANGE = 0
001332	000000	XXDP:	.WORD	0	:THE LOW BYTE CONTAINS THE DRIVE NUMBER FROM WHICH :THE PROGRAM WAS LOADED. THE HIGH BYTE CONTAINS THE : 'XXDP' DEVICE CODE FOR THE RM80.
001334	000	LSTRK:	.BYTE	0	:LO BYTE = 0
001335	015		.BYTE	13.	:HI BYTE, CONTAINS LAST TRACK ADDRESS OF UNIT :UNDER TEST. RM80 = 13.

:THE REGISTER INPUT BUFFER IS USED FOR
 :STORING DRIVE STATUS

001336

GETBUF:

					:REGISTER INPUT BUFFER
001336	000000	RMCS1I:	.WORD	0	:CONTROL, STATUS REGISTER #1
001340	000000	RMWCI:	.WORD	0	:WORD COUNT REGISTER
001342	000000	RMBAI:	.WORD	0	:BUS ADDRESS REGISTER
001344	000000	RMDAI:	.WORD	0	:DISK ADDRESS REGISTER
001346	000000	RMCS2I:	.WORD	0	:CONTROL, STATUS REGISTER #2
001350	000000	RMDSI:	.WORD	0	:DRIVE STATUS REGISTER
001352	000000	RMER1I:	.WORD	0	:ERROR REGISTER #1
001354	000000	RMASI:	.WORD	0	:ATTENTION SUMMARY REGISTER
001356	000000	RMLAI:	.WORD	0	:LOOK AHEAD REGISTER
001360	000000	RMDBI:	.WORD	0	:DATA BUFFER
001362	000000	RMMR1I:	.WORD	0	:MAINTENANCE REGISTER #1
001364	000000	RMDTI:	.WORD	0	:DRIVE TYPE REGISTER
001366	000000	RMSNI:	.WORD	0	:SERIAL NUMBER REGISTER
001370	000000	RMOFI:	.WORD	0	:OFFSET REGISTER
001372	000000	RMDCI:	.WORD	0	:DESIRED CYLINDER REGISTER
001374	000000	RMHRI:	.WORD	0	:HOLDING REGISTER
001376	000000	RMMR2I:	.WORD	0	:MAINTENANCE REGISTER #2
001400	000000	RMER2I:	.WORD	0	:ERROR REGISTER #2
001402	000000	RMEC1I:	.WORD	0	:ECC POSITION REGISTER
001404	000000	RMEC2I:	.WORD	0	:ECC PATTERN REGISTER
001406	000000	RMBAEI:	.WORD	0	:BUS ADDRESS EXTENSION REGISTER
001410	000000	RMCS3I:	.WORD	0	:CONTROL, STATUS REGISTER #3

:THE REGISTER OUTPUT BUFFER IS USED FOR
 :ASSEMBLING DATA GOING TO REGISTER

001412

PUTBUF:

					:REGISTER OUTPUT BUFFER
001412	000000	RMCS1O:	.WORD	0	:CONTROL, STATUS REGISTER #1
001414	000000	RMWCO:	.WORD	0	:WORD COUNT REGISTER
001416	000000	RMBAO:	.WORD	0	:BUS ADDRESS REGISTER
001420	000000	RMDAO:	.WORD	0	:DISK ADDRESS REGISTER
001422	000000	RMCS2O:	.WORD	0	:CONTROL, STATUS REGISTER #2
001424	000000	RMDSO:	.WORD	0	:DRIVE STATUS REGISTER
001426	000000	RMER1O:	.WORD	0	:ERROR REGISTER #1
001430	000000	RMASO:	.WORD	0	:ATTENTION SUMMARY REGISTER
001432	000000	RMLAO:	.WORD	0	:LOOK AHEAD REGISTER
001434	000000	RMDBO:	.WORD	0	:DATA BUFFER
001436	000000	RMMR1O:	.WORD	0	:MAINTENANCE REGISTER #1

001440	000000	RMDTO: .WORD	0	;DRIVE TYPE REGISTER
001442	000000	RMSNO: .WORD	0	;SERIAL NUMBER REGISTER
001444	000000	RMOFO: .WORD	0	;OFFSET REGISTER
001446	000000	RMDCO: .WORD	0	;DESIRED CYLINDER REGISTER
001450	000000	RMHRO: .WORD	0	;HOLDING REGISTER
001452	000000	RMMR20: .WORD	0	;MAINTENANCE REGISTER #2
001454	000000	RMER20: .WORD	0	;ERROR REGISTER #2
001456	000000	RMEC10: .WORD	0	;ECC POSITION REGISTER
001460	000000	RMEC20: .WORD	0	;ECC PATTERN REGISTER
001462	000000	RMBAEO: .WORD	0	;BUS ADDRESS EXTENSION REGISTER
001464	000000	RMCS30: .WORD	0	;CONTROL, STATUS REGISTER #3

;EACH WORD OF THE TEST QUE CONTAINS THE DEVICE NUMBER IN
 ;THE LOW BYTE AND THE ATTENTION BIT IN THE HIGH BYTE. THE
 ;FIRST WORD CONTAINS THE ADDRESS OF THE DEVICE UNDER TEST
 ;IN THE TABLE. A ZERO WORD IS A BLANK AND REPRESENTS THE
 ;END OF THE QUE.

001466	000000	TSTQUE: .WORD	0	;CONTAINS DEVICE POINTER
001470		.BLKW	8.	;TEST QUE FOR DEVICES UNDER TEST
001510	000000	.WORD	0	;TABLE TERMINATOR GOES HERE WHEN ;ALL 8. DEVICES ARE UNDER TEST.

;MEDIA ENABLE IS SET IF THE BAD SECTOR FILES HAVE BEEN RECOVERED
 ;FOR THE UNIT UNDER TEST, OTHERWISE IT IS ZERO.

001512	000000	MEDENB: .WORD	0	;MEDIA ENABLE
--------	--------	---------------	---	---------------

;SKIP SECTOR FAILURE ENABLE IS SET IF THE "SSF" BIT SHOULD BE
 ;SET IN THE FIRST HEADER WORD WHEN THE FE CYLINDERS ARE BEING
 ;REFORMATTED.

001514	000000	SSFENB: .WORD	0	;SSF ENABLE
--------	--------	---------------	---	-------------

;LOCATIONS "ASND" AND "ASND" CONTAIN THE CYLINDER, TRACK AND SECTOR
 ;ADDRESS ASSIGNED BY THE BAD SECTOR MODULE.

001516	000000	ASND: .WORD	0	;ASSIGNED DESIRED CYLINDER
001520	000000	ASNCA: .WORD	0	;ASSIGNED TRACK, AND SECTOR
001522	000000	CLADR: .WORD	0	;UNIBUS ADDRESS OF KW11 CLOCK
001524	000000	CLKVCT: .WORD	0	;VECTOR ADDRESS OF KW11 CLOCK

;THE GET INDEX TABLE CONTAINS A BYTE LIST OF REGISTERS WHICH
 ;ARE READ BY THE GET SUBROUTINE. THE LIST IS TERMINATED BY
 ;A NEGATIVE BYTE.

001526		GETINX: .BLKB	23.	;GET INDEX TABLE
--------	--	---------------	-----	------------------

;THE PUT INDEX TABLE ICONTAINS A BYTE LIST OF REGISTERS WHICH
 ;ARE WRITTEN BY THE PUT SUBROUTINE. THE LIST IS TERMINATED BY
 ;A NEGATIVE BYTE.

001555		PUTINX: .BLKB	23.	;PUT INDEX TABLE
--------	--	---------------	-----	------------------

;PUT TAGS HERE

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 ;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 ;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ::POINTS TO THE ERROR MESSAGE
 ;* DH ::POINTS TO THE DATA HEADER
 ;* DT ::POINTS TO THE DATA
 ;* DF ::POINTS TO THE DATA FORMAT

001604		\$ERRTB:	
1		:ERROR 1	WRONG UNIT SELECTED
2			
3			
001604	070002	EMT1	
001606	074140	EHT1	
001610	074264	EDT1	
001612	074354	EFT1	
4		:ERROR 2	DEVICE WENT UNAVAILABLE
5			
6			
001614	070006	EMT2	
001616	074140	EHT1	
001620	074264	EDT1	
001622	074354	EFT1	
7		:ERROR 3	DEVICE WENT NONEXISTENT
8			
9			
001624	070014	EMT3	
001626	074140	EHT1	
001630	074264	EDT1	
001632	074354	EFT1	
10		:ERROR 4	CONTROLLER NOT READY
11			
12			
001634	070022	EMT4	
001636	074140	EHT1	
001640	074264	EDT1	
001642	074354	EFT1	
13		:ERROR 5	DRIVE NOT READY AND GO NOT RESET
14			
15			
001644	070030	EMT5	
001646	074140	EHT1	
001650	074264	EDT1	
001652	074354	EFT1	
16		:ERROR 6	UNEXPECTED VALUE FOR "ATA" STATUS
17			

18	001654	070036	EMT6
	001656	074140	EHT1
	001660	074264	EDT1
	001662	074354	EFT1
19			
20			:ERROR 7 BUS TIMEOUT TRYING TO READ OR WRITE REGISTER
21			
	001664	070044	EMT7
	001666	000000	0
	001670	000000	0
	001672	000000	0
22			
23			:ERROR 10 DRIVE NOT READY BUT GO IS RESET
24			
	001674	070052	EMT10
	001676	074140	EHT1
	001700	074264	EDT1
	001702	074354	EFT1
25			
26			:ERROR 11 GO NOT RESET BUT DRIVE IS READY
27			
	001704	070056	EMT11
	001706	074140	EHT1
	001710	074264	EDT1
	001712	074354	EFT1
28			
29			:ERROR 12 INCORRECT FUNCTION CODE
30			
	001714	070062	EMT12
	001716	074140	EHT1
	001720	074264	EDT1
	001722	074354	EFT1
31			
32			:ERROR 13 PARITY ERROR READING REMOTE REGISTERS
33			
	001724	070070	EMT13
	001726	074140	EHT1
	001730	074264	EDT1
	001732	074354	EFT1
34			
35			:ERROR 14 TRANSFER ERROR IS INCORRECT
36			
	001734	070102	EMT14
	001736	074140	EHT1
	001740	074264	EDT1
	001742	074354	EFT1
37			
38			:ERROR 15 INCORRECT WORD COUNT
39			

	001744	070110		EMT15
	001746	074140		EHT1
	001750	074264		EDT1
	001752	074354		EFT1
40				
41			:ERROR 16	INCORRECT BUS ADDRESS
42				
	001754	070116		EMT16
	001756	074140		EHT1
	001760	074264		EDT1
	001762	074354		EFT1
43				
44			:ERROR 17	INCORRECT LBT STATUS
45				
	001764	070126		EMT17
	001766	074140		EHT1
	001770	074264		EDT1
	001772	074354		EFT1
46				
47			:ERROR 20	INCORRECT AOE
48				
	001774	070136		EMT20
	001776	074140		EHT1
	002000	074264		EDT1
	002002	074354		EFT1
49				
50			:ERROR 21	INCORRECT DISK ADDRESS
51				
	002004	070146		EMT21
	002006	074140		EHT1
	002010	074264		EDT1
	002012	074354		EFT1
52				
53			:ERROR 22	INCORRECT CYLINDER ADDRESS
54				
	002014	070156		EMT22
	002016	074140		EHT1
	002020	074264		EDT1
	002022	074354		EFT1
55				
56			:ERROR 23	INCORRECT WLE STATUS
57				
	002024	070166		EMT23
	002026	074140		EHT1
	002030	074264		EDT1
	002032	074354		EFT1
58				
59			:ERROR 24	INCORRECT UPE STATUS
60				
	002034	070176		EMT24

	002036	074140	EHT1	
	002040	074264	EDT1	
	002042	074354	EFT1	
61				
62				:ERROR 25 INCORRECT WCF STATUS
63				
	002044	070206	EMT25	
	002046	074140	EHT1	
	002050	074264	EDT1	
	002052	074354	EFT1	
64				
65				:ERROR 26 INCORRECT WCE STATUS
66				
	002054	070216	EMT26	
	002056	074140	EHT1	
	002060	074264	EDT1	
	002062	074354	EFT1	
67				
68				:ERROR 27 INCORRECT MDPE STATUS
69				
	002064	070226	EMT27	
	002066	074140	EHT1	
	002070	074264	EDT1	
	002072	074354	EFT1	
70				
71				:ERROR 30 INCORRECT DCK STATUS
72				
	002074	070236	EMT30	
	002076	074140	EHT1	
	002100	074264	EDT1	
	002102	074354	EFT1	
73				
74				:ERROR 31 INCORRECT ECH STATUS
75				
	002104	070246	EMT31	
	002106	074140	EHT1	
	002110	074264	EDT1	
	002112	074354	EFT1	
76				
77				:ERROR 32 DLT SHOULD NOT BE SET
78				
	002114	070256	EMT32	
	002116	074140	EHT1	
	002120	074264	EDT1	
	002122	074354	EFT1	
79				
80				:ERROR 33 MXF SHOULD NOT BE SET
81				
	002124	070266	EMT33	
	002126	074140	EHT1	

002130	074264	EDT1	
002132	074354	EFT1	
82			
83		:ERROR	34 DTE SHOULD NOT BE SET
84			
002134	070276	EMT34	
002136	074140	EHT1	
002140	074264	EDT1	
002142	074354	EFT1	
85			
86		:ERROR	35 INCORRECT HCRC STATUS
87			
002144	070306	EMT35	
002146	074140	EHT1	
002150	074264	EDT1	
002152	074354	EFT1	
88			
89		:ERROR	36 INCORRECT HCE STATUS
90			
002154	070316	EMT36	
002156	074140	EHT1	
002160	074264	EDT1	
002162	074354	EFT1	
91			
92		:ERROR	37 INCORRECT FER STATUS
93			
002164	070326	EMT37	
002166	074140	EHT1	
002170	074264	EDT1	
002172	074354	EFT1	
94			
95		:ERROR	40 DPE SHOULD NOT BE SET (NOT A DATA COMMAND)
96			
002174	070336	EMT40	
002176	074140	EHT1	
002200	074264	EDT1	
002202	074354	EFT1	
97			
98		:ERROR	41 LOST 'MOL' DURING PACK ACKNOWLEDGE
99			
002204	070344	EMT41	
002206	074140	EHT1	
002210	074264	EDT1	
002212	074354	EFT1	
100			
101		:ERROR	42 UNSAFE ERROR DURING PACK ACKNOWLEDGE
102			
002214	070354	EMT42	
002216	074140	EHT1	
002220	074264	EDT1	

	002222	074354	EFT1	
103				
104			:ERROR 43	'OPI' ERROR DURING PACK ACKNOWLEDGE
105				
	002224	070366	EMT43	
	002226	074140	EHT1	
	002230	074264	EDT1	
	002232	074354	EFT1	
106				
107			:ERROR 44	'RMR' ERROR DURING PACK ACKNOWLEDGE
108				
	002234	070376	EMT44	
	002236	074140	EHT1	
	002240	074264	EDT1	
	002242	074354	EFT1	
109				
110			:ERROR 45	'ILR' ERROR DURING PACK ACKNOWLEDGE
111				
	002244	070406	EMT45	
	002246	074140	EHT1	
	002250	074264	EDT1	
	002252	074354	EFT1	
112				
113			:ERROR 46	'ILF' ERROR DURING PACK ACKNOWLEDGE
114				
	002254	070416	EMT46	
	002256	074140	EHT1	
	002260	074264	EDT1	
	002262	074354	EFT1	
115				
116			:ERROR 47	COMPOSITE ERROR STATUS IS INCORRECT
117				
	002264	070426	EMT47	
	002266	074140	EHT1	
	002270	074264	EDT1	
	002272	074354	EFT1	
118				
119			:ERROR 50	PARITY ERROR WRITING REMOTE REGISTERS
120				
	002274	070434	EMT50	
	002276	074140	EHT1	
	002300	074264	EDT1	
	002302	074354	EFT1	
121				
122			:ERROR 51	INCORRECT IAE STATUS DURING SEEK COMMAND
123				
	002304	070444	EMT51	
	002306	074140	EHT1	
	002310	074264	EDT1	
	002312	074354	EFT1	

124				
125			:ERROR 52	OPI ERROR DURING SEEK - MEDIUM IS NOT ON LINE
126				
	002314	070456	EMT52	
	002316	074140	EHT1	
	002320	074264	EDT1	
	002322	074354	EFT1	
127				
128			:ERROR 53	OPI ERROR DURING SEEK - MEDIUM IS ON LINE, ASSUME
129			:	ON CYLINDER LATCH DIDN'T RESET
130				
	002324	070474	EMT53	
	002326	074140	EHT1	
	002330	074264	EDT1	
	002332	074354	EFT1	
131				
132			:ERROR 54	SEEK INCOMPLETE ERROR DURING SEEK COMMAND
133				
	002334	070512	EMT54	
	002336	074140	EHT1	
	002340	074264	EDT1	
	002342	074354	EFT1	
134				
135			:ERROR 55	DEVICE CHECK DURING SEEK COMMAND
136				
	002344	070522	EMT55	
	002346	074140	EHT1	
	002350	074264	EDT1	
	002352	074354	EFT1	
137				
138			:ERROR 56	PIP IS STILL SET AFTER SEEK - SKI IS RESET
139				
	002354	070534	EMT56	
	002356	074140	EHT1	
	002360	074264	EDT1	
	002362	074354	EFT1	
140				
141			:ERROR 57	ATA DID NOT SET DURING SEEK COMMAND
142				
	002364	070552	EMT57	
	002366	074140	EHT1	
	002370	074264	EDT1	
	002372	074354	EFT1	
143				
144			:ERROR 60	IVC ERROR DURING SEEK COMMAND - LOST
145			:	VOLUME VALID
146				
	002374	070562	EMT60	
	002376	074140	EHT1	
	002400	074264	EDT1	

002402	074354	EFT1	
147			
148		:ERROR 61	ERRONEOUS IVC ERROR DURING SEEK COMMAND -
149		:	VOLUME VALID IS STIL SET
150			
002404	070600	EMT61	
002406	074140	EHT1	
002410	074264	EDT1	
002412	074354	EFT1	
151			
152		:ERROR 62	MOL IS ZERO, BUT OPI WAS NOT
153		:	REPORTED DURING SEEK COMMAND
154			
002414	070620	EMT62	
002416	074140	EHT1	
002420	074264	EDT1	
002422	074354	EFT1	
155			
156		:ERROR 63	SSE SHOULD NOT BE SET
157			
002424	070634	EMT63	
002426	074140	EHT1	
002430	074264	EDT1	
002432	074354	EFT1	
158			
159		:ERROR 64	DRIVE DID NOT DETECT "IVC" ERROR DURING SEEK
160			
002434	070644	EMT64	
002436	074140	EHT1	
002440	074264	EDT1	
002442	074354	EFT1	
161			
162		:ERROR 65	DRIVE EXECUTED A SEEK WITH ERROR SET
163			
002444	070664	EMT65	
002446	074140	EHT1	
002450	074264	EDT1	
002452	074354	EFT1	
164			
165		:ERROR 66	UNEXPECTED ERROR SET IN RMER1
166			
002454	070704	EMT66	
002456	074140	EHT1	
002460	074264	EDT1	
002462	074354	EFT1	
167			
168		:ERROR 67	UNEXPECTED ERROR SET IN RMER2
169			
002464	070716	EMT67	
002466	074140	EHT1	

	002470	074264	EDT1	
	002472	074354	EFT1	
170				
171			:ERROR	70 ERRONEOUS 'IAE' ERROR DURING RECALIBRATE
172				
	002474	070730	EMT70	
	002476	074140	EHT1	
	002500	074264	EDT1	
	002502	074354	EFT1	
173				
174			:ERROR	71 'ILF' ERROR DURING RECALIBRATE
175				
	002504	070740	EMT71	
	002506	074140	EHT1	
	002510	074264	EDT1	
	002512	074354	EFT1	
176				
177			:ERROR	72 'DPI' ERROR DURING RECALIBRATE DUE TO 'MOL' = 0
178				
	002514	070750	EMT72	
	002516	074140	EHT1	
	002520	074264	EDT1	
	002522	074354	EFT1	
179				
180			:ERROR	73 'DPI' ERROR DURING RECALIBRATE BECAUSE ON
181			:	CYLINDER DIDNT DROP
182				
	002524	070766	EMT73	
	002526	074140	EHT1	
	002530	074264	EDT1	
	002532	074354	EFT1	
183				
184			:ERROR	74 'IVC' ERROR DURING RECALIBRATE - 'VV' = 0
185				
	002534	071004	EMT74	
	002536	074140	EHT1	
	002540	074264	EDT1	
	002542	074354	EFT1	
186				
187			:ERROR	75 ERRONEOUS 'IVC' ERROR DURING RECALIBRATE - 'VV' = 1
188				
	002544	071014	EMT75	
	002546	074140	EHT1	
	002550	074264	EDT1	
	002552	074354	EFT1	
189				
190			:ERROR	76 'SKI' ERROR DURING RECALIBRATE
191				
	002554	071034	EMT76	
	002556	074140	EHT1	

	002560	074264	EDT1	
	002562	074354	EFT1	
192				
193				:ERROR 77 'DVC' OCCURRED DURING RECALIBRATE
194				
	002564	071044	EMT77	
	002566	074140	EHT1	
	002570	074264	EDT1	
	002572	074354	EFT1	
195				
196				:ERROR 100 LOST 'MOL' DURING RECALIBRATE - 'OPI' = 0
197				
	002574	071056	EMT100	
	002576	074140	EHT1	
	002600	074264	EDT1	
	002602	074354	EFT1	
198				
199				:ERROR 101 LOST 'VV' DURING RECALIBRATE - 'IVC' = 0
200				
	002604	071074	EMT101	
	002606	074140	EHT1	
	002610	074264	EDT1	
	002612	074354	EFT1	
201				
202				:ERROR 102 'ATA' DID NOT SET DURING RECALIBRATE
203				
	002614	071112	EMT102	
	002616	074140	EHT1	
	002620	074264	EDT1	
	002622	074354	EFT1	
204				
205				:ERROR 103 'OM' DID NOT RESET DURING RECALIBRATE
206				
	002624	071122	EMT103	
	002626	074140	EHT1	
	002630	074264	EDT1	
	002632	074354	EFT1	
207				
208				:ERROR 104 'PIP' IS STIL SET AFTER RECALIBRATE
209				
	002634	071134	EMT104	
	002636	074140	EHT1	
	002640	074264	EDT1	
	002642	074354	EFT1	
210				
211				:ERROR 105 UNEXPECTED 'ILR' ERROR DURING RECALIBRATE
212				
	002644	071152	EMT105	
	002646	074140	EHT1	
	002650	074264	EDT1	

	002652	074354	EFT1	
213				
214			:ERROR 106	UNEXPECTED 'RMR' ERROR DURING RECALIBRATE
215				
	002654	071162	EMT106	
	002656	074140	EHT1	
	002660	074264	EDT1	
	002662	074354	EFT1	
216				
217			:ERROR 107	'UNS' ERROR DURING RECALIBRATE - AC POWER IS LOW
218				
	002664	071172	EMT107	
	002666	074140	EHT1	
	002670	074264	EDT1	
	002672	074354	EFT1	
219				
220			:ERROR 110	CANNOT ACCESS MASSBUS CONTROLLER VIA UNIBUS
221				
	002674	071212	EMT110	
	002676	074162	EHT110	
	002700	074302	EDT110	
	002702	074372	EFT110	
222				
223			:ERROR 111	NONEXISTENT DEVICE
224				
	002704	071224	EMT111	
	002706	074166	EHT111	
	002710	074304	EDT111	
	002712	074374	EFT111	
225				
226			:ERROR 112	DEVICE NOT AVAILABLE
227				
	002714	071232	EMT112	
	002716	074166	EHT111	
	002720	074304	EDT111	
	002722	074374	EFT111	
228				
229			:ERROR 113	BUS TIMEOUT-NED STATUS FAILURE
230				
	002724	071240	EMT113	
	002726	000000	0	
	002730	000000	0	
	002732	000000	0	
231				
232			:ERROR 114	UNUSED
233				
	002734	000000	0	
	002736	000000	0	
	002740	000000	0	
	002742	000000	0	

234			
235		;ERROR	115 RMCS1 NOT INITIALIZED BY UNIBUS
236			
	002744	071256	EMT115
	002746	074140	EHT1
	002750	074264	EDT1
	002752	074354	EFT1
237			
238		;ERROR	116 RMBA NOT INITIALIZED BY UNIBUS
239			
	002754	071266	EMT116
	002756	074140	EHT1
	002760	074264	EDT1
	002762	074354	EFT1
240			
241		;ERROR	117 RMCS2 NOT INITIALIZED BY UNIBUS
242			
	002764	071276	EMT117
	002766	074140	EHT1
	002770	074264	EDT1
	002772	074354	EFT1
243			
244		;ERROR	120 RMER1 NOT INITIALIZED BY UNIBUS
245			
	002774	071306	EMT120
	002776	074140	EHT1
	003000	074264	EDT1
	003002	074354	EFT1
246			
247		;ERROR	121 RMAS NOT INITIALIZED BY UNIBUS
248			
	003004	071316	EMT121
	003006	074140	EHT1
	003010	074264	EDT1
	003012	074354	EFT1
249			
250		;ERROR	122 RMMR1 NOT INITIALIZED BY UNIBUS
251			
	003014	071326	EMT122
	003016	074140	EHT1
	003020	074264	EDT1
	003022	074354	EFT1
252			
253		;ERROR	123 RMDS NOT INITIALIZED BY UNIBUS
254			
	003024	071336	EMT123
	003026	074140	EHT1
	003030	074264	EDT1
	003032	074354	EFT1

255				
256			:ERROR 124	RMEC2 NOT INITIALIZED BY UNIBUS
257	003034	071346		EMT124
	003036	074140		EHT1
	003040	074264		EDT1
	003042	074354		EFT1
258				
259			:ERROR 125	RMMR2 NOT INITIALIZED BY UNIBUS
260	003044	071356		EMT125
	003046	074140		EHT1
	003050	074264		EDT1
	003052	074354		EFT1
261				
262			:ERROR 126	RMCS1 NOT CLEARED BY CONTROLLER CLEAR
263	003054	071366		EMT126
	003056	074140		EHT1
	003060	074264		EDT1
	003062	074354		EFT1
264				
265			:ERROR 127	RMBA NOT CLEARED BY CONTROLLER CLEAR
266	003064	071400		EMT127
	003066	074140		EHT1
	003070	074264		EDT1
	003072	074354		EFT1
267				
268			:ERROR 130	RMCS2 NOT CLEARED BY CONTROLLER CLEAR
269	003074	071412		EMT130
	003076	074140		EHT1
	003100	074264		EDT1
	003102	074354		EFT1
270				
271			:ERROR 131	RMER1 NOT CLEARED BY CONTROLLER CLEAR
272	003104	071424		EMT131
	003106	074140		EHT1
	003110	074264		EDT1
	003112	074354		EFT1
273				
274			:ERROR 132	RMAS NOT CLEARED BY CONTROLLER CLEAR
275	003114	071436		EMT132
	003116	074140		EHT1
	003120	074264		EDT1
	003122	074354		EFT1
276				

277		:ERROR 133	RMMR1 NOT CLEARED BY CONTROLLER CLEAR
278	003124 071450	EMT133	
	003126 074140	EHT1	
	003130 074264	EDT1	
	003132 074354	EFT1	
279		:ERROR 134	RMDS NOT CLEARED BY CONTROLLER CLEAR
280			
281	003134 071462	EMT134	
	003136 074140	EHT1	
	003140 074264	EDT1	
	003142 074354	EFT1	
282		:ERROR 135	RMEC2 NOT CLEARED BY CONTROLLER CLEAR
283			
284	003144 071474	EMT135	
	003146 074140	EHT1	
	003150 074264	EDT1	
	003152 074354	EFT1	
285		:ERROR 136	RMMR2 NOT CLEARED BY CONTROLLER CLEAR
286			
287	003154 071506	EMT136	
	003156 074140	EHT1	
	003160 074264	EDT1	
	003162 074354	EFT1	
288		:ERROR 137	RMCS1 NOT CLEARED BY ERROR CLEAR
289			
290	003164 071520	EMT137	
	003166 074140	EHT1	
	003170 074264	EDT1	
	003172 074354	EFT1	
291		:ERROR 140	RMCS2 NOT CLEARED BY ERROR CLEAR
292			
293	003174 071530	EMT140	
	003176 074140	EHT1	
	003200 074264	EDT1	
	003202 074354	EFT1	
294		:ERROR 141	RMCS1 NOT CLEARED BY DRIVE CLEAR
295			
296	003204 071540	EMT141	
	003206 074140	EHT1	
	003210 074264	EDT1	
	003212 074354	EFT1	
297		:ERROR 142	RMDS NOT CLEARED BY DRIVE CLEAR
298			

299	003214 071550	EMT142	
	003216 074140	EHT1	
	003220 074264	EDT1	
	003222 074354	EFT1	
300			
301		:ERROR 143	RMER1 NOT CLEARED BY DRIVE CLEAR
302			
	003224 071560	EMT143	
	003226 074140	EHT1	
	003230 074264	EDT1	
	003232 074354	EFT1	
303			
304		:ERROR 144	RMA5 NOT CLEARED BY DRIVE CLEAR
305			
	003234 071570	EMT144	
	003236 074140	EHT1	
	003240 074264	EDT1	
	003242 074354	EFT1	
306			
307		:ERROR 145	RMMR1 NOT CLEARED BY DRIVE CLEAR
308			
	003244 071600	EMT145	
	003246 074140	EHT1	
	003250 074264	EDT1	
	003252 074354	EFT1	
309			
310		:ERROR 146	RMMR2 NOT CLEARED BY DRIVE CLEAR
311			
	003254 071610	EMT146	
	003256 074140	EHT1	
	003260 074264	EDT1	
	003262 074354	EFT1	
312			
313		:ERROR 147	RMER2 NOT CLEARED BY DRIVE CLEAR
314			
	003264 071620	EMT147	
	003266 074140	EHT1	
	003270 074264	EDT1	
	003272 074354	EFT1	
315			
316		:ERROR 150	RMEC2 NOT CLEARED BY DRIVE CLEAR
317			
	003274 071630	EMT150	
	003276 074140	EHT1	
	003300 074264	EDT1	
	003302 074354	EFT1	
318			
319		:ERROR 151	MEDIUM NOT ON LINE
320			

	003304	071640		EMT151
	003306	074140		EHT1
	003310	074264		EDT1
	003312	074354		EFT1
321				
322			:ERROR 152	DRIVE FAULT
323				
	003314	071652		EMT152
	003316	074140		EHT1
	003320	074264		EDT1
	003322	074354		EFT1
324				
325			:ERROR 153	UNSAFE SHOULD BE SET BECAUSE DVC IS SET
326				
	003324	071664		EMT153
	003326	074140		EHT1
	003330	074264		EDT1
	003332	074354		EFT1
327				
328			:ERROR 154	UNSAFE SHOULD NOT BE SET, AC IS LOW
329				
	003334	071702		EMT154
	003336	074140		EHT1
	003340	074264		EDT1
	003342	074354		EFT1
330				
331			:ERROR 155	VOLUME VALID NOT SET BY PACK ACK
332				
	003344	071720		EMT155
	003346	074140		EHT1
	003350	074264		EDT1
	003352	074354		EFT1
333				
334			:ERROR 156	OFFSET MODE NOT SET BY OFFSET COMMAND
335				
	003354	071732		EMT156
	003356	074140		EHT1
	003360	074264		EDT1
	003362	074354		EFT1
336				
337			:ERROR 157	OFFSET MODE NOT RESET BY RTC COMMAND
338				
	003364	071744		EMT157
	003366	074140		EHT1
	003370	074264		EDT1
	003372	074354		EFT1
339				
340			:ERROR 160	RMOF NOT RESET BY RIP COMMAND
341				
	003374	071756		EMT160

	003376	074140	EHT1	
	003400	074264	EDT1	
	003402	074354	EFT1	
342				
343			:ERROR	161 RMDA NOT RESET BY RIP COMMAND
344				
	003404	071766	EMT161	
	003406	074140	EHT1	
	003410	074264	EDT1	
	003412	074354	EFT1	
345				
346			:ERROR	162 RMDC NOT RESET BY RIP COMMAND
347				
	003414	072000	EMT162	
	003416	074140	EHT1	
	003420	074264	EDT1	
	003422	074354	EFT1	
348				
349			:ERROR	163 DATA WAS ECC CORRECTED BUT DOES NOT COMPARE WITH
350			:	WRITE BUFFER
351				
	003424	073734	EMT336	
	003426	074222	EHT336	
	003430	074320	EDT336	
	003432	074410	EFT336	
352				
353			:ERROR	164 OPI SHOULD NOT BE SET
354				
	003434	072022	EMT164	
	003436	074140	EHT1	
	003440	074264	EDT1	
	003442	074354	EFT1	
355				
356			:ERROR	165 IVC SHOULD NOT BE SET
357				
	003444	072030	EMT165	
	003446	074140	EHT1	
	003450	074264	EDT1	
	003452	074354	EFT1	
358				
359			:ERROR	166 IAE SHOULD NOT BE SET
360				
	003454	072036	EMT166	
	003456	074140	EHT1	
	003460	074264	EDT1	
	003462	074354	EFT1	
361				
362			:ERROR	167 NEM SHOULD NOT BE SET
363				
	003464	072044	EMT167	

ERROR POINTER TABLE

	003466	074140		EHT1
	003470	074264		EDT1
	003472	074354		EFT1
364				
365			:ERROR 170	INCORRECT 'MOL' STATUS DURING DIAGNOSTIC MODE
366				
	003474	072052		EMT170
	003476	074140		EHT1
	003500	074264		EDT1
	003502	074354		EFT1
367				
368			:ERROR 171	'ATA' NOT SET DURING RETURN TO CENTERLINE
369				
	003504	072064		EMT171
	003506	074140		EHT1
	003510	074264		EDT1
	003512	074354		EFT1
370				
371			:ERROR 172	'ATA' NOT SET BY OFFSET COMMAND
372				
	003514	072074		EMT172
	003516	074140		EHT1
	003520	074264		EDT1
	003522	074354		EFT1
373				
374			:ERROR 173	RMER2 NOT INITIALIZED BY UNIBUS INIT
375				
	003524	072104		EMT173
	003526	074140		EHT1
	003530	074264		EDT1
	003532	074354		EFT1
376				
377			:ERROR 174	RMER2 NOT INITIALIZED BY CONTROLLER CLEAR
378				
	003534	072114		EMT174
	003536	074140		EHT1
	003540	074264		EDT1
	003542	074354		EFT1
379				
380			:ERROR 175	SELECTED DEVICE IS IN WRITE PROTECT
381				
	003544	072126		EMT175
	003546	074140		EHT1
	003550	074264		EDT1
	003552	074354		EFT1
382				
383			:ERROR 176	CANNOT SET DIAGNOSTIC MODE
384				
	003554	072134		EMT176
	003556	074140		EHT1

	003550	074264	EDT1	
	003562	074354	EFT1	
385				
386				:ERROR 177 --RESERVED FOR POWER MONITOR BIT FAILURE--
387				
	003564	000000	0	
	003566	000000	0	
	003570	000000	0	
	003572	000000	0	
388				
389				:ERROR 200 INCORRECT 'PIP' STATUS DURING DIAGNOSTIC MODE
390				
	003574	072144	EMT200	
	003576	074140	EHT1	
	003600	074264	EDT1	
	003602	074354	EFT1	
391				
392				:ERROR 201 INCORRECT 'WRL' STATUS DURING DIAGNOSTIC MODE
393				
	003604	072156	EMT201	
	003606	074140	EHT1	
	003610	074264	EDT1	
	003612	074354	EFT1	
394				
395				:ERROR 202 INCORRECT 'SKI' STATUS DURING DIAGNOSTIC MODE
396				
	003614	072170	EMT202	
	003616	074140	EHT1	
	003620	074264	EDT1	
	003622	074354	EFT1	
397				
398				:ERROR 203 INCORRECT 'DVC' STATUS DURING DIAGNOSTIC MODE
399				
	003624	072202	EMT203	
	003626	074140	EHT1	
	003630	074264	EDT1	
	003632	074354	EFT1	
400				
401				:ERROR 204 'VV' WAS NOT RESET BY MAINTENANCE UNIT READY
402				
	003634	072214	EMT204	
	003636	074140	EHT1	
	003640	074264	EDT1	
	003642	074354	EFT1	
403				
404				:ERROR 205 SELECTED DEVICE HAS A PERSISTENT 'SKI' ERROR
405				
	003644	072232	EMT205	
	003646	074140	EHT1	
	003650	074264	EDT1	

	003652	074354	EFT1	
406				
407				
408				
	003654	072242	EMT206	
	003656	074140	EHT1	
	003660	074264	EDT1	
	003662	074354	EFT1	
409				
410				
411				
	003664	072252	EMT207	
	003666	074140	EHT1	
	003670	074264	EDT1	
	003672	074354	EFT1	
412				
413				
414				
	003674	072264	EMT210	
	003676	074140	EHT1	
	003700	074264	EDT1	
	003702	074354	EFT1	
415				
416				
417				
	003704	072272	EMT211	
	003706	074140	EHT1	
	003710	074264	EDT1	
	003712	074354	EFT1	
418				
419				
420				
	003714	072306	EMT212	
	003716	074140	EHT1	
	003720	074264	EDT1	
	003722	074354	EFT1	
421				
422				
423				
	003724	072322	EMT213	
	003726	074140	EHT1	
	003730	074264	EDT1	
	003732	074354	EFT1	
424				
425				
426				
	003734	072332	EMT214	
	003736	074152	EHT2	
	003740	074274	EDT2	
	003742	074364	EFT2	

427				
428			;ERROR 215	DRIVE DID NOT DETECT "IVC" ERROR DURING RECALIBRATE
429	003744	072352	EMT215	
	003746	074152	EHT2	
	003750	074274	EDT2	
	003752	074364	EFT2	
430				
431			;ERROR 216	INCORRECT "IVC" STATUS
432	003754	072364	EMT216	
	003756	074140	EHT1	
	003760	074264	EDT1	
	003762	074354	EFT1	
433				
434			;ERROR 217	INCORRECT "IAE" STATUS
435	003764	072374	EMT217	
	003766	074140	EHT1	
	003770	074264	EDT1	
	003772	074354	EFT1	
436				
437			;ERROR 220	INCORRECT "WLE" STATUS
438	003774	072404	EMT220	
	003776	074140	EHT1	
	004000	074264	EDT1	
	004002	074354	EFT1	
439				
440			;ERROR 221	INCORRECT "OPI" STATUS
441	004004	072414	EMT221	
	004006	074140	EHT1	
	004010	074264	EDT1	
	004012	074354	EFT1	
442				
443			;ERROR 222	RM80 DID NOT DETECT RMR ERROR
444	004014	072424	EMT222	
	004016	074140	EHT1	
	004020	074264	EDT1	
	004022	074354	EFT1	
445				
446			;ERROR 223	RM80 DI: NOT DETECT PARITY ERROR ON MASSBUS CONTROL BUS
447	004024	072434	EMT223	
	004026	074176	EHT223	
	004030	074310	EDT223	
	004032	074400	EFT223	

ERROR POINTER TABLE

448			
449		:ERROR 224	SSE NOT DETECTED DURING DATA TRANSFER
450	004034 072444		EMT224
	004036 074140		EHT1
	004040 074264		EDT1
	004042 074354		EFT1
451			
452		:ERROR 225	"SSEI" NOT RESET BY END OF TRACK DURING DATA TRANSFER
453	004044 072460		EMT225
	004046 074140		EHT1
	004050 074264		EDT1
	004052 074354		EFT1
454			
455		:ERROR 226	"SSEI" SHOULD BE SET AFTER DATA TRANSFER
456	004054 072500		EMT226
	004056 074140		EHT1
	004060 074264		EDT1
	004062 074354		EFT1
457			
458		:ERROR 227	SSE WAS DETECTED W/ SSEI SET
459	004064 072510		EMT227
	004066 074140		EHT1
	004070 074264		EDT1
	004072 074354		EFT1
460			
461		:ERROR 230	UNUSED
462	004074 072524		EMT230
	004076 000000		0
	004100 000000		0
	004102 000000		0
463			
464		:ERROR 231	UNUSED
465	004104 072526		EMT231
	004106 000000		0
	004110 000000		0
	004112 000000		0
466			
467		:ERROR 232	UNUSED
468	004114 072530		EMT232
	004116 000000		0
	004120 000000		0
	004122 000000		0
469			

470			:ERROR	233	UNUSED
471					
	004124	072532		EMT233	
	004126	000000		0	
	004130	000000		0	
	004132	000000		0	
472					
473			:ERROR	234	UNUSED
474					
	004134	000000		0	
	004136	000000		0	
	004140	000000		0	
	004142	000000		0	
475					
476			:ERROR	235	UNUSED
477					
	004144	000000		0	
	004146	000000		0	
	004150	000000		0	
	004152	000000		0	
478					
479			:ERROR	236	UNUSED
480					
	004154	000000		0	
	004156	000000		0	
	004160	000000		0	
	004162	000000		0	
481					
482			:ERROR	237	UNUSED
483					
	004164	000000		0	
	004166	000000		0	
	004170	000000		0	
	004172	000000		0	
484					
485			:ERROR	240	UNUSED
486					
	004174	000000		0	
	004176	000000		0	
	004200	000000		0	
	004202	000000		0	
487					
488			:ERROR	241	UNUSED
489					
	004204	000000		0	
	004206	000000		0	
	004210	000000		0	
	004212	000000		0	
490					
491			:ERROR	242	UNUSED

492	004214	000000	0	
	004216	000000	0	
	004220	000000	0	
	004222	000000	0	
493				
494			:ERROR 243	UNUSED
495	004224	000000	0	
	004226	000000	0	
	004230	000000	0	
	004232	000000	0	
496				
497			:ERROR 244	UNUSED
498	004234	000000	0	
	004236	000000	0	
	004240	000000	0	
	004242	000000	0	
499				
500			:ERROR 245	UNUSED
501	004244	000000	0	
	004246	000000	0	
	004250	000000	0	
	004252	000000	0	
502				
503			:ERROR 246	'ATA' NOT RESET BY GO WHEN 'ERR' = 0
504	004254	072560	EMT246	
	004256	074140	EHT1	
	004260	074264	EDT1	
	004262	074354	EFT1	
505				
506			:ERROR 247	'ATA' NOT RESET BY WRITING RMAS
507	004264	072570	EMT247	
	004266	074140	EHT1	
	004270	074264	EDT1	
	004272	074354	EFT1	
508				
509			:ERROR 250	'ATA' WAS RESET BY GO WHEN 'ERR' = 1
510	004274	072602	EMT250	
	004276	074140	EHT1	
	004300	074264	EDT1	
	004302	074354	EFT1	
511				
512			:ERROR 251	PROGRAM INTERRUPT WAS NOT GENERATED
513				

ERROR POINTER TABLE

	004304	072616		EMT251	
	004306	074152		EHT2	
	004310	074274		EDT2	
	004312	074364		EFT2	
514					
515			:ERROR	252	PROGRAM INTERRUPT SHOULD NOT HAVE BEEN GENERATED
516					
	004314	072624		EMT252	
	004316	074152		EHT2	
	004320	074274		EDT2	
	004322	074364		EFT2	
517					
518			:ERROR	253	OFFSET MODE WAS NOT RESET BY WRITING RMDC
519					
	004324	072632		EMT253	
	004326	074140		EHT1	
	004330	074264		EDT1	
	004332	074354		EFT1	
520					
521			:ERROR	254	INCORRECT "ILF" STATUS
522					
	004334	072650		EMT254	
	004336	074140		EHT1	
	004340	074264		EDT1	
	004342	074354		EFT1	
523					
524			:ERROR	255	INCORRECT "ATA" STATUS
525					
	004344	072660		EMT255	
	004346	074140		EHT1	
	004350	074264		EDT1	
	004352	074354		EFT1	
526					
527			:ERROR	256	INCORRECT "ILR" STATUS
528					
	004354	072670		EMT256	
	004356	074210		EHT256	
	004360	074310		EDT223	
	004362	074400		EFT223	
529					
530			:ERROR	257	INVALID IAE STATUS DURING SEARCH COMMAND
531					
	004364	072700		EMT257	
	004366	074140		EHT1	
	004370	074264		EDT1	
	004372	074354		EFT1	
532					
533			:ERROR	260	"IVC" WAS NOT DETECTED DURING SEARCH COMMAND
534					
	004374	072712		EMT260	

	004376	074140		EHT1
	004400	074264		EDT1
	004402	074354		EFT1
535				
536			:ERROR	261 DRIVE EXECUTED SEARCH WITH ERROR SET
537				
	004404	072724		EMT261
	004406	074140		EHT1
	004410	074264		EDT1
	004412	074354		EFT1
538				
539			:ERROR	262 'LBC' ERROR NOT SET DURING DIAGNOSTIC MODE
540				
	004414	072744		EMT262
	004416	074140		EHT1
	004420	074264		EDT1
	004422	074354		EFT1
541				
542			:ERROR	263 'SKI' ERROR DURING SEARCH COMMAND
543				
	004424	072754		EMT263
	004426	074140		EHT1
	004430	074264		EDT1
	004432	074354		EFT1
544				
545			:ERROR	264 'IVC' ERROR DURING SEARCH - LOST VOLUME VALID
546				
	004434	072764		EMT264
	004436	074140		EHT1
	004440	074264		EDT1
	004442	074354		EFT1
547				
548			:ERROR	265 ERRONEOUS IVC ERROR DURING SEARCH - VOLUME IS VALID
549				
	004444	073004		EMT265
	004446	074140		EHT1
	004450	074264		EDT1
	004452	074354		EFT1
550				
551			:ERROR	266 DEVICE FAULT (DVC) DURING SEARCH
552				
	004454	073024		EMT266
	004456	074140		EHT1
	004460	074264		EDT1
	004462	074354		EFT1
553				
554			:ERROR	267 SKI SHOULD HAVE BEEN SET BECAUSE CYLINDER
555			:	ADDRESS IS TOO LARGE
556				
	004464	073036		EMT267

004466	074140	EHT1	
004470	074264	EDT1	
004472	074354	EFT1	
557			
558		:ERROR	270 OPI ERROR DURING SEARCH BECAUSE MOL = 0
559			
004474	073054	EMT270	
004476	074140	EHT1	
004500	074264	EDT1	
004502	074354	EFT1	
560			
561		:ERROR	271 OPI ERROR DURING SEARCH BECAUSE ON CYLINDER
562		:	DIDN'T DROP
563			
004504	073070	EMT271	
004506	074140	EHT1	
004510	074264	EDT1	
004512	074354	EFT1	
564			
565		:ERROR	272 LOST MOL DURING SEARCH, OPI IS NOT SET
566			
004514	073106	EMT272	
004516	074140	EHT1	
004520	074264	EDT1	
004522	074354	EFT1	
567			
568		:ERROR	273 PIP STIL SET AFTER SEARCH
569			
004524	073124	EMT273	
004526	074140	EHT1	
004530	074264	EDT1	
004532	074354	EFT1	
570			
571		:ERROR	274 PARITY ERROR OCCURRED WHILE WRITING REMOTE
572		:	REGISTERS BUT MXF DID NOT SET
573			
004534	073142	EMT274	
004536	074140	EHT1	
004540	074264	EDT1	
004542	074354	EFT1	
574			
575		:ERROR	275 MXF ERROR - COMPOSITE ERROR OCCURRED BEFORE DATA
576		:	COMMAND STARTED
577			
004544	073160	EMT275	
004546	074140	EHT1	
004550	074264	EDT1	
004552	074354	EFT1	
578			
579		:ERROR	276 'OPI' ERROR DURING DATA TRANSFER BECAUSE 'MOL' WAS

ERROR POINTER TABLE

580			:	ZERO
581				
	004554	073172		EMT276
	004556	074140		EHT1
	004560	074264		EDT1
	004562	074354		EFT1
582				
583			:ERROR	277 'OPI' ERROR DURING DATA TRANSFER BECAUSE 1) ON
584			:	CYLINDER DIDN'T DROP OR 2) SEARCH TIMED OUT OR
585			:	3) RUN TIMED OUT
586				
	004564	073206		EMT277
	004566	074140		EHT1
	004570	074264		EDT1
	004572	074354		EFT1
587				
588			:ERROR	300 'IVC' ERROR DURING DATA TRANSFER BECAUSE VOLUME
589			:	WAS NOT VALID
590				
	004574	073224		EMT300
	004576	074140		EHT1
	004600	074264		EDT1
	004602	074354		EFT1
591				
592			:ERROR	301 ERRONEOUS 'IVC' ERROR DURING DATA TRANSFER - VOLUME
593			:	IS VALID
594				
	004604	073244		EMT301
	004606	074140		EHT1
	004610	074264		EDT1
	004612	074354		EFT1
595				
596			:ERROR	302 'ILR' ERROR DURING DATA TRANSFER
597				
	004614	073266		EMT302
	004616	074140		EHT1
	004620	074264		EDT1
	004622	074354		EFT1
598				
599			:ERROR	303 'ILF' ERROR DURING DATA TRANSFER
600				
	004624	073300		EMT303
	004626	074140		EHT1
	004630	074264		EDT1
	004632	074354		EFT1
601				
602			:ERROR	304 'RMR' ERROR DURING DATA TRANSFER
603				
	004634	073312		EMT304
	004636	074140		EHT1
	004640	074264		EDT1

ERROR POINTER TABLE

	004642	074354	EFT1	
604				
605				
606				:ERROR 305 INCORRECT 'IAE' STATUS DURING DATA TRANSFER
	004644	073324	EMT305	
	004646	074140	EHT1	
	004650	074264	EDT1	
	004652	074354	EFT1	
607				
608				
609				:ERROR 306 'SKI' ERROR DURING DATA TRANSFER
	004654	073336	EMT306	
	004656	074140	EHT1	
	004660	074264	EDT1	
	004662	074354	EFT1	
610				
611				
612				:ERROR 307 DRIVE DID NOT DETECT SKI ERROR DUE TO CYLINDER
	004664	073346	EMT307	
	004666	074140	EHT1	
	004670	074264	EDT1	
	004672	074354	EFT1	
613				
614				
615				:ERROR 310 DEVICE FAULT DURING DATA TRANSFER
	004674	073366	EMT310	
	004676	074140	EHT1	
	004700	074264	EDT1	
	004702	074354	EFT1	
616				
617				
618				:ERROR 311 LOSS OF BIT CLOCK DURING DATA TRANSFER
	004704	073400	EMT311	
	004706	074140	EHT1	
	004710	074264	EDT1	
	004712	074354	EFT1	
619				
620				
621				:ERROR 312 LOSS OF SYSTEM CLOCK DURING DATA TRANSFER
	004714	073412	EMT312	
	004716	074140	EHT1	
	004720	074264	EDT1	
	004722	074354	EFT1	
622				
623				
624				:ERROR 313 UNSAFE ERROR DURING DATA TRANSFER (DVC = 0)
	004724	073424	EMT313	
	004726	074140	EHT1	
	004730	074264	EDT1	
	004732	074354	EFT1	

625			
626		:ERROR 314	DRIVE TIMING ERROR DURING DATA TRANSFER
627	004734	073444	EMT314
	004736	074140	EHT1
	004740	074264	EDT1
	004742	074354	EFT1
628			
629		:ERROR 315	WRITE LOCK ERROR
630	004744	073456	EMT315
	004746	074140	EHT1
	004750	074264	EDT1
	004752	074354	EFT1
631			
632		:ERROR 316	ERRONEOUS WRITE LOCK ERROR
633	004754	073470	EMT316
	004756	074140	EHT1
	004760	074264	EDT1
	004762	074354	EFT1
634			
635		:ERROR 317	HEADER CRC ERROR DURING DATA TRANSFER
636	004764	073502	EMT317
	004766	074140	EHT1
	004770	074264	EDT1
	004772	074354	EFT1
637			
638		:ERROR 320	FORMAT ERROR DURING DATA TRANSFER
639	004774	073512	EMT320
	004776	074140	EHT1
	005000	074264	EDT1
	005002	074354	EFT1
640			
641		:ERROR 321	HEADER COMPARE ERROR DURING DATA TRANSFER
642	005004	073522	EMT321
	005006	074140	EHT1
	005010	074264	EDT1
	005012	074354	EFT1
643			
644		:ERROR 322	HEADER ERRORS SHOULD NOT BE SET
645	005014	073532	EMT322
	005016	074140	EHT1
	005020	074264	EDT1
	005022	074354	EFT1

646			
647			:ERROR 323 DATA CHECK ERROR DURING DATA TRANSFER
648			
	005024	073540	EMT323
	005026	074140	EHT1
	005030	074264	EDT1
	005032	074354	EFT1
649			
650			:ERROR 324 CORRECTABLE DATA CHECK ERROR DURING DATA TRANSFER
651			
	005034	073550	EMT324
	005036	074140	EHT1
	005040	074264	EDT1
	005042	074354	EFT1
652			
653			:ERROR 325 UNCORRECTABLE DATA CHECK ERROR DURING DATA TRANSFER
654			
	005044	073562	EMT325
	005046	074140	EHT1
	005050	074264	EDT1
	005052	074354	EFT1
655			
656			:ERROR 326 DATA PARITY ERROR DURING READ COMMAND
657			
	005054	073574	EMT326
	005056	074140	EHT1
	005060	074264	EDT1
	005062	074354	EFT1
658			
659			:ERROR 327 OFFSET MODE NOT RESET BY WRITE COMMAND
660			
	005064	073612	EMT327
	005066	074140	EHT1
	005070	074264	EDT1
	005072	074354	EFT1
661			
662			:ERROR 330 DATA PARITY ERROR DURING WRITE COMMAND
663			
	005074	073624	EMT330
	005076	074140	EHT1
	005100	074264	EDT1
	005102	074354	EFT1
664			
665			:ERROR 331 WRITE CLOCK FAILURE DURING WRITE COMMAND
666			
	005104	073634	EMT331
	005106	074140	EHT1
	005110	074264	EDT1
	005112	074354	EFT1
667			

668		:ERROR 332	DATA LATE ERROR DURING DATA TRANSFER
669			
	005114 073646		EMT332
	005116 074140		EHT1
	005120 074264		EDT1
	005122 074354		EFT1
670		:ERROR 333	PIP STIL SET AFTER DATA TRANSFER - SKI = 0
671			
672			
	005124 073660		EMT333
	005126 074140		EHT1
	005130 074264		EDT1
	005132 074354		EFT1
673		:ERROR 334	LOST MOL DURING DATA TRANSFER - OPI = 0
674			
675			
	005134 073676		EMT334
	005136 074140		EHT1
	005140 074264		EDT1
	005142 074354		EFT1
676		:ERROR 335	LOST VOLUME VALID DURING DATA TRANSFER - IVC = 0
677			
678			
	005144 073714		EMT335
	005146 074140		EHT1
	005150 074264		EDT1
	005152 074354		EFT1
679		:ERROR 336	DATA READ DOES NOT COMPARE WITH DATA WRITTEN
680			
681			
	005154 073734		EMT336
	005156 074222		EHT336
	005160 074320		EDT336
	005162 074410		EFT336
682		:ERROR 337	WRITE CHECK ERROR NOT DETECTED
683			
684			
	005164 073744		EMT337
	005166 074234		EHT337
	005170 074330		EDT337
	005172 074420		EFT337
685		:ERROR 340	WRITE CHECK ERROR AT UNEXPECTED ADDRESS
686			
687			
	005174 073754		EMT340
	005176 074222		EHT336
	005200 074320		EDT336
	005202 074410		EFT336
688		:ERROR 341	INCORRECT DATA DURING WRITE CHECK ERROR
689			

ERROR POINTER TABLE

690	005204	073766	EMT341	
	005206	074222	EHT336	
	005210	074320	EDT336	
	005212	074410	EFT336	
691				
692			:ERROR	342 "IVC" ERROR NOT DETECTED DURING DATA TRANSFER
693	005214	073774	EMT342	
	005216	074140	EHT1	
	005220	074264	EDT1	
	005222	074354	EFT1	
694				
695			:ERROR	343 "FER" NOT DETECTED DURING DATA TRANSFER
696	005224	074006	EMT343	
	005226	074140	EHT1	
	005230	074264	EDT1	
	005232	074354	EFT1	
697				
698			:ERROR	344 "HCE" NOT DETECTED DURING DATA TRANSFER
699	005234	074020	EMT344	
	005236	074246	EHT344	
	005240	074340	EDT344	
	005242	074430	EFT344	
700				
701			:ERROR	345 "BSE" NOT DETECTED DURING DATA TRANSFER
702	005244	074032	EMT345	
	005246	074140	EHT1	
	005250	074264	EDT1	
	005252	074354	EFT1	
703				
704			:ERROR	346 HEADER ERROR WAS DETECTED W/ HCI SET
705	005254	074042	EMT346	
	005256	074140	EHT1	
	005260	074264	EDT1	
	005262	074354	EFT1	
706				
707			:ERROR	347 DATA TRANSFER NOT ABORTED W/ COMP ERROR SET
708	005264	074056	EMT347	
	005266	074140	EHT1	
	005270	074264	EDT1	
	005272	074354	EFT1	
709				
710			:ERROR	350 LOST VOLUME VALID DURING SEARCH - "IVC" = 0
711				

ERROR POINTER TABLE

005274	074070	EMT350
005276	074140	EHT1
005300	074264	EDT1
005302	074354	EFT1

712
713
714

```

;ERROR 351 'ATA' DID NOT SET DURING SEARCH

```

005304	074106	EMT351
005306	074140	EHT1
005310	074264	EDT1
005312	074354	EFT1

715
716
717

```

;ERROR 352 PROGRAM TIMEOUT WHILE TESTING RMLA

```

005314	074116	EMT352
005316	000000	0
005320	000000	0
005322	000000	0

718
719
720

```

;ERROR 353 LOOK AHEAD TEST FAILS

```

005324	074122	EMT353
005326	074260	EHT353
005330	074352	EDT353
005332	074440	EFT353

721
722
723

```

;ERROR 354 BSE SHOULD NOT BE SET

```

005334	074132	EMT354
005336	074140	EHT1
005340	074264	EDT1
005342	074354	EFT1

724
725

```

;PUT ERROR TABLE HERE

```

ERROR TABLE USAGE

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28

.SBTTL ERROR TABLE USAGE

:THE ERROR TABLE ABOVE CONSISTS OF FOUR WORD ENTRIES FOR EACH ERROR
:NUMBER, I.E.,: EMT - ERROR MESSAGE TABLE ADDRESS
: EHT - ERROR HEADER TABLE ADDRESS
: EDT - ERROR DATA TABLE ADDRESS
: EFT - ERROR FORMAT TABLE ADDRESS:THE EMT ENTRY IS THE ADDRESS OF THE TABLE OF ERROR MESSAGE STRINGS
:FOR THE PARTICULAR ERROR. EACH ERROR MESSAGE TABLE LISTS THE ADDRESS
:OF ONE OR MORE ERROR MESSAGE STRINGS WHICH ARE TO BE FORMATTED AND
:TYPED BY THE ERROR TYPE SUBROUTINE. IF THE EMT ENTRY IS ZERO, THERE IS
:NO MESSAGE TO BE TYPED FOR THE ERROR.:SIMILARLY, THE EHT, EDT, AND EFT ENTRIES ARE ADDRESSES OF TABLES
:OF HEADER, DATA AND FORMAT INFORMATION FOR A GIVEN ERROR. EACH ENTRY
:IN THE ERROR HEADER TABLE MAY OR MAY NOT HAVE AN ASSOCIATED LINE OF
:DATA, HOWEVER, EACH DATA LINE MUST HAVE AN ASSOCIATED FORMAT AND
:HEADER. THAT IS, A HEADER LINE MAY BE PRINTED WITHOUT ANY DATA,
:BUT A DATA LINE IS NOT PRINTED WITHOUT A HEADER, AND EACH DATA LINE
:MUST ALSO HAVE A FORMAT.

:IN SUMMARY,

: EACH NONZERO ENTRY IS THE ADDRESS OF A TABLE,
: EACH TABLE IS A LIST OF ADDRESSES WHICH DEFINES THE LOCATIONS
: OF MESSAGE STRINGS, HEADERS, DATA OR FORMAT.

```

1      ;THIS ROUTINE HANDLES UNEXPECTED TIMEOUTS
2
3 005344 011600      BADTMO: MOV    (SP),R0      ;SAVE PC WHERE THE TIME OUT OCCURED
4 005346 005740      TST    -(R0)      ;ADJUST PC -2
5 005350 022626      CMP    (SP)+,(SP)+  ;RESTORE STACK POINTER
6 005352 104401 005360  TYPE    65$      ;:TYPE ASCIZ STRING
   005356 000417      BR     64$      ;:GET OVER THE ASCIZ
   ;:65$: .ASCIZ <CRLF>/UNEXPECTED BUS TIMEOUT, PC=/
   64$:
7 005416 010046      MOV    R0,-(SP)    ;SETUP FOR TYPING OUT PC
8 005420 104402      TYPOC
9 005422 000240      NOP
   ;PUT 'HALT(0)' INSTRUCTION HERE IF YOU WISH
   ;TO STOP ON UNEXPECTED TIMEOUT.
10
11
12      .SBTTL  START OF PROGRAM
13
14 005424 012737 177777 001330  START1: MOV    #-1,CHGADR  ;CHANGE RH/RM BUS ADDRESS
15 005432 000402      BR     START2
16
17 005434 005037 001330  START:  CLR    CHGADR  ;NO CHANGE IN ADDRESS
18 005440 000240  START2: NOP
19 005442 005227 000000  INC     #0      ;TTY LOOP, WAIT FOR INCREMENT
20 005446 001375      BNE    -4      ;OF WORD
21 005450 000005      RESET     ;RESET THE WORLD
22
23      .SBTTL  INITIALIZE THE COMMON TAGS
   ;:CLEAR THE COMMON TAGS ($CMTAG) AREA
   MOV    #SCMTAG,R6  ;:FIRST LOCATION TO BE CLEARED
   CLR    (R6)+      ;:CLEAR MEMORY LOCATION
   CMP    #SWR,R6    ;:DONE?
   BNE    -6        ;:LOOP BACK IF NO
   MOV    #STACK,SP  ;:SETUP THE STACK POINTER
   ;:INITIALIZE A FEW VECTORS
   MOV    #SCOPE,@IOTVEC ;:IOT VECTOR FOR SCOPE ROUTINE
   MOV    #340,@IOTVEC+2 ;:LEVEL 7
   MOV    #ERROR,@EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
   MOV    #340,@EMTVEC+2 ;:LEVEL 7
   MOV    #TRAP,@TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
   MOV    #340,@TRAPVEC+2 ;:LEVEL 7
   MOV    #SPWRDN,@PWRVEC ;:POWER FAILURE VECTOR
   MOV    #340,@PWRVEC+2 ;:LEVEL 7
   MOV    $ENDCT,$EOPCT ;:SETUP END-OF-PROGRAM COUNTER
   CLR    $TIMES     ;:INITIALIZE NUMBER OF ITERATIONS
   CLR    $ESCAPE    ;:CLEAR THE ESCAPE ON ERROR ADDRESS
   MOVB   #1,$ERMAX  ;:ALLOW ONE ERROR PER TEST
   MOV    #,$SLPADR  ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
   MOV    #,$SLPERR  ;:SETUP THE ERROR LOOP ADDRESS
   ;:SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
   ;:EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
   MOV    @ERRVEC,-(SP) ;:SAVE ERROR VECTOR
   MOV    #64$,@ERRVEC ;:SET UP ERROR VECTOR
   MOV    #DSWR,$SWR ;:SETUP FOR A HARDWARE SWICH REGISTER
   MOV    #DDISP,$DISPLAY ;:AND A HARDWARE DISPLAY REGISTER
   CMP    #-1,$SWR   ;:TRY TO REFERENCE HARDWARE SWR
   BNE    66$       ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
   ;:AND THE HARDWARE SWR IS NOT = -1
   BR     65$       ;:BRANCH IF NO TIMEOUT

```



```

005652 012716 005660      64$:  MOV    #65$, (SP)      ;;SET UP FOR TRAP RETURN
005656 000002
005660 012737 000176 001154 65$:  MOV    #SWREG,SWR      ;;POINT TO SOFTWARE SWR
005666 012737 000174 001156  MOV    #DISPRÉG,DISPLAY
005674 012637 000004      66$:  MOV    (SP)+,@#ERRVEC    ;;RESTORE ERROR VECTOR

005700 005037 001230      CLR    $PASS            ;;CLEAR PASS COUNT
005704 132737 000200 001243  BITB   #APTSIZÉ,$ENVM   ;;TEST USER SIZE UNDER APT
005712 001403      BEQ    67$             ;;YES,USE NON-APT SWITCH
005714 012737 001244 001154  MOV    #$$SWREG,SWR     ;;NO,USE APT SWITCH REGISTER
005722
24 005722 012737 005344 000004 67$:  ;SETUP "TIMEOUT" TRAP VECTOR FOR UNEXPECTED BUS TIMEOUTS
25 005730 012737 000300 000006  MOV    #BADTMO,ERRVEC   ;;SETUP FOR UNEXPECTED TIMEOUT
26  MOV    #PR6,ERRVEC+2  ;;LEVEL 6
27
28 .SBTTL  TYPE PROGRAM NAME
   ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
005736 005227 177777      INC    #-1              ;;FIRST TIME?
005742 001033      BNE    68$             ;;BRANCH IF NO
005744 022737 033756 000042  CMP    #SENDAD,@#42     ;;ACT-11?
005752 001427      BEQ    68$             ;;BRANCH IF YES
005754 104401 005762      TYPE   ,69$           ;;TYPE ASCIZ STRING
005760 000424      BR     68$            ;;GET OVER THE ASCIZ
   ;;69$: .ASCIZ <CRLF>@CZRNFAD - RM80 FUNCTIONAL TEST, PT 3@<CRLF>
   68$:
   .SBTTL  GET VALUE FOR SOFTWARE SWITCH REGISTER
006032 005737 000042      TST    @#42            ;;ARE WE RUNNING UNDER XXDP/ACT?
006036 001012      BNE    70$            ;;BRANCH IF YES
006040 123727 001242 000001  CMPB   $ENV,#1         ;;ARE WE RUNNING UNDER APT?
006046 001406      BEQ    70$            ;;BRANCH IF YES
006050 023727 001154 000176  CMP    SWR,#SWREG      ;;SOFTWARE SWITCH REG SELECTED?
006056 001005      BNE    71$            ;;BRANCH IF NO
006060 104407      GTSWR                ;;GET SOFT-SWR SETTINGS
006062 000403      BR     71$
006064 112737 000001 001150 70$:  MOVB   #1,$AUTOB      ;;SET AUTO-MODE INDICATOR
006072 71$:

29
30 ;THE FOLLOWING FINDS OUT THE PROGRAM CONTROL MODE:
31 ;PAPER TAPE (MANUAL), ACT11, XXDP CHAIN OR DUMP
32
33 006072 005037 001332      CLR    XXDP            ;;CLEAR 'XXDP' LOAD DEVICE STORAGE
34 006076 122737 000016 000041  CMPB   #16,@#41       ;;LOADED FROM AN RM80 ?
35 006104 001121      BNE    3$             ;;BR IF NOT
36 006106 013737 000040 001332  MOV    @#40,XXDP      ;;GET DEVICE INDICATOR AND NUMBER
37 006114 122737 000007 001332  CMPB   #7,XXDP        ;;IS IT A VALID NUMBER ?
38 006122 103002      BHIS   1$            ;;YES
39 006124 105037 001332      CLRB   XXDP          ;;NO, DEFAULT TO DRIVE 0
40 006130 005737 000042 1$:  TST    @#42            ;;CHAIN MODE OR ACT11 AUTO ACCEPT ?
41 006134 001425      BEQ    2$            ;;BR IF NEITHER
42 006136 104401 006144      TYPE   ,73$         ;;TYPE ASCIZ STRING
006142 000412      BR     72$         ;;GET OVER THE ASCIZ
   ;;73$: .ASCIZ <CRLF>/NOT TESTING DRIVE /
   72$:
43 006170 005046      CLR    -(SP)          ;;CLEAR WORD ON STACK
44 006172 113716 001332  MOVB   XXDP,(SP)     ;;GET DRIVE ADDRESS
45 006176 104403      TYPOS                ;;TYPE THE ADDRESS
46 006200 001      .BYTE 1             ;;ONLY 1 CHARACTER

```

```

47 006201      000      .BYTE 0      ;SUPRESS LEADING ZEROS
48 006202 104401 001217 TYPE 3$      ;CR-LF
49 006206 000460      BR 3$      ;GET NUMBER OF DRIVES
50
51 006210 005227 177777 2$: INC #-1      ;FIRST TIME THRU HERE ?
52 006214 001055      BNE 3$      ;NO
53 006216 104401 006224 TYPE 75$     ;TYPE ASCIZ STRING
    006222 000410      BR 74$     ;GET OVER THE ASCIZ
    ;75$: .ASCIZ <CRLF>/TO TEST DRIVE /
    74$:
54 006244 005046      CLR -(SP)    ;CLEAR WORD ON STACK
55 006246 113716 001332 MOVB XXDP,(SP) ;GET DRIVE ADDRESS
56 006252 104403      TYPOS      ;TYPE DRIVE ADDRESS
57 006254      001      .BYTE 1      ;ONLY 1 CHARACTER
58 006255      000      .BYTE 0      ;SUPRESS LEADING ZEROS
59 006256 104401 006264 TYPE 76$     ;TYPE ASCIZ STRING
    006262 000432      BR 3$      ;GET OVER THE ASCIZ
    ;76$: .ASCIZ /, HALT PROGRAM, CLEAR LOC. 40 AND RESTART PROGRAM./<CRLF>
    3$:
    006350
63
64 ;CHECK FOR AUTO MODE OR STANDALONE MODE
65 006350 005737 000042 TST 242     ;RUNNING IN AUTO MODE ?
66 006354 001537      BEQ STANDALONE ;BR IF NO
67 006356 012737 000377 001300 MOV #377,$DEV ;SET DEVICE MAP FOR ALL DRIVES
68
69 ;PROGRAM IS RUNNING IN AUTO MODE - SEE IF SIZING IS ALLOWED
70 XSIZ:
71 006364 132737 000200 001243 BITB #BIT7,$ENVM ;SIZING ALLOWED ?
72 006372 001124      BNE 12$     ;NO
73
74 006374 005001      CLR R1      ;START FROM DRIVE 0
75 006376 013700 001276 MOV $BASE,R0 ;LOAD THE BASE ADDRESS
76 006402 104401 067044 TYPE ,SYSTAT ;TYPE 'UNIT STATUS:'
77
78 006406 136137 067344 001300 1$: BITB ATNTBL(R1),$DEV ;IS DEVICE PRESENT IN MAP ?
79 006414 001507      BEQ 11$     ;BR IF NO
80 006416 104401 001217 TYPE 3$      ;CR-LF
81 006422 010146      MOV R1,-(SP) ;SAVE R1 FOR TYPEOUT
    006424 104403      TYPOS      ;GO TYPE--OCTAL ASCII
    006426      002      .BYTE 2      ;TYPE 2 DIGIT(S)
    006427      000      .BYTE 0      ;SUPPRESS LEADING ZEROS
82 006430 104401 067236 TYPE ,BLNKS4 ;TYPE 4 BLANKS
83
84 006434 012760 000040 000010 MOV #CLR,RMCS2(R0) ;CLEAR MASS BUS
85 006442 010160 000010 MOV R1,RMCS2(R0) ;LOAD THE DRIVE ADDRESS
86 006446 005760 000012 TST RMD5(R0) ;ACCESS DRIVE REGISTER
87 006452 032760 010000 000010 BIT #NED,RMCS2(R0) ;IS DRIVE PRESENT ?
88 006460 001027      BNE 3$      ;BR IF NO
89 006462 032760 004000 000000 BIT #DVA,RMCS1(R0) ;IS DRIVE AVAILABLE ?
90 006470 001426      BEQ 4$      ;BR IF NO
91 006472 012737 067062 006632 MOV #SRM80,10$ ;ASSUME RM80 DEVICE
92 006500 022760 020026 000026 CMP #20026,RMDT(R0) ;SINGLE PORT RM80 ?
93 006506 001407      BEQ 2$      ;BR IF YES
94 006510 022760 024026 000026 CMP #24026,RMDT(R0) ;DUAL PORT RM80 ?
95 006516 001403      BEQ 2$      ;BR IF YES
96 006520 104401 067067 TYPE ,NOTRM ;DRIVE NOT AN RM80
97 006524 000412      BR 5$      ;CHECK NEXT DRIVE
    
```

98	006526	032760	010000	000012	2\$:	BIT	#MOL,RMDS(R0)	:IS MEDIUM ON LINE ?
99	006534	001412				BEQ	6\$:BR IF NO
100	006536	000417				BR	7\$	
101								
102	006540	104401	067121		3\$:	TYPE	,NOTPRS	:DRIVE NOT PRESENT
103	006544	000402				BR	5\$:CHECK NEXT DRIVE
104								
105	006546	104401	067136		4\$:	TYPE	,NOTAVL	:DRIVE NOT AVAILABLE
106	006552	146137	067344	001300	5\$:	BICB	ATNTBL(R1),SDEVM	:CLEAR DEVICE FROM BIT MAP
107	006560	000425				BR	11\$:CHECK NEXT DRIVE
108								
109	006562	104401	067155		6\$:	TYPE	,UNTOFF	:DRIVE OFFLINE
110	006566	146137	067344	001300		BICB	ATNTBL(R1),SDEVM	:CLEAR DEVICE FROM BIT MAP
111	006574	000413				BR	9\$:PRINT DRIVE TYPE
112								
113	006576	005737	001332		7\$:	TST	XXDP	:LOADED FROM RM80 ?
114	006602	001406				BEQ	8\$:NO
115	006604	123701	001332			CMPB	XXDP,R1	:IS THIS THE DRIVE ?
116	006610	001003				BNE	8\$:BR IF NO
117	006612	104401	067104			TYPE	,LODEV	:DRIVE IS LOAD DEVICE
118	006616	000755				BR	5\$	
119								
120	006620	104401	067166		8\$:	TYPE	,UNTON	:DRIVE ONLINE
121	006624	104401	067240		9\$:	TYPE	,BLNKS2	:TYPE 2 BLANKS
122	006630	104401				TYPE		:PRINT DRIVE TYPE
123	006632	000000			10\$:	.WORD	0	:MESSAGE ADDRESS HERE
124								
125	006634	005201			11\$:	INC	R1	:INCREMENT THE DRIVE ADDRESS
126	006636	020127	000007			CMP	R1,#7	:ALL DRIVES ARE CHECKED ?
127	006642	003661				BLE	1\$:BRANCH IF NOT
128								
129	006644	104401	001217		12\$:	TYPE	,\$CRLF	:CR-LF
130	006650	000137	007332			JMP	CMNSTART	:JUMP TO COMMON START

```

1          .SBTTL  STANDALONE INPUT ROUTINES
2
3          STANDALONE:
4 006654   JSR      PC,$TKINT      ;INITIALIZE CONSOLE
5
6 006660   INC      #-1           ;FIRST TIME THRU HERE ?
7 006664   BNE      2$           ;BR IF NO
8
9          ;SEE IF OPERATOR WANTS HELP TEXT
10
11 006666   TYPE     ,MSHELP       ;WANT HELP ?
12 006672   RDCHR    ;             ;GET RESPONSE
13 006674   MOV      (SP)+,$TMP1   ;SAVE AND ECHO RESPONSE
14 006700   CMPB    $TMP1,#'Y     ;WAS IT A YES RESPONSE ?
15 006706   BNE      1$           ;NO
16 006710   TYPE     , $TMP1      ;TYPE 'Y'
17 006714   TYPE     ,HELP       ;YES - TYPE HELP TEXT
18 006720   BR       3$
19 006722   1$:     TYPE     ,N     ;TYPE 'N'
20 006726   TYPE     , $CRLF      ;CR-LF
21 006732   BR       3$
22
23          ;SEE IF USER WANTS TO CHANGE UNIBUS ADDRESS
24 006734   2$:
25 006734   TST      CHGADR        ;CHANGE RH/RM BUS ADDRESS ?
26 006740   BEQ      7$           ;BR IF NO
27 006742   CLR      CHGADR        ;NO CHANGE NEXT TIME
28 006746   TYPE     , $CRLF      ;CR-LF
29
30          ;DIALOGUE TO CHANGE THE UNIBUS ADDRESS, VECTOR ADDRESS AND INTERRUPT PRIORITY
31 006752   3$:
32 006752   TYPE     ,CNSL01      ;TYPE CURRENT BUS ADDRESS
33 006756   MOV      $BASE,-(SP)   ;SAVE $BASE FOR TYPEOUT
34 006762   TYPOC   ;             ;GO TYPE--OCTAL ASCII(ALL DIGITS)
35 006764   TYPE     ,BLNKS2      ;TYPE 2 BLANKS
36 006770   RDOCT   ;             ;GET NEW BUS ADDRESS
37 006772   MOV      (SP)+,$TMP1  ;CARRIAGE RETURN ?
38 006776   BEQ      5$           ;YES-SKIP TO NEXT ENTRY
39 007000   CMP      #160000,$TMP1 ;BASE ADDRESS IN I/O PAGE ?
40 007006   BLOS    4$           ;YES
41 007010   TYPE     ,CNSL02      ;TYPE WARNING MESSAGE
42 007014   BR       3$          ;TRY AGAIN
43 007016   MOV      $TMP1,$BASE   ;STORE NEW BUS ADDRESS
44 007024   5$:     TYPE     ,CNSL03
45 007030   CLR      -(SP)
46 007032   MOVB    $VECT1,(SP)  ;GET CURRENT VECTOR ADDRESS
47 007036   TYPOC   ;             ;GO TYPE--OCTAL ASCII(ALL DIGITS)
48 007040   TYPE     ,BLNKS2      ;TYPE 2 BLANKS
49 007044   RDOCT   ;             ;GET NEW VECTOR ADDRESS
50 007046   MOV      (SP)+,$TMP1  ;CARRIAGE RETURN?
51 007052   BEQ      7$           ;YES-SKIP TO NEXT ENTRY
52 007054   CMP      #1000,$TMP1 ;VECTOR ADDRESS < 1000 ?
53 007062   BHI     6$           ;YES!!
54 007064   TYPE     ,CNSL04      ;TYPE WARNING MESSAGE
55 007070   BR       5$          ;RETRY
56 007072   MOVB    $TMP1,$VECT1  ;STORE NEW VECTOR ADDRESS

```

```

57
58          : DIALOGUE TO INPUT DEVICE NUMBERS
59 007100 005227 177777 7$: INC # -1 ; FIRST TIME THRU ?
60 007104 001002      BNE 8$ ; BR IF NO
61 007106 104401 066636      TYPE ,CNSLO7 ; TYPE INPUT INSTRUCTIONS
62 007112 104401 001217 8$: TYPE ,SCRLF ; CR-LF
63 007116 005037 001300 9$: CLR $DEVN ; CLEAR DEVICE MAP
64 007122 104401 067022      TYPE ,MSDRVS ; TYPE 'DRIVE(S): '
65 007126 104411      RDCHR
66 007130 012637 001176      MOV (SP)+,$TMP1 ; GET RESPONSE
67 007134 023727 001176 000101  CMP $TMP1,#'A ; IS INPUT 'A' ?
68 007142 001007      BNE 10$ ; NO
69 007144 104401 066074      TYPE ,ALL ; YES, TYPE 'ALL' AND GO
70 007150 012737 000377 001300  MOV #377,$DEVN ; SET DEVICE MAP FOR ALL DRIVES
71 007156 000137 006364      JMP XSIZ ; AUTO SIZE.
72
73 007162 023727 001176 000015 10$: CMP $TMP1,#CR ; CARRIAGE RETURN ?
74 007170 001436      BEQ 12$ ; YES
75 007172 104401 001176      TYPE , $TMP1 ; ECHO RESPONSE
76 007176 023727 001176 000060  CMP $TMP1,#'0 ; NUMBER < 0 ?
77 007204 002430      BLT 12$ ; YES
78 007206 023727 001176 000067  CMP $TMP1,#'7 ; NUMBER > 7 ?
79 007214 003427      BLE 13$ ; NO
80 007216 000423      BR 12$ ; ILLEGAL INPUT
81
82 007220 104411      RDCHR 11$:
83 007222 012637 001176      MOV (SP)+,$TMP1 ; GET RESPONSE
84 007226 023727 001176 000015  CMP $TMP1,#CR ; CARRIAGE RETURN ?
85 007234 001432      BEQ 14$ ; YES
86 007236 104401 066105      TYPE ,COMMA ; TYPE ' , '
87 007242 104401 001176      TYPE , $TMP1 ; ECHO RESPONSE
88 007246 023727 001176 000060  CMP $TMP1,#'0 ; NUMBER < 0 ?
89 007254 002404      BLT 12$ ; YES
90 007256 023727 001176 000067  CMP $TMP1,#'7 ; NUMBER > 7 ?
91 007264 003403      BLE 13$ ; NO
92 007266 104401 067000 12$: TYPE ,CNSLO8 ; TYPE '' ?ILLEGAL INPUT''
93 007272 000711      BR 9$ ; RETRY
94
95 007274 013701 001176 13$: MOV $TMP1,R1 ; R1 = DRIVE NUMBER
96 007300 042701 177770      BIC #^C7,R1
97 007304 156137 067344 001300  BISB ATNTBL(R1),$DEVN ; SET DEVICE IN MAP
98 007312 122737 000377 001300  CMPB #377,$DEVN ; DONE ?
99 007320 101337      BHI 11$ ; NO
100 007322 104401 001217 14$: TYPE ,SCRLF ; CR-LF
101 007326 000137 006364      JMP XSIZ ; GO SIZE DEVICES
    
```

```

1
2 007332
3 007332 104401 067176
4 007336 013700 001300
5 007342 001004
6 007344 104401 066105
7 007350 104401 067225
8 007354 012701 001470
9 007360 010137 001466
10 007364 012702 000001
11 007370 005003
12 007372 030700
13 007374 001413
14 007376 104401 066105
15 007402 010311
16 007404 010346
    007406 104403
    007410 001
    007411 000
17 007412 116361 067344 000001
18 007420 062701 000002
19 007424 006302
20 007426 105702
21 007430 001402
22 007432 005203
23 007434 000756
24 007436 005011
25 007440 104401 001217
26
27
28 007444 004737 040610
29 007450 000425
30 007452 104401 007460
    007456 000413
    007506
31 007506 005737 000042
32 007512 001002
33 007514 000137 005434
34 007520 000137 033746
35 007524
36
37 007524 000240
38 007526 105737 001300
39 007532 001007
40 007534 005737 000042
41 007540 001002
42 007542 000137 005434
43 007546 000137 033746
44
45 007552 105037 001116
46 007556 005037 001206
47 007562 005037 001326
48 007566 005037 001512
49 007572 004737 063670
50 007576 012746 000240
    007602 012746 007610

```

```

, ASSEMBLE TEST QUE FROM DEVICE MAP
CPMNSTART:
    TYPE      DRIVES      ;TYPE 'DRIVE(S) TO BE TESTED'
    MOV      $DEVN,R0      ;R0 = DEVICE MAP
    BNE      1$            ;BR IF DRIVES TO TEST
    TYPE      ,COMMA      ;TYPE ','
    TYPE      ,NONE       ;TYPE 'NONE'
1$:  MOV      #TSTQUE+2,R1 ;R1 = ADDRESS OF FIRST ENTRY IN QUE
    MOV      R1,TSTQUE     ;INITIALIZE ENTRY POINTER
    MOV      #1,R2        ;R2 = DEVICE POINTER
    CLR      R3           ;R3 = DEVICE NUMBER
2$:  BIT      R2,R0        ;IS THIS DEVICE IN MAP ?
    BEQ      3$           ;NO !!
    TYPE      ,COMMA      ;TYPE ','
    MOV      R3,(R1)      ;YES - ENTER DEVICE NUMBER IN QUE
    MOV      R3,-(SP)     ;SAVE R3 FOR TYPEOUT
    TYPOS    1           ;GO TYPE--OCTAL ASCII
    .BYTE    1           ;TYPE 1 DIGIT(S)
    .BYTE    0           ;SUPPRESS LEADING ZEROS
    MOVB     ATNTBL(R3),1(R1);ENTER ATTENTION BIT IN QUE
    ADD      #2,R1        ;ADVANCE ENTRY POINTER
3$:  ASL      R2           ;ADVANCE DEVICE POINTER
    TSTB     R2           ;DONE ALL DEVICES ?
    BEQ      4$           ;YES
    INC      R3           ;ADVANCE DEVICE NUMBER
    BR       2$          ;ENTER NEXT DEVICE
4$:  CLR      (R1)        ;TERMINATE TEST QUE
    TYPE     ,$CRLF      ;CR-LF

;SIZE FOR CLOCK
    JSR     PC,SIZCLK    ;SEE IF CLOCK PRESENT
    BR      6$           ;YES - CLOCK IS PRESENT
    TYPE    ,65$        ;TYPE ASCII STRING
    BR      64$         ;GET OVER THE ASCII
65$: .ASCII <CRLF>/NO 'L' OR 'P' CLOCK/
64$:
    TST     @#42        ;ANY MONITOR PRESENT ?
    BNE     5$          ;BR IF YES
    JMP     START       ;JUMP TO START
5$:  JMP     $GET42      ;RETURN CONTROL TO MONITOR
6$:
READY: NOP
    TSTB    $DEVN       ;ANY DRIVES IN MAP ?
    BNE     2$         ;BR IF YES
    TST     @#42        ;ANY MONITOR PRESENT ?
    BNE     1$         ;BR IF YES
    JMP     START       ;JUMP TO START
1$:  JMP     $GET42      ;RETURN CONTROL TO MONITOR
2$:  CLRB    $TSTNM     ;RESET TEST NUMBER
    CLR     $TIMES      ;INITIALIZE NUMBER OF ITERATIONS
    CLR     CTLFG       ;CLEAR CONTROL-C FLAG
    CLR     MEDENB      ;CLEAR MEDIA ENABLE
    JSR     PC,$TKINT   ;INITIALIZE TTY
    MOV     #PR5,-(SP)  ;PUT NEW PS ON STACK
    MOV     #64$,-(SP)  ;PUT NEW PC ON STACK

```

```

007606 000002          RTI          ;;POP NEW PC AND PS
007610
51 007610 117737 171652 001234 64$:  MOVB  @TSTQUE,$UNIT  ;LOAD DRIVE NUMBER
52
53          ;CLEAR MASSBUS CONTROLLER, SELECT DRIVE AND SET LAST TRACK ADDRESS
54 007616 013700 001276      MOV  $BASE,R0      ;R0 = UNIBUS ADDRESS
55 007622 012760 000040 000010  MOV  #CLR,RMCS2(R0) ;CLEAR MASSBUS
56 007630 113760 001234 000010  MOVB $UNIT,RMCS2(R0) ;SELECT DEVICE UNDER TEST
57 007636 012737 006400 001334  MOV  #TAB!TA4!TA1,LSTRK ;SET LAST TRACK = 13.
58
59          ;TYPE DRIVE NUMBER TO BE TESTED($UNIT)
60 007644 104401 001217      TYPE  .SCRLF      ;CR-LF
61 007650 104401 067036      TYPE  .MSGDRV     ;TYPE 'DRIVE'
62 007654 013746 001234      MOV  $UNIT,-(SP)  ;SAVE $UNIT FOR TYPEOUT
                    ;TYPE DRIVE NUMBER
                    ;GO TYPE--OCTAL ASCII
                    ;TYPE 2 DIGIT(S)
                    ;SUPPRESS LEADING ZEROS
                    ;THESE TWO LOOPS ARE ADDED TO
                    ;WAIT FOR TTY
007660 104403          TYPOS
007662 002          .BYTE 2
007663 000          .BYTE 0
63 007664 005004      CLR  R4
64 007666 005304      DEC  R4
65 007670 001376      BNE  .-2
66 007672 005304      DEC  R4
67 007674 001376      BNE  .-2
    
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36

```

007676
007676 000004
007700 000240
007702 012706 001100
007706 013700 001276
007712 013701 001466
007716 012737 000001 001226

007724 005001
007726 013746 000004
007732 013746 000006
007736 012737 010040 000004
007744 012737 000300 000006

007752 110160 000001
007756 010160 000002
007762 016002 000002
007766 010160 000004
007772 016002 000004
007776 016046 000010
010002 010160 000010
010006 016002 000010
010012 012660 000010
010016 010160 000022
010022 016002 000022
010026 012637 000006
010032 012637 000004
010036 000417

010040 022626
010042 012637 000006
010046 012637 000004
010052 104110
010054 005737 000042
010060 001002
010062 000137 005424
010066 005037 001300
010072 000137 033746
010076
    
```

```

*****
*TEST 1          CONTROLLER ACCESS TEST
*****
TST1:
    
```

```

SCOPE          :SCOPE CALL
NOP            :START OF TEST
MOV #STACK,SP  :INITIALIZE STACK POINTER
MOV $BASE,R0   :R0 = UNIBUS ADDRESS
MOV TSTQUE,R1  :(R1) = DEVICE BEING TESTED
MOV #1,$TESTN  ;;SET TEST NUMBER IN APT MAIL BOX

CLR R1
MOV ERRVEC,-(SP) ;;PUSH ERRVEC ON STACK
MOV ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
MOV #1$,ERRVEC
MOV #PR6,ERRVEC+2

MOVB R1,RMCS1+1(R0) :MOVE HI BYTE TO RMCS1
MOV R1,RMWC(R0)     :MOVE WORD COUNT REGISTER
MOV RMWC(R0),R2
MOV R1,RMBA(R0)    :MOVE BUS ADDRESS REGISTER
MOV RMBA(R0),R2
MOV RMCS2(R0),-(SP) ;;PUSH RMCS2(R0) ON STACK
MOV R1,RMCS2(R0)   :MOVE CONTROL STATUS REGISTER
MOV RMCS2(R0),R2
MOV (SP)+,RMCS2(R0) ;;POP STACK INTO RMCS2(R0)
MOV R1,RMDB(R0)   :MOVE DATA BUFFER
MOV RMDB(R0),R2
MOV (SP)+,ERRVEC+2 ;;POP STACK INTO ERRVEC+2
MOV (SP)+,ERRVEC  ;;POP STACK INTO ERRVEC
BR 3$             :NO BUS TIMEOUT OCCURRED

1$: CMP (SP)+,(SP)+ :ADJUST STACK
MOV (SP)+,ERRVEC+2 ;;POP STACK INTO ERRVEC+2
MOV (SP)+,ERRVEC  ;;POP STACK INTO ERRVEC
EMT 110
TST 2#42          :STAND ALONE MODE ?
BNE 2$           :NO!!
JMP START1       :YES-GO GET $BASE
2$: CLR $DEVN    :FUDGE NO DRIVES IN MAP
JMP $GET42       :RETURN CONTROL TO MONITOR
3$:
    
```

```

*****
*TEST 2          WRITE, READ ZEROS
*****
TST2:
    
```

```

SCOPE          :SCOPE CALL
NOP            :START OF TEST
MOV #STACK,SP  :INITIALIZE STACK POINTER
MOV $BASE,R0   :R0 = UNIBUS ADDRESS
MOV TSTQUE,R1  :(R1) = DEVICE BEING TESTED
MOV #2,$TESTN  ;;SET TEST NUMBER IN APT MAIL BOX

*****
:LCOP #1        FORMAT,WRITE,READ
    
```



```

37
38 010124          1$:
39
40
41 010124 004737 034032 ;PREPARE DEVICE FOR TEST
    C10130 154130          JSR   PC,TSTPRP      ;PREPARE DEVICE FOR TEST
                                .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 2$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 25$ IF ERROR

    010132 000404          BR    2$
    010134 000240          NOP
    010136 104000          EMT
    010140 000137 011104  JMP    25$

42
43 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
44 2$:
45 010144 012737 001057 001446 MOV    #559.,RMDCO      ;CYLINDER = 559.
46 010152 012737 001000 001420 MOV    #TA2,RMDAO      ;TRACK = 2, SECTOR = 0
47 010160 012737 104254 001416 MOV    #BUFONE,RMBAO   ;BUS ADDRESS
48 010166 012737 17376 001414 MOV    #-258.,RMWCO    ;2 + 256. WORDS (2'S COMP)
49 010174 012737 010000 001444 MOV    #FMT16,RMFO    ;16 BIT FORMAT
50 010202 012737 000063 001412 MOV    #WH!GO,RMCS10  ;WRITE HEADER AND DATA COMMAND
51
52 ;VERIFY THAT SECTOR IS NOT BAD
    010210 004737 034762 JSR   PC,BADSCT      ;CALL BAD SECTOR MODULE
    010214 000405          BR    3$             ;GO TO 3$ IF NO ERROR
    010216 104401 066006 TYPE   .SCTMSG       ;TYPE BAD SECTOR MESSAGE
    010222 104000          EMT
    010224 000137 011104  JMP    25$       ;ERROR # DEFINED BY BADSCT SUBROUTINE
                                ;GO TO 25$ IF ERROR
53 3$:
54 010230 012737 067456 001176 MOV    #ZEROS,$TMP0   ;STARTING ADDRESS OF PATTERN
55 010236 012737 000001 001176 MOV    #1,$TMP1       ;RANGE OF PATTERN
56 010244 004737 037214 JSR   PC,GENBUF      ;GO GENERATE BUFFER FOR FORMAT
57
58 ;SETUP PARAMETERS AND EXECUTE COMMAND
    010250 012702 001555 MOV    #PUTINX,R2     ;R2 = BYTE ENTRY POSITION
59 010254 112722 000034 MOVB  #RMDC,(R2)+
60 010260 112722 000006 MOVB  #RMDA,(R2)+
61 010264 112722 000004 MOVB  #RMBA,(R2)+
62 010270 112722 000002 MOVB  #RMWC,(R2)+
63 010274 112722 000032 MOVB  #RMWF,(R2)+
64 010300 112722 000000 MOVB  #RMCS1,(R2)+
65 010304 112712 000200 MOVB  #200,(R2)       ;TERMINATE TABLE
66
67 4$:
68 010310 004737 040360 JSR   PC,PUT         ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    010314 000404          BR    5$             ;GO TO 5$ IF NO ERROR
    010316 000240          NOP
    010320 104000          EMT
    010322 000137 011104  JMP    25$       ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY PUT SUBROUTINE
                                ;GO TO 25$ IF ERROR
69 5$:
70
71 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
    010326 004737 040024 JSR   PC,GETSTS     ;GO TO GETSIS SUBROUTINE
    
```

```

72
73      C10332 004737 040732      :WAIT FOR COMMAND TO COMPLETE
      JSR      PC,TIMOUT      :GO TO TIMEOUT SUBROUTINE
74
75      :GO GET REGISTER STATUS
76      010336 004737 040110      JSR      PC,GET      :GO READ REGISTER(S) WITH GET SUBROUTINE
      010342 000404      BR      6$      :GO TO 6$ IF NO ERROR
      010344 000240      NOP      :RETURN HERE IF ERROR
      010346 104000      EMT      :ERROR # DEFINED BY GET SUBROUTINE
      010350 000137 011104      JMP      25$      :GO TO 25$ IF ERROR
77      010354      6$:
78
79      :VERIFY RESULTS OF WRITE COMMAND
80      010354 004737 054166      JSR      PC,DTASTS      :GO VERIFY RESULTS OF DATA TRANSFER
      010360 000405      BR      7$      :GO TO 7$ IF NO ERROR
      010364 000240      NOP      :RETURN HERE IF ERROR
      010366 104000      EMT      :ERROR # DEFINED BY DTASTS SUBROUTINE
      010370 004736      JSR      PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
      010374 000137 011104      JMP      25$      :GO TO 25$ IF ERROR
81
82
83      :MOVE LOOP ADDRESSES TO NEXT OPERATION
84      010374 012737 010404 001124      MOV      #8$,SLPERR
85      010402 000410      BR      9$      :SKIP TO WRITE OPERATION
86
87      :*****
88      :LOOP #2      WRITE,READ
89
90      010404      8$:
91
92      :PREPARE DEVICE FOR TEST
93      010404 004737 034032      JSR      PC,TSTPRP      :PREPARE DEVICE FOR TEST
      010410 154130      .WORD 154130      :TASK DESCRIPTOR AS FOLLOWS:
      :SELECT DEVICE & VERIFY DEVICE AVAILABLE
      :CLEAR CONTROLLER & SELECT DEVICE
      :VERIFY CONTROLLER CLEAR OPERATION
      :PACK ACKNOWLEDGE IF VOLUME NOT VALID
      :VERIFY PACK ACKNOWLEDGE
      :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      :VERIFY RECALIBRATION
      010412 000404      BR      9$      :GO TO 9$ IF NO ERROR
      010414 000240      NOP      :RETURN HERE IF ERROR
      010416 104000      EMT      :ERROR # DEFINED BY TSTPRP SUBROUTINE
      010420 000137 011104      JMP      25$      :GO TO 25$ IF ERROR
94      C10424      9$:
95
96      :SETUP PARAMETERS AND EXECUTE COMMAND
97      010424      10$:
98      010424 012737 104260 001416      MOV      #BUFONE+4,RMBAD      :MOVE MEMORY ADDRESS
99      010432 012737 177400 001414      MOV      #-256.,RMWCO      :CHANGE WORD COUNT
100     010440 012737 000061 001412      MOV      #WD!GO,RMCS10      :WRITE DATA COMMAND
101     010446 012702 001555      MOV      #PUTINX,R2      :LOAD PUT REGISTER INDEX TABLE
102     010452 112722 000006      MOVB     #RMDA,(R2)+
103     010456 112722 000034      MOVB     #RMDC,(R2)+
104     010462 112722 000032      MOVB     #RMCF,(R2)+
105     010466 112722 000004      MOVB     #RMBA,(R2)+
106     010472 112722 000002      MOVB     #RMWC,(R2)+

```

```

T2 WRITE, READ ZEROS
107 010476 112722 000000      MOVB  #RMC51,(R2)+
108 010502 112722 000200      MOVB  #200,(R2)+                ;TERMINATE TABLE
109
110 010506 004737 040360      JSR   PC,PUT                    ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    010512 000404              BR    11$                      ;GO TO 11$ IF NO ERROR
    010514 000240              NOP                               ;RETURN HERE IF ERROR
    010516 104000              EMT                               ;ERROR # DEFINED BY PUT SUBROUTINE
    010520 000137 011104      JMP   25$                      ;GO TO 25$ IF ERROR
111 010524                    11$:
112
113                    ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
    010524 004737 040024      JSR   PC,GETSTS                ;GO TO GETSTS SUBROUTINE
114
115                    ;WAIT FOR COMMAND TO COMPLETE
    010530 004737 040732      JSR   PC,TIMOUT                ;GO TO TIMOUT SUBROUTINE
116
117                    ;GO GET REGISTER STATUS
118 010534 004737 040110      JSR   PC,GET                    ;GO READ REGISTER(S) WITH GET SUBROUTINE
    010540 000404              BR    12$                      ;GO TO 12$ IF NO ERROR
    010542 000240              NOP                               ;RETURN HERE IF ERROR
    010544 104000              EMT                               ;ERROR # DEFINED BY GET SUBROUTINE
    010546 000137 011104      JMP   25$                      ;GO TO 25$ IF ERROR
119 010552                    12$:
120
121                    ;VERIFY RESULTS OF WRITE COMMAND
122 010552 004737 041126      JSR   PC,PRIERR                ;GO CHECK FOR PRIMARY ERRORS
    010556 000405              BR    13$                      ;GO TO 13$ IF NO ERROR
    010560 000240              NOP                               ;RETURN HERE IF ERROR
    010562 104000              EMT                               ;ERROR # DEFINED BY PRIERR SUBROUTINE
    010564 004736              JSP   PC,@(SP)+                ;GO BACK FOR MORE ERROR CHECKS
    010566 000137 011104      JMP   25$                      ;GO TO 25$ IF ERROR
123 010572                    13$:
124 010572 004737 054166      JSR   PC,DTASTS                ;GO VERIFY RESULTS OF DATA TRANSFER
    010576 000405              BR    14$                      ;GO TO 14$ IF NO ERROR
    010600 000240              NOP                               ;RETURN HERE IF ERROR
    010602 104000              EMT                               ;ERROR # DEFINED BY DTASTS SUBROUTINE
    010604 004736              JSR   PC,@(SP)+                ;GO BACK FOR MORE ERROR CHECKS
    010606 000137 011104      JMP   25$                      ;GO TO 25$ IF ERROR
125 010612                    14$:
126 010612 004737 041760      JSR   PC,SECERR                ;GO CHECK FOR SECONDARY ERRORS
    010616 000405              BR    15$                      ;GO TO 15$ IF NO ERROR
    010620 000240              NOP                               ;RETURN HERE IF ERROR
    010622 104000              EMT                               ;ERROR # DEFINED BY SECERR SUBROUTINE
    010624 004736              JSR   PC,@(SP)+                ;GO BACK FOR MORE ERROR CHECKS
    010626 000137 011104      JMP   25$                      ;GO TO 25$ IF ERROR
127 010632                    15$:
128
129                    ;CHANGE LOOP ADDRESSES
130 010632 012737 010642 001124  MOV   #16$,$LPERR
131 010640 000410              BR    17$                ;SKIP TO NEXT OPERATION
132
133                    ;*****
134                    ;LOOP #3      READ
135
136 01064?                    16$:
137
138                    ;PREPARE DEVICE FOR TEST

```

139	010642	004737	034032	.JSR	PC,TSTPRP		:PREPARE DEVICE FOR TEST
	010646	154130		.WORD	154130		:TASK DESCRIPTOR AS FOLLOWS:
							:SELECT DEVICE & VERIFY DEVICE AVAILABLE
							:CLEAR CONTROLLER & SELECT DEVICE
							:VERIFY CONTROLLER CLEAR OPERATION
							:PACK ACKNOWLEDGE IF VOLUME NOT VALID
							:VERIFY PACK ACKNOWLEDGE
							:RECALIBRATE IF 'SKI' OR 'PIP' IS SET
							:VERIFY RECALIBRATION
	010650	000404		BR	17\$:GO TO 17\$ IF NO ERROR
	010652	000240		NOP			:RETURN HERE IF ERROR
	010654	104000		EMT			:ERROR # DEFINED BY TSTPRP SUBROUTINE
	010656	000137	011104	JMP	25\$:GO TO 25\$ IF ERROR
140	010662					17\$:	
141							
142							:SETUP PARAMETERS AND EXECUTE COMMAND
143	010662					18\$:	
144	010662	012737	105264	MOV	#BUFTWO+4,RMBA0		:CHANGE MEMORY ADDRESS
145	010670	012737	000071	MOV	#RD!GO,RMCS10		:READ DATA COMMAND
146	010676	012702	001555	MOV	#PUTINX,R2		:LOAD PUT REGISTER INDEX TABLE
147	010702	112722	000006	MOVB	#RMDA,(R2)+		
148	010706	112722	000032	MOVB	#RMOF,(R2)+		
149	010712	112722	000034	MOVB	#RMDC,(R2)+		
150	010716	112722	000004	MOVB	#RMDA,(R2)+		
151	010722	112722	000002	MOVB	#RMC,(R2)+		
152	010726	112722	000000	MOVB	#RMCS1,(R2)+		
153	010732	112712	000200	MOVB	#200,(R2)		
154							
155	010736	004737	040360	JSR	PC,PUT		:GO WRITE REGISTER(S) WITH PUT SUBROUTINE
	010742	000404		BR	19\$:GO TO 19\$ IF NO ERROR
	010744	000240		NOP			:RETURN HERE IF ERROR
	010746	104000		EMT			:ERROR # DEFINED BY PUT SUBROUTINE
	010750	000137	011104	JMP	25\$:GO TO 25\$ IF ERROR
156	010754					19\$:	
157							
158							:SETUP GET INDEX TABLE TO READ ALL REGISTERS
	010754	004737	040024	JSR	PC,GETSTS		:GO TO GETSTS SUBROUTINE
159							
160							:WAIT FOR COMMAND TO COMPLETE
	010760	004737	040732	JSR	PC,TIMOUT		:GO TO TIMOUT SUBROUTINE
161							
162							:GO GET REGISTER STATUS
163	010764	004737	040110	JSR	PC,GET		:GO READ REGISTER(S) WITH GET SUBROUTINE
	010770	000404		BR	20\$:GO TO 20\$ IF NO ERROR
	010772	000240		NOP			:RETURN HERE IF ERROR
	010774	104000		EMT			:ERROR # DEFINED BY GET SUBROUTINE
	010776	000137	011104	JMP	25\$:GO TO 25\$ IF ERROR
164	011002					20\$:	
165							
166							:VERIFY RESULTS OF READ COMMAND
167	011002	004737	041126	JSR	PC,PRIERR		:GO CHECK FOR PRIMARY ERRORS
	011006	000405		BR	21\$:GO TO 21\$ IF NO ERROR
	011010	000240		NOP			:RETURN HERE IF ERROR
	011012	104000		EMT			:ERROR # DEFINED BY PRIERR SUBROUTINE
	011014	004736		JSR	PC,@(SP)+		:GO BACK FOR MORE ERROR CHECKS
	011016	000137	011104	JMP	25\$:GO TO 25\$ IF ERROR
168	011022					21\$:	

```

169 011022 004737 054166      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      011026 000405          BR      22$          ;GO TO 22$ IF NO ERROR
      011030 000240          NOP          ;RETURN HERE IF ERROR
      011032 104000          EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
      011034 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      011036 000137 011104    JMP     25$          ;GO TO 25$ IF ERROR
170 011042          22$:
171 011042 004737 041760      JSR    PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      011046 000405          BR      23$          ;GO TO 23$ IF NO ERROR
      011050 000240          NOP          ;RETURN HERE IF ERROR
      011052 104000          EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE
      011054 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      011056 000137 011104    JMP     25$          ;GO TO 25$ IF ERROR
172 011062          23$:
173
174          ;GO VERIFY DATA
175 011062 004737 037462      JSR    PC,CMPBUF     ;GO COMPARE WRITE, READ DATA BUFFERS
      011066 104260          .WORD  BUFOFF+4     ;STARTING ADDRESS OF WRITE BUFFER
      011070 105264          .WORD  BUFTWO+4    ;STARTING ADDRESS OF READ BUFFER
      011072 000404          BR      24$          ;GO TO 24$ IF NO ERROR
      011074 000240          NOP          ;RETURN HERE IF ERROR
      011076 104000          EMT          ;ERROR # DEFINED BY CMPBUF SUBROUTINE
      011100 000137 011104    JMP     25$          ;GO TO 25$ IF ERROR
176 011104          24$:
177
178 011104          25$:
179
180          ;*****
          ;*TEST 3          WRITE, WRITE CHECK ZEROS
          ;*****
          TST3:
          SCOPE          ;SCOPE CALL
          NOP          ;START OF TEST
          MOV    #STACK,SP ;INITIALIZE STACK POINTER
          MOV    $BASE,R0  ;R0 = UNIBUS ADDRESS
          MOV    TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
          MOV    #3,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
181
182          ;*****
183          ;LOOP #1          FORMAT,WRITE,WRITE CHECK DATA
184
185 011132          1$:
186
187          ;PREPARE DEVICE FOR TEST
188 011132 004737 034032      JSR    PC,TSTPRP     ;PREPARE DEVICE FOR TEST
      011136 154130          .WORD  154130      ;TASK DESCRIPTOR AS FOLLOWS:
          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
          ;CLEAR CONTROLLER & SELECT DEVICE
          ;VERIFY CONTROLLER CLEAR OPERATION
          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
          ;VERIFY PACK ACKNOWLEDGE
          ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
          ;VERIFY RECALIBRATION
          BR      2$          ;GO TO 2$ IF NO ERROR
          NOP          ;RETURN HERE IF ERROR
          EMT          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
          JMP     24$        ;GO TO 24$ IF ERROR
011140 000404          BR      2$
011142 000240          NOP
011144 104000          EMT
011146 000137 012062      JMP     24$
  
```

```

189
190      ;LOAD PARAMETERS AND GENERATE DATA BUFFER
191 011152      2$:
192 011152      012737 001057 001446      MOV      #559.,RMDCO      ;CYLINDER = 559.
193 011160      012737 001000 001420      MOV      #TA2,RMDAO      ;TRACK = 2, SECTOR = 0
194 011166      012737 104254 001416      MOV      #BUFONE,RMBAO    ;BUS ADDRESS
195 011174      012737 177376 001414      MOV      #-258.,RMWCO     ;2 + 256. WORDS (2'S COMP)
196 011202      012737 010000 001444      MOV      #FMT16,RMOFO    ;16 BIT FORMAT
197 011210      012737 000063 001412      MOV      #WH!GO,RMCS10   ;WRITE HEADER AND DATA COMMAND
198
199      ;VERIFY THAT SECTOR IS NOT BAD
      JSR      PC,BADSCCT   ;CALL BAD SECTOR MODULE
      BR      3$           ;GO TO 3$ IF NO ERROR
      TYPE    .SCTMSG     ;TYPE BAD SECTOR MESSAGE
      EMT
      JMP     24$         ;ERROR # DEFINED BY BADSCCT SUBROUTINE
                          ;GO TO 24$ IF ERROR
200 011236      3$:
201 011236      012737 067456 001174      MOV      #ZEROS,$TMP0    ;STARTING ADDRESS OF PATTERN
202 011244      012737 000001 001176      MOV      #1,$TMP1       ;RANGE OF PATTERN
203 011252      004737 037214      JSR      PC,GENBUF      ;GO GENERATE BUFFER FOR FORMAT
204
205      ;SETUP PARAMETERS AND EXECUTE COMMAND
      MOV     #PUTINX,R2   ;R2 = BYTE ENTRY POSITION
      MOVB   #RMDC,(R2)+
      MOVB   #RMDA,(R2)+
      MOVB   #RMBA,(R2)+
      MOVB   #RMWC,(R2)+
      MOVB   #RMOF,(R2)+
      MOVB   #RMCS1,(R2)+
      MOVB   #200,(R2)   ;TERMINATE TABLE
206 011256      012702 001555
207 011262      112722 000034
208 011266      112722 000006
209 011272      112722 000004
210 011276      112722 000002
211 011302      112722 000032
212 011306      112722 000000
213 011312      112712 000200
214 011316
215 011316      004737 040360      4$:
      JSR     PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      BR     5$          ;GO TO 5$ IF NO ERROR
      NOP
      EMT
      JMP     24$         ;RETURN HERE IF ERROR
                          ;ERROR # DEFINED BY PUT SUBROUTINE
                          ;GO TO 24$ IF ERROR
216 011334
217
218      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR     PC,GETSTS   ;GO TO GETSTS SUBROUTINE
219 011334      004737 040024
220      ;WAIT FOR COMMAND TO COMPLETE
      JSR     PC,TIMOUT   ;GO TO TIMEOUT SUBROUTINE
221 011340      004737 040732
222      ;GO GET REGISTER STATUS
      JSR     PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      BR     6$          ;GO TO 6$ IF NO ERROR
      NOP
      EMT
      JMP     24$         ;RETURN HERE IF ERROR
                          ;ERROR # DEFINED BY GET SUBROUTINE
                          ;GO TO 24$ IF ERROR
223 011344      004737 040110      6$:
      JSR     PC,GET
224 011350      000404
225 011352      000240
226 011354      104000
227 011356      000137 012062
228 011362
229 011362      004737 054166      ;VERIFY RESULTS OF WRITE COMMAND
      JSR     PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      BR     7$          ;GO TO 7$ IF NO ERROR
      NOP
      EMT
      EMT               ;RETURN HERE IF ERROR
                          ;ERROR # DEFINED BY DTASTS SUBROUTINE
    
```

```

011374 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
011376 000137 012062 JMP 24$ ;GO TO 24$ IF ERROR
228 011402 7$:
229
230 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
231 011402 012737 011412 001124 MOV #8$,$LPERR
232 011410 000410 BR 9$ ;SKIP TO WRITE OPERATION
233
234 ::*****
235 ;LOOP #2 WRITE,WRITE CHECK DATA
236
237 011412 8$:
238
239 ;PREPARE DEVICE FOR TEST
240 011412 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
011416 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 9$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 24$ IF ERROR
011420 000404 BR 9$
011422 000240 NOP
011424 104000 EMT
011426 000137 012062 JMP 24$
241 011432 9$:
242
243 ;SETUP PARAMETERS AND EXECUTE COMMAND
244 011432 10$:
245 011432 012737 104260 001416 MOV #BUFONE+4,RMBA0 ;CHANGE MEMORY ADDRESS
246 011440 012737 177400 001414 MOV #-256.,RMWCO ;CHANGE WORD COUNT
247 011446 012737 000061 001412 MOV #WD!GO,RMCS10 ;WRITE DATA COMMAND
248 011454 012702 001555 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
249 011460 112722 000006 MOVB #RMDA,(R2)+
250 011464 112722 000034 MOVB #RMDC,(R2)+
251 011470 112722 000032 MOVB #RMOF,(R2)+
252 011474 112722 000004 MOVB #RMBA,(R2)+
253 011500 112722 000002 MOVB #RMWC,(R2)+
254 011504 112722 000000 MOVB #RMCS1,(R2)+
255 011510 112722 000200 MOVB #200,(R2)+ ;TERMINATE TABLE
256
257 011514 004737 040360 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
011520 000404 BR 11$ ;GO TO 11$ IF NO ERROR
011522 000240 NOP ;RETURN HERE IF ERROR
011524 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
011526 000137 012062 JMP 24$ ;GO TO 24$ IF ERROR
258 011532 11$:
259
260 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
011532 004737 040024 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
261
262 ;WAIT FOR COMMAND TO COMPLETE
011536 004737 040732 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
263
264 ;GO GET REGISTER STATUS
    
```

```

265 011542 004737 040110      JSR    PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      011546 000404          BR     12$            ;GO TO 12$ IF NO ERROR
      011550 000240          NOP                    ;RETURN HERE IF ERROR
      011552 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      011554 000137 012062    JMP     24$            ;GO TO 24$ IF ERROR
266 011560                    12$:
267
268
269 011560 004737 041126      JSR    PC,PRIERR       ;GO CHECK FOR PRIMARY ERRORS
      011564 000405          BR     13$            ;GO TO 13$ IF NO ERROR
      011566 000240          NOP                    ;RETURN HERE IF ERROR
      011570 104000          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      011572 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      011574 000137 012062    JMP     24$            ;GO TO 24$ IF ERROR
270 011600                    13$:
271 011600 004737 054166      JSR    PC,DTASTS       ;GO VERIFY RESULTS OF DATA TRANSFER
      011604 000405          BR     14$            ;GO TO 14$ IF NO ERROR
      011606 000240          NOP                    ;RETURN HERE IF ERROR
      011610 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      011612 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      011614 000137 012062    JMP     24$            ;GO TO 24$ IF ERROR
272 011620                    14$:
273 011620 004737 041760      JSR    PC,SECERR       ;GO CHECK FOR SECONDARY ERRORS
      011624 000405          BR     15$            ;GO TO 15$ IF NO ERROR
      011626 000240          NOP                    ;RETURN HERE IF ERROR
      011630 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      011632 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      011634 000137 012062    JMP     24$            ;GO TO 24$ IF ERROR
274 011640                    15$:
275
276
277 011640 012737 011650 001124 ;CHANGE LOOP ADDRESSES
      011646 000410          MOV    #16$,$LPERR
      BR     17$
                                ;SKIP TO NEXT OPERATION
279
280
281
282
283 011650                    ;*****
                                ;LOOP #3      WRITE CHECK DATA
284
285
286 011650 004737 034032      JSR    PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      011654 154130          .WORD 154130
                                ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAI'ABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 17$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 24$ IF ERROR
      011656 000404          BR     17$
      011660 000240          NOP
      011662 104000          EMT
      011664 000137 012062    JMP     24$
287 011670                    17$:
288
289
290 011670                    ;SETUP PARAMETERS AND EXECUTE COMMAND
                                18$:
    
```



```

291 011670 012737 000051 001412      MOV      #WCD!GO,RMCS10      ;WRITE CHECK DATA DATA COMMAND
292 011676 012702 001555              MOV      #PUTINX,R2         ;LOAD PUT REGISTER INDEX TABLE
293 011702 112722 000006      MOVB    #PMDA,(R2)+
294 011706 112722 000032      MOVB    #RMDF,(R2)+
295 011712 112722 000034      MOVB    #RMDC,(R2)+
296 011716 112722 000004      MOVB    #RMBB,(R2)+
297 011722 112722 000002      MOVB    #RMWC,(R2)+
298 011726 112722 000000      MOVB    #RMCS1,(R2)+
299 011732 112712 000200      MOVB    #2CO,(R2)
300
301 011736 004737 040360      JSR     PC,PUT              ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      011742 000404              BR      19$                ;GO TO 19$ IF NO ERROR
      011744 000240              NOP
      011746 104000              EMT
      011750 000137 012062      JMP     24$                ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 24$ IF FRRUR
302 011754              19$:
303
304              ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      011754 004737 040024      JSR     PC,GETSTS          ;GO TO GETSTS SUBROUTINE
305
306              ;WAIT FOR COMMAND TO COMPLETE
      011760 004737 040732      JSR     PC,TIMOUT          ;GO TO TIMOUT SUBROUTINE
307
308              ;GO GET REGISTER STATUS
309 011764 004737 040110      JSR     PC,GET              ;GO READ REGISTER(S) WITH GET SUBROUTINE
      011770 000404              BR      20$                ;GO TO 20$ IF NO ERROR
      011772 000240              NOP
      011774 104000              EMT
      011776 000137 012062      JMP     24$                ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 24$ IF ERROR
310 012002              20$:
311
312              ;VERIFY RESULTS OF WRITE CHECK COMMAND
313 012002 004737 041126      JSR     PC,PRIERR          ;GO CHECK FOR PRIMARY ERRORS
      012006 000405              BR      21$                ;GO TO 21$ IF NO ERROR
      012010 000240              NOP
      012012 104000              EMT
      012014 004736              JSR     PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      012016 000137 012062      JMP     24$                ;GO TO 24$ IF ERROR
314 012022              21$:
315 012022 004737 054166      JSR     PC,DTASTS          ;GO VERIFY RESULTS OF DATA TRANSFER
      012026 000405              BR      22$                ;GO TO 22$ IF NO ERROR
      012030 000240              NOP
      012032 104000              EMT
      012034 004736              JSR     PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      012036 000137 012062      JMP     24$                ;GO TO 24$ IF ERROR
316 012042              22$:
317 012042 004737 041760      JSR     PC,SECERR          ;GO CHECK FOR SECONDARY ERRORS
      012046 000405              BR      23$                ;GO TO 23$ IF NO ERROR
      012050 000240              NOP
      012052 104000              EMT
      012054 004736              JSR     PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      012056 000137 012062      JMP     24$                ;GO TO 24$ IF ERROR
318 012062              23$:
319
320 012062              24$:
321
322              ;:*****
    
```

```

: *TEST 4      WRITE, WRITE CHECK ZEROS W/ WCE ERROR
: *****
TST4:
012062          000004          : SCOPE          : SCOPE CALL
012062          000240          : NOP            : START OF TEST
012064          000240          : MOV #STACK,SP : INITIALIZE STACK POINTER
012066          012706          001100          : MOV $BASE,R0  : RC = UNIBUS ADDRESS
012072          013700          001276          : MOV TSTQUE,R1 : (R1) = DEVICE BEING TESTED
012076          013701          001466          : MOV           : SET TEST NUMBER IN APT MAIL BOX
012102          012737          000004          C01226          : MOV #4,$TESTN

323
324
325
326
327 012110
328
329
330 012110          004737          034032          : PREPARE DEVICE FOR TEST
012114          154130          : JSR PC,TSTPRP : TASK DESCRIPTOR AS FOLLOWS:
: .WORD 154130   : SELECT DEVICE & VERIFY DEVICE AVAILABLE
:              : CLEAR CONTROLLER & SELECT DEVICE
:              : VERIFY CONTROLLER CLEAR OPERATION
:              : PACK ACKNOWLEDGE IF VOLUME NOT VALID
:              : VERIFY PACK ACKNOWLEDGE
:              : RECALIBRATE IF 'SKI' OR 'PIP' IS SET
:              : VERIFY RECALIBRATION
:              : GO TO 2$ IF NO ERROR
:              : RETURN HERE IF ERROR
:              : ERROR # DEFINED BY TSTPRP SUBROUTINE
:              : GO TO 28$ IF ERROR

012116          000404          BR 2$
012120          000240          NOP
012122          104000          EMT
012124          000137          013256          JMP 28$

331
332
333 012130          : LOAD PARAMETERS AND GENERATE DATA BUFFER
334 012130          012737          001057          001446          2$: MOV #559.,RMDCO : CYLINDER = 559.
335 012136          012737          001000          001420          MOV #TA2,RMDAO  : TRACK = 2, SECTOR = 0
336 012144          012737          104254          001416          MOV #BUFONE,RMBAO : BUS ADDRESS
337 012152          012737          177376          001414          MOV #-258.,RMWCO : 2 + 256. WORDS (2'S COMP)
338 012160          012737          010000          001444          MOV #FMT16,RMFOF : 16 BIT FORMAT
339 012166          012737          000063          001412          MOV #WH!GO,RMCSI0 : WRITE HEADER AND DATA COMMAND

340
341 012174          004737          034762          : VERIFY THAT SECTOR IS NOT BAD
012200          000405          JSR PC,BADSCT  : CALL BAD SECTOR MODULE
012202          104401          066006          BR 3$          : GO TO 3$ IF NO ERROR
012206          104000          TYPE           : TYPE BAD SECTOR MESSAGE
012210          000137          013256          EMT           : ERROR # DEFINED BY BADSCT SUBROUTINE
342 012214          : JMP 28$      : GO TO 28$ IF ERROR

343 012214          012737          067456          001174          3$: MOV #ZEROS,$TMP0 : STARTING ADDRESS OF PATTERN
344 012222          012737          000001          001176          MOV #1,$TMP1   : RANGE OF PATTERN
345 012230          004737          037214          JSR PC,GENBUF  : GO GENERATE BUFFER FOR FORMAT

346
347 012234          012702          001555          MOV #PUTINX,R2 : R2 = BYTE ENTRY POSITION
348 012240          112722          000034          MOVB #RMDC,(R2)+
349 012244          112722          000006          MOVB #RMDA,(R2)+
350 012250          112722          000004          MOVB #RMBA,(R2)+
351 012254          112722          000002          MOVB #RMWC,(R2)+
352 012260          112722          000032          MOVB #RMOF,(R2)+
353 012264          112722          000000          MOVB #RMCS1,(R2)+
    
```

```

354 012270 112712 000200          MOVB   #200,(R2)          :TERMINATE TABLE
355 012274                                     4$:
356 012274 004737 040360          JSR    PC,PUT           :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    012300 000404                                     BR     5$              :GO TO 5$ IF NO ERROR
    012302 000240                                     NOP                                :RETURN HERE IF ERROR
    012304 104000                                     EMT                                :ERROR # DEFINED BY PUT SUBROUTINE
    012306 000137 013256          JMP    28$             :GO TO 28$ IF ERROR
357 012312                                     5$:
358
359                                     :SETUP GET INDEX TABLE TO READ ALL REGISTERS
    012312 004737 040024          JSR    PC,GETSTS       :GO TO GETSTS SUBROUTINE
360
361                                     :WAIT FOR COMMAND TO COMPLETE
    012316 004737 040732          JSR    PC,TIMOUT      :GO TO TIMEOUT SUBROUTINE
362
363                                     :GO EGT REGISTER STATUS
364 012322 004737 040110          JSR    PC,GET         :GO READ REGISTER(S) WITH GET SUBROUTINE
    012326 000404                                     BR     6$              :GO TO 6$ IF NO ERROR
    012330 000240                                     NOP                                :RETURN HERE IF ERROR
    012332 104000                                     EMT                                :ERROR # DEFINED BY GET SUBROUTINE
    012334 000137 013256          JMP    28$             :GO TO 28$ IF ERROR
365 012340                                     6$:
366
367                                     :VERIFY RESULTS OF WRITE COMMAND
368 012340 004737 054166          JSR    PC,DTASTS      :GO VERIFY RESULTS OF DATA TRANSFER
    012344 000405                                     BR     7$              :GO TO 7$ IF NO ERROR
    012346 000240                                     NOP                                :RETURN HERE IF ERROR
    012350 104000                                     EMT                                :ERROR # DEFINED BY DTASTS SUBROUTINE
    012352 004736                                     JSR    PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
    012354 000137 013256          JMP    28$             :GO TO 28$ IF ERROR
369 012360                                     7$:
370
371                                     :MOVE LOOP ADDRESSES TO NEXT OPERATION
372 012360 012737 012370 001124    MOV    #8$,$LPERR
373 012366 000410                                     BR     9$              :SKIP TO WRITE OPERATION
374
375                                     ::*****
376                                     :LOOP #2          WRITE,WRITE CHECK DATA
377
378 012370                                     8$:
379
380                                     :PREPARE DEVICE FOR TEST
381 012370 004737 034032          JSR    PC,TSTPRP     :PREPARE DEVICE FOR TEST
    012374 154130          .WORD 154130         :TASK DESCRIPTOR AS FOLLOWS:
                                                                :SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                                                :CLEAR CONTROLLER & SELECT DEVICE
                                                                :VERIFY CONTROLLER CLEAR OPERATION
                                                                :PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                                                :VERIFY PACK ACKNOWLEDGE
                                                                :RECALIBRATE IF "SKI" OR "PIP" IS SET
                                                                :VERIFY RECALIBRATION
    012376 000404                                     BR     9$              :GO TO 9$ IF NO ERROR
    012400 000240                                     NOP                                :RETURN HERE IF ERROR
    012402 104000                                     EMT                                :ERROR # DEFINED BY TSTPRP SUBROUTINE
    012404 000137 013256          JMP    28$             :GO TO 28$ IF ERROR
382 012410                                     9$:
383
    
```

```

384          ;SETUP PARAMETERS AND EXECUTE COMMAND
385 012410 10$:
386 012410 012737 177400 001414 MOV # -256, RMWCO ;CHANGE WORD COUNT
387 012416 012737 104260 001416 MOV #BUFONE+4, RMBAD ;CHANGE MEMORY ADDRESS
388 012424 012737 000061 001412 MOV #WD!GO, RMCS10 ;WRITE DATA COMMAND
389 012432 012702 001555 MOV #PUTINX, R2 ;LOAD PUT REGISTER INDEX TABLE
390 012436 112722 000006 MOVB #RMDA, (R2)+
391 012442 112722 000034 MOVB #RMDC, (R2)+
392 012446 112722 000032 MOVB #RMOF, (R2)+
393 012452 112722 000004 MOVB #RMBB, (R2)+
394 012456 112722 000002 MOVB #RMWC, (R2)+
395 012462 112722 000000 MOVB #RMCS1, (R2)+
396 012466 112722 000200 MOVB #200, (R2)+ ;TERMINATE TABLE
397
398 012472 004737 040360 JSR PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    012476 000404 BR 11$ ;GO TO 11$ IF NO ERROR
    012500 000240 NOP ;RETURN HERE IF ERROR
    012502 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
    012504 000137 013256 JMP 28$ ;GO TO 28$ IF ERROR
399 012510 11$:
400
401 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
    JSR PC, GETSTS ;GO TO GETSTS SUBROUTINE
402
403 ;WAIT FOR COMMAND TO COMPLETE
    JSR PC, TIMEOUT ;GO TO TIMEOUT SUBROUTINE
404
405 ;GO READ STATUS FOR WRITE COMMAND
406 012520 004737 040110 JSR PC, GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
    012524 000404 BR 12$ ;GO TO 12$ IF NO ERROR
    012526 000240 NOP ;RETURN HERE IF ERROR
    012530 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
    012532 000137 013256 JMP 28$ ;GO TO 28$ IF ERROR
407 012536 12$:
408
409 ;CHECK FOR ERRORS DURING WRITE OPERATION
410 012536 004737 041126 JSR PC, PRIERR ;GO CHECK FOR PRIMARY ERRORS
    012542 000405 BR 13$ ;GO TO 13$ IF NO ERROR
    012544 000240 NOP ;RETURN HERE IF ERROR
    012546 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
    012550 004736 JSR PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
    012552 000137 013256 JMP 28$ ;GO TO 28$ IF ERROR
411 012556 13$:
412 012556 004737 054166 JSR PC, DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
    012562 000405 BR 14$ ;GO TO 14$ IF NO ERROR
    012564 000240 NOP ;RETURN HERE IF ERROR
    012566 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
    012570 004736 JSR PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
    012572 000137 013256 JMP 28$ ;GO TO 28$ IF ERROR
413 012576 14$:
414 012576 004737 041760 JSR PC, SECERR ;GO CHECK FOR SECONDARY ERRORS
    012602 000405 BR 15$ ;GO TO 15$ IF NO ERROR
    012604 000240 NOP ;RETURN HERE IF ERROR
    012606 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
    012610 004736 JSR PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
    012612 000137 013256 JMP 28$ ;GO TO 28$ IF ERROR
415 012616 15$:
    
```

```

416
417
418 012616 012737 012630 001124 ;CHANGE LOOP ADDRESSES
419 MOV #16$, $LPERR
420 ;*****
421 ;LOOP #3 WRITE CHECK DATA
422
423 012624 012703 000001 16$: MOV #1, R3 ;R3+WCE BIT POSITION
424 012630 BIS R3, BUFTWO-2 ;CHANGE LAST WORD OF BUFFER
425 012630 050337 105256
426
427 ;PREPARE DEVICE FOR TEST
428 012634 004737 034032 JSR PC, TSTPRP ;PREPARE DEVICE FOR TEST
012640 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER ( SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SK!' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 17$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 28$ IF ERROR

012642 000404 BR 17$
012644 000240 NOP
012646 104000 EMT
012650 000137 013256 JMP 28$
429 012654 17$:
430
431 ;READ DATA FROM DEVICE
432 18$:
433 012654 012737 000051 001412 MOV #WCD!GO, RMCS10 ;WRITE CHECK DATA DATA COMMAND
434 012662 012702 001555 MOV #PUTINX, R2 ;LOAD PUT REGISTER INDEX TABLE
435 012666 112722 000006 MOVB #RMDA, (R2)+
436 012672 112722 000032 MOVB #RMOF, (R2)+
437 012676 112722 000034 MOVB #RMDC, (R2)+
438 012702 112722 000004 MOVB #RMEA, (R2)+
439 012706 112722 000002 MOVB #RMWC, (R2)+
440 012712 112722 000000 MOVB #RMCS1, (R2)+
441 012716 112712 000200 MOVB #200, (R2)
442
443 012722 004737 040360 JSR PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
012726 000404 BR 19$ ;GO TO 19$ IF NO ERROR
012730 000240 NOP ;RETURN HERE IF ERROR
012732 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
012734 000137 013256 JMP 28$ ;GO TO 28$ IF ERROR
444 012740 19$:
445
446 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
012740 004737 040024 JSR PC, GETSTS ;GO TO GETSTS SUBROUTINE
447
448 ;WAIT FOR COMMAND TO COMPLETE
012744 004737 040732 JSR PC, TIMEOUT ;GO TO TIMEOUT SUBROUTINE
449
450 ;GO READ STATUS FOR WRITE CHECK DATA OPERATION
451 012750 004737 040110 JSR PC, GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
012754 000404 BR 20$ ;GO TO 20$ IF NO ERROR
012756 000240 NOP ;RETURN HERE IF ERROR
012760 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE

```

```

012762 000137 013256          JMP      28$          ;GO TO 28$ IF ERROR
452 012766          20$:
453
454          ;CHECK FOR ERRORS DURING WRITE CHECK DATA OPERAT;ON
455 012766 004737 041126          JSR      PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
                                BR          21$          ;GO TO 21$ IF NO ERROR
                                NOP          ;RETURN HERE IF ERROR
                                EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
                                JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
                                JMP      28$          ;GO TO 28$ IF ERROR
456 013006          21$:
457 013006 032737 040000 001346          BIT      #WCE,RMCS2I    ;WAS 'WCE' DETECTED??
458 013014 001030          BNE          23$          ;YES!!
459
460 013016 004737 054166          JSR      PC,DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
                                BR          22$          ;GO TO 22$ IF NO ERROR
                                NOP          ;RETURN HERE IF ERROR
                                EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
                                JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
                                JMP      28$          ;GO TO 28$ IF ERROR
461 013036          22$:
462 013036 013737 001346 001140          MOV      RMCS2I,$GDDAT    ;EXPECTED STATUS
463 013044 052737 040000 001140          BIS      #WCE,$GDDAT
464 013052 013737 001346 001142          MOV      RMCS2I,$BDDAT    ;RECEIVED STATUS
465 013060 010337 001174          MOV      R3,$STMP0        ;FAILING BIT POSITION
466 013064 012737 105256 001176          MOV      #BUFTWO-2,$STMP1 ;FAILING ADDRESS
467 013072 104337          EMT      337
468 013074 000470          BR          28$
469 013076          23$:
470 013076 112737 000022 001526          MOVB    #RMDB,GETINX    ;SETUP GET INDEX TABLE
                                MOVB    #200,GETINX+1 ;SETUP TERMINATOR BYTE
                                JSR      PC,GET        ;GO READ RMDB VIA GET SUBROUTINE
                                BR          24$          ;GO TO 24$ IF NO ERROR
                                NOP          ;RETURN HERE IF ERROR
                                EMT          ;ERROR DEFINED BY GET SUBROUTINE
                                JMP      28$          ;GO TO 28$ IF ERROR
471 013130          24$:
472 013130 013737 001360 001142          MOV      RMDBI,$BDDAT    ;RECEIVED DATA
473 013136 013737 105256 001140          MOV      BUFTWO-2,$GDDAT ;EXPECTED DATA
474 013144 040337 001140          BIC      R3,$GDDAT
475 013150 012737 105256 001134          MOV      #BUFTWO-2,$GDADR ;EXPECTED ADDRESS
476 013156 013737 001342 001136          MOV      RMBAI,$BDADR    ;RECEIVED ADDRESS
477 013164 162737 000002 001136          SUB      #2,$BDADR        ;ADJUST BUS ADDRESS
478 013172 023737 001134 001136          CMP      $GDADR,$BDADR    ;ADDRESSES OK??
479 013200 001402          BEQ      25$          ;YES!!
480 013202 104340          EMT      340
481 013204 000424          BR          28$
482 013206 023737 001140 001142 25$:          CMP      $GDDAT,$BDDAT    ;DATA OK??
483 013214 001402          BEQ      26$          ;YES!!
484 013216 104341          EMT      341
485 013220 000416          BR          28$
486 013222          26$:
487
488 013222 004737 041760          JSR      PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
                                BR          27$          ;GO TO 27$ IF NO ERROR
                                NOP          ;RETURN HERE IF ERROR
                                EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE
    
```

```

013234 004736 JSR PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
013236 000137 013256 JMP 28$ ;GO TO 28$ IF ERROR
489 013242 27$: BIC R3,BUFTWO-2 ;RESTORE DATA PATTERN
490 013242 040337 105256 ASL R3 ;SHIFT TO NEXT BIT
491 013246 006303 BEQ 28$ ;EXIT IF DONE
492 013250 001402 JMP 16$ ;REPEAT TEST FOR NEXT DATA BIT
493 013252 000137 012630
494 013256 28$:
495
496
*****
*TEST 5 WRITE, READ ONES
*****
TST5:
013256 000004 SCOPE ;SCOPE CALL
013260 000240 NOP ;START OF TEST
013262 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
013266 013700 001276 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
013272 013701 001466 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
013276 012737 000005 001226 MOV #5,$STESTN ;;SET TEST NUMBER IN APT MAIL BOX
497
498
499 ;LOOP #1 FORMAT,WRITE,READ
500
501 013304 1$:
502
503 ;PREPARE THE DEVICE FOR TEST
504 013304 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
013310 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 2$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 25$ IF ERROR
013312 000404 BR 2$
013314 000240 NOP
013316 104000 EMT
013320 000137 014264 JMP 25$
505
506 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
507 013324 2$:
508 013324 012737 001057 001446 MOV #559.,RMDCO ;CYLINDER = 559.
509 013332 012737 001000 001420 MOV #TA2,RMDAO ;TRACK = 2, SECTOR = 0
510 013340 012737 104254 001416 MOV #BUFO1E,RMBAO ;BUS ADDRESS
511 013346 012737 177376 001414 MOV #-258.,RMWCO ;2 + 256. WORDS (2'S COMP)
512 013354 012737 010000 001444 MOV #FMT16,RMFOFO ;16 BIT FORMAT
513 013362 012737 000063 001412 MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND
514
515 ;VERIFY THAT SECTOR IS NOT BAD
013370 004737 034762 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
013374 000405 BR 3$ ;GO TO 3$ IF NO ERROR
013376 104401 066006 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
013402 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
013404 000137 014264 JMP 25$ ;GO TO 25$ IF ERROR
516 013410 3$:
517 013410 012737 067414 001174 MOV #ONES,$TMP0 ;STARTING ADDRESS OF PATTERN

```

```

T5
518 013416 012737 000001 001176      MOV    #1,$STMP1      ;RANGE OF PATTERN
519 013424 004737 037214              JSR    PC,GENBUF     ;GO GENERATE BUFFER FOR FORMAT
520
521      ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
522 013430 012702 001555      MOV    #PUTINX,R2    ;R2 = BYTE ENTRY POSITION
523 013434 112722 000034      MOVB  #RMDC,(R2)+
524 013440 112722 000006      MOVB  #RMDA,(R2)+
525 013444 112722 000004      MOVB  #RMB A,(R2)+
526 013450 112722 000002      MOVB  #RMC,(R2)+
527 013454 112722 000032      MOVB  #RMOF,(R2)+
528 013460 112722 000000      MOVB  #RMC$1,(R2)+
529 013464 112712 000200      MOVB  #200,(R2)     ;TERMINATE TABLE
530 013470
531
532      ;FORMAT THE DRIVE
533 013470 004737 040360      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      013474 000404      BR     5$           ;GO TO 5$ IF NO ERROR
      013476 000240      NOP                    ;RETURN HERE IF ERROR
      013500 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      013502 000137 014264      JMP    25$          ;GO TO 25$ IF ERROR
534 013506
535
536      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR    PC,GETSTS    ;GO TO GETSTS SUBROUTINE
537
538      ;WAIT FOR COMMAND TO COMPLETE
      JSR    PC,TIMOUT    ;GO TO TIMEOUT SUBROUTINE
539
540      ;GO READ STATUS FOR FORMAT OPERATION
541 013516 004737 040110      JSR    PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      013522 000404      BR     6$           ;GO TO 6$ IF NO ERROR
      013524 000240      NOP                    ;RETURN HERE IF ERROR
      013526 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      013530 000137 014264      JMP    25$          ;GO TO 25$ IF ERROR
542 013534
543
544      ;VERIFY NO ERRORS DURING FORMAT
545 013534 004737 054166      JSR    PC,DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
      013540 000405      BR     7$           ;GO TO 7$ IF NO ERROR
      013542 000240      NOP                    ;RETURN HERE IF ERROR
      013544 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      013546 004736      JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      013550 000137 014264      JMP    25$          ;GO TO 25$ IF ERROR
546 013554
547
548      ;MOVE LOOP ADDRESSES TO NEXT OPERATION
549 013554 012737 013564 001124      MOV    #8$,$SLPERR
550 013562 000410      BR     9$           ;SKIP TO WRITE OPERATION
551
552      ;*****
553      ;LOOP #2      WRITE,READ
554
555 013564
556
557
558      ;PREPARE DEVICE FOR TEST
559 013564 004737 034032      JSR    PC,TSTPRP    ;PREPARE DEVICE FOR TEST

```


013570	154130			.WORD	154130				:TASK DESCRIPTOR AS FOLLOWS:
									:SELECT DEVICE & VERIFY DEVICE AVAILABLE
									:CLEAR CONTROLLER & SELECT DEVICE
									:VERIFY CONTROLLER CLEAR OPERATION
									:PACK ACKNOWLEDGE IF VOLUME NOT VALID
									:VERIFY PACK ACKNOWLEDGE
									:RECALIBRATE IF 'SKI' OR 'PIP' IS SET
									:VERIFY RECALIBRATION
									:GO TO 9\$ IF NO ERROR
									:RETURN HERE IF ERROR
									:ERROR # DEFINED BY TSTPRP SUBROUTINE
									:GO TO 25\$ IF ERROR
560	013604			9\$:					
561									
562									
563	013604								
564	013604	012737	104260	001416					
565	013612	012737	177400	001414					
566	013620	012737	000061	001412					
567	013626	012702	001555						
568	013632	112722	000006						
569	013636	112722	000034						
570	013642	112722	000032						
571	013646	112722	000004						
572	013652	112722	000002						
573	013656	112722	000000						
574	013662	112722	000200						
575									
576	013666	004737	040360						
	013672	000404							
	013674	000240							
	013676	104000							
	013700	000137	014264						
577	013704								
578									
579									
	013704	004737	040024						
580									
581									
	013710	004737	040732						
582									
583									
584	013714	004737	040110						
	013720	000404							
	013722	000240							
	013724	104000							
	013726	000137	014264						
585	013732								
586									
587									
588	013732	004737	041126						
	013736	000405							
	013740	000240							
	013742	104000							
	013744	004736							
	013746	000137	014264						
589	013752								

```

:TASK DESCRIPTOR AS FOLLOWS:
:SELECT DEVICE & VERIFY DEVICE AVAILABLE
:CLEAR CONTROLLER & SELECT DEVICE
:VERIFY CONTROLLER CLEAR OPERATION
:PACK ACKNOWLEDGE IF VOLUME NOT VALID
:VERIFY PACK ACKNOWLEDGE
:RECALIBRATE IF 'SKI' OR 'PIP' IS SET
:VERIFY RECALIBRATION
:GO TO 9$ IF NO ERROR
:RETURN HERE IF ERROR
:ERROR # DEFINED BY TSTPRP SUBROUTINE
:GO TO 25$ IF ERROR

9$:
:WRITE DATA TO THE DRIVE
10$:
MOV #BUFONE+4,RMBA0 ;CHANGE MEMORY ADDRESS
MOV #-256,RMWC0 ;CHANGE WORD COUNT
MOV #WD!GO,RMCS10 ;WRITE DATA COMMAND
MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
MOVB #RMBA,(R2)+
MOVB #RMDC,(R2)+
MOVB #RMDF,(R2)+
MOVB #RMBA,(R2)+
MOVB #RMWC,(R2)+
MOVB #RMCS1,(R2)+
MOVB #200,(R2)+ ;TERMINATE TABLE

JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
BR 11$ ;GO TO 11$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
EMT ;ERROR # DEFINED BY PUT SUBROUTINE
JMP 25$ ;GO TO 25$ IF ERROR

11$:
;SETUP GET INDEX TABLE TO READ ALL REGISTERS
JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE

;WAIT FOR COMMAND TO COMPLETE
JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE

;GO READ STATUS FOR WRITE COMMAND
JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
BR 12$ ;GO TO 12$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
EMT ;ERROR # DEFINED BY GET SUBROUTINE
JMP 25$ ;GO TO 25$ IF ERROR

12$:
;CHECK FOR ERRORS DURING WRITE OPERATION
JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
BR 13$ ;GO TO 13$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
JMP 25$ ;GO TO 25$ IF ERROR

13$:

```

```

590 013752 004737 054166      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      013756 000405      BR     14$           ;GO TO 14$ IF NO ERROR
      013760 000240      NOP                    ;RETURN HERE IF ERROR
      013762 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      013764 004736      JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      013766 000137 014264      JMP    25$           ;GO TO 25$ IF ERROR
591 013772      14$:
592 013772 004737 041760      JSR    PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      013776 000405      BR     15$           ;GO TO 15$ IF NO ERROR
      014000 000240      NOP                    ;RETURN HERE IF ERROR
      014002 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      014004 004736      JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      014006 000137 014264      JMP    25$           ;GO TO 25$ IF ERROR
593 014012      15$:
594
595      ;CHANGE LOOP ADDRESSES
596 014012 012737 014022 001124      MOV    #16$, $LPERR
597 014020 000410      BR     17$           ;SKIP TO NEXT OPERATION
598
599      ;*****
600      ;LOOP #3      READ
601
602 014022      16$:
603
604      ;PREPARE DEVICE FOR TEST
605 014022 004737 034032      JSR    PC,TSTPRP    ;PREPARE DEVICE FOR TEST
      014026 154130      .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 17$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 25$ IF ERROR
      014030 000404      BR     17$
      014032 000240      NOP
      014034 104000      EMT
      014036 000137 014264      JMP    25$
606 014042      17$:
607
608      ;READ DATA FROM DEVICE
609      18$:
610 014042 012737 105264 001416      MOV    #BUFTWO+4,RMBA0 ;CHANGE MEMORY ADDRESS
611 014050 012737 000071 001412      MOV    #RD!GO,RMCS10  ;READ DATA COMMAND
612 014056 012702 001555      MOV    #PUTINX,R2     ;LOAD PUT REGISTER INDEX TABLE
613 014062 112722 000906      MOVB  #RMDA,(R2)+
614 014066 112722 000032      MOVB  #RMOF,(R2)+
615 014072 112722 000034      MOVB  #RMDC,(R2)+
616 014076 112722 000004      MOVB  #RMB A,(R2)+
617 014102 112722 000002      MOVB  #RMCW,(R2)+
618 014106 112722 000000      MOVB  #RMCS1,(R2)+
619 014112 112712 000200      MOVB  #200,(R2)
620
621 014116 004737 040360      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      014122 000404      BR     19$           ;GO TO 19$ IF NO ERROR
      014124 000240      NOP                    ;RETURN HERE IF ERROR
      014126 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
    
```

T5 WRITE, READ ONES

```

622 014130 000137 014264          JMP      25$          ;GO TO 25$ IF ERROR
623 014134          19$:
624          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
        JSR      PC,GETSTS      ;GO TO GETSTS SUBROUTINE
625          ;WAIT FOR COMMAND TO COMPLETE
        JSR      PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
626 014140 004737 040732
627          ;GO READ STATUS FOR READ OPERATION
628          JSR      PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
629 014144 004737 040110          BR      20$          ;GO TO 20$ IF NO ERROR
        014150 000404          NOP          ;RETURN HERE IF ERROR
        014152 000240          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
        014154 104000          JMP      25$          ;GO TO 25$ IF ERROR
        014156 000137 014264
630 014162          20$:
631          ;CHECK FOR ERRORS DURING READ OPERATION
632          JSR      PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
633 014162 004737 041126          BR      21$          ;GO TO 21$ IF NO ERROR
        014166 000405          NOP          ;RETURN HERE IF ERROR
        014170 000240          EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
        014172 104000          JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
        014174 004736          JMP      25$          ;GO TO 25$ IF ERROR
        014176 000137 014264
634 014202          21$:
635 014202 004737 054166          JSR      PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
        014206 000405          BR      22$          ;GO TO 22$ IF NO ERROR
        014210 000240          NOP          ;RETURN HERE IF ERROR
        014212 104000          EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
        014214 004736          JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
        014216 000137 014264          JMP      25$          ;GO TO 25$ IF ERROR
636 014222          22$:
637 014222 004737 041760          JSR      PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
        014226 000405          BR      23$          ;GO TO 23$ IF NO ERROR
        014230 000240          NOP          ;RETURN HERE IF ERROR
        014232 104000          EMT          ;ERROR # DEFINED BY SECEPR SUBROUTINE
        014234 004736          JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
        014236 000137 014264          JMP      25$          ;GO TO 25$ IF ERROR
638 014242          23$:
639 014242 004737 037462          JSR      PC,CMPBUF      ;GO COMPARE WRITE, READ DATA BUFFERS
        014246 104260          .WORD      BUFOFF+4      ;STARTING ADDRESS OF WRITE BUFFER
        014250 105264          .WORD      BUFTWO+4     ;STARTING ADDRESS OF READ BUFFER
        014252 000404          BR      24$          ;GO TO 24$ IF NO ERROR
        014254 000240          NOP          ;RETURN HERE IF ERROR
        014256 104000          EMT          ;ERROR # DEFINED BY CMPBUF SUBROUTINE
        014260 000137 014264          JMP      25$          ;GO TO 25$ IF ERROR
640 014264          24$:
641          25$:
642 014264
643
644

```

```

:*****
:*TEST 6      WRITE, WRITE CHECK ONES
:*****
TST6:

```

```

014264          SCOPE          ;SCOPE CALL
014264 000004          NJP          ;START OF TEST
014266 000240          MOV      #STACK,SP      ;INITIALIZE STACK POINTER
014270 012706 001100

```

```

014274 013700 001276      MOV      $BASE,R0      ;R0 = UNIBUS ADDRESS
014300 013701 001466      MOV      TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
014304 012737 000006 001226  MOV      #6,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX

645
646      ;*****
647      ;LOOP #1      FORMAT,WRITE,WRITE CHECK DATA
648
649 014312      1$:
650
651      ;PREPARE THE DEVICE FOR TEST
652 014312 004737 034032      JSR      PC,TSTPRP    ;PREPARE DEVICE FOR TEST
014316 154130      .WORD   154130      ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 2$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 24$ IF ERROR

014320 000404      BR      2$
014322 000240      NOP
014324 104000      EMT
014326 000137 015242      JMP      24$

653
654      ;LOAD PARAMETERS AND GENERATE DATA BUFFER
655 014332      2$:
656 014332 012737 001057 001446      MOV      #559.,RMDCO    ;CYLINDER = 559.
657 014340 012737 001000 001420      MOV      #TA2,RMDAO    ;TRACK = 2, SECTOR = 0
658 014346 012737 104254 001416      MOV      #BUFONE,RMBAO ;BUS ADDRESS
659 014354 012737 177376 001414      MOV      #-256.,RMWCO  ;2 + 256. WORDS (2'S COMP)
660 014362 012737 010000 001444      MOV      #FMT16,RMFO   ;16 BIT FORMAT
661 014370 012737 000063 001412      MOV      #WH!GO,RMCS10 ;WRITE HEADER AND DATA COMMAND
662
663      ;VERIFY THAT SECTOR IS NOT BAD
014376 004737 034762      JSR      PC,BADSCT    ;CALL BAD SECTOR MODULE
014402 000405      BR      3$           ;GO TO 3$ IF NO ERROR
014404 104401 066006      TYPE    .SCTMSG     ;TYPE BAD SECTOR MESSAGE
014410 104000      EMT
014412 000137 015242      JMP      24$         ;ERROR # DEFINED BY BADSCT SUBROUTINE
                                ;GO TO 24$ IF ERROR

664 014416      3$:
665 014416 012737 067414 001174      MOV      #ONES,$TMP0   ;STARTING ADDRESS OF PATTERN
666 014424 012737 000001 001176      MOV      #1,$TMP1     ;RANGE OF PATTERN
667 014432 004737 037214      JSR      PC,GENBUF    ;GO GENERATE BUFFER FOR FORMAT
668
669      ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
670 014436 012702 001555      MOV      #PUTINX,R2   ;R2 = BYTE ENTRY POSITION
671 014442 112722 000034      MOVB    #RMDC,(R2)+
672 014446 112722 000006      MOVB    #RMDA,(R2)+
673 014452 112722 000004      MOVB    #RMBA,(R2)+
674 014456 112722 000002      MOVB    #RMWC,(R2)+
675 014462 112722 000032      MOVB    #RMOF,(R2)+
676 014466 112722 000000      MOVB    #RMCS1,(R2)+
677 014472 112712 000200      MOVB    #200,(R2)    ;TERMINATE TABLE
678 014476
679
680      ;FORMAT THE DRIVE
681 014476 004737 040360      JSR      PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    
```

T6

WRITE, WRITE CHECK ONES

```

014502 000404          BR      5$          ;GO TO 5$ IF NO ERROR
014504 000240          NOP          ;RETURN HERE IF ERROR
014506 104000          EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
014510 000137 015242   JMP      24$          ;GO TO 24$ IF ERROR
682 014514          5$:
683
684          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
014514 004737 040024   JSR      PC,GETSTS    ;GO TO GETSTS SUBROUTINE
685
686          ;WAIT FOR COMMAND TO COMPLETE
014520 004737 040732   JSR      PC,TIMOUT    ;GO TO TIMOUT SUBROUTINE
687
688          ;GO READ STATUS FOR FORMAT OPERATION
689 014524 004737 040110   JSR      PL,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
014530 000404          BR      6$          ;GO TO 6$ IF NO ERROR
014532 000240          NOP          ;RETURN HERE IF ERROR
014534 104000          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
014536 000137 015242   JMP      24$          ;GO TO 24$ IF ERROR
690 014542          6$:
691
692          ;VERIFY NO ERRORS DURING FORMAT
693 014542 004737 054166   JSR      PC,DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
014546 000405          BR      7$          ;GO TO 7$ IF NO ERROR
014550 000240          NOP          ;RETURN HERE IF ERROR
014552 104000          EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
014554 004736          JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
014556 000137 015242   JMP      24$          ;GO TO 24$ IF ERROR
694 014562          7$:
695
696          ;MOVE LOOP ADDRESSES TO NEXT OPERATION
697 014562 012737 014572 001124   MOV      #8$, $LPERR
698 014570 000410          BR          ;SKIP TO WRITE OPERATION
699
700          ;*****
701          ;LOOP #2          WRITE,WRITE CHECK DATA
702
703 014572          8$:
704
705          ;PREPARE DEVICE FOR WRITE OPERATION
706
707 014572 004737 034032   JSR      PC,TSTPRP    ;PREPARE DEVICE FOR TEST
014576 154130          .WORD    154130    ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF "SKI" OR "PIP" IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 9$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 24$ IF ERROR
014600 000404          BR      9$
014602 000240          NOP
014604 104000          EMT
014606 000137 015242   JMP      24$
708 014612          9$:
709
710          ;WRITE DATA TO THE DRIVE
711 014612          10$:

```

```

712 014612 012737 104260 001416      MOV      #SUFONE+4,RMBA0      ;CHANGE MEMORY ADDRESS
713 014620 012737 177400 001414      MOV      #-256.,RMWCO      ;CHANGE WORD COUNT
714 014626 012737 000061 001412      MOV      #WD!GO,RMCS10     ;WRITE DATA COMMAND
715 014634 012702 001555          MOV      #PUTJNX,R2        ;LOAD PUT REGISTER INDEX TABLE
716 014640 112722 000006      MOVSB   #RMDA,(R2)+
717 014644 112722 000034      MOVSB   #RMDC,(R2)+
718 014650 112722 000032      MOVSB   #RMOF,(R2)+
719 014654 112722 000004      MOVSB   #RMBA,(R2)+
720 014660 112722 000002      MOVSB   #RMWC,(R2)+
721 014664 112722 000000      MOVSB   #RMCS1,(R2)+
722 014670 112722 000200      MOVSB   #200,(R2)+        ;TERMINATE TABLE
723
724 014674 004737 040360          JSR      PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      014700 000404          BR       11$              ;GO TO 11$ IF NO ERROR
      014702 000240          NOP
      014704 104000          EMT
      014706 000137 015242          JMP      24$              ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 24$ IF ERROR
725 014712          11$:
726
727          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      014712 004737 040024          JSR      PC,GETSTS        ;GO TO GETSTS SUBROUTINE
728
729          ;WAIT FOR COMMAND TO COMPLETE
      014716 004737 040732          JSR      PC,TIMOUT        ;GO TO TIMEOUT SUBROUTINE
730
731          ;GO READ STATUS FOR WRITE COMMAND
732 014722 004737 040110          JSR      PC,GET            ;GO READ REGISTER(S) WITH GET SUBROUTINE
      014726 000404          BR       12$              ;GO TO 12$ IF NO ERROR
      014730 000240          NOP
      014732 104000          EMT
      014734 000137 015242          JMP      24$              ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 24$ IF ERROR
733 014740          12$:
734
735          ;CHECK FOR ERRORS DURING WRITE OPERATION
736 014740 004737 041126          JSR      PC,PRIERR        ;GO CHECK FOR PRIMARY ERRORS
      014744 000405          BR       13$              ;GO TO 13$ IF NO ERROR
      014746 000240          NOP
      014750 104000          EMT
      014752 004736          JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      014754 000137 015242          JMP      24$              ;GO TO 24$ IF ERROR
737 014760          13$:
738 014760 004737 054166          JSR      PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
      014764 000405          BR       14$              ;GO TO 14$ IF NO ERROR
      014766 000240          NOP
      014770 104000          EMT
      014772 004736          JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      014774 000137 015242          JMP      24$              ;GO TO 24$ IF ERROR
739 015000          14$:
740 015000 004737 041760          JSR      PC,SECERR        ;GO CHECK FOR SECONDARY ERRORS
      015004 000405          BR       15$              ;GO TO 15$ IF NO ERROR
      015006 000240          NOP
      015010 104000          EMT
      015012 004736          JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      015014 000137 015242          JMP      24$              ;GO TO 24$ IF ERROR
741 015020          15$:
742
743          ;CHANGE LOOP ADDRESSES
    
```

```

744 015020 012737 015030 001124      MOV    #16$,SLPERR
745 015026 000410                      BR     17$                :SKIP TO NEXT OPERATION
746
747                                     :*****
748                                     :LOOP #3      WRITE CHECK DATA
749
750 015030      16$:
751
752                                     ;PREPARE DEVICE FOR WRITE CHECK DATA OPERATION
753 015030 004737 034032      JSR    PC,TSTPRP      ;PREPARE DEVICE FOR TEST
015034 154130      .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
                                     ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                     ;CLEAR CONTROLLER & SELECT DEVICE
                                     ;VERIFY CONTROLLER CLEAR OPERATION
                                     ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                     ;VERIFY PACK ACKNOWLEDGE
                                     ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                     ;VERIFY RECALIBRATION
015036 000404      BR     17$                ;GO TO 17$ IF NO ERROR
015040 000240      NOP
015042 104000      EMT
015044 000137 015242      JMP    24$                ;RETURN HERE IF ERROR
                                     ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                     ;GO TO 24$ IF ERRCR
754 015050      17$:
755
756                                     ;WRITE CHECK DATA DATA FROM DEVICE
757 015050      18$:
758 015050 012737 000051 001412      MOV    #WCD!GO,RMCS10      ;WRITE CHECK DATA DATA COMMAND
759 015056 012702 001555                      MOV    #PUTINX,R2          ;LOAD PUT REGISTER INDEX TABLE
760 015062 112722 000006      MOVB   #RMDA,(R2)+
761 015066 112722 000032      MOVB   #RMOF,(R2)+
762 015072 112722 000034      MOVB   #RMDC,(R2)+
763 015076 112722 000004      MOVB   #RMBA,(R2)+
764 015102 112722 000002      MOVB   #RMWC,(R2)+
765 015106 112722 000000      MOVB   #RMCS1,(R2)+
766 015112 112712 000200      MOVB   #200,(R2)
767
768 015116 004737 040360      JSR    PC,PUT              ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
015122 000404      BR     19$                ;GO TO 19$ IF NO ERROR
015124 000240      NOP                        ;RETURN HERE IF ERROR
015126 104000      EMT                        ;ERROR # DEFINED BY PUT SUBROUTINE
015130 000137 015242      JMP    24$                ;GO TO 24$ IF ERRCR
769 015134      19$:
770
771                                     ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
015134 004737 040024      JSR    PC,GETSTS          ;GO TO GETSTS SUBROUTINE
772
773                                     ;WAIT FOR COMMAND TO COMPLETE
015140 004737 040732      JSR    PC,TIMOUT          ;GO TO TIMEOUT SUBROUTINE
774
775                                     ;GO READ STATUS FOR WRITE CHECK DATA OPERATION
776 015144 004737 040110      JSR    PC,GET              ;GO READ REGISTER(S) WITH GET SUBROUTINE
015150 000404      BR     20$                ;GO TO 20$ IF NO ERROR
015152 000240      NOP                        ;RETURN HERE IF ERROR
015154 104000      EMT                        ;ERROR # DEFINED BY GET SUBROUTINE
015156 000137 015242      JMP    24$                ;GO TO 24$ IF ERROR
777 015162      20$:
778
    
```

```

779 ;CHECK FOR ERRORS DURING WRITE CHECK DATA OPERATION
780 015162 004737 041126 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
015166 000405 BR 21$ ;GO TO 21$ IF NO ERROR
015170 000240 NOP ;RETURN HERE IF ERROR
015172 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
015174 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
015176 000137 015242 JMP 24$ ;GO TO 24$ IF ERROR

781 015202 21$:
782 015202 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
015206 000405 BR 22$ ;GO TO 22$ IF NO ERROR
015210 000240 NOP ;RETURN HERE IF ERROR
015212 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
015214 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
015216 000137 015242 JMP 24$ ;GO TO 24$ IF ERROR

783 015222 22$:
784 015222 004737 041760 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
015226 000405 BR 23$ ;GO TO 23$ IF NO ERROR
015230 000240 NOP ;RETURN HERE IF ERROR
015232 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
015234 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
015236 000137 015242 JMP 24$ ;GO TO 24$ IF ERROR

785 015242 23$:
786
787 015242 24$:
788
789

;*****
;*TEST 7 WRITE, WRITE CHECK ONES W/ WCE ERROR
;*****
TST7:
015242
015242 000004 SCOPE ;SCOPE CALL
015244 000240 NOP ;START OF TEST
015246 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
015252 013700 001276 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
015256 013701 001466 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
015262 012737 000007 001226 MOV #7,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX

790
791 ;*****
792 ;LOOP #1 FORMAT,WRITE.WRITE CHECK DATA
793
794 015270 1$:
795
796 ;PREPARE THE DEVICE FOR FORMAT OPERATION
797 015270 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
015274 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
015276 000404 BR 2$ ;GO TO 2$ IF NO ERROR
015300 000240 NOP ;RETURN HERE IF ERROR
015302 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
015304 000137 016440 JMP 28$ ;GO TO 28$ IF ERROR

798 015310 2$:
799

```



```

800 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
801 015310 012737 001057 001446 MOV #559.,RMDCO ;CYLINDER = 559.
802 015316 012737 001000 001420 MOV #TA2,RMDAO ;TRACK = 2, SECTOR = 0
803 015324 012737 104254 001416 MOV #BUFONE,RMBAC ;BUS ADDRESS
804 015332 012737 177376 001414 MOV #-258.,RMWCO ;WORD COUNT = 1 SECTOR
805 015340 012737 010000 001444 MOV #FMT16,RMFOFO ;16 BIT FORMAT
806 015346 012737 000063 001412 MOV #WH!GO,RMCS1J ;WRITE HEADER AND DATA COMMAND
807
808 ;VERIFY THAT SECTOR IS NOT BAD
      015354 004737 034762 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
      015360 000405 BR 3$ ;GO TO 3$ IF NO ERROR
      015362 104401 066006 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
      015366 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
      015370 000137 016440 JMP 28$ ;GO TO 28$ IF ERROR
809 015374 3$:
810 015374 012737 067414 001174 MOV #ONES,$TMP0 ;STARTING ADDRESS OF PATTERN
811 015402 012737 000001 001176 MOV #1,$TMP1 ;RANGE OF PATTERN
812 015410 004737 037214 JSR PC,GENBUF ;GO GENERATE BUFFER FOR FORMAT
813
814 ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
      015414 012702 001555 MOV #PUTINX,R2 ;R2 = BYTE ENTRY POSITION
816 015420 112722 000034 MOVB #RMDC,(R2)+
817 015424 112722 000006 MOVB #RMDA,(R2)+
818 015430 112722 000004 MOVB #RMBE,(R2)+
819 015434 112722 000002 MOVB #RPMC,(R2)+
820 015440 112722 000032 MOVB #RMOF,(R2)+
821 015444 112722 000000 MOVB #RMCS1,(R2)+
822 015450 112712 000200 MOVB #200,(R2) ;TERMINATE TABLE
823 015454 4$:
824
825 ;FORMAT THE DRIVE
826 015454 004737 040360 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      015460 000404 BR 5$ ;GO TO 5$ IF NO ERROR
      015462 000240 NOP ;RETURN HERE IF ERROR
      015464 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
      015466 000137 016440 JMP 28$ ;GO TO 28$ IF ERROR
827 015472 5$:
828
829 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      015472 004737 040024 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
830
831 ;WAIT FOR COMMAND TO COMPLETE
      015476 004737 040732 JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
832
833 ;GO READ STATUS FOR FORMAT OPERATION
834 015502 004737 040110 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
      015506 000404 BR 6$ ;GO TO 6$ IF NO ERROR
      015510 000240 NOP ;RETURN HERE IF ERROR
      015512 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
      015514 000137 016440 JMP 28$ ;GO TO 28$ IF ERROR
835 015520 6$:
836
837 ;VERIFY NO ERRORS DURING FORMAT
838 015520 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
      015524 000405 BR 7$ ;GO TO 7$ IF NO ERROR
      015526 000240 NOP ;RETURN HERE IF ERROR
      015530 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
  
```

```

015532 004736 JSR PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
015534 000137 016440 JMP 28$ ;GO TO 28$ IF ERROR
839 015540 7$:
840
841 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
842 015540 012737 015550 001124 MOV #8$, $LPERR
843 015546 000410 BR 9$ ;SKIP TO WRITE OPERATION
844
845 ;*****
846 ;LOOP #2 WRITE,WRITE CHECK DATA
847
848 015550 8$:
849
850
851 ;PREPARE DEVICE FOR WRITE OPERATION
852 015550 004737 034032 JSR PC, TSTPRP ;PREPARE DEVICE FOR TEST
015554 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 9$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 28$ IF ERROR
015556 000404 BR 9$
015560 000240 NOP
015562 104000 EMT
015564 000137 016440 JMP 28$
853 015570 9$:
854
855 ;WRITE DATA TO THE DRIVE
856 015570 10$:
857 015570 012737 177400 001414 MOV #-256., RMWCO ;CHANGE WORD COUNT
858 015576 012737 104260 001416 MOV #BUFONE+4, RMBAD ;CHANGE MEMORY ADDRESS
859 015604 012737 000061 001412 MOV #WD!GO, RMCS10 ;WRITE DATA COMMAND
860 015612 012702 001555 MOV #PUTINX, R2 ;LOAD PUT REGISTER INDEX TABLE
861 015616 112722 000006 MOVB #RMDA, (R2)+
862 015622 112722 000034 MOVB #RMDC, (R2)+
863 015626 112722 000032 MOVB #RMPF, (R2)+
864 015632 112722 000004 MOVB #RMPA, (R2)+
865 015636 112722 000002 MOVB #RMLC, (R2)+
866 015642 112722 000000 MOVB #RMCS1, (R2)+
867 015646 112722 000200 MOVB #200, (R2)+ ;TERMINATE TABLE
868
869 015652 004737 040360 JSR PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
015656 000404 BR 11$ ;GO TO 11$ IF NO ERROR
015660 000240 NOP ;RETURN HERE IF ERROR
015662 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
015664 000137 016440 JMP 28$ ;GO TO 28$ IF ERROR
870 015670 11$:
871
872 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
015670 004737 040024 JSR PC, GETSTS ;GO TO GETSTS SUBROUTINE
873
874 ;WAIT FOR COMMAND TO COMPLETE
015674 004737 040732 JSR PC, TIMEOUT ;GO TO TIMEOUT SUBROUTINE
875

```

```

876                                     ;GO READ STATUS FOR WRITE COMMAND
877 015700 004737 040110                JSR   PC,GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
                                BR     12$          ;GO TO 12$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
                                JMP     28$          ;GO TO 28$ IF ERROR
878 015716                                12$:
879
880                                     ;CHECK FOR ERRORS DURING WRITE OPERATION
881 015716 004737 041126                JSR   PC,PRIERR        ;GO CHECK FOR PRIMARY ERRORS
                                BR     13$          ;GO TO 13$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
                                JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
                                JMP     28$          ;GO TO 28$ IF ERROR
882 015736                                13$:
883 015736 004737 054166                JSR   PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
                                BR     14$          ;GO TO 14$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
                                JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
                                JMP     28$          ;GO TO 28$ IF ERROR
884 015756                                14$:
885 015756 004737 041760                JSR   PC,SECERR        ;GO CHECK FOR SECONDARY ERRORS
                                BR     15$          ;GO TO 15$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
                                JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
                                JMP     28$          ;GO TO 28$ IF ERROR
886 015776                                15$:
887
888                                     ;CHANGE LOOP ADDRESSES
889 015776 012737 016010 001124        MOV   #16$,SLPERR
890
891                                     ;*****
892                                     ;LOOP #3          WRITE CHECK DATA
893
894 016004 012703 000001                MOV   #1,R3           ;R3+WCE BIT POSITION
895 016010                                16$:
896 016010 040337 105256                BIC   R3,BUFTWO-2     ;CHANGE LAST WORD OF BUFFER
897
898                                     ;PREPARE DEVICE FOR WRITE CHECK DATA OPERATION
899 016014 004737 034032                JSR   PC,TSTPRP        ;PREPARE DEVICE FOR TEST
                                .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
                                                    ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                                    ;CLEAR CONTROLLER & SELECT DEVICE
                                                    ;VERIFY CONTROLLER CLEAR OPERATION
                                                    ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                                    ;VERIFY PACK ACKNOWLEDGE
                                                    ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                                    ;VERIFY RECALIBRATION
                                BR     17$          ;GO TO 17$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                JMP     28$          ;GO TO 28$ IF ERROR

                                016022 000404
                                016024 000240
                                016026 104000
                                016030 000137 016440
900 016034                                17$:
901
    
```

```

902                                     :READ DATA FROM DEVICE
903 016034                               18$:
904 016034 012737 000051 001412      MOV    #WCD!GO,RMCS10      :WRITE CHECK DATA DATA COMMAND
905 016042 012702 001555                MOV    #PUTINX,R2        :LOAD PUT REGISTER INDEX TABLE
906 016046 112722 000006                MOVB   #RMDA,(R2)+
907 016052 112722 000032                MOVB   #RMOF,(R2)+
908 016056 112722 000034                MOVB   #RMDC,(R2)+
909 016062 112722 000004                MOVB   #RMDA,(R2)+
910 016066 112722 000002                MOVB   #RMC,(R2)+
911 016072 112722 000000                MOVB   #RMCS1,(R2)+
912 016076 112712 000200                MOVB   #200,(R2)
913
914 016102 004737 040360                JSR    PC,PUT           :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    016106 000404                        BR     19$             :GO TO 19$ IF NO ERROR
    016110 C00240                        NOP
    016112 104000                        EMT
    016114 000137 016440                JMP    28$             :ERROR # DEFINED BY PUT SUBROUTINE
    :GO TO 28$ IF ERROR
915 016120                               19$:
916
917                                     :SETUP GET INDEX TABLE TO READ ALL REGISTERS
    016120 004737 040024                JSR    PC,GETSTS       :GO TO GETSTS SUBROUTINE
918
919                                     :WAIT FOR COMMAND TO COMPLETE
    016124 004737 040732                JSR    PC,TIMOUT       :GO TO TIMOUT SUBROUTINE
920
921                                     :GO READ STATUS FOR WRITE CHECK DATA OPERATION
922 016130 004737 040110                JSR    PC,GET           :GO READ REGISTER(S) WITH GET SUBROUTINE
    016134 000404                        BR     20$             :GO TO 20$ IF NO ERROR
    016136 000240                        NOP
    016140 104000                        EMT
    016142 000137 016440                JMP    28$             :ERROR # DEFINED BY GET SUBROUTINE
    :GO TO 28$ IF ERROR
923 016146                               20$:
924
925                                     :CHECK FOR ERRORS DURING WRITE CHECK DATA OPERATION
926 016146 004737 041126                JSR    PC,PRIERR       :GO CHECK FOR PRIMARY ERRORS
    016152 000405                        BR     21$             :GO TO 21$ IF NO ERROR
    016154 000240                        NOP
    016156 104000                        EMT
    016160 004736                        JSR    PC,@(SP)+       :GO BACK FOR MORE ERROR CHECKS
    016162 000137 016440                JMP    28$             :GO TO 28$ IF ERROR
927 016166                               21$:
928 016166 032737 040000 001346        BIT    #WCE,RMCS2I     :WAS 'WCE' DETECTED??
929 016174 001030                        BNE    23$             :YES!!
930 016176 004737 054166                JSR    PC,DTASTS       :GO VERIFY RESULTS OF DATA TRANSFER
    016202 000405                        BR     22$             :GO TO 22$ IF NO ERROR
    016204 000240                        NOP
    016206 104000                        EMT
    016210 004736                        JSR    PC,@(SP)+       :GO BACK FOR MORE ERROR CHECKS
    016212 000137 016440                JMP    28$             :GO TO 28$ IF ERROR
931 016216                               22$:
932 016216 013737 001346 001140        MOV    RMCS2I,$GDDAT   :EXPECTED STATUS
933 016224 052737 040000 001140        BIS    #WCE,$GDDAT
934 016232 013737 001346 001142        MOV    RMCS2I,$BDDAT   :RECEIVED STATUS
935 016240 010337 001174                MOV    R3,$IMP0        :FAILING BIT POSITION
936 016244 012737 105256 001176        MOV    #BUF TWO-2,$TMP1 :FAILING ADDRESS
937 016252 104337                        EMT
938 016254 000471                        BR     28$
  
```

```

939
940 U16256          23$:
941 C16256 112737 000022 U01526      MOVB  #RMDB,GETINX      ;SETUP GET INDEX TABLE
    016264 112737 000200 001527      MOVB  #200,GETINX+1    ;SETUP TERMINATOR BYTE
    016272 012737 016440 001360      MOV   #28$,RMDBI      ;SET RMDB INPUT BUFFER = 28$
    016300 004737 040110              JSR   PC,GET          ;GO READ RMDB VIA GET SUBROUTINE
    016304 000402                    BR    24$            ;GO TO 24$ IF NO ERROR
    016306 000240                    NOP                      ;RETURN HERE IF ERROR
    016310 104000                    EMT                     ;ERROR DEFINED BY GET SUBROUTINE

942
943 016312          24$:
944 016312 013737 001360 001142      MOV   RMDBI,$BDDAT     ;RECEIVED DATA
945 016320 013737 105256 001140      MOV   BUFTWO-2,$GDDAT ;EXPECTED DATA
946 016326 050337 001140              BIS   R3,$GDDAT
947 016332 012737 105256 001134      MOV   #BUFTWO-2,$GDADR ;EXPECTED ADDRESS
948 016340 013737 001342 001136      MOV   RMBAI,$BDADR    ;RECEIVED ADDRESS
949 016346 162737 000002 001136      SUB   #2,$BDADR       ;CORRECT MEMORY ADDRESS
950 016354 023737 001134 001136      CMP   $GDADR,$BDADR   ;ADDRESSES OK??
951 016362 001402                    BEQ   25$            ;YES!!
952 016364 104340                    EMT                     340
953 016366 000424                    BR    28$
954 016370 023737 001140 001142 25$:  CMP   $GDDAT,$BDDAT   ;DATA OK??
955 016376 001402                    BEQ   26$            ;YES!!
956 016400 104341                    EMT                     341
957 016402 000416                    BR    28$
958 016404          26$:
959
960 016404 004737 041760              JSR   PC,SECERR       ;GO CHECK FOR SECONDARY ERRORS
    016410 000405                    BR    27$            ;GO TO 27$ IF NO ERROR
    016412 000240                    NOP                      ;RETURN HERE IF ERROR
    016414 104000                    EMT                     ;ERROR # DEFINED BY SECERR SUBROUTINE
    016416 004736                    JSR   PC,@(SP)+       ;GO BACK FOR MORE ERROR CHECKS
    016420 000137 016440              JMP   28$            ;GO TO 28$ IF ERROR

961 016424          27$:
962 016424 050337 105256              BIS   R3,BUFTWO-2     ;RESTORE DATA PATTERN
963 016430 006303                    ASL   R3              ;SHIFT TO NEXT BIT
964 016432 001402                    BEQ   28$            ;EXIT IF DONE
965 016434 000137 016010              JMP   16$            ;REPEAT TEST FOR NEXT DATA BIT
966 016440          28$:
967
968
    ;*****
    ;*TEST 10      WRITE, WRITE CHECK MULTIPLE SECTORS
    ;*****
    TST10:
    016440          SCOPE                ;SCOPE CALL
    016440 000004                    NOP                      ;START OF TEST
    016442 000240                    MOV   #STACK,SP       ;INITIALIZE STACK POINTER
    016444 012706 001100              MOV   $BASE,R0        ;R0 = UNIBUS ADDRESS
    016450 013700 001276              MOV   TSTQUE,R1      ;(R1) = DEVICE BEING TESTED
    016454 013701 001466              MOV   #10,$TESTN     ;:SET TEST NUMBER IN APT MAIL BOX
    016460 012737 000010 001226

969
970
971          ;*****
972          ;LOOP #1      FORMAT,WRITE,WRITE CHECK
973
974 016466          1$:
975 016466 012737 010000 001444      MOV   #FMT16,RMOFO    ;16 BIT FORMAT
  
```

```

976                                     ;LOAD PARAMETERS AND GENERATE DATA BUFFER
977 016474                               2$:
978 016474 012737 001057 001446          MOV #559,RMDCO          ;CYLINDER = 559.
979 016502 012737 001000 001420          MOV #TA2,RMDAO        ;TRACK = 2, SECTOR = 0
980 016510 012737 104254 001416          MOV #BUFONE,RMBAO     ;BUS ADDRESS
981 016516 012737 176774 001414          MOV #-258,*2,RMWCO    ;WORD COUNT FOR 2 SECTORS (2'S COMP)
982 016524 012737 000063 001412          MOV #WH!GO,RMCS10     ;WRITE HEADER AND DATA COMMAND
983
984                                     ;PREPARE THE DEVICE FOR FORMAT OPERATION
985 016532 004737 034032                  JSR PC,TSTPRP          ;PREPARE DEVICE FOR TEST
    016536 154130                          .WORD 154130           ;TASK DESCRIPTOR AS FOLLOWS:
                                                    ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                                    ;CLEAR CONTROLLER & SELECT DEVICE
                                                    ;VERIFY CONTROLLER CLEAR OPERATION
                                                    ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                                    ;VERIFY PACK ACKNOWLEDGE
                                                    ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                                    ;VERIFY RECALIBRATION
    016540 000404                          BR 3$                  ;GO TO 3$ IF NO ERROR
    016542 000240                          NOP                     ;RETURN HERE IF ERROR
    016544 104000                          EMT                     ;ERROR # DEFINED BY TSTPRP SUBROUTINE
    016546 000137 017466                  JMP 25$                ;GO TO 25$ IF ERROR
986 016552                               3$:
987
988                                     ;VERIFY THAT SECTOR IS NOT BAD
    016552 004737 034762                  JSR PC,BADSCT          ;CALL BAD SECTOR MODULE
    016556 000405                          BR 4$                  ;GO TO 4$ IF NO ERROR
    016560 104401 066006                  TYPE .SCTMSG           ;TYPE BAD SECTOR MESSAGE
    016564 104000                          EMT                     ;ERROR # DEFINED BY BADSCT SUBROUTINE
    016566 000137 017466                  JMP 25$                ;GO TO 25$ IF ERROR
989 016572                               4$:
990 016572 012737 067456 001174          MOV #ZEROS,$TMP0       ;STARTING ADDRESS OF PATTERN
991 016600 012737 000001 001176          MOV #1,$TMP1           ;RANGE OF PATTERN
992 016606 004737 037214                  JSR PC,GENBUF          ;GO GENERATE BUFFER FOR FORMAT
993
994                                     ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
995 016612 012702 001555                  MOV #PUTINX,R2         ;R2 = BYTE ENTRY POSITION
996 016616 112722 000034                  MOVB #RMDC,(R2)+
997 016622 112722 000006                  MOVB #RMDA,(R2)+
998 016626 112722 000004                  MOVB #RMB A,(R2)+
999 016632 112722 000002                  MOVB #RMMC,(R2)+
1000 016636 112722 000032                  MOVB #RMOF,(R2)+
1001 016642 112722 000000                  MOVB #RMCS1,(R2)+
1002 016646 112712 000200                  MOVB #200,(R2)        ;TERMINATE TABLE
1003 016652                               5$:
1004
1005                                     ;FORMAT THE DRIVE
1006 016652 004737 040360                  JSR PC,PUT             ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    016656 000404                          BR 6$                  ;GO TO 6$ IF NO ERROR
    016660 000240                          NOP                     ;RETURN HERE IF ERROR
    016662 104000                          EMT                     ;ERROR # DEFINED BY PUT SUBROUTINE
    016664 000137 017466                  JMP 25$                ;GO TO 25$ IF ERROR
1007 016670                               6$:
1008
1009                                     ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
1010 016670 004737 040024                  JSR PC,GETSTS          ;GO TO GETSTS SUBROUTINE
  
```

```

1011 ;WAIT FOR COMMAND TO COMPLETE
      JSR PC,TIMGUT ;GO TO TIMEOUT SUBROUTINE
1012
1013 ;GO READ STATUS FOR FORMAT OPERATION
1014 016700 004737 040110 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
      016704 000404 BR 7$ ;GO TO 7$ IF NO ERROR
      016706 000240 NOP ;RETURN HERE IF ERROR
      016710 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
      016712 000137 017466 JMP 25$ ;GO TO 25$ IF ERROR
1015 016716 7$:
1016
1017 ;VERIFY NO ERRORS DURING FORMAT
1018 016716 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
      016722 000405 BR 8$ ;GO TO 8$ IF NO ERROR
      016724 000240 NOP ;RETURN HERE IF ERROR
      016726 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
      016730 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      016732 000137 017466 JMP 25$ ;GO TO 25$ IF ERROR
1019 016736 8$:
1020
1021 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
1022 016736 012737 017010 001124 MOV #9$,$LPERR
1023
1024 ;REGENERATE DATA BUFFER
1025 016744 012737 177000 001414 MOV #-256.*2,RMWC0 ;CHANGE WORD COUNT
1026 016752 012737 104254 001416 MOV #BUFONE,RMBA0 ;CHANGE BUS ADDRESS
1027 016760 012737 000060 001412 MOV #WD,RMCS10 ;WRITE DATA
1028 016766 012737 067414 001174 MOV #ONES,$TMP0 ;STARTING ADDRESS OF PATTERN
1029 016774 012737 000001 001176 MOV #1,$TMP1 ;RANGE OF PATTERN
1030 017002 004737 037214 JSR PC,GENBUF
1031 017006 000410 BR 10$ ;SKIP TO WRITE OPERATION
1032
1033 ;*****
1034 ;LOOP #2 WRITE,WRITE CHECK
1035
1036 017010 9$:
1037
1038
1039 ;PREPARE DEVICE FOR WRITE OPERATION
1040 017010 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
      017014 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF "SKI" OR "PIP" IS SET
      ;VERIFY RECALIBRATION
      017016 000404 BR 10$ ;GO TO 10$ IF NO ERROR
      017020 000240 NOP ;RETURN HERE IF ERROR
      017022 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      017024 000137 017466 JMP 25$ ;GO TO 25$ IF ERROR
1041 017030 10$:
1042
1043 ;WRITE DATA TO THE DRIVE
1044 017030 11$:
1045 017030 012737 000061 001412 MOV #WD!GO,RMCS10 ;WRITE DATA COMMAND
  
```

```

1046 017036 012702 001555      MOV      #PUTINX,R2          ;LOAD PUT REGISTER INDEX TABLE
1047 017042 112722 000006      MOVB    #RMDA,(R2)+
1048 017046 112722 000034      MOVB    #RMDC,(R2)+
1049 017052 112722 000032      MOVB    #RMOF,(R2)+
1050 017056 112722 000004      MOVB    #RMA,(R2)+
1051 017062 112722 000002      MOVB    #RMWC,(R2)+
1052 017066 112722 000000      MOVB    #RMCS1,(R2)+
1053 017072 112722 000200      MOVB    #200,(R2)+          ;TERMINATE TABLE
1054
1055 017076 004737 040360      JSR     PC,PUT              ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      117102 000404      BR      12$                ;GO TO 12$ IF NO ERROR
      117104 000240      NOP
      117106 104000      EMT
      017110 000137 017466      JMP     25$                ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 25$ IF ERROR
1056 017114      12$:
1057
1058      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR     PC,GETSTS      ;GO TO GETSTS SUBROUTINE
1059 017114 004737 040024
1060      ;WAIT FOR COMMAND TO COMPLETE
      JSR     PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
1061 017120 004737 040732
1062      ;GO READ STATUS FOR WRITE COMMAND
1063 017124 004737 040110      JSR     PC,GET              ;GO READ REGISTER(S) WITH GET SUBROUTINE
      017130 000404      BR      13$                ;GO TO 13$ IF NO ERROR
      017132 000240      NOP
      017134 104000      EMT
      017136 000137 017466      JMP     25$                ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 25$ IF ERROR
1064 017142      13$:
1065
1066      ;CHECK FOR ERRORS DURING WRITE OPERATION
1067 017142 004737 041126      JSR     PC,PRIERR          ;GO CHECK FOR PRIMARY ERRORS
      017146 000405      BR      14$                ;GO TO 14$ IF NO ERROR
      017150 000240      NOP
      017152 104000      EMT
      017154 004736      JSR     PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      017156 000137 017466      JMP     25$                ;GO TO 25$ IF ERROR
1068 017162      14$:
1069 017162 004737 054166      JSR     PC,DTASTS          ;GO VERIFY RESULTS OF DATA TRANSFER
      017166 000405      BR      15$                ;GO TO 15$ IF NO ERROR
      017170 000240      NOP
      017172 104000      EMT
      017174 004736      JSR     PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      017176 000137 017466      JMP     25$                ;GO TO 25$ IF ERROR
1070 017202      15$:
1071 017202 004737 041760      JSR     PC,SECERR          ;GO CHECK FOR SECONDARY ERRORS
      017206 000405      BR      16$                ;GO TO 16$ IF NO ERROR
      017210 000240      NOP
      017212 104000      EMT
      017214 004736      JSR     PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      017216 000137 017466      JMP     25$                ;GO TO 25$ IF ERROR
1072 017222      16$:
1073
1074      ;CHANGE LOOP ADDRESSES
1075 017222 012737 017232 001124      MOV     #17$,SLPERR
1076 017230 000410      BR      18$
      ;SKIP TO NEXT OPERATION
1077

```



```

1078 ::*****
1079 ;LOOP #3 WRITE CHECK
1080
1081 017232 17$:
1082
1083 ;PREPARE DEVICE FOR READ OPERATION
1084 017232 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
    017236 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
    ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
    ;CLEAR CONTROLLER & SELECT DEVICE
    ;VERIFY CONTROLLER CLEAR OPERATION
    ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
    ;VERIFY PACK ACKNOWLEDGE
    ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
    ;VERIFY RECALIBRATION
    ;GO TO 18$ IF NO ERROR
    ;RETURN HERE IF ERROR
    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
    ;GO TO 25$ IF ERROR

    017240 000404 BR 18$
    017242 000240 NOP
    017244 104000 EMT
    017246 000137 017466 JMP 25$

1085 017252 18$:
1086
1087 ;READ DATA FROM DEVICE
1088 017252 19$:
1089 017252 012737 000051 001412 MOV #WCD!GO,RMCS10 ;READ DATA COMMAND
1090 017260 012702 001555 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
1091 017264 112722 000006 MOVB #RMDA,(R2)+
1092 017270 112722 000032 MOVB #RMPF,(R2)+
1093 017274 112722 000034 MOVB #RMDC,(R2)+
1094 017300 112722 000004 MOVB #RMB A,(R2)+
1095 017304 112722 000002 MOVB #RMWC,(R2)+
1096 017310 112722 000000 MOVB #RMCS1,(R2)+
1097 017314 112712 000200 MOVB #200,(R2)
1098
1099 017320 004737 040360 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    017324 000404 BR 20$ ;GO TO 20$ IF NO ERROR
    017326 000240 NOP ;RETURN HERE IF ERROR
    017330 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
    017332 000137 017466 JMP 25$ ;GO TO 25$ IF ERROR

1100 017336 20$:
1101
1102 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
    JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
1103
1104 ;WAIT FOR COMMAND TO COMPLETE
    JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
1105
1106 ;GO READ STATUS FOR WRITE CHECK OPERATION
1107 017346 004737 040110 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
    017352 000404 BR 21$ ;GO TO 21$ IF NO ERROR
    017354 000240 NOP ;RETURN HERE IF ERROR
    017356 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
    017360 000137 017466 JMP 25$ ;GO TO 25$ IF ERROR

1108 017364 21$:
1109
1110 ;CHECK FOR ERRORS DURING WRITE CHECK OPERATION
1111 017364 004737 041126 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
    017370 000405 BR 22$ ;GO TO 22$ IF NO ERROR
  
```

```
017372 000240 NOP ;RETURN HERE IF ERROR
017374 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
017376 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
017400 000137 017466 JMP 25$ ;GO TO 25$ IF ERROR
1112 017404 22$: JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
1113 017404 004737 054166 BR 23$ ;GO TO 23$ IF NO ERROR
017410 000405 NOP ;RETURN HERE IF ERROR
017412 000240 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
017414 104000 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
017416 004736 JMP 25$ ;GO TO 25$ IF ERROR
1114 017424 23$: JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
1115 017424 004737 041760 BR 24$ ;GO TO 24$ IF NO ERROR
017430 000405 NOP ;RETURN HERE IF ERROR
017432 000240 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
017434 104000 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
017436 004736 JMP 25$ ;GO TO 25$ IF ERROR
1116 017444 24$: BIT #SSEI,RMOFO ;TEST 16 BIT MODE W/ SSEI SET ?
1117 017444 032737 001000 001444 BNE 25$ ;YES !!
1118 017452 001005 BIS #SSEI,RMOFO ;SET SSEI IN OFFSET AND
1119 017454 052737 001000 001444 JMP 2$ ;TEST AGAIN
1120 017462 000137 016474
1121 017466
1122
1123
```

*TEST 11 WRITE, READ W/ IMPLIED SEEK

```
TST11:
017466 000004 SCOPE ;SCOPE CALL
017470 000240 NOP ;START OF TEST
017472 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
017476 013700 001276 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
017502 013701 001466 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
017506 012737 000011 001226 MOV #11,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
```

:LOOP #1 FORMAT,WRITE,READ

```
1124
1125
1126
1127
1128 017514 1$:
1129
1130 ;PREPARE THE DEVICE FOR FORMAT OPERATION
1131 017514 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
017520 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF "SKI" OR "PIP" IS SET
;VERIFY RECALIBRATION
017522 000404 BR 2$ ;GO TO 2$ IF NO ERROR
017524 000240 NOP ;RETURN HERE IF ERROR
017526 104000 EMT ;ERROR # DEFINED BY TSTPRP SUPROUTINE
017530 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR
```

1132 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
1133

```

1134 017534          2$:
1135 017534 012737 001057 001446      MOV      #559.,RMDCO      ;CYLINDER = 559.
1136 017542 013737 001446 020710      MOV      RMDCO,32$      ;SAVE DESIRED CYLINDER
1137 017550 012737 001000 001420      MOV      #TA2,RMDAO     ;TRACK = 2, SECTOR = 0
1138 017556 012737 104254 001416      MOV      #BUFONE,RMBAO  ;BUS ADDRESS
1139 017564 012737 177376 001414      MOV      #-258.,RMWCG   ;2 + 256. WORDS (2'S COMP)
1140 017572 012737 010000 001444      MOV      #FMT16,RMOFO   ;16 BIT FORMAT
1141 017600 012737 000063 001412      MOV      #WH!GO,RMCS10  ;WRITE HEADER AND DATA COMMAND
1142
1143          ;VERIFY THAT SECTOR IS NOT BAD
          JSR      PC,BADSCT      ;CALL BAD SECTOR MODULE
          BR      3$              ;GO TO 3$ IF NO ERROR
          TYPE     ,SCTMSG        ;TYPE BAD SECTOR MESSAGE
          EMT      ;ERROR # DEFINED BY BADSCT SUBROUTINE
          JMP      31$           ;GO TO 31$ IF ERROR
          017606 004737 034762
          017612 000405
          017614 104401 066006
          017620 104000
          017622 000137 020706
1144 017626          3$:
1145 017626 012737 067414 001174      MOV      #ONES,$TMP0    ;STARTING ADDRESS OF PATTERN
1146 017634 012737 000001 001176      MOV      #1,$TMP1       ;RANGE OF PATTERN
1147 017642 004737 037214          JSR      PC,GENBUF      ;GO GENERATE BUFFER FOR FORMAT
1148
1149          ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
          MOV      #PUTINX,R2    ;R2 = BYTE ENTRY POSITION
          MOVB     #RMDC,(R2)+
          MOVB     #RMDA,(R2)+
          MOVB     #RMBA,(R2)+
          MOVB     #RMWC,(R2)+
          MOVB     #RMOF,(R2)+
          MOVB     #RMCS1,(R2)+
          MOVB     #200,(R2)    ;TERMINATE TABLE
1150 017646 012702 001555
1151 017652 112722 000034
1152 017656 112722 000006
1153 017662 112722 000004
1154 017666 112722 000002
1155 017672 112722 000032
1156 017676 112722 000000
1157 017702 112712 000200
1158 017706
1159
1160          ;FORMAT THE DRIVE
1161 017706 004737 040360      JSR      PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
          BR      5$              ;GO TO 5$ IF NO ERROR
          NOP      ;RETURN HERE IF ERROR
          EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
          JMP      31$           ;GO TO 31$ IF ERROR
          017712 000404
          017714 000240
          017716 104000
          017720 000137 020706
1162 017724          5$:
1163
1164          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
          JSR      PC,GETSTS    ;GO TO GETSTS SUBROUTINE
1165 017724 004737 040024
1166          ;WAIT FOR COMMAND TO COMPLETE
          JSR      PC,TIMOUT    ;GO TO TIMEOUT SUBROUTINE
1167 017730 004737 040732
1168          ;GO READ STATUS FOR FORMAT OPERATION
1169 017734 004737 040110      JSR      PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
          BR      6$              ;GO TO 6$ IF NO ERROR
          NOP      ;RETURN HERE IF ERROR
          EMT      ;ERROR # DEFINED BY GET SUBROUTINE
          JMP      31$           ;GO TO 31$ IF ERROR
          017740 000404
          017742 000240
          017744 104000
          017746 000137 020706
1170 017752          6$:
1171
1172          ;VERIFY NO ERRORS DURING FORMAT
1173 017752 004737 054166      JSR      PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
          BR      7$              ;GO TO 7$ IF NO ERROR
          NOP      ;RETURN HERE IF ERROR
          017756 000405
          017760 000240

```

```

017762 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
017764 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
017766 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR
1174 017772 7$:
1175
1176 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
1177 017772 012737 020002 001124 MOV #8$, $LPERR
1178 020000 000410 BR 9$ ;SKIP TO WRITE OPERATION
1179
1180 ;*****
1181 ;LOOP #2 WRITE,READ
1182
1183 020002 8$:
1184
1185 ;PREPARE DEVICE FOR WRITE OPERATION
1186 020002 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
020006 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVILE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF "SKI" OR "PIP" IS SET
;VERIFY RECALIBRATION
;GO TO 9$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 31$ IF ERROR
020010 000404 BR 9$
020012 000240 NOP
020014 104000 EMT
020016 000137 020706 JMP 31$
1187 020022 9$:
1188 020022 012737 000000 001446 MOV #0,RMDCO ;SEEK TO FIRST CYLINDER
1189 020030 012737 000005 001412 MOV #SEEK!GO,RMCS10 ;WRITE SEEK COMMAND
1190
1191 020036 004737 040360 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
020042 000404 BR 10$ ;GO TO 10$ IF NO ERROR
020044 000240 NOP ;RETURN HERE IF ERROR
020046 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
020050 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR
1192 020054 10$:
1193
1194 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
1195 020054 004737 040024 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
1196
1197 ;WAIT FOR COMMAND TO COMPLETE
1198 020060 004737 040732 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
1199
1199 ;GO GET REGISTER STATUS
020054 004737 040110 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
020070 000404 BR 11$ ;GO TO 11$ IF NO ERROR
020072 000240 NOP ;RETURN HERE IF ERROR
020074 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
020076 000137 020706 JMP 31$ ;GO TO 31$ IF ERRGR
1200 020102 11$:
1201
1202 ;VERIFY RESULTS OF SEEK COMMAND
1203 020102 004737 046550 JSR PC,SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
020106 000405 DR 12$ ;GO TO 12$ IF NO ERROR
020110 000240 NOP ;RETURN HERE IF ERROR

```

```

111 WRITE, READ W/ IMPLIED SEEK
020112 104000 EMT ;ERROR # DEFINED BY SEKSTS SUBROUTINE
020114 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
020116 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR
1204 020122 12$:
1205
1206 ;SETUP PARAMETERS AND EXECUTE WRITE DATA COMMAND
1207 020122 13$:
1208 020122 013737 020710 001446 MOV 32$,RMDCO ;RESTOKE CYLINDER
1209 020130 012737 177400 001414 MOV #-256.,RMWCO ;CHANGE WORD COUNT
1210 020136 012737 104260 001416 MOV #BUFONE+4,RMBAO ;CHANGE BUS ADDRESS
1211 020144 012737 000061 001412 MOV #WD!GO,RMCS10 ;WRITE DATA COMMAND
1212 020152 012702 001555 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
1213 020156 112722 000006 MOVB #RMDA,(R2)+
1214 020162 112722 000034 MOVB #RMDC,(R2)+
1215 020166 112722 000032 MOVB #RMOF,(R2)+
1216 020172 112722 000004 MOVB #RMBA,(R2)+
1217 020176 112722 000002 MOVB #RMWC,(R2)+
1218 020202 112722 000000 MOVB #RMCS1,(R2)+
1219 020206 112722 000200 MOVB #200,(R2)+ ;TERMINATE TABLE
1220
1221 020212 004737 040360 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
020216 000404 BR 14$ ;GO TO 14$ IF NO ERROR
020220 000240 NOP ;RETURN HERE IF ERROR
020222 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
020224 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR
1222 020230 14$:
1223
1224 ;WAIT FOR COMMAND TO COMPLETE
020230 004737 040732 JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
1225
1226 ;GO READ STATUS FOR WRITE COMMAND
1227 020234 004737 040110 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
020240 000404 BR 15$ ;GO TO 15$ IF NO ERROR
020242 000240 NOP ;RETURN HERE IF ERROR
020244 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
020246 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR
1228 020252 15$:
1229
1230 ;CHECK FOR ERRORS DURING WRITE OPERATION
1231 020252 004737 041126 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
020256 000405 BR 16$ ;GO TO 16$ IF NO ERROR
020260 000240 NOP ;RETURN HERE IF ERROR
020262 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
020264 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
020266 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR
1232 020272 16$:
1233 020272 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
020276 000405 BR 17$ ;GO TO 17$ IF NO ERROR
020300 000240 NOP ;RETURN HERE IF ERROR
020302 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
020304 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
020306 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR
1234 020312 17$:
1235 020312 004737 041760 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
020316 000405 BR 18$ ;GO TO 18$ IF NO ERROR
020320 000240 NOP ;RETURN HERE IF ERROR
020322 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE

```

```

020324 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
020326 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR
1236 020332 18$:
1237
1238 ;CHANGE LOOP ADDRESSES
1239 020332 012737 020342 001124 MOV #19$,SLPERR
1240 020340 000410 BR 20$ ;SKIP TO NEXT OPERATION
1241
1242 ::*****
1243 :LOOP #3 READ
1244
1245 020342 19$:
1246
1247 ;PREPARE DEVICE FOR READ OPERATION
1248 020342 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
020346 154130 .WORD 15413C ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 20$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 31$ IF ERROR
020350 000404 BR 20$
020352 000240 NOP
020354 104000 EMT
020356 000137 020706 JMP 31$
1249 020362 20$:
1250 020362 012737 000000 001446 MOV #0,RMDCO ;SEEK TO FIRST CYLINDER
1251 020370 012737 000005 001412 MOV #SEEK!GO,RMCS10 ;WRITE SEEK COMMAND
1252
1253 020376 004737 040360 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
020402 000404 BR 21$ ;GO TO 21$ IF NO ERROR
020404 000240 NOP ;RETURN HERE IF ERROR
020406 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
020410 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR
1254 020414 21$:
1255
1256 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
020414 004737 040024 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
1257
1258 ;WAIT FOR COMMAND TO COMPLETE
020420 004737 040732 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
1259
1260 ;GO GET REGISTER STATUS
1261 020424 004737 040110 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
020430 000404 BR 22$ ;GO TO 22$ IF NO ERROR
020432 000240 NOP ;RETURN HERE IF ERROR
020434 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
020436 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR
1262 020442 22$:
1263
1264 ;VERIFY RESULTS OF SEEK COMMAND
1265 020442 004737 046550 JSR PC,SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
020446 000405 BR 23$ ;GO TO 23$ IF NO ERROR
020450 000240 NOP ;RETURN HERE IF ERROR
020452 104000 EMT ;ERROR # DEFINED BY SEKSTS SUBROUTINE

```

```

020454 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
020456 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR

1266
1267 020462 23$:
1268
1269 ;SETUP PARAMETERS AND EXECUTE READ DATA COMMAND
1270 020462 24$:
1271 020462 013737 020710 001446 MOV 32$,RMDCO ;RESTORE CYLINDER
1272 020470 012737 000071 001412 MOV #RD!GO,RMCS10 ;READ DATA COMMAND
1273 020476 012737 105264 001416 MOV #BUFTWO+4,RMBA0 ;LOAD STARTING BUFFER ADDRESS
1274 020504 012702 001555 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
1275 020510 112722 000006 MOVB #RMDA,(R2)+
1276 020514 112722 000032 MOVB #RMOF,(R2)+
1277 020520 112722 000034 MOVB #RMDC,(R2)+
1278 020524 112722 000004 MOVB #RMB A,(R2)+
1279 020530 112722 000002 MOVB #RMWC,(R2)+
1280 020534 112722 000000 MOVB #RMCS1,(R2)+
1281 020540 112712 000200 MOVB #200,(R2)

1283 020544 004737 040360 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
020550 000404 BR 25$ ;GO TO 25$ IF NO ERROR
020552 000240 NOP ;RETURN HERE IF ERROR
020554 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
020556 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR

1284 020562 25$:
1285
1286 ;WAIT FOR COMMAND TO COMPLETE
020562 004737 040732 JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE

1287
1288 ;GO READ STATUS FOR READ OPERATION
1289 020566 004737 040110 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
020572 000404 BR 26$ ;GO TO 26$ IF NO ERROR
020574 000240 NOP ;RETURN HERE IF ERROR
020576 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
020600 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR

1290 020604 26$:
1291
1292 ;CHECK FOR ERRORS DURING READ OPERATION
1293 020604 004737 041126 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
020610 000405 BR 27$ ;GO TO 27$ IF NO ERROR
020612 000240 NOP ;RETURN HERE IF ERROR
020614 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
020616 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
020620 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR

1294 020624 27$:
1295 020624 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
020630 000405 BR 28$ ;GO TO 28$ IF NO ERROR
020632 000240 NOP ;RETURN HERE IF ERROR
020634 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
020636 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
020640 000137 020706 JMP 31$ ;GO TO 31$ IF ERROR

1296 020644 28$:
1297 020644 004737 041760 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
020650 000405 BR 29$ ;GO TO 29$ IF NO ERROR
020652 000240 NOP ;RETURN HERE IF ERROR
020654 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
020656 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
  
```

```

111 WRITE, READ W/ IMPLIED SEEK
1298 020660 000137 020706          JMP      31$          ;GO TO 31$ IF ERROR
1299 020664 004737 037462          JSR      PC,CMPBUF   ;GO COMPARE WRITE, READ DATA BUFFERS
                                .WORD    BUFO1+4           ;STARTING ADDRESS OF WRITE BUFFER
                                .WORD    BUFTWO+4          ;STARTING ADDRESS OF READ BUFFER
020670 104260                      BR       30$          ;GO TO 30$ IF NO ERROR
020672 105264                      NOP                      ;RETURN HERE IF ERROR
020674 000404                      EMT                      ;ERROR # DEFINED BY CMPBUF SUBROUTINE
020676 000240                      JMP      31$          ;GO TO 31$ IF ERROR
1300 020702 000137 020706          JSR      PC,CMPBUF   ;GO COMPARE WRITE, READ DATA BUFFERS
                                .WORD    BUFO1+4           ;STARTING ADDRESS OF WRITE BUFFER
                                .WORD    BUFTWO+4          ;STARTING ADDRESS OF READ BUFFER
1301 020706 000401                      BR       33$
1302 020710 000000                      .WORD    0              ;STORAGE FOR DATA CYLINDER
1303 020712
1304
1305
1306
1307
1308
1309
*****
;*TEST 12      READ, WRITE CHECK W/ HEAD SWITCHING
*****
TST12:
020712 000004                      SCOPE                   ;SCOPE CALL
020714 000240                      NOP                      ;START OF TEST
020716 012706 001100                  MOV      #STACK,SP      ;INITIALIZE STACK POINTER
020722 013700 001276                  MOV      $BASE,R0       ;R0 = UNIBUS ADDRESS
020726 013701 001466                  MOV      TSTQUE,R1      ;(R1) = DEVICE BEING TESTED
020732 012737 000012 001226          MOV      #12,$TESTN     ;;SET TEST NUMBER IN APT MAIL BOX
*****
;LOOP #1      READ,WRITE CHECK
;LOAD PARAMETERS AND GENERATE DATA BUFFER
1$:
1315 020740 012737 001036 001420      MOV      #TA2!30.,RMDAO ;TRACK = 2, SECTOR = 30.
1316 020740 012737 010000 001444      MOV      #FMT16,RMFO    ;16 BIT FORMAT
1317 020746
1318 020754
2$:
1319 020754 012737 001057 001446      MOV      #559.,RMDCO    ;CYLINDER = 559.
1320 020762 012737 104254 001416      MOV      #BUFO1,RMBAO   ;BUS ADDRESS
1321 020770 012737 177000 001414      MOV      #-256.*2,RMWCO ;WORD COUNT FOR 2 SECTORS (2'S COMP)
1322 020776 012737 000070 001412      MOV      #RD,RMCS10     ;READ DATA COMMAND
1323 021004
3$:
;PREPARE THE DEVICE FOR FORMAT OPERATION
1333 021004 004737 034032          JSR      PC,TSTPRP     ;PREPARE DEVICE FOR TEST
                                .WORD    154130           ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
021012 000404                      BR       4$            ;GO TO 4$ IF NO ERROR
021014 000240                      NOP                      ;RETURN HERE IF ERROR
021016 104000                      EMT                      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
021020 000137 021734          JMP      26$           ;GO TO 26$ IF ERROR

```



```

1334 021024          4$:
1335
1336                ;SETUP PARAMETERS AND SEEK TO GET DRIVE ON CYLINDER
1337 021024 012737 000005 001412  MOV    #SEEK!GO, RMCS10      ;LOAD SEEK COMMAND
1338 021032 012702 001555          MOV    #PUTINX, R2          ;R2 = BYTE ENTRY POSITION
1339 021036 112722 000034          MOVB  #RMDC, (R2)+
1340 021042 112722 000006          MOVB  #RMDA, (R2)+
1341 021046 112722 000004          MCVB  #RMB, (R2)+
1342 021052 112722 000002          MOVB  #RMWC, (R2)+
1343 021056 112722 000032          MOVB  #RMOF, (R2)+
1344 021062 112722 000000          MOVB  #RMCS1, (R2)+
1345 021066 112712 000200          MOVB  #200, (R2)          ;TERMINATE TABLE
1346 021072          5$:
1347
1348 021072 004737 040360          JSR   PC, PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
1349 021076 000404          BR    6$                ;GO TO 6$ IF NO ERROR
1350 021100 000240          NOP
1351 021102 104000          EMT
1352 021104 000137 021734          JMP   26$              ;RETURN HERE IF ERROR
1353                                ;ERROR # DEFINED BY PUT SUBROUTINE
1354                                ;GO TO 26$ IF ERROR
1355          6$:
1356                ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
1357 021110 004737 040024          JSR   PC, GETSTS        ;GO TO GETSTS SUBROUTINE
1358
1359                ;WAIT FOR COMMAND TO COMPLETE
1360 021114 004737 040732          JSR   PC, TIMEOUT       ;GO TO TIMEOUT SUBROUTINE
1361
1362                ;GO READ REGISTER STATUS
1363 021120 004737 040110          JSR   PC, GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
1364 021124 000404          BR    7$                ;GO TO 7$ IF NO ERROR
1365 021126 000240          NOP                      ;RETURN HERE IF ERROR
1366 021130 104000          EMT                      ;ERROR # DEFINED BY GET SUBROUTINE
1367 021132 000137 021734          JMP   26$              ;GO TO 26$ IF ERROR
1368          7$:
1369
1370                ;GO VERIFY RESULTS OF SEEK
1371 021136 004737 046550          JSR   PC, SEKSTS        ;GO VERIFY RESULTS OF SEEK OPERATION
1372 021142 000405          BR    8$                ;GO TO 8$ IF NO ERROR
1373 021144 000240          NOP                      ;RETURN HERE IF ERROR
1374 021146 104000          EMT                      ;ERROR # DEFINED BY SEKSTS SUBROUTINE
1375 021150 004736          JSR   PC, @ (SP)+       ;GO BACK FOR MORE ERROR CHECKS
1376 021152 000137 021734          JMP   26$              ;GO TO 26$ IF ERROR
1377          8$:
1378
1379                ;READ DATA FROM THE DRIVE
1380 021156          9$:
1381 021156 012737 000071 001412  MOV    #RD!GO, RMCS10      ;READ DATA COMMAND
1382 021164 012702 001555          MOV    #PUTINX, R2        ;LOAD PUT REGISTER INDEX TABLE
1383 021170 112722 000006          MOVB  #RMDA, (R2)+
1384 021174 112722 000034          MOVB  #RMDC, (R2)+
1385 021200 112722 000032          MOVB  #RMOF, (R2)+
1386 021204 112722 000004          MOVB  #RMB, (R2)+
1387 021210 112722 000002          MOVB  #RMWC, (R2)+
1388 021214 112722 000000          MOVB  #RMCS1, (R2)+
1389 021220 112722 000200          MOVB  #200, (R2)+          ;TERMINATE TABLE
1390
1391 021224 004737 040360          JSR   PC, PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
  
```

```

021230 000404 BR 10$ :GO TO 10$ IF NO ERROR
021232 000240 NOP :RETURN HERE IF ERROR
021234 104000 EMT :ERROR # DEFINED BY PUT SUBROUTINE
021236 000137 021734 JMP 26$ :GO TO 26$ IF ERROR
1379 021242 10$:
1380
1381 :SETUP GET INDEX TABLE TO READ ALL REGISTERS
021242 004737 040024 JSR PC,GETSTS :GO TO GETSTS SUBROUTINE
1382
1383 :WAIT FOR COMMAND TO COMPLETE
021246 004737 040732 JSR PC,TIMOUT :GO TO TIMOUT SUBROUTINE
1384
1385 :GO READ STATUS FOR READ COMMAND
1386 021252 004737 040110 JSR PC,GET :GO READ REGISTER(S) WITH GET SUBROUTINE
021256 000404 BR 11$ :GO TO 11$ IF NO ERROR
021260 000240 NOP :RETURN HERE IF ERROR
021262 104000 EMT :ERROR # DEFINED BY GET SUBROUTINE
021264 000137 021734 JMP 26$ :GO TO 26$ IF ERROR
1387
1388 :CHECK TO SEE IF THIS SECTOR WAS SKIP SECTORED FIRST, IF SO
1389 :DO NOT EXECUTE THIS TEST IN 16 BIT FORMAT MODE
1390 021270 11$:
1391 021270 032737 000040 001400 BIT #SSE,RMER2I :IS 'SSE' BIT SET ?
1392 021276 001030 BNE 14$ :BR IF YES
1393
1394 :CHECK FOR ERRORS DURING READ OPERATION
1395 021300 004737 041126 JSR PC,PRIERR :GO CHECK FOR PRIMARY ERRORS
021304 000405 BR 12$ :GO TO 12$ IF NO ERROR
021306 000240 NOP :RETURN HERE IF ERROR
021310 104000 EMT :ERROR # DEFINED BY PRIERR SUBROUTINE
021312 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
021314 000137 021734 JMP 26$ :GO TO 26$ IF ERROR
1396 021320 12$:
1397 021320 004737 054166 JSR PC,DTASTS :GO VERIFY RESULTS OF DATA TRANSFER
021324 000405 BR 13$ :GO TO 13$ IF NO ERROR
021326 000240 NOP :RETURN HERE IF ERROR
021330 104000 EMT :ERROR # DEFINED BY DTASTS SUBROUTINE
021332 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
021334 000137 021734 JMP 26$ :GO TO 26$ IF ERROR
1398 021340 13$:
1399 021340 004737 041760 JSR PC,SECERR :GO CHECK FOR SECONDARY ERRORS
021344 000405 BR 14$ :GO TO 14$ IF NO ERROR
021346 000240 NOP :RETURN HERE IF ERROR
021350 104000 EMT :ERROR # DEFINED BY SECERR SUBROUTINE
021352 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
021354 000137 021734 JMP 26$ :GO TO 26$ IF ERROR
1400 021360 14$:
1401
1402 :CHANGE LOOP ADDRESSES
1403 021360 012737 021370 001124 MOV #15$,SLPERR
1404 021366 000410 BR 16$ :SKIP TO NEXT OPERATION
1405
1406 :*****
1407 :LOOP #2 WRITE CHECK DATA
1408
1409 021370 15$:
1410

```

```

1411 ;PREPARE DEVICE FOR READ OPERATION
1412 02137C 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
      021374 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 16$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 26$ IF ERROR
      021376 000404 BR 16$
      021400 000240 NOP
      021402 104000 EMT
      021404 000137 021734 JMP 26$
1413 021410 16$:
1414 021410 012737 000005 001412 MOV #SEEK!GO,RMCS10 ;LOAD SEEK COMMAND
1415
1416 021416 004737 040360 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      021422 000404 BR 17$ ;GO TO 17$ IF NO ERROR
      021424 000240 NOP ;RETURN HERE IF ERROR
      021426 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
      021430 000137 021734 JMP 26$ ;GO TO 26$ IF ERROR
1417 021434 17$:
1418
1419 021434 004737 040024 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
1420
1421 021440 004737 040732 ;WAIT FOR COMMAND TO COMPLETE
      JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
1422
1423 ;GO READ REGISTER STATUS
1424 021444 004737 040110 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
      021450 000404 BR 18$ ;GO TO 18$ IF NO ERROR
      021452 000240 NOP ;RETURN HERE IF ERROR
      021454 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
      021456 000137 021734 JMP 26$ ;GO TO 26$ IF ERROR
1425 021462 18$:
1426
1427 ;GO VERIFY RESULTS OF SEEK
1428 021462 004737 046550 JSR PC,SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
      021466 000405 BR 19$ ;GO TO 19$ IF NO ERROR
      021470 000240 NOP ;RETURN HERE IF ERROR
      021472 104000 EMT ;ERROR # DEFINED BY SEKSTS SUBROUTINE
      021474 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      021476 000137 021734 JMP 26$ ;GO TO 26$ IF ERROR
1429 021502 19$:
1430
1431 ;READ DATA FROM DEVICE
1432 021502 20$:
1433 021502 012737 000051 001412 MOV #WCD!GO,RMCS10 ;READ DATA COMMAND
1434 021510 012702 001555 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
1435 021514 112722 000006 MOVB #RMDA,(R2)+
1436 021520 112722 000032 MOVB #RMOF,(R2)+
1437 021524 112722 000034 MOVB #RMDC,(R2)+
1438 021530 112722 000004 MOVB #RMDA,(R2)+
1439 021534 112722 000002 MOVB #RPMC,(R2)+
1440 021540 112722 000000 MOVB #RMCS1,(R2)+
  
```

```

1441 021544 112712 000200          MOV8   #200,(R2)
1442
1443 021550 004737 040360          JSR    PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      021554 000404          BR     21$           ;GO TO 21$ IF NO ERROR
      021556 000240          NOP                    ;RETURN HERE IF ERROR
      021560 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      021562 000137 021734          JMP    26$           ;GO TO 26$ IF ERROR
1444 021566          21$:
1445
1446          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      021566 004737 040024          JSR    PC,GETSTS      ;GO TO GETSTS SUBROUTINE
1447
1448          ;WAIT FOR COMMAND TO COMPLETE
      021572 004737 040732          JSR    PC,TIMOUT     ;GO TO TIMOUT SUBROUTINE
1449
1450          ;GO READ STATUS FOR WRITE CHECK OPERATION
1451 021576 004737 040110          JSR    PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      021602 000404          BR     22$           ;GO TO 22$ IF NO ERROR
      021604 000240          NOP                    ;RETURN HERE IF ERROR
      021606 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      021610 000137 021734          JMP    26$           ;GO TO 26$ IF ERROR
1452
1453          ;CHECK TO SEE IF THIS SECTOR WAS SKIP SECTORED FIRST, IF SO
1454          ;DO NOT EXECUTE THIS TEST IN 16 BIT FORMAT MODE
1455 021614          22$:
1456 021614 032737 000040 001400          BIT    #SSE,RMER2I   ;IS 'SSE' BIT SET ?
1457 021622 001030          BNE    25$           ;BR IF YES
1458
1459          ;CHECK FOR ERRORS DURING WRITE CHECK OPERATION
1460 021624 004737 041126          JSR    PC,PRIERR     ;GO CHECK FOR PRIMARY ERRORS
      021630 000405          BR     23$           ;GO TO 23$ IF NO ERROR
      021632 000240          NOP                    ;RETURN HERE IF ERROR
      021634 104000          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      021636 004736          JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      021640 000137 021734          JMP    26$           ;GO TO 26$ IF ERROR
1461 021644          23$:
1462 021644 004737 054166          JSR    PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      021650 000405          BR     24$           ;GO TO 24$ IF NO ERROR
      021652 000240          NOP                    ;RETURN HERE IF ERROR
      021654 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      021656 004736          JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      021660 000137 021734          JMP    26$           ;GO TO 26$ IF ERROR
1463 021664          24$:
1464 021664 004737 041760          JSR    PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      021670 000405          BR     25$           ;GO TO 25$ IF NO ERROR
      021672 000240          NOP                    ;RETURN HERE IF ERROR
      021674 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      021676 004736          JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      021700 000137 021734          JMP    26$           ;GO TO 26$ IF ERROR
1465 021704          25$:
1466 021704 032737 001000 001444          BIT    #SSEI,RMOFO   ;TEST 16 BIT MODE W/ SSEI SET ?
1467 021712 001010          BNE    26$           ;YES !!
1468 021714 012737 001037 001420          MOV    #TA2!31.,RMDAO ;TRACK = 1, SECTOR = 31.
1469 021722 052737 001000 001444          BIS    #SSEI,RMOFO   ;SET SSEI BIT IN OFFSET AND
1470 021730 000137 020754          JMP    2$            ;TEST AGAIN.
1471 021734          26$:
1472

```

1473

```

*****
*TEST 13      READ, WRITE CHECK W/ MID-TRANSFER SEEK
*****
TST13:
SCOPE          :SCOPE CALL
NOP            :START OF TEST
MOV #STACK,SP  :INITIALIZE STACK POINTER
MOV $BASE,R0   :R0 = UNIBUS ADDRESS
MOV TSTQUE,R1  :(R1) = DEVICE BEING TESTED
MOV #13,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
  
```

1474

1475

1476

1477

1478

1479 021762

1480 021762

1481 021770

1482 021776

1483 022004

1484 022004

1485 022012

1486 022020

1487 022026

1495 022034

1496

1497

1498 022034

022040

004737

034032

```

*****
:LOOP #1      READ,WRITE CHECK
  
```

```

:LOAD PARAMETERS AND GENERATE DATA BUFFER
1$:
  
```

```

MOV LSTRK,RMDAO ;SET LAST TRACK AND
MOVE #30,RMDAO  ;LAST SECTOR
MOV #FMT16,RMOFO ;16 BIT FORMAT
  
```

2\$:

```

MOV #559,RMDCO  ;CYLINDER = 559.
MOV #-256,*2,RMWCO ;CHANGE WORD COUNT
MOV #BUFONE,RMBAO ;CHANGE BUS ADDRSS
MOV #RD,RMCS10  ;READ DATA COMMAND
  
```

3\$:

```

:PREPARE DEVICE FOR READ OPERATION
  
```

```

JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 4$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 19$ IF ERROR
BR 4$
NOP
EMT
JMP 19$
  
```

022042

000404

BR 4\$

022044

000240

022046

104000

022050

000137

022546

JMP 19\$

1499 022054

1500

1501

1502 022054

1503 022054

1507 022062

1508 022066

1509 022072

1510 022076

1511 022102

1512 022106

1513 022112

1514 022116

1515

1516 022122

022126

000404

040360

```

:READ DATA FROM THE DRIVE
5$:
  
```

```

MOV #RD!GO,RMCS10 ;READ DATA COMMAND
MOV #PUTINX,R2    ;LOAD PUT REGISTER INDEX TABLE
MOVB #RMDA,(R2)+
MOVB #RMDC,(R2)+
MOVB #RMOF,(R2)+
MOVB #RMBA,(R2)+
MOVB #RMWC,(R2)+
MOVB #RMCS1,(R2)+
MOVB #200,(R2)+ ;TERMINATE TABLE
  
```

```

JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
BR 6$ ;GO TO 6$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
  
```

```

022132 104000          EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
022134 000137 022546   JMP          19$          ;GO TO 19$ IF ERROR
1517 022140          6$:
1518
1519          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
022140 004737 040024   JSR          PC,GETSTS      ;GO TO GETSTS SUBROUTINE
1520
1521          ;WAIT FOR COMMAND TO COMPLETE
022144 004737 040732   JSR          PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
1522
1523          ;GO READ STATUS FOR READ COMMAND
1524 022150 004737 040110   JSR          PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
022154 000404          BR          7$          ;GO TO 7$ IF NO ERROR
022156 000240          NOP          ;RETURN HERE IF ERROR
022160 104000          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
022162 000137 022546   JMP          19$          ;GO TO 19$ IF ERROR
1525
1526          ;CHECK TO SEE IF THIS SECTOR WAS SKIP SECTORED FIRST, IF SO
1527          ;DO NOT EXECUTE THIS TEST IN 16 BIT FORMAT MODE
1528 022166          7$:
1529 022166 032737 000040 001400   BIT          #SSE,RMER2I    ;IS 'SSE' BIT SET ?
1530 022174 001030          BNE          10$          ;BP IF YES
1531
1532          ;CHECK FOR ERRORS DURING READ OPERATION
1533 022176 004737 041126   JSR          PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
022202 000405          BR          8$          ;GO TO 8$ IF NO ERROR
022204 000240          NOP          ;RETURN HERE IF ERROR
022206 104000          EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
022210 004736          JSR          PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
022212 000137 022546   JMP          19$          ;GO TO 19$ IF ERROR
1534 022216          8$:
1535 022216 004737 054166   JSR          PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
022222 000405          BR          9$          ;GO TO 9$ IF NO ERROR
022224 000240          NOP          ;RETURN HERE IF ERROR
022226 104000          EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
022230 004736          JSR          PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
022232 000137 022546   JMP          19$          ;GO TO 19$ IF ERROR
1536 022236          9$:
1537 022236 004737 041760   JSR          PC,SECERR      ;GO CHECK FOR SECONDARY ERROR
022242 000405          BR          10$         ;GO TO 10$ IF NO ERROR
022244 000240          NOP          ;RETURN HERE IF ERROR
022246 104000          EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE
022250 004736          JSR          PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
022252 000137 022546   JMP          19$          ;GO TO 19$ IF ERROR
1538 022256          10$:
1539
1540          ;CHANGE LOOP ADDRESSES
1541 022256 012737 022266 001124   MOV          #11$,$LPERR
1542 022264 000410          BR          12$          ;SKIP TO NEXT OPERATION
1543
1544          ;*****
1545          ;LOOP #2          WRITE CHECK DATA
1546
1547 022266          11$:
1548
1549          ;PREPARE DEVICE FOR WRITE CHECK OPERATION
1550 022266 004737 034032   JSR          PC,TSTPRP      ;PREPARE DEVICE FOR TEST
  
```

```

022272 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 12$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 19$ IF ERROR

1551 022274 000404 BR 12$
1552 022276 000240 NOP
1553 022300 104000 EMT
1554 022302 000137 022546 JMP 19$
1555 022306 012737 000051 001412 12$:
;WRITE CHECK DATA FROM DEVICE
13$:
MOV #WCD!GO, RMCS10 ;READ DATA COMMAND
MOV #PUTINX, R2 ;LOAD PUT REGISTER INDEX TABLE
MOV #RMDA, (R2)+
MOV #RMOF, (R2)+
MOV #RMDC, (R2)+
MOV #RMBA, (R2)+
MOV #RMWC, (R2)+
MOV #RMCS1, (R2)+
MOV #200, (R2)

1565 022354 004737 040360 JSR PC, PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
022360 000404 BR 14$ ;GO TO 14$ IF NO ERROR
022362 000240 NOP ;RETURN HERE IF ERROR
022364 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
022366 000137 022546 JMP 19$ ;GO TO 19$ IF ERROR

1566 022372 14$:
;SETUP GET INDEX TABLE TO READ ALL REGISTERS
1567 JSR PC, GETSTS ;GO TO GETSTS SUBROUTINE
1568 022372 004737 040024

1569 ;WAIT FOR COMMAND TO COMPLETE
1570 JSR PC, TIMEOUT ;GO TO TIMEOUT SUBROUTINE
022376 004737 040732

1571 ;GO READ STATUS FOR READ OPERATION
1572 JSR PC, GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
1573 022402 004737 040110 BR 15$ ;GO TO 15$ IF NO ERROR
022406 000404 NOP ;RETURN HERE IF ERROR
022410 000240 EMT ;ERROR # DEFINED BY GET SUBROUTINE
022412 104000 JMP 19$ ;GO TO 19$ IF ERROR
022414 000137 022546

1574 ;CHECK TO SEE IF THIS SECTOR WAS SKIP SECTORED FIRST, IF SO
1575 ;DO NOT EXECUTE THIS TEST IN 16 BIT FORMAT MODE
1576 15$:
1577 022420 032737 000040 001400 BIT #SSE, RMER21 ;IS 'SSE' BIT SET ?
1578 022420 001030 BNE 18$ ;BR IF YES
1579 022426

1580 ;CHECK FOR ERRORS DURING READ OPERATION
1581 JSR PC, PRIERR ;GO CHECK FOR PRIMARY ERRORS
1582 022430 004737 041126 BR 16$ ;GO TO 16$ IF NO ERROR
022434 000405 NOP ;RETURN HERE IF ERROR
022436 000240 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
022440 104000
  
```

```

022442 004736 JSR PC,@(SP)+ ;GO PACK FOR MORE ERROR CHECKS
022444 000137 022546 JMP 19$ ;GO TO 19$ IF ERRCP
1583 022450 16$: JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
1584 022450 004737 024166 BR 17$ ;GO TO 17$ IF NO ERROR
022454 000405 NOP ;RETURN HERE IF ERROR
022456 000240 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
022460 104000 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
022462 004736 JMP 19$ ;GO TO 19$ IF ERROR
1585 022470 17$: JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
1586 022470 004737 041760 BR 18$ ;GO TO 18$ IF NO ERROR
022474 000405 NOP ;RETURN HERE IF ERROR
022476 000240 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
022500 104000 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
022502 004736 JMP 19$ ;GO TO 19$ IF ERROR
1587 022510 18$: BIT #SSEI,RMOFO ;TEST 16 BIT MODE W/ SSEI SET ?
1588 022510 032737 001000 001444 BNE 19$ ;YES !!
1589 022516 001013 MOV LSTRK,RMDAO ;SET LAST TRACK AND
1590 022520 013737 001334 001420 MOVB #31,RMDAO ;LAST SECTOR
1591 022526 112737 000037 001420 BIS #SSEI,RMOFO ;SET SSEI BIT IN RMOF AND
1592 022534 052737 001000 001444 JMP 2$ ;TEST AGAIN.
1593 022542 000137 022004
1594 022546
1595
1596
;*****
;*TEST 14 WRITE, READ W/ HCE ERROR
;*****
;ST14:
022546 000004 SCOPE ;SCOPE CALL
022550 000240 NOP ;START OF TEST
022552 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
022556 013700 001276 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
022562 013701 001466 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
022566 012737 000014 001226 MOV #14,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
1597
1598
1599
;*****
;LOOP #1 FORMAT,WRITE,READ
;*****
1600
1601 022574 012704 000000 MOV #0,R4 ;R4 = 1ST HEADER WORD
1602 022600 012703 000001 1$: MOV #1,R3 ;R3 = HCE BIT
1603 022604 2$:
1604
1605
;PREPARE THE DEVICE FOR FORMAT OPERATION
1606 022604 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
022610 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
022612 000404 BR 3$ ;GO TO 3$ IF NO ERROR
022614 000240 NOP ;RETURN HERE IF ERROR
022616 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
022620 000137 024416 JMP 47$ ;GO TO 47$ IF ERROR
  
```



```

1607
1608          ;LOAD PARAMETERS AND GENERATE DATA BUFFER
1609 022624          3$:
1610 022624 012737 001057 001446      MOV      #559.,R,DCO      ;CYLINDER = 559.
1611 022632 012737 001000 001420      MOV      #TA2,RMDAO     ;TRACK = 2, SECTOR# = 0
1612 022640 012737 104254 001416      MOV      #BUFONE,RMBAO  ;BUS ADDRESS
1613 022646 012737 177376 001414      MOV      #-258.,RMWCO   ;2 + 256. WORDS (2'S COMP)
1614 022654 012737 010000 001444      MOV      #FMT16,RMOFO   ;16 BIT FORMAT
1615 022662 012737 000063 001412      MOV      #WH!GO,RMCS10  ;WRITE HEADER AND DATA COMMAND
1616
1617          ;VERIFY THAT SECTOR IS NOT BAD
          JSR      PC,BADSCT      ;CALL BAD SECTOR MODULE
          BR      4$              ;GO TO 4$ IF NO ERROR
          TYPE     ,SCTMSG        ;TYPE BAD SECTOR MESSAGE
          EMT      46$           ;ERROR # DEFINED BY BADSCT SUBROUTINE
          JMP      46$           ;GO TO 46$ IF ERROR
1618 022710          4$:
1619 022710 012737 067456 001174      MOV      #ZEROS,$TMP0    ;STARTING ADDRESS OF PATTERN
1620 022716 012737 000001 001176      MOV      #1,$TMP1       ;RANGE OF PATTERN
1621 022724 004737 037214          JSR      PC,GENBUF       ;GO GENERATE BUFFER FOR FORMAT
1622
1623          ;CHANGE HEADER WORD TO FORCE HCE DURING WRITE & READ
          BIT      R3,BUFONE(R4)  ;SET OR RESET FOR HCE??
          BEQ      5$
          BIC      R3,BUFONE(R4)  ;RESET BIT FOR HCE
          BR      6$
1624 022730 030364 104254          5$:  BIS      R3,BUFONE(R4)  ;SET FOR HCE
1625 022734 001403
1626 022736 040364 104254
1627 022742 000402
1628 022744 050364 104254
1629
1630          ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
          6$:
1631 022750          MOV      #PUTINX,R2      ;R2 = BYTE ENTRY POSITION
1632 022750 012702 001555      MOVB     #RMDC,(R2)+
1633 022754 112722 000034      MOVB     #RMDA,(R2)+
1634 022760 112722 000006      MOVB     #RMBA,(R2)+
1635 022764 112722 000004      MOVB     #RMWC,(R2)+
1636 022770 112722 000002      MOVB     #RMOF,(R2)+
1637 022774 112722 000032      MOVB     #RMCS1,(R2)+
1638 023000 112722 000000      MOVB     #200,(R2)
1639 023004 112712 000200      ;TERMINATE TABLE
1640 023010          7$:
1641 023010 004737 040360      JSR      PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
          BR      8$              ;GO TO 8$ IF NO ERROR
          NOP      46$           ;RETURN HERE IF ERROR
          EMT      46$           ;ERROR # DEFINED BY PUT SUBROUTINE
          JMP      46$           ;GO TO 46$ IF ERROR
1642 023026          8$:
1643
1644          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
          JSR      PC,GETSTS      ;GO TO GETSTS SUBROUTINE
1645 023026 004737 040024
1646          ;WAIT FOR COMMAND TO COMPLETE
          JSR      PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
1647 023032 004737 040732
1648
1649          ;GO READ STATUS FOR FORMAT OPERATION
          JSR      PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
          BR      9$              ;GO TO 9$ IF NO ERROR
          NOP      46$           ;RETURN HERE IF ERROR
          EMT      46$           ;ERROR # DEFINED BY GET SUBROUTINE
          023042 000404
          023044 000240
          023046 104000
    
```

```

1650 023050 000137 024416          JMP      46$          ;GO TO 46$ IF ERROR
1651 023054
1652
1653 023054 004737 054166          ;VERIFY NO ERRORS DURING FORMAT
      023060 000405          JSR      PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      023062 000240          BR       10$        ;GO TO 10$ IF NO ERROR
      023064 104000          NOP
      023066 004736          EMT      ;RETURN HERE IF ERROR
      023070 000137 024416          JSR      PC,@(SP)+  ;ERROR # DEFINED BY DTASTS SUBROUTINE
      023074          JMP      46$        ;GO BACK FOR MORE ERROR CHECKS
      ;GO TO 46$ IF ERROR

1654 023074
1655
1656
1657 023074 012737 023104 001124      ;MOVE LOOP ADDRESSES TO NEXT OPERATION
1658 023102 000410          MOV      #11$, $LPERR
1659
1660
1661
1662
1663 023104
1664
1665
1666 023104 004737 034032      ;PREPARE DEVICE FOR WRITE OPERATION
      023110 154130          JSR      PC,TSTPRP  ;PREPARE DEVICE FOR TEST
      ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 12$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 46$ IF ERROR
      BR       12$
      NOP
      EMT
      JMP      46$

1667 023124
1668
1669
1670 023124
1671 023124 012737 104260 001416      ;WRITE DATA TO THE DRIVE
1672 023132 012737 177400 001414      13$:
1673 023140 012737 000061 001412      MOV      #BUFONE+4,RMBAD ;CHANGE BUS ADDRESS
1674 023146 012702 001555          MOV      #-256.,RMWCO   ;CHANGE WORD COUNT
1675 023152 112722 000006          MOV      #WD!GO,RMCS10 ;WRITE DATA COMMAND
1676 023156 112722 000034          MOV      #PUTINX,R2    ;LOAD PUT REGISTER INDEX TABLE
1677 023162 112722 000032          MOVB    #RMDA,(R2)+
1678 023166 112722 000004          MOVB    #RMDC,(R2)+
1679 023172 112722 000002          MOVB    #RMOF,(R2)+
1680 023176 112722 000000          MOVB    #RMDA,(R2)+
1681 023202 112722 000200          MOVB    #RMC1,(R2)+
1682
1683 023206 004737 040360          MOVB    #200,(R2)+
      ;TERMINATE TABLE
      JSR      PC,PUT    ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      BR       14$      ;GO TO 14$ IF NO ERROR
      NOP
      EMT
      JMP      46$      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 46$ IF ERROR

1684 023224          14$:

```

```

1685
1686      023224 004737 040024      :SEIUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR      PC,GETSTS      :GO TO GETSTS SUBROUTINE
1687
1688      023230 004737 040732      :WAIT FOR COMMAND TO COMPLETE
      JSR      PC,TIMOUT      :GO TO TIMEOUT SUBROUTINE
1689
1690      023234 004737 040110      :GO READ STATUS FOR WRITE COMMAND
1691      023240 000404      JSR      PC,GET      :GO READ REGISTER(S) WITH GET SUBROUTINE
      023242 000240      BR       15$      :GO TO 15$ IF NO ERROR
      023244 104000      NOP      :RETURN HERE IF ERROR
      023246 000137 024416      EMT      :ERROR # DEFINED BY GET SUBROUTINE
      JMP      46$      :GO TO 46$ IF ERROR
1692      023252      15$:
1693
1694      023252 004737 041126      :CHECK FOR ERRORS DURING WRITE OPERATION
1695      023256 000405      JSR      PC,PRIERR      :GO CHECK FOR PRIMARY ERRORS
      023260 000240      BR       16$      :GO TO 16$ IF NO ERROR
      023262 104000      NOP      :RETURN HERE IF ERROR
      023264 004736      EMT      :ERROR # DEFINED BY PRIERR SUBROUTINE
      023266 000137 024416      JSR      PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
      JMP      46$      :GO TO 46$ IF ERROR
1696
1697      023272      16$:
1698      023272 005704      :DECODE THE TYPE OF ERROR PRODUCED BY THE BIT POSITION OF R3
1699      023274 001011      TST      R4      :IS THIS THE FIRST HEADER WORD ?
1700      023276 032703 020000      BNE      17$      :NO !!
1701
1702      023302 001042      BIT      #SSF,R3      :SHOULD SSE BE SET ?
1703      023304 032703 010000      BNE      20$      :YES !!
1704      023310 001067      BIT      #FMT16,R3      :SHOULD FER BE SET ?
1705      023312 032703 140000      BNE      22$      :YES !!
1706      023316 001111      BIT      #MSE!USE,R3      :SHOULD BSE BE SET ?
1707      023316 001111      BNE      24$      :YES !!
1708
1709      023320      17$:
1710      023320 032737 000200 001352      :VERIFY THAT A HEADER COMPARE ERROR WAS DETECTED
1711      023326 001132      BIT      #HCE,RMER11      :WAS HCE DETECTED ??
1712      023330 004737 054166      BNE      26$      :YES !!
1713
1714      023334 000405      JSR      PC,DTASTS      :GO VERIFY RESULTS OF DATA TRANSFER
      023336 000240      BR       18$      :GO TO 18$ IF NO ERROR
      023340 104000      NOP      :RETURN HERE IF ERROR
      023342 004736      EMT      :ERROR # DEFINED BY DTASTS SUBROUTINE
      023344 000137 024416      JSR      PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
      JMP      46$      :GO TO 46$ IF ERROR
1715      023350      18$:
1716      023350 013737 001352 001142      MOV      RMER11,$BDDAT      :RECEIVED STATUS
1717      023356 012737 000200 001140      MOV      #HCE,$GDDAT      :EXPECTED STATUS
1718      023364 010437 001174      MOV      R4,$TMP0      :R4 = HEADER WORD NUMBER AND
1719      023370 001002      BNE      19$      :ADJUST NUMBER.
1720      023372 005237 001174      INC      $TMP0
1721      023376 010337 001176      19$: MOV      R3,$TMP1      :R3 = BIT POSIITON
1722      023402 104344      EMT      344
1723      023404 000137 024416      JMP      46$
1724
1725      :VERIFY THAT SSE IS SET
  
```

```

1726 023410          20$:
1727 023410 032737 000040 001400 BIT #SSE,RMER2I ;IS SSE SET ?
1728 023416 001076 BNE 26$ ;YES !!
1729
1730 023420 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
      023424 000405 BR 21$ ;GO TO 21$ IF NO ERROR
      023426 000240 NOP ;RETURN HERE IF ERROR
      023430 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
      023432 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      023434 000137 JMP 46$ ;GO TO 46$ IF ERROR
1731 023440
1732 023440 013737 001400 001142 21$: MOV RMER2I,$BDDAT ;GET RECIEVED STATUS
1733 023446 013737 001400 001140 MOV RMER2I,$GDDAT ;GET EXPECTED STATUS AND
1734 023454 052737 000040 001140 BIS #SSE,$GDDAT ;SET SSE.
1735 023462 104224 EMT 224
1736 023464 000137 024416 JMP 46$
1737
1738 ;VERIFY THAT A FORMAT ERROR WAS DETECTED
1739 023470 22$:
1740 023470 032737 000020 001352 BIT #FER,RMER1I ;WAS FER DETECTED ??
1741 023476 001046 BNE 26$ ;YES !!
1742
1743 023500 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
      023504 000405 BR 23$ ;GO TO 23$ IF NO ERROR
      023506 000240 NOP ;RETURN HERE IF ERROR
      023510 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
      023512 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      023514 000137 JMP 46$ ;GO TO 46$ IF ERROR
1744 023520
1745 023520 012737 000020 001140 23$: MOV #FER,$GDDAT ;EXPECTED STATUS
1746 023526 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
1747 023534 104343 EMT 343
1748 023536 000137 024416 JMP 46$
1749
1750 ;VERIFY THAT A BAD SECTOR ERROR WAS DETECTED
1751 023542 24$:
1752 023542 032737 100000 001400 BIT #BSE,RMER2I ;WAS BSE DETECTED ??
1753 023550 001021 BNE 26$ ;YES !!
1754
1755 023552 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
      023556 000405 BR 25$ ;GO TO 25$ IF NO ERROR
      023560 000240 NOP ;RETURN HERE IF ERROR
      023562 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
      023564 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      023566 000137 JMP 46$ ;GO TO 46$ IF ERROR
1756 023572
1757 023572 013737 001400 001142 25$: MOV RMER2I,$BDDAT ;RECEIVED STATUS
1758 023600 012737 100000 001140 MOV #BSE,$GDDAT ;EXPECTED STAIUS
1759 023606 104345 EMT 345
1760 023610 000137 024416 JMP 46$
1761
1762 ;CHECK FOR OTHER ERRORS
1763 023614 26$:
1764 023614 004737 041760 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
      023620 000405 BR 27$ ;GO TO 27$ IF NO ERROR
      023622 000240 NOP ;RETURN HERE IF ERROR
      023624 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
  
```

```

023626 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
023630 000137 024416 JMP 46$ ;GO TO 46$ IF ERROR
1765 023634 27$:
1766
1767 ;CHANGE LOOP ADDRESSES
1768 023634 012737 023642 001124 MOV #28$,SLPERR
1769
1770 ;*****
1771 ;LOOP #3 READ
1772
1773 023642 28$:
1774
1775 ;PREPARE DEVICE FOR READ OPERATION
1776 023642 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
023646 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 29$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 46$ IF ERROR

023650 000404 BR 29$
023652 000240 NOP
023654 104000 EMT
023656 000137 024416 JMP 46$
1777 023662 29$:
1778
1779 ;READ DATA FROM DEVICE
1780 023662 30$:
1781 023662 012737 105264 001416 MOV #BUFTWO+4,RMBAO ;CHANGE BUS ADDRESS
1782 023670 012737 177400 001414 MOV #-256,RMWCO ;CHANGE WORD COUNT
1783 023676 012737 000071 001412 MOV #RD!GO,RMCS10 ;READ DATA COMMAND
1784 023704 012702 001555 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
1785 023710 112722 000006 MOVB #RMDA,(R2)+
1786 023714 112722 000032 MOVB #RMOF,(R2)+
1787 023720 112722 000034 MOVB #RMDC,(R2)+
1788 023724 112722 000004 MOVB #RMEA,(R2)+
1789 023730 112722 000002 MOVB #RMJC,(R2)+
1790 023734 112722 000000 MOVB #RMCS1,(R2)+
1791 023740 112712 000200 MOVB #200,(R2)
1792
1793 023744 004737 040360 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
023750 000404 BR 31$ ;GO TO 31$ IF NO ERROR
023752 000240 NOP ;RETURN HERE IF ERROR
023754 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
023756 000137 024416 JMP 46$ ;GO TO 46$ IF ERROR
1794 023762 31$:
1795
1796 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
023762 004737 040024 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
1797
1798 ;WAIT FOR COMMAND TO COMPLETE
023766 004737 040732 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
1799
1800 ;GO READ STATUS FOR READ OPERATION
1801 023772 004737 040110 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
    
```

```

023776 000404 BR 32$ :GO TO 32$ IF NO ERROR
024000 000240 NOP :RETURN HERE IF ERROR
024002 104000 EMT :ERROR # DEFINED BY GET SUBROUTINE
024004 000137 024416 JMP 46$ :GO TO 46$ IF ERROR
1802 024010 32$:
1803
1804 :CHECK FOR ERRORS DURING READ OPERATION
1805 024010 004737 041126 JSR PC,PRIERR :GO CHECK FOR PRIMARY ERRORS
024014 000405 BR 33$ :GO TO 33$ IF NO ERROR
024016 000240 NOP :RETURN HERE IF ERROR
024020 104000 EMT :ERROR # DEFINED BY PRIERR SUBROUTINE
024022 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
024024 000137 024416 JMP 46$ :GO TO 46$ IF ERROR
1806 024030 33$:
1807 024030 005704 TST R4 :IS THIS THE FIRST HEADER WORD ?
1808 024032 001011 BNE 34$ :NO !!
1809
1810 024034 032703 020000 BIT #SSF,R3 :SHOULD SSE BE SET ?
1811 024040 001042 BNE 37$ :YES !!
1812 024042 032703 010000 BIT #FMT16,R3 :SHOULD FER BE SET ?
1813 024046 001067 BNE 39$ :YES !!
1814 024050 032703 140000 BIT #MSE!USE,R3 :SHOULD BSE BE SET ?
1815 024054 001111 BNE 41$ :YES !!
1816
1817 :VERIFY THAT A HEADER COMPARE ERROR WAS DETECTED
1818 024056 34$:
1819 024056 032737 000200 001352 BIT #HCE,RMER11 :WAS HCE DETECTED ??
1820 024064 001132 BNE 43$ :YES !!
1821
1822 024066 004737 054166 JSR PC,DTASTS :GO VERIFY RESULTS OF DATA TRANSFER
024072 000405 BR 35$ :GO TO 35$ IF NO ERROR
024074 000240 NOP :RETURN HERE IF ERROR
024076 104000 EMT :ERROR # DEFINED BY DTASTS SUBROUTINE
024100 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
024102 000137 024416 JMP 46$ :GO TO 46$ IF ERROR
1823 024106 35$:
1824 024106 013737 001352 001142 MOV RMER11,$BDDAT :RECEIVED STATUS
1825 024114 012737 000200 001140 MOV #HCE,$GDDAT :EXPECTED STATUS
1826 024122 010437 001174 MOV R4,$TMP0 :R4 = HEADER WORD NUMBER AND
1827 024126 001002 BNE 36$ :ADJUST NUMBER.
1828 024130 005237 001174 INC $TMP0
1829 024134 010337 001176 36$: MOV R3,$TMP1 :R3 = BIT POSITION
1830 024140 104344 EMT 344
1831 024142 000137 024416 JMP 46$
1832
1833 :VERIFY THAT SSE BIT IS SET
1834 024146 37$:
1835 024146 032737 000040 001400 BIT #SSE,RMER21 :IS SSE SET ?
1836 024154 001076 BNE 43$ :YES !!
1837
1838 024156 004737 054166 JSR PC,DTASTS :GO VERIFY RESULTS OF DATA TRANSFER
024162 000405 BR 38$ :GO TO 38$ IF NO ERROR
024164 000240 NOP :RETURN HERE IF ERROR
024166 104000 EMT :ERROR # DEFINED BY DTASTS SUBROUTINE
024170 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
024172 000137 024416 JMP 46$ :GO TO 46$ IF ERROR
1839 024176 38$:

```

4 WRITE, READ W/ HCE ERROR

```

1840 024176 013737 001400 001142      MOV      RMER2I,$BDDA1      ;GET RECIEVED STATUS
1841 024204 013737 001400 001140      MOV      RMER2I,$GDDAT     ;GET EXPECTED STATUS AND
1842 024212 052737 000040 001140      BIS      #SSE,$GDDAT      ;SET SSE.
1843 024220 104224                      EMT      224
1844 024222 000137 024416                      JMP      46$
1845
1846                                     ;VERIFY THAT A FORMAT ERRCR WAS DETECTED
1847 024226                                     39$:
1848 024226 032737 000020 001352      BIT      #FER,RMER1I      ;WAS FER DETECTED ??
1849 024234 001046                      BNE      43$              ;YES !!
1850
1851 024236 004737 054166                      JSR      PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
                                024242 000405                      BR      40$              ;GO TO 40$ IF NO ERROR
                                024244 000240                      NOP                      ;RETURN HERE IF ERROR
                                024246 104000                      EMT                      ;ERROR # DEFINED BY DTASTS SUBROUTINE
                                024250 004736                      JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
                                024252 000137 024416                      JMP      46$              ;GO TO 46$ IF ERROR
1852 024256                                     40$:
1853 024256 012737 000020 001140      MOV      #FER,$GDDAT      ;EXPECTED STATUS
1854 024264 013737 001352 001142      MOV      RMER1I,$BDDAT    ;RECEIVED STATUS
1855 024272 104343                      EMT      343
1856 024274 000137 024416                      JMP      46$
1857
1858                                     ;VERIFY THAT A BAD SECTOR ERROR WAS DETECTED
1859 024300                                     41$:
1860 024300 032737 100000 001400      BIT      #BSE,RMER2I      ;WAS BSE DETECTED ??
1861 024306 001021                      BNE      43$              ;YES !!
1862
1863 024310 004737 054166                      JSR      PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
                                024314 000405                      BR      42$              ;GO TO 42$ IF NO ERROR
                                024316 000240                      NOP                      ;RETURN HERE IF ERROR
                                024320 104000                      EMT                      ;ERROR # DEFINED BY DTASTS SUBROUTINE
                                024322 004736                      JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
                                024324 000137 024416                      JMP      46$              ;GO TO 46$ IF ERROR
1864 024330                                     42$:
1865 024330 013737 001400 001142      MOV      RMER2I,$BDDAT    ;RECEIVED STATUS
1866 024336 012737 100000 001140      MOV      #BSE,$GDDAT     ;EXPECTED STAIUS
1867 024344 104345                      EMT      345
1868 024346 000137 000350                      JMP      350
1869
1870                                     ;CHECK FOR OTHER ERRORS
1871 024352                                     43$:
1872 024352 004737 041760                      JSR      PC,SECERR        ;GO CHECK FOR SECONDARY ERRORS
                                024356 000405                      BR      44$              ;GO TO 44$ IF NO ERROR
                                024360 000240                      NOP                      ;RETURN HERE IF ERROR
                                024362 104000                      EMT                      ;ERROR # DEFINED BY SECERR SUBROUTINE
                                024364 004736                      JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
                                024366 000137 024416                      JMP      46$              ;GO TO 46$ IF ERROR
1873 024372                                     44$:
1874 024372 006303                      ASL      R3                ;SHIFT TO NEXT BIT
1875 024374 001006                      BNE      45$              ;REPEAT IF NOT DONE
1876
1877 024376 005704                      TST      R4                ;SECOND HEADER WORD DONE??
1878 024400 001006                      BNE      46$              ;YES!!
1879 024402 012704 000002                      MOV      #2,R4            ;SETUP FOR 2ND HEADER WORD
1880 024406 012703 000001                      MOV      #1,R3            ;SETUP FOR HCE
1881 024412                                     45$:

```

1882 024412 000137 022604
 1883 024416
 1884
 1885 024416
 1886
 1887

JMP 2\$
 46\$:
 47\$:

 :*TEST 15 WRITE, READ W/ HCI & SSEI

 TST15:

024416
 024416 000004
 024420 000240
 024422 012706 001100
 024426 013700 001276
 024432 013701 001466
 024436 012737 000015 001226

SCOPE :SCOPE CALL
 NOP :START OF TEST
 MOV #STACK,SP :INITIALIZE STACK POINTER
 MOV \$BASE,R0 :R0 = UNIBUS ADDRESS
 MOV TSTQUE,R1 :(R1) = DEVICE BEING TESTED
 MOV #15,\$TESTN ;;SET TEST NUMBER IN APT MAIL BOX

1888
 1889
 1890
 1891
 1892 024444 012704 000000
 1893 024450 012703 000001
 1894 024454
 1895
 1896
 1897 024454 004737 034032
 024460 154130

 :LOOP #1 FORMAT,WRITE,READ

1\$: MOV #0,R4 :HEADER WORD
 MOV #1,R3 :HCE BIT
 2\$:

;PREPARE THE DEVICE FOR FORMAT OPERATION

JSR PC,TSTPRP :PREPARE DEVICE FOR TEST
 .WORD 154130 :TASK DESCRIPTOR AS FOLLOWS.
 :SELECT DEVICE & VERIFY DEVICE AVAILABLE
 :CLEAR CONTROLLER & SELECT DEVICE
 :VERIFY CONTROLLER CLEAR OPERATION
 :PACK ACKNOWLEDGE IF VOLUME NOT VALID
 :VERIFY PACK ACKNOWLEDGE
 :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
 :VERIFY RECALIBRATION
 :GO TO 3\$ IF NO ERROR
 :RETURN HERE IF ERROR
 :ERROR # DEFINED BY TSTPRP SUBROUTINE
 :GO TO 38\$ IF ERROR

024462 000404
 024464 000240
 024466 104000
 024470 000137 025720

BR 3\$
 NOP
 EMT
 JMP 38\$

1898
 1899
 1900 024474
 1901 024474 012737 001057 001446
 1902 024502 012737 001000 001420
 1903 024510 012737 104254 001416
 1904 024516 012737 177376 001414
 1905 024524 012737 010000 001444
 1906 024532 012737 000063 001412
 1907
 1908

;LOAD PARAMETERS AND GENERATE DATA BUFFER

3\$: MOV #559.,RMDCO :CYLINDER = 559.
 MOV #TA2,RMDAO :TRACK = 2, SECTOR = 0
 MOV #BUFONE,RMBAO :BUS ADDRESS
 MOV #-258.,RMDCO :2 + 256. WORDS (2' COMP)
 MOV #FMT16,RMFO :16 BIT FORMAT
 MOV #WH!GO,RMCS10 :WRITE HEADER AND DATA COMMAND

;VERIFY THAT SECTOR IS NOT BAD

JSR PC,BADSCT :CALL BAD SECTOR MODULE
 BR 4\$:GO TO 4\$ IF NO ERROR
 TYPE ,SCTMSG :TYPE BAD SECTOR MESSAGE
 EMT :ERROR # DEFINED BY BADSCT SUBROUTINE
 JMP 37\$:GO TO 37\$ IF ERROR

024540 004737 034762
 024544 000405
 024546 104401 066006
 024552 104000
 024554 000137 025720
 1909 024560
 1910 024560 012737 067414 001174
 1911 024566 012737 000001 001176
 1912 024574 004737 037214

4\$: MOV #ONES,\$TMP0 :STARTING ADDRESS OF PATTERN
 MOV #1,\$TMP1 :RANGE OF PATTERN
 JSR PC,GENBUF :GO GENERATE BUFFER FOR FORMAT

1917
 1914
 1915
 1916
 1917
 1918
 1919
 1920
 1921
 1922
 1923
 1924
 1925
 1926
 1927
 1928
 1929
 1930
 1931
 1932
 1933
 1934
 1935
 1936
 1937
 1938
 1939
 1940
 1941
 1942
 1943
 1944
 1945
 1946
 1947
 1948
 1949
 1950
 1951
 1952
 1953
 1954

024600 030364 104254
 024604 001403
 024606 040364 104254
 024612 000402
 024614 050364 104254
 024620
 024620 012702 001555
 024624 112722 000034
 024630 112722 000006
 024634 112722 000004
 024640 112722 000002
 024644 112722 000032
 024650 112722 000000
 024654 112712 000200
 024660
 024660 004737 040360
 024664 000404
 024666 000240
 024670 104000
 024672 000137 025720
 024676
 024676 004737 040024
 024702 004737 040732
 024706 004737 040110
 024712 000404
 024714 000240
 024716 104000
 024720 000137 025720
 024724
 024724 004737 054166
 024730 000405
 024732 000240
 024734 104000
 024736 004736
 024740 000137 025720
 024744
 024744 012737 024754 001124
 024752 000410

```

;CHANGE HEADER WORD TO FORCE ERROR DURING WRITE
BI!   R3, BUFONE(R4)   ;SET OR RESET BIT??
BEQ   5$
BIC   R3, BUFONE(R4)   ;RESET BIT
BR    6$
BIS   R3, BUFONE(R4)   ;SET BIT

;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
6$:
MOV   #PUTINX, R2      ;R2 = BYTE ENTRY POSITION
MOVB  #RMDC, (R2)+
MOVB  #RMDA, (R2)+
MOVB  #RMBA, (R2)+
MOVB  #RMWC, (R2)+
MOVB  #RMOF, (R2)+
MOVB  #RMCST, (R2)+
MOVB  #200, (R2)       ;TERMINATE TABLE

7$:

;FORMAT THE DRIVE
JSR   PC, PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
BR    8$              ;GO TO 8$ IF NO ERROR
NOP   ;RETURN HERE IF ERROR
EMT   ;ERROR # DEFINED BY PUT SUBROUTINE
JMP   37$             ;GO TO 37$ IF ERROR

8$:

;SETUP GET INDEX TABLE TO READ ALL REGISTERS
JSR   PC, GETSTS      ;GO TO GETSTS SUBROUTINE

;WAIT FOR COMMAND TO COMPLETE
JSR   PC, TIMEOUT    ;GO TO TIMEOUT SUBROUTINE

;GO READ STATUS FOR FORMAT OPERATION
JSR   PC, GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
BR    9$              ;GO TO 9$ IF NO ERROR
NOP   ;RETURN HERE IF ERROR
EMT   ;ERROR # DEFINED BY GET SUBROUTINE
JMP   37$             ;GO TO 37$ IF ERROR

9$:

;VERIFY NO ERRORS DURING FORMAT
JSR   PC, DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
BR    10$            ;GO TO 10$ IF NO ERROR
NOP   ;RETURN HERE IF ERROR
EMT   ;ERROR # DEFINED BY DTASTS SUBROUTINE
JSR   PC, @ (SP)+    ;GO BACK FOR MORE ERROR CHECKS
JMP   37$            ;GO TO 37$ IF ERROR

10$:

;MOVE LOOP ADDRESSES TO NEXT OPERATION
MOV   #11$, $LPERR
BR    12$            ;SKIP TO WRITE OPERATION

;*****
;LOOP #2          WRITE, READ
  
```

```

1955
1956 024754      11$:
1957
1958
1959 024754 004737 034032  :PREPARE DEVICE FOR WRITE OPERATION
      024760 154130      JSR   PC,TSTPRP      ;PREPARE DEVICE FOR TEST
                          .WOFD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
                          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                          ;CLEAR CONTROLLER & SELECT DEVICE
                          ;VERIFY CONTROLLER CLEAR OPERATION
                          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                          ;VERIFY PACK ACKNOWLEDGE
                          ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                          ;VERIFY RECALIBRATION
                          ;GO TO 12$ IF NO ERROR
                          ;RETURN HERE IF ERROR
                          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                          ;GO TO 37$ IF ERROR

      024762 000404      BR    12$
      024764 000240      NOP
      024766 104000      EMT
      024770 000137 025720 JMP   37$
1960 024774
1961
1962
1963 024774      :WRITE DATA TO THE DRIVE
1964 024774 012737 013000 001444 13$:
      MOV   #FMT16!HCI!SSEI,RMOFO      ;INHIBIT HEADER COMPARE AND SKIP
      MOV   #WD!GO,RMCS10              ;SKIP SECTOR ERRORS
      MOV   #BUFONE+4,RMBA0            ;WRITE DATA COMMAND
      MOV   #PUTINX,R2                 ;LOAD STARTING BUFFER ADDRESS
      MOV   #RMDA,(R2)+               ;LOAD PUT REGISTER INDEX TABLE
      MOV   #RMDC,(R2)+
      MOV   #RMOF,(R2)+
      MOV   #RMBA,(R2)+
      MOV   #RMWC,(R2)+
      MOV   #RMCS1,(R2)+
      MOV   #200,(R2)+                ;TERMINATE TABLE
1965
1966 025002 012737 000061 001412
1967 025010 012737 104260 001416
1968 025016 012702 001555
1969 025022 112722 000006
1970 025026 112722 000034
1971 025032 112722 000032
1972 025036 112722 000004
1973 025042 112722 000002
1974 025046 112722 000000
1975 025052 112722 000200
1976
1977 025056 004737 040360      JSR   PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      025062 000404      BR    14$        ;GO TO 14$ IF NO ERROR
      025064 000240      NOP          ;RETURN HERE IF ERROR
      025066 104000      EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
      025070 000137 025720 JMP   37$        ;GO TO 37$ IF ERROR
1978 025074
1979
1980 025074 004737 040024      :SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR   PC,GETSTS      ;GO TO GETSTS SUBROUTINE
1981
1982 025100 004737 040732      :WAIT FOR COMMAND TO COMPLETE
      JSR   PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
1983
1984
1985 025104 004737 040110      :GO READ STATUS FOR WRITE COMMAND
      JSR   PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      BR    15$          ;GO TO 15$ IF NO ERROR
      NOP          ;RETURN HERE IF ERROR
      EMT          ;ERROR # DEFINED BY GET SUBROUTINE
      JMP   37$          ;GO TO 37$ IF ERROR
1986 025122
1987
1988
1989 025122 004737 041126      :CHECK FOR ERRORS DURING WRITE OPERATION
      JSR   PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
  
```

M 10

```

025126 000405 BR 16$ ;GO TO 16$ IF NO ERROR
025130 000240 NOP ;RETURN HERE IF ERROR
025132 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
025134 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
025136 000137 JMP 37$ ;GO TO 37$ IF ERROR
1990 025142 005037 001140 16$: CLR $GDDAT ;EXPECTED STATUS
1991
1992 025146 032737 000220 001352 BIT #HCE!FER,RMER1I ;ANY ERROR??
1993 025154 001407 BEQ 17$
1994 025156 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
1995 025164 042737 177557 001142 BIC #^C<HCE!FER>,$BDDAT ;CLEAR DONT CARES
1996 025172 000412 BR 18$
1997 025174
1998 025174 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
1999 025202 032737 100000 001400 BIT #BSE,RMER2I ;ANY BAD SECTOR ERROR ?
2000 025210 001406 BEQ 19$ ;NO !!
2001 025212 042737 077777 001142 BIC #^CBSE,$BDDAT ;SAVE BSE FOR ERROR
2002 025220
2003 025220 104346 EMT 346
2004 025222 000137 025720 JMP 37$
2005 025226
2006 025226 032737 000040 001400 BIT #SSE,RMER2I ;ANY SKIP SECTOR ERROR ?
2007 025234 001406 BEQ 20$
2008 025236 043737 177737 001142 BIC ^CSSE,$BDDAT ;SAVE SSE FOR ERROR
2009 025244 104227 EMT 227
2010 025246 000137 025720 JMP 37$
2011 025252
2012 025252 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
025256 000405 BR 21$ ;GO TO 21$ IF NO ERROR
025260 000240 NOP ;RETURN HERE IF ERROR
025262 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
025264 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
025266 000137 025720 JMP 37$ ;GO TO 37$ IF ERROR
2013 025272
2014 025272 004737 041760 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
025276 000405 BR 22$ ;GO TO 22$ IF NO ERROR
025300 000240 NOP ;RETURN HERE IF ERROR
025302 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
025304 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
025306 000137 025720 JMP 37$ ;GO TO 37$ IF ERROR
2015 025312
2016
2017 ;CHANGE LOOP ADDRESSES
2018 025312 012737 025322 001124 MOV #23$,$LPERR
2019 025320 000410 BR 24$
2020
2021 ;*****
2022 ;LOOP #3 READ
2023
2024 025322 23$:
2025
2026 ;PREPARE DEVICE FOR READ OPERATION
2027 025322 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
025326 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
  
```

```

;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 24$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TS!PRP SUBROUTINE
;GO TO 37$ IF ERROR

025330 000404 BR 24$
025332 000240 NOP
025334 104000 EMT
025336 000137 025720 JMP 37$
2028 025342 24$:
2029
2030 ;READ DATA FROM DEVICE
2031 025342 25$:
2032 025342 012737 000071 001412 MOV #RD!GO,RMCS10 ;READ DATA COMMAND
2033 025350 012737 105264 001416 MOV #BUFTWO+4,RMBA0 ;LOAD STARTING BUFFER ADDRESS
2034 025356 012702 001555 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
2035 025362 112722 000006 MOVB #RMDA,(R2)+
2036 025366 112722 000032 MOVB #RMOF,(R2)+
2037 025372 112722 000034 MOVB #RMDC,(R2)+
2038 025376 112722 000004 MOVB #RMBA,(R2)+
2039 025402 112722 000002 MOVB #RMWC,(R2)+
2040 025406 112722 000000 MOVB #RMCS1,(R2)+
2041 025412 112712 000200 MOVB #200,(R2)
2042
2043 025416 004737 040360 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
025422 000404 BR 26$ ;GO TO 26$ IF NO ERROR
025424 000240 NOP ;RETURN HERE IF ERROR
025426 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
025430 000137 025720 JMP 37$ ;GO TO 37$ IF ERROR
2044 025434 26$:
2045
2046 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
025434 004737 040024 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
2047
2048 ;WAIT FOR COMMAND TO COMPLETE
025440 004737 040732 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
2049
2050 ;GO READ STATUS FOR READ OPERATION
2051 025444 004737 040110 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
025450 000404 BR 27$ ;GO TO 27$ IF NO ERROR
025452 000240 NOP ;RETURN HERE IF ERROR
025454 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
025456 000137 025720 JMP 37$ ;GO TO 37$ IF ERROR
2052 025462 27$:
2053
2054 ;CHECK FOR ERRORS DURING READ OPERATION
2055 025462 004737 041126 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
025466 000405 BR 28$ ;GO TO 28$ IF NO ERROR
025470 000240 NOP ;RETURN HERE IF ERROR
025472 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
025474 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
025476 000137 025720 JMP 37$ ;GO TO 37$ IF ERROR
2056 025502 005037 001140 28$: CLR $GDDAT ;EXPECTED STATUS
2057
2058 025506 032737 000220 001352 BIT #HCE!FER,RMER1 ;ANY ERROR ?
2059 025514 001407 BEQ 29$ ;NO!!
2060 025516 013737 001352 001142 MOV RMER1,$BDDAT ;RECEIVED STATUS
2061 025524 042737 177557 001142 BIC #^C<HCE!FER>,$BDDAT ;CLEAR DONT CARES

```

```

2062 025532 000412 BR 30$
2063 025534 29$:
2064 025534 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
2065 025542 032737 100000 001400 BIT #BSE,RMER2I ;ANY BAD SECTOR ERROR ?
2066 025550 001406 BEQ 31$ ;NO !!
2067 025552 042737 077777 001142 BIC #^CBSE,$BDDAT ;CLEAR DONT CARES
2068 025560 30$:
2069 025560 104346 EMT 346
2070 025562 000137 025720 JMP 37$
2071 025566 31$:
2072 025566 032737 000040 001400 BIT #SSE,RMER2I ;ANY SKIP SECTOR ERROR ?
2073 025574 001406 BEQ 32$ ;NO !!
2074 025576 043737 177737 001142 BIC ^CSSE,$BDDAT ;SAVE SSE FOR ERROR
2075 025604 104227 EMT 227
2076 025606 000137 025720 JMP 37$
2077 025612 32$:
2078 025612 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
025616 000405 BR 33$ ;GO TO 33$ IF NO ERROR
025620 000240 NOP ;RETURN HERE IF ERROR
025622 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
025624 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
025626 000137 025720 JMP 37$ ;GO TO 37$ IF ERROR
2079 025632 33$:
2080 025632 004737 041760 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
025636 000405 BR 34$ ;GO TO 34$ IF NO ERROR
025640 000240 NOP ;RETURN HERE IF ERROR
025642 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
025644 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
025646 000137 025720 JMP 37$ ;GO TO 37$ IF ERROR
2081 025652 34$:
2082 025652 004737 037462 JSR PC,CMPBUF ;GO COMPARE WRITE, READ DATA BUFFERS
025656 104260 .WORD BUFOFF+4 ;STARTING ADDRESS OF WRITE BUFFER
025660 105264 .WORD BUFTWO+4 ;STARTING ADDRESS OF READ BUFFER
025662 000404 BR 35$ ;GO TO 35$ IF NO ERROR
025664 000240 NOP ;RETURN HERE IF ERROR
025666 104000 EMT ;ERROR # DEFINED BY CMPBUF SUBROUTINE
025670 000137 025720 JMP 37$ ;GO TO 37$ IF ERROR
2083 025674 35$:
2084
2085 025674 006303 ASL R3 ;SHIFT HCE BIT
2086 025676 001006 BNE 36$ ;CONTINUE IF NOT DONE
2087 025700 005704 TST R4 ;SECOND HEADER DONE??
2088 025702 001006 BNE 37$ ;YES!!
2089 025704 012703 000001 MOV #1,R3 ;START WITH BIT 0
2090 025710 012704 000002 MOV #2,R4 ;DO SECOND HEADER WORD
2091 025714 36$:
2092 025714 000137 024454 JMP 2$
2093 025720 37$:
2094
2095 025720 38$:
2096
2097

```

```

*****
;*TEST 16 WRITE, READ W/ IVC ERROR
*****
TST16:
SCOPE ;SCOPE CALL
NOP ;START OF TEST

```

```

025720
025720 000004
025722 000240

```

T16 WRITE, READ W/ IVC ERROR

```

025724 012706 001100      MOV      #STACK,SP      ;INITIALIZE STACK POINTER
025730 013700 001276      MOV      $BASE,R0       ;R0 = UNIBUS ADDRESS
025734 013701 001466      MOV      TSTQUE,R1      ;(R1) = DEVICE BEING TESTED
025740 012737 000016 001226  MOV      #16,$TESTN     ;;SET TEST NUMBER IN APT MAIL BOX

2098
2099      ;*****
2100      ;LOOP #1      WRITE,READ
2101
2102      ;LOAD PARAMETERS AND GENERATE DATA BUFFER
2103 1$:
2104 025746      MOV      #559.,RMDCO     ;CYLINDER = 559.
2105 025746 012737 001057 001446  MOV      #TA2,RMDAO     ;TRACK = 2, SECTOR = 0
2106 025754 012737 001000 001420  MOV      #BUFONE,RMBAD  ;BUS ADDRESS
2107 025762 012737 104254 001416  MOV      #-256.,RMWCO   ;256. WORDS (2'S COMP)
2108 025770 012737 177400 001414  MOV      #FMT16,RMOFO   ;16 BIT FORMAT
2109 025776 012737 010000 001444  MOV      #WD,RMCS10     ;WRITE HEADER AND DATA COMMAND
2110
2111      ;VERIFY THAT SECTOR IS NOT BAD
026012 004737 034762      JSR      PC,BADSCT      ;CALL BAD SECTOR MODULE
026016 000405      BR       2$            ;GO TO 2$ IF NO ERROR
026020 104401 066006      TYPE    .SCTMSG        ;TYPE BAD SECTOR MESSAGE
026024 104000      EMT                      ;ERROR # DEFINED BY BADSCT SUBROUTINE
026026 000137 026740      JMP     22$           ;GO TO 22$ IF ERROR

2112 2$:
2113 026032 012737 001420 001174  MOV      #RMDAO,$TMP0   ;USE SECTOR FOR DATA PATTERN
2114 026040 012737 000001 001176  MOV      #1,$TMP1
2115 026046 004737 037214      JSR      PC,GENBUF     ;GO GENERATE DATA BUFFER
2116
2117      ;PREPARE DEVICE FOR WRITE OPERATION
2118 026052 004737 034032      JSR      PC,TSTPRP     ;PREPARE DEVICE FOR TEST
026056 154130      .WORD   154130        ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
026060 000404      BR       3$            ;GO TO 3$ IF NO ERROR
026062 000240      NOP                      ;RETURN HERE IF ERROR
026064 104000      EMT                      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
026066 000137 026740      JMP     22$           ;GO TO 22$ IF ERROR

2119 3$:
2120
2121      ;RESET VOLUME VALID
2122 026072 112737 000024 001555  MOVB    #RMMR1,PUTINX   ;SETUP PUT INDEX TABLE
026100 112737 000200 001556  MOVB    #200,PUTINX+1  ;SET TERMINATOR BYTE
026106 012737 000001 001436  MOV     #DMD,RMMR1O     ;SET RMMR1 OUTPUT BUFFER = DMD
026114 004737 040360      JSR     PC,PUT         ;GO WRITE RMMR1 VIA PUT SUBROUTINE
026120 000404      BR     4$            ;GO TO 4$ IF NO ERROR
026122 000240      NOP                      ;RETURN HERE IF ERROR
026124 104000      EMT                      ;ERROR DEFINED BY PUT SUBROUTINE
026126 000137 026740      JMP     22$           ;GO TO 22$ IF ERROR

2123 4$:
2124
2125      ;SETUP PARAMETERS AND EXECUTE WRITE DATA COMMAND
2126 026132 5$:

```

```

2127 026132 012737 000061 001412      MOV      #WD!GO,RMCS10      ;WRITE DATA COMMAND
2128 026140 012737 000000 001436      MOV      #0,RMMR10        ;RESET DIAGNOSTIC MODE
2129 026146 012702 001555                MOV      #PUTINX,R2       ;LOAD PUT REGISTER INDEX TABLE
2130 026152 112722 000024                MOV      #RMMR1,(R2)+
2131 026156 112722 000006                MOV      #RMDA,(R2)+
2132 026162 112722 000034                MOV      #RMDC,(R2)+
2133 026166 112722 000032                MOV      #RMOF,(R2)+
2134 026172 112722 000002                MOV      #RMVC,(R2)+
2135 026176 112722 000004                MOV      #RMB A,(R2)+
2136 026202 112722 000000                MOV      #RMCS1,(R2)+
2137 026206 112722 000200                MOV      #200,(R2)+      ;TERMINATE TABLE
2138
2139 026212 004737 040360                JSR      PC,PUT           ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      026216 000404                BR       6$             ;GO TO 6$ IF NO ERROR
      026220 000240                NOP                    ;RETURN HERE IF ERROR
      026222 104000                EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      026224 000137 026740                JMP      22$            ;GO TO 22$ IF ERROR
2140 026230
2141
2142                                ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR      PC,GETSTS      ;GO TO GETSTS SUBROUTINE
2143
2144                                ;WAIT FOR COMMAND TO COMPLETE
      JSR      PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
2145
2146                                ;GO READ STATUS FOR WRITE COMMAND
2147 026240 004737 040110                JSR      PC,GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
      026244 000404                BR       7$             ;GO TO 7$ IF NO ERROR
      026246 000240                NOP                    ;RETURN HERE IF ERROR
      026250 104000                EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      026252 000137 026740                JMP      22$            ;GO TO 22$ IF ERROR
2148 026256
2149
2150                                ;CHECK FOR ERRORS DURING WRITE OPERATION
2151 026256 004737 041126                JSR      PC,PRIERR        ;GO CHECK FOR PRIMARY ERRORS
      026262 000405                BR       8$             ;GO TO 8$ IF NO ERROR
      026264 000240                NOP                    ;RETURN HERE IF ERROR
      026266 104000                EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      026270 004736                JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      026272 000137 026740                JMP      22$            ;GO TO 22$ IF ERROR
2152 026276
2153 026276 032737 010000 001400          8$:      BIT      #IVC,RMER2I      ;WAS "IVC" DETECTED??
2154 026304 001024                BNE      10$            ;YES!!
2155
2156 026306 004737 054166                JSR      PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
      026312 000405                BR       9$             ;GO TO 9$ IF NO ERROR
      026314 000240                NOP                    ;RETURN HERE IF ERROR
      026316 104000                EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      026320 004736                JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      026322 000137 026740                JMP      22$            ;GO TO 22$ IF ERROR
2157 026326
2158 026326 013737 001400 001142          9$:      MOV      RMER2I,$BDDAT      ;RECEIVED STATUS
2159 026334 013737 001400 001140          MOV      RMER2I,$GDDAT    ;EXPECTED STATUS
2160 026342 052737 010000 001140          BIS      #IVC,$GDDAT
2161 026350 104342                EMT      342
2162 026352 000137 026740                JMP      22$
2163 026356          10$:
    
```

```

116 WRITE, READ W/ IVC ERROR
2164 026356 004737 041760 JSR PC, SECERR ;GO CHECK FOR SECONDARY ERRORS
      026362 00C405 BR 11$ ;GO TO 11$ IF NO ERROR
      026364 000240 NOP ;RETURN HERE IF ERROR
      026366 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
      026370 004736 JSR PC, @ (SP)+ ;GO BACK FOR MORE ERROR CHECKS
      026372 000137 026740 JMP 22$ ;GO TO 22$ IF ERROR
2165 026376 11$:
2166
2167
2168 026376 012737 026406 001124 ;CHANGE LOOP ADDRESSES
2169 026404 000410 MOV #12$, $LPERR
      BR 13$
2170
2171
2172 ;*****
2173 ;LOOP #2 READ
2174 026406 12$:
2175
2176 ;PREPARE DEVICE FOR READ OPERATION
2177 026406 004737 034032 JSR PC, TSTPRP ;PREPARE DEVICE FOR TEST
      026412 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 13$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 22$ IF ERROR
      BR 13$
      026414 000404 BR 13$
      026416 000240 NOP
      026420 104000 EMT
      026422 000137 026740 JMP 22$
2178 026426 13$:
2179
2180 ;RESET VOLUME VALID
2181 026426 112737 000024 001555 MOV #RMMR1, PUTINX ;SETUP PUT INDEX TABLE
      026434 112737 000200 001556 MOV #200, PUTINX+1 ;SET TERMINATOR BYTE
      026442 012737 000001 001436 MOV #DMD, RMMR10 ;SET RMMR1 OUTPUT BUFFER = DMD
      026450 004737 040360 JSR PC, PUT ;GO WRITE RMMR1 VIA PUT SUBROUTINE
      026454 000404 BR 14$ ;GO TO 14$ IF NO ERROR
      026456 000240 NOP ;RETURN HERE IF ERROR
      026460 104000 EMT ;ERROR DEFINED BY PUT SUBROUTINE
      026462 000137 026740 JMP 22$ ;GO TO 22$ IF ERROR
2182 026466 14$:
2183
2184 ;READ DATA FROM DEVICE
2185 026466 15$:
2186 026466 012737 000011 001412 MOV #RD!GO, RMCS10 ;READ DATA COMMAND
2187 026474 012737 105260 001416 MOV #BUFTWO, RMBAC ;LOAD STARTING BUFFER ADDRESS
2188 026502 012737 000000 001436 MOV #0, RMMR10 ;RESET DIAGNOSTIC MODE
2189 026510 012702 001555 MOV #PUTINX, R2 ;LOAD PUT REGISTER INDEX TABLE
2190 026514 112722 000024 MOV #RMMR1, (R2)+
2191 026520 112722 000006 MOV #RMDA, (R2)+
2192 026524 112722 000032 MOV #RMOF, (R2)+
2193 026530 112722 000034 MOV #RMDC, (R2)+
2194 026534 112722 000004 MOV #RMBAC, (R2)+
2195 026540 112722 000002 MOV #RMWC, (R2)+
2196 026544 112722 000000 MOV #RMCS1, (R2)+

```



```

116 WRITE, READ W/ IVC ERROR
2197 026550 112712 000200      MOVB    #200,(R2)
2198
2199 026554 004737 040360      JSR     PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      026560 000404      BR      16$        ;GO TO 16$ IF NO ERROR
      026562 000240      NOP
      026564 104000      EMT
      026566 000137 026740      JMP     22$        ;ERROR # DEFINED BY PUT SUBROUTINE
                        ;GO TO 22$ IF ERROR
2200 026572      16$:
2201
2202      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR     PC,GETSTS ;GO TO GETSTS SUBROUTINE
2203
2204      ;WAIT FOR COMMAND TO COMPLETE
      JSR     PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
2205
2206      ;GO READ STATUS FOR READ OPERATION
2207 026602 004737 040110      JSR     PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      026606 000404      BR      17$        ;GO TO 17$ IF NO ERROR
      026610 000240      NOP
      026612 104000      EMT
      026614 000137 026740      JMP     22$        ;ERROR # DEFINED BY GET SUBROUTINE
                        ;GO TO 22$ IF ERROR
2208 026620      17$:
2209
2210      ;CHECK FOR ERRORS DURING READ OPERATION
2211 026620 004737 041126      JSR     PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      026624 000405      BR      18$        ;GO TO 18$ IF NO ERROR
      026626 000240      NOP
      026630 104000      EMT
      026632 004736      JSR     PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      026634 000137 026740      JMP     22$        ;GO TO 22$ IF ERROR
2212 026640      18$:
2213 026640 032737 010000 001400  BIT     #IVC,RMER2I ;WAS "IVC" DETECTED??
2214 026646 001024      BNE    20$        ;YES!!
2215
2216 026650 004737 054166      JSR     PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      026654 000405      BR      19$        ;GO TO 19$ IF NO ERROR
      026656 000240      NOP
      026660 104000      EMT
      026662 004736      JSR     PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      026664 000137 026740      JMP     22$        ;GO TO 22$ IF ERROR
2217 026670      19$:
2218 026670 013737 001400 001140  MOV     RMER2I,$GDDAT ;EXPECTED STATUS
2219 026676 052737 010000 001140  BIS     #IVC,$GDDAT
2220 026704 013737 001400 001142  MOV     RMER2I,$BDDAT ;RECEIVED STATUS
2221 026712 104342      EMT
2222 026714 000137 026740      JMP     22$
2223 026720      20$:
2224 026720 004737 041760      JSR     PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
      026724 000405      BR      21$        ;GO TO 21$ IF NO ERROR
      026726 000240      NOP
      026730 104000      EMT
      026732 004736      JSR     PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      026734 000137 026740      JMP     22$        ;GO TO 22$ IF ERROR
2225 026740      21$:
2226
2227 026740      22$:
2228

```

2229

 :TEST 17 WRITE, READ W/ ABORT

TST17:
 SCOPE :SCOPE CALL
 NOP :START OF TEST
 MOV #STACK,SP :INITIALIZE STACK POINTER
 MOV \$BASE,R0 :R0 = UNIBUS ADDRESS
 MOV TSTQUE,R1 :(R1) = DEVICE BEING TESTED
 MOV #17,\$TESTN ;;SET TEST NUMBER IN APT MAIL BOX

2230

 :LOOP #1 WRITE,READ

2231

2232

2233

2234

2235

2236

2237

2238

2239

2240

2241

2242

2243

2244

:LOAD PARAMETERS AND GENERATE DATA BUFFER
 MOV #559.,RMDCO :CYLINDER = 559.
 MOV #TA2,RMDAO :TRACK = 2, SECTOR = 0
 MOV #BUFONE,RMBAO :BUS ADDRESS
 MOV #-256.,RMCWO :256. WORDS (2'S COMP)
 MOV #FMT16,RMFOFO :16 BIT FORMAT
 MOV #WD!GO,RMCS10 :WRITE DATA COMMAND

1\$:

:PREPARE DEVICE FOR WRITE OPERATION
 JSR PC,TSTPRP :PREPARE DEVICE FOR TEST
 .WORD 154130 :TASK DESCRIPTOR AS FOLLOWS:
 :SELECT DEVICE & VERIFY DEVICE AVAILABLE
 :CLEAR CONTROLLER & SELECT DEVICE
 :VERIFY CONTROLLER CLEAR OPERATION
 :PACK ACKNOWLEDGE IF VOLUME NOT VALID
 :VERIFY PACK ACKNOWLEDGE
 :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
 :VERIFY RECALIBRATION
 :GO TO 2\$ IF NO ERROR
 :RETURN HERE IF ERROR
 :ERROR # DEFINED BY TSTPRP SUBROUTINE
 :GO TO 21\$ IF ERROR

2\$:

:SET UNSAFE ERROR
 MOV #RMER1,PUTINX :SETUP PUT INDEX TABLE
 MOV #200,PUTINX+1 :SET TERMINATOR BYTE
 MOV #UNS,RMER10 :SET RMER1 OUTPUT BUFFER = UNS
 JSR PC,PUT :GO WRITE RMER1 VIA PUT SUBROUTINE
 BR 3\$:GO TO 3\$ IF NO ERROR
 NOP :RETURN HERE IF ERROR
 EMT :ERROR DEFINED BY PUT SUBROUTINE
 JMP 21\$:GO TO 21\$ IF ERROR

3\$:

:WRITE DATA TO THE DRIVE
 4\$:
 MOV #WD!GO,RMCS10 :WRITE DATA COMMAND
 MOV #PUTINX,R2 :LOAD PUT REGISTER INDEX TABLE
 MOV #RMDA,(R2)+
 MOV #RMDC,(R2)+
 MOV #RMOF,(R2)+

027040

027042

027044

027046

2245

2246

2247

2248

027060

027066

027074

027100

027102

027104

027106

2249

2250

2251

2252

2253

2254

2255

2256

2257

026740 000094
 026742 000240
 026744 012706 001100
 026750 013700 001276
 026754 013701 001466
 026760 012737 000017 001226

026766 012737 001057 001446
 026774 012737 001000 001420
 027002 012737 104254 001416
 027010 012737 177400 001414
 027016 012737 010000 001444
 027024 012737 000061 001412

027032 004737 034032
 027036 154130

027040 000404
 027042 000240
 027044 104000
 027046 000137 027656

027052 112737 000014 001555
 027060 112737 000200 001556
 027066 012737 040000 001426
 027074 004737 040360
 027100 000404
 027102 000240
 027104 104000
 027106 000137 027656

027112
 027112 012737 000061 001412
 027120 012702 001555
 027124 112722 000006
 027130 112722 000034
 027134 112722 000032

```

117 WRITE, READ W/ ABORT
2258 027140 112722 000004      MOVB  #RMB, (R2)+
2259 027144 112722 000002      MOVB  #RMWC, (R2)+
2260 027150 112722 000000      MOVB  #RMC1, (R2)+
2261 027154 112722 000200      MOVB  #200, (R2)+
2262
2263 027160 004737 040360      JSR   PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      027164 000404      BR    5$          ;GO TO 5$ IF NO ERROR
      027166 000240      NOP                    ;RETURN HERE IF ERROR
      027170 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      027172 000137 027656      JMP   21$         ;GO TO 21$ IF ERROR
2264 027176
2265
2266      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR   PC,GETSTS ;GO TO GETSTS SUBROUTINE
2267
2268
2269 027202 004737 040110      ;GO GET REGISTER STATUS
      JSR   PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      BR    6$          ;GO TO 6$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      JMP   21$         ;GO TO 21$ IF ERROR
2270 027220
2271 027220 032737 020000 001350 6$:      BIT   #PIP,RMDSI    ;WAS COMMAND EXECUTED?
2272 027226 001412      BEQ   7$          ;NO, GO WAIT
2273 027230 013737 001350 001140      MOV   RMDSI,$GDDAT ;EXPECTED STATUS
2274 027236 042737 020000 001140      BIC   #PIP,$GDDAT
2275 027244 013737 001350 001142      MOV   RMDSI,$BDDAT ;RECEIVED STATUS
2276 027252 104347      EMT   347
2277 027254
2278
2279      ;WAIT FOR COMMAND TO COMPLETE
      JSR   PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
2280
2281
2282 027260 004737 040110      ;GO GET REGISTER STATUS
      JSR   PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      BR    8$          ;GO TO 8$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      JMP   21$         ;GO TO 21$ IF ERROR
2283 027276
2284 027276 004737 041126      8$:      JSR   PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
      BR    9$          ;GO TO 9$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      JSR   PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      JMP   21$         ;GO TO 21$ IF ERROR
2285 027316
2286 027316 004737 041760      9$:      JSR   PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
      BR    10$         ;GO TO 10$ IF NO ERROR
      NOP                    ;RETURN HERE IF ERROR
      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      JSR   PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      JMP   21$         ;GO TO 21$ IF ERROR
2287 027336
2288
2289
2290 027336 012737 027346 001124 ;CHANGE LOOP ADDRESSES
      MOV   #11,$LPERR

```

```

2291 027344 000410          BR      12$
2292
2293          ;*****
2294          ;LOOP #2          READ
2295
2296 027346          11$:
2297
2298          ;PREPARE DEVICE FOR READ OPERATION
2299 027346 004737 034032      JSR      PC,TSTPRP      ;PREPARE DEVICE FOR TEST
          027352 154130      .WORD    154130      ;TASK DESCRIPTOR AS FOLLOWS:
          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
          ;CLEAR CONTROLLER & SELECT DEVICE
          ;VERIFY CONTROLLER CLEAR OPERATION
          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
          ;VERIFY PACK ACKNOWLEDGE
          ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
          ;VERIFY RECALIBRATION
          ;GO TO 12$ IF NO ERROR
          ;RETURN HERE IF ERROR
          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
          ;GO TO 21$ IF ERROR

          027354 000404          BR      12$
          027356 000240          NOP
          027360 104000          EMT
          027362 000137 027656      JMP      21$
2300 027366          12$:
2301
2302          ;SET UNSAFE ERROR
2303 027366 112737 000014 001555      MOVB     #RMER1,PUTINX      ;SETUP PUT INDEX TABLE
          027374 112737 000200 001556      MOVB     #200,PUTINX+1      ;SET TERMINATOR BYTE
          027402 012737 040000 001426      MOV      #UNS,RMER10      ;SET RMER1 OUTPUT BUFFER = UNS
          027410 004737 040360      JSR      PC,PUT          ;GO WRITE RMER1 VIA PUT SUBROUTINE
          027414 000404          BR      13$              ;GO TO 13$ IF NO ERROR
          027416 000240          NOP                      ;RETURN HERE IF ERROR
          027420 104000          EMT                      ;ERROR DEFINED BY PUT SUBROUTINE
          027422 000137 027656      JMP      21$              ;GO TO 21$ IF ERROR
2304 027426          13$:
2305
2306          ;READ DATA FROM DEVICE
2307 027426          14$:
2308 027426 012737 000071 001412      MOV      #RD!GO,RMCS10      ;READ DATA COMMAND
          027434 012702 001555          MOV      #PUTINX,R2        ;LOAD PUT REGISTER INDEX TABLE
          027440 112722 000006          MOVB     #RMDA,(R2)+
          027444 112722 000032          MOVB     #RMOF,(R2)+
          027450 112722 000034          MOVB     #RMDC,(R2)+
          027454 112722 000004          MOVB     #RMDA,(R2)+
          027460 112722 000002          MOVB     #RMWC,(R2)+
          027464 112722 000000          MOVB     #RMCS1,(R2)+
          027470 112712 000200          MOVB     #200,(R2)
2317
2318 027474 004737 040360      JSR      PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
          027500 000404          BR      15$              ;GO TO 15$ IF NO ERROR
          027502 000240          NOP                      ;RETURN HERE IF ERROR
          027504 104000          EMT                      ;ERROR # DEFINED BY PUT SUBROUTINE
          027506 000137 027656      JMP      21$              ;GO TO 21$ IF ERROR
2319 027512          15$:
2320
2321          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
          027512 004737 040024      JSR      PC,GETSTS      ;GO TO GETSTS SUBROUTINE
2322
2323          ;SEE IF DEVICE STARTED COMMAND
  
```

```

2324 027516 004737 040110      JSR    PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      027522 000404      BR     16$        ;GO TO 16$ IF NO ERROR
      027524 000240      NOP                    ;RETURN HERE IF ERROR
      027526 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      027530 000137 027656      JMP    21$        ;GO TO 21$ IF ERROR
2325 027534      16$:
2326 027534 032737 020000 001350      BIT    #PIP,RMSI    ;WAS COMMAND EXECUTED??
2327 027542 001414      BEQ    17$        ;NO!!
2328 027544 013737 001350 001140      MOV    RMSI,$GDDAT ;EXPECTED STATUS
2329 027552 042737 020000 001140      BIC    #PIP,$GDDAT
2330 027560 013737 001350 001142      MOV    RMSI,$BDDAT ;RECEIVED STATUS
2331 027566 104347      EMT    347
2332 027570 000137 027656      JMP    21$
2333 027574      17$:
2334
2335      ;WAIT FOR COMMAND TO COMPLETE
      JSR    PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
2336 027574 004737 040732
2337      ;GO READ STATUS FOR READ OPERATION
2338 027600 004737 040110      JSR    PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      027604 000404      BR     18$        ;GO TO 18$ IF NO ERROR
      027606 000240      NOP                    ;RETURN HERE IF ERROR
      027610 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      027612 000137 027656      JMP    21$        ;GO TO 21$ IF ERROR
2339 027616      18$:
2340 027616 004737 041126      JSR    PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      027622 000405      BR     19$        ;GO TO 19$ IF NO ERROR
      027624 000240      NOP                    ;RETURN HERE IF ERROR
      027626 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      027630 004736      JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      027632 000137 027656      JMP    21$        ;GO TO 21$ IF ERROR
2341 027636      19$:
2342 027636 004737 041760      JSR    PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
      027642 000405      BR     20$        ;GO TO 20$ IF NO ERROR
      027644 000240      NOP                    ;RETURN HERE IF ERROR
      027646 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      027650 004736      JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      027652 000137 027656      JMP    21$        ;GO TO 21$ IF ERROR
2343 027656      20$:
2344
2345 027656      21$:
2346
2347      ;*****
      ;*TEST 20      WRITE, READ EARLY PEAK SHIFT
      ;*****
      TST20:
      027656      000004      MOV    SCOPE        ;SCOPE CALL
      027660 000240      NOP                    ;START OF TEST
      027662 012706 001100      MOV    #STACK,SP    ;INITIALIZE STACK POINTER
      027666 013700 001276      MOV    $BASE,R0     ;R0 = UNIBUS ADDRESS
      027672 013701 001466      MOV    TSTQUE,R1    ;(R1) = DEVICE BEING TESTED
      027676 012737 000020 001226      MOV    #20,$TESTN   ;SET TEST NUMBER IN APT MAIL BOX
2348
2349
2350      ;*****
      ;LOOP #1      FORMAT,WRITE,READ
2351
2352 027704      1$:
  
```

```

2353
2354
2355 027704 004737 034032      ;PREPARE THE DEVICE FOR FORMAT OPERATION
                                JSR   PC,TSTPRP      ;PREPARE DEVICE FOR TEST
                                .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
                                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                                ;CLEAR CONTROLLER & SELECT DEVICE
                                                ;VERIFY CONTROLLER CLEAR OPERATION
                                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                                ;VERIFY PACK ACKNOWLEDGE
                                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                                ;VERIFY RECALIBRATION
                                                ;GO TO 2$ IF NO ERROR
                                                ;RETURN HERE IF ERROR
                                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                                ;GO TO 25$ IF ERROR
                                BR    2$
                                NOP
                                EMT
                                JMP   25$
2356 027712 000404      BR    2$
2357 027714 000240      NOP
2358 027716 104000      EMT
2359 027720 000137 030664      JMP   25$
2360 027724      2$:
2361 027724 012737 001057 001446      ;LOAD PARAMETERS AND GENERATE DATA BUFFER
                                MOV   #559,RMDCO      ;CYLINDER = 559.
                                MOV   #TA2,RMDAO      ;TRACK = 2, SECTOR = 0
                                MOV   #BUFONE,RMBAO    ;BUS ADDRESS
                                MOV   #-258,RMWCO     ;2 + 256. WORDS (2'S COMP)
                                MOV   #FMT16,RMOFO    ;16 BIT FORMAT
                                MOV   #WH!GO,RMCS10    ;WRITE HEADER AND DATA COMMAND
2362 027732 012737 001000 001420
2363 027740 012737 104254 001416
2364 027746 012737 177376 001414
2365 027754 012737 010000 001444
2366 027762 012737 000063 001412
2367 027770 004737 034762      ;VERIFY THAT SECTOR IS NOT BAD
                                JSR   PC,BADSCT      ;CALL BAD SECTOR MODULE
                                BR    3$            ;GO TO 3$ IF NO ERROR
                                TYPE  ,SCTMSG        ;TYPE BAD SECTOR MESSAGE
                                EMT
                                JMP   25$         ;ERROR # DEFINED BY BADSCT SUBROUTINE
                                                ;GO TO 25$ IF ERROR
2368 027774 000405      BR    3$
2369 027776 104401 066006      TYPE  ,SCTMSG
2370 030002 104000      EMT
2371 030004 000137 030664      JMP   25$
2372 030010      3$:
2373 030010 012737 067670 001174      MOV   #EARLY,$TMP0      ;STARTING ADDRESS OF PATTERN
2374 030016 012737 000001 001176      MOV   #1,$TMP1        ;RANGE OF PATTERN
2375 030024 004737 037214      JSR   PC,GENBUF        ;GO GENERATE BUFFER FOR FORMAT
2376 030030      ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
                                MOV   #PUTINX,R2      ;R2 = BYTE ENTRY POSITION
                                MOV   #RMDC,(R2)+
                                MOV   #RMDA,(R2)+
                                MOV   #RMBA,(R2)+
                                MOV   #RMWC,(R2)+
                                MOV   #RMOF,(R2)+
                                MOV   #RMCS1,(R2)+
                                MOV   #200,(R2)
2377 030034 112722 000034
2378 030040 112722 000006
2379 030044 112722 000004
2380 030050 112722 000002
2381 030054 112722 000032
2382 030060 112722 000000
2383 030064 112712 000200      ;TERMINATE TABLE
2384 030070      4$:
2385 030070 004737 040360      JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
2386 030074 000404      BR    5$            ;GO TO 5$ IF NO ERROR
2387 030076 000240      NOP
2388 030100 104000      EMT
2389 030102 000137 030664      JMP   25$         ;ERROR # DEFINED BY PUT SUBROUTINE
                                                ;GO TO 25$ IF ERROR
2390 030106      5$:
2391 030106 004737 040024      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
                                JSR   PC,GETSTS      ;GO TO GETSTS SUBROUTINE
2392
2393
2394
2395
2396
2397
    ;WAIT FOR COMMAND TO COMPLETE
    
```

```

2388 030112 004737 040732          JSR    PC,TIMOUT          ;GO TO TIMEOUT SUBROUTINE
2389                                     ;GO READ STATUS FOR FORMAT OPERATION
2390 030116 004737 040110          JSR    PC,GET              ;GO READ REGISTER(S) WITH GET SUBROUTINE
030122 000404                      BR     6$                 ;GO TO 6$ IF NO ERROR
030124 000240                      NOP                    ;RETURN HERE IF ERROR
030126 104000                      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
030130 000137 030664          JMP    25$                 ;GO TO 25$ IF ERROR
2391 030134          6$:
2392
2393                                     ;VERIFY NO ERRORS DURING FORMAT
2394 030134 004737 054166          JSR    PC,DTASTS          ;GO VERIFY RESULTS OF DATA TRANSFER
030140 000405                      BR     7$                 ;GO TO 7$ IF NO ERROR
030142 000240                      NOP                    ;RETURN HERE IF ERROR
030144 104000                      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
030146 004736                      JSR    PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
030150 000137 030664          JMP    25$                 ;GO TO 25$ IF ERROR
2395 030154          7$:
2396
2397                                     ;MOVE LOOP ADDRESSES TO NEXT OPERATION
2398 030154 012737 030164 001124  MOV    #8$,$LPERR
2399 030162 000410                      BR     9$
2400
2401                                     ;*****
2402                                     ;LOOP #2          WRITE,READ
2403
2404 030164          8$:
2405
2406                                     ;PREPARE DEVICE FOR WRITE OPERATION
2407 030164 004737 034032          JSR    PC,TSTPRP          ;PREPARE DEVICE FOR TEST
030170 154130          .WORD 154130          ;TASK DESCRIPTOR AS FOLLOWS:
                                     ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                     ;CLEAR CONTROLLER & SELECT DEVICE
                                     ;VERIFY CONTROLLER CLEAR OPERATION
                                     ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                     ;VERIFY PACK ACKNOWLEDGE
                                     ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                     ;VERIFY RECALIBRATION
030172 000404                      BR     9$                 ;GO TO 9$ IF NO ERROR
030174 000240                      NOP                    ;RETURN HERE IF ERROR
030176 104000                      EMT                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
030200 000137 030664          JMP    25$                 ;GO TO 25$ IF ERROR
2408 030204          9$:
2409
2410                                     ;WRITE DATA TO THE DRIVE
2411 030204          10$:
2412 030204 012737 177400 001414  MOV    #-256.,RMWCO      ;CHANGE WORD COUNT
2413 030212 012737 104260 001416  MOV    #BUFONE+4,RMBAO  ;CHANGE ADDRESS
2414 030220 012737 000061 001412  MOV    #WD!GO,RMCS10    ;WRITE DATA COMMAND
2415 030226 012702 001555          MOV    #PUTINX,R2       ;LOAD PUT REGISTER INDEX TABLE
2416 030232 112722 000006          MOVB  #RMDA,(R2)+
2417 030236 112722 000034          MOVB  #RMDC,(R2)+
2418 030242 112722 000032          MOVB  #RMOF,(R2)+
2419 030246 112722 000004          MOVB  #RMBA,(R2)+
2420 030252 112722 000002          MOVB  #RMWC,(R2)+
2421 030256 112722 000000          MOVB  #RMCS1,(R2)+
2422 030262 112722 000200          MOVB  #200,(R2)+          ;TERMINATE TABLE
    
```

```

2423
2424 030266 004737 040360      JSR    PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      030272 000404          BR     11$            ;GO TO 11$ IF NO ERROR
      030274 000240          NOP                    ;RETURN HERE IF ERROR
      030276 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      030300 000137 030664      JMP    25$            ;GO TO 25$ IF ERROR
2425 030304          11$:
2426
2427          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      030304 004737 040024      JSR    PC,GETSTS      ;GO TO GETSTS SUBROUTINE
2428
2429          ;WAIT FOR COMMAND TO COMPLETE
      030310 004737 040732      JSR    PC,TIMOUT     ;GO TO TIMEOUT SUBROUTINE
2430
2431          ;GO READ STATUS FOR WRITE COMMAND
2432 030314 004737 040110      JSR    PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      030320 000404          BR     12$            ;GO TO 12$ IF NO ERROR
      030322 000240          NOP                    ;RETURN HERE IF ERROR
      030324 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      030326 000137 030664      JMP    25$            ;GO TO 25$ IF ERROR
2433 030332          12$:
2434
2435          ;CHECK FOR ERRORS DURING WRITE OPERATION
2436 030332 004737 041126      JSR    PC,PRIERR     ;GO CHECK FOR PRIMARY ERRORS
      030336 000405          BR     13$            ;GO TO 13$ IF NO ERROR
      030340 000240          NOP                    ;RETURN HERE IF ERROR
      030342 104000          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      030344 004736          JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      030346 000137 030664      JMP    25$            ;GO TO 25$ IF ERROR
2437 030352          13$:
2438 030352 004737 054166      JSR    PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      030356 000405          BR     14$            ;GO TO 14$ IF NO ERROR
      030360 000240          NOP                    ;RETURN HERE IF ERROR
      030362 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      030364 004736          JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      030366 000137 030664      JMP    25$            ;GO TO 25$ IF ERROR
2439 030372          14$:
2440 030372 004737 041760      JSR    PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      030376 000405          BR     15$            ;GO TO 15$ IF NO ERROR
      030400 000240          NOP                    ;RETURN HERE IF ERROR
      030402 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      030404 004736          JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      030406 000137 030664      JMP    25$            ;GO TO 25$ IF ERROR
2441 030412          15$:
2442
2443          ;CHANGE LOOP ADDRESSES
2444 030412 012737 030422 001124  MOV    #16$,$LPERR
2445 030420 000410          BR     17$
2446
2447          ;*****
2448          ;LOOP #3      READ
2449
2450 030422          16$:
2451
2452          ;PREPARE DEVICE FOR READ OPERATION
2453 030422 004737 034032      JSR    PC,TSTPRP    ;PREPARE DEVICE FOR TEST
      030426 154130          .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
  
```



```

                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF "SKI" OR "PIP" IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 17$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 25$ IF ERROR
030430 000404 BR 17$
030432 000240 NOP
030434 104000 EMT
030436 000137 030664 JMP 25$
2454 030442 17$:
2455
2456 ;READ DATA FROM DEVICE
2457 030442 18$:
2458 030442 012737 000071 001412 MOV #RD:GO,RMCS10 ;READ DATA COMMAND
2459 030450 012737 105264 001416 MOV #BUFTWO+4,RMBAO ;CHANGE BUFFER
2460 030456 012702 001555 MOV #PUTINX,R2 ;LOAD PUT REGISTER INDEX TABLE
2461 030462 112722 000006 MOVB #RMDA,(R2)+
2462 030466 112722 000032 MOVB #RMDF,(R2)+
2463 030472 112722 000034 MOVB #RMDC,(R2)+
2464 030476 112722 000004 MOVB #RMBA,(R2)+
2465 030502 112722 000002 MOVB #RMWC,(R2)+
2466 030506 112722 000000 MOVB #RMCS1,(R2)+
2467 030512 112712 000200 MOVB #200,(R2)
2468
2469 030516 004737 040360 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
030522 000404 BR 19$ ;GO TO 19$ IF NO ERROR
030524 000240 NOP ;RETURN HERE IF ERROR
030526 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
030530 000137 030664 JMP 25$ ;GO TO 25$ IF ERROR
2470 030534 19$:
2471
2472 ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
030534 004737 040024 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
2473
2474 ;WAIT FOR COMMAND TO COMPLETE
030540 004737 040732 JSR PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
2475
2476 ;GO READ STATUS FOR READ OPERATION
2477 030544 004737 040110 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
030550 000404 BR 20$ ;GO TO 20$ IF NO ERROR
030552 000240 NOP ;RETURN HERE IF ERROR
030554 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
030556 000137 030664 JMP 25$ ;GO TO 25$ IF ERROR
2478 030562 20$:
2479
2480 ;CHECK FOR ERRORS DURING READ OPERATION
2481 030562 004737 041126 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
030566 000405 BR 21$ ;GO TO 21$ IF NO ERROR
030570 000240 NOP ;RETURN HERE IF ERROR
030572 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
030574 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
030576 000137 030664 JMP 25$ ;GO TO 25$ IF ERROR
2482 030602 21$:
2483 030602 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
030606 000405 BR 22$ ;GO TO 22$ IF NO ERROR
    
```

T20 WRITE, READ EARLY PEAK SHIFT

```

030610 000240      NOP      ;RETURN HERE IF ERROR
030612 104000      EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
030614 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
030616 000137 030664 JMP      25$      ;GO TO 25$ IF ERROR
2484 030622      22$:
2485 030622 004737 041760 JSR      PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
030626 000405      BR      23$      ;GO TO 23$ IF NO ERROR
030630 000240      NOP      ;RETURN HERE IF ERROR
030632 104000      EMT      ;ERROR # DEFINED BY SECERR SUBROUTINE
030634 004736      JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
030636 000137 030664 JMP      25$      ;GO TO 25$ IF ERROR
2486 030642      23$:
2487 030642 004737 037462 JSR      PC,CMPBUF ;GO COMPARE WRITE, READ DATA BUFFERS
030646 104260      .WORD   BUFOFF+4 ;STARTING ADDRESS OF WRITE BUFFER
030650 105264      .WORD   BUFTWO+4 ;STARTING ADDRESS OF READ BUFFER
030652 000404      BR      24$      ;GO TO 24$ IF NO ERROR
030654 000240      NOP      ;RETURN HERE IF ERROR
030656 104000      EMT      ;ERROR # DEFINED BY CMPBUF SUBROUTINE
030660 000137 030664 JMP      25$      ;GO TO 25$ IF ERROR
2488 030664      24$:
2489
2490 030664      25$:
2491
2492
;*****
;*TEST 21      WRITE, READ EACH TRACK W/ MIXED PEAK SHIFT
;*****
TST21:
030664 000004      SCOPE     ;SCOPE CALL
030666 000240      NOP      ;START OF TEST
030670 0127C6 001100 MOV      #STACK,SP ;INITIALIZE STACK POINTER
030674 013700 001276 MOV      $BASE,R0  ;R0 = UNIBUS ADDRESS
030700 013701 001466 MOV      TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
030704 012737 000021 001226 MOV      #21,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
2493
2494
2495 ;*****
2496 ;LOOP #1      FORMAT,WRITE,READ
2497 030712      1$:
2498
2499 ;PREPARE THE DEVICE FOR FORMAT OPERATION
2500 030712 004737 034032 JSR      PC,TSTPRP ;PREPARE DEVICE FOR TEST
030716 154130      .WORD   154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
030720 000404      BR      2$      ;GO TO 2$ IF NO ERROR
030722 000240      NOP      ;RETURN HERE IF ERROR
030724 104000      EMT      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
030726 000137 031712 JMP      26$      ;GO TO 26$ IF ERROR
2501 030732      2$:
2502
2503 ;LOAD PARAMETERS AND GENERATE DATA BUFFER
2504 030732 012737 001060 001446 MOV      #560.,RMDCO ;CYLINDER = 560.

```

```

2505 030740 012737 000000 001420      MOV      #0,RMDAD      ;TRACK = 0, SECTOR = 0
2506 030746      3$:      MOV      #BUFONE,RMBAD      ;BUS ADDRESS
2507 030746 012737 104254 001416      MOV      #-258.,RMWCO      ;2 + 256. WORDS (2'S COMP)
2508 030754 012737 177376 001414      MOV      #FMT16,RMFOFO      ;16 BIT FORMAT
2509 030762 012737 010000 001444      MOV      #WH!GO,RMCS10      ;WRITE HEADER AND DATA COMMAND
2510 030770 012737 000063 001412
2511
2512      ;VERIFY THAT SECTOR IS NOT BAD
      JSR      PC,BADSCT      ;CALL BAD SECTOR MODULE
      BR      4$      ;GO TO 4$ IF NO ERROR
      TYPE      ,SCTMSG      ;TYPE BAD SECTOR MESSAGE
      EMT      ;ERROR # DEFINED BY BADSCT SUBROUTINE
      JMP      26$      ;GO TO 26$ IF ERROR
2513 031016      4$:      MOV      #MIXED,$TMP0      ;STARTING ADDRESS OF PATTERN
2514 031016 012737 067354 001174      MOV      #128.,$TMP1      ;RANGE OF PATTERN
2515 031024 012737 000200 001176      JSR      PC,GENBUF      ;GO GENERATE BUFFER FOR FORMAT
2516 031032 004737 037214
2517
2518      ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
      MOV      #PUTINX,R2      ;R2 = BYTE ENTRY POSITION
2519 031036 012702 001555      MOV      #RMDC,(R2)+
2520 031042 112722 000034      MOV      #RMDA,(R2)+
2521 031046 112722 000006      MOV      #RMBB,(R2)+
2522 031052 112722 000004      MOV      #RMWC,(R2)+
2523 031056 112722 000002      MOV      #RMOF,(R2)+
2524 031062 112722 000032      MOV      #RMCS1,(R2)+
2525 031066 112722 000000      MOV      #200,(R2)      ;TERMINATE TABLE
2526 031072 112712 000200
2527 031076      5$:
2528
2529      ;FORMAT THE DRIVE
      JSR      PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      BR      6$      ;GO TO 6$ IF NO ERROR
      NOP      ;RETURN HERE IF ERROR
      EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
      JMP      26$      ;GO TO 26$ IF ERROR
2530 031076 004737 040360
2531 031102 000404
2532 031104 000240
2533 031106 104000
2534 031110 000137 031712      6$:
2535
2536      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR      PC,GETSTS      ;GO TO GETSTS SUBROUTINE
2537
2538      ;WAIT FOR COMMAND TO COMPLETE
      JSR      PC,TIMOUT      ;GO TO TIMOUT SUBROUTINE
2539 031120 004737 040732
2540
2541      ;GO READ STATUS FOR FORMAT OPERATION
      JSR      PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      BR      7$      ;GO TO 7$ IF NO ERROR
      NOP      ;RETURN HERE IF ERROR
      EMT      ;ERROR # DEFINED BY GET SUBROUTINE
      JMP      26$      ;GO TO 26$ IF ERROR
2542 031124 004737 040110      7$:
2543 031130 000404
2544 031132 000240
2545 031134 104000
2546 031136 000137 031712
2547 031142      ;VERIFY NO ERRORS DURING FORMAT
      JSR      PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      BR      8$      ;GO TO 8$ IF NO ERROR
      NOP      ;RETURN HERE IF ERROR
      EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
      JSR      FC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
2548 031142 004737 054166
2549 031146 000405
2550 031150 000240
2551 031152 104000
2552 031154 004736
    
```

```

2543 031156 000137 031712      JMP      26$      ;GO TO 26$ IF ERROR
2544 031162
2545
2546 031162 012737 031172 001124 ;MOVE LOOP ADDRESSES TO NEXT OPERATION
2547 031170 060410      MOV      #9$, $LPERR
2548                                BR      10$      ;SKIP TO WRITE OPERATION
2549
2550                                ;*****
2551                                ;LOOP #2      WRITE,READ
2552 031172      9$:
2553
2554                                ;PREPARE DEVICE FOR WRITE OPERATION
2555 031172 004737 034032      JSR      PC, TSTPRP ;PREPARE DEVICE FOR TEST
031176 154130      .WORD   154130    ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 10$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 26$ IF ERROR
031200 000404      BR      10$
031202 000240      NOP
031204 104000      EMT
031206 000137 031712      JMP      26$
2556 031212      10$:
2557
2558                                ;WRITE DATA TO THE DRIVE
2559 031212      11$:
2560 031212 012737 104260 001416      MOV      #BUFONE+4, RMBAD ;CHANGE BUS ADDRESS
2561 031220 012737 177400 001414      MOV      #-256., RMCDC ;CHANGE WORD COUNT
2562 031226 012737 000061 001412      MOV      #WD!GO, RMCSD ;WRITE DATA COMMAND
2563 031234 012702 001555      MOV      #PUTINX, R2    ;LOAD PUT REGISTER INDEX TABLE
2564 031240 112722 000006      MOV      #RMDA, (R2)+
2565 031244 112722 000034      MOV      #RMDC, (R2)+
2566 031250 112722 000032      MOV      #RMOF, (R2)+
2567 031254 112722 000004      MOV      #RMDA, (R2)+
2568 031260 112722 000002      MOV      #RMCSD, (R2)+
2569 031264 112722 000000      MOV      #RMCSD, (R2)+
2570 031270 112722 000200      MOV      #200, (R2)+
2571
2572 031274 004737 040360      JSR      PC, PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
031300 000404      BR      12$      ;GO TO 12$ IF NO ERROR
031302 000240      NOP
031304 104000      EMT
031306 000137 031712      JMP      26$      ;ERROR # DEFINED BY PUT SUBROUTINE
2573 031312      12$:
2574
2575                                ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
031312 004737 040024      JSR      PC, GETSTS ;GO TO GETSTS SUBROUTINE
2576
2577                                ;WAIT FOR COMMAND TO COMPLETE
031316 004737 040732      JSR      PC, TIMEOUT ;GO TO TIMEOUT SUBROUTINE
2578
2579                                ;GO READ STATUS FOR WRITE COMMAND
2580 031322 004737 040110      JSR      PC, GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
    
```

```

031326 C00404 BR 13$ ;GO TO 13$ IF NO ERROR
031330 000240 NOP ;RETURN HERE IF ERROR
031332 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
031334 000137 031712 JMP 26$ ;GO TO 26$ IF ERROR
2581 031340 13$:
2582
2583 ;CHECK FOR ERRORS DURING WRITE OPERATION
2584 031340 004737 041126 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
031344 000405 BR 14$ ;GO TO 14$ IF NO ERROR
031346 000240 NOP ;RETURN HERE IF ERROR
031350 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
031352 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
031354 000137 031712 JMP 26$ ;GO TO 26$ IF ERROR
2585 031360 14$:
2586 031360 004737 054166 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
031364 000405 BR 15$ ;GO TO 15$ IF NO ERROR
031366 000240 NOP ;RETURN HERE IF ERROR
031370 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
031372 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
031374 000137 031712 JMP 26$ ;GO TO 26$ IF ERROR
2587 031400 15$:
2588 031400 004737 041760 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
031404 000405 BR 16$ ;GO TO 16$ IF NO ERROR
031406 000240 NOP ;RETURN HERE IF ERROR
031410 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
031412 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
031414 000137 031712 JMP 26$ ;GO TO 26$ IF ERROR
2589 031420 16$:
2590
2591 ;CHANGE LOOP ADDRESSES
2592 031420 012737 031430 001124 MOV #17$,SLPERR
2593 031426 000410 BR 18$ ;SKIP TO NEXT OPERATION
2594
2595 ;*****
2596 ;LOOP #3 READ
2597
2598 031430 17$:
2599
2600 ;PREPARE DEVICE FOR READ OPERATION
2601 031430 004737 034032 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
031434 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF "SKI" OR "PIP" IS SET
;VERIFY RECALIBRATION
;GO TO 18$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 26$ IF ERROR
031436 000404 BR 18$
031440 000240 NOP
031442 104000 EMT
031444 000137 031712 JMP 26$
2602 031450 18$:
2603
2604 ;READ DATA FROM DEVICE
2605 031450 19$:
2606 031450 012737 105264 001416 MOV #BUFTWO+4,RMBA0 ;CHANGE BUS ADDRESS
    
```

```

2607 031456 012737 000071 001412      MOV      #RD!GO,RMCS10      ;READ DATA COMMAND
2608 031464 012702 001555              MOV      #PUTINX,R2        ;LOAD PUT REGISTER INDEX TABLE
2609 031470 112722 000006              MOVB     #RMDA,(R2)+
2610 031474 112722 000032              MOVB     #RMOF,(R2)+
2611 031500 112722 000034              MOVB     #RMDC,(R2)+
2612 031504 112722 000004              MOVB     #RMBA,(R2)+
2613 031510 112722 000002              MOVB     #RMWC,(R2)+
2614 031514 112722 000000              MOVB     #RMCS1,(R2)+
2615 031520 112712 000200              MOVB     #200,(R2)
2616
2617 031524 004737 040360              JSR      PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      031530 000404              BR       20$              ;GO TO 20$ IF NO ERROR
      031532 000240              NOP                      ;RETURN HERE IF ERROR
      031534 104000              EMT                      ;ERROR # DEFINED BY PUT SUBROUTINE
      031536 000137 031712              JMP      26$              ;GO TO 26$ IF ERROR
2618 031542      20$:
2619
2620      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR      PC,GETSTS      ;GO TO GETSTS SUBROUTINE
2621 031542 004737 040024
2622      ;WAIT FOR COMMAND TO COMPLETE
      JSR      PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
2623 031546 004737 040732
2624      ;GO READ STATUS FOR READ OPERATION
2625 031552 004737 040110              JSR      PC,GET            ;GO READ REGISTER(S) WITH GET SUBROUTINE
      031556 000404              BR       21$              ;GO TO 21$ IF NO ERROR
      031560 000240              NOP                      ;RETURN HERE IF ERROR
      031562 104000              EMT                      ;ERROR # DEFINED BY GET SUBROUTINE
      031564 000137 031712              JMP      26$              ;GO TO 26$ IF ERROR
2626 031570      21$:
2627
2628      ;CHECK FOR ERRORS DURING READ OPERATION
2629 031570 004737 041126              JSR      PC,PRIERR        ;GO CHECK FOR PRIMARY ERRORS
      031574 000405              BR       22$              ;GO TO 22$ IF NO ERROR
      031576 000240              NOP                      ;RETURN HERE IF ERROR
      031600 104000              EMT                      ;ERROR # DEFINED BY PRIERR SUBROUTINE
      031602 004736              JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      031604 000137 031712              JMP      26$              ;GO TO 26$ IF ERROR
2630 031610      22$:
2631 031610 004737 054166              JSR      PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
      031614 000405              BR       23$              ;GO TO 23$ IF NO ERROR
      031616 000240              NOP                      ;RETURN HERE IF ERROR
      031620 104000              EMT                      ;ERROR # DEFINED BY DTASTS SUBROUTINE
      031622 004736              JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      031624 000137 031712              JMP      26$              ;GO TO 26$ IF ERROR
2632 031630      23$:
2633 031630 004737 041760              JSR      PC,SECERR        ;GO CHECK FOR SECONDARY ERRORS
      031634 000405              BR       24$              ;GO TO 24$ IF NO ERROR
      031636 000240              NOP                      ;RETURN HERE IF ERROR
      031640 104000              EMT                      ;ERROR # DEFINED BY SECERR SUBROUTINE
      031642 004736              JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      031644 000137 031712              JMP      26$              ;GO TO 26$ IF ERROR
2634 031650      24$:
2635 031650 004737 037462              JSR      PC,CMPBUF        ;GO COMPARE WRITE, READ DATA BUFFERS
      031654 104260              .WORD   BUFW0+4          ;STARTING ADDRESS OF WRITE BUFFER
      031656 105264              .WORD   BUFTW0+4        ;STARTING ADDRESS OF READ BUFFER
      031660 000404              BR       25$              ;GO TO 25$ IF NO ERROR

```

```

031662 000240      NOP      ;RETURN HERE IF ERROR
031664 104000      EMT      ;ERROR # DEFINED BY CMPBUF SUBROUTINE
031666 000137 031712 25$:      JMP      26$      ;GO TO 26$ IF ERROR
2636 031672      INCB     RMDAO+1      ;ADVANCE TO NEXT TRACK
2637 031672 105237 001421      CMPB     RMDAO+1,LSTRK+1      ;DONE ?
2638 031676 123737 001421 001335      BHI     26$      ;YES!!
2639 031704 101002      JMP      3$      ;TEST NEXT TRACK
2640 031706 000137 030746      26$:
2641 031712
2642
2643
*****
;*TEST 22      READ, WRITE CHECK MULTIPLE SECTORS IN OFFSET MODE
*****
TST22:
031712      SCOPE     ;SCOPE CALL
031712 000004      NOP      ;START OF TEST
031714 000240      MOV      #STACK,SP      ;INITIALIZE STACK POINTER
031716 012706 001100      MOV      $BASE,R0      ;R0 = UNIBUS ADDRESS
031722 013700 001276      MOV      TSTQUE,R1      ;(R1) = DEVICE BEING TESTED
031726 013701 001466      MOV      #22,$TESTN     ;:SET TEST NUMBER IN APT MAIL BOX
031732 012737 000022 001226
2644
2645
2646
2647 031740      :LOOP #1      FORMAT,READ OFFSET,WRITE CHECK OFFSET IN BOTH DIRECTIONS
2648 1$:
2649
2650 031740 004737 034032      ;PREPARE DEVICE FOR FORMAT OPERATION
031744 154130      JSR      PC,TSTPRP      ;PREPARE DEVICE FOR TEST
                          .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
                          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                          ;CLEAR CONTROLLER & SELECT DEVICE
                          ;VERIFY CONTROLLER CLEAR OPERATION
                          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                          ;VERIFY PACK ACKNOWLEDGE
                          ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                          ;VERIFY RECALIBRATION
031746 000404      BR       2$      ;GO TO 2$ IF NO ERROR
031750 000240      NOP      ;RETURN HERE IF ERROR
031752 104000      EMT      ;ERROR # DEFINED BY TSTPKP SUBROUTINE
031754 000137 033074      JMP      28$      ;GO TO 28$ IF ERROR
2651
2652
2653 031760      ;LOAD PARAMETERS AND GENERATE DATA BUFFER
2654 031760 012737 001057 001446      2$:      MOV      #559,RMDCO      ;CYLINDER = 559.
2655 031766 012737 001000 001420      MOV      #TA2,RMDAO      ;TRACK = 2, SECTOR = 0
2656 031774 012737 104254 001416      MOV      #BUFONE,RMBAO   ;BUFFER ADDRESS
2657 032002 012737 176774 001414      MOV      #-258,*2,RMWCO  ;WORD COUNT FOR 2 SECTORS (2'S COMP)
2658 032010 012737 010000 001444      MOV      #FMT16,RMOFO   ;16 BIT MODE
2659 032016 012737 000063 001412      MOV      #WH!GO,RMCS10  ;WRITE HEADER
2660
2661
032024 004737 034762      ;VERIFY THAT SECTOR IS NOT BAD
032030 000405      JSR      PC,BADSCT      ;CALL BAD SECTOR MODULE
032032 104401 066006      BR       3$      ;GO TO 3$ IF NO ERROR
032036 104000      TYPE     ,SCTMSG      ;TYPE BAD SECTOR MESSAGE
032040 000137 033074      EMT      ;ERROR # DEFINED BY BADSCT SUBROUTINE
2662 032044      JMP      28$      ;GO TO 28$ IF ERROR
2663 032044 012737 067456 001174      3$:      MOV      #ZEROS,$TMP0   ;DATA PATTERN

```

```

2664 032052 012737 000001 001176      MOV    #1,STMP1
2665 032060 004737 037214              JSR    PC,GENBUF          ;TO GENERATE BUFFER FOR FORMAT
2666
2667                                ;LOAD PUT REGISTER INDEX TABLE FOR FORMAT OPERATION
2668 032064 012702 001555      MOV    #PUTINX,R2          ;BYTE ENTRY TABLE
2669 032070 112722 000034      MOVB  #RMDC,(R2)+
2670 032074 112722 000006      MOVB  #RMDA,(R2)+
2671 032100 112722 000004      MOVB  #RMB A,(R2)+
2672 032104 112722 000002      MOVB  #RMWC,(R2)+
2673 032110 112722 000032      MOVB  #RMOF,(R2)+
2674 032114 112722 000000      MOVB  #RMCS1,(R2)+
2675 032120 112712 000200      MOVB  #200,(R2)          ;TABLE TERMINATOR
2676 032124
2677 032124 004737 040360      4$:   JSR    PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      BR    5$              ;GO TO 5$ IF NO ERROR
      NOP              ;RETURN HERE IF ERROR
      EMT              ;ERROR # DEFINED BY PUT SUBROUTINE
      JMP    28$          ;GO TO 28$ IF ERROR
2678 032142      5$:
2679
2680                                ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR    PC,GETSTS      ;GO TO GETSTS SUBROUTINE
2681 032142 004737 040024
2682                                ;WAIT FOR COMMAND TO COMPLETE
      JSR    PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
2683 032146 004737 040732
2684                                ;GO READ STATUS FOR FORMAT OPERATION
2685 032152 004737 040110      JSR    PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      BR    6$              ;GO TO 6$ IF NO ERROR
      NOP              ;RETURN HERE IF ERROR
      EMT              ;ERROR # DEFINED BY GET SUBROUTINE
      JMP    28$          ;GO TO 28$ IF ERROR
2686 032164 000137 033074
2687 032170      6$:
2688                                ;VERIFY NO ERROR DURING FORMAT
2689 032170 004737 054166      JSR    PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
      BR    7$              ;GO TO 7$ IF NO ERROR
      NOP              ;RETURN HERE IF ERROR
      EMT              ;ERROR # DEFINED BY DTASTS SUBROUTINE
      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      JMP    28$          ;GO TO 28$ IF ERROR
2690 032204 000137 033074
2691                                ;MOV LOOP ADDRESSES TO NEXT OPERATION
2692 032210      7$:
2693 032210 012737 032232 001124      MOV    #8$,$LPERR      ;ERROR LOOP ADDRESS
2694
2695                                ;LOCATE BUFFER ADDRESS AND WORD COUNT
2696 032216 012737 177000 001414      MOV    #-256.*2,RMWCO  ;TWO SECTORS
2697 032224 012737 104254 001416      MOV    #BUFONE,RMBAO   ;BUFFER ADDRESS
2698
2699                                ;*****
2700 032232                                ;LOOP 2 READ AND WRITE CHECK IN OFFSET MODE
2701      8$:
2702 032232 004737 034032      ;PREPARE DEVICE FOR READ OFFSET OPEATION
      JSR    PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      .WORD 154130          ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
  
```



```

    032240 000404          BR      9$
    032242 000240          NOP
    032244 104000          EMT
    032246 000137 033074  JMP      28$
2703 032252          9$:
2704 032252          10$:
2705          ;READ OFFSET
2706 032252 012702 001555  MOV      #PUTINX,R2      ;LOAD THE TABLE
2707 032256 112722 000006  MOVB    #RMDA,(R2)+
2708 032262 112722 000034  MOVB    #RMDC,(R2)+
2709 032266 112722 000032  MOVB    #RMOF,(R2)+
2710 032272 112722 000004  MOVB    #RMBA,(R2)+
2711 032276 112722 000002  MOVB    #RMWC,(R2)+
2712 032302 112722 000200  MOVB    #200,(R2)+      ;TABLE TERMINATOR
2713
2714 032306 004737 040360  JSR      PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    032312 000404          BR      11$
    032314 000240          NOP
    032316 104000          EMT
    032320 000137 033074  JMP      28$
2715 032324 012737 000015 001412 11$: MOV      #OFFSET!GO,RMCS10 ;OFFSET COMMAND
2716 032332 012702 001555  MOV      #PUTINX,R2
2717 032336 112722 000000  MOVB    #RMCS1,(R2)+
2718 032342 112722 000200  MOVB    #200,(R2)+
2719
2720 032346 004737 040360  JSR      PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    032352 000404          BR      12$
    032354 000240          NOP
    032356 104000          EMT
    032360 000137 033074  JMP      28$
2721 032364          12$:
2722
2723          ;WAIT FOR COMMAND TO COMPLETE
    032364 004737 040732  JSR      PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
2724
2725 032370 012737 000071 001412  MOV      #RD!GO,RMCS10    ;READ DATA COMMAND
2726 032376 012702 001555  MOV      #PUTINX,R2      ;TABLE INDX
2727 032402 112722 000000  MOVB    #RMCS1,(R2)+
2728 032406 112712 000200  MOVB    #200,(R2)      ;TABLE TERMINATOR
2729
2730 032412 004737 040360  JSR      PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    032416 000404          BR      13$
    032420 000240          NOP
    032422 104000          EMT
    032424 000137 033074  JMP      28$
2731 032430          13$:
2732
2733          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
    032430 004737 040024  JSR      PC,GETSTS      ;GO TO GETSTS SUBROUTINE
2734
2735          ;WAIT FOR COMMAND TO COMPLETE
    032434 004737 040732  JSR      PC,TIMOUT      ;GO TO TIMEOUT SUBROUTINE
  
```

```

;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 9$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 28$ IF ERROR
  
```

```

;LOAD THE TABLE
  
```

```

;TABLE TERMINATOR
  
```

```

;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
;GO TO 11$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY PUT SUBROUTINE
;GO TO 28$ IF ERROR
;OFFSET COMMAND
  
```

```

;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
;GO TO 12$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY PUT SUBROUTINE
;GO TO 28$ IF ERROR
  
```

```

;GO TO TIMEOUT SUBROUTINE
;READ DATA COMMAND
;TABLE INDX
;TABLE TERMINATOR
  
```

```

;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
;GO TO 13$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY PUT SUBROUTINE
;GO TO 28$ IF ERROR
  
```

```

;GO TO GETSTS SUBROUTINE
  
```

```

;GO TO TIMEOUT SUBROUTINE
  
```

```

2736
2737
2738 032440 004737 040110      ;READ STATUS FOR READ OFFSET OPERATION
      032444 000404          JSR   PC,GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
      032446 000240          BR    14$             ;GO TO 14$ IF NO ERROR
      032450 104000          NOP                    ;RETURN HERE IF ERROR
      032452 000137 033074    EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
                                      JMP   28$             ;GO TO 28$ IF ERROR

2739
2740
2741 032456
2742 032456 004737 041126      ;CHECK ERROR DURING READ OFFSET
      032462 000405          14$: JSR   PC,PRIERR        ;GO CHECK FOR PRIMARY ERRORS
      032464 000240          BR    15$             ;GO TO 15$ IF NO ERROR
      032466 104000          NOP                    ;RETURN HERE IF ERROR
      032470 004736          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      032472 000137 033074    JSR   PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
                                      JMP   28$             ;GO TO 28$ IF ERROR

2743 032476
2744 032476 004737 054166      15$: JSR   PC,DTASTS       ;GO VERIFY RESULTS OF DATA TRANSFER
      032502 000405          BR    16$             ;GO TO 16$ IF NO ERROR
      032504 000240          NOP                    ;RETURN HERE IF ERROR
      032506 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      032510 004736          JSR   PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      032512 000137 033074    JMP   28$             ;GO TO 28$ IF ERROR

2745 032516
2746 032516 004737 041760      16$: JSR   PC,SECERR       ;GO CHECK FOR SECONDARY ERRORS
      032522 000405          BR    17$             ;GO TO 17$ IF NO ERROR
      032524 000240          NOP                    ;RETURN HERE IF ERROR
      032526 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      032530 004736          JSR   PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      032532 000137 033074    JMP   28$             ;GO TO 28$ IF ERROR

2747 032536
2748
2749
2750 032536 012737 032546 001124 ;CHANGE LOOP ADDRESS
      032544 000410          MOV   #18$, $LPERR
      2752
      2753
      2754
      2755 032546
      2756
      2757
      2758 032546 004737 034032 ;PREPARE DEVICE FOR READ OPERATION
      032552 154130          JSR   PC,TSTPRP       ;PREPARE DEVICE FOR TEST
                                      .WORD 154130          ;TASK DESCRIPTOR AS FOLLOWS:
                                      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                      ;CLEAR CONTROLLER & SELECT DEVICE
                                      ;VERIFY CONTROLLER CLEAR OPERATION
                                      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                      ;VERIFY PACK ACKNOWLEDGE
                                      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                      ;VERIFY RECALIBRATION
      032554 000404          BR    19$             ;GO TO 19$ IF NO ERROR
      032556 000240          NOP                    ;RETURN HERE IF ERROR
      032560 104000          EMT                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      032562 000137 033074    JMP   28$             ;GO TO 28$ IF ERROR

2759 032566
2760
2761
      19$:
      ;WRITE CHECK DATA IN OFFSET MODE
  
```

```

2762 032566          20$:
2763 032566 012702 001555      MOV    #PUTINX,R2
2764 032572 112722 000006      MOVB  #RMDA,(R2)+
2765 032576 112722 000032      MOVB  #RMOF,(R2)+
2766 032602 112722 000034      MOVB  #RMDC,(R2)+
2767 032606 112722 000004      MOVB  #RMDA,(R2)+
2768 032612 112722 0000C2      MOVB  #RMWC,(R2)+
2769 032616 112712 000200      MOVB  #200,(R2)          ;TABLE TERMINATOR
2770
2771 032622 004737 040360      JSR   PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      032626 000404          BR    21$              ;GO TO 21$ IF NO ERROR
      032630 000240          NOP                    ;RETURN HERE IF ERROR
      032632 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      032634 000137 033074      JMP   28$              ;GO TO 28$ IF ERROR

2772
2773          ;SETUP OFFSET MODE FIRST
2774 032640          21$:
2775 032640 012737 000015 001412      MOV   #OFFSET!GO,RMCS10 ;OUTPUT BUFFER
2776 032646 012702 001555          MOV   #PUTINX,R2
2777 032652 112722 000000          MOVB  #RMCS1,(R2)+
2778 032656 112712 000200          MOVB  #200,(R2)
2779
2780 032662 004737 040360      JSR   PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      032666 000404          BR    22$              ;GO TO 22$ IF NO ERROR
      032670 000240          NOP                    ;RETURN HERE IF ERROR
      032672 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      032674 000137 033074      JMP   28$              ;GO TO 28$ IF ERROR

2781 032700          22$:
2782
2783          ;WAIT FOR COMMAND TO COMPLETE
      032700 004737 040732      JSR   PC,TIMOUT        ;GO TO TIMOUT SUBROUTINE
2784
2785          ;EXECUTE WRITE CHECK DATA COMMAND
2786 032704 012737 000051 001412      MOV   #WCD!GO,RMCS10
2787 032712 012702 001555          MOV   #PUTINX,R2
2788 032716 112722 000000          MOVB  #RMCS1,(R2)+
2789 032722 112712 000200          MOVB  #200,(R2)
2790
2791 032726 004737 040360      JSR   PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      032732 000404          BR    23$              ;GO TO 23$ IF NO ERROR
      032734 000240          NOP                    ;RETURN HERE IF ERROR
      032736 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      032740 000137 033074      JMP   28$              ;GO TO 28$ IF ERROR

2792 032744          23$:
2793
2794          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      032744 004737 040024      JSR   PC,GETSTS        ;GO TO GETSTS SUBROUTINE
2795
2796          ;WAIT FOR COMMAND TO COMPLETE
      032750 004737 040732      JSR   PC,TIMOUT        ;GO TO TIMOUT SUBROUTINE
2797
2798          ;READ STATUS FOR WRITE CHECK OFFSET OPERATION
2799 032754 004737 040110      JSR   PC,GET            ;GO READ REGISTER(S) WITH GET SUBROUTINE
      032760 000404          BR    24$              ;GO TO 24$ IF NO ERROR
      032762 000240          NOP                    ;RETURN HERE IF ERROR
      032764 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      032766 000137 033074      JMP   28$              ;GO TO 28$ IF ERROR
  
```

```

2800 032772          24$:
2801
2802
2803 032772 004737 041126 :CHECK ERROR DURING WRITE CHECK OFFSET OPERATION
      032776 000405      JSR PC,PRIERR :GO CHECK FOR PRIMARY ERRORS
      033000 000240      BR 25$ :GO TO 25$ IF NO ERROR
      033002 104000      NOP :RETURN HERE IF ERROR
      033004 004736      EMT :ERROR # DEFINED BY PRIERR SUBROUTINE
      033006 000137 033074 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
      JMP 28$ :GO TO 28$ IF ERROR

2804 033012          25$:
2805 033012 004737 054166 JSR PC,DTASTS :GO VERIFY RESULTS OF DATA TRANSFER
      033016 000405      BR 26$ :GO TO 26$ IF NO ERROR
      033020 000240      NOP :RETURN HERE IF ERROR
      033022 104000      EMT :ERROR # DEFINED BY DTASTS SUBROUTINE
      033024 004736      JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
      033026 000137 033074 JMP 28$ :GO TO 28$ IF ERROR

2806 033032          26$:
2807 033032 004737 041760 JSR PC,SECERR :GO CHECK FOR SECONDARY ERRORS
      033036 000405      BR 27$ :GO TO 27$ IF NO ERROR
      033040 000240      NOP :RETURN HERE IF ERROR
      033042 104000      EMT :ERROR # DEFINED BY SECERR SUBROUTINE
      033044 004736      JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
      033046 000137 033074 JMP 28$ :GO TO 28$ IF ERROR

2808 033052          27$:
2809 033052 032737 000200 001444 BIT #OFD,RMOFO :IN FORWARD DIRECTION OF OFFSET ?
2810 033060 001005      BNE 28$ :BRANCH IF SO
2811 033062 052737 000200 001444 BIS #OFD,RMOFO :SET TO FORWARD DIRECTION
2812 033070 000137 032210 JMP 7$ :CHANGE OFFSET DIRECTION TEST AGAIN
2813 033074          28$:
2814
2815

```

```

:*****
:*TEST 23          FORMAT FE CYLINDERS
:*****
TST23:

```

```

033074 000004      SCOPE :SCOPE CALL
033074 000240      NOP :START OF TEST
033100 012706 001100 MOV #STACK,SP :INITIALIZE STACK POINTER
033104 013700 001276 MOV $BASE,R0 :R0 = UNIBUS ADDRESS
033110 013701 001466 MOV TSTQUE,R1 : (R1) = DEVICE BEING TESTED
033114 012737 000001 001206 MOV #1,$TIMES :DO 1 ITERATION
033122 012737 000023 001226 MOV #23,$TESTN :SET TEST NUMBER IN APT MAIL BOX

2816
2817 :SETUP PARAMETERS FOR GENERATING DATA BUFFER
2818 033130 012737 001057 001446 MOV #559,RMDCO :CYLINDER = 559.
2819 033136 012737 001000 001420 MOV #TA2,RMDAO :TRACK = 2, SECTOR = 0
2820 033144          1$:
2821 033144 012737 011000 001444 MOV #FMT16!SSEI,RMOFO :16 BIT FORMAT WITH SSEI SET
2822 033152 012737 177776 001414 MOV #-2,RMWCO :2 WORDS (2'S COMP)
2823 033160 012737 104254 001416 MOV #BUFONE,RMBAO :DATA BUFFER ADDRESS
2824 033166 012737 000062 001412 MOV #WH,RMCS10 :WRITE HEADER AND DATA
2825
2826 :VERIFY THAT SECTOR IS NOT BAD
033174 004737 034762 JSR PC,BADSCT :CALL BAD SECTOR MODULE
033200 000405      BR 2$ :GO TO 2$ IF NO ERROR
033202 104401 066006 TYPE ,SCTMSG :TYPE BAD SECTOR MESSAGE
033206 104000      EMT :ERROR # DEFINED BY BADSCT SUBROUTINE
033210 000137 033522 JMP 12$ :GO TO 12$ IF ERROR

```

```

2827 033214          2$:
2828 033214 023727 001446 001060      CMP      RMDCO,#560.      ;IS DESIRED CYLINDER, OUTSIDE FE CYLINDERS ?
2829 033222 101402          BLOS     3$              ;NO !!
2830 033224 000137 033522          JMP      12$            ;YES, EXIT TEST
2831 033230          3$:
2832 033230 004737 037214          JSR      PC,GENBUF      ;GO GENERATE DATA BUFFER
2833 033234          4$:
2834 033234 005737 001514          TST      SSFENB         ;TEST SSF ENABLE FOR 1ST HEADER WORD
2835 033240 001403          BEQ      5$              ;NO, DO NOT SET 'SSF'
2836 033242 052737 020000 104254     BIS      #SSF,BUFONE    ;YES, SET SSF BIT
2837 033250          5$:
2838
2839          ;PREPARE DEVICE FOR DATA TRANSFER
2840 033250 004737 034032          JSR      PC,TSTPRP     ;PREPARE DEVICE FOR TEST
      033254 154130          .WORD   154130        ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 6$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 12$ IF ERROR
      BR      6$
      NOP
      EMT
      JMP     12$
      033254 000404          BR      6$
      033260 000240          NOP
      033262 104000          EMT
      033264 000137 033522          JMP     12$
      ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
2841
2842          6$:
2843 033270          MOV      #WH!GO,RMCS10 ;WRITE HEADER AND DATA
2844 033270 012737 000063 001412     MOV      #PUTINX,R2    ;WRITE REGISTER INDEX TABLE
2845 033276 012702 001555          MOVB    #RMDA,(R2)+
2846 033302 112722 000006          MOVB    #RMDC,(R2)+
2847 033306 112722 000034          MOVB    #RMOF,(R2)+
2848 033312 112722 000032          MOVB    #RMWC,(R2)+
2349 033316 112722 000002          MOVB    #RMBB,(R2)+
2850 033322 112722 000004          MOVB    #RMCS1,(R2)+
2851 033326 112722 000030          MOVB    #200,(R2)+
2852 033332 112722 000200          MOVB
2853
2854 033336 004737 040360          JSR      PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      033342 000404          BR      7$              ;GO TO 7$ IF NO ERROR
      033344 000240          NOP                    ;RETURN HERE IF ERROR
      033346 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      033350 000137 033522          JMP     12$            ;GO TO 12$ IF ERROR
2855 033354          7$:
2856
2857          ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      033354 004737 040024          JSR      PC,GETSTS     ;GO TO GETSTS SUBROUTINE
2858
2859          ;WAIT FOR COMMAND TO COMPLETE
      033360 004737 040732          JSR      PC,TIMOUT     ;GO TO TIMOUT SUBROUTINE
2860
2861 033364 004737 040110          JSR      PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      033370 000404          BR      8$              ;GO TO 8$ IF NO ERROR
      033372 000240          NOP                    ;RETURN HERE IF ERROR
      033374 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      033376 000137 033522          JMP     12$            ;GO TO 12$ IF ERROR
    
```

```

2862 033402      8$:
2863
2864      ;VERIFY RESULTS OF WRITE COMMAND
2865 033402 004737 041126      JSR    PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      033406 000405      BR     9$             ;GO TO 9$ IF NO ERROR
      033410 000240      NOP                    ;RETURN HERE IF ERROR
      033412 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      033414 004736      JSR    PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      033416 000137 033522      JMP    12$           ;GO TO 12$ IF ERROR

2866 033422      9$:
2867 033422 004737 041760      JSR    PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
      033426 000405      BR     10$            ;GO TO 10$ IF NO ERROR
      033430 000240      NOP                    ;RETURN HERE IF ERROR
      033432 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      033434 004736      JSR    PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
      033436 000137 033522      JMP    12$           ;GO TO 12$ IF ERROR

2868 033442      10$:
2869
2870      ;INCREMENT ADDRESS
2871 033442 005237 001420      INC    RMDAO          ;ADVANCE SECTOR COUNT
2872 033446 123727 001420 000037  CMPB   RMDAO,#31.     ;DONE ALL SECTORS ?
2873 033454 101420      BLOS   11$           ;NO !!
2874
2875 033456 105037 001420      CLRB   RMDAO          ;START AT SECTOR 0 AND
2876 033462 105237 001421      INCB   RMDAO+1        ;ADVANCE TO NEXT TRACK.
2877 033466 123737 001421 001335  CMPB   RMDAO+1,LSTRK+1 ;DONE WITH LAST TRACK ?
2878 033474 101410      ELOS   11$           ;NO !!
2879
2880 033476 105037 001421      CLRB   RMDAO+1        ;START WITH TRACK 0 AND
2881 033502 005237 001446      INC    RMDCO          ;ADVANCE TO NEXT CYLINDER.
2882 033506 023727 001446 001060  CMP    RMDCO,#560.    ;DONE WITH LAST CYLINDER ?
2883 033514 101002      BHI    12$           ;YES !!
2884 033516 000137 033144      JMP    1$             ;GO DO TEST AGAIN
2885
2886 033522      12$:
  
```

```

1      .SBTTL  END OF SUB-PASS ROUTINE
2
3      :THIS IS THE END OF SUB-PASS ROUTINE. THIS ROUTINE IS USED TO
4      :TERMINATE THE OPERATION OF THE CURRENT DEVICE UNDER TEST AND
5      :SELECT THE NEXT DEVICE FOR TEST. IF THERE ARE NO MORE DEVICES
6      :TO TEST, EXIT IS MADE TO '$EOP' ROUTINE. OTHERWISE, RETURN
7      :IS MADE TO 'SHUT' ROUTINE.
8
9 033522 000004      $EOSP:  SCOPE
10 033524 000240      NOP
11 033526 013700 001466      MOV      TSTQUE,R0      ;GET POINTER TO TSTQUE
12 033532 062700 000002      ADD      #2,R0      ;ADJUST POINTER TO NEXT DEVICE
13 033536 010037 001466      MOV      R0,TSTQUE      ;SAVE POINTER TO TSTQUE
14 033542 005710      TST      (R0)      ;ANY MORE DEVICES FOR TEST ?
15 033544 001402      BEQ      1$      ;BR IF NO
16 033546 000137 033776      JMP      SHUT      ;YES, JUMP TO 'SHUT' ROUTINE
17 033552 012737 001470 001466 1$:      MOV      #TSTQUE+2,TSTQUE      ;INITIALIZE POINTER TO FIRST DEVICE IN
18                                          ;TEST QUE TABLE
19
20     .SBTTL  END OF PASS ROUTINE

```

```

:*****
:*INCREMENT THE PASS NUMBER ($PASS)
:*TYPE 'END PASS #XXXXX TOTAL NUMBER OF ERRORS SINCE LAST REPORT YYYYY'
:*WHERE XXXXX AND YYYYY ARE DECIMAL NUMBERS
:*IF THERES A MONITOR GO TO IT
:*IF THERE ISN'T JUMP TO SHUT

```

```

033560      $EOP:
033560 000240      NOP
033562 005037 001116      CLR      $TSTNM      ;;ZERO THE TEST NUMBER
033566 005037 001206      CLR      $TIMES      ;;ZERO THE NUMBER OF ITERATIONS
033572 005237 001230      INC      $PASS      ;;INCREMENT THE PASS NUMBER
033576 042737 100000 001230      BIC      #100000,$PASS      ;;DON'T ALLOW A NEG. NUMBER
033604 005327      DEC      (PC)+      ;;LOOP?
033606 000001      SEOPCT: .WORD 1
033610 003066      BGT      $DOAGN      ;;YES
033612 012737      MOV      (PC)+,a(PC)+      ;;RESTORE COUNTER
033614 000001      SENDCT: .WORD 1
033616 033606      $EOPCT
033620 104401 033626      TYPE      .65$      ;;TYPE ASCIZ STRING
033624 000407      BR      64$      ;;GET OVER THE ASCIZ
64$:      .ASCIZ <12><15>/END PASS #/
033644      MOV      $PASS,-(SP)      ;;SAVE $PASS FOR TYPEOUT
033644 013746 001230      ;;TYPE PASS NUMBER
033650 104405      TYPDS      ;;GO TYPE--DECIMAL ASCII WITH SIGN
033652 005737 001126      TST      $ERTTL      ;;SEE IF ANY ERRORS THIS PASS
033656 001431      BEQ      $GT42P      ;;BR IF NO ERRORS TO REPORT
033660 104401 033666      TYPE      .67$      ;;TYPE ASCIZ STRING
033664 000421      BR      66$      ;;GET OVER THE ASCIZ
66$:      .ASCIZ / TOTAL ERRORS SINCE LAST REPORT /
033730      MOV      $ERTTL,-(SP)      ;;SAVE $ERTTL FOR TYPEOUT
033730 013746 001126      ;;TOTAL NUMBER OF ERRORS
033734 104405      TYPDS      ;;GO TYPE--DECIMAL ASCII WITH SIGN
033736 005037 001126      CLR      $ERTTL      ;;CLEAR ERROR TOTAL

```

033742	104401	001217		\$GT42P:	TYPE	, \$CRLF	:: TYPE CARRIAGE RETURN, LINE FEED
033746	013700	000042		\$GET42:	MOV	@#42, R0	:: GET MONITOR ADDRESS
033752	001405				BEQ	\$DOAGN	:: BRANCH IF NO MONITOR
033754	000005				RESET		:: CLEAR THE WORLD
033756	004710			\$ENDAD:	JSR	PC, (R0)	:: GO TO MONITOR
033760	000240				NOP		:: SAVE ROOM
033762	000240				NOP		:: FOR
033764	000240				NOP		:: ACT11
033766				\$DOAGN:			
033766	000137				JMP	@(PC)+	:: RETURN
033770	033776			\$RTNAD:	.WORD	SHUT	
033772	377	377	000	\$ENULL:	.BYTE	-1, -1, 0	:: NULL CHARACTER STRING
					.EVEN		
21							
22	033776	005737	001326	SHUT:	TST	CTLFG	:: WAS CONTROL C FLAGGED ?
23	034002	001002			BNE	1\$:: BR IF YES
24	034004	000137	007524		JMP	READY	:: CONTINUE
25	034010	005737	000042	1\$:	TST	@#42	:: ANY MONITOR PRESENT ?
26	034014	001002			BNE	2\$:: BR IF YES
27	034016	000137	005434		JMP	START	:: GO TO START
28	034022	005037	001300	2\$:	CLR	\$DEVN	:: FUDGE NO DRIVES IN MAP
29	034026	000137	033560		JMP	\$EOP	:: RETURN TO \$EOP

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL TEST PREPARATION MODULE

: THIS MODULE PREPARES THE SUBSYSTEM FOR THE EXECUTION OF A TEST,
 : REPORTING AN ERROR TO THE USER IF AN ERROR IS DETECTED. THE USER
 : SPECIFIES TASKS TO BE PERFORMED, WHICH THE MODULE EXECUTES
 : USING SUBROUTINES.

:CALL:

```

    JSR    PC,TSTPRP          TASK/VERIFY DESCRIPTOR
    .WORD  NNNNNN            RETURN HERE IF NO ERROR
    BR     ??                RETURN HERE IF ERROR
    NOP
    ERROR  ERROR DEFINED BY MODULE
    
```

:TASK/VERIFY DESCRIPTOR

```

    BIT 15 = 1              SELECT DEVICE AND VERIFY DEVICE IS AVAILABLE
    -----
    BIT 14 = 1              CLEAR CONTROLLER AND SELECT DEVICE
    BIT 13                  (RESERVED FOR DRIVE CLEAR)
    BIT 12 = 1              PACK ACKNOWLEDGE IF VOLUME NOT VALID
    -----
    BIT 11 = 1              RECALIBRATE IF POSITIONING IN PROGRESS OR SKI ERROR
    BIT 10 = 1              RECALIBRATE DRIVE
    BIT 9
    -----
    BIT 8
    BIT 7
    BIT 6 = 1              VERIFY CONTROLLER CLEAR OPERATION
    -----
    BIT 5                  (RESERVED FOR DRIVE CLEAR)
    BIT 4 = 1              VERIFY PACK ACKNOWLEDGE
    BIT 3 = 1              VERIFY RECALIBRATION
    -----
    BIT 2
    BIT 1
    BIT 0
    
```

TSTPRP:

:STORE TASK DESCRIPTOR AND CLEAR USER'S ERROR CALL

```

41 034032 017657 000000 034756
42 034040 062716 000006
43 034044 105076 00000C
44 034050 162716 000004
46 034054 004737 040024
47 034060 004737 040110
48 034064 000411
49 034066 000401
50 034070 000000
51 034072 062716 000004 1$:
52 034076 113776 034070 000000
53 034104 000137 034746
55 034110 013737 001400 034760 2$:
    
```

```

    MOV    @ (SP),39$        :STORE DESCRIPTOR
    ADD    #6,(SP)          :MOVE SP TO USERS ERROR CALL
    CLRB   @ (SP)           :CLEAR ERROR CALL
    SUB    #4,(SP)          :MOVE SP TO NO ERROR RETURN

    JSR    PC,GETSTS        :SETUP TO READ ALL REGISTERS
    JSR    PC,GET           :GET RMER2
    BR     2$              :BR IF NO ERROR DETECTED
    BR     1$              :GET OVER ERROR NUMBER
    .WORD  0                :ERROR DEFINED BY GET SUBROUTINE
    ADD    #4,(SP)          :XFER ERROR TO USER AND
    MOVB   1$-2,@(SP)       :GET ERROR NUMBER.
    JMP    37$

    MOV    RMER2I,40$       :GET RMER2 AND SAVE FOR LATER
    
```

:*****

```

58                                     ;SELECT DEVICE AND VERIFY DEVICE AVAILABLE IF BIT 15 SET IN TASK
59 034116 005737 034756                TST      39$      ;SELECT DEVICE??
60 034122 100014                        BPL      4$      ;NO!!
61
62 034124 004737 046336                JSR      PC,DEVSEL ;GO SELECT DEVICE
63 034130 000411                        BR       4$      ;NO ERROR - CONTINUE
64 034132 000401                        BR       3$
65 034134 000000                        .WORD   0        ;ERROR NUMBER FROM DEVSEL
66 034136 062716 000004 000000 3$:  ADD     #4,(SP)   ;TRANSFER ERROR TO USER
67 034142 113776 034134 000000      MOVB    3$,a(SP)
68 034150 000137 034746                JMP     37$
69
70                                     ;*****
71                                     ;CLEAR CONTROLLER IF BIT 14 IS SET IN TASK
72 034154                                4$:
73 034154 032737 040000 034756        BIT     #BIT14,39$ ;CLEAR CONTROLLER??
74 034162 001451                        BEQ     13$      ;NO!!
75
76 034164 004737 050030                JSR      PC,CNTCLR ;GO CLEAR CONTROLLER
77 034170 000411                        BR       7$      ;CONTINUE - NO ERROR
78 034172 000401                        BR       6$
79 034174 000000                        .WORD   0        ;ERROR NUMBER FROM CNTCLR
80 034176 062716 000004 000000 5$:  ADD     #4,(SP)   ;TRANSFER ERROR TO USER
81 034202 113776 034174 000000 6$:  MOVB    5$,a(SP)
82 034210 000137 034746                JMP     37$
83
84                                     ;*****
85                                     ;VERIFY CONTROLLER CLEAR IF BIT6 SET IN TASK
86 034214                                7$:
87 034214 032737 000100 034756        BIT     #BIT6,39$ ;VERIFY??
88 034222 001431                        BEQ     13$      ;NO!!
89
90 034224 004737 040110                JSR      PC,GET    ;GO GET STATUS
91 034230 000411                        BR      10$      ;NO ERROR GETTING STATUS
92 034232 000401                        BR       9$
93 034234 000000                        .WORD   0        ;ERROR FROM GETTING STATUS
94 034236 062716 000004 000000 8$:  ADD     #4,(SP)   ;TRANSFER ERROR TO USER
95 034242 113776 034234 000000 9$:  MOVB    8$,a(SP)
96 034250 000137 034746                JMP     37$
97
98 034254 004737 050146                10$: JSR     PC,CLRSTS ;GO VERIFY STATUS CLEAR
99 034260 000412                        BR      13$      ;NO ERROR IN CLEAR
100 034262 000401                        BR      12$
101 034264 000000                        .WORD   0        ;ERROR IN STATUS CLEAR
102 034266 005726                        TST     (SP)+    ;STRIP RETURN ADDRESS TO
103 034270 062716 000004 000000 11$: ADD     #4,(SP)   ;SUBROUTINE AND TRANSFER
104 034274 113776 034264 000000 12$: MOVB    11$,a(SP) ;ERROR TO USER
105 034302 000137 034746                JMP     37$
106
107                                     ;*****
108                                     ;EXECUTE PACK ACKNOWLEDGE IF BIT12 SET IN TASK AND VOLUME IS
109                                     ;NOT VALID
110 034306                                13$:
111 034306 032737 010000 034756        BIT     #BIT12,39$ ;PACK ACKNOWLEDGE??
112 034314 001501                        BEQ     25$      ;NO!!
113
114 034316 004737 040110                JSR     PC,GET
    
```

C
C

```

115 034322 000411          BR      16$          ;NO ERROR GETTING RMDS
116 034324 000401          BR      15$
117 034326 000000          14$: .WORD 0
118 034330 062716 000004 15$: ADD #4,(SP)      ;TRANSFER ERROR TO USER
119 034334 113776 034326 000000 MOVB 14$,a(SP)
120 034342 000137 034746 JMP 37$
121
122 034346 032737 000100 001350 16$: BIT #VV,RMDSI      ;IS VOLUME VALID??
123 034354 001061          BNE 25$          ;YES!!
124
125 034356 012737 000023 001412 MOV #PAKACK!GO,RMCS10 ;LOAD PACK ACK COMMAND
126 034364 112737 000000 001555 MOVB #RMCS1,PUTINX    ;SETUP REGISTER INDEX TABLE
127 034372 112737 000200 001556 MOVB #200,PUTINX+1
128 034400 004737 040360 JSR PC,PUT          ;GO WRITE COMMAND
129 034404 000410          BR      19$          ;NO ERROR LOADING REGISTER
130 034406 000401          BR      18$
131 034410 000000          17$: .WORD 0      ;ERROR FROM PUT SUB
132 034412 062716 000004 18$: ADD #4,(SP)      ;TRANSFER ERROR TO USER
133 034416 113776 034410 000000 MOVB 17$,a(SP)
134 034424 000550          BR      37$
135
136 034426 004737 040732 19$: JSR PC,TIMOUT    ;WAIT FOR COMMAND TO COMPLETE
137
138
139
140 034432 032737 000020 034756 :*****
:VERIFY PACK ACKNOWLEDGE IF #BIT4 SET IN TASK
141 034440 001427          BIT #BIT4,39$      ;VERIFY PACK ACKNOWLEDGE??
142          BEQ 25$          ;NO!!
143 034442 004737 040110 JSR PC,GET          ;GO GET STATUS
144 034446 000410          BR      22$          ;NO ERROR GETTING STATUS
145 034450 000401          BR      21$
146 034452 000000          20$: .WORD 0      ;ERROR FROM GET SUB
147 034454 062716 000004 21$: ADD #4,(SP)      ;TRANSFER ERROR TO USER
148 034460 113776 034452 000000 MOVB 20$,a(SP)
149 034466 000527          BR      37$
150
151 034470 004737 051026 22$: JSR PC,ACKSTS    ;GO CHECK ACKNOWLEDGE
152 034474 000411          BR      25$          ;NO ERROR
153 034476 000401          BR      24$
154 034500 000000          23$: .WORD 0      ;PACK ACKNOWLEDGE ERROR
155 034502 005726          24$: TST (SP)+      ;STRIP RETURN TO SUB AND
156 034504 062716 000004 ADD #4,(SP)          ;TRANSFER ERROR TO USER
157 034510 113776 034500 000000 MOVB 23$,a(SP)
158 034516 000513          BR      37$
159
160
161 :*****
162 :RECALIBRATE DRIVE IF BIT 11 IS SET IN TASK AND 'SKI' IS SET
163 :OR 'PIP' IS ACTIVE.
164 :RECALIBRATE DRIVE IF BIT 10 IS SET
165 034520 032737 002000 034756 25$: BIT #BIT10,39$    ;RECALIBRATE DRIVE ?
166 034526 001027          BNE 29$          ;YES!!
167 034530 032737 004000 034756 BIT #BIT11,39$      ;RECALIBRATE??
168 034536 001505          BEQ 38$          ;NO!!
169
170 034540 004737 040110 JSR PC,GET          ;GO GET RMDS
171 034544 000410          BR      28$          ;NO ERROR GETTING RMDS
    
```

```

172 034546 000401          BR      27$
173 034550 000000          .WORD  0          :ERROR FROM GET SUB
174 034552 062716 000004 26$:      ADD      #4,(SP)      :TRANSFER ERROR TO USER
175 034556 113776 034550 000000 27$:      MOVB     26$,@ (SP)
176 034564 000470          BR      37$
177
178 034566 032737 040000 034760 28$:      BIT      #SKI,40$      :WAS SKI SET ?
179 034574 001004          BNE     29$          :YES, GO RECALIBRATE
180 034576 032737 020000 001350          BIT      #PIP,RMDSI      :IS PIP ACTIVE??
181 034604 001462          BEQ     38$          :NO!!
182
183 034606 012737 000007 001412 29$:      MOV      #RECAL!GO,RMCS10      :LOAD RECALIBRATE COMMAND
184 034614 112737 000000 001555          MOVB     #RMCS1,PUTINX      :AND REGISTER INDEX
185 034622 112737 000200 001556          MOVB     #200,PUTINX+1      :SET TERMINATOR
186 034630 004737 040360          JSR      PC,PUT          :GO ISSUE RECALIBRATE
187 034634 000410          BR      31$          :NO ERROR
188 034636 000401          BR      30$
189 034640 000000          .WORD  0          :ERROR IN REGISTER TRANSFER
190 034642 062716 000004 30$:      ADD      #4,(SP)      :TRANSFER ERROR TO USER
191 034646 113776 034640 000000          MOVB     30$-2,@ (SP)
192 034654 000434          BR      37$
193
194 034656 004737 040732          JSR      PC,TIMOUT        :WAIT FOR COMPLETION
195
196          :*****
197          :VERIFY RECALIBRATE IF BIT 3 SET IN TASK
198 034662 032737 000010 034756          BIT      #BIT3,39$      :VERIFY RECALIBRATE??
199 034670 001430          BEQ     38$          :NO!!
200
201 034672 004737 040110          JSR      PC,GET          :GO GET STATUS
202 034676 000410          BR      34$          :NO ERROR GETTING STATUS
203 034700 000401          BR      33$
204 034702 000000          32$:      .WORD  0          :ERROR FROM GET
205 034704 062716 000004 33$:      ADD      #4,(SP)      :TRANSFER ERROR TO USER
206 034710 113776 034702 000000          MOVB     32$,@ (SP)
207 034716 000413          BR      37$
208
209 034720 004737 051622          JSR      PC,RCLSTS       :GO CHECK RECALIBRATE
210 034724 000412          BR      38$          :NO ERROR DURING RECALIBRATE
211 034726 000401          BR      36$
212 034730 000000          35$:      .WORD  0          :ERROR DURING RECALIBRATE
213 034732 005726          36$:      TST      (SP)+        :STRIP RETURN TO SUB AND
214 034734 062716 000004          ADD      #4,(SP)      :TRANSFER ERROR TO USER
215 034740 113776 034730 000000          MOVB     35$,@ (SP)
216 034746 162716 000002          37$:      SUB      #2,(SP)      :MOVE SP BACK BEFORE ERROR
217 034752 000240          38$:      NOP
218 034754 000207          RTS      PC          :RETURN TO USER
219
220 034756 000000          39$:      .WORD  0          :TASK/VERIFY DESCRIPTOR
221 034760 000000          40$:      .WORD  0          :CONTAINS RMER2
    
```

```

1      .SBTTL  BAD SECTOR MODULE
2
3      ;THE MODULE IS INTENDED TO BE CALLED PRIOR TO CALLING THE BUFFER
4      ;GENERATOR SUBROUTINE, AND PRESERVES THE 'PUT BUFFER' SO THAT THE
5      ;BUFFER NEED ONLY BE FILLED ONCE FOR THE EXECUTION OF A FORMAT
6      ;OPERATION.
7
8      ;THE MODULE RETURNS TO THE CALLING TEST WITH THE APPROVED OR ASSIGNED
9      ;SECTOR IN THE PUT BUFFER AND ALSO IN LOCATIONS 'ASNDA' AND 'ASNDC'
10     ;SO THAT A REFERENCE IS AVAILABLE TO THE TEST OUTSIDE OF THE PUT BUFFER.
11
12     ;THE BAD SECTOR MODULE PERFORMS TWO MAJOR FUNCTIONS:
13     (1) RECOVER THE BAD SECTOR FILES AND
14     (2) APPROVE THE USAGE OF A SECTOR BASED ON INFORMATION IN
15     THE BAD SECTOR FILES OR ASSIGN A NEW SECTOR IF THE ONE
16     ELECTED IS NOT AVAILABLE FOR USE.
17
18     ;INFORMATION REQUIRED BY THE MODULE INCLUDES:
19     (1) .RMDCO - THE DESIRED CYLINDER,
20     (2) .RMDAO - THE TRACK AND SECTOR ADDRESS,
21     (3) .RMCWC - THE WORD COUNT,
22     (4) .RMCS10 - THE COMMAND,
23     (5) .RMOFO - THE FORMAT MODE AND SKIP SECTOR ERROR INHIBIT.
24
25     ;CALL:
26     JSR      PC,BADSCT      ;CALL SUBROUTINE
27     BR       ???           ;RETURN HERE IF NO ERROR
28     TYPE     ,MESSAGE      ;RETURN HERE IF THE BAD SECTOR FILE
29     ;CANNOT BE RECOVERED.
30     ERROR   N              ;THE EMT OFFSET NUMBER 'N' IS DEFINED
31     ;BY BAD SECTOR MODULE.
32
33     BADSCT: ADD     #6,(SP)   ;CLEAR ERROR NUMBER IN USER'S
34             CLR8    @ (SP)   ;ERROR CALL.
35             SUB     #6,(SP)
36
37     ;TEST 'MEDIA ENABLE' TO DETERMINE WHETHER OR NOT THE BAD SECTOR FILES
38     ;HAVE BEEN RECOVERED.
39     TST     MEDENB         ;HAVE BAD SECTOR FILES BEEN RECOVERED ?
40     BEQ     1$            ;BR IF NO
41     JMP     56$           ;YES, BAD SECTOR FILE IS AVAILABLE
42
43     ;RECOVER SKIP SECTOR FILE FROM CYLINDER = 559., TRACK = 0 AND
44     ;RECOVER THE MANUFACTURES / USERS BAD SECTOR FILE FROM CYLINDER = 558.,
45     ;TRACK = LAST TRACK (RM80 = 13.). ALSO, SAVE THE USER'S PUT BUFFER
46     1$:
47     MOV     R0,-(SP)       ;;PUSH R0 ON STACK
48     CLR     R0             ;START WITH RMCS1
49     MOV     PUTBUF(R0),BUFFER(R0)
50     ADD     #2,R0          ;ADVANCE TO NEXT BUFFER POSITION
51     CMP     #46,R0        ;END OF BUFFER
52     BHS    2$             ;NO !!
53
54     ;SET RETRY COUNT AND LOAD PUT BUFFER AND REGISTER INDEX TABLE
55     ;SETUP PARAMETERS TO READ SKIP SECTOR FILE FIRST (3 SECTORS)
56     MOV     #3,74$        ;RETRY COUNT
57     MOV     #559.,RMDCO   ;DESIRED CYLINDER = 559.
    
```

BAD SECTOR MODULE

```

57 035050 012737 000000 001420      MOV      #0,RMDAO      ;STARTING TRACK = 0, SECTOR = 0
58 035056 012737 176372 001414      MOV      #-258,*3,RMWCO ;258. * 3 SECTORS (2'S COMP)
59 035064 012737 010000 001444      MOV      #FMT16,RMOFO  ;16 BIT FORMAT
60 035072 012737 105260 001416      MOV      #BUFTWO,RMBAO ;SETUP BUS ADDRESS TO READ SKIP SECTOR FILE
61
62 035100 012700 001555      MOV      #PUTINX,R0    ;R0 POINTS TO REGISTER INDEX TABLE
63 035104 112720 000006      MOV      #RMDA,(R0)+
64 035110 112720 000034      MOV      #RMDC,(R0)+
65 035114 112720 000002      MOV      #RMWC,(R0)+
66 035120 112720 000032      MOV      #RMOF,(R0)+
67 035124 112720 000004      MOV      #RMBA,(R0)+
68 035130 112720 000000      MOV      #RMCS1,(R0)+
69 035134 112720 000200      MOV      #200,(R0)+
70 035140 012600      MOV      (SP)+,R0      ;:FOP STACK INTO R0
71
72      ;SET GET INDEX TABLE FOR READING STATUS
73 035142      3$:
74 035142 004737 040024      JSR      PC,GETSTS    ;SETUP GET INDEX REGISTER FOR STATUS
75 035146 004737 040110      JSR      PC,GET      ;GET REGISTERS
76 035152 000411      BR      5$           ;BR IF NO ERROR
77 035154 000401      BR      4$           ;JUMP OVER ERROR NUMBER
78 035156 000000      .WORD   0           ;ERROR DEFINED BY GET SUB
79 035160 062716 000006      4$:      ADD      #6,(SP)     ;XFER ERROR TO USER AND
80 035164 113776 035156 000000      MOV      4$,2,@(SP)  ;GET ERROR NUMBER.
81 035172 000137 035766      JMP      42$
82
83 035176 013737 001400 037066      5$:      MOV      RMER2I,79$  ;GET RMER2 AND SAVE FOR LATER
84
85      ;CLEAR THE DEVICE USING DRIVE CLEAR COMMAND
86 035204 012737 000011 001412      MOV      #DRVCLR!GO,RMCS10 ;LOAD COMMAND IN PUT BUFFER
87 035212 004737 040360      JSR      PC,PUT      ;OUTPUT COMMAND
88 035216 000411      BR      8$           ;RETURN HERE IF NO ERROR
89 035220 000401      BR      7$           ;GET AROUND ERROR #
90 035222 000000      6$:      .WORD   0           ;ERROR # GOES HERE
91 035224 062716 000006      7$:      ADD      #6,(SP)     ;MOVE SP TO USERS ERROR CALL
92 035230 113776 035222 000000      MOV      6$,@ (SP)   ;MOVE ERROR NUMBER TO USER
93 035236 000137 035766      JMP      42$
94
95 035242 004737 040732      8$:      JSR      PC,TIMOUT   ;WAIT FOR COMPLETION
96 035246 004737 040110      JSR      PC,GET      ;GO GET STATUS
97 035252 000411      BR      11$          ;RETURN HERE IF NO ERROR
98 035254 000401      BR      10$          ;GET AROUND ERROR #
99 035256 000000      9$:      .WORD   0           ;ERROR # GOES HERE
100 035260 062716 000006      10$:     ADD      #6,(SP)     ;MOVE SP TO USERS ERROR CALL
101 035264 113776 035256 000000      MOV      9$,@ (SP)   ;MOVE ERROR # TO USERS ERROR CALL
102 035272 000137 035766      JMP      42$
103
104 035276 004737 053364      11$:     JSR      PC,DRVSTS   ;GO VERIFY DRIVE CLEAR COMMAND
105 035302 000412      BR      14$          ;RETURN HERE IF NO ERROR
106 035304 000401      BR      13$          ;GET AROUND ERROR
107 035306 000000      12$:     .WORD   0           ;ERROR # GOES HERE
108 035310 005726      13$:     TST      (SP)+      ;STRIP RETURN TO SUBROUTINE
109 035312 062716 000006      ADD      #6,(SP)     ;MOVE SP TO USERS ERROR CALL
110 035316 113776 035306 000000      MOV      12$,@ (SP)  ;MOVE ERROR # TO USER CALL
111 035324 000137 035766      JMP      42$
112
113      ;ISSUE A PACK ACKNOWLEDGE IF VOLUME VALID IS RESET

```

```
114 035330
115 035330 032737 000100 001350 14$: BIT #VV,RMDSI ;IS VV RESET ??
116 035336 001052 BNE 23$ ;NO !!
117
118 035340 012737 000023 001412 MOV #PACACK!GO,RMCS10 ;LOAD COMMAND
119 035346 004737 040360 JSR PC,PUT ;GO PUT COMMAND TO DRIVE
120 035352 000411 BR 17$ ;RETURN HERE IF NO OUTPUT ERROR
121 035354 000401 BR 16$ ;GET AROUND ERROR #
122 035356 000000 .WORD 0 ;ERROR # GOES HERE
123 035360 062716 000006 15$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
124 035364 113776 035356 000000 16$: MOVB 15$,a(SP) ;MOVE ERROR # TO ERROR CALL
125 035372 000137 035766 JMP 42$
126
127 035376 004737 040732 17$: JSR PC,TIMOUT ;WAIT FOR COMPLETION
128 035402 004737 040110 JSR PC,GET ;GO GET STATUS FOR PACK ACK
129 035406 000411 BR 20$ ;RETURN HERE IF NO ERROR
130 035410 000401 BR 19$ ;GET AROUND ERROR #
131 035412 000000 .WORD 0 ;ERROR # GOES HERE
132 035414 062716 000006 18$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
133 035420 113776 035412 000000 19$: MOVB 18$,a(SP) ;MOVE ERROR # TO CALL
134 035426 000137 035766 JMP 42$
135
136 035432 004737 051026 20$: JSR PC,ACKSTS ;GO VERIFY ACKNOWLEDGE STATUS
137 035436 000412 BR 23$ ;RETURN HERE IF NO ERROR
138 035440 000401 BR 22$ ;GET AROUND ERROR #
139 035442 000000 .WORD 0 ;ERROR # GOES HERE
140 035444 005726 21$: TST (SP)+ ;STRIP RETURN TO SUBROUTINE
141 035446 062716 000006 22$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
142 035452 113776 035442 000000 MOVB 21$,a(SP) ;MOVE ERROR # TO USERS ERROR CALL
143 035460 000137 035766 JMP 42$
144
145 ;RECALIBRATE THE DRIVE IF "SKI" OR "PIP IS SET
23$:
146 035464 BIT #SKI,79$ ;WAS SKI SET ?
147 035464 032737 040000 037066 BNE 24$ ;YES, GO RECALIBRATE
148 035472 001004 BIT #PIP,RMDSI ;IS PIP SET ??
149 035474 032737 020000 001350 BEQ 32$ ;NO !!
150 035502 001452
151
152 035504 012737 000007 001412 24$: MOV #RECAL!GO,RMCS10 ;LOAD RECALIBRATE COMMAND
153 035512 004737 040360 JSR PC,PUT ;PUT THE RECAL COMMAND
154 035516 000411 BR 26$ ;RETURN HERE IF NO ERROR
155 035520 000401 BR 25$ ;GET AROUND ERROR #
156 035522 000000 .WORD 0 ;ERROR # GOES HERE
157 035524 062716 000006 25$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
158 035530 113776 035522 000000 MOVB 25$-2,a(SP) ;MOVE ERROR # TO USERS CALL
159 035536 000137 035766 JMP 42$
160
161 035542 004737 040732 26$: JSR PC,TIMOUT ;WAIT FOR RECALIBRATE TO COMPLETE
162 035546 004737 040110 JSR PC,GET ;GO GET RECAL STATUS
163 035552 000411 BR 29$ ;RETURN HERE IF NO ERROR
164 035554 000401 BR 28$ ;GET AROUND ERROR #
165 035556 000000 .WORD 0 ;ERROR # GOES HERE
166 035560 062716 000006 27$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
167 035564 113776 035556 000000 28$: MOVB 27$,a(SP) ;MOVE ERROR TO USERS CALL
168 035572 000137 035766 JMP 42$
169
170 035576 004737 051622 29$: JSR PC,RCLSTS ;GO VERIFY RECALIBRATE STATUS
```

```

171 035602 000412          BR      32$          ;RETURN HERE IF NO ERROR
172 035604 000401          BR      31$          ;GET AROUND ERROR #
173 035606 000000          30$: .WORD 0          ;ERROR # GOES HERE
174 035610 005726          31$: TST (SP)+        ;STRIP RETURN TO SUBROUTINE
175 035612 062716 000006          ADD #6,(SP)        ;MOVE SP TO USERS ERROR CALL
176 035616 113776 035506 000000          MOVB 30$,a(SP)     ;MOVE ERROR # TO USERS CALL
177 035624 000137 035766          JMP 42$
178
179          ;READ THE SECTOR IDENTIFIED BY RMDAO, INCLUDING HEADER AND DATA
180 035630          32$:
181 035630 012737 000073 001412          MOV #RH!GO,RMCS10 ;LOAD READ HEADER AND DATA COMMAND
182 035636 004737 040360          JSR PC,PUT         ;PUT COMMAND
183 035642 000411          BR 35$            ;RETURN HERE IF NO ERROR
184 035644 000401          BR 34$            ;GET AROUND ERROR #
185 035646 000000          33$: .WORD 0          ;ERROR # GOES HERE
186 035650 062716 000006          34$: ADD #6,(SP)        ;MOVE SP TO USERS ERROR CALL
187 035654 113776 035646 000000          MOVB 33$,a(SP)     ;MOVE ERROR # TO USERS ERROR CALL
188 035662 000137 035766          JMP 42$
189
190 035666 004737 040732          35$: JSR PC,TIMOUT    ;WAIT FOR READ OPERATION TO COMPLETE
191 035672 004737 040110          JSR PC,GET         ;GO GET STATUS FOR READ OPERATION
192 035676 000411          BR 38$            ;RETURN HERE IF NO ERROR
193 035700 000401          BR 37$            ;GET AROUND ERROR #
194 035702 000000          36$: .WORD 0          ;ERROR # GOES HERE
195 035704 062716 000006          37$: ADD #6,(SP)        ;MOVE SP TO USERS ERROR CALL
196 035710 113776 035702 000000          MOVB 36$,a(SP)     ;MOVE ERROR # TO CALL
197 035716 000137 035766          JMP 42$
198
199 035722 004737 054166          38$: JSR PC,DTASTS    ;GO VERIFY RESULTS OF READ OPERATION
200 035726 000412          BR 41$            ;RETURN HERE IF NO ERROR
201 035730 000401          BR 40$            ;GET AROUND ERROR #
202 035732 000000          39$: .WORD 0          ;ERROR # GOES HERE
203 035734 005726          40$: TST (SP)+        ;STRIP RETURN ADDRESS TO SUBROUTINE
204 035736 062716 000006          ADD #6,(SP)        ;MOVE SP TO USERS ERROR CALL
205 035742 113776 035732 000000          MOVB 39$,a(SP)     ;MOVE ERROR # TO USERS CALL
206 035750 000137 035766          JMP 42$
207
208 035754 032737 040000 0C1336 41$: BIT #TRE,RMCS1I    ;ANY CONTROLLER ERRORS ?
209 035762 001001          BNE 42$           ;BR IF YES
210 035764 000477          BR 51$            ;NO ERRORS DETECTED
211
212          ;:*****
213          ;AN ERROR HAS BEEN DETECTED IN TRYING TO READ THE BAD SECTOR FILE.
214          ;THE SECTOR WILL BE RETRIED IF POSSIBLE.
215
216 035766 005337 037054          42$: DEC 74$        ;YES, DECREMENT RETRY COUNT AND
217 035772 001057          BNE 48$           ;RETRY IF COUNT IS POSITIVE
218
219          ;THE RETRY COUNT HAS EXPIRED - SEE IF THE ERROR IS MEDIA RELATED
220
221 035774 032737 100720 001352          BIT #DCK!HCRC!HCE!FER!ECH,RMER1I ;ANY MEDIA RELATED ERRORS ?
222 036002 001004          BNE 43$           ;YES, GO TRY NEXT AVAILABLE SECTOR
223
224 036004 032737 100040 001400          BIT #BSE!SSE,RMER2I ;ANY MEDIA RELATED ERRORS ?
225 036012 001453          BEQ 49$           ;NO, EXIT AND REPORT ERROR ON RETURN
226
227          ;THE ERRORS DETECTED WHILE TRYING TO RECOVER THE BAD SECTOR FILE ARE
    
```


BAD SECTOR MODULE

```

228
229
230
231 036014 032737 000040 001400 43$: BIT #SSE,RMER2I ;SSE ERROR ?
232 036022 001406 BEQ 44$ ;NO !!
233 036024 005237 001420 INC RMDAO ;DISPLACE SECTOR ADDRESS BY 1 TO
234 ;ACCOUNT FOR THE SKIP SECTOR ERROR
235 036030 052737 001000 001444 BIS #SSEI,RMOFO ;AND SET SSEI IN OFFSET REGISTER.
236 036036 000452 BR 47$ ;TRY AGAIN
237
238 036040 062737 000002 001420 44$: ADD #2,RMDAO ;ADVANCE SECTOR ADDRESS BY 2
239 036046 022737 001056 001446 CMP #558.,RMDCO ;READING DEC 144 BAD SECTOR FILE ?
240 036054 001407 BEQ 45$ ;YES !!
241 036056 005237 001420 INC RMDAO ;IF READING SSF, THEN ADVANCE SECTOR ADDRESS BY 1 MORE
242 036062 122737 000017 001420 CMPB #15.,RMDAO ;QUIT IF ALL SSF SECTORS HAVE BEEN
243 036070 101424 BLOS 49$ ;TRIED.
244 036072 000414 BR 47$
245
246 036074 022737 106264 001416 45$: CMP #MFGFIL,RMBAO ;READING MANUFACTURES BAD FILE ?
247 036102 001004 BNE 46$ ;NO !!
248 036104 122737 000012 001420 CMPB #10.,RMDAO ;QUIT IF ALL MFG SECTORS HAVE BEEN
249 036112 101413 BLOS 49$ ;TRIED.
250 036114 122737 000040 001420 46$: CMPB #32.,RMDAO ;QUIT IF ALL USER SECTORS HAVE BEEN
251 036122 101407 BLOS 49$ ;TRIED.
252
253 036124 012737 000003 037054 47$: MOV #3,74$ ;REINSTATE RETRY COUNT FOR THIS SECTOR
254 036132 162716 000006 48$: SUB #6,(SP) ;MOVE SP BACK TO NO ERROR
255 036136 000137 035142 JMP 3$ ;RETRY THE READ OPERATION
256
257 ;THE BAD SECTOR FILE CANNOT BE READ
258 036142 49$:
259 036142 000240 NOP
260 036144 032777 020000 143002 BIT #SW13,@SWR ;INHIBIT MESSAGE ?
261 036152 001002 BNE 50$ ;YES
262 036154 162716 000004 SUB #4,(SP) ;MOVE SP TO ERROR RETURN
263 036160 000137 037050 50$: JMP 73$ ;GO TO MODULE EXIT
264
265 ;THE SECTOR WAS RECOVERED WITHOUT ERROR - READ THE MFG/USER FILE IF
266 ;THIS IS THE SSF FILE OR ELSE DONE.
267 036164 51$:
268 036164 022737 001056 001446 CMP #558.,RMDCO ;READING DEC 144 FILES ?
269 036172 001422 BEQ 52$ ;YES !
270 036174 004737 037070 JSR PC,GETSSF ;GET SKIP SECTOR FILE FOR USE
271
272 036200 012737 001056 001446 MOV #558.,RMDCO ;READ DEC 144 FILE, CYLINDER 558.
273 036206 013737 001334 001420 MOV LSTRK,RMDAO ;MFG FILE LAST TRACK, SECTOR = 0
274 036214 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
275 036222 012737 106264 001416 MOV #MFGFIL,RMBAO ;POINT TO MANUFACTURES FILE BUFFER
276 036230 012737 177376 001414 MOV #-258.,RMWCO ;2 + 256. WORDS (2'S COMP)
277 036236 000415 BR 53$ ;GO READ MFG FILE
278 036240 52$:
279 036240 022737 107272 001416 CMP #USRFIL,RMBAO ;WAS THE USER FILE READ ??
280 036246 001416 BEQ 54$ ;YES - READ IS COMPLETE
281 036250 112737 000012 001420 MOVB #10.,RMDAO ;READ THE USER FILE LAST TRACK, SECTOR = 10.
282 036256 012737 107272 001416 MOV #USRFIL,RMBAO ;POINT TO USERS FILE BUFFER
283 036264 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
284

```

BAD SECTOR MODULE

```

285 036272 012737 000003 037054 53$:  MOV    #3,74$      ;RELOAD THE RETRY COUNT FOR THIS SECTOR
286 036300 000137 035142          JMP    3$          ;GO READ THE USER FILE
287
288          ;SET MEDIA ENABLE AND RESTORE THE USERS PUT BUFFER
289 036304          54$:
036304 010046          MOV    R0,-(SP)    ;;PUSH R0 ON STACK
036306 005000          CLR    R0          ;R0 IS REGISTER INDEX
290 036310 012737 177777 001512          MOV    #-1,MEDENB
291 036310 012737 177777 001512          MOV    BUFFER(R0),PUTBUF(R0)
292 036316 016060 104254 001412 55$:  ADD    #2,R0       ;ADVANCE R0
293 036324 062700 000002          CMP    #46,R0     ;DONE ??
294 036330 022700 000046          BHS   55$
295 036334 103370          MOV    (SP)+,R0   ;;POP STACK INTO R0
296 036336 012600
297
298          ;*****
299          ;VERIFY THAT THE DESIRED SECTOR IS NOT IN THE MFG BAD SECTOR FILE,
300          ;NOT IN THE USERS BAD SECTOR FILE AND NOT IN THE SSF BAD SECTOR FILE.
301          ;ASSIGN A NEW SECTOR IF THE SECTOR IS IN ANY OF THE FILES.
302          ;*****
303
304          ;LOAD INITIAL VARIABLES AND COMPUTE THE NUMBER OF SECTORS
305 036340          56$:
036340 010046          MOV    R0,-(SP)   ;PUSH R0 ON STACK
036342 010146          MOV    R1,-(SP)   ;PUSH R1 ON STACK
036344 010246          MOV    R2,-(SP)   ;PUSH R2 ON STACK
306 036346 013737 001446 001516          MOV    RMDCO,ASNDC ;LOAD REQUESTED CYLINDER, TRACK,
307 036354 013737 001420 001520          MOV    RMDAO,ASNDA ;AND SECTOR ADDRESS IN ASSIGNED STORAGE
308 036362 005002          CLR    R2         ;R2 = NUMBER OF SECTORS
309 036364 013700 001414          MOV    RMCWO,R0   ;R0 = WORD COUNT
310 036370 005400          NEG   R0          ;MAKE NUMBER POSITIVE
311 036372 012701 000400          MOV    #256,R1    ;R1 = NUMBER OF WORDS PER SECTOR
312 036376 032737 000002 001412          BIT    #BIT1,RMCS10 ;IS THIS A HEADER AND DATA COMMAND ??
313 036404 001402          BEQ   57$        ;NO !!
314 036406 012701 000402          MOV    #258,R1    ;CHANGE WORDS PER SECTOR
315 036412 020100          57$:  CMP    R1,R0      ;IS THERE A FULL SECTOR ??
316 036414 101404          BLOS  58$        ;YES !!
317 036416 005700          TST   R0         ;IS R0 ZERO ??
318 036420 001405          BEQ   59$        ;YES !!
319 036422 005202          INC   R2         ;INCREMENT FOR PARTIAL SECTOR
320 036424 000403          BR   59$
321 036426 160100          58$:  SUB    R1,R0      ;SUBTRACT ONE SECTOR FROM WORD COUNT
322 036430 005202          INC   R2         ;INCREMENT SECTOR COUNT
323 036432 000767          BR   57$
324 036434 010237 037054          59$:  MOV    R2,74$    ;SAVE SECTOR COUNT
325
326          ;LOAD PARAMETERS AND SEARCH THE MFG, USER AND THE MAPPED SSF BAD
327          ;SECTOR FILES FOR THE ASSIGNED SECTOR. ALSO, SEARCH THE ADJACENT
328          ;SECTORS IF THE SECTOR COUNT IS MORE THAN ONE.
329
330 036440 012737 106300 037064          MOV    #MFGFIL+14,78$ ;THE STARTING ADDRESS OF MFG FILE
331          ;TO BASE ADDRESS STORAGE.
332 036446 004737 036506          JSR   PC,60$     ;GO SEARCH FILE
333 036452 012737 107306 037064          MOV    #USRFIL+14,78$ ;LOAD STARTING ADDRESS OF USR FILE
334          ;TO BASE ADDRESS STORAGE.
335 036460 004737 036506          JSR   PC,60$     ;GO SEARCH FILE
336 036464 012737 110304 037064          MOV    #SSFIL+4,78$ ;LOAD STARTING ADDRESS OF MAPPED SSF
337          ;FILE TO BASE ADDRESS STORAGE.

```

BAD SECTOR MODULE

```

338 036472 005037 001514          CLR      SSFENB          ;ASSUME 'SSF' BIT IS NOT TO BE WRITTEN
339                                ;IN THE 1ST HEADER WORD.
340 036476 004737 036506          JSR      PC,60$         ;SEARCH SKIP SECTOR MAPPED FILE
341 036502 000137 037026          JMP      71$           ;DONE WITH ALL FILE SEARCHES !!
342
343 036506 013737 001516 037060 60$:  MOV      ASNDC,76$      ;LOAD COMPARING CYLINDER ADDRESS
344 036514 013737 001520 037062      MOV      ASNDA,77$      ;LOAD COMPARING TRACK, SECTOR ADDRESS
345 036522 013737 037054 037056      MOV      74$,75$       ;LOAD NUMBER OF SECTORS TO CONFIRM
346
347                                ;SETUP FOR A BINARY SEARCH OF THE CURRENT FILE FOR THE COMPARING
348                                ;CYLINDER, TRACK AND SECTOR ADDRESS
349
350 036530 013700 037064          61$:  MOV      78$,R0          ;LOAD THE BASE ADDRESS IN R0
351 036534 022710 177777          62$:  CMP      #-1,(R0)      ;IS THIS FILE TERMINATOR ?
352 036540 001462                                BEQ      67$             ;BR IF YES
353 036542 023710 037060          CMP      76$,(R0)      ;IS THIS CYLINDER IN BAD TABLE ?
354 036546 001014                                BNE      63$             ;BR IF NO
355
356                                ;FILE ENTRY EQUALS COMPARING CYLINDER. SEE IF THE NEXT ENTRY EQUALS
357                                ;THE COMPARING TRACK, AND SECTOR.
358
359 036550 123760 037063 000003      CMPB     77$+1,3(R0)    ;IS THIS TRACK IN BAD TABLE ?
360 036556 001010                                BNE      63$             ;BR IF NO
361
362 036560 123760 037062 000002      CMPB     77$,2(R0)     ;IS THIS SECTOR IN BAD TABLE ?
363 036566 001406                                BEQ      64$             ;BR IF YES
364 036570 002403                                BLT      63$             ;BR IF SECTOR IS LESS THAN TABLE ENTRY, ELSE
365 036572 012737 177777 001514      MOV      #-1,SSFENB    ;ENABLE 'SSF' BIT TO BE WRITTEN IN THE
366                                ;1ST HEADER WORD.
367
368 036600 022020          63$:  CMP      (R0)+,(R0)+    ;NO, ADJUST CYLINDER POINTER IN BAD FILE
369 036602 000754          BR      62$             ;AND CONTINUE SEARCH.
370
371                                ;THE COMPARING CYLINDER, TRACK AND SECTOR IS IN THE BAD SECTOR FILE.
372                                ;ADVANCE THE ASSIGNED SECTOR AND START THE SEARCH ALL OVER.
373 036604          64$:
374 036604 105237 001520          INCB     ASNDA          ;INCREMENT SECTOR
375 036610 032737 001000 001444      BIT      #SSEI,RMOFO    ;IS SSEI SET ?
376 036616 001405                                BEQ      65$             ;NO !!
377 036620 122737 000037 001520      CMPB     #31,ASNDA     ;SECTOR OK ?
378 036626 103327                                BHIS    60$             ;YES !!
379 036630 000404                                BR      66$
380 036632 122737 000036 001520 65$:  CMPB     #30,ASNDA     ;SECTOR OK ??
381 036640 103322                                BHIS    60$             ;YES !!
382 036642 105037 001520          66$:  CLRB     ASNDA          ;CLEAR SECTOR AND ADVANCE TRACK
383 036646 105237 001521          INCB     ASNDA+1
384 036652 123737 001335 001521      CMPB     LSTRK+1,ASNDA+1 ;TRACK OK ?
385 036660 103312                                BHIS    60$             ;YES !!
386 036662 005037 001520          CLR      ASNDA          ;CLEAR TRACK AND SECTOR
387 036666 005237 001516          INC      ASNDC          ;INCREMENT CYLINDER
388 036672 022737 001060 001516      CMP      #560,ASNDC    ;CYLINDER OK ??
389 036700 103302                                BHIS    60$             ;YES !!
390 036702 005726          TST      (SP)+          ;RESTORE STACK AND
391 036704 000450          BR      71$             ;GET OUT !!
392
393                                ;THE COMPARING SECTOR IS NOT IN THE BAD SECTOR FILES. DECREMENT THE
394                                ;NUMBER OF SECTORS TO COMPARE AND SEARCH THE NEXT SECTOR IF THE NUMBER

```

```

395                                     ;IS NOT ZERO.
396 036706                             67$:
397 036706 005337 037056                DEC    75$      ;DECREMENT NUMBER OF SECTORS TO COMPARE
398 036712 001456                        BEQ    73$      ;DONE IF ZERO
399
400 036714 105237 037062                INCB   77$      ;INCREMENT THE COMPARING SECTOR
401 036720 032737 001000 001444        BIT    #SSEI,RMOFO ;IS SSEI SET ?
402 036726 001405                        BEQ    68$      ;NO !!
403 036730 122737 000037 037062        CMPB  #31.,77$  ;SECTOR OK ?
404 036736 103032                        BHIS  70$      ;YES !!
405 036740 000404                        BR    69$
406 036742 122737 000036 037062 68$:  CMPB  #30.,77$  ;SECTOR OK ??
407 036750 103025                        BHIS  70$      ;YES !!
408 036752 105037 037062                CLRB  77$      ;CLEAR SECTOR
409 036756 105237 037063                INCB  77$+1    ;INCREMENT TRACK
410 036762 123737 001335 037063        CMPB  LSTRK+1,77$+1 ;TRACK OK ??
411 036770 103015                        BHIS  70$      ;YES !!
412 036772 005037 037062                CLR   77$      ;CLEAR SECTOR TRACK
413 036776 005237 037060                INC   76$      ;INCFEMENT CYLINDER
414 037002 022737 001060 037060        CMP   #560.,76$ ;CYLINDER OK ??
415 037010 103005                        BHIS  70$      ;YES !!
416 037012 013737 037060 001446        MOV   76$,RMDCO ;LOAD CYLINDER
417 037020 005726                        TST   (SP)+    ;RESTORE STACK AND
418 037022 000407                        BR    72$      ;GET OUT !!
419
420 037024 000641                         70$:  BR    61$      ;SEARCH NEXT SECTOR
421
422                                     ;ASSIGN THE SECTOR AND RETURN TO USER
423 037026                             71$:
424 037026 013737 001516 001446        MOV   ASNDC,RMDCO ;LOAD CYLINDER
425 037034 013737 001520 001420        MOV   ASNDA,RMDAO ;LOAD TRACK AND SECTOR
426 037042
    037042 012602                         72$:  MOV   (SP)+,R2    ;:POP STACK INTO R2
    037044 012601                         MOV   (SP)+,R1    ;:POP STACK INTO R1
    037046 012600                         MOV   (SP)+,R0    ;:POP STACK INTO R0
427
428 037050 000240                         73$:  NOP
429 037052 000207                        RTS    PC
430
431                                     ;THE FOLLOWING ARE STORAGE LOCATIONS FOR THE MODULE
432
433 037054 000000                         74$:  .WORD 0      ;RETRY COUNT/ NUMBER OF SECTORS REQUIRED
434 037056 000000                         75$:  .WORD 0      ;NUMBER OF SECTORS TO COMPARE
435 037060 000000                         76$:  .WORD 0      ;COMPARING CYLINDER
436 037062 000000                         77$:  .WORD 0      ;COMPARING TRACK AND SECTOR
437 037064 000000                         78$:  .WORD 0      ;BASE ADDRESS OF BAD SECTOR FILE BEING SEARCHED
438 037066 000000                         79$:  .WORD 0      ;CONTAINS RMR2
439
440                                     ;THIS ROUTINE SEARCHES THE SKIP SECTOR FILE FOR ANY BAD SECTORS
441                                     ;WHICH OCCUR ON THE FE CYLINDERS. THE BAD SECTORS ARE THEN MAPPED
442                                     ;INTO A 'SSFIL' TABLE TO BE USED BY THE 'BADSC' ROUTINE.
443
444 037070
    037070 010046                         GETSSF: MOV   R0,-(SP)    ;:PUSH R0 ON STACK
    037072 010146                         MOV   R1,-(SP)    ;:PUSH R1 ON STACK
445 037074 012700 105260                 MOV   #BUFTWO,R0  ;:R0 = POINTER TO BUFFER
446 037100 012701 110300                 MOV   #SSFIL,R1   ;:R1 = POINTER TO SKIP SECTOR TABLE
    
```

BAD SECTOR MODULE

```

447 037104 012021      MOV      (R0)+,(R1)+      ;SAVE HEADER WORD 0(CYL ADDRESS)
448 037106 012021      MOV      (R0)+,(R1)+      ;SAVE HEADER WORD 1(TRK/SEC ADDRESS)
449
450 037110 012721 177777      1$:      MOV      #-1,(R1)+      ;INITIALIZE 'SSFIL' TABLE
451 037114 022701 110374      CMP      #SSFIL+60.,R1    ;DONE ?
452 037120 001373      BNE      1$              ;BR IF NO
453
454 037122 012701 110304      MOV      #SSFIL+4,R1      ;SETUP TO MAP SSFIL TABLE
455 037126 062700 000026      ADD      #22.,R0          ;GET OVER S/N(2), CREATE DATE, REV DATE, REV#,
456                                     ;FORMAT TYPE, UNUSED WORDS(3), ENTRY# AND
457                                     ;CHECKSUM (11. WORDS)
458 037132 021027 001057      2$:      CMP      (R0),#559.      ;IS CYLINDER IN FE AREA ?
459 037136 103410      BLO      4$              ;NO !!
460 037140 101004      BHI      3$              ;YES, ON CYLINDER 560.
461                                     ;YES, WHEN ON CYLINDER 559. DO NOT LOG
462                                     ;ANY BAD SECTORS THAT OCCUR ON THE SKIP
463                                     ;SECTOR TRACK(0) OR ALTERNATE DEC144 TRACK(1)
464 037142 126027 000003 000001      CMPB     3(R0),#1        ;IS IT ON TRACK 0 OR 1 ?
465 037150 003403      BLE      4$              ;YES !!
466 037152 011021      3$:      MOV      (R0),(R1)+      ;LOG THIS CYLINDER AND
467 037154 016021 000002      MOV      2(R0),(R1)+      ;TRACK/SECTOR IN 'SSFIL' TABLE.
468
469 037160 022020      4$:      CLD      (R0)+,(R0)+      ;ADJUST BUFFER TO NEXT CYLINDER ENTRY
470 037162 020127 110374      CMP      R1,#SSFIL+60.    ;ANY MORE ENTRIES AVAILABLE IN TABLE ?
471 037166 103003      BHS      5$              ;NO, EXIT !!
472 037170 020027 110274      CMP      R0,#BUFTWO+1548. ;DONE WITH ALL 3 SECTORS ?
473 037174 103756      BLO      2$              ;NO, DO NEXT ENTRY
474
475 037176 012737 177777 107270      5$:      MOV      #-1,MFGFIL+516. ;RESTORE TERMINATOR TO MFGFIL
476 037204 000240      NOP
477 037206 012601      MOV      (SP)+,R1          ;;POP STACK INTO R1
478 037210 012600      MOV      (SP)+,R0          ;;POP STACK INTO R0
478 037212 000207      RTS      PC

```

BUFFER GENERATOR SUBROUTINE

.SBTTL BUFFER GENERATOR SUBROUTINE

:THIS SUBROUTINE GENERATES A DATA BUFFER FOR WRITE COMMANDS. THE
 :BUFFER STARTS AT RMBA AND IS RMWC WORDS LONG. THE BUFFER
 :CONTAINS A REPETITIVE DATA PATTERN CONSISTING OF \$TMP1 WORDS
 :FROM THE DATA PATTERN TABLE, BEGINNING AT ADDRESS \$TMP0.
 :HEADER INFORMATION FOR THE BUFFER IS EXTRACTED FROM RMDC,
 :RMDA AND RMOF.

:R0 = ADDRESS OF DATA BUFFER
 :R1 = LENGTH OF DATA BUFFER
 :R2 = ADDRESS OF DATA PATTERN
 :R3 = LENGTH OF DATA PATTERN
 :R4 = SECTOR COUNT

:CALL:
 :(1) JSR PC,GENBUF
 :(2) ?? RETURN HERE

GENBUF:

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52

```

037214      010046      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
037216      010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
037220      010246      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
037222      010346      MOV      R3,-(SP)      ;;PUSH R3 ON STACK
037224      010446      MOV      R4,-(SP)      ;;PUSH R4 ON STACK
21 037226      013700      001416      MOV      RMBAD,R0      ;;LOAD DATA BUFFER ADDRESS
22 037232      013701      001414      MOV      RMWCO,R1      ;;LOAD WORD COUNT
23 037236      013737      001446      037456      MOV      RMDCO,7$      ;;LOAD STARTING CYLINDER ADDRESS
24 037244      013737      001420      037460      MOV      RMDAO,8$      ;;LOAD STARTING TRACK,SECTOR ADDRESS
25
26 037252      032737      000002      001412      1$:      BIT      #BIT1,RMCS10      ;;WRITE HEADER & DATA??
27 037260      001451      BEQ      3$              ;;NO!!
28 037262      013710      037456      MOV      7$(R0);WRITE  ;;WRITE HEADER WORD #1
29 037266      052710      140000      BIS      #MSE!USE,(R0)  ;;SET BAD SECTOR FLAGS FOR GOOD SECTOR
30 037272      012702      000035      MOV      #29.,R2        ;;R2 = MAXIMUM SECTOR ADDRESS (29.)
31
32 037276      032737      010000      001444      BIT      #FMT16,RMOFO    ;;18 BIT FORMAT??
33 037304      001410      BEQ      2$              ;;YES !!
34 037306      052710      010000      BIS      #FMT16,(R0)    ;;SET 16 FORMAT BIT IN HEADER
35 037312      005202      INC      R2              ;;CHANGE MAXIMUM SECTOR ADDRESS (30.)
36
37 037314      032737      001000      001444      BIT      #SSEI,RMOFO    ;;IS SSEI SET TO ACCESS ALL SECTORS ?
38 037322      001401      BEQ      2$              ;;NO !!
39 037324      005202      INC      R2              ;;CHANGE MAXIMUM SECTOR ADDRESS (31.)
40
41 037326      005201      2$:      INC      R1              ;;INCREMENT WORD COUNT
42 037330      001443      BEQ      6$              ;;EXIT IF DONE
43
44 037332      005720      TST      (R0)+          ;;MOVE R0 TO HEADER WORD #2
45 037334      013720      037460      MOV      8$(R0)+      ;;WRITE HEADER WORD #2
46 037340      005201      INC      R1              ;;INCREMENT WORD COUNT AND
47 037342      001436      BEQ      6$              ;;EXIT IF DONE
48 037344      012703      037460      MOV      #8$,R3        ;;ADVANCE SECTOR ADDRESS
49 037350      105213      INCB     (R3)
50 037352      120213      CMPB    R2,(R3)        ;;SECTOR OVERFLOW ??
51 037354      103013      BHIS   3$              ;;NO !!
52 037356      105013      CLRB   (R3)            ;;YES - CLEAR SECTOR ADDRESS
    
```

53	037360	105263	000001		INCB	1(R3)	:ADVANCE TRACK ADDRESS
54	037364	123763	001335	000001	CMPB	LSTRK+1,1(R3)	:TRACK OVERFLOW ??
55	037372	103004			BHIS	3\$:NO !!
56	037374	105063	000001		CLRB	1(R3)	:YES - CLEAR TRACK ADDRESS
57	037400	105237	037456		INCB	7\$:ADVANCE CYLINDER ADDRESS
58	037404	012704	000400	3\$:	MOV	#256.,R4	:LOAD SECTOR DATA COUNT
59	037410	013702	001174	4\$:	MOV	\$TMP0,R2	:LOAD PATTERN ADDRESS
60	037414	013703	001176		MOV	\$TMP1,R3	:LOAD PATTERN COUNT
61	037420	012220		5\$:	MOV	(R2)+,(R0)+	:WRITE DATA PATTERN
62	037422	005201			INC	R1	:INCREMENT WORD COUNT AND
63	037424	001405			BEQ	6\$:EXIT IF DONE
64	037426	005304			DEC	R4	:DECREMENT SECTOR COUNT
65	037430	001710			BEQ	1\$:START NEXT SECTOR IF 0
66	037432	005303			DEC	R3	:DECREMENT PATTERN COUNT
67	037434	001765			BEQ	4\$:RESTART PATTERN IF 0
68	037436	000770			BR	5\$:CONTINUE DATA PATTERN
69	037440			6\$:			
	037440	012604			MOV	(SP)+,R4	::POP STACK INTO R4
	037442	012603			MOV	(SP)+,R3	::POP STACK INTO R3
	037444	012602			MOV	(SP)+,R2	::POP STACK INTO R2
	037446	012601			MOV	(SP)+,R1	::POP STACK INTO R1
	037450	012600			MOV	(SP)+,R0	::POP STACK INTO R0
70	037452	000240			NOP		
71	037454	000207			RTS	PC	
72							
73	037456	000000		7\$:	.WORD		:CYLINDER ADDRESS STORAGE
74	037460	000000		8\$:	.WORD		:TRACK, SECTOR ADDRESS STORAGE

COMPARE BUFFER SUBROUTINE

```

1      .SBTTL COMPARE BUFFER SUBROUTINE
2
3      :THIS SUBROUTINE COMPARES THE CONTENTS OF BUFONE AND BUFTWO,
4      :ASSUMING THAT BUFONE IS THE BUFFER FROM WHICH DATA WAS WRITTEN
5      :AND BUFTWO IS THE BUFFER TO WHICH DATA WAS READ. ERRORS IN BUFFER
6      :COMPARISON ARE REPORTED TO THE USER VIA THE USER'S ERROR CALL.
7
8      :CALL:
9      : (1) JSR PC,CMPBUF
10     : (2) .WORD WRITE BUFFER ADDRESS
11     : (3) .WORD READ BUFFER ADDRESS
12     : (4) BR ?? RETURN HERE IF NO ERROR
13     : (5) NOP RETURN HERE IF ERROR
14     : (6) ERROR ERROR DEFINED BY SUBROUTINE
15     : (7) ???
16
17     CMPBUF:
18     037462 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
19     037464 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
20     037466 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
21     037470 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
22     037472 005037 040022 CLR 14$ ;;CLEAR CORRECTION FLAG
23
24     :DETERMINE IF DATA SHOULD BE CORRECTED
25     037476 033737 004000 001370 BIT ECI,RMOFI ;;WAS ECC CORRECTION ALLOWED ??
26     037504 001063 BNE 9$ ;;NO !!
27     037506 032737 100000 001352 BIT #DCK,RMER1I ;;WAS THERE A DATA CHECK ??
28     037514 001457 BEQ 9$ ;;NO !!
29     037516 032737 000100 001352 BIT #ECH,RMER1I ;;IS ERROR CORRECTION HARD SET ?
30     037524 001053 BNE 9$ ;;YES !!
31     037526 032737 010000 001370 BIT #FMT16,RMOFI ;;IS THIS 16 BIT FORMAT ??
32     037534 001447 BEQ 9$ ;;NO !!
33
34     :CORRECT DATA USING ECC INFORMATION
35     037536 013700 001416 MOV RMBAD,R0 ;;R0 = STARTING BUFFER ADDRESS
36     037542 013701 001402 MOV RMECI,R1 ;;R1 = ECC POSITION
37     037546 052737 100000 040022 BIS #BIT15,14$ ;;SET CORRECTION FLAG
38
39     :MOVE R0 TO WORD BOUNDARY OF ERROR BURST
40     1$: CMP #16.,R1 ;;IS BIT POSITION > 1 WORD
41     BHS 2$ ;;NO !!
42     SUB #16.,R1 ;;SUBTRACT 1 WORDS WORTH
43     TST (R0)+ ;;ADVANCE BUFFER ADDRESS 1 WORD
44     BR 1$
45     2$: MOV #1,R2 ;;R2 = BIT POINTER
46     MOV R2,R3 ;;R3 = BIT NUMBER
47
48     :MOVE R2 TO STARTING BIT OF ERROR BURST
49     3$: CMP R3,R1 ;;IS R3 SAME AS R1 ??
50     BEQ 4$ ;;YES !!
51     ASL R2 ;;SHIFT BIT POINTER
52     INC R3 ;;INCREMENT BIT NUMBER
53     BR 3$
54     4$: MOV #11.,R3 ;;R3 = LENGTH OF ERROR BURST
55
56     :CORRECT THE ERROR BURST
57     5$: BIT R2,RMEC2I ;;IS THIS BIT SET IN ECC PATTERN ??

```


COMPARE BUFFER SUBROUTINE

```

54 037622 001405          BEQ      7$          ;NO - DO NOT CORRECT THIS BIT
55 037624 030210          BIT      R2,(R0)      ;IS THE BIT PRESENTLY SET ??
56 037626 001402          BEQ      6$          ;NO
57 037630 040210          BIC      R2,(R0)      ;RESET THE BIT
58 037632 000401          BR       7$
59 037634 050210          6$:    BIS      R2,(R0)      ;SET THE BIT
60 037636 006302          7$:    ASL      R2          ;SHIFT TO NEXT BIT
61 037640 001003          BNE
62 037642 012702 000001  MOV      #1,R2          ;CONTINUE WITH FIRST BIT OF NEXT WORD
63 037646 005720          TST     (R0)+
64 037650 005303          8$:    DEC      R3          ;END OF BURST ??
65 037652 001361          BNE     5$          ;NO !!
66
67          ;COMPARE WRITE BUFFER TO READ BUFFER
68 037654 017600 000010  9$:    MCV      @10(SP),R0      ;R0 = WRITE BUFFER
69 037660 062766 000002 000010  ADD      #2,10(SP)        ;MOVE SP TO READ ADDRESS
70 037666 017601 000010          MOV      @10(SP),R1      ;R1 = READ BUFFER
71 037672 062766 000002 000010  ADD      #2,10(SP)        ;MOVE SP TO RETURN ADDRESS
72 037700 013702 001340          MOV      RMWCI,R2        ;R2 = NUMBER OF WORDS TRANSFER
73 037704 163702 001414          SUB      RMWCO,R2
74 037710 022021          10$:   CMP      (R0)+,(R1)+    ;COMPARE DATA WORDS
75 037712 001003          BNE     11$          ;EXIT IF NOT EQUAL
76 037714 005302          DEC     R2          ;DECREMENT WORD COUNT
77 037716 001374          BNE     10$         ;CONTINUE IF NOT DONE
78 037720 000433          BR      13$         ;DONE COMPARE - NO ERROR
79
80          ;DATA COMPARE FAILED
81 037722 014037 001140  11$:   MOV      -(R0),%GDDAT    ;STORE GOOD DATA FOR TYPEOUT
82 037726 014137 001142          MOV      -(R1),%BDDAT    ;STORE BAD DATA FOR TYPEOUT
83 037732 010037 001134          MOV      R0,%GDADR       ;STORE ADDRESS OF GOOD DATA
84 037736 010137 001136          MOV      R1,%BDADR       ;STORE ADDRESS OF BAD DATA
85 037742 010237 001174          MOV      R2,%TMP0        ;STORE WORD COUNT OF ERROR
86 037746 062766 000004 000010  ADD      #4,10(SP)        ;MOVE SP TO USER'S ERROR CALL
87 037754 112776 000336 000010  MOV     #336,@10(SP)     ;WRITE ERROR NUMBER IN CALL
88
89          ;CHANGE ERROR NUMBER IF ECC CORRECTION FAILED
90 037762 032737 100000 040022  BIT      #BIT15,14$      ;WAS ECC CORRECTION USED ??
91 037770 001403          BEQ     12$          ;NO !!
92 037772 112776 000163 000010  MOV     #163,@10(SP)    ;ECC CORRECTION FAILED
93 040000 162766 000002 000010  12$:   SUB      #2,10(SP)      ;MOVE SP TO RETURN IF ERROR
94 040006 000240          NOP
95 040010          13$:   MOV      (SP)+,R3        ;;POP STACK INTO R3
          MOV      (SP)+,R2        ;;POP STACK INTO R2
          MOV      (SP)+,R1        ;;POP STACK INTO R1
          MOV      (SP)+,R0        ;;POP STACK INTO R0
96 040020 000207          RTS      PC          ;RETURN TO USER
97
98 040022 000000          14$:   .WORD          ;ECC CORRECTION FLAG

```

GET STATUS SUBROUTINE

```

1
2
3
4
5
6
7
8
9
10 040024
11 040024 010046
12 040026 010146
13 040030 010246
14 040032 012700 001526
15 040036 012701 001406
16 040042 012702 000046
17 040046 110220
18 040050 005041
19 040052 162702 000002
20 040056 100405
21 040060 022702 000022
22 040064 001370
23 040066 005041
24 040070 000770
25 040072 112720 000200
26 040076 012602
27 040100 012601
28 040102 012600
29 040104 000240
30 040106 000207
    
```

.SBTTL GET STATUS SUBROUTINE

```

:THIS SUBROUTINE SETS UP THE 'GET INDEX TABLE' AND THE 'GET
:BUFFER' FOR READING ALL SUBSYSTEM REGISTERS VIA THE GET SUBROUTINE
:AND THEN RETURNS TO THE USER.
    
```

```

:CALL: JSR PC,GETSTS
:      ??? RETURN HERE
    
```

```

GETSTS:
MOV R0,-(SP)      ;;PUSH R0 ON STACK
MOV R1,-(SP)      ;;PUSH R1 ON STACK
MOV R2,-(SP)      ;;PUSH R2 ON STACK
MOV #GETINX,R0    ;R0 = ADDRESS OF INDEX TABLE
MOV #RMEC2I+2,R1 ;R1 = ADDRESS OF GET BUFFER
MOV #RMEC2,R2     ;R2 = REGISTER INDE
1$: MOVB R2,(R0)+ ;WRITE REGISTER INDEX IN TABLE
   CLR -(R1)      ;CLEAR CORRESPONDING LOCATION
2$: SUB #2,R2     ;DECREMENT TO NEXT INDEX
   BMI 3$        ;BRANCH OUT IF DONE
   CMP #RMDB,R2  ;DONT WRITE RMDB INDEX
   BNE 1$
   CLR -(R1)
   BR 2$
3$: MOVB #200,(R0)+ ;WRITE TERMINATOR
   MOV (SP)+,R2   ;;POP STACK INTO R2
   MOV (SP)+,R1   ;;POP STACK INTO R1
   MOV (SP)+,R0   ;;POP STACK INTO R0
NOP
RTS PC
    
```

GET SUBROUTINE

.SBTTL GET SUBROUTINE

:THIS SUBROUTINE READS THE REGISTERS WHICH ARE LISTED IN THE
 : "GET INDEX TABLE" AND STORES THEIR VALUES IN THE CORRESPONDING
 : LOCATION IN THE "GET REGISTER BUFFER". FOR EXAMPLE, AN
 : ENTRY OF 04 IN THE TABLE WILL CAUSE THE SUBROUTINE TO
 : READ "RMA" AND STORE ITS CONTENTS AT THE LOCATION IN
 : THE BUFFER ASSIGNED TO THAT REGISTER. THE NUMBER OF
 : REGISTERS TO BE READ IS VARIABLE FROM 1 TO 22; THE INDEX
 : TABLE MUST BE TERMINATED WITH A CONTROL BYTE (200)
 : WHICH SHOULD FOLLOW THE LAST ENTRY.

:SUBROUTINE CALL:

- (1) "GET INDEX TABLE" HAS BEEN LOADED WITH REGISTER INDEX
VALUES AND TERMINATED WITH A CONTROL BYTE
- (2) "GET INPUT BUFFER" IS AVAILABLE FOR USE. (NOTE THAT
UNUSED LOCATIONS, I.E., ENTRIES IN BUFFER CORRESPONDING
TO REGISTERS NOT READ, ARE NOT CHANGED.)
- (3) JSR PC,GET
BR ??? RETURN HERE IF NO ERROR FOUND
NOP RETURN HERE IF ANY ERROR FOUND
ERROR SUB DEFINES ERROR NUMBER
???

:R0 = REGISTER BASE ADDRESS
 :R1 = REGISTER ADDRESS
 :R2 = BUFFER BASE ADDRESS
 :R3 = BUFFER ADDRESS
 :R4 = POINTER TO REGISTER INDEX

```

GET:  NOP
      ADD #4,(SP) ;CLEAR ERROR NUMBER IN USER'S
      CLRB @ (SP) ;ERROR CALL
      SUB #4,(SP)
      MOV R0,-(SP) ;:PUSH R0 ON STACK
      MOV R1,-(SP) ;:PUSH R1 ON STACK
      MOV R2,-(SP) ;:PUSH R2 ON STACK
      MOV R3,-(SP) ;:PUSH R3 ON STACK
      MOV R4,-(SP) ;:PUSH R4 ON STACK
      MOV ERRVEC,-(SP) ;:PUSH ERRVEC ON STACK
      MOV ERRVEC+2,-(SP) ;:PUSH ERRVEC+2 ON STACK
      MOV $BASE,R0
      MOV #GETBUF,R2
      MOV #GETINX,R4
      MOV #3$,ERRVEC ;:SETUP FOR TIMEOUT
      MOV #PR6,ERRVEC+2
      1$: MOV RMCS2(R0),$TMP0 ;GET 'NED' STATUS
      MOV RMCS1(R0),$TMP1 ;GET 'DVA' STATUS
      BIT #DVA,$TMP1 ;DEVICE AVAILABLE??
      BNE 2$ ;YES!!
      ADD #4,16(SP) ;WRITE ERROR NUMBER IN USER'S
      MOVB #112,@16(SP) ;ERROR CALL
      BR 4$
      2$: TSTB (R4) ;DONE??
      BMI 6$ ;YES!!
      MOVB (R4),R1 ;R1 = REGISTER ADDRESS
      BIC #^CIDXMSK,R1 ;CLEAR ANY SIGN EXTENSION
    
```

1							
2							
3							
4							
5							
6							
7							
8							
9							
10							
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
21							
22							
23							
24							
25							
26							
27							
28							
29							
30							
31	040110	000240					
32	040112	062716	000004				
33	040116	105076	000000				
34	040122	162716	000004				
35	040126	010046					
	040130	010146					
	040132	010246					
	040134	010346					
	040136	010446					
	040140	013746	000004				
	040144	013746	000006				
36	040150	013700	001276				
37	040154	012702	001336				
38	040160	012704	001526				
39	040164	012737	040272	000004			
40	040172	012737	000300	000006			
41	040200	016037	000010	001174	1\$:		
42	040206	016037	000000	001176			
43	040214	032737	004000	001176			
44	040222	001007					
45	040224	062766	000004	000016			
46	040232	112776	000112	000016			
47	040240	000423					
48	040242	105714			2\$:		
49	040244	100433					
50	040246	111401					
51	040250	042701	177700				

SET SUBROUTINE

```

52 040254 060001          ADD    R0,R1
53 040256 112403          MOVB  (R4)+,R3      ;R3 = STORAGE ADDRESS FOR REGISTER
54 040260 042703 177700  BIC   #^CIDXMSK,R3 ;CLEAR ANY SIGN EXTENSION
55 040264 060203          ADD    R2,R3
56 040266 011113          MOV   (R1),(R3)    ;READ REGISTER
57 040270 000764          BR    2$
58
59 040272 022626          3$:   CMP   (SP)+,(SP)+  ;RESTORE STACK
60 040274 062766 000004 000016  ADD   #4,16(SP)    ;WRITE ERROR NUMBER IN
61 040302 112776 000007 000016  MOVB  #7,@16(SP)  ;USER'S ERROR CALL
62 040310 162766 000002 000016  4$:   SUB   #2,16(SP)
63 040316 105714          5$:   TSTB  (R4)        ;DONE CLEARING??
64 040320 100405          BMI   6$          ;YES!!
65 040322 005003          CLR   R3          ;CLEAR REMAINING STORAGE
66 040324 112403          MOVB  (R4)+,R3    ;LOCATIONS
67 040326 060203          ADD   R2,R3
68 040330 005013          CLR   (R3)
69 040332 000771          BR    5$
70 040334          6$:
   040334 012637 000006          MOV   (SP)+,ERRVEC+2  ;;POP STACK INTO ERRVEC+2
   040340 012637 000004          MOV   (SP)+,ERRVEC   ;;POP STACK INTO ERRVEC
   040344 012604          MOV   (SP)+,R4      ;;POP STACK INTO R4
   040346 012603          MOV   (SP)+,R3      ;;POP STACK INTO R3
   040350 012602          MOV   (SP)+,R2      ;;POP STACK INTO R2
   040352 012601          MOV   (SP)+,R1      ;;POP STACK INTO R1
   040354 012600          MOV   (SP)+,R0      ;;POP STACK INTO R0
71 040356 000207          RTS   PC          ;RETURN

```

.SBTTL PUT SUBROUTINE

: THIS SUBROUTINE WRITES THE REGISTERS WHICH ARE LISTED IN THE
: 'PUT INDEX TABLE' WITH THE CONTENTS OF THE CORRESPONDING
: LOCATION IN THE 'PUT REGISTER BUFFER'. THE NUMBER OF
: REGISTERS WRITTEN IS VARIABLE; THE INDEX TABLE MUST
: BE TERMINATED WITH A CONTROL BYTE (200) WHICH SHOULD
: FOLLOW THE LAST ENTRY.

: SUBROUTINE CALL:

- (1) 'PUT INDEX TABLE' HAS BEEN LOADED WITH INDEX VALUES OF REGISTERS TO BE WRITTEN.
- (2) 'PL REGISTER BUFFER' CONTAINS CONTENTS OF EACH REGISTER TO BE WRITTEN.
- (3) JSR PC,PUT
BR ??? RETURN HERE IF NO ERROR FOUND
NOP RETURN HERE IF ANY ERROR FOUND
ERROR SUB DEFINES ERROR NUMBER
???

:R0 = REGISTER BASE ADDRESS
:R1 = REGISTER ADDRESS
:R2 = BUFFER BASE ADDRESS
:R3 = BUFFER ADDRESS
:R4 = POINTER TO REGISTER INDEX

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51

040360	000240		
040362	010046		
040364	010146		
040366	010246		
040370	010346		
040372	010446		
040374	013746	000004	
040400	013746	000006	
040404	013700	001276	
040410	012702	001412	
040414	012704	001555	
040420	012737	040540	000004
040426	012737	000300	000006
040434	016037	000010	001174
040442	016037	000000	001176
040450	032737	004000	001176
040456	001007		
040460	062766	000004	000016
040466	112776	000112	000016
040474	000430		
040476	105714		
040500	100431		
040502	111401		
040504	042701	177700	
040510	060001		
040512	111403		
040514	042703	177700	
040520	060203		
040522	011311		
040524	122714	000032	

```

PUT:  NOP
      MOV R0,-(SP)      ;;PUSH R0 ON STACK
      MOV R1,-(SP)      ;;PUSH R1 ON STACK
      MOV R2,-(SP)      ;;PUSH R2 ON STACK
      MOV R3,-(SP)      ;;PUSH R3 ON STACK
      MOV R4,-(SP)      ;;PUSH R4 ON STACK
      MOV ERRVEC,-(SP)  ;;PUSH ERRVEC ON STACK
      MOV ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
      MOV $BASE,R0
      MOV #PUTBUF,R2
      MOV #PUTINX,R4
      MOV #4$,ERRVEC    ;SETUP FOR TIMEOUT
      MOV #PR6,ERRVEC+2
1$:   MOV RMCS2(R0),$TMP0 ;GET 'NED' STATUS
      MOV RMCS1(R0),$TMP1 ;GET 'DVA' STATUS
      BIT #DVA,$TMP1      ;DEVICE AVAILABLE??
      BNE 2$             ;YES!!
      ADD #4,16(SP)      ;WRITE ERROR NUMBER IN
      MOVB #112,@16(SP) ;USER'S ERROR CALL
      BR 5$
2$:   TSTB (R4)          ;DONE??
      BMI 6$             ;YES!!
      MOVB (R4),R1      ;R1 = REGISTER ADDRESS
      BIC #^CIDXMSK,R1  ;CLEAR ANY SIGN EXTENSION
      ADD R0,R1
      MOVB (R4),R3      ;R3 = STORAGE ADDRESS
      BIC #^CIDXMSK,R3 ;CLEAR ANY SIGN EXTENSION
      ADD R2,R3
      MOV (R3),(R1)     ;WRITE REGISTER
      CMPB #RMOF,(R4)  ;WAS RMOF JUST LOADED ?

```

PUT SUBROUTINE

52	040530	001001		BNE	3\$:BR IF NO
53	040532	011311		MOV	(R3), (R1)		:WRITE RMOF AGAIN, TO ENSURE THAT 16 BIT MODE
54							:IS SET BEFORE 'SSEI' BIT IS SET.
55	040534	105724	3\$:	TSTB	(R4)+		:ADJUST REGISTER POINTER
56	040536	000757		BR	2\$		
57							
58	040540	022626	4\$:	CMP	(SP)+, (SP)+		:ADJUST STACK
59	040542	062766	000004	ADD	#4, 16(SP)		:WRITE ERROR NUMBER IN
60	040550	112776	000007	MOVB	#7, @16(SP)		:USER'S ERROR CALL
61	040556	162766	000002	SUB	#2, 16(SP)		
62							
63	040564		6\$:	MOV	(SP)+, ERRVEC+2		::POP STACK INTO ERRVEC+2
	040564	012637	000006	MOV	(SP)+, ERRVEC		::POP STACK INTO ERRVEC
	040570	012637	000004	MOV	(SP)+, R4		::POP STACK INTO R4
	040574	012604		MOV	(SP)+, R3		::POP STACK INTO R3
	040576	012603		MOV	(SP)+, R2		::POP STACK INTO R2
	040600	012602		MOV	(SP)+, R1		::POP STACK INTO R1
	040602	012601		MOV	(SP)+, R0		::POP STACK INTO R0
	040604	012600		MOV	(SP)+, R0		::POP STACK INTO R0
64	040606	000207		RTS	PC		:RETURN

SIZE CLOCK SUBROUTINE

```

1          .SETTL  SIZE CLOCK SUBROUTINE
2
3 040610    017746  000004    SIZCLK:
040610    013746  000006      MOV    ERRVEC,-(SP)      ;;PUSH ERRVEC ON STACK
040614    013746  000006      MOV    ERRVEC+2,-(SP)    ;;PUSH ERRVEC+2 ON STACK
4 040620    012737  040656  000004      MOV    #1$,ERRVEC      ;;SET UP FOR BUS TIMEOUT
5 040626    012737  000300  000006      MOV    #PR6,ERRVEC+2
6 040634    012737  177546  001522      MOV    #177546,CLKADR  ;;LOAD ADDRESSES FOR KW11-L
7 040642    012737  000100  001524      MOV    #100,CLKVCT
8 040650    005777  140646      TST    @CLKADR          ;;TEST FOR KW11-L PRESENT
9 040654    000421      BR     3$              ;;YES - KW11-L IS PRESENT
10 040656   022626      1$:  CMP    (SP)+,(SP)+    ;;RESTORE SP
11 040660   012737  040710  000004      MOV    #2$,ERRVEC      ;;SET UP FOR BUS TIMEOUT
12 040666   012737  172540  001522      MOV    #172540,CLKADR  ;;LOAD ADDRESSES FOR KW11-P CLOCK
13 040674   012737  000104  001524      MOV    #104,CLKVCT
14 040702   005777  140614      TST    @CLKADR          ;;TEST FOR KW11-P PRESENT
15 040706   000404      BR     3$              ;;YES - KW11-P IS PRESENT
16 040710   022626      2$:  CMP    (SP)+,(SP)+    ;;RESTORE SP
17 040712   062766  000002  000004      ADD    #2,4(SP)        ;;MOVE RETURN TO ERROR
18 040720      3$:
040720    012637  000006      MOV    (SP)+,ERRVEC+2  ;;POP STACK INTO ERRVEC+2
040724    012637  000004      MOV    (SP)+,ERRVEC    ;;POP STACK INTO ERRVEC
19 040730    000207      RTS    PC              ;;RETURN TO USER

```

```

1      .SBTTL  TIMEOUT SUBROUTINE
2
3      ;THIS SUBROUTINE WAITS FOR RDY = 1 AND GO = 0 OR FOR A TIMEOUT
4      ;GREATER THAN APPROX. 500 MSEC AND THEN RETURNS.
5
6      ;CALL:  JSR      PC,TIMOUT
7      ;      ???
8      ;      RETURN HERE
9
10     TIMOUT:
11     040732 010046      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
12     040734 010246      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
13     040736 013746 000004  MOV      ERRVEC,-(SP)  ;;PUSH ERRVEC ON STACK
14     040742 013746 000006  MOV      ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
15     10 040746 012737 041032 000004  MOV      #3$,ERRVEC    ;SETUP FOR BUS TIMEOUT - 04 TRAP
16     11 040754 012737 000300 000006  MOV      #PR6,ERRVEC+2
17     12 040762 013700 001276      MOV      $BASE,R0      ;R0=BASE ADDRESS
18     13 040766 012702 000036      MOV      #30,R2       ;R2=NUMBER OF CLOCK CYCLES
19     14 040772 004737 041074 1$:      JSR      PC,STIMER    ;START CLOCK TIMER
20
21     16 040776 016046 000000 2$:      MOV      RMCS1(R0),-(SP) ;GET STATUS
22     17 041002 042716 177576      BIC      #^C<RDY!GO>,(SP)
23     18 041006 022726 000200      CMP      #RDY,(SP)+   ;RDY=1,GO=0??
24     19 041012 001421      BEQ      4$          ;YES!!
25     20 041014 032777 000200 140500  BIT      #BIT7,@CLKADR ;TIMER DONE??
26     21 041022 001765      BEQ      2$          ;NO!!
27     22 041024 005302      DEC      R2          ;DEC NUMBER OF CYCLES
28     23 041026 001361      BNE      1$          ;CONTINUE IF NOT DONE
29     24 041030 000412      BR       4$          ;'RDY' DID NOT SET OR 'GO' DID NOT RESET
30     ;WITHIN 500 MSEC AFTER THE COMMAND WAS ISSUED.
31     26 041032 022626      CMP      (SP)+,(SP)+ ;ADJUST STACK
32     27 041034 062766 000004 000012  ADD      #4,12(SP)    ;MOVE SP TO USER'S CALL
33     28 041042 112776 000007 000012  MOVB    #7,@12(SP)   ;WRITE ERROR NUMBER
34     29 041050 162766 000002 000012  SUB
35
36     31 041056      4$:      MOV      (SP)+,ERRVEC+2 ;;POP STACK INTO ERRVEC+2
37     32 041056 012637 000006      MOV      (SP)+,ERRVEC  ;;POP STACK INTO ERRVEC
38     33 041062 012637 000004      MOV      (SP)+,R2      ;;POP STACK INTO R2
39     34 041066 012602      MOV      (SP)+,R0      ;;POP STACK INTO R0
40     35 041070 012600      RTS      PC           ;RETURN TO USER
41     36 041072 000207
42
43     ;THIS ROUTINE IS USED START THE KW11-L OR THE KW11-P CLOCK. THE CLOCK
44     ;IS STARTED TO RUN IN FLAG MODE. A CLOCK WILL BE 16.667MS FOR A 60 HZ CPU
45     ;AND 20MS FOR A 50 HZ CPU.
46
47     STIMER:
48     38 041074 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
49     39 041076 013701 001522      MOV      CLKADR,R1    ;R1=CLOCK ADDRESS
50     40 041102 020127 172540      CMP      R1,#172540   ;KW11-P CLOCK??
51     41 041106 001003      BNE      1$          ;NO!!
52     42 041110 012761 000001 000002  MOV      #1,2(R1)     ;SET COUNTER
53     43 041116 012711 000005 1$:      MOV      #BIT2!BIT0,(R1) ;START COUNTER
54     44 041122 012601      MOV      (SP)+,R1    ;;POP STACK INTO R1
55     45 041124 000207      RTS      PC           ;RETURN
    
```


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39 041126
40
41
42 041126 062716 000004
43 041132 105076 000000
44 041136 162716 000004
45
46
47 041142 013737 001346 001142
48 041150 042737 177770 001142
49 041156 013737 001234 001140
50 041164 042737 177770 001140
51 041172 123737 001140 001142
52
53 041200 001415
54 041202 062716 000004
55 041206 112776 000001 000000
56 041214 162716 000002
57 041220 004736

```

.SBTTL PRIMARY ERPOR CHECK SUBROUTINE

:THE PURPOSE OF THIS SUBROUTINE IS TO VERIFY THAT STATUS IS VALID AND
:THAT FURTHER ERROR AND STATUS CHECKING SHOULD BE PERFORMED. THE
:FOLLOWING CHECKS ARE MADE:
:
:   .CORRECT UNIT IS SELECTED, I.E., THE UNIT SELECT BITS OF RMCS2
:(BITS 0-2) EQUAL THE UNIT BEING TESTED;
:
:   .SELECTED UNIT IS AVAILABLE, I.E., DVA (BIT 11 OF RMCS1) IS SET
:AND NED (BIT 12 OF RMCS2) IS RESET;
:
:   .LAST COMMAND WAS COMPLETED, I.E., THE MASSBUS CONTROLLER IS
:READY (BIT 7 OF RMCS1) AND THE GO BIT IS RESET (BIT 0 OF RMCS1) OR THE
:DRIVE READY BIT (BIT 7 OF RMDS) IS SET.
:   .NO PARITY ERROR OCCURRED WHEN READING REMOTE REGISTERS,
:I.E., MCRPE = 0.
:   .NO PARITY ERROR OCCURRED WHEN WRITING REMOTE REGISTERS,
:I.E., PAR = 0, OR, PAR = DPE = 1
:
:THE SUBROUTINE ASSUMES THAT:
:
:   .STATUS HAS BEEN STORED IN THE REGISTER INPUT BUFFER,
:IN PARTICULAR, RMCS1, RMCS2 AND RMDS HAVE BEEN STORED IN THEIR
:CORRESPONDING LOCATIONS OF THE "GET" BUFFER.
:
:   .($UNIT) CONTAINS THE DRIVE NUMBER
:
:THE SUBROUTINE IS CALLED AS FOLLOWS:
:(1)   JSR    PC,PRIERR      RETURN HERE IF NO ERROR
:       BR     ???           RETURN HERE TO REPORT AN ERROR
:       NOP                    ERROR NUMBER DEFINED BY SUB
:       ERROR  PC,@(SP)+     GO BACK TO SUB FOR MORE ERROR CHECKS
:       JSR    ???           RETURN HERE IF NO MORE ERRORS
:
PRIERR:
:CLEAR USER'S ERROR CALL
:ADD     #4,(SP)             :MOVE (SP) TO ERROR CALL
:CLRB   @ (SP)              :CLEAR ERROR NUMBER
:SUB    #4,(SP)             :MOVE (SP) TO NO ERROR RETURN
:
:REPORT AN ERROR IF THE WRONG UNIT IS SELECTED
:MOV    RMCS2I,$BDDAT      :CORRECT UNIT SELECTED??
:BIC    #^CUNTMSK,$BDDAT
:MOV    $UNIT,$GDDAT      :GOOD DATA FOR TYPEOUT
:BIC    #^CUNTMSK,$GDDAT
:CPMB   $GDDAT,$BDDAT     :COMPARE EXPECTED AND RECEIVED
:                           :DRIVE NUMBERS
:                           :YES!!
:BEQ    1$
:ADD    #4,(SP)
:MOVB   #1,@(SP)          :ERROR 1
:SUB    #2,(SP)           :MOVE SP TO RETURN FOR ERROR
:JSR    PC,@(SP)+        :REPORT WRCNG UNIT SELECTED
    
```

```

58 041222 162716 000010      SUB      #10,(SP)      ;RESTORE (SP)
59 041226 000240      NOP
60 041230 000137 041750      JMP      10$          ;SKIP OTHER CHECKS
61 041232
62
63
64
65 041234 000137 004000 001336      BIT      #DVA, RMCS1I  ;DEVICE AVAILABLE??
66 041242 001045          BNE      3$           ;YES!!
67 041244 013737 001336 001140      MOV      RMCS1I,$GDDAT ;EXPECTED STATUS
68 041252 052737 004000 001140      BIS      #DVA,$GDDAT
69 041260 013737 001336 001142      MOV      RMCS1I,$BDDAT ;RECEIVED STATUS
70 041266 062716 000004          ADD      #4,(SP)
71 041272 112776 000002 000000      MOVB     #2,@(SP)      ;ERROR #2
72 041300 032737 010000 001346      BIT      #NED, RMCS2I  ;WAS NED SET??
73 041306 001414          BEQ      2$           ;NO!!
74 041310 013737 001346 001140      MOV      RMCS2I,$GDDAT ;EXPECTED STATUS
75 041316 013737 001346 001142      MOV      RMCS2I,$BDDAT ;RECEIVED STATUS
76 041324 042737 010000 001140      BIC      #NED,$GDDAT
77 041332 112776 000003 000000      MOVB     #3,@(SP)      ;YES - CHANGE ERROR NUMBER
78 041340 162716 000002          SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
79 041344 004736          JSR      PC,@(SP)+    ;REPORT DEVICE NOT AVAILABLE
80 041346 162716 000010          SUB      #10,(SP)     ;RESTORE (SP)
81 041352 000240          NOP
82 041354 000575          BR       10$          ;SKIP OTHER CHECKS
83 041356
84
85
86 041356 032737 000200 001336      ;REPORT AN ERROR IF MASSBUS CONTROLLER IS NOT READY
87 041364 001030          BIT      #RDY, RMCS1I  ;CONTROLLER READY??
88 041366 013737 001336 001140      BNE      4$           ;YES!!
89 041374 052737 000200 001140      MOV      RMCS1I,$GDDAT ;EXPECTED STATUS
90 041402 042737 160001 001140      BIS      #RDY,$GDDAT
91 041410 013737 001336 001142      BIC      #SC!TR!MCPE!GO,$GDDAT
92 041416 062716 000004          MOV      RMCS1I,$BDDAT ;RECEIVED STATUS
93 041422 112776 000004 000000      ADD      #4,(SP)
94 041430 162716 000002          MOVB     #4,@(SP)      ;ERROR #4
95 041434 004736          SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
96 041436 162716 000010          JSR      PC,@(SP)+    ;REPORT CONTROLLER NOT READY
97 041442 000240          SUB      #10,(SP)     ;RESTORE (SP)
98 041444 000541          NOP
99 041446          BR       10$          ;SKIP OTHER CHECKS
100
101
102 041446 032737 000001 001336      ;REPORT AN ERROR IF GO IS NOT ZERO AND DRY IS NOT ONE
103 041454 001431          BEQ      5$           ;GO RESET??
104 041456 032737 000200 001350      BIT      #DRY, RMDSI   ;DRIVE READY??
105 041464 001025          BNE      5$           ;YES!!
106 041466 013737 001336 001140      MOV      RMCS1I,$GDDAT ;EXPECTED STATUS
107 041474 042737 160001 001140      BIC      #SC!TR!MCPE!GO,$GDDAT
108 041502 013737 001336 001142      MOV      RMCS1I,$BDDAT ;RECEIVED STATUS
109 041510 062716 000004          ADD      #4,(SP)
110 041514 112776 000005 000000      MOVB     #5,@(SP)      ;ERROR #5
111 041522 162716 000002          SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
112 041526 004736          JSR      PC,@(SP)+    ;REPORT DRIVE NOT READY
113 041530 162716 000010          SUB      #10,(SP)     ;RESTORE (SP)
114 041534 000240          NOP
    
```

```

115 041536 000504          BR      10$
116 041540          5$:
:17
118          :REPORT AN ERROR IF THE RM CONTROLLER DETECTED BAD
119          :PARITY ON THE MASSBUS CONTROL BUS
120 041540 032737 020000 001336  BIT      #MCPE,RMCS1I  ;PARITY ERROR ??
121 041546 001425          BEQ      6$          ;NO!!
122 041550 013737 001336 001140  MOV      RMCS1I,$GDDAT ;EXPECTED STATUS
123 041556 042737 160001 001140  BIC      #SC!TRE!MCPE!GO,$GDDAT
124 041564 013737 001336 001142  MOV      RMCS1I,$BDDAT ;RECEIVED STATUS
125 041572 062716 000004          ADD      #4,(SP)      ;MOVE STACK TO USER'S ERROR
126 041576 112776 000013 000000  MOVB    #13,@(SP)    ;ERROR #13
127 041604 162716 000002          SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
128 041610 004736          JSR     PC,@(SP)+    ;REPORT ERROR VIA USER
129 041612 162716 000010          SUB      #10,(SP)    ;RESTORE STACK
130 041616 000240          NOP
131 041620 000453          BR      10$
132 041622          6$:
133
134          :REPORT AN ERROR IF THE RM80 DETECTED A CONTROL BUS PARITY ERROR
135 041622 032737 000010 001352  BIT      #PAR,RMER1I  ;WAS THERE A PARITY ERROR??
136 041630 001451          BEQ      11$         ;NO!!
137 041632 032737 000010 001400  BIT      #DPE,RMER2I  ;WAS IT THE CONTROL BUS??
138 041640 001045          BNE     11$         ;NOT SURE!!
139 041642 032737 000010 001426  BIT      #PAR,RMER1O  ;DID TEST SET PAR ??
140 041650 001413          BEQ      9$          ;NO!!
141 041652 010046          MOV     R0,-(SP)     ;:PUSH R0 ON STACK
142 041654 012700 001555          MOV     #PUTINX,R0  ;:R0 POINTS TO INDEX TABLE
143 041660 122710 000014          7$:  CMPB   #RMER1,(R0)  ;:SEARCH TABLE FOR RMER1
144 041664 001002          BNE     8$          ;:POP STACK INTO R0
145 041666 012600          MOV     (SP)+,R0    ;:PAR WAS SET BY TEST
146 041670 000431          BR     11$         ;:END OF TABLE??
147 041672 105720          8$:  TSTB  (R0)+         ;:NO!!
148 041674 100371          BPL    7$          ;:POP STACK INTO R0
149 041676 012600          MOV     (SP)+,R0    ;:EXPECTED STATUS
150 041700 013737 001352 001140  9$:  MOV     RMER1I,$GDDAT
151 041706 042737 000010 001140  BIC     #PAR,$GDDAT
152 041714 013737 001352 001142  MOV     RMER1I,$BDDAT ;RECEIVED STATUS
153 041722 062716 000004          ADD     #4,(SP)     ;MOVE SP TO USER'S ERROR CALL
154 041726 112776 000050 000000  MOVB   #50,@(SP)    ;WRITE THE ERROR NUMBER
155 041734 162716 000002          SUB     #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
156 041740 004736          JSR    PC,@(SP)+    ;REPORT THE ERROR
157 041742 162716 000010          SUB     #10,(SP)    ;MOVE SP TO NO ERROR RETURN
158 041746 000240          NOP
159 041750 062716 000010          10$: ADD     #10,(SP)    ;RETURN TO ERROR
160 041754 000240          11$: NOP             ;RETURN TO NO ERROR
161 041756 000207          RTS     PC
    
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTIL SECONDARY ERROR CHECK SUBROUTINE
 :THE ERROR CHECK SUBROUTINE PROVIDES DETECTION OF SECONDARY ERRORS
 :SUCH AS UNEXPECTED ERRORS AND UNEXPECTED REGISTER CONTENTS. THESE
 :ERRORS ARE DEEMED SECONDARY IN THAT THEY ARE NOT NECESSARILY
 :ASSOCIATED WITH THE OPERATION BEING PERFORMED.
 :WHEN THE SUBROUTINE IDENTIFIES SUCH AN ERROR, IT MOVES THE ERROR
 :NUMBER TO THE ERROR CALL IN THE TEST ROUTINE AND THEN RETURNS
 :TO THE TEST ROUTINE WHICH MAKES THE ERROR CALL. AFTER THE TEST ROUTINE
 :MAKES THE ERROR CALL, IT RETURNS TO THE SUBROUTINE WHICH THEN LOOKS FOR
 :OTHER ERRORS. WHEN ALL ERRORS HAVE BEEN REPORTED, THE SUBROUTINE
 :RETURNS TO THE ADDRESS FOLLOWING THE SUBROUTINE CALL.

```

CALL: JSR    PC,SECERR
      BR     ???          RETURN HERE IF NO ERROR
      NOP
      ERROR          RETURN HERE TO REPORT AN ERROR
      JSR    PC,@(SP)+   ERROR NUMBER DEFINED BY SUB
      ???          GO BACK TO SUB FOR MORE ERROR CHECKS
                    RETURN HERE IF NO MORE ERRORS
    
```

:NOTE: THE SUBROUTINE ASSUMES THAT REGISTERS HAVE BEEN STORED AT THE
 :INPUT REGISTER BUFFER.

SECERR:

```

:STORE FUNCTION CODE AND CLEAR USER'S ERROR NUMBER
MOV    RMCS10,B1$      :STORE FUNCTION CODE
BIC    #^C<F0!F1!F2!F3!F4>,B1$
ADD    #4,(SP)        :MOVE (SP) TO ERROR CALL
CLRB   @ (SP)         :CLEAR ERROR NUMBER
SUB    #4,(SP)        :MOVE (SP) TO NO ERROR RETURN
    
```

```

:REPORT ERROR IF DRIVE IS NOT READY, I.E., IF DRY = 0
BIT    #DRY,RMDSI     :DRIVE READY??
BNE    1$            :YES!!
MOV    RMDSI,$BDDAT   :BAD DATA FOR TYPEOUT
BIC    #^CDRY,$BDDAT
MOV    #DRY,$GDDAT    :GOOD DATA FOR TYPEOUT
ADD    #4,(SP)
MOVB   #10,@(SP)     :ERROR NUMBER
SUB    #2,(SP)       :MOVE SP TO RETURN FOR ERROR
JSR    PC,@(SP)+     :REPORT NOT READY
SUB    #10,(SP)      :RESTORE (SP) TO ERROR N
NOP
    
```

```

:REPORT ERROR IF GO BIT IS NOT RESET
1$: BIT    #GO,RMCS11  :GO BIT RESET??
    BEQ    2$          :YES!!
    MOV    RMCS11,$BDDAT :BAD DATA FOR TYPEOUT
    BIC    #^CGO,$BDDAT
    CLR    $GDDAT      :GOOD DATA FOR TYPEOUT
    ADD    #4,(SP)
    MOVB   #11,@(SP)   :ERROR NUMBER
    SUB    #2,(SP)     :MOVE SP TO RETURN FOR ERROR
    JSR    PC,@(SP)+   :REPORT DEVICE NOT AVAILABLE
    SUB    #10,(SP)    :RESTORE (SP)
    NOP
    
```

```

24 041760
27 041760 013737 001412 046120
28 041766 042737 177701 046120
29 041774 062716 000004
30 042000 105076 000000
31 042004 162716 000004
34 042010 032737 000200 001350
35 042016 001024
36 042020 013737 001350 001142
37 042026 042737 177577 001142
38 042034 012737 000200 001140
39 042042 062716 000004
40 042046 112776 000010 000000
41 042054 162716 000002
42 042060 004736
43 042062 162716 000010
44 042066 000240
47 042070 032737 000001 001336
48 042076 001423
49 042100 013737 001336 001142
50 042106 042737 177776 001142
51 042114 005037 001140
52 042120 062716 000004
53 042124 112776 000011 000000
54 042132 162716 000002
55 042136 004736
56 042140 162716 000010
57 042144 000240
    
```

SECONDARY ERROR CHECK SUBROUTINE

```

58
59
60 042146 013737 001336 001142 :REPORT ERROR IF FUNCTION CODE READ FROM DEVICE IS NOT CORRECT
61 042154 042737 177701 001142 2$: MOV RMCS1I,$BDDAT :IS FUNCTION CODE CORRECT??
62 042162 013737 046120 001140 BIC #^C76,$BDDAT
63 042170 023737 001142 001140 MOV B1,$GDDAT :EXPECTED FUNCTION CODE
64 042176 001413 BEQ 3$ :YES!!
65 042200 062716 000004 ADD #4,(SP)
66 042204 112776 000012 000000 MOVB #12,@(SP) :ERROR NUMBER
67 042212 162716 000002 SUB #2,(SP) :MOVE SP TO RETURN FOR ERROR
68 042216 004736 JSR PC,@(SP)+ :REPORT WRONG FUNCTION CODE
69 042220 162716 000010 SUB #10,(SP) :RESTORE (SP)
70 042224 000240 NOP
71 042226
72
73
74
75 042226 005037 001140 :REPORT AN ERROR IF COMPOSITE ERROR IS SET AND NO OTHER
76 042232 005737 001352 :ERRORS ARE SET, OR IF COMPOSITE ERROR IS NOT SET AND
77 042236 001003 :OTHER ERRORS ARE SET
78 042240 005737 001400 CLR $GDDAT :EXPECT 'ERR' = 0
79 042244 001403 TST RMER1I :IS RMER1 = 0??
80 042246 052737 040000 001140 4$: BNE 4$ :NO!!
81 042254 013737 001350 001142 5$: TST RMER2I :IS RMER2 = 0??
82 042262 042737 137777 001142 BEQ 5$ :YES!!
83 042270 023737 001140 001142 6$: BIS #ERR,$GDDAT :'ERR' SOULD BE SET
84 042276 001412 MOV RMDSI,$BDDAT
85 042300 062716 000004 000000 BIC #^CERR,$BDDAT
86 042304 112776 000047 000000 CMP $GDDAT,$BDDAT :IS 'ERR' OK??
87 042312 162716 000002 BEQ 6$ :YES!!
88 042316 004736 ADD #4,(SP) :MOVE SP TO USER'S ERROR
89 042320 162716 000010 MOVB #47,@(SP) :WRITE ERROR NUMBER
90
91 :REPORT AN ERROR IF 'TRE' IS SET AND NONE OF THE BITS WHICH SET
92 :TRE IS SET, OR IF TRE IS NOT SET AND ONE OR MORE BITS WHICH
93 :SET TRE IS SET
94 042324 005037 001140 6$: CLR $GDDAT :EXPECT 'TRE' = 0
95 042330 013746 001346 MOV RMCS2I,-(SP) :WAS DLT, WCE, UPE, NED, NEM
96 042334 042726 000377 BIC #377,(SP)+ :PGE, MXF OR MDPE SET
97 042340 001010 BNE 7$ :YES!!
98 042342 032737 040000 001350 BIT #ERR,RMSI :WAS EXCEPTION RECEIVED??
99 042350 001407 BEQ 8$ :NO!!
100 042352 022737 000030 046120 CMP #SEARCH,B1$ :WAS DATA TRANSFERRED??
101 042360 103003 BHIS 8$ :NO!!
102 042362 052737 040000 001140 7$: BIS #TRE,$GDDAT :'TRE' SHOULD BE SET
103 042370 013737 001336 001142 8$: MOV RMCS1I,$BDDAT :BAD DATA FOR TYPEOUT
104 042376 042737 137777 001142 BIC #^CTRE,$BDDAT
105 042404 023737 001140 001142 CMP $GDDAT,$BDDAT :IS 'TRE' OK??
106 042412 001413 BEQ 9$ :YES!!
107 042414 062716 000004 ADD #4,(SP) :MOVE SP TO USER'S ERROR CALL
108 042420 112776 000014 000000 MOVB #14,@(SP) :WRITE ERROR NUMBER
109 042426 162716 000002 SUB #2,(SP) :MOVE SP TO RETURN FOR ERROR
110 042432 004736 JSR PC,@(SP)+ :REPORT TRE ERROR
111 042434 162716 000010 SUB #10,(SP) :RESTORE (SP)
112 042440 000240 NOP
113 042442
114
9$:

```

```

115
116
117
118
119
120
121
122
123
124 042442 010046
125 042444 013700 046120
126 042450 016037 067244 046112
127 042456 012600
128
129
130
131 042460 013737 046112 001140
132 042466 032737 040000 001350
133 042471 001403
134 042476 052737 100000 001140
135 042504 042737 077777 001140
136 042512 013737 001350 001142
137 042520 042737 077777 001142
138 042526 023737 001140 001142
139 042534 001413
140 042536 062716 000004
141 042542 112776 000006 000000
142 042550 162716 000002
143 042554 004736
144 042556 162716 000010
145 042562 000240
146 042564
147
148
149
150 042564 013737 046112 001140
151 042572 042737 177776 001140
152 042600 013737 001352 001142
153 042606 042737 177776 001142
154 042614 023737 001140 001142
155 042622 001412
156 042624 062716 000004
157 042630 112776 000254 000000
158 042636 162716 000002
159 042642 004736
160 042644 162716 000010
161 042650 005037 001140
162
163
164 042654 013746 046112
165 042660 052716 137777
166 042664 013737 001346 001142
167 042672 042637 001142
168 042676 001412
169 042700 062716 000004
170 042704 112776 000026 000000
171 042712 162716 000002

```

 :USING THE FUNCTION CODE TABLE, CHECK FOR THE FOLLOWING ERRORS:
 : .STATUS BITS NOT SET THAT SHOULD BE SET, E.G., ATA AND ILF
 : .STATUS BITS SET THAT SHOULD NOT BE SET, E.G., WCE AND ECH
 :NOTE THAT SOME ERROR BITS ARE CONDITIONAL ON THE COMMAND AND OTHER
 :STATUS CONDITIONS, E.G., WRITE LOCK ERROR SHOULD ONLY BE SET IF
 :WRITE LOCK IS ON AND THE COMMAND IS A WRITE.
 :GET AND STORE THE ENTRY FROM THE FUNCTION CODE TABLE
 :MOV R0, -(SP) :PUSH R0 ON STACK
 :MOV 81\$, R0 :GET FUNCTION CODE
 :MOV FNCDTB(R0), 78\$:STORE ENTRY
 :MOV (SP)+, R0 :POP STACK INTO R0
 :REPORT AN ERROR IF AN UNEXPECTED ATTENTION OCCURRED OR IF
 :ATA IS NOT SET AND SHOULD BE SET.
 :MOV 78\$, \$GDDAT :GET EXPECTED ATA STATUS
 :BIT #ERR, RMDSI :IS COMPOSITE ERROR SET ??
 :BEQ 10\$:NO !!
 :BIS #ATA, \$GDDAT :EXPECT AN ATTENTION
 :BIC #^ATA, \$GDDAT :STRIP DONT CARES
 :MOV RMDSI, \$BDDAT :GET RECEIVED ATA
 :BIC #^ATA, \$BDDAT :STRIP DONT CARES
 :CMP \$GDDAT, \$BDDAT :IS ATA OK ??
 :BEQ 11\$:YES !!
 :ADD #4, (SP) :MOVE SP TO USERS ERROR CALL
 :MOVB #6, @ (SP) :LOAD ERROR # IN CALL
 :SUB #2, (SP) :MOVE SP TO ERROR RETURN
 :JSR PC, @ (SP)+ :REPORT ERROR
 :SUB #10, (SP) :RESTORE SP
 10\$:
 11\$:
 :REPORT ERROR IF ILF IS INCORRECT, I.E., IF ILF DOES NOT COMPARE
 :WITH FUNCTION CODE TABLE
 :MOV 78\$, \$GDDAT :GET EXPECTED ILF
 :BIC #^CILF, \$GDDAT :CLEAR ALL OTHER BITS
 :MOV RMER11, \$BDDAT :GET RECEIVED ILF
 :BIC #^CILF, \$BDDAT :CLEAR ALL OTHER BITS
 :CMP \$GDDAT, \$BDDAT :IS ILF OK ??
 :BEQ 12\$:YES !!
 :ADD #4, (SP) :MOVE SP TO USERS ERROR CALL
 :MOVB #254, @ (SP) :WRITE ERROR NUMBER IN CALL
 :SUB #2, (SP) :MOVE SP TO ERROR RETURN
 :JSR PC, @ (SP)+ :REPORT ERROR AND RETURN
 :SUB #10, (SP) :MOVE SP TO NO ERROR
 12\$: CLR \$GDDAT :CLEAR EXPECTED STATUS
 :REPORT AN ERROR IF WCE IS SET AND SHOULD NOT BE SET
 :MOV 78\$, -(SP) :GET WCE STATUS ENABLE
 :BIS #^CWCE, (SP) :SET ALL OTHER BITS
 :MOV RMCS21, \$BDDAT :RECEIVED STATUS
 :BIC (SP)+, \$BDDAT :CLEAR WCE IF ENABLED
 :BEQ 13\$:BRANCH IF WCE OK
 :ADD #4, (SP) :MOVE SP TO USER'S ERROR CALL
 :MOVB #26, @ (SP) :WRITE ERROR NUMBER
 :SUB #2, (SP) :MOVE SP TO ERROR RETURN

```

172 042716 004736          JSR    PC,@(SP)+      ;REPORT ERROR
173 042720 162716 000010  SUB    #10,(SP)      ;RESTORE ERROR
174 042724          13$:
175
176          ;REPORT ERROR IF OPI STATUS IS SET AND SHOULD NOT BE SET
177 042724 013746 046112  MOV    78$,-(SP)    ;GET OPI STATUS ENABLE
178 042730 052716 157777  BIS    #*COPI,(SP)  ;SET ALL OTHER BITS
179 042734 013737 001352 001142  MOV    RMER1I,$BDDAT ;GET RECEIVED STATUS
180 042742 042637 001142  BIC    (SP)+,$BDDAT ;CLEAR OPI IF ENABLED
181 042746 001412          BEQ    14$          ;BRANCH IF OPI OK
182 042750 062716 000004  ADD    #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
183 042754 112776 000164 000000  MOVB   #164,@(SP)   ;WRITE ERROR NUMBER IN CALL
184 042762 162716 000002  SUB    #2,(SP)      ;MOVE SP TO ERROR RETURN
185 042766 004736          JSR    PC,@(SP)+      ;REPORT ERROR
186 042770 162716 000010  SUB    #10,(SP)      ;RESTORE SP
187 042774          14$:
188
189          ;REPORT ERROR IF IVC IS SET AND IS NOT ENABLED OR IF IVC IS
190          ;SET AND VV IS NOT RESET
191 042774 013746 046112  MOV    78$,-(SP)    ;GET IVC STATUS ENABLE
192 043000 032737 000100 001350  BIT    #VV,RMDSI    ;IS VV SET
193 043006 001402          BEQ    15$          ;NO !!
194 043010 042716 010000  BIC    #IVC,(SP)    ;YES - IVC SHOULD BE 0
195 043014 052716 167777 001142 15$:  BIS    #*CIVC,(SP)  ;SET ALL OTHER BITS
196 043020 013737 001400  MOV    RMER2I,$BDDAT ;GET RECEIVED STATUS
197 043026 042637 001142  BIC    (SP)+,$BDDAT ;CLEAR IVC IF ENABLED
198 043032 001412          BEQ    16$          ;BRANCH IF IVC OK
199 043034 062716 000004  ADD    #4,(SP)      ;MOVE SP TO USERS ERROR CALL
200 043040 112776 000165 000000  MOVB   #165,@(SP)   ;WRITE ERROR NUMBFR IN CALL
201 043046 162716 000002  SUB    #2,(SP)      ;MOVE SP TO ERROR RETURN
202 043052 004736          JSR    PC,@(SP)+      ;REPORT ERROR
203 043054 162716 000010  SUB    #10,(SP)      ;RESTORE SP TO NO ERROR
204 043060          16$:
205
206          ;BIT 11 (WLE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
207          ; ALL WRITE ERRORS, I.E.,
208          ; RMER1 - WLE, WCF
209          ; RMER2 - DPE
210          ; RMCS2 - UPE.
211          ;EACH OF THESE ERRORS IS CHECKED TO SEE IF AN ERROR IS SET WHEN THE
212          ;WRITE ERROR ENABLE BIT IS RESET.
213
214          ;REPORT AN ERROR IF WLE IS SET AND WRITE ERRORS ARE NOT ENABLED, OR IF
215          ;THE DRIVE IS NOT WRITE PROTECTED
216 043060 012746 177777  MOV    #-1,-(SP)    ;ASSUME WRITE ERRORS ENABLED
217 043064 032737 004000 046112  BIT    #WLE,78$    ;ARE WRITE ERRORS ENABLED ??
218 043072 001404          BEQ    17$          ;NO !!
219 043074 032737 004000 001350  BIT    #WRL,RMDSI   ;IS THE DRIVE WRITE PROTECTED ??
220 043102 001002          BNE    18$          ;YES !!
221 043104 042716 004000 17$:  BIC    #WLE,(SP)    ;RESET WLE ENABLE
222 043110 013737 001352 001142 18$:  MOV    RMER1I,$BDDAT ;GET RECEIVED STATUS
223 043116 042637 001142  BIC    (SP)+,$BDDAT ;CLEAR WLE IF ENABLED
224 043122 001412          BEQ    19$          ;BRANCH IF WLE OK
225 043124 062716 000004  ADD    #4,(SP)      ;MOVE SP TO USERS ERROR CALL
226 043130 112776 000023 000000  MOVB   #23,@(SP)   ;WRITE ERROR NUMBER IN CALL
227 043136 162716 000002  SUB    #2,(SP)      ;MOVE SP TO ERROR RETURN
228 043142 004736          JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
    
```

```

229 043144 162716 000010          SUB      #10,(SP)          :RESTORE SP TO NO ERROR
230 043150          19$:
231
232          :REPORT ERROR IF WCF IS SET AND WRITE ERRORS ARE NOT ENABLED
233 043150 012746 177777          MOV      #-1,-(SP)          :ASSUME WRITE ERRORS ENABLED
234 043154 032737 004000 046112          BIT      #WLE,78$          :ARE WRITE ERRORS ENAB'ED ??
235 043162 001002          BNE      20$              :YES !!
236 043164 042716 000040          BIC      #WCF,(SP)          :DISABLE WCF ERROR
237 043170 013737 001352 001142 20$:          MOV      RMER11,$BDDAT      :GET RECEIVED STATUS
238 043176 042637 001142          BIC      (SP)+,$BDDAT      :RESET WCF IF ENABLED
239 043202 001412          BEQ      21$              :BRANCH IF WCF OK
240 043204 062716 000004          ADD      #4,(SP)          :MOVE SP TO USERS ERROR CALL
241 043210 112776 000025 000000          MOVSB   #25,@(SP)          :WRITE ERROR NUMBER IN CALL
242 043216 162716 000002          SUB      #2,(SP)          :MOVE SP TO ERROR RETURN
243 043222 004736          JSR      PC,@(SP)+        :REPORT ERROR
244 043224 162716 000010          SUB      #10,(SP)         :RESTORE SP TO NO ERROR
245 043230          21$:
246
247          :REPORT ERROR IF DPE IS SET AND WRITE ERRORS ARE NOT ENABLED
248 043230 012746 177777          MOV      #-1,-(SP)          :ASSUME WRITE ERRORS ARE ENABLED
249 043234 032737 004000 046112          BIT      #WLE,78$          :ARE WRITE ERRORS ENABLED ??
250 043242 001002          BNE      22$              :YES !!
251 043244 042716 000010          BIC      #DPE,(SP)          :RESET DPE ENABLE
252 043250 013737 001400 001142 22$:          MOV      RMER21,$BDDAT      :GET RECEIVED STATUS
253 043256 042637 001142          BIC      (SP)+,$BDDAT      :RESET DPE IF ENABLED
254 043262 001412          BEQ      23$              :BRANCH IF DPE OK
255 043264 062716 000004          ADD      #4,(SP)          :MOVE SP TO USERS ERROR CALL
256 043270 112776 000040 000000          MOVSB   #40,@(SP)         :WRITE ERROR NUMBER IN CALL
257 043276 162716 000002          SUB      #2,(SP)          :MOVE SP TO ERROR RETURN
258 043302 004736          JSR      PC,@(SP)+        :REPORT ERROR
259 043304 162716 000010          SUB      #10,(SP)         :RESTORE SP TO NO ERROR
260 043310          23$:
261
262          :REPORT AN ERROR IF UPE IS SET AND WRITE ERRORS ARE NOT ENABLED
263 043310 012746 177777          MOV      #-1,-(SP)          :ASSUME WRITE ERRORS ARE ENABLED
264 043314 032737 004000 046112          BIT      #WLE,78$          :ARE WRITE ERRORS ENABLED ??
265 043322 001002          BNE      24$              :YES !!
266 043324 042716 020000          BIC      #UPE,(SP)          :DISABLE UPE ERROR
267 043330 013737 001346 001142 24$:          MOV      RMCS21,$BDDAT      :GET RECEIVED STATUS
268 043336 042637 001142          BIC      (SP)+,$BDDAT      :RESET UPE IF ENABLED
269 043342 001412          BEQ      25$              :BRANCH IF UPE OK
270 043344 062716 000004          ADD      #4,(SP)          :MOVE SP TO USERS ERROR CALL
271 043350 112776 000024 000000          MOVSB   #24,@(SP)         :WRITE ERROR NUMBER IN CALL
272 043356 162716 000002          SUB      #2,(SP)          :MOVE SP TO ERROR RETURN
273 043362 004736          JSR      PC,@(SP)+        :REPORT ERROR AND RETURN
274 043364 162716 000010          SUB      #10,(SP)         :MOVE SP TO NO ERROR
275 043370          25$:
276
277          :REPORT AN ERROR IF IAE IS SET AND IS NOT ENABLED
278 043370 013746 046112          MOV      78$,-(SP)          :GET IAE ENABLE
279 043374 052716 175777          BIS      #CIAE,(SP)        :SET ALL OTHER BITS
280 043400 013737 001352 001142          MOV      RMER11,$BDDAT      :GET RECEIVED STATUS
281 043406 042637 001142          BIC      (SP)+,$BDDAT      :CLEAR IAE IF ENABLED
282 043412 001412          BEQ      26$              :BRANCH IF IAE IS OK
283 043414 062716 000004          ADD      #4,(SP)          :MOVE SP TO USERS ERROR CALL
284 043420 112776 000166 000000          MOVSB   #166,@(SP)        :WRITE ERROR NUMBER
285 043426 162716 000002          SUB      #2,(SP)          :MOVE SP TO ERROR RETURN
    
```



```

286 043432 004736          JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
287 043434 162716 000010  SUB    #10,(SP)        ;MOVE SP TO NO ERROR
288 043440          26$:
289
290          ;BIT 09 (AOE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
291          ; ALL READ/WRITE ERRORS, I.E..
292          ;
293          ; RMCS1 - TRE
294          ; RMCS2 - DLT,NEM,MXF
295          ; RMDS  - LBT
296          ; RMER1 - AOE
297          ;NOTE:
298          ; LBT IS NOT CHECKED BECAUSE IT ONLY RESETS WHEN THE DESIRED
299          ; CYLINDER REGISTER IS WRITTEN
300          ;NOTE:
301          ; AOE CANNOT BE SET IF LBT IS NOT ALSO SET
302          ;NOTE:
303          ; TRE IS CHECKED AS A FUNCTION OF OTHER ERROR CONDITONS ABOVE
304
305          ;REPORT AN ERROR IF DLT IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
306 043440 012746 177777  MOV    #-1,-(SP)      ;ASSUME ERRORS ARE ENABLED
307 043444 032737 001000 046112 BIT    #AOE,78$      ;ARE ERRORS ENABLED ??
308 043452 001002          BNE    27$           ;YES !!
309 043454 042716 100000  BIC    #DLT,(SP)     ;RESET DLT ENABLE
310 043460 013737 001346 001142 27$: MOV    RMCS2I,$BDDAT ;GET RECEIVED STATUS
311 043466 042637 001142  BIC    (SP)+,$BDDAT ;CLEAR DLT IF ENABLED
312 043472 001412          BEQ    28$           ;BRANCH IF DLT IS OK
313 043474 062716 000004  ADD    #4,(SP)       ;MOVE SP TO USERS ERROR CALL
314 043500 112776 000032 0C0000 MOVB   #32,@(SP)     ;WRITE ERROR NUMBER IN CALL
315 043506 162716 000002  SUB    #2,(SP)       ;MOVE SP TO ERROR RETURN
316 043512 004736          JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
317 043514 162716 000010  SUB    #10,(SP)     ;MOVE SP TO NO ERROR
318 043520          28$:
319
320          ;REPORT ERROR IF NEM IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
321 043520 012746 177777  MOV    #-1,-(SP)      ;ASSUME ERRORS ARE ENABLED
322 043524 032737 001000 046112 BIT    #AOE,78$      ;ARE ERRORS ENABLED ??
323 043532 001002          BNE    29$           ;YES !!
324 043534 042716 004000  BIC    #NEM,(SP)     ;DISABLE NEM
325 043540 013737 001346 001142 29$: MOV    RMCS2I,$BDDAT ;GET RECEIVED STATUS
326 043546 042637 001142  BIC    (SP)+,$BDDAT ;CLEAR NEM IF ENABLED
327 043552 001412          BEQ    30$           ;BRANCH IF NEM IS OK
328 043554 062716 000004  ADD    #4,(SP)       ;MOVE SP TO USERS ERROR CALL
329 043560 112776 000167 000000 MOVB   #167,@(SP)    ;WRITE ERROR NUMBER IN CALL
330 043566 162716 000002  SUB    #2,(SP)       ;MOVE SP TO ERROR RETURN
331 043572 004736          JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
332 043574 162716 000010  SUB    #10,(SP)     ;MOVE SP TO NO ERROR
333 043600          30$:
334
335          ;REPORT ERROR IF MXF IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
336 043600 012746 177777  MOV    #-1,-(SP)      ;ASSUME ERRORS ARE ENABLED
337 043604 032737 001000 046112 BIT    #AOE,78$      ;ARE DATA ERRORS ENABLED ??
338 043612 001002          BNE    31$           ;YES !!
339 043614 042716 001000  BIC    #MXF,(SP)     ;DISABLE MXF ERROR
340 043620 013737 001346 001142 31$: MOV    RMCS2I,$BDDAT ;GET RECEIVED STATUS
341 043626 042637 001142  BIC    (SP)+,$BDDAT ;CLEAR MXF IF ENABLED
342 043632 001412          BEQ    32$           ;BRANCH IF MXF IS OK
    
```

```

343 043634 062716 000004          ADD      #4,(SP)          ;MOVE SP TO USERS ERROR CALL
344 043640 112776 000033 000000    MOV      #33,@(SP)       ;WRITE ERROR NUMBER IN CALL
345 043646 162716 000002          SUB      #2,(SP)         ;MOVE SP TO ERROR RETURN
346 043652 004736          JSR      PC,@(SP)+       ;REPORT ERROR AND RETURN
347 042654 162716 000010          SUB      #10,(SP)        ;MOVE SP TO NO ERROR
348 043660          32$:
349
350          ;REPORT ERROR IF AOE IS SET AND DATA ERRORS ARE NOT ENABLED
351 043660 012746 177777          MOV      #-1,-(SP)       ;ASSUME DATA ERRORS ARE ENABLED
352 043664 032737 001000 046112    BIT      #AOE,78$        ;ARE DATA ERRORS ENABLED ??
353 043672 001404          BEQ      33$             ;NO !!
354 043674 032737 002000 001350    BIT      #LBT,RMDSI      ;IS LBT ALSO SET ??
355 043702 001002          BNE      34$             ;YES !!
356 043704 042716 001000 33$:      BIC      #AOE,(SP)        ;DISABLE AOE
357 043710 013737 001352 001142 34$:      MOV      RMER1I,$BDDAT    ;GET RECEIVED STATUS
358 043716 042637 001142          BIC      (SP)+,$BDDAT    ;CLEAR AOE IF ENABLED
359 043722 001412          BEQ      35$             ;BRANCH IF AOE IS OK
360 043724 062716 000004          ADD      #4,(SP)         ;MOVE SP TO USERS ERROR CALL
361 043730 112776 000020 000000    MOV      #20,@(SP)       ;WRITE ERROR NUMBER
362 043736 162716 000002          SUB      #2,(SP)         ;MOVE SP TO ERROR RETURN
363 043742 004736          JSR      PC,@(SP)+       ;REPORT ERROR AND RETURN
364 043744 162716 000010          SUB      #10,(SP)        ;MOVE SP TO NO ERROR
365 043750          35$:
366
367          ;BIT 07 (HCE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
368          ;HEADER ERRORS, I.E.,
369          ;
370          ;
371          ;
372          ;RESET THE ENABLING BIT (HCE) IF HEADER COMPARE INHIBIT IS SET
373 043750 032737 002000 001370    BIT      #HCI,RMOFI      ;IS HCI SET ??
374 043756 001403          BEQ      36$             ;NO !!
375 043760 042737 000200 046112    BIC      #HCE,78$        ;YES - DISABLE ALL HEADER ERRORS
376 043766          36$:
377
378          ;REPORT AN ERROR IF HCRC IS SET AND HEADER ERRORS ARE NOT ENABLED
379 043766 012746 177777          MOV      #-1,-(SP)       ;ASSUME ERRORS ENABLED
380 043772 032737 000200 046112    BIT      #HCE,78$        ;ARE HEADER ERRORS ENABLED ??
381 044000 001002          BNE      37$             ;YES !!
382 044002 042716 000400          BIC      #HCRC,(SP)      ;DISABLE HCRC
383 044006 013737 001352 001142 37$:      MOV      RMER1I,$BDDAT    ;GET RECEIVED STATUS
384 044014 042637 001142          BIC      (SP)+,$BDDAT    ;RESET HCRC IF ENABLED
385 044020 001412          BEQ      38$             ;BRANCH IF HCRC IS OK
386 044022 062716 000004          ADD      #4,(SP)         ;MOVE SP TO USERS ERROR CALL
387 044026 112776 000035 000000    MOV      #35,@(SP)       ;WRITE ERROR NUMBER IN CALL
388 044034 162716 000002          SUB      #2,(SP)         ;MOVE SP TO ERROR RETURN
389 044040 004736          JSR      PC,@(SP)+       ;REPORT ERROR AND RETURN
390 044042 162716 000010          SUB      #10,(SP)        ;MOVE SP TO NO ERROR
391 044046          38$:
392
393          ;REPORT ERROR IF HCE IS SET AND HEADER ERRORS ARE NOT ENABLED
394 044046 012746 177777          MOV      #-1,-(SP)       ;ASSUME ERRORS ENABLED
395 044052 032737 000200 046112    BIT      #HCE,78$        ;ARE ERRORS ENABLED ??
396 044060 001002          BNE      39$             ;YES !!
397 044062 042716 000200          BIC      #HCE,(SP)       ;DISABLE HCE
398 044066 013737 001352 001142 39$:      MOV      RMER1I,$BDDAT    ;GET RECEIVED STATUS
399 044074 042637 001142          BIC      (SP)+,$BDDAT    ;CLEAR HCE IF ENABLED
    
```

```

400 044100 001412          BEQ      40$          :BRANCH IF HCE IS OK
401 044102 062716 000004  ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
402 044106 112776 000036 000000  MOVVB   #36,@(SP)    :WRITE ERROR NUMBER IN CALL
403 044114 162716 000002  SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
404 044120 004736  JSR     PC,@(SP)+    :REPORT ERROR AND RETURN
405 044122 162716 000010  SUB      #10,(SP)     :MOVE SP TO NO ERROR
406 044126          40$:
407
408          :REPORT ERROR IF FER IS SET AND HEADER ERRORS ARE NOT ENABLED
409 044126 012746 177777  MOV      #-1,-(SP)    :ASSUME FER IS ENABLED
410 044132 032737 000200 046112  BIT      #HCE,78$     :ARE HEADER ERRORS ENABLED ??
411 044140 001002  BNE      41$          :YES !!
412 044142 042716 000020  BIC      #FER,(SP)    :DISABLE FER
413 044146 013737 001352 001142 41$:  MOV      RMER11,$BDDAT :GET RECEIVED STATUS
414 044154 042637 001142  BIC      (SP)+,$BDDAT :RESET FER IF ENABLED
415 044160 001412  BEQ      42$          :BRANCH IF FER OK
416 044162 062716 000004  ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
417 044166 112776 000037 000000  MOVVB   #37,@(SP)    :WRITE ERROR NUMBER IN CALL
418 044174 162716 000002  SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
419 044200 004736  JSR     PC,@(SP)+    :REPORT ERROR AND RETURN
420 044202 162716 000010  SUB      #10,(SP)     :MOVE SP TO NO ERROR
421 044206          42$:
422
423          :REPORT ERROR IF BSE IS SET AND HEADER ERRORS ARE NOT ENABLED
424 044206 012746 177777  MOV      #-1,-(SP)    :ASSUME ERRORS ENABLED
425 044212 032737 000200 046112  BIT      #HCE,78$     :ARE THEY ENABLED ??
426 044220 001002  BNE      43$          :YES !!
427 044222 042716 100000  BIC      #BSE,(SP)    :DISABLE BSE
428 044226 013737 001400 001142 43$:  MOV      RMER21,$BDDAT :GET RECEIVED STATUS
429 044234 042637 001142  BIC      (SP)+,$BDDAT :CLEAR BSF IF ENABLED
430 044240 001412  BEQ      44$          :BRANCH IF BSE OK
431 044242 062716 000004  ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
432 044246 112776 000354 000000  MOVVB   #354,@(SP)   :WRITE ERROR NUMBER
433 044254 162716 000002  SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
434 044260 004736  JSR     PC,@(SP)+    :REPORT ERROR AND RETURN
435 044262 162716 000010  SUB      #10,(SP)     :MOVE SP TO NO ERROR
436 044266          44$:
437
438          :HCE IS USED AS THE ENABLING BIT FOR DETECTING SSE, SO REESTABLISH ENTRY
439          :FROM THE FUNCTION CODE TABLE, TO CHECK THE "SSE" BIT
440 044266 010046  MOV      R0,-(SP)     ;;PUSH R0 ON STACK
441 044270 013700 046120  MOV      #81,R0       :GET FUNCTION CODE
442 044274 016037 067244 046112  MOV      FNCDTB(R0),78$ :STORE FUNCTION TABLE ENTRY
443 044302 012600  MOV      (SP)+,R0     ;;POP STACK INTO R0
444
445          :IF SKIP SECTOR ERROR INHIBIT (SSEI) IS SET OR FORMAT 16 (FMT) IS CLEAR,
446          :RESET THE ENABLING BIT (HCE), OTHERWISE LEAVE ENABLING BIT (HCE) SET.
447 044304 032737 010000 001370  BIT      #FMT16,RMOFI  :18 BIT FORMAT MODE ?
448 044312 001404  BEQ      45$          :BR IF YES
449 044314 032737 001000 001370  BIT      #SSEI,RMOFI  :IS SSEI SET ?
450 044322 001403  BEQ      46$          :BR IF NO
451 044324 042737 000200 046112 45$:  BIC      #HCE,78$     :DISABLE HEADER ERROR
452 044332          46$:
453
454          :REPORT ERROR IF SSE IS SET AND HEADER ERROR IS NOT ENABLED
455 044332 012746 177777  MOV      #-1,-(SP)    :ASSUME ERRORS ENABLED
456 044336 032737 000200 046112  BIT      #HCE,78$     :IS HCE ENABLED ?
    
```

```

457 044344 001002          BNE      47$          :YES !!
458 044346 042716 000040    BIC      #SSE,(SP)    :DISABLE SSE
459 044352 013737 001400 001142 47$:  MOV      RMER21,$BDDAT :GET RECEIVED STATUS
460 044360 042637 001142    BIC      (SP)+,$BDDAT :CLEAR SSE IF NOT VALID FOR FUNCTION
461 044364 001412          BEQ      48$          :BRANCH IF SSE OK
462 044366 062716 000004    ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
463 044372 112776 000063 000000    MOV      #63,@(SP)    :WRITE ERROR NUMBER
464 044400 162716 000002    SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
465 044404 004736          JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
466 044406 162716 000010    SUB      #10,(SP)     :MOVE SP TO NO ERROR
467 044412          48$:
468
469          :BIT 06 OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR DATA
470          :FIELD ERRORS, I.E.,
471          :
472          :   RMCS2 - MDPE
473          :   RMER1 - DCK,ECH
474          :NOTE:
475          :
476          :   ECH CANNOT SET UNLESS IT IS ENABLED AND ECI IS RESET AND
477          :   DCK IS SET.
478 044412 012746 177777    :REPORT ERROR IF MDPE IS SET AND IS NOT ENABLED
479 044416 032737 000100 046112    MOV      #-1,-(SP)    :ASSUME ENABLED
480 044424 001002          BIT      #ECH,78$     :ARE DATA FIELD ERRORS ENABLED ??
481 044426 042716 000400    BNE      49$          :YES !!
482 044432 013737 001346 001142 49$:  MOV      #MDPE,(SP)   :DISABLE MDPE
483 044440 042637 001142    MOV      RMCS21,$BDDAT :GET RECEIVED STATUS
484 044444 001412          BIC      (SP)+,$BDDAT :CLEAR MDPE IF ENABLED
485 044446 062716 000004    BEQ      50$          :BRANCH IF MDPE OK
486 044452 112776 000027 000000    ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
487 044460 162716 000002    MOV      #27,@(SP)    :WRITE ERROR NUMBER IN CALL
488 044464 004736          SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
489 044466 162716 000010    JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
490 044472          SUB      #10,(SP)     :MOVE SP TO NO ERROR
491          50$:
492          :REPORT ERROR IF DCK IS SET AND DATA FIELD ERRORS ARE NOT ENABLED
493 044472 012746 177777    MOV      #-1,-(SP)    :ASSUME ENABLED
494 044476 032737 000100 046112    BIT      #ECH,78$     :ARE THEY ENABLED ??
495 044504 001002          BNE      51$          :YES !!
496 044506 042716 100000    BIC      #DCK,(SP)    :DISABLE DCK
497 044512 013737 001352 001142 51$:  MOV      RMER11,$BDDAT :GET RECEIVED STATUS
498 044520 042637 001142    BIC      (SP)+,$BDDAT :CLEAR DCK IF ENABLED
499 044524 001412          BEQ      52$          :BRANCH IF DCK IS (X
500 044526 062716 000004    ADD      #4,(SP)      :MOVE SP TO USERS ERROR CALL
501 044532 112776 000030 000000    MOV      #30,@(SP)    :WRITE ERROR NUMBER IN CALL
502 044540 162716 000002    SUB      #2,(SP)      :MOVE SP TO ERROR RETURN
503 044544 004736          JSR      PC,@(SP)+    :REPORT ERROR AND RETURN
504 044546 162716 000010    SUB      #10,(SP)     :MOVE SP TO NO ERROR
505 044552          52$:
506
507          :REPORT ERROR IF ECH IS SET AND,
508          :   DATA FIELD ERRORS ARE NOT ENABLED, OR
509          :   ECI IS SET, OR
510          :   DCK IS NOT SET.
511 044552 012746 177777    MOV      #-1,-(SP)    :ASSUME ENABLED
512 044556 032737 000100 046112    BIT      #ECH,78$     :ARE ERRORS ENABLED ??
513 044564 001410          BEQ      53$          :NO !!
    
```

```
514 044566 032737 004000 001370 BIT #ECI,RMOFI ;IS ECI SET ??
515 044574 001004 BNF 53$ ;YES !!
516 044576 032737 100000 001352 BIT #DCK,RMER11 ;IS DCK ALSO SET ??
517 044604 001002 BNE 54$ ;YES !!
518 044606 042716 000100 53$: BIC #ECH,(SP) ;DISABLE ECH
519 044612 013737 001352 001142 54$: MOV RMER11,$BDDAT ;GET RECEIVED STATUS
520 044620 042637 001142 BIC (SP)+,$BDDAT ;CLEAR ECH IF ENABLED
521 044624 001412 BEQ 55$ ;BRANCH IF ECH IS OK
522 044626 062716 000004 ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
523 044632 112776 000031 000000 MOVB #31,@(SP) ;WRITE ERROR NUMBER IN CALL
524 044640 162716 000002 SUB #2,(SP) ;MOVE SP TO ERROR RETURN
525 044644 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
526 044646 162716 000010 SUB #10,(SP) ;MOVE SP TO NO ERKOR
527 044652 55$:
528
529
530 ;*****
531 ;*PERFORM THE REMAINING ERROR CHECKS FGR DATA TRANSFER COMMANDS
532 ;*****
533 044652 022737 000030 046120 CMP #SEARCH,81$ ;WAS DATA TRANSFERRED ?
534 044660 103402 BLO 56$ ;BR IF YES
535 044662 000137 046064 JMP 75$ ;NO - EXIT
536
537 ;REPORT ERROR IF RMWC NOT ZERO AND TRE IS ZERO
538 044666 013737 001340 001142 56$: MOV RMWCI,$BDDAT ;WORD COUNT ZERO??
539 044674 001421 BEQ 57$ ;YES
540 044676 032737 040000 001336 BIT #TRE,RMCS11 ;TRANSFER ERROR DETECTED??
541 044704 001015 BNE 57$ ;YES!!
542 044706 062716 000004 ADD #4,(SP)
543 044712 112776 000015 000000 MOVB #15,@(SP) ;ERROR NUMBER
544 044720 005037 001140 CLR $GDDAT ;GOOD DATA FOR TYPEOUT
545 044724 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
546 044730 004736 JSR PC,@(SP)+ ;REPORT WORD COUNT NOT ZERO
547 044732 162716 000010 SUB #10,(SP) ;RESTORE (SP)
548 044736 000240 NOP
549
550 ;REPORT ERROR IF RMBA IS NOT CORRECT
551 044740 013737 001340 001140 57$: MOV RMWCI,$GDDAT ;GET WORD COUNT AT END OF TRANSFER AND
552 044746 163737 001414 001140 SUB RMWCO,$GDDAT ;SUBTRACT STARTING WORD COUNT.
553 044754 006337 001140 ASL $GDDAT ;* 2
554 044760 063737 001416 001140 ADD RMBAO,$GDDAT ;ADD STARTING BUS ADDRESS
555
556 044766 032737 000010 001346 BIT #BAI,RMCS21 ;WAS BUS ADDRESS INHIBIT (BAI) SET ??
557 044774 001403 BEQ 58$ ;NO !!
558 044776 013737 001416 001140 MOV RMBAO,$GDDAT ;ADDRESS SHOULD NOT HAVE CHANGED
559
560 045004 023737 001140 001342 58$: CMP $GDDAT,RMBAI ;BUS ADDRESS OK??
561 045012 001416 BEQ 59$ ;YES!!
562 045014 013737 001342 001142 MOV RMBAI,$BDDAT ;BAD DATA FOR TYPEOUT
563 045022 062716 000004 ADD #4,(SP)
564 045026 112776 000016 000000 MOVB #16,@(SP) ;ERROR NUMBER
565 045034 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
566 045040 004736 JSR PC,@(SP)+ ;REPORT UNEXPECTED ADDRESS
567 045042 162716 000010 SUB #10,(SP) ;RESTORE (SP)
568 045046 000240 NOP
569
570 ;COMPUTE NUMBER OF SECTORS TRANSFERRED FROM WORD COUNT
```

I
R
B
O
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

```

571 045050 005046          59$: CLR      -(SP)      ;NUMBER OF SECTORS TRANSFERRED
572 045052 013746 001340   MOV      RMWCI,-(SP)   ;GET WORD COUNT AT END OF TRANSFER AND
573 045056 163716 001414   SUB      RMWCO,(SP)   ;SUBTRACT STARTING WORD COUNT.
574
575 045062 012746 000400   MOV      #256,-(SP)   ;ASSUME 256. WORDS PER SECTOR
576 045066 032737 000002 001412 BIT      #BIT1,RMCS10 ;HEADER & DATA COMMAND ??
577 045074 001402          BEQ      60$          ;NO !!
578 045076 062716 000002   ADD      #2,(SP)      ;CHANGE TO 258. WORDS PER SECTOR
579
580 045102 005266 000004   60$: INC      4(SP)      ;INCREMENT SECTOR COUNT
581 045106 161666 000002   SUB      (SP),2(SP)   ;SUBTRACT ONE SECTOR'S WORTH
582 045112 003373          BGT      60$          ;CONTINUE IF NOT DONE
583 045114 022626          CMP      (SP)+,(SP)+  ;RESTORE STACK
584
585 ;COMPUTE EXPECTED SECTOR, TRACK AND CYLINDER ADDRESS FROM
586 ;NUMBER OF SECTORS
587 045116 013737 001446 046112 MOV      RMDCO,78$    ;STORE ORIGINAL CYLINDER
588 045124 013737 001420 046114 MOV      RMDAO,79$    ;STORE ORIGINAL TRACK
589 045132 013737 001420 046116 MOV      RMDAO,80$    ;STORE ORIGINAL SECTOR
590 045140 013737 001334 046122 MOV      LSTRK,82$    ;STORE LAST TRACK.
591 045146 000337 046122   SWAB     82$          ;GET TRACK ADDRESS TO LO BYTE AND
592 045152 005237 046122   INC      82$          ;INCREMENT TO GET TOTL # OF TRACKS.
593
594 045156 042737 000377 046114 BIC      #^CTADMSK,79$ ;SAVE TRACK ADDRESS BITS AND
595 045164 000337 046114   SWAB     79$          ;GET TRACK ADDRESS TO LO BYTE.
596 045170 042737 177400 046116 BIC      #^CSADMSK,80$ ;SAVE SECTOR ADDRESS BITS
597 045176 062637 046116   ADD      (SP)+,80$
598
599 045202 032737 001000 001444 BIT      #SSEI,RMOFO  ;WAS SSEI SET ?
600 045210 001111          BEQ      61$          ;NO !!
601
602 045212 023727 046116 000040 CMP      80$,#32.     ;SECTOR OVEFLOWED??
603 045220 103417          BLO      63$          ;NO!!
604 045222 005237 046114   INC      79$          ;INCREMENT TRACK
605 045226 162737 000040 046116 SUB      #32.,80$     ;ADJUST SECTOR
606
607 045234 023727 046116 000037 61$: CMP      80$,#31.     ;SECTOR OVEFLOWED ?
608 045242 103406          BLO      63$          ;NO !!
609 045244 005237 046114   62$: INC      79$          ;INCREMENT TRACK
610 045250 162737 000037 046116 SUB      #31.,80$     ;ADJUST SECTOR
611 045256 000766          BR       61$          ;TRY AGAIN
612
613 045260 023737 046114 046122 63$: CMP      79$,82$    ;TRACK OVEFLOWED??
614 045266 103407          BLO      64$          ;NO!!
615 045270 005237 046112   INC      78$          ;INCREMENT CYLINDER
616 045274 163737 046122 046114 SUB      82$,79$     ;ADJUST TRACK
617 045302 000766          BR       63$          ;TRY AGAIN
618 045304 000240          NOP
619
620 ;REPORT ERROR IF "SSEI" IS SET AFTER TRACK SWITCHING OCCURED
621 ;THRU DATA TRANSFER
622 045306 005037 001140   64$: CLR      $GDDAT    ;SETUP EXPECTED SSEI = 0
623 045312 013737 001370 001142 MOV      RMOFI,$BDDAT ;GET RECIEVED DATA AND
624 045320 042737 176777 001142 BIC      #^CSSEI,$BDDAT ;SAVE SSEI BIT FOR COMPARE.
625
626 045326 032737 001000 001444 BIT      #SSEI,RMOFO  ;WAS SSEI SET BEFORE DATA TRANSFER ?
627 045334 001420          BEQ      66$          ;NO
    
```

```

628 045336 125737 001421 001345      CMPB   RMDAO+1,RMDAI+1 ;DID TRACK SWITCH OCCUR ?
629 045344 001411                      BEQ    65$              ;NO
630 045346 005737 001142                      TST   $BDDAT           ;IS SSEI STILL SET ?
631 045352 001430                      BEQ    68$              ;NO
632 045354 062716 000004                      ADD   #4,(SP)          ;POINT TO ERROR
633 045360 112776 000225 000000          MOVB  #225,@(SP)       ;DEFINE ERROR NUMBER
634 045366 000414                      BR    67$              ;
635
636                                     ;REPORT ERROR IF "SSEI" IS INCORRECT
637 045370 012737 001000 001140          65$:  MOV   #SSEI,$GDDAT   ;SETUP EXPECTED SSEI = 1
638 045376 023737 001140 001142          66$:  CMP   $GDDAT,$BDDAT ;IS SSEI CORRECT ?
639 045404 001413                      BEQ    68$              ;YES
640 045406 062716 000004                      ADD   #4,(SP)          ;POINT TO ERROR
641 045412 112776 000226 000000          MOVB  #226,@(SP)       ;DEFINE ERROR NUMBER
642 045420 162716 000002                      67$:  SUB   #2,(SP)       ;ADJUST RETURN TO ERROR
643 045424 004736                      JSR   PC,@(SP)+        ;REPORT ERROR
644 045426 162716 000010                      SUB   #10,(SP)         ;RESTORE (SP)
645 045432 000240                      NOP
646
647                                     ;REPORT ERROR IF "LBT" IS NOT CORRECT
648 045434 005037 001140                      68$:  CLR   $GDDAT        ;SET GOOD DATA FOR LBT = 0
649 045440 023727 046112 001060          CMP   78$,#560.        ;SHOULD LBT BE SET??
650 045446 101407                      BLOS  69$              ;NO!!
651 045450 032737 002000 001352          BIT   #IAE,RMER1I      ;WAS IAE SET ??
652 045456 001003                      BNE   69$              ;YES - LBT SHOULD NOT BE SET
653 045460 012737 002000 001140          MOV   #LBT,$GDDAT      ;SET GOOD DATA FOR LBT = 1
654 045466 013737 001350 001142          69$:  MOV   RMDSI,$BDDAT ;BAD DATA FOR TYPEOUT
655 045474 042737 175777 001142          BIC   #^CLBT,$BDDAT
656 045502 023737 001140 001142          CMP   $GDDAT,$BDDAT   ;IS LBT CORRECT??
657 045510 001413                      BEQ    70$              ;YES!!
658 045512 062716 000004                      ADD   #4,(SP)          ;
659 045516 112776 000017 000000          MOVB  #17,@(SP)        ;ERROR NUMBER
660 045524 162716 000002                      SUB   #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
661 045530 004736                      JSR   PC,@(SP)+        ;REPORT LBT IS WRONG
662 045532 162716 000010                      SUB   #10,(SP)         ;RESTORE (SP)
663 045536 000240                      NOP
664
665                                     ;REPORT ERROR IF "AOE" IS INCORRECT
666 045540 005037 001140                      70$:  CLR   $GDDAT        ;SET FOR AOE = 0
667 045544 032737 002000 001352          BIT   #IAE,RMER1I      ;WAS "IAE" DETECTED??
668 045552 001031                      BNE   72$              ;YES-"AOE" SHOULD BE ZERO
669 045554 023727 046112 001060          CMP   78$,#560.        ;SHOULD AOE BE SET??
670 045562 101425                      BLOS  72$              ;NO!!
671 045564 005737 046114                      TST   79$              ;MAYBE
672 045570 001012                      BNE   71$              ;YES
673 045572 005737 046116                      TST   80$              ;
674 045576 001007                      BNE   71$              ;YES !!
675 045600 032737 000010 046120          BIT   #F2,81$ ;WAS THIS READ OR WRITE CHECK ??
676 045606 001413                      BEQ    72$              ;NO !!
677 045610 005737 001340                      TST   RMWCI            ;WAS ALL DATA TRANSFERRED ??
678 045614 001410                      BEQ    72$              ;YES !!
679 045616 012737 001000 001140          71$:  MOV   #AOE,$GDDAT   ;SET FOR AOE = 1
680 045624 005037 046114                      CLR   79$              ;CLEAR EXPECTED TRACK
681 045630 012737 000001 046116          MOV   #1,80$           ;EXPECT SECTOR = 1
682 045636 013737 001352 001142          72$:  MOV   RMER1I,$BDDAT ;BAD DATA FOR TYPEOUT
683 045644 042737 176777 001142          BIC   #^CAOE,$BDDAT
684 045652 023737 001140 001142          CMP   $GDDAT,$BDDAT   ;IS AOE CORRECTY??
    
```

```

685 045660 001413          BEQ      73$          ;YES!!
686 045662 062716 000004    ADD      #4,(SP)
687 045666 112776 000020 000000    MOVB    #20,@(SP)    ;ERROR NUMBER
688 045674 162716 000002          SUB      #2,(SP)    ;MOVE SP TO RETURN FOR ERROR
689 045700 004736          JSR     PC,@(SP)+    ;REPORT AOE IS WRONG
690 045702 162716 000010    SUB      #10,(SP)   ;RESTORE (SP)
691 045706 000240          NOP
692
693
694 045710 032737 002000 001352    ;REPORT ERROR IF RMDA IS NOT CORRECT
73$: BII     #IAE,RMER1I ;WAS THERE AN IAE ERROR ??
695 045716 001062          BNE     75$          ;YES - DONT CHECK RMDA,RMDC
696 045720 013737 046114 001140    MOV     79$,$GDDAT  ;SETUP EXPECTED DISK ADDRESS
697 045726 000337 001140          SWAB   $GDDAT
698 045732 113737 046116 001140    MOVB   80$,$GDDAT
699 045740 013737 001344 001142    MOV     RMDAI,$BDDAT ;SETUP RECEIVED DISK ADDRESS
700 045746 023737 001140 001142    CMP     $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
701 045754 001413          BEQ     74$          ;BRANCH IF EQUAL
702 045756 062716 000004    ADD     #4,(SP)
703 045762 112776 000021 000000    MOVB   #21,@(SP)    ;ERROR NUMBER
704 045770 162716 000002          SUB     #2,(SP)    ;MOVE SP TO RETURN FOR ERROR
705 045774 004736          JSR     PC,@(SP)+    ;REPORT BAD DISK ADDRESS
706 045776 162716 000010    SUB     #10,(SP)   ;RESTORE (SP)
707 046002 000240          NOP
708
709
710 046004 013737 046112 001140    ;REPORT ERROR IF RMDC IS INCORRECT
74$: MOV     78$,$GDDAT ;SETUP EXPECTED CYLINDER
711 046012 042737 176000 001140    BIC     #^C1777,$GDDAT
712 046020 013737 001372 001142    MOV     RMDCI,$BDDAT ;SETUP RECEIVED CYLINDER
713 046026 023737 001140 001142    CMP     $GDDAT,$BDDAT ;COMPARE CYLINDERS
714 046034 001413          BEQ     75$          ;BRANCH IF EQUAL
715 046036 062716 000004    ADD     #4,(SP)
716 046042 112776 000022 000000    MOVB   #22,@(SP)    ;ERROR NUMBER
717 046050 162716 000002          SUB     #2,(SP)    ;MOVE SP TO RETURN FOR ERROR
718 046054 004736          JSR     PC,@(SP)+    ;REPORT BAD CYLINDER
719 046056 162716 000010    SUB     #10,(SP)   ;RESTORE (SP)
720 046062 000240          NOP
721
722 046064 062716 000004    75$:   ADD     #4,(SP)    ;MOVE (SP) TO ERROR CALL
723 046070 105776 000000          TSTB   @(SP)        ;WAS ERROR FOUND??
724 046074 001403          BEQ     76$
725 046076 062716 000004          ADD     #4,(SP)    ;MOVE (SP) TO ERROR RETURN
726 046102 000402          BR     77$
727 046104 162716 000004    76$:   SUB     #4,(SP)    ;MOVE (SP) TO NO ERROR RETURN
728 046110 000207    77$:   RTS     PC
729
730 046112 000000    78$:   .WORD 0          ;CYLINDER
731 046114 000000    79$:   .WORD 0          ;TRACK
732 046116 000000    80$:   .WORD 0          ;SECTOR
733 046120 000000    81$:   .WORD 0          ;FUNCTION CODE
734 046122 000000    82$:   .WORD 0          ;TOTAL # OF TRACKS = LAST TRACK +1
    
```


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL COMPOSITE ERROR CHECK SUBROUTINE

:THIS SUBROUTINE CHECKS THE STORED CONTENTS OF RMER1 AND
 :RMER2 AFTER MASKING EACH REGISTER WORD WITH THE USER'S STATUS
 :MASKS AND REPORTS AN ERROR IF ANY BITS ARE LEFT ON AFTER
 :THE MASKS ARE APPLIED.

```

:CALL:
:(1) JSR      PC,CMPERRSTS      MASK FOR ERROR REGISTER 1
      .WORD   .WORD           MASK FOR ERROR REGISTER 2
      BR      ???              RETURN HERE IF NO ERROR
      NOP     .WORD           RETURN HERE TO REPORT AN ERROR
      ERROR  .WORD           ERROR NUMBER DEFINED BY SUB
      JSR     PC,@(SP)+        GO BACK TO SUB FOR MORE ERROR CHECKS
      ???
    
```

:NOTE: BITS TO BE MASKED SHOULD BE ONE; BITS TO BE TESTED SHOULD
 :BE ZERO

CMPEERRSTS:

```

:MASK AND STORE THE CONTENTS OF RMER1 AND RMER2
MOV     RMER1,$TMP1      :STORE RMER1 AT TEMP STORAGE
BIC     @(SP),$TMP1     :MASK RMER1
ADD     #2,(SP)         :MOVE SP TO NEXT MASK
MOV     RMER2,$TMP2     :STORE RMER2 AT TEMP STORAGE
BIC     @(SP),$TMP2     :MASK RMER2
    
```

```

:CLEAR USER'S ERROR CALL
ADD     #6,(SP)         :MOVE SP TO USER'S ERROR CALL
CLRB   @(SP)           :CLEAR ERROR NUMBER
SUB     #4,(SP)         :LEAVE SP AT NO ERROR RETURN
    
```

```

:SEE IF THERE WERE ANY ERRORS IN RMER1, I.E., $TMP1
TST     $TMP1          :ANY ERRORS TO REPORT??
BEQ     1$             :NO !!
MOV     $TMP1,$BDDAT  :RECEIVED STATUS FOR TYPEOUT
CLR     $GDDAT        :EXPECTED STATUS FOR TYPEOUT
ADD     #4,(SP)       :MOVE SP TO USER'S ERROR CALL
MOVB   #6,@(SP)      :CORRECTABLE DATA CHECK ERROR #
SUB     #2,(SP)       :MOVE SP TO RETURN FOR ERROR
JSR     PC,@(SP)+    :REPORT ERROR VIA USER
SUB     #10,(SP)     :MOVE SP BACK TO BRANCH
NOP
    
```

1\$:

```

:SEE IF THERE ARE ANY ERRORS TO REPORT IN RMER2 ($TMP2)
TST     $TMP2          :ANY ERRORS IN RMER2?
BEQ     2$             :NO!!
MOV     $TMP2,$BDDAT  :RECEIVED STATUS FOR TYPEOUT
CLR     $GDDAT        :EXPECTED STATUS FOR TYPEOUT
ADD     #4,(SP)       :MOVE SP TO USER'S ERROR CALL
MOVB   #6,@(SP)      :WRITE ERROR NUMBER IN USER'S CALL
SUB     #2,(SP)       :MOVE SP TO RETURN FOR ERROR
    
```

```

046124
046124 015737 001352 001176
046132 047637 000000 001176
046140 062716 000002
046144 013737 001400 001200
046152 047637 000000 001200
046160 062716 000006
046164 105076 000000
046170 162716 000004
046174 005737 001176
046200 001420
046202 013737 001176 001142
046210 005037 001140
046214 062716 000004
046220 112776 000066 000000
046226 162716 000002
046232 004736
046234 162716 000010
046240 000240
046242
046242 005737 001200
046246 001420
046250 013737 001200 001142
046256 005037 001140
046262 062716 000004
046266 112776 000067 000000
046274 162716 000002
    
```

58	046300	004736		JSR	PC,@(SP)+	:REPORT ERROR VIA USER
59	046302	162716	000010	SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
60	046306	000240		NOP		
61	046310					
62			2\$:			
63						:AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
64	046310	062716	000004	ADD	#4,(SP)	:MOVE SP TO USER'S ERROR CALL
65	046314	105716	000000	TSTB	@(SP)	:WAS THERE AN ERROR CALLED??
66	046320	001403		BEQ	3\$:NO!!
67	046322	062716	000004	ADD	#4,(SP)	:YES - MOVE SP TO ERROR RETURN
68	046326	000402		BR	4\$	
69	046330	162716	000004	3\$: SUB	#4,(SP)	:MOVE SP TO NO ERROR RETURN
70	046334	000207	4\$:	RTS	PC	:RETURN TO USER

```

1      .SBTTL  DEVICE SELECT SUBROUTINE
2
3      ; THIS SUBROUTINE SELECTS THE DEVICE, GETTING THE DEVICE NUMBER FROM THE
4      ; TEST QUEUE.
5
6      ;CALL:
7      ;(1)  JSR    PC,DEVSEL
8      ;(2)  BR     ??          RETURN IF NO ERROR
9      ;(3)  NOP
10     ;(4)  ERROR          RETURN IF ERROR
11                                ERROR DEFINED BY SUBROUTINE
12 046336  DEVSEL:
13
14     ;CLEAR USER'S ERROR CALL
15 046336 062716 000004      ADD    #4,(SP)          ;MOVE SP TO USER'S ERROR
16 046342 105076 000000      CLRB  @ (SP)          ;CLEAR LOW ORDER BYTE OF CALL
17 046346 162716 000004      SUB    #4,(SP)          ;MOVE SP BACK
18
19     ;SAVE USER'S INFORMATION AND SETUP REGISTERS
20 046352 013746 000004      MOV    ERRVEC,-(SP)    ;;PUSH ERRVEC ON STACK
21 046356 013746 000006      MOV    ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
22 046362 010046             MOV    R0,-(SP)        ;;PUSH R0 ON STACK
23 046364 010146             MOV    R1,-(SP)        ;;PUSH R1 ON STACK
24 046366 012737 046506 000004  MOV    #2$,ERRVEC     ;SETUP FOR BUS TIMEOUT
25 046374 012737 000300 000006  MOV    #PR6,ERRVEC+2
26 046402 013700 001276       MOV    $BASE,R0       ;R0 = UNIBUS ADDRESS
27 046406 013701 001466       MOV    TSTQUE,R1      ;R1 POINTS TO DEVICE NUMBER
28
29     ;SELECT DEVICE AND VERIFY THAT DEVICE IS AVAILABLE
30
31 046412 111160 000010       MOV    (R1),RMCS2(R0) ;WRITE UNIT SELECT BITS
32 046416 016037 000000 001176  MOV    RMCS1(R0),$TMP1 ;GET 'DVA' STATUS
33 046424 016037 000010 001174  MOV    RMCS2(R0),$TMP0 ;GET 'NED' STATUS
34
35 046432 032737 010000 001174  BIT    #NED,$TMP0     ;IS DEVICE NONEXISTENT ?
36 046440 001407             BEQ    1$             ;NO!!
37 046442 062766 000004 000010  ADD    #4,10(SP)      ;MOVE SP TO USERS ERROR CALL
38 046450 112776 000111 000010  MOV    #11,@10(SP)   ;WRITE ERROR NUMBER
39 046456 000422             BR     3$
40
41 046460 032737 004000 001176  1$: BIT    #DVA,$TMP1   ;IS DEVICE AVAILABLE ?
42 046466 001021             BNE    4$             ;YES!!
43 046470 062766 000004 000010  ADD    #4,10(SP)      ;MOVE SP TO USERS ERROR CALL
44 046476 112776 000112 000010  MOV    #112,@10(SP)  ;WRITE ERROR NUMBER
45 046504 000407             BR     3$
46
47     ;HANDLE BUS TIMEOUT
48
49 046506 022626             2$: CMP    (SP)+,(SP)+   ;ADJUST SP
50 046510 062766 000004 000010  ADD    #4,10(SP)      ;MOVE SP TO USERS ERROR CALL
51 046516 112776 000113 000010  MOV    #113,@10(SP)  ;WRITE BUS TIMEOUT ERROR NUMBER
52 046524 162766 000002 000010  3$: SUB    #2,10(SP)   ;ADJUST RETURN TO 'NOP' PRECEDING
53                                ;THE ERROR CALL
54
55     ;RESTORE USERS DATA AND RETURN TO ADDRESS ON STACK
56
57 046532 012601             4$: MOV    (SP)+,R1      ;;POP STACK INTO R1
58 046534 012600             MOV    (SP)+,R0      ;;POP STACK INTO R0
59 046536 012637 000006             MOV    (SP)+,ERRVEC+2 ;;POP STACK INTO ERRVEC+2

```

DEVICE SELECT SUBROUTINE

046542 012637 000004
52 046546 000207

MOV
RTS

(SP)+,ERRVEC
PC

::POP STACK INTO ERRVEC
:EXIT

```

1      .SBTTL  SEEK STATUS CHECK SUBROUTINE
2
3      :THIS SUBROUTINE VERIFIES THE RESULTS OF SEEK TESTS USING STATUS
4      :STORED IN THE GET BUFFER AND TEST PARAMETERS STORED IN THE PUT BUFFER.
5
6      :
7      :THE SUBROUTINE RETURNS TO THE CALLING ROUTINE IF AN ERROR IS DETECTED
8      :AFTER HAVING LOADED THE APPROPRIATE ERROR NUMBER IN THE 'ERROR' TRAP
9      :OF THE CALLING ROUTINE.  SEEK STATUS IS CHECKED AS FOLLOWS:
10
11      :CALL:
12      : (1)  JSR    PC,SEKSTS
13           BR     ???          RETURN HERE IF NO ERROR
14           NOP
15           ERROR          RETURN HERE TO REPORT AN ERROR
16           JSR    PC,@(SP)+   ERROR NUMBER DEFINED BY SUB
17           ???          GO BACK TO SUB FOR MORE ERROR CHECKS
18                           RETURN HERE IF NO MORE ERRORS
19
20      SEKSTS:
21
22      :CLEAR USERS' ERROR CALL
23      :
24      :
25      :
26      :
27
28      :TEST FOR MASSBUS CONTROL BUS PARITY ERROR WHEN WRITING
29      :LOCAL REGISTERS, I.E., 'PAR' = 1 AND 'DPE' = 0
30      :
31      :
32      :
33      :
34
35      :REPORT REGISTER PARITY ERROR VIA USER'S ERROR CALL
36      :
37      :
38      :
39      :
40      :
41      :
42      :
43      :
44
45      :DETERMINE THE VALUE OF "IAE" STATUS BASED ON TRACK, SECTOR, CYLINDER,
46      :AND THE STATUS OF "SSEI" BIT DURING A SEEK OPERATION. ALSO, SET "SKI"
47      :IF CYLINDER ADDRESS IS TOO LARGE.
48      :
49      :
50      :
51      :
52      :
53
54      :
55      :
56
57

```

58	046722	101420			BLOS	2\$:BR IF NO
59	046724	032737	010000	001444	BIT	#FMT16,RMOFO	:18 BIT FORMAT ?
60	046732	001416			BEQ	3\$:YES - SECTOR IS INVALID FOR 18 BIT MODE
61	046734	123727	001420	000036	CMPB	RMDAO,#30.	:SECTOR > 30. ?
62	046742	101410			BLOS	2\$:BR IF NO
63	046744	032737	001000	001444	BIT	#SSEI,RMOFO	:IS SSEI CLEAR ?
64	046752	001406			BEQ	3\$:YES - SECTOR IS INVALID FOR 16 BIT MODE
65	046754	123727	001420	000037	CMPB	RMDAO,#31.	:SECTOR > 31. ?
66	046762	101002			BHI	3\$:YES - SECTOR IS INVALID
67							
68	046764	005037	001140		2\$: CLR	\$GDDAT	: "IAE" SHOULD = 0
69							
70							
71	046770	013737	001352	001142	3\$: MOV	RMER11,\$BDDAT	:COMPARE EXPECTED AND RECIEVED "IAE" STATUS
72	046776	042737	175777	001142	BIC	#^CIAE,\$BDDAT	:IS IAE OK??
73	047004	023737	001140	001142	CMP	\$GDDAT,\$BDDAT	:SAVE IAE BIT FOR COMPARE
74	047012	001004			BNE	4\$:CORRECT "IAE" STATUS ?
75	047014	042737	040000	050026	BIC	#SKI,20\$:BR IF NO
76	047022	000413			BR	5\$:CLEAR SKI FLAG
77	047024				4\$:		:GO CHECK NEXT ERROR
78					:REPORT	INCORRECT "IAE" STATUS VIA USER'S ERROR CALL	
79	047024	062716	000004		ADD	#4,(SP)	
80	047030	112776	000051	000000	MOVB	#51,@(SP)	:ERROR 51
81	047036	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
82	047042	004736			JSR	PC,@(SP)+	:REPORT INCORRECT IAE
83	047044	162716	000010		SUB	#10,(SP)	:RESTORE (SP)
84	047050	000240			NOP		
85	047052				5\$:		
86							
87					:REPORT	ANY IVC ERROR AS	
88					:	IVC ERROR WITH VOLUME VALID ZERO	
89					:	ERRONEOUS IVC ERROR, VOLUME VALID IS SET	
90	047052	032737	010000	001400	BIT	#IVC,RMER21	:IVC ERROR??
91	047060	001427			BEQ	7\$:NO!!
92	047062	005037	001140		CLR	\$GDDAT	:EXPECTED STATUS
93	047066	013737	001400	001142	MOV	RMER21,\$BDDAT	:RECEIVED STATUS
94	047074	062716	000004		ADD	#4,(SP)	:MOVE SP TO USER'S ERROR
95	047100	112776	000060	000000	MOVB	#60,@(SP)	:ERROR 60 IF VV = 0
96	047106	032737	000100	001350	BIT	#VV,RMDSI	
97	047114	001403			BEQ	6\$	
98	047116	112776	000061	000000	MOVB	#61,@(SP)	:ERROR 61 IF VV = 1
99	047124	162716	000002		6\$: SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
100	047130	004736			JSR	PC,@(SP)+	:REPORT ERROR VIA USER
101	047132	162716	000010		SUB	#10,(SP)	:RESTORE SP
102	047136	000240			NOP		
103							
104	047140	013737	001400	001142	7\$: MOV	RMER21,\$BDDAT	:RECEIVED STATUS
105	047146	042737	137777	001142	BIC	#^CSKI,\$BDDAT	:CLEAR DONT CARES
106	047154	013737	050026	001140	MOV	20\$,\$GDDAT	:GET EXPECTED SKI STATUS
107	047162	042737	137777	001140	BIC	#^CSKI,\$GDDAT	:CLEAR DONT CARES
108	047170	001417			BEQ	8\$:BRANCH IF 0 EXPECTED
109							
110					:REPORT	ERROR IF SKI IS NOT SET (IAE WAS NOT DETECTED)	
111	047172	032737	040000	001142	BIT	#SKI,\$BDDAT	:WAS SKI DETECTED ??
112	047200	001032			BNE	9\$:YES !!
113	047202	062716	000004		ADD	#4,(SP)	:MOVE SP TO USERS ERROR CALL
114	047206	112776	000267	000000	MOVB	#267,@(SP)	:WRITE ERROR NUMBER

```

115 047214 162716 000002          SUB      #2,(SP)          ;MOVE SP TO ERROR RETURN
116 047220 004736          JSR      PC,@(SP)+      ;REPORT ERROR AND RETURN
117 047222 162716 000010          SUB      #10,(SP)       ;MOVE SP TO NO ERROR
118 047226 000443          BR       10$           ;GO TO NEXT ERROR CHECK
119 047230          8$:
120
121          ;REPORT ERROR IF SKI IS SET
122 047230 032737 040000 001142      BIT      #SKI,$BDDAT    ;IS SKI SET ??
123 047236 001413          BEQ      9$           ;NO - SKI IS OK
124 047240 062716 000004          ADD      #4,(SP)       ;MOVE (SP) TO ERROR
125 047244 112776 000054 000000      MOV      #54,@(SP)     ;LOAD ERROR NUMBER
126 047252 162716 000002          SUB      #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
127 047256 004736          JSR      PC,@(SP)+      ;REPORT SEEK ERROR
128 047260 162716 000010          SUB      #10,(SP)      ;RESTORE (SP)
129 047264 000240          NOP
130
131          ;REPORT ANY DEVICE CHECK
132 047266 032737 000200 001400      9$: BIT      #DVC,RMER2I  ;WAS THERE DVC DURING SEEK??
133 047274 001420          BEQ      10$         ;NO!!
134 047276 005037 001140          CLR      $GDDAT       ;EXPECTED STATUS
135 047302 013737 001400 001142      MOV      RMER2I,$BDDAT ;RECEIVED STATUS
136 047310 062716 000004          ADD      #4,(SP)
137 047314 112776 000055 000000      MOV      #55,@(SP)    ;ERROR #55
138 047322 162716 000002          SUB      #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
139 047326 004736          JSR      PC,@(SP)+      ;REPORT ERROR VIA USER
140 047330 162716 000010          SUB      #10,(SP)      ;RESTOR! SP
141 047334 000240          NOP
142
143          ;REPORT ANY 'OPI' ERROR AS OPI WITH MOL = 0, OR OPI
144          ;BECAUSE ON CYLINDER LATCH DIDN'T RESET
145 047336 032737 020000 001352      10$: BIT      #OPI,RMER1I ;'OPI' ERROR??
146 047344 001427          BEQ      12$         ;NO!!
147 047346 005037 001140          CLR      $GDDAT       ;EXPECTED STATUS
148 047352 013737 001352 001142      MOV      RMER1I,$BDDAT ;RECEIVED STATUS
149 047360 062716 000004          ADD      #4,(SP)
150 047364 112776 000052 000000      MOV      #52,@(SP)    ;MOVE (SP) TO ERROR
151 047372 032737 010000 001350      MOV      #52,@(SP)    ;LOAD ERROR NUMBER
152 047400 001403          BIT      #MOL,RMDSI   ;WAS MEDIUM ON LINE??
153 047402 112776 000053 000000      BEQ      11$         ;NO!!
154 047410 162716 000002          MOV      #53,@(SP)    ;YES - CHANGE ERROR NUMBER
155 047414 004736          SUB      #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
156 047416 162716 000010          JSR      PC,@(SP)+      ;REPORT 'OPI' ERROR
157 047422 000240          SUB      #10,(SP)      ;RESTORE (SP)
158          NOP
159          ;SEE IF 'PIP' = 0, AND 'ATA', 'MOL' AND 'VV' = 1
160 047424 013746 001350          12$: MOV      RMDSI,-(SP)
161 047430 042716 047677          BIC      #^C<ATA!PIP!MOL!VV>,(SP)
162 047434 022726 110100          CMP      #ATA!MOL!VV,(SP)+
163 047440 001002          BNE      13$         ;ERROR IN RMDS
164 047442 000137 047776          JMP      17$         ;RMDS IS OK
165
166          ;REPORT ERROR IF MOL = 0 AND OPI = 0
167 047446 032737 010000 001350      13$: BIT      #MOL,RMDSI  ;IS MOL RESET??
168 047454 001030          BNE      14$         ;NO - MOL IS SET
169 047456 032737 020000 001352      BIT      #OPI,RMER1I  ;WAS OPI SET
170 047464 001024          BNE      14$         ;YES - DONT REPORT ERROR
171 047466 013737 001350 001140      MOV      RMDSI,$GDDAT  ;EXPECTED STATUS
    
```

```

172 047474 052737 010000 001140      BIS      #MOL,$GDDAT
173 047502 013737 001350 001142      MOV      RMDSI,$BDDAT      ;RECEIVED STATUS
174 047510 062716 000004      ADD      #4,(SP)
175 047514 112776 000062 000000      MOVVB   #62,@(SP)
176 047522 162716 000002      SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
177 047526 004736      JSR      PC,@(SP)+        ;REPORT ERROR VIA USER
178 047530 162716 000010      SUB      #10,(SP)
179 047534 000240      NOP
180
181      ;REPORT AN ERROR IF 'PIP' IS STIL SET AND SKI NOT SET
182 047536 032737 020000 001350 14$: BIT      #PIP,RMDSI      ;IS 'PIP' STILL SET??
183 047544 001430      BEQ     15$              ;NO!!
184 047546 032737 040000 001400      BIT      #SKI,RMER2I     ;WAS 'SKI' SET??
185 047554 001024      BNE     15$              ;YES-DONT REPORT PIP
186 047556 013737 001350 001140      MOV      RMDSI,$GDDAT    ;EXPECTED STATUS
187 047564 042737 020000 001142      BIC      #PIP,$BDDAT
188 047572 013737 001350 001142      MOV      RMDSI,$BDDAT    ;RECEIVED STATUS
189 047600 062716 000004      ADD      #4,(SP)          ;MOVE (SP) TO ERROR
190 047604 112776 000056 000000      MOVVB   #56,@(SP)        ;LOAD ERROR NUMBER
191 047612 162716 000002      SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
192 047616 004736      JSR      PC,@(SP)+        ;REPORT 'PIP' SET AFTER SEEK
193 047620 162716 000010      SUB      #10,(SP)        ;RESTORE (SP)
194 047624 000240      NOP
195
196      ;REPORT AN ERROR IF 'ATA' IS NOT SET
197 047626 032737 100000 001350 15$: BIT      #ATA,RMDSI      ;WAS 'ATA' SET ??
198 047634 001024      BNE     16$              ;YES!!
199 047636 013737 001350 001140      MOV      RMDSI,$GDDAT    ;EXPECTED STATUS
200 047644 052737 110600 001140      BIS      #ATA!MOL!DPR!DRY,$GDDAT
201 047652 013737 001350 001142      MOV      RMDSI,$BDDAT    ;RECEIVED STATUS
202 047660 062716 000004      ADD      #4,(SP)          ;MOVE (SP) TO ERROR
203 047664 112776 000057 000000      MOVVB   #57,@(SP)        ;LOAD ERROR NUMBER
204 047672 162716 000002      SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
205 047676 004736      JSR      PC,@(SP)+        ;REPORT ATTENTION NOT SET DURING
206      ;SEEK TEST
207 047700 162716 000010      SUB      #10,(SP)        ;RESTORE (SP)
208 047704 000240      NOP
209
210      ;REPORT ERROR IF VOLUME VALID IS RESET AND IVC IS ZERO
211 047706 032737 000100 001350 16$: BIT      #VV,RMDSI      ;IS VV = 0 ??
212 047714 001030      BNE     17$              ;NO!!
213 047716 032737 010000 001400      BIT      #IVC,RMER2I     ;IS IVC ALSO 0 ??
214 047724 001024      BNE     17$              ;NO - IVC IS SET
215 047726 013737 001350 001140      MOV      RMDSI,$GDDAT    ;EXPECTED STATUS
216 047734 052737 000100 001140      BIS      #VV,$GDDAT
217 047742 013737 001350 001142      MOV      RMDSI,$BDDAT    ;RECEIVED STATUS
218 047750 062716 000004      ADD      #4,(SP)
219 047754 112776 000064 000000      MOVVB   #64,@(SP)        ;ERROR #64
220 047762 162716 000002      SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
221 047766 004736      JSR      PC,@(SP)+
222 047770 162716 000010      SUB      #10,(SP)
223 047774 000240      NOP
224 047776      17$:
225
226      ;MODIFY THE RETURN ADDRESS IF AN ERROR WAS DETECTED
227 047776 000240      NOP
228 050000 062716 000004      ADD      #4,(SP)          ;MOVE (SP) TO ERROR CALL
    
```


229	050004	105776	000000		TSTB	@(SP)	:WAS ERROR CALLED??
230	050010	001403			BEQ	18\$:NO!!
231	050012	062716	000004		ADD	#4,(SP)	:MOVE TO ERROR RETURN
232	050016	000402			BR	19\$	
233							
234	050020	162716	000004	18\$:	SUB	#4,(SP)	:MOVE (SP) TO NO ERROR RETURN
235	050024	000207		19\$:	RTS	PC	:RETURN
236							
237	050026	000000		20\$:	.WORD	0	:ERROR FLAGS

```

1      .SBITL  CONTROLLER CLEAR SUBROUTINE
2
3      ;THIS SUBROUTINE CLEARS THE MASSBUS CONTROLLER, MASSBUS ADAPTERS,
4      ;AND DRIVES, THEN SELECTS THE DRIVE.
5
6      :CALL:  JSR      PC,CNTCLR
7              BR      ???
8              NOP
9              ERROR
10             ???
11
12      CNTCLR:  MOV      R0,-(SP)      ;;PUSH R0 ON STACK
13              MOV      R1,-(SP)      ;;PUSH R1 ON STACK
14              MOV      ERRVEC,-(SP)   ;;PUSH ERRVEC ON STACK
15              MOV      ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
16              MOV      #1$,ERRVEC     ;SETUP FOR BUS TIMEOUT
17              MOV      #PR6,ERRVEC+2
18              MOV      $BASE,R0      ;R0 = UNIBUS ADDRESS
19              MOV      #CLR,RMCS2(R0) ;CLEAR MASSBUS
20              MOV      TSTQUE,R1     ;GET DEVICE UNDER TEST
21              MOVB     (R1),RMCS2(R0) ;SELECT DEVICE
22              BR      2$
23
24      1$:  CMP      (SP)+,(SP)+      ;ADJUST STACK
25              ADD     #4,10(SP)     ;MOVE SP TO USER'S ERROR CALL
26              MOVB   #7,@10(SP)    ;WRITE THE ERROR NUMBER
27              SUB     #2,10(SP)     ;ADJUST SP TO RETURN TO ERROR
28
29      2$:  MOV      (SP)+,ERRVEC+2   ;;POP STACK INTO ERRVEC+2
30              MOV      (SP)+,ERRVEC  ;;POP STACK INTO ERRVEC
31              MOV      (SP)+,R1      ;;POP STACK INTO R1
32              MOV      (SP)+,R0      ;;POP STACK INTO R0
33              RTS      PC
    
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL CONTROLLER CLEAR STATUS CHECK SUBROUTINE

:THIS SUBROUTINE VERIFIES THAT THE SUBSYSTEM IS INITIALIZED BASED ON
 :STATUS STORED IN THE GET BUFFER. THIS SUBROUTINE SHOULD ONLY BE
 :USED FOLLOWING A CONTROLLER CLEAR OPERATION, I.E., WRITING A 1 IN BIT
 :5 OF RMCS2, BECAUSE THE ERROR MESSAGES ARE BASED ON THAT CONDITION.

:STATUS PERTINENT TO THE DEVICE IS NOT CHECKED. IN PARTICULAR, THE
 :FOLLOWING STATUS BITS ARE NOT CHECKED:

ATA,ERR,PIP,MOL,WRL,LBT,PGM,VV,OM,UNS,SKI,DVC

:CALL:

```
(1) JSR PC,CLRSTS          RETURN HERE IF NO ERROR
      BR   ???              RETURN HERE TO REPORT AN ERROR
      NOP                      ERROR NUMBER DEFINED BY SUB
      ERROR                    GO BACK TO SUB FOR MORE ERROR CHECKS
      JSR PC,@(SP)+          RETURN HERE IF NO MORE ERRORS
      ???
```

CLRSTS:

:CLEAR USER'S ERROR CALL

```
ADD #4,(SP)          ;MOVE SP TO ERROR
CLRB @ (SP)          ;CLEAR ERROR NUMBER
SUB #4,(SP)          ;MOVE SP BACK TO NO ERROR
:REPORT ERROR IF RMCS1 NOT INITIALIZED
1$: MOV RMCS1I,$BDDAT ;VERIFY RMCS1
    BIC #SC,$BDDAT   ;IGNORE SPECIAL CONDITION
    MOV #DVA!RDY,$GDDAT ;EXPECT DVA & RDY
    CMP $GDDAT,$BDDAT ;COMPARE EXPECTED, RECEIVED
    BEQ 2$           ;BRANCH IF EQUAL
    ADD #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
    MOVB #126,@(SP) ;WRITE ERROR NUMBER IN CALL
    SUB #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
    JSR PC,@(SP)+    ;REPORT ERROR VIA USER
    SUB #10,(SP)     ;MOVE SP BACK TO NO ERROR
    NOP
```

:REPORT ERROR IF RMBA NOT RESET

```
2$: CLR $GDDAT        ;VERIFY RMBA IS ZERO
    MOV RMBAI,$BDDAT
    BEQ 3$           ;BRANCH IF ZERO
    ADD #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
    MOVB #127,@(SP) ;WRITE ERROR NUMBER IN CALL
    SUB #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
    JSR PC,@(SP)+    ;REPORT ERROR VIA USER
    SUB #10,(SP)     ;MOVE SP BACK TO NO ERROR
    NOP
```

:REPORT ERROR IF RMCS2 NOT INITIALIZED

```
3$: MOV RMCS2I,$BDDAT ;VERIFY RMCS2
    MOV R1,-(SP)      ;PUSH R1 ON STACK
    CLR -(SP)         ;EXPECT IR & UNIT NUMBER
    MOV TSTQUE,R1     ;R1 = ADDRESS OF TEST QUE
    MOVB (R1),(SP)
    BIS #IR,(SP)
    MOV (SP)+,$GDDAT
```

```
050146
050146 062716 000004
050152 105076 000000
050156 162716 000004
050162 013737 001336 001142
050170 042737 100000 001142
050176 012737 004200 001140
050204 023737 001140 001142
050212 001413
050214 062716 000004
050220 112776 000126 000000
050226 162716 000002
050232 004736
050234 162716 000010
050240 000240
050242 005037 001140
050246 013737 001342 001142
050254 001413
050256 062716 000004
050262 112776 000127 000000
050270 162716 000002
050274 004736
050276 162716 000010
050302 000240
050304 013737 001346 001142
050312 010146
050314 005046
050316 013701 001466
050322 111116
050324 052716 000100
050330 012637 001140
```

```

58 050334 012601          MOV      (SP)+,R1          ;;POP STACK INTO R1
59 050336 023737 001140 001142  CMP      $GDDAT,$BDDAT    ;;COMPARE EXPECTED & RECEIVED
60 050344 001413          BEQ      4$              ;;BRANCH IF EQUAL
61 050346 062716 000004          ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
62 050352 112776 000130 000000  MOVB    #130,@(SP)        ;;WRITE ERROR NUMBER IN CALL
63 050360 162716 000002          SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
64 050364 004736          JSR     PC,@(SP)+         ;;REPORT ERROR VIA USER
65 050366 162716 000010          SUB      #10,(SP)        ;;MOVE SP BACK TO NO ERROR
66 050372 000240          NOP
67                                ;REPORT ERROR IF RMER1 NOT RESET-IGNORE UNS
68 050374 005037 001140 4$: CLR      $GDDAT          ;;VERIFY RMER1
69 050400 013737 001352 001142  MOV      RMER1I,$BDDAT
70 050406 042737 040000 001142  BIC     #UNS,$BDDAT      ;;IGNORE UNSAFE
71 050414 001413          BEQ     5$              ;;BRANCH IF ZERO
72 050416 062716 000004          ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
73 050422 112776 000131 000000  MOVB    #131,@(SP)        ;;WRITE ERROR NUMBER IN CALL
74 050430 162716 000002          SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
75 050434 004736          JSR     PC,@(SP)+         ;;REPORT ERROR VIA USER
76 050436 162716 000010          SUB      #10,(SP)        ;;MOVE SP BACK TO NO ERROR
77 050442 000240          NOP
78                                ;REPORT ERROR IF RMMR1 NOT INITIALIZED-IGNORE WC,LS,LST
79 050444 013737 001362 001142 5$: MOV      RMMR1I,$BDDAT    ;;VERIFY RMMR
80 050452 042737 000046 001142  BIC     #WC!LS!LST,$BDDAT ;;IGNORE WORD CLOCK, SCT, TRK
81 050460 012737 000010 001140  MOV      #MWD,$GDDAT      ;;EXPECT WRITE DATA BIT
82 050466 023737 001140 001142  CMP      $GDDAT,$BDDAT    ;;COMPARE EXPECTED AND RECEIVED
83 050474 001413          BEQ     6$              ;;BRANCH IF 0
84 050476 062716 000004          ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
85 050502 112776 000133 000000  MOVB    #133,@(SP)        ;;WRITE ERROR NUMBER IN CALL
86 050510 162716 000002          SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
87 050514 004736          JSR     PC,@(SP)+         ;;REPORT ERROR VIA USER
88 050516 162716 000010          SUB      #10,(SP)        ;;MOVE SP BACK TO NO ERROR
89 050522 000240          NOP
90                                ;REPORT AN ERROR IF RMEC2 IS NOT RESET
91 050524 005037 001140 6$: CLR      $GDDAT          ;;EXPECT ZEROS
92 050530 013737 001404 001142  MOV      RMEC2I,$BDDAT    ;;VERIFY RMEC2=0
93 050536 001413          BEQ     7$              ;;BRANCH IF 0
94 050540 062716 000004          ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
95 050544 112776 000135 000000  MOVB    #135,@(SP)        ;;WRITE ERROR NUMBER IN CALL
96 050552 162716 000002          SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
97 050556 004736          JSR     PC,@(SP)+         ;;REPORT ERROR VIA USER
98 050560 162716 000010          SUB      #10,(SP)        ;;MOVE SP BACK TO NO ERROR
99 050564 000240          NOP
100                                ;REPORT ERROR IF RMMR2 NOT INITIALIZED-IGNORE RQA,RQB
101 050566 013737 001376 001142 7$: MOV      RMMR2I,$BDDAT    ;;VERIFY RMMR2
102 050574 042737 140000 001142  BIC     #RQA:RQB,$BDDAT
103 050602 012737 011777 001140  MOV      #TST!1777,$GDDAT ;;EXPECT TEST BIT ON
104 050610 023737 001140 001142  CMP      $GDDAT,$BDDAT
105 050616 001413          BEQ     8$              ;;BRANCH IF 0
106 050620 062716 000004          ADD      #4,(SP)          ;;MOVE SP TO USER'S ERROR CALL
107 050624 112776 000136 000000  MOVB    #136,@(SP)        ;;WRITE ERROR NUMBER IN CALL
108 050632 162716 000002          SUB      #2,(SP)          ;;MOVE SP TO RETURN FOR ERROR
109 050636 004736          JSR     PC,@(SP)+         ;;REPORT ERROR VIA USER
110 050640 162716 000010          SUB      #10,(SP)        ;;MOVE SP BACK TO NO ERROR
111 050644 000240          NOP
112                                ;REPORT ERROR IF RMER2 NOT RESET-IGNORE SKI,DVC
113 050646 005037 001140 8$: CLR      $GDDAT          ;;EXPECT ALL ZEROS
114 050652 013737 001400 001142  MOV      RMER2I,$BDDAT    ;;VERIFY RMER2
    
```

115	050660	042737	040200	001142	BIC	#SKI!DVC,\$BDDAT	:IGNORE DEVICE ERRORS
116	050666	001413			BEQ	9\$:BRANCH IF OTHER BITS 0
117	050670	062716	000004		ADD	#4,(SP)	:MOVE SP TO USER'S ERROR CALL
118	050674	112776	000174	000000	MOVB	#174,@(SP)	:WRITE ERROR NUMBER IN CALL
119	050702	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
120	050706	004736			JSR	PC,@(SP)+	:REPORT ERROR VIA USER
121	050710	162716	000010		SL3	#10,(SP)	:MOVE SP BACK TO NO ERROR
122	050714	000240			NOP		
123							:REPORT ERROR IF RMDS NOT INITIALIZED
124	050716	013737	001350	001142	9\$: MOV	RMDSI,\$BDDAT	:TEST DRIVE STATUS REGISTER
125	050724	042737	177177	001142	BIC	#*C<DRY!DPR>,\$BDDAT	
126	050732	012737	000600	001140	MOV	#DPR!DRY,\$GDDAT	:EXPECTED DRIVE STATUS
127	050740	023737	001140	001142	CMP	\$GDDAT,\$BDDAT	:COMPARE EXPECTED & RECEIVED
128	050746	001413			BEQ	10\$:BRANCH IF EQUAL
129	050750	062716	000004		ADD	#4,(SP)	:MOVE SP TO USER'S ERROR CALL
130	050754	112776	000134	000000	MOVB	#134,@(SP)	:WRITE ERROR NUMBER
131	050762	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
132	050766	004736			JSR	PC,@(SP)+	:REPORT ERROR TO USER
133	050770	162716	000010		SUB	#10,(SP)	:MOVE SP BACK TO NO ERROR
134	050774	000240			NOP		
135	050776	062716	000004		10\$: ADD	#4,(SP)	:MOVE SP TO ERROR CALL
136	051002	105776	000000		TSTB	@(SP)	:WAS AN ERROE DETECTED??
137	051006	001403			BEQ	11\$:NO!!
138	051010	062716	000004		ADD	#4,(SP)	:YES - MOVE TO ERROR RETURN
139	051014	000402			BR	12\$	
140	051016	162716	000004		11\$: SUB	#4,(SP)	:MOVE SP TO NO ERROR RETURN
141	051022	000240			12\$: NOP		
142	051024	000207			RTS	PC	

2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL PACK ACKNOWLEDGE STATUS CHECK

:THIS SUBROUTINE CHECKS THE RESULTS OF A PACK ACKNOWLEDGE
 :COMMAND USING THE STATUS STORED IN THE GET BUFFER. ERRORS ARE
 :REPORTED TO THE USER VIA THE USER'S ERROR CALL.

```

:CALL:
:(1) JSR    PC,ACKSTS
      BR    ???
      NOP
      ERROR
      JSR    PC,@(SP)+
      ???
    RETURN HERE IF NO ERROR
    RETURN HERE TO REPORT AN ERROR
    ERROR NUMBER DEFINED BY SUB
    GO BACK TO SUB FOR MORE ERROR CHECKS
    RETURN HERE IF NO MORE ERRORS
    
```

ACKSTS:

```

:CLEAR USER'S ERROR CALL
ADD    #4,(SP)      ;MOVE SP TO ERROR CALL
CLRB   @(SP)       ;CLEAR LOW ORDER BYTE
SUB    #4,(SP)     ;MOVE SP BACK

:REPORT AN ERROR IF 'VV' IS 0
BIT    #VV,RMSI    ;IS VOLUME VALID SET??
BNE    1$         ;YES!!
MOV    RMSI,$GDDAT ;EXPECTED STATUS
BIS    #VV,$GDDAT
MOV    RMSI,$BDDAT ;RECEIVED STATUS
ADD    #4,(SP)    ;MOVE SP TO ERROR CALL
MOVB   #155,@(SP) ;WRITE NUMBER IN ERROR CALL
SUB    #2,(SP)    ;MOVE SP TO RETURN FOR ERROR
JSR    PC,@(SP)+  ;REPORT THE ERROR
SUB    #10,(SP)   ;MOVE SP BACK TO BRANCH
NOP
    
```

1\$:

```

:REPORT AN ERROR IF 'MOL' IS 0
BIT    #MOL,RMSI   ;IS MOL SET??
BNE    2$         ;YES!!
MOV    RMSI,$GDDAT ;EXPECTED STATUS
BIS    #MOL,$GDDAT
MOV    RMSI,$BDDAT ;RECEIVED STATUS
ADD    #4,(SP)    ;MOVE SP TO ERROR CALL
MOVB   #41,@(SP)  ;WRITE NUMBER OF ERROR IN CALL
SUB    #2,(SP)    ;MOVE SP TO RETURN FOR ERROR
JSR    PC,@(SP)+  ;REPORT TH ERROR
SUB    #10,(SP)   ;MOVE SP TO BRANCH
NOP
    
```

2\$:

```

:SEE IF 'UNS','OPI','RMR','ILR', OR 'ILF' IS SET
BIT    #UNS!OPI!RMR!ILR!ILF,RMER1I
BEQ    7$
    
```

```

:REPORT AN ERROR IF 'UNS' IS SET
BIT    #UNS,RMER1I ;WAS UNS SET??
BEQ    3$         ;NO!!
MOV    RMER1I,$BDDAT ;RECEIVED STATUS
    
```

```

051026
051026 062716 000004
051032 105076 000000
051036 162716 000004
051042 032737 000100 001350
051050 001024
051052 013737 001350 001140
051060 052737 000100 001140
051066 013737 001350 001142
051074 062716 000004
051100 112776 000155 000000
051106 162716 000002
051112 004736
051114 162716 000010
051120 000240
051122
051122 032737 010000 001350
051130 001024
051132 013737 001350 001140
051140 052737 010000 001140
051146 013737 001350 001142
051154 062716 000004
051160 112776 000041 000000
051166 162716 000002
051172 004736
051174 162716 000010
051200 000240
051202
051202 032737 060007 001352
051210 001570
051212 032737 040000 001352
051220 001424
051222 013737 001352 001142
    
```

58	051230	013737	001352	001140	MOV	RMER11,\$GDDAT	:EXPECTED STATUS
59	051236	042737	040000	001140	BIC	#UNS,\$GDDAT	
60	051244	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
61	051250	112776	000042	000000	MOVB	#4,@(SP)	:WRITE NUMBER OF ERROR IN CALL
62	051256	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
63	051262	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
64	051264	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
65	051270	000240			NOP		
66	051272					3\$:	
67							
68						:REPORT ANY OPI ERROR	
69	051272	032737	020000	001352	BIT	#OPI,RMER11	:WAS OPI SET ??
70	051300	001424			BEQ	4\$:NO!!
71	051302	013737	001352	001142	MOV	RMER11,\$BDDAT	:RECEIVED STATUS
72	051310	013737	001352	001140	MOV	RMER11,\$GDDAT	:EXPECTED STATUS
73	051316	042737	020000	001140	BIC	#OPI,\$GDDAT	
74	051324	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
75	051330	112776	000043	000000	MOVB	#4,@(SP)	:WRITE NUMBER OF ERROR IN CALL
76	051336	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
77	051342	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
78	051344	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
79	051350	000240			NOP		
80	051352					4\$:	
81							
82						:REPORT ANY RMR ERROR	
83	051352	032737	000004	001352	BIT	#RMR,RMER11	:WAS RMR SET??
84	051360	001424			BEQ	5\$:NO!!
85	051362	013737	001352	001142	MOV	RMER11,\$BDDAT	:RECEIVED STATUS
86	051370	013737	001352	001140	MOV	RMER11,\$GDDAT	:EXPECTED STATUS
87	051376	042737	000004	001140	BIC	#RMR,\$GDDAT	
88	051404	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
89	051410	112776	000044	000000	MOVB	#4,@(SP)	:WRITE NUMBER OF ERROR IN CALL
90	051416	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
91	051422	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
92	051424	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
93	051430	000240			NOP		
94	051432					5\$:	
95							
96						:REPORT ANY ILR ERROR	
97	051432	032737	000002	001352	BIT	#ILR,RMER11	:WAS ILR SET??
98	051440	001424			BEQ	6\$:NO!!
99	051442	013737	001352	001142	MOV	RMER11,\$BDDAT	:RECEIVED STATUS
100	051450	013737	001352	001140	MOV	RMER11,\$GDDAT	:EXPECTED STATUS
101	051456	042737	000002	001140	BIC	#ILR,\$GDDAT	
102	051464	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
103	051470	112776	000045	000000	MOVB	#4,@(SP)	:WRITE NUMBER OF ERROR IN CALL
104	051476	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
105	051502	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
106	051504	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
107	051510	000240			NOP		
108	051512					6\$:	
109							
110						:REPORT ANY ILF ERROR	
111	051512	032737	000001	001352	BIT	#ILF,RMER11	:WAS ILF SET??
112	051520	001424			BEQ	7\$:NO!!
113	051522	013737	001352	001142	MOV	RMER11,\$BDDAT	:RECEIVED STATUS
114	051530	013737	001352	001140	MOV	RMER11,\$GDDAT	:EXPECTED STATUS

115	051536	042737	000001	001140	BIC	#ILF,\$GDDAT	
116	051544	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
117	051550	112776	000046	000000	MOVB	#46,@(SP)	:WRITE NUMBER OF ERROR IN CALL
118	051556	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
119	051562	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
120	051564	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
121	051570	000240			NOP		
122	051572						
123							
124							
125	051572	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
126	051576	105776	000000		TSTB	@(SP)	:WAS ERROR FOUND??
127	051602	001403			BEQ	8\$:NO!!
128	051604	062716	000004		ADD	#4,(SP)	:YES - MOVE TO ERROR RETURN
129	051610	000402			BR	9\$	
130	051612	162716	000004		SUB	#4,(SP)	:MOVE SP TO NO ERROR RETURN
131	051616	000240			NOP		
132	051620	000207			RTS	PC	

7\$:

;AUGMENT RETURN ADDRESS IF ERROR WAS FOUND

8\$:

9\$:

J 1

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL RECALIBRATE STATUS CHECK SUBROUTINE

:THIS SUBROUTINE CHECKS THE RESULTS OF A RECALIBRATE OPERATION
 :USING THE STATUS STORED IN THE GET BUFFER.

:CALL:

```

(1) JSR PC,RCLSTS ;CALL SUBROUTINE
     BR   ???      ;RETURN HERE IF NO ERROR
     NOP          ;RETURN HERE TO REPORT AN ERROR
     ERROR       ;ERROR NUMBER DEFINED BY SUB
     JSR PC,@(SP)+ ;GO BACK TO SUB FOR MORE ERROR CHECKS
     ???        ;RETURN HERE IF NO MORE ERRORS
    
```

RCLSTS:

:CLEAR USER'S ERROR NUMBER

```

ADD #4,(SP)
CLRB @(SP) ;CLEAR USER'S ERROR CALL
SUB #4,(SP) ;MOVE SP BACK TO BRANCH
    
```

:SEE IF 'PAR' OR 'ILF' OR 'OPI' OR 'IAE' IS SET

```

BIT #OPI!PAR!ILF!IAE,RMER1I
BEQ 5$ ;NONE ARE SET - GO TO NEXT CHECK
    
```

:REPORT ANY MASSBUS CONTROL BUS PARITY ERROR, I.E.,

:'PAR' = 1 AND 'DPE' = 0

```

BIT #PAR,RMER1I ;WAS 'PAR' SET??
BEQ 1$ ;NO!!
BIT #DPE,RMER2I ;WAS 'DPE' SET??
BNE 1$ ;YES - NOT A REGISTER ERROR
MOV RMER1I,$GDDAT ;EXPECTED STATUS
BIC #PAR,$GDDAT
MOV RMER1I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #50,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ ;GO REPORT ERROR
SUB #10,(SP) ;MOVE SP BACK TO BRANCH
NOP
    
```

1\$:

:REPORT ANY 'ILF' ERROR

```

BIT #ILF,RMER1I ;WAS 'ILF' SET??
BEQ 2$ ;NO!!
MOV RMER1I,$GDDAT ;EXPECTED STATUS
BIC #ILF,$GDDAT
MOV RMER1I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #71,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP BACK TO BRANCH
NOP
    
```

2\$:

```

15 051622
18 051622 062716 000004
19 051626 105076 000000
20 051632 162716 000004
24 051636 032737 022011 001352
25 051644 001553
29 051646 032737 000010 001352
30 051654 001430
31 051656 032737 000010 001400
32 051664 001024
33 051666 013737 001352 001140
34 051674 042737 000010 001140
35 051702 013737 001352 001142
36 051710 062716 000004
37 051714 112776 000050 000000
38 051722 162716 000002
39 051726 004736
40 051730 162716 000010
41 051734 000240
42 051736
45 051736 032737 000001 001352
46 051744 001424
47 051746 013737 001352 001140
48 051754 042737 000001 001140
49 051762 013737 001352 001142
50 051770 062716 000004
51 051774 112776 000071 000000
52 052002 162716 000002
53 052006 004736
54 052010 162716 000010
55 052014 000240
56 052016
    
```

```

58      ;REPORT ANY 'OPI' ERROR AS
59      . OPI DUE TO 'MOL' = 0
60      . OPI BECAUSE ON CYLINDER LATCH DIDN'T RESET
61 052016 032737 020000 001352      BIT      #OPI,RMER1I      ;WAS OPI SET??
62 052024 001433                    BEQ      4$              ;NO!!
63 052026 013737 001352 001140      MOV      RMER1I,$GDDAT  ;EXPECTED STATUS
64 052034 042737 020000 001140      BIC      #OPI,$GDDAT
65 052042 013737 001352 001142      MOV      RMER1I,$BDDAT ;RECEIVED STATUS
66 052050 062716 000004              ADD      #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
67 052054 112776 000072 000000      MOV      #72,@(SP)    ;WRITE ERROR NUMBER IN USER'S CALL
68 052062 032737 010000 001350      BIT      #MOL,RMDSI   ;WAS 'MOL' = 0??
69 052070 001403                    BEQ      3$              ;YES!!
70 052072 112776 000073 000000      MOV      #73,@(SP)    ;NO - CHANGE ERROR NUMBER
71 052100 162716 000002      3$:   SUB      #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
72 052104 004736                    JSR      PC,@(SP)+    ;REPORT ERROR VIA USER
73 052106 162716 000010      SUB      #10,(SP)    ;MOVE SP BACK TO BRANCH
74 052112 000240                    NOP
75 052114      4$:
76
77      ;REPORT AN ERROR IF 'IAE' IS SET
78 052114 032737 002000 001352      BIT      #IAE,RMER1I  ;IS 'IAE' SET??
79 052122 001424                    BEQ      5$              ;NO!!
80 052124 013737 001352 001140      MOV      RMER1I,$GDDAT ;EXPECTED STATUS
81 052132 042737 002000 001140      BIC      #IAE,$GDDAT
82 052140 013737 001352 001142      MOV      RMER1I,$BDDAT ;RECEIVED STATUS
83 052146 062716 000004              ADD      #4,(SP)       ;MOVE SP TO ERROR CALL
84 052152 112776 000070 000000      MOV      #70,@(SP)    ;WRITE ERROR NUMBER IN USER'S CALL
85 052160 162716 000002      SUB      #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
86 052164 004736                    JSR      PC,@(SP)+    ;REPORT ERROR
87 052166 162716 000010      SUB      #10,(SP)    ;MOVE SP BACK TO NO ERROR RETURN
88 052172 000240                    NOP
89 052174      5$:
90
91      ;SEE IF 'SKI' OR 'IVC' OR 'DVC' IS SET
92 052174 032737 050200 001400      BIT      #SKI!IVC!DVC,RMER2I
93 052202 001517                    BEQ      9$              ;NONE OF THE BITS ARE SET
94
95
96      ;REPORT ANY 'IVC' ERROR AS
97      . IVC WITH VV = 0
98      . ERRONEOUS IVC ERROR
99 052204 032737 010000 001400      BIT      #IVC,RMER2I  ;WAS IVC SET??
100 052212 001433                    BEQ      7$              ;NO!!
101 052214 013737 001400 001140      MOV      RMER2I,$GDDAT ;EXPECTED STATUS
102 052222 042737 010000 001140      BIC      #IVC,$GDDAT
103 052230 013737 001400 001142      MOV      RMER2I,$BDDAT ;RECEIVED STATUS
104 052236 062716 000004              ADD      #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
105 052242 112776 000074 000000      MOV      #74,@(SP)    ;WRITE ERROR NUMBER IN CALL
106 052250 032737 000100 001350      BIT      #VV,RMDSI   ;WAS VV = 0??
107 052256 001403                    BEQ      6$              ;YES!!
108 052260 112776 000075 000000      MOV      #75,@(SP)    ;NO - CHANGE ERROR NUMBER
109 052266 162716 000002      6$:   SUB      #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
110 052272 004736                    JSR      PC,@(SP)+    ;REPORT ERROR VIA USER
111 052274 162716 000010      SUB      #10,(SP)    ;MOVE SP BACK TO BRANCH
112 052300 000240                    NOP
113 052302      7$:
114

```

```

115 ;REPORT ANY "SKI" ERROR
116 052302 032737 040000 001400 BIT #SKI,RMER2I ;WAS SKI SET??
117 052310 001424 BEQ 8$ ;NO!!
118 052312 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
119 052320 042737 040000 001140 BIC #SKI,$GDDAT
120 052326 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
121 052334 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
122 052340 112776 000076 000000 MOVB #76,@(SP) ;WRITE ERROR NUMBER
123 052346 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
124 052352 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
125 052354 162716 000010 SUB #10,(SP) ;MOVE SP TO BRANCH
126 052360 000240 NOP
127 052362 8$:
128
129 ;REPORT ANY "DVC" ERROR
130 052362 032737 000200 001400 BIT #DVC,RMER2I ;WAS "DVC" SET??
131 052370 001424 BEQ 9$ ;NO!!
132 052372 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
133 052400 042737 000200 001140 BIC #DVC,$GDDAT
134 052406 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
135 052414 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
136 052420 112776 000077 000000 MOVB #77,@(SP) ;WRITE ERROR NUMBER
137 052426 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
138 052432 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
139 052434 162716 000010 SUB #10,(SP) ;MOVE SP TO USER'S BRANCH
140 052440 000240 NOP
141 052442 9$:
142
143 ;SEE IF "PIP" AND "OM" ARE 0, AND "ATA","MOL" AND "VV" ARE 1
144 052442 013746 001350 MOV RMDSI,-(SP) ;PUT RMDS ON STACK
145 052446 042716 047676 BIC #^C<PIP!MOL!VV!OM!ATA>,(SP)
146 052452 022726 110100 CMP #ATA!MOL!VV,(SP)+
147 052456 001002 BNE 10$
148 052460 000137 053074 JMP 15$
149 052464 10$:
150
151 ;REPORT AN ERROR IF MOL = 0 AND OPI = 0, I.E., MEDIUM WENT OFF
152 ;LINE AFTER RECALIBRATE WAS INITIATED
153 052464 032737 010000 001350 BIT #MOL,RMDSI ;DID MOL DROP??
154 052472 001030 BNE 11$ ;NO!!
155 052474 032737 020000 001352 BIT #OPI,RMER1I ;WAS OPI ERROR REPORTED??
156 052502 001024 BNE 11$ ;YES - DON'T REPORT MOL=0
157 052504 013737 001350 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
158 052512 052737 010000 001140 BIS #MOL,$GDDAT
159 052520 013737 001350 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
160 052526 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
161 052532 112776 000100 000000 MOVB #100,@(SP) ;WRITE ERROR NUMBER
162 052540 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
163 052544 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
164 052546 162716 000010 SUB #10,(SP) ;MOVE SP BACK TO USER'S BRANCH
165 052552 000240 NOP
166 052554 11$:
167
168 ;REPORT AN ERROR IF "VV" = 0 AND "IVC" = 0
169 052554 032737 000100 001350 BIT #VV,RMDSI ;DID "VV" DROP??
170 052562 001030 BNE 12$ ;NO!!
171 052564 032737 010000 001400 BIT #IVC,RMER2I ;WAS THERE A IVC ERROR??
    
```

172	052572	001024			BNE	12\$:YES - DONT REPORT VV=0
173	052574	013737	001350	001140	MOV	RMDSI,\$GDDAT	:EXPECTED STATUS
174	052602	013737	001350	001142	MOV	RMDSI,\$BDDAT	:RECEIVED STATUS
175	052610	052737	000100	001140	BIS	#VV,\$GDDAT	
176	052616	062716	000004		ADD	#4,(SP)	:MOVE SP TO USER'S ERROR CALL
177	052622	112776	000101	000000	MOVB	#101,@(SP)	:WRITE ERROR NUMBER IN CALL
178	052630	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
179	052634	004736			JSR	PC,@(SP)+	
180	052636	162716	000010		SUB	#10,(SP)	:MOVE SP BACK TO USER'S BRANCH
181	052642	000240			NOP		
182	052644					12\$:	
183							
184						:REPORT AN ERROR IF ATA IS NOT SET	
185	052644	032737	100000	001350	BIT	#ATA,RMDSI	:WAS ATA SET DURING RECALIBRATE??
186	052652	001024			BNE	13\$:YES!!
187	052654	013737	001350	001140	MOV	RMDSI,\$GDDAT	:EXPECTED STATUS
188	052662	052737	100000	001140	BIS	#ATA,\$GDDAT	
189	052670	013737	001350	001142	MOV	RMDSI,\$BDDAT	:RECEIVED STATUS
190	052676	062716	000004		ADD	#4,(SP)	:MOVE SP TO USER'S ERROR CALL
191	052702	112776	000102	000000	MOVB	#102,@(SP)	:WRITE ERROR NUMBER IN CALL
192	052710	162716	000002		SUB	#2,(SP)	
193	052714	004736			JSR	PC,@(SP)+	
194	052716	162716	000010		SUB	#10,(SP)	:MOVE SP TO USER'S BRANCH
195	052722	000240			NOP		
196							
197	052724					13\$:	
198							
199						:REPORT AN ERROR IF 'OM' IS NOT ZERO BECAUSE RECALIBRATE SHOULD	
200						:ALWAYS CLEAR OFFSET MODE	
201	052724	032737	000001	001350	BIT	#OM,RMDSI	:WAS 'OM' RESET??
202	052732	001424			BEQ	14\$:YES!!
203	052734	013737	001350	001140	MOV	RMDSI,\$GDDAT	:EXPECTED STATUS
204	052742	042737	000001	001140	BIC	#OM,\$GDDAT	
205	052750	013737	001350	001142	MOV	RMDSI,\$BDDAT	:RECEIVED STATUS
206	052756	062716	000004		ADD	#4,(SP)	:MOVE SP TO USER'S ERROR CALL
207	052762	112776	000103	000000	MOVB	#103,@(SP)	:WRITE ERROR NUMBER
208	052770	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
209	052774	004736			JSR	PC,@(SP)+	:REPORT ERROR VIA USER
210	052776	162716	000010		SUB	#10,(SP)	:MOVE SP TO USER'S BRANCH
211	053002	000240			NOP		
212	053004						
213						14\$:	
214						:REPORT AN ERROR IF 'PIP' IS STIL ON, I.E., DRIVE NOT ON	
215						:CYLINDER	
216	053004	032737	020000	001350	BIT	#PIP,RMDSI	:IS DRIVE OFF CYLINDER??
217	053012	001430			BEQ	15\$:NO!!
218	053014	032737	040000	001400	BIT	#SKI,RMER2I	:WAS 'SKI' DETECTED??
219	053022	001024			BNE	15\$:YES-DONT REPORT 'PIP'
220	053024	013737	001350	001140	MOV	RMDSI,\$GDDAT	:EXPECTED STATUS
221	053032	042737	020000	001140	BIC	#PIP,\$GDDAT	
222	053040	013737	001350	001142	MOV	RMDSI,\$BDDAT	:RECEIVED STATUS
223	053046	062716	000004		ADD	#4,(SP)	:MOVE SP TO USER'S ERROR CALL
224	053052	112776	000104	000000	MOVB	#104,@(SP)	:WRITE ERROR NUMBER
225	053060	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
226	053064	004736			JSR	PC,@(SP)+	
227	053066	162716	000010		SUB	#10,(SP)	:MOVE SP BACK TO USER'S BRANCH
228	053072	000240			NOP		

```

229 053074      15$:
230
231              ;SEE IF 'ILR' OR 'RMR' OR 'UNS' IS SET
232 053074      032737 040006 001352      BIT      #ILR!RMR!UNS,RMER1I
233 053102      001514              BEQ      18$
234
235              ;REPORT AN ERROR IF 'ILR' IS SET
236 053104      032737 000002 001352      BIT      #ILR,RMER1I      ;WAS ILR SET DURING RECALIBRATE??
237 053112      001424              BEQ      16$              ;NO!!
238 053111      013737 001352 001140      MOV      RMER1I,$GDDAT      ;EXPECTED STATUS
239 053122      042737 000002 001140      BIC      #ILR,$GDDAT
240 053130      013737 001352 001142      MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
241 053136      062716 000004              ADD      #4,(SP) ;MOVE SP TO USER'S ERROR CALL
242 053142      112776 000105 000000      MOV      #105,@(SP) ;WRITE ERROR NUMBER IN CALL
243 053150      162716 000002              SUB      #2,(SP) ;MOVE SP TO RETURN FOR ERROR
244 053154      004736              JSR      PC,@(SP)+
245 053156      162716 000010              SUB      #10,(SP) ;MOVE SP TO USER'S BRANCH
246 053162      000240              NOP
247 053164
248
249              ;REPORT AN ERROR IF 'RMR' IS SET
250 053164      032737 000004 001352      BIT      #RMR,RMER1I      ;WAS RMR SET??
251 053172      001424              BEQ      17$              ;NO!!
252 053174      013737 001352 001140      MOV      RMER1I,$GDDAT      ;EXPECTED STATUS
253 053202      042737 000004 001140      BIC      #RMR,$GDDAT
254 053210      013737 001352 001142      MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
255 053216      062716 000004              ADD      #4,(SP) ;MOVE SP TO USER'S ERROR CALL
256 053222      112776 000106 000000      MOV      #106,@(SP) ;WRITE ERROR NUMBER IN USER'S CALL
257 053230      162716 000002              SUB      #2,(SP) ;MOVE SP TO RETURN FOR ERROR
258 053234      004736              JSR      PC,@(SP)+
259 053236      162716 000010              SUB      #10,(SP) ;MOVE SP TO USER'S BRANCH
260 053242      000240              NOP
261 053244
262
263              ;REPORT AN ERROR IF 'UNS' IS SET AND 'DVC' IS 0
264 053244      032737 040000 001352      BIT      #UNS,RMER1I      ;WAS UNSAFE ON??
265 053252      001430              BEQ      18$              ;NO!!
266 053254      032737 000200 001400      BIT      #DVC,RMER2I      ;WAS THERE A DEVICE CHECK??
267 053262      001024              BNE      18$              ;YES - DON'T REPORT UNSAFE
268 053264      013737 001352 001140      MOV      RMER1I,$GDDAT      ;EXPECTED STATUS
269 053272      042737 040000 001140      BIC      #UNS,$GDDAT
270 053300      013737 001352 001142      MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
271 053306      062716 000004              ADD      #4,(SP) ;MOVE SP TO USER'S ERROR CALL
272 053312      112776 000107 000000      MOV      #107,@(SP) ;WRITE ERROR NUMBER
273 053320      162716 000002              SUB      #2,(SP) ;MOVE SP TO RETURN FOR ERROR
274 053324      004736              JSR      PC,@(SP)+
275 053326      162716 000010              SUB      #10,(SP) ;MOVE SP BACK TO USER'S BRANCH
276 053332      000240              NOP
277 053334
278
279              ;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
280 053334      062716 000004              ADD      #4,(SP) ;MOVE SP TO USER'S ERROR CALL
281 053340      105776 000000      TSTB    @(SP) ;WAS AN ERROR REPORTED??
282 053344      001403              BEQ      19$              ;NO!!
283 053346      062716 000004              ADD      #4,(SP) ;YES - AUGMENT SP RETURN
284 053352      000402              BR       20$
285 053354      162716 000004      19$:      SUB      #4,(SP) ;NO ERROR - RETURN SP TO BRANCH
    
```

286 053360 000240
287 053362 000207

20\$: NOP
RTS PC

:STATUS CECK IS COMPLETE

```

1      .SBTTL  DRIVE CLEAR STATUS CHECK SUBROUTINE
2
3      :      BR      ???      RETURN HERE IF NO ERROR
4      :      NOP      RETURN HERE TO REPORT AN ERROR
5      :      ERROR   ERROR NUMBER DEFINED BY SUB
6      :      JSR      PC,@(SP)+ GO BACK TO SUB FOR MORE ERROR CHECKS
7      :      ???      RETURN HERE IF NO MORE ERRORS
8
9      053364  DRVSTS:
10
11      :CLEAR USER'S ERROR CALL
12      053364 062716 000004  ADD #4,(SP)      ;MOVE SP TO ERROR CALL
13      053370 105076 000000  CLRB @(SP)      ;CLEAR ERROR CALL
14      053374 162716 000004  SUB #4,(SP)      ;MOVE SP TO USER'S BRANCH
15
16      053400 013737 001336 001142 1$:  MOV RMCSI,$BDDAT ;CHECK RMCSI
17      053406 042737 173700 001142  BIC #^C<DVA!FNCMSK>,$BDDAT ;CLEAR DONT CARES
18      053414 012737 004010 001140  MOV #DVA!DRVCLR,$GDDAT ;EXPECT DVA
19      053422 023737 001140 001142  CMP $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
20      053430 001443  BEQ 3$          ;BRANCH IF EQUAL
21      053432 062716 000004  ADD #4,(SP)      ;MOVE SP TO ERROR CALL
22      053436 112776 000141 000000  MOVB #141,@(SP) ;WRITE NUMBER OF ERROR IN CALL
23      053444 162716 000002  SUB #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
24      053450 004736  JSR PC,@(SP)+   ;REPORT THE ERROR VIA USER
25      053452 152716 000010  SUB #10,(SP)     ;MOVE SP TO NO ERROR RETURN
26      053456 000240  NOP
27
28      053460 013737 001350 001142 2$:  MOV RMDSI,$BDDAT ;CHECK RMDS
29      053466 042737 021101 001142  BIC #PGM!OM!VV!PIP,$BDDAT ;CLEAR DONT CARES
30      053474 012737 010600 001140  MOV #MOL!DPR!DRY,$GDDAT ;EXPECT DRY & DPR
31      053502 023737 001140 001142  CMP $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
32      053510 001413  BEQ 3$          ;BRANCH IF EQUAL
33      053512 062716 000004  ADD #4,(SP)      ;MOVE SP TO ERROR CALL
34      053516 112776 000142 000000  MOVB #142,@(SP) ;WRITE NUMBER OF ERROR IN CALL
35      053524 162716 000002  SUB #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
36      053530 004736  JSR PC,@(SP)+   ;REPORT THE ERROR VIA USER
37      053532 162716 000010  SUB #10,(SP)     ;MOVE SP TO NO ERROR RETURN
38      053536 000240  NOP
39
40      053540 005037 001140 3$:  CLR $GDDAT      ;EXPECT 0'S
41      053544 013737 001352 001142  MOV RMER1,$BDDAT ;CHECK RMER1
42      053552 001413  BEQ 4$          ;BRANCH IF EQUAL
43      053554 062716 000004  ADD #4,(SP)      ;MOVE SP TO ERROR CALL
44      053560 112776 000143 000000  MOVB #143,@(SP) ;WRITE NUMBER OF ERROR IN CALL
45      053566 162716 000002  SUB #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
46      053572 004736  JSR PC,@(SP)+   ;REPORT THE ERROR VIA USER
47      053574 162716 000010  SUB #10,(SP)     ;MOVE SP TO NO ERROR RETURN
48      053600 000240  NOP
49
50      053602 013737 001354 001142 4$:  MOV RMAS1,$BDDAT ;CHECK ATTENTION BIT
51      053610 010146  MOV R1,-(SP)     ;:PUSH R1 ON STACK
52      053612 010246  MOV R2,-(SP)     ;:PUSH R2 ON STACK
53      053614 013701 001466  MOV TSTQUE,R1
54      053620 116102 000001  MOVB 1(R1),R2
55      053624 042702 177400  BIC #^CATNMSK,R2
56      053630 005102  COM R2
57      053632 040237 001142  BIC R2,$BDDAT
    
```

```

58 053636 012602      MOV      (SP)+,R2      ;;POP STACK INTO R2
59 053640 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
60 053642 005737 001142  TST      $BDDAT        ;;IS ATTENTION CLEARED??
61 053646 001413      BEQ      5$            ;;BRANCH IF ATTENTION CLEARED
62 053650 062716 000004  ADD      #4,(SF)        ;;MOVE SP TO ERROR CALL
63 053654 112776 000144 000000  MOVB    #144,@(SP)     ;;WRITE NUMBER OF ERROR IN CALL
64 053662 162716 000002      SUB      #2,(SP)        ;;MOVE SP TO RETURN FOR ERROR
65 053666 004736      JSR     PC,@(SP)+      ;;REPORT THE ERROR VIA USER
66 053670 162716 000010      SUB      #10,(SP)       ;;MOVE SP TO NO ERROR RETURN
67 053674 000240      NOP
68
69 053676 013737 001362 001142 5$:      :REPORT ERROR IF RMMR1 NOT INITIALIZED
70 053704 042737 000046 001142  MOV      RMMR1,$BDDAT  ;;CHECK RMMR
71 053712 012737 000010 001140  BIC     #WC!LS!LST,$BDDAT ;;CLEAR DONT CARES
72 053720 023737 001140 001142  MOV      #MWD,$GDDAT   ;;EXPECT WRITE DATA ON
73 053726 001413      CMP     $GDDAT,$BDDAT  ;;COMPARE EXPECTED AND RECEIVED
74 053730 062716 000004  ADD      #4,(SP)        ;;MOVE SP TO ERROR CALL
75 053734 112776 000145 000000  MOVB    #145,@(SP)     ;;WRITE NUMBER OF ERROR IN CALL
76 053742 162716 000002      SUB      #2,(SP)        ;;MOVE SP TO RETURN FOR ERROR
77 053746 004736      JSR     PC,@(SP)+      ;;REPORT THE ERROR VIA USER
78 053750 162716 000010      SUB      #10,(SP)       ;;MOVE SP TO NO ERROR RETURN
79 053754 000240      NOP
80
81 053756 013737 001376 001142 6$:      :REPORT ERROR IF RMMR2 NOT INITIALIZED
82 053764 042737 140000 001142  MOV      RMMR2,$BDDAT  ;;CHECK RMMR2
83 053772 012737 011777 001140  BIC     #RQA!ROB,$BDDAT ;;CLEAR RQA, ROQB
84 054000 023737 001140 001142  MOV      #TST!1777,$GDDAT ;;EXPECT TEST BIT ON
85 054006 001413      CMP     $GDDAT,$BDDAT  ;;COMPARE EXPECTED & RECEIVED
86 054010 062716 000004  ADD      #4,(SP)        ;;MOVE SP TO ERROR CALL
87 054014 112776 000146 000000  MOVB    #146,@(SP)     ;;WRITE NUMBER OF ERROR IN CALL
88 054022 162716 000002      SUB      #2,(SP)        ;;MOVE SP TO RETURN FOR ERROR
89 054026 004736      JSR     PC,@(SP)+      ;;REPORT THE ERROR VIA USER
90 054030 162716 000010      SUB      #10,(SP)       ;;MOVE SP TO NO ERROR RETURN
91 054034 000240      NOP
92 054036 005037 001140 7$:      CLR     $GDDAT         ;;EXPECT ZEROS
93
94 054042 013737 001404 001142 8$:      :REPORT ERROR IF RMEC2 NOT RESET
95 054050 001413      MOV      RMEC2I,$BDDAT ;;CHECK RMEC2
96 054052 062716 000004  ADD      #4,(SP)        ;;MOVE SP TO ERROR CALL
97 054056 112776 000150 000000  MOVB    #150,@(SP)     ;;WRITE NUMBER OF ERROR IN CALL
98 054064 162716 000002      SUB      #2,(SP)        ;;MOVE SP TO RETURN FOR ERROR
99 054070 004736      JSR     PC,@(SP)+      ;;REPORT THE ERROR VIA USER
100 054072 162716 000010      SUB      #10,(SP)       ;;MOVE SP TO NO ERROR RETURN
101 054076 000240      NOP
102
103 054100 013737 001400 001142 9$:      :REPORT ERROR IF RMER2 NOT RESET
104 054106 001413      MOV      RMER2I,$BDDAT ;;CHECK RMER2
105 054110 062716 000004  ADD      #4,(SP)        ;;MOVE SP TO ERROR CALL
106 054114 112776 000147 000000  MOVB    #147,@(SP)     ;;WRITE NUMBER OF ERROR IN CALL
107 054122 162716 000002      SUB      #2,(SP)        ;;MOVE SP TO RETURN FOR ERROR
108 054126 004736      JSR     PC,@(SP)+      ;;REPORT THE ERROR VIA USER
109 054130 162716 000010      SUB      #10,(SP)       ;;MOVE SP TO NO ERROR RETURN
110 054134 000240      NOP
111 054136
112
113 054136
114

```


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL DATA TRANSFER COMMAND STATUS CHECK SUBROUTINE

;THIS SUBROUTINE VERIFIES THE RESULTS OF ALL DATA TRANSFER COMMANDS
 ;USING STATUS STORED IN THE GET BUFFER AND TEST PARAMETERS
 ;STORED IN THE PUT BUFFER. ERRORS ARE REPORTED BY WRITING
 ;THE ERROR NUMBER IN THE USERS ERROR CALL.

;USER'S SUBROUTINE CALL:

;(1)	JSR	PC,DTASTS	
;(2)	BR	??	RETURN HERE IF NO DATA ERRORS
;(3)	NOP		RETURN HERE TO REPORT AN ERROR
;(4)	ERROR		SUB WRITES ERROR NUMBER
;(5)	JSR	PC,@(SP)+	USER RETURNS FOR MORE CHECKS
;(6)	??		SUB RETURNS HERE AFTER ALL
			ERRORS ARE REPORTED

DTASTS:

;CLEAR USER'S ERROR CALL AND ERROR FLAGS

ADD	#4,(SP)	;MOVE SP TO USER'S ERROR
CLRB	@(SP)	;CLEAR LOW ORDER BYTE OF TRAP
SUB	#4,(SP)	;RESTORE SP TO NO ERROR
CLR	49\$;CLEAR ERROR FLAGS

;REPORT ANY CONTROL BUS PARITY ERROR WHILE READING REMOTE REGISTERS,

;I.E., MCPE = 1

BIT	#MCPE,RMCS1I	;WAS THERE A PARITY ERROR??
BEQ	1\$;NO!!
MOV	RMCS1I,\$GDDAT	;EXPECTED STATUS
BIC	#MCPE,\$GDDAT	
MOV	RMCS1I,\$BDDAT	;RECEIVED STATUS
ADD	#4,(SP)	;MOVE SP TO USER'S ERROR CALL
MOVB	#13,@(SP)	;WRITE ERROR NUMBER
SUB	#2,(SP)	;MOVE SP TO RETURN IF ERROR
JSR	PC,@(SP)+	;REPORT ERROR AND RETURN
BR	4\$	

1\$:

;REPORT ANY CONTROL BUS PARITY ERROR WHILE WRITTING REMOTE REGISTERS,

;I.E., PAR = 1 AND DPE = 0

BIT	#PAR,RMER1I	;WAS THERE A PARITY ERROR??
BEQ	3\$;NO!!
BIT	#DPE,RMER2I	;DATA PARITY ERROR ?
BNE	3\$;YES!!
MOV	RMER1I,\$GDDAT	;EXPECTED STATUS
BIC	#PAR,\$GDDAT	
MOV	RMER1I,\$BDDAT	;RECEIVED STATUS
ADD	#4,(SP)	;MOVE SP TO USER'S ERROR
MOVB	#50,@(SP)	;WRITE ERROR NUMBER
BIT	#MXF,RMCS2I	;DID MXF GET SET??
BNE	2\$;YES!!
MOVB	#274,@(SP)	;NO - CHANGE ERROR NUMBER
SUB	#2,(SP)	;MOVE SP TO RETURN IF ERROR
JSR	PC,@(SP)+	;REPORT ERROR AND RETURN
BR	4\$	

;LOOK FOR ANY ERRORS WHICH MAY HAVE OCCURRED DURING COMMAND INITIATION OR

```

58      :MECHANICAL POSITIONING
59
60      ;FIRST TEST MXF WHICH WOULD INDICATE COMPOSITE ERROR SET WHEN FUNCTION
61      ;CODE AND GO BIT WERE LOADED
62      054364      032737      001000      001346      3$:      BIT      #MXF,RMCS2I      :WAS 'MISSED TRANSFER' SET??
63      054364      001425
64      054372      001425
65      054374      013737      001346      001140      BEQ      5$      :NO!!
66      054402      042737      001000      001140      MOV      RMCS2I,$GDDAT      :EXPECTED STATUS
67      054410      013737      001346      001142      BIC      #MXF,$GDDAT
68      054416      062716      000004      :RECEIVED STATUS
69      054422      112776      000275      000000      MOV      RMCS2I,$BDDAT      :MOVE SP TO USER'S ERROR CALL
70      054430      162716      000002      MOVB     #4,(SP)      :WRITE ERROR NUMBER
71      054434      004736      :MOVE SP TO RETURN IF ERROR
72      054436      4$:      JSR      PC,@(SP)+      :REPORT ERROR AND RETURN
73
74      ;RESTORE SP TO NO ERROR RETURN AND BYPASS FURHTER STATUS CHECKING
75      054436      162716      000010      SUB      #10,(SP)      :MOVE SP TO NO ERROR
76      054442      000137      057554      JMP      46$      :SKIP TO END OF SUB
77
78      054446      5$:
79
80      ;REPORT AN ERROR IF 'OPI' ERROR OCCURRED DUE TO 'MOL' = 0, OR IF 'OPI'
81      ;AND 'MOL' ARE SET, BUT 'VV' IS RESET, INDICATING AN INTERMITTENT
82      ;'MOL'
83      054446      032737      020000      001352      BIT      #OPI,RMER1I      :IS 'OPI' SET??
84      054454      001447
85      054456      013737      001352      001140      BEQ      8$      :NO!!
86      054464      042737      020000      001140      MOV      RMER1I,$GDDAT      :EXPECTED STATUS
87      054472      013737      001352      001142      BIC      #OPI,$GDDAT
88      054500      032737      010000      001350      MOV      RMER1I,$BDDAT      :RECEIVED STATUS
89      054506      001404
90      054510      032737      000100      001350      BIT      #MOL,RMDSI      :WAS MEDIUM OFF LINE??
91      054516      001013
92      054520      062716      000004      BEQ      6$      :YES!!
93      054524      112776      000276      000000      BIT      #VV,RMDSI      :WAS 'MOL' INTERMITTENT??
94      054532      162716      000002      BNE      7$      :NO!!
95      054536      004736
96      054540      162716      000010      6$:      ADD      #4,(SP)      :MOVE SP TO USER'S ERROR CALL
97      054544      000413      MOVB     #276,@(SP)      :WRITE ERROR NUMBER IN CALL
98      054546      :MOVE SP TO RETURN IF ERROR
99
100     ;REPORT 'OPI' ERROR, WHICH IS DUE TO 'ON CYLINDER' NOT DROPPING OR
101     ;'RUN' TIMEOUT (20 MS) OR SEARCH TIMEOUT (50 MS)
102     054546      062716      000004      SUB      #2,(SP)      :MOVE SP TO RETURN IF ERROR
103     054552      112776      000277      000000      JSR      PC,@(SP)+      :REPORT ERROR AND RETURN
104     054560      162716      000002      SUB      #10,(SP)      :RESTORE SP TO NO ERROR
105     054564      004736
106     054566      162716      000010
107     054572      000240
108     054574      8$:
109
110     ;LOOK FOR 'IVC' ERROR DURING COMMAND INITIATION
111     054574      032737      010000      001400      BIT      #IVC,RMER2I      :WAS THERE AN 'IVC' ERROR??
112     054602      001432
113     ;REPORT 'IVC' ERROR DUE TO 'VV' = 0, OR REPORT ERRONEOUS 'IVC' ERROR
114     054604      013737      001400      001140      BEQ      10$      :NO!!
115
116     MOV      RMER2I,$GDDAT      :EXPECTED STATUS
    
```

```

115 054612 042737 010000 001140      BIC      #IVC,$GDDAT
116 054620 013737 001400 001142      MOV      RMER2I,$BDDAT      :RECEIVED STATUS
117 054626 062716 000004      ADD      #4,(SP)           :MOVE SP TO USER'S ERROR
118 054632 112776 000300 000000      MOVVB   #300,@(SP)        :WRITE ERROR NUMBER IN CALL
119 054640 032737 000100 001350      BIT      #VV,RMDSI        :WAS VOLUME VALID??
120 054646 001403      BEQ      9$              :NO!!
121 054650 112776 000301 000000      MOVVB   #301,@(SP)        :CHANGE ERROR NUMBER
122 054656 162716 000002      9$:      SUB      #2,(SP)        :MOVE SP TO RETURN IF ERROR
123 054662 004736      JSR      PC,@(SP)+        :REPORT 'IVC' ERROR AND RETURN
124 054664 162716 000010      SUB      #10,(SP)         :RESTORE SP TO NO ERROR
125 054670      10$:
126
127      ;SEE IF 'ILF' OR 'RMR' IS SET
128 054670 032737 000007 001352      BIT      #ILR!ILF!RMR,RMER1I
129 054676 001510      BEQ      13$             :NO ERRORS DETECTED
130      ;REPORT AN ERROR IF 'ILR' IS SET
131 054700 032737 000002 001352      BIT      #ILR,RMER1I     :WAS 'ILR' DETECTED??
132 054706 001424      BEQ      11$             :NO!!
133 054710 013737 001352 001140      MOV      RMER1I,$GDDAT   :EXPECTED STATUS
134 054716 042737 000002 001140      BIC      #ILR,$GDDAT
135 054724 013737 001352 001142      MOV      RMER1I,$BDDAT   :RECEIVED STATUS
136 054732 062716 000004      ADD      #4,(SP)         :MOVE SP TO USER'S ERROR CALL
137 054736 112776 000302 000000      MOVVB   #302,@(SP)        :WRITE ERROR NUMBER IN CALL
138 054744 162716 000002      SUB      #2,(SP)         :MOVE SP TO RETURN IF ERROR
139 054750 004736      JSR      PC,@(SP)+        :REPORT ERROR AND RETURN
140 054752 162716 000010      SUB      #10,(SP)         :RESTORE SP TO NO ERROR
141 054756 000240      NOP
142 054760      11$:
143
144      ;REPORT AN ERROR IF 'ILF' IS SET
145 054760 032737 000001 001352      BIT      #ILF,RMER1I     :WAS 'ILF' DETECTED??
146 054766 001424      BEQ      12$             :NO!!
147 054770 013737 001352 001140      MOV      RMER1I,$GDDAT   :EXPECTED STATUS
148 054776 042737 000001 001140      BIC      #ILF,$GDDAT
149 055004 013737 001352 001142      MOV      RMER1I,$BDDAT   :RECEIVED STATUS
150 055012 062716 000004      ADD      #4,(SP)         :MOVE SP TO USER'S ERROR CALL
151 055016 112776 000303 000000      MOVVB   #303,@(SP)        :WRITE ERROR NUMBER IN CALL
152 055024 162716 000002      SUB      #2,(SP)         :MOVE SP TO RETURN IF ERROR
153 055030 004736      JSR      PC,@(SP)+        :REPORT ERROR AND RETURN
154 055032 162716 000010      SUB      #10,(SP)         :RESTORE SP TO NO ERROR
155 055036 000240      NOP
156 055040      12$:
157
158      ;REPORT AN ERROR IF 'RMR' IS SET
159 055040 032737 000004 001352      BIT      #RMR,RMER1I     :WAS 'RMR' DETECTED??
160 055046 001424      BEQ      13$             :NO!!
161 055050 013737 001352 001140      MOV      RMER1I,$GDDAT   :EXPECTED STATUS
162 055056 042737 000004 001140      BIC      #RMR,$GDDAT
163 055064 013737 001352 001142      MOV      RMER1I,$BDDAT   :RECEIVED STATUS
164 055072 062716 000004      ADD      #4,(SP)         :MOVE SP TO USER'S ERROR CALL
165 055076 112776 000304 000000      MOVVB   #304,@(SP)        :WRITE ERROR NUMBER IN CALL
166 055104 162716 000002      SUB      #2,(SP)         :MOVE SP TO RETURN IF ERROR
167 055110 004736      JSR      PC,@(SP)+        :REPORT ERROR AND RETURN
168 055112 162716 000010      SUB      #10,(SP)         :RESTORE SP TO NO ERROR
169 055116 000240      NOP
170 055120      13$:
171      ;DETERMINE WHETHER OR NOT 'IAE' SHOULD BE SET AND CHECK FOR ERROR
    
```

```

172 055120 012737 002000 001140      MOV      #IAE,$GDDAT      :SETUP FOR "IAE" = 1
173 055126 052737 040000 057602      BIS      #SKI,49$        :SETUP FOR "SKI" = 1
174 055134 023727 001446 001060      CMP      RMDCO,#560.     :GREATER THAN LAST CYLINDER ?
175 055142 101035          BHI      15$             :YES - CYLINDER IS INVALID
176 055144 042737 040000 057602      BIC      #SKI,49$        :RESET SKI FLAG
177
178 055152 123737 001421 001335      CMPB     RMDAO+1,LSTRK+1 :GREATER THAN LAST TRACK ?
179 055160 101026          BHI      15$             :YES - TRACK IS INVALID
180
181 055162 123727 001420 000035      CMPB     RMDAO,#29.      :IS SECTOR > 29. ?
182 055170 101420          BLOS     14$            :NO
183 055172 032737 010000 001444      BIT      #FMT16,RMOFO    :18 BIT FORMAT ?
184 055200 001416          BEQ      15$            :YES - SECTOR IS INVALID FOR 18 BIT MODE
185 055202 123727 001420 000036      CMPB     RMDAO,#30.      :IS SECTOR > 30. ?
186 055210 101410          BLOS     14$            :NO
187 055212 032737 001000 001444      BIT      #SSEI,RMOFO     :IS SSEI CLEAR ?
188 055220 001406          BEQ      15$            :YES - SECTOR IS INVALID FOR 16 BIT MODE
189 055222 123727 001420 000037      CMPB     RMDAO,#31.      :IS SECTOR > 31. ?
190 055230 101002          BHI      15$            :YES - SECTOR IS INVALID
191 055232 005037 001140          CLR      $GDDAT         : "IAE" SHOULD = 0
192
193 055236 013737 001352 001142      14$:     MOV      RMER1I,$BDDAT :GET RECEIVED STATUS
194 055244 042737 175777 001142      BIC      #^CIAE,$BDDAT
195 055252 023737 001140 001142      CMP      $GDDAT,$BDDAT  :IS "IAE" STATUS OK??
196 055260 001004          BNE      16$            :NO!!
197 055262 042737 040000 057602      BIC      #SKI,49$        :IAE OK - SKI SHOULD BE 0
198 055270 000412          BR
199 055272 062716 000004          15$:     ADD      #4,(SP)         :MOVE SP TO USER'S ERROR CALL
200 055276 112776 000305 000000      MOVB     #305,@(SP)      :WRITE ERROR NUMBER
201 055304 162716 000002          SUB      #2,(SP)         :MOVE SP TO RETURN IF ERROR
202 055310 004736          JSR      PC,@(SP)+      :REPORT ERROR AND RETURN
203 055312 162716 000010          SUB      #10,(SP)       :MOVE SP TO NO ERROR
204 055316
205
206                                     :REPORT AN ERROR IF "SKI" IS SET AND "IAE" STATUS WAS OK
207 055316 013737 001400 001142      MOV      RMER2I,$BDDAT  :RECEIVED STATUS
208 055324 042737 137777 001142      BIC      #^CSKI,$BDDAT
209 055332 013737 057602 001140      MOV      49$,$GDDAT     :EXPECTED STATUS
210 055340 042737 137777 001140      BIC      #^CSKI,$GDDAT
211 055346 032737 040000 001400      BIT      #SKI,RMER2I    :WAS "SKI" SET??
212 055354 001417          BEQ      18$            :NO!!
213 055356 032737 040000 057602      BIT      #SKI,49$        :WAS SKI CAUSED BY IAE = 0??
214 055364 001032          BNE      19$            :YES - DON'T REPORT SKI
215 055366 062716 000004          ADD      #4,(SP)         :MOVE SP TO USERS ERROR CALL
216 055372 112776 000306 000000      MOVB     #306,@(SP)      :WRITE ERROR NUMBER
217 055400 162716 000002          SUB      #2,(SP)         :MOVE SP TO RETURN IF ERROR
218 055404 004736          JSR      PC,@(SP)+      :REPORT ERROR AND RETURN
219 055406 162716 000010          SUB      #10,(SP)       :MOVE SP TO NO ERROR
220 055412 000417          BR      19$
221
222 055414          16$:
223
224                                     :REPORT AN ERROR IF SKI = 0 AND IAE WAS NOT DETECTED
225 055414 032737 040000 057602      BIT      #SKI,49$        :SHOULD SKI BE SET??
226 055422 001413          BEQ      19$            :NO!!
227 055424 062716 000004          ADD      #4,(SP)         :MOVE SP TO USER'S ERROR CALL
228 055430 112776 000307 000000      MOVB     #307,@(SP)      :WRITE ERROR NUMBER IN CALL
    
```



```

286 055716 032737 040000 001352      BIT      #UNS,RMER11      ;IS 'UNS' SET??
287 055724 001427                      BEQ      23$            ;NO!!
288 055725 032737 000200 001400      RIT      #DVC,RMER2I    ;WAS 'UNS' CAUSED BY 'DVC'??
289 055734 001023                      BNE      23$            ;YES!!
290 055736 013737 001352 001140      MOV      RMER11,$GDDAT  ;EXPECTED STATUS
291 055744 042737 040000 001140      BIC      #UNS,$GDDAT
292 055752 013737 001352 001142      MOV      RMER11,$BDDAT  ;RECEIVED STATUS
293 055760 062716 000004                      ADD      #4,(SP)        ;MOVE SP TO USERS ERROR CALL
294 055764 112776 000313 000000      MOVVB   #313,@(SP)     ;WRITE ERROR NUMBER
295 055772 162716 000002                      SUB      #2,(SP)        ;MOVE SP TO RETURN IF ERROR
296 055776 004736                      JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
297 056000 162716 000010                      SUB      #10,(SP)      ;RESTORE SP TO NO ERROR
298 056004
299
300                                     ;REPORT ANY DRIVE TIMING ERROR, I.E., 'DTE' = 1
301 056004 032737 010000 001352      BIT      #DTE,RMER11    ;IS DTE SET??
302 056012 001423                      BEQ      24$            ;NO!!
303 056014 013737 001352 001140      MOV      RMER11,$GDDAT  ;EXPECTED STATUS
304 056022 042737 010000 001140      BIC      #DTE,$GDDAT
305 056030 013737 001352 001142      MOV      RMER11,$BDDAT  ;RECEIVED STATUS
306 056036 062716 000004                      ADD      #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
307 056042 112776 000314 000000      MOVVB   #314,@(SP)     ;WRITE ERROR NUMBER IN CALL
308 056050 162716 000002                      SUB      #2,(SP)        ;MOVE SP TO RETURN IF ERROR
309 056054 004736                      JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
310 056056 162716 000010                      SUB      #10,(SP)      ;MOVE SP TO 'IO ERROR
311 056062
312
313                                     ;REPORT AN ERROR IF WRITE LOCK ERROR IS SET. SEE IF DRIVE IS NOT
314                                     ;WRITE PROTECTED, OR IF FUNCTION WAS NOT A WRITE
315 056062 032737 004000 001352      BIT      #WLE,RMER11    ;WAS 'WLE' SET??
316 056070 001441                      BEQ      27$            ;NO!!
317 056072 013737 001352 001142      MOV      RMER11,$BDDAT  ;RECEIVED STATUS
318 056100 013737 001352 001140      MOV      RMER11,$GDDAT  ;EXPECTED STATUS
319 056106 052737 004000 001140      BIS      #WLE,$GDDAT
320 056114 062716 000004                      ADD      #4,(SP)        ;MOVE SP TO USERS ERROR CALL
321 056120 112776 000315 000000      MOVVB   #315,@(SP)     ;WRITE ERROR NUMBER IN CALL
322 056126 032737 004000 001350      BIT      #WRL,RMDSI     ;WAS DRIVE WRITE PROTECTED??
323 056134 001404                      BEQ      25$            ;NO!!
324 056136 032737 000010 001412      BIT      #BIT3,RMCS10   ;WAS COMMAND A WRITE??
325 056144 001406                      BEQ      26$            ;YES!!
326 056146 112776 000316 000000      MOVVB   #316,@(SP)     ;CHANGE ERROR NUMBER
327 056154 042737 004000 001140      BIC      #WLE,$GDDAT
328 056162 162716 000002                      SUB      #2,(SP)        ;MOVE SP TO RETURN IF ERROR
329 056166 004736                      JSR      PC,@(SP)+     ;REPORT ERROR AND RETURN
330 056170 162716 000010                      SUB      #10,(SP)      ;MOVE SP TO NO ERROR
331
332 056174                                     ;CHECK FOR WRITE LOCK ERROR
333
334                                     ;OMIT DATA ERROR CHECKS IF ANY PREVIOUS ERRORS HAVE BEEN DETECTED
335 056174 062716 000004                      ADD      #4,(SP)        ;MOVE SP TO USER'S ERROR
336 056200 105776 000000                      TSTB    @(SP)          ;WAS ERROR DETECTED??
337 056204 001404                      BEQ      28$            ;NO - DO DATA CHECKS
338 056206 162716 000004                      SUB      #4,(SP)        ;RESTORE SP
339 056212 000137 057214                      JMP      42$            ;SKIP DATA CHECKS
340 056216 162716 000004      28$:    SUB      #4,(SP)        ;RESTORE SP
341
342                                     ;CHECK HEADER ERRORS IF FUNCTION WAS NOT WRITE HEADER AND DATA, AND
    
```

```

343 ;IF HEADER COMPARE IS NOT INHIBITED
344 056222 013737 001412 057604 MOV RMCS10,50$ ;STRIP AND STORE FUNCTION CODE
345 056230 042737 177700 057604 BIC #^CFNCMSK,50$
346 056236 022737 000063 057604 CMP #WH!GO,50$ ;WAS FUNCTION WRITE HEADER & DATA??
347 056244 001512 BEQ 31$ ;YES - SKIP HEADER CHECKS
348 056246 032737 002000 001370 BIT #HCI,RMOFI ;WAS HCI SET??
349 056254 001106 BNE 31$ ;YES - SKIP HEADER CHECKS
350
351 ;SEE IF ANY HEADER ERRORS ARE SET, I.E., 'FER' OR 'HCRC' OR 'HCE'
352 056256 032737 000620 001352 BIT #HCRC!FER!HCE,RMER1I
353 056264 001533 BEQ 33$ ;NO ERRORS SET
354
355 ;REPORT HEADER CRC ERROR IF SET
356 056266 032737 000400 001352 BIT #HCRC,RMER1I ;WAS HCRC SET??
357 056274 001422 BEQ 29$ ;NO!!
358 056276 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
359 056304 042737 000400 001140 BIC #HCRC,$GDDAT
360 056312 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
361 056320 062716 000004 ADD #4,(SP) ;MOVE SP TO USERS ERROR
362 056324 112776 000317 000000 MOVB #317,@(SP) ;WRITE ERROR NUMBER
363 056332 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
364 056336 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
365 056340 000501 BR 32$
366 056342 29$:
367
368 ;REPORT FORMAT ERROR IF SET
369 056342 032737 000020 001352 BIT #FER,RMER1I ;WAS 'FER' SET??
370 056350 001422 BEQ 30$ ;NO!!
371 056352 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
372 056360 042737 000020 001140 BIC #FER,$GDDAT
373 056366 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
374 056374 062716 000004 ADD #4,(SP) ;MOVE SP TO USERS ERROR
375 056400 112776 000320 000000 MOVB #320,@(SP) ;WRITE ERROR NUMBER
376 056406 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
377 056412 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
378 056414 000453 BR 32$
379 056416 30$:
380
381 ;REPORT HEADER COMPARE ERROR IF SET
382 056416 032737 000200 001352 BIT #HCE,RMER1I ;WAS 'HCE' SET??
383 056424 001453 BEQ 33$ ;NO!!
384 056426 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
385 056434 042737 000200 001140 BIC #HCE,$GDDAT
386 056442 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
387 056450 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR
388 056454 112776 000321 000000 MOVB #321,@(SP) ;WRITE ERROR NUMBER
389 056462 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
390 056466 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
391 056470 000425 BR 32$
392
393 ;THERE SHOULD BE NO HEADER ERRORS BECAUSE
394 ; .COMMAND WAS WRITE HEADER AND DATA, OR
395 ; .HEADER COMPARE INHIBIT WAS SET
395 056472 032737 000620 001352 31$: BIT #HCE!FER!HCRC,RMER1I
396 056500 001425 BEQ 33$ ;NO ERRORS WERE SET
397 056502 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
398 056510 042737 000620 001140 BIC #HCE!FER!HCRC,$GDDAT
399 056516 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
    
```



```

400 056524 062716 000004          ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
401 056530 112776 000322 000000    MOVB     #322,@(SP)       ;WRITE ERROR NUMBER
402 056536 162716 000002          SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
403 056542 004736          JSR      PC,@(SP)+       ;REPORT ERROR AND RETURN
404 056544 162716 000010 32$:    SUB      #10,(SP)        ;MOVE SP TO NO ERROR
405 056550 000137 057214          JMP      42$            ;OMIT FURTHER DATA CHECKS
406
407 056554          33$:
408
409          ;IF COMMAND WAS A WRITE COMMAND, GO DO WRITE ERROR CHECKS, OTHERWISE
410          ;DO READ ERROR CHECKS
411 056554 032737 000010 057604    BIT      #BIT3,50$      ;WAS THIS A WRITE COMMAND?
412 056562 001002          BNE     34$            ;NO!!
413 056564 000137 057002          JMP      39$            ;GO DO WRITE STATUS CHECK
414 056570          34$:
415
416          ;REPORT DATA CHECK IF SET
417 056570 032737 100000 001352    BIT      #DCK,RMER1I     ;DATA CHECK ERROR??
418 056576 001450          BEQ     37$            ;NO!!
419 056600 013737 001352 001140    MOV      RMER1I,$GDDAT   ;EXPECTED STATUS
420 056606 042737 100000 001140    BIC      #DCK,$GDDAT
421 056614 013737 001352 001142    MOV      RMER1I,$BDDAT   ;RECEIVED STATUS
422 056622 062716 000004          ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR
423 056626 112776 000323 000000    MOVB     #323,@(SP)       ;WRITE ERROR NUMBER
424 056634 032737 004000 001370    BIT      #ECI,RMOFI     ;WAS ECC CORRECTION DISABLED??
425 056642 001021          BNE     36$            ;YES!!
426 056644 112776 000324 000000    MOVB     #324,@(SP)       ;CHANGE TO RECOVERABLE ERROR
427 056652 032737 000100 001352    BIT      #ECH,RMER1I     ;IS ERROR RECOVERABLE??
428 056660 001007          BNE     35$            ;NO !!
429          ;DO NOT REPORT RECOVERABLE ERROR IF READ COMMAND
430 056662 032737 000020 057604    BIT      #BIT4,50$      ;WAS THIS A READ COMMAND ??
431 056670 001406          BEQ     36$            ;NO !!
432 056672 162716 000004          SUB      #4,(SP)         ;RESTORE SP
433 056676 000410          BR      37$            ;SKIP ERROR - DATA WILL BE CORRECTED
434 056700 112776 000325 000000 35$:    MOVB     #325,@(SP)       ;CHANGE TO NON RECOVERABLE
435 056706 162716 000002 36$:    SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
436 056712 004736          JSR      PC,@(SP)+       ;REPORT ERROR AND RETURN
437 056714 162716 000010          SUB      #10,(SP)        ;RESTORE SP TO NO ERROR
438
439 056720          37$:
440
441          ;REPORT DATA BUS PARITY ERROR IF SET, I.E., MDPE = 1
442 056720 032737 000400 001346    BIT      #MDPE,RMCS2I    ;PARITY ERROR SET??
443 056726 001423          BEQ     38$            ;NO!!
444 056730 013737 001346 001140    MOV      RMCS2I,$GDDAT   ;EXPECTED STATUS
445 056736 042737 000400 001140    BIC      #MDPE,$GDDAT
446 056744 013737 001346 001142    MOV      RMCS2I,$BDDAT   ;RECEIVED STATUS
447 056752 062716 000004          ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR
448 056756 112776 000326 000000    MOVB     #326,@(SP)       ;WRITE ERROR NUMBER
449 056764 162716 000002          SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
450 056770 004736          JSR      PC,@(SP)+       ;REPORT ERROR AND RETURN
451 056772 162716 000010          SUB      #10,(SP)        ;MOVE SP TO NO ERROR
452 056776 000137 057214          JMP      42$            ;SKIP WRITE STATUS CHECK
453
454 057002          39$:
455
456          ;TEST TO SEE THAT OFFSET MODE WAS RESET; REPORT ERROR IF 'OM' = 1
    
```

```

457 057002 032737 000001 001350      BIT      #OM,RMDSI      ;IS OFFSET ON??
458 057010 001423                      BEQ      40$          ;NO
459 057012 013737 001350 00114C      MOV      RMDSI,$GDDAT ;EXPECTED STATUS
460 057020 042737 000001 001140      BIC      #OM,$GDDAT
461 057026 013737 001350 001142      MOV      RMDSI,$BDDAT ;RECEIVED STATUS
462 057034 062716 000004                      ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
463 057040 112776 000327 000000      MOVVB   #327,@(SP)   ;WRITE ERROR NUMBER IN CALL
464 057046 162716 000002                      SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
465 057052 004736                      JSR      PC,@(SP)+    ;REPORT ERROR AND RETURN
466 057054 162716 000010                      SUB      #10,(SP)    ;MOVE SP TO NO ERROR
467 057060
468
469                                     ;TEST FOR DATA BUS PARITY ERROR; REPORT ERROR IF 'DPE' = 1
470 057060 032737 000010 001400      BIT      #DPE,RMER2I  ;DATA PARITY ERROR??
471 057066 001423                      BEQ      41$          ;NO!!
472 057070 013737 001400 001140      MOV      RMER2I,$GDDAT ;EXPECTED STATUS
473 057076 042737 000010 001140      BIC      #DPE,$GDDAT
474 057104 013737 001400 001142      MOV      RMER2I,$BDDAT ;RECEIVED STATUS
475 057112 062716 000004                      ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
476 057116 112776 000330 000000      MOVVB   #330,@(SP)   ;WRITE ERROR NUMBER
477 057124 162716 000002                      SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
478 057130 004736                      JSR      PC,@(SP)+    ;REPORT ERROR AND RETURN
479 057132 162716 000010                      SUB      #10,(SP)    ;MOVE SP TO NO ERROR
480 057136
481
482                                     ;TEST FOR WRITE CLOCK FAILURE; REPORT ERROR IF 'WCF' = 1
483 057136 032737 000040 001352      BIT      #WCF,RMER1I  ;IS 'WCF' SET??
484 057144 001423                      BEQ      42$          ;NO!!
485 057146 013737 001352 001140      MOV      RMER1I,$GDDAT ;EXPECTED STATUS
486 057154 042737 000040 001140      BIC      #WCF,$GDDAT
487 057162 013737 001352 001142      MOV      RMER1I,$BDDAT ;RECEIVED STATUS
488 057170 062716 000004                      ADD      #4,(SP)      ;MOVE SP TO USERS ERROR CALL
489 057174 112776 000331 000000      MOVVB   #331,@(SP)   ;WRITE ERROR NUMBER
490 057202 162716 000002                      SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
491 057206 004736                      JSR      PC,@(SP)+    ;REPORT ERROR AND RETURN
492 057210 162716 000010                      SUB      #10,(SP)    ;MOVE SP TO NO ERROR
493 057214
494
495                                     ;REPORT 'DATA LATE' ERROR IF 'DLT' = 1
496 057214 032737 100000 001346      BIT      #DLT,RMCS2I  ;IS 'DLT' SET??
497 057222 001423                      BEQ      43$          ;NO!!
498 057224 013737 001346 001140      MOV      RMCS2I,$GDDAT ;EXPECTED STATUS
499 057232 042737 100000 001140      BIC      #DLT,$GDDAT
500 057240 013737 001346 001142      MOV      RMCS2I,$BDDAT ;RECEIVED STATUS
501 057246 062716 000004                      ADD      #4,(SP)      ;MOVE SP TO USERS ERROR CALL
502 057252 112776 000332 000000      MOVVB   #332,@(SP)   ;WRITE ERROR NUMBER
503 057260 162716 000002                      SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
504 057264 004736                      JSR      PC,@(SP)+    ;REPORT ERROR AND RETURN
505 057266 162716 000010                      SUB      #10,(SP)    ;MOVE SP TO NO ERROR
506 057272
507                                     ;LOOK FOR UNEXPECTED CHANGES IN DRIVE STATUS
508 057272 013746 001350                      MOV      RMDSI,-(SP)  ;STACK DRIVE STATUS
509 057276 042716 147677                      BIC      #^C<PIP!MOL!VV>,(SP) ;CLEAR DONT CARES
510 057302 022726 010100                      CMP      #MOL!VV,(SP)+ ;IS DRIVE STATUS OK??
511 057306 001522                      BEQ      46$          ;YES!!
512
513                                     ;REPORT ERROR IF POSITIONING IN PROGRESS AND NO SEEK INCOMPLETE ERROR,
    
```

```

514                                     :I.E., PIP = 1 AND SKI = 0
515 057310 032737 020000 001350      BIT    #PIP,RMDSI      :IS 'PIP' SET??
516 057316 001430                    BEQ    44$           :NO!!
517 057320 032737 040000 001400      BIT    #SKI,RMER2I   :WAS 'SKI' ERROR REPORTED??
518 057326 001024                    BNE    44$           :YES-DONT REPORT PIP
519 057330 013737 001350 0C1140      MOV    RMDSI,$GDDAT  :EXPECTED STATUS
520 057336 042737 020000 001140      BIC    #PIP,$GDDAT
521 057344 013737 001350 001142      MOV    RMDSI,$BDDAT :RECEIVED STATUS
522 057352 062716 000004              ADD    #4,(SP)       :MOVE SP TO USERS ERROR CALL
523 057356 112776 000333 000000      MOVB  #333,a(SP)    :WRITE ERROR NUMBER
524 057364 162716 000002              SUB    #2,(SP)       :MOVE SP TO RETURN IF ERROR
525 057370 004736                    JSR    PC,a(SP)+     :REPORT ERROR AND RETURN
526 057372 162716 000010              SUB    #10,(SP)     :MOVE SP TO NO ERROR
527 057376 000240                    NOP
528 057400                          44$:
529
530                                     :REPORT ERROR IF MEDIUM IS NOT ON LINE AND OPI ERROR WAS NOT
531                                     :REPORTED, I.E., MOL = OPI = 0
532 057400 032737 010000 001350      BIT    #MOL,RMDSI   :IS MEDIUM ON LINE??
533 057406 001027                    BNE    45$           :YES!!
534 057410 032737 020000 001352      BIT    #OPI,RMER1I  :WAS OPI ERROR REPORTED??
535 057416 001023                    BNE    45$           :YES!!
536 057420 013737 001350 001140      MOV    RMDSI,$GDDAT :EXPECTED STATUS
537 057426 052737 010000 001140      BIS    #MOL,$GDDAT
538 057434 013737 001350 001142      MOV    RMDSI,$BDDAT :RECEIVED STATUS
539 057442 062716 000004              ADD    #4,(SP)       :MOVE SP TO USER'S ERROR
540 057446 112776 000334 000000      MOVB  #334,a(SP)    :WRITE ERROR NUMBER
541 057454 162716 000002              SUB    #2,(SP)       :MOVE SP TO RETURN IF ERROR
542 057460 004736                    JSR    PC,a(SP)+     :REPORT ERROR AND RETURN
543 057462 162716 000010              SUB    #10,(SP)     :MOVE SP TO NO ERROR
544 057466                          45$:
545
546                                     :REPORT ERROR IF VOLUME IS NOT VALID AND 'IVC' ERROR WAS NOT
547                                     :REPORTED, I.E., VV = IVC = 0
548 057466 032737 000100 001350      BIT    #VV,RMDSI    :IS VOLUME VALID??
549 057474 001027                    BNE    46$           :YES!!
550 057476 032737 010000 001400      BIT    #IVC,RMER2I  :WAS IVC ERROR REPORTED??
551 057504 001033                    BNE    47$           :YES!!
552 057506 013737 001350 001140      MOV    RMDSI,$GDDAT :EXPECTED STATUS
553 057514 052737 000100 001140      BIS    #VV,$GDDAT
554 057522 013737 001350 001142      MOV    RMDSI,$BDDAT :RECEIVED STATUS
555 057530 062716 000004              ADD    #4,(SP)       :MOVE SP TO USERS ERROR CALL
556 057534 112776 000335 000000      MOVB  #335,a(SP)    :WRITE ERROR NUMBER
557 057542 162716 000002              SUB    #2,(SP)       :MOVE SP TO RETURN IF ERROR
558 057546 004736                    JSR    PC,a(SP)+     :REPORT ERROR AND RETURN
559 057550 162716 000010              SUB    #10,(SP)     :MOVE SP TO NO ERROR
560 057554                          46$:
561
562                                     :AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS FOUND
563 057554 062716 000004              ADD    #4,(SP)       :MOVE SP TO ERROR CALL
564 057560 105776 000000              TSTB  a(SP)         :ANY ERROR??
565 057564 001403                    BEQ    47$           :NO!!
566 057566 062716 000004              ADD    #4,(SP)       :YES - MOVE SP TO ERROR RETURN
567 057572 000402                    BR     48$
568 057574 162716 000004              47$: SUB    #4,(SP)     :MOVE SP TO NO ERROR RETURN
569
570 057600 000207                          48$: RTS    PC         :RETURN TO USER
    
```

571
572 057602 000000
573 057604 000000

49\$: .WORD
50\$: .WORD

;ERROR FLAGS
;TEMPORARY STORAGE

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

057606
 057606 062716 000004
 057612 105076 000000
 057616 162716 000004
 057622 013746 001350
 057626 042716 147677
 057632 022726 010100
 057636 001524
 057640 032737 010000 001350
 057646 001030
 057650 032737 020000 001352
 057656 001024
 057660 013737 001350 001140
 057666 052737 010000 001140
 057674 013737 001350 001142
 057702 062716 000004
 057706 112776 000207 000000
 057714 162716 000002
 057720 004736
 057722 162716 000010
 057726 000240
 057730
 057730 032737 000100 001350
 057736 001030

```

.SBTTL  STATIC DRIVE STATUS CHECK SUBROUTINE

:THIS SUBROUTINE LOOKS FOR UNEXPECTED CHANGES IN DRIVE
:STATUS, SUCH AS THE DRIVE LOSING VOLUME VALID.  THE SUBROUTINE
:CAN BE USED BY HOUSEKEEPING AND OTHER COMMANDS DURING WHICH THERE
:SHOULD NOT BE ANY DRIVE ERRORS OR CHANGES IN STATE.

:THE FOLLOWING CONDITIONS ARE TESTED AND REPORTED AS ERRORS
:IF TRUE:

:
:   .MOL = 0, INDICATES DRIVE WENT OFFLINE, NOTE
:   THAT MOL IS ASSUMED TO HAVE BEEN SET
:
:   .VV = 0, INDICATES THE DRIVE LOST VOLUME VALID
:
:   .PIP = 1, INDICATES THAT THE DRIVE IS OFF CYLINDER
:
:   .SKI = 1, INDICATES THE DRIVE HAS AN UNEXPECTED SKI ERROR
:
:   .DVC = 1, INDICATES AN UNEXPECTED DEVICE FAULT

:THE SUBROUTINE IS CALLED AFTER STORING STATUS IN THE GET BUFFER.

:(1)  JSR    PC,STCDRVSTS
:      BR    ???          RETURN HERE IF NO ERROR
:      NOP          RETURN HERE TO REPORT AN ERROR
:      ERROR        ERROR NUMBER DEFINED BY SUB
:      JSR    PC,@(SP)+   GO BACK TO SUB FOR MORE ERROR CHECKS
:      ???          RETURN HERE IF NO MORE ERRORS

STCDRVSTS:

:CLEAR USER'S ERROR CALL
ADD    #4,(SP) ;MOVE SP TO USER'S ERROR CALL
CLRB  @(SP)   ;CLEAR ERROR NUMBER
SUB   #4,(SP) ;MOVE SP BACK TO NO ERROR RETURN

:SEE IF 'MOL' = 'VV' = 1, AND 'PIP' = 0
MOV   RMDSI,-(SP) ;PUT DRIVE STATUS ON STACK
BIC  #'C<PIP!MOL!VV>,(SP)
CMP  #MOL!VV,(SP)+ ;ARE MOL,VV AND PIP O.K.??
BEQ  3$       ;YES!!

:REPORT AN ERROR IF MOL = 0 AND 'OPI' = 0
BIT   #MOL,RMDSI ;IS MOL ON ??
BNE  1$       ;YES!!
BIT   #OPI,RMER1 ;WAS 'OPI' SET??
BNE  1$       ;YES-DONT REPORT 'MOL' = 0
MOV   RMDSI,$GDDAT ;EXPECTED STATUS
BIS   #MOL,$GDDAT
MOV   RMDSI,$BDDAT ;RECEIVED STATUS
ADD   #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #207,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB  #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR  PC,@(SP)+ ;REPORT ERROR VIA USER
SUB  #10,(SP) ;MOVE SP BACK TO NO ERROR RETURN

1$:

:REPORT AN ERROR IF VOLUME VALID IS NOW ZERO AND 'IVC' = 0
BIT   #VV,RMDSI ;IS 'VV' = 0??
BNE  2$       ;NO!!
    
```

```

58 057740 032737 010000 001400 BIT #IVC,RMER2I ;WAS 'IVC' SET??
59 057746 001024 BNE 2$ ;YES-DONT REPORT 'VV' = 0
60 057750 013737 001350 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
61 057756 052737 000100 001350 BIS #VV,RMDSI
62 057764 013737 001350 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
63 057772 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
64 057776 112776 000210 000000 MOVB #210,@(SP) ;WRITE ERROR NUMBER IN CALL
65 060004 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
66 060010 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
67 060012 162716 000010 SUB #10,(SP) ;MOVE SP BACK TO NO ERROR
68 060016 000240 NOP
69 060020 2$:
70
71 ;REPORT AN ERROR IF DRIVE IS OFF CYLINDER AND 'SKI' = 0
72 060020 032737 020000 001350 BIT #PIP,RMDSI ;IS DRIVE OFF CYLINDER??
73 060026 001430 BEQ 3$ ;NO!!
74 060030 032737 040000 001400 BIT #SKI,RMER2I ;WAS 'SKI' SET??
75 060036 001024 BNE 3$ ;YES-DONT REPORT 'PIP' = 1
76 060040 013737 001350 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
77 060046 042737 020000 001140 BIC #PIP,$GDDAT
78 060054 013737 001350 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
79 060062 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
80 060066 112776 000211 000000 MOVB #211,@(SP) ;WRITE ERROR NUMBER IN USER'S CALL
81 060074 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
82 060100 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
83 060102 162716 000010 SUB #10,(SP) ;MOVE SP TO NO ERROR RETURN
84 060106 000240 NOP
85 060110 3$:
86
87 ;SEE IF 'SKI' = 'DVC' = 0
88 060110 013746 001400 MOV RMER2I,-(SP) ;PUT ERROR REG 2 ON STACK
89 060114 042726 137577 BIC #^C<SKI!DVC>,(SP)+
90 060120 001460 BEQ 6$ ;BRANCH IF NO ERROR
91 060122 4$:
92
93 ;REPORT AN ERROR IF THERE IS A DEVICE FAULT
94 060122 032737 000200 001400 BIT #DVC,RMER2I ;ANY DEVICE FAULT??
95 060130 001424 BEQ 5$ ;NO!!
96 060132 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
97 060140 042737 000200 001140 BIC #DVC,$GDDAT
98 060146 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
99 060154 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S CALL
100 060160 112776 000212 000000 MOVB #212,@(SP) ;WRITE NUMBER OF ERROR IN CALL
101 060166 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
102 060172 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
103 060174 162716 000010 SUB #10,(SP) ;MOVE SP BACK TO NO ERROR
104 060200 000240 NOP
105 060202 5$:
106
107 ;REPORT AN ERROR IF 'SKI' = 1
108 060202 032737 040000 001400 BIT #SKI,RMER2I ;IS THERE A SEEK INCOMPLETE ERROR
109 060210 001424 BEQ 6$ ;NO!!
110 060212 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
111 060220 042737 040000 001140 BIC #SKI,$GDDAT
112 060226 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
113 060234 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
114 060240 112776 000213 000000 MOVB #213,@(SP) ;WRITE ERROR NUMBER IN USER'S ERROR CALL
    
```

```
115 060246 162716 000002          SUB    #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
116 060252 004736                JSR    PC,@(SP)+   ;REPORT ERROR VIA USER
117 060254 162716 000010          SUB    #10,(SP)    ;MOVE SP BACK TO NO ERROR
118 060260 000240                NOP
119 060262                                6$:
120
121                                ;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
122 060262 062716 000004          ADD    #4,(SP)     ;MOVE SP TO USER'S ERROR CALL
123 060266 105776 000000          TSTB  @ (SP)       ;WAS AN ERROR DETECTED??
124 060272 001403                BEQ    7$          ;NO!!
125 060274 062716 000004          ADD    #4,(SP)     ;YES - MOVE SP TO USER'S ERROR RETURN
126 060300 000402                BR     8$
127 060302 162716 000004          SUB    #4,(SP)    ;NO - MOVE SP TO NO ERROR RETURN
128 060306 000240                                7$:
129 060310 000207                                8$:
                                NOP
                                RTS    PC                ;RETURN TO USER
```

1

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES

```

:*****
:*SAVE R0-R5
:*CALL:
:*   SAVREG
:*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
:*
:*TOP---(+16)
:* +2---(+18)
:* +4---R5
:* +6---R4
:* +8---R3
:*+10---R2
:*+12---R1
:*+14---R0
    
```

```

060312
060312 010046
060314 010146
060316 010246
060320 010346
060322 010446
060324 010546
060326 016646 000022
060332 016646 000022
060336 016646 000022
060342 016646 000022
060346 000002

$SAVREG:
MOV R0,-(SP)      ::PUSH R0 ON STACK
MOV R1,-(SP)      ::PUSH R1 ON STACK
MOV R2,-(SP)      ::PUSH R2 ON STACK
MOV R3,-(SP)      ::PUSH R3 ON STACK
MOV R4,-(SP)      ::PUSH R4 ON STACK
MOV R5,-(SP)      ::PUSH R5 ON STACK
MOV 22(SP),-(SP)  ::SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP)  ::SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP)  ::SAVE PS OF CALL
MOV 22(SP),-(SP)  ::SAVE PC OF CALL
RTI
    
```

```

:*RESTORE R0-R5
:*CALL:
:*   RESREG
$RESREG:
MOV (SP)+,22(SP)  ::RESTORE PC OF CALL
MOV (SP)+,22(SP)  ::RESTORE PS OF CALL
MOV (SP)+,22(SP)  ::RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP)  ::RESTORE PS OF MAIN FLOW
MOV (SP)+,R5      ::POP STACK INTO R5
MOV (SP)+,R4      ::POP STACK INTO R4
MOV (SP)+,R3      ::POP STACK INTO R3
MOV (SP)+,R2      ::POP STACK INTO R2
MOV (SP)+,R1      ::POP STACK INTO R1
MOV (SP)+,R0      ::POP STACK INTO R0
RTI
    
```

```

060350
060350 012666 000022
060354 012666 000022
060360 012666 000022
060364 012666 000022
060370 012605
060372 012604
060374 012603
060376 012602
060400 012601
060402 012600
060404 000002
    
```


.SBTTL BINARY TO ASCII AND TYPE ROUTINE

 *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 16-BIT
 *BINARY-ASCII NUMBER AND TYPE IT.

*CALL:

					MOV	NUMBER,-(SP)	::NUMBER TO BE TYPED
					TYPBN		::TYPE IT
060406	010146				\$TYPBN: MOV	R1,-(SP)	::SAVE R1 ON THE STACK
060410	016601	000006			MOV	6(SP),R1	::GET THE INPUT NUMBER
060414	000261				SEC		::SET 'C' SO CAN KEEP TRACK OF THE NUMBER OF BITS
060416	112737	000060	060460	1\$:	MOVB	#'0,\$BIN	::SET CHARACTER TO AN ASCII '0'.
060424	006101				ROL	R1	::GET THIS BIT
060426	001406				BEQ	2\$::DONE?
060430	105537	060460			ADCB	\$BIN	::NO--SET THE CHARACTER EQUAL TO THIS BIT
060434	104401	060460			TYPE	,\$BIN	::GO TYPE THIS BIT
060440	000241				CLC		::CLEAR 'C' SO CAN KEEP TRACK OF BITS
060442	000765				BR	1\$::GO DO THE NEXT BIT
060444	012601			2\$:	MOV	(SP)+,R1	::POP THE STACK INTO R1
060446	016666	000002	000004		MOV	2(SP),4(SP)	::ADJUST THE STACK
060454	012616				MOV	(SP)+,(SP)	
060456	000002				RTI		::RETURN TO USER
060460	000	000			\$BIN: .BYTE	0,0	::STORAGE FOR ASCII CHAR. AND TERMINATOR

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

 *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
 *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
 *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
 *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
 *REPLACED WITH SPACES.
 *CALL:

* MOV NUM,-(SP) ;;PUT THE BINARY NUMBER ON THE STACK
 * TYPDS ;;GO TO THE ROUTINE

060462				\$TYPDS:	MOV R0,-(SP)	::PUSH R0 ON STACK
060462	010046				MOV R1,-(SP)	::PUSH R1 ON STACK
060464	010146				MOV R2,-(SP)	::PUSH R2 ON STACK
060466	010246				MOV R3,-(SP)	::PUSH R3 ON STACK
060470	010346				MOV R5,-(SP)	::PUSH R5 ON STACK
060472	010546				MOV #20200,-(SP)	::SET BLANK SWITCH AND SIGN
060474	012746	020200			MOV 20(SP),R5	::GET THE INPUT NUMBER
060500	016605	000020			BPL 1\$::BR IF INPUT IS POS.
060504	100004				NEG R5	::MAKE THE BINARY NUMBER POS.
060506	005405				MOVB #'-,1(SP)	::MAKE THE ASCII NUMBER NEG.
060510	112766	000055	000001	1\$:	CLR R0	::ZERO THE CONSTANTS INDEX
060516	005000				MOV #SDBLK,R3	::SETUP THE OUTPUT POINTER
060520	012703	060676			MOVB #' ,(R3)+	::SET THE FIRST CHARACTER TO A BLANK
060524	112723	000040		2\$:	CLR R2	::CLEAR THE BCD NUMBER
060530	005002				MOV \$DTBL(R0),R1	::GET THE CONSTANT
060532	016001	060666		3\$:	SUB R1,R5	::FORM THIS BCD DIGIT
060536	160105				BLT 4\$::BR IF DONE
060540	002402				INC R2	::INCREASE THE BCD DIGIT BY 1
060542	005202				BR 3\$	
060544	000774				ADD R1,R5	::ADD BACK THE CONSTANT
060546	060105			4\$:	TST R2	::CHECK IF BCD DIGIT=0
060550	005702				BNE 5\$::FALL THROUGH IF 0
060552	001002				TSTB (SP)	::STILL DOING LEADING 0'S?
060554	105716				BMI 7\$::BR IF YES
060556	100407				ASLB (SP)	::MSD?
060560	106316			5\$:	BCC 6\$::BR IF NO
060562	103003				MOVB 1(SP),-1(R3)	::YES--SET THE SIGN
060564	116663	000001	177777		BIS #'0,R2	::MAKE THE BCD DIGIT ASCII
060572	052702	000060		6\$:	BIS #' ,R2	::MAKE IT A SPACE IF NOT ALREADY A DIGIT
060576	052702	000040		7\$:	MOVB R2,(R3)+	::PUT THIS CHARACTER IN THE OUTPUT BUFFER
060602	110223				TST (R0)+	::JUST INCREMENTING
060604	005720				CMP R0,#10	::CHECK THE TABLE INDEX
060606	020027	000010			BLT 2\$::GO DO THE NEXT DIGIT
060612	002746				BGT 8\$::GO TO EXIT
060614	003002				MOV R5,R2	::GET THE LSD
060616	010502				BR 6\$::GO CHANGE TO ASCII
060620	000764				TSTB (SP)+	::WAS THE LSD THE FIRST NON-ZERO?
060622	105726			8\$:	BPL 9\$::BR IF NO
060624	100003				MOVB -1(SP),-2(R3)	::YES--SET THE SIGN FOR TYPING
060626	116663	177777	177776	9\$:	CLRB (R3)	::SET THE TERMINATOR
060634	105013				MOV (SP)+,R5	::POP STACK INTO R5
060636	012605				MOV (SP)+,R3	::POP STACK INTO R3
060640	012603				MOV (SP)+,R2	::POP STACK INTO R2
060642	012602				MOV (SP)+,R1	::POP STACK INTO R1
060644	012601					

060646	012600			MOV	(SP)+,R0	::POP STACK INTO R0
060650	104401	060676		TYPE	\$DBLK	::NOW TYPE THE NUMBER
060654	016666	000002	000004	MOV	2(SP),4(SP)	::ADJUST THE STACK
060662	012616			MOV	(SP)+,(SP)	
060664	000002			RTI		::RETURN TO USER
060666	023420			\$DTBL:	10000.	
060670	001750				1000.	
060672	000144				100.	
060674	000012				10.	
060676				\$DBLK:	.BLKW 4	

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS   N              ;;CALL FOR TYPEOUT
*   .BYTE  N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE  M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS

```

```

*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC

```

```

*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON   N              ;;CALL FOR TYPEOUT

```

```

*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER

```

```

*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC   N              ;;CALL FOR TYPEOUT

```

```

060706 017646 000000
060712 116637 000001 061131
060720 112637 061133
060724 062716 000002
060730 000406
060732 112737 000001 061131
060740 112737 000006 061133
060746 112737 000005 061130
060754 010346
060756 010446
060760 010546
060762 113704 061133
060766 005404
060770 062704 000006
060774 110437 061132
061000 113704 061131
061004 016605 000012
061010 005003
061012 006105 1$: ROL R5
061014 000404 BR 3$
061016 006105 2$: ROL R5
061020 006105 ROL R5
061022 006105 ROL R5
061024 010503 MOV R5,R3
061026 006103 3$: ROL R3
061030 105337 061132 DECB $OMODE
061034 100016 BPL 7$
061036 042703 177770 BIC #177770,R3
061042 001002 BNE 4$
061044 005704 TST R4
061046 001403 BEQ 5$
061050 005204 4$: INC R4

```

```

$TYPOS: MOV @ (SP),-(SP) ;;PICKUP THE MODE
MOV B 1(SP),$OFILL ;;LOAD ZERO FILL SWITCH
MOV B (SP)+,$OMODE+1 ;;NUMBER OF DIGITS TO TYPE
ADD #2,(SP) ;;ADJUST RETURN ADDRESS
BR $TYPON
$TYPOC: MOV B #1,$OFILL ;;SET THE ZERO FILL SWITCH
MOV B #6,$OMODE+1 ;;SET FOR SIX(6) DIGITS
$TYPON: MOV B #5,$OCNT ;;SET THE ITERATION COUNT
MOV R3,-(SP) ;;SAVE R3
MOV R4,-(SP) ;;SAVE R4
MOV R5,-(SP) ;;SAVE R5
MOV B $OMODE+1,R4 ;;GET THE NUMBER OF DIGITS TO TYPE
NEG R4
ADD #6,R4 ;;SUBTRACT IT FOR MAX. ALLOWED
MOV B R4,$OMODE ;;SAVE IT FOR USE
MOV B $OFILL,R4 ;;GET THE ZERO FILL SWITCH
MOV 12(SP),R5 ;;PICKUP THE INPUT NUMBER
CLR R3 ;;CLEAR THE OUTPUT WORD
1$: ROL R5 ;;ROTATE MSB INTO 'C'
BR 3$ ;;GO DO MSB
2$: ROL R5 ;;FORM THIS DIGIT
ROL R5
MOV R5,R3
3$: ROL R3 ;;GET LSB OF THIS DIGIT
DECB $OMODE ;;TYPE TH'S DIGIT?
BPL 7$ ;;BR IF " "
BIC #177770,R3 ;;GET R OF JUNK
BNE 4$ ;;TEST FOR 0
TST R4 ;;SUPPRESS THIS 0?
BEQ 5$ ;;BR IF YES
4$: INC R4 ;;DON'T SUPPRESS ANYMORE 0'S

```

061052	052703	000060		BIS	#'0,R3	::MAKE THIS DIGIT ASCII
061056	052703	000040	5\$:	BIS	#',R3	::MAKE ASCII IF NOT ALREADY
061062	110337	061126		MOVB	R3,8\$::SAVE FOR TYPING
061066	104401	061126		TYPE	8\$::GO TYPE THIS DIGIT
061072	105337	061130	7\$:	DECB	\$OCNT	::COUNT BY 1
061076	003347			BGT	2\$::BR IF MORE TO DO
061100	002402			BLT	6\$::BR IF DONE
061102	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
061104	000744			BR	2\$::GO DO THE LAST DIGIT
061106	012605		6\$:	MOV	(SP)+,R5	::RESTORE R5
061110	012604			MOV	(SP)+,R4	::RESTORE R4
061112	012603			MOV	(SP)+,R3	::RESTORE R3
061114	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
061122	012616			MOV	(SP)+,(SP)	
061124	000002			RTI		::RETURN
061126	000		8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
061127	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
061130	000		\$OCNT:	.BYTE	0	::OCTAL DIGIT COUNTER
061131	000		\$OFILL:	.BYTE	0	::ZERO FILL SWITCH
061132	000000		\$OMODE:	.WORD	0	::NUMBER OF DIGITS TO TYPE

.SBTTL TYPE ROUTINE

 *ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
 *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
 *NOTE1: \$NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
 *NOTE2: \$FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
 *NOTE3: \$FILLC CONTAINS THE CHARACTER TO FILL AFTER.

*CALL:
 *1) USING A TRAP INSTRUCTION
 * TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
 *OR
 * TYPE
 * MESADR

061134	105737	001173	\$TYPE:	TSTB	\$TPFLG	::IS THERE A TERMINAL?
061140	100002			BPL	1\$::BR IF YES
061142	000000			HALT		::HALT HERE IF NO TERMINAL
061144	000430			BR	3\$::LEAVE
061146	010046		1\$:	MOV	RO,-(SP)	::SAVE RO
061150	017600	000002		MOV	@2(SP),RO	::GET ADDRESS OF ASCIZ STRING
061154	122737	000001	001242	CMPB	#APTENV,\$ENV	::RUNNING IN APT MODE
061162	001011			BNE	62\$::NO,GO CHECK FOR APT CONSOLE
061164	132737	000100	001243	BITB	#APTPOOL,\$ENVM	::SPOOL MESSAGE TO APT
061172	001405			BEQ	62\$::NO,GO CHECK FOR CONSOLE
061174	010037	061204		MOV	RO,61\$::SETUP MESSAGE ADDRESS FOR APT
061200	004737	065546		JSR	PC,\$ATY3	::SPOOL MESSAGE TO APT
061204	000000		61\$:	.WORD	0	::MESSAGE ADDRESS
061206	132737	000040	001243	62\$:	BITB #APTCSUP,\$ENVM	::APT CONSOLE SUPPRESSED
061214	001003			BNE	60\$::YES,SKIP TYPE OUT
061216	112046		2\$:	MOVB	(RO)+,-(SP)	::PUSH CHARACTER TO BE TYPED ONTO STACK
061220	001005			BNE	4\$::BR IF IT ISN'T THE TERMINATOR
061222	005726			TST	(SP)+	::IF TERMINATOR POP IT OFF THE STACK
061224	012600		60\$:	MOV	(SP)+,RO	::RESTORE RO
061226	062716	000002	3\$:	ADD	#2,(SP)	::ADJUST RETURN PC
061232	000002			RTI		::RETURN
061234	122716	000011	4\$:	CMPB	#HT,(SP)	::BRANCH IF <HT>
061240	001430			BEQ	8\$	
061242	122716	000200		CMPB	#CRLF,(SP)	::BRANCH IF NOT <CRLF>
061246	001006			BNE	5\$	
061250	005726			TST	(SP)+	::POP <CR><LF> EQUIV
061252	104401			TYPE		::TYPE A CR AND LF
061254	001217			\$CRLF		
061256	105037	061464		CLRB	\$CHARCNT	::CLEAR CHARACTER COUNT
061262	000755			BR	2\$::GET NEXT CHARACTER
061264	004737	061346	5\$:	JSR	PC,\$TYPEC	::GO TYPE THIS CHARACTER
061270	123726	001172	6\$:	CMPB	\$FILLC,(SP)+	::IS IT TIME FOR FILLER CHARS.?
061274	001350			BNE	2\$::IF NO GO GET NEXT CHAR.
061276	013746	001170		MOV	\$NULL,-(SP)	::GET # OF FILLER CHARS. NEEDED
						::AND THE NULL CHAR.
061302	105366	000001	7\$:	DECB	1(SP)	::DOES A NULL NEED TO BE TYPED?
061306	002770			BLT	6\$::BR IF NO--GO POP THE NULL OFF OF STACK
061310	004737	061346		JSR	PC,\$TYPEC	::GO TYPE A NULL
061314	105337	061464		DECB	\$CHARCNT	::DO NOT COUNT AS A COUNT
061320	000770			BR	7\$::LOOP

:HORIZONTAL TAB PROCESSOR

061322	112716	000040		8\$:	MOVB	#' (SP)	::REPLACE TAB WITH SPACE
061326	004737	061346		9\$:	JSR	PC,\$TYPEC	::TYPE A SPACE
061332	132737	000007	061464		BITB	#7,\$CHARCNT	::BRANCH IF NOT AT
061340	001372				BNE	9\$::TAB STOP
061342	005726				TST	(SP)+	::POP SPACE OFF STACK
061344	000724				BR	2\$::GET NEXT CHARACTER
061346				\$TYPEC:			
061346	105777	117606			TSTB	@\$TKS	::CHAR IN KYBD BUFFER?
061352	100022				BPL	10\$::BR IF NOT
061354	017746	117602			MOV	@\$TKB, -(SP)	::GET CHAR
061360	042716	177600			BIC	#177600, (SP)	::STRIP EXTRANEIOUS BITS
061364	122716	000023			CMPB	#\$XOFF, (SP)	::WAS CHAR XOFF
061370	001012				BNE	102\$::BR IF NOT
061372				101\$:			
061372	105777	117562			TSTB	@\$TKS	::WAIT FOR CHAR
061376	100375				BPL	101\$	
061400	117716	117556			MOVB	@\$TKB, (SP)	::GET CHAR
061404	042716	177600			BIC	#177600, (SP)	::STRIP IT
061410	122716	000021			CMPB	#\$XON, (SP)	::WAS IT XON?
061414	001366				BNE	101\$::BR IF NOT
061416				102\$:			
061416	005726				TST	(SP)+	::FIX STACK
061420				10\$:			
061420	105777	117540			TSTB	@\$TPS	::WAIT UNTIL PRINTER IS READY
061424	100375				BPL	10\$	
061426	116677	000002	117532		MOVB	2(SP), @\$TPB	::LOAD CHAR TO BE TYPED INTO DATA REG.
061434	122766	000015	000002		CMPB	#CR, 2(SP)	::IS CHARACTER A CARRIAGE RETURN?
061442	001003				BNE	1\$::BRANCH IF NO
061444	105037	061464			CLRB	\$CHARCNT	::YES--CLEAR CHARACTER COUNT
061450	000406				BR	\$TYPEX	::EXIT
061452	122766	000012	000002	1\$:	CMPB	#LF, 2(SP)	::IS CHARACTER A LINE FEED?
061460	001402				BEQ	\$TYPEX	::BRANCH IF YES
061462	105227				INCB	(PC)+	::COUNT THE CHARACTER
061464	000000			\$CHARCNT:	WORD	0	::CHARACTER COUNT STORAGE
061466	000207			\$TYPEX:	RTS	PC	

.SBTTL SCOPE HANDLER ROUTINE

```

:*****
:*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
:*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
:*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
:*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
:*SW14=1      LOOP ON TEST
:*SW11=1      INHIBIT ITERATIONS
:*SW09=1      LOOP ON ERROR
:*SW08=1      LOOP ON TEST IN SWR<7:0>
:*CALL
:*          SCOPE          ;;SCOPE=IOT
    
```

```

061470          $SCOPE:          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
061470 104410          JSR          PC,STOP
061472 004737 062222          BIT          #BIT14,@SWR          ;;LOOP ON PRESENT TEST?
061476 032777 040000 117450 1$:          BEQ          9$          ;;NO IF SW14=0
061504 001402          JMP          $OVER          ;;JUMP OVER SCOPE ROUTINE
061506 000137 062136
061512
9$:
:#####START OF CODE FOR THE XOR TESTER#####
061512 000416          $XTSTR: BR          6$          ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
:THIS INSTRUCTION TO A 'NOP' (NOP=240)
061514 013746 000004          MOV          @ERRVEC,-(SP)          ;;SAVE THE CONTENTS OF THE ERROR VECTOR
061520 012737 061540 000004          MOV          #5$,@ERRVEC          ;;SET FOR TIMEOUT
061526 005737 177060          TST          @#177060          ;;TIME OUT ON XOR?
061532 012637 000004          MOV          (SP)+,@ERRVEC          ;;RESTORE THE ERROR VECTOR
061536 000561          BR          $$VLAD          ;;GO TO THE NEXT TEST
061540 022626          5$:          CMP          (SP)+,(SP)+          ;;CLEAR THE STACK AFTER A TIME OUT
061542 012637 000004          MOV          (SP)+,@ERRVEC          ;;RESTORE THE ERROR VECTOR
061546 000521          BR          7$          ;;LOOP ON THE PRESENT TEST
061550
6$:;#####END OF CODE FOR THE XOR TESTER#####
061550 032777 000400 117376          BIT          #BIT08,@SWR          ;;LOOP ON SPEC. TEST?
061556 001421          BEQ          2$          ;;BR IF NO
061560 005046          CLR          -(SP)          ;;CLEAR A TEMP. LOCATION
061562 117716 117366          MOVB         @SWR,(SP)          ;;PICKUP THE DESIRED TEST NUMBER
061566 001414          BEQ          8$          ;;BRANCH IF BAD TEST NUMBER IN SWR
061570 022716 000023          CMP          #23,(SP)          ;;CHECK THE NUMBER IN THE SWR
061574 002411          BLT          8$          ;;BRANCH IF TEST NUMBER IS OUT OF RANGE
061576 011637 001116          MOV          (SP),$TSTNM          ;;UPDATE THE TEST NUMBER
061602 005316          DEC          (SP)          ;;BACKUP BY ONE
061604 006316          ASL          (SP)          ;;SCALE THE TEST NUMBER AS AN INDEX
061606 062716 062154          ADD          #$$SW08TBL,(SP)          ;;FORM THE ADDRESS OF TEST POINTER
061612 013637 001122          MOV          @(SP)+,$LPADR          ;;SET LOOP ADDRESS TO DESIRED TEST
061616 000547          BR          $OVER          ;;GO LOOP ON THE TEST
061620 005726          8$:          TST          (SP)+          ;;CLEAN THE BAD TEST NUMBER OFF OF THE STACK
061622 105737 001117          2$:          TSTB         $ERFLG          ;;HAS AN ERROR OCCURRED?
061626 001502          BEQ          3$          ;;BR IF NO
061630 022737 177777 062640          CMP          #-1,CPSAVE          ;;SEE IF TIMEOUT WAS PREVIOUSLY RECORDED
061636 001455          BEQ          2003$          ;;KICK AROUND ROUTINE IF SO
061640 013746 000004          MOV          ERRVEC,-(SP)          ;;SAVE CONTENTS OF ERROR VECTOR
061644 012737 061662 000004          MOV          #2000$,ERRVEC          ;;SETUP 'TRAP' RETURN ADDRESS
061652 013737 177766 062640          MOV          177766,CPSAVE          ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
061660 000406          BR          2001$
061662 012737 177777 062640 2000$:          MOV          #-1,CPSAVE          ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
061670 012716 061676          MOV          #2001$,(SP)          ;;SETUP RETURN ADDRESS
    
```



```

061674 000002          RTI
061676 012637 000004    2001$: MOV      (SP)+,ERRVEC    ;;RESTORE CONTENTS OF ERROR VECTOR

061702 022737 177777 062640 2002$: CMP      #-1,CPSAVE    ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
061710 001430          BEQ      2003$        ;;BRANCH IF SO
061712 032737 000001 062640    BIT      #BIT00,CPSAVE  ;;SEE IF THE POWER MONITOR BIT IS ON
061720 001424          BEQ      2003$        ;;BRANCH TO CONTINUE ROUTINE IF CLEAR
061722 042737 000001 177766    BIC      #BIT00,177766 ;;CLEAR THE BIT FOUND TO BE SET
061730 013746 001154          MOV      SWR,-(SP)     ;;SAVE SWR ADDRESS
061734 017646 000000          MOV      @ (SP),-(SP)  ;;SAVE SWR VALUE
061740 012737 000176 001154    MOV      #176,SWR     ;;GET SOFTWARE SWR ADDRESS
061746 011677 117202          MOV      (SP),@SWR    ;;GET CURRENT SWR VALUE
061752 042777 001000 117174    BIC      #BIT09,@SWR  ;;DON'T ALLOW LOOP ON ERROR ON THIS ERROR
061760 104177          EMT      177        ;;CALL SPECIAL POWER FAIL BIT ERROR CALL
061762 012676 000000          MOV      (SP)+,@(SP)  ;;RESTORE SWR TO ORIGINAL VALUE
061766 012637 001154          MOV      (SP)+,SWR   ;;RESTORE SWR ADDRESS
061772          2003$:
061772 123737 001131 001117    CMPB    $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?
062000 101015          BHI      3$          ;;BR IF NO
062002 032777 001000 117144    BIT      #BIT09,@SWR  ;;LOOP ON ERROR?
062010 001404          BEQ      4$          ;;BR IF NO
062012 013737 001124 001122    7$: MOV      $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
062020 000446          BR       $OVER
062022 105037 001117          4$: CLRB    $ERFLG     ;;ZERO THE ERROR FLAG
062026 005037 001206          CLR     $TIMES      ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
062032 000415          BR       1$        ;;ESCAPE TO THE NEXT TEST
062034 032777 004000 117112    3$: BIT      #BIT11,@SWR  ;;INHIBIT ITERATIONS?
062042 001011          BNE     1$          ;;BR IF YES
062044 005737 001230          TST    $PASS       ;;IF FIRST PASS OF PROGRAM
062050 001406          BEQ    1$          ;;INHIBIT ITERATIONS
062052 005237 001120          INC    $ICNT      ;;INCREMENT ITERATION COUNT
062056 023737 001206 001120    CMP    $TIMES,$ICNT  ;;CHECK THE NUMBER OF ITERATIONS MADE
062064 002024          BGE    $OVER      ;;BR IF MORE ITERATION REQUIRED
062066 012737 000001 001120    1$: MOV    #1,$ICNT   ;;REINITIALIZE THE ITERATION COUNTER
062074 013737 062152 001206    MOV    $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
062102 105237 001116          $SVLAD: INCB   $TSTNM  ;;COUNT TEST NUMBERS
062106 113737 001116 001226    MOVB   $TSTNM,$TESTN ;;SET TEST NUMBER IN APT MAILBOX
062114 011637 001122          MOV    (SP),$LPADR  ;;SAVE SCOPE LOOP ADDRESS
062120 011637 001124          MOV    (SP),$LPERR  ;;SAVE ERROR LOOP ADDRESS
062124 005037 001210          CLR    $ESCAPE     ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
062130 112737 000001 001131    MOVB   #1,$ERMAX    ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
062136 013777 001116 117012    $OVER: MOV    $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER
062144 013716 001122          MOV    $LPADR,(SP) ;;FUDGE RETURN ADDRESS
062150 000002          RTI
062152 000005          $MXCNT: 5.        ;;FIXES PS
062154          $SWO8TBL:  ;;MAX. NUMBER OF ITERATIONS
                                .REPT $TN-1
062154 007700          .WORD  TST1+2     ;;STARTING ADDRESS OF TEST 1
062156 010100          .WORD  TST2+2     ;;STARTING ADDRESS OF TEST 2
062160 011106          .WORD  TST3+2     ;;STARTING ADDRESS OF TEST 3
062162 012064          .WORD  TST4+2     ;;STARTING ADDRESS OF TEST 4
062164 013260          .WORD  TST5+2     ;;STARTING ADDRESS OF TEST 5
062166 014266          .WORD  TST6+2     ;;STARTING ADDRESS OF TEST 6
062170 015244          .WORD  TST7+2     ;;STARTING ADDRESS OF TEST 7
062172 016442          .WORD  TST10+2    ;;STARTING ADDRESS OF TEST 10
062174 017470          .WORD  TST11+2   ;;STARTING ADDRESS OF TEST 11
062176 020714          .WORD  TST12+2   ;;STARTING ADDRESS OF TEST 12

```

062200	021736		.WORD	TST13+2	::STARTING ADDRESS OF TEST 13
062202	022550		.WORD	TST14+2	::STARTING ADDRESS OF TEST 14
062204	024420		.WORD	TST15+2	::STARTING ADDRESS OF TEST 15
062206	025722		.WORD	TST16+2	::STARTING ADDRESS OF TEST 16
062210	026742		.WORD	TST17+2	::STARTING ADDRESS OF TEST 17
062212	027660		.WORD	TST20+2	::STARTING ADDRESS OF TEST 20
062214	030666		.WORD	TST21+2	::STARTING ADDRESS OF TEST 21
062216	031714		.WORD	TST22+2	::STARTING ADDRESS OF TEST 22
062220	033076		.WORD	TST23+2	::STARTING ADDRESS OF TEST 23
2					
3					
4					
5	062222				
	062222	012746	000140	STOP:	
	062226	012746	062234	MOV	#PR3,-(SP) ::PUT NEW PS ON STACK
	062232	000002		MOV	#64\$,-(SP) ::PUT NEW PC ON STACK
	062234			RTI	::POP NEW PC AND PS
6				64\$:	
7					
8					
9	062234	012746	000240		
	062240	012746	062246	MOV	#PR5,-(SP) ::PUT NEW PS ON STACK
	062244	000002		MOV	#65\$,-(SP) ::PUT NEW PC ON STACK
	062246			RTI	::POP NEW PC AND PS
10	062246	000207		65\$:	
				RTS	PC :RETURN

1

.SBTTL ERROR HANDLER ROUTINE

```

:*****
:*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
:*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
:*AND GO TO ERRTP ON ERROR
:*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
:*SW15=1      HALT ON ERROR
:*SW13=1      INHIBIT ERROR TYPEOUTS
:*SW10=1      BELL ON ERROR
:*SW09=1      LOOP ON ERROR
:*CALL
:*          ERROR      N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
    
```

```

062250 105037 062642 $ERROR. CLR      IBSAVE      ;;CLEAR THE ITEM BYTE SAVE LOCATION
062254 104710          CKSWR      ;;TEST FOR CHANGE IN SOFT-SWR
062256 105237 001117 7$:      INCB      SERFLG      ;;SET THE ERROR FLAG
062262 001775          BEQ      7$      ;;DON'T LET THE FLAG GO TO ZERO
062264 013777 001116 116664     MOV      $STNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
062272 032777 002000 116654     BIT      #BIT10,@SWR    ;;BELL ON ERROR?
062300 001402          BEQ      1$      ;;NO - SKIP
062302 104401 001212          TYPE     .SBELL      ;;RING BELL
062306 005237 001126 1$:      INC      $ERTTL     ;;COUNT THE NUMBER OF ERRORS
062312 011637 001132          MOV      (SP),$ERRPC  ;;GET ADDRESS OF ERROR INSTRUCTION
062316 162737 00000? 001132     SUB      #2,$ERRPC
062324 117737 116602 001130     MOV      @ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
062332 032777 001000 116614     BIT      #BIT09,@SWR    ;;SEE IF LOOP ON ERROR IS SET
062340 001060          BNE      1004$     ;;BRANCH AROUND ROUTINE IF SO
062342 122737 000177 001130     CMP      #177,$ITEMB   ;;SEE IF THIS IS THE POWER FAIL CALL
062350 001454          BEQ      1004$     ;;BRANCH AROUND ROUTINE IF IT IS
062352 105737 J62642          TSTB     IBSAVE      ;;SEE IF THIS IS THE 2ND ERROR CALL IN THIS ROUTINE
062356 001047          BNE      1003$     ;;BRANCH IF SO
062360 022737 177777 062640     CMP      #-1,CPSAVE    ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
062366 001445          BEQ      1004$     ;;BRANCH IF SO
062370 013746 000004          MOV      ERRVEC,-(SP)  ;;SAVE CONTENTS OF ERROR VECTOR
062374 012737 062412 000004     MOV      #1000$,ERRVEC ;;SETUP 'TRAP' RETURN ADDRESS
062402 013737 177766 062640     MOV      177766,CPSAVE ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
062410 000406          BR      1001$
062412 012737 177777 062640 1000$: MOV      #-1,CPSAVE    ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
062420 012716 062426          MOV      #1001$, (SP)  ;;SETUP RETURN ADDRESS
062424 000002          RTI
062426 012637 000004 1001$: MOV      (SP)+,ERRVEC  ;;RESTORE CONTENTS OF ERROR VECTOR

062432 022737 177777 062640 1002$: CMP      #-1,CPSAVE    ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
062440 001420          BEQ      1004$     ;;BRANCH IF SO
062442 032737 000001 062640     BIT      #BIT00,CPSAVE ;;SEE IF POWER MONITOR BIT IS SET IN CPU ERR REG
062450 001414          BEQ      1004$     ;;BRANCH IF OK
062452 042737 000001 177766     BIC      #BIT00,177766 ;;CLEAR THE BIT FOUND SET
062460 113737 001130 062642     MOV      $ITEMB,IBSAVE ;;MAKE IBSAVE NON-ZERO FOR DUAL ERROR CALL
062466 112737 000177 001130     MOV      #177,$ITEMB  ;;SET $ITEMB TO SPECIAL POWER FAIL POINTER
062474 000402          BR      1004$     ;;BRANCH OVER IBSAVE CLEARING

062476 105037 062642 1003$: CLR      IBSAVE      ;;CLEAR IBSAVE SO 2ND TIME THROUGH EXITS
062502 032777 020000 116444 1004$: BIT      #BIT13,@SWR  ;;SKIP TYPEOUT IF SET
062510 001004          BNE      20$      ;;SKIP TYPEOUTS
062512 004737 062644          JSR      PC,ERRTP    ;;GO TO USER ERROR ROUTINE
    
```

062516	104401	001217		TYPE	,\$CRLF	
062522			20\$:			
062522	122737	000001	001242	CMPB	#APTENV,\$ENV	::RUNNING IN APT MODE
062530	001007			BNE	2\$::NO SKIP APT ERRGR REPORT
062532	113737	001130	062544	MOVB	\$ITEMB,21\$::SET ITEM NUMBER AS ERROR NUMBER
062540	004737	065556		JSR	PC,\$ATY4	::REPORT FATAL ERROR TO APT
062544	000		21\$:	.BYTE	0	
062545	000			.BYTE	0	
062546	000777		22\$:	BR	22\$::APT ERROR LOOP
062550	105737	062642	2\$:	TSTB	IBSAVE	::SEE IF IBSAVE IS LOADED
062554	001005			BNE	3\$::BRANCH IF NOT - NO HALT ON PWR MON BIT ERROR
062556	005777	116372		TST	@SWR	::HALT ON ERROR
062562	100002			BPL	3\$::SKIP IF CONTINUE
062564	000000			HALT		::HALT ON ERROR!
062566	104410			CKSWR		::TEST FOR CHANGE IN SOFT-SWR
062570			3\$:			
062570	032777	001000	116356	BIT	#BIT09,@SWR	::LOOP ON ERROR SWITCH SET?
062576	001402			BEQ	4\$::BR IF NO
062600	013716	001124		MOV	\$LPERR,(SP)	::FUDGE RETURN FOR LOOPING
062604	005737	001210	4\$:	TST	\$ESCAPE	::CHECK FOR AN ESCAPE ADDRESS
062610	001402			BEQ	5\$::BR IF NONE
062612	013716	001210		MOV	\$ESCAPE,(SP)	::FUDGE RETURN ADDRESS FOR ESCAPE
062616			5\$:			
062616	022737	033756	000042	CMP	#SENDAD,@#42	::ACT-11 AUTO-ACCEPT?
062624	001001			BNE	6\$::BRANCH IF NO
062626	000000			HALT		::YES
062630			6\$:			
062630	105737	062642		TSTB	IBSAVE	::SEE IF ITEM BYTE SAVE LOCATION HAS AN ERROR CALL
062634	001210			BNE	7\$::BRANCH BACK TO CALL ORIGINAL ERROR
062636	000002			RTI		::RETURN
062640	000000			CPSAVE:	.WORD 0	::LOCATION TO SAVE CPU ERROR REG CONTENTS
062642	000000			IBSAVE:	.WORD 0	::LOCATION TO SAVE ITEM BYTE

.SBTTL ERROR TYPEOUT ROUTINE

```

: *THE ERROR TYPEOUT ROUTINE ASSEMBLES AND PRINTS INFORMATION
: *REGARDING THE DETECTION OF AN ERROR AS FOLLOWS:
: *
: * .UNIT NUMBER, DRIVE TYPE, TEST NUMBER, ERROR NUMBER AND
: * PROGRAM COUNTER ARE PRINTED ON THE FIRST LINE;
: * .ERROR MESSAGE IS ASSEMBLED, FORMATTED AND PRINTED ON
: * ONE OR MORE SUCCEEDING LINES;
: * .PAIRED LINES OF ERROR HEADERS AND ERROR DATA ARE PRINTED
: * AFTER THE ERROR MESSAGE.
    
```

```

2
3
4
5
6
7
8
9
10
11
12
13 062644 104414
14 062646 032777 020000 116300
15 062654 001402
16 062656 000137 063454
17
18
19
20 062662 104401 001217
21 062666 104401 063470
22 062672 013746 001234
    062676 104403
    062700 003
    062701 000
23
24
25 062702 013700 001276
26 062706 016000 000026
27 062712 042700 177740
28 062716 012737 067062 062740
29 062724 022700 000026
30 062730 001004
31 062732 104401 063525
32 062736 104401
33 062740 000600
34
35
36 062742 005037 063460
37 062746 013737 001226 063460
38 062754 104401 063475
39 062760 013746 063460
    062764 104403
    062766 003
    062767 000
40 062770 005037 063462
41 062774 113737 001130 063462
42 063002 001406
43 063004 104401 063505
44 063010 013746 063462
    063014 104403
    063016 003
    063017 000
45 063020 104401 063514
    
```

```

ERRTYP: SAVREG
BIT #SW13,@SWR ;INHIBIT TYPEOUTS??
BEQ 1$ ;NO!!
JMP 27$ ;YES!!

:TYPE UNIT NUMBER, DRIVE TYPE, TEST NUMBER, ERROR NUMBER, AND
:PROGRAM COUNTER
1$: TYPE ,SCRLF ;TYPE 'DRV#'
TYPE ,ERTY00 ;:SAVE $UNIT FOR TYPEOUT
MOV $UNIT,-(SP) ;:TYPE DRIVE NUMBER
;:GO TYPE--OCTAL ASCII
;:TYPE 3 DIGIT(S)
;:SUPPRESS LEADING ZEROS
TYPOS
.BYTE 3
.BYTE 0

:TYPE 'DRIVE TYPE', RM80 FOR UNIT UNDER TEST
MOV $BASE,R0 ;GET RM BASE ADDRESS
MOV RMDT(R0),R0 ;GET DRIVE TYPE REGISTER
BIC #177740,R0 ;SAVE DRIVE TYPE BITS AND
MOV #SRM80,3$ ;GET ASCII DRIVE TYPE
CMP #26,R0 ;IS DEVICE AN RM80 ?
BNE 4$ ;NO !!
2$: TYPE ,ERTY05 ;TYPE " - "
TYPE ;TYPE DRIVE TYPE
3$: .WORD 0 ;DRIVE TYPE MESSAGE IS STORED HERE

:TYPE TEST NUMBER, ERROR NUMBER AND PROGRAM COUNTER
4$: CLR TSTNMB ;LOAD TEST NUMBER FOR
MOV $TESTN,TSTNMB ;TYPE 'TST#'
TYPE ,ERTY01 ;:SAVE TSTNMB FOR TYPEOUT
MOV TSTNMB,-(SP) ;:TYPE TEST NUMBER
;:GO TYPE--OCTAL ASCII
;:TYPE 3 DIGIT(S)
;:SUPPRESS LEADING ZEROS
CLR ERRNMB ;LOAD ERROR NUMBER FOR
MOVB $ITEMB,ERRNMB ;TYPEOUT
BEQ 5$ ;SKIP IF NO ERROR CALLED
TYPE ,ERTY02 ;TYPE 'ERR#'
MOV ERRNMB,-(SP) ;SAVE ERRNMB FOR TYPEOUT
;TYPE ERROR NUMBER
;GO TYPE--OCTAL ASCII
;TYPE 3 DIGIT(S)
;SUPPRESS LEADING ZEROS
5$: TYPE ,ERTY03 ;TYPE 'PC='
    
```

```

46 063024 013746 001132      MOV      $ERRPC,-(SP)      ;;SAVE $ERRPC FOR TYPEOUT
                                ;;TYPE PROGRAM COUNTER
                                ;;GO TYPE--OCTAL ASCII
063030 104403      TYPOS
063032 006        .BYTE      6            ;;TYPE 6 DIGIT(S)
063033 001        .BYTE      1            ;;TYPE LEADING ZEROS
47
48      ;GENERATE POINTER TO ERROR TABLE UNLESS ERROR NUMBER IS 0
49 063034 005737 063462      6$:      TST      ERRNMB      ;WAS AN ERROR CALLED?
50 063040 001002      BNE      7$              ;BR IF YES
51 063042 000137 063454      JMP      27$            ;NO--EXIT
52
53 063046 104401 001217      7$:      TYPE      , $CRLF      ;YES-TYPE CRLF
54 063052 105037 063466      CLR      BOTFLG        ;CLEAR BOT FLAG
55 063056 105037 063467      CLR      CHRCNT        ;CLEAR CHARACTER COUNTER
56 063062 013700 063462      MOV      ERRNMB,R0      ;R0 POINTS TO FIRST OF
57 063066 122700 000177      CMPB     #177,R0        ;SEE IF THIS ERROR CALL IS SPECIAL POWER FAIL CALL
58 063072 001003      BNE      8$              ;BRANCH IF NOT
59 063074 012700 063532      MOV      #PFECH,R0      ;MOVE POWER FAIL ERROR CALL TABLE TO R0
60 063100 000405      BR
61 063102 006300      8$:      ASL      R0              ;FOUR ENTRIES IN ERROR
62 063104 006300      ASL      R0              ;TABLE
63 063106 006300      ASL      R0
64 063110 062700 001574      ADD      # $ERRTB-8.,R0
65 063114 011001      9$:      MOV      (R0),R1        ;R1 POINTS TO ERROR MESSAGE
66
67 063116 001507      BEQ      19$            ;BRANCH IF NO ERROR MESSAGE
68
69      ;TYPE THE ERROR MESSAGE
70 063120 012102      10$:     MOV      (R1)+,R2      ;R2=ADDRESS OF MESSAGE STRING
71 063122 001505      BEQ      19$            ;BRANCH IF END OF MESSAGE
72 063124 010237 063272      MOV      R2,18$         ;LOAD ADDRESS OF STRING
73 063130 005037 063464      CLR      BOTADR        ;CLEAR BOT ADDRESS
74 063134 112203      11$:     MOV      (R2)+,R3        ;END OF STRING??
75 063136 001454      BEQ      17$            ;YES!!
76 063140 122703 000015      CMPB     #CR,R3         ;CARRIAGE RETURN??
77 063144 001003      BNE      12$            ;NO!!
78 063146 105037 063467      CLR      CHRCNT        ;YES-CLEAR CHAR COUNT
79 063152 000770      BR              ;GET NEXT CHARACTER
80 063154 122703 000012      12$:     CMPB     #LF,R3         ;LINE FEED??
81 063160 001765      BEQ      11$            ;YES-GET NEXT CHARACTER
82 063162 122703 000011      CMPB     #HT,R3         ;HORIZONTAL TAB??
83 063166 001007      BNE      14$            ;NO!!
84 063170 105237 063467      13$:     INCB     CHRCNT        ;ADJUST CHARACTER COUNT
85 063174 132737 000007 063467      BITB     #7,CHRCNT
86 063202 001372      BNE      13$
87 063204 000407      BR              ;
88 063206 105237 063467      14$:     INCB     CHRCNT        ;INCREMENT CHARACTER COUNT
89 063212 122703 000040      CMPB     #' ,R3         ;SPACE??
90 063216 001002      BNE      15$            ;NO!!
91 063220 010237 063464      MOV      R2,BOTADR      ;SAVE ADDRESS OF SPACE
92 063224 122737 000100 063467      15$:     CMPB     #64.,CHRCNT    ;END OF LINE??
93 063232 103340      BHS      11$            ;NO!!
94 063234 013704 063464      MOV      BOTADR,R4      ;GET ADDRESS OF LAST SPACE
95 063240 001007      BNE      16$            ;BRANCH IF SPACE DETECTED
96 063242 104401 001217      TYPE      , $CRLF      ;TYPE CRLF
97 063246 105037 063467      CLR      CHRCNT        ;CLEAR CHARACTER COUNT
98 063252 013702 063272      MOV      18$,R2        ;SET UP R2 FOR TESTING
    
```

```

99 063256 000726 BR 11$
100 063260 105044 16$: CLRB -(R4) ;REPLACE SPACE
101 063262 112737 177777 063466 MOVB #-1,BOTFLG ;SET BOT FLAG
102 063270 104401 17$: TYPE ;TYPE ERROR MESSAGE STRING
103 063272 000000 18$: .WORD ;STRING ADDRESS GOES HERE
104 063274 105737 063466 TSTB BOTFLG ;WAS STRING TRUNCATED??
105 063300 001707 BEQ 10$ ;NO!!
106 063302 104401 001217 TYPE ,SCRLF ;YES-TYPE CRLF
107 063306 105037 063466 CLRB BOTFLG ;CLEAR BOT FLAG
108 063312 105037 063467 CLRB CHRCNT ;CLEAR CHARACTER COUNT
109 063316 013702 063464 MOV BOTADR,R2 ;SETUP R2 FOR TESTING
110 063322 010237 063272 MOV R2,18$ ;SETUP 18$ FOR TYPING
111 063326 112742 000040 MOVB #'-(R2) ;RESTORE SPACE
112 063332 105722 TSTB (R2)+ ;RESTORE R2
113 063334 000677 BR 11$ ;TYPE REST OF STRING
114
115 ;TYPE ERROR HEADER AND ERROR DATA
116 063336 016001 000002 19$: MOV 2(R0),R1 ;R1 POINTS TO ERROR HEADER TABLE
117 063342 001444 BEQ 27$ ;BRANCH IF NO HEADER
118 063344 104401 001217 TYPE ,SCRLF ;(ASSUME NO DATA)
119 063350 016002 000004 MOV 4(R0),R2 ;R2 POINTS TO DATA ADDRESS TABLE
120 063354 016003 000006 MOV 6(R0),R3 ;R3 POINTS TO FORMAT TABLE
121 063360 012137 063370 20$: MOV (R1)+,21$ ;PUT HEADER ADDRESS FOR TYPE
122 063364 001433 BEQ 27$ ;BRANCH IF END OF HEADERS
123 ;(ASSUME END OF DATA)
124 063366 104401 TYPE
125 063370 000000 21$: .WORD 0 ;HEADER ADDRESS GOES HERE
126 063372 104401 001217 TYPE ,SCRLF
127 063376 005702 TST R2 ;DATA WITH HEADER??
128 063400 001767 BEQ 20$ ;NO!!
129 063402 012204 MOV (R2)+,R4 ;R4 POINTS TO DATA ADDRESS
130 063404 012305 MOV (R3)+,R5 ;R5 POINTS TO FORMAT
131 063406 105725 22$: TSTB (R5)+ ;WHAT KIND OF DATA??
132 063410 100407 BMI 24$ ;BINARY
133 063412 001403 BEQ 23$ ;OCTAL
134 063414 013446 MOV @ (R4)+,-(SP) ;DECIMAL
135 063416 104405 TYPDS
136 063420 000405 BR 25$
137 063422 013446 23$: MOV @ (R4)+,-(SP)
138 063424 104402 TYPOC
139 063426 000402 BR 25$
140 063430 013446 24$: MOV @ (R4)+,-(SP)
141 063432 104406 TYPBN
142 063434 005714 25$: TST (R4) ;MORE DATA??
143 063436 001403 BEQ 26$ ;NO!!
144 063440 104401 063522 TYPE ,ERTY04 ;YES-TYPE 2 SPACES
145 063444 000760 BR 22$ ;AND CONTINUE
146 063446 104401 001217 26$: TYPE ,SCRLF ;TYPE ONE BLANK LINE
147 063452 000742 BR 20$ ;BEFORE NEXT HEADER
148 063454 104415 27$: RESREG
149 063456 000207 RTS PC
150
151 063460 000000 TSTNMB: .WORD 0 ;TEST NUMBER
152 063462 000000 ERRNMB: .WORD 0 ;ERROR NUMBER
153 063464 000000 BOTADR: .WORD 0 ;BEGINNING OF TEXT ADDRESS
154 063466 000 BOTFLG: .BYTE 0 ;BOT FLAG
155 063467 000 CHRCNT: .BYTE 0 ;CHARACTER COUNT
    
```

156						
157	063470	104	122	126	ERTY00:	.ASCIZ @DRV#@
158	063475	054	040	124	ERTY01:	.ASCIZ @, TEST#@
159	063505	054	040	105	ERTY02:	.ASCIZ @, ERR#@
160	063514	054	040	120	ERTY03:	.ASCIZ @, PC=@
161	063522	040	040	000	ERTY04:	.ASCIZ @ @
162	063525	040	055	040	ERTY05:	.ASCIZ @ - @
163						.EVEN
164	063532	063542	063630	063646	PFEC:	PFEC1,PFEC2,PFEC3,PFEC4 ;WORDS DEFINING TABLES BELOW
165	063542	063546	000000		PFEC1:	+.4,0
166	063546	120	117	127		.ASCIZ ?POWER MONITOR BIT IN CPU ERROR REGISTER FOUND SET?
167						.EVEN
168	063630	063634	000000		PFEC2:	+.4,0
169	063634	103	120	125		.ASCIZ ?CPUERREG?
170						.EVEN
171	063646	063650			PFEC3:	+.2
172	063650	062640	000000			.WORD CPSAVE,0
173	063654	063656			PFEC4:	+.2
174	063656	000	000			.BYTE 0,0

1

.SBTTL TTY INPUT ROUTINE

063660 000000
 063662 000000
 063664 000000
 063666 063667

```

*****
ENABL LSB
$TKCNT: .WORD 0      ;;NUMBER OF ITEMS IN QUEUE
$TKQIN: .WORD 0      ;;INPUT POINTER
$TKQOUT: .WORD 0     ;;OUTPUT POINTER
$TKQSRV: .BLKB 1     ;;TTY KEYBOARD QUEUE
$TKQEND=.
.EVEN
  
```

```

;*TK INITIALIZE ROUTINE
;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
  
```

063670 005037 063660
 063674 012737 063666 063662
 063702 013737 063662 063664
 063710 012737 063740 000060
 063716 012737 000200 000062
 063724 005777 115232
 063730 012777 000100 115222
 063736 000207

```

;*CALL:
;*      JSR      PC,$TKINT
;*      RETURN
$TKINT: CLR      $TKCNT      ;;CLEAR COUNT OF ITEMS IN QUEUE
        MOV      # $TKQSRV,$TKQIN ;;MOVE THE STARTING ADDRESS OF THE
        MOV      $TKQIN,$TKQOUT ;;QUEUE INTO THE INPUT & OUTPUT POINTERS.
        MOV      # $TKSRV,$TKVEC ;;INITIALIZE THE KEYBOARD VECTOR
        MOV      #200,$TKVEC+2 ;;'BR' LEVEL 4
        TST      @ $TKB      ;;CLEAR DONE FLAG
        MOV      #100,$TKS     ;;ENABLE TTY KEYBOARD INTERRUPT
        RTS      PC         ;;RETURN TO CALLER
  
```

```

;*TK SERVICE ROUTINE
;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
;*IT IN THE QUEUE.
;*IF THE CHARACTER IS A "CONTROL-C" (^C) $TKINT IS CALLED AND
;*UPON RETURN EXIT IS MADE TO THE "CONTROL-C" RESTART ADDRESS (SHUT2)
  
```

063740 117746 115216
 063744 042716 177600
 063750 021627 000021
 063754 001002
 063756 005726
 063760 000002
 063762
 063762 021627 000003
 063766 001007
 063770 104401 065066
 063774 004737 063670
 064000 005726
 064002 000137 065130
 064006 021627 000007
 064012 001004
 064014 022737 000176 001154
 064022 001500
 064024
 064024 022737 000001 063660
 064032 001004
 064034 104401 001212

```

$TKSRV: MOVB    @ $TKB, -(SP) ;;PICKUP THE CHARACTER
        BIC     #^C177, (SP) ;;STRIP THE JUNK
        CMP     (SP), # $XON ;;IS IT A RANDOM XON?
        BNE    30$ ;;BRANCH IF NO
        TST    (SP)+ ;;CLEAN RANDOM XON OFF STACK
        RTI    ;;RETURN
30$:    CMP     (SP), #3 ;;IS IT A CONTROL C?
        BNE    1$ ;;BRANCH IF NO
        TYPE   ,SCNTLC ;;TYPE A CONTROL-C (^C)
        JSR    PC,$TKINT ;;INIT THE KEYBOARD
        TST    (SP)+ ;;CLEAN UP STACK
        JMP    SHUT2 ;;CONTROL C RESTART
1$:    CMP     (SP), #7 ;;IS IT A CONTROL G?
        BNE    2$ ;;BRANCH IF NO
        CMP    #SWREG,SWR ;;IS SOFT-SWR SELECTED?
        BEQ    6$ ;;GO TO SWR CHANGE
2$:    CMP     #1,$TKCNT ;;IS THE QUEUE FULL?
        BNE    3$ ;;BRANCH IF NO
        TYPE   ,SBELL ;;RING THE TTY BELL
  
```

```

064040 005726          TST      (SP)+      ;;CLEAN CHARACTER OFF OF STACK
064042 000451          BR       5$          ;;EXIT
064044 021627 000023  3$:    CMP      (SP),#23    ;;IS IT A CONTROL-S?
064050 001021          BNE     32$          ;;BRANCH IF NO
064052 005077 115102          CLR      @STKS      ;;DISABLE TTY KEYBOARD INTERRUPTS
064056 005726          TST      (SP)+      ;;CLEAN CHAR OFF STACK
064060 105777 115074  31$:    TSTB   @STKS      ;;WAIT FOR A CHAR
064064 100375          BPL     31$          ;;LOOP UNTIL ITS THERE
064066 117746 115070          MOVB   @STKB,-(SP)  ;;GET THE CHARACTER
064072 042716 177600          BIC     #'C177,(SP) ;;MAKE IT 7-BIT ASCII
064076 022627 000021          CMP      (SP)+,#21  ;;IS IT A CONTROL-Q?
064102 001366          BNE     31$          ;;BRANCH IF NO
064104 012777 000100 115046          MOV     #100,@STKS  ;;REENABLE TTY KEYBOARD INTERRUPTS
064112 000002          RTI                    ;;RETURN
064114 005237 063660  32$:    INC     $TKCNT      ;;COUNT THIS CHARACTER
064120 021627 000140          CMP      (SP),#140  ;;IS IT UPPER CASE?
064124 002405          BLT     4$          ;;BRANCH IF YES
064126 021627 000175          CMP      (SP),#175  ;;IS IT A SPECIAL CHAR?
064132 003002          BGT     4$          ;;BRANCH IF YES
064134 042716 000040          BIC     #40,(SP)    ;;MAKE IT UPPER CASE
064140 112677 177516  4$:    MOVB   (SP)+,@STKQIN ;;AND PUT IT IN QUEUE
064144 005237 063662          INC     $TKQIN      ;;UPDATE THE POINTER
064150 023727 063662 063667          CMP     $TKQIN,$STKQEND ;;GO OFF THE END?
064156 001003          BNE     5$          ;;BRANCH IF NO
064160 012737 063666 063662          MOV     #$STKQSRST,$STKQIN ;;RESET THE POINTER
064166 000002          5$:    RTI                    ;;RETURN

```

*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
*CALL WHEN OPERATING IN TTY INTERRUPT MODE.

```

064170 022737 000176 001154 $CKSWR: CMP     #SWREG,SWR    ;;IS THE SOFT-SWR SELECTED
064176 001124          BNE     15$          ;;EXIT IF NOT
064200 105777 114754          TSTB   @STKS      ;;IS A CHAR WAITING?
064204 100121          BPL     15$          ;;IF NOT, EXIT
064206 117746 114750          MOVB   @STKB,-(SP) ;;YES
064212 042716 177600          BIC     #'C177,(SP) ;;MAKE IT 7-BIT ASCII
064216 021627 000007          CMP     (SP),#7    ;;IS IT A CONTROL-G?
064222 001300          BNE     2$          ;;IF NOT, PUT IT IN THE TTY QUEUE
                                ;;AND EXIT

```

*CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
*ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
*CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.

```

064224 123727 001150 000001 6$:    CMPB   $AUTOB,#1    ;;ARE WE RUNNING IN AUTO-MODE?
064232 001674          BEQ     2$          ;;BRANCH IF YES
064234 005726          TST     (SP)+      ;;CLEAR CONTROL-G OFF STACK
064236 004737 063670          JSR    PC,$TKINT   ;;FLUSH THE TTY INPUT QUEUE
064242 005077 114712          CLR     @STKS      ;;DISABLE TTY KEYBOARD INTERRUPTS
064246 112737 000001 001151          MOVB   #1,$INTAG   ;;SET INTERRUPT MODE INDICATOR

064254 104401 065100          TYPE   ,SCNTLG     ;;ECHO THE CONTROL-G (^G)
064260 104401 065105          SGTSWR: TYPE   ,MSWR      ;;TYPE CURRENT CONTENTS
064264 013746 000176          MOV     SWREG,-(SP) ;;SAVE SWREG FOR TYPEOUT
064270 104402          TYPOC                ;;GO TYPE--OCTAL ASCII(ALL DIGITS)

```

064272	104401	065116		TYPE	.SMNEW	::PROMPT FOR NEW SWR
064276	005046		19\$:	CLR	-(SP)	::CLEAR COUNTER
064300	005046			CLR	-(SP)	::THE NEW SWR
064302	105777	114652	7\$:	TSTB	@STKS	::CHAR THERE?
064306	100375			BPL	7\$::IF NOT TRY AGAIN
064310	117746	114646		MOVB	@STKB, -(SP)	::PICK UP CHAR
064314	042716	177600		BIC	#^C177, (SP)	::MAKE IT 7-BIT ASCII
064320	021627	000003		CMP	(SP), #3	::IS IT A CONTROL-C?
064324	001015			BNE	9\$::BRANCH IF NOT
064326	104401	065066		TYPE	.SCNTLC	::YES, ECHO CONTROL-C (^C)
064332	062706	000006		ADD	#6, SP	::CLEAN UP STACK
064336	123727	001151	000001	CMPB	\$INTAG, #1	::REENABLE TTY KEYBOARD INTERRUPTS?
064344	001003			BNE	8\$::BRANCH IF NO
064346	012777	000100	114604	MOV	#100, @\$.KS	::ALLOW TTY KEYBOARD INTERRUPTS
064354	000137	065130	8\$:	JMP	SHUT2	::CONTROL-C RESTART
064360	021627	000025	9\$:	CMP	(SP), #25	::IS IT A CONTROL-U?
064364	001005			BNE	10\$::BRANCH IF NOT
064366	104401	065073		TYPE	.SCNTLU	::YES, ECHO CONTROL-U (^U)
064372	062706	000006	20\$:	ADD	#6, SP	::IGNORE PREVIOUS INPUT
064376	000737			BR	19\$::LET'S TRY IT AGAIN
064400	021627	000015	10\$:	CMP	(SP), #15	::IS IT A <CR>?
064404	001022			BNE	16\$::BRANCH IF NO
064406	005766	000004		TST	4(SP)	::YES, IS IT THE FIRST CHAR?
064412	001403			BEQ	11\$::BRANCH IF YES
064414	016677	000002	114532	MOV	2(SP), @SWR	::SAVE NEW SWR
064422	062706	000006	11\$:	ADD	#6, SP	::CLEAR UP STACK
064426	104401	001217	14\$:	TYPE	.SCRLF	::ECHO <CR> AND <LF>
064432	123727	001151	000001	CMPB	\$INTAG, #1	::RE-ENABLE TTY KBD INTERRUPTS?
064440	001003			BNE	15\$::BRANCH IF NOT
064442	012777	000100	114510	MOV	#100, @STKS	::RE-ENABLE TTY KBD INTERRUPTS
064450	000002		15\$:	RTI		::RETURN
064452	004737	061346	16\$:	JSR	PC, \$TYPEC	::ECHO CHAR
064456	021627	000060		CMP	(SP), #60	::CHAR < 0?
064462	002420			BLT	18\$::BRANCH IF YES
064464	021627	000067		CMP	(SP), #67	::CHAR > 7?
064470	003015			BGT	18\$::BRANCH IF YES
064472	042726	000060		BIC	#60, (SP)+	::STRIP-OFF ASCII
064476	005766	000002		TST	2(SP)	::IS THIS THE FIRST CHAR
064502	001403			BEQ	17\$::BRANCH IF YES
064504	006316			ASL	(SP)	::NO, SHIFT PRESENT
064506	006316			ASL	(SP)	::CHAR OVER TO MAKE
064510	006316			ASL	(SP)	::ROOM FOR NEW ONE.
064512	005266	000002	17\$:	INC	2(SP)	::KEEP COUNT OF CHAR
064516	056616	177776		BIS	-2(SP), (SP)	::SET IN NEW CHAR
064522	000667			BR	7\$::GET THE NEXT ONE
064524	104401	001216	18\$:	TYPE	.\$QUES	::TYPE ?<CR><LF>
064530	000720			BR	20\$::SIMULATE CONTROL-U
				.DSABL	LSB	

::*****

```

: *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
: *CALL:
: *      RDCHR          ::GET A CHARACTER FROM THE QUEUE
: *      RETURN HERE   ::CHARACTER IS ON THE STACK
: *                   ::WITH PARITY BIT STRIPPED OFF
:
064532 011646          SRDCHR: MOV      (SP),-(SP)      ::PUSH DOWN THE PC AND
064534 016656 000004 000002 MOV      4(SP),2(SP)  ::THE PS
064542 005066 000004          CLR      4(SP)          ::GET READY FOR A CHARACTER
064546 005046          CLR      -(SP)         ::PUT NEW PS ON STACK
064550 012746 064556          MOV      #64$,-(SP)      ::PUT NEW PC ON STACK
064554 000002          RTI                    ::POP NEW PC AND PS
064556
064556 005737 063660 64$:  TST      $TKCNT          ::WAIT ON A CHARACTER
064562 001775 1$:      BEQ      1$
064564 005337 063660          DEC      $TKCNT          ::DECREMENT THE COUNTER
064570 117766 177070 000004 MOVB    @$TKQOUT,4(SP) ::GET ONE CHARACTER
064576 005237 063664          INC      $TKQOUT        ::UPDATE THE POINTER
064602 023727 063664 063667 CMP     $TKQOUT,$$TKQEND ::DID IT GO OFF OF THE END?
064610 001003          BNE     2$
064612 012737 063666 063664 MOV     $$TKQRT,$$TKQOUT ::RESET THE POINTER
064620 000002          RTI                    ::RETURN
: *****
: *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
: *CALL:
: *      RDLIN          ::INPUT A STRING FROM THE TTY
: *      RETURN HERE   ::ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
: *                   ::TERMINATOR WILL BE A BYTE OF ALL 0'S
:
064622 010346          SRDLIN: MOV     R3, -(SP)      ::SAVE R3
064624 005046          CLR     -(SP)        ::CLEAR THE RUBOUT KEY
064626 012703 065056 1$:  MOV     $$TTYIN,R3      ::GET ADDRESS
064632 022703 065066 2$:  CMP     $$TTYIN+8.,R3  ::BUFFER FULL?
064636 101456          BLOS   4$
064640 104411          RDCHR          ::GO READ ONE CHARACTER FROM THE TTY
064642 112613          MOVB   (SP)+,(R3)     ::GET CHARACTER
064644 122713 000177 10$: CMPB   #177,(R3)      ::IS IT A RUBOUT
064650 001022          BNE   5$
064652 005716          TST   (SP)
064654 001007          BNE   6$
064656 112737 000134 065054 MOVB   #' \,9$        ::TYPE A BACK SLASH
064664 104401 065054          TYPE  ,9$
064670 012716 177777          MOV   #-1,(SP)      ::SET THE RUBOUT KEY
064674 005303 6$:      DEC     R3
064676 020327 065056          CMP   R3,$$TTYIN    ::BACKUP BY ONE
064702 103434          BLO   4$
064704 111337 065054          MOVB (R3),9$        ::STACK EMPTY?
064710 104401 065054          TYPE ,9$           ::BR IF YES
064714 000746          BR    2$            ::SETUP TO TYPEOUT THE DELETED CHAR.
064716 005716 5$:      TST   (SP)
064720 001406          BEQ   7$
064722 112737 000134 065054 MOVB   #' \,9$        ::GO TYPE
064730 104401 065054          TYPE ,9$           ::GO READ ANOTHER CHAR.
064734 005016          CLR   (SP)
064736 122713 000025 7$:  CMPB  #25,(R3)      ::RUBOUT KEY SET?
064742 001003          BNE  8$            ::BR IF NO
: *TYPE A BACK SLASH
: *CLEAR THE RUBOUT KEY
: *IS CHARACTER A CTRL U?
: *BR IF NO

```

064744	104401	065073			TYPE	SCNTLU	::TYPE A CONTROL 'U'	
064750	C00726				BR	1\$::GO START OVER	
064752	122713	000022	8\$:		CMPB	#22,(R3)	::IS CHARACTER A '^R'?	
064756	001011				BNE	3\$::BRANCH IF NO	
064760	105013				CLRB	(R3)	::CLEAR THE CHARACTER	
064762	104401	001217			TYPE	,\$SCLF	::TYPE A 'CR' & 'LF'	
064766	104401	065056			TYPE	,\$TTYIN	::TYPE THE INPUT STRING	
064772	000717				BR	2\$::GO PICKUP ANOTHER CHACTER	
064774	104401	001216	4\$:		TYPE	,\$QUES	::TYPE A '?'	
065000	000712				BR	1\$::CLEAR THE BUFFER AND LOOP	
065002	111337	065054	3\$:		MOVB	(R3),9\$::ECHO THE CHARACTER	
065006	104401	065054			TYPE	,\$9\$		
065012	122723	000015			CMPB	#15,(R3)+	::CHECK FOR RETURN	
065016	001305				BNE	2\$::LOOP IF NOT RETURN	
065020	105063	177777			CLRB	-1(R3)	::CLEAR RETURN (THE 15)	
065024	104401	001220			TYPE	,\$LF	::TYPE A LINE FEED	
065030	005726				TST	(SP)+	::CLEAN RUBOUT KEY FROM THE STACK	
065032	012603				MOV	(SP)+,R3	::RESTORE R3	
065034	011646				MOV	(SP),-(SP)	::ADJUST THE STACK AND PUT ADDRESS OF THE	
065036	016666	000004	000002		MOV	4(SP),2(SP)	::FIRST ASCII CHARACTER ON IT	
065044	012766	065056	000004		MOV	#\$TTYIN,4(SP)		
065052	000002				RTI		::RETURN	
065054	000			9\$:	.BYTE	0	::STORAGE FOR ASCII CHAR. TO TYPE	
065055	000				.BYTE	0	::TERMINATOR	
065056					,\$TTYIN:	.BLKB	8.	
065066	136	103	015		,\$CNTLC:	.ASCIZ	/^C/<15><12>	
065073	136	125	015		,\$CNTLU:	.ASCIZ	/^U/<15><12>	
065100	136	107	015		,\$CNTLG:	.ASCIZ	/^G/<15><12>	
065105	015	012	123		,\$MSWR:	.ASCIZ	<15><12>/SWR = /	
065116	040	040	116		,\$MNEW:	.ASCIZ	/ NEW = /	
					.EVEN			
2								
3	065130	012737	177777	001326	SHUT2:	MOV	#-1,CTFLG	::SET THE CONTROL-C FLAG
4	065136	105737	001116			TSTB	,\$STNM	::DOING ANY TESTS ?
5	065142	001002				BNE	1\$::BR IF YES
6	065144	000137	033776			JMP	SHUT	::NO--RESPOND TO ^C
7	065150	000002			1\$:	RTI		::EXIT FROM INTERRUPT

1

.SBTTL READ AN OCTAL NUMBER FROM THE TTY

```

:*****
:*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
:*CHANGE IT TO BINARY.
:*CALL:
:*      RDOCT          ::READ AN OCTAL NUMBER
:*      RETURN HERE   ::LOW ORDER BITS ARE ON TOP OF THE STACK
:*                   ::HIGH ORDER BITS ARE IN $HIOCT
  
```

```

065152 011646          SRDOCT: MOV      (SP),-(SP)      ::PROVIDE SPACE FOR THE
065154 016666 000004 000002  MOV      4(SP),2(SP)    ::INPUT NUMBER
065162 010046          MOV      R0,-(SP)      ::PUSH R0 ON STACK
065164 010146          MOV      R1,-(SP)      ::PUSH R1 ON STACK
065166 010246          MOV      R2,-(SP)      ::PUSH R2 ON STACK
065170 104412          1$:  RDLIN                    ::READ AN ASCII LINE
065172 012600          MOV      (SP)+,R0        ::GET ADDRESS OF 1ST CHARACTER
065174 005001          CLR      R1                    ::CLEAR DATA WORD
065176 005002          CLR      R2
065200 112046          2$:  MOVB     (R0)+,-(SP)      ::PICKUP THIS CHARACTER
065202 001412          BEQ      3$                    ::IF ZERO GET OUT
065204 006301          ASL     R1                    ::*2
065206 006102          ROL     R2
065210 006301          ASL     R1                    ::*4
065212 006102          ROL     R2
065214 006301          ASL     R1                    ::*8
065216 006102          ROL     R2
065220 042716 177770  BIC     #^C7,(SP)      ::STRIP THE ASCII JUNK
065224 062601          ADD     (SP)+,R1        ::ADD IN THIS DIGIT
065226 000764          BR      2$                    ::LOOP
065230 005726          3$:  TST     (SP)+          ::CLEAN TERMINATOR FROM STACK
065232 010166 000012  MOV     R1,12(SP)      ::SAVE THE RESULT
065236 010237 065252  MOV     R2,$HIOCT
065242 012602          MOV     (SP)+,R2        ::POP STACK INTO R2
065244 012601          MOV     (SP)+,R1        ::POP STACK INTO R1
065246 012600          MOV     (SP)+,R0        ::POP STACK INTO R0
065250 000002          RTI
065252 000000          $HIOCT: .WORD 0      ::HIGH ORDER BITS GO HERE
  
```

.SBTTL TRAP DECODER

 *THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION
 *AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
 *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
 *GO TO THAT ROUTINE.

065254	016646	000002	\$TRAP:	MOV	2(SP),-(SP)	::ASSUME THE STATUS OF
065260	042716	000020		BIC	#20,(SP)	:: THE CALLER--DO NOT ALLOW
065264	012746	065272		MOV	#1\$,-(SP)	:: T-BIT TRAPS
065270	000002			RTI		::SET THE NEW STATUS
065272	010046		1\$:	MOV	R0,-(SP)	::SAVE R0
065274	016600	000002		MOV	2(SP),R0	::GET TRAP ADDRESS
065300	005740			TST	-(R0)	::BACKUP BY 2
065302	111000			MOVB	(R0),R0	::GET RIGHT BYTE OF TRAP
065304	006300			ASL	R0	::POSITION FOR INDEXING
065306	016000	065326		MOV	\$TRPAD(R0),R0	::INDEX TO TABLE
065312	000200			RTS	R0	::GO TO ROUTINE

::THIS IS USE TO HANDLE THE 'GETPRI' MACRO

065314	011646	000004	000002	\$TRAP2:	MOV	(SP),-(SP)	::MOVE THE PC DOWN
065316	016666				MOV	4(SP),2(SP)	::MOVE THE PSW DOWN
065324	000002				RTI		::RESTORE THE PSW

.SBTTL TRAP TABLE

*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
 *BY THE 'TRAP' INSTRUCTION.

			:	ROUTINE		
			:	-----		
065326	065314		\$TRPAD:	.WORD	\$TRAP2	
065330	061134			\$TYPE	::CALL=TYPE	TRAP+1(104401) TTY TYPEOUT ROUTINE
065332	060732			\$TYPOC	::CALL=TYPOC	TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
065334	060706			\$TYPOS	::CALL=TYPOS	TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
065336	060746			\$TYPON	::CALL=TYPON	TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
065340	060462			\$TYPDS	::CALL=TYPDS	TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
065342	060406			\$TYPBN	::CALL=TYPBN	TRAP+6(104406) TYPE BINARY (ASCII) NUMBER
065344	064260			\$GTSWR	::CALL=GTSWR	TRAP+7(104407) GET SOFT-SWR SETTING
065346	064170			\$CKSWR	::CALL=CKSWR	TRAP+10(104410) TEST FOR CHANGE IN SOFT-SWR
065350	064532			\$RDCHR	::CALL=RDCHR	TRAP+11(104411) TTY TYPEIN CHARACTER ROUTINE
065352	064622			\$RDLIN	::CALL=RDLIN	TRAP+12(104412) TTY TYPEIN STRING ROUTINE
065354	065152			\$RDOCT	::CALL=RDOCT	TRAP+13(104413) READ AN OCTAL NUMBER FROM TTY
065356	060312			\$SAVREG	::CALL=SAVREG	TRAP+14(104414) SAVE R0-R5 ROUTINE
065360	060350			\$RESREG	::CALL=RESREG	TRAP+15(104415) RESTORE R0-R5 ROUTINE

.SBTTL POWER DOWN AND UP ROUTINES

::*****

:POWER DOWN ROUTINE

065362	012737	065522	000024	\$PWRDN: MOV	#\$ILLUP,@#PWRVEC	::SET FOR FAST UP
065370	012737	000340	000026	MOV	#340,@#PWRVEC+2	::PRIO:7
065376	010046			MOV	R0,-(SP)	::PUSH R0 ON STACK
065400	010146			MOV	R1,-(SP)	::PUSH R1 ON STACK
065402	010246			MOV	R2,-(SP)	::PUSH R2 ON STACK
065404	010346			MOV	R3,-(SP)	::PUSH R3 ON STACK
065406	010446			MOV	R4,-(SP)	::PUSH R4 ON STACK
065410	010546			MOV	R5,-(SP)	::PUSH R5 ON STACK
065412	017746	113536		MOV	@SWR,-(SP)	::PUSH @SWR ON STACK
065416	010637	065526		MOV	SP,\$SAVR6	::SAVE SP
065422	012737	065434	000024	MOV	#\$PWRUP,@#PWRVEC	::SET UP VECTOR
065430	0000C0			HALT		
065432	000776			BR	.-2	::HANG UP

::*****

:POWER UP ROUTINE

065434	012737	065522	000024	\$PWRUP: MOV	#\$ILLUP,@#PWRVEC	::SET FOR FAST DOWN
065442	013706	065526		MOV	\$\$SAVR6,SP	::GET SP
065446	005037	065526		CLR	\$\$SAVR6	::WAIT LOOP FOR THE TTY
065452	005237	065526		1\$: INC	\$\$SAVR6	::WAIT FOR THE INC
065456	001375			BNE	1\$::OF WORD
065460	012677	113470		MOV	(SP)+,@SWR	::POP STACK INTO @SWR
065464	012605			MOV	(SP)+,R5	::POP STACK INTO R5
065466	012604			MOV	(SP)+,R4	::POP STACK INTO R4
065470	012603			MOV	(SP)+,R3	::POP STACK INTO R3
065472	012602			MOV	(SP)+,R2	::POP STACK INTO R2
065474	012601			MOV	(SP)+,R1	::POP STACK INTO R1
065476	012600			MOV	(SP)+,R0	::POP STACK INTO R0
065500	012737	065362	000024	MOV	#\$PWRDN,@#PWRVEC	::SET UP THE POWER DOWN VECTOR
065506	012737	000340	000026	MOV	#340,@#PWRVEC+2	::PRIO:7
065514	104401			TYPE		::REPORT THE POWER FAILURE
065516	065530			\$PWRMG: .WORD	\$POWER	::POWER FAIL MESSAGE POINTER
065520	000002			RTI		
065522	000000			\$ILLUP: HALT		::THE POWER UP SEQUENCE WAS STARTED
065524	000776			BR	.-2	::BEFORE THE POWER DOWN WAS COMPLETE
065526	000000			\$\$SAVR6: 0		::PUT THE SP HERE
065530	015	012	120	\$POWER: .ASCIZ	<15><12>'POWER'	
					.EVEN	

.SBTTL APT COMMUNICATIONS ROUTINE

```

*****
065540 112737 000001 066004 $ATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
065546 112737 000001 066002 $ATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
065554 000403
065556 112737 000001 066004 $ATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
065564 $ATYC:
065564 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
065566 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
065570 105737 066002 TSTB SMFLG ;;SHOULD TYPE A MESSAGE?
065574 001450 BEQ 5$ ;;IF NOT: BR
065576 122737 000001 001242 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
065604 001031 BNE 3$ ;;IF NOT: BR
065606 132737 000100 001243 BITB #APTSPool,$ENVM ;;SHOULD SPOOL MESSAGES?
065614 001425 BEQ 3$ ;;IF NOT: BR
065616 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
065622 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
065630 005737 001222 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
065634 001375 BNE 1$ ;;IF NOT: WAIT
065636 010037 001236 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
065642 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
065644 001376 BNE 2$
065646 163700 001236 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
065652 006200 ASR R0 ;;GET MESSAGE LNTH IN WORDS
065654 010037 001240 MOV R0,$MSGLGT ;;PUT LENGTH IN MAILBOX
065660 012737 000004 001222 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
065666 000413 BR 5$
065670 017637 000004 065714 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
065676 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
065704 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
065710 004737 061134 JSR PC,$TYPE ;;CALL TYPE MACRO
065714 000000 4$: .WORD 0
065716 5$:
065716 105737 066004 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
065722 001416 BEQ 12$ ;;IF NOT: BR
065724 005737 001242 TST $ENV ;;RUNNING UNDER APT?
065730 001413 BEQ 12$ ;;IF NOT: BR
065732 005737 001222 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
065736 001375 BNE 11$ ;;IF NOT: WAIT
065740 017637 000004 001224 MOV @4(SP),$FATAL ;;GET ERROR #
065746 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
065754 005237 001222 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
065760 105037 066004 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
065764 105037 066003 CLRB $LFLG ;;CLEAR LOG FLAG
065770 105037 066002 CLRB $MFLG ;;CLEAR MESSAGE FLAG
065774 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
065776 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
066000 000207 RTS PC ;;RETURN
066002 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
066003 000 $LFLG: .BYTE 0 ;;LOG FLAG
066004 000 $FFLG: .BYTE 0 ;;FATAL FLAG
. EVEN
000200 APTSIZE = 200
000001 APTENV = 001
000100 APTSPool = 100
000040 APTCSUP = 040
  
```

.SBTTL CONSOLE MESSAGES

2					
3	066006	200	103	101	SCTMSG: .ASCIZ <CRLF>@CANNOT RECOVER THE BAD SECTOR FILES ON THIS DEVICE@
4	066072	075	000		EQUALS: .ASCIZ @=@
5	066074	101	114	114	ALL: .ASCIZ @ALL@<CRLF>
6	066101	040	077	040	QUES: .ASCIZ @ ? @
7	066105	054	040	000	COMMA: .ASCIZ @, @
8	066110	200	124	117	MSHELP: .ASCII <CRLF>@TO ENSURE THAT NO BAD HEADERS ARE LEFT ON THE DISK@
9	066176	200	104	125	.ASCII <CRLF>@DURING ERROR FREE OPERATION, THIS PROGRAM SHOULD BE@
10	066264	200	102	105	.ASCII <CRLF>@BE HALTED BY TYPING A (^C) CONTROL C. AS A RESULT,@
11	066352	200	124	110	.ASCII <CRLF>@THE PROGRAM WILL BE HALTED WHEN THE DRIVE UNDER TEST@
12	066440	200	110	101	.ASCII <CRLF>@HAS COMPLETED TESTING.@
13	066467	200			.ASCII <CRLF>
14	066470	200	124	131	.ASCIZ <CRLF>@TYPE HELP TEXT (L) N ? @
15	066521	200	122	115	CNSL01: .ASCIZ <CRLF>@RMCS1=@
16	066531	040	114	111	CNSL02: .ASCIZ @ LIMITS - LO= 160000, HI= 17XXXX@<CRLF>
17	066573	122	115	126	CNSL03: .ASCIZ @RMVEC=@
18	066602	040	114	111	CNSL04: .ASCIZ @ LIMITS - LO= 0, HI= 1000@<CRLF><LF>
19	066636	200	124	131	CNSL07: .ASCII <CRLF>@TYPE 'A' TO TEST ALL DRIVES, OR TYPE DRIVE NUMBER(S)@
20	066723	200	101	116	.ASCIZ <CRLF>@AND TERMINATE INPUT WITH A CARRIAGE RETURN.@
21	067000	200			CNSL08: .ASCII <CRLF>
22	067001	040	077	111	CNSL09: .ASCIZ @ ?ILLEGAL INPUT@<CRLF>
23	067022	200	104	122	MSDRVS: .ASCIZ <CRLF>/DRIVE(S): /
24	067036	104	122	111	MSGDRV: .ASCIZ /DRIVE/
25	067044	200	125	116	SYSTAT: .ASCIZ <CRLF>/UNIT STATUS:/
26	067062	122	115	070	SRM80: .ASCIZ /RM80/
27	067067	040	116	117	NOTRM: .ASCIZ / NOT AN RM80/
28	067104	040	114	117	LODEV: .ASCIZ / LOAD DEVICE/
29	067121	040	116	117	NOTPRS: .ASCIZ / NOT PRESENT/
30	067136	040	116	117	NOTAVL: .ASCIZ / NOT AVAILABLE/
31	067155	040	117	106	UNTOFF: .ASCIZ / OFFLINE/
32	067166	040	117	116	UNTON: .ASCIZ / ONLINE/
33	067176	200	104	122	DRIVES: .ASCIZ <CRLF>/DRIVE(S) TO BE TESTED/
34	067225	116	117	116	NONE: .ASCIZ /NONE/
35	067232	116	000		N: .ASCIZ /N/
36	067234	131	000		Y: .ASCIZ /Y/
37	067236	040			BLNKS4: .ASCII / /
38	067237	040			BLNKS3: .ASCII / /
39	067240	040			BLNKS2: .ASCII / /
40	067241	040	000		BLNKS1: .ASCIZ / /
41					.EVEN

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL FUNCTION CODE TABLE
;THE FUNCTION CODE TABLE IS USED TO DEFINE STATUS CONDITIONS FOR
;EACH FUNCTION CODE. BIT USAGE IS AS FOLLOWS:
;
;ATA - BIT 15 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
;IF ATA SHOULD BE SET WHEN THE FUNCTION CODE IS EXECUTED, OTHERWISE,
;BIT 15 IS ZERO, INDICATING THAT ATA SHOULD NOT NORMALLY BE SET.
;NOTE THAT ATA MAY BE SET WHEN A COMMAND IS EXECUTED EVEN THOUGH
;IT IS NOT EXPECTED AS A RESULT OF THE COMMAND.
;
;WCE - BIT 14 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
;IF WRITE CHECK ERRORS ARE ENABLED AS A FUNCTION OF THE COMMAND.
;
;OPI - BIT 13 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
;IF OPI ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
;
;IVC - BIT 12 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
;IF IVC ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
;
;WLE - BIT 11 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
;IF WRITE ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
;THE WRITE ERRORS WHICH ARE ENABLED ARE 'WLE', 'WCF', 'DPE', 'UPE'.
;
;IAE - BIT 10 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
;IF INVALID ADDRESS ERROR IS ENABLED FOR THAT COMMAND.
;
;AOE - BIT 09 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
;IF READ AND WRITE ERRORS ARE ENABLED DURING THE EXECUTION OF THE
;COMMAND. THE ERRORS ENABLED BY THIS BIT ARE 'TRE', 'DLT', 'NEM',
;'MXF', 'LBT', AND 'AOE'.
;
; BIT 08 IS NOT USED.
;
;HCE - BIT 07 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
;IF HEADER ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
;HEADER ERRORS INCLUDE 'HCRC', 'HCE', 'FER', AND 'BSE'.
;
;ECH - BIT 06 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
;IF DATA FIELD ERRORS ARE ENABLED DURING THE EXECUTION OF THAT
;COMMAND. THESE ERRORS INCLUDE 'MDPE', 'DCK', AND 'ECH'.
;
; BIT 05 IS NOT USED.
;
; BIT 04 IS NOT USED.
;
; BIT 03 IS NOT USED.
;
; BIT 02 IS NOT USED.
;
; BIT 01 IS NOT USED.
;
; ILF - BIT 00 IS SET IF THE FUNCTION CODE IS ILLEGAL.
FNCDTB: ;FUNCTION CODE TABLE
.WORD OPI ;NOP

067244
067244 020000

FUNCTION CODE TABLE

58	067246	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (2)
59	067250	132000	.WORD	ATA!OPI!IVC!IAE	:SEEK
60	067252	130000	.WORD	ATA!OPI!IVC	:RECALIBRATE
61	067254	020000	.WORD	OPI	:DRIVE CLEAR
62	067256	030000	.WORD	OPI!IVC	:RELEASE
63	067260	130000	.WORD	OPI!ATA!IVC	:OFFSET
64	067262	130000	.WORD	OPI!ATA!IVC	:RETURN TO CENTERLINE
65	067264	020000	.WORD	OPI	:READ IN PRESET
66	067266	020000	.WORD	OPI	:PACK ACKNOWLEDGE
67	067270	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (24)
68	067272	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (26)
69	067274	132000	.WORD	ATA!OPI!IVC!IAE	:SEARCH
70	067276	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (32)
71	067300	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (34)
72	067302	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (36)
73	067304	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (40)
74	067306	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (42)
75	067310	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (44)
76	067312	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (46)
77	067314	073300	.WORD	WCE!OPI!IVC!IAE!AOE!HCE!ECH	:WRITE CHECK DATA
78	067316	073300	.WORD	WCE!OPI!IVC!IAE!AOE!HCE!ECH	:WRITE CHECK HEADER AND DATA
79	067320	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (54)
80	067322	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (56)
81	067324	037200	.WORD	OPI!IVC!WLE!IAE!AOE!HCE	:WRITE DATA
82	067326	037000	.WORD	OPI!IVC!WLE!IAE!AOE	:WRITE HEADER AND DATA
83	067330	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (64)
84	067332	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (66)
85	067334	033300	.WORD	OPI!IVC!IAE!AOE!HCE!ECH	:READ DATA
86	067336	033300	.WORD	OPI!IVC!IAE!AOE!HCE!ECH	:READ HEADER AND DATA
87	067340	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (74)
88	067342	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (76)

1
2
3 067344 001
4 067345 002
5 067346 004
6 067347 010
7 067350 020
8 067351 040
9 067352 100
10 067353 200

.SBTTL ATTENTION (ATA) TABLE

ATNTBL: .BYTE 1.
.BYTE 2.
.BYTE 4.
.BYTE 8.
.BYTE 16.
.BYTE 32.
.BYTE 64.
.BYTE 128.

DATA PATTERN TABLE

.SBTTL DATA PATTERN TABLE

1			
2			
3	067354		
4	067354		
5	067354	000000	
6	067356	000001	
7	067360	000003	
8	067362	000007	
9	067364	000017	
10	067366	000037	
11	067370	000077	
12	067372	000177	
13	067374	000377	
14	067376	000777	
15	067400	001777	
16	067402	003777	
17	067404	007777	
18	067406	017777	
19	067410	037777	
20	067412	077777	
21	067414	177777	
22	067416	177777	
23	067420	077777	
24	067422	037777	
25	067424	017777	
26	067426	007777	
27	067430	003777	
28	067432	001777	
29	067434	000777	
30	067436	000377	
31	067440	000177	
32	067442	000077	
33	067444	000037	
34	067446	000017	
35	067450	000007	
36	067452	000003	
37	067454	000001	
38	067456	000000	
39	067460	000000	
40	067462	000001	
41	067464	000002	
42	067466	000004	
43	067470	000010	
44	067472	000020	
45	067474	000040	
46	067476	000100	
47	067500	000200	
48	067502	000400	
49	067504	001000	
50	067506	002000	
51	067510	004000	
52	067512	010000	
53	067514	020000	
54	067516	040000	
55	067520	100000	
56	067522	100000	
57	067524	040000	

RGDTPT:
MIXED:

.WORD 0.
.WORD 1.
.WORD 3.
.WORD 7.
.WORD 15.
.WORD 31.
.WORD 63.
.WORD 127.
.WORD 255.
.WORD 511.
.WORD 1023.
.WORD 2047.
.WORD 4095.
.WORD 8191.
.WORD 16383.
.WORD 32767.
.WORD 65535.
.WORD 65535.
.WORD 32767.
.WORD 16383.
.WORD 8191.
.WORD 4095.
.WORD 2047.
.WORD 1023.
.WORD 511.
.WORD 255.
.WORD 127.
.WORD 63.
.WORD 31.
.WORD 15.
.WORD 7.
.WORD 3.
.WORD 1.

ONES:

ZEROS:

.WORD 0.
.WORD 0.
.WORD 1.
.WORD 2.
.WORD 4.
.WORD 8.
.WORD 16.
.WORD 32.
.WORD 64.
.WORD 128.
.WORD 256.
.WORD 512.
.WORD 1024.
.WORD 2048.
.WORD 4096.
.WORD 8192.
.WORD 16384.
.WORD 32768.
.WORD 32768.
.WORD 16384.

58	067526	020000	.WORD	8192.
59	067530	010000	.WORD	4096.
60	067532	004000	.WORD	2048.
61	067534	002000	.WORD	1024.
62	067536	001000	.WORD	512.
63	067540	000400	.WORD	256.
64	067542	000200	.WORD	128.
65	067544	000100	.WORD	64.
66	067546	000040	.WORD	32.
67	067550	000020	.WORD	16.
68	067552	000010	.WORD	8.
69	067554	000004	.WORD	4.
70	067556	000002	.WORD	2.
71	067560	000001	.WORD	1.
72	067562	000000	.WORD	0.
73	067564	177777	.WORD	65535.
74	067566	177776	.WORD	65534.
75	067570	177774	.WORD	65532.
76	067572	177770	.WORD	65528.
77	067574	177760	.WORD	65520.
78	067576	177740	.WORD	65504.
79	067600	177700	.WORD	65472.
80	067602	177600	.WORD	65408.
81	067604	177400	.WORD	65280.
82	067606	177000	.WORD	65024.
83	067610	176000	.WORD	64512.
84	067612	174000	.WORD	63488.
85	067614	170000	.WORD	61440.
86	067616	160000	.WORD	57344.
87	067620	140000	.WORD	49152.
88	067622	100000	.WORD	32768.
89	067624	000000	.WORD	0.
90	067626	000000	.WORD	0.
91	067630	100000	.WORD	32768.
92	067632	140000	.WORD	49152.
93	067634	160000	.WORD	57344.
94	067636	170000	.WORD	61440.
95	067640	174000	.WORD	63488.
96	067642	176000	.WORD	64512.
97	067644	177000	.WORD	65024.
98	067646	177400	.WORD	65280.
99	067650	177600	.WORD	65408.
100	067652	177700	.WORD	65472.
101	067654	177740	.WORD	65504.
102	067656	177760	.WORD	65520.
103	067660	177770	.WORD	65528.
104	067662	177774	.WORD	65532.
105	067664	177776	.WORD	65534.
106	067666	177777	.WORD	65535.
107	067670	125252	EARLY: .WORD	43690.
108	067672	152525	.WORD	43690./2
109	067674	125252	.WORD	43690.
110	067676	177777	.WORD	65535.
111	067700	177776	.WORD	65534.
112	067702	177775	.WORD	65533.
113	067704	177773	.WORD	65531.
114	067706	177767	.WORD	65527.

115	067710	177757	.WORD	65519.
116	067712	177737	.WORD	65503.
117	067714	177677	.WORD	65471.
118	067716	177577	.WORD	65407.
119	067720	177377	.WORD	65279.
120	067722	176777	.WORD	65023.
121	067724	175777	.WORD	64511.
122	067726	173777	.WORD	63487.
123	067730	167777	.WORD	61439.
124	067732	157777	.WORD	57343.
125	067734	137777	.WORD	49151.
126	067736	077777	.WORD	32767.
127	067740	077777	.WORD	32767.
128	067742	137777	.WORD	49151.
129	067744	157777	.WORD	57343.
130	067746	167777	.WORD	61439.
131	067750	173777	.WORD	63487.
132	067752	175777	.WORD	64511.
133	067754	176777	.WORD	65023.
134	067756	177377	.WORD	65279.
135	067760	177577	.WORD	65407.
136	067762	177677	.WORD	65471.
137	067764	177737	.WORD	65503.
138	067766	177757	.WORD	65519.
139	067770	177767	.WORD	65527.
140	067772	177773	.WORD	65531.
141	067774	177775	.WORD	65533.
142	067776	177776	.WORD	65534.
143	070000	177777	.WORD	65535.
144	070002			

ENRGDT:

				.SBTTL	ERROR MESSAGE TABLE		
1							
2							
3	070002	074442	000000	EMT1:	.WORD	EMS1,0	
4	070006	074511	074526	000000	EMT2:	.WORD	EMS2,EMS3,0
5	070014	074511	074571	000000	EMT3:	.WORD	EMS2,EMS4,0
6	070022	074634	074664	000000	EMT4:	.WORD	EMS5,EMS6,0
7	070030	074634	074776	000000	EMT5:	.WORD	EMS5,EMS10,0
8	070036	101427	076657	000000	EMT6:	.WORD	EMS167,EMS64,0
9	070044	077425	101454	000000	EMT7:	.WORD	EMS110,EMS170,0
10	070052	074731	000000	EMT10:	.WORD	EMS7,0	
11	070056	074776	000000	EMT11:	.WORD	EMS10,0	
12	070062	075040	075051	000000	EMT12:	.WORD	EMS11,EMS12,0
13	070070	075112	075123	075134	EMT13:	.WORD	EMS13,EMS14,EMS15,EMS16,0
14	070107	075206	076657	000000	EMT14:	.WORD	EMS17,EMS64,0
15	070110	075040	075271	000000	EMT15:	.WORD	EMS11,EMS21,0
16	070116	075040	075314	075443	EMT16:	.WORD	EMS11,EMS22,EMS27,0
17	070126	075040	075330	075454	EMT17:	.WORD	EMS11,EMS23,EMS30,0
18	070136	075040	075356	075454	EMT20:	.WORD	EMS11,EMS24,EMS30,0
19	070146	075040	075405	075443	EMT21:	.WORD	EMS11,EMS25,EMS27,0
20	070156	075040	075422	075443	EMT22:	.WORD	EMS11,EMS26,EMS27,0
21	070166	075040	075464	075454	EMT23:	.WORD	EMS11,EMS31,EMS30,0
22	070176	075040	075513	075454	EMT24:	.WORD	EMS11,EMS32,EMS30,0
23	070206	075040	075542	075454	EMT25:	.WORD	EMS11,EMS33,EMS30,0
24	070216	075040	075570	075454	EMT26:	.WORD	EMS11,EMS34,EMS30,0
25	070226	075040	075641	075454	EMT27:	.WORD	EMS11,EMS35,EMS30,0
26	070236	075040	075670	075454	EMT30:	.WORD	EMS11,EMS36,EMS30,0
27	070246	075040	075717	075454	EMT31:	.WORD	EMS11,EMS37,EMS30,0
28	070256	075040	075745	075454	EMT32:	.WORD	EMS11,EMS40,EMS30,0
29	070266	075040	075774	075454	EMT33:	.WORD	EMS11,EMS41,EMS30,0
30	070276	075040	076022	075454	EMT34:	.WORD	EMS11,EMS42,EMS30,0
31	070306	075040	076051	075454	EMT35:	.WORD	EMS11,EMS43,EMS30,0
32	070316	075040	076100	075454	EMT36:	.WORD	EMS11,EMS44,EMS30,0
33	070326	075040	076153	075454	EMT37:	.WORD	EMS11,EMS45,EMS30,0
34	070336	076743	075246	000000	EMT40:	.WORD	EMS66,EMS20,0
35	070344	077131	100631	077137	EMT41:	.WORD	EMS75,EMS141,EMS76,0
36	070354	100722	100732	077065	EMT42:	.WORD	EMS144,EMS145,EMS72,EMS76,0
37	070366	076245	076363	077137	EMT43:	.WORD	EMS47,EMS53,EMS76,0
38	070376	077170	076363	077137	EMT44:	.WORD	EMS77,EMS53,EMS76,0
39	070406	077216	076363	077137	EMT45:	.WORD	EMS100,EMS53,EMS76,0
40	070416	077244	076363	077137	EMT46:	.WORD	EMS101,EMS53,EMS76,0
41	070426	076675	076657	000000	EMT47:	.WORD	EMS65,EMS64,0
42	070434	075112	075134	076631	EMT50:	.WORD	EMS13,EMS15,EMS63,0
43	070444	075040	076216	075454	EMT51:	.WORD	EMS11,EMS46,EMS30,EMS67,0
44	070456	076245	076363	077013	EMT52:	.WORD	EMS47,EMS53,EMS67,EMS115,EMS140,EMS141,0
45	070474	076245	076363	077013	EMT53:	.WORD	EMS47,EMS53,EMS67,EMS115,EMS141,EMS164,0
46	070512	076274	076363	077013	EMT54:	.WORD	EMS50,EMS53,EMS67,0
47	070522	100657	100674	076363	EMT55:	.WORD	EMS142,EMS143,EMS53,EMS67,0
48	070534	076323	077065	077013	EMT56:	.WORD	EMS51,EMS72,EMS67,EMS115,EMS50,EMS70,0
49	070552	101427	077075	077013	EMT57:	.WORD	EMS167,EMS73,EMS67,0
50	070562	076446	077013	077625	EMT60:	.WORD	EMS56,EMS67,EMS115,EMS150,EMS152,EMS70,0
51	070600	077052	076446	077013	EMT61:	.WORD	EMS71,EMS56,EMS67,EMS115,EMS150,EMS152,EMS72,0
52	070620	100610	077013	077625	EMT62:	.WORD	EMS140,EMS67,EMS115,EMS47,EMS70,0
53	070634	102627	102652	075246	EMT63:	.WORD	EMS225,EMS226,EMS20,0
54	070644	101015	101057	077040	EMT64:	.WORD	EMS150,EMS152,EMS70,EMS115,EMS56,EMS73,EMS67,0
55	070664	076351	102054	102235	EMT65:	.WORD	EMS52,EMS205,EMS214,EMS206,EMS115,EMS51,EMS72,0
56	070704	101366	077321	077065	EMT66:	.WORD	EMS165,EMS103,EMS72,EMS124,0
57	070716	101366	077321	077065	EMT67:	.WORD	EMS165,EMS103,EMS72,EMS171,0

58	070730	076216	075246	101261	EMT70:	.WORD	EMS46,EMS20,EMS163,0
59	070740	077052	077244	101261	EMT71:	.WORD	EMS71,EMS101,EMS163,0
60	070750	076245	077065	101261	EMT72:	.WORD	EMS47,EMS72,EMS163,EMS115,EMS140,EMS141,0
61	070766	076245	077065	101261	EMT73:	.WORD	EMS47,EMS72,EMS163,EMS115,EMS141,EMS72,0
62	071004	076446	076363	101261	EMT74:	.WORD	EMS56,EMS53,EMS163,0
63	071014	077052	076446	101261	EMT75:	.WORD	EMS71,EMS56,EMS163,EMS115,EMS150,EMS152,EMS72,0
64	071034	076274	076363	101261	EMT76:	.WORD	EMS50,EMS53,EMS163,0
65	071044	100657	100674	076363	EMT77:	.WORD	EMS142,EMS143,EMS53,EMS163,0
66	071056	077131	100631	101261	EMT100:	.WORD	EMS75,EMS141,EMS163,EMS115,EMS47,EMS70,0
67	071074	077131	101015	101261	EMT101:	.WORD	EMS75,EMS150,EMS163,EMS115,EMS56,EMS73,0
68	071117	101427	077075	101261	EMT102:	.WORD	EMS167,EMS73,EMS163,0
69	071122	101000	101033	077112	EMT103:	.WORD	EMS147,EMS151,EMS74,EMS163,0
70	071134	07323	077112	101261	EMT104:	.WORD	EMS51,EMS74,EMS163,EMS115,EMS50,EMS70,0
71	071134	10366	077216	101261	EMT105:	.WORD	EMS165,EMS100,EMS163,0
72	071162	101366	077170	101261	EMT106:	.WORD	EMS165,EMS77,EMS163,0
73	071172	100722	100732	076363	EMT107:	.WORD	EMS144,EMS145,EMS53,EMS163,EMS115,EMS143,EMS70,0
74	071212	077425	077465	077630	EMT110:	.WORD	EMS110,EMS112,EMS116,EMS111,0
75	071224	077551	074571	000000	EMT111:	.WORD	EMS113,EMS4,0
76	071232	077551	074526	000000	EMT112:	.WORD	EMS113,EMS3,0
77	071240	077425	077625	077630	EMT113:	.WORD	EMS110,EMS115,EMS116,EMS117,EMS114,0
78	071254	000000			EMT114:	.WORD	
79	071256	077702	100342	100366	EMT115:	.WORD	EMS121,EMS132,EMS133,0
80	071266	077745	100342	100366	EMT116:	.WORD	EMS122,EMS132,EMS133,0
81	071276	100002	100342	100366	EMT117:	.WORD	EMS123,EMS132,EMS133,0
82	071306	100045	100342	100366	EMT120:	.WORD	EMS124,EMS132,EMS133,0
83	071316	100077	100342	100366	EMT121:	.WORD	EMS125,EMS132,EMS133,0
84	071326	100142	100342	100366	EMT122:	.WORD	EMS126,EMS132,EMS133,0
85	071336	100553	100342	100366	EMT123:	.WORD	EMS137,EMS132,EMS133,0
86	071346	100244	100342	100366	EMT124:	.WORD	EMS130,EMS132,EMS133,0
87	071356	100302	100342	100366	EMT125:	.WORD	EMS131,EMS132,EMS133,0
88	071366	077702	100342	100411	EMT126:	.WORD	EMS121,EMS132,EMS134,EMS123,0
89	071400	077745	100342	100411	EMT127:	.WORD	EMS122,EMS132,EMS134,EMS123,0
90	071412	100002	100342	100411	EMT130:	.WORD	EMS123,EMS132,EMS134,EMS123,0
91	071424	100045	100342	100411	EMT131:	.WORD	EMS124,EMS132,EMS134,EMS123,0
92	071436	100077	100342	100411	EMT132:	.WORD	EMS125,EMS132,EMS134,EMS123,0
93	071450	100142	100342	100411	EMT133:	.WORD	EMS126,EMS132,EMS134,EMS123,0
94	071462	100553	100342	100411	EMT134:	.WORD	EMS137,EMS132,EMS134,EMS123,0
95	071474	100244	100342	100411	EMT135:	.WORD	EMS130,EMS132,EMS134,EMS123,0
96	071506	100302	100342	100411	EMT136:	.WORD	EMS131,EMS132,EMS134,EMS123,0
97	071520	077702	100342	100453	EMT137:	.WORD	EMS121,EMS132,EMS135,0
98	071530	100002	100342	100453	EMT140:	.WORD	EMS123,EMS132,EMS135,0
99	071540	077702	100342	100526	EMT141:	.WORD	EMS121,EMS132,EMS136,0
100	071550	100553	100342	100526	EMT142:	.WORD	EMS137,EMS132,EMS136,0
101	071560	100045	100342	100526	EMT143:	.WORD	EMS124,EMS132,EMS136,0
102	071570	100077	100342	100526	EMT144:	.WORD	EMS125,EMS132,EMS136,0
103	071600	100142	100342	100526	EMT145:	.WORD	EMS126,EMS132,EMS136,0
104	071610	100302	100342	100526	EMT146:	.WORD	EMS131,EMS132,EMS136,0
105	071620	101503	100342	100526	EMT147:	.WORD	EMS171,EMS132,EMS136,0
106	071630	100244	100342	100526	EMT150:	.WORD	EMS130,EMS132,EMS136,0
107	071640	100610	077625	100631	EMT151:	.WORD	EMS140,EMS115,EMS141,EMS70,0
108	071652	100657	077625	100674	EMT152:	.WORD	EMS142,EMS115,EMS143,EMS72,0
109	071664	100722	100732	100761	EMT153:	.WORD	EMS144,EMS145,EMS146,EMS115,EMS143,EMS72,0
110	071702	100722	100732	075246	EMT154:	.WORD	EMS144,EMS145,EMS20,EMS115,EMS143,EMS70,0
111	071720	101015	101057	101125	EMT155:	.WORD	EMS150,EMS152,EMS154,EMS153,0
112	071732	101000	101033	101125	EMT156:	.WORD	EMS147,EMS151,EMS154,EMS155,0
113	071744	101000	101033	101161	EMT157:	.WORD	EMS147,EMS151,EMS156,EMS157,0
114	071756	101231	101161	101214	EMT160:	.WORD	EMS161,EMS156,EMS160,0

ERROR MESSAGE TABLE

115	071766	075405	075443	101161	EMT161:	.WORD	EMS25,EMS27,EMS156,EMS160,0
116	072000	075422	075443	101161	EMT162:	.WORD	EMS26,EMS27,EMS156,EMS160,0
117	072012	076245	101261	100610	EMT163:	.WORD	EMS47,EMS163,EMS140,0
118	072022	076245	075246	000000	EMT164:	.WORD	EMS47,EMS20,0
119	072030	076446	075246	000000	EMT165:	.WORD	EMS56,EMS20,0
120	072036	076216	075246	000000	EMT166:	.WORD	EMS46,EMS20,0
121	072044	102555	075246	000000	EMT167:	.WORD	EMS224,EMS20,0
122	072052	102013	100631	075454	EMT170:	.WORD	EMS203,EMS141,EMS30,EMS202,0
123	072064	101427	101125	101177	EMT171:	.WORD	EMS167,EMS154,EMS157,0
124	072074	101427	101125	101141	EMT172:	.WORD	EMS167,EMS154,EMS155,0
125	072104	101503	100342	100366	EMT173:	.WORD	EMS171,EMS132,EMS133,0
126	072114	101503	100342	100411	EMT174:	.WORD	EMS171,EMS132,EMS134,EMS123,0
127	072126	077551	101656	000000	EMT175:	.WORD	EMS113,EMS177,0
128	072134	101700	101715	000000	EMT176:	.WORD	EMS200,EMS201,0
129	072142	000000			EMT177:	.WORD	
130	072144	102013	076323	075454	EMT200:	.WORD	EMS203,EMS51,EMS30,EMS202,0
131	072156	102013	102026	075454	EMT201:	.WORD	EMS203,EMS204,EMS30,EMS202,0
132	072170	102013	076274	075454	EMT202:	.WORD	EMS203,EMS50,EMS30,EMS202,0
133	072202	102013	100674	075454	EMT203:	.WORD	EMS203,EMS143,EMS30,EMS202,0
134	072214	101015	077112	101763	EMT204:	.WORD	EMS150,EMS74,EMS202,EMS115,EMS152,EMS72,0
135	072232	076274	077321	077065	EMT205:	.WORD	EMS50,EMS103,EMS72,0
136	072242	077330	077075	101763	EMT206:	.WORD	EMS104,EMS73,EMS202,0
137	072252	077131	100631	077625	EMT207:	.WORD	EMS75,EMS141,EMS115,EMS140,0
138	072264	077131	101015	000000	EMT210:	.WORD	EMS75,EMS150,0
139	072272	076323	077065	077625	EMT211:	.WORD	EMS51,EMS72,EMS115,EMS50,EMS70,0
140	072306	100657	076363	077625	EMT212:	.WORD	EMS142,EMS53,EMS115,EMS143,EMS72,0
141	072322	076274	077321	076363	EMT213:	.WORD	EMS50,EMS103,EMS53,0
142	072332	076351	102054	101402	EMT214:	.WORD	EMS52,EMS205,EMS166,EMS206,EMS115,EMS51,EMS72,0
143	072352	076351	077660	076446	EMT215:	.WORD	EMS52,EMS117,EMS56,EMS163,0
144	072364	076446	075454	076657	EMT216:	.WORD	EMS56,EMS30,EMS64,0
145	072374	076216	075454	076657	EMT217:	.WORD	EMS46,EMS30,EMS64,0
146	072404	075464	075454	076657	EMT220:	.WORD	EMS31,EMS30,EMS64,0
147	072414	076245	075454	076657	EMT221:	.WORD	EMS47,EMS30,EMS64,0
148	072424	076351	077660	077170	EMT222:	.WORD	EMS52,EMS117,EMS77,0
149	072434	076351	077660	076631	EMT223:	.WORD	EMS52,EMS117,EMS63,0
150	072444	076351	077660	102527	EMT224:	.WORD	EMS52,EMS117,EMS225,EMS115,EMS226,0
151	072460	102627	102701	102712	EMT225:	.WORD	EMS225,EMS227,EMS230,EMS115,EMS156,EMS231,EMS57,0
152	072500	075040	102712	075454	EMT226:	.WORD	EMS11,EMS230,EMS30,0
153	072510	102627	102652	077625	EMT227:	.WORD	EMS225,EMS226,EMS115,EMS230,EMS72,0
154	072524	000000			EMT230:	.WORD	
155	072526	000000			EMT231:	.WORD	
156	072530	000000			EMT232:	.WORD	
157	072532	000000			EMT233:	.WORD	
158	072534	000000			EMT234:	.WORD	
159	072536	000000			EMT235:	.WORD	
160	072540	000000			EMT236:	.WORD	
161	072542	000000			EMT237:	.WORD	
162	072544	000000			EMT240:	.WORD	
163	072546	000000			EMT241:	.WORD	
164	072550	000000			EMT242:	.WORD	
165	072552	000000			EMT243:	.WORD	
166	072554	000000			EMT244:	.WORD	
167	072556	000000			EMT245:	.WORD	
168	072560	101427	100342	102113	EMT246:	.WORD	EMS167,EMS132,EMS207,0
169	072570	101427	100342	102140	EMT247:	.WORD	EMS167,EMS132,EMS210,EMS125,0
170	072602	101427	102151	102140	EMT250:	.WORD	EMS167,EMS211,EMS210,EMS207,EMS206,0
171	072616	102167	102212	000000	EMT251:	.WORD	EMS212,EMS213,0

ERROR MESSAGE TABLE

172	072624	101366	102167	000000	EMT252: .WORD	EMS165,EMS212,0
173	072632	101000	101033	101161	EMT253: .WORD	EMS147,EMS151,EMS156,EMS210,EMS26,EMS27,0
174	072650	102013	077244	075454	EMT254: .WORD	EMS203,EMS101,EMS30,0
175	072660	102013	101427	075454	EMT255: .WORD	EMS203,EMS167,EMS30,0
176	072670	102013	077216	075454	EMT256: .WORD	EMS203,EMS100,EMS30,0
177	072700	075040	076216	075454	EMT257: .WORD	EMS11,EMS46,EMS30,EMS102,0
178	072712	076351	077660	076446	EMT260: .WORD	EMS52,EMS117,EMS56,EMS102,0
179	072724	076351	102054	102357	EMT261: .WORD	EMS52,EMS205,EMS220,EMS206,EMS115,EMS51,EMS72,0
180	072744	077330	077075	101763	EMT262: .WORD	EMS104,EMS73,EMS202,0
181	072754	076274	076363	077272	EMT263: .WORD	EMS50,EMS53,EMS102,0
182	072764	076446	076363	077272	EMT264: .WORD	EMS56,EMS53,EMS102,EMS115,EMS150,EMS152,EMS70,0
183	073004	077052	076446	077272	EMT265: .WORD	EMS71,EMS56,EMS102,EMS115,EMS150,EMS152,EMS72,0
184	073024	100657	100674	076363	EMT266: .WORD	EMS142,EMS143,EMS53,EMS102,0
185	073036	076274	100761	077625	EMT267: .WORD	EMS50,EMS146,EMS115,EMS52,EMS117,EMS46,0
186	073054	076245	076363	077272	EMT270: .WORD	EMS47,EMS53,EMS102,EMS115,EMS140,0
187	073070	076245	076363	077272	EMT271: .WORD	EMS47,EMS53,EMS102,EMS115,EMS141,EMS72,0
188	073106	077131	100631	077272	EMT272: .WORD	EMS75,EMS141,EMS102,EMS115,EMS47,EMS73,0
189	073124	076323	077112	077272	EMT273: .WORD	EMS51,EMS74,EMS102,EMS115,EMS50,EMS70,0
190	073142	076631	076363	076523	EMT274: .WORD	EMS63,EMS53,EMS57,EMS115,EMS41,EMS146,0
191	073160	077630	076363	075774	EMT275: .WORD	EMS116,EMS53,EMS41,EMS57,0
192	073172	076245	076363	076523	EMT276: .WORD	EMS47,EMS53,EMS57,EMS115,EMS140,0
193	073206	076245	076363	076523	EMT277: .WORD	EMS47,EMS53,EMS57,EMS115,EMS141,EMS72,0
194	073224	076446	076363	076523	EMT300: .WORD	EMS56,EMS53,EMS57,EMS115,EMS150,EMS152,EMS70,0
195	073244	077052	076446	076363	EMT301: .WORD	EMS71,EMS56,EMS53,EMS57,EMS115,EMS150,EMS152,EMS72,0
196	073266	101366	077216	077321	EMT302: .WORD	EMS165,EMS100,EMS103,EMS57,0
197	073300	101366	077244	077321	EMT303: .WORD	EMS165,EMS101,EMS103,EMS57,0
198	073312	101366	077170	077321	EMT304: .WORD	EMS165,EMS77,EMS103,EMS57,0
199	073324	076216	075454	076657	EMT305: .WORD	EMS46,EMS30,EMS64,EMS57,0
200	073336	076274	076363	076523	EMT306: .WORD	EMS50,EMS53,EMS57,0
201	073346	076274	100761	077625	EMT307: .WORD	EMS50,EMS146,EMS115,EMS52,EMS117,EMS46,EMS57,0
202	073366	100657	100674	076363	EMT310: .WORD	EMS142,EMS143,EMS53,EMS57,0
203	073400	077330	077321	076363	EMT311: .WORD	EMS104,EMS103,EMS53,EMS57,0
204	073412	077357	077321	076363	EMT312: .WORD	EMS105,EMS103,EMS53,EMS57,0
205	073424	100722	100732	077321	EMT313: .WORD	EMS144,EMS145,EMS103,EMS57,EMS115,EMS143,EMS70,0
206	073444	076022	077321	076363	EMT314: .WORD	EMS42,EMS103,EMS53,EMS57,0
207	073456	075464	077321	076363	EMT315: .WORD	EMS31,EMS103,EMS53,EMS57,0
208	073470	077052	075464	077321	EMT316: .WORD	EMS71,EMS31,EMS103,EMS57,0
209	073502	076051	077321	076523	EMT317: .WORD	EMS43,EMS103,EMS57,0
210	073512	076153	077321	076523	EMT320: .WORD	EMS45,EMS103,EMS57,0
211	073522	076100	077321	076523	EMT321: .WORD	EMS44,EMS103,EMS57,0
212	073532	077406	075246	000000	EMT322: .WORD	EMS106,EMS20,0
213	073540	075670	077321	076523	EMT323: .WORD	EMS36,EMS103,EMS57,0
214	073550	101556	075670	077321	EMT324: .WORD	EMS173,EMS36,EMS103,EMS57,0
215	073562	101536	075670	077321	EMT325: .WORD	EMS172,EMS36,EMS103,EMS57,0
216	073574	075112	101573	075134	EMT326: .WORD	EMS13,EMS174,EMS15,EMS35,EMS53,EMS175,0
217	073612	101000	101033	077112	EMT327: .WORD	EMS147,EMS151,EMS74,EMS175,0
218	073624	076743	076363	101601	EMT330: .WORD	EMS66,EMS53,EMS175,0
219	073634	075542	077321	076363	EMT331: .WORD	EMS33,EMS103,EMS53,EMS175,0
220	073646	075745	077321	076363	EMT332: .WORD	EMS40,EMS103,EMS53,EMS57,0
221	073660	076323	077112	076523	EMT333: .WORD	EMS51,EMS74,EMS57,EMS115,EMS50,EMS70,0
222	073676	077131	100631	076523	EMT334: .WORD	EMS75,EMS141,EMS57,EMS115,EMS47,EMS73,0
223	073714	077131	101015	101057	EMT335: .WORD	EMS75,EMS150,EMS152,EMS57,EMS115,EMS56,EMS73,0
224	073734	076551	076564	076613	EMT336: .WORD	EMS60,EMS61,EMS62,0
225	073744	077630	077660	075570	EMT337: .WORD	EMS116,EMS117,EMS34,0
226	073754	075570	076363	076375	EMT340: .WORD	EMS34,EMS53,EMS54,EMS111,0
227	073766	076417	075570	000000	EMT341: .WORD	EMS55,EMS34,0
228	073774	076351	077660	076446	EMT342: .WORD	EMS52,EMS117,EMS56,EMS57,0

229	074006	076351	077660	076153	EMT343: .WORD	EMS52,EMS117,EMS45,EMS57.0
230	074020	076351	077660	076100	EMT344: .WORD	EMS52,EMS117,EMS44,EMS57.0
231	074032	076351	077660	102377	EMT345: .WORD	EMS52,EMS117,EMS221.0
232	074042	077406	075246	077625	EMT346: .WORD	EMS106,EMS20,EMS115,EMS223,EMS72.0
233	074056	076351	102054	102447	EMT347: .WORD	EMS52,EMS205,EMS222,EMS206.0
234	074070	077131	101015	077272	EMT350: .WORD	EMS75,EMS150,EMS102,EMS115,EMS56,EMS73.0
235	074106	101427	077075	077272	EMT351: .WORD	EMS167,EMS73,EMS102.0
236	074116	102253	000000		EMT352: .WORD	EMS215.0
237	074122	102324	102013	102274	EMT353: .WORD	EMS217,EMS203,EMS216.0
238	074132	102377	075246	000000	EMT354: .WORD	EMS221,EMS20.0

1	074140	103004	103610	103665	EHT1:	.WORD	EH1,STSH1,STSH2,STSH4,0
2	074152	103610	103665	104012	EHT2:	.WORD	STSH1,STSH2,STSH4,0
3							
4	074162	103023	000000		EHT110:	.WORD	EH110,0
5	074166	103032	000000		EHT111:	.WORD	EH111,0
6							
7	074172	103051	000000		EHT114:	.WORD	EH114,0
8	074176	103100	103610	103665	EHT223:	.WORD	EH223,STSH1,STSH2,STSH4,0
9	074210	103126	103610	103665	EHT256:	.WORD	EH256,STSH1,STSH2,STSH4,0
10							
11	074222	103202	103610	103665	EHT336:	.WORD	EH336,STSH1,STSH2,STSH4,0
12	074234	103241	103610	103665	EHT337:	.WORD	EH337,STSH1,STSH2,STSH4,0
13	074246	103376	103610	103665	EHT344:	.WORD	EH344,STSH1,STSH2,STSH4,0
14							
15	074260	103534	000000		EHT353:	.WORD	EH353,0

1	074264	104050	104144	104162	EDT1:	.WORD	ED1,STSD1,STSD2,STSD4
2	074274	104144	104162	104214	EDT2:	.WORD	STSD1,STSD2,STSD4
3							
4	074302	104056			EDT110:	.WORD	ED110
5	074304	104062			EDT111:	.WORD	ED111
6							
7	074306	104070			EDT114:	.WORD	ED114
8	074310	104100	104144	104162	EDT223:	.WORD	ED223,STSD1,STSD2,STSD4
9							
10	074320	104110	104144	104162	EDT336:	.WORD	ED336,STSD1,STSD2,STSD4
11	074330	104122	104144	104162	EDT337:	.WORD	ED337,STSD1,STSD2,STSD4
12	074340	104122	104144	104162	EDT344:	.WORD	ED337,STSD1,STSD2,STSD4,0
13							
14	074352	104134			EDT353:	.WORD	ED353

1	074354	104227	104245	104245	EFT1:	.WORD	EF111,STSF,STSF,STSF
2	074364	104245	104245	104245	EFT2:	.WORD	STSF,STSF,STSF
3							
4	074372	104226			EFT110:	.WORD	EF110
5	074374	104227			EFT111:	.WORD	EF111
6							
7	074376	104231			EFT114:	.WORD	EF114
8	074400	104231	104245	104245	EFT223:	.WORD	EF114,STSF,STSF,STSF
9							
10	074410	104234	104245	104245	EFT336:	.WORD	EF336,STSF,STSF,STSF
11	074420	104234	104245	104245	EFT337:	.WORD	EF336,STSF,STSF,STSF
12	074430	104234	104245	104245	EFT344:	.WORD	EF336,STSF,STSF,STSF
13							
14	074440	104231			EFT353:	.WORD	EF114

		.SBTTL		ERROR MESSAGE STRINGS	
1					
2					
3	074442	127	122	117	EMS1: .ASCIZ @WRONG UNIT SELECTED (RMCS2, BITS 0-2) @
4	074511	104	105	126	EMS2: .ASCIZ @DEVICE WENT @
5	074526	125	116	101	EMS3: .ASCIZ @UNAVAILABLE 'DVA' (RMCS1, BIT 11) @
6	074571	116	117	116	EMS4: .ASCIZ @NONEXISTENT 'NED' (RMCS2, BIT 12) @
7	074634	103	117	115	EMS5: .ASCIZ @COMMAND NOT COMPLETED, @
8	074664	103	117	116	EMS6: .ASCIZ @CONTROLLER NOT READY (RMCS1, BIT 7) @
9	074731	104	122	111	EMS7: .ASCIZ @DRIVE NOT READY 'DRY' (RMDS, BIT 7) @
10	074776	107	117	040	EMS10: .ASCIZ @GO NOT RESET 'GO' (RMCS1, BIT 0) @
11	075040	111	116	126	EMS11: .ASCIZ @INVALID @
12	075051	106	125	116	EMS12: .ASCIZ @FUNCTION CODE (RMCS1, BITS 1-5) @
13	075112	115	101	123	EMS13: .ASCIZ @MASSBUS @
14	075123	103	117	116	EMS14: .ASCIZ @CONTROL @
15	075134	102	125	123	EMS15: .ASCIZ @BUS PARITY ERROR @
16	075156	042	115	103	EMS16: .ASCIZ @'MCPE' (RMCS1, BIT 13) @
17	075206	124	122	101	EMS17: .ASCIZ @TRANSFER ERROR (RMCS1, BIT 14) @
18	075246	123	110	117	EMS20: .ASCIZ @SHOULD NOT BE SET @
19	075271	127	117	122	EMS21: .ASCIZ @WORD COUNT (RMWC) @
20	075314	102	125	123	EMS22: .ASCIZ @BUS (RMB) @
21	075330	042	114	102	EMS23: .ASCIZ @'LBT' (RMDS, BIT 10) @
22	075356	042	101	117	EMS24: .ASCIZ @'AOE' (RMER1, BIT 09) @
23	075405	104	111	123	EMS25: .ASCIZ @DISK (RMDA) @
24	075422	103	131	114	EMS26: .ASCIZ @CYLINDER (RMDC) @
25	075443	101	104	104	EMS27: .ASCIZ @ADDRESS @
26	075454	123	124	101	EMS30: .ASCIZ @STATUS @
27	075464	042	127	114	EMS31: .ASCIZ @'WLE' (RMER1, BIT 11) @
28	075513	042	125	120	EMS32: .ASCIZ @'UPE' (RMCS2, BIT 13) @
29	075542	042	127	103	EMS33: .ASCIZ @'WCF' (RMER1, BIT 5) @
30	075570	127	122	111	EMS34: .ASCIZ @WRITE CHECK ERROR-'WCE' (RMCS2, BIT 14) @
31	075641	042	115	104	EMS35: .ASCIZ @'MDPE' (RMCS2, BIT 8) @
32	075670	042	104	103	EMS36: .ASCIZ @'DCK' (RMER1, BIT 15) @
33	075717	042	105	103	EMS37: .ASCIZ @'ECH' (RMER1, BIT 6) @
34	075745	042	104	114	EMS40: .ASCIZ @'DLT' (RMCS2, BIT 15) @
35	075774	042	115	130	EMS41: .ASCIZ @'MXF' (RMCS2, BIT 9) @
36	076022	042	104	124	EMS42: .ASCIZ @'DTE' (RMER1, BIT 12) @
37	076051	042	110	103	EMS43: .ASCIZ @'HCRC' (RMER1, BIT 8) @
38	076100	110	105	101	EMS44: .ASCIZ @HEADER COMPARE ERROR 'HCE' (RMER1, BIT 7) @
39	076153	106	117	122	EMS45: .ASCIZ @FORMAT ERROR 'FER' (RMER1, BIT 4) @
40	076216	042	111	101	EMS46: .ASCIZ @'IAE' (RMER1, BIT 10) @
41	076245	042	117	120	EMS47: .ASCIZ @'OPI' (RMER1, BIT 13) @
42	076274	042	123	113	EMS50: .ASCIZ @'SKI' (RMER2, BIT 14) @
43	076323	042	120	111	EMS51: .ASCIZ @'PIP' (RMDS, BIT 13) @
44	076351	124	110	105	EMS52: .ASCIZ @THE RM80 @
45	076363	104	105	124	EMS53: .ASCIZ @DETECTED @
46	076375	101	124	040	EMS54: .ASCIZ @AT AN UNEXPECTED @
47	076417	111	116	103	EMS55: .ASCIZ @INCORRECT DATA DURING @
48	076446	111	116	126	EMS56: .ASCIZ @INVALID COMMAND ERROR 'IVC' (RMER2, BIT 12) @
49	076523	104	125	122	EMS57: .ASCIZ @DURING DATA TRANSFER @
50	076551	104	101	124	EMS60: .ASCIZ @DATA READ @
51	076564	104	117	105	EMS61: .ASCIZ @DOES NOT COMPARE WITH @
52	076613	104	101	124	EMS62: .ASCIZ @DATA WRITTEN @
53	076631	042	120	101	EMS63: .ASCIZ @'PAR' (RMER1, BIT 3) @
54	076657	111	123	040	EMS64: .ASCIZ @IS INCORRECT @
55	076675	103	117	115	EMS65: .ASCIZ @COMPOSITE ERROR 'ERR' (RMDS, BIT 14) @
56	076743	104	101	124	EMS66: .ASCIZ @DATA PARITY ERROR 'DPE' (RMER2, BIT 3) @
57	077013	104	125	122	EMS67: .ASCIZ @DURING SEEK COMMAND @

ERROR MESSAGE STRINGS

58	077040	111	123	040	EMS70:	.ASCIZ	@IS RESET @
59	077052	105	122	122	EMS71:	.ASCIZ	@ERRONEOUS @
60	077065	111	123	040	EMS72:	.ASCIZ	@IS SET @
61	077075	104	111	104	EMS73:	.ASCIZ	@DID NOT SET @
62	077112	104	111	104	EMS74:	.ASCIZ	@DID NOT RESET @
63	077131	114	117	123	EMS75:	.ASCIZ	@LOST @
64	077137	104	125	122	EMS76:	.ASCIZ	@DURING PACK ACK COMMAND @
65	077170	042	122	115	EMS77:	.ASCIZ	@'RMR' (RMR1, BIT 2) @
66	077216	042	111	114	EMS100:	.ASCIZ	@'ILR' (RMR1, BIT 1) @
67	077244	042	111	114	EMS101:	.ASCIZ	@'ILF' (RMR1, BIT 0) @
68	077272	104	125	122	EMS102:	.ASCIZ	@DURING SEARCH COMMAND @
69	077321	105	122	122	EMS103:	.ASCIZ	@ERROR @
70	077330	042	114	102	EMS104:	.ASCIZ	@'LBC' (RMR2, BIT 10) @
71	077357	042	114	123	EMS105:	.ASCIZ	@'LSC' (RMR2, BIT 11) @
72	077406	110	105	101	EMS106:	.ASCIZ	@HEADER ERRORS @
73	077425	102	125	123	EMS110:	.ASCIZ	@BUS TIMEOUT (04 TRAP) @
74	077454	101	104	104	EMS111:	.ASCIZ	@ADDRESS @
75	077465	127	110	105	EMS112:	.ASCII	@WHEN READING/WRITING RH REGISTERS @
76	077527	101	124	040	.ASCIZ	.ASCIZ	@AT THE FOLLOWING @
77	077551	124	110	105	EMS113:	.ASCIZ	@THE SELECTED DEVICE IS @
78	077601	116	117	116	EMS114:	.ASCIZ	@NONEXISTENT DEVICE @
79	077625	015	012	000	EMS115:	.ASCIZ	<CR><LF>
80	077630	124	110	105	EMS116:	.ASCIZ	@THE MASSBUS CONTROLLER @
81	077660	106	101	111	EMS117:	.ASCIZ	@FAILED TO DETECT @
82	077702				EMS120:		:NOT USED
83	077702	103	117	116	EMS121:	.ASCIZ	@CONTROL STATUS REGISTER 1, RMCS1, @
84	077745	102	125	123	EMS122:	.ASCIZ	@BUS ADDRESS REGISTER, RMAA, @
85	100002	103	117	116	EMS123:	.ASCIZ	@CONTROL STATUS REGISTER 2, RMCS2, @
86	100045	105	122	122	EMS124:	.ASCIZ	@ERROR REGISTER 1, RMR1, @
87	100077	101	124	124	EMS125:	.ASCIZ	@ATTENTION SUMMARY REGISTER, RMAA, @
88	100142	115	101	111	EMS126:	.ASCIZ	@MAINTENANCE REGISTER #1, RMR #1, @
89	100205	105	103	103	EMS127:	.ASCIZ	@ECC POSITION REGISTER, RMEC1, @
90	100244	105	103	103	EMS130:	.ASCIZ	@ECC PATTERN REGISTER, RMEC2, @
91	100302	115	101	111	EMS131:	.ASCIZ	@MAINTENANCE REGISTER 2, RMR2, @
92	100342	116	117	124	EMS132:	.ASCIZ	@NOT INITIALIZED BY @
93	100366	125	116	111	EMS133:	.ASCIZ	@UNIBUS INITIALIZE @
94	100411	103	117	116	EMS134:	.ASCIZ	@CONTROLLER CLEAR, I.E. BIT 5 OF @
95	100453	122	110	040	EMS135:	.ASCIZ	@RH CONTROLLER ERROR CLEAR (RMCS1, BIT 14) @
96	100526	104	122	111	EMS136:	.ASCIZ	@DRIVE CLEAR COMMAND @
97	100553	104	122	111	EMS137:	.ASCIZ	@DRIVE STATUS REGISTER, RMDA @
98	100610	115	105	104	EMS140:	.ASCIZ	@MEDIUM OFF LINE @
99	100631	042	115	117	EMS141:	.ASCIZ	@'MOL' (RMDA, BIT 12) @
100	100657	104	122	111	EMS142:	.ASCIZ	@DRIVE FAULT @
101	100674	042	104	126	EMS143:	.ASCIZ	@'DVC' (RMR2, BIT 7) @
102	100722	125	116	123	EMS144:	.ASCIZ	@UNSAFE @
103	100732	042	125	116	EMS145:	.ASCIZ	@'UNS' (RMR1, BIT 14) @
104	100761	123	110	117	EMS146:	.ASCIZ	@SHOULD BE SET @
105	101000	117	106	106	EMS147:	.ASCIZ	@OFFSET MODE @
106	101015	126	117	114	EMS150:	.ASCIZ	@VOLUME VALID @
107	101033	042	117	115	EMS151:	.ASCIZ	@'OM' (RMDA, BIT 0) @
108	101057	042	126	126	EMS152:	.ASCIZ	@'VV' (RMDA, BIT 6) @
109	101103	120	101	103	EMS153:	.ASCIZ	@PACK ACK COMMAND @
110	101125	116	117	124	EMS154:	.ASCIZ	@NOT SET BY @
111	101141	117	106	106	EMS155:	.ASCIZ	@OFFSET COMMAND @
112	101161	116	117	124	EMS156:	.ASCIZ	@NOT RESET BY @
113	101177	122	124	103	EMS157:	.ASCIZ	@RTC COMMAND @
114	101214	122	111	120	EMS160:	.ASCIZ	@RIP COMMAND @

ERROR MESSAGE STRINGS

115	101231	117	106	106	EMS161:	.ASCIZ	@OFFSET REGISTER (RMOF) @
116	101261				EMS162:		:<UNUSED>
117	101261	104	125	122	EMS163:	.ASCIZ	@DURING RECALIBRATE @
118	101305	111	123	040	EMS164:	.ASCII	@IS INTERMITTENT OR DRIVE DIDNT DROP ON @
119	101354	103	131	114		.ASCIZ	@CYLINDER @
120	101366	125	116	105	EMS165:	.ASCIZ	@UNEXPECTED @
121	101402	122	105	103	EMS166:	.ASCIZ	@RECALIBRATE COMMAND @
122	101427	042	101	124	EMS167:	.ASCIZ	@'ATA' (RMDS, BIT15) @
123	101454	127	110	105	EMS170:	.ASCIZ	@WHEN READING REGISTER @
124	101503	105	122	122	EMS171:	.ASCIZ	@ERROR REGISTER #2, RMER2, @
125	101536	116	117	116	EMS172:	.ASCIZ	@NONRECOVERABLE @
126	101556	122	105	103	EMS173:	.ASCIZ	@RECOVERABLE @
127	101573	104	101	124	EMS174:	.ASCIZ	@DATA @
128	101601	104	125	122	EMS175:	.ASCIZ	@DURING WRITE COMMAND @
129	101627	042	117	120	EMS176:	.ASCIZ	@'DPE' (RMER2, BIT 13) @
130	101656	111	116	040	EMS177:	.ASCIZ	@IN WRITE PROTECT @
131	101700	103	101	116	EMS200:	.ASCIZ	@CAN NOT SET @
132	101715	104	111	101	EMS201:	.ASCIZ	@DIAGNOSTIC MODE 'DMD' (RMMR1, BIT 0) @
133	101763	104	125	122	EMS202:	.ASCIZ	@DURING DIAGNOSTIC MODE @
134	102013	111	116	103	EMS203:	.ASCIZ	@INCORRECT @
135	102026	042	127	122	EMS204:	.ASCIZ	@'WRL' (RMDS, BIT 11) @
136	102054	105	130	105	EMS205:	.ASCIZ	@EXECUTED @
137	102066	127	111	124	EMS206:	.ASCIZ	@WITH COMP ERROR SET @
138	102113	042	107	117	EMS207:	.ASCIZ	@'GO' (RMCS1, BIT 0) @
139	102140	127	122	111	EMS210:	.ASCIZ	@WRITING @
140	102151	127	101	123	EMS211:	.ASCIZ	@WAS RESET BY @
141	102167	120	122	117	EMS212:	.ASCIZ	@PROGRAM INTERRUPT @
142	102212	127	101	123	EMS213:	.ASCIZ	@WAS NOT GENERATED @
143	102235	123	105	105	EMS214:	.ASCIZ	@SEEK COMMAND @
144	102253	120	122	117	EMS215:	.ASCIZ	@PROGRAM TIMEOUT @
145	102274	104	125	122	EMS216:	.ASCIZ	@DURING LOOK AHEAD TEST @
146	102324	1 4	117	117	EMS217:	.ASCIZ	@LOOK AHEAD REGISTER,RMLA, @
147	102357	123	105	101	EMS220:	.ASCIZ	@SEARCH COMMAND @
148	102377	102	101	104	EMS221:	.ASCIZ	@BAD SECTOR ERROR 'BSE' (RMER2, BIT 15) @
149	102447	101	040	104	EMS222:	.ASCIZ	@A DATA TRANSFER COMMAND @
150	102500	110	105	101	EMS223:	.ASCIZ	@HEADER COMPARE INHIBIT 'HCI' (RMOF, BIT 10) @
151	102555	116	117	116	EMS224:	.ASCIZ	@NONEXISTENT MEMORY 'NEM' (RMCS2, BIT 11) @
152	102627	123	113	111	EMS225:	.ASCIZ	@SKIP SECTOR ERROR @
153	102652	042	123	123	EMS226:	.ASCIZ	@'SSE' (RMER2, BIT 05) @
154	102701	111	116	110	EMS227:	.ASCIZ	@INHIBIT @
155	102712	042	123	123	EMS230:	.ASCIZ	@'SSE1' (RMOF, BIT 09) @
156	102741	105	116	104	EMS231:	.ASCIZ	@END OF TRACK @
157	102757	101	106	124	EMS232:	.ASCIZ	@AFTER DATA TRANSFER @

1	103004	105	130	120	EH1:	.ASCIZ	@EXPCTD	RECEVD@			
2	103023	102	125	123	EH110:	.ASCIZ	@BUSADR@				
3	103032	040	122	115	EH111:	.ASCIZ	@ RMCS2	RMCS1@			
4											
5	103051	122	105	103	EH114:	.ASCIZ	@RECEVD	SNGPRT	DULPRT@		
6	103100	105	130	120	EH223:	.ASCIZ	@EXPCTD	RECEVD	DATA@		
7	103126	105	130	120	EH256:	.ASCII	@EXPCTD	RECEVD	RGSTR@<CRLF>		
8	103154	123	124	101		.ASCIZ	@STATUS	STATUS	INDEX@		
9											
10	103202	117	104	101	EH336:	.ASCIZ	@GDADRS	GDDATA	BDADRS	BDDATA@	
11	103241	122	115	103	EH337:	.ASCII	@RMCS2	STATUS	FAILING	DATA@<CRLF>	
12	103300	37	137	137		.ASCII	@			@<CRLF>	
13	103337	05	130	120		.ASCIZ	@EXPCTD	RECEVD	--BIT--	ADRESS@	
14											
15	103376	122	115	105	EH344:	.ASCII	@RMER1	STATUS	HEADER	FAILING@<CRLF>	
16	103436	137	137	137		.ASCII	@		WORD	BIT@<CRLF>	
17	103474	105	130	120		.ASCIZ	@EXPCTD	RECEVD	NUMBER	POSITON@	
18	103534	105	130	120	EH353:	.ASCII	@EXPCTD	RECEVD@<CRLF>			
19	103553	074	103	122		.ASCIZ	@<CRLF>	RMLA	RMLA	RMOF @	
20											
21	103610	040	122	115	STSH1:	.ASCII	@ RMCS1	RMCS2	RMDS	RMER1	RMER2@
22	103655	040	040	040		.ASCIZ	@	RMAS@			
23	103665	040	122	115	STSH2:	.ASCII	@ RMWC	RMBA	RMDA	RMOF	RMDC@
24	103732	040	040	040		.ASCIZ	@	RMEC1	RMEC2@		
25	103754	040	122	115	STSH3:	.ASCIZ	@ RMDA	RMDC	RMOF	RMLA@	
26	104012	040	122	115	STSH4:	.ASCIZ	@ RMMR1	RMMR2	RMDT	RMSN@	
27					.EVEN						

1	104050	001140	001142	000000	ED1:	.WORD	\$GDDAT,\$BDDAT,0
2	104056	001276	000000		ED110:	.WORD	\$BASE,0
3	104062	001174	001176	000000	ED111:	.WORD	\$TMP0,\$TMP1,0
4							
5	104070	001364	001176	001200	ED114:	.WORD	RMDTI,\$TMP1,\$TMP2,0
6	104100	001140	001142	001174	ED223:	.WORD	\$GDDAT,\$BDDAT,\$TMP0,0
7							
8	104110	001134	001140	001136	ED336:	.WORD	\$GDADR,\$GDDAT,\$BDADR,\$BDDAT,0
9							
10	104122	001140	001142	001174	ED337:	.WORD	\$GDDAT,\$BDDAT,\$TMP0,\$TMP1,0
11	104134	001140	001142	001444	ED353:	.WORD	\$GDDAT,\$BDDAT,RMOFO,0
12							
13	104144	001336	001346	001350	STSD1:	.WORD	RMCS1I,RMCS2I,RMDSI,RMER1I,RMER2I,RMASI,0
14	104162	001340	001342	001344	STSD2:	.WORD	RMWCI,RMBAI,RMDAI,RMOFI,RMDCI,RMEC1I
15	104176	001404	000000			.WORD	RMEC2I,0
16	104202	001344	001372	001370	STSD3:	.WORD	RMDAI,RMDCI,RMOFI,RMLAI,0
17	104214	001362	001376	001364	STSD4:	.WORD	RMMR1I,RMMR2I,RMDTI,RMSNI,0

1	104226	000			EF110:	.BYTE	0
2	104227	000	000		EF111:	.BYTE	0,0
3	104231	000	000	000	EF114:	.BYTE	0,0,0
4	104234	000	000	000	EF336:	.BYTE	0,0,0,0
5	104240	000	000	000	EF337:	.BYTE	0,0,0,0,0
6							
7	104245	000	000	000	STSF:	.BYTE	0,0,0,0,0,0,0
8					.EVEN		

```
1 ;STORAGE FOR GENERAL DATA TRANSFERRS
2 104254 BUFFER:
3 104254 BUFSIZE: .BLKW 258.
4 105260 BUFTWO: .BLKW 258.
5
6 ;STORAGE FOR MANUFACTURES 16 BIT MODE BAD SECTOR FILE
7 106264 000000 000000 MFGFIL: .WORD 0,0 ;2 HEADER WORDS
8 106270 .BLKW 256. ;256. WORDS OF DATA
9 107270 177777 .WORD -1 ;TERMINATOR IF FILE IS FULL
10
11 ;STORAGE FOR USERS 16 BIT MODE BAD SECTOR FILE
12 107272 000000 000000 USRFIL: .WORD 0,0 ;2 HEADER WORDS
13 107276 .BLKW 256. ;256. WORDS OF DATA
14 110276 177777 .WORD -1 ;TERMINATOR IF FILE IS FULL
15
16 ;STORAGE FOR SKIP SECTOR FILE
17 110300 000000 000000 SSFIL: .WORD 0,0 ;2 HEADER WORDS
18 110304 .BLKW 28. ;2 CYLINDERS OF SKIP SECTOR ENTRIES
19 110374 177777 .WORD -1 ;TERMINATOR
20
21 104254 .=BUFFER
```

```
22
23 104254 HELP:
24 104254 200 .ASCII <CRLF>
25 104255 200 .ASCII <CRLF>
26 104256 114 111 123 .ASCII @LIST OF TESTS@<CRLF>
27 104274 055 055 055 .ASCII @-----@<CRLF>
28 104312 124 061 011 .ASCII @T1 CONTROLLER ACCESS TEST@<CRLF>
29 104344 124 062 011 .ASCII @T2 WRITE, READ ZEROS@<CRLF>
30 104371 124 063 011 .ASCII @T3 WRITE, WRITE CHECK ZEROS@<CRLF>
31 104425 124 064 011 .ASCII @T4 WRITE, WRITE CHECK ZEROS W/ WCE ERROR@<CRLF>
32 104476 124 065 011 .ASCII @T5 WRITE, READ ONES@<CRLF>
33 104522 124 066 011 .ASCII @T6 WRITE, WRITE CHECK ONES@<CRLF>
34 104555 124 067 011 .ASCII @T7 WRITE, WRITE CHECK ONES W/ WCE ERROR@<CRLF>
35 104625 124 061 060 .ASCII @T10 WRITE, WRITE CHECK MULTIPLE SECTORS@<CRLF>
36 104675 124 061 061 .ASCII @T11 WRITE, READ W/ IMPLIED SEEK@<CRLF>
37 104735 124 061 062 .ASCII @T12 WRITE, WRITE CHECK W/ HEAD SWITCHING@<CRLF>
38 105006 124 061 063 .ASCII @T13 WRITE, WRITE CHECK W/ MID-TRANSFER SEEK@<CRLF>
39 105062 124 061 064 .ASCII @T14 WRITE, READ W/ HCE ERROR@<CRLF>
40 105117 124 061 065 .ASCII @T15 WRITE, READ W/ HCI & SSEI@<CRLF>
41 105155 124 061 066 .ASCII @T16 WRITE, READ W/ IVC ERROR@<CRLF>
42 105212 124 061 067 .ASCII @T17 WRITE, READ W/ ABORT@<CRLF>
43 105243 124 062 060 .ASCII @T20 WRITE, READ EARLY PEAK SHIFT@<CRLF>
44 105304 124 062 061 .ASCII @T21 WRITE, READ EACH TRACK W/ MIXED PEAK SHIFT@<CRLF>
45 105363 124 062 062 .ASCII @T22 READ, WRITE CHECK MULTIPLE SECTORS IN OFFSET MODE@<CRLF>
46 105451 124 062 063 .ASCII @T23 FORMAT FE CYLINDERS@<CRLF>
47 105501 200 .ASCII <CRLF>
48 105502 117 120 105 .ASCII @OPERATIONAL SWITCH SETTINGS@<CRLF>
49 105536 055 055 055 .ASCII @-----@<CRLF>
50 105572 123 127 111 .ASCII @SWITCH USE@<CRLF>
51 105607 055 055 055 .ASCII @-----@<CRLF>
52 105644 040 040 061 .ASCII @ 15 HALT ON ERROR@<CRLF>
53 105670 040 040 061 .ASCII @ 14 LOOP ON TEST@<CRLF>
54 105713 040 040 061 .ASCII @ 13 INHIBIT ERROR TYPEOUTS@<CRLF>
55 105750 040 040 061 .ASCII @ 12 @<CRLF>
56 105757 040 040 061 .ASCII @ 11 INHIBIT ITERATIONS@<CRLF>
57 106010 040 040 061 .ASCII @ 10 BELL ON ERROR@<CRLF>
```

ERROR MESSAGE STRINGS

58	106034	040	040	040	.ASCII	@	9	LOOP ON ERROR@<CRLF>
59	106060	040	040	040	.ASCII	@	8	LOOP ON TEST IN SWR<7:0>@<CRLF>
60	106117	040	040	040	.ASCII	@	7	TN128@<CRLF>
61	106133	040	040	040	.ASCII	@	6	TN64@<CRLF>
62	106146	040	040	040	.ASCII	@	5	TN32@<CRLF>
63	106161	040	040	040	.ASCII	@	4	TN16@<CRLF>
64	106174	040	040	040	.ASCII	@	3	TN8@<CRLF>
65	106206	040	040	040	.ASCII	@	2	TN4@<CRLF>
66	106220	040	040	040	.ASCII	@	1	TN2@<CRLF>
67	106232	040	040	040	.ASCIZ	@	0	TN1@<CRLF>
68								
69		000200			.END		200	

ABASE = 176700	ATNMSK= 000377	BUFONE 104254	EBL = 020000	EH344 103376
ACDW1 = 000000	ATNTBL 067344	BUFTWO 105260	ECH = 000100	EH353 103534
ACDW2 = 000000	AUNIT = 000000	CC = 004000	ECI = 004000	EMS1 074442
ACKSTS 051026	AUSWR = 000000	CH = 002000	ECRC = 001000	EMS10 074776
ACPUOP= 000000	AVECT1= 120254	CHGADR 001330	EDT1 074264	EMS100 077216
ADDW0 = 000000	AVECT2= 000000	CHRCNT 063467	EDT110 074302	EMS101 077244
ADDW1 = 000000	A16 = 000400	CKSWR = 104410	EDT111 074304	EMS102 077272
ADDW10= 000000	A17 = 001000	CLKADR 001522	EDT114 074306	EMS103 077321
ADDW11= 000000	BACK = 000001	CLKVCT 001524	EDT2 074274	EMS104 077330
ADDW12= 000000	BADSCT 034762	CLR = 000040	EDT223 074310	EMS105 077357
ADDW13= 000000	BADTMO 005344	CLRSTS 050146	EDT336 074320	EMS106 077406
ADDW14= 000000	BAI = 000010	CMNSTA 007332	EDT337 074330	EMS11 075040
ADDW15= 000000	BB00 = 000001	CMPBUF 037462	EDT344 074340	EMS110 077425
ADDW2 = 000000	BB01 = 000002	CMPERR 046124	EDT353 074352	EMS111 077454
ADDW3 = 000000	BB02 = 000004	CNSL01 066521	ED1 104050	EMS112 077465
ADDW4 = 000000	BB03 = 000010	CNSL02 066531	ED110 104056	EMS113 077551
ADDW5 = 000000	BB04 = 000020	CNSL03 066573	ED111 104062	EMS114 077601
ADDW6 = 000000	BB05 = 000040	CNSL04 066602	ED114 104070	EMS115 077625
ADDW7 = 000000	BB06 = 000100	CNSL07 066636	ED223 104100	EMS116 077630
ADDW8 = 000000	BB07 = 000200	CNSL08 067000	ED336 104110	EMS117 077660
ADDW9 = 000000	BB08 = 000400	CNSL09 067001	ED337 104122	EMS12 075051
ADEVCT= 000000	BB09 = 001000	CNTCLR 050030	ED353 104134	EMS120 077702
ADEVM = 000000	BIT0 = 000001	COMMA 066105	EECC = 000020	EMS121 077702
ADR = 000001	BIT00 = 000001	CONT = 000100	EFT1 074354	EMS122 077745
AENV = 000000	BIT01 = 000002	CPSAVE 062640	EFT110 074372	EMS123 100002
AENVM = 000000	BIT02 = 000004	CR = 000015	EFT111 074374	EMS124 100045
AFATAL= 000000	BIT03 = 000010	CRLF = 000200	EFT114 074376	EMS125 100077
ALL 066074	BIT04 = 000020	CTLFG 001326	EFT2 074364	EMS126 100142
AMADR1= 000000	BIT05 = 000040	CYLSK= 001777	EFT223 074400	EMS127 100205
AMADR2= 000000	BIT06 = 000100	DBCK = 100000	EFT336 074410	EMS13 075112
AMADR3= 000000	BIT07 = 000200	DBEN = 040000	EFT337 074420	EMS130 100244
AMADR4= 000000	BIT08 = 000400	DBL = 002000	EFT344 074430	EMS131 100302
AMAMS1= 000000	BIT09 = 001000	DCK = 100000	EFT353 074440	EMS132 100342
AMAMS2= 000000	BIT1 = 000002	DDISP = 177570	EF110 104226	EMS133 100366
AMAMS3= 000000	BIT10 = 002000	DEBL = 020000	EF111 104227	EMS134 100411
AMAMS4= 000000	BIT11 = 004000	DEVSEL 046336	EF114 104231	EMS135 100453
AMSGAD= 000000	BIT12 = 010000	DISPLA 001156	EF336 104234	EMS136 100526
AMSGLG= 000000	BIT13 = 020000	DISPRE 000174	EF337 104240	EMS137 100553
AMSGTY= 000000	BIT14 = 040000	DLT = 100000	EHT1 074140	EMS14 075123
AMTYP1= 000000	BIT15 = 100000	DMD = 000001	EHT110 074162	EMS140 100610
AMTYP2= 000000	BIT2 = 000004	DPE = 000010	EHT111 074166	EMS141 100631
AMTYP3= 000000	BIT3 = 000010	DPEHI = 040000	EHT114 074172	EMS142 100657
AMTYP4= 000000	BIT4 = 000020	DPELO = 020000	EHT2 074152	EMS143 100674
AOE = 001000	BIT5 = 000040	DPR = 000400	EHT223 074176	EMS144 100722
APASS = 000000	BIT6 = 000100	DRIVES 067176	EHT256 074210	EMS145 100732
APE = 100000	BIT7 = 000200	DRQ = 004000	EHT336 074222	EMS146 100761
APRIOR= 000000	BIT8 = 000400	DRVCLR= 000010	EHT337 074234	EMS147 101000
APTCSU= 000040	BIT9 = 001000	DRVSTS 053364	EHT344 074246	EMS15 075134
APTENV= 000001	BLNKS1 067241	DRY = 000200	EHT353 074260	EMS150 101015
APTSIZ= 000200	BLNKS2 067240	DSWR = 177570	EH1 103004	EMS151 101033
APTSPO= 000100	BLNKS3 067237	DTASTS 054166	EH110 103023	EMS152 101057
ARGS = 000004	BLNKS4 067236	DTE = 010000	EH111 103032	EMS153 101103
ASNDA 001520	BOTADR 063464	DTO = 010000	EH114 103051	EMS154 101125
ASNDC 001516	BOTFLG 063466	DULPRT= 024026	EH223 103100	EMS155 101141
ASWREG= 000000	BPTVEC= 000014	DVA = 004000	EH256 103126	EMS156 101161
ATA = 100000	BSE = 100000	DVC = 000200	EH336 103202	EMS157 101177
ATESTN= 000000	BUFFER 104254	EARLY 067670	EH337 103241	EMS16 075156

SYMBOL TABLE

EMS160	101214	EMS33	075542	EMT114	071254	EMT177	072142	EMT260	072712
EMS161	101231	EMS34	075570	EMT115	071255	EMT2	070006	EMT261	072724
EMS162	101261	EMS35	075641	EMT116	071266	EMT20	070136	EMT262	072744
EMS163	101261	EMS36	075670	EMT117	071276	EMT200	072144	EMT263	072754
EMS164	101305	EMS37	075717	EMT12	070062	EMT201	072156	EMT264	072764
EMS165	101366	EMS4	074571	EMT120	071306	EMT202	072170	EMT265	073004
EMS166	101402	EMS40	075745	EMT121	071316	EMT203	072202	EMT266	073024
EMS167	101427	EMS41	075774	EMT122	071326	EMT204	072214	EMT267	073036
EMS17	075206	EMS42	076022	EMT123	071336	EMT205	072232	EMT27	070226
EMS170	101454	EMS43	076051	EMT124	071346	EMT206	072242	EMT270	073054
EMS171	101503	EMS44	076100	EMT125	071356	EMT207	072252	EMT271	073070
EMS172	101536	EMS45	076153	EMT126	071366	EMT21	070146	EMT272	073106
EMS173	101556	EMS46	076216	EMT127	071400	EMT210	072264	EMT273	073124
EMS174	101573	EMS47	076245	EMT13	070070	EMT211	072272	EMT274	073142
EMS175	101601	EMS5	074634	EMT130	071412	EMT212	072306	EMT275	073160
EMS176	101627	EMS50	076274	EMT131	071424	EMT213	072322	EMT276	073172
EMS177	101656	EMS51	076323	EMT132	071436	EMT214	072332	EMT277	073206
EMS2	074511	EMS52	076351	EMT133	071450	EMT215	072352	EMT3	070014
EMS20	075246	EMS53	076363	EMT134	071462	EMT216	072364	EMT30	070236
EMS200	101700	EMS54	076375	EMT135	071474	EMT217	072374	EMT300	073224
EMS201	101715	EMS55	076417	EMT136	071506	EMT22	070156	EMT301	073244
EMS202	101763	EMS56	076446	EMT137	071520	EMT220	072404	EMT302	073266
EMS203	102013	EMS57	076523	EMT14	070102	EMT221	072414	EMT303	073300
EMS204	102026	EMS6	074664	EMT140	071530	EMT222	072424	EMT304	073312
EMS205	102054	EMS60	076551	EMT141	071540	EMT223	072434	EMT305	073324
EMS206	102066	EMS61	076564	EMT142	071550	EMT224	072444	EMT306	073336
EMS207	102113	EMS62	076613	EMT143	071560	EMT225	072460	EMT307	073346
EMS21	075271	EMS63	076631	EMT144	071570	EMT226	072500	EMT31	070246
EMS210	102140	EMS64	076657	EMT145	071600	EMT227	072510	EMT310	073366
EMS211	102151	EMS65	076675	EMT146	071610	EMT23	070166	EMT311	073400
EMS212	102167	EMS66	076743	EMT147	071620	EMT230	072524	EMT312	073412
EMS213	102212	EMS67	077013	EMT15	070110	EMT231	072526	EMT313	073424
EMS214	102235	EMS7	074731	EMT150	071630	EMT232	072530	EMT314	073444
EMS215	102253	EMS70	077040	EMT151	071640	EMT233	072532	EMT315	073456
EMS216	102274	EMS71	077052	EMT152	071652	EMT234	072534	EMT316	073470
EMS217	102324	EMS72	077065	EMT153	071664	EMT235	072536	EMT317	073502
EMS22	075314	EMS73	077075	EMT154	071702	EMT236	072540	EMT32	070256
EMS220	102357	EMS74	077112	EMT155	071720	EMT237	072542	EMT320	073512
EMS221	102377	EMS75	077131	EMT156	071732	EMT24	070176	EMT321	073522
EMS222	102447	EMS76	077137	EMT157	071744	EMT240	072544	EMT322	073532
EMS223	102500	EMS77	077170	EMT16	070116	EMT241	072546	EMT323	073540
EMS224	102555	EMTVEC=	000030	EMT160	071756	EMT242	072550	EMT324	073550
EMS225	102627	EMT1	070002	EMT161	071766	EMT243	072552	EMT325	073562
EMS226	102652	EMT10	070052	EMT162	072000	EMT244	072554	EMT326	073574
EMS227	102701	EMT100	071056	EMT163	072012	EMT245	072556	EMT327	073612
EMS23	075330	EMT101	071074	EMT164	072022	EMT246	072560	EMT33	070266
EMS230	102712	EMT102	071112	EMT165	072030	EMT247	072570	EMT330	073624
EMS231	102741	EMT103	071122	EMT166	072036	EMT25	070206	EMT331	073634
EMS232	102757	EMT104	071134	EMT167	072044	EMT250	072602	EMT332	073646
EMS24	075356	EMT105	071152	EMT17	070126	EMT251	072616	EMT333	073660
EMS25	075405	EMT106	071162	EMT170	072052	EMT252	072624	EMT334	073676
EMS26	075422	EMT107	071172	EMT171	072064	EMT253	072632	EMT335	073714
EMS27	075443	EMT11	070056	EMT172	072074	EMT254	072650	EMT336	073734
EMS3	074526	EMT110	071212	EMT173	072104	EMT255	072660	EMT337	073744
EMS30	075454	EMT111	071224	EMT174	072114	EMT256	072670	EMT34	070276
EMS31	075464	EMT112	071232	EMT175	072126	EMT257	072700	EMT340	073754
EMS32	075513	EMT113	071240	EMT176	072134	EMT26	070216	EMT341	073766

SYMBOL TABLE

RMOF = 000032	STSD4 104214	TST12 020712	\$BELL 001212	\$ILLUP 065522
RMOFI 001370	STSF 104245	TST13 021734	\$BIN 060460	\$INTAG 001151
RMOFO 001444	STSH1 103610	TST14 022546	\$CDW1 001302	\$ITEMB 001130
PMR = 000004	STSH2 103665	TST15 024416	\$CDW2 001304	\$LF 001220
RMSN = 000030	STSH3 103754	TST16 025720	\$CHARC 061464	\$LFLG 066003
RMSNI 001366	STSH4 104012	TST17 026740	\$CKSWR 064170	\$LPADR 001122
RMSNO 001442	SWR 001154	TST2 010076	\$CMTAG 001114	\$LPERR 001124
RMWC = 000002	SWREG 000176	TST20 027656	\$CM3 = 000000	\$MADR1 001254
RMWCI 001340	SWO = 000001	TST21 030664	\$CM4 = 000005	\$MADR2 001260
RMWCO 001414	SWO0 = 000001	TST22 031712	\$CNTLC 065066	\$MADR3 001264
RQA = 100000	SW01 = 000002	TST23 033074	\$CNTLG 065100	\$MADR4 001270
RQB = 040000	SW02 = 000004	TST3 011104	\$CNTLU 065073	\$MAIL 001222
RTC = 000016	SW03 = 000010	TST4 012062	\$CPUOP 001250	\$MAMS1 001252
R6 = 000006	SW04 = 000020	TST5 013256	\$CRLF 001217	\$MAMS2 001256
R7 = 000007	SW05 = 000040	TST6 014264	\$DBLK 060676	\$MAMS3 001262
SADMSK= 000377	SW06 = 000100	TST7 015242	\$DDW0 001306	\$MAMS4 001266
SAVREG= 104414	SW07 = 000200	TYPBN = 104406	\$DDW1 001310	\$MBADR 001102
SA1 = 000001	SW08 = 000400	TYPDS = 104405	\$DDW2 001312	\$MFLG 066002
SA16 = 000020	SW09 = 001000	TYPE = 104401	\$DDW3 001314	\$MNEW 065116
SA2 = 000002	SW1 = 000002	TYPDC = 104402	\$DDW4 001316	\$MSGAD 001236
SA4 = 000004	SW10 = 002000	TYPDN = 104404	\$DDW5 001320	\$MSGLG 001240
SAB = 000010	SW11 = 004000	TYPOS = 104403	\$DDW6 001322	\$MSGTY 001222
SC = 100000	SW12 = 010000	UNS = 040000	\$DDW7 001324	\$MSWR 065105
SCOPE = 000004	SW13 = 020000	UNTMSK= 000007	\$DEVCT 001232	\$MTYP1 001253
SCTMSG 066006	SW14 = 040000	UNTOFF 067155	\$DEVM 001300	\$MTYP2 001257
SCTMSK= 003700	SW15 = 100000	UNTON 067166	\$DOAGN 033766	\$MTYP3 001263
SCO = 000100	SW2 = 000004	UPE = 020000	\$DTBL 060666	\$MTYP4 001267
SC1 = 000200	SW3 = 000010	USE = 040000	\$ENDAD 033756	\$MXCNT 062152
SC2 = 000400	SW4 = 000020	USRFIL 107272	\$ENDCT 033614	\$NULL 001170
SC3 = 001000	SW5 = 000040	U0 = 000001	\$ENULL 033772	\$NWTST= 000001
SC4 = 002000	SW6 = 000100	U1 = 000002	\$ENV 001242	\$OCNT 061130
SEARCH= 000030	SW7 = 000200	U2 = 000004	\$ENVM 001243	\$OMODE 061132
SECERR 041760	SW8 = 000400	VV = 000100	\$EOP 033560	\$OVER 062136
SEEK = 000004	SW9 = 001000	WC = 000040	\$EOPCT 033606	\$PASS 001230
SEKSTS 046550	SYSTAT 067044	WCD = 000050	\$EOSP 033522	\$PASTM 001106
SHUT 033776	TADMSK= 177400	WCE = 040000	\$ERFLG 001117	\$POWER 065530
SHUT2 065130	TAG = 020000	WCEHI = 010000	\$ERMAX 001131	\$PURDN 065362
SIZCLK 040610	TAGADR= 001114	WCELO = 004000	\$ERROR 062250	\$PURMG 065516
SKI = 040000	TAP = 040000	WCF = 000040	\$ERRPC 001132	\$PURUP 065434
SNGPRT= 020026	TA1 = 000400	WCH = 000052	\$ERRTB 001604	\$QUES 001216
SSE = 000040	TA2 = 001000	WD = 000060	\$ERTTL 001126	\$RDCHR 064532
SSEI = 001000	TA4 = 002000	WH = 000062	\$ESCAP 001210	\$RDLIN 064622
SSF = 020000	TAB = 004000	WLE = 004000	\$ETABL 001242	\$RDOCT 065152
SSFEMB 001514	TBITVE= 000014	WRL = 004000	\$ETEND 001326	\$RDSZ = 000010
SSFIL 110300	TIMOUT 040732	XSIZ 006364	\$FATAL 001224	\$RESRE 060350
STACK = 001100	TKVEC = 000060	XXDP 001332	\$FFLG 066004	\$RM80 067062
STANDA 006654	TPVEC = 000064	Y 067234	\$FILLC 001172	\$RTNAD 033770
START 005434	TRAPVE= 000034	ZEROS 067456	\$FILLS 001171	\$SAVRE 060312
START1 005424	TRE = 040000	\$APTHD 001100	\$GDADR 001134	\$SAVR6 065526
START2 005440	TRTVEC= 000014	\$ATYC 065564	\$GDDAT 001140	\$SCOPE 061470
STCDRV 057606	TST = 010000	\$ATY1 065540	\$GET42 033746	\$SETUP= 000137
STIMER 041074	TSTNMB 063460	\$ATY3 065546	\$GTSWR 064260	\$STUP = 177777
STKLMT= 1.7774	TSTPRP 034032	\$ATY4 065556	\$GT42P 033742	\$SVLAD 062102
STOP 062222	TSTQUE 001466	\$AUTOB 001150	\$HD = 000000	\$SVPC = 000210
STSD1 104144	TST1 007676	\$BASE 001276	\$HIBTS 001100	\$STR = 167400
STSD2 104162	TST10 016440	\$BDADR 001136	\$HIOCT 065252	\$SWREG 001244
STSD3 104202	TST11 017466	\$BDDAT 001142	\$ICNT 001120	\$SWRMK= 000000

SYMBOL TABLE

\$SW08T 062154	\$TKS 001160	\$TPS 001164	\$TYPE 061134	\$VECT1 001272
\$TESTN 001226	\$TKSRV 063740	\$STRAP 065254	\$TYPEC 061346	\$VECT2 001274
\$TIMES 001206	\$TMP0 001174	\$STRAP2 065314	\$TYPEX 061466	\$XOFF = 000023
\$TKB 001162	\$TMP1 001176	\$STRP = 000016	\$TYPC 060732	\$XON = 000021
\$TKCNT 063660	\$TMP2 001200	\$STRPAD 065326	\$TYPON 060746	\$XTSTR 061512
\$TKINT 063670	\$TMP3 001202	\$STSM 001104	\$TYPOS 060706	\$SGET4= 000000
\$TKQEN= 063667	\$TMP4 001204	\$STSTM 001116	\$UNIT 001234	\$SSW08= 000024
\$TKQIN 063662	\$TN = 000024	\$TTYIN 065056	\$UNITM 001110	\$OFILL 061131
\$TKQOU 063664	\$TPB 001166	\$TYPBN 060406	\$USWR 001246	\$.SX = 001100
\$TKQSR 063666	\$TPFLG 001173	\$TYPDS 060462		

. ABS. 110376 000
 000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 62208 WORDS (243 PAGES)
 DYNAMIC MEMORY AVAILABLE FOR 70 PAGES
 CZRNFA.BIC,CZRNFAC=CZRNFADOC,CZRNFAC,[20,0]SYSMAC/M

	13-J82#	13-J85#	13-J89#	13-K02	13-K02#	13-K14#	13-K20#	13-K23#	13-K30#	13-K33#	13-K35#	13-K38#	13-K42#	13-K44#
	13-K46#	13-K58	13-K58#	13-K71#	13-K80#	13-K83#	13-K91#	13-K94#	13-K96#	13-K99#	13-L03#	13-L05#	13-L07#	13-L26#
	13-L40	13-L40#	13-L54#	13-L57#	13-L59#	13-L61#	13-L65#	13-L67#						
ASNDA	7-0#	16-307*	16-344	16-374*	16-377	16-380	16-382*	16-383*	16-384	16-386*	16-425			
ASNDC	7-0#	16-306*	16-343	16-387*	16-388	16-424								
ASWREG	6-0	6-0												
ATA	4-559#	25-134	25-135	25-137	28-161	28-162	28-197	28-200	32-145	32-146	32-185	32-188	50-58	50-59
	50-60	50-63	50-64	50-67	50-68	50-69	50-70	50-71	50-72	50-73	50-74	50-75	50-76	50-79
	50-80	50-83	50-84	50-87	50-88									
ATESTN	6-0	6-0												
ATNMSK	4-596#	33-55												
ATNTBL	10-78	10-106	10-110	11-97	12-17	51-3#								
AUNIT	6-0	6-0												
AUSWR	6-0	6-0												
AVECT1	4-783#	6-0	6-0											
AVECT2	6-0	6-0												
BACK	13-41	13-41#	13-52	13-52#	13-68	13-68#	13-71#	13-73#	13-76	13-76#	13-80	13-80#	13-80#	13-93
	13-93#	13-110	13-110#	13-113#	13-115#	13-118	13-118#	13-122	13-122#	13-122#	13-124	13-124#	13-124#	13-126
	13-126#	13-126#	13-139	13-139#	13-155	13-155#	13-158#	13-160#	13-163	13-163#	13-167	13-167#	13-167#	13-169
	13-169#	13-169#	13-171	13-171#	13-171#	13-175	13-175#	13-188	13-188#	13-199	13-199#	13-215	13-215#	13-218#
	13-220#	13-223	13-223#	13-227	13-227#	13-227#	13-240	13-240#	13-257	13-257#	13-260#	13-262#	13-265	13-265#
	13-269	13-269#	13-269#	13-271	13-271#	13-271#	13-273	13-273#	13-273#	13-286	13-286#	13-301	13-301#	13-304#
	13-306#	13-309	13-309#	13-313	13-313#	13-313#	13-315	13-315#	13-315#	13-317	13-317#	13-317#	13-330	13-330#
	13-341	13-341#	13-356	13-356#	13-359#	13-361#	13-364	13-364#	13-368	13-368#	13-368#	13-381	13-381#	13-398
	13-398#	13-401#	13-403#	13-406	13-406#	13-410	13-410#	13-410#	13-412	13-412#	13-412#	13-414	13-414#	13-414#
	13-428	13-428#	13-443	13-443#	13-446#	13-448#	13-451	13-451#	13-455	13-455#	13-455#	13-460	13-460#	13-460#
	13-488	13-488#	13-488#	13-504	13-504#	13-515	13-515#	13-533	13-533#	13-536#	13-538#	13-541	13-541#	13-545
	13-545#	13-545#	13-559	13-559#	13-576	13-576#	13-579#	13-581#	13-584	13-584#	13-588	13-588#	13-588#	13-590
	13-590#	13-590#	13-592	13-592#	13-592#	13-605	13-605#	13-621	13-621#	13-624#	13-626#	13-629	13-629#	13-633
	13-633#	13-633#	13-635	13-635#	13-635#	13-637	13-637#	13-637#	13-639	13-639#	13-652	13-652#	13-663	13-663#
	13-681	13-681#	13-684#	13-686#	13-689	13-689#	13-693	13-693#	13-693#	13-707	13-707#	13-724	13-724#	13-727#
	13-729#	13-732	13-732#	13-736	13-736#	13-736#	13-738	13-738#	13-738#	13-740	13-740#	13-740#	13-753	13-753#
	13-768	13-768#	13-771#	13-773#	13-776	13-776#	13-780	13-780#	13-780#	13-782	13-782#	13-782#	13-784	13-784#
	13-784#	13-797	13-797#	13-808	13-808#	13-826	13-826#	13-829#	13-831#	13-834	13-834#	13-838	13-838#	13-838#
	13-852	13-852#	13-869	13-869#	13-872#	13-874#	13-877	13-877#	13-881	13-881#	13-881#	13-883	13-883#	13-883#
	13-885	13-885#	13-885#	13-899	13-899#	13-914	13-914#	13-917#	13-919#	13-922	13-922#	13-926	13-926#	13-926#
	13-930	13-930#	13-930#	13-960	13-960#	13-960#	13-985	13-985#	13-988	13-988#	13-:06	13-:06#	13-:09#	13-:11#
	13-:14	13-:14#	13-:18	13-:18#	13-:18#	13-:40	13-:40#	13-:55	13-:55#	13-:58#	13-:60#	13-:63	13-:63#	13-:67
	13-:67#	13-:67#	13-:69	13-:69#	13-:69#	13-:71	13-:71#	13-:71#	13-:84	13-:84#	13-:99	13-:99#	13-:02#	13-:04#
	13-:07	13-:07#	13-:11	13-:11#	13-:11#	13-:13	13-:13#	13-:13#	13-:15	13-:15#	13-:15#	13-:31	13-:31#	13-:43
	13-:43#	13-:61	13-:61#	13-:64#	13-:66#	13-:69	13-:69#	13-:73	13-:73#	13-:73#	13-:86	13-:86#	13-:91	13-:91#
	13-:94#	13-:96#	13-:99	13-:99#	13-:99#	13-<03	13-<03#	13-<03#	13-<21	13-<21#	13-<24#	13-<27	13-<27#	13-<31
	13-<31#	13-<33	13-<33#	13-<33#	13-<35	13-<35#	13-<35#	13-<48	13-<48#	13-<53	13-<53#	13-<56#	13-<58#	13-<61
	13-<61#	13-<65	13-<65#	13-<65#	13-<83	13-<83#	13-<86#	13-<89	13-<89#	13-<93	13-<93#	13-<95	13-<95#	13-<95#
	13-<95#	13-<97	13-<97#	13-<97#	13-<99	13-<99#	13-33	13-33#	13-48	13-48#	13-51#	13-53#	13-56	13-56#
	13-60	13-60#	13-60#	13-78	13-78#	13-81#	13-83#	13-86	13-86#	13-95	13-95#	13-95#	13-97	13-97#
	13-97#	13-99	13-99#	13-99#	13->12	13->12#	13->16	13->16#	13->19#	13->21#	13->24	13->24#	13->28	13->28#
	13->28#	13->43	13->43#	13->46#	13->48#	13->51	13->51#	13->60	13->60#	13->60#	13->62	13->62#	13->62#	13->64
	13->64#	13->64#	13->98	13->98#	13-?16	13-?16#	13-?19#	13-?21#	13-?24	13-?24#	13-?33	13-?33#	13-?33#	13-?35
	13-?35#	13-?35#	13-?37	13-?37#	13-?37#	13-?50	13-?50#	13-?65	13-?65#	13-?68#	13-?70#	13-?73	13-?73#	13-?82
	13-?82#	13-?82#	13-?84	13-?84#	13-?84#	13-?86	13-?86#	13-?86#	13-206	13-206#	13-217	13-217#	13-241	13-241#
	13-244#	13-246#	13-249	13-249#	13-253	13-253#	13-253#	13-266	13-266#	13-283	13-283#	13-286#	13-288#	13-291
	13-291#	13-295	13-295#	13-295#	13-A14	13-A14#	13-A14#	13-A30	13-A30#	13-A30#	13-A43	13-A43#	13-A43#	13-A55
	13-A55#	13-A55#	13-A64	13-A64#	13-A64#	13-A76	13-A76#	13-A93	13-A93#	13-A96#	13-A98#	13-B01	13-B01#	13-B05
	13-B05#	13-B05#	13-B22	13-B22#	13-B22#	13-B38	13-B38#	13-B38#	13-B51	13-B51#	13-B51#	13-B63	13-B63#	13-B63#
	13-B72	13-B72#	13-B72#	13-B97	13-B97#	13-C08	13-C08#	13-C34	13-C34#	13-C37#	13-C39#	13-C42	13-C42#	13-C46

	13-C46#	13-C46#	13-C59	13-C59#	13-C77	13-C77#	13-C80#	13-C82#	13-C85	13-C85#	13-C89	13-C89#	13-C89#	13-D12
	13-D12#	13-D12#	13-D14	13-D14#	13-D14#	13-D27	13-D27#	13-D43	13-D43#	13-D46#	13-D48#	13-D51	13-D51#	13-D55
	13-D55#	13-D55#	13-D78	13-D78#	13-D78#	13-D80	13-D80#	13-D80#	13-D82	13-D82#	13-E11	13-E11#	13-E18	13-E18#
	13-E39	13-E39#	13-E42#	13-E44#	13-E47	13-E47#	13-E51	13-E51#	13-E51#	13-E56	13-E56#	13-E56#	13-E64	13-E64#
	13-E64#	13-E77	13-E77#	13-E99	13-E99#	13-F02#	13-F04#	13-F07	13-F07#	13-F11	13-F11#	13-F11#	13-F16	13-F16#
	13-F16#	13-F24	13-F24#	13-F24#	13-F44	13-F44#	13-F63	13-F63#	13-F66#	13-F69	13-F69#	13-F79#	13-F82	13-F82#
	13-F84	13-F84#	13-F84#	13-F86	13-F86#	13-F86#	13-F99	13-F99#	13-G18	13-G18#	13-G21#	13-G24	13-G24#	13-G35#
	13-G38	13-G38#	13-G40	13-G40#	13-G40#	13-G42	13-G42#	13-G42#	13-G55	13-G55#	13-G66	13-G66#	13-G82	13-G82#
	13-G85#	13-G87#	13-G90	13-G90#	13-G94	13-G94#	13-G94#	13-H07	13-H07#	13-H24	13-H24#	13-H27#	13-H29#	13-H32
	13-H32#	13-H36	13-H36#	13-H36#	13-H38	13-H38#	13-H38#	13-H40	13-H40#	13-H40#	13-H53	13-H53#	13-H69	13-H69#
	13-H72#	13-H74#	13-H77	13-H77#	13-H81	13-H81#	13-H81#	13-H83	13-H83#	13-H83#	13-H85	13-H85#	13-H85#	13-H87
	13-H87#	13-100	13-100#	13-112	13-112#	13-130	13-130#	13-133#	13-135#	13-138	13-138#	13-142	13-142#	13-142#
	13-155	13-155#	13-172	13-172#	13-175#	13-177#	13-180	13-180#	13-184	13-184#	13-184#	13-186	13-186#	13-186#
	13-188	13-188#	13-188#	13-J01	13-J01#	13-J17	13-J17#	13-J20#	13-J22#	13-J25	13-J25#	13-J29	13-J29#	13-J29#
	13-J31	13-J31#	13-J31#	13-J33	13-J33#	13-J33#	13-J35	13-J35#	13-J50	13-J50#	13-J61	13-J61#	13-J77	13-J77#
	13-J80#	13-J82#	13-J85	13-J85#	13-J89	13-J89#	13-J89#	13-K02	13-K02#	13-K14	13-K14#	13-K20	13-K20#	13-K23#
	13-K30	13-K30#	13-K33#	13-K35#	13-K38	13-K38#	13-K42	13-K42#	13-K42#	13-K44	13-K44#	13-K44#	13-K46	13-K46#
	13-K46#	13-K58	13-K58#	13-K71	13-K71#	13-K80	13-K80#	13-K83#	13-K91	13-K91#	13-K94#	13-K96#	13-K99	13-K99#
	13-L03	13-L03#	13-L03#	13-L05	13-L05#	13-L05#	13-L07	13-L07#	13-L07#	13-L26	13-L26#	13-L40	13-L40#	13-L54
	13-L54#	13-L57#	13-L59#	13-L61	13-L61#	13-L65	13-L65#	13-L65#	13-L67	13-L67#	13-L67#			
BADSCT	13-52	13-199	13-341	13-515	13-663	13-808	13-988	13-;43	13-017	13-C08	13-E11	13-G66	13-I12	13-J61
	13-L26	16-33#												
BADTM#	10-3#	10-25												
BAI	4-749#	25-556												
BB00	4-678#													
BB01	4-678#													
BB02	4-678#													
BB03	4-678#													
BB04	4-678#													
BB05	4-678#													
BB06	4-678#													
BB07	4-678#													
BB08	4-678#													
BB09	4-678#													
BIT0	4-492#	23-43												
BIT00	4-492	4-492#	4-504	4-551	4-569	4-588	4-625	4-643	4-678	4-752	4-770	41-1	41-1	42-1
	42-1													
BIT01	4-492	4-492#	4-503	4-550	4-587	4-624	4-642	4-678	4-752	4-769				
BIT02	4-492	4-492#	4-502	4-549	4-586	4-623	4-641	4-678	4-752	4-768				
BIT03	4-492	4-492#	4-501	4-548	4-585	4-622	4-640	4-678	4-690	4-749	4-767			
BIT04	4-492	4-492#	4-500	4-547	4-584	4-639	4-678	4-748						
BIT05	4-492	4-492#	4-499	4-583	4-621	4-638	4-678	4-689	4-747					
BIT06	4-492	4-492#	4-568	4-582	4-604	4-620	4-637	4-678	4-733	4-746	4-766			
BIT07	4-492	4-492#	4-567	4-581	4-603	4-619	4-636	4-661	4-678	4-688	4-732	4-745		
BIT08	4-492	4-492#	4-544	4-566	4-580	4-602	4-618	4-635	4-678	4-731	4-744	41-1		
BIT09	4-492	4-492#	4-543	4-565	4-579	4-601	4-617	4-634	4-660	4-678	4-730	4-743	41-1	41-1
	42-1	42-1												
BIT11	4-492#	16-312	17-26	25-576										
BIT10	4-492#	4-542	4-564	4-578	4-600	4-616	4-633	4-659	4-675	4-687	4-729	4-742	4-765	15-165
	42-1													
BIT11	4-492#	4-498	4-541	4-563	4-577	4-615	4-632	4-650	4-658	4-674	4-686	4-741	4-764	15-167
	41-1													
BIT12	4-492#	4-562	4-576	4-614	4-631	4-657	4-673	4-685	4-740	4-763	15-111			
BIT13	4-492#	4-561	4-575	4-613	4-630	4-649	4-672	4-684	4-696	4-728	4-739	4-762	42-1	
BIT14	4-492#	4-560	4-574	4-612	4-629	4-648	4-671	4-683	4-695	4-727	4-738	4-761	15-73	41-1
BIT15	4-492#	4-559	4-573	4-611	4-628	4-647	4-670	4-682	4-694	4-726	4-737	4-760	18-33	18-90

F
F
G
G
G
G
G

EMT213	8-423	53-141#
EMT214	8-426	53-142#
EMT215	8-429	53-143#
EMT216	8-432	53-144#
EMT217	8-435	53-145#
EMT22	8-54	53-20#
EMT220	8-438	53-146#
EMT221	8-441	53-147#
EMT222	8-444	53-148#
EMT223	8-447	53-149#
EMT224	8-450	53-150#
EMT225	8-453	53-151#
EMT226	8-456	53-152#
EMT227	8-459	53-153#
EMT23	8-57	53-21#
EMT230	8-462	53-154#
EMT231	8-465	53-155#
EMT232	8-468	53-156#
EMT233	8-471	53-157#
EMT234	53-158#	
EMT235	53-159#	
EMT236	53-160#	
EMT237	53-161#	
EMT24	8-60	53-22#
EMT240	53-162#	
EMT241	53-163#	
EMT242	53-164#	
EMT243	53-165#	
EMT244	53-166#	
EMT245	53-167#	
EMT246	8-504	53-168#
EMT247	8-507	53-169#
EMT25	8-63	53-23#
EMT250	8-510	53-170#
EMT251	8-513	53-171#
EMT252	8-516	53-172#
EMT253	8-519	53-173#
EMT254	8-522	53-174#
EMT255	8-525	53-175#
EMT256	8-528	53-176#
EMT257	8-531	53-177#
EMT26	8-66	53-24#
EMT260	8-534	53-178#
EMT261	8-537	53-179#
EMT262	8-540	53-180#
EMT263	8-543	53-181#
EMT264	8-546	53-182#
EMT265	8-549	53-183#
EMT266	8-552	53-184#
EMT267	8-556	53-185#
EMT27	8-69	53-25#
EMT270	8-559	53-186#
EMT271	8-563	53-187#
EMT272	8-566	53-188#
EMT273	8-569	53-189#
EMT274	8-573	53-190#

TY
TY
TY
UO
U1
U2
UN
UN
UN
UN
UN
UP
US
US
VV

WC
WC
WC
WC
WC
WC
WD

WH

WL
WR
XS
XX
Y
ZE

EMT37	8-93	53-33#																		
EMT4	8-12	53-6#																		
EMT40	8-96	53-34#																		
EMT41	8-99	53-35#																		
EMT42	8-102	53-36#																		
EMT43	8-105	53-37#																		
EMT44	8-108	53-38#																		
EMT45	8-111	53-39#																		
EMT46	8-114	53-40#																		
EMT47	8-117	53-41#																		
EMT5	8-15	53-7#																		
EMT50	8-120	53-42#																		
EMT51	8-123	53-43#																		
EMT52	8-126	53-44#																		
EMT53	8-130	53-45#																		
EMT54	8-133	53-46#																		
EMT55	8-136	53-47#																		
EMT56	8-139	53-48#																		
EMT57	8-142	53-49#																		
EMT6	8-18	53-8#																		
EMT60	8-146	53-50#																		
EMT61	8-150	53-51#																		
EMT62	8-154	53-52#																		
EMT63	8-157	53-53#																		
EMT64	8-160	53-54#																		
EMT65	8-163	53-55#																		
EMT66	8-166	53-56#																		
EMT67	8-169	53-57#																		
EMT7	8-21	53-9#																		
EMT70	8-172	53-58#																		
EMT71	8-175	53-59#																		
EMT72	8-178	53-60#																		
EMT73	8-182	53-61#																		
EMT74	8-185	53-62#																		
EMT75	8-188	53-63#																		
EMT76	8-191	53-64#																		
EMT77	8-194	53-65#																		
EMTVEC	4-492#	10-23*																		
ENRGDT	52-144#																			
EQUALS	49-4#																			
ERR	4-560#	25-80	25-82	25-98	25-132															
ERRNMB	43-40*	43-41*	43-44	43-49	43-56	43-152#														
ERROR	4-492#																			
ERRTYP	42-1	43-13#																		
ERRVEC	4-492#	10-23	10-23*	10-23*	10-25*	10-26*	13-5	13-5	13-6*	13-7*	13-20*	13-20*	13-24*	13-24*						
	20-35	20-35	20-39*	20-40*	20-70*	20-70*	21-29	21-29	21-33*	21-34*	21-63*	21-63*	22-3	22-3						
	22-4*	22-5*	22-11*	22-18*	22-18*	23-9	23-9	23-10*	23-11*	23-31*	23-31*	27-20	27-20	27-21*						
	27-22*	27-51*	27-51*	29-12	29-12	29-13*	29-14*	29-25*	29-25*	41-1	41-1	41-1*	41-1*	41-1*						
	41-1*	41-1*	42-1	42-1*	42-1*															
ERTY00	43-21	43-157#																		
ERTY01	43-38	43-158#																		
ERTY02	43-43	43-159#																		
ERTY03	43-45	43-160#																		
ERTY04	43-144	43-161#																		
ERTY05	43-31	43-162#																		
ESRC	4-632#																			

CO
EM
E

ES
GE
GE
MS
PL
NE
M
PC
PL
PL
RE
RC
SE
SE
SI

	13-A14#	13-A30	13-A30#	13-A30#	13-A43	13-A43#	13-A43#	13-A55	13-A55#	13-A55#	13-A64	13-A64#	13-A64#	13-A76
	13-A76#	13-A76#	13-A93	13-A93#	13-A93#	13-A96	13-A96#	13-A98	13-A98#	13-B01	13-B01#	13-B01#	13-B05	13-B05#
	13-B05#	13-B22	13-B22#	13-B22#	13-B38	13-B38#	13-B38#	13-B51	13-B51#	13-B51#	13-B63	13-B63#	13-B63#	13-B72
	13-B72#	13-B72#	13-B97	13-B97#	13-B97#	13-C08	13-C08#	13-C08#	13-C34	13-C34#	13-C34#	13-C37	13-C37#	13-C39
	13-C39#	13-C42	13-C42#	13-C42#	13-C46	13-C46#	13-C46#	13-C59	13-C59#	13-C59#	13-C77	13-C77#	13-C77#	13-C80
	13-C80#	13-C82	13-C82#	13-C85	13-C85#	13-C85#	13-C89	13-C89#	13-C89#	13-D12	13-D12#	13-D12#	13-D14	13-D14#
	13-D14#	13-D27	13-D27#	13-D27#	13-D43	13-D43#	13-D43#	13-D46	13-D46#	13-D48	13-D48#	13-D51	13-D51#	13-D51#
	13-D55	13-D55#	13-D55#	13-D78	13-D78#	13-D78#	13-D80	13-D80#	13-D80#	13-D82	13-D82#	13-D82#	13-E11	13-E11#
	13-E11#	13-E18	13-E18#	13-E18#	13-E39	13-E39#	13-E39#	13-E42	13-E42#	13-E44	13-E44#	13-E47	13-E47#	13-E47#
	13-E51	13-E51#	13-E51#	13-E56	13-E56#	13-E56#	13-E64	13-E64#	13-E64#	13-E77	13-E77#	13-E77#	13-E99	13-E99#
	13-E99#	13-F02	13-F02#	13-F04	13-F04#	13-F04#	13-F07	13-F07#	13-F07#	13-F11	13-F11#	13-F11#	13-F16	13-F16#
	13-F24	13-F24#	13-F24#	13-F44	13-F44#	13-F44#	13-F63	13-F63#	13-F63#	13-F66	13-F66#	13-F69	13-F69#	13-F69#
	13-F79	13-F79#	13-F82	13-F82#	13-F82#	13-F84	13-F84#	13-F84#	13-F86	13-F86#	13-F86#	13-F99	13-F99#	13-F99#
	13-G18	13-G18#	13-G18#	13-G21	13-G21#	13-G24	13-G24#	13-G24#	13-G35	13-G35#	13-G38	13-G38#	13-G38#	13-G40
	13-G40#	13-G40#	13-G42	13-G42#	13-G42#	13-G55	13-G55#	13-G55#	13-G66	13-G66#	13-G66#	13-G82	13-G82#	13-G82#
	13-G85	13-G85#	13-G87	13-G87#	13-G90	13-G90#	13-G90#	13-G94	13-G94#	13-G94#	13-H07	13-H07#	13-H07#	13-H24
	13-H24#	13-H24#	13-H27	13-H27#	13-H29	13-H29#	13-H32	13-H32#	13-H32#	13-H36	13-H36#	13-H36#	13-H38	13-H38#
	13-H38#	13-H40	13-H40#	13-H40#	13-H53	13-H53#	13-H53#	13-H69	13-H69#	13-H69#	13-H72	13-H72#	13-H74	13-H74#
	13-H77	13-H77#	13-H77#	13-H81	13-H81#	13-H81#	13-H83	13-H83#	13-H83#	13-H85	13-H85#	13-H85#	13-H87	13-H87#
	13-H87#	13-I00	13-I00#	13-I00#	13-I12	13-I12#	13-I12#	13-I30	13-I30#	13-I30#	13-I33	13-I33#	13-I35	13-I35#
	13-I38	13-I38#	13-I38#	13-I42	13-I42#	13-I42#	13-I55	13-I55#	13-I55#	13-I72	13-I72#	13-I72#	13-I75	13-I75#
	13-I77	13-I77#	13-I80	13-I80#	13-I80#	13-I84	13-I84#	13-I84#	13-I86	13-I86#	13-I86#	13-I88	13-I88#	13-I88#
	13-J01	13-J01#	13-J01#	13-J17	13-J17#	13-J17#	13-J20	13-J20#	13-J22	13-J22#	13-J25	13-J25#	13-J25#	13-J29
	13-J29#	13-J29#	13-J31	13-J31#	13-J31#	13-J33	13-J33#	13-J33#	13-J35	13-J35#	13-J35#	13-J50	13-J50#	13-J50#
	13-J61	13-J61#	13-J61#	13-J77	13-J77#	13-J77#	13-J80	13-J80#	13-J82	13-J82#	13-J85	13-J85#	13-J85#	13-J89
	13-J89#	13-J89#	13-K02	13-K02#	13-K02#	13-K14	13-K14#	13-K14#	13-K20	13-K20#	13-K20#	13-K23	13-K23#	13-K30
	13-K30#	13-K30#	13-K33	13-K33#	13-K35	13-K35#	13-K38	13-K38#	13-K38#	13-K42	13-K42#	13-K42#	13-K44	13-K44#
	13-K44#	13-K46	13-K46#	13-K46#	13-K58	13-K58#	13-K58#	13-K71	13-K71#	13-K71#	13-K80	13-K80#	13-K80#	13-K83
	13-K83#	13-K91	13-K91#	13-K91#	13-K94	13-K94#	13-K96	13-K96#	13-K99	13-K99#	13-K99#	13-L03	13-L03#	13-L03#
	13-L05	13-L05#	13-L05#	13-L07	13-L07#	13-L07#	13-L26	13-L26#	13-L26#	13-L40	13-L40#	13-L40#	13-L54	13-L54#
	13-L54#	13-L57	13-L57#	13-L59	13-L59#	13-L61	13-L61#	13-L61#	13-L65	13-L65#	13-L65#	13-L67	13-L67#	13-L67#
FMT16	4-657#	13-49	13-196	13-338	13-512	13-660	13-805	13-974	13-40	13-17	13->82	13-@14	13-A04	13-B12
	13-C05	13-C64	13-E08	13-F39	13-G63	13-I09	13-J58	13-L21	16-59	16-274	16-283	17-32	17-34	18-27
	25-447	28-59	34-183											
FNCDTB	25-126	25-442	50-55#											
FNCMSK	4-505#	33-17	34-345											
GENBUF	13-56	13-203	13-345	13-519	13-667	13-812	13-992	13-:30	13-:47	13-@21	13-C12	13-E15	13-G70	13-I16
	13-J65	13-L32	17-20#											
GET	13-76	13-118	13-163	13-223	13-265	13-309	13-364	13-406	13-451	13-470	13-541	13-584	13-629	13-689
	13-732	13-776	13-834	13-877	13-922	13-941	13-:14	13-:63	13-:07	13-:69	13-:99	13-<27	13-<61	13-<89
	13-=56	13-=86	13->24	13->51	13-?24	13-?73	13-@49	13-@91	13-B01	13-C42	13-C85	13-D51	13-E47	13-F07
	13-F69	13-F82	13-G24	13-G38	13-G90	13-H32	13-H77	13-I38	13-I80	13-J25	13-J85	13-K38	13-K99	13-L61
	15-47	15-90	15-114	15-143	15-170	15-201	16-75	16-96	16-128	16-162	16-191	20-31#		
GETBUF	7-0#	20-37												
GETINX	7-0#	13-470*	13-470*	13-941*	13-941*	19-:3	20-38							
GETSSF	16-270	16-444#												
GETSTS	13-71	13-113	13-158	13-218	13-260	13-304	13-359	13-401	13-446	13-536	13-579	13-624	13-684	13-727
	13-771	13-829	13-872	13-917	13-:09	13-:58	13-:02	13-:64	13-:94	13-<56	13-=51	13-=81	13->19	13->46
	13-?19	13-?68	13-@44	13-@86	13-A96	13-C37	13-C80	13-D46	13-E42	13-F02	13-F66	13-G21	13-G85	13-H27
	13-H72	13-I33	13-I75	13-J20	13-J80	13-K33	13-K94	13-L57	15-46	16-74	19-10#			
GNS	5-1	5-1	10-6	10-28	10-42	10-53	10-59	12-30	14-20	14-20	46-1	46-1	46-1	46-1
	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1
	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1
GO	4-504#	13-50	13-100	13-145	13-197	13-247	13-291	13-339	13-388	13-433	13-513	13-566	13-611	13-661
	13-714	13-758	13-806	13-859	13-904	13-982	13-:45	13-:89	13-:41	13-:89	13-<11	13-<51	13-<72	13-=37
	13-=65	13->14	13->33	13-?03	13-?55	13-@15	13-@73	13-A83	13-C06	13-C66	13-D32	13-E27	13-E86	13-F40

CROSS REFERENCE TABLE (CREF V04.00)

	13-F53	13-G08	13-G64	13-H14	13-H58	13-I10	13-I62	13-J07	13-J59	13-K15	13-K25	13-K75	13-K86	13-L44
	15-125	15-183	16-86	16-118	16-152	16-181	23-17	24-90	24-102	24-107	24-123	25-47	25-50	34-346
GTSWR	10-28	46-1#												
HCE	4-581#	4-590	13-A11	13-A17	13-B19	15-B25	13-C92	13-C95	13-D58	13-D61	16-221	25-375	25-380	25-395
	25-397	25-410	25-425	25-451	25-456	34-352	34-382	34-385	34-395	34-398	50-77	50-78	50-81	50-85
	50-86													
HCI	4-659#	13-C64	25-373	34-348										
HCRC	4-580#	4-590	16-221	25-382	34-352	34-356	34-359	34-395	34-398					
HELP	11-17	61-23#												
HT	4-492#	40-1	40-1	43-82										
IAE	4-578#	25-279	25-651	25-667	25-694	28-48	28-72	32-24	32-78	32-81	34-172	34-194	50-59	50-69
	50-77	50-78	50-81	50-82	50-85	50-86								
IBSAVE	42-1	42-1	42-1	42-1	42-1	42-1#	42-1*	42-1*	42-1*					
IDXMSK	4-720#	20-51	20-54	21-45	21-48									
IE	4-733#	4-766#												
ILF	4-588#	25-151	25-153	31-51	31-111	31-115	32-24	32-45	32-48	34-128	34-145	34-148	50-58	50-67
	50-68	50-70	50-71	50-72	50-73	50-74	50-75	50-76	50-79	50-80	50-83	50-84	50-87	50-88
ILF02	4-509#													
ILF24	4-519#													
ILF26	4-520#													
ILF30	4-524#													
ILF32	4-524#													
ILF34	4-524#													
ILF36	4-524#													
ILF40	4-524#													
ILF42	4-524#													
ILF44	4-524#													
ILF46	4-524#													
ILF54	4-527#													
ILF56	4-528#													
ILF64	4-531#													
ILF66	4-532#													
ILF74	4-535#													
ILF76	4-536#													
ILR	4-587#	31-51	31-97	31-101	32-232	32-236	32-239	34-128	34-131	34-134				
ILRG50	4-718#													
ILRG52	4-718#													
ILRG54	4-718#													
ILRG56	4-718#													
ILRG60	4-718#													
ILRG62	4-718#													
ILRG64	4-718#													
ILRG66	4-718#													
ILRG70	4-718#													
ILRG72	4-718#													
ILRG74	4-718#													
ILRG76	4-718#													
IOTVEC	4-492#	10-23*	10-23*											
IPCK0	4-770#													
IPCK1	4-769#													
IPCK2	4-768#													
IPCK3	4-767#													
IR	4-746#	30-56												
IVC	4-685#	13-E53	13-E60	13-F13	13-F19	25-194	25-195	28-90	28-213	32-92	32-99	32-102	32-171	34-111
	34-115	34-550	35-58	50-58	50-59	50-60	50-62	50-63	50-64	50-67	50-68	50-69	50-70	50-71
	50-72	50-73	50-74	50-75	50-76	50-77	50-78	50-79	50-80	50-81	50-82	50-83	50-84	50-85

REX	4-631#													
RG	4-629#													
RGDTPT	52-3#													
RH	4-534#	16-181												
RIP	4-516#													
RELEASE	4-513#													
RPIAS	4-704#													
RPMAS	7-0#	33-50	59-13											
RPMASO	7-0#													
RMBA	4-776#	13-12*	13-13	13-62	13-105	13-150	13-209	13-252	13-296	13-350	13-393	13-438	13-525	13-571
	13-616	13-673	13-719	13-763	13-818	13-864	13-909	13-998	15-:50	13-:94	13-:53	13-<16	13-<78	13-:41
	13-:73	13->38	13-?11	13-?60	13-@35	13-@78	13-A88	13-C26	13-C72	13-D38	13-E35	13-E94	13-F58	13-G13
	13-G76	13-H19	13-H64	13-I22	13-I67	13-J12	13-J71	13-K10	13-K67	13-L50	16-67			
RMBAE	4-779#													
RMBAEI	7-0#													
RMBAEO	7-0#													
RMBAI	7-0#	13-476	13-948	25-560	25-562	30-42	59-14							
RMBAO	7-0#	13-47*	13-98*	13-144*	13-194*	13-245*	13-336*	13-387*	13-510*	13-564*	13-610*	13-658*	13-712*	13-803*
	13-858*	13-980*	13-:26*	13-:38*	13-<10*	13-<73*	13-:20*	13->86*	13-@12*	13-@71*	13-A81*	13-C03*	13-C67*	13-D33*
	13-E06*	13-E87*	13-F37*	13-G61*	13-H13*	13-H59*	13-I07*	13-I60*	13-J06*	13-J56*	13-J97*	13-L23*	16-60*	16-246
	16-275*	16-279	16-282*	17-21	18-31	25-554	25-558							
RMCS1	4-700#	4-774#	10-89	13-?*	13-65	13-107	13-152	13-212	13-254	13-298	13-353	13-395	13-440	13-528
	13-573	13-618	13-676	13-721	13-765	13-821	13-866	13-911	13-:01	13-:52	13-:96	13-:56	13-<18	13-<80
	13-:44	13-:75	13->40	13-?13	13-?62	13-@38	13-@80	13-A90	13-C29	13-C74	13-D40	13-E36	13-E96	13-F60
	13-G15	13-G79	13-H21	13-H66	13-I25	13-I69	13-J14	13-J74	13-K17	13-K27	13-K77	13-K88	13-L51	15-126
	15-184	16-68	20-42	21-36	23-16	27-28								
RMCS1I	7-0#	16-208	24-65	24-67	24-69	24-86	24-88	24-91	24-102	24-106	24-108	24-120	24-122	24-124
	25-47	25-49	25-60	25-103	25-540	30-29	33-16	34-27	34-29	34-31	59-13			
RMCS1O	7-0#	13-50*	13-100*	13-145*	13-197*	13-247*	13-291*	13-339*	13-388*	13-433*	13-513*	13-566*	13-611*	13-661*
	13-714*	13-758*	13-806*	13-859*	13-904*	13-982*	13-:27*	13-:45*	13-:89*	13-:41*	13-:89*	13-<11*	13-<51*	13-<72*
	13-:22*	13-:37*	13-:65*	13->14*	13->33*	13->87*	13-?03*	13-?55*	13-@15*	13-@73*	13-A83*	13-C06*	13-C66*	13-D32*
	13-E09*	13-E27*	13-E86*	13-F40*	13-F53*	13-G08*	13-G64*	13-H14*	13-H58*	13-I10*	13-I62*	13-J07*	13-J59*	13-K15*
	13-K25*	13-K75*	13-K86*	13-L24*	13-L44*	15-125*	15-183*	16-86*	16-118*	16-152*	16-181*	16-312	17-26	25-27
	25-576	34-324	34-344											
RMCS2	4-777#	10-84*	10-85*	10-87	12-55*	12-56*	13-14	13-15*	13-16	13-17*	20-41	21-35	27-27*	27-29
	29-16*	29-18*												
RMCS2I	7-0#	13-457	13-462	13-464	13-928	13-932	13-934	24-47	24-72	24-74	24-75	25-95	25-166	25-267
	25-310	25-325	25-340	25-482	25-556	30-51	34-50	34-63	34-65	34-67	34-442	34-444	34-446	34-496
	34-498	34-500	59-13											
RMCS2O	7-0#													
RMCS3	4-780#													
RMCS3I	7-0#													
RMCS3O	7-0#													
RMDA	4-701#	13-61	13-102	13-147	13-208	13-249	13-293	13-349	13-390	13-435	13-524	13-568	13-613	13-672
	13-716	13-760	13-817	13-861	13-906	13-997	13-:47	13-:91	13-:52	13-<13	13-<75	13-:40	13-:70	13->35
	13-?08	13-?57	13-@34	13-@75	13-A85	13-C25	13-C69	13-D35	13-E31	13-E91	13-F55	13-G10	13-G75	13-H16
	13-H61	13-I21	13-I64	13-J09	13-J70	13-K07	13-K64	13-L46	16-63					
RMDAI	7-0#	25-628	25-699	59-14	59-16									
RMDAO	7-0#	13-46*	13-193*	13-335*	13-509*	13-657*	13-802*	13-979*	13-:37*	13-:16*	13->68*	13->80*	13->81*	13-?90*
	13-?91*	13-@11*	13-C02*	13-E05*	13-E13	13-F36*	13-G60*	13-I05*	13-J37*	13-J38	13-J55*	13-L19*	13-L71*	13-L72
	13-L75*	13-L76*	13-L77	13-L80*	16-57*	16-233*	16-238*	16-241*	16-242	16-248	16-250	16-273*	16-281*	16-307
	16-425*	17-24	25-588	25-589	25-628	28-54	28-57	28-61	28-65	34-178	34-181	34-185	34-189	
RMDB	4-778#	13-18*	13-19	13-470	13-941	19-20								
RMDBI	7-0#	13-472	13-941*	13-944										
RMDBO	7-0#													
RMDC	4-710#	13-60	13-103	13-149	13-207	13-250	13-295	13-348	13-391	13-437	13-523	13-569	13-615	13-671

SNGPRT	4-652#													
SSE	4-689#	13-=91	13->56	13-?29	13-?78	13-A27	13-A34	13-B35	13-B42	13-D06	13-D08	13-D72	13-D74	16-224
	16-231	25-458												
SSE1	4-660#	13-;17	13-;19	13->66	13->69	13-?88	13-?92	13-C64	13-L21	16-235	16-375	16-401	17-37	25-449
	25-599	25-624	25-626	25-637	28-63	34-187								
SSF	4-696#	13-A02	13-B10	13-L36										
SSFENB	7-0#	13-L34	16-338*	16-365*										
SSFIL	16-336	16-446	16-451	16-454	16-470	61-17#								
STACK	4-492#	10-23	13-2	13-33	13-180	13-322	13-496	13-644	13-789	13-968	13-;23	13-=09	13->73	13-?96
	13-887	13-D97	13-F29	13-G47	13-H92	13-J43	13-L15							
STANDA	10-66	11-3#												
START	5-1	10-17#	12-33	12-42	14-27									
START1	5-3	10-14#	13-28											
START2	10-15	10-18#												
STCDRV	35-27#													
STIMER	23-14	23-38#												
STKMT	4-492#													
STOP	41-1	41-5#												
STSD1	55-1	55-2	55-8	55-10	55-11	55-12	59-13#							
STSD2	55-1	55-2	55-8	55-10	55-11	55-12	59-14#							
STSD3	59-16#													
STSD4	55-1	55-2	55-8	55-10	55-11	55-12	59-17#							
STSF	56-1	56-1	56-1	56-2	56-2	56-2	56-8	56-8	56-8	56-10	56-10	56-10	56-11	56-11
	56-11	56-12	56-12	56-12	60-7#									
STSH1	54-1	54-2	54-8	54-9	54-11	54-12	54-13	58-21#						
STSH2	54-1	54-2	54-8	54-9	54-11	54-12	54-13	58-23#						
STSH3	58-25#													
STSH4	54-1	54-2	54-8	54-9	54-11	54-12	54-13	58-26#						
SW0	4-492#													
SW00	4-492#	4-492#												
SW01	4-492#	4-492#												
SW02	4-492#	4-492#												
SW03	4-492#	4-492#												
SW04	4-492#	4-492#												
SW05	4-492#	4-492#												
SW06	4-492#	4-492#												
SW07	4-492#	4-492#												
SW08	4-492#	4-492#												
SW09	4-492#	4-492#												
SW1	4-492#													
SW10	4-492#													
SW11	4-492#													
SW12	4-492#													
SW13	4-492#	16-260	43-14											
SW14	4-492#													
SW15	4-492#													
SW2	4-492#													
SW3	4-492#													
SW4	4-492#													
SW5	4-492#													
SW6	4-492#													
SW7	4-492#													
SW8	4-492#													
SW9	4-492#													
SWR	6-0#	10-23	10-23	10-23*	10-23*	10-23*	10-28	16-260	41-1	41-1	41-1	41-1	41-1	41-1
	41-1*	41-1*	41-1*	41-1*	42-1	42-1	42-1	42-1	42-1	43-14	44-1	44-1	44-1*	47-1

SWREG	47-1*														
SYSTAT	5-1#	10-23	10-28	44-1	44-1	44-1									
TA1	10-76	49-25#													
TA2	4-544#	12-57													
TA4	4-543#	13-46	13-193	13-335	13-509	13-657	13-802	13-979	13-:37	13-=16	13->68	13-a11	13-C02	13-E05	
TAB	13-F36	13-G60	13-J55	13-L19											
TADMSK	4-542#	12-57													
TAG	4-541#	12-57													
TAGADR	4-554#	25-594													
TAP	4-672#														
TBITVE	5-9#	6-0													
TIMOUT	4-648#														
	4-492#														
	13-73	13-115	13-160	13-220	13-262	13-306	13-361	13-403	13-448	13-538	13-581	13-626	13-686	13-729	
	13-773	13-831	13-874	13-919	13-:11	13-:60	13-:04	13-:66	13-:96	13-<24	13-<58	13-<86	13-=53	13-=83	
	13->21	13->48	13-?21	13-?70	13-a46	13-a88	13-A98	13-C39	13-C82	13-D48	13-E44	13-F04	13-F79	13-G35	
	13-G87	13-H29	13-H74	13-I35	13-I77	13-J22	13-J82	13-K23	13-K35	13-K83	13-K96	13-L59	15-136	15-194	
	16-95	16-127	16-161	16-190	23-9#										
TKVEC	4-492#	44-1*	44-1*												
TPVEC	4-492#														
TRAPVE	4-492#	10-23*	10-23*												
TRE	4-727#	16-208	24-90	24-107	24-123	25-102	25-104	25-540							
TRTVEC	4-492#														
TST	4-673#	30-103	33-83												
TST1	13-2#	41-1													
TST10	13-968#	41-1													
TST11	13-:23#	41-1													
TST12	13-=09#	41-1													
TST13	13->73#	41-1													
TST14	13-?96#	41-1													
TST15	13-887#	41-1													
TST16	13-D97#	41-1													
TST17	13-F29#	41-1													
TST2	13-33#	41-1													
TST20	13-G47#	41-1													
TST21	13-H92#	41-1													
TST22	13-J43#	41-1													
TST23	13-L15#	41-1													
TST3	13-180#	41-1													
TST4	13-322#	41-1													
TST5	13-496#	41-1													
TST6	13-644#	41-1													
TST7	13-789#	41-1													
TSTNMB	43-36*	43-37*	43-39	43-151#											
TSTPRP	13-41	13-93	13-139	13-188	13-240	13-286	13-330	13-381	13-428	13-504	13-559	13-605	13-652	13-707	
	13-753	13-797	13-852	13-899	13-985	13-:40	13-:84	13-:31	13-:86	13-<48	13-=33	13->12	13->98	13-?50	
	13-a06	13-a66	13-A76	13-B97	13-C59	13-D27	13-E18	13-E77	13-F44	13-F99	13-G55	13-H07	13-H53	13-I00	
	13-155	13-J01	13-J50	13-K02	13-K58	13-L40	15-38#								
TSTQUE	7-0#	12-8	12-9*	12-51	13-2	13-33	13-180	13-322	13-496	13-644	13-789	13-968	13-:23	13-=09	
	13->73	13-?96	13-887	13-D97	13-F29	13-G47	13-H92	13-J43	13-L15	14-11	14-13*	14-17	14-17*	27-24	
	29-17	30-54	33-53												
TYPBN	43-141	46-1#													
TYPDS	14-20	14-20	43-135	46-1#											
TYPE	10-6	10-28	10-42	10-48	10-53	10-59	10-76	10-80	10-82	10-96	10-102	10-105	10-109	10-117	
	10-120	10-121	10-122	10-129	11-11	11-16	11-17	11-19	11-20	11-28	11-32	11-34	11-40	11-44	
	11-48	11-54	11-61	11-62	11-64	11-69	11-75	11-86	11-87	11-92	11-100	12-3	12-6	12-7	

	12-14	12-25	12-30	12-60	12-61	13-52	13-199	13-341	13-515	13-663	13-808	13-988	13-:43	13-@17
	13-C08	13-E11	13-G66	13-I12	13-J61	13-L26	14-20	14-20	14-20	37-1	38-1	39-1	40-1	42-1
	42-1	43-20	43-21	43-31	43-32	43-38	43-43	43-45	43-53	43-96	43-102	43-106	43-118	43-124
	43-126	43-144	43-146	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1
	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1
TYPOC	10-8	11-33	11-47	43-138	44-1	46-1#								
TYPON	46-1#													
TYPOS	10-45	10-56	10-81	12-16	12-62	43-22	43-39	43-44	43-46	46-1#				
UO	4-752#													
U1	4-752#													
U2	4-752#													
UNS	4-574#	13-F48	13-G03	30-70	31-51	31-55	31-59	32-232	32-264	32-269	34-283	34-286	34-291	
UNTMSK	4-756#	24-48	24-50											
UNTOFF	10-109	49-31#												
UNTON	10-120	49-32#												
UPE	4-739#	25-266												
USE	4-695#	13-A06	13-B14	17-29										
USRF IL	16-279	16-282	16-333	61-12#										
VV	4-568#	15-122	16-115	25-192	28-96	28-161	28-162	28-211	28-216	31-23	31-26	32-106	32-145	32-146
	32-169	32-175	33-29	34-90	34-119	34-509	34-510	34-548	34-553	35-35	35-36	35-56	35-61	
WC	4-638#	30-80	33-70											
WCD	4-525#	13-291	13-433	13-758	13-904	13-:89	13->33	13-?55	13-K86					
WCE	4-738#	13-457	13-463	13-928	13-933	25-165	50-77	50-78						
WCEHI	4-763#													
WCELO	4-764#													
WCF	4-583#	4-590	25-236	34-483	34-486									
WCH	4-526#													
WD	4-529#	13-100	13-247	13-388	13-566	13-714	13-859	13-:27	13-:45	13-<11	13-@73	13-C66	13-E09	13-E27
	13-F40	13-F53	13-H14	13-162										
WH	4-530#	13-50	13-197	13-339	13-513	13-661	13-806	13-982	13-:41	13-@15	13-C06	13-G64	13-I10	13-J59
	13-L24	13-L44	34-346											
WLE	4-577#	4-590	25-217	25-221	25-234	25-249	25-264	34-283	34-315	34-319	34-327	50-81	50-82	
WRL	4-563#	25-219	34-322											
XSIZ	10-70#	11-71	11-101											
XXDP	7-0#	10-33*	10-36*	10-37	10-39*	10-44	10-55	10-113	10-115					
Y	49-36#													
ZEROS	13-54	13-201	13-343	13-990	13-@19	13-J63	52-38#							

SSCMRE	5-10#													
SSCMTM	5-10#	6-0	6-0	6-0	6-0	6-0								
SSESCA	4-492#													
SSNEWT	4-492#	13-2	13-33	13-180	13-322	13-496	13-644	13-789	13-968	13-:23	13-=09	13->73	13-?96	13-887
	13-D97	13-F29	13-G47	13-H92	13-J43	13-L15								
SSSET	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1	46-1#
SSSETM	10-23	10-23#												
SSSKIP	4-492#													
.SACT1	4-484#	5-5												
.SAPT8	4-484#	6-0	6-0#											
.SAPTH	4-484#	5-8												
.SAPTY	4-484#	48-1												
.SCATC	4-480#	5-1												
.SCMTA	4-481#	5-10												
.SEOP	4-481#	14-20												
.SERRO	4-481#	42-1												
.SPOWE	4-483#	47-1												
.SRDDE	4-482#													
.SRDOC	4-482#	45-1												
.SREAD	4-482#	44-1												
.SSAVE	4-483#	36-1												
.SSCOP	4-481#	41-1												
.SSIZE	4-483#													
.STRAP	4-483#	46-1												
.STYPB	4-482#	37-1												
.STYPD	4-482#	38-1												
.STYPE	4-481#	40-1												
.STYPO	4-482#	39-1												
.EQUAT	4-480#	4-492												
.HEADE	4-480#	4-488												
.SETUP	4-480#	4-785												
.SWRHI	4-480#	4-489												
.SWRLO	4-480#	4-489#	4-490											
CALCLR	4-192#													
CALSUB	4-206#	13-41	13-52	13-68	13-71	13-73	13-76	13-80	13-93	13-110	13-113	13-115	13-118	13-122
	13-124	13-126	13-139	13-155	13-158	13-160	13-163	13-167	13-169	13-171	13-175	13-188	13-199	13-215
	13-218	13-220	13-223	13-227	13-240	13-257	13-260	13-262	13-265	13-269	13-271	13-273	13-286	13-301
	13-304	13-306	13-309	13-313	13-315	13-317	13-330	13-341	13-356	13-359	13-361	13-364	13-368	13-381
	13-398	13-401	13-403	13-406	13-410	13-412	13-414	13-428	13-443	13-446	13-448	13-451	13-455	13-460
	13-488	13-504	13-515	13-533	13-536	13-538	13-541	13-545	13-559	13-576	13-579	13-581	13-584	13-588
	13-590	13-592	13-605	13-621	13-624	13-626	13-629	13-633	13-635	13-637	13-639	13-652	13-663	13-681
	13-684	13-686	13-689	13-693	13-707	13-724	13-727	13-729	13-732	13-736	13-738	13-740	13-753	13-768
	13-771	13-773	13-776	13-780	13-782	13-784	13-797	13-808	13-826	13-829	13-831	13-834	13-838	13-852
	13-869	13-872	13-874	13-877	13-881	13-883	13-885	13-899	13-914	13-917	13-917	13-922	13-926	13-930
	13-960	13-985	13-988	13-:06	13-:09	13-:11	13-:14	13-:18	13-:40	13-:55	13-:58	13-:60	13-:63	13-:67
	13-:69	13-:71	13-:84	13-:99	13-:02	13-:04	13-:07	13-:11	13-:13	13-:15	13-:31	13-:43	13-:61	13-:64
	13-:66	13-:69	13-:73	13-:86	13-:91	13-:94	13-:96	13-:99	13-<03	13-<21	13-<24	13-<27	13-<31	13-<33
	13-<35	13-<48	13-<53	13-<56	13-<58	13-<61	13-<65	13-<83	13-<86	13-<89	13-<93	13-<95	13-<97	13-<99
	13-=33	13-=48	13-=51	13-=53	13-=56	13-=60	13-=78	13-=81	13-=83	13-=86	13-=95	13-=97	13-=99	13->12
	13->16	13->19	13->21	13->24	13->28	13->43	13->46	13->48	13->51	13->60	13->62	13->64	13->98	13-?16
	13-?19	13-?21	13-?24	13-?33	13-?35	13-?37	13-?50	13-?65	13-?68	13-?70	13-?73	13-?82	13-?84	13-?86
	13-@06	13-@17	13-@41	13-@44	13-@46	13-@49	13-@53	13-@66	13-@83	13-@86	13-@88	13-@91	13-@95	13-A14
	13-A30	13-A43	13-A55	13-A64	13-A76	13-A93	13-A96	13-A98	13-B01	13-B05	13-B22	13-B38	13-B51	13-B63
	13-B72	13-B97	13-C08	13-C34	13-C37	13-C39	13-C42	13-C46	13-C59	13-C77	13-C80	13-C82	13-C85	13-C89
	13-D12	13-D14	13-D27	13-D43	13-D46	13-D48	13-D51	13-D55	13-D78	13-D80	13-D82	13-E11	13-E18	13-E39
	13-E42	13-E44	13-E47	13-E51	13-E56	13-E64	13-E77	13-E99	13-F02	13-F04	13-F07	13-F11	13-F16	13-F24

SKIP	4-492#													
SLASH	4-492#													
STARS	4-492#	5-5	5-8	5-8	5-8	5-0	6-0	6-0	13-2	13-2	13-33	13-33	13-35	13-87
	13-133	13-180	13-190	13-182	13-234	13-280	13-322	13-322	13-324	13-375	13-420	13-496	13-496	13-498
	13-552	13-599	13-644	13-644	13-646	13-700	13-747	13-789	13-789	13-791	13-845	13-891	13-968	13-968
	13-970	13-:33	13-:78	13-:23	13-:23	13-:25	13-:80	13-<42	13-=09	13-=09	13-=11	13->06	13->73	13->73
	13->75	13-?44	13-?96	13-?96	13-?98	13-@60	13-A70	13-B87	13-B87	13-B89	13-C53	13-D21	13-D97	13-D97
	13-D99	13-E71	13-F29	13-F29	13-F31	13-F93	13-G47	13-G47	13-G49	13-H01	13-H47	13-H92	13-n92	13-H94
	13-I49	13-195	13-J43	13-J43	13-J45	13-J98	13-K53	13-L15	13-L15	14-20	15-57	15-70	15-84	15-107
	15-138	15-160	15-196	16-212	16-298	16-302	25-115	25-529	25-531	36-1	37-1	38-1	39-1	40-1
	41-1	42-1	44-1	44-1	44-1	44-1	44-1	45-1	46-1	47-1	47-1	48-1		
SWRSU	4-492#	10-23	10-23#											
TAGS	4-103#	6-0												
TRMTRP	46-1#													
TYPBIN	4-492#													
TYPDEC	4-492#	14-20	14-20											
TYPNAM	4-480#	4-492#	10-28											
TYPNUM	4-492#													
TYPOCS	4-492#	10-81	12-16	12-62	13-22	43-39	43-44	43-46						
TYPOCT	4-492#	11-33	41-1											
TYPTXT	4-492#	10-6	10-42	10-53	10-59	12-30	14-20	14-20						
XPER	4-12#	8-3	8-6	8-9	8-12	8-15	8-18	8-21	8-24	8-27	8-30	8-33	8-36	8-39
	8-42	8-45	8-48	8-51	8-54	8-57	8-60	8-63	8-66	8-69	8-72	8-75	8-78	8-81
	8-84	8-87	8-90	8-93	8-96	8-99	8-102	8-105	8-108	8-111	8-114	8-117	8-120	8-123
	8-126	8-130	8-133	8-136	8-139	8-142	8-146	8-150	8-154	8-157	8-160	8-163	8-166	8-169
	8-172	8-175	8-178	8-182	8-185	8-188	8-191	8-194	8-197	8-200	8-203	8-206	8-209	8-212
	8-215	8-218	8-221	8-224	8-227	8-230	8-233	8-236	8-239	8-242	8-245	8-248	8-251	8-254
	8-257	8-260	8-263	8-266	8-269	8-272	8-275	8-278	8-281	8-284	8-287	8-290	8-293	8-296
	8-299	8-302	8-305	8-308	8-311	8-314	8-317	8-320	8-323	8-326	8-329	8-332	8-335	8-338
	8-341	8-344	8-347	8-351	8-354	8-357	8-360	8-363	8-366	8-369	8-372	8-375	8-378	8-381
	8-384	8-387	8-390	8-393	8-396	8-399	8-402	8-405	8-408	8-411	8-414	8-417	8-420	8-423
	8-426	8-429	8-432	8-435	8-438	8-441	8-444	8-447	8-450	8-453	8-456	8-459	8-462	8-465
	8-468	8-471	8-474	8-477	8-480	8-483	8-486	8-489	8-492	8-495	8-498	8-501	8-504	8-507
	8-510	8-513	8-516	8-519	8-522	8-525	8-528	8-531	8-534	8-537	8-540	8-543	8-546	8-549
	8-552	8-556	8-559	8-563	8-566	8-569	8-573	8-577	8-581	8-586	8-590	8-594	8-597	8-600
	8-603	8-606	8-609	8-612	8-615	8-618	8-621	8-624	8-627	8-630	8-633	8-636	8-639	8-642
	8-645	8-648	8-651	8-654	8-657	8-660	8-663	8-666	8-669	8-672	8-675	8-678	8-681	8-684
	8-687	8-690	8-693	8-696	8-699	8-702	8-705	8-708	8-711	8-714	8-717	8-720	8-723	