

RA60/80/81  
UDA50A KDA50Q

UDA50/KDA50-Q DRV EXE  
CZUDIAO

COPYRIGHT (c) 1984  
RH-T931A-MC FICHE  
FICHE 01 OF 02

FEB 1985  
Digital  
Made In USA

This microfiche card contains a grid of frames, each containing technical data for the RA60/80/81 UDA50A/KDA50Q. The data is organized into several columns and rows, with each frame containing a small table of values. The data includes various parameters such as frequency, voltage, and current, along with their units and ranges. The frames are arranged in a regular grid, with a small white tab visible at the bottom center of the card.

Frame	Parameter	Value	Unit
1	...	...	...
2	...	...	...
3	...	...	...
4	...	...	...
5	...	...	...
6	...	...	...
7	...	...	...
8	...	...	...
9	...	...	...
10	...	...	...
11	...	...	...
12	...	...	...
13	...	...	...
14	...	...	...
15	...	...	...
16	...	...	...
17	...	...	...
18	...	...	...
19	...	...	...
20	...	...	...
21	...	...	...
22	...	...	...
23	...	...	...
24	...	...	...
25	...	...	...
26	...	...	...
27	...	...	...
28	...	...	...
29	...	...	...
30	...	...	...
31	...	...	...
32	...	...	...
33	...	...	...
34	...	...	...
35	...	...	...
36	...	...	...
37	...	...	...
38	...	...	...
39	...	...	...
40	...	...	...
41	...	...	...
42	...	...	...
43	...	...	...
44	...	...	...
45	...	...	...
46	...	...	...
47	...	...	...
48	...	...	...
49	...	...	...
50	...	...	...
51	...	...	...
52	...	...	...
53	...	...	...
54	...	...	...
55	...	...	...
56	...	...	...
57	...	...	...
58	...	...	...
59	...	...	...
60	...	...	...
61	...	...	...
62	...	...	...
63	...	...	...
64	...	...	...
65	...	...	...
66	...	...	...
67	...	...	...
68	...	...	...
69	...	...	...
70	...	...	...
71	...	...	...
72	...	...	...
73	...	...	...
74	...	...	...
75	...	...	...
76	...	...	...
77	...	...	...
78	...	...	...
79	...	...	...
80	...	...	...
81	...	...	...
82	...	...	...
83	...	...	...
84	...	...	...
85	...	...	...
86	...	...	...
87	...	...	...
88	...	...	...
89	...	...	...
90	...	...	...
91	...	...	...
92	...	...	...
93	...	...	...
94	...	...	...
95	...	...	...
96	...	...	...
97	...	...	...
98	...	...	...
99	...	...	...
100	...	...	...

RA60/80/81  
UDA50A KDA50Q

UDA50/KDA50-Q DRW EXE  
CZUDIAO

COPYRIGHT (c) 1984  
AH-T931A-MC FICHE  
FICHE 02 OF 02

FEB 1985  
digital  
Made In USA

Microfiche grid containing multiple frames of data, including headers like 'PROGRAM NAME' and 'PROGRAM NUMBER'.

Vertical barcode or tracking mark.

IDENTIFICATION  
-----

PRODUCT CODE: AC-T930A-MC  
PRODUCT NAME: CZUDIAO UDA50A/KDA50Q DRIVE EXERCISER  
PRODUCT DATE: 7-OCT-1984  
MAINTAINER: ROGER OAKY  
AUTHOR: JOHN HERTZ

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1984 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DEC	DIBOL	RSX
DEC/CMS	EduSystem	UNIBUS
DECnet	IAS	VAX
DECsystem-10	MASSBUS	VMS
DECSYSTEM-20	PDP	VT
DECUS	PDT	Digital Logo
DECwriter	RSTS	

1  
3

.REM 8

TABLE OF CONTENTS

1.0	GENERAL INFORMATION . . . . .	5
1.1	PROGRAM ABSTRACT . . . . .	5
1.2	SYSTEM REQUIREMENTS . . . . .	6
2.0	OPERATING INSTRUCTIONS . . . . .	7
2.1	COMMANDS . . . . .	7
2.2	SWITCHES . . . . .	8
2.3	FLAGS . . . . .	9
2.4	HARDWARE QUESTIONS . . . . .	10
2.5	SOFTWARE QUESTIONS . . . . .	11
2.6	EXTENDED P-TABLE DIALOGUE . . . . .	13
2.7	QUICK START-UP PROCEDURE . . . . .	15
3.0	ERROR INFORMATION . . . . .	17
3.1	TYPES OF ERROR MESSAGES . . . . .	17
3.2	SPECIFIC ERROR MESSAGES . . . . .	19
3.2.1	MOST PROGRAM ERROR MESSAGES (00001 To 00999) . .	19

3.2.1.1	00002 - TWO UNITS SELECT SAME DRIVE . . . . .	19
3.2.1.2	00003 MORE THAN 4 DRIVES SELECTED ON THIS CONTROLLER . . . . .	20
3.2.1.3	00004 NOT ENOUGH ROOM IN MEMORY TO TEST THE UNITS SELECTED . . . . .	20
3.2.1.4	00006 - TABLE INCONSISTANCY ERROR . . . . .	20
3.2.1.5	00014 - CONTROLLER IS NOT SUPPORTED BY DIAGNOSTIC PROGRAM . . . . .	21
3.2.1.6	00030 - FATAL ERROR REPORTED BY CONTROLLER . . . . .	21
3.2.1.7	00031 - NO INTERRUPT RECEIVED FROM DM PROGRAM FOR 3 MINUTES . . . . .	23
3.2.1.8	00032 - UNKNOWN REQUEST RECEIVED FROM DM PROGRAM . . . . .	23
3.2.1.9	00033 - RESPONSE PACKET FROM CONTROLLER DOES NOT CONTAIN EXPECTED DATA . . . . .	24
3.2.1.10	00035 - DM PROGRAM ASKED FOR DATA ON UNKNOWN DRIVE . . . . .	24
3.2.1.11	00034 - NO INTERRUPT RECEIVED FROM CONTROLLER FOR 30 SECONDS . . . . .	25
3.2.1.12	00038 - MEMORY ERROR TRYING TO READ CONTROLLER REGISTERS . . . . .	25
3.2.1.13	00040 - FATAL CONTROLLER ERROR . . . . .	25
3.2.2	DM PROGRAM INFORMATIONAL MESSAGES . . . . .	26
3.2.2.1	ECC CORRECTABLE DATA . . . . .	26
3.2.2.2	INITIAL WRITE COMPLETE . . . . .	26
3.2.2.3	READ ONLY DRIVE, INITIAL WRITE WILL NOT BE PERFORMED . . . . .	26
3.2.2.4	THE AREA BEING TESTED HAS N BYTES/SECTOR . . . . .	27
3.2.2.5	DEVICE FATAL WILL CAUSE THE FOLLOWING DRIVES TO BE DROPPED . . . . .	27
3.2.3	DM PROGRAM ERROR MESSAGES (04000 TO 04999) . . . . .	28
3.2.3.1	4001 - ATTN ASSERTED DURING SEEK . . . . .	28
3.2.3.2	4002 - ATTN ASSERTED UNEXPECTEDLY . . . . .	28
3.2.3.3	4003 - SEEK DID NOT COMPLETE . . . . .	28
3.2.3.4	4004 - RCT AREA CORRUPTED . . . . .	29
3.2.3.5	4005 - HEADER NOT FOUND DURING WRITE . . . . .	29
3.2.3.6	4006 - SELECT TRACK AND WRITE NOT SENT . . . . .	30
3.2.3.7	4007 - ECC DETECTED ERROR . . . . .	30
3.2.3.8	4008 - ECC DETECTED ERROR, BUT CORRECTION FAILED . . . . .	30
3.2.3.9	4009 - ECC CORRECTIONS EXCEED THRESHOLD . . . . .	31
3.2.3.10	4010 - ECC CORRECTION SUCCEEDED, BUT EDC DETECTS ERROR . . . . .	31
3.2.3.11	4011 - READ DID NOT SUCCEED ON ANY RECOVERY LEVEL . . . . .	32
3.2.3.12	4012 - DATA COMPARISON FAILED . . . . .	32
3.2.3.13	4013 - DRIVE NOT ONLINE TO CONTROLLER, AND NOT SPINABLE . . . . .	33
3.2.3.14	4014 - UNABLE TO COMPLETE SEEK -- TRIED 3 TIMES . . . . .	34
3.2.3.15	4015 - SEEK REQUIRED N RETRIES BEFORE COMPLETING . . . . .	34
3.2.3.16	4016 - ERRORS DURING DRIVE INITIALIZATION AND SETUP . . . . .	34
3.2.3.17	4017 - NO VALID STATE FROM DRIVE . . . . .	34
3.2.3.18	4018 - ATTEMPT TO WRITE ON WRITE PROTECTED DRIVE . . . . .	35
3.2.3.19	4019 - HEADER NOT FOUND DURING READ . . . . .	36
3.2.3.20	4020 - SELECT TRACK AND READ LEVEL 1 CMD NOT SENT . . . . .	36

3.2.3.21	4021 - DRIVE NOT FORMATTED IN 512 BYTE MODE . . .	37
3.2.3.22	4021 - DRIVE NOT FORMATTED IN 512 OR 576 BYTE MODE . . . . .	37
3.2.3.23	4022 - COULD NOT READ FCT BLOCK ZERO . . . . .	37
3.2.3.24	4023 - UNABLE TO CONTINUE TESTING . . . . .	38
3.2.3.25	4024 - EDC DETECTED ERROR BUT ECC DID NOT . . . . .	39
3.2.3.26	4025 - WRITE ATTEMPTED MAXIMUM TIMES . . . . .	39
3.2.3.27	4026 - READ ATTEMPTED MAXIMUM TIMES . . . . .	39
3.2.3.28	4028 - BOTH READ ONLY <AND> WRITE ONLY BITS SET . . . . .	40
3.2.3.29	4029 - HEADER NOT FOUND DURING ERROR LEVEL RECOVERY . . . . .	40
3.2.3.30	4030 - ERROR DETECTED AFTER DRIVE WAS SPUN DOWN . . . . .	40
3.2.3.31	4034 - SERDES OVERRUN ERROR DURING READ . . . . .	41
3.2.3.32	4035 - DATA OR STATE CLOCK TIMEOUT DURING READ . . . . .	41
3.2.3.33	4036 - DATA SYNC TIMEOUT DURING READ . . . . .	42
3.2.3.34	4037 - R/W RDY DROPPED BEFORE/DURING READ . . . . .	42
3.2.3.35	4038 - RCVR RDY DROPPED BEFORE/DURING READ . . . . .	42
3.2.3.36	4040 - ALL COPIES OF RCT READ WITH ERROR . . . . .	43
3.2.3.37	4041 - COULD NOT FIND REPLACEMENT . . . . .	43
3.2.3.38	4042 - TIMEOUT WAITING FOR SECTOR OR INDEX PULSE . . . . .	44
3.2.3.39	4044 - SEEK OR HEAD SELECT ERROR DETECTED DURING WRITE . . . . .	44
3.2.3.40	4045 - SEEK OR HEAD SELECT ERROR DETECTED DURING READ . . . . .	44
3.2.3.41	4047 - DATA OR STATE CLOCK TIMEOUT DURING WRITE . . . . .	45
3.2.3.42	4048 - R/W RDY DROPPED BEFORE/DURING WRITE . . . . .	45
3.2.3.43	4049 - RCVR RDY DROPPED BEFORE/DURING WRITE . . . . .	46
3.2.3.44	4050 - BEGIN/END SET STARTING BLOCK NUMBER GREATER THAN ENDING BLOCK NUMBER . . . . .	46
3.2.3.45	4051 - THE BEGIN/END SETS OVERLAP . . . . .	46
3.2.3.46	4052 - BEGIN/END SET ENDING BLOCK NUMBER EXCEEDS MAXIMUM . . . . .	47
3.2.3.47	4053 - DUPLICATE BAD BLOCKS . . . . .	47
3.2.3.48	4054 - BAD BLOCK NUMBER EXCEEDS MAXIMUM . . . . .	47
3.2.3.49	4055 - STARTING CYLINDER GREATER THAN ENDING CYLINDER . . . . .	48
3.2.3.50	4056 - RANDOM AND SEQUENTIAL SEEKS CANNOT BE MIXED WITHIN A UNIT . . . . .	48
3.2.3.51	4057 - OVERFLOW WHEN CALCULATING THE L/DBN FROM THE GIVEN CYLINDER . . . . .	48
3.2.3.52	4058 - TRACK EXCEEDS MAXIMUM FOR DEVICE . . . . .	49
3.2.3.53	4058 - GROUP EXCEEDS MAXIMUM FOR DEVICE . . . . .	49
3.2.3.54	4059 - TWO IDENTICAL TRACKS . . . . .	49
3.2.3.55	4059 - TWO IDENTICAL GROUPS . . . . .	49
3.2.3.56	4062 - DBN COMPUTED FROM END CYLINDER GIVEN EXCEEDS MAXIMUM DBN NUMBER . . . . .	50
3.2.3.57	4063 - REAL TIME STATE RECEIVE ERROR DURING WRITE . . . . .	50
3.2.3.58	4064 - REAL TIME STATE RECEIVE ERROR DURING READ . . . . .	51
3.2.3.59	4068 - UNKNOWN ERROR CODE DURING WRITE . . . . .	51
3.2.3.60	4069 - UNKNOWN ERROR CODE DURING READ . . . . .	52
3.2.3.61	4070 - TIMEOUT OF SEND . . . . .	52
3.2.3.62	4071 - TIMEOUT OF RECEIVE . . . . .	52
3.2.3.63	4072 - FIRST WORD RECEIVED WAS NOT START FRAME . . . . .	53

3.2.3.64	4073 - FRAMING ERROR ON LEVEL 0 RECEIVE . . . . .	53
3.2.3.65	4074 - CHECKSUM ERROR ON LEVEL 0 RECEIVE . . . . .	54
3.2.3.66	4075 - BUFFER SIZE SMALLER THAN LEVEL 2 RESPONSE . . . . .	54
3.2.3.67	4076 - RESPONSE OF LEVEL 2 CMD NOT AS EXPECTED . . . . .	54
3.2.3.68	4077 - DRIVE NEVER DEASSERTED RECEIVER READY AFTER LEVEL 2 SEND . . . . .	55
3.2.3.69	4078 - UNKNOWN ERROR CODE RETURNED FROM LEVEL 2 RECEIVE . . . . .	55
3.2.4	SPECIAL DEVICE FATAL (05000) . . . . .	57
4.0	DM PROGRAM RETRY AND RECOVERY METHODS . . . . .	59
4.1	ECC ERRORS . . . . .	59
4.2	EDC ERRORS . . . . .	59
4.3	SDI LEVEL 2 AND ASYNCHRONOUS ERRORS . . . . .	60
4.3.1	PACKET ACKNOWLEDGE FAILURE . . . . .	60
4.3.2	LEVEL 2 COMMAND ERROR RESPONSES . . . . .	61
4.3.2.1	"DE" BIT SET . . . . .	62
4.3.2.2	"PE" OR "RE" BIT SET . . . . .	62
4.3.3	RECEIPT OF AN ERRONEOUS DRIVE RESPONSE . . . . .	63
4.3.4	SEEK COMPLETE TIMEOUT . . . . .	64
4.3.5	ASYNCHRONOUS DRIVE ERRORS . . . . .	65
4.3.5.1	DRIVE I/O ERRORS . . . . .	66
4.3.6	HEADER NOT FOUND (HEADER COMPARE ERROR) . . . . .	66
4.3.7	SEEK OR HEAD SELECT ERROR (POSITIONER ERROR) . . . . .	67
4.3.8	DATA SYNC TIMEOUT ERROR . . . . .	68
4.3.9	DATA OR STATE CLOCK TIMEOUT (LOSS OF DRIVE CLOCK) OR RECEIVER READY FAILURE (Loss Of Drive Receiver Ready) . . . . .	68
4.3.10	READ/WRITE READY DROPPED (LOSS OF DRIVE READ/WRITE READY) OR SERDES . . . . .	70
5.0	DEC STANDARD 166 EXCERPTS . . . . .	71
5.1	The Replacement And Caching Tables . . . . .	71
5.2	Replacement And Caching Table Format . . . . .	71
5.3	FCT STRUCTURE . . . . .	73
5.4	FCT SECTOR 0 CONTENTS . . . . .	75
6.0	PERFORMANCE AND PROGRESS REPORTS . . . . .	77
7.0	TEST SUMMARIES . . . . .	78
7.1	TEST 1 - DISK DRIVE EXERCISER . . . . .	78

## 1.0 GENERAL INFORMATION

### 1.1 PROGRAM ABSTRACT

This diagnostic program is provided for testing the UDA50-A or KDA50-Q Disk Controller and the associated disk drives. There is one test within this diagnostic:

Test # 1 - Disk Exerciser. Exercises the disk drives in a manner similar to normal operating systems. This test should be used to gain confidence in the reliability of the disk drive.

This program is designed to handle all future disk drives that are attached to the UDA50-A or KDA50-Q without modifying or rereleasing the program. This is possible because the disk drives are programmed to tell this diagnostic about all their characteristics that make them different from other drives, such as number of cylinders, sectors per cylinder, etc.

If this program is run on a system that does not support memory management, the program is limited to testing one controller and one drive at a time.

The following PDP-11 diagnostic programs are also provided for the UDA50-A or KDA50-Q disk subsystem:

CZUDHA0 - UDA50-A/KDA50-Q Basic Subsystem Diagnostic.

CZUDKA0 - UDA50-A/KDA50-Q Formatter.

This diagnostic has been written for use with the Diagnostic Runtime Services Software (Supervisor). These services provide the interface to the operator and to the software environment. For a complete description of the Runtime Services, refer to the XXDP User's Manual. There is a brief description of the Runtime Services in section 2 of this document.

This diagnostic can isolate many controller faults to either the processor module or the SDI module of the controller. Whenever a controller fault is detected and the fault can be isolated to one of the two controller modules, that module should be replaced.



## 1.2 SYSTEM REQUIREMENTS

This program was designed using the PDP-11 Diagnostic Runtime Services revision C. Run time environments are determined by the Runtime Services and may change as new versions of the Services are developed. This program requires the following:

- PDP-11 Unibus processor
- 28K words of memory (minimum)
- Console terminal
- XXDP+ load media containing this program
- One or more UDA50-A or KDA50-Q subsystems. The subsystem controller must be at the latest hardware and microcode revision level.
- Line clock - either Type L or P

The line clock is used for all timed loops in the program. If a clock exists on the system it should be enabled so it can interrupt the processor. The diagnostic will run on a system with no clock or with the clock disabled, but will hang whenever an event for which the program is waiting does not happen (i.e., a time-out error message will not result).

The XXDP+ system device does not need to remain on-line during the execution of this diagnostic.

## 2.0 OPERATING INSTRUCTIONS

This section contains a brief description of the Runtime Services. For detailed information, refer to the XXDP+ User's Manual (CHGUS).

### 2.1 COMMANDS

There are eleven legal commands for the Diagnostic Runtime Services (Supervisor). This section lists the commands and gives a very brief description of them. The XXDP+ User's Manual has more details.

COMMAND	EFFECT
-----	-----
START	Start the diagnostic from an initial state
RESTART	Start the diagnostic without initializing
CONTINUE	Continue at test that was interrupted (after ↑C)
PROCEED	Continue from an error halt
EXIT	Return to XXDP+ Monitor (XXDP+ OPERATION ONLY!)
ADD	Activate a unit for testing (all units are considered to be active at start time)
DROP	Deactivate a unit
PRINT	Print statistical information (see section 4.0)
DISPLAY	Type a list of all device information
FLAGS	Type the state of all flags (see section 2.3)
ZFLAGS	Clear all flags (see section 2.3)

A command can be recognized by the first three characters. So you may, for example, type "STA" instead of "START".

### 2.2 SWITCHES

There are several switches which are used to modify supervisor operation. These switches are appended to the legal commands. All of the legal switches are tabulated below with a brief description of each. In the descriptions below, a decimal number is designated by "DDDDD".

SWITCH	EFFECT
/TESTS:LIST	Execute only those tests specified in the list. List is a string of test numbers, for example - /TESTS:1:5:7-10. This list will cause tests 1,5,7,8,9,10 to be run. All other tests will not be run.
/PASS:DDDDD	Execute DDDDD passes (DDDDD = 1 to 64000)
/FLAGS:FLGS	Set specified flags. Flags are described in section 2.3.
/EOP:DDDDD	Report end of pass message after every DDDDD passes only. (DDDDD = 1 to 64000)
/UNITS:LIST	TEST/ADD/DROP only those units specified in the list. List example - /UNITS:0:5:10-12 use units 0,5,10,11,12 (unit numbers = 0-63).

Example of switch usage:

START/TESTS:1-5/PASS:1000/EOP:100

The effect of this command will be: 1) tests 1 through 5 will be executed, 2) all units will tested 1000 times and 3) the end of pass messages will be printed after each 100 passes only. A switch can be recognized by the first three characters. You may, for example, type "/TES:1-5" instead of "/TESTS:1-5".

Below is a table that specifies which switches can be used by each command.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

## 2.3 FLAGS

Flags are used to set up certain operational parameters such as looping on error. All flags are cleared at startup and remain cleared until explicitly set using the flag switch. Flags are also cleared after a START or RESTART command unless set using the flag switch. The ZFLAGS command may also be used to clear all flags. With the exception of the START, the RESTART and ZFLAGS commands, no commands affect the state of the flags; they remain set or cleared as specified by the last flag switch.

FLAG	EFFECT
-----	-----
HOE	Halt on error - control is returned to runtime services command mode
LOE	Loop on error
IER*	Inhibit all error reports
IBE*	Inhibit all error reports except first level (first level contains error type, number, PC, test and unit)
IXE*	Inhibit extended error reports (those called by PRINTX macro's)
PRI	Direct messages to line printer
PNT	Print test number as test executes
BOE	"BELL" on error
UAM	Unattended mode (no manual intervention)
ISR	Inhibit statistical reports
IDU	Inhibit program dropping of units
LOT	Loop on test

\*Error messages are described in section 3.1

See the XXDP+ User's Manual for more details on flags. You may specify more than one flag with the FLAG switch. For example, to cause the program to loop on error, inhibit error reports and type a "BELL" on error, you may use the following string:

```
/FLAGS:LOE:IER:BOE
```

2.4 HARDWARE QUESTIONS

When a diagnostic is STARTed, the Runtime Services will prompt the user for hardware information by typing "CHANGE HW (L) ?" . When you answer this question with a "Y", the Runtime Services will ask for the number of units (in decimal). You will then be asked the following questions for each unit. When you answer this question with an "N", the Runtime Services will use the answers built into the program by the SETUP utility (see chapter 6 of the XXDP+ User's Manual). If you have never run the SETUP utility on this program file, the default values listed below (just before the question mark) will be used.

CSR ADDRESS OF CONTROLLER (C) 172150 ?

Answer with the CSR address of one controller as addressed by the processor with memory management turned off (i.e., an even 16-bit address in the range of 160000 to 177774).

DRIVE # (D) 0 ?

Answer with the drive number of the drive you wish to test. This is the number which appears on the "unit plug" on the front of the disk drive. A maximum of four disk drives may be tested on one controller at a time (controller configuration limit).

EXERCISE ON CUSTOMER DATA AREA (L) N ?

Answer "N" to have this test run on the diagnostic area of the disk. Answer "Y" to run on the customer data area. A "Y" answer will destroy any customer data that may be on the disk. A warning message will be printed before testing begins if this question is answered "Y".

CUSTOMER DATA WILL BE DESTROYED ON:  
UNIT      CONTROLLER AT      DRIVE  
  xx            xxxxxxx            xxx

Unless the diagnostic is being run in unattended mode (i.e., START/FLAG:UAM command), a confirmation will also be required as follows:

ARE YOU SURE CUSTOMER DATA CAN BE DESTROYED (L) ?

If the above question is answered "N", the entire diagnostic will stop and the Runtime Services prompt will be displayed. No default answer is provided for this question.

## 2.5 SOFTWARE QUESTIONS

After you have answered the hardware questions or after a RESTART or CONTINUE command, the Runtime Services will ask for software parameters. You will be prompted by "CHANGE SW (L) ?" If you wish to change any parameters, answer by typing "Y". The software questions and the default values are described in the next paragraphs.

ENTER MANUAL INTERVENTION MODE FOR SPECIAL DIAGNOSIS (L) N ?

This test has a manual intervention mode which allows additional parameters to be input to alter the normal testing of a disk drive. This question should normally be answered "N" when this diagnostic is first run. Then, depending on the errors detected, it may be desirable to change this answer to "Y" and alter the testing to further isolate the problem. If this question is answered "Y", and the UAM (unattended mode operation) flag is set, the test will print a warning message that the mode cannot be entered and will proceed as if answered "N". See the description of the individual tests in section 5 for more information.

ERROR LIMIT (D) 32 ?

Enter the number of hard errors allowed before a drive is dropped from exercise. A number in the range of 1 to 65535 will be accepted.

READ TRANSFER LIMIT IN MEGABYTES - 0 FOR NO LIMIT (D) 0 ?

When the specified number of bytes have been read from a drive, the drive will be dropped from testing. When all drives are dropped, an end of pass will be indicated and the selected tests will be run again. This is the method used to determine how long this test is to run. Answer with a zero to prevent test from ending. The only other way this test can end is to have all drives dropped because the error limit on each is exceeded. Of course, the operator can always stop the test by typing a control-C.

SUPPRESS PRINTING SOFT ERRORS (L) Y?

When the test needs to perform retries, soft error reports will be printed to give as much information as possible. These actions are considered normal operation and are not error conditions until the retries fail. When the test is being run only to see how reliable the drive performs, this question should be answered "Y" so they are not confused with hard errors. The number of these soft errors is always reported in the statistical report. Answer "N" to see all the soft error reports.

DO INITIAL WRITE ON START (L) Y ?

If this test is to do data compares, the drive will need to be written with data patterns readable by the program. If the diagnostic area is selected for testing, the initial write is always performed (regardless of how this question is answered). If the customer data area is selected for testing, the initial write will be performed when ALL of the following are true:

1. This question is answered "Y".
2. This is the first time test #4 is being run after a START command.
3. The disk is write enabled.

Answering this question "N" when testing on the customer data area will normally result in data comparison errors if the disk was not previously written by this diagnostic or the formatter. Note that write checks are not performed during the initial write.

#### ENABLE ERROR LOG (L) N ?

A "Y" answer will cause error messages to be stored in a log buffer. Once the log buffer is full, additional error information is lost. The contents of the log buffer will be printed when the test is stopped and a statistical report requested. This log feature is intended to allow the Digital Diagnosis Center (DDC) to start this test then hang up from the system and let it run for some period of time. DDC can call the system back later, type control-C, then CONT and see the errors that have occurred (up to the limit of the log buffer). A message will be printed to indicate no errors have occurred if the log buffer is empty. This test will not be allowed to end while the error log is enabled until the error log is printed. The log buffer will hold 16 error messages. Using the log buffer will decrease the number of units that can be simultaneously tested.

## 2.6 EXTENDED P-TABLE DIALOGUE

When you answer the hardware questions, you are building entries in a table that describes the devices under test. The simplest way to build this table is to answer all questions for each unit to be tested. If you are testing multiple drives on the same controller, this becomes tedious since most of the answers are repetitious.

To illustrate a more efficient method, suppose you are testing a UDA50-A with 4 disk drives attached to it. These units are numbered 0 through 3. There is one hardware parameter that can vary among units, the drive number. This drive number may be 0 through 252. Below is a simple way to build a table for one UDA50-A with four units.

```
# UNITS (D) ? 4<CR>
```

```
UNIT 0
UNIBUS ADDRESS OF CONTROLLER (O) 172150 ? <CR>
DRIVE # (D) 0 ? 0<CR>
EXERCISE ON CUSTOMER DATA AREA (L) N ? <CR>
```

```
UNIT 1
UNIBUS ADDRESS OF CONTROLLER (O) 172150 ? <CR>
DRIVE # (D) 0 ? 1<CR>
EXERCISE ON CUSTOMER DATA AREA (L) N ? <CR>
```

```
UNIT 2
UNIBUS ADDRESS OF CONTROLLER (O) 172150 ? <CR>
DRIVE # (D) 1 ? 2<CR>
EXERCISE ON CUSTOMER DATA AREA (L) N ? <CR>
```

```
UNIT 3
UNIBUS ADDRESS OF CONTROLLER (O) 172150 ? <CR>
DRIVE # (D) 2 ? 3<CR>
EXERCISE ON CUSTOMER DATA AREA (L) N ? <CR>
```

As you can see from the above example, the hardware parameters do not vary significantly from unit to unit. The procedure shown is not very efficient. Also, notice that the default value for the drive number changes when a non-default response is given.

The Runtime Services can take multiple unit specifications however. Let's build the same table using the multiple specification feature.

Example 1:

```
# UNITS (D) ? 4<CR>
```

```
UNIT 0
UNIBUS ADDRESS OF CONTROLLER (O) 172150 ? <CR>
DRIVE # (D) 0 ? 0-3<CR>
EXERCISE ON CUSTOMER DATA AREA (L) N ? <CR>
```



## Example 2:

```
# UNITS (D) ? 4<CR>
```

```
UNIT 0  
UNIBUS ADDRESS OF CONTROLLER (C) 172150 ? <CR>  
DRIVE # (D) 0 ? 0,1,2,3<CR>  
EXERCISE ON CUSTOMER DATA AREA (L) N ? <CR>
```

As you can see in the above dialogue, the supervisor will build as many entries as it can with the information given in any one pass through the questions. In each example, four entries are built since four drive numbers were specified. The supervisor assumes that the controller CSR address is 172150 and the diagnostic should not exercise on the customer data area for each entry since these values were specified only once. In the first example, the "-" construct tells the supervisor to increment the data from the first number to the second. In this case, drive numbers 0, 1, 2, and 3 were specified.

## 2.7 QUICK START-UP PROCEDURE

To start-up this program:

1. Boot XXDP.
2. Enter the date.
3. On certain systems you will be asked if the system has a Unibus.  
If this question is asked, answer it either "Y" or "N".
4. Type "R ZUDIAO"
5. Type "START"
6. Answer the "CHANGE HW" question with "Y"
7. Answer all the hardware questions
8. Answer the "CHANGE SW" question with "N"

When you follow this procedure you will be using only the defaults for flags and software parameters. These defaults are described in sections 2.3 and 2.5.

Sample of terminal dialogue to test two disks on one UDA50-A or KDA50-Q:

```
DR>STA/FLA:PNT
CHANGE HW (L) ? Y
# UNITS (D) ? 2
UNIT 0
UNIBUS ADDRESS OF CONTROLLER (D) 172150 ?
DRIVE NUMBER (D) 0,1
EXERCISE ON CUSTOMER DATA AREA (L) N ?
CHANGE SW (L) ? N
TST: 001
UNIT 0 CONTROLLER AT 172150 DRIVE 0  RUNTIME 0:02:43
INITIAL WRITE COMPLETE
UNIT 1 CONTROLLER AT 172150 DRIVE 1  RUNTIME 0:05:31
INITIAL WRITE COMPLETE
TEST 1 IN PROGRESS.  RUNTIME 0:15:00
UNIT DRIVE      SERIAL-NUMBER SEKS MBYTES  MBYTES  HARD  SOFT  ECC
```

		X1000	READ	WRITTEN	ERRORS	ERRORS	
0	0	0	3	9	6	0	0
1	1	1	3	8	6	0	0

.  
.  
.  
Sample of terminal dialogue going through software questions to specify transfer limit (one disk being tested).

DR>STA/FLA:PNT/PAS:1

CHANGE HW (L) ? N

CHANGE SW (L) ? Y

ENTER MANUAL INTERVENTION MODE FOR SPECIAL DIAGNOSIS (L) N ?

ERROR LIMIT (D) 32 ?

READ TRANSFER LIMIT IN MEGABYTES - 0 FOR NO LIMIT (D) 0 ? 5

SUPPRESS PRINTING SOFT ERRORS (L) Y ?

DO INITIAL WRITE ON START (L) Y ?

ENABLE ERROR LOG (L) N ?

TST: 001

UNIT 0 CONTROLLER AT 172150 DRIVE 0    RUNTIME 0:02:43  
INITIAL WRITE COMPLETE

UNIT 0 CONTROLLER AT 172150 DRIVE 0    RUNTIME 0:09:41  
REACHED TRANSFER LIMIT - TESTING STOPPED

TEST 1 IN PROGRESS.    RUNTIME 0:09:41

UNIT	DRIVE	SERIAL-NUMBER	SEEKS X1000	MBYTES READ	MBYTES WRITTEN	HARD ERRORS	SOFT ERRORS	ECC
0	0		0	2	5	4	0	0

CZUDC EOP    1  
0 CUMULATIVE ERRORS

DR>

### 3.0 ERROR INFORMATION

#### 3.1 TYPES OF ERROR MESSAGES

There are three levels of error messages that may be issued by a diagnostic: general, basic and extended. General error messages are always printed unless the "IER" flag is set (section 2.3). The general error message is of the form:

```
diag severity errnum ON UNIT unit TST tst SUB sub PC: hostpc
error message
```

where:

```
diag = diagnostic name
severity = error type (SYS FTL ERR, DEV FTL ERR, HRD ERR or SFT ERR)
errnum = error number
unit = Arbitrary number assigned by the supervisor to each P-table
tst = test where error occurred
sub = subst where error occurred
hostpc = address of error message call in the host program
```

System fatal errors (SYS FTL ERR) are used to report errors that are fatal to the entire diagnostic program. The diagnostic stops and the supervisor prompt is printed.

Device fatal errors (DVC FTL ERR) are used to report errors that are fatal to the device (may be either a UDA50-A or KDA50-Q or disk drive). Testing stops on that device for the remainder of the current test.

Hard errors (HRD ERR) reports most of the errors detected. Testing will normally continue after the printing of the error.

Soft errors (SFT ERR) are not used by this diagnostic program.

Basic error messages are messages that contain some additional information about the error. These are always printed unless the "IER" or "IBE" flags are set (section 2.3). These messages are printed after the associated general message.

Extended error messages contain supplementary error information such as register contents or good/bad data. These are always printed unless the "IER", "IBE" or "IXE" flags are set (section 2.3). These messages are printed after the associated general error message and any associated basic error messages.

The general and basic error messages from this diagnostic are always one line each. The basic message defines what program detected the error, the drive being tested and the time of the error.

The PDP-11 program that is loaded into memory when you give the "R ZUDIAO" command to the XXDP monitor contains two parts, the host level code and a program which is loaded into the UDA50-A or KDA50-Q for execution. The controller program is called a "diagnostic machine" or DM program. The "diagnostic machine" is the facility in the controller which executes a PDP-11 like program. The large majority of the testing is done by the "diagnostic machine" program. Once the host level program has loaded and started the "diagnostic machine" program, all it does is respond to requests from that program. These requests include such things as telling the "diagnostic machine" which disks on that UDA50-A or KDA50-Q are to be tested and printing error messages.

The basic message (the second line of every error message) will be one of the following:

HOST PROGRAM CONTROLLER AT cer RUNTIME hh:mm:ss

The host program (PDP-11) detected the error. CONTROLLER AT cer identifies the address of the UDA50-A or KDA50-Q being tested. It may be omitted if the error is not specific to one controller.

DISK EXERCISER DM PC:xxxx UDA AT xxxxxx DRIVE xxx RUNTIME hhh:mm:ss

The "diagnostic machine" program loaded in test 1 detected the error.

Sample error message:

```

CZUDI DVC FTL ERR 00021 ON UNIT 00 TST 001 SUB 003 PC: 021062 - general message
HOST PROGRAM CONTROLLER AT 172150 RUNTIME 0:00:12           - basic message
CONTROLLER RESIDENT DIAGNOSTICS DETECTED FAILURE           \
  SA REGISTER CONTAINS 104041                               )- extended
REPLACE CONTROLLER PROCESSOR MODULE                         / message

```

Some informational messages are also printed by this program. They are usually one or two lines in length. They are printed as extended messages and are printed unless the "IER", "IBE" or "IXE" flags are set. These messages are for informational purposes only and their contents are self explanatory.

Sample informational message:

```
UNIT 0 CONTROLLER AT 172150 DRIVE 0 RUNTIME 0:02:43  
INITIAL WRITE COMPLETE
```

### 3.2 SPECIFIC ERROR MESSAGES

Following is a list of the error messages that may be printed by the diagnostic program. In the list, some of the numbers that may vary with execution or program version are shown as lower case words. These include program counters and runtime. Other numbers, such as unit number, drive number, UDA50-A or KDA50-Q address and data in registers are filled with sample numbers. Additional information about the error may follow the error message.

#### 3.2.1 HOST PROGRAM ERROR MESSAGES (00001 To 00999) -

##### 3.2.1.1 00002 - TWO UNITS SELECT SAME DRIVE -

```
CZUDI SYS FTL ERR 00002 ON UNIT 00 TST tst SUB sub PC: hostpc  
HOST PROGRAM CONTROLLER AT 172150 RUNTIME hh:mm:ss  
INVALID ANSWERS GIVEN TO THE HARDWARE QUESTIONS  
TWO UNITS SELECT THE SAME DRIVE
```

The hardware questions for two units were exactly the same. The program is aborted and returns to the Runtime Services prompt so that you can change the hardware questions.

**3.2.1.2 00003 MORE THAN 4 DRIVES SELECTED ON THIS CONTROLLER -**

CZUDI SYS FTL ERR 00003 ON UNIT 00 TST tst SUB sub PC: hostpc  
HOST PROGRAM CONTROLLER AT 172150 RUNTIME hh:mm:ss  
INVALID ANSWERS GIVEN TO THE HARDWARE QUESTIONS  
MORE THAN 4 DRIVES SELECTED ON THIS CONTROLLER

Up to four physical disk drives can be attached to a UDA50-A or KDA50-Q at one time. The program is aborted and returns to the supervisor prompt so that you can change the hardware questions.

**3.2.1.3 00004 NOT ENOUGH ROOM IN MEMORY TO TEST THE UNITS SELECTED -**

CZUDI SYS FTL ERR 00004 ON UNIT 00 TST tst SUB sub PC: hostpc  
HOST PROGRAM RUNTIME hh:mm:ss  
NOT ENOUGH ROOM IN MEMORY TO TEST THE UNITS SELECTED  
RESTART PROGRAM AND TEST FEWER UNITS AT A TIME

This program does not limit the number of units that can be tested by specifying a maximum number. What limits the number is the amount of memory used to store data on each unit. You have exceeded the number of units that are testable at one time. Start program over and select fewer units.

**3.2.1.4 00006 - TABLE INCONSISTANCY ERROR -**

CZUDI SYS FTL ERR 00006 ON UNIT 00 TST tst SUB sub PC: hostpc  
HOST PROGRAM RUNTIME hh:mm:ss  
TABLE INCONSISTANCY ERROR. PLEASE RE-LOAD PROGRAM

When the host program is started, controller tables are set according to the P-tables. Error 00006 will occur if the tables were corrupted after restarting the diagnostic. Load and start your program again.

### 3.2.1.5 00014 - CONTROLLER IS NOT SUPPORTED BY DIAGNOSTIC PROGRAM -

CZUDI DVC FTL ERR 00014 ON UNIT 00 TST tst SUB sub PC: hostpc  
 MOST PROGRAM CONTROLLER AT 172150 RUNTIME hh:mm:ss  
 CONTROLLER IS NOT SUPPORTED BY THIS DIAGNOSTIC PROGRAM.  
 THIS PROGRAM REQUIRES A UDA50A (MODEL 6, MICROCODE VERSION AT LEAST 3),  
 OR A KDA50-Q (MODEL 13, MICROCODE VERSION AT LEAST 0)  
 CONTROLLER REPORTED MODEL CODE xx AND MICROCODE VERSION xx

This diagnostic program will only test UDA50-A (modules M7485-6) or  
 KDA50-Q (modules M7164-5) controllers. UDA50 (modules M7161-2)  
 controllers will not be tested by this diagnostic controller and  
 should be replaced. If the program detects that the controller being  
 tested is not a UDA50-A or a KDA50-Q, it will not be tested. If the  
 microcode version of the controller is not at the current revision  
 level, the test will proceed, but accurate results are not guaranteed.

- 104000 - Fatal sequencer error
- 104040 - D PROC ALU test error
- 104041 - D PROC ROM parity test error / Timeout test error
- 105102 - D PROC no board 2 error / D PROC control reg test error /  
 D PROC RAM parity error
- 105105 - D PROC RAM buffer error
- 105152 - D PROC SDI error
- 105153 - D PROC write mode, wrap SERDES 16 error
- 105154 - D PROC read mode, SERDES 16, 10 RSGEN and ECC error
- 106040 - U PROC ALU error / DFAIL test error / Unexpected trap
- 106041 - U PROC control reg test error
- 106042 - U PROC parity error set erroneously / CROM parity error
- 106047 - U PROC Constant ROM error with D proc running SDI test
- 106055 - Unexpected trap - abnormal termination of diagnostics
- 106071 - U PROC ROM error
- 106072 - U PROC ROM parity test error
- 106200 - STEP 1 data error (MSB wasn't set)
- 107103 - U PROC RAM parity error
- 107107 - U PROC RAM buffer error
- 107115 - Board #2 test count was wrong
- 112300 - STEP 2 INIT error
- 122240 - DMA test error
- 122300 - STEP 3 INIT error
- 142300 - STEP 4 INIT error

### 3.2.1.6 00030 - FATAL ERROR REPORTED BY CONTROLLER -

CZUDI DVC FTL ERR 00030 ON UNIT 00 TST tst SUB sub PC: hostpc  
 MOST PROGRAM CONTROLLER AT 172150 RUNTIME hh:mm:ss  
 FATAL ERROR REPORTED BY CONTROLLER  
 SA REGISTER CONTAINS 100004

A message from the controller firmware reports an unexpected failure.



An error code is presented in the SA register. Here is a list of the codes and their meanings:

- 004400 - Controller has been inited by either a bus init or by writing into the IP register.
- 100001 - Bus envelope/packet read error (parity or timeout)
- 100002 - Bus envelope/packet write error (parity or timeout)
- 100003 - Controller ROM and RAM parity error
- 100004 - Controller RAM parity error
- 100005 - Controller ROM parity error
- 100006 - Bus ring read error
- 100007 - Bus ring write error
- 100010 - Bus interrupt master failure
- 100011 - Host access timeout error
- 100012 - Host exceeded credit limit
- 100013 - Controller SDI hardware fatal error
- 100014 - DM XFC fatal error
- 100015 - Hardware timeout of instruction loop
- 100016 - Invalid virtual circuit identifier
- 100017 - Interrupt write error on bus

### 3.2.1.7 00031 - NO INTERRUPT RECEIVED FROM DM PROGRAM FOR 3 MINUTES -

CZUDI DVC FTL ERR 00031 ON UNIT 00 TST tst SUB sub PC: hostpc  
 HOST PROGRAM CONTROLLER AT 172150 RUNTIME hh:mm:ss  
 NO INTERRUPT RECEIVED FROM DM PROGRAM FOR 3 MINUTES  
 ASSUME PROGRAM IS HUNG

All DM programs are required to communicate with the host program; so as to assure the host program that the DM program is not hung up or in an endless loop. If the DM program has not done so, the host program assumes the DM is hung and this message appears.

### 3.2.1.8 00032 - UNKNOWN REQUEST RECEIVED FROM DM PROGRAM -

CZUDI DVC FTL ERR 00032 ON UNIT 00 TST tst SUB sub PC: hostpc  
 HOST PROGRAM CONTROLLER AT 172150 RUNTIME hh:mm:ss  
 MESSAGE BUFFER RECEIVED FROM DM PROGRAM WITH UNKNOWN REQUEST NUMBER  
 MESSAGE BUFFER CONTAINS:  
 000001 000002 000003 000004 000005 000006 000007  
 000008 000009 000010 000011 000012 000013 000014  
 000015 000016 000017 000018 000019 000020 000021  
 000022 000023 000024 000025 000026 000027 000028  
 000029 000030 000031 000032 000033 000034 000035

The DM program and the host program communicate with each other using packets. Each packet must have a request number set up by the DM program and interpreted by the host program. This request number is not a known request number. The problem may be the bus or either one of the controller modules or a corrupted DM program. Word 1 contains the DM request number, and word 2 typically contains the drive number. The rest of the buffer contains information specific to a DM request. The numbers in the example show the order in which words are displayed.

3.2.1.9 00033 - RESPONSE PACKET FROM CONTROLLER DOES NOT CONTAIN  
EXPECTED DATA -

CZUDI DVC FTL ERR 00033 ON UNIT 00 TST tst SUB sub PC: hostpc  
 HOST PROGRAM CONTROLLER AT 172150 RUNTIME hh:mm:ss  
 RESPONSE PACKET FROM CONTROLLER DOES NOT CONTAIN EXPECTED DATA  
 EITHER CONTROLLER RETURNED ERROR STATUS OR PACKET WAS NOT RECEIVED CORRECTLY

COMMAND PACKET SENT	RESPONSE PACKET RECEIVED
000000 000020	000000 000020
000000 000000	000000 000000
000000 000002	000000 000202
000000 014336	000000 014336
000000 034674	000000 034674
000000 000000	000000 000000
000000 000000	000000 000000
000000 051232	000000 051232
000000 000000	000000 000000
000000 000000	000000 000000
000000 000000	000000 000000
000000 000000	000000 000000

The host program inspected the response packet which was given by to controller. The response packet may have been in error with one of the following points:

- 1) The end code was not as expected.
- 2) The status code showed an error occurred with the last command.
- 3) The command reference numbers (the first word) did not match.

If 1 or 3 occurred, there may have been a transmission problem between the controller and the host program. If 2 occurred, check the error code in the MSCP specification for further information. The packets are displayed two words per line, low order word and byte to the right (corresponding to the MSCP long-word entity).

## 3.2.1.10 00035 - DM PROGRAM ASKED FOR DATA ON UNKNOWN DRIVE -

CZUDI DVC FTL ERR 00035 ON UNIT 00 TST tst SUB sub PC: hostpc  
 HOST PROGRAM CONTROLLER AT 172150 RUNTIME hh:mm:ss  
 DM PROGRAM ASKED FOR DATA ON UNKNOWN DRIVE  
 MESSAGE BUFFER CONTAINS:

000001 000002 000003 000004 000005 000006 000007
000008 000009 000010 000011 000012 000013 000014
000015 000016 000017 000018 000019 000020 000021
000022 000023 000024 000025 000026 000027 000028
000029 000030 000031 000032 000033 000034 000035

The currently running DM program sent a message to the controller referencing a drive which doesn't have an entry in the host program's drive data tables. The message sent to the host program is also included in the error message. This error indicates either a software

or hardware error. Re-load the diagnostic program and run TEST 1 to diagnose the failure.

### 3.2.1.11 00036 - NO INTERRUPT RECEIVED FROM CONTROLLER FOR 30 SECONDS

CZUDI DVC FTL ERR 00036 ON UNIT 00 TST tst SUB sub PC: hostpc  
 HOST PROGRAM CONTROLLER AT 172150 RUNTIME hh:mm:ss  
 NO INTERRUPT RECEIVED FROM CONTROLLER FOR 30 SECONDS  
 WHILE LOADING DM PROGRAM

After a DM program has been sent to the controller, the host program expects an interrupt within 30 seconds. The interrupt is used to assure the host program that the DM program is sane. If no interrupt occurred, then error message 00036 is displayed and the DM program is assumed to be hung.

### 3.2.1.12 00038 - MEMORY ERROR TRYING TO READ CONTROLLER REGISTERS -

CZUDI DVC FTL ERR 00038 ON UNIT 00 TST 001 SUB 002 PC: hostpc  
 HOST PROGRAM CONTROLLER AT 172150 RUNTIME hh:mm:ss  
 MEMORY ERROR TRYING TO READ CONTROLLER REGISTERS  
 CHECK BUS SELECTION SWITCHES ON CONTROLLER PROCESSOR MODULE  
 OR BUS  
 OR REPLACE CONTROLLER PROCESSOR MODULE

A non-existent memory error occurred when the host program tried to access the controller IP and SA registers while in subtest 2 of test 1. The controller is at another CSR address (check the bus selection switches) or the processor module is broken or the bus is broken.

### 3.2.1.13 00040 - FATAL CONTROLLER ERROR -

CZUDI DVC FTL ERR 00040 ON UNIT 00 TST 001 SUB 000 PC: hostpc  
 HOST PROGRAM CONTROLLER AT 172150 RUNTIME hh:mm:ss  
 FATAL CONTROLLER ERROR  
 USE DIAGNOSTIC ZUDHAO TO DIAGNOSE FAILURE

This error message will be printed when a controller timeout or error occurs during controller initialization. It is not the intent of this diagnostic to diagnose controller errors. If this message is printed, use the diagnostic program ZUDHAO to diagnose the controller failure.

### 3.2.2 DM PROGRAM INFORMATIONAL MESSAGES -

These messages inform the operator of events occurring that may be of interest.

#### 3.2.2.1 ECC CORRECTABLE DATA -

UNIT unit CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
ECC CORRECTABLE DATA EXISTS IN type bn  
number\_of\_errors OUT OF A MAXIMUM OF ecc\_maximum SYMBOLS WERE CORRECTED  
SECTORS FROM INDEX sector TRK track GRP group CYL cylinder

number\_of\_errors:

The number of symbols that were corrected using the ECC correction algorithm.

ecc\_maximum:

The maximum number of ECC errors that can be corrected (an SDI DRIVE CHARACTERISTIC) without error.

The above message occurs when TEST 4 1) detects an ECC error and 2) is able to correct it, and 3) the corrections are less than the drive ECC threshold, (a SDI DRIVE CHARACTERISTIC) and 4) the EDC computed over the corrected sector matched the EDC read.

#### 3.2.2.2 INITIAL WRITE COMPLETE -

UNIT unit CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
INITIAL WRITE COMPLETE

Whenever TEST 4 is STARTed with initial write enabled, <<OR>> whenever it is STARTed or RESTARTed and the diagnostic area is being tested on a drive not in read only mode, the disk will be initially written. The above message occurs when the initial write completes.

#### 3.2.2.3 READ ONLY DRIVE, INITIAL WRITE WILL NOT BE PERFORMED -

UNIT unit CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
READ ONLY DRIVE, INITIAL WRITE WILL NOT BE PERFORMED

If an initial write is to be performed (see above for conditions) and a unit or subunit is in read only mode, (can be set in the manual intervention questions) an initial write will not be performed, and this message will print to inform the operator.

NOTE: DATA COMPARE ERRORS RESULT IF THE DISK IS NOT INITIALLY WRITTEN!!

## 3.2.2.4 THE AREA BEING TESTED HAS N BYTES/SECTOR -

UNIT unit CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
THE AREA BEING TESTED HAS bytes\_per\_sector BYTES/SECTOR

## bytes\_per\_sector:

Number of bytes contained in one sector on the drive being tested. This will be 512 for 16 bit drives and 576 for 18 bit drives.

THIS MESSAGE WILL ONLY APPEAR ON MANUFACTURING SOFTWARE. NO FIELD DIAGNOSTIC WILL DISPLAY THIS MESSAGE.

Manufacturing has special TEST 4 software that allows TEST 4 to run on both 16 and 18 bit drives. To enable the operator to know what kind of drive the test is being run on, the above message will print out at the start of the test.

## 3.2.2.5 DEVICE FATAL WILL CAUSE THE FOLLOWING DRIVES TO BE DROPPED -

UNIT unit CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
THE PREVIOUS DEVICE FATAL WILL CAUSE THE FOLLOWING DRIVES  
TO BE DROPPED: plug. plug+1. plug+2. plug+3

## plug:

drive plug number -- each subunit's plug number is displayed. for a single subunit drive (such as a RA80) only one plug number is displayed.

If a device fatal error occurs and dropping is enabled, <<ALL>> subunits on the unit that the device fatal occurred must be dropped. To inform the operator, this message is printed after the device fatal error message.

NOTE: IF MORE THAN ONE CONTROLLER IS ON A SYSTEM, THIS MESSAGE MAY NOT IMMEDIATELY FOLLOW THE DEVICE FATAL IF AN ERROR HAPPENS AT THE SAME TIME ON ANOTHER CONTROLLER.

## 3.2.3 DM PROGRAM ERROR MESSAGES (04000 TO 04999) -

## 3.2.3.1 4001 - ATTN ASSERTED DURING SEEK -

CZUDI SFT ERR 04001 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 ATTN ASSERTED DURING SEEK  
 SEEK FROM GRP group CYL cylinder TO GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

This error occurs when the drive asserts the SDI ATTENTION signal without asserting the READ/WRITE READY signal, indicating the unsuccessful completion of a seek.

See retry/recovery section for recovery details.

## 3.2.3.2 4002 - ATTN ASSERTED UNEXPECTEDLY -

CZUDI SFT ERR 04002 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 ATTN ASSERTED UNEXPECTEDLY, ASYNC DRIVE ERROR OR LOGGABLE  
 INFORMATION  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

This is an asynchronous drive error. Asynchronous drive errors are those errors reported by the drive which are not related to a level 2 or command. These errors are reported by the drive using the SDI ATTENTION signal. The operator must look at the status returned to determine the error that occurred.

See retry/recovery section for recovery details.

## 3.2.3.3 4003 - SEEK DID NOT COMPLETE -

CZUDI SFT ERR 04003 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 SEEK DID NOT COMPLETE, NEITHER ATTN OR R/W RDY WAS ASSERTED  
 BEFORE TIMEOUT  
 SEEK FROM GRP group CYL cylinder TO GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

This error occurs when the drive fails to assert READ/WRITE READY before the seek timeout, which indicates the successful completion of a seek.

See retry/recovery section for recovery details.

### 3.2.3.4 4004 - RCT AREA CORRUPTED -

CZUDI HRD ERR 04004 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
RCT AREA CORRUPTED, COULD NOT FIND REPLACEMENT FOR  
LBN THAT WAS REVECTORED  
ATTEMPTING TO READ RCT LBN bn  
SEARCHING FOR LBN bn

CZUDI HRD ERR 04004 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
RCT AREA CORRUPTED, COULD NOT FIND REPLACEMENT FOR  
LBN WITH HEADER NOT FOUND  
ATTEMPTING TO READ RCT LBN bn  
SEARCHING FOR LBN bn

Error 4004 will occur only when TEST 4 is running in the customer data area. It occurs when 1) A sector is either marked revectorred or the header can't be found in two revolutions of the disk (both cases should be revectorred) and 2) The replacement for that sector isn't found in the RCT and 3) a NULL entry isn't found at the end of the RCT (see DEC STANDARD 166, Replacement and Caching Table Format). In either case, the subunit should be reformatted, and the cause of the RCT corruption determined.

### 3.2.3.5 4005 - HEADER NOT FOUND DURING WRITE -

CZUDI HRD ERR 04005 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
HEADER NOT FOUND DURING WRITE  
DBN bn  
SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
ORIGIN OF SEEK: GRP group CYL cylinder

Error 4005 occurs only when TEST 4 is writing a DBN or RBN. This is because bad blocks in the diagnostic area are not revectorred, and RBN's are what LBN's are revectorred to, so they should never be bad. TEST 4 reports this error if the header being searched for couldn't be found in two revolutions of the disk.



## 3.2.3.6 4006 - SELECT TRACK AND WRITE NOT SENT -

CZUDI SFT ERR 04006 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 SELECT TRACK AND WRITE LEVEL 1 CMD NOT SENT  
 ATTEMPT attempt  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 ORIGIN OF SEEK: GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

Select track and read or write not executed occurs when the controller attempts to send the select track and read/write level 1 cmd, but receiver ready is deasserted or the state is invalid so it cannot send the command (the SERDES could also be broken so it's unable to send the command). The same error is generated if the controller gets a header sync timeout, and when it looks at the drive's state, it is either invalid or receiver ready is deasserted (header sync timeout is <<NOT>> a error -- it's quite normal on a high-density disk).

See retry/recovery section for recovery details.

## 3.2.3.7 4007 - ECC DETECTED ERROR -

CZUDI SFT ERR 04007 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 ECC DETECTED ERROR  
 RETRY retry  
 ERROR RECOVERY LEVEL level  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder

Error 4007 occurs if an ECC error is detected but ECC correction is disabled.

See retry/recovery section for recovery details.

## 3.2.3.8 4008 - ECC DETECTED ERROR, BUT CORRECTION FAILED -

CZUDI SFT ERR 04008 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 ECC DETECTED ERROR, BUT CORRECTION FAILED  
 RETRY retry  
 ERROR RECOVERY LEVEL level  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder

Error 4008 occurs if an ECC error is detected, but the correction

algorithm is unable to correct the errors.

NOTE: THIS IS USUALLY (BUT NOT ALWAYS) INDICATIVE OF A BAD SPOT IN THE ECC RESIDUE AREA AFTER THE DATA AREA OF THE SECTOR.

See retry/recovery section for recovery details.

### 3.2.3.9 4009 - ECC CORRECTIONS EXCEED THRESHOLD -

CZUDI SFT ERR 04009 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
ECC CORRECTIONS EXCEED THRESHOLD  
RETRY retry  
ERROR RECOVERY LEVEL level  
type bn  
SECTORS FROM INDEX sector TRK track GRP group CYL cylinder

Error 4009 occurs if an ECC error is detected, the correction algorithm succeeds in correcting the errors, but the number of bits that were corrected exceeds the correction threshold. The correction threshold is a SDI DRIVE CHARACTERISTIC; at startup, the controller asks the drive how many bits are ALLOWED to be corrected. If, after correction, the number of corrections exceed this threshold, error 40009 results.

See retry/recovery section for recovery details.

### 3.2.3.10 4010 - ECC CORRECTION SUCCEEDED, BUT EDC DETECTS ERROR -

CZUDI SFT ERR 04010 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
ECC CORRECTION SUCCEEDED, BUT EDC DETECTS ERROR  
RETRY retry  
ERROR RECOVERY LEVEL level  
type bn  
SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
EDC COMPUTED edc\_computed  
EDC READ edc\_read

edc\_computed:

This is the EDC in octal computed over the sector as it resided in the controller's memory.

edc\_read:

This is the EDC in octal that was found written at the end of the sector.

Error 4010 could be caused by several problems:

1) A buffer with a few ECC errors that can be corrected, but the EDC was incorrectly computed or written, or 2) The ECC algorithm incorrectly corrected the buffer and/or the EDC value, (but corrections were less than the threshold) or 3) a buffer RAM problem within the controller.

See retry/recovery section for recovery details.

### 3.2.3.11 4011 - READ DID NOT SUCCEED ON ANY RECOVERY LEVEL -

```
CZUDI HRD ERR 04011 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
READ DID NOT SUCCEED ON ANY RECOVERY LEVEL
type bn
GRP group CYL cylinder
```

Error 4011 occurs when retries are enabled, and TEST 4 has tried to read a sector using all retries on all levels of error recovery. See ECC and EDC retries in the retry/recovery section.

### 3.2.3.12 4012 - DATA COMPARISON FAILED -

```
CZUDI HRD ERR 04012 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
DATA COMPARISON FAILED
ECC OR EDC HAD DETECTED ERROR IN BUFFER
type bn
SECTORS FROM INDEX sector TRK track GRP group CYL cylinder
PATTERN NUMBER pattern
OFFSET OF ERROR WITHIN BUFFER: buffer_offset
OFFSET OF ERROR WITHIN DISPLAYED LIST: list_offset (1ST WORD OFFSET 0)
  data0  data1  data2  data3  data4  data5
  data6  data7  data8  data9  data10 data11
```

```
CZUDI HRD ERR 04012 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
DATA COMPARISON FAILED
ECC OR EDC HAD <<NOT>> DETECTED ERROR IN BUFFER
type bn
SECTORS FROM INDEX sector TRK track GRP group CYL cylinder
PATTERN NUMBER pattern
OFFSET OF ERROR WITHIN BUFFER: buffer_offset
OFFSET OF ERROR WITHIN DISPLAYED LIST: list_offset (1ST WORD OFFSET 0)
  data0  data1  data2  data3  data4  data5
  data6  data7  data8  data9  data10 data11
```

pattern:

The pattern number (decimal) that failed the comparison.

**buffer\_offset:**

The offset of the error (decimal) within the sector read, where the first word in the sector is offset 0

**list\_offset:**

The offset of the error (decimal) within the displayed list, where the first word in the list is offset 0

**dataX:**

TEST 4 displays twelve data words read from the sector. They are displayed left to right, top to bottom.

Error 4012 occurs when a data compare detects a difference between the buffer read and a known data pattern. The operator is informed if the error was detected by the ECC or EDC. The first word of the sector (which may or may not be printed, depending on the position of the error) is the pattern number replicated in each nibble of the word. If a disk is not initially written, it is likely that data comparison failures will occur in the first word of the sector. The following is the first word of the sector (octal) for the sixteen different patterns.

pattern	word 0	pattern	word 0
1	010421	9	114631
2	021042	10	125252
3	031463	11	135673
4	042104	12	146314
5	052525	13	156735
6	063146	14	167356
7	073567	15	177777
8	104210	16	000000

Note that pattern 16 is mapped to pattern 0.

### 3.2.3.13 4013 - DRIVE NOT ONLINE TO CONTROLLER, AND NOT SPINABLE -

CZUDI DVC FTL ERR 04013 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
DRIVE NOT ONLINE TO CONTROLLER, AND NOT SPINABLE

If a drive drops offline while being tested (a normal occurrence during TEST 4) and some event happens that makes the drive unspinnable (such as the operator popping out the run/stop switch) error 4013 will be printed. If the operator inhibits dropping units, TEST 4 will go into error recovery and loop on error 4023, spindle dropped ready.

### 3.2.3.14 4014 - UNABLE TO COMPLETE SEEK -- TRIED 3 TIMES -

CZUDI DVC FTL ERR 04014 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 UNABLE TO COMPLETE SEEK -- TRIED 3 TIMES  
 type bn  
 GRP group CYL cylinder

Once a seek has been attempted 3 times, and never successfully completed, error 4014 will be printed and the entire unit dropped. If the operator inhibits dropping units, the drive will be recalibrated, and the seek will be attempted again.

### 3.2.3.15 4015 - SEEK REQUIRED N RETRIES BEFORE COMPLETING -

CZUDI SFT ERR 04015 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 SEEK REQUIRED retries RETRIES BEFORE COMPLETING  
 GRP group CYL cylinder

retries:

The number of times the seek was re-issued

If a seek required retries, error 4015 would print to notify the operator.

### 3.2.3.16 4016 - ERRORS DURING DRIVE INITIALIZATION AND SETUP -

CZUDI DVC FTL ERR 04016 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 ERRORS DURING DRIVE INITIALIZATION AND SETUP  
 THIS CONTROLLER AND ALL DRIVES ATTACHED WILL BE REMOVED FROM TESTING

If any errors occur during drive and test initialization, DRIVES ATTACHED TO THE CONTROLLER THAT HAD THE DRIVE INITIALIZATION ERRORS WILL NOT BE TESTED. In this case, error 4016 will be printed to notify the operator. THIS ERROR DOES <<NOT>> REFER TO CONTROLLER INITIALIZATION. This error is unaffected by the operator inhibiting the dropping of units.

### 3.2.3.17 4017 - NO VALID STATE FROM DRIVE -

CZUDI DVC FTL ERR 04017 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 NO VALID STATE FROM DRIVE  
 NO DRIVE CLOCKS

CZUDI DVC FTL ERR 04017 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
NO VALID STATE FROM DRIVE  
HARD PARITY OR PULSE ERROR FOR 1/2 A SECOND

If TEST 4 is <<EVER>> unable to get valid drive state, the drive is immediately dropped, and error 4017 is printed. There are two types of invalid state: no clocks or 'hard' errors. If TEST 4 <<EVER>> detects no clocks, the driver is dropped IMMEDIATELY. Parity and pulse errors are normal, so TEST 4 tolerates them, <<UNLESS THEY HAPPEN CONTINUOUSLY FOR 1/2 A SECOND>>. If they do occur for 1/2 a second, either the drive transmitter or controller receiver is bad, and the drive is dropped. If the operator has inhibited the dropping of units, TEST 4 will retry the module that the error occurred on.

### 3.2.3.18 4018 - ATTEMPT TO WRITE ON WRITE PROTECTED DRIVE -

CZUDI DVC FTL ERR 04018 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
ATTEMPT TO WRITE ON WRITE PROTECTED DRIVE  
ERROR CODE RETURNED FROM CONTROLLER: code  
REAL TIME STATE state  
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

#### code:

The error (in octal) returned to TEST 4 from the controller when TEST 4 attempted to write on the write protected drive.

The controller error codes (in octal) are as follows:

code	error
2	SELECT TRACK AND WRITE LEVEL 1 CMD NOT SENT
3	LBN IS REVECTORED
4	HEADER NOT FOUND
153	SEEK OR HEAD SELECT ERROR
213	R/W RDY DROPPED
253	DATA OR STATE CLOCK TIMEOUT
313	RCVR RDY DROPPED
413	REAL TIME STATE RECEIVE ERROR

If TEST 4 attempts to write on a write protected drive, error 4018 is printed. TEST 4 requires the drive to detect the attempt to write when write protected and return an error for this error to be printed. If the operator has inhibited the dropping of units, a seek will be issued and the write attempted again.

## 3.2.3.19 4019 - HEADER NOT FOUND DURING READ -

CZUDI HRD ERR 04019 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 HEADER NOT FOUND DURING READ  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 ORIGIN OF SEEK: GRP group CYL cylinder

Error 4019 can occur only when TEST 4 is reading a DBN, RBN or RCT LBN.

DBN space is for diagnostic use only, and bad blocks in this area are merely written with a bad header code; TEST 4 will call out the 'missing' block with this error, but this condition IS NOT an error.

The RCT LBN space is protected from bad blocks with a multi-copy structure. No blocks in the RCT LBN space are revectorred. TEST 4 will call out the 'missing' block with this error, but this condition IS NOT an error. It is an error if all copies of the RCT cannot be read, in which case a group of these errors will be followed by a 4040 error. See error 4040 for more information.

If this error occurs on a RBN, this is a definite hard error. This is because bad LBN's are revectorred to RBN's, so the RBN that the LBN is revectorred to should never be bad.

TEST 4 reports this error if the header being searched for couldn't be found in two revolutions of the disk.

## 3.2.3.20 4020 - SELECT TRACK AND READ LEVEL 1 CMD NOT SENT -

CZUDI SFT ERR 04020 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 SELECT TRACK AND READ LEVEL 1 CMD NOT SENT  
 ATTEMPT attempt  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 ORIGIN OF SEEK: GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

Select track and read or write not executed occurs when the controller attempts to send the select track and read/write level 1 cmd, but receiver ready is deasserted or the state is invalid so it cannot send the command (the SERDES could also be broken so it's unable to send the command). The same error is generated if the controller gets a header sync timeout, and when it looks at the drive's state, it is either invalid or receiver ready is deasserted (header sync timeout is <<NOT>> a error -- it's quite normal on a high-density disk).

See retry/recovery section for recovery details.

### 3.2.3.21 4021 - DRIVE NOT FORMATTED IN 512 BYTE MODE -

CZUDI DVC FTL ERR 04021 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 DRIVE NOT FORMATTED IN 512 BYTE MODE -- UNABLE TO TEST  
 FCT BLOCK ZERO MODE WORD: mode

\*\*\* THIS PACK HAS AN INVALID FORMAT AND CANNOT BE USED \*\*\*

mode:

The mode word found on the drive's FCT block zero

Error 4021 occurs when TEST 4 Finds that the mode word found in FCT block zero is not the 512 byte mode word (126736 octal). See DEC STANDARD 166 "FCT Structure". Inhibiting the dropping of units has no effect on this error. A disk with this error must be re-formatted.

### 3.2.3.22 4021 - DRIVE NOT FORMATTED IN 512 OR 576 BYTE MODE -

CZUDI DVC FTL ERR 04021 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 DRIVE NOT FORMATTED IN 512 OR 576 BYTE MODE -- UNABLE TO TEST  
 FCT BLOCK ZERO MODE WORD: mode

\*\*\* THIS PACK HAS AN INVALID FORMAT AND CANNOT BE USED \*\*\*

mode:

The mode word found on the drive's FCT block zero

THIS ERROR WILL ONLY APPEAR ON MANUFACTURING SOFTWARE. NO FIELD DIAGNOSTIC WILL DISPLAY THIS ERROR.

Error 4021 occurs when TEST 4 Finds that the mode word found in FCT block zero is not the 512 or 576 byte mode word (126736 octal for 512, 074161 for 576 bytes/sector). See DEC STANDARD 166 "FCT Structure". Inhibiting the dropping of units has no effect on this error. A disk with this error must be re-formatted.

### 3.2.3.23 4022 - COULD NOT READ FCT BLOCK ZERO -

CZUDI DVC FTL ERR 04022 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 COULD NOT READ FCT BLOCK ZERO

\*\*\* THIS PACK HAS AN INVALID FORMAT AND CANNOT BE USED \*\*\*



Error 4022 occurs when TEST 4 is unable to read ANY copy of FCT block zero. See DEC STANDARD 166 "FCT Structure". Inhibiting the dropping of units has no effect on this error. A disk with this error must be re-formatted.

### 3.2.3.24 4023 - UNABLE TO CONTINUE TESTING -

```
CZUDI DVC FTL ERR 04023 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
UNABLE TO CONTINUE TESTING
PORT SWITCH OUT
REAL TIME STATE state
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0
```

If, during testing, the operator disables the drive port that TEST 4 is using by popping out the drive's port switch, TEST 4 prints error 4023. CHANGING THE STATE OF THE PORT SWITCH FOR THE PORT THAT TEST 4 IS <<NOT>> USING HAS NO EFFECT ON THE TEST. If dropping of units is inhibited, TEST 4 will loop in error recovery, printing this error, until the error state is corrected (by some external action).

```
CZUDI DVC FTL ERR 04023 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
UNABLE TO CONTINUE TESTING
RUN/STOP SWITCH OUT
REAL TIME STATE state
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0
```

If, during testing, the operator pops out the drive's run/stop switch, TEST 4 prints error 4023. If dropping of units is inhibited, TEST 4 will loop in error recovery, printing this error, until the error state is corrected (by some external action).

```
CZUDI DVC FTL ERR 04023 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
UNABLE TO CONTINUE TESTING
SPINDLE DROPPED READY
REAL TIME STATE state
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0
```

If, during testing, the spindle drops from its ready state, error 4023 is printed. If dropping of units is inhibited, TEST 4 will loop in error recovery, printing this error, until the error state is corrected (by some external action).

## 3.2.3.25 4024 - EDC DETECTED ERROR BUT ECC DID NOT -

CZUDI SFT ERR 04024 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 EDC DETECTED ERROR BUT ECC DID NOT  
 RETRY retry  
 ERROR RECOVERY LEVEL level  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 EDC COMPUTED edc\_computed  
 EDC READ edc\_read

**edc\_computed:**

This is the EDC in octal computed over the sector as it resided in the controller's memory.

**edc\_read:**

This is the EDC in octal that was found written at the end of the sector.

**edc:**

The edc computed and read in octal.

Error 4024 could be caused by several problems. 1) A buffer with no ECC errors, but the EDC was incorrectly computed or written, or 2) a buffer RAM problem within the controller, or 3) The error is such that the ECC really doesn't detect an error... Case 3 is very unlikely.

See retry/recovery section for recovery details.

## 3.2.3.26 4025 - WRITE ATTEMPTED MAXIMUM TIMES -

CZUDI WRD ERR 04025 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 WRITE ATTEMPTED MAXIMUM TIMES  
 type bn

If three I/O errors occur when attempting to write to the drive (one I/O error if retries are disabled) error 4025 is printed to inform the operator.

## 3.2.3.27 4026 - READ ATTEMPTED MAXIMUM TIMES -

CZUDI WRD ERR 04026 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 READ ATTEMPTED MAXIMUM TIMES  
 type bn

If three I/O errors occur when attempting to read from the drive (one

I/O error if retries are disabled) error 4026 is printed to inform the operator.

### 3.2.3.28 4028 - BOTH READ ONLY <AND> WRITE ONLY BITS SET -

CZUDI DVC FTL ERR 04028 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
BOTH READ ONLY <AND> WRITE ONLY BITS SET -- MOST ERROR

Error 4028 prints ONLY IF THERE IS A MOST CODE ERROR -- THIS IS NOT AN ERROR FROM A DRIVE. Inhibiting the dropping of units has no effect on this error.

### 3.2.3.29 4029 - HEADER NOT FOUND DURING ERROR LEVEL RECOVERY -

CZUDI SFT ERR 04029 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
HEADER NOT FOUND DURING ERROR LEVEL RECOVERY  
ATTEMPT attempt  
type bn  
SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
ORIGIN OF SEEK: GRP group CYL cylinder  
REAL TIME STATE state  
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

This error occurs during error recovery when the recovery methods cause the header to be unable to be read.

It is quite possible that the recovery methods (such as moving the heads off-track) will cause the header to be un-readable. Note that this does NOT destroy the header, the drive has modified its read-write path in such a way that the header can't be read at this instant. In this case, the correct action IS NOT to see if the sector is revectorred. All retries and retry levels should be attempted first.

This error occurs ONLY if error level recovery is already in progress when the 'HEADER NOT FOUND' error appears.

### 3.2.3.30 4030 - ERROR DETECTED AFTER DRIVE WAS SPUN DOWN -

CZUDI HRD ERR 04030 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
ERROR DETECTED AFTER DRIVE WAS SPUN DOWN  
REAL TIME STATE state  
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

THIS ERROR WILL ONLY APPEAR ON MANUFACTURING SOFTWARE. NO FIELD DIAGNOSTIC WILL DISPLAY THIS ERROR.

Some manufacturing software causes the drive being tested to be spun down, then up before exercising begins. If, after spinning the drive down, a drive error is detected the above message will be displayed.

### 3.2.3.31 4034 - SERDES OVERRUN ERROR DURING READ -

CZUDI SFT ERR 04034 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 SERDES OVERRUN ERROR DURING READ  
 ATTEMPT attempt  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 ORIGIN OF SEEK: GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

The SERDES overrun error is detected on a read operation and is indicative of a drive whose transfer rate is greater than 25 MHz or a broken SERDES.

See retry/recovery section for recovery details.

### 3.2.3.32 4035 - DATA OR STATE CLOCK TIMEOUT DURING READ -

CZUDI SFT ERR 04035 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 DATA OR STATE CLOCK TIMEOUT DURING READ  
 ATTEMPT attempt  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 ORIGIN OF SEEK: GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

The loss of drive clock occurs when the controller is clocking data to or from the drive through the SERDES. Failure of a word to be clocked in during a 125 millisecond time period triggers a loss of drive clock error.

See retry/recovery section for recovery details.

### 3.2.3.33 4036 - DATA SYNC TIMEOUT DURING READ -

CZUDI SFT ERR 04036 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 DATA SYNC TIMEOUT DURING READ  
 ATTEMPT attempt  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 ORIGIN OF SEEK: GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

This error occurs on a read operation after the correct header has been found and the controller times out waiting for the data sync word.

See retry/recovery section for recovery details.

### 3.2.3.34 4037 - R/W RDY DROPPED BEFORE/DURING READ -

CZUDI SFT ERR 04037 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 R/W RDY DROPPED BEFORE/DURING READ  
 ATTEMPT attempt  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 ORIGIN OF SEEK: GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

The loss of read/write ready error is detected either before an I/O has begun when trying to send out the real time command or at the end of an I/O operation when checking for errors.

See retry/recovery section for recovery details.

### 3.2.3.35 4038 - RCVR RDY DROPPED BEFORE/DURING READ -

CZUDI SFT ERR 04038 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 RCVR RDY DROPPED BEFORE/DURING READ  
 ATTEMPT attempt  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 ORIGIN OF SEEK: GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

The loss of drive receiver ready is detected when the controller is

trying to send out a real-time read or write command.

See retry/recovery section for recovery details.

### 3.2.3.36 4040 - ALL COPIES OF RCT READ WITH ERROR -

```
CZUDI HRD ERR 04040 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
ALL COPIES OF RCT READ WITH ERROR, SEARCHING FOR
LBN THAT WAS REVECTORED
LAST RCT LBN SEARCHED bn
SEARCHING FOR LBN bn
```

```
CZUDI HRD ERR 04040 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
ALL COPIES OF RCT READ WITH ERROR, SEARCHING FOR
LBN WITH HEADER NOT FOUND
LAST RCT LBN SEARCHED bn
SEARCHING FOR LBN bn
```

Error 4040 occurs when TEST 4 is trying to find the RBN that replaces a LBN that was revectorized or whose header could not be found (both should be revectorized). TEST 4 was unable to get a valid copy out of the M copies of the RCT due to I/O errors or ECC/EDC errors. M is a SDI DRIVE CHARACTERISTIC and is defined by the drive. This is indicative of either a bad pack (HDA) or that something wrote over the RCT incorrectly. Try to reformat the subunit.

### 3.2.3.37 4041 - COULD NOT FIND REPLACEMENT -

```
CZUDI HRD ERR 04041 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
COULD NOT FIND REPLACEMENT FOR
LBN THAT WAS REVECTORED
LBN TO REPLACE bn
```

```
CZUDI HRD ERR 04041 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
COULD NOT FIND REPLACEMENT FOR
LBN WITH HEADER NOT FOUND
LBN TO REPLACE bn
```

Error 4041 only occurs when TEST 4 is running in the customer data area, and is trying to find the RBN that replaces a LBN that was revectorized (must be in the RCT) or whose header could not be found (should be in the RCT, unless the media under the header has 'grown' a bad spot recently). In either case, TEST 4 was unable to find an entry in the RCT for the the sector and the subunit should be reformatted. In the case of the revectorized LBN, the cause of the

RCT's corruption should be determined (even with the header not found, the RCT may have been corrupted because a header going bad without warning [eg. the formatter not being able to see it as a weak spot] is a very low probability occurrence).

### 3.2.3.38 4042 - TIMEOUT WAITING FOR SECTOR OR INDEX PULSE -

CZUDI DVC FTL ERR 04042 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 TIMEOUT WAITING FOR SECTOR OR INDEX PULSE  
 GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

Error 4042 occurs when the controller microcode never detects a sector or index pulse from the drive before a read or write operation. If dropping of units is inhibited, a seek will be issued, and the write attempted again.

### 3.2.3.39 4044 - SEEK OR HEAD SELECT ERROR DETECTED DURING WRITE -

CZUDI SFT ERR 04044 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 SEEK OR HEAD SELECT ERROR DETECTED DURING WRITE  
 ATTEMPT attempt  
 LBN bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 ORIGIN OF SEEK: GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

See error 4045 for description.

See retry/recovery section for recovery details.

### 3.2.3.40 4045 - SEEK OR HEAD SELECT ERROR DETECTED DURING READ -

CZUDI SFT ERR 04045 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 SEEK OR HEAD SELECT ERROR DETECTED DURING READ  
 ATTEMPT attempt  
 LBN bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 ORIGIN OF SEEK: GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

errors 4044 and 4045 occur when the header comparison routine determines that the drive is positioned at the wrong physical cylinder, or that the wrong head (which can be cylinders, groups or tracks, or any combination depending on the drive) had been selected. This error only occurs when the drive itself had not detected the misseek or incorrect head selected.

NOTE: These errors will only be detected when the operator is running TEST 4 in the customer data area. This error will <<never>> appear when running in the diagnostic area.

See retry/recovery section for recovery details.

#### 3.2.3.41 4047 - DATA OR STATE CLOCK TIMEOUT DURING WRITE -

CZUDI SFT ERR 04047 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
DATA OR STATE CLOCK TIMEOUT DURING WRITE  
ATTEMPT attempt  
type bn  
SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
ORIGIN OF SEEK: GRP group CYL cylinder  
REAL TIME STATE state  
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

The loss of drive clock occurs when the controller is clocking data to or from the drive through the SERDES. Failure of a word to be clocked in during a 125 millisecond time period triggers a loss of drive clock error.

See retry/recovery section for recovery details.

#### 3.2.3.42 4048 - R/W RDY DROPPED BEFORE/DURING WRITE -

CZUDI SFT ERR 04048 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
R/W RDY DROPPED BEFORE/DURING WRITE  
ATTEMPT attempt  
type bn  
SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
ORIGIN OF SEEK: GRP group CYL cylinder  
REAL TIME STATE state  
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

The loss of read/write ready error is detected either before an I/O has begun when trying to send out the real time command or at the end of an I/O operation when checking for errors.

See retry/recovery section for recovery details.



### 3.2.3.43 4049 - RCVR RDY DROPPED BEFORE/DURING WRITE -

CZUDI SFT ERR 04049 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 RCVR RDY DROPPED BEFORE/DURING WRITE  
 ATTEMPT attempt  
 type bn  
 SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
 ORIGIN OF SEEK: GRP group CYL cylinder  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

The loss of drive receiver ready is detected when the controller is trying to send out a real-time read or write command.

See retry/recovery section for recovery details.

### 3.2.3.44 4050 - BEGIN/END SET STARTING BLOCK NUMBER GREATER THAN ENDING BLOCK NUMBER -

CZUDI DVC FTL ERR 04050 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
 BEGIN/END SET STARTING BLOCK NUMBER GREATER THAN ENDING BLOCK NUMBER

This is a TEST 4 initialization error due to an operator error. Go back to the manual intervention questions and check the answers to the BEGIN/END set questions. Inhibiting the dropping of units has no effect on this error.

### 3.2.3.45 4051 - THE BEGIN/END SETS OVERLAP -

CZUDI DVC FTL ERR 04051 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
 THE BEGIN/END SETS OVERLAP

This is a TEST 4 initialization error due to an operator error. Go back to the manual intervention questions and check the answers to the BEGIN/END set questions. Inhibiting the dropping of units has no effect on this error.

### 3.2.3.46 4052 - BEGIN/END SET ENDING BLOCK NUMBER EXCEEDS MAXIMUM -

CZUDI DVC FTL ERR 04052 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
 BEGIN/END SET ENDING BLOCK NUMBER EXCEEDS MAXIMUM  
 MAXIMUM BLOCK NUMBER ON DEVICE IS maximum\_block\_number

maximum\_block\_number:

This is the highest block number the operator can specify.

This is a TEST 4 initialization error due to an operator error. Go back to the manual intervention questions and check the answers to the BEGIN/END set questions. Inhibiting the dropping of units has no effect on this error.

### 3.2.3.47 4053 - DUPLICATE BAD BLOCKS -

CZUDI DVC FTL ERR 04053 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
 DUPLICATE BAD BLOCKS

This is a TEST 4 initialization error due to an operator error. Go back to the manual intervention questions and check the answers to the BAD BLOCK questions. Inhibiting the dropping of units has no effect on this error.

### 3.2.3.48 4054 - BAD BLOCK NUMBER EXCEEDS MAXIMUM -

CZUDI DVC FTL ERR 04054 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
 BAD BLOCK NUMBER EXCEEDS MAXIMUM. MAXIMUM BLOCK NUMBER  
 ON DEVICE IS maximum\_block\_number

maximum\_block\_number:

This is the highest block number the operator can specify.

This is a TEST 4 initialization error due to an operator error. Go back to the manual intervention questions and check the answers to the BAD BLOCK questions. Inhibiting the dropping of units has no effect on this error.

### 3.2.3.49 4055 - STARTING CYLINDER GREATER THAN ENDING CYLINDER -

CZUDI DVC FTL ERR 04055 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
 STARTING CYLINDER GREATER THAN ENDING CYLINDER

This is a TEST 4 initialization error due to an operator error. Go back to the manual intervention questions and check the answers to the STARTING AND ENDING CYLINDER questions. Inhibiting the dropping of units has no effect on this error.

### 3.2.3.50 4056 - RANDOM AND SEQUENTIAL SEEKS CANNOT BE MIXED WITHIN A UNIT -

CZUDI DVC FTL ERR 04056 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
 RANDOM AND SEQUENTIAL SEEKS CANNOT BE MIXED WITHIN A UNIT

Error 4056 is an operator error. The error occurs on a multiple subunit drive when one subunit is selected to run in random mode, and another is selected to run in sequential mode. This mix is not supported, so the above message is issued. Inhibiting the dropping of units has no effect on this error.

### 3.2.3.51 4057 - OVERFLOW WHEN CALCULATING THE L/DBN FROM THE GIVEN CYLINDER -

CZUDI DVC FTL ERR 04057 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
 OVERFLOW WHEN CALCULATING THE L/DBN FROM THE GIVEN CYLINDER  
 CYLINDER TOO LARGE

This is a TEST 4 initialization error due to an operator error. The operator entered a cylinder number, that when converted to a block number, the block number exceeded  $(2^{*28}) - 1$ . Go back to the manual intervention questions and check the answers to the STARTING AND ENDING CYLINDER questions. Inhibiting the dropping of units has no effect on this error.

## 3.2.3.52 4058 - TRACK EXCEEDS MAXIMUM FOR DEVICE -

## 3.2.3.53 4058 - GROUP EXCEEDS MAXIMUM FOR DEVICE -

CZUDI DVC FTL ERR 04058 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
TRACK EXCEEDS MAXIMUM FOR DEVICE. MAXIMUM IS maximum\_track

## maximum\_track:

This is the highest track number the operator can specify.

This is a TEST 4 initialization error due to an operator error. Go back to the manual intervention questions and check the answers to the TRACK questions. Inhibiting the dropping of units has no effect on this error.

CZUDI DVC FTL ERR 04058 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
GROUP EXCEEDS MAXIMUM FOR DEVICE. MAXIMUM IS maximum\_group

## maximum\_group:

This is the highest group number the operator can specify.

This is a TEST 4 initialization error due to an operator error. Go back to the manual intervention questions and check the answers to the GROUP questions. Inhibiting the dropping of units has no effect on this error.

## 3.2.3.54 4059 - TWO IDENTICAL TRACKS -

## 3.2.3.55 4059 - TWO IDENTICAL GROUPS -

CZUDI DVC FTL ERR 04059 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
TWO IDENTICAL TRACKS

This is a TEST 4 initialization error due to an operator error. Go back to the manual intervention questions and check the answers to the TRACK questions. Inhibiting the dropping of units has no effect on this error.

CZUDI DVC FTL ERR 04059 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT

## TWO IDENTICAL GROUPS

This is a TEST 4 initialization error due to an operator error. Go back to the manual intervention questions and check the answers to the GROUP questions. Inhibiting the dropping of units has no effect on this error.

## 3.2.3.56 4062 - DBN COMPUTED FROM END CYLINDER GIVEN EXCEEDS MAXIMUM DBN NUMBER -

CZUDI DVC FTL ERR 04062 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
DBN COMPUTED FROM END CYLINDER GIVEN EXCEEDS MAXIMUM DBN NUMBER ON  
DEVICE - CYLINDER TOO LARGE

This is a TEST 4 initialization error due to an operator error. Note that though there may be writeable DBN's on the 'last' cylinder, the read only diagnostic area may start on that same cylinder, and TEST 4 tries to write to the end of the cylinder that the operator specified. Therefore, specify the previous cylinder if cylinders must be specified. Inhibiting the dropping of units has no effect on this error.

CZUDI DVC FTL ERR 04062 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
OPERATOR ERROR IN ANSWERING MANUAL INTERVENTION QUESTIONS FOR THIS UNIT  
LBN COMPUTED FROM END CYLINDER GIVEN EXCEEDS MAXIMUM LBN NUMBER ON  
DEVICE - CYLINDER TOO LARGE

This is a TEST 4 initialization error due to an operator error. Note that though there may be writeable LBN's on the 'last' cylinder, the RCT area may start on that same cylinder, and TEST 4 tries to write to the end of the cylinder that the operator specified. Therefore, specify the previous cylinder if cylinders must be specified. Inhibiting the dropping of units has no effect on this error.

## 3.2.3.57 4063 - REAL TIME STATE RECEIVE ERROR DURING WRITE -

CZUDI SFT ERR 04063 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
REAL TIME STATE RECEIVE ERROR DURING WRITE  
ATTEMPT attempt  
type bn  
SECTORS FROM INDEX sector TRK track GRP group CYL cylinder  
ORIGIN OF SEEK: GRP group CYL cylinder  
REAL TIME STATE state  
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

The real time drive state receive error is detected at the end of an I/O operation and indicates that there was a pulse or parity error in the receipt of the drive's state during the I/O operation.

See retry/recovery section for recovery details.

### 3.2.3.58 4064 - REAL TIME STATE RECEIVE ERROR DURING READ -

```
CZUDI SFT ERR 04064 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
REAL TIME STATE RECEIVE ERROR DURING READ
ATTEMPT attempt
type bn
SECTORS FROM INDEX sector TRK track GRP group CYL cylinder
ORIGIN OF SEEK: GRP group CYL cylinder
REAL TIME STATE state
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0
```

The real time drive state receive error is detected at the end of an I/O operation and indicates that there was a pulse or parity error in the receipt of the drive's state during the I/O operation.

See retry/recovery section for recovery details.

### 3.2.3.59 4068 - UNKNOWN ERROR CODE DURING WRITE -

```
CZUDI WRD ERR 04068 ON UNIT unit TST 001 SUB 000 PC: hostpc
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss
UNKNOWN ERROR CODE DURING WRITE
ERROR CODE RETURNED error_code
REAL TIME STATE state
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0
```

error\_code:

This is the error code returned to TEST 4 by the controller that TEST 4 does not recognize.

The unknown error code occurs when the controller returns an error code from an operation that TEST 4 does not recognize. Possible controller microcode change without TEST 4 update.

See retry/recovery section for recovery details.

### 3.2.3.60 4069 - UNKNOWN ERROR CODE DURING READ -

CZUDI HRD ERR 04069 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 UNKNOWN ERROR CODE DURING READ  
 ERROR CODE RETURNED error\_code  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

#### error\_code:

This is the error code returned to TEST 4 by the controller that TEST 4 does not recognize.

The unknown error code occurs when the controller returns an error code from an operation that TEST 4 does not recognize. Possible controller microcode change without TEST 4 update.

See retry/recovery section for recovery details.

### 3.2.3.61 4070 - TIMEOUT OF SEND -

CZUDI SFT ERR 04070 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 TIMEOUT OF SEND  
 command\_type  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

#### command\_type:

See section following error 4078 for a description

If TEST 4 tries to send a level 2 command to the drive, and receiver ready is deasserted, error 4070 occurs.

See retry/recovery section for recovery details.

### 3.2.3.62 4071 - TIMEOUT OF RECEIVE -

CZUDI SFT ERR 04071 ON UNIT unit TST 001 SUB 000 PC: hostpc  
 DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
 TIMEOUT OF RECEIVE  
 command\_type  
 REAL TIME STATE state  
 STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

#### command\_type:

See section following error 4078 for a description

This error is a failure of the drive to respond to an SDI level 2

command (see the SDI specification) before the drive-supplied command timeout expires.

See retry/recovery section for recovery details.

### 3.2.3.63 4072 - FIRST WORD RECEIVED WAS NOT START FRAME -

CZUDI SFT ERR 04072 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
FIRST WORD RECEIVED WAS NOT START FRAME

command\_type  
REAL TIME STATE state  
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

command\_type:  
See section following error 4078 for a description

The first word received by the controller from the drive was not a valid message start frame.

See retry/recovery section for recovery details.

### 3.2.3.64 4073 - FRAMING ERROR ON LEVEL 0 RECEIVE -

CZUDI SFT ERR 04073 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
FRAMING ERROR ON LEVEL 0 RECEIVE

command\_type  
REAL TIME STATE state  
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

command\_type:  
See section following error 4078 for a description

Error 4073 is caused by one or more of the following conditions: 1) Illegal frame code -- the frame is not a message start, continue, or end frame. 2) Illegal sequence of frames -- such as a message start frame without ever receiving a message end frame. This can be caused by the drive sending a response before the controller asserts receiver ready, or a random hit on the SDI cable that garbles a frame or a bad drive transmitter or receiver on the controller.

See retry/recovery section for recovery details.



## 3.2.3.65 4074 - CHECKSUM ERROR ON LEVEL 0 RECEIVE -

CZUDI SFT ERR 04074 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
CHECKSUM ERROR ON LEVEL 0 RECEIVE

command\_type  
REAL TIME STATE state  
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

command\_type:  
See section following error 4078 for a description

The checksum attached to a message end frame did not match the checksum computed over the level 2 command. This could be caused by a bad drive transmitter, bad controller receiver, incorrectly computed checksum by the drive (unlikely) or a random hit on the SDI cable.

See retry/recovery section for recovery details.

## 3.2.3.66 4075 - BUFFER SIZE SMALLER THAN LEVEL 2 RESPONSE -

CZUDI SFT ERR 04075 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
BUFFER SIZE SMALLER THAN LEVEL 2 RESPONSE

command\_type  
REAL TIME STATE state  
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

command\_type:  
See section following error 4078 for a description

The buffer size set aside for the response was not large enough for the response received. This is caused by the drive sending a response that is incorrect for the request sent to the drive, or the drive sending some garbage with the response.

See retry/recovery section for recovery details.

## 3.2.3.67 4076 - RESPONSE OF LEVEL 2 CMD NOT AS EXPECTED -

CZUDI SFT ERR 04076 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
RESPONSE OF LEVEL 2 CMD NOT AS EXPECTED

command\_type  
EXPECTED RESPONSE expected\_response  
RESPONSE RECEIVED response\_received  
REAL TIME STATE state  
STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0

**command\_type:**  
See section following error 4078 for a description

**expected\_response:**  
This is the correct response (HEX) for the command.

**response\_received:**  
This is the response received from the drive, (HEX) where a 7D is an unsuccessful response. Any other than a 7D for this value indicates a <<VREY>> sick drive.

This is caused by receiving an UNSUCCESSFUL response from the drive, or the drive sending some response other than the correct response for the request sent to the drive. See the contents of status for the unexpected response error (or reason).

See retry/recovery section for recovery details.

### 3.2.3.68 4077 - DRIVE NEVER DEASSERTED RECEIVER READY AFTER LEVEL 2 SEND -

CZUDI SFT ERR 04077 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
DRIVE NEVER DEASSERTED RECEIVER READY AFTER LEVEL 2 SEND

**command\_type**  
**REAL TIME STATE state**  
**STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0**

**command\_type:**  
See section following error 4078 for a description

After a successful send of a level 2 command and before receiving the response, TEST 4 checks the drive's receiver ready to make sure it has been deasserted. If it hasn't, error 4077 is printed.

See retry/recovery section for recovery details.

### 3.2.3.69 4078 - UNKNOWN ERROR CODE RETURNED FROM LEVEL 2 RECEIVE -

CZUDI SFT ERR 04078 ON UNIT unit TST 001 SUB 000 PC: hostpc  
DISK EXERCISER DM PC:dmpc CONTROLLER AT caddr DRIVE plug RUNTIME hh:mm:ss  
UNKNOWN ERROR CODE RETURNED FROM LEVEL 2 RECEIVE

**command\_type**  
**ERROR CODE RETURNED error\_code**  
**REAL TIME STATE state**  
**STATUS (R TO L): word6 word5 word4 word3 word2 word1 word0**

**command\_type:**

**error\_code:**

This is the error code returned to TEST 4 by the controller that TEST 4 does not recognize.

The unknown error code occurs when the controller returns an error code from an operation that TEST 4 does not recognize. Possible controller microcode change without TEST 4 update.

See retry/recovery section for recovery details.

NOTE: Errors 4070 - 4078 will become device fatal if attempted 3 times. If dropping of units are inhibited, error recovery is the same as if the error was a soft error.

**command\_type:**

in errors 4070-4078 command\_type is one of the following level 2 commands:

ATTEMPTING TO BRING DRIVE ONLINE  
ATTEMPTING TO ISSUE SEEK  
ATTEMPTING TO GET STATUS  
ATTEMPTING DRIVE CLEAR CMD  
ATTEMPTING TO BRING DRIVE ONLINE  
ATTEMPTING TO CHANGE MODE  
ATTEMPTING ERROR RECOVERY CMD  
ATTEMPTING TO ISSUE SEEK  
ATTEMPTING TO RECALIBRATE

The following command\_types occur only during initialization, and will cause a device fatal if they occur. Inhibiting the dropping of units has no effect on these errors.

ATTEMPTING TO SPIN UP DRIVE  
ATTEMPTING TO GET COMMON CHAR  
ATTEMPTING TO GET SUBUNIT CHAR

If <<ANY>> error occurs during initialization, <<NO>> testing is done on <<ANY>> drive attached to the controller that the initialization error occurred on. See error number 4016.

**3.2.4 SPECIAL DEVICE FATAL (05000) -**

CZUDI DVC FTL ERR 05000 ON UNIT 00 TST 001 SUB 000 PC: hostpc  
 DISK zzzzzzzz DM PC: dmpc CONTROLLER AT car DRIVE plug RUNTIME hhh:mm:ss  
 UNABLE TO FIND REQUESTED DRIVE FOR TESTING  
 THE FOLLOWING IS VISIBLE ON THE PORTS  
 PORT 0 -- description  
 PORT 1 -- description  
 PORT 2 -- description  
 PORT 3 -- description

Where zzzzzzzz is either 'RESIDENT', 'FUNCION' or 'EXERCISER'. This message is presented when the specified drive was not found by test 2 or test 3 on any of the ports. A description of what was on each port follows.

**NO DRIVE ATTACHED**

There is nothing on the port. If there is suppose to be a drive on this port, make sure there is an odd number of cables between the controller and the drive and make sure the cables are properly attached.

**RCVR RDY NEVER ASSERTED**

The device on the port did not assert RCVR RDY while trying to get state.

**TIMEOUT OF SEND**

Sending an SDI command timed out. RCVR RDY is not asserted.

**TIMEOUT OF RECEIVE**

Receiving an SDI command timed out. The drive failed to respond to an SDI level 2 command before a timeout expired.

**FIRST WORD RECEIVED WAS NOT START FRAME**

The first word received by the controller from the drive was not a valid message start frame.

**FRAMING ERROR ON LEVEL 0 RECEIVE**

The device and the controller are out of sync or an illegal frame code (the frame is not a message start, continue, or end frame) or illegal sequence of frames. This can be caused by the drive sending a response before the controller asserts receiver ready, or a random hit on the SDI cable that garbles a frame or a bad drive transmitter or controller receiver.

**CHECKSUM ERROR ON LEVEL 0 RECEIVE**

The checksum attached to a message end frame did not match the checksum computed over the level 2 command. This could be caused by a bad drive transmitter, bad controller receiver, incorrectly computed checksum by the drive (unlikely) or a random hit on the SDI cable.

**RESPONSE LONGER THAN EXPECTED FOR CMD**

The buffer size set aside for the response was not large enough for

the response received. This is caused by the drive sending a response that is incorrect for the request sent to the drive, or the drive sending some garbage with the response.

**DRIVE n [further explanation]**

A drive was found at the end of the cable. A further explanation may be presented. These further explanations are:

**DRIVE NOT AVAILABLE TO THIS CONTROLLER**

The drive was found but is not available to this controller. It may be dual ported and the drive is online to another controller.

**UNSPINABLE DRIVE**

The drive is unspinnable. The drive may be powered up but the RUN/STOP switch may be popped out.

#### 4.0 DM PROGRAM RETRY AND RECOVERY METHODS

##### 4.1 ECC ERRORS

ECC DETECTED ERROR, BUT CORRECTION FAILED  
ECC CORRECTIONS EXCEED THRESHOLD  
ECC DETECTED ERROR (If ECC correction disabled)

**Retry/Recovery** - The controller or TEST 4 will first re-read the sector with the erroneous ECC N times, then N times for each level of error recovery the drive supports. The value of N is an SDI drive characteristic. This retry mechanism will persist until either the recovery level reaches zero or the operation succeeds. It should be noted that the manual intervention questions can disable retries (in this case the recovery fails the first time) and disable error correction (i.e., no ECC correction will be performed). ECC correction and retries are <<ALWAYS>> enabled when TEST 4 is reading the RCT.

**Recovery success** - One soft error is counted for the entire operation including retries.

**Recovery Failure** - TEST 4 will issue a hard error for the sector. No soft errors will be counted.

##### 4.2 EDC ERRORS

EDC DETECTED ERROR BUT ECC DID NOT  
ECC CORRECTION SUCCEEDED, BUT EDC DETECTS ERROR

This error is indicative of a controller hardware error, either a SERDES failure or an undetected RAM failure, or a sector that was written with an incorrectly computed EDC.

**Retry/Recovery** - The controller or TEST 4 will re-read the sector with the erroneous EDC N times, then N times for each level of error recovery the drive supports. The value of N is an SDI drive characteristic. This retry mechanism will persist until either the recovery level reaches zero or the operation succeeds. It should be noted that the manual intervention questions can disable retries (in this case the recovery fails the first time). Retries are <<ALWAYS>> enabled when TEST 4 is reading the RCT.

**Recovery success** - One soft error is counted for the entire operation including retries.

**Recovery Failure** - TEST 4 will issue a hard error for the sector. No soft errors will be counted.

#### 4.3 SDI LEVEL 2 AND ASYNCHRONOUS ERRORS

The SDI level 2 errors are as follows:

- o Packet acknowledge failure
- o Level 2 command error response, "DE" bit set
- o Level 2 command error response, "PE" or "RE" bit set
- o Receipt of erroneous drive response
- o Seek complete timeout
- o Asynchronous drive errors

Level 2 errors are always retried, even if retries are disabled in the manual intervention questions.

In the following retry/recovery algorithms, TEST 4 'Generic error recovery' is the following steps:

1. Issue online command
2. Get status
  - 2a. If the port, run or spindle ready (PS, RU or SR) bit is deasserted, an Immediate device fatal error is reported and the unit and all its subunits are dropped from testing.
  - 2b. If the recalibrate requested (RR) bit is set, TEST 4 will issue a RECALIBRATE, then SEEK <<AFTER>> generic error recovery is complete.
  - 2c. If the drive error (DE) bit is set, TEST 4 will issue a SEEK <<AFTER>> generic error recovery is complete.
3. If no drive errors, go to 5
4. Send DRIVE CLEAR command
5. Change mode

NOTE: If the drive's timeout expires once, so the drive asserts attention just to get TEST 4 to issue a level 2, TEST 4 will go through the above error recovery. However, since the timeout expiring is not an error, no error message is issued.

##### 4.3.1 PACKET ACKNOWLEDGE FAILURE -

TIMEOUT OF SEND  
TIMEOUT OF RECEIVE

The timeout of send occurs when the controller attempts to send a level 2 command to the drive, but the drive's receiver ready is not asserted. Timeout of receive is a failure of the drive to

respond to an SDI level 2 command (see the SDI specification) before the drive-supplied command timeout expires. These errors are grouped together because their recoveries are the same.

Retry/Recovery - Controller mode - The steps listed below are performed.

1. The drive is initialized.
2. An SDI GET STATUS command is issued.
  3. If the status obtained in the previous step indicated error conditions, these error conditions are resolved and then cleared by an SDI DRIVE CLEAR command.
4. An SDI SEEK command is issued.
5. The command is retried.

Retry/Recovery - TEST 4 - The steps listed below are performed.

1. The drive is initialized
2. TEST 4 Generic error recovery is performed
3. An SDI SEEK command is issued.
4. The command is retried.

Recovery success - One soft error is counted for the entire operation including retries.

Recovery Failure - The above sequence will be repeated two times and, if the failure persists, TEST 4 will issue a device fatal error and the drive and all its subunits will be dropped. It should be noted that the retry strategy for SDI level 2 errors involves issuing additional level 2 commands. The retry count is the sum of all retries on all SDI level 2 commands, including those commands issued in recovery attempts.

#### 4.3.2 LEVEL 2 COMMAND ERROR RESPONSES -

##### RESPONSE OF LEVEL 2 CMD NOT AS EXPECTED

A level 2 error response is when a command has successfully been sent to the drive and an error-free level 2 response has been received which has a UNSUCCESSFUL or unrecognized opcode.



## 4.3.2.1 "DE" BIT SET -

## RESPONSE OF LEVEL 2 CMD NOT AS EXPECTED

An UNSUCCESSFUL response to a level 2 command, with the "DE" bit set in the status response, notifies TEST 4 that a drive error was detected (or occurred) in connection with the execution of the SDI command.

Retry/Recovery - Controller mode - The steps listed below are performed.

1. An SDI GET STATUS command is issued.
2. The drive error is cleared by an SDI DRIVE CLEAR command and a SEEK command is issued for the cylinder where the drive was positioned when the error was reported.
3. The command is retried.

Retry/Recovery - TEST 4 - The steps listed below are performed.

1. TEST 4 Generic error recovery is performed. Note that because the "DE" bit is set, TEST 4 generic error recovery will issue a SEEK (see generic error recovery)
2. The command is retried

Recovery success - One soft error is counted for the entire operation including retries.

Recovery Failure - The above sequence is repeated two times and, if the failure persists, TEST 4 will issue a device fatal error and the drive and all its subunits will be dropped. Note that the retry strategy for SDI level 2 errors involves issuing additional level 2 commands. The retry count is the sum of all retries on all SDI level 2 commands, including those commands issued in recovery attempts.

## 4.3.2.2 "PE" OR "RE" BIT SET -

## RESPONSE OF LEVEL 2 CMD NOT AS EXPECTED

An UNSUCCESSFUL response to a level 2 command with the "PE" or "RE" bit set in the status response notifies TEST 4 that the command either was not appropriate for the state of the drive, or that the command contained invalid arguments.

Retry/Recovery - Controller mode - The steps listed below are performed.

1. An SDI GET STATUS command is issued
2. The drive error is cleared by an SDI DRIVE CLEAR command.
3. The controller verifies the state of the drive and, if possible, retries the level 2 command. Otherwise, the controller notifies the host and bypasses subsequent retries.

Retry/Recovery - TEST 4 - The steps listed below are performed.

1. TEST 4 Generic error recovery is performed
2. The command is retried

Recovery success - One soft error is counted for the entire operation including retries.

Recovery Failure - The above sequence is repeated two times and, if the failure persists, TEST 4 will issue a device fatal error and the drive and all its subunits will be dropped. Note that the retry strategy for SDI level 2 errors involves issuing additional level 2 commands. The retry count is the sum of all retries on all SDI level 2 commands, including those commands issued in recovery attempts.

#### 4.3.3 RECEIPT OF AN ERRONEOUS DRIVE RESPONSE -

FIRST WORD RECEIVED WAS NOT START FRAME  
FRAMING ERROR ON LEVEL 0 RECEIVE  
CHECKSUM ERROR ON LEVEL 0 RECEIVE  
BUFFER SIZE SMALLER THAN RESPONSE  
DRIVE NEVER DEASSERTED RECEIVER READY AFTER LEVEL 2 SEND  
UNKNOWN ERROR CODE RETURNED FROM LEVEL 2 RECEIVE (hard error)

The first word not start frame error is caused when the controller does not see a valid message start frame as the first frame received from the drive. The framing error is caused by the controller receiving an illegal frame code -- the frame is not a message start, continue, or end frame or Illegal sequence of frames -- such as a message start frame without ever receiving a message end frame. The checksum error occurs when a message end frame checksum did not match the checksum computed over the level 2 command. The buffer size smaller than response error occurs when the buffer set aside for the response was not large

enough for the response received. The unknown error code is returned when the controller returns an error code that TEST 4 does not recognize. These errors are grouped together because their recoveries are the same.

Retry/Recovery - Controller mode - The steps listed below are performed.

1. An SDI GET STATUS command is issued.
2. If the status obtained in the previous step indicated error conditions, these error conditions are resolved and then cleared by an SDI DRIVE CLEAR command.
3. The command is retried.

Retry/Recovery - TEST 4 - The steps listed below are performed.

1. TEST 4 Generic error recovery is performed
2. The command is retried

Recovery success - One soft error is counted for the entire operation including retries.

Recovery Failure - The above sequence is repeated two times and, if the failure persists, TEST 4 will issue a device fatal error and the drive and all its subunits will be dropped. Note that the retry strategy for SDI level 2 errors involves issuing additional level 2 commands. The retry count is the sum of all retries on all SDI level 2 commands, including those commands issued in recovery attempts.

#### 4.3.4 SEEK COMPLETE TIMEOUT -

ATTN ASSERTED DURING SEEK  
SEEK DID NOT COMPLETE, NEITHER ATTN OR R/W RDY WAS ASSERTED

This error occurs when the drive fails to assert READ/WRITE READY, indicating the successful completion of a seek, or asserts the SDI ATTENTION signal without asserting the READ/WRITE READY signal, indicating the unsuccessful completion of a seek.

Retry/Recovery - Controller mode - The steps listed below are performed.

1. An SDI GET STATUS command is issued.
2. If the status obtained in the previous step indicated error conditions, these error conditions are resolved and then cleared by an SDI DRIVE CLEAR command.

3. The SEEK is retried.

Retry/Recovery - TEST 4 - The steps listed below are performed.

1. TEST 4 Generic error recovery is performed
2. The SEEK is retried

Recovery success - One soft error is counted for the entire operation including retries.

Recovery Failure - The above sequence is repeated two times and, if the failure persists, TEST 4 will issue a device fatal error and the drive and all its subunits will be dropped. Note that the retry strategy for SDI level 2 errors involves issuing additional level 2 commands. The retry count is the sum of all retries on all SDI level 2 commands, including those commands issued in recovery attempts.

#### 4.3.5 ASYNCHRONOUS DRIVE ERRORS -

##### ATTN ASSERTED UNEXPECTEDLY, ASYN DRIVE ERROR OR LOGGABLE INFORMATION

Asynchronous drive errors are those errors reported by the drive which are not related to a level 2 or command. These errors are reported by the drive using the SDI ATTENTION signal. Examples are OFF CYLINDER and HDA OVERTEMPERATURE errors. Drive errors are reported to the controller by the "DE" or "WE" bit being set in the error byte in the status response.

Retry/Recovery - Controller mode - The steps listed below are performed.

1. An SDI GET STATUS command is issued.
2. The drive error is cleared by an SDI DRIVE CLEAR command and, if the error is not "WE", a SEEK command is issued for the cylinder where the drive was last positioned.

Retry/Recovery - TEST 4 - The steps listed below are performed.

1. TEST 4 Generic error recovery is performed
2. A SEEK is issued

NOTE: A "WE" is a write on a write protected drive; TEST 4 detects this in a different manner, so "WE" will never be set.

Recovery Failure -

**NOTE:** There is a difference between the controller mode and TEST 4 for this type of error.

When in controller mode, the controller will repeat the above sequence two times and, if the drive error persists, the drive would be marked as offline.

TEST 4 will <<NOT>> drop the drive after two retries. Instead, the drive will be dropped due to a side effect of such an error: A seek never completing, (causing a device fatal error) or Spindle ready dropping (causing a device fatal error).

#### 4.3.5.1 DRIVE I/O ERRORS -

The drive I/O errors occur either during the header compare process (i.e., before I/O actually begins) or during the I/O operation itself. They are as follows:

- o Header not found
- o Seek or head select error
- o Data sync timeout
- o Data or state clock timeout during operation (read/write)
- o Receiver ready dropped during operation (read/write)
- o Read/write ready dropped during operation (read/write)
- o SERDES overrun error
- o Drive failed to execute select track and (read/write)
- o Real time state receive error

#### 4.3.6 HEADER NOT FOUND (HEADER COMPARE ERROR) -

##### HEADER NOT FOUND DURING (read/write)

This error occurs when the header compare routine fails to find the desired header (or a revectorized version of the desired header) in two disk revolutions.

**Retry/Recovery - Controller mode and TEST 4 -** Failure to find the desired header in two rotations of the disk will cause TEST 4 to search the Replacement and Caching Table (RCT) to check if the logical block number has been replaced. If a match is found, TEST 4 will perform the desired operation on the revectorized block. Enabling/disabling retries has no effect on this operation.

**Recovery success -** No error is reported or counted.

**Recovery Failure -** A hard error (header not found) is reported.

## 4.3.7 SEEK OR HEAD SELECT ERROR (POSITIONER ERROR) -

## SEEK OR HEAD SELECT ERROR DETECTED DURING (read/write)

This error occurs when the header comparison routine determines that the drive is positioned at the wrong cylinder and that the drive has not detected a seek error.

NOTE: The header comparison routine is active <<ONLY>> in the customer data area. This error will never be detected in the diagnostic area.

Retry/Recovery - Controller mode - The steps listed below are performed.

1. An SDI GET STATUS command is issued.
2. If the status obtained in the previous step indicated error conditions, these error conditions are resolved and then cleared by an SDI DRIVE CLEAR command.
3. An SDI RECALIBRATE command is issued.
4. An SDI SEEK command is issued.
5. The I/O operation is retried.

Retry/Recovery - TEST 4 - The steps listed below are performed.

1. TEST 4 Generic error recovery is performed
2. An SDI RECALIBRATE command is issued.
3. An SDI SEEK command is issued.
4. If retries are disabled, Immediate recovery failure. Retries are <<ALWAYS>> enabled when TEST 4 is reading the RCT.
5. The I/O operation is retried.

Recovery success - One soft error is counted for the entire operation including retries.

Recovery Failure - The above sequence is repeated two times and, if a drive I/O error persists, a hard error is reported for the sector. No soft errors are counted.

**4.3.8 DATA SYNC TIMEOUT ERROR -****DATA SYNC TIMEOUT DURING READ**

This error occurs on a read operation after the correct header has been found and the controller times out waiting for the data sync word.

Retry/Recovery - Controller mode - The steps listed below are performed.

1. An SDI GET STATUS command is issued.
2. If the status obtained in the previous step indicated error conditions, these error conditions are resolved and then cleared by an SDI DRIVE CLEAR COMMAND.
3. An SDI SEEK command is issued.
4. The read operation is retried.

Retry/Recovery - TEST 4 - The steps listed below are performed.

1. TEST 4 Generic error recovery is performed
2. An SDI SEEK command is issued.
3. If retries are disabled, Immediate recovery failure. Retries are <<ALWAYS>> enabled when TEST 4 is reading the RCT.
4. The read operation is retried.

Recovery success - One soft error is counted for the entire operation including retries.

Recovery Failure - The above sequence is repeated two times and, if a drive I/O error persists, a hard error is reported for the sector. No soft errors are counted.

**4.3.9 DATA OR STATE CLOCK TIMEOUT (LOSS OF DRIVE CLOCK) OR RECEIVER READY FAILURE (Loss Of Drive Receiver Ready) -**

DATA OR STATE CLOCK TIMEOUT DURING (read/write)  
RCVR RDY DROPPED DURING (read/write)  
COULD NOT SEND SELECT TRACK AND (read/write) CMD OR  
HEADER SYNC TIMEOUT WITH INVALID STATE

The loss of drive clock occurs when the controller is clocking data to or from the drive through the SERDES. Failure of a word to be clocked in during a 125 millisecond time period triggers a

loss of drive clock error. The loss of drive receiver ready is detected when the controller is trying to send out a real-time read or write command. Unable to select track and read or write occurs when the controller attempts to send the select track and read/write level 1 cmd, but receiver ready is deasserted or the state is invalid so it cannot send the command (the SERDES could also be broken so it's unable to send the command). The same error is generated if the controller gets a header sync timeout, and when it looks at the drive's state, it is either invalid or receiver ready is deasserted (header sync timeout is <<NOT>> a error -- it's quite normal on a high-density disk). These errors are grouped together because their recoveries are the same.

Retry/Recovery - Controller mode - The steps listed below are performed.

1. The drive is initialized.
2. An SDI GET STATUS command is issued.
  3. If the status obtained in the previous step indicated error conditions, these error conditions are resolved and then cleared by an SDI DRIVE CLEAR command.
4. An SDI SEEK command is issued.
5. The I/O operation is retried.

Retry/Recovery - TEST 4 - The steps listed below are performed.

1. The drive is initialized
2. TEST 4 Generic error recovery is performed
3. An SDI SEEK command is issued.
  4. If retries are disabled, Immediate recovery failure. Retries are <<ALWAYS>> enabled when TEST 4 is reading the RCT.
5. The I/O operation is retried.

Recovery success - One soft error is counted for the entire operation including retries.

Recovery Failure - The above sequence is repeated two times and, if a drive I/O error persists, a hard error is reported for the sector. No soft errors are counted.



#### 4.3.10 READ/WRITE READY DROPPED (LOSS OF DRIVE READ/WRITE READY) OR SERDES - OVERRUN ERROR OR REAL TIME STATE RECEIVE ERROR (REAL TIME DRIVE STATE RECEIVE ERROR)

R/W RDY DROPPED DURING (read/write)  
SERDES OVERRUN ERROR DURING READ  
REAL TIME STATE RECEIVE ERROR DURING (read/write)  
UNKNOWN ERROR CODE DURING (read/write)

The loss of read/write ready error is detected either before an I/O has begun when trying to send out the real time command or at the end of an I/O operation when checking for errors. The SERDES overrun error is detected on a read operation and is indicative of a drive whose transfer rate is greater than 23 MHz or a broken SERDES. The real time drive state receive error is detected at the end of an I/O operation and indicates that there was a pulse or parity error in the receipt of the drive's state during the I/O operation. The unknown error code is returned when the controller returns an error code that TEST 4 does not recognize. They are grouped together because their recoveries are the same.

Retry/Recovery - Controller mode - The steps listed below are performed.

1. An SDI GET STATUS command is issued.
2. If the status obtained in the previous step indicated error conditions, these error conditions are resolved and then cleared by an SDI DRIVE CLEAR command.
3. An SDI SEEK command is issued.
4. The I/O operation is retried.

Retry/Recovery - TEST 4 - The steps listed below are performed.

1. TEST 4 Generic error recovery is performed
2. An SDI SEEK command is issued.
3. If retries are disabled, Immediate recovery failure. Retries are <<ALWAYS>> enabled when TEST 4 is reading the RCT.
4. The read operation is retried.

Recovery success - One soft error is counted for the entire operation including retries.

Recovery Failure - The above sequence is repeated two times and, if a drive I/O error persists, a hard error is reported for the sector. No soft errors are counted.

## 5.0 DEC STANDARD 166 EXCERPTS

DEC standard 166 is also known as the Digital standard disk format (DSDF). It specifies the exact format to be found on any RA family disk.

### 5.1 The Replacement And Caching Tables

The Replacement and Caching Tables record the locations of all revectored LBN sectors and the status of each RBN on the unit. Each copy of the table is organized in ascending RBN order, with an entry for each RBN sector on the unit. There are "n" copies of the table on the unit, where "n" is a device characteristic. The tables are stored at the high address end of the LBN area of the unit. Table entries (and RBNs) are allocated via a hash algorithm described later.

### 5.2 Replacement And Caching Table Format

Each entry in the Replacement and Caching Table represents an RBN on the unit. The table is ordered in ascending RBN order. Thus the first entry corresponds to the first RBN on the unit, etc. The size of each copy of the table may exceed that required to contain an entry for each RBN on the unit since additional entries may be required to align the table so that adjacent copies can begin on a track boundary. Entries that do not correspond to RBNs on the unit are called "null entries"; there is always at least one null entry at the end of the RCT. All other entries past this last null entry are undefined.

#### NOTE

The RCT pad area is controller specific and should never be accessed by the host.

The format of a replacement block descriptor in the Replacement and Caching Tables is:

```

!<-----16 bits----->!
!-----!
!               LBN (low)      !
!-----!
!  CODE !           LBN (high)  !
!-----!
! 4 bits!<-----12 bits----->!

```

**Where:**

LBN is the Logical Block Number of a revectored LBN sector.

CODE is one of the following octal values:

- 00 - Unallocated (empty) replacement block.
- 02 - Allocated replacement block - primary RBN.
- 03 - Allocated replacement block - non-primary RBN.
- 04 - Unusable replacement block.
- \* 05 - Alternate unusable replacement block
- 10 - Null entry - no corresponding RBN sector.

For codes 00, 04, and 10 the LBN field is always zero.

**NOTE**


\* This code is reserved. Programs should treat this code as if it were code 04.

Embedded-controllers with no distinction between primary and secondary RBN's must use:

1. Code 02 if the replacement block can be retrieved with little degradation of performance for all blocks.
2. Code 03 if accessing the replacement block has a large impact on performance for all blocks.

### 5.3 FCT STRUCTURE

Each copy of the FCT is composed of one volume information block, one 512 byte format table, one 576 byte format table, and one subsystem temporary storage area (distributed amongst the alignment pads). An FCT copy has the following format:



! scratch !  
! storage ! SECTOR Fct-1  
-----

The XBN area itself is always formatted to contain 512 byte sectors. The calculations for m and p are:

m := (((Lc\*gst\*r)+1)/2)\*127)/128

p := 2\*m

## 5.4 FCT SECTOR 0 CONTENTS

Sector 0 contains various volume identification information. The format is:

media mode	WORD 0
formatting instance number	WORD 1
volume serial number least significant word	WORD 2
volume serial number	WORD 3
volume serial number	WORD 4
volume serial number most significant word	WORD 5
date that volume was first formatted (low)	WORD 6
date that volume was first formatted	WORD 7
date that volume was first formatted	WORD 8
date that volume was first formatted (high)	WORD 9
date of most recent volume formatting (low)	WORD 10
date of most recent volume formatting	WORD 11
date of most recent volume formatting	WORD 12
date of most recent volume formatting (high)	WORD 13
number of used entries in 512 table (low)	WORD 14
number of used entries in 512 table (high)	WORD 15

! number of used entries! ! in 576 table (low)	! WORD 16
! number of used entries! ! in 576 table (high)	! WORD 17
! XBN of scratch area ! in this copy (low)	! WORD 18
! XBN of scratch area ! in this copy (high)	! WORD 19
! size of scratch area ! in this copy	! WORD 20
! zeros	
! zeros	! WORD 255

**Where:**

WORD 0: "Media Mode" - is "126736" for a 512 byte format and "074161" for a 576 byte format. During formatting the media mode word is set to zero.

## 6.0 PERFORMANCE AND PROGRESS REPORTS

At the end of each pass, the pass count is given along with the total number of errors reported since the diagnostic was started. The "EOP" switch can be used to control how often the end of pass message is printed. Section 2.2 describes switches.

A statistical report will automatically be printed periodically (approximately every fifteen minutes). It can be suppressed by setting the Inhibit Statistical Report flag (e.g. START/FLAGS:ISR). This is the same report that can be printed on demand with the PRINT command. The report will contain statistics on each drive for the current pass of the test; for example:

TEST 1 IN PROGRESS RUN TIME 2:24:10

UNIT	DRIVE	SERIAL-NUMBER	SEEKS X1000	MBYTES READ	MBYTES WRITTEN	HARD ERRORS	SOFT ERRORS	ECC
0	0	1002	12	36	22	0	0	1
1	4	7342102112	14	42	29	0	2	0

Explanation of each column:

**UNIT** The unit number (number of HW P-table).

**DRIVE** The drive number (the number which appears on the "unit plug" on the front of the disk drive).

**SERIAL-NUMBER** The decimal serial number of the disk drive.

**SEEKS X1000** The decimal number of seeks performed by this drive during this pass of the test. Multiply value by 1000.

**MBYTES READ** The number of mega-bytes (million bytes) read by this drive during this pass of the test. It is this value that is used to optionally drop a drive by the READ TRANSFER LIMIT software question.

**MBYTES WRITTEN** The number of mega-bytes written by this drive during this pass of the test.

**HARD ERRORS** The number of hard error reports printed for this drive during this pass of the test. It is this value that is used to optionally drop a drive by the ERROR LIMIT software question.

**SOFT ERRORS** The number of soft errors reported for the drive during this pass of the test. A soft error is any error condition that resulted in a retry operation that eventually succeeded in recovering from the error condition. One soft error is counted even though several retry attempts may be made and does not correspond to the number of soft error reports printed. To see the soft error reports, you must change the default answer to the SUPPRESS PRINTING SOFT ERRORS software question.

**ECC** The number of times data read from the drive was modified using the error correction code (ECC) and resulted in a matching error detection code (EDC).



## 7.0 TEST SUMMARIES

The controller Host Resident Diagnostic consists of one PDP-11 diagnostic supervisor program that runs in the PDP-11 processor and one program that runs in the controller's buffer memory through an interpreter called the "diagnostic machine" which resides in the controller. The PDP-11 program mainly is responsible for downline loading the "diagnostic machine" program into the controller and starting its execution. The "diagnostic machine" program controls the testing from that point by requesting the PDP-11 processor to supply information, print error messages and update statistics. The "diagnostic machine" program informs the PDP-11 processor when a test is complete.

### 7.1 TEST 1 - DISK DRIVE EXERCISER

The purpose of test 1 is to exercise the disk drives in a manner similar to normal usage under standard operating systems. Execution of this test should give an indication of the performance of the disk drive. This test may be run for long or short periods of time, depending on how the software questions are answered.

These are two modes of operation for test 1:

1. Default operation on the entire area selected (customer or diagnostic) with all parameters selected for random operation as shown by default answers below.
2. Manual intervention mode where a number of questions are asked and operation is controlled by their answers.

Which mode is entirely determined by the answer to the first software question asking, "Enter manual intervention mode for special diagnosis?" This question would normally have been answered "N" (default) and testing will begin immediately. If answered "Y", the following series of questions will be asked for each unit selected for testing:

THE FOLLOWING QUESTIONS REFER TO UNIT xx CONTROLLER AT xxxxxx DRIVE  
xxx

This message will identify to which drive the questions are being asked. The entire series of questions will be asked for each drive, there is no short way to answer like in the hardware questions.

NUMBER OF BAD BLOCKS (D) 0 ?

An answer in the range of 1 to 16 will allow that many bad block numbers to be entered. The program will allow writes and reads to these blocks but no error messages will be printed for these

blocks. Errors encountered on these blocks will not appear in the statistics. Answer zero to bypass entering bad blocks.

#### BAD BLOCK (A) ?

This question will be asked the number of times requested by the previous answer. Any decimal number that can be converted into a 28-bit binary value will be accepted. No other error checking will be made at this time to determine if the block number actually exists on the disk.

#### CHANGE TESTING PARAMETERS FOR THIS DRIVE (L) N ?

Answer "N" to bypass all further questioning on this drive. Answer "Y" to be asked the following questions.

#### READ ONLY (L) N ?

Answer "Y" to dictate read only and prevent test 4 from performing any writes to the disk.

#### WRITE ONLY (L) N ?

This question will only be asked if the previous question was answered "N". Answer "Y" to dictate write only.

#### CHECK ALL WRITES BY READING (L) N ?

Answer "Y" to cause all writes to be checked by reading the data immediately after the write operation.

#### RANDOMLY CHECK WRITES BY READING (L) Y ?

This question will only be asked if the previous question was answered "N". Answer "Y" for the write check to be performed randomly. Answer "N" if write checks are not desired. This question is asked no matter how previous questions were asked.

#### DATA PATTERN - 0 FOR RANDOM SELECTION (D) 0 ?

There are 16 data patterns available, selected as 1 to 16. Pattern number 0 will cause patterns 1 to 15 to be randomly selected for each write. If pattern number 16 is selected, the following set of questions will be asked for a pattern to be input.

#### ENABLE ECC DATA CORRECTION (L) Y ?

A "Y" answer will enable the use of ECC to correct data errors. If the number of corrections is within the drive's threshold, an informational message will be printed identifying the block number. These ECC corrections will also appear in the statistical report for the drive. An "N" answer will prevent the

use of ECC. All ECC errors will cause an error message to be printed and retries to be attempted.

COMPARE ALL DATA READ (L) N ?

Answer "Y" to cause a data compare after every read.

RANDOMLY COMPARE DATA READ (L) Y ?

This question will only be asked if the previous question was answered "N". Answer "Y" for the data compare to be performed on random records. Answer "N" if data compares are not desired.

ENABLE RETRIES (L) Y

A "Y" answer will enable retries to be performed on disk errors.

RANDOM ACCESS MODE (L) Y ?

Answer "Y" to cause block numbers to be chosen randomly. Answer "N" to cause block numbers to be selected sequentially up and down the disk surface.

ENTER TEST AREA DESIRED:

- 0 - ENTIRE DISK AREA
- 1 - SPECIFIC BEGIN/END SETS
- 2 - SPECIFIC TRACKS & CYLINDERS
- 3 - SPECIFIC GROUPS & CYLINDERS
- 4 - SPECIFIC CYLINDERS TEST

(D) 0 ?

This question specifies the options available to limit testing to a portion of the selected area (customer or diagnostic) of the disk. A zero answer is the default which specifies to use the entire area for the test. Other answers will cause additional questions to be asked.

NUMBER OF BEGIN/END SETS (D) 1 ?

BEGIN BLOCK (A) 0 ?

END BLOCK (A) 0 ?

These questions are asked if begin/end sets were selected to limit the testing area (Answer 1). One to four sets may be specified. The BEGIN BLOCK and END BLOCK questions are asked as many times as needed.

NUMBER OF TRACKS TO TEST (D) 1 ?

TRACK (D) 0 ?

NUMBER OF GROUPS TO TEST (D) 1 ?

GROUP (D) 0 ?

One of these sets of questions is asked if either tracks and

cylinders or groups and cylinders was specified to limit the testing area (Answers 2 or 3). Up to seven tracks or groups may be specified on which testing will be limited.

#### LIMIT THE CYLINDERS TESTED (L) N ?

This question is asked only after the tracks or groups have been specified above. If testing is to be further limited to a set of cylinders, answer "Y" and the following two questions will be asked:

STARTING CYLINDER (A) 0 ?  
ENDING CYLINDER (A) 0 ?

These questions are asked if the question immediately above was answered "Y" or if cylinders were selected to limit the testing area (Answer 4). One set of cylinder numbers may be specified to limit the testing area.

After the above questions have been asked for all drives selected for testing, the following questions will be asked if data pattern 16 was selected for any drive:

NUMBER OF WORDS IN DATA PATTERN 16 (D) 1 ?  
DATA WORD (O) 0 ?

Data pattern 16 can be input by these questions. A data pattern consists of a buffer of one to 16 words which is repeated throughout the data portion of the disk block. Enter the contents of the data pattern buffer. The DATA WORD question will be repeated as needed.

The test will then initialize each controller selected for testing and downline load a "diagnostic machine" program into each controller. The "diagnostic machine" program asks what drives are to be tested and then for the parameters for each drive (the answers to the manual intervention questions or their defaults). Once all controllers have been started, the PDP-11 program responds to requests from all controllers.

The disks are then be exercised according to the parameters. The exercise consists of selecting a disk sector, seeking to the proper cylinder, then reading or writing the sector. The parameters control how the disk sector is selected, whether the sector is written or read and whether a write is followed by a read (write check).

The "diagnostic machine" program periodically sends statistics to the PDP-11 program. These statistics include counts of reads, writes, seeks and errors on a per drive basis. The PDP-11 program accumulates the statistics from all the controllers and watches for the transfer limit to be exceeded. As long as the error log is not enabled, the exceeding of the transfer limit will cause the end of the test.

Each time an error occurs, the "diagnostic machine" tells the PDP-11 program. A message is printed (or stored in the log buffer) and then the error limit for the drive is checked. If the error limit has been reached, the drive is dropped from testing. If no more drives remain to be tested, the test will end (unless the error log is enabled).

When the end of the test occurs, the accumulated statistics for each drive is printed. This statistical report can be printed at any time during testing by typing control-C then the PRINT command.

The data patterns used by the test are indicated below. Each pattern is generated by writing the pattern number in each 4-bit nibble of the first word, then repeating the data pattern (sequence of one to 16 words) throughout the rest of the data buffer. Pattern number 16 writes nibbles of zeros. When pattern number zero is used, the actual pattern number written (1 to 15) is placed in the nibbles.

**PATTERN 0** This pattern number is used to indicate any pattern number 1 to 15 chosen at random.

**PATTERN 1** Words in pattern sequence - 1

Sequence (Octal) 105613  
Sequence (Hex) 8888

**PATTERN 2** Words in pattern sequence - 1

Sequence (Octal) 031463  
Sequence (Hex) 3333

**PATTERN 3** Words in pattern sequence - 1

Sequence (Octal) 030221  
Sequence (Hex) 3091

**PATTERN 4** Words in pattern sequence - 16 (Shifting ones)

Sequence (Octal) 000001, 000003, 000007, 000017, 000037,  
000077, 000177, 000377, 000777, 001777,  
003777, 007777, 017777, 037777, 077777,  
177777

Sequence (Hex) 0001, 0003, 0007, 000F, 001F, 003F,  
007F, 00FF, 01FF, 03FF, 07FF, 0FFF,  
1FFF, 3FFF, 7FFF, FFFF

**PATTERN 5** Words in pattern sequence - 16 (Shifting zeroes)

Sequence (Octal) 177776, 177774, 177770, 177760, 177740,  
177700, 177600, 177400, 177000, 176000,  
174000, 170000, 160000, 140000, 100000,  
000000

Sequence (Hex) FFFE, FFFC, FFF8, FFF0, FFE0, FFC0,  
FF80, FF00, FE00, FC00, F800, F000,  
E000, C000, 8000, 0000

PATTERN 6 Words in pattern sequence - 16

Sequence (Octal) 000000, 000000, 000000, 177777, 177777,  
177777, 000000, 000000, 177777, 177777,  
000000, 177777, 000000, 177777, 000000,  
177777

Sequence (Hex) 0000, 0000, 0000, FFFF, FFFF, FFFF,  
0000, 0000, FFFF, FFFF, 0000, FFFF,  
0000, FFFF, 0000, FFFF

PATTERN 7 Words in pattern sequence - (BINARY 1011011011011001)

Sequence (Octal) 133331

Sequence (Hex) B6D9

PATTERN 8 Words in pattern sequence - 16

Sequence (Octal) 052525, 052525, 052525, 125252, 125252,  
125252, 052525, 052525, 125252, 125252,  
052525, 125252, 052525, 125252, 052525,  
125252

Sequence (Hex) 5555, 5555, 5555, AAAA, AAAA, AAAA,  
5555, 5555, AAAA, AAAA, 5555, AAAA,  
5555, AAAA, 5555, AAAA

PATTERN 9 Words in pattern sequence - 1 (BINARY 1101101101101100)

Sequence (Octal) 155554

Sequence (Hex) D86C

PATTERN 10 Words in pattern sequence - 16

Sequence (Octal) 026455, 026455, 026455, 151322, 151322,  
151322, 026455, 026455, 151322, 151322,  
026455, 151322, 026455, 151322, 026455,  
151322

Sequence (Hex) 2020, 2020, 2020, D202, D202, D202,  
2020, 2020, D202, D202, 2020, D202,  
2020, D202, 2020, D202

PATTERN 11 Words in pattern sequence - 1 (BINARY 0110110110110110)

Sequence (Octal) 066666

Sequence (Hex) 6DD6

**PATTERN 12** Words in pattern sequence - 16 (Ripple one)

Sequence (Octal) 000001, 000002, 000004, 000010, 000020,  
000040, 000100, 000200, 000400, 001000,  
002000, 004000, 010000, 020000, 040000,  
100000

Sequence (Hex) 0001, 0002, 0004, 0008, 0010, 0020,  
0040, 0080, 0100, 0200, 0400, 0800,  
1000, 2000, 4000, 8000

**PATTERN 13** Words in pattern sequence - 16 (Ripple zero)

Sequence (Octal) 177776, 177775, 177773, 177767, 177757,  
177737, 177677, 177577, 177377, 176777,  
175777, 173777, 167777, 157777, 137777,  
077777

Sequence (Hex) FFFE, FFFD, FFFB, FFF7, FFEF, FFDF,  
FFBF, FF7F, FEFF, FDFE, FBFF, F7FF,  
EFFF, DFFF, BFFF, 7FFF

**PATTERN 14** Words in pattern sequence - 3

Sequence (Octal) 155555, 133333, 155555  
Sequence (Hex) DB6D, B6DB, DB6D

**PATTERN 15** Words in pattern sequence - 16

Sequence (Octal) 133331, 133331, 133331, 155554, 155554,  
155554, 133331, 133331, 155554, 155554,  
133331, 155554, 133331, 155554, 133331,  
155554

Sequence (Hex) B6D9, B6D9, B6D9, DB6C, DB6C, DB6C,  
B6D9, B6D9, DB6C, DB6C, B6D9, DB6C,  
B6D9, DB6C, B6D9, DB6C

**PATTERN 16** This is the operator selectable pattern in manual intervention mode. Questions are asked when the test is started for the operator to input the number of words in the sequence and the contents of the words.

Sample of terminal dialogue going through manual intervention questions:

DR>STA

CHANGE HW (L) ? N

CHANGE SW (L) ? Y

ENTER MANUAL INTERVENTION MODE FOR SPECIAL DIAGNOSIS (L) N ? Y

ERROR LIMIT (D) 32 ?  
 READ TRANSFER LIMIT IN MEGABYTES - 0 FOR NO LIMIT (D) 0 ?  
 SUPPRESS PRINTING SOFT ERRORS (L) Y ? N  
 DO INITIAL WRITE ON START (L) Y ?  
 ENABLE ERROR LOG (L) N ?

THE FOLLOWING QUESTIONS REFER TO UNIT 0 CONTROLLER AT 172150 DRIVE 0

NUMBER OF BAD BLOCKS (D) 0 ? 2

BAD BLOCK (A) ? 234

BAD BLOCK (A) ? 8900

CHANGE TESTING PARAMETERS FOR THIS DRIVE (L) N ? Y

READ ONLY (L) N ?

WRITE ONLY (L) N ?

CHECK ALL WRITES BY READING (L) N ? Y

DATA PATTERN - 0 FOR RANDOM SELECTION (D) 0 ? 1

ENABLE ECC DATA CORRECTION (L) Y ?

COMPARE ALL DATA READ (L) N ? Y

ENABLE RETRIES (L) Y ?

RANDOM ACCESS MODE (L) Y ? N

ENTER TEST AREA DESIRED:

- 0 - ENTIRE DISK AREA
- 1 - SPECIFIC BEGIN/END SETS
- 2 - SPECIFIC TRACKS & CYLINDERS
- 3 - SPECIFIC GROUPS & CYLINDERS
- 4 - SPECIFIC CYLINDERS

(D) 0 ? 1

NUMBER OF BEGIN/END SETS (D) 1 ?

BEGIN BLOCK (A) 0 ?

END BLOCK (A) 0 ? 200

NUMBER OF WORDS IN DATA PATTERN 16 (D) 1 ?

DATA WORD (D) 0 ?

Q



```

1      .NLIST BEX,CND
2      :++
3      :      REVISION HISTORY:
4      :      REV. A - JFM - 12-SEP-1984
5      :      THIS PROGRAM HAS BEEN ADAPTED FROM CZUDCO, REVISION E.
6      :--
7      :++
8      :      M A C R O   D E F I N I T I O N   S E C T I O N
9      :--
10     :
11     :++
12     :      PUSH - PUT DATA ON THE STACK
13     :
14     :      ARGUMENTS:
15     :      A - DATA TO BE PUT ON THE STACK
16     :--
17     :
18     .MACRO PUSH      A
19     .IRP      B,<A>
20     MOV      B,-(SP)      ; PUSH B ON STACK
21     .ENDM
22     .ENDM PUSH
23     :
24     :++
25     :      POP - REMOVE DATA FROM THE STACK
26     :
27     :      ARGUMENTS:
28     :      A - LOCATION TO PUT THE DATA REMOVED FROM THE STACK
29     :--
30     :
31     .MACRO POP      A
32     .IRP      B,<A>
33     MOV      (SP)+,B      ; POP STACK INTO B
34     .ENDM
35     .ENDM POP
36     :
37     :++
38     :      ASSUME - CHECK VALIDITY OF PROGRAM ASSUMPTIONS
39     :--
40     .MACRO ASSUME FIRST,CONDITION,SECOND
41     .IF CONDITION <FIRST>--<SECOND>
42     .IFF
43     .ERROR ;BAD ASSUME OF <FIRST> CONDITION <SECOND>
44     .ENDC
45     .ENDM ASSUME
46     :
47     :++
48     :      MACRO DEFINITIONS FOR GLOBAL EQUATES
49     :
50     :      THESE MACROS ARE USED TO DEFINE INDEXES INTO A TABLE
51     :
52     :      CALLING SEQUENCE MUST BE
53     :
54     :      TABLE
55     :      ITEM      NAME      BYTES      COMMENT
56     :      ITEM      NAME      BYTES      COMMENT
57     :      ITEM      NAME      BYTES      COMMENT

```

```

58      ;           END      SIZE
59      ;
60      ;           TABLE - DESIGNATES THAT A TABLE IS ABOUT TO BE DEFINED.
61      ;           END - TERMINATES THE DEFINITION.
62      ;           ITEM - ENTRY IN THE TABLE. ANY NUMBER OF ITEM LINES CAN APPEAR.
63      ;           NAME - THE NAME OF THE SYMBOL BEING EQUATED TO THE INDEX. THE INDEX
64      ;           ALWAYS STARTS AT ZERO.
65      ;           BYTES - THE SIZE OF THE VALUE TO BE STORED AT THAT INDEX IN BYTES.
66      ;           SIZE - (OPTIONAL) THE SIZE OF THE TABLE IN BYTES.
67      ;           TINDEX - KEEPS TRACK OF THE INDEX VALUE AND WILL BE EQUAL TO THE SIZE
68      ;           OF THE TABLE AFTER THE END STATEMENT.
69      ;--
70
71      .MACRO TABLE
72      TINDEX = 0
73      .ENDM TABLE
74
75      .MACRO ITEM NAME BYTES COMMENT
76      NAME=TINDEX ;COMMENT
77      TINDEX=TINDEX+BYTES
78      .ENDM ITEM
79
80      .MACRO END SIZE COMMENT
81      .IF NB SIZE
82      SIZE=TINDEX ;COMMENT
83      .ENDC
84      .ENDM END
85
86      ;**
87      ;           PRINT - PRINT CHARACTER
88      ;
89      ;           ARGUMENT MUST BE SOURCE STATEMENT TO MOVE CHARACTER TO PRINT (MOV ARG,RO)
90      ;           EX: "PRINT R1" WILL PRINT THE CHARACTER IN R1
91      ;           SPECIAL CASE: "PRINT #CR" WILL PRINT END OF LINE SEQUENCE
92      ;           THE PRINTING IS DONE AT THE MODE OF THE LAST PRINT LINE CALL
93      ;           IE., PNTF, PNTB, PNTX, PNTS
94      ;--
95
96      .MACRO PRINT ARG1
97      .IF DIF <ARG1>,RO
98      MOVB ARG1,RO ; STORE ARG1 IN RO AND
99      .ENDC
100     CALL PRINTC ; PRINT THE CHARACTER.
101     .ENDM PRINT
102
103     ;**
104     ;           PNT... - PROCESSING MACRO FOR NEXT SET OF FORMATTED MESSAGE MACROS
105     ;--
106
107     .MACRO PNT... RTN,ADR,ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
108     ARG.CT = 0
109     .IRP AA,<ARG8,ARG7,ARG6,ARG5,ARG4,ARG3,ARG2,ARG1>
110     .IF NB,<AA>
111     MOV AA,-(SP) ; PUSH AA ON STACK
112     ARG.CT = ARG.CT+2 ; INCREMENT ARGUMENT COUNT
113     .ENDC
114     .ENDM

```

```

115          JSR      R1,RTN          ; CALL RTN PRINT ROUTINE
116          .WORD   ADR              ; ADDRESS OF ASCIZ STRING
117          .WORD   ARG.CT          ; ARGUMENT COUNT * 2
118          .ENDM   PNT...
119
120          ;**
121          ;       PNTF, PNTB, PNTX, PNTS - PRINT FORMATTED MESSAGE MACROS
122          ;
123          ;       USE THESE MACROS TO PRINT A FORMATTED MESSAGE
124          ;       FIRST ARGUMENT MUST BE ADDRESS OF FIRST CHARACTER OF MESSAGE STRING
125          ;       TO BE PUT INTO WORD (.WORD ARG)
126          ;       UP TO 8 SOURCE STATEMENTS MAY FOLLOW TO SPECIFY PARAMETERS TO BE
127          ;       USED BY THE FORMAT
128          ;--
129
130          .MACRO   PNTF      ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
131          PNT... LPNTF ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
132          .ENDM   PNTF
133
134          .MACRO   PNTB      ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
135          PNT... LPNTB ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
136          .ENDM   PNTB
137
138          .MACRO   PNTX      ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
139          PNT... LPNTX ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
140          .ENDM   PNTX
141
142          .MACRO   PNTS      ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
143          PNT... LPNTS ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
144          .ENDM   PNTS
145
146          .MACRO   PNT       ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
147          PNT... LPNT ADR ARG1,ARG2,ARG3,ARG4,ARG5,ARG6,ARG7,ARG8
148          .ENDM   PNT
149
150          .SBTTL  PROGRAM HEADER
151
152          .MCALL  SVC
153          SVC              ; INITIALIZE SUPERVISOR MACROS
154
155          ;**
156          ;       IF STRUCTURED MACROS ARE TO BE USED, ".MCALL STRUCT" AND "STRUCT"
157          ;       MUST BE ADDED TO INITIALIZE THE STRUCTURED MACROS.
158
159          SVCINS= 0          ; LIST INSTRUCTIONS, SHIFTED RIGHT
160          SVCTST= 0         ; LIST TEST TAGS, SHIFTED RIGHT
161          SVCSUB= 0        ; LIST SUBTEST TAGS, SHIFTED RIGHT
162          SVCGBL= 0        ; LIST GLOBAL TAGS, SHIFTED RIGHT
163          SVCTAG= 0        ; LIST OTHER TAGS, SHIFTED RIGHT
164
165          ;       THE VALUES OF THE SVC... SYMBOLS ARE ZERO TO ALIGN THE MACRO CALLS
166          ;       AND THEIR EXPANSIONS.  SETTING THE SYMBOLS TO BE MINUS-ONE WILL CAUSE
167          ;       THE EXPANSIONS TO NOT BE LISTED.  THE SYMBOLS MAY BE CHANGED AT ANY
168          ;       POINT IN THE PROGRAM.
169          ;--
170
171          .ASECT

```

CZUDIA0 UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 87-3  
PROGRAM HEADER

```

172          .ENABL  AMA          2000
173          002000
174
175          : **
176          : THE PROGRAM HEADER IS THE INTERFACE BETWEEN
177          : THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
178          :
179          : THE FOLLOWING ARE THE OPTIONAL 'HEADER' ARGUMENTS:
180          :
181          : ARGUMENT          OPTION
182          : -----          -----
183          : BGNRPT            REPORT CODE
184          : BGNSW             SOFTWARE TABLE
185          : BGNSFT            SOFTWARE TABLE QUESTIONS
186          : BGNAU            ADD          CODE
187          : BGNDU            DROP CODE
188          : ERRRTL           ERROR TABLE
189          : BGNSETUP        ASSEMBLED P-TABLES
190          : --
191
192          002000          POINTER BGNRPT,BGNSW,BGNSFT,ERRRTL,BGNSETUP
193
194          : **
195          : THE "HEADER" ARGUMENTS ARE: NAME, REV, PATCH, LONGEST TEST
196          : TIME, TYPE, AND PRIORITY. "TYPE" = 0 FOR SEQUENTIAL DIAGNOSTIC AND = 1
197          : FOR EXERCISER. "PRIORITY" SPECIFIES THE PROCESSOR PRIORITY TO BE SET
198          : WHEN STARTING THE DIAGNOSTIC (DEFAULT IS 0).
199          : --
200
201          002000          HEADER CZUDI,A,0,0,1,PRI07 ; TEST 4
202          002000          L#NAME:: ;DIAGNOSTIC NAME
203          002000          103          .ASCII /C/
204          002001          132          .ASCII /Z/
205          002002          125          .ASCII /U/
206          002003          104          .ASCII /D/
207          002004          111          .ASCII /I/
208          002005          000          .BYTE 0
209          002006          000          .BYTE 0
210          002007          000          .BYTE 0
211          002010          L#REV:: ;REVISION LEVEL
212          002010          101          .ASCII /A/
213          002011          L#DEPO:: ;0
214          002011          060          .ASCII /0/
215          002012          L#UNIT:: ;NUMBER OF UNITS
216          002012          000001          .WORD T#PTHV
217          002014          L#TIML:: ;LONGEST TEST TIME
218          002014          000000          .WORD 0
219          002016          L#MPCP:: ;POINTER TO H.W. QUES.
220          002016          025714          .WORD L#HARD
221          002020          L#SPCP:: ;POINTER TO S.W. QUES.
222          002020          026050          .WORD L#SOFT
223          002022          L#HPTP:: ;PTR. TO DEF. H.W. PTABLE
224          002022          002130          .WORD L#HW
225          002024          L#SPTP:: ;PTR. TO S.W. PTABLE
226          002024          002140          .WORD L#SW
227          002026          L#LADP:: ;DIAG. END ADDRESS
228          002026          000044          .WORD L#LAST

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 87-4  
PROGRAM HEADER

002030		L\$STA::		;RESERVED FOR APT STATS
002030	000000		.WORD 0	
002032		L\$CO::		
002032	000000		.WORD 0	
002034		L\$DTYP::		;DIAGNOSTIC TYPE
002034	000001		.WORD 1	
002036		L\$APT::		;APT EXPANSION
002036	000000		.WORD 0	
002040		L\$DTP::		;PTR. TO DISPATCH TABLE
002040	002124		.WORD L\$DISPATCH	
002042		L\$PRIO::		;DIAGNOSTIC RUN PRIORITY
002042	000340		.WORD PRI07	
002044		L\$ENVI::		;FLAGS DESCRIBE HOW IT WAS SETUP
002044	000000		.WORD 0	
002046		L\$EXP1::		;EXPANSION WORD
002046	000000		.WORD 0	
002050		L\$MREV::		;SVC REV AND EDIT #
002050	003		.BYTE C\$REVISION	
002051	003		.BYTE C\$EDIT	
002052		L\$EF::		;DIAG. EVENT FLAGS
002052	000000		.WORD 0	
002054	000000		.WORD 0	
002056		L\$SPC::		
002056	000000		.WORD 0	
002060		L\$DEVP::		; POINTER TO DEVICE TYPE LIST
002060	002374		.WORD L\$DVTYP	
002062		L\$REPP::		;PTR. TO REPORT CODE
002062	016430		.WORD L\$RPT	
002064		L\$EXP4::		
002064	000000		.WORD 0	
002066		L\$EXP5::		
002066	000000		.WORD 0	
002070		L\$AUT::		;PTR. TO ADD UNIT CODE
002070	000000		.WORD 0	
002072		L\$DUT::		;PTR. TO DROP UNIT CODE
002072	000000		.WORD 0	
002074		L\$LUN::		;LUN FOR EXERCISERS TO FILL
002074	000000		.WORD 0	
002076		L\$DESP::		;POINTER TO DIAG. DESCRIPTION
002076	002420		.WORD L\$DESC	
002100		L\$LOAD::		;GENERATE SPECIAL AUTOLOAD EMT
002100	104035		EMT E\$LOAD	
002102		L\$ETP::		;POINTER TO ERR TBL
002102	002146		.WORD L\$ERR TBL	
002104		L\$ICP::		;PTR. TO INIT CODE
002104	017772		.WORD L\$INIT	
002106		L\$CCP::		;PTR. TO CLEAN-UP CODE
002106	021304		.WORD L\$CLEAN	
002110		L\$ACP::		;PTR. TO AUTO CODE
002110	021302		.WORD L\$AUTO	
002112		L\$PRT::		;PTR. TO PROTECT TABLE
002112	017764		.WORD L\$PROT	
002114		L\$TEST::		;TEST NUMBER
002114	000000		.WORD 0	
002116		L\$DLY::		;DELAY COUNT
002116	000000		.WORD 0	
002120		L\$HIME::		;PTR. TO HIGH MEM

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 87-5  
PROGRAM HEADER

203 002120 000000

.WORD 0

CZUDIAO UDASO-A/KDASO-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 88  
DISPATCH TABLE

1  
2  
3  
4  
5  
6  
7  
8  
9  
11 002122  
002122 000001  
002124  
002124 021326  
12

.SBTTL DISPATCH TABLE

```

: **
: THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
: IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST. THE
: ARGUMENT OF 'DISPATCH' INDICATES THE NUMBER OF HARDWARE TESTS
: IN THE DIAGNOSTIC.
: --

```

```

DISPATCH 1
.WORD 1
L#DISPATCH::
.WORD T1

```

CZUDIA0 UD450-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 89  
 DEFAULT HARDWARE P-TABLE

```

1      .SBTTL  DEFAULT HARDWARE P-TABLE
2
3      ;**
4      ;      THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
5      ;      THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
6      ;      IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES,
7      ;      AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.
8      ;      THE ACTUAL P-TABLE BUILT AT RUNTIME IS STORED IN SUPERVISOR
9      ;      SPACE.
10     ;--
11
12     002126      BGNHW  DFPTBL
13     002126      .WORD  L10000-L#HW/2
14     002130      L#HW::
15     002130      DFPTBL::
16     13 002130      .WORD  172150      ; CSR ADDRESS
17     18 002132      .WORD  0.          ; LOGICAL DRIVE NUMBER
18     20 002134      .WORD  0.          ; CUSTOMER DATA AREA
19
20
21
22
23     002136      ENDHW
24     002136      L10000:

```



CZUDIA0 UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 90  
SOFTWARE P-TABLE

```

1      .SBTTL  SOFTWARE P-TABLE
2
3      ;**
4      ;      THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
5      ;      PROGRAM AS OPERATIONAL PARAMETERS.  THESE PARAMETERS ARE
6      ;      SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
7      ;      AT RUN TIME.  THIS TABLE, UNLIKE THE HARDWARE TABLE, WILL CONTAIN
8      ;      THE ACTUAL VALUES ENTERED BY THE OPERATOR.
9      ;--
10
11     002136      BGNSW      SFPTBL
12     002136      .WORD      L10001-L$SW/2
13     002140      000003
14     002140      L$SW::
15     002140      SFPTBL::
16     002140      .WORD      32.
17     002142      000000      ;ERROR LIMIT
18     002144      040400      ;DATA TRANSFER LIMIT (MEGABITS)
19
20
21     002146      .WORD      0.
22     002146      .WORD      †8010000001000000000
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 91  
 GLOBAL EQUATES SECTION

1  
 2  
 3  
 4  
 5  
 6  
 7  
 8 002146

.SBTTL GLOBAL EQUATES SECTION

; \*\*  
 ; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT  
 ; ARE USED IN MORE THAN ONE TEST.  
 ; --

EQUALS

; BIT DIFINITIONS

100000	BIT15--	100000
040000	BIT14--	40000
020000	BIT13--	20000
010000	BIT12--	10000
004000	BIT11--	4000
002000	BIT10--	2000
001000	BIT09--	1000
000400	BIT08--	400
000200	BIT07--	200
000100	BIT06--	100
000040	BIT05--	40
000020	BIT04--	20
000010	BIT03--	10
000004	BIT02--	4
000002	BIT01--	2
000001	BIT00--	1
001000	BIT9--	BIT09
000400	BIT8--	BIT08
000200	BIT7--	BIT07
000100	BIT6--	BIT06
000040	BIT5--	BIT05
000020	BIT4--	BIT04
000010	BIT3--	BIT03
000004	BIT2--	BIT02
000002	BIT1--	BIT01
000001	BIT0--	BIT00

; EVENT FLAG DEFINITIONS

; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040	EF.START--	32.	; START COMMAND WAS ISSUED
000037	EF.RESTART--	31.	; RESTART COMMAND WAS ISSUED
000036	EF.CONTINUE--	30.	; CONTINUE COMMAND WAS ISSUED
000035	EF.NEW--	29.	; A NEW PASS HAS BEEN STARTED
000034	EF.PWR--	28.	; A POWER-FAIL/POWER-UP OCCURRED

; PRIORITY LEVEL DEFINITIONS

000340	PRI07--	340
000300	PRI06--	300
000240	PRI05--	240
000200	PRI04--	200
000140	PRI03--	140
000100	PRI02--	100

000040  
000000

PRI01== 40  
PRI00== 0

;  
;OPERATOR FLAG BITS

000004  
000010  
000020  
000040  
000100  
000200  
000400  
001000  
002000  
004000  
010000  
020000  
040000  
100000

;  
EVL== 4  
LOT== 10  
ADR== 20  
IDU== 40  
ISR== 100  
UAM== 200  
BOE== 400  
PNT== 1000  
PRI== 2000  
IXE== 4000  
IBE== 10000  
IER== 20000  
LOE== 40000  
MOE== 100000

```

1      .SBTTL  CONTROLLER BIT DEFINITIONS
2
3      ;
4      ;      SA REGISTER UNIVERSAL READ BITS
5      ;
6
7      100000  SA.ERR  = 100000      ; ERROR INDICATOR
8      040000  SA.S4   = 040000      ; STEP 4 STATUS BIT
9      020000  SA.S3   = 020000      ; STEP 3 STATUS BIT
10     010000  SA.S2   = 010000      ; STEP 2 STATUS BIT
11     004000  SA.S1   = 004000      ; STEP 1 STATUS BIT
12
13     ;
14     ;      SA REGISTER ERROR STATUS BITS
15     ;
16
17     003777  SA.ERC  = 003777      ; ERROR CODE
18
19     ;
20     ;      SA REGISTER STEP 1 SEND BITS
21     ;
22
23     000177  SA.VEC  = 000177      ; INTERRUPT VECTOR (DIVIDED BY 4)
24     000200  SA.INT  = 000200      ; INTERRUPT ENABLE DURING INIT
25     003400  SA.MSG  = 003400      ; MESSAGE RING LENGTH
26     034000  SA.CMD  = 034000      ; COMMAND RING LENGTH
27     040000  SA.WRP  = 040000      ; WRAP BIT
28     100000  SA.STP  = 100000      ; STEP - MUST ALWAYS BE WRITTEN A ONE
29
30     000400  SA.MS1  = 000400      ; LSB OF MESSAGE RING LENGTH
31     004000  SA.CH1  = 004000      ; LSB OF COMMAND RING LENGTH
32
33     ;
34     ;      SA REGISTER STEP 1 RESPONSE BITS
35     ;
36
37     002000  SA.NV   = 002000      ; NON SETTABLE INTERRUPT VECTOR
38     001000  SA.QB   = 001000      ; 22 BIT ADDRESS BUS
39     000400  SA.DI   = 000400      ; ENHANCED DIAGNOSTICS
40     000100  SA.MP   = 000100      ; MAPPING BIT
41     000040  SA.SM   = 000040      ; SPECIAL MODE BIT FOR KDA50-Q
42     ;          000377      ; THESE BITS RESERVED
43
44     ;
45     ;      SA REGISTER STEP 2 SEND BITS
46     ;
47
48     000001  SA.PRG  = 000001      ; ENABLE VAX UBA PURGE INTERRUPT
49     ;          177776      ; LOW ORDER MESSAGE RING BYTE ADDRESS
50
51     ;
52     ;      SA REGISTER STEP 2 RESPONSE BITS
53     ;
54
55     000007  SA.MSE  = 000007      ; MESSAGE RING LENGTH ECHO
56     000070  SA.CME  = 000070      ; COMMAND RING LENGTH ECHO
57     ;          000100      ; RESERVED

```

CZUDIA0 UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 92-1  
 CONTROLLER BIT DEFINITIONS

58	000200	SA.STE = 000200	; STEP ECHO
59	003400	SA.CTP = 003400	; CONTROLLER TYPE
60			
61		:	
62		SA REGISTER STEP 3 SEND BITS	
63		:	
64			
65		077777	; HIGH ORDER MESSAGE RING BYTE ADDRESS
69	000000	SA.TST = 000000	; PURGE/POLL TEST DISABLED
71		:	
72		SA REGISTER STEP 3 RESPONSE BITS	
73		:	
74			
75	000177	SA.VCE = 000177	; INTERRUPT VECTOR ECHO
76	000200	SA.INE = 000200	; INTERRUPT ENABLE ECHO
77	000400	SA.NVE = 000400	; VECTOR NOT PROGRAMMABLE
78		003000	; RESERVED
79		:	
80			
81		SA REGISTER STEP 4 SEND BITS	
82		:	
83			
84	000001	SA.GO = 000001	; GO BIT TO START CONTROLLER FIRMWARE
85	000002	SA.LFC = 000002	; LAST FAILURE CODE REQUEST
86	000374	SA.BST = 000374	; BURST LEVEL
87			
88		:	
89		SA REGISTER STEP 4 RESPONSE BITS	
90		:	
91			
92	000017	SA.MCV = 000017	; CONTROLLER MICROCODE VERSION
93	000360	SA.CNT = 000360	; CONTROLLER TYPE
94		003400	; RESERVED
95		:	

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 93  
 HOST COMMUNICATION AREA DEFINIIONS

```

1      .SBTTL  HOST COMMUNICATION AREA DEFINIIONS
2
3      :
4      :      COMMAND/MESSAGE RING BIT DEFINITIONS
5      :
6
7      100000  RG.OWN  = 100000      ; SET WHEN CONTROLLER OWNS RING
8      040000  RG.FLG  = 040000      ; FLAG BIT
9
10     :
11     :      VIRTUAL CIRCUIT IDENTIFIERS
12     :
13
14     000000  MSCP    = 0           ; MSCP CIRCUIT
15     000001  LOG     = 1           ; LOG CIRCUIT
16     177777  DIAG   = -1          ; DIAGNOSTIC CIRCUIT
17     001000  DUP     = 1000        ; DIAGNOSTIC AND UTILITIES PROTOCOL
18
19     :
20     :      OFFSETS INTO HOST COMMUNICATIONS AREA WITH ONE DESCRIPTOR TO EACH RING
21     :      AND TWO PACKETS
22     :
23     :      -----
24     HC.INT  )      INTERRUPT INDICATORS      )      4 BYTES
25     :      )
26     :      -----
27     HC.MSG  )      MESSAGE (RESPONSE) RING    )      4 BYTES
28     HC.MCT  )
29     :      -----
30     HC.CMD  )      COMMAND RING                )      4 BYTES
31     HC.CCT  )
32     :      -----
33     HC.MEV & HC.CEV)      MESSAGE & COMMAND ENVELOPE )      4 BYTES
34     :      )
35     HC.MPK & HC.CPK)      MESSAGE & COMMAND PACKET   )      48 BYTES
36     :      )
37     :      -----
38     HC.BF1  )      BUFFER # 1 (RESPONSE TO DM PROGRAM) )      70 BYTES
39     :      )
40     :      -----
41     HC.BF2  )      BUFFER # 2 (REQUEST FROM DM PROGRAM) )      70 BYTES
42     :      )
43     :      -----
44
45     :
46     :      NOTE: BYTES ARE GIVEN IN DECIMAL
47
48     000004  HC.ISZ  = 4.           ; SIZE OF INTERRUPT INDICATOR WORDS
49     000004  HC.RSZ  = 4.           ; SIZE OF RING IN BYTES
50     000004  HC.ESZ  = 4.           ; SIZE OF ENVELOPE WORDS BEFORE PACKET
51     000060  HC.PSZ  = 48.          ; SIZE OF COMMAND AND MESSAGE PACKETS
52     000106  HC.BSZ  = 70.          ; SIZE OF BUFFER
53
54     000000  HC.INT  = 0.           ; INTERRUPT INDICATOR WORDS START
55
56     000004  HC.MSG  = HC.INT+HC.ISZ ; MESSAGE RING START
57     000006  HC.MCT  = HC.MSG+2.    ; MESSAGE RING CONTROL WORD

```

CZUDIAO UDA50-A/KDA50-G DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 93-1  
HOST COMMUNICATION AREA DEFINIIONS

58				
59	000010	HC.CMD = HC.MSG+HC.RSZ		; COMMAND RING START
60	000012	HC.CCT = HC.CMD+2.		; COMMAND RING CONTROL WORDS
61				
62	000014	HC.MEV = HC.CMD+HC.RSZ		; MESSAGE ENVELOPE START
63	000020	HC.MPK = HC.MEV+HC.ESZ		; MESSAGE PACKET START
64				
65	000014	HC.CEV = HC.MEV		; COMMAND ENVELOPE START
66	000020	HC.CPK = HC.MPK		; COMMAND PACKET START
67				
68	000100	HC.BF1 = HC.CPK+HC.PSZ		; FIRST BUFFER
69	000206	HC.BF2 = HC.BF1+HC.BSZ		; SECOND BUFFER
70				
71	000314	HC.SIZ = HC.BF2+HC.ESZ		; TOTAL SIZE OF HOST COMMUNICATION AREA
72				

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 94  
 COMMAND PACKET OPCODES DEFINITIONS

```

1      .SBTTL  COMMAND PACKET OPCODES DEFINITIONS
2
3      ;**
4      ;
5      ;   NOTE: END PACKET OPCODES (ALSO CALLED ENDCODES) ARE FORMED BY ADDING
6      ;   THE END PACKET FLAG TO THE COMMAND OPCODE. FOR EXAMPLE, A READ
7      ;   COMMAND'S END PACKET CONTAINS THE VALUE OP.RD+OP.END IN ITS OPCODE
8      ;   FIELD. THE INVALID COMMAND END PACKET CONTAINS JUST THE END PACKET
9      ;   FLAG (I.E., OP.END) IN ITS OPCODE FIELD. THE SERIOUS EXCEPTION END
10     ;   PACKET CONTAINS THE SUM OF THE END PACKET FLAG PLUS THE SERIOUS
11     ;   EXCEPTION OPCODE SHOWN ABOVE (I.E., OP.SEX+OP.END) IN ITS OPCODE FIELD.
12     ;
13     ;   COMMAND OPCODE BITS 3 THROUGH 5 INDICATE THE COMMAND CLASS, WHICH IS
14     ;   ENCODED AS FOLLOWS:
15     ;   000 IMMEDIATE COMMANDS
16     ;   001 SEQUENTIAL COMMANDS
17     ;   010 NON-SEQUENTIAL COMMANDS THAT DO NOT INCLUDE A BUFFER DESCRIPTOR
18     ;   100 NON-SEQUENTIAL COMMANDS THAT DO INCLUDE A BUFFER DESCRIPTOR
19     ;--
20     000001  OP.ABO  = 1      ; ABORT COMMAND
21     000020  OP.ACC  = 20     ; ACCESS COMMAND
22     000010  OP.AVL  = 10     ; AVAILABLE COMMAND
23     000021  OP.CCD  = 21     ; COMPARE CONTROLLER DATA COMMAND
24     000040  OP.CMP  = 40     ; COMPARE HOST DATA COMMAND
25     000022  OP.ERS  = 22     ; ERASE COMMAND
26     000023  OP.FLU  = 23     ; FLUSH COMMAND
27     000002  OP.GCS  = 2      ; GET COMMAND STATUS COMMAND
28     000003  OP.GUS  = 3      ; GET UNIT STATUS COMMAND
29     000011  OP.ONL  = 11     ; ONLINE COMMAND
30     000041  OP.RD   = 41     ; READ COMMAND
31     000024  OP.RPL  = 24     ; REPLACE COMMAND
32     000004  OP.SCC  = 4      ; SET CONTROLLER CHARACTERISTICS COMMAND
33     000012  OP.SUC  = 12     ; SET UNIT CHARACTERISTICS COMMAND
34     000042  OP.WR   = 42     ; WRITE COMMAND
35     000030  OP.HRD  = 30     ; MAINTENANCE READ COMMAND
36     000031  OP.HWR  = 31     ; MAINTENANCE WRITE COMMAND
37     000200  OP.END  = 200    ; END PACKET FLAG
38     000007  OP.SEX  = 7      ; SERIOUS EXCEPTION END PACKET
39     000100  OP.AVA  = 100    ; AVAILABLE ATTENTION MESSAGE
40     000101  OP.DUP  = 101    ; DUPLICATE UNIT NUMBER ATTENTION MESSAGE
41     000102  OP.SMC  = 102    ; SHADOW COPY COMPLETE ATTENTION MESSAGE
42     000103  OP.RLC  = 103    ; RESET COMMAND LIMIT ATTENTION MESSAGE
43
44     000001  OP.GSS  = 1      ; DUP GET DUST STATUS
45     000002  OP.ESP  = 2      ; DUP EXECUTE SUPPLIED PROGRAM
46     000003  OP.ELP  = 3      ; DUP EXECUTE LOCAL PROGRAM
47     000004  OP.SSD  = 4      ; DUP SEND DUST DATA
48     000005  OP.RSD  = 5      ; DUP RECEIVE DUST DATA
49
50     ;
51     ;   COMMAND MODIFIERS
52     ;
53     ;
54     ;   = 020000      ; CLEAR SERIOUS EXCEPTION
55     040000  MD.CMP  = 040000 ; COMPARE
56     100000  MD.EXP  = 100000 ; EXPRESS REQUEST
57     010000  MD.ERR  = 010000 ; FORCE ERROR

```



CZUDIA0 UDA50-A/KDA50-G DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 94-1  
 COMMAND PACKET OPCODES DEFINITIONS

58	004000	MD.SCH = 004000	: SUPPRESS CACHING (HIGH SPEED)
59	002000	MD.SCL = 002000	: SUPPRESS CACHING (LOW SPEED)
60	000100	MD.SEC = 000100	: SUPPRESS ERROR CORRECTION
61	000400	MD.SER = 000400	: SUPPRESS ERROR RECOVERY
62	000200	MD.SSH = 000200	: SUPPRESS SHADOWING
63	000100	MD.WBN = 000100	: WRITE-BACK (NON-VOLATILE)
64	000400	MD.WBV = 000400	: WRITE BACK (VOLATILE)
65	000020	MD.SEG = 000020	: WRITE SHADOW SET ONE UNIT AT A TIME
66	000001	MD.SPD = 000001	: SPIN-DOWN
67	000001	MD.FEU = 000001	: FLUSH ENTIRE UNIT
68	000002	MD.VOL = 000002	: VOLATILE ONLY
69	000001	MD.NXU = 000001	: NEXT UNIT
70	000001	MD.RIP = 000001	: ALLOW SELF DESTRUCTION
71	000002	MD.IMF = 000002	: IGNORE MEDIA FORMAT ERROR
72	000004	MD.SWP = 000004	: SET WRITE PROTECT
73	000010	MD.CWB = 000010	: CLEAR WRITE-BACK DATA LOST
74	000001	MD.PRI = 000001	: PRIMARY REPLACEMENT BLOCK
75			
76		:	
77		: END PACKET FLAGS	
78		:	
79			
80	000200	EF.BBR = 000200	: BAD BLOCK REPORTED
81	000100	EF.BBU = 000100	: BAD BLOCK UNREPORTED
82	000040	EF.LOG = 000040	: ERROR LOG GENERATED
83	000020	EF.SEX = 000020	: SERIOUS EXCEPTION
84			
85		:	
86		: CONTROLLER FLAGS	
87		:	
88			
89	000200	CF.ATN = 000200	: ENABLE ATTENTION MESSAGES
90	000100	CF.MSC = 000100	: ENABLE MISCELLANEOUS ERROR LOG MESSAGES
91	000040	CF.OTH = 000040	: ENABLE OTHER HOST'S ERROR LOG MESSAGES
92	000020	CF.THS = 000020	: ENABLE THIS HOST'S ERROR LOG MESSAGES
93	000002	CF.SHD = 000002	: SHADOWING
94	000001	CF.576 = 000001	: 576 BYTE SECTORS
95			
96		:	
97		: UNIT FLAGS	
98		:	
99			
100	000001	UF.CMR = 000001	: COMPARE READS
101	000002	UF.CMW = 000002	: COMPARE WRITES
102	100000	UF.RPL = 100000	: HOST INITIATED BAD BLOCK REPLACEMENT
103	040000	UF.INA = 040000	: INACTIVE SHADOW SET UNIT
104	004000	UF.SCH = 004000	: SUPPRESS CACHING (HIGH SPEED)
105	002000	UF.SCL = 002000	: SUPPRESS CACHING (LOW SPEED)
106	000100	UF.WBN = 000100	: WRITE-BACK (NON-VOLATILE)
107	020000	UF.WPH = 020000	: WRITE PROTECT (HARDWARE)
108	001000	UF.WPS = 001000	: WRITE PROTECT (SOFTWARE OR VOLUME)
109	000004	UF.576 = 000004	: 576 BYTE SECTORS
110			

CZUDIAO UDA50-~~A~~/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 95  
 COMMAND PACKET OFFSETS

```

1      .SBTTL  COMMAND PACKET OFFSETS
2
3      ;
4      ;      GENERIC COMMAND PACKET OFFSETS
5      ;
6
7      000000      P.CRF      = 0.      ; COMMAND REFERENCE NUMBER
8      000004      P.UNIT     = 4.      ; UNIT NUMBER
9      000010      P.OPCD     = 8.      ; OPCODE
10     000012      P.MOD      = 10.     ; MODIFIERS
11     000014      P.BCNT     = 12.     ; BYTE COUNT
12     000020      P.BUFF     = 16.     ; BUFFER DESCRIPTOR
13     000020      P.UADR     = 16.     ; BUS ADDRESS OF BUFFER DESCRIPTOR
14     000034      P.LBN      = 28.     ; LOGICAL BLOCK NUMBER
15
16     ;
17     ;      ABORT AND GET COMMAND STATUS COMMAND PACKET OFFSETS
18     ;
19
20     000014      P.OTRF     = 12.     ; OUTSTANDING REFERENCE NUMBER
21
22     ;
23     ;      ONLINE AND SET UNIT CHARACTERISTICS COMMAND PACKET OFFSETS
24     ;
25
26     000016      P.UNFL     = 14.     ; UNIT FLAGS
27     000020      P.HSTI     = 16.     ; HOST IDENTIFIER / RESERVED
28     000034      P.ELGF     = 28.     ; ERROR LOG FLAGS
29     000040      P.SHUN     = 32.     ; SHADOW UNIT
30     000042      P.CPSP     = 34.     ; COPY SPEED
31
32     ;
33     ;      REPLACE COMMAND PACKET OFFSETS
34     ;
35
36     000014      P.RBN      = 12.     ; REPLACEMENT BLOCK NUMBER
37
38     ;
39     ;      SET CONTROLLER CHARACTERISTICS COMMAND PACKET OFFSETS
40     ;
41
42     000014      P.VRSN     = 12.     ; MSCP VERSION
43     000016      P.CNTF     = 14.     ; CONTROLLER FLAGS
44     000020      P.HTMO     = 16.     ; HOST TIMEOUT
45     000022      P.USEF     = 18.     ; USE FRACTION
46     000024      P.TIME     = 20.     ; QUAD-WORD TIME AND DATE
47
48     ;
49     ;      MAINTENANCE READ AND MAINTENANCE WRITE COMMAND PACKET OFFSETS
50     ;
51
52     000034      P.RGID     = 28.     ; REGION ID
53     000040      P.RGOF     = 32.     ; REGION OFFSET
54
55     ;
56     ;      EXECUTE SUPPLIED PROGRAM COMMAND PACKET OFFSETS
57     ;

```

CZUDIAO UDASO-A/KDASO-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 95-1  
COMMAND PACKET OFFSETS

58  
59  
60  
61

000024  
000034

P.DMDT = 20.  
P.OVRL = 28.

; DMDT TERMINAL ADDR. (MAINT WRITE ONLY)  
; BUFFER DESCRIPTOR FOR OVERLAYS

```

1          .SBTTL END PACKET OFFSETS
2
3          ;
4          ;      GENERIC END PACKET OFFSETS
5          ;
6
7          000000      P.CRF      = 0.          ; COMMAND REFERENCE NUMBER
8          000004      P.UNIT     = 4.          ; UNIT NUMBER
9          000010      P.OPCD     = 8.          ; OP CODE (ALSO CALLED ENDCODE)
10         000011      P.FLGS     = 9.          ; END PACKET FLAGS
11         000012      P.STS      = 10.         ; STATUS
12         000014      P.BCNT     = 12.         ; BYTE COUNT
13         000034      P.FBBK     = 28.         ; FIRST BAD BLOCK
14
15         ;
16         ;      GET COMMAND STATUS END PACKET OFFSETS
17         ;
18
19         000014      P.OTRF     = 12.         ; OUTSTANDING REFERENCE NUMBER
20         000020      P.CMST     = 16.         ; COMMAND STATUS
21
22         ;
23         ;      GET UNIT STATUS END PACKET OFFSETS
24         ;
25
26         000014      P.MLUN     = 12.         ; MULTI-UNIT CODE
27         000016      P.UNFL     = 14.         ; UNIT FLAGS
28         000020      P.HSTI     = 16.         ; HOST IDENTIFIER
29         000024      P.UNTI     = 20.         ; UNIT IDENTIFIER
30         000034      P.MEDI     = 28.         ; MEDIA TYPE IDENTIFIER
31         000040      P.SHUN     = 32.         ; SHADOW UNIT
32         000042      P.SHST     = 34.         ; SHADOW STATUS
33         000044      P.TRKS     = 36.         ; TRACK SIZE
34         000046      P.GRPS     = 38.         ; GROUP SIZE
35         000050      P.CYLS     = 40.         ; CYLINDER SIZE
36         000054      P.RCTS     = 44.         ; RCT TABLE SIZE
37         000056      P.RBNS     = 46.         ; RBNS / TRACK
38         000057      P.RCTC     = 47.         ; RCT COPIES
39
40         ;
41         ;      ONLINE AND SET UNIT CHARACTERISTICS END PACKET AND AVAILABLE
42         ;      ATTENTION MESSAGE OFFSETS
43         ;
44
45         000014      P.MLUN     = 12.         ; MULTI-UNIT CODE
46         000016      P.UNFL     = 14.         ; UNIT FLAGS
47         000020      P.HSTI     = 16.         ; HOST IDENTIFIER
48         000024      P.UNTI     = 20.         ; UNIT IDENTIFIER
49         000034      P.MEDI     = 28.         ; MEDIA TYPE IDENTIFIER
50         000040      P.SHUN     = 32.         ; SHADOW UNIT
51         000042      P.SHST     = 34.         ; SHADOW STATUS
52         000044      P.UNSZ     = 36.         ; UNIT SIZE
53         000050      P.VSER     = 40.         ; VOLUME SERIAL NUMBER
54
55         ;
56         ;      SET CONTROLLER CHARACTERISTICS END PACKET OFFSETS
57         ;

```

CZUDIA0 UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 96-1  
 END PACKET OFFSETS

58				
59	000014	P.VRSN = 12.		; MSCP VERSION
60	000016	P.CNTF = 14.		; CONTROLLER FLAGS
61	000020	P.CTMO = 16.		; CONTROLLER TIMEOUT
62	000022	P.CSVR = 18.		; CONTROLLER SOFTWARE VERSION
63	000023	P.CHVR = 19.		; CONTROLLER HARDWARE VERSION
64	000024	P.CNTI = 20.		; CONTROLLER ID
65				
66		:		
67		:	GET DUST STATUS END PACKET OFFSETS	
68		:		
69				
70	000014	P.DEXT = 12.		; EXTENSION - DOWNLINE LOADABLE PROGRAM
71	000017	P.DFLG = 15.		; FLAGS
72	000020	P.DPRG = 16.		; PROGRESS INDICATOR FOR REMOTE PROGRAM
73	000024	P.DTMO = 20.		; TIMEOUT
74				
75		:		
76		:	STATUS AND EVENT CODE DEFINITIONS	
77		:		
78				
79	000037	ST.MSK = 37		; STATUS / EVENT CODE MASK
80	000040	ST.SUB = 40		; SUB-CODE MULTIPLIER
81	000000	ST.SUC = 0		; SUCCESS
82	000001	ST.CMD = 1		; INVALID COMMAND
83	000002	ST.ABO = 2		; COMMAND ABORTED
84	000003	ST.OFL = 3		; UNIT-OFFLINE
85	000004	ST.AVL = 4		; UNIT-AVAILABLE
86	000005	ST.MFE = 5		; MEDIA FORMAT ERROR
87	000006	ST.WPR = 6		; WRITE PROTECTED
88	000007	ST.CMP = 7		; COMPARE ERROR
89	000010	ST.DAT = 10		; DATA ERROR
90	000011	ST.HST = 11		; HOST BUFFER ACCESS ERROR
91	000012	ST.CNT = 12		; CONTROLLER ERROR
92	000013	ST.DRV = 13		; DRIVE ERROR
93	000037	ST.DIA = 37		; MESSAGE FROM AN INTERNAL DIAGNOSTIC
94	000400	ST.AOL = 400		; ALREADY ON-LINE
95				
96		:		
97		:	DUP MESSAGE TYPES	
98		:		
99				
100	010000	DU.QUE = 10000		; QUESTION
101	020000	DU.DFL = 20000		; DEFAULT QUESTION
102	030000	DU.INF = 30000		; INFORMATION
103	040000	DU.TER = 40000		; TERMINATOR
104	050000	DU.FTL = 50000		; FATAL ERROR
105	060000	DU.SPC = 60000		; SPECIAL
106				

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 97  
CONTROLLER TABLE DEFINITIONS

```

1      .SBTTL  CONTROLLER TABLE DEFINITIONS
2
3      ;**
4      ;      CONTROLLER TABLE DEFINITIONS
5      ;
6      ;      ONE TABLE WILL BE SET UP BY INITIALIZATION SECTION FOR EACH CONTROLLER
7      ;      SELECTED FOR TESTING.  TABLES ARE CONTIGUOUS.  THE END OF THE TABLES IS
8      ;      MARKED BY A WORD OF ZEROS.
9      ;
10     ;      THE FIRST TABLE IS POINTED TO BY THE CONTENTS OF CTABS.
11     ;      THE NUMBER OF TABLES IS CONTAINED IN CTRLRS.
12     ;--
13
14     000077      CT.UNT  = 000077      ; LOGICAL UNIT NUMBER MASK
15     000777      CT.VEC  = 000777      ; VECTOR ADDRESS MASK
16     007000      CT.BRL  = 007000      ; BR LEVEL MASK
17
18     100000      CT.AVL  = BIT15      ; SET WHEN NOT AVAILABLE FOR TESTING
19     000100      CT.VER  = BIT6      ; CONTROLLER MICRO VERSION NUMBER WAS
20                                     ; PRINTED IF SET
21     000020      CT.REQ  = BIT4      ; BUFFER HAS BEEN GIVEN TO CONTROLLER
22                                     ; FOR REQUEST.  SET WHENEVER READ
23                                     ; DUST DATA COMMAND ISSUED.
24     000010      CT.MSG  = BIT3      ; MESSAGE RESPONSE RECEIVED.  WHENEVER
25                                     ; SET, CT.CMD IS CLEARED.
26     000004      CT.CMD  = BIT2      ; COMMAND ISSUED, WAITING FOR RESPONSE
27     000002      CT.RN   = BIT1      ; DM PROGRAM RUNNING
28
29     002146      TABLE      ; START A TABLE DEFINITION
30     002146      ITEM C.UADR  2      <BUS ADDRESS OF IP REGISTER>
31     002146      ITEM C.UNIT  2      <UNIT NUMBER TO TEST>
32     002146      ITEM C.VEC   2      <VECTOR ADDRESS/BR LEVEL>
33     002146      ITEM C.JSR   2      <INTERRUPT SERVICE ROUTINE FOR CONTROLLER>
34     002146      ITEM C.JAD   2      <THESE TWO WORDS LOADED WITH [JSR PO  CNTSRV]>
35     002146      ITEM C.FLG   2      <FLAGS>
36     002146      ITEM C.MCOM  2      <BEGINNING ADRS OF HOST COMM AREA IN MEMORY>
37     002146      ITEM C.DRO   2      <POINTER TO DRIVE TABLES>
38     002146      ITEM C.DR1   2      <IF ZERO, NO DRIVE TABLE EXISTS>
39     002146      ITEM C.DR2   2
40     002146      ITEM C.DR3   2
41     002146      ITEM C.TO    2      <TIMEOUT COUNTER>
42     002146      ITEM C.TOH   2      <( TWO WORDS)>
43     002146      ITEM C.REF   2      <COMMAND REFERENCE NUMBER>
44
45     002146      END C.SIZE  <SIZE OF CONTROLLER TABLE IN BYTES>
46

```

```

1      .SBTTL  DRIVE TABLE DEFINITIONS
2
3      ;**
4      ;      DRIVE TABLE DEFINITIONS
5      ;
6      ;      ONE DRIVE TABLE WILL BE SET UP BY THE INITIALIZE SECTION FOR EACH
7      ;      DRIVE SELECTED FOR TESTING.  EACH TABLE IS POINTED TO BY A
8      ;      WORD IN THE CONTROLLER TABLE ON WHICH THE DRIVE EXISTS.
9      ;
10     ;      THE FIRST TABLE IS POINTED TO BY THE CONTENTS OF DTABS.
11     ;--
12
13     000077      DT.UNT  = 000077      ; LOGICAL UNIT NUMBER OF DRIVE
14
15     100000      DT.AVL  = BIT15      ; SET WHEN NOT AVAILABLE FOR TESTING
16     040000      D.IW   = BIT14      ; INITIAL WRITE
17     020000      D.DCY  = BIT13      ; DIAGNOSTIC CYLINDERS
18     010000      D.ECC  = BIT12      ; ECC CORRECTION ENABLED
19     004000      D.RO   = BIT11      ; READ ONLY
20     002000      D.WO   = BIT10      ; WRITE ONLY
21     001000      D.RET  = BIT9       ; RETRIES ENABLED
22     000400      D.CYL  = BIT8       ; START/END CYLINDERS SPECIFIED
23     000100      D.SEQ  = BIT6       ; SEQUENTIAL ACCESS
24     000040      D.BE   = BIT5       ; BEGIN/END BLOCKS USED
25     000020      D.TR   = BIT4       ; WHEN D.BE=0: 1 - TRACKS, 0 - GROUPS
26     000010      D.WC   = BIT3       ; WRITE CHECKS ENABLED
27     000004      D.WCA  = BIT2       ; ALWAYS WRITE CHECK
28     000002      D.DC   = BIT1       ; DATA COMPARES ENABLED
29     000001      D.DCA  = BIT0       ; ALWAYS DATA COMPARE
30     011012      DDEF   = D.ECC+D.WC+D.DC+D.RET ; DEFAULT D.PRM
31     140200      D.ZERO  = BIT15+BIT7+D.IW ; BITS TO BE CLEARED
32
33     002146      TABLE ; START A TABLE DEFINITION
34     002146      ITEM D.DRV      2      <DRIVE NUMBER>
35     002146      ITEM D.UNIT     2      <LOGICAL UNIT NUMBER>
36     002146      ITEM D.PRM      2      <SOFTWARE QUESTION FLAGS>
37     002146      ITEM D.PAT      2      <DATA PATTERN NUMBER>
38     002146      ITEM D.BB       2      <BAD BLOCK COUNT>
39     002146      ITEM D.BB01     4      <BAD BLOCK 1>
40     002146      ITEM D.BB02     4      <      2>
41     002146      ITEM D.BB03     4      <      3>
42     002146      ITEM D.BB04     4      <      4>
43     002146      ITEM D.BB05     4      <      5>
44     002146      ITEM D.BB06     4      <      6>
45     002146      ITEM D.BB07     4      <      7>
46     002146      ITEM D.BB08     4      <      8>
47     002146      ITEM D.BB09     4      <      9>
48     002146      ITEM D.BB10     4      <     10>
49     002146      ITEM D.BB11     4      <     11>
50     002146      ITEM D.BB12     4      <     12>
51     002146      ITEM D.BB13     4      <     13>
52     002146      ITEM D.BB14     4      <     14>
53     002146      ITEM D.BB15     4      <     15>
54     002146      ITEM D.BB16     4      <     16>
55     002146      ITEM D.BEC      2      <BEGIN/END SET COUNT>
56     002146      ITEM D.BGN1     4      <BEGIN BLOCK 1>
57     002146      ITEM D.END1     4      <END>
58     002146
    
```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 98-1  
 DRIVE TABLE DEFINITIONS

59	002146	ITEM D.BGN2	4	<BEGIN BLOCK 2>
60	002146	ITEM D.END2	4	<END>
61	002146	ITEM D.BGN3	4	<BEGIN BLOCK 3>
62	002146	ITEM D.END3	4	<END>
63	002146	ITEM D.BGN4	4	<BEGIN BLOCK 4>
64	002146	ITEM D.END4	4	<END>
65	002146	ITEM D.BCYL	4	<BEGIN CYLINDER>
66	002146	ITEM D.ECYL	4	<END CYLINDER>
67	002146	ITEM D.XFRW	2	<MEGABITS WRITTEN COUNT>
68	002146	ITEM D.XFRR	2	<MEGABITS READ COUNT>
69	002146	ITEM D.HERR	2	<HARD ERROR COUNTER>
70	002146	ITEM D.SERR	2	<SOFT ERROR COUNTER>
71	002146	ITEM D.SEEK	2	<NUMBER OF SEEKS X1000>
72	002146	ITEM D.ECC	2	<ECC COUNTER>
73	002146	ITEM D.SERN	6	<DRIVE SERIAL NUMBER>
74	002146	ITEM D.SKER	2	<SEEK ERROR COUNT>
75	002146	ITEM D.HDAS	8.	<HDA SERIAL NUMBER>
77				
78	002146	END D.SIZE		<SIZE OF DRIVE TABLE IN BYTES>
79				

80		:		
81		:	DM PROGRAM HEADER DEFINITIONS	
82		:		
83		:		
84	000000	DMTRLN	= 0	; OFFSET TO DOWNLINE LOAD PROGRAM SIZE
85	000004	DMOVRL	= 4	; OFFSET TO SIZE OF OVERLAY
86	000040	DMMAIN	= 40	; OFFSET TO FIRST WORD OF MAIN PROGRAM
87	001000	DMFRST	= 1000	; ADDRESS START OF HEADER IN DM FILE
88				



```

1          .SBTTL GLOBAL DATA SECTION
2
3          ;**
4          ; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
5          ; IN MORE THAN ONE TEST.
6          ;--
7
8          ERRTABL
9          L#ERRTABL::
10         ERRTABL:: .WORD 0
11         ERRNBR:: .WORD 0
12         ERRMSG:: .WORD 0
13         ERRTBL:: .WORD 0
14
15         FFREE:: .BLKW 1 ; FIRST FREE WORD IN MEMORY
16         FSIZE:: .BLKW 1 ; SIZE OF FREE MEMORY IN WORDS
17         FMEM: .BLKW 1 ; COPY OF FFREE AT END OF INIT SECTION
18         FMEMS: .BLKW 1 ; COPY OF FSIZE AT END OF INIT SECTION
19         DTABS:: .BLKW 1 ; START OF DRIVE TABLE STORAGE
20         CTABS:: .BLKW 1 ; START OF CONTROLLER TABLE STORAGE
21         CTRLRS: .BLKW 1 ; COUNT OF CONTROLLERS IN PTABLES
22         TSTTAB: .BLKW 1 ; POINTER TO 1ST CONTROLLER TABLE
23         DMPROG: .BLKW 1 ; START ADDRESS OF DM PROGRAM
24
25         IFLAGS:: .BLKW 1 ; FLAGS FROM INIT CODE
26
27         ICONT == BIT1 ; CONTINUE EVENT FLAG
28         IREST == BIT2 ; RESTART FLAG
29         ISTRT == BIT3 ; START FLAG
30         ISTRTH == BIT4 ; START FLAG HOLD FOR DMRQ4 ROUTINE
31
32         TNUM: .WORD 0 ; NUMBER OF TEST EXECUTING
33         URUN: .BLKW 1 ; NUMBER OF UNITS TO RUN AT ONE TIME
34         URNING: .BLKW 1 ; NUMBER OF UNITS STILL RUNNING
35         UCNT: .BLKW 1 ; COUNTER OF UNITS UNDER TEST
36         INTRCV: .BLKW 1 ; INTERRUPT RECEIVED FLAG
37
38         TEMP: .BLKW 12. ; TEMPORARY STORAGE FOR GMANI RESPONSES
39
40         IPADRS: .WORD 0 ; 4 ENTRIES
41         .WORD 0 ; FOR CONTROLLER
42         .WORD 0 ; CSR
43         .WORD 0 ; ADDRESSES
44
45         BRSAV: .BLKW 1 ; STORE COMPUTED BR LEVEL AND VECTOR
46         PAT16C: .WORD 1 ; COUNT OF WORDS IN DATA PATTERN 16
47         PAT16W: .WORD 0 ; WORD SEQUENCE FOR DATA PATTERN 16
48         .WORD 0
49         .WORD 0
50         .WORD 0
51         .WORD 0
52         .WORD 0
53         .WORD 0

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 99-1  
GLOBAL DATA SECTION

```

54 002306 000000          .WORD 0
55 002310 000000          .WORD 0
56 002312 000000          .WORD 0
57 002314 000000          .WORD 0
58 002316 000000          .WORD 0
60
61      ;
62      ;      KW11 CLOCK CONTROL
63      ;
64
65 002320 000000  KW.CSR: .WORD 0      ; CSR OF CLOCK
66 002322          KW.BRL: .BLKW 1      ; BR LEVEL
67 002324          KW.VEC: .BLKW 1      ; VECTOR
68 002326          KW.HZ:  .BLKW 1      ; HERTZ (50. OR 60.)
69 002330          KW.EL:  .BLKW 2      ; ELAPSED TIME
70 002334          STIME:  .BLKW 2      ; STATISTICAL REPORT TIMER
71
72 002340          NXMAD:  .BLKW 1      ; SET TO -1 BY NON-EXISTANT ADDRESS
73
74
75
76
77
78
79
80 002342 007452  PTYPE:  .WORD  PF      ; PRINT TYPE
81 002344          TTYOUT: .BYTE  0      ; TTY OUTPUT BUFFER
82 002345          .BYTE  0      ; TERMINATOR FOR ASCIZ STRING
83          .EVEN
84
85      ;
86      ;      DATA TO BE SENT AND RECEIVED BY CONTROLLER INITIALIZATION
87      ;
88
89 002346 015710  INITBL:  .WORD  RSP.S1      ; 1ST WORD RESPONSE CHECK ROUTINE
90 002350 000000  SND.S1:  .WORD  0      ; 1ST WORD TO SEND TO SA REGISTER
91 002352 015722          .WORD  RSP.S2      ; 2ND WORD RESPONSE CHECK ROUTINE
92 002354 000000  SND.S2:  .WORD  0      ; 2ND WORD TO SEND TO SA REGISTER
93 002356 015742          .WORD  RSP.S3      ; 3RD WORD RESPONSE CHECK ROUTINE
94 002360 000000  SND.S3:  .WORD  0      ; 3RD WORD TO SEND TO SA REGISTER
95          ;;          .WORD  RSP.S4      ; 4TH WORD RESPONSE CHECK ROUTINE
96
97 002362 000000  SSTEP4:  .WORD  0      ; LOCATION TO SAVE STEP 4 VALUE
98 002364 000000  CNTRSD:  .WORD  0      ; LOCATION FOR STEP BIT MASK
99
100
101
102
103
104
105
106
107
108
109      ;
110      ;      ERROR LOG CONTROL WORDS
111      ;
112
113 002366          LBUFS:  .BLKW 1      ; START ADDRESS OF LOG/ZERO IF NONE
114 002370          LBUFN:  .BLKW 1      ; ADDRESS FOR MORE DATA FOR LOG
115 002372          LBUFE:  .BLKW 1      ; LAST ADDRESS AVAILABLE FOR LOG DATA
116          001060  LBSIZ  =          560. ; LENGTH IN WORDS OF ERROR LOG

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 100  
GLOBAL TEXT SECTION

```

1      .SBTTL GLOBAL TEXT SECTION
2
3      ;**
4      ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
5      ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
6      ; MORE THAN ONE TEST.
7      ;--
8
9      ;
10     ; NAMES OF DEVICES SUPPORTED BY PROGRAM
11     ;
12
13     002374      DEVTYP <LOGICAL DISK DRIVE>
14     002374      L#DVTYP::
15     002374      114      117      107 .ASCIZ /LOGICAL DISK DRIVE/
16                                     .EVEN
17
18     ;
19     ; TEST DESCRIPTION
20     ;
21     002420      DESCRIPT <CZUDIAO UDA50A,KDA50-Q DRIVE EXER>
22     002420      L#DESC::
23     002420      103      132      125 .ASCIZ /CZUDIAO UDA50A,KDA50-Q DRIVE EXER/
24                                     .EVEN
25
26     ;
27     ; UNFORMATTED MESSAGES
28     ;
29     002462      040      040      000 T4OPT7: .ASCIZ \ \
30     002465      101      122      105 INITWC: .ASCIZ \ARE YOU SURE CUSTOMER DATA CAN BE DESTROYED\
31
32     ;
33     ; FORMAT STATEMENTS USED IN PRINT CALLS
34     ;
35     002541      045      124      000 FRMTT: .ASCIZ \#T\
36     002544      045      116      000 CRLF: .ASCIZ \#N\
37     002547      042      040      040 RNTIM: .ASCIZ \ " RUNTIME "D16": "\
38     002572      104      071      042 RNTIM1: .ASCIZ \D9": "\
39     002600      104      071      000 RNTIM2: .ASCIZ \D9\
40     002603      042      040      040 ERRME1: .ASCIZ \ " * * * ERROR PROCESSING MESSAGE STRING * * * "N\
41     002672      116      042      122 MXFERP: .ASCIZ \N"REACHED TRANSFER LIMIT - TESTING STOPPED"N\
42     002747      116      042      125 ERRLIM: .ASCIZ \N"UNIT "D6" REACHED ERROR LIMIT - UNIT DROPPED FROM TEST"N\
43     003042      116      042      103 LOGM1: .ASCIZ \N"CONTENTS OF ERROR LOG:"\
44     003074      116      042      105 LOGM2: .ASCIZ \N"END OF ERROR LOG"N\
45     003121      116      042      105 LOGM3: .ASCIZ \N"ERROR LOG IS EMPTY"N\
46     003150      116      042      115 T4WARN: .ASCIZ \N"MANUAL INTERVENTION NOT ALLOWED. USING DEFAULT PARAMETERS"N\
47     003246      116      042      103 INITWA: .ASCIZ \N"CUSTOMER DATA WILL BE DESTROYED ON: "N55"UNIT"S3"CONTROLLER"S3"DRIVE"N\
48     003356      045      123      066 INITWB: .ASCIZ \#S6#D2#S6#06#S6#D3#N\
49     003403      116      042      125 MESSG: .ASCIZ \N"UNIT "D6" CONTROLLER AT "016" DRIVE "D9S\
50     003456      042      116      117 NOCLOCK: .ASCIZ \ "NO LINE CLOCK AVAILABLE FOR TIMING EVENTS"N\
51
52     ;
53     ;
54     003533      042      110      117 BASNO: .ASCIZ \ "HOST PROGRAM"\
55     003552      042      104      111 BASN4: .ASCIZ \ "DISK EXERCISER"\
56     003573      042      040      040 BASL1: .ASCIZ \ " DM PC: "012\

```

## GLOBAL TEXT SECTION

```

79 003611      042      040      040  BASL2: .ASCIZ \" CONTROLLER AT \"016\
80 003637      042      040      040  BASL3: .ASCIZ \" DRIVE \"D9\
81 003654      000
82
83 003655      122      066      122  BASLN: .ASCIZ \R6R6R6R6\           ; FORMAT FOR BASIC LINE OF ERROR MESSAGE
84
85 003666
86 003666
87 003666
88 003666      042      111      116  X1A:
89 003666
90 003666
91 003666
92 003751      122      065      122  X2A:
93 004020      122      065      122  X3A:
94 004106      122      064      042  X8A: .ASCIZ \"INVALID ANSWERS GIVEN TO THE HARDWARE QUESTIONS\"N\
95 004167      042      122      105  X2: .ASCIZ \R5R6\"TWO UNITS SELECT THE SAME DRIVE\"N\
96 004251      122      064      042  X3: .ASCIZ \R5R6\"MORE THAN 4 DRIVES SELECTED ON THIS CONTROLLER\"N\
100 004336     122      065      042  X4: .ASCII \R4\"NOT ENOUGH MEMORY TO TEST THE UNITS SELECTED\"N\
101 004432     042      124      110  X6: .ASCIZ \"RESTART PROGRAM AND TEST FEWER UNITS AT A TIME\"N\
102 004526     042      040      101  X14: .ASCIZ \R4\"TABLE CONSISTANCY ERROR. PLEASE RE-LOAD PROGRAM\"N\
103 004546     042      117      122  X14: .ASCII \R5\"CONTROLLER IS NOT SUPPORTED BY THIS DIAGNOSTIC PROGRAM.\"N\
104 004636     116      042      103  X14: .ASCII \"THIS PROGRAM REQUIRES A UDA50A (MODEL 6, MICROCODE VERSION\"N\
127 004737     122      065      042  X14: .ASCII \" AT LEAST 3),\"N\
128 005027     042      101      123  X14: .ASCII \"OR A KDA50-Q (MODEL 13, MICROCODE VERSION AT LEAST 0)\"N\
129 005061     122      065      042  X31: .ASCIZ \N\"CONTROLLER REPORTED MODEL CODE \"D4\" AND MICROCODE VERSION \"D4N\
130 005172     122      065      042  X31: .ASCII \R5\"NO INTERRUPT RECEIVED FROM DM PROGRAM FOR 3 MINUTES\"N\
131 005252     122      065      042  X31: .ASCIZ \"ASSUME PROGRAM IS HUNG\"N\
132 005343     042      127      110  X32: .ASCIZ \R5\"MESSAGE BUFFER RECEIVED FROM DM PROGRAM WITH UNKNOWN REQUEST NUMBER\"N\
133 005377     122      065      042  X35: .ASCIZ \R5\"DM PROGRAM ASKED FOR DATA ON UNKNOWN DRIVE\"N\
134 005464     042      103      110  X36: .ASCII \R5\"NO INTERRUPT RECEIVED FROM CONTROLLER FOR 30 SECONDS\"N\
135 005562     042      117      122  X36: .ASCIZ \"WHILE LOADING DM PROGRAM\"N\
136 005573     042      117      122  X38: .ASCII \R5\"MEMORY ERROR TRYING TO READ CONTROLLER REGISTERS\"N\
143 005603     122      065      042  X38: .ASCII \"CHECK BUS SELECTION SWITCHES ON CONTROLLER PROCESSOR MODULE\"N\
144 005640     042      125      123  X38: .ASCII \"OR BUS\"N\
146 005725     122      065      042  X40: .ASCIZ \"OR \"R7\
147 005777     042      115      105  X40: .ASCII \R5\"FATAL CONTROLLER ERROR\"NR8\
148 006033     123      063      117  XFCE: .ASCIZ \R5\"FATAL ERROR REPORTED BY CONTROLLER\"NR8\
149 006100     122      065      042  XMSG1: .ASCIZ \"MESSAGE BUFFER CONTAINS:\"N\
150 006203     042      105      111  XMSG2: .ASCIZ \S3016S1016S1016S1016S1016S1016S1016S1016S1016S1016N\
151 006320     123      063      042  XPKT1: .ASCII \R5\"RESPONSE PACKET FROM CONTROLLER DOES NOT CONTAIN EXPECTED DATA\"N\
152 006405     123      066      117  XPKT1: .ASCIZ \"EITHER CONTROLLER RETURNED ERROR STATUS OR PACKET WAS RECEIVED INCORRECTLY\"
153 006434     042      123      101  XPKT2: .ASCIZ \S3\"COMMAND PACKET SENT\"S6\"RESPONSE PACKET RECEIVED\"N\
154 006471     042      122      105  XSA: .ASCIZ \S6016S1016S14016S1016N\
156
157
XFRU: .ASCIZ \"SA REGISTER CONTAINS: \"016N\
      .ASCIZ \"REPLACE CONTROLLER PROCESSOR MODULE\"N\
      .EVEN

```

```

1          .SBTTL GLOBAL ERROR REPORT SECTION
2
3          ;**
4          ; THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS USED
5          ; BY MORE THAN ONE TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PNTB
6          ; (BASIC) AND PNTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
7          ;--
8
14
15 006540 BGNMSG ERR002
16 006540 ERR002::
17 006540 PNTB X2,@X2A
18 006554 ENDMSG
19 006554 L10002:
20 006554 TRAP C#MSG
21 104423
22
23 006556 BGNMSG ERR003
24 006556 ERR003::
25 006556 PNTB X3,@X3A
26 006572 ENDMSG
27 006572 L10003:
28 006572 TRAP C#MSG
29 104423
30
31 006574 BGNMSG ERR004
32 006574 ERR004::
33 006574 PNTB X4
34 006604 ENDMSG
35 006604 L10004:
36 006604 TRAP C#MSG
37 104423
38
39 006606 BGNMSG ERR006
40 006606 ERR006::
41 006606 PNTB X6
42 006616 ENDMSG
43 006616 L10005:
44 006616 TRAP C#MSG
45 104423
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100 006620 BGNMSG ERR014
101 006620 ERR014::
102 006620 PNTB X14,R3,R1
103 006634 ENDMSG
104 006634 L10006:
105 006634 TRAP C#MSG
106 104423
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363
2364
2365
2366
2367
2368
2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396
2397
2398
2399
2400
2401
2402
2403
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446
2447
2448
2449
2450
2451
2452
2453
2454
2455
2456
2457
2458
2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500
2501
2502
2503
2504
2505
2506
2507
2508
2509
2510
2511
2512
2513
2514
2515
2516
2517
2518
2519
2520
2521
2522
2523
2524
2525
2526
2527
2528
2529
2530
2531
2532
2533
2534
2535
2536
2537
2538
2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
25
```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 101-1  
 GLOBAL ERROR REPORT SECTION

	006652			L10010:		
	006662	104423		TRAP	C#MSG	
107						
108	006664			BGNMSG ERRO32		
	006664			ERRO32::		
109	006664			PNTB	X32	
110	006674	004737	007060	CALL	MSGPKT	
111	006700			ENDMSG		
	006700			L10011:		
	006700	104423		TRAP	C#MSG	
112						
113	006702			BGNMSG ERRO33		
	006702			ERRO33::		
114	006702	004737	006766	CALL	PNTPKT	
115	006706			ENDMSG		
	006706			L10012:		
	006706	104423		TRAP	C#MSG	
116						
117	006710			BGNMSG ERRO35		
	006710			ERRO35::		
118	006710			PNTB	X35	
119	006720	004737	007060	CALL	MSGPKT	
120	006724			ENDMSG		
	006724			L10013:		
	006724	104423		TRAP	C#MSG	
121						
122	006726			BGNMSG ERRO36		
	006726			ERRO36::		
123	006726			PNTB	X36	
124	006736			ENDMSG		
	006736			L10014:		
	006736	104423		TRAP	C#MSG	
125						
126	006740			BGNMSG ERRO38		
	006740			ERRO38::		
127	006740			PNTB	X38	
128	006750			ENDMSG		
	006750			L10015:		
	006750	104423		TRAP	C#MSG	
129						
136	006752			BGNMSG ERRO40		
	006752			ERRO40::		
137	006752			PNTB	X40,R2	
138	006764			ENDMSG		
	006764			L10016:		
	006764	104423		TRAP	C#MSG	
140						
141	006766			PNTPKT: PNTB	XPKT1	
142	006776	010401		MOV	R4,R1	
143	007000	062701	000020	ADD	#HC.CPK,R1	
144	007004	010402		MOV	R4,R2	
145	007006	062702	000020	ADD	#HC.MPK,R2	
146	007012	012703	000014	MOV	#12.,R3	
147						
148	007016			PNTPKL: PNTB	XPKT2,2(R1),(R1),2(R2),(R2)	
149	007042	062701	000004	ADD	#4,R1	
150	007046	062702	000004	ADD	#4,R2	

151	007052	005303			DEC	R3		
152	007054	001360			BNE	PNTPKL		
153	007056	000207			RETURN			
154								
155	007060				MSGPKT: PNTB	XMSG1		
156	007070	016504	000014		MOV	C.HCOM(R5),R4		
157	007074	062704	000206		ADD	#HC.BF2,R4		
158	007100	012703	000005		MOV	#5,R3		
159	007104				MSGPKL: PNTB	XMSG2,(R4),2(R4),4(R4),6(R4),8.(R4),10.(R4),12.(R4)		
160	007146	062704	000016		ADD	#14.,R4		
161	007152	005303			DEC	R3		
162	007154	001353			BNE	MSGPKL		
163	007156	000207			RETURN			
164								
165	007160				BGNMSG ERR.TN			: ERROR REPORT ROUTINE
	007160				ERR.TN::			
166	007160	013702	002202		MOV	TNUM,R2		: GET TEST NUMBER
167	007164	006302			ASL	R2		: DOUBLE
168	007166	012703	003637		MOV	#BASL3,R3		: GET ADDRESS OF DRIVE PRINT LINE
169	007172	005764	000004		TST	4(R4)		: CHECK IF DRIVE NUMBER GIVEN
170	007176	100002			BPL	1#		: BRANCH IF SO
171	007200	012703	003654		MOV	#BAS,R3		
172	007204			1#:	PNTB	BASLN,TNAMES-2(R2),#BASL1,(R4),#BASL2,(R5),R3,4(R4)		
173	007242					ASSUME C.UADR EQ 0		
174	007242	004737	016236		CALL	RNTIME		: GET RUNTIME PARAMETERS
175	007246				PRINT	#CR		: ADVANCE TO NEW LINE
176	007256	062704	000006		ADD	#6,R4		: SET R4 TO POINT TO MESSAGE POINTER
177	007262	012402			MOV	(R4)+,R2		: GET MESSAGE POINTER
178	007264	006302			ASL	R2		: DOUBLE TO MAKE BYTE OFFSET
179	007266	063702	002176		ADD	DMPROG,R2		: ADD TO START OF MESSAGE STRINGS
180	007272	067702	172700		ADD	SDMPROG,R2		: ADD SIZE OF MAIN PROGRAM
181	007276	105712			TSTB	(R2)		: CHECK FIRST BYTE
182	007300	001001			BNE	NCON		: IF ZERO
183	007302	005202			INC	R2		: INCREMENT TO NEXT BYTE
184	007304	012737	007522	002342	NCON: MOV	#PX,PTYPE		: CHANGE TO EXTENDED OUTPUT
185	007312	004737	007676		CALL	OSTRNG		: OUTPUT ACCORDING TO STRING
186	007316				ENDMSG			
	007316				L10017:			
	007316	104423			TRAP	C#MSG		
187								

```

1      .SBTTL GLOBAL SUBROUTINES SECTION
2
3      ;**
4      ; FMERR - MEMORY ALLOCATION ERROR
5      ;
6      ; THIS ROUTINE PRINTS A SYSTEM FATAL ERROR AND EXITS THE TEST
7      ;--
8
9      007320      FMERR:  ERRSF 4,,ERR004
10     007320      TRAP   C:ERSF
11     007322      .WORD  4
12     007324      .WORD  0
13     007326      .WORD  ERR004
14
15     ; DO CLEAN-UP TRAP
16
17     007330      DOCLN
18     007330      TRAP   C:DCLN
19
20     ;**
21     ; ALOCM - ALLOCATE A BLOCK OF FREE MEMORY. REPORT ERROR IF MEMORY
22     ; EXHAUSTED.
23     ;
24     ; INPUTS:
25     ; R1 - NUMBER OF WORDS TO ALLOCATE
26     ; FFREE - FIRST FREE WORD IN MEMORY
27     ; FSIZE - SIZE OF FREE MEMORY AVAILABLE IN WORDS
28     ;
29     ; OUTPUTS:
30     ; R1 - ADDRESS OF FIRST WORD OF ALLOCATED MEMORY
31     ; FFREE - NEW FIRST FREE WORD IN MEMORY
32     ; FSIZE - SIZE OF FREE MEMORY LEFT AFTER ALLOCATION
33     ;
34     ; SYSTEM FATAL ERROR WILL BE REPORTED IF NOT ENOUGH MEMORY AVAILABLE
35     ; AND ENTIRE PROGRAM WILL BE STOPPED.
36     ;--
37
38     007332      ALOCM:  PUSH   <FFREE>           ; SAVE FFREE AT ENTRY
39     007336      SUB     R1,FSIZE             ; REDUCE SIZE OF FREE MEMORY
40     007342      BLT    FMERR                ; REPORT ERROR IF NOT ENOUGH MEMORY
41     007344      ADD    R1,R1                ; CHANGE WORDS TO BYTES
42     007346      ADD    R1,FFREE            ; CALCULATE NEW START OF FREE MEMORY
43     007352      POP    <R1>                ; GET START OF ALLOCATED MEMORY
44     007354      RETURN
45
46     ;**
47     ; MCOMM - ALLOCATE MEMORY FOR HOST COMMUNICATION AREA AND PACKET
48     ; BUFFERS WITH ONE DESCRIPTOR IN EACH RING. THIS SUBROUTINE IS CALLED
49     ; AFTER INITIALIZING A CONTROLLER WITH SA.MSG=0 AND SA.C:ID=0.
50     ;
51     ; INPUTS:
52     ; R5 - ADDRESS OF CONTROLLER TABLE
53     ;
54     ; OUTPUTS:
55     ; CONTROLLER TABLE POINTING TO HOST COMMUNICATION AREA,
56     ; RING POINTERS TO PACKETS,
57     ; R4 - ADDRESS OF HOST COMMUNICATION AREA
58     ;--
59
60     007356      MCOMM:  MOV     @<HC.SIZ>/2,R1   ; GET SIZE OF AREA TO ALLOCATE
61     007362      CALL   ALOCM                 ; ALLOCATE THE MEMORY

```



CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 102-1  
GLOBAL SUBROUTINES SECTION

```

53 007366 010104      MOV      R1,R4      ; GET ADDRESS OF MOST COMM AREA
54 007370 010465 000014  MOV      R4,C.MCOM(R5) ; PLACE BEGINNING ADRS OF MOST COMM
55                                     ; AREA IN THE CONTROLLER TABLE
56 007374 062701 000020  ADD      @MC.MPK,R1  ; COMPUTE START OF MESSAGE PACKET
57 007400 010164 000004  MOV      R1,MC.MSG(R4) ; PLACE IN RING
58 007404 062701 000000  ADD      @<MC.CPK-MC.MPK>,R1 ; COMPUTE START OF COMMAND PACKET
59 007410 010164 000010  MOV      R1,MC.CMD(R4) ; PLACE IN RING
60 007414 000207      RETURN

61
62                                     ;**
63                                     ; PRINTC - PRINT A CHARACTER
64                                     ;
65                                     ; CALL WITH MACRO PRINT
66                                     ;**
67
68 007416 110037 002344  PRINTC: MOV     RO,TTYOUT      ; SAVE CHARACTER FOR TTY OUTPUT
69 007422                                     PUSH    <R1>
70 007424 012701 002541  MOV     @FRMTT,R1          ; GET FORMATTED ASCIZ STRING STATEMENT
71 007430 120027 000015  CMPB   RO,@CR             ; IF NOT A CARRIAGE RETURN, THEN
72 007434 001002                                     BNE    1$                 ; PRINT SOME OTHER CHARACTER, ELSE
73 007436 012701 002544  MOV     @CRLF,R1          ; GET FORMATTED ASCIZ STRING STATEMENT
74                                     ; GO PRINT CR-LF.
75 007442 004777 172674  1$:    CALL   @PTYPE          ; PRINT THE ASCIZ STRING.
76 007446                                     POP     <R1>
77 007450 000207      RETURN
78 007452      PF:    PRINTF   R1,@TTYOUT
79 007452 012746 002344  MOV     @TTYOUT,-(SP)
80 007456 010146      MOV     R1,-(SP)
81 007460 012746 000002  MOV     @2,-(SP)
82 007464 010600      MOV     SP,RO
83 007466 104417      TRAP   C@PNTF
84 007470 062706 000006  ADD     @6,SP
85 007474 000207      RETURN
86 007476      PB:    PRINTB   R1,@TTYOUT
87 007476 012746 002344  MOV     @TTYOUT,-(SP)
88 007502 010146      MOV     R1,-(SP)
89 007504 012746 000002  MOV     @2,-(SP)
90 007510 010600      MOV     SP,RO
91 007512 104414      TRAP   C@PNTB
92 007514 062706 000006  ADD     @6,SP
93 007520 000207      RETURN
94 007522      PX:    PRINTX   R1,@TTYOUT
95 007522 012746 002344  MOV     @TTYOUT,-(SP)
96 007526 010146      MOV     R1,-(SP)
97 007530 012746 000002  MOV     @2,-(SP)
98 007534 010600      MOV     SP,RO
99 007536 104415      TRAP   C@PNTX
100 007540 062706 000006  ADD     @6,SP
101 007544 000207      RETURN
102 007546      PS:    PRINTS   R1,@TTYOUT
103 007546 012746 002344  MOV     @TTYOUT,-(SP)
104 007552 010146      MOV     R1,-(SP)
105 007554 012746 000002  MOV     @2,-(SP)
106 007560 010600      MOV     SP,RO
107 007562 104416      TRAP   C@PNTS
108 007564 062706 000006  ADD     @6,SP
109 007570 000207      RETURN

```

```

86
87
88      :..
89      :
90      :
91      :..
92
93 007572 012737 007452 002342 LPNTF: MOV   @PF,PTYPE
94 007600 000413                BR    LPNT
95
96 007602 012737 007476 002342 LPNTB: MOV   @PB,PTYPE
97 007610 000407                BR    LPNT
98
99 007612 012737 007522 002342 LPNTX: MOV   @PX,PTYPE
100 007620 000403                BR    LPNT
101
102 007622 012737 007546 002342 LPNTS: MOV   @PS,PTYPE
103
104 007630                LPNT:  PUSH   <R2,R3,R4,R5>
105 007640 012102                MOV   (R1)+,R2      ; GET ADDRESS OF ASCIZ STRING
106 007642 010604                MOV   SP,R4        ; COMPUTE ADDRESS OF 1ST ARGUMENT AND
107 007644 062704 000012                ADD   @12,R4       ; SAVE IT IN R4.
108 007650                PUSH   <R1>          ; SAVE R1 ON THE STACK
109 007652 004737 007676                CALL  OSTRING     ; PRINT THE FORMATTED MESSAGE
110 007656                POP    <R0,R5,R4,R3,R2,R1> ; RESTORE REGISTERS FROM STACK
111 007672 062006                ADD   (R0)+,SP    ; ADJUST STACK POINTER OVER ARGUMENTS
112 007674 000110                JMP   BR0        ; RETURN
113
114      :..
115      :
116      :
117      :
118      :
119      :
120      :
121      :
122      :
123      :
124      :
125      :
126      :
127      :
128      :
129      :
130      :
131      :
132      :
133      :
134      :
135      :
136      :
137      :
138      :
139      :
140      :
141      :
142      :

```

PRINT FORMATTED MESSAGE

CALL WITH MACRO PNT, PNTF, PNTB, PNTX, OR PNTS

OSTRING - OUTPUT A MESSAGE ACCORDING TO A FORMAT STRING

FORMAT OF THE ASCIZ STRING IS AS FOLLOWS:

CHARACTERS ENCLOSED IN QUOTES ARE TO BE PRINTED AS THEY ARE.

OTHERWISE CODE IS A SINGLE LETTER FOLLOWED BY AN OPTIONAL DECIMAL NUMBER:

- ON - PRINT OCTAL NUMBER. N REPRESENTS SIZE OF BINARY NUMBER PASSED IN PARAMETER IN BITS. MAY BE IN RANGE 1 TO 32. IF N>16, TWO PARAMETER WORDS ARE USED, OTHERWISE ONLY ONE WORD. LEADING ZEROS ARE PRINTED. N IS ALWAYS SPECIFIED.
- DN - PRINT UNSIGNED DECIMAL NUMBER FROM N BIT PARAMETER. LEADING ZEROS ARE NOT PRINTED. A 16 BIT NUMBER EQUAL TO ZERO WILL PRINT "0".
- MN - PRINT HEX NUMBER FROM PARAMETER OF N BITS. IF N>16 TWO PARAMETERS ARE USED, OTHERWISE ONLY ONE PARAMETER. LEADING ZEROS ARE PRINTED.
- SN - PRINT N SPACES. N ASSUMED TO BE 1.
- NN - START NEW LINE (CR-LF SEQUENCE). N ASSUMED TO BE 1.
- AN - PRINT N ASCII CHARACTERS FROM PARAMETERS. N ASSUMED TO BE 1. N/2 PARAMETER WORDS USED.
- RN - EXECUTE ROUTINE #N. N MUST BE GIVEN AND DEFINED IN MOST PROGRAM.

A NULL CHARACTER MEANS END OF MESSAGE. A NULL AS FIRST CHARACTER IN STRING MUST BE IGNORED.

INPUTS:

```

143      ;           R2 - ADDRESS OF START OF FORMAT STRING
144      ;           R4 - ADDRESS OF PARAMETERS
145      ;           OUTPUTS:
146      ;           R2 AND R4 UPDATED TO END OF STRING AND PARAMETERS
147      ;--
148
149 007676 112201 OSTRNG: MOVB (R2),R1      ; SEE IF TERMINATOR IN ASCIZ STRING,
150 007700 001421      BEQ  OSTRE      ; EXIT
151 007702 012700 010202      MOV  #ERRC,R0      ; GET POINTER TO CHARACTER TABLE
152 007706 120110      NCONS: CMPB  R1,(R0)      ; COMPARE CHARACTER WITH TABLE ENTRY
153 007710 001407      BEQ  NCONF      ; BRANCH IF MATCH FOUND
154 007712 105720      TSTB  (R0),      ; INCREMENT POINTER
155 007714 001374      BNE  NCONS      ; CONTINUE SEARCH IF NOT END OF TABLE
156 007716      PNTF  ERRME1      ; REPORT BAD CONTROL CHARACTER
157 007726 000406      BR   OSTRE      ;
158 007730 162700 010202      NCONF: SUB  #ERRC,R0      ; GET INCREMENT INTO TABLE
159 007734 006300      ASL  R0      ; DOUBLE TO WORD COUNT
160 007736 004770 010214      CALL BERRD(R0)      ; DISPATCH TO PRINT ROUTINE
161 007742 000755      BR   OSTRNG      ; GET NEXT
162 007744 000207      OSTRE: RETURN
163
164      ;
165      ; CONTROL CHARACTER WAS A QUOTE, SO PRINT ALL CHARACTERS TO
166      ; THE NEXT QUOTE.
167      ;
168
169 007746 112200      CON.GU: MOVB (R2),R0      ; GET CHARACTER
170 007750 120027 000042      CMPB  R0,' '      ; CHECK IF ENDING QUOTE
171 007754 001403      BEQ  CON.GX      ; IF SO, GO GET NEXT CONTROL CHARACTER
172 007756      PRINT R0
173 007762 000771      BR   CON.GU      ; CONTINUE PRINTING
174 007764 000207      CON.GX: RETURN
175
176      ;
177      ; CONTROL CHARACTER WAS AN 'A', SO PRINT ASCII CHARACTERS FROM
178      ; PARAMETERS.
179      ;
180
181 007766 004737 013314      CON.A: CALL  GETCNT      ; GET COUNT OF CHARACTERS
182 007772      CON.A1: PRINT (R4),      ;
183 010000 005301      DEC  R1      ; COUNT THE CHARACTERS
184 010002 001373      BNE  CON.A1      ; PRINT UNTIL COUNT REACHES ZERO
185 010004 032704 000001      BIT  #1,R4      ; CHECK IF R4 NOW ODD
186 010010 001401      BEQ  CON.A2      ;
187 010012 005204      INC  R4      ; IF SO, INCREMENT TO NEXT EVEN ADDRESS
188 010014 000207      CON.A2: RETURN      ; NOW GET NEXT CONTROL CHARACTER
189
190      ;
191      ; CONTROL CHARACTER WAS A 'D', SO PRINT A DECIMAL NUMBER.
192      ;
193
194 010016 012701 000012      CON.D: MOV  #10.,R1      ; LOAD RADIX
195 010022 004737 013372      CALL  PNTNUM      ; PRINT NUMBER
196 010026 000207      RETURN      ; NOW GET NEXT CONTROL CHARACTER
197
198      ;
199      ; CONTROL CHARACTER WAS AN 'H', SO PRINT A HEX NUMBER.

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 102-4  
GLOBAL SUBROUTINES SECTION

```

200      ;
201      ;
202 010030 012701 000020      CON.H:  MOV    #16.,R1      ; LOAD RADIX
203 010034 004737 013372      CALL    PNTNUM      ; PRINT NUMBER
204 010040 000207              RETURN      ; NOW GET NEXT CONTROL CHARACTER
205      ;
206      ;
207      ;      CONTROL CHARACTER WAS AN 'O', SO PRINT AN OCTAL NUMBER.
208      ;
209      ;
210 010042 012701 000010      CON.O:  MOV    #8.,R1      ; LOAD RADIX
211 010046 004737 013372      CALL    PNTNUM      ; PRINT NUMBER
212 010052 000207              RETURN      ; NOW GET NEXT CONTROL CHARACTER
213      ;
214      ;
215      ;      CONTROL CHARACTER WAS AN 'N', SO PRINT A CARRIAGE RETURN-LINE FEED.
216      ;
217      ;
218 010054 004737 013314      CON.N:  CALL    GETCNT      ; GET COUNT
219 010060              CON.N1: PRINT    #CR      ;
220 010070 005301              DEC     R1      ; COUNT THE SEQUENCES
221 010072 001372              BNE    CON.N1      ;
222 010074 000207              RETURN      ; NOW GET NEXT CONTROL CHARACTER
223      ;
224      ;
225      ;      CONTROL CHARACTER WAS AN 'R', SO CALL ONE OF THE PRE-PROGRAMMED
226      ;      ROUTINE.
227      ;
228      ;
229 010076 004737 013314      CON.R:  CALL    GETCNT      ; GET ROUTINE NUMBER
230 010102 020127 000011      CMP    R1,#ERR.SZ      ; CHECK IF DEFINED ROUTINE NUMBER
231 010106 101004              BHI    CON.R1      ;
232 010110 060101              ADD    R1,R1      ; DOUBLE COUNT TO GET WORD INDEX
233 010112 004771 010154      CALL    @ERR.TB-2(R1)  ; CALL ROUTINE
234 010116 000207              RETURN      ; NOW GET NEXT CONTROL CHARACTER
235      ;
236 010120              CON.R1: PNTF    ERRME1      ; REPORT BAD MESSAGE STRING
237 010130              POP     R1      ; FIX THE STACK
238 010132 000207              RETURN
239      ;
240      ;
241      ;      CONTROL CHARACTER WAS AN 'S', SO PRINT SOME NUMBER OF SPACES.
242      ;
243      ;
244 010134 004737 013314      CON.S:  CALL    GETCNT      ; GET COUNT
245 010140              CON.S1: PRINT    '<#>'      ;
246 010150 005301              DEC     R1      ; COUNT THE SPACES
247 010152 001372              BNE    CON.S1      ;
248 010154 000207              RETURN      ; NOW GET NEXT CONTROL CHARACTER
249      ;
250      ;
251      ;      PRE-PROGRAMMED ERROR ROUTINE DISPATCH TABLE
252      ;
253      ;
254 010156 012656      ERR.TB: .WORD CALR1      ; CALL ALTERNATE PRINT STRING IN DM PGM
255 010160 012704      .WORD CALR2      ; PRINT AN SDI DIAGNOSE RESPONSE
256 010162 013002      .WORD CALR3      ; DECIDE WHETHER TO PRINT RBN

```

## GLOBAL SUBROUTINES SECTION

```

257 010164 013016      .WORD CALR4      ; PRINT BASIC LINE W/O CONTROLLER ADDR.
258 010166 013072      .WORD CALR5      ; PRINT BASIC LINE W/ CONTROLLER ADDR.
259 010170 013150      .WORD CALR6      ; CALL ALTERNATE PRINT STRING IN PDP-11
260 010172 013164      .WORD CALR7      ; PRINT "REPLACE PROCESSOR MODULE"
261 010174 013202      .WORD CALR8      ; PRINT "SA REGISTER CONTAINS XXXXXX"
262 010176 013220      .WORD CALR9      ; REPRINT LAST NUMBER
263
264                000011      ERR.SZ = <.-ERR.TB>/2
265
266 010200                TNAME$ :
273 010200 003552      .WORD BASN4
275
276                ;
277                ; CONTROL CHARACTER TABLE
278                ;
279
280 010202                042      ERRC: .BYTE  "
281 010203                101      .BYTE  'A
282 010204                104      .BYTE  'D
283 010205                110      .BYTE  'H
284 010206                117      .BYTE  'O
285 010207                116      .BYTE  'N
286 010210                122      .BYTE  'R
287 010211                123      .BYTE  'S
288
289 010212                000      .BYTE  0      ;FOLLOW WITH A NULL BYTE
290                .EVEN
291
292                ;
293                ; ROUTINE ADDRESS TABLE
294                ;
295
296 010214 007746      ERRD: .WORD  CON.QU
297 010216 007766      .WORD  CON.A
298 010220 010016      .WORD  CON.D
299 010222 010030      .WORD  CON.H
300 010224 010042      .WORD  CON.C
301 010226 010054      .WORD  CON.N
302 010230 010076      .WORD  CON.R
303 010232 010134      .WORD  CON.S

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 103  
 GLOBAL SUBROUTINES SECTION

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15 010234
16 010234 010137 002202
17 010240 004737 016134
19 010244 005037 002366
21 010250 013737 002162 002156
22 010256 013737 002164 002160
23 010264 006301
24 010266 016137 010274 002176
25 010274 000207
26
27 010276
34 010276 000000G

      ;**
      ;
      ;   TINIT - INITIALIZE VARIABLES FOR TEST
      ;
      ;   INPUTS:
      ;       R1 - TEST NUMBER
      ;
      ;   OUTPUTS:
      ;       DMPROG - POINTER TO START OF DM PROGRAM IN MEMORY
      ;       LBUFS - CLEARED (DELETES ERROR LOG)
      ;       TNUM - TEST NUMBER FROM R1
      ;       ALL REGISTERS CLOBERED
      ;
      ;--
TINIT:
      MOV     R1,TNUM           ; SAVE TEST NUMBER
      CALL   RESET            ; RESET ALL CONTROLLERS
      CLR    LBUFS            ; CLEAR ERROR LOG BUFFER POINTER
      MOV    FMEM,FFREE       ; INIT FREE
      MOV    FMEMS,FSIZE     ; INIT FSIZE
      ASL   R1                ; R1 IS WORD INDEX
      MOV    READDT-2(R1),DMPROG ; STORE ADDRESS OF DM TEST INTO DMPROG
      RETURN

READDT:
      .WORD  TEST4

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 104  
GLOBAL SUBROUTINES SECTION

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16 010300 010137 002204
17 010304 005037 002206
18
19
20
21 010310 013705 002174
22 010314 013737 002204 002210
23 010322
24 010322 005065 000012
25 010326 116537 000002 002074
26 010334 005765 000002
27 010340 100405
28 010342
29 010342 004737 014376
30 010346 001402
31 010350 005237 002206
32 010354 062705 000034
33 010360 005337 002210
34 010364 001356
35
36
37
38 010366 005737 002206
39
40
41
42
43 010372 000207
44

```

```

***
:
:   RUNDH - LOAD AND RUN A DM PROGRAM IN THE CONTROLLERS. RETURN WHEN ALL
:   DM PROGRAMS HAVE TERMINATED.
:
:   INPUTS:
:   R1 - NUMBER OF CONTROLLERS TO TEST
:   R5 - POINTER TO FIRST CONTROLLER TABLE
:
:   IMPLICIT INPUTS:
:   DMPROG - POINTER TO START OF DM PROGRAM IN MEMORY
:
:   OUTPUTS:
:   Z SET IF NO CONTROLLERS SUCCESSFULLY STARTED
:   R1-R5 - CONTENTS DESTROYED
:
:--
:
:
:   RUNDH:  MOV   R1,URUN           ; SAVE NUMBER OF UNITS TO RUN
:          CLR   URNING           ; CLEAR NUMBER OF UNITS RUNNING
:
:          ;
:          ;   LOAD DM PROGRAM INTO EACH CONTROLLER
:          ;
:          MOV   TSTTAB,R5        ; GET CONTROLLER TABLE ADDRESS
:          MOV   URUN,UCNT        ; SET COUNTER OF UNITS
:
:   LDDH:   CLR   C.FLG(R5)       ; CLEAR ALL FLAGS
:          MOVB  C.UNIT(R5),L#LUN ; SEE IF UNIT TO BE TESTED
:          TST   C.UNIT(R5)       ;
:          BMI   LDNEXT           ; IF NOT, DON'T LOAD THIS UNIT
:          ASSUME CT.AVL EQ BIT15
:          CALL  LOADDM           ; LOAD THE DM PROGRAM
:          BEQ   LDNEXT           ; IF ERROR, GO TO NEXT CONTROLLER
:          INC   URNING           ; IF NO ERROR, COUNT UNIT RUNNING
:   LDNEXT: ADD   #C.SIZE,R5      ; MOVE TO NEXT CONTROLLER TABLE
:          DEC   UCNT             ; CHECK IF MORE CONTROLLERS
:          BNE   LDDH            ; LOAD NEXT CONTROLLER
:
:          ;
:          ;   CHECK IF ANY CONTROLLERS LOADED
:          ;
:          TST   URNING           ; ANY UNITS LOADED?
:
:          ;
:          ;   THE DM PROGRAMS ARE NOW IN CONTROL
:          ;   RESPDM MUST BE CALLED TO RESPOND TO THEIR REQUESTS
:
:          ;
:          ;   RETURN
:
:

```





CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 105-1  
GLOBAL SUBROUTINES SECTION

```

54 010552 101005      BHI      RSPRPT      ; IF GREATER PRINT REPORT
55 010554 001005      BNE      RSPNRP      ; IF NOT SAME, ITS NOT TIME YET
56 010556 023737 002330 002334  CMP      KW.EL,STIME ; CHECK LOW WORD OF ELAPSED TIME
57 010564 103401      BLO      RSPNRP      ; IF LESS, ITS NOT TIME YET
58 010566      RSPRPT:      ;
59 010566      DORPT      ; PRINT A STATISTICAL REPORT
   010566 104424      TRAP      C#DRPT
60      ;
61      ; SWITCH TO NEXT CONTROLLER
62      ;
63 010570 062705 000034  RSPNRP: ADD      #C.SIZE,R5      ; MOVE TO NEXT TABLE
64 010574 005337 002210  DEC      UCNT          ; CHECK IF MORE CONTROLLERS
65 010600 001302      BNE      RESPCT       ; LOOK AT NEXT CONTROLLER
66 010602 000674      BR       RESPDM       ; LOOK AT FIRST CONTROLLER AGAIN
67      ;
68      ; REMOVE A CONTROLLER FROM TESTING
69      ;
70 010604 042765 000012 000012 RSPDRP: BIC      #CT.RN+CT.MSG,C.FLG(R5) ; CLEAR PROGRAM RUNNING
71 010612 005337 002206  DEC      URNING       ; REDUCE RUNNING CONTROLLERS COUNT
72 010616 001347      BNE      RSPNXT       ; IF ANY STILL RUNNING, LOOK AT THEM
73 010620 000207      RETURN      ; ELSE RETURN TO TEST SECTION
74      ;
75      ; CONTROLLER HAS RESPONDED, LOOK AT MESSAGE PACKET
76      ; CHECK FOR PROPER OPCODE IN END PACKET
77      ;
78 010622 012700 000204  RSPIN:  MOV      #OP.END+OP.SSD,R0      ; GET SEND DATA END PACKET OPCODE
79 010626 032765 000020 000012  BIT      #CT.REQ,C.FLG(R5)      ; LOOK IF SEND DATA OR RECEIVE DATA
80 010634 001402      BEQ      RSPMR        ;
81 010636 012700 000205  MOV      #OP.END+OP.RSD,R0      ; CHANGE TO RECEIVE DATA ENDCODE
82 010642 120064 000030  RSPMR:  CMPB     R0,HC.MPK+P.OPCD(R4) ; COMPARE TO OPCODE IN END PACKET
83 010646 001010      BNE      RSPERR        ;
84      ;
85      ; LOOK AT STATUS CODE
86      ;
87 010650 032764 000037 000032  BIT      #ST.MSK,HC.MPK+P.STS(R4) ; CHECK FOR STATUS CODE ST.SUC (ZERO)
88 010656 001004      BNE      RSPERR        ;
89      ;
90      ; CHECK FOR EXPECTED REFERENCE NUMBER
91      ;
92 010660 026564 000032 000020  CMP      C.REF(R5),HC.MPK+P.CRF(R4) ; CHECK IF CORRECT REF NUMBER
93 010666 001405      BEQ      RSPPTW       ;
94 010670      RSPERR:  ERDF    33,ERR033      ;
   010670 104455      TRAP      C#ERDF
   010672 000041      .WORD    33
   010674 000000      .WORD    0
   010676 006702      .WORD    ERR033
95 010700 000741      BR       RSPDRP        ; DROP UNIT FROM TESTING
96      ;
97      ; CHECK IF RESPONSE FROM SEND OR RECEIVE DATA COMMAND
98      ;
99 010702 032765 000020 000012  RSPPTW: BIT      #CT.REQ,C.FLG(R5)      ; CHECK IF RESPONSE FROM DM PROGRAM
100 010710 001445      RSPDU:  BEQ      RSPDU        ; LOOK AT REQUEST NUMBER IF SO
101      ;
102      ; MAINTENANCE READ END PACKET RECEIVED, LOOK AT REQUEST FROM DM PROGRAM
103      ;
104 010712 016401 000206  RSPPT2: MOV      HC.BF2(R4),R1      ; GET REQUEST NUMBER
105 010716 042701 007777  BIC      #007777,R1      ; CHECK TYPE

```

CZUDIA0 UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 105-2  
GLOBAL SUBROUTINES SECTION

```

106 010722 022701 060000      CMP      #DU.SPC,R1      ; IS SPECIAL TYPE SET?
107 010726 001010      BNE      18            ; IF NOT, ERROR
108 010730 042764 170000 000206  BIC      #+C007777,HC.BF2(R4) ; CLEAR TYPE
109 010736 016401 000206      MOV      HC.BF2(R4),R1 ; GET REQUEST NUMBER
110 010742 020127 000017      CMP      R1,#DPSIZ    ; CHECK IF IN EXPECTED RANGE
111 010746 103405      BLO      RSPPT3      ;
112 010750      18:      ERRDF 32,ERR032    ; BAD REQUEST NUMBER
      010750 104455      TRAP   C+ERRDF
      010752 000040      .WORD 32
      010754 000000      .WORD 0
      010756 006664      .WORD ERR032
113 010760 000711      BR      RSPDRP      ; DROP UNIT FROM TESTING
114
115 010762 012700 000004      RSPPT3: MOV      #OP.SSD,R0 ; BUILD A SEND DATA COMMAND PACKET
116 010766 004737 014572      CALL   BLDCHD      ; FOR ANSWER TO DM PROGRAM
117 010772 012700 000100      MOV      #HC.BF1,R0 ; POINT TO BUFFER IN PACKET
118 010776 004737 014732      CALL   CLRBUF      ; AND CLEAR BUFFER
119 011002 010403      MOV      R4,R3      ; R3 POINTS TO COMMAND BUFFER
120 011004 062704 000106      ADD      #HC.BSZ,R4 ; R4 POINTS TO MESSAGE BUFFER
121 011010 011401      MOV      (R4),R1    ; GET REQUEST NUMBER
122 011012 012423      MOV      (R4)+,(R3)+ ; PUT REQUEST # INTO COMMAND PACKET
123 011014 060101      ADD      R1,R1      ; DOUBLE REQUEST NUMBER
124 011016 004771 011126      CALL   BRSPDSP(R1) ; CALL REQUESTED ROUTINE
125 011022 001270      BNE      RSPDRP      ; RETURN Z CLEAR TO DROP UNIT
126
127
128      ; SEND COMMAND BACK TO CONTROLLER
129
130 011024 042765 000010 000012  RSPOUT: BIC      #CT.MSG,C.FLG(R5) ; CLEAR MESSAGE RECEIVED FLAG
131 011032 032765 000020 000012  BIT      #CT.REQ,C.FLG(R5) ; CHECK WHICH COMMAND TO SEND
132 011040 001014      BNE      RSPOU2      ; BRANCH IF RESPONSE TO REQUEST
133 011042 012700 000005      MOV      #OP.RSD,R0 ; BUILD RECEIVE DATA COMMAND
134 011046 004737 014572      CALL   BLDCHD      ;
135 011052 012700 000206      MOV      #HC.BF2,R0 ; POINT TO MESSAGE BUFFER
136 011056 004737 014732      CALL   CLRBUF      ; AND CLEAR IT
137 011062 052765 000020 000012  BIS      #CT.REQ,C.FLG(R5) ; SET REQUEST BIT
138 011070 000403      BR      RSPOU3      ;
139
140 011072 042765 000020 000012  RSPOU2: BIC      #CT.REQ,C.FLG(R5) ; CLEAR REQUEST BIT
141 011100      RSPOU3:
142 011100 004737 014664      CALL   SNDCHD      ; SEND COMMAND TO CONTROLLER
143 011104 012700 000264      MOV      #3.*60.,R0 ; SET TIMEOUT FOR 3 MINUTES
144 011110 010501      MOV      R5,R1      ;
145 011112 062701 000026      ADD      #C.TO,R1   ; PUT TIME IN CONTROLLER TABLE
146 011116 004737 015210      CALL   SETTO      ;
147 011122 000137 010536      JMP      RSPNXT     ; NOW WAIT FOR END PACKET
148
149      ; RESPONSE REQUEST DISPATCH TABLE
150
151 011126 011164      RSPDSP: .WORD DMRQ0 ; 0 SET UP MEMORY FOR ADDRESS TESTING
152 011130 000000      .WORD 0 ; 1 *** REQUEST NO LONGER VALID ***
168 011132 000000      .WORD 0 ; 2 *** NOT VALID FOR CZUDIO ***
169 011134 011304      .WORD DMRQ3 ; 3 TELL DATA PATTERN 16.
170 011136 011326      .WORD DMRQ4 ; 4 TELL UNIT PARAMS, CLEAR CONTENTS
171 011140 011622      .WORD DMRQ5 ; 5 TELL BAD BLOCKS (FIRST 14)
172 011142 011652      .WORD DMRQ6 ; 6 TELL BAD BLOCKS (LAST TWO)
173 011144 011702      .WORD DMRQ7 ; 7 ADD TO SOFT ERROR AND ECC COUNTS

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 105-3  
GLOBAL SUBROUTINES SECTION

174 011146 011734  
175 011150 011754  
176 011152 012116  
177 011154 012176  
178 011156 012402  
179 011160 012540  
180 011162 012652  
182  
183 000017  
184

.WORD DMRQ8  
.WORD DMRQ9  
.WORD DMRQA  
.WORD DMRQB  
.WORD DMRQC  
.WORD DMRQD  
.WORD DMRQE

DSPSIZ = <.-RSPDSP>/2

; 8 ADD 1000 TO SEEK COUNT  
; 9 ADD TO MEGABITS TRANSFERRED COUNT  
;10 TELL WHICH DRIVES TO TEST  
;11 REPORT ERROR MESSAGE  
;12 REPORT ERROR & COUNT HARD ERROR  
;13 PRINT A DESCRIPTIVE MESSAGE  
;14 MARK DM PROGRAM AS NOT RUNNING  
;LEGAL NUMBERS ARE LOWER THAN THIS

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39

```

: **
: NORMAL MAINTENANCE READ BUFFER DESCRIPTION
    
```

```

: BYTE OFFSET FROM
: START OF BUFFER
:
: 0 ) REQUEST NUMBER ) USED TO SELECT ROUTINE
:
: 2 ) DATA ARGUMENT #1 ) R4 CONTAINS THIS ADDRESS
:
: 4 ) DATA ARGUMENT #2 )
:
: 6 ) DATA ARGUMENT #3 )
:
: .
:
: .
:
: 68 ) DATA ARGUMENT #34 )
:
    
```

```

: NORMAL PSEUDO-TERMINAL IN PACKET DESCRIPTION GIVEN IN RESPONSE TO ABOVE PACKET
    
```

```

: BYTE OFFSET FROM
: START OF PACKET
:
: 0 ) REQUEST NUMBER ) ECHOED FROM REQUEST PACKET
:
: 2 ) DATA ARGUMENT #1 ) R3 CONTAINS THIS ADDRESS
:
: 4 ) DATA ARGUMENT #2 ) ALL DATA ARGUMENTS ARE RETURNED
: CONTAINING ZEROS UNLESS
: SPECIFICALLY INDICATED BY
: RESPONSE ROUTINE.
:
: 6 ) DATA ARGUMENT #3 )
:
: .
:
: .
:
: 68 ) DATA ARGUMENT #34 )
:
    
```



CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 107-1  
GLOBAL SUBROUTINES SECTION

58	011252	006300	ASL	R0	
59	011254	006300	ASL	R0	
60	011256	006300	ASL	R0	
61	011260	006300	ASL	R0	
62	011262	006101	ROL	R1	
63	011264	006300	ASL	R0	
64	011266	006101	ROL	R1	
65	011270	052700	BIS	#76,R0	;SET LOW ORDER BITS
66	011274	010023	MOV	R0,(R3).	;PUT INTO BUFFER
67	011276	010123	MOV	R1,(R3).	
68	011300	000264	SEZ		
69	011302	000207	RETURN		
70					

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 108  
 GLOBAL SUBROUTINES SECTION

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19 011304 012701 000021
20 011310 012702 002256
21 011314 012223
22 011316 005301
23 011320 001375
24 011322 000264
25 011324 000207

;DMRQ3 - DM REQUEST 3
;
;REQUEST FOR CZUDIO CONTENTS OF DATA PATTERN 16.
;
;INPUTS:
;   R5 - CONTROLLER TABLE ADDRESS
;   R4 - MESSAGE DATA ADDRESS
;         (NO DATA)
;   R3 - COMMAND DATA ADDRESS
;OUTPUTS:
;   COMMAND DATA FILLED WITH THE FOLLOWING:
;   (R3) NUMBER OF WORDS IN DATA PATTERN 16
;   2.(R3) DATA IN PATTERN 16
;   "
;   32.(R3) "
;   Z SET
DMRQ3:  MOV     #17.,R1           ;GET COUNT
        MOV     #PAT16C,R2      ; AND ADDRESS OF PATTERN 16 PARAMETERS
1$:    MOV     (R2),.(R3).      ;COPY THE DATA TO BUFFER
        DEC     R1
        BNE    1$
        SEZ
        RETURN
;RETURN WITH Z SET

```

```

1
2      ;DMRQ4 - DM REQUEST 4
3      ;
4      ;REQUEST FOR CZUDIO UNIT PARAMETERS
5      ;
6      ;INPUTS:
7      ;   R5 - CONTROLLER TABLE ADDRESS
8      ;   R4 - MESSAGE DATA ADDRESS
9      ;       (R4) DRIVE NUMBER
10     ;       2.(R4) DRIVE SERIAL NUMBER
11     ;       :
12     ;       6.(R4)
13     ;       8.(R4) HDA SERIAL NUMBER
14     ;       :
15     ;       14.(R4)
16     ;   R3 - COMMAND DATA ADDRESS
17     ;OUTPUTS:
18     ;   COMMAND DATA FILLED WITH THE FOLLOWING:
19     ;   (R3) PARAMETER BITS (1 FOR TRUE)
20     ;   BIT      14 - INITIAL WRITE
21     ;   BIT      13 - DIAGNOSTIC CYLINDERS
22     ;   BIT      12 - ECC CORRECTION
23     ;   BIT      11 - READ ONLY
24     ;   BIT      10 - WRITE ONLY
25     ;   BIT      9 - RETRIES
26     ;   BIT      8 - TRACK/GROUP AND CYLINDERS SPECIFIED
27     ;   BIT      7 - (NOT USED)
28     ;   BIT      6 - SEQUENTIAL SEEKS
29     ;   BIT      5 - BEGIN/END SETS SPECIFIED
30     ;   BIT      4 - TRACK SPECIFIED (0 - GROUPS SPECIFIED)
31     ;   HAS MEANING ONLY WHEN BIT 5 IS ZERO
32     ;   BIT      3 - WRITE CHECKS ENABLED
33     ;   BIT      2 - WRITE CHECKS ALWAYS
34     ;   BIT      1 - DATA COMPARES ENABLED
35     ;   BIT      0 - DATA COMPARE ALWAYS
36     ;   2.(R3) DATA PATTERN NUMBER
37     ;   IF PARAMETER BIT 5 SET
38     ;   4.(R3) COUNT OF BEGIN/END SETS
39     ;   6.(R3) BEGIN BLOCK (2 WORDS) THEN END BLOCK (2 WORDS)
40     ;       :
41     ;       :   1 TO 4 SETS
42     ;       :   OR
43     ;       :   IF COUNT OF BEGIN/END BLOCKS = 0
44     ;   36.(R3) START CYLINDER (2 WORDS) THEN END CYLINDER (2 WORDS)
45     ;       END CYLINDER A NEGATIVE VALUE IF TO TEST ENTIRE AREA
46     ;   IF PARAMETER BIT 5 CLEAR
47     ;   4.(R3) STARTING CYLINDER
48     ;   6.(R3) (2 WORDS)
49     ;   8.(R3) ENDING CYLINDER (2 WORDS)
50     ;   10.(R3) NEGATIVE FOR ALL CYLINDERS
51     ;   12.(R3) NUMBER OF TRACKS OR GROUPS SPECIFIED
52     ;   14.(R3) 1 TO 7 TRACK OR GROUP NUMBERS
53     ;       :   DETERMINED BY PARAMETER BIT 4
54     ;   26.(R3)
55     ;   Z SET IF DATA RETURNED
56     ;   Z CLEAR IF UNIT NUMBER NOT ON THIS CONTROLLER
57     ;
58     ;DMRQ4:

```



CZUDIOA UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 109-1  
GLOBAL SUBROUTINES SECTION

```

58 011326 012401      MOV      (R4),R1      ;GET DRIVE NUMBER
59 011330 010402      MOV      R4,R2      ;SAVE DATA ADDRESS
60 011332 004737 013224 CALL     GTDRVT      ;GET DRIVE TABLE ADDRESS
61 011336 001130      BNE      DMRQ4X     ;CHECK IF DRIVE FOUND
62 011340 012264 000200 MOV      (R2),D.SERN(R4) ;COPY DRIVE SERIAL # TO DRIVE TABLE
63 011344 012264 000202 MOV      (R2),D.SERN+2(R4)
64 011350 012264 000204 MOV      (R2),D.SERN+4(R4)
65 011354 012264 000210 MOV      (R2),D.HDAS(R4)      ;COPY HDA SERIAL NUMBER TO DRIVE TABLE
66 011360 012264 000212 MOV      (R2),D.HDAS+2(R4)
67 011364 012264 000214 MOV      (R2),D.HDAS+4(R4)
68 011370 016401 000004 MOV      D.PRM(R4),R1      ;GET PARAMETER BITS
69 011374 042701 140200 BIC      #D.ZERO,R1      ;CLEAR SOME BITS
70 011400 032737 000020 002200 BIT      #ISTRM,IFLAGS    ;FIRST TIME CZUDIO BEING RUN,
71 011406 001406      BEQ      1#           ;BRANCH IF NOT, ELSE
72 011410 032737 040000 002144 BIT      #SM.IW,SFPTBL+SO.BIT ;GET INITIAL WRITE BIT.
73 011416 001402      BEQ      1#
74 011420 052701 040000      BIS      #D.IW,R1      ;MOVE INTO PARAMETER BITS
75 011424 010123      MOV      R1,(R3)      ;PUT INTO BUFFER
76 011426 016423 000006 1#:   MOV      D.PAT(R4),(R3)  ;PUT PATTERN NUMBER IN BUFFER
77 011432 032701 000040      BIT      #D.BE,R1      ;CHECK BEGIN/END PARAMETER BIT
78 011436 001411      BEQ      3#           ;BRANCH IF NOT SET
79          ;
80          ; RETURN BEGIN/END SETS
81          ;
82 011440 012701 000021      MOV      #4*4+1,R1     ; # OF SETS * WORDS PER SET+COUNT WORD
83 011444 010402      MOV      R4,R2      ;GET INDEX INTO DRIVE TABLE
84 011446 062702 000112      ADD      #D.BEC,R2
85 011452 012223      MOV      (R2),R3     ;TRANSFER THE BEGIN/END SETS
86 011454 005301      DEC      R1
87 011456 001375      BNE      2#
88 011460 000457      BR       DMRQ4X
89          ;
90 011462 032764 000400 000004 3#: BIT      #D.CYL,D.PRM(R4) ;LOOK AT D.CYL BIT
91 011470 001441      BEQ      8#           ;BRANCH IF NOT SET
92          ;
93          ; RETURN TRACKS/GROUPS AND CYLINDERS
94          ;
95          ;
96          ;
97 011472 005764 000112      TST      D.BEC(R4)    ;CHECK IF ANY TRACKS/GROUPS
98 011476 001421      BEQ      6#           ;BRANCH IF NONE
99 011500 012701 000004      MOV      #4,R1      ;COUNT OF CYLINDER WORDS
100 011504 010402      MOV      R4,R2
101 011506 062702 000154      ADD      #D.BCYL,R2
102 011512 012223      MOV      (R2),R3     ;CYLINDERS
103 011514 005301      DEC      R1
104 011516 001375      BNE      4#
105 011520 012701 000010      MOV      #8,R1
106 011524 010402      MOV      R4,R2
107 011526 062702 000112      ADD      #D.BEC,R2
108 011532 012223      MOV      (R2),R3     ;TRACKS/GROUPS
109 011534 005301      DEC      R1
110 011536 001375      BNE      5#
111 011540 000427      BR       DMRQ4X
112          ;
113          ; RETURN CYLINDERS ONLY
114          ;

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 109-2  
 GLOBAL SUBROUTINES SECTION

```

115 011542 052763 000040 177774 68:   BIS      @D.BE,-4(R3)           ;SET D.BE FOR DM PROGRAM
116 011550 005023                CLR      (R3)+                 ;SEND ZERO BEGIN/END COUNT
117 011552 012701 000004                MOV      @4,R1
118 011556 010402                MOV      R4,R2
119 011560 062702 000154                ADD      @D.BCYL,R2
120 011564 012223                78:    MOV      (R2)+,(R3)+       ;CYLINDERS
121 011566 005301                DEC      R1
122 011570 001375                BNE     78
123 011572 000412                BR      DMRQ4X
124
125                ;
126                ;   RETURN ENTIRE AREA
127                ;
128
129 011574 052763 000040 177774 88:   BIS      @D.BE,-4(R3)           ;SET D.BE FOR DM PROGRAM
130 011602 005023                CLR      (R3)+                 ;BEGIN/END COUNT OF ZERO
131 011604 005023                CLR      (R3)+                 ;START CYLINDER OF ZERO
132 011606 005023                CLR      (R3)+
133 011610 005023                CLR      (R3)+                 ;END CYLINDER NEGATIVE
134 011612 012723 177777                MOV      @-1,(R3)+
135 011616 000264                SEZ
136 011620 000207                DMRQ4X: RETURN

```

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23 011622 011401
24 011624 004737 013224
25 011630 001007
26 011632 062704 000010
27 011636 012701 000035
28 011642 012423
29 011644 005301
30 011646 001375
31 011650 000207

;DMRQ5 - DM REQUEST 5
;
;REQUEST FOR FIRST 14 BAD BLOCKS
;
;INPUTS:
;   R5 - CONTROLLER TABLE ADDRESS
;   R4 - MESSAGE DATA ADDRESS
;       (R4) DRIVE NUMBER
;   R3 - COMMAND DATA ADDRESS
;
;OUTPUTS:
;   COMMAND DATA FILLED WITH BAD BLOCKS
;   (R3) COUNT OF BAD BLOCKS
;   2.(R3) BAD BLOCK 1 (LOW)
;   4.(R3)                (HIGH)
;
;   :
;   :
;   56.(R3) BAD BLOCK 14 (LOW)
;   58.(R3)                (HIGH)
;
;   Z SET IF DATA RETURNED
;   Z CLEAR IF DRIVE NUMBER NOT ON THIS CONTROLLER
;
DMRQ5:  MOV     (R4),R1           ;GET DRIVE NUMBER
        C/LL   GDRVT           ;GET DRIVE TABLE ADDRESS
        BNE   DMRQ5E          ;CHECK IF DRIVE FOUND
        ADD   #D.BB,R4        ;INCREASE ADDRESS TO DATA TO COPY
        MOV   #<1+<14,+2>>,R1 ;GET COUNT OF WORDS
14:    MOV   (R4)+,(R3)+      ;COPY THE WORDS
        DEC   R1
        BNE  14
DMRQ5E: RETURN

```

CZUDIA0 UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 111  
 GLOBAL SUBROUTINES SECTION

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16 011652 011401
17 011654 004737 013224
18 011660 001007
19 011662 062704 000102
20 011666 012701 000004
21 011672 012423
22 011674 005301
23 011676 001375
24 011700 000207

;DMRQ6 - DM REQUEST 6
;
;REQUEST LAST TWO BAD BLOCKS
;
;INPUTS:
; R5 - CONTROLLER TABLE ADDRESS
; R4 - MESSAGE DATA ADDRESS
; (R4) DRIVE NUMBER
; R3 - COMMAND DATA ADDRESS
;OUTPUTS:
; COMMAND DATA FILLED WITH BAD BLOCKS 15 AND 16
; Z SET IF DATA RETURNED
; Z CLEAR IF UNIT NUMBER NOT ON THIS CONTROLLER

DMRQ6:  MOV    (R4),R1          ;GET DRIVE NUMBER
        CALL  GDRVT          ;GET DRIVE TABLE ADDRESS
        BNE  DMRQ6E         ;CHECK IF DRIVE FOUND
        ADD  #D.BB15,R4      ;INCREASE ADDRESS TO DATA TO COPY
        MOV  #4,R1          ;GET COUNT OF WORDS
1$:     MOV  (R4)+,(R3)+     ;COPY THE WORDS
        DEC  R1
        BNE  1$
DMRQ6E: RETURN

```

```

1
2
3
4
14
15
16
17
18
19
20
21
22
23
24
25
26 011702 012401
27 011704 010402
28 011706 004737 013224
29 011712 001007
30 011714 062264 000172
31 011720 062264 000176
32 011724 062264 000206
33 011730 000264
34 011732 000207

: **
:
: DMRQ7 - DM REQUEST 7
:
: CZUDIO - ADD TO SOFT ERROR AND ECC COUNTS
:
: INPUTS:
: R5 - CONTROLLER TABLE ADDRESS
: R4 - MESSAGE DATA ADDRESS
: (R4) DRIVE NUMBER
: 2.(R4) VALUE TO ADD TO SOFT ERROR COUNT
: 4.(R4) VALUE TO ADD TO ECC COUNT
: 6.(R4) VALUE TO ADD TO SEEK ERROR COUNT
: R3 - COMMAND DATA ADDRESS
: --
DMRQ7: MOV (R4)+,R1 ;GET DRIVE NUMBER
MOV R4,R2 ;SAVE DATA ADDRESS
CALL GTDRVT ;GET DRIVE TABLE ADDRESS
BNE 1$ ;CHECK IF DRIVE FOUND
ADD (R2)+,D.SERR(R4) ;ADD TO SOFT ERROR COUNT
ADD (R2)+,D.ECCC(R4) ;ADD TO ECC COUNT
ADD (R2)+,D.SKER(R4) ;ADD TO SEEK ERROR COUNT
SEZ ;EXIT
1$: RETURN
    
```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 113  
 GLOBAL SUBROUTINES SECTION

```

1
2
3      ;**
4      ;   DMRQ8 - DM REQUEST 8.
5      ;
6      ;   RECORD 1000 SEEKS COMPLETED ON DRIVE
7      ;
8      ;   INPUTS:
9      ;           R5 - CONTROLLER TABLE ADDRESS
10     ;           R4 - MESSAGE DATA ADDRESS
11     ;           (R4) DRIVE NUMBER
12     ;           R3 - COMMAND DATA ADDRESS
13     ;--
14 011734 011401      DMRQ8:  MOV   (R4),R1      ; GET DRIVE NUMBER
15 011736 004737 013224  CALL  GTDRVT      ; GET DRIVE TABLE ADDRESS
16 011742 001003      BNE   SEKERE      ; CHECK IF DRIVE FOUND
17 011744 005264 000174  INC   D.SEEK(R4)  ; COUNT THE BITS TRANSFERRED
18 011750 000264      SEZ
19 011752 000207      SEKERE: RETURN      ; NORMAL RETURN

```

CZUDIA0 UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 114  
GLOBAL SUBROUTINES SECTION

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19 011754 010402
20 011756 011401
21 011760 004737 013224
22 011764 001053
23 011766 005764 000002
24 011772 100003
25 011774
26 011774 052713 100000
27 012000 000444
28 012002
29 012002 066264 000002 000166
30 012010 066264 000004 000164
31 012016 005737 002142
32 012022 001433
33 012024 026437 000166 002142
34 012032 103427
35 012034
   012034 104421
36 012036 032700 000040
37 012042 001023
38 012044 052713 100000
39 012050 042765 000010 000012
40 012056
41 012076 004737 016236
42 012102
43 012112 000264
44 012114 000207

;DMRQ9 - DM REQUEST 9.
;
;RECORD 1M BITS TRANSFERRED ON UNIT. COMPARE TO TRANSFER LIMIT AND
;REPORT LIMIT REACHED.
;
;INPUTS:
;   R5 - CONTROLLER TABLE ADDRESS
;   R4 - MESSAGE DATA ADDRESS
;       (R4) DRIVE NUMBER
;       2.(R4) VALUE TO ADD TO READ COUNT
;       4.(R4) VALUE TO ADD TO WRITE COUNT
;   R3 - COMMAND DATA ADDRESS
;
;OUTPUTS:
;   (R3) BIT 15 SET IF TRANSFER LIMIT REACHED
;   MESSAGE PRINTED IF TRANSFER LIMIT REACHED
;   Z CLEAR IF DRIVE NUMBER NOT ON THIS CONTROLLER

DMRQ9:  MOV     R4,R2           ;GET MESSAGE DATA ADDRESS
        MOV     (R4),R1       ;GET DRIVE NUMBER
        CALL    GDRVT        ;GET DRIVE TABLE ADDRESS
        BNE     MXFERE       ;CHECK IF DRIVE FOUND
        TST     D.UNIT(R4)   ;SEE IF UNIT HAS BEEN DROPPED
        BPL     1$          ;CONTINUE IF STILL TO BE TESTED
                               ASSUME DT.AVL EQ BIT15
        BIS     @BIT15,(R3)  ;TELL DM PROGRAM TO STOP TESTING THIS UNIT!
        BR      MXFERX      ; AND EXIT WITHOUT ADDING TO ADDING TO COUNTS

1$:     ADD     2(R2),D.XFRR(R4) ;ADD MEGABITS READ
        ADD     4(R2),D.XFRW(R4) ;ADD MEGABITS WRITTEN
        TST     SFPTBL+SO,XL  ;SEE IF LIMIT SPECIFIED
        BEQ     MXFERX       ;BRANCH IF NOT
        CMP     D.XFRR(R4),SFPTBL+SO,XL ;CHECK IF LIMIT REACHED
        BLO     MXFERX       ;BRANCH IF LIMIT NOT REACHED
        RFLAGS R0           ;CHECK FLAGS
        TRAP   C@RFLA
        BIT     @IDU,R0      ;SEE IF DROPPING UNITS IS INHIBITED
        BNE     MXFERX
        BIS     @BIT15,(R3)  ;SET DROP UNIT BIT
        BIC     @CT.MSG,C.FLG(R5) ;CLEAR MESSAGE RECEIVED FLAG
        PNTX   MESSG,D.UNIT(R4),(R5),(R4) ;PRINT TESTING DONE
        CALL   RNTIME       ;PRINT RUNTIME
        PNTX   MXFERP
MXFERX: SEZ
MXFERE: RETURN
;NORMAL RETURN

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 115  
GLOBAL SUBROUTINES SECTION

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18 012116 010504
19 012120 062704 000016
20 012124 012702 000004
21 012130 012400
22 012132 001415
23 012134 005760 000002
24 012140 100410
25 012142
26 012142 011023
28 012144 062700 000164
29 012150 012701 000016
30 012154 005020
31 012156 005301
32 012160 001375
34 012162 005302
35 012164 001361
36 012166 012723 100000
37 012172 000264
38 012174 000207

;DMRQA - DM REQUEST 10
;
; TELL DM PROGRAM WHICH DRIVES ARE SELECTED FOR TESTING
; AND CLEAR STATISTICS IN DRIVE TABLE
;
; INPUTS:
; R5 - CONTROLLER TABLE ADDRESS
; R4 - MESSAGE DATA ADDRESS
; (NO DATA)
; R3 - COMMAND DATA ADDRESS
; OUTPUTS:
; COMMAND PACKET CONTAINING UP TO 4 DRIVE NUMBERS.
; LIST IS ENDED BY A WORD WITH BIT 15 SET.
; D.XFRW, D.XFRR, D.HERR, D.SERR, D.SEEK AND D.ECC CLEARED
; Z SET

DMRQA: MOV R5,R4 ;GET ADDRESS OF CONTROLLER TABLE
ADD #C.DRU,R4 ;BUMP TO DRIVE TABLE POINTERS
MOV #4.,R2 ;GET COUNT OF PORTS
UTOT1: MOV (R4)+,R0 ;SEE IF DRIVE TABLE POINTER EXISTS
BEQ UTOT2 ;BRANCH IF NOT
TST D.UNIT(R0) ;LOOK IF UNIT AVAILABLE FOR TESTING
BMI UTOT1A
MOV (R0),(R3)+ ;LOAD DRIVE NUMBER FROM TABLE
ADD #D.XFRW,R0 ;CLEAR STATISTICS IN DRIVE TABLE
MOV #<D.SIZE-D.XFRW>/2,R1
1$: CLR (R0)+
DEC R1
BNE 1$
UTOT1A: DEC R2 ; COUNT THE DRIVE TABLES
BNE UTOT1 ; REPEAT FOR EACH TABLE
UTOT2: MOV #BIT15,(R3)+ ; TERMINATE LIST
SEZ ;
RETURN ; RETURN WITH Z SET

```



```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26 012176
27
28
29
30
31
32
33
34
35
36
37
38 012176 005764 000002
39 012202 100406
40 012204
    012204 104421
41 012206 032700 000040
42 012212 001014
43 012214 052713 100000
44 012220 016400 000002
45 012224 005100
46 012226 032700 140000
47 012232 001004
48 012234 032737 000400 002144
49 012242 001055
50 012244
51 012244 042765 000010 000012
53 012252 032737 001000 002144
54 012260 001005
56 012262 004737 014232
57 012266 103043
58 012270
    ;DMRQB - DM REQUEST 11
    ;PRINT AN ERROR MESSAGE
    ;INPUTS:
    ; R5 - CONTROLLER TABLE ADDRESS
    ; R4 - MESSAGE DATA ADDRESS
    ; (R4) ERROR PC IN DM PROGRAM
    ; 2.(R4) <15:14> ERROR TYPE
    ; <13:0 > ERROR NUMBER
    ; 4.(R4) DRIVE NUMBER (-1 IF NOT GIVEN)
    ; 6.(R4) MESSAGE POINTER
    ; 8.(R4) OPTIONAL PARAMETERS FOR ERROR PRINT ROUTINE
    ; 10.(R4) "
    ; "
    ; "
    ; 58.(R4) "
    ; R3 - COMMAND DATA ADDRESS
    ;OUTPUTS:
    ; COMMAND PACKET CONTAINING THE FOLLOWING:
    ; (R3) - BIT 15 SET IF FATAL ERROR TO INDICATE DRIVE SHOULD
    ; NO LONGER BE TESTED
    ; Z SET TO INDICATE DATA RETURNED
    ; Z CLEAR IF DRIVE NUMBER NOT ON THIS CONTROLLER
    DMRQB:
    ;; PUSH R4 ; SAVE R4
    ;; MOV 4(R4),R1 ; R1 = DRIVE #
    ;; BMI 1# ; IF -1, THEN NO DRIVE # GIVEN
    ;; CALL GDRVT ; GET DRIVE TABLE ADDRESS
    ;; TST D.UNIT(R4) ; IF DRIVE HAS BEEN DROPPED, EXIT
    ;; BGE 1# ; NEGATIVE VALUE MEANS DRIVE DROPPED
    ;; POP R4 ;
    ;; BIS #BIT15,(R3) ; SET DROP DRIVE BIT
    ;; BR 8# ; EXIT
    ;; 1#: POP R4 ;RESTORE R4
    ;;
    ;; TST 2(R4) ;CHECK IF FATAL ERROR
    ;; BHI 5# ;BRANCH IF NOT
    ;; RFLAGS R0 ;LOOK AT FLAGS
    ;; TRAP C#RFLA
    ;; BIT #IDU,R0 ;SEE IF ALLOWED TO DROP UNITS
    ;; BNE 6# ;BRANCH IF NOT
    ;; BIS #BIT15,(R3) ;SET DROP DRIVE BIT
    ;; 5#: MOV 2(R4),R0 ;SEE IF SOFT ERROR
    ;; COM R0
    ;; BIT #140000,R0
    ;; BNE 6# ;BRANCH IF NOT
    ;; BIT #SM.SSF,SO.BIT+SFPTBL ;SEE IF SOFT ERRORS SUPPRESSED
    ;; BNE ERRMSX ;DON'T PRINT IF SO
    ;; 6#: BIC #CT.MSG,C.FLG(R5) ;CLEAR MESSAGE RECEIVED FLAG
    ;; BIT #SM.LOG,SFPTBL+SO.BIT ; SEE IF LOG BEING USED
    ;; BNE ERRMSL ; IF SO, LOG IT ELSE
    ;; CALL PNERR ; PRINT ERROR MESSAGE
    ;; 8#: BCC ERRMSX ; IF DRIVE HASN'T BEEN DROPPED, PRINT
    
```

C2  
PR



```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30 012402
31 012404 004737 012176
32 012410
33 012412 005713
34 012414 100445
35 012416 016401 000004
36 012422 016402 000002
37 012426 004737 013224
38 012432 001040
39 012434 042702 037777
40 012440 022702 100000
41 012444 001031
42 012446 005264 000170
43 012452 026437 000170 002140
44 012460 103423
45 012462
   012462 104421
46 012464 032700 000040
47 012470 001017
48 012472 005764 000002
49 012476 100003
50 012500 052713 100000
51 012504 000411
52 012506
53 012506
54 012522 052713 100000
55
56 012526

```

```

;DMRQC - DM REQUEST 12.
;
;REPORT AN ERROR MESSAGE IDENTICAL TO DM REQUEST DMRQB
;THEN ADD ONE TO THE ERROR COUNT FOR THE DRIVE AND SEE IF
;ERROR LIMIT REACHED.
;
;INPUTS:
;   R5 - CONTROLLER TABLE ADDRESS
;   R4 - MESSAGE DATA ADDRESS
;       (R4) ERROR PC IN DM PROGRAM
;       2.(R4) < 9:8 > ERROR TYPE
;           < 7:0 > ERROR NUMBER
;       4.(R4) DRIVE NUMBER (-1 IF NOT GIVEN)
;       6.(R4) <15:12> TYPE
;           <11:0 > MESSAGE POINTER
;       8.(R4) OPTIONAL PARAMETERS FOR ERROR PRINT ROUTINE
;       10.(R4)
;           "
;           "
;           "
;       38.(R4)
;           "
;
;   R3 - COMMAND DATA ADDRESS
;
;OUTPUTS:
;   COMMAND PACKET CONTAINING THE FOLLOWING:
;   (R3) BIT 15 SET IF ERROR COUNT REACHED
;       TO INDICATE DRIVE SHOULD NO LONGER BE TESTED.
;   Z CLEAR IF DRIVE NUMBER NOT ON THIS CONTROLLER
;   Z SET TO INDICATE DATA RETURNED
;
DMRQC:  PUSH    R4
        CALL   DMRQB           ; CALL REQUEST DMRQB
        POP    R4
        TST    (R3)           ; SEE IF UNIT ALREADY TO BE DROPPED
        BMI    38             ; IF SO, JUST EXIT NOW
        MOV    4(R4),R1       ; GET DRIVE NUMBER
        MOV    2(R4),R2       ; GET ERROR TYPE
        CALL   GDRVT         ; GET DRIVE TABLE
        BNE    38             ; EXIT IF NO TABLE FOR UNIT
        BIC    @C140000,R2    ; CHECK IF HARD ERROR
        CMP    @100000,R2     ; BRANCH IF NOT
        BNE    38
        INC    D,HERR(R4)     ; COUNT THE ERROR
        CMP    D,HERR(R4),SFPTBL*SO,EL ; CHECK IF AT LIMIT
        BLO    38             ; IF LIMIT REACHED, BRANCH
        RFLAGS RO           ; LOOK AT THE FLAGS
        TRAP  C,RFLA
        BIT    @IDU,RO        ; SEE IF DROPPING UNITS INHIBITED
        BNE    38             ; BRANCH IF SO
        TST    D,UNIT(R4)     ; ALL READY BEEN DROPPED?
        BPL    28             ; IF SO, DO NOT PRINT LINE
        BIS    @BIT15,(R3)    ; SET STOP TESTING BIT
        BR    38
26:    PNTX    ERRLIM,D,UNIT(R4) ; PRINT LIMIT REACHED
        BIS    @BIT15,(R3)    ; SET STOP TESTING BIT
        DORPT                    ; PRINT A STATISTICAL REPORT

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 117-1  
GLOBAL SUBROUTINES SECTION

	012526	104424		TRAP	C:DRPT	
57						
58	012530	000264	34:	SEZ		; SET Z FOR NORMAL RETURN
59	012532	000207		RETURN		; RETURN TO CALLING PROGRAM
60						
61	012534	000244	54:	CLZ		; FLAG AS ERROR
62	012536	000207		RETURN		; RETURN TO CALLING PROGRAM

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 118  
GLOBAL SUBROUTINES SECTION

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19 012540 042765 000010 000012 DMRQD: BIC      #CT.MSG,C.FLG(R5)      ;CLEAR MESSAGE RECEIVED FLAG
20 012546 012401                MOV      (R4),R1          ;GET DRIVE NUMBER
21 012550                PUSH     R4              ;SAVE DATA POINTER
22 012552 004737 013224        CALL     GTDRVT         ;GET DRIVE TABLE ADDRESS
23 012556 001033                BNE     1$             ;CHECK IF DRIVE FOUND
24 012560 005764 000002        TST     D.UNIT(R4)     ;IF UNIT DROPPED FROM TESTING
25 012564 100430                BMI     1$             ; DON'T PRINT ANYTHING
26 012566                PNTX    MESSG,D.UNIT(R4),(R5),(R4); PRINT HEADER
27 012606 004737 016236        CALL     RNTIME        ; GET RUNTIME PARAMETERS
28 012612                POP     R4             ; RESTORE MESSAGE POINTER
29 012614 012402                MOV     (R4),R2        ;GET MESSAGE POINTER
30 012616 006302                ASL     R2             ;DOUBLE TO MAKE BYTE OFFSET
31 012620 063702 002176        ADD     DMPROG,R2     ;ADD TO START OF MESSAGE STRINGS
32 012624 067702 167346        ADD     SDMPROG,R2    ;ADD SIZE OF MAIN PROGRAM
33 012630 105712                TSTB   (R2)           ;CHECK FIRST BYTE
34 012632 001001                BNE     2$             ;IF ZERO
35 012634 005202                INC     R2             ; INCREMENT TO NEXT BYTE
36 012636 004737 007676        2$:    CALL     OSTRNG    ;OUTPUT ACCORDING TO STRING
37 012642 000264                SEZ
38 012644 000207                RETURN
39 012646                1$:    POP     R4
40 012650 000207                RETURN

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 119  
GLOBAL SUBROUTINES SECTION

```
1
2
3
4
5
6
7
8
9
10
11
12
13
14 012652 000244
15 012654 000207

;DMRQE - DM REQUEST 14
;
;MARK DM PROGRAM AS NO LONGER RUNNING
;
;INPUTS:
; R5 - CONTROLLER TABLE ADDRESS
; R4 - MESSAGE DATA ADDRESS
; (NO DATA)
; R3 - COMMAND DATA ADDRESS
;OUTPUTS:
; Z CLEAR TO DROP UNIT FROM TESTING

DMRQE: CLZ ;DROP UNIT FROM TESTING
RETURN
```

```

1
2
3
4
5
6
7
8
9 012656
10 012660 012402
11 012662 006302
12 012664 063702 002176
13 012670 067702 167302
14 012674 004737 007676
15 012700
16 012702 000207
17
18
19
20
21
22
23
24 012704
25 012706 012402
26 012710
27 012712 042702 177400
28 012716 001414
29 012720 012700 000020
30 012724 012701 000040
31 012730 004737 013400
32 012734
33 012744 005302
34 012746 001364
35 012750
36 012752 000301
37 012754 042701 177400
38 012760 001406
39 012762 004737 007772
40 012766
41 012776
42 013000 000207
43
44
45
46
47
48
49
50
51
52
53
54
55
56 013002 032724 000200
57 013006 001323

```

```

.SBTTL PRE-PROGRAMMED SUBROUTINES

; **
; CALR1 - PRE-PROGRAMMED PRINT ROUTINE 1
;
; CALL ALTERNATE PRINT STRING IN DM PROGRAM IMAGE
; --

CALR1:  PUSH    R2
        MOV     (R4)+,R2      ;GET NEW STRING POINTER
        ASL    R2             ;DOUBLE FOR WORD COUNT
        ADD    DMPROG,R2     ;ADD START OF STRING STORAGE
        ADD    SDMPROG,R2    ;ADD SIZE OF MAIN PROGRAM
        CALL   OSTRING       ;OUTPUT USING THIS STRING
        POP    R2            ;GET OLD POINTER BACK
        RETURN               ;NOW CONTINUE THE OLD STRING

; **
; CALR2 - PRE-PROGRAMMED PRINT ROUTINE 2
;
; PRINT AN SDI DIAGNOSE RESPONSE
; --

CALR2:  PUSH    R2
        MOV     (R4)+,R2      ;GET COUNTS
        PUSH   R2            ;SAVE COUNTS
        BIC    #177400,R2    ;GET BINARY COUNT
        BEQ    2$,           ;BYPASS BINARY IF COUNT IS ZERO
        MOV    #16.,R0       ;RADIX IS HEX
        MOV    #32.,R1       ;32 BIT NUMBERS
        CALL   PNTNUS        ;PRINT THE NUMBER
        PRINT  #CR           ;GO TO NEW LINE
        DEC    R2
        BNE   1$,
        POP    R1
        SWAB  R1             ;GET ASCII COUNT
        BIC    #177400,R1    ;BYPASS IS COUNT IS ZERO
        BEQ    3$,           ;BYPASS IS COUNT IS ZERO
        CALL   CON.A1        ;PRINT THE ASCII
        PRINT  #CR           ;GO TO NEW LINE
        POP    R2
        RETURN

; **
; CALR3 - PRE-PROGRAMMED PRINT ROUTINE 3
;
; DECIDE WHETHER TO PRINT RBN
;
; FOUR PARAMETERS ARE PROVIDED FOR THIS ROUTINE. THE FIRST PARAMETER
; SHOULD BE CHECKED TO SEE IF BIT 7 IS SET:
; IF SET - TURN INTO A CALL TO ROUTINE 1 (WHICH WILL USE OTHER 3
; PARAMETERS).
; IF CLEAR - SKIP OVER NEXT 3 PARAMETERS AND END ROUTINE
; --

CALR3:  BIT     #BIT7,(R4)+    ;CHECK BIT 7 IN FIRST PARAMETER WORD
        BNE   CALR1          ;IF SET, TURN INTO A CALR1

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 120-1  
 PRE-PROGRAMMED SUBROUTINES

```

58 013010 062704 000006          ADD    #6,R4          ;ELSE, SKIP OVER NEXT 3 PARAMETERS
59 013014 000207          RETURN
60
61          ;**
62          ; CALR4 - PRE-PROGRAMMED PRINT ROUTINE 4
63          ;
64          ; PRINT BASIC LINE FOR HOST PROGRAM ERROR WITHOUT CONTROLLER ADDRESS
65          ; THEN SWITCH TO EXTENDED FORMAT
66          ;--
67
68 013016          CALR4: PNTB    BASLN,#BASNO,#BAS,#BAS,#BAS
69 013046 004737 016236          CALL    RNTIME
70 013052          PRINT   #CR
71 013062 012737 007522 002342          MOV    #PX,PTYPE
72 013070 000207          RETURN
73
74          ;**
75          ; CALR5 - PRE-PROGRAMMED PRINT ROUTINE 5
76          ;
77          ; PRINT BASIC LINE FOR HOST PROGRAM ERROR WITH CONTROLLER ADDRESS
78          ; THEN SWITCH TO EXTENDED FORMAT
79          ;--
80
81 013072          CALR5: PNTB    BASLN,#BASNO,#BASL2,(R5),#BAS,#BAS
82 013124 004737 016236          CALL    RNTIME
83 013130          PRINT   #CR
84 013140 012737 007522 002342          MOV    #PX,PTYPE
85 013146 000207          RETURN
86
87          ;**
88          ; CALR6 - PRE-PROGRAMMED PRINT ROUTINE 6
89          ;
90          ; CALL ALTERNATE PRINT ROUTINE IN PDP-11 MEMORY
91          ;--
92
93 013150          CALR6: PUSH    R2
94 013152 012402          MOV    (R4),R2          ;GET NEW STRING POINTER
95 013154 004737 007676          CALL    OSTRNG          ;OUTPUT USING THIS STRING
96 013160          POP     R2
97 013162 000207          RETURN          ;NOW CONTINUE THE OLD STRING
98
99          ;**
100          ; CALR7 - PRE-PROGRAMMED PRINT ROUTINE 7
101          ;
102          ; PRINT "REPLACE CONTROLLER PROCESSOR MODULE"
103          ;--
104
105 013164          CALR7: PUSH    R2
106 013166 012702 006471          MOV    #XFRU,R2
107 013172 004737 007676          CALL    OSTRNG
108 013176          POP     R2
109 013200 000207          RETURN
110
111          ;**
112          ; CALR8 - PRE-PROGRAMMED PRINT ROUTINE 8
113          ;
114          ; PRINT " SA REGISTER CONTAINS XXXXXX"

```



CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 120-2  
PRE-PROGRAMMED SUBROUTINES

```
115
116
117 013202
118 013204 012702 006434
119 013210 004737 007676
120 013214
121 013216 000207
122
123
124
125
126
127
128
129
130 013220 005744
131 013222 000207
132
```

```

:--
CALR8:  PUSH   R2
        MOV    @XSA,R2
        CALL  OSTRNG
        POP   R2
        RETURN

:++
:      CALR9 - PRE-PROGRAMMED PRINT ROUTINE 9
:
:      REPRINT LAST NUMBER
:              R4 -> TABLE
:--

CALR9:  TST    -(R4)
        RETURN
```

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14 013224
15 013226 010504
16 013230 062704 000016
17 013234 012702 000004
18 013240 005714
19 013242 001406
20 013244 027401 000000
21 013250 001412
22 013252 005724
23 013254 005302
24 013256 001370
25 013260
    013260 104455
    013262 000043
    013264 000000
    013266 006710
26 013270
27 013272 000244
28 013274 000207
29
30 013276 011404
31 013300 116437 000002 002074
32 013306
33 013310 000264
34 013312 000207

;GTDRVT
;
;GET DRIVE TABLE POINTER
;
;INPUTS:
;   R5 - CONTROLLER TABLE ADDRESS
;   R1 - DRIVE NUMBER
;OUTPUTS:
;   R4 - DRIVE TABLE ADDRESS
;   L#LUN - LOADED WITH UNIT NUMBER OF DRIVE
;   Z CLEAR IF DRIVE TABLE NOT FOUND AFTER ERROR PRINTED

GTDRVT: PUSH    R2
        MOV     R5,R4
        ADD     @C.DRO,R4
        MOV     @4.,R2
10:     TST     (R4)
        BEQ     30
        CMP     @R4,R1
        BEQ     40
20:     TST     (R4)+
        DEC     R2
        BNE     10
30:     ERDF   35,ERR035
        TRAP   C#ERDF
        .WORD  35
        .WORD  0
        .WORD  ERR035
        POP     R2
        CLZ
        RETURN
;GET CONTROLLER TABLE ADDRESS
;ADD OFFSET TO DRIVE TABLE ADDRESS
;GET COUNT OF DRIVES
;CHECK IF AN ADDRESS HERE
;COMPARE DRIVE NUMBERS
;BRANCH IF A MATCH
;BUMP ADDRESS
;LOOK AT ALL OF THEM
;UNIT NUMBER NOT FOUND
;CLEAR Z AS ERROR FLAG

40:     MOV     (R4),R4
        MOVB   D.UNIT(R4),L#LUN
        POP     R2
        SEZ
        RETURN
;GET ADDRESS OF TABLE
;GET UNIT NUMBER
;SET Z FLAG

```

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14 013314
15 013316 005001
16 013320 121227 000060
17 013324 103415
18 013326 121227 000071
19 013332 101012
20 013334 006301
21 013336 010100
22 013340 006301
23 013342 006301
24 013344 060001
25 013346 112200
26 013350 162700 000060
27 013354 060001
28 013356 000760
29 013360 005701
30 013362 001001
31 013364 005201
32 013366
33 013370 000207

;GETCNT
;
;GET COUNT IN NEXT CHARACTERS OF STRING POINTED TO BY R2.
;NUMBER WILL BE IN DECIMAL. IF NO NUMBER, RETURN A
;DEFAULT OF 1.
;
;INPUTS:
; R2 - POINTER TO ASCII STRING
;OUTPUTS:
; R1 - NUMBER READ OR A ONE
; R2 - POINTING TO CHARACTER AFTER NUMBER

GETCNT: PUSH R0
        CLR R1
        ;START WITH ZERO COUNT
GETCNX: CMPB (R2),#'0
        BLO GETCDN
        ;CHECK IF CHARACTER A DIGIT
        ;BRANCH IF LOWER THAN ZERO
        CMPB (R2),#'9
        BHI GETCDN
        ;BRANCH IF HIGHER THAN NINE
        ASL R1
        ;MULTIPLY NUMBER BY 10
        MOV R1,R0
        ;SAVE 2N
        ASL R1
        ;COMPUTE 4N
        ASL R1
        ;COMPUTE 8N
        ADD R0,R1
        ;8N + 2N = 10N
        MOVB (R2)+,R0
        ;GET DIGIT FROM STING
        SUB #'0,R0
        ;GET RID OF ASCII
        ADD R0,R1
        ;ADD TO NUMBER
        BR GETCNX
        ;GO TO NEXT CHARACTER
GETCDN: TST R1
        BNE GETCXX
        ;CHECK IF NUMBER IS ZERO
        ;IF ZERO, CHANGE
        ; TO DEFAULT OF ONE
GETCXX: POP R0
        RETURN

```

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15 013372 010100
16 013374 004737 013314
17 013400
18 013406 012403
19 013410 005005
20 013412 020127 000020
21 013416 003401
22 013420 012405
23 013422
24 013424 010504
25 013426 012702 000020
26 013432 160102
27 013434 002002
28 013436 062702 000020
29 013442 001414
30 013444 012705 100000
31 013450 005302
32 013452 001402
33 013454 006205
34 013456 000774
35 013460 020127 000020
36 013464 003402
37 013466 040504
38 013470 000401
39 013472 040503
40 013474 004737 013634
41 013500
42 013502 005202
43 013504 005703
44 013506 001372
45 013510 005704
46 013512 001370
47 013514 020027 000012
48 013520 001423
49 013522 010103
50 013524 162700 000014
51 013530 003002
52 013532 012700 000003
53 013536 004737 013634
54 013542 005705
55 013544 001401
56 013546 005203
57 013550 160203

;PNTNUM
;
;PRINT A NUMBER
;
;INPUTS:
; R1 - RADIX OF NUMBER
; R2 - ASCII STRING TO COUNT OF BITS IN NUMBER
; R4 - POINTER TO NUMBER (LOW WORD)
;
;OUTPUTS:
; NUMBER IS PRINTED. LEADING ZEROS ARE PRINTED EXCEPT FOR
; DECIMAL NUMBERS (LEFT JUSTIFIED).
;
; R0 - CONTENTS DESTROYED

PNTNUM: MOV R1,R0 ; SAVE RADIX
CALL GETCNT ; GET COUNT OF BITS
PNTNUM: PUSH <R2,R3,R5> ; SAVE REGISTERS ON STACK
MOV (R4)+,R3 ; GET ONE PARAMETER WORD
CLR R5 ; CLEAR STORAGE FOR OTHER
CMP R1,#16 ; MORE THAN 16 BITS IN NUMBER?
BLE 1# ; NO, SKIP
MOV (R4)+,R5 ; YES, GET SECOND PARAMETER WORD
1#: PUSH R4 ; SAVE R4 ON STACK
MOV R5,R4 ; PUT LOW WORD IN R4
MOV #16.,R2 ; COMPUTE BITS NOT WANTED
SUB R1,R2 ; BY SUBTRACTING BITS TO USE
BGE 2# ; FROM 16.
ADD #16.,R2 ; IF NEGATIVE, ADD 16 FOR FIRST WORD
2#: BEQ 6# ; IF ZERO, NO BITS NEED BE CLEARED
MOV #BIT15,R5 ; START MASK WITH SIGN BIT SET
3#: DEC R2 ; COUNT BITS IN MASK
BEQ 4# ;
ASR R5 ; SHIFT MORE BITS TO RIGHT
BR 3# ;
4#: CMP R1,#16. ; MORE THAN 16 BITS IN NUMBER?
BLE 5# ;
BIC R5,R4 ; YES, CLEAR IN HIGH WORD
BR 6# ;
5#: BIC R5,R3 ; NO, CLEAR IN LOW WORD
6#: CALL DIVIDE ; DIVIDE BY RADIX IN R0
PUSH R5 ; PUSH REMAINDER ON STACK
INC R2 ; COUNT DIGITS ON STACK
TST R3 ; CHECK IF QUOTIENT IS ZERO
BNE 6# ;
TST R4 ;
BNE 6# ;
CMP R0,#10. ; IF RADIX IS DECIMAL
BEQ 10# ; JUST GO PRINT DIGITS ON STACK
MOV R1,R3 ; OTHERWISE COMPUTE NUMBER OF LEADING 0
SUB #12.,R0 ; DIVIDEND IS BITS IN NUMBER
BGT 7# ; DIVISOR IS BITS PER DIGIT PRINTED
MOV #3,R0 ; (3 OR 4)
7#: CALL DIVIDE ;
TST R5 ; IF REMAINDER NOT ZERO
BEQ 8# ; INCREMENT QUOTIENT
INC R3 ;
8#: SUB R2,R3 ; SUBTRACT DIGITS ON STACK

```

58	013552	001406		BEG	10\$		:	NO LEADING ZEROS IF ZERO
59	013554		9\$:	PRINT	#'0		:	
60	013554	005303		DEC	R3		:	
61	013566	001372		BNE	9\$		:	REPEAT UNTIL COUNT REACHES ZERO
62	013570		10\$:	POP	R5		:	GET CHARACTER FROM STACK
63	013572	062705	000050	ADD	#'0,R5		:	CONVERT TO ASCII DIGIT
64	013576	020527	000071	CMP	R5,#'9		:	IF GREATER THAN A 9
65	013602	003402		BLE	11\$		:	CONVERT TO A OR HIGHER
66	013604	062705	000007	ADD	#<'A-'9-1>,R5		:	FOR HEX DIGIT
67	013610		11\$:	PRINT	R5		:	
68	013616	005302		DEC	R2		:	REPEAT FOR ALL DIGITS
69	013620	001363		BNE	10\$		:	ON STACK
70	013622			POP	<R4,R5,R3,R2>		:	
71	013632	000207		RETURN			:	
72							:	

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17 013634
18 013636 012702 000040
19 013642 005005
20 013644 006303
21 013646 006104
22 013650 006105
23 013652 020005
24 013654 101002
25 013656 160005
26 013660 005203
27 013662 005302
28 013664 001367
29 013666
30 013670 000207

;DIVIDE
;
;DIVIDE A 32 BIT UNSIGNED NUMBER BY A 16 BIT UNSIGNED NUMBER.
;REPLACE DIVIDEND WITH QUOTIENT AND RETURN REMAINDER.
;WILL NOT CHECK FOR DIVIDE BY ZERO.
;
;INPUTS:
; R3 - LOW 16 BITS OF DIVIDEND
; R4 - HIGH 16 BITS OF DIVIDEND
; R0 - DIVISOR
;OUTPUTS:
; R3 - LOW 16 BITS OF QUOTIENT
; R4 - HIGH 16 BITS OF QUOTIENT
; R5 - REMAINDER

DIVIDE: PUSH R2
MOV #32.,R2 ;SET UP SHIFT COUNT
CLR R5 ;START WITH ZERO REMAINDER
1$: ASL R3 ;SHIFT LEFT INTO R5
ROL R4
ROL R5
CMP R0,R5 ;WILL DIVISOR GO INTO REMAINDER
BHI 2$ ;ONLY SUBTRACT IF IT WILL
SUB R0,R5 ;SUBTRACT DIVISOR
INC R3 ;PUT A ONE INTO QUOTIENT
2$: DEC R2 ;COUNT THE SHIFTS
BNE 1$
POP R2
RETURN

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 125  
 PRE-PROGRAMMED SUBROUTINES

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20 013672
21 013674 012700 000100
22 013700 005005
23 013702 006301
24 013704 006102
25 013706 006103
26 013710 006104
27 013712 006105
28 013714 022705 000012
29 013720 101003
30 013722 162705 000012
31 013726 005201
32 013730 005300
33 013732 001363
34 013734
35 013736 000207
36

;DIV10
;
;DIVIDE A 64 BIT UNSIGNED NUMBER BY A 10.
;REPLACE DIVIDEND WITH QUOTIENT AND RETURN REMAINDER.
;WILL NOT CHECK FOR DIVIDE BY ZERO.
;
;INPUTS:
;   R1 - LOW 16 BITS OF DIVIDEND
;   R2 - NEXT 16 BITS OF DIVIDEND
;   R3 - NEXT 16 BITS OF DIVIDEND
;   R4 - HIGH 16 BITS OF DIVIDEND
;
;OUTPUTS:
;   R1 - QUOTIENT,
;   R2 - QUOTIENT,
;   R3 - QUOTIENT,
;   R4 - QUOTIENT,
;   R5 - REMAINDER
;
DIV10:  PUSH    R0
        MOV     #64.,R0
        CLR    R5
14:     ASL     R1
        ROL    R2
        ROL    R3
        ROL    R4
        ROL    R5
        CMP    #10.,R5
        BHI    24
        SUB    #10.,R5
        INC    R1
24:     DEC    R0
        BNE    14
        POP    R0
        RETURN

;DIVIDEND IS IN <R4,R3,R2,R1>
;SET UP SHIFT COUNT
;START WITH ZERO REMAINDER

;SHIFT LEFT INTO R5

;WILL DIVISOR GO INTO REMAINDER?
;ONLY SUBTRACT IF IT WILL
;SUBTRACT DIVISOR
;PUT A ONE INTO QUOTIENT
;COUNT THE SHIFTS

;RETURN WITH QUOTIENT IN
; <R4,R3,R2,R1> AND REMAINDER IN R5

```

```

1
2
3
4
5
6
7
8 013740
9 013752 011403
10 013754 016404 000002
11 013760 012700 000012
12 013764 005001
13 013766 004737 013634
14 013772 062705 000060
15 013776
16 014000 005201
17 014002 010305
18 014004 050405
19 014006 001367
20 014010 012700 002214
21 014014
22 014016 110520
23 014020 005301
24 014022 001374
25 014024 105020
26 014026
27 014040 000207

;BUILD DEFAULT 28-BIT NUMBER
;
;INPUT:
; R4 - POINTER TO 2 WORD DEFAULT NUMBER
;OUTPUT:
; TEMP - ASCIZ STRING REPRESENTING DEFAULT NUMBER

BLD28: PUSH <R0,R1,R3,R4,R5>
      MOV (R4),R3 ;GET NUMBER
      MOV 2(R4),R4
      MOV #10.,R0 ;DIVISOR IS 10.
      CLR R1 ;CLEAR CHARACTER COUNT
14:   CALL DIVIDE
      ADD #0,R5 ;CONVERT REMAINDER TO ASCII CHARACTER
      PUSH R5 ;STORE ON STACK
      INC R1 ;COUNT THE CHARACTER
      MOV R3,R5 ;REPEAT UNTIL QUOTIENT IS ZERO
      BIS R4,R5
      BNE 14
24:   MOV #TEMP,R0 ;GET POINTER TO STRING
      POP R5 ;PUT CHARACTERS INTO STRING
      MOVB R5,(R0)
      DEC R1
      BNE 24
      CLRB (R0) ;END WITH NULL
      POP <R5,R4,R3,R1,R0>
      RETURN

```



CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 127  
PRE-PROGRAMMED SUBROUTINES

```

1      ;CONVERT ASCIZ STRING TO 28-BIT NUMBER
2      ;
3      ;INPUTS:
4      ;   TEMP - ASCIZ STRING UP TO 9 CHARACTERS LONG
5      ;   R4 - ADDRESS OF TWO WORD STORAGE
6      ;OUTPUTS:
7      ;   IF STRING IS VALID NUMBER
8      ;   TWO WORDS AT R4 LOADED WITH NUMBER
9      ;   R4 POINTING TO WORD AFTER STORAGE
10     ;   CARRY CLEAR
11     ;   IF STRING INVALID
12     ;   ERROR MESSAGE PRINTED
13     ;   CARRY SET
14
15 014042 CNV28: PUSH <R0,R1,R2,R3>
16 014052    CLR R0                                ;START WITH ZEROS
17 014054    CLR R1
18 014056    MOV #TEMP,R2                          ;GET ADDRESS OF STRING
19 014062    1$: MOVB (R2)+,R3                       ;GET A DIGIT FROM STRING
20 014064    BEQ 3$                                  ;IF NULL CHARACTER, ALL DONE
21 014066    SUB #'0,R3                             ;SUBTRACT CHARACTER 0
22 014072    BMI 2$
23 014074    CMP #'9.,R3
24 014100    BLO 2$
25 014102    ASL R0
26 014104    ROL R1
27 014106    PUSH <R1,R0>
28 014112    ASL R0
29 014114    ROL R1
30 014116    ASL R0
31 014120    ROL R1
32 014122    ADD (SP)+,R0
33 014124    ADC R1
34 014126    ADD (SP)+,R1
35 014130    ADD R3,R0
36 014132    ADC R1
37 014134    BIT #170000,R1
38 014140    BEQ 1$
39 014142    PRINTF #INP28A
40     014142    012746    025557    MOV #INP28A,-(SP)
41     014146    012746    000001    MOV #1,-(SP)
42     014152    010600    MOV SP,R0
43     014154    104417    TRAP C#PNTF
44     014156    062706    000004    ADD #4,SP
45 014162    SEC
46 014164    BR 4$
47     2$: PRINTF #INP28B
48     014166    012746    025621    MOV #INP28B,-(SP)
49     014172    012746    000001    MOV #1,-(SP)
50     014176    010600    MOV SP,R0
51     014200    104417    TRAP C#PNTF
52     014202    062706    000004    ADD #4,SP
53 014206    SEC
54 014210    BR 4$
55 014212    010024    3$: MOV R0,(R4)+

```

;MOVE NUMBER TO STORAGE AREA

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 127-1  
PRE-PROGRAMMED SUBROUTINES

48 014214 010124  
49 014216 000241  
50 014220  
51 014230 000207  
150

48: MOV R1,(R4)  
CLC  
POP <R3,R2,R1,R0>  
RETURN

;CLEAR CARRY TO INDICATE ALL IS WELL

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14 014232          PNTERR: PUSH    <R0,R1,R2>      ; SAVE REGISTERS ON STACK
15 014240 005764 000004  TST      4(R4)          ; CHECK IF BIT 15 SET
16 014244 002004          BGE      1$              ; IF SO, GET UNIT FROM MESSAGE DATA
17 014246 116537 000002 002074  MOVB    C.UNIT(R5),L$LUN ; ELSE, GET UNIT FROM CONTROLLER TABLE
18 014254 000417          BR      2$              ;
19 014256          1$:  PUSH    R4              ; SAVE DATA ADDRESS
20 014260 016401 000004  MOV      4(R4),R1        ; GET DRIVE NUMBER
21 014264 004737 013224  CALL    GDRVT           ; GET DRIVE TABLE ADDRESS
22 014270 001037          BNE      5$              ; IF UNIT DROPPED, EXIT
23 014272 005764 000002  TST      D.UNIT(R4)     ; IS TESTING DONE ON UNIT?
24 014276 100005          BPL      3$              ; IF NOT DONE, PROCEED
25 014300 052713 100000  BIS      @BIT15,(R3)    ; MARK UNIT AS DONE TESTING
26 014304          DORPT  C$DRPT          ; PRINT A STATISTICAL REPORT
    014304 104424          TRAP    C$DRPT
27 014306          POP      R4              ; RESTORE DATA ADDRESS
28 014310 000423          BR      4$              ;
29
30 014312          3$:  POP      R4              ; RESTORE DATA ADDRESS
31 014314 012702 002146  2$:  MOV      @ERRTYP,R2    ; GET POINTER TO ERROR TABLE
32 014320 016412 000002  MOV      2(R4),(R2)     ; GET ERROR TYPE
33 014324 006112          ROL      (R2)           ;
34 014326 006112          ROL      (R2)           ;
35 014330 006112          ROL      (R2)           ;
36 014332 042722 177774  BIC      @C3,(R2)       ; CLEAR LOW 2 BITS
37 014336 016412 000002  MOV      2(R4),(R2)     ;
38 014342 042722 140000  BIC      @140000,(R2)   ; MASK LOW 14 BITS
39 014346 005022          CLR      (R2)          ; CLEAR MESSAGE POINTER
40 014350 012712 007160  MOV      @ERR.TN,(R2)   ; GET ROUTINE NUMBER
41 014354          ERROR  TRAP    C$ERROR          ; PRINT THE ERROR MESSAGE
    014354 104460          TRAP    C$ERROR
42 014356 000241          CLC              ; DRIVE HAS NOT BEEN DROPPED
43 014360          4$:  POP      <R2,R1,R0>     ; RESTORE REGISTERS
44 014366 000207          RETURN          ;
45 014370          5$:  POP      <R4>          ; RESTORE STACK
46 014372 000261          SEC              ; DRIVE HAS BEEN DROPPED
47 014374 000771          BR      4$              ;
48
    
```

```

1
2
3      ;**
4      ;   LOADDM - LOAD AND START A DM PROGRAM IN A CONTROLLER
5      ;
6      ;   INPUTS:
7      ;           R5 - CONTROLLER TABLE ADDRESS
8      ;   IMPLICIT INPUTS:
9      ;           DMPROG - POINTER TO START OF DM PROGRAM IN MEMORY
10     ;
11     ;   OUTPUTS:
12     ;           IF LOAD SUCCEEDS - Z CLEAR
13     ;                   CONTROLLER TABLE MARKED LOADED
14     ;           IF ERROR - Z SET
15     ;
16     ;---
17
18     LOADDM:
19
20     MOV     C.VEC(R5),R4           ; GET VECTOR OF CONTROLLER
21     BIC     #C<CT.VEC>,R4         ; CLEAR ALL BUT VECTOR
22     MOV     R5,R1                 ; GET INTERRUPT SERVICE LINK
23     ADD     #C.JSR,R1             ;
24     SETVEC R4,R1,#PRI07          ; SET UP INTERRUPT VECTOR
25     MOV     #PRI07,-(SP)
26     MOV     R1,-(SP)
27     MOV     R4,-(SP)
28     MOV     #3,-(SP)
29     TRAP   C#SVEC
30     ADD     #10,SP
31     ASR     R4                     ; INITIALIZE CONTROLLER WITH SMALLEST
32     ASR     R4                     ;     POSITION VECTOR FOR RING
33     CALL   CNTINT                 ;     BUFFER AND INTERRUPTS ENABLED
34     BEQ    LOADER                 ; IF ERROR, EXIT
35     CALL   HCONM                  ; ALLOCATE SPACE FOR HOST COMM AREA
36
37     LOADTX: MOV     #DMPROG,R1     ; GET SIZE OF PROGRAM
38     LOADB: MOV     #OP.ESP,R0     ; BUILD EXECUTE SUPPLIED
39     CALL   BLDCHD                 ;     PROGRAM COMMAND PACKET
40     MOV     DMPROG,HC.CPK+P.UADR(R4); LOAD MAIN PROGRAM ADDRESS
41     MOV     R1,HC.CPK+P.BCNT(R4)  ;     AND SIZE
42     MOV     DMPROG,HC.CPK+P.OVRL(R4); LOAD OVERLAY ADDRESS
43     ADD     #DMPROG,HC.CPK+P.OVRL(R4)
44     CALL   SNOCHD                 ; SEND COMMAND TO CONTROLLER
45     CALL   WAITMS                 ; WAIT FOR MESSAGE RESPONSE
46     BEQ    LOADER                 ; EXIT IF ERROR
47     BIT     #ST.MSK,HC.MPK+P.STS(R4); CHECK FOR ERRORS
48     BNE    LOADE1                 ;
49     BIC     #CT.CMD+CT.REQ,C.FLG(R5); CLEAR COMMAND OUTSTANDING FLAG
50     BIS     #CT.RN,C.FLG(R5)     ; SET DM PROGRAM RUNNING FLAG
51
52     RETURN                         ; SUCCESS RETURN
53
54     ;
55     ;   CONTROLLER FAILED TO DOWNLINE LOAD DM PROGRAM
56     ;
57
58     LOADE1: ERRDF 33,,ERR033      ;
59     TRAP   C#ERDF
60     .WORD 33
61     .WORD 0
62     .WORD ERR033

```

92 014566 000264  
93 014570 000207  
94

LOADER: SEZ  
RETURN

; SET 7 TO INDICATE ERROR OCCURRED  
; ERROR RETURN

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17 014572
18 014576 016504 000014
19 014602 010400
20 014604 062700 000014
21 014610 012720 000060
22 014614 012701 001000
23 014620 022716 000031
24 014624 001403
25 014626 022716 000030
26 014632 001002
27 014634 012701 177777
28 014640 010120
29 014642 012701 000030
30 014646 005020
31 014650 005301
32 014652 001375
33 014654
34 014660
35 014662 000207
36

```

```

: **
:
: BLDCMD - BUILD A COMMAND IN COMMAND PACKET
:
: INPUTS:
: R5 - CONTROLLER TABLE ADDRESS
: R0 - COMMAND CODE
:
: OUTPUTS:
: R4 - ADDRESS OF HOST COMM AREA
: COMMAND PACKET CONTAINING REF NUMBER AND OPCODE. ALL
: OTHER FIELDS CLEARED.
: COMMAND REFERENCE NUMBER IN CONTROLLER TABLE INCREMENTED
: AND RESULT IN COMMAND PACKET.
: R0 - CONTENTS DESTROYED
: --

```

```

BLDCMD: PUSH <R1,R0> ; SAVE REGISTERS ON STACK
MOV C.HCOM(R5),R4 ; GET ADDRESS OF HOST COMM AREA
MOV R4,R0 ; COPY TO R0
ADD #HC.CEV,R0 ; COMPUTE ADDRESS OF COMMAND ENVELOPE
MOV #HC.PSZ,(R0)+ ; LOAD PACKET LENGTH
MOV #DUP,R1 ; LOAD DUP CIRCUIT IDENTIFIER
CMP #OP.MWR,(SP) ; IF CODE IS MAINTENANCE WRITE
BEQ 1$ ; USE DIAGNOSTIC CIRCUIT ID
CMP #OP.MRD,(SP) ; IF CODE IS NOT MAINTENANCE READ
BNE BLDC0 ; SKIP
1$: MOV #DIAG,R1 ; ELSE, USE DIAGNOSTIC CIRCUIT ID
BLDC0: MOV R1,(R0)+ ; PUT IDENTIFIER INTO PACKET
MOV #<HC.PSZ>/2,R1 ; GET WORDS TO CLEAR
BLDC1: CLR (R0)+ ; CLEAR PACKET
DEC R1 ; ANY MORE
BNE BLDC1 ; WORDS TO CLEAR?
POP HC.CPK+P.OPCD(R4) ; PUT OPCODE IN PACKET
POP R1 ; RESTORE R1
RETURN

```

```

1
2
3      ;**
4      ;   SNDCMD - SEND A COMMAND TO THE CONTROLLER. CLEAR THE RESPONSE
5      ;   PACKET. MARK BOTH PACKETS AVAILABLE TO THE CONTROLLER. SET COMMAND
6      ;   ISSUED BIT IN CONTROLLER TABLE AND INITIALIZE TIMEOUT COUNTER.
7      ;
8      ;   INPUTS:
9      ;           R5 - CONTROLLER TABLE ADDRESS
10     ;
11     ;   OUTPUTS:
12     ;           R4 - ADDRESS OF HOST COMM AREA
13     ;---
13 014664 016504 000014      SNDCMD: MOV      C.HCOM(R5),R4          ; LOAD R4 WITH HOST COMM AREA ADDRESS
14 014670 005265 000032      INC      C.REF(R5)          ; INCREMENT CMD REFERENCE NUMBER
15 014674 016564 000032 000020  MOV      C.REF(R5),HC.CPK+P.CRF(R4); PUT IN PACKET
16 014702 012764 140000 000006  MOV      @RG.OWN+RG.FLG,HC.MCT(R4); MARK MESSAGE PACKET AVAILABLE
17 014710 012764 100000 000012  MOV      @RG.OWN,HC.CCT(R4)    ; MARK COMMAND TO CONTROLLER
18 014716 005775 000000      TST      @B(R5)              ; TELL CONTROLLER COMMAND IS THERE
19 014722 052765 000004 000012  BIS      @CT.CMD,C.FLG(R5)    ; MARK COMMAND ISSUED
20 014730 000207
21

```

```

1
2
3      : **
4      : CLRBUF - CLEAR THE SPECIFIED DATA BUFFER IN THE HOST COMM AREA
5      : AND LOAD BUFFER DESCRIPTOR IN COMMAND PACKET TO THE BUFFER
6      :
7      : INPUTS:
8      : R5 - CONTROLLER TABLE ADDRESS
9      : R4 - ADDRESS OF HOST COMM AREA
10     : R0 - OFFSET INTO HOST COMM AREA TO DATA BUFFER
11     :
12     : OUTPUTS:
13     : DATA BUFFER CLEARED
14     : COMMAND PACKET POINTING TO BUFFER
15     : BYTE COUNT SET TO SIZE OF BUFFER
16     : R4 - ADDRESS OF DATA BUFFER
17     : --
18
17 014732 CLRBUF: PUSH    <R0,R1>          ; SAVE REGISTERS ON STACK
18 014736 060400 ADD      R4,R0          ; CREATE BUFFER ADDRESS
19 014740 010064 000040 MOV      R0,HC.CPK+P.UADR(R4) ; PUT BUFFER ADDRESS IN COMMAND PACKET
20 014744 012764 000106 000034 MOV      @HC.BSZ,HC.CPK+P.BCNT(R4); PUT SIZE OF BUFFER IN COMMAND PACKET
21 014752 010004 MOV      R0,R4          ; PUT BUFFER ADDRESS IN R4
22 014754 012701 000043 MOV      @<HC.BSZ>/2,R1     ; GET SIZE OF BUFFER IN WORDS
23 014760 005020 CLRBFL: CLR    (R0)+      ; CLEAR ALL THE WORDS
24 014762 005301 DEC      R1          ; ANY MORE
25 014764 001375 BNE     CLRBFL         ; WORDS TO CLEAR?
26 014766 POP      <R1,R0>      ;
27 014772 000207 RETURN          ;
28

```



```

1
2
3      ;**
4      ;
5      ;
6      ;
7      ;
8      ;
9      ;
10     ;--
11
12 014774      WAITMS: PUSH      <R0,R1>      ; SAVE REGISTERS ON STACK
13 015000      MOV          #30.,R0        ; SET TIME OUT VALUE OF 30 SECONDS
14 015004      MOV          R5,R1         ; POINT TO TIME OUT COUNTER
15 015006      MOV          #C.TO,R1      ; POINTER TO TIMER FIELD
16 015012      MOV          004737 015210  CALL      SETTO          ; START TIMER
17 015016      MOV          011500      1#:  MOV      (R5),R0        ; GET ADDRESS OF IP REGISTER
18 015020      MOV          032765 000010 000012  BIT      #CT.MSG,C.FLG(R5)    ; LOOK IF INTERRUPT OCCURRED
19 015026      MOV          001025      BNE      3#          ; BRANCH IF SO
20 015030      MOV          016001 000002      MOV      2(R0),R1      ; LOOK AT SA REGISTER
21 015034      MOV          001031      BNE      4#          ; BRANCH IF ERROR CODE PRESENT
22 015036      MOV          104422      BREAK     ; >>>>>>BREAK BACK TO MONITOR<<<<<<<
23 015040      MOV          005737 002320      TRAP     C#BRK        ; SEE IF A CLOCK ON SYSTEM
24 015044      MOV          001764      TST      KW.CSR        ; IF NOT, DON'T TIMEOUT
25 015046      MOV          023765 002332 000030  BEQ      1#          ; CHECK HIGH WORD OF INTERVAL
26 015054      MOV          101005      BHI      2#          ; IF GREATER, TIMED OUT
27 015056      MOV          001357      BNE      1#          ; IF NOT EQUAL, NO TIMEOUT OCCURRED
28 015060      MOV          023765 002330 000026  CMP      KW.EL,C.TO(R5)  ; CHECK LOW WORD OF INTERVAL
29 015066      MOV          103753      BLO      1#          ; IF LOWER, NO TIMEOUT OCCURRED
30 015070      MOV          104455      2#:  ERDF     36.,ERR036    ; PRINT TIMEOUT ERROR
31 015072      MOV          000044      TRAP     C#ERDF
32 015074      MOV          000000      .WORD   36
33 015076      MOV          006726      .WORD   0
34 015100      MOV          000416      .WORD   ERR036
35 015102      MOV          042765 000010 000012  3#:  BIC      #CT.MSG,C.FLG(R5)  ; ERROR EXIT
36 015110      MOV          000244      POP      <R1,R0>      ; CLEAR MESSAGE RECEIVED FLAG
37 015114      MOV          000207      CLZ          ; SAVE REGISTERS ON STACK
38 015120      MOV          010102      4#:  PUSH     R2          ; GIVE NO ERROR RETURN
39 015122      MOV          010102      MOV      R1,R2      ; SAVE R2
40 015124      MOV          010102      ERDF     40.,ERR040    ; GET SA REGISTER CONTENTS
41 015126      MOV          000050      TRAP     C#ERDF      ; CONTROLLER DETECTED ERROR
42 015130      MOV          000000      .WORD   40
43 015132      MOV          006752      .WORD   0
44 015134      MOV          000264      .WORD   ERR040
45 015142      MOV          000207      POP      R2          ; RESTORE REGISTERS
46 015144      MOV          000207      POP      <R1,R0>      ; RESTORE REGISTERS
47 015144      MOV          000207      SEZ          ; Z SET OR ERROR RETURN
48 015144      MOV          000207      RETURN     ;
49
50
51
52
53

```

```

1
2
3      ;**
4      ;   NXMI - NON-EXISTANT MEMORY SERVICE ROUTINE
5      ;
6      ;   INPUTS:
7      ;           NXMAD SET TO ZERO
8      ;   OUTPUTS:
9      ;           NXMAD SET TO ONES IF NON-EXISTANT TRAP OCCURED
10     ;---
11     015146      BGNSRV  NXMI
12     015146      NXMI::
13     015146 012737 177777 002340      MOV      @-1,NXMAD
14     015154      ENDSRV
15     015154      L10020:
16     015154 000002      RTI
17
18     ;**
19     ;   CNTSRV - CONTROLLER INTERRUPT SERVICE ROUTINE. MARKS CONTROLLER TABLE
20     ;   THAT AN INTERRUPT HAS BEEN RECEIVED.
21     ;
22     ;   THIS ROUTINE IS CALLED BY A [JSR RO,CNTSRV] INSTRUCTION FROM WITHIN
23     ;   THE CONTROLLER TABLE. THE PC STORED IN RO IS THE ADDRESS OF THE C.FLG
24     ;   WORD IN THE CONTROLLER TABLE. THE STACK CONTAINS THE SAVED CONTENTS
25     ;   OF RO FOLLOWED BY THE INTERRUPTED PC AND PS.
26     ;
27     ;   INPUTS:
28     ;           RO - ADDRESS OF C.FLG WORD IN CONTROLLER TABLE
29     ;           STACK - SAVED CONTENTS OF RO
30     ;   OUTPUTS:
31     ;           CT.MSG SET IN C.FLG WORD OF CONTROLLER TABLE
32     ;           RO - RESTORED FROM STACK
33     ;---
34     015156      BGNSRV  CNTSRV
35     015156      CNTSRV::
36     015156 052710 000010      BIS      #CT.MSG,(RO)      ; SET CT.MSG
37     015162      POP      RO      ; RESTORE RO
38     015164      ENDSRV
39     015164      L10021:
40     015164 000002      RTI
41
42     ;**
43     ;   KW11I - CLOCK INTERRUPT SERVICE ROUTINE
44     ;
45     ;---
46     015166      BGNSRV  KW11I
47     015166      KW11I::
48     015166 062737 000001 002330      ADD      #1,KW.EL      ; COUNT THE INTERRUPT
49     015174 005537 002332      ADC      KW.EL+2      ; PUT CARRY IN HIGH WORD
50     015200 012777 000105 165112      MOV      @KW.OUT,@KW.CSR      ; RESTART THE CLOCK
51     015206      ENDSRV
52     015206      L10022:
53     015206 000002      RTI
54
55

```

```

1
2
3      ;**
4      ;   SETTO - SET TIMEOUT COUNTER TO A GIVEN NUMBER OF SECONDS FROM CURRENT
5      ;   TIME.
6      ;
7      ;   INPUTS:
8      ;       R0 - NUMBER OF SECONDS FOR TIMEOUT
9      ;       R1 - ADDRESS WHERE TWO WORD TIME TO BE PUT
10     ;
11     ;   OUTPUTS:
12     ;       R0 - CONTENTS DESTROYED
13     ;       R1 - INCREMENTED BY 2
14     ;--
15     SETTO:  PUSH    <R2,R3>
16             CLR     R2                ; CLEAR PRODUCT
17             MOV     KW.HZ,R3         ; GET MULTIPLICAND
18
19     SET00:  ASR     R0                ; SHIFT MULTIPLIER TO RIGHT
20             BCC    SET01            ; IF A ONE BIT SHIFTED OUT
21             ADD    R3,R2            ; ADD MULTIPLICAND TO PRODUCT
22
23     SET01:  ASL     R3                ; DOUBLE THE MULTIPLICAND
24             TST    R0                ;
25             BNE    SET00            ; CONTINUE UNTIL MULTIPLIER IS ZERO
26
27     ;
28     ;   GET CURRENT TIME
29
30     SET02:  MOV     KW.EL,R0          ; GET TIME (LOW WORD)
31             MOV     KW.EL+2,R3      ; GET TIME (HIGH WORD)
32             CMP    R0,KW.EL        ; IF CHANGED DURING RETRIEVAL
33             BNE    SET02            ; GET IT AGAIN
34
35     ;
36     ;   ADD TIME TIL TIMEOUT
37
38     ADD     R2,R0                    ; ADD TIMEOUT TO CURRENT TIME
39     ADC     R3                       ; INCREMENT HIGH WORD IF CARRY
40
41     ;
42     ;   PUT RESULT IN STORAGE
43
44     ;
45     MOV     R0,(R1)+                ; SAVE LOW WORD OF TIMEOUT
46     MOV     R3,(R1)                ; SAVE HIGH WORD OF TIMEOUT
47
48     POP    <R3,R2>
49     RETURN
50

```



CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 136-1  
PRE-PROGRAMMED SUBROUTINES

112	015360	006003		ROR	R3		; RIGHT
113	015362	006003		ROR	R3		; JUSTIFY
114	015364	006003		ROR	R3		; MODEL
115	015366	006003		ROR	R3		; NUMBER
116	015370	042703	177760	BIC	#C<SA.CNT/16.>,R3		; R3 = CONTROLLER MODEL NUMBER
117	015374	022703	000006	CMF	#6.,R3		; CHECK IF UDA50A
118	015400	001413		BEQ	24:		; IF SO, BRANCH
119	015402	022703	000015	CMF	#13.,R3		; CHECK IF KDA50-Q
120	015406	001420		BEQ	25:		; IF SO BRANCH
121	015410	052765	100000 000002	BIS	#BIT15,C.UNIT(R5)		; ELSE MARK AS DO NOT EXECUTE
122	015416			ERRDF	14,,ERR014		; REPORT ERROR
	015416	104455		TRAP	CERRDF		
	015420	000016		.WORD	14		
	015422	000000		.WORD	0		
	015424	006620		.WORD	ERR014		
123	015426	000422		BR	9:		; EXIT
124	015430						
126	015430	020127	000003	CMF	R1,#3.		; UDA50A MICROCODE VERSION UP TO DATE?
127	015434	002014		BGE	26:		; IF SO, BRANCH
128	015436			ERRSF	14,,ERR014		; ELSE, REPORT ERROR
	015436	104454		TRAP	CERRSF		
	015440	000016		.WORD	14		
	015442	000000		.WORD	0		
	015444	006620		.WORD	ERR014		
129	015446	000407		BR	26:		
130	015450						
132	015450	020127	000000	CMF	R1,#0.		; KDA50-Q MICROCODE VERSION UP TO DATE?
133	015454	002004		BGE	26:		; IF SO, BRANCH
134	015456			ERRSF	14,,ERR014		; ELSE, REPORT ERROR
	015456	104454		TRAP	CERRSF		
	015460	000016		.WORD	14		
	015462	000000		.WORD	0		
	015464	006620		.WORD	ERR014		
135	015466			POP	<R3>		; RESTORE R3 FROM STACK
136	015470	000244		CLZ			; CLEAR Z TO INDICATE NO ERROR
137	015472	000207		RETURN			
138							
139							
140							
141							
142							
143	015474						
144	015476	000264		POP	<R3>		; RESTORE R3 FROM STACK
145	015500	000207		SEZ			; SET Z TO INDICATE ERROR OCCURRED
146				RETURN			



```

45 015642 012703 002346      MOV      #INITBL,R3      ; GET INDEX TO SEND/REPOOND INIT TABLE
46
47      ;
48      ;      WAIT FOR AND CHECK RESPONSE DATA
49      ;
50
51 015646 004737 015776      24:     CALL      CNTRSP      ; WAIT FOR STEP OR ERROR BITS
52 015652 103414              BCS      44           ; EXIT IF ERROR
53 015654 004733              CALL     @R3)+       ; CALL RESPONSE CHECKER FOR STEP
54 015656 103412              BCS      44           ; GET OUT IF ERROR
55 015660 006337 002364      ASL      CNTRSD      ; SHIFT TO NEXT STEP BIT
56 015664 032737 040000 002364  BIT      @SA.S4,CNTRSD ; CHECK IF NOW AT STEP 4
57 015672 001003              BNE      34           ; GET OUT IF SO
58 015674 012364 000002      MOV      (R3)+,2(R4)  ; WRITE DATA TO SA REGISTER
59 015700 000762              BR       24           ; STAY IN LOOP
60
61 015702 000241              34:     CLC              ; CLEAR CARRY FOR NO ERROR INDICATION
62 015704              44:     POP       R1       ; RESTORE R1
63 015706 000207              RETURN
64      ;
65      ;      RESPONSE CHECK FOR FIRST WORD (STEP 1) FROM SA REGISTER
66      ;      CHECK FOR PROPER CONTROLLER TYPE
67      ;
68 015710 012701 004400      RSP.S1: MOV      @SA.S1+SA.DI,R1  ; SET STEP ONE BIT
69 015714 042702 001140      BIC      @SA.QB+SA.MP+SA.SM,R2 ; CLEAR Q22 & SM BIT FOR KDA50-Q
70 015720 000416              BR       RSP.CK      ; NOW DO A RESPONSE CHECK
71      ;
72      ;      RESPONSE CHECK FOR SECOND WORD (STEP 2) FROM SA REGISTER
73      ;      CHECK FOR ECHO OF INTERRUPT ENABLE FLAG AND INTERRUPT VECTOR
74      ;
75 015722 013701 002350      RSP.S2: MOV      SMD.S1,R1      ; GET WORD SENT TO SA REGISTER
76 015726 000301              SWAB     R1           ; GET HIGH 8 BITS
77 015730 042701 177400      BIC      @177400,R1    ;
78 015734 052701 010000      BIS      @SA.S2,R1    ; SET STEP 2 BIT
79 015740 000406              BR       RSP.CK      ; NOW DO A RESPONSE CHECK
80      ;
81      ;      RESPONSE CHECK FOR THIRD WORD (STEP 3) FROM SA REGISTER
82      ;      CHECK FOR ECHO OF MESSAGE AND COMMAND RING LENGTHS
83      ;
84 015742 013701 002350      RSP.S3: MOV      SMD.S1,R1      ; GET WORD SENT TO SA REGISTER
85 015746 042701 177400      BIC      @177400,R1    ; JUST LOW 8 BITS
86 015752 052701 020000      BIS      @SA.S3,R1    ; SET STEP 3 BIT
87      ;
88      ;      RESPONSE CHECK, COMPARE EXPECTED DATA IN R1 WITH ACTUAL DATA IN R2
89      ;
90 015756 020102              RSP.CK: CMP      R1,R2      ; COMPARE THE DATA
91 015760 001405              BEQ      14           ; EXIT IF COMPARED CORRECTLY
95 015762              ERRDF   40,,ERR040   ; ERROR - WRONG DATA IN SA REGISTER
    015762 104455              TRAP    C#ERRDF
    015764 000050              .WORD   40
    015766 000000              .WORD   0
    015770 006752              .WORD   ERR040
97 015772 000261              SEC
98 015774 000207              14:     RETURN      ; SET CARRY TO INDICATE ERROR
99

```

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21 015776
22 016000 052737 100000 002364
23 016006 012700 000012
24 016012 010501
25 016014 062701 000026
26 016020 004737 015210
27 016024
28 016026 033764 002364 000002 1:
29 016034 001024
30 016036
    016036 104422
31 016040 005737 002320
32 016044 001770
33 016046 023765 002332 000030
34 016054 101005
35 016056 001363
36 016060 023765 002330 000026
37 016066 103757
38 016070 016402 000002 2:
42 016074
    016074 104455
    016076 000050
    016100 000000
    016102 006752
44 016104 000407
45
46
47
48 016106 016402 000002 3:
49 016112 100006
53 016114
    016114 104455
    016116 000050
    016120 000000
    016122 006752
55 016124 000261
56 016126 000207

: **
:
: CNTRSP
:
: WAIT FOR CONTROLLER TO RESPOND WITH DATA IN SA REGISTER.
: EITHER STEP BIT FROM MASK IN LOCATION CNTRSD OR ERROR BIT
: WILL CAUSE A TERMINATION.
: AN ERROR MESSAGE WILL BE PRINTED IF THE CONTROLLER DOES NOT RESPOND
: IN 10 SECONDS OR IF ERROR SETS.
:
: INPUTS:
: CNTRSD - MASK OF STEP BIT TO LOOK FOR
: R5 - ADDRESS OF CONTROLLER TABLE
: R4 - ADDRESS OF IP REGISTER
:
: OUTPUTS:
: ERROR MESSAGE IF TIME OUT ON RESPONSE OR ERROR BIT SETS
: R2 - DATA FROM SA REGISTER
: CARRY SET IF ERROR BIT SETS OR TIME OUT
:
: ---
CNTRSP: PUSH R1
BIS #SA.ERR,CNTRSD ; SET ERROR BIT IN MASK WORD
MOV #10,,R0 ; SET UP FOR 10 SECOND TIMEOUT
MOV R5,R1 ; POINT TO COUNTER IN CONTROLLER TABLE
ADD #C.TO,R1
CALL SETTO
POP R1
BIT CNTRSD,2(R4) ; LOOK AT ERROR AND STEP BIT
BNE 3: ; BRANCH IF EITHER SET
BREAK ; >>>>>>>BREAK BACK TO MONITOR<<<<<<<
TRAP C1BRK
TST KW.CSR ; SEE IF CLOCK ON SYSTEM
BEQ 1:
CMP KW.EL+2,C.TO(R5) ; CHECK IF TIME OUT OCCURRED
BHI 2:
BNE 1:
CMP KW.EL.C.TO(R5)
BLO 1:
MOV 2(R4),R2 ; GET REGISTER CONTENTS
ERRDF 40,,ERR040 ; REPORT TIME OUT ERROR
TRAP C1ERDF
.WORD 40
.WORD 0
.WORD ERR040
BR 4:

:
: CHECK IF ERROR BIT SET
:
3: MOV 2(R4),R2 ; GET REGISTER CONTENTS
BPL 5: ; EXIT IF ERROR NOT SET
ERRDF 40,,ERR040 ; REPORT ERROR INFO
TRAP C1ERDF
.WORD 40
.WORD 0
.WORD ERR040
4: SEC
RETURN
    
```



CZUDIAO UDASO-A/KDASO-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 138-1  
PRE-PROGRAMMED SUBROUTINES

```
57      ;  
58      ;      NORMAL EXIT  
59      ;  
60 016130 000241      5# :      CLC      ; CLEAR CARRY AS NO ERROR INDICATION  
61 016132 000207      ;      RETURN      ;
```

```

1
2
3
4
5
6
7
8
9
10
11
12 016134 005037 002340
13 016140
14 016144
    016144 012746 000340
    016150 012746 015146
    016154 012746 000004
    016160 012746 000003
    016164 104437
    016166 062706 000010
15 016172 012703 000004
16 016176 012704 002244
17 016202 005714
18 016204 001403
19 016206 005034
20 016210 005303
21 016212 001373
22 016214 005737 002320
23 016220 001403
24 016222 012777 000105 164070
25 016230
26 016234 000207
27

;RESET
;
; RESET ALL CONTROLLERS IN THE CONTROLLER TABLES
;
; INPUTS:
; IPADRS - CONTAINS ALL IP ADDRESSES
; OUTPUTS:
; NONE
;

RESET: CLR NXMAD ; CLEAR NON-EXISTANT MEMORY ADDRESS
        PUSH <R3,R4> ; SAVE R3 AND R4 ON STACK
        SETVEC @ERRVEC,@NXMI,@PRI07 ; SETUP TIMEOUT ERROR VECTOR
        MOV @PRI07,-(SP)
        MOV @NXMI,-(SP)
        MOV @ERRVEC,-(SP)
        MOV @3,-(SP)
        TRAP C+SVEC
        ADD @10,SP
        MOV @4,,R3 ; STORE MAXIMUM # OF CONTROLLERS IN R3
        MOV @IPADRS,R4 ; STORE IP ADDRESS IN R4
1$: TST (R4) ; IS THERE AN ENTRY?
    BEQ 2$ ; IF NOT, DONE
    CLR @R4) ; INIT CONTROLLER
    DEC R3 ; MAKE SURE WE DO NOT EXTEND OVER AREA
    BNE 1$ ; IF NOT DONE, BRANCH
2$: TST KW.CSR ; SEE IF CLOCK PRESENT,
    BEQ 3$ ; BRANCH IF NOT, ELSE
    MOV @KW.OUT,@KW.CSR ; START THE CLOCK.
3$: POP <R4,R3> ; RESTORE R3,R4 FROM STACK
    RETURN
    
```

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14 016236 005737 002320
15 016242 001465
16 016244
17 016254 013703 002330
18 016260 013704 002332
19 016264 013700 002326
20 016270 004737 013634
21 016274 012700 000074
22 016300 004737 013634
23 016304
24 016306 004737 013634
25 016312
26 016324 020527 000011
27 016330 003004
28 016332
29 016342
30 016354
31 016356 020527 000011
32 016362 003004
33 016364
34 016374
35 016406
36 016416
37 016426 000207
65

;RNTIME
;
;PRINT RUNTIME
;
;INPUTS:
;   KW.EL - CONTAINS ELAPSED TIME
;   KW.HZ - HERTZ OF CLOCK
;OUTPUTS:
;   IF CLOCK ON SYSTEM:
;       " RUN TIME HH:MM:SS " PRINTED
;   IF NO CLOCK: ONE SPACE IS PRINTED

RNTIME: TST     KW.CSR           ;CHECK IF A CLOCK PRESENT
        BEQ     RNTIMX          ;BRANCH IF NOT
        PUSH   <R0,R3,R4,R5>
        MOV    KW.EL,R3         ;GET ELAPSED TIME
        MOV    KW.EL*2,R4
        MOV    KW.HZ,R0        ;GET SPEED OF CLOCK
        CALL   DIVIDE          ;COMPUTE SECONDS OF ELAPSED TIME
        MOV    #60.,R0         ;NOW DIVIDE BY 60
        CALL   DIVIDE          ; TO COMPUTE MINUTES
        PUSH   R5              ;SAVE REMAINDER AS SECONDS
        CALL   DIVIDE          ;DIVIDE BY 60 AGAIN
        PNT    RNTIM,R3        ;PRINT HOURS
        CMP    R5,#9.          ;IF MINUTES 9 OR LESS
        BGT    1#             ;PRINT A LEADING ZERO
        PRINT  #'0             ;NOW PRINT MINUTES
        POP    R5              ;GET SECONDS
        CMP    R5,#9.          ;IF 9 OR LESS
        BGT    2#             ;PRINT A LEADING ZERO
        PRINT  #'0             ;NOW PRINT SECONDS
        POP    <R5,R4,R3,R0>   ;HOURS IN R3
        RNTIMX: PRINT <'>    ;PRINT A SPACE
        RETURN

```

1			.SBTTL	REPORT CODING SECTION	
2					
3			;	**	
4			;	THE REPORT CODING SECTION CONTAINS THE CODE FOR PRINTING	
5			;	STATISTICAL INFORMATION GATHERED BY THE DIAGNOSTIC. IT IS	
6			;	EXECUTED BY THE OPERATOR COMMAND "PRINT" OR BY THE MACRO CALL	
7			;	"DORPT".	
8			;		
9			;	--	
10	016430			BGNRPT	
	016430		L#RPT::		
11					
12	016430		PUSH	<R0,R1,R2,R3,R4,R5>	
13	016444		PNTS	RPTMSG,TNUM	; PRINT TEST NUMBER
14	016460	004737	CALL	RNTIME	; GET RUNTIME PARAMETERS
15	016464		PRINT	@CR	; END THE LINE
16	016474	012701	MOV	@STIME,R1	; GET REPORT TIMER
17	016500	012700	MOV	@15.*60.,R0	; GET REPORT INTERVAL
18	016504	004737	CALL	SETTO	; SET TIME FOR NEXT REPORT
19					
21	016510		1#:	PNTS	RPTMSH
22	016520	013705	MOV	CTABS,R5	;GET ADDRESS OF 1ST CONTROLLER TABLE
23					
24	016524	005765	RPTCT:	TST	C.UNIT(R5)
25	016530	100010		BPL	1#
26	016532			PRINTS	@RPTMS5
	016532	012746	MOV	@RPTMS5,-(SP)	; SEE IF CONTROLLER IS AVAILABLE
	016536	012746	MOV	@1,-(SP)	; IF SO, SKIP (BIT 15 = 0)
	016542	010600	MOV	SP,R0	
	016544	104416	TRAP	C#PNTS	
	016546	062706	ADD	@4,SP	
27	016552		1#:		
28	016552	010504	MOV	R5,R4	; GET ADDRESS OF CONTROLLER TABLE
29	016554	062704	ADD	@C.DR0,R4	; POINT TO DRIVE TABLE POINTERS
30	016560	012703	MOV	@4.,R3	; GET COUNT OF DRIVES
31	016564	012401	RPTDT:	MOV	(R4)+,R1
32	016566	001571		BEQ	RPTCTN
33	016570	005761		TST	D.UNIT(R1)
34	016574	100010		BPL	5#
35	016576				ASSUME DT.AVL EQ BIT15
36	016576			PRINTS	@RPTMS4
	016576	012746	MOV	@RPTMS4,-(SP)	
	016602	012746	MOV	@1,-(SP)	
	016606	010600	MOV	SP,R0	
	016610	104416	TRAP	C#PNTS	
	016612	062706	ADD	@4,SP	
37	016616		5#:		
38	016616			PUSH	<R3,R4,R5,R1>
39	016626	012700	MOV	@TEMP,R0	;PLACE 18 SPACE CHARACTERS INTO
40	016632	012701	MOV	@18.,R1	; TEMP STORAGE
41	016636	112720	1#:	MOVB	@',(R0)+
42	16642	005301		DEC	R1
43	016644	001374		BNE	1#
44	016646	005010		CLR	(R0)
45	016650	011605		MOV	(SP),R5
46	016652	016501		MOV	D.SERN(R5),R1
47	016656	016502		MOV	D.SERN+2(R5),R2

48	016662	016503	000204		MOV	D.SERN+4(R5),R3	
49	016665	005004			CLR	R4	
50	016670	004737	013672	2#:	CALL	DIV10	;DIVIDE BY 10
51	016674	062705	000060		ADD	#'0,R5	;CONVERT TO ASCII CHARACTER
52	016700	110540			MOVB	R5,-(R0)	;PUT DIGIT INTO TEMP STORAGE
53	016702	010146			MOV	R1,-(SP)	
54	016704	050216			BIS	R2,(SP)	;SEE IF QUOTIENT IS ZERO
55	016706	050316			BIS	R3,(SP)	
56	016710	050426			BIS	R4,(SP)+	
57	016712	001366			BNE	2#	;IF NOT, DIVIDE AGAIN
58	016714				POP	R1	
59	016716				PRINTS	#RPTMSD,D.UNIT(R1),(R1),#TEMP,D.SEEK(R1),D.XFRR(R1),D.XFRW(R1)	
	016716	016146	000164		MOV	D.XFRW(R1),-(SP)	
	016722	016146	000166		MOV	D.XFRR(R1),-(SP)	
	016726	016146	000174		MOV	D.SEEK(R1),-(SP)	
	016732	012746	002214		MOV	#TEMP,-(SP)	
	016736	011146			MOV	(R1),-(SP)	
	016740	016146	000002		MOV	D.UNIT(R1),-(SP)	
	016744	012746	017460		MOV	#RPTMSD,-(SP)	
	016750	012746	000007		MOV	#7,-(SP)	
	016754	010600			MOV	SP,R0	
	016756	104416			TRAP	C#PNTS	
	016760	062706	000020		ADD	#20,SP	
60	016764					ASSUME D.DRV EQ 0	
61	016764				PRINTS	#RPTMD2,D.HERR(R1),D.SERR(R1),D.ECCC(R1)	
	016764	016146	000176		MOV	D.ECCC(R1),-(SP)	
	016770	016146	000172		MOV	D.SERR(R1),-(SP)	
	016774	016146	000170		MOV	D.HERR(R1),-(SP)	
	017000	012746	017527		MOV	#RPTMD2,-(SP)	
	017004	012746	000004		MOV	#4,-(SP)	
	017010	010600			MOV	SP,R0	
	017012	104416			TRAP	C#PNTS	
	017014	062706	000012		ADD	#12,SP	
62	017020				PUSH	R1	
63	017022	016102	000212		MOV	D.HDAS+2(R1),R2	
64	017026	016103	000214		MOV	D.HDAS+4(R1),R3	
65	017032	016104	000216		MOV	D.HDAS+6(R1),R4	
66	017036	016101	000210		MOV	D.HDAS(R1),R1	
67	017042	012700	002214		MOV	#TEMP,R0	
68	017046	012705	000024		MOV	#20,R5	
69	017052	112720	000040	3#:	MOVB	#',(R0)+	
70	017056	005305			DEC	R5	
71	017060	001374			BNE	3#	
72	017062	005010			CLR	(R0)	
73	017064	004737	013672	4#:	CALL	DIV10	
74	017070	062705	000060		ADD	#'0,R5	
75	017074	110540			MOVB	R5,-(R0)	
76	017076	010146			MOV	R1,-(SP)	
77	017100	050216			BIS	R2,(SP)	
78	017102	050316			BIS	R3,(SP)	
79	017104	050426			BIS	R4,(SP)+	
80	017106	001366			BNE	4#	
81	017110				POP	R1	
82	017112				PRINTS	#RPTMD3,R0,D.SKER(R1)	
	017112	016146	000206		MOV	D.SKER(R1),-(SP)	
	017116	010046			MOV	R0,-(SP)	
	017120	012746	017551		MOV	#RPTMD3,-(SP)	

REPORT CODING SECTION

```

017124 012746 000003      MOV    #3,-(SP)
017130 010600      MOV    SP,R0
017132 104416      TRAP   C#PNTS
017134 062706 000010      ADD    #10,SP
83 017140      POP    <R5,R4,R3>
84 017146 005303      RPTDTN: DEC    R3          ;COUNT THE DRIVE TABLES
85 017150 003205      BGT RPTDT          ;REPEAT FOR ALL DRIVE TABLES
86 017152 062705 000034      RPTCTN: ADD    #C.SIZE,R5      ;GO TO NEXT CONTROLLER TABLE
87 017156 005715      TST    (R5)
88 017160 001402      BEQ    RPTXX
89 017162 000137 016524      RPTXX: JMP    RPTCT
91 017166      POP    <R5,R4,R3,R2,R1,R0>
92
93 017170      EXIT   RPT
017172 000167      .WORD J#JMP
017204 000554      .WORD L10023-2-.

94
95 017206      116      042      124 RPTMSG: .ASCIZ \N"TEST "D3" IN PROGRESS. "\
97 017242      116      042      125 RPTMSH: .ASCII \N"UNIT DRIVE SERIAL-NUMBER SEEKS MBYTES MBYTES HARD SOFT ECC"N\
98 017334      042      040      040 .ASCIZ \ " X1000 READ WRITTEN ERRORS ERRORS"N\
99 017460      045      123      062 RPTMSD: .ASCIZ \#S2#D2#S3#D3#S1#T#S1#D5#S2#D5#S3#D5#S2\
100 017527      045      104      065 RPTMD2: .ASCIZ \#D5#S2#D5#S1#D5#N\
101 017551      045      101      011 RPTMD3: .ASCIZ \#A HDA SERIAL NUMBER #T#A SEEK ERRORS #D5#N\
102 017631      045      101      040 RPTMS4: .ASCIZ \#A *** FOLLOWING UNIT WAS DROPPED *** #N\
103 017702      045      101      040 RPTMS5: .ASCIZ \#A *** FOLLOWING CONTROLLER WAS DROPPED *** #N\
105 .EVEN
106
107 017762      ENDRPT
017762      L10023:
017762 104425      TRAP   C#RPT
    
```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 142  
REPORT CODING SECTION

```
1
2
3
4
5
6
7
8
9 017764
  017764
10
11 017764 177777
12 017766 177777
13 017770 177777
14
15 017772
16
```

.SBTTL PROTECTION TABLE

\*\*\*  
: THIS TABLE IS USED BY THE RUNTIME SERVICES  
: TO PROTECT THE LOAD MEDIA.  
:--

BGNPROT  
L\$PROT::

-1 ; P-TABLE OFFSET FOR CSR ADDRESS  
-1 ; P-TABLE OFFSET FOR MASSBUS ADDRESS  
-1 ; P-TABLE OFFSET FOR DRIVE NUMBER

ENDPROT





## INITIALIZE SECTION

```

020016 104447 TRAP C0REFG ;BRANCH TO 20 IF NOT, ELSE
53
54 020020 BNCOMPLETE 20
020020 103004 BCC 20
55 020022 052737 000004 002200 BIS #IREST,IFLAGS ;SET RESTART BIT IN FLAG.
56 020030 000515 BR INIT1 ;HERE FROM CONTINUE COMMAND?
57 020032 20:
58 020032 READEF #EF.CON
020032 012700 000036 MOV #EF.CON,R0
020036 104447 TRAP C0REFG ;BRANCH TO 30 IF NOT, ELSE
59
60 020040 BNCOMPLETE 30
020040 103007 BCC 30
61 020042 042737 000020 002200 BIC #ISTRTH,IFLAGS ;CLEAR 1ST TIME THRU CZUDIO FLAG AND
62 020050 052737 000002 002200 BIS #ICONT,IFLAGS ;SET CONTINUE BIT IN FLAG.
63 020056 000472 BR 130 ;HERE FROM POWER FAIL?
64 020060 30:
65 020060 READEF #EF.PWR
020060 012700 000034 MOV #EF.PWR,R0
020064 104447 TRAP C0REFG ;BRANCH TO 40 IF NOT, ELSE
66
67 020066 BNCOMPLETE 40
020066 103001 BCC 40
68 020070 000465 BR 130
69
70 ;
71 ; MAKE ALL CONTROLLER/DRIVE TABLES NOT AVAILABLE FOR TESTING
72 ;
73 ;
74 020072 013705 002170 40: MOV CTABS,R5 ;GET ADDRESS OF 1ST CONTROLLER TABLE
75 020076 052765 100000 000002 50: BIS #CT.AVL,C.UNIT(R5) ;SET CONTROLLER TABLE NOT AVAILABLE
76 020104 010502 MOV R5,R2 ;GET POINTER TO DRIVE TABLES
77 020106 062702 000016 ADD #C.DRO,R2
78 020112 012703 000004 MOV #4,R3 ; GET NUMBER OF DRIVES PER CONTROLLER
79 020116 012200 60: MOV (R2),R0 ;SEE IF THIS DRIVES HAS A TABLE.
80 020120 001403 BEQ 70 ;BRANCH IF NOT, ELSE
81 020122 052760 100000 000002 BIS #DT.AVL,D.UNIT(R0) ;SET DRIVE TABLE NOT AVAILABLE.
82 020130 005303 70: DEC R3 ;LOOK AT NEXT DRIVE IN CONTROLLER TABLE.
83 020132 001371 BNE 60 ;BRANCH IF NO DRIVES, ELSE
84 020134 062705 000034 ADD #C.SIZE,R5 ;MOVE TO NEXT CONTROLLER TABLE
85 020140 005715 TST (R5) ;IS THERE A NEXT ONE?
86 020142 001355 BNE 50 ;IF SO, CLEAR THE BITS THERE
87 ;
88 ; NOW GET EACH P-TABLE AND MAKE THE APPROPRIATE CONTROLLER/DRIVE
89 ; TABLES AVAILABLE FOR TESTING.
90 ;
91 020144 005003 80: CLR R3 ;START WITH LOGICAL UNIT 0
92 020146 80: GPHARD R3,R0 ;GET POINTER TO IT'S P-TABLE
93 020146 MOV R3,R0
020146 010300 TRAP C0GPHRD
020150 104442 ;BRANCH TO 120 IF NOT AVAILABLE
94
95 020152 BNCOMPLETE 120
020152 103030 BCC 120
96 020154 013705 002170 90: MOV CTABS,R5 ;GET ADDRESS OF 1ST CONTROLLER TABLE
97 020160 021015 90: CMP (R0),(R5) ;SEE IF CSR ADDRESSES ARE THE SAME.
98 020162 001411 BEQ 110 ;BRANCH IF SO, ELSE

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 143.2  
INITIALIZE SECTION

```

99 020164 062705 000034      ADD      #C.SIZE,R5      ;LOOK AT NEXT CONTROLLER TABLE.
100 020170 005715           TST      (R5)           ;SEE IF THERE IS ANOTHER CONTROLLER TABLE,
101 020172 001372           BNE      9#            ;BRANCH IF SO, ELSE
102 020174           10#:      ;REPORT TABLE CONSISTANCY ERROR.
103 020174           ERRSF   6,,ERR006
    020174 104454          TRAP    C#ERSF
    020176 000006          .WORD   6
    020200 000000          .WORD   0
    020202 006606          .WORD   ERR006
104                               ;DO CLEAN-UP TRAP
105 020204           DOCLN  C#DCLN
    020204 104444          TRAP
106
107 020206 016001 000002      11#:   MOV      H.DRV(R0),R1      ;GET DRIVE NUMBER FROM P-TABLE
108 020212 004737 013224      CALL    GTDRV          ;FIND THE DRIVE TABLE ADDRESS
109 020216 001366           BNE      10#           ;BRANCH IF NOT FOUND, ELSE
110 020220 042765 100000 000002  BIC     #CT.AVL,C.UNIT(R5) ;CLEAR AVAILABLE BIT IN CONTROLLER AND
111 020226 042764 100000 000002  BIC     #DT.AVL,D.UNIT(R4) ;THE DRIVE TABLES.
112 020234 005203           12#:   INC      R3            ;INCREMENT TO NEXT UNIT IN P-TABLE
113 020236 020337 002012      CMP     R3,L#UNIT      ;SEE IF ALL P-TABLES CHECKED,
114 020242 002741           BLT     8#            ;BRANCH IF NOT, ELSE
115 020244 012701 002334      13#:   MOV     #STIME,R1      ; GET REPORT TIMER
116 020250 012700 001604      MOV     #15.*60.,R0    ; GET REPORT INTERVAL
117 020254 004737 015210      CALL    SETIO          ; SET TIME FOR NEXT REPORT
118 020260 000137 021232      JMP     INITXX         ;EXIT THE INITIALIZE SECTION.
119
120                               ;
121                               ;   INITIALIZE KW11 CLOCK, FREE MEMORY AND IP ADDRESS TABLE
122                               ;   DURING START OR RESTART COMMAND ONLY
123                               ;
124
125 020264 005037 002330      INIT1: CLR     KW.EL          ;CLEAR ELAPSED TIME
126 020270 005037 002332      CLR     KW.EL+2
127 020274           CLOCK   L,R0          ;SEE IF L-CLOCK PRESENT
    020274 012700 000114      MOV     #L,R0
    020300 104462          TRAP    C#CLCK
128 020302           BCOMPLETE 1#
    020302 103413          BCS     1#
129 020304           CLOCK   P,R0          ;SEE IF P-CLOCK PRESENT
    020304 012700 000120      MOV     #P,R0
    020310 104462          TRAP    C#CLCK
130 020312           BCOMPLETE 1#
    020312 103407          BCS     1#
131 020314 005037 002320      CLR     KW.CSR        ;IF NEITHER, CLEAR CSR STORAGE WORD
132 020320           PNTF   NOCLOCK
133 020330 000434           SR      2#
134
135 020332 012037 002320      1#:   MOV     (R0),KW.CSR    ;STORE DATA RETURNED
136 020336 012037 002322      MOV     (R0),KW.BRL
137 020342 012037 002324      MOV     (R0),KW.VEC
138 020346 012037 002326      MOV     (R0),KW.HZ
139
140 020352           SETVEC  KW.VEC,#KW11I,#PRI07 ;SETUP KW11 VECTOR ADDRESS
    020352 012746 000340      MOV     #PRI07,-(SP)
    020356 012746 015166      MOV     #KW11I,-(SP)
    020362 013746 002324      MOV     KW.VEC,-(SP)
    020366 012746 000003      MOV     #3,-(SP)

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 143-3  
INITIALIZE SECTION

```

020372 104437          TRAP  C$VVEC
020374 062706 000010    ADD   #10,SP
141 020400 012777 000105 161712    MOV   @KW.OUT,@KW.CSR      ;START THE CLOCK
142 020406 012701 002334          MOV   @STIME,R1           ; GET REPORT TIMER
143 020412 012700 001604          MOV   #15.*60.,R0        ; GET REPORT INTERVAL
144 020416 004737 015210          CALL  SETTO              ; SET TIME FOR NEXT REPORT
145 020422 004737 016134          CALL  RESET             ;RESET ALL CONTROLLERS
146 020426          MEMORY FFREE          ;RESET START OF FREE MEMORY
020426 104431          TRAP  C$MEM
020430 010037 002156    MOV   R0,FFREE
147 020434 017737 161516 002160    MOV   @FFREE,F$SIZE      ;RESET SIZE OF FREE MEMORY
148 020442 005037 002202          CLR   TNUM              ;INITIALIZE TEST NUMBER TO NO TEST RUNNING
149
150          ;
151          ;          ALLOCATE DRIVE TABLES TO MEMORY
152          ;
153
154 020446 013737 002156 002166  INIT2:  MOV   FFREE,DTABS        ;STORE START OF DRIVE TABLES AND
155 020454 005077 161506          CLR   @DTABS            ;MARK ZERO END.
156 020460 013700 002012          MOV   L$UNIT,R0        ;GET NUMBER OF LOGICAL UNITS TO RUN,
157 020464 012701 000001          MOV   #1,R1           ;GET INITIAL SIZE OF DRIVE TABLE AND
158 020470 062701 000110          ADD   @<D.SIZE>/2,R1   ;ACCUMULATE DRIVE TABLE SIZE.
159 020474 005300          DEC   R0              ;SEE IF ANY MORE LOGICAL UNITS,
160 020476 001374          BNE   1$              ;BRANCH IF NOT, ELSE
161 020500 004737 007332          CALL  ALOCH           ;ALLOCATE ALL DRIVE TABLES TO MEMORY.
162          ;          ; R1 POINTS TO 1ST WORD IN DRIVE TABLE
163
164          ;
165          ;          INITIALIZE CONTROLLER TABLE STORAGE WITH A WORD OF ZEROS
166          ;
167
168 020504 013737 002156 002170  INIT3:  MOV   FFREE,CTABS        ; STORE START OF CONTROLLER TABLES AND
169 020512 005077 161452          CLR   @CTABS           ; MARK ZEROS END.
170 020516 005037 002172          CLR   CTRLRS          ; CLEAR CONTROLLER COUNT
171 020522 012701 002244          MOV   @IPADRS,R1      ; R1 -> IP ADDRESS
172 020526 012702 000004          MOV   #4.,R2         ; GET MAXIMUM # OF CONTROLLERS
173 020532 005021          CLR   (R1).          ; CLEAR ENTRY
174 020534 005302          DEC   R2              ; DONE?
175 020536 001375          BNE   1$              ; IF NOT, BRANCH
176
177          ;
178          ;          BUILD CONTROLLER TABLES
179          ;
180
181 020540 005005          CLR   R5              ;CLEAR CUSTOMER DATA FLAG
182 020542 005002          CLR   R2              ;START WITH LOGICAL UNIT 0
208 020544 012737 005160 002254  INIT4:  MOV   #5160,BRS$V      ; SAVE DEFAULT FOR BR LEVEL & VECTOR
209 020552          GPHRD  R2,R0         ; GET POINTER TO IT'S P-TABLE
020552 010200          MOV   R2,R0
020554 104442          TRAP  C$GPHRD
210 020556          BNCOMPLETE 16$      ; BRANCH TO 16$ IF NOT AVAILABLE
020556 103124          BCC   16$
211 020560 013703 002170          MOV   CTABS,R3        ; GET ADDRESS OF 1ST CONTROLLER TABLE
212 020564 005713          TST  (R3)             ; CHECK IF ANY MORE TABLES
213 020566 001405          BEQ   6$              ; BUILD NEW TABLE IF FOUND ZERO WORD
214 020570 021013          CMP   (R0),(R3)      ; CHECK IF SAME CSR ADDRESS.
215 020572          ASSUME C.UADR EQ 0

```

## INITIALIZE SECTION

```

216 020572          ASSUME H.UBA EQ 0
217 020572 001444    BEQ      11#          ; BRANCH IF SO
219
220 020574 062703 000034 5# : ADD     #C.SIZE,R3      ;POINT TO BEGINNING OF NEXT CONTROLLER
221 020600 000771      BR      2#          ;TABLE IN MEMORY.
222
223 ;
224 ; BUILD NEW CONTROLLER TABLE
225 ;
226
227 020602 012704 002244 6# : MOV     #IPADRS,R4      ;GET BEGINNING OF IP ADDRESS TABLE
228 020606 020427 002254 7# : CMP     R4,#IPADRS+8.  ;SEE IF END OF IP ADDRESS TABLE,
229 020612 101004      BHI     9#          ;BRANCH IF SO, ELSE
230 020614 005724      TST     (R4)+.        ;DID WE FIND AN OPEN ENTRY ?
231 020616 001401      BEQ     8#          ;BRANCH IF SO, ELSE
232 020620 000772      BR      7#          ;LOOK AGAIN.
233
234 020622 011044      8# : MOV     (R0),-(R4)      ;TAKE CSR ADDRESS FROM P-TABLE
235 ; AND STORE IT IN THE IP ADDRESS TABLE.
236 020624 012701 000016 9# : MOV     #<C.SIZE>/2,R1 ;GET # OF ENTRIES IN CONTROLLER TABLE
237 020630 004737 007332 CALL    ALOCM          ;AND ALLOCATE A TABLE TO MEMORY.
238 ; R0 => 1ST WORD P-TABLE
239 ; R1 => 1ST WORD IN CONTROLLER TABLE
240 020634 011021      MOV     (R0),(R1)+.    ; STORE CSR ADDRESS AND
241 020636 010221      MOV     R2,(R1)+.    ; UNIT NUMBER IN THE CONTROLLER TABLE.
248 020640 013704 002254 MOV     BRSAV,R4      ; GET DEFAULT VECTOR & BR LEVEL
249 020644 162704 000004 SUB     #4,R4         ; GET NEXT VECTOR
250 020650 010437 002254 MOV     R4,BRSAV     ; SAVE NEXT VECTOR
252 020654 010421      MOV     R4,(R1)+.    ;STORE IT IN THE CONTROLLER TABLE.
253 020656 012721 004037 MOV     #4037,(R1)+. ;THE 'JSR R0' INSTRUCTION AND
254 020662 012721 015156 MOV     #CNTSRV,(R1)+;THE ADDRESS OF THE INTERRUPT SERVICE
255 ;ROUTINE IN THE CONTROLLER TABLE.
256 020666 012704 000011 10# : MOV     #<C.SIZE-C.FLG>/2,R4 ;GET # OF ENTRIES TO END OF TABLE.
257 020672 005021      CLR     (R1)+.        ;CLEAR REST OF TABLE AND
258 020674 005304      DEC     R4           ;ADD ZERO WORD AT END.
259 020676 002375      BGE     10#         ;LOOP TIL ALL CLEARED
260 020700 005237 002172 INC     CTRLRS        ;KEEP TRACK OF CONTROLLER COUNT
261
262 ;
263 ; BUILD DRIVE TABLES
264 ;
265
266 020704 013701 002166 11# : MOV     DTABS,R1      ;GET ADDRESS OF CURRENT DRIVE TABLE
267 020710 062703 000016 ADD     #C.DRO,R3     ; INDEX TO 1ST DRIVE IN TABLE
268 020714 012704 000004 MOV     #4,R4         ; GET # OF DRIVES PER CONTROLLER
269 020720 005713 12# : TST     (R3)         ;ANY ENTRY TO DRIVE TABLE.
270 020722 001411      BEQ     14#         ;BRANCH IF NOT, ELSE
271 020724 026033 000002 CMP     H.DRV(R0),B(R3)+;COMPARE DRIVE NUMBER IN DRIVE TABLE.
272 020730 001002      BNE     13#         ;BRANCH IF DIFFERENT, ELSE
273 020732 000137 021244 JMP     MLDREX        ;FOUND TWO P-TABLES WITH SAME DRIVE.
274
275 020736 005304 13# : DEC     R4           ; COUNT DRIVES
276 020740 001367      BNE     12#         ; IF FOUR DRIVE TABLES ALREADY EXIST,
277 020742 000137 021262 JMP     TOOMER        ; THEN REPORT ERROR
278
279 020746 010113 14# : MOV     R1,(R3)      ;STORE ADDRESS OF DRIVE TABLE IN
280 ;CONTROLLER TABLE.

```

INITIALIZE SECTION

```

281 020750 016021 000002      MOV      H.DRV(R0),(R1)      ;STORE DRIVE NUMBER AND
282 020754 010221              MOV      R2,(R1)           ;LOGICAL UNIT NUMBER IN DRIVE TABLE.
284 020756 016011 000004      MOV      H.PRM(R0),(R1)    ;GET TEST AREA BIT
285 020762 051105              BIS      (R1),R5           ;SAVE "OR" OF BIT FROM ALL DRIVES
286 020764 005111              COM      (R1)             ;COMPLIMENT IT
287 020766 042711 157777      BIC      @+C<HM.CYL>,(R1)  ; SET BIT FOR WRITE ON CUST DATA
288 020772 052721 011012      BIS      @DDEF,(R1)       ;LOAD DEFAULT PARAMETER BITS
289 020776 012704 000105      MOV      @<D.SIZE/2>-3,R4  ;CLEAR REST OF TABLE
290 021002 005021              15:    CLR      (R1)
291 021004 005304              DEC      R4
292 021006 003375              BGT      15:
293 021010 012761 177777 177742  MOV      @-1,<D.ECYL+2-D.SIZE>(R1) ;MARK CYLINDERS AT TEST ALL
295
296 021016 062737 000220 002166  ADD      @D.SIZE,DTABS     ;NEXT DRIVE TABLE ADDRESS AND
297 021024 005077 161136              CLR      @DTABS           ;MARK ZERO END.
298 021030 005202              16:    INC      R2             ;INCREMENT LOGICAL UNIT NUMBER
299 021032 020237 002012      CMP      R2,L#UNIT        ;CHECK IF GOT ALL TABLES
300 021036 002645              BLT      1:               ;IF NOT, GO BACK FOR NEXT, ELSE
301 021040 012701 000001      MOV      @1,R1            ;GET 1 WORD TO TERMINATE ALL CONTROLLER
302 021044 004737 007332      CALL    ALOCM             ;TABLES AND ALLOCATE IT TO MEMORY.
303
305
306
307
308
309 021050 032705 020000      INITS:  BIT      @HM.CYL,R5 ;CHECK IF BIT EVER SET
310 021054 001460              BEQ      INIT6           ;BYPASS IF NOT
311 021056              PNTF    INITWA          ;PRINT WARNING HEADER
312 021066 013705 002170      MOV      CTABS,R5        ;GET ADDRESS 1ST CONTROLLER TABLE
313 021072 010504              1:    MOV      R5,R4          ;GET ADDRESS OF POINTER TO DRIVE TABLE
314 021074 062704 000016      ADD      @C.DRO,R4
315 021100 012701 000004      MOV      @4.,R1          ;GET COUNT OF DRIVE TABLES
316 021104 012403              2:    MOV      (R4)+,R3      ;GET ADDRESS OF DRIVE TABLE
317 021106 001422              BEQ      4:
318 021110 032763 020000 000004  BIT      @D.DCY,D.PRM(R3) ;CHECK IF CUSTOMER DATA SELECTED
319 021116 001014              BNE      3:
320 021120              PRINTF @INITWB,D.UNIT(R3),(R5),(R3) ;PRINT NUMBERS
    021120 011346              MOV      (R3),-(SP)
    021122 011546              MOV      (R5),-(SP)
    021124 016346 000002      MOV      D.UNIT(R3),-(SP)
    021130 012746 003356      MOV      @INITWB,-(SP)
    021134 012746 000004      MOV      @4,-(SP)
    021140 010600              MOV      SP,R0
    021142 104417              TRAP    C#PNTF
    021144 062706 000012      ADD      @12,SP
321 021150 005301              3:    DEC      R1             ;COUNT THE DRIVE TABLES
322 021152 001354              BNE      2:             ;LOOK AT ALL OF THEM
323 021154 062705 000034      4:    ADD      @C.SIZE,R5    ;MOVE TO NEXT CONTROLLER TABLE
324 021160 005715              TST     (R5)           ;SEE IF ANOTHER TABLE AND
325 021162 001343              BNE      1:             ;LOOK AT IT
326
327
328
329
330
331 021164              ;
    021164 104450      MANUAL  ;CHECK IF MANUAL INTERVENTION ALLOWED
    TRAP   C#MANI

```

## INITIALIZE SECTION

```

332 021166          BNCOMPLETE      INIT6          ;BRANCH IF NOT ALLOWED
    021166 103013    BCC          INIT6
333 021170          GMANIL          INITWC,TEMP,1,NO ;ASK OPERATOR
    021170 104443    TRAP          C#GMAN
    021172 000404    BR           10000#
    021174 002214    .WORD        TEMP
    021176 000120    .WORD        T#CODE
    021200 002465    .WORD        INITWC
    021202 000001    .WORD        1
    021204          10000#;
334 021204 032737 000001 002214    BIT          #1,TEMP ;LOOK AT RESPONSE
335 021212 001001          BNE          INIT6 ;BRANCH IF YES WAS ANSWER
336          ;DO CLEAN-UP TRAP
337 021214          DOCLN
    021214 104444    TRAP          C#DCLN
338
340          ;
341          ;   SAVE CURRENT PARAMETERS TO FREE MEMORY SO EACH TEST CAN USE ALL OF IT
342          ;
343
344 021216 013737 002156 002162    INIT6: MOV      FFREE,FHEM ;SAVE START ADDRESS
345 021224 013737 002160 002164    MOV      FSIZE,FHEMS ;SAVE SIZE
346
347          ;
348          ;   EXIT INITIALIZE SECTION
349          ;
350
351 021232          INITXX: SETPRI   #PRI00 ;SET RUNNING PRIORITY TO ZERO
    021232 012700 000000    MOV      #PRI00,R0
    021236 104441    TRAP          C#SPRI
352
353 021240          EXIT          INIT
    021240 104432    TRAP          C#EXIT
    021242 000036    .WORD        L10025-.

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 144  
INITIALIZE ERRORS

```

1          .SBTTL  INITIALIZE ERRORS
13
14          :
15          :      TWO P-TABLES FOR SAME DRIVE
16          :
17
18 021244  013705  002214  MLDRER:  MOV      TEMP,R5          ;GET CONTROLLER ADDRESS
19 021250          104454  ERRSF 2,,ERR002
   021250          000002  TRAP      C#ERSF
   021252          000000  .WORD     2
   021254          000000  .WORD     0
   021256          006540  .WORD     ERR002          ;DO CLEAN-UP TRAP
20
21 021260          104444  DOCLN
   021260          000000  TRAP      C#DCLN
22
23          :
24          :      MORE THAN FOUR DRIVES SELECTED ON ONE CONTROLLER
25          :
26
27 021262  013705  002214  TOOMER: MOV      TEMP,R5          ;GET CONTROLLER ADDRESS
28 021266          104454  ERRSF 3,,ERR003
   021266          000003  TRAP      C#ERSF
   021270          000000  .WORD     3
   021272          000000  .WORD     0
   021274          006556  .WORD     ERR003          ;DO CLEAN-UP TRAP
29
30 021276          104444  DOCLN
   021276          000000  TRAP      C#DCLN
41
42 021300          104411  ENDINIT
   021300          000000  L10025:
   021300          000000  TRAP      C#INIT
43

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 145  
AUTODROP SECTION

```
1          .SBTTL AUTODROP SECTION
2
3          ;**
4          ; THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
5          ; THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO
6          ; SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
7          ; DROPPED FROM TESTING.
8          ;--
9
10         021302          BGNAUTO
11         021302          L$AUTO::
12
13         021302          ENDAUTO
14         021302          L10026:
15         021302 104461   TRAP      C$AUTO
```



1  
2  
3  
4  
5  
6  
7  
8 021304  
021304  
9  
13  
14 021304  
021304 104432  
021306 000002  
15  
16 021310  
021310  
021310 104412  
17

.SBTTL CLEANUP CODING SECTION

;++  
:  
: THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED  
: AFTER EACH PASS AND AFTER THE PROGRAM IS INTERRUPTED BY "tC".  
:--

BGNCLN  
L\$CLEAN::  
  
EXIT CLN  
TRAP C\$EXIT  
.WORD L10027-.  
  
ENDCLN  
L10027: TRAP C\$CLEAN

CZUDIA0 UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 147  
 DROP UNIT SECTION

1		.SBTTL	DROP UNIT SECTION
2			
3		;++	
4		:	THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
5		:	TO NO LONGER BE TESTED.
6		!--	
7			
8	021312		BGNDU
	021312	L#DU::	
9			
10	021312	EXIT	DU
	021312	.WORD	J#JMP
	021314	.WORD	L10030-2-.
11			
12	021316	ENDDU	
	021316	L10030:	
	021316	TRAP	C#DU
13			

CZUDIA0 UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 148  
 ADD UNIT SECTION

1		.SBTTL	ADD	UNIT SECTION
2				
3		;	++	
4		;		THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
5		;		TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
6		;		TO THE TEST CYCLE.
7		;	--	
8				
9	021320			BGNAU
	021320	L\$AU::		
10				
11				
12	021320		EXIT	AU
	021320		.WORD	J\$JMP
	021322	000167	.WORD	L10031-2-.
		000000		
13				
14	021324		ENDAU	
	021324	L10031:		
	021324		TRAP	C\$AU
15				

1  
2

.SBTTL HARDWARE TESTS

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 150  
 TEST 1: DISK EXERCISER

```

1          .SBTTL TEST 1: DISK EXERCISER
2
3 021326   BGNTST
4 021326   T1::
9 021326  022737 000001 002202   CMP      #1,TNUM      ;CHECK IF TEST 1 WAS IN PROGRESS
10 021334  001053          BNE      T4STRT      ;BRANCH IF NOT
11 021336  022737 000002 002200   CMP      #ICONT,IFLAGS ;CHECK IF HERE BY CONTINUE COMMAND
12 021344  001047          BNE      T4STRT      ;BRANCH IF NOT
13 021346  005037 002200          CLR      IFLAGS      ;CLEAR FLAGS FOR NEXT TIME HERE
14 021352  013704 002366          MOV      LBUFS,R4    ;GET LOG BUFFER POINTER
15 021356  001423          BEQ      LOGCHK      ; IF ZERO, NONE EXISTS
16 021360          PNTF      LOGM1      ;INTRODUCE ERROR LOG
17 021370  005037 002366          CLR      LBUFS      ;CLEAR START ADDRESS TO ERASE BUFFER
18 021374  012405          LOGOUT: MOV      (R4)+,R5 ;GET CONTROLLER TABLE ADDRESS
19 021376  004737 014232          CALL     PNTERR      ;PRINT ERROR REPORT
20 021402  062704 000104          ADD      #<HC.BSZ-2>,R4 ;BUMP POINTER TO NEXT ENTRY
21 021406  020437 002370          CMP      R4,LBUFN    ;CHECK IF AT END
22 021412  103770          BLO      LOGOUT      ;PRINT ALL ENTRIES
23 021414          PNTF      LOGM2
24 021424  000410          BR       T4CON
25
26 021426  032737 001000 002144 LOGCHK: BIT      #SM.LOG,SFPTBL+SO.BIT ;CHECK IF LOG ENABLED
27 021434  001404          BEQ      T4CON
28 021436          PNTF      LOGM3      ;REPORT LOG EMPTY
29 021446  005737 002206          T4CON: TST      URNING ;CHECK IF ANY CONTROLLERS STILL RUNNING
30 021452  001404          BEQ      T4STRT      ;RESTART IF NOT
31 021454  004737 010374          CALL     RESPDM      ;CONTINUE BY RESPONDING TO REQUESTS
32 021460  000137 021756          JMP      T4WAIT      ;END OF TEST WHEN DONE
33
34          ;
35          ; START TEST
36 021464  012701 000001          T4STRT: MOV      #1,R1      ;INITIALIZE TEST PARAMETERS
37 021470  004737 010234          CALL     TINIT
38 021474  032737 000014 002200   BIT      #IIRST,IREST,IFLAGS ;HERE FROM OPERATOR COMMAND?
39 021502  001506          BEQ      T4RUN      ;RUN WITH PREVIOUS PARAMETERS IF NEW PASS
40 021504  032737 000200 002144   BIT      #SM.MAN,SFPTBL+SO.BIT ;MANUAL INTERVENTION MODE?
41 021512  001450          BEQ      T4DEF      ;IF NOT, SET UP DEFAULT PARAMETERS
42 021514          MANUAL
43 021514  104450          TRAP     C#MANI      ;MANUAL INTERVENTION ALLOWED?
44 021516          BNCOMPLETE T4DEFW
45 021516  103042          BCC      T4DEFW      ;IF NOT, GIVE WARNING
46
47          ;
48          ; INPUT PARAMETERS
49          ;
50          ;
51          ;
52          ;
53          ;
54          ;
55          ;
56          ;
57          ;
58 021520  005037 002210          1#: CLR      UCNT      ;CLEAR COUNT OF UNITS USING PATTERN 16
59 021524  013705 002170          MOV      CTABS,R5    ;GET ADDRESS OF 1ST CONTROLLER TABLE
60 021530  012702 000004          T4PRM1: MOV      #4.,R2    ;GET COUNT OF DRIVE TABLES
61 021534  010504          MOV      R5,R4      ;GET FIRST DRIVE TABLE POINTER
62 021536  062704 000016          ADD      #C.DRO,R4
63 021542  012403          T4PRM2: MOV      (R4)+,R3 ;GET DRIVE TABLE ADDRESS
64 021544  001416          BEQ      T4PRM4      ;GO TO NEXT CONTROLLER IF NONE
65 021546  032763 100000 000002   BIT      #DT.AVL,D.UNIT(R3) ;SEE IF TO BE TESTED
66 021554  001010          BNE      T4PRM3
67 021556  004737 022000          CALL     T4QUES      ; ASK CZUDIO QUESTIONS
68          ;
69          ; INPUT - NONE
70          ;
71          ;
72          ;
73          ;
74          ;
75          ;
76          ;
77          ;
78          ;
79          ;
80          ;
81          ;
82          ;
83          ;
84          ;
85          ;
86          ;
87          ;
88          ;
89          ;
90          ;
91          ;
92          ;
93          ;
94          ;
95          ;
96          ;
97          ;
98          ;
99          ;
100         ;
101         ;
102         ;
103         ;
104         ;
105         ;
106         ;
107         ;
108         ;
109         ;
110         ;
111         ;
112         ;
113         ;
114         ;
115         ;
116         ;
117         ;
118         ;
119         ;
120         ;
121         ;
122         ;
123         ;
124         ;
125         ;
126         ;
127         ;
128         ;
129         ;
130         ;
131         ;
132         ;
133         ;
134         ;
135         ;
136         ;
137         ;
138         ;
139         ;
140         ;
141         ;
142         ;
143         ;
144         ;
145         ;
146         ;
147         ;
148         ;
149         ;
150         ;
151         ;
152         ;
153         ;
154         ;
155         ;
156         ;
157         ;
158         ;
159         ;
160         ;
161         ;
162         ;
163         ;
164         ;
165         ;
166         ;
167         ;
168         ;
169         ;
170         ;
171         ;
172         ;
173         ;
174         ;
175         ;
176         ;
177         ;
178         ;
179         ;
180         ;
181         ;
182         ;
183         ;
184         ;
185         ;
186         ;
187         ;
188         ;
189         ;
190         ;
191         ;
192         ;
193         ;
194         ;
195         ;
196         ;
197         ;
198         ;
199         ;
200         ;
201         ;
202         ;
203         ;
204         ;
205         ;
206         ;
207         ;
208         ;
209         ;
210         ;
211         ;
212         ;
213         ;
214         ;
215         ;
216         ;
217         ;
218         ;
219         ;
220         ;
221         ;
222         ;
223         ;
224         ;
225         ;
226         ;
227         ;
228         ;
229         ;
230         ;
231         ;
232         ;
233         ;
234         ;
235         ;
236         ;
237         ;
238         ;
239         ;
240         ;
241         ;
242         ;
243         ;
244         ;
245         ;
246         ;
247         ;
248         ;
249         ;
250         ;
251         ;
252         ;
253         ;
254         ;
255         ;
256         ;
257         ;
258         ;
259         ;
260         ;
261         ;
262         ;
263         ;
264         ;
265         ;
266         ;
267         ;
268         ;
269         ;
270         ;
271         ;
272         ;
273         ;
274         ;
275         ;
276         ;
277         ;
278         ;
279         ;
280         ;
281         ;
282         ;
283         ;
284         ;
285         ;
286         ;
287         ;
288         ;
289         ;
290         ;
291         ;
292         ;
293         ;
294         ;
295         ;
296         ;
297         ;
298         ;
299         ;
300         ;
301         ;
302         ;
303         ;
304         ;
305         ;
306         ;
307         ;
308         ;
309         ;
310         ;
311         ;
312         ;
313         ;
314         ;
315         ;
316         ;
317         ;
318         ;
319         ;
320         ;
321         ;
322         ;
323         ;
324         ;
325         ;
326         ;
327         ;
328         ;
329         ;
330         ;
331         ;
332         ;
333         ;
334         ;
335         ;
336         ;
337         ;
338         ;
339         ;
340         ;
341         ;
342         ;
343         ;
344         ;
345         ;
346         ;
347         ;
348         ;
349         ;
350         ;
351         ;
352         ;
353         ;
354         ;
355         ;
356         ;
357         ;
358         ;
359         ;
360         ;
361         ;
362         ;
363         ;
364         ;
365         ;
366         ;
367         ;
368         ;
369         ;
370         ;
371         ;
372         ;
373         ;
374         ;
375         ;
376         ;
377         ;
378         ;
379         ;
380         ;
381         ;
382         ;
383         ;
384         ;
385         ;
386         ;
387         ;
388         ;
389         ;
390         ;
391         ;
392         ;
393         ;
394         ;
395         ;
396         ;
397         ;
398         ;
399         ;
400         ;
401         ;
402         ;
403         ;
404         ;
405         ;
406         ;
407         ;
408         ;
409         ;
410         ;
411         ;
412         ;
413         ;
414         ;
415         ;
416         ;
417         ;
418         ;
419         ;
420         ;
421         ;
422         ;
423         ;
424         ;
425         ;
426         ;
427         ;
428         ;
429         ;
430         ;
431         ;
432         ;
433         ;
434         ;
435         ;
436         ;
437         ;
438         ;
439         ;
440         ;
441         ;
442         ;
443         ;
444         ;
445         ;
446         ;
447         ;
448         ;
449         ;
450         ;
451         ;
452         ;
453         ;
454         ;
455         ;
456         ;
457         ;
458         ;
459         ;
460         ;
461         ;
462         ;
463         ;
464         ;
465         ;
466         ;
467         ;
468         ;
469         ;
470         ;
471         ;
472         ;
473         ;
474         ;
475         ;
476         ;
477         ;
478         ;
479         ;
480         ;
481         ;
482         ;
483         ;
484         ;
485         ;
486         ;
487         ;
488         ;
489         ;
490         ;
491         ;
492         ;
493         ;
494         ;
495         ;
496         ;
497         ;
498         ;
499         ;
500         ;
501         ;
502         ;
503         ;
504         ;
505         ;
506         ;
507         ;
508         ;
509         ;
510         ;
511         ;
512         ;
513         ;
514         ;
515         ;
516         ;
517         ;
518         ;
519         ;
520         ;
521         ;
522         ;
523         ;
524         ;
525         ;
526         ;
527         ;
528         ;
529         ;
530         ;
531         ;
532         ;
533         ;
534         ;
535         ;
536         ;
537         ;
538         ;
539         ;
540         ;
541         ;
542         ;
543         ;
544         ;
545         ;
546         ;
547         ;
548         ;
549         ;
550         ;
551         ;
552         ;
553         ;
554         ;
555         ;
556         ;
557         ;
558         ;
559         ;
560         ;
561         ;
562         ;
563         ;
564         ;
565         ;
566         ;
567         ;
568         ;
569         ;
570         ;
571         ;
572         ;
573         ;
574         ;
575         ;
576         ;
577         ;
578         ;
579         ;
580         ;
581         ;
582         ;
583         ;
584         ;
585         ;
586         ;
587         ;
588         ;
589         ;
590         ;
591         ;
592         ;
593         ;
594         ;
595         ;
596         ;
597         ;
598         ;
599         ;
600         ;
601         ;
602         ;
603         ;
604         ;
605         ;
606         ;
607         ;
608         ;
609         ;
610         ;
611         ;
612         ;
613         ;
614         ;
615         ;
616         ;
617         ;
618         ;
619         ;
620         ;
621         ;
622         ;
623         ;
624         ;
625         ;
626         ;
627         ;
628         ;
629         ;
630         ;
631         ;
632         ;
633         ;
634         ;
635         ;
636         ;
637         ;
638         ;
639         ;
640         ;
641         ;
642         ;
643         ;
644         ;
645         ;
646         ;
647         ;
648         ;
649         ;
650         ;
651         ;
652         ;
653         ;
654         ;
655         ;
656         ;
657         ;
658         ;
659         ;
660         ;
661         ;
662         ;
663         ;
664         ;
665         ;
666         ;
667         ;
668         ;
669         ;
670         ;
671         ;
672         ;
673         ;
674         ;
675         ;
676         ;
677         ;
678         ;
679         ;
680         ;
681         ;
682         ;
683         ;
684         ;
685         ;
686         ;
687         ;
688         ;
689         ;
690         ;
691         ;
692         ;
693         ;
694         ;
695         ;
696         ;
697         ;
698         ;
699         ;
700         ;
701         ;
702         ;
703         ;
704         ;
705         ;
706         ;
707         ;
708         ;
709         ;
710         ;
711         ;
712         ;
713         ;
714         ;
715         ;
716         ;
717         ;
718         ;
719         ;
720         ;
721         ;
722         ;
723         ;
724         ;
725         ;
726         ;
727         ;
728         ;
729         ;
730         ;
731         ;
732         ;
733         ;
734         ;
735         ;
736         ;
737         ;
738         ;
739         ;
740         ;
741         ;
742         ;
743         ;
744         ;
745         ;
746         ;
747         ;
748         ;
749         ;
750         ;
751         ;
752         ;
753         ;
754         ;
755         ;
756         ;
757         ;
758         ;
759         ;
760         ;
761         ;
762         ;
763         ;
764         ;
765         ;
766         ;
767         ;
768         ;
769         ;
770         ;
771         ;
772         ;
773         ;
774         ;
775         ;
776         ;
777         ;
778         ;
779         ;
780         ;
781         ;
782         ;
783         ;
784         ;
785         ;
786         ;
787         ;
788         ;
789         ;
790         ;
791         ;
792         ;
793         ;
794         ;
795         ;
796         ;
797         ;
798         ;
799         ;
800         ;
801         ;
802         ;
803         ;
804         ;
805         ;
806         ;
807         ;
808         ;
809         ;
810         ;
811         ;
812         ;
813         ;
814         ;
815         ;
816         ;
817         ;
818         ;
819         ;
820         ;
821         ;
822         ;
823         ;
824         ;
825         ;
826         ;
827         ;
828         ;
829         ;
830         ;
831         ;
832         ;
833         ;
834         ;
835         ;
836         ;
837         ;
838         ;
839         ;
840         ;
841         ;
842         ;
843         ;
844         ;
845         ;
846         ;
847         ;
848         ;
849         ;
850         ;
851         ;
852         ;
853         ;
854         ;
855         ;
856         ;
857         ;
858         ;
859         ;
860         ;
861         ;
862         ;
863         ;
864         ;
865         ;
866         ;
867         ;
868         ;
869         ;
870         ;
871         ;
872         ;
873         ;
874         ;
875         ;
876         ;
877         ;
878         ;
879         ;
880         ;
881         ;
882         ;
883         ;
884         ;
885         ;
886         ;
887         ;
888         ;
889         ;
890         ;
891         ;
892         ;
893         ;
894         ;
895         ;
896         ;
897         ;
898         ;
899         ;
900         ;
901         ;
902         ;
903         ;
904         ;
905         ;
906         ;
907         ;
908         ;
909         ;
910         ;
911         ;
912         ;
913         ;
914         ;
915         ;
916         ;
917         ;
918         ;
919         ;
920         ;
921         ;
922         ;
923         ;
924         ;
925         ;
926         ;
927         ;
928         ;
929         ;
930         ;
931         ;
932         ;
933         ;
934         ;
935         ;
936         ;
937         ;
938         ;
939         ;
940         ;
941         ;
942         ;
943         ;
944         ;
945         ;
946         ;
947         ;
948         ;
949         ;
950         ;
951         ;
952         ;
953         ;
954         ;
955         ;
956         ;
957         ;
958         ;
959         ;
960         ;
961         ;
962         ;
963         ;
964         ;
965         ;
966         ;
967         ;
968         ;
969         ;
970         ;
971         ;
972         ;
973         ;
974         ;
975         ;
976         ;
977         ;
978         ;
979         ;
980         ;
981         ;
982         ;
983         ;
984         ;
985         ;
986         ;
987         ;
988         ;
989         ;
990         ;
991         ;
992         ;
993         ;
994         ;
995         ;
996         ;
997         ;
998         ;
999         ;
1000        ;
1001        ;
1002        ;
1003        ;
1004        ;
1005        ;
1006        ;
1007        ;
1008        ;
1009        ;
1010        ;
1011        ;
1012        ;
1013        ;
1014        ;
1015        ;
1016        ;
1017        ;
1018        ;
1019        ;
1020        ;
1021        ;
1022        ;
1023        ;
1024        ;
1025        ;
1026        ;
1027        ;
1028        ;
1029        ;
1030        ;
1031        ;
1032        ;
1033        ;
1034        ;
1035        ;
1036        ;
1037        ;
1038        ;
1039        ;
1040        ;
1041        ;
1042        ;
1043        ;
1044        ;
1045        ;
1046        ;
1047        ;
1048        ;
1049        ;
1050        ;
1051        ;
1052        ;
1053        ;
1054        ;
1055        ;
1056        ;
1057        ;
1058        ;
1059        ;
1060        ;
1061        ;
1062        ;
1063        ;
1064        ;
1065        ;
1066        ;
1067        ;
1068        ;
1069        ;
1070        ;
1071        ;
1072        ;
1073        ;
1074        ;
1075        ;
1076        ;
1077        ;
1078        ;
1079        ;
1080        ;
1081        ;
1082        ;
1083        ;
1084        ;
1085        ;
1086        ;
1087        ;
1088        ;
1089        ;
1090        ;
1091        ;
1092        ;
1093        ;
1094        ;
1095        ;
1096        ;
1097        ;
1098        ;
1099        ;
1100        ;
1101        ;
1102        ;
1103        ;
1104        ;
1105        ;
1106        ;
1107        ;
1108        ;
1109        ;
1110        ;
1111        ;
1112        ;
1113        ;
1114        ;
1115        ;
1116        ;
1117        ;
1118        ;
1119        ;
1120        ;
1121        ;
1122        ;
1123        ;
1124        ;
1125        ;
1126        ;
1127        ;
1128        ;
1129        ;
1130        ;
1131        ;
1132        ;
1133        ;
1134        ;
1135        ;
1136        ;
1137        ;
1138        ;
1139        ;
1140        ;
1141        ;
1142        ;
1143        ;
1144        ;
1145        ;
1146        ;
1147        ;
1148        ;
1149        ;
1150        ;
1151        ;
1152        ;
1153        ;
1154        ;
1155        ;
1156        ;
1157        ;
1158        ;
1159        ;
1160        ;
1161        ;
1162        ;
1163        ;
1164        ;
1165        ;
1166        ;
1167        ;
1168        ;
1169        ;
1170        ;
1171        ;
1172        ;
1173        ;
1174        ;
1175        ;
1176        ;
1177        ;
1178        ;
1179        ;
1180        ;
1181        ;
1182        ;
1183        ;
1184        ;
1185        ;
1186        ;
1187        ;
1188        ;
1189        ;
1190        ;
1191        ;
1192        ;
1193        ;
1194        ;
1195        ;
1196        ;
1197        ;
1198        ;
1199        ;
1200        ;
1201        ;
1202        ;
1203        ;
1204        ;
1205        ;
1206        ;
1207        ;
1208        ;
1209        ;
1210        ;
1211        ;
1212        ;
1213        ;
1214        ;
1215        ;
1216        ;
1217        ;
1218        ;
1219        ;
1220        ;
1221        ;
1222        ;
1223        ;
1224        ;
1225        ;
1226        ;
1227        ;
1228        ;
1229        ;
1230        ;
1231        ;
1232        ;
1233        ;
1234        ;
1235        ;
1236        ;
1237        ;
1238        ;
1239        ;
1240        ;
1241        ;
1242        ;
1243        ;
1244        ;
1245        ;
1246        ;
1247        ;
1248        ;
1249        ;
1250        ;
1251        ;
1252        ;
1253        ;
1254        ;
1255        ;
1256        ;
1257        ;
1258        ;
1259        ;
1260        ;
1261        ;
1262        ;
1263        ;
1264        ;
1265        ;
1266        ;
1267        ;
1268        ;
1269        ;
1270        ;
1271        ;
1272        ;
1273        ;
1274        ;
1275        ;
1276        ;
1277        ;
1278        ;
1279        ;
1280        ;
1281        ;
1282        ;
1283        ;
1284        ;
1285        ;
1286        ;
1287        ;
1288        ;
1289        ;
1290        ;
1291        ;
1292        ;
1293        ;
1294        ;
1295        ;
1296        ;
1297        ;
1298        ;
1299        ;
1300        ;
1301        ;
1302        ;
1303        ;
1304        ;
1305        ;
1306        ;
1307        ;
1308        ;
1309        ;
1310        ;
1311        ;
1312        ;
1313        ;
1314        ;
1315        ;
1316        ;
1317        ;
1318        ;
1319        ;
1320        ;
1321        ;
1322        ;
1323        ;
1324        ;
1325        ;
1326        ;
1327        ;
1328        ;
1329        ;
1330        ;
1331        ;
1332        ;
1333        ;
1334        ;
1335        ;
1336        ;
1337        ;
1338        ;
1339        ;
1340        ;
1341        ;
1342        ;
1343        ;
1344        ;
1345        ;
1346        ;
1347        ;
1348        ;
1349        ;
1350        ;
1351        ;
1352        ;
1353        ;
1354        ;
1355        ;
1356        ;
1357        ;
1358        ;
1359        ;
1360        ;
1361        ;
1362        ;
1363        ;
1364        ;
1365        ;
1366        ;
1367        ;
1368        ;
1369        ;
1370        ;
1371        ;
1372        ;
1373        ;
1374        ;
1375        ;
1376        ;
1377        ;
1378        ;
1379        ;
1380        ;
1381        ;
1382        ;
1383        ;
1384        ;
1385        ;
1386        ;
1387        ;
1388        ;
1389        ;
1390        ;
1391        ;
1392        ;
1393        ;
1394        ;
1395        ;
1396        ;
1397        ;
1398        ;
1399        ;
1400        ;
1401        ;
1402        ;
1403        ;
1404        ;
1405        ;
1406        ;
1407        ;
1408        ;
1409        ;
1410        ;
1411        ;
1412        ;
1413        ;
1414        ;
1415        ;
1416        ;
1417        ;
1418        ;
1419        ;
1420        ;
1421        ;
1422        ;
1423        ;
1424        ;
1425        ;
1426        ;
1427        ;
1428        ;
1429        ;
1430        ;
1431        ;
1432        ;
1433        ;
1434        ;
1435        ;
1436        ;
1437        ;
1438        ;
1439        ;
1440        ;
1441        ;
1442        ;
1443        ;
1444        ;
1445        ;
1446        ;
1447        ;
1448        ;
1449        ;
1450        ;
1451        ;
1452        ;
1453        ;
1454        ;
1455        ;
1456        ;
1457        ;
1458        ;
1459        ;
1460        ;
1461        ;
1462        ;
1463        ;
1464        ;
1465        ;
1466        ;
1467        ;
1468        ;
1469        ;
1470        ;
1471        ;
1472        ;
1473        ;
1474        ;
1475        ;
1476        ;
1477        ;
1478        ;
1479        ;
1480        ;
1481        ;
1482        ;
1483        ;
1484        ;
1485        ;
1486        ;
1487        ;
1488        ;
1489        ;
1490        ;
1491        ;
1492        ;
1493        ;
1494        ;
1495        ;
1496        ;
1497        ;
1498        ;
1499        ;
1500        ;
1501        ;
1502        ;
1503        ;
1504        ;
1505        ;
1506        ;
1507        ;
1508        ;
1509        ;
1510        ;
1511        ;
1512        ;
1513        ;
1514        ;
1515        ;
1516        ;
1517        ;
1518        ;
1519        ;
1520        ;
1521        ;
1522        ;
1523        ;
1524        ;
1525        ;
1526        ;
1527        ;
1528        ;
1529        ;
1530        ;
1531        ;
1532        ;
1533        ;
1534        ;
1535        ;
1536        ;
1537        ;
1538        ;
1539        ;
1540        ;
1541        ;
1542        ;
1543        ;
1544        ;
1545        ;
1546        ;
1547        ;
1548        ;
1549        ;
1550        ;
1551        ;
1552        ;
1553        ;
1554        ;
1555        ;
1556        ;
1557        ;
1558        ;
1559        ;
1560        ;
1561        ;
1562        ;
1563        ;
1564        ;
1565        ;
1566        ;
1567        ;
1568        ;
1569        ;
1570        ;
1571        ;
1572        ;
1573        ;
1574        ;
1575        ;
1576        ;
1577        ;
1578        ;
1579        ;
1580        ;
1581        ;
1582        ;
1583        ;
1584        ;
1585        ;
1586        ;
1587        ;
1588        ;
1589        ;
1590        ;
1591        ;
1592        ;
1593        ;
1594        ;
1595        ;
1596        ;
1597        ;
1598        ;
1599        ;
1600        ;
1601        ;
1602        ;
1603        ;
1604        ;
1605        ;
1606        ;
1607        ;
1608        ;
1609        ;
1610        ;
1611        ;
1612        ;
1613        ;
1614        ;
1615        ;
1616        ;
1617        ;
1618        ;
1619        ;
1620        ;
1621        ;
1622        ;
1623        ;
1624        ;
1625        ;
1626        ;
1627        ;
1628        ;
1629        ;
1630        ;
1631        ;
1632        ;
1633        ;
1634        ;
1635        ;
1636        ;
1637        ;
1638        ;
1639        ;
1640        ;
1641        ;
1642        ;
1643        ;
1644        ;
1645        ;
1646        ;
1647        ;
1648        ;
1649        ;
1650        ;
1651        ;
1652        ;
1653        ;
1654        ;
1655        ;
1656        ;
1657        ;
1658        ;
1659        ;
1660        ;
1661        ;
1662        ;
1663        ;
1664        ;
1665        ;
1666        ;
1667        ;
1668        ;
1669        ;
1670        ;
1671        ;
1672        ;
1673        ;
1674        ;
1675        ;
1676        ;
1677        ;
1678        ;
1679        ;
1680        ;
1681        ;
1682        ;
1683        ;
1684        ;
1685        ;
1686        ;
1687        ;
1688        ;
1689        ;
1690        ;
1691        ;
1692        ;
1693        ;
1694        ;
1695        ;
1696        ;
1697        ;
1698        ;
1699        ;
1700        ;
1701        ;
1702        ;
1703        ;
1704        ;
17
```

CZUDIAO UDA50-A/KDA50-G DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 150-1

TEST 1: DISK EXERCISER

```

59 021570 001002          BNE      T4PRM3
60 021572 005237 002210  T4PRM3: INC      UCNT
61 021576 005302          DEC      R2          ;COUNT DRIVE TABLES
62 021600 001360          BNE      T4PRM2      ;GO LOOK AT NEXT
63 021602 062705 000034  T4PRM4: ADD     @C.SIZE,R5 ;GO TO NEXT CONTROLLER
64 021606 005715          TST     (R5)         ; IF THERE IS ONE
65 021610 001347          BNE      T4PRM1
66
67
68
69 021612 012701 002256  MOV     @PAT16C,R1    ; R1 -> PAT16C FOR INPUT
70 021616 004737 024014  CALL    T4QUE2        ; ASK LAST OF THE CZUDIO QUESTIONS
71
72 021622          BR      ASSUME PAT16W EQ PAT16C*2
73 021622 000436          T4RUN
74
75
76
77 021624          ; GIVE WARNING MANUAL INTERVENTION NOT ALLOWED, IF NEEDED
78
79
80
81 021634 013705 002170  T4DEF:  MOV     CTABS,R5 ;GET ADDRESS OF 1ST CONTROLLER TABLE
82 021640 012702 000004  T4DEFA: MOV     @4.,R2   ;GET COUNT OF DRIVE TABLES
83 021644 010504          MOV     R5,R4        ;GET FIRST DRIVE TABLE POINTER
84 021646 062704 000016  ADD     @C.DRO,R4
85 021652 012403          T4DEFB: MOV     (R4),R3 ;GET DRIVE TABLE ADDRESS
86 021654 001415          BEQ     T4DEFE        ;GO TO NEXT CONTROLLER IF NONE
87 021656 062703 000004  ADD     @D.PRM,R3
88 021662 042713 157777  BIC     @1C<D.DCY>,(R3) ;INITIALIZE ALL PARAMETER BITS
89 021666 052723 011012  BIS     @DDEF,(R3)
90 021672 012700 000067  MOV     @55.,R0
91 021676 005023          T4DEFC: CLR     (R3)
92 021700 005300          DEC     R0
93 021702 001375          BNE     T4DEFC
94 021704 005302          T4DEFD: DEC     R2          ;COUNT DRIVE TABLES
95 021706 001361          BNE     T4DEFB        ;GO LOOK AT NEXT
96 021710 062705 000034  T4DEFE: ADD     @C.SIZE,R5 ;GO TO NEXT CONTROLLER
97 021714 005715          TST     (R5)         ; IF THERE IS ONE
98 021716 001350          BNE     T4DEFA
99
100
101
102 021720 006137 002200  T4RUN:  ROL     IFLAGS ;CLEAR FLAGS FOR NEXT TIME HERE
103 021724 042737 177757 002200  BIC     @1C<ISTRTH>,IFLAGS ;HOLD START FOR DMRQ4 REQUEST
104
105
106 021732 013737 002170 002174  MOV     @1,R1        ;INITIALIZE TEST PARAMETERS
107 021740 013701 002172          CALL    TINIT
108 021744 004737 010300          MOV     CTABS,TSTTAB ;GET ADDRESS OF 1ST CONTROLLER TABLE
109 021750 001402          MOV     CTRLRS,R1    ;RUN DM PROGRAM ON ALL CONTROLLERS
110 021752 004737 010374          CALL    RUNDH
111 021756 032737 001000 002144  T4WAIT: BEQ     T4WAIT        ;CHECK IF LOG IS ENABLED
112 021764 001402          CALL    RESPDM      ;EXIT IF NOT
113
114 021766          BEQ     T4EXIT
114 021766 104422          BREAK
TRAP          C#BRK

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 150-2  
TEST 1: DISK EXERCISER

115 021770 000772  
116 021772  
117 021772  
021772 104424  
118 021774  
021774 104432  
021776 003712  
119

T4EXIT: BR T4WAIT  
DORPT  
TRAP C:DRPT  
EXIT TST  
TRAP C:EXIT  
.WORD L10032-.

;WAIT TILL STOPPED BY CONTROL C  
;PRINT A STATISTICAL REPORT

```

1      .SBTTL CZUDIO QUESTIONS
2
3      ;**
4      ; ASK CZUDIO MANUAL INTERVENTION QUESTIONS
5      ;
6      ; INPUTS:
7      ; R5 - POINTER TO CONTROLLER TABLE
8      ; R3 - POINTER TO DRIVE TABLE
9      ; R2 AND R4 MUST BE PRESERVED
10     ;
11     ; OUTPUTS:
12     ; DRIVE TABLE WITH NEW PARAMETERS
13     ; R0 AND R1 CONTENTS DESTROYED
14     ;--
15     022000 T4QUES: PUSH <R2,R4>
16     022004 PRINTF @T4QHED,D,UNIT(R3),(R5),(R3) ;PRINT HEADER
17     022004 011346 MOV (R3),-(SP)
18     022006 011546 MOV (R5),-(SP)
19     022010 016346 000002 MOV D,UNIT(R3),-(SP)
20     022014 012746 025127 MOV @T4QHED,-(SP)
21     022020 012746 000004 MOV @4,-(SP)
22     022024 010600 MOV SP,R0
23     022026 104417 TRAP C@PNTF
24     022030 062706 000012 ADD @12,SP
25     17 022034 016337 000010 002214 MOV D,BB(R3),TEMP
26     18 022042 GMANID T48B,TEMP,D,-1,0,16,,YES ;NUMBER OF BAD BLOCKS
27     022042 104443 TRAP C@GMAN
28     022044 000406 BR 100006
29     022046 002214 .WORD TEMP
30     022050 000052 .WORD T@CODE
31     022052 024122 .WORD T48B
32     022054 177777 .WORD -1
33     022056 000000 .WORD T@L@LIM
34     022060 000020 .WORD T@H@LIM
35     022062 100006:
36     19 022062 013763 002214 000010 MOV TEMP,D,BB(R3)
37     20 022070 001424 BEQ T4Q02
38     21
39     22 022072 010304 MOV R3,R4 ;GET POINTER TO STORAGE
40     23 022074 062704 000012 ADD @D,BB@1,R4 ; FOR BAD BLOCKS
41     24 022100 013701 002214 MOV TEMP,R1 ;GET COUNT OF BLOCKS TO INPUT
42     25 022104 004737 013740 T4Q01: CALL BLD28 ;BUILD DEFAULT ANSWER
43     26 022110 GMANID T48BI,TEMP,A,-1,0,9,,YES ;BAD BLOCK
44     022110 104443 TRAP C@GMAN
45     022112 000406 BR 100016
46     022114 002214 .WORD TEMP
47     022116 000152 .WORD T@CODE
48     022120 024220 .WORD T48BI
49     022122 177777 .WORD -1
50     022124 000000 .WORD T@L@LIM
51     022126 000011 .WORD T@H@LIM
52     022130 100016:
53     27 022130 004737 014042 CALL CNV28 ;CONVERT TO BINARY
54     28 022134 103763 BCS T4Q01 ;REPEAT UNTIL RIGHT
55     29 022136 005301 DEC R1 ;DECREMENT COUNT
56     30 022140 001361 BNE T4Q01 ;GET ALL NUMBERS
57     31 022142 T4Q02:

```



CZUDIA0 UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 151-1  
 CZUDIO QUESTIONS

```

32 022142 005037 025706          CLR          ANYMOR          ; DEFAULT ANYMORE WITH 0
33 022146          GMANIL      T4DMN, ANYMOR, ANY.YS, YES
   022146 104443          TRAP          C#GMAN
   022150 000404          BR           10002#
   022152 025706          .WORD       ANYMOR
   022154 000130          .WORD       T#CODE
   022156 024147          .WORD       T4DMN
   022160 000001          .WORD       ANY.YS
   022162          10002#:
34 022162 032737 000001 025706    BIT          #ANY.YS, ANYMOR    ; DO WE ASK ANY MORE QUESTIONS?
35 022170 001002          BNE         1#                 ; IF SO, CONTINUE
36 022172 000137 024006          JMP         T4Q30              ; ELSE EXIT
37 022176          1#:
38 022176 016337 000004 002214    MOV D.PRM(R3), TEMP          ; GET PARAMETER BITS
39 022204          GMANIL      T4RO, TEMP, D.RO, YES ; READ ONLY?
   022204 104443          TRAP          C#GMAN
   022206 000404          BR           10003#
   022210 002214          .WORD       TEMP
   022212 000130          .WORD       T#CODE
   022214 024232          .WORD       T4RO
   022216 004000          .WORD       D.RO
   022220          10003#:
40 022220 032737 004000 002214    BIT #D.RO, TEMP              ; CHECK IF READ ONLY
41 022226 001404          BEQ        T4Q03              ; IF NOT, GO TO WRITE ONLY QUESTION
42 022230 042737 002000 002214    BIC #D.WO, TEMP              ; ELSE, CLEAR WRITE ONLY BIT
43 022236 000432          BR         T4Q05              ; AND BRANCH AROUND WRITE ONLY QUESTION
44 022240          T4Q03:
45 022240          GMANIL      T4WO, TEMP, D.WO, YES ; WRITE ONLY?
   022240 104443          TRAP          C#GMAN
   022242 000404          BR           10004#
   022244 002214          .WORD       TEMP
   022246 000130          .WORD       T#CODE
   022250 024244          .WORD       T4WO
   022252 002000          .WORD       D.WO
   022254          10004#:
46 022254          GMANIL      T4WCA, TEMP, D.WCA, YES ; CHECK ALL WRITES
   022254 104443          TRAP          C#GMAN
   022256 000404          BR           10005#
   022260 002214          .WORD       TEMP
   022262 000130          .WORD       T#CODE
   022264 024257          .WORD       T4WCA
   022266 000004          .WORD       D.WCA
   022270          10005#:
47 022270 032737 000004 002214    BIT #D.WCA, TEMP              ; CHECK ANSWER
48 022276 001007          BNE        T4Q04              ; BRANCH IF YES
49 022300          GMANIL      T4WCR, TEMP, D.WC, YES ; RANDOMLY CHECK WRITES
   022300 104443          TRAP          C#GMAN
   022302 000404          BR           10006#
   022304 002214          .WORD       TEMP
   022306 000130          .WORD       T#CODE
   022310 024313          .WORD       T4WCR
   022312 000010          .WORD       D.WC
   022314          10006#:
50 022314 000403          BR         T4Q05
51 022316 052737 000010 002214    T4Q04: BIS #D.WC, TEMP          ; BOTH BITS GET SET
52 022324 013763 002214 000004    T4Q05: MOV TEMP, D.PRM(R3)          ; PUT PARAM BITS BACK
53 022332 016337 000006 002214    MOV D.PAT(R3), TEMP

```



75	022544	005137	002214	100134:	COM TEMP	
76	022550	104443			GMANIL T4SEK,TEMP,D.SEQ,YES	;ENABLE SEEKS
	022552	000404			TRAP C#GMAN	
	022554	002214			BR 100144	
	022556	000130			.WORD TEMP	
	022560	024555			.WORD T#CODE	
	022562	000100			.WORD T4SEK	
	022564				.WORD D.SEQ	
77	022564	005137	002214	100144:	COM TEMP	;COMPLIMENTED
78	022570	013763	002214		MOV TEMP,D.PRM(R3)	
79						
80	022576	005037	002214		CLR TEMP	;DETERMINE DEFAULT SELECTION
81	022602	032763	000040		BIT #D.BE,D.PRM(R3)	;IF D.BE SET - LOAD 1
82	022610	001403			BEQ T4Q10	;IF D.CYL CLEAR - LOAD 0
83	022612	005237	002214		INC TEMP	;IF D.BEC CONTAINS 0 - LOAD 4
84	022616	000422			BR T4Q11	;IF D.TR SET - LOAD 2
85	022620	032763	000400	000004	T4Q10: BIT #D.CYL,D.PRM(R3)	;LOAD 3
86	022626	001416			BEQ T4Q11	
87	022630	012737	000004	002214	MOV #4,TEMP	
88	022636	005763	000112		TST D.BEC(R3)	
89	022642	001410			BEQ T4Q11	
90	022644	005337	002214		DEC TEMP	
91	022650	032763	000020	000004	BIT #D.TR,D.PRM(R3)	
92	022656	001402			BEQ T4Q11	
93	022660	005337	002214		DEC TEMP	
94	022664				T4Q11: PRINTF #T4OPT1	; ENTER AREA DESIRED:
	022664	012746	025247		MOV #T4OPT1,-(SP)	
	022670	012746	000001		MOV #1,-(SP)	
	022674	010600			MOV SP,R0	
	022676	104417			TRAP C#PNTF	
	022700	062706	000004		ADD #4,SP	
95	022704				PRINTF #T4OPT2	; 0 - ENTIRE DISK AREA
	022704	012746	025306		MOV #T4OPT2,-(SP)	
	022710	012746	000001		MOV #1,-(SP)	
	022714	010600			MOV SP,R0	
	022716	104417			TRAP C#PNTF	
	022720	062706	000004		ADD #4,SP	
96	022724				PRINTF #T4OPT3	; 1 - BEGIN/END SETS
	022724	012746	025342		MOV #T4OPT3,-(SP)	
	022730	012746	000001		MOV #1,-(SP)	
	022734	010600			MOV SP,R0	
	022736	104417			TRAP C#PNTF	
	022740	062706	000004		ADD #4,SP	
97	022744				PRINTF #T4OPT4	; 2 - TRACKS & CYLINDERS
	022744	012746	025405		MOV #T4OPT4,-(SP)	
	022750	012746	000001		MOV #1,-(SP)	
	022754	010600			MOV SP,R0	
	022756	104417			TRAP C#PNTF	
	022760	062706	000004		ADD #4,SP	
98	022764				PRINTF #T4OPT5	; 3 - GROUPS & CYLINDERS
	022764	012746	025454		MOV #T4OPT5,-(SP)	
	022770	012746	000001		MOV #1,-(SP)	
	022774	010600			MOV SP,R0	
	022776	104417			TRAP C#PNTF	
	023000	062706	000004		ADD #4,SP	

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 151-4  
 CZUDIO QUESTIONS

99	023004				PRINTF	@T4OPT6			: 4 - CYLINDERS ONLY
	023004	012746	025523		MOV	@T4OPT6, -(SP)			
	023010	012746	000001		MOV	@1, -(SP)			
	023014	010600			MOV	SP, R0			
	023016	104417			TRAP	C#PNTF			
	023020	062706	000004		ADD	@4, SP			
100	023024				GMANID	T4OPT7, TEMP, D, -1, 0, 4, YES;			
	023024	104443			TRAP	C#GMAN			
	023026	000406			BR	100154			
	023030	002214			.WORD	TEMP			
	023032	000052			.WORD	T#CODE			
	023034	002462			.WORD	T4OPT7			
	023036	177777			.WORD	-1			
	023040	000000			.WORD	T#LOLIM			
	023042	000004			.WORD	T#HILIM			
	023044			100154:					
101	023044	005337	002214		DEC	TEMP			: CHECK ANSWER
102	023050	002004			BGE	T4Q12			: IF NOT 0, SKIP
103	023052	042763	000440	000004	BIC	@D.BE, D.CYL, D.PRM(R3)			: ELSE, CLEAR D.BE AND D.CYL
104	023060	000467			BR	T4Q19			: EXIT QUESTIONS
105	023062	005337	002214		T4Q12:	DEC	TEMP		: CHECK ANSWER
106	023066	002013			BGE	T4Q13			: IF NOT 1, SKIP
107	023070	032763	000040	000004	BIT	@D.BE, D.PRM(R3)			: CHECK D.BE
108	023076	001060			BNE	T4Q19			: BRANCH IF D.BE SET
109	023100	052763	000040	000004	BIS	@D.BE, D.PRM(R3)			: SET B/E SET FLAG
110	023106	042763	000400	000004	BIC	@D.CYL, D.PRM(R3)			: CLEAR CYLINDER FLAG
111	023114	000436			BR	T4Q16			: GET B/E SETS
112	023116	042763	000040	000004	T4Q13:	BIC	@D.BE, D.PRM(R3)		: CLEAR B/E SET FLAG
113	023124	022737	000002	002214	CMF	@2, TEMP			
114	023132	001006			BNE	T4Q14			: IF NOT 4, SKIP
115	023134	052763	000400	000004	BIS	@D.CYL, D.PRM(R3)			: SET CYLINDER FLAG
116	023142	005063	000112		CLR	D.BEC(R3)			: CLEAR B/E SET COUNT
117	023146	000434			BR	T4Q19			: GET CYLINDERS
118	023150				T4Q14:	PUSH	D.PRM(R3)		: IF 2 OR 3
119	023154	052763	000420	000004	BIS	@D.CYL, D.TR, D.PRM(R3)			: SAVE D.PRM BITS
120	023162	005337	002214		DEC	TEMP			: SET D.CYL AND D.TR
121	023166	001403			BEQ	T4Q15			: IF 3
122	023170	042763	000020	000004	BIC	@D.TR, D.PRM(R3)			: CLEAR TRACK FLAG
123	023176	022663	000004		T4Q15:	CMF	(SP), D.PRM(R3)		: CHECK OLD PARAMETER BITS
124	023202	001003			BNE	T4Q16			: IF D.CYL OR D.TR CHANGED, SKIP
125	023204	005763	000112		TST	D.BEC(R3)			: CHECK B/E SET COUNT
126	023210	001013			BNE	T4Q19			: IF NOT 0, GET CYLINDERS
127	023212	012763	000001	000112	T4Q16:	MOV	@1, D.BEC(R3)		: LOAD 1 INTO B/E SET COUNT
128	023220	010304			T4Q17:	MOV	R3, R4		: GET POINTER TO DRIVE TABLE
129	023222	062704	000114		ADD	@D.BGN1, R4			: POINT TO 1ST B/E SET
130	023226	012701	000020		MOV	@16, R1			: GET COUNT OF WORDS TO CLEAR
131	023232	005024			T4Q18:	CLR	(R4)		: CLEAR A WORD
132	023234	005301			DEC	R1			: DECREMENT WORD COUNTER
133	023236	001375			BNE	T4Q18			: IF NOT DONE, LOOP
134	023240	032763	000040	000004	T4Q19:	BIT	@D.BE, D.PRM(R3)		: CHECK IF WE'RE USING B/E SETS
135	023246	001460			BEQ	T4Q22			: IF D.BE CLEAR, USE CYLINDERS
136	023250	016337	000112	002214	MOV	D.BEC(R3), TEMP			: GET PREVIOUS B/E SET COUNT
137	023256				GMANID	T4BE, TEMP, D, -1, 1, 4, YES			: NUMBER OF B/E SETS?
	023256	104443			TRAP	C#GMAN			
	023260	000406			BR	100164			
	023262	002214			.WORD	TEMP			
	023264	000052			.WORD	T#CODE			

```

023266 024600 .WORD T48E
023270 177777 .WORD -1
023272 000001 .WORD T%LOLIM
023274 000004 .WORD T%HILIM
023276
138 023276 013763 002214 000112 100164: MOV TEMP,D.BEC(R3) ; SAVE NEW B/E SET COUNT
139 023304 013701 002214 MOV TEMP,R1 ; INIT LOOP COUNTER
140 023310 010304 MOV R3,R4 ; GET POINTER TO STORAGE AREA
141 023312 062704 000114 ADD #D.BGN1,R4 ; POINT TO START OF 1ST B/E SET
142 023316 004737 013740 T4Q20: CALL BLD28 ; BUILD DEFAULT VALUE
143 023322 GMANID T4BEG,TEMP,A,-1,0,9.,YES; BEGIN BLOCK?
023322 104443 TRAP C%GMAN
023324 000406 BR 100174
023326 002214 .WORD TEMP
023330 000152 .WORD T%CODE
023332 024631 .WORD T4BEG
023334 177777 .WORD -1
023336 000000 .WORD T%LOLIM
023340 000011 .WORD T%HILIM
023342
144 023342 004737 014042 100174: CALL CNV28 ; CHECK RESPONSE & SAVE IN TABLE
145 023346 103763 BCS T4Q20 ; BRANCH ON ERROR
146 023350 004737 013740 T4Q21: CALL BLD28 ; BUILD DEFAULT VALUE
147 023354 GMANID T4END,TEMP,A,-1,0,9.,YES; END BLOCK?
023354 104443 TRAP C%GMAN
023356 000406 BR 100204
023360 002214 .WORD TEMP
023362 000152 .WORD T%CODE
023364 024645 .WORD T4END
023366 177777 .WORD -1
023370 000000 .WORD T%LOLIM
023372 000011 .WORD T%HILIM
023374
148 023374 004737 014042 100204: CALL CNV28 ; CHECK RESPONSE & SAVE IN TABLE
149 023400 103763 BCS T4Q21 ; BRANCH ON ERROR
150 023402 005301 DEC R1 ; DECREMENT LOOP COUNT
151 023404 001344 BNE T4Q20 ; IF NOT DONE, LOOP
152 023406 000577 BR T4Q30 ; ELSE, EXIT QUESTIONS
153 023410 032763 000400 000004 T4Q22: BIT #D.CYL,D.PRM(R3) ;IF D.CYL CLEAR - ALL DONE
154 023416 001573 BEQ T4Q30
155 023420 005763 000112 TST D.BEC(R3) ;IF D.BEC CLEAR - GO RIGHT TO B/E CYLS
156 023424 001526 BEQ T4Q27
157 023426 010304 MOV R3,R4
158 023430 062704 000112 ADD #D.BEC,R4
159 023434 032763 000020 000004 BIT #D.TR,D.PRM(R3) ;LOOK AT D.TR.TO DETERMINE QUESTION
160 023442 001434 BEQ T4Q24
161 023444 011437 002214 MOV (R4),TEMP
162 023450 GMANID T4TRC,TEMP,D,-1,1,7.YES ;NUMBER OF TRACKS
023450 104443 TRAP C%GMAN
023452 000406 BR 100214
023454 002214 .WORD TEMP
023456 000052 .WORD T%CODE
023460 024657 .WORD T4TRC
023462 177777 .WORD -1
023464 000001 .WORD T%LOLIM
023466 000007 .WORD T%HILIM
023470 100214:

```

163	023470	013714	002214		MOV TEMP,(R4)	
164	023474	012401			MOV (R4),R1	;GET COUNT OF TRACKS
165	023476	011437	002214	T4Q23:	MOV (R4),TEMP	
166	023502				GMANID T4TRAK,TEMP,D,-1,0,255.,YES	;TRACK
	023502	104443			TRAP C#GMAN	
	023504	000406			BR 100224	
	023506	002214			.WORD TEMP	
	023510	000052			.WORD T#CODE	
	023512	024710			.WORD T4TRAK	
	023514	177777			.WORD -1	
	023516	000000			.WORD T#LOLIM	
	023520	000377			.WORD T#HILIM	
	023522			100224:		
167	023522	013724	002214		MOV TEMP,(R4)	
168	023526	005301			DEC R1	
169	023530	001362			BNE T4Q23	
170	023532	000433			BR T4Q26	
171	023534	011437	002214	T4Q24:	MOV (R4),TEMP	
172	023540				GMANID T4GRC,TEMP,D,-1,1,7.YES	;NUMBER OF GROUPS
	023540	104443			TRAP C#GMAN	
	023542	000406			BR 100234	
	023544	002214			.WORD TEMP	
	023546	000052			.WORD T#CODE	
	023550	024716			.WORD T4GRC	
	023552	177777			.WORD -1	
	023554	000001			.WORD T#LOLIM	
	023556	000007			.WORD T#HILIM	
	023560			100234:		
173	023560	013714	002214		MOV TEMP,(R4)	
174	023564	012401			MOV (R4),R1	;GET COUNT OF GROUPS
175	023566	011437	002214	T4Q25:	MOV (R4),TEMP	
176	023572				GMANID T4GRP,TEMP,D,-1,0,255.,YES	;GROUP
	023572	104443			TRAP C#GMAN	
	023574	000406			BR 100244	
	023576	002214			.WORD TEMP	
	023600	000052			.WORD T#CODE	
	023602	024747			.WORD T4GRP	
	023604	177777			.WORD -1	
	023606	000000			.WORD T#LOLIM	
	023610	000377			.WORD T#HILIM	
	023612			100244:		
177	023612	013724	002214		MOV TEMP,(R4)	
178	023616	005301			DEC R1	
179	023620	001362			BNE T4Q25	
180	023622	016337	000162	002214	T4Q26:	MOV D.ECYL+2(R3),TEMP
181	023630	005137	002214		COM TEMP	
182	023634				GMANIL T4CYL,TEMP,BIT15,YES	;WISH TO LIMIT CYLINDERS
	023634	104443			TRAP C#GMAN	
	023636	000404			BR 100254	
	023640	002214			.WORD TEMP	
	023642	000130			.WORD T#CODE	
	023644	024755			.WORD T4CYL	
	023646	100000			.WORD BIT15	
	023650			100254:		
183	023650	005737	002214		TST TEMP	
184	023654	100412			BMI T4Q27	
185	023656	005063	000154		CLR D.BCYL(R3)	

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 151-7  
 CZUDIO QUESTIONS

186	023662	005063	000156		CLR D.BCYL+2(R3)	
187	023666	005063	000160		CLR D.ECYL(R3)	
188	023672	012763	177777	000162	MOV #-1,D.ECYL+2(R3)	
189	023700	000442			BR T4Q30	
190	023702	005763	000162	T4Q27:	TST D.ECYL+2(R3)	
191	023706	002002			BGE T4Q27A	
192	023710	005063	000162	T4Q27A:	CLR D.ECYL+2(R3)	
193	023714	010304			MOV R3,R4	
194	023716	062704	000154		ADD #D.BCYL,R4	
195	023722	004737	013740	T4Q28:	CALL BLD28	
196	023726				GMANID T4CYLB,TEMP,A,-1,0,9.,YES	; STARTING CYLINDER
	023726	104443			TRAP C#GMAN	
	023730	000406			BR 10026+	
	023732	002214			.WORD TEMP	
	023734	000152			.WORD T#CODE	
	023736	025010			.WORD T4CYLB	
	023740	177777			.WORD -1	
	023742	000000			.WORD T#LOLIM	
	023744	000011			.WORD T#HILIM	
	023746			10026+:		
197	023746	004737	014042		CALL CNV28	
198	023752	103763			BCS T4Q28	
199	023754	004737	013740	T4Q29:	CALL BLD28	
200	023760				GMANID T4CYL,TEMP,A,-1,0,9.,YES	; ENDING CYLINDER
	023760	104443			TRAP C#GMAN	
	023762	000406			BR 10027+	
	023764	002214			.WORD TEMP	
	023766	000152			.WORD T#CODE	
	023770	025032			.WORD T4CYL	
	023772	177777			.WORD -1	
	023774	000000			.WORD T#LOLIM	
	023776	000011			.WORD T#HILIM	
	024000			10027+:		
201	024000	004737	014042		CALL CNV28	
202	024004	103763			BCS T4Q29	
203	024006			T4Q30:	POP <R4,R2>	
204	024012	000207			RETURN	
205					; NOW GET DATA PATTERN 16 IF SELECTED BY ANY DRIVE	
206					;	
207					;	
208					INPUT R1 POINTS TO PATTERN 16 SIZE	
209	024014			T4QUE2:		
210	024014	032737	000001	025706	BIT #ANY.YS,ANYMOR	; DO WE ASK THESE QUESTIONS?
211	024022	001436			BEG T4QUE2	; IF NOT, EXIT
212	024024	011137	002214		MOV (R1),TEMP	
213	024030				GMANID T4DPC,TEMP,D,-1,0,16.,YES; COUNT OF WORDS	
	024030	104443			TRAP C#GMAN	
	024032	000406			BR 10030+	
	024034	002214			.WORD TEMP	
	024036	000052			.WORD T#CODE	
	024040	025052			.WORD T4DPC	
	024042	177777			.WORD -1	
	024044	000000			.WORD T#LOLIM	
	024046	000020			.WORD T#HILIM	
	024050			10030+:		
214	024050	013721	002214		MOV TEMP,(R1)+	; GET COUNT OF WORDS
215	024054	010104			MOV R1,R4	; R4 HAS ADDRESS OF STORAGE

## CZUDIO QUESTIONS

```

216 024056 013701 002214      MOV    TEMP,R1
217 024062 001416              BEQ    T4QU2E          ; IF 0, NO DATA WORDS
218 024064 011437 002214      T4PRM5: MOV (R4),TEMP
219 024070              GMANID T4DPD,TEMP,0,-1,0,-1,YES ;DATA WORD
      024070 104443          TRAP   C#GMAN
      024072 000406          BR     10031#
      024074 002214          .WORD TEMP
      024076 000032          .WORD T#CODE
      024100 025115          .WORD T4DPD
      024102 177777          .WORD -1
      024104 000000          .WORD T#LOLIM
      024106 177777          .WORD T#HILIM
      024110              10031#:
220 024110 013724 002214      MOV TEMP,(R4)
221 024114 005301              DEC R1          ;COUNT THE WORDS
222 024116 001362              BNE T4PRM5
223 024120 000207      T4QU2E: RETURN
224

```



```

1
2      ; UNFORMATTED QUESTIONS
3
4
5 024122      116      125      115  T4BB: .ASCIZ\NUMBER OF BAD BLOCKS\
6 024147      103      110      101  T4DMN: .ASCIZ\CHANGE TESTING PARAMETERS FOR THIS DRIVE\
7 024220      102      101      104  T4BBI: .ASCIZ\BAD BLOCK\
8 024232      122      105      101  T4RO: .ASCIZ\READ ONLY\
9 024244      127      122      111  T4WO: .ASCIZ\WRITE ONLY\
10 024257     103      110      105  T4WCA: .ASCIZ\CHECK ALL WRITES BY READING\
11 024313     122      101      116  T4WCR: .ASCIZ\RANDOMLY CHECK WRITES BY READING\
12 024354     104      101      124  T4DP: .ASCIZ\DATA PATTERN - 0 FOR RANDOM SELECTION\
13 024422     105      116      101  T4ECC: .ASCIZ\ENABLE ECC DATA CORRECTION\
14 024455     103      117      115  T4DCA: .ASCIZ\COMPARE ALL DATA READ\
15 024503     122      101      116  T4DCR: .ASCIZ\RANDOMLY COMPARE DATA READ\
16 024536     105      116      101  T4RET: .ASCIZ\ENABLE RETRIES\
17 024555     122      101      116  T4SEK: .ASCIZ\RANDOM ACCESS MODE\
18 024600     116      125      115  T4BE: .ASCIZ\NUMBER OF BEGIN/END SETS\
19 024631     102      105      107  T4BEG: .ASCIZ\BEGIN BLOCK\
20 024645     105      116      104  T4END: .ASCIZ\END BLOCK\
21 024657     116      125      115  T4TRC: .ASCIZ\NUMBER OF TRACKS TO TEST\
22 024710     124      122      101  T4TRAK: .ASCIZ\TRACK\
23 024716     116      125      115  T4GRC: .ASCIZ\NUMBER OF GROUPS TO TEST\
24 024747     107      122      117  T4GRP: .ASCIZ\GROUP\
25 024755     114      111      115  T4CYL: .ASCIZ\LIMIT THE CYLINDERS TESTED\
26 025010     123      124      101  T4CYLB: .ASCIZ\STARTING CYLINDER\
27 025032     105      116      104  T4CYLE: .ASCIZ\ENDING CYLINDER\
28 025052     116      125      115  T4DPC: .ASCIZ\NUMBER OF WORDS IN DATA PATTERN 16\
29 025115     104      101      124  T4DPD: .ASCIZ\DATA WORD\
30
31      ; FORMATTED QUESTIONS
32
33 025127     045      116      045  T4QMED: .ASCIZ\#N#THE FOLLOWING QUESTIONS REFER TO UNIT #D2#A CONTROLLER AT #06#A DRIVE #D3
34 025247     045      116      045  T4OPT1: .ASCIZ\#N#ENTER TEST AREA DESIRED:#N\
35 025306     045      101      040  T4OPT2: .ASCIZ\#A 0 - ENTIRE DISK AREA#N\
36 025342     045      101      040  T4OPT3: .ASCIZ\#A 1 - SPECIFIC BEGIN/END SETS#N\
37 025405     045      101      040  T4OPT4: .ASCIZ\#A 2 - SPECIFIC TRACKS & CYLINDERS#N\
38 025454     045      101      040  T4OPT5: .ASCIZ\#A 3 - SPECIFIC GROUPS & CYLINDERS#N\
39 025523     045      101      040  T4OPT6: .ASCIZ\#A 4 - SPECIFIC CYLINDERS\
40 025557     045      101      114  INP28A: .ASCIZ\#ALIMITS - LO= 0, HI= 268435455#N\
41 025621     045      101      111  INP28B: .ASCIZ\#AINVALID CHAR, TYPE DECIMAL NUMBER 0 TO 268435455#N\
42      .EVEN
43
44 025706     000000      ANYMOR: .WORD 0 ; ANY MORE QUESTIONS
45      000001      ANY.YS = BITO
46
47 025710      ENDTST
      025710      L10032:
      025710 104401      TRAP C#ETST
48
49
50

```

```

1      .SBTTL  HARDWARE PARAMETER CODING SECTION
2
3      ;**
4      ;   THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
5      ;   THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
6      ;   MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
7      ;   INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
8      ;   MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
9      ;   WITH THE OPERATOR.
10     ;--
11     025712      BGNHRD
12     025712      .WORD L10033-L#HARD/2
13     025714      L#HARD::
14     025714      TABLE                                ;START A TABLE DEFINITION
15     025714      ITEM H.UBA          2          <CSR ADDRESS>
16     025714      ITEM H.DRV          2          <DRIVE NUMBER>
17     025714      ITEM H.PRM          2          <PROGRAM PARAMETERS>
18
19     025714      HM.CYL  == BIT13                      ; TEST CUSTOMER DATA AREA
20
21     025714      END                                  ; CSR ADDRESS OF CONTROLLER?
22
23     025714      GPRMA  MSGUBA,H.UBA,0,160000,177774,YES
24     025714      .WORD  T#CODE
25     025714      .WORD  MSGUBA
26     025716      .WORD  T#LOLIM
27     025720      .WORD  T#HILIM
28     025722      177774
29
30
31
32
33
34
35     025724      GPRMD  MSGLDR,H.DRV,D,-1,0,,255,,YES
36     025724      .WORD  T#CODE
37     025726      .WORD  MSGLDR
38     025730      .WORD  -1
39     025732      .WORD  T#LOLIM
40     025734      .WORD  T#HILIM
41
42
43
44
45
46
47
48
49
50     025736      GPRML  MSGCST,H.PRM,HM.CYL,YES
51     025736      .WORD  T#CODE
52     025740      .WORD  MSGCST
53     025742      .WORD  HM.CYL
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
    
```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 154  
SOFTWARE PARAMETER CODING SECTION

```

1      .SBTTL  SOFTWARE PARAMETER CODING SECTION
2
3      : **
4      : THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
5      : THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
6      : MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
7      : INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
8      : MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
9      : WITH THE OPERATOR.
10     : **
11
12     BGNSFT
13     .WORD L10034-L#SOFT/2
14     L#SOFT::
15     TABLE ; START A TABLE DEFINITION
16     ITEM SO.EL 2 <ERROR LIMIT>
17     ITEM SO.XL 2 <DATA TRANSFER LIMIT (MEGABITS)>
18     ITEM SO.BIT 2 <SINGLE BIT ANSWERS>
19
20     SM.MAN == BIT07 ; MANUAL INTERVENTION MODE
21     SM.SSF == BIT08 ; SUPPRESS SOFT ERRORS
22     SM.LOG == BIT09 ; ERROR LOG ENABLED
23     SM.IW == BIT14 ; INITIAL WRITE
24     END
25
26     ; ENTER MANUAL INTERVENTION MODE
27     ; FOR SPECIAL DIAGNOSIS?'
28
29     GPRML S.MAN,SO.BIT,SM.MAN,YES
30     .WORD T#CODE
31     .WORD S.MAN
32     .WORD SM.MAN
33     ; ERROR LIMIT?
34
35     GPRMD S.EL,SO.EL,D,-1,1...-1..YES
36     .WORD T#CODE
37     .WORD S.EL
38     .WORD -1
39     .WORD T#LOLIM
40     .WORD T#HILIM
41     ; READ TRANSFER LIMIT IN MEGABYTES
42     ; - 0 FOR NO LIMIT?
43
44     GPRMD S.XL,SO.XL,D,-1,0...-1..YES
45     .WORD T#CODE
46     .WORD S.XL
47     .WORD -1
48     .WORD T#LOLIM
49     .WORD T#HILIM
50     ; SUPPRESS PRINTING SOFT ERRORS?
51
52     GPRML S.SSF,SO.BIT,SM.SSF,YES
53     .WORD T#CODE
54     .WORD S.SSF
55     .WORD SM.SSF
56     ;PRINT 'DO INITIAL WRITE ON START?'
57
58     GPRML S.IW,SO.BIT,SM.IW,YES
59     .WORD T#CODE
60     .WORD S.IW
61     .WORD SM.IW
62     ;PRINT 'ENABLE ERROR LOG?'

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 154-1  
SOFTWARE PARAMETER CODING SECTION

48	026116				GPRML	S.LOG,SO.BIT,SM.LOG,YES
	026116	002130			.WORD	T#CODE
	026120	026377			.WORD	S.LOG
	026122	001000			.WORD	SM.LOG
55	026124				ENDSFT	
					.EVEN	
	026124			L10034:		
56						
61	026124	105	116	124	S.MAN:	.ASCIZ \ENTER MANUAL INTERVENTION MODE FOR SPECIAL DIAGNOSIS\
62	026211	105	122	122	S.EL:	.ASCIZ \ERROR LIMIT\
63	026225	122	105	101	S.XL:	.ASCIZ \READ TRANSFER LIMIT IN MEGABYTES - 0 FOR NO LIMIT\
64	026307	123	125	120	S.SSF:	.ASCIZ \SUPPRESS PRINTING SOFT ERRORS\
65	026345	104	117	040	S.IW:	.ASCIZ \DO INITIAL WRITE ON START\
66	026377	105	116	101	S.LOG:	.ASCIZ \ENABLE ERROR LOG\
71					.EVEN	
72						

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 155  
 SOFTWARE PARAMETER CODING SECTION

```

1          ;**
2          ;   THIS IS WHERE THE DM PROGRAMS WILL BE LINKED
3          ;--
4
5          .DSABL AMA
6 000000   .PSECT DM,ABS           ; DM PROGRAMS ARE LINKED HERE
7 000000   .PSECT END
8
9          ;**
10         ;   THIS IS A PATCH AREA THAT SHOULD BE INCLUDED IN ALL DIAGNOSTICS.
11         ;   THE SIZE IS ADJUSTED AS NEEDED.
12         ;--
13
14         #PATCH::
15         .BLKW 16.
16
17         LASTAD
18         .EVEN
19         .WORD T#FREE
20         .WORD T#SIZE
21
22         L#LAST::
23
24         000040 000056'
25         000042 000005
26         000044

```

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 156  
SOFTWARE PARAMETER CODING SECTION

```

1
2
3
4
5
6
7
8
9
10
11
12
13 000044          BGNSETUP          1
14 000044          BGNPTAB
   000044 000000    .WORD 0
   000046 000003    .WORD L10037-./2-1
15 000050 172150   L10035: .WORD 172150          ; CSR ADDRESS
20 000052 000000    .WORD 0.             ; DRIVE NUMBER
22 000054 000000    .WORD 0.             ; COSTUMER DATA AREA
24 000056          ENDPTAB
   000056          L10037:
25 000056          ENDSETUP
26          .END
000001

```

## Symbol table

ADR	=	000020	G
ALOCM		007332	
ANYMOR		025706	
ANY.YS	=	000001	
ARG.CT	=	000000	
ASS	=	000004	
ASSEMB	=	000010	
BAS		003654	
BASLN		003655	
BASL1		003573	
BASL2		003611	
BASL3		003637	
BASNO		003533	
BASN4		003552	
BELL	=	000007	G
BIT0	=	000001	G
BIT00	=	000001	G
BIT01	=	000002	G
BIT02	=	000004	G
BIT03	=	000010	G
BIT04	=	000020	G
BIT05	=	000040	G
BIT06	=	000100	G
BIT07	=	000200	G
BIT08	=	000400	G
BIT09	=	001000	G
BIT1	=	000002	G
BIT10	=	002000	G
BIT11	=	004000	G
BIT12	=	010000	G
BIT13	=	020000	G
BIT14	=	040000	G
BIT15	=	100000	G
BIT2	=	000004	G
BIT3	=	000010	G
BIT4	=	000020	G
BIT5	=	000040	G
BIT6	=	000100	G
BIT7	=	000200	G
BIT8	=	000400	G
BIT9	=	001000	G
BLDCMD		014572	
BLDC0		014640	
BLDC1		014646	
BLD28		013740	
BOE	=	000400	G
BRSVAV		002254	
CALR1		012656	
CALR2		012704	
CALR3		013002	
CALR4		013016	
CALR5		013072	
CALR6		013150	
CALR7		013164	
CALR8		013202	
CALR9		013220	
CF.ATN	=	000200	
CF.MSC	=	000100	
CF.OTH	=	000040	
CF.SHD	=	000002	
CF.TMS	=	000020	
CF.576	=	000001	
CLRBFL		014760	
CLRBUF		014732	
CNTINT		015272	
CNTIST		015502	
CNTRSD		002364	
CNTRSP		015776	
CNTRSRV		015156	G
CNV28		014042	
CON.A		007766	
CON.A1		007772	
CON.A2		010014	
CON.D		010016	
CON.H		010030	
CON.N		010054	
CON.N1		010060	
CON.O		010042	
CON.QU		007746	
CON.QX		007764	
CON.R		010076	
CON.R1		010120	
CON.S		010134	
CON.S1		010140	
CR	=	000015	G
CRLF		002544	
CTABS		002170	G
CTRLRS		002172	
CT.AVL	=	100000	
CT.BRL	=	007000	
CT.CMD	=	000004	
CT.MSG	=	000010	
CT.REQ	=	000020	
CT.RN	=	000002	
CT.UNT	=	000077	
CT.VEC	=	000777	
CT.VER	=	000100	
C#AU	=	000052	
C#AUTO	=	000061	
C#BRK	=	000022	
C#BSEG	=	000004	
C#BSUB	=	000002	
C#CEFG	=	000045	
C#CLCK	=	000062	
C#CLEA	=	000012	
C#CLOS	=	000035	
C#CLP1	=	000006	
C#CVEC	=	000036	
C#DCLN	=	000044	
C#DODU	=	000051	
C#DRPT	=	000024	
C#DU	=	000053	
C#EDIT	=	000003	
C#ERDF	=	000055	
C#ERMR	=	000056	
C#ERRO	=	000060	
C#ERSF	=	000054	
C#ERSO	=	000057	
C#ESCA	=	000010	
C#ESEG	=	000005	
C#ESUB	=	000003	
C#ETST	=	000001	
C#EXIT	=	000032	
C#GETB	=	000026	
C#GETW	=	000027	
C#GMAN	=	000043	
C#GPHR	=	000042	
C#GPLO	=	000030	
C#GPRI	=	000040	
C#INIT	=	000011	
C#INLP	=	000020	
C#MANI	=	000050	
C#MEM	=	000031	
C#MSG	=	000023	
C#OPEN	=	000034	
C#PNTB	=	000014	
C#PNTF	=	000017	
C#PNTS	=	000016	
C#PNTX	=	000015	
C#QIO	=	000377	
C#RDBU	=	000007	
C#REFG	=	000047	
C#RESE	=	000033	
C#REVI	=	000003	
C#RFLA	=	000021	
C#RPT	=	000025	
C#SEFG	=	000046	
C#SPRI	=	000041	
C#SVEC	=	000037	
C#TPRI	=	000013	
C.DR0	=	000016	
C.DR1	=	000020	
C.DR2	=	000022	
C.DR3	=	000024	
C.FLG	=	000012	
C.HCOM	=	000014	
C.JAD	=	000010	
C.JSR	=	000006	
C.REF	=	000032	
C.SIZE	=	000034	
C.TO	=	000026	
C.TOH	=	000030	
C.UADR	=	000000	
C.UNIT	=	000002	
C.VEC	=	000004	
DDEF	=	011012	
DEBUG	=	000000	
DFPTBL		002130	G
DIAG	=	177777	
DIAGMC	=	000000	
DIVIDE		013634	
DIV10		013672	
DMFRST	=	001000	
DMMAIN	=	000040	
DMOVRL	=	000004	
DMPROG		002176	
DMRQA		012116	
DMRQB		012176	
DMRQC		012402	
DMRQD		012540	
DMRQE		012652	
DMRQO		011164	
DMRQ3		011304	
DMRQ4		011326	
DMRQ4X		011620	
DMRQ5		011622	
DMRQ5E		011650	
DMRQ6		011652	
DMRQ6E		011700	
DMRQ7		011702	
DMRQ8		011734	
DMRQ9		011754	
DHTRLN	=	000000	
DSPSIZ	=	000017	
DTABS		002166	G
DT.AVL	=	100000	
DT.UNT	=	000077	
DUP	=	001000	
DU.DFL	=	020000	
DU.FTL	=	050000	
DU.INF	=	030000	
DU.GUE	=	010000	
DU.SPC	=	060000	
DU.TER	=	040000	
D.BB	=	000010	
D.BB01	=	000012	
D.BB02	=	000016	
D.BB03	=	000022	
D.BB04	=	000026	
D.BB05	=	000032	
D.BB06	=	000036	
D.BB07	=	000042	
D.BB08	=	000046	
D.BB09	=	000052	
D.BB10	=	000056	
D.BB11	=	000062	
D.BB12	=	000066	
D.BB13	=	000072	
D.BB14	=	000076	
D.BB15	=	000102	
D.BB16	=	000106	
D.BCYL	=	000154	
D.BE	=	000040	
D.BEC	=	000112	
D.BGN1	=	000114	
D.BGN2	=	000124	
D.BGN3	=	000134	
D.BGN4	=	000144	
D.CYL	=	000400	
D.DC	=	000002	
D.DCA	=	000001	
D.DCY	=	020000	
D.DRV	=	000000	
D.ECC	=	010000	
D.ECCC	=	000176	
D.ECYL	=	000160	
D.END1	=	000120	
D.END2	=	000130	
D.END3	=	000140	
D.END4	=	000150	
D.HDAS	=	000210	
D.HERR	=	000170	
D.IW	=	040000	
D.PAT	=	000006	
D.PRM	=	000004	
D.RET	=	001000	
D.RO	=	004000	
D.SEEK	=	000174	
D.SEQ	=	000100	
D.SERN	=	000200	
D.SERR	=	000172	
D.SIZE	=	000220	
D.SKER	=	000206	
D.TR	=	000020	
D.UNIT	=	000002	
D.WC	=	000010	
D.WCA	=	000004	
D.WO	=	002000	
D.XFRR	=	000166	
D.XFRW	=	000164	
D.ZERO	=	140200	
EF.BBR	=	000200	
EF.BBU	=	000100	
EF.CON	=	000036	G
EF.LOG	=	000040	
EF.NEW	=	000035	G
EF.PWR	=	000034	G
EF.RES	=	000037	G
EF.SEX	=	000020	
EF.STA	=	000040	G
ERRBLK		002154	G
ERRC		010202	
ERRD		010214	
ERRLIM		00274	
ERRME1		002603	
ERRMSG		002152	G
ERRMSL		012274	
ERRMSX		012376	
ERRNBR		002150	G
ERRTYP		002146	G
ERRVEC	=	000004	G
ERR.SZ	=	000011	
ERR.TB		010156	
ERR.TN		007160	G
ERR002		006540	G

Symbol table

ERR003	006556	G	G#PRMD=	000002	I#AU	=	000041	L#CLEA	021304	G	L10011	006700				
ERR004	006574	G	G#PRML=	000000	I#AUTO=	000041	L#CO	002032	G	L10012	006706					
ERR006	006606	G	G#RADA=	000140	I#CLN	=	000041	L#DEPO	002011	G	L10013	006724				
ERR014	006620	G	G#RADB=	000000	I#DU	=	000041	L#DESC	002420	G	L10014	006736				
ERR030	006636	G	G#RADD=	000040	I#HRD	=	000041	L#DESP	002076	G	L10015	006750				
ERR031	006652	G	G#RADL=	000120	I#INIT=	000041	L#DEVP	002060	G	L10016	006764					
ERR032	006664	G	G#RADO=	000020	I#MOD	=	000041	L#DISP	002124	G	L10017	007316				
ERR033	006702	G	G#XFER=	000004	I#MSG	=	000041	L#DLY	002116	G	L10020	015154				
ERR035	006710	G	G#YES	=	000010	I#PROT=	000040	L#DTP	002040	G	L10021	015164				
ERR036	006726	G	HCOMM	007356	I#PTAB=	000041	L#DTYP	002034	G	L10022	015206					
ERR038	006740	G	HC.BF1=	000100	I#PMR	=	000041	L#DU	021312	G	L10023	017762				
ERR040	006752	G	HC.BF2=	000206	I#RPT	=	000041	L#DUT	002072	G	L10025	021300				
EVL	=	000004	HC.BSZ=	000106	I#SEG	=	000041	L#DVTY	002374	G	L10026	021302				
E#END	=	002100	HC.CCT=	000012	I#SETU=	000041	L#EF	002052	G	L10027	021310					
E#LOAD=	000035		HC.CEV=	000014	I#SFT	=	000041	L#ENVI	002044	G	L10030	021316				
FFREE	002156	G	HC.CMD=	000010	I#SRV	=	000041	L#ERRT	002146	G	L10031	021324				
FNEM	002162		HC.CPK=	000020	I#SUB	=	000041	L#ETP	002102	G	L10032	025710				
FNEMS	002164		HC.ESZ=	000004	I#TST	=	000041	L#EXP1	002046	G	L10033	025744				
FNERR	007320		HC.INT=	000000	J#JMP	=	0C0167	L#EXP4	002064	G	L10034	026124				
FRMTT	002541		HC.ISZ=	000004	KW.BRL	002322	L#EXP5	002066	G	L10035	000050R	003				
FSIZE	002160	G	HC.MCT=	000006	KW.CSR	002320	L#HARD	025714	G	L10037	000056R	003				
F#AU	=	000015	HC.MEV=	000014	KW.EL	002330	L#HIME	002120	G	MD.CMP=	040000					
F#AUTO=	000020		HC.MPK=	000020	KW.HZ	002326	L#HPCP	002016	G	MD.CMB=	000010					
F#BGN	=	000040	HC.MSG=	000004	KW.OUT=	000105	L#HPTP	002022	G	MD.ERR=	010000					
F#CLEA=	000007		HC.PSZ=	000060	KW.VEC	002324	L#HW	002130	G	MD.EXP=	100000					
F#DU	=	000016	HC.RSZ=	000004	KW11I	015166	L#ICP	002104	G	MD.FEU=	000001					
F#END	=	000041	HC.SIZ=	000314	LBSIZ	=	001060	L#INIT	017772	G	MD.INF=	000002				
F#HARD=	000004		HM.CYL=	020000	LBUFE	002372	L#LADP	002026	G	MD.NKU=	000001					
F#HW	=	000013	H#DOE	=	100000	LBUFN	002370	L#LAST	000044RG	003	MD.PRI=	000001				
F#INIT=	000006		H.DRV	=	000002	LBUFS	002366	L#LOAD	002100	G	MD.RIP=	000001				
F#JMP	=	000050	H.PRM	=	000004	LDDM	010322	L#LUN	002074	G	MD.SCH=	004000				
F#MOD	=	000000	H.UBA	=	000000	LDNEXT	010354	L#HREV	002050	G	MD.SCL=	002000				
F#MSG	=	000011	IBE	=	010000	LF	=	000012	G	L#NAME	002000	G	MD.SEC=	000100		
F#PROT=	000021		ICONT	=	000002	LOADB	014460	L#PRIO	002042	G	L#PRID	002042	G	MD.SEG=	000020	
F#PMR	=	000017	IDU	=	000040	LOADDM	014376	L#PROT	017764	G	L#PRT	002112	G	MD.SER=	000400	
F#RPT	=	000012	IER	=	020000	LOADER	014566	L#PRT	002112	G	L#REPP	002062	G	MD.SPD=	000001	
F#SEG	=	000003	IFLAGS	002200	G	LOADE1	014556	L#REV	002062	G	L#REV	002010	G	MD.SSH=	000200	
F#SOFT=	000005		INITBL	002346		LOADTX	014454	L#RPT	016430	G	L#RPT	016430	G	MD.SMP=	000004	
F#SRV	=	000010	INITWA	003246		LOE	=	040000	G	L#SOFT	026050	G	MD.VOL=	000002		
F#SUB	=	000002	INITWB	003356		LOG	=	000001		L#SPC	002056	G	MD.WBN=	000100		
F#SW	=	000014	INITWC	002465		LOGCHK	021426	L#SPCP	002020	G	L#SPTP	002024	G	MD.WBV=	000400	
F#TEST=	000001		INITXX	021232		LOGM1	003042	L#STA	002030	G	L#SW	002140	G	MEMFIL	011174	
GETCDN	013360		INIT1	020264		LOGM2	003074	L#SPTP	002024	G	L#TEST	002114	G	MESSG	003403	
GETCNT	013314		INIT2	020446		LOGM3	003121	L#STA	002030	G	L#TIML	002014	G	MLDRER	021244	
GETCNX	013320		INIT3	020504		LOGOUT	021374	L#SW	002140	G	L#UNIT	002012	G	MSCP	=	000000
GETCXX	013366		INIT4	020540		LOT	=	000010	G	L#TEST	002114	G	MSGCST	026006		
GTDVRT	013224		INIT5	021050		LPNT	007630	L#TEST	002114	G	L#TIML	002014	G	MSGLDR	025776	
G#CNT0=	000200		INIT6	021216		LPNTB	007602	L#UNIT	002012	G	L#UNIT	002012	G	MSGPKL	007104	
G#DELM=	000372		INP28A	025557		LPNTF	007572	L10000	002136		L10000	002136		MSGPKT	007060	
G#DISP=	000003		INP28B	025621		LPNTS	007622	L10001	002146		L10001	002146		MSGUBA	025744	
G#EXCP=	000400		INTRCV	002212		LPNTX	007612	L10002	006554		L10002	006554		MXFERE	012114	
G#HILI=	000002		IPADRS	002244		L#ACP	002110	G	L10003	006572	L10003	006572		MXFERP	002672	
G#LOLI=	000001		IREST	=	000004	L#APT	002036	G	L10004	006604	L10004	006604		MXFERX	012112	
G#NO	=	000000	ISR	=	000100	L#AU	021320	G	L10005	006616	L10005	006616		NCON	007304	
G#OFFS=	000400		ISTRT	=	000010	L#AUT	002070	G	L10006	006634	L10006	006634		NCONF	007730	
G#OFSI=	000376		ISTRTH=	000020	G	L#AUTO	021302	G	L10007	006650	L10007	006650		NCONS	007706	
G#PRMA=	000001		IXE	=	004000	L#CCP	002106	G	L10010	006662	L10010	006662		NOCLOC	003456	



## Symbol table

NXMAD	002340	PRI04	= 000200 G	RESPECT	010406	SA.MCV	= 000017	SVCSUB	= 000000
NXMI	015146 G	PRI05	= 000240 G	RESPDM	010374	SA.MP	= 000100	SVCTAG	= 000000
OP.ABO	= 000001	PRI06	= 000300 G	RG.FLG	= 040000	SA.MSE	= 000007	SVCTST	= 000000
OP.ACC	= 000020	PRI07	= 000340 G	RG.OMN	= 100000	SA.MSG	= 003400	S#LSYM	= 010000
OP.AVA	= 000100	PS	007546	RNTIM	002347	SA.MS1	= 000400	S.EL	026211
OP.AVL	= 000010	PTYPE	002342	RNTIME	016236	SA.NV	= 002000	S.IW	026345
OP.CCD	= 000021	PX	007522	RNTIMX	016416	SA.NVE	= 000400	S.LOG	026377
OP.CMP	= 000040	P.BCNT	= 000014	RNTIM1	002572	SA.PRG	= 000001	S.MAN	026124
OP.DUP	= 000101	P.BUFF	= 000020	RNTIM2	002600	SA.QB	= 001000	S.S&F	026307
OP.ELP	= 000003	P.CHVR	= 000023	RPTCT	016524	SA.SM	= 000040	S.XL	026225
OP.END	= 000200	P.CMST	= 000020	RPTCTN	017152	SA.STE	= 000200	TEMP	002214
OP.ERS	= 000022	P.CNTF	= 000016	RPTDT	016564	SA.STP	= 100000	TEST4	= ***** GX
OP.ESP	= 000002	P.CNTI	= 000024	RPTDTN	017146	SA.S1	= 004000	TINDEX	= 000006
OP.FLU	= 000023	P.CPSP	= 000042	RPTHD2	017527	SA.S2	= 010000	TINIT	010234
OP.GCS	= 000002	P.CRF	= 000000	RPTHD3	017551	SA.S3	= 020000	TNAMES	010200
OP.GSS	= 000001	P.CSVR	= 000022	RPTMSD	017460	SA.S4	= 040000	TNUM	002202
OP.GUS	= 000003	P.CTMO	= 000020	RPTMSG	017206	SA.TST	= 000000	TOONER	021262
OP.HRD	= 000030	P.CYLS	= 000050	RPTMSH	017242	SA.VCE	= 000177	TSTTAB	002174
OP.MMR	= 000031	P.DEXT	= 000014	RPTMS4	017631	SA.VEC	= 000177	TTYOUT	002344
OP.ONL	= 000011	P.DFLG	= 000017	RPTMS5	017702	SA.WRP	= 040000	T#ARGC	= 000001
OP.RD	= 000041	P.DMT	= 000024	RPTXX	017166	SEKERE	011752	T#CODE	= 002130
OP.RLC	= 000103	P.DPRG	= 000020	RSPDRP	010604	SET00	015222	T#ERRN	= 000003
OP.RPL	= 000024	P.DTMO	= 000024	RSPDSP	011126	SET01	015230	T#EXCP	= 000000
OP.RSD	= 000005	P.ELGF	= 000034	RSPERR	010670	SET02	015236	T#FLAG	= 000040
OP.SCC	= 000004	P.FBBK	= 000034	RSPIN	010622	SETTO	015210	T#FREE	= 000056R
OP.SEX	= 000007	P.FLGS	= 000011	RSPMR	010642	SFPTBL	002140 G	T#GMAN	= 000000
OP.SHC	= 000102	P.GRPS	= 000046	RSPNRP	010570	SM.IW	= 040000 G	T#HILI	= 177777
OP.SSD	= 000004	P.HSTI	= 000020	RSPNTO	010534	SM.LOG	= 001000 G	T#LAST	= 000001
OP.SUC	= 000012	P.HTMO	= 000020	RSPNXT	010536	SM.MAN	= 000200 G	T#LOLI	= 000000
OP.WR	= 000042	P.LBN	= 000034	RSPOU	010710	SM.SSF	= 000400 G	T#LSYM	= 010000
OSTRE	007744	P.MEDI	= 000034	RSPOUT	011024	SNDCHD	014664	T#LTNO	= 000001
OSTRNG	007676	P.MLUN	= 000014	RSPOU2	011072	SND.S1	002350	T#NEST	= 177777
O#APTS	= 000000	P.MOD	= 000012	RSPOUS	011100	SND.S2	002354	T#NSO	= 000005
O#AU	= 000000	P.OPCD	= 000010	RSPPTW	010702	SND.S3	002360	T#PCNT	= 000000
O#BGNR	= 000001	P.OTRF	= 000014	RSPPT2	010712	SO.BIT	= 000004	T#PTAB	= 010036
O#BGNS	= 000001	P.OVRL	= 000034	RSPPT3	010762	SO.EL	= 000000	T#PTHV	= 000001
O#DU	= 000000	P.RBN	= 000014	RSPRPT	010566	SO.XL	= 000002	T#PTNU	= 000001
O#ERRT	= 000001	P.RBNS	= 000056	RSPTH	010472	SSTEP4	002362	T#SAVL	= 177777
O#GNSW	= 000001	P.RCTC	= 000057	RSPTHD	010522	STIME	002334	T#SEGL	= 177777
O#POIN	= 000001	P.RCTS	= 000054	RSP.CK	015736	ST.ABO	= 000002	T#SIZE	= 000005
O#SETU	= 000001	P.RGID	= 000034	RSP.S1	015710	ST.AQL	= 000400	T#SUBN	= 000000
PAT16C	002256	P.RGOF	= 000040	RSP.S2	015722	ST.AVL	= 000004	T#TAGL	= 177777
PAT16W	002260	P.SHST	= 000042	RSP.S3	015742	ST.CMD	= 000001	T#TAGN	= 010040
PB	007476	P.SHLN	= 000040	RUNDM	010300	ST.CMP	= 000007	T#TEMP	= 000005
PF	007452	P.STS	= 000012	SA.BST	= 000374	ST.CNT	= 000012	T#TEST	= 000001
PNT	= 001000 G	P.TIME	= 000024	SA.CMD	= 034000	ST.DAT	= 000010	T#TSTM	= 177777
PNTERR	014232	P.TRKS	= 000044	SA.CHE	= 000070	ST.DIA	= 000037	T#TSTS	= 000001
PNTNUM	013372	P.UADR	= 000020	SA.CM1	= 004000	ST.DRV	= 000013	T#AU	= 010031
PNTNUS	013400	P.UNFL	= 000016	SA.CNT	= 000360	ST.HST	= 000011	T#AUT	= 010026
PNTPKL	007016	P.UNIT	= 000004	SA.CTP	= 003400	ST.MFE	= 000005	T#CLE	= 010027
PNTPKT	006766	P.UNSZ	= 000044	SA.DI	= 000400	ST.MSK	= 000037	T#DAT	= 010037
PRI	= 002000 G	P.UNTI	= 000024	SA.ERC	= 003777	ST.OFL	= 000003	T#DU	= 010030
PRINTC	007416	P.USEF	= 000022	SA.ERR	= 100000	ST.SUB	= 000040	T#HAR	= 010033
PRI00	= 000000 G	P.VRSN	= 000014	SA.GO	= 000001	ST.SUC	= 000000	T#HW	= 010000
PRI01	= 000040 G	P.VSER	= 000050	SA.INE	= 000200	ST.WPR	= 000006	T#INI	= 010025
PRI02	= 000100 G	READDT	010276	SA.INT	= 000200	SVCGBL	= 000000	T#MSG	= 010017
PRI03	= 000140 G	RESET	016134	SA.LFC	= 000002	SVCINS	= 000000	T#PC	= 000001

## Symbol table

T##PRO=	010024	T4DPD	025115	T4Q07	022444	T4SEK	024555	XFCE	005725
T##PTA=	010036	T4ECC	024422	T4Q08	022522	T4STRT	021464	XFRU	006471
T##RPT=	010023	T4END	024645	T4Q09	022530	T4TRAK	024710	XMSG1	005777
T##SOF=	010034	T4EXIT	021772	T4Q10	022620	T4TRC	024657	XMSG2	006033
T##SRV=	010022	T4GRC	024716	T4Q11	022664	T4WAIT	021756	XPKT1	006100
T##SM =	010001	T4GRP	024747	T4Q12	023062	T4WARN	003150	XPKT2	006405
T##TES=	010032	T4OPT1	025247	T4Q13	023116	T4WCA	024257	XSA	006434
T1	021326	T4OPT2	025306	T4Q14	023150	T4WCR	024313	X#ALWA=	000000
T4BB	024122	T4OPT3	025342	T4Q15	023176	T4WO	024244	X#FALS=	000040
T4BBI	024220	T4OPT4	025405	T4Q16	023212	UAM	= 000200	X#OFFS=	000400
T4BE	024600	T4OPT5	025454	T4Q17	023220	UCNT	002210	X#TRUE=	000020
T4BEG	024631	T4OPT6	025523	T4Q18	023232	UF.CMR=	000001	X1A	003666
T4CON	021446	T4OPT7	002462	T4Q19	023240	UF.CMW=	000002	X14	004336
T4CYL	024755	T4PRM1	021530	T4Q20	023316	UF.INA=	040000	X2	003751
T4CYLB	025010	T4PRM2	021542	T4Q21	023350	UF.RPL=	100000	X2A	003666
T4CYLE	025032	T4PRM3	021576	T4Q22	023410	UF.SCH=	004000	X3	004020
T4DCA	024455	T4PRM4	021602	T4Q23	023476	UF.SCL=	002000	X3A	003666
T4DCR	024503	T4PRM5	024064	T4Q24	023534	UF.WBN=	000100	X31	004737
T4DEF	021634	T4QHED	025127	T4Q25	023566	UF.WPH=	020000	X32	005061
T4DEFA	021640	T4QUES	022000	T4Q26	023622	UF.WPS=	001000	X35	005172
T4DEFB	021652	T4QUE2	024014	T4Q27	023702	UF.576=	000004	X36	005252
T4DEFC	021676	T4QU2E	024120	T4Q27A	023714	URNING	002206	X38	005377
T4DEFD	021704	T4Q01	022104	T4Q28	023722	URUN	002204	X4	004106
T4DEFE	021710	T4Q02	022142	T4Q29	023754	UTOT1	012130	X40	005603
T4DEFW	021624	T4Q03	022240	T4Q30	024006	UTOT1A	012162	X6	004251
T4DMN	024147	T4Q04	022316	T4RET	024536	UTOT2	012166	X8A	003666
T4DP	024354	T4Q05	022324	T4RO	024232	WAITMS	014774	#PATCH	000000RG
T4DPC	025052	T4Q06	022414	T4RUN	021720				003
. ABS.	026420	000	(RW,I,G,L,ABS,OVR)						
	000000	001	(RW,I,LCL,REL,CON)						
DM	000000	002	(RW,I,LCL,ABS,CON)						
END	000056	003	(RW,I,LCL,REL,CON)						

## \*\*\* Assembler statistics

Work file reads: 732  
 Work file writes: 625  
 Size of work file: 28769 Words ( 113 Pages)  
 Size of core pool: 14336 Words ( 56 Pages)  
 Operating system: RT-11 (Under RTE-11)

Elapsed time: 00:04:51.00  
 ZUDIAO,ZUDIAO/C=SVC34R.MLB,ZUDIAO.DOC,CZUDHO.MAC





















CZUDIA0 UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 5-10  
 Cross reference table (CREF V05.01)

L\$LOAD	87-202#						
L\$LUN	87-202#	104-25#	105-15#	121-31#	128-17#		
L\$HREV	87-202#						
L\$NAME	87-202#						
L\$PRIO	87-202#						
L\$PRJT	87-202	142-9#					
L\$PRT	87-202#						
L\$REPP	87-202#						
L\$REV	87-202#						
L\$RPT	87-202	141-10#					
L\$SOFT	87-202	154-12	154-12#				
L\$SPC	87-202#						
L\$SPCP	87-202#						
L\$SPTP	87-202#						
L\$STA	87-202#						
L\$SM	87-202	90-11	90-11#				
L\$TEST	87-202#						
L\$TIML	87-202#						
L\$UNIT	87-202#	143-113	143-156	143-299			
L10000	89-12	89-23#					
L10001	90-11	90-21#					
L10002	101-17#						
L10003	101-21#						
L10004	101-25#						
L10005	101-29#						
L10006	101-39#						
L10007	101-102#						
L10010	101-106#						
L10011	101-111#						
L10012	101-115#						
L10013	101-120#						
L10014	101-124#						
L10015	101-128#						
L10016	101-138#						
L10017	101-186#						
L10020	134-13#						
L10021	134-35#						
L10022	134-54#						
L10023	141-93	141-107#					
L10025	143-353	144-42#					
L10026	145-12#						
L10027	146-14	146-16#					
L10030	147-10	147-12#					
L10031	148-12	148-14#					
L10032	150-118	152-47#					
L10033	153-11	153-41#					
L10034	154-12	154-55#					
L10035	156-14#						
L10037	156-14	156-24#					
LBSIZ	99-116#	116-65	116-69				
LPUFE	99-115#	116-70#	116-73				
LBUFN	99-114#	116-68#	116-71	116-72#	116-73	116-81#	150-21
LBUFS	99-113#	103-19#	116-63	116-67#	150-14	150-17#	
LDDM	104-23#	104-34					
LDNEXT	104-27	104-30	104-32#				
LF	91-10						

















	151-200	151-200	151-200	151-200	151-200	151-200	151-213	151-213	151-213	151-213	151-213	151-213	151-213	151-213
	151-213	151-213	151-213	151-213	151-213	151-213	151-213	151-213	151-219	151-219	151-219	151-219	151-219	151-219
	151-219	151-219	151-219	151-219	151-219	151-219	151-219	151-219	151-219	151-219	152-47	152-47	153-11	153-11
	153-27	153-27	153-27	153-27	153-27	153-27	153-27	153-27	153-35	153-35	153-35	153-35	153-35	153-35
	153-35	153-35	153-35	153-35	153-38	153-38	153-38	153-38	153-38	153-38	153-41	153-41	154-12	154-12
	154-37	154-37	154-37	154-37	154-37	154-37	154-39	154-39	154-39	154-39	154-39	154-39	154-39	154-39
	154-39	154-39	154-42	154-42	154-42	154-42	154-42	154-42	154-42	154-42	154-42	154-42	154-44	154-44
	154-44	154-44	154-44	154-44	154-46	154-46	154-46	154-46	154-46	154-46	154-48	154-48	154-48	154-48
	154-48	154-48	154-55	154-55	155-17	155-17	155-17	155-17	155-17	155-17	156-14	156-14	156-14	156-14
SVCSUB	87-1530	87-1610												
SVCTAG	87-1530	87-1630	89-23	89-23	89-23	90-21	90-21	90-21	101-17	101-17	101-17	101-21	101-21	101-21
	101-25	101-25	101-25	101-29	101-29	101-29	101-39	101-39	101-39	101-102	101-102	101-102	101-106	101-106
	101-106	101-111	101-111	101-111	101-115	101-115	101-115	101-120	101-120	101-120	101-124	101-124	101-124	101-128
	101-128	101-128	101-138	101-138	101-138	101-186	101-186	101-186	134-13	134-13	134-13	134-35	134-35	134-35
	134-54	134-54	134-54	141-107	141-107	141-107	143-333	143-333	143-333	144-42	144-42	144-42	145-12	145-12
	145-12	146-16	146-16	146-16	147-12	147-12	147-12	148-14	148-14	148-14	151-18	151-18	151-18	151-26
	151-26	151-26	151-33	151-33	151-33	151-39	151-39	151-39	151-45	151-45	151-45	151-46	151-46	151-46
	151-49	151-49	151-49	151-54	151-54	151-54	151-67	151-67	151-67	151-68	151-68	151-68	151-71	151-71
	151-71	151-74	151-74	151-74	151-76	151-76	151-76	151-100	151-100	151-100	151-137	151-137	151-137	151-143
	151-143	151-143	151-147	151-147	151-147	151-162	151-162	151-162	151-166	151-166	151-166	151-172	151-172	151-172
	151-176	151-176	151-176	151-182	151-182	151-182	151-196	151-196	151-196	151-200	151-200	151-200	151-213	151-213
	151-213	151-219	151-219	151-219	152-47	152-47	152-47	153-41	153-41	153-41	154-55	154-55	154-55	156-14
	156-14	156-14	156-24	156-24	156-24	156-24	156-24	156-24	156-24	156-24	156-24	156-24	156-24	156-24
SVCTST	87-1530	87-1600	150-3	150-3	150-3	150-3	150-3	150-3	150-3	150-3	150-3	150-3	150-3	150-3
T#AU	148-90	148-12	148-14											
T#AUT	145-100	145-12												
T#CLE	146-80	146-14	146-16											
T#DAT	156-14	156-140	156-24											
T#DU	147-80	147-10	147-12											
T#HAR	153-11	153-110	153-41											
T#HM	89-12	89-120	89-23											
T#INI	143-440	143-333	144-42											
T#MSG	101-150	101-17	101-190	101-21	101-230	101-25	101-270	101-29	101-370	101-39	101-1000	101-102	101-1040	101-106
	101-1080	101-111	101-1130	101-115	101-1170	101-120	101-1220	101-124	101-1260	101-128	101-1360	101-138	101-1650	101-186
T#PC	156-130	156-25												
T#PRO	142-90													
T#PTA	156-130	156-14	156-140											
T#RPT	141-100	141-93	141-107											
T#SOF	154-12	154-120	154-55											
T#SRV	134-110	134-13	134-320	134-35	134-500	134-54								
T#SM	90-11	90-110	90-21											
T#TES	150-30	150-118	152-47											
T#ARGC	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202
	87-2020	87-2020	87-2020	102-78	102-78	102-78	102-780	102-780	102-80	102-80	102-80	102-800	102-800	102-82
	102-82	102-82	102-820	102-820	102-84	102-84	102-84	102-840	102-840	127-39	127-39	127-390	127-43	127-43
	127-430	141-26	141-26	141-260	141-36	141-36	141-360	141-59	141-59	141-59	141-59	141-59	141-59	141-59
	141-59	141-590	141-590	141-590	141-590	141-590	141-590	141-590	141-61	141-61	141-61	141-61	141-61	141-610
	141-610	141-610	141-610	141-82	141-82	141-82	141-820	141-820	141-820	143-320	143-320	143-320	143-320	143-320
	143-320	143-3200	143-3200	143-3200	143-3200	151-16	151-16	151-16	151-16	151-16	151-160	151-160	151-160	151-160
	151-94	151-94	151-940	151-95	151-95	151-950	151-96	151-96	151-96	151-960	151-97	151-97	151-970	151-98
	151-960	151-99	151-99	151-990										
T#CODE	143-333	143-333	143-333	143-3330	143-3330	143-3330	151-18	151-18	151-18	151-180	151-180	151-180	151-26	151-26
	151-26	151-260	151-260	151-260	151-33	151-33	151-33	151-330	151-330	151-330	151-330	151-39	151-39	151-390
	151-390	151-390	151-45	151-45	151-45	151-450	151-450	151-450	151-46	151-46	151-46	151-460	151-460	151-460
	151-49	151-49	151-49	151-490	151-490	151-490	151-54	151-54	151-54	151-540	151-540	151-540	151-67	151-67
	151-67	151-670	151-670	151-670	151-68	151-68	151-68	151-680	151-680	151-680	151-680	151-71	151-71	151-710





CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 5-21  
 Cross reference table (CREF V05.01)

T4DCR	151-71	152-150			
T4DEF	150-41	150-810			
T4DEFA	150-820	150-98			
T4DEFB	150-850	150-95			
T4DEFC	150-910	150-93			
T4DEFD	150-940				
T4DEFE	150-86	150-960			
T4DEFW	150-43	150-770			
T4DPM	151-33	152-60			
T4DP	151-54	152-120			
T4DPC	151-213	152-280			
T4DPD	151-219	152-290			
T4ECC	151-67	152-130			
T4END	151-147	152-200			
T4EXIT	150-112	150-1160			
T4GRC	151-172	152-230			
T4GRP	151-176	152-240			
T4OPT1	151-94	152-340			
T4OPT2	151-95	152-350			
T4OPT3	151-96	152-360			
T4OPT4	151-97	152-370			
T4OPT5	151-98	152-380			
T4OPT6	151-99	152-390			
T4OPT7	100-260	151-100			
T4PRM1	150-490	150-65			
T4PRM2	150-520	150-62			
T4PRM3	150-55	150-59	150-610		
T4PRM4	150-53	150-630			
T4PRM5	151-2180	151-222			
T4Q01	151-250	151-28	151-30		
T4Q02	151-20	151-310			
T4Q03	151-41	151-440			
T4Q04	151-48	151-510			
T4Q05	151-43	151-50	151-520		
T4Q06	151-610				
T4Q07	151-62	151-64	151-670		
T4Q08	151-70	151-730			
T4Q09	151-66	151-72	151-740		
T4Q10	151-82	151-850			
T4Q11	151-84	151-86	151-89	151-92	151-940
T4Q12	151-102	151-1050			
T4Q13	151-106	151-1120			
T4Q14	151-114	151-1180			
T4Q15	151-121	151-1230			
T4Q16	151-111	151-124	151-1270		
T4Q17	151-1280				
T4Q18	151-1310	151-133			
T4Q19	151-104	151-108	151-117	151-126	151-1340
T4Q20	151-1420	151-145	151-151		
T4Q21	151-1460	151-149			
T4Q22	151-135	151-1530			
T4Q23	151-1650	151-169			
T4Q24	151-160	151-1710			
T4Q25	151-1750	151-179			
T4Q26	151-170	151-1800			
T4Q27	151-156	151-184	151-1900		





CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page 5-23  
 Cross reference table (CREF V05.01)

UF.WBN	94-106#					
UF.WPH	94-107#					
UF.WPS	94-108#					
URNING	99-29#	104-17*	104-31*	104-38	105-71*	150-29
URIN	99-28#	104-16*	104-22	105-11		
UTOT1	115-21#	115-35				
UTOT1A	115-24	115-34#				
UTOT2	115-22	115-36#				
WAITMS	129-79	133-12#				
X#ALWA	87-153#					
X#FALS	87-153#					
X#OFFS	87-153#					
X#TRUE	87-153#					
X14	100-100#	101-38				
X1A	100-85#					
X2	100-92#	101-16				
X2A	100-86#	101-16				
X3	100-93#	101-20				
X31	100-127#	101-105				
X32	100-129#	101-109				
X35	100-130#	101-118				
X36	100-131#	101-123				
X38	100-133#	101-127				
X3A	100-87#	101-20				
X4	100-94#	101-24				
X40	100-143#	101-137				
X6	100-96#	101-28				
X8A	100-88#					
XFCE	100-146#	101-101				
XFRU	100-154#	120-106				
XMSG1	100-147#	101-155				
XMSG2	100-148#	101-159				
XPKT1	100-149#	101-141				
XPKT2	100-152#	101-148				
XSA	100-153#	120-118				





CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page M-3  
Cross reference table (CREF V05.01)

	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202
	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	100-13
M#DECR	100-13#	100-20	100-20#											
	1-D29#	87-153#	89-23	89-23#	90-21	90-21#	101-17	101-17#	101-21	101-21#	101-25	101-25#	101-29	101-29#
	101-39	101-39#	101-102	101-102#	101-106	101-106#	101-111	101-111#	101-115	101-115#	101-120	101-120#	101-124	101-124#
	101-128	101-128#	101-138	101-138#	101-186	101-186#	134-13	134-13#	134-35	134-35#	134-54	134-54#	141-107	141-107#
	142-15	142-15#	144-42	144-42#	145-12	145-12#	146-16	146-16#	147-12	147-12#	148-14	148-14#	152-47	152-47#
	153-41	153-41#	154-55	154-55#	156-14	156-14#								
M#DEFA	1-E70#	87-153#	143-333	143-333#	151-18	151-18#	151-26	151-26#	151-33	151-33#	151-39	151-39#	151-45	151-45#
	151-46	151-46#	151-49	151-49#	151-54	151-54#	151-67	151-67#	151-68	151-68#	151-71	151-71#	151-74	151-74#
	151-76	151-76#	151-100	151-100#	151-137	151-137#	151-143	151-143#	151-147	151-147#	151-162	151-162#	151-166	151-166#
	151-172	151-172#	151-176	151-176#	151-182	151-182#	151-196	151-196#	151-200	151-200#	151-213	151-213#	151-219	151-219#
	153-27	153-27#	153-35	153-35#	153-38	153-38#	154-37	154-37#	154-39	154-39#	154-42	154-42#	154-44	154-44#
	154-46	154-46#	154-48	154-48#										
M#ENDE	1-D74#	87-153#	89-23#	90-21#	101-17#	101-21#	101-25#	101-29#	101-39#	101-102#	101-106#	101-111#	101-115#	101-120#
	101-124#	101-128#	101-138#	101-186#	134-13#	134-35#	134-54#	141-107#	144-42#	145-12#	146-16#	147-12#	148-14#	152-47#
	153-41#	154-55#												
M#ERRI	1-849#	87-153#	102-9	102-9#	105-26	105-26#	105-44	105-44#	105-94	105-94#	105-112	105-112#	121-25	121-25#
	129-91	129-91#	133-35	133-35#	133-48	133-48#	136-122	136-122#	136-128	136-128#	136-134	136-134#	137-36	137-36#
	137-95	137-95#	138-42	138-42#	138-53	138-53#	143-103	143-103#	144-19	144-19#	144-28	144-28#		
M#ESCA	1-D06#	87-153#												
M#ESCS	1-D10#	87-153#												
M#EXCP	1-E01#	87-153#	151-18	151-18	151-18#	151-26	151-26	151-26#	151-54	151-54	151-54#	151-100	151-100	151-100#
	151-137	151-137	151-137#	151-143	151-143	151-143#	151-147	151-147	151-147#	151-162	151-162	151-162#	151-166	151-166
	151-166#	151-172	151-172	151-172#	151-176	151-176	151-176#	151-196	151-196	151-196#	151-200	151-200	151-200#	151-213
	151-213	151-213#	151-219	151-219	151-219#	153-27	153-27	153-27#	153-35	153-35	153-35#	154-39	154-39	154-39#
	154-42	154-42	154-42#											
M#EXIT	1-D14#	87-153#	141-93#	143-353	143-353#	146-14	146-14#	147-10#	148-12#	150-118	150-118#			
M#EXSE	1-D22#	87-153#	141-93#	143-353#	146-14#	147-10#	148-12#	150-118#						
M#EXTJ	1-D18#	87-153#	141-93	141-93#	143-353#	146-14#	147-10	147-10#	148-12	148-12#	150-118#			
M#GEN	1-D38#	87-153#	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202
	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202
	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202	87-202
	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#
	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#
	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#	87-202#
	89-23	89-23#	90-11	90-11	90-11#	90-11#	90-21	90-21#	99-8	99-8#	100-13	100-13#	100-20	100-20#
	101-15	101-15#	101-17	101-17#	101-19	101-19#	101-21	101-21#	101-23	101-23#	101-25	101-25#	101-27	101-27#
	101-29	101-29#	101-37	101-37#	101-39	101-39#	101-100	101-100#	101-102	101-102#	101-104	101-104#	101-106	101-106#
	101-108	101-108#	101-111	101-111#	101-113	101-113#	101-115	101-115#	101-117	101-117#	101-120	101-120#	101-122	101-122#
	101-124	101-124#	101-126	101-126#	101-128	101-128#	101-136	101-136#	101-138	101-138#	101-165	101-165#	101-186	101-186#
	134-11	134-11#	134-13	134-13#	134-32	134-32#	134-35	134-35#	134-50	134-50#	134-54	134-54#	141-10	141-10#
	141-107	141-107#	142-9	142-9#	143-44	143-44#	143-333	143-333#	144-42	144-42#	145-10	145-10#	145-12	145-12#
	146-8	146-8#	146-16	146-16#	147-8	147-8#	147-12	147-12#	148-9	148-9#	148-14	148-14#	150-3	150-3#
	151-18	151-18#	151-26	151-26#	151-33	151-33#	151-39	151-39#	151-45	151-45#	151-46	151-46#	151-49	151-49#
	151-54	151-54#	151-67	151-67#	151-68	151-68#	151-71	151-71#	151-74	151-74#	151-76	151-76#	151-100	151-100#
	151-137	151-137#	151-143	151-143#	151-147	151-147#	151-162	151-162#	151-166	151-166#	151-172	151-172#	151-176	151-176#
	151-182	151-182#	151-196	151-196#	151-200	151-200#	151-213	151-213#	151-219	151-219#	152-47	152-47#	153-11	153-11#
	153-41	153-41#	154-12	154-12#	154-55	154-55#	155-17	155-17#	156-14	156-14#	156-24	156-24#		
M#GENB	1-C38#	87-153#	143-333	143-333#	151-18	151-18#	151-26	151-26#	151-33	151-33#	151-39	151-39#	151-45	151-45#
	151-46	151-46#	151-49	151-49#	151-54	151-54#	151-67	151-67#	151-68	151-68#	151-71	151-71#	151-74	151-74#
	151-76	151-76#	151-100	151-100#	151-137	151-137#	151-143	151-143#	151-147	151-147#	151-162	151-162#	151-166	151-166#
	151-172	151-172#	151-176	151-176#	151-182	151-182#	151-196	151-196#	151-200	151-200#	151-213	151-213#	151-219	151-219#
M#GETS	1-D35#	87-153#	89-23	89-23#	90-21	90-21#	101-17	101-17#	101-21	101-21#	101-25	101-25#	101-29	101-29#
	101-39	101-39#	101-102	101-102#	101-106	101-106#	101-111	101-111#	101-115	101-115#	101-120	101-120#	101-124	101-124#
	101-128	101-128#	101-138	101-138#	101-186	101-186#	134-13	134-13#	134-35	134-35#	134-54	134-54#	141-107	141-107#



	143-333	143-333	143-333	143-333	143-333	143-333	143-333	143-333	143-337	143-337	143-351	143-351	143-351	143-351
	143-353	143-353	143-353	143-353	144-19	144-19	144-19	144-19	144-19	144-19	144-19	144-19	144-19	144-21
	144-21	144-28	144-28	144-28	144-28	144-28	144-28	144-28	144-28	144-28	144-30	144-30	144-42	144-42
	145-12	145-12	146-14	146-14	146-14	146-14	146-16	146-16	147-10	147-10	147-10	147-10	147-12	147-12
	148-12	148-12	148-12	148-12	148-14	148-14	148-14	150-42	150-42	150-43	150-43	150-114	150-114	150-117
	150-118	150-118	150-118	150-118	151-16	151-16	151-16	151-16	151-16	151-16	151-16	151-16	151-16	151-16
	151-16	151-16	151-16	151-16	151-16	151-18	151-18	151-18	151-18	151-18	151-18	151-18	151-18	151-18
	151-18	151-18	151-18	151-26	151-26	151-26	151-26	151-26	151-26	151-26	151-26	151-26	151-26	151-26
	151-26	151-33	151-33	151-33	151-33	151-33	151-33	151-33	151-33	151-33	151-33	151-33	151-39	151-39
	151-39	151-39	151-39	151-39	151-39	151-39	151-39	151-45	151-45	151-45	151-45	151-45	151-45	151-45
	151-45	151-45	151-45	151-46	151-46	151-46	151-46	151-46	151-46	151-46	151-46	151-46	151-46	151-49
	151-49	151-49	151-49	151-49	151-49	151-49	151-49	151-49	151-49	151-54	151-54	151-54	151-54	151-54
	151-54	151-54	151-54	151-54	151-54	151-54	151-54	151-67	151-67	151-67	151-67	151-67	151-67	151-67
	151-67	151-67	151-67	151-68	151-68	151-68	151-68	151-68	151-68	151-68	151-68	151-68	151-68	151-71
	151-71	151-71	151-71	151-71	151-71	151-71	151-71	151-71	151-71	151-74	151-74	151-74	151-74	151-74
	151-74	151-74	151-74	151-74	151-74	151-76	151-76	151-76	151-76	151-76	151-76	151-76	151-76	151-76
	151-76	151-94	151-94	151-94	151-94	151-94	151-94	151-94	151-94	151-94	151-95	151-95	151-95	151-95
	151-95	151-95	151-95	151-95	151-95	151-96	151-96	151-96	151-96	151-96	151-96	151-96	151-96	151-96
	151-97	151-97	151-97	151-97	151-97	151-97	151-97	151-97	151-97	151-98	151-98	151-98	151-98	151-98
	151-98	151-98	151-98	151-98	151-99	151-99	151-99	151-99	151-99	151-99	151-99	151-99	151-99	151-100
	151-100	151-100	151-100	151-100	151-100	151-100	151-100	151-100	151-100	151-100	151-100	151-100	151-137	151-137
	151-137	151-137	151-137	151-137	151-137	151-137	151-137	151-137	151-137	151-137	151-143	151-143	151-143	151-143
	151-143	151-143	151-143	151-143	151-143	151-143	151-143	151-147	151-147	151-147	151-147	151-147	151-147	151-147
	151-147	151-147	151-147	151-147	151-147	151-162	151-162	151-162	151-162	151-162	151-162	151-162	151-162	151-162
	151-162	151-162	151-162	151-166	151-166	151-166	151-166	151-166	151-166	151-166	151-166	151-166	151-166	151-166
	151-166	151-172	151-172	151-172	151-172	151-172	151-172	151-172	151-172	151-172	151-172	151-172	151-172	151-176
	151-176	151-176	151-176	151-176	151-176	151-176	151-176	151-176	151-176	151-176	151-176	151-176	151-182	151-182
	151-182	151-182	151-182	151-182	151-182	151-182	151-182	151-196	151-196	151-196	151-196	151-196	151-196	151-196
	151-196	151-196	151-196	151-196	151-196	151-200	151-200	151-200	151-200	151-200	151-200	151-200	151-200	151-200
	151-200	151-200	151-200	151-213	151-213	151-213	151-213	151-213	151-213	151-213	151-213	151-213	151-213	151-213
	151-213	151-219	151-219	151-219	151-219	151-219	151-219	151-219	151-219	151-219	151-219	151-219	151-219	152-47
	152-47	153-11	153-11	153-27	153-27	153-27	153-27	153-27	153-35	153-35	153-35	153-35	153-35	153-35
	153-38	153-38	153-38	153-38	153-41	153-41	153-41	154-12	154-12	154-37	154-37	154-37	154-37	154-39
	154-39	154-39	154-39	154-39	154-42	154-42	154-42	154-42	154-42	154-42	154-44	154-44	154-44	154-44
	154-46	154-46	154-46	154-46	154-48	154-48	154-48	154-48	154-55	154-55	155-17	155-17	155-17	155-17
	156-14	156-14	156-14	156-14										
M#GNLS	1-C13	87-153	143-333	143-333	151-18	151-18	151-26	151-26	151-33	151-33	151-39	151-39	151-45	151-45
	151-46	151-46	151-49	151-49	151-54	151-54	151-67	151-67	151-68	151-68	151-71	151-71	151-74	151-74
	151-76	151-76	151-100	151-100	151-137	151-137	151-143	151-143	151-147	151-147	151-162	151-162	151-166	151-166
	151-172	151-172	151-176	151-176	151-182	151-182	151-196	151-196	151-200	151-200	151-213	151-213	151-219	151-219
M#GNSU	1-898	87-153												
M#GNNTA	1-890	87-153	89-23	89-23	90-21	90-21	101-17	101-17	101-21	101-21	101-25	101-25	101-29	101-29
	101-39	101-39	101-102	101-102	101-106	101-106	101-111	101-111	101-115	101-115	101-120	101-120	101-124	101-124
	101-128	101-128	101-138	101-138	101-186	101-186	134-13	134-13	134-35	134-35	134-54	134-54	141-107	141-107
	144-42	144-42	145-12	145-12	146-16	146-16	147-12	147-12	148-14	148-14	152-47	152-47	153-41	153-41
	154-55	154-55	156-14	156-14	156-24	156-24								
M#GNTE	1-894	87-153	150-3	150-3										
M#HAPT	1-A39	87-153	87-202	87-202										
M#HMAP	1-824	87-153	87-202	87-202										
M#INCR	1-D26	87-153	89-12	89-12	89-12	89-12	90-11	90-11	90-11	90-11	101-15	101-15	101-15	101-15
	101-17	101-19	101-19	101-19	101-19	101-21	101-23	101-23	101-23	101-23	101-25	101-27	101-27	101-27
	101-27	101-29	101-37	101-37	101-37	101-37	101-39	101-100	101-100	101-100	101-100	101-102	101-104	101-104
	101-104	101-104	101-106	101-108	101-108	101-108	101-108	101-111	101-113	101-113	101-113	101-113	101-115	101-117
	101-117	101-117	101-117	101-120	101-122	101-122	101-122	101-122	101-124	101-126	101-126	101-126	101-126	101-128
	101-136	101-136	101-136	101-136	101-138	101-165	101-165	101-165	101-165	101-186	102-9	102-11	102-78	102-80
	102-82	102-84	105-26	105-44	105-47	105-59	105-94	105-112	114-35	116-40	117-45	117-56	121-25	127-39

CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page M-6  
 Cross reference table (CREF V05.01)

	127-430	128-260	128-410	129-200	129-910	133-270	133-350	133-480	134-11	134-11	134-110	134-110	134-32	134-32
	134-320	134-320	134-50	134-50	134-500	134-500	136-1220	136-1280	136-1340	137-170	137-300	137-330	137-360	137-950
	138-300	138-420	138-530	139-140	141-10	141-10	141-100	141-100	141-260	141-360	141-590	141-610	141-820	141-1070
	142-9	142-9	142-90	142-90	143-44	143-44	143-440	143-440	143-460	143-520	143-580	143-650	143-930	143-1030
	143-1050	143-1270	143-1290	143-1400	143-1460	143-2090	143-3200	143-3310	143-333	143-3330	143-3330	143-3370	143-3510	143-3530
	144-190	144-210	144-280	144-300	144-420	145-10	145-10	145-100	145-100	145-120	146-8	146-8	146-80	146-80
	146-140	146-160	147-8	147-8	147-80	147-80	147-120	148-9	148-9	148-90	148-90	148-140	150-3	150-3
	150-3	150-30	150-30	150-30	150-420	150-1140	150-1170	150-1180	151-160	151-18	151-180	151-180	151-26	151-260
	151-260	151-33	151-330	151-350	151-39	151-390	151-390	151-45	151-450	151-450	151-46	151-460	151-460	151-49
	151-490	151-490	151-54	151-540	151-540	151-67	151-670	151-670	151-68	151-680	151-680	151-71	151-710	151-710
	151-74	151-740	151-740	151-76	151-760	151-760	151-940	151-950	151-960	151-970	151-980	151-990	151-100	151-1000
	151-1000	151-137	151-1370	151-1370	151-143	151-1430	151-1430	151-147	151-1470	151-1470	151-162	151-1620	151-1620	151-166
	151-1660	151-1660	151-172	151-1720	151-1720	151-176	151-1760	151-1760	151-182	151-1820	151-1820	151-196	151-1960	151-1960
	151-200	151-2000	151-2000	151-213	151-2130	151-2130	151-219	151-2190	151-2190	152-470	153-11	153-11	153-110	153-110
	154-12	154-12	154-120	154-120	156-13	156-130	156-14	156-14	156-14	156-140				
M#IOSE	1-A000	87-1530												
M#LDRO	1-C420	87-1530	137-33	137-330	143-46	143-460	143-52	143-520	143-58	143-580	143-65	143-650	143-93	143-930
	143-127	143-1270	143-129	143-1290	143-209	143-2090	143-351	143-3510						
M#MASK	1-8710	87-1530												
M#MCHI	1-40	87-153	87-1530	87-1530										
M#MCLO	1-8240	87-153	87-1530	87-1530										
M#MSK1	1-8770	87-1530												
M#POP	1-8810	87-1530	89-23	89-230	90-21	90-210	101-17	101-170	101-21	101-210	101-25	101-250	101-29	101-290
	101-39	101-390	101-102	101-1020	101-106	101-1060	101-111	101-1110	101-115	101-1150	101-120	101-1200	101-124	101-1240
	101-128	101-1280	101-138	101-1380	101-186	101-1860	134-13	134-130	134-35	134-350	134-54	134-540	141-107	141-1070
	142-15	142-150	144-42	144-420	145-12	145-120	146-16	146-160	147-12	147-120	148-14	148-140	152-47	152-470
	153-41	153-410	154-55	154-550										
M#PRIN	1-8360	87-1530	102-78	102-780	102-80	102-800	102-82	102-820	102-84	102-840	127-39	127-390	127-43	127-430
	141-26	141-260	141-36	141-360	141-59	141-590	141-61	141-610	141-82	141-820	143-320	143-3200	151-16	151-160
	151-94	151-940	151-95	151-950	151-96	151-960	151-97	151-970	151-98	151-980	151-99	151-990		
M#PUSH	1-8310	87-1530	89-12	89-120	90-11	90-110	101-15	101-150	101-19	101-190	101-23	101-230	101-27	101-270
	101-37	101-370	101-100	101-1000	101-104	101-1040	101-108	101-1080	101-113	101-1130	101-117	101-1170	101-122	101-1220
	101-126	101-1260	101-136	101-1360	101-165	101-1650	134-11	134-110	134-32	134-320	134-50	134-500	141-10	141-100
	142-9	142-90	143-44	143-440	145-10	145-100	146-8	146-80	147-8	147-80	148-9	148-90	150-3	150-30
	153-11	153-110	154-12	154-120										
M#PUT	1-C720	87-1530	102-78	102-78	102-78	102-780	102-80	102-80	102-80	102-80	102-82	102-82	102-82	102-820
	102-84	102-84	102-84	102-840	127-39	127-39	127-390	127-43	127-43	127-430	129-20	129-20	129-20	129-20
	129-200	137-30	137-30	137-30	137-30	137-300	139-14	139-14	139-14	139-14	139-140	141-26	141-26	141-260
	141-36	141-36	141-360	141-59	141-59	141-59	141-59	141-59	141-59	141-59	141-59	141-590	141-61	141-61
	141-61	141-61	141-61	141-610	141-82	141-82	141-82	141-82	141-820	143-140	143-140	143-140	143-140	143-1400
	143-320	143-320	143-320	143-320	143-320	143-3200	151-16	151-16	151-16	151-16	151-16	151-160	151-94	151-94
	151-940	151-95	151-95	151-950	151-96	151-96	151-96	151-97	151-97	151-970	151-98	151-98	151-980	151-99
	151-99	151-990												
M#PUT1	1-C810	87-1530	102-78	102-78	102-78	102-780	102-780	102-780	102-80	102-80	102-80	102-800	102-800	102-800
	102-82	102-82	102-82	102-820	102-820	102-820	102-84	102-84	102-84	102-840	102-840	102-840	127-39	127-39
	127-390	127-390	127-43	127-43	127-430	127-430	129-20	129-20	129-20	129-20	129-200	129-200	129-200	129-200
	137-30	137-30	137-30	137-30	137-300	137-300	137-300	137-300	139-14	139-14	139-14	139-14	139-140	139-140
	139-140	139-140	141-26	141-26	141-260	141-260	141-36	141-36	141-360	141-360	141-59	141-59	141-59	141-59
	141-59	141-59	141-59	141-59	141-590	141-590	141-590	141-590	141-590	141-590	141-590	141-590	141-61	141-61
	141-61	141-61	141-61	141-610	141-610	141-610	141-610	141-610	141-82	141-82	141-82	141-82	141-820	141-820
	141-820	141-820	143-140	143-140	143-140	143-140	143-1400	143-1400	143-1400	143-1400	143-320	143-320	143-320	143-320
	143-320	143-3200	143-3200	143-3200	143-3200	143-3200	151-16	151-16	151-16	151-16	151-16	151-160	151-160	151-160
	151-160	151-160	151-94	151-94	151-940	151-940	151-95	151-95	151-950	151-950	151-96	151-96	151-960	151-960
	151-97	151-97	151-970	151-970	151-98	151-98	151-980	151-980	151-99	151-99	151-990	151-990		
M#RADI	1-D770	87-1530	143-333	143-3330	151-18	151-180	151-26	151-260	151-33	151-330	151-39	151-390	151-45	151-450
	151-46	151-460	151-49	151-490	151-54	151-540	151-67	151-670	151-68	151-680	151-71	151-710	151-74	151-740





CZUDIAO UDA50-A/KDA50-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page M-8  
 Cross reference table (CREF V05.01)

	151-980	151-99	151-990	151-100	151-1000	151-137	151-1370	151-143	151-1430	151-147	151-1470	151-162	151-1620	151-166
	151-1660	151-172	151-1720	151-176	151-1760	151-182	151-1820	151-196	151-1960	151-200	151-2000	151-213	151-2130	151-219
MEMWORD	151-2190	152-47	152-470											
	1-C940	87-1530	87-202	87-2020	88-11	88-11	88-110	102-9	102-9	102-9	102-90	105-26	105-26	105-26
	105-260	105-44	105-44	105-44	105-440	105-94	105-94	105-94	105-940	105-112	105-112	105-112	105-1120	121-25
	121-25	121-25	121-250	129-91	129-91	129-91	129-910	133-35	133-35	133-35	133-350	133-48	133-48	133-48
	133-480	136-122	136-122	136-122	136-1220	136-128	136-128	136-128	136-1280	136-134	136-134	136-134	136-1340	137-36
	137-36	137-36	137-360	137-95	137-95	137-95	137-950	138-42	138-42	138-42	138-420	138-53	138-53	138-53
	138-530	141-93	141-930	143-103	143-103	143-103	143-1030	143-333	143-333	143-3330	143-3330	143-3530	144-19	144-19
	144-19	144-190	144-28	144-28	144-280	144-280	146-140	147-10	147-100	148-12	148-120	150-1180	151-18	151-18
	151-180	151-180	151-26	151-26	151-260	151-260	151-33	151-33	151-330	151-330	151-39	151-39	151-390	151-390
	151-45	151-45	151-450	151-450	151-46	151-46	151-460	151-460	151-49	151-49	151-490	151-490	151-54	151-54
	151-540	151-540	151-67	151-67	151-670	151-670	151-68	151-68	151-680	151-680	151-71	151-71	151-710	151-710
	151-74	151-74	151-740	151-740	151-76	151-76	151-760	151-760	151-100	151-100	151-1000	151-1000	151-137	151-137
	151-1370	151-1370	151-143	151-143	151-1430	151-1430	151-147	151-147	151-1470	151-1470	151-162	151-162	151-1620	151-1620
	151-166	151-166	151-1660	151-1660	151-172	151-172	151-1720	151-1720	151-176	151-176	151-1760	151-1760	151-182	151-182
	151-1820	151-1820	151-196	151-196	151-1960	151-1960	151-200	151-200	151-2000	151-2000	151-213	151-213	151-2130	151-2130
	151-219	151-219	151-2190	151-2190	153-27	153-270	153-35	153-350	153-38	153-380	154-37	154-370	154-39	154-390
	154-42	154-420	154-44	154-440	154-46	154-460	154-48	154-480	156-14	156-140				
MAXFER	1-8820	87-1530												
MANUAL	1-;620	87-1530	143-331	150-42										
MEMORY	1-;660	87-1530	143-146											
OPEN	1-;710	87-1530												
PNT	87-1460	140-25	140-29	140-34										
PNT...	87-1070	101-16	101-20	101-24	101-28	101-38	101-101	101-105	101-109	101-118	101-123	101-127	101-137	101-141
	101-148	101-155	101-159	101-172	102-156	102-236	114-40	114-42	117-53	118-26	120-68	120-81	140-25	140-29
	140-34	141-13	141-21	143-132	143-311	150-16	150-23	150-28	150-77					
PNTB	87-1340	101-16	101-20	101-24	101-28	101-38	101-101	101-105	101-109	101-118	101-123	101-127	101-137	101-141
	101-148	101-155	101-159	101-172	120-68	120-81								
PNTF	87-1300	102-156	102-236	143-132	143-311	150-16	150-23	150-28	150-77					
PNTS	87-1420	141-13	141-21											
PNTX	87-1380	114-40	114-42	117-53	118-26									
POINTE	1-;760	87-1530	87-192											
POP	87-310	102-35	102-76	102-110	102-237	117-32	118-28	118-39	120-15	120-35	120-41	120-96	120-108	120-120
	121-26	121-32	122-32	123-62	123-70	124-29	125-34	126-21	126-26	127-50	128-27	128-30	128-43	128-45
	130-33	130-34	132-26	133-39	133-49	133-51	134-34	135-48	136-135	136-143	137-62	138-27	139-25	140-30
	140-35	141-58	141-81	141-83	141-91	151-203								
PRINT	87-960	101-175	102-172	102-182	102-219	102-245	120-32	120-40	120-70	120-80	123-59	123-67	140-28	140-33
	140-36	141-15												
PRINTB	1-<390	87-1530	102-80											
PRINTF	1-<790	87-1530	102-78	127-39	127-43	143-320	151-16	151-94	151-95	151-96	151-97	151-98	151-99	
PRINTS	1-;190	87-1530	102-84	141-26	141-36	141-59	141-61	141-82						
PRINTX	1-;590	87-1530	102-82											
PUSH	87-180	102-30	102-69	102-104	102-108	117-30	118-21	120-9	120-24	120-26	120-93	120-105	120-117	121-14
	122-14	123-17	123-23	123-41	124-17	125-20	126-8	126-15	127-15	127-27	128-14	128-19	130-17	132-17
	133-12	133-46	135-14	136-30	137-18	138-21	139-13	140-16	140-23	141-12	141-38	141-62	151-15	151-118
READBU	1-;990	87-1530												
REDEF	1->030	87-1530	143-46	143-52	143-58	143-65								
RFLAGS	1->080	87-1530	114-35	116-40	117-45									
SETPRI	1->130	87-1530	143-351											
SETVEC	1->180	87-1530	129-20	137-30	139-14	143-140								
SLASH	1->240	87-1530												
STARS	1->380	87-1530												
SVC	1->520	87-1520	87-153											
TABLE	87-710	97-29	98-33	153-13	154-13									
XFER	1-8120	87-1530	141-930	143-3530	146-140	147-100	148-120	150-1180						

CZUDIAO UDASO-A/KDASO-Q DRIVE E MACRO V05.01b Sunday 07-Oct-84 20:58 Page M-9  
Cross reference table (CREF V05.01)

XFERF	1-0160	87-1530
FERT	1-0200	87-1530