

RP04/05/06

READ/WRITE TEST

MD-11-DZRJA-A

EP-DZRJA-A-DL-A

NOV 1978

COPYRIGHT © 1978



FICHE 1 OF 1

MADE IN USA



1

CO1

NO-11-02RJA-AA RPO4/5/6 MECHANICAL AND READ/WRITE TEST MACY11 27(1006) 02-NOV-76 18:27 PAGE 2  
RPO456.010 14-APR-76 00:00

2

MD-11-DZJJA-AA RPO4/5/6 MECHANICAL AND READ/WRITE TEST MACY11 27(1006) 02-NOV-76 18:27 PAGE 4  
DZJJA.014 19-APP-76 00:30

```

*TITLE MD-11-DZJJA-AA RPO4/5/6 MECHANICAL AND READ/WRITE TEST
*COPYRIGHT (C) 1976
*DIGITAL EQUIPMENT CORP.
*MAYNARD, MASS. 01754
*PROGRAM BY C. HESS
*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
*PACKAGE (MAINDEC-11-DZQAC-C2), SEPT 14, 1976.

```

.SBTTL CONTROL SWITCH SETTINGS

SWITCH	STATE	USE
15	0	WRITE PACK BEFORE TESTING (TEST 21)
	1	INHIBIT WRITING PACK BEFORE TESTING (TEST 21)
14	0	NO STALL BETWEEN DRIVE FUNCTIONS
	1	STALL AFTER EVERY DRIVE FUNCTION
13	0	USE SPECIFIC STALL TIME
	1	USE RANDOM STALL
12	0	NO INCREMENTING STALL IN TEST 4
	1	DO INCREMENTING STALL IN TEST 4
8	0	DO IMPLIED SEEKS WITH DATA FROM SERS
	1	DO EXPLICIT SEEKS BEFORE DATA FROM SERS
7	0	DO "READ HEADER AND DATA" IN TESTS 0-11
	1	DO EXPLICIT SEEKS IN TESTS 0-11
6	0	60 HZ
	1	50 HZ
5	0	RUN WATCHDOG TIMER
	1	INHIBIT WATCHDOG TIMER
0	0	TEST DRIVE(S) IN 22 SECTOR (16 BIT) MODE
	1	TEST DRIVE(S) IN 20 SECTOR (18 BIT) MODE

.SBTTL OPERATIONAL SWITCH SETTINGS

SWITCH	USE
15	HALT ON ERROR
14	LOOP ON TEST
13	INHIBIT ERROR TYPEOUTS
10	BELL ON ERROR
9	LOOP ON ERROR
8	PRINT ERROR MESSAGE ON LINE PRINTER
7	READ CONTROL SWITCH SETTINGS FROM TTY
6	INHIBIT TIME REPORTS (TESTS 12-15)
5	REPORT ONE ERROR PER SECTOR (TESTS 16 & 17)
4	INHIBIT WRITES (TEST 15)
3	INHIBIT WRITE CHECKS (TEST 20)
2	INHIBIT READ AND SOFTWARE COMPARES (TEST 20)
1	INHIBIT SOFTWARE COMPARES (TEST 20)
0	PERFORM READ AFTER WRITE CHECK ERROR (TEST 20)

.SBTTL TRAP CATCHER

000000

.=0



# E01

5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100

```
000174 000174
000176 000000
000176 000000

; *ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
; *SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
; *LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
; =174
DISPREG: .WORD 0 ; SOFTWARE DISPLAY REGISTER
SMREG: .WORD 0 ; SOFTWARE SWITCH REGISTER

.SBTTL ACT11 HOOKS

; *****
; HOOKS REQUIRED BY ACT11
; $SVPC= ; SAVE PC
; =46
SEND=30 ; 1) SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
; =52
; .WORD 0 ; 2) SET LOC.52 TO ZERO
; = $SVPC ; RESTORE PC

.SBTTL STARTING ADDRESSES
; =200
; *200 = NORMAL START
; JMP @START1
; *204 = SELECT OPERATING PARAMETERS
; JMP @START2
; *210 = SELECT RH11/RPD4/5/6 ADDRESSES
; JMP @START3
; *214 = COMBINATION OF 204 AND 210
; JMP @START4

.SBTTL BASIC DEFINITIONS

; *INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
001100
STACK= 1100
.EQUIV EMT,ERROR ; BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE ; BASIC DEFINITION OF SCOPE CALL

; *MISCELLANEOUS DEFINITIONS
000011 HT= 11 ; CODE FOR HORIZONTAL TAB
000012 LF= 12 ; CODE FOR LINE FEED
000015 CR= 15 ; CODE FOR CARRIAGE RETURN
000200 CRLF= 200 ; CODE FOR CARRIAGE RETURN-LINE FEED
177776 PS= 177776 ; PROCESSOR STATUS WORD
; .EQUIV PS,PSW
177774 STKLMT= 177774 ; STACK LIMIT REGISTER
177772 PIPQ= 177772 ; PROGRAM INTERRUPT REQUEST REGISTER
177570 DSAR= 177570 ; HARDWARE SWITCH REGISTER
177570 DCISP= 177570 ; HARDWARE DISPLAY REGISTER

; *GENERAL PURPOSE REGISTER DEFINITIONS
000000 R0= %0 ; GENERAL REGISTER
000001 R1= %1 ; GENERAL REGISTER
000002 R2= %2 ; GENERAL REGISTER
000003 R3= %3 ; GENERAL REGISTER
000004 R4= %4 ; GENERAL REGISTER
000005 R5= %5 ; GENERAL REGISTER
000006 R6= %6 ; GENERAL REGISTER
```

BASIC DEFINITIONS

115	000007	R7=	X7	::	GENERAL REGISTER
116	000006	SP=	X6	::	STACK POINTER
117	000007	PC=	X7	::	PROGRAM COUNTER

.\*PRIORITY LEVEL DEFINITIONS

118		PR0=	0	::	PRIORITY LEVEL 0
119	000000	PR1=	40	::	PRIORITY LEVEL 1
120	000040	PR2=	100	::	PRIORITY LEVEL 2
121	000100	PR3=	140	::	PRIORITY LEVEL 3
122	000140	PR4=	200	::	PRIORITY LEVEL 4
123	000200	PR5=	240	::	PRIORITY LEVEL 5
124	000240	PR6=	300	::	PRIORITY LEVEL 6
125	000300	PR7=	340	::	PRIORITY LEVEL 7
126	000340				

.\*"SWITCH REGISTER" SWITCH DEFINITIONS

127	100000	SW15=	100000		
128	040000	SW14=	40000		
129	020000	SW13=	20000		
130	010000	SW12=	10000		
131	004000	SW11=	4000		
132	002000	SW10=	2000		
133	001000	SW09=	1000		
134	000400	SW08=	400		
135	000200	SW07=	200		
136	000100	SW06=	100		
137	000040	SW05=	40		
138	000020	SW04=	20		
139	000010	SW03=	10		
140	000004	SW02=	4		
141	000002	SW01=	2		
142	000001	SW00=	1		
143		.EQUIV	SW09, SW9		
144		.EQUIV	SW08, SW8		
145		.EQUIV	SW07, SW7		
146		.EQUIV	SW06, SW6		
147		.EQUIV	SW05, SW5		
148		.EQUIV	SW04, SW4		
149		.EQUIV	SW03, SW3		
150		.EQUIV	SW02, SW2		
151		.EQUIV	SW01, SW1		
152		.EQUIV	SW00, SW0		

.\*DATA BIT DEFINITIONS (BIT00 TO BIT15)

153	100000	BIT15=	100000
154	040000	BIT14=	40000
155	020000	BIT13=	20000
156	010000	BIT12=	10000
157	004000	BIT11=	4000
158	002000	BIT10=	2000
159	001000	BIT09=	1000
160	000400	BIT08=	400
161	000200	BIT07=	200
162	000100	BIT06=	100
163	000040	BIT05=	40
164	000020	BIT04=	20
165	000010	BIT03=	10

BASIC DEFINITIONS

171 000004  
172 000002  
173 000001  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186 000004  
187 000010  
188 000014  
189 000014  
190 000014  
191 000020  
192 000024  
193 000030  
194 000034  
195 000060  
196 000064  
197 000240  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223 000001  
224 000002  
225 000004  
226 000010

BIT02= 4  
BIT01= 2  
BIT00= 1  
.EQUIV BIT09,BIT9  
.EQUIV BIT08,BIT8  
.EQUIV BIT07,BIT7  
.EQUIV BIT06,BIT6  
.EQUIV BIT05,BIT5  
.EQUIV BIT04,BIT4  
.EQUIV BIT03,BIT3  
.EQUIV BIT02,BIT2  
.EQUIV BIT01,BIT1  
.EQUIV BIT00,BIT0

;\*BASIC "CPU" TRAP VECTOR ADDRESSES

ERRVEC= 4 ; TIME OUT AND OTHER ERRORS  
RESVEC= 10 ; RESERVED AND ILLEGAL INSTRUCTIONS  
TBITVEC= 14 ; "T" BIT  
TRTVEC= 14 ; TRACE TRAP  
BPTVEC= 14 ; BREAKPOINT TRAP (BPT)  
IOTVEC= 20 ; INPUT/OUTPUT TRAP (IOT) \*\*SCOPE\*\*  
PWRVEC= 24 ; POWER FAIL  
EMTVEC= 30 ; EMULATOR TRAP (EMT) \*\*ERROR\*\*  
TRAPVEC= 34 ; "TRAP" TRAP  
TKVEC= 60 ; TTY KEYBOARD VECTOR  
TPVEC= 64 ; TTY PRINTER VECTOR  
PIRQVEC= 240 ; PROGRAM INTERRUPT REQUEST VECTOR

;;\*\*\*\*\*

.SBTTL RH11 REGISTERS

;;\*\*\*\*\*

;CONTROL AND STATUS REGISTER 1 (RPCS1)

000100 IE= 100 ; INTERRUPT ENABLE (BIT #6)  
000200 RDY= 200 ; READY (BIT #7)  
000400 A16= 400 ; HIGH ORDER BUS ADDRESS BIT (BIT #8)  
001000 A17= 1000 ; HIGH ORDER BUS ADDRESS BIT (BIT #9)  
002000 PSEL= 2000 ; PORT SELECT (BIT #10)  
020000 MACE= 20000 ; MASSBUSS PARITY ERROR (BIT #13)  
040000 TRFE= 40000 ; TRANSFER ERROR (BIT #14)  
;SC= 100000 ; SPECIAL CONDITION (BIT #15)

;WORD COUNT REGISTER (RPWC)  
;(EACH BIT IS CALLED BY BIT NUMBER)

;BUS ADDRESS REGISTER (RPBA)  
;(EACH BIT IS CALLED BY BIT NUMBER)

;CONTROL AND STATUS REGISTER 2 (RPCS2)

US1= 1 ; UNIT SELECT (BIT #0)  
US2= 2 ; UNIT SELECT (BIT #1)  
US4= 4 ; UNIT SELECT (BIT #2)  
BAI= 10 ; BUS ADDRESS INCREMENT INHIBIT (BIT #3)



237  
236  
235  
234  
233  
232  
231  
230  
229  
228  
227  
226  
225  
224  
223  
222  
221  
220  
219  
218  
217  
216  
215  
214  
213  
212  
211  
210  
209  
208  
207  
206  
205  
204  
203  
202  
201  
200  
199  
198  
197  
196  
195  
194  
193  
192  
191  
190  
189  
188  
187  
186  
185  
184  
183  
182  
181  
180  
179  
178  
177  
176  
175  
174  
173  
172  
171  
170  
169  
168  
167  
166  
165  
164  
163  
162  
161  
160  
159  
158  
157  
156  
155  
154  
153  
152  
151  
150  
149  
148  
147  
146  
145  
144  
143  
142  
141  
140  
139  
138  
137  
136  
135  
134  
133  
132  
131  
130  
129  
128  
127  
126  
125  
124  
123  
122  
121  
120  
119  
118  
117  
116  
115  
114  
113  
112  
111  
110  
109  
108  
107  
106  
105  
104  
103  
102  
101  
100  
99  
98  
97  
96  
95  
94  
93  
92  
91  
90  
89  
88  
87  
86  
85  
84  
83  
82  
81  
80  
79  
78  
77  
76  
75  
74  
73  
72  
71  
70  
69  
68  
67  
66  
65  
64  
63  
62  
61  
60  
59  
58  
57  
56  
55  
54  
53  
52  
51  
50  
49  
48  
47  
46  
45  
44  
43  
42  
41  
40  
39  
38  
37  
36  
35  
34  
33  
32  
31  
30  
29  
28  
27  
26  
25  
24  
23  
22  
21  
20  
19  
18  
17  
16  
15  
14  
13  
12  
11  
10  
9  
8  
7  
6  
5  
4  
3  
2  
1  
0

000040  
000100  
000200  
000400  
001000  
002000  
004000  
010000  
020000  
040000  
100000

:PAT= 20  
:CLR= 40  
:IR= 100  
:OR= 200  
:MPE= 400  
:MXF= 1000  
:PGE= 2000  
:NEH= 4000  
:NED= 10000  
:LPE= 20000  
:WCE= 40000  
:DLT= 100000

:MASSBUS PARITY TEST (BIT #4)  
:CLEAR (BIT #5)  
:INPUT READY (BIT #6)  
:OUTPUT READY (BIT #7)  
:MASS BUS PARITY ERROR (BIT #8)  
:MISSED TRANSFER ERROR (BIT #9)  
:PROGRAM ERROR (BIT #10)  
:NON EXISTENT MEMORY (BIT #11)  
:NON EXISTENT DRIVE (BIT #12)  
:UNIBUS PARITY ERROR (BIT #13)  
:WRITE CHECK ERROR (BIT #14)  
:DATA LATE (BIT #15)

:DATA BUFFER REGISTER (RPDB)  
:(EACH BIT IS CALLED BY BIT NUMBER)

;;\*\*\*\*\*

.SBTTL RPD4/5/6 REGISTERS

;;\*\*\*\*\*

:CONTROL AND STATUS 1 REGISTER. (#00)

000001  
000002  
000004  
000010  
000020  
000040  
004000

GO= 1  
F1= 2  
F2= 4  
F3= 10  
F4= 20  
F5= 40  
DVA= 4000

:GO BIT (BIT #0)  
:FUNCTION CODE BIT #1  
:FUNCTION CODE BIT #2  
:FUNCTION CODE BIT #3  
:FUNCTION CODE BIT #4  
:FUNCTION CODE BIT #5  
:DEVICE AVAILABLE (BIT #11)

:DRIVE STATUS REGISTER (RPDS1) (#01)

000002  
000004  
000010  
000020  
000040  
000100  
000200  
000400  
001000  
002000  
004000  
010000  
020000  
040000  
100000

:DFS= 1  
:OFF20= 2  
:DTGB= 4  
:GRV= 10  
:DL64= 20  
:DEL= 40  
:VV= 100  
:DRY= 200  
:DPR= 400  
:PGM= 1000  
:LST= 2000  
:WRL= 4000  
:MOL= 10000  
:PIP= 20000  
:ERR= 40000  
:ATA= 100000

DRIVE FORWARD 5"/SEC. (BIT #0)  
:DRIVE FORWARD 20"/SEC. (BIT #1)  
:DRIVE TO INNER GUARD BAND (BIT #2)  
:GO REVERSE (BIT #3)  
:DIFFERENCE LESS THAN 64 (BIT #4)  
:DIFFERENCE EQUALS 1 (BIT #5)  
:VOLUME VALID (BIT #6)  
:DRIVE READY (BIT #7)  
:DRIVE PRESENT (BIT #8)  
:PROGRAMABLE (BIT #9)  
:LAST SECTOR TRANSFERRED (BIT #10)  
:WRITE LOCK (BIT #11)  
:MEDIUM ON-LINE (BIT #12)  
:POSITIONING OPERATION IN PROGRESS (BIT #13)  
:COMPOSITE ERROR (BIT #14)  
:ATTENTION ACTIVE (BIT #15)

:ERROR REGISTER #01 (RPER1) (#02)

000001  
000002

ILF= 1  
ILR= 2

:ILLEGAL FUNCTION (BIT #0)  
:ILLEGAL REGISTER (BIT #1)

283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333  
334  
335  
336  
337  
338

000004  
000010  
000020  
000040  
000100  
000200  
000400  
001000  
002000  
004000  
010000  
020000  
040000  
100000  
  
000001  
000002  
000004  
000010  
000020  
000040  
000200  
  
000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
  
000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
  
000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
000400  
020000  
040000  
100000

RMR= 4  
PAR= 10  
FER= 20  
WCF= 40  
ECH= 100  
HCE= 200  
HCRC= 400  
AOE= 1000  
IAE= 2000  
MLE= 4000  
JTE= 10000  
OPT= 20000  
UNS= 40000  
DCK= 100000

; REGISTER MODIFICATION REFUSED (BIT #2)  
; WRITABILITY ERROR (BIT #3)  
; FORMAT ERROR (BIT #4)  
; WRITE CLOCK FAIL (BIT #5)  
; ECC HARD ERROR (BIT #6)  
; HEADER COMPARE ERROR (BIT #7)  
; HEADER CRC ERROR (BIT #8)  
; ADDRESS OVERFLOW ERROR (BIT #9)  
; INVALID ADDRESS ERROR (BIT #10)  
; WRITE LOCK ERROR (BIT #11)  
; DRIVE TIMING ERROR (BIT #12)  
; OPERATION INCOMPLETE (BIT #13)  
; DRIVE UNSAFE (BIT #14)  
; DATA CHECK ERROR (BIT #15)

; MAINTAINABILITY REGISTER (RPMR) (#03)

DMD= 1  
MCLK= 2  
MINX= 4  
MSTCK= 10  
MRD= 20  
MWR= 40  
DTSY= 200

; DIAGNOSTIC MODE (BIT #0)  
; MAINTAINABILITY CLOCK (BIT #1)  
; MAINTAINABILITY INDEX (BIT #2)  
; MAINTAINABILITY SECTOR CLOCK (BIT #3)  
; MAINTAINABILITY READ (BIT #4)  
; MAINTAINABILITY WRITE (BIT #5)  
; MAINTAINABILITY SYNC DETECTED (BIT #7)

; ATTENTION SUMMARY PSEUDO-REGISTER (RPARS) (#04)

AT0= 1  
AT1= 2  
AT2= 4  
AT3= 10  
AT4= 20  
AT5= 40  
AT6= 100  
AT7= 200

; DEVICE 0 (BIT #0)  
; DEVICE 1 (BIT #1)  
; DEVICE 2 (BIT #2)  
; DEVICE 3 (BIT #3)  
; DEVICE 4 (BIT #4)  
; DEVICE 5 (BIT #5)  
; DEVICE 6 (BIT #6)  
; DEVICE 7 (BIT #7)

; DESIRED SECTOR/TRACK ADDRESS REGISTER (RPDA) (#05)  
; (EACH BIT IS CALLED BY BIT NUMBER)

; DRIVE TYPE REGISTER (RPDT) (#06)

DT00= 1  
DT01= 2  
DT02= 4  
DT03= 10  
DT04= 20  
DT05= 40  
DT06= 100  
DT07= 200  
DT08= 400  
DRQ= 4000  
MOM= 20000  
TAP= 40000  
NBQ= 100000

; DRIVE TYPE NUMBER BIT 1  
; DRIVE TYPE NUMBER BIT 2  
; DRIVE TYPE NUMBER BIT 3  
; DRIVE TYPE NUMBER BIT 4  
; DRIVE TYPE NUMBER BIT 5  
; DRIVE TYPE NUMBER BIT 6  
; DRIVE TYPE NUMBER BIT 7  
; DRIVE TYPE NUMBER BIT 8  
; DRIVE TYPE NUMBER BIT 9  
; DRIVE REQUEST REQUIRED (BIT #11)  
; MOVING HEAD (BIT #13)  
; TAPE DRIVE (BIT #14)  
; NOT BLOCK ADDRESSED (BIT #15)

; LOOK-AHEAD REGISTER (RPLA) (#07)

333  
334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394

050001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
  
001000  
002000  
004000  
010000  
020000  
040000  
100000  
  
000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
000400  
001000  
002000  
004000  
010000  
020000  
100000  
  
000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
000400  
001000  
002000  
004000  
020000  
  
000001  
000002

EXT1= 1  
EXT2= 2  
EXT4= 4  
EXT10= 10  
EXT20= 20  
EXT40= 40  
SC1= 100  
SC2= 200  
SC4= 400  
SC10= 1000  
SC20= 2000  
TRK1= 4000  
TRK2= 10000  
TRK4= 20000  
TRK10= 40000  
TRK20= 100000  
  
;RPO4 ERROR REGISTER #2 (RPER2) (#10)  
WCU= 1  
CSF= 2  
WSU= 4  
CSU= 10  
MSE= 20  
TDF= 40  
TUF= 100  
FEM= 200  
WRU= 400  
MHS= 1000  
NHS= 2000  
IXE= 4000  
VU30= 10000  
PLU= 20000  
ACU= 100000  
  
;RPO5/6 ERROR REGISTER #02 (RPER2) (#10)  
WCU= 1  
CSF= 2  
WSU= 4  
CSU= 10  
RAW= 20  
TDF= 40  
TUF= 100  
ABS= 200  
WRU= 400  
MHS= 1000  
NHS= 2000  
IXE= 4000  
PLU= 20000  
  
;OFFSET REGISTER (RPOF) (#11)  
OF25= 1  
OF50= 2

;EXTENSION 1 (BIT #0)  
;EXTENSION 2 (BIT #1)  
;EXTENSION 3 (BIT #2)  
;EXTENSION 4 (BIT #3)  
;EXTENSION 5 (BIT #4)  
;EXTENSION 6 (BIT #5)  
;SECTOR COUNT FIELD 0 (BIT #6)  
;SECTOR COUNT FIELD 1 (BIT #7)  
;SECTOR COUNT FIELD 2 (BIT #8)  
;SECTOR COUNT FIELD 3 (BIT #9)  
;SECTOR COUNT FIELD 4 (BIT #10)  
;TRACK FIELD 1 (BIT #11)  
;TRACK FIELD 2 (BIT #12)  
;TRACK FIELD 3 (BIT #13)  
;TRACK FIELD 4 (BIT #14)  
;TRACK FIELD 5 (BIT #15)  
  
;WRITE CURRENT UNSAFE (BIT #0)  
;CURRENT SINK FAILURE (BIT #1)  
;WRITE SELECT UNSAFE (BIT #2)  
;CURRENT SWITCH UNSAFE (BIT #3)  
;MOTOR SEQUENCE ERROR (BIT #4)  
;TRANSITIONS DETECTOR FAILURE (BIT #5)  
;TRANSITIONS UNSAFE (BIT #6)  
;FAILSAFE ENABLED (BIT #7)  
;WRITE READY UNSAFE (BIT #8)  
;MULTIPLE HEAD SELECT (BIT #9)  
;NO HEAD SELECTION (BIT #10)  
;INDEX ERROR (BIT #11)  
;30VOLT UNSAFE (BIT #12)  
;PLO UNSAFE (BIT #13)  
;AC UNSAFE (BIT #15)  
  
;WRITE CURRENT UNSAFE (BIT #0)  
;CURRENT SINK FAILURE (BIT #1)  
;WRITE SELECT UNSAFE (BIT #2)  
;CURRENT SWITCH UNSAFE (BIT #3)  
;READ AND WRITE (BIT #4)  
;TRANSITIONS DETECTOR FAILURE (BIT #5)  
;TRANSITIONS UNSAFE (BIT #6)  
;ABNORMAL STOP (BIT #7)  
;WRITE READY UNSAFE (BIT #8)  
;MULTIPLE HEAD SELECT (BIT #9)  
;NO HEAD SELECTION (BIT #10)  
;INDEX ERROR (BIT #11)  
;PLO UNSAFE (BIT #12)  
  
;OFFSET 25 MICRO INCHES (BIT #0)  
;OFFSET 50 MICRO INCHES (BIT #1)



# K01

```
395 000004 OF100= 4 ;OFFSET 100 MICRO INCHES (BIT #2)
396 000010 OF200= 10 ;OFFSET 200 MICRO INCHES (BIT #3)
397 000020 OF400= 20 ;OFFSET 400 MICRO INCHES (BIT #4)
398 000040 OF800= 40 ;OFFSET 800 MICRO INCHES (BIT #5)
399 000200 OFREV= 200 ;OFFSET NEGATIVE (REVERSE) (BIT #5)
400 002000 HCI= 2000 ;HEADER COMPARE INHIBIT (BIT #10)
401 004000 ECI= 4000 ;ERROR CORRECTION CODE INHIBIT (BIT #11)
402 010000 FMT22= 10000 ;FORMAT BIT (BIT #12)
403
404 ;DESIRED CYLINDER ADDRESS (RPCA) (#12)
405 ;(EACH BIT IS CALLED BY BIT NUMBER)
406
407 ;CURRENT CYLINDER ADDRESS (RPCC) (#13)
408 ;(EACH BIT IS CALLED BY BIT NUMBER)
409
410 ;SERIAL NUMBER REGISTER (RPSN) (#14)
411 ;(EACH IS CALLED BY BIT NUMBER)
412
413 ;RPO4 ERROR REGISTER #03 (RPER3) (#15)
414
415 000001 PSU= 1 ;PACK SPEED UNSAFE (BIT #0)
416 000002 VUF= 2 ;VELOCITY UNSAFE (BIT #1)
417 000010 UMR= 10 ;ANY UNSAFE EXCEPT READ/WRITE (BIT #3)
418 000040 ACL= 40 ;AC LOW (BIT #5)
419 000100 DCL= 100 ;DC LOW (BIT #6)
420 040000 SKI= 40000 ;SEEK INCOMPLETE (BIT #14)
421 100000 OCYL= 100000 ;OFF CYLINDER (BIT #15)
422
423 ;RPO5/6 ERROR REGISTER #03 (RPER3) (#15)
424
425 000001 DCU= 1 ;DC UNSAFE (BIT #0)
426 000002 WAC= 2 ;WRITE AND OFFSET (BIT #1)
427 000040 ACL= 40 ;AC LOW (BIT #5)
428 000100 DCL= 100 ;DC LOW (BIT #6)
429 020000 OPE= 20000 ;OPERATOR PLUG ERROR (BIT #13)
430 040000 SKI= 40000 ;SEEK INCOMPLETE (BIT #14)
431 100000 OCYL= 100000 ;OFF CYLINDER ERROR (BIT #15)
432
433 ;ECC POSITION REGISTER (RPEC1) (#16)
434 ;(EACH BIT IS CALLED BY BIT NUMBER)
435
436 ;ECC PATTERN REGISTER (RPEC2) (#17)
437 ;(EACH BIT IS CALLED BY BIT NUMBER)
438
439 ;*****
440
441 ;OP CODE DEFINITIONS
442 NOOP=101
443 UNLOAD=103
444 SEEK=105
445 RECAL=107
446 DRVCLR=111
447 RELEASE=113
448 OFFSET=115
449 RTC=117
450 READIN=121
```

#51  
#52  
#53  
#54  
#55  
#56  
#57  
#58  
#59  
#60  
#61  
#62  
#63  
#64  
#65  
#66  
#67

000123  
000131  
000151  
000153  
000161  
000163  
000171  
000173  
000141  
000143  
000145

177400  
010000

PACK=123  
SEARCH=131  
WRCKD=151  
WRCKHD=153  
WRITE=161  
WRTHD=163  
READ=171  
READHD=173  
GETREG=141  
SETFORM=143  
SELDIV=145

; OTHER EQUATES

SCTRWC = -256.  
FMT22=10000

; WORD COUNT FOR SECTOR  
; FORMAT 22 BIT

.SBTTL COMMON TAGS

\*\*\*\*\*  
\*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS  
\*USED IN THE PROGRAM.

468  
469  
470  
471  
472  
473  
474 001100 001100  
475 001100 000000  
476 001100 000000  
477 001102 000  
478 001103 000  
479 001104 000000  
480 001106 000000  
481 001110 000000  
482 001112 000000  
483 001114 000  
484 001115 001  
485 001116 000000  
486 001120 000000  
487 001122 000000  
488 001124 000000  
489 001126 000000  
490 001130 000000  
491 001132 000000  
492 001134 000  
493 001135 000  
494 001136 000000  
495 001140 177570  
496 001142 177570  
497 001144 177560  
498 001146 177562  
499 001150 177564  
500 001152 177566  
501 001154 000  
502 001155 002  
503 001156 012  
504 001157 000  
505 001160 000000  
506  
507 001162 000000  
508 001164 000000  
509 001166 000000  
510 001170 000000  
511 001172 000000  
512 001174 000000  
513 001176 000000  
514 001200 000000  
515 001202 000000  
516 001204 000000  
517 001206 000000  
518 001210 177607 000377  
519 001214 077  
520 001215 015  
521 001216 000012  
522  
523 000015

. = 1100  
\$CMTAG: .WORD 0  
\$PASS: .WORD 0  
\$STINM: .BYTE 0  
\$ERFLG: .BYTE 0  
\$ICNT: .WORD 0  
\$LPADR: .WORD 0  
\$LPERR: .WORD 0  
\$ERTTL: .WORD 0  
\$ITEMB: .BYTE 0  
\$ERMAX: .BYTE 1  
\$ERRPC: .WORD 0  
\$GDADR: .WORD 0  
\$BODR: .WORD 0  
\$GDDAT: .WORD 0  
\$BDDAT: .WORD 0  
\$AUTOB: .BYTE 0  
\$INTAG: .BYTE 0  
\$SWR: .WORD DSWR  
\$DISPLAY: .WORD DDISP  
\$TKS: 177560  
\$TKB: 177562  
\$TPS: 177564  
\$TPB: 177566  
\$NULL: .BYTE 0  
\$FILLS: .BYTE 2  
\$FILLC: .BYTE 12  
\$TFPLG: .BYTE 0  
\$REGAD: .WORD 0  
\$REG0: .WORD 0  
\$REG1: .WORD 0  
\$REG2: .WORD 0  
\$REG3: .WORD 0  
\$REG4: .WORD 0  
\$REG5: .WORD 0  
\$TFAD: .WORD 0  
\$TFP1: .WORD 0  
\$TFP2: .WORD 0  
\$TIMES: 0  
\$ESCAPE: 0  
\$BELL: .ASCIZ <207><377><377>  
\$QUES: .ASCIZ '?'  
\$CRLF: .ASCIZ <15>  
\$LF: .ASCIZ <12>  
CR = 15

START OF COMMON TAGS  
CONTAINS PASS COUNT  
CONTAINS THE TEST NUMBER  
CONTAINS ERROR FLAG  
CONTAINS SUBTEST ITERATION COUNT  
CONTAINS SCOPE LOOP ADDRESS  
CONTAINS SCOPE RETURN FOR ERRORS  
CONTAINS TOTAL ERRORS DETECTED  
CONTAINS ITEM CONTROL BYTE  
CONTAINS MAX. ERRORS PER TEST  
CONTAINS PC OF LAST ERROR INSTRUCTION  
CONTAINS ADDRESS OF 'GOOD' DATA  
CONTAINS ADDRESS OF 'BAD' DATA  
CONTAINS 'GOOD' DATA  
CONTAINS 'BAD' DATA  
RESERVED--NOT TO BE USED  
AUTOMATIC MODE INDICATOR  
INTERRUPT MODE INDICATOR  
ADDRESS OF SWITCH REGISTER  
ADDRESS OF DISPLAY REGISTER  
TTY KBD STATUS  
TTY KBD BUFFER  
TTY PRINTER STATUS REG. ADDRESS  
TTY PRINTER BUFFER REG. ADDRESS  
CONTAINS NULL CHARACTER FOR FILLS  
CONTAINS # OF FILLER CHARACTERS REQUIRED  
INSERT FILL CHARS. AFTER A "LINE FEED"  
"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)  
CONTAINS THE ADDRESS FROM WHICH (\$REG0) WAS OBTAINED  
CONTAINS ((\$REGAD)+0)  
CONTAINS ((\$REGAD)+2)  
CONTAINS ((\$REGAD)+4)  
CONTAINS ((\$REGAD)+6)  
CONTAINS ((\$REGAD)+10)  
CONTAINS ((\$REGAD)+12)  
USER DEFINED  
USER DEFINED  
USER DEFINED  
MAX. NUMBER OF ITERATIONS  
ESCAPE ON ERROR ADDRESS  
CODE FOR BELL  
QUESTION MARK  
CARRIAGE RETURN  
LINE FEED



524		000012		LF	=	12		
525	001220	000000		C.SWR:	.WORD	0		: CONTROL SWITCHES
526	001222	000000		SAVCSW:	.WORD	0		: PREVIOUS CONTENTS OF 'C.SWR'
527	001224	000000		CNTRLC:	.WORD	0		: CONTROL "C" FLAG
528	001226	000000		BUSADR:	.WORD	0		: GET ADDRESSES FROM THE TTY FLAG (0=NO, -1=YES)
529	001230	000000		LPTAVL:	.WORD	0		: LPT AVAILABLE STATUS (0=NO, 1=YES)
530	001232	000000		DRVSEL:	.WORD	0		: DRIVES SELECTED FOR TESTING
531	001234	037777	000000	TSTNMS:	.WORD	37777,0		: RUN TESTS 0-15
532	001240	000000	000000	OPNFLG:	.WORD	0,0		: MODIFY TEST PARAMETER FLAGS
533	001244	000000		CLKSTA:	.WORD	0		: CLOCK STATUS (0=NO CLOCK, +1=KW11-P, AND -1=KW11-L)
535	001246	000020		TICKMS:	.WORD	16.		: 16 MILLISECONDS PER CLOCK TICK
536	001250	040432		TICKUS:	.WORD	16666.		: 16666 MICROSECONDS PER CLOCK TICK
537	001252	000000		BYPASS:	.WORD	0		
538	001254	000000		CHKDRV:	.WORD	0		: DRIVE UNDER TEST
539	001256	000000		DRVMSK:	.WORD	0		: DRIVE MASK BIT
540	001260	000000		SVSTAT:	.WORD	0		: STATUS/ERROR INDICATOR IS SAVED HERE ON AN ERROR
541								
542	001262	000000		CYL.RD:	.WORD	0		: CYLINDER READ
543	001264	000000		TRK.RD:	.WORD	0		: TRACK READ
544	001266	000000		SEC.RD:	.WORD	0		: SECTOR READ
545	001270	000000		CYL.DS:	.WORD	0		: CYLINDER DESIRED
546	001272	000000		SEC.DS:	.WORD	0		: SECTOR DESIRED
547	001274	000000		TRK.DS:	.WORD	0		: TRACK DESIRED
548	001276	000000		TIM.UP:	.WORD	0		: MINIMUM TIME
549	001300	000000			.WORD	0		: NUMBER OF COUNTS BELOW MIN. LIMIT
550	001302	000000			.WORD	0		: MAXIMUM TIME
551	001304	000000			.WORD	0		: NUMBER OF COUNTS ABOVE MAX. LIMIT
552	001306	000000	000000		.WORD	0,0		: TOTAL TIME OF ALL SEEKS
553	001312	000000			.WORD	0		: NUMBER OF SEEKS PERFORMED
554	001314	000000		TIM.DN:	.WORD	0		: MINIMUM TIME
555	001316	000000			.WORD	0		: NUMBER OF COUNTS BELOW MIN. LIMIT
556	001320	000000			.WORD	0		: MAXIMUM TIME
557	001322	000000			.WORD	0		: NUMBER OF COUNTS ABOVE MAX. LIMIT
558	001324	000000	000000		.WORD	0,0		: TOTAL TIME OF ALL SEEKS
559	001330	000000			.WORD	0		: NUMBER OF SEEKS PERFORMED
560	001332	000000		TIM.PT:	.WORD	0		: POINTS TO TABLE OF TIMES
561	001334	000000		WCEFLG:	.WORD	0		: FATAL WRITE CHECK ERROR FLAG (TEST 20)
562	001336	000000		STALLO:	.WORD	0		: VARIABLE STALL (TEST 4)
563	001340	000000	000000	SVADR:	.WORD	0,0		: SAVE DISK ADDRESS (TEST 22)
564	001344	000000		SEKTR:	.WORD	0		: SEEK TIMER (TEST 10)
565	001346	000000		SEKNT:	.WORD	0		: SEEK COUNTER
566	001350	000000		DELTA:	.WORD	0		: TESTING RANGE FOR SERVO SETTLE DOWN TEST
567	001352	165000		TRCKWC:	.WORD	-(256.*22.)		: WORD COUNT FOR A FULL TRACK IN 16 BIT MODE
568	001354	000012		STALL1:	.WORD	10.		: 10 MILLISECONDS STALL (TEST 0-11)
569	001356	000012		STALL2:	.WORD	10.		: 10 MILLISECONDS STALL (TEST 16-21)
570	001360	011610		STALL3:	.WORD	5000.		: 5 SEC STALL (TEST 22)
571	001362	000031		MXSTAL:	.WORD	25.		: MAX. INCREMENTING STALL ALLOWED IN TEST 4
572	001364	144		ERR.CT:	.BYTE	100.		: NUMBER OF ERRORS ALLOWED IN TESTS 16 - 21 BEFORE GOING TO THE NEXT TEST
573								: RESERVED
574	001365	000			.BYTE	0		
575								
576				: ADDRESSES AND VECTORS				
577	001366	176700		RH.ADR:	.WORD	176700		: RH11-RH70 UNIBUS ADDRESS
578	001370	000254	000240	RH.VEC:	.WORD	254,5*32.		: RH11-RH70 VECTOR ADDRESS AND PRIORITY
579	001374	000104	000106	PKV:	.WORD	104,106		: KW11-P VECTOR ADDRESS

DUL

COMMON TAGS

580 001400 172540  
 581 001402 172542  
 582 001404 172544  
 583 001406 000100  
 584 001412 177546  
 585 001414 177564  
 586 001416 177566  
 587 001420 177514  
 588 001422 177516

000102

PKCS: .WORD 172540  
 PKB: .WORD 172542  
 PKC: .WORD 172544  
 LKV: .WORD 100,102  
 LKS: .WORD 177546  
 TPS: .WORD 177564  
 TPB: .WORD 177566  
 LPS: .WORD 177514  
 LPB: .WORD 177516

:KW11-P CONTROL AND STATUS REG.  
 :KW11-P COUNT SET BUFFER  
 :KW11-P COUNTER  
 :KW11-L VECTOR ADDRESS  
 :KW11-L STATUS REGISTER  
 :TTY PRINTER STATUS  
 :TTY PRINTER BUFFER  
 :LINE PRINTER STATUS  
 :LINE PRINTER BUFFER

:BIT TABLE

591 001424 000001  
 592 001426 000002  
 593 001430 000004  
 594 001432 000010  
 595 001434 000020  
 596 001436 000040  
 597 001440 000100  
 598 001442 000200  
 599 001444 000400  
 600 001446 001000  
 601 001450 002000  
 602 001452 004000  
 603 001454 010000  
 604 001456 020000  
 605 001460 040000  
 606 001462 100000  
 607 001464 000001  
 608 001466 000002  
 609 001470 000004  
 610 001472 000010  
 611 001474 000020  
 612 001476 000040  
 613 001500 000100  
 614 001502 000200

BITS: .WORD BIT00  
 .WORD BIT01  
 .WORD BIT02  
 .WORD BIT03  
 .WORD BIT04  
 .WORD BIT05  
 .WORD BIT06  
 .WORD BIT07  
 .WORD BIT08  
 .WORD BIT09  
 .WORD BIT10  
 .WORD BIT11  
 .WORD BIT12  
 .WORD BIT13  
 .WORD BIT14  
 .WORD BIT15  
 .WORD BIT00  
 .WORD BIT01  
 .WORD BIT02  
 .WORD BIT03  
 .WORD BIT04  
 .WORD BIT05  
 .WORD BIT06  
 .WORD BIT07

:COMMON STORAGE FOR TEST PARAMETER

618 001504 000000  
 619 001506 000000  
 620 001510 000000  
 621 001512 000000  
 622 001514 000000  
 623 001516 000000  
 624 001520 000000  
 625 001522 000000  
 626 001524 000000  
 627 001526 000600  
 628 001530 000000  
 629 001532 000000  
 630 001534 000000

PRM: .WORD 0  
 RPT: .WORD 0  
 FC: .WORD 0  
 LC: .WORD 0  
 IC: .WORD 0  
 FT: .WORD 0  
 LT: .WORD 0  
 IT: .WORD 0  
 FS: .WORD 0  
 LS: .WORD 0  
 PAT: .WORD 0  
 NC1: .WORD 0  
 NC2: .WORD 0

:REPEAT COUNTS FOR ALL TESTS  
 :FIRST CYLINDER  
 :LAST CYLINDER  
 :INCREMENT CYLINDER  
 :FIRST TRACK  
 :LAST TRACK  
 :INCREMENT TRACK  
 :FIRST SECTOR  
 :LAST SECTOR  
 :PATTERN CODE  
 :NEW CYLINDER ADDRESS  
 :NEW CYLINDER ADDRESS

:TABLE OF PARAMETER POINTERS

631 001536 002330  
 632 001540 002344  
 633 001542 002372

PRMPT: .WORD PRM0  
 .WORD PRM1  
 .WORD PRM2

638 001544 002414  
639 001546 002436  
640 001550 002460  
641 001552 002502  
642 001554 002524  
643 001556 002544  
644 001560 002564  
645 001562 002606  
646 001564 002622  
647 001566 002636  
648 001570 002652  
649 001572 002666  
650 001574 002700  
651 001576 002712  
652 001600 002744  
653 001602 002760  
654 001604 000000  
655 001606 032767  
656 001610 000632  
657 001612 000632  
658 001614 001456  
659 001616 001456  
660 001620 001456  
661 001622 000022  
662 001624 000022  
663 001626 000022  
664 001630 000025  
665 001632 000025  
666 001634 177777  
667  
668  
669 001636 042750  
670 001640 042752  
671 001642 042755  
672 001644 042760  
673 001646 042764  
674 001650 042770  
675 001652 042773  
676 001654 042776  
677 001656 043001  
678 001660 043004  
679 001662 043007  
680  
681  
682  
683 001664 001125 000310 000632  
684 001672 001456 000000 000000  
685 001700 003377 000144 000000  
686 001706 000200 000000 000400  
687 001714 000000 000000 000000  
688 001722 000000 000000 000000  
689 001726 001177 000001 000000  
690 001734 000632 000000 001456  
691 001742 000001 000000 000000

.WORD PRM3  
.WORD PRM4  
.WORD PRM5  
.WORD PRM6  
.WORD PRM7  
.WORD PRM10  
.WORD PRM11  
.WORD PRM12  
.WORD PRM13  
.WORD PRM14  
.WORD PRM15  
.WORD PRM16  
.WORD PRM17  
.WORD PRM20  
.WORD PRM21  
.WORD PRM22  
.WORD 0 ; TERMINATOR

: PARAMETER UPPER LIMIT  
PRMLMT: .WORD 32767  
.WORD 410.  
.WORD 410.  
.WORD 814.  
.WORD 814.  
.WORD 814.  
.WORD 814.  
.WORD 18.  
.WORD 18.  
.WORD 18.  
.WORD 21.  
.WORD 21.  
.WORD 177777

: TABLE OF MESSAGE POINTERS  
PRMSG: .WORD MSG.R  
.WORD MSG.FC  
.WORD MSG.LC  
.WORD MSG.FCP  
.WORD MSG.LCP  
.WORD MSG.IC  
.WORD MSG.FT  
.WORD MSG.LT  
.WORD MSG.IT  
.WORD MSG.FS  
.WORD MSG.LS

: STATUS/ERROR INDICATOR MESSAGES POINTER TABLE  
: DEFAULT VALUES OF TEST PARAMETERS  
DFLT: .WORD 1125,200.,410.,814.,0,0 ; RECAL/SEEK (T0)  
.WORD 3377,100.,0,128.,0,256.,0,0,0,0,0 ; SEEK/SEEK (T1)  
.WORD 1177,1,0,410.,0,814.,1,0,0 ; INCREMENT SEEK (T2)

..R  
..FC  
..LC  
..FCP  
..LCP  
..IC  
..FT  
..LT  
..IT  
..FS  
..LS  
..PAT



692	001750	001177	000010	000000	.WORD	1177,10,0,256.,0,256.,1,0,0 ;STEPPING SEEK (T3)
693	001756	000400	000000	000400		
694	001764	000001	000000	000000		
695	001772	001177	000001	000000	.WORD	1177,1,0,410.,0,814.,1,0,0 ;OSCILLATING SEEK (T4)
696	002000	000632	000000	001456		
697	002006	000001	000000	000000		
698	002014	001177	000001	000000	.WORD	1177,1,0,410.,0,814.,1,0,0 ;CONVERGING/DIVERGING SEEK (T5)
699	002022	000632	000000	001456		
700	002030	000001	000000	000000		
701	002038	001177	000001	000000	.WORD	1177,1,0,410.,0,814.,1,0,0 ;SERVO ADDRESSING LOGIC NOISE (T6)
702	002044	000632	000000	001456		
703	002050	000001	000000	000000		
704	002058	000377	011610	000000	.WORD	337,5000.,0,410.,0,814.,0,18. ;RANDOM SEEK TEST (T7)
705	002056	000632	000000	001456		
706	002074	000000	000022	000000		
707	002108	000177	000001	000000	.WORD	177,1,0,410.,0,814.,100.,0 ;SERVO SETTLE DOWN TEST (T10)
708	002106	000632	000000	001456		
709	002114	000144	000000	000000		
710	002120	001177	000001	000000	.WORD	1177,1,0,410.,0,814.,1,0,0 ;ALL SEEKS TEST (T11)
711	002126	000632	000000	001456		
712	002134	000001	000000	000000		
713	002142	001113	000001	000000	.WORD	1113,1,0,0,0,0 ;ROTATIONAL SPEED TIMING TEST (T12)
714	002150	000000	000000	000000		
715	002158	000037	000001	000000	.WORD	37,1,0,410.,0,814. ;ONE CYLINDER SEEK TIMING TEST (T13)
716	002164	000632	000000	001456		
717	002172	000037	000001	000000	.WORD	37,1,0,136.,0,255. ;ACCESS TIME MEASUREMENT TEST (T14)
718	002200	000210	000000	000377		
719	002206	000037	000001	000000	.WORD	37,1,0,410.,0,814. ;MAXIMUM SEEK TIMING TEST (T15)
720	002214	000632	000000	001456		
721	002222	000113	000001	000000	.WORD	113,1,0,0,0 ;SECTOR ADDRESSING TEST (T16)
722	002230	000000	000000	000000		
723	002234	001013	000001	000000	.WORD	1013,1,0,0,0 ;TRACK ADDRESSING TEST (T17)
724	002242	000000	000000	000000		
725	002246	007777	000001	000000	.WORD	7777,1,0,410.,0,814.,64.,0,18.,1,1,0,177777 ;DATA TEST (T20)
726	002254	000632	000000	001456		
727	002262	000100	000000	000022		
728	002270	000001	000001	000000		
729	002276	177777				
730	002300	000037	047040	000000	.WORD	37,20000.,0,410.,0,814. ;EXERCISER (T21)
731	002306	000632	000000	001456		
732	002314	000037	011610	000000	.WORD	37,5000.,0,136.,0,255. ;RPO4 ACCESS TIME ADJUSTMENT TEST (T22)
733	002322	000210	000000	000377		

;PARAMETER TABLES

:RECR./SEEK (T0)

```
PRM0: .WORD 1125
      .WORD 200.
      .WORD 410.
      .WORD 814.
      .WORD 0
      .WORD 0
```

:SEEK/SEEK (T1)

```
PRM1: .WORD 3377
      .WORD 100.
```

734						
735						
736						
737						
738	002330	001125				
739	002332	0003.0				
740	002334	000632				
741	002336	001456				
742	002340	000000				
743	002342	000000				
744						
745						
746	002344	003377				
747	002346	000144				

748 002350 000000  
749 002352 000200  
750 002354 000000  
751 002356 000400  
752 002358 000000  
753 002362 000000  
754 002364 000000  
755 002366 000000  
756 002370 000000

.WORD 0  
.WORD 128.  
.WORD 0  
.WORD 256.  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0

. INCREMENT SEEK (T2)

759 002372 001177  
760 002374 000001  
761 002376 000000  
762 002400 000632  
763 002402 000000  
764 002404 001456  
765 002406 000001  
766 002410 000000  
767 002412 000000

PRM2: .WORD 1177  
.WORD 1  
.WORD 0  
.WORD 410.  
.WORD 0  
.WORD 814.  
.WORD 1  
.WORD 0  
.WORD 0

. STEPPING SEEK (T3)

770 002414 001177  
771 002416 000001  
772 002420 000000  
773 002424 000400  
774 002428 000000  
775 002432 001000  
776 002436 000001  
777 002440 000000  
778 002444 000000

PRM3: .WORD 1177  
.WORD 1  
.WORD 0  
.WORD 256.  
.WORD 0  
.WORD 512.  
.WORD 1  
.WORD 0  
.WORD 0

. OSCILLATING SEEK (T4)

781 002446 001177  
782 002450 000001  
783 002452 000000  
784 002454 000632  
785 002456 000000  
786 002460 001456  
787 002462 000001  
788 002464 000000  
789 002466 000000

PRM4: .WORD 1177  
.WORD 1  
.WORD 0  
.WORD 410.  
.WORD 0  
.WORD 814.  
.WORD 1  
.WORD 0  
.WORD 0

. CONVERGING/DIVERGING SEEK (T5)

791 002468 001177  
792 002470 000001  
793 002472 000000  
794 002474 000000  
795 002476 000632  
796 002480 000000  
797 002482 001456  
798 002484 000001  
799 002486 000000  
800 002500 000000

PRM5: .WORD 1177  
.WORD 1  
.WORD 0  
.WORD 410.  
.WORD 0  
.WORD 814.  
.WORD 1  
.WORD 0  
.WORD 0

. SERVO ADDRESSING LOGIC NOISE GENERATOR (T6)

803 002502 001177

PRM6: .WORD 1177

804 002504 000001  
805 002506 000000  
806 002510 000632  
807 002512 000000  
808 002514 001456  
809 002516 000001  
810 002520 000000  
811 002522 000000

.WORD 1  
.WORD 0  
.WORD 410.  
.WORD 0  
.WORD 814.  
.WORD 1  
.WORD 0  
.WORD 0

:RANDOM SEEK TEST (T7)

814 002524 000337  
815 002526 011610  
816 002530 000000  
817 002532 000632  
818 002534 000000  
819 002536 001456  
820 002540 000000  
821 002542 000022

PRM7: .WORD 337  
.WORD 5000.  
.WORD 0  
.WORD 410.  
.WORD 0  
.WORD 814.  
.WORD 0  
.WORD 18.

:SERVO SETTLE DOWN TEST (T10)

824 002544 000177  
825 002546 000001  
826 002550 000000  
827 002552 000632  
828 002554 000000  
829 002556 001456  
830 002560 000144  
831 002562 000000

PRM10: .WORD 177  
.WORD 1  
.WORD 0  
.WORD 410.  
.WORD 0  
.WORD 814.  
.WORD 100.  
.WORD 0

:ALL SEEKS TEST (T11)

834 002564 001177  
835 002566 000001  
836 002570 000000  
837 002572 000632  
838 002574 000000  
839 002576 001456  
840 002600 000001  
841 002602 000000  
842 002604 000000

PRM11: .WORD 1177  
.WORD 1  
.WORD 0  
.WORD 410.  
.WORD 0  
.WORD 814.  
.WORD 1  
.WORD 0  
.WORD 0

:ROTATIONAL SPEED TIMING TEST (T12)

845 002606 001113  
846 002610 000001  
847 002612 000000  
848 002614 000000  
849 002616 000000  
850 002620 000000

PRM12: .WORD 1113  
.WORD 1  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0

:ONE CYLINDER SEEK TIMING TEST (T13)

853 002622 000037  
854 002624 000001  
855 002626 000000  
856 002630 000632  
857 002632 000000  
858 002634 001456  
859

PRM13: .WORD 37  
.WORD 1  
.WORD 0  
.WORD 410.  
.WORD 0  
.WORD 814.

850  
851 002636 000037  
852 002640 000001  
853 002642 000000  
854 002644 000210  
855 002646 000000  
856 002650 000377  
857  
858  
859 002652 000037  
870 002654 000001  
871 002656 000000  
872 002660 000632  
873 002662 000000  
874 002664 001456  
875  
876  
877 002666 000113  
878 002670 000001  
879 002672 000000  
880 002674 000000  
881 002676 000000  
882  
883  
884 002700 001013  
885 002702 000001  
886 002704 000000  
887 002706 000000  
888 002710 000000  
889  
890  
891 002712 007777  
892 002714 000001  
893 002716 000000  
894 002720 000632  
895 002722 000000  
896 002724 001456  
897 002726 000100  
898 002730 000000  
899 002732 000000  
900 002734 000001  
901 002736 000001  
902 002740 000000  
903 002742 177777  
904  
905  
906 002744 000037  
907 002746 047040  
908 002750 000000  
909 002752 000632  
910 002754 000000  
911 002756 001456  
912  
913  
914 002760 000037  
915 002762 011610

: ACCESS TIME MEASUREMENT TEST (T14)

PRM14: .WORD 37  
.WORD 1  
.WORD 0  
.WORD 136.  
.WORD 0  
.WORD 255.

: MAXIMUM SEEK TIMING TEST (T15)

PRM15: .WORD 37  
.WORD 1  
.WORD 0  
.WORD 410.  
.WORD 0  
.WORD 814.

: SECTOR ADDRESSING TEST (T16)

PRM16: .WORD 113  
.WORD 1  
.WORD 0  
.WORD 0  
.WORD 0

: TRACK ADDRESSING TEST (T17)

PRM17: .WORD 1013  
.WORD 1  
.WORD 0  
.WORD 0  
.WORD 0

: DATA TEST (T20)

PRM20: .WORD 7777  
.WORD 1  
.WORD 0  
.WORD 410.  
.WORD 0  
.WORD 814.  
.WORD 64.  
.WORD 0  
.WORD 18.  
.WORD 1  
.WORD 1  
.WORD 0  
PTRN15: .WORD 177777

: EXERCISER (T21)

PRM21: .WORD 37  
.WORD 20000.  
.WORD 0  
.WORD 410.  
.WORD 0  
.WORD 814.

: RPO4 ACCESS TIME ADJUSTMENT TEST (T22)

PRM22: .WORD 37  
.WORD 5000.

916 002764 000000  
917 002766 000210  
918 002770 000000  
919 002772 000377

.WORD 0  
.WORD 136.  
.WORD 0  
.WORD 255.

;SEEK TIMING LIMITS

925 002774 043370  
926 002776 000000  
927 003000 003142  
928 003002 003244

T7A: .WORD MSG7  
.WORD 0  
.WORD 1634.  
.WORD 1700.

;(16.67-2%)\*#2  
;(16.67+2%)\*#2

930 003004 043370  
931 003006 000000  
932 003010 003131  
933 003012 003255

T7B: .WORD MSG7  
.WORD 0  
.WORD 1625.  
.WORD 1709.

;(16.67-2.5%)\*#2  
;(16.67+2.5%)\*#2

935 003014 043422  
936 003016 043471  
937 003020 000000  
938 003022 001750

T10: .WORD MSG10A  
.WORD MSG10B  
.WORD 0  
.WORD 1000.

;NO LOWER LIMIT  
;(7+3)\*#2

941 003024 043506  
942 003026 043554  
943 003030 000000  
944 003032 005670

T11: .WORD MSG11A  
.WORD MSG11B  
.WORD 0  
.WORD 3000.

;NO LOWER LIMIT  
;(28+2)\*#2

945 003034 043571  
946 003036 043633  
947 003040 000000  
948 003042 012120

T12: .WORD MSG12A  
.WORD MSG12B  
.WORD 0  
.WORD 5200.

;NO LOWER LIMIT  
;(50+2)\*#2

951 003044 003104  
952 003046 003144  
953 003050 003204  
954 003052 003244  
955 003054 003304  
956 003056 003344  
957 003060 003404  
958 003062 003444  
959 003064 003504  
960 003066 003544  
961 003070 003604  
962 003072 003644  
963 003074 003704  
964 003076 003744  
965 003100 004004  
966 003102 004044

PAT.PT: .WORD PAT0  
.WORD PAT1  
.WORD PAT2  
.WORD PAT3  
.WORD PAT4  
.WORD PAT5  
.WORD PAT6  
.WORD PAT7  
.WORD PAT8  
.WORD PAT9  
.WORD PAT10  
.WORD PAT11  
.WORD PAT12  
.WORD PAT13  
.WORD PAT14  
.WORD PAT15

;TABLE OF POINTERS WHICH POINT TO THE  
;PATTERNS USED BY THE DATA TEST

;PATTERNS 0 THRU 15

969 003104 165555  
970 003106 133333  
971 003110 165555

PAT0: .WORD 165555  
.WORD 133333  
.WORD 165555

;PATTERN 0



972	003112	133333	.WORD	133333
973	003114	165555	.WORD	165555
974	003116	133333	.WORD	133333
975	003120	165555	.WORD	165555
976	003122	133333	.WORD	133333
977	003124	165555	.WORD	165555
978	003126	133333	.WORD	133333
979	003130	165555	.WORD	165555
980	003132	133333	.WORD	133333
981	003134	165555	.WORD	165555
982	003136	133333	.WORD	133333
983	003140	165555	.WORD	165555
984	003142	133333	.WORD	133333
985				
986	003144	000001	PAT1: .WORD	000001 ;PATTERN 1
987	003146	000003	.WORD	000003
988	003150	000007	.WORD	000007
989	003152	000017	.WORD	000017
990	003154	000037	.WORD	000037
991	003156	000077	.WORD	000077
992	003160	000177	.WORD	000177
993	003162	000377	.WORD	000377
994	003164	000777	.WORD	000777
995	003166	001777	.WORD	001777
996	003170	003777	.WORD	003777
997	003172	007777	.WORD	007777
998	003174	017777	.WORD	017777
999	003176	037777	.WORD	037777
1000	003200	077777	.WORD	077777
1001	003202	177777	.WORD	177777
1002				
1003	003204	177776	PAT2: .WORD	177776 ;PATTERN 2
1004	003206	177774	.WORD	177774
1005	003210	177770	.WORD	177770
1006	003212	177760	.WORD	177760
1007	003214	177740	.WORD	177740
1008	003216	177700	.WORD	177700
1009	003220	177600	.WORD	177600
1010	003222	177400	.WORD	177400
1011	003224	177000	.WORD	177000
1012	003226	176000	.WORD	176000
1013	003230	174000	.WORD	174000
1014	003232	170000	.WORD	170000
1015	003234	160000	.WORD	160000
1016	003236	140000	.WORD	140000
1017	003240	100000	.WORD	100000
1018	003242	000000	.WORD	000000
1019				
1020	003244	000000	PAT3: .WORD	000000 ;PATTERN 3
1021	003246	000000	.WORD	000000
1022	003250	000000	.WORD	000000
1023	003252	177777	.WORD	177777
1024	003254	177777	.WORD	177777
1025	003256	177777	.WORD	177777
1026	003260	000000	.WORD	000000
1027	003262	000000	.WORD	000000

1028	003264	177777	.WORD	177777
1029	003266	177777	.WORD	177777
1030	003270	000000	.WORD	000000
1031	003272	177777	.WORD	177777
1032	003274	000000	.WORD	000000
1033	003276	177777	.WORD	177777
1034	003300	000000	.WORD	000000
1035	003302	177777	.WORD	177777

1036				
1037	003304	000000	PAT4: .WORD	000000 ;PATTERN 4
1038	003306	010421	.WORD	010421
1039	003310	021042	.WORD	021042
1040	003312	031463	.WORD	031463
1041	003314	042104	.WORD	042104
1042	003316	052525	.WORD	052525
1043	003320	063146	.WORD	063146
1044	003322	073567	.WORD	073567
1045	003324	104210	.WORD	104210
1046	003326	114631	.WORD	114631
1047	003330	125252	.WORD	125252
1048	003332	135673	.WORD	135673
1049	003334	146314	.WORD	146314
1050	003336	156735	.WORD	156735
1051	003340	167356	.WORD	167356
1052	003342	177777	.WORD	177777

1053				
1054	003344	052525	PAT5: .WORD	052525 ;PATTERN 5
1055	003346	052525	.WORD	052525
1056	003350	052525	.WORD	052525
1057	003352	125252	.WORD	125252
1058	003354	125252	.WORD	125252
1059	003356	125252	.WORD	125252
1060	003360	052525	.WORD	052525
1061	003362	052525	.WORD	052525
1062	003364	125252	.WORD	125252
1063	003366	125252	.WORD	125252
1064	003370	052525	.WORD	052525
1065	003372	125252	.WORD	125252
1066	003374	052525	.WORD	052525
1067	003376	125252	.WORD	125252
1068	003400	052525	.WORD	052525
1069	003402	125252	.WORD	125252

1070				
1071	003404	007417	PAT6: .WORD	007417 ;PATTERN 6
1072	003406	007417	.WORD	007417
1073	003410	007417	.WORD	007417
1074	003412	170360	.WORD	170360
1075	003414	170360	.WORD	170360
1076	003416	170360	.WORD	170360
1077	003420	007417	.WORD	007417
1078	003422	007417	.WORD	007417
1079	003424	170360	.WORD	170360
1080	003426	170360	.WORD	170360
1081	003430	007417	.WORD	007417
1082	003432	170360	.WORD	170360
1083	003434	007417	.WORD	007417

1084	003436	170360	.WORD	170360	
1085	003440	007417	.WORD	007417	
1086	003442	170360	.WORD	170360	
1087					
1088	003444	026455	PAT7: .WORD	026455	;PATTERN 7
1089	003446	026455	.WORD	026455	
1090	003450	026455	.WORD	026455	
1091	003452	151322	.WORD	151322	
1092	003454	151322	.WORD	151322	
1093	003456	151322	.WORD	151322	
1094	003460	026455	.WORD	026455	
1095	003462	026455	.WORD	026455	
1096	003464	151322	.WORD	151322	
1097	003466	151322	.WORD	151322	
1098	003470	026455	.WORD	026455	
1099	003472	151322	.WORD	151322	
1100	003474	026455	.WORD	026455	
1101	003476	151322	.WORD	151322	
1102	003500	026455	.WORD	026455	
1103	003502	151322	.WORD	151322	
1104					
1105	003504	165555	PAT8: .WORD	165555	;PATTERN 8
1106	003506	133333	.WORD	133333	
1107	003510	165555	.WORD	165555	
1108	003512	133333	.WORD	133333	
1109	003514	165555	.WORD	165555	
1110	003516	133333	.WORD	133333	
1111	003520	165555	.WORD	165555	
1112	003522	133333	.WORD	133333	
1113	003524	165555	.WORD	165555	
1114	003526	133333	.WORD	133333	
1115	003530	165555	.WORD	165555	
1116	003532	133333	.WORD	133333	
1117	003534	165555	.WORD	165555	
1118	003536	133333	.WORD	133333	
1119	003540	165555	.WORD	165555	
1120	003542	133333	.WORD	133333	
1121					
1122	003544	000001	PAT9: .WORD	000001	;PATTERN 9
1123	003546	000002	.WORD	000002	
1124	003550	000004	.WORD	000004	
1125	003552	000010	.WORD	000010	
1126	003554	000020	.WORD	000020	
1127	003556	000040	.WORD	000040	
1128	003560	000100	.WORD	000100	
1129	003562	000200	.WORD	000200	
1130	003564	000400	.WORD	000400	
1131	003566	001000	.WORD	001000	
1132	003570	002000	.WORD	002000	
1133	003572	004000	.WORD	004000	
1134	003574	010000	.WORD	010000	
1135	003576	020000	.WORD	020000	
1136	003600	040000	.WORD	040000	
1137	003602	100000	.WORD	100000	
1138					
1139	003604	177776	PAT10: .WORD	177776	;PATTERN 10

1140	003606	177775	.WORD	177775
1141	003610	177773	.WORD	177773
1142	003612	177767	.WORD	177767
1143	003614	177757	.WORD	177757
1144	003616	177737	.WORD	177737
1145	003620	177677	.WORD	177677
1146	003622	177577	.WORD	177577
1147	003624	177377	.WORD	177377
1148	003626	176777	.WORD	176777
1149	003630	175777	.WORD	175777
1150	003632	173777	.WORD	173777
1151	003634	167777	.WORD	167777
1152	003636	157777	.WORD	157777
1153	003640	137777	.WORD	137777
1154	003642	077777	.WORD	077777
1155				
1156	003644	172666	PAT11: .WORD	172666 ;PATTERN 11
1157	003646	155555	.WORD	155555
1158	003650	172666	.WORD	172666
1159	003652	155555	.WORD	155555
1160	003654	172666	.WORD	172666
1161	003656	155555	.WORD	155555
1162	003660	172666	.WORD	172666
1163	003662	155555	.WORD	155555
1164	003664	172666	.WORD	172666
1165	003666	155555	.WORD	155555
1166	003670	172666	.WORD	172666
1167	003672	155555	.WORD	155555
1168	003674	172666	.WORD	172666
1169	003676	155555	.WORD	155555
1170	003700	172666	.WORD	172666
1171	003702	155555	.WORD	155555
1172				
1173	003704	077777	PAT12: .WORD	077777 ;PATTERN 12
1174	003706	137777	.WORD	137777
1175	003710	157777	.WORD	157777
1176	003712	167777	.WORD	167777
1177	003714	173777	.WORD	173777
1178	003716	175777	.WORD	175777
1179	003720	176777	.WORD	176777
1180	003722	177377	.WORD	177377
1181	003724	177577	.WORD	177577
1182	003726	177677	.WORD	177677
1183	003730	177737	.WORD	177737
1184	003732	177757	.WORD	177757
1185	003734	177767	.WORD	177767
1186	003736	177773	.WORD	177773
1187	003740	177775	.WORD	177775
1188	003742	177776	.WORD	177776
1189				
1190	003744	153333	PAT13: .WORD	153333 ;PATTERN 13
1191	003746	066667	.WORD	066667
1192	003750	153333	.WORD	153333
1193	003752	066667	.WORD	066667
1194	003754	153333	.WORD	153333
1195	003756	066667	.WORD	066667

1196	003760	153333	.WORD	153333
1197	003762	066667	.WORD	066667
1198	003764	153333	.WORD	153333
1199	003766	066667	.WORD	066667
1200	003770	153333	.WORD	153333
1201	003772	066667	.WORD	066667
1202	003774	153333	.WORD	153333
1203	003776	066667	.WORD	066667
1204	004000	153333	.WORD	153333
1205	004002	066667	.WORD	066667

1206				
1207	004004	000000	PAT14: .WORD	000000 ;PATTERN 14
1208	004006	177777	.WORD	177777
1209	004010	177777	.WORD	177777
1210	004012	177777	.WORD	177777
1211	004014	177777	.WORD	177777
1212	004016	177777	.WORD	177777
1213	004020	177777	.WORD	177777
1214	004022	177777	.WORD	177777
1215	004024	177777	.WORD	177777
1216	004026	177777	.WORD	177777
1217	004030	177777	.WORD	177777
1218	004032	177777	.WORD	177777
1219	004034	177777	.WORD	177777
1220	004036	177 77	.WORD	177777
1221	004040	177777	.WORD	177777
1222	004042	177777	.WORD	177777

1223				
1224	004044	177777	PAT15: .WORD	177777 ;PATTERN 15
1225	004046	000000	.WORD	000000
1226	004050	000000	.WORD	000000
1227	004052	000000	.WORD	000000
1228	004054	000000	.WORD	000000
1229	004056	000000	.WORD	000000
1230	004060	000000	.WORD	000000
1231	004062	000000	.WORD	000000
1232	004064	000000	.WORD	000000
1233	004066	000000	.WORD	000000
1234	004070	000000	.WORD	000000
1235	004072	000000	.WORD	000000
1236	004074	000000	.WORD	000000
1237	004076	000000	.WORD	000000
1238	004100	000000	.WORD	000000
1239	004102	000000	.WORD	000000

1240  
1241 ;DPB (DATA PARAMETER BLOCK)

1242				
1243	004104	000	DPB.A: .BYTE	0 ; (0) DRIVE NUMBER
1244	004105	000	.BYTE	0 ; (1) OFFSET VALUE OR FMT22, ECI, AND HCI
1245	004106	000	.BYTE	0 ; (2) COMMAND
1246	004107	000	.BYTE	0 ; (3) PSEL AND A17 AND A16
1247	004110	000000	.WORD	0 ; (4) WORD COUNT (MUST BE NEG.)
1248	004112	047662	.WORD	BUFFER ; (6) BUFFER ADDRESS OR
1249				REGISTER TABLE POINTER
1250	004114	000	.BYTE	0 ; (10) SECTOR ADDRESS OR
1251				FIRST REG. INDEX



1252	004115	000	.BYTE	0	(11) TRACK ADDRESS OR LAST REG. INDEX
1253					
1254	004116	000000	.WORD	0	(12) CYLINDER ADDRESS
1255	004120	004204	.WORD	RP.REG	(14) ERROR TABLE POINTER POINTS TO THE FIRST OF TWENTY LOCATIONS OF WHERE THE DRIVER IS TO STORE THE RH11/RPO4 REGISTERS ON AN ERROR. IF LEFT ZERO REGISTERS ARE NOT SAVED.
1256					
1257					
1258					
1259					
1260					
1261	004122	000000	.WORD	0	(16) STATUS/ERROR INDICATOR BIT15=1=>ERROR OCCURRED BIT07=1=>DONE BIT14-BIT09 AND BIT06-BIT03 INDICATE TYPE OF ERROR
1262					
1263					
1264					
1265					
1266					
1267	004124	000	DPB.B: .BYTE	0	(0) DRIVE NUMBER
1268	004125	000	.BYTE	0	(1) OFFSET VALUE OR FMT22, ECI, AND HCI
1269	004126	000	.BYTE	0	(2) COMMAND
1270	004127	000	.BYTE	0	(3) PSEL AND A17 AND A16
1271	004130	177776	.WORD	-2	(4) WORD COUNT (MUST BE NEG.)
1272	004132	047662	.WORD	BUFFER	(6) BUFFER ADDRESS OR REGISTER TABLE POINTER
1273					
1274	004134	000	.BYTE	0	(10) SECTOR ADDRESS OR FIRST REG. INDEX
1275					
1276	004135	000	.BYTE	0	(11) TRACK ADDRESS OR LAST REG. INDEX
1277					
1278	004136	000000	.WORD	0	(12) CYLINDER ADDRESS
1279	004140	004204	.WORD	RP.REG	(14) ERROR TABLE POINTER POINTS TO THE FIRST OF TWENTY LOCATIONS OF WHERE THE DRIVER IS TO STORE THE RH11/RPO4 REGISTERS ON AN ERROR. IF LEFT ZERO REGISTERS ARE NOT SAVED.
1280					
1281					
1282					
1283					
1284					
1285	004142	000000	.WORD	0	(16) STATUS/ERROR INDICATOR BIT15=1=>ERROR OCCURRED BIT07=1=>DONE BIT14-BIT09 AND BIT06-BIT03 INDICATE TYPE OF ERROR
1286					
1287					
1288					
1289					
1290					
1291	004144	000	DPB.C: .BYTE	0	(0) DRIVE NUMBER
1292	004145	000	.BYTE	0	(1) OFFSET VALUE OR FMT22, ECI, AND HCI
1293	004146	000	.BYTE	0	(2) COMMAND
1294	004147	000	.BYTE	0	(3) PSEL AND A17 AND A16
1295	004150	177776	.WORD	-2	(4) WORD COUNT (MUST BE NEG.)
1296	004152	047662	.WORD	BUFFER	(6) BUFFER ADDRESS OR REGISTER TABLE POINTER
1297					
1298	004154	000	.BYTE	0	(10) SECTOR ADDRESS OR FIRST REG. INDEX
1299					
1300	004155	000	.BYTE	0	(11) TRACK ADDRESS OR LAST REG. INDEX
1301					
1302	004156	000000	.WORD	0	(12) CYLINDER ADDRESS
1303	004160	004204	.WORD	RP.REG	(14) ERROR TABLE POINTER POINTS TO THE FIRST OF TWENTY LOCATIONS OF WHERE THE DRIVER IS TO STORE THE RH11/RPO4 REGISTERS ON AN ERROR. IF LEFT
1304					
1305					
1306					
1307					

1308					:ZERO REGISTERS ARE NOT SA ED.	
1309	004162	000000	.WORD	0	:(16) STATUS/ERROR INDICATOR	
1310					:BIT15=1=>ERROR OCCURRED	
1311					:BIT07=1=>DONE	
1312					:BIT14-BIT09 AND BIT06-BIT03	
1313					:INDICATE TYPE OF ERROR	
1314						
1315	004164	000	DTROPB:	.BYTE	0	:(0) DRIVE NUMBER
1316	004165	000		.BYTE	0	:(1) OFFSET VALUE OR FMT22, ECT, AND HCI
1317	004166	000		.BYTE	0	:(2) COMMAND
1318	004167	000		.BYTE	0	:(3) PSEL AND A17 AND A16
1319	004170	000000		.WORD	0	:(4) WORD COUNT (MUST BE NEG.)
1320	004172	047662		.WORD	BUFFER	:(6) BUFFER ADDRESS OR
1321						REGISTER TABLE POINTER
1322	004174	000		.BYTE	0	:(10) SECTOR ADDRESS OR
1323						FIRST REG. INDEX
1324	004175	000		.BYTE	C	:(11) TRACK ADDRESS OR
1325						LAST REG. INDEX
1326	004176	000000		.WORD	0	:(12) CYLINDER ADDRESS
1327	004200	004204		.WORD	RP.REG	:(14) ERROR TABLE POINTER
1328						POINTS TO THE FIRST OF TWENTY
1329						LOCATIONS OF WHERE THE DRIVER
1330						IS TO STORE THE RH11/RP04
1331						REGISTERS ON AN ERROR. IF LEFT
1332						ZERO REGISTERS ARE NOT SAVED.
1333	004202	000000		.WORD	0	:(16) STATUS/ERROR INDICATOR
1334						:BIT15=1=>ERROR OCCURRED
1335						:BIT07=1=>DONE
1336						:BIT14-BIT09 AND BIT06-BIT03
1337						:INDICATE TYPE OF ERROR
1338						
1339						
1340						
1341						
1342						
1343	004204	000000		.WORD	0	:RPCS1 (776700) CONTROL & STATUS #1
1344	004206	000000		.WORD	0	:RPWC (776702) WORD COUNT
1345	004210	000000		.WORD	0	:RPBA (776704) BUS ADDRESS
1346	004212	000000		.WORD	0	:RPOA (776706) DESIRED SECTOR/TRACK
1347	004214	000000		.WORD	0	:RPCS2 (776710) CONTROL & STATUS #2
1348	004216	000000		.WORD	0	:RPCS1 (776712) DISK STATUS
1349	004220	000000		.WORD	0	:RPER1 (776714) ERROR REG. #1
1350	004222	000000		.WORD	0	:RPRS (776716) ATTENTION SUMMARY
1351	004224	000000		.WORD	0	:RPLA (776720) LOOK AHEAD
1352	004226	000000		.WORD	0	:RPOB (776722) DATA BUFFER
1353	004230	000000		.WORD	0	:RPMR (776724) MAINTAINABILITY
1354	004232	000000		.WORD	0	:RPOT (776726) DRIVE TYPE
1355	004234	000000		.WORD	0	:RPSN (776730) SERIAL NUMBER
1356	004236	000000		.WORD	0	:RPOF (776732) OFFSET
1357	004240	000000		.WORD	0	:RPCA (776734) DESIRED CYLINDER
1358	004242	000000		.WORD	0	:RPCC (776736) CURRENT CYLINDER
1359	004244	000000		.WORD	0	:RPER2 (776740) ERROR REG #2
1360	004246	000000		.WORD	0	:RPER3 (776742) ERROR REG #3
1361	004250	000000		.WORD	0	:RPEC1 (776744) ECC POSITION
1362	004252	000000		.WORD	0	:RPEC2 (776746) ECC PATTERN
1363						

;SAVE RH11/RP04 REGISTERS HERE ON ERROR

1364		
1365	004254	044672
1366	004256	044734
1367	004260	044765
1368	004262	045007
1369	004264	045035
1370	004266	045060
1371	004270	045117
1372	004272	045161
1373	004274	045225
1374	004276	045275
1375	004300	045315
1376	004302	045365
1377	004304	045435

:STATUS/ERROR MESSAGE POINTER TABLE

STATBL:	.WORD	MSG814	:OFFLINE OR UNSAFE DRIVE REQUESTED
	.WORD	MSG813	:UNLOAD DRIVE REQUESTED
	.WORD	MSG812	:PERSISTENT UNSAFE
	.WORD	MSG811	:PARITY ERROR OCCURRED
	.WORD	MSG810	:FATAL PARITY ERROR
	.WORD	MSG809	:SOFTWARE TIMEOUT ON THIS DRIVE
	.WORD	MSG808	:SOFTWARE TIMEOUT ON ANOTHER DRIVE
	.WORD	MSG806	:ERROR OCCURRED DURING I/O OPERATION
	.WORD	MSG805	:ERROR OCCURRED DURING NON-I/O OPERATION
	.WORD	MSG804	:UNSAFE OCCURRED
	.WORD	MSG803	:AUTOMATIC RECALIBRATE SEQUENCE OCCURRED
	.WORD	MSG802	:DRIVE HAS NOT RESPONDED TO PORT REQUEST
	.WORD	MSG801	:DRIVE HAS BECOME NONEXISTENT

.SBTTL ERROR POINTER TABLE

\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
\*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
\*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

::\* EM ::POINTS TO THE ERROR MESSAGE  
::\* DH ::POINTS TO THE DATA HEADER  
::\* DT ::POINTS TO THE DATA  
::\* DF ::POINTS TO THE DATA FORMAT

004306

\$ERRTB:  
\*EM AND DH ARE ASCIZ MESSAGES, DT IS A STRING OF WORDS THAT POINT TO THE  
\*DATA TO BE TYPED AND DF IS A STRING OF DATA THAT TELL HOW THE DT WORDS  
\*ARE TO BE TYPED. IF ANY OF THE POINTERS ARE NOT NEEDED FOR A PARTICULAR  
\*ERROR IT IS REPLACED WITH A ZERO.  
\*EACH OF THE ITEMS BELOW REFER TO THE ERROR NUMBER AND INDICATE  
\*THE INFORMATION THAT WILL BE TYPED WHEN THE ERROR OCCURS.  
\*UNLESS STATED OTHER ALL NUMBERS ARE OCTAL

::\* ERROR ITEM 1  
::\* RH11 INTERRUPT OCCURED (RPAS = 0)  
::\* ERR PC RPAS  
::\* \$ERRPC \$RFG3

1406 004306 044013  
1407 004310 045473  
1408 004312 047054  
1409 004314 047506

EM1  
DH1  
DT1  
DF1

::\* ERROR ITEM 2  
::\* UNEXPECTED ATTENTION OCCURRED  
::\* ERR PC DRIVE RPAS RPOS1 RPER1 RPER2 RPER3  
::\* \$ERRPC \$REG1 \$REG3 RPERRS RPERRS+2 RPERRS+4 RPERRS+6

1416 004316 044056  
1417 004320 045510  
1418 004322 047060  
1419 004324 047512

EM2  
DH2  
DT2  
DF2

::\* ERROR ITEM 3  
::\* MASSBUS PARITY ERROR (MCPE=1)  
::\* TEST ERR PC ADDRESS DATA  
::\* \$TMP0 \$ERRPC RD.ADR RD.WRD

1426 004326 044114  
1427 004330 045576  
1428 004332 047076  
1429 004334 047516

EM3  
DH3  
DT3  
DF3

::\* ERROR ITEM 4  
::\* MASSBUS PARITY ERROR (PAR=1)  
::\* TEST ERR PC ADDRESS GDATA BDDATA

1378  
1379  
1380  
1381  
1382  
1383  
1384  
1385  
1386  
1387  
1388  
1389  
1390  
1391  
1392  
1393  
1394  
1395  
1396  
1397  
1398  
1399  
1400  
1401  
1402  
1403  
1404  
1405  
1410  
1411  
1412  
1413  
1414  
1415  
1420  
1421  
1422  
1423  
1424  
1425  
1430  
1431  
1432  
1433

# E03

NO-11-DZRJA-AA RPO4/5/6 MECHANICAL AND READ/WRITE TEST MACY11 27(1006) 02-NOV-76 18:27 PAGE 31  
DZRJA.014 19-APR-76 00:00 ERROR POINTER TABLE

Line	STMPD	SERRPC	WRT.ADR	WRT.WD	RD.WRD
1452					
1453	004338	044151			
1454	004340	045633			
1455	004342	047106			
1456	004344	047522			
1457					
1458					
1459					
1460					
1461					
1462					
1463					
1464					
1465					
1466					
1467					
1468					
1469					
1470	004376	044241			
1471	004400	045702			
1472	004402	047140			
1473	004404	047526			
1474					
1475					
1476					
1477					
1478					
1479					
1480	004406	044317			
1481	004410	045721			
1482	004412	047144			
1483	004414	047532			
1484					
1485					
1486					
1487					
1488					
1489					

;\* STMPD SERRPC WRT.ADR WRT.WD RD.WRD

EM4  
DH4  
DT4  
DF4

;\* ERROR ITEM 5  
ADDRESS PLUG CHANGE BIT SET  
ERR PC DRIVE RFRS RPS1 RPER1 RPER2 RPER3  
SERRPC SREG1 SREG3 RPERRS RPERRS+2 RPERRS+4 RPERRS+6

EM5  
DH5  
DT5  
DF5

;\* ERROR ITEM 6 -- NOT USED

0  
0  
0  
0

;\* ERROR ITEM 7 -- NOT USED

0  
0  
0  
0

;\* ERROR ITEM 10  
RH11/RPO4/5/6 FAILED TO RESPOND TO ADDRESSING  
RPS1 ERR PC  
RH.ADR SERRPC

EM10  
DH10  
DT10  
DF10

;\* ERROR ITEM 11  
DRIVE SELECTED IS NOT ONLINE  
DRIVE ERR PC  
SREG2 SERRPC

EM11  
DH11  
DT11  
DF11

;\* ERROR ITEM 12  
IMPROPER HEADER DATA  
TEST ERR PC TST PC DRIVE CYLNR TRACK SECTOR  
STMPD SERRPC SREGO CHKDRV CYL.DS TRK.DS SEC.DS  
GDCYL GOTRK GDSCTR BOCYL BOTRK BDSCTR

# F03

Line No.	Code	Address	Description
1490			;* CYL.DS TRK.DS SEC.DS CYL.RD TRK.RD SEC.RD
1491			;* CYLNR, TRACK, AND SECTOR ARE DECIMAL
1492	004416	044354	EM12
1493	004420	045740	DH12
1494	004422	047150	DT12
1495	004424	047536	DF12
1498			;* ERROR ITEM 13
1499			DATA COMPARE FAILURE
1500			TEST ERR PC TST PC DRIVE CYLNR TRACK SECTOR
1501			STMPO SERRPC SREG0 CHKDRV CYL.DS TRK.DS SEC.DS
1502			GOOAT BOOAT WRDCNT GOADR BOADR
1503			SGOOAT SBOOAT SREG4 SGDAOR SBOADR
1504			;* CYLNR, TRACK, SECTOR, AND WRDCNT ARE DECIMAL
1506	004426	044401	EM13
1507	004430	045740	DH12
1508	004432	047202	DT13
1509	004434	047546	DF13
1511			;* ERROR ITEM 14 -- FOLLOWS #13
1512			SGOOAT SBOOAT SREG4 SGDAOR SBOADR
1514	004436	000000	0
1515	004440	000000	0
1516	004442	047200	DT13A
1517	004444	047556	DF14
1519			;* ERROR ITEM 15
1520			DATA COMPARE FAILURE
1521			TEST ERR PC TST PC DRIVE CYLNR TRACK SECTOR
1522			STMPO SERRPC SREG0 CHKDRV CYL.DS TRK.DS SEC.DS
1523			GOOAT BOOAT WRDCNT GOADR BOADR
1524			SGOOAT SBOOAT SREG4 SGDAOR SBOADR
1525			;* CYLNR, TRACK, SECTOR, AND WRDCNT ARE DECIMAL
1527	004446	044401	EM13
1528	004450	045740	DH12
1529	004452	047202	DT13
1530	004454	047546	DF13
1532			;* ERROR ITEM 16 -- FOLLOWS #15
1533			SGOOAT SBOOAT SREG4 SGDAOR SBOADR
1535	004456	000000	0
1536	004460	000000	0
1537	004462	047220	DT13A
1538	004464	047556	DF14
1540			;* ERROR ITEM 17
1541			DISK ERROR IN TIMING TEST
1542			TEST ERR PC DRIVE RPS1 RPS2 RPER1 RPER2 RPER3
1543			STMPO SERRPC CHKDRV RP.REG RP.REG+12 RP.REG+14 RP.REG+40 RP.REG+42
1545	004466	044426	EM17



1546	004470	046154	DM17
1547	004472	047232	DT17
1548	004474	047562	DF17
1549			
1550			*** ERROR ITEM 20
1551			*** CLOCK (KW11-P) OVERFLOW IN TIMING TEST
1552			*** TEST ERR PC DRIVE RPCS1 RPDS1 RPER1 RPER2 RPER3
1553			*** STMPO \$ERRPC CHKDRV RP.REG RP.REG+12 RP.REG+14 RP.REG+40 RP.REG+42
1554			
1555	004476	044460	EM20
1556	004500	046154	DM17
1557	004502	047232	DT17
1558	004504	047562	DF17
1559			
1560			*** ERROR ITEM 21
1561			*** DATA COMPARE FAILURE
1562			*** TEST ERR PC TST PC DRIVE CYLNDR TRACK
1563			*** STMPO \$ERRPC \$REGC CHKDRV CYL.DS TRK.DS
1564			*** GDDAT BDDAT WRDCNT SECTOR
1565			*** \$REG1 \$BDDAT \$REG4 \$REG1
1566			*** CYLINDER, TRACK, WRDCNT, AND SECTOR ARE DECIMAL
1567			
1568	004506	044401	EM13
1569	004510	046232	DM21
1570	004512	047232	DT21
1571	004514	047566	DF21
1572			
1573			*** ERROR ITEM 22--FOLLOWS #21
1574			*** \$REG1 \$BDDAT \$REG4 \$REG1
1575			
1576	004516	000000	0
1577	004520	000000	0
1578	004522	047266	DT22
1579	004524	047578	DF22
1580			
1581			*** ERROR ITEM 23
1582			*** DISK ERROR DURING SEEK
1583			*** TEST ERR PC DRIVE CYLNDR RPCS1 RPCS2 RPDS1
1584			*** STMPO \$ERRPC CHKDRV CYL.DS RP.REG RP.REG+10 RP.REG+12
1585			*** RPER1 RPER2 RPER3 RPER4 RPER5
1586			*** RP.REG+14 RP.REG+40 RP.REG+42 RP.REG+34 RP.REG+36
1587			
1588	004526	044527	EM23
1589	004530	046367	DM23
1590	004532	047276	DT23
1591	004534	047602	DF23
1592			
1593			*** ERROR ITEM 24
1594			*** SEEK NOT COMPLETE WITHIN 120 MS
1595			*** TEST ERR PC DRIVE CYLNDR RPCS1 RPCS2 RPDS1
1596			*** STMPO \$ERRPC CHKDRV CYL.DS RP.REG RP.REG+10 RP.REG+12
1597			*** RPER1 RPER2 RPER3 RPER4 RPER5
1598			*** RP.REG+14 RP.REG+40 RP.REG+42 RP.REG+34 RP.REG+36
1599			
1600	004536	044556	EM24
1601	004540	046367	DM23

1602 004542 047276  
1603 004544 047602

DT23  
DF23

1604  
1605  
1606  
1607  
1608  
1609  
1610  
1611  
1612  
1613  
1614  
1615  
1616  
1617  
1618  
1619  
1620  
1621  
1622  
1623  
1624  
1625

```
*****
*****
* ERROR ITEMS 23-40 NOT USED
* ERROR ITEMS 41-46 WILL HAVE AN EM THAT
* VARIES DEPENDING ON THE ERROR, IT WILL BE IN THE FORM:
* RH11/RPO4/S/6 ERROR (MESSAGE)
* WHERE MESSAGE WILL BE ONE OR MORE OF THE FOLLOWING:
* 1) OFFLINE OR UNSAFE DRIVE REQUESTED
* 2) UNLOADED DRIVE REQUESTED
* 3) PERSISTENT UNSAFE
* 4) PARITY ERROR OCCURRED
* 5) FATAL PARITY ERROR
* 6) SOFTWARE TIMEOUT ON THIS DRIVE
* 7) SOFTWARE TIMEOUT ON ANOTHER DRIVE
* 8) ERROR OCCURRED DURING I/O OPERATION
* 9) ERROR OCCURRED DURING NON-I/O OPERATION
* 10) UNSAFE OCCURRED
* 11) AUTOMATIC RECALIBRATE SEQUENCE OCCURRED
```

1626 004546

ITEM41:

1627  
1628  
1629  
1630  
1631  
1632

```
..* ERROR ITEM 41
..* RH11/RPO4/S/6 ERROR (MESSAGE)
..* TEST ERR PC TST PC DRIVE
..* $TMPO $ERRPC $REGO CHKDRV
```

1633 004546 044616  
1634 004550 046522  
1635 004552 047326  
1636 004554 047612

EM41  
DM41  
DT41  
DF41

1637  
1638  
1639  
1640  
1641  
1642

```
..* ERROR ITEM 42
..* RH11/RPO4/S/6 ERROR (MESSAGE)
..* TEST ERR PC TST PC DRIVE RPCS1 RPCS2 RPDS1
..* $TMPO $ERRPC $REGO CHKDRV RP.REG RP.REG+10 RP.REG+12
```

1643 004556 044616  
1644 004560 046560  
1645 004562 047336  
1646 004564 047616

EM41  
DM42  
DT42  
DF42

1647  
1648  
1649  
1650  
1651  
1652

```
..* ERROR ITEM 43
..* RH11/RPO4/S/6 ERROR (MESSAGE)
..* TEST ERR PC TST PC DRIVE RPCS1 RPCS2 RPDS1
..* $TMPO $ERRPC $REGO CHKDRV RP.REG RP.REG+10 RP.REG+12
..* RPER1 RPER2 RPER3
..* RP.REG+14 RP.REG+40 RP.REG+42
```

1653  
1654  
1655 004566 044616  
1656 004570 046560  
1657 004572 047354

EM41  
DM42  
DT43

1658 004574 047622

DF43

```

:* ERROR ITEM 44
:* RH11/RPD4/5/6 ERROR (MESSAGE)
:* TEST ERR PC TST PC DRIVE CYLNR TRACK SECTOR
:* STMPO SERRPC SREGO CHKDRV CYL.DS TRK.DS SEC.DS
:* RPCS1 RPCS2 RPS1 RPCC RPCA RPD
:* RP.REG RP.REG+10 RP.REG+12 RP.REG+34 RP.REG+34 RP.REG+06
:* RPER1 RPER2 RPER3
:* RP.REG+14 RP.REG+40 RP.REG+42
:* CYLNR, TRACK, AND SECTOR ARE DECIMAL

```

1670 004576 044616

EM41

1671 004600 045740

DH12

1672 004602 047400

DT44

1673 004604 047632

DF44

1675

```

:* ERROR ITEM 45
:* RH11/RPD4/5/6 ERROR (MESSAGE)
:* TEST ERR PC TST PC DRIVE CYLNR TRACK SECTOR
:* STMPO SERRPC SREGO CHKDRV CYL.DS TRK.DS SEC.DS
:* RPCS1 RPCS2 RPS1 RPCC RPCA RPD
:* RP.REG RP.REG+10 RP.REG+12 RP.REG+36 RP.REG+34 RP.REG+06
:* RPER1 RPER2 RPER3 RPERC RPERA RPERB
:* RP.REG+14 RP.REG+40 RP.REG+42 RP.REG+2 RP.REG+4 RP.REG+22
:* CYLNR, TRACK, AND SECTOR ARE DECIMAL

```

1685 004606 044616

EM41

1686 004610 045740

DH12

1687 004612 047440

DT45

1688 004614 047646

DF45

1690

```

:* ERROR ITEM 46
:* FATAL WRITE CHECK ERROR (MESSAGE)
:* TEST ERR PC TST PC DRIVE CYLNR TRACK SECTOR
:* STMPO SERRPC SREGO CHKDRV CYL.DS TRK.DS SEC.DS
:* RPCS1 RPCS2 RPS1 RPCC RPCA RPD
:* RP.REG RP.REG+10 RP.REG+12 RP.REG+36 RP.REG+34 RP.REG+06
:* RPER1 RPER2 RPER3 RPERC RPERA RPERB
:* RP.REG+14 RP.REG+40 RP.REG+42 RP.REG+2 RP.REG+4 RP.REG+22
:* CYLNR, TRACK, AND SECTOR ARE DECIMAL

```

1700 004616 044642

EM46

1701 004620 045740

DH12

1702 004622 047440

DT45

1703 004624 047646

DF45

1704

```

1705
1706 .SBTTL START OF PROGRAM
1707
1708
1709 004626 012737 177777 001226 START3: MOV # -1, @BUSADR ;GET BUSADR FLAG
1710 004634 000402 BR STRT1A
1711 004636 005037 001226 START1: CLR @BUSADR ;CLR BUSADR FLAG
1712 004642 005037 001224 STRT1A: CLR @CNTRLC ;NO CONTROL "C"
1713 004646 000411 BR START
1714 004650 012737 177777 001226 START4: MOV # -1, @BUSADR ;SET BUSADR FLAG
1715 004656 000402 BR STRT2A
1716 004660 005037 001226 START2: CLR @BUSADR ;CLR BUSADR FLAG
1717 004664 012737 177777 001224 STRT2A: MOV # -1, @CNTRLC ;SET CONTROL "C" FLAG
1718 004672 000005 START: RESET
1719
1720 .SBTTL INITIALIZE THE COMMON TAGS
1721 004674 012706 001100 ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
1722 004700 005026 MOV @CMTAG, R6 ;;FIRST LOCATION TO BE CLEARED
1723 004702 022706 001140 CLR (R6)+ ;;CLEAR MEMORY LOCATION
1724 004706 001374 CMP #SWR, R6 ;;DONE?
1725 004710 012706 001100 BNE -6 ;;LOOP BACK IF NO
1726 ;;INITIALIZE A FEW VECTORS
1727 004714 012737 022564 000020 MOV @SCOPE, @IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
1728 004722 012737 000340 000022 MOV #340, @IOTVEC+2 ;;LEVEL 7
1729 004730 012737 017624 000030 MOV @ERROR, @EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
1730 004736 012737 000340 000032 MOV #340, @EMTVEC+2 ;;LEVEL 7
1731 004744 012737 023104 000034 MOV @STRAP, @TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
1732 004752 012737 000340 000036 MOV #340, @TRAPVEC+2 ;;LEVEL 7
1733 004760 012737 176543 023556 MOV #176543, $HINUM ;;PRIME THE RANDOM NUMBER GENERATOR
1734 004766 012737 123456 023560 MOV #123456, $LONUM ;;BOTH HIGH AND LOW WORDS
1735 004774 005037 001204 CLR $TIMES ;;INITIALIZE NUMBER OF ITERATIONS
1736 005000 005037 001206 CLR $ESCAPE ;;CLEAR THE ESCAPE ON ERROR ADDRESS
1737 005004 112737 000001 001115 MOVB #1, $ERMAX ;;ALLOW ONE ERROR PER TEST
1738 005012 012737 005012 001106 MOV #., $LPAOR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
1739 005020 012737 005020 001110 MOV #., $LPERA ;;SETUP THE ERROR LOOP ADDRESS
1740 ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1741 ;;EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
1742 005026 013746 000004 MOV @ERRVEC, -(SP) ;;SAVE ERROR VECTOR
1743 005032 012737 005066 000004 MOV #64$, @ERRVEC ;;SET UP ERROR VECTOR
1744 005040 012737 177570 001140 MOV @OSWR, SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
1745 005046 012737 177570 001142 MOV @DISP, DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
1746 005054 022777 177777 174056 CMP # -1, @SWR ;;TRY TO REFERENCE HARDWARE SWR
1747 005062 001012 BNE 66$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
1748 ;;AND THE HARDWARE SWR IS NOT = -1
1749 BR 65$ ;;BRANCH IF NO TIMEOUT
1750 005066 012716 005074 64$: MOV #65$, (SP) ;;SET UP FOR TRAP RETURN
1751 005072 000002 RTI
1752 005074 012737 000176 001140 65$: MOV @SWREG, SWR ;;POINT TO SOFTWARE SWR
1753 005102 012737 000174 001142 MOV @DISPREG, DISPLAY
1754 005110 012637 000004 66$: MOV (SP)+, @ERRVEC ;;RESTORE ERROR VECTOR
1755
1756 005114 012700 001160 1$: MOV @SREGAD, R0 ;;FIRST ADDRESS
1757 005120 005020 CLR (R0)+ ;;CLEAR VARIABLE STORAGE
1758 005122 022700 001210 CMP # $BELL, R0 ;;DONE?
1759 005126 001374 BNE 1$ ;;NO--BRANCH
1760 005130 013737 001414 001150 MOV @STPS, @STPS ;;SETUP THE STATUS AND BUFFER REG'S
    
```

1761	005136	013737	001416	001152		MOV	2#TPB,2#STPB	FOR THE TYPE ROUTINE
1762	005144	005227	177777			INC	#-1	FIRST START ?
1763	005150	001026				BNE	3\$	BR IF NOT
1764	005152	104401	047662			TYPE	TITLE	TYPE THE PROGRAM'S TITLE
1765	005156	005737	000042			TST	42	AUTO ACCEPT OR CHAIN MODE ?
1766	005162	001006				BNE	2\$	BR IF EITHER
1767	005164	122737	000011	000041		CMPB	#11,41	LOADED FROM AN RPO4/5/6 ?
1768	005172	001002				BNE	2\$	BR IF NOT
1769	005174	104401	047762			TYPE	,LOADRV	INSTRUCT THE OPERATOR TO REMOVE THE PACK
1770								ON DRIVE 0 IF DRIVE 0 IS TO BE TESTED
1771	005200	105737	000041		2\$:	TSTB	2#41	LOADED FROM PAPER TAPE ?
1772	005204	001410				BEG	3\$	BR IF NOT
1773	005206	004737	050256			JSR	PC,\$SIZE	SIZE THE MEMORY
1774	005212	023727	050352	100000		CMP	\$LSTAD,#100000	16K OR MORE ON THE SYSTEM ?
1775	005220	103002				BHS	3\$	BR IF YES
1776	005222	104401	050160			TYPE	,NLOAD	INFORM THE OPERATOR THAT THE 'XXDP' LOADER
1777								WILL BE OVERRITTEN
1778	005226	004737	021322		3\$:	JSR	PC,\$TKINT	TURN ON THE JTY KEYBOARD INTERRUPT
1779					.S8TTL	GET	VALUE FOR SOFTWARE SWITCH REGISTER	
1780	005232	005737	000042			TST	2#42	ARE WE RUNNING UNDER XXDP/ACT?
1781	005236	001006				BNE	67\$	BRANCH IF YES
1782	005240	023727	001140	000176		CMP	SWR,#SWREG	SOFTWARE SWITCH REG SELECTED?
1783	005246	001005				BNE	68\$	BRANCH IF NO
1784	005250	104401				GTSWR		GET SOFT-SWR SETTINGS
1785	005252	000403				BR	68\$	
1786	005254	112737	000001	001134	67\$:	MOVB	#1,\$AUTOB	SET AUTO-MODE INDICATOR
1787	005262				68\$:			
1788	005262	005227	177777			INC	#-1	SEE IF FIRST START
1789	005266	001002				BNE	SRTINT	BR IF NOT
1790	005270	004737	050354			JSR	PC,GETADR	GET OR CHECK THE RHI1 ADDRESS
1791	005274	104401	001215		SRTINT:	TYPE	,SCLF	CR-LF
1792	005300	004737	024002			JSR	PC,2#LP.AVL	CHECK FOR A LINE PRINTER
1793	005304	005037	177776			CLR	2#PS	ENSURE THE PRIORITY = 0
1794	005310	012737	000001	001104		MOV	#1,\$ICNT	SET ITERATION COUNT TO 1
1795	005316	004737	031374			JSR	PC,2#GETSWR	GO CHECK FOR CONTROL SWITCHES
1796	005322	004737	024044			JSR	PC,2#ST.CLK	INITIALIZE THE CLOCK
1797	005326	004737	034502		SETVEC:	JSR	PC,RPINIT	CHECK THE DRIVE STATUS
1798	005332	012737	177777	034424		MOV	#-1,\$AVEFG	SET THE SAVE REGISTERS FLAG
1799	005340	062727	177777	000000		ADD	#-1,#0	FIRST START ?
1800	005346	103003				BCC	11\$	BR IF YES
1801	005350	005737	001224			TST	CNTRLC	CONTROL 'C' SWITCH SET ?
1802	005354	001102				BNE	SRTDRV	CONTINUE IF YES
1803	005356	012737	000340	177776	11\$:	MOV	#PR7,PS	SET PRIORITY TO 7
1804	005364	005004				CLR	R4	DRIVE TABLE POINTER
1805	005366	104401	001215			TYPE	,SCLF	CR-LF
1806	005372	104401	043050			TYPE	,SYSTAT	TYPE STATUS HEADING
1807	005376				1\$:			
1808	005376	010446				MOV	R4,-(SP)	SAVE R4 FOR TYPEOUT
1809								TYPE DRIVE NUMBER
1810	005400	104403				TYPOS		GO TYPE--OCTAL ASCII
1811	005402	002				.BYTE	2	TYPE 2 DIGIT(S)
1812	005403	000				.BYTE	0	SUPPRESS LEADING ZEROS
1813	005404	104401	044010			TYPE	,MSG.SP	SPACES
1814	005410	104401	044010			TYPE	,MSG.SP	SPACES
1815	005414	105764	034336			TSTB	0#VSTA(R4)	CHECK DRIVE'S STATUS
1816	005420	100416				BNI	4\$	BR IF UNSAFE

L03

MD-11-DZRJA-AA RPO4/5/6 MECHANICAL AND READ/WRITE TEST MACY11 27(1006) 02-NOV-76 18:27 PAGE 38  
DZRJA.014 19-APR-76 00:00 GET VALUE FOR SOFTWARE SWITCH REGISTER

1817	005422	001020			BNE	5\$		:BR IF ONLINE
1818	005424	105764	034346		TSTB	DRVYP(R4)		:SEE IF OFFLINE OR NONEXISTENT
1819	005430	001404			BEQ	2\$		:BR IF NONEXISTENT
1820	005432	100006			BPL	3\$		:BR IF OFFLINE
1821	005434	104401	043144		TYPE	NOTRP		:DRIVE NOT AN RPO4/5/6
1822	005440	000440			BR	9\$		:CHECK NEXT DRIVE
1823	005442	104401	043117	2\$:	TYPE	NOTPRS		:DRIVE NOT PRESENT
1824	005446	000435			BR	9\$		:CHECK NEXT DRIVE
1825	005450	104401	043076	3\$:	TYPE	UNTOFF		:DRIVE OFFLINE
1826	005454	000405			BR	6\$		:PRINT DRIVE TYPE
1827	005456	104401	043134	4\$:	TYPE	NOTSAF		:DRIVE UNSAFE
1828	005462	000402			BR	6\$		:PRINT DRIVE TYPE
1829	005464	104401	043107	5\$:	TYPE	UNTON		:DRIVE ONLINE
1830	005470	104401	044010	6\$:	TYPE	MSG.SP		:SPACES
1831	005474	012737	043162	005540	MOV	#RPO4,8\$		:ADDRESS OF RPO4 MESSAGE
1832	005502	132764	000001	034346	BITB	#BIT00,DRVYP(R4)		:RPO ?
1833	005510	001012			BNE	7\$		:BR IF YES
1834	005512	012737	043167	005540	MOV	#RPO5,8\$		:ADDRESS OF RPO5 MESSAGE
1835	005520	132764	000002	034346	BITB	#BIT01,DRVYP(R4)		:RPO5 ?
1836	005526	001003			BNE	7\$		:BR IF YES
1837	005530	012737	043174	005540	MOV	#RPO6,8\$		:ADDRESS OF RPO6 MESSAGE
1838	005536	104401		7\$:	TYPE			:TYPE THE DRIVE TYPE MESSAGE
1839	005540	000000		8\$:	.WORD	0		:MESSAGE ADDRESS HERE
1840	005542	104401	001215	9\$:	TYPE	SCRLF		:CR-LF
1841	005546	005204			INC	R4		:INCREMENT DRIVE NUMBER/TABLE POINTER
1842	005550	020427	000010		CMP	R4,#8.		:FINISHED ?
1843	005554	001310			BNE	1\$		:BR IF NOT
1844	005556	005037	177775		CLR	PS		:SET PRIORITY BACK TO '0'
1845	005562	005737	001224	SRTDRV:	TST	#CNTRLC		:CONTROL "C" START/RESTART?
1846	005566	001417			BEQ	1\$		:NO--BRANCH
1847	005570	013746	001222		MOV	SAVCSW,-(SP)		:GET THE PREVIOUS 'C.SWR' CONTENTS
1848	005574	063716	001220		ADD	C.SWR,(SP)		:SET UP TO SEE IF 'BIT00' IS DIFFERENT
1849	005600	032726	000001		BIT	#BIT00,(SP)+		:IS 'BIT00' DIFFERENT ?
1850	005604	001405			BEQ	9\$		:BR IF NOT
1851	005606	013737	001220	001222	MOV	C.SWR,SAVCSW		:STORE PRESENT 'C.SWR' VALUE
1852	005614	004737	024322		JSR	PC,LOOFLT		:RESET PARAMETERS TO THEIR DEFAULT ALUES
1853	005620	004737	031624	9\$:	JSR	PC,#GT.PRM		:GET PARAMETERS
1854	005624	000420			BR	4\$		
1855	005626	004737	024322	1\$:	JSR	PC,LOOFLT		:SETUP DEFAULT PARAMETERS
1856	005632	005037	001232		CLR	DRVSEL		:NO DRIVES SELECTED
1857	005636	005000			CLR	RD		:DETERMINE THE DRIVES THAT
1858	005640	012701	000001		MOV	#1,R1		:ARE AVAILABLE FOR TESTING
1859	005644	105760	034336	2\$:	TSTB	DRVSTA(R0)		
1860	005650	003403			BLE	3\$		
1861	005652	156037	034452	001232	BISB	ATABIT(R0),#DRVSEL		
1862	005660	005200		3\$:	INC	RD		
1863	005662	106301			R1	R1		
1864	005664	001367			BNE	2\$		
1865	005666	005037	034476	4\$:	CLR	#SEEKFG		:CLEAR SEEK FLAG
1866	005672	032737	000400	001220	BIT	#SW08,#C.SWR		:DO SEEK BEFORE DATA TRANSFER?
1867	005700	001002			BNE	5\$		:YES--BRANCH
1868	005702	005137	034426		C.	#SEEKFG		:NO
1869	005706	122737	000011	000041	CMQB	#11,41 ;LOADED		:FROM AN RPO4/5/6 ?
1870	005714	001003			BNE	10\$		:BR IF NOT
1871	005716	042737	000001	001232	BIC	#BIT00,DRVSEL		:CLEAR THE DRIVE 0 SELECTION BIT
1872	005724	104401	043201	10\$:	TYPE	,DRIVES		: 'DRIVES(S) TO BE TESTED'



# M03

1873	005730	005037	017540		CLR	2#SENOCT	: DETERMINE PASSES TO MAKE AND
1874	005734	005000			CLR	R0	: THE DRIVES TO BE TESTED
1875	005736	013701	001232		MOV	2#DRVSEL,R1	: ANY DRIVES SELECTED?
1876	005742	001004			BNE	6\$	: YES--BRANCH
1877	005744	104401	043232		TYPE	,NONE	: 'NONE'
1878							
1879	005750	000137	017356		JMP	2#SEOP	: GO TO END OF PROGRAM
1880	005754	006201		6\$:	ASR	R1	: REPORT THE DRIVES TO BE TESTED
1881	005756	103011			BCC	7\$	
1882	005760	005237	017540		INC	2#SENOCT	: GIVE THIS DRIVE A PASS
1883	005764	010046			MOV	R0,-(SP)	: SAVE R0 FOR TYPEOUT
1884	005766	104403			TYPOS		: GO TYPE--OCTAL ASCII
1885	005770	001			.BYTE	1	: TYPE 1 DIGIT(S)
1886	005771	000			.BYTE	0	: SUPPRESS LEADING ZEROS
1887	005772	005701			TST	R1	: MORE DRIVES?
1888	005774	001404			BEQ	8\$	: NO--BRANCH
1889	005776	104401	043237		TYPE	,COMMA	
1890	006002	005200		7\$:	INC	R0	: FORM DRIVE NUMBER
1891	006004	000763			BR	6\$	
1892	006006	013737	017540	017532	8\$:	MOV	2#SENOCT,2#SEOPCT
1893	006014	005737	001244		TST	2#CLKSTA	: KW11-P AVAILABLE
1894	006020	003006			BGT	RSTRT1	: YES--BRANCH
1895	006022	032737	036000	001234	BIT	#36000,2#TSTNMS	: NO--ANY TIMING TESTS TO BE PERFORMED?
1896	006030	001402			BEQ	RSTRT1	: NO--BRANCH
1897	006032	104401	043241		TYPE	,NOCLK	: 'NO KW11-P CLOCK TIMING TESTS WILL NOT BE PERFORMED'
1898	006036	005737	001232		RSTRT1: TST	DRVSEL	: ANY DRIVES SELECTED ?
1899	006042	001002			BNE	1\$	: BR IF YES
1900	006044	000137	004367		JMP	START2	: GET DRIVE SELECTION ENTRY
1901	006050	005037	001254		1\$:	CLR	CHKDRV
1902	006054	012737	000001	001256	MOV	#1,DRVMSK	: INIT. THE CHECK DRIVE KEY
1903	006062	033737	001256	001232	RSTRT2: BIT	DRVMSK,DRVSEL	: START TO CHECK DESIRED DRIVES
1904	006070	001010			BNE	DRVOK	: IS THIS DRIVE SELECTED?
1905	006072	012706	001100		RESTART: MOV	#STACK,SP	: YES--GO CHECK IF DRIVE IS READY FOR TESTING
1906	006076	005237	001254		INC	CHKDRV	: SETUP THE STACK POINTER
1907	006102	106337	001256		ASLB	DRVMSK	: MOVE TO NEXT DRIVE NUMBER
1908	006106	103753			BCS	RSTRT1	: POSITION THE MASK
1909	006110	000764			BR	RSTRT2	: BRANCH IF THE DRIVE NUMBER NEEDS INITIALIZED
1910							
1911	006112	013702	001254		DRVOK: MOV	CHKDRV,R2	: PICKUP THE DRIVE NUMBER
1912	006116	105762	034336		TSTB	DRVSTA(R2)	: IS DESIRED DRIVE ON-LINE?
1913	006122	103005			BGT	1\$	: YES, BRANCH
1914	006124	104011			ERROR	11	: DRIVE SELECTED IS NOT ONLINE
1915	006126	043737	001256	001232	BIC	DRVMSK,DRVSEL	: CLEAR DRIVE'S SELECTION BIT
1916	006128	000756			BR	RESTART	: RETURN
1917	006136	010237	004104		1\$:	MOV	R2,2#DPB.A
1918	006142	010237	004124		MOV	R2,2#DPB.B	: SET THE DRIVE NUMBER INTO THE DPB'S
1919	006146	010237	004144		MOV	R2,2#DPB.C	
1920	006152	010237	004164		MOV	R2,2#DTADPB	
1921	006156	004737	024736		JSR	PC,2#LDC'D	: LOAD COMMAND INTO DPB.B AND DPB.C
1922	006162	012737	017356	001252	MOV	#SEOP,2#BYPASS	: IF ERROR GO TO END OF PROGRAM
1923	006170	112737	000020	004105	MOV	#FMT22/256,D+1	: -ASSUME 16 BIT FORMAT
1924	006176	032737	000001	001220	BIT	#BIT00,C.SWR	: 16 BIT FORMAT REQUESTED ?
1925	006204	001402			BEQ	2\$	: BR IF YES
1926	006206	105037	004105		CLRB	DPB,4+1	: CLEAR THE 'FMT22' BIT
1927	006212	112737	000143	004106	2\$:	MOV	#SETFORM,DPB.A+2
1928	006220	004037	025002		JSR	R0,2#CALL.A	: SET THE FORMAT BIT PER DPB.A+1
							: GO EXECUTE THE COMMAND

# N03

MD-11-DZRJA-AA RPO4/5/6 MECHANICAL AND READ/WRITE TEST MACY11 27(1006) 02-NOV-76 18:27 PAGE 40  
 DZRJA.014 19-APR-76 00:00 GET VALUE FOR SOFTWARE SWITCH REGISTER

1929	006224	112737	000107	004106	MOVB	#RECAL, @DPB.A+2	:RECAL=COMMAND
1930	006232	004037	025002		JSR	RC, @CALL.A	:GO EXECUTE THE COMMAND
1931	006236	104401	043327		TYPE	TESTNG	: 'TESTING DRIVE'
1932	006242	010246			MOV	R2, -(SP)	:SAVE R2 FOR TYPEOUT
1933	006244	104403			TYPOS		:GO TYPE--OCTAL ASCII
1934	006246	001			.BYTE	1	:TYPE 1 DIGIT(S)
1935	006247	000			BYTE	0	:SUPPRESS LEADING ZEROS
1936	006250	104401	044010		TYPE	,MSG.SP	:TYPE SPACES
1937	006254	104401	043351		TYPE	SERIAL	: 'SERIAL NUMBER'
1938	006260	012700	000004		MOV	#4, R0	:FOUR DIGITS TO TYPE
1939	006264	013701	004234		MOV	RP, REG+30, R1	:SERIAL NUMBER
1940	006270	005002		3\$:	CLR	R2	:ZERO
1941	006272	006101			ROL	R1	:PUT THE NEXT DIGIT
1942	006274	006102			ROL	R2	:INTO R2
1943	006276	006101			ROL	R1	
1944	006300	006102			ROL	R2	
1945	006302	006101			ROL	R1	
1946	006304	006102			ROL	R2	
1947	006306	006101			ROL	R1	
1948	006310	006102			ROL	R2	
1949	006312	062702	000060		ROD	#'0, R2	:MAKE IT ASCII
1950	006316	010227			MOV	R2, (PC)+	:SAVE IT
1951	006320	000000		4\$:	.WORD	0	
1952	006322	104401	006320		TYPE	4\$	:TYPE
1953	006326	005300			DEC	R0	: 'ALL DIGITS TYPED?'
1954	006330	003357			BGT	3\$	:NO -- BRANCH
1955	006332	104401	001215		TYPE	\$CRLF	
1956	006336	113737	001364	001115	MOVB	ERR.CT, \$ERMAX	:SETUP MAX ERROR COUNT



2013  
2014  
2015  
2016  
2017  
2018  
2019  
2020  
2021  
2022  
2023  
2024  
2025  
2026  
2027  
2028  
2029  
2030  
2031  
2032  
2033  
2034  
2035  
2036  
2037  
2038  
2039  
2040  
2041  
2042  
2043  
2044  
2045  
2046  
2047  
2048  
2049  
2050  
2051  
2052  
2053  
2054  
2055  
2056  
2057  
2058  
2059  
2060  
2061  
2062  
2063  
2064  
2065  
2066  
2067  
2068

006344  
006344 000240  
006346 033737 001424 001234  
006354 001002  
006356 000137 006506  
006362 012737 000000 001102  
006370 004737 024560  
006374 012737 006470 001110  
006402 013777 001102 172532  
006410 013737 001506 001204  
006416 112737 000031 001115  
006424 112737 000107 004106  
006432 113737 001524 004134  
006440 113737 001516 004135  
006446 013737 001512 004136  
006454 012737 006504 001252  
006462 012737 006470 001106  
006470 012706 001100  
006474 004037 025002  
006500 004037 025114  
006504 000004

```

;* THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A RECALIBRATE
;* COMMAND CYCLE AND THEN SEEK FORWARD TO CYLINDER "LC" AT
;* THE COMPLETION OF BOTH COMMANDS STATUS INDICATIONS ARE
;* CHECKED TO ENSURE NO ERRORS OCCURRED.
*****
†TST0:
NOP
BIT @#BITS+(0*2),TSTNMS ;DO THIS TEST?
BNE 645 ;YES--BRANCH
JMP TST1 ;NO--GO TO THE NEXT TEST
MOV 645,@#TSTNM ;SET UP TEST NUMBER AND
;CLEAR THE ERROR FLAG (SERFLG)
JSR PC,LOOPRM ;LOAD THE PARAMETERS FOR THE TEST
MOV @#TEST0,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
MOV $TSTNM,@#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
MOV @#RPT,$TIMES ;GET THE ITERATION COUNT
MOVB @#S,SERMAX ;MAX ERRORS ALLOWED FOR TEST
;RECAL=COMMAND
MOVB @#RECAL,@#DPB.A+2
MOVB @#FS,@#DPB.B+10 ;FS
MOVB @#FT,@#DPB.B+11 ;FT
MOVB @#LC,@#DPB.B+12 ;LC
MOV @#EXIT0,@#BYPASS ;GO TO EXIT0 ON ERROR
MOV @#TEST0,@#SLPADR ;SETUP LOOP ADDRESS
TEST0: MOV @#STACK,SP ;SET UP STACK POINTER
JSR RD,@#CALL.A ;GO EXECUTE THE COMMAND
JSR RD,@#CALL.B ;GO EXECUTE THE COMMAND
EXIT0: SCOPE ;LOOP
*****
;#TEST 1 SEEK/SEEK TEST
;* THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A FORWARD SEEK
;* CYCLE TO "LC" "LT" "LS" FOLLOWED BY A REVERSE SEEK CYCLE TO
;* "FC" "FT" "FS". AT THE COMPLETION OF EACH SEEK, THE PROPER
;* INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.
;* "LC" WILL DEFAULT TO 128 AND "FC", "FT", "LT", "FS", AND "LS"
;* WILL DEFAULT TO 0
*****
†TST1:
NOP
BIT @#BITS+(1*2),TSTNMS ;DO THIS TEST?
BNE 645 ;YES--BRANCH
JMP TST2 ;NO--GO TO THE NEXT TEST
MOV 645,@#TSTNM ;SET UP TEST NUMBER AND
;CLEAR THE ERROR FLAG (SERFLG)
JSR PC,LOOPRM ;LOAD THE PARAMETERS FOR THE TEST
MOV @#TEST1,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
MOV $TSTNM,@#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
MOV @#RPT,$TIMES ;GET THE ITERATION COUNT
MOVB @#S,SERMAX ;MAX ERRORS ALLOWED FOR TEST
MOVB @#FS,@#DPB.B+10 ;FS
MOVB @#LS,@#DPB.C+10 ;LS
MOVB @#FT,@#DPB.B+11 ;FT

```

2069 006610 113737 001520 004155  
2070 006616 013737 001510 004136  
2071 006624 013737 001512 004156  
2072 006632 012737 006662 001252  
2073 006640 012737 006646 001106  
2074 006646 012706 001100  
2075 006652 004037 025304  
2076 006656 004037 025114  
2077 006662 000004

MOV B @B,T,@DPB.C+11 ;LT  
MOV @FC,@DPB.B+12 ;FC  
MOV @LC,@DPB.C+12 ;LC  
MOV @EXIT1,@BYPASS ;GO TO EXIT1 ON ERROR  
MOV @TEST1,@LPADR ;SETUP LOOP ADDRESS  
TEST1: MOV @STACK,SP ;SET THE STACK POINTER  
JSR RO,@CALL.C ;GO EXECUTE THE COMMAND  
JSR RO,@CALL.B ;GO EXECUTE THE COMMAND  
EXIT1: SCOPE ;LOOP

\*\*\*\*\*  
;TEST 2 INCREMENT/SEEK TEST  
\*\*\*\*\*

;\* THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE  
;\* CYLINDER ADDRESS FROM "FC" TO "LC" BY THE INCREMENT "IC".  
;\* WHEN THE RESULTANT CYLINDER ADDRESS (NC) EXCEEDS  
;\* "LC" REVERSE SEEK CYCLES ARE INITIATED; STARTING  
;\* AT THE LAST LEGAL "NC" AND DECREMENTING BY "IC"  
;\* UNTIL "NC" IS LESS THAN "FC". AT THE COMPLETION OF EACH  
;\* SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO  
;\* ENSURE PROPER OPERATION.

006664  
006670 000240  
006674 033737 001430 001234  
006676 001002  
006678 000137 007102  
006702 012737 000002 001102  
006710 004737 024560  
006714 012737 006774 001110  
006722 013777 001102 172212  
006730 013737 001506 001204  
006736 112737 000031 001115  
006744 012737 006752 001106  
006752 113737 001524 004134 18:  
006760 113737 001516 004135  
006766 012737 007100 001252  
006774 013737 001510 004136 TEST2:  
007002 012737 007002 001110  
007010 012706 001100  
007014  
007014 004037 025114 INCSK:  
007020 063737 001514 004136  
007026 023737 001512 004136  
007034 002367  
007036 013737 001512 004136  
007044 012737 007044 001110  
007052 012706 001100  
007056  
007056 004037 025114 DECSK:  
007062 163737 001514 004136  
007070 023737 001510 004136  
007076 003767  
007100 000004 EXIT2: SCOPE ;LOOP

\*\*\*\*\*  
;TEST2:  
NOP  
BIT @B,BITS+(2\*2),TSTNMS ;DO THIS TEST?  
BNE 648 ;YES--BRANCH  
JMP TST3 ;NO--GO TO THE NEXT TEST  
648: MOV @2,@STSTNM ;SET UP TEST NUMBER AND  
;CLEAR THE ERROR FLAG (SERFLG)  
JSR PC,LOOPRM ;LOAD THE PARAMETERS FOR THE TEST  
MOV @TEST2,@SLPERR ;SETUP THE LOOP ON ERROR ADDRESS  
MOV @STSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER  
MOV @RPT,@TIMES ;GET THE ITERATION COUNT  
MOV B @25,@SERMAX ;MAX ERRORS ALLOWED FOR TEST  
MOV @18,@LPADR ;SETUP LOOP ADDRESS  
18: MOV B @FS,@DPB.B+10 ;FS  
MOV B @FT,@DPB.B+11 ;FT  
MOV @EXIT2,@BYPASS ;GO TO EXIT2 ON ERROR  
TEST2: MOV @FC,@DPB.B+12 ;FC  
MOV @SLPERR ;SETUP THE ERROR LOOP ADDRESS  
MOV @STACK,SP ;LOAD THE STACK POINTER  
INCSK: JSR RO,@CALL.B ;GO EXECUTE THE COMMAND  
ADD @IC,@DPB.B+12 ;MOVE TO NEXT CYLINDER  
CMP @LC,@DPB.B+12 ;OUT OF CYLINDERS?  
BGE INCSK ;NO--BRANCH  
MOV @LC,@DPB.B+12  
MOV @SLPERR ;SETUP THE ERROR LOOP ADDRESS  
MOV @STACK,SP ;LOAD THE STACK POINTER  
DECSK: JSR RO,@CALL.B ;GO EXECUTE THE COMMAND  
SUB @IC,@DPB.B+12  
CMP @FC,@DPB.B+12  
BLE DECSK  
EXIT2: SCOPE ;LOOP

E04

2125  
2126  
2127  
2128  
2129  
2130  
2131  
2132  
2133  
2134  
2135  
2136  
2137  
2138  
2139  
2140  
2141  
2142  
2143  
2144  
2145  
2146  
2147  
2148  
2149  
2150  
2151  
2152  
2153  
2154  
2155  
2156  
2157  
2158  
2159  
2160  
2161  
2162  
2163  
2164  
2165  
2166  
2167  
2168  
2169  
2170  
2171  
2172  
2173  
2174  
2175  
2176  
2177  
2178  
2179  
2180

007102  
007102 000240  
007104 033737 001432 001234  
007112 001002  
007114 000137 007276  
007120 012737 000003 001102  
007126 004737 024560  
007132 012737 007212 001110  
007140 013777 001172 171774  
007146 013737 001106 001204  
007154 112737 000031 001115  
007162 012737 007170 001106  
007170 113737 001524 004134  
007176 113737 001516 004135  
007204 012737 007274 001252  
007212 013737 001510 004136  
007220 012737 007220 001110  
007226 012706 001100  
007232 004037 025114  
007236 013701 001514  
007242 012737 007242 001110  
007250 012706 001100  
007254 010137 004136  
007260 004037 025114  
007264 00101  
007266 020137 001512  
007272 003770  
007274 000004

\*\*\*\*\*  
TEST 3 STEPPING SEEK TEST

THIS TEST WILL COMMAND SEEK CYCLES TO CYLINDER 0, 1, 2, 4, 8, 16, 32, 64, 128, AND 256. AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

\*\*\*\*\*  
TEST3:

NOP  
BIT 2#BITS+(3\*2),TSTNMS ;DO THIS TEST?  
BNE 645 ;YES--BRANCH  
JMP TST4 ;NO--GO TO THE NEXT TEST  
MOV #3,2#STSTNM ;SET UP TEST NUMBER AND  
;CLEAR THE ERROR FLAG (SERFLG)  
JSR PC,LOOPRM ;LOAD THE PARAMETERS FOR THE TEST  
MOV 2#TEST3,2#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS  
MOV 2#STSTNM,2#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER  
MOV 2#RPT,2#TIMES ;GET THE ITERATION COUNT  
MOVB #25,2#SERMAX ;MAX ERRORS ALLOWED FOR TEST  
MOV #15,2#LPADR ;SETUP TEST LOOP ADDRESS  
MOVB 2#FS,2#OPB.B+10 ;FS  
MOVB 2#FT,2#OPB.B+11 ;FT  
MOV 2#EXIT3,2#BYPASS ;GO TO BYPASS ON ERROR  
TEST3: MOV 2#FC,2#OPB.B+12 ;FC  
MOV #0,2#SLPERR ;SETUP THE ERROR LOOP ADDRESS  
MOV 2#STACK,SP ;LOAD THE STACK POINTER  
JSR RO,2#CALL.B ;GO EXECUTE THE COMMAND  
MOV IC,R1 ;CYLINDER 1  
MOV #0,2#SLPERR ;SETUP THE ERROR LOOP ADDRESS  
MOV 2#STACK,SP ;LOAD THE STACK POINTER  
IS: MOV R1,2#OPB.B+12 ;DESIRED CYLINDER  
JSR RO,2#CALL.B ;GO EXECUTE THE COMMAND  
ASL R1 ;MOVE TO NEXT CYLINDER  
CMP R1,2#LC ;DONE?  
BLE IS ;NO--LOOP  
EXIT3: SCOPE

\*\*\*\*\*  
TEST 4 OSCILLATING SEEK TEST

THIS TEST WILL COMMAND SEEK CYCLES FROM "FC" TO "NC" AND BACK TO "FC". "NC" STARTS AT "FC" AND INCREMENTS BY "IC" UP TO CYLINDER "LC", THEN IS DECREMENTED BY "IC" BACK TO CYLINDER "FC". AT THE COMPLETION OF EVERY SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

\*\*\*\*\*  
TEST4:

NOP  
BIT 2#BITS+(4\*2),TSTNMS ;DO THIS TEST?  
BNE 645 ;YES--BRANCH  
JMP TST5 ;NO--GO TO THE NEXT TEST  
MOV #4,2#STSTNM ;SET UP TEST NUMBER AND

2181								JSR	PC,LODPRM	:CLEAR THE ERROR FLAG (SERFLG)
2182	007322	004737	024560					MOV	#TEST4,#\$SLPERR	:LOAD THE PARAMETERS FOR THE TEST
2183	007326	012737	007422	001110				MOV	\$STSTN,\$DISPLAY	:SETUP THE LOOP ON ERROR ADDRESS
2184	007334	013777	001102	171600				MOV	#RPT,\$TIMES	:LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2185	007342	013737	001506	001204				MOV	#25,\$ERMAX	:GET THE ITERATION COUNT
2186	007350	112737	000731	001115				MOV	#1,\$SLPADR	:MAX ERRORS ALLOWED FOR TEST
2187	007356	012737	007364	001106				MOV	#FS,#OPB.B+10	:SETUP LOOP ADDRESS
2188	007364	113737	071524	004134	1S:		MOV	#FT,#OPB.B+11	:FS	
2189	007372	113737	001516	004135			MOV	#EXIT4,#BYPASS	:FT	
2190	007400	012737	007662	001252			CLR	R2	:GO TO EXIT4 ON ERROR	
2191	007406	005002					BIT	#SW12,#C.SWR	:CLEAR STALL SWITCH (NO STALL)	
2192	007410	032737	010000	001220			BEQ	TEST4	:STALL REQUIRED?	
2193	007416	001401					COM	R2	:NO--BRANCH	
2194	007420	005102					MOV	#FC,R1	:YES--SET SWITCH	
2195	007422	013701	001510		TEST4:		CLR	#STALLO	:SET NC TO FC	
2196	007426	005037	001336				MOV	#,\$SLPERR	:START AT ZERO IF STALLS REQUIRED	
2197	007432	012737	007432	001110			MOV	#STACK,SP	:SETUP THE ERROR LOOP ADDRESS	
2198	007440	012706	001100				MOV	R1,#OPB.B+12	:LOAD THE STACK POINTER	
2199	007444	010137	004136		1S:		JSR	R0,#CALL.B	:NC	
2200	007450	004037	025114				TST	R2	:GO EXECUTE THE COMMAND	
2201	007454	005702					BEQ	#	:STALL?	
2202	007456	001403					JSR	R0,#STALL	:NO--BRANCH	
2203	007460	004037	026334				.WORD	STALLO	:YES--GO TO STALL ROUTINE	
2204	007464	001336					MOV	FC,#OPB.B+12	:TIME POINTER	
2205	007466	013737	001510	004136	2S:		JSR	R0,#CALL.B	:FC	
2206	007474	004037	025114				TST	R2	:GO EXECUTE THE COMMAND	
2207	007500	005702					BEQ	#	:STALL?	
2208	007502	001413					JSR	R0,#STALL	:NO--BRANCH	
2209	007504	004037	026334				.WORD	STALLO	:YES--GO TO STALL ROUTINE	
2210	007510	001336					INC	#STALLO	:TIME POINTER	
2211	007512	005237	001336				CMP	#MAXSTAL,#STALLO	:UPDATE THE TIME	
2212	007516	023737	001362	001336			BGT	#	:TIME TOO BIG?	
2213	007524	003347					CLR	#STALLO	:NO--BRANCH	
2214	007526	005037	001336				ADD	#IC,R1	:YES--START OVER AT ZERO	
2215	007532	063701	001514		3S:		CMP	R1,#LC	:MOVE TO NEXT CYLINDER	
2216	007536	020137	001512				BLE	#	:LAST CYLINDER COMPLETED?	
2217	007542	003740					MOV	#LC,R1	:NO--BRANCH	
2218	007544	013701	001512				MOV	#,\$SLPERR	:SET NC TO LC	
2219	007550	012737	007550	001110			MOV	#STACK,SP	:SETUP THE ERROR LOOP ADDRESS	
2220	007552	012706	001100				MOV	R1,#OPB.B+12	:LOAD THE STACK POINTER	
2221	007556	010137	004136		4S:		JSR	R0,#CALL.B	:NC	
2222	007558	004037	025114				TST	R2	:GO EXECUTE THE COMMAND	
2223	007572	005702					BEQ	#	:STALL?	
2224	007574	001403					JSR	R0,#STALL	:NO--BRANCH	
2225	007576	004037	026334				.WORD	STALLO	:YES--GO TO STALL ROUTINE	
2226	007602	001336					MOV	#LC,#OPB.B+12	:TIME POINTER	
2227	007604	013737	001512	004136	5S:		JSR	R0,#CALL.B	:LC	
2228	007612	004037	025114				TST	R2	:GO EXECUTE THE COMMAND	
2229	007616	005702					BEQ	#	:STALL?	
2230	007620	001413					JSR	R0,#STALL	:NO--BRANCH	
2231	007622	004037	026334				.WORD	STALLO	:YES--GO TO STALL ROUTINE	
2232	007626	001336					INC	#STALLO	:TIME POINTER	
2233	007630	005237	001336				CMP	#MAXSTAL,#STALLO	:UPDATE STALL TIME	
2234	007634	023737	001362	001336			BGT	#	:TIME TOO BIG?	
2235	007642	003347					CLR	#STALLO	:NO--BRANCH	
2236	007644	005037	001336						:YES--SET STALL TIME BACK TO ZERO	



2237 007650 163701 001514  
2238 007654 020137 001510  
2239 007660 002340  
2240 007662 000004

6S: SUB @#IC,R1 ;NEXT CYLINDER  
CMP R1,@#FC ;DONE?  
BGE 4S ;NO--BRANCH  
EXIT4: SCOPE ;LOOP

\*\*\*\*\*  
;#TEST 5 CONVERGING/DIVERGING SEEK TEST

;; THIS TEST WILL CAUSE THE DRIVE TO EXECUTE FORWARD AND REVERSE  
;; SEEKS FROM "NC1" AND "NC2" RESPECTIVELY, "NC1" WILL BE INCREMENTED  
;; BY "IC" AND "NC2" WILL BE DECREMENTED BY "IC" UNTIL "NC1" IS  
;; GREATER THAN THE INITIAL VALUE OF "NC2" AND "NC2" IS  
;; LESS THAN THE INITIAL VALUE OF "NC1". AT THE COMPLETION OF  
;; EACH SEEK COMP. THE PROPER INDICATORS ARE EXAMINED TO  
;; ENSURE PROPER OPERATION. "NC1" AND "NC2" DEFAULT TO  
;; "FC" AND "LC" RESPECTIVELY.

2255 007664  
2256 007664 000240  
2257 007666 033737 001436 001234  
2258 007674 001002  
2259 007676 000137 010064  
2260 007702 012737 000005 001102  
2261  
2262 007710 004737 024560  
2263 007714 012737 007774 001110  
2264 007722 013777 001102 171212  
2265 007730 013737 001506 001204  
2266 007736 112737 000031 001115  
2267 007744 012737 007752 001106  
2268 007752 113737 001524 004134 1S:  
2269 007760 113737 001516 004135  
2270 007766 012737 010062 001252  
2271 007774 013701 001510  
2272 010000 013702 001512  
2273 010004 012737 010004 001110  
2274 010012 012706 001100  
2275 010016 010137 004136 1S:  
2276 010022 004037 025114  
2277 010026 010237 004136  
2278 010032 004037 025114  
2279 010036 063701 001514  
2280 010042 163702 001514  
2281 010046 020137 001512  
2282 010052 003003  
2283 010054 020237 001510  
2284 010060 002356  
2285 010062 000004

\*\*\*\*\*  
;#TESTS:

NOP  
BIT @#BITS+(5\*2),TSTNMS ;DO THIS TEST?  
BNE 64S ;YES--BRANCH  
JMP TST6 ;NO--GO TO THE NEXT TEST  
64S: MOV #S,@#TSTN ;SET UP TEST NUMBER AND  
;CLEAR THE ERROR FLAG (SERFLG)  
JSR PC,LOOPRM ;LOAD THE PARAMETERS FOR THE TEST  
MOV @#TESTS,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS  
MOV @#TSTN,@#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER  
MOV @#APT,@#ITRES ;GET THE ITERATION COUNT  
MOVB @#S,SERMAX ;MAX ERRORS ALLOWED FOR TEST  
MOV @#S,SLPADR ;SETUP LOOP ADDRESS  
1S: MOVB @#FS,@#DPB.B+10 ;FS  
MOVB @#FT,@#DPB.B+11 ;FT  
MOV @#EXITS,@#BYPASS ;GO TO EXITS ON ERROR  
TESTS: MOV @#FC,R1 ;START NC1 AT FC  
MOV @#LC,R2 ;START NC2 AT LC  
MOV @#SLPERR ;SETUP THE ERROR LOOP ADDRESS  
MOV @#STACK,SP ;LOAD THE STACK POINTER  
1S: MOV R1,@#DPB.B+12 ;NC1  
JSR R0,@#CALL.B ;GO EXECUTE THE COMMAND  
MOV R2,@#DPB.B+12 ;NC2  
JSR R0,@#CALL.B ;GO EXECUTE THE COMMAND  
2279: ADD @#IC,R1 ;NEXT NC1  
SUB @#IC,R2 ;NEXT NC2  
CMP R1,@#LC ;DONE?  
BGT EXITS ;YES--BRANCH  
CMP R2,@#FC ;?  
BGE 1S ;NO--BRANCH  
EXITS: SCOPE ;LOOP

\*\*\*\*\*  
;#TEST 6 SERVO ADDRESSING LOGIC NOISE GENERATOR

;; IN THIS TEST A SEEK IS DONE TO CYL "NC" THEN A SEEK TO  
;; NC+4 THEN NC+1 THEN NC+3 THEN NC+2 THEN NC+5. NOW "NC" IS UPDATED  
;; BY "IC" AND THE ABOVE SEQUENCE IS REPEATED UNTIL "LC" IS

2286  
2287  
2288  
2289  
2290  
2291  
2292

H04

```

2293 ;* EXCEEDED BY ANY OF THE ABOVE VALUES. THE INITIAL VALUE OF "NC"
2294 ;* IS "FC". AT THE COMPLETION OF EACH SEEK COMMAND THE
2295 ;* PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.
2296
2297 ;*****
2298 *ST6:
2299 010064 000240 NOP
2300 010066 033737 001440 001234 BIT @#BITS+(6*2),TSTNMS ;DO THIS TEST?
2301 010074 001002 BNE 64$ ;YES--BRANCH
2302 010076 000137 010330 JMP TST7 ;NO--GO TO THE NEXT TEST
2303 010102 012737 000006 001102 64$: MOV @6,@#STSTNM ;SET UP TEST NUMBER AND
2304 ;CLEAR THE ERROR FLAG (SERFLG)
2305 010110 004737 024560 JSR PC,LOOPM ;LOAD THE PARAMETERS FOR THE TEST
2306 010114 012737 010174 001110 MOV @TEST6,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
2307 010122 013777 001102 171012 MOV $STSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2308 010130 013737 001506 001204 MOV @RPT,$TIMES ;GET THE ITERATION COUNT
2309 010136 112737 000031 001115 MOVVB @25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
2310 010144 012737 010152 001106 MOV @18,$LPAOR ;SETUP LOOP ADDRESS
2311 010152 113737 001524 004134 18: MOVVB @#FS,@#OPB.B+10 ;FS
2312 010160 113737 001516 004135 MOVVB @#FT,@#OPB.B+11 ;FT
2313 010166 012737 010326 001252 MOV @EXIT6,@#BYPASS ;GO TO EXIT6 ON ERROR
2314 010174 013701 001510 TEST6: MOV @#FC,R1 ;PICKUP "FC"
2315 010200 013702 001512 MOV @#LC,R2 ;FORM LAST CYLINDER THAT
2316 010204 162702 000005 SUB @5,R2 ;IS AVAILABLE FOR TESTING
2317 010210 012737 010210 001110 MOV @,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
2318 010216 012706 001100 MOV @STACK,SP ;LOAD THE STACK POINTER
2319 010222 020102 18: CMP R1,R2 ;LAST CYLINDER
2320 010224 003040 BGT EXIT6 ;YES--BRANCH
2321 010226 010137 004136 MOV R1,@#OPB.B+12 ;NC
2322 010232 004037 025114 JSR @#CALL.B ;GO EXECUTE THE COMMAND
2323 010236 062737 000004 004136 ADD @4,@#OPB.B+12 ;NC+4
2324 010244 004037 025114 JSR @#CALL.B ;GO EXECUTE THE COMMAND
2325 010250 162737 000003 004136 SUB @3,@#OPB.B+12 ;NC+1
2326 010256 004037 025114 JSR @#CALL.B ;GO EXECUTE THE COMMAND
2327 010262 062737 000002 004136 ADD @2,@#OPB.B+12 ;NC+3
2328 010270 004037 025114 JSR @#CALL.B ;GO EXECUTE THE COMMAND
2329 010274 162737 000001 004136 SUB @1,@#OPB.B+12 ;NC+2
2330 010302 004037 025114 JSR @#CALL.B ;GO EXECUTE THE COMMAND
2331 010306 062737 000003 004136 ADD @3,@#OPB.B+12 ;NC+5
2332 010314 004037 025114 JSR @#CALL.B ;GO EXECUTE THE COMMAND
2333 010320 063701 001514 ADD @#LC,R1
2334 010324 000736 BR 18
2335 010326 000004 EXIT6: SCOPE ;LOOP
2336
2337 ;*****
2338 ;*TEST 7 RANDOM SEEK TEST
2339
2340 ;* THIS TEST PERFORMS RANDOM SEEK OPERATIONS BETWEEN CYLINDERS 'FC'
2341 ;* 'LC'. AFTER EACH SEEK, THE POSITION OF THE DRIVE IS VERIFIED BY
2342 ;* READING A SECTOR FROM THE CURRENTLY ADDRESSED CYLINDER AND TRACK.
2343 ;* THE TRACK ADDRESS IS INCREMENTED FOR EACH SEEK SO THAT VERIFICATION
2344 ;* OF POSITIONING OCCURS USING EACH HEAD. TRACK ADDRESSES ARE INCREMENTED
2345 ;* BETWEEN PARAMETERS 'FT' AND 'LT'.
2346
2347 ;*****
2348 *ST7:

```

2349	010330	000240				NOP		
2350	010332	033737	001442	001234		BIT	2*BITS+(7*2),TSTNMS ;DO THIS TEST?	
2351	010340	001002				BNE	64\$	;YES--BRANCH
2352	010342	000137	010710			JMP	TST10	;NO--GO TO THE NEXT TEST
2353	010346	012737	000007	001102	64\$:	MOV	#7,2*STSTNM	;SET UP TEST NUMBER AND
2354								;CLEAR THE ERROR FLAG (SERFLG)
2355	010354	004737	024560			JSR	PC,LODPRM	;LOAD THE PARAMETERS FOR THE TEST
2356	010360	012737	010452	001110		MOV	#TEST7,2*SLPERR	;SETUP THE LOOP ON ERROR ADDRESS
2357	010366	013777	001102	170546		MOV	\$STSTM,2*DISPAY	;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2358	010374	013737	001506	001204		MOV	2*RPRT,\$TIMES	;GET THE ITERATION COUNT
2359	010402	112737	000031	001115		MOV	#25,\$ERMAX	;MAX ERRORS ALLOWED FOR TEST
2360	010410	113737	001516	004135		MOV	FT,DPB.B+11	;LOAD STARTING TRACK ADDRESS
2361	010416	112737	000105	004106		MOV	#SEEK,2*DPB.A+2	;SEEK-COMMAND
2362	010424	112737	000173	004126		MOV	#READHD,DPB.B+2	;READ HEADER & DATA COMMAND
2363	010432	013704	034464			MOV	RPRADR,R4	;UNIBUS ADDRESS OF THE RH11
2364	010436	012737	010706	001252		MOV	#EXIT7,BYPASS	;ERROR TERMINATION ADDRESS
2365	010444	012737	010452	001106		MOV	#TEST7,SLPADR	;SETUP THE LOOP ON TEST ADDRESS
2366	010452	012706	001100		TEST7:	MOV	#STACK,SP	;SETUP THE STACK POINTER
2367	010456	013737	001510	004136		MOV	FC,DPB.B+12	;INITIAL CYLINDER ADDRESS
2368	010464	023737	001510	001512		CMP	FC,LC	;CYLINDER LIMITS THE SAME ?
2369	010472	001422				BEQ	1\$	;BR IF THEY ARE
2370	010474	004737	023460			JSR	PC,\$RAND	;CYCLE THE RANDOM NUMBER GENERATOR
2371	010500	013746	023556			MOV	\$HNUM,-(SP)	;USE THE HIGH RANDOM NUMBER
2372	010504	005046				CLR	-(SP)	;UPPER DIVIDEND
2373	010506	013746	001512			MOV	LC,-(SP)	;FORM THE DIVISOR
2374	010512	005216				INC	(SP)	;INCREMENT
2375	010514	163716	001510			SUB	FC,(SP)	;SUBTRACT THE LOWER LIMIT
2376	010520	004737	023562			JSR	PC,\$DIV	;DIVIDE
2377	010524	062637	004136			ADD	(SP)+,DPB.B+12	;ADD THE REMAINDER TO THE INITIAL CYLINDER
2378	010530	005726				TST	(SP)+	;DISCARD THE QUOTIENT
2379	010532	013737	004136	004116		MOV	DPB.B+12,DPB.A+12	;COPY NEW CYLINDER ADDRESS
2380	010540				1\$:			
2381	010540	012737	010540	001110		MOV	#SLPERR	;SETUP THE ERROR LOOP ADDRESS
2382	010546	012706	001100			MOV	#STACK,SP	;LOAD THE STACK POINTER
2383	010552	004037	025002			JSR	RD,2*CALL.A	;GO EXECUTE THE COMMAND
2384	010556	012737	010556	001110		MOV	#SLPERR	;SETUP THE ERROR LOOP ADDRESS
2385	010564	012706	001100			MOV	#STACK,SP	;LOAD THE STACK POINTER
2386	010570	113764	004104	000010		MOV	DPB.A,RPCS2(R4)	;SELECT THE DRIVE
2387	010576	016446	000020			MOV	RPLA(R4),-(SP)	;GET THE LOOK AHEAD REGISTER
2388	010582	006316				ASL	(SP)	;ALIGN THE SECTOR ADDRESS
2389	010604	006316				ASL	(SP)	;ALIGN THE SECTOR ADDRESS
2390	010606	000316				SWAB	(SP)	;PUT ADDRESS IN LOWER BYTE
2391	010610	135766	000001			TSTB	1(SP)	;IN THE 1ST 20% OF SECTOR ?
2392	010614	001401				BEQ	2\$	;BR IF YES
2393	010616	105216				INCB	(SP)	;INCREMENT THE SECTOR ADDRESS
2394	010620	105216			2\$:	INCB	(SP)	;INCREMENT THE SECTOR ADDRESS
2395	010622	112637	004174			MOV	(SP)+,DTADPB+10	;LOAD THE DPB
2396	010626	013746	001630			MOV	PANLMT+22,-(SP)	;PUT LAST SECTOR ADDRESS ON THE STACK
2397	010632	005216				INC	(SP)	;INCREMENT IT
2398	010634	122637	004174			CMPB	(SP)+,DTADPB+10	;NEW SECTOR ADDRESS TOO LARGE ?
2399	010640	103007				BHS	4\$	;BR IF NOT
2400	010642	103403				BLO	3\$	;BR IF ADDRESS IS 2 GREATER
2401	010644	105037	004174			CLRB	DTADPB+10	;RESET TO SECTOR ADDRESS 0
2402	010650	000403				BR	4\$	;CONTINUE
2403	010652	112737	000001	004174	3\$:	MOV	#1,DTADPB+10	;RESET ADDRESS TO SECTOR 1
2404	010660				4\$:			

010660 004037 025114  
010664 105237 004135  
010670 123737 004135 001520  
010676 101403  
010700 113737 001516 004135  
010706 000004

JSR RD,@CALL.B ;GO EXECUTE THE COMMAND  
INCB DPB.B+11 ;INCREMENT THE TRACK ADDRESS  
CMPB DPB.B+11,LT ;MAXIMUM ?  
BLOS EXIT7 ;BR IF NOT  
MOVB FT,DPB.B+11 ;RELOAD STARTING TRACK ADDRESS  
EXIT7: SCOPE ;LOOP ?

\*\*\*\*\*  
;TEST 10 SERVO SETTLE DOWN TEST

THIS TEST VERIFIES THAT THE SERVO HAS SETTLED DOWN AND THAT THE DRIVE IS ON CYLINDER WHEN THE DRIVE INDICATES SEEK COMPLETE. RANDOM SEEKS ARE ISSUED BETWEEN CYLINDERS 'NC1' AND 'NC1+IC' ('NC1' STARTS AT VALUE 'FC'). AT THE COMPLETION OF 1000 (10) SEEKS, 'NC1' IS INCREMENTED BY VALUE 'IC' AND THE SEQUENCE IS REPEATED. THE TEST IS COMPLETED WHEN 'NC1' HAS BEEN INCREMENTED BEYOND 'LC'.

WHEN THE SEEK COMPLETES, THE PROGRAM READS THE DRIVE'S LOOK-AHEAD REGISTER (RPLA) TO DETERMINE THE ADDRESS OF THE SECTOR ROTATING INTO POSITION. THE PROGRAM THEN ISSUES A WRITE HEADER AND DATA COMMAND FOR THAT SECTOR. IF THE DRIVE'S POSITIONER HAS NOT SETTLED DOWN OR IF THE POSITIONER IS NOT ON CYLINDER (IF THE DRIVE IS AN RPO4, THE OFF CYLINDER CONDITION MUST LAST FOR AT LEAST 800 US), THE DRIVE WILL REPORT A 'WRU' ERROR. (RPOS/6'S MAY ALSO REPORT 'NHS' ERROR UNDER ERRORS IN THIS TEST INDICATE THAT THE SERVO SYSTEM MAY NOT BE ADJUSTED CORRECTLY, THAT THE DRIVE IS MALFUNCTIONING, OR THAT A PACK WITH MARGINAL SERVO TRACKS IS MOUNTED ON THE DRIVE.

THIS TEST USES THE EXTENTION BITS IN THE LOOK-AHEAD REGISTER TO DETERMINE WHETHER OR NOT IT CAN PICK UP THE SECTOR ROTATING INTO POSITION. THE TEST IS OPTIMIZED SUCH THAT IF THE DRIVE SIGNALS SEEK DONE WITHIN THE FIRST 80% OF THE SECTOR CURRENTLY UNDER THE HEAD, THE TEST WILL TRY TO ADDRESS THE NEXT SECTOR. BASED ON OBSERVATION, THE PROGRAM IS ABLE TO START THE OPERATION WITHOUT LOSING A REVOLUTION MOST OF THE TIME.

THIS TEST IS VALID ONLY IF THE OPERATION IS STARTED WITHIN A FEW HUNDRED MICRO-SECONDS AFTER SEEK DONE OCCURS. THE NECESSARY TIME TIME DEPENDENT PARAMETERS OCCUR FREQUENTLY ENOUGH WITHIN THE REQUIRED RANGE TO PERMIT THIS TEST TO BE EFFECTIVE.

\*\*\*\*\*  
;TST10:

010710  
010710 000240  
010712 033737 001444 001234  
010720 001002  
010722 000137 012014  
010726 012737 000010 001102  
010734 004737 024560  
010740 012737 011116 001110  
010746 013777 001102 170166  
010754 013737 001506 001204  
010762 112737 000031 001115  
010770 012737 010776 001106

NOP  
BIT @#BITS+(10\*2),TSTNMS ;DO THIS TEST?  
BNE 64\$ ;YES--BRANCH  
JMP TST11 ;NO--GO TO THE NEXT TEST  
64\$: MOV @10,@#TSTNM ;SET UP TEST NUMBER AND  
;CLEAR THE ERROR FLAG (SERFLG)  
JSR PC,LODPAM ;LOAD THE PARAMETERS FOR THE TEST  
MOV @TST10,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS  
MOV \$TSTNM,@DISP ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER  
MOV @RPT,\$TIMES ;GET THE ITERATION COUNT  
MOVB @25,\$SERMAX ;MAX ERRORS ALLOWED FOR TEST  
MOV @18,\$LPROR ;SETUP THE LOOP ADDRESS

K04

```

2561 010776 112737 000105 004106 15: MOVB #SEEK,2#DPB,A+2 ;SEEK=COMMAND
2562 010776 112737 000161 004166 MOVB #WRT,2,DTADPB+2 ;COMMAND
2563 011004 112737 001516 004175 MOVB FT,DTADPB+11 ;TRACK ADDRESS FOR THE WRITE
2564 011012 113737 001510 004116 MOV FC,DPB,A+12 ;CYLINDER ADDRESS FOR THE SEEK
2565 011020 013737 001510 004176 MOV FC,DTADPB+12 ;CYLINDER ADDRESS FOR THE WRITE
2566 011026 013737 001510 001532 MOV FC,N01 ;STARTING CYLINDER
2567 011034 013737 001514 001350 MOV IC,DELTA ;CYLINDER INCREMENT VALUE
2568 011042 012737 176000 004170 MOV #-<256.#4.>,DTADPB+4 ;WORD COUNT
2569 011050 012737 047662 004172 MOV #BUFFER,DTADPB+6 ;BUFFER ADDRESS
2570 011056 005000 CLR R0 ;PATTERN POINTER (MC PATTERN)
2571 011064 004737 030330 JSR PC,SETBUF ;LOAD THE WRITE BUFFER
2572 011072 005001 CLR R1 ;CLEAR REGISTER
2573 011074 113701 004104 MOVB DPB,A,R1 ;LOAD DRIVE ADDRESS
2574 011100 012704 024454 MOV RPAR,R4 ;UNIBUS ADDRESS OF THE RH11
2575 011104 004737 042466 JSR PC,CLIQUE ;CLEAR THE OPERATION QUEUES
2576 011110 012737 012012 001252 MOV #EXIT10,BYPASS ;ERROR EXIT FROM TEST
2577 011116 012737 011116 001110 TEST10: MOV #SLPERR ;SETUP THE ERROR LOOP ADDRESS
2578 011124 012706 001100 MOV #STACK,SP ;LOAD THE STACK POINTER
2579 011130 012737 000340 177776 MOV #PR7,2#PS ;SET PRIORITY TO 7
2580 011136 005737 001244 TST CLKSTA ;SEE WHICH CLOCK ON SYSTEM
2581 011142 001415 BEQ 35 ;BR IF NO CLOCK
2582 011144 100405 BMT 15 ;BR IF KW11-L CLOCK
2583 011146 017746 170222 MOV #PKV,-(SP) ;SAVE THE VECTOR
2584 011152 013746 001374 MOV #PKV,-(SP) ;SAVE THE VECTOR ADDRESS
2585 011156 000404 BR 25 ;CONTINUE
2586 011160 017746 170222 15: MOV #LKV,-(SP) ;SAVE THE 'L' CLOCK VECTOR
2587 011164 013746 001406 MOV #LKV,-(SP) ;SAVE THE VECTOR ADDRESS
2588 011170 017776 011746 25: MOV #TST10,2(SP) ;CHANGE THE VECTOR
2589 011176 017776 027022 35: MOV #DORT,2#PVEC ;CHANGE THE RPO4/RPOS VECTOR
2590 011204 012737 000010 001344 MOV #8,SEKTR ;LOAD THE SEEK TIMER
2591 011212 012764 000040 000010 MOV #BIT05,RPCS2(R4) ;INIT THE MASSBUS
2592 011220 110164 000010 MOVB R1,RPCS2(R4) ;RESELECT THE DRIVE
2593 011224 013764 004116 000034 MOV #DPB,A+12,RPCA(R4) ;LOAD THE CYLINDER ADDRESS
2594 011232 013737 004116 001270 MOV #DPB,A+12,CYL.DS ;CYLINDER ADDRESS FOR ERROR MESSAGE
2595 011240 013764 000105 000000 MOVB #SEEK,RPCS1(R4) ;START THE SEEK
2596 011246 005037 177776 CLR 2#PS ;CLEAR THE PRIORITY
2597 011252 105764 000012 45: TSTB RPO51(R4) ;HAS THE DRIVE FINISHED ?
2598 011256 100402 BMT 55 ;BR IF IT HAS
2599 011260 000001 WAIT ;WAIT FOR THE OPERATION TO COMPLETE
2600 011262 000773 PR 45 ;CONTINUE
2601 011264 012737 000340 177776 55: MOV #PR7,2#PS ;CHANGE PRIORITY TO MAX
2602 011272 032764 040000 000012 BIT #BIT14,RPO51(R4) ;ERROR ?
2603 011300 001412 BEQ 65 ;BR IF NOT
2604 011302 012702 004104 MOV #CPB,A,R2 ;DPB POINTER
2605 011306 004737 042004 JSR PC,SVRH11 ;SAVE THE REGISTERS
2606 011312 104023 ERROR 23 ;ERROR DURING SEEK
2607 011314 012764 000040 000010 MOV #BIT05,RPCS2(R4) ;INIT THE MASSBUS
2608 011322 110164 000010 MOVB R1,RPCS2(R4) ;RESELECT THE DRIVE
2609 011326 012777 037346 023132 65: MOV #ISR,2#PVEC ;SETUP THE RPO4/RPOS VECTOR
2610 011334 005737 001244 TST CLKSTA ;WHICH CLOCK
2611 011340 001405 BEQ TST10A ;BR IF NONE
2612 011342 015676 000002 000000 MOV 2(SP),2(SP) ;RELOAD THE CLOCK VECTOR
2613 011344 062706 000004 000000 ADD #4,SP ;CORRECT THE STACK POINTER
2614 011354

```

2517	011354	012737	011354	001110	MOV	#SLPERR	SETUP THE ERROR LOOP ADDRESS
2518	011362	012706	001100		MOV	#STACK,SP	LOAD THE STACK POINTER
2519	011366	110164	000010		MOVB	R1,RPCS2(R4)	SELECT THE DRIVE
2520	011372	016446	000020		MOV	RP(A(R4),-(SP)	GET THE LOOK AHEAD REGISTER
2521	011376	006316			ASL	(SP)	ALIGN THE SECTOR ADDRESS
2522	011400	006316			ASL	(SP)	ALIGN THE SECTOR ADDRESS
2523	011402	000316			SWAB	(SP)	PUT ADDRESS IN LOWER BYTE
2524	011404	122766	000300	000001	CMPB	#300,1(SP)	IN THE LAST 20% OF SECTOR ?
2525	011412	001001			ENE	2\$	BR IF NOT
2526	011414	105216			INCB	(SP)	INCREMENT THE SECTOR ADDRESS
2527	011416	105216			INCB	(SP)	INCREMENT THE SECTOR ADDRESS
2528	011420	112637	004174		MOVB	(SP)+,DTADPB+10	LOAD THE DPB
2529	011424	013746	001630		MOV	PRMLMT+22,-(SP)	PUT MAXIMUM SECTOR ADDRESS ON THE STACK
2530	011430	005216			INC	(SP)	INCREMENT PAST THE MAXIMUM ADDRESS
2531	011432	122637	004174		CMPB	(SP)+,DTADPB+10	NEW SECTOR ADDRESS TOO LARGE ?
2532	011436	101007			BHI	4\$	BR IF NOT
2533	011440	103403			BLO	3\$	BR IF ADDRESS IS 2 GREATER THAN MAXIMUM
2534	011442	105037	004174		CLRB	DTADPB+10	RESET TO SECTOR ADDRESS 0
2535	011446	000403			BR	4\$	CONTINUE
2536	011450	112737	000001	004174	MOVB	#1,DTADPB+10	RESET ADDRESS TO SECTOR 1
2537	011456	012703	004170		MOV	#DTADPB+4,R3	POINTER
2538	011462	012764	000111	000000	MOV	#DRVCLR,RPCS1(R4)	CLEAR THE DRIVE
2539	011470	012364	000002		MOV	(R3)+,RPWC(R4)	LOAD THE WORD COUNT
2540	011474	012364	000004		MOV	(R3)+,RPBA(R4)	LOAD THE BUFFER ADDRESS
2541	011500	012364	000006		MOV	(R3)+,RPDA(R4)	LOAD THE TRACK/SECTOR ADDR
2542	011504	005037	004202		CLR	DTADPB+16	RESET 'DONE' INDICATOR
2543	011510	012737	004164	034376	MOV	#DTADPB,TRANSW	LOAD 'TRANSFER' DPB ADDRESS
2544	011516	010137	034450		MOV	R1,DTUM	ADDRESS OF DRIVE TRANSFERRING
2545	011522	112761	000001	034326	MOVB	#1,DRVACT(R1)	SET DRIVE ACTIVE INDICATOR
2546	011530	006301			ASL	R1	SHIFT DRIVE ADDRESS
2547	011532	012761	001750	034430	MOV	#1000.,TIMER(R1)	SETUP THE OPERATION TIMER
2548	011540	006201			ASR	R1	RESTORE R1
2549	011542	013764	004166	000000	MOV	DTADPB+2,RPCS1(R4)	START THE OPERATION
2550	011550	005037	177776		CLR	#PS	CLEAR THE PRIORITY
2551	011554	004037	025514		JSR	RD,DRVCL1	WAIT FOR OPERATION TO COMPLETE
2552	011560	023727	001346	031750	CMP	SEKCNT,#1000.	FINISHED SEEKS ?
2553	011566	001026			BNE	6\$	BR IF NOT
2554	011570	005037	001346		CLR	SEKCNT	CLEAR THE SEEK COUNT
2555	011574	063737	001514	001532	ADD	IC,NC1	ADD THE INCREMENT
2556	011602	023737	001532	001512	CMP	NC1,LC	EXCEEDED THE CYLINDER LIMIT ?
2557	011610	103100			BHIS	EXIT10	BR IF IT WAS
2558	011612	013737	001512	001350	MOV	LC,DELTA	GET THE NEXT 'ZONE' ADDRESS
2559	011620	163737	001532	001350	SUB	NC1,DELTA	CHECK THE DIFFERENCE
2560	011626	023737	001514	001350	CMP	IC,DELTA	DIFFERENCE GREATER THAN THE INCREMENT ?
2561	011634	101003			BHI	6\$	BR IF IT IS
2562	011636	013737	001514	001750	MOV	IC,DELTA	USE THE INCREMENT PARAMETER
2563	011644	005237	001346		INC	SEKCNT	COUNT THE NEXT SEEK
2564	011650	023737	001510	001512	CMP	FC,LC	BEGINNING AND ENDING CYLINDERS THE SAME ?
2565	011656	001002			BNE	7\$	BR IF NOT
2566	011660	000137	011116		JMP	TEST10	BR IF THEY ARE
2567	011664	013737	001532	004116	MOV	NC1,DPB.A+12	RESET THE CYLINDER ADDRESS
2568	011672	004737	023460		JSR	PC,\$RAND	CYCLE THE RANDOM NUMBER GENERATOR
2569	011676	013746	023556		MOV	#HNUM,-(SP)	USE THE HIGH RANDOM NUMBER
2570	011702	005046			CLR	-(SP)	CLEAR THE UPPER DIVIDEND
2571	011704	013746	001350		MOV	DELTA,-(SP)	FORM THE DIVISOR
2572	011710	005216			INC	(SP)	INCREMENT



MO4

```

2573 011712 004737 023562 JSR PC,SDIV ;DIVIDE
2574 011716 062637 004116 ADD (SP)+,DPB.A+12 ;ADD THE REMAINDER TO THE INITIAL CYLINDER
2575 011722 005726 TST (SP)+ ;DISCARD THE QUOTIENT
2576 011724 023737 004116 004176 CMP DPB.A+12,DTADPB+12 ;SAME CYLINDER SELECTED AS LAST TIME ?
2577 011732 001754 BEQ 7$ ;BR IF IT WAS
2578 011734 013737 004116 004176 MOV DPB.A+12,DTADPB+12 ;COPY NEW CYLINDER ADDRESS
2579 011742 000137 011116 JMP TEST10 ;CONTINUE
2580 011746 005337 001344 TST10B: DEC SEKTR ;DECREMENT THE SEEK TIMER
2581 011752 001016 BNE 1$ ;CONTINUE IF NOT DONE
2582 011754 012702 004104 MOV #DPB.A,R2 ;DPB ADDRESS
2583 011760 004737 042004 JSR PC,SVR11 ;SAVE THE REGISTERS
2584 011764 104024 ERROR 24 ;TIMEOUT DURING SEEK
2585 011766 012764 000040 000010 MOV #BITS,RPCS2(R4) ;INIT THE MASSBUS
2586 011774 110164 000010 MOV R1,RPCS2(R4) ;RESELECT THE DRIVE
2587 012000 016676 000002 000000 MOV 2(SP),2(SP) ;RESTORE THE CLOCK VECTOR ADDRESS
2588 012006 000401 BR ;ABORT THE TEST
2589 012010 000002 1$: RTI ;RETURN
2590 012012 000004 EXIT10: SCOPE ;LOOP ?

```

\*\*\*\*\*  
;TEST 11 ALL SEEKS TEST

;\* THIS TEST VERIFIES THAT THE DISK DRIVE CAN SEEK FROM EACH CYLINDER TO ALL OTHER CYLINDERS.

;\* BEGINNING WITH CYLINDER 'FC', THE TEST SEEKS TO EACH CYLINDER BETWEEN 'FC' AND 'LC' FROM CYLINDER 'FC'. THE BEGINNING CYLINDER ADDRESS IS INCREMENTED AND THE TEST SEEKS BETWEEN THE NEW CYLINDER ADDRESS AND ALL CYLINDERS BETWEEN 'FC' AND 'LC'. THE SEQUENCE CONTINUES UNTIL ALL CYLINDERS HAVE BEEN CHECKED.

\*\*\*\*\*  
;TEST11:

```

2605 012014 000240 NOP
2606 012014 033737 001446 001234 BIT #BITS+(11*2),TSTNMS ;DO THIS TEST?
2607 012016 001002 BNE 64$ ;YES--BRANCH
2608 012024 000137 012234 JMP TST12 ;NO--GO TO THE NEXT TEST
2609 012026 012737 000011 001102 64$: MOV #11,#TSTN ;SET 11TH TEST NUMBER AND
2610 012032 004737 024560 JSR PC,LOOPRM ;CLEAR THE ERROR FLAG (SERFLG)
2611 012040 012737 001110 MOV #TST11,#SLPERR ;LOAD THE PARAMETERS FOR THE TEST
2612 012044 013777 001102 167062 MOV $TSTN,#DISPLAY ;SETUP THE LOOP ON ERROR ADDRESS
2613 012052 013737 001506 001204 MOV #RPT,$TIMES ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2614 012060 112737 000031 001115 MOV #25,$ERMAX ;GET THE ITERATION COUNT
2615 012066 012737 012102 001106 MOV #1$,$LPADR ;MAX ERRORS ALLOWED FOR TEST
2616 012074 113737 001524 004134 1$: MOVB FS,DPB.B+10 ;SETUP THE LOOP ADDRESS
2617 012102 113737 001524 004154 MOVB FS,DPB.C+10 ;SECTOR ADDRESS
2618 012110 113737 001516 004135 MOVB FT,DPB.B+11 ;SECTOR ADDRESS
2619 012116 113737 001516 004155 MOVB FT,DPB.C+11 ;TRACK ADDRESS
2620 012124 013737 001510 004136 MOV FC,DPB.B+12 ;STARTING CYLINDER ADDRESS
2621 012132 013737 001510 004156 MOV FC,DPB.C+12 ;STARTING CYLINDER ADDRESS
2622 012140 012737 012232 001252 MOV #EXIT11,BYPASS ;TEST ABORT EXIT
2623 012146 012706 001100 TEST11: MOV #STACK,$P ;SETUP THE STACK POINTER
2624 012154 004037 025304 1$: JSR RO,#CALL.C ;GO EXECUTE THE COMMAND
2625 012160 004037 025114 JSR RO,#CALL.B ;GO EXECUTE THE COMMAND

```



N04

2629	012170	063737	001514	004156	ADD	IC,DPE C+12	; INCREMENT THE ENDING CYLINDER ADDRESS
2630	012176	023737	001512	004156	CMP	LC,DPB.C+12	; CHECK IF EXCEEDING MAXIMUM
2631	012204	002365			BGE	IS	; BR IF NOT
2632	012206	013737	001510	004156	MOV	FC,DPB.C+12	; RESET ENDING CYLINDER ADDRESS
2633	012214	063737	001514	004136	ADD	IC,DPB.B+12	; INCREMENT THE STARTING ADDRESS
2634	012222	023737	001512	004136	CMP	LC,DPB.B+12	; EXCEEDING MAXIMUM ?
2635	012230	002353			BGE	IS	; BR IF NOT
2636	012232	000004			EXIT11:	SCOPE	; LOOP ?
2637							

2638  
2639  
2640

.SBTTL \*\*\* TIMING TESTS \*\*\*

```

:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:#
:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:#
:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:#

```

```

*THE TIMING TESTS WILL ENSURE THAT THOSE FUNCTIONS BEING
*TIMED ARE WITHIN THE TOLERANCES SPECIFIED IN THE "RPO4
*ENGINEERING SPECIFICATIONS".
*THE "SEE" TIMING WILL BE PERFORMED USING EXPLICIT SEEK
*OPERATIONS. AT THE COMPLETION OF EACH OF THE TIMING
*TESTS THE MINIMUM, MAXIMUM AND AVERAGE TIMES WILL BE
*TYPED.

```

```

:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:#
:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:#
:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:/#/:#

```

2658  
2659  
2660  
2661  
2662  
2663  
2664  
2665  
2666  
2667  
2668  
2669  
2670  
2671  
2672  
2673  
2674  
2675  
2676  
2677  
2678  
2679  
2680  
2681  
2682  
2683  
2684  
2685  
2686  
2687  
2688  
2689  
2690  
2691  
2692  
2693

```

*****
;TEST 12          ROTATIONAL SPEED TIMING TEST

```

```

;*      THIS TEST WILL START A SEARCH TO CYLINDER 0, TRACK 0, SECTOR
;*      0. AS SOON AS THE INTERRUPT OCCURS, THE GO BIT IS SET AGAIN
;*      AND THE OPERATION IS TIMED. THIS PROCEDURE IS REPEATED 10
;*      TIMES THEN THE AVERAGE TIME IS CALCULATED AND CHECKED TO
;*      ENSURE IT IS WITHIN TOLERANCE:
;*              16.67 MS/REV + OR - 2% IF 60HZ
;*              16.67 MS/REV + OR - 2.5% IF 50HZ.

```

```

*****
TST12:

```

```

NOP
BIT      2#BITS+(12*2),TSTNMS ;DO THIS TEST?
BNE     645 ;YES--BRANCH
JMP     TST13 ;NO--GO TO THE NEXT TEST
MOV     645: 812,2#TSTNM ;SET UP TEST NUMBER AND
;CLEAR THE ERROR FLAG (SERFLG)
JSR     PC,LOADPM ;LOAD THE PARAMETERS FOR THE TEST
MOV     8TST12,2#SLPERR ;SETUP THE ERROR LOOP ADDRESS
MOV     8TSTNM,2#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
MOV     2#RPT,8TIMES ;GET THE ITERATION COUNT
MOVB   25.,8ERMAX ;MAX ERRORS ALLOWED FOR TEST
TST    2#CLKSTA ;K11-P CLOCK?
BGT    15 ;YES--START TEST
JMP     TST13 ;NO--GO TO NEXT TEST
MOV     15: 815,8LPAOR ;SETUP LOOP ADDRESS
JSR     RO,2#SRCHOO ;DO A MASC-RUS INIT & RECAL
BR     25 ;RETURN HERE IF NO ERROR
JMP     EXIT12 ;RETURN HERE IF ERROR
MOV     25: 2#FC,APCA(R4) ;FC
MOV     2#FS,-(SP) ;S
MOVB   2#FT,1(SP) ;FT
MOV     (SP)+,RPA(R4) ;LOAD FT/FS

```

2694	012372	012737	012770	001206		MOV	#EXIT12, #ESCAPE	:: ESCAPE TO EXIT12 ON ERROR
2695	012400	005005				CLR	R5	:: COUNT UP
2696	012402	012703	002774			MOV	#17A, K3	:: 60HZ PARAMETERS
2697	012406	032737	000100	001220		BIT	#SW06, #BC.SWR	:: 60 HZ?
2698	012414	001402				BEQ	TEST12	:: YES--BRANCH
2699	012416	012703	003004			MOV	#17B, R3	:: NO--50 HZ PARAMETERS
2700	012422	012706	001100		TEST12:	MOV	#STACK, SP	:: SETUP STACK
2701	012426	012701	000012			MOV	#10, R1	:: TIME 10 SEARCHES
2702	012432	004737	027024			JSR	PC, #STRTMR	:: INITIALIZE THE TIMERS
2703	012436	012777	012644	166730		MOV	#78, #PKV	:: SETUP VECTOR IN CASE OF OVERFLOW
2704	012444	012777	027022	022014		MOV	#DOATI, #RPEC	:: SETUP RPO4/5/6 VECTOR
2705	012452	005077	166724		18:	CLR	#PKB	:: START COUNTING AT ZERO
2706	012456	012777	000131	166714		MOV	#131, #PKCS	:: INT.EN., COUNT UP AT 100KHZ
2707	012464	012714	000131			MOV	#SEARCH, (R4)	:: START A SEARCH
2708	012470	000001				WAIT		:: WAIT ON INTERRUPT
2709	012472	042777	000101	166700		BIC	#101, #PKCS	:: STOP THE CLOCK
2710	012500	032764	040000	000012		BIT	#BIT14, #RPS1(R4)	:: ERROR?
2711	012506	001415				BEQ	25	:: NO--BRANCH
2712	012510	104412				SAVREG		:: SAVE R0-R5
2713	012512	012702	004164			MOV	#DTADPB, R2	:: DPB POINTER
2714	012516	004737	042004			JSR	PC, #SVRH11	:: SAVE ALL THE RH11/RP04 REGISTERS
2715	012522	012764	000040	000010		MOV	#BIT05, #RCS2(R4)	:: MASSBUS CLEAR
2716	012530	013764	004164	000010		MOV	#DTADPB, #RCS2(R4)	:: SELECT DRIVE
2717	012536	104413				RESREG		:: RESTORE R0-R5
2718	012540	104017				ERROR	17	
2719	012542	005077	166634		25:	CLR	#PKB	:: START THE COUNT AT ZERO
2720	012546	012714	000131			MOV	#SEARCH, (R4)	:: START A SEARCH
2721	012552	012777	000131	166620		MOV	#131, #PKCS	:: START THE CLOCK
2722	012560	000001				WAIT		:: WAIT ON INTERRUPT
2723	012562	042777	000101	166610		BIC	#101, #PKCS	:: STOP THE CLOCK
2724	012570	032764	040000	000012		BIT	#BIT14, #RPS1(R4)	:: IS "ERR=1"?
2725	012576	001415				BEQ	35	:: NO--BRANCH
2726	012600	104412				SAVREG		:: SAVE R0-R5
2727	012602	012702	004164			MOV	#DTADPB, R2	:: DPB POINTER
2728	012606	004737	042004			JSR	PC, #SVRH11	:: SAVE ALL THE RH11/RP04 REGISTERS
2729	012612	012764	000040	000010		MOV	#BIT05, #RCS2(R4)	:: MASSBUS CLEAR
2730	012620	013764	004164	000010		MOV	#DTADPB, #RCS2(R4)	:: SELECT DRIVE
2731	012628	104413				RESREG		:: RESTORE R0-R5
2732	012630	104017				ERROR	17	:: DISK ERROR OCCURRED
2733	012632	004737	027070		35:	JSR	PC, #COUNT	:: UPDATE THE COUNT
2734	012636	005301				DEC	R1	:: DONE?
2735	012640	003304				BGT	18	:: NO--BRANCH
2736	012642	000424				BR	85	:: YES--GO TO THE EXIT
2737	012644	042777	000101	166526	75:	BIC	#101, #PKCS	:: STOP THE CLOCK
2738	012652	005037	177776			CLF	#FS	:: DROP THE PRIORITY
2739	012656	012600				MV	(SP)+, R0	:: PC OF WAIT+2
2740	012658	005726				ST	(SP)+	:: POP THE PS FROM THE STACK
2741	012662	104412				SAVREG		:: SAVE R0-R5
2742	012664	012702	004164			MOV	#DTADPB, R2	:: DPB POINTER
2743	012670	004737	042004			JSR	PC, #SVRH11	:: SAVE ALL THE RH11/RP04 REGISTERS
2744	012674	012764	000040	000010		MOV	#BIT05, #RCS2(R4)	:: MASSBUS CLEAR
2745	012702	013764	004164	000010		MOV	#DTADPB, #RCS2(R4)	:: SELECT DRIVE
2746	012710	104413				RESREG		:: RESTORE R0-R5
2747	012712	104020				ERROR	20	:: CLOCK OVERFLOWED
2748	012714				85:			
2749	012714	012764	000040	000010		MOV	#BIT05, #RCS2(R4)	:: MASSBUS INIT.

```

2750 012728 013764 004164 000010      MOV      @DTP0PB,RPCS2(R4) ;SELECT DRIVE
2751 012730 004737 024044          JSR      PC,@ST.CLK      ;INITIALIZE THE CLOCK
2752 012734 012777 037346 021524      MOV      @ISR,@PVEC     ;RESTORE RHI1/RPO4/5/6 INT. VECTOR
2753 012742 032737 000100 001220      BIT      @SW06,@C.SWR   ;60 HZ?
2754 012750 001004          BNE     9$              ;NO -- BRANCH
2755 012752 004737 027222      JSR      R0,@TYPTIM     ;GO TYPE THE TIMES
2756 012756 005774          T7A     ;POINTER
2757 012760 010403          BR      EXIT12         ;GO TO EXIT
2758 012762          9$:
2759 012762 004037 027222      JSR      R0,@TYPTIM     ;GO TYPE THE TIMES
2760 012766 003004          T7B     ;POINTER
2761 012770 000004          EXIT12: SCOPE         ;LOOP
2762
2763
2764
2765
2766
2767
2768
2769
2770
2771
2772
2773
2774
2775 012772          ;*****
2776 012772 000240          ;TEST 13      ONE CYLINDER SEEK TIMING TEST
2777 012774 033737 001452 001234      ;*
2778 013002 001002          ;* THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE
2779 013004 000137 013436          ;* CYLINDER BY ONE UNTIL THE INCREMENT IS GREATER THAN THE
2780 013010 012737 000013 001102 64$: MOV      #13,@STSTNM     ;* CYLINDER 'LC', THEN REVERSE SEEK TO CYLINDER 'FC'. THE
2781          ;* TIME TO PERFORM EACH SEEK IS CHECKED TO ENSURE IT DOES NOT
2782 013016 004737 024560          ;* EXCEED THE MAXIMUM TIME PERMITTED FOR A ONE CYLINDER SEEK.
2783 013022 012737 012772 001110      ;* THE TIME MUST BE LESS THAN 10MS.
2784 013030 013777 001102 166104      ;*****
2785 013036 013737 001506 001204      ;TEST13:
2786 013044 112737 000031 001115      NOP
2787 013052 005737 001244          BIT      @BITS+(13*2),TSTNMS ;DO THIS TEST?
2788 013056 003002          BNE     64$            ;YES--BRANCH
2789 013060 000137 013436          JMP     TST14         ;NO--GO TO THE NEXT TEST
2790 013064 012737 013064 001106 1$: MOV      #13,@STSTNM     ;SET UP TEST NUMBER AND
2791 013072 004037 026640          JSR      PC,LOOPRM     ;CLEAR THE ERROR FLAG (SERFLG)
2792 013076 000402          BR      2$              ;LOAD THE PARAMETERS FOR THE TEST
2793 013100 000137 013434          JMP     EXIT13        ;SETUP THE ERROR LOOP ADDRESS
2794 013104 012703 003014          MOV     @STSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2795 013110 012737 013434 001206      MOV     @RPT,$TIMES     ;GET THE ITERATION COUNT
2796 013116 012706 001100          MOV     @25,$ERMAX     ;MAX ERRORS ALLOWED FOR TEST
2797 013122 013737 001510 004176      TST     @CLKSTA        ;KHI1-P CLOCK?
2798 013130 005237 004176          BGT     1$            ;YES--START TEST
2799 013134 005305          JMP     TST14         ;NO--GO TO NEXT TEST
2800 013136 004737 027024          MOV     #15,$LPADR     ;SETUP THE LOOP ADDRESS
2801 013142 012777 013330 166224      JSR     R0,@SRCH00     ;DO A MASSBUS INIT. AND RECAL
2802 013150 012777 027022 021310      BR      2$            ;NO ERROR RETURN
2803 013156 01777 166220          JMP     EXIT13        ;ERROR RETURN--SCOPE LOOP CALL
2804 013162 013764 004176 000034      MOV     @T10,R3        ;PARAMETER POINTER
2805 013170 012714 000105          MOV     @EXIT13,$ESCAPE ;ESCAPE TO EXIT13 ON ERROR
2806          TEST13: MOV     @STACK,$P      ;SETUP STACK
2807          MOV     FC,@DTP0PB+12 ;START WITH BEGINNING CYLINDER
2808          INC     DTP0PB+12   ;INCREMENT THE BEGINNING CYLINDER
2809          CLR     R5         ;SET THE UP/DOWN SWITCH TO UP
2810          JSR     PC,@STRTRM ;INITIALIZE THE TIMERS
2811          MOV     @7,$@PKV   ;SETUP INCASE OF OVERFLOW
2812          MOV     @DORTI,@PVEC ;SET RPO4/5/6 VECTOR
2813          CLR     @PKB      ;START THE COUNTER AT ZERO
2814          MOV     @DTP0PB+12,RPC(R4) ;LOAD DESIRED CYLINDER
2815          MOV     @SEEK,(R4) ;START A SEEK

```

# E05

```
2806 013174 012777 000131 166176 MOV #131, @PKCS ; START THE CLOCK
2807 013202 000001 WAIT ; WAIT ON INTERRUPT
2808 013204 042777 000101 166166 SIC #101, @PKCS ; STOP THE CLOCK
2809 013212 032764 040000 000012 BIT #BIT14, RPOS1(R4) ; ANY DISK ERRORS?
2810 013220 001415 BEQ 25 ; NO--BRANCH
2811 013222 104412 SAVREG ; SAVE R0-R5
2812 013224 012702 004164 MOV #DTADPB, R2 ; DPB POINTER
2813 013230 004737 042004 JSR PC, @SVRH11 ; SAVE ALL THE RH11/RPO4 REGISTERS
2814 013234 012764 000040 000010 MOV #BIT05, RPCS2(R4) ; MASSBUS CLEAR
2815 013242 013764 004164 000010 MOV #DTADPB, RPCS2(R4) ; SELECT DRIVE
2816 013250 104413 RESREG ; RESTORE R0-R5
2817 013252 104017 ERROR 17 ; REPORT THE ERROR
2818 013254 004737 027070 25: JSR PC, @COUNT ; COUNT THIS SEEKS TIME
2819 013260 004737 026416 JSR PC, @TWOMS ; STALL FOR 2 MILLISECONDS
2820 013264 005705 TST R5 ; UP OR DOWN?
2821 013266 001011 BNE 45 ; DOWN--BRANCH
2822 013270 005237 004176 35: INC @DTADPB+12 ; MOVE TO NEXT CYLINDER
2823 013274 023737 004176 001512 CMP @DTADPB+12, LC ; OUT OF CYLINDERS?
2824 013302 002725 BLT 15 ; NO--GO DO THE NEXT SEEK
2825 013304 012705 177777 MOV #-1, R5 ; SET UP/DOWN SWITCH TO DOWN
2826 013310 000722 BR 15 ; GO DO THE NEXT SEEK
2827 013312 005337 004176 45: DEC @DTADPB+12 ; MOVE TO NEXT CYLINDER
2828 013316 023727 004176 000000 CMP @DTADPB+12, #0 ; OUT OF CYLINDERS?
2829 013324 003314 BGT 15 ; NO--GO DO THE NEXT SEEK
2830 013326 000424 BR 85 ; GO TO THE EXIT
2831 013330 042777 000101 166042 75: BIC #101, @PKCS ; STOP THE CLOCK
2832 013336 005037 177776 CLR @PS ; DROP THE PRIORITY
2833 013342 012600 MOV (SP)+, R0 ; PC OF WAIT+2
2834 013344 005726 TST (SP)+ ; POP THE PS FROM THE STACK
2835 013346 104412 SAVREG ; SAVE R0-R5
2836 013350 012702 004164 MOV #DTADPB, R2 ; DPB POINTER
2837 013354 004737 042004 JSR PC, @SVRH11 ; SAVE ALL THE RH11/RPO4 REGISTERS
2838 013360 012764 000040 000010 MOV #BIT05, RPCS2(R4) ; MASSBUS CLEAR
2839 013366 013764 004164 000010 MOV #DTADPB, RPCS2(R4) ; SELECT DRIVE
2840 013374 104413 RESREG ; RESTORE R0-R5
2841 013376 104020 ERROR 20 ; REPORT CLOCK OVERFLOW
2842 013400 85:
2843 013400 012764 000040 000010 MOV #BIT05, RPCS2(R4) ; MASSBUS INIT.
2844 013406 013764 004164 000010 MOV #DTADPB, RPCS2(R4) ; SELECT DRIVE
2845 013414 004737 024044 JSR PC, @ST.CLK ; INITIALIZE THE CLOCK
2846 013420 012777 037346 021040 MOV #ISR, @RVEC ; RESTORE RH11/RPO4/5/6 INT. VECTOR
2847 013426 004037 027222 JSR R0, @TYPTIM ; GO TYPE THE TIMES
2848 013432 003014 TIO ; POINTER
2849 013434 000004 EXIT13: SCOPE ; LOOP ?
```

\*\*\*\*\*  
\*TEST 14 ACCESS TIME MEASUREMENT TEST

THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 0 TO  
CYLINDER 'LC', THEN A REVERSEK FROM CYLINDER 'LC' TO  
CYLINDER 0. BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE THEY  
ARE WITHIN THE TOLERANCE ALLOWED FOR THE ACCESS TIME MEASUREMENT.  
THIS SEQUENCE IS REPEATED 128 TIMES (FOR A TOTAL  
OF 256 SEEKS). THE AVERAGE ACCESS TIME MUST BE LESS THAN 30 MS.  
CYLINDER 'LC' DEFAULTS TO 136 (10) FOR AN RPO4/5 OR TO 255 (10)

2850  
2851  
2852  
2853  
2854  
2855  
2856  
2857  
2858  
2859  
2860  
2861

# F05

;\* FOR AN RPO6.

\*\*\*\*\*

```

2862
2863
2864
2865 013436
2866 013436 000240
2867 013440 033737 001454 001234
2868 013446 001002
2869 013450 000137 014154
2870 013454 012737 000014 001162
2871
2872 013462 004737 024560
2873 013466 012737 013436 001110
2874 013474 013777 001102 165440
2875 013502 013737 001506 001204
2876 013510 112737 000031 001115
2877 013516 005737 001244
2878 013522 003002
2879 013524 000137 014154
2880 013530 012737 013530 001106
2881 013536 004037 026640
2882 013542 000402
2883 013544 000137 014152
2884 013550 012703 003024
2885 013554 012737 014152 001206
2886 013562 012706 001100
2887 013566 012701 000200
2888 013572 004737 027024
2889 013576 012777 014046 165570
2890 013604 012777 027022 020654
2891 013612 005077 165564
2892 013616 013764 001512 000034
2893 013624 012764 000105 000000
2894 013632 012777 000131 165540
2895 013640 000001
2896 013642 042777 000101 165530
2897 013650 032764 040000 000012
2898 013656 001415
2899 013660 104412
2900 013662 012702 004164
2901 013666 004737 042004
2902 013672 012764 000040 000010
2903 013700 013764 004164 000010
2904 013706 104413
2905 013710 104017
2906 013712 005005
2907 013714 004737 027070
2908 013720 004737 026416
2909 013724 005077 165452
2910 013730 013764 001510 000034
2911 013736 012764 000105 000000
2912 013744 012777 000131 165426
2913 013752 000001
2914 013754 042777 000101 165416
2915 013762 032764 040000 000012
2916 013770 001415
2917 013772 104412
    
```

```

TST14:
NOP
BIT 2#BITS+(14*2),TSTNMS ;DO THIS TEST?
BNE 645 ;YES--BRANCH
JMP TST15 ;NO--GO TO THE NEXT TEST
MOV 645,2#TSTNM ;SET UP TEST NUMBER AND
;CLEAR THE ERROR FLAG (SERFLG)
JSR PC,LOOPRM ;LOAD THE PARAMETERS FOR THE TEST
MOV 2#TST14,2#SLPERR ;SETUP THE ERROR LOOP ADDRESS
MOV 2#TSTNM,2#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
MOV 2#RPT,$TIMES ;GET THE ITERATION COUNT
MOVB 25,$SERMAX ;MAX ERRORS ALLOWED FOR TEST
TST 2#CLKSTA ;K11-P CLOCK?
BGT 18 ;YES--START TEST
JMP TST15 ;NO--GO TO NEXT TEST
MOV 18,$LPAOR ;SET THE LOOP ADDRESS
JSR RD,2#SRCHOO ;DO A MASSBUS INIT & RECAL
BR 25 ;RETURN HERE IF NO ERROR
JMP EXIT14 ;RETURN HERE ON ERROR
MOV 2#T11,R3 ;PARAMETER POINTER
MOV 2#EXIT14,$ESCAPE ;ESCAPE TO EXIT14 ON ERROR
MOV 2#STACK,$P ;SETUP STACK
MOV 128,$R1 ;REPEAT "0-136-0" 128 TIMES
JSR PC,2#STRMR ;INIT. THE COUNTERS
MOV 2#7,$2PKV ;SET UP VECTOR IN CASE OF OVERFLOW
MOV 2#0,2#ARTI,2#RVEC ;SETUP RPO4/5/6 VECTOR
18: CLR 2#PKB ;START COUNT AT ZERO
MOV LC,RPC4(R4) ;"MIDDLE" CYLINDER
MOV 2#SEEK,RPCS1(R4) ;START A SEEK
MOV 2#131,2#PKCS ;START THE CLOCK
WAIT ;WAIT ON INTERRUPT
BIC 2#101,2#PKCS ;STOP CLOCK
BIT 2#BIT14,RPCS1(R4) ;ERR=1?
BEQ 25 ;NO--BRANCH
SAVREG ;SAVE R0-R5
MOV 2#DTADPB,R2 ;DPB POINTER
JSR PC,2#SVRH11 ;SAVE ALL THE RH11/RPO4 REGISTERS
MOV 2#BIT05,RPCS2(R4) ;MASSBUS CLEAR
MOV 2#DTADPB,RPCS2(R4) ;SELECT DRIVE
RESREG ;RESTORE R0-R5
ERROR 17
25: CLR R ;SET UP/DOWN SWITCH TO UP
JSR PC,2#COUNT ;UPDATE THE COUNT
JSR PC,2#TWOMS ;STALL FOR 2 MILLISECONDS
CLR 2#PKB ;START THE COUNT AT ZERO
MOV FC,RPC4(R4) ;BEGINNING CYLINDER
MOV 2#SEEK,RPCS1(R4) ;START A SEEK
MOV 2#131,2#PKCS ;START THE CLOCK
WAIT ;WAIT ON INTERRUPT
BIC 2#101,2#PKCS ;STOP THE CLOCK
BIT 2#BIT14,RPCS1(R4) ;ERR=1?
BEQ 35 ;NO--BRANCH
SAVREG ;SAVE R0-R5
    
```

```

2918 013774 012702 004164      MOV      #DTADPB,R2      ;DPB POINTER
2919 014000 004737 042004      JSR      PC,@SVRH11     ;SAVE ALL THE RH11/RPO4 REGISTERS
2920 014004 012764 000040 000010      MOV      #BIT05,RPCS2(R4) ;MASSBUS CLEAR
2921 014012 013764 004164 000010      MOV      @#DTADPB,RPCS2(R4) ;SELECT DRIVE
2922 014020 104413      RESREG      ;RESTORE R0-R5
2923 014022 104017      ERROR      17
2924 014024 012705 177777      35:     MOV      #-1,R5      ;SET UP/DOWN SWITCH TO DOWN
2925 014030 004737 027070      JSR      PC,@COUNT    ;UPDATE THE COUNT
2926 014034 004737 026416      JSR      PC,@TWOMS     ;STALL FOR 2 MILLISECONDS
2927 014040 005301      DEC      R1           ;DONE?
2928 014042 003263      BGT      18          ;NO--BRANCH
2929 014044 000424      BR       B9          ;YES--EXIT
2930 014046 042777 000101 165324      75:     BIC      #101,@PKCS    ;STOP THE CLOCK
2931 014054 005037 177776      CLR      @#PS        ;DROP THE PRIORITY
2932 014060 012600      MOV      (SP)+,R0     ;PC OF WAIT+2
2933 014062 005726      *ST      (SP)+      ;POP THE PS FROM THE STACK
2934 014064 104412      SAVREG      ;SAVE R0-R5
2935 014066 012702 004164      MOV      #DTADPB,R2   ;DPB POINTER
2936 014072 004737 042004      JSR      PC,@SVRH11   ;SAVE ALL THE RH11/RPO4 REGISTERS
2937 014076 012764 000040 000010      MOV      #BIT05,RPCS2(R4) ;MASSBUS CLEAR
2938 014104 013764 004164 000010      MOV      @#DTADPB,RPCS2(R4) ;SELECT DRIVE
2939 014112 104413      RESREG      ;RESTORE R0-R5
2940 014114 104020      ERROR      20        ;CLOCK OVERFLOWED
2941 014116      85:
2942 014116 012764 000040 000010      MOV      #BIT05,RPCS2(R4) ;MASSBUS INIT.
2943 014124 013764 004164 000010      MOV      @#DTADPB,RPCS2(R4) ;SELECT DRIVE
2944 014132 004737 024044      JSR      PC,@ST.CLK   ;INITIALIZE THE CLOCK
2945 014136 012777 037346 020322      MOV      #ISR,@RPEC   ;RESTORE RH11/RPO4/5/6 INT. VECTOR
2946 014144 004037 027222      JSR      R0,@TYPTIM   ;GO TYPE THE TIMES
2947 014150 003024      T11        ;POINTER
2948 014152 000004      EXIT14: SCOPE      ;LOOP ?
2949
2950
2951 *****
2952 ;*TEST 15      MAXIMUM SEEK TIMING TEST
2953
2954 ;*      THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 0 TO
2955 ;*      CYLINDER 'LC', THEN A REVERSE SEEK FROM CYLINDER 'LC' TO
2956 ;*      CYLINDER 0. BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE
2957 ;*      THEY ARE WITHIN THE TOLERANCE ALLOWED FOR THE MAXIMUM SEEK
2958 ;*      TIME. THIS SEQUENCE IS REPEATED 128 TIMES (FOR
2959 ;*      A TOTAL OF 256 SEEKS). THE MAXIMUM SEEK TIME MUST BE LESS THAN
2960 ;*      54 MS. 'LC' DEFAULTS TO 410 (10) FOR RPO4/5'S AND TO 814 (10)
2961 ;*      FOR RPO6'S.
2962 *****
2963 ;*TEST15:
2964 014154 000240      NOP
2965 014154 033737 001456 001234      BIT      @#BITS+(15*2),TSTNMS ;DO THIS TEST?
2966 014164 001002      BNE      645        ;YES--BRANCH
2967 014166 000137 014672      JMP      TST16      ;NO--GO TO THE NEXT TEST
2968 014172 012737 000015 001102      645:   MOV      #15,@#TSTNM  ;SET UP TEST NUMBER AND
2969      ;CLEAR THE ERROR FLAG (SERFLG)
2970 014200 004737 024560      JSR      PC,LOOPRM   ;LOAD THE PARAMETERS FOR THE TEST
2971 014204 012737 014154 001110      MOV      @#TST15,@#SLPERR ;SETUP THE ERROR LOOP ADDRESS
2972 014212 013777 001102 164722      MOV      $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2973 014220 013737 001506 001204      MOV      @#RPT,$TIMES ;GET THE ITERATION COUNT

```



# H05

MD-11-DZRJA-AA RPO4/5/6 MECHANICAL AND READ/WRITE TEST MACY11 27(1006) 02-NOV-76 18:27 PAGE 60  
 DZRJA.014 19-APR-76 00:00 T15 MAXIMUM SEEK TIMING TEST

2974	014226	112737	000031	001115		MOVB	#25, \$ERMAX	MAX ERRORS ALLOWED FOR TEST
2975	014234	005737	001244			TST	#CLKSTA	: KHI1-P CLOCK
2976	014240	003002				BGT	1\$	: YES--START TEST
2977	014242	000137	014672			JMP	TST16	: NO--GO TO NEXT TEST
2978	014246	012737	014246	001106	1\$:	MOV	#1\$,\$LPAOR	: SETUP THE LOOP ADDRESS
2979	014254	004037	026640			JSR	RO,#SRCH00	: DO A MASSBUS INIT & RECAL
2980	014260	000402				BR	2\$	: RETURN HERE IF NO ERROR
2981	014262	000137	014670			JMP	EXIT15	: RETURN HERE ON ERROR
2982	014266	012703	003034		2\$:	MOV	#T12,R3	: PARAMETER POINTER
2983	014272	012737	014670	001206		MOV	#EXIT15,\$ESCAPE	: ESCAPE TO EXIT15 ON ERROR
2984	014300	012706	001100		TEST15:	MOV	#STACK,SP	: SETUP STACK
2985	014304	012701	000200			MOV	#128,R1	: REPEAT "0-'LC'-0" 128 TIMES
2986	014310	004737	027024			JSR	PC,#STRTHR	: INIT. THE TIMERS
2987	014314	012777	014564	165052		MOV	#7\$,\$PKV	: SETUP VECTOR IN CASE OF OVERFLOW
2988	014322	012777	027022	020136		MOV	#DCATI,\$RPVEC	: SETUP RPO4/5/6 VECTOR
2989	014330	005077	165046		1\$:	CLR	\$PKB	: START COUNTING FROM ZERO
2990	014334	013764	001512	000034		MOV	LC,RPCA(R4)	: MAXIMUM CYLINDER
2991	014342	012764	000105	000000		MOV	#SEEK,RPCS1(R4)	: START A SEEK
2992	014350	012777	000131	165022		MOV	#131,\$PKCS	: START THE CLOCK
2993	014356	000001				WAIT		: WAIT ON INTERRUPT
2994	014360	042777	000101	165012		BIC	#101,\$PKCS	: STOP THE CLOCK
2995	014366	032764	040000	000012		BIT	#BIT14,RPCS1(R4)	: "ERR"=1?
2996	014374	001415				BEQ	2\$	: NO--BRANCH
2997	014376	104412				SAVREG		: SAVE R0-R5
2998	014400	012702	004164			MOV	#DTADPB,R2	: DPB POINTER
2999	014404	004737	042004			JSR	PC,#SVRH11	: SAVE ALL THE RH11/RPO4 REGISTERS
3000	014410	012764	000040	000010		MOV	#BIT05,RPCS2(R4)	: MASSBUS CLEAR
3001	014416	013764	004164	000010		MOV	#DTADPB,RPCS2(R4)	: SELECT DRIVE
3002	014424	104413				RESREG		: RESTORE R0-R5
3003	014426	104017				ERROR	17	
3004	014430	005005			2\$:	CLR	R5	: SET THE UP/DOWN SWITCH TO UP
3005	014432	004737	027070			JSR	PC,#COUNT	: UP THE COUNT
3006	014436	004737	026416			JSR	PC,#TWOMS	: STALL FOR 2 MILLISECONDS
3007	014442	005077	164734			CLR	\$PKB	: START COUNT AT ZERO
3008	014446	013764	001510	000034		MOV	FC,RPCA(R4)	: BEGINNING CYLINDER
3009	014454	012764	000105	000000		MOV	#SEEK,RPCS1(R4)	: START A SEEK
3010	014462	012777	000131	164710		MOV	#131,\$PKCS	: START THE CLOCK
3011	014470	000001				WAIT		: WAIT ON INTERRUPT
3012	014472	042777	000101	164700		BIC	#101,\$PKCS	: STOP THE CLOCK
3013	014500	032764	040000	000012		BIT	#BIT14,RPCS1(R4)	: "ERR"=1?
3014	014506	001415				BEQ	3\$	: NO--BRANCH
3015	014510	104412				SAVREG		: SAVE R0-R5
3016	014512	012702	004164			MOV	#DTADPB,R2	: DPB POINTER
3017	014516	004737	042004			JSR	PC,#SVRH11	: SAVE ALL THE RH11/RPO4 REGISTERS
3018	014522	012764	000040	000010		MOV	#BIT05,RPCS2(R4)	: MASSBUS CLEAR
3019	014530	013764	004164	000010		MOV	#DTADPB,RPCS2(R4)	: SELECT DRIVE
3020	014536	104413				RESREG		: RESTORE R0-R5
3021	014540	104017				ERROR	17	: REPORT THE ERROR
3022	014542	012705	177777		3\$:	MOV	#-1,R5	: SET THE UP/DOWN SWITCH TO DOWN
3023	014546	004737	027070			JSR	PC,#COUNT	: UPDATE THE COUNT
3024	014552	004737	026416			JSR	PC,#TWOMS	: STALL FOR 2 MILLISECONDS
3025	014556	005301				DEC	R1	: DONE?
3026	014560	003753				BGT	1\$	: NO--BRANCH
3027	014562	000424				EX	8\$	: YES--EXIT
3028	014564	042777	000101	164606	7\$:	BIC	#101,\$PKCS	: STOP THE CLOCK
3029	014572	005037	177776			CLR	\$PS	: DROP THE PRIORITY



```

3030 014576 012600      MOV      (SP)+,R0      ;PC OF WAIT+2
3031 014600 005726      TST      (SP)+        ;POP THE PS FROM THE STACK
3032 014602 104412      SAVREG          ;SAVE R0-R5
3033 014604 012702 004164    MOV      @DTACPB,R2   ;DPB POINTER
3034 014610 004737 042004    JSR      PC,@SVRH11   ;SAVE ALL THE RH11/RPO4 REGISTERS
3035 014614 012764 000040 000010  MOV      @BIT05,RPCS2(R4) ;MASSEBUS CLEAR
3036 014622 013764 004164 000010  MOV      @DTACPB,RPCS2(R4) ;SELECT DRIVE
3037 014630 104413      RESREG          ;RESTORE R0-R5
3038 014632 104020      ERROR 20         ;CLOCK OVERFLOWED
3039 014634
3040 014634 012764 000040 000010  BS:      MOV      @BIT05,RPCS2(R4) ;MASSEBUS INIT.
3041 014642 013764 004164 000010  MOV      @DTACPB,RPCS2(R4) ;SELECT DRIVE
3042 014650 004737 024044    JSR      PC,@ST.CLK   ;INITIALIZE THE CLOCK
3043 014654 012777 037346 017604    MOV      @ISR,@RPVEC  ;RESTORE RH11/RPO4/5/6 INT. VECTOR
3044 014662 004037 027222    JSR      R0,@TYPTIM   ;GO TYPE THE TIMES
3045 014666 003034      T12            ;POINTER
3046 014670 000004      EXIT15: SCOPE     ;LOOP ?

```



# K05

```

3103 015064 012737 015064 001110      MOV      #. $LPERR      ;SETUP THE ERROR LOOP ADDRESS
3104 015072 012706 001100      MOV      #STACK,SP     ;LOAD THE STACK POINTER
3105 015076 004037 025474      JSR      RO,#DRVCAL    ;START A DATA TRANSFER
3106 015102 012737 015102 001110      MOV      #. $LPERR      ;SETUP THE ERROR LOOP ADDRESS
3107 015110 012706 001100      MOV      #STACK,SP     ;LOAD THE STACK POINTER
3108 015114 004037 027712      JSR      RO,#CLRBUF    ;CLEAR BUFFER
3109 015120 012737 000171 004166      MOV      #READ,#DTADPB+2 ;COMMAND = READ
3110 015126 004037 025474      JSR      RO,#DRVCAL    ;START A DATA TRANSFER
3111 015132 004037 027760      JSR      RO,#CKSCTR    ;CHECK THE SECTOR DATA READ
3112 015136 012700 047662      MOV      #BUFFER,RO    ;BUFFER ADDRESS
3113 015142 005001      CLR      R1            ;FIRST SECTOR
3114 015144 012737 015144 001110      MOV      #. $LPERR      ;SETUP THE ERROR LOOP ADDRESS
3115 015152 012706 001100      MOV      #STACK,SP     ;LOAD THE STACK POINTER
3116 015156 012737 000161 004166 18:      MOV      #WRITE,#DTADPB+2 ;COMMAND=WRITE DATA
3117 015164 012737 177400 004170      MOV      #SCTRWC,#DTADPB+4 ;WORD COUNT
3118 015172 010037 004172      MOV      RO,#DTADPB+6  ;BUFFER ADDRESS
3119 015176 110137 004174      MOV      R1,#DTADPB+10 ;SECTOR
3120 015202 004037 025474      JSR      RO,#DRVCAL    ;START A DATA TRANSFER
3121 015206 012737 015206 001110      MOV      #. $LPERR      ;SETUP THE ERROR LOOP ADDRESS
3122 015214 012706 001100      MOV      #STACK,SP     ;LOAD THE STACK POINTER
3123 015220 012737 000151 004166      MOV      #WRCKD,#DTADPB+2 ;COMMAND=WRITE CHECK DATA
3124 015226 013737 001352 004170      MOV      #TRCKWC,#DTADPB+4 ;WORD COUNT
3125 015234 012737 047662 004172      MOV      #BUFFER,#DTADPB+6 ;BUFFER ADDRESS
3126 015242 105037 004174      CLR      #DTADPB+10   ;SECTOR
3127 015246 004037 025474      JSR      RO,#DRVCAL    ;START A DATA TRANSFER
3128 015252 062700 001000      ADD      #512,RO       ;MOVE TO NEXT SECTOR
3129 015256 005201      INC      R1
3130 015260 023701 001630      CMP      PRMLMT+22,R1  ;DONE?
3131 015254 103334      BHS     18             ;NO--BRANCH
3132 015266 000004      EXIT16: SCOPE        ;LOOP ?
3133
3134 ;*****
3135 ;*TEST 17          TRACY ADDRESSING TEST
3136
3137 ;*      THIS TEST WILL WRITE DATA IN THE FORM OF TRACK ADDRESSES
3138 ;*      IN CYLINDER "FC" SECTOR "FS" OF EVERY TRACK WITH EACH TRACK
3139 ;*      GETTING ITS OWN TRACK ADDRESS.
3140 ;*      A WRITE CHECK IS THEN PERFORMED ON EACH TRACK TO ENSURE
3141 ;*      THE DATA IS VALID. THEN TRACK 0 IS REWRITTEN AND TRACK 1
3142 ;*      THROUGH TRACK 18 IS WRITE CHECKED. THEN TRACK 1 IS
3143 ;*      REWRITTEN AND TRACK 2 THROUGH TRACK 18 IS WRITE CHECKED.
3144 ;*      THIS PROCEDURE IS CONTINUED UP THROUGH REWRITING TRACK 17
3145 ;*      AND WRITE CHECKING TRACK 18.
3146
3147 ;*****
3148 †ST17:
3149 015270 000240      NOP
3150 015272 033737 001462 001234      BIT      #BITS+(17*2),TSTNMS ;DO THIS TEST?
3151 015300 001002      BNE     648           ;YES--BRANCH
3152 015302 000137 015710      JMP     TST20        ;NO--GO TO THE NEXT TEST
3153 015306 012737 000017 001102 648:      MOV      #17,#STSTNM  ;SET UP TEST NUMBER AND
3154 ;*      CLEAR THE ERROR FLAG (SERFLG)
3155 015314 004737 024560      JSR      PC,LODPRM   ;LOAD THE PARAMETERS FOR THE TEST
3156 015320 012737 015364 001110      MOV      #TST17,#$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
3157 015326 013777 001102 163606      MOV      $STSTNM,#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3158 015334 013737 001506 001204      MOV      #RPT,$TIMES  ;GET THE ITERATION COUNT
    
```

# L05

3159	015342	113737	001364	001115		MOV	ERR.CT, SERMAX	;MAX ERRORS ALLOWED FOR TEST
3160	015350	012737	015706	001252		MOV	#EXIT17, 2#BYPASS	
3161	015356	012737	015364	001106		MOV	#TEST17, \$LPRDR	;SETUP THE LOOP ADDRESS
3162	015364	012706	001100		TEST17:	MOV	#STACK, SP	;SET THE STACK POINTER
3163	015370	004737	027654			JSR	PC, 2#FILBUF	;FILL THE BUFFER WITH TRACK ADDRESS
3164	015374	012737	000161	004166		MOV	#WRITE, 2#DTADPB+2	;COMMAND=WRITE DATA
3165	015402	013737	001510	004176		MOV	2#FC, 2#DTADPB+12	;CYLINDER
3166	015410	113737	001524	004174		MOV	2#FS, 2#DTADPB+10	;SECTOR
3167	015416	012737	177400	004170		MOV	#SCTRAC, 2#DTADPB+4	;WORD COUNT
3168	015424	012737	047662	004172		MOV	#BUFFER, 2#DTADPB+6	;BUFFER ADDRESS
3169	015432	005000				CLR	RO	;TRACK=0
3170	015434	012737	015434	001110		MOV	#SLPERB	;SETUP THE ERROR LOOP ADDRESS
3171	015442	012706	001100			MOV	#STACK, SP	;LOAD THE STACK POINTER
3172	015446	110037	004175		15:	MOV	RO, 2#DTADPB+11	;TRACK ADDRESS
3173	015452	004037	025474			JSR	RO, 2#DRVCAL	;START A DATA TRANSFER
3174	015456	062737	001000	004172		ADD	#256.*2., 2#DTADPB+6	;UPDATE BUFFER ADDRESS
3175	015464	005200				INC	RO	;UPDATE TRACK NUMBER
3176	015466	022700	000023			CMP	#19., RO	;OUT OF TRACKS?
3177	015472	003365				BGT	15	;NO--BRANCH
3178	015474	012737	047662	004172		MOV	#BUFFER, 2#DTADPB+6	;BUFFER ADDRESS
3179	015502	005000				CLR	RO	
3180	015504	012737	015504	001110		MOV	#SLPERB	;SETUP THE ERROR LOOP ADDRESS
3181	015512	012706	001100			MOV	#STACK, SP	;LOAD THE STACK POINTER
3182	015516	012737	000151	004166		MOV	#WRCKD, 2#DTADPB+2	;COMMAND=WRITE CHECK
3183	015524	110037	004175		25:	MOV	RO, 2#DTADPB+11	;TRACK ADDRESS
3184	015530	004037	025474			JSR	RO, 2#DRVCAL	;START A DATA TRANSFER
3185	015534	062737	001000	004172		ADD	#256.*2., 2#DTADPB+6	;UPDATE BUFFER ADDRESS
3186	015542	005200				INC	RO	;UPDATE TRACK NUMBER
3187	015544	022700	000023			CMP	#19., RO	;OUT OF TRACKS?
3188	015550	003365				BGT	25	;NO--BRANCH
3189	015552	005000				CLR	RO	;FIRST TRACK ADDRESS
3190	015554	110037	004175		35:	MOV	RO, 2#DTADPB+11	;TRACK
3191	015560	010001				MOV	RO, R1	;FORM BUFFER ADDRESS
3192	015562	012737	047662	004172		MOV	#BUFFER, 2#DTADPB+6	;BUFFER ADDRESS
3193	015570	005301			45:	DEC	R1	
3194	015572	002411				BLT	55	
3195	015574	062737	001000	004172		ADD	#256.*2., 2#DTADPB+6	
3196	015602	000772				BR	45	
3197	015604	012737	015604	001110		MOV	#SLPERB	;SETUP THE ERROR LOOP ADDRESS
3198	015612	012706	001100			MOV	#STACK, SP	;LOAD THE STACK POINTER
3199	015616	012737	000161	004166	55:	MOV	#WRITE, 2#DTADPB+2	;COMMAND=WRITE DATA
3200	015624	004037	025474			JSR	RO, 2#DRVCAL	;START A DATA TRANSFER
3201	015630	062737	001000	004172	65:	ADD	#256.*2., 2#DTADPB+6	;UPDATE BUFFER ADDRESS
3202	015630	105237	004175			INCB	2#DTADPB+11	;MOVE TO NEXT TRACK
3203	015642	012737	015642	001110		MOV	#SLPERB	;SETUP THE ERROR LOOP ADDRESS
3204	015650	012706	001100			MOV	#STACK, SP	;LOAD THE STACK POINTER
3205	015654	012737	000151	004166		MOV	#WRCKD, 2#DTADPB+2	;COMMAND=WRITE CHECK DATA
3206	015662	004037	025474			JSR	RO, 2#DRVCAL	;START A DATA TRANSFER
3207	015666	122737	000022	004175		CMPB	#18., 2#DTADPB+11	;OUT OF TRACKS?
3208	015674	003355				BGT	65	;NO--BRANCH
3209	015676	005200				INC	RO	;NEXT TRACK TO WRITE
3210	015700	022700	000022			CMP	#18., RO	;OUT OF TRACKS?
3211	015704	003323				BGT	35	;NO--BRANCH
3212	015706	000004			EXIT17:	SCOPE		

# M05

.SBTTL \*\*\* DATA TEST \*\*\*

\*\*\*\*\*  
;TEST 20 DATA TEST

THIS TEST PERFORMS DATA STORAGE AND RETRIEVAL ON CYLINDERS "FC" THROUGH "LC" BY THE INCREMENT "IC" USING THE DATA PATTERNS SPECIFIED. THE FOLLOWING SEQUENCE OCCURS FOR EACH CYLINDER:  
1. SET "NT" TO "FT" THEN REPEAT 2-4 UNTIL "NT" > "LT"  
2. WRITE THEN WRITE CHECK "FS" THROUGH "LS" OF TRACK "NT"  
3. READ THEN SOFTWARE COMPARE "FS" THROUGH "LS" OF TRACK "NT"  
4. INCREMENT "NT" BY "IT"  
5. REPEAT STEPS 1-4 FOR EACH DATA PATTERN  
6. REPEAT STEPS 1-5 FOR "FC" THROUGH "LC" ADVANCING BY "IC"

IF A WRITE CHECK ERROR OCCURS THE ERROR IS REPORTED AND THE TRACK IN ERROR IS REWRITTEN AND CHECKED. THIS CHECK IS ACCOMPLISHED BY PERFORMING TWO(2) SUCCESSIVE ERROR FREE WRITE CHECKS. IF THE CHECK FAILS THE ERROR IS REPORTED AS FATAL AND NO READ OCCURS.  
FS DEFAULTS TO 1 AND LS DEFAULTS TO 0  
PAT DEFAULTS TO 17777 (ALL POSSIBLE PATTERNS)  
THE POSSIBLE PATTERNS ARE:

PAT 0	PAT 1	PAT 2	PAT 3	PAT 4	PAT 5	PAT 6	PAT 7
165555	000001	177776	000000	000000	052525	007417	026455
133333	000003	177774	000000	010421	052525	007417	026455
165555	000007	177770	000000	021042	052525	007417	026455
133333	000017	177760	177777	031463	125252	170360	151322
165555	000037	177740	177777	042104	125252	170360	151322
133333	000077	177700	177777	052525	125252	170360	151322
165555	000177	177600	000000	063146	052525	007417	026455
133333	000377	177400	000000	073567	052525	007417	026455
165555	000777	177000	177777	104210	125252	170360	151322
133333	001777	176000	177777	114631	125252	170360	151322
165555	003777	174000	000000	125252	052525	007417	026455
133333	007777	170000	177777	135673	125252	170360	151322
165555	017777	160000	000000	146314	052525	007417	026455
133333	037777	140000	177777	156735	125252	170360	151322
165555	077777	100000	000000	167356	052525	007417	026455
133333	177777	000000	177777	177777	125252	170360	151322
PAT 8	PAT 9	PAT 10	PAT 11	PAT 12	PAT 13	PAT 14	PAT 15
165555	000001	177776	172666	077777	153333	000000	177777
133333	000002	177775	155555	137777	066667	177777	000000
165555	000004	177773	172666	157777	153333	177777	000000
133333	000010	177767	155555	167777	066667	177777	000000
165555	000020	177757	172666	173777	153333	177777	000000
133333	000040	177737	155555	175777	066667	177777	000000
165555	000100	177677	172666	176777	153333	177777	000000
133333	000200	177577	155555	177377	066667	177777	000000
165555	000400	177377	172666	177577	153333	177777	000000
133333	001000	176777	155555	177677	066667	177777	000000
165555	002000	175777	172666	177737	153333	177777	000000

3213  
3214  
3215  
3216  
3217  
3218  
3219  
3220  
3221  
3222  
3223  
3224  
3225  
3226  
3227  
3228  
3229  
3230  
3231  
3232  
3233  
3234  
3235  
3236  
3237  
3238  
3239  
3240  
3241  
3242  
3243  
3244  
3245  
3246  
3247  
3248  
3249  
3250  
3251  
3252  
3253  
3254  
3255  
3256  
3257  
3258  
3259  
3260  
3261  
3262  
3263  
3264  
3265  
3266  
3267  
3268

N05

```

3269 :* 133333 004000 173777 155555 177757 066667 177777 000000
3270 :* 165555 010000 167777 172666 177767 153333 177777 000000
3271 :* 133333 020000 157777 155555 177773 066667 177777 000000
3272 :* 165555 040000 137777 172666 177775 153333 177777 000000
3273 :* 133333 100000 077777 155555 177776 066667 177777 000000
3274 :*
3275
3276

```

```

3277 015710
3278 01710 000240
3279 015712 033737 001424 001236
3280 015720 001002
3281 015722 000137 016430
3282 015726 012737 000020 001102 64$:
3283
3284 015734 004737 024560 JSR PC,LOOPRM
3285 015740 012737 016112 001110 MOV #TEST20,#SLPERR
3286 015746 013777 001102 163166 MOV STSTNM,#DISPLAY
3287 015754 013737 001506 001204 MOV #RPT,$TIMES
3288 015762 113737 001364 001115 MOV#B ERR.CT,$ERRMAX
3289 015770 012737 015770 001106 MOV #,$SLPADR
3290 015776 005000 CLR R0
3291 016000 005004 CLR R4
3292 016002 013701 001526 MOV #LS,R1
3293 016006 163701 001524 SUB #FS,R1
3294 016012 002004 BGE 1$
3295 016014 063701 001630 ADD PRMLMT+22,R1
3296 016020 005201 INC R1
3297 016022 005100 COM R0
3298 016024 062704 000400 1$: ADD #256.,R4
3299 016030 005301 DEC R1
3300 016032 002374 BGE 1$
3301 016034 005404 NEG R4
3302 016036 010405 MOV R4,R5
3303 016040 005700 TST R0
3304 016042 001412 BEQ 3$
3305 016044 005005 CLR R5
3306 016046 013701 001630 MOV PRMLMT+22,R1
3307 016052 163701 001524 SUB #FS,R1
3308 016056 062705 000400 2$: ADD #256.,R5
3309 016062 005301 DEC R1
3310 016064 002374 BGE 2$
3311 016066 005405 NEG R5
3312 016070 113737 001524 004174 3$: MOV#B #FS,#DTAOPB+10 ;SECTOR
3313 016076 012737 047662 004172 MOV #BUFFER,#DTAOPB+6 ;DATA BUFFER
3314 016104 012737 016426 001252 MOV #EXIT20,#BYPASS
3315 016112 012706 001100 TEST20: MOV #STACK,$P ;LOAD THE STACK POINTER
3316 016116 005037 001334 CLR #CEFLG ;CLEAR THE WRITE CHECK ERROR FLAG
3317 016122 013701 001510 MOV #FC,R1 ;PICKUP FIRST CYLINDER.
3318 016126 000407 BR 2$
3319 016130 005720 1$: TST (R0)+ ;MOVE TO NEXT DATA PATTERN
3320 016132 022700 000040 CMP #16.*2.,R0 ;OUT OF PATTERNS?
3321 016136 003004 BGT 3$ ;NO--BRANCH
3322 016140 004037 027600 JSR R0,#INCCYL ;MOVE TO NEXT CYLINDER
3323 016144 000530 BR EXIT20 ;OUT OF CYLINDERS
3324 016146 005000 2$: CLR R0 ;START WITH PATTERN 0

```

dlu

3325	016150	036037	001424	001530	3\$:	BIT	BITS(R0),@#PAT	: THIS PATTERN SELECTED?
3326	016156	071764				BEQ	1\$	: NO--BRANCH
3327	016160	013702	001516			MOV	@#FT,R2	: FIRST TRACK
3328	016164	010137	004176			MOV	R1,@#DTADPB+12	: CYLINDER
3329	016170	110237	004175		4\$:	MOV#	R2,@#DTADPB+11	: TRACK
3330	016174	010437	004170			MOV	R4,@#DTADPB+4	: WORD COUNT
3331	016200	023701	001512			CMP	1C,R1	: LAST DISK CYLINDER?
3332	016204	003005				BGT	5\$	: NO--BRANCH
3333	016206	022702	000022			CMP	#18.,R2	: LAST DISK TRACK?
3334	016212	003002				BGT	5\$	: NO--BRANCH
3335	016214	010537	004170			MOV	R5,@#DTADPB+4	: SHORT WORD COUNT
3336	016220	017703	162714		5\$:	MOV	@SWR,R3	: INHIBIT WRITE AND
3337	016224	005103				COM	R3	: WRITE CHECK?
3338	016226	032703	000030			BIT	#SW04!SW03,R3	
3339	016232	001436				BEQ	7\$	: YES--BRANCH
3340	016234	004737	030330			JSR	PC,@#SETBUF	: MOVE DATA PATTERN INTO THE BUFFER
3341	016240	032777	000020	162672		BIT	#SW04,@SWR	: INHIBIT WRITE?
3342	016246	001012				BNE	6\$	: YES--BRANCH
3343	016250	012737	016250	001110		MOV	#. SLPERR	: SETUP THE ERROR LOOP ADDRESS
3344	016256	012706	001100			MOV	#STACK,SP	: LOAD THE STACK POINTER
3345	016262	012737	000161	004166		MOV	#WRITE,@#DTADPB+2	: COMMAND=WRITE DATA
3346	016270	004037	025474			JSR	R0,@#DRVCAL	: START A DATA TRANSFER
3347	016274	032777	000010	162636	6\$:	BIT	#SW03,@SWR	: INHIBIT WRITE CHECK?
3348	016302	001012				BNE	7\$	: YES--BRANCH
3349	016304	012737	016304	001110		MOV	#. SLPERR	: SETUP THE ERROR LOOP ADDRESS
3350	016312	012706	001100			MOV	#STACK,SP	: LOAD THE STACK POINTER
3351	016316	012737	000151	004166		MOV	#RCKD,@#DTADPB+2	: COMMAND=WRITE CHECK DATA
3352	016324	004037	025474			JSR	R0,@#DRVCAL	: START A DATA TRANSFER
3353	016330	005737	001334		7\$:	TST	@#WCEFLG	: WRITE CHECK ERROR FLAG SET?
3354	016334	001404				BEQ	8\$	: NO--BRANCH
3355	016336	032777	000001	162574		BIT	#SW00,@SWR	: PERFORM READ AFTER FATAL "WCE"?
3356	016344	001424				BEQ	9\$	: NO--BRANCH
3357	016346	032777	000004	162564	8\$:	BIT	#SW02,@SWR	: INHIBIT READ DATA AND SOFTWARE COMPARE?
3358	016354	001020				BNE	9\$	: YES--BRANCH
3359	016356	012737	016356	001110		MOV	#. SLPERR	: SETUP THE ERROR LOOP ADDRESS
3360	016364	012706	001100			MOV	#STACK,SP	: LOAD THE STACK POINTER
3361	016370	012737	000171	004166		MOV	#READ,@#DTADPB+2	: COMMAND=READ
3362	016376	004037	025474			JSR	R0,@#DRVCAL	: START A DATA TRANSFER
3363	016402	032777	000002	162530		BIT	#SW01,@SWR	: COMPARE THE DATA?
3364	016410	001002				BNE	9\$	: NO--BRANCH
3365	016412	004737	030420			JSR	PC,@#DATCMP	: YES--DO IT
3366	016416	004037	027550		9\$:	JSR	R0,@#INCRK	: MOVE TO NEXT TRACK
3367	016422	000642				BR	1\$	: OUT OF TRACKS GO TO NEXT PATTERN
3368	016424	000661				BR	4\$	: LOOP
3369	016426	000004			EXIT20:	SCOPE		: SCOPE LOOP



3370  
3371  
3372  
3373  
3374  
3375  
3376  
3377  
3378  
3379  
3380  
3381  
3382  
3383  
3384  
3385  
3386  
3387  
3388  
3389  
3390  
3391  
3392  
3393  
3394  
3395  
3396  
3397  
3398  
3399  
3400  
3401  
3402  
3403  
3404  
3405  
3406  
3407  
3408  
3409  
3410  
3411  
3412  
3413  
3414  
3415  
3416  
3417  
3418  
3419  
3420  
3421  
3422  
3423  
3424  
3425

016430  
016430 000240  
016432 033737 001426 001236  
016440 001002  
016442 000137 017206  
016446 012737 000021 001102  
016454 004737 024560  
016460 012737 016700 001110  
016466 013777 001102 162446  
016474 013737 001506 001204  
016502 113737 001364 001115  
016510 012737 016510 001106  
016516 012737 017204 001252  
016524 012737 176543 023556  
016532 012737 123456 023560  
016540 013737 001510 004176  
016546 013737 001352 004170  
016554 012737 047662 004172  
016562 012737 000161 004166  
016570 032737 100000 001220  
016576 001027  
016600 004037 020736  
016604 005037 004174  
016610 012737 016610 001110  
016616 012706 001100  
016622  
016622 004037 025474  
016626 105237 004175

.SBTTL \*\*\* EXERCISE TEST \*\*\*  
:\*\*\*\*\*  
:TEST 21 RANDOM ADDRESS AND RANDOM PATTERN TEST  
: \* STARTING AT "FC" AND GOING THROUGH "LC" THE DISK PACK  
: \* IS WRITTEN WITH A RANDOM PATTERN. THE FIRST TWO WORDS  
: \* OF EACH SECTOR WILL BE THE BASE OF THE RANDOM GENERATOR  
: \* FOR THAT SECTOR.  
: \* THE TEST THEN PERFORMS THE FOLLOWING SEQUENCE "R" TIMES  
: \* "R" DEFAULTS TO 20,000.  
: \* 1) GENERATE A RANDOM ADDRESS  
: \* 2) WRITE A RANDOM PATTERN AT THE ADDRESS  
: \* GENERATED IN 1.  
: \* 3) GENERATE A RANDOM ADDRESS  
: \* 4) READ THE SECTOR AT THE ADDRESS  
: \* GENERATED IN 3.  
: \* 5) DO A SOFTWARE CHECK OF THE DATA READ IN 4.  
: \* 6) DO A WRITE CHECK OF THE DATA WRITTEN IN 2  
: \* 7) GENERATE A RANDOM ADDRESS  
: \* 8) READ THE SECTOR AT THE ADDRESS  
: \* GENERATED IN 7.  
: \* 9) DO A SOFTWARE CHECK OF THE DATA READ IN 8  
: \* 10) DO A WRITE CHECK OF THE DATA WRITTEN IN 2

:\*\*\*\*\*  
:TST21:  
NOP  
BIT BITS+(21\*2-40),TSTNMS+2 ;DO THIS TEST ?  
BNE 645 ;YES--BRANCH  
JMP TST22 ;NO--GO TO THE NEXT TEST  
MOV #21,2#STSTNM ;SET UP TEST NUMBER AND  
;CLEAR THE ERROR FLAG (SERFLG)  
JSR PC,LOOPRM ;LOAD THE PARAMETERS FOR THE TEST  
MOV #TST21,2#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS  
MOV #STSTNM,2#DISP1AY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER  
MOV #APT,2#TIMES ;GET THE ITERATION COUNT  
MOV #ERR,CT,2#ERRMAX ;MAX ERRORS ALLOWED FOR TEST  
MOV #,2#SLPERR ;SETUP THE LOOP ADDRESS  
MOV #EXIT21,2#BYPASS  
MOV #176543,2#SHIMUM ;PRIME THE RANDOM NUMBER GENERATOR  
MOV #123456,2#SLONUM  
MOV #FC,2#OTADPB+12 ;CYLINDER  
MOV #TRACK,2#OTADPB+4 ;WORD COUNT  
MOV #BUFFER,2#OTADPB+6 ;BUFFER ADDRESS  
MOV #WRITE,2#OTADPB+2 ;COMMAND  
BIT #SW15,2#C.SWR ;WRITE THE DISK PACK BEFORE TESTING?  
BNE 3\$ ;NO--BRANCH  
JSR RO,2#FILRAN ;FILL DATA BUFFER WITH RANDOM DATA  
CLR #OTADPB+10 ;SECTOR AND TRACK  
MOV #,2#SLPERR ;SETUP THE ERROR LOOP ADDRESS  
MOV #STACK,SP ;LOAD THE STACK POINTER  
JSR RO,2#DRVVAL ;START A DATA TRANSFER  
INCB #OTADPB+11 ;NEXT TRACK



```

3426 016632 122737 000023 004175      CMPB    #19.,#DTADPB+11 ;TIME FOR NEXT CYLINDER
3427 016640 003370                BGT     #0 ;NO--BRANCH
3428 016642 005237 004176      INC     #DTADPB+12
3429 016646 023737 001512 004176      CMP     #0, #DTADPB+12 ;OUT OF CYLINDERS?
3430 016654 002353                BGE     #0 ;NO--BRANCH
3431 016656 012737 177400 004170 3$:    MOV     #SCTRWC, #DTADPB+4 ;WORD COUNT
3432 016664 012737 016700 001106      MOV     #TEST21, #SLPADR
3433 016672 012737 016700 001110      MOV     #TEST21, #SLPERR
3434 016700 012706 001100      TEST21: MOV    #STACK, SP ;SET STACK POINTER
3435 016704 004037 031212      JSR     R0, #RANADR ;GENERATE A RANDOM ADDRESS
3436 016710 013737 004174 001340      MOV     #DTADPB+10, #SVADR ;SAVE THE TRACK/SECTOR
3437 016716 013737 004176 001342      MOV     #DTADPB+12, #SVADR+2 ;SAVE THE CYLINDER
3438 016724 012737 000161 004166      MOV     #WRITE, #DTADPB+2 ;COMMAND=WRITE DATA
3439 016732 012701 047662      MOV     #BUFFER, R1 ;BUFFER ADDRESS
3440 016736 010137 004172      MOV     R1, #DTADPB+6
3441 016742 004037 031156      JSR     R0, #RANPAT ;GENERATE RANDOM PATTERN
3442 016746 012737 016746 001110      MOV     #SLPERR ;SETUP THE ERROR LOOP ADDRESS
3443 016754 012706 001100      MOV     #STACK, SP ;LOAD THE STACK POINTER
3444 016760 004037 025474      JSR     R0, #DRVCL ;START A DATA TRANSFER
3445 016764 004037 031212      JSR     R0, #RANADR
3446 016770 012737 000171 004166      MOV     #READ, #DTADPB+2 ;COMMAND=READ DATA
3447 016776 012737 050662 004172      MOV     #BUFFER+512., #DTADPB+6 ;BUFFER ADDRESS
3448 017004 012737 017004 001110      MOV     #SLPERR ;SETUP THE ERROR LOOP ADDRESS
3449 017012 012706 001100      MOV     #STACK, SP ;LOAD THE STACK POINTER
3450 017016 004037 025474      JSR     R0, #DRVCL ;START A DATA TRANSFER
3451 01702 004037 030760      JSR     R0, #RANCK ;CHECK THE DATA
3452 017026 013737 001340 004174      MOV     #SVADR, #DTADPB+10 ;GET ADDRESS OF WHERE THE LAST
3453 017034 013737 001342 004176      MOV     #SVADR+2, #DTADPB+12 ;WRITE WAS PERFORMED
3454 017042 012737 000151 004166      MOV     #WCKD, #DTADPB+2 ;COMMAND=WRITE CHECK DATA
3455 017050 012737 047662 004172      MOV     #BUFFER, #DTADPB+6 ;DATA BUFFER ADDRESS
3456 017056 012737 017056 001110      MOV     #SLPERR ;SETUP THE ERROR LOOP ADDRESS
3457 017064 012706 001100      MOV     #STACK, SP ;LOAD THE STACK POINTER
3458 017070 004037 025474      JSR     R0, #DRVCL ;START A DATA TRANSFER
3459 017074 004037 031212      JSR     R0, #RANADR ;GENERATE A RANDOM ADDRESS
3460 017100 012737 000171 004166      MOV     #READ, #DTADPB+2 ;COMMAND=READ
3461 017106 012737 050662 004172      MOV     #BUFFER+512., #DTADPB+6 ;DATA BUFFER ADDRESS
3462 017114 012737 017114 001110      MOV     #SLPERR ;SETUP THE ERROR LOOP ADDRESS
3463 017122 012706 001100      MOV     #STACK, SP ;LOAD THE STACK POINTER
3464 017126 004037 025474      JSR     R0, #DRVCL ;START A DATA TRANSFER
3465 017132 004037 030760      JSR     R0, #RANCK ;CHECK THE DATA
3466 017136 013737 001342 004174      MOV     #SVADR, #DTADPB+10 ;GET DISK ADDRESS OF THE
3467 017144 013737 001342 004176      MOV     #SVADR+2, #DTADPB+12 ;LAST WRITE
3468 017152 012737 000151 004166      MOV     #WCKD, #DTADPB+2 ;COMMAND=WRITE CHECK DATA
3469 017160 012737 047662 004172      MOV     #BUFFER, #DTADPB+6 ;DATA BUFFER ADDRESS
3470 017166 012737 017166 001110      MOV     #SLPERR ;SETUP THE ERROR LOOP ADDRESS
3471 017174 012706 001100      MOV     #STACK, SP ;LOAD THE STACK POINTER
3472 017200 004037 025474      JSR     R0, #DRVCL ;START A DATA TRANSFER
3473 017204 000004      EXIT21: SCOPE ;LOOP ?

```

.SBTTL \*\*\* RPO4 ACCESS TIME ADJUSTMENT TEST \*\*\*

;;\*\*\*\*\*  
;#TEST 22 RPO4 ACCESS TIME ADJUSTMENT TEST

;; THIS TEST PERFORMS SEEKS BETWEEN CYLINDERS 0 & 136 TO ALLOW THE  
;# OPERATOR TO ADJUST THE ACCESS TIME ON AN RPO4 USING THE

3474  
3475  
3476  
3477  
3478  
3479  
3480  
3481

E06

;\* DOU THE PROGRAM STALLS APPROXIMATELY 5 SECONDS BETWEEN SEEKS  
;\* SO THAT THE ACCESS TIME INDICATORS ON THE DOU MAY BE OBSERVED.

\*\*\*\*\*

3518  
3519  
3520  
3521  
3522  
3523  
3524  
3525  
3526  
3527  
3528  
3529  
3530  
3531  
3532  
3533  
3534  
3535  
3536  
3537

017206  
017206 000240  
017210 033737 001430 001236  
017216 001032  
017220 000137 017356  
017224 012737 000022 001102  
017232 004737 024560  
017236 012737 017274 001110  
017244 013777 001102 161670  
017252 013737 001506 001204  
017260 112737 000144 001115  
017266 012737 017274 001106  
017274 012706 001100  
017300 013737 001512 004116  
017306 112737 000105 004106  
017314 004037 025002  
017320 004037 026334  
017324 001360  
017326 013737 001510 004116  
017334 112737 000105 004106  
017342 004037 025002  
017346 004037 026334  
017352 001360  
017354 000004

TST22:  
NOP  
BIT BITS+(22\*2-40), TSTNMS+2 ; DO THIS TEST ?  
BNE 645 ; YES--BRANCH  
JMP SEOP ; NO--GO TO THE END OF THE PROGRAM  
645: MOV #22, #STSTNM ; SET UP TEST NUMBER AND  
; CLEAR THE ERROR FLAG (SERFLG)  
JSR PC, LOOPRM ; LOAD THE PARAMETERS FOR THE TEST  
MOV #TST22, #SLPERR ; SETUP THE LOOP ON ERROR ADDRESS  
MOV STSTNM, #DISPLAY ; LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER  
MOV #RPT, \$TIMES ; GET THE ITERATION COUNT  
MOVB #100, \$ERMAX ; MAX ERRORS ALLOWED FOR TEST  
MOV #TST22, \$LPADR ; SETUP THE LOOP ADDRESS  
TEST22: MOV #STACK, SP ; SETUP THE STACK POINTER  
MOV LC, DPB, A+12 ; ENDING CYLINDER  
MOVB #SEEK, #DPB, A+2 ; SEEK=COMMAND  
JSR RO, #CALL, A ; GO EXECUTE THE COMMAND  
JSR RO, STALL ; STALL  
; ADDRESS OF STALL VALUE  
MOV FC, DPB, A+12 ; STARTING CYLINDER  
MOVB #SEEK, #DPB, A+2 ; SEEK=COMMAND  
JSR RO, #CALL, A ; GO EXECUTE THE COMMAND  
JSR RO, STALL ; STALL  
; ADDRESS OF STALL VALUE  
EXIT22: SCOPE ; LOOP ?

.SBTTL END OF PASS ROUTINE

\*\*\*\*\*  
;\* INCREMENT THE PASS NUMBER (\$PASS)  
;\* INDICATE END-OF-PROGRAM AFTER 8. PASSES THRU THE PROGRAM  
;\* IF THERES A MONITOR GO TO IT  
;\* IF THERE ISN'T JUMP TO RESTART

017356  
017356 104401 017364  
017362 000410  
017404  
017404 005737 001232  
017410 001434  
017412 104401 017420  
017416 000405  
017432  
017432 013746 001254  
017436 104403  
017440 002  
017441 000  
017442 104401 017450

SEOP:  
TYPE ,65\$ ; TYPE ASCIZ STRING  
BR 645 ; GET OVER THE ASCIZ  
65\$: .ASCIZ <CR><LF><LF>/END OF PASS/  
645:  
TST #DRVSEL ; ANY DRIVES SELECTED?  
BEQ 15 ; NO--BRANCH  
TYPE ,67\$ ; TYPE ASCIZ STRING  
BR 66\$ ; GET OVER THE ASCIZ  
67\$: .ASCIZ / ON DRIVE/  
66\$:  
MOV #CHKDRV, -(SP) ; SAVE #CHKDRV FOR TYPEOUT  
TYPOS ; GO TYPE--OCTAL ASCII  
.BYTE 2 ; TYPE 2 DIGIT(S)  
.BYTE 0 ; SUPPRESS LEADING ZEROS  
TYPE ,69\$ ; TYPE ASCIZ STRING

3538	017446	000412			BR	688	::GET OVER THE ASCIZ
3539					::698: .ASCIZ	/	ERRORS DETECTED=
3540	017474				688:		
3541	017474	013746	001112		MOV	2(SERTTL,-(SP)	::SAVE 2(SERTTL FOR TYPEOUT
3542	017500	104402			TYPOC		::GO TYPE--OCTAL ASCII(ALL DIGITS)
3543	017502	005037	001112		18:	CLR	2(SERTTL
3544	017505	005037	001102		CLR	\$STNM	::ZERO THE TEST NUMBER
3545	017512	005037	001204		CLR	\$TIMES	::ZERO THE NUMBER OF ITERATIONS
3546	017516	005237	001100		INC	\$PASS	::INCREMENT THE PASS NUMBER
3547	017522	042737	100000	001100	BIC	#100000,\$PASS	::DON'T ALLOW A NEG. NUMBER
3548	017530	005327			DEC	(PC)+	::LOOP?
3549	017532	000010			SEOPCT:	B.	
3550	017534	003027			BGT	\$DOAGN	::YES
3551	017536	012737			MOV	(PC)+,2(PC)+	::RESTORE COUNTER
3552	017540	000010			SENOCT:	B.	
3553	017542	017532			SEOPCT		
3554	017544	104401	017552		TYPE	658	::TYPE ASCIZ STRING
3555	017550	000407			JR	648	::GET OVER THE ASCIZ
3556					::658: .ASCIZ	(CR)<LF>/END OF	TEST/
3557	017570				648:		
3558	017570	104401	017620		TYPE	\$ENULL	::TYPE NULL CHARACTER
3559	017574	013700	000042		\$GET42:	2#42,R0	::GET MONITOR ADDRESS
3560	017600	001405			BEQ	\$DOAGN	::BRANCH IF NO MONITOR
3561	017602	000005			RESET		::CLEAR THE WORLD
3562	017604	004710			SENDAD:	JSR	PC,(R0)
3563	017606	000240			NOP		::GO TO MONITOR
3564	017610	000240			NOP		::SAVE ROOM
3565	017612	000240			NOP		::FOR
3566	017614				\$DOAGN:		::ACT11
3567	017614	000137			JMP	2(PC)+	::RETURN
3568	017616	006072			\$RTNAD:	.WORD	RESTART
3569	017620	377	377	000	\$ENULL:	.BYTE	-1,-1,0
3570		017624			.EVEN		::NULL CHARACTER STRING

```

3571
3572
3573
3574
3575
3576
3577
3578
3579
3580
3581
3582
3583
3584
3585
3586
3587
3588
3589 017624
3590 017624 104407
3591 017626 032777 000400 161304
3592 017634 001411
3593 017636 005737 001230
3594 017642 001406
3595 017644 013737 001420 001150
3596 017652 013737 001422 001152
3597 017660 105237 001103
3598 017664 001775
3599 017666 013777 001102 161246
3600 017674 032777 002000 161236
3601 017702 001402
3602 017704 104401 001210
3603 017710 005237 001112
3604 017714 011637 001116
3605 017720 162737 000002 001116
3606 017726 117737 161164 001114
3607 017734 032777 020000 161176
3608 017742 001004
3609 017744 004737 020032
3610 017750 104401 001215
3611 017754
3612 017754 005777 161160
3613 017760 100002
3614 017762 000000
3615 017764 104407
3616 017766 032777 001000 161144
3617 017774 001402
3618 017776 013716 001110
3619 020002 005737 001206
3620 020006 001402
3621 020010 013716 001206
3622 020014
3623 020014 013737 001414 001150
3624 020022 013737 001416 001152
3625 020030
3626 000002

```

.SBTTL \*\*\* SYSMAC SUBROUTINES \*\*\*

.SBTTL ERROR HANDLER ROUTINE

```

*****
*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
*AND GO TO TYPEERR ON ERROR
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW15=1 HALT ON ERROR
*SW13=1 INHIBIT ERROR TYPEOUTS
*SW10=1 BELL ON ERROR
*SW09=1 LOOP ON ERROR
*CALL
* ERROR N ;;ERROR=EMT AND N=ERROR ITEM NUMBER

```

\$ERROR:

```

CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
BIT #SW08, %SWR ;;SEND ERROR MESSAGE TO TTY?
BEQ 7$ YES--BRANCH
TST @LPTAVL ;;IS THERE A LINE PRINTER AVAILABLE?
BEQ 7$ NO--BRANCH
MOV @LPS, @STPS ;;YES--SETUP STATUS
MOV @LPB, @STPB ;;AND BUFFER REG.'S FOR LINE PRINTER
7$: INCB $ERFLG ;;SET THE ERROR FLAG
BEQ 7$ ;;DON'T LET THE FLAG GO TO ZERO
MOV $STNM, @DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
BIT #BIT10, %SWR ;;BELL ON ERROR?
BEQ 1$ NO - SKIP
TYPE $BELL ;;RING BELL
1$: INC $ERTTL ;;COUNT THE NUMBER OF ERRORS
MOV (SP), $ERRPC ;;GET ADDRESS OF ERROR INSTRUCTION
SUB #2, $ERRPC
MOVB @ERRPC, $ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
BIT #BIT13, %SWR ;;SKIP TYPEOUT IF SET
BNE 20$ ;;SKIP TYPEOUTS
JSR PC, TYPEERR ;;GO TO USER ERROR ROUTINE
TYPE $CRLF
20$:
2$: TST @SWR ;;HALT ON ERROR
BPL 3$ ;;SKIP IF CONTINUE
HALT ;;HALT ON ERROR!
CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
BIT #BIT09, %SWR ;;LOOP ON ERROR SWITCH SET?
BEQ 4$ BR IF NO
MOV $LPERR, (SP) ;;FLDGE RETURN FOR LOOPING
4$: TST $ESCAPE ;;CHECK FOR AN ESCAPE ADDRESS
BEQ 5$ BR IF NONE
MOV $ESCAPE, (SP) ;;FLDGE RETURN ADDRESS FOR ESCAPE
5$:
MOV @STPS, @STPS ;;SET STATUS AND BUFFER REG.'S
MOV @STPB, @STPB ;;FOR TTY
RTI ;;RETURN FROM ERROR CALL

```

;;\*\*\*\*\*

```

3627 .SBTTL TYPERR - TYPE ERROR ROUTINE
3628 ; THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE
3629 ; WHICH ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR
3630 ; TABLE" ($ERRTB), AND REPORTS THE APPROPRIATE INFORMATION
3631 ; CONCERNING THE ERROR.
3632 ; CALL
3633 ; JSR PC, @TYPERR
3634 ; RETURN
3635
3636 020032 113737 001102 001176 TYPERR: MOVB @#STSTNM, @#STMPO ; SAVE THE TEST NUMBER
3637 020040 104412 SAVREG ; SAVE R0 - R5
3638 020042 162700 000004 SUB #4, R0 ; FORM TEST PC
3639 020046 010037 001162 MOV R0, @#SREG0 ; COPY R0-R5 IN SREG0-SREG5
3640 020052 010137 001164 MOV R1, @#SREG1
3641 020056 010237 001166 MOV R2, @#SREG2
3642 020062 010337 001170 MOV R3, @#SREG3
3643 020066 010437 001172 MOV R4, @#SREG4
3644 020072 010537 001174 MOV R5, @#SREG5
3645 020076 113700 001114 MOVB @#ITEMB, R0 ; PICKUP ERROR ITEM NUMBER
3646 020102 010001 MOV R0, R1 ; AND COPY IT INTO R1
3647 020104 005300 DEC R0 ; FORM INDEX FOR ERROR TABLE
3648 020106 106300 ASLB R0
3649 020110 106300 ASLB R0
3650 020112 106300 ASLB R0
3651 020114 103002 BCC 1$ ; IS ERROR > 37?
3652 020116 062700 000240 ADD #ITEM41-$ERRTB, R0 ; YES--FORM OFFSET
3653 020122 062700 004306 1$: ADD #ERRTB, R0 ; FORM ADDRESS
3654 020126 012037 020142 MOV (R0)+, 2$ ; GET ERROR MESSAGE (EM) POINTER
3655 020132 001447 BEQ 7$ ; BRANCH IF THERE ISN'T ONE
3656 020134 104401 001215 TYPE , $CRLF ; "CARRIAGE RETURN - LINE FEED"
3657 020140 104401 TYPE
3658 020142 000000 2$: .WORD 0 ; "EM" POINTER GOES HERE
3659 020144 162701 000041 SUB #41, R1 ; SPECIAL ERROR ITEM NUMBER?
3660 020150 100440 BMI 7$ ; NO--BRANCH
3661 020152 013701 001260 MOV @#SVSTAT, R1 ; GET STATUS/ERROR INDICATOR
3662 020156 106301 ASLB R1 ; STRIP "DONE" BIT (BIT07)
3663 020160 006301 ASL R1 ; STRIP "ERROR" BIT (BIT15)
3664 020162 012702 004254 MOV #STATBL, R2 ; 1ST ADDRESS ON STATUS MESSAGE POINTERS
3665 020166 005003 CLR R3 ; CARRIAGE RETURN-LINE FEED SWITCH
3666 020170 104401 020176 TYPE , 65$ ; TYPE ASCIZ STRING
3667 020174 000402 BR 64$ ; GET OVER THE ASCIZ
3668 ; 65$: .ASCIZ / (/
3669 ; 64$:
3670 020202 012237 020224 3$: MOV (R2)+, 5$ ; MESSAGE POINTER
3671 020206 006301 ASL R1 ; TYPE THIS MESSAGE?
3672 020210 103013 BCC 6$ ; NO--BRANCH
3673 020212 005103 COM R3 ; YES--TYPE A "CR" & "LF"?
3674 020214 001002 BNE 4$ ; NO--BRANCH
3675 020216 104401 001215 TYPE , $CRLF ; YES
3676 020222 104401 4$: TYPE
3677 020224 000000 5$: .WORD 0 ; MESSAGE POINTER GOES HERE
3678 020226 005701 TST R1 ; MORE TO TYPE?
3679 020230 001403 BEQ 6$ ; NO--BRANCH
3680 020232 104401 044010 TYPE , MSG. SP ; YES--SPACES
3681 020236 000761 BR 3$ ; LOOP
3682 020240 001360 6$: BNE 3$ ; BRANCH IF NOT FINISHED

```

```

3683 020242 104401 020250          TYPE      67$      ;;TYPE ASCIZ STRING
3684 020246 000401                BR          66$      ;;GET OVER THE ASCIZ
3685                ;;67$: .ASCIZ  /)/
3686 020252 66$:
3687 020252 012037 020266          7$:  MOV      (R0)+,B$  ;PICK UP DATA HEADER (DH) POINTER
3688 020256 001404                BEQ          9$      ;BRANCH IF NONE
3689 020260 104401 001215          TYPE      ,SCRLF  ;CARRIAGE RETURN-LINE FEED
3690 020264 104401                TYPE
3691 020266 000000          8$:  .WORD      0      ;"DH" POINTER GOES HERE
3692 020270 012001          9$:  MOV      (R0)+,R1  ;PICKUP DATA TABLE (DT) POINTER
3693 020272 001450                BEQ          20$     ;BRANCH IF NONE
3694 020274 005005                CLR          R5      ;SET INDENT SWITCH
3695 020276 012000                MOV      (R0)+,R0  ;DATA FORMAT (DF) POINTER
3696 020300 012002                MOV      (R0)+,R2  ;NUMBER OF DH'S TO TYPE
3697 020302 001441                BEQ          17$     ;BRANCH IF DH NUMBER IS 0
3698 020304 005105                COM          R5      ;NO INDENT
3699 020306 104401 001215          TYPE      ,SCRLF  ;CARRIAGE RETURN-LINE FEED
3700 020312 112003          10$: MOV      (R0)+,R3  ;NUMBER OF DATA WORDS TO TYPE
3701 020314 112004                MOV      (R0)+,R4  ;AND HOW TO TYPE THEM
3702 020316 006004          11$: ROR          R4      ;OCTAL OR DECIMAL?
3703 020320 103403                BCS          12$     ;DECIMAL--BRANCH
3704 020322 013146                MOV      2(R1)+,-(SP) ;SAVE 2(R1)+ FOR TYPEOUT
3705 020324 104402                TYPDC
3706 020326 000402                BR          13$
3707 020330          12$:
3708 020330 013146                MOV      2(R1)+,-(SP) ;SAVE 2(R1)+ FOR TYPEOUT
3709 020332 104405                TYPDS
3710 020334 005303          13$: DEC          R3      ;GO TYPE--DECIMAL ASCII WITH SIGN
3711 020336 001403                BEQ          14$     ;MORE NUMBERS TO TYPE?
3712 020340 104401 044010          TYPE      ,MSG.SP  ;NO--BRANCH
3713 020344 000764                BR          11$     ;YES--TYPE SEPERATORS
3714 020346 005302          14$: DEC          R2      ;LOOP
3715 020350 003421                BLE          20$     ;MORE DH'S?
3716 020352 104401 001215          TYPE      ,SCRLF  ;NO--BRANCH
3717 020356 005105                COM          R5      ;YES--START A NEW LINE
3718 020360 001002                BNE          15$     ;INDENT?
3719 020362 104401 044010          TYPE      ,MSG.SP  ;NO--BRANCH
3720 020366 012037 020374          15$: MOV      (R0)+,16$ ;YES--TYPE SPACES
3721 020372 104401                TYPE
3722 020374 000000                .WORD      0      ;GET NEXT DH
3723 020376 104401 001215          TYPE      ,SCRLF  ;AND TYPE IT
3724 020402 005705                TST          R5      ;DH POINTER GOES HERE
3725 020404 001342                BNE          10$     ;CARRIAGE RETURN-LINE FEED
3726 020406 104401 044010          16$: TYPE      ,MSG.SP  ;INDENT?
3727 020412 000737                BR          10$     ;NO--BRANCH
3728 020414 104413                RESREG
3729 020416 000207                RTS          PC    ;YES--TYPE SPACES
                                ;LOOP
                                ;RESTORE R0 - R5
                                ;RETURN

```

.SBTTL TYPE ROUTINE

```

3730
3731
3732
3733 *****
3734 *ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
3735 *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
3736 *NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
3737 *NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
3738 *NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.

```

```

3739
3740
3741
3742
3743
3744
3745
3746
3747
3748 020420 105737 001157
3749 020424 100002
3750 020426 000000
3751 020430 000407
3752 020432 010046
3753 020434 017600 000002
3754 020440 112046
3755 020442 001005
3756 020444 005726
3757 020446 012600
3758 020450 062716 000002
3759 020454 000002
3760 020456 122716 000011
3761 020462 001430
3762 020464 122716 000200
3763 020470 001006
3764 020472 005726
3765 020474 104401
3766 020476 001215
3767 020500 105037 020634
3768 020504 000755
3769 020506 004737 020570
3770 020512 123726 001156
3771 020516 001350
3772 020520 013746 001154
3773
3774 020524 105366 000001
3775 020530 002770
3776 020532 004737 020570
3777 020536 105337 020634
3778 020542 000770
3779
3780
3781
3782 020544 112716 000040
3783 020550 004737 020570
3784 020554 132737 000007 020634
3785 020562 001372
3786 020564 005726
3787 020566 000724
3788 020570 105777 160354
3789 020574 100375
3790 020576 116677 000002 160346
3791 020604 122766 000015 000002
3792 020612 001003
3793 020614 105037 020634
3794 020620 000406

; *
; *CALL:
; *1) USING A TRAP INSTRUCTION
; * TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
; *OR
; * TYPE
; * MESADR
; *
STYPE: TSTB STPFLG ;; IS THERE A TERMINAL?
        BPL 15 ;; BR IF YES
        HALT ;; HALT HERE IF NO TERMINAL
        BR 35 ;; LEAVE
15: MOV RC, -(SP) ;; SAVE RO
        MOV 22(SP), RO ;; GET ADDRESS OF ASCIZ STRING
25: MOVB (RO)+, -(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
        BNE 45 ;; BR IF IT ISN'T THE TERMINATOR
        TST (SP)+ ;; IF TERMINATOR POP IT OFF THE STACK
605: MOV (SP)+, RO ;; RESTORE RO
35: ADD #2, (SP) ;; ADJUST RETURN PC
        RTI ;; RETURN
45: CMPB #HT, (SP) ;; BRANCH IF <HT>
        BEQ 85
        CMPB #CRLF, (SP) ;; BRANCH IF NOT <CRLF>
        BNE 55 ;; POP <CR><LF> EQUIV
        TST (SP)+ ;; TYPE ? CR AND LF
55: CLRB $CHARCNT ;; CLEAR CHARACTER COUNT
        BR 25 ;; GET NEXT CHARACTER
55: JSR PC, $TYPE^ ;; GO TYPE THIS CHARACTER
65: CMPB $FILLC, (SP)+ ;; IS IT TIME FOR FILLER CHARS.?
        BNE 25 ;; IF NO GO GET NEXT CHAR.
        MOV $NULL, -(SP) ;; GET # OF FILLER CHARS. NEEDED
        AND THE NULL CHAR.
75: DECB 1(SP) ;; DOES A NULL NEED TO BE TYPED?
        BLT 65 ;; BR IF NO--GO POP THE NULL OFF OF STACK
        JSR PC, $TYPE^ ;; GO TYPE A NULL
        DECB $CHARCNT ;; DO NOT COUNT AS A COUNT
        BR 75 ;; LOOP

; HORIZONTAL TAB PROCESSOR
85: MOVB #' (SP) ;; REPLACE TAB WITH SPACE
95: JSR PC, $TYPE^ ;; TYPE A SPACE
        BITB #7, $CHARCNT ;; BRANCH IF NOT AT
        BNE 95 ;; TAB STOP
        TST (SP)+ ;; POP SPACE OFF STACK
        BR 25 ;; GET NEXT CHARACTER
STYPEC: TSTB $STPS ;; WAIT UNTIL PRINTER IS READY
        BPL $TYPE^
        MOVB 2(SP), $STPB ;; LOAD CHAR TO BE TYPED INTO DATA REG.
        CMPB #CR, 2(SP) ;; IS CHARACTER A CARRIAGE RETURN?
        BNE 15 ;; BRANCH IF NO
        CLRB $CHARCNT ;; YES--CLEAR CHARACTER COUNT
        BR $TYPE^ ;; EXIT

```



3795 020622 122766 000012 000002 18:  
3796 020630 001402  
3797 020632 105227  
3798 020634 000000  
3799 020636 002207  
3800  
3801  
3802  
3803  
3804  
3805  
3806  
3807  
3808  
3809  
3810  
3811  
3812  
3813  
3814  
3815  
3816  
3817  
3818  
3819  
3820  
3821  
3822  
3823  
3824  
3825  
3826  
3827 020640 017646 000000  
3828 020644 116637 000001 021063  
3829 020652 112637 021065  
3830 020656 062716 000002  
3831 020662 000406  
3832 020664 112737 000001 021063  
3833 020672 112737 000006 021065  
3834 020700 112737 000005 021062  
3835 020706 010346  
3836 020710 010446  
3837 020712 010546  
3838 020714 113704 021065  
3839 020720 005404  
3840 020722 062704 000006  
3841 020726 110437 021064  
3842 020732 113704 021063  
3843 020736 016605 000012  
3844 020742 005003  
3845 020744 006105 18:  
3846 020746 000404  
3847 020750 006105 28:  
3848 020752 006105  
3849 020754 006105  
3850 020756 010503

CMPB #LF,2(SP) ;: IS CHARACTER A LINE FEED?  
BEQ \$TYPEX ;: BRANCH IF YES  
, INCB (PC)+ ;: COUNT THE CHARACTER  
\$CHARCNT: .WORD 0 ;: CHARACTER COUNT STORAGE  
\$TYPEX: RTS PC

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

\*\*\*\*\*  
\*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT  
\*OCTAL (ASCII) NUMBER AND TYPE IT.  
\*STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE  
\*CALL:  
\* MOV NUM,-(SP) ;: NUMBER TO BE TYPED  
\* TYPOS ;: CALL FOR TYPEOUT  
\* .BYTE N ;: N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE  
\* .BYTE M ;: M=1 OR 0  
\* ;: 1=TYPE LEADING ZEROS  
\* ;: 0=SUPPRESS LEADING ZEROS  
\*STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST  
\*STYPOS OR \$TYPOC  
\*CALL:  
\* MOV NUM,-(SP) ;: NUMBER TO BE TYPED  
\* TYPON ;: CALL FOR TYPEOUT  
\*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER  
\*CALL:  
\* MOV NUM,-(SP) ;: NUMBER TO BE TYPED  
\* TYPOC ;: CALL FOR TYPEOUT  
\*STYPOS: MOV 2(SP),-(SP) ;: PICKUP THE MODE  
\* MOV 1(SP),SOFILL ;: LOAD ZERO FILL SWITCH  
\* MOV (SP)+,SOMODE+1 ;: NUMBER OF DIGITS TO TYPE  
\* ADD #2,(SP) ;: ADJUST RETURN ADDRESS  
\* BR \$TYPON  
\*STYPOC: MOV #1,SOFILL ;: SET THE ZERO FILL SWITCH  
\* MOV #6,SOMODE+1 ;: SET FOR SIX(6) DIGITS  
\* MOV #7,SOCNT ;: SET THE ITERATION COUNT  
\* MOV R3,-(SP) ;: SAVE R3  
\* MOV R4,-(SP) ;: SAVE R4  
\* MOV R5,-(SP) ;: SAVE R5  
\* MOV \$SOMODE+1,R4 ;: GET THE NUMBER OF DIGITS TO TYPE  
\* NEG R4  
\* ADD #6,R4 ;: SUBTRACT IT FOR MAX. ALLOWED  
\* MOV R4,SOMODE ;: SAVE IT FOR USE  
\* MOV \$SOFILL,R4 ;: GET THE ZERO FILL SWITCH  
\* MOV 12(SP),R5 ;: PICKUP THE INPUT NUMBER  
\* CLR R3 ;: CLEAR THE OUTPUT WORD  
18: ROL R5 ;: ROTATE MSB INTO "C"  
BR 38 ;: GO DO MSB  
28: ROL R5 ;: FORM THIS DIGIT  
ROL R5  
MOV R5,R3

```

3851 020760 006103      3$:   ROL      R3      ;; GET LSB OF THIS DIGIT
3852 020762 105337 021064   DECB     $OMODE    ;; TYPE THIS DIGIT?
3853 020766 100016      BPL      7$      ;; BR IF NO
3854 020770 042703 177770   BIC      #177770,R3 ;; GET RID OF JUNK
3855 020774 001002      BNE      4$      ;; TEST FOR 0
3856 020776 005704      TST      R4      ;; SUPPRESS THIS 0?
3857 021000 001403      BEQ      5$      ;; BR IF YES
3858 021002 005204      4$:   INC      R4      ;; DON'T SUPPRESS ANYMORE 0'S
3859 021004 052703 000060   BIS      #'0,R3   ;; MAKE THIS DIGIT ASCII
3860 021010 052703 000040   5$:   BIS      #' ,R3 ;; MAKE ASCII IF NOT ALREADY
3861 021014 110337 021060   MOVB     R3,B$    ;; SAVE FOR TYPING
3862 021020 104401 021060   TYPE     B$      ;; GO TYPE THIS DIGIT
3863 021024 105337 021062   7$:   DECB     $OCNT  ;; COUNT BY 1
3864 021030 003347      BGT      2$      ;; BR IF MORE TO DO
3865 021032 002402      BLT      6$      ;; BR IF DONE
3866 021034 075204      INC      R4      ;; INSURE LAST DIGIT ISN'T A BLANK
3867 021036 000744      BR       2$      ;; GO DO THE LAST DIGIT
3868 021040 012605      6$:   MOV      (SP)+,R5 ;; RESTORE R5
3869 021042 012604      MOV      (SP)+,R4 ;; RESTORE R4
3870 021044 012603      MOV      (SP)+,R3 ;; RESTORE R3
3871 021046 016666 000002 003004   MOV      2(SP),4(SP) ;; SET THE STACK FOR RETURNING
3872 021054 012616      MOV      (SP)+,(SP)
3873 021056 000002      RTI      ;; RETURN
3874 021060 000      8$:   .BYTE    0      ;; STORAGE FOR ASCII DIGIT
3875 021061 000      .BYTE    0      ;; TERMINATOR FOR TYPE ROUTINE
3876 021062 000      $OCNT: .BYTE    0      ;; OCTAL DIGIT COUNTER
3877 021063 000      $OFILL: .BYTE   0      ;; ZERO FILL SWITCH
3878 021064 000000   $OMODE: .WORD    0      ;; NUMBER OF DIGITS TO TYPE

```

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

3882 *****
3883 *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
3884 *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
3885 *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
3886 *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
3887 *REPLACED WITH SPACES.
3888 *CALL:
3889 *   MOV      NUM,-(SP)      ;; PUT THE BINARY NUMBER ON THE STACK
3890 *   TYPDS      ;; GO TO THE ROUTINE
3891
3892 $TYPDS:
3893   MOV      R0,-(SP)      ;; PUSH R0 ON STACK
3894   MOV      R1,-(SP)      ;; PUSH R1 ON STACK
3895   MOV      R2,-(SP)      ;; PUSH R2 ON STACK
3896   MOV      R3,-(SP)      ;; PUSH R3 ON STACK
3897   MOV      R5,-(SP)      ;; PUSH R5 ON STACK
3898   MOV      #20200,-(SP)   ;; SET BLANK SWITCH AND SIGN
3899   MOV      20(SP),R5     ;; GET THE INPUT NUMBER
3900   BPL      1$          ;; BR IF INPUT IS POS.
3901   NEG      R5          ;; MAKE THE BINARY NUMBER POS.
3902   MOVB     #'-,1(SP)    ;; MAKE THE ASCII NUMBER NEG.
3903   1$:   CLR      R0      ;; ZERO THE CONSTANTS INDEX
3904   MOV      #0BLK,R3     ;; SETUP THE OUTPUT POINTER
3905   MOVB     #' ,(R3)+    ;; SET THE FIRST CHARACTER TO A BLANK
3906   2$:   CLR      R2      ;; CLEAR THE BCD NUMBER

```

# M06

```

3907 021136 016001 021272          MOV     $DTBL(R0),R1      ;; GET THE CONSTANT
3908 021142 160105          3$:    SUB     R1,R5        ;; FORM THIS BCD DIGIT
3909 021144 002402          BLT     4$,             ;; BR IF DONE
3910 021146 005202          INC     R2              ;; INCREASE THE BCD DIGIT BY 1
3911 021150 000774          BR     3$
3912 021152 060105          4$:    ADD     R1,R5        ;; ADD BACK THE CONSTANT
3913 021154 005702          TST     R2              ;; CHECK IF BCD DIGIT=0
3914 021156 001002          BNE     5$              ;; FALL THROUGH IF 0
3915 021160 105716          TSTB   (SP)            ;; STILL DOING LEADING 0'S?
3916 021162 100407          BMI     7$              ;; BR IF YES
3917 021164 106316          5$:    ASLB   (SP)        ;; MSD?
3918 021166 103003          BCC     6$              ;; BR IF NO
3919 021170 116663 000001 177777  MOVB   1(SP),-1(R3)      ;; YES--SET THE SIGN
3920 021176 052702 000060 6$:    BIS     #'0,R2        ;; MAKE THE BCD DIGIT ASCII
3921 021202 052702 000040 7$:    BIS     #' ',R2       ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
3922 021206 110223          MOVB   R2,(R3)+        ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
3923 021210 005720          TST   (R0)+           ;; JUST INCREMENTING
3924 021212 020027 000010 8$:    CMP     R0,#10        ;; CHECK THE TABLE INDEX
3925 021216 002746          BLT   2$              ;; GO DO THE NEXT DIGIT
3926 021220 003002          BGT   8$              ;; GO TO EXIT
3927 021222 010502          MOV   R5,R2           ;; GET THE LSD
3928 021224 000764          BR    6$              ;; GO CHANGE TO ASCII
3929 021226 105726          8$:    TSTB  (SP)+        ;; WAS THE LSD THE FIRST NON-ZERO?
3930 021230 100003          BPL   9$              ;; BR IF NO
3931 021232 116663 177777 177776 9$:    MOVB  -1(SP),-2(R3)   ;; YES--SET THE SIGN FOR TYPING
3932 021240 105013          CLRB  (R3)            ;; SET THE TERMINATOR
3933 021242 012605          MOV   (SP)+,R5        ;; POP STACK INTO R5
3934 021244 012603          MOV   (SP)+,R3        ;; POP STACK INTO R3
3935 021246 012602          MOV   (SP)+,R2        ;; POP STACK INTO R2
3936 021250 012501          MOV   (SP)+,R1        ;; POP STACK INTO R1
3937 021252 012500          MOV   (SP)+,R0        ;; POP STACK INTO R0
3938 021254 104401 021302          TYPE  $DBLK           ;; NOW TYPE THE NUMBER
3939 021260 016666 000002 000004 10$:   MOV   2(SP),4(SP)     ;; ADJUST THE STACK
3940 021266 012616          MOV   (SP)+,(SP)
3941 021270 000002          RTI
3942 021272 023420          $DTBL: 10000.
3943 021274 001750          1000.
3944 021276 000144          100.
3945 021300 000012          10.
3946 021302 000004          $DBLK: .BLKW 4
3947
3948
3949
3950          .TTL TTY INPUT ROUTINE
3951          ;; *****
3952 021312 000000          .ENABL LSB
3953 021314 000000          $TKCNT: .WORD 0      ;; NUMBER OF ITEMS IN QUEUE
3954 021316 000000          $TKQIN: .WORD 0     ;; INPUT POINTER
3955 021320 000002          $TKQOUT: .WORD 0    ;; OUTPUT POINTER
3956          $TKQSRT: .BLKB 2 ;; TTY KEYBOARD QUEUE
3957          $TKQEND=.
3958          ;; *TK INITIALIZE ROUTINE
3959          ;; *THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
3960          ;; *SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
3961          ;;
3962          ;; *CALL:
    
```

```

3963          ;*      JSR      PC,STKINT
3964          ;*      RETURN
3965
3966 021322 005037 021312      ;STKINT: CLR      STKCNT      ;; CLEAR COUNT OF ITEMS IN QUEUE
3967 021326 012737 021320 021314      MOV      #TKQSR,STKQIN ;; MOVE THE STARTING ADDRESS OF THE
3968 021334 013737 021314 021316      MOV      STKQIN,STKQOUT ;; QUEUE INTO THE INPUT & OUTPUT POINTERS.
3969 021342 012737 021372 000060      MOV      *TKSRV,STKVEC ;; INITIALIZE THE KEYBOARD VECTOR
3970 021350 012737 000200 000062      MOV      #0,STKVEC+2 ;; "BR" LEVEL 4
3971 021356 005777 157564      TST     -STKB      ;; CLEAR DONE FLAG
3972 021362 012777 000100 157554      MOV      #100,STKS   ;; ENABLE TTY KEYBOARD INTERRUPT
3973 021370 000207          RTS      PC      ;; RETURN TO CALLER
3974
3975          ;*TK SERVICE ROUTINE
3976          ;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
3977          ;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
3978          ;*IT IN THE QUEUE.
3979          ;*IF THE CHARACTER IS A "CONTROL-C" (1C) STKINT IS CALLED AND
3980          ;*UPON RETURN EXIT IS MADE TO THE "CONTROL-C" RESTART ADDRESS (START2)
3981
3982 021372 117746 157550      ;TKSRV: MOVB     STKB,-(SP) ;; PICKUP THE CHARACTER
3983 021376 042716 177600      BIC     #1C177,(SP) ;; STRIP THE JUNK
3984 021402 021627 000003      CMP     (SP),#3 ;; IS IT A CONTROL C?
3985 021406 001007          BNE     1$ ;; BRANCH IF NO
3986 021410 104401 022522      TYPE   $CNTLC ;; TYPE A CONTROL-C (1C)
3987 021414 004737 021322      JSR    PC,STKINT ;; INIT THE KEYBOARD
3988 021420 005726          TST     (SP)+ ;; CLEAN UP STACK
3989 021422 000137 004660      JMP    START2 ;; CONTROL C RESTART
3990 021426 021627 000007      1$:    CMP     (SP),#7 ;; IS IT A CONTROL G?
3991 021432 001004          BNE     2$ ;; BRANCH IF NO
3992 021434 022737 000176 001140      CMP     #SWREG,SWR ;; IS SOFT-SWR SELECTED?
3993 021442 001500          BEQ    6$ ;; GO TO SWR CHANGE
3994
3995          2$:
3996 021444 022737 000002 021312      CMP     #2,STKCNT ;; IS THE QUEUE FULL?
3997 021452 001004          BNE     3$ ;; BRANCH IF NO
3998 021454 104401 001210      TYPE   $BELL ;; RING THE TTY BELL
3999 021460 005726          TST     (SP)+ ;; CLEAN CHARACTER OFF OF STACK
4000 021462 000451          BR     5$ ;; EXIT
4001 021464 021627 000023      3$:    CMP     (SP),#23 ;; IS IT A CONTROL-S?
4002 021470 001021          BNE     32$ ;; BRANCH IF NO
4003 021472 005077 157446      CLR     STKS ;; DISABLE TTY KEYBOARD INTERRUPTS
4004 021476 005726          TST     (SP)+ ;; CLEAN CHAR OFF STACK
4005 021500 105777 157440      31$:   TSTB   STKS ;; WAIT FOR A CHAR
4006 021504 100375          BPL     31$ ;; LOOP UNTIL ITS THERE
4007 021506 117746 157434      MOVB   STKB,-(SP) ;; GET THE CHARACTER
4008 021512 042716 177600      BIC     #1C177,(SP) ;; MAKE IT 7-BIT ASCII
4009 021516 022627 000021      CMP     (SP)+,#21 ;; IS IT A CONTROL-Q?
4010 021522 001366          BNE     31$ ;; BRANCH IF NO
4011 021524 012777 000100 157412      MOV     #100,STKS ;; REENABLE TTY KEYBOARD INTERRUPTS
4012 021532 000002          RTI ;; RETURN
4013 021534 005237 021312      32$:   INC     STKCNT ;; COUNT THIS CHARACTER
4014 021540 021627 000140      CMP     (SP),#140 ;; IS IT UPPER CASE?
4015 021544 002405          BLT    4$ ;; BRANCH IF YES
4016 021546 021627 000175      CMP     (SP),#175 ;; IS IT A SPECIAL CHAR?
4017 021552 003002          BGT    4$ ;; BRANCH IF YES
4018 021554 042716 000040      BIC     #40,(SP) ;; MAKE IT UPPER CASE

```

```

4014 021560 112677 177530 48:   MOVB   (SP)+,STKQIN   ;; AND PUT IT IN QUEUE
4020 021564 005237 021314       INC    STKQIN         ;; UPDATE THE POINTER
4021 021570 023727 021314 021322   CMP    STKQIN,STKQEND ;; GO OFF THE END?
4022 021576 001003                BNE    55            ;; BRANCH IF NO
4023 021600 012737 021320 021314   MOV    STKQSR,STKQIN ;; RESET THE POINTER
4024 021606 000002                RTI                    ;; RETURN
4025
4026
4027
4028
4029
4030
4031 021610 022737 000176 001140 $CKSWR: CMP    #SWREG,SWR   ;; IS THE SOFT-SWR SELECTED
4032 021616 001124                BNE    155          ;; EXIT IF NOT
4033 021620 105777 157320       TSTB   STKS         ;; IS A CHAR WAITING?
4034 021624 100121                BPL    155          ;; IF NOT, EXIT
4035 021626 117746 157314       MOVB   STKB,-(SP)    ;; YES
4036 021632 042716 177600       BIC    #177,(SP)    ;; MAKE IT 7-BIT ASCII
4037 021636 021627 000007       CMP    (SP),#7      ;; IS IT A CONTROL-G?
4038 021642 001300                BNE    25           ;; IF NOT, PUT IT IN THE TTY QUEUE
4039
4040
4041
4042
4043
4044
4045 021644 123727 001134 000001 65:   CMPEB  SAUTOB,#1    ;; ARE WE RUNNING IN AUTO-MODE?
4046 021652 001674                BEQ    25           ;; BRANCH IF YES
4047 021654 005726                TST   (SP)+        ;; CLEAR CONTROL-G OFF STACK
4048 021656 014737 021322       JSR    PC,STKINT    ;; FLUSH THE TTY INPUT QUEUE
4049 021662 005077 157256       CLR    STKS        ;; DISABLE TTY KEYBOARD INTERRUPTS
4050 021666 112737 000001 001135   MOVB   #1,SINTAG    ;; SET INTERRUPT MODE INDICATOR
4051
4052 021674 104401 022534       TYPE   ,SCNTLG      ;; ECHO THE CONTROL-G (#G)
4053 021700 104401 022541       TYPE   SMSWR        ;; TYPE CURRENT CONTENTS
4054 021704 013746 000176       MOV    SWREG,-(SP)  ;; SAVE SWREG FOR TYPEOUT
4055 021710 104402                TYPOC                ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
4056 021712 104401 022552       TYPE   ,SNEW        ;; PROMPT FOR NEW SWR
4057 021716 005046       195:  CLR    -(SP)      ;; CLEAR COUNTER
4058 021720 005046                CLR    -(SP)        ;; THE NEW SWR
4059 021722 105777 157216       75:   TSTB   STKS        ;; CHAR THERE?
4060 021726 100375                BPL    75           ;; IF NOT TRY AGAIN
4061
4062 021730 117746 157212       MOVB   STKB,-(SP)  ;; PICK UP CHAR
4063 021734 042716 177600       BIC    #177,(SP)  ;; MAKE IT 7-BIT ASCII
4064
4065 021740 021627 000003                CMP    (SP),#3     ;; IS IT A CONTROL-C?
4066 021744 001015                BNE    95          ;; BRANCH IF NOT
4067 021746 104401 022522       TYPE   ,SCNTLC      ;; YES, ECHO CONTROL-C (#C)
4068 021752 062706 000006                ADD    #6,SP        ;; CLEAN UP STACK
4069 021756 123727 001135 000001   CMPEB  SINTAG,#1    ;; REENABLE TTY KEYBOARD INTERRUPTS?
4070 021764 001003                BNE    85          ;; BRANCH IF NO
4071 021766 012777 000100 157150   MOV    #100,STKS   ;; ALLOW TTY KEYBOARD INTERRUPTS
4072 021774 005137 004660       85:   JMP    START2      ;; CONTROL-C RESTART
4073
4074

```

```

4075 022000 021627 000025 95:  CMP (SP),#25  ;; IS IT A CONTROL-U?
4076 022004 001005  BNE 105  ;; BRANCH IF NO?
4077 022006 104401 032527  TYPE $CNTLU  ;; YES, ECHO CONTROL-U (!U)
4078 022012 062706 000006 205:  ADD #6,SP  ;; IGNORE PREVIOUS INPUT
4079 022016 000737  BR 195  ;; LET'S TRY IT AGAIN
4080
4081
4082 022020 021627 000015 105:  CMP (SP),#15  ;; IS IT A <CR.
4083 022024 001022  BNE 165  ;; BRANCH IF NO
4084 022026 005766 000004  TST 4(SP)  ;; YES, IS IT THE FIRST CHAR?
4085 022032 001403  BEQ 115  ;; BRANCH IF YES
4086 022034 016677 000002 157076  MOV 2(SP),@SWR  ;; SAVE NEW SWR
4087 022042 062706 000006 115:  ADD #6,SP  ;; CLEAR UP STACK
4088 022046 104401 001215 145:  TYPE $CNTLF  ;; ECHO <CR> AND <LF>
4089 022052 123727 001135 000001  CMPB $INTAG,#1  ;; RE-ENABLE TTY KBD INTERRUPTS?
4090 022060 001003  BNE 155  ;; BRANCH IF NOT
4091 022062 012777 000100 157054  MOV #100,@STKS  ;; RE-ENABLE TTY KBD INTERRUPTS
4092 022070 000002 155:  RTI  ;; RETURN
4093 022072 004737 020570 165:  JSR PC,$TYPEC  ;; ECHO CHAR
4094 022076 021627 000060  CMP (SP),#60  ;; CHAR < 0?
4095 022102 002420  BLT 185  ;; BRANCH IF YES
4096 022104 021627 000067  CMP (SP),#67  ;; CHAR > 7?
4097 022110 003015  BGT 185  ;; BRANCH IF YES
4098 022112 042726 000060  BIC #60,(SP)+  ;; STRIP-OFF ASCII
4099 022116 005766 000002  TST 2(SP)  ;; IS THIS THE FIRST CHAR
4100 022122 001403  BEQ 175  ;; BRANCH IF YES
4101 022124 006316  ASL (SP)  ;; NO, SHIFT PRESENT
4102 022126 006316  ASL (SP)  ;; CHAR OVER TO MAKE
4103 022130 006316  ASL (SP)  ;; ROOM FOR NEW ONE.
4104 022132 005266 000002 175:  INC 2(SP)  ;; KEEP COUNT OF CHAR
4105 022136 056616 177776  BIS -2(SP),(SP)  ;; SET IN NEW CHAR
4106 022142 000667  BR 75  ;; GET THE NEXT ONE
4107 022144 104401 001214 185:  TYPE $QUES  ;; TYPE ?<CR><LF>
4108 022150 000720  BR 205  ;; SIMULATE CONTROL-U
4109  .DSABL  L58

```

\*\*\*\*\*  
THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY  
\*CALL:

```

4110
4111
4112
4113
4114
4115  *      RDCHR  ;; GET A CHARACTER FROM THE QUEUE
4116  *      RETURN HERE  ;; CHARACTER IS ON THE STACK
4117  *  ;; WITH PARITY BIT STRIPPED OFF
4118
4119
4120  $RDCHR:  MOV (SP),-(SP)  ;; PUSH DOWN THE PC AND
4121  MOV 4(SP),2(SP)  ;; THE PS
4122  CLR 4(SP)  ;; GET READY FOR A CHARACTER
4123  CLR -(SP)  ;; PUT NEW PS ON STACK
4124  MOV #645,-(SP)  ;; PUT NEW PC ON STACK
4125  RTI  ;; POP NEW PC AND PS
4126
4127 645:  TST $STKCNT  ;; WAIT ON A CHARACTER
4128 15:  BEQ 15  ;;
4129  DEC $STKCNT  ;; DECREMENT THE COUNTER
4130 022210 117766 177102 0000J4  MOVB @STKQOUT,4(SP)  ;; GET ONE CHARACTER

```

```

4131 022216 005237 021316      INC      STKOUT      ; UPDATE THE POINTER
4132 022222 023727 021316 021322  CMP      STKOUT,#STKEND ; DID IT GO OFF OF THE END?
4133 022230 001003                BNE      2$          ; BRANCH IF NO
4134 022232 012737 021320 021316  MOV      #STKOSRT,STKOUT ; RESET THE POINTER
4135 022240 000002                RTI                    ; RETURN
4136                                     ; *****
4137                                     ; THIS ROUTINE WILL INPUT A STRING FROM THE TTY
4138                                     ; *CALL:
4139                                     ; *
4140                                     ; *   ROLIN
4141                                     ; *   RETURN HERE
4142                                     ; *
4143 022242 010346      SRDLIN: MOV      R3,-(SP)      ; SAVE R3
4144 022244 005046      CLR      -(SP)        ; CLEAR THE RUBOUT KEY
4145 022246 012703 022476 1$:  MOV      #STTYIN,R3    ; GET ADDRESS
4146 022252 021703 022522 2$:  CMP      #STTYIN+20.,R3 ; BUFFER FULL?
4147 022256 101456                BLOS     4$          ; BR IF YES
4148 022260 104410      ROCHR     ; GO READ ONE CHARACTER FROM THE TTY
4149 022262 112613      MOVB    (SP)+,(R3)   ; GET CHARACTER
4150 022264 122713 000177 10$:  CMPB    #177,(R3)    ; IS IT A RUBOUT
4151 022270 001022                BNE      5$          ; BR IF NO
4152 022272 005716      TST     (SP)        ; IS THIS THE FIRST RUBOUT?
4153 022274 001007                BNE      6$          ; BR IF NO
4154 022276 112737 000134 022474  MOVB    #'\\,9$      ; TYPE A BACK SLASH
4155 022304 104401 022474      TYPE    9$
4156 022310 012716 177777      MOV     #-1,(SP)    ; SET THE RUBOUT KEY
4157 022314 005303 6$:  DEC     R3          ; BACKUP BY ONE
4158 022316 020327 022476      CMP     R3,#STTYIN ; STACK EMPTY?
4159 022322 103434                BLOS     4$          ; BR IF YES
4160 022324 111337 022474      MOVB    (R3),9$     ; SETUP TO TYPEOUT THE DELETED CHAR.
4161 022330 104401 022474      TYPE    9$
4162 022334 000746                BR       2$          ; GO READ ANOTHER CHPR.
4163 022336 005716 5$:  TST     (SP)        ; RUBOUT KEY SET?
4164 022340 001406                BEQ     7$          ; BR IF NO
4165 022342 112737 000134 022474  MOVB    #'\\,9$      ; TYPE A BACK SLASH
4166 022350 104401 022474      TYPE    9$
4167 022354 005016      CLR     (SP)        ; CLEAR THE RUBOUT KEY
4168 022356 122713 000025 7$:  CMPE   #25,(R3)    ; IS CHARACTER A CTRL U?
4169 022362 001003                BNE      8$          ; BR IF NO
4170 022364 104401 022527      TYPE    #CNTLU     ; TYPE A CONTROL "U"
4171 022370 000726                BR       1$          ; GO START OVER
4172 022372 122713 000022 8$:  CMPB    #22,(R3)    ; IS CHARACTER A "R"?
4173 022376 001011                BNE      3$          ; BRANCH IF NO
4174 022400 105013      CLRB   (R3)        ; CLEAR THE CHARACTER
4175 022402 104401 001215      TYPE    #CRLF     ; TYPE A "CR" & "LF"
4176 022406 104401 022476      TYPE    #STTYIN   ; TYPE THE INPUT STRING
4177 022412 000717                BR       2$          ; GO PICKUP ANOTHER CHARACTER
4178 022414 104401 001214 4$:  TYPE    #QUES     ; TYPE A '?'
4179 022420 000712                BR       1$          ; CLEAR THE BUFFER AND LOOP
4180 022422 111337 022474 3$:  MOVB    (R3),9$     ; ECHO THE CHARACTER
4181 022426 104401 022474      TYPE    9$
4182 022432 122723 000015      CMPB    #15,(R3)+  ; CHECK FOR RETURN
4183 022436 001305                BNE      2$          ; LOOP IF NOT RETURN
4184 022440 105063 177777      CLRB   -(R3)       ; CLEAR RETURN (THE 15)
4185 022444 104401 001216      TYPE    #LF        ; TYPE A LINE FEED
4186 022450 005726                TST     (SP)+      ; CLEAN RUBOUT KEY FROM THE STACK

```



```

4187 022452 012603      MOV      (SP)+,R3      ;:RESTORE R3
4188 022454 011646      MOV      (SP)-(SP)    ;:ADJUST THE STACK AND PUT ADDRESS OF THE
4189 022456 016666 000004 000002      MOV      4(SP),2(SP) ;:FIRST ASCII CHARACTER ON IT
4190 022464 012766 022476 000004      MOV      @STTYIN,4(SP)
4191 022472 000002      RTI                    ;:RETURN
4192 022474 000      95: .BYTE 0           ;:STORAGE FOR ASCII CHAR. TO TYPE
4193 022476 000      .BYTE 0           ;:TERMINATOR
4194 022478 000024      STTYIN: .BLKB 20.    ;:RESERVE 20. BYTES FOR TTY INPUT
4195 022522 041536 005015 000      SCNTLC: .ASCIZ /1C/(15)<12> ;:CONTROL "C"
4196 022527 006525 000012      SCNTLU: .ASCIZ /1U/(15)<12> ;:CONTROL "U"
4197 022534 043536 005015 000      SCNTLG: .ASCIZ /1G/(15)<12> ;:CONTROL "G"
4198 022541 015      SMSMR: .ASCIZ <15><12>/SMR = /
4199 022546 036440 000040      SANEH: .ASCIZ / NEW = /
4200 022552 020040 042516 020127
4201 022560 020075 000
4202 022564      .EVEN
4203
4204      .SBTTL SCOPE HANDLER ROUTINE
4205
4206      ;:*****
4207      ;:THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
4208      ;:AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
4209      ;:AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
4210      ;:THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
4211      ;:SW14=1 LOOP ON TEST
4212      ;:SW11=1 INHIBIT ITERATIONS
4213      ;:SW09=1 LOOP ON ERROR
4214      ;:CALL
4215      ;:SCOPE ;:SCOPE=IOT
4216
4217 022564      $SCOPE:
4218 022564 104407      CKCHR
4219 022566 032777 040000 156344 15: BIT @BIT14,@SWR ;:TEST FOR CHANGE IN SOFT-SWR
4220 022574 001076      BNE $OVER ;:LOOP ON PRESENT TEST?
4221      ;:###START OF CODE FOR THE XOR TESTER###
4222 022576 000416      $XTSTR: BR 6$ ;:IF RUNNING ON THE "XOR" TESTER CHANGE
4223      ;:THIS INSTRUCTION TO A "NOP" (NOP=240)
4224 022600 013746 000004      MOV @BERRVEC,-(SP) ;:SAVE THE CONTENTS OF THE ERROR VECTOR
4225 022604 012737 022624 000004      MOV @BERRVEC ;:SET FOR TIMEOUT
4226 022612 005737 177060      TST @177060 ;:TIME OUT ON XOR?
4227 022616 012637 000004      MOV (SP)+,@BERRVEC ;:RESTORE THE ERROR VECTOR
4228 022622 000450      BR $SVLAD ;:GO TO THE NEXT TEST
4229 022624 022626      5$: CMP (SP)+,(SP)+ ;:CLEAR THE STACK AFTER A TIME OUT
4230 022626 012637 000004      MOV (SP)+,@BERRVEC ;:RESTORE THE ERROR VECTOR
4231 022632 000413      BR 7$ ;:LOOP ON THE PRESENT TEST
4232 022634      6$;###END OF CODE FOR THE XOR TESTER###
4233 022634 105737 001103      2$: TSTB $ERFLG ;:HAS AN ERROR OCCURRED?
4234 022640 001421      BEQ 3$ ;:BR IF NO
4235 022642 123737 001115 001103      CMPB $ERMAX,$ERFLG ;:MAX. ERRORS FOR THIS TEST OCCURRED?
4236 022650 101015      SHI 3$ ;:BR IF NO
4237 022652 032777 001000 156260      BIT @BIT09,@SWR ;:LOOP ON ERROR?
4238 022660 001404      BEQ 4$ ;:BR IF NO
4239 022662 013737 001110 001106      7$: MOV $LPERR,$LPADR ;:SET LOOP ADDRESS TO LAST SCOPE
4240 022670 000440      BR $OVER
4241 022672 105037 001103      4$: CLRB $ERFLG ;:ZERO THE ERROR FLAG
4242 022676 005037 001204      CLR $TIMES ;:CLEAR THE NUMBER OF ITERATIONS TO MAKE

```

```

4243 022702 000412          BR      1$          ;; ESCAPE TO THE NEXT TEST
4244 022704 032777 004000 156226 3$: BIT    @BIT11,@$AR  ;; INHIBIT ITERATIONS?
4245 022712 001006          BNE    1$          ;; BR IF YES
4246 022714 005237 001104          INC    $ICNT      ;; INCREMENT ITERATION COUNT
4247 022720 023737 001204 001104  CMP    $TIMES,$ICNT ;; CHECK THE NUMBER OF ITERATIONS MADE
4248 022726 002021          BGE    $OVER     ;; BR IF MORE ITERATION REQUIRED
4249 022730 012737 000001 001104 1$: MOV   @1,$ICNT   ;; REINITIALIZE THE ITERATION COUNTER
4250 022736 013737 023006 001204  MOV   $MXCNT,$TIMES ;; SET NUMBER OF ITERATIONS TO DO
4251 022744 105237 001102  $SVLAD: INCB  $STNM  ;; COUNT TEST NUMBERS
4252 022750 011637 001106          MOV   (SP),$LPADR ;; SAVE SC^PE LOOP ADDRESS
4253 022754 011637 001110          MOV   (SP),$LPERR ;; SAVE ERROR LOOP ADDRESS
4254 022760 005037 001206          CLR   $ESCAPE    ;; CLEAR THE ESCAPE FROM ERROR ADDRESS
4255 022764 112737 000001 001115  MOVB  @1,$ERMAX  ;; ONLY ALLOW ONE(1) ERROR ON NEXT TEST
4256 022772 013777 001102 156142 $OVER: MOV   $STNM,@DISPLAY ;; DISPLAY TEST NUMBER
4257 023000 013716 001106          MOV   $LPADR,(SP) ;; FUDGE RETURN ADDRESS
4258 023004 000002          RTI          ;; FIXES PS
4259 023006 000001          $MXCNT: 1      ;; MAX. NUMBER OF ITERATIONS

```

.SBTTL SAVE AND RESTORE RO-RS ROUTINES

```

4260
4261
4262
4263
4264
4265
4266
4267
4268
4269
4270
4271
4272
4273
4274
4275
4276
4277

```

```

*****
;SAVE RO-RS
;CALL:
; SAVREG
;UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
;
;TOP---(+16)
; +2---(+18)
; +4---R5
; +6---R4
; +8---R3
;+10---R2
;+12---R1
;+14---R0

```

```

4278 023010          $SAVREG:
4279 023010 010046          MOV   R0,-(SP)    ;; PUSH R0 ON STACK
4280 023012 010146          MOV   R1,-(SP)    ;; PUSH R1 ON STACK
4281 023014 010246          MOV   R2,-(SP)    ;; PUSH R2 ON STACK
4282 023016 010346          MOV   R3,-(SP)    ;; PUSH R3 ON STACK
4283 023020 010446          MOV   R4,-(SP)    ;; PUSH R4 ON STACK
4284 023022 010546          MOV   R5,-(SP)    ;; PUSH R5 ON STACK
4285 023024 016646 000022  MOV   22(SP),-(SP) ;; SAVE PS OF MAIN FLOW
4286 023030 016646 000022  MOV   22(SP),-(SP) ;; SAVE PC OF MAIN FLOW
4287 023034 016646 000022  MOV   22(SP),-(SP) ;; SAVE PS OF CALL
4288 023040 015646 000022  MOV   22(SP),-(SP) ;; SAVE PC OF CALL
4289 023044 000002          RTI

```

```

4290
4291
4292
4293
4294
4295
4296
4297
4298

```

```

; *RESTORE RO-RS
; *CALL:
; RESREG
$RESREG:
MOV   (SP)+,22(SP) ;; RESTORE PC OF CALL
MOV   (SP)+,22(SP) ;; RESTORE PS OF CALL
MOV   (SP)+,22(SP) ;; RESTORE PC OF MAIN FLOW
MOV   (SP)+,22(SP) ;; RESTORE PS OF MAIN FLOW

```

```

4299 023066 012605      MOV      (SP)+,R5      ;; POP STACK INTO R5
4300 023070 012604      MOV      (SP)+,R4      ;; POP STACK INTO R4
4301 023072 012603      MOV      (SP)+,R3      ;; POP STACK INTO R3
4302 023074 012602      MOV      (SP)+,R2      ;; POP STACK INTO R2
4303 023076 012601      MOV      (SP)+,R1      ;; POP STACK INTO R1
4304 023100 012600      MOV      (SP)+,R0      ;; POP STACK INTO R0
4305 023102 000002      RTI

```

.SBTTL TRAP DECODER

```

4307
4308
4309 ;; *****
4310 ;; *THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
4311 ;; *AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
4312 ;; *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
4313 ;; *GO TO THAT ROUTINE.
4314

```

```

4315 023104 010046      STRAP:  MOV      RO,-(SP)      ;; SAVE RO
4316 023106 016600 000002  MOV      2(SP),RO      ;; GET TRAP ADDRESS
4317 023112 005740      TST      -(RO)          ;; BACKUP BY 2
4318 023114 111000      MOV      (RO),RO        ;; GET RIGHT BYTE OF TRAP
4319 023116 006300      ASL      RO              ;; POSITION FOR INDEXING
4320 023120 016000 023140  MOV      STRPAD(RO),RO   ;; INDEX TO TABLE
4321 023124 000200      RTS      RO              ;; GO TO ROUTINE
4322
4323

```

;; THIS IS USE TO HANDLE THE "GETPRI" MACRO

```

4324
4325
4326 023126 011646      STRAP2: MOV      (SP),-(SP)  ;; MOVE THE PC DOWN
4327 023130 016666 000004 000002  MOV      4(SP),2(SP)    ;; MOVE THE PSM DOWN
4328 023136 000002      RTI                    ;; RESTORE THE PSM
4329
4330

```

.SBTTL TRAP TABLE

;; THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED  
;; BY THE "TRAP" INSTRUCTION.

	ROUTINE	
4331	ROUTINE	
4332	-----	
4333	STRPAD: .WORD STRAP2	
4334	\$TYPE	TRAP+1(104401) TTY TYPEOUT ROUTINE
4335	;;CALL=TYPE	
4336	\$TYPOC	TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
4337	;;CALL=TYPOC	
4338	\$TYPOS	TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
4339	;;CALL=TYPOS	
4340	\$TYPON	TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
4341	;;CALL=TYPON	
4342	\$TYPDS	TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
4343	;;CALL=TYPDS	
4344	\$GTSWR	TRAP+6(104406) GET SOFT-SWR SETTING
4345	;;CALL=GTSWR	
4346	\$CKSWR	TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
4347	;;CALL=CKSWR	
4348	\$RDCHR	TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
4349	;;CALL=RDCHR	
4350	\$ROLIN	TRAP+11(104411) TTY TYPEIN STRING ROUTINE
4351	;;CALL=ROLIN	
4352	\$SAVREG	TRAP+12(104412) SAVE RO-R5 ROUTINE
4353	;;CALL=SAVREG	
4354	\$RESREG	TRAP+13(104413) RESTORE RO-R5 ROUTINE
4355	;;CALL=RESREG	

.SBTTL SINGLE LENGTH BINARY TO DECIMAL ASCIZ ROUTINE

;; \*\*\*\*\*

# H07

```

4355 ;*THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
4356 ;*UNSIGNED DECIMAL ASCIZ NUMBER.
4357 ;*CALL
4358 ;*   MOV   NUMBER, -(SP)   ;; PUT BINARY NUMBER ON THE STACK
4359 ;*   JSR   PC, @$$S820    ;; CALL
4360 ;*   RETURN                ;; ADDRESS OF THE 1ST ASCIZ CHAR. IS ON THE STACK
4361
4362
4363 023170 016637 000002 023220 $$S820: MOV   2(SP), 1$   ;; SAVE BINARY NUMBER
4364 023176 012746 023220      MOV   @1$, -(SP)  ;; SET POINTER
4365 023202 004737 023224      JSR   PC, @$$S820  ;; CALL DOUBLE LENGTH CONVERT
4366 023206 062716 000005      ADD   @5, (SP)    ;; ONLY ALLOW FIVE CHARACTERS
4367 023212 012666 000002      MOV   (SP)+, 2(SP) ;; PICKUP POINTER
4368 023216 000207                RTS    PC          ;; RETURN
4369 023220 000000 000000      1$:   .WORD   0, 0
4370
4371 .SBTTL  DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE
4372
4373 ;*****
4374 ;*THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
4375 ;*DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
4376 ;*POSITIVE.
4377 ;*CALL
4378 ;*   MOV   @PNTR, -(SP)    ;; POINTER TO LOW WORD OF BINARY NUMBER
4379 ;*   JSR   PC, @$$S820    ;; THE FIRST ADDRESS OF ASCIZ
4380 ;*   RETURN                ;; IS ON THE STACK
4381
4382
4383
4384 023224 104412                $$S820: SAVREG    ;; SAVE REGISTERS
4385 023226 016602 000002      MOV   2(SP), R2    ;; PICKUP THE DATA POINTER
4386 023232 012700 023404      MOV   @SDECLV, R0  ;; GET ADDRESS OF "SDECLV" STRING
4387 023236 010056 000002      MOV   R0, 2(SP)   ;; PUT ADDRESS OF ASCIZ STRING ON STACK
4388 023242 012201                MOV   (R2)+, R1    ;; PICKUP THE BINARY NUMBER
4389 023244 012202                MOV   (R2)+, R2
4390 023246 012737 000012 023322      MOV   @10, 4$     ;; SET UP TO DO 10 CONVERSIONS
4391 023254 012704 023334      MOV   @STNPNR, R4  ;; ADDRESS OF TEN POWER
4392 023260 012705 023336      MOV   @STNPNR+2, R5
4393 023264 005003                1$:   CLR   R3          ;; CLEAR PARTIAL
4394 023266 161401                2$:   SUB   (R4), R1    ;; SUBTRACT TEN POWER
4395 023270 005602                SBC   R2
4396 023272 161502                SUB   (R5), R2
4397 023274 002402                BLT   3$          ;; BR IF TEN POWER TO LARGE
4398 023276 005203                INC   R3          ;; ADD 1 TO PARTIAL
4399 023300 000772                BR    2$         ;; LOOP
4400 023302 062401                3$:   ADD   (R4)+, R1  ;; RESTORE SUBTRACTED VALUE
4401 023304 005502                ADC   R2
4402 023306 062402                ADD   (R4)+, R2
4403 023310 022525                CMP   (R5)+, (R5)+ ;; MOVE TO NEXT TEN POWER
4404 023312 052703 000060      BIS   @'0, R3     ;; CHANGE PARTIAL TO ASCII
4405 023316 110320                MOVB  R3, (R0)+   ;; SAVE IT
4406 023320 005327                DEC   (PC)+       ;; DONE?
4407 023322 000000                4$:   .WORD   0
4408 023324 001357                BNE   1$         ;; BR IF NO
4409 023326 105020                CLRB  (R0)+      ;; TERMINATOR
4410 023330 104413                RESREG    ;; RESTORE REGISTERS

```

4411 023332 000207  
4412 023334 145000  
4413 023336 035632  
4414 023340 160400  
4415 023342 002765  
4416 023344 113200  
4417 023346 000230  
4418 023350 041100  
4419 023352 000017  
4420 023354 103240  
4421 023356 000001  
4422 023360 023420  
4423 023362 000000  
4424 023364 001750  
4425 023366 000000  
4426 023370 000144  
4427 023372 000000  
4428 023374 000012  
4429 023376 000000  
4430 023400 000001  
4431 023402 000000  
4432 023404 000014  
4433  
4434  
4435  
4436  
4437  
4438  
4439  
4440  
4441  
4442  
4443  
4444 023420 010046  
4445 023422 016600 000004  
4446 023426 105710  
4447 023430 001403  
4448 023432 122720 000060  
4449 023436 001773  
4450 023440 005300  
4451 023442 010337 023450  
4452 023446 104401  
4453 023450 000000  
4454 023452 012600  
4455 023454 012616  
4456 023456 000207  
4457  
4458  
4459  
4460  
4461  
4462  
4463  
4464  
4465  
4466

RTS PC ;; RETURN  
STNPR: 145000 ;; 1.0E09  
35632  
160400 ;; 1.0E08  
2765  
113200 ;; 1.0E07  
230  
041100 ;; 1.0E06  
17  
103240 ;; 1.0E05  
1  
23420 ;; 1.0E04  
0  
1750 ;; 1.0E03  
0  
144 ;; 1.0E02  
0  
12 ;; 1.0E01  
0  
1 ;; 1.0E00  
0  
\$DECVL: .BLKB 12. ;; RESERVE STORAGE FOR ASCIZ STRING

.SBTTL TYPE NUMERICAL ASCIZ STRING SUPPRESS LEADING ZEROS  
\*\*\*\*\*  
\*THIS ROUTINE IS USED TO TYPE AN ASCIZ NUMBER SUPPRESSING THE  
\*LEADING NUMBERS.  
\*CALL  
\* MOV #NUMADR, -(SP) ;; FIRST ADDRESS OF ASCIZ STRING  
\* JSR PC, @SSUPRS  
SSUPRS: MOV RO, -(SP) ;; SAVE RO  
MOV 4(SP), RO ;; PICKUP THE POINTER  
1\$: TSTB (RO) ;; TERMINATE OR?  
BEQ 2\$ BR IF YES  
CMPB #'0, (RO)+ ;; IS THIS AN ASCII "0" ?  
BEQ 1\$ BR IF YES  
2\$: DEC RO ;; BACKUP BY "1"  
MOV RO, 3\$ ;; SAVE FOR TYPING  
TYPE GO TYPE  
3\$: .WORD 0 ;; ASCIZ POINTER GOES HERE  
MOV (SP)+, RO ;; RESTORE RO  
MOV (SP)+, (SP) ;; RESTORE THE STACK  
RTS PC ;; RETURN

.SBTTL RANDOM NUMBER GENERATOR ROUTINE  
\*\*\*\*\*  
\*THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR  
\*WITH A RANGE OF 0 TO 2(+33)-1.  
\*CALL:  
\* JSR PC, \$RAND ;; CALL THE ROUTINE  
\* RETURN ;; RETURN HERE THE RANDOM  
\* ;; NUMBER WILL BE IN

4467  
4468  
4469 023460  
4470 023461 010046  
4471 023462 010146  
4472 023464 010246  
4473 023466 013700 023560  
4474 023472 013701 023556  
4475 023476 012702 177771  
4476 023502 006300  
4477 023504 006101  
4478 023506 005202  
4479 023510 001374  
4480 023512 063700 023560  
4481 023516 005501  
4482 023520 063701 023556  
4483 023524 062700 001057  
4484 023530 005501  
4485 023532 062701 047401  
4486 023536 010037 023560  
4487 023542 010137 023556  
4488 023546 012602  
4489 023550 012601  
4490 023552 012600  
4491 023554 000207  
4492 023556 176543  
4493 023560 123456

```
;* ;;SHINUM,SLONUM
SRAND:
      MOV    RO,-(SP)      ;; PUSH RO ON STACK
      MOV    R1,-(SP)      ;; PUSH R1 ON STACK
      MOV    R2,-(SP)      ;; PUSH R2 ON STACK
      MOV    SLONUM,RO     ;; SET RO WITH LOW
      MOV    SHINUM,R1     ;; SET R1 WITH HIGH
      MOV    #7,R2        ;; SET SHIFT COUNT
IS:   ASL    RO            ;; SHIFT RO LEFT AND
      ROL    R1            ;; ROTATE CARRY INTO R1 AND
      INC    R2            ;; CHECK FOR DONE
      BNE    IS           ;; CONTINUE SHIFT LOOP
      ADD    SLONUM,RO     ;; ADD NUMBER TO MAKE X 129
      ADC    R1            ;; PROPOGATE CARRY
      ADD    SHINUM,R1     ;; ADD NUMBER TO MAKE X 129
      ADD    #1057,RO     ;; ADD LOW CONSTANT
      ADC    R1            ;; PROPOGATE CARRY
      ADD    #47401,R1    ;; ADD HIGH CONSTANT
      MOV    RO,SLONUM    ;; SAVE RO
      MOV    R1,SHINUM    ;; SAVE R1
      MOV    (SP)+,R2     ;; POP STACK INTO R2
      MOV    (SP)+,R1     ;; POP STACK INTO R1
      MOV    (SP)+,RO     ;; POP STACK INTO RO
      RTS    PC           ;; RETURN
SHINUM: .WORD 176543
SLONUM: .WORD 123456
```

.SBTTL INTEGER DIVIDE ROUTINE

4494  
4495  
4496  
4497  
4498  
4499  
4500  
4501  
4502  
4503  
4504  
4505  
4506  
4507  
4508  
4509  
4510  
4511  
4512  
4513  
4514  
4515  
4516  
4517  
4518  
4519  
4520 023562  
4521 023562 104400  
4522 023564 042716 000017

```
*****
*THIS ROUTINE WILL DIVIDE A 32-BIT TWO'S COMPLEMENT INTEGER
*DIVIDEND BY A 16-BIT TWO'S COMPLEMENT INTEGER DIVISOR GIVING
* A 16-BIT TWO'S COMPLEMENT INTEGER QUOTIENT AND A 16-BIT REMAINDER.
*DIVISION WILL BE PERFORMED SO THAT THE REMAINDER IS OF THE
*SAME SIGN AS THE DIVIDEND.
*CALL:
*   MOV    LOW DIVIDEND,-(SP) ;; THE HIGH DIVIDEND MUST BE < 1/2
*   MOV    HIGH DIVIDEND,-(SP); AS LARGE AS THE DIVISOR
*   MOV    DIVISOR,-(SP)
*   JSR    PC,SDIV
*   RETURN ;; QUOTIENT & REMAINDER ARE ON THE STACK
*   "V"=0  IMPLIES NO ERROR
*   "V"=1  IMPLIES ERROR OCCURRED
*   "C"=0  DIVIDE OVERFLOW OCCURRED
*   "C"=1  ATTEMPTED TO DIVIDE BY ZERO
*
*   STACK  NO ERROR      OVERFLOW      DIVIDE BY ZERO
*   -----
*   TOP    REMAINDER     ALL ZEROS   ALL ONES
*   +2     QUOTIENT      ALL ZEROS   ALL ONES
*
SDIV:  TRAP
      BIC    #17,(SP)    ;; PUSH OLD PSW AND PC ON STACK
      ;; STRIP AWAY CONDITION CODES
```

4523	023570	010046		MOV	RO, -(SP)	:: PUSH RO ON STACK	
4524	023572	010146		MOV	R1, -(SP)	:: PUSH R1 ON STACK	
4525	023574	010246		MOV	R2, -(SP)	:: PUSH R2 ON STACK	
4526	023576	010346		MOV	R3, -(SP)	:: PUSH R3 ON STACK	
4527	023600	005046		CLR	-(SP)	:: SAVE A PLACE FOR SIGNS	
4528	023602	012746	000021	MOV	#17, -(SP)	:: SETUP THE ITERATION COUNTER	
4529	023606	016601	000024	MOV	24(SP), R1	:: PICKUP THE DIVIDEND	
4530	023612	016600	000022	MOV	22(SP), RO		
4531	023616	100005		BPL	1\$	:: CHECK THE SIGN	
4532	023620	105366	000003	DECB	3(SP)	:: KEEP TRACK OF THE SIGN	
4533	023624	005400		NEG	RO	:: AND NEGATE THE ORIGINAL	
4534	023626	005401		NEG	R1	:: NUMBER	
4535	023630	005600		SBC	RO		
4536	023632	016602	000020	1\$:	MOV	20(SP), R2	:: PICKUP THE DIVISOR
4537	023636	002407		BLT	2\$	:: CHECK THE SIGN	
4538	023640	003011		BGT	3\$	:: DIVISOR OF 0 IS A NO-NO	
4539	023642	052766	000003 000014	BIS	#3, 14(SP)	:: SET "V" & "C"	
4540	023650	012700	177777	MOV	#-1, RO	:: SET REMAINDER TO ALL ONES	
4541	023654	000424		BR	7\$	:: EXIT	
4542	023656	005266	000002	2\$:	INC	2(SP)	:: KEEP TRACK OF DIVISORS SIGN
4543	023662	000401		BR	4\$		
4544	023664	005402		3\$:	NEG	R2	:: NEGATE THE ORIGINAL NUMBER
4545	023666	000241		4\$:	CLC		:: CLEAR "C"
4546	023670	000405		BR	6\$		:: START FORMING QUOTIENT
4547	023672	006100		5\$:	ROL	RO	:: POSITION MSB'S
4548	023674	010003		MOV	RO, R3	:: COPY	
4549	023676	060203		ADD	R2, R3	:: COMPARE DIVIDEND & DIVISOR	
4550	023700	103001		BCC	6\$	:: BR IF DIVIDEND > DIVISOR	
4551	023702	010300		MOV	R3, RO	:: REMAINDER AFTER THIS LOOP	
4552	023704	006111		6\$:	ROL	R1	:: QUOTIENT BIT ENTERS HERE
4553	023706	005316		DEC	(SP)	:: DONE?	
4554	023710	001370		BNE	5\$	:: BR IF NO	
4555	023712	005701		TST	R1	:: OVERFLOW?	
4556	023714	100005		BPL	8\$	:: BR IF NO	
4557	023716	052766	000002 000014	BIS	#2, 14(SP)	:: SET "V" IN RETURN STATUS WORD	
4558	023724	005000		CLR	RO	:: SET REMAINDER TO ALL ZEROS	
4559	023726	010001		7\$:	MOV	RO, R1	:: COPY REMAINDER INTO QUOTIENT
4560	023730	005726		8\$:	TST	(SP)+	:: CLEAR COUNTER FROM STACK
4561	023732	005716		TST	(SP)	:: REMAINDER SIGN CORRECTION NEEDED?	
4562	023734	002004		BGE	9\$	:: BR IF NO	
4563	023736	005400		NEG	RO	:: NEGATE REMAINDER	
4564	023740	105066	000001	CLRB	1(SP)	:: CLEAR SIGN	
4565	023744	005316		DEC	(SP)	:: BUT DON'T FORGET QUOTIENT	
4566	023746	005726		9\$:	TST	(SP)+	:: QUOTIENT SIGN CORRECTION NEEDED?
4567	023750	001401		BEQ	10\$	:: BR IF NO	
4568	023752	005401		NEG	R1	:: NEGATE QUOTIENT	
4569	023754	010166	000020	10\$:	MOV	R1, 20(SP)	:: RETURN QUOTIENT AND
4570	023760	010066	000016	MOV	RO, 16(SP)	:: REMAINDER TO USER	
4571	023764	012603		MOV	(SP)+, R3	:: POP STACK INTO R3	
4572	023766	012602		MOV	(SP)+, R2	:: POP STACK INTO R2	
4573	023770	012601		MOV	(SP)+, R1	:: POP STACK INTO R1	
4574	023772	012600		MOV	(SP)+, RO	:: POP STACK INTO RO	
4575	023774	012666	000002	MOV	(SP)+, 2(SP)	:: SETUP TO RETURN CONDITION CODES	
4576	024000	000002		RTI		:: RETURN	
4577							
4578							

.SBTTL \*\*\* PROGRAM SUBROUTINES \*\*\*





```

4635 024154 001407          BEQ      4$          ;BRANCH IF 60
4636 024156 012737 000020 001246    MOV      #20, @TICKMS ;SETUP TIME PER
4637 024164 012737 047040 001250    MOV      #20000., @TICKUS ;TICK FOR 50HZ
4638 024172 000406          BR       5$
4639 024174 012737 000016 001246    4$: MOV    #16, @TICKMS ;SETUP TIME PER
4640 024202 012737 040432 001250    MOV    #16666., @TICKUS ;TICK FOR 60HZ
4641 024210 000207          5$: RTS      PC          ;RETURN
4642
4643 024212          ST.PCLK:
4644 024212 032737 000040 001220    BIT     #SW05, @C.SWR ;ALLOW SOFTWARE TIMEOUTS?
4645 024220 001014          BNE     1$          ;NO--BRANCH
4646 024222 012777 024310 155144    MOV     #SRVCLK, @PKV ;SETUP THE KW11-P VECTOR
4647 024230 012777 000300 155140    MOV     #300, @PKV+2
4648 024236 012777 000001 155136    MOV     #1, @PKB      ;COUNT ONE TICK
4649 024244 012777 000115 155126    MOV     #115, @PKCS  ;"INT.EN." COUNT DOWN, "MODE 1 (REPEAT)",
4650                                     ;"LINE FREQ", AND "RUN"
4651 024252 000207          1$: RTS      PC          ;RETURN
4652
4653 024254          ST.LCLK:
4654 024254 032737 000040 001220    BIT     #SW05, @C.SWR ;ALLOW SOFTWARE TIMEOUTS?
4655 024262 001011          BNE     1$          ;NO--BRANCH
4656 024264 012777 024310 155114    MOV     #SRVCLK, @LKV ;SETUP THE KW11-L VECTOR
4657 024272 012777 000300 155110    MOV     #300, @LKV+2
4658 024300 012777 000100 155104    MOV     #100, @LKS   ;START THE KW11-L
4659 024306 000207          1$: RTS      PC          ;RETURN
4660
4661 024310 013746 001246          SRVCLK: MOV    @TICKMS, -(SP) ;TIME PER TICK IN MILLISECONDS
4662 024314 004737 040704          JSR    PC, @RPTMR    ;COUNT THE ELAPSED TIME
4663 024320 000002          RTI                    ;RETURN AFTER INTERRUPT
4664
4665                                     ;THIS ROUTINE SETS UP DEFAULT PARAMETER VALUES WHEN THE PROGRAM IS
4666                                     ;STARTED OR WHEN THE VALUE OF BIT00 IN 'C.SWR' IS CHANGED.
4667                                     ;CALL
4668                                     ; JSR    PC, LODFLT
4669                                     ; RETURN
4670
4671                                     LODFLT:
4672 024322 010046          MOV     R0, -(SP)    ;: PUSH R0 ON STACK
4673 024324 010146          MOV     R1, -(SP)    ;: PUSH R1 ON STACK
4674 024326 010246          MOV     R2, -(SP)    ;: PUSH R2 ON STACK
4675 024330 010346          MOV     R3, -(SP)    ;: PUSH R3 ON STACK
4676 024332 012737 176777 001234    MOV     #176777, TSTNMS ;SELECT TESTS 0-10, 12-17
4677 024340 012737 000001 001236    MOV     #1, TSTNMS+2 ;SET SELECT BIT FOR TEST 20
4678 024346 012700 001664          MOV     #DFLT, R0    ;DEFAULT PARAMETERS POINTER
4679 024352 012701 002330          MOV     #PRMO, R1    ;TABLE POINTER
4680 024356 010102          MOV     R1, R2      ;STOP ADDRESS
4681 024360 012021          1$: MOV    (R0)+, (R1)+ ;MOVE DEFAULT PARAMETERS INTO
4682 024362 020002          CMP    R0, R2      ;RUN TIME TABLES ** DONE?
4683 024364 103775          BLO    1$          ;NO--BRANCH
4684 024366 012700 003504          MOV     #PAT8, R0    ;PATO DEFAULTS TO PATTERN 8
4685 024372 012701 003104          MOV     #PATO, R1
4686 024376 012021          2$: MOV    (R0)+, (R1)+
4687 024400 020027 003744          CMP    R0, #PAT9
4688 024404 103774          BLO    2$
4689 024406 032737 000001 001220    BIT     #BIT00, C.SWR ;: 16 BIT MODE ?
4690 024414 001012          BNE    3$          ;BR IF 18

```

```

4691 024416 012737 000025 001630      MOV      #21.,PRMLMT+22 ;SET 'FS' LIMIT TO 21.
4692 024424 012737 000025 001632      MOV      #21.,PRMLMT+24 ;SET 'LS' LIMIT TO 21.
4693 024432 012737 165000 001352      MOV      #-(256.*22.),TRCKWC ;WORD COUNT FOR A 16 BIT TRACK
4694 024440 000411                BR        4$ ;CONTINUE
4695 024442 012737 000023 001630 3$:      MOV      #19.,PRMLMT+22 ;SET 'FS' LIMIT TO 19.
4696 024450 012737 000023 001632      MOV      #19.,PRMLMT+24 ;SET 'LS' LIMIT TO 19.
4697 024456 012737 166000 001352      MOV      #-(256.*20.),TRCKWC ;WORD COUNT FOR AN 18 BIT TRACK
4698 024464 012701 001536                4$:      MOV      #PRMPT,R1 ;ADDRESS OF PARAMETER POINTER TABLE
4699 024470 005711                5$:      TST      (R1) ;END OF THE TABLE ?
4700 024472 001425                BEQ      8$ ;BR IF END
4701 024474 032731 002000                BIT      #BIT10,2(R1)+ ;'LS' SELECTED ?
4702 024500 001773                BEQ      5$ ;BR IF NOT
4703 024502 016102 177776                MOV      -2(R1),R2 ;PARAMETER TABLE ADDRESS
4704 024506 011246                MOV      (R2),-(SP) ;PARAMETER ALLOCATION BITS
4705 024510 012703 000013                MOV      #11.,R3 ;NUMBER OF PARAMETERS (MAXIMUM) BEFORE 'LS'
4706 024514 006216                6$:      ASR      (SP) ;COUNT THE PARAMETER
4707 024516 103002                BCC      7$ ;BR IF NOT USED
4708 024520 062702 000002                ADD      #2,R2 ;INCREMENT THE PARAMETER TABLE ADDRESS
4709 024524 005303                7$:      DEC      R3 ;COUNT THE PARAMETER
4710 024526 001372                BNE      6$ ;BR IF NOT THERE YET
4711 024530 005726                TST      (SP)+ ;CORRECT THE STACK POINTER
4712 024532 021237 001_30                CMP      (R2),PRMLMT+22 ;IS 'LS' TOO LARGE FOR THE MODE SELECTED ?
4713 024536 101754                BLOS     5$ ;BR IF NOT
4714 024540 013712 001630                MOV      PRMLMT+22,(R2) ;RESET VALUE FOR MODE USED
4715 024544 000751                BR        5$ ;CONTINUE
4716 024546                8$:
4717 024546 012603                MOV      (SP)+,R3 ;: POP STACK INTO R3
4718 024550 012602                MOV      (SP)+,R2 ;: POP STACK INTO R2
4719 024552 012501                MOV      (SP)+,R1 ;: POP STACK INTO R1
4720 024554 012600                MOV      (SP)+,R0 ;: POP STACK INTO R0
4721 024556 000207                RTS      PC ;RETURN
4722
4723 ;THIS ROUTINE FILLS THE PARAMETER TABLE THE CURRENT TEST.
4724 ;CALL
4725 ;:
4726 ;:
4727 ;:
4728 ;:
4729 ;:
4730 024560                LOOPRM:
4731 024560 010146                MOV      R1,-(SP) ;: PUSH R1 ON STACK
4732 024562 010246                MOV      R2,-(SP) ;: PUSH R2 ON STACK
4733 024564 010346                MOV      R3,-(SP) ;: PUSH R3 ON STACK
4734 024566 010446                MOV      R4,-(SP) ;: PUSH R4 ON STACK
4735 024570 005004                CLR      R4 ;: CLEAR R4
4736 024572 113704 001102                MOV      #STSTNM,R4 ;: GET THE TEST NUMBER
4737 024576 006304                ASL      R4 ;: SETUP TO ADDRESS WORDS
4738 024600 016401 001536                MOV      PRMPT(R4),R1 ;: GET THE TEST'S PARAMETER TABLE ADDRESS
4739 024604 012702 001504                MOV      #PRM,R2 ;: PARAMETER EXECUTION TABLE
4740 024610 005003                CLR      R3 ;: R3 IS USED AS A COUNTER
4741 024612 013704 001254                MOV      #CHKDRV,R4 ;: DRIVE'S ADDRESS
4742 024616 012122                MOV      (R1)+,(R2)+ ;: PARAMETER SPECIFIER
4743 024620 006237 001504                1$:      ASR      PRM ;: THIS PARAMETER USED IN THE TEST ?
4744 024624 103002                BCC      2$ ;: BR IF NOT
4745 024626 012122                MOV      (R1)+,(R2)+ ;: LOAD THE VALUE
4746 024630 000401                BR        3$ ;: CONTINUE
4747 024632 005022                2$:      CLR      (R2)+ ;: CLEAR THE UNUSED PARAMETER LOCATION
    
```

DUU

```

4747 024634 005203 35: INC R3 ;COUNT THE POSITION IN THE OUTPUT TABLE
4748 024636 020327 000014 CMP R3,#12. ;FINISHED?
4749 024642 001430 BEQ 65 ;BR IF YES
4750 024644 020327 000003 CMP R3,#3 ;DOING THE CYLINDER ADDRESSES?
4751 024650 001363 BNE 15 ;BR IF NOT
4752 024652 132764 000004 034346 BITB #BIT02,DRVTP(R4) ;RPO6?
4753 024660 001016 BNE 55 ;BR IF IT IS
4754 024662 062703 000002 ADD #2,R3 ;COUNT THE BYPASSED PARAMETERS (FC' & LC')
4755 024666 006237 001504 ASR PR4 ;SHIFT THE COUNTER
4756 024672 103002 BCC 45 ;BR IF FC' IS NOT USED
4757 024674 062701 000002 ADD #2,R1 ;MOVE THE INPUT POINTER
4758 024700 006237 001504 45: ASR PR4 ;COUNT THE PARAMETER
4759 024704 103045 BCC 15 ;BR IF LC' NOT USED
4760 024706 062701 000002 ADD #2,R1 ;MOVE THE INPUT PINTER
4761 024712 000742 BR 15 ;KEEP GOING
4762 024714 000741 BR 15 ;KEEP GOING
4763 024716 162702 000004 55: SUB #4,R2 ;BACKUP THE OUTPUT POINTER
4764 024722 000736 BR 15 ;KEEP GOING
4765 024724 65: MOV (SP)+,R4 ;POP STACK INTO R4
4766 024724 012604 MOV (SP)+,R3 ;POP STACK INTO R3
4767 024726 012603 MOV (SP)+,R2 ;POP STACK INTO R2
4768 024730 012602 MOV (SP)+,R1 ;POP STACK INTO R1
4769 024732 012601 RTS PC ;RETURN
4770 024734 000207

```

;; THIS ROUTINE LOADS A READ HEADER AND DATA COMMAND OR A SEEK COMMAND  
INTO DPB.B+2 AND DPB.C+2, DEPENDING ON THE STATE OF "CONTROL SWITCH"  
BIT07.

```

4771 4772 4773 4774 4775 4776 4777 4778 4779 4780 4781 4782 4783 4784 4785 4786 4787 4788 4789 4790 4791 4792 4793 4794 4795 4796 4797 4798 4799 4800 4801 4802
CALL JSR RETURN PC,#LDCMD
LDCMD: BIT #SW07,#WC.SWK ;DO EXPLICIT SEEKS?
BNE 15 ;YES--BRANCH
MOV #READHD,#DPB.B+2 ;NO--SET UP FOR READ HEADER AND
MOV #READHD,#DPB.C+2 ;DATA COMMAND
BR 25
15: MOV #SEEK,#DPB.B+2 ;SETUP FOR SEEK COMMAND
MOV #SEEK,#DPB.C+2
25: RTS PC

```

;; THIS ROUTINE WILL CALL THE RPO4/5/6 DRIVER AND THEN WAIT ON THE FUNCTION  
TO COMPLETE. IF AN ERROR OCCURS IT IS REPORTED.

```

4795 4796 4797 4798 4799 4800 4801 4802
CALL CALL.A: CLR #SEESCAPE ;NO ESCAPE ADDRESS
JSR RO,#RPO4 ;CALL RPO4 DRIVER
DPB.A
BR CALL.A
15: TST #DPB.A+16 ;DONE?
BEQ 15 ;NO--LOOP
BPL 35 ;BRANCH IF NO ERROR
MOV #25,SEESCAPE ;ESCAPE TO 25 ON ERROR

```

```

4803 025034 013737 004116 001270      MOV      2#DPB.A+12,2#CYL.DS ;CYLINDER
4804 025034 113737 004115 001274      MOVB    2#DPB.A+11,2#TRK.DS ;TRACK
4805 025050 113737 004114 001272      MOVB    2#DPB.A+10,2#SEC.DS ;SECTOR
4806 025056 012746 004122      MOV     2#DPB.A+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
4807 025062 004737 026216      JSR     PC,2#ERINDEX ;FORM DISPATCH INDEX
4808 025066 062607      ADD     (SP)+,PC ;REPORT PROPER ERROR
4809 025070 104041      ERROR  41 ;
4810 025072 104042      ERROR  42 ;PARITY ERROR
4811 025074 104043      ERROR  43 ;UNSAFE ERROR
4812 025076 104044      ERROR  44 ;NON-I/O ERROR
4813 025100 104045      ERROR  45 ;I/O ERROR
4814 025102 013746 004122 28:      MOV     DPB.A+16,-(SP) ;STATUS WORD
4815 025106 004737 026156      JSR     PC,LOP.CK ;SEE IF LOOP, ABORT, OR CONTINUE
4816 025112 000200      RTS    RD ;RETURN

```

: THIS ROUTINE IS THE SAME AS "CALL.A" EXCEPT FOR THE DPB USED AND IF THE COMMAND IS A READ HEADER AND DATA THE HEADER (CYLINDER, TRACK, AND SECTOR) READ IS CHECKED FOR VALIDITY.

```

4817
4818
4819
4820
4821
4822
4823
4824
4825
4826
4827
4828
4829
4830
4831
4832
4833
4834
4835
4836
4837
4838
4839
4840
4841
4842
4843
4844
4845
4846
4847
4848
4849
4850
4851
4852
4853
4854
4855
4856
4857
4858

```

```

CALL
CALL.B: CLR      2#ESCAPZ ;NO ESCAPE ADDRESS
        JSR     RD,2#RPO4 ;CALL RPO4 DRIVER
        DPB.B
        BR     CALL.B
18:     TST     DPB.B+16 ;DONE?
        BEQ    18 ;NO--BRANCH
        BPL    48 ;BRANCH IF NO ERROR
        MOV     2#3S,2#ESCAPZ ;ESCAPE TO 3S ON ERROR
        MOV     2#DPB.B+12,2#CYL.DS ;CYLINDER
        MOVB    2#DPB.B+11,2#TRK.DS ;TRACK
        MOVB    2#DPB.B+10,2#SEC.DS ;SECTOR
        MOV     2#DPB.B+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
        JSR     PC,2#ERINDEX ;FORM DISPATCH INDEX
        ADD     (SP)+,PC ;REPORT PROPER ERROR
        ERROR  41 ;
        ERROR  42 ;PARITY ERROR
        ERROR  43 ;UNSAFE ERROR
        ERROR  44 ;NON-I/O ERROR
        TST     RP.REG+RPER1 ;DRIVE ERROR?
        BEQ    28 ;BR IF NOT
        BIT     2#C100,RP.REG+RPER1 ;SEE IF ONLY 'HCE' SET
        BEQ    48 ;BR IF IT IS
        ERROR  45 ;I/O ERROR
28:     MOV     DPB.B+16,-(SP) ;STATUS WORD
38:     JSR     PC,LOP.CK ;SEE IF LOOP, ABORT, OR CONTINUE
        BR     58 ;CHECK FOR STALL
48:     CNPB    2#DPB.B+2,2#READHD ;DOING IMPLIED SEEKS?
        BNE    58 ;NO--BRANCH
        JSR     RD,2#VERIFY ;YES--GO CHECK THE DATA
        DPB.B+10
        BR     68 ;ERROR DURING VERIFY
58:     BIT     2#SH14,2#C.SWR ;STALL?
        BEQ    68 ;NO--BRANCH

```

```

4859 025274 004037 026334          JSP      RO,#STALL      ;YES--CALL STALL ROUTINE
4860 025300 001354          .WORD   STALL1         ;STALL TIME POINTER
4861 025302 000200          6S:     RTS          RO  ;RETURN
4862
4863          ;THIS ROUTINE IS THE SAME AS "CALL.B" EXCEPT FOR THE DPB USED.
4864          ;CALL
4865          ;
4866          ;      FILL DPB
4867          ;      JSR      RO,#CALL.C
4868          ;      RETURN
4869
4869 025304 005037 001206          CALL.C: CLR      #ESCAPE  ;NO ESCAPE ADDRESS
4870 025310 004037 035252          JSR      RC,#RPO4      ;CALL RPO4 DRIVER
4871 025314 004144          DPB.C
4872 025316 000772          BR      CALL.C
4873 025320 005737 004162          1S:     TST      #DPB.C+16 ;DONE?
4874 025324 001775          BEQ     1S             ;NO--LOOP
4875 025326 100042          BPL     4S             ;YES--BRANCH IF NO ERROR
4876 025330 012737 025422 001206          MOV     #3S,#ESCAPE   ;ESCAPE TO 3S ON ERROR
4877 025336 013737 004156 001270          MOV     #DPB.C+12,#CYL.DS ;CYLINDER
4878 025344 113737 004155 001274          MOV     #DPB.C+11,#TRK.DS ;TRACK
4879 025352 113737 004154 001272          MOV     #DPB.C+10,#SEC.DS ;SECTOR
4880 025360 012746 001162          MOV     #DPB.C+1F,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
4881 025364 004737 026216          JSR     PC,#ERR!NOX    ;FORM DISPATCH INDEX
4882 025370 062607          ADD     (SP)+,PC      ;REPORT PROPER ERROR
4883 025372 104041          ERROR  41
4884 025374 104042          ERROR  42             ;PARITY ERROR
4885 025376 104043          ERROR  43             ;UNSAFE ERROR
4886 025400 104044          ERROR  44             ;NON-I/O ERROR
4887 025402 005737 004220          TST     RP.REG+RPER1   ;DRIVE ERROR?
4888 025406 001404          BEQ     2S             ;BR IF NOT
4889 025410 032737 177677 004220          BIT     #1C100,RP.REG+RPER1 ;SEC IF ONLY 'MCE' SET
4890 025416 001406          BEQ     4S             ;BR IF IT IS
4891 025420 104045          2S:     ERROR  45             ;I/O ERROR
4892 025422 013746 004162          3S:     MOV     DPB.C+16,-(SP) ;STATUS WORD
4893 025426 004737 026156          JSR     PC,L0P.CK      ;SEE IF LOOP, ABORT, OR CONTINUE
4894 025432 000410          BR      5S
4895 025434 123727 004146 000173          4S:     CMP     #DPB.C+2,#READHD ;DOING IMPLIED SEEK?
4896 025442 001004          BNE     5S             ;NO--EXIT
4897 025444 004037 026476          JSR     RO,#VERIFY     ;YES--CHECK THE DATA
4898 025450 001154          DPB.C+10
4899 025452 000407          BR      6S             ;ERROR DURING VERIFY
4900 025454 032737 040000 001220          5S:     BIT     #SW14,#C.SWR   ;STALL?
4901 025462 001403          BEQ     6S             ;NO--BRANCH
4902 025464 004037 026334          JSR     RO,#STALL     ;YES--CALL STALL ROUTINE
4903 025470 001354          .WORD   STALL1         ;STALL TIME POINTER
4904 025472 000200          6S:     RTS          RO
4905
4906
4907          ;THIS ROUTINE IS THE SAME AS "CALL.A" EXCEPT FOR THE DPB USED AND
4908          ;ON AN ERROR LOCATION "ERR.CT" IS EXAMINED. IF ERR.CT IS EQUAL TO
4909          ;SERFLG EXIT IS TO THE NEXT TEST.
4910          ;CALL
4911          ;
4912          ;      FILL DPB
4913          ;      JSR      RO,#DRVCAL
4914          ;      RETURN

```

# E08

4915	025474	005037	001206			DRVCL:	CLR	2#SESCAPE	: NO ESCAPE ADDRESS
4916	025476	005037	001334				CLR	2#WCEFLG	: CLEAR WRITE CHECK ERROR FLAG
4917	025478	004037	035252				JSR	RO,2#RPO4	: CALL RPO4 DRIVER
4918	025480	004164					DTADPB		
4919	025482	000770					BR	DRVCL	
4920	025484	005737	004202			DRVCL1:	TST	2#DTADPB+16	: DONE
4921	025486	001775					BEQ	DRVCL1	: NO--LOOP
4922	025488	100402					BMI	15	: BR IF ERRORS
4923	025490	000137	026136				JMP	105	: NO ERRORS
4924	025492					15:			
4925	025494	012737	025604	001206			MOV	2#SESCAPE	: ESCAPE TO 25 ON ERROR
4926	025496	013737	004176	001270			MOV	2#DTADPB+12,2#CYL.DS	: CYLINDER
4927	025498	113737	004175	001274			MOVB	2#DTADPB+11,2#TRK.DS	: TRACK
4928	025500	113737	004174	001272			MOVB	2#DTADPB+10,2#SEC.DS	: SECTOR
4929	025502	012746	004202				MOV	2#DTADPB+16,-(SP)	: STATUS/ERROR INDICATOR ADDRESS
4930	025504	004737	026216				JSR	PC,2#ERINDX	: FORM DISPATCH INDEX
4931	025506	062607					ADD	(SP)+,PC	: REPORT PROPER ERROR
4932	025508	104041					ERROR	41	
4933	025510	104042					ERROR	42	: PARITY ERROR
4934	025512	104043					ERROR	43	: UNSAFE ERROR
4935	025514	104044					ERROR	44	: NON-I/O ERROR
4936	025516	104045					ERROR	45	: I/O ERROR
4937	025518	122737	000020	001102	25:		CHPB	20,2#STSTNM	: TEST 20?
4938	025520	001137					BNE	85	: NO--BRANCH
4939	025522	013746	004202				MOV	DTADPB+16,-(SP)	: STATUS WORD
4940	025524	004737	026156				JSR	PC,LOP.CK	: SEE IF LOOP ABORT, OR CONTINUE
4941	025526	122737	000151	004166			CHPB	2#WCKD,2#DTADPB+2	: DOING A WRITE CHECK?
4942	025528	001137					BNE	125	: NO--BRANCH
4943	025530	032737	040000	004214			BIT	2#BIT14,2#RP.REG+10	: IS "WCE"=1?
4944	025532	001527					BEQ	125	: NO--BRANCH
4945	025534	032777	000020	153266			BIT	2#W04,2#WR	: INHIBIT WRITES?
4946	025536	001123					BNE	125	: YES--BRANCH
4947	025538	112737	000161	004166			MOVB	2#WRITE,2#DTADPB+2	: SETUP FOR A WRITE
4948	025540	005037	001206				CLR	2#SESCAPE	: NO ESCAPE ADDRESS
4949	025542	004037	035252				JSR	RO,2#RPO4	: DO THE WRITE
4950	025544	004164					DTADPB		
4951	025546	000240					NOP		
4952	025548	005737	004202			35:	TST	2#DTADPB+16	: DONE?
4953	025550	001775					BEQ	35	: NO--LOOP
4954	025552	100126					BPL	45	: YES--BRANCH IF NO ERROR
4955	025554	012737	026112	001206			MOV	2#SESCAPE	: ESCAPE TO 85 ON ERROR
4956	025556	013737	004176	001270			MOV	2#DTADPB+12,2#CYL.DS	: CYLINDER
4957	025558	113737	004175	001274			MOVB	2#DTADPB+11,2#TRK.DS	: TRACK
4958	025560	113737	004174	001272			MOVB	2#DTADPB+10,2#SEC.DS	: SECTOR
4959	025562	012746	004202				MOV	2#DTADPB+16,-(SP)	: STATUS/ERROR INDICATOR ADDRESS
4960	025564	004737	026216				JSR	PC,2#ERINDX	: FORM DISPATCH INDEX
4961	025566	062607					ADD	(SP)+,PC	: REPORT PROPER ERROR
4962	025568	104041					ERROR	41	
4963	025570	104042					ERROR	42	: PARITY ERROR
4964	025572	104043					ERROR	43	: UNSAFE ERROR
4965	025574	104044					ERROR	44	: NON-I/O ERROR
4966	025576	104045					ERROR	45	: I/O ERROR
4967	025578	112737	000151	004166	45:		MOVB	2#WCKD,2#DTADPB+2	: COMMAND=WRITE CHECK DATA
4968	025580	004037	035252				JSR	RO,2#RPO4	: DO THE WRITE CHECK
4969	025582	004164					DTADPB		
4970	025584	000240					NOP		



```

4971 026000 005737 004202 58: TST @DTADPB+16 ;DONE?
4972 026004 001775 BEQ 58 ;NO--LOOP
4973 025006 100410 BMI 78 ;YES--BRANCH IF ERROR
4974 025010 004037 035252 JSR RO,@RPO4 ;DO A 2ND WRITE CHECK
4975 025014 004164 DTADPB
4976 026016 000240 NOP
4977 026020 005737 004202 68: TST @DTADPB+16 ;DONE?
4978 025024 001775 BEQ 68 ;NO--LOOP
4979 025026 100043 BPL 108 ;YES--BRANCH IF NO ERROR
4980 026030 012737 000001 001334 78: MOV @!,@#WCEFLG ;SET THE WRITE CHECK ERROR FLAG
4981 026036 012737 026112 001206 MOV @8,@#ESCAPE ;ESCAPE TO 88 ON ERROR
4982 026044 013737 004176 001270 MOV @DTADPB+12,@#CYL.DS ;CYLINDER
4983 026052 113737 004175 001274 MOV @DTADPB+11,@#TRK.DS ;TRACK
4984 026050 113737 004174 001272 MOV @DTADPB+10,@#SEC.DS ;SECTOR
4985 026056 012746 004202 MOV @DTADPB+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
4986 026072 004737 026216 JSR PC,@#ERINDX ;FORM DISPATCH INDEX
4987 026076 062607 ADD (SP)+,PC ;REPORT PROPER ERROR
4988 026100 104041 ERROR 41 ;
4989 026102 104042 ERROR 42 ;PARITY ERROR
4990 026104 104043 ERROR 43 ;UNSAFE ERROR
4991 026106 104044 ERROR 44 ;NON-I/O ERROR
4992 026110 104046 ERROR 46 ;FATAL WRITE CHECK
4993 026112 013746 004202 88: MOV DTADPB+16,-(SP) ;STATUS WORD
4994 026116 004737 026156 JSR PC,LOP.CK ;SEE IF LOOP, ABORT, OR CONTINUE
4995 026122 123737 001364 001103 128: CMPB @#ERR.CT,@#SERFLG ;GO TO NEXT TEST?
4996 026120 101002 BHI 108 ;NO--BRANCH
4997 026124 013700 001252 98: MOV @#BYPASS,RO ;YES--GET EXIT ADDRESS
4998 026126 032737 040000 001220 108: BIT @SW14,@#C.SWR ;STALL?
4999 026144 001403 BEQ 118 ;NO--BRANCH
5000 026146 004037 026334 JSR RO,@#STALL ;YES--CALL STALL ROUTINE
5001 026154 001356 .WORD STALL2 ;STALL TIME POINTER
5002 000200 118: RTS RO
; THIS SUBROUTINE CHECK FOR LOOP, ABORT, OR CONTINUE SWITCHES AFTER
; ERRORS 41, 42, 43, 44, 45, AND 46.
; CALL
; MOV DTA+16,-(SP) ;STATUS WORD FROM DPB IN USE
; JSR PC,LOP.CK
; RETURN
5011 026156 032777 001000 152754 LOP.CK: BIT @SW9,@SWR ;LOOP ON ERROR
5012 026164 091402 BEQ 18 ;BR IF NOT
5013 026166 000177 152716 JMP @#LPERR ;START AT THE LOOP ADDRESS
5014 026172 005037 001206 18: CLR @#ESCAPE ;CLEAR ERROR ESCAPE FLAG
5015 026176 032766 072006 000002 BIT @BIT14!@BIT13!@BIT12!@BIT10!@BIT02!@BIT01,2(SP) ;CHECK ERROR TYPE
5016 026204 001402 BEQ 28 ;BR IF DRIVE NOT OFFLINE, UNLOADED, OR
5017 ; PERSISTENT UNSAFE OR FATAL MASSBUS PARITY
5018 026206 000137 017356 JMP @#EOP ;TERMINATE DRIVE
5019 026212 012616 28: MOV (SP)+,(SP) ;ADJUST RETURN ADDRESS
5020 026214 000207 RTS PC
; THIS ROUTINE FORMS AN INDEX THAT WILL BE USED TO DISPATCH
; TO THE PROPER ERROR CALL. THE INDEX IS FORMED BY EXAMINING
; THE STATUS/ERROR INDICATOR OF THE APPLICABLE DPB.
; INDEX STATUS/ERROR
; -----

```

```

5027      :      0 BIT14!BIT13!BIT08!BIT01
5028      :      2 BIT11!BIT10!BIT02
5029      :      4 BIT12!BIT04
5030      :      6 BIT05!BIT03!<BIT09 & COMMAND=NON-I/O>
5031      :      10 BIT06!<BIT09 & COMMAND=I/O>
5032      :CALL
5033      :      JSR      #OPB+16,-(SP)      ;ADDRESS OF STATUS/ERROR INDICATOR
5034      :      JSR      PC,@#ERINDX      ;FORM INDEX
5035      :      RETURN     ;INDEX IS ON THE STACK
5036
5037      026216 010046      ERINDX: MOV      RO,-(SP)      ;SAVE RO
5038      026220 010146      MOV      R1,-(SP)      ;SAVE R1
5039      026222 016600 000006  MOV      6(SP),RO      ;GET STATUS/ERROR INDICATOR POINTER
5040      026226 011037 001260  MOV      (RO),@#SVSTAT ;SAVE THE STATUS/ERROR INDICATOR
5041      026232 005001      CLR      R1            ;START INDEX AT ZERO
5042      026234 032710      BIT      (PC)+(RO)     ;FORM INDEX OF 0
5043      026236 020402      .WORD   BIT13!BIT08!BIT01
5044      026240 001027      BNE     5$            ;YES--BRANCH
5045      026242 032710      BIT      (PC)+(RO)     ;FORM PARITY ERROR OR PORT REQUEST INDEX (2)?
5046      026244 006004      .WORD   BIT11!BIT10!BIT02
5047      026246 001023      BNE     4$            ;YES--BRANCH
5048      026250 032710      BIT      (PC)+(RO)     ;FORM UNSAFE INDEX (4)?
5049      026252 050020      .WORD   BIT14!BIT12!BIT04
5050      026254 001017      BNE     3$            ;YES--BRANCH
5051      026256 032710      BIT      (PC)+(RO)     ;FORM NON-I/O ERROR INDEX (6)?
5052      026260 000050      .WORD   BIT05!BIT03
5053      026262 001013      BNE     2$            ;YES--BRANCH
5054      026264 032710      BIT      (PC)+(RO)     ;FORM I/O ERROR INDEX (10)?
5055      026266 000100      .WORD   BIT06
5056      026270 001007      BNE     1$            ;YES--BRANCH
5057      026272 032710      BIT      (PC)+(RO)     ;SOFTWARE TIMEOUT?
5058      026274 001000      .WORD   BIT09
5059      026276 001410      BEQ     5$            ;NO--FORM INDEX OF 0
5060      026300 122760 000150 177762  CMPB    #150,-16(RO)  ;YES--I/O?
5061      026306 003001      BGT     2$            ;NO--BRANCH
5062      026310 005201      1$: INC      R1            ;INDEX=10---ERROR=45 OR 46
5063      026312 005201      2$: INC      R1            ;INDEX=6---ERROR=44
5064      026314 005201      3$: INC      R1            ;INDEX=4---ERROR=43
5065      026316 005201      4$: INC      R1            ;INDEX=2---ERROR=42
5066      026320 006301      5$: ASL     R1            ;INDEX=0---ERROR=41
5067      026322 010166 000006  MOV      R1,6(SP)     ;RETURN INDEX TO USER
5068      026326 012601      MOV      (SP)+,R1     ;RESTORE R1
5069      026330 012600      MOV      (SP)+,RO     ;RESTORE RO
5070      026332 000207      RTS      PC           ;RETURN FROM CALL
5071
5072      :THIS ROUTINE WILL PROVIDE A STALL IN MILLISECONDS FOR A SPECIFIC
5073      :AMOUNT OF TIME IF BIT13 OF C.SWR = 0 OR A RANDOM AMOUNT OF TIME
5074      :IF BIT 13 OF C.SWR = 1.
5075      :STALL1 CONTAINS SPECIFIED TIME FOR TESTS 0 - 7, AND STALL2
5076      :CONTAINS THE TIME FOR TESTS 16-21.
5077      :CALL
5078      :      JSR      RO,@#STALL
5079      :      TIME POINTER      ;WHERE TO FIND THE STALL TIME
5080
5081      026334 013046      STALL: MOV      @<(RO)+,-(SP) ;PICKUP STALL TIME
5082      026336 032737 020000 001220  BIT      #SW13,@#C.SWR ;USE A RANDOM TIME?
    
```

```

5083 026344 001406 BEQ 1$ ;NO--BRANCH
5084 026346 004737 JSR PC,@$RAND ;YES--FORM RANDOM NUMBER
5085 026352 013716 MOV @#$LONUM,(SP) ;AND USE IT FOR THE STALL TIME
50 5 026356 042716 BIC @1C77,(SP) ;BUT NEVER > 64 MILLISECONDS
50-7 026362 005046 CLR -(SP) ;CLEAR TEMP. LOCATION
5088 026364 162766 000001 000002 2$: SUB @1,2(SP) ;MORE STALL REQUIRED?
5089 026372 103407 3$: JLO 4$ ;NO--BRANCH
5090 026374 012716 000144 MOV @100.,(SP) ;STALL FOR ABOUT 1 MILLISECOND
5091 026400 005700 3$: TST R0 ;NOP TO KILL TIME
5092 026402 005366 000000 DEC @1(SP) ;COUNT
5093 026406 001374 BNE 3$ ;LOOP IF MORE COUNTS NEEDED
5094 026410 000765 BR 2$
5095 026412 022626 4$: CMP (SP)+,(SP)+ ;CLEAN OFF THE STACK
5096 026414 000200 RTS R0 ;EXIT
5097
5098
5099

```

```

5100 ;ROUTINE TO PROVIDE A 2 MS STALL AFTER A SEEK OPERATION IN THE SEEK TIMING
5101 ;TESTS. THIS STALL IS REQUIRED TO COMPENSATE FOR THE 'ACCESS READY' DELAY
5102 ;IN THE RPO4. THIS STALL TIME IS NOT INCLUDED IN THE CALCULATED SEEK TIMES.
5103 ;CALL

```

```

5103 ;CALL
5103 JSR PC,@TWOMS
5104 ;
5104 RETURN
5105
5106 026416 013746 177776 TWOMS: MOV @#PS,-(SP) ;SAVE THE PRESENT PROCESSOR STATUS
5107 026422 012 37 000240 177776 MOV @(<5*32.)@#PS ;SET THE PROCESSOR PRIORITY TO 5
5108 026430 017746 152740 MOV @PKV,-(SP) ;SAVE THE OLD CLOCK VECTOR ADDRESS
5109 026434 012777 026460 152732 MOV @1$@PKV ;SETUP NEW VECTOR ADDRESS
5110 026442 012777 000310 152732 MOV @200.@PKB ;LOAD THE CLOCK BUFFER
5111 026450 012777 000101 152722 MOV @101,@PKCS ;START THE CLOCK
5112 026456 000001 WAIT ;WAIT FOR 2 MS
5113 026460 062706 000004 1$: ADD @4,SP ;INCREMENT STACK FOR RETURN
5114 026464 012677 152704 MOV (SP)+,@PKV ;RESTORE OLD CLOCK VECTOR
5115 026470 012637 177776 MOV (SP)+,@#PS ;RESTORE THE OLD PROCESSOR STATUS
5116 026474 000207 RTS PC ;RETURN
5117
5118 ;ROUTINE TO SOFTWARE COMPARE HEADER ON IMPLIED SEEKS
5119 ;CALL

```

```

5120 ;CALL
5120 JSR R0,@VERIFY
5121 ;ADR POINTER ;ADDRESS OF DPB+10 (SECTOR NUMBER)
5122 ;RETURN
5123

```

```

5124 026476 010146 VERIFY: MOV R1,-(SP) ;SAVE R1
5125 026500 012301 MOV (R0)+,R1 ;GET ADDRESS OF DPB+10
5126 026502 042737 010000 047662 BIC @FMT22,@BUFFER ;STRIP FORMAT BIT FROM CYLINDER NUMBER
5127 026510 023761 047662 000002 CMP @BUFFER,2(R1) ;CYLINDER NUMBER OK?
5128 026516 001003 BNE 1$ ;NO--BRANCH
5129 026520 023711 047664 CMP @BUFFER+2,(R1) ;YES--HOW ABOUT TRACK/SECTOR?
5130 026524 001441 BEQ 3$ ;BRANCH IF GOOD
5131 026526 013737 047662 001262 1$: MOV @BUFFER,@CYL,R0 ;SAVE THE EXPECTED AND THE
5132 026534 113737 047665 001264 MOV @BUFFER+3,@TRK,R0 ;RECEIVED CYLINDER, TRACK,
5133 026542 113737 047664 001266 MOV @BUFFER+2,@SEC,R0 ;AND SECTOR
5134 026550 112137 001272 MOV (R1)+,@SEC,DS
5135 026554 112137 001274 MOV (R1)+,@TRK,DS
5136 026560 011137 001270 MOV (R1),@CYL,DS
5137 026564 012737 026576 001206 MOV @2$, $ESCAPE ;;ESCAPE TO 2$ ON ERROR
5138 026572 005740 TST -(R0) ;MAKE IT TEST PC+4

```

```

S139 026574 104012          ERROR 12          ;REPORT THE ERROR
S140 026576 012737 000107 004106 2$: MOV  #RECAL,DPB,A+2 ;LOAD RECALIBRATE ORDER CODE
S141 026604 004037 025002          JSR  R0,#CALL.A ;GO EXECUTE THE COMMAND
S142 026610 005037 001206          CLR  $ESCAPE ;CLEAR ERROR ESCAPE FLAG
S143 026614 032777 001000 152316 BIT  #SW9,#SWR ;LOOP ON ERROR ?
S144 026622 001404          BEQ  4$ ;BR IF NOT
S145 026624 000177 152260          JMP  @SLPERR ;RETURN TO ERROR LOOP ADDRESS
S146 026630 062700 000002          3$: ADD  #2,R0 ;INCREMENT RETURN ADDRESS
S147 026634 012601          4$: MOV  (SP)+,R1 ;RESTORE R1
S148 026636 000200          RTS   R0 ;EXIT

;THIS ROUTINE WILL PERFORM A "MASSBUS" INIT. FOLLOWED BY
;A "RECALIBRATE" ON THE DRIVE UNDER TEST.
;NOTE: THIS ROUTINE DESTROYS R1 AND R4
;CALL
;JSR  R0,SRCH00 ;DO A MASSBUS INIT. AND RECAL
;RETURN1 ;RETURN HERE IF NO ERROR
;RETURN2 ;RETURN HERE ON ERROR

SRCH00: CLR  R1 ;IN CASE OF ERROR (TYPTIM)
        CLR  @#PS
        MOV  #ISR,@RPEC ;SETUP INTERRUPT VECTOR
        MOV  @RPAOR,R4 ;PICKUP ADDRESS OF RPCS1
        MOV  #BIT05,RPCS2(R4) ;MASSBUS INIT.
        CLR  @DTADPB+10 ;TRACK=0; SECTOR=0
        CLR  @DTADPB+12 ;CYLINDER =0
        MOV  #RECAL,@DTADPB+2 ;COMMAND = RECALIBRATE
        CLR  @SESCAPE ;NO ESCAPE ADDRESS
        JSR  R0,@RPO4 ;CALL THE DRIVER
        DTAOPB ;DPB POINTER
        BR   4$ ;QUEUE IS FULL
        1$: TST DTADPB+16 ;WAIT ON DONE
        BEQ  1$
        BFL  3$ ;TAKE NORMAL EXIT IF NO ERROR
        MOV  #2$,$ESCAPE ;ESCAPE TO 2$ ON ERROR
        MOV  @DTADPB+12,@CYL.DS ;CYLINDER
        MOVB @DTADPB+11,@TRK.DS ;TRACK
        MOVB @DTADPB+10,@SEC.DS ;SECTOR
        MOV  @DTADPB+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
        JSR  PC,@ERINDEX ;FORM DISPATCH INDEX
        ADD  (SP)+,PC ;REPORT PROPER ERROR
        ERROR 41
        ERROR 42 ;PARITY ERROR
        ERROR 43 ;UNSAFE ERROR
        ERROR 44 ;NON-I/O ERROR
        ERROR 45 ;I/O ERROR
        2$: TST (R0)+ ;ADJUST FOR ERROR EXIT
        BR   4$ ;GO TO THE EXIT
        3$: CLR  RPOA(R4) ;TRACK AND SECTOR = 0
        CLR  RPOA(R4) ;CYLINDER = 0
        4$: RTS   R0 ;RETURN

;THIS IS AN RTI WHICH IS USED BY THE TIMING TESTS & THE SERVO SETTLE DOWN TEST
DORTI: RTI ;RETURN FROM INTERRUPT
  
```

```

5195          ;THIS ROUTINE WILL INITIALIZE THE TIMERS USED BY THE "TIMING ROUTINES
5196          ;CALL
5197          ;
5198          ;
5199          ;
5200 027024 104412          STRTMR: SAVREG          ;SAVE RO-RS
5201 027026 012700 001276      MOV          #TIM.UP,RO          ;START AT TIM.UP (MINIMUM)
5202 027032 012701 001332      MOV          #TIM.PT,R1          ;STOP AT TIM.PT
5203 027036 005020          1$: CLR          (RO)+          ;CLEAR
5204 027040 020001          CMP          RO,R1          ;DONE?
5205 027042 103775          BLO          1$          ;NO--BRANCH
5206 027044 012710 047662      MOV          #BUFFER,(RO)          ;SETUP POINTER
5207 027050 012737 077777 001276  MOV          #TIM.UP,#TIM.UP ;SET MINIMUM TIME TO MAXIMUM
5208 027056 012737 077777 001314  MOV          #TIM.DN,#TIM.DN ;POSITIVE NUMBER
5209 027064 104413          RESREG          ;RESTORE RO-RS
5210 027066 000207          RTS          PC          ;RETURN
5211
5212          ;THIS ROUTINE WILL ADD THE ELAPSED TIME TO THE AVERAGE COUNTER AND
5213          ;MAINTAIN THE MINIMUM AND MAXIMUM TIMES.
5214          ;NOTE: THIS ROUTINE DESTROYS R2
5215          ;CALL
5216          ;
5217          ;
5218          ;
5219          ;
5220          ;
5221          ;
5222 027070 012702 001276      COUNT: MOV          #TIM.UP,R2          ;PICKUP THE "UP" POINTER
5223 027074 005705          TST          R5          ;USE IT?
5224 027076 001402          BEQ          1$          ;YES--BRANCH
5225 027100 012702 001314      MOV          #TIM.DN,R2          ;NO--PICKUP "DOWN" POINTER
5226 027104 027722 152274      1$: CMP          @PKC,(R2)+          ;LESS THAN PREVIOUS LOW?
5227 027110 002003          BGE          2$          ;NO--BRANCH
5228 027112 017762 152266 177776  MOV          @PKC,-2(R2)          ;YES--SAVE IT
5229 027120 027763 152260 000004  2$: CMP          @PKC,4(R3)          ;LESS THAN THE LOW LIMIT?
5230 027126 002001          BGE          3$          ;NO--BRANCH
5231 027130 005212          INC          (R2)          ;YES--COUNT IT
5232 027132 005722          TST          (R2)+          ;ADVANCE THE POINTER
5233 027134 027722 152244      3$: CMP          @PKC,(R2)+          ;GREATER THAN PREVIOUS HIGH?
5234 027140 003403          BLE          4$          ;NO--BRANCH
5235 027142 017762 152236 177776  MOV          @PKC,-2(R2)          ;YES--SAVE IT
5236 027150 027763 152230 000006  4$: CMP          @PKC,6(R3)          ;GREATER THAN THE HIGH LIMIT?
5237 027156 003401          BLE          5$          ;NO--BRANCH
5238 027160 005212          INC          (R2)          ;YES--COUNT IT
5239 027162 005722          TST          (R2)+          ;ADVANCE THE POINTER
5240 027164 067722 152214      5$: ADD          @PKC,(R2)+          ;ADD THIS COUNT TO THE TOTAL
5241 027170 005522          ADC          (R2)+
5242 027172 005212          INC          (R2)
5243 027174 022737 056152 001332  CMP          #BUFFER+(4*814.),@TIM.PT ;COUNT THIS READING
5244 027202 101406          BLOS          6$          ;SAVE THIS COUNT?
5245 027204 017777 152174 152120  MOV          @PKC,@TIM.PT          ;NO--BRANCH
5246 027212 062737 000002 001332  ADD          #2,@TIM.PT          ;YES--WELL SAVE IT THEN
5247 027220 000207          RTS          PC          ;ADVANCE THE POINTER
5248          ;RETURN
5249
5250          ;THIS ROUTINE IS USED TO TYPE THE MINIMUM,
          ;MAXIMUM, AND AVERAGE TIMES FOR THE TIMING TESTS

```

```

5251
5252
5253
5254
5255
5256
5257
5258
5259
5260
5261
5262
5263
5264 027222 012002
5265 027224 032777 000100 151706
5266 027232 001145
5267 027234 012237 027254
5268 027240 012205
5269 027242 012203
5270 027244 011202
5271 027246 012704 001276
5272 027252 104401
5273 027254 000000
5274 027256 005764 000014
5275 027262 001527
5276 027264 104401 043650
5277 027270 012446
5278 027272 004737 023170
5279 027276 004737 023420
5280 027302 104401 043675
5281 027306 005724
5282 027310 001421
5283 027312 104401 044010
5284 027316 016446 177776
5285 027322 004737 023170
5286 027326 004737 023420
5287 027332 104401 043702
5288 027336 010346
5289 027340 004737 023170
5290 027344 004737 023420
5291 027350 104401 043675
5292 027354 104401 043657
5293 027360 012446
5294 027362 004737 023170
5295 027366 004737 023420
5296 027372 104401 043675
5297 027376 005724
5298 027400 000421
5299 027402 104401 044010
5300 027406 016446 177776
5301 027412 004737 023170
5302 027416 004737 023420
5303 027422 104401 043731
5304 027426 010246
5305 027430 004737 023170
5306 027434 004737 023420

```

```

: IT WILL ALSO CHECK THE TIMES TO ENSURE
: THEY ARE WITHIN TOLERANCE AND IF NOT FLAG THE BAD TIMES.
: NOTE: THIS ROUTINE DESTROYS R2-R5
CALL
      JSR      RD,2#TYPTIM      ;GO REPORT THE TIMES
      TABLE  ;POINT TO THE PROPER TABLE
      RETURN
:
: TABLE:MSGADR1      ;ADDRESS OF ASCIZ MESSAGE NUMBER 1
:       MSGADR2      ;ADDRESS OF ASCIZ MESSAGE NUMBER 2
:       MIN.ALLOWED  ;MINIMUM TIME ALLOWED
:       MAX.ALLOWED  ;MAXIMUM TIME ALLOWED
:
TYPTIM: MOV      (R0)+,R2      ;PICKUP THE TABLE POINTER
        BIT      @SW06,@SWR   ;INHIBIT TIME REPORTS?
        BNE     7$          ;YES--BRANCH
        MOV     (R2)+,2$     ;ADDRESS OF MESSAGE NUMBER 1
        MOV     (R2)+,R5     ;ADDRESS OF MESSAGE NUMBER 2
        MOV     (R2)+,R3     ;PICKUP THE LOW LIMIT
        MOV     (R2),R2      ;AND THE HIGH LIMIT
        MOV     @TIM,UP,R4   ;PARAMETER POINTER
        TYPE    THE MESSAGE
1$:     .WORD    0           ;ASCIZ MESSAGE POINTER GOES HERE
2$:     .WORD    14(R4)     ;DID ANY COUNTS OCCUR?
        BEQ     6$          ;NO--BRANCH
        TYPE    ,MSGMIN     ;"MIN="
        MOV     (R4)+,-(SP)  ;PUT (R4)+ ON THE STACK
        JSR     PC,@$$SB20  ;CHANGE (R4)+ TO DECIMAL ASCIZ
        JSR     PC,@$$SUPRS ;TYPE WITHOUT LEADING ZEROS
        TYPE    ,MSGOUS     ;"0 US"
        TST    (R4)+       ;ANY SEEKS BELOW THE LOW LIMIT
        BEQ     3$          ;NO--BRANCH
        TYPE    ,MSG.SP     ;" "
        MOV     -2(R4),-(SP) ;PUT -2(R4) ON THE STACK
        JSR     PC,@$$SB20  ;CHANGE -2(R4) TO DECIMAL ASCIZ
        JSR     PC,@$$SUPRS ;TYPE WITHOUT LEADING ZEROS
        TYPE    ,MBELOW     ;"BELOW THE MINIMUM OF"
        MOV     R3,-(SP)    ;PUT R3 ON THE STACK
        JSR     PC,@$$SB20  ;CHANGE R3 TO DECIMAL ASCIZ
        JSR     PC,@$$SUPRS ;TYPE WITHOUT LEADING ZEROS
        TYPE    ,MSGOUS     ;" "
        TST    (R4)+       ;ANY SEEKS ABOVE THE HIGH LIMIT
        BR     4$          ;NO--BRANCH
        TYPE    ,MSG.SP     ;" "
        MOV     (R4)+,-(SP) ;PUT (R4)+ ON THE STACK
        JSR     PC,@$$SB20  ;CHANGE (R4)+ TO DECIMAL ASCIZ
        JSR     PC,@$$SUPRS ;TYPE WITHOUT LEADING ZEROS
        TYPE    ,MSGOUS     ;" "
        TST    (R4)+       ;ANY SEEKS ABOVE THE HIGH LIMIT
        BR     4$          ;NO--BRANCH
        TYPE    ,MSG.SP     ;" "
        MOV     -2(R4),-(SP) ;PUT -2(R4) ON THE STACK
        JSR     PC,@$$SB20  ;CHANGE -2(R4) TO DECIMAL ASCIZ
        JSR     PC,@$$SUPRS ;TYPE WITHOUT LEADING ZEROS
        TYPE    ,MABOVE     ;"ABOVE THE MAXIMUM OF"
        MOV     R2,-(SP)    ;PUT R2 ON THE STACK
        JSR     PC,@$$SB20  ;CHANGE R2 TO DECIMAL ASCIZ
        JSR     PC,@$$SUPRS ;TYPE WITHOUT LEADING ZEROS
3$:     TYPE    ,MSGMAX     ;"MAX="
        MOV     (R4)+,-(SP) ;PUT (R4)+ ON THE STACK
        JSR     PC,@$$SB20  ;CHANGE (R4)+ TO DECIMAL ASCIZ
        JSR     PC,@$$SUPRS ;TYPE WITHOUT LEADING ZEROS
        TYPE    ,MSGOUS     ;" "
        TST    (R4)+       ;ANY SEEKS ABOVE THE HIGH LIMIT
        BR     4$          ;NO--BRANCH
        TYPE    ,MSG.SP     ;" "
        MOV     -2(R4),-(SP) ;PUT -2(R4) ON THE STACK
        JSR     PC,@$$SB20  ;CHANGE -2(R4) TO DECIMAL ASCIZ
        JSR     PC,@$$SUPRS ;TYPE WITHOUT LEADING ZEROS
        TYPE    ,MABOVE     ;"ABOVE THE MAXIMUM OF"
        MOV     R2,-(SP)    ;PUT R2 ON THE STACK
        JSR     PC,@$$SB20  ;CHANGE R2 TO DECIMAL ASCIZ
        JSR     PC,@$$SUPRS ;TYPE WITHOUT LEADING ZEROS

```

```

5307 027440 104401 043675
5308 027444 104401 043666
5309 027450 012446
5310 027452 012446
5311 027454 012446
5312 027456 004737 023562
5313 027462 006126
5314 027464 100001
5315 027466 005216
5316 027470
5317 027470 004737 023170
5318 027474 004737 023420
5319 027500 104401 043675
5320 027504 104401 044010
5321 027510 016446 177776
5322 027514 004737 023170
5323 027520 004737 023420
5324 027524 104401 043760
5325 027530 010537 027254
5326 027534 001404
5327 027536 005005
5328 027540 000644
5329 027542 104401 043775
5330 027546 000200
5331
5332
5333
5334
5335
5336
5337
5338
5339 027550 020237 001520
5340 027554 001410
5341 027556 063702 001522
5342 027562 020237 001520
5343 027566 003402
5344 027570 013702 001520
5345 027574 005720
5346 027576 000200
5347
5348
5349
5350
5351
5352
5353
5354
5355
5356 027600 020137 001512
5357 027604 001410
5358 027606 063701 001514
5359 027612 020137 001512
5360 027616 003402
5361 027620 013701 001512
5362 027624 005720

45:  TYPE      ,MSGOUS
      TYPE      ,MSGAVG      ;"AVG="
      MOV       (R4)+,-(SP)  ;FORM THE AVERAGE
      MOV       (R4)+,-(SP)
      MOV       (R4)+,-(SP)
      JSR       PC,2#5DIV
      ROL       (SP)+
      BPL       55          ;IS THE REMAINDER OVER HALF?
      INC       (SP)       ;NO--BRANCH
                          ;YES--ROUND UP

55:  JSR       PC,2#5B2D      ;CHANGE TO DECIMAL ASCIZ
      JSR       PC,2#5SUPRS  ;TYPE WITHOUT LEADING ZEROS
      TYPE      ,MSGOUS
      TYPE      ,MSG.SP
      MOV       -2(R4),-(SP) ;PUT -2(R4) ON THE STACK
      JSR       PC,2#5B2D    ;CHANGE -2(R4) TO DECIMAL ASCIZ
      JSR       PC,2#5SUPRS  ;TYPE WITHOUT LEADING ZEROS
      TYPE      ,MSGNUM
      MOV       R5,25        ;"SEEKS TIMED"
      BEQ       75          ;NEXT MESSAGE POINTER
      CLR       R5          ;IF NONE EXIT
      BR        15          ;NO MORE THAN 2

65:  TYPE      ,MSGNON
75:  RTS       R0           ;EXIT

;THIS SUBROUTINE WILL INCREMENT THE TRACK
;NUMBER (R2) BY THE AMOUNT SPECIFIED BY 'IT'.
;CALL
;      JSR     R0,2#INCTRK
;      RETURN1
;      RETURN2
;          ;TRACK NUMBER GREATER THAN LT15
;          ;TRACK NUMBER INCREMENTED

INCTRK: CMP     R2,2#LT
        BEQ     25
        ADD     2#IT,R2
        CMP     R2,2#LT
        BLE     15
        MOV     2#LT,R2
15:     TST     (R0)+
25:     RTS     R0
        ;LAST TRACK COMPLETED?
        ;YES--EXIT
        ;NO--UPDATE TRACK
        ;TRACK TO BIG?
        ;NO--EXIT
        ;YES--SET TRACK TO LAST TRACK
        ;ADJUST FOR RETURN 2
        ;RETURN

;THIS SUBROUTINE WILL INCREMENT THE CYLINDER
;NUMBER (R1) BY THE AMOUNT SPECIFIED BY 'IC'.
;CALL
;      JSR     R0,2#INCCYL
;      RETURN1
;      RETURN2
;          ;CYLINDER NUMBER GREATER THAN LC15
;          ;CYLINDER NUMBER INCREMENTED

INCCYL: CMP     R1,2#LC
        BEQ     25
        ADD     2#IC,R1
        CMP     R1,2#LL
        BLE     15
        MOV     2#LC,R1
15:     TST     (R0)+
        ;LAST CYLINDER COMPLETED?
        ;YES--EXIT
        ;NO--UPDATE CYLINDER
        ;CYLINDER TO BIG?
        ;NO--EXIT
        ;YES--SET CYLINDER TO LAST CYLINDER
        ;ADJUST FOR RETURN 2
    
```



```

5363 027626 000200      2$:   RTS      RO          ;RETURN
5364
5365                  ;THIS ROUTINE DECREMENTS THE SECTOR ADDRESS.
5366                  ;CALL
5367                  ;
5368                  ;   CLR      -(SP)          ;CLEAR THE STACK
5369                  ;   JSR      PC,DECSEC      ;SUBROUTINE ENTRY
5370                  ;   RETURN
5371 027630 113766 004212 000002 DECSEC: MOVB    RP,REG+RPOA,2(SP) ;PUT THE SECTOR ADDRESS ON THE STACK
5372 027636 005366 000002      DEC    2(SP)          ;DECREMENT THE ADDRESS
5373 027642 100003      BPL    1$              ;BR IF NOT CORRECTION NEEDED
5374 027644 013766 001634 000002      MOV    PRMLMT+22.,2(SP) ;OVERFLOW OCCURED, FORCE TO MAXIMUM ADDRESS
5375 027652 000207      1$:   RTS      PC          ;RETURN
5376
5377                  ;THIS SUBROUTINE IS USED TO FILL THE DATA BUFFER
5378                  ;WITH ADDRESSES FROM 0 TO 21 WITH EACH ADDRESS
5379                  ;BEING STORED IN 256 CONSECUTIVE LOCATIONS
5380                  ;CALL
5381                  ;   JSR      PC,2#FILBUF
5382                  ;   RETURN
5383
5384 027654 104412      FILBUF: SAVREG          ;SAVE RO - RS
5385 027656 005000      CLR    RO              ;FIRST DISK ADDRESS
5386 027660 012701 047662      MOV    #BUFFER,R1      ;START FILLING HERE
5387 027664 012702 000400      1$:   MOV    #256,R2      ;DO 256 WORDS
5388 027670 010021      2$:   MOV    RO,(R1)+      ;STORE
5389 027672 005302      DEC    R2              ;MORE?
5390 027674 003375      BGT    2$              ;YES--BRANCH
5391 027676 005200      INC    RO              ;NO--UPDATE DISK ADDRESS
5392 027700 023700 001630      CMP    PRMLMT+22,RO    ;DONE?
5393 027704 103367      BHS    1$              ;NO--BRANCH
5394 027706 104413      RESREG          ;RESTORE RO - RS
5395 027710 000207      RTS      PC          ;RETURN
5396
5397                  ;THIS ROUTINE WILL CLEAR THE BUFFER BY
5398                  ;SETTING EACH WORD TO "177400".
5399                  ;CALL
5400                  ;   JSR      RO,2#CLRBUF
5401                  ;   RETURN
5402
5403 027712 104412      CLRBUF: SAVREG          ;SAVE RO - RS
5404 027714 012701 177400      MOV    #177400,R1      ;WORD TO FILL BUFFER WITH
5405 027720 012702 047662      MOV    #BUFFER,R2      ;FIRST ADDRESS OF BUFFER
5406 027724 012703 075662      MOV    #BUFFER+(512.*22.),R3 ;LAST ADDRESS+2 OF BUFFER
5407 027730 010122      1$:   MOV    R1,(R2)+      ;FILL WORDS 1, 9,...249,...5625
5408 027732 010122      MOV    R1,(R2)+      ;FILL WORDS 2,10,...250,...5626
5409 027734 010122      MOV    R1,(R2)+      ;FILL WORDS 3,11,...251,...5627
5410 027736 010122      MOV    R1,(R2)+      ;FILL WORDS 4,12,...252,...5628
5411 027740 010122      MOV    R1,(R2)+      ;FILL WORDS 5,13,...253,...5629
5412 027742 010122      MOV    R1,(R2)+      ;FILL WORDS 6,14,...254,...5630
5413 027744 010122      MOV    R1,(R2)+      ;FILL WORDS 7,15,...255,...5631
5414 027746 010122      MOV    R1,(R2)+      ;FILL WORDS 8,16,...256,...5632
5415 027750 020203      CMP    R2,R3          ;DONE?
5416 027752 103766      BLO    1$              ;NO--BRANCH
5417 027754 104413      RESREG          ;RESTORE RO - RS
5418 027756 000200      RTS      RO          ;RETURN FROM CALL
    
```

```

5419
5420
5421
5422
5423
5424
5425
5426
5427 027760 104412
5428 027762 162756 000004
5429 027766 005001
5430 027770 012716 047662
5431 027774 005066 000002
5432 030000 012702 000020
5433 030004 011603
5434 030006
5435 030006 020123
5436 030010 001063
5437 030012 020123
5438 030014 001061
5439 030016 020123
5440 030020 001057
5441 030022 020123
5442 030024 001055
5443 030026 020123
5444 030030 001053
5445 030032 020123
5446 030034 001051
5447 030036 020123
5448 030040 001047
5449 030042 020123
5450 030044 001045
5451 030046 020123
5452 030050 001043
5453 030052 020123
5454 030054 001041
5455 030056 020123
5456 030060 001037
5457 030062 020123
5458 030064 001035
5459 030066 020123
5460 030070 001033
5461 030072 020123
5462 030074 001031
5463 030076 020123
5464 030100 001027
5465 030102 020123
5466 030104 001025
5467 030106 005302
5468 030110 001336
5469 030112 062716 001000
5470 030116 005201
5471 030120 023701 001630
5472 030124 103325
5473 030126 005766 000002
5474 030132 001406

```

```

; THIS ROUTINE IS USED TO CHECK THE DATA BUFFER
; FOR ADDRESSES 0 THROUGH 21 WITH EACH ADDRESS
; BEING STORED IN 256 CONSECUTIVE LOCATIONS
; CALL
; JSR      RO,2#CKSCTR
; RETURN
CKSCTR: SAVREG      ;SAVE R0 - R5
SUB      #4,SP      ;RESERVE TEMP. STORAGE AREA
CLR      R1         ;FIRST SECTOR
MOV      #BUFFER,(SP) ;FIRST ADDRESS OF DATA BUFFER
CLR      2(SP)      ;NO ERRORS
15:      MOV      #16.,R2 ;LOOP COUNT (16*16=256)
        MOV      (SP),R3 ;GET 1ST ADDRESS OF THIS SECTORS DATA
25:      CMP      R1,(R3)+ ;WORD 1
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 2
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 3
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 4
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 5
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 6
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 7
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 8
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 9
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 10
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 11
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 12
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 13
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 14
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 15
        BNE      7$      ;BRANCH IF BAD
        CMP      R1,(R3)+ ;WORD 16
        BNE      7$      ;BRANCH IF BAD
        DEC      R2      ;FINISHED WITH THIS SECTORS DATA?
        BNE      25$    ;NO--BRANCH
35:      ADD      #512.,(SP) ;YES--FIRST ADDRESS OF NEXT SECTOR
        INC      R1      ;MOVE TO NEXT SECTOR
        CMP      PRMLMT+22,R1 ;DONE?
        BHS     1$      ;NO--BRANCH
45:      TST     2(SP)   ;ERROR OCCUR?
        BEQ     6$      ;0--BRANCH

```

```

5475 030134 123737 001364 001103      CMPB  @ERR.CT,@SERFLG ;MAX. ERROR OCCURRED?
5476 030142 101002                      BHI   6$
5477 030144 013700 001252      5$:  MOV  @BYPASS,R0      ;TAKE ERROR EXIT
5478 030150 062706 000004      6$:  ADD  #4,SP          ;FREE TEMP. AREA
5479 030154 104413                      RESREG
5480 030156 001300                      RTS   R0              ;RETURN FROM CALL
5481 030160 010304      7$:  MOV  R3,R4          ;FORM WORD NUMBER AND
5482 030162 161604                      SUB  (SP),R4         ;ADDRESS TO CONTINUE FROM
5483 030164 010415                      MOV  R4,R5
5484 030166 006204                      ASR  R4              ;WORD NUMBER
5485 030170 042705 177740                      BIC  #1C37,R5
5486 030174 001002                      BNE  8$              ;BRANCH IF NOT A MULTIPLE OF 16
5487 030176 012705 000040      8$:  MOV  #40,R5         ;SET TO WORD 16
5488 030202 006305                      ASL  R5
5489 030204 062705 030006      9$:  ADD  #25,R5         ;ADDRESS
5490 030210 016337 177776 001126      MOV  -2(R3),@#1BDUAT ;SAVE BAD DATA
5491 030216 005766 000002                      TST  2(SP)          ;FIRST ERROR?
5492 030222 001015                      BNE  10$            ;NO--BRANCH
5493 030224 013737 004176 001270      MOV  @#DTADPB+12,@#CYL.DS ;CYLINDER NUMBER
5494 030232 113737 004175 001274      MOV  @#DTADPB+11,@#TRK.DS ;TRACK NUMBER
5495 030240 012737 030250 001206      MOV  #9$,#ESCAPE    ;ESCAPE TO 9$ ON ERROR
5496 030246 104021                      ERROR 21            ;REPORT THE ERROR
5497 030250 105166 000002      9$:  COMB 2(SP)        ;SET ERROR SWITCH
5498 030254 000404                      BR   11$
5499 030256                      10$:
5500 030256 012737 030266 001206      MOV  #11$,#ESCAPE   ;ESCAPE TO 11$ ON ERROR
5501 030264 104022                      ERROR 22            ;REPORT THE ERROR
5502 030266 032777 001000 150644      11$: BIT  #SW09,@SWR   ;LOOP ON ERROR?
5503 030274 001323                      BNE  5$              ;YES
5504 030276 032777 000002 150634      BIT  #SW01,@SWR   ;STOP DATA COMPARE?
5505 030204 001310                      BNE  4$              ;YES--BRANCH
5506 030306 123737 001364 001103      CMPB  @ERR.CT,@SERFLG ;MAX. ERRORS?
5507 030314 101713                      BLOS 5$              ;YES--BRANCH
5508 030316 032777 000040 150614      BIT  #SW05,@SWR   ;REPORT ONLY 1ST ERROR PER SECTOR?
5509 030324 001272                      BNE  3$              ;YES--BRANCH
5510 030326 000115                      JMP  (R5)

```

: THIS ROUTINE WILL MOVE THE 16 WORDS OF THE  
: DESIRED PATTERN INTO THE DATA BUFFER.

```

: CALL
: MOV  @#NIX,R0      ;PATTERN NUMBER INDEX TO R0
: JSR  PC,@#SETBUF

```

```

SETBUF: SAVREG
: MOV  @#BUFFER,R1  ;SAVE R0 - R5
: MOV  @#DTADPB+4,R2 ;FIRST ADDRESS
: MOV  PAT.PT(R0),R3 ;WORD COUNT
1$:  MOV  (R3)+,(R1)+ ;PICKUP PATTERN POINTER
: MOV  WORD 1 INTO DATA BUFFER
: MOV  WORD 2 INTO DATA BUFFER
: MOV  WORD 3 INTO DATA BUFFER
: MOV  WORD 4 INTO DATA BUFFER
: MOV  WORD 5 INTO DATA BUFFER
: MOV  WORD 6 INTO DATA BUFFER
: MOV  WORD 7 INTO DATA BUFFER
: MOV  WORD 8 INTO DATA BUFFER
: MOV  WORD 9 INTO DATA BUFFER

```

```

5511
5512
5513
5514
5515
5516
5517
5518 030330 104412
5519 030332 012701 047612
5520 030336 013702 004173
5521 030342 016003 003044
5522 030346 012321
5523 030350 012321
5524 030352 012321
5525 030354 012321
5526 030356 012321
5527 030360 012321
5528 030362 012321
5529 030364 012321
5530 030366 012321

```

```

030370 012321 MOV (R3)+,(R1)+ ; MOVE WORD 10 INTO DATA BUFFER
030372 012321 MOV (R3)+,(R1)+ ; MOVE WORD 11 INTO DATA BUFFER
030374 012321 MOV (R3)+,(R1)+ ; MOVE WORD 12 INTO DATA BUFFER
030376 012321 MOV (R3)+,(R1)+ ; MOVE WORD 13 INTO DATA BUFFER
030408 012321 MOV (R3)+,(R1)+ ; MOVE WORD 14 INTO DATA BUFFER
030409 012321 MOV (R3)+,(R1)+ ; MOVE WORD 15 INTO DATA BUFFER
03040A 012321 MOV (R3)+,(R1)+ ; MOVE WORD 16 INTO DATA BUFFER
03040B 012321 MOV (R3)+,(R1)+
03040C 062702 ADD #16,R2 ; DONE?
030412 001353 BNE 15 ; NO-BRANCH
030414 104413 RESTREG ; RESTORE R0 - R5
030416 000207 RETURN

```

000020

: THIS ROUTINE COMPARES A 16 WORD DATA PATTERN  
: AGAINST THE DATA BUFFER

```

: CALL
: MOV     R0,R2          ; PATTERN NUMBER INDEX TO R0
: LSR    PC,C'DATCMP
: RETURN

```

```

DATCMP: SAVREG      ; SAVE R0 - R5
MOV     #BUFFER,R1  ; FIRST ADDRESS OF BUFFER
MOV     #DTADPB+4,R2 ; WORD COUNT
CLR     -(SP)       ; NO ERROR
15:    MOV     PAT.PT(R0),R3 ; PATTERN POINTER
25:

```

```

030420 104412 162321 SUB (R3)+,(R1)+ ; CHECK WORD 1
030422 012701 45 BNE 45 ; BRANCH IF DIFFERENT
030426 013702 162321 SUB (R3)+,(R1)+ ; CHECK WORD 2
030432 005046 45 BNE 45 ; BRANCH IF DIFFERENT
030434 016003 162321 SUB (R3)+,(R1)+ ; CHECK WORD 3
030440 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030442 001044 162321 SUB (R3)+,(R1)+ ; CHECK WORD 4
030444 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030446 001042 162321 SUB (R3)+,(R1)+ ; CHECK WORD 5
030450 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030452 001040 162321 SUB (R3)+,(R1)+ ; CHECK WORD 6
030454 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030456 162321 45 SUB (R3)+,(R1)+ ; CHECK WORD 7
030460 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030462 001034 162321 SUB (R3)+,(R1)+ ; CHECK WORD 8
030464 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030466 001032 162321 SUB (R3)+,(R1)+ ; CHECK WORD 9
030470 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030472 001030 162321 SUB (R3)+,(R1)+ ; CHECK WORD 10
030474 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030476 001026 162321 SUB (R3)+,(R1)+ ; CHECK WORD 11
030500 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030502 001024 162321 SUB (R3)+,(R1)+ ; CHECK WORD 12
030504 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030506 001022 162321 SUB (R3)+,(R1)+ ; CHECK WORD 13
030510 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030512 001020 162321 SUB (R3)+,(R1)+ ; CHECK WORD 14
030514 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030516 001016 162321 SUB (R3)+,(R1)+ ; CHECK WORD 15
030520 162321 45 BNE 45 ; BRANCH IF DIFFERENT
030522 001014 162321 SUB (R3)+,(R1)+ ; CHECK WORD 16
030524 162321 45 BNE 45
030526 001012 45 SUB (R3)+,(R1)+
030530 162321 45 BNE 45
030532 001010 45 SUB (R3)+,(R1)+
030534 162321 45 BNE 45

```

047662

004170

003044

```

5587 030536 001206          BNE      48          ; BRANCH IF DIFFERENT
5588 030540 062702 000020  ADD      #16.,R2     ; DONE ?
5589 030544 001333          BNE      18          ; NO--BRANCH
5590 030546 005726          TST      (SP)+       ; YES -- CLEAN UP STACK
5591 030550 104413          RESREG          ; RESTORE R0 - R5
5592 030552 000207          RTS      PC
5593 030554 010104          48:     MOV      R1,R4          ; FORM THE WORD NUMBER
5594 030556 162704 047662  SUB      #BUFFER,R4
5595 030562 006204          ASR      R4          ; WORD NUMBER
5596 030564 010305          MOV      R3,R5       ; FORM ADDRESS TO CONTINUE FROM
5597 030566 166005 003044  SUB      PAT.PT(R0),R5
5598 030572 006305          ASL      R5
5599 030574 062705 030440  ADD      #25,R5       ; ADDRESS
5600 030600 064341          ADD      -(R3),-(R1) ; RECONSTRUCT THE BAD WORD
5601 030602 010137 001122  MOV      R1,#$BDAOR  ; SAVE THE ERROR INFORMATION
5602 030606 010337 001120  MOV      R3,#$GDAOR
5603 030612 012137 001126  MOV      (R1)+,#$BDDAT
5604 030616 012337 001124  MOV      (R3)+,#$GDDAT
5605 030622 005716          TST      (SP)
5606 030624 001023          BNE      68          ; 1ST DATA COMPARE ERROR?
5607 030626 013737 004176 001270  MOV      #0TADPB+12,#CYL.DS ; CYLINDER
5608 030634 113737 004175 001274  MOV      #0TADPB+11,#TRK.DS ; TRACK
5609 030642 113737 004174 001272  MOV      #0TADPB+10,#SEC.DS ; SECTOR
5610 030650 016600 000016  MOV      16(SP),R0   ; GET TEST PC+4
5611 030654 012737 030664 001206  MOV      #55,SESCAPE ; ESCAPE TO 55 ON ERROR
5612 030662 104013          ERROR    13         ; REPORT THE ERROR
5613 030664 016600 000014  58:     MOV      14(SP),R0 ; PATTERN NUMBER INDEX
5614 030670 105116          COMB     (SP)       ; SET THE ERROR SWITCH
5615 030672 000404          BR      78
5616 030674          68:
5617 030674 012737 030704 001206  MOV      #78,SESCAPE ; ESCAPE TO 78 ON ERROR
5618 030702 104014          ERROR    14         ; REPORT THE ERROR
5619 030704 032777 000002 150226  78:     BIT      #5401,#SWR   ; STOP DATA COMPARE?
5620 030712 001315          BNE      38          ; YES--EXIT
5621 030714 123737 001364 001103  CMP      #ERR.CT,#SERFLG ; MAX. ERRORS?
5622 030722 101004          BHI      68          ; NO--BRANCH
5623 030724 013766 001252 000016  MOV      #BYPASS,16(SP) ; YES--ERROR EXIT
5624 030732 000705          BR      38
5625 030734 000115          88:     JNP      (R5)          ; NO--CONTINUE AT NEXT WORD
5626
5627 ; THIS ROUTINE WILL FILL THE DATA BUFFER (256*22 WORDS) WITH
5628 ; A RANDOM PATTERN. THE FIRST TWO WORDS OF EVERY 256 WILL
5629 ; BE THE BASE OF THE RANDOM NUMBER GENERATOR FOR THE
5630 ; NEXT 254 WORDS.
5631 ; NOTE: THIS ROUTINE DESTROYS R1 AND R2
5632 ; CALL
5633 ; JSR      RO,#FILRAN
5634 ; RETURN
5635
5636 030736 012701 047662  FILRAN: MOV      #BUFFER,R1
5637 030742 013702 001630  MOV      PRM.LMT+22,R2 ; MAXIMUM NUMBER OF SECTORS
5638 030746 004037 031156  18:     JSR      RO,#RANPAT
5639 030752 005302          DEC      R2
5640 030754 100374          BPL      18
5641 030756 000200          RTS      R0
5642

```

5643  
5644  
5645  
5646  
5647  
5648  
5649  
5650  
5651  
5652  
5653  
5654  
5655  
5656  
5657  
5658  
5659  
5660  
5661  
5662  
5663  
5664  
5665  
5666  
5667  
5668  
5669  
5670  
5671  
5672  
5673  
5674  
5675  
5676  
5677  
5678  
5679  
5680  
5681  
5682  
5683  
5684  
5685  
5686  
5687  
5688  
5689  
5690  
5691  
5692  
5693  
5694  
5695  
5696  
5697  
5698

030765 013746 023556  
030764 013746 023560  
030770 012702 050662  
030774 012701 051662  
031000 010103  
031002 011237 023560  
031006 016237 000002 023556  
031014 004037 031156  
031020 012637 023560  
031024 012637 023556  
031030 005046  
031032 162322  
031034 001441  
031036 012737 031110 001206  
031042 064342  
031044 010237 001122  
031046 010337 001120  
031048 012237 001126  
031050 012337 001124  
031052 010204  
031054 162704 050662  
031056 006204  
031058 005716  
031100 001002  
031102 105116  
031104 104015  
031106 104016  
031110 032777 001000 150022  
031116 001012  
031120 123737 001364 001103  
031126 101406  
031130 032777 000002 150002  
031136 001002  
031140 020103  
031142 101333  
031144 005726  
031146 001402  
031150 013700 001252  
031154 000200

```
; THIS ROUTINE USES THE FIRST TWO WORDS OF THE  
; READ BUFFER TO GENERATE A RANDOM PATTERN. THEN  
; THE READ BUFFER IS COMPARED TO THE PATTERN GENERATED.  
; NOTE: THIS ROUTINE DESTROYS R1-R4  
CALL  
; JSR RO, @#RANCK  
; RETURN  
RANCK: MOV @#SHINUM, -(SP) ; SAVE THE PRESENT RANDOM NUMBER  
MOV @#SLONUM, -(SP) ; READ BUFFER ADDRESS  
MOV @BUFFER+512., R2 ; RANDOM PATTERN ADDRESS  
MOV @BUFFER+1024., R1 ; COPY IT INTO R3 FOR LATER USE  
MOV R1, R3 ; PRIME THE RANDOM NUMBER GENERATOR  
MOV (R2), @#SLONUM  
MOV 2(R2), @#SHINUM  
JSR RO, @#RANPAT ; GENERATE A RANDOM PATTERN  
MOV (SP)+, @#SLONUM ; RESTORE PRESENT RANDOM NUMBER  
MOV (SP)+, @#SHINUM  
CLR -(SP) ; NO ERRORS  
18: SUB (R3)+, (R2)+ ; ARE THESE TWO WORDS DIFFERENT?  
BEQ 48 ; NO--BRANCH  
MOV @38, @#ESCAPE ; ESCAPE TO 38 ON ERROR  
ADD -(R3), -(R2) ; RECREATE THE BAD WORD  
MOV R2, @#BADADR ; ADDRESS OF BAD DATA  
MOV R3, @#GOODADR ; ADDRESS OF GOOD DATA  
MOV (R2)+, @#BADDAT ; BAD DATA  
MOV (R3)+, @#GOODAT ; GOOD DATA  
MOV R2, R4 ; FORM WORD NUMBER (1 TO 256)  
SUB @BUFFER+512., R4  
ASR R4  
TST (SP) ; FIRST ERROR  
BNE 18 ; NO--BRANCH  
COMB (SP) ; YES--SET ERROR SWITCH  
ERROR 15 ; REPORT THE ERROR  
ERROR 16 ; REPORT THE ERROR  
28: BIT @SW09, @SWR ; LOOP ON ERROR?  
38: BNE 58 ; YES--BRANCH  
CMPB @#ERR.CT, @#SERFLG ; MAX. ERRORS OCCURRED?  
BLOS 58 ; YES--BRANCH  
BIT @SW01, @SWR ; STOP COMPARING?  
BNE 58 ; YES--BRANCH  
48: CMP R1, R3 ; ALL DATA BEEN COMPARED?  
BHI 18 ; NO--BRANCH  
58: TST (SP)+ ; ERROR OCCUR?  
BEQ 58 ; NO--BRANCH  
MOV @#BYPASS, RO ; TAKE ERROR EXIT  
68: RTS RO ; EXIT
```

```
; THIS ROUTINE FILLS A 256 WORD BUFFER WITH A RANDOM  
; PATTERN OF WHICH THE FIRST TWO WORDS ARE THE BASE  
; OF THE PATTERN.  
CALL  
MOV @ADR, R1 ; ADDRESS OF THE BUFFER  
JSR RO, @#RANPAT  
RETURN
```

```

5699 031156 010246          RANPAT: MOV     R2,-(SP)      ;SAVE R2
5700 031160 012702 000200      MOV     #256./2.,R2      ;GENERATE 256 WORDS
5701 031164 000402          BR      2$
5702 031166 004737 023460      1$: JSR     PC,@$RAND      ;GENERATE A RANDOM NUMBER
5703 031172 013721 023560      2$: MOV     @#$LONUM,(R1)+ ;PUT LOW WORD IN BUFFER
5704 031176 013721 023556      MOV     @#$HINUM,(R1)+ ;PUT HIGH WORD IN BUFFER
5705 031202 005302          DEC     R2              ;DONE?
5706 031204 003370          BGT     1$             ;NO--BRANCH
5707 031206 012602          MOV     (SP)+,R2       ;RESTORE R2
5708 031210 000200          RTS      R0            ;EXIT
5709
5710
5711
5712
5713
5714
5715
5716
5717 031212 004737 023460      RANADR: JSR     PC,@$RAND      ;GENERATE A RANDOM NUMBER
5718 031216 113701 023560      MOV     @#$LONUM,R1     ;FORM SECTOR IN R1
5719 031222 113702 023561      MOV     @#$LONUM+1,R2   ;FORM TRACK IN R2
5720 031226 013703 023556      MOV     @#$HINUM,R3     ;FORM CYLINDER IN R3
5721 031232 105701          TST     R1              ;ENSURE THE SECTOR IS BETWEEN 0 AND 21
5722 031234 002403          BLT     2$
5723 031236 123701 001630      1$: CMP     PRMLHT+22,R1 ;CHECK MAXIMUM SECTOR ADDRESS
5724 031242 103003          BHS     3$
5725 031244 000241          CLC
5726 031246 106001          RORB   R1
5727 031250 000772          BR      1$
5728 031252 105702          3$: TST     R2              ;ENSURE THE TRACK IS BETWEEN 0 AND 18
5729 031254 002403          BLT     5$
5730 031256 122702 000023      4$: CMP     #19.,R2
5731 031262 003003          BGT     6$
5732 031264 000241          5$: CLC
5733 031266 106002          RORB   R2
5734 031270 000772          BR      4$
5735 031272 023703 001510      6$: CMP     @#FC,R3        ;ENSURE THE CYLINDER IS BETWEEN FC AND LC
5736 031276 003413          BLE     7$
5737 031300 000241          CLC
5738 031302 006003          ROR    R3
5739 031304 005503          ADC    R3
5740 031306 001371          BNE    6$
5741 031310 010103          MOV     R1,R3
5742 031312 000303          SWAB  R3
5743 031314 062203          ADD    R2,R3
5744 031316 005203          INC    R3
5745 031320 003364          BGT    6$
5746 031322 005403          NEG    R3
5747 031324 000762          BR      6$
5748 031326 023703 001512      7$: CMP     @#LC,R3
5749 031328 002003          BGE    8$
5750 031334 000241          CLC
5751 031336 006003          ROR    R3
5752 031340 000772          BR      7$
5753 031342 023703 001510      8$: CMP     @#FC,R3
5754 031346 003403          BLE     9$
    
```

THIS ROUTINE GENERATES RANDOM CYLINDER, TRACK, AND SECTOR ADDRESSES AND SAVES THEM IN THE DPB (DTADPB+10 AND DTADPB+12).  
 NOTE: THIS ROUTINE DESTROYS R1-R3  
 CALL  
 JSR R0,@\$RANADR  
 RETURN



5755 031350 005203  
5756 031352 000303  
5757 031354 000764  
5758 031356 110137 004174  
5759 031362 110237 004175  
5760 031366 010337 004176  
5761 031372 000200  
5762  
5763  
5764  
5765  
5766  
5767  
5768  
5769  
5770  
5771 031374 032777 000200 147536  
5772 031402 001430  
5773 031404 104401 031412  
5774 031410 000410  
5775  
5776 031422  
5777 031432 012703 043020  
5778 031436 013704 001220  
5779 031442 004037 031466  
5780 031446 000771  
5781 031450 000240  
5782 031452 013737 001220 001222  
5783 031460 010437 001220  
5784 031464 000207  
5785  
5786  
5787  
5788  
5789  
5790  
5791  
5792  
5793  
5794  
5795  
5796  
5797  
5798  
5799  
5800  
5801 031466 010337 031474  
5802 031472 104401  
5803 031474 000000  
5804 031476 010446  
5805 031500 104402  
5806 031502 104401 043044  
5807 031506 104411  
5808 031510 012601  
5809 031512 004037 033736  
5810 031516 031472

```
INC R3
SWAB R3
BR 7$
9$: MOV R1, @DTADPB+10 ;SAVE SECTOR ADDRESS
MOV R2, @DTADPB+11 ;SAVE TRACK ADDRESS
MOV R3, @DTADPB+12 ;SAVE CYLINDER ADDRESS
RTS R0 ;RETURN

;THIS ROUTINE IS USED TO INPUT THE "CONTROL SWITCHES".
;IF SWR<07>=1 THE PRESENT SETTING WILL BE TYPED AND THE NEW
;SETTING IS READ AND STORED.
;NOTE: THIS ROUTINE DESTROYS R3 AND R4
CALL
JSR PC, @GETSWR
RETURN ;(C.SWR)=DESIRED CONTROL SWITCHES

GETSWR: BIT @SW07, @SWR ;READ CONTROL SWITCHES?
BEQ 2$ ;NO--BRANCH
TYPE 65$ ;TYPE ASCIZ STRING
BR 64$ ;GET OVER THE ASCIZ
65$: .ASCIZ <CR><LF>/SET SWR<07>=0/
64$:
1$: MOV @MSG.CS, R3 ;"CONTROL SWITCHES="
MOV @C.SWR, R4 ;PRESENT CONTROL SWITCH SETTINGS
JSR R0, @GETNUM ;GET THE NEW SWITCH SETTINGS
BR 1$ ;COMMA
NOP ;PERIOD
MOV C.SWR, SAVCSW ;SAVE PREVIOUS VALUE
MOV R4, @C.SWR ;DOUBLE PERIOD--SAVE NEW SWITCH SETTING
2$: RTS PC ;RETURN FROM CALL

;THIS ROUTINE WILL TYPE AN ASCIZ MESSAGE AND THEN
;INPUT AN ASCIZ STRING AND CHANGE THE STRING TO OCTAL
;IF REQUIRED.
;NOTE: THIS ROUTINE DESTROYS R1
CALL
MOV @ADR, R3 ;ADDRESS OF ASCIZ MESSAGE
MOV @NUM, R4 ;OCTAL NUMBER
JSR R0, @GETNUM
RETURN1 ;INPUT TERMINATED WITH A COMMA
RETURN2 ;WITH A PERIOD
RETURN3 ;WITH A DOUBLE PERIOD
;R4=INPUT NUMBER AND
;R2=R4*32 FOR ALL
;THREE RETURNS

GETNUM: MOV R3, 2$ ;SAVE MESSAGE POINTER
1$: TYPE ;TYPE THE MESSAGE
2$: .WORD 0 ;MESSAGE POINTER GOES HERE
MOV R4, -(SP) ;SAVE R4 FOR TYPEOUT
TYPOC ;GO TYPE--OCTAL ASCII(ALL DIGITS)
TYPE , SLASH /
RDLIN ;READ AN ASCIZ STRING
MOV (SP)+, R1 ;ADDRESS OF FIRST CHARACTER
JSR R0, @CK.CHR ;CHECK ONE CHARACTER
1$ ;ILLEGAL CHARACTER
```

```

5811 031520 031472          1$          :CARRIAGE RETURN
5812 031522 031534          3$          :"/
5813 031524 031560          7$          :".
5814 031526 031566          8$          :'.
5815 031530 031532          11$         :DIGIT 0-9
5816 031532 005301          11$: DEC      R1          :DECREMENT THE INPUT POINTER
5817 031534
5818 031534 004037 034176          3$: JSR      RO, @CK.NUM :CHECK THE NUMBER
5819 031540 031472          1$          :ILLEGAL INPUT
5820 031542 031554          6$          :TERMINATED WITH A "." OR "CR"
5821 031544 031552          5$          :TERMINATED WITH A "!"
5822 031546 031550          4$          :TERMINATED WITH A "..."
5823 031550 C 5720          4$: TST      (R0)+       :DOUBLE PERIOD
5824 031552 005720          5$: TST      (R0)+       :SINGLE PERIOD
5825 031554 010204          6$: MOV      R2, R4      :COMMA--SAVE INPUT NUMBER
5826 031556 000414          BR 10$      :GO TO EXIT
5827 031560 105711          7$: TSTB    (R1)        :TERMINATOR AFTER A COMMA?
5828 031562 001343          BNE 1$      :NO--LOOP
5829 031564 000411          BR 10$      :YES--EXIT
5830 031566 105711          8$: TSTB    (R1)        :TERMINATOR AFTER A PERIOD?
5831 031570 001406          BEQ 9$      :YES--EXIT
5832 031572 122721 000056          CMPB    #'., (R1)+   :NO--DOUBLE PERIOD?
5833 031576 001335          BNE 1$      :NO--LOOP
5834 031600 105711          TSTB    (R1)        :YES--TERMINATOR?
5835 031602 001333          BNE 1$      :NO--LOOP
5836 031604 005720          TST      (R0)+       :DOUBLE PERIOD
5837 031606 005720          9$: TST      (R0)+       :PERIOD
5838 031610 010402          10$: MOV     R4, R2      :COMMA--POSITION THE
5839 031612 000302          SWAB    R2          :NUMBER IN CASE IT
5840 031614 006202          ASR     R2          :IS THE PRIORITY LEVEL
5841 031616 006202          ASR     R2
5842 031620 006202          ASR     R2
5843 031622 000200          RTS      R0          :EXIT
5844
5845
5846
5847
5848
5849
5850
5851 031624 104412          GT.PRM: SAVREG          :SAVE R0 - R5
5852 031626 005037 001232          GT.PRI: CLR      DRVSEL :NO DRIVE SELECTED
5853 031632 104401 031640          TYPE    65$          :TYPE ASCIZ STRING
5854 031636 000406          BR 64$          :GET OVER THE ASCIZ
5855
5856          65$: .ASCIZ <CR><LF>/DRIVE(S)=/
5857          64$:
5858 031654 104411          ROLIN
5859 031656 012601          MOV     (SP)+, R1    :READ TTY
5860 031660 004037 033736          JSR     RO, @CK.CHR  :ADDRESS OF ASCIZ STRING
5861 031664 031626          GT.PRI          :CHECK ONE CHARACTER
5862 031666 031626          GT.PRI          :ILLEGAL CHARACTER
5863 031670 031626          GT.PRI          :CARRIAGE RETURN
5864 031672 031626          GT.PRI          :"/
5865 031674 031626          GT.PRI          :".
5866 031676 031700          1$: DEC      R1          :DIGIT 0-9
5866 031700 005301

```

```

5867 031702          25:
5868 031702 012702 000007      MOV      #7,R2      ;UPPER LIMIT OF INPUT
5869 031706 004037 034012      JSR      RO,@#CK.DIG ;CHECK THE DIGIT(S)
5870 031712 031626          GT.PRI1      ;ILLEGAL INPUT
5871 031714 031626          GT.PRI1      ;INPUT TO LARGE
5872 031716 031724          35:          ;TERMINATED WITH A "." OR "CR"
5873 031720 031750          45:          ;TERMINATED WITH A "."
5874 031722 031750          45:          ;TERMINATED WITH A "."
5875 031724 156237 034452 001232 35:      BISB     ATABIT(R2),DRVSEL ;SET THE DRIVE SELECTED BIT
5876 031732 105741          TSTB     -(R1)      ;WAS THE LINE TERMINATED?
5877 031734 001362          BNE     25        ;NO-GET THE NEXT DRIVE
5878 031736 005037 001234      CLR     @#TSTNMS   ;DESELECT ALL TESTS
5879 031742 005037 001236      CLR     TSTNMS+2
5880 031746 000405          BR      GTTST1    ;YES--SELECT TEST
5881 031750 156237 034452 001232 45:      BISB     ATABIT(R2),DRVSEL ;SET THE SELECTED DRIVE BITS
5882 031756 104413          GT.PR2:  RESREG   ;RESTORE RO - R5
5883 031760 000207          RTS     PC        ;EXIT
5884
5885 031762          GTTST1:
5886 031762 104401 031770      TYPE     655      ;:TYPE ASCIZ STRING
5887 031766 000403          BR      645      ;:GET OVER THE ASCIZ
5888
5889 031776          ;:655: .ASCIZ /TEST=/
5890 031776 104411          645:
5891 032000 012601          ROLIN    ;:READ AN ASCIZ STRING
5892 032002 122711 000056      MOV     (SP)+,R1  ;:POINTER TO R1
5893 032006 001007          CMPB    #'.,(R1) ;:DOUBLE PERIOD?
5894 032010 122761 000056 000001  BNE     15        ;:NO--BRANCH
5895 032016 001003          CMPB    #'.,1(R1)
5896 032020 105761 000002          BNE     15
5897 032024 001754          TSTB    2(R1)    ;:"CR"?
5898 032026 005037 001234      BEQ     GT.PR2   ;:YES--EXIT
5899 032032 005037 001236      CLR     TSTNMS   ;:NO TEST SELECTED
5900 032036 005037 001240      CLR     TSTNMS+2
5901 032042 005037 001242      CLR     OPNFLG   ;:NO TESTS TO BE OPENED
5902 032046 121127 000123      CLR     OPNFLG+2
5903 032052 001004          GTTST2: CMPB    (R1),#'S  ;:ALL SEEK TESTS?
5904 032054 052737 000777 001234  BNE     15        ;:NO--BRANCH
5905 032062 000552          BIS     #777,TSTNMS ;:YES--SELECT TESTS 0-10
5906 032064 121127 000124      BR      GTTST3
5907 032070 001004          15:      CMPB    (R1),#'T  ;:ALL TIMING TESTS?
5908 032072 052737 036000 001234  BNE     25        ;:NO--BRANCH
5909 032100 000543          BIS     #36000,TSTNMS ;:YES--SELECT TESTS 12-15
5910 032102 121127 000101      BR      GTTST3
5911 032106 001004          25:      CMPB    (R1),#'A  ;:ALL ADDRESSING TESTS?
5912 032110 052737 140000 001234  BNE     35        ;:NO--BRANCH
5913 032116 000534          BIS     #140000,TSTNMS ;:YES--SELECT TESTS 16 & 17
5914 032120 121127 000104      BR      GTTST3
5915 032124 001004          35:      CMPB    (R1),#'D  ;:DATA TEST?
5916 032126 052737 000001 001236  BNE     45        ;:NO--BRANCH
5917 032134 000525          BIS     #1,TSTNMS+2 ;:YES--SELECT TEST 20
5918 032136 121127 000105      BR      GTTST3
5919 032142 001004          45:      CMPB    (R1),#'E  ;:EXERCISER TEST?
5920 032144 052737 000002 001236  BNE     55        ;:NO--BRANCH
5921 032152 000516          BIS     #2,TSTNMS+2 ;:YES--SELECT TEST 21
5922 032154 004037 033662      BR      GTTST3
                    JSR     RO,@#CK.OCT ;:OCTAL DIGIT?
    
```

5923	032160	000514		BR	GTTST4	:NO--BRANCH
5924	032162	010205		MOV	R2,R5	:YES--SAVE IT
5925	032164	005201		INC	R1	:MOVE TO NEXT CHARACTER
5926	032166	004037	033662	JSR	R0,2#CK.OCT	:OCTAL DIGIT
5927	032172	000405		BR	6\$	:NO--BRANCH
5928	032174	005201		INC	R1	:MOVE TO NEXT CHARACTER
5929	032176	006305		ASL	R5	:SCALE HIGH DIGIT
5930	032200	006305		ASL	R5	
5931	032202	006305		ASL	R5	
5932	032204	060502		ADD	R5,R2	:COMBINE HIGH & LOW DIGITS
5933	032206	020227	000022	6\$: CMP	R2,#\$TN-1	:VALID TEST NUMBER?
5934	032212	003263		BGT	GTTST1	:NO--BRANCH
5935	032214	010237	032406	MOV	R2,9\$	:SAVE THE TEST NUMBER
5936	032220	010204		MOV	R2,R4	:CONVERT TEST NUMBER INTO AN INDEX
5937	032222	042704	000017	BIC	#17,R4	:CLEAR UNWANTED BITS
5938	032226	006204		ASR	R4	:SHIFT THE BITS
5939	032230	006204		ASR	R4	:SHIFT THE BITS
5940	032232	006204		ASR	R4	:SHIFT THE BITS
5941	032234	006302		ASL	R2	
5942	032236	056264	001424 001234	BIS	BITS(R2),TSTNMS(R4)	:SELECT TEST
5943	032244	121127	000055	CMPB	(R1),#'-	:TEST STRING?
5944	032250	001060		BNE	GTTST4	:NO--BRANCH
5945	032252	005201		INC	R1	:YES--MOVE TO NEXT CHARACTER
5946	032254	004037	033662	JSR	R0,2#CK.OCT	:OCTAL DIGIT?
5947	032260	000640		BR	GTTST1	:NO--BRANCH
5948	032262	010205		MOV	R2,R5	:YES--SAVE IT
5949	032264	005201		INC	R1	:MOVE TO NEXT CHARACTER
5950	032266	004037	033662	JSR	R0,2#CK.OCT	:OCTAL DIGIT?
5951	032272	000405		BR	7\$	:NO--BRANCH
5952	032274	005201		INC	R1	:YES--MOVE TO NEXT CHARACTER
5953	032276	006305		ASL	R5	:SCALE HIGH DIGIT
5954	032300	006305		ASL	R5	
5955	032302	006305		ASL	R5	
5956	032304	060502		ADD	R5,R2	:COMBINE HIGH & LOW DIGIT
5957	032306	020227	000022	7\$: CMP	R2,#\$TN-1	:VALID TEST NUMBER?
5958	032312	003223		BGT	GTTST1	:NO--BRANCH
5959	032314	023702	032406	CMP	9\$,R2	:IS THE FIRST NUMBER OF THE
5960						:STRING SMALLER THAN THE LAST?
5961	032320	002220		BGE	GTTST1	:NO--BRANCH
5962	032322	010246		MOV	R2,-(SP)	:SAVE ENDING TEST NUMBER
5963	032324	013702	032406	MOV	9\$,R2	:GET STARTING TEST NUMBER
5964	032330	012637	032406	MOV	(SP)+,9\$	:STORE ENDING TEST NUMBER
5965	032334	006337	032406	ASL	9\$	:SHIFT ENDING TEST NUMBER
5966	032340	006302		ASL	R2	:SHIFT TEST NUMBER
5967	032342	010204		MOV	R2,R4	:COPY TEST NUMBER INTO R4
5968	032344	042704	000037	BIC	#37,R4	:CLEAR LOWER BITS
5969	032350	006204		ASR	R4	:SHIFT THE TEST NUMBER
5970	032352	006204		ASR	R4	:SHIFT THE TEST NUMBER
5971	032354	006204		ASR	R4	:SHIFT THE TEST NUMBER
5972	032356	006204		ASR	R4	:SHIFT THE TEST NUMBER
5973	032360	056264	001424 001234	BIS	BITS(R2),TSTNMS(R4)	:SELECT THE TEST
5974	032366	062702	000002	ADD	#2,R2	:INCREMENT THE TEST NUMBER
5975	032372	020237	032406	CMP	R2,9\$	:SEE IF FINISHED
5976	032376	101761		BLOS	8\$	:BR IF NOT
5977	032400	162702	000002	SUB	#2,R2	:CORRECT TEST NUMBER
5978	032404	000402		BR	GTTST4	:CONTINUE

```

5979 032406 000000          9$: .WORD 0          ;STORE TEST NUMBER HERE
5980 032410 005201          GTTST3: INC R1          ;MOVE TO NEXT CHARACTER
5981 032412 121127 000056    GTTST4: CMPB (R1),#'    ;"PERIOD"?
5982 032416 001441          BEQ GTTST5          ;YES--BRANCH
5983 032420 005737 001234    TST TSTNMS          ;ANY TEST SELECTED THIS CYCLE?
5984 032424 001005          BNE 1$             ;BR IF YES
5985 032426 005737 001236    TST TSTNMS+2        ;ANY TEST SELECTED THIS CYCLE ?
5986 032432 001002          BNE 1$             ;BR IF YES
5987 032434 000137 031762    JMP GTTST1          ;NO
5988 032440 121127 000057    1$: CMPB (R1),#'/    ;"OPEN"?
5989 032444 001004          BNE 2$             ;NO--BRANCH
5990 032446 056264 001424 031240  BIS BITS(R2), OPNFLG(R4) ;YES--SET BITS FOR TEST TO OPEN
5991 032454 000405          BR 3$              ;
5992 032456 121127 000054    2$: CMPB (R1),#'    ;"COMMA"?
5993 032462 001402          BEQ 3$             ;BR IF YES
5994 032464 000137 031762    JMP GTTST1          ;NO
5995 032470 005201          3$: INC R1          ;MOVE TO NEXT CHARACTER
5996 032472 105711          TSTB (R1)          ;"CR"?
5997 032474 001402          BEQ 4$             ;BR IF 'CR'
5998 032476 000137 032046    JMP GTTST2          ;NO--GO GET NEXT CHARACTER
5999 032502 005737 001240    4$: TST OPNFLG        ;ANY TESTS TO OPEN ?
6000 032506 001042          BNE OPNTST         ;BR IF YES
6001 032510 005737 001242    TST OPNFLG+2      ;ANY TESTS TO OPEN ?
6002 032514 001037          BNE OPNTST         ;BR IF YES
6003 032516 000137 031762    JMP GTTST1          ;NO--START AGAIN
6004 032522 005201          GTTST5: INC R1      ;MOVE TO NEXT CHARACTER
6005 032524 121127 000056    CMPB (R1),#'    ;"PERIOD"?
6006 032530 001414          BEQ GTTST6        ;YES--BRANCH
6007 032532 105711          TSTB (R1)        ;"CR"?
6008 032534 001402          BEQ 1$            ;YES--BRANCH
6009 032536 000137 031762    JMP GTTST1        ;NO
6010 032542 005737 001240    1$: TST OPNFLG      ;ANY TESTS TO OPEN ?
6011 032546 001022          BNE OPNTST        ;BR IF YES
6012 032550 005737 001242    TST OPNFLG+2     ;ANY TESTS TO OPEN ?
6013 032554 001017          BNE OPNTST        ;BR IF YES
6014 032556 000137 031756    JMP GT.PR2        ;NO--GO START TESTING
6015 032562 005201          GTTST6: INC R1     ;MOVE TO NEXT CHARACTER
6016 032564 105711          TSTB (R1)        ;"CR"?
6017 032566 001402          BEQ 1$            ;YES--BRANCH
6018 032570 000137 031762    JMP GTTST1        ;NO--GO ASK FOR TEST
6019 032574 005737 001240    1$: TST OPNFLG      ;ANY TESTS TO OPEN ?
6020 032600 001005          BNE OPNTST        ;BR IF YES
6021 032602 005737 001242    TST OPNFLG+2     ;ANY TESTS TO OPEN ?
6022 032606 001002          BNE OPNTST        ;BR IF YES
6023 032610 000137 031756    JMP GT.PR2        ;NO--GO START TESTING
6024
6025 ;OPEN THE SELECTED TEST FOR CHANGES
6026
6027 032614 104412          OPNTST: SAVREG    ;SAVE R0 - R5
6028 032616 005027          CLR (PC)+         ;START WITH TEST 0
6029 032620 000000          OPN.CT: .WORD 0   ;COUNT STORED HERE
6030 032622 000411          BR OPN.2          ;SKIP THE INCREMENT
6031 032624 005237 032620          OPN.1: INC OPN.CT ;MOVE TO THE NEXT TEST
6032 032630 022737 000022 032620  CMP #STN-1,OPN.CT ;TEST NUMBER TOO BIG?
6033 032636 002003          BGE OPN.2         ;NO--OPEN THE NEXT TEST
6034 032640 104413          RESREG           ;RESTORE R0 - R5

```

6035	032642	000137	031762		JMP	GTTST1		:YES--GO ASK FOR MORE TESTS
6036	032646	013705	032620	OPN.2:	MOV	OPN.CT,R5		:SETUP TO USE THE
6037	032652	006305			ASL	R5		:TEST NUMBER AS AN INDEX
6038	032654	013703	032620		MOV	OPN.CT,R3		:GET INDEX
6039	032660	042703	000017		BIC	#17,R3		:CLEAR LOWER TEST BITS
6040	032664	006203			ASR	R3		:SHIFT TEST NUMBER
6041	032666	006203			ASR	R3		:SHIFT TEST NUMBER
6042	032670	006203			ASR	R3		:SHIFT TEST NUMBER
6043	032672	036563	001424	001240	BIT	BITS(R5),OPNFLG(R3)		:OPEN THIS TEST?
6044	032700	001751			BEQ	OPN.1		:NO--MOVE TO NEXT TEST
6045	032702	104401	032710		TYPE	65\$		:TYPE ASCIZ STR'NG
6046	032706	000404			BR	64\$		:GET OVER THE _JIZ
6047								
6048	032720							
6049	032720	013746	032620		MOV	OPN.CT,-(SP)		:SAVE OPN.CT FOR TYPEOUT
6050								:TEST NUMBER
6051	032724	104403			TYPOS			:GO TYPE--OCTAL ASCII
6052	032726	002			.BYTE	2		:TYPE 2 DIGIT(S)
6053	032727	000			.BYTE	0		:SUPPRESS LEADING ZEROS
6054	032730	104401	001215		TYPE	\$CRLF		:TYPE "CR" & "LF"
6055	032734	016500	001536		MOV	PRMPT(R5),R0		:PICKUP PARAMETER POINTER
6056	032740	011046			MOV	(R0),-(SP)		:SAVE THE VARIABLE INDICATOR
6057	032742	012702	001504		MOV	#PRM,R2		:FIRST ADDRESS OF TABLE
6058	032746	000405			BR	2\$		
6059	032750	006216		1\$:	ASR	(SP)		:CHECK FOR A VARIABLE
6060	032752	103403			BCS	2\$		:GO MOVE THIS ONE
6061	032754	001404			BEQ	OPNPRM		:DONE
6062	032756	005722			TST	(R2)+		:BUMP THE POINTER
6063	032760	000773			BR	1\$		
6064	032762	012022		2\$:	MOV	(R0)+,(R2)+		:MOVE THIS VARIABLE INTO THE
6065	032764	000771			BR	1\$		:COMMON AREA
6066	032766	013716	001504	OPNPRM:	MOV	#PRM,(SP)		:GET THE VARIABLE INDICATOR
6067	032772	005004			CLR	R4		:ZERO THE INDEX
6068	032774	006216		1\$:	ASR	(SP)		:CHECK FOR A VARIABLE
6069	032776	103403			BCS	3\$		:GO GET IT
6070	033000	001772			BEQ	OPNPRM		:OUT OF VARIABLES
6071	033002	005724		2\$:	TST	(R4)+		:UPDATE THE INDEX
6072	033004	000773			BR	1\$		
6073	033006	005764	001606	3\$:	TST	PRMLMT(R4)		:IS THE MAX. MAGNITUDE NEG?
6074	033012	100466			BMI	OPNPAT		:YES--THEN IT IS THE PATTERN
6075	033014	104401	044010		TYPE	MSG.SP		:TYPE SPACES
6076	033020	016437	001636	033030	MOV	PRMMSG(R4),4\$		:TYPE THE NAME OF THIS VARIABLE
6077	033026	104401			TYPE			
6078	033030	000000		4\$:	.WORD	0		
6079	033032	104401	043016		TYPE	MSG.EQ		:TYPE "="
6080	033036	016446	001506		MOV	RPT(R4),-(SP)		:PUT RPT(R4) ON THE STACK
6081	033042	004737	023170		JSR	PC,@#SSB20		:CHANGE RPT(R4) TO DECIMAL ASCIZ
6082	033046	004737	023420		JSR	PC,@#SSSUPRS		:TYPE WITHOUT LEADING ZEROS
6083	033052	104401	043044		TYPE	,SLASH		: '/'
6084	033056	104411			RD.IN			
6085	033060	012601			MOV	(SP)+,R1		:READ AN ASCIZ STRING
6086	033062	004037	033736		JSR	R0,@#CK.CHR		:CHECK ONE CHARACTER
6087	033066	033006			3\$			:ILLEGAL CHARACTER
6088	033070	033002			2\$			:CARRIAGE RETURN
6089	033072	033140			8\$			
6090	033074	033102			5\$			

6091	033076	033110		6S			
6092	033100	033136		7S			
6093	033102	105711		5S:	TSTB (R1)		:DIGIT 0-9
6094	033104	001340			BNE 3S		: "CR"?
6095	033106	000735			BR 2S		: NO--STAY ON THIS VARIABLE
6096	033110	105711		6S:	TSTB (R1)		: YES--MOVE TO NEXT VARIABLE
6097	033112	001002			BNE 64S		: IS THERE A "CR" AFTER THE PERIOD?
6098	033114	000137	033530		JMP OPN.N2		: NO
6099	033120	122721	000056	64S:	CMPB #'.,(R1)+		: YES--GO CLOSE THIS TEST
6100	033124	001330			BNE 3S		: DOUBLE PERIOD?
6101	033126	105711			TSTB (R1)		: NO--GO ASK FOR THIS VARIABLE
6102	033130	001326			BNE 3S		: YES--IS A "CR" AFTER THE DOUBLE PERIOD?
6103	033132	000137	033546		JMP OPN.X2		: NO--ASK FOR THIS VARIABLE AGAIN
6104	033136	005301		7S:	DEC R1		: YES--CLOSE ALL TEST
6105	033140			8S:			: BACK THE POINTER UP BY ONE
6106	033140	016402	001606		MOV PRMLMT(R4),R2		: UPPER LIMIT OF INPUT
6107	033144	004037	034012		JSR RD, @CK.DIG		: CHECK THE DIGIT(S)
6108	033150	033006			3S		: ILLEGAL INPUT
6109	033152	033006			3S		: INPUT TO LARGE
6110	033154	033162			9S		: TERMINATED WITH A ".,." OR "CR"
6111	033156	033524			OPN.N1		: TERMINATED WITH A ".,."
6112	033160	033542			OPN.X1		: TERMINATED WITH A ".,."
6113	033162	010264	001506	9S:	MOV R2,RPT(R4)		: SAVE THIS VARIABLE
6114	033166	000705			BR 2S		: MOVE TO NEXT VARIABLE
6115	033170	104401	044010	OPNPAT:	TYPE ,MSG.SP		: TYPE SPACES
6116	033174	104401	043012		TYPE ,MSG.PAT		: TYPE "PAT"
6117	033200	104401	043016		TYPE ,MSG.EQ		: TYPE "="
6118	033204	016446	001506		MOV RPT(R4),-(SP)		: SAVE RPT(R4) FOR TYPEOUT
6119	033210	104402			TYPOC		: GO TYPE--OCTAL ASCII(ALL DIGITS)
6120	033212	104401	044011		TYPE ,MSG.SP+1		: TYPE ONE SPACE
6121	033216	104411			RDLIN		: READ ASCII STRING
6122	033220	012601			MOV (SP)+,R1		: PICKUP POINTER
6123	033222	004037	033736		JSR RD,@CK.CHR		: CHECK ONE CHARACTER
6124	033226	033170			OPNPAT		: ILLEGAL CHARACTER
6125	033230	032766			OPNPRM		: CARRIAGE RETURN
6126	033232	033264			3S		: "/"
6127	033234	032766			OPNPRM		: ".,."
6128	033236	033242			1S		: ".,."
6129	033240	033262			2S		: DIGIT 0-9
6130	033242	105711		1S:	TSTB (R1)		: "CR" AFTER THE PERIOD?
6131	033244	001531			BEQ OPN.N2		: YES--GO CLOSE THIS TEST
6132	033246	122721	000056		CMPB #'.,(R1)+		: NO--PERIOD?
6133	033252	001346			BNE OPNPAT		: NO--LOOP
6134	033254	105711			TSTB (R1)		: "CR" AFTER A DOUBLE PERIOD?
6135	033256	001533			BEQ OPN.X2		: YES--GO START TESTING
6136	033260	000743			BR OPNPAT		: NO--LOOP
6137	033262	005301		2S:	DEC R1		: BACKUP THE ASCII POINTER
6138	033264			3S:			
6139	033264	004037	034176		JSR RC,@CK.NUM		: CHECK THE NUMBER
6140	033270	033170			OPNPAT		: ILLEGAL INPUT
6141	033272	033300			4S		: TERMINATED WITH A ".,." OR "CR"
6142	033274	033524			OPN.N1		: TERMINATED WITH A ".,."
6143	033276	033542			OPN.X1		: TERMINATED WITH A ".,."
6144	033300	010264	001506	4S:	MOV R2,RPT(R4)		: SAVE THE INPUT NUMBER
6145	033304	006002			ROR R2		: OPEN PATTERN 0
6146	033306	103227			BCC OPNPRM		: NO--START AT BEGINNING OF PARAMETER TABLE



6147	033307	104412			OPNWD5: SAVREG	:SAVE R0 - R5
6148	033312	005000			CLR R0	:START WITH WORD 0
6149	033314	012704	003104		MOV #PATO,R4	
6150	033320			15:		
6151	033320	104401	033326		TYPE 655	::TYPE ASCIZ STRING
6152	033324	000403			BR 645	::GET OVER THE ASCIZ
6153				::655:	.ASCIZ / WD/	
6154	033334			645:		
6155	033334	010046			MOV R0,-(SP)	:PUT R0 ON THE STACK
6156	033336	004737	023170		JSR PC,@#SSB2D	:CHANGE R0 TO DECIMAL ASCIZ
6157	033342	004737	023420		JSR PC,@#SSUPRS	:TYPE WITHOUT LEADING ZEROS
6158	033346	104401	043016		TYPE MSG.EQ	:TYPE "="
6159	033352	011446			MOV (R4),-(SP)	:SAVE (R4) FOR TYPEOUT
6160	033354	104402			TYPOC	:GO TYPE--OCTAL ASCII(ALL DIGITS)
6161	033356	104411			RDLIN	:READ ASCIZ STRING
6162	033360	012601			MOV (SP)+,R1	:PICKUP THE POINTER
6163	033362	004037	033736		JSR R0,@#CK.CHR	:CHECK ONE CHARACTER
6164	033366	033320			15	:ILLEGAL CHARACTER
6165	033370	033422			45	:CARRIAGE RETURN
6166	033372	033404			25	"/
6167	033374	033422			45	" "
6168	033376	033436			55	"' "
6169	033400	033402			105	:DIGIT 0-9
6170	033402	005301		105:	DEC R1	:BACKUP THE ASCII POINTER
6171	033404			25:		
6172	033404	004037	034176		JSR R0,@#CK.NUM	:CHECK THE NUMBER
6173	033410	033320			15	:ILLEGAL INPUT
6174	033412	033420			35	:TERMINATED WITH A " " OR "CR"
6175	033414	033456			65	:TERMINATED WITH A ":'"
6176	033416	033470			85	:TERMINATED WITH A "..."
6177	033420	010214		35:	MOV R2,(R4)	:SAVE THE INPUT
6178	033422	005724		45:	TST (R4)+	:MOVE TO NEXT WORD
6179	033424	005200			INC R0	:INCREMENT THE COUNT
6180	033426	022700	000020		CMP #16.,R0	:COUNT TO LARGE?
6181	033432	003332			15	:NO--BRANCH
6182	033434	000726			BR OPNWD5	:YES--BRANCH
6183	033436	105711		55:	TSTB (R1)	: "CR" AFTER THE PERIOD?
6184	033440	001407			BEQ 75	:YES--GO CLOSE THIS TEST
6185	033442	122721	000056		CMPB #'.,(R1)+	:NO--PERIOD?
6186	033446	001324			BNE 15	:NO--BRANCH ILLEGAL INPUT STRING
6187	033450	105711			TSTB (R1)	: "CR" AFTER THE "PERIOD-PERIOD"?
6188	033452	001407			BEQ 95	:YES--GO START TESTING
6189	033454	000721			BR 15	:NO--LOOP
6190	033456	010224		65:	MOV R2,(R4)+	:SAVE THE INPUT
6191	033460	004737	033502	75:	JSR PC,@#CL5WD5	:CLOSE THE DATA PATTERN
6192	033464	104413			RESREG	:RESTORE R0 - R5
6193	033466	000420			BR OPN.N2	:MOVE TO NEXT TEST
6194	033470	010224		85:	MOV R2,(R4)+	:SAVE THE INPUT
6195	033472	004737	033502	95:	JSR PC,@#CL5WD5	:CLOSE THE DATA PATTERN
6196	033476	104413			RESREG	:RESTORE R0 - R5
6197	033500	000422			BR OPN.X2	:START TESTING
6198	033502	012701	003104	CLS5D5:	MOV #PATO,R1	:FIRST ADDRESS OF DATA PATTERN
6199	033506	005200		15:	INC R0	:COUNT THE LAST WORD THAT WAS STORED
6200	033510	022700	000017		CMP #15.,R0	:END OF TABLE
6201	033514	002402			BLT 25	:YES--EXIT
6202	033516	012124			MOV (R1)+,(R4)+	:COPY

DLU

6203	033520	000772		BH	1\$	: LOOP
6204	033522	000207		2\$:	RTS	PC
6205	033524	010264	001506	OPN.N1:	MOV	R2,RPT(R4)
6206	033530	005726		OPN.N2:	TST	(SP)+
6207	033532	004737	033602		JSR	PC,CLOSE
6208	033536	000137	033524		JMP	OPN
6209	033542	010264	001506	OPN.X1:	MOV	R2,RPT(R4)
6210	033546	005726		OPN.X2:	TST	(SP)+
6211	033550	004737	033602	1\$:	JSR	PC,CLOSE
6212	033554	005725		2\$:	TST	(RS)+
6213	033556	020527	000034		CMP	RS,#16*2
6214	033562	002403			BLT	3\$
6215	033564	104413			RESREG	
6216	033566	000137	031756		JMP	GT.PR2
6217	033572	036503	001424	3\$:	BIT	BITS(R5),F3
6218	033576	001364			BNE	1\$
6219	033600	000765			BR	2\$
6220	033602	104412		CLOSE:	SAVREG	
6221	033604	012700	001504		MOV	#PRM,R0
6222	033610	016501	001536		MOV	PRPT(R5),R1
6223	033614	012302			MOV	(R0)+,R2
6224	033616	012103			MOV	(R1)+,R3
6225	033620	012704	000001		MOV	#1,R4
6226	033624	030402		1\$:	BIT	R4,R2
6227	033626	001403			BEQ	2\$
6228	033630	030403			BIT	R4,R3
6229	033632	001404			BEQ	3\$
6230	033634	011011			MOV	(R0),(R1)
6231	033636	030403		2\$:	BIT	R4,R3
6232	033640	001401			BEQ	3\$
6233	033642	005721			TST	(R1)+
6234	033644	005720		3\$:	TST	(R0)+
6235	033646	006304			ASL	R4
6236	033650	032704	002000		BIT	#BIT10,R4
6237	033654	001763			BEQ	1\$
6238	033656	104413			RESREG	
6239	033660	000207			RTS	PC
6240						
6241						
6242						
6243						
6244						
6245						
6246						
6247						
6248						
6249						
6250						
6251	033662	121127	000360	CK.OCT:	CMPB	(R1),#0
6252	033666	103407			BLO	1\$
6253	033670	121127	000067		CMPB	(R1),#7
6254	033674	101004			BHI	1\$
6255	033676	111102			MOVB	(R1),R2
6256	033700	042702	177770		BIC	#107,R2
6257	033704	005720			TST	(R0)+
6258	033706	000200		1\$:	RTS	R0
6259						
6260						

: THIS ROUTINE IS USED TO CHECK IF AN ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7.  
 CALL  
 MOV #ADR,R1 ; ADDRESS OF ASCII CHARACTER  
 JSR R0,CHK.OCT ; CHECK THE CHARACTER  
 RETURN1 ; CHARACTER IS NOT BETWEEN 0-7  
 RETURN2 ; CHARACTER IS IN R2 AS A OCTAL DIGIT

: LESS THAN ZERO?  
 YES -- BRANCH  
 GREATER THAN SEVEN?  
 YES -- BRANCH  
 GET THE CHARACTER  
 STRIP AWAY THE ASCII  
 ADJUST FOR RETURN  
 RETURN

; THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER

```

6259
6260
6261
6262
6263
6264
6265
6266
6267 033710 121127 000060
6268 033714 103407
6269 033716 121127 000071
6270 033722 101004
6271 033724 111102
6272 033726 042702 000060
6273 033732 005720
6274 033734 000200
6275
6276
6277
6278
6279
6280
6281
6282
6283
6284
6285
6286
6287
6288
6289 033736 105711
6290 033740 001420
6291 033742 121127 000057
6292 033746 001414
6293 033750 121127 000054
6294 033754 001410
6295 033756 121127 000056
6296 033762 001404
6297 033764 004037 033710
6298 033770 000406
6299 033772 005720
6300 033774 005720
6301 033776 005720
6302 034000 005720
6303 034002 005720
6304 034004 005201
6305 034006 011000
6306 034010 000200
6307
6308
6309
6310
6311
6312
6313
6314

```

```

: AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.
CALL
      MOV      #ADR, R1      ; ADDRESS OF ASCII CHARACTER
      JSR      RO, @CK.DEC   ; CHECK THE CHARACTER
      RETURN   ; NOT BETWEEN 0 AND 9
      RETURN   ; BETWEEN 0 AND 9
      ; R2 = DIGIT

```

```

CK.DEC:  CMPB   (R1), #'0     ; LESS THAN ZERO?
          BLO   IS           ; YES -- BRANCH
          CMPB   (R1), #'9     ; GREATER THAN NINE?
          BHI   IS           ; YES -- BRANCH
          MOVB  (R1), R2      ; GET THE CHARACTER
          BIC   #'0, R2       ; STRIP AWAY THE ASCII
          TST   (R0)+         ; ADJUST FOR RETURN
IS:      RTS    RO           ; RETURN

```

```

: THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
: DETERMINE WHAT IT IS.

```

```

CALL
      MOV      #ADR, R1      ; ADDRESS OF ASCII CHARACTER
      JSR      RO, @CK.CHR   ; CHECK CHARACTER
      RETURN   ADR1         ; UNKNOWN CHARACTER
      RETURN   ADR2         ; CARRIAGE RETURN * (R1)=ADR+1
      RETURN   ADR3         ; SLASH * (R1)=ADR+1
      RETURN   ADR4         ; COMMA * (R1)=ADR+1
      RETURN   ADR5         ; PERIOD * (R1)=ADR+1
      RETURN   ADR6         ; DIGIT BETWEEN 0 AND 9.
      ; R2 = DIGIT * (R1)=ADR+1

```

```

CK.CHR:  TSTB   (R1)         ; "CARRIAGE RETURN"?
          BEQ   4$           ; YES -- BRANCH
          CMPB   (R1), #'/'   ; "SLASH"?
          BEQ   3$           ; YES -- BRANCH
          CMPB   (R1), #','   ; "COMMA"?
          BEQ   2$           ; YES -- BRANCH
          CMPB   (R1), #'.'   ; "PERIOD"?
          BEQ   1$           ; YES -- BRANCH
          JSR      RO, @CK.DEC ; "DIGIT"?
          BR     5$         ; NO -- BRANCH
          TST   (R0)+         ; DIGIT BETWEEN 0-9
1$:      TST   (R0)+         ; PERIOD
2$:      TST   (R0)+         ; COMMA
3$:      TST   (R0)+         ; SLASH
4$:      TST   (R0)+         ; CARRIAGE RETURN
          INC   R1           ; MOVE POINTER TO NEXT CHARACTER
5$:      MOV   (R0), R0      ; UNKNOWN CHARACTER
          RTS    RO         ; RETURN

```

```

: THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
: CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN R2.

```

```

CALL
      MOV      #ADR, R1      ; ADDRESS OF ASCII STRING
      MOV      #NUM, R2     ; MAX. MAGNITUDE OF INPUT NUMBER
      JSR      RO, @CK.DIG   ; CHECK DIGITS
      RETURN   ADR1         ; ILLEGAL CHARACTER -- R2=?

```

```

6315      :      RETURN  ADR2      : INPUT NUMBER TO LARGE -- R2=?
6316      :      RETURN  ADR3      : "COMMA" -- R2 = NUMBER
6317      :      RETURN  ADR4      : "PERIOD" -- R2 = NUMBER
6318      :      RETURN  ADR5      : "PERIOD-PERIOD" -- R2 = NUMBER
6319
6320      034012 010446      CK.DIG: MOV      R4, -(SP)      : SAVE R4
6321      034014 010346      : MOV      R3, -(SP)      : SAVE R3
6322      034016 010246      : MOV      R2, -(SP)      : SAVE THE MAX. SIZE ON THE STACK
6323      034020 005002      : CLR      R2              : START WITH 0
6324      034022 005003      : CLR      R3
6325      034024 005004      : CLR      R4
6326      034026 004037 033736 : JSR      RD, @CK.CHR      : CHECK ONE CHARACTER
6327      034028 004116      : BS       BS              : ILLEGAL CHARACTER
6328      034030 004116      : BS       BS              : CARRIAGE RETURN
6329      034032 004116      : BS       BS              : "/
6330      034034 004116      : BS       BS              : ".
6331      034036 004046      : BS       BS              : "
6332      034038 006303      15:  ASL      R3              : DIGIT 0-9
6333      034040 010346      : MOV      R3, -(SP)      : SAVE #2
6334      034042 006303      : ASL      R3              : 2
6335      034044 006303      : ASL      R3              : 4
6336      034046 006263      : ADD      (SP)+, R3       : 8
6337      034048 006263      : ADD      R2, R3         : (#8)+(#2)=#10.
6338      034050 006203      : JSR      RD, @CK.CHR      : UPDATE THE INPUT NUMBER
6339      034052 004116      : BS       BS              : CHECK ONE CHARACTER
6340      034054 004116      : BS       BS              : ILLEGAL CHARACTER
6341      034056 004116      : BS       BS              : CARRIAGE RETURN
6342      034058 004116      : BS       BS              : "/
6343      034060 004116      : BS       BS              : ".
6344      034062 004116      : BS       BS              : "
6345      034064 005721      95:  DEC      R1              : DIGIT 0-9
6346      034066 000401      : BR       BS              : BACKUP THE CHARACTER POINTER
6347      034068 005721      25:  TST      (R4)+          : CONTINUE
6348      034070 005721      35:  TST      (R4)+          : "PERIOD"
6349      034072 004037 033736 : JSR      RD, @CK.CHR      : "COMMA" OR "CR"
6350      034074 004116      : BS       BS              : CHECK ONE CHARACTER
6351      034076 004116      : BS       BS              : ILLEGAL CHARACTER
6352      034078 004116      : BS       BS              : CARRIAGE RETURN
6353      034080 004116      : BS       BS              : "/
6354      034082 004116      : BS       BS              : ".
6355      034084 004116      : BS       BS              : "
6356      034086 005721      45:  TST      (R4)+          : DIGIT 0-9
6357      034088 005721      : TSTB     (R1)           : "PERIOD-PERIOD"
6358      034090 001105      : BEQ      BS             : "CR"?
6359      034092 001410      : BR       BS             : YES--BRANCH
6360      034094 001410      : BR       BS             :
6361      034096 001410      : BR       BS             :
6362      034098 001410      : BR       BS             :
6363      034100 001410      : BR       BS             :
6364      034102 001410      : BR       BS             :
6365      034104 001410      : BR       BS             :
6366      034106 001410      : BR       BS             :
6367      034108 001410      : BR       BS             :
6368      034110 001410      : BR       BS             :
6369      034112 001410      : BR       BS             :
6370      034114 001410      : BR       BS             :
6371      034116 001410      : BR       BS             :
6372      034118 001410      : BR       BS             :
6373      034120 001410      : BR       BS             :
6374      034122 001410      : BR       BS             :
6375      034124 001410      : BR       BS             :
6376      034126 001410      : BR       BS             :
6377      034128 001410      : BR       BS             :
6378      034130 001410      : BR       BS             :
6379      034132 001410      : BR       BS             :
6380      034134 001410      : BR       BS             :
6381      034136 001410      : BR       BS             :
6382      034138 001410      : BR       BS             :
6383      034140 001410      : BR       BS             :
6384      034142 001410      : BR       BS             :
6385      034144 001410      : BR       BS             :
6386      034146 001410      : BR       BS             :
6387      034148 001410      : BR       BS             :
6388      034150 001410      : BR       BS             :
6389      034152 001410      : BR       BS             :
6390      034154 001410      : BR       BS             :
6391      034156 001410      : BR       BS             :
6392      034158 001410      : BR       BS             :
6393      034160 001410      : BR       BS             :
6394      034162 001410      : BR       BS             :
6395      034164 001410      : BR       BS             :
6396      034166 001410      : BR       BS             :
6397      034168 001410      : BR       BS             :
6398      034170 001410      : BR       BS             :

```

# E10

```

6371 034172 011000      MOV      (R0),R0      ;GET RETURN ADDRESS
6372 034174 000200      RTS        R0        ;RETURN
6373
6374                ; THIS ROUTINE CHECKS AN ASCIZ STRING FOR LEGAL CHARACTERS
6375                ; AND FORMS AN OCTAL NUMBER IN R2
6376                ; CALL:
6377                ;     MOV      @ADR,R1      ; ADDRESS OF ASCIZ STRING
6378                ;     JSR      R0,@CK.NUM   ; GO FORM THE NUMBER
6379                ;     RETURN  ADR1        ; ILLEGAL CHARACTER IN THE INPUT STRING
6380                ;     RETURN  ADR2        ; "COMMA" OR "CR"--R2=NUMBER
6381                ;     RETURN  ADR3        ; "PERIOD"--R2=NUMBER
6382                ;     RETURN  ADR4        ; "PERIOD-PERIOD"--R2=NUMBER
6383
6384 034176 010346      CK.NUM: MOV      R3,-(SP)   ; SAVE R3
6385 034200 005003      CLR      R3          ; START NUMBER AT ZERO
6386 034202 004037 033662  JSR      R0,@CK.OCT  ; OCTAL DIGIT?
6387 034206 000440      BR       6$         ; NO--BRANCH
6388 034210 005201      1$: INC      R1       ; MOVE TO NEXT CHARACTER
6389 034212 006303      ASL     R3          ; FOR THE OCTAL NUMBER IN R3
6390 034214 103435      BCS     6$         ; DON'T LET IT GET TO BIG
6391 034216 006303      ASL     R3
6392 034220 103433      BCS     6$
6393 034222 006303      ASL     R3
6394 034224 103431      BCS     6$
6395 034226 060203      ADD     R2,R3
6396 034230 004037 033662  JSR      R0,@CK.OCT  ; IS THIS AN OCTAL DIGIT?
6397 034234 000401      BR       2$         ; NO--FIND OUT WHAT IT IS
6398 034236 000764      BR       1$         ; YES--MAKE IT PART OF THE NUMBER
6399 034240 010302      2$: MOV     R3,R2    ; SAVE THE OCTAL NUMBER
6400 034242 005003      CLR     R3          ; START WITH ZERO INDEX
6401 034244 004037 033736  JSR      R0,@CK.CHR  ; CHECK ONE CHARACTER
6402 034250 034310      6$     ; ILLEGAL CHARACTER
6403 034252 034300      5$     ; CARRIAGE RETURN
6404 034254 034310      6$     ;
6405 034256 034300      5$     ;
6406 034260 034264      3$     ;
6407 034262 034310      6$     ;
6408 034264 005723      3$: TST     (R3)+     ; DIGIT 0-9
6409 034266 121127 000056  CMPB    (R1),#'.    ; "PERIOD"
6410 034272 001002      BNE     5$         ; "PERIOD-PERIOD"?
6411 034274 005201      INC     R1         ; NO--BRANCH
6412 034276 005723      4$: TST     (R3)+     ; YES--ADVANCE THE POINTER
6413 034300 005723      5$: TST     (R3)+     ; "PERIOD-PERIOD"
6414 034302 105711      TSTB   (R1)        ; "COMMA"
6415 034304 001001      BNE     6$         ; "CR"?
6416 034306 060300      ADD     R3,R0      ; NO--BRANCH
6417 034310 012603      6$: MOV     (SP)+,R3   ; YES--SAVE THE OCTAL NUMBER
6418 034312 011000      MOV     (R0),R0    ; RESTORE R3
6419 034314 000200      RTS     R0         ; PICKUP EXIT ADDRESS
                    ; RETURN

```

6420  
6421  
6422  
6423  
6424  
6425  
6426  
6427  
6428  
6429  
6430  
6431  
6432  
6433  
6434  
6435  
6436  
6437  
6438  
6439  
6440  
6441  
6442  
6443  
6444  
6445  
6446  
6447  
6448  
6449  
6450  
6451  
6452  
6453  
6454  
6455  
6456  
6457  
6458  
6459  
6460  
6461  
6462  
6463  
6464  
6465  
6466  
6467  
6468  
6469  
6470  
6471  
6472  
6473  
6474  
6475

;;\*\*\*\*\*

.SBTTL SINGLE/DUAL PORT RH11/RPO4/5/6 DRIVER (REV 1.0)

;COPYRIGHT (C) 1976  
;DIGITAL EQUIPMENT CORP.  
;MAYNARD MA 01754  
;AUTHOR(S): JIM LACEY/CHUCK HESS

;;\*\*\*\*\*

;STORAGE FOR RPOS1, RPER1, RPER2, AND RPER3 ON AN ERROR "2"

;RPERRS = RPOS1  
;RPERRS+2 = RPER1  
;RPERRS+4 = RPER2  
;RPERRS+6 = RPER3

034316 000000 000000 000000 RPERRS: .WORD 0,0,0,0  
034324 000000

;TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=8 BYTES)

;DRVACT=0 IF DRIVE IS IDLE  
;DRVACT>0 IF DRIVE IS ACTIVE WITH A COMMAND  
;DRVACT<0 IF DRIVE IS ACTIVE WITH AN ERROR RECOVERY OPERATION

034326 000 :DRVACT: .BYTE 0 ;DRIVE 0  
034327 000 :.BYTE 0 ;DRIVE 1  
034330 000 :.BYTE 0 ;DRIVE 2  
034331 000 :.BYTE 0 ;DRIVE 3  
034332 000 :.BYTE 0 ;DRIVE 4  
034333 000 :.BYTE 0 ;DRIVE 5  
034334 000 :.BYTE 0 ;DRIVE 6  
034335 000 :.BYTE 0 ;DRIVE 7

;TABLE OF DRIVE STATUS INDICATORS (DRVSTA=8 BYTES)

;DRVSTA=0 IF DRIVE IS OFFLINE OR NONEXISTENT  
;DRVSTA>0 IF DRIVE IS ONLINE  
;DRVSTA<0 IF DRIVE IS UNSAFE

034336 000 DRVSTA: .BYTE 0 ;DRIVE 0  
034337 000 :.BYTE 0 ;DRIVE 1  
034340 000 :.BYTE 0 ;DRIVE 2  
034341 000 :.BYTE 0 ;DRIVE 3  
034342 000 :.BYTE 0 ;DRIVE 4  
034343 000 :.BYTE 0 ;DRIVE 5  
034344 000 :.BYTE 0 ;DRIVE 6  
034345 000 :.BYTE 0 ;DRIVE 7

;TABLE OF DRIVE TYPES (DRV TYP=8 BYTES)

;DRV TYP=0 IF DRIVE IS NONEXISTENT (DRVSTA=0, ALSO)  
;DRV TYP=1 IF DRIVE IS RPO4  
;DRV TYP=2 IF DRIVE IS RPOS  
;DRV TYP=4 IF DRIVE IS RPO6  
;DRV TYP=-1 IF NOT RPO4/5/6

# G10

```
6476 034346 000
6477 034347 000
6478 034350 000
6479 034351 000
6480 034352 000
6481 034353 000
6482 034354 000
6483 034355 000
```

```
DRVTYP: .BYTE 0          ;DRIVE 0
         .BYTE 0          ;DRIVE 1
         .BYTE 0          ;DRIVE 2
         .BYTE 0          ;DRIVE 3
         .BYTE 0          ;DRIVE 4
         .BYTE 0          ;DRIVE 5
         .BYTE 0          ;DRIVE 6
         .BYTE 0          ;DRIVE 7
```

```
;TABLE OF DUAL PORT INITIALIZATION INDICATORS
;DPINT=0 IF INITIALIZATION IS NOT ACTIVE ON THE DRIVE
;DPINT<0 IF INITIALIZATION IS IN PROGRESS
```

```
6484
6485
6486
6487
6488
6489 034356 000
6490 034357 000
6491 034360 000
6492 034361 000
6493 034362 000
6494 034363 000
6495 034364 000
6496 034365 000
```

```
DPINT:  .BYTE 0          ;DRIVE 0
        .BYTE 0          ;DRIVE 1
        .BYTE 0          ;DRIVE 2
        .BYTE 0          ;DRIVE 3
        .BYTE 0          ;DRIVE 4
        .BYTE 0          ;DRIVE 5
        .BYTE 0          ;DRIVE 6
        .BYTE 0          ;DRIVE 7
```

```
;TABLE OF PENDING DUAL PORT REQUESTS
;DPRQS=0 IF THAT A DUAL PORT REQUEST IS NOT PENDING FOR THAT DRIVE
;DPRQS<0 IF THAT A DUAL PORT REQUEST IS PENDING FOR THAT DRIVE
```

```
6497
6498
6499
6500
6501
6502 034366 000
6503 034367 000
6504 034370 000
6505 034371 000
6506 034372 000
6507 034373 000
6508 034374 000
6509 034375 000
```

```
DPRQS:  .BYTE 0          ;DRIVE 0
        .BYTE 0          ;DRIVE 1
        .BYTE 0          ;DRIVE 2
        .BYTE 0          ;DRIVE 3
        .BYTE 0          ;DRIVE 4
        .BYTE 0          ;DRIVE 5
        .BYTE 0          ;DRIVE 6
        .BYTE 0          ;DRIVE 7
```

```
;TRANSFER WAIT FLAG (TRNSWT=1 WORD)
;THIS IS A ONE WORD QUEUE. IT WILL CONTAIN THE ADDRESS OF
;"DPB" OF THE I/O OPERATION.
```

```
6510
6511
6512
6513
6514
6515 034376 000000
```

```
TRNSWT: .WORD 0
```

```
;SEARCH WAIT KEYS (SRCHWT=1 WORD)
;THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF
;THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O
;REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE.
;EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0.
```

```
6516
6517
6518
6519
6520
6521
6522
6523 034400 000000
```

```
SRCHWT: .WORD 0
```

```
;RPO4/5/6 DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)
;ACTDRV=0 IF DRIVER IS INACTIVE
;ACTDRV>0 IF DRIVER IS ACTIVE
```

```
6524
6525
6526
6527
6528
6529 034402 000
```

```
ACTDRV: .BYTE 0
```

```
;SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
```

```
6530
6531
```



# H10

MD-11-DZRJA-AA RPO4/5/6 MECHANICAL AND READ/WRITE TEST MACY11 27(1006) 02-NOV-76 18:27 PAGE 125  
DZRJA.014 19-APR-76 00:00 SINGLE/DUAL PORT RH11/RPO4/5/6 DRIVER (REV 1.0)

```
6532                                     ;ACTSTR=0 IF SOFTWARE TIMER ROUTINE IS INACTIVE
6533                                     ;ACTSTR>0 IF SOFTWARE TIMER ROUTINE IS ACTIVE
6534
6535 034403      000      ACTSTR: .BYTE  0
6536
6537                                     ;UNLOAD FLAG (ULDFLG=8 BYTES)
6538                                     ;ULDFLG=0 IF NO UNLOAD COMMAND
6539                                     ;ULDFLG>0 IF UNLOAD COMMAND IN PROGRESS
6540                                     ;ULDFLG<0 IF UNLOAD COMMAND IN WAIT QUEUE
6541
6542 034404      000      ULDFLG: .BYTE  0          ;DRIVE 0
6543 034405      000          .BYTE  0          ;DRIVE 1
6544 034406      000          .BYTE  0          ;DRIVE 2
6545 034407      000          .BYTE  0          ;DRIVE 3
6546 034410      000          .BYTE  0          ;DRIVE 4
6547 034411      000          .BYTE  0          ;DRIVE 5
6548 034412      000          .BYTE  0          ;DRIVE 6
6549 034413      000          .BYTE  0          ;DRIVE 7
6550
6551                                     ;LOOK AHEAD COUNT (LACNT=8 BYTES)
6552                                     ;LACNT WILL INDICATE THE NUMBER OF LOOK AHEADS PERFORMED
6553
6554 034414      000      LACNT:  .BYTE  0          ;DRIVE 0
6555 034415      000          .BYTE  0          ;DRIVE 1
6556 034416      000          .BYTE  0          ;DRIVE 2
6557 034417      000          .BYTE  0          ;DRIVE 3
6558 034420      000          .BYTE  0          ;DRIVE 4
6559 034421      000          .BYTE  0          ;DRIVE 5
6560 034422      000          .BYTE  0          ;DRIVE 6
6561 034423      000          .BYTE  0          ;DRIVE 7
6562
6563                                     ;SAVE REGISTERS FLAG (SAVEFG =1 WORD)
6564                                     ;SAVEFG <0 IF SAVE THE RH11/RPO4/5/6 REGISTERS WHEN THE
6565                                     ;OPERATION IS COMPLETED AS PER (DPB+14).
6566                                     ;SAVEFG=0 IF SAVE THE RH11/RPO4/5/6 REGISTERS, AS PER
6567                                     ;(DPB+14), AFTER AN ERROR.
6568
6569 034424      000000     SAVEFG. .WORD  0
6570
6571                                     ;SEEK FLAG (SEEKFG=1 WORD)
6572                                     ;SEEKFG=0 IF WHEN THE DISK ADDRESS ISN'T IN THE WINDOW
6573                                     ;FOR A DATA TRANSFER START A SEARCH COMMAND
6574                                     ;SEEKFG<0 IF DATA TRANSFER WILL DO IMPLIED SEEKS,
6575                                     ;DISREGARD THE WINDOW
6576
6577 034426      000000     SEEKFG: .WORD  0
6578
6579                                     ;TIMEOUT TABLE (TIMER=8 WORDS)
6580                                     ;THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION
6581
6582 034430      177777     TIMER:  .WORD  -1          ;DRIVE 0
6583 034432      177777          .WORD  -1          ;DRIVE 1
6584 034434      177777          .WORD  -1          ;DRIVE 2
6585 034436      177777          .WORD  -1          ;DRIVE 3
6586 034440      177777          .WORD  -1          ;DRIVE 4
6587 034442      177777          .WORD  -1          ;DRIVE 5
```

6588 034444 177777  
 6589 034446 177777  
 6590  
 6591  
 6592  
 6593  
 6594  
 6595 034450 177777  
 6596  
 6597  
 6598  
 6599  
 6600  
 6601 034452 001  
 6602 034453 002  
 6603 034454 004  
 6604 034455 010  
 6605 034456 020  
 6606 034457 040  
 6607 034460 100  
 6608 034461 200  
 6609  
 6610  
 6611  
 6612  
 6613 034462 000003  
 6614  
 6615  
 6616  
 6617  
 6618 034464 176700  
 6619 034466 000254 000240  
 6620  
 6621  
 6622  
 6623 034472 000004  
 6624  
 6625  
 6626 034474 001000  
 6627  
 6628  
 6629 034476 000200  
 6630  
 6631  
 6632 034500 000005  
 6633  
 6634  
 6635  
 6636 000000  
 6637 000002  
 6638 000004  
 6639 000006  
 6640 000010  
 6641 000012  
 6642 000014  
 6643 000016

```

        .WORD -1      ;DRIVE 6
        .WORD -1      ;DRIVE 7

;DATA TRANSFER UNDERWAY INDICATOR (DTUM=1 WORD)
;DTUM<0 IF NO DATA TRANSFER UNDERWAY
;DTUM=+N (WHERE N=0 TO 7) IMPLIES DATA TRANSFER UNDERWAY ON DRIVE N

DTUM:  .WORD -1

;ATTENTION BITS TABLE (ATABIT=8 BYTES)
;THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES
;ATTENTION BIT

ATABIT: .BYTE 1      ;DRIVE 0
        .BYTE 2      ;DRIVE 1
        .BYTE 4      ;DRIVE 2
        .BYTE 10     ;DRIVE 3
        .BYTE 20     ;DRIVE 4
        .BYTE 40     ;DRIVE 5
        .BYTE 100    ;DRIVE 6
        .BYTE 200    ;DRIVE 7

;RPO4/5/6 TO RH11 "MASSEBUS CONTROL BUS PARITY ERRORS" (MCPE) ALLOWED BEFORE
;CALLING IT FATAL (MCPEMX=1 WORD)

MCPEMX: .WORD 3

;STORAGE FOR RPADR (THE FIRST ADDRESS (776700) OF THE RH11/RPO4/5/6),
;RPVEC (THE VECTOR ADDRESS (254)), AND RPVEC+2 (THE BR LEVEL (5)).

RPADR:  .WORD 176700
RPVEC:  .WORD 254,5*32.

;MAXIMUM NUMBER OF LOOK AHEADS ALLOWED IS 4 (MXLACT=1 WORD)

MXLACT: .WORD 4
;MAXIMUM DELTA DELAY IS 8 SECTORS (MXDLTA=1 WORD)

MXDLTA: .WORD 8*64.
;MINIMUM DELTA DELAY IS 2 SECTORS (MNDLTA=1 WORD)

MNDLTA: .WORD 2*64.
;MAXIMUM SEARCH FOR I/O WINDOW IS 5 SECTORS (MXWINDW=1 WORD)

MXWINDW: .WORD 5

;DEFINITIONS OF THE RH11/RPO4/5/6 ADDRESS INDEXES

RPCS1=0      ;CONTROL AND STATUS REGISTER #1 (DRIVE REG. 00)
RPWC=2      ;WORD COUNT REGISTER (NOT A DRIVE REG)
RPBA=4      ;UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
RPOA=6      ;DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG. 05)
RPCS2=10    ;CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
RPS1=12     ;DRIVE STATUS REGISTER (DRIVE REG 01)
RPER1=14    ;ERROR REGISTER #1 (DRIVE REG. 02)
RPAS=16     ;ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG. 04)
    
```

6644	000020	RPLA=20	:LOOK AHEAD REGISTER (DRIVE REG. 07)
6645	000022	RPOB=22	:DATA BUFFER REGISTER (NOT A DRIVE REG.)
6646	000024	RPMB=24	:MAINTAINABILITY REGISTER (DRIVE REG. 03)
6647	000026	RPDT=26	:DRIVE TYPE REGISTER (DRIVE REG. 06)
6648	000030	RPSN=30	:SERIAL NUMBER REGISTER (DRIVE REG. 10)
6649	000032	RPOF=32	:OFFSET REGISTER (DRIVE REG. 11)
6650	000034	RPCA=34	:DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG. 12)
6651	000036	RPCC=36	:CURRENT CYLINDER ADDRESS REGISTER (DRIVE REG. 13)
6652	000040	RPER2=40	:ERROR REGISTER #2 (DRIVE REG. 14)
6653	000042	RPER3=42	:ERROR REGISTER #3 (DRIVE REG. 15)
6654	000044	RPEC1=44	:ECC POSITION REGISTER (DRIVE REG. 16)
6655	000046	RPEC2=46	:ECC PATTERN REGISTER (DRIVE REG. 17)

```

;RH11/RPO4/5/6 DRIVER INITIALIZATION CODE
;THIS ROUTINE WILL DETERMINE WHICH RPO4/5/6 DRIVES ARE
;AVAILABLE FOR TESTING AND SET THE DRVSTA INDICATOR
;TO THE PROPER STATE FOR EACH DRIVE.
;NOTE: THIS ROUTINE CALLS DRVINT

```

CALL

```

JSR PC,RPINIT
RETURN

```

NOTE: THE 'P' OR 'L' CLOCK MUST BE STARTED

6670	034502	104412	RPINIT: SAVREG	:SAVE R0 - R5
6671	034504	013746	MOV 2#PS, -(SP)	:SAVE THE PRESENT PROCESSOR STATUS
6672	034510	012737	MOV 8<5*32.>, 2#PS	:CHANGE THE PRIORITY TO 5
6673	034516	004737	JSR PC, CLRQUE	:CLEAR ALL REQUEST QUEUES
6674	034522	012701	MOV #RPER5, R1	:FIRST ADDRESS TO BE CLEARED
6675	034526	012702	MOV #SEEKFG, R2	:LAST ADDRESS TO BE CLEARED
6676	034532	005021	1\$: CLR (R1)+	:CLEAR
6677	034534	020102	CMP R1, R2	:ARE WE DONE?
6678	034536	101775	BLOS 1\$	:BRANCH IF NO
6679	034540	012702	MOV #DTUM, R2	:LAST ADDRESS
6680	034544	012721	2\$: MOV #-1, (R1)+	:INITIALIZE
6681	034550	020102	CMP R1, R2	:DONE?
6682	034552	101774	BLOS 2\$	:LOOP IF NO
6683	034554	005037	CLR DRVSTA	:SET ALL DRIVES TO OFFLINE
6684	034560	005037	CLR DRVSTA+2	
6685	034564	005037	CLR DRVSTA+4	
6686	034570	005037	CLR DRVSTA+6	
6687	034574	013703	MOV RPVEC, R3	:SETUP THE RH11/RPO4/5/6 VECTOR
6688	034600	012723	MOV #ISR, (R3)+	
6689	034604	013713	MOV RPVEC+2, (R3)	
6690	034610	013704	MOV RPAOR, R4	:FIRST ADDRESS OF RH11/RPO4
6691	034614	012764	MOV #BIT05, RPCS2(R4)	:MASSBUS INIT
6692	034622	005001	CLR R1	:START WITH DRIVE 0
6693	034624	004037	3\$: JSR R0, DRVINT	:INIT THE DRIVE
6694	034630	000401	BR 4\$	: 'DVA' NOT SET OR PARITY ERROR
6695	034632	000402	BP 5\$	:NORMAL RETURN
6696	034634	105061	4\$: CLRB DRVSTA(R1)	:SET DRIVE STATUS TO OFFLINE
6697	034640	005201	5\$: INC R1	:GO TO NEXT DRIVE
6698	034642	042701	BIC #1C7, R1	:MASK OUT UNUSED BITS
6699	034646	001366	BNE 3\$	:BR IF MORE DRIVES TO GO

# K10

MD-11-DZRJA-AA RPO4/5/6 MECHANICAL AND READ/WRITE TEST MACY11 27(1006) 02-NOV-76 18:27 PAGE 128  
 DZRJA.014 19-APR-76 00:00 SINGLE/DUAL PORT RH11/RPO4/5/6 DRIVER (REV 1.0)

6700	034650	012701	000007				MOV	#7,R1	;START WITH DRIVE 7
6701	034654	005037	177776				CLR	#PS	;CLEAR THE PROCESSOR STATUS
6702	034660	105761	034356	6\$:			TSTB	DPINT(R1)	;WAITING FOR DRIVE TO SWITCH PORTS ?
6703	034664	001405					BEQ	8\$	;BR NOT WAITING
6704	034666	004737	042122				JSR	PC,SET.IE	;SET INTERRUPT
6705	034672	105761	034356	7\$:			TSTB	DPINT(R1)	;DRIVE SWITCHED PORTS ?
6706	034676	001375					BNE	7\$	;BR IF NOT
6707	034700	005301		8\$:			DEC	R1	;GO TO THE NEXT DRIVE
6708	034702	100366					BPL	6\$	;CHECK NEXT DRIVE
6709	034704	012637	177776				MOV	(SP)+,#PS	;RESTORE THE PROCESSOR STATUS
6710	034710	104413					RESREG		;RESTORE R0 - R5
6711	034712	000207					RTS	PC	;BYE-BYE
6712									
6713									
6714									
6715									
6716									
6717									
6718									
6719									
6720									
6721									
6722									
6723									
6724									
6725									
6726									
6727	034714	010546							
6728	034716	105061	034336						
6729	034722	105061	034346						
6730	034726	105061	034404						
6731	034732	010164	000010						
6732	034736	112764	000111	000000					
6733	034744	032764	010000	000010					
6734	034752	001403							
6735	034754	004737	042122						
6736	034760	000520							
6737	034762	105061	034336						
6738	034766	032764	034000	000000	1\$:				
6739	034774	001514							
6740	034776	004037	041432						
6741	035002	000026							
6742	035004	035246							
6743	035006	012605							
6744	035010	112761	000001	034346					
6745	035016	022705	020020						
6746	035022	001431							
6747	035024	022705	024020						
6748	035030	001426							
6749	035032	112761	000002	034346					
6750	035040	022705	020021						
6751	035044	001420							
6752	035046	022705	024021						
6753	035052	001415							
6754	035054	112761	000004	034346					
6755	035062	022705	020022						

**;DRIVE INITIALIZATION ROUTINE**

;THIS ROUTINE DETERMINES IF A DRIVE EXIST AND IF IT IS  
 ;AN RPO4/5/6. IF IT IS, A "READ-IN PRESET" IS ISSUED AND FMT22  
 ;IS SET TO A "1". THEN MOL, DPR, DRY, AND VV ARE CHECKED TO  
 ;INSURE THEY ARE ALL ON A "1". AND DEPENDING ON THEIR STATE,  
 ;DRVSTA IS SET TO THE PROPER CONDITION.

**;CALL**

MOV	#DRVNUM,R1	;DRIVE NUMBER TO R1
MOV	RPADR,R4	;UNIBUS ADDRESS OF RH11/RPO4/5/6 (RPCS1)
JSR	RO,DRVINT	;CALLED BY A JSR
RETURN1		;ERROR OCCURRED (PARITY)
RETURN2		;NORMAL RETURN

**DRVINT:**

MOV	R5,-(SP)	;SAVE R5
CLRB	DRVSTA(R1)	;START DRIVE STATUS AS OFFLINE
CLRB	DRVTP(R1)	;CLEAR THE DRIVE TYPE INDICATOR
CLRB	ULDFLG(R1)	;CLEAR THE UNLOAD FLAG
MOV	R1,RPCS2(R4)	;SELECT A DRIVE
MOVSB	#11,RPCS1(R4)	;DO A DRIVE CLEAR COMMAND (& SEIZE DRIVE)
BIT	#BIT12,RPCS2(R4)	;NONEXISTENT DRIVE?
BEQ	1\$	;NO---BRANCH
JSR	PC,SET.IE	;GO SET "IE" WITHOUT A "TRE"
BR	6\$	;LEAVE THIS ROUTINE
CLRB	DRVSTA(R1)	;SET DRIVE STATUS TO OFFLINE
BIT	#BIT11,RPCS1(R4)	;SEE IF DRIVE AVAILABLE
BEQ	7\$	;BR IF DRIVE NOT AVAILABLE
JSR	RO,RO.RP	;READ THE DRIVE TYPE REG.
RPO4		
BEQ	8\$	;ERROR RETURN ADDRESS
MOV	(SP)+,R5	;PUT DRIVE TYPE IN R5
MOVSB	#1,DRVTP(R1)	;SET RPO4 INDICATOR
CMP	#20020,R5	;IS IT A SINGLE PORT RPO4?
BEQ	2\$	;BRANCH IF YES
CMP	#24020,R5	;IS IT A DUAL PORT RPO4?
BEQ	2\$	;BR IF YES
MOVSB	#2,DRVTP(R1)	;SET RPO5 INDICATOR
CMP	#20021,R5	;SINGLE PORT RPO5 ?
BEQ	2\$	;BR IF YES
CMP	#24021,R5	;DUAL PORT RPO5 ?
BEQ	2\$	;BR IF YES
MOVSB	#4,DRVTP(R1)	;SET RPO6 INDICATOR
CMP	#20022,R5	;SINGLE PORT RPO6 ?

```

6756 035066 001407          BEQ      2$          ;BR IF YES
6757 035070 022705 024022      CMP      #24022,RS   ;DUAL PORT RPO6 ?
6758 035074 001404          BEQ      2$          ;BR IF YES
6759 035076 112761 177777 034346  MOVB    #-1,DRVTP(R1) ;SET INDICATOR TO 'OTHER'
6760 035104 000446          BR       6$          ;EXIT
6761 035106 012746 000121      2$:     MOV     #121, -(SP)   ;DO A "READ-IN PRESET"
6762 035112 004037 041612      JSR     RO, WRT.RP
6763 035116 000000          RPCSI
6764 035120 035246          BS
6765 035122 012746 010000      MOV     #BIT12, -(SP) ;SET FMT22=1
6766 035126 004037 041612      JSR     RO, WRT.RP
6767 035132 000032          RPOF
6768 035134 035246          BS
6769 035136 004037 041432      JSR     RO, RO.RP    ;READ RPO51
6770 035142 000012          RPO51
6771 035144 035246          BS
6772 035146 012605          MOV     (SP)+, RS    ;AND SAVE IT IN RS
6773 035150 100015          BPL     4$          ;BRANCH IF ATA=0
6774 035152 116164 034452 000016  MOVB    ATABIT(R1), RPA5(R4) ;CLEAR ATTENTION BIT
6775 035160 004037 041432      JSR     RO, RO.RP    ;FIND OUT WHY ATA=1
6776 035164 000014          RPER1
6777 035166 035246          BS
6778 035170 006126          ROL     (SP)+        ;IS IT UNSAFE?
6779 035172 100004          BPL     4$          ;BR IF NOT
6780 035174 112761 177777 034336  MOVB    #-1,DRVSTA(R1) ;SET UNSAFE INDICATOR
6781 035202 000407          BR       6$          ;EXIT
6782 035204 005105          COM     RS          ;CHECK MOL, DPR, DRY, AND VV
6783 035206 042705 167077      BIC     #1<BIT12:BIT08:BIT07:BIT06>, RS
6784 035212 001003          BNE     6$          ;BRANCH IF MOL, DPR, DRY, OR VV IS CLEAR
6785 035214 112761 000001 034336  MOVB    #1,DRVSTA(R1) ;SET DRIVE STATUS TO ONLINE
6786 035222 005720          TST    (RO)+        ;STEP OVER THE ERROR RETURN
6787 035224 000410          BR       8$          ;EXIT
6788 035226 006301          ASL     R1          ;CHANGE INDEX TO ADDRESS WORDS
6789 035230 012761 003720 034430  MOV     #2000., TIMER(R1) ;START 2 SEC TIMER
6790 035236 006201          ASR     R1          ;RESTORE R1
6791 035240 112761 177777 034356  MOVB    #-1, DPINT(R1) ;SET PORT INITIALIZE INDICATOR
6792 035246 012605          MOV     (SP)+, RS    ;RESTORE RS
6793 035250 000200          RTS     RO          ;EXIT
6794
6795 ;REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
6796
6797 ;CALL
6798
6799 ;
6800 ; JSR     RO, #RPO4 ;CALL THE RPO4/5/6 DRIVER
6801 ; PNTADR ;ADDRESS OF POINTER OF DRIVES PARAMETER BLOCK
6802 ; RETURN1 ;RETURN HERE IF QUEUE IS FULL
6803 ; RETURN2 ;RETURN HERE IF REQUEST IS IN QUEUE OR THERE
6804 ; IS AN ERROR CONDITION
6805 RPO4: MOV     #RPS, -(SP) ;SAVE THE CALLING STATUS
6806 MOV     RVEC+2, #RPS ;DON'T ALLOW ANY RPO4/5/6 INTERRUPTS
6807 MOVB    #1, ACTDRV ;SET "ACTIVE DRIVER" FLAG
6808 SAVREG ;SAVE RO - R5
6809 MOV     (RO), R2    ;PICKUP THE DRIVE PARAMETER BLOCK POINTER
6810 CLR     16(R2)     ;CLEAR THE STATUS/ERROR INDICATOR
6811 MOVB    (R2), R1    ;PICKUP THE DRIVE NUMBER
    
```

# M10

6812	035304	013704	034464		MOV	RPADR,R4	: UNIBUS ADDRESS OF RPCS1
6813	035310	105761	034336		TSTB	DRVSTA(R1)	: CHECK DRIVES STATUS
6814	035314	003014			BGT	1\$	: BRANCH IF ONLINE
6815	035316	105761	034404		TSTB	ULDFLG(R1)	: UNLOAD COMMAND IN QUEUE?
6816	035322	001036			BNE	3\$	: BRANCH IF YES
6817	035324	105761	034356		TSTB	DPINT(R1)	: TRYING TO INIT THE DRIVE
6818	035330	001042			BNE	5\$	: BR IF YES
6819	035332	004037	034714		JSR	RO,DRVINT	: GO INIT. THE DRIVE
6820	035336	000434			BR	4\$	: ERROR RETURN
6821	035340	105761	034336		TSTB	DRVSTA(R1)	: IS DRIVE STATUS ONLINE?
6822	035344	003445			BLE	6\$	: BR IF NOT
6823	035346	105761	034366	1\$:	TSTB	DPROS(R1)	: OUTSTANDING PORT REQUEST FOR THE DRIVE ?
6824	035352	001031			BNE	5\$	: BR IF YES
6825	035354	012164	000010		MOV	R1,RPCS2(R4)	: SELECT THE DRIVE
6826	035360	004037	042564		JSR	RO,DRVQUE	: PUT THIS REQUEST IN QUEUE
6827	035364	000460			BR	9\$	: QUEUE IS FULL
6828	035366	122762	000103	000002	CMPS	#103,2(R2)	: IS THIS REQ. FOR AN UNLOAD?
6829	035370	001003			BNE	2\$	: BR IF NO
6830	035376	112761	177777	034404	MOVB	#-1,ULDFLG(R1)	: SET THE "UNLOAD IN QUEUE" FLAG
6831	035404	105761	034326	2\$:	TSTB	DRVACT(R1)	: IS THIS DRIVE ACTIVE?
6832	035410	001043			BNE	8\$	: BR IF YES
6833	035412	004737	035544		JSR	PC,OPT	: CALL THE OPTIMIZER
6834	035416	000440			BR	8\$	
6835	035420	012762	120000	000016	3\$:	MOV	#BIT15:BIT13,16(R2) : SET THE "UNLOAD IN QUEUE" ERROR FLAG
6836	035426	000434			BR	8\$	: EXIT
6837	035430	004737	036654	4\$:	JSR	PC,C17	: GO HANDLE THE PARITY ERROR
6838	035434	000431			BR	8\$	
6839	035436	004037	042564	5\$:	JSR	RO,DRVQUE	: PUT REQUEST IN QUEUE
6840	035442	000431			BR	9\$	: QUEUE IS FULL
6841	035444	032714	000100		BIT	#BIT06,(R4)	: IS 'IE' SET ALREADY ?
6842	035450	001023			BNE	8\$	: BR IF IT IS
6843	035452	004737	042122		JSR	PC,SET.IE	: SET INTERRUPT
6844	035456	000420			BR	8\$	: RETURN, REQUEST IN QUEUE
6845	035460	105761	034336	6\$:	TSTB	DRVSTA(R1)	: SEE IF DRIVE OFFLINE OR UNSAFE
6846	035464	002412			BLT	7\$	: BR IF UNSAFE
6847	035466	012762	140000	000016	MOV	#BIT15:BIT14,16(R2) : SET OFFLINE ERROR INDICATOR	
6848	035474	105761	034346		TSTB	DRVSTYP(R1)	: SEE IF OFFLINE OR NONEXISTENT
6849	035500	001007			BNE	8\$	: BR IF OFFLINE
6850	035502	012762	100002	000016	MOV	#BIT15:BIT01,16(R2) : REPORT DRIVE NONEXISTENT	
6851	035510	000403			BR	8\$	: GO TO EXIT
6852	035512	012762	110000	000016	7\$:	MOV	#BIT15:BIT12,16(R2) : DRIVE IS UNSAFE
6853	035520	104413		8\$:	RESREG		: RESTORE R0 - R5
6854	035522	005720			TST	(R0)+	: SETUP FOR NORMAL RETURN
6855	035524	000401			BR	10\$	: FINISH UP, THEN EXIT
6856	035526	104413		9\$:	RESREG		: RESTORE R0 - R5
6857	035530	005720		10\$:	TST	(R0)+	: CORRECT THE RETURN ADDRESS
6858	035532	105037	034402		CLRB	ACTDRV	: CLEAR "ACTIVE DRIVER" FLAG
6859	035536	012637	177776		MOV	(SP)+,2#PS	: RETURN "PS" TO USER LEVEL
6860	035542	000200			RTS	RO	: RETURN TO CALLER
6861							
6862							: OPTIMIZER-CALLED FOR A PARTICULAR DRIVE
6863							
6864							: CALL
6865					MOV	#DRVNUM,R1	: DRIVE NUMBER TO R1
6866					JSR	PC,OPT	: SETUP A COMMAND
6867							

# N10

6868	035544	104412			OPT: SAVREG	
6869	035546	013746	177776		MOV	2#PS -(SP) ;SAVE R0 - R5
6870	035552	146137	034452	034400	BICB	ATABIT(R1),SRCHMT ;SAVE PROC. STATUS
6871	035560	004737	042640		JSR	PC,GETREQ ;CLEAR "SEARCH WAIT" KEY
6872	035564	005702			TST	R2 ;GET "DPS" POINTER OF REQUEST
6873	035566	001505			BEQ	7\$ ;IS THERE A REQUEST IN QUEUE?
6874	035570	032764	010000	000012	BIT	#BIT12,RPDS1(R4) ;NO--BRANCH TO EXIT
6875	035576	001404			BEQ	9\$ ;IS MOL STILL SET ?
6876	035600	032764	000100	000012	BIT	#BIT6,RPDS1(R4) ;BR IF NOT
6877	035606	001003			BNE	10\$ ;IS VV SET ?
6878	035610	004037	034714		JSR	RO,DRVINT ;BR IF IT IS
6879	035614	000470			BR	6\$ ;SEE IF DRIVE STILL ONLINE ?
6880	035616	105761	034336		10\$: TSTB	DRVSTA(R1) ;PARITY OR 'DVA' NOT SET
6881	035622	003014			BGT	1\$ ;IS DRIVE ONLINE?
6882	035624	004737	042662		JSR	PC,POPQUE ;YES--BRANCH
6883	035630	012762	140000	000016	MOV	#BIT15!BIT14,16(R2) ;NO--REMOVE REQUEST FROM QUEUE
6884	035636	105761	034336		TSTB	DRVSTA(R1) ;SET OFFLINE STATUS/ERROR INDICATOR
6885	035642	100064			BPL	8\$ ;IS DRIVE UNSAFE ?
6886	035644	012762	110000	000016	MOV	#BIT15!BIT12,15(R2) ;BR TO EXIT IF NOT
6887	035652	000460			BR	8\$ ;SET UNSAFE STATUS/ERROR INDICATOR
6888	035654	012746	000111		15\$: MOV	#111,-(SP) ;BRANCH TO EXIT
6889	035660	004037	041612		JSR	RO,WRT.RP ;LOAD COMMAND ONTO THE STACK
6890	035664	000000			RPCS1	6\$ ;LOAD THE REGISTER
6891	035666	035776			6\$	6\$ ;REGISTER INCREMENT
6892	035670	032714	004000		BIT	#BIT11,(R4) ;ERROR RETURN ADDRESS
6893	035674	001427			BEQ	5\$ ;DRIVE AVAILABLE ?
6894	035676	122762	000150	000002	CMPB	#150,2(R2) ;BR IF NOT
6895	035704	002403			BLT	2\$ ;IS THE REQUEST FOR I/O?
6896	035706	004737	036240		JSR	PC,C14 ;YES--BRANCH
6897	035712	000440			BR	8\$ ;CALL THE COMMAND INITIATOR
6898	035714	005737	034450		2\$: TST	DTUM ;BRANCH TO EXIT
6899	035720	002012			BGE	4\$ ;DATA TRANSFER UNDERWAY?
6900	035722	005737	034426		TST	SEEKFG ;YES--GO START A SEARCH
6901	035726	100404			JMI	3\$ ;DO IMPLIED SEEKS?
6902	035730	004037	037210		JSR	RO,LA ;YES---BRANCH
6903	035734	000427			BR	8\$ ;NO--DO LOOK AHEAD
6904	035736	000403			BR	4\$ ;RETURN HERE ON A PARITY ERROR
6905	035740	004737	036024		3\$: JSR	PC,C11 ;GO START A SEARCH
6906	035744	000423			BR	8\$ ;START A DATA TRANSFER
6907	035746	004737	036132		4\$: JSR	PC,C13 ;START A SEARCH
6908	035752	000420			BR	8\$ ;GO TO THE EXIT
6909	035754	112761	177777	034366	5\$: MOVB	#-1,DPROS(R1) ;SET PORT REQUEST INDICATOR
6910	035762	010103			MOV	R1,R3 ;SET UP TO ADDRESS WORDS
6911	035764	006303			ASL	R3 ;CONVERT TO WORD INDEX
6912	035766	012763	023420	034430	MOV	#10000.,TIMER(R3) ;START 10 SEC TIMER
6913	035774	000402			BR	7\$ ;EXIT
6914	035776	004737	036654		6\$: JSR	PC,C17 ;PROCESS THE PARITY ERROR
6915	036002	032714	000100		7\$: BIT	#BIT06,(R4) ;SEE IF 'IE' ALREADY SET
6916	036006	001002			BNE	8\$ ;BR IF SET
6917	036010	004737	042122		JSR	PC,SET.IE ;SET "IE" WITHOUT A "TRE"
6918	036014	012637	177776		8\$: MOV	(SP)+,2#PS ;RESTORE PROC. STATUS
6919	036020	104413			RESREG	PC ;RESTORE R0 - R5
6920	036022	000207			RTS	PC
6921						
6922						
6923						

;COMMAND INITIATOR  
;



```

6924          :CALL
6925          :
6926          :
6927          :
6928          :
6929          :
6930          :
6931          :
6932          :
6933 036024 004737 042662      C11: JSR PC,POQUE      ; REMOVE REQUEST FROM "DRIVES WAIT" QUEUE
6934 036030 010237 034376      MOV R2,TRANSWT    ; PUT REQ. IN TRANSFER WAIT QUEUE
6935 036034 010203              MOV R2,R3         ; DPB ADDRESS TO R3
6936 036036 013704 034464      MOV RPADR,R4     ; RPCS1 ADDRESS
6937 036042 010164 000010      MOV R1,RPCS2(R4) ; SELECT DRIVE
6938 036046 062703 000004      ADD #4,R3        ; DESIRED WORD COUNT
6939 036052 062704 00000E      ADD #2,R4        ; RPMC ADDRESS
6940 036056 012324              MOV (R3)+,(R4)+  ; LOAD WORD COUNT
6941 036060 012324              MOV (R3)+,(R4)+  ; LOAD BUFFER ADDRESS
6942 036062 012346              MOV (R3)+,-(SP)  ; LOAD SECTOR AND TRACK
6943 036064 004037 041612      JSR RO,WRT.RP    ; CALL THE LOAD(WRITE) ROUTINE
6944 036070 000006              RPDAR            ; INDEX OF REGISTER TO LOAD
6945 036072 036654              CI7             ; ERROR RETURN ADDRESS
6946 036074 012346              MOV (R3)+,-(SP) ; LOAD CYLINDER ADDRESS
6947 036076 004037 041612      JSR RO,WRT.RP
6948 036102 000034              RPCA            ;
6949 036104 036654              CI7             ;
6950 036106 016246 000002      MOV 2(R2),-(SP) ; LOAD "COMMAND+GO", "A17&A16", AND "PSEL"
6951 036112 004037 041612      JSR RO,WRT.RP
6952 036116 000000              RPCS1           ;
6953 036120 036654              CI7             ;
6954 036122 010137 034450      MOV R1,DTUM      ; SET "DATA TRANSFER UNDERWAY"
6955 036126 000137 03661E      JMP CIS          ;
6956 036132 013704 034464      C13: MOV RPADR,R4    ; RPCS1 ADDRESS
6957 036136 010164 000010      MOV R1,RPCS2(R4) ; SELECT DRIVE
6958 036142 016246 00001E      MOV 12(R2),-(SP) ; DESIRED CYLINDER ADDRESS
6959 036146 004037 041612      JSR RO,WRT.RP
6960 036152 000034              RPCA            ;
6961 036154 036654              CI7             ;
6962 036156 116203 000010      MOV#B 10(R2),R3  ; PICKUP SECTOR ADDRESS
6963 036162 163703 034500      SUB MYWINDOW,R3  ; BACKUP BY MAX. SEARCH FOR I/O WINDOW
6964 036166 002002 15              BGE 15           ;
6965 036170 062703 000026      ADD #22,R3       ;
6966 036174 010346 15              15              ;
6967 036176 116266 000011 000001 15: MOV R3,-(SP)     ; COMBINE THE ADJUSTED SECTOR WITH
6968 036204 004037 041612      JSR RO,WRT.RP    ; THE DESIRED TRACK
6969 036210 000006              RPDAR            ; LOAD DESIRED TRACK & SECTOR
6970 036212 036654              CI7             ;
6971 036214 012746 000131      MOV #131,-(SP)   ; START A SEARCH
6972 036220 004037 041612      JSR RO,WRT.RP
6973 036224 000000              RPCS1           ;
6974 036226 036654              CI7             ;
6975 036230 156137 034452 034400  B1SB ATABIT(R1),SRCHWT ; SET "SEARCH WAIT" KEY
6976 036236 000067              BR CIS          ;
6977 036240 013704 034464      C14: MOV RPADR,R4    ; RPCS1 ADDRESS
6978 036244 010154 000010      MOV R1,RPCS2(R4) ; SELECT DRIVE
6979 036250 116203 000002      MOV#B 2(R2),R3   ; PICKUP THE REQUESTED COMMAND

```

# C11

6980	036254	122703	000131		CMPB	#131,R3	: IS IT A SEARCH COMMAND?
6981	036260	001007			BNE	1\$	: BRANCH IF NO
6982	036262	016246	000010		MOV	10(R2),-(^0)	: LOAD DESIRED TRACK & SECTOR
6983	036265	004037	041612		JSR	RO,WRT.RP	
6984	036272	000006			RPOA		
6985	036274	036654			CI7		
6986	036276	000403			BR	2\$	: GO LOAD CYLINDER
6987	036300	122703	000105	1\$:	CMPB	#105,R3	: IS IT A SEEK COMMAND
6988	036304	001007			BNE	3\$	: BRANCH IF NO
6989	036306	016246	000012	2\$:	MOV	12(R2),-(SP)	: LOAD DESIRED CYLINDER
6990	036312	004037	041612		JSR	RO,WRT.RP	
6991	036316	000034			RPOA		
6992	036320	036654			CI7		
6993	036322	000546			BR	CI6	
6994	036324	122703	000115	3\$:	CMPB	#115,R3	: IS IT AN "OFFSET" COMMAND?
6995	036330	001013			BNE	4\$	: BR IF NO
6996	036332	004037	041432		JSR	RO,RO.RP	: MERGE THE OFFSET VALUE INTO RPOF
6997	036336	000032			RPOF		: BUT DON'T CHANGE THE UPPER
6998	036340	036654			CI7		
6999	036342	116216	000001		MOV8	1(R2),(SP)	: BYTE WHEN LOADING THE
7000	036346	004037	041612		JSR	RO,WRT.RP	: REGISTER (RPOF)
7001	036352	000032			RPOF		
7002	036354	036654			CI7		
7003	036356	000530			BR	CI6	: GO START THE COMMAND
7004	036360	122703	000107	4\$:	CMPB	#107,R3	: IS IT A "RECALIBRATE" COMMAND?
7005	036364	001525			BEQ	CI6	: BRANCH IF YES
7006	036366	122703	000117		CMPB	#117,R3	: IS IT A RETURN TO CENTER?
7007	036372	001522			BEQ	CI6	: BRANCH IF YES
7008	036374	122703	000103		CMPB	#103,R3	: IS IT AN "UNLOAD" COMMAND?
7009	036400	001016			BNE	5\$	: BRANCH IF NO
7010	036402	112761	000001	034326	MOV8	#1,DRVACT(R1)	: SET THE DRIVE ACTIVE INDICATOR
7011	036410	105061	034336		CLR8	DRVSTA(R1)	: PUT DRIVE STATUS TO OFFLINE
7012	036414	112761	000001	034404	MOV8	#1,ULDFLG(R1)	: SET "UNLOAD IN PROGRESS" FLAG
7013	036422	010346			MOV	R3,-(SP)	: START THE "UNLOAD" COMMAND
7014	036424	004037	041612		JSR	RO,WRT.RP	
7015	036430	000000			RPCS1		
7016	036432	036654			CI7		
7017	036434	000207			RTS	PC	: RETURN TO USER
7018	036436	122703	000143	5\$:	CMPB	#143,R3	: IS IT A "SET FORMAT" COMMAND?
7019	036442	001014			BNE	6\$	: BRANCH IF NO
7020	036444	004037	041432		JSR	RO,RO.RP	: READ THE OFFSET REGISTER
7021	036450	000032			RPOF		
7022	036452	036654			CI7		
7023	036454	116256	000001	000001	MOV8	1(R2),1(SP)	: COMBINE "FMT22", "ECI", AND "HCI"
7024	036462	004037	041612		JSR	RO,WRT.RP	: LOAD "FMT22", "ECI", AND/OR "HCI".
7025	036466	000032			RPOF		
7026	036470	036654			CI7		
7027	036472	000436			BR	12\$	
7028	036474	122703	000141	6\$:	CMPB	#141,R3	: IS IT A "GET REGISTER" COMMAND?
7029	036500	001023			BNE	10\$	: BRANCH IF NO
7030	036502	016203	000006	7\$:	MOV	6(R2),R3	: POINTS TO 1ST ADDRESS OF WHERE
7031							: TO PUT THE REGISTER(S)
7032	036506	116237	000010	036524	MOV8	10(R2),9\$	: INIT. THE INDEX FOR THE FIRST REG.
7033	036514	116205	000011		MOV8	11(R2),R5	: INDEX OF LAST REG. TO MOVE
7034	036520	004037	041432	8\$:	JSR	RO,RO.RP	: READ RPO4/5/6 REGISTER
7035	036524	000000		9\$:	RPCS1		: INDEX OF REG. TO READ

7036	036526	036654				CI7		
7037	036530	012623				MOV	(SP)+,(R3)+	;GET THE CONTENTS OF RH11/RPO4/5/6 REG.
7038	036532	023705	036524			CMP	R6,R5	;LAST REG. BEEN READ?
7039	036536	001414				BEQ	124	;GET OUT IF YES
7040	036540	062737	000002	036524		ADD	R2,R6	;INCREASE THE INDEX BY 2
7041	036546	000764				BR	R6	;LOOP--MORE TO READ
7042	036550	122703	000145		108:	CMPB	R145,R3	;IS IT A "SELECT DRIVE" COMMAND?
7043	036554	001405				BEQ	128	;BRANCH IF YES
7044	036556	010346			118:	MOV	R3,-(SP)	;LOAD THE COMMAND
7045	036560	004037	041612			JSR	RD,WRT.RP	
7046	036564	000000				RPCS1		
7047	036566	036654				CI7		
7048	036570	004737	042662		128:	JSR	PC,POPQUE	;REMOVE REQ. FROM QUEUE
7049	036574	052762	000200	000016		BIS	R8BIT07,16(R2)	;SET THE "DONE" BIT
7050	036602	005737	034424			TST	SAVEFG	;SAVE THE RH11/RPO4/5/6 REGISTERS?
7051	036606	100002				BPL	138	;BRANCH IF NO
7052	036610	004737	042004			JSR	PC,SVRH11	;YES--GO SAVE THE REGISTERS
7053	036614	000207			138:	RTS	PC	;RETURN TO USER
7054	036616	006301			CI5:	ASL	R1	
7055	036620	012761	001750	034430		MOV	R1000.,TIMER(R1)	;SET A ONE SECOND TIMER
7056	036626	006201				ASR	R1	
7057	036630	112761	000001	034326		MOV	R1,DRVACT(R1)	;SET THE DRIVE ACTIVE
7058	036636	000207				RTS	PC	;RETURN TO THE USER
7059	036640	010346			CI6:	MOV	R3,-(SP)	;LOAD THE COMMAND
7060	036642	004037	041612			JSR	RD,WRT.RP	
7061	036646	000000				RPCS1		
7062	036650	036654				CI7		
7063	036652	000761				BR	CI5	
7064	036654	032764	010000	000010	CI7:	BIT	R8BIT12,RPCS2(R4)	;DRIVE NON-EXISTENT ?
7065	036662	001034				BNE	CI8	;BR IF YES
7066	036664	005702			18:	TST	R2	;ANYTHING IN QUEUE ?
7067	036666	001405				BEQ	CI7B	;BR IF NOT
7068	036670	012762	104000	000016		MOV	R8BIT15!BIT11,16(R2)	;SET "PARITY" ERROR INDICATOR
7069	036676	004737	042004			JSR	PC,SVRH11	;GO SAVE THE RH11/RPO4/5/6 REGISTERS
7070	036702	012746	000111		CI7B:	MOV	R11,-(SP)	;DO A "DRIVE CLEAR"
7071	036706	004037	041612			JSR	RD,WRT.RP	
7072	036712	000000				RPCS1		
7073	036714	036754				CI8		
7074	036716	004737	042544			JSR	PC,EMPTYQ	;EMPTY THE QUEUE
7075	036722	105061	034404			CLR	UI,DFLG(R1)	;CLEAR THE UNLOAD IN QUEUE FLAG
7076	036726	105061	034326			CLR	DRVACT(R1)	;DRIVE IS IDLE
7077	036732	020137	034450			CMP	R1,DTUM	;IF THIS DRIVE HAD AN I/O REQUEST
7078	036736	001005				BNE	18	;IN PROGRESS CLEAR ALL OF THE FLAGS
7079	036740	005037	034376			CLR	TRANST	
7080	036744	012737	177777	034450		MOV	R-1,DTUM	
7081	036752	000207			18:	RTS	PC	
7082	036754	104412			CI8:	SAVREG		;SAVE RD - RS
7083	036756	032764	010000	000010		BIT	R8BIT12,RPCS2(R4)	;IS "RED" SET ?
7084	036764	001002				BNE	18	;BR IF YES
7085	036766	000001				CLR	R1	
7086	036770	000003				CLR	R3	
7087	036772	105761	034326		18:	TST	DRVACT(R1)	;DRIVE ACTIVE?
7088	036776	001443				BEQ	58	;BRANCH IF NO
7089	037000	013702	034376			MOV	TRANST,R2	;GET THE "TRANSFER WAIT" QUEUE
7090	037004	020137	034450			CMP	R1,DTUM	;DID THIS DRIVE HAVE AN I/O IN PROGRESS?
7091	037010	001402				BEQ	28	;BRANCH IF YES

# E11

7092	037012	004737	042640		JSR	PC, GETREQ	:GET THE DPB POINTER	
7093	037016	005702		2S:	TST	R2	:QUEUE ENTRY FOR DRIVE ?	
7094	037020	001415			BEQ	4S	:BR IF NOT	
7095	037022	032764	010000	000010	BIT	#BIT12, RPCS2(R4)	: 'MED' SET ?	
7096	037030	001404			BEQ	3S	:BR IF NOT	
7097	037032	012762	100002	000016	NOV	#BIT15!BIT01, 16(R2)	:SET 'DRIVE NON-EXISTENT' INDICATOR	
7098	037040	000405			BR	4S	:CONTINUE	
7099	037042	012762	102000	000016	NOV	#BIT15!BIT10, 16(R2)	:SET "NON-CLEARABLE PARITY" ERROR INDICATOR	
7100	037050	004737	042004		JSR	PC, SVRH11	:SAVE RH11/RP04/5/6 REGISTERS	
7101	037054	012763	177777	034430	NOV	#-1, TIMER(R3)	:STOP THE TIMER	
7102	037062	105061	034326		CLRB	DRVACT(R1)	:SET "DRIVE ACTIVE" TO IDLE	
7103	037066	020137	034450		CHP	R1, DTUM	:IS THIS DRIVE SET UP FOR A TRANSFER	
7104	037072	001005			BNE	5S	:BR IF NOT	
7105	037074	012737	177777	034450	NOV	#-1, DTUM	:RESET THE INDICATOR	
7106	037102	005037	034376		CLR	TRNSWT	:CLEAR THE TRANSFER QUEUE	
7107	037106	105061	034404		CLRB	ULDFLG(R1)	:CLEAR UNLOAD FLAG	
7108	037112	032764	010000	000010	BIT	#BIT12, RPCS2(R4)	: 'MED' SET ?	
7109	037120	001021			BNE	6S	:BR IF YES	
7110	037122	005201			INC	R1	:MOVE TO THE NEXT DRIVE	
7111	037124	762703	000002		ADD	#2, R3		
7112	037130	042701	177770		BIC	#1C7, R1		
7113	037134	001316			BNE	1S	:BRANCH IF MORE DRIVES	
7114	037136	012737	177777	034450	NOV	#-1, DTUM	:NO DATA TRANSFERS UNDERWAY	
7115	037144	005037	034376		CLR	TRNSWT	:CLEAR THE 'TRANSFER WAIT' QUEUE	
7116	037150	004737	042466		JSR	PC, CLRQUE	:CLEAR ALL OF THE REQUEST QUEUES	
7117	037154	012764	000040	000010	NOV	#BIT05, RPCS2(R4)	:DO A MASSBUS INIT.	
7118	037162	000406			BR	7S	:CONTINUE	
7119	037164	004737	042544		JSR	PC, EMPTYQ	:CLEAR THE DRIVE'S QUEUE	
7120	037170	105061	034336		CLRB	DRVSTA(R1)	:SET DRIVE TO OFFLINE	
7121	037174	105061	034346		CLRB	DRVTYP(R1)	:CLEAR THE DRIVE TYPE INDICATOR	
7122	037200	004737	042122		JSR	PC, SET.IE	:SET "IE" WITHOUT "TRE"	
7123	037204	104413			RESREG		:RESTORE R0 - R5	
7124	037206	000207			RTS	PC	:RETURN	
7125								
7126								
7127								
7128								
7129								
7130								
7131								
7132								
7133								
7134								
7135								
7136	037210	013704	034464		LA:	MOV	RPAOR, R4	:GET RPCS1'S ADDRESS
7137	037214	010164	000010			MOV	R1, RPCS2(R4)	:SELECT DRIVE
7138	037220	004037	041432			JSR	RO, RA	:READ CURRENT CYLINDER
7139	037224	000036				RPCC		
7140	037226	037340				4S		:ERROR RETURN ADDRESS
7141	037230	022662	000012			CHP	(SP)+, 12(R2)	:IS CURRENT CYLINDER=DESIRED
7142								:CYLINDER?
7143	037234	001037				BNE	3S	:EXIT IF NO
7144	037236	105261	034414			INCB	LACNT(R1)	:INCREMENT THE LOOK AHEAD COUNT
7145	037242	126137	034414	034472		CMPS	LACNT(R1), MXLACT	:EXCEED MAX?
7146	037250	003026				BGT	2S	:BRANCH IF YES
7147	037252	116203	000010			MOVB	10(R2), R3	:GET DESIRED SECTOR ADDRESS AND

:LOOK AHEAD ROUTINE

:CALL

```

MOV    #DRVNUM, R1    ;DRIVE NUMBER
MOV    #DPB, R2      ;POINT TO DPB
JSR    RO, LA        ;GO CHECK THE WINDOW
RETURN1 ;ERROR RETURN
RETURN2 ;START A SEARCH
RETURN3 ;START A DATA TRANSFER
  
```

# F11

7148	037256	000303				SWAB	R3		;MULT. BY 64--ALIGN WITH
7149	037260	006203				ASR	R3		;LOOK AHEAD REGISTER
7150	037262	006203				ASR	R3		
7151	037264	012737	000340	177776		MOV	#340, #PS		;PRIORITY LEVEL "7"
7152	037272	004037	041432			JSR	RD, RD.RP		;READ LOOK AHEAD REGISTER
7153	037276	000020				RPLA			
7154	037300	037340				4\$			
7155	037302	162603				SUB	(SP)+, R3		;CALCULATE THE DELTA
7156	037304	002002				BGE	1\$		
7157	037306	062703	002600			ADD	#(22.#64.), R3		;MAKE THE DELTA POSITIVE
7158	037312	023703	034474		1\$:	CMP	MDLTA, R3		;CHECK THE DELTA TO SEE
7159	037316	002406				BLT	3\$		;IF IT IS WITHIN THE
7160	037320	023703	034476			CMP	MDLTA, R3		;WINDOW---IF YES, ZERO
7161	037324	002003				BGE	3\$		;THE LOOK AHEAD COUNT
7162	037326	105061	034414		2\$:	CLRB	LACNT(R1)		;AND TAKE THE I/O EXIT
7163	037332	005720				TST	(R0)+		
7164	037334	005720			3\$:	TST	(R0)+		;ADJUST THE RETURN ADDRESS
7165	037336	000402				BR	5\$		;EXIT
7166	037340	004737	036654		4\$:	JSR	PC, CI7		;PROCESS THE ERROR
7167	037344	000200			5\$:	RTS	RO		;RETURN
7168									
7169									; INTERRUPT SERVICE ROUTINE
7170									
7171	037346	112737	000001	034402	ISR:	MOVB	#1, ACTDRV		;SET "ACTIVE DRIVER" FLAG
7172	037354	104412				SAVREG			;SAVE R0 - R5
7173	037356	013704	034464			MOV	RPADR, R4		;ADDRESS OF RMCSI
7174	037362	013701	034450			MOV	DTUM, R1		;GET "DATA TRANSFER UNDERWAY" INDICATOR
7175	037366	002403				BLT	1\$		;BRANCH IF NO DATA TRANSFER UNDERWAY
7176	037370	004737	037412			JSR	PC, TD		;CALL TRANSFER DONE
7177	037374	000402				BR	2\$		;EXIT
7178	037376	004737	037552		1\$:	JSR	PC, SC		;CALL SPECIAL CONDITIONS
7179	037402	104413			2\$:	RESREG			;RESTORE R0 - R5
7180	037404	105037	034402			CLRB	ACTDRV		;CLEAR "ACTIVE DRIVER" FLAG
7181	037410	000002				RTI			;RETURN
7182									
7183									; TRANSFER DONE ROUTINE
7184									
7185	037412	105061	034326		TD:	CLRB	DRVACT(R1)		;SET DRIVE ACTIVE INDICATOR TO IDLE
7186	037416	012737	177777	034450		MOV	#-1, DTUM		;NO DATA TRANSFERS UNDERWAY
7187	037424	006301				ASL	R1		
7188	037426	012761	177777	034430		MOV	#-1, TIMER(R1)		;CANCEL TIMEOUT
7189	037434	006201				ASR	R1		
7190	037436	013702	034376			MOV	TRNSWT, R2		;GET "DPB" ADDRESS FROM THE
7191	037442	005037	034376			CLR	TRNSWT		;TRANSFER WAIT QUEUE--CLEAR QUEUE
7192	037446	052762	000200	000016		BIS	#BIT07, 16(R2)		;SET DONE
7193	037454	010164	000010			MOV	R1, RPCS2(R4)		;SELECT THE DRIVE
7194	037460	004037	041432			JSR	RD, RD.RP		;TRANSFER ERROR(TRE=1)?
7195	037464	000000				RPCS1			
7196	037466	036654				CI7			
7197	037470	006126				ROL	(SP)+		
7198	037472	100413				BMI	3\$		;BR IF YES
7199	037474	005737	034424			TST	SAVEFG		;SAVE THE RH11/RPO4/5/6 REGISTERS?
7200	037500	100002				BPL	1\$		;BRANCH IF NO
7201	037502	004737	042004			JSR	PC, SVRH11		;YES--SAVE THE REGISTERS
7202	037506	004737	035544		1\$:	JSR	PC, OPT		;CALL OPTIMIZER
7203	037512	000417				BR	SC		;CHECK OTHER DRIVES

# G11

```

7204 037514 012714 000113      2$:  MOV      #113,(R4)      ;RELEASE THE DRIVE
7205 037520 000414              BR          SC             ;CHECK FOR OTHER DRIVES
7206 037522 052762 100100 000016 3$:  BIS      #BIT15!BIT06,16(R2) ;SET DATA ERROR FLAG
7207 037530 004737 042544              JSR      PC,EMPTYQ        ;EMPTY THE "DRIVE'S WAIT" QUEUE
7208 037534 004737 042004              JSR      PC,SVRH11        ;SAVE THE RH11/RPO4/5/6 REGISTERS
7209 037540 012714 040111              MOV      #40111,(R4)     ;ISSUE A "DRIVE CLEAR"
7210 037544 012714 000113              MOV      #113,(R4)     ;ISSUE A RELEASE TO THE DRIVE
7211 037550 000400              BR          SC             ;CHECK FOR OTHER DRIVES
7212
7213
7214
7215 037552 116403 000016      SC:  MOVB    RPAS(R4),R3     ;READ "RPAS"
7216 037556 001014              BNE     2$                ;BRANCH IF ANY 'ATA' BITS SET
7217 037560 004037 041432              JSR      RD,RD.RP        ;READ CONTROL AND STATUS REGISTER
7218 037564 000000              RPCS1
7219 037566 036754              CIB
7220 037570 106126              ROLB    (SP)+
7221 037572 100405              BMI     1$                ;IS "IE"=1?
7222 037574 004037 042724              JSR      RD,ES.SAV      ;YES NO DRIVES TO CHECK
7223 037600 104001              ERROR   1                 ;SAVE THE ADDRESS IN 'SESCAPE'
7224 037602 004737 042122              JSR      PC,SET.IE      ;REPORT AN ILLEGAL INTERRUPT
7225 037606 000207              RTS     PC                ;SET INTERRUPT ENABLE
7226 037610 005046              CLR     -(SP)            ;RETURN
7227 037612 110316              MOVB    R3,(SP)         ;PROCESS ALL DRIVES THAT HAVE
7228 037614 012703 000001              MOV      #1,R3          ;AN "ATA"=1
7229 037620 005001              CLR     R1
7230 037622 030316      SC3:  BIT      R3,(SP)        ;ATA=1?
7231 037624 001005              BNE     SC5              ;YES--BRANCH
7232 037626 005201      SC4:  INC     R1             ;MOVE TO THE NEXT DRIVE
7233 037630 106303              ASLB    R3
7234 037632 001373              BNE     SC3              ;BRANCH IF MORE TO CHECK?
7235 037634 005726              TST     (SP)+           ;CLEAN OFF THE STACK
7236 037636 000207              RTS     PC                ;RETURN TO USER
7237 037640 105761 034356      SC5:  TSTB    DPINT(R1)     ;INITIALIZING THE DRIVE ?
7238 037644 101402              BEQ     1$                ;BR IF NOT
7239 037646 000137 040544              JMP     SC13             ;PROCESS THE DRIVE
7240 037652 105761 034366      1$:  TSTB    DPRQS(R1)     ;PORT REQUEST OUTSTANDING ?
7241 037656 001402              BEQ     2$                ;BR IF NOT
7242 037660 000137 040544              JMP     SC13             ;START THE OUTSTANDING COMMAND
7243 037664 105761 034336      2$:  TSTB    DRVSTA(R1)    ;CHECK THE DRIVE STATUS
7244 037670 003025              BGT     5$                ;BRANCH IF ONLINE
7245 037672 105761 034404              TSTB    ULDFLG(R1)     ;UNLOAD IN PROGRESS?
7246 037676 003422              BLE     5$                ;BRANCH IF NOT
7247 037700 004737 042640              JSR      PC,GETREQ      ;GET DPB POINTER
7248 037704 004737 042004              JSR      PC,SVRH11      ;SAVE THE RH11/RPO4/5/6 REGISTERS
7249 037710 004737 040474              JSR      PC,SC12        ;SAVE RPOS1, RPER1, RPER2, AND RPER3
7250
7251 037714 105761 034336              TSTB    DRVSTA(R1)     ;ALSO DO A DRIVE INIT (DRVINT)
7252 037720 003416              BLE     6$                ;DID DRIVE COME ONLINE?
7253 037722 032737 040000 034316      6$:  BIT      #BIT14,RPERFS  ;NO---BRANCH
7254 037730 001002              BNE     3$                ;WAS THERE AN ERROR?
7255 037732 000137 040404              JMP     SC11             ;BR IF ERROR
7256 037736 013705 034320      3$:  MOV      RPERRS+2,R5    ;NO ERROR
7257 037742 000502              BR      SC6A             ;YES -- PICKUP RPER1 AND
7258 037744 105761 034326      5$:  TSTB    DRVACT(R1)     ;GO PROCESS THE ERROR
7259 037750 001033              BNE     SC6              ;DRIVE ACTIVE WITH COMMAND OR ERROR RECOVERY ?
                          ;BR IF EITHER
  
```

# H11

7260	037752	004737	040474			JSR	PC, SC12	;SAVE RPO51, RPER1, RPER2, AND RPER3
7261								;ALSO DO A DRVINT
7262	037756	105761	034356	6S:		TSTB	DPINT(R1)	;TRYING TO INIT THE DRIVE ?
7263	037762	001321				BNE	SC4	;BR IF YES, CHECK ON MORE DRIVES
7264	037764	105761	034336			TSTB	DRVSTA(R1)	;CHECK ON DRIVE'S STATUS
7265	037770	100412				BMI	7S	;BR IF UNSAFE
7266	037772	032737	020000	034324		BIT	#BIT13, RPER5+6	;ADDRESS PLUG CHANGED ?
7267	040000	001013				BNE	8S	;BR IF YES
7268	040002	012746	000113			MOV	#113, -(SP)	;RELEASE COMMAND
7269	040006	004037	041612			JSR	RD, WRT.RP	;WRITE THE COMMAND INTO RPCS!
7270	040012	000000				RPCS1		;REGISTER INDEX
7271	040014	040354				SCB		;PARITY EXIT ADDRESS
7272	040016	011605			7S:	MOV	(SP), RS	;PICKUP (RPAS) BE RE THE ERROR CALL
7273	040020	004037	042724			JSR	RD, ES.SAV	;SAVE THE ADDRESS IN 'SESCAPE'
7274	040024	104002				ERROR	2	;REPORT THE UNEXPECTED ATTENTION
7275	040026	000677				BR	SC4	;GO CHECK FOR MORE ATA'S
7276	040030				8S:			
7277	040030	004037	042724			JSR	RD, ES.SAV	;SAVE THE ADDRESS IN 'SESCAPE'
7278	040034	104005				ERROR	5	;REPORT THE ADDRESS PLUG CHANGE
7279	040036	000673				BR	SC4	;CHECK FOR MORE DRIVES
7280	040040	006301			SC6:	ASL	R1	;SETUP TO ADDRESS WORDS
7281	040042	012761	177777	034430		MOV	#-1, TIMER(R1)	;STOP THE TIMER
7282	040050	006201				ASR	R1	;RESTORE THE DRIVE ADDRESS
7283	040052	004737	042640			JSR	PC, GETREQ	;GET THE DPB POINTER FROM THE QUEUE
7284	040056	010164	000010			MOV	R1, RPCS2(R4)	;SELECT DRIVE
7285	040062	004037	041432			JSR	RD, RD.RP	;READ THE RPO4'S STATUS REG.
7286	040066	000012				RPO51		
7287	040070	040354				SCB		
7288	040072	011605				MOV	(SP), RS	;AND PUT IT IN RS
7289	040074	006126				ROL	(SP)↓	;WAS THERE AN ERROR?
7290	040076	100407				BMI	1S	;BR IF ERROR
7291	040100	105761	034326			TSTB	DRVACT(R1)	;CHECK DRIVE'S STATE
7292	040104	003137				BGT	SC11	;BR IF DRIVE ACTIVE WITH ORDER
7293	040106	052762	100210	000016		BIS	#BIT15!BIT07!BIT03, 16(R2)	;INFORM USER OF ERROR RECOVER COMPLETION
7294	040114	000470				BR	SC7	
7295	040116	004037	041432		1S:	JSR	RD, RD.RP	;READ ERROR REGISTER #1
7296	040122	000014				RPER1		
7297	040124	040354				SCB		
7298	040126	012605				MOV	(SP)+, RS	;AND SAVE IT IN RS
7299	040130	004737	042004			JSR	PC, SVRH11	;SAVE RH11/RPO4/5/6 REGISTERS
7300	040134	012746	000111			MOV	#111, -(SP)	;ISSUE A DRIVE CLEAR
7301	040140	004037	041612			JSR	RD, WRT.RP	
7302	040144	000000				RPCS1		
7303	040146	040354				SCB		
7304	040150	006105			SC6A:	ROL	RS	;WAS "UNSAFE" CONDITION =1?
7305	040152	100406				BMI	1S	;BRANCH IF YES
7306	040154	005702				TST	R2	;ANYTHING IN QUEUE ?
7307	040156	001447				BEQ	SC7	;BR IF NOT
7308	040160	052762	100240	000016		BIS	#BIT15!BIT07!BIT05, 16(R2)	;INFORM USER OF ERROR
7309	040166	000443				BR	SC7	
7310	040170	004037	041432		1S:	JSR	RD, RD.RP	;READ DRIVE STATUS REG. #1
7311	040174	000012				RPO51		
7312	040176	040354				SCB		
7313	040200	011605				MOV	(SP), RE	;SAVE RPO51 IN RS
7314	040202	006126				ROL	(SP)↓	;ERR=1?
7315	040204	100011				BPL	2S	;BR IF NO--UNSAFE CLEARED



```

7316 040206 112761 177777 034336      MOVB      # -1,DRVSTA(R1) ;DRIVE IS UNSAFE
7317 040214 004737 042004      JSR      PC,SVRH11 ;SAVE RH11/RPO4/5/6 REGISTERS
7318 040220 052762 110000 000016      BIS      #BIT15!BIT12,16(R2) ;INFORM USER OF UNSAFE ERROR
7319 040226 000423          BR      SC7
7320 040230 032705 010000      2$:      BIT      #BIT12,R5 ;"MOL" = 1 ?
7321 040234 001015          BNE     3$ ;BR IF YES
7322 040236 112761 177777 034326      MOVB     # -1,DRVACT(R1) ;ACTIVE ERROR RECOVER
7323 040244 112761 000001 034336      MOVB     #1,DRVSTA(R1) ;ONLINE
7324 040252 006301          ASL     R1
7325 040254 012761 072460 034430      MOV     #30000.,TIMER(R1) ;START 30 SECOND TIMER
7326 040262 006201          ASR     R1
7327 040264 000137 037626      JMP     SC4
7328 040270 052762 100220 000016      3$:      BIS      #BIT15!BIT07!BIT04,16(R2) ;INFORM USER OF ERROR
7329 040276 105061 034326      SC7:     CLR     DRVACT(R1) ;DRIVE IS IDLE
7330 040302 004737 042544      JSR     PC,EMPTYQ ;DUMP THE QUEUE
7331 040306 105761 034404      TST     ULDFLG(R1) ;UNLOAD IN PROGRESS OR QUEUE?
7332 040312 003002          BGT     1$ ;BR IF NOT
7333 040314 105061 034404      CLR     ULDFLG(R1) ;CLEAR UNLOAD FLAG
7334 040320 116164 034452 000016      1$:      MOVB     ATABIT(R1),RPAS(R4) ;CLEAR ATTENTION BIT
7335 040322 105761 034336      TST     DRVSTA(R1) ;IS THE DRIVE UNSAFE ?
7336 040324 100406          BMI     2$ ;BR IF IT IS
7337 040326 012746 000113      MOV     #113,-(SP) ;RELEASE COMMAND
7338 040328 004037 041612      JSR     RD,WRT.RP ;WRITE THE COMMAND INTO RPCS1
7339 040344 000000          RPS1   ;REGISTER INDEX
7340 040346 040354          SC8     ;PARITY EXIT ADDRESS
7341 040350 000137 037626      2$:      JMP     SC4 ;CHECK FOR MORE DRIVES
7342 040354 105761 034326      SC8:     TST     DRVACT(R1) ;IS DRIVE IDLE?
7343 040360 001405          BEQ     1$ ;YES--BRANCH
7344 040362 004737 042640      JSR     PC,GETREQ ;GET DPB POINTER
7345 040366 004737 036654      JSR     PC,C17 ;PROCESS THE PARITY ERROR
7346 040372 000402          BR     2$ ;CONTINUE
7347 040374 004737 036702      1$:      JSR     PC,C17B ;PROCESS THE UNCORRECTABLE PARITY ERROR
7348 040400 000137 037626      2$:      JMP     SC4 ;CHECK MORE DRIVES
7349 040404 105761 034404      SC11:    TST     ULDFLG(R1) ;"UNLOAD IN PROGRESS"?
7350 040410 003402          BLE     1$ ;BRANCH IF NO
7351 040412 105061 034404      CLR     ULDFLG(R1) ;CLEAR UNLOAD FLAG
7352 040416 105061 034326      1$:      CLR     DRVACT(R1) ;SET DRIVE IDLE
7353 040422 136137 034452 034400      BIT     ATABIT(R1),SRCHMT ;DOING A SEARCH OPERATION FOR
7354          ;AN I/O COMMAND?
7355 040430 001012          BNE     2$ ;BRANCH IF YES
7356 040432 004737 042662      JSR     PC,POPQUE ;REMOVE REQUEST FROM QUEUE
7357 040436 052762 000200 000016      BIS     #BIT07,16(R2) ;SET "DONE" BIT
7358 040444 005737 034424      TST     SAVEFG ;SAVE THE REGISTERS?
7359 040450 100002          BPL     2$ ;BRANCH IF NO
7360 040452 004737 042004      JSR     PC,SVRH11 ;YES--SAVE ALL OF THE RH11/RPO4/5/6 REG'S
7361 040456 116164 034452 000016      2$:      MOVB     ATABIT(R1),RPAS(R4) ;CLEAR ATTENTION BIT
7362 040464 004737 035544      JSR     PC,OPT ;START A REQUEST
7363 040470 000137 037526      JMP     SC4 ;CHECK FOR MORE DRIVES
7364 040474 010164 000010      SC12:    MOV     R1,RPCS2(R4) ;SELECT DRIVE
7365 040500 016437 000012 034316      MOV     RPOS1(R4),RPERRS ;SAVE THE FOUR REGISTERS THAT
7366 040506 016437 000014 034320      MOV     RPER1(R4),RPERRS+2 ;WILL TELL US SOMETHING
7367 040514 016437 000040 034322      MOV     RPER2(R4),RPERRS+4
7368 040522 016437 000042 034324      MOV     RPER3(R4),RPERRS+6
7369 040530 004037 034714      JSR     RD,DRVINT ;INIT. THE STATE OF THE DRIVE
7370 040534 000401          BR     1$ ;TAKE ERROR EXIT
7371 040536 000207          RTS     PC ;RETURN

```

```

7372 040540 005726          1$:   TST      (SP)+      ;POP PC OFF OF THE STACK
7373 040542 000704          BR       SC8         ;PROCESS THE PARITY ERROR
7374 040544 006301          SC13:  ASL      R1         ;SETUP TO ADDRESS WORDS
7375 040546 012761 177777 034430  MOV     #-1,TIMER(R1) ;STOP THE TIMER
7376 040554 006201          ASR      R1         ;
7377 040556 010164 000010  MOV     R1,RPCS2(R4) ;SELECT THE DRIVE
7378 040562 116164 034452 000016  MOVB   ATABIT(R1),RPAS(R4) ;CLEAR THE ATTENTION BIT
7379 040570 032714 004000  BIT     #BIT11,(R4)   ;DRIVE AVAILABLE ?
7380 040574 001006          BNE     1$         ;BR IF AVAILABLE
7381 040576 006301          ASL      R1         ;
7382 040600 012761 023420 034430  MOV     #10000.,TIMER(R1) ;START 10 SEC TIMER AGAIN
7383 040606 006201          ASR      R1         ;
7384 040610 000433          BR       3$         ;EXIT
7385 040612 105761 034356          1$:   TSTB   DPINT(R1)   ;INITIALIZING THE DRIVE ?
7386 040616 001424          BEQ     2$         ;BR IF NOT
7387 040620 105061 034356          CLRB   DPINT(R1)   ;CLEAR THE INIT INDICATOR
7388 040624 004037 034714          JSR    RD,DRVINT   ;GO INIT THE DRIVE
7389 040630 000240          NOP                    ;DUMMY PARITY ERROR RETURN
7390 040632 105761 034336          TSTB   DRVSTA(R1)  ;DRIVE ONLINE ?
7391 040636 003014          BGT     2$         ;BR IF YES -- START ORDER
7392 040640 005702          TST     R2         ;QUEUE ENTRY FOR THE DRIVE
7393 040642 001416          BEQ     3$         ;BR IF NOT
7394 040644 004737 042640          JSR    PC,GETREQ  ;GET DPB ADDRESS
7395 040650 052762 140000 000016  BIS    #BIT15:BIT14,16(R2) ;INFORM USER THAT DRIVE OFFLINE
7396 040656 004737 042004          JSR    PC,SVRH11  ;SAVE THE REGISTERS
7397 040662 004737 042544          JSR    PC,EMPTYQ  ;EMPTY THE REQUEST QUEUE
7398 040666 000404          BR       3$         ;
7399 040670 105061 034366          2$:   CLRB   DPRQS(R1) ;CLEAR THE PORT REQUEST INDICATOR
7400 040674 004737 035544          JSR    PC,OPT     ;START THE PENDING REQUEST
7401 040700 000137 037626          3$:   JMP     SC9         ;PROCESS OTHER DRIVES
7402
7403          ;RPO4/5/6 TIMER ROUTINE
7404          ;CALL
7405          ;
7406          ;   MOV     #TIME, -(SP) ;ELAPSED TIME IN MILLISECONDS ON THE STACK
7407          ;   JSR    PC,RPTMR  ;CALL RPO4/5/6 TIME ROUTINE
7408 040704 005737 034402          RPTMR: TST     ACTDRV   ;CHECK "ACTDRV & ACTSTR"
7409 040710 001030          BNE     4$         ;IF NON ZERO EXIT
7410 040712 112737 000001 034403  MOVB   #1,ACTSTR   ;SET "ACTSTR"
7411 040720 104412          SAVREG          ;SAVE R0 - R5
7412 040722 005001          CLR     R1         ;START WITH DRIVE 0
7413 040724 005003          CLR     R3         ;
7414 040726 005763 034430          1$:   TST     TIMER(R3) ;IS THE TIMER RUNNING?
7415 040732 002407          BLT     2$         ;BRANCH IF NO
7416 040734 166663 000002 034430  SUB     2(SP),TIMER(R3) ;COUNT THE INTERVAL
7417 040742 003003          BGT     2$         ;BR IF NO SOFTWARE TIMEOUT
7418 040744 004737 040776          JSR    PC,STO     ;CALL SOFTWARE TIMEOUT ROUTINE
7419 040750 000405          BR     3$         ;GO TO THE EXIT
7420 040752 005201          2$:   INC     R1         ;MOVE TO NEXT DRIVE
7421 040754 005723          TST     (R3)+      ;
7422 040756 022701 000010  CMP     #8.,R1     ;OUT OF DRIVES?
7423 040762 003361          BGT     1$         ;BRANCH IF NO
7424 040764 104413          3$:   RESREG          ;RESTORE R0 - R5
7425 040766 105037 034403          CLRB   ACTSTR     ;ZERO ACTIVE SOFTWARE TIMEOUT ROUTINE FLAG
7426 040772 012616          4$:   MOV     (SP)+,(SP) ;ADJUST THE STACK
7427 040774 000207          RTS     PC         ;RETURN
    
```

7428  
7429  
7430  
7431  
7432  
7433  
7434  
7435  
7436  
7437  
7438  
7439 040776 010146  
7440 041000 010346  
7441 041002 013704 034464  
7442 041006 010164 000010  
7443 041012 004037 041432  
7444 041016 000012  
7445 041020 041320  
7446 041022 105726  
7447 041024 100477  
7448 041026 105761 034356  
7449 041032 001074  
7450 041034 105761 034366  
7451 041040 001071  
7452 041042 013702 034376  
7453 041046 020137 034450  
7454 041052 001402  
7455 041054 004737 042640  
7456 041060 052762 100400 000016 15:  
7457 041066 004737 042004  
7458 041072 012764 000040 000010  
7459 041100 105061 034326  
7460 041104 105061 034404  
7461 041110 005001  
7462 041112 005003  
7463 041114 004037 034714  
7464 041120 000477  
7465 041122 105761 034326  
7466 041126 001414  
7467 041130 013702 034376  
7468 041134 023701 034450  
7469 041140 001402  
7470 041142 004737 042640  
7471 041146 052762 100400 000016 33:  
7472 041154 105061 034326  
7473 041160 105061 034404 45:  
7474 041164 012763 177777 034430  
7475 041172 005723  
7476 041174 005201  
7477 041176 022701 000010  
7478 041202 003344  
7479 041204 012737 177777 034450  
7480 041212 005037 034376  
7481 041216 004737 042466  
7482 041222 000500  
7483 041224 116405 000016

```
SOFTWARE TIMEOUT ROUTINE
NOTE: THIS ROUTINE MUST BE ENTERED AT PRIORITY 6
OR GREATER
CALL: STO
      MOV      #DRVNUM,R1      ;DRIVE NUMBER
      JSR      PC,STO          ;CALL
      RETURN
STO:  MOV      R1,-(SP)        ;SAVE R1
      MOV      R3,-(SP)        ;SAVE R3
      MOV      RPADR,R4        ;GET ADDRESS OF "RPCS1"
      MOV      R1,RPCS2(R4)    ;SELECT THE DRIVE
      JSR      RD,RD.RP        ;READ "DRIVE STATUS REG"
      RPD51
      STOS
      TSTB     (SP)+           ;IS "DRY"=1?
      BMI      ST02            ;BR IF YES
      ST01:   TSTB     DPINT(R1) ;TRYING TO INITIALIZE THE DRIVE ?
      BNE      ST02            ;BR IF YES
      TSTB     DRQS(R1)        ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
      BNE      ST02            ;BR IF YES
      MOV      TRNSWT,R2       ;PICKUP TRANSFER WAIT QUEUE
      CMP      R1,DTUW         ;TRANSFER UNDERWAY ON THIS DRIVE?
      BEQ      1$              ;BRANCH IF YES
      JSR      PC,GETREQ        ;GET DPB ADDRESS
      BIS      #BIT15:BIT09,16(R2) ;SET THE ERROR FLAGS
      JSR      PC,SVRH11        ;SAVE RH11/RPO4/5/6 REGISTERS
      MOV      #BIT05,RPCS2(R4) ;"INIT" THE MASS BUS
      CLRB     DRVACT(R1)       ;DRIVE IS IDLE
      CLRB     ULDFLG(R1)       ;CLEAR THE UNLOAD FLAG
      CLR      R1               ;START WITH DRIVE 0
      CLR      R3
      JSR      RD,DRVINT        ;INIT. THIS DRIVE
      BR       ST05            ;PARITY ERROR RETURN
      TSTB     DRVACT(R1)       ;DRIVE IDLE BEFORE THE INIT.?
      BEQ      4$              ;YES--BRANCH
      MOV      TRNSWT,R2       ;GET TRANSFER WAIT QUEUE
      CMP      DTUW,R1         ;WAS THERE I/O ON THIS DRIVE?
      BEQ      3$              ;YES--BRANCH
      JSR      PC,GETREQ        ;GET THE DPB POINTER FROM QUEUE
      BIS      #BIT15:BIT08,16(R2) ;INFORM USER OF INIT.
      CLRB     DRVACT(R1)       ;SET DRIVE ACTIVE TO IDLE
      CLRB     ULDFLG(R1)       ;NO UNLOAD
      MOV      #-1,TIMER(R3)    ;STOP THE TIMER
      TST      (R3)+           ;UPDATE THE INDEX
      INC      R1               ;INCREMENT THE DRIVE NUMBER
      CMP      #8.,R1          ;LAST DRIVE BEEN CHECKED?
      BGT      2$              ;NO--LOOP
      MOV      #-1,DTUW        ;NO DATA TRANSFERS UNDERWAY
      CLR      TRNSWT          ;CLEAR TRANSFER WAIT QUEUE
      JSR      PC,CLRQUE       ;CLEAR ALL REQUEST QUEUES
      BR       ST09            ;EXIT
      MOVB     RPA5(R4),R5      ;READ ATTENTION REG
```

```

7484 041230 136105 034452 BITB ATABIT(R1),R5 ;IS ATTENTION FOR THIS DRIVE UP ?
7485 041234 001017 BNE ST03 ;YES--BRANCH
7486 041236 105761 034356 TSTB DPINT(R1) ;TRYING TO INITIALIZE THE DRIVE ?
7487 041242 001031 BNE ST06 ;BR IF YES - DRIVE NOT ONLINE
7488 041244 105761 034366 TSTB DPRQS(R1) ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
7489 041250 001045 BNE ST07 ;BR IF YES - NO RESPONSE TO REQUEST
7490 041252 020137 034450 CMP R1,DTLW ;DATA TRANSFER UNDERWAY FOR THIS DRIVE
7491 041256 001263 BNE ST01 ;BR IF NC
7492 041260 004037 041432 JSR RD,RD.RP ;YES--CHECK "RDY"
7493 041264 000000 RPCS1
7494 041266 041320 STOS
7495 041270 105726 TSTB (SP)+
7496 041272 100255 BPL ST01 ;BR IF "RDY"=0
7497 041274 105761 034356 ST03: TSTB DPINT(R1) ;INITIALIZING THE DRIVE ?
7498 041300 001003 BNE IS ;BR IF INIT PENDING
7499 041302 105761 034366 TSTB DPRQS(R1) ;PORT REQUEST PENDING ?
7500 041305 001446 BEQ ST09 ;BR IF NOT
7501 041310 012763 177777 034430 IS: MOV #-1,TIMER(R3) ;STOP THE TIMER
7502 041316 000442 BR ST09 ;EXIT
7503 041320 004737 036754 ST05: JSR PC,CIB ;GO HANDLE THE PARITY ERROR
7504 041324 000437 BR ST09
7505 041326 105061 034356 ST06: CLRB DPINT(R1) ;CLEAR THE INITIALIZE INDICATOR
7506 041332 105061 034336 CLRB DRVSTA(R1) ;SET UNIT OFFLINE
7507 041336 012763 177777 034430 MOV #-1,TIMER(R3) ;STOP THE TIMER
7508 041344 004737 042640 JSR PC,GETREQ ;GET THE DPB ADDRESS
7509 041350 005702 TST R2 ;REQUEST IN QUEUE ?
7510 041352 001424 BEQ ST09 ;BR IF NOT
7511 041354 052762 140000 000016 BIS #BIT15:BIT14,16(R2) ;INFORM THE USER DRIVE NOT AVAILABLE
7512 041362 000414 BR ST08 ;FINISH
7513 041364 012763 177777 034430 ST07: MOV #-1,TIMER(R3) ;STOP THE TIMER
7514 041372 105061 034366 CLRB DPRQS(R1) ;CLEAR PORT REQUEST INDICATOR
7515 041376 004737 042640 JSR PC,GETREQ ;GET DPB ADDRESS
7516 041402 005702 TST R2 ;QUEUE ENTRY FOR DRIVE ?
7517 041404 001407 BEQ ST09 ;BR IF NONE
7518 041406 012762 100004 000016 MOV #BIT15:BIT2,16(R2) ;INFORM USER OF PORT REQUEST ERROR
7519 041414 004737 042544 ST08: JSR PC,EMPTYQ ;CLEAR THE QUEUE FOR THE DRIVE
7520 041420 004737 042004 JSR PC,SVRH11 ;SAVE THE REGISTERS
7521 041424 012603 ST09: MOV (SP)+,R3 ;RESTORE R3
7522 041426 012601 MOV (SP)+,R1 ;RESTORE R1
7523 041430 000207 RTS ;RETURN
7524
7525 ;ROUTINE TO READ A RH11/RP04/5/6 REGISTER
7526
7527 ;CALL
7528 JSR RD,RD.RP ;GO READ A REGISTER
7529 INDEX ;REG. INDEX FROM BASE
7530 ERRADR ;ERROR ADDRESS--PROCESS ERROR STARTING
7531 ;AT THIS ADDRESS
7532 ;CONTENTS OF REG. IS ON THE STACK
7533
7534 041432 013737 034462 041600 RD.RF: MOV MCPENX,RD.RP2 ;MAX. RETRYS ALLOWED
7535 041440 011646 MOV (SP)-,(SP) ;SAVE RD FOR RETURN
7536 041442 013737 034464 041456 MOV RPAOR,RD.ADR ;FORM THE DESIRED ADDRESS
7537 041450 062037 041456 ADD (RD)+,RD.ADR ;USING THE BASE AND THE INDEX
7538 041454 013727 RD.RP1: MOV @((PC)+),(PC)+ ;READ THE DESIRED REGISTER OF THE RPO4
7539 041456 000000 RD.ADR: .WORD 0 ;ADDRESS IS FORMED HERE
    
```

# M11

```

7540 041460 000000 RD.WRD: .WORD 0 ;REG. CONTENTS PUT HERE
7541 041462 013766 041460 000002 MOV RD.WRD,2(SP) ;RETURN IT TO THE USER
7542 041470 013746 034464 MOV RPADR,-(SP) ;PUT THE ADDRESS ON THE STACK
7543 041474 062716 000010 ADD #RPCS2,(SP) ;FORM THE ADDRESS OF RPCS2
7544 041500 032736 010000 BIT #BIT12,2(SP)+ ;CHECK THE 'MED' BIT
7545 041504 001037 BNE RD.RP3 ;BR IF DRIVE NON-EXISTENT
7546 041506 017746 172752 MOV #RPADR,-(SP) ;READ RPCS1
7547 041512 032716 020000 BIT #BIT13,(SP) ;DID MCPE SET?
7548 041516 001002 BNE IS ;BRANCH IF YES
7549 041520 022620 CMP ,(SP)+,(RD)+ ;ADJUST FOR RETURN
7550 041522 000432 BR RD.RP4 ;EXIT
7551 041524
7552 041524 004037 042724 IS: JSR RD,ES.SAV ;SAVE THE ADDRESS IN 'SESCAPE'
7553 041530 104003 ERROR 3 ;REPORT "MCPE" ERROR
7554 041532 005737 034450 TST DTLW ;DATA TRANSFER UNDERWAY?
7555 041536 100405 BMI 2S ;NO--BRANCH
7556 041540 032716 040000 BIT #BIT14,(SP) ;NO--"TRE"=1?
7557 041544 001402 BEQ 2S ;NO--BRANCH
7558 041546 005726 TST (SP)+ ;YES--CLEAN OFF THE STACK AND
7559 041550 000415 BR RD.RP3 ;TAKE THE FATAL ERROR EXIT
7560 041552 052716 040000 2S: BIS #BIT14,(SP) ;CLEAR "MCPE" BY SENDING A "1" TO "TRE"
7561 041556 000316 SWAB (SP) ;POSITION BEFORE WRITING
7562 041560 013737 034464 041574 MOV RPADR,3S ;FORM ADDRESS OF HIGH BYTE
7563 041566 005237 041574 INC 3S
7564 041572 112637 MOVB (SP)+,2(PC)+ ;WRITE THE HIGH BYTE OF RPCS1
7565 041574 000000 3S: .WORD 0 ;ADDRESS STORAGE
7566 041576 005327 DEC (PC)+ ;EXCEEDED MAX. RETRYS
7567 041600 000003 RD.RP2: .WORD 3
7568 041602 002324 BGE RD.RP1 ;BRANCH IF NO
7569 041604 011000 RD.RP3: MOV (RD),RD ;FATAL ERROR EXIT
7570 041606 012616 MOV (SP)+,(SP)
7571 041610 000200 RD.RP4: RTS RD
7572
7573 ;ROUTINE TO WRITE A REGISTER
7574 ;CALL
7575 ;CALL
7576 ;CALL
7577 ;CALL
7578 ;CALL
7579 ;CALL
7580 ;CALL
7581 ;CALL
7582 041612 013737 034462 041766 WRT.RP: MOV MCPEM,X,WRT.RE ;MAX RETRYS ALLOWED
7583 041620 016637 000002 041700 MOV 2(SP),WRT.WD ;SAVE THE WORD TO WRITE
7584 041626 012616 MOV (SP)+,(SP) ;ADJUST THE STACK
7585 041630 012037 041702 MOV (RD)+,WRT.AD ;GET INDEX OF REGISTER TO BE WRITTEN
7586 041634 001015 BNE IS ;BRANCH IF NOT RPCS1
7587 041636 122737 000150 041700 CMPB #150,WRT.WD ;IS THE COMMAND FOR DATA TRANSFERS?
7588 041644 002411 BLT IS ;YES--DON'T GET THE OLD A16 & A17, & PSEL
7589 041646 004037 041432 JSR RD,RD.RP ;NO---COMBINE A16&A17, & PSEL WITH
7590 041652 000000 RPCS1 ;THE COMMAND BEFORE SENDING IT TO
7591 041654 041774 WRT.R3 ;THE RH11/RPO4
7592 041656 000316 SWAB (SP)
7593 041660 042716 177770 BIC #1C7,(SP)
7594 041664 112637 041701 MOVB (SP)+,WRT.WD+1
7595 041670 063737 034464 041702 IS: ADD RPADR,WRT.AD ;FORM THE ADDRESS OF THE DISK REG.

```

# N11

```

7596 041676 012737      WRT.R1: MOV      (PC)+,2(PC)+      ;LOAD THE DESIRED REG.
7597 041700 000000      WRT.WD: .WORD    0                ;WORD TO WRITE GOES HERE
7598 041700 000000      WRT.AD: .WORD    0                ;ADDRESS IS FORMED HERE
7599 041704 713746 034464  MOV      RPADR, -(SP)           ;PUT THE ADDRESS ON THE STACK
7600 041710 062716 000010  ADD      #RPCS2, (SP)          ;FORM THE ADDRESS OF RPCS2
7601 041714 032736 010000  BIT      #BIT12, 2(SP)+        ;CHECK THE 'MED' BIT
7602 041720 001025          BNE      WRT.R3                ;BR IF DRIVE NON-EXISTENT
7603 041722 004037 041432  JSR      RO, RD.RP             ;CHECK FOR PARITY ERROR ON WRITE
7604 041726 000014          RPER1
7605 041730 041774          WRT.R3
7606 041732 032726 000010  BIT      #BIT03, (SP)+        ;
7607 041736 001420          BEQ      WRT.R4                ;BRANCH IF "PAR=0"
7608 041740 016037 177776 041752  MOV      -2(RO), 1$           ;PICKUP THE INDEX
7609 041745 004037 041432  JSR      RO, RD.RP             ;READ THE REG.
7610 041752 000000      1$: .WORD    0                ;REG. INDEX
7611 041754 041774          WRT.R3
7612 041756 004037 042724  JSR      RO, ES.SAV           ;RETURN TO THIS ADDRESS ON ERROR
7613 041762 104004          ERROR 4                    ;SAVE THE ADDRESS IN 'SESCAPE'
7614 041764 005327          DEC      (PC)+                ;REPORT THE PARITY ON WRITE ERROR
7615 041766 000003          WRT.R2: .WORD    3            ;DECREMENT THE ERROR COUNT
7616 041770 002342          BGE      WRT.R1                ;RETRY COUNTER
7617 041772 005726          TST      (SP)+                ;TRY AGAIN IF NOT FINISHED
7618 041774 011000          WRT.R3: MOV      (RO), RO        ;CLEAN OFF THE STACK
7619 041776 000401          SR      WRT.R5                ;TAKE THE "PARITY ON WRITE" ERROR EXIT
7620 042000 005720          WRT.R4: TST      (RO)+          ;EXIT
7621 042002 000200          WRT.R5: RTS      RC            ;ADJUST FOR ERROR FREE EXIT
7622
7623      ;ROUTINE TO SAVE THE RH11/RPO4/5/6 REGISTERS AS PER DPB+14
7624      ;CALL
7625
7626      MOV      #DPBNUM, R2        ;DPB POINTER TO R2
7627      JSR      PC, SVRH11        ;SAVE THE DRIVES REG'S
7628
7629 042004 104412      SVRH11: SAVREG                ;SAVE RO - R5
7630 042006 005702          TST      R2                    ;QUEUE ENTRY FOR THE DRIVE
7631 042010 001430          BEQ      4$                    ;BR IF NONE
7632 042012 013704 034464  MOV      RPAOR, R4              ;SELECT DRIVE
7633 042016 111264 000010  MOV      (R2), RPCS2(R4)        ;GET THE ERROR TABLE POINTER
7634 042022 016203 000014  MOV      14(R2), R3            ;
7635 042026 001433          BEQ      6$                    ;EXIT IF NO ADDRESS
7636 042030 005037 042064  CLR      3$                    ;COUNTER & POINTER
7637 042034 023727 042064 04222  1$: CMP      3$, #RPOB            ;REACHED THE BUFFER REGISTER
7638 042042 001006          BIT      2$                    ;BR IF NOT
7639 042044 032764 000200 000010  BIT      #BIT07, RPCS2(R4)      ;OR 'SET'
7640 042052 001002          BNE      2$                    ;BR IF SET
7641 042054 005023          CLR      (R3)+                ;STORE RPOB AS ZEROES
7642 042056 000405          BR      4$                    ;CONTINUE
7643 042060 004037 041432  2$: JSR      RO, RD.RP            ;READ THE SELECTED REGISTER
7644 042064 000000      3$: .WORD    0                ;REGISTER INDEX
7645 042066 042112          5$: MOV      (SP)+, (R3)+          ;ERROR RETURN ADDRESS
7646 042070 012623          MOV      (SP)+, (R3)+          ;STORE THE REGISTER CONTENTS
7647 042072 023727 042064 000046  4$: CMP      3$, #RPEC2          ;REACHED THE END
7648 042100 001406          BEQ      6$                    ;BR IF YES
7649 042102 062737 000002 042064  ROR      #2, 3$                ;INCREMENT THE REGISTER INDEX
7650 042110 000751          BR      1$                    ;CONTINUE READING THE REGISTERS
7651 042112 004737 036654      5$: JSR      PC, CI7            ;PROCESS THE UNCORRECTABLE PARITY ERROR

```

OIC

```

7652 042116 104413      6S:  RESREG      ;RESTORE R0 - R5
7653 042120 000207      RTS      PC      ;RETURN
7654
7655      ;ROUTINE TO SET THE INTERRUPT WITHOUT GETTING A "TRE"
7656      ;CALL
7657      ;
7658      ;
7659      ;
7659      ;
7660      ;
7661 042122 010446      SET.IE: MOV      R4, -(SP) ;SAVE R4
7662 042124 013704 034464      MOV      RPAOR, R4 ;PICKUP ADDRESS OF RPCS1
7663 042130 010164 000010      MOV      R1, RPCS2(R4) ;SELECT DRIVE
7664 042134 011446      MOV      (R4), -(SP) ;READ RPCS1
7665 042136 052716 040000      BIS      #BIT14, (SP) ;SET THE "TRE" BIT OF THE WORD READ
7666 042142 000316      SWAB      (SP) ;ADJUST FOR DATO
7667 042144 112714 000100      MOVB     #BIT06, (R4) ;SET "IE"
7668 042150 032764 010000 000010      BIT      #BIT12, RPCS2(R4) ;IS "MED"=1?
7669 042156 001002      BNE      IS ;YES--CLEAR "TRE"
7670 042160 005726      TST      (SP)+ ;CLEAN OFF THE STACK
7671 042162 000402      BR      2$
7672 042164 112664 000001      1$:  MOVB     (SP)+, 1(R4) ;CLEAR "TRE"
7673 042170 012604      2$:  MOV      (SP)+, R4 ;RESTORE R4
7674 042172 000207      RTS      PC      ;RETURN TO CALLER
7675
7676      ; QUEUE COUNT
7677 042174      000      QCNT: .BYTE 0 ;DRIVE 0
7678 042175      000      .BYTE 0 ;DRIVE 1
7679 042176      000      .BYTE 0 ;DRIVE 2
7680 042177      000      .BYTE 0 ;DRIVE 3
7681 042200      000      .BYTE 0 ;DRIVE 4
7682 042201      000      .BYTE 0 ;DRIVE 5
7683 042202      000      .BYTE 0 ;DRIVE 6
7684 042203      000      .BYTE 0 ;DRIVE 7
7685
7686      ; QUEUE INPUT POINTERS
7687
7688 042204 042266      QINPT: .WORD  QDRV0 ;DRIVE 0
7689 042206 042306      .WORD  QDRV1 ;DRIVE 1
7690 042210 042326      .WORD  QDRV2 ;DRIVE 2
7691 042212 042346      .WORD  QDRV3 ;DRIVE 3
7692 042214 042366      .WORD  QDRV4 ;DRIVE 4
7693 042216 042406      .WORD  QDRV5 ;DRIVE 5
7694 042220 042426      .WORD  QDRV6 ;DRIVE 6
7695 042222 042446      .WORD  QDRV7 ;DRIVE 7
7696
7697      ; QUEUE OUTPUT POINTERS
7698
7699 042224 042266      QOUTPT: .WORD  QDRV0 ;DRIVE 0
7700 042226 042306      .WORD  QDRV1 ;DRIVE 1
7701 042230 042326      .WORD  QDRV2 ;DRIVE 2
7702 042232 042346      .WORD  QDRV3 ;DRIVE 3
7703 042234 042366      .WORD  QDRV4 ;DRIVE 4
7704 042236 042406      .WORD  QDRV5 ;DRIVE 5
7705 042240 042426      .WORD  QDRV6 ;DRIVE 6
7706 042242 042446      .WORD  QDRV7 ;DRIVE 7
7707
    
```



```

7708 042244 042266 QSTART: .WORD QDRV0 ;DRIVE 0 START ADDRESS
7709 042246 042306 QSTOP: .WORD QURV1 ;DRIVE 0 STOP ADDRESS & DRIVE 1 START ADDRESS
7710 042250 042326 .WORD QDRV2 ;STOP DRIVE 1--START DRIVE 2
7711 042252 042346 .WORD QDRV3 ;STOP DRIVE 2--START DRIVE 3
7712 042254 042366 .WORD QDRV4 ;STOP DRIVE 3--START DRIVE 4
7713 042256 042406 .WORD QDRV5 ;STOP DRIVE 4--START DRIVE 5
7714 042260 042426 .WORD QDRV6 ;STOP DRIVE 5--START DRIVE 6
7715 042262 042446 .WORD QDRV7 ;STOP DRIVE 6--START DRIVE 7
7716 042264 042466 .WORD QTERM ;STOP DRIVE 7

```

;DRIVE REQUEST QUEUES

```

7720 042266 000010 QDRV0: .BLKW 10
7721 042268 000010 QDRV1: .BLKW 10
7722 042270 000010 QDRV2: .BLKW 10
7723 042272 000010 QDRV3: .BLKW 10
7724 042274 000010 QDRV4: .BLKW 10
7725 042276 000010 QDRV5: .BLKW 10
7726 042278 000010 QDRV6: .BLKW 10
7727 042280 000010 QDRV7: .BLKW 10
7728 042466 QTERM=.

```

;ROUTINE TO CLEAR ALL OF THE REQUEST QUEUES

```

7730 ;CALL
7731 ;
7732 ; JSR PC,CLRQUE
7733 ;
7734 CLRQUE: SAVREG ;SAVE R0 - R5
7735 042466 104412 MOV #0CNT,R2 ;ZERO THE QUEUE COUNTS
7736 042470 012702 042174 CLR (R2)+ ;DRIVES 0 & 1
7737 042474 005022 CLR (R2)+ ;DRIVES 2 & 3
7738 042476 005022 CLR (R2)+ ;DRIVES 4 & 5
7739 042500 005022 CLR (R2)+ ;DRIVES 6 & 7
7740 042502 005022 MOV #8,R3 ;MOVE THE STARTING
7741 042504 012703 000010 MOV #QSTART,R1 ;ADDRESS OF THE QUEUE INTO
7742 042510 012701 042244 18: MOV (R1)+,(R2)+ ;THE QUEUE INPUT POINTER
7743 042514 012122 DEC R3
7744 042516 005303 BNE 18
7745 042520 001375 MOV #8,R3 ;MOVE THE STARTING ADDRESS
7746 042522 012703 000010 MOV #QSTART,R1 ;OF THE QUEUE INTO THE
7747 042526 012701 042244 28: MOV (R1)+,(R2)+ ;QUEUE OUTPUT POINTER
7748 042532 012122 DEC R3
7749 042534 005303 BNE 28
7750 042536 001375 RESREG ;RESTORE R0 - R5
7751 042540 104413 RTS PC
7752 042542 000207

```

;EMPTY THE QUEUE SPECIFIED BY R1

```

7754 ;CALL
7755 ;
7756 ; MOV DRVNUM,R1 ;DRIVE NUMBER TO R1
7757 ; JSR PC,EMPTYQ
7758 ;
7759 ;
7760 042544 105061 042174 EMPTYQ: CLR# QCNT(R1) ;CLEAR NUMBER OF ITEMS IN QUEUE
7761 042550 006301 ASL R1
7762 042552 016161 042204 042224 MOV @INPT(R1),@OUTPT(R1) ;SET OUTPUT QUEUE POINTER=INPUT POINTER
7763 042560 006201 ASR R1

```

```

7764 042562 000207          RTS      PC
7765
7766          ;ROUTINE TO PUT A REQUEST IN QUEUE
7767          ;CALL
7768          ;CALL
7769          ;CALL
7770          ;CALL
7771          ;CALL
7772          ;CALL
7773          ;CALL
7774          ;CALL
7775 042564 122761 000010 042174 DRVQUE:  CMPB    #DRVNUM,R1      ;DRIVE NUMBER
7776 042572 001421          DECB    #DPB,R2      ;ADDRESS OF PARAMETER BLOCK
7777 042574 105261 042174          INCB    QCNT(R1)    ;GO PUT REQUEST IN QUEUE
7778 042600 006301          ASL    R1           ;RETURN HERE IF QUEUE IS FULL
7779 042602 010271 042204          MOV    R2,#QINPT(R1) ;RETURN HERE IF REQUEST IS IN QUEUE
7780 042606 062761 000002 042204          ADD    #2,QINPT(R1) ;IS QUEUE FULL?
7781 042614 026161 042204 042246          CMP    QINPT(R1),QSTOP(R1) ;BR IF YES-TAKE RETURN1
7782 042622 001003          BNE    IS          ;INCREMENT QUEUE COUNT
7783 042624 016161 042244 042204          MOV    QSTART(R1),QINPT(R1) ;PUT THIS REQUEST IN QUEUE
7784 042632 006201          ASR    R1           ;UPDATE THE QUEUE POINTER
7785 042634 005720          TST   (R0)+        ;TIME TO RESET THE POINTER
7786 042636 000200          RTS    R0         ;BRANCH IF NO
7787          ;
7788          ;
7789          ;
7790          ;
7791          ;
7792          ;
7793          ;
7794          ;
7795          ;
7796 042640 005002          GETREQ: CLR    R2           ;YES--RESET POINTER
7797 042642 105761 042174          TSTB   QCNT(R1)    ;TAKE RETURN 2
7798 042646 001404          ASR    R1           ;RETURN TO USER
7799 042650 006301          ASL    R1           ;
7800 042652 017102 042224          MOV    #QOUTPT(R1),R2 ;ROUTINE TO GET THE "DPB" ADDRESS OF NEXT REQUEST IN QUEUE
7801 042656 006201          ASR    R1           ;CALL
7802 042660 000207          RTS    PC         ;DRIVE NUMBER TO R1
7803          ;
7804          ;
7805          ;
7806          ;
7807          ;
7808          ;
7809          ;
7810          ;
7811 042662 105361 042174          POPQUE: DECB   QCNT(R1) ;GO GET THE REQUEST
7812 042666 006301          ASL    R1           ;R2="DPB" ADDRESS OF THE REQUEST
7813 042670 017102 042224          MOV    #QOUTPT(R1),R2 ;R2=0 IF NO REQUEST IN QUEUE
7814 042674 062761 000002 042224          ADD    #2,QOUTPT(R1) ;IS THERE ANY REQUEST IN QUEUE?
7815 042702 026161 042224 042246          CMP    QOUTPT(R1),QSTOP(R1) ;NO---BRANCH
7816 042710 001003          BNE    IS          ;PI UP "DPB" POINTER FOR THIS DRIVE
7817 042712 016161 042244 042224          MOV    QSTART(R1),QOUTPT(R1) ;RETURN TO USER
7818 042720 006201          ASR    R1           ;
7819 042722 000207          RTS    PC         ;
    
```

```

7820
7821
7822
7823
7824
7825
7826
7827
7828
7829 042724 012037 042740
7830 042730 013746 001206
7831 042734 005037 001206
7832 042737 000000
7833 042742 012037 001206
7834 042746 000000
7835
7836
7837
7838
7839
7840 042750 000122
7841 042752 041506 000
7842 042755 114 000103
7843 042760 041506 000047
7844 042764 041514 000047
7845 042770 041511 000
7846 042773 106 000124
7847 042776 052114 000
7848 043001 111 000124
7849 043004 051506 000
7850 043007 114 000123
7851 043012 040520 000124
7852 043016 000075
7853 043020 005015 047503 052116
7854 043026 047522 020114 053523
7855 043034 052111 044103 051505
7856
7857 043044 027440 000040
7858 043050 047125 052111 051440
7859 043056 040524 052524 035123
7860 043064 005015 000012
7861 043070 051104 053111 000105
7862 043076 047140 043106 044514
7863 043104 042516 000
7864 043107 040 047117 044514
7865 043114 042516 000
7866 043117 040 047516 020124
7867 043124 051120 051575 047105
7868 043132 000124
7869 043134 052440 051516 043101
7870 043142 000105
7871 043144 047040 052117 051040
7872 043152 030120 027464 027465
7873 043160 000066
7874 043162 050122 032060 000
7875 043167 122 030120 000065
    
```

```

: ROUTINE TO SAVE THE CONTENTS OF 'SESCAPE' WHEN THE DRIVER
: REPORTS AN ERROR DIRECTLY.
: CALL
:       JSR      RD,ES.SAV
:       ERROR   N
:       RETURN
: THE ERROR CALL
: THE RETURN IS PAST THE ERROR CALL
ES.SAV: MOV      (RD)+,IS
: GET THE ERROR CALL
: SAVE THE ADDRESS IN 'SESCAPE'
MOV      SESCOPE,-(SP)
: CLEAR THE ESCAPE RETURN
CLR      SESCOPE
: THE ERROR CALL IS MOVED HERE
IS:      .WORD   0
: RESTORE THE ESCAPE ADDRESS
MOV      (SP)+,SESCAPE
: RETURN
RTS      RD
    
```

.SBTTL ASCIZ MESSAGES

```

MSG.R:  .ASCIZ  /R/
MSG.FC:  .ASCIZ  /FC/
MSG.LC:  .ASCIZ  /LC/
MSG.FC:  .ASCIZ  /FC'/
MSG.LC:  .ASCIZ  /LC'/
MSG.IC:  .ASCIZ  /IC/
MSG.FT:  .ASCIZ  /FT/
MSG.LT:  .ASCIZ  /LT/
MSG.IT:  .ASCIZ  /IT/
MSG.FS:  .ASCIZ  /FS/
MSG.LS:  .ASCIZ  /LS/
MSG.PAT: .ASCIZ  /PAT/
MSG.EQ:  .ASCIZ  /=/
MSG.CS:  .ASCIZ  <CR><LF>/CONTROL SWITCHES=/
SLASH:  .ASCIZ  @ / @
SYSTAT: .ASCIZ  /UNIT STATUS:/(CR)<LF><LF>
UNMSG:  .ASCIZ  /DRIVE/
UNTOFF: .ASCIZ  / OFFLINE/
UNTON:  .ASCIZ  / ONLINE/
NOTPRS: .ASCIZ  / NOT PRESENT/
NUISAF: .ASCIZ  / UNSAFE/
NOT'P:  .ASCIZ  @ NOT RPO4/5/6@
RPO4B:  .ASCIZ  /RPO4/
RPO5:   .ASCIZ  /RPO5/
    
```

7876	043174	050122	033060	000	RPO6: .ASCIZ /RPO6/
7877	043170	015	042012	044522	DRIVES: .ASCIZ <CR><LF>/DRIVE(S) TO BE TESTED /
7878	043106	042526	051450	020051	
7879	043214	047514	041040	020105	
7880	043132	042524	052123	042105	
7881	043130	000040			
7882	043133	047516	042516	000	NONE: .ASCIZ /NONE/
7883	043237	054	000		COMMA: .ASCIZ / /
7884	043241	015	047012	020117	NOCLOCK: .ASCIZ <CR><LF>/NO KMI-P CLOCK, TIMING TESTS WILL NOT BE PERFORMED/
7885	043146	053513	030461	050055	
7886	043254	041440	047514	045503	
7887	043262	020054	044524	044515	
7888	043270	043516	052040	051505	
7889	043276	051524	053440	046111	
7890	047304	020114	047516	020124	
7891	043312	042502	050040	051105	
7892	043320	047506	046522	042105	
7893	043326	000			
7894	043327	015	005012	042524	TESTING: .ASCIZ <CR><LF><LF>/TESTING DRIVE /
7895	043334	052123	047111	020107	
7896	043342	051104	053111	020105	
7897	043350	000			
7898	043351	123	051105	040511	SERIAL: .ASCIZ /SERIAL NUMBER /
7899	043356	020114	052516	041115	
7900	043364	051105	000040		
7901					
7902	043370	005015	051012	052117	MSG7: .ASCIZ <CR><LF><LF>/ROTATIONAL SPEED TIMES/
7903	042376	052101	047511	040516	
7904	043404	020114	050123	042105	
7905	043412	020104	044524	042515	
7906	043420	000123			
7907	043422	005015	047412	042516	MSG10A: .ASCIZ <CR><LF><LF>/ONE CYLINDER SEEK TIMES/<CR><LF>/ * FORWARD/
7908	043430	041440	046131	047111	
7909	043436	042504	020122	047523	
7910	043444	045505	052040	047511	
7911	043452	051505	005015	023040	
7912	043460	043040	051117	043527	
7913	043466	042122	000		
7914	043471	015	020012	020052	MSG10B: .ASCIZ <CR><LF>/ * REVERSE/
7915	043476	042522	042526	051522	
7916	043504	000105			
7917	043506	005015	040412	041503	MSG11A: .ASCIZ <CR><LF><LF>/ACCESS TIME MEASUREMENT/<CR><LF>/ * FORWARD/
7918	043514	051505	020123	044524	
7919	043522	042515	046440	040505	
7920	043530	052523	046522	047105	
7921	043536	006524	020012	040052	
7922	043544	047506	053522	051101	
7923	043552	000104			
7924	043554	005015	025040	051040	MSG11B: .ASCIZ <CR><LF>/ * REVERSE/
7925	043562	053105	051105	042523	
7926	043570	000			
7927	043571	015	005012	040515	MSG12A: .ASCIZ <CR><LF><LF>/MAXIMUM SEEK TIMES/<CR><LF>/ * FORWARD/
7928	043576	044530	052515	020115	
7929	043604	042523	045505	053040	
7930	043612	046511	051505	005015	
7931	043620	025040	043040	051117	

7932	043626	040527	042122	000	
7933	043633	015	020012	020052	MSG128: .ASCIZ <CR><LF>/ * REVERSE/
7934	043640	042522	042526	051522	
7935	043646	000105			
7936					
7937	043650	005015	044515	036516	MSGMIN: .ASCIZ <CR><LF>/MIN=/ MSGMAX: .ASCIZ <CR><LF>/MAX=/ MSGAVG: .ASCIZ <CR><LF>/AVG=/ MSGOUS: .ASCIZ /0 US/ MBELOW: .ASCIZ / BELOW THE MINIMUM OF / MABOVE: .ASCIZ / ABOVE THE MAXIMUM OF /
7938	043656	000			
7939	043657	015	046412	054101	
7940	043664	000075			
7941	043666	005015	053101	036507	
7942	043674	000			
7943	043675	050	052440	000123	
7944	043702	041040	046105	053517	
7945	043710	057110	042510	046440	
7946	043716	047111	046511	046525	
7947	043724	047150	020106	000	
7948	043731	040	041101	053117	
7949	043736	020105	044124	020105	
7950	043744	040515	044530	052515	
7951	043752	020115	043117	000040	
7952	043760	051440	042505	051513	MSGNUM: .ASCIZ / SEEKS TIMED/
7953	043766	052040	046511	042105	
7954	043774	000			
7955	043775	040	047516	020124	MSGNON: .ASCIZ / NOT TIMED/
7956	044002	044524	042515	000104	
7957	044010	020040	000		MSG.SP: .ASCIZ / / ;TWO (2) SPACES
7958					
7959					.SBTTL ERROR HEADER (EM) MESSAGES
7960					
7961	044013	122	030510	020061	EM1: .ASCIZ /RH11 INTERRUPT OCCURRED (RPAS = 0)/
7962	044020	047111	042524	051122	
7963	044026	050125	020124	041517	
7964	044034	052503	051122	042105	
7965	044042	024040	050122	051501	
7966	044050	036440	030040	000051	
7967	044056	047125	054105	042520	EM2: .ASCIZ /UNEXPECTED ATTENTION OCCURRED/
7968	044064	052103	042105	040440	
7969	044072	052124	047105	044524	
7970	044100	047117	047440	041503	
7971	044106	051125	042522	000104	
7972	044114	040515	051523	052502	EM3: .ASCIZ /MSSBUS PARITY ERROR(MCPE=1)/
7973	044122	020123	040520	044522	
7974	044130	054524	042440	051122	
7975	044136	051117	046450	050103	
7976	044144	036505	024461	000	
7977	044151	115	051501	041123	EM4: .ASCIZ /MSSBUS PARITY ERROR(PAR=1)/
7978	044156	051525	050040	051101	
7979	044164	052111	020131	051105	
7980	044172	047522	024122	040520	
7981	044200	036522	024461	000	
7982	044205	101	042104	042522	EM5: .ASCIZ /ADDRESS PLUG CHANGE BIT SET/
7983	044212	051523	050040	052514	
7984	044220	020107	044103	047101	
7985	044226	042507	041040	052111	
7986	044234	051440	052105	000	
7987	044241	122	030510	027461	EM10: .ASCIZ "RH11/RP04/5/6 FAILED TO RESPOND TO ADDRESSING"

7988	044246	050122	032060	032457	
7989	044254	033057	043040	044501	
7990	044262	042514	020104	047524	
7991	044270	051040	051505	047520	
7992	044276	042116	052040	020117	
7993	044304	042101	051104	051505	
7994	044312	044523	043516	000	
7995	044317	104	044522	042526	EM11: .ASCIZ /DRIVE SELECTED IS NOT ONLINE/
7996	044324	051440	046105	041505	
7997	044332	042524	020104	051511	
7998	044340	047040	052117	047440	
7999	044346	046116	047111	000105	
8000	044354	046511	051120	050117	EM12: .ASCIZ /IMPROPER HEADER DATA/
8001	044352	051105	044040	040505	
8002	044370	042504	020122	040504	
8003	044376	040524	000		
8004	044401	104	052101	020101	EM13: .ASCIZ /DATA COMPARE FAILURE/
8005	044406	047503	050115	051101	
8006	044414	020105	040506	046111	
8007	044422	051123	000105		
8008	044426	044504	045523	042440	EM17: .ASCIZ /DISK ERROR IN TIMING TEST/
8009	044434	051122	051117	044440	
8010	044442	020116	044524	044515	
8011	044450	043516	052040	051505	
8012	044456	000124			
8013	044460	046103	041517	020113	EM20: .ASCIZ /CLOCK (KW11-P) OVERFLOW IN TIMING TEST/
8014	044466	045450	030527	020461	
8015	044474	024520	047440	042526	
8016	044502	043122	047514	020127	
8017	044510	047111	052040	046511	
8018	044516	047111	020107	042524	
8019	044524	052123	000		
8020	044527	104	051511	020113	EM23: .ASCIZ /DISK ERROR DURING SEEK/
8021	044534	051105	047522	020122	
8022	044542	052504	044522	043516	
8023	044550	051440	042505	000113	
8024	044556	042523	045505	047040	EM24: .ASCIZ /SEEK NOT COMPLETE WITHIN 120 MS/
8025	044564	052117	041440	046517	
8026	044572	046120	052105	020105	
8027	044580	044527	044124	047111	
8028	044586	030440	030062	046440	
8029	044614	000123			
8030	044616	044122	030461	051057	EM41: .ASCIZ "RH11/RPO4/5/6 ERROR"
8031	044624	030120	027464	027465	
8032	044632	020066	051105	047522	
8033	044640	000122			
8034	044642	040506	040524	020114	EM46: .ASCIZ /FATAL WRITE CHECK ERROR/
8035	044650	051127	052111	020105	
8036	044656	044103	041505	020113	
8037	044664	051105	047522	000122	
8038					
8039					.SBTTL STATUS/ERROR INDICATOR MESSAGES
8040					
8041	044672	043117	046106	047111	MSG814: .ASCIZ /OFFLINE OR UNSAFE DRIVE REQUESTED/
8042	044700	020105	051117	052440	
8043	044706	051516	043101	020105	

8044	044714	051104	053111	020105	
8045	044722	042522	052521	051505	
8046	044730	042524	000104		
8047	044734	047125	047514	042101	MSG813: .ASCIZ /UNLOADED DRIVE REQUESTED/
8048	044742	042105	042040	044522	
8049	044750	042523	051040	050505	
8050	044756	042525	052123	042105	
8051	044764	000			
8052	044765	120	051105	044523	MSG812: .ASCIZ /PERSISTENT UNSAFE/
8053	044772	052123	047105	020124	
8054	045000	047125	040523	042506	
8055	045006	000			
8056	045007	120	051101	052111	MSG811: .ASCIZ /PARITY ERROR OCCURRED/
8057	045011	020131	051105	047522	
8058	04501	020122	041517	052503	
8059	045031	051122	042105	000	
8060	045035	106	052101	046101	MSG810: .ASCIZ /FATAL PARITY ERROR/
8061	045042	050040	051101	052111	
8062	045050	020131	051105	047522	
8063	045056	000122			
8064	045060	047523	052106	040527	MSG809: .ASCIZ /SOFTWARE TIMEOUT ON THIS DRIVE/
8065	045066	042522	052040	046511	
8066	045074	047505	052125	047440	
8067	045102	020116	044124	051511	
8068	045110	042040	044522	042526	
8069	045116	000			
8070	045117	123	043117	053524	MSG808: .ASCIZ /SOFTWARE TIMEOUT ON ANOTHER DRIVE/
8071	045124	051101	020105	044524	
8072	045132	042515	052517	020124	
8073	045140	047117	040440	047516	
8074	045146	044124	051105	042040	
8075	045154	044522	042526	000	
8076	045161	105	051122	051117	MSG806: .ASCIZ "ERROR OCCURRED DURING I/O OPERATION"
8077	045166	047440	041503	051125	
8078	045174	042522	020104	052504	
8079	045202	044522	043516	044440	
8080	045210	047457	047440	042520	
8081	045216	040522	044524	047117	
8082	045224	000			
8083	045225	105	051122	051117	MSG805: .ASCIZ "ERROR OCCURRED DURING NON-I/O OPERATION"
8084	045232	047440	041503	051125	
8085	045240	042522	020104	052504	
8086	045246	044522	043516	047040	
8087	045254	047117	044455	047457	
8088	045262	047440	042520	040522	
8089	045270	044524	047117	000	
8090	045275	125	051516	043101	MSG804: .ASCIZ /UNSAFE OCCURRED/
8091	045302	020105	041517	052503	
8092	045310	051122	042105	000	
8093	045315	101	052125	046517	MSG803: .ASCIZ /AUTOMATIC RECALIBRATE SEQUENCE OCCURRED/
8094	045322	052101	041511	051040	
8095	045330	041505	046101	041111	
8096	045336	040522	042524	051440	
8097	045344	050505	042525	041516	
8098	045352	020105	041517	052503	
8099	045360	051122	042105	000	



8100	045365	104	044522	042526
8101	045372	044040	051501	047040
8102	045400	052117	051040	051505
8103	045406	047520	042116	042105
8104	045414	052040	020117	047520
8105	045422	052122	051040	050505
8106	045430	042525	052123	000
8107	045435	104	044522	042526
8108	045442	044040	051501	041040
8109	045450	041505	046517	020105
8110	045456	047516	026516	054105
8111	045464	051511	042524	052116
8112	045472	000		
8113				
8114				
8115				
8116	045473	105	051122	050040
8117	045500	020103	051040	040520
8118	045506	000123		
8119	045510	051105	020122	041520
8120	045516	020040	051104	053111
8121	045524	020105	020040	050122
8122	045532	051501	020040	020040
8123	045540	050122	051504	020061
8124	045546	020040	050122	051105
8125	045554	020061	020040	050122
8126	045562	051105	020062	020040
8127	045570	050122	051105	000063
8128	045576	042524	052123	020040
8129	045604	020040	051105	020122
8130	045612	041520	020040	042101
8131	045620	051104	051505	020123
8132	045626	040504	040524	000
8133	045633	124	051505	020124
8134	045640	020040	042440	051122
8135	045646	050040	020103	040440
8136	045654	042104	042522	051523
8137	045662	043440	042104	052101
8138	045670	020101	041040	042104
8139	045676	052101	000101	
8140	045702	050122	051503	020061
8141	045710	020040	051105	020122
8142	045716	041520	000	
8143	045721	104	044522	042526
8144	045726	020040	042440	051122
8145	045734	050040	000103	
8146	045740	042524	052123	020040
8147	045746	020040	051105	020122
8148	045754	041520	020040	051524
8149	045762	020124	041520	020040
8150	045770	051104	053111	020105
8151	045776	020040	054503	047114
8152	046004	051104	020040	051124
8153	046012	041501	020113	020040
8154	046020	042523	052103	051117
8155	046026	000		

MSG802: .ASCIZ /DRIVE HAS NOT RESPONDED TO PORT REQUEST/

MSG801: .ASCIZ /DRIVE HAS BECOME NON-EXISTENT/

.SBTTL DATA HEADER (DT) MESSAGES

DH1: .ASCIZ /ERR PC RPAS/

DH2: .ASCIZ /ERR PC DRIVE RPAS RPOS1 RPER1 RPER2 RPER3/

DH3: .ASCIZ /TEST ERR PC ADDRESS DATA/

DH4: .ASCIZ /TEST ERR PC ADDRESS GDDATA BDDATA/

DH10: .ASCIZ /RPCS1 ERR PC/

DH11: .ASCIZ /DRIVE ERR PC/

DH12: .ASCIZ /TEST ERR PC TST PC DRIVE CYLNR TRACK SECTOR/



8212	046520	000103											
8213	046522	042524	052123	020040	DH41:	.ASCIZ	/TEST	ERR PC	TST PC	DRIVE/			
8214	046530	020040	051105	020122									
8215	046536	041520	020040	051524									
8216	046544	020124	041520	020040									
8217	046552	051104	053111	000105									
8218	046560	042524	052123	020040	DH42:	.ASCIZ	/TEST	ERR PC	TST PC	DRIVE	RPCS1	RPCS2	RPDS1/
8219	046566	020040	051105	020122									
8220	046574	041520	020040	051524									
8221	046602	020124	041520	020040									
8222	046610	051104	053111	020105									
8223	046616	020040	050122	051503									
8224	046624	020061	020040	050122									
8225	046632	051503	020062	020040									
8226	046640	050122	051504	000061									
8227	046646	050122	051105	020061	DH43A:	.ASCIZ	/RPER1	RPER2	RPER3/				
8228	046654	020040	050122	051105									
8229	046662	020062	020040	050122									
8230	046670	051105	000063										
8231	046674	050122	051503	020061	DH44A:	.ASCIZ	/RPCS1	RPCS2	RPDS1	RPCC	RPCA	RPDA/	
8232	046702	020040	050122	051503									
8233	046710	020062	020040	050122									
8234	046716	051504	020061	020040									
8235	046724	050122	041503	020040									
8236	046732	020040	050122	040503									
8237	046740	020040	020040	050122									
8238	046746	040504	000										
8239	046751	122	042520	030522	DH44B:	.ASCIZ	/RPER1	RPER2	RPER3/				
8240	046756	020040	051040	042520									
8241	046764	031122	020040	051040									
8242	046772	042520	031522	000									
8243	046777	122	042520	030522	DH45A:	.ASCIZ	/RPER1	RPER2	RPER3	RPWC	RPBA	RPDB/	
8244	047004	020040	051040	042520									
8245	047012	031122	020040	051040									
8246	047020	042520	031522	020040									
8247	047026	051040	053520	020103									
8248	047034	020040	051040	041120									
8249	047042	020101	020040	051040									
8250	047050	042120	000102										
8251													
8252													
8253													
8254													
8255													
8256													
8257	047054	001116	001170		DT1:	.WORD	SERRPC, \$REG3						
8258	047060	001116	001164	001170	DT2:	.WORD	SERRPC, \$REG1, \$REG3, RPERRS, RPERRS+2, RPERRS+4, RPERRS+6						
8259	047066	034316	034320	034322									
8260	047074	034324											
8261	047076	001176	001116	041456	DT3:	.WORD	STMP0, SERRPC, RD.ADR, RD.WRD						
8262	047104	041460											
8263	047106	001176	001116	041702	DT4:	.WORD	STMPC, SERRPC, WRT.ADR, WRT.WD, RD.WRD						
8264	047114	041700	041460										
8265	047120	001176	001116	001164	DT5:	.WORD	STMP0, SERRPC, \$REG1, \$REG5, RPERRS, RPERRS+2, RPERRS+4, RPERRS+6						
8266	047126	001174	034316	034320									
8267	047134	034322	034324										

.EVEN

.SBTTL DATA TABLE (DT)

8268	047140	001366	001116		DT10:	.WORD	RM.ADR, SERRPC
8269	047144	001166	001116		DT11:	.WORD	SREG2, SERRPC
8270	047150	001176	001116	001162	DT12:	.WORD	STMPD, SERRPC, SREGD, CHKDRV, CYL.DS, TRK.DS, SEC.DS
8271	047156	001254	001270	001274			
8272	047164	001272					
8273	047166	001270	001274	001272	DT12A:	.WORD	CYL.DS, TRK.DS, SEC.DS, CYL.RD, TRK.RD, SEC.RD
8274	047174	001262	001264	001266			
8275	047202	001176	001116	001162	DT13:	.WORD	STMPD, SERRPC, SREGD, CHKDRV, CYL.DS, TRK.DS, SEC.DS
8276	047210	001254	001270	001274			
8277	047216	001272					
8278	047220	001124	001126	001172	DT13A:	.WORD	SGDDAT, SBDDAT, SREG4, SGDAOR, SBDAOR
8279	047226	001120	001122				
8280	047232	001176	001116	001254	DT17:	.WORD	STMPD, SERRPC, CHKDRV, RP.REG, RP.REG+12, RP.REG+14, RP.REG+40, RP.REG+42
8281	047240	004204	004216	004220			
8282	047246	004244	004246				
8283	047252	001176	001116	001162	DT21:	.WORD	STMPD, SERRPC, SREGD, CHKDRV, CYL.DS, TRK.DS
8284	047260	001254	001270	001274			
8285	047266	001164	001126	001172	DT21A:	.WORD	SREG1, SBDDAT, SREG4, SREG1
8286	047274	001164					
8287	047276	001176	001116	001254	DT23:	.WORD	STMPD, SERRPC, CHKDRV, CYL.DS, RP.REG, RP.REG+10, RP.REG+12
8288	047304	001270	004204	004214			
8289	047312	004216					
8290	047314	004220	004244	004246	DT23A:	.WORD	RP.REG+14, RP.REG+40, RP.REG+42, RP.REG+34, RP.REG 36
8291	047322	004240	004242				
8292	047326	001176	001116	001162	DT41:	.WORD	STMPD, SERRPC, SREGD, CHKDRV
8293	047334	001254					
8294	047336	001176	001116	001162	DT42:	.WORD	STMPD, SERRPC, SREGD, CHKDRV, RP.REG, RP.REG+10, RP.REG+12
8295	047344	001254	004204	004214			
8296	047352	004216					
8297	047354	001176	001116	001162	DT43:	.WORD	STMPD, SERRPC, SREGD, CHKDRV, RP.REG, RP.REG+10, RP.REG+12
8298	047362	001254	004204	004214			
8299	047370	004216					
8300	047372	004220	004244	004246	DT43A:	.WORD	RP.REG+14, RP.REG+40, RP.REG+42
8301	047400	001176	001116	001162	DT44:	.WORD	STMPD, SERRPC, SREGD, CHKDRV, CYL.DS, TRK.DS, SEC.DS
8302	047406	001254	001270	001274			
8303	047414	001272					
8304	047416	004204	004214	004216	DT44A:	.WORD	RP.REG, RP.REG+10, RP.REG+12, RP.REG+36, RP.REG+34, RP.REG+66
8305	047424	004242	004240	004212			
8306	047432	004220	004244	004246	DT44B:	.WORD	RP.REG+14, RP.REG+40, RP.REG+42
8307	047440	001176	001116	001162	DT45:	.WORD	STMPD, SERRPC, SREGD, CHKDRV, CYL.DS, TRK.DS, SEC.DS
8308	047446	001254	001270	001274			
8309	047454	001272					
8310	047456	004204	004214	004216	DT45A:	.WORD	RP.REG, RP.REG+10, RP.REG+12, RP.REG+36, RP.REG+34, RP.REG+66
8311	047464	004242	004240	004212			
8312	047472	004220	004244	004246	DT45B:	.WORD	RP.REG+14, RP.REG+40, RP.REG+42, RP.REG+2, RP.REG+4, RP.REG+22
8313	047500	004206	004210	004226			

8314  
8315 .SBTTL DATA FORMAT (DF) TABLE

8316					DF1:	.WORD	1	: NUMBER OF DATA HEADERS
8317	047506	000001				.BYTE	2	: NUMBER OF WORDS IN DATA TABLE
8318	047510	002				.BYTE	0	: ALL 3 NUMBERS ARE OCTAL
8319	047511	000						
8320								
8321	047512	000001			DF2:	.WORD	1	
8322	047514	007				.BYTE	7	
8323	047515	000				.BYTE	0	

8324					
8325	047516	000001	DF3:	.WORD	1
8326	047520	004		.BYTE	4
8327	047521	000		.BYTE	0
8328					
8329	047522	000001	DF4:	.WORD	1
8330	047524	005		.BYTE	5
8331	047525	000		.BYTE	0
8332					
8333	047526	000001	DF10:	.WORD	1
8334	047530	002		.BYTE	2
8335	047531	000		.BYTE	0
8336					
8337	047532	000001	DF11:	.WORD	1
8338	047534	002		.BYTE	2
8339	047535	000		.BYTE	0
8340					
8341	047536	000002	DF12:	.WORD	2
8342	047540	007		.BYTE	7
8343	047541	160		.BYTE	160
8344	047542	046027		.WORD	DH12A
8345	047544	006		.BYTE	6
8346	047545	000		.BYTE	0
8347					
8348	047546	000002	DF13:	.WORD	2
8349	047550	007		.BYTE	7
8350	047551	160		.BYTE	160
8351	047552	046106		.WORD	DH13A
8352	047554	005		.BYTE	5
8353	047555	004		.BYTE	4
8354					
8355	047556	000000	DF14:	.WORD	0
8356	047560	005		.BYTE	5
8357	047561	004		.BYTE	4
8358					
8359	047562	000001	DF17:	.WORD	1
8360	047564	010		.BYTE	10
8361	047565	000		.BYTE	0
8362					
8363	047566	000002	DF21:	.WORD	2
8364	047570	006		.BYTE	6
8365	047571	060		.BYTE	60
8366	047572	046330		.WORD	DH21A
8367	047574	004		.BYTE	4
8368	047575	014		.BYTE	14
8369					
8370	047576	000000	DF22:	.WORD	0
8371	047600	004		.BYTE	4
8372	047601	014		.BYTE	14
8373					
8374	047602	000002	DF23:	.WORD	2
8375	047604	007		.BYTE	7
8376	047605	010		.BYTE	10
8377	047606	046455		.WORD	DH23A
8378	047610	005		.BYTE	5
8379	047611	000		.BYTE	0

;2 DH'S TO BE TYPED  
;7 DATA WORDS FOLLOW THE 1ST DH  
;WORDS 1-4 ARE OCTAL 5-7 ARE DECIMAL  
;ADDRESS OF 2ND DH  
;6 DATA WORDS FOLLOW THE 2ND DH  
;ALL WORDS ARE OCTAL

;WORD 3 IS DECIMAL

;WORD 3 IS DECIMAL

;WORD 4 IS DECIMAL

013

8380								
8381								
8382	047612	000001			DF41:	.WORD	1	
8383	047614	004				.BYTE	4	
8384	047615	000				.BYTE	0	
8385								
8386	047616	000001			DF42:	.WORD	1	
8387	047620	007				.BYTE	7	
8388	047621	000				.BYTE	0	
8389								
8390	047622	000002			DF43:	.WORD	2	
8391	047624	007				.BYTE	7	
8392	047625	000				.BYTE	0	
8393	047626	046646				.WORD	0443A	
8394	047630	003				.BYTE	3	
8395	047631	000				.BYTE	0	
8396								
8397	047632	000003			DF44:	.WORD	3	
8398	047634	007				.BYTE	7	
8399	047635	160				.BYTE	160	
8400	047636	046674				.WORD	0444A	
8401	047640	006				.BYTE	6	
8402	047641	000				.BYTE	0	
8403	047642	046751				.WORD	0444B	
8404	047644	003				.BYTE	3	
8405	047645	000				.BYTE	0	
8406								
8407	047646	000002			DF45:	.WORD	2	
8408	047650	007				.BYTE	7	
8409	047651	160				.BYTE	160	
8410	047652	046674				.WORD	0444A	
8411	047654	006				.BYTE	6	
8412	047655	000				.BYTE	0	
8413	047656	046777				.WORD	0445A	
8414	047660	006				.BYTE	6	
8415	047661	000				.BYTE	0	
8416								
8417								
8418		047662				.EVEN		
8419						BUFFER=.		
8420	047662	005015	046412	044501	TITLE:	.ASCII	<CR><LF><LF>/MAINDEC-11-DZRJA-A/<CR><LF>	
8421	047670	042116	041505	030455				
8422	047676	026461	055104	045122				
8423	047704	026501	006501	012				
8424	047711	122	030120	027464		.ASCIIZ	3RPO4/5/6 MECHANICAL & READ-WRITE TEST<CR><LF><LF>	
8425	047716	027465	020066	042515				
8426	047724	044103	047101	041511				
8427	047732	046101	023040	051040				
8428	047740	040505	026504	051127				
8429	047746	052111	020105	042524				
8430	047754	052123	005015	000012				
8431	047762	005015	047524	052040	LOADRV:	.ASCII	<CR><LF>/TO TEST DRIVE 0 REPLACE THE 'XXDP' PACK ON DRIVE 0/<CR><LF>	
8432	047770	051505	020124	051104				
8433	047776	053111	020105	020060				
8434	050004	042522	046123	041501				
8435	050012	020105	044124	020105				

050020	054047	042130	023520
050026	051040	041501	020113
050027	047117	042040	044522
050028	042526	030040	005015
050050	044527	044124	040440
050056	047516	044124	051105
050064	030040	041501	026113
050072	041440	042514	051101
050108	046440	046505	051117
050109	020131	047514	040503
050110	044524	047117	032040
050111	026060	040440	042116
050112	051040	051505	040524
050113	052122	005015	
050114	044124	020105	051120
050115	043517	040522	075515
050116	000012		
050117	005015	054523	052123
050118	046505	044040	051501
050119	030440	045466	046440
050202	046505	051117	026131
050210	023440	054130	050104
050216	020047	047514	042101
050227	051105	053440	046111
050232	020114	042502	047440
050240	042526	053522	044522
050246	052124	047105	005015
050254	000012		
050256	010046		
050260	010146		
050262	013746	000004	
050266	013746	000006	
050272	010600		
050274	104400		
050276	012637	000006	
050302	012737	050322	000004
050310	012701	020000	
050314	005711		
050316	005721		
050320	000775		
050322	162701	000002	
050326	010006		
050330	012637	000006	
050334	012637	000004	

.ASCII /WITH ANOTHER PACK, CLEAR MEMORY LOCATION 40, AND RESTART/<CR><LF>

.ASCIZ /THE PROGRAM/<CR><LF>

NOLoad: .ASCIZ <CR><LF>/SYSTEM HAS 16K MEMORY, 'XXDP' LOADER WILL BE OVERWRITTEN/<CR><L

.EVEN

.SBTTL ROUTINE TO SIZE MEMORY

\*\*\*\*\*

\*CALL:

\* JSR PC,SSIZE

\* RETURN

\*\$LSTAD WILL CONTAIN THE LAST AVAILABLE MEMORY LOCATION

SSIZE: MOV R0,-(SP) ;:SAVE R0 ON THE STACK

MOV R1,-(SP) ;:SAVE R1 ON THE STACK

MOV @#ERRVEC,-(SP) ;:SAVE PRESENT ERROR VECTOR PS & PC

MOV @#ERRVEC+2,-(SP)

MOV SP,R0 ;:SAVE THE STACK POINTER

::SET THE ERRVEC PS TO THE PRESENT PS

TRAP ;:PUSH OLD PSW AND PC ON STACK

MOV (SP)+,@#ERRVEC+2 ;:SAVE THE PSW IN @#ERRVEC+2

MOV @2,@#ERRVEC ;:SET FOR TIMEOUT

MOV @20000,R1 ;:FIRST ADDRESS

1\$: TST (R1) ;:TEST THIS ADDRESS

TST (R1)+ ;:STEP TO NEXT ADDRESS

BR 1\$ ;:TRY ANOTHER

2\$: SUB @2,R1 ;:DROP BACK

MOV R0,SP ;:RESTORE THE STACK

MOV (SP)+,@#ERRVEC+2 ;:RESTORE ERROR VECTOR

MOV (SP)+,@#ERRVEC



```

8492 050340 010137 050352          MOV    R1,SLSTAD          ;;LAST ADDRESS
8493 050344 012601          MOV    (SP)+,R1          ;;RESTORE R1
8494 050346 012600          MOV    (SP)+,R0          ;;RESTORE R0
8495 050350 000207          RTS    PC
8496 050352 000000          SLSTAD: .WORD    0          ;;CONTAINS THE LAST ADDRESS
8497
8498
8499
8500
8501
8502
8503
8504
8505
8506
8507
8508
8509
8510 050354 005737 001226          GETADR: TST    @#BUSADR          ;INPUT FROM TTY REQUESTED?
8511 050360 001427          BEQ    7$                    ;NO--BRANCH
8512 050362 005037 001226          CLR    @#BUSADR          ;YES--CLEAR THE REQUEST FLAG
8513 050366 012700 001366          1$: MOV    @#RH.ADR,R0          ;FIRST ADDRESS
8514 050372 012703 050532          MOV    @#RPCS1,R3          ;"RPCS1="
8515 050376 011004          MOV    (R0),R4          ;PRESENT RPCS1 ADDRESS
8516 050400 004037 031466          JSR    R0,@#GETNUM          ;GET NEW RPCS1
8517 050404 000402          BR     2$                    ;COMMA
8518 050406 000767          BR     1$                    ;PERIOD
8519 050410 000412          BR     5$                    ;DOUBLE PERIOD
8520 050412 010420          2$: MOV    R4,(R0)+          ;SAVE NEW RPCS1
8521 050414 012703 050543          MOV    @#RHVEC,R3          ;"RHVEC="
8522 050420 011004          MOV    (R0),R4          ;PRESENT RH11 VECTOR ADDRESS
8523 050422 004037 031466          JSR    R0,@#GETNUM          ;GET NEW RHVEC
8524 050426 000402          BR     3$                    ;COMMA
8525 050430 000756          BR     1$                    ;PERIOD
8526 050432 000401          BR     5$                    ;DOUBLE PERIOD
8527 050434 010420          3$: MOV    R4,(R0)+          ;SAVE NEW RHVEC
8528 050436 010410          5$: MOV    R4,(R0)          ;SAVE INPUT
8529 050440 013701 000004          7$: MOV    @#ERRVEC,R1          ;SAVE THE ERROR VECTOR
8530 050444 012737 050500 000004          MOV    @#$,@#ERRVEC          ;SETUP FOR TRAP
8531 050448 005777 130710          TST    @#RH.ADR          ;CHECK FOR RH11/RPO4
8532 050452 010137 000004          MOV    R1,@#ERRVEC          ;RESTORE ERROR VECTOR
8533 050456 012700 001366          MOV    @#RH.ADR,R0          ;FIRST ADDRESS OF NEW PARAMETERS
8534 050460 012701 034464          MOV    @#RPAOR,R1          ;FIRST ADDRESS OF WHERE TO PUT THEM
8535 050464 012021          MOV    (R0)+,(R1)+          ;BUS ADDRESS
8536 050468 012021          MOV    (R0)+,(R1)+          ;VECTOR ADDRESS
8537 050472 000207          RTS    PC          ;RETURN
8538 050476 010137 000004          8$: MOV    R1,@#ERRVEC          ;RESTORE ERROR VECTOR
8539 050480 022626          CMP    (SP)+,(SP)+          ;CLEAN OFF THE STACK
8540 050484 104010          ERROR 10          ;REPORT THE ERROR
8541 050488 005737 000042          TST    @#42          ;IS THERE A MONITOR?
8542 050492 001724          BEQ    1$                    ;NO--GO ASK FOR ADDRESS
8543 050496 005037 001232          CLR    @#DRVSEL          ;YES--NO DRIVES SELECTED
8544 050500 005037 017532          CLR    @#SEOPCT          ;NO PASSES
8545 050504 000137 017356          JMP    @#SEOP          ;GO TO END OF PROGRAM
8546
8547 050532 005015 050122 051503 MRPCS1: .ASCIZ <CR><LF>/RPCS1=/

```

# E13

MD-11-DZRJA-RA RPO4/5/6 MECHANICAL AND READ/WRITE TEST MACY11 27(1006) 02-NOV-76 18:27 PAGE 161  
DZRJA.014 19-APR-76 00:00 GETADR - GET BUS ADDRESS AND VECTOR ADDRESS

8548	050540	036461	000	
8549	050543	015	051012	053110 MRHVEC: .ASCIZ <CR><LF>/RHVEC=/ .END
8550	050550	041505	000075	
8551		000001		

# F13

ABS = 000200	384#																	
ACL = 000040	418#	427#																
ACTDRV = 034402	6529#	6807#	6858#	7171#	7180#	7408												
ACTSTR = 034403	6535#	7410#	7425#															
ACU = 100000	373#																	
AOE = 001000	290#																	
ATA = 100000	277#																	
ATABIT = 034452	1861	5875	5881	6601#	6774	6870	6975	7334	7353	7361	7378	7484						
ATO = 000001	310#																	
AT1 = 000002	311#																	
AT2 = 000004	312#																	
AT3 = 000010	313#																	
AT4 = 000020	314#																	
AT5 = 000040	315#																	
AT6 = 000100	316#																	
AT7 = 000200	317#																	
A16 = 000400	209#																	
A17 = 001000	204#																	
BAI = 000010	226#																	
BITS = 001424	591#	2022	2056	2094	2137	2177	2257	2300	2350	2450	2607	2673	2777					
	2867	2965	3079	3150	3279	3325	3399	3488	5942	5973	5990	6043	6217					
BIT0 = 000001	183#																	
BIT00 = 000001	173#	183	591	607	1832	1849	1871	1924	4689									
BIT01 = 000002	172#	182	592	608	1835	5015	5043	6850	7097									
BIT02 = 000004	171#	181	593	609	4752	5015	5046											
BIT03 = 000010	170#	180	594	610	5052	7293	7606											
BIT04 = 000020	167#	179	595	611	5049	7328												
BIT05 = 000040	168#	178	596	612	2493	2509	2585	2715	2729	2744	2749	2814	2838					
	2843	2902	2920	2937	2942	3000	3018	3035	3040	5052	5162	6691	7117					
	7308	7458																
BIT06 = 000100	167#	177	597	613	5055	6783	6841	6915	7206	7667								
BIT07 = 000200	166#	176	598	614	6783	7049	7192	7293	7308	7328	7357	7639						
BIT08 = 000400	165#	175	599	615	5043	6793	7471											
BIT09 = 001000	164#	174	600	615	3615	4237	5058	7456										
BIT1 = 000002	182#																	
BIT10 = 002000	163#	601	3599	4701	5015	5046	6236	7099										
BIT11 = 004000	162#	602	4244	5046	6738	6892	7068	7379										
BIT12 = 010000	161#	603	5015	5049	6733	6765	6783	6852	6874	6886	7064	7083	7095					
	7108	7318	7320	7544	7601	7668												
BIT13 = 020000	160#	604	3606	5315	5043	6835	7266	7547										
BIT14 = 040000	159#	605	2504	2710	2724	2809	2897	2915	2995	3013	4219	4943	5015					
	5049	6847	6893	7253	7395	7511	7556	7560	7665									
BIT15 = 100000	158#	606	5207	5308	6835	6847	6850	6852	6883	6886	7068	7097	7099					
	7206	7293	7308	7318	7328	7395	7456	7471	7511	7518								
BIT2 = 000004	181#	7518																
BIT3 = 000010	180#																	
BIT4 = 000020	179#																	
BIT5 = 000040	178#																	
BIT6 = 000100	177#	6876																
BIT7 = 000200	176#																	
BIT8 = 000400	175#																	
BIT9 = 001000	174#																	
BPTVEC = 000014	190#																	
BUFFER = 047662	1248	1272	1296	1320	2470	3097	3112	3125	3168	3178	3192	3313	3415					
	3439	3447	3455	3461	3469	5126#	5127	5129	5131	5132	5133	5206	5243					
	5386	5405	5406	5430	5519	5551	5594	5636	5653	5654	5671	8418#						





































SREG0	001162	507#	3639*	8270	8275	8283	8292	8294	8297	8301	8307								
SREG1	001164	508#	3640*	8258	8265	8285													
SREG2	001166	509#	3641*	8269															
SREG3	001170	510#	3642*	8257	8258														
SREG4	001172	511#	3643*	8278	8285														
SREG5	001174	512#	3644*	8265															
SRESRE	023046	4294#	4350																
SRTMAD	017616	3568#																	
SR2A =	***** U	4351																	
SSAVRE	023010	4278#	4349																
SS820	023170	4363#	5278	5285	5289	5294	5301	5305	5317	5322	6081	6156							
SSCOPE	022564	1727	4217#																
SSETUP=	000147	1799#	1726	1727	1729	1731	1733	1735	1736	1738	1779	3544	3589	3614					
		3627	3990	3995	3996	4026	4202	4218											
SSIZE	050256	1773	8475#																
SSTUP =	177777	1705#																	
SSUPRS	023420	4444#	5279	5286	5290	5295	5302	5306	5318	5323	6082	6157							
SSVLAD	022744	4228	4252#																
SSVPC =	000200	70#	75																
SSMR =	167000	3#	13	41	42	43	44	45	46	468#	516	517	518	1735					
		1736	1733	1739	2032	2065	2104	2147	2187	2267	2310	2360	2460	2617					
		2683	2787	2877	2975	3089	3160	3289	3409	3498	3519	3545	3561	3567					
		3569	3580	3581	3582	3583	3584	3599	3606	3611	3615	3625	4210	4211					
		4212	4213	4214	4219	4231	4233	4234	4235	4242	4243	4244	4253	4256					
		4259																	
SSUPMK=	000000	4214																	
STIMES	001204	516#	1735*	2030*	2064*	2102*	2145*	2185*	2265*	2308*	2358*	2458*	2615*	2681*					
		2785#	2875*	2973*	3087*	3158*	3287*	3407*	3496*	3545*	4242*	4247	4250*	4259					
		498#	3971	3971	3982	4007	4035	4062											
STKB	001146	3952#	3966*	3996	4013*	4127	4129*												
STKCN	021312	1778	3966#	3987	4048														
STKINT	021322	3956#	4021	4132															
STKQEN=	021322	3953#	3967*	3968	4019*	4020*	4021	4023*											
STKQIN	021314	3954#	3968*	4130	4131*	4132	4134*												
STKQOU	021316	3955#	3967	4023	4134														
STK2SR	021320	497#	3951	3972*	4003*	4005	4011*	4033	4049*	4059	4071*	4091*							
STKS	001144	3969	3982#																
STKSRV	021372	513#	3636*	8261	8263	8265	8270	8275	8280	8283	8287	8292	8294	8297					
STMP0	001176	8301	8307																
		514#																	
STMP1	001200	515#																	
STMP2	001202	3#	13	2011	2020	2022	2031	2032#	2043	2054	2076	2065	2066#	2079					
STN =	000023	2092	2094	2103	2104#	2126	2135	2137	2146	2147#	2165	2175	2177	2186					
		2187#	2242	2255	2257	2266	2267#	2287	2298	2300	2309	2310#	2337	2348					
		2350	2359	2360#	2413	2448	2450	2459	2460#	2592	2605	2607	2616	2617#					
		2659	2671	2673	2682	2683#	2764	2775	2777	2786	2787#	2852	2865	2867					
		2876	2877#	2950	2963	2965	2974	2975#	3064	3077	3079	3088	3089#	3134					
		3148	3150	3159	3160#	3215	3277	3279	3288	3289#	3372	3397	3399	3408					
		3409#	3477	3486	3488	3497	3498#	5933	5957	6032									
STMPWR	023334	4391	4392	4412#															
STPB	001152	500#	1761*	3595*	3623*	3790*	380'												
STPFLG	001157	504#	3748	3801															
STPS	001150	499#	1760*	3594*	3622*	3788	3801												
STRAP	023104	1731	4215#																
STRAP2	023126	4326#	4337																
STRP =	000014	4330#	4339#	4340#	4341#	4342#	4343#	4344	4345#	4346	4347#	4348#	4349#	4350#					

# K14

MD-11-DZRJA-AA RPO4/5/6 MECHANICAL AND READ/WRITE TEST MACY11 27(1006) 02-NOV-76 18:27 PAGE 181  
 DZRJA.014 19-APR-76 00:00 CROSS REFERENCE TABLE -- USER SYMBOLS

\$TRPAD 023140	4351#												
\$TSTNM 001102	4320	4337#											
	477#	2025*	2029	2059*	2063	2097*	2101	2140*	2144	2180*	2184	2260*	2264
	2303*	2307	2353*	2357	2453*	2457	2610*	2614	2676*	2680	2780*	2784	2870*
	2874	2968*	2972	3082*	3086	3153*	3157	3282*	3286	3402*	3406	3491*	3495
	3544*	3598	3625	3636	4209	4251*	4256	4r20	4735	4937			
\$TTYIN 022476	4145	4146	4158	4176	4190	4194#							
\$TYP8N= ***** U	4343												
\$TYPOS 021066	3892#	4342											
\$TYPE 020420	3748#	4330	4338										
\$TYPEC 020570	3769	3776	3783	3788#	3789	4093							
\$TYPEX 020636	3794	3796	3799#										
\$TYPOC 020664	3832#	4339											
\$TYPON 020700	3831	3834#	4341										
\$TYPOS 020640	3827#	4340											
\$XTSTR 022576	4222#												
\$SGET4= 000000	3561#												
\$OFILL 021063	3828*	3832#	3842	3877#									
\$4OCAT= ***** U	3608	4219											
.	58#	62#	70	71#	73#	75#	78#	474#	522	1724	1738	1739	2109
	2117	2152	2156	2197	2219	2273	2317	2381	2384	2479	2517	3098	3103
	3106	3114	3121	3170	3180	3197	3203	3289	3343	3349	3359	3409	3421
	3442	3448	3456	3462	3470	3526#	3569	3570#	3625	3669#	3801	3946#	3951
	3955#	3956	3957	4194#	4195	4202#	4259	4260	4432#	6048#	7720#	7721#	7722#
	7723#	7724#	7725#	7726#	7727#	7728	8418						



CKCHR	1705#	5809	5859	6086	6123	6163	6326	6339	6350	6401					
CKDIG	1705#	5867	6105												
CKNUM	1705#	5817	6138	6171											
COMMEN	198#	1960	1995	2641	3050										
COMND	1705#	1929	2032	2361	2461	3501	3506								
DO	1705#	1928	1930	2039	2040	2075	2076	2112	2120	2154	2159	2200	2206	2222	2228
	2276	2278	2322	2324	2326	2328	2330	2332	2383	2404	2626	2628	3502	3507	5141
DOOTA	1705#	3101	3105	3110	3120	3127	3173	3184	3200	3206	3346	3352	3362	3423	3444
	3450	3458	3464	3472											
DRV. IN	1705#	2748	2842	2941	3039										
ENDCOM	198#	1988	2006	2654	3059										
ENCPAS	1705#	3554													
ERRCAL	6421#	7222	7273	7276	7551	7612									
ERREND	1705#	3622													
ERROR	92#	1914	2506	2584	2718	2732	2747	2917	2841	2905	2923	2940	3003	3071	3108
	4809	4810	4811	4812	4813	4840	4841	4842	4843	4848	4883	4884	4885	4887	4888
	4932	4933	4974	4935	4936	4962	4963	4964	4965	4966	4988	4989	4990	4991	4992
	5139	5180	5181	5182	5183	5184	5496	5501	5612	5618	5676	5677	7223	7274	7278
	7553	7613	8540												
ERRTYP	1705#	3590													
ER.NDX	1705#	4803	4834	4877	4926	4956	4982	5174							
ESCAPE	198#	2694	2795	2885	2983	4802	4833	4876	4924	4955	4981	5137	5173	5495	5479
	5611	5616	5664												
GETPRI	198#	4520	8481												
GETSWR	3#	198#	1779												
LOOP	1705#	2109	2117	2152	2156	2197	2219	2273	2317	2380	2394	2478	2516	3098	3103
	3106	3114	3121	3170	3180	3197	3203	3343	3349	3359	3421	3442	3448	3456	3462
	3470														
MORETA	468#	523													
MORE.S	1705#	2020	2054	2092	2135	2175	2255	2298	2348	2448	2605	2671	2775	2865	2963
	3077	3148	3277	3397	3486										
MSG	2011#	2013	2043#	2045	2079#	2081	2126#	2128	2165#	2167	2242#	2244	2287#	2289	2337#
	2339	2412#	2415	2592#	2594	2658#	2661	2764#	2766	2852#	2854	2950#	2952	3064#	3066
	3134#	3136	3215#	3217	3372#	3374	3477#	3479							
MULT	198#														
NEWTST	198#	2011	2043	2079	2126	2165	2242	2287	2337	2413	2592	2659	2764	2852	2950
	3054	3134	3215	3372	3477										
POP	198#	3333	4299	4488	4571	4716	4765								
PUSH	198#	3292	4279	4469	4523	4671	4729								
REPORT	198#	1705#	2755	2758	2847	2946	3044								
RPO4.D	2#	6421													
SAV. RH	1705#	2712	2726	2741	2811	2835	2899	2917	2934	2997	3015	3032			
SCOPE	93#	2041	2077	2124	2163	2240	2285	2335	2410	2590	2636	2761	2849	2948	3046
	3132	3212	3369	3473	3510										
SETPRI	198#	4123													
SE.TRA	4330#	4339	4340	4341	4342	4344	4346	4347	4348	4349	4350				
SETUP	198#	1719													
SET.TN	1705#	2021	2055	2093	2136	2176	2256	2299	2349	2449	2606	2672	2776	2866	2964
	3078	3149	3278	3398	3487										
SKIP	198#														
SLASH	198#														
SPACE	198#														
STAPS	68	198#	202	244	248	439	470	522	1607	2011	2019	2043	2053	2079	2091
	2126	2134	2165	2174	2242	2254	2287	2297	2337	2347	2413	2447	2592	2604	2659
	2670	2764	2774	2852	2864	2950	2962	3064	3076	3134	3147	3215	3276	3372	3396
	3477	3485	3516	3576	3626	3733	3804	3882	3950	4026	4041	4112	4136	4206	4263

SWRSU	4309	4354	4373	4436	4460	4497	6420	6430	8469	8498									
TRMTRP	198#	1740#																	
TYPBIN	4330#																		
TYPB2D	198#																		
TYPDEC	1705#	5277	5284	5288	5293	5300	5304	5316	5321	6080	6155								
TYPEND	198#	3707																	
TYPNAM	1705#	3523																	
TYPNUM	198#																		
TYPNUM	198#																		
TYPNUM	198#	1807	1883	1932	3533	6049													
TYPNUM	198#	3541	3704	4054	5804	6118	6159												
TYPNUM	198#	3523	3529	3537	3554	3666	3683	5773	5853	5885	6045	6150							
TYPNUM	198#	507	508	509	510	511	512												
TYPNUM	468#	513	514	515															
TYPNUM	468#																		
TYPNUM	198#																		
TYPNUM	198#	2011	2043	2079	2126	2165	2242	2287	2337	2413	2592	2659	2764	2852	2950				
TYPNUM	3064	3134	3215	3372	3477														
TYPNUM	4330#	4339	4340	4341	4342	4344	4346	4347	4348	4349	4350								
TYPNUM	198#																		
TYPNUM	3#	88																	
TYPNUM	3#																		
TYPNUM	3#	1709																	
TYPNUM	3#	37																	
TYPNUM	3#	48	49	50	51	52	53	54											
TYPNUM	47#																		
TYPNUM	3#	66																	
TYPNUM	3#	56																	
TYPNUM	3#	468																	
TYPNUM	3#	4371																	
TYPNUM	3#	4495																	
TYPNUM	3#	3514																	
TYPNUM	3#	3574																	
TYPNUM	3#	4458																	
TYPNUM	3#																		
TYPNUM	3#	3948																	
TYPNUM	3#	4261																	
TYPNUM	3#	4352																	
TYPNUM	3#	4214																	
TYPNUM	3#	8417																	
TYPNUM	3#	4414																	
TYPNUM	3#	4317																	
TYPNUM	3#	3730																	
TYPNUM	3#	3731																	
TYPNUM	3#	3802																	

. ABS. 050554 000

ERRORS DETECTED: 0  
DEFAULT GLOBALS GENERATED: 0

NOW. SEQ/SOL/CRF/LI:ME/NL:TOC:MC:MD:CND=RPO456.010,DZRJA.014  
RUN-TIME: 89 92 10 SECONDS  
RUN-TIME RATIO: 710/192=3.6  
CORE USED: 46K (91 PAGES)

N14

MD-11-DZRJA-AA RPO4/5/6 MECHANICAL AND READ/WRITE TEST MACY11 27(1006) 02-NOV-76 18:27 PAGE 185  
DZRJA.014 19-APR-76 00:00 CROSS REFERENCE TABLE -- MACRO NAMES

