

# RM03

RM03 PERFORMANCE EX.  
MD-11-DZRMB-A

EP-DZRMB-A-DL-A

OCT 1977

COPYRIGHT © 1977

**digital**

FICHE 1 OF 2

MADE IN USA

This microfiche card contains 144 frames of data, arranged in a 12x12 grid. Each frame displays a small, high-contrast image of a document page, likely a performance report or technical document. The text in the frames is too small to be legible but appears to be organized into tables and sections.

# RM03

RM03 PERFORMANCE EX.  
MD-11-DZRMB-A

EP-DZRMB-A-DL-A  
COPYRIGHT © 1977  
FICHE 2 OF 2

OCT 1977  
**digital**  
MADE IN USA

801

EOF1DZRMABSEQ

00010000

770804

PDP10 411

HDR1DZRMABSEQ

00010000

770804

.REM 2

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZRMB-A-D

PRODUCT NAME: RMO3 PERFORMANCE EXERCISER

DATE CREATED: AUGUST 1977

MAINTAINER: DIAGNOSTIC ENGINEERING

AUTHOR: C. CHEN

COPYRIGHT (C) 1977 DIGITAL EQUIPMENT CORP., MAYNARD, MASS.

THE INFORMATION IN THIS STATEMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

ACTUAL DISTRIBUTION OF THE SOFTWARE DESCRIBED IN THIS DOCUMENT WILL BE SUBJECT TO TERMS AND CONDITIONS TO BE ANNOUNCED ON SOME FUTURE DATE BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

THIS SOFTWARE IS FURNISHED TO PURCHASER UNDER A LICENSE TO USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DEC'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DEC.

## CONTENTS

- 1. ABSTRACT
- 2. REQUIREMENTS
  - 2.1 EQUIPMENT
  - 2.2 MEDIA
  - 2.3 PRELIMINARY PROGRAMS
- 3. OPERATING THE PROGRAM
  - 3.1 LOADING THE PROGRAM
  - 3.2 STARTING THE PROGRAM
  - 3.3 RESTARTING THE PROGRAM
  - 3.4 PROGRAM CONTROL
  - 3.5 PASS/TEST TERMINATION
    - 3.5.1 PASS TERMINATION
    - 3.5.2 TEST TERMINATION
  - 3.6 RUN TIME
    - 3.6.1 DATA TRANSFER MODE
    - 3.6.2 SEEK VERIFICATION MODE
  - 3.7 UNIBUS & VECTOR ADDRESSES
  - 3.8 DUAL PORT OPERATION
  - 3.9 APT
  - 3.10 APT ENVIRONMENTAL TABLE DEFINITIONS
- 4. CONTROLLING THE PROGRAM
  - 4.1 DATE & OPERATOR IDENTIFICATION
  - 4.2 PARAMETERS
    - 4.2.1 PROGRAM CONTROL PARAMETERS
    - 4.2.2 PERIPHERAL DEVICE ADDRESSES
    - 4.2.3 PARAMETERS FOR THE FIRST OPERATION
  - 4.3 SWITCH REGISTER SETTINGS
  - 4.4 KEYBOARD COMMANDS
    - 4.4.1 'T' COMMAND
    - 4.4.2 'D' COMMAND
    - 4.4.3 'S' COMMAND
    - 4.4.4 'W' COMMAND
    - 4.4.5 'R' COMMAND
    - 4.4.6 'WT' COMMAND
    - 4.4.7 GENERAL COMMAND INFORMATION
- 5. PERFORMANCE SUMMARY TYPEOUT
  - 5.1 PERFORMANCE SUMMARY TYPEOUT EXPLANATION
  - 5.2 HARD/SOFT ERROR DEFINITIONS
    - 5.2.1 HARD ERRORS
    - 5.2.2 SOFT ERRORS
- 6. DATA CHECKING & ERROR RECOVERY
  - 6.1 DATA BUFFER COMPARISON
  - 6.2 VERIFICATION OF DATA WRITTEN

47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102

103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
1216.3 SECTOR REFORMATTING  
6.4 BAD TRACK/SECTOR FLAGGING

## 7. ERROR MESSAGES

7.1 ERROR DESCRIPTION LINES  
7.2 DETAIL ERROR LINES

## 8. PROGRAM DESCRIPTION

8.1 HOW THE PROGRAM OPERATES  
8.2 DUAL PORT OPERATION  
8.3 HOW VARIABLES ARE SELECTED FOR EACH OPERATION  
8.4 DATA PATTERNS

## 9. RMO3 SOFTWARE DRIVER DOCUMENT

1. ABSTRACT

THE RMO3 PERFORMANCE EXERCISER PROGRAM IS DESIGNED TO PERFORM AN INTERACTIVE TEST ON RMO3 DISK DRIVES CONNECTED TO A MASSBUS SUBSYSTEM. THE DRIVES MAY BE CONTROLLED BY EITHER AN RH11 OR AN RH70. IN ADDITION TO PERFORMING AN INTERACTIVE TEST OF THE DISK DRIVES ON THE SUBSYSTEM, THE PROGRAM IS INTENDED TO BE USED TO VERIFY THAT THE DRIVES UNDER TEST ARE PERFORMING TO THEIR DATA ERROR RATE AND SEEK ERROR RATE (SEE ERROR RATE SPECIFICATIONS).

THE RMO3 PERFORMANCE EXERCISER PROGRAM WILL EXERCISE DRIVES CONNECTED AS EITHER SINGLE OR DUAL PORT UNITS. DUAL PORT DRIVES ARE TESTED BY LOADING AND RUNNING THE PROGRAM FROM BOTH CONTROLLING SYSTEMS. THE PROGRAM WILL EXERCISE A MIXED SYSTEM OF DUAL PORT AND SINGLE PORT DRIVES.

TO OBTAIN INTERACTIVE TESTING, OPERATIONS ON THE DRIVES ARE OVERLAPPED (OTHER DRIVES ARE PERFORMING SEEK/SEARCH OPERATIONS WHILE ONE DRIVE IS PERFORMING A DATA TRANSFER OR WRITE CHECK OPERATION). OPERATIONS AMONG THE DRIVES ARE OPTIMIZED SO THAT A HIGH SUBSYSTEM DATA TRANSFER RATE OR A HIGH POSITIONING OPERATION RATE IS MAINTAINED.

THE PERFORMANCE OF EACH DRIVE IS MONITORED BY THE PROGRAM. IF A DRIVE EXCEEDS A PRESET NUMBER OF ERRORS IN ANY OF SEVERAL CATEGORIES, THAT DRIVE IS AUTOMATICALLY DEASSIGNED. (THE OPERATOR MAY OVERRIDE THE AUTOMATIC DEASSIGNMENT FEATURE.) THE PROGRAM REPORTS PERFORMANCE STATISTICS FOR EACH DRIVE BEING EXERCISED ON REQUEST FROM THE OPERATOR OR AUTOMATICALLY AT AN INTERVAL DETERMINED BY THE OPERATOR.

ALL DATA TRANSFER COMMANDS ARE USED (I.E., WRITE DATA, WRITE HEADER & DATA, READ DATA, AND READ HEADER & DATA) AS WELL AS WRITE CHECK DATA AND WRITE CHECK HEADER & DATA COMMANDS. RECALIBRATE AND READ-IN PRESET COMMANDS ARE USED AT STARTUP AND DRIVE INITIALIZATION. RECALIBRATE, OFFSET, AND RETURN-TO-CENTERLINE COMMANDS ARE USED DURING ERROR RECOVERY.

THE DATA TRANSFER COMMANDS ARE SELECTED RANDOMLY EXCEPT FOR THE WRITE CHECK COMMANDS. THE WRITE CHECK COMMANDS ARE USED TO VERIFY A PREVIOUS WRITE OPERATION. THUS, WHEN A WRITE COMMAND IS SELECTED, THE DATA WRITTEN IS VERIFIED BY THE APPROPRIATE WRITE CHECK COMMAND.

DEPENDING UPON WHETHER PROGRAM HAS BEEN LOADED VIA APT AUTOMATIC MODE OR APT DUMP MODE WILL DETERMINE WHETHER; PROGRAM/OPERATOR COMMUNICATIONS ARE THROUGH THE KEYBOARD, DYNAMIC PROGRAM OPTIONS ARE SELECTED VIA SWITCH REGISTER SETTINGS AND ERRORS ARE REPORTED ON THE TELETYPE.

ALL COMMANDS, DATA PATTERNS, AND DATA BUFFER SIZES ARE SELECTED RANDOMLY BY THE PROGRAM. ADDITIONALLY THE ADDRESSES (EG, CYLINDER, TRACK, AND SECTOR) FOR EACH OPERATION ARE SELECTED RANDOMLY.

122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175

176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
2152. REQUIREMENTS  
-----

## 2.1 EQUIPMENT

REQUIRED  
-----

PDP-11 PROCESSOR  
16K MEMORY (20K IF THE PROGRAM IS INCLUDED IN AN 'XXDP' CHAIN  
TELETYPE  
PROGRAM LOADING DEVICE  
KW11-L OR KW11-P CLOCK  
RH11 OR RH70 WITH 1 RMO3 DISK DRIVE

OPTIONAL  
-----

ADDITIONAL MEMORY TO A MAXIMUM OF 28K  
1 TO 7 ADDITIONAL RMO3'S ON THE SAME RH11 OR RH70

## 2.2 MEDIA

THE RMO3 PERFORMANCE EXERCISER PROGRAM REQUIRES FORMATTED DISK  
PACKS GENERATED BY THE RMO3 FORMATTER PROGRAM (MD-11-DZRMA-A).  
THE PACKS MUST BE FORMATTED IN 32 SECTOR (16 BIT) MODE; THE  
ALTERNATE (30 SECTOR - 18 BIT ) MODE IS NOT SUPPORTED.

## 2.3 PRELIMINARY PROGRAMS

RMO3 DISKLESS DIAGNOSTIC  
RMO3 FUNCTIONAL TEST



216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
2713. OPERATING THE PROGRAM  
-----

3.1 THE PROGRAM MAY BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR IT MAY BE LOADED FROM THE APPROPRIATE 'XXDP' MEDIA USING THE ASSOCIATED LOADER. THE PROGRAM MAY BE INCLUDED IN AN 'XXDP' CHAIN. IF THE PROGRAM IS BEING RUN ON A PROCESSOR WITH 16K, THE 'XXDP' LOADER WILL NOT BE PRESERVED. THE PROGRAM MUST BE RUN ON A SYSTEM WITH 20K OR MORE TO PRESERVE THE 'XXDP' LOADER. THE 'ABSOLUTE' LOADER WILL BE PRESERVED IN A 16K SYSTEM, HOWEVER.

3.2 THE PROGRAM STARTS AT LOCATION 200(8). PARAMETERS NOT INCLUDED IN THE TELETYPE DIAGLOGUE GROUP MUST BE CHANGED BEFORE THE PROGRAM IS STARTED.

THE PROGRAM PERFORMS "TEST" OPERATION TO ALL DRIVES UNDER TESTING AT THE 200(8) STARTING LOCATION AUTOMATICALLY.

3.3 START THE PROGRAM AT LOCATION 204(8) IF THE RH11 OR THE RH70 IS NOT AT ADDRESS 176700.

3.4 PROVIDED THE PROGRAM HAS BEEN LOADED AND STARTED VIA THE APT DUMP MODE OR THE DIAGNOSTIC IS RUNNING IN STAND ALONE PROCESSOR/DRIVE OPERATIONS ARE INITIATED AND CONTROLLED BY KEYBOARD COMMANDS AND SWITCH REGISTER SWITCH SETTINGS. IF THIS IS THE PROGRAM'S FIRST START, THE STATUS OF THE DRIVES ON THE SELECTED MASSBUS SUBSYSTEM WILL BE TYPED OUT. ON SUBSEQUENT STARTS, THIS TYPEOUT MAY BE INHIBITED BY SETTING SW<02>= 1.

HOWEVER, IF THE PROGRAM IS LOADED VIA APT SCRIPT MODE ALL SETUP AND SWITCH REGISTER SETTINGS WILL BE PROVIDED THROUGH THE APT E TABLE. TYPEOUTS FROM THE USER DIAGNOSTIC MAY OR MAYNOT BE INHIBITED DEPENDING UPON WHETHER OR NOT THE APPROPRIATE BIT IN THE E TABLE HAS BEEN SET.

## 3.5 PASS/TEST TERMINATION

A PASS IS DETERMINED BY EITHER BITS READ OR SEEKS PERFORMED. THE NUMBER OF BITS OR SEEKS REQUIRED FOR A PASS IS DERIVED FROM EITHER THE SOFT ERROR RATE SPECIFICATION OR THE SEEK ERROR RATE SPECIFICATION. THE SPECIFICATIONS FOR THE RMO3'S SPECIFY NO MORE THAN 1 SOFT ERROR (NON-PACK RELATED) IN  $1 \times 10^{19}$  BITS READ OR NO MORE THAN 1 SEEK ERROR IN  $1 \times 10^{16}$  SEEKS. THE NUMBER OF BITS OR SEEKS DETERMINING A PASS WERE SELECTED TO PROVIDE A 90% CONFIDENCE LEVEL THAT THE DRIVE IS PERFORMING TO THE APPLICABLE SPECIFICATION.

## 3.5.1 PASS TERMINATION

END OF PASS FOR A SINGLE DRIVE MAY BE DETERMINED BY EITHER OF THE FOLLOWING CONDITIONS. THE END OF PASS CONDITION USED IS DETERMINED BY PARAMETER 'ENDING'.

A. IF PARAMETER 'ENDING' IS 1, END OF PASS OCCURS WHEN THE DRIVE HAS READ  $1.875 \times 10^{18}$  WORDS ( $3 \times 10^{19}$  BITS).

272  
273  
274  
275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327

B. IF PARAMETER 'ENDING' IS 0, END OF PASS OCCURS WHEN THE DRIVE HAS PERFORMED 3 X 10<sup>16</sup> SEEKS.

3.5.2 TEST TERMINATION

THE TEST FOR A DRIVE IS TERMINATED (SW<04> = 0) WHEN:

- A. THE DRIVE HAS COMPLETED THE NUMBER OF PASSES SPECIFIED IN PARAMETER 'PASSES'.
- B. THE TOTAL ERRORS ACCUMULATED EXCEED 100.
- C. A FATAL ERROR OCCURS: EM12 OR EM14.
- D. OPERATOR DEASSIGNS THE DRIVE

3.6 RUN TIME

THE EXERCISER PROGRAM MAY BE RUN IN TWO MODES. THE MODE IS DETERMINED BY THE VALUE IN PARAMETER 'SIZE'. IF 'SIZE' IS ONE SECTOR, THE PROGRAM RUNS IN A SEEK HEAVY MODE; IF 'SIZE' APPROACHES 1/2 TRACK IN SIZE (4096 DECIMAL) THE PROGRAM RUNS IN A DATA TRANSFER HEAVY MODE. THE PROGRAM RUN TIME VARIES GREATLY DEPENDING ON THE OPERATION MODE SELECTED, THE MEMORY AVAILABLE OVER 16K, THE READ/WRITE RATIO PARAMETER - 'RATIO', AND BY SWITCHES 0, 1, & 2.

3.6.1 DATA TRANSFER MODE

1 DRIVE - APPROXIMATELY 3.6 HRS (TO REACH 1.875 X 10<sup>18</sup> WORDS)  
TO  
8 DRIVES - APPROXIMATELY 16 HRS (FOR ALL DRIVES TO REACH 1.875 X 10<sup>18</sup> WORDS)

IF THE PROGRAM IS RUN WITH BOTH SW<00> AND SW<01> SET, THE RUN TIMES SHOULD BE ABOUT 20% FASTER.

3.6.2 SEEK VERIFICATION MODE

PARAMETER 'SIZE' = 1 SECTOR (256 WORDS)  
PARAMETER 'MAXTRK' = 'MINTRK'  
PARAMETER 'MAXSEC' = 'MINSEC'  
SW<00> = 1 (READ ONLY MODE)

1 DRIVE - APPROXIMATELY 25 HRS (3 X 10<sup>16</sup> SEEKS)  
TO  
8 DRIVES - APPROXIMATELY 40 HRS (3 X 10<sup>16</sup> SEEKS FOR ALL DRIVES)

3.7 UNIBUS & VECTOR ADDRESSES

THE PROGRAM ASSUMES THE FOLLOWING UNIBUS AND VECTOR ADDRESSES. (REFER TO SECTION 4.2.2 FOR THE LOCATIONS AT WHICH TO CHANGE THESE ADDRESSES.)

UNIT	UNIBUS ADDRESS	VECTOR ADDRESS
RH11 OR RH70	176700	254
TTY PRINTER	177564	NOT USED

328  
329  
330  
331  
332  
333  
334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383

TTY KEYBOARD	177560	60
KW11-L	177546	100
KW11-P	172542	104

## 3.8 DUAL PORT OPERATION

- A. LOAD THE RMD3 PERFORMANCE EXERCISER PROGRAM INTO BOTH PROCESSORS.
- B. SWITCH THE 'CONTROLLER SELECT' SWITCH TO 'A/B' ON EACH DRIVE WHICH IS TO BE TESTED AS A DUAL PORT DRIVE; CYCLE THE DRIVES UP.
- C. START THE PROGRAM IN EACH PROCESSOR. RUN THE PROGRAM AS THOUGH EACH PROCESSOR WERE RUNNING INDEPENDENTLY OF THE OTHER.

## 3.9 APT

THIS PROGRAM IS APT COMPATIBLE TO THE EXTENT THAT APT HOOKS WILL BE IN THE PROGRAM AND WILL WORK THRU THE 'OPTION INTERFACE'.

FOR OTHER INTERFACES APT MAY ONLY LOAD AND START THE PROGRAM. I.E. LOAD AND DUMP MODE.

## AUTOMATIC MODE (MONITOR)

1. THE INPUT DIALOGUE IS BYPASSED.
2. THE BUSS ADDRESS AND CONTROLLER INTERRUPT VECTOR IS DEFAULTED.

DUMP MODE: INPUT DIALOGUE AFTER PROGRAM STARTS

## 3.10 APT ETABLE DEFINITIONS

THE FOLLOWING DEFINITIONS ARE VALID FOR SPECIFYING APT ENVIRONMENTAL TABLE (ETABLE) ENTRIES, VIA RUNNING THE APT UTILITY PROGRAM "TSP":

## 1. SOFTWARE ENVIRONMENT:

= 1 IF APT SCRIPT MODE  
= 0 IF STANDLONE MODE

## 2. ENVIRONMENT MODE:

BIT 7 = 1 ETABLE DOES SIZING  
= 0 PROGRAM DOES SIZING

BIT 6 = 1 SPOOL MESSAGES TO APT IF SCRIPT MODE  
= 0 DON'T SPOOL TO APT

BIT 5 = 1 SUPPRESS CONSOLE OUTPUT  
= 0 ALLOW CONSOLE OUTPUT

BIT 4 TO BIT 0 ARE NOT USED

384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424

3. SWITCH 1 (SOFTWARE SWITCH REGISTER)  
IF ENVIRONMENT MODE BIT 7 (SIZING BIT ) IS SET TO 1,  
THE SOFTWARE SWITCH REGISTER WILL BE USED, INSTEAD  
OF THE HARDWARE CONSOLE SWITCH REGISTER.
4. SWITCH 2 (USER SWITCH REGISTER)  
NOT USED
5. CPU OPTIONS  
NOT USED
6. MEMORY TYPES 1-4 AND MAX MEMORY ADDRESSES  
NOT USED
7. INTERRUPT VECTOR 1:  
USED WHEN ENVIRONMENT MODE BIT 7 = 1;DEFAULT = 254
8. BUS PRIORITY 1:  
NOT USED.
9. INTERRUPT VECTOR 2:  
NOT USED
10. BUS PRIORITY 2:  
NOT USED
11. BASE ADDRESS:  
USED WHEN ENVIRONMENT MODE BIT 7 = 1;DEFAULT = 176700
12. DEVICE MAP:  
NOT USED
13. CONTROLLER DESCRIPTOR WORDS:  
NOT USED
14. CONTROLLER DESCRIPTOR WORDS:  
NOT USED

425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480

4. CONTROLLING THE PROGRAM  
-----

THE FOLLOWING KEYBOARD CONVENTIONS ARE USED BY THE KEYBOARD ENTRY ROUTINES IN THE PROGRAM:

- A. TO DELETE AN INCORRECT CHARACTER FROM AN ENTRY STRING, TYPE A 'RUBOUT' ('RO'). TYPING A 'RO' WILL DELETE SUCESSIVE CHARACTERS FROM THE INPUT.
- B. TO DELETE AN ENTIRE LINE, TYPE A 'CONTROL U' ('↑U').
- C. AN ENTRY MUST BE TERMINATED BY EITHER A 'CARRIAGE RETURN' OR A 'PERIOD'. THE 'PERIOD' TERMINATION IS RECOGNIZED BY THE PROGRAM AS A DEFAULT ENTRY REQUEST. WHEN A LINE IS TERMINATED BY A 'PERIOD' INSTEAD OF A 'CARRIAGE RETURN', THE PROGRAM WILL ACCEPT THE ENTERED VALUE AND WILL DEFAULT TO THE PRELOADED VALUES FOR ANY REMAINING ENTRIES.
- D. IF A 'CONTROL C' IS TYPED DURING KEYBOARD ENTRY, THE PROGRAM WILL RETURN TO THE BEGINNING OF THE GROUP BEING ENTERED.

4.1 DATE & OPERATOR IDENTIFICATION

ASSUMING THE DIAGNOSTIC HAS BEEN LOADED BY ANY OTHER MODE OTHER THAN THE APT SCRIPT MODE THE PROGRAM WHEN IT IS INITIALLY STARTED, WILL ASK FOR DATE AND OPERATOR I.D. ENTRIES. (THE REQUEST FOR THESE ENTRIES OCCURS ONLY WHEN THE PROGRAM IS FIRST STARTED AND WILL NOT APPEAR WHEN THE PROGRAM IS RESTARTED.) THESE ENTRIES ARE OPTIONAL AND MAY BE BYPASSED BY ENTERING A 'CARRIAGE RETURN' IN RESPONSE TO THE REQUEST. THE PROGRAM DOES NOT EDIT OR CHECK EITHER ENTRY. UP TO 8 CHARACTERS OF DATE INFORMATION AND UP TO 6 CHARACTERS OF OPERATOR IDENTIFICATION MAY BE ENTERED. BOTH THE DATE AND THE OPERATOR I.D. WILL BE TYPED WHEN THE 'SA' COMMAND IS PREFORMED (SEE SECTION 4.4.3).

4.2 PARAMETERS

WHEN THE PROGRAM IS STARTED FROM LOCATION 204, THE OPERATOR WILL BE ASKED TO ENTER PARAMETERS. THE FOLLOWING MESSAGE WILL BE DISPLAYED:

ENTER PARAMETERS:

THE OPERATOR MUST ENTER A 'Y' TERMINATED BY A CARRIAGE RETURN (CR) IF PARAMETER ENTRIES ARE TO BE MADE. ANY OTHER CHARACTER IS ACCEPTED AS A 'NO' ENTRY. THE PROGRAM WILL IDENTIFY THE PARAMETER BY THE NAME GIVEN BELOW, DISPLAY THE CURRENT VALUE OF THE PARAMETER AND WAIT FOR THE ENTRY. THE PROGRAM WILL TYPE 'INVALID ENTRY' IF THE ENTRY IS NOT CORRECT AND WAIT FOR A CORRECT ENTRY TO BE TYPED.

NOTE: WHEN THE DIAGNOSTIC IS LOADED VIA APT SCRIPT MODE ALL PARAMETERS ARE LOADED FROM THE APT SYSTEM E TABLE. THIS INCLUDES THE SOFTWARE SWITCH REGISTER. THEREFORE A WORST CASE CONDITION WILL BE SET IN THE E TABLE FOR NORMAL AUTOMATIC OPERATION.

4.2.1 KEYBOARD ENTRY PARAMETERS

481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500  
501  
502  
503  
504  
505  
506  
507  
508  
509  
510  
511  
512  
513  
514  
515  
516  
517  
518  
519  
520  
521  
522  
523  
524  
525  
526  
527  
528  
529  
530  
531  
532  
533  
534  
535  
536

NAME	BASE	DEFAULT VALUE	VALUE RANGE	FUNCTION
SIZE	10	(SEE NOTE)		CONTROLS THE MAXIMUM BUFFER SIZE USED FOR DATA TRANSFERS
PASSES	10	1	1 - 999	NUMBER OF PASSES TO END OF TEST.
MINUTE	10	5	0 - 256	DETERMINES THE INTERVAL (IN MINUTES) BETWEEN AUTOMATIC PERFORMANCE SUMMARY TYPEOUTS
RANDOM	8	000000	0 OR 1	ERRORS PRINTED OUT IF SW<07>=0 IF PARAMETER = 0, THE DATA TRANSFER WORD COUNT IS RANDOMLY SELECTED BETWEEN 4 AND THE VALUE IN 'SIZE'. IF PARAMETER = 1, THE DATA TRANSFER WORD COUNT WILL BE THE VALUE IN 'MAXDL'
ENDING	8	000001	0 OR 1	IF PARAMETER = 1, END OF PASS DETERMINED BY THE 'WORDS READ' COUNT. IF PARAMETER = 0, END OF PASS IS DETERMINED BY THE NUMBER OF SEEKS.
FORMAT	8	000001	0 OR 1	IF PARAMETER = 0: DO NOT PERFORM WRITE HEADER & DATA ORDERS; IF PARAMETER > 0, PERFORM WRITE HEADER & DATA ORDERS
RATIO	8	000003	0 - 7	CONTROLS THE APPROXIMATE RATIO OF READ TO WRITE ORDERS.
				VALUE R/W RATIO
				0 15/1
				1 7/1
				2 6/2
				3 5/3
				4 4/4
				5 3/5
				6 2/6
				7 1/7
MESSAGE	8	000001	0 OR 1	IF PARAMETER = 1, DO NOT PRINT ERROR MESSAGES FOR DATA ERRORS OCCURING AT LOCATIONS DEFINED BY THE OPERATOR AS BAD PACK LOCATION. IF PARAMETER = 0, PRINT ERROR MESSAGES ASSOCIATED WITH BAD PACK LOCATIONS.

537  
538  
539  
540  
541  
542  
543  
544  
545  
546  
547  
548  
549  
550  
551  
552  
553  
554  
555  
556  
557  
558  
559  
560  
561  
562  
563  
564  
565  
566  
567  
568  
569  
570  
571  
572  
573  
574  
575  
576  
577  
578  
579  
580  
581  
582  
583  
584  
585  
586  
587  
588  
589  
590  
591  
592

PATTERN 10 000000 0 - 15

IF PARAMETER=0, DATA PATTERN IS RANDOMLY SELECTED.  
 IF PARAMETER>0, SPECIFIES ONE OF THE 15 PATTERNS. THE SELECTED DATA PATTERN IS POINTED BY THE PARAMETER "PATTERN".  
 IF PARAMETER=0, RANDOM DATA BLOCK ADDRESS IS USED IN "TEST" COMMAND  
 IF PARAMETER=1, SEQUENTIAL DATA BLOCK IS USED IN "TEST" COMMAND.

HEADER 8 000001 0 OR 1

NOTE: THE PROGRAM WILL SELECT A MAXIMUM BUFFER SIZE WHICH IS DETERMINED BY THE MEMORY AVAILABLE. THE MAXIMUM BUFFER SIZE ASSIGNED BY THE PROGRAM IS 8192 (10) WORDS. THE OPERATOR MAY SPECIFY ANY OTHER MAXIMUM SIZE AS LONG AS THE VALUE SPECIFIED IS AT LEAST 4 WORDS BUT NO LARGER THAN THE INITIAL VALUE OF 'MAXDL' DETERMINED BY THE PROGRAM.

4.2.2 PERIPHERAL ADDRESSES AND OTHER LOCATIONS OF INTEREST

TO ALTER THESE LOCATIONS, THE OPERATOR MUST MAKE MANUAL ENTRIES BEFORE THE PROGRAM IS STARTED. THE KEYBOARD ENTRY ROUTINE DOES NOT PROVIDE ACCESS TO THESE LOCATIONS.

LOC	TAG	CONTENTS	FUNCTION
---	---	-----	-----
1160	STKS	177560	TTY KEYBOARD STATUS REGISTER
1162	STKB	177562	TTY KEYBOARD BUFFER REGISTER
1164	STPS	177564	TTY PRINTER STATUS REGISTER
1166	STPB	177566	TTY PRINTER BUFFER REGISTER
1274	SLKCSR	172540	ADDRESS OF KW11-P STATUS REGISTER
1276	SLKCSB	172542	ADDRESS OF KW11-P COUNTER BUFFER
1300	SLPVEC	104	KW11-P VECTOR ADDRESS
1302	SLKS	177546	ADDRESS OF KW11-L STATUS REGISTER
1304	SLLVEC	100	KW11-L VECTOR ADDRESS
1312	HZ	74	74 (60 DECIMAL) IF SYSTEM IS 60 HZ; 62 (50 DECIMAL) IF SYSTEM IS 50 HZ.

THE RH11-RH70 ADDRESS AND VECTOR MAY BE CHANGED WHEN THE PROGRAM IS STARTED FROM LOCATION 204(8) OR IF THE PROGRAM DOES NOT RECEIVE A RESPONSE WHEN IT ACCESSES THE DEFAULT RH11-RH70 ADDRESS.

4.2.3 PARAMETERS FOR THE FIRST OPERATION

THE FOLLOWING PARAMETERS ARE USED FOR THE INITIAL OPERATION (IN ADDITION TO THE 'MINIMUM' ADDRESS VALUES).

593  
594  
595  
596  
597  
598  
599  
600  
601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619  
620  
621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631  
632  
633  
634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648

LOC	TAG	INITIAL VALUE	VALUE RANGE	FUNCTION
1514	BEGPAT	10	1 - 15	THE CODE FOR THE STARTING PATTERN. (IF A WRITE ORDER OR A WRITE CHECK ORDER IS SPECIFIED IN 'BEGCOD')
1516	BEGCOD	5	0 - 5	THE INITIAL COMMAND FOR EACH DRIVE EXERCISED. 0 = WRITE CHECK DATA 1 = WRITE CHECK HEADER & DATA 2 = WRITE DATA 3 = WRITE HEADER & DATA 4 = READ DATA 5 = READ HEADER & DATA
1520	BEGSIZ	402	2 - SIZE	THE BUFFER SIZE FOR THE FIRST DATA TRANSFER OPERATION.

4.3 SWITCH REGISTER SETTINGS

- SW <15> = 1 HALT ON ERROR
- SW <13> = 1 INHIBIT ERROR TYPEOUT
- SW <10> = 1 RING THE TELETYPE BELL IF ERROR
- SW <7> = 1 DISPLAY ALL DATA COMPARE ERRORS
- SW <6> = 1 DO NOT ALTER THE CURRENT OPERATION PARAMETERS
- SW <5> = 1 PARTIAL REGISTER DISPLAY IF ERROR; DO NOT DISPLAY ECC CORRECTION RESULTS
- SW <4> = 1 INHIBIT MAXIMUM ERROR COUNT CHECK; DO NOT DEASSIGN DRIVES WHEN NORMAL END OF TEST REACHED.
- SW <3> = 1 DISPLAY THE SECTOR IN ERROR (BEFORE RETRY ATTEMPTS) IF 'DCK', 'DTE', OR 'WCF' ERRORS OR AFTER THE 28TH RETRY IF UNCORRECTABLE 'DCK' ERROR. IF DATA COMPARE ERRORS & SW<7> SET, DISPLAY REST OF BUFFER
- SW <2> = 1 INHIBIT SUBSYSTEM STATUS TYPEOUT DURING STARTUP. INHIBIT PERFORMANCE SUMMARY TYPEOUTS.
- SW <1> = 1 INHIBIT DATA COMPARISON AFTER READ ORDERS
- SW <0> = 1 READ ONLY MODE

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM IS IN KEYBOARD ENTRY MODE, OR IS AT A HIGHER PRIORITY PROCESSING AN RMD3 INTERRUPT. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTINGS ARE ENTERED, THE ENTIRE SWITCH REGISTER



649  
650  
651  
652  
653  
654  
655  
656  
657  
658  
659  
660  
661  
662  
663  
664  
665  
666  
667  
668  
669  
670  
671  
672  
673  
674  
675  
676  
677  
678  
679  
680  
681  
682  
683  
684  
685  
686  
687  
688  
689  
690  
691  
692  
693  
694  
695  
696  
697  
698  
699  
700  
701  
702  
703  
704

IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

#### 4.4 KEYBOARD COMMANDS

NOTE: ALL KEYBOARD COMMANDS WILL BE DISABLED IF DIAGNOSTIC IS RUNNING IN THE APT SCRIPT MODE.

THROUGH THE KEYBOARD COMMANDS, THE OPERATOR MAY ASSIGN DRIVES FOR TEST ('T' COMMAND), WRITE AND CHECK DATA PACKS ('W' COMMAND), PERFORM WRITE DATA AND FOLLOWED BY TEST ('WT' COMMAND), PERFORM A SEQUENTIAL READ OF A PACK ('R' COMMAND), REQUEST A DRIVE PERFORMANCE SUMMARY ('S' COMMAND), OR DEASSIGN A DRIVE WHICH IS BEING TESTED, READING, OR WRITING ('D' COMMAND).

AFTER THE PROGRAM HAS BEEN INITIALIZED, THE FOLLOWING MESSAGE WILL BE TYPED:

'PROGRAM INITIALIZATION COMPLETE  
'TYPE A CONTROL C TO ENTER COMMANDS'

KEYBOARD ENTRIES WILL NOT BE RECOGNIZED UNTIL THE OPERATOR TYPES A 'CONTROL C'. WHEN THE PROGRAM SEES A 'CONTROL C' ENTRY, IT WILL SUSPEND THE SCHEDULING OF FURTHER DEVICE OPERATIONS AND WAIT UNTIL ALL OUTSTANDING ORDERS HAVE TERMINATED. THE PROGRAM WILL ENTER COMMAND ENTRY MODE AND TYPE THE FOLLOWING PROMPTING MESSAGE:

'HH:MM:SS  
'ENTER COMMANDS:'

THE PROGRAM WILL THEN ACCEPT ANY OF THE VALID COMMANDS. AT THE COMPLETION OF A COMMAND, THE PROGRAM WILL EXIT COMMAND MODE; THE OPERATOR MUST TYPE ANOTHER 'CONTROL C' TO RETURN THE PROGRAM TO COMMAND MODE. IF THE COMMAND ENTERED SPECIFIED AN 'A' DRIVE NUMBER, THE PROGRAM WILL REMAIN IN COMMAND MODE UNTIL ALL AVAILABLE DRIVES HAVE BEEN PROCESSED.

THE 'WT', 'T', 'W', AND 'R' COMMANDS REQUIRE ADDRESS LIMITS, DRIVE I.D., AND BAD LOCATION ADDRESS ENTRIES FOR THE DRIVE BEING REFERENCED.

THE PROGRAM WILL FIRST ASK FOR ADDRESS LIMITS WITH THE FOLLOWING TYPEOUT:

'ENTER ADDRESS LIMITS FOR DRV #N / RMO3

THE PROGRAM WILL REQUEST VALUES FOR THE FOLLOWING ADDRESS LIMIT PARAMETERS.

DEFAULT VALUE

705  
706  
707  
708  
709  
710  
711  
712  
713  
714  
715  
716  
717  
718  
719  
720  
721  
722  
723  
724  
725  
726  
727  
728  
729  
730  
731  
732  
733  
734  
735  
736  
737  
738  
739  
740  
741  
742  
743  
744  
745  
746  
747  
748  
749  
750  
751  
752  
753  
754  
755  
756  
757  
758  
759  
760

NAME	BASE	VALUE	RANGE	FUNCTION
MINCYL	10	0	0 - 822	THE MINIMUM CYLINDER ADDRESS
MAXCYL	10	822	0 - 822	THE MAXIMUM CYLINDER ADDRESS
MINTRK	10	0	0 - 4	THE MINIMUM TRACK ADDRESS
MAXTRK	10	4	0 - 4	THE MAXIMUM TRACK ADDRESS
MINSEC	10	0	0 - 31	THE MINIMUM SECTOR ADDRESS
MAXSEC	10	31	0 - 31	THE MAXIMUM SECTOR ADDRESS

NOTE: 1. THE ADDRESS LIMITS ARE IN DECIMAL

2. THE MINIMUM CYLINDER, TRACK, OR SECTOR ADDRESS MAY BE SPECIFIED AS BEING LARGER THAN THE MAXIMUM ADDRESS. WHEN THESE VALUES ARE INVERTED, THE PROGRAM WILL SELECT ADDRESSES BETWEEN THE 'MIN' ADDRESS AND THE UPPER PHYSICAL LIMIT FOR THAT ADDRESS AND BETWEEN '0' AND THE VALUE IN 'MAX'.

EACH COMMAND, EXCEPT THE 'S' AND THE 'D' COMMANDS, WILL ASK FOR A DRIVE IDENTIFICATION ENTRY. THE DRIVE IDENTIFICATION ENTRY REQUEST IS MADE BY THE FOLLOWING MESSAGE:

'ENTER I.D. FOR DRV #N:'

THE OPERATOR MAY ENTER AN I.D. NUMBER FOR THE DRIVE OF UP TO 6 CHARACTERS IN LENGTH. THIS I.D. WILL BE DISPLAYED, ALONG WITH THE DATE AND OPERATOR I.D. ENTRIES (SEE SECTION 4.1), WHEN THE 'SA' COMMAND IS EXECUTED. THE OPERATOR MAY ENTER ANY CHARACTER STRING, TERMINATED BY A 'CARRIAGE RETURN', OR A 'PERIOD' ONLY (NULL ENTRY) IN RESPONSE TO THE I.D. REQUEST.

4.4.1

'T' COMMAND

USED TO ASSIGN A DRIVE(S) FOR TEST. THIS COMMAND IS REQUIRED TO PERFORM THE TEST OF THE DRIVE(S). THE OTHER COMMANDS ARE CONVIENCE COMMANDS OR SUPPORT COMMANDS.

FORMAT: TN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINIATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: TO<CR> - ASSIGN DRIVE 0 FOR TEST  
TA<CR> - ASSIGN ALL AVAILABLE DRIVES FOR TEST

NOTE: DRIVE OPERATION BEGINS IMMEDIATELY AFTER COMMAND IS ENTERED.

4.4.2

'D' COMMAND

USED TO DEASSIGN A DRIVE(S) BEING EXERCISED.

FORMAT: DN<CR>

761  
762  
763  
764  
765  
766  
767  
768  
769  
770  
771  
772  
773  
774  
775  
776  
777  
778  
779  
780  
781  
782  
783  
784  
785  
786  
787  
788  
789  
790  
791  
792  
793  
794  
795  
796  
797  
798  
799  
800  
801  
802  
803  
804  
805  
806  
807  
808  
809  
810  
811  
812  
813  
814  
815  
816

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINIATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: DO<CR> - DEASSIGN DRIVE 0  
DA<CR> - DEASSIGN ALL DRIVES BEING TESTED.

- NOTES:
1. IF THE 'D' COMMAND REFERENCES A DRIVE NOT ASSIGNED THE PROGRAM WILL TYPEOUT '?DRIVE NOT ASSIGNED'
  2. THE DRIVES WILL BE DEASSIGNED AS THEIR OPERATIONS COMPLETE.
  3. IF 'DA' IS USED, ALL DRIVES BEING TESTED WILL BE DEASSIGNED; THE MESSAGE IN (1) WILL BE DISPLAYED FOR ALL DRIVES NOT BEING TESTED.

#### 4.4.3 'S' COMMAND

USED TO REQUEST A PERFORMANCE SUMMARY TYPEOUT FOR THE REFERENCED DRIVE(S).

FORMAT: SN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINIATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: SO<CR> - TYPEOUT PERFORMANCE SUMMARY FOR DRIVE 0  
SA<CR> - TYPEOUT PERFORMANCE SUMMARY FOR ALL DRIVES BEING TESTED.

- NOTES:
1. IF 'SA' IS USED ONLY DRIVES BEING TESTED WILL BE DISPLAYED.
  2. IF PARAMETER 'MINUTE' IS NOT ZERO, THE PROGRAM WILL AUTOMATICALLY DISPLAY A PERFORMANCE SUMMARY FOR EACH DRIVE BEING TESTED AT A RATE DETERMINED BY 'MINUTE'.
  3. IF THE 'SA' COMMAND IS USED, THE PROGRAM WILL TYPEOUT THE OPERATOR ENTERED DATE, OPERATOR I.D., AND THE DRIVE I.D. FOR EACH DRIVE BEING TESTED. THE DATE AND OPERATOR I.D. WILL NOT BE TYPED OUT IF NO DRIVES ARE BEING TESTED.

#### 4.4.4 'W' COMMAND

USED TO WRITE A DATA PACK WITH DATA ACCEPTABLE TO THE RMO3 PERFORMANCE EXERCISER PROGRAM.

FORMAT: WN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINIATED BY A CARRIAGE RETURN <CR>.

817  
818  
819  
820  
821  
822  
823  
824  
825  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835  
836  
837  
838  
839  
840  
841  
842  
843  
844  
845  
846  
847  
848  
849  
850  
851  
852  
853  
854  
855  
856  
857  
858  
859  
860  
861  
862  
863  
864  
865  
866  
867  
868  
869  
870  
871  
872

EXAMPLE: WA<CR> - WRITE DATA PACKS ON ALL AVAILABLE DRIVES.  
WD<CR> - GENERATE A DATA PACK ON DRIVE 0.

NOTES: 1. DATA PATTERNS GENERATED BY THE RMD3 FORMATTER PROGRAM (MD-11-DZRMBA-A) ARE COMPATIBLE.

2. THE 'W' COMMAND MUST BE USED TO WRITE A NEW PACK UNDER TEST BEFORE OTHER COMMANDS ARE ISSUED; IF THE DISK PACK HAS BEEN WRITTEN BY ANY PROGRAM OTHER THAN THE FORMATTER.

3. THE 'W' COMMAND PERFORMS A SEQUENTIAL WRITE OF THE PACK USING A 'WRITE DATA' COMMAND. THE DATA PATTERN USED FOR EACH WRITE IS SELECTED RANDOMLY. HOWEVER, THE OPERATION OF THE COMMAND IS SEQUENTIAL, BEGINNING AT 'MINCYL', 'MINTRK' AND CONTINUING TO 'MAXCYL', 'MAXTRK'.

4. THE 'W' COMMAND DOES NOT WRITE HEADERS AND ASSUMES THAT THE FORMAT OF THE PACK IS GOOD.

5. THE 'W' COMMAND CANNOT BE STARTED IF SWITCH 0 (READ ONLY MODE) IS SET. IF SWITCH 0 IS SET DURING THE OPERATION OF THE 'W' COMMAND, THE DRIVE PERFORMING THE 'W' COMMAND WILL IGNORE THE SWITCH.

#### 4.4.5 'R' COMMAND

USED TO PERFORM A SEQUENTIAL READ OF THE PACK.

FORMAT: RN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: RA<CR> - READ THE PACKS ON ALL OF THE ONLINE DRIVES.  
RD<CR> - READ THE PACK ON DRIVE 0.

NOTES: 1. THE PROGRAM WILL PERFORM A NORMAL CHECK OF ALL DATA READ. HOWEVER, ALL OPERATIONS WILL BE SEQUENTIAL.

2. THE PROGRAM WILL READ THE PACK STARTING AT THE ADDRESS SPECIFIED BY 'MINCYL', 'MINTRK' TO THE ADDRESS SPECIFIED BY 'MAXCYL', 'MAXTRK'. THE READ WILL BE SEQUENTIAL.

#### 4.4.6 'WT' COMMAND

USED TO PERFORM A SEQUENTIAL WRITE PACK AND FOLLOWED BY A "TEST" COMMAND

FORMAT: WTN<CR>

873  
874  
875  
876  
877  
878  
879  
880  
881  
882  
883  
884  
885  
886  
887  
888  
889  
890  
891  
892  
893  
894  
895  
896  
897  
898  
899  
900  
901  
902  
903  
904  
905  
906  
907  
908  
909

N= DRIVE NUMBER 0 TO 7 OR "A". ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: WTA<CR> -WRITE ALL PACKS AND TEST ALL PACKS  
WTO<CR>-WRITE PACK 0 AND TEST PACK 0

4.4.7 GENERAL COMMAND INFORMATION

- A. CONTROL-C MUST BE ENTERED BEFORE ISSUING ANY COMMAND.
- B. T,R,W AND WT COMMANDS ARE EXCLUSIVE TO ONE ANOTHER ON THE SAME DRIVE UNDER TESTING. D COMMAND MUST BE ENTERED IN ORDER TO SWITCH COMMANDS AMONG T,R,W AND WT .
- C. S COMMAND CAN BE ENTERED ANY TIME DURING THE TEST.
- D. THE ERROR RESPONSES FROM THE PROGRAM ARE AS FOLLOWS

<u>RESPONSE</u>	<u>COMMAND(S)</u>
?UNIT N OFFLINE	T, W, R,WT
?UNIT N NOT ASSIGNED	D, S
?UNIT N ALREADY ASSIGNED	T, W, R,WT
?UNIT N NOT PRESENT	T, W, R,WT
?UNIT N UNSAFE	T, W, R,WT
?UNIT N NOT AN RMO3	T, W, R,WT

910  
911  
912  
913  
914  
915  
916  
917  
918  
919  
920  
921  
922  
923  
924  
925  
926  
927  
928  
929  
930  
931  
932  
933  
934  
935  
936  
937  
938  
939  
940  
941  
942  
943  
944  
945  
946  
947  
948  
949  
950  
951  
952  
953  
954  
955  
956  
9575. PERFORMANCE SUMMARY TYPEOUT  
-----

- 5.1 THE PROGRAM WILL DISPLAY A PERFORMANCE SUMMARY FOR THE DRIVES BEING EXERCISED. THIS SUMMARY WILL BE DISPLAYED AUTOMATICALLY IF THE PARAMETER 'INTRVL' IS NOT ZERO OR CAN BE DISPLAYED ON REQUEST BY THE OPERATOR THROUGH THE USE OF THE 'S' COMMAND. THE PERFORMANCE SUMMARY TYPEOUT CONTAINS THE FOLLOWING FIELDS:

'DRV'	THE DRIVE NUMBER
'PASS'	THE PRESENT PASS COUNT FOR THE DRIVE
'ORDERS'	THE NUMBER OF ORDERS PERFORMED BY THE DRIVE
'SEEKS'	THE NUMBER OF SEEK OPERATIONS THE DRIVE PERFORMED
'WRDS XFER'	THE TOTAL NUMBER OF WORDS WRITTEN AND READ BY THE DRIVE
'WRDS READ'	THE TOTAL NUMBER OF WORDS READ BY THE DRIVE
'SOFT'	THE NUMBER OF SOFT DATA ERRORS
'HARD'	THE NUMBER OF HARD DATA ERRORS
'SKI'	THE NUMBER OF 'SKI' ERRORS
'MISP'	THE NUMBER OF POSITIONING ERRORS
'OTHER'	THE TOTAL ERRORS OF OTHER TYPES

NOTE: ERRORS EM1, EM2, EM3, EM4, EM5, &amp; EM10 ARE NOT INCLUDED IN THE 'OTHER' ERROR TOTAL.

## 5.2 SOFT/HARD ERROR DEFINITIONS

## 5.2.1 HARD ERRORS

- A. A 'DTE' (DRIVE TIMING ERROR) OR A 'DCK' (DATA CHECK ERROR) WHICH OCCURS DURING A READ DATA OR A READ HEADER & DATA OPERATION AND IS NOT CORRECTABLE OR DOES NOT BECOME CORRECTABLE AFTER THE PROGRAM HAS PERFORMED THE COMPLETE RETRY SEQUENCE ON THE BAD SECTOR. THE RETRY SEQUENCE IS 16 RE-READS AT TRACK CENTER AND 2 ATTEMPTS BOTH AT POSITIVE AND NEGATIVE OFFSETS:

## 5.2.2 SOFT ERRORS

- A. ECC CORRECTABLE 'DCK' ERRORS.  
 B. 'DCK' & 'ECH' ERRORS WHICH BECOME ECC CORRECTABLE DURING RETRY OR WHICH ARE READ CORRECTLY DURING RETRY.  
 C. HEADER READ ERRORS - READ DATA, READ HEADER & DATA, OR WRITE DATA ORDERS.  
 D. 'DTE' ERRORS WHICH ARE CORRECTED OR WHICH BECOME ECC CORRECTABLE 'DCK' ERROR DURING THE RETRY SEQUENCE.

958  
959  
960  
961  
962  
963  
964  
965  
966  
967  
968  
969  
970  
971  
972  
973  
974  
975  
976  
977  
978  
979  
980  
981  
982  
983  
984  
985  
986  
987  
988  
989  
990  
991  
992  
993  
994  
995  
996  
997  
998  
999  
1000  
1001  
1002  
1003  
1004  
1005  
1006  
1007  
1008  
1009  
1010  
1011

## 6. DATA CHECKING & ERROR RECOVERY

### 6.1 DATA COMPARISON

DATA COMPARISON OCCURS AFTER EACH 'RDDAT' (READ DATA) OR 'RDHD' (READ HEADER AND DATA) OPERATION UNDER THE FOLLOWING CONDITIONS:

- A. THE ORDER TERMINATED WITH NO ERROR.
- B. THE OPERATION TERMINATED WITH 'DCK' SET AND THE ERROR IS ECC CORRECTABLE OR THE SECTOR IN ERROR IS READ CORRECTLY AFTER RETRY ATTEMPTS.

### 6.2 VERIFICATION OF DATA WRITTEN

DATA VERIFICATION IS DONE EITHER THROUGH READING THE WRITTEN DATA BACK AND MATCHING THE DATA WITH ONE OF THE 15 PATTERNS OR THROUGH ISSUING WRITE CHECK COMMANDS.

### 6.3 SECTOR REFORMATTING

THE PROGRAM WILL REFORMAT AN UNCORRECTABLE ERROR SECTOR IN THE FOLLOWING CASES (PARAMETER 'FORMAT' MUST BE SET AND SW<00> = 0). THIS PREVENTS THE SAME ERROR FROM BEING CONTINUOUSLY REPORTED.

- A. DATA CHECK ERRORS - EM21
- B. HEADER READ ERRORS - EM20, EM24, EM25, EM26, EM27
- C. DRIVE TIMING ERRORS - EM31
- D. OPERATION INCOMPLETE ERRORS - EM32
- E. WRITE CHECK ERRORS - EM22, EM23

### 6.4 BAD TRACK/SECTOR FLAGGING

SINCE THE RMO3 SUBSYSTEM HAS AN AUTOMATIC BAD TRACK HANDLING CAPABILITY, THE MULTIDRIVE EXERCISER ALLOWS TO IDENTIFY UP TO 16 BAD TRACK/SECTOR LOCATIONS WHEN THE DRIVE IS ASSIGNED FOR TEST. (SEE SECTION 4.4 FOR ADDITIONAL INFORMATION.)

IF ONE OF THE FOLLOWING ERRORS OCCURS AT A LOCATION IDENTIFIED BY THE OPERATOR, THE PROGRAM WILL INHIBIT THE ERROR REPORT FOR THAT ERROR.

DATA CHECK ERRORS ('DCK')  
WRITE CHECK ERRORS ('WCE')  
OPERATION INCOMPLETE ERRORS ('OPI')  
DRIVE TIMING ERRORS ('DTE')  
HEADER READ ERRORS ('FER' & 'HCRC', 'HCE' & 'HCRC', 'HCRC')

OPTIONALLY, THE OPERATOR MAY REQUEST AN ERROR REPORT FOR FLAGGED AREAS. (PARAMETER 'NOTPRT' MUST BE SET TO 0 AT STARTUP.) THE PROGRAM WILL IDENTIFY ERROR MESSAGES ASSOCIATED WITH THE PACK; THESE ERRORS WILL NOT BE ADDED TO THE ERROR TOTALS MAINTAINED BY THE PROGRAM.

1012  
1013  
1014  
1015  
1016  
1017  
1018  
1019  
1020  
1021  
1022  
1023  
1024  
1025  
1026  
1027  
1028  
1029  
1030  
1031  
1032  
1033  
1034  
1035  
1036  
1037  
1038  
1039  
1040  
1041  
1042  
1043  
1044  
1045  
1046  
1047  
1048  
1049  
1050  
1051  
1052  
1053  
1054  
1055  
1056  
1057  
1058  
1059  
1060  
1061  
1062  
1063  
1064  
1065  
1066  
1067

7. ERROR MESSAGES

DRIVE ERRORS ARE REPORTED ON THE TELETYPE OR (IF AVAILABLE) A LINE PRINTER. ALL ERROR CONDITIONS ARE REPORTED IN ERROR MESSAGES; THE PROGRAM CONTAINS NO CODED ERROR HALTS. IF THE PROGRAM HALTS (ASSUMING, OF COURSE, THAT SW(15) IS NOT SET), AN UNRECOVERABLE PROGRAM CONDITION HAS OCCURRED OR A CENTRAL PROCESSOR FAILURE HAS OCCURRED.

ERROR MESSAGES ARE MADE UP OF SEVERAL LINES. EACH TYPE OF ERROR HAS SEVERAL OPTIONAL LINES WHICH MAY APPEAR WITH IT. ALL OF THE POSSIBLE ERROR MESSAGE LINES WHICH MAY APPEAR ARE GIVEN IN THE SECTION DESCRIBING THE PARTICULAR ERROR HEADER.

7.1 ERROR DESCRIPTION LINES

MESSAGES EM1, EM2, EM3, EM4, EM5, EM10, EM11, & EM12 ARE ALWAYS DISPLAYED ON THE TTY. THE OTHER MESSAGES ARE DISPLAYED ON EITHER THE LINE PRINTER (IF AVAILABLE) OR THE TTY.

(THE MESSAGE TAGS ARE GIVEN FOR REFERENCE.)

MESSAGE  
TAG  
---

TEXT  
----

- EM1 RH11 INTERRUPT OCCURRED (RMAS=0)  
THE RH11 INTERRUPTED AND THE ATTENTION SUMMARY REGISTER (RMAS) WAS CLEARED.
- EM2 UNEXPECTED ATTENTION OCCURRED  
THE INDICATED DRIVE INTERRUPTED BUT THE DRIVE WAS NOT PERFORMING AN OPERATION.
- EM3 MASSBUS PARITY ERROR (MCPE=1)  
THE RH11 DETECTED A CONTROL BUS PARITY ERROR WHEN READING THE INDICATED REGISTER FROM THE INDICATED DRIVE.
- EM4 MASSBUS PARITY ERROR (PAR=1)  
THE INDICATED RMO3 DETECTED A CONTROL BUS PARITY ERROR WHEN THE RH11 LOADED THE SPECIFIED REGISTER.
- EM5 ADDRESS PLUG CHANGE BIT SET  
THE 'OPE' BIT WAS SET WHEN THE INDICATED DRIVE INTERRUPTED.
- EM6 RH11 DIDN'T RESPOND TO ADDRESSING  
WHEN THE PROGRAM ADDRESSED THE RH11, NO RESPONSE WAS RECEIVED FROM THE INDICATED ADDRESS.



1068  
1069  
1070  
1071  
1072  
1073  
1074  
1075  
1076  
1077  
1078  
1079  
1080  
1081  
1082  
1083  
1084  
1085  
1086  
1087  
1088  
1089  
1090  
1091  
1092  
1093  
1094  
1095  
1096  
1097  
1098  
1099  
1100  
1101  
1102  
1103  
1104  
1105  
1106  
1107  
1108  
1109  
1110  
1111  
1112  
1113  
1114  
1115  
1116  
1117  
1118  
1119  
1120  
1121  
1122  
1123

EM10 UNCORRECTABLE MASSBUS PARITY ERROR  
THE PROGRAM HAS TRIED 3 TIMES TO READ OR WRITE THE INDICATED REGISTER.

EM11 FATAL MASSBUS PARITY ERROR  
A CONTROL BUS PARITY ERROR OCCURRED WHEN THE RH11 ATTEMPTED TO PROCESS A PREVIOUS, DIFFERENT PARITY ERROR.

EM12 PERSISTENT DEVICE UNSAFE  
THE DRIVE BECAME UNSAFE; DRIVE CLEAR TO THE DRIVE DID NOT CLEAR THE UNSAFE CONDITION. THE PROGRAM WILL AUTOMATICALLY DEASSIGN THE DRIVE. THE DRIVE CANNOT BE EXERCISED UNTIL THE UNSAFE CONDITION HAS BEEN CLEARED BY MANUAL INTERVENTION.

EM13 OPERATION NOT COMPLETED WITHIN TIME LIMIT  
THE DRIVE DID NOT COMPLETE THE OPERATION WITHIN 1 SECOND AFTER THE OPERATION WAS INITIATED.

EM14 UNIT WENT OFFLINE  
THE DRIVE WENT OFFLINE DURING THE INDICATED OPERATION. (THE 'MOL' BIT BECAME ZERO.) THE PROGRAM WILL AUTOMATICALLY DEASSIGN THE DRIVE. THE OPERATOR MUST REASSIGN THE DRIVE WITH THE 'T' COMMAND TO RE-INITIATE TESTING.

EM15 NO RESPONSE TO PORT REQUEST  
THE PROGRAM IS TESTING A DUAL PORT DRIVE WHICH HAS NOT SWITCHED TO THE REQUESTING PORT WITHIN 10 SECONDS AFTER PORT REQUEST TO THE DRIVE FROM THE REPORTING PORT.

EM20 HEADER CRC ERROR  
A HEADER CRC ERROR WAS DETECTED AT THE INDICATED DISK ADDRESS. THE CONTENTS OF THE HEADER ARE DISPLAYED. THE OPERATION WILL BE RETRIED 3 TIMES.

EM21 DATA CHECK ('DCK') ERROR  
A DATA CHECK ERROR WAS DETECTED AT THE INDICATED SECTOR. THE FULL RETRY SEQUENCE (INCLUDING OFFSET) WILL BE INITIATED FOR THE SECTOR IN ERROR IF THE ECC HARD ERROR ('ECH') BIT IS SET.

EM22 WRITE CHECK ERROR - DATA CHECK ('DCK') SET  
A WRITE CHECK ERROR OCCURRED AND THE DATA CHECK ('DCK') BIT WAS SET. IF 'ECH' IS NOT SET, THE OPERATION WILL BE RETRIED UP TO 3 TIMES; IF THE 'ECH' BIT IS SET, THE OPERATION WILL BE RETRIED UP TO 16 TIMES.

1124  
1125  
1126  
1127  
1128  
1129  
1130  
1131  
1132  
1133  
1134  
1135  
1136  
1137  
1138  
1139  
1140  
1141  
1142  
1143  
1144  
1145  
1146  
1147  
1148  
1149  
1150  
1151  
1152  
1153  
1154  
1155  
1156  
1157  
1158  
1159  
1160  
1161  
1162  
1163  
1164  
1165  
1166  
1167  
1168  
1169  
1170  
1171  
1172  
1173  
1174  
1175  
1176  
1177  
1178  
1179

EM23 WRITE CHECK ERROR - DATA CHECK ('DCK') NOT SET  
A WRITE CHECK ERROR OCCURRED AND 'DCK' WAS NOT SET. THE WORDS WHICH CAUSED THE ERROR ARE DISPLAYED IN THE ERROR MESSAGE. THE OPERATION WILL BE RETRIED 3 TIMES.

EM24 HEADER READ ERROR - 'FMT' BIT DROPPED  
A WRITE DATA, WRITE CHECK DATA, OR A READ DATA WAS BEING PERFORMED AND A 'FMT' ERROR OCCURRED. THE PROGRAM RE-READ THE HEADER OF THE ERROR SECTOR AND THE 'HCRC' BIT WAS SET. THE CONTENTS OF THE HEADER ARE DISPLAYED. THE OPERATION WILL BE RETRIED 3 TIMES.

EM25 HEADER READ ERROR - HEADER COMPARE ('HCE') ERROR  
SIMILAR TO EM24, EXCEPT THAT THE 'HCE' ERROR BIT WAS SET INITIALLY. THE OPERATION WILL BE RETRIED 3 TIMES.

EM26 FORMAT ERROR ('FER')  
FORMAT ERROR OCCURRED. WHEN THE HEADER WAS RE-READ, THE 'HCRC' BIT WAS NOT SET. THE CONTENTS OF THE HEADER ARE DISPLAYED. THE OPERATION WILL BE RETRIED 3 TIMES.

EM27 HEADER COMPARE ('HCE') ERROR  
SIMILAR TO EM26 EXCEPT THAT THE 'HCE' BIT WAS SET INITIALLY. THE OPERATION WILL BE RETRIED 3 TIMES.

EM30 MISCELLANEOUS DRIVE ERROR  
THIS MESSAGE IS GIVEN FOR THE FOLLOWING ERROR BITS: 'AOE', 'RMR', 'ILF', OR 'ILR'

EM31 OPERATION INCOMPLETE ('OPI') ERROR  
AN OPERATION INCOMPLETE ERROR OCCURRED AT THE INDICATED SECTOR.

EM32 DRIVE TIMING ('DTE') ERROR  
DRIVE TIMING ERROR OCCURRED ON THE INDICATED SECTOR. THE OPERATION WILL BE RETRIED 3 TIMES.

EM33 PARITY ('PAR') ERROR AFTER OPERATION STARTED  
THE 'PAR' BIT WAS SET WHEN THE OPERATION WAS COMPLETED. THE OPERATION WILL BE RETRIED 3 TIMES.

EM34 WRITE CLOCK FAILURE ('WCF')  
A WRITE CLOCK FAILURE OCCURRED DURING THE OPERATION. THE OPERATION WILL BE RETRIED 3 TIMES.

EM35 INVALID ADDRESS ('IAE') ERROR

1180		AN INVALID ADDRESS ERROR OCCURRED DURING THE OPERATION.
1181		
1182		
1183	EM36	WRITE LOCK ('WLE') ERROR
1184		A WRITE OPERATION WAS ATTEMPTED BUT THE DRIVE WAS WRITE LOCKED.
1185		
1186		
1187		
1188	EM40	RH11 OR UNIBUS TRANSFER ERROR
1189		'TRE' IS SET IN THE RH11 CONTROL REGISTER AND NO DRIVE ERROR HAS OCCURRED. THE OPERATION WILL BE RETRIED 3 TIMES IF THE ERROR WAS CAUSED BY 'DLT', 'UPE', 'MXF', OR 'MDPE'.
1190		
1191		
1192		
1193		
1194		
1195	EM41	BUS ADDRESS OR WORD COUNT INCORRECT
1196		NO DRIVE ERROR OCCURRED BUT EITHER THE BUS ADDRESS INDICATES THAT AN INCORRECT NUMBER OF WORDS WERE TRANSFERED OR THE WORD COUNT REGISTER IS NOT ZERO.
1197		
1198		
1199		
1200		
1201	EM42	DATA COMPARE ERRORS - NO DRIVE ERROR DETECTED
1202		NO SUBSYSTEM ERROR WAS SIGNALLED; HOWEVER, THE DATA DOES NOT COMPARE.
1203		
1204		
1205		
1206	EM43	CAN'T MATCH DATA READ WITH A PATTERN
1207		THE DATA IN THE BUFFER DOES NOT MATCH ANY OF THE STANDARD PATTERNS.
1208		
1209		
1210		
1211	EM44	ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH11
1212		THE OPERATION COMPLETED NORMALLY; HOWEVER, THE PROGRAM FOUND EITHER ERROR BITS IN THE RMO3 SET OR ERROR BITS IN THE RH11 SET.
1213		
1214		
1215		
1216		
1217	EM45	ECC LOGIC FAILURE
1218		THE CONTENTS OF EITHER THE ECC POSITION REGISTER (RMEC1) OR THE CONTENTS OF ECC PATTERN REGISTER (RMEC2) ARE NOT VALID. THE POSITION REGISTER IS EITHER '0' OR > 40066 (8) OR THE PATTERN REGISTER CONTAINS ZEROS.
1219		
1220		
1221		
1222		
1223	EM46	BUS ADDRESS OR WORD COUNT NOT CONSISTENT
1224		THE PROGRAM WAS PROCESSING AN ERROR AND FOUND THAT THE NUMBER OF WORDS TRANSFERED AS INDICATED BY THE BUS ADDRESS REGISTER DOES NOT AGREE WITH THE TRANSFER COUNT FROM THE WORD COUNT REGISTER.
1225		
1226		
1227		
1228		
1229		
1230		
1231	EM50	SEEK INCOMPLETE ERROR
1232		THE DRIVE SIGNALLED EITHER 'SKI' OR 'OCYL' ERROR BITS.
1233		
1234		
1235	EM51	NOT USED

1236  
1237  
1238  
1239  
1240  
1241  
1242  
1243  
1244  
1245  
1246  
1247  
1248  
1249  
1250  
1251  
1252  
1253  
1254  
1255  
1256  
1257  
1258  
1259  
1260  
1261  
1262  
1263  
1264  
1265  
1266  
1267  
1268  
1269  
1270  
1271  
1272  
1273  
1274  
1275  
1276  
1277  
1278  
1279  
1280  
1281  
1282  
1283  
1284  
1285  
1286  
1287  
1288  
1289  
1290  
1291

EM60 DEVICE UNSAFE

THE INDICATED DRIVE UNSAFE ERROR OCCURRED; THE ERROR WAS  
CLEARED BY A 'DRIVE CLEAR' INSTRUCTION.

7.2 DETAIL ERROR LINES

THE LINE NUMBERS GIVEN BELOW ARE FOR REFERENCE ONLY.

LINE 1

TT:TT:TT (DESCRIPTION OF ERROR)

'TT:TT:TT' IS THE TIME SINCE THE PROGRAM  
WAS STARTED. TT:TT:TT IS GIVEN IN HOURS:  
MINUTES: SECONDS.

LINE 2

'PRESENT ORDER = XXXX PREVIOUS ORDER = YYYY'

MNEMONICS USED FOR THE ORDERS ARE DEFINED BELOW:

UNLOAD - UNLOAD (OCTAL 3)  
SEEK - SEEK (OCTAL 5)  
RECAL - RECALIBRATE (OCTAL 7)  
DRVCLR - DRIVE CLEAR (OCTAL 11)  
RELSE - RELEASE (OCTAL 13)  
OFFSET - OFFSET (OCTAL 15)  
RTC - RETURN TO CENTERLINE (OCTAL 17)  
READIN - READIN PRESET (OCTAL 21)  
PACK - PACK ACKNOWLEDGE (OCTAL 23)  
SEARCH - SEARCH (OCTAL 31)  
GETREG - GET REGISTERS (OCTAL 41)  
SETFMT - SET FORMAT (ECI OR HCI) (OCTAL 43)  
SELDRV - SELECT DRIVE (OCTAL 45)  
WCKD - WRITE CHECK DATA (OCTAL 51)  
WCKHD - WRITE CHECK HEADER & DATA (OCTAL 53)  
WRTDAT - WRITE DATA (OCTAL 61)  
WRTHD - WRITE CHECK HEADER & DATA (OCTAL 63)  
RDDAT - READ DATA (OCTAL 71)  
RDHD - READ HEADER & DATA (OCTAL 73)

(DISPLAY OF THE RH11/RMO3 REGISTERS IN TWO GROUPS:  
RMCS1, RMCS2, RMDS1, RMER1, RMER2, RMER3, RMEC1, & RMEC2 FORM THE FIRST  
GROUP; ALL THE OTHER REGISTERS ARE IN THE SECOND GROUP.  
IF SW<05> IS SET, ONLY THE REGISTERS IN THE FIRST GROUP WILL BE  
DISPLAYED.)

THE ABOVE LINE WILL BE TYPED IF THE ERROR OCCURRED DURING

1292  
1293  
1294  
1295  
1296  
1297  
1298  
1299  
1300  
1301  
1302  
1303  
1304  
1305  
1306  
1307  
1308  
1309  
1310  
1311  
1312  
1313  
1314  
1315  
1316  
1317  
1318  
1319  
1320  
1321  
1322  
1323  
1324  
1325  
1326  
1327  
1328  
1329  
1330  
1331  
1332  
1333  
1334  
1335  
1336  
1337  
1338  
1339  
1340  
1341  
1342  
1343  
1344  
1345  
1346  
1347

THE NON-DATA TRANSFER PART OF THE OPERATION.

'\* ERROR AT BAD TRACK/SECTOR'

THE ABOVE LINE WILL BE PRINTED IF A DATA ERROR OCCURES AT AN ADDRESS ON THE PACK WHICH THE OPERATOR HAS IDENTIFIED AS BEING BAD. PARAMETER 'NOTPRT' MUST BE 0 FOR THE ERROR TO BE REPORTED.

A WORD CALLED 'STATUS' IS DISPLAYED WITH THE RMD3 REGISTERS. THE CONTENTS OF THIS WORD IDENTIFY HOW THE ERROR WAS PROCESSED BY THE RMD3 DRIVE HANDLER ROUTINE. THE BITS IN THIS WORD ARE ENCODED AS FOLLOWS:

BIT #	MEANING IF BIT IS '1'
15	ERROR OCCURRED DONE (BIT07=0), BITS 14-9, 2, 1 SPECIFY TYPE DONE (BIT07=1), BITS 6-3 SPECIFY TYPE
14	DRIVE IS OFFLINE
12	PERSISTENT UNSAFE CONDITION EXISTS
11	UNCORRECTABLE PARITY ERROR OCCURRED
10	FATAL PARITY ERROR OCCURRED. MASSBUS CLEAR WAS PERFORMED
9	OPERATION NOT COMPLETED WITHIN 1 SECOND MASSBUS CLEAR PERFORMED. ALL OTHER OUTSTANDING OPERATIONS WERE RESTARTED.
7	DONE - OPERATION COMPLETED
6	DATA ERROR OCCURRED DURING THE TRANSFER
5	ERROR OCCURRED WHILE SEARCHING FOR THE 'TRANSFER' SECTOR OR DURING RECALIBRATE OR OFFSET COMMANDS
4	CORRECTABLE UNSAFE CONDITION OCCURRED
3	DRIVE ERROR OCCURRED THAT CAUSED AN AUTOMATIC RECALIBRATE SEQUENCE
2	PORT REQUEST TIMEOUT
1	NON-EXISTENT DRIVE REQUESTED

LINE 3

-----  
ERROR AT CXXX TYY SZZ PREV ADDR = CUUU TVV SWW

THE ACTUAL ADDRESS OF THE ERROR SECTOR AND THE PREVIOUS DISK ADDRESS ARE GIVEN IN THIS LINE. CYLINDER, TRACK, &

1348  
1349  
1350  
1351  
1352  
1353  
1354  
1355  
1356  
1357  
1358  
1359  
1360  
1361  
1362  
1363  
1364  
1365  
1366  
1367  
1368  
1369  
1370  
1371  
1372  
1373  
1374  
1375  
1376  
1377  
1378  
1379  
1380  
1381  
1382  
1383  
1384  
1385  
1386  
1387  
1388  
1389  
1390  
1391  
1392  
1393  
1394  
1395  
1396  
1397  
1398  
1399  
1400  
1401  
1402  
1403

SECTOR ADDRESSES ARE IN DECIMAL.

LINE 4  
-----

PRESENT ADDR = CXXX TYY SZZ PREV ADDR = CUUU TVV SWW

THIS LINE IDENTIFIES THE ADDRESS WHEN THE ERROR WAS DETECTED;  
THE PREVIOUS ADDRESS IS ALSO GIVEN. CYLINDER, TRACK, & SECTOR  
ADDRESSES ARE GIVEN IN DECIMAL.

LINE 5  
-----

START CYL = XXX END CYL = YYY

THIS LINE IDENTIFIES THE STARTING CYLINDER OR A SEEK (IMPLIED)  
AND THE DESTINATION CYLINDER. CYLINDER ADDRESSES ARE IN  
DECIMAL.

LINE 6  
-----

START CYL = XXX END CYL = YYY ACTUAL CYL = ZZZ

THIS LINE IDENTIFIES THE STARTING CYLINDER OF AN IMPLIED SEEK,  
THE DESTINATION CYLINDER, AND THE CYLINDER THE DISK ACTUALLY  
STOPPED AT. CYLINDER ADDRESSES ARE IN DECIMAL.

LINE 7  
-----

RMBA = XXXX RMWC = YYYY

THIS LINE GIVES THE CONTENTS OF THE RH11 BUFFER ADDRESS  
REGISTER AND THE RH11 WORD COUNT REGISTER. THIS LINE IS  
NOT PRINTED IF SW<05> IS NOT SET.

LINE 8  
-----

START CYL = XXX START TRK = YY START SECTOR = ZZ

THIS LINE IDENTIFIES THE STARTING DISK ADDRESS OF THE PRESENT  
OPERATION. CYLINDER, TRACK, AND SECTOR VALUES ARE DECIMAL.

LINE 9  
-----

RMDA = XXXX RMCA = YYYY

THIS LINE GIVES THE CONTENTS OF THE RMO3 TRACK AND SECTOR  
ADDRESS REGISTER AND THE CONTENTS OF THE DESIRED CYLINDER  
ADDRESS REGISTER. THIS LINE IS NOT PRINTED IF SW<05> IS NOT  
SET.

1404  
1405  
1406  
1407  
1408  
1409  
1410  
1411  
1412  
1413  
1414  
1415  
1416  
1417  
1418  
1419  
1420  
1421  
1422  
1423  
1424  
1425  
1426  
1427  
1428  
1429  
1430  
1431  
1432  
1433  
1434  
1435  
1436  
1437  
1438  
1439  
1440  
1441  
1442  
1443  
1444  
1445  
1446  
1447  
1448  
1449  
1450  
1451  
1452  
1453  
1454  
1455  
1456  
1457  
1458  
1459LINE 10  
-----

BUFFER ADDR = XXXX SIZE = YYYY ACTUAL NUMBR WRDS XFRD = ZZZZ

THIS LINE GIVES THE STARTING ADDRESS OF THE BUFFER USED FOR THE CURRENT DATA TRANSFER OPERATION, ITS SIZE, AND THE ACTUAL NUMBER OF WORD TRANSFERED. THE STARTING ADDRESS OF THE BUFFER IS IN OCTAL, THE SIZE AND WORD TRANSFERED VALUE ARE IN DECIMAL.

LINE 11  
-----

GOOD DATA = XXXX BAD DATA = YYYY SECT POS = ZZZ

THIS LINE GIVES THE GOOD DATA, THE ACTUAL DATA FROM THE DISK, AND THE LOCATION IN THE SECTOR OF THE ACTUAL DATA. THE SECTOR POSITION IS IN DECIMAL.

LINE 12  
-----

HEADER CONTENTS OF ERROR SECTOR = XXXX XXXX XXXX XXXX

THIS LINE GIVES THE CONTENTS OF THE HEADER OF THE SECTOR WHICH GAVE THE ERROR.

LINE 13  
-----

RMEC1 = XXXX RMEC2 = YYYY

THIS LINE WILL BE PRINTED AFTER A SUCESSFUL RETRY OF A SECTOR WHICH BECAME ECC CORRECTABLE DURING RETRY.

LINE 14  
-----

ECC CORRECTABLE WITHOUT OFFSET

THE SECTOR IN ERROR IS ECC CORRECTABLE; NO RETRY ATTEMPTS ARE NECESSARY.

LINE 15  
-----

READ CORRECTLY AT (NEG OR POS) OFFSET

THE SECTOR IN ERROR WAS READ WITHOUT ERROR AT THE INDICATED OFFSET VALUE.

LINE 16  
-----

ECC CORRECTABLE AT (NEG OR POS) OFFSET

1460  
1461  
1462  
1463  
1464  
1465  
1466  
1467  
1468  
1469  
1470  
1471  
1472  
1473  
1474  
1475  
1476  
1477  
1478  
1479  
1480  
1481  
1482  
1483  
1484  
1485  
1486  
1487  
1488  
1489  
1490  
1491  
1492  
1493  
1494  
1495  
1496  
1497  
1498  
1499  
1500  
1501  
1502  
1503  
1504  
1505  
1506  
1507  
1508  
1509  
1510  
1511  
1512  
1513  
1514  
1515

THE SECTOR IN ERROR BECAME ECC CORRECTABLE AT THE INDICATED  
OFFSET.

LINE 17  
-----

CORRECTED ON X RETRY

THE OPERATION WAS PERFORMED ERROR FREE ON THE INDICATED RETRY  
ATTEMPT.

LINE 18  
-----

UNCORRECTABLE AFTER X RETRIES

THE OPERATION COULD NOT BE PERFORMED CORRECTLY AFTER THE  
INDICATED NUMBER OF RETRY ATTEMPTS.

LINE 19  
-----

DIFFERENT ERROR DURING RETRY

WHILE THE PROGRAM WAS RETRYING THE ERROR, A DIFFERENT OCCURRED.  
IF THIS LINE IS PRINTED, THE RH11/RMO3 REGISTERS WILL ALSO BE  
PRINTED (SEE LINE 2).

LINE 20  
-----

DATA COMPARISON ERRORS

A PRINTOUT OF THE DATA COMPARISON ERRORS FOLLOW THIS LINE.

LINE 21  
-----

TOTAL COMPARE ERRORS = XXXX

THIS LINE GIVES THE TOTAL DATA COMPARISON ERROR COUNT. THE  
VALUE GIVEN IS IN DECIMAL.

LINE 22  
-----

THE DATA COMPARED OK

THIS LINE INDICATES THE RESULTS OF THE DATA COMPARISON FOLLOWING  
ECC CORRECTION.

LINE 23  
-----

ECC CORRECTION RESULTS



1516  
1517  
1518  
1519  
1520  
1521  
1522  
1523  
1524  
1525  
1526  
1527  
1528  
1529  
1530  
1531  
1532  
1533  
1534  
1535  
1536  
1537  
1538  
1539  
1540  
1541  
1542  
1543  
1544  
1545  
1546  
1547  
1548  
1549  
1550  
1551  
1552  
1553  
1554  
1555  
1556  
1557  
1558  
1559  
1560  
1561  
1562  
1563  
1564  
1565  
1566  
1567  
1568  
1569  
1570  
1571

THE PROGRAM PERFORMED ECC CORRECTION AND THE RESULTS ARE REPORTED.  
THE ADDRESS IN MEMORY OF THE WORD(S) IN ERROR ARE GIVEN, THE WORD(S)  
BEFORE CORRECTION AND THE WORD(S) AFTER CORRECTION ARE PRINTED.

LINE 24  
-----

ERROR BURST BEGINS AT WORD XXX IN DATA FIELD OF ERROR SECTOR

THIS IS AN INFORMATIONAL LINE WHICH WILL BE PRINTED FOR 'DCK' ERRORS  
WHICH ARE ECC CORRECTABLE OR WHICH BECOME ECC CORRECTABLE DURING  
RETRY. 'XXX' IS THE WORD OFFSET VALUE FROM 'RMECI' AND IS IN  
DECIMAL.

LINE 25  
-----

ERROR WAS NOT IN THE DATA READ -  
ECC CORRECTION CAN'T BE PERFORMED

THE DATA ERROR WAS NOT IN DATA TRANSFERED TO MEMORY.

LINE 26  
-----

CONTENTS OF THE ERROR SECTOR (REPORTED ABOVE)

IF SW<03> IS SET, THE SECTOR WHICH GAVE THE 'DCK', 'DTE' OR,  
'WCF' ERROR OR 'HARD' DATA CHECK ERROR IS PRINTED. THE  
CONTENTS OF THE SECTOR FOLLOW THIS LINE.

LINE 27  
-----

ORDERS: WWW ERRORS: X WRDS XFR: YYYY WRDS READ: ZZZZ

THIS IS THE LAST LINE PRINTED FOR ALL NON-POSITIONING  
TYPE ERRORS.

'ORDERS' IS THE TOTAL NUMBER OF COMMANDS GIVEN TO THE DRIVE  
WHICH REPORTED THE ERROR.

'ERRORS' IS THE TOTAL ERROR COUNT FOR THE DRIVE AND INCLUDES  
EVERY ERROR DETECTED, REGARDLESS OF TYPE.

'WRDS XFR' IS THE TOTAL NUMBER OF WORDS WRITTEN AND READ BY  
THE DRIVE.

'WRDS READ' IS THE TOTAL NUMBER OF WORD READ BY THE DRIVE.

LINE 28  
-----

ORDERS: WWW TOTAL SEEKS: XXX TOTAL POS ERR = YYY TOTAL SKI ERR = Z

THIS IS THE LAST LINE PRINTED FOR ALL POSITIONING TYPE ERRORS.

G03

MD-11-DZRM8 AO/00, RMO3 PERFORMANCE EXERCISER  
DZRM8A.P11 27-JUL-77 08:04

MACY11 30(1046) 27-JUL-77 08:07 PAGE 32

SEQ 0031

1572  
1573  
1574  
1575  
1576  
1577  
1578  
1579  
1580

'ORDERS' IS THE TOTAL NUMBER OF ORDERS GIVEN TO THE DRIVE WHICH REPORTED THE ERROR.

'TOTAL SEEKS' IS THE TOTAL NUMBER OF SEEK OPERATIONS PERFORMED BY THE DRIVE.

'TOTAL SKI ERR' IS THE TOTAL NUMBER OF 'SKI' ERRORS SIGNALLED BY THE DRIVE.

1581  
1582  
1583  
1584  
1585  
1586  
1587  
1588  
1589  
1590  
1591  
1592  
1593  
1594  
1595  
1596  
1597  
1598  
1599  
1600  
1601  
1602  
1603  
1604  
1605  
1606  
1607  
1608  
1609  
1610  
1611  
1612  
1613  
1614  
1615  
1616  
1617  
1618  
1619  
1620  
1621  
1622  
1623  
1624  
1625  
1626  
1627  
1628  
1629  
1630  
1631  
1632  
1633  
1634  
1635  
1636

8. PROGRAM DESCRIPTION  
-----

8.1 PROGRAM OPERATION

WHEN THE PROGRAM IS STARTED, PROVIDING APT TTY ENABLE BIT IS SET OR DIAGNOSTIC LOADED BY OTHER THAN APT SCRIPT MODE, ALL TABLES AND PARAMETERS ARE CLEARED OR INITIALIZED. THE PARAMETERS WHICH ARE UNDER OPERATOR TTY ENTRY CONTROL ARE CHECKED FOR VALIDITY AND CONSISTENCY. RH11 INTERRUPT ENABLE ('IE') IS SET, TTY KEYBOARD INTERRUPT ENABLE IS SET, AND THE KW11-L OR KW11-P CLOCK IS STARTED. WHEN THESE ACTIONS HAVE BEEN COMPLETED, THE PROGRAM TYPES OUT 'PROGRAM INITIALIZE COMPLETE'. COMMAND ENTRIES WILL NOW BE ACCEPTED BY THE PROGRAM

THE PROGRAM SCANS ITS INTERNAL ASSIGNMENT TABLES, LOOKING FOR:

- 1) DRIVES TO ASSIGN/DEASSIGN
- 2) PERFORMANCE SUMMARY TYPEOUT REQUESTS
- 3) DRIVES REQUIRING COMMAND INITIATION, BUFFER ASSIGNMENT, OR PARAMETER SELECTION.
- 4) DRIVES COMPLETING CURRENT OPERATIONS.

THE PROGRAM CONTINUES SCANNING ITS TABLES UNTIL AN ENTRY IS FOUND. IN THE CASE OF THE PROGRAM AT INITIAL START, THE FIRST ENTRY WILL BE MADE BY THE OPERATOR WHEN A DRIVE IS ASSIGNED ('T' COMMAND).

WHEN A DRIVE IS ASSIGNED, THE KEYBOARD ENTRY ROUTINE VERIFIES THAT THE DRIVE IS PRESENT, IS AN RMO3, AND IS ONLINE. THE ASSIGNMENT ROUTINE THEN ISSUES A 'READIN PRESET' INSTRUCTION, SETS 'FMT22', AND ISSUES A 'RECALIBRATE' INSTRUCTION.

PARAMETERS FOR THE OPERATION ARE SELECTED AND A BUFFER IS ASSIGNED. IF THE OPERATION IS A WRITE OR WRITE CHECK ORDER, THE ASSIGNED BUFFER WILL BE FILLED WITH THE SELECTED PATTERN. (WRITE CHECK ORDERS ARE ISSUED AFTER EACH WRITE ORDER. THE WRITE CHECK ORDER USES THE PARAMETERS SELECTED FOR THE PRECEEDING WRITE ORDER.) CONTROL IS THEN PASSED TO THE COMMAND INITIATION ROUTINE.

THE COMMAND INITIATION ROUTINE FIRST LOOKS AT THE CYLINDER ADDRESS OF THE REQUESTED OPERATION. IF THE DRIVE MUST SEEK TO ANOTHER CYLINDER TO PERFORM THE OPERATION, THE PROGRAM ISSUES A SEARCH INSTRUCTION TO THE DRIVE WITH A 'TARGET' SECTOR WHICH IS 8 SECTORS EARLIER THAN THE 'TRANSFER' SECTOR. (THIS ALLOWS THE PROGRAM TO INITIATE OPERATIONS ON ANOTHER DRIVE WHILE THE PRESENT DRIVE, OR OTHER DRIVES, ARE SEARCHING FOR 'TARGET' SECTORS. ALL SEEKS ISSUED BY THE PROGRAM ARE IMPLIED SEEK SEARCH OPERATIONS.) WHEN A SEARCHING DRIVE FINDS THE 'TARGET' SECTOR AND INTERRUPTS, THE PROGRAM READS THE LOOK AHEAD REGISTER (RMLA) OF THE INTERRUPTING DRIVE AND COMPARES THE POSITION OF THE DISK WITH THAT OF THE DESIRED SECTOR.

IF OTHER DRIVES ARE WAITING ON CYLINDER, THEY ARE ALSO CHECKED. THE PROGRAM THEN ISSUES THE REQUESTED ORDER TO THE DRIVE NEAREST ITS TRANSFER SECTOR. THE DRIVES NOT SELECTED WILL HAVE ANOTHER SEARCH INITIATED. IF A DRIVE IS NOT SELECTED FOR TRANSFER AFTER THREE REVOLUTIONS OF ITS DISK, IT IS GIVEN PRIORITY OVER DRIVES WHICH HAVE

1637  
1638  
1639  
1640  
1641  
1642  
1643  
1644  
1645  
1646  
1647  
1648  
1649  
1650  
1651  
1652  
1653  
1654  
1655  
1656  
1657  
1658  
1659  
1660  
1661  
1662  
1663  
1664  
1665  
1666  
1667  
1668  
1669  
1670  
1671  
1672  
1673  
1674  
1675  
1676  
1677  
1678  
1679  
1680  
1681  
1682  
1683  
1684  
1685  
1686  
1687  
1688  
1689  
1690  
1691  
1692

NOT BEEN ON CYLINDER AS LONG.

WHEN THE DATA TRANSFER OPERATION IS COMPLETE, THE DRIVE REGISTERS ARE STORED AND A DATA TRANSFER IS INITIATED FOR A WAITING DRIVE.

IF THE OPERATION HAS BEEN COMPLETED NORMALLY, THE SAVED DRIVE REGISTERS ARE CHECKED TO VERIFY THAT NO ERROR BITS ARE SET; THE RH11 BUS ADDRESS AND WORD COUNT ADDRESS REGISTERS ARE CHECKED TO VERIFY THAT THE CORRECT NUMBER OF WORDS HAVE BEEN TRANSFERRED AND THAT THE TWO REGISTERS ARE CONSISTENT WITH EACH OTHER; AND IF THE ORDER WAS A READ ORDER, THE DATA BUFFER IS COMPARED. WHEN THIS SEQUENCE IS COMPLETED, THE DRIVE IS RETURNED TO THE ASSIGNED, INACTIVE LIST. THE PROGRAM THEN INITIATES A DATA TRANSFER ON A WAITING DRIVE AND RESELECTS AND REINITIATES ANOTHER OPERATION ON THE RELEASED DRIVE.

ERRORS WHICH OCCUR ARE PROCESSED IN THE FOLLOWING ORDER. MULTIPLE ERRORS WILL BE REPORTED AS THE FIRST ERROR TYPE CHECKED.

A. ERRORS REPORTED FOR OPERATIONS WHICH HAVE NOT COMPLETED NORMALLY.

PERSISTENT UNSAFE CONDITION - EM12  
UNCORRECTABLE MASSBUS PARITY ERROR - EM10  
FATAL MASSBUS PARITY ERROR - EM11  
OPERATION NOT COMPLETED WITHIN TIME LIMIT - EM13  
UNIT WENT OFFLINE - EM14

B. ERRORS REPORTED FOR OPERATIONS WHICH COMPLETE NORMALLY.

CORRECTABLE UNSAFE - EM60  
DRIVE TIMING ERROR - EM32  
DATA CHECK ERROR - EM21  
WRITE CHECK WITH DCK SET - EM22  
HEADER CRC ERRORS - EM20  
FORMAT ERRORS - EM24, EM26  
HEADER COMPARE ERRORS - EM25, EM27  
PROGRAM DETECTED POSITIONING ERROR - EM51  
SEEK INCOMPLETE OR OFF CYLINDER ERROR - EM50  
WRITE CHECK WITHOUT 'DCK' SET - EM23  
RH11 OR UNIBUS TRANSFER ERROR - EM40  
'OPI' ERROR - EM31  
'PAR' ERROR - EM33  
'WCF' ERROR - EM34  
'IAE' ERROR - EM35  
'WLE' ERROR - EM36  
MISCELLANEOUS DRIVE ERROR - EM30

C. ERRORS NOT FLAGGED BY THE HARDWARE ERROR DETECTION LOGIC.

BUS ADDRESS OR WORD COUNT INCORRECT - EM41  
DATA COMPARE ERRORS - NO DRIVE ERROR DETECTED - EM42  
CAN'T MATCH DATA READ WITH A PATTERN - EM43  
ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH11 - EM44  
ECC LOGIC FAILURE - EM45  
BUS ADDRESS OR WORD COUNT NOT CONSISTENT - EM46

1693  
1694  
1695  
1696  
1697  
1698  
1699  
1700  
1701  
1702  
1703  
1704  
1705  
1706  
1707  
1708  
1709  
1710  
1711  
1712  
1713  
1714  
1715  
1716  
1717  
1718  
1719  
1720  
1721  
1722  
1723  
1724  
1725  
1726  
1727  
1728  
1729  
1730  
1731  
1732  
1733  
1734  
1735  
1736  
1737  
1738  
1739  
1740  
1741  
1742  
1743  
1744  
1745  
1746  
1747  
1748

DUAL PORT OPERATION IS NEARLY IDENTICAL TO THE OPERATION DESCRIBED IN SECTION 8.1. THE DIFFERENCES ARE IN COMMAND SEQUENCE INITIATION AND ORDER TERMINATION.

WHEN THE DUAL PORT HANDLER ROUTINE IN THE EXERCISER PROGRAM RECEIVES A REQUEST FOR A DRIVE, THE PROGRAM VERIFIES THAT THE DRIVE IS ONLINE. THE DRIVE IS SELECTED AND READ THE RMCS1 REGISTER BY TEST THE "DVA" BIT.

IF THE DRIVE IS IN NEUTRAL, THIS WILL SEIZE THE DRIVE. IF THE DRIVE IS SEIZED BY THE OTHER PORT, READING 'RMD51' WILL SET 'PORT REQUEST'. THE PROGRAM CHECKS 'DVA' IN 'RMCS1'. IF THE DRIVE IS AVAILABLE AS INDICATED BY THE 'DVA' BIT, THE COMMAND SEQUENCE WILL BE INITIATED IN THE NORMAL MANNER (SEE SECTION 8.1 ABOVE). IF 'DVA' WAS NOT SET, THE PROGRAM MAKES AN ENTRY FOR THE DRIVE IN AN INTERNAL 'PORT REQUEST PENDING' TABLE AND STARTS A 10 SECOND TIMER FOR THE DRIVE. IF THE DRIVE HAS NOT SWITCHED TO THE REQUESTING SYSTEM WITHIN THE 10 SECOND INTERVAL, THE PROGRAM REPORTS A 'NO RESPONSE TO PORT REQUEST' ERROR. NORMALLY THIS ERROR MESSAGE INDICATES A FAILURE IN THE DUAL PORT CONTROL LOGIC IN THE DRIVE BEING TESTED; HOWEVER, UNDER CERTAIN CONDITIONS (E.G. MASSBUS PARITY ERRORS BEING REPORTED ON THE OTHER SYSTEM ON A MOD33 TTY), THE OTHER PROCESSOR WAS UNABLE TO PROCESS THE DRIVE AFTER IT HAD REQUESTED THE DRIVE. THE OPERATOR MUST BE AWARE OF WHAT THE OTHER SYSTEM IS DOING AT ALL TIMES TO INTERPRET THE PORT RELATED ERROR MESSAGES PROPERLY.

AFTER A DRIVE HAS COMPLETED AN OPERATION, THE PROGRAM WILL STORE THE REGISTERS AND ISSUE A 'RELEASE' TO THE DRIVE; IF THE OPERATION TERMINATED WITH AN ERROR, THE DRIVE WILL NOT BE RELEASED UNTIL ERROR PROCESSING HAS BEEN COMPLETED.

SINGLE PORT DRIVES, DRIVES WHICH ARE IN NEUTRAL BUT NOT BEING EXERCISED BY THE OPPOSITE PORT ARE STILL TREATED AS DUAL PORT DRIVES IN THAT A RELEASE COMMAND IS ISSUED AT THE END OF NORMAL ORDER PROCESSING OR AT THE END OF ERROR PROCESSING. A RELEASE COMMAND ISSUED UNDER THESE CONDITIONS HAS NO FUNCTIONAL EFFECT ON THE OPERATION OF THE DRIVE.

### 8.3 SELECTION OF OPERATION VARIABLES

- A. SECTOR ADDRESS SELECTION IS RANDOM BETWEEN THE VALUES IN 'MINSEC' AND 'MAXSEC'. TRACK ADDRESS SELECTION IS RANDOM BETWEEN THE VALUES IN 'MINTRK' AND 'MAXTRK'. CYLINDER ADDRESS SELECTION IS RANDOM BETWEEN 'MINCYL' AND 'MAXCYL'. IF A MINIMUM ADDRESS IS GREATER THAN THE CORRESPONDING MAXIMUM ADDRESS, THE PROGRAM WILL EXCLUDE ALL ADDRESSES BETWEEN 'MAX' AND 'MIN' FROM THE SELECTION. FOR EXAMPLE: IF 'MINTRK' IS 5 AND 'MAXTRK' IS 2, THEN TRACK ADDRESS SELECTION WILL EXCLUDE TRACKS 3 - 4 FROM THE SELECTION AND SELECT AN ADDRESS FROM AMONG ADDRESSES 5, 0, 1, 2.
- B. THE BUFFER SIZE IS RANDOM SELECTED BETWEEN 4 - AND THE VALUE IN 'SIZE'. THE SIZE SELECTED IS WEIGHTED TO ENSURE THIS IS NECESSARY AS THE PROGRAM REQUIRES 4 LOCATIONS IN THE DATA PORTION OF THE SECTOR TO BE ABLE TO MATCH THE DATA

1749  
1750  
1751  
1752  
1753  
1754  
1755  
1756  
1757  
1758  
1759  
1760  
1761  
1762  
1763  
1764  
1765  
1766  
1767  
1768  
1769  
1770  
1771  
1772  
1773  
1774  
1775  
1776  
1777  
1778  
1779  
1780  
1781  
1782  
1783  
1784  
1785  
1786  
1787  
1788  
1789  
1790  
1791  
1792  
1793  
1794  
1795  
1796  
1797  
1798  
1799  
1800  
1801  
1802  
1803  
1804

TO A PATTERN FOR DATA COMPARISON PURPOSES.

- C. THE DATA WRITTEN IS RANDOMLY SELECTED AMONG THE 15 STANDARD PATTERNS. THE PARAMETER "PATTERN" ENABLES THE RANDOM PATTERN SELECTION, IF THIS PARAMETER IS 0; OTHERWISE, THE DATA PATTERN INDEXED BY THE VALUE "PATTERN" IS SELECTED.
- D. THE ORDERS ARE SELECTED RANDOMLY. WRITE CHECK DATA AND WRITE CHECK HEADER & DATA ORDERS ARE PERFORMED ONLY IF THE PREVIOUS ORDER WAS THE APPROPRIATE DATA ORDER. IF THE 'FORMAT' PARAMETER IS ZERO, THE PROGRAM WILL NOT SELECT WRITE HEADER & DATA (AND WRITE CHECK HEADER & DATA) ORDERS. WHEN THE PROGRAM SELECTS A WRITE HEADER & DATA ORDER, THE BUFFER SIZE IS FORCED TO 258 (10); THE PROGRAM WILL NOT PERFORM A MULTI-SECTOR FORMAT WRITE OPERATION.
- E. THE FIRST ORDER PERFORMED AFTER A UNIT IS ASSIGNED WITH A 'W' OR 'R' COMMAND IS NOT RANDOMLY SELECTED. THE PARAMETERS FOR THE FIRST OPERATION ARE THE MINIMUM OR STARTING VALUES OF THE VARIABLES.

8.4 DATA PATTERNS

THE PROGRAM SELECTS ONE OF THE FOLLOWING DATA PATTERNS TO WRITE WHEN A WRITE ORDER IS SELECTED. THE ENTIRE BUFFER IS FILLED WITH THE SELECTED PATTERN. WHEN DATA IS READ FROM THE DISK, THE PROGRAM COMPARES DATA ON A SECTOR BASIS: FROM THE FIRST 4 DATA WORDS OF EACH SECTOR, THE PROGRAM MATCHES THE DATA TO ONE OF THE FOLLOWING PATTERNS.

PAT 1	PAT 2	PAT 3	PAT 4	PAT 5	PAT 6	PAT 7	PAT 8
000001	177776	000000	133331	052525	155554	026455	066666
000003	177774	000000	133331	052525	155554	026455	066666
000007	177770	000000	133331	052525	155554	026455	066666
000017	177760	177777	133331	125252	155554	151322	066666
000037	177740	177777	133331	125252	155554	151322	066666
000077	177700	177777	133331	125252	155554	151322	066666
000177	177600	000000	133331	052525	155554	026455	066666
000377	177400	000000	133331	052525	155554	026455	066666
000777	177000	177777	133331	125252	155554	151322	066666
001777	176000	177777	133331	125252	155554	151322	066666
003777	174000	000000	133331	052525	155554	026455	066666
007777	170000	177777	133331	125252	155554	151322	066666
017777	160000	000000	133331	052525	155554	026455	066666
037777	140000	177777	133331	125252	155554	151322	066666
077777	100000	000000	133331	052525	155554	026455	066666
177777	000000	177777	133331	125252	155554	151322	066666
PAT 9	PAT 10	PAT 11	PAT 12	PAT 13	PAT 14	PAT 15	
000001	177776	172666	077777	153333	000000	177777	
000002	177775	155555	137777	066667	177777	000000	
000004	177773	172666	157777	153333	177777	000000	
000010	177767	155555	167777	066667	177777	000000	

L03

MD-11-DZRMBA AO/00, RMO3 PERFORMANCE EXERCISER  
DZRMBA.P11 27-JUL-77 08:04

MACY11 30(1046) 27-JUL-77 08:07 PAGE 37

SEQ 0036

1805	000020	177757	172666	173777	153333	177777	000000
1806	000040	177737	155555	175777	066667	177777	000000
1807	000100	177677	172666	176777	153333	177777	000000
1808	000200	177577	155555	177377	066667	177777	000000
1809	000400	177377	172666	177577	153333	177777	000000
1810	001000	176777	155555	177677	066667	177777	000000
1811	002000	175777	172666	177737	153333	177777	000000
1812	004000	173777	155555	177757	066667	177777	000000
1813	010000	167777	172666	177767	153333	177777	000000
1814	020000	157777	155555	177773	066667	177777	000000
1815	040000	137777	172666	177775	153333	177777	000000
1816	100000	077777	155555	177776	066667	177777	000000

1817  
1818  
1819  
1820  
1821  
1822  
1823  
1824  
1825  
1826  
1827  
1828  
1829  
1830  
1831  
1832  
1833  
1834  
1835  
1836  
1837  
1838  
1839  
1840  
1841  
1842  
1843  
1844  
1845  
1846  
1847  
1848  
1849  
1850  
1851  
1852  
1853  
1854  
1855  
1856  
1857  
1858  
1859  
1860  
1861  
1862  
1863  
1864  
1865  
1866  
1867  
1868  
1869  
1870  
1871  
18729.1 RH70(11)/RMO3 DRIVER

THIS DOCUMENT IS THE USER'S GUIDE FOR THE RH70/RMO3 DRIVER.

## 9.2 TO INITIALIZE THE DRIVER:

```

      JSR    PC,RMINIT
      RETURN

```

UPON RETURN YOU MUST EXAMINE THE "DRVSTA" TABLE TO DETERMINE THE DRIVES THAT ARE ONLINE FOR TESTING. THE 'DRVSTA' TABLE IS EIGHT BYTES; ONE BYTE PER DRIVE. THE STATE OF EACH DRIVE WILL BE INDICATED AS FOLLOWS:

DRVSTA	DRIVE STATE
-----	-----
>0	ONLINE RMO3
=0	OFFLINE RMO3, DRIVE IS NOT AN RMO3, OR NONEXISTENT DRIVE
<0	UNSAFE RMO3

THE DRIVE TYPE IS DEFINED IN AN 8 BYTE LONG TABLE TAGGED 'DRVTYP'. THE TABLE CONTAINS ONE BYTE FOR EACH DRIVE AND IS INDEXED BY THE DRIVE NUMBER. ENTRIES ARE ENCODED AS FOLLOWS:

DRVTYP	CONDITION
-----	-----
0	NONEXISTENT DRIVE
4	RMO3
-1	NOT AN RMO3

THE 'RMINIT' ROUTINE WILL DO A READIN PRESET AND WILL SET FMT22.

## 9.3 AFTER THE DRIVER HAS BEEN INITIALIZED, IT IS CALLED USING THE FOLLOWING SEQUENCE.

CALL:

```

      JSR    RO,RMO3          ;MAKE THE CALL
      PNTDPB          ;ADDRESS OF DPB*
      RETURN1         ;RETURN IF QUEUE IS FULL
      RETURN2         ;RETURN IF REQUEST IS IN
                        ;QUEUE OR THERE IS AN
                        ;ERROR CONDITION

```

\*DPB (DATA PARAMETER BLOCK)

```

PNTDPB: .BYTE 0          ;(0) DRIVE NUMBER
        .BYTE 0          ;(1) OFFSET VALUE OF FMT22, ECT, AND HCI
        .BYTE 0          ;(2) COMMAND
        .BYTE 0          ;(3) PSEL AND A17 AND A16
        .WORD 0          ;(4) WORD COUNT (MUST BE NEG.)

```



1873	.WORD	0	;(6) BUFFER ADDRESS OR
1874			;REGISTER TABLE POINTER
1875	.BYTE	0	;(10) SECTOR ADDRESS OR
1876			;FIRST REG. INDEX
1877	.BYTE	0	;(11) TRACK ADDRESS OR
1878			;LAST REG. INDEX
1879	.WORD	0	;(12) CYLINDER ADDRESS
1880	.WORD	0	;(14) ERROR TABLE POINTER
1881			;POINTS TO THE FIRST OF TWENTY
1882			;LOCATIONS OF WHERE THE DRIVER
1883			;IS TO STORE THE RM70/RM03
1884			;REGISTERS ON AN ERROR. IF LEFT
1885			;ZERO REGISTERS ARE NOT SAVED.
1886	.WORD	0	;(16) STATUS/ERROR INDICATOR
1887			;BIT15=1=>ERROR OCCURRED
1888			;BIT07=1=>DONE
1889			;BIT14-BIT09 AND BIT06-BIT03
1890			;INDICATE TYPE OF ERROR

9.4 THE DRIVER PROVIDES A SOFTWARE TIMEOUT CAPABILITY.  
TO UTILIZE THIS CAPABILITY YOU MUST SUPPLY THE "RM TIMER" ROUTINE  
WITH THE ELAPSED TIME IN THE FOLLOWING MANNER:

```

MOV    #16.,-(SP)    ;16 MILLISECONDS BETWEEN
                    ;CLOCK TICKS
JSR    PC,RMTMR     ;CALL THE TIMER ROUTINE
    
```

IT SHOULD BE NOTED THAT YOU MUST PROVIDE THE CODE TO DRIVE THE  
CLOCK. AND THE ELAPSED TIME MUST BE IN MILLISECONDS.  
THE DRIVER WILL SET THE TIMEOUT TO 1 SECOND FOR ALL POSITIONING  
AND DATA TRANSFER OPERATIONS AND WILL SET THE TIMOUT TO 30  
SECONDS FOR ERROR RECOVERY OPERATIONS.

9.4.1 EXAMPLE - WRITE 1000. WORDS

```

1$:    JSR    RO,RM03    ;CALL THE DRIVER
        WRTDPB    ;DPB ADDRESS
        BR      1$      ;WAIT FOR QUEUE IF FULL
2$:    TST    WRTDPB+16  ;WAIT FOR COMMAND TO COMPLETE
        BEQ    2$
        BMI    ERROR1   ;ERROR OCCURRED
        .
        .
        .
    
```

```

WRTDPB: .BYTE    5      ;DRIVE #5
        .BYTE    0
        .BYTE    161   ;WRITE COMMAND
        .BYTE    0
        .WORD    -1000. ;WORD COUNT
        .WORD    WRTBUF ;BUFFER ADDRESS
        .BYTE    3     ;SECTOR
        .BYTE    5     ;TRACK
        .WORD    400   ;CYLINDER
        .WORD    ERRTB5 ;ERROR TABLE
    
```

1873  
1874  
1875  
1876  
1877  
1878  
1879  
1880  
1881  
1882  
1883  
1884  
1885  
1886  
1887  
1888  
1889  
1890  
1891  
1892  
1893  
1894  
1895  
1896  
1897  
1898  
1899  
1900  
1901  
1902  
1903  
1904  
1905  
1906  
1907  
1908  
1909  
1910  
1911  
1912  
1913  
1914  
1915  
1916  
1917  
1918  
1919  
1920  
1921  
1922  
1923  
1924  
1925  
1926  
1927  
1928

1929  
1930  
1931  
1932  
1933  
1934  
1935  
1936  
1937  
1938  
1939  
1940  
1941  
1942  
1943  
1944  
1945  
1946  
1947  
1948  
1949  
1950  
1951  
1952  
1953  
1954  
1955  
1956  
1957  
1958  
1959  
1960  
1961  
1962  
1963  
1964  
1965  
1966  
1967  
1968  
1969  
1970  
1971  
1972  
1973  
1974  
1975  
1976  
1977  
1978  
1979  
1980  
1981  
1982  
1983  
1984

.WORD 0 ;STATUS/ERROR INDICATOR

ALTERNATE DPB SETUP

WRTDPB: .WORD 5 ; THIS SETUP ACHIEVED  
 .WORD WRITE ; EVERYTHING THE  
 .WORD -1000. ; ABOVE TABLE DID, BUT  
 .WORD WRTBUF ; IN A CLEANER FORMAT  
 .BYTE 3,5  
 .WORD 400,ERRTBS,0

9.5 RH70/RM03 REGISTERS

MNEMONIC	INDEX
RMCS1	0
RMWC	2
RMBR	4
RMDR	6
RMCS2	10
RMDS	12
RMR1	14
RMR2	16
RMLA	20
RMDR	22
RMMR1	24
RMDT	26
RMSN	30
RMOF	32
RMDC	34
RMHR	36
RMMR2	40
RMR2	42
RMEC1	44
RMEC2	46

9.6 COMMANDS PERFORMED BY THE DRIVER

COMMAND	CODE	COMMAND TYPE
NO OPERATION	101	N
UNLOAD	103	N
SEEK	105	P
RECALIRATE	107	P
DRIVE CLEAR	111	N
RELEASE	113	N
OFFSET	115	P

1985  
1986  
1987  
1988  
1989  
1990  
1991  
1992  
1993  
1994  
1995  
1996  
1997  
1998  
1999  
2000  
2001  
2002  
2003  
2004  
2005  
2006  
2007  
2008  
2009  
2010  
2011  
2012  
2013  
2014  
2015  
2016  
2017  
2018  
2019  
2020  
2021  
2022  
2023  
2024  
2025  
2026  
2027  
2028  
2029  
2030  
2031  
2032  
2033  
2034  
2035  
2036  
2037  
2038  
2039  
2040

RETURN TO CENTER	117	P
READIN PRESET	121	N
PACK ACKNOWLEDGE	123	N
SEARCH	131	P
GET REGISTER(S)	141	S
SET FORMAT	143	S
SELECT DRIVE	145	S
WRITE CHECK DATA	151	D
WRITE CHECK HEADER AND DATA	153	D
WRITE DATA	161	D
WRITE HEADER & DATA	163	D
READ DATA	171	D
READ HEADER & DATA	173	D

N = HOUSEKEEPING  
P = POSITIONING  
D = DATA TRANSFER  
S = SPECIAL PROVIDED BY THE DRIVER

9.7 DPB STATUS/ERROR INDICATOR WORD

THIS INDICATOR WILL INFORM THE USER OF THE RESULTS OF THE REQUEST.  
THIS IS ACCOMPLISHED BY SETTING VARIES BITS OF THE INDICATOR TO  
A ONE.

<u>BIT NO.</u>	<u>MEANING IF ON A "1"</u>
15	ERROR OCCURRED DONE (BIT07=0); BITS 14-10 SPECIFIES TYPE DONE (BIT07=1); BITS 06-03 SPECIFIES TYPE
14(1)	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON AN OFFLINE OR UNSAFE DRIVE
13(1)	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON A DRIVE THAT HAS AN UNLOAD REQUEST IN QUEUE.
12(2)	PERSISTENT UNSAFE CONDITION EXIST.
11(2)	UNCORRECTABLE PARITY ERROR OCCURRED

2041		
2042		
2043	10(2)(4)	FATAL PARITY ERROR. A MASSBUS CLEAR WAS PERFORMED, ALL QUEUES WERE EMPTIED, AND ALL DRVACT'S SET TO THE IDLE STATE
2044		
2045		
2046	9(3)(4)	SOFTWARE TIMEOUT OCCURRED ON THIS DRIVE
2047		
2048	8(4)	SOFTWARE TIMEOUT OCCURRED ON ANOTHER DRIVE
2049		
2050	7	DONE
2051		
2052	6(2)	ERROR OCCURRED DURING AN I/O OPERATION
2053		
2054	5(2)	ERROR OCCURRED DURING AN OPERATION OTHER THAN I/O.
2055		
2056		
2057	4(2)	CORRECTABLE UNSAFE CONDITION OCCURRED
2058		
2059	3(2)	DRIVE ERROR OCCURRED THAT CAUSED AN AUTOMATIC "RECALIBRATE" SEQUENCE
2060		
2061		
2062	2	PORT REQUEST TIMEOUT. THE DRIVER REQUESTED THE DRIVE BUT THE OPPOSITE PORT DID NOT RELEASE THE DRIVE WITHIN 20 SECONDS.
2063		
2064		
2065		
2066	1	NON-EXISTENT DRIVE REQUESTED. USER MADE A REQUEST FOR A NON-EXISTENT DRIVE.
2067		
2068		
2069	(1) =>	REQUEST WASN'T PUT IN QUEUE. (RH70/RMD3 REGISTERS WERE NOT SAVED)
2070		
2071		
2072	(2) =>	REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A "DRIVE CLEAR" TO THE DRIVE. NOTE: ALL RH70/RMD3 REGISTERS ARE SAVED AS PER DPB+14 BEFORE THE "DRIVE CLEAR".
2073		
2074		
2075		
2076		
2077	(3) =>	REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A MASSBUS INIT. ALL RH70/RMD3 REGISTERS FOR THE DRIVE WERE SAVED AS PER DPB+14 BEFORE THE INIT.
2078		
2079		
2080		
2081		
2082	(4) =>	A "RECALIBRATE" SHOULD BE ISSUED BEFORE ANY OTHER COMMAND.

9.8 ERROR CALLS MADE BY THE DRIVER.

THERE ARE A FEW ERRORS THAT CAN OCCUR THAT CAN NOT BE INDICATED IN A DPB.

WHEN THIS TYPE OF ERROR IS DETECTED BY THE DRIVER IT WILL MAKE AN ERROR CALL OF THE FORM "ERROR N", WHERE "N" IS THE ERROR NUMBER AND THE ERROR WILL BE AN EMT INSTRUCTION.

N	TYPE	DATA AVAILABLE
-	----	-----

2096

2097  
2098  
2099  
2100  
2101  
2102  
2103  
2104  
2105  
2106  
2107  
2108  
2109  
2110  
2111  
2112  
2113  
2114  
2115  
2116  
2117  
2118  
2119  
2120  
2121  
2122  
2123  
2124  
2125  
2126  
2127

1 RH70 INTERRUPT OCCURRED (RHAS=0) \*R4= RMCS1'S ADDRESS

2 UNEXPECTED ATTENTION OCCURRED  
R1= DRIVE NUMBER  
R3= ATA BIT  
\*R4= RMCS1'S ADDRESS  
R5= (RMAS)  
RMERRS =RMDS  
RMERRS+2=RMER1  
RMERRS+4=RMER2  
RMERRS+6=RMMR2

3 MASSBUS PARITY ERROR (MCPE=1) RD.ADR= ADDRESS OF REG. READ  
RD.WRD= WORD READ

4 MASSBUS PARITY ERROR (PAR=1) WRT.AD= ADDRESS OF REG. WRITTEN  
WRT.WD= WORD WRITTEN  
RD.WRD= WORD READ BACK

5 ADDRESS PLUG CHANGE BIT SET ('OPE' ERROR)  
R1= DRIVE NUMBER  
R3= ATA BIT  
\*R4= RMCS1'S ADDRESS  
R5= (RMAS)  
RMERRS =RMDS  
RMERRS+2=RMER1  
RMERRS+4=RMER2  
RMERRS+6=RMMR2

\* THIS IS THE ACTUAL UNIBUS ADDRESS (176700)

2

```

2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182
2183

```

```

.TITLE MD-11-DZRMBA AO/00, RMO3 PERFORMANCE EXERCISER
;*COPYRIGHT (C) 1976
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*PROGRAM BY C. CHEN
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
;*
.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;*      SWITCH          USE
;*      -----          -
;*      15             HALT ON ERROR
;*      13             INHIBIT ERROR TYPEOUTS
;*      10             BELL ON ERROR
;*      7              DISPLAY ALL DATA COMPARE ERRORS
;*      6              DON'T CHANGE PARAMETERS (LOOP ON PRESENT VALUES)
;*      5              A. PARTIAL REGISTER DISPLAY IF ERROR
;*                   B. NO ECC CORRECTION RESULTS DISPLAYED IF ERROR
;*      4              A. DO NOT CHECK FOR MAXIMUM ERROR COUNTS
;*                   B. DO NOT DROP DRIVE WHEN NORMAL END OF TEST REACHED
;*      3              A. DISPLAY ERROR SECTOR IF 'DCK' 'DTE' OR 'WCF' ERROR
;*                   B. DISPLAY SECTOR IF 'DCK' ERR UNCORRECTABLE AFTER
;*                      28TH RETRY
;*      C. IF DATA COMPARE ERROR & SW7 SET, DISPLAY
;*         REMAINDER OF BUFFER
;*      2              A. DON'T TYPE SUBSYSTEM STATUS WHEN PROGRAM STARTED
;*                   B. DON'T TYPE PERFORMANCE SUMMARY
;*      1              INHIBIT DATA COMPARISON AFTER READ ORDERS
;*      0              READ ONLY MODE
.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
.EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL

;*MISCELLANEOUS DEFINITIONS
HT= 11                ;;CODE FOR HORIZONTAL TAB
LF= 12                ;;CODE FOR LINE FEED
CR= 15                ;;CODE FOR CARRIAGE RETURN
CRLF= 200             ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776           ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLMT= 177774        ;;STACK LIMIT REGISTER
PIRQ= 177772          ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570          ;;HARDWARE SWITCH REGISTER
DDISP= 177570         ;;HARDWARE DISPLAY REGISTER

;*GENERAL PURPOSE REGISTER DEFINITIONS
R0= %0                ;;GENERAL REGISTER
R1= %1                ;;GENERAL REGISTER
R2= %2                ;;GENERAL REGISTER

```

2184	000003	R3=	%3	::	GENERAL REGISTER
2185	000004	R4=	%4	::	GENERAL REGISTER
2186	000005	R5=	%5	::	GENERAL REGISTER
2187	000006	R6=	%6	::	GENERAL REGISTER
2188	000007	R7=	%7	::	GENERAL REGISTER
2189	000006	SP=	%6	::	STACK POINTER
2190	000007	PC=	%7	::	PROGRAM COUNTER

```

: *PRIORITY LEVEL DEFINITIONS
2193 000000 PR0= 0 :: PRIORITY LEVEL 0
2194 000040 PR1= 40 :: PRIORITY LEVEL 1
2195 000100 PR2= 100 :: PRIORITY LEVEL 2
2196 000140 PR3= 140 :: PRIORITY LEVEL 3
2197 000200 PR4= 200 :: PRIORITY LEVEL 4
2198 000240 PR5= 240 :: PRIORITY LEVEL 5
2199 000300 PR6= 300 :: PRIORITY LEVEL 6
2200 000340 PR7= 340 :: PRIORITY LEVEL 7

```

```

: * "SWITCH REGISTER" SWITCH DEFINITIONS
2203 100000 SW15= 100000
2204 040000 SW14= 40000
2205 020000 SW13= 20000
2206 010000 SW12= 10000
2207 004000 SW11= 4000
2208 002000 SW10= 2000
2209 001000 SW09= 1000
2210 000400 SW08= 400
2211 000200 SW07= 200
2212 000100 SW06= 100
2213 000040 SW05= 40
2214 000020 SW04= 20
2215 000010 SW03= 10
2216 000004 SW02= 4
2217 000002 SW01= 2
2218 000001 SW00= 1
2219 .EQUIV SW09, SW9
2220 .EQUIV SW08, SW8
2221 .EQUIV SW07, SW7
2222 .EQUIV SW06, SW6
2223 .EQUIV SW05, SW5
2224 .EQUIV SW04, SW4
2225 .EQUIV SW03, SW3
2226 .EQUIV SW02, SW2
2227 .EQUIV SW01, SW1
2228 .EQUIV SW00, SW0

```

```

: * DATA BIT DEFINITIONS (BIT00 TO BIT15)
2230
2231 100000 BIT15= 100000
2232 040000 BIT14= 40000
2233 020000 BIT13= 20000
2234 010000 BIT12= 10000
2235 004000 BIT11= 4000
2236 002000 BIT10= 2000
2237 001000 BIT09= 1000
2238 000400 BIT08= 400
2239 000200 BIT07= 200

```

2240 000100  
2241 000040  
2242 000020  
2243 000010  
2244 000004  
2245 000002  
2246 000001

BIT06= 100  
BIT05= 40  
BIT04= 20  
BIT03= 10  
BIT02= 4  
BIT01= 2  
BIT00= 1  
.EQUIV BIT09,BIT9  
.EQUIV BIT08,BIT8  
.EQUIV BIT07,BIT7  
.EQUIV BIT06,BIT6  
.EQUIV BIT05,BIT5  
.EQUIV BIT04,BIT4  
.EQUIV BIT03,BIT3  
.EQUIV BIT02,BIT2  
.EQUIV BIT01,BIT1  
.EQUIV BIT00,BIT0

2258  
2259 000004  
2260 000010  
2261 000014  
2262 000014  
2263 000014  
2264 000020  
2265 000024  
2266 000030  
2267 000034  
2268 000060  
2269 000064  
2270 000240  
2271 176700  
2272 000254

.\*BASIC "CPU" TRAP VECTOR ADDRESSES  
ERRVEC= 4 ;: TIME OUT AND OTHER ERRORS  
RESVEC= 10 ;: RESERVED AND ILLEGAL INSTRUCTIONS  
TBITVEC=14 ;: "T" BIT  
TRTVEC= 14 ;: TRACE TRAP  
BPTVEC= 14 ;: BREAKPOINT TRAP (BPT)  
IOTVEC= 20 ;: INPUT/OUTPUT TRAP (IOT) \*\*SCOPE\*\*  
PWRVEC= 24 ;: POWER FAIL  
EMTVEC= 30 ;: EMULATOR TRAP (EMT) \*\*ERROR\*\*  
TRAPVEC=34 ;: "TRAP" TRAP  
TKVEC= 60 ;: TTY KEYBOARD VECTOR  
TPVEC= 64 ;: TTY PRINTER VECTOR  
PIRQVEC=240 ;: PROGRAM INTERRUPT REQUEST VECTOR  
ABASE=176700  
AVECT1=254

2273  
2274  
2275

;;\*\*\*\*\*

2276

.SBTTL RM03 REGISTERS

2277  
2278

;;\*\*\*\*\*

2280

;CONTROL AND STATUS REGISTER 1 (RMCS1)

2281  
2282 000100  
2283 000200  
2284 000400  
2285 001000  
2286 002000  
2287 020000  
2288 040000

IE= 100 ;: INTERRUPT ENABLE (BIT #6)  
RDY= 200 ;: READY (BIT #7)  
A16= 400 ;: HIGH ORDER BUS ADDRESS BIT (BIT #8)  
A17= 1000 ;: HIGH ORDER BUS ADDRESS BIT (BIT #9)  
PSEL= 2000 ;: PORT SELECT (BIT #10)  
MCPE= 20000 ;: MASSBUSS PARITY ERROR (BIT #13)  
TRE= 40000 ;: TRANSFER ERROR (BIT #14)  
;SC= 100000 ;: SPECIAL CONDITION (BIT #15)

2289  
2290

;WORD COUNT REGISTER (RMWC)  
;(EACH BIT IS CALLED BY BIT NUMBER)

2291  
2292

;BUS ADDRESS REGISTER (RMBA)  
;(EACH BIT IS CALLED BY BIT NUMBER)

2293  
2294  
2295



```

2296
2297
2298
2299          000001      US1=      1          ;UNIT SELECT (BIT #0)
2300          000002      US2=      2          ;UNIT SELECT (BIT #1)
2301          000004      US4=      4          ;UNIT SELECT (BIT #2)
2302          000010      BAI=     10          ;BUS ADDRESS INCREMENT INHIBIT (BIT #3)
2303          000020      PAT=     20          ;MASSBUS PARITY TEST (BIT #4)
2304          000040      CLR=     40          ;CLEAR (BIT #5)
2305          000100      IR=     100         ;INPUT READY (BIT #6)
2306          000200      OR=     200         ;OUTPUT READY (BIT #7)
2307          000400      MDPE=   400         ;MASS BUS PARITY ERROR (BIT #8)
2308          001000      MXF=   1000        ;MISSED TRANSFER ERROR (BIT #9)
2309          002000      PGE=   2000        ;PROGRAM ERROR (BIT #10)
2310          004000      NEM=   4000        ;NON EXISTENT MEMORY (BIT #11)
2311          010000      NED=  10000       ;NON EXISTENT DRIVE (BIT #12)
2312          020000      UPE=  20000       ;UNIBUS PARITY ERROR (BIT #13)
2313          040000      WCE=  40000       ;WRITE CHECK ERROR (BIT #14)
2314          100000      DLT= 100000       ;DATA LATE (BIT #15)
2315
2316          ;DATA BUFFER REGISTER (RMD8)
2317          ;(EACH BIT IS CALLED BY BIT NUMBER)
2318
2319
2320          ;;*****
2321
2322          .SBTTL  RMO3 REGISTERS
2323
2324          ;;*****
2325
2326          ;CONTROL AND STATUS 1 REGISTER. (#00)
2327
2328          000001      GO=       1          ;GO BIT (BIT #0)
2329          000002      FO=       2          ;FUNCTION CODE BIT #1
2330          000004      F1=       4          ;FUNCTION CODE BIT #2
2331          000010      F2=      10          ;FUNCTION CODE BIT #3
2332          000020      F3=      20          ;FUNCTION CODE BIT #4
2333          000040      F4=      40          ;FUNCTION CODE BIT #5
2334          004000      DVA=   4000        ;DEVICE AVAILABLE (BIT #11)
2335
2336          ;DRIVE STATUS REGISTER (RMD51) (#01)
2337
2338          000001      OFFON=   1          ;OFFSET ON (BIT #0)
2339          000100      VV=     100         ;VOLUME VALID (BIT #6)
2340          000200      DRY=     200         ;DRIVE READY (BIT #7)
2341          000400      DPR=     400         ;DRIVE PRESENT (BIT #8)
2342          001000      PGM=    1000        ;PROGRAMABLE (BIT #9)
2343          002000      LBT=    2000        ;LAST SECTOR TRANSFERRED (BIT #10)
2344          004000      WRL=    4000        ;WRITE LOCK (BIT #11)
2345          010000      MOL=   10000       ;MEDIUM ON-LINE (BIT #12)
2346          020000      PIP=   20000       ;POSITIONING OPERATION IN PROGRESS (BIT #13)
2347          040000      ERR=   40000       ;COMPOSITE ERROR (BIT #14)
2348          100000      ATA=  100000       ;ATTENTION ACTIVE (BIT #15)
2349
2350          ;ERROR REGISTER #01 (RMER1) (#02)
2351
  
```

2352	000001	ILF=	1	; ILLEGAL FUNCTION (BIT #0)
2353	000002	ILR=	2	; ILLEGAL REGISTER (BIT #1)
2354	000004	RMR=	4	; REGISTER MODIFICATION REFUSED (BIT #2)
2355	000010	PAR=	10	; PARITY ERROR (BIT #3)
2356	000020	FER=	20	; FORMAT ERROR (BIT #4)
2357	000040	WCF=	40	; WRITE CLOCK FAIL (BIT #5)
2358	000100	ECH=	100	; ECC HARD ERROR (BIT #6)
2359	000200	HCE=	200	; HEADER COMPARE ERROR (BIT #7)
2360	000400	HCRC=	400	; HEADER CRC ERROR (BIT #8)
2361	001000	AOE=	1000	; ADDRESS OVERFLOW ERROR (BIT #9)
2362	002000	IAE=	2000	; INVALID ADDRESS ERROR (BIT #10)
2363	004000	WLE=	4000	; WRITE LOCK ERROR (BIT #11)
2364	010000	DTE=	10000	; DRIVE TIMING ERROR (BIT #12)
2365	020000	OPI=	20000	; OPERATION INCOMPLETE (BIT #13)
2366	040000	UNS=	40000	; DRIVE UNSAFE (BIT #14)
2367	100000	DCK=	100000	; DATA CHECK ERROR (BIT 15)

; MAINTAINABILITY REGISTER (RMMR1) (#03)

2368  
2369  
2370  
2371  
2372  
2373

; ATTENTION SUMMARY PSEUDO-REGISTER (RMAS) (#04)

2374	000001	AT0=	1	; DEVICE 0 (BIT #0)
2375	000002	AT1=	2	; DEVICE 1 (BIT #1)
2376	000004	AT2=	4	; DEVICE 2 (BIT #2)
2377	000010	AT3=	10	; DEVICE 3 (BIT #3)
2378	000020	AT4=	20	; DEVICE 4 (BIT #4)
2379	000040	AT5=	40	; DEVICE 5 (BIT #5)
2380	000100	AT6=	100	; DEVICE 6 (BIT #6)
2381	000200	AT7=	200	; DEVICE 7 (BIT #7)

; DESIRED SECTOR/TRACK ADDRESS REGISTER (RMDA) (#05)

2382  
2383  
2384  
2385  
2386  
2387

; DRIVE TYPE REGISTER (RMDT) (#06)

2388	000001	DT00=	1	; DRIVE TYPE NUMBER BIT 1
2389	000002	DT01=	2	; DRIVE TYPE NUMBER BIT 2
2390	000004	DT02=	4	; DRIVE TYPE NUMBER BIT 3
2391	000010	DT03=	10	; DRIVE TYPE NUMBER BIT 4
2392	000020	DT04=	20	; DRIVE TYPE NUMBER BIT 5
2393	000040	DT05=	40	; DRIVE TYPE NUMBER BIT 6
2394	000100	DT06=	100	; DRIVE TYPE NUMBER BIT 7
2395	000200	DT07=	200	; DRIVE TYPE NUMBER BIT 8
2396	000400	DT08=	400	; DRIVE TYPE NUMBER BIT 9
2397	004000	DRQ=	4000	; DRIVE REQUEST REQUIRED (BIT #11)
2398	020000	MOH=	20000	; MOVING HEAD (BIT #13)
2399	040000	TAP=	40000	; TAPE DRIVE (BIT #14)
2400	100000	NSA=	100000	; NOT SECTOR ADDRESSED (BIT #15)

; LOOK-AHEAD REGISTER (RMLA) (#07)

2401				
2402				
2403				
2404	000100	SC1=	100	; SECTOR COUNT FIELD 0 (BIT #6)
2405	000200	SC2=	200	; SECTOR COUNT FIELD 1 (BIT #7)
2406	000400	SC04=	400	; SECTOR COUNT FIELD 2 (BIT #8)
2407	001000	SC10=	1000	; SECTOR COUNT FIELD 3 (BIT #9)

```

2408          002000          SC20= 2000          ;SECTOR COUNT FIELD 4 (BIT #10)
2409
2410
2411          ;SERIAL NUMBER REGISTER (RMSN) (#10)
2412          ;(EACH IS CALLED BY BIT NUMBER)
2413          ;OFFSET REGISTER (RMOF) (#11)
2414
2415          000001          OFFDIR= 1          ;RMO3 OFFSET DIRECTION
2416          002000          HCI= 2000          ;HEADER COMPARE INHIBIT (BIT #10)
2417          004000          ECI= 4000          ;ERROR CORRECTION CODE INHIBIT (BIT #11)
2418          010000          FMT16= 10000        ;FORMAT BIT (BIT #12)
2419
2420          ;DESIRED CYLINDER ADDRESS (RMDC) (#12)
2421          ;(EACH BIT IS CALLED BY BIT NUMBER)
2422
2423          ;CURRENT CYLINDER ADDRESS (RMCC) (#13)
2424          ;(REGISTER CURRENTLY NOT USED)
2425
2426          ;RMO3 ERROR REGISTER #02 (RMER2) (#15)
2427
2428          000010          OPE= 10
2429          000200          DVC= 200
2430          002000          LBC= 2000
2431          004000          LSC= 4000
2432          010000          IVC= 10000
2433          020000          DPE= 20000
2434          040000          SKI= 40000          ;SEEK INCOMPLETE (BIT #14)
2435
2436          ;ECC POSITION REGISTER (RMEC1) (#16)
2437          ;(EACH BIT IS CALLED BY BIT NUMBER)
2438
2439          ;ECC PATTERN REGISTER (RMEC2) (#17)
2440          ;(EACH BIT IS CALLED BY BIT NUMBER)
2441
2442          ;*****
2443
2444          .SBTTL RMO3 DRIVER COMMANDS
2445
2446          ;*****
2447
2448          000101          RNOP = 101          ;NO OPERATION
2449          000105          SEEK = 105          ;SEEK
2450          000107          RECAL = 107          ;RECALIBRATE
2451          000111          DRVCLR = 111          ;DRIVE CLEAR
2452          000113          RELSE = 113          ;RELEASE
2453          000115          OFFSET = 115          ;OFFSET
2454          000117          RTC = 117          ;RETURN TO CENTER LINE
2455          000121          READIN = 121          ;READ IN PRESET
2456          000123          ACK = 123          ;PACK ACKNOWLEDGE
2457          000131          SEARCH = 131          ;SEARCH
2458          000141          GETREG = 141          ;GET REGISTERS
2459          000143          SETFMT = 143          ;SET FORMAT (& ECI OR HCI)
2460          000145          SELDRV = 145          ;SELECT DRIVE
2461          000151          WCKD = 151          ;WRITE CHECK DATA
2462          000153          WCKHD = 153          ;WRITE CHECK HEADER & DATA
2463          000161          WRTDAT = 161          ;WRITE DATA

```

```

2464      000163      WRTHD = 163      ;WRITE HEADER & DATA
2465      000171      RDDAT = 171      ;READ DATA
2466      000173      RDHD  = 173      ;READ HEADER & DATA
2467
2468      .SBTTL TRAP CATCHER
2469
2470      000000      .=0
2471      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
2472      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
2473      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
2474
2475      000174      000000      .SREG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
2476      000176      000000      SWREG: .WORD 0      ;;SOFTWARE SWITCH REGISTER
2477
2478      000200      000137      003632      .SBTTL STARTING ADDRESS(ES)
2479      000204      000137      003622      JMP 3#START1      ;;JUMP TO STARTING ADDRESS OF PROGRAM
2480
2481      JMP 3#START      ;;CHANGE THE RH11 UNIBUS ADDRESS
2482      ;AFTER INITIAL START
2483
2484      .SBTTL ACT11 HOOKS
2485
2486      ;*****
2487      ;HOOKS REQUIRED BY ACT11
2488      $SVPC=.      ;SAVE PC
2489      .=46
2490      SENDAD      ;;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
2491      .52
2492      .WORD 40000      ;;2)SET LOC.52 TO 40000
2493      .=52
2494      $SVPC      ;; RESTORE PC
2495      .1100
2496      .SBTTL APT PARAMETER BLOCK
2497
2498      ;*****
2499      ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
2500      ;*****
2501      .SX=.      ;;SAVE CURRENT LOCATION
2502      .24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
2503      200      ;;FOR APT START UP
2504      .44      ;;POINT TO APT INDIRECT ADDRESS PNTR.
2505      $APTHDR      ;;POINT TO APT HEADER BLOCK
2506      .=.SX      ;;RESET LOCATION COUNTER
2507
2508      ;*****
2509      ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
2510      ;INTERFACE SPEC.
2511
2512      $APTHD:
2513      $HIBTS: .WORD 0      ;; TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
2514      $MBADR: .WORD $MAIL      ;; ADDRESS OF APT MAILBOX (BITS 0-15)
2515      $STMT: .WORD 180.      ;; RUN TIM OF LONGEST TEST
2516      $PASTM: .WORD 180.      ;; RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
2517      $UNITM: .WORD 180.      ;; ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
2518      .WORD SETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
2519      TAB.XY=.

```

2516  
2517  
2518  
2519  
2520  
2521  
2522 001114  
2523 001114 000000  
2524 001114 000000  
2525 001116 000  
2526 001117 000  
2527 001120 000000  
2528 001122 000000  
2529 001124 000000  
2530 001126 000000  
2531 001130 000  
2532 001131 001  
2533 001132 000000  
2534 001134 000000  
2535 001136 000000  
2536 001140 000000  
2537 001142 000000  
2538 001144 000000  
2539 001146 000000  
2540 001150 000  
2541 001151 000  
2542 001152 000000  
2543 001154 177570  
2544 001156 177570  
2545 001160 177560  
2546 001162 177562  
2547 001164 177564  
2548 001166 177566  
2549 001170 000  
2550 001171 002  
2551 001172 012  
2552 001173 000  
2553 001174 177607 000377  
2554 001200 077  
2555 001201 015  
2556 001202 000012  
2557  
2558  
2559  
2560  
2561  
2562 001204  
2563 001204 000000  
2564 001206 000000  
2565 001210 000000  
2566 001212 000000  
2567 001214 000000  
2568 001216 000000  
2569 001220 000000  
2570 001222 000000  
2571 001224

.SBTTL COMMON TAGS

\*\*\*\*\*  
\*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS  
\*USED IN THE PROGRAM.

.=TAB.XY

SCMTAG: .; START OF COMMON TAGS  
STSTNM: .WORD 0 ; CONTAINS THE TEST NUMBER  
SERFLG: .BYTE 0 ; CONTAINS ERROR FLAG  
\$ICNT: .WORD 0 ; CONTAINS SUBTEST ITERATION COUNT  
\$LPADR: .WORD 0 ; CONTAINS SCOPE LOOP ADDRESS  
\$LPERR: .WORD 0 ; CONTAINS SCOPE RETURN FOR ERRORS  
\$ERTTL: .WORD 0 ; CONTAINS TOTAL ERRORS DETECTED  
\$ITEMB: .BYTE 0 ; CONTAINS ITEM CONTROL BYTE  
\$ERMAX: .BYTE 1 ; CONTAINS MAX. ERRORS PER TEST  
\$ERRPC: .WORD 0 ; CONTAINS PC OF LAST ERROR INSTRUCTION  
\$GDADR: .WORD 0 ; CONTAINS ADDRESS OF 'GOOD' DATA  
\$BDADR: .WORD 0 ; CONTAINS ADDRESS OF 'BAD' DATA  
\$GDDAT: .WORD 0 ; CONTAINS 'GOOD' DATA  
\$BDDAT: .WORD 0 ; CONTAINS 'BAD' DATA  
; RESERVED--NOT TO BE USED  
\$AUTOB: .BYTE 0 ; AUTOMATIC MODE INDICATOR  
\$INTAG: .BYTE 0 ; INTERRUPT MODE INDICATOR  
\$SWR: .WORD DSWR ; ADDRESS OF SWITCH REGISTER  
\$DISPLAY: .WORD DDISP ; ADDRESS OF DISPLAY REGISTER  
\$TKS: 177560 ; TTY KBD STATUS  
\$TKB: 177562 ; TTY KBD BUFFER  
\$TPS: 177564 ; TTY PRINTER STATUS REG. ADDRESS  
\$TPB: 177566 ; TTY PRINTER BUFFER REG. ADDRESS  
\$NULL: .BYTE 0 ; CONTAINS NULL CHARACTER FOR FILLS  
\$FILLS: .BYTE 2 ; CONTAINS # OF FILLER CHARACTERS REQUIRED  
\$FILLC: .BYTE 12 ; INSERT FILL CHARS. AFTER A "LINE FEED"  
\$TPFLG: .BYTE 0 ; "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)  
\$BELL: .ASCIZ <207><377><377> ; CODE FOR BELL  
\$QUES: .ASCII /?/ ; QUESTION MARK  
\$CRLF: .ASCII <15> ; CARRIAGE RETURN  
\$LF: .ASCIZ <12> ; LINE FEED

\*\*\*\*\*  
.SBTTL APT MAILBOX-ETABLE

\*\*\*\*\*  
.EVEN

\$MAIL: .; APT MAILBOX  
\$MSGTY: .WORD AMSGTY ; MESSAGE TYPE CODE  
\$FATAL: .WORD AFATAL ; FATAL ERROR NUMBER  
\$TESTN: .WORD ATESTN ; TEST NUMBER  
\$PASS: .WORD APASS ; PASS COUNT  
\$DEVCT: .WORD ADEVCT ; DEVICE COUNT  
\$SUNIT: .WORD AUNIT ; I/O UNIT NUMBER  
\$MSGAD: .WORD AMSGAD ; MESSAGE ADDRESS  
\$MSGLG: .WORD AMSLG ; MESSAGE LENGTH  
\$ETABLE: .; APT ENVIRONMENT TABLE

2572	001224	000	SENV:	.BYTE	RENV	:: ENVIRONMENT BYTE		
2573	001225	000	SENVN:	.BYTE	RENVN	:: ENVIRONMENT MODE BITS		
2574	001226	000000	SSWREG:	.WORD	ASWREG	:: APT SWITCH REGISTER		
2575	001230	000000	SUSWR:	.WORD	AUSWR	:: USER SWITCHES		
2576	001232	000000	SCPUOP:	.WORD	ACPUOP	:: CPU TYPE, OPTIONS		
2577			::*			BITS 15-11=CPU TYPE		
2578			::*			11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05		
2579			::*			11/70=06, PD0=07, Q=10		
2580			::*			BIT 10=REAL TIME CLOCK		
2581			::*			BIT 9=FLOATING POINT PROCESSOR		
2582			::*			BIT 8=MEMORY MANAGEMENT		
2583	001234	000	SMAMS1:	.BYTE	AMAMS1	:: HIGH ADDRESS, M.S. BYTE		
2584	001235	000	SMTYP1:	.BYTE	AMTYP1	:: MEM. TYPE, BLK#1		
2585			::*			MEM. TYPE BYTE -- (HIGH BYTE)		
2586			::*			900 NSEC CORE=001		
2587			::*			300 NSEC BIPOLAR=002		
2588			::*			500 NSEC MOS=003		
2589	001236	000000	SMADR1:	.WORD	AMADR1	:: HIGH ADDRESS, BLK#1		
2590			::*			MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE		
2591	001240	000	SMAMS2:	.BYTE	AMAMS2	:: HIGH ADDRESS, M.S. BYTE		
2592	001241	000	SMTYP2:	.BYTE	AMTYP2	:: MEM. TYPE, BLK#2		
2593	001242	000000	SMADR2:	.WORD	AMADR2	:: MEM. LAST ADDRESS, BLK#2		
2594	001244	000	SMAMS3:	.BYTE	AMAMS3	:: HIGH ADDRESS, M.S. BYTE		
2595	001245	000	SMTYP3:	.BYTE	AMTYP3	:: MEM. TYPE, BLK#3		
2596	001246	000000	SMADR3:	.WORD	AMADR3	:: MEM. LAST ADDRESS, BLK#3		
2597	001250	000	SMAMS4:	.BYTE	AMAMS4	:: HIGH ADDRESS, M.S. BYTE		
2598	001251	000	SMTYP4:	.BYTE	AMTYP4	:: MEM. TYPE, BLK#4		
2599	001252	000000	SMADR4:	.WORD	AMADR4	:: MEM. LAST ADDRESS, BLK#4		
2600	001254	000254	SVECT1:	.WORD	AVECT1	:: INTERRUPT VECTOR#1, BUS PRIORITY#1		
2601	001256	000000	SVECT2:	.WORD	AVECT2	:: INTERRUPT VECTOR#2, BUS PRIORITY#2		
2602	001260	176700	SBASE:	.WORD	ABASE	:: BASE ADDRESS OF EQUIPMENT UNDER TEST		
2603	001262	000000	SDEVN:	.WORD	ADEVN	:: DEVICE MAP		
2604	001264	000000	SCDW1:	.WORD	ACDW1	:: CONTROLLER DESCRIPTION WORD#1		
2605	001266	000000	SCDW2:	.WORD	ACDW2	:: CONTROLLER DESCRIPTION WORD#2		
2606	001270		SETEND:					
2607			.MEXIT					
2608		000015	CR	=	15			
2609		000012	LF	=	12			
2610	001270	176700	SRMADR:	.WORD	176700	:: FIRST ADDRESS OF RH11/RMO3 REGISTERS		
2611	001272	000254	SRMVEC:	.WORD	254	:: RMO3 VECTOR ADDRESS		
2612	001274	172540	SLKCSR:	.WORD	172540	:: ADDR OF KW11-P STATUS REGISTER		
2613	001276	172542	SLKCSB:	.WORD	172542	:: ADDR OF KW11-P COUNTER BUFFER		
2614	001300	000104	SLPVEC:	.WORD	104	:: ADDR OF KW11-P VECTOR		
2615	001302	177546	SLKS:	.WORD	177546	:: ADDR OF KW11-L STATUS REGISTER		
2616	001304	000100	SLLVEC:	.WORD	100	:: ADDR OF KW11-L VECTOR		
2617	001306	177777	PCLOCK:	.WORD	-1	:: '0' IF KW11-P IS ON SYSTEM		
2618	001310	177777	CLKFLG:	.WORD	-1	:: '0' IF A CLOCK IS AVAILABLE		
2619	001312	000074	HZ:	.WORD	74	:: 74 (8) IF 60 HZ SYSTEM; 62 (8) IF 50 HZ SYSTEM		
2620	001314	000000	STATIN:	.WORD	0	:: 'TYPE STATISTICS' INDICATOR		
2621	001316	000000	PACK:	.WORD	0	:: 'W' COMMAND INDICATOR		
2622	001320	000000	000000	000000	DATE:	.WORD	0,0,0,0,0	:: OPERATOR ENTERED DATE
2623	001326	000000	000000	000000	OPERID:	.WORD	0,0,0,0	:: OPERATOR ID
2624	001332	000000	000000	000000	DRIVE	=	SUNIT	:: DRIVE # STORAGE: ERRORS 1-5 & 10
2625	001340	000000	ATTN:	.WORD	0			:: ATTN REG STORAGE: ERRORS 1-5 & 10
2626		001216						
2627	001342	000000						

2628	001344	000000	UNIT:	.WORD	0	;	DRIVE & STORAGE FOR PRINTOUT
2629	001345	000000	MASK:	.WORD	0	;	ERROR RETRY REGISTER MASK
2630	001350	000	RETRY:	.BYTE	0,0	;	ERROR RETRY LIMIT IN THE LOWER BYTE
2631						;	RETRY COUNT IN THE UPPER BYTE
2632	001352	000003	FAIRNS:	.WORD	3	;	MAXIMUM TIME IN QUEUE VALUE
2633	001354	000000	LSTAD:	.WORD	0	;	STORE LAST MEMORY ADDRESS HERE
2634	001356	000000	CHGADR:	.WORD	0	;	CHANGE RM11 UNIBUS ADDRESS FLAG
2635	001360	000000	CFLAG:	.WORD	0	;	'CONTROL C' FLAG
2636	001362	000000	BADSEC:	.WORD	0	;	BAD SECTOR/TRACK FLAG
2637	001364	000000	HOUR:	.WORD	0	;	HOUR COUNT STORED HERE (MAXIMUM - 999.)
2638	001366	000000	MINUTE:	.WORD	0	;	MINUTE'S COUNT STORED HERE
2639	001370	000000	SECOND:	.WORD	0	;	SECOND'S COUNT STORED HERE
2640	001372	000000	SIXTEE:	.WORD	0	;	TIMER ROUTINE COUNTER (FOR ONE SECOND)
2641	001374	177777	ZROIND:	.WORD	-1	;	ZERO INDICATOR FOR THE DATA COMPARE ROUTINE
2642	001376	000	FRSTER:	.BYTE	0	;	DATA COMPARE ERROR FLAG
2643						;	IF > 0, PROCESSING 'DCKER' OR CAN'T MATCH PATTERN
2644						;	IF < 0, MISCOMPARISON FOUND
2645	001377	000		.BYTE	0	;	MISCOMPARISON OR CAN'T MATCH PATTERN FLAG
2646						;	IF < 0, ERROR IN BUFFER
2647	001400	000000	SAVER1:	.WORD	0	;	SAVE R1 HERE
2648	001402	000000	SAVERS:	.WORD	0	;	SAVE RS HERE
2649	001404	000000	ERCTR:	.WORD	0	;	NUMBER OF ERRORS
2650	001406	000000	LIMIT:	.WORD	0	;	DISPLAY LIMIT
2651	001410	000000	CMCNT:	.WORD	0	;	WORD COUNT
2652	001412	000000	CMCYL:	.WORD	0	;	CYLINDER ADDRESS
2653	001414	000	CMSEC:	.BYTE	0	;	SECTOR ADDRESS
2654	001415	000	CMTRK:	.BYTE	0	;	TRACK ADDRESS
2655	001416	000000	ECBIT:	.WORD	0	;	ERROR BURST BIT OFFSET
2656	001420	000000	ECSEC:	.WORD	0	;	ERROR BURST WORD OFFSET (RELATIVE TO SECTOR)
2657	001422	000000	ECMSK0:	.WORD	0	;	CORRECTION MASK FOR FIRST ERROR WORD
2658	001424	000000	ECMSK1:	.WORD	0	;	CORRECTION MASK FOR SECOND ERROR WORD
2659	001426	000000	ECWRD:	.WORD	0	;	LOCATION OF FIRST ERROR WORD
2660	001430	000000	ECGD:	.WORD	0	;	GOOD DATA, FIRST WORD
2661	001432	000000	ECBAD0:	.WORD	0	;	BAD DATA, FIRST WORD
2662	001434	000000	ECWRD1:	.WORD	0	;	LOCATION OF SECOND ERROR WORD
2663	001436	000000	ECGD1:	.WORD	0	;	GOOD DATA, SECOND WORD
2664	001440	000000	ECBAD1:	.WORD	0	;	BAD DATA, SECOND WORD
2665	001442	000037	SECLMT:	.WORD	31.	;	SECTOR ADDRESS LIMIT
2666	001444	000004	TRKLMT:	.WORD	4.	;	TRACK ADDRESS LIMIT
2667	001446	001465	CYLIMT:	.WORD	821.	;	CYLINDER ADDRESS LIMIT FOR RMD3
2668							
2669			;;	*****			
2670							
2671			.SBTTL	COMMON PARAMETERS			
2672							
2673			;;	*****			
2674							
2675	001450	002740	ENDCON:	.WORD	002740	;	1.875X10 <sup>18</sup> WORDS (10) [3X10 <sup>19</sup> BITS]
2676	001452	005455		.WORD	005455	;	MSW
2677	001454	143300	ENDSEK:	.WORD	143300	;	3 X 10 <sup>16</sup> SEEKS (LSW)
2678	001456	000055		.WORD	55	;	MSW
2679	001460	000001	PASCNT:	.WORD	1	;	NUMBER OF PASSES TO END OF TEST
2680	001462	000000	MAXDL:	.WORD	0	;	MAXIMUM DATA TRANSFER SIZE IN WORDS
2681						;	(FILLED BY PROGRAM AT STARTUP OR BY OPERATOR
2682						;	DURING PARAMETER ENTRY DIALOG.)
2683	001464	000144	MAXER:	.WORD	100.	;	MAXIMUM ERRORS - 100(10)

```

2684 001466 000005 000000      INTRVL: .WORD  5,0
2685
2686
2687
2688 001472 000004      CMPLMT: .WORD  4
2689 001474 000001      FORMAT: .WORD  1
2690
2691 001476 000000      WCSEL:  .WORD  0
2692
2693
2694
2695 001500 000003      RATIO:  .WORD  3
2696
2697
2698
2699
2700
2701
2702
2703
2704 001502 000001      AUTOCK: .WORD  1
2705
2706
2707
2708 001504 000001      NOTPRT: .WORD  1
2709
2710
2711
2712
2713 001506 000001      ENDET:  .WORD  1
2714
2715
2716
2717 001510 000000      PATTEN: .WORD  0
2718
2719
2720 001512 000000      HEADER: .WORD  0
2721
2722
2723
2724
2725
2726
2727
2728
2729
2730
2731 001514 000010      BEGPAT: .WORD  10
2732 001516 000004      BEGCOD: .WORD   4
2733
2734
2735
2736
2737
2738
2739 001520 000400      BEGSIZ: .WORD  400

```

```

;FIRST WORD IS THE PERFORMANCE TYPEOUT INTERVAL
;(IN MINUTES). SECOND WORD IS THE INTERVAL
;COUNTER
;COUNTER. UPPER BYTE IS VALUE.
;NUMBER OF COMPARE ERRORS TYPED OUT
;IF NOT EQ 0, ALLOW WRITE HEADER & DATA ORDERS
;IF EQ 0, DO NOT ALLOW WRITE HEADER & DATA ORDERS
;IF EQ TO 0, GENERATE A RANDOM WORD COUNT
;FOR THE OPERATION.
;IF NOT EQ TO 0, USE THE VALUE IN 'MAXDL' FOR
;THE WORD COUNT
;READ/WRITE RATIO [RANGE 0 - 7]
;0 - 0/8 (READ/WRITE)
;1 - 7/1
;2 - 6/2
;3 - 5/3
;4 - 4/4
;5 - 3/5
;6 - 2/6
;7 - 1/7
;IF NOT EQ 0, DO AN APPROPRIATE WRITE
;CHECK AFTER EACH WRITE ORDER.
;IF EQ 0, SELECT WRITE CHECK ORDERS
;RANDOMLY.
;IF EQ 1, DO NOT PRINT DATA ERROR MESSAGES
;ASSOCIATED WITH OPERATOR SPECIFIED
;BAD PACK AREAS.
;IF NOT EQ 0, PRINT ERROR MESSAGES RELATING TO
;THESE AREAS.
;IF NOT EQ 0, END OF PASS DETERMINED
;BY THE 'WORDS READ' COUNT.
;IF EQ 0, END OF PASS DETERMINED
;BY THE SEEK COUNT.
;IF EQ 0,RANDOMLY SELECT DATA PATTERN
;IF NOT EQ 0,SELECT ONE SET OF PATTERN
;POINTED BY THE "PATTEN".
;IF EQ TO 0,RANDOMLY SELECT DATA BLOCK
;ADDRESS. IF NOT EQU 0,SEQUENTIALLY
;SELECT DATA BLOCK ADDRESS

```

```

;;*****
;SBTTL VALUES FOR FIRST OPERATION
;;*****

```

```

;STARTING PATTERN CODE [RANGE 1 - 17 (OCTAL)]
;STARTING COMMAND CODE [RANGE 0 - 5]
;0 = WRITE CHECK DATA ('WCKD')
;1 = WRITE CHECK HEADER & DATA ('WCHKHD')
;2 = WRITE DATA ('WRDAT')
;3 = WRITE HEADER & DATA ('WRTHD')
;4 = READ DATA ('RDDAT')
;5 = READ HEADER & DATA ('RDHD')
;STARTING RECORD SIZE [RANGE 4 - MAXMEM]

```



```

2740
2741 ;*****
2742
2743 .SBTTL TABLES, CONSTANTS, AND VARIABLE LOCATIONS
2744
2745 ;*****
2746
2747 001522 000000 000000 000000 ORDERQ: .WORD 0,0,0,0,0,0,0,0,0 ;LIST OF DRIVES PERFORMING COMMANDS
2748 001530 000000 000000 000000
2749 001536 000000 000000 000000
2750
2751 001544 000000 ASNLST: .WORD 0 ;A BIT SET IS AN ASSIGNED DRIVE
2752
2753 001546 000000 000000 000000 DUNIT: .WORD 0,0,0,0,0,0,0,0,0 ;ADDRESSES OF DRIVES TO BE DEASSIGNED
2754 001554 000000 000000 000000
2755 001562 000000 000000 000000
2756
2757 001570 000000 000000 000000 NEWUNT: .WORD 0,0,0,0,0,0,0,0,0 ;ADDRESSES OF NEWLY ASSIGNED DRIVES
2758 001576 000000 000000 000000
2759 001604 000000 000000 000000
2760
2761 001612 000000 000000 000000 AVAIL: .WORD 0,0,0,0,0,0,0,0,0 ;LIST OF DRIVES WAITING FOR BUFFERS/PARAMETERS
2762 001620 000000 000000 000000
2763 001626 000000 000000 000000
2764
2765 001634 000000 000000 000000 WAIT: .WORD 0,0,0,0,0,0,0,0,0 ;LIST OF DRIVES WAITING FOR BUFFERS
2766 001642 000000 000000 000000
2767 001650 000000 000000 000000
2768
2769 001656 000000 000000 000000 PARQ: .WORD 0,0,0,0,0,0,0,0,0 ;LIST OF DRIVES WAITING FOR NEXT PARAMETERS
2770 001664 000000 000000 000000
2771 001672 000000 000000 000000
2772
2773 001700 000000 BUFTBL: .WORD 0 ;BUFFER ALLOCATION TABLE ENTRY COUNT
2774 001702 000000 000000 .WORD 0,0
2775 001706 000000 000000 .WORD 0,0
2776 001712 000000 000000 .WORD 0,0
2777 001716 000000 000000 .WORD 0,0
2778 001722 000000 000000 .WORD 0,0
2779 001726 000000 000000 .WORD 0,0
2780 001732 000000 000000 .WORD 0,0
2781 001736 000000 000000 .WORD 0,0
2782 001742 000000 000000 .WORD 0,0
2783 001746 000000 000000 .WORD 0,0
2784 001752 000000 000000 .WORD 0,0
2785 001756 000000 000000 .WORD 0,0
2786 001762 000000 000000 .WORD 0,0
2787 001766 000000 000000 .WORD 0,0
2788 001772 000000 000000 .WORD 0,0
2789 001776 000000 000000 .WORD 0,0
2790 002002 000000 000000 .WORD 0,0
2791 002006 000000 000000 .WORD 0,0
2792 002012 000000 000000 .WORD 0,0
2793 002016 000000 000000 .WORD 0,0
2794 002022 000000 000000 .WORD 0,0
2795 002026 000000 000000 .WORD 0,0

```

2796	002032	000000	000000		.WORD	0,0	
2797	002036	000000	000000		.WORD	0,0	
2798	002042	000000	000000		.WORD	0,0	
2799	002046	000000	000000		.WORD	0,0	
2800	002052	000000	000000		.WORD	0,0	
2801	002056	000000	000000		.WORD	0,0	
2802	002062	000000	000000		.WORD	0,0	
2803	002066	000000	000000		.WORD	0,0	
2804	002072	000000	000000		.WORD	0,0	
2805	002076	000000	000000		.WORD	0,0	
2806							
2807	002102	042472		BLKADR:	.WORD	DRIVE0	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 0
2808	002104	042776			.WORD	DRIVE1	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 1
2809	002106	043302			.WORD	DRIVE2	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 2
2810	002110	043606			.WORD	DRIVE3	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 3
2811	002112	044112			.WORD	DRIVE4	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 4
2812	002114	044416			.WORD	DRIVE5	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 5
2813	002116	044722			.WORD	DRIVE6	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 6
2814	002120	045226			.WORD	DRIVE7	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 7
2815							
2816	002122	151		COMTBL:	.BYTE	WCKD	: WRITE CHECK DATA
2817	002123	153			.BYTE	WCKHD	: WRITE CHECK HEADER AND DATA
2818	002124	161			.BYTE	WRTDAT	: WRITE DATA
2819	002125	163			.BYTE	WRTHD	: WRITE HEADER AND DATA
2820	002126	171			.BYTE	RDDAT	: READ DATA
2821	002127	173			.BYTE	RDHD	: READ HEADER AND DATA
2822							
2823	002130	002		OPTBL:	.BYTE	2	: UNLOAD
2824	002131	004			.BYTE	4	: SEEK
2825	002132	006			.BYTE	6	: RECAL
2826	002133	010			.BYTE	10	: DRIVE CLEAR
2827	002134	012			.BYTE	12	: RELEASE
2828	002135	014			.BYTE	14	: OFFSET
2829	002136	016			.BYTE	16	: RETURN TO CENTERLINE
2830	002137	020			.BYTE	20	: READIN PRESET
2831	002140	022			.BYTE	22	: PACK ACKNOWLEDGE
2832	002141	030			.BYTE	30	: SEARCH
2833	002142	050			.BYTE	50	: WRITE CHECK DATA
2834	002143	052			.BYTE	52	: WRITE CHECK HEADER AND DATA
2835	002144	060			.BYTE	60	: WRITE DATA
2836	002145	062			.BYTE	62	: WRITE HEADER AND DATA
2837	002146	070			.BYTE	70	: READ DATA
2838	002147	072			.BYTE	72	: READ HEADER AND DATA
2839	002150	377			.BYTE	-1	: TERMINATOR
2840							
2841		002152		.EVEN			
2842							
2843							
2844	002152	047125	047514	042101	MNTBL:	.ASCIZ	/UNLOAD /
2845	002160	000040					
2846	002162	042523	045505	020040		.ASCIZ	/SEEK /
2847	002170	000040					
2848	002172	042522	040503	020114		.ASCIZ	/RECAL /
2849	002200	000040					
2850	002202	051104	041526	051114		.ASCIZ	/DRVCLR /
2851	002210	000040					

2852	002212	042522	051514	020105	.ASCIZ /RELSE /
2853	002220	000040			
2854	002222	043117	051506	052105	.ASCIZ /OFFSET /
2855	002230	000040			
2856	002232	052122	020103	020040	.ASCIZ /RTC /
2857	002240	000040			
2858	002242	042522	042101	047111	.ASCIZ /READIN /
2859	002250	000040			
2860	002252	040520	045503	020040	.ASCIZ /PACK /
2861	002260	000040			
2862	002262	042523	051101	044103	.ASCIZ /SEARCH /
2863	002270	000040			
2864	002272	041527	042113	020040	.ASCIZ /WCKD /
2865	002300	000040			
2866	002302	041527	044113	020104	.ASCIZ /WCKHD /
2867	002310	000040			
2868	002312	051127	042124	052101	.ASCIZ /WRTDAT /
2869	002320	000040			
2870	002322	051127	044124	020104	.ASCIZ /WRTHD /
2871	002330	000040			
2872	002332	042122	040504	020124	.ASCIZ /RDDAT /
2873	002340	000040			
2874	002342	042122	042110	020040	.ASCIZ /RDHD /
2875	002350	000040			
2876	002352	047516	042516	020040	.ASCIZ /NONE /
2877	002360	000040			

2878					
2879					
2880	002362	043101	042524	020122	OFMSG0: .ASCIZ /AFTER RETRY WITHOUT OFFSET/
2881	002370	042522	051124	020131	
2882	002376	044527	044124	052517	
2883	002404	020124	043117	051506	
2884	002412	052105	000		
2885	002415	101	020124	042516	OFMSG1: .ASCIZ /AT NEGATIVE OFFSET/
2886	002422	040507	044524	042526	
2887	002430	047440	043106	042523	
2888	002436	000124			
2889	002440	052101	050040	051517	OFMSG2: .ASCIZ /AT POSITIVE OFFSET/
2890	002446	052111	053111	020105	
2891	002454	043117	051506	052105	
2892	002462	000			

2893					
2894		002464			.EVEN
2895					
2896	002464	000			OFFCOD: .BYTE 0 ; OFFSET CODE TABLE
2897	002465	001			.BYTE 1 ; NUMBER FOR NEGATIVE OFFSET (DIR = OUT)
2898	002466	000			.BYTE 0 ; NUMBER FOR POSITIVE OFFSET (DIR = IN)
2899					
2900		002470			.EVEN
2901					
2902	002470	002362			OFMTBL: .WORD OFMSG0 ; 1ST OFFSET MESSAGE
2903	002472	002415			.WORD OFMSG1 ; 2ND OFFSET MESSAGE
2904	002474	002440			.WORD OFMSG2 ; 3RD OFFSET MESSAGE
2905					
2906					
2907					

;;\*\*\*\*\*

2908  
2909  
2910  
2911  
2912  
2913  
2914  
2915  
2916  
2917  
2918  
2919  
2920  
2921  
2922  
2923  
2924  
2925  
2926  
2927  
2928  
2929  
2930  
2931  
2932  
2933  
2934  
2935  
2936  
2937  
2938  
2939  
2940  
2941  
2942  
2943  
2944  
2945  
2946  
2947  
2948  
2949  
2950  
2951  
2952  
2953  
2954  
2955  
2956  
2957  
2958  
2959  
2960  
2961  
2962  
2963

002476 002542  
002500 002602  
002502 002642  
002504 002702  
002506 002742  
002510 003002  
002512 003042  
002514 003102  
002516 003142  
002520 003202  
002522 003242  
002524 003302  
002526 003342  
002530 003402  
002532 003442  
002534 003502  
002536 002542  
002540 003444  
  
002542 000000  
002544 000000  
002546 000000  
002550 000000  
002552 000000  
002554 000000  
002556 000000  
002560 000000  
002562 000000  
002564 000000  
002566 000000  
002570 000000  
002572 000000  
002574 000000  
002576 000000  
002600 000000  
  
002602 000001  
002604 000003  
002606 000007  
002610 000017  
002612 000037  
002614 000077  
002616 000177  
002620 000377  
002622 000777  
002624 001777  
002626 003777  
002630 007777  
002632 017777  
002634 037777  
002636 077777

.SBTTL DATA PATTERNS

;;\*\*\*\*\*

STNDAT: .WORD DATA0 ;STANDARD DATA PATTERN POINTER TABLE

.WORD DATA1  
.WORD DATA1+40  
.WORD DATA1+100  
.WORD DATA1+140  
.WORD DATA1+200  
.WORD DATA1+240  
.WORD DATA1+300  
.WORD DATA1+340  
.WORD DATA1+400  
.WORD DATA1+440  
.WORD DATA1+500  
.WORD DATA1+540  
.WORD DATA1+600  
.WORD DATA1+640  
.WORD DATA1+700  
.WORD DATA0  
.WORD DATA1+642

;ZEROES  
;ONES

DATA0: .WORD 0 ;DUMMY DATA PATTERN

.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0

DATA1: .WORD 000001 ;STANDARD PATTERN 1

.WORD 000003  
.WORD 000007  
.WORD 000017  
.WORD 000037  
.WORD 000077  
.WORD 000177  
.WORD 000377  
.WORD 000777  
.WORD 001777  
.WORD 003777  
.WORD 007777  
.WORD 017777  
.WORD 037777  
.WORD 077777

2964	002640	177777	.WORD	177777	
2965					
2966	002642	177776	.WORD	177776	;STANDARD PATTERN 2
2967	002644	177774	.WORD	177774	
2968	002646	177770	.WORD	177770	
2969	002650	177760	.WORD	177760	
2970	002652	177740	.WORD	177740	
2971	002654	177700	.WORD	177700	
2972	002656	177600	.WORD	177600	
2973	002660	177400	.WORD	177400	
2974	002662	177000	.WORD	177000	
2975	002664	176000	.WORD	176000	
2976	002666	174000	.WORD	174000	
2977	002670	170000	.WORD	170000	
2978	002672	160000	.WORD	160000	
2979	002674	140000	.WORD	140000	
2980	002676	100000	.WORD	100000	
2981	002700	000000	.WORD	000000	
2982					
2983	002702	000000	.WORD	000000	;STANDARD PATTERN 3
2984	002704	000000	.WORD	000000	
2985	002706	000000	.WORD	000000	
2986	002710	177777	.WORD	177777	
2987	002712	177777	.WORD	177777	
2988	002714	177777	.WORD	177777	
2989	002716	000000	.WORD	000000	
2990	002720	000000	.WORD	000000	
2991	002722	177777	.WORD	177777	
2992	002724	177777	.WORD	177777	
2993	002726	000000	.WORD	000000	
2994	002730	177777	.WORD	177777	
2995	002732	000000	.WORD	000000	
2996	002734	177777	.WORD	177777	
2997	002736	000000	.WORD	000000	
2998	002740	177777	.WORD	177777	
2999					
3000	002742	133331	.WORD	133331	;STANDARD PATTERN 4
3001	002744	133331	.WORD	133331	
3002	002746	133331	.WORD	133331	
3003	002750	133331	.WORD	133331	
3004	002752	133331	.WORD	133331	
3005	002754	133331	.WORD	133331	
3006	002756	133331	.WORD	133331	
3007	002760	133331	.WORD	133331	
3008	002762	133331	.WORD	133331	
3009	002764	133331	.WORD	133331	
3010	002766	133331	.WORD	133331	
3011	002770	133331	.WORD	133331	
3012	002772	133331	.WORD	133331	
3013	002774	133331	.WORD	133331	
3014	002776	133331	.WORD	133331	
3015	003000	133331	.WORD	133331	
3016					
3017	003002	052525	.WORD	052525	;STANDARD PATTERN 5
3018	003004	052525	.WORD	052525	
3019	003006	052525	.WORD	052525	

3020	003010	125252	.WORD	125252
3021	003012	125252	.WORD	125252
3022	003014	125252	.WORD	125252
3023	003016	052525	.WORD	052525
3024	003020	052525	.WORD	052525
3025	003022	125252	.WORD	125252
3026	003024	125252	.WORD	125252
3027	003026	052525	.WORD	052525
3028	003030	125252	.WORD	125252
3029	003032	052525	.WORD	052525
3030	003034	125252	.WORD	125252
3031	003036	052525	.WORD	052525
3032	003040	125252	.WORD	125252
3033				
3034	003042	155554	.WORD	155554
3035	003044	155554	.WORD	155554
3036	003046	155554	.WORD	155554
3037	003050	155554	.WORD	155554
3038	003052	155554	.WORD	155554
3039	003054	155554	.WORD	155554
3040	003056	155554	.WORD	155554
3041	003060	155554	.WORD	155554
3042	003062	155554	.WORD	155554
3043	003064	155554	.WORD	155554
3044	003066	155554	.WORD	155554
3045	003070	155554	.WORD	155554
3046	003072	155554	.WORD	155554
3047	003074	155554	.WORD	155554
3048	003076	155554	.WORD	155554
3049	003100	155554	.WORD	155554
3050				
3051	003102	026455	.WORD	026455
3052	003104	026455	.WORD	026455
3053	003106	026455	.WORD	026455
3054	003110	151322	.WORD	151322
3055	003112	151322	.WORD	151322
3056	003114	151322	.WORD	151322
3057	003116	026455	.WORD	026455
3058	003120	026455	.WORD	026455
3059	003122	151322	.WORD	151322
3060	003124	151322	.WORD	151322
3061	003126	026455	.WORD	026455
3062	003130	151322	.WORD	151322
3063	003132	026455	.WORD	026455
3064	003134	151322	.WORD	151322
3065	003136	026455	.WORD	026455
3066	003140	151322	.WORD	151322
3067				
3068	003142	066666	.WORD	066666
3069	003144	066666	.WORD	066666
3070	003146	066666	.WORD	066666
3071	003150	066666	.WORD	066666
3072	003152	066666	.WORD	066666
3073	003154	066666	.WORD	066666
3074	003156	066666	.WORD	066666
3075	003160	066666	.WORD	066666

;STANDARD PATTERN 6

;STANDARD PATTERN 7

;STANDARD PATTERN 8

J05

3076	003162	066666	.WORD	066666	
3077	003164	066666	.WORD	066666	
3078	003166	066666	.WORD	066666	
3079	003170	066666	.WORD	066666	
3080	003172	066666	.WORD	066666	
3081	003174	066666	.WORD	066666	
3082	003176	066666	.WORD	066666	
3083	003200	066666	.WORD	066666	
3084					
3085	003202	000001	.WORD	000001	; STANDARD PATTERN 9
3086	003204	000002	.WORD	000002	
3087	003206	000004	.WORD	000004	
3088	003210	000010	.WORD	000010	
3089	003212	000020	.WORD	000020	
3090	003214	000040	.WORD	000040	
3091	003216	000100	.WORD	000100	
3092	003220	000200	.WORD	000200	
3093	003222	000400	.WORD	000400	
3094	003224	001000	.WORD	001000	
3095	003226	002000	.WORD	002000	
3096	003230	004000	.WORD	004000	
3097	003232	010000	.WORD	010000	
3098	003234	020000	.WORD	020000	
3099	003236	040000	.WORD	040000	
3100	003240	100000	.WORD	100000	
3101					
3102	003242	177776	.WORD	177776	; STANDARD PATTERN 10
3103	003244	177775	.WORD	177775	
3104	003246	177773	.WORD	177773	
3105	003250	177767	.WORD	177767	
3106	003252	177757	.WORD	177757	
3107	003254	177737	.WORD	177737	
3108	003256	177677	.WORD	177677	
3109	003260	177577	.WORD	177577	
3110	003262	177377	.WORD	177377	
3111	003264	176777	.WORD	176777	
3112	003266	175777	.WORD	175777	
3113	003270	173777	.WORD	173777	
3114	003272	167777	.WORD	167777	
3115	003274	157777	.WORD	157777	
3116	003276	137777	.WORD	137777	
3117	003300	077777	.WORD	077777	
3118					
3119	003302	172666	.WORD	172666	; STANDARD PATTERN 11
3120	003304	155555	.WORD	155555	
3121	003306	172666	.WORD	172666	
3122	003310	155555	.WORD	155555	
3123	003312	172666	.WORD	172666	
3124	003314	155555	.WORD	155555	
3125	003316	172666	.WORD	172666	
3126	003320	155555	.WORD	155555	
3127	003322	172666	.WORD	172666	
3128	003324	155555	.WORD	155555	
3129	003326	172666	.WORD	172666	
3130	003330	155555	.WORD	155555	
3131	003332	172666	.WORD	172666	

3132	003334	155555	.WORD	155555	
3133	003336	172666	.WORD	172666	
3134	003340	155555	.WORD	155555	
3135					
3136	003342	077777	.WORD	077777	; STANDARD PATTERN 12
3137	003344	137777	.WORD	137777	
3138	003346	157777	.WORD	157777	
3139	003350	167777	.WORD	167777	
3140	003352	173777	.WORD	173777	
3141	003354	175777	.WORD	175777	
3142	003356	176777	.WORD	176777	
3143	003360	177377	.WORD	177377	
3144	003362	177577	.WORD	177577	
3145	003364	177677	.WORD	177677	
3146	003366	177737	.WORD	177737	
3147	003370	177757	.WORD	177757	
3148	003372	177767	.WORD	177767	
3149	003374	177773	.WORD	177773	
3150	003376	177775	.WORD	177775	
3151	003400	177776	.WORD	177776	
3152					
3153	003402	153333	.WORD	153333	; STANDARD PATTERN 13
3154	003404	066667	.WORD	066667	
3155	003406	153333	.WORD	153333	
3156	003410	066667	.WORD	066667	
3157	003412	153333	.WORD	153333	
3158	003414	066667	.WORD	066667	
3159	003416	153333	.WORD	153333	
3160	003420	066667	.WORD	066667	
3161	003422	153333	.WORD	153333	
3162	003424	066667	.WORD	066667	
3163	003426	153333	.WORD	153333	
3164	003430	066667	.WORD	066667	
3165	003432	153333	.WORD	153333	
3166	003434	066667	.WORD	066667	
3167	003436	153333	.WORD	153333	
3168	003440	066667	.WORD	066667	
3169					
3170	003442	000000	.WORD	000000	; STANDARD PATTERN 14
3171	003444	177777	.WORD	177777	
3172	003446	177777	.WORD	177777	
3173	003450	177777	.WORD	177777	
3174	003452	177777	.WORD	177777	
3175	003454	177777	.WORD	177777	
3176	003456	177777	.WORD	177777	
3177	003460	177777	.WORD	177777	
3178	003462	177777	.WORD	177777	
3179	003464	177777	.WORD	177777	
3180	003466	177777	.WORD	177777	
3181	003470	177777	.WORD	177777	
3182	003472	177777	.WORD	177777	
3183	003474	177777	.WORD	177777	
3184	003476	177777	.WORD	177777	
3185	003500	177777	.WORD	177777	
3186					
3187	003502	177777	.WORD	177777	; STANDARD PATTERN 15



L05

MD-11-DZRM8 AO/00 RMO3 PERFORMANCE EXERCISER MACY11 30(1046)  
DZRM8A.P11 27-JUL-77 08:04 DATA PATTERNS

27-JUL-77 08:07 PAGE 63

SEQ 0062

3188	003504	000000	.WORD	000000
3189	003506	000000	.WORD	000000
3190	003510	000000	.WORD	000000
3191	003512	000000	.WORD	000000
3192	003514	000000	.WORD	000000
3193	003516	000000	.WORD	000000
3194	003520	000000	.WORD	000000
3195	003522	000000	.WORD	000000
3196	003524	000000	.WORD	000000
3197	003526	000000	.WORD	000000
3198	003530	000000	.WORD	000000
3199	003532	000000	.WORD	000000
3200	003534	000000	.WORD	000000
3201	003536	000000	.WORD	000000
3202	003540	000000	.WORD	000000
3203				

## ERROR POINTER TABLE

```

3204      .SBTTL  ERROR POINTER TABLE
3205
3206      ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
3207      ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
3208      ;*LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
3209      ;*NOTE1:      IF SITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
3210      ;*NOTE2:      EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
3211
3212      ;*      EM      ;;POINTS TO THE ERROR MESSAGE
3213      ;*      DH      ;;POINTS TO THE DATA HEADER
3214      ;*      DT      ;;POINTS TO THE DATA
3215      ;*      DF      ;;POINTS TO THE DATA FORMAT
3216
3217
3218      003542      $ERRTB:
3219      ;ERROR 1
3220
3221      ;ERROR 1
3222
3223      003542      045622      EM1      ;RH70 INTERRUPT OCCURRED (RMAS = 0)
3224      003544      050241      DH1
3225      003546      050672      DT1
3226      003550      000000      0
3227
3228      ;ERROR 2
3229
3230      003552      045671      EM2      ;UNEXPECTED ATTENTION OCCURRED
3231      003554      050246      DH2
3232      003556      050676      DT2
3233      003560      000000      0
3234
3235      ;ERROR 3
3236
3237      003562      045727      EM3      ;MASSBUS PARITY ERROR (MCPE=1)
3238      003564      050322      DH3
3239      003566      050714      DT3
3240      003570      000000      0
3241
3242      ;ERROR 4
3243
3244      003572      045765      EM4      ;MASSBUS PARITY ERROR (PAR=1)
3245      003574      050350      DH4
3246      003576      050724      DT4
3247      003600      000000      0
3248
3249      ;ERROR 5
3250
3251      003602      046022      EM5      ;ADDRESS PLUG BIT CHANGED
3252      003604      050246      DH2
3253      003606      050676      DT2
3254      003610      000000      0
3255
3256      ;ERROR 6
3257
3258      003612      046056      EM6
3259      003614      050407      DH6

```

```

3260 003616 050736 DT6
3261 003620 000000 0
3262
3263 ;;*****
3264
3265 .SBTTL SETUP AND INITIALIZATION ROUTINE
3266
3267 ; START ADDRESS = 200
3268 ; ADDRESS TO CHANGE RH11 UNIBUS ADDRESS = 204
3269
3270 ;;*****
3271
3272 003622 012737 177777 001356 START: MOV #-1,CHGADR ;SET RH11 ADDRESS CHANGE FLAG
3273 003630 000407 BR START2 ;START THE PROGRAM
3274 003632 012737 000400 001356 START1: MOV #400,CHGADR ;CLEAR THE RH11 ADDRESS CHANGE FLAG
3275 ;;*****
3276 003640 000240 †ST1: NOP
3277 003642 012737 000001 001210 MOV #1,STESTN ;SET TEST NUMBER IN APT MAIL BOX
3278 003650 000005 START2: RESET ;CLEAR THE BUS
3279 .SBTTL INITIALIZE THE COMMON TAGS
3280 ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
3281 003652 012706 001114 MOV #CMTAG,R6 ;FIRST LOCATION TO BE CLEARED
3282 003656 005026 CLR (R6)+ ;CLEAR MEMORY LOCATION
3283 003660 022706 001154 CMP #SWR,R6 ;;DONE?
3284 003664 001374 BNE -6 ;LOOP BACK IF NO
3285 003666 012706 001100 MOV #STACK,SP ;SETUP THE STACK POINTER
3286 ;;INITIALIZE A FEW VECTORS
3287 003672 012737 031006 000030 MOV #ERROR,#EMTVEC ;EMT VECTOR FOR ERROR ROUTINE
3288 003700 012737 000340 000032 MOV #340,#EMTVEC+2 ;LEVEL 7
3289 003706 012737 034062 000034 MOV #STRAP,#TRAPVEC ;TRAP VECTOR FOR TRAP CALLS
3290 003714 012737 000340 000036 MOV #340,#TRAPVEC+2 ;LEVEL 7
3291 003722 012737 032056 000024 MOV #SPWRDN,#PWRVEC ;POWER FAILURE VECTOR
3292 003730 012737 000340 000026 MOV #340,#PWRVEC+2 ;LEVEL 7
3293 003736 012737 176543 033446 MOV #176543,$HINUM ;PRIME THE RANDOM NUMBER GENERATOR
3294 003744 012737 123456 033450 MOV #123456,$LONUM ;BOTH HIGH AND LOW WORDS
3295 ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
3296 ;;EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
3297 003752 013746 000004 MOV #ERRVEC,-(SP) ;SAVE ERROR VECTOR
3298 003756 012737 004012 000004 MOV #64$,#ERRVEC ;SET UP ERROR VECTOR
3299 003764 012737 177570 001154 MOV #DSWR,SWR ;SETUP FOR A HARDWARE SWICH REGISTER
3300 003772 012737 177570 001156 MOV #DDISP,DISPLAY ;AND A HARDWARE DISPLAY REGISTER
3301 004000 022777 177777 175146 CMP #-1,$SWR ;TRY TO REFERENCE HARDWARE SWR
3302 004006 001012 BNE 66$ ;BRANCH IF NO TIMEOUT TRAP OCCURRED
3303 ;AND THE HARDWARE SWR IS NOT = -1
3304 BR 65$ ;BRANCH IF NO TIMEOUT
3305 004010 000403 BR 65$
3306 004012 012716 004020 64$: MOV #65$,(SP) ;SET UP FOR TRAP RETURN
3307 004016 000002 RTI
3308 004020 012737 000176 001154 65$: MOV #SWREG,SWR ;POINT TO SOFTWARE SWR
3309 004026 012737 000174 001156 MOV #DISPREG,DISPLAY
3310 004034 012637 000004 66$: MOV (SP)+,#ERRVEC ;RESTORE ERROR VECTOR
3311 004040 005037 001212 CLR $PASS ;CLEAR PASS COUNT
3312 004044 132737 000200 001225 BITB #APTSIZE,$ENVM ;TEST USER SIZE UNDER APT
3313 004052 001403 BEQ 67$ ;YES,USE NON-APT SWITCH
3314 004054 012737 001226 001154 MOV #SSWREG,SWR ;NO,USE APT SWITCH REGISTER
3315 004062 67$:

```

3316	004062	012737	000240	000032	NOV	0240,0#ENTVEC+2	:CHANGE ENT PRIORITY TO 4	
3317	004070	012737	000240	000036	NOV	0240,0#TRAPVEC+2	:CHANGE TRAP PRIORITY TO 4	
3318	004076	005227	177777		INC	0-1	:FIRST START ?	
3319	004102	001013			BNE	1\$	:BR IF NOT	
3320	004104	104401	057150		TYPE	TITLE	:NAME AND MANDEC NUMBER	
3321	004110	005737	000042		TST	42	:AUTO ACCEPT OR CHAIN MODE ?	
3322	004114	001006			BNE	1\$	:BR IF EITHER	
3323	004116	122737	000011	000041	CMPS	011,41	:LOADED FROM AN RM03 ?	
3324	004124	001002			BNE	1\$	:BR IF NOT	
3325	004126	104401	057233		TYPE	LOADRV	:INSTRUCT THE OPERATOR ON HOW TO TEST DRIVE 0	
3326	004132	004737	030326		JSR	PC,STKINT	:TURN ON THE KEYBOARD INTERRUPT	
3327					.SBTTL	GET VALUE FOR SOFTWARE SWITCH REGISTER		
3328	004136	005737	000042		TST	0#42	:ARE WE RUNNING UNDER XXDP/ACT?	
3329	004142	001012			BNE	68\$	:BRANCH IF YES	
3330	004144	123727	001224	000001	CMPS	SENV,01	:ARE WE RUNNING UNDER APT?	
3331	004152	001406			BEQ	68\$	:BRANCH IF YES	
3332	004154	023727	001154	000176	CMPS	SMR,#SMREG	:SOFTWARE SWITCH REG SELECTED?	
3333	004162	001005			BNE	69\$	:BRANCH IF NO	
3334	004164	104406			GTSWR		:GET SOFT-SMR SETTINGS	
3335	004166	000403			BR	69\$		
3336	004170	112737	000001	001150	68\$: 69\$:	MOV	01,SAUTOB	:;SET AUTO-MODE INDICATOR
3337	004176							
3338	004176	105737	001224		TST	SENV	:RUN UNDER APT MODE	
3339	004202	001423			BEQ	4\$	:NO, DONOT BOTHER	
3340	004204	105737	001254		TST	SVECT1	:NEW VECTOR ?	
3341	004210	001403			BEQ	.+10	:NOT LOAD IF = 0	
3342	004212	113737	001254	001272	MOV	SVECT1,SRMVEC	:NEW VECTOR	
3343	004220	005737	001260		TST	SBASE	:NEW BASE ADDRESS ?	
3344	004224	001403			BEQ	.+10	:NO	
3345	004226	013737	001260	001270	MOV	SBASE,SRMADR	:NEW BASE ADDRESS	
3346	004234	013737	001270	034316	MOV	SRMADR,RMADR	:LOAD ADDRESS INTO DRIVER	
3347	004242	013737	001272	034320	MOV	SRMVEC,RMVEC	:LOAD VECTOR INTO DRIVER	
3348	004250	000420			BR	2\$		
3349	004252	105737	001150		4\$:	TST	SAUTOB	:AUTO MODE ?
3350	004256	001015			BNE	2\$	:YES	
3351	004260	004737	055676		JSR	PC,BUSADR	:CHECK RH11 BUS ADDRESS	
3352	004264	013737	001270	034316	MOV	SRMADR,RMADR	:RH11 ADDRESS	
3353	004272	013737	001272	034320	MOV	SRMVEC,RMVEC	:RH11 VECTOR ADDRESS	
3354	004300	005227	177777		INC	0-1	:FIRST START ?	
3355	004304	001002			BNE	2\$	:BRANCH IF NOT	
3356	004306	004737	055410		JSR	PC,OPRDAT	:GET THE DATE AND OPERATOR ID	
3357	004312	005037	001314		2\$:	CLR	STATIN	:CLEAR PERFORMANCE SUMMARY TYPEOUT FLAG
3358	004316	012705	001522		MOV	#ORDERQ,R5	:START OF AREA TO CLEAR	
3359	004322	005025			3\$:	CLR	(R5)+	
3360	004324	022705	002102		CMPS	#BLKADR,R5	:LOOK FOR END OF CLEAR AREA	
3361	004330	001374			BNE	3\$	:BR IF NOT FINISHED	
3362	004332	012706	001100		MOV	#STACK,SP	:SETUP THE STACK POINTER	
3363	004336	005037	177776		CLR	PS	:CLEAR THE PROCESSOR STATUS WORD	
3364	004342	013737	001312	001372	MOV	HZ,SIXTEE	:1/60 TH OR 1/50 TH SECOND COUNTER VALUE	
3365	004350	005037	001364		CLR	HOUR	:CLEAR THE HOUR'S COUNTER	
3366	004354	005037	001366		CLR	MINUTE	:CLEAR THE MINUTE'S COUNTER	
3367	004360	005037	001370		CLR	SECOND	:CLEAR THE SECOND'S COUNTER	
3368	004364	005037	001470		CLR	INTRVL+2	:CLEAR INTERVAL COUNTER	
3369	004370	005037	001316		CLR	PACK	:CLEAR THE 'R' OR 'W' COMMAND FLAG	
3370	004374	005037	001360		CLR	CFLAG	:CLEAR THE 'CONTROL C' FLAG	
3371	004400	042737	170000	001464	BIC	#170000,MAXER	:MAKE SURE ERROR LIMITS ARE NOT TOO HIGH	

```

3372
3373
3374
3375 004406 005227 177777          ;ROUTINE TO DETERMINE BUFFER AREA SIZE
3376 004412 001005          SIZMEM: INC      #-1          ;SEE IF TIME TO SIZE MEMORY
3377 004414 004737 055600          BNE      1$          ;BR IF NOT
3378 004420 013737 055674 001354  JSR      PC,SSIZE    ;SEE HOW MUCH MEMORY ON SYSTEM
3379 004426 012737 000001 001700  MOV      $LSTAD,LSTAD ;SAVE THE LAST ADDRESS
3380 004434 012737 057150 001702 1$:  MOV      #1,BUFTBL   ;LOAD NUMBER OF BUFFERS
3381 004442 013737 001354 001704  MOV      #ENDPGM,BUFTBL+2 ;STARTING ADDRESS OF BUFFER
3382 004450 023727 001354 160000  MOV      LSTAD,BUFTBL+4 ;LAST ADDR TO BUFFER ALLOCATION TABLE
3383 004456 101403          CMP      LSTAD,#160000 ;OVER 28K ?
3384 004460 012737 160000 001704  BLOS    2$          ;NO
3385 004466 162737 057150 001704 2$:  MOV      #160000,BUFTBL+4 ;XXDP MAX MEMORY 28K
3386 004474 000241          SUB      #ENDPGM,BUFTBL+4 ;SUBTRACT PROGRAM SPACE
3387 004476 006037 001704          CLC          ;CLEAR THE 'C' BIT
3388 004502 162737 000144 001704  ROR      BUFTBL+4    ;CONVERT TO WORD COUNT
3389 004510 005737 000042          SUB      #100.,BUFTBL+4 ;SAVE ROOM FOR THE 'ABS' LOADER
3390 004514 001403          TST      42          ;LOAD FROM XXDP OR OTHER MONITOR ?
3391 004516 162737 002570 001704  BEQ      3$          ;BR IF LOADED BY PAPER TAPE
3392 004524 005737 001462          SUB      #1400.,BUFTBL+4 ;SUBTRACT 'XXDP' LOADER SIZE
3393 004530 001003          TST      MAXDL       ;VALUE IN 'MAXDL' ?
3394 004532 012737 020000 001462  BNE      4$          ;BR IF VALUE IS
3395 004540 023737 001462 001704 4$:  MOV      #8192.,MAXDL  ;ASSUME FULL TRACK MAXIMUM
3396 004546 103403          CMP      MAXDL,BUFTBL+4 ;IS THAT TOO LARGE ?
3397 004550 013737 001704 001462  BLO      5$          ;BR IF NOT
3398 004556 013737 001704 054354 5$:  MOV      BUFTBL+4,MAXDL ;USE MAX AVAIL MEMORY AS MAX BUFFER SIZE
3399 004556 013737 001704 054354  MOV      BUFTBL+4,PARLST+2 ;VALUE FOR THE PARAMETER TABLE
3400
3401          ;SEE IF THE OPERATOR WANTS TO CHANGE ANY PARAMETERS
3402 004564 105737 001150          LKPAR: TSTB     SAUTOB   ;'XXDP' CHAIN MODE OR 'ACT11' OPERATION ?
3403 004570 001027          BNE      SETVEC      ;BR IF YES
3404 004572 105737 001224          TSTB     $ENV        ;APT STAND ALONE MODE ?
3405 004576 001024          BNE      SETVEC      ;NO
3406 004600 104401 001201          TYPE    ',SCRLF     ;
3407 004604 104401 054450          TYPE    ',ASKPAR    ;ASK FOR PARAMETERS
3408 004610 104411          RDLIN   ;READ THE ENTRY
3409 004612 012605          MOV      (SP)+,R5    ;ADDRESS OF ENTRY TO R5
3410 004614 122715 000131          CMPB    #'Y',(R5)   ;WAS ENTRY A 'Y' (YES)
3411 004620 001013          BNE      SETVEC      ;BR IF NOT 'Y'
3412 004622 012703 054352          ENTPR: MOV      #PARLST,R3 ;PARAMETER TABLE ADDRESS
3413 004626 004737 026420          JSR     PC,PARENT   ;GET THE PARAMETER ENTRY
3414 004632 023727 001462 000004  CMP      MAXDL,#4    ;IS THE 'MAXDL' VALUE OK ?
3415 004640 103003          BHS     SETVEC      ;BR IF IT IS
3416 004642 012737 000004 001462  MOV      #4,MAXDL   ;SET 'MAXDL' TO THE MINIMUM VALUE
3417
3418          ;DISPLAY DRIVE STATUS AND SET UP THE OTHER SYSTEM DEVICES THAT
3419          ; THE PROGRAM WILL USE
3420
3421 004650 004737 022412          SETVEC: JSR      PC,CKCLK ;START THE CLOCK
3422 004654 004737 034334          JSR     PC,RMINIT  ;INITIALIZE THE RMO3 DRIVER
3423 004660 012737 177777 034256  MOV      #-1,SAVEFG ;SET THE SAVE REGISTERS FLAG
3424 004666 062727 177777 000000  ADD      #-1,#0     ;CHECK FOR FIRST START
3425 004674 103004          BCC     11$         ;BR IF FIRST START
3426 004676 032777 000004 174250  BIT      #SW02,$SWR ;TYPEOUT THE DRIVE STATUS TABLE ?
3427 004704 001061          BNE     10$        ;BR IF NOT
    
```

```

3428 004706 005004      11$: CLR      R4          ;DRIVE TABLE POINTER
3429 004710 104401 001201    TYPE      ,SCRLF      ;CR-LF
3430 004714 104401 053135    TYPE      ,SYSTAT     ;TYPE STATUS HEADING
3431 004720
3432 004720 010446      1$:  MOV      R4,-(SP)   ;;SAVE R4 FOR TYPEOUT
3433
3434 004722 104403      TYPOS
3435 004724      002      .BYTE      2          ;;TYPE DRIVE NUMBER
3436 004725      000      .BYTE      0          ;;GO TYPE--OCTAL ASCII
3437 004726 104401 052714    TYPE      LINHSP      ;;TYPE 2 DIGIT(S)
3438 004732 105764 034170    TSTB     DRVSTA(R4)   ;;SUPPRESS LEADING ZEROS
3439 004736 100416      BMI      4$           ;SPACES
3440 004740 001020      BNE      5$           ;CHECK DRIVE'S STATUS
3441 004742 105764 034200    TSTB     DRVSTYP(R4) ;BR IF UNSAFE
3442 004746 001404      BEQ      2$           ;BR IF ONLINE
3443 004750 100006      BPL      3$           ;BR IF OFFLINE OR NONEXISTENT
3444 004752 104401 053054      12$: TYPE      NOTRM    ;BR IF NONEXISTENT
3445 004756 000426      BR       9$           ;BR IF OFFLINE
3446 004760 104401 053071      2$: TYPE      NOTPRS   ;DRIVE NOT AN RMO3
3447 004764 000423      BR       9$           ;CHECK NEXT DRIVE
3448 004766 104401 052763      3$: TYPE      UNTOFF   ;DRIVE NOT PRESENT
3449 004772 000405      BR       6$           ;CHECK NEXT DRIVE
3450 004774 104401 053125      4$: TYPE      NOTSAF   ;DRIVE OFFLINE
3451 005000 000402      BR       6$           ;PRINT DRIVE TYPE
3452 005002 104401 052774      5$: TYPE      ,UNTON   ;DRIVE UNSAFE
3453 005006 104401 052716      6$: TYPE      ,LINSF   ;PRINT DRIVE TYPE
3454 005012 012737 053155 005032    MOV      #RMO3A,8$   ;DRIVE ONLINE
3455 005020 132764 000004 034200    BITB     #BIT02,DRVSTYP(R4) ;SPACES
3456 005026 001751      BEQ      12$         ;ADDRESS OF RMO3 MESSAGE
3457 005030 104401      BR       12$         ;RMO3 ?
3458 005032 000000      7$: TYPE
3459 005034 104401 001201      8$: .WORD      0
3460 005040 005204      9$: TYPE      ,SCRLF   ;BR IF NO TYPE NOT RMO3 MSG
3461 005042 020427 000010    CMP      R4,#8.     ;TYPE THE DRIVE TYPE MESSAGE
3462 005046 001324      BNE      1$           ;MESSAGE ADDRESS HERE
3463 005050 104401 001201      10$: TYPE     ,SCRLF   ;CR-LF
3464 005054 005037 177776    CLR      PS         ;INCREMENT DRIVE NUMBER/TABLE POINTER
3465 005060 000137 005064    JMP      MONTR      ;FINISHED ?
3466
3467 ;SETUP IF 'XXDP' OR 'ACT11' OPERATION ;BR IF NOT
3468
3469 005064 005737 000042    MONTR: TST      42    ;'XXDP' CHAIN MODE OR 'ACT11' AUTO ACCEPT
3470 005070 001405      BEQ      1$         ;BR IF NEITHER
3471 005072 005737 001356    TST      CHGADR     ;200 START ?
3472 005076 003002      BGT      1$         ;YES
3473 005100 004737 024324    JSR      PC,ASGN2   ;ASSIGN DRIVES
3474 005104 005227 177777      1$: INC      #-1     ;FIRST START ?
3475 005110 001011      BNE      2$         ;BR IF NOT
3476 005112 105737 000041    TSTB     2#41      ;LOADED FROM PAPER TAPE ?
3477 005116 001406      BEQ      2$         ;BR IF YES
3478 005120 023727 001354 100000    CMP      LSTAD,#100000 ;MORE THAN 16K ON THE SYSTEM ?
3479 005126 103002      BHIS    2$         ;BR IF YES
3480 005130 104401 057432      TYPE     ,NOLOAD   ;TELL THE OPERATOR THAT THE 'XXDP' LOADER
3481
3482 005134 004737 030326      2$: JSR      PC,$TKINT ;WILL BE OVERWRITTEN
3483 ; FORCE TO TEST PACK FOR 200 START ;INITIALIZE THE KEYBOARD INTERRUPT HANDLER
    
```

```

3484 005140 105737 001150          FOWT1: TSTB      $AUTOB      ;AUTO MODE ?
3485 005144 001412                BEQ          1$              ;NO
3486 005146 012737 000001 001500      MOV          #1,RATIO      ;SPEED UP TEST
3487 005154 012737 077777 001450      MOV          #77777,ENDCON ;SET LSW OF ENDING VALUE
3488 005162 012737 000027 001452      MOV          #27,ENDCON+2  ;SET MSW OF ENDING VALUE
3489 005170 000403                BR           FOWT2          ;START TO WRITE AND TEST
3490 005172 005737 001356          1$: TST          CHGADR      ;START AT 200 ?
3491 005176 003461                BLE          FOWT3          ;NO
3492 005200 005001          FOWT2: CLR          R1        ;DRIVE #
3493 005202 005002                CLR          R2        ;AVAIL TABLE INDEX
3494 005204 005003                CLR          R3        ;DRIVE# X 2
3495 005206 122737 000024 000041      CMPB        #24,41        ;LOAD FROM DRIVE RMO3
3496 005214 001002                BNE          1$              ;NO
3497 005216 005201                INC          R1        ;START FROM DRIVE 1
3498 005220 005723                TST          (R3)+        ;ADJUST INDEX
3499 005222 105761 034170          1$: TSTB        DRVSTA(R1)  ;DRIVE ON LINE ?
3500 005226 003434                BLE          2$              ;NO
3501 005230 016300 002102      MOV          BLKADR(R3),R0 ;LOAD DPB ADDRESS
3502 005234 004737 025212      JSR          PC,CLADPB     ;CLEAR DPB BLOCK
3503 005240 004537 025764      JSR          RS,GETADR     ;RETRIEVE BAD SPOT FILE
3504 005244 000425                BR           2$              ;ERROR RET FROM GETADR RT.
3505 005246 010062 001570      MOV          R0,NEWUNT(R2) ;LOAD DPB ADDRESS TO ABAIL QUEUE
3506 005252 105060 000026      CLRB        $PACK(R0)     ;TEST PACK FLAG
3507 005256 013760 001446 000106      MOV          CYLIMT,MAXCYL(R0) ;UP CYLINDER LIMIT
3508 005264 013760 001444 000112      MOV          TRKLMT,MAXTRK(R0) ;UPPER TRACK LIMIT
3509 005272 013760 001442 000116      MOV          SECLMT,MAXSEC(R0) ;UPPER SECTOR LIMIT
3510 005300 005060 000110      CLR          MINCYL(R0)   ;CLEAR LOWER LIMIT
3511 005304 005060 000114      CLR          MINTRK(R0)  ;CLEAR LOWER LIMIT
3512 005310 005060 000120      CLR          MINSEC(R0)  ;CLEAR LOWER LIMIT
3513 005314 004737 017474      JSR          PC,IRTPK     ;SET UP PARAMETERS
3514 005320 022322          2$: CMP          (R3)+,(R2)+ ;INCREMENT INDEX
3515 005322 005201                INC          R1        ;NEXT DRIVE
3516 005324 022701 000007      CMP          #7,R1        ;ALL DRIVE ASSIGN ?
3517 005330 002334                BGE          1$              ;NO
3518 005332 005037 001316      CLR          PACK        ;TEST PACK FLAG
3519 005336 000137 005524      JMP          MAIN1        ;JUMP TO WAIT PARAMETER AND BUFFER LOOP
3520 005342 104401 054120          FOWT3: TYPE        INTDON   ;TYPE 'INITIALIZE COMPLETE'
3521 005346 000137 005524      JMP          MAIN1        ;START THE PROGRAM
3522                ;;SDOAGN:      JMP          START        ;START AGAIN
3523
3524                ;;*****
3525
3526                .SBTTL  MAIN PROGRAM
3527
3528                ;;*****
3529
3530 005352 005737 001522          MAIN: TST          ORDERQ   ;DON'T DEASSIGN ANY DRIVE IF SYSTEM NOT IDLE
3531 005356 001402                BEQ          1$              ;LET ALL DRIVE FINISH WITH COMMAND
3532 005360 000137 006006      JMP          IDLE
3533 005364 005737 001360          1$: TST          CFLAG     ;KEYBOARD INTERRUPTED ?
3534 005370 001402                BEQ          2$              ;BRANCH IF NOT
3535 005372 004737 023710      JSR          PC,KSR       ;SERVICE THE KEYBOARD
3536 005376
3537 005376 012703 000010          2$: MAINDA: MOV          #8,R3 ;DRIVE COUNTER
3538 005402 012705 001546      MOV          #DUNIT,R5   ;ADDRESS OF 'DROP DRIVE' TABLE
3539 005406 005715          1$: TST          (R5)      ;SEE IF ENTRY AT PRESENT POSITION

```

```

3540 005410 001011          BNE      3$          ;BR IF THERE IS ONE
3541 005412 062705 000002 2$:  ADD      #2,R5      ;INCREMENT TO NEXT TABLE POSITION
3542 005416 005303          DEC      R3          ;DECREMENT DRIVE COUNTER
3543 005420 001372          BNE      1$          ;BR IF MORE TO CHECK
3544 005422 105737 001544  TSTB    ASNLST       ;ANY DRIVES ACTIVE ?
3545 005426 001036          BNE      MAIN1       ;BR IF YES
3546 005430 000137 027250  JMP      $GET42      ;CHECK FOR MONITOR RETURN
3547 005434 012701 001612 3$:  MOV      #AVAIL,R1   ;ADDRESS OF 'AVAILABLE DRIVES' TABLE
3548 005440 005711 4$:  TST      (R1)        ;SEE IF AT END OF TABLE
3549 005442 001405          BEQ      5$          ;BR IF AT END: GO CHECK 'WAIT' TABLE
3550 005444 021115          CMP      (R1),(R5)   ;IS DRIVE IN 'AVAIL' THE ONE TO BE DROPPED
3551 005446 001414          BEQ      7$          ;BR IF YES
3552 005450 062701 000002  ADD      #2,R1        ;INCREMENT 'AVAIL' TABLE ADDRESS
3553 005454 000771          BR       4$          ;CONTINUE LOOKING
3554 005456 012701 001634 5$:  MOV      #WAIT,R1    ;MOVE THE ADDRESS OF THE BUFFER WAIT TABLE
3555 005462 005711 6$:  TST      (R1)        ;AT THE END OF THE 'WAIT' TABLE ?
3556 005464 001752          BEQ      2$          ;BR IF YES: SEE IF ANY MORE 'DROP' REQUESTS
3557 005466 021115          CMP      (R1),(R5)   ;DRIVE IN THE 'WAIT' TABLE ?
3558 005470 001403          BEQ      7$          ;BR IF IT IS
3559 005472 062701 000002  ADD      #2,R1        ;INCREMENT 'WAIT' TABLE ADDRESS
3560 005476 000771 6$:  BR       6$          ;CONTINUE LOOK THROUGH THE 'WAIT' TABLE
3561 005500 011100 7$:  MOV      (R1),R0     ;PUT THE DRIVE'S BLOCK ADDRESS IN R0
3562 005502 104401 053427  TYPE    ,DEASSG      ;TYPE 'DRIVE DEASSIGNED'
3563 005506 004737 022702  JSR     PC,TYPEST    ;TYPE THE DRIVE'S PERFORMANCE SUMMARY
3564 005512 005015          CLR     (R5)        ;CLEAR THE 'DROP DRIVE' TABLE ENTRY
3565 005514 005011          CLR     (R1)        ;REMOVE THE DRIVE FROM THE 'AVAIL' OR 'WAIT' TABLE
3566 005516 004737 017456  JSR     PC,CMPRES    ;COMPRESS THE RESPECTIVE TABLE
3567 005522 000733          BR     2$          ;SEE IF ANY MORE DRIVES
3568
3569          ;LOOK FOR DRIVES TO BE ASSIGNED
3570
3571 005524 012703 000010  MAIN1:  MOV     #8.,R3   ;DRIVE COUNT
3572 005530 005002          CLR     R2          ;'AVAIL' INDEX
3573 005532 005004          CLR     R4          ;ASSIGN LIST INDEX
3574 005534 005005          CLR     R5          ;NEW DRIVE INDEX
3575 005536 005765 001570 1$:  TST     NEWUNT(R5)   ;NEW DRIVE IN THIS POSITION
3576 005542 001006          BNE     3$          ;BR IF THERE IS
3577 005544 062705 000002 2$:  ADD     #2,R5        ;INCREMENT R5
3578 005550 005204          INC     R4          ;INCREMENT ASSIGN INDEX
3579 005552 005303          DEC     R3          ;DECREMENT DRIVE COUNT
3580 005554 001370          BNE     1$          ;BR IF MORE DRIVES
3581 005556 000430          BR     MAIN2        ;START OPERATIONS FOR THE AVAILABLE DRIVES
3582 005560 104401 052755 3$:  TYPE    ,UNMSG      ;'DRIVE'
3583 005564 010446          MOV     R4,-(SP)    ;SAVE R4 FOR TYPEOUT
3584
3585 005566 104403          TYPOS   2          ;TYPE DRIVE NUMBER
3586 005570 002          .BYTE  2          ;GO TYPE--OCTAL ASCII
3587 005571 000          .BYTE  0          ;TYPE 2 DIGIT(S)
3588 005572 104401 053477  TYPE    ,ASGND      ;SUPPRESS LEADING ZEROS
3589 005576 005762 001612 4$:  TST     AVAIL(R2)   ;'STARTED'
3590 005602 001403          BEQ     5$          ;AT END OF AVAILABLE TABLE
3591 005604 062702 000002  ADD     #2,R2        ;BR IF YES
3592 005610 000772          BR     4$          ;INCREMENT AVAILABLE TABLE INDEX
3593 005612 016562 001570 001612 5$:  MOV     NEWUNT(R5),AVAIL(R2) ;CONTINUE LOOKING FOR END OF TABLE
3594 005620 005065 001570          CLR     NEWUNT(R5) ;MOVE ADDR OF DRIVE INTO AVAIL LST
3595 005624 156437 034304 001544  BISB    ATABIT(R4),ASNLST ;TAKE DRIVE OUT OF NEW DRIVE TABLE
;SET DRIVE ASSIGNED INDICATOR

```



```

3596 005632 062702 000002          ADD    #2,R2          ;INCREMENT AVAILABLE TABLE POINTER
3597 005636 000742          BR     25            ;LOOK FOR MORE DRIVES
3598
3599          ;GET PARAMETERS, BUFFER SPACE, AND START ORDERS FOR DRIVES IN
3600          ; THE 'AVAILABLE' QUEUE
3601
3602 005640 005737 001522  MAIN2:  TST    ORDERQ      ;OUTSTANDING BUFFER REQUESTS
3603 005644 001060          BNE    IDLE         ;BR IF THERE ARE
3604 005646 005002          CLR    R2           ;CLEAR DRIVE TABLE POINTER
3605 005650 005762 001612  1$:   TST    AVAIL(R2) ;ANY DRIVES WAITING FOR PARAMETERS
3606 005654 001002          BNE    .+6         ;BRANCH IF ANY
3607 005656 000137 006006          JMP    IDLE         ;BRANCH IF NONE
3608 005662 016200 001612          MOV    AVAIL(R2),R0 ;CONTROL BLOCK ADDR IN R0
3609 005666 005760 000104          TST    $NEXT(R0)   ;PARAMETERS BEEN SELECTED ?
3610 005672 001010          BNE    6$          ;BR IF THEY HAVE
3611 005674 105760 000026          TSTB   $PACK(R0)   ;'R' OR 'M' COMMAND FOR THE DRIVE ?
3612 005700 001403          BEQ    5$          ;BR IF NOT
3613 005702 004737 017474          JSR    PC,WRTPK    ;GET DATA PACK PARAMETERS
3614 005706 000404          BR     7$          ;GET THE BUFFER
3615 005710 004737 016210  5$:   JSR    PC,SELPAR  ;SELECT THE PARAMETERS
3616 005714 004737 017164  6$:   JSR    PC,GETPAR  ;LOAD NEW PARAMETERS
3617 005720 005046  7$:   CLR    -(SP)       ;MAKE ROOM ON THE STACK FOR THE BUFFER ADDR
3618 005722 004737 015420          JSR    PC,GETBUF   ;GET BUFFER
3619 005726 012660 000006          MOV    (SP)+,$BUF(R0) ;MOVE BUFFER ADDR TO DPB
3620 005732 001414          BEQ    8$          ;BR IF '0' ADDR (NO BUFFER)
3621 005734 004737 016004          JSR    PC,FILBUF   ;FILL THE BUFFER
3622 005740 005060 000072          CLR    $FAIR(R0)   ;CLEAR THE 'FAIRNESS' COUNT
3623 005744 004737 016132          JSR    PC,GODRIV   ;PUT CURRENT DPB IN DRIVER
3624 005750 012705 001522          MOV    #ORDERQ,R5 ;ADDRESS OF ORDER QUEUE IN R5
3625 005754 005725          TST    (R5)+       ;END OF QUEUE ?
3626 005756 001376          BNE    .-2         ;BR IF NOT
3627 005760 010045          MOV    R0,-(R5)    ;PUT BLOCK ADDRESS INTO QUEUE
3628 005762 000403          BR     10$        ;CONTINUE LOOKING
3629 005764 062702 000002  8$:   ADD    #2,R2       ;INCREMENT INDEX
3630 005770 000727          BR     1$         ;BRANCH BACK TO FIRE NEXT DRIVE
3631 005772 012701 001612  10$:  MOV    #AVAIL,R1   ;'AVAILABLE' TABLE ADDRESS
3632 005776 060201          ADD    R2,R1       ;FORM ADDRESS OF LAST ENTRY
3633 006000 004737 017456          JSR    PC,CMPRES   ;COMPRESS THE TABLE
3634 006004 000721          BR     1$         ;CONTINUE LOOKING
3635
3636          ;GET BUFFER ASSIGNMENTS FOR DRIVES IN THE 'BUFFER WAIT' QUEUE
3637
3638
3639          ;WAIT FOR AN ORDER TO FINISH
3640
3641 006006 012701 001522  IDLE:  MOV    #ORDERQ,R1  ;ADDRESS OF THE ORDER QUEUE IN R1
3642 006012 012100  1$:   MOV    (R1)+,R0    ;PUT BLOCK ADDRESS INTO R0
3643 006014 001433          BEQ    IDLE1       ;BR IF END OF QUEUE
3644 006016 005760 000016          TST    $STATUS(R0) ;SEE IF DRIVE FINISHED
3645 006022 001773          BEQ    1$         ;BR IF DRIVE NOT FINISHED
3646 006024 162701 000002          SUB    #2,R1       ;CORRECT THE QUEUE POINTER
3647 006030 010146          MOV    R1,-(SP)    ;SAVE THE QUEUE ADDRESS
3648 006032 004737 015262          JSR    PC,STATIS   ;ACCUMULATE STATISTICS FOR DRIVE IN R0
3649 006036 000240          NOP               ;DEBUGGING AID
3650 006040 004737 006260          JSR    PC,PROCES   ;PROCESS END OF ORDER
3651 006044 005037 001362          CLR    BADSEC     ;CLEAR THE BAD TRK/SEC ERROR INDICATOR

```

```

3652 006050 004737 026674      JSR    PC,ABNRML      ;SEE IF ANY DRIVES HAVE TOO MANY ERRORS
3653 006054 004737 026722      JSR    PC,EOP        ;SEE IF ANY DRIVE HAS XFERED 3X10+9 BITS
3654 006060 012601              MOV    (SP)+,R1      ;RESTORE THE ORDER TABLE INDEX
3655 006062 012705 001612      MOV    #AVAIL,R5     ;FIND THE END OF THE 'AVAILABLE' TABLE
3656 006066 005725              2$:   TST    (R5)+      ;END OF THE TABLE ?
3657 006070 001376              BNE    2$            ;BR IF NOT AT END OF LIST
3658 006072 011145              MOV    (R1),-(R5)    ;MOVE THE BLOCK ADDRESS INTO THE TABLE
3659 006074 004737 017456      JSR    PC,COMPRES    ;COMPRESS THE ORDER QUEUE
3660 006100 004737 015554      JSR    PC,RELBUF     ;RESTORE BUFFER
3661 006104              IDLE1:
3662 006104 032777 000004 173042 1$:   BIT    #SW02,JSWR    ;TYPE PERFORMANCE SUMMARY
3663 006112 001007              BNE    2$            ;BR IF NOT
3664 006114 005737 001314      TST    STATIN        ;TIME TO TYPE THE PERFORMANCE SUMMARY ?
3665 006120 001404              BEQ    2$            ;BR IF NOT
3666 006122 005037 001314      CLR    STATIN        ;CLEAR THE INDICATOR
3667 006126 004737 022614      JSR    PC,STATPR    ;TYPE THE SUMMARY
3668 006132 000137 005352      2$:   JMP    MAIN        ;CONTINUE THE LOOP
3669
3670 ;SETUP TO REFORMAT AN ERROR SECTOR
3671
3672 006136 032777 000001 173010 REFMT: BIT    #SW0,JSWR    ;READ ONLY SWITCH SET ?
3673 006144 001044              BNE    REFMTX        ;BR IF IT IS
3674 006146 032777 000200 173000 BIT    #SW7,JSWR    ;SWITCH 7 SET ?
3675 006154 001040              BNE    REFMTX        ;BR IF IT IS
3676 006156 005737 001474      TST    FORMAT        ;WRITE HEADER & DATA ORDERS ALLOWED ?
3677 006162 001435              BEQ    REFMTX        ;BR IF NOT
3678 006164 022760 001465 000270 CMP    #821,$RMDC(RO) ;LEGAL VALUE ?
3679 006172 101431              BLOS   REFMTX        ;NO, NOT FORMAT
3680 006174 004737 022262      JSR    PC,READDR     ;GET CORRECTED SECTOR-TRACK ADDRESSES
3681 006200 012660 000100      MOV    (SP)+,$NCYL(RO) ;CYLINDER
3682 006204 112660 000077      MOV    (SP)+,$NTRK(RO) ;TRACK ADDR TO DPB
3683 006210 112660 000076      MOV    (SP)+,$NSEC(RO) ;SECTOR ADDR TO DPB
3684 006214 012760 000402 000102 MOV    #258,$NWRDL(RO) ;WORD COUNT FOR FORMAT
3685 006222 112760 000003 000074 1$:   MOV    #3,$NCODE(RO) ;COMMAND CODE
3686 006230 004537 016762      JSR    R5,CHKADR     ;AVOID REFORMAT BAD SPOT
3687 006234 000401              BR     2$            ;BRANCH IF NOT ON BAD SPOT
3688 006236 000407              BR     REFMTX        ;BRANCH IF ON BAD SPOT
3689 006240 004737 017122      2$:   JSR    PC,GETPAT    ;GET A PATTERN
3690 006244 110560 000075      MOV    R5,$NPATC(RO) ;PATTERN CODE TO CONTROL BLOCK
3691 006250 012760 177777 000104 MOV    #-1,$NEXTR(RO) ;SET PARAMETERS SELECTED INDICATOR
3692 006256 000207      REFMTX: RTS    PC    ;RETURN
3693
3694 ;PROCESS THE ORDER TERMINATION
3695
3696 006260 111037 001344      PROCES: MOV    (RO),UNIT ;DRIVE NUMBER FOR ANY ERROR MESSAGES
3697 006264 005760 000016      TST    $STATUS(RO)  ;SEE IF DRIVER SIGNALLED AN ERROR
3698 006270 100427              BMI    ERPROC        ;BR IF ERROR
3699 006272 032760 100000 000234 BIT    #BIT15,$RMCS1(RO) ;SEE IF 'SC' SET
3700 006300 001410              BEQ    1$            ;BR IF NOT SET
3701 006302 032760 040000 000234 BIT    #BIT14,$RMCS1(RO) ;SEE IF 'TRE' SET
3702 006310 001017              BNE    ERPROC        ;BR IF SET
3703 006312 032760 040000 000246 BIT    #BIT14,$RMDS(RO) ;SEE IF 'ERR' SET
3704 006320 001013              BNE    ERPROC        ;BR IF SET
3705 006322 004737 012440      1$:   JSR    PC,CKERR     ;NO ERROR, CHECK ERROR BITS ANYWAY
3706 006326 004737 012532      JSR    PC,CKBUS     ;NO ERROR, CHECK BUS ADDR & WC
3707 006332 032777 000002 172614 BIT    #SW01,JSWR    ;DATA COMPARE ?
    
```

```

3708 006340 001002          BNE 2$          ;BR IF NOT
3709 006342 004737 012616 JSR PC,CMPAR    ;NO ERROR, COMPARE DATA
3710 006346 000207          RTS PC          ;RETURN
3711
3712          ;ORDER TERMINATED WITH AN ERROR - PROCESS THE ERROR
3713
3714 006350 032760 000200 000016 ERPROC: BIT #BIT07,STATUS(RO) ;DONE BIT SET ?
3715 006356 001402          BEQ ERPRC1      ;BR IF ORDER DIDN'T COMPLETE NORMALLY
3716 006360 000137 007004          JMP DONE       ;PROCESS ERROR WITH 'DONE' BIT SET
3717
3718          ;PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE NOT' BITS
3719
3720 006364 032760 010000 000016 ERPRC1: BIT #BIT12,STATUS(RO) ;SEE IF DRIVE WAS UNSAFE
3721 006372 001025          BNE PUNSAF     ;BR IF YES
3722 006374 032760 004000 000016 BIT #BIT11,STATUS(RO) ;PARITY ERROR OCCURRED
3723 006402 001055          BNE UCPAR     ;BR IF IT DID
3724 006404 032760 002000 000016 BIT #BIT10,STATUS(RO) ;FATAL PARITY ERROR?
3725 006412 001056          BNE FALPAR    ;BR IF THERE IS ONE
3726 006414 032760 001000 000016 BIT #BIT09,STATUS(RO) ;TIMEOUT?
3727 006422 001076          BNE SWTIM     ;BR IF YES
3728 006424 032760 040002 000016 BIT #BIT14!BIT01,STATUS(RO) ;DRIVE WENT OFFLINE ?
3729 006432 001111          BNE OFLIN    ;BR IF IT DID
3730 006434 032760 000004 000016 BIT #BIT2,STATUS(RO) ;PORT REQUEST TIME OUT ?
3731 006442 001141          BNE PRTIM    ;BR IF IT DID
3732 006444 000207          RTS PC        ;ERROR. RETURN
3733
3734          ;DRIVE IS PERSISTENTLY UNSAFE
3735
3736 006446 104401 001201          PUNSAF: TYPE , $CRLF ;CR-LF
3737 006452 104401 046222          TYPE ,EM12 ;'DRIVE UNSAFE' MESSAGE
3738 006456 104401 053452          TYPE ,DRNUM ;DRIVE NUMBER
3739 006462 013746 001344          MOV UNIT,-(SP) ;SAVE UNIT FOR TYPEOUT
3740          ;TYPE DRIVE NUMBER
3741 006466 104403          TYPOS ;GO TYPE--OCTAL ASCII
3742 006470 002          .BYTE 2 ;TYPE 2 DIGIT(S)
3743 006471 000          .BYTE 0 ;SUPPRESS LEADING ZEROS
3744 006472 104401 001201          TYPE , $CRLF ;CR-LF
3745 006476 004737 020176          JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
3746 006502 104414 046222          DISPLY ,EM12 ;PERSISTENT DEVICE UNSAFE MESSAGE
3747 006506 004737 020242          JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
3748 006512 004737 020650          JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
3749 006516 004737 021320          JSR PC,LINE4 ;PRINT LINE 4 OF THE ERROR MESSAGE
3750 006522 004737 023424          JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3751 006526 004737 021730          JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
3752 006532 000137 026574          JMP DROP     ;DROP THE DRIVE
3753
3754          ;UNCORRECTABLE MASSBUS PARITY ERROR OCCURRED
3755
3756 006536 104401 001201          UCPAR: TYPE , $CRLF ;CR-LF
3757 006542 104401 046124          TYPE ,EM10 ;'UNCORRECTABLE PARITY ERROR' MESSAGE
3758 006546 000404          BR FALPR1   ;FINISH PROCESSING THE ERROR
3759
3760          ;'FATAL' MASSBUS PARITY ERROR OCCURRED
3761
3762 006550 104401 001201          FALPAR: TYPE , $CRLF ;CR-LF
3763 006554 104401 046167          TYPE ,EM11 ;'FATAL PARITY ERROR' MESSAGE
    
```

```

3764 006560 104401 053452      FALPR1: TYPE      DRNUM      ;DRIVE NUMBER
3765 006564 013746 001344      MOV      UNIT,-(SP) ;SAVE UNIT FOR TYPEOUT
3766                                     ;TYPE DRIVE NUMBER
3767 006570 104403      TYPOS      ;GO TYPE--OCTAL ASCII
3768 006572      002      .BYTE      2      ;TYPE 2 DIGIT(S)
3769 006573      000      .BYTE      0      ;SUPPRESS LEADING ZEROS
3770 006574 104401 001201      TYPE      ,SCRFLF ;CR-LF
3771 006600 004737 023424      JSR      PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3772 006604 032777 100000 172342      BIT      #SW15,JSWR ;HALT ON ERROR ?
3773 006612 001401      BEQ      1$      ;BR IF NOT
3774 006614 000000      HALT      ;ERROR HALT
3775 006616 000207      1$:      RTS      PC
3776
3777      ;SOFTWARE TIMEOUT OCCURRED
3778
3779 006620 004737 020176      SWTIM: JSR      PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
3780 006624 104414 046253      DISPLY   EM13      ;PRINT THE TIME OUT MESSAGE
3781 006630 004737 020242      JSR      PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
3782 006634 004737 020650      JSR      PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
3783 006640 004737 021320      JSR      PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
3784 006644 004737 023424      JSR      PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3785 006650 004737 021730      JSR      PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
3786 006654 000207      RTS      PC      ;RETURN
3787
3788      ;DRIVE WENT OFFLINE
3789
3790 006656 104401 001201      OFLIN: TYPE      ,SCRFLF ;CR-LF
3791 006662 104401 046325      TYPE      ,EM14      ;'DRIVE WENT OFFLINE' MESSAGE
3792 006666 104401 053452      TYPE      DRNUM      ;DRIVE NUMBER
3793 006672 013746 001344      MOV      UNIT,-(SP) ;SAVE UNIT FOR TYPEOUT
3794                                     ;TYPE DRIVE NUMBER
3795 006676 104403      TYPOS      ;GO TYPE--OCTAL ASCII
3796 006700      002      .BYTE      2      ;TYPE 2 DIGIT(S)
3797 006701      000      .BYTE      0      ;SUPPRESS LEADING ZEROS
3798 006702 104401 001201      TYPE      ,SCRFLF ;CR-LF
3799 006706 004737 020176      JSR      PC,LINE1 ;PRINT LINE 1 OF THE ERROR MESSAGE
3800 006712 104414 046325      DISPLY   EM14      ;PRINT OFFLINE MESSAGE
3801 006716 004737 020242      JSR      PC,LINE2 ;PRINT LINE 2 OF THE ERROR MESSAGE
3802 006722 004737 020650      JSR      PC,LINE3 ;PRINT LINE 3 OF THE ERROR MESSAGE
3803 006726 004737 021320      JSR      PC,LINE4 ;PRINT LINE 4 OF THE ERROR MESSAGE
3804 006732 004737 023424      JSR      PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3805 006736 004737 021730      JSR      PC,LINE7 ;PRINT LINE 7 OF THE ERROR MESSAGE
3806 006742 000137 026574      JMP      DROP      ;DROP THE DRIVE
3807
3808      ;PORT REQUEST TIMEOUT ERROR
3809
3810 006746 004737 020176      PRTIM: JSR      PC,LINE1 ;TYPE LINE 1 OF THE ERROR MESSAGE
3811 006752 104414 046350      DISPLY   EM15      ;PRINT PORT TIME OUT MESSAGE
3812 006756 004737 020242      JSR      PC,LINE2 ;TYPE LINE 2 OF THE ERROR MESSAGE
3813 006762 004737 020650      JSR      PC,LINE3 ;TYPE LINE 3 OF THE ERROR MESSAGE
3814 006766 004737 021320      JSR      PC,LINE4 ;TYPE LINE 4 OF THE ERROR MESSAGE
3815 006772 004737 023424      JSR      PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3816 006776 004737 021730      JSR      PC,LINE7 ;TYPE LINE 7 OF THE ERROR MESSAGE
3817 007002 000207      RTS      PC      ;RETURN
3818
3819      ;PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE' BITS SET
    
```

```

3820
3821 007004 032760 000030 000016 DONE: BIT #BIT04!BIT03,STATUS(RO) ;UNSAFE OCCURRED
3822 007012 001402 BEQ .+6 ;BR IF NOT
3823 007014 000137 012106 JMP UNSAF ;REPORT UNSAFE
3824 007020 032760 040000 000244 BIT #BIT14,$RMCS2(RO) ;IS 'WCE' SET ?
3825 007026 001402 BEQ .+6 ;BRANCH IF NOT SET
3826 007030 000137 007766 JMP WCKER ;WRITE CHECK ERROR
3827 007034 032760 040000 000246 BIT #BIT14,$RMDS(RO) ;CHECK 'ERR'
3828 007042 001002 BNE 1$ ;BR IF SET
3829 007044 000137 011652 JMP TRFER ;PROCESS 'TRE'
3830 007050 032760 000400 000250 1$: BIT #BIT08,$RMER1(RO) ;'HCRC' SET?
3831 007056 001402 BEQ .+6 ;BR IF NOT
3832 007060 000137 010314 JMP HCRCER ;PROCESS 'HCRC'
3833 007064 032760 000020 000250 BIT #BIT04,$RMER1(RO) ;'FMT' SET?
3834 007072 001402 BEQ .+6 ;BR IF NOT SET
3835 007074 000137 010512 JMP CKFMT ;CHECK FORMAT ERROR
3836 007100 032760 000200 000250 BIT #BIT07,$RMER1(RO) ;'HCE' SET?
3837 007106 001402 BEQ .+6 ;BR IF NOT SET
3838 007110 000137 010706 JMP CKHCE ;CHECK 'HCE' ERROR
3839 007114 032760 020000 000250 BIT #BIT13,$RMER1(RO) ;'OPI' SET?
3840 007122 001402 BEQ .+6 ;BR IF NOT SET
3841 007124 000137 011206 JMP OPIER ;REPORT 'OPI'
3842 007130 032760 000010 000250 BIT #BIT3,$RMER1(RO) ;'PAR' SET?
3843 007136 001402 BEQ .+6 ;BR IF NOT SET
3844 007140 000137 011340 JMP PARER ;REPORT 'PAR'
3845 007144 032760 000040 000250 BIT #BIT5,$RMER1(RO) ;'WCF' SET?
3846 007152 001402 BEQ .+6 ;BR IF NOT SET
3847 007154 000137 012010 JMP WCFER ;REPORT 'WCF'
3848 007160 032760 002000 000250 BIT #BIT10,$RMER1(RO) ;'IAE' SET?
3849 007166 001402 BEQ .+6 ;BR IF NOT SET
3850 007170 000137 011432 JMP IAEER ;REPORT 'IAE'
3851 007174 032760 004000 000250 BIT #BIT11,$RMER1(RO) ;'WLE' SET?
3852 007202 001402 BEQ .+6 ;BR IF NOT SET
3853 007204 000137 011464 JMP WLEER ;REPORT 'WLE'
3854 007210 032760 001000 000250 BIT #BIT9,$RMER1(RO) ;'AOE' SET?
3855 007216 001405 BEQ 2$ ;BR IF NOT SET
3856 007220 032760 002000 000246 BIT #BIT10,$RMDS(RO) ;'LST' SET?
3857 007226 001401 BEQ 2$ ;BR IF NOT SET
3858 007230 000207 RTS PC ;'AOE' & 'LST' SET, EXIT
3859 007232 032760 010000 000250 2$: BIT #BIT12,$RMER1(RO) ;SEE IF 'DTE' SET
3860 007240 001402 BEQ .+6 ;BR IF NOT
3861 007242 000137 011316 JMP DTEER ;REPORT 'DTE' ERROR
3862 007246 005760 000250 TST $RMER1(RO) ;SEE IF 'DCK' SET
3863 007252 100002 BPL .+6 ;BR IF NOT
3864 007254 000137 007312 JMP DCKER ;PROCESS 'DCK'
3865 007260 032760 060000 000276 BIT #BIT14!BIT13,$RMER2(RO) ;'SKI' OR 'OCYL' SET
3866 007266 001006 BNE 3$ ;BRANCH IF SKI, OCYL SET
3867 007270 032760 100000 000276 BIT #BIT15,$RMER2(RO) ;BAD SPOT ?
3868 007276 001004 BNE 4$ ;BRANCH IF SO (NO, OTHER ERROR)
3869 007300 000137 010460 JMP DRVER ;REPORT ERROR
3870 007304 000137 011752 3$: JMP SKIER ;REPORT SKI ERROR
3871 007310 000207 4$: RTS PC ;EXIT FROM ERROR ANALYSIS ROUT.
3872
3873 ;PROCESS DATA ('DCK') CHECK ERROR
3874
3875 007312 022760 010041 000300 DCKER: CMP #10041,$RMEC1(RO) ;VALID POSITION COUNT ?
    
```



```

3932 007626 005737 045550 4$: TST GENDPB+STATUS ;SEE IF FINISHED WITH OFFSET
3933 007632 001775 BEQ 4$ ;BR IF NOT
3934 007634 100324 BPL 2$ ;BR IF NO ERROR PERFORMING OFFSET
3935 007636 004737 022176 5$: JSR PC,LINE8 ;PRINT LINE 8 OF ERROR MESSAGE
3936 007642 004737 023330 6$: JSR PC,INCRD ;INCREMENT 'HARD' ERROR COUNT
3937 007646 004737 023424 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3938 007652 004737 021730 JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
3939 007656 004737 014566 JSR PC,PRTBAD ;PRINT THE BAD SECTOR
3940 007662 000436 BR 13$ ;CLEAN UP AND RETURN
3941 007664 004737 021640 7$: JSR PC,LINE6B ;PRINT LINE 6B OF ERROR MESSAGE
3942 007670 004737 021556 JSR PC,LINE5B ;PRINT LINE 5B OF THE ERROR MESSAGE
3943 007674 004737 023304 8$: JSR PC,INCSOF ;INCREMENT 'SOFT' ERROR COUNT
3944 007700 004737 014026 JSR PC,ECC ;CORRECT THE ERROR USING ECC AND CHECK IT
3945 007704 000407 BR 11$ ;COMPARE THE BUFFER
3946 007706 004737 021654 9$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
3947 007712 000753 BR 6$ ;INCREMENT ERROR COUNT
3948 007714 004737 021632 10$: JSR PC,LINE6A ;PRINT LINE 6A OF ERROR MESSAGE
3949 007720 004737 023304 JSR PC,INCSOF ;INCREMENT 'SOFT' ERROR COUNT
3950 007724 012737 000001 001376 11$: MOV #1,FRSTER ;SET PROCESSING 'DCKER' INDICATOR
3951 007732 004737 012634 JSR PC,CMPCD ;COMPARE THE BUFFER
3952 007736 105737 001377 TSTB FRSTER+1 ;ERROR IN COMPARE ?
3953 007742 100406 BMI 13$ ;BRANCH IF ERROR
3954 007744 004737 023424 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3955 007750 104414 052303 DISPLY LIN9G ;'DATA COMPARE OK' MESSAGE
3956 007754 004737 021730 12$: JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
3957 007760 004737 006136 13$: JSR PC,REFMT ;REFORMAT THE ERROR SECTOR
3958 007764 000207 RTS PC ;RETURN
3959
3960 ;WRITE CHECK ERROR PROCESSING
3961
3962 007766 032760 100000 000250 WCKER: BIT #BIT15,$RMR1(RO) ;SEE IF 'DCK' SET ALSO
3963 007774 001034 BNE 2$ ;BR IF IT IS
3964 007776 004737 020176 JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
3965 010002 104414 046531 DISPLY EM23 ;PRINT WCE & DCK NOT
3966 010006 005037 001346 CLR MASK ;CLEAR ERROR MASK
3967 010012 004737 020242 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
3968 010016 004737 020650 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
3969 010022 004737 021320 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
3970 010026 004737 021410 JSR PC,LINE5 ;PRINT LINE 5 OF ERROR MESSAGE
3971 010032 004737 023424 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
3972 010036 012737 000003 001350 MOV #3,RETRY ;RETRY LIMIT
3973 010044 004737 015134 JSR PC,$RETRY ;RETRY THE OPERATION
3974 010050 000403 BR 1$ ;RETRY UNSUCCESSFUL
3975 010052 004737 021646 JSR PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
3976 010056 000502 BR 8$ ;FINISH PROCESSING THE ERROR
3977 010060 004737 021654 1$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
3978 010064 000506 BR 10$ ;FINISH PROCESSING THE ERROR
3979 010066 004737 020060 2$: JSR PC,SPOTCK ;SEE IF ERROR AT BAD SPOT ON THE PACK
3980 010072 000507 BR 11$ ;EXIT IF AT BAD SPOT ON PACK
3981 010074 004737 020176 JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
3982 010100 012737 046456 010126 MOV #EM22,13$ ;ASSUME THAT EM22 WILL BE PRINTED
3983 010106 032760 040000 000244 BIT #BIT14,$RMC52(RO) ;DID 'WCK' ALSO SET ?
3984 010114 001003 BNE 12$ ;BR IF IT DID
3985 010116 012737 047357 010126 MOV #EM37,13$ ;MESSAGE FOR 'DCK' AND 'WCK' NOT DURING
3986 ;WRITE CHECK
3987 010124 104414 12$: DISPLY ;TYPE THE ERROR MESSAGE
    
```

```

3988 010126 000000      13$: .WORD      0      ;MESSAGE ADDRESS GOES HERE
3989 010130 004737 020242      JSR      PC,LINE2    ;PRINT LINE 2 OF ERROR MESSAGE
3990 010134 004737 020650      JSR      PC,LINE3    ;PRINT LINE 3 OF ERROR MESSAGE
3991 010140 004737 021320      JSR      PC,LINE4    ;PRINT LINE 4 OF ERROR MESSAGE
3992 010144 004737 021410      JSR      PC,LINE5    ;PRINT LINE 5 OF ERROR MESSAGE
3993 010150 032760 000100 000250      BIT      #BIT06,$RMR1(RO) ;ECH SET ALSO ?
3994 010156 001442      BEQ      8$          ;FINISH PROCESSING THE ERROR
3995 010160 012737 000020 001350 3$:      MOV      #16,$RETRY   ;RETRY LIMIT - 16 (10)
3996 010166 004737 016132      4$:      JSR      PC,GODRIV ;RETRY THE ORDER
3997 010172 005760 000016      5$:      TST      $STATUS(RO) ;ORDER FINISHED ?
3998 010176 001775      BEQ      5$          ;BR IF NOT
3999 010200 100405      BMI      6$          ;BR IF ERROR ON ORDER
4000 010202 105237 001351      INCB     RETRY+1     ;INCREMENT RETRY COUNT
4001 010206 004737 021646      JSR      PC,LINE6C   ;PRINT LINE 6C OF ERROR MESSAGE
4002 010212 000431      BR       9$          ;FINISH ERROR PROCESSING
4003 010214 105237 001351 6$:      INCB     RETRY+1     ;INCREMENT RETRY COUNT
4004 010220 123737 001350 001351      CMPB    RETRY,RETRY+1 ;DONE ?
4005 010226 001714      BEQ      1$          ;BR IF AT RETRY LIMIT
4006 010230 032760 100000 000250      BIT      #BIT15,$RMR1(RO) ;'DCK' SET
4007 010236 001407      BEQ      7$          ;BR IF NOT - DIFFERENT ERROR
4008 010240 032760 000100 000250      BIT      #BIT06,$RMR1(RO) ;'ECH' ALSO SET ?
4009 010246 001347      BNE     4$          ;BR IF IT IS, RETRY ORDER
4010 010250 004737 021646      JSR      PC,LINE6C   ;PRINT LINE 6C OF ERROR MESSAGE
4011 010254 000403      BR       8$          ;FINISH PROCESSING ERROR
4012 010256 004737 022176      7$:      JSR      PC,LINE8   ;PRINT LINE 8 - 'DIFFERENT ERROR'
4013 010262 000405      BR       9$          ;FINISH PROCESSING ERROR
4014 010264 004737 023424      8$:      JSR      PC,INCTOT  ;INCREMENT TOTAL ERROR COUNT
4015 010270 004737 021730      JSR      PC,LINE7    ;FINISH THE ERROR MESSAGE
4016 010274 000406      BR       11$         ;EXIT
4017 010276 004737 023424      9$:      JSR      PC,INCTOT  ;INCREMENT TOTAL ERROR COUNT
4018 010302 004737 021730      10$:     JSR      PC,LINE7    ;FINISH THE ERROR MESSAGE
4019 010306 004737 006136      JSR      PC,REFMT    ;REFORMAT THE SECTOR IN ERROR
4020 010312 000207      11$:     RTS      PC      ;RETURN
4021
4022      ;REPORT 'HCRC' ERROR
4023
4024 010314 004737 020060      HCRCER: JSR      PC,SPOTCK ;SEE IF ERROR AT PACK BAD SPOT
4025 010320 000456      BR       3$          ;EXIT IF IT IS
4026 010322 004737 022262      JSR      PC,READDR   ;READ ERROR SECTOR HEADER
4027 010326 004737 015042      JSR      PC,READHD   ;GET THE HEAD INFORMATION
4028 010332 004737 020176      JSR      PC,LINE1    ;PRINT LINE 1 OF ERROR MESSAGE
4029 010336 104414 046404      DISPLY  ,EM20       ;REPORT 'HCRC'
4030 010342 004737 020242      JSR      PC,LINE2    ;PRINT LINE 2 OF ERROR MESSAGE
4031 010346 004737 020650      JSR      PC,LINE3    ;PRINT LINE 3 OF ERROR MESSAGE
4032 010352 004737 021320      JSR      PC,LINE4    ;PRINT LINE 4 OF ERROR MESSAGE
4033 010356 004737 021510      JSR      PC,LINE5A   ;PRINT THE HEADER INFORMATION
4034 010362 032760 040000 000244      BIT      #BIT14,$RMC2(RO) ;'WCE' ERROR ALSO ?
4035 010370 001402      BEQ      1$          ;BR IF NOT
4036 010372 004737 021410      JSR      PC,LINE5    ;DISPLAY WORDS WHICH CAUSED 'WCE'
4037 010376 004737 023304      1$:      JSR      PC,INCSOF   ;INCREMENT 'SOFT' ERROR COUNT
4038 010402 004737 023424      JSR      PC,INCTOT  ;INCREMENT TOTAL ERROR COUNT
4039 010406 012737 000400 001346      MOV      #BIT8,MASK  ;SET ERROR MASK
4040 010414 012737 000003 001350      MOV      #3,$RETRY   ;RETRY LIMIT
4041 010422 004737 015134      JSR      PC,$RETRY   ;RETRY ORDER
4042 010426 000405      BR       2$          ;RETRY NOT SUCCESSFUL
4043 010430 004737 021646      JSR      PC,LINE6C   ;PRINT LINE 6C OF ERROR MESSAGE
    
```



```

4044 010434 004737 021730      JSR    PC,LINE7      ;PRINT LINE 7 OF ERROR MESSAGE
4045 010440 000406              BR     3$            ;EXIT
4046 010442 004737 021654      JSR    PC,LINE6D     ;PRINT LINE 6D OF ERROR MESSAGE
4047 010446 004737 021730      JSR    PC,LINE7      ;PRINT LINE 7 OF ERROR MESSAGE
4048 010452 004737 006136      JSR    PC,REFMT      ;REFORMAT THE ERROR SECTOR
4049 010456 000207              RTS     PC           ;RETURN
4050
4051                               ;REPORT DRIVE ERROR
4052
4053 010460 004737 020176      DRIVER: JSR    PC,LINE1      ;PRINT LINE 1 OF ERROR MESSAGE
4054 010464 104414 047021      DISPLY EM30         ;REPORT DRIVE ERROR
4055 010470 004737 020242      JSR    PC,LINE2      ;PRINT LINE 2 OF ERROR MESSAGE
4056 010474 004737 020650      JSR    PC,LINE3      ;PRINT LINE 3 OF ERROR MESSAGE
4057 010500 004737 023424      JSR    PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
4058 010504 004737 021730      JSR    PC,LINE7      ;PRINT LINE 7 OF ERROR MESSAGE
4059 010510 000207              RTS     PC           ;RETURN
4060
4061                               ;PROCESS FORMAT ('FER') ERROR
4062
4063 010512 032760 000400 000250 CKFMT: BIT    #BIT8,$RMR1(RO) ;'HCRC' SET ON ORIGINAL ERROR ?
4064 010520 001402              BEQ    1$            ;BR IF NOT SET
4065 010522 000137 010314      JMP    HRCRER        ;REPORT HCRC ERROR
4066 010526 004737 022262      1$: JSR    PC,READR    ;GET CORRECTED TRACK & SECTOR ADDRSSES
4067 010532 004737 015042      JSR    PC,READHD     ;READ HEADER
4068 010536 032737 000400 045566 BIT    #BIT8,GENREG+RMR1 ;'HCRC' SET WHEN HEADER READ?
4069 010544 001002              BNE    2$            ;BR IF 'HCRC' SET
4070 010546 000137 011512      JMP    FMTER         ;NO. ERROR IS 'FMT' ONLY
4071 010552 004737 020060      2$: JSR    PC,SPOTCK   ;SEE IF ERROR AT BAD SPOT ON THE PACK
4072 010556 000452              BR     5$            ;EXIT IF IT IS
4073 010560 004737 020176      JSR    PC,LINE1      ;PRINT LINE 1 OF ERROR MESSAGE
4074 010564 104414 046610      DISPLY EM24         ;HEADER READ ERROR - FMT BIT DROPPED UP
4075 010570 004737 020242      JSR    PC,LINE2      ;PRINT LINE 2 OF ERROR MESSAGE
4076 010574 004737 020650      JSR    PC,LINE3      ;PRINT LINE 3 OF ERROR MESSAGE
4077 010600 004737 021320      JSR    PC,LINE4      ;PRINT LINE 4 OF ERROR MESSAGE
4078 010604 032760 040000 000244 BIT    #BIT14,$RMCS2(RO) ;'WCE' ERROR ALSO ?
4079 010612 001402              BEQ    3$            ;BR IF NOT
4080 010614 004737 021410      JSR    PC,LINES      ;DISPLAY WORDS WHICH CAUSED 'WCE'
4081 010620 004737 021510      3$: JSR    PC,LINESA    ;DISPLAY HEADER
4082 010624 004737 023304      JSR    PC,INCSOF     ;INCREMENT SOFT ERROR COUNT
4083 010630 004737 023424      JSR    PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
4084 010634 012737 000020 001346 MOV    #BIT4,MASK    ;SET ERROR MASK
4085 010642 012737 000003 001350 MOV    #3,RETRY      ;RETRY LIMIT
4086 010650 004737 015134      JSR    PC,$RETRY     ;RETRY THE ORDER
4087 010654 000405              BR     4$            ;RETRY NOT SUCCESSFUL
4088 010656 004737 021646      JSR    PC,LINE6C     ;PRINT LINE 6C OF ERROR MESSAGE
4089 010662 004737 021730      JSR    PC,LINE7      ;PRINT LINE 7 OF ERROR MESSAGE
4090 010666 000406              BR     5$            ;EXIT
4091 010670 004737 021654      4$: JSR    PC,LINE6D   ;PRINT LINE 6D OF ERROR MESSAGE
4092 010674 004737 021730      JSR    PC,LINE7      ;PRINT LINE 7 OF ERROR MESSAGE
4093 010700 004737 006136      JSR    PC,REFMT      ;REFORMAT THE ERROR SECTOR
4094 010704 000207              5$: RTS     PC           ;RETURN
4095
4096                               ;PROCESS HEADER COMPARE ('HCE') ERROR
4097
4098 010706 032760 000400 000250 CKHCE: BIT    #BIT8,$RMR1(RO) ;HCRC SET ON ORIGINAL ERROR ?
4099 010714 001402              BEQ    1$            ;BR IF NOT SET

```

```

4100 010716 000137 010314          JMP      HCRCER          ;REPORT HEADER CRC ERROR
4101 010722 004737 022262          JSR      PC,READDR      ;GET CURRENT SECTOR & TRACK ADDRS
4102 010726 004737 015042          JSR      PC,READHD      ;READ HEADER OF CURRENT SECTOR
4103 010732 032737 000400 045566  BIT      #BIT8,GENREG+RMER1 ;'HCRC' SET ?
4104 010740 001016                   BNE     3$              ;BR IF SET
4105 010742 042737 150000 056150  BIC     #150000,CYLDER  ;CLEAR FORMAT,MFG,USER BITS FROM HEADER
4106 010750 026037 000270 056150  CMP     SRMDC(R0),CYLDER ;CORRECT CYLINDER ?
4107 010756 001402                   BEQ     2$              ;BR IF IT IS
4108 010760 000137 011132          JMP      POSER          ;REPORT POSITIONING ERROR
4109 010764 052737 150000 056150  BIS     #150000,CYLDER  ;RESTORE THE FORMAT,MFG,USER BITS
4110 010772 000137 011570          JMP      HCEER          ;REPORT 'HCE' ERROR
4111 010776 004737 020060          JSR      PC,SPOTCK      ;SEE IF ERROR AT BAD SPOT
4112 011002 000452                   BR      6$              ;EXIT IF IT IS
4113 011004 004737 020176          JSR      PC,LINE1       ;PRINT LINE 1 OF ERROR MESSAGE
4114 011010 104414 046656          DISPLY  ,EM25           ;HEADER READ ERROR - 'HCE' SET
4115 011014 004737 020242          JSR      PC,LINE2       ;PRINT LINE 2 OF ERROR MESSAGE
4116 011020 004737 020650          JSR      PC,LINE3       ;PRINT LINE 3 OF ERROR MESSAGE
4117 011024 004737 021320          JSR      PC,LINE4       ;PRINT LINE 4 OF ERROR MESSAGE
4118 011030 032760 040000 000244  BIT     #BIT14,SRMCS2(R0) ;'HCE' ERROR ALSO ?
4119 011036 001402                   BEQ     4$              ;BR IF NOT
4120 011040 004737 021410          JSR      PC,LINES       ;DISPLAY WORDS WHICH CAUSED 'HCE'
4121 011044 004737 021510          JSR      PC,LINESA      ;PRINT LINE 5 OF ERROR MESSAGE
4122 011050 004737 023304          JSR      PC,INCSOF      ;INCREMENT SOFT ERROR COUNT
4123 011054 004737 023424          JSR      PC,INCTOT      ;INCREMENT TOTAL ERROR COUNT
4124 011060 012737 000200 001346  MOV     #BIT7,MASK      ;SET ERROR MASK
4125 011066 012737 000003 001350  MOV     #3,RETRY        ;RETRY LIMIT
4126 011074 004737 015134          JSR      PC,SRETRY      ;RETRY THE ORDER
4127 011100 000405                   BR      5$              ;RETRY NOT SUCCESSFUL
4128 011102 004737 021646          JSR      PC,LINE6C      ;PRINT LINE 6C OF ERROR MESSAGE
4129 011106 004737 021730          JSR      PC,LINE7       ;PRINT LINE 7 OF ERROR MESSAGE
4130 011112 000406                   BR      6$              ;EXIT
4131 011114 004737 021654          JSR      PC,LINE6D      ;PRINT LINE 6D OF ERROR MESSAGE
4132 011120 004737 021730          JSR      PC,LINE7       ;PRINT LINE 7 OF ERROR MESSAGE
4133 011124 004737 006136          JSR      PC,REFMT       ;REFORMAT THE ERROR SECTOR
4134 011130 000207          6$:    RTS      PC          ;RETURN
4135
4136          ;REPORT POSSIBLE POSITIONING ERROR
4137
4138 011132 004737 014764          POSER: JSR      PC,RECALT ;RECALIBRATE
4139 011136 004737 020176          JSR      PC,LINE1       ;PRINT LINE 1 OF ERROR MESSAGE
4140 011142 104414 050153          DISPLY  ,EM51           ;PROGRAM DETECTED POSITIONING ERROR
4141 011146 004737 020242          JSR      PC,LINE2       ;PRINT LINE 2 OF ERROR MESSAGE
4142 011152 004737 020676          JSR      PC,LINE3C      ;PRINT LINE 3C OF ERROR MESSAGE
4143 011156 052737 150000 056150  BIS     #150000,CYLDER  ;RESTORE THE FORMAT BIT
4144 011164 004737 021510          JSR      PC,LINESA      ;PRINT LINE 5A OF THE ERROR MESSAGE
4145 011170 004737 023400          JSR      PC,INCMIS      ;INCREMENT MISPOSITIONING COUNT
4146 011174 004737 023424          JSR      PC,INCTOT      ;INCREMENT TOTAL ERROR COUNT
4147 011200 004737 022056          JSR      PC,LINE7A      ;PRINT LINE 7A OF ERROR MESSAGE
4148 011204 000207          RTS      PC          ;EXIT
4149
4150          ;REPORT 'OPI' ERROR
4151
4152 011206 004737 020060          OPIER: JSR      PC,SPOTCK ;SEE IF ERROR AT BAD SPOT
4153 011212 000207          RTS      PC          ;RETURN IF IT IS
4154 011214 004737 020176          JSR      PC,LINE1       ;PRINT LINE 1 OF ERROR MESSAGE
4155 011220 104414 047053          DISPLY  ,EM31           ;'OPI' ERROR

```

```

4156 011224 004737 020242      JSR    PC,LINE2      ;PRINT LINE 2 OF ERROR MESSAGE
4157 011230 004737 020650      JSR    PC,LINE3      ;PRINT LINE 3 OF ERROR MESSAGE
4158 011234 004737 021320      JSR    PC,LINE4      ;PRINT LINE 4 OF ERROR MESSAGE
4159 011240 004737 023424      JSR    PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
4160 011244 012737 020000      MOV    #BIT13,MASK   ;ERROR MASK
001346
4161 011252 012737 000003      MOV    #3,RETRY      ;RETRY LIMIT
001350 OPIER1:
4162 011260 004737 015134      JSR    PC,$RETRY     ;RETRY THE ORDER
4163 011264 000405                BR     1$            ;RETRY UNSUCCESSFUL
4164 011266 004737 021646      JSR    PC,LINE6C     ;PRINT LINE 6C OF ERROR MESSAGE
4165 011272 004737 021730      JSR    PC,LINE7      ;PRINT LINE 7 OF ERROR MESSAGE
4166 011276 000207                RTS    PC            ;EXIT
4167 011300 004737 021654      1$: JSR    PC,LINE6D   ;PRINT LINE 6D OF ERROR MESSAGE
4168 011304 004737 021730      JSR    PC,LINE7      ;PRINT LINE 7 OF ERROR MESSAGE
4169 011310 004737 006136      JSR    PC,REFMT      ;REFORMAT THE ERROR SECTOR
4170 011314 000207                RTS    PC            ;RETURN
4171
4172                ;REPORT 'DTE' ERROR
4173
4174 011316 004737 020060      DTEER: JSR    PC,SPOTCK ;SEE IF ERROR AT BAD SPOT
4175 011322 000207                RTS    PC            ;RETURN IF IT IS
4176 011324 004737 020176      JSR    PC,LINE1      ;PRINT LINE 1 OF ERROR MESSAGE
4177 011330 104414 047116      DISPLY ,EM32         ;'DTE' ERROR
4178 011334 000137 007432      JMP    DCKER1        ;FINISH PROCESSING THE 'DTE' ERROR
4179
4180                ;REPORT 'PAR' ERROR
4181
4182 011340 004737 020176      PARER: JSR    PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4183 011344 104414 047151      DISPLY ,EM33         ;REPORT 'PAR'
4184 011350 004737 020242      JSR    PC,LINE2      ;PRINT LINE 2 OF ERROR MESSAGE
4185 011354 004737 020754      JSR    PC,LINE3E     ;PRINT LINE 3E OF ERROR MESSAGE
4186 011360 004737 021320      JSR    PC,LINE4      ;PRINT LINE 4 OF ERROR MESSAGE
4187 011364 004737 023424      JSR    PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
4188 011370 012737 000010      MOV    #BIT03,MASK   ;ERROR MASK
001346
4189 011376 012737 000003      MOV    #3,RETRY      ;RETRY LIMIT
001350
4190 011404 004737 015134      JSR    PC,$RETRY     ;RETRY ORDER
4191 011410 000405                BR     2$            ;RETRY UNSUCCESSFUL
4192 011412 004737 021646      JSR    PC,LINE6C     ;RETRY SUCCESSFUL
4193 011416 004737 021730      1$: JSR    PC,LINE7    ;PRINT LINE 7 OF ERROR MESSAGE
4194 011422 000207                RTS    PC            ;EXIT
4195 011424 004737 021654      2$: JSR    PC,LINE6D   ;PRINT LINE 6D OF ERROR MESSAGE
4196 011430 000772                BR     1$            ;FINISH ERROR MESSAGE
4197
4198                ;REPORT 'IAE' ERROR
4199
4200 011432 004737 020176      IAEER: JSR    PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4201 011436 104414 047270      DISPLY ,EM35         ;REPORT 'IAE'
4202 011442 004737 020242      JSR    PC,LINE2      ;PRINT LINE 2 OF ERROR MESSAGE
4203 011446 004737 021042      JSR    PC,LINE3F     ;PRINT LINE 3F OF ERROR MESSAGE
4204 011452 004737 023424      JSR    PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
4205 011456 004737 021730      JSR    PC,LINE7      ;PRINT LINE 7 OF ERROR MESSAGE
4206 011462 000207                RTS    PC            ;RETURN
4207
4208                ;REPORT 'WLE' ERROR
4209
4210 011464 004737 020176      WLEER: JSR    PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4211 011470 104414 047326      DISPLY ,EM36         ;REPORT 'WLE'
    
```

```

4212 011474 004737 020242      JSR    PC,LINE2      ;PRINT LINE 2 OF ERROR MESSAGE
4213 011500 004737 023424      JSR    PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
4214 011504 004737 021730      JSR    PC,LINE7     ;PRINT LINE 7 OF ERROR MESSAGE
4215 011510 000207              RTS    PC            ;RETURN
4216
4217      ;REPORT FORMAT ERROR
4218
4219 011512 004737 020176      FMTER: JSR    PC,LINE1      ;PRINT LINE 1 OF ERROR MESSAGE
4220 011516 104414 046737      DISPLY  EM26          ;FORMAT ERROR
4221 011522 004737 020242      JSR    PC,LINE2     ;PRINT LINE 2 OF ERROR MESSAGE
4222 011526 004737 020650      JSR    PC,LINE3     ;PRINT LINE 3 OF ERROR MESSAGE
4223 011532 004737 021320      JSR    PC,LINE4     ;PRINT LINE 4 OF ERROR MESSAGE
4224 011536 032760 040000 000244  BIT    #BIT14,SRMCS2(R0) ;'WCE' ERROR ALSO ?
4225 011544 001402              BEQ    1$            ;BR IF NOT
4226 011546 004737 021410      JSR    PC,LINES     ;DISPLAY WORDS WHICH CAUSED 'WCE'
4227 011552 004737 021510      1$:  JSR    PC,LINE5A    ;PRINT LINE 5A OF ERROR MESSAGE
4228 011556 004737 023424      JSR    PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
4229 011562 004737 021730      JSR    PC,LINE7     ;PRINT LINE 7 OF ERROR MESSAGE
4230 011566 000207              RTS    PC
4231
4232      ;REPORT HEADER COMPARE ERROR
4233
4234 011570 004737 020176      HCEER: JSR    PC,LINE1      ;PRINT LINE 1 OF ERROR MESSAGE
4235 011574 104414 046764      DISPLY  EM27          ;HEADER COMPARE ERROR
4236 011600 004737 020242      JSR    PC,LINE2     ;PRINT LINE 2 OF ERROR MESSAGE
4237 011604 004737 020650      JSR    PC,LINE3     ;PRINT LINE 3 OF ERROR MESSAGE
4238 011610 004737 021320      JSR    PC,LINE4     ;PRINT LINE 4 OF ERROR MESSAGE
4239 011614 032760 040000 000244  BIT    #BIT14,SRMCS2(R0) ;'WCE' ERROR ALSO ?
4240 011622 001402              BEQ    1$            ;BR IF NOT
4241 011624 004737 021410      JSR    PC,LINES     ;DISPLAY WORDS WHICH CAUSED 'WCE'
4242 011630 004737 021510      1$:  JSR    PC,LINE5A    ;PRINT LINE 5A OF ERROR MESSAGE
4243 011634 004737 023424      JSR    PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
4244 011640 004737 021730      JSR    PC,LINE7     ;PRINT LINE 7 OF ERROR MESSAGE
4245 011644 004737 006136      JSR    PC,REFMT     ;REFORMAT THE ERROR SECTOR
4246 011650 000207              RTS    PC            ;RETURN
4247
4248      ;PROCESS CONTROL/INTERFACE TRANSFER ERROR
4249
4250 011652 004737 020176      TRFER: JSR    PC,LINE1      ;PRINT LINE 1 OF ERROR MESSAGE
4251 011656 104414 047441      DISPLY  EM40          ;RH11 OR UNIBUS TRANSFER ERROR
4252 011662 004737 020242      JSR    PC,LINE2     ;PRINT LINE 2 OF ERROR MESSAGE
4253 011666 004737 020650      JSR    PC,LINE3     ;PRINT LINE 3 OF ERROR MESSAGE
4254 011672 004737 021320      JSR    PC,LINE4     ;PRINT LINE 4 OF ERROR MESSAGE
4255 011676 004737 023424      JSR    PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
4256 011702 032760 121400 000244  BIT    #BIT15:BIT13:BIT9:BIT8,SRMCS2(R0) ;'DLT','UPE','MXF','MDPE' SET ?
4257 011710 001415              BEQ    2$            ;BR IF NONE SET
4258 011712 012737 000003 001350  MOV    #3,RETRY      ;RETRY LIMIT
4259 011720 005037 001346      CLR    MASK         ;CLEAR ERROR MASK
4260 011724 004737 015134      JSR    PC,$RETRY    ;RETRY THE OPERATION
4261 011730 000403              BR     1$            ;RETURN HERE IF RETRY UNSUCCESSFUL
4262 011732 004737 021646      JSR    PC,LINE6C    ;PRINT LINE 6C OF ERROR MESSAGE
4263 011736 000402              BR     2$            ;FINISH THE ERROR REPORT
4264 011740 004737 021654      1$:  JSR    PC,LINE6D    ;PRINT LINE 6D OF ERROR MESSAGE
4265 011744 004737 021730      2$:  JSR    PC,LINE7     ;PRINT LINE 7 OF ERROR MESSAGE
4266 011750 000207              RTS    PC
4267

```

```

4268 ;PROCESS 'SKI' OR 'OCYL' ERRORS
4269
4270 011752 004737 020176 SKIER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4271 011756 104414 050115 DISPLY EM50 ;'SKI' OR 'OCYL' ERROR
4272 011762 004737 020242 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4273 011766 004737 020664 JSR PC,LINE3B ;PRINT LINE 3B OF ERROR MESSAGE
4274 011772 004737 023424 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4275 011776 004737 023354 JSR PC,INCKI ;INCREMENT 'SKI' OR 'OCYL' ERROR COUNT
4276 012002 004737 022056 JSR PC,LINE7A ;PRINT LINE 7A OF ERROR MESSAGE
4277 012006 000207 RTS PC
    
```

```

4278 ;REPORT WRITE CLOCK FAILURE ('WCF')
4279
4280
4281 012010 004737 020176 WCFER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4282 012014 104414 047226 DISPLY EM34 ;REPORT WRITE CLOCK FAILURE
4283 012020 004737 020242 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4284 012024 004737 020656 JSR PC,LINE3A ;PRINT LINE 3A OF ERROR MESSAGE
4285 012030 004737 021320 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
4286 012034 004737 023424 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4287 012040 004737 014566 JSR PC,PRTBAD ;SEE IF BAD SECTOR TO BE PRINTED
4288 012044 012737 000003 001350 MOV #3,RETRY ;RETRY COUNT
4289 012052 012737 000040 001346 MOV #BIT05,MASK ;ERROR MASK
4290 012060 004737 015134 JSR PC,SRETRY ;RETRY THE ORDER
4291 012064 000405 BR 2$ ;RETURN HERE IF RETRY UNSUCCESSFUL
4292 012066 004737 021646 JSR PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
4293 012072 004737 021730 1$: JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4294 012076 000207 RTS PC
4295 012100 004737 021654 2$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
4296 012104 000772 BR 1$
    
```

```

4297 ;PROCESS DRIVE UNSAFE ERROR
4298
4299
4300 012106 004737 020176 UNSAF: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4301 012112 104414 050216 DISPLY EM60 ;REPORT DRIVE UNSAFE
4302 012116 004737 020242 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4303 012122 004737 020650 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
4304 012126 004737 023424 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4305 012132 012737 000003 001350 MOV #3,RETRY ;RETRY COUNT
4306 012140 004737 015134 JSR PC,SRETRY ;RETRY THE ORDER
4307 012144 000403 BR 1$ ;RETRY WAS UNSUCCESSFUL
4308 012146 004737 021646 JSR PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
4309 012152 000402 BR 2$ ;CONTINUE WITH ERROR REPORT
4310 012154 004737 021654 1$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
4311 012160 004737 021730 2$: JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4312 012164 000207 RTS PC ;RETURN
    
```

```

4313 ;REPORT AN 'UNKNOWN' DATA PATTERN
4314
4315
4316 012166 105737 001376 NOMTCH: TSTB FRSTER ;FIRST ERROR IN THE SECTOR ?
4317 012172 001013 BNE 1$ ;BR IF NOT OR IF PROCESSING 'DCKER'
4318 012174 004737 020176 JSR PC,LINE1 ;TYPE LINE 1 OF ERROR MESSAGE
4319 012200 104414 047624 DISPLY EM43 ;'CAN'T MATCH DATA WITH PATTERN'
4320 012204 004737 020242 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4321 012210 004737 020656 JSR PC,LINE3A ;PRINT LINE 3A OF ERROR MESSAGE
4322 012214 004737 021320 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
4323 012220 000404 BR 2$ ;CONTINUE PROCESSING ERROR
    
```

```

4324 012222 104414 047624 1S:  DISPLY ,EM43 ;'CAN'T MATCH DATA WITH PATTERN'
4325 012226 104414 001201  DISPLY ,SCRLF ;CR-LF
4326 012232 104414 052233 2S:  DISPLY ,LIN9I ;HEADER FOR DATA PRINTOUT
4327 012236 010146  MOV R1,-(SP) ;ADDRESS OF WORD 1
4328 012240 004737 022210 JSR PC,LIN0CT ;TYPE WORD 1
4329 012244 104414 052716  DISPLY ,LINSF ;SPACES
4330 012250 012146  MOV (R1)+,-(SP) ;ADDRESS OF WORD 1
4331 012252 004737 022210 JSR PC,LIN0CT ;TYPE WORD 1
4332 012256 104414 001201  DISPLY ,SCRLF ;CR-LF
4333 012262 010146  MOV R1,-(SP) ;ADDRESS OF WORD 2
4334 012264 004737 022210 JSR PC,LIN0CT ;TYPE WORD 2
4335 012270 104414 052716  DISPLY ,LINSF ;SPACES
4336 012274 012146  MOV (R1)+,-(SP) ;ADDRESS OF WORD 2
4337 012276 004737 022210 JSR PC,LIN0CT ;TYPE WORD 2
4338 012302 104414 001201  DISPLY ,SCRLF ;CR-LF
4339 012306 010146  MOV R1,-(SP) ;ADDRESS OF WORD 3
4340 012310 004737 022210 JSR PC,LIN0CT ;TYPE WORD 3
4341 012314 104414 052716  DISPLY ,LINSF ;SPACES
4342 012320 012146  MOV (R1)+,-(SP) ;ADDRESS OF WORD 3
4343 012322 004737 022210 JSR PC,LIN0CT ;TYPE WORD 3
4344 012326 104414 001201  DISPLY ,SCRLF ;CR-LF
4345 012332 010146  MOV R1,-(SP) ;ADDRESS OF WORD 4
4346 012334 004737 022210 JSR PC,LIN0CT ;TYPE WORD 4
4347 012340 104414 052716  DISPLY ,LINSF ;SPACES
4348 012344 012146  MOV (R1)+,-(SP) ;ADDRESS OF WORD 4
4349 012346 004737 022210 JSR PC,LIN0CT ;TYPE WORD 4
4350 012352 104414 001201  DISPLY ,SCRLF ;CR-LF
4351 012356 062701 000770  ADD #(<252.*2.>,R1 ;INCREMENT BUFFER POINTER
4352 012362 162737 000400 001410  SUB #256,CMCNT ;ADJUST WORD COUNT FOR MATCH
4353 012370 132760 000001 000024  BITB #BIT00,$CODE(R0) ;HEADER OPERATION INVOLVED ?
4354 012376 001405  BEQ 3S ;NO
4355 012400 062701 000004  ADD #4,R1 ;ADJUST BUFFER ADDRESS
4356 012404 162737 000002 001410  SUB #2,CMCNT ;ADJUST WORD COUNT
4357 012412 005002 3S:  CLR R2 ;CLEAR 'WORDS TO COMPARE' COUNT IN R2
4358 012414 112737 000001 001376  MOVB #1,FRSTER ;SET 'NOT FIRST ERROR' INDICATOR
4359 012422 112737 177777 001377  MOVB #-1,FRSTER+1 ;SET ERROR FOUND INDICATOR
4360 012430 013737 001472 001406  MOV CMLMT,LIMIT ;RESET THE COMPARE ERROR TIMEOUT LIMIT
4361 012436 000207  RTS PC ;RETURN
4362
4363 ;CHECK ERROR BITS IN THE RH11 & RMD3 REGISTERS
4364
4365 012440 032760 060000 000234 CKERR: BIT #60000,$RMCS1(R0) ;SEE IF 'TRE' OR 'MCPE' SET
4366 012446 001012  BNE 1S ;BR IF EITHER SET
4367 012450 032760 177400 000244  BIT #177400,$RMCS2(R0) ;SEE IF ERROR BITS IN CS2 SET
4368 012456 001006  BNE 1S ;BR IF ANY SET
4369 012460 005760 000250  TST $RMER1(R0) ;ANY BITS SET IN ER1
4370 012464 001003  BNE 1S ;BR IF ANY SET
4371 012466 005760 000276  TST $RMER2(R0) ;ANY BITS SET IN ER2 ?
4372 012472 001416  BEQ 2S ;BR IF NONE SET
4373 012474 004737 020176 1S:  JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4374 012500 104414 047671  DISPLY ,EM44 ;ERROR BITS SET, BUT 'SC' OR 'TRE' NOT SET
4375 012504 004737 020242  JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4376 012510 004737 020650  JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
4377 012514 004737 021320  JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
4378 012520 004737 023424  JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4379 012524 004737 021730  JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE

```

```

4380 012530 000207      2S:   RTS      PC          ;RETURN
4381
4382                      ;CHECK BUS ADDRESS REGISTER & WORD COUNT REGISTER
4383
4384 012532 005760 000236  CKBUS:  TST      $RMWC(RO)    ;CHECK WORD COUNT
4385 012536 001010                BNE      1$                ;BR IF NOT ZERO
4386 012540 016046 000020                MOV      $WRDL(RO),-(SP)  ;WORD LENGTH
4387 012544 006316                ASL      (SP)              ;CHANGE INTO BYTE COUNT
4388 012546 066016 000006                ADD      $BUF(RO), (SP)  ;ADD THE STARTING LOCATION
4389 012552 022660 000240                CMP      (SP)+,$RMBA(RO) ;BUFFER ADDRESS PROPER ?
4390 012556 001416                BEQ      2$                ;BR IF OK
4391 012560 004737 020176      1$:   JSR      PC,LINE1      ;PRINT LINE 1 OF ERROR MESSAGE
4392 012564 104414 047477                DISPLY   EM41             ;BUS ADDRESS OR WORD COUNT INCORRECT
4393 012570 004737 020242                JSR      PC,LINE2      ;PRINT LINE 2 OF ERROR MESSAGE
4394 012574 004737 020706                JSR      PC,LINE3D     ;PRINT LINE 3D OF ERROR MESSAGE
4395 012600 004737 021320                JSR      PC,LINE4      ;PRINT LINE 4 OF ERROR MESSAGE
4396 012604 004737 023424                JSR      PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
4397 012610 004737 021730                JSR      PC,LINE7      ;PRINT LINE 7 OF ERROR MESSAGE
4398 012614 000207      2$:   RTS      PC
4399
4400                      ;COMPARE THE BUFFER
4401
4402 012616 132760 000004 000024  CMPAR:  BITB     #BIT02,$CODE(RO) ;SEE IF READ ORDER
4403 012624 001001                BNE      1$                ;BR IF IT IS
4404 012626 000207                RTS      PC                ;RETURN
4405 012630 005037 001376      1$:   CLR      FRSTER         ;CLEAR 'FIRST ERROR' INDICATOR
4406 012634 032777 000002 166312  CMPARD:  BIT      #SW01,$SWR  ;IS SWITCH 1 SET?
4407 012642 001401                BEQ      1$                ;BR IF NOT
4408 012644 000207                RTS      PC                ;YES, DON'T COMPARE
4409 012646 005037 001404      1$:   CLR      ERCTR         ;CLEAR THE ERROR COUNTER
4410 012652 016001 000006                MOV      $BUF(RO),R1     ;BUFFER ADDRESS
4411 012656 016037 000020 001410  MOV      $WRDL(RO),CMCNT ;WORD COUNT TO WORKING LOCATION
4412 012664 066037 000236 001410  ADD      $RMWC(RO),CMCNT ;CALCULATE ACTUAL WORDS TRANSFERED
4413 012672 016037 000012 001412  MOV      $CYL(RO),CMCYL  ;CYLINDER ADDRESS WORKING LOCATION
4414 012700 052737 010000 001412  BIS      #BIT12,CMCYL    ;SET FORMAT BIT
4415 012706 052737 140000 001412  BIS      #140000,CMCYL  ;SET MFG AND USER BITS
4416 012714 016037 000010 001414  MOV      $SEC(RO),CMSEC  ;SECTOR & TRACK ADDRESSES TO WORKING LOCNS
4417 012722 013737 001472 001406  MOV      CMPLMT,LIMIT    ;DISPLAY LIMIT
4418 012730 005237 001406                INC      LIMIT           ;CONVERT PARAMETER INTO LIMIT VALUE
4419 012734 012737 177777 001374  CMSTR:  MOV      #-1,ZROIND     ;CLEAR THE 'ZERO'S' INDICATOR
4420 012742 005037 001400                CLR      SAVER1          ;CLEAR THE R1 SAVE WORD
4421 012746 005037 001402                CLR      SAVER5          ;CLEAR THE R5 SAVE WORD
4422 012752 023760 001410 000022  CMP      CMCNT,$SSEC(RO) ;IS BUFFER SIZE GREATER THAN ONE SECTOR ?
4423 012760 101005                BHI      1$                ;BR IF IT IS
4424 012762 013702 001410                MOV      CMCNT,R2        ;LESS THAN, USE REMAINING BUFFER
4425 012766 005037 001410                CLR      CMCNT           ;SET COUNTER TO 0
4426 012772 000405                BR       2$
4427 012774 016002 000022      1$:   MOV      $SSEC(RO),R2    ;COMPARE SECTOR
4428 013000 166037 000022 001410  SUB      $SSEC(RO),CMCNT ;DECREMENT WORD COUNT
4429 013006 126027 000024 000005  2$:   CMPB     $CODE(RO),#5    ;READ HEADER & DATA?
4430 013014 001023                BNE      CMDAT           ;BR IF NOT
4431 013016 023721 001412      CMHED:  CMP      CMCYL,(R1)+    ;CHECK CYLINDER
4432 013022 001402                BEQ      1$                ;BR IF COMPARE OK
4433 013024 004737 013052                JSR      PC,CMSTR2       ;REPORT ERROR
4434 013030 023721 001414      1$:   CMP      CMSEC,(R1)+    ;COMPARE SECTOR & TRACK
4435 013034 001402                BEQ      4$                ;BR IF EQ
    
```

4436	013036	004737	013052		JSR	PC, CMSTR2	REPORT ERROR	
4437	013042	162702	000002	4\$:	SUB	#2, R2	SUBTRACT HEADER LENGTH FROM SIZE	
4438	013046	003564			BLE	CMPRX	BR IF FINISHED	
4439	013050	000405			BR	CMDAT	COMPARE THE DATA PORTION	
4440	013052	005237	001404	CMSTR2:	INC	ERCTR	INCREMENT THE ERROR COUNT	
4441	013056	004737	013426		JSR	PC, CMPRT	REPORT THE COMPARISON ERROR	
4442	013062	000207			RTS	PC	CHECK THE REST OF THE HEADER	
4443	013064	004737	013750	CMDAT:	JSR	PC, MATCH	FIND THE PATTERN	
4444	013070	000403			BR	2\$	FOUND A PATTERN	
4445	013072	004737	012166		JSR	PC, NOMTCH	RETURN HERE IF NO MATCH WITH PATTERN MADE	
4446	013076	000456			BR	8\$	BYPASS COMPARE ROUTINE	
4447	013100	011405		2\$:	MOV	(R4), R5	ADDRESS OF PATTERN ADDRESS IN R4	
4448	013102	012703	000020		MOV	#20, R3	R3 IS PATTERN POS COUNTER	
4449	013106	022125		3\$:	CMP	(R1)+, (R5)+	COMPARE BUFFER WITH PATTERN	
4450	013110	001016			BNE	5\$	BR IF NOT EQUAL	
4451	013112	005737	001404		TST	ERCTR	ERRORS DETECTED ?	
4452	013116	001406			BEQ	4\$	BR IF NO ERRORS	
4453	013120	032777	000010	166026	BIT	#SW3, JSWR	SWITCH 3 SET ?	
4454	013126	001402			BEQ	4\$	BR IF NOT SET	
4455	013130	004737	013426		JSR	PC, CMPRT	DISPLAY THE WORD	
4456	013134	005302		4\$:	DEC	R2	DECREMENT SIZE COUNT	
4457	013136	003436			BLE	8\$	BR WHEN AT END	
4458	013140	005303			DEC	R3	DECREMENT PATT POS COUNT	
4459	013142	001361			BNE	3\$	BR IF NOT AT END OF PATT	
4460	013144	000755			BR	2\$	RESTART THE PATTERN	
4461	013146	005761	177776	5\$:	TST	-2(R1)	IS MISCOMPARED CHARACTER=0	
4462	013152	001410			BEQ	6\$	BR IF YES	
4463	013154	012737	177777	001374	MOV	#-1, ZROIND	SET NON-ZERO MISCOMPARED INDICATOR	
4464	013162	005237	001404		INC	ERCTR	INCREMENT THE ERROR COUNTER	
4465	013166	004737	013426		JSR	PC, CMPRT	REPORT ERROR	
4466	013172	000760			BR	4\$	CONTINUE COMPARE	
4467	013174	105737	001376	6\$:	TSTB	FRSTER	FIRST ERROR?	
4468	013200	100407			BMI	7\$	BR IF NOT	
4469	013202	005037	001374		CLR	ZROIND	SET THE ZERO INDICATOR	
4470	013206	010137	001400		MOV	R1, SAVER1	SAVE CURRENT R1	
4471	013212	010537	001402		MOV	R5, SAVERS	SAVE CURRENT R5	
4472	013216	000746			BR	4\$	CONTINUE COMPARE	
4473	013220	005737	001374	7\$:	TST	ZROIND	ANY MISCOMPARISONS NOT ZEROS ?	
4474	013224	001743			BEQ	4\$	BR IF NONE-ALL ERRORS=ZERO	
4475	013226	004737	013426		JSR	PC, CMPRT	REPORT ERROR	
4476	013232	000740			BR	4\$	CONTINUE COMPARING	
4477	013234	023727	001410	000004	8\$:	CMP	CMCNT, #4	LAST 3 WORDS ?
4478	013242	002466			BLT	CMPRX	YES	
4479	013244	126027	000024	000005	CMPB	\$CODE(R0), #5	READ HEAD AND DATA ?	
4480	013252	001414			BEQ	9\$	YES	
4481	013254	013702	001410	13\$:	MOV	CMCNT, R2	SET COUNTER = REMAIN BUFFER LENGTH	
4482	013260	020227	000004		CMP	R2, #4	LAST 3 WORDS ?	
4483	013264	002455			BLT	CMPRX	YES, EXIT	
4484	013266	162737	000400	001410	SUB	#256., CMCNT	GREATER THAN A SECTOR ?	
4485	013274	003673			BLE	CMDAT	NO, RETURN TO COMPARE LOOP	
4486	013276	012702	000400		MOV	#256., R2	SET COUNTER = SECTOR SIZE	
4487	013302	000670			BR	CMDAT	RETURN TO COMPARE LOOP	
4488	013304	105237	001414	9\$:	INCB	CMSEC	INCREMENT COUNTER	
4489	013310	123727	001414	000040	CMPB	CMSEC, #32.	MAX SECTOR # ?	
4490	013316	103421			BLO	10\$	NO	
4491	013320	105037	001414		CLRB	CMSEC	RESET SECTOR #	



4492	013324	105237	001415		INCB	CMTRK	; INCREMENT TRACK #
4493	013330	123727	001415	000005	CMPB	CMTRK, #5	; MAX TRACK # ?
4494	013336	103411			BLO	10\$	; NO
4495	013340	105037	001415		CLRB	CMTRK	; RESET TRACK #
4496	013344	005237	001412		INC	CMCYL	; INCREMENT CYLINDER NUMBER
4497	013350	023727	001412	151466	CMP	CMCYL, #150000+822.	; LAST CYLINDER ?
4498	013356	103401			BLO	10\$	; NO
4499	013360	000417			BR	CMPRX	; NORMAL RETURN, NOT WRAP AROUND
4500	013362	023721	001412		10\$: CMP	CMCYL, (R1)+	; COMPARE 1ST HEADER WORD
4501	013366	001402			BEQ	11\$	; MATCH
4502	013370	004737	013052		JSR	PC, CMSTR2	; NOT MATCH
4503	013374	023721	001414		11\$: CMP	CMSEC, (R1)+	; SECOND WORD OF HEADER
4504	013400	001402			BEQ	12\$	; MATCH
4505	013402	004737	013052		JSR	PC, CMSTR2	; NOT MATCH
4506	013406	162737	000002	001410	12\$: SUB	#2, CMCNT	; ADJUST WORD COUNT
4507	013414	003401			BLE	CMPRX	; COMPARE IS DONE
4508	013416	000716			BR	13\$	; RETURN TO COMPARE LOOP
4509							
4510	013420	004737	013702		CMPRX: JSR	PC, ENDCMP	; PRINT LAST LINE IF ERRORS
4511	013424	000207			RTS	PC	
4512							
4513							
4514							
4515	013426	005737	001400		CMPRT: TST	SAVER1	; PRINT SAVED VALUES ?
4516	013432	001010			BNE	2\$	; BR IF NOT
4517	013434	105737	001376		TSTB	FRSTER	; FIRST ERROR?
4518	013440	100402			BMI	1\$	; BR IF NOT
4519	013442	004737	013522		JSR	PC, 4\$	; PRINT INITIAL MESSAGE INFO
4520	013446	004737	013604		1\$: JSR	PC, 8\$	; PRINT REMAINDER OF MESSAGE
4521	013452	000422			BR	3\$	; EXIT
4522	013454				2\$:		
4523	013454	010146			MOV	R1, -(SP)	; PUSH R1 ON STACK
4524	013456	010546			MOV	R5, -(SP)	; PUSH R5 ON STACK
4525	013460	013701	001400		MOV	SAVER1, R1	; DISPLAY SAVED R1
4526	013464	013705	001402		MOV	SAVER5, R5	; DISPLAY SAVED R5
4527	013470	004737	013522		JSR	PC, 4\$	; PRINT INITIAL MESSAGE INFO
4528	013474	004737	013604		JSR	PC, 8\$	; PRINT SAVED VALUES
4529	013500	005037	001400		CLR	SAVER1	; CLEAR SAVED REGISTER INDICATORS
4530	013504	005037	001402		CLR	SAVER5	; CLEAR THE OTHER ONE
4531	013510	012605			MOV	(SP)+, R5	; POP STACK INTO R5
4532	013512	012601			MOV	(SP)+, R1	; POP STACK INTO R1
4533	013514	004737	013604		JSR	PC, 8\$	; PRINT REMAINDER OF MESSAGE
4534	013520	000207			3\$: RTS	PC	; RETURN
4535	013522	105737	001376		4\$: TSTB	FRSTER	; FIRST ERROR ?
4536	013526	100425			BMI	7\$	; BR IF NOT
4537	013530	001013			BNE	5\$	; BR IF FIRST ERROR AND PROCESSING 'DCK' ERROR
4538	013532	004737	020176		JSR	PC, LINE1	; PRINT LINE 1 OF ERROR MESSAGE
4539	013536	104414	047543		DISPLY	EM42	; DATA COMPARE ERROR
4540	013542	004737	020242		JSR	PC, LINE2	; PRINT LINE 2 OF ERROR MESSAGE
4541	013546	004737	020656		JSR	PC, LINE3A	; PRINT LINE 3A OF ERROR MESSAGE
4542	013552	004737	021320		JSR	PC, LINE4	; PRINT LINE 4 OF ERROR MESSAGE
4543	013556	000404			BR	6\$	; GO TO TYPE HEADER
4544	013560	104414	052126		5\$: DISPLY	, LIN9B	; HEADER MESSAGE OF PROCESSING 'DCK' ERROR
4545	013564	104414	001201		DISPLY	, \$CRLF	; CR-LF
4546	013570	104414	052155		6\$: DISPLY	, LIN9H	; DISPLAY HEADER
4547	013574	012737	177777	001376	MOV	#-1, FRSTER	; SET ERROR FLAG

```

4548 013602 000207      7$:   RTS      PC      ;RETURN
4549 013604 005737 001406 8$:   TST      LIMIT   ;TYPEOUT LIMIT REACHED ?
4550 013610 001403      BEQ      9$      ;BR IF IT HAS
4551 013612 005337 001406 DEC     LIMIT   ;DECREMENT LIMIT COUNTER
4552 013616 001005      BNE     10$     ;BR IF NOT AT LIMIT
4553 013620 032777 000200 165326 9$:   BIT      #SW07,JSWR ;PRINT ALL DATA COMPARE ERRORS ?
4554 013626 001001      BNE     10$     ;BR IF YES
4555 013630 000207      RTS      PC      ;RETURN
4556 013632 010146      10$:  MOV      R1,-(SP) ;BUFFER ADDRESS
4557 013634 162716 000002 SUB     #2,(SP)  ;ADJUST ADDRESS
4558 013640 004737 022210 JSR     PC,LIN0CT ;TYPE IT
4559 013644 104414 052716 DISPLY ,LINS    ;2 SPACES
4560 013650 016546 177776 MOV     -2(R5),-(SP) ;PUT GOOD DATA ON THE STACK
4561 013654 004737 022210 JSR     PC,LIN0CT ;TYPE IT
4562 013660 104414 052716 DISPLY ,LINS    ;2 SPACES
4563 013664 016146 177776 MOV     -2(R1),-(SP) ;BAD DATA
4564 013670 004737 022210 JSR     PC,LIN0CT ;TYPE IT
4565 013674 104414 001201 DISPLY $CRLF   ;CR-LF
4566 013700 000207      RTS      PC      ;RETURN
4567
4568
4569
4570 013702 105737 001377 ENDCMP: TSTB   FRSTER+1 ;ANY COMPARE ERRORS FOUND ?
4571 013706 001417      BEQ      2$      ;BR IF NOT
4572 013710 005737 001404 TST     ERCTR   ;SEE HOW MANY ERRORS
4573 013714 001410      BEQ      1$      ;BR IF ONLY CAN'T MATCH PATTERN
4574 013716 104414 052253 DISPLY ,LIN9E   ;'NUMBER OF ERRORS='
4575 013722 013746 001404 MOV     ERCTR,-(SP) ;NUMBER OF ERRORS
4576 013726 004737 022242 JSR     PC,LINDEC ;TYPE IT
4577 013732 104414 001201 DISPLY $CRLF   ;CR-LF
4578 013736 004737 023424 1$:   JSR     PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4579 013742 004737 021730 JSR     PC,LINE7  ;PRINT LINE 7 OF ERROR MESSAGE
4580 013746 000207      2$:   RTS      PC      ;RETURN
4581
4582
4583
4584
4585
4586
4587
4588
4589
4590 013750 010146      MATCH: MOV     R1,-(SP) ;SAVE R1 ON THE STACK
4591 013752 012704 000044 MOV     #4,R4   ;PATTERN TABLE INDEX
4592 013756 011601 1$:   MOV     (SP),R1 ;RELOAD R1
4593 013760 162704 000002 SUB     #2,R4   ;DECREMENT INDEX
4594 013764 001413      BEQ      3$      ;BR IF PATTERN NOT MATCH
4595 013766 016405 002476 MOV     STNDAT(R4),R5 ;ADDRESS OF PATTERN ADDRESS
4596 013772 012703 000004 MOV     #4,R3   ;NUMBER OF LOCATIONS TO CHECK
4597 013776 022125 2$:   CMP     (R1)+,(R5)+ ;COMPARE THE BUFFER AGAINST THE PATTERN
4598 014000 001366      BNE     1$      ;BR IF NOT EQUAL, TRY NEXT PATTERN
4599 014002 005303      DEC     R3      ;FINISHED CHECKING?
4600 014004 001374      BNE     2$      ;BR IF NOT FINISHED
4601 014006 062704 002476 ADD     #STNDAT,R4 ;MAKE PATTERN ADDRESS ABSOLUTE
4602 014012 000403      BR      4$      ;EXIT
4603 014014 062766 000002 000002 3$:  ADD     #2,2(SP) ;INCREMENT RETURN ADDRESS

```

```

4604 014022 012601          4$:  MOV      (SP)+,R1      ;RESTORE R1
4605 014024 000207          RTS      PC              ;RETURN
4606
4607                          ;USE ECC TO CORRECT THE DATA ERROR
4608
4609 014026 016037 000240 001420 ECC:  MOV      $RMBA(RO),ECSEC ;ADDRESS OF LAST LOCN XFERED
4610 014034 016046 000236          MOV      $RMWC(RO),-(SP) ;ACT WORDS XFERED (2'S COMP)
4611 014040 066016 000020          ADD      $WRDL(RO),(SP)  ;ADD WORDS REQUESTED
4612 014044 005046          CLR      -(SP)          ;CLEAR NEXT STACK LOCN
4613 014046 016046 000022          MOV      $SSEC(RO),-(SP) ;SECTOR SIZE
4614 014052 004737 027332          JSR      PC,LINKDV      ;DIVIDE WORDS XFERED BY SECTOR SIZE
4615 014056 005716          TST      (SP)          ;PARTIAL SECTOR XFERED ?
4616 014060 001413          BEQ     1$             ;BR IF NOT
4617 014062 006316          ASL      (SP)          ;CONVERT INTO NUMBER OF BYTES
4618 014064 161637 001420          SUB      (SP),ECSEC    ;SUBTRACT SECTOR RESIDUE
4619 014070 126027 000024 000005  CMPB     $CODE(RO),#5  ;WAS OP READ HEAD & DATA
4620 014076 001007          BNE     2$             ;BR IF NOT
4621 014100 062737 000004 001420          ADD      #4,ECSEC      ;ADD HEADER SIZE (IN BYTES) BACK IN
4622 014106 000403          BR      2$             ;GO ADJUST THE STACK POINTER
4623 014110 162737 001000 001420 1$:  SUB      #1000,ECSEC   ;SUBTRACT SECTOR DATA FIELD SIZE (IN BYTES)
4624 014116 062706 000004          ADD      #4,SP         ;ADJUST THE STACK POINTER
4625 014122 016037 000300 001416 2$:  MOV      $RMEC1(RO),ECBIT ;ECC POSITION COUNT
4626 014130 005337 001416          DEC      ECBIT         ;ADJUST THE POSITION COUNT
4627 014134 013737 001416 001426          MOV      ECBIT,ECWRD   ;LOAD THE WORD COUNT LOCATION
4628 014142 042737 177760 001416          BIC      #17,ECBIT     ;SAVE THE BIT OFFSET COUNT
4629 014150 042737 000017 001426          BIC      #17,ECWRD     ;CLEAR THE BIT OFFSET
4630 014156 006237 001426          ASR      ECWRD         ;CHANGE TO BYTE COUNT
4631 014162 006237 001426          ASR      ECWRD         ;CHANGE TO BYTE COUNT
4632 014166 006237 001426          ASR      ECWRD         ;CHANGE TO BYTE COUNT
4633 014172 104414 052332          DISPLY  ,LIN10A        ;'ERROR BURST BEGINS AT '
4634 014176 013746 001426          MOV      ECWRD,-(SP)   ;PUT THE WORD COUNT ON THE STACK
4635 014202 006216          ASR      (SP)          ;CONVERT TO WORD COUNT FOR MESSAGE
4636 014204 004737 030246          JSR      PC,$$SB2D     ;CONVERT THE WORD COUNT
4637 014210 004737 027646          JSR      PC,$$SUPRS    ;PRINT IT
4638 014214 104414 052366          DISPLY  ,LIN10B        ;' IN DATA FIELD OF ERROR SECTOR'
4639 014220 063737 001420 001426          ADD      ECSEC,ECWRD   ;FIND THE BEGINNING OF THE ERROR BURST
4640 014226 026037 000240 001426          CMP      $RMBA(RO),ECWRD ;SEE IF BURST WAS IN DATA READ
4641 014234 101002          BHI     .+6            ;BR IF IN DATA READ
4642 014236 000137 014554          JMP      ECC2           ;NOT IN DATA READ - REPORT IT
4643 014242 016037 000302 001422          MOV      $RMEC2(RO),ECMSK0 ;GET THE ERROR MASK
4644 014250 005037 001424          CLR      ECMSK1        ;CLEAR THE UPPER MASK WORD
4645 014254 005737 001416          3$:  TST      ECBIT         ;BIT OFFSET EQUAL ZERO
4646 014260 001407          BEQ     4$             ;BR IF IT IS
4647 014262 005337 001416          DEC      ECBIT         ;DECREMENT THE BIT OFFSET COUNT
4648 014266 006337 001422          ASL      ECMSK0        ;SHIFT THE ERROR MASK
4649 014272 006137 001424          ROL      ECMSK1        ;SHIFT THE LOWER INTO THE UPPER
4650 014276 000766          BR      3$            ;CONTINUE THE SHIFT
4651 014300 017737 165122 001432 4$:  MOV      @ECWRD,ECBADD  ;SAVE THE INCORRECT WORD
4652 014306 005037 001434          CLR      ECWRD1        ;CLEAR SECOND INCORRECT WORD ADDRESS
4653 014312 013746 001422          MOV      ECMSK0,-(SP)  ;PUT LOWER MASK ON STACK
4654 014316 047716 165104          BIC      @ECWRD,(SP)   ;CLEAR ERRONEOUS ONE BITS FROM MASK
4655 014322 043777 001422 165076          BIC      ECMSK0,@ECWRD ;CLEAR ERRONEOUS ONE BITS FROM BAD WORD
4656 014330 052677 165072          BIS      (SP)+,@ECWRD ;SET DROPPED BITS
4657 014334 005737 001424          TST      ECMSK1        ;DOES BURST GO INTO NEXT WORD ?
4658 014340 001431          BEQ     ECC1           ;BR IF BURST ONLY IN ONE WORD
4659 014342 013737 001426 001434          MOV      ECWRD,ECWRD1 ;DUPLICATE ADDRESS

```

```

4660 014350 062737 000002 001434 ADD #2,ECWRD1 ;INCREMENT ERROR ADDRESS
4661 014356 026037 000240 001434 CMP $RMBA(RO),ECWRD1 ;IS NEXT WORD IN THE BUFFER
4662 014364 101003 BHI 5$ ;BR IF IT IS
4663 014366 005037 001434 CLR ECWRD1 ;CLEAR 2ND WORD ADDRESS
4664 014372 000414 BR ECC1 ;PRINT WORD CORRECTED
4665 014374 017737 165034 001440 5$: MOV @ECWRD1,ECBAD1 ;SAVE THE SECOND BAD WORD
4666 014402 013746 001424 MOV ECMSK1,-(SP) ;PUT THE UPPER MASK ON THE STACK
4667 014406 047716 165022 BIC @ECWRD1,(SP) ;CLEAR ERRONEOUS ONE BITS FROM UPPER MASK
4668 014412 043777 001424 165014 BIC ECMSK1,@ECWRD1 ;CLEAR ERRONEOUS ONE BITS FROM DATA WORD
4669 014420 052677 165010 BIS (SP)+,@ECWRD1 ;SET DROPPED BITS
4670 014424 104414 052534 ECC1: DISPLY ,LIN10H ;HEADER
4671 014430 013746 001426 MOV ECWRD,-(SP) ;PUT ECWRD ON THE STACK
4672 014434 004737 022210 JSR PC,LIN0CT ;TYPE ECWRD
4673 014440 104414 052716 DISPLY ,LINSF ;SPACES
4674 014444 013746 001432 MOV ECBADO,-(SP) ;PUT ECBADO ON THE STACK
4675 014450 004737 022210 JSR PC,LIN0CT ;TYPE ECBADO
4676 014454 104414 052716 DISPLY ,LINSF ;SPACES
4677 014460 017746 164742 MOV @ECWRD,-(SP) ;PUT @ECWRD ON THE STACK
4678 014464 004737 022210 JSR PC,LIN0CT ;TYPE @ECWRD
4679 014470 104414 052716 DISPLY ,LINSF ;SPACES
4680 014474 005737 001434 TST ECWRD1 ;PRINT THE NEXT WORD ?
4681 014500 001427 BEQ ECCX ;BR IF NOT
4682 014502 104414 001201 DISPLY ,SCRFL ;CR-LF
4683 014506 013746 001434 MOV ECWRD1,-(SP) ;PUT ECWRD1 ON THE STACK
4684 014512 004737 022210 JSR PC,LIN0CT ;TYPE ECWRD1
4685 014516 104414 052716 DISPLY ,LINSF ;SPACES
4686 014522 013746 001440 MOV ECBAD1,-(SP) ;PUT ECBAD1 ON THE STACK
4687 014526 004737 022210 JSR PC,LIN0CT ;TYPE ECBAD1
4688 014532 104414 052716 DISPLY ,LINSF ;SPACES
4689 014536 017746 164672 MOV @ECWRD1,-(SP) ;PUT @ECWRD1 ON THE STACK
4690 014542 004737 022210 JSR PC,LIN0CT ;TYPE @ECWRD1
4691 014546 104414 052716 DISPLY ,LINSF ;SPACES
4692 014552 000402 BR ECCX ;EXIT
4693 014554 104414 052427 ECC2: DISPLY ,LIN10C ;ERROR BURST WAS NOT TRANSFERED TO MEMORY
4694 014560 104414 001201 ECCX: DISPLY ,SCRFL ;CR-LF
4695 014564 000207 RTS PC ;RETURN
4696
4697 ;ROUTINE TO DISPLAY THE SECTOR WHICH GAVE THE HARD ERROR
4698
4699 014566 032777 000010 164360 PRTBAD: BIT #SW3,@SWR ;PRINT THE BAD SECTOR ?
4700 014574 001460 BEQ 6$ ;BR IF NOT
4701 014576 016001 000240 MOV $RMBA(RO),R1 ;PUT THE END ADDRESS INTO R1
4702 014602 016046 000020 MOV $WRDL(RO),-(SP) ;FIND THE BEGINNING OF THE SECTOR
4703 014606 066016 000236 ADD $RMWC(RO),(SP) ;SUBTRACT THE WORDS NOT TRANSFERED
4704 014612 005046 CLR -(SP) ;MAKE THE UPPER DIVIDEND 0
4705 014614 016046 000022 MOV $$SSEC(RO),-(SP) ;DIVIDE THE WORDS TRANSFERED BY THE SECTOR SIZE
4706 014620 004737 027332 JSR PC,LINKDV ;DIVIDE
4707 014624 005716 TST (SP) ;REMAINDER = 0 ?
4708 014626 001403 BEQ 1$ ;BR IF IT IS - COMPLETE SECTOR TRANSFERED
4709 014630 006316 ASL (SP) ;CONVERT THE RESIDUAL SECTOR SIZE INTO BYTE COUNT
4710 014632 161601 SUB (SP),R1 ;SUBTRACT IT FROM THE END ADDRESS
4711 014634 000410 BR 2$ ;FINISH THE SIZING
4712 014636 162701 001000 1$: SUB #1000,R1 ;SUBTRACT FULL SECTOR SIZE FROM END ADDR
4713 014642 126027 000024 000005 CMPB $CODE(RO),#5 ;WAS OPERATION READ HEADER & DATA ?
4714 014650 001002 BNE 2$ ;BR IF NOT
4715 014652 162701 000004 SUB #4,R1 ;SUBTRACT HEADER SIZE FROM ADDR

```

```

4716 014656 062706 000004 2$: ADD #4,SP ;RESTORE THE STACK POINTER
4717 014662 104414 052621 DISPLY ,LIN11H ;PRINT THE HEADER
4718 014666 012702 000007 3$: MOV #7,R2 ;R2 CONTAINS THE WORDS/LINE COUNT
4719 014672 010146 MOV R1,-(SP) ;PUT THE ADDRESS ON THE STACK
4720 014674 004737 022210 JSR PC,LIN0CT ;TYPE THE ADDRESS
4721 014700 020160 000240 4$: CMP R1,$RMB(A) ;PRINTED ALL THE SECTOR ?
4722 014704 001412 BEQ 5$ ;BR IF ALL PRINTED
4723 014706 104414 052716 DISPLY ,LINSF ;SPACES
4724 014712 012146 MOV (R1)+,-(SP) ;PUT THE DATA ON THE STACK
4725 014714 004737 022210 JSR PC,LIN0CT ;TYPE THE DATA
4726 014720 005302 DEC R2 ;DECREMENT THE HORIZONTAL COUNT
4727 014722 001366 BNE 4$ ;BR IF NOT AT THE END OF THE LINE
4728 014724 104414 001201 DISPLY ,SCRLF ;CR-LF
4729 014730 000756 BR 3$ ;RESTORE THE WORDS/LINE COUNT
4730 014732 104414 001201 5$: DISPLY ,SCRLF ;PRINT WHAT REMAINS IN THE BUFFER
4731 014736 000207 6$: RTS PC ;RETURN
4732
4733 ;ROUTINE TO DO AN RTC - DRIVE SELECTED IN RO
4734 ;CALL:
4735 ; MOV #DPB,RO ;DPB ADDRESS
4736 ; JSR PC,RTNCTR
4737 ; RETURN
4738
4739 014740 111037 045532 RTNCTR: MOVB (RO),GENDPB ;MOVE THE DRIVE # TO THE GENERAL DPB
4740 014744 112737 000117 045534 MOVB #RTC,GENDPB+$COMND ;COMMAND CODE
4741 014752 004037 035040 1$: JSR RO,RM03 ;DRIVER ENTRANCE
4742 014756 045532 GENDPB ;DPB ADDRESS FOR ORDER
4743 014760 000774 BR 1$ ;DRIVER DIDN'T ACCEPT ORDER
4744 014762 000207 RTS PC ;RETURN
4745
4746 ;ROUTINE TO DO A RECALIBRATE - DRIVE SELECTED IN RO
4747 ;CALL:
4748 ; MOV #DPB,RO ;DPB ADDRESS
4749 ; JSR PC,RECALT
4750 ; RETURN
4751
4752 ;OR
4753
4754 ; MOV #DPB,RO ;DPB ADDRESS
4755 ; MOVB #DRIVE,GENDPB ;DRIVE ADDRESS
4756 ; JSR PC,RECALTO
4757 ; RETURN
4758
4759 014764 111037 045532 RECALT: MOVB (RO),GENDPB ;MOVE THE DRIVE # TO THE GENERAL DPB
4760 014770 112737 000107 045534 RECALO: MOVB #RECAL,GENDPB+$COMND ;RECALIBRATE COMMAND
4761 014776 004037 035040 1$: JSR RO,RM03 ;DRIVER ENTRANCE
4762 015002 045532 GENDPB ;DPB ADDRESS FOR ORDER
4763 015004 000774 BR 1$ ;DRIVER DIDN'T ACCEPT THE ORDER
4764 015006 005737 045550 2$: TST GENDPB+$STATUS ;SEE IF FINISHED
4765 015012 001775 BEQ 2$ ;BR IF NOT FINISHED
4766 015014 000207 RTS PC ;RETURN
4767
4768 ;OFFSET THE DRIVE IN RO (OFFSET CODE PRELOADED INTO 'RM0F')
4769 ;CALL:
4770 ; MOVB #OFFSET,GENDPB+$FMT ;OFFSET CODE
4771 ; MOV #DPB,RO ;DPB ADDRESS
    
```

```

4772      ;      JSR      PC,OFFST
4773      ;      RETURN
4774
4775 015016 111037 045532      OFFST:  MOVB      (RO),GENDPB      ;DRIVE # TO GENERAL DPB
4776 015022 112737 000115 045534  MOVB      #OFFSET,GENDPB+SCOMD ;COMMAND
4777 015030 004037 035040      1$:      JSR      RO,RMD3      ;DRIVER ENTRANCE
4778 015034 045532      GENDPB      ;DPB ADDRESS FOR ORDER
4779 015036 000774      BR      1$      ;DRIVER DIDN'T ACCEPT ORDER
4780 015040 000207      RTS      PC
4781
4782      ;UTILITY READ HEADER ROUTINE
4783      ;CALL:
4784      ;      MOV      #DPB,RO      ;DPB ADDRESS
4785      ;      MOV      #SECTOR,-(SP) ;SECTOR ADDRESS
4786      ;      MOV      #TRACK,-(SP) ;TRACK ADDRESS
4787      ;      MOV      #CYLINDER,-(SP);CYLINDER ADDRESS
4788      ;      JSR      PC,READR
4789      ;      RETURN
4790
4791 015042 116637 000004 045543 READHD:  MOVB      4(SP),GENDPB+STRK ;TRACK ADDRESS
4792 015050 116637 000006 045542      MOVB      6(SP),GENDPB+SSEC ;SECTOR ADDRESS
4793 015056 016637 000002 045544      MOV      2(SP),GENDPB+SCYL ;CYLINDER ADDRESS
4794 015064 111037 045532      MOVB      (RO),GENDPB      ;DRIVE NUMBER
4795 015070 112737 000173 045534      MOVB      #RDHD,GENDPB+SCOMD ;COMMAND
4796 015076 012737 177776 045536      MOV      #-2,GENDPB+SMRDM ;WORD CTR = 2
4797 015104 004037 035040      1$:      JSR      RO,RMD3      ;DRIVER ENTRANCE
4798 015110 045532      GENDPB      ;DPB ADDRESS FOR ORDER
4799 015112 000774      BR      1$      ;DRIVER DIDN'T ACCEPT COMMAND
4800 015114 005737 045550      2$:      TST      GENDPB+STATUS ;FINISHED?
4801 015120 001775      BEQ      2$      ;BR IF NOT
4802 015122 011666 000006      MOV      (SP),6(SP) ;ADJUST STACK FOR RETURN
4803 015126 062706 000006      ADD      #6,SP ;ADJUST RETRUN POINTER
4804 015132 000207      RTS      PC ;RETURN
4805
4806      ;RETRY THE PRESENT OPERATION
4807      ;CALL:
4808      ;      MOV      #COUNT,RETRY ;RETRY COUNT
4809      ;      JSR      PC,$RETRY
4810      ;      RETURN1
4811      ;      RETURN2
4812      ;
4813      ;
4814      ;
4815 015134 004737 016132      $RETRY: JSR      PC,GODRIV ;RE-START ORDER
4816 015140 005760 000016      1$:      TST      STATUS(RO) ;ORDER FINISHED?
4817 015144 001775      BEQ      1$      ;BR IF NOT
4818 015146 100405      BMI      2$      ;BR IF ERROR
4819 015150 105237 001351      INCB      RETRY+1 ;INCREMENT RETRY COUNT
4820 015154 062716 000002      ADD      #2,(SP) ;INCREMENT RETURN
4821 015160 000425      BR      5$      ;GO TO EXIT
4822 015162 032760 000200 000016 2$:      BIT      #BIT7,STATUS(RO) ;DID ORDER TERMINATE NORMALLY ?
4823 015170 001430      BEQ      7$      ;BR IF NOT
4824 015172 005737 001346      TST      MASK ;IS ERROR MASK 0 ?
4825 015176 001004      BNE      3$      ;BR IF NOT
4826 015200 005760 000250      TST      $RMER1(RO) ;MAKE SURE THAT THE DRIVE ERROR REG IS CLEAR
4827 015204 001014      BNE      6$      ;BR IF NOT
    
```

```

4828 015206 000404          BR      4$          ;CONTINUE RETRY
4829 015210 033760 001346 000250 3$:  BIT      MASK,$RMR1(RO) ;SAME ERROR?
4830 015216 001407          BEQ      6$          ;BR IF NOT
4831 015220 105237 001351          INCB     RETRY+1      ;INCREMENT RETRY COUNT
4832 015224 123737 001350 001351  CMPB     RETRY,RETRY+1 ;DONE ?
4833 015232 001340          BNE     $RETRY      ;BR IF NOT DONE
4834 015234 000207          RTS     PC          ;RETURN
4835 015236 004737 022176          JSR     PC,LINE8    ;REPORT DIFFERENT ERROR
4836 015242 004737 021730          JSR     PC,LINE7    ;PRINT LINE 7
4837 015246 005726          TST     (SP)+       ;ADJUST STACK POINTER FOR DIRECT RETURN
4838 015250 000207          RTS     PC          ;RETURN
4839 015252 104414 052103          DISPLY  ,LIN8M      ;'DIFFERENT ERROR DURING RETRY'
4840 015256 000137 006364          JMP     ERPRC1      ;REPORT THE ERROR
4841
4842          ;ROUTINE TO UPDATE THE PERFORMANCE SUMMARY STATISTICS
4843          ;CALL:
4844          ;       MOV     #DPB,RO          ;DPB ADDRESS
4845          ;       JSR     PC,STATIS
4846          ;       RETURN
4847
4848 015262 032760 000300 000016  STATIS: BIT      #BIT07!BIT06,STATUS(RO) ;CHECK FOR DATA TERMINATION
4849 015270 001451          BEQ      3$          ;BR IF NOT DATA TERMINATION
4850 015272 016037 000240 015416  MOV     $RMB8(RO),FACTOR ;STORE THE FINAL BUFFER ADDRESS
4851 015300 166037 000006 015416  SUB     $BUF(RO),FACTOR ;SUBTRACT THE INITIAL ADDRESS
4852 015306 001431          BEQ      2$          ;BR IF NO DATA TRANSFER
4853 015310 006237 015416          ASR     FACTOR      ;CONVERT TO A WORD COUNT
4854 015314 063760 015416 000046  ADD     FACTOR,$TRANS(RO) ;UPDATE WORD COUNT
4855 015322 005560 000050          ADC     $TRANS+2(RO) ;ADD ANY CARRY
4856 015326 132760 000002 000024  BITB    #BIT01,$CODE(RO) ;SEE IF ORDER READ OR WRITE
4857 015334 001016          BNE     2$          ;BRANCH IF ORDER WRITE
4858 015336 126027 000024 000001  CMPB    $CODE(RO),#1 ;PRESENT OPERATION AN AUTOMATIC WRITE CHECK ?
4859 015344 101005          BHI     1$          ;BR IF NOT
4860 015346 066060 000020 000046  ADD     $WRDL(RO),$TRANS(RO) ;ADD WORDS WRITTEN
4861 015354 005560 000050          ADC     $TRANS+2(RO) ;ADD A CARRY
4862 015360 063760 015416 000052  1$:  ADD     FACTOR,$READ(RO) ;UPDATE THE READ WORD COUNT
4863 015366 005560 000054          ADC     $READ+2(RO) ;ADD ANY CARRY
4864 015372 026060 000012 000270  2$:  CMP     $CYL(RO),$RMD(RO) ;DID MID-TRANSFER SEEK OCCUR
4865 015400 001405          BEQ      3$          ;BR IF NOT
4866 015402 062760 000001 000042  ADD     #1,$POSIT(RO) ;INCREMENT SEEK COUNT
4867 015410 005560 000044          ADC     $POSIT+2(RO) ;ADD CARRY TO UPPER WORD
4868 015414 000207          3$:  RTS     PC
4869
4870 015416 000000          FACTOR: .WORD 0 ;USED FOR WORDS TRANSFERED
4871
4872          ;ROUTINE TO GET A BUFFER
4873          ;CALL:
4874          ;       MOV     #DPB,RO          ;DPB ADDRESS
4875          ;       CLR     -(SP)           ;CLEAR THE STACK
4876          ;       JSR     PC,GETBUF
4877          ;       RETURN
4878          ;       ;BUFFER ADDRESS WILL BE ON THE STACK
4879          ;       ;STACK WILL BE ZERO IF NO BUFFER AVAILABLE
4880 015420 010146          GETBUF: MOV     R1,-(SP) ;SAVE R1
4881 015422 010246          MOV     R2,-(SP) ;SAVE R2
4882 015424 010346          MOV     R3,-(SP) ;SAVE R3
4883 015426 013702 001700          MOV     BUFTBL,R2 ;NUMBER OF SEPARATE BUFFERS
    
```

```

4884 015432 001444          BEQ      6$          ;BR IF NONE AVAILABLE
4885 015434 012701 001702  MOV      #BUFTBL+2,R1 ;FIRST ADDRESS OF ALLOCATION TABLE
4886 015440 026061 000020 000002 1$:  CMP      $WRDL(R0),2(R1) ;SEE IF THERE IS A BLOCK LARGE ENOUGH
4887 015446 101405          BLOS    3$          ;BRANCH IF IT IS
4888 015450 005332          DEC      R2          ;DECREMENT TABLE COUNT
4889 015452 001434          BEQ      6$          ;BR IF THROUGH TABLE
4890 015454 062701 000004          ADD      #4,R1       ;INCREMENT TABLE POINTER
4891 015460 000767          BR      1$          ;CONTINUE LOOKING
4892 015462 011166 000010 000002 3$:  MOV      (R1),10(SP)  ;BUFFER ADDRESS TO STACK
4893 015466 166061 000020          SUB      $WRDL(R0),2(R1) ;ADJUST BUFFER SIZE
4894 015474 001407          BEQ      4$          ;BR IF DIFFERENCE IS ZERO
4895 015476 006360 000020          ASL      $WRDL(R0)   ;CONVERT # WORDS TO BYTES
4896 015502 066011 000020          ADD      $WRDL(R0),(R1) ;MAKE NEW STARTING ADDRESS
4897 015506 006260 000020          ASR      $WRDL(R0)   ;RETURN # BYTES TO WORDS
4898 015512 000414          BR      6$          ;RETURN
4899 015514 005337 001700          4$:  DEC      BUFTBL     ;DECREMENT ENTRIES COUNT
4900 015520 001411          BEQ      6$          ;BR IF ALLOCATION TABLE EMPTY
4901 015522 005302          DEC      R2          ;DECREMENT TABLE COUNT
4902 015524 001407          BEQ      6$          ;BR IF ITEM WERE LAST ENTRY
4903 015526 010103          MOV      R1,R3      ;MOVE TABLE POINTER
4904 015530 062703 000004          ADD      #4,R3      ;POINT TO NEXT ENTRY
4905 015534 012321          5$:  MOV      (R3)+,(R1)+ ;MOVE ITEMS
4906 015536 012321          MOV      (R3)+,(R1)+
4907 015540 005302          DEC      R2          ;DECREMENT TABLE COUNT
4908 015542 001374          BNE     5$          ;CONTINUE IF NOT AT END OF TABLE
4909 015544 012603          6$:  MOV      (SP)+,R3    ;RESTORE R3
4910 015546 012602          MOV      (SP)+,R2    ;RESTORE R2
4911 015550 012601          MOV      (SP)+,R1    ;RESTORE R1
4912 015552 000207          RTS      PC          ;RETURN
4913
4914
4915          ;ROUTINE TO PUT BUFFER BACK IN TABLE
4916          ;CALL:
4917          ;
4918          ;
4919          ;
4920          ;
4921          RELBUF: MOV      R1,-(SP) ;SAVE R1
4922          MOV      R2,-(SP) ;SAVE R2
4923          MOV      R4,-(SP) ;SAVE R4
4924          MOV      R5,-(SP) ;SAVE R5
4925          MOV      #BUFTBL+2,R1 ;BEGINNING OF TABLE
4926          MOV      BUFTBL,R2 ;ENTRY COUNT
4927          BEQ      2$          ;BR IF EMPTY TABLE
4928          MOV      $WRDL(R0),R3 ;TRIAL ADDRESS
4929          ASL      R3          ;CHANGE TO BYTE COUNT
4930          ADD      $BUF(R0),R3 ;ADDRESS OF HIGHER ADJACENT BLOCK
4931          1$:  CMP      (R1),R3      ;UPPER ADJACENT BLOCK
4932          BEQ      4$          ;BR IF YES
4933          ADD      #4,R1       ;INCREMENT POINTER
4934          DEC      R2          ;DECREMENT ENTRY COUNT
4935          BNE     1$          ;CONTINUE SEARCHING
4936          MOV      $BUF(R0),(R1) ;PUT THE BUFFER BLOCK INTO THE TABLE
4937          MOV      $WRDL(R0),2(R1) ;BLOCK SIZE
4938          INC      BUFTBL     ;INCREMENT ENTRY COUNT
4939          INC      R2          ;INCREMENT R2 FOR USE LATER
    
```



```

4940 015644 000414          BR      5$          ;SEE IF A LOWER ADJACENT BLOCK IS IN THE TABLE
4941 015646 016021 000006 2$:  MOV     $BUF(RO), (R1)+ ;BLOCK ADDRESS TO TABLE
4942 015652 016021 000020          MOV     $WRDL(RO), (R1)+ ;SIZE TO TABLE
4943 015656 005237 001700          INC     BUFTBL          ;INCREMENT ENTRY COUNT
4944 015662 000443          BR      10$         ;EXIT
4945 015664 016011 000006          MOV     $BUF(RO), (R1)   ;RELEASED BUFFER IS LOWER ADJACENT
4946 015670 066061 000020 000002 4$:  ADD     $WRDL(RO), 2(R1) ;INCREMENTED SIZE
4947 015676 010246          MOV     R2, -(SP)       ;SAVE R2
4948 015700 013702 001700          MOV     BUFTBL, R2      ;ENTRY COUNT
4949 015704 012705 001702          MOV     #BUFTBL+2, R5   ;BEGINNING OF TABLE
4950 015710 016504 000002 6$:  MOV     2(R5), R4       ;BLOCK SIZE (IN WORDS)
4951 015714 006304          ASL     R4              ;CHANGE TO BYTE COUNT
4952 015716 061504          ADD     (R5), R4        ;ADD BLOCK BEGINNING ADDRESS
4953 015720 020411          CMP     R4, (R1)        ;R1 STILL POINTS TO INSERTED ENTRY
4954 015722 001406          BEQ     8$             ;LOWER ADJACENT IN TABLE
4955 015724 062705 000004          ADD     #4, R5          ;INCREMENT POINTER
4956 015730 005302          DEC     R2              ;DECREMENT ENTRY COUNT
4957 015732 001366          BNE     6$             ;CONTINUE LOOKING
4958 015734 005726          TST     (SP)+           ;RESTORE STACK POINTER
4959 015736 000415          BR      10$         ;END
4960 015740 012602          MOV     (SP)+, R2       ;RESTORE R2
4961 015742 066165 000002 000002 8$:  ADD     2(R1), 2(R5)    ;INCREMENT LOWER BLOCK LENGTH
4962 015750 005337 001700          DEC     BUFTBL          ;DECREMENT ENTRY COUNT
4963 015754 010105          MOV     R1, R5          ;GET READY TO COMPRESS
4964 015756 062705 000004          ADD     #4, R5          ;INCREMENT TO NEXT ENTRY
4965 015762 012521 9$:  MOV     (R5)+, (R1)+    ;COMPRESS TABLE
4966 015764 012521          MOV     (R5)+, (R1)+    ;MOVE SIZE FIELD DOWN
4967 015766 005302          DEC     R2              ;DECREMENT ENTRY COUNT
4968 015770 001374          BNE     9$             ;BR IF NOT FINISHED
4969 015772 012605 10$:  MOV     (SP)+, R5       ;RESTORE R5
4970 015774 012604          MOV     (SP)+, R4       ;RESTORE R4
4971 015776 012602          MOV     (SP)+, R2       ;RESTORE R2
4972 016000 012601          MOV     (SP)+, R1       ;RESTORE R1
4973 016002 000207          RTS     PC              ;RETURN
4974
4975
4976
4977
4978
4979
4980
4981
4982
4983

```

;FILL THE ASSIGNED BUFFER (IF WRITE OR WRITE CHECK ORDER)

;CALL:

```

:      MOV     #DPB, RO      ;DPB ADDRESS
:      MOV     #BUFADR, $BUF(RO) ;LOAD BUFFER ADDRESS INTO THE DPB
:      MOVB    #PATTERN, $PATT(RO) ;PATTERN CODE
:      JSR     PC, FILBUF
:      RETURN

```

```

4984 016004 104412          FILBUF: SAVREG          ;SAVE THE REGISTERS
4985 016006 132760 000004 000024 BITB    #BIT02, $CODE(RO) ;SEE IF READ ORDER
4986 016014 001044          BNE     4$             ;BR IF READ
4987 016016 016001 000006 1$:  MOV     $BUF(RO), R1    ;BUFFER ADDRESS
4988 016022 016002 000020          MOV     $WRDL(RO), R2  ;POSITIVE WORD COUNT
4989 016026 132760 000001 000024 BITB    #BIT00, $CODE(RO) ;SEE IF WRITE HEADER TYPE ORDER
4990 016034 001413          BEQ     2$             ;BR IF NOT
4991 016036 016011 000012          MOV     $CYL(RO), (R1) ;CYLINDER ADDRESS
4992 016042 052711 010000          BIS     #BIT12, (R1)   ;SET FMT22 BIT
4993 016046 052721 140000          BIS     #140000, (R1)+ ;SET MFG AND USER BITS
4994 016052 016021 000010          MOV     $SEC(RO), (R1)+ ;MOVE SECTOR & TRACK
4995 016056 162702 000002          SUB     #2, R2         ;ADJUST THE WORD COUNT

```

```

4996 016062 003421          BLE      4$          ;BR IF END OF PATTERN
4997 016064 005004          2$: CLR      R4          ;CLEAR R4
4998 016066 116004 000030    MOVB     $PATT(R0),R4 ;RELATIVE PATTERN ADDRESS
4999 016072 016405 002476    MOV      STNDAT(R4),R5 ;PATTERN ADDRESS
5000 016076 012703 000020    MOV      #20,R3       ;PATTERN COUNT
5001 016102 012521          3$: MOV      (R5)+,(R1)+ ;MOVE THE PATTERN INTO THE BUFFER
5002 016104 005302          DEC      R2          ;DECREMENT THE WORD COUNT
5003 016106 003407          BLE      4$          ;BR IF DONE (WORD COUNT = 0)
5004 016110 005303          DEC      R3          ;DECREMENT THE PATTERN COUNT
5005 016112 001373          BNE      3$          ;BR IF MORE PATTERN
5006 016114 012703 000020    MOV      #20,R3       ;RESTORE PATTERN COUNT
5007 016120 016405 002476    MOV      STNDAT(R4),R5 ;RESTORE THE ADDRESS
5008 016124 000766          BR       3$          ;CONTINUE DISTRIBUTING THE PATTERN
5009 016126 104413          4$: RESREG ;RESTORE THE REGISTERS
5010 016130 000207          RTS      PC          ;RETURN
5011
5012          ;START THE ORDER FOR THE DPB IN R0
5013          ;CALL:
5014          ;MOV      #DPB,R0          ;DPB ADDRESS
5015          ;JSR      PC,GODRIV
5016          ;RETURN
5017
5018 016132 010046          GODRIV: MOV     R0,-(SP)    ;SAVE R0
5019 016134 010037 016144    MOV     R0,2$        ;CURRENT DPB ADDRESS
5020 016140 004037 035040    1$: JSR     R0,RMO3   ;CALL THE DRIVE HANDLER
5021 016144 000000          2$: .WORD   0          ;DRIVE BLOCK ADDRESS GOES HERE
5022 016146 000000          HALT    ;DRIVER REJECTED REQUEST
5023 016150 012600          MOV     (SP)+,R0     ;RESTORE R0
5024 016152 062760 000001 000036    ADD     #1,$OPERC(R0) ;INCREMENT THE OPERATION COUNT
5025 016160 005560 000040    ADC     $OPERC+2(R0)
5026 016164 026060 000034 000012    CMP     $PREVA+2(R0),$CYL(R0) ;DID ORDER REQUIRE A CYLINDER CHANGE
5027 016172 001405          BEQ     3$          ;BR IF NOT
5028 016174 062760 000001 000042    ADD     #1,$POSIT(R0) ;INCREMENT SEEK COUNT
5029 016202 005560 000044          ADC     $POSIT+2(R0) ;ADD ANY CARRY
5030 016206 000207          3$: RTS      PC
5031
5032          ;GENERATE PARAMETERS FOR THE OPERATION
5033          ;CALL:
5034          ;MOV      #DPB,R0          ;DPB ADDRESS
5035          ;JSR      PC,SELPAR
5036          ;RETURN
5037
5038 016210 004737 033350          SELPAR: JSR     PC,$RAND ;CYCLE THE RANDOM NUMBER GENERATOR
5039 016214 032777 000001 162732    BIT     #SMD,$SMR    ;SEE IF SMD SET
5040 016222 001012          BNE     2$          ;BR IF SET - READ ONLY
5041 016224 012705 000010          1$: MOV     #10,R5     ;READ/WRITE SELECTION DIVISOR
5042 016230 004737 027304          JSR     PC,$ETREM   ;GET SELECTION VALUE
5043 016234 020537 001500          CMP     R5,$RATIO   ;DETERMINE IF READ OR WRITE
5044 016240 103003          BHIS   2$          ;BR IF READ
5045 016242 004737 017066          JSR     PC,$ANWRT   ;SELECT A WRITE ORDER
5046 016246 000410          BR      $HEAD       ;SELECT ADDRESS
5047 016250 013705 033450          2$: MOV     $LONUM,R5 ;SELECT READ OPERATION CODE
5048 016254 042705 177776          BIC     #1,R5        ;MASK OUT ALL BUT BIT 0
5049 016260 062705 000004          ADD     #4,R5        ;TABLE OFFSET FOR READ CODE
5050 016264 110560 000074          MOVB   R5,$NCODE(R0) ;ORDER SELECTION CODE TO CONTROL BLOCK
5051 016270 005737 001512          THEAD: TST     HEADER ;ENABLE RANDOM ADDRESS SELECT ?
    
```

```

5052 016274 001425          BEQ      RANSEC          :YES
5053 016276 016060 000242 000076  MOV      SRMDA(RO),S$NSEC(RO) :SECTOR AND TRACK
5054 016304 016060 000270 000100  MOV      SRMDC(RO),S$NCYL(RO) :CYLINDER NUMBER
5055 016312 026060 000100 000106  CMP      S$NCYL(RO),MAXCYL(RO) ;OVER MAX CYLINDER # ?
5056 016320 103520          BLO      XWCNT          :NO
5057 016322 016060 000110 000100  MOV      MINCYL(RO),S$NCYL(RO) ;RESET CYLINDER NUMBER
5058 016330 116060 000120 000076  MOV      MINSEC(RO),S$NSEC(RO) ;RESET SECTOR NUMBER
5059 016336 116060 000114 000077  MOV      MINTRK(RO),S$NTRK(RO) ;RESET TRACK NUMBER
5060 016344 000137 016562          JMP      XWCNT          ;SELECT BUFFER SIZE
5061
5062          ;GENERATE A RANDOM SECTOR ADDRESS BETWEEN VALUES 'MINSEC' & 'MAXSEC'
5063
5064 016350 016005 000116          RANSEC: MOV      MAXSEC(RO),R5 :GET MAXIMUM SECTOR ADDRESS
5065 016354 026005 000120          CMP      MINSEC(RO),R5 :'MINSEC' AND 'MAXSEC' THE SAME ?
5066 016360 001417          BEQ      2$           :BR IF THEY ARE
5067 016362 166005 000120          SUB      MINSEC(RO),R5 :SUBTRACT MINIMUM SECTOR ADDRESS
5068 016366 100002          BPL      1$           :BR IF MAX LARGER THAN MIN
5069 016370 062705 000040          ADD      #32.,R5 :CORRECT THE NUMBER
5070 016374 005205          1$: INC      R5 :INCREMENT DIFFERENCE TO USE AS DIVISOR
5071 016376 004737 027304          JSR      PC,GETREM :GET THE RANDOM AUGMENT
5072 016402 066005 000120          ADD      MINSEC(RO),R5 :NEW ADDRESS
5073 016406 020527 000037          CMP      R5,#31. :IS VALUE TOO LARGE ?
5074 016412 101402          BLOS    2$           :BR IF NOT
5075 016414 162705 000040          SUB      #32.,R5 :CORRECT VALUE
5076 016420 110560 000076          2$: MOV      R5,S$NSEC(RO) ;STORE SECTOR ADDRESS IN DPB
5077
5078          ;GENERATE A RANDOM TRACK ADDRESS BETWEEN VALUES 'MINTRK' & 'MAXTRK'
5079
5080 016424 016005 000112          RANTRK: MOV      MAXTRK(RO),R5 :GET MAXIMUM TRACK ADDRESS
5081 016430 026005 000114          CMP      MINTRK(RO),R5 :'MINTRK' AND 'MAXTRK' THE SAME ?
5082 016434 001417          BEQ      2$           :BR IF THEY ARE
5083 016436 166005 000114          SUB      MINTRK(RO),R5 :SUBTRACT MINIMUM TRACK ADDRESS
5084 016442 100002          BPL      1$           :BR IF MAX LARGER THAN MIN
5085 016444 062705 000005          ADD      #5.,R5 :CORRECT THE NUMBER
5086 016450 005205          1$: INC      R5 :INCREMENT DIFFERENCE TO USE AS DIVISOR
5087 016452 004737 027304          JSR      PC,GETREM :GET THE RANDOM AUGMENT
5088 016456 066005 000114          ADD      MINTRK(RO),R5 :NEW TRACK ADDRESS
5089 016462 020527 000004          CMP      R5,#4. :IS VALUE TOO LARGE ?
5090 016466 101402          BLOS    2$           :BR IF NOT
5091 016470 162705 000005          SUB      #5.,R5 :CORRECT VALUE
5092 016474 110560 000077          2$: MOV      R5,S$NTRK(RO) ;STORE TRACK ADDRESS IN DPB
5093
5094          ;GENERATE A RANDOM CYLINDER ADDRESS BETWEEN VALUES 'MINCYL' & 'MAXCYL'
5095
5096 016500 016037 000106 001446          RANCYL: MOV      MAXCYL(RO),CYLINT :ASSUME AN RMO3
5097 016506 016005 000106          MOV      MAXCYL(RO),R5 :GET MAXIMUM CYLINDER ADDRESS
5098 016512 026005 000110          CMP      MINCYL(RO),R5 :'MINCYL' AND 'MAXCYL' THE SAME ?
5099 016516 001417          BEQ      2$           :BR IF THEY ARE
5100 016520 166005 000110          SUB      MINCYL(RO),R5 :SUBTRACT MINIMUM CYLINDER ADDRESS
5101 016524 100002          BPL      1$           :BR IF MAX LARGER THAN MIN
5102 016526 063705 001446          ADD      CYLINT,R5 :CORRECT THE NUMBER
5103 016532 005205          1$: INC      R5 :INCREMENT DIFFERENCE TO USE AS DIVISOR
5104 016534 004737 027304          JSR      PC,GETREM :GET THE RANDOM AUGMENT
5105 016540 066005 000110          ADD      MINCYL(RO),R5 :NEW CYLINDER ADDRESS
5106 016544 023705 001446          CMP      CYLINT,R5 :IS VALUE TOO LARGE ?
5107 016550 003002          BGT      2$           :BR IF NOT

```

```

5108 016552 016005 000110      MOV      MINCYL(R0),R5      ;CORRECT VALUE
5109 016556 010560 000100      2$:     MOV      R5,$NCYL(R0) ;STORE CYLINDER ADDRESS IN DPB
5110 016562 132760 000001 000074 XWCNT:  BITB     #BIT00,$NCODE(R0) ;HEADER OPERATION INVOLVED ?
5111 016570 001414                BEQ      RANSIZ           ;NO
5112 016572 012760 000402 000102      MOV      #258,$NWRDL(R0) ;CHANGE WORD LENGTH TO 258 FOR WIRTHD ORDER
5113 016600 122760 000005 000074 3$:     CMPB     #5,$NCODE(R0)    ;READ HEADER AND DATA ?
5114 016606 001461                BEQ      RANXIT           ;YES
5115 016610 004537 016762      JSR      R5,CHKADR       ;IF WRITE HEAD AND DATA COMMAND
5116                                ;AVOID WRITING BAD SPOT HEADER
5117 016614 000452                BR       RANPAT          ;BRANCH IF NOT ON BAD SPOT
5118 016616 000137 016210      JMP      SELPAR          ;SELECT THE PARAMETERS AGAIN
5119
5120                                ;GENERATE A RANDOM BUFFER LENGTH BETWEEN 4 & THE VALUE IN 'MAXDL'
5121
5122 016622 013705 001462      RANSIZ: MOV      MAXDL,R5      ;GET BUFFER SIZE
5123 016626 005737 001476      TST     WCSEL           ;SELECT A RANDOM WORD COUNT ?
5124 016632 001010                BNE     1$              ;BR IF NOT
5125 016634 005205                INC     R5              ;INCREMENT THE MAXIMUM SIZE
5126 016636 004737 027304      JSR     PC,GETREM       ;DIVIDE BY MAX VALUE
5127 016642 005705                TST     R5              ;IS THE REMAINDER 0 ?
5128 016644 001003                BNE     1$              ;NOT 0, CONTINUE
5129 016646 004737 033350      JSR     PC,$RAND        ;CYCLE THE RANDOM NUMBER GENERATOR
5130 016652 000763                BR     RANSIZ           ;TRY AGAIN
5131 016654 022705 000004      1$:     CMP     #4,R5         ;LESS THAN 4 ?
5132 016660 003403                BLE     2$              ;NO
5133 016662 012705 000004      MOV     #4,R5          ;SET SIZE TO 4
5134 016666 000405                BR     3$
5135 016670 023705 001462      2$:     CMP     MAXDL,R5     ;LARGE THAN MAX ALLOWED ?
5136 016674 101002                BHI     3$              ;NO
5137 016676 013705 001462      MOV     MAXDL,R5       ;RESET COUNTER
5138 016702 132760 000004 000074 3$:     BITB     #BIT02,$NCODE(R0) ;READ OPERATION ?
5139 016710 001006                BNE     4$              ;YES
5140 016712 042705 000377      BIC     #377,R5        ;SECTOR BOUNDARY FOR WRITE OP
5141 016716 005705                TST     R5              ;NONE
5142 016720 003002                BGT     4$              ;NO
5143 016722 012705 000400      MOV     #400,R5        ;AT LEAST ONE SECTOR
5144 016726 010560 000102      4$:     MOV     R5,$NWRDL(R0) ;WORD COUNT
5145 016732 132760 000004 000074      BITB     #BIT02,$NCODE(R0) ;READ OP ?
5146 016740 001004                BNE     RANXIT          ;YES
5147                                ;GET A RANDOM PATTERN NUMBER
5148
5149 016742 004737 017122      RANPAT: JSR     PC,GETPAT   ;GET PATTERN CODE
5150 016746 110560 000075      MOV     R5,$NPATC(R0)  ;MOVE PATTERN CODE TO CONTROL BLOCK
5151 016752 012760 177777 000104 RANXIT: MOV     #-1,$NEXT(R0) ;SET PARAMETERS SELECTED INDICATOR
5152 016760 000207                RTS     PC              ;RETURN
5153
5154                                ;ROUTINE TO CHECK THE SELECTED ADDRESS IS NOT ON THE BAD SPOT
5155                                ;CALLING SEQ
5156                                ;RD=DPB ADDRESS
5157                                ;JSR R5,CHKADR
5158                                ;RET1 NORMAL RETURN
5159                                ;RET2 ERROR RET
5160
5161 016762                                CHKADR:
5162 016762 010146      MOV     R1,-(SP)       ;;PUSH R1 ON STACK
5163 016764 010246      MOV     R2,-(SP)       ;;PUSH R2 ON STACK
    
```

```

5164 016766 010346      MOV      R3,-(SP)      ;; PUSH R3 ON STACK
5165 016770 012701 000020  MOV      #16,R1      ;; TOTAL 16 SETS OF BAD SECTOR ADDRESSES
5166 016774 010002      MOV      R0,R2      ;; TABLE ADDRESS
5167 016776 062702 000124  ADD      #SDSEC,R2   ;; DBP ADDRESS + TABLE ADDRESS OFFSET
5168 017002 022712 177777      1$:     CMP      #-1,(R2)   ;; EMPTY ENTRY ?
5169 017006 001423      BEQ      3$         ;; BRANCH IF SO
5170 017010 026012 000100  CMP      $NCYL(R0),(R2) ;; ON THE SAME CYLINDER ?
5171 017014 001013      BNE      2$         ;; BRANCH IF NOT
5172 017016 126062 000011 000003  CMPB    $TRK(R0),3(R2) ;; ON THE SAME TRACK ?
5173 017024 001007      BNE      2$         ;; BRANCH IF NOT
5174 017026 126062 000010 000002  CMPB    $SEC(R0),2(R2) ;; ON THE SAME SECTOR ?
5175 017034 001003      BNE      2$         ;; BRANCH IF NOT
5176 017036 062705 000002      ADD      #2,R5      ;; OTHERWISE, TAKE ERROR EXIT
5177 017042 000405      BR       3$         ;; EXIT
5178 017044 005301      2$:     DEC      R1      ;; ALL 16 BAD SPOT CHECKED ?
5179 017046 003403      BLE      3$         ;; BRANCH IF SO
5180 017050 062702 000004      ADD      #4,R2      ;; ADJUST TO NEXT TABLE ENTRY
5181 017054 000752      BR       1$         ;; LOOP BACK
5182 017056      3$:
5183 017056 012603      MOV      (SP)+,R3   ;; POP STACK INTO R3
5184 017060 012602      MOV      (SP)+,R2   ;; POP STACK INTO R2
5185 017062 012601      MOV      (SP)+,R1   ;; POP STACK INTO R1
5186 017064 000205      RTS      R5         ;; RETRUN
5187
5188      ;ROUTINE TO SELECT A WRITE (OR WRITE HEAD AND DATA) OPERATION
5189
5190 017066 012705 000002  RANWRT: MOV      #2,R5      ;; SET WRITE DATA COMMAND
5191 017072 005737 001474      TST     FORMAT     ;; ALLOW FORMAT OPERATION ?
5192 017076 001406      BEQ     1$         ;; NO
5193 017100 122760 000004 000024  CMPB    #4,$CODE(R0) ;; PREVIOUS A READ DATA COMMAND ?
5194 017106 001002      BNE     1$         ;; NO
5195 017110 012705 000003      MOV     #3,R5      ;; SET A WRITE HEAD AND DATA COMMAND
5196 017114 110560 000074      1$:     MOVB   R5,$NCODE(R0) ;; SELECT THE WRITE COMMAND
5197 017120 000207      RTS     PC         ;; EXIT
5198
5199      ;ROUTINE TO SELECT A PATTERN
5200
5201 017122 012705 000020  GETPAT: MOV     #20,R5   ;; SELECT PATTERN
5202 017126 005737 001510      TST     PATTEN     ;; ENABLE RANDOM PATTERN SELECTION ?
5203 017132 001403      BEQ     2$         ;; YES
5204 017134 013705 001510      MOV     PATTEN,R5  ;; USE INDEXED PATTERN
5205 017140 000407      BR     1$         ;; NO
5206 017142 004737 027304      2$:     JSR     PC,GETREM  ;; GET CODE
5207 017146 005705      TST     R5        ;; WAS PATTERN ZERO SELECTED ?
5208 017150 001003      BNE     1$         ;; BR IF NOT ZERO
5209 017152 004737 033350      JSR     PC,$RAND   ;; CYCLE THE RANDOM NUMBER GENERATOR
5210 017156 000761      BR     GETPAT     ;; TRY AGAIN
5211 017160 006305      1$:     ASL     R5      ;; MAKE CODE INTO TABLE INDEX
5212 017162 000207      RTS     PC
5213
5214      ;ROUTINE TO GET THE PREVIOUSLY SELECTED PARAMETER VALUES
5215      ;CALL:
5216      ;
5217      ;     MOV     #DPB,R0      ;; DPB ADDRESS
5218      ;     JSR     PC,SELPAR   ;; SELECT THE PARAMETERS
5219      ;     JSR     PC,GETPAR
5220      ;     RETURN

```

```

5220
5221 017164 010546          GETPAR: MOV      RS, -(SP)          ;SAVE RS
5222 017166 116060 000234 000027  MOVB     $RMCS1(R0), $PREVO(R0) ;SAVE CURRENT PARAMETERS
5223 017174 142760 177701 000027  BICB    #1C76, $PREVO(R0)       ;STRIP GO, AND IE BITS
5224 017202 032760 000006 000074  BIT     #6, $NCODE(R0)         ;SEE IF NEXT OPERATION IS READ OR WRITE
5225 017210 001007          BNE     1$                    ;BR IF EITHER
5226 017212 016060 000012 000034  MOV     $CYL(R0), $PREVA+2(R0)  ;SAVE STARTING CYLINDER
5227 017220 016060 000010 000032  MOV     $SEC(R0), $PREVA(R0)   ;SAVE STARTING SECTOR AND TRACK
5228 017226 000410          BR      22$
5229 017230 004737 022262          1$:   JSR     PC, READOR           ;GET THE DECREMENTED SECTOR AND TRACK ADDRESSES
5230 017234 012660 000034          MOV     (SP)+, $PREVA+2(R0)    ;CYLINDER ADDRESS
5231 017240 112660 000033          MOVB   (SP)+, $PREVA+1(R0)    ;TRACK ADDRESS
5232 017244 112660 000032          MOVB   (SP)+, $PREVA(R0)      ;SECTOR ADDRESS
5233          MOV     $CYL(R0), $PREVA+2(R0) ;CURRENT CYLINDER
5234 017250 032777 000100 161676 22$:  BIT     #SM06, $SMR           ;SWITCH 6 SET ?
5235 017256 001073          BNE     5$                    ;BR IF SET
5236 017260 116060 000074 000024  MOVB   $NCODE(R0), $CODE(R0)  ;LOGICAL CODE FOR OPERATION
5237 017266 116005 000074          MOVB   $NCODE(R0), R5        ;LOAD R5 FOR USE AS TABLE INDEX
5238 017272 116560 002122 000002  MOVB   COMBL(R5), $COMND(R0)  ;RMO3 COMMAND CODE
5239 017300 122760 000151 000002  CMPB   #151, $COMND(R0)      ;WRITE CHECK DATA COMMAND ?
5240 017306 001013          BNE     3$                    ;NO, DONOT CARE
5241 017310 122760 000060 000027  CMPB   #60, $PREVO(R0)       ;PREVIOUS A WRITE DATA COMMAND ?
5242 017316 001420          BEQ     4$                    ;YES, 0 K
5243 017320 112760 000171 000002 2$:   MOVB   #171, $COMND(R0)       ;CHANG TO READ DATA COMMAND
5244 017326 112760 000004 000024  MOVB   #4, $CODE(R0)         ;CODE NUMBER CHANGED TO READ DATA
5245 017334 000411          BR      4$                    ;EXIT
5246 017336 122760 000153 000002 3$:   CMPB   #153, $COMND(R0)      ;WRITE CHECK HEAD AND DATA COMMAND ?
5247 017344 001005          BNE     4$                    ;NO, THEN EXIT
5248 017346 122760 000062 000027  CMPB   #62, $PREVO(R0)       ;PREVIOUS A WRITE HEAD AND DATA COMMAND?
5249 017354 001401          BEQ     4$                    ;YES, EXIT
5250 017356 000760          BR      2$                    ;SET TO READ DATA COMMAND
5251 017360          4$:
5252 017360 116060 000075 000030  MOVB   $NPATC(R0), $PATTC(R0) ;PATTERN CODE
5253 017366 016060 000076 000010  MOV     $NSEC(R0), $SEC(R0)   ;TRACK AND SECTOR ADDRESSES
5254 017374 016060 000100 000012  MOV     $NCYL(R0), $CYL(R0)  ;CYLINDER ADDRESS
5255 017402 016060 000102 000020  MOV     $NWRDL(R0), $WRDL(R0) ;BUFFER SIZE
5256 017410 016060 000102 000004  MOV     $NWRDL(R0), $WRDM(R0) ;WORD COUNT FOR THE RH11
5257 017416 005460 000004          NEG     $WRDM(R0)            ;COMPLEMENT IT
5258 017422 012760 000400 000022  MOV     #256, $SSEC(R0)      ;INITIAL VALUE OF SECTOR SIZE
5259 017430 032760 000001 000024  BIT     #1, $CODE(R0)        ;HEADER OPERATION ?
5260 017436 001403          BEQ     5$                    ;BR IF NOT
5261 017440 062760 000002 000022  ADD     #2, $SSEC(R0)        ;ADD HEADER SIZE
5262 017446 005060 000104          CLR     $NEXT(R0)           ;RESET 'PARAMETERS LOADED' INDICATOR
5263 017452 012605          MOV     (SP)+, R5           ;RESTORE R5
5264 017454 000207          RTS     PC                  ;RETURN
5265
5266          ;ROUTINE TO COMPRESS A LIST
5267          ;CALL:
5268          ;       MOV     #ADDRS, R1          ;COMPRESS LIST STARTING AT THIS ADDRESS
5269          ;       JSR     PC, CMPRES
5270          ;       RETURN
5271
5272 017456 016111 000002          CMPRES: MOV     2(R1), (R1)    ;COMPRESS THE TABLE IN R1
5273 017462 001403          BEQ     1$                    ;BR WHEN ZERO FOUND
5274 017464 062701 000002          ADD     #2, R1              ;INCREMENT R1
5275 017470 000772          BR      CMPRES             ;CONTINUE COMPRESSING TABLE
    
```

```

5276 017472 000207 1S: RTS PC ;RETURN
5277
5278 ;ROUTINE TO SETUP PARAMETERS FOR A SEQUENTIAL READ OR WRITE OF THE DISK
5279 ;CALL:
5280 MOV #DPB,RO ;DPB ADDRESS
5281 MOV #-1,$PACK(RO) ;'WRITE PACK' FLAG
5282 OR
5283 MOV #1,$PACK(RO) ;'READ PACK' FLAG
5284 JSR PC,WRTPK
5285 RETURN
5286
5287 017474 004737 033350 WRTPK: JSR PC,$RAND ;CYCLE THE RANDOM NUMBER GENERATOR
5288 017500 005760 000040 TST $OPERC+2(RO) ;SEE IF FIRST OPERATION
5289 017504 001007 BNE WRTPK1 ;BR IF UPPER WORD OF COUNTER NOT ZERO
5290 017506 005760 000036 TST $OPERC(RO) ;LOWER WORD ZERO ?
5291 017512 001004 BNE WRTPK1 ;BR IF NOT 1ST OPERATION
5292 017514 105760 000026 TSTB $PACK(RO) ;SEE WHICH - 'R' OR 'W'
5293 017520 100530 BMI WRTPK3 ;BR IF 'W'
5294 017522 000515 BR WRTPK2 ;'R' OPERATION
5295 017524 116060 000234 000027 WRTPK1: MOVB $RMCS1(RO),$PREV0(RO) ;SAVE CURRENT PARAMETERS
5296 017532 004737 022262 JSR PC,READDR ;GET THE DECREMENTED SECTOR AND TRACK ADDRESSES
5297 017536 012660 000034 MOV (SP)+,$PREVA+2(RO) ;CYLINDER ADDRESS
5298 017542 112660 000033 MOVB (SP)+,$PREVA+1(RO) ;TRACK ADDRESS
5299 017546 112660 000032 MOVB (SP)+,$PREVA(RO) ;SECTOR ADDRESS
5300 017552 016060 000242 000010 MOV $RMDA(RO),$SEC(RO) ;NEW SECTOR & TRACK ADDRESS
5301 017560 016060 000270 000012 MOV $RMDC(RO),$CYL(RO) ;NEW CYLINDER ADDRESS
5302 017566 026060 000012 000106 CMP $CYL(RO),MAXCYL(RO) ;SEE IF AT END
5303 017574 103436 BLO 2$ ;BR IF LESS THAN 'MAXCYL'
5304 017576 101004 BHI 1$ ;BR IF GREATER THAN 'MAXCYL'
5305 017600 126060 000011 000112 CMPB $TRK(RO),MAXTRK(RO) ;SEE IF AT MAX TRACK
5306 017606 103431 BLO 2$ ;BR IF NOT GREATER
5307 017610 116060 000114 000011 1S: MOVB MINTRK(RO),$TRK(RO) ;RESET TRACK ADDRESS
5308 017616 116060 000120 000010 MOVB MINSEC(RO),$SEC(RO) ;RESET SECTOR ADDRESS
5309 017624 016060 000110 000012 MOV MINCYL(RO),$CYL(RO) ;RESET CYLINDER ADDRESS
5310 017632 112760 000004 000024 MOVB #4,$CODE(RO) ;SET CODE TO READ DATA
5311 017640 122760 177776 000026 CMPB #-2,$PACK(RO) ;WT OPERATION IN PROCESSING
5312 017646 001475 BEQ WRTPK5 ;YES
5313 017650 004737 026776 JSR PC,EOP2 ;DROP THE DRIVE (NORMAL TERMINATION)
5314 017654 032777 000020 161272 BIT #SW04,$SWR ;IS SWITCH 4 SET ?
5315 017662 001003 BNE 2$ ;BR IF SET
5316 017664 005726 TST (SP)+ ;INCREMENT THE STACK POINTER
5317 017666 000137 005352 JMP MAIN ;RETURN DIRECTLY TO 'MAIN'
5318 017672 013760 001462 000020 2S: MOV MAXDL,$WRDL(RO) ;BUFFER SIZE IS MAXIMUM
5319 017700 042760 000377 000020 BIC #377,$WRDL(RO) ;SECTOR BOUNDARY FOR WRITTING
5320 017706 013760 001462 000004 MOV MAXDL,$WRDM(RO) ;WORD COUNT
5321 017714 042760 000377 000004 BIC #377,$WRDM(RO) ;SECTOR BOUNDARY FOR WRITTING
5322 017722 005760 000004 TST $WRDM(RO) ;SIZE=0 ?
5323 017726 003006 BGT 3$ ;NO
5324 017730 012760 000400 000004 MOV #400,$WRDM(RO) ;SET TO ONE SECTOR
5325 017736 012760 000400 000020 MOV #400,$WRDL(RO) ;SET ONE SECTOR
5326 017744 005460 000004 3S: NEG $WRDM(RO) ;CHANGE WORD COUNT TO 2'S COMPLEMENT
5327 017750 105760 000026 TSTB $PACK(RO) ;READ OR WRITE ?
5328 017754 100412 BMI WRTPK3 ;BR IF WRITE
5329 017756 012760 000402 000022 WRTPK2: MOV #258,$SSEC(RO) ;SECTOR SIZE FOR READ
5330 017764 112760 000005 000024 MOVB #5,$CODE(RO) ;CODE FOR READ HEADER & DATA
5331 017772 112760 000173 000002 MOVB #RDHD,$COMND(RO) ;DRIVE CODE FOR OPERATION
    
```

```

5332 020000 000415          BR      WRTPK4          ;SET UP FOR EXIT
5333 020002 012760 000400 000022 WRTPK3: MOV      #256, $SSEC(RO) ;SECTOR SIZE
5334 020010 112760 000002 000024      MOVB     #2, $CODE(RO) ;CODE FOR WRTDAT
5335 020016 112760 000161 000002      MOVB     #WRTDAT, $COMND(RO) ;OP CODE
5336 020024 004737 017122          JSR      PC, GETPAT ;GET PATTERN CODE
5337 020030 110560 000030          MOVB     RS, $PATT(RO) ;PATTERN CODE
5338 020034 005060 000104          WRTPK4: CLR     $NEXT(RO) ;CLEAR 'PARAMETER SELECTED' INDICATOR
5339 020040 000207          RTS      PC ;RETURN
5340 020042 005037 001316          WRTPK5: CLR     PACK ;CLEAR WT FLAG
5341 020046 105060 000026          CLRB    $SPACK(RO) ;CLEAR WT FLAG
5342 020052 005726          TST     (SP)+ ;CLEAR STACK LEVEL
5343 020054 000137 005352          JMP     MAIN ;JUMP TO MAIN BACKGROUND LOOP
5344
5345 ;ROUTINE TO DETERMINE OF ERROR IS AT A LOCATION ON THE PACK DEFINED
5346 ; IN THE BAD TRACK/SECTOR TABLE FOR THE DRIVE.
5347 ;CALL:
5348 ;      JSR      PC, SPOTCK
5349 ;      RETURN1
5350 ;      RETURN2
5351 ;
5352 ;
5353 SPOTCK:
5354 020060 010146          MOV      R1, -(SP) ;: PUSH R1 ON STACK
5355 020062 010246          MOV      R2, -(SP) ;: PUSH R2 ON STACK
5356 020064 012701 000124          MOV      # $BDSEC, R1 ;: INCREMENT FOR BAD SECTOR TABLE
5357 020070 060001          ADD     RO, R1 ;: ADD THE BLOCK'S STARTING ADDRESS
5358 020072 012702 000020          MOV      #16, R2 ;: BAD SECTOR TABLE SIZE COUNT
5359 020076 004737 022262          1$: JSR     PC, READDR ;: DECREMENT THE SECTOR/TRACK ADDRESS
5360 020102 021126          CMP     (R1), (SP)+ ;: ON THE SAME CYLINDER ?
5361 020104 001007          BNE     2$ ;: BRANCH IF NOT
5362 020106 122661 000003          CMPB   (SP)+, 3(R1) ;: COMPARE THE TRACK ADDRESS
5363 020112 001005          BNE     3$ ;: BR IF IT IS NOT EQUAL
5364 020114 122661 000002          CMPB   (SP)+, 2(R1) ;: COMPARE THE SECTOR ADDRESS
5365 020120 001003          BNE     4$ ;: BR IF NOT EQUAL
5366 020122 000411          BR      5$ ;: CHECK 'NOTPRT'
5367 020124 005726          2$: TST     (SP)+ ;: CLEAR OFF THE STACK
5368 020126 005726          3$: TST     (SP)+ ;: INCREMENT THE STACK POINTER
5369 020130 062701 000004          4$: ADD     #4, R1 ;: GO TO THE NEXT LOCATION IN THE TABLE
5370 020134 005711          TST     (R1) ;: PAST THE TABLE ENTRIES ?
5371 020136 100411          BMI     6$ ;: BR IF PAST
5372 020140 005302          DEC     R2 ;: DECREMENT THE MAXIMUM ENTRY COUNT
5373 020142 001355          BNE     1$ ;: BR IF MORE TO CHECK
5374 020144 000406          BR      6$ ;: END, EXIT
5375 020146 005737 001504          5$: TST     NOTPRT ;: PRINT THE ERROR ANYWAY ?
5376 020152 001006          BNE     7$ ;: BR IF NOT
5377 020154 012737 177777 001362          MOV     #-1, BADSEC ;: SET THE INDICATOR FOR THE IDENTIFICATION LINE
5378 020162 062766 000002 000004          6$: ADD     #2, 4(SP) ;: INCREMENT THE RETURN
5379 020170          7$:
5380 020170 012602          MOV     (SP)+, R2 ;: POP STACK INTO R2
5381 020172 012601          MOV     (SP)+, R1 ;: POP STACK INTO R1
5382 020174 000207          RTS     PC ;: RETURN
5383
5384 ;:*****
5385
5386 .SBTTL ERROR MESSAGE GENERATION ROUTINES
5387

```



```

5388 ;*****
5389
5390 ;PRINT LINE 1 OF ERROR MESSAGE:
5391 ;'HH:MM:SS'
5392
5393 020176 032777 002000 160750 LINE1: BIT #SW10,JSWR ;SWITCH 10 SET ?
5394 020204 001402 BEQ 1$ ;BR IF NOT
5395 020206 104401 001174 TYPE ,SBELL ;RING THE BELL
5396 020212 032777 020000 160734 1$: BIT #SW13,JSWR ;INHIBIT TYPEOUT ?
5397 020220 001403 BEQ 2$ ;BR IF NOT
5398 020222 104414 001201 DISPLY ,SCRLF ;CR-LF
5399 020226 000404 BR 3$ ;EXIT
5400 020230 004737 023450 2$: JSR PC,STIME ;TYPE THE TIME
5401 020234 104414 052717 DISPLY LINSPO ;SPACES
5402 020240 000207 3$: RTS PC ;RETURN & TYPE DESCRIPTION
5403
5404 ;PRINT LINE 2 OF ERROR MESSAGE
5405 ;'PRESENT ORDER = XXXX PREVIOUS ORDER = XXXX'
5406 ;'* ERROR AT BAD TRACK/SECTOR'
5407 ;'DRV RMCS1 RMCS2 RMD51 RMER1 RMMR2 RMER2 RMEC1 RMEC2'
5408 ;'RMWC RMBA RMDA RMAS RMLA RMDB RMMR1 RMDT'
5409 ;'RMSN RMOF RMDC RMCC STATUS'
5410 ;'BUS ADDRESS OR WORD COUNT NOT CONSISTENT'
5411 ;'RMBA = XXXXXX RMWC = XXXXXX'
5412 ;'BUFFER ADR = XXXXXX SIZE = XXXX ACTUAL NMBR WRDS XFRD = XXX'
5413
5414 020242 LINE2:
5415 020242 010346 MOV R3,-(SP) ;: PUSH R3 ON STACK
5416 020244 010446 MOV R4,-(SP) ;: PUSH R4 ON STACK
5417 020246 010546 MOV R5,-(SP) ;: PUSH R5 ON STACK
5418 020250 104414 001201 DISPLY ,SCRLF ;CR-LF
5419 020254 005037 020402 CLR 4$ ;CLEAR MESSAGE ADDRESS STORAGE
5420 020260 005004 CLR R4 ;WORKING REGISTER
5421 020262 012737 051022 020402 MOV #LIN2C,4$ ;ADDRESS OF 'PRESENT ORDER = ' MSG
5422 020270 116004 000234 MOVB $RMCS1(RO),R4 ;GET THE OPCODE
5423 020274 042704 177701 BIC #C76,R4 ;SAVE ONLY SIGNIFICANT BITS
5424 020300 004737 020336 JSR PC,1$ ;TYPE THE FIRST MNEMONIC
5425 020304 005737 020406 TST 5$ ;SEE IF MNEMONIC ENTRY FOUND
5426 020310 001440 BEQ LINE2A ;BR IF NOT
5427 020312 012737 051043 020402 MOV #LIN2P,4$ ;ADDRESS OF 'PREVIOUS ORDER = ' MSG
5428 020320 116004 000027 MOVB $PREVO(RO),R4 ;PREVIOUS OPERATION CODE
5429 020324 042704 177701 BIC #C76,R4 ;SAVE ONLY SIGNIFICANT BITS
5430 020330 004737 020336 JSR PC,1$ ;TYPE THE PREVIOUS MNEMONIC
5431 020334 000426 BR LINE2A ;CONTINUE
5432 020336 005005 1$: CLR R5 ;CLEAR THE TABLE INDEX
5433 020340 126504 002130 2$: CMPB OPTBL(R5),R4 ;LOOK FOR THE OPCODE
5434 020344 001405 BEQ 3$ ;BR WHEN OPCODE COUNT EQUALS OPCODE
5435 020346 105765 002130 TSTB OPTBL(R5) ;LOOK FOR END OF TABLE
5436 020352 100402 BMI 3$ ;BR IF END
5437 020354 005205 INC R5 ;INCREMENT THE POINTER
5438 020356 000770 BR 2$ ;CONTINUE - NOT END OF TABLE
5439 020360 006305 3$: ASL R5 ;SHIFT INDEX
5440 020362 006305 ASL R5 ;SHIFT THE INDEX
5441 020364 006305 ASL R5 ;SHIFT THE INDEX
5442 020366 012737 002152 020406 MOV #MNTBL,5$ ;ADDRESS OF ASCII TEXT TABLE
5443 020374 060537 020406 ADD R5,5$ ;ADD THE INDEX

```

5444	020400	104414			DISPLY				:TYPE IT
5445	020402	000000			4S: .WORD	0			:ADDRESS OF 'PRESENT' OR 'PREVIOUS' MESSAGE
5446	020404	104414			DISPLY				:TYPE THE OPERATION MNEMONIC
5447	020406	000000			5S: .WORD	0			:ADDRESS OF MESSAGE
5448	020410	000207			RTS	PC			:RETURN TO MAIN ROUTINE
5449	020412	005737	001362		LINE2A: TST	BADSEC			:PRINT THE BAD SECTOR LINE ?
5450	020416	001404			BEQ	LINE2B			:BR IF NOT
5451	020420	104414	001201		DISPLY	,SCLF			:CR-LF
5452	020424	104414	051067		DISPLY	,LIN2S			:ERROR ADDRESS DEFINED AS BAD AREA
5453	020430	104414	001201		LINE2B: DISPLY	,SCLF			:CR-LF
5454	020434	104414	050416		DISPLY	,DH14			:STANDARD RM03 REGISTER HEADER
5455	020440	104414	052717		DISPLY	,LINSPO			:TYPE A SPACE
5456	020444	013746	001344		MOV	UNIT,-(SP)			:PUT THE DRIVE NUMBER ON THE STACK
5457	020450	004737	022242		JSR	PC,LINDEC			:TYPE DRIVE NUMBER
5458	020454	104414	052716		DISPLY	,LINS			:SPACES
5459	020460	012705	050742		MOV	#DT14,R5			:REGISTER INDEXES
5460	020464	004737	020614		JSR	PC,3S			:PRINT THE REGISTERS
5461	020470	032777	000040	160456	BIT	#SM05,#SWR			:PRINT THE OPTIONAL REGISTERS ?
5462	020476	001014			BNE	1S			:BR IF NOT
5463	020500	104414	050521		DISPLY	,DH15			
5464	020504	012705	050764		MOV	#DT15,R5			:SECOND DATA LINE
5465	020510	004737	020614		JSR	PC,3S			:PRINT THEM
5466	020514	104414	050620		DISPLY	,DH16			
5467	020520	012705	051006		MOV	#DT16,R5			:THIRD DATA LINE
5468	020524	004737	020614		JSR	PC,3S			:PRINT THE REGISTERS
5469	020530	032760	000100	000016	1S: BIT	#BIT6,STATUS(RO)			:DATA ERROR ?
5470	020536	001422			BEQ	2S			:BR IF NOT
5471	020540	016046	000020		MOV	\$WRDL(RO),-(SP)			:TRANSFER SIZE
5472	020544	066016	000236		ADD	\$RMWC(RO),(SP)			:ADD REMAINING WORD COUNT
5473	020550	006316			ASL	(SP)			:CONVERT TO AN BYTE INCREMENT
5474	020552	066016	000006		ADD	\$BUF(RO),(SP)			:BUFFER STARTING ADDRESS
5475	020556	022660	000240		CMP	(SP)+,\$RMB(RO)			:CORRECT BUFFER ADDRESS ?
5476	020562	001410			BEQ	2S			:BR IF YES
5477	020564	104414	050043		DISPLY	,EM46			:BUS ADDRESS AND WORD COUNT ARE NOT CONSISTENT'
5478	020570	104414	001201		DISPLY	,SCLF			:CR-LF
5479	020574	004737	020706		JSR	PC,LINE3D			:PRINT LINE 3D OF ERROR MESSAGE
5480	020600	004737	021320		JSR	PC,LINE4			:PRINT LINE 4 OF ERROR MESSAGE
5481	020604				2S: MOV	(SP)+,R5			::POP STACK INTO R5
5482	020604	012605			MOV	(SP)+,R4			::POP STACK INTO R4
5483	020606	012604			MOV	(SP)+,R3			::POP STACK INTO R3
5484	020610	012603			RTS	PC			:RETURN TO ERROR PROCESSING ROUTINE
5485	020612	000207			3S: MOV	(R5)+,-(SP)			:PUT THE REGISTER INDEX ON THE STACK
5486	020614	012546			ADD	RO,(SP)			:ADD DRIVE'S TABLE ADDRESS
5487	020616	060016			MOV	2(SP),-(SP)			:VALUE
5488	020620	017646	000000		JSR	PC,LINOC			:TYPE IT
5489	020624	004737	022210		TST	(SP)+			:CORRECT THE STACK POINTER
5490	020630	005726			DISPLY	,LINS			:PRINT 2 SPACES
5491	020632	104414	052716		TST	(R5)			:AT END OF LINE ?
5492	020636	005715			BNE	3S			:BR IF NOT
5493	020640	001365			4S: DISPLY	,SCLF			:CR-LF
5494	020642	104414	001201		RTS	PC			:RETURN
5495	020646	000207							
5496									
5497									
5498									
5499									

:PRINT LINE 3 OF ERROR MESSAGE  
 :ERROR AT CCC TT SS PREVIOUS ADR = CCC TT SS'

```

5500 020650 104414 051123 LINE3: DISPLY ,LINM3 ;LINE 3 ENTRANCE
5501 020654 000517 BR LIN3.1 ;FINISH PRINTOUT
5502
5503 ;PRINT LINE 3A OF ERROR MESSAGE
5504 ;'START CYL = CCC END CYL = CCC'
5505
5506 020656 104414 051141 LINE3A: DISPLY ,LINM3 ;LINE 3A ENTRANCE
5507 020662 000514 BR LIN3.1 ;FINISH ERROR LINE
5508
5509 ;PRINT LINE 3B OF ERROR MESSAGE
5510 ;'START CYL = CCC END CYL = CCC ACTUAL CYL = CCC'
5511
5512 020664 004737 021222 LINE3B: JSR PC,LIN3.3 ;LINE 3B ENTRANCE
5513 020670 104414 001201 DISPLY ,SCLF
5514 020674 000207 RTS PC
5515
5516 ;PRINT LINE 3C OF ERROR MESSAGE
5517 ;'START CYL = CCC END CYL = CCC ACTUAL CYL = CCC TRK = TT'
5518
5519 020676 004737 021222 LINE3C: JSR PC,LIN3.3 ;LINE 3C ENTRANCE
5520 020702 000137 021254 JMP LIN3.4 ;FINISH MESSAGE
5521
5522 ;PRINT LINE 3D OF ERROR MESSAGE
5523 ;'RMB8 = XXXXXX RMWC = XXXXXX'
5524
5525 020706 032777 000040 160240 LINE3D: BIT #SW05,JSWR ;SWITCH 5 SET ?
5526 020714 001416 BEQ IS ;BR IF IT IS
5527 020716 104414 051312 DISPLY ,LINB3 ;'RMB8 = '
5528 020722 016046 000240 MOV $RMB8(RO),-(SP) ;BUFFER ADDR REG CONTENTS
5529 020726 004737 022210 JSR PC,LINOC7 ;CONVERT TO OCTAL AND TYPE IT
5530 020732 104414 051322 DISPLY ,LINM3 ;' RMWC = '
5531 020736 016046 000236 MOV $RMWC(RO),-(SP) ;WORD COUNT REGISTER CONTENTS
5532 020742 004737 022210 JSR PC,LINOC7 ;CONVERT TO OCTAL AND TYPE IT
5533 020746 104414 001201 DISPLY ,SCLF
5534 020752 000207 RTS PC
5535
5536 ;PRINT LINE 3E OF ERROR MESSAGE
5537 ;'START CYL = CCC START TRK = TT START SEC = SS'
5538
5539 020754 104414 051206 LINE3E: DISPLY ,LINS3 ;'START CYL = '
5540 020760 016046 000012 MOV $CYL(RO),-(SP) ;MOVE CYL TO STACK
5541 020764 004737 022242 JSR PC,LINDEC ;TYPE IT IN DECIMAL
5542 020770 104414 052716 DISPLY ,LINS3 ;SPACES
5543 020774 104414 051334 DISPLY ,LINST3 ;'START TRK = '
5544 021000 005046 CLR -(SP) ;CLEAR STACK
5545 021002 116016 000011 MOVB $TRK(RO),(SP) ;TRACK TO STACK
5546 021006 004737 022242 JSR PC,LINDEC ;TYPE IT IN DECIMAL
5547 021012 104414 052716 DISPLY ,LINS3 ;SPACES
5548 021016 104414 051351 DISPLY ,LINS3 ;'START SEC = '
5549 021022 005046 CLR -(SP) ;CLEAR STACK
5550 021024 116016 000010 MOVB $SEC(RO),(SP) ;SECTOR ADDR TO STACK
5551 021030 004737 022242 JSR PC,LINDEC ;TYPE IT IN DECIMAL
5552 021034 104414 001201 DISPLY ,SCLF
5553 021040 000207 RTS PC
5554
5555 ;PRINT LINE 3F OF ERROR MESSAGE

```

```

5556 ;'RMDA = XXXXXX RMCA = XXXXXX'
5557
5558 021042 032777 000040 160104 LINE3F: BIT #SWS,JSWR ;SWITCH 5 SET ?
5559 021050 001420 BEQ IS ;BR IF NOT
5560 021052 104414 051302 DISPLY LINDA3 ;'RMDA = '
5561 021056 016046 000242 MOV $RMDA(RO),-(SP) ;PUT SECTOR/TRACK ADDRESS ON THE STACK
5562 021062 004737 022210 JSR PC,LINOC ;TYPE IT
5563 021066 104414 052716 DISPLY ,LINS ;SPACES
5564 021072 104414 051271 DISPLY ,LINCA3 ;' RMDC = '
5565 021076 016046 000270 MOV $RMDC(RO),-(SP) ;PUT DESIRED CYLINDER ADDRESS ON THE STACK
5566 021102 004737 022210 JSR PC,LINOC ;TYPE IT
5567 021106 104414 001201 DISPLY $CRLF
5568 021112 000207 IS: RTS PC
5569
5570 ;'CCC TT SS PREV ADR = CCC TT SS'
5571
5572 ;LIN3.1: MOV $RMDC(RO),-(SP) ;PUT CYLINDER ADDR ON STACK
5573 021114 004737 022262 LIN3.1: JSR PC,READR ;DECREMENT TRACK AND SECTOR ADDRESS
5574 021120 004737 022242 JSR PC,LINDEC ;TYPE IT IN DECIMAL
5575 021124 104414 051136 DISPLY T ;PRINT ' T'
5576 ; JSR PC,READR ;DECREMENT TRACK AND SECTOR ADDRESSES
5577 021130 004737 022242 JSR PC,LINDEC ;TYPE TRACK IN DECIMAL
5578 021134 104414 051162 DISPLY S ;PRINT ' S'
5579 021140 004737 022242 JSR PC,LINDEC ;TYPE SECTOR ADDRESS
5580 021144 104414 051165 DISPLY ,LINS3 ;PRINT 'PREV ADR'
5581 021150 016046 000034 MOV $PREVA+2(RO),-(SP) ;PREVIOUS CYLINDER
5582 021154 004737 022242 JSR PC,LINDEC ;TYPE IT IN DECIMAL
5583 021160 104414 051136 DISPLY T ;PRINT ' T'
5584 021164 005046 CLR -(SP) ;MAKE ROOM ON THE STACK
5585 021166 116016 000033 MOVB $PREVA+1(RO),(SP) ;PREVIOUS TRACK ADDRESS
5586 021172 004737 022242 JSR PC,LINDEC ;TYPE IT IN DECIMAL
5587 021176 104414 051162 DISPLY S ;PRINT ' S'
5588 021202 005046 CLR -(SP) ;MAKE ROOM ON THE STACK
5589 021204 116016 000032 MOVB $PREVA(RO),(SP) ;PREVIOUS SECTOR DRESS
5590 021210 004737 022242 JSR PC,LINDEC ;TYPE IT IN DECIMAL
5591 021214 104414 001201 DISPLY $CRLF
5592 021220 000207 RTS PC
5593
5594 ;'START CYL = CCC END CYL = CCC'
5595
5596 021222 104414 051206 LIN3.3: DISPLY LINS3 ;LINE '3B & 3C' ENTRANCE
5597 021226 016046 000034 MOV $PREVA+2(RO),-(SP) ;PREVIOUS CYLINDER
5598 021232 004737 022242 JSR PC,LINDEC ;TYPE IT IN DECIMAL
5599 021236 104414 051223 DISPLY ,LINS3 ;PRINT 'END CYL'
5600 021242 016046 000270 MOV $RMDC(RO),-(SP) ;PRESENT CYLINDER
5601 021246 004737 022242 JSR PC,LINDEC ;TYPE IT IN DECIMAL
5602 021252 000207 RTS PC
5603
5604 ;'ACTUAL CYL = CCC TRK = TT'
5605
5606 021254 104414 051240 LIN3.4: DISPLY LINA3 ;PRINT 'ACTUAL'
5607 021260 013746 056150 MOV CYLDER, -(SP) ;ACTUAL CYLINDER
5608 021264 042716 010000 BIC #BIT12,(SP) ;CLEAR THE FORMAT BIT
5609 021270 004737 022242 JSR PC,LINDEC ;TYPE IT IN DECIMAL
5610 021274 104414 051260 DISPLY ,LINT3 ;PRINT TRACK
5611 021300 005046 CLR -(SP) ;CLEAR STACK WORD

```

```

5612 021302 116016 000243          MOVB   SRMDA+1(RO), (SP) ;PUT TRACK ON STACK
5613 021306 004737 022242          JSR    PC,LINDEC        ;TYPE IT IN DECIMAL
5614 021312 104414 001201          DISPLY $CRLF
5615 021316 000207          RTS    PC
5616
5617                                ;PRINT LINE 4 OF ERROR MESSAGE
5618                                ;'BUFFER ADR = XXXXXX  SIZE = XXXX  ACTUAL NMBR WRDS XFRD = XXX'
5619
5620 021320 032760 000100 000016 LINE4: BIT    #BIT06,STATUS(RO) ;DATA ERROR ?
5621 021326 001427          BEQ    IS                ;BR IF NOT
5622 021330 104414 051366          DISPLY ,LINS4           ;'PRINT BUFFER'
5623 021334 016046 000006          MOV    $BUF(RO),-(SP)   ;BUFFER ADDR ON STACK
5624 021340 004737 022210          JSR    PC,LINOC†       ;CONVERT TO OCTAL & PRINT
5625 021344 104414 051405          DISPLY ,LINS4           ;PRINT 'SIZE'
5626 021350 016046 000020          MOV    $WRDL(RO),-(SP) ;BUFFER SIZE
5627 021354 004737 022242          JSR    PC,LINDEC        ;TYPE IT IN DECIMAL
5628 021360 104414 051417          DISPLY ,LINS4           ;'ACTUAL NMBR WRDS XFRD = '
5629 021364 016046 000240          MOV    $RMB8(RO),-(SP) ;VALUE IN BUFFER ADDR REGISTER
5630 021370 166016 000006          SUB    $BUF(RO),(SP)   ;SUBTRACT STARTING ADDRESS
5631 021374 006216          ASR    (SP)            ;CONVERT INTO A WORD COUNT
5632 021376 004737 022242          JSR    PC,LINDEC        ;TYPE IT IN DECIMAL
5633 021402 104414 001201          DISPLY $CRLF           ;CR-LF
5634 021406 000207          RTS    PC              ;RETURN
5635
5636                                ;PRINT LINE 5 OF ERROR MESSAGE
5637                                ;'GOOD DATA = XXXXXX  BAD DATA = XXXXXX  SECT POS = XXX'
5638
5639 021410 104414 051452          LINES: DISPLY ,LINS5    ;PRINT 'GOOD DATA'
5640 021414 162760 000002 000240 SUB    #2,$RMB8(RO)     ;BACK THE ADDRESS UP
5641 021422 017046 000240          MOV    $RMB8(RO),-(SP) ;'GOOD' DATA - AT THE BUFFER LOCATION
5642 021426 004737 022210          JSR    PC,LINOC†       ;TYPE IT
5643 021432 104414 051467          DISPLY ,LINS5           ;PRINT 'BAD DATA'
5644 021436 016046 000256          MOV    $RMD8(RO),-(SP) ;BAD DATA FROM BUFFER
5645 021442 004737 022210          JSR    PC,LINOC†       ;TYPE IT
5646 021446 016046 000236          MOV    $RMC(RO),-(SP)  ;WORD LENGTH ON STACK
5647 021452 066016 000020          ADD    $WRDL(RO),(SP)  ;MAKE INTO A POSITIVE NUMBER
5648 021456 005046          CLR    -(SP)           ;UPPER DIVIDEND TO ZERO
5649 021460 016046 000022          MOV    $SSEC(RO),-(SP) ;SECTOR SIZE ON THE STACK
5650 021464 004737 027332          JSR    PC,LINKDV       ;DIVIDE WORDS XFERED BY SECTOR SIZE
5651 021470 012616          MOV    (SP)+,(SP)      ;MOVE REMAINDER UP THE STACK
5652 021472 104414 051505          DISPLY ,LINS5           ;PRINT 'SECT POS'
5653 021476 004737 022242          JSR    PC,LINDEC        ;TYPE THE POSITION
5654 021502 104414 001201          DISPLY $CRLF
5655 021506 000207          RTS    PC
5656
5657                                ;PRINT LINE 5A OF THE ERROR MESSAGE
5658                                ;'HEADER FROM ERROR SECTOR XXXXXX XXXXXX XXXXXX XXXXXX'
5659
5660 021510          LINESA:
5661 021510 104414 051523          2$:  DISPLY ,LINS5       ;'HEADER CONTENTS OF ERROR SECTOR'
5662 021514 013746 056150          MOV    $CYLDER, -(SP)   ;HEADER POSITION
5663 021520 004737 022210          JSR    PC,LINOC†       ;TYPE IT
5664 021524 104414 052716          DISPLY ,LINS5           ;SPACES
5665 021530 013746 056152          MOV    $CYLDER+2, -(SP) ;HEADER POSITION +2
5666 021534 004737 022210          JSR    PC,LINOC†       ;TYPE IT
5667 021540 104414 052716          DISPLY ,LINS5           ;SPACES
    
```

```

5668 021544 104414 052721
5669 021550 104414 001201
5670 021554 000207
5671
5672
5673
5674
5675 021556 104414 051557
5676 021562 016046 000300
5677 021566 004737 022210
5678 021572 104414 052716
5679 021576 104414 051570
5680 021602 016046 000302
5681 021606 004737 022210
5682 021612 104414 001201
5683 021616 000207
5684
5685
5686
5687
5688 021620 104414 051602
5689 021624 104414 001201
5690 021630 000207
5691
5692
5693
5694
5695 021632 104414 051635
5696 021636 000411
5697
5698
5699
5700
5701 021640 104414 051602
5702 021644 000406
5703
5704
5705
5706
5707 021646 104414 051664
5708 021652 000414
5709
5710
5711
5712
5713 021654 104414 051713
5714 021660 000411
5715
5716
5717
5718 021662 006301
5719 021664 016137 002470 021674
5720 021672 104414
5721 021674 000000
5722 021676 104414 001201
5723 021702 000207

3$:   DISPLY ,LINX5           ;APPENDING INFO 1/23/77
      DISPLY ,$CRLF
      RTS      PC

;PRINT LINE 5B OF ERROR MESSAGE
;'RMEC1 = XXXXXX RMEC2 = XXXXXX'
LINE5B: DISPLY  LINEP5           ;'RMEC1 = '
        MOV    $RMEC1(RO),-(SP) ;PUT REGISTER CONTENTS ON THE STACK
        JSR    PC,LINOCT        ;TYPE IT
        DISPLY ,LINS5           ;SPACES
        DISPLY ,LINEO5         ;' RMEC2 = '
        MOV    $RMEC2(RO),-(SP) ;PUT REGISTER CONTENTS ON THE STACK
        JSR    PC,LINOCT        ;TYPE IT
        DISPLY ,$CRLF
        RTS      PC           ;RETURN

;PRINT LINE 6 OF ERROR MESSAGE
;'SECTOR IS ECC CORRECTABLE'
LINE6:  DISPLY ,LIN6           ;ECC CORRECTABLE
        DISPLY ,$CRLF
        RTS      PC

;PRINT LINE 6A OF THE ERROR MESSAGE
;'SECTOR READ CORRECTLY AT OFFSET N'
LINE6A: DISPLY ,LINC6           ;PRINT 'READ CORRECTLY AT OFFSET N'
        BR     LIN6.1         ;TYPE THE REST OF THE LINE

;PRINT LINE 6B OF THE ERROR MESSAGE
;'SECTOR IS ECC CORRECTABLE AT OFFSET N'
LINE6B: DISPLY ,LIN6           ;PRINT 'SECTOR IS ECC CORRECTABLE '
        BR     LIN6.1

;PRINT LINE 6C OF THE ERROR MESSAGE
;'CORRECTED ON NTH RETRY'
LINE6C: DISPLY ,LINC6           ;'CORRECTED ON NTH RETRY'
        BR     LIN6.2         ;TYPE THE REST OF THE LINE

;PRINT LINE 6D OF THE ERROR MESSAGE
;'UNCORRECTABLE AFTER N RETRIES'
LINE6D: DISPLY ,LIN6.0         ;'UNCORRECTABLE AFTER N RETRIES'
        BR     LIN6.2         ;FINISH

;TYPE THE OFFSET VALUE IN MICRO-INCHES
LIN6.1: ASL    R1               ;DOUBLE THE OFFSET TABLE INDEX
        MOV    OFMTBL(R1),1$   ;ADDRESS OF OFFSET POSITION MESSAGE
        DISPLY ,WORD 0         ;OFFSET VALUE
1$:    DISPLY ,$CRLF
        RTS      PC

```

5724  
5725  
5726  
5727 021704 005046  
5728 021706 113716 001351  
5729 021712 004737 022242  
5730 021716 104414 051702  
5731 021722 104414 001201  
5732 021726 000207

;RETRY COUNT TIMEOUT

LINE6.2: CLR -(SP) ;CLEAR STACK  
MOV RETRY+1,(SP) ;RETRY COUNT  
JSR PC,LINDEC ;TYPE IT IN DECIMAL  
DISPLY ,LINR6 ;'RETRY'  
DISPLY ,\$CRLF  
RTS PC

5733  
5734  
5735  
5736

;PRINT LINE 7 OF THE ERROR MESSAGE  
;'ORDERS:XXXXX TOTAL ERRORS:XXX WRDS XFRD:XXXXXXX WRDS READ:XXXXXXX'

5737 021730 104414 051766  
5738 021734 012746 000036  
5739 021740 060016  
5740 021742 004737 033546  
5741 021746 004737 027646  
5742 021752 104414 052040  
5743 021756 016046 000056  
5744 021762 004737 022242  
5745 021766 104414 052052  
5746 021772 012746 000046  
5747 021776 060016  
5748 022000 004737 033546  
5749 022004 004737 027646  
5750 022010 104414 052066  
5751 022014 012746 000052  
5752 022020 060016  
5753 022022 004737 033546  
5754 022026 004737 027646  
5755 022032 104414 001201  
5756 022036 104414 001201  
5757 022042 032777 100000 157104  
5758 022050 001401  
5759 022052 000000  
5760 022054 000207

LINE7: DISPLY LIN70 ;PRINT ORDER COUNT  
MOV \$SOPERC,-(SP) ;TO STACK  
ADD RO,(SP) ;ADD THE BASE ADDRESS  
JSR PC,\$DB2D ;CONVERT IT  
JSR PC,\$SUPRS ;PRINT IT  
DISPLY ,LIN7T ;TOTAL ERRORS  
MOV \$TOTAL(RO),-(SP) ;TO STACK  
JSR PC,LINDEC ;TYPE IT IN DECIMAL  
DISPLY ,LIN7X ;PRINT 'WRDS XFR'  
MOV \$STRANS,-(SP) ;ADDRESS OF LOW WORD ON STACK  
ADD RO,(SP)  
JSR PC,\$DB2D ;CONVERT  
JSR PC,\$SUPRS ;PRINT  
DISPLY ,LIN7R ;'BITS READ'  
MOV \$SREAD,-(SP) ;LOW WORD ADDRESS  
ADD RO,(SP)  
JSR PC,\$DB2D ;CONVERT  
JSR PC,\$SUPRS ;PRINT  
DISPLY , \$CRLF  
DISPLY , \$CRLF  
BIT \$SW15,\$SWR ;SEE IF 'HALT ON ERROR' - SWITCH 15  
BEQ IS ;BR IF NOT  
HALT ;SWITCH 15 HALT  
IS: RTS PC

5761  
5762  
5763  
5764

;PRINT LINE 7A OF ERROR MESSAGE  
;'ORDERS:XXXXX TOTAL SEEKS=XXXXX TOTAL MISPOS ERR = XXX TOTAL SKI= XXX'

5765 022056 104414 051766  
5766 022062 012746 000036  
5767 022066 060016  
5768 022070 004737 033546  
5769 022074 004737 027646  
5770 022100 104414 051776  
5771 022104 012746 000042  
5772 022110 060016  
5773 022112 004737 033546  
5774 022116 004737 027646  
5775 022122 104414 051740  
5776 022126 016046 000066  
5777 022132 004737 022242  
5778 022136 104414 052016  
5779 022142 016046 000064

LINE7A: DISPLY LIN70 ;'ORDERS = '  
MOV \$SOPERC,-(SP) ;ORDER COUNT INCREMENT  
ADD RO,(SP) ;ADD BASE ADDRESS  
JSR PC,\$DB2D ;CONVERT THE COUNT  
JSR PC,\$SUPRS ;PRINT IT  
DISPLY ,LIN7P ;'TOTAL SEEKS = '  
MOV \$SPOSIT,-(SP) ;TOTAL SEEKS  
ADD RO,(SP) ;DEVICE TABLE ADDRESS  
JSR PC,\$DB2D ;CONVERT THE SEEK COUNT  
JSR PC,\$SUPRS ;PRINT IT  
DISPLY ,LIN7M ;' TOTAL MISPOS ERR = '  
MOV \$MISPO(RO),-(SP) ;TOTAL ERRORS  
JSR PC,LINDEC ;TYPE IT IN DECIMAL  
DISPLY ,LIN7S ;' TOTAL SKI OCYL ERR = '  
MOV \$SKI(RO),-(SP) ;CONVERT & PRINT IT

```

5780 022146 004737 022242      JSR      PC,LINDEC      ;TYPE IT IN DECIMAL
5781 022152 104414 001201      DISPLY   ,SCLRF
5782 022156 104414 001201      DISPLY   ,SCLRF
5783 022162 032777 100000 156764      BIT      #SW15,JSWR      ;SEE IF HALT ON ERROR - SWITCH 15 SET
5784 022170 001401                      BEQ      1$              ;BR IF NOT
5785 022172 000000                      HALT
5786 022174 000207      1$:      RTS      PC      ;SWITCH 15 HALT
5787
5788      ;PRINT LINE 8 OF THE ERROR MESSAGE
5789      ;'DIFFERENT ERROR DURING RETRY'
5790
5791 022176 104414 052103      LINE8:   DISPLY   LIN8M
5792 022202 004737 020242      JSR      PC,LINE2      ;PRINT LINE 2 OF ERROR MESSAGE
5793 022206 000207      RTS      PC
5794
5795      ;OCTAL TYPEOUT ROUTINE
5796      ;CALL:
5797      ;
5798      ;
5799      ;
5800
5801 022210 016646 000002      LINOCT:  MOV      2(SP),-(SP) ;PUT NUMBER IN PROPER LOCATION ON STACK
5802 022214 004737 030276      JSR      PC,$S820      ;CONVERT THE NUMBER TO OCTAL
5803 022220 012637 022234      MOV      (SP)+,1$      ;GET THE ADDRESS OF THE ASCII STRING
5804 022224 062737 000005 022234      ADD      #5.,1$        ;ADDRESS THE LAST 6 ASCII DIGITS
5805 022232 104414                      DISPLY   ;TYPE IT
5806 022234 000000      1$:      .WORD      0      ;ADDRESS
5807 022236 012616      MOV      (SP)+,(SP)    ;CORRECT THE STACK
5808 022240 000207      RTS      PC      ;RETURN
5809
5810      ;ROUTINE TO CONVERT THE INPUT NUMBER TO DECIMAL AND TYPE IT WITH
5811      ;LEADING ZERO SUPPRESSION
5812      ;CALL:
5813      ;
5814      ;
5815      ;
5816
5817 022242 016646 000002      LINDEC:  MOV      2(SP),-(SP) ;SET UP STACK FOR CONVERT
5818 022246 004737 030246      JSR      PC,$S820      ;CONVERT IT TO DECIMAL
5819 022252 004737 027646      JSR      PC,$SUPRS     ;TYPE IT (WITH LEADING ZEROS SUPRESSED)
5820 022256 012616      MOV      (SP)+,(SP)    ;RESTORE STACK POINTER
5821 022260 000207      RTS      PC
5822
5823      ;*****
5824
5825      .SBTTL  GENERAL SUPPORT SUBROUTINES
5826
5827      ;*****
5828
5829      ;DECREMENT THE SECTOR-TRACK ADDRESS
5830      ;CALL:
5831      ;
5832      ;
5833      ;
5834      ;
5835      ;
5836      ;
5837      ;
5838      ;
5839      ;
5840      ;
5841      ;
5842      ;
5843      ;
5844      ;
5845      ;
5846      ;
5847      ;
5848      ;
5849      ;
5850      ;
5851      ;
5852      ;
5853      ;
5854      ;
5855      ;
5856      ;
5857      ;
5858      ;
5859      ;
5860      ;
5861      ;
5862      ;
5863      ;
5864      ;
5865      ;
5866      ;
5867      ;
5868      ;
5869      ;
5870      ;
5871      ;
5872      ;
5873      ;
5874      ;
5875      ;
5876      ;
5877      ;
5878      ;
5879      ;
5880      ;
5881      ;
5882      ;
5883      ;
5884      ;
5885      ;
5886      ;
5887      ;
5888      ;
5889      ;
5890      ;
5891      ;
5892      ;
5893      ;
5894      ;
5895      ;
5896      ;
5897      ;
5898      ;
5899      ;
5900      ;
5901      ;
5902      ;
5903      ;
5904      ;
5905      ;
5906      ;
5907      ;
5908      ;
5909      ;
5910      ;
5911      ;
5912      ;
5913      ;
5914      ;
5915      ;
5916      ;
5917      ;
5918      ;
5919      ;
5920      ;
5921      ;
5922      ;
5923      ;
5924      ;
5925      ;
5926      ;
5927      ;
5928      ;
5929      ;
5930      ;
5931      ;
5932      ;
5933      ;
5934      ;
5935      ;
5936      ;
5937      ;
5938      ;
5939      ;
5940      ;
5941      ;
5942      ;
5943      ;
5944      ;
5945      ;
5946      ;
5947      ;
5948      ;
5949      ;
5950      ;
5951      ;
5952      ;
5953      ;
5954      ;
5955      ;
5956      ;
5957      ;
5958      ;
5959      ;
5960      ;
5961      ;
5962      ;
5963      ;
5964      ;
5965      ;
5966      ;
5967      ;
5968      ;
5969      ;
5970      ;
5971      ;
5972      ;
5973      ;
5974      ;
5975      ;
5976      ;
5977      ;
5978      ;
5979      ;
5980      ;
5981      ;
5982      ;
5983      ;
5984      ;
5985      ;
5986      ;
5987      ;
5988      ;
5989      ;
5990      ;
5991      ;
5992      ;
5993      ;
5994      ;
5995      ;
5996      ;
5997      ;
5998      ;
5999      ;
6000      ;
    
```



```

5836 ; 4(SP) CONTAINS THE SECTOR ADDRESS
5837
5838 022262 162706 000006 READDR: SUB #6, SP ; DECREMENT THE STACK POINTER
5839 022266 016616 000006 MOV 6(SP), (SP) ; MOVE THE RETURN ADDR DOWN THE STACK
5840 022272 005066 000006 CLR 6(SP) ; CLEAR STACK FOR SECTOR
5841 022276 005066 000004 CLR 4(SP) ; CLEAR STACK FOR TRACK
5842 022302 005066 000002 CLR 2(SP) ; CLEAR STACK FOR CYLINDER
5843 022306 116066 000242 000006 MOVSB $RMDA(R0), 6(SP) ; SECTOR ON STACK
5844 022314 116066 000243 000004 MOVSB $RMDA+1(R0), 4(SP) ; TRACK ADDRESS
5845 022322 016066 000270 000002 MOV $RMDC(R0), 2(SP) ; CYLINDER ADDRESS
5846 022330 005766 000006 TST 6(SP) ; SECTOR 0 ?
5847 022334 001403 BEQ 1$ ; BRANCH IF 50
5848 022336 105366 000006 DECB 6(SP) ; DECREMENT ONE SECTOR
5849 022342 000421 BR 3$ ; BRANCH TO EXIT
5850 022344 005766 000004 1$: TST 4(SP) ; ALSO ON TRACK 0 ?
5851 022350 001406 BEQ 2$ ; BRANCH IF 50
5852 022352 112766 000037 000006 MOVSB #31, 6(SP) ; LAST SECTOR
5853 022360 105366 000004 DECB 4(SP) ; DECREMENT ONE TRACK
5854 022364 000410 BR 3$ ; EXIT
5855 022366 112766 000037 000006 2$: MOVSB #31, 6(SP) ; LAST SECTOR
5856 022374 112766 000004 000004 MOVSB #4, 4(SP) ; LAST TRACK
5857 022402 005366 000002 DEC 2(SP) ; DECREMENT ONE CYLINDER COUNT
5858 022406 000240 3$: NOP ; DONE
5859 022410 000207 RTS PC ; RETURN
5860
5861 ; ROUTINE TO CHECK FOR KW11-L OR KW11-P CLOCKS
5862
5863 022412 012737 177777 001310 CKCLK: MOV #-1, CLKFLG ; CLEAR CLOCK AVAILABILITY FLAG
5864 022420 012737 177777 001306 MOV #-1, PCLOCK ; CLEAR KW11-P CLOCK AVAILABILITY FLAG
5865 022426 012737 022506 000004 MOV #CKCLK1, ERRVEC ; SET UP VECTOR FOR CLOCK CHECK
5866 022434 005037 000006 CLR 2#ERRVEC+2 ; NEW PSW
5867 022440 005777 156630 TST 2$CLKCSR ; CHECK FOR KW11-P
5868 022444 005037 001310 CLR CLKFLG ; SET CLOCK AVAILABILITY FLAG
5869 022450 005037 001306 CLR PCLOCK ; SET KW11-P CLOCK FLAG
5870 022454 013701 001300 MOV $LLVEC, R1 ; KW11-P VECTOR ADDRESS
5871 022460 012721 023546 MOV #CLOCK, (R1)+ ; SET UP KW11-P VECTOR
5872 022464 012711 000300 MOV #300, (R1) ; PSW - PRI 6
5873 022470 012777 174575 156600 MOV #-1667, 2$CLKCSB ; LOAD COUNTER BUFFER WITH 16.67
5874 022476 012777 000131 156570 MOV #131, 2$CLKCSR ; SET CLOCK - CNT UP, 10US, CONT INT
5875 022504 000437 BR CKCLK3
5876 022506 062706 000004 CKCLK1: ADD #4, SP ; RESTORE THE STACK POINTER
5877 022512 012737 022554 000004 MOV #CKCLK2, 2#ERRVEC ; CHANGE ERROR VECTOR TO CHECK FOR KW11-L
5878 022520 005777 156556 TST 2$CLKS ; LOOK FOR KW11-L
5879 022524 005037 001310 CLR CLKFLG ; SET CLOCK FLAG
5880 022530 013701 001304 MOV $LLVEC, R1 ; KW11-L VECTOR ADDRESS
5881 022534 012721 023546 MOV #CLOCK, (R1)+ ; SET UP KW11-L VECTOR
5882 022540 012711 000300 MOV #300, (R1) ; PSW - PRI 6
5883 022544 012777 000100 156530 MOV #100, 2$CLKS ; SET KW11-L INTERRUPT
5884 022552 000414 BR CKCLK3
5885 022554 062706 000004 CKCLK2: ADD #4, SP ; RESTORE THE STACK POINTER
5886 022560 104401 053512 TYPE #NEDCLK ; 'P OR L CLOCK MUST BE ON SYSTEM'
5887 022564 005737 000042 TST 42 ; UNDER MONITOR CONTROL ?
5888 022570 001402 BEQ 1$ ; BR IF NOT
5889 022572 000137 027250 JMP $GET42 ; ABORT PROGRAM
5890 022576 000000 1$: HALT ; HALT
5891 022600 000137 003622 JMP START ; TRY AGAIN
    
```

```

5892 022604 012737 000006 000004 CKCLK3: MOV #6,2#ERRVEC ;RESTORE THE ERROR VECTOR
5893 022612 000207 RTS PC
5894
5895 ;ROUTINE TO DISPLAY STATISTICS FOR ALL DRIVES ASSIGNED
5896 ;CALL:
5897 ; JSR PC,STATPR
5898 ; RETURN
5899
5900 022614 010046 STATPR: MOV R0,-(SP) ;SAVE R0
5901 022616 010446 MOV R4,-(SP) ;SAVE R4
5902 022620 005737 001544 TST ASNLST ;ANY DRIVES ASSIGNED ?
5903 022624 001423 BEQ 3$ ;BR IF NOT
5904 022626 004737 022730 JSR PC,SHDTYP ;TYPE THE HEADING
5905 022632 005004 CLR R4 ;CLEAR THE DRIVE INDEX
5906 022634 006304 1$: ASL R4 ;CHANGE TO INDEX WORDS
5907 022636 016400 002102 MOV BLKADR(R4),R0 ;GET THE DRIVE'S BLOCK ADDRESS
5908 022642 006204 ASR R4 ;RESTORE R4
5909 022644 136437 034304 001544 BITB ATABIT(R4),ASNLST ;IS THIS DRIVE ASSIGNED ?
5910 022652 001404 BEQ 2$ ;BR IF NOT
5911 022654 004737 022752 JSR PC,SDETAL ;TYPE THE PERFORMANCE SUMMARY
5912 022660 104401 001201 TYPE $CRLF ;CR-LF
5913 022664 005204 2$: INC R4 ;INCREMENT THE INDEX
5914 022666 020427 000010 CMP R4,#8. ;FINISHED ?
5915 022672 001360 BNE 1$ ;BR IF NOT
5916 022674 012604 3$: MOV (SP)+,R4 ;RESTORE R4
5917 022676 012600 MOV (SP)+,R0 ;RESTORE R0
5918 022700 000207 RTS PC ;RETURN
5919
5920 ;ROUTINE TO TYPE STATISTICS FOR AN INDIVIDUAL DRIVE
5921 ;CALL:
5922 ; MOV #DPB,R0 ;DPB ADDRESS
5923 ; JSR PC,TYPEST
5924 ; RETURN
5925
5926 022702 010046 TYPEST: MOV R0,-(SP) ;SAVE R0
5927 022704 010446 MOV R4,-(SP) ;SAVE R4
5928 022706 004737 022730 JSR PC,SHDTYP ;TYPE THE HEADING
5929 022712 005004 CLR R4 ;CLEAR R4 FOR DRIVE NUMBER
5930 022714 111004 MOV#B (R0),R4 ;DRIVE NUMBER
5931 022716 004737 022752 JSR PC,SDETAL ;TYPE THE STATISTICS
5932 022722 012604 MOV (SP)+,R4 ;RESTORE R4
5933 022724 012600 MOV (SP)+,R0 ;RESTORE R0
5934 022726 000207 RTS PC ;RETURN
5935
5936 ;TYPE THE HEADER FOR THE DRIVE PERFORMANCE SUMMARY TYPEOUT
5937 ;CALL:
5938 ; JSR PC,SHDTYP
5939 ; RETURN
5940
5941 022730 004737 023450 SHDTYP: JSR PC,$TIME ;TYPE THE TIME OF DAY
5942 022734 004537 027706 JSR R5,TYPRI4 ;TYPE AT PRIORITY 4
5943 022740 001201 $CRLF ;CR-LF
5944 022742 004537 027706 JSR R5,TYPRI4 ;TYPE THE HEADER
5945 022746 053162 STATHD ;HEADER
5946 022750 000207 RTS PC ;RETURN
5947

```

```

5948 ;TYPE THE PERFORMANCE SUMMARY DATE LINE
5949 ;CALL:
5950 ;      MOV      #DRIVE,R4      ;DRIVE NUMBER
5951 ;      MOV      #DPB,R0       ;DPB ADDRESS
5952 ;
5953 ;
5954 SDETAL: MOV      R2,-(SP)      ;SAVE R2
5955 ;      MOV      R0,R2         ;DPB ADDRESS
5956 ;      ADD      #SOPERC,R2    ;FIRST STATISTICAL FIELD
5957 ;      MOV      R4,-(SP)     ;SAVE R4 FOR TYPEOUT
5958 ;
5959 ;      TYPOS
5960 ;      .BYTE   2             ;GO TYPE--OCTAL ASCII
5961 ;      .BYTE   0             ;TYPE 2 DIGIT(S)
5962 ;      TYPE    ,LINSPL       ;SUPPRESS LEADING ZEROS
5963 ;      MOV      $PASSC(R0),-(SP) ;SPACES
5964 ;      JSR     PC,$SB2D      ;PUT THE PASS COUNT ON THE STACK
5965 ;      JSR     R5,REPLZ     ;CONVERT IT
5966 ;      .WORD   3             ;TYPE IT
5967 ;      TYPE    ,LINSPL       ;TYPE 3 DIGITS
5968 ;      MOV      R2,-(SP)     ;SPACES
5969 ;      JSR     PC,$SB2D      ;PUT $OPERC ON THE STACK
5970 ;      JSR     R5,REPLZ     ;CONVERT IT
5971 ;      .WORD   6             ;TYPE $OPERC
5972 ;      TYPE    ,LINSPL       ;TYPE 6 DIGITS
5973 ;      ADD     #4,R2         ;SPACES
5974 ;      MOV      R2,-(SP)     ;INCREMENT R2
5975 ;      JSR     PC,$SB2D      ;PUT $POSIT ON THE STACK
5976 ;      JSR     R5,REPLZ     ;CONVERT IT
5977 ;      .WORD   6             ;TYPE $POSIT
5978 ;      TYPE    ,LINSPL       ;TYPE 6 DIGITS
5979 ;      ADD     #4,R2         ;SPACES
5980 ;      MOV      R2,-(SP)     ;INCREMENT R2
5981 ;      JSR     PC,$SB2D      ;PUT $TRANS ON THE STACK
5982 ;      JSR     R5,REPLZ     ;CONVERT $TRANS
5983 ;      .WORD   10            ;TYPE IT
5984 ;      TYPE    ,LINSPL       ;TYPE 10 DIGITS
5985 ;      ADD     #4,R2         ;SPACES
5986 ;      MOV      R2,-(SP)     ;INCREMENT R2
5987 ;      JSR     PC,$SB2D      ;PUT $READ ON THE STACK
5988 ;      JSR     R5,REPLZ     ;CONVERT $READ
5989 ;      .WORD   10            ;TYPE IT
5990 ;      TYPE    ,LINSPL       ;TYPE 10 DIGITS
5991 ;      ADD     #4,R2         ;1 SPACE
5992 ;      ADD     #2,R2         ;INCREMENT R2
5993 ;      MOV      (R2)+,-(SP)   ;INCREMENT R2 AGAIN
5994 ;      JSR     PC,$SB2D      ;PUT $SOFT ON THE STACK
5995 ;      JSR     R5,REPLZ     ;CONVERT $SOFT
5996 ;      .WORD   4             ;TYPEOUT $SOFT
5997 ;      TYPE    ,LINSPL       ;TYPE 4 DIGITS
5998 ;      MOV      (R2)+,-(SP)   ;SPACES
5999 ;      JSR     PC,$SB2D      ;PUT $HARD ON THE STACK
6000 ;      JSR     R5,REPLZ     ;CONVERT $HARD
6001 ;      .WORD   4             ;TYPEOUT $HARD
6002 ;      TYPE    ,LINSPL       ;TYPE 4 DIGITS
6003 ;      MOV      (R2)+,-(SP)   ;SPACES
6003 ;      MOV      (R2)+,-(SP)   ;PUT $SKI ON THE STACK
    
```

```

6004 023204 004737 030246 JSR PC,SSB2D ;CONVERT $SKI
6005 023210 004537 027556 JSR R5,REPLZ ;TYPEOUT $SKI
6006 023214 000004 .WORD 4 ;TYPE 4 DIGITS
6007 023216 104401 052717 TYPE LINSPO ;SPACES
6008 023222 012246 MOV (R2)+,-(SP) ;PUT $MISPO ON THE STACK
6009 023224 004737 030246 JSR PC,SSB2D ;CONVERT $MISPO
6010 023230 004537 027556 JSR R5,REPLZ ;TYPEOUT $MISPO
6011 023234 000004 .WORD 4 ;TYPE 4 DIGITS
6012 023236 104401 052717 TYPE LINSPO ;SPACES
6013 023242 016046 000056 MOV $TOTAL(R0),-(SP) ;CALCULATE NUMBER OF OTHER ERRORS
6014 023246 166016 000060 SUB $SOFT(R0),(SP) ;SUBTRACT $SOFT FROM $TOTAL
6015 023252 166016 000062 SUB $SHARD(R0),(SP) ;SUBTRACT $SHARD FROM $TOTAL
6016 023256 166016 000064 SUB $SKI(R0),(SP) ;SUBTRACT $SKI FROM $TOTAL
6017 023262 166016 000066 SUB $MISPO(R0),(SP) ;SUBTRACT $MISPO FROM $TOTAL
6018 023266 004737 030246 JSR PC,SSB2D ;CONVERT 'OTHER' COUNT
6019 023272 004537 027556 JSR R5,REPLZ ;TYPE IT
6020 023276 000004 .WORD 4 ;TYPE 4 DIGITS
6021 023300 005726 TST (SP)+ ;CLEAR STACK
6022 023302 000207 RTS PC

;ROUTINE TO INCREMENT $SOFT
;NOTE: $SOFT WILL NOT BE INCREMENTED BEYOND 9999 (10)
6023
6024
6025
6026
6027
6028
6029
6030 023304 005737 001362 INCSOF: TST BADSEC ;SEE IF BAD TRK/SEC INDICATOR SET
6031 023310 001006 BNE 1$ ;BR IF IT'S SET, DON'T INCREMENT COUNT
6032 023312 026027 000060 023417 CMP $SOFT(R0),#9999. ;IS $SOFT ALREADY AT MAXIMUM?
6033 023320 103002 BHIS 1$ ;BR IF IT IS
6034 023322 005260 000060 INC $SOFT(R0) ;INCREMENT $SOFT
6035 023326 000207 1$: RTS PC ;RETURN
6036
6037
6038
6039
6040
6041
6042 023330 005737 001362 INCHRD: TST BADSEC ;SEE IF BAD TRK/SEC INDICATOR SET
6043 023334 001006 BNE 1$ ;BR IF IT'S SET, DON'T INCREMENT COUNT
6044 023336 026027 000062 023417 CMP $SHARD(R0),#9999. ;IS $SHARD ALREADY AT MAXIMUM?
6045 023344 103002 BHIS 1$ ;BR IF IT IS
6046 023346 005260 000062 INC $SHARD(R0) ;INCREMENT $SHARD
6047 023352 000207 1$: RTS PC ;RETURN
6048
6049
6050
6051
6052
6053
6054 023354 005737 001362 INCSKI: TST BADSEC ;SEE IF BAD TRK/SEC INDICATOR SET
6055 023360 001006 BNE 1$ ;BR IF IT'S SET, DON'T INCREMENT COUNT
6056 023362 026027 000064 023417 CMP $SKI(R0),#9999. ;IS $SKI ALREADY AT MAXIMUM?
6057 023370 103002 BHIS 1$ ;BR IF IT IS
6058 023372 005260 000064 INC $SKI(R0) ;INCREMENT $SKI
6059 023376 000207 1$: RTS PC ;RETURN
    
```

```

6060
6061
6062 ;ROUTINE TO INCREMENT $MISPO
6063 ;
6064 ;NOTE: $MISPO WILL NOT BE INCREMENTED BEYOND 9999 (10)
6065
6066 023400 005737 001362 INCMIS: TST BADSEC ;SEE IF BAD TRK/SEC INDICATOR SET
6067 023404 001006 BNE 1$ ;BR IF IT'S SET, DON'T INCREMENT COUNT
6068 023406 026027 000066 023417 CMP $MISPO(RO),#9999. ;IS $MISPO ALREADY AT MAXIMUM ?
6069 023414 103002 BHIS 1$ ;BR IF IT IS
6070 023416 005260 000066 INC $MISPO(RO) ;INCREMENT $MISPO
6071 023422 000207 1$: RTS PC ;RETURN
6072
6073
6074 ;ROUTINE TO INCREMENT $TOTAL
6075 ;
6076 ;NOTE: $TOTAL WILL NOT BE INCREMENTED BEYOND 9999 (10)
6077
6078 023424 005737 001362 INCTOT: TST BADSEC ;SEE IF BAD TRK/SEC INDICATOR SET
6079 023430 001006 BNE 1$ ;BR IF IT'S SET, DON'T INCREMENT COUNT
6080 023432 026027 000056 023417 CMP $TOTAL(RO),#9999. ;IS $TOTAL ALREADY AT MAXIMUM ?
6081 023440 103002 BHIS 1$ ;BR IF IT IS
6082 023442 005260 000056 INC $TOTAL(RO) ;INCREMENT $TOTAL
6083 023446 000207 1$: RTS PC ;RETURN
6084
6085
6086 ;ROUTINE TO TYPE THE TIME
6087
6088 023450 005737 001310 $TIME: TST CLKFLG ;CLOCK ON THE SYSTEM ?
6089 023454 001033 BNE 1$ ;BR IF NOT
6090 023456 104401 001201 TYPE ,SCRLF ;CR-LF
6091 023462 013746 001364 MOV HOUR,-(SP) ;PUT 'HOURS' ON THE STACK
6092 023466 004737 030246 JSR PC,$SB2D ;CONVERT TO DECIMAL
6093 023472 004537 027556 JSR R5,REPLZ ;TYPE IT
6094 023476 000002 .WORD 2 ;TYPE 2 DIGITS
6095 023500 104401 053766 TYPE COLON ;:
6096 023504 013746 001366 MOV MINUTE,-(SP) ;PUT 'MINUTES' ON THE STACK
6097 023510 004737 030246 JSR PC,$SB2D ;CONVERT TO DECIMAL
6098 023514 004537 027556 JSR R5,REPLZ ;TYPE IT
6099 023520 000002 .WORD 2 ;TYPE 2 DIGITS
6100 023522 104401 053766 TYPE COLON ;:
6101 023526 013746 001370 MOV SECOND,-(SP) ;PUT SECONDS ON THE STACK
6102 023532 004737 030246 JSR PC,$SB2D ;CONVERT TO DECIMAL
6103 023536 004537 027556 JSR R5,REPLZ ;TYPE IT
6104 023542 000002 .WORD 2 ;TYPE 2 DIGITS
6105 023544 000207 1$: RTS PC
6106
6107 ;CLOCK HANDLER ROUTINE
6108
6109 023546 005337 001372 CLOCK: DEC SIXTEE ;INCREMENT THE 1/60 SECOND COUNTER
6110 023552 001035 BNE 1$ ;BR IF A SECOND NOT COUNTED
6111 023554 013737 001312 001372 MOV HZ,SIXTEE ;RESTORE THE VALUE
6112 023562 005237 001370 INC SECOND ;COUNT THE SECOND
6113 023566 022737 000074 001370 CMP #60.,SECOND ;AT MAXIMUM ?
6114 023574 001024 BNE 1$ ;BR IF NOT
6115 023576 005037 001370 CLR SECOND ;CLEAR THE SECOND'S COUNTER
    
```

```

6116 023602 005237 001470      INC      INTRVL+2      ;COUNT THE PERFORMANCE SUMMARY INTERVAL
6117 023606 005237 001366      INC      MINUTE       ;COUNT THE MINUTE
6118 023612 022737 000074 001366      CMP      #60.,MINUTE ;AT MAXIMUM ?
6119 023620 001012                BNE      1$          ;BR IF NOT
6120 023622 005037 001366      CLR      MINUTE       ;CLEAR THE MINUTE'S COUNTER
6121 023626 005237 001364      INC      HOUR         ;COUNT THE HOURS
6122 023632 022737 001747 001364      CMP      #999.,HOUR  ;AT MAXIMUM
6123 023640 103002                BNE      1$          ;BR IF NOT
6124 023642 005037 001364      CLR      HOUR         ;CLEAR THE HOURS
6125 023646 012746 000020 1$:      MOV      #20,-(SP)    ;1 MS ON THE STACK
6126 023652 004737 040576      JSR      PC,RPTMR     ;DRIVER TIMER ROUTINE
6127 023656 005737 001466      TST      INTRVL      ;DISPLAY THE PERFORMANCE SUMMARY ?
6128 023662 001411                BEQ      2$          ;BR IF NOT
6129 023664 023737 001466 001470      CMP      INTRVL,INTRVL+2 ;DISPLAY INTERVAL FINISHED ?
6130 023672 001005                BNE      2$          ;BR IF NOT
6131 023674 012737 177777 001314      MOV      #-1,STATIN  ;SET PERFORMANCE SUMMARY DISPLAY FLAG
6132 023702 005037 001470      CLR      INTRVL+2    ;CLEAR THE PERFORMANCE INTERVAL COUNTER
6133 023706 000002 2$:      RTI
6134
6135      ;COMMAND DECODE ROUTINE
6136      ;CALL:
6137      ;      MOV      #-1,CFLAG      ;'CFLAG' IS NORMALLY SET BY THE TTY SERVICE
6138      ;      ;ROUTINE IN INTERRUPT MODE
6139      ;      JSR      PC,KSR
6140      ;      RETURN1      ;SYSTEM BUSY RETURN
6141      ;      RETURN2     ;RETURN AFTER KEYBOARD SERVICED
6142
6143 023710 005737 001540      KSR:    TST      ORDERQ+16      ;ANY OPERATIONS ACTIVE ?
6144 023714 001402                BEQ      KSR1
6145 023716 104401 054077      TYPE    ,BUSY
6146 023722 104412      KSR1:   SAVREG
6147 023724 012737 000200 177776      MOV      #PR4,PS
6148 023732 005037 001360      CLR      CFLAG
6149 023736 004737 023450      JSR      PC,STIME
6150 023742 005777 155214      TST      #STKB
6151 023746 104401 053612      TYPE    ,ENTCOM
6152 023752 104411      RDLIN
6153 023754 012605      MOV      (SP)+,R5
6154 023756 005737 001360      TST      CFLAG
6155 023762 001116                BNE      7$
6156 023764 005205      INC      R5
6157 023766 122715 000124      CMPB    #'T,(R5)
6158 023772 001462                BEQ      8$
6159 023774 122715 000101      CMPB    #'A,(R5)
6160 024000 001410                BEQ      1$
6161 024002 121527 000067      CMPB    (R5),#'7
6162 024006 101102                BHI      6$
6163 024010 121527 000060      CMPB    (R5),#'0
6164 024014 103477                BLO      6$
6165 024016 142715 177770      BICB    #7,(R5)
6166 024022 122765 000124 177777 1$:      CMPB    #'T,-1(R5)
6167 024030 001003                BNE      2$
6168 024032 004737 024576      JSR      PC,NEWASN
6169 024036 000470                BR       7$
6170 024040 122765 000104 177777 2$:      CMPB    #'D,-1(R5)
6171 024046 001003                BNE      3$
    
```

6172	024050	004737	024606			JSR	PC,DEASGN		;DEASSIGN DRIVE
6173	024054	000461				BR	7\$		;EXIT
6174	024056	122765	000123	177777	3\$:	CMPB	#'S,-1(R5)		;EQ TO 'S'
6175	024064	001003				BNE	4\$		;BR IF NOT EQ
6176	024066	004737	024716			JSR	PC,SCMND		;TYPE STATISTICS
6177	024072	000452				BR	7\$		;EXIT
6178	024074	122765	000127	177777	4\$:	CMPB	#'W,-1(R5)		;EQ TO 'W'
6179	024102	001007				BNE	5\$		;BR IF NOT EQ
6180	024104	032777	000001	155042		BIT	#SW0,ASWR		;IS SWITCH 0 SET ?
6181	024112	001040				BNE	6\$		;BR IF SET, CAN'T DO 'W' COMMAND
6182	024114	004737	025150			JSR	PC,DATAPK		;WRITE A DATA PACK
6183	024120	000437				BR	7\$		;EXIT
6184	024122	122765	000122	177777	5\$:	CMPB	#'R,-1(R5)		;EQ TO 'R' ?
6185	024130	001031				BNE	6\$		;BR IF NOT EQ
6186	024132	004737	025200			JSR	PC,REDAPK		;READ A DATA PACK
6187	024136	000430				BR	7\$		;EXIT
6188	024140	122765	000127	177777	8\$:	CMPB	#'W,-1(R5)		;WT COMMAND ?
6189	024146	001022				BNE	6\$		;NO
6190	024150	122765	000101	000001		CMPB	#'A,1(R5)		;ALL DRIVES ?
6191	024156	001413				BEQ	9\$		;YES
6192	024160	126527	000001	000067		CMPB	1(R5),#'7		;GREAT THAN 7
6193	024166	101012				BHI	6\$		;YES
6194	024170	126527	000001	000000		CMPB	1(R5),#0		;LESS THAN 0
6195	024176	103406				BLO	6\$		;YES
6196	024200	142765	177770	000001		BICB	#C7,1(R5)		;CHOP OFF THE HIGHER BITS
6197	024206	004737	025162		9\$:	JSR	PC,WATPAK		;ASSIGN DRIVES WITH WT COMMAND
6198	024212	000402				BR	7\$		
6199	024214	104401	053570		6\$:	TYPE	,INVLD		;TYPE 'INVALID COMMAND' MESSAGE
6200	024220	104413			7\$:	RESREG			;RESTORE R0 - R5
6201	024222	005777	154734			TST	ASSTKB		;CLEAR THE TTY BUFFER
6202	024226	052777	000100	154724		BIS	#BIT06,ASSTKS		;SET TTY INTERRUPT ENABLE
6203	024234	005037	177776			CLR	PS		;SET PRIORITY BACK TO ZERO
6204	024240	000207				RTS	PC		;RETURN
6205									
6206									
6207									;ROUTINE TO PROCESS THE ASSIGN REQUEST ('T', 'R', OR 'W' COMMANDS)
6208	024242	122715	000101			ASSIGN:	CMPB #'A,(R5)		;ASSIGN ALL DRIVES?
6209	024246	001426				BEQ	ASGN2		;BR IF ALL DRIVES
6210	024250	111504				ASGN1:	MOV (R5),R4		;PUT DRIVE # IN R4
6211	024252	012737	053026	026564		MOV	#UNTSN,ASNMSG		;DRIVE ASSIGNED' MESSAGE ADDRESS
6212	024260	136437	034304	001544		BITB	ATABIT(R4),ASNLST		;DRIVE ALREADY ASSIGNED ?
6213	024266	001014				BNE	2\$		;BR IF IT IS
6214	024270	005704				TST	R4		;TRYING TO ASSIGN DRIVE 0 ?
6215	024272	001007				BNE	1\$		;BR IF NOT
6216	024274	012737	053106	026564		MOV	#NOTAVL,ASNMSG		;NOT AVAILABLE' MESSAGE ADDRESS
6217	024302	122737	000024	000041		CMPB	#24,41		;SEE IF LOADED FROM AN RMO3
6218	024310	001403				BEQ	2\$		;BR IF RMO3 IS THE LOAD DEVICE
6219	024312	004737	024406		1\$:	JSR	PC,ASGN3		;SEE IF DRIVE ON THE SYSTEM
6220	024316	000207				RTS	PC		;RETURN
6221	024320	000137	026544		2\$:	JMP	ASNERR		;EXIT ERROR
6222	024324	122737	000024	000041	ASGN2:	CMPB	#24,41		;LOADED FROM AN RMO3 ?
6223	024332	001003				BNE	1\$		;BR IF NOT
6224	024334	012704	000001			MOV	#1,R4		;START WITH DRIVE 1
6225	024340	000401				BR	2\$		;CONTINUE
6226	024342	005004			1\$:	CLR	R4		;START WITH DRIVE 0
6227	024344	012737	053026	026564	2\$:	MOV	#UNTSN,ASNMSG		;ERROR MESSAGE

```

6228 024352 136437 034304 001544 BITB ATABIT(R4),ASNLST ;ALREADY ASSIGNED ?
6229 024360 001007 BNE 4$ ;YES
6230 024362 004737 024406 JSR PC,ASGN3 ;ASSIGN THE DRIVE
6231 024366 005204 3$: INC R4 ;INCREMENT DRIVE #
6232 024370 022704 000007 CMP #7,R4 ;ALL DRIVE CHECKED ?
6233 024374 002363 BGE 2$ ;NO
6234 024376 000207 RTS PC ;YES
6235 024400 004737 026544 4$: JSR PC,ASNERR ;ERROR MESSAGE
6236 024404 000770 BR 3$ ;TO LOOP
6237 024406 136437 034304 001544 ASGN3: BITB ATABIT(R4),ASNLST ;DRIVE ALREADY ASSIGNED ?
6238 024414 001041 BNE ASGN4 ;BR IF IT IS
6239 ;1$: TST DTUM ;DATA TRANSFER UNDER WAY ?
6240 ; BPL 1$ ;BR IF IT IS
6241 024416 110437 045532 MOV R4,GENDPB ;DRIVE NUMBER
6242 024422 004737 014770 JSR PC,RECALO ;RECALIBRATE DRIVE
6243 024426 105764 034170 TSTB DRVSTA(R4) ;DRIVE AVAILABLE?
6244 024432 001440 BEQ ASGN7 ;BR IF DRIVE OFFLINE OR NONEXISTENT
6245 024434 100432 BMI ASGN6 ;BR IF DRIVE UNSAFE
6246 024436 006304 ASL R4 ;MAKE R4 INTO WORD INDEX
6247 ; MOV BLKADR(R4),NEWUNT(R4) ;DPB ADDRESS
6248 024440 016400 002102 MOV BLKADR(R4),RO ;PUT BLOCK'S ADDR INTO RO
6249 024444 004737 025212 JSR PC,CLRDPB ;CLEAR BLOCK FOR DRIVE JUST ASSIGNED
6250 024450 004737 025412 JSR PC,DRVPRM ;GET THE DRIVE'S ADDRESS LIMITS
6251 024454 004737 025654 JSR PC,GETID ;GET DRIVE I.D.
6252 024460 004537 025764 JSR R5,GETADR ;GET BAD SECTOR ADDRESSES
6253 024464 000414 BR 2$ ;BRANCH IF RETRIEVE FAILS
6254 024466 016464 002102 001570 MOV BLKADR(R4),NEWUNT(R4) ;DPB ADDRESS
6255 024474 012760 000001 000070 MOV #1,SPASSC(RO) ;PRESET PASS COUNT TO 1
6256 024502 005737 001316 TST PACK ;WRITE DATA PACK ?
6257 024506 001403 BEQ 2$ ;BR IF NOT
6258 024510 113760 001316 000026 MOV BPL,SPACK(RO) ;SET READ/WRITE DATA PACK INDICATOR
6259 024516 006204 2$: ASL R4 ;RESTORE DRIVE ADDRESS
6260 024520 000207 ASGN4: RTS PC ;RETURN
6261 024522 012737 053125 026564 ASGN6: MOV #NOTSAF,ASNMSG ;'UNSAFE' MESSAGE ADDRESS
6262 024530 000137 026544 JMP ASNERR ;TO ERROR ROUTINE
6263 024534 105764 034200 ASGN7: TSTB DRVSTYP(R4) ;DRIVE PRESENT?
6264 024540 001405 BEQ 1$ ;BR IF NOT
6265 024542 100010 BPL 2$ ;BR IF DRIVE OFFLINE
6266 024544 012737 053054 026564 MOV #NOTRM,ASNMSG ;ADDRESS OF 'NOT RMD3' MSG
6267 024552 000407 BR 3$ ;EXIT
6268 024554 012737 053071 026564 1$: MOV #NOTPRS,ASNMSG ;ADDRESS OF 'NOT PRESENT' MSG
6269 024562 000403 BR 3$ ;EXIT
6270 024564 012737 052763 026564 2$: MOV #UNTOFF,ASNMSG ;ADDRESS OF 'DRIVE OFFLINE' MESSAGE
6271 ;3$: RTS PC ;ERROR RETURN
6272 024572 000137 026544 3$: JMP ASNERR ;TO ERROR ROUTINE
6273
6274 ;'T' COMMAND (ROUTINE TO ASSIGN A DRIVE)
6275
6276 024576 005037 001316 NEWASN: CLR PACK ;CLEAR 'W' COMMAND INDICATOR
6277 024602 000137 024242 JMP ASSIGN ;GO TO THE ASSIGN ROUTINE
6278
6279 ;'D' COMMAND (ROUTINE TO DEASSIGN A DRIVE)
6280
6281 024606 005004 DEASGN: CLR R4
6282 024610 012703 000010 MOV #8,R3 ;COUNTER
6283 024614 122715 000101 CMPB #'A',(R5) ;DEASSIGN ALL DRIVES ?
    
```



```

6284 024620 001403      BEQ      1$          ;BR IF YES
6285 024622 012703 000001  MOV      #BIT00,R3    ;SET R3 FOR ONE UNIT
6286 024626 111504      MOVB     (R5),R4      ;GET DRIVE NUMBER
6287 024630 136437 034304 001544 1$:  BITB     ATABIT(R4),ASNLST ;DRIVE ASSIGNED ?
6288 024636 001414      BEQ      3$          ;BR IF NOT
6289 024640 146437 034304 001544  BICB     ATABIT(R4),ASNLST ;DELETE THE DRIVE FROM THE ASSIGNED LIST
6290 024646 006304      ASL      R4          ;MAKE ADDR INTO A WORD INDEX
6291 024650 016464 002102 001546  MOV      BLKADR(R4),DUNIT(R4) ;PUT ADDRESS IN DEASSIGN LIST
6292 024656 006204      ASR      R4
6293 024660 005303      2$:  DEC      R3          ;ANY MORE DRIVES ?
6294 024662 001412      BEQ      4$          ;BR IF NOT
6295 024664 005204      INC      R4
6296 024666 000760      BR       1$
6297 024670 012737 053004 026564 3$:  MOV      #UNTNOT,ASNMSG ;ADDR OF 'NOT ASSIGNED' MESSAGE
6298 024676 004737 026544      JSR      PC,ASNERR    ;REPORT IT
6299 024702 122715 000101      CMPB     #'A',(R5)    ;ALL DRIVE ?
6300 024706 001764      BEQ      2$          ;YES
6301 024710 104401 001201 4$:  TYPE     SCRLF
6302 024714 000207      RTS      PC
6303
6304 ;'S' COMMAND (ROUTINE TO TYPE DRIVE PERFORMANCE SUMMARY)
6305
6306 024716 005004      SCMND:  CLR      R4
6307 024720 012703 000010  MOV      #8.,R3      ;COUNTER
6308 024724 122715 000101  CMPB     #'A',(R5)    ;ALL STATISTICS ?
6309 024730 001421      BEQ      3$          ;BR IF YES
6310 024732 111504      MOVB     (R5),R4      ;GET DRIVE NUMBER
6311 024734 136437 034304 001544  BITB     ATABIT(R4),ASNLST ;SEE IF DRIVE ASSIGNED
6312 024742 001406      BEQ      1$          ;BR IF NOT
6313 024744 006304      ASL      R4          ;MAKE DRIVE ADDR INTO WORD INDEX
6314 024746 016400 002102  MOV      BLKADR(R4),R0 ;ADDR OF BLOCK
6315 024752 004737 022702  JSR      PC,TYPEST    ;TYPE DRIVE STATISTICS
6316 024756 000471      BR       8$
6317 024760 012737 053004 026564 1$:  MOV      #UNTNOT,ASNMSG ;ADDR OF 'NOT ASSIGNED' MSG
6318 024766 004737 026544      JSR      PC,ASNERR    ;TYPE ERROR MESSAGE
6319 024772 000463      BR       8$
6320 024774 105737 001544 3$:  TSTB     ASNLST      ;ANY DRIVE ASSIGNED ?
6321 025000 001001      BNE     4$          ;YES
6322 025002 000457      BR       8$
6323 025004 004737 022614 4$:  JSR      PC,STATPR    ;TYPE ALL STATISTICS
6324 025010 105737 001320  TSTB     DATE        ;SEE IF 'DATE' ENTERED
6325 025014 001404      BEQ      11$         ;BR IF NOT
6326 025016 104401 053770  TYPE     ,DATEIS     ;'DATE: '
6327 025022 104401 001320  TYPE     ,DATE        ;THE OPERATOR ENTERED DATE
6328 025026 105737 001332 11$:  TSTB     OPERID      ;SEE IF OPERATOR I.D. ENTERED
6329 025032 001404      BEQ      12$         ;BR IF NOT
6330 025034 104401 054001  TYPE     ,IDIS       ;'OPERATOR I.D.: '
6331 025040 104401 001332  TYPE     ,OPERID      ;THE OPERATOR I.D.
6332 025044 104401 054023 12$:  TYPE     ,HEDLIN     ;HEADER LINE
6333 025050 012737 042716 025116  MOV      #DRIVED+$ORVID,6$ ;DRIVE I.D. FIELD ADDRESS
6334 025056 136437 034304 001544 5$:  BITB     ATABIT(R4),ASNLST ;SEE IF DRIVE ASSIGNED
6335 025064 001417      BEQ      7$          ;BR IF NOT ASSIGNED
6336 025066 010446      MOV      R4,-(SP)    ;SAVE R4 FOR TYPEOUT
6337
6338 025070 104403      TYPOS
6339 025072 002          .BYTE 2            ;TYPE 2 DIGIT(S)

```

```

6340 025073 000 .BYTE 0 ; SUPPRESS LEADING ZEROS
6341 025074 104401 052714 TYPE LINHSP ; 4 SPACES
6342 025100 105777 000012 TSTB #65 ; SEE IF DRIVE I.D. ENTERED
6343 025104 001003 BNE 105 ; BR IF DRIVE I.D. PRESENT
6344 025106 104401 054046 TYPE NONE ; TYPE 'NONE'
6345 025112 000404 BR #7 ; CONTINUE
6346 025114 104401 105: TYPE ; TYPE THE DRIVE I.D.
6347 025116 000000 65: .WORD 0 ; ADDRESS OF DRIVE I.D. FIELD HERE
6348 025120 104401 001201 TYPE SCRLF ; CR-LF
6349 025124 005303 75: DEC R3 ; DECREMENT THE COUNTER
6350 025126 003405 BLE #5 ; BR IF AT END
6351 025130 062737 000304 025116 ADD #SRMEC2+2,65 ; INCREMENT THE MESSAGE FIELD ADDRESS
6352 025136 005204 INC R4 ; INCREMENT DRIVE ADDRESS
6353 025140 000746 BR #5 ; CONTINUE
6354 025142 104401 001201 85: TYPE SCRLF ; CR-LF
6355 025146 000207 95: RTS PC
6356
6357 ; 'W' COMMAND (ROUTINE TO WRITE A DATA PACK)
6358
6359 025150 012737 177777 001316 DATAPK: MOV #-1,PACK ; SET THE 'W' COMMAND INDICATOR
6360 025156 000137 024242 JMP ASSIGN ; ASSIGN REQUESTED DRIVE
6361
6362 ; 'WT' COMMAND (TO WRITE A PACK AND FOLLOWED BY TEST PACK)
6363 025162 116515 000001 WATPAK: MOVB 1(R5),R5 ; ADJUST DRIVE NUMBER ADDRESS
6364 025166 012737 177776 001316 MOV #-2,PACK ; PACK WRITE COMMAND
6365 025174 000137 024242 JMP ASSIGN ; JUMP TO ASSIGN ROUTINE
6366
6367 ; 'R' COMMAND (ROUTINE TO READ A DATA PACK)
6368 025200 012737 000001 001316 REDAPK: MOV #1,PACK ; SET THE 'READ' INDICATOR
6369 025206 000137 024242 JMP ASSIGN ; ASSIGN THE REQUESTED DRIVE
6370
6371 ; ROUTINE TO CLEAR THE DPB FOR THE ASSIGNED DRIVE
6372 ; CALL:
6373 ; MOV #DPB,R0 ; DPB ADDRESS
6374 ; JSR PC,CLRDPB
6375 ; RETURN
6376
6377 CLRDPB:
6378 025212 010146 MOV R1,-(SP) ; PUSH R1 ON STACK
6379 025214 010346 MOV R3,-(SP) ; PUSH R3 ON STACK
6380 025216 010446 MOV R4,-(SP) ; PUSH R4 ON STACK
6381 025220 010546 MOV R5,-(SP) ; PUSH R5 ON STACK
6382 025222 010004 MOV R0,R4 ; GET THE DPB ADDRESS
6383 025224 062704 000002 ADD #2,R4 ; ADDRESS OF FIRST LOCN TO BE CLEARED
6384 025230 012703 000005 MOV #5,R3 ; NUMBER OF LOCNS TO BE CLEARED
6385 025234 005024 15: CLR (R4)+ ; CLEAR THE LOCATION
6386 025236 005303 DEC R3 ; DECREMENT THE COUNTER
6387 025240 001375 BNE #1 ; BR IF NOT FINISHED
6388 025242 062704 000002 ADD #2,R4 ; MOVE THE ADDRESS PAST THE 'REG' ADDR
6389 025246 012703 000070 MOV #SNEXT-SREG,R3 ; NUMBER OF LOCNS TO BE CLEARED
6390 025252 005024 25: CLR (R4)+ ; CLEAR
6391 025254 162703 000002 SUB #2,R3 ; DECREMENT THE LOCN COUNTER
6392 025260 001374 BNE #25 ; BR IF NOT FINISHED
6393 025262 062704 000014 ADD #12,R4 ; MOVE PAST ADDRESS LIMITS
6394 025266 012703 000162 MOV #SRMEC2-MINSEC,R3 ; NUMBER OF LOCNS TO BE CLEARED
6395 025272 005024 35: CLR (R4)+ ; CLEAR A LOCATION
    
```

```

6396 025274 162703 000002 SUB #2,R3 ;DECREMENT THE COUNTER
6397 025300 001374 BNE 3$ ;BR IF NOT DONE
6398 025302 113760 001516 000024 MOVB BEGCOO,$CODE(RO) ;INITIAL COMMAND CODE
6399 025310 013701 001516 MOV BEGCOO,R1 ;GET THE ACTUAL OP CODE
6400 025314 116160 002122 000002 MOVB COMTBL(R1),$COMND(RO) ;OPERATION CODE
6401 025322 113760 001514 000030 MOVB BEGPAT,$PATTTC(RO) ;PATTERN CODE
6402 025330 106360 000030 ASLB $PATTTC(RO) ;CONVERT CODE TO A TABLE INDEX
6403 025334 013760 001520 000020 MOV BEGSIZ,$SRDL(RO) ;BEGINNING RECORD SIZE
6404 025342 013760 001520 000004 MOV BEGSIZ,$SRDM(RO) ;VALUE FOR DATA TRANSFER
6405 025350 005460 000004 NEG $SRDM(RO) ;MAKE IT INTO 2'S COMPLEMENT
6406 025354 012760 000400 000022 MOV #256,$SSEC(RO) ;INITIAL VALUE OF SECTOR SIZE
6407 025362 132760 000001 000024 BITB #1,$CODE(RO) ;HEADER ORDER ?
6408 025370 001403 BEQ 4$ ;BR IF NOT
6409 025372 062760 000002 000022 ADD #2,$SSEC(RO) ;ADD HEADER SIZE TO SECTOR SIZE
6410 025400 4$:
6411 025400 012605 MOV (SP)+,R5 ;:POP STACK INTO R5
6412 025402 012604 MOV (SP)+,R4 ;:POP STACK INTO R4
6413 025404 012603 MOV (SP)+,R3 ;:POP STACK INTO R3
6414 025406 012601 MOV (SP)+,R1 ;:POP STACK INTO R1
6415 025410 000207 RTS PC ;RETURN
6416
6417 ;ROUTINE TO GET ADDRESS LIMITS FROM THE OPERATOR
6418
6419 025412 010346 DRVPRM: MOV R3,-(SP) ;SAVE R3
6420 025414 010446 MOV R4,-(SP) ;SAVE R4
6421 025416 005737 000042 TST 42 ;RUNNING UNDER MONITOR CONTROL
6422 025422 001024 BNE 3$ ;BR IF YES
6423 025424 104401 053664 TYPE ,ENTLMT ;'ENTER ADDRESSES'
6424 025430 006204 ASR R4 ;CONVERT INDEX TO DRIVE NUMBER
6425 025432 010446 MOV R4,-(SP) ;SAVE R4 FOR TYPEOUT
6426 ;TYPE DRIVE NUMBER
6427 025434 104403 TYPOS ;GO TYPE--OCTAL ASCII
6428 025436 002 .BYTE 2 ;TYPE 2 DIGIT(S)
6429 025437 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
6430 025440 104401 054474 TYPE ,SLASH ;'/'
6431 025444 012737 053155 025466 MOV #RMO3A,2$ ;ADDRESS OF 'RMO3' MESSAGE
6432 025452 132764 000004 034200 BITB #BIT02,DRVTP(R4) ;RMO3 ?
6433 025460 001001 BNE 1$ ;BR IF YES
6434 025462 000000 HALT ;NOT RMO3 PROGRAM SHOULD NOT HAVE
6435 ;REACHED THIS POINT
6436 025464 104401 1$: TYPE ;TYPE THE MESSAGE WHICH FOLLOWS
6437 025466 000000 2$: .WORD 0 ;MESSAGE ADDRESS
6438 025470 104401 001201 TYPE ,$CRLF ;CR-LF
6439 025474 012737 001465 001446 3$: MOV #821,CYLIMT ;ASSUME AN RMO3
6440 025502 132764 000004 034200 BITB #BIT02,DRVTP(R4) ;MAKE SURE RMO3
6441 025510 001001 BNE 4$ ;BR IF RMO3
6442 025512 000000 HALT ;HALT IF NOT
6443 025514 116460 034200 000262 4$: MOVB DRVTP(R4),$RMDT(RO) ;INITIATE $RMDT
6444 025522 062760 177777 000122 ADD #-1,$FIRST(RO) ;SEE IF FIRST TIME STARTED
6445 025530 103417 BCS 5$ ;BR IF NOT
6446 025532 013760 001446 000106 MOV CYLIMT,MAXCYL(RO) ;LOAD MAXIMUM CYLINDER
6447 025540 005060 000110 CLR MINCYL(RO) ;CLEAR MINIMUM CYLINDER
6448 025544 013760 001444 000112 MOV TRKLMT,MAXTRK(RO) ;LOAD MAXIMUM TRACK
6449 025552 005060 000114 CLR MINTRK(RO) ;CLEAR MINIMUM TRACK
6450 025556 013760 001442 000116 MOV SECLMT,MAXSEC(RO) ;LOAD MAXIMUM SECTOR
6451 025564 005060 000120 CLR MINSEC(RO) ;CLEAR MINIMUM SECTOR

```

```

6452 025570 006304          5$: ASL    R4          ;SETUP TO ADDRESS WORDS
6453 025572 016403 054710  MOV    TABLE(R4),R3 ;PARAMETER TABLE ADDRESS
6454 025576 013763 001446 000002  MOV    CYLINT,2(R3)  ;LOAD CYLINDER LIMIT FOR LAST CYLINDER
6455 025604 013763 001446 000010  MOV    CYLINT,10(R3) ;LOAD CYLINDER LIMIT FOR STARTING CYLINDER
6456 025612 005737 000042          TST    42          ;UNDER MONITOR CONTROL ?
6457 025616 001002          BNE    6$          ;BR IF YES
6458 025620 004737 026420          JSR    PC,PARENT   ;GET THE DRIVE'S PARAMETERS
6459 025624 116060 000120 000010 6$: MOVB  MINSEC(RO),SSEC(RO) ;INITIAL SECTOR VALUE
6460 025632 116060 000114 000011  MOVB  MINTRK(RO),STRK(RO) ;INITIAL TRACK VALUE
6461 025640 016060 000110 000012  MOV    MINCYL(RO),SCYL(RO) ;INITIAL CYLINDER VALUE
6462 025646 012604          MOV    (SP)+,R4    ;RESTORE R4
6463 025650 012603          MOV    (SP)+,R3    ;RESTORE R3
6464 025652 000207          RTS    PC          ;RETURN
    
```

;ROUTINE TO GET THE DRIVE I.D. FROM THE OPERATOR

```

6466          GETID: MOV    R5,-(SP)    ;SAVE R5
6467          TST    42          ;UNDER MONITOR CONTROL ?
6468 025654 010546 000042          BNE    2$          ;BR IF NOT
6469 025656 005737          CLR    CFLAG      ;CLEAR THE 'CONTROL C' FLAG
6470 025662 001036          TYPE  ,ENTDRV    ;'ENTER DRV I.D.:'
6471 025664 005037 001360          CLR    -(SP)     ;CLEAR THE STACK
6472 025670 104401 053637          MOVB  (RO),(SP)  ;PUT THE DRIVE NUMBER ON THE STACK
6473 025674 005046          TYPOS           ;TYPE THE DRIVE NUMBER
6474 025676 111016          .BYTE 2         ;TYPE 2 DIGITS
6475 025700 104403          .BYTE 0         ;SUPPRESS LEADING ZEROS
6476 025702          .BYTE 0         ;CR-LF
6477 025703          TYPE  ,$CRLF   ;READ THE ENTRY
6478 025704 104401 001201          MOV    (SP)+,R5  ;GET THE ENTRY ADDRESS
6479 025710 104411          TST    CFLAG     ;'CONTROL C' ENTERED ?
6480 025712 012605          BNE    1$        ;BR IF IT WAS
6481 025714 005737 001360          CMPB  (R5),#'.' ;PERIOD ENTERED ?
6482 025720 001361          BEQ    2$        ;BR IF YES
6483 025722 121527 000056          MOVB  (R5)+,$DRVID(RO) ;STORE THE I.D.
6484 025726 001414          MOVB  (R5)+,$DRVID+1(RO) ;STORE THE I.D.
6485 025730 112560 000224          MOVB  (R5)+,$DRVID+2(RO) ;STORE THE I.D.
6486 025734 112560 000225          MOVB  (R5)+,$DRVID+3(RO) ;STORE THE I.D.
6487 025740 112560 000226          MOVB  (R5)+,$DRVID+4(RO) ;STORE THE I.D.
6488 025744 112560 000227          MOVB  (R5)+,$DRVID+5(RO) ;STORE THE I.D.
6489 025750 112560 000230          MOVB  (R5)+,$DRVID+5(RO) ;STORE THE I.D.
6490 025754 112560 000231          MOV    (SP)+,R5  ;RESTORE R5
6491 025760 012605          RTS    PC        ;RETURN
6492 025762 000207
    
```

;ROUTINE TO GET THE ADDRESSES OF ANY BAD SECTORS (UP TO A MAX OF 16)

```

6493          ;CALL SEQ
6494          ;
6495          ;
6496          ;
6497          ;
6498          ;
6499          ;
6500          ;RO DPB ADDRESS
6501          GETADR:
6502 025764          MOV    R1,-(SP)  ;;PUSH R1 ON STACK
6503 025764 010146          MOV    R2,-(SP)  ;;PUSH R2 ON STACK
6504 025766 010246          MOV    R3,-(SP)  ;;PUSH R3 ON STACK
6505 025770 010346          MOV    R4,-(SP)  ;;PUSH R4 ON STACK
6506 025772 010446          MOV    R0,R1     ;;DPB ADDRESS
6507 025774 010001
    
```

6508	025776	062701	000124		ADD	#\$B0SEC,R1	; ADDRESS OF BAD SECTOR TABLE	
6509	026002	012702	000040		MOV	#32.,R2	; WORD CTR	
6510	026006	012721	177777	1\$:	MOV	#-1,(R1)+	; INITIALIZE ALL LOCS TO -1	
6511	026012	005302			DEC	R2	; DECREMENT WORD CTR	
6512	026014	001374			BNE	1\$	; BRANCH IF NOT DONE	
6513	026016	112737	000171	045534	MOVB	#\$DDAT,GENDPB+\$COMND	; READ DATA COMMAND	
6514	026024	012737	001466	045544	MOV	#\$22.,GENDPB+\$CYL	; LAST CYLINDER	
6515	026032	112737	000004	045543	MOVB	#\$4,GENDPB+\$TRK	; LAST TRACK	
6516	026040	012737	177400	045536	MOV	#\$-256.,GENDPB+\$WRDM	; ONE SECTOR WORD CTR	
6517	026046	111037	045532		MOVB	(R0),GENDPB	; DRIVE NUMBER	
6518	026052	005037	001264		CLR	\$CDW1	; ERROR FLAG	
6519	026056	005046			CLR	-(SP)	; DUMMY PAIR	
6520	026060	005046			CLR	-(SP)	; DUMMY PAIR	
6521	026062	012746	000012		MOV	#\$12,-(SP)	; STARTING SECTOR 10.	
6522	026066	012746	000036		MOV	#\$30,-(SP)	; LAST SECTOR	
6523	026072	012737	000010	001266	MOV	#\$10,\$CDW2	; LAST SECTOR	
6524	026100	105037	045542		CLRB	GENDPB+\$SEC	; STARTING SECTOR	
6525	026104	004037	035040	2\$:	JSR	R0,RMO3	; READ CURRENT SECTOR	
6526	026110	045532			GENDPB		; BRANCH IF QUEUE FAILS	
6527	026112	000774			BR	2\$		
6528	026114	005737	045550	3\$:	TST	GENDPB+\$STATUS	; DONE YET ?	
6529	026120	001775			BEQ	3\$	; BRANCH IF NOT	
6530	026122	100013			BPL	4\$	; BRANCH IF DONE WITHOUT ERROR	
6531	026124	062737	000002	045542	ADD	#\$2,GENDPB+\$SEC	; INCREMENT TO NEXT 2ND SECTOR	
6532	026132	123737	001266	045542	CMPB	\$CDW2,GENDPB+\$SEC	; ALL SECTORS ARE TRIED ?	
6533	026140	103361			BHIS	2\$	; BRANCH IF NOT	
6534	026142	052737	000001	001264	BIS	#\$BIT0,\$CDW1	; FLAG-RETRIEVE FAILS	
6535	026150	000451			BR	9\$	; NEXT SETS	
6536	026152	010001		4\$:	MOV	R0,R1	; BAD SECTOR TABLE	
6537	026154	062701	000124		ADD	#\$B0SEC,R1	; BAD SECTOR TABLE ADDRESS	
6538	026160	012702	000040		MOV	#32.,R2	; WORD CTR OF BAD SECTOR TABLE	
6539	026164	012703	056150		MOV	#\$CYLDR,R3	; BUFFER ADDRESS	
6540	026170	062703	000010		ADD	#\$10,R3	; STARTS AT THE 5TH WORD	
6541	026174	012704	000374		MOV	#\$252.,R4	; WORD CTR FOR BAD SPOT FILE	
6542	026200	022713	177777	5\$:	CMP	#-1,(R3)	; END OF BAD SPOT FILE ?	
6543	026204	001433			BEQ	9\$	; BRANCH IF SO	
6544	026206	022711	177777	6\$:	CMP	#-1,(R1)	; ENTRY OF THE TABLE ?	
6545	026212	001406			BEQ	7\$	; BRANCH IF SO	
6546	026214	062701	000004		ADD	#\$4,R1	; ADJUST TABLE ENTRY	
6547	026220	162702	000002		SUB	#\$2,R2	; DECREMENT WORD CTR	
6548	026224	002420			BLT	8\$	; OVER 16 BAD SECTOR DETECTED	
6549	026226	000767			BR	6\$	; LOOP BACK	
6550	026230	011311		7\$:	MOV	(R3),(R1)	; LOAD THE TABLE	
6551	026232	016361	000002	000002	MOV	2(R3),2(R1)	; TRK AND SECTOR	
6552	026240	162704	000002		SUB	#\$2,R4	; DECREMENT WORD CTR FOR FILE	
6553	026244	003413			BLE	9\$	; BRANCH IF DONE	
6554	026246	062703	000004		ADD	#\$4,R3	; ADJUST FILE ADDRESS	
6555	026252	162702	000002		SUB	#\$2,R2	; DECREMENT TABLE WORD CTR	
6556	026256	003403			BLE	8\$	; TABLE ENTRY EXHAUSTED	
6557	026260	062701	000004		ADD	#\$4,R1	; ADJUST TABLE ENTRY	
6558	026264	000745			BR	5\$	; LOOP BACK	
6559	026266	052737	000002	001264	8\$:	BIS	#\$BIT1,\$CDW1	; ERROR FLAG-OVER 16 BAD SECTORS
6560	026274	012637	001266	9\$:	MOV	(SP)+,\$CDW2	; UPDATE LAST SECTOR	
6561	026300	112637	045542		MOVB	(SP)+,GENDPB+\$SEC	; STARTING SECTOR	
6562	026304	001277			BNE	2\$	; BRANCH IF NOT DUMMY PAIR	
6563	026306	032737	000001	001264	BIT	#\$BIT0,\$CDW1	; RETRIEVE FAILS ?	

```

6564 026314 001412 BEQ 10$ ;BRANCH IF NOT
6565 026316 104401 054233 TYPE ,MERR1 ;FAILS TO RETRIEVE BAD SPOT FILE
6566 026322 104401 052755 TYPE ,UNMSG ;ON DRIVE
6567 026326 111046 MOVB (R0),-(SP) ;#
6568 026330 104403 TYPOS
6569 026332 002 .BYTE 2
6570 026333 000 .BYTE 0
6571 026334 104401 001201 TYPE ,SCLF ;CR-LF
6572 026340 000415 BR 11$ ;EXIT
6573 026342 032737 000002 001264 10$: BIT #BIT1,$CDW1 ;OVER 16 BAD SECTORS ?
6574 026350 001411 BEQ 11$ ;BRANCH IF NOT
6575 026352 104401 054301 TYPE ,MERR2 ;OVER 16 BAD SECTORS DETECTED
6576 026356 104401 052755 TYPE ,UNMSG ;ON DRIVE
6577 026362 111046 MOVB (R0),-(SP) ;
6578 026364 104403 TYPOS
6579 026366 002 .BYTE 2
6580 026367 000 .BYTE 0
6581 026370 104401 001201 TYPE ,SCLF
6582 026374 005737 001264 11$: TST $CDW1 ;ERROR FLAG SET ?
6583 026400 001002 BNE 12$ ;BRANCH IS SET
6584 026402 062705 000002 ADD #2,R5 ;ADJUST FOR NORMAL RET
6585 026406 12$: MOV (SP)+,R4 ;;POP STACK INTO R4
6586 026406 012604 MOV (SP)+,R3 ;;POP STACK INTO R3
6587 026410 012603 MOV (SP)+,R2 ;;POP STACK INTO R2
6588 026412 012602 MOV (SP)+,R1 ;;POP STACK INTO R1
6589 026414 012601 RTS R5 ;EXIT
6590 026416 000205
6591
6592 ;PARAMETER ENTRY ROUTINE
6593 ;CALL
6594 ; MOV #ADR,R3 ;PARAMETER TABLE ADDRESS
6595 ; JSR PC,PARENT ;GET THE PARAMETERS
6596
6597 026420 010346 PARENT: MOV R3,-(SP) ;SAVE THE PARAMETER TABLE ADDRESS
6598 026422 005037 001360 CLR CFLAG ;CLEAR THE 'CONTROL C' FLAG
6599 026426 012337 026436 1$: MOV (R3)+,$3 ;ADDRESS OF PARAMETER NAME
6600 026432 001442 BEQ 9$ ;BR IF AT END OF TABLE
6601 026434 104401 TYPE ;TYPE THE PARAMETER NAME
6602 026436 000000 3$: .WORD 0 ;ADDRESS OF PARAMETER NAME TEXT
6603 026440 012302 MOV (R3)+,R2 ;MAXIMUM PARAMETER VALUE
6604 026442 012305 MOV (R3)+,R5 ;ADDRESS OF PARAMETER
6605 026444 011546 MOV (R5),-(SP) ;CURRENT VALUE OF PARAMETER
6606 026446 104405 TYPDS ;TYPE THE CURRENT VALUE OF THE PARAMETER
6607 026450 104401 054474 TYPE ,SLASH ;'/'
6608 026454 104411 RDLIN ;READ THE KEYBOARD
6609 026456 012601 MOV (SP)+,R1 ;INPUT ASCII STRING ADDRESS
6610 026460 005737 001360 TST CFLAG ;'CONTROL C' ENTERED ?
6611 026464 001021 BNE 8$ ;BR IF IT WAS
6612 026466 004537 030110 JSR R5,CK.DIG ;CHECK THE DIGIT(S)
6613 026472 026426 1$ ;CARRIAGE RETURN ONLY ENTERED
6614 026474 026540 9$ ;PERIOD ONLY ENTERED
6615 026476 026512 6$ ;ILLEGAL INPUT
6616 026500 026506 5$ ;TERMINATED WITH A CARRIAGE RETURN
6617 026502 026512 6$ ;TERMINATED WITH A "."
6618 026504 026524 7$ ;TERMINATED WITH A " "
6619 026506 010215 5$: MOV R2,(R5) ;MOVE NEW VALUE TO PARAMETER LOCATION
    
```

```

6620 026510 000746          BR      1$          ;GET MORE PARAMETERS
6621 026512 104401 054055 6$:      TYPE      ,BADENT ;'BAD ENTRY'
6622 026516 162703 000006          SUB      #6,R3     ;DECREMENT THE TABLE POINTER
6623 026522 000741          BR      1$          ;TRY AGAIN
6624 026524 010215          7$:      MOV      R2,(R5) ;NEW VALUE
6625 026526 000404          BR      9$          ;EXIT
6626 026530 005037 001360          8$:      CLR      CFLAG  ;CLEAR THE 'CONTROL C' FLAG
6627 026534 011603          MOV      (SP),R3   ;RELOAD THE PARAMETER TABLE ADDRESS
6628 026536 000733          BR      1$          ;TRY AGAIN
6629 026540 005726          9$:      TST      (SP)+ ;CORRECT THE STACK POINTER
6630 026542 000207          RTS      PC        ;RETURN
6631
6632          ;TYPEOUT ASSIGN/DEASSIGN ERROR MESSAGE
6633          ;CALL
6634          ;
6635          ;
6636          ;
6637          ;
6638 026544 104401 053566          ASNERR: TYPE      ,QUES   ;QUESTION MARK
6639 026550 104401 052755          TYPE      ,UNTMSG  ;TYPE 'DRIVE'
6640 026554 010446          MOV      R4,-(SP) ;SAVE R4 FOR TYPEOUT
6641          ;
6642 026556 104403          TYPOS   ;TYPE DRIVE NUMBER
6643 026560          .BYTE 2 ;GO TYPE--OCTAL ASCII
6644 026561          .BYTE 0 ;TYPE 2 DIGIT(S)
6645 026562 104401          TYPE      ;SUPPRESS LEADING ZEROS
6646 026564 000000          ASNMSG: .WORD 0 ;TYPE SPECIFIC MESSAGE
6647 026566 104401 001201          TYPE      ,%CRLF  ;MESSAGE ADDRESS
6648 026572 000207          RTS      PC
6649
6650          ;DEASSIGN DRIVE IF A FATAL ERROR OCCURS
6651          ;CALL
6652          ;
6653          ;
6654          ;
6655 026574 005004          DROP:  CLR      R4 ;CLEAR R4 FOR DRIVE NUMBER
6656 026576 111004          MOVB     (R0),R4   ;MOVE DRIVE NUMBER TO R4
6657 026600 146437 034304 001544          BICB     ATABIT(R4),ASNLS ;REMOVE DRIVE FROM ASSIGNED LIST
6658 026606 006304          ASL      R4 ;MAKE DRIVE NUMBER INTO A TABLE INDEX
6659 026610 010064 001546          MOV      R0,DUNIT(R4) ;PUT DRIVE IN DROP LIST
6660 026614 104401 001201          TYPE      ,%CRLF
6661 026620 104401 001201          TYPE      ,%CRLF
6662 026624 104401 053341          TYPE      ,DROPNG ;TYPE 'DROPPING DRIVE'
6663 026630 104401 053452          TYPE      ,DRNUM  ;'DRIVE #'
6664 026634 006204          ASR      R4 ;DRIVE NUMBER
6665 026636 010446          MOV      R4,-(SP) ;SAVE R4 FOR TYPEOUT
6666          ;
6667 026640 104403          TYPOS   ;TYPE DRIVE NUMBER
6668 026642          .BYTE 2 ;GO TYPE--OCTAL ASCII
6669 026643          .BYTE 0 ;TYPE 2 DIGIT(S)
6670 026644 104401 001201          TYPE      ,%CRLF ;SUPPRESS LEADING ZEROS
6671 026650 105737 001544          TSTB     ASNLS ;MORE DRIVES ACTIVE
6672 026654 001006          BNE      1$ ;YES
6673 026656 005737 000042          TST      #42 ;ANY MONITOR ?
6674 026662 001403          BEQ      1$ ;NO
6675 026664 005726          TST      (SP)+ ;CLEAR STACK
    
```

```

6676 026666 000137 027250          JMP      $GET42          ;GIVE CONTROL TO MONITOR
6677 026672 000207          1$:    RTS      PC
6678
6679          ;ROUTINE TO DEASSIGN DRIVE IF ERRORS BECOMES EXCESSIVE
6680
6681 026674 032777 000020 152252 ABNRML: BIT      #SW04, $SWR          ;SEE IF SWITCH 4 SET
6682 026702 001006          BNE      1$            ;BR IF IT'S SET
6683 026704 023760 001464 000056      CMP      MAXER, $TOTAL(R0) ;CHECK TOTAL ERROR VALUE
6684 026712 103002          BHIS     1$            ;BR IF ERRORS DONOT EXCEED MAX
6685 026714 000137 026574          JMP      DROP          ;DEASSING THE DRIVE
6686 026720 000207          1$:    RTS      PC          ;RETURN
6687
6688          ;ROUTINE TO CHECK FOR END OF PASS AND END OF TEST
6689
6690          .SBTTL  END OF PASS ROUTINE
6691
6692          ;*****
6693          ;*INCREMENT THE PASS NUMBER ($PASS)
6694          ;*IF THERES A MONITOR GO TO IT
6695          ;*IF THERE ISN'T JUMP TO FISK
6696
6697 026722          $EOP:
6698 026722 005737 001506          EOP:   TST      ENDET          ;END OF PASS DETERMINED BY SEEKS OR WORDS ?
6699 026726 001412          BEQ      EOP1          ;BR IF SEEKS
6700 026730 026037 000054 001452      CMP      $READ+2(R0), ENDCON+2 ;CHECK MSW OF WORDS READ COUNT
6701 026736 101017          BHI      EOP2          ;BR IF MSW GREATER THAN LIMIT
6702 026740 103527          BLO      EOPX          ;BR IF MSW LESS THAN LIMIT
6703 026742 026037 000052 001450      CMP      $READ(R0), ENDCON    ;CHECK LSW AGAINST LIMIT
6704 026750 103012          BHIS     EOP2          ;BR IF EQUAL OR GREATER
6705 026752 000522          BR       EOPX          ;EXIT
6706 026754 026037 000044 001456      EOP1:  CMP      $POSIT+2(R0), ENDSEK+2 ;CHECK MSW OF SEEK COUNT
6707 026762 101005          BHI      EOP2          ;BR IF MSW GREATER THAN LIMIT
6708 026764 103515          BLO      EOPX          ;EXIT IF MSW LESS THAN LIMIT
6709 026766 026037 000042 001454      CMP      $POSIT(R0), ENDSEK   ;CHECK LSW OF SEEK COUNT
6710 026774 103511          BLO      EOPX          ;EXIT IF LSW LESS THAN LIMIT
6711 026776 104401 001201          EOP2:  TYPE     , $CRLF          ;CR-LF
6712 027002 104401 053375          TYPE     , $ENDPAS        ;END OF PASS FOR THE DRIVE
6713 027006 016046 000070          MOV      $PASSC(R0), -(SP)   ;PUT PASS COUNT ON THE STACK
6714 027012 104405          TYPDS    ;CONVERT PASS COUNT TO DECIMAL AND TYPE IT
6715 027014 111037 001344          MOVVB    (R0), UNIT          ;STORE THE DRIVE NUMBER
6716 027020 032777 000020 152126      BIT      #SW04, $SWR        ;SWITCH 4 SET ?
6717 027026 001017          BNE      1$            ;BR IF SET
6718 027030 026037 000070 001460      CMP      $PASSC(R0), PASCNT   ;SEE IF AT END OF TEST
6719 027036 103413          BLO      1$            ;BR IF NOT
6720 027040 104401 053411          TYPE     , $ENDTST        ;TYPE 'END OF TEST'
6721 027044 104401 053452          TYPE     , $DRNUM         ;'DRIVE #'
6722 027050 013746 001344          MOV      UNIT, -(SP)        ;SAVE UNIT FOR TYPEOUT
6723
6724          ;TYPE DRIVE NUMBER
6725 027054 104403          TYPOS    ;GO TYPE--OCTAL ASCII
6726 027056 002          .BYTE    2                ;TYPE 2 DIGIT(S)
6727 027057 000          .BYTE    0                ;SUPPRESS LEADING ZEROS
6728 027060 104401 001201          TYPE     , $CRLF          ;CR-LF
6729 027064 000431          BR       3$            ;DEASSIGN THE DRIVE
6730 027066 104401 053452          1$:    TYPE     , $DRNUM         ;'DRIVE #'
6731 027072 013746 001344          MOV      UNIT, -(SP)        ;SAVE UNIT FOR TYPEOUT
                                ;TYPE DRIVE NUMBER

```



```

6732 027076 104403          TYPOS          ;GO TYPE--OCTAL ASCII
6733 027100          .BYTE          2          ;TYPE 2 DIGIT(S)
6734 027101          .BYTE          0          ;SUPPRESS LEADING ZEROS
6735 027102 104401 001201  TYPE          $CRLF        ;CR-LF
6736 027106 004737 022702  JSR          PC,TYPEST    ;TYPE THE DRIVE'S STATISTICS
6737 027112 010346          MOV          R3,-(SP)     ;SAVE R3
6738 027114 010446          MOV          R4,-(SP)     ;SAVE R4
6739 027116 010004          MOV          R0,R4       ;DRIVE'S BLOCK ADDRESS
6740 027120 062704 000036  ADD          $0PERC,R4    ;ADD THE STARTING ADDR OF SECTIONS TO CLEAR
6741 027124 012703 000010  MOV          $8.,R3      ;NUMBER OF LOCNS TO BE CLEARED
6742                                     ;(ERROR COUNTERS NOT CLEARED)
6743 027130 005024          2$: CLR        (R4)+      ;CLEAR THE LOCN
6744 027132 005303          DEC        R3          ;DECREMENT THE LOCATION COUNTER
6745 027134 001375          BNE        2$         ;BR IF MORE TO GO
6746 027136 012604          MOV        (SP)+,R4    ;RESTORE R4
6747 027140 012603          MOV        (SP)+,R3    ;RESTORE R3
6748 027142 005260 000070  INC        $PASSC(R0)   ;INCREMENT THE PASS COUNT
6749 027146 000424          BR         EOPX        ;EXIT
6750 027150 104401 001201  3$: TYPE          $CRLF
6751 027154 005004          CLR        R4          ;CLEAR R4 FOR DRIVE NUMBER
6752 027156 111004          MOVB       (R0),R4     ;MOVE DRIVE NUMBER
6753 027160 146437 034304 001544  BICB       ATABIT(R4),ASNLST ;DELETE DRIVE FROM ASSIGNED LIST
6754 027166 006304          ASL        R4          ;MAKE DRIVE NUMBER INTO TABLE INDEX
6755 027170 010064 001546  MOV        R0,DUNIT(R4) ;PUT BLOCK ADDRESS INTO DROP LIST
6756 027174 105737 001544  TSTB      ASNLST      ;ALL DRIVES ARE DESIGNED ?
6757 027200 001007          BNE        EOPX        ;BRANCH IF NOT
6758 027202 005237 001214  INC        $DEVCT      ;INCREMENT DEVICE COUNT
6759 027206 005237 001212  INC        $PASS       ;INCREMENT THE PASS NUMBER FOR APT
6760 027212 042737 100000 001212  BIC        $100000,$PASS ;AVIOD NEGATIVE NUMBER
6761 027220 000207          RTS        PC          ;RETURN
6762 027222 005237 001212  INC        $PASS       ;INCREMENT THE PASS NUMBER
6763 027226 042737 100000 001212  BIC        $100000,$PASS ;DON'T ALLOW A NEG. NUMBER
6764 027234 005327          DEC        (PC)+      ;LOOP?
6765 027236 000001          $EOPCT: .WORD      1
6766 027240 003013          BGT        $DOAGN      ;YES
6767 027242 012737          MOV        (PC)+,2(PC)+ ;RESTORE COUNTER
6768 027244 000001          $ENDCT: .WORD      1
6769 027246 027236          $EOPCT
6770 027250 013700 000042  $GET42: MOV        2#42,R0 ;GET MONITOR ADDRESS
6771 027254 001405          BEQ        $DOAGN      ;BRANCH IF NO MONITOR
6772 027256 000005          RESET      ;CLEAR THE WORLD
6773 027260 004710          $ENDAD: JSR        PC,(R0) ;GO TO MONITOR
6774 027262 000240          NOP        ;SAVE ROOM
6775 027264 000240          NOP        ;FOR
6776 027266 000240          NOP        ;ACT11
6777 027270          $DOAGN:
6778 027270 000137          JMP        2(PC)+      ;RETURN
6779 027272 027274          $RTNAD: .WORD      FISK
6780 027274 005237 001210  FISK: INC        $TESTN ;INCREMENT THE TEST NUMBER IN THE MAIL BOX
6781 027300 000137 005524  JMP        MAIN1      ;RETURN TO LOOP
6782
6783 ;ROUTINE TO GET THE REMAINDER OF THE RANDOM NUMBER
6784 ;CALL
6785 ;
6786 ;       MOV        NUMBER,R5 ;DIVISOR INTO R5
6787 ;       JSR        PC,GETREM
;       RETURN ;REMAINDER IS IN R5

```

```

6788
6789 027304 013746 033450      GETREM: MOV    $LONUM,-(SP)      ;STORE RANDOM NUMBER ON THE STACK FOR DIVIDE
6790 027310 013746 033446      MOV    $HINUM,-(SP)      ;UPPER PART
6791 027314 010546              MOV    R5,-(SP)          ;PUT THE DIVISOR ONTO THE STACK
6792 027316 004737 027332      JSR   PC,LINKDV          ;DIVIDE THE RANDOM NUMBERS
6793 027322 012605              MOV    (SP)+,R5          ;PUT THE REMAINDER INTO R5
6794 027324 005726              TST   (SP)+              ;ADJUST THE STACK POINTER
6795 027326 000240              NOP                      ;FOR DEBUGGING HALT
6796 027330 000207              RTS    PC
6797
6798                               ;LINK ROUTINE TO THE DIVISION UTILITY SUBROUTINE
6799                               ; THIS ROUTINE ALLOWS THE 'SYSMAC' DIVIDE ROUTINE
6800                               ; CALLING SEQUENCE TO BE USED
6801
6802 027332 104412              LINKDV: SAVREG           ;STORE R0 - R5
6803 027334 016605 000026      MOV    26(SP),R5         ;DIVISOR
6804 027340 005004              CLR    R4                ;OTHER DIVISOR WORD
6805 027342 016602 000030      MOV    30(SP),R2         ;UPPER DIVIDEND WORD
6806 027346 016603 000032      MOV    32(SP),R3         ;LOWER DIVIDEND WORD
6807 027352 005000              CLR    R0                ;CLEAR OTHER DIVIDEND REGISTERS
6808 027354 005001              CLR    R1
6809 027356 004737 027400      JSR   PC,M.DPID          ;GO TO THE DIVIDE ROUTINE
6810 027362 010166 000030      MOV    R1,30(SP)         ;REMAINDER ON THE STACK
6811 027366 010366 000032      MOV    R3,32(SP)         ;QUOTIENT ON THE STACK
6812 027372 104413              RESREG                    ;RESTORE R0 - R5
6813 027374 012616              MOV    (SP)+,(SP)        ;MOVE RETURN UP THE STACK
6814 027376 000207              RTS    PC
6815
6816                               ;
6817                               ; DIVISION UTILITY SUBROUTINE
6818                               ; R0-R1-R2-R3=DIVIDEND
6819                               ; R4-R5=DIVISOR
6820                               ; R0-R1=REMAINDER AFTER DIVISION
6821                               ; R2-R3=QUOTIENT AFTER DIVISION
6822                               ; ENTER WITH JSR PC,M.DPID
6823 027400 012746 000040      M.DPID: MOV    #40,-(SP)    ;COUNTER FOR DIVISION CYCLES
6824 027404 010446              MOV    R4,-(SP)          ;HIGH ORDER
6825 027406 010546              MOV    R5,-(SP)          ;LOW ORDER DIVISOR TO THE STACK
6826 027410 005466 000002      NEG    2(SP)              ;FORM NEGATIVE
6827 027414 005416              NEG    @SP                ;VERSION OF THE DIVISOR
6828 027416 005666 000002      SBC   2(SP)
6829 027422 061601              ADD    @SP,R1
6830 027424 005500              ADC    R0                ;PERFORM THE INITIAL SUBTRACTION
6831 027426 066600 000002      ADD    2(SP),R0
6832 027432 103445              BCS   M.DP50             ;IF CARRY THEN OVERFLOW HAS OCCURRED
6833 027434 005046              CLR    -(SP)             ;THIS IS A LONGER LASTING CARRY BIT
6834 027436 006103              M.DP40: ROL    R3
6835 027440 006102              ROL    R2
6836 027442 006101              ROL    R1
6837 027444 006100              ROL    R0
6838 027446 005716              TST   @SP                ;TEST "CARRY" INDICATOR
6839 027450 001410              BEQ   M.DP41             ;IF NO "CARRY" THEN ADD ELSE SUBTRACT
6840 027452 005016              CLR    @SP                ;CLEAR UP FOR NEXT TIME
6841 027454 066601 000002      ADD    2(SP),R1
6842 027460 005500              ADC    R0                ;ADD -(DIVISOR)
6843 027462 005516              ADC    @SP ; I          ;SET "CARRY"

```

```

6844 027464 066600 000004      ADD      4(SP),R0;<-
6845 027470 000404      BR       M.DP42
6846 027472 060501      M.DP41: ADD      R5,R1
6847 027474 005500      ADC      R0                ;ADD +(DIVISOR)
6848 027476 005516      ADC      @SP                ;SET "CARRY"
6849 027500 060400      ADD      R4,R0                ;<-
6850 027502 005516      M.DP42: ADC      @SP                ;SET "CARRY"
6851 027504 005716      TST      @SP                ;TEST THE UPDATE INDICATOR
6852 027506 001401      BEQ      .+4                ;IF ZERO FORGET IT
6853 027510 005203      INC      R3                ;NO CARRY POSSIBLE HERE
6854 027512 005366 000006      DEC      6(SP)                ;DECREMENT COUNTER
6855 027516 003347      BGT      M.DP40                ;BRANCH IF MORE TO DO
6856 027520 006003      ROR      R3
6857 027522 103404      BCS      M.DP44
6858 027524 060501      ADD      R5,R1
6859 027526 005500      ADC      R0
6860 027530 060400      ADD      R4,R0
6861 027532 000241      CLC
6862 027534 006103      M.DP44: ROL      R3
6863 027536 062706 000010      ADD      #10,SP                ;ADJUST STACK BY 4 WORDS
6864 027542 000242      CLV
6865 027544 000207      RTS      PC
6866 027546 062706 000006      M.DP50: ADD      #6,SP
6867 027552 000262      SEV
6868 027554 000207      RTS      PC
6869
6870
6871      ;ROUTINE TO REPLACE LEADING ZEROS IN A NUMERIC STRING WITH SPACES
6872      ;CALL
6873      ;      MOV      #ADR, -(SP)                ;ADDRESS OF NUMBER (IN ASCII)
6874      ;      JSR      R5, REPLZ
6875      ;      .WORD   N                        ;'N' IS NUMBER OF DIGITS TO BE TYPED
6876
6877      REPLZ: MOV      R0, -(SP)                ;SAVE R0
6878      027556 012746 000012      MOV      #10, -(SP)            ;MAXIMUM NUMBER OF DIGITS TO BE TYPED
6879      027564 162516      SUB      (R5)+, (SP)            ;SUBTRACT DIGITS TO FORM INDEX
6880      027566 016600 000006      MOV      6(SP), R0            ;ADDRESS OF NUMBER TO R0
6881      027572 122710 000060      1$:  CMPB     #'0', (R0)          ;BYTE EQUAL TO ASCII '0' ?
6882      027576 001004      BNE      2$                    ;BR IF NOT
6883      027600 112710 000040      MOVB     #40, (R0)            ;REPLACE THE ZERO WITH A SPACE
6884      027604 005200      INC      R0                    ;INCREMENT THE BYTE ADDRESS
6885      027606 000771      BR       1$                    ;GO BACK AND LOOK FOR MORE LEADING ZEROS
6886      027610 105710      2$:  TSTB     (R0)                ;SEE IF ZERO BYTE TERMINATOR
6887      027612 001003      BNE      3$                    ;BR IF NOT
6888      027614 005300      DEC      R0                    ;BACKUP STRING POINTER
6889      027616 112710 000060      MOVB     #'0', (R0)            ;PUT A ZERO BACK IN
6890      027622 016637 000006 027636 3$:  MOV      6(SP), 4$            ;PUT ADDRESS IN LOCATION FOR TYPEOUT
6891      027630 062637 027636      ADD      (SP)+, 4$            ;BEGINNING OF SIGNIFICANT DIGITS
6892      027634 104401      TYPE
6893      027636 000000      4$:  .WORD   0                    ;ADDRESS OF NUMBER
6894      027640 012600      MOV      (SP)+, R0            ;RESTORE R0
6895      027642 012616      MOV      (SP)+, (SP)          ;MOVE RETURN ADDRESS
6896      027644 000205      RTS      R5                    ;RETURN
6897
6898      ;TYPE NUMERICAL ASCII STRING SUPPRESS LEADING ZEROS
6899

```

```

6900      ;CALL
6901      ;      MOV      #NUMADR, -(SP)      ;FIRST ADDRESS OF ASCIZ STRING
6902      ;      JSR      PC, $SUPRS
6903
6904      $SUPRS: MOV      RO, -(SP)      ;SAVE RO
6905      027646 010046      000004      MOV      4(SP), RO      ;PICKUP THE POINTER
6906      027650 016600      000004      1$: TSTB      (RO)      ;TERMINATOR ?
6907      027654 105710      001403      BEQ      2$      ;BR IF YES
6908      027660 122720      000060      CMPB     #'0', (RO)+      ;IS THIS AN ASCII '0' ?
6909      027664 001773      000000      BEQ      1$      ;BR IF YES
6910      027666 005300      000000      2$: DEC      RO      ;BACKUP BY '1'
6911      027670 010037      027676      MOV      RO, 3$      ;SAVE FOR TYPING
6912      027674 104414      000000      DISPLY   0      ;GO PRINT
6913      027676 000000      000000      3$: .WORD   0      ;ASCIZ POINTER GOES HERE
6914      027700 012600      000000      MOV      (SP)+, RO      ;RESTORE RO
6915      027702 012616      000000      MOV      (SP)+, (SP)      ;RESTORE THE STACK
6916      027704 000207      000000      RTS      PC      ;RETURN
6917
6918      ;ROUTINE TO TYPE AT PRIORITY 4
6919
6920      027706 013746      177776      TYPRI4: MOV      2$PS, -(SP)      ;SAVE THE PRESENT STATUS
6921      027712 012737      000200      177776      MOV      #200, 2$PS      ;CHANGE THE PRIORITY TO 4
6922      027720 012537      027730      MOV      (R5)+, 1$      ;MESSAGE ADDRESS
6923      027724 004737      031326      JSR      PC, $TYPE      ;TYPE THE MESSAGE
6924      027730 000000      000000      1$: .WORD   0      ;MESSAGE ADDRESS GOES HERE
6925      027732 000205      000000      RTS      R5      ;RETURN
6926
6927      ;ROUTINE TO TYPE ERRORS
6928      ;CALL
6929      ;      DISPLY   MESADR      ;MUST DEFINED IN 'TRAP' TABLE
6930      ;      RETURN      ;ADDRESS OF MESSAGE
6931
6932
6933      027734 032777      020000      151212      $DSPLY: BIT      #BIT13, 2$SWR      ;INHIBIT ERROR TIMEOUT ?
6934      027742 001004      000000      1$: BNE     1$      ;BR IF YES
6935      027744 005037      177776      CLR      2$PS      ;SET PRIORITY TO ZERO
6936      027750 000137      031326      JMP      $TYPE      ;TYPE THE MESSAGE
6937      027754 062716      000002      1$: ADD     #2, (SP)      ;INCREMENT THE RETURN
6938      027760 000002      000000      RTI
6939
6940      ;THIS ROUTINE IS USED TO CHECK IF AN
6941      ;ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7.
6942      ;CALL
6943      ;      MOV      #ADR, R1      ;ADDRESS OF ASCII CHARACTER
6944      ;      JSR      R5, CK.OCT      ;CHECK THE CHARACTER
6945      ;      RETURN1      ;CHARACTER IS NOT BETWEEN 0-7
6946      ;      RETURN2      ;CHARACTER IS IN R2 AS A
6947      ;      ;OCTAL DIGIT
6948
6949      CK.OCT: CMPB     (R1), #'0      ;LESS THAN ZERO?
6950      027762 121127      000060      BLO     1$      ;YES -- BRANCH
6951      027766 103407      000067      CMPB     (R1), #'7      ;GREATER THAN SEVEN?
6952      027770 121127      000067      BHI     1$      ;YES -- BRANCH
6953      027774 101004      000000      MOVB     (R1), R2      ;GET THE CHARACTER
6954      027776 111102      000000      BIC     #7, R2      ;STRIP AWAY THE ASCII
6955      030000 042702      177770      TST     (R5)+      ;ADJUST FOR RETURN
        
```

```

6956 030006 000205      1$:   RTS      R5           ;RETURN
6957
6958                   ; THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER
6959                   ; AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.
6960                   ; CALL
6961                   ;       MOV      #ADR,R1           ; ADDRESS OF ASCII CHARACTER
6962                   ;       JSR      R5,CK.DEC        ; CHECK THE CHARACTER
6963                   ;       RETURN1  ; NOT BETWEEN 0 AND 9
6964                   ;       RETURN2  ; BETWEEN 0 AND 9
6965                   ;                   ; R2 = DIGIT
6966
6967 030010 121127 000060  CK.DEC: CMPB    (R1),#'0      ; LESS THAN ZERO?
6968 030014 103407          BLO     1$           ; YES -- BRANCH
6969 030016 121127 000071  CMPB    (R1),#'9      ; GREATER THAN NINE?
6970 030022 101004          BHI     1$           ; YES -- BRANCH
6971 030024 111102          MOVB   (R1),R2       ; GET THE CHARACTER
6972 030026 042702 000060  BIC     #'0,R2        ; STRIP AWAY THE ASCII
6973 030032 005725          TST    (R5)+         ; ADJUST FOR RETURN
6974 030034 000205      1$:   RTS      R5           ;RETURN
6975
6976                   ; THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
6977                   ; DETERMINE WHAT IT IS.
6978                   ; CALL
6979                   ;       MOV      #ADR,R1           ; ADDRESS OF ASCII CHARACTER
6980                   ;       JSR      R5,CK.CHR        ; CHECK CHARACTER
6981                   ;       RETURN  ADR1             ; UNKNOWN CHARACTER
6982                   ;       RETURN  ADR2             ; CARRIAGE RETURN * (R1)=ADR+1
6983                   ;       RETURN  ADR3             ; COMMA * (R1)=ADR+1
6984                   ;       RETURN  ADR4             ; PERIOD * (R1)=ADR+1
6985                   ;       RETURN  ADR5             ; DIGIT BETWEEN 0 AND 7.
6986                   ;       RETURN  ADR6             ; DIGIT BETWEEN 8 AND 9.
6987                   ;                   ; R2 = DIGIT * (R1)=ADR+1
6988
6989 030036 105711          CK.CHR: TSTB   (R1)      ; "CARRIAGE RETURN"?
6990 030040 001417          BEQ     3$           ; YES -- BRANCH
6991 030042 121127 000054  CMPB   (R1),#',      ; "COMMA"?
6992 030046 001413          BEQ     2$           ; YES -- BRANCH
6993 030050 121127 000056  CMPB   (R1),#'.      ; "PERIOD"?
6994 030054 001407          BEQ     1$           ; YES -- BRANCH
6995 030056 004537 030010  JSR     R5,CK.DEC    ; "DIGIT"?
6996 030062 000410          BR      4$           ; NO -- BRANCH
6997 030064 004537 027762  JSR     R5,CK.OCT    ; OCTAL ?
6998 030070 005725          TST    (R5)+         ; DIGIT BETWEEN 8-9
6999 030072 005725          TST    (R5)+         ; DIGIT BETWEEN 0-7
7000 030074 005725      1$:   TST    (R5)+         ; PERIOD
7001 030076 005725      2$:   TST    (R5)+         ; COMMA
7002 030100 005725      3$:   TST    (R5)+         ; CARRIAGE RETURN
7003 030102 005201          INC     R1           ; MOVE POINTER TO NEXT CHARACTER
7004 030104 011505      4$:   MOV     (R5),R5      ; UNKNOWN CHARACTER
7005 030106 000205          RTS      R5           ; RETURN
7006
7007                   ; THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
7008                   ; CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN R2.
7009                   ; CALL
7010                   ;       MOV      #ADR,R1           ; ADDRESS OF ASCII STRING
7011                   ;       MOV      #NUM,R2          ; MAX. MAGNITUDE OF INPUT NUMBER
    
```

```

7012      :      JSR      R5,CK.DIG      ;CHECK DIGITS
7013      :      RETURN   ADR1          ;"CR" ONLY ENTERED -- R2=0
7014      :      RETURN   ADR2          ;"PERIOD" ONLY ENTERED -- R2=0
7015      :      RETURN   ADR3          ;ILLEGAL CHARACTER OR INPUT TOO LARGE -- R2=?
7016      :      RETURN   ADR4          ;"CR" -- R2 = NUMBER
7017      :      RETURN   ADR5          ;"COMMA" -- R2 = NUMBER
7018      :      RETURN   ADR6          ;"PERIOD" -- R2 = NUMBER
7019
7020      CK.DIG: MOV      R4,-(SP)      ;SAVE R4
7021      :      MOV      R3,-(SP)      ;SAVE R3
7022      :      MOV      R2,-(SP)      ;SAVE THE MAX. SIZE ON THE STACK
7023      :      CLR      R2            ;START WITH 0
7024      :      CLR      R3
7025      :      CLR      R4
7026      :      JSR      R5,CK.CHR     ;CHECK ONE CHARACTER
7027      :      B$      ;ILLEGAL CHARACTER
7028      :      B$      ;CARRIAGE RETURN
7029      :      B$      ;" "
7030      :      B$      ;"'"
7031      :      B$      ;DIGIT 0-7
7032      :      B$      ;DIGIT 8-9
7033      :      B$      ;STEP RETURN POINTER PAST "CR" & "PERIOD" RETURNS
7034      :      B$      ;INPUT NUMBER *2
7035      :      B$      ;SAVE #2
7036      :      B$      ;#4
7037      :      B$      ;#8
7038      :      B$      ;(*2)+(*8) = *10
7039      :      B$      ;UPDATE THE INPUT NUMBER
7040      :      B$      ;CHECK ONE CHARACTER
7041      :      B$      ;ILLEGAL CHARACTER
7042      :      B$      ;CARRIAGE RETURN
7043      :      B$      ;" "
7044      :      B$      ;"'"
7045      :      B$      ;DIGIT 0-7
7046      :      B$      ;DIGIT 8-9
7047      :      B$      ;DOES A "CR" FOLLOW THE "PERIOD"
7048      :      B$      ;BR IF NOT
7049      :      B$      ;INCREMENT THE RETURN
7050      :      B$      ;INCREMENT THE RETURN
7051      :      B$      ;INCREMENT THE RETURN
7052      :      B$      ;INCREMENT THE RETURN
7053      :      B$      ;CHECK THE MAGNITUDE OF THE NUMBER
7054      :      B$      ;BR IF ENTERED NUMBER TOO LARGE
7055      :      B$      ;BYPASS INCREMENT
7056      :      B$      ;INCREMENT RETURN PAST INVALID RETURN
7057      :      B$      ;INCREMENT RETURN
7058      :      B$      ;SETUP RETURN POINTER
7059      :      B$      ;ENTERED VALUE
7060      :      B$      ;CLEAN MAX. SIZE OFF OF STACK
7061      :      B$      ;RESTORE R3
7062      :      B$      ;RESTORE R4
7063      :      B$      ;GET RETURN ADDRESS
7064      :      B$      ;RETURN
7065
7066      ; THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
7067      ; UNSIGNED DECIMAL ASCII NUMBER.
7068      ; CALL

```

```

7068      :      MOV      NUMBER,-(SP)      ;PUT THE NUMBER ON THE STACK
7069      :      JSR      PC,$SSB2D          ;CALL
7070      :      RETURN                     ;ADDRESS OF THE 1ST ASCIZ CHAR IS ON THE STACK
7071      :
7072      :NOTE:  THE PROGRAM REQUIRES THIS FORM OF '$SSB2D', NOT THE VERSION ON
7073      :      THE SYSMAC LIBRARY, REV C AND LATER
7074      :
7075      030246 016637 000002 030272 $SSB2D: MOV      2(SP),1$      ;SAVE THE BINARY NUMBER
7076      030254 012746 030272          MOV      #1$,-(SP)      ;SET THE POINTER
7077      030260 004737 033546          JSR      PC,$DB2D       ;CALL THE DOUBLE LENGTH CONVERT
7078      030264 012666 000002          MOV      (SP)+,2(SP)    ;PICKUP THE POINTER
7079      030270 000207                    RTS      PC             ;RETURN
7080      030272 000000 000000          1$:      .WORD      0,0
7081      :
7082      :THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
7083      :UNSIGNED OCTAL ASCIZ NUMBER.
7084      :CALL
7085      :      MOV      NUMBER,-(SP)      ;PUT THE NUMBER ON THE STACK
7086      :      JSR      PC,$SSB2D          ;CALL
7087      :      RETURN                     ;ADDRESS OF THE 1ST ASCIZ CHAR IS ON THE STACK
7088      :
7089      :NOTE:  THE PROGRAM REQUIRES THIS FORM OF '$SSB2D', NOT THE VERSION ON
7090      :      THE SYSMAC LIBRARY, REV C AND LATER
7091      :
7092      030276 016637 000002 030322 $SSB2D: MOV      2(SP),1$      ;SAVE THE BINARY NUMBER
7093      030304 012746 030322          MOV      #1$,-(SP)      ;SET THE POINTER
7094      030310 004737 033742          JSR      PC,$DB2D       ;CALL THE DOUBLE LENGTH CONVERT
7095      030314 012666 000002          MOV      (SP)+,2(SP)    ;PICKUP THE POINTER
7096      030320 000207                    RTS      PC             ;RETURN
7097      030322 000000 000000          1$:      .WORD      0,0
7098      :
7099      :KEYBOARD INTERRUPT INITIALIZATION ROUTINE
7100      :CALL
7101      :      JSR      PC,$TKINT          ;
7102      :      RETURN
7103      :
7104      030326 012737 030356 000060 $TKINT: MOV      #STKSRV,TKVEC ;SETUP VECTOR
7105      030334 012737 000100 000062  MOV      #100,TKVEC+2 ;PRIORITY TO 4
7106      030342 005777 150614          TST      @STKB         ;CLEAR THE BUFFER
7107      030346 012777 000100 150604  MOV      #BIT06,@STKS ;SET INTERRUPT ENABLE
7108      030354 000207                    RTS      PC             ;RETURN
7109      :
7110      :KEYBOARD INTERRUPT SERVICE ROUTINE
7111      :CALL
7112      :      ENTER VIA INTERRUPT
7113      :
7114      030356 104410          $TKSRV: RDCHR                    ;READ THE KEYBOARD
7115      030360 112637 030506          MOV      (SP)+,5$      ;GET THE CHARACTER
7116      030364 023727 030506 000003  CMP      5$,#3         ;'CONTROL C' ?
7117      030372 001012          BNE      1$           ;BR IF NOT
7118      030374 104401 001201          TYPE      ,SCLF       ;CR-LF
7119      030400 104401 031000          TYPE      ,SCNTLC     ;'C'
7120      030404 012737 177777 001360  MOV      #-1,CFLAG    ;SET THE 'CONTROL C' FLAG
7121      030412 005077 150542          CLR      @STKS        ;CLEAR THE TTY INTERRUPT
7122      030416 000432          BR      4$           ;EXIT
7123      030420 023727 001154 000176 1$:      CMP      SWR,#SWREG    ;SOFTWARE SWITCH REGISTER IN USE ?

```

```

7124 030426 001024          BNE      3$          ;BR IF NOT
7125 030430 023727 030506 000007  CMP      5$,#7      ;'CONTROL G' ?
7126 030436 001020          BNE      3$          ;BR IF NOT
7127 030440 104401 001201  TYPE     ,SCRLF     ;CR-LF
7128 030444 104401 033321  TYPE     ,SCNTLG    ;'IG'
7129 030450 013746 177776  MOV      PS,-(SP)   ;PUT THE STATUS WORD ON THE STACK
7130 030454 012746 030470  MOV      #2$,-(SP) ;RETURN ADDRESS
7131 030460 005077 150474  CLR      @STKS     ;CLEAR THE TTY INTERRUPT ENABLE
7132 030464 000137 032762  JMP      $GTSWR    ;GET THE SWITCH REGISTER ENTRY
7133 030470 012777 000100 150462 2$:  MOV      #100,@STKS ;ENABLE TTY KEYBOARD INTERRUPT
7134 030476 000402          BR       4$          ;EXIT
7135 030500 104401 030506          TYPE     ,5$        ;ECHO THE CHARACTER
7136 030504 000002          RTI                    ;RETURN
7137
7138 030506 000000          5$:      .WORD    0          ;ENTERED CHARACTER
7139
7140          ;THIS ROUTINE WILL INPUT A STRING FROM THE TTY
7141          ;CALL:
7142          ;
7143          ;
7144          ;
7145          ;
7146 030510 010346          SRDLIN: MOV      R3,-(SP) ;SAVE R3
7147 030512 005046          CLR      -(SP)      ;CLEAR THE RUBOUT KEY
7148 030514 012703 030766  1$:      MOV      #STTYIN,R3 ;GET ADDRESS
7149 030520 022703 031000  2$:      CMP      #STTYIN+10.,R3 ;BUFFER FULL?
7150 030524 101467          BLOS    4$          ;BR IF YES
7151 030526 104410          RDCHR                    ;GO READ ONE CHARACTER FROM THE TTY
7152 030530 112613          MOVB    (SP)+,(R3)  ;GET CHARACTER
7153 030532 122713 000177  CMPB    #177,(R3)   ;IS IT A RUBOUT
7154 030536 001022          BNE     5$          ;BR IF NO
7155 030540 005716          TST     (SP)        ;IS THIS THE FIRST RUBOUT?
7156 030542 001007          BNE     6$          ;BR IF NO
7157 030544 112737 000134 030764  MOVB    #' \,9$    ;TYPE A BACK SLASH
7158 030552 104401 030764          TYPE     ,9$
7159 030556 012716 177777          MOV     #-1,(SP)   ;SET THE RUBOUT KEY
7160 030562 005303          6$:      DEC     R3      ;BACKUP BY ONE
7161 030564 020327 030766          CMP     R3,#STTYIN ;STACK EMPTY?
7162 030570 103445          BLO     4$          ;BR IF YES
7163 030572 111337 030764          MOVB    (R3),9$    ;SETUP TO TYPEOUT THE DELETED CHAR.
7164 030576 104401 030764          TYPE     ,9$
7165 030602 000746          BR      2$          ;GO TYPE
7166 030604 005716          5$:      TST     (SP)        ;GO READ ANOTHER CHAR.
7167 030606 001406          BEQ     7$          ;RUBOUT KEY SET?
7168 030610 112737 000134 030764  MOVB    #' \,9$    ;BR IF NO
7169 030616 104401 030764          TYPE     ,9$      ;TYPE A BACK SLASH
7170 030622 005016          CLR     (SP)
7171 030624 122713 000025          7$:      CMPB    #25,(R3)   ;CLEAR THE RUBOUT KEY
7172 030630 001003          BNE     10$         ;IS CHARACTER A CTRL U?
7173 030632 104401 033314          TYPE     ,SCNTLU   ;BR IF NO
7174 030636 000726          BR      1$          ;TYPE A CONTROL "U"
7175 030640 122713 000003          10$:     CMPB    #3,(R3)   ;GO START OVER
7176 030644 001006          BNE     8$          ;IS CHARACTER A CTRL C ?
7177 030646 012737 177777 001360  MOV     #-1,CFLAG  ;BR IF NOT
7178 030654 104401 031000          TYPE     ,SCNTLC   ;SET CNTRL C FLAG
7179 030660 000427          BR      11$        ;ECHO IT
                          ;EXIT

```



```

7180 030662 122713 000012      8$:  CMPB    #12,(R3)      ; IS CHARACTER A "LF"?
7181 030666 001011              BNE     3$              ; BRANCH IF NO
7182 030670 105013              CLRB   (R3)            ; CLEAR THE CHARACTER
7183 030672 104401 001201      TYPE   ,SCLF           ; TYPE A "CR" & "LF"
7184 030676 104401 030766      TYPE   ,STTYIN        ; TYPE THE INPUT STRING
7185 030702 000706              BR     2$              ; GO PICKUP ANOTHER CHACTER
7186 030704 104401 001200      4$:  TYPE   ,SQUES      ; TYPE A '?'
7187 030710 000701              BR     1$              ; CLEAR THE BUFFER AND LOOP
7188 030712 111337 030764      3$:  MOVB   (R3),9$     ; ECHO THE CHARACTER
7189 030716 104401 030764      TYPE   9$
7190 030722 122723 000015      CMPB   #15,(R3)+      ; CHECK FOR RETURN
7191 030726 001274              BNE     2$              ; LOOP IF NOT RETURN
7192 030730 105063 177777      CLRB   -1(R3)         ; CLEAR RETURN (THE 15)
7193 030734 104401 001202      TYPE   ,SLF           ; TYPE A LINE FEED
7194 030740 005726              11$: TST    (SP)+        ; CLEAN RUBOUT KEY FROM THE STACK
7195 030742 012603              MOV     (SP)+,R3      ; RESTORE R3
7196 030744 011646              MOV     (SP)-,(SP)    ; ADJUST THE STACK AND PUT ADDRESS OF THE
7197 030746 016666 000004 000002 MOV     4(SP),2(SP)   ; FIRST ASCII CHARACTER ON IT
7198 030754 012766 030766 000004 MOV     #STTYIN,4(SP)
7199 030762 000002              RTI                    ; RETURN
7200 030764 000          9$:  .BYTE   0              ; STORAGE FOR ASCII CHAR. TO TYPE
7201 030765 000          .BYTE   0              ; TERMINATOR
7202 030766 000012      $TTYIN: .BLKB  10.     ; RESERVE 10 BYTES FOR TTY INPUT
7203 031000 041536 005015 000  $CNTLC: .ASCIZ  /↑C/<CR><LF> ; CONTROL "C"
7204
7205 031006      .EVEN
7206
7207
7208
7209 ;*****
7210
7211 .SBTTL  MACRO ROUTINES
7212
7213 .SBTTL  ERROR HANDLER ROUTINE
7214
7215 ;*****
7216 ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
7217 ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
7218 ;*AND GO TO SERRTYP ON ERROR
7219 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
7220 ;*SW15=1      HALT ON ERROR
7221 ;*SW13=1      INHIBIT ERROR TYPEOUTS
7222 ;*SW10=1      BELL ON ERROR
7223 ;*CALL
7224 ;*      ERROR  N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
7225
7226 031006      $ERROR:
7227 031006 104407      CKSWR
7228 031010 010337 001342      MOV     R3,ATTN      ; TEST FOR CHANGE IN SOFT-SWR
7229 031014 010137 001216      MOV     R1,DRIVE    ; SAVE THE ATTENTION REGISTER CONTENTS
7230 031020 032777 020000 150126 BIT     #SW13,2SWR   ; DRIVE NUMBER
7231 031026 001002              BNE     +6           ; INHIBIT PRINTOUTS ?
7232 031030 004737 023450      JSR     PC,$TIME    ; BR IF YES
7233 031034 105237 001117      7$:  INCB   $ERFLG     ; TYPE THE TIME
7234 031040 001775              BEQ     7$          ; SET THE ERROR FLAG
7235 031042 013777 001116 150106 MOV     $TSTNM,2DISPLAY ; DON'T LET THE FLAG GO TO ZERO
; DISPLAY TEST NUMBER AND ERROR FLAG

```

```

7236 031050 032777 002000 150076 BIT #BIT10,2SWR ;;BELL ON ERROR?
7237 031056 001402 BEQ 1$ ;;NO - SKIP
7238 031060 104401 001174 TYPE $BELL ;;RING BELL
7239 031064 005237 001126 1$: INC $ERTTL ;;COUNT THE NUMBER OF ERRORS
7240 031070 011637 001132 MOV (SP), $ERRPC ;;GET ADDRESS OF ERROR INSTRUCTION
7241 031074 162737 000002 001132 SUB #2, $ERRPC
7242 031102 117737 150024 001130 MOVB 2$ERRPC, $ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
7243 031110 032777 020000 150036 BIT #BIT13,2SWR ;;SKIP TYPEOUT IF SET
7244 031116 001004 BNE 20$ ;;SKIP TYPEOUTS
7245 031120 004737 031172 JSR PC, $ERRTYP ;;GO TO USER ERROR ROUTINE
7246 031124 104401 001201 TYPE , $CRLF
7247 031130 20$:
7248 031130 122737 000001 001224 CMPB #APTENV, $ENV ;;RUNNING IN APT MODE
7249 031136 001007 BNE 2$ ;;NO SKIP APT ERROR REPORT
7250 031140 113737 001130 031152 MOVB $ITEMB, 21$ ;;SET ITEM NUMBER AS ERROR NUMBER
7251 031146 004737 031626 JSR PC, $ATY4 ;;REPORT FATAL ERROR TO APT
7252 031152 000 21$: .BYTE 0
7253 031153 000 .BYTE 0
7254 031154 000777 22$: BR 22$ ;;APT ERROR LOOP
7255 031156 005777 147772 2$: TST 2$SWR ;;HALT ON ERROR
7256 031162 100002 BPL 3$ ;;SKIP IF CONTINUE
7257 031164 000000 HALT ;;HALT ON ERROR!
7258 031166 104407 CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
7259 031170 3$:
7260 031170 000002 RTI ;;RETURN
    
```

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE

```

*****
;THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
;ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
;AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
    
```

```

$ERRTYP:
7270 031172 104401 001201 TYPE , $CRLF ;; "CARRIAGE RETURN" & "LINE FEED"
7271 031176 010046 MOV RO, -(SP) ;; SAVE RO
7272 031200 005000 CLR RO ;; PICKUP THE ITEM INDEX
7273 031202 153700 001130 BISB 2$ITEMB, RO
7274 031206 001004 BNE 1$ ;; IF ITEM NUMBER IS ZERO, JUST
7275 031210 013746 001132 MOV $ERRPC, -(SP) ;; TYPE THE PC OF THE ERROR
7276 031214 104402 TYP0C ;; SAVE $ERRPC FOR TYPEOUT
7277 031216 000426 BR 6$ ;; ERROR ADDRESS
7278 031220 005300 1$: DEC RO ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
7279 031222 006300 ASL RO ;; GET OUT
7280 031224 006300 ASL RO ;; ADJUST THE INDEX SO THAT IT WILL
7281 031226 006300 ASL RO ;; WORK FOR THE ERROR TABLE
7282 031230 062700 003542 ADD # $ERRTB, RO ;; FORM TABLE POINTER
7283 031234 012037 031244 MOV (RO)+, 2$ ;; PICKUP "ERROR MESSAGE" POINTER
7284 031240 001404 BEQ 3$ ;; SKIP TYPEOUT IF NO POINTER
7285 031242 104401 TYPE ;; TYPE THE "ERROR MESSAGE"
7286 031244 000000 2$: .WORD 0 ;; "ERROR MESSAGE" POINTER GOES HERE
7287 031246 104401 001201 TYPE , $CRLF ;; "CARRIAGE RETURN" & "LINE FEED"
7288 031252 012037 031262 3$: MOV (RO)+, 4$ ;; PICKUP "DATA HEADER" POINTER
7289 031256 001404 BEQ 5$ ;; SKIP TYPEOUT IF 0
    
```

```

7292 031260 104401          TYPE                                ;; TYPE THE "DATA HEADER"
7293 031262 000000          4$: .WORD 0                                ;; "DATA HEADER" POINTER GOES HERE
7294 031264 104401 001201  TYPE .SCRLF                                ;; "CARRIAGE RETURN" & "LINE FEED"
7295 031270 011000          5$: MOV (RO),RO                                ;; PICKUP "DATA TABLE" POINTER
7296 031272 001004          BNE 7$                                ;; GO TYPE THE DATA
7297 031274 012600          6$: MOV (SP)+,RO                                ;; RESTORE RO
7298 031276 104401 001201  TYPE .SCRLF                                ;; "CARRIAGE RETURN" & "LINE FEED"
7299 031302 000207          RTS PC                                ;; RETURN
7300 031304
7301 031304 013046          7$: MOV 2(RO)+,-(SP)                            ;; SAVE 2(RO)+ FOR TYPEOUT
7302 031306 104402          TYP0C                                ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
7303 031310 005710          TST (RO)                                ;; IS THERE ANOTHER NUMBER?
7304 031312 001770          BEQ 6$                                ;; BR IF NO
7305 031314 104401 031322  TYPE .8$                                ;; TYPE TWO(2) SPACES
7306 031320 000771          BR 7$                                ;; LOOP
7307 031322 020040 000      8$: .ASCIZ / /                            ;; TWO(2) SPACES
7308 031326 .EVEN

```

.SBTTL TYPE ROUTINE

```

7310
7311
7312
7313
7314
7315
7316
7317
7318
7319
7320
7321
7322
7323
7324
7325
7326
7327 031326 105737 001173  $TYPE: TSTB $TPFLG                                ;; IS THERE A TERMINAL?
7328 031332 100002          BPL 1$                                ;; BR IF YES
7329 031334 000000          HALT                                ;; HALT HERE IF NO TERMINAL
7330 031336 000430          BR 3$                                ;; LEAVE
7331 031340 010046          1$: MOV RO,-(SP)                                ;; SAVE RO
7332 031342 017600 000002  MOV 2(SP),RO                                ;; GET ADDRESS OF ASCIZ STRING
7333 031346 122737 000001 001224  CMPB #APTENV,$ENV                                ;; RUNNING IN APT MODE
7334 031354 001011          BNE 62$                                ;; NO, GO CHECK FOR APT CONSOLE
7335 031356 132737 000100 001225  BITB #APTPOOL,$ENVM                            ;; SPOOL MESSAGE TO APT
7336 031364 001405          BEQ 62$                                ;; NO, GO CHECK FOR CONSOLE
7337 031366 010037 031376  MOV RO,61$                                ;; SETUP MESSAGE ADDRESS FOR APT
7338 031372 004737 031616  JSR PC,$ATY3                            ;; SPOOL MESSAGE TO APT
7339 031376 000000          61$: .WORD 0                                ;; MESSAGE ADDRESS
7340 031400 132737 000040 001225  62$: BITB #APTCSUP,$ENVM                            ;; APT CONSOLE SUPPRESSED
7341 031406 001003          BNE 60$                                ;; YES, SKIP TYPE OUT
7342 031410 112046          2$: MOVB (RO)+,-(SP)                            ;; PUSH CHARACTER TO BE TYPED ONTO STACK
7343 031412 001005          BNE 4$                                ;; BR IF IT ISN'T THE TERMINATOR
7344 031414 005726          TST (SP)+                                ;; IF TERMINATOR POP IT OFF THE STACK
7345 031416 012600          60$: MOV (SP)+,RO                                ;; RESTORE RO
7346 031420 062716 000002  3$: ADD #2,(SP)                            ;; ADJUST RETURN PC
7347 031424 000002          RTI                                ;; RETURN

```

```

*****
; ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
; THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
; NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
; NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
; NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
;
; CALL:
; 1) USING A TRAP INSTRUCTION
; TYPE ,MESADR ; MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
; OR
; TYPE MESADR
;

```

```

7348 031426 122716 000011 4S:  CMPB  #HT,(SP)      ;;BRANCH IF <HT>
7349 031432 001430      BEQ    8S
7350 031434 122716 000200      CMPB  #CRLF,(SP)   ;;BRANCH IF NOT <CRLF>
7351 031440 001006      BNE   5S
7352 031442 005726      TST   (SP)+        ;;POP <CR><LF> EQUIV
7353 031444 104401      TYPE                    ;;TYPE A CR AND LF
7354 031446 001201      $CRLF
7355 031450 105037 031604      CLRB  $CHARCNT     ;;CLEAR CHARACTER COUNT
7356 031454 000755      BR    2S           ;;GET NEXT CHARACTER
7357 031456 004737 031540      JSR   PC,$TYPEC    ;;GO TYPE THIS CHARACTER
7358 031462 123726 001172      6S:  CMPB  $FILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?
7359 031466 001350      BNE   2S           ;;IF NO GO GET NEXT CHAR.
7360 031470 013746 001170      MOV   $NULL,-(SP)  ;;GET # OF FILLER CHARS. NEEDED
7361                                ;;AND THE NULL CHAR.
7362 031474 105366 000001      7S:  DECB  1(SP)      ;;DOES A NULL NEED TO BE TYPED?
7363 031500 002770      BLT   6S           ;;BR IF NO--GO POP THE NULL OFF OF STACK
7364 031502 004737 031540      JSR   PC,$TYPEC    ;;GO TYPE A NULL
7365 031506 105337 031604      DECB  $CHARCNT     ;;DO NOT COUNT AS A COUNT
7366 031512 000770      BR    7S           ;;LOOP

```

;HORIZONTAL TAB PROCESSOR

```

7367
7368
7369
7370 031514 112716 000040      8S:  MOVB  #' (SP)    ;;REPLACE TAB WITH SPACE
7371 031520 004737 031540      9S:  JSR   PC,$TYPEC    ;;TYPE A SPACE
7372 031524 132737 000007 031604      BITB  #7,$CHARCNT  ;;BRANCH IF NOT AT
7373 031532 001372      BNE   9S           ;;TAB STOP
7374 031534 005726      TST   (SP)+        ;;POP SPACE OFF STACK
7375 031536 000724      BR    2S           ;;GET NEXT CHARACTER
7376 031540 105777 147420      $TYPEC: TSTB  $STPS     ;;WAIT UNTIL PRINTER IS READY
7377 031544 100375      BPL   $TYPEC
7378 031546 116677 000002 147412      MOVB  2(SP),2$TPB  ;;LOAD CHAR TO BE TYPED INTO DATA REG.
7379 031554 122766 000015 000002      CMPB  #CR,2(SP)    ;;IS CHARACTER A CARRIAGE RETURN?
7380 031562 001003      BNE   1S           ;;BRANCH IF NO
7381 031564 105037 031604      CLRB  $CHARCNT     ;;YES--CLEAR CHARACTER COUNT
7382 031570 000406      BR    $TYPEX       ;;EXIT
7383 031572 122766 000012 000002      1S:  CMPB  #LF,2(SP)  ;;IS CHARACTER A LINE FEED?
7384 031600 001402      BEQ   $TYPEX       ;;BRANCH IF YES
7385 031602 105227      INCB  (PC)+        ;;COUNT THE CHARACTER
7386 031604 000000      $CHARCNT: .WORD  0 ;;CHARACTER COUNT STORAGE
7387 031606 000207      $TYPEX: RTS    PC
7388
7389
7390

```

.SBTTL APT COMMUNICATIONS ROUTINE

```

7391
7392
7393 031610 112737 000001 032054  $ATY1: MOVB  #1,$FFLG  ;;TO REPORT FATAL ERROR
7394 031616 112737 000001 032052  $ATY3: MOVB  #1,$MFLG  ;;TO TYPE A MESSAGE
7395 031624 000403      BR    $ATYC
7396 031626 112737 000001 032054  $ATY4: MOVB  #1,$FFLG  ;;TO ONLY REPORT FATAL ERROR
7397 031634      $ATYC:
7398 031634 010046      MOV   R0,-(SP)     ;;PUSH R0 ON STACK
7399 031636 010146      MOV   R1,-(SP)     ;;PUSH R1 ON STACK
7400 031640 105737 032052      TSTB  $MFLG        ;;SHOULD TYPE A MESSAGE?
7401 031644 001450      BEQ   5S           ;;IF NOT: BR
7402 031646 122737 000001 001224      CMPB  #APTENV,$ENV  ;;OPERATING UNDER APT?
7403 031654 001031      BNE   3S           ;;IF NOT: BR

```

```

7404 031656 132737 000100 001225 BITB #APTPOOL,SENV ;: SHOULD SPOOL MESSAGES?
7405 031664 001425 BEQ 3$ ;: IF NOT: BR
7406 031666 017600 000004 MOV 24(SP),RO ;: GET MESSAGE ADDR.
7407 031672 062766 000002 000004 ADD #2,4(SP) ;: BUMP RETURN ADDR.
7408 031700 005737 001204 1$: TST $MSGTYPE ;: SEE IF DONE W/ LAST XMISSION?
7409 031704 001375 BNE 1$ ;: IF NOT: WAIT
7410 031706 010037 001220 MOV RO,$MSGAD ;: PUT ADDR IN MAILBOX
7411 031712 105720 2$: TSTB (RO)+ ;: FIND END OF MESSAGE
7412 031714 001376 BNE 2$
7413 031716 163700 001220 SUB $MSGAD,RO ;: SUB START OF MESSAGE
7414 031722 006200 ASR RO ;: GET MESSAGE LNTH IN WORDS
7415 031724 010037 001222 MOV RO,$MSGLGT ;: PUT LENGTH IN MAILBOX
7416 031730 012737 000004 001204 MOV #4,$MSGTYPE ;: TELL APT TO TAKE MSG.
7417 031736 000413 BR 5$
7418 031740 017637 000004 031764 3$: MOV 24(SP),4$ ;: PUT MSG ADDR IN JSR LINKAGE
7419 031746 062766 000002 000004 ADD #2,4(SP) ;: BUMP RETURN ADDRESS
7420 031754 013746 177776 MOV 177776,-(SP) ;: PUSH 177776 ON STACK
7421 031760 004737 031326 JSR PC,$TYPE ;: CALL TYPE MACRO
7422 031764 000000 4$: .WORD 0
7423 031766 5$:
7424 031766 105737 032054 10$: TSTB $FFLG ;: SHOULD REPORT FATAL ERROR?
7425 031772 001416 BEQ 12$ ;: IF NOT: BR
7426 031774 005737 001224 TST $ENV ;: RUNNING UNDER APT?
7427 032000 001413 BEQ 12$ ;: IF NOT: BR
7428 032002 005737 001204 11$: TST $MSGTYPE ;: FINISHED LAST MESSAGE?
7429 032006 001375 BNE 11$ ;: IF NOT: WAIT
7430 032010 017637 000004 001206 MOV 24(SP),$FATAL ;: GET ERROR #
7431 032016 062766 000002 000004 ADD #2,4(SP) ;: BUMP RETURN ADDR.
7432 032024 005237 001204 INC $MSGTYPE ;: TELL APT TO TAKE ERROR
7433 032030 105037 032054 12$: CLRB $FFLG ;: CLEAR FATAL FLAG
7434 032034 105037 032053 CLRB $LFLG ;: CLEAR LOG FLAG
7435 032040 105037 032052 CLRB $MFLG ;: CLEAR MESSAGE FLAG
7436 032044 012601 MOV (SP)+,R1 ;: POP STACK INTO R1
7437 032046 012600 MOV (SP)+,RO ;: POP STACK INTO RO
7438 032050 000207 RTS PC ;: RETURN
7439 032052 000 $MFLG: .BYTE 0 ;: MESSG. FLAG
7440 032053 000 $LFLG: .BYTE 0 ;: LOG FLAG
7441 032054 000 $FFLG: .BYTE 0 ;: FATAL FLAG
7442 032056 .EVEN
7443 000200 APTSIZE=200
7444 000001 APTENV=001
7445 000100 APTSPool=100
7446 000040 APTCSUP=040
7447
7448 .SBTTL POWER DOWN AND UP ROUTINES
7449
7450 ;: *****
7451 ;: POWER DOWN ROUTINE
7452 032056 012737 032222 000024 $PWRDN: MOV #SILLUP,2#PWRVEC ;: SET FOR FAST UP
7453 032064 012737 000340 000026 MOV #340,2#PWRVEC+2 ;: PRIO:7
7454 032072 010046 MOV RO,-(SP) ;: PUSH RO ON STACK
7455 032074 010146 MOV R1,-(SP) ;: PUSH R1 ON STACK
7456 032076 010246 MOV R2,-(SP) ;: PUSH R2 ON STACK
7457 032100 010346 MOV R3,-(SP) ;: PUSH R3 ON STACK
7458 032102 010446 MOV R4,-(SP) ;: PUSH R4 ON STACK
7459 032104 010546 MOV R5,-(SP) ;: PUSH R5 ON STACK

```

```

7460 032106 017746 147042      MOV    @SWR, -(SP)      ;; PUSH @SWR ON STACK
7461 032112 010637 032226      MOV    SP, $SAVR6     ;; SAVE SP
7462 032116 012737 032130 000024  MOV    @SPWRUP, @PWRVEC ;; SET UP VECTOR
7463 032124 000000                HALT
7464 032126 000776                BR     .-2            ;; HANG UP
7465
7466      ;; *****
7467      ;; POWER UP ROUTINE
7468 032130 012737 032222 000024 $PWRUP: MOV    $SILLUP, @PWRVEC ;; SET FOR FAST DOWN
7469 032136 013706 032226      MOV    $SAVR6, SP     ;; GET SP
7470 032142 005037 032226      CLR    $SAVR6        ;; WAIT LOOP FOR THE TTY
7471 032146 005237 032226      1$:   INC    $SAVR6    ;; WAIT FOR THE INC
7472 032152 001375                BNE    1$            ;; OF WORD
7473 032154 012677 146774      MOV    (SP)+, @SWR    ;; POP STACK INTO @SWR
7474 032160 012605      MOV    (SP)+, R5     ;; POP STACK INTO R5
7475 032162 012604      MOV    (SP)+, R4     ;; POP STACK INTO R4
7476 032164 012603      MOV    (SP)+, R3     ;; POP STACK INTO R3
7477 032166 012602      MOV    (SP)+, R2     ;; POP STACK INTO R2
7478 032170 012601      MOV    (SP)+, R1     ;; POP STACK INTO R1
7479 032172 012600      MOV    (SP)+, R0     ;; POP STACK INTO R0
7480 032174 012737 032056 000024  MOV    @SPWRDN, @PWRVEC ;; SET UP THE POWER DOWN VECTOR
7481 032202 012737 000340 000026  MOV    #340, @PWRVEC+2 ;; PRIO:7
7482 032210 104401                TYPE    $POWER        ;; REPORT THE POWER FAILURE
7483 032212 032230      SPWRMG: .WORD    $POWER    ;; POWER FAIL MESSAGE POINTER
7484 032214 012716      MOV    (PC)+, (SP)   ;; RESTART AT START2
7485 032216 003650      SPWRAD: .WORD    START2  ;; RESTART ADDRESS
7486 032220 000002                RTI
7487 032222 000000      $SILLUP: HALT      ;; THE POWER UP SEQUENCE WAS STARTED
7488 032224 000776                BR     .-2            ;; BEFORE THE POWER DOWN WAS COMPLETE
7489 032226 000000      $SAVR6: 0            ;; PUT THE SP HERE
7490 032230 005015 047520 042527 $POWER: .ASCIZ  <15><12>"POWER"
7491 032236 000122
7492      .EVEN
7493
7494      .SBTTL  BINARY TO OCTAL (ASCII) AND TYPE
7495
7496      ;; *****
7497      ;; THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
7498      ;; OCTAL (ASCII) NUMBER AND TYPE IT.
7499      ;; $TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
7500      ;; $CALL:
7501      ;;     MOV    NUM, -(SP)      ;; NUMBER TO BE TYPED
7502      ;;     TYPOS      ;; CALL FOR TYPEOUT
7503      ;;     .BYTE  N            ;; N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
7504      ;;     .BYTE  M            ;; M=1 OR 0
7505      ;;     ;; 1=TYPE LEADING ZEROS
7506      ;;     ;; 0=SUPPRESS LEADING ZEROS
7507
7508      ;; $STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
7509      ;; $TYPOS OR $TYPOC
7510      ;; $CALL:
7511      ;;     MOV    NUM, -(SP)      ;; NUMBER TO BE TYPED
7512      ;;     TYPON      ;; CALL FOR TYPEOUT
7513
7514      ;; $STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
7515      ;; $CALL:
    
```

```

7516      ;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
7517      ;*      TYPOC      ;;CALL FOR TYPEOUT
7518
7519      032240 017646 000000      STYPOS: MOV      2(SP),-(SP)      ;;PICKUP THE MODE
7520      032244 116637 000001 032463      MOVVB     1(SP),SOFILL      ;;LOAD ZERO FILL SWITCH
7521      032252 112637 032465      MOVVB     (SP)+,SOMODE+1      ;;NUMBER OF DIGITS TO TYPE
7522      032256 062716 000002      ADD      #2,(SP)      ;;ADJUST RETURN ADDRESS
7523      032262 000406      BR      STYPON
7524      032264 112737 000001 032463      STYPOC: MOVVB     #1,SOFILL      ;;SET THE ZERO FILL SWITCH
7525      032272 112737 000006 032465      MOVVB     #6,SOMODE+1      ;;SET FOR SIX(6) DIGITS
7526      032300 112737 000005 032462      STYPON: MOVVB     #5,SOCNT      ;;SET THE ITERATION COUNT
7527      032306 010346      MOV      R3,-(SP)      ;;SAVE R3
7528      032310 010446      MOV      R4,-(SP)      ;;SAVE R4
7529      032312 010546      MOV      R5,-(SP)      ;;SAVE R5
7530      032314 113704 032465      MOVVB     SOMODE+1,R4      ;;GET THE NUMBER OF DIGITS TO TYPE
7531      032320 005404      NEG      R4
7532      032322 062704 000006      ADD      #6,R4      ;;SUBTRACT IT FOR MAX. ALLOWED
7533      032326 110437 032464      MOVVB     R4,SOMODE      ;;SAVE IT FOR USE
7534      032332 113704 032463      MOVVB     SOFILL,R4      ;;GET THE ZERO FILL SWITCH
7535      032336 016605 000012      MOV      12(SP),R5      ;;PICKUP THE INPUT NUMBER
7536      032342 005003      CLR      R3      ;;CLEAR THE OUTPUT WORD
7537      032344 006105      1$:      ROL      R5      ;;ROTATE MSB INTO "C"
7538      032346 000404      BR      3$      ;;GO DO MSB
7539      032350 006105      2$:      ROL      R5      ;;FORM THIS DIGIT
7540      032352 006105      ROL      R5
7541      032354 006105      ROL      R5
7542      032356 010503      MOV      R5,R3
7543      032360 006103      3$:      ROL      R3      ;;GET LSB OF THIS DIGIT
7544      032362 105337 032464      DECB     SOMODE      ;;TYPE THIS DIGIT?
7545      032366 100016      BPL      7$      ;;BR IF NO
7546      032370 042703 177770      BIC      #177770,R3      ;;GET RID OF JUNK
7547      032374 001002      BNE      4$      ;;TEST FOR 0
7548      032376 005704      TST      R4      ;;SUPPRESS THIS 0?
7549      032400 001403      BEQ      5$      ;;BR IF YES
7550      032402 005204      4$:      INC      R4      ;;DON'T SUPPRESS ANYMORE 0'S
7551      032404 052703 000060      BIS      #'0,R3      ;;MAKE THIS DIGIT ASCII
7552      032410 052703 000040      5$:      BIS      #' ,R3      ;;MAKE ASCII IF NOT ALREADY
7553      032414 110337 032460      MOVVB     R3,#$      ;;SAVE FOR TYPING
7554      032420 104401 032460      TYPE     #,$      ;;GO TYPE THIS DIGIT
7555      032424 105337 032462      7$:      DECB     SOCNT      ;;COUNT BY 1
7556      032430 003347      BGT      2$      ;;BR IF MORE TO DO
7557      032432 002402      BLT      6$      ;;BR IF DONE
7558      032434 005204      INC      R4      ;;INSURE LAST DIGIT ISN'T A BLANK
7559      032436 000744      BR      2$      ;;GO DO THE LAST DIGIT
7560      032440 012605      6$:      MOV      (SP)+,R5      ;;RESTORE R5
7561      032442 012604      MOV      (SP)+,R4      ;;RESTORE R4
7562      032444 012603      MOV      (SP)+,R3      ;;RESTORE R3
7563      032446 016666 000002 000004      MOV      2(SP),4(SP)      ;;SET THE STACK FOR RETURNING
7564      032454 012616      MOV      (SP)+,(SP)
7565      032456 000002      RTI
7566      032460 000      8$:      .BYTE   0      ;;RETURN
7567      032461 000      .BYTE   0      ;;STORAGE FOR ASCII DIGIT
7568      032462 000      SOCNT:   .BYTE   0      ;;TERMINATOR FOR TYPE ROUTINE
7569      032463 000      SOFILL: .BYTE   0      ;;OCTAL DIGIT COUNTER
7570      032464 000000      SOMODE: .WORD   0      ;;ZERO FILL SWITCH
7571

```

```

7572 .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
7573
7574 *****
7575 *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
7576 *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
7577 *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
7578 *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
7579 *REPLACED WITH SPACES.
7580 *CALL:
7581 *      MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
7582 *      TYPDS                    ;;GO TO THE ROUTINE
7583
7584 $TYPDS:
7585      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
7586      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
7587      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
7588      MOV      R3,-(SP)      ;;PUSH R3 ON STACK
7589      MOV      R5,-(SP)      ;;PUSH R5 ON STACK
7590      MOV      #20200,-(SP)  ;;SET BLANK SWITCH AND SIGN
7591      MOV      20(SP),R5     ;;GET THE INPUT NUMBER
7592      BPL      1$           ;;BR IF INPUT IS POS.
7593      NEG      R5           ;;MAKE THE BINARY NUMBER POS.
7594      MOVB    #'-,1(SP)     ;;MAKE THE ASCII NUMBER NEG.
7595      CLR      R0           ;;ZERO THE CONSTANTS INDEX
7596      MOV      #SDBLK,R3    ;;SETUP THE OUTPUT POINTER
7597      MOVB    #' ,(R3)+    ;;SET THE FIRST CHARACTER TO A BLANK
7598      CLR      R2           ;;CLEAR THE BCD NUMBER
7599      MOV      $DTBL(R0),R1 ;;GET THE CONSTANT
7600      SUB      R1,R5        ;;FORM THIS BCD DIGIT
7601      BLT     4$           ;;BR IF DONE
7602      INC     R2           ;;INCREASE THE BCD DIGIT BY 1
7603      BR      3$
7604      ADD     R1,R5        ;;ADD BACK THE CONSTANT
7605      TST     R2           ;;CHECK IF BCD DIGIT=0
7606      BNE     5$           ;;FALL THROUGH IF 0
7607      TSTB   (SP)         ;;STILL DOING LEADING 0'S?
7608      BMI     7$           ;;BR IF YES
7609      ASLB   (SP)         ;;MSD?
7610      BCC     6$           ;;BR IF NO
7611      MOVB   1(SP),-1(R3) ;;YES--SET THE SIGN
7612      BIS    #'0,R2       ;;MAKE THE BCD DIGIT ASCII
7613      BIS    #' ,R2       ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
7614      MOVB   R2,(R3)+    ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
7615      TST    (R0)+       ;;JUST INCREMENTING
7616      CMP    R0,#10      ;;CHECK THE TABLE INDEX
7617      BLT    2$           ;;GO DO THE NEXT DIGIT
7618      BGT    8$           ;;GO TO EXIT
7619      MOV    R5,R2       ;;GET THE LSD
7620      BR     6$           ;;GO CHANGE TO ASCII
7621      TSTB   (SP)+       ;;WAS THE LSD THE FIRST NON-ZERO?
7622      BPL    9$           ;;BR IF NO
7623      MOVB   -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
7624      CLRB   (R3)        ;;SET THE TERMINATOR
7625      MOV    (SP)+,R5     ;;POP STACK INTO R5
7626      MOV    (SP)+,R3     ;;POP STACK INTO R3
7627      MOV    (SP)+,R2     ;;POP STACK INTO R2
    
```



```

7628 032650 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
7629 032652 012600      MOV      (SP)+,R0      ;;POP STACK INTO R0
7630 032654 104401 032702  TYPE      $DBLK      ;;NOW TYPE THE NUMBER
7631 032656 016666 000002 000004  MOV      2(SP),4(SP)  ;;ADJUST THE STACK
7632 032666 012616      MOV      (SP)+,(SP)
7633 032670 000002      RTI                          ;;RETURN TO USER
7634 032672 023420      SOTBL:  10000.
7635 032674 001750      1000.
7636 032676 000144      100.
7637 032700 000012      10.
7638 032702 000004      SDBLK:  .BLKW  4
7639
7640      .SBTTL  TTY INPUT ROUTINE
7641
7642      ;:*****
7643      .ENABL  LSB
7644
7645      ;:*****
7646      ;:SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
7647      ;:ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
7648      ;:SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
7649      ;:WHEN OPERATING IN TTY FLAG MODE.
7650 032712 022737 000176 001154  SCKSWR:  CMP      #SWREG,SWR      ;; IS THE SOFT-SWR SELECTED?
7651 032720 001074      BNE      15$                ;; BRANCH IF NO
7652 032722 105777 146232      TSTB    @STKS                ;; CHAR THERE?
7653 032726 100071      BPL      15$                ;; IF NO, DON'T WAIT AROUND
7654 032730 117746 146226      MOVB    @STKB,-(SP)          ;; SAVE THE CHAR
7655 032734 042716 177600      BIC     #1C177,(SP)         ;; STRIP-OFF THE ASCII
7656 032740 022726 000007      CMP     #7,(SP)+            ;; IS IT A CONTROL G?
7657 032744 001062      BNE     15$                ;; NO, RETURN TO USER
7658 032746 123727 001150 000001      CMPB    $AUTOB,#1           ;; ARE WE RUNNING IN AUTO-MODE?
7659 032754 001456      BEQ     15$                ;; BRANCH IF YES
7660
7661 032756 104401 033321      TYPE    ,SCNTLG             ;; ECHO THE CONTROL-G (1G)
7662 032762 104401 033326      SGTSWR: TYPE    ,SMSWR             ;; TYPE CURRENT CONTENTS
7663 032766 013746 000176      MOV     $WREG,-(SP)         ;; SAVE SWREG FOR TYPEOUT
7664 032772 104402      TYPOC  ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
7665 032774 104401 033337      TYPE    ,SMNEW             ;; PROMPT FOR NEW SWR
7666 033000 005046      19$:   CLR     -(SP)          ;; CLEAR COUNTER
7667 033002 005046      CLR     -(SP)          ;; THE NEW SWR
7668 033004 105777 146150      7$:   TSTB    @STKS                ;; CHAR THERE?
7669 033010 100375      BPL     7$                ;; IF NOT TRY AGAIN
7670
7671 033012 117746 146144      MOVB    @STKB,-(SP)          ;; PICK UP CHAR
7672 033016 042716 177600      BIC     #1C177,(SP)         ;; MAKE IT 7-BIT ASCII
7673
7674
7675
7676 033022 021627 000025      9$:   CMP     (SP),#25         ;; IS IT A CONTROL-U?
7677 033026 001005      BNE     10$                ;; BRANCH IF NOT
7678 033030 104401 033314      TYPE    ,SCNTLU            ;; YES, ECHO CONTROL-U (1U)
7679 033034 062706 000006      20$:  ADD     #6,SP            ;; IGNORE PREVIOUS INPUT
7680 033040 000757      BR      19$                ;; LET'S TRY IT AGAIN
7681
7682
7683 033042 021627 000015      10$:  CMP     (SP),#15         ;; IS IT A <CR>?
    
```

7684	033046	001022				BNE	16\$	:: BRANCH IF NO
7685	033050	005766	000004			TST	4(SP)	:: YES, IS IT THE FIRST CHAR?
7686	033054	001403				BEQ	11\$	:: BRANCH IF YES
7687	033056	016677	000002	146070		MOV	2(SP), 2\$SR	:: SAVE NEW \$SR
7688	033064	062706	000006		11\$:	ADD	#6, SP	:: CLEAR UP STACK
7689	033070	104401	001201		14\$:	TYPE	\$CR LF	:: ECHO <CR> AND <LF>
7690	033074	123727	001151	000001		CMPB	\$INTAG, #1	:: RE-ENABLE TTY KBD INTERRUPTS?
7691	033102	001003				BNE	15\$	:: BRANCH IF NOT
7692	033104	012777	000100	146046		MOV	#100, 2\$TKS	:: RE-ENABLE TTY KBD INTERRUPTS
7693	033112	000002			15\$:	RTI		:: RETURN
7694	033114	004737	031540		16\$:	JSR	PC, \$TYPEC	:: ECHO CHAR
7695	033120	021627	000060			CMP	(SP), #60	:: CHAR < 0?
7696	033124	002420				BLT	18\$	:: BRANCH IF YES
7697	033126	021627	000067			CMP	(SP), #67	:: CHAR > 7?
7698	033132	003015				BGT	18\$	:: BRANCH IF YES
7699	033134	042726	000060			BIC	#60, (SP)+	:: STRIP-OFF ASCII
7700	033140	005766	000002			TST	2(SP)	:: IS THIS THE FIRST CHAR
7701	033144	001403				BEQ	17\$	:: BRANCH IF YES
7702	033146	006316				ASL	(SP)	:: NO, SHIFT PRESENT
7703	033150	006316				ASL	(SP)	:: CHAR OVER TO MAKE
7704	033152	006316				ASL	(SP)	:: ROOM FOR NEW ONE.
7705	033154	005266	000002		17\$:	INC	2(SP)	:: KEEP COUNT OF CHAR
7706	033160	056616	177776			BIS	-2(SP), (SP)	:: SET IN NEW CHAR
7707	033164	000707				BR	7\$	:: GET THE NEXT ONE
7708	033166	104401	001200		18\$:	TYPE	\$QUES	:: TYPE ?<CR><LF>
7709	033172	000720				BR	20\$	:: SIMULATE CONTROL-U
7710					.DSABL	LSB		

:: \*\*\*\*\*

:: \*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

:: \*CALL:

:: *	RDCHR	:: INPUT A SINGLE CHARACTER FROM THE TTY
:: *	RETURN HERE	:: CHARACTER IS ON THE STACK
:: *		:: WITH PARITY BIT STRIPPED OFF

7721	033174	011646				\$RDCHR: MOV	(SP), -(SP)	:: PUSH DOWN THE PC
7722	033176	016666	000004	000002		MOV	4(SP), 2(SP)	:: SAVE THE PS
7723	033204	105777	145750		1\$:	TSTB	2\$TKS	:: WAIT FOR
7724	033210	100375				BPL	1\$	:: A CHARACTER
7725	033212	117766	145744	000004		MOVB	2\$TKB, 4(SP)	:: READ THE TTY
7726	033220	042766	177600	000004		BIC	#1C<177>, 4(SP)	:: GET RID OF JUNK IF ANY
7727	033226	026627	000004	000023		CMP	4(SP), #23	:: IS IT A CONTROL-S?
7728	033234	001013				BNE	3\$	:: BRANCH IF NO
7729	033236	105777	145716		2\$:	TSTB	2\$TKS	:: WAIT FOR A CHARACTER
7730	033242	100375				BPL	2\$	:: LOOP UNTIL ITS THERE
7731	033244	117746	145712			MOVB	2\$TKB, -(SP)	:: GET CHARACTER
7732	033250	042716	177600			BIC	#1C177, (SP)	:: MAKE IT 7-BIT ASCII
7733	033254	022627	000021			CMP	(SP)+, #21	:: IS IT A CONTROL-Q?
7734	033260	001366				BNE	2\$	:: IF NOT DISCARD IT
7735	033262	000750				BR	1\$	:: YES, RESUME
7736	033264	026627	000004	000140	3\$:	CMP	4(SP), #140	:: IS IT UPPER CASE?
7737	033272	002407				BLT	4\$	:: BRANCH IF YES
7738	033274	026627	000004	000175		CMP	4(SP), #175	:: IS IT A SPECIAL CHAR?
7739	033302	003003				BGT	4\$	:: BRANCH IF YES

```

7740 033304 042766 000040 000004 BIC #40,4(SP) ;;MAKE IT UPPER CASE
7741 033312 000002 4S: RTI ;;GO BACK TO USER
7742 033314 052536 005015 000 SCNTLU: .ASCIZ /↑U/<15><12> ;;CONTROL "U"
7743 033321 136 006507 000012 SCNTLG: .ASCIZ /↑G/<15><12> ;;CONTROL "G"
7744 033326 005015 053523 020122 SMSWR: .ASCIZ <15><12>/SWR = /
7745 033334 020075 000
7746 033337 040 047040 053505 SMNEW: .ASCIZ / NEW = /
7747 033344 036440 000040

```

.SBTTL RANDOM NUMBER GENERATOR ROUTINE

```

7748
7749
7750
7751 ;*****
7752 ;*THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
7753 ;*WITH A RANGE OF 0 TO 2(+33)-1.
7754 ;*CALL:
7755 ;* JSR PC,SRAND ;;CALL THE ROUTINE
7756 ;* RETURN ;;RETURN HERE THE RANDOM
7757 ;* ;;NUMBER WILL BE IN
7758 ;* ;;SHINUM,SLONUM
7759

```

```

7760 033350 SRAND:
7761 033350 010046 MOV RO,-(SP) ;;PUSH RO ON STACK
7762 033352 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
7763 033354 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
7764 033356 013700 033450 MOV $LONUM,RO ;;SET RO WITH LOW
7765 033362 013701 033446 MOV $SHINUM,R1 ;;SET R1 WITH HIGH
7766 033366 012702 177771 MOV #-7,R2 ;;SET SHIFT COUNT
7767 033372 006300 1S: ASL RO ;;SHIFT RO LEFT AND
7768 033374 006101 ROL R1 ;;ROTATE CARRY INTO R1 AND
7769 033376 005202 INC R2 ;;CHECK FOR DONE
7770 033400 001374 BNE 1S ;;CONTINUE SHIFT LOOP
7771 033402 063700 033450 ADD $LONUM,RO ;;ADD NUMBER TO MAKE X 129
7772 033406 005501 ADC R1 ;;PROPOGATE CARRY
7773 033410 063701 033446 ADD $SHINUM,R1 ;;ADD NUMBER TO MAKE X 129
7774 033414 062700 001057 ADD #1057,RO ;;ADD LOW CONSTANT
7775 033420 005501 ADC R1 ;;PROPOGATE CARRY
7776 033422 062701 047401 ADD #47401,R1 ;;ADD HIGH CONSTANT
7777 033426 010037 033450 MOV RO,$LONUM ;;SAVE RO
7778 033432 010137 033446 MOV R1,$SHINUM ;;SAVE R1
7779 033436 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
7780 033440 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
7781 033442 012600 MOV (SP)+,RO ;;POP STACK INTO RO
7782 033444 000207 RTS PC ;;RETURN
7783 033446 176543 $SHINUM: .WORD 176543
7784 033450 123456 $LONUM: .WORD 123456
7785

```

.SBTTL SAVE AND RESTORE RO-R5 ROUTINES

```

7786
7787
7788 ;*****
7789 ;*SAVE RO-R5
7790 ;*CALL:
7791 ;* SAVREG
7792 ;*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
7793 ;*
7794 ;*TOP---(+16)
7795 ;* +2---(+18)

```

```

7796
7797
7798
7799
7800
7801
7802
7803 033452
7804 033452 010046
7805 033454 010146
7806 033456 010246
7807 033460 010346
7808 033462 010446
7809 033464 010546
7810 033466 016646 000022
7811 033472 016646 000022
7812 033476 016646 000022
7813 033502 016646 000022
7814 033506 000002
7815
7816
7817
7818
7819 033510
7820 033510 012666 000022
7821 033514 012666 000022
7822 033520 012666 000022
7823 033524 012666 000022
7824 033530 012605
7825 033532 012604
7826 033534 012603
7827 033536 012602
7828 033540 012601
7829 033542 012600
7830 033544 000002
7831
7832
7833
7834
7835
7836
7837
7838
7839
7840
7841
7842
7843
7844
7845 033546 104412
7846 033550 016602 000002
7847 033554 012700 033726
7848 033560 010066 000002
7849 033564 012201
7850 033566 012202
7851 033570 012737 000012 033644

```

```

; * +4---R5
; * +6---R4
; * +8---R3
; * +10---R2
; * +12---R1
; * +14---R0

$SAVREG:
MOV RO, -(SP) ;; PUSH RO ON STACK
MOV R1, -(SP) ;; PUSH R1 ON STACK
MOV R2, -(SP) ;; PUSH R2 ON STACK
MOV R3, -(SP) ;; PUSH R3 ON STACK
MOV R4, -(SP) ;; PUSH R4 ON STACK
MOV R5, -(SP) ;; PUSH R5 ON STACK
MOV 22(SP), -(SP) ;; SAVE PS OF MAIN FLOW
MOV 22(SP), -(SP) ;; SAVE PC OF MAIN FLOW
MOV 22(SP), -(SP) ;; SAVE PS OF CALL
MOV 22(SP), -(SP) ;; SAVE PC OF CALL
RTI

; *RESTORE RO-R5
; *CALL:
; * RESREG
$RESREG:
MOV (SP)+, 22(SP) ;; RESTORE PC OF CALL
MOV (SP)+, 22(SP) ;; RESTORE PS OF CALL
MOV (SP)+, 22(SP) ;; RESTORE PC OF MAIN FLOW
MOV (SP)+, 22(SP) ;; RESTORE PS OF MAIN FLOW
MOV (SP)+, R5 ;; POP STACK INTO R5
MOV (SP)+, R4 ;; POP STACK INTO R4
MOV (SP)+, R3 ;; POP STACK INTO R3
MOV (SP)+, R2 ;; POP STACK INTO R2
MOV (SP)+, R1 ;; POP STACK INTO R1
MOV (SP)+, R0 ;; POP STACK INTO R0
RTI

.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

; *****
; *THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
; *DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
; *POSITIVE.
; *CALL
; * MOV #PNTR, -(SP) ;; POINTER TO LOW WORD OF BINARY NUMBER
; * JSR PC, @#$DB2D
; * RETURN ;; THE FIRST ADDRESS OF ASCII
; ;; IS ON THE STACK

$DB2D: SAVREG ;; SAVE REGISTERS
MOV 2(SP), R2 ;; PICKUP THE DATA POINTER
MOV #$DECVL, R0 ;; GET ADDRESS OF "$DECVL" STRING
MOV R0, 2(SP) ;; PUT ADDRESS OF ASCII STRING ON STACK
MOV (R2)+, R1 ;; PICKUP THE BINARY NUMBER
MOV (R2)+, R2
MOV #10., 4$ ;; SET UP TO DO 10 CONVERSIONS

```

```

7852 033576 012704 033656      MOV      #STNPWR,R4      ;; ADDRESS OF TEN POWER
7853 033602 012705 033660      MOV      #STNPWR+2,R5
7854 033606 005003      1$:    CLR      R3          ;; CLEAR PARTIAL
7855 033610 161401      2$:    SUB      (R4),R1      ;; SUBTRACT TEN POWER
7856 033612 005602      SBC      R2
7857 033614 161502      SUB      (R5),R2
7858 033616 002402      BLT      3$              ;; BR IF TEN POWER TO LARGE
7859 033620 005203      INC      R3              ;; ADD 1 TO PARTIAL
7860 033622 000772      BR       2$              ;; LOOP
7861 033624 062401      3$:    ADD      (R4)+,R1      ;; RESTORE SUBTRACTED VALUE
7862 033626 005502      ADC      R2
7863 033630 062402      ADD      (R4)+,R2
7864 033632 022525      CMP      (R5)+,(R5)+    ;; MOVE TO NEXT TEN POWER
7865 033634 052703 000060  BIS      #'0,R3          ;; CHANGE PARTIAL TO ASCII
7866 033640 110320      MOVB     R3,(R0)+        ;; SAVE IT
7867 033642 005327      DEC      (PC)+          ;; DONE?
7868 033644 000000      4$:    .WORD    0
7869 033646 001357      BNE      1$              ;; BR IF NO
7870 033650 105020      CLRB     (R0)+          ;; TERMINATOR
7871 033652 104413      RESREG   ;; RESTORE REGISTERS
7872 033654 000207      RTS      PC              ;; RETURN
7873 033656 145000      STNPWR: 145000          ;; 1.0E09
7874 033660 035632      35632
7875 033662 160400      160400          ;; 1.0E08
7876 033664 002765      2765
7877 033666 113200      113200          ;; 1.0E07
7878 033670 000230      230
7879 033672 041100      041100          ;; 1.0E06
7880 033674 000017      17
7881 033676 103240      103240          ;; 1.0E05
7882 033700 000001      1
7883 033702 023420      23420          ;; 1.0E04
7884 033704 000000      0
7885 033706 001750      1750          ;; 1.0E03
7886 033710 000000      0
7887 033712 000144      144          ;; 1.0E02
7888 033714 000000      0
7889 033716 000012      12          ;; 1.0E01
7890 033720 000000      0
7891 033722 000001      1          ;; 1.0E00
7892 033724 000000      0
7893 033726 000014      $DECVL: .BLKB 12.      ;; RESERVE STORAGE FOR ASCII STRING
7894
7895      .SBTTL  DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE
7896
7897      ;; *****
7898      ;; *THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
7899      ;; *UNSIGNED OCTAL ASCII NUMBER.
7900      ;; *CALL
7901      ;; *      MOV      #PNTR,-(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
7902      ;; *      JSR      PC,@#$DB20      ;; CALL THE ROUTINE
7903      ;; *      RETURN                      ;; THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK
7904
7905
7906 033742 104412      $DB20: SAVREG
7907 033744 016601 000002      MOV      2(SP),R1      ;; SAVE ALL REGISTERS
                          ;; PICKUP THE POINTER TO LOW WORD
    
```

```

7908 033750 012705 034061      MOV      #SOCTVL+13.,R5    ;; POINTER TO DATA TABLE
7909 033754 012704 000014      MOV      #12.,R4         ;; DO ELEVEN CHARACTERS
7910 033760 012703 177770      MOV      #C7,R3         ;; MASK
7911 033764 012100              MOV      (R1)+,R0        ;; LOWER WORD
7912 033766 012101              MOV      (R1)+,R1        ;; HIGH WORD
7913 033770 005002              CLR      R2             ;; TERMINATOR
7914 033772 110245      1$:    MOVB   R2,-(R5)        ;; PUT CHARACTER IN DATA TABLE
7915 033774 010002              MOV      R0,R2         ;; GET THIS DIGIT
7916 033776 005304              DEC      R4            ;; COUNT THIS CHARACTER
7917 034000 003007              BGT     3$             ;; BR IF NOT THE LAST DIGIT
7918 034002 001405              BEQ     2$             ;; BR IF IT IS THE LAST DIGIT
7919 034004 005205              INC     R5            ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
7920 034006 010566 000002      MOV      R5,2(SP)       ;; ASCIZ CHAR. & PUT IT ON THE STACK
7921 034012 104413              RESREG                    ;; RESTORE ALL REGISTERS
7922 034014 000207              RTS     PC             ;; RETURN TO USER
7923 034016 006203      2$:    ASR     R3            ;; POSITION THE MASK FOR THE LAST DIGIT
7924 034020 006001      3$:    ROR     R1            ;; POSITION THE BINARY NUMBER FOR
7925 034022 006000              ROR     R0            ;; THE NEXT OCTAL DIGIT
7926 034024 006001              ROR     R1
7927 034026 006000              ROR     R0
7928 034030 006001              ROR     R1
7929 034032 006000              ROR     R0
7930 034034 040302              BIC     R3,R2         ;; MASK OUT ALL JUNK
7931 034036 062702 000060      ADD     #'0,R2         ;; MAKE THIS CHAR. ASCII
7932 034042 000753              BR      1$            ;; GO PUT IT IN THE DATA TABLE
7933 034044 000016      SOCTVL: .BLKB 14.     ;; RESERVE DATA TABLE
7934
7935      .SBTTL TRAP DECODER
7936
7937      ;;*****
7938      ;;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
7939      ;;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
7940      ;;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
7941      ;;*GO TO THAT ROUTINE.
7942
7943 034062 010046      $TRAP: MOV     R0,-(SP)    ;; SAVE R0
7944 034064 016600 000002      MOV     2(SP),R0      ;; GET TRAP ADDRESS
7945 034070 005740              TST     -(R0)         ;; BACKUP BY 2
7946 034072 111000              MOVB   (R0),R0        ;; GET RIGHT BYTE OF TRAP
7947 034074 006300              ASL     R0            ;; POSITION FOR INDEXING
7948 034076 016000 034116      MOV     $TRPAD(R0),R0 ;; INDEX TO TABLE
7949 034102 000200              RTS     R0            ;; GO TO ROUTINE
7950
7951
7952      ;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
7953
7954 034104 011646      $TRAP2: MOV    (SP),-(SP) ;; MOVE THE PC DOWN
7955 034106 016666 000004 000002  MOV    4(SP),2(SP) ;; MOVE THE PSW DOWN
7956 034114 000002              RTI                    ;; RESTORE THE PSW
7957
7958      .SBTTL TRAP TABLE
7959
7960      ;;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
7961      ;;*BY THE "TRAP" INSTRUCTION.
7962
7963      ; ROUTINE
    
```

7964  
7965 034116 034104  
7966 034120 031326  
7967 034122 032264  
7968 034124 032240  
7969 034126 032300  
7970 034130 032466  
7971  
7972 034132 032762  
7973  
7974 034134 032712  
7975 034136 033174  
7976 034140 030510  
7977 034142 033452  
7978 034144 033510  
7979 034146 027734  
7980 000032  
7981  
7982  
7983  
7984  
7985  
7986  
7987  
7988  
7989  
7990  
7991  
7992  
7993  
7994  
7995  
7996  
7997  
7998  
7999  
8000  
8001 034150 000000 000000 000000  
8002 034156 000000  
8003  
8004  
8005  
8006  
8007  
8008  
8009 034160 000  
8010 034161 000  
8011 034162 000  
8012 034163 000  
8013 034164 000  
8014 034165 000  
8015 034166 000  
8016 034167 000  
8017  
8018  
8019

```

$TRPAD: .WORD $TRAP2
        $TYPE  ;;CALL=TYPE      TRAP+1(104401) TTY TYPEOUT ROUTINE
        $TYPOC ;;CALL=TYPOC     TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
        $TYPOS ;;CALL=TYPOS     TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
        $TYPON ;;CALL=TYPON     TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
        $TYPDS ;;CALL=TYPDS     TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)

        $GTSWR ;;CALL=GTSWR     TRAP+6(104406) GET SOFT-SWR SETTING

        $CKSWR ;;CALL=CKSWR     TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
        $RDCHR ;;CALL=RDCHR     TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
        $RDLIN ;;CALL=RDLIN     TRAP+11(104411) TTY TYPEIN STRING ROUTINE
        $SAVREG ;;CALL=SAVREG    TRAP+12(104412) SAVE R0-R5 ROUTINE
        $RESREG ;;CALL=RESREG    TRAP+13(104413) RESTORE R0-R5 ROUTINE
        $SDPLY  ;;CALL=DISPLY    TRAP+14(104414) ROUTINE TO TYPE ERROR MESSAGES

$TERM=. -$TRPAD
```

;;\*\*\*\*\*

.SBTTL SINGLE/DUAL PORT RH70/RMO3 DRIVER (REV 1.0)

;COPYRIGHT (C) 1976  
;DIGITAL EQUIPMENT CORP.  
;MAYNARD, MA 01754  
;AUTHOR(S): JIM LACEY/CHUCK HESS/C. CHEN

;;\*\*\*\*\*

;STORAGE FOR RMDS, RMER1, RMER2, AND RMMR2 ON AN ERROR "2"

```

;RMERRS = RMDS
;RMERRS+2 = RMER1
;RMERRS+4 = RMER2
;RMERRS+6 = RMMR2
```

RMERRS: .WORD 0,0,0,0

;TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=8 BYTES)

```

;DRVACT=0 IF DRIVE IS IDLE
;DRVACT>0 IF DRIVE IS ACTIVE WITH A COMMAND
;DRVACT<0 IF DRIVE IS ACTIVE WITH AN ERROR RECOVERY OPERATION
```

```

DRVACT: .BYTE 0 ;DRIVE 0
        .BYTE 0 ;DRIVE 1
        .BYTE 0 ;DRIVE 2
        .BYTE 0 ;DRIVE 3
        .BYTE 0 ;DRIVE 4
        .BYTE 0 ;DRIVE 5
        .BYTE 0 ;DRIVE 6
        .BYTE 0 ;DRIVE 7
```

;TABLE OF DRIVE STATUS INDICATORS (DRVSTA=8 BYTES)  
;DRVSTA=0 IF DRIVE IS OFFLINE OR NONEXISTENT

```

8020                                     ;DRVSTA>0 IF DRIVE IS ONLINE
8021                                     ;DRVSTA<0 IF DRIVE IS UNSAFE
8022
8023 034170      000      DRVSTA: .BYTE 0          ;DRIVE 0
8024 034171      000      .BYTE 0          ;DRIVE 1
8025 034172      000      .BYTE 0          ;DRIVE 2
8026 034173      000      .BYTE 0          ;DRIVE 3
8027 034174      000      .BYTE 0          ;DRIVE 4
8028 034175      000      .BYTE 0          ;DRIVE 5
8029 034176      000      .BYTE 0          ;DRIVE 6
8030 034177      000      .BYTE 0          ;DRIVE 7
8031
8032                                     ;TABLE OF DRIVE TYPES (DRVTP=8 BYTES)
8033                                     ;DRVTP=0 IF DRIVE IS NONEXISTENT (DRVSTA=0, ALSO)
8034                                     ;DRVTP=4 IF DRIVE IS RMO3
8035                                     ;DRVTP=-1 IF NOT RMO3
8036
8037 034200      000      DRVTP: .BYTE 0          ;DRIVE 0
8038 034201      000      .BYTE 0          ;DRIVE 1
8039 034202      000      .BYTE 0          ;DRIVE 2
8040 034203      000      .BYTE 0          ;DRIVE 3
8041 034204      000      .BYTE 0          ;DRIVE 4
8042 034205      000      .BYTE 0          ;DRIVE 5
8043 034206      000      .BYTE 0          ;DRIVE 6
8044 034207      000      .BYTE 0          ;DRIVE 7
8045
8046                                     ;TABLE OF DUAL PORT INITIALIZATION INDICATORS
8047                                     ;DPINT=0 IF INITIALIZATION IS NOT ACTIVE ON THE DRIVE
8048                                     ;DPINT<0 IF INITIALIZATION IS IN PROGRESS
8049
8050 034210      000      DPINT: .BYTE 0          ;DRIVE 0
8051 034211      000      .BYTE 0          ;DRIVE 1
8052 034212      000      .BYTE 0          ;DRIVE 2
8053 034213      000      .BYTE 0          ;DRIVE 3
8054 034214      000      .BYTE 0          ;DRIVE 4
8055 034215      000      .BYTE 0          ;DRIVE 5
8056 034216      000      .BYTE 0          ;DRIVE 6
8057 034217      000      .BYTE 0          ;DRIVE 7
8058
8059                                     ;TABLE OF PENDING DUAL PORT REQUESTS
8060                                     ;DPRQS=0 IF THAT A DUAL PORT REQUEST IS NOT PENDING FOR THAT DRIVE
8061                                     ;DPRQS<0 IF THAT A DUAL PORT REQUEST IS PENDING FOR THAT DRIVE
8062
8063 034220      000      DPRQS: .BYTE 0          ;DRIVE 0
8064 034221      000      .BYTE 0          ;DRIVE 1
8065 034222      000      .BYTE 0          ;DRIVE 2
8066 034223      000      .BYTE 0          ;DRIVE 3
8067 034224      000      .BYTE 0          ;DRIVE 4
8068 034225      000      .BYTE 0          ;DRIVE 5
8069 034226      000      .BYTE 0          ;DRIVE 6
8070 034227      000      .BYTE 0          ;DRIVE 7
8071
8072                                     ;TRANSFER WAIT FLAG (TRNSWT=1 WORD)
8073                                     ;THIS IS A ONE WORD QUEUE. IT WILL CONTAIN THE ADDRESS OF
8074                                     ;"DPB" OF THE I/O OPERATION.
8075
    
```



```

8076 034230 000000      TRNSWT: .WORD 0
8077
8078                      ;SEARCH WAIT KEYS (SRCHWT=1 WORD)
8079                      ;THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF
8080                      ;THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O
8081                      ;REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE.
8082                      ;EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0.
8083
8084 034232 000000      SRCHWT: .WORD 0
8085
8086                      ;RMD3 DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)
8087                      ;ACTDRV=0 IF DRIVER IS INACTIVE
8088                      ;ACTDRV>0 IF DRIVER IS ACTIVE
8089
8090 034234 000         ACTDRV: .BYTE 0
8091
8092                      ;SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
8093                      ;ACTSTR=0 IF SOFTWARE TIMER ROUTINE IS INACTIVE
8094                      ;ACTSTR>0 IF SOFTWARE TIMER ROUTINE IS ACTIVE
8095
8096 034235 000         ACTSTR: .BYTE 0
8097
8098                      ;UNLOAD FLAG (ULDFLG=8 BYTES)
8099                      ;ULDFLG=0 IF NO UNLOAD COMMAND
8100                      ;ULDFLG>0 IF UNLOAD COMMAND IN PROGRESS
8101                      ;ULDFLG<0 IF UNLOAD COMMAND IN WAIT QUEUE
8102
8103 034236 000         ULDFLG: .BYTE 0           ;DRIVE 0
8104 034237 000         .BYTE 0           ;DRIVE 1
8105 034240 000         .BYTE 0           ;DRIVE 2
8106 034241 000         .BYTE 0           ;DRIVE 3
8107 034242 000         .BYTE 0           ;DRIVE 4
8108 034243 000         .BYTE 0           ;DRIVE 5
8109 034244 000         .BYTE 0           ;DRIVE 6
8110 034245 000         .BYTE 0           ;DRIVE 7
8111
8112                      ;LOOK AHEAD COUNT (LACNT=8 BYTES)
8113                      ;LACNT WILL INDICATE THE NUMBER OF LOOK AHEADS PERFORMED
8114
8115 034246 000         LACNT:  .BYTE 0           ;DRIVE 0
8116 034247 000         .BYTE 0           ;DRIVE 1
8117 034250 000         .BYTE 0           ;DRIVE 2
8118 034251 000         .BYTE 0           ;DRIVE 3
8119 034252 000         .BYTE 0           ;DRIVE 4
8120 034253 000         .BYTE 0           ;DRIVE 5
8121 034254 000         .BYTE 0           ;DRIVE 6
8122 034255 000         .BYTE 0           ;DRIVE 7
8123
8124                      ;SAVE REGISTERS FLAG (SAVEFG =1 WORD)
8125                      ;SAVEFG <0 IF SAVE THE RH70/RMD3 REGISTERS WHEN THE
8126                      ;OPERATION IS COMPLETED AS PER (DPB+14).
8127                      ;SAVEFG=0 IF SAVE THE RH70/RMD3 REGISTERS, AS PER
8128                      ;(DPB+14), AFTER AN ERROR.
8129
8130 034256 000000      SAVEFG: .WORD 0
8131
    
```

```

8132 ;SEEK FLAG (SEEKFG=1 WORD)
8133 ;SEEKFG=0 IF WHEN THE DISK ADDRESS ISN'T IN THE WINDOW
8134 ;FOR A DATA TRANSFER START A SEARCH COMMAND
8135 ;SEEKFG<0 IF DATA TRANSFER WILL DO IMPLIED SEEKS,
8136 ;DISREGARD THE WINDOW
8137
8138 034260 177777 SEEKFG: .WORD -1
8139
8140 ;TIMEOUT TABLE (TIMER=8 WORDS)
8141 ;THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION
8142
8143 034262 177777 TIMER: .WORD -1 ;DRIVE 0
8144 034264 177777 .WORD -1 ;DRIVE 1
8145 034266 177777 .WORD -1 ;DRIVE 2
8146 034270 177777 .WORD -1 ;DRIVE 3
8147 034272 177777 .WORD -1 ;DRIVE 4
8148 034274 177777 .WORD -1 ;DRIVE 5
8149 034276 177777 .WORD -1 ;DRIVE 6
8150 034300 177777 .WORD -1 ;DRIVE 7
8151
8152 ;DATA TRANSFER UNDERWAY INDICATOR (DTUW=1 WORD)
8153 ;DTUW<0 IF NO DATA TRANSFER UNDERWAY
8154 ;DTUW=+N (WHERE N=0 TO 7) IMPLIES DATA TRANSFER UNDERWAY ON DRIVE N
8155
8156 034302 177777 DTUW: .WORD -1
8157
8158 ;ATTENTION BITS TABLE (ATABIT=8 BYTES)
8159 ;THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES
8160 ;ATTENTION BIT
8161
8162 034304 001 ATABIT: .BYTE 1 ;DRIVE 0
8163 034305 002 .BYTE 2 ;DRIVE 1
8164 034306 004 .BYTE 4 ;DRIVE 2
8165 034307 010 .BYTE 10 ;DRIVE 3
8166 034310 020 .BYTE 20 ;DRIVE 4
8167 034311 040 .BYTE 40 ;DRIVE 5
8168 034312 100 .BYTE 100 ;DRIVE 6
8169 034313 200 .BYTE 200 ;DRIVE 7
8170
8171 ;FSRMO3 TO RH70 "MASSBUS CONTROL BUS PARITY ERRORS" (MCPE) ALLOWED BEFORE
8172 ;CALLING IT FATAL (MCPEMX=1 WORD)
8173
8174 034314 000003 MCPEMX: .WORD 3
8175
8176 ;STORAGE FOR RMADR (THE FIRST ADDRESS (776700) OF THE RH70/RMO3),
8177 ;RMVEC (THE VECTOR ADDRESS (254)), AND RMVEC+2 (THE BR LEVEL (5)).
8178
8179 034316 176700 RMADR: .WORD 176700
8180 034320 000254 000240 RMVEC: .WORD 254,5*32.
8181
8182 ;MAXIMUM NUMBER OF LOOK AHEADS ALLOWED IS 4 (MXLACT=1 WORD)
8183
8184 034324 000004 MXLACT: .WORD 4
8185 ;MAXIMUM DELTA DELAY IS 8 SECTORS (MXDLTA=1 WORD)
8186
8187 034326 001000 MXDLTA: .WORD 8.*64.
    
```

```

8188 ;MINIMUM DELTA DELAY IS 2 SECTORS (MNDLTA=1 WORD)
8189
8190 034330 000200 MNDLTA: .WORD 2*64.
8191 ;MAXIMUM SEARCH FOR I/O WINDOW IS 5 SECTORS (MXWINDW=1 WORD)
8192
8193 034332 000005 MXWINDW: .WORD 5
8194
8195 ;DEFINITIONS OF THE RH70/RMO3 ADDRESS INDEXES
8196
8197 000000 RMCS1=0 ;CONTROL AND STATUS REGISTER #1 (DRIVE REG. 00)
8198 000002 RMWC=2 ;WORD COUNT REGISTER (NOT A DRIVE REG)
8199 000004 RMBA=4 ;UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
8200 000006 RMDA=6 ;DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG. 05)
8201 000010 RMCS2=10 ;CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
8202 000012 RMDS=12 ;DRIVE STATUS REGISTER (DRIVE REG 01)
8203 000014 RMER1=14 ;ERROR REGISTER #1 (DRIVE REG. 02)
8204 000016 RMAS=16 ;ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG. 04)
8205 000020 RMLA=20 ;LOOK AHEAD REGISTER (DRIVE REG. 07)
8206 000022 RMDB=22 ;DATA BUFFER REGISTER (NOT A DRIVE REG.)
8207 000024 RMMR1=24 ;MAINTAINABILITY REGISTER (DRIVE REG. 03)
8208 000026 RMDT=26 ;DRIVE TYPE REGISTER (DRIVE REG. 06)
8209 000030 RMSN=30 ;SERIAL NUMBER REGISTER (DRIVE REG. 10)
8210 000032 RMOF=32 ;OFFSET REGISTER (DRIVE REG. 11)
8211 000034 RMDC=34 ;DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG. 12)
8212 000036 RMHR=36 ;DUMMY ADDRESS REGISTER (DRIVE REG. 13)
8213 000040 RMMR2=40 ;MAINTENANCE REGISTER #2
8214 000042 RMER2=42 ;ERROR REGISTER #2 (DRIVE REG. 15)
8215 000044 RMEC1=44 ;ECC POSITION REGISTER (DRIVE REG. 16)
8216 000046 RMEC2=46 ;ECC PATTERN REGISTER (DRIVE REG. 17)
8217
8218 ;RH70/RMO3 DRIVER INITIALIZATION CODE
8219 ;THIS ROUTINE WILL DETERMINE WHICH RMO3 DRIVES ARE
8220 ;AVAILABLE FOR TESTING AND SET THE DRVSTA INDICATOR
8221 ;TO THE PROPER STATE FOR EACH DRIVE.
8222 ;NOTE: THIS ROUTINE CALLS DRVINT
8223
8224 ;CALL
8225
8226 ; JSR PC,RMINIT
8227 ; RETURN
8228
8229 ;NOTE: THE 'P' OR 'L' CLOCK MUST BE STARTED
8230
8231 034334 104412 RMINIT: SAVREG ;SAVE R0 - R5
8232 034336 013746 177776 MOV #PS, -(SP) ;SAVE THE PRESENT PROCESSOR STATUS
8233 034342 012737 000240 177776 MOV #(<5*32.>), #PS ;CHANGE THE PRIORITY TO 5
8234 034350 004737 042230 JSR PC, CLRQUE ;CLEAR ALL REQUEST QUEUES
8235 034354 012701 034150 MOV #RMERRS, R1 ;FIRST ADDRESS TO BE CLEARED
8236 034360 012702 034260 MOV #SEEKFG, R2 ;LAST ADDRESS TO BE CLEARED
8237 034364 005021 1$: CLR (R1)+ ;CLEAR
8238 034366 020102 CMP R1, R2 ;ARE WE DONE?
8239 034370 103775 BLO 1$ ;BRANCH IF NO
8240 034372 012702 034302 MOV #DTUM, R2 ;LAST ADDRESS
8241 034376 012721 177777 2$: MOV #-1, (R1)+ ;INITIALIZE
8242 034402 020102 CMP R1, R2 ;DONE?
8243 034404 101774 BLOS 2$ ;LOOP IF NO

```

```

8244 034406 005037 034170          CLR    DRVSTA          ;SET ALL DRIVES TO OFFLINE
8245 034412 005037 034172          CLR    DRVSTA+2
8246 034416 005037 034174          CLR    DRVSTA+4
8247 034422 005037 034176          CLR    DRVSTA+6
8248 034426 013703 034320          MOV    RMVEC,R3        ;SETUP THE RH70/RMO3 VECTOR
8249 034432 012723 037122          MOV    #ISR,(R3)+
8250 034436 013713 034322          MOV    RMVEC+2,(R3)
8251 034442 013704 034316          MOV    RMADR,R4        ;FIRST ADDRESS OF RH70/RMO3
8252 034446 012764 000040 000010  MOV    #BIT05,RMCS2(R4) ;MASSBUS INIT
8253 034454 005001                    CLR    R1              ;START WITH DRIVE 0
8254 034456 004037 034546          JSR    RO,DRVINT       ;INIT THE DRIVE
8255 034462 000401                    BR     4$              ;'DVA' NOT SET OR PARITY ERROR
8256 034464 000402                    BR     5$              ;NORMAL RETURN
8257 034466 105061 034170          CLRB  DRVSTA(R1)       ;SET DRIVE STATUS TO OFFLINE
8258 034472 005201                    INC    R1              ;GO TO NEXT DRIVE
8259 034474 042701 177770          BIC   #1C7,R1         ;MASK OUT UNUSED BITS
8260 034500 001366                    BNE   3$              ;BR IF MORE DRIVES TO GO
8261 034502 012701 000007          MOV    #7,R1          ;START WITH DRIVE 7
8262 034506 005037 177776          CLR   2#PS            ;CLEAR THE PROCESSOR STATUS
8263 034512 105761 034210          TSTB  DPINT(R1)       ;WAITING FOR DRIVE TO SWITCH PORTS ?
8264 034516 001405                    BEQ   8$              ;BR NOT WAITING
8265 034520 004737 041664          JSR   PC,SET.IE       ;SET INTERRUPT
8266 034524 105761 034210          TSTB  DPINT(R1)       ;DRIVE SWITCHED PORTS ?
8267 034530 001375                    BNE   7$              ;BR IF NOT
8268 034532 005301                    DEC   R1              ;GO TO THE NEXT DRIVE
8269 034534 100366                    BPL   6$              ;CHECK NEXT DRIVE
8270 034536 012637 177776          MOV    (SP)+,2#PS     ;RESTORE THE PROCESSOR STATUS
8271 034542 104413                    RESREG ;RESTORE RO - R5
8272 034544 000207                    RTS   PC              ;BYE-BYE
8273
8274
8275 ;DRIVE INITIALIZATION ROUTINE
8276 ;THIS ROUTINE DETERMINES IF A DRIVE EXIST AND IF IT IS
8277 ;AN RMO3. IF IT IS, A "READ-IN PRESET" IS ISSUED AND FMT22
8278 ;IS SET TO A "1". THEN MOL, DPR, DRY, AND VV ARE CHECKED TO
8279 ;INSURE THEY ARE ALL ON A "1". AND DEPENDING ON THEIR STATE,
8280 ;DRVSTA IS SET TO THE PROPER CONDITION.
8281 ;CALL
8282 :
8283 :
8284 :
8285 :
8286 :
8287 :
8288 034546 010546          DRVINT: MOV    R5,-(SP)      ;SAVE R5
8289 034550 105061 034170  DULP:  CLRB  DRVSTA(R1) ;START DRIVE STATUS AS OFFLINE
8290 034554 105061 034200          CLRB  DRVSTYP(R1)    ;CLEAR THE DRIVE TYPE INDICATOR
8291 034560 105061 034236          CLRB  ULDFLG(R1)     ;CLEAR THE UNLOAD FLAG
8292 034564 010164 000010          MOV    R1,RMCS2(R4) ;SELECT A DRIVE
8293 034570 112764 000111 000000  MOVB  #11,RMCS1(R4) ;DO A DRIVE CLEAR COMMAND (& SEIZE DRIVE)
8294 034576 032764 010000 000010  BIT   #BIT12,RMCS2(R4) ;NONEXISTENT DRIVE?
8295 034604 001403                    BEQ   1$              ;NO---BRANCH
8296 034606 004737 041664          JSR   PC,SET.IE       ;GO SET "IE" WITHOUT A "TRE"
8297 034612 000476                    BR     6$              ;LEAVE THIS ROUTINE
8298 034614 105061 034170          CLRB  DRVSTA(R1)     ;SET DRIVE STATUS TO OFFLINE
8299 034620 032764 004000 000000  BIT   #BIT11,RMCS1(R4) ;SEE IF DRIVE AVAILABLE

```

M12

```

8300 034626 001750          BEQ      DULP          ;BR IF DRIVE NOT AVAILABLE
8301 034630 004037 041204   JSR      RO,RO.RM     ;READ THE DRIVE TYPE REG.
8302 034634 000026          RMDT
8303 034636 035034          BS
8304 034640 012605          MOV      (SP)+,R5     ;ERROR RETURN ADDRESS
8305 034642 112761 000004 034200  MOVB     #4,DRVSTYP(R1) ;PUT DRIVE TYPE IN R5
8306 034650 022705 020024   CMP      #20024,R5    ;SET RMD3 INDICATOR
8307 034654 001407          BEQ      2$           ;SINGLE PORT RMD3 ?
8308 034656 022705 024024   CMP      #24024,R5    ;BR IF YES
8309 034662 001404          BEQ      2$           ;DUAL PORT RMD3 ?
8310 034664 112761 177777 034200  MOVB     #-1,DRVSTYP(R1) ;BR IF YES
8311 034672 000446          BR
8312 034674 012746 000121 2$:   MOV      #121,-(SP)    ;SET INDICATOR TO 'OTHER'
8313 034700 004037 041360   JSR      RO,WRT.RM    ;EXIT
8314 034704 000000          RMCS1
8315 034706 035034          BS
8316 034710 012746 010000   MOV      #BIT12,-(SP) ;DO A "READ-IN PRESET"
8317 034714 004037 041360   JSR      RO,WRT.RM
8318 034720 000032          RMOF
8319 034722 035034          BS
8320 034724 004037 041204   JSR      RO,RO.RM     ;READ RMD3
8321 034730 000012          RMD3
8322 034732 035034          BS
8323 034734 012605          MOV      (SP)+,R5     ;AND SAVE IT IN R5
8324 034736 100015          BPL      4$           ;BRANCH IF ATA=0
8325 034740 116164 034304 000016  MOVB     ATABIT(R1),RMAS(R4) ;CLEAR ATTENTION BIT
8326 034746 004037 041204   JSR      RO,RO.RM     ;FIND OUT WHY ATA=1
8327 034752 000014          RMER1
8328 034754 035034          BS
8329 034756 006126          ROL      (SP)+        ;IS IT UNSAFE?
8330 034760 100004          BPL      4$           ;BR IF NOT
8331 034762 112761 177777 034170  MOVB     #-1,DRVSTA(R1) ;SET UNSAFE INDICATOR
8332 034770 000407          BR
8333 034772 005105          COM      R5           ;EXIT
8334 034774 042705 167077 4$:   BIC      #1<BIT12!BIT08!BIT07!BIT06>,R5 ;CHECK MOL, DPR, DRY, AND VV
8335 035000 001003          BNE      6$           ;BRANCH IF MOL, DPR, DRY, OR VV IS CLEAR
8336 035002 112761 000001 034170  MOVB     #1,DRVSTA(R1) ;SET DRIVE STATUS TO ONLINE
8337 035010 005720          TST      (R0)+        ;STEP OVER THE ERROR RETURN
8338 035012 000410          BR
8339 035014 006301          ASL      R1           ;EXIT
8340 035016 012761 003720 034262 7$:   MOV      #2000.,TIMER(R1) ;CHANGE INDEX TO ADDRESS WORDS
8341 035024 006201          ASR      R1           ;START 2 SEC TIMER
8342 035026 112761 177777 034210  MOVB     #-1,DPINT(R1) ;RESTORE R1
8343 035034 012605          MOV      (SP)+,R5     ;SET PORT INITIALIZE INIDICATOR
8344 035036 000200          RTS      RO           ;RESTORE R5
8345                                     ;EXIT
8346                                     ;REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
8347                                     ;CALL
8348                                     ;
8349                                     ;
8350                                     ;
8351                                     ;
8352                                     ;
8353                                     ;
8354                                     ;
8355                                     ;
      JSR      RO,#RMD3 ;CALL THE RMD3 DRIVER
      PNTADR ;ADDRESS OF POINTER OF DRIVES PARAMETER BLOCK
      RETURN1 ;RETURN HERE IF QUEUE IS FULL
      RETURN2 ;RETURN HERE IF REQUEST IS IN QUEUE OR THERE
      ;IS AN ERROR CONDITION
    
```

8356	035040	013746	177776		RMD3:	MOV	2#PS, -(SP)	;SAVE THE CALLING STATUS
8357	035044	013737	034322	177776		MOV	RMVEC+2, 2#PS	;DON'T ALLOW ANY RMD3 INTERRUPTS
8358	035052	112737	000001	034234		MOV	#1, ACTDRV	;SET "ACTIVE DRIVER" FLAG
8359	035060	104412				SAVREG		;SAVE R0 - R5
8360	035062	011002				MOV	(R0), R2	;PICKUP THE DRIVE PARAMETER BLOCK POINTER
8361	035064	005062	000016			CLR	16(R2)	;CLEAR THE STATUS/ERROR INDICATOR
8362	035070	111201				MOV	(R2), R1	;PICKUP THE DRIVE NUMBER
8363	035072	013704	034316			MOV	RMADR, R4	;UNIBUS ADDRESS OF RMCS1
8364	035076	105761	034170			TSTB	DRVSTA(R1)	;CHECK DRIVES STATUS
8365	035102	003014				BGT	1\$	;BRANCH IF ONLINE
8366	035104	105761	034236			TSTB	ULDFLG(R1)	;UNLOAD COMMAND IN QUEUE?
8367	035110	001036				BNE	3\$	;BRANCH IF YES
8368	035112	105761	034210			TSTB	DPINT(R1)	;TRYING TO INIT THE DRIVE
8369	035116	001042				BNE	5\$	;BR IF YES
8370	035120	004037	034546			JSR	R0, DRVINT	;GO INIT. THE DRIVE
8371	035124	000434				BR	4\$	;ERROR RETURN
8372	035126	105761	034170			TSTB	DRVSTA(R1)	;IS DRIVE STATUS ONLINE?
8373	035132	003445				BLE	6\$	;BR IF NOT
8374	035134	105761	034220		1\$:	TSTB	DPRQS(R1)	;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
8375	035140	001031				BNE	5\$	;BR IF YES
8376	035142	010164	000010			MOV	R1, RMCS2(R4)	;SELECT THE DRIVE
8377	035146	004037	042326			JSR	R0, DRVQUE	;PUT THIS REQUEST IN QUEUE
8378	035152	000460				BR	9\$	;QUEUE IS FULL
8379	035154	122762	000103	000002		CMPB	#103, 2(R2)	;IS THIS REQ. FOR AN UNLOAD?
8380	035162	001003				BNE	2\$	;BR IF NO
8381	035164	112761	177777	034236		MOV	#-1 ULDFLG(R1)	;SET THE "UNLOAD IN QUEUE" FLAG
8382	035172	105761	034160		2\$:	TSTB	DRVACT(R1)	;IS THIS DRIVE ACTIVE?
8383	035176	001043				BNE	8\$	;BR IF YES
8384	035200	004737	035332			JSR	PC, OPT	;CALL THE OPTIMIZER
8385	035204	000440				BR	8\$	
8386	035206	012762	120000	000016	3\$:	MOV	#BIT15:BIT13, 16(R2)	;SET THE "UNLOAD IN QUEUE" ERROR FLAG
8387	035214	000434				BR	8\$	;EXIT
8388	035216	004737	036412		4\$:	JSR	PC, CI7	;GO HANDLE THE PARITY ERROR
8389	035222	000431				BR	8\$	
8390	035224	004037	042326		5\$:	JSR	R0, DRVQUE	;PUT REQUEST IN QUEUE
8391	035230	000431				BR	9\$	;QUEUE IS FULL
8392	035232	032714	000100			BIT	#BIT06, (R4)	;IE BIT SET ?
8393	035236	001023				BNE	8\$	;YES
8394	035240	004737	041664			JSR	PC, SET.IE	;SET THE INTERRUPT
8395	035244	000420				BR	8\$	;RETURN
8396	035246	105761	034170		6\$:	TSTB	DRVSTA(R1)	;SEE IF DRIVE OFFLINE OR UNSAFE
8397	035252	002412				BLT	7\$	;BR IF UNSAFE
8398	035254	012762	140000	000016		MOV	#BIT15:BIT14, 16(R2)	;SET OFFLINE ERROR INDICATOR
8399	035262	105761	034200			TSTB	DRVSTP(R1)	;SEE IF OFFLINE OR NONEXISTENT
8400	035266	001007				BNE	8\$	;BR IF OFFLINE
8401	035270	012762	100002	000016		MOV	#BIT15:BIT01, 16(R2)	;REPORT DRIVE NONEXISTENT
8402	035276	000403				BR	8\$	;GO TO EXIT
8403	035300	012762	110000	000016	7\$:	MOV	#BIT15:BIT12, 16(R2)	;DRIVE IS UNSAFE
8404	035306	104413			8\$:	RESREG		;RESTORE R0 - R5
8405	035310	005720				TST	(R0)+	;SETUP FOR NORMAL RETURN
8406	035312	000401				BR	10\$	;FINISH UP, THEN EXIT
8407	035314	104413			9\$:	RESREG		;RESTORE R0 - R5
8408	035316	005720			10\$:	TST	(R0)+	;CORRECT THE RETURN ADDRESS
8409	035320	105037	034234			CLRB	ACTDRV	;CLEAR "ACTIVE DRIVER" FLAG
8410	035324	012637	177776			MOV	(SP)+, 2#PS	;RETURN "PS" TO USER LEVEL
8411	035330	000200				RTS	R0	;RETURN TO CALLER

```

8412
8413
8414
8415
8416
8417
8418
8419 035332 104412
8420 035334 013746 177776
8421 035340 146137 034304 034232
8422 035346 105061 034220
8423 035352 004737 042402
8424 035356 005702
8425 035360 001472
8426 035362 010164 000010
8427 035366 012764 000111 000000
8428 035374 032764 004000 000000
8429 035402 001446
8430 035404 105761 034170 10$:
8431 035410 003014
8432 035412 004737 042424
8433 035416 012762 140000 000016
8434 035424 105761 034170
8435 035430 100053
8436 035432 012762 110000 000016
8437 035440 000447
8438 035442 1$:
8439
8440
8441
8442
8443
8444
8445 035442 122762 000150 000002
8446 035450 002403
8447 035452 004737 035776
8448 035456 000440
8449 035460 005737 034302 2$:
8450 035464 002012
8451 035466 005737 034260
8452 035472 100404
8453 035474 004037 036746
8454 035500 000427
8455 035502 000403
8456 035504 004737 035570 3$:
8457 035510 000423
8458 035512 004737 035676 4$:
8459 035516 000420
8460 035520 112761 177777 034220 5$:
8461 035526 010103
8462 035530 006303
8463 035532 012763 023420 034262
8464 035540 000402
8465 035542 004737 036412 6$:
8466 035546 032714 000100 7$:
8467 035552 001002
;OPTIMIZER-CALLED FOR A PARTICULAR DRIVE
;CALL
;MOV #DRVNUM,R1 ;DRIVE NUMBER TO R1
;JSR PC,OPT ;SETUP A COMMAND
OPT:
;SAVREG ;SAVE R0 - R5
;MOV #PS,-(SP) ;SAVE PROC. STATUS
;BICB ATABIT(R1),SRCHWT ;CLEAR LA SEARCH FLAG
;CLRB DPRQS(R1) ;RESET THE PORT REQ FLAG ****
;JSR PC,GETREQ ;GET "DPB" POINTER OF REQUEST
;TST R2 ;IS THERE A REQUEST IN QUEUE?
;BEQ 7$ ;NO--BRANCH TO EXIT
;MOV R1, RMCS2(R4) ;LOAD THE DRIVE ADDRESS *****
;MOV #11, RMCS1(R4) ;CLEAR THE DRIVE
;BIT #BIT11, RMCS1(R4) ;DVA SET ?
;BEQ 5$ ;TO PROT REQUEST, IF NOT
;TSTB DRVSTA(R1) ;IS DRIVE ONLINE?
;BGT 1$ ;YES--BRANCH
;JSR PC,POPQUE ;NO--REMOVE REQUEST FROM QUEUE
;MOV #BIT15:BIT14,16(R2) ;SET OFFLINE STATUS/ERROR INDICATOR
;TSTB DRVSTA(R1) ;IS DRIVE UNSAFE ?
;BPL 8$ ;BR TO EXIT IF NOT
;MOV #BIT15:BIT12,16(R2) ;SET UNSAFE STATUS/ERROR INDICATOR
;BR 8$ ;BRANCH TO EXIT
1$:
;MOV #11,-(SP) ;LOAD COMMAND ONTO THE STACK
;JSR RO,WRT.RM ;LOAD THE REGISTER
;RMCS1 ;REGISTER INCREMENT
;6$ ;ERROR RETURN ADDRESS
;BIT #BIT11,(R4) ;DRIVE AVAILABLE ?
;BEQ 9$ ;BR IF NOT
;CMPB #150,2(R2) ;IS THE REQUEST FOR I/O?
;BLT 2$ ;YES--BRANCH
;JSR PC,CI4 ;CALL THE COMMAND INITIATOR
;BR 8$ ;BRANCH TO EXIT
;TST DTUW ;DATA TRANSFER UNDERWAY?
;BGE 4$ ;YES--GO START A SEARCH
;TST SEEKFG ;DO IMPLIED SEEKS?
;BMI 3$ ;YES---BRANCH
;JSR RO,LA ;NO--DO LOOK AHEAD
;BR 8$ ;RETURN HERE ON A PARITY ERROR
;BR 4$ ;GO START A SEARCH
;JSR PC,CI1 ;START A DATA TRANSFER
;BR 8$
;JSR PC,CI3 ;START A SEARCH
;BR 8$ ;GO TO THE EXIT
;MOVB #-1,DPRQS(R1) ;SET PORT REQUEST INDICATOR
;MOV R1,R3 ;SET UP TO ADDRESS WORDS
;ASL R3 ;CONVERT TO WORD INDEX
;MOV #10000.,TIMER(R3) ;START 10 SEC TIMER
;BR 7$ ;EXIT
;JSR PC,CI7 ;PROCESS THE PARITY ERROR
;BIT #BIT06,(R4) ;SEE IF 'IE' ALREADY SET
;BNE 8$ ;BR IF SET
    
```

8468	035554	004737	041664		JSR	PC, SET IE	;SET "IE" WITHOUT A "TRE"
8469	035560	012637	177776		MOV	(SP)+, J#PS	;RESTORE PROC. STATUS
8470	035564	104413		BS:	RESREG		;RESTORE R0 - R5
8471	035566	000207			RTS	PC	
8472							
8473							
8474							
8475							
8476							
8477							
8478							
8479							
8480							
8481							
8482							
8483							
8484	035570	004737	042424		JSR	PC, POPQUE	;REMOVE REQUEST FROM "DRIVES WAIT" QUEUE
8485	035574	010237	034230		MOV	R2, TRNSWT	;PUT REQ. IN TRANSFER WAIT QUEUE
8486	035600	010203			MOV	R2, R3	;DPB ADDRESS TO R3
8487	035602	013704	034316		MOV	RMADR, R4	;RMCS1 ADDRESS
8488	035606	010164	000010		MOV	R1, RMCS2(R4)	;SELECT DRIVE
8489	035612	062703	000004		ADD	#4, R3	;DESIRED WORD COUNT
8490	035616	062704	000002		ADD	#2, R4	;RMC ADDRESS
8491	035622	012324			MOV	(R3)+, (R4)+	;LOAD WORD COUNT
8492	035624	012324			MOV	(R3)+, (R4)+	;LOAD BUFFER ADDRESS
8493	035626	012346			MOV	(R3)+, -(SP)	;LOAD SECTOR AND TRACK
8494	035630	004037	041360		JSR	RO, WRT.RM	;CALL THE LOAD(WRITE) ROUTINE
8495	035634	000006			RMDA		;INDEX OF REGISTER TO LOAD
8496	035636	036412			CI7		;ERROR RETURN ADDRESS
8497	035640	012346			MOV	(R3)+, -(SP)	;LOAD CYLINDER ADDRESS
8498	035642	004037	041360		JSR	RO, WRT.RM	
8499	035646	000034			RMDC		
8500	035650	036412			CI7		
8501	035652	016246	000002		MOV	2(R2), -(SP)	;LOAD "COMMAND+GO", "A17&A16", AND "PSEL"
8502	035656	004037	041360		JSR	RO, WRT.RM	
8503	035662	000000			RMCS1		
8504	035664	036412			CI7		
8505	035666	010137	034302		MOV	R1, DTUW	;SET "DATA TRANSFER UNDERWAY"
8506	035672	000137	036354		JMP	CI5	
8507	035676	013704	034316		MOV	RMADR, R4	;RMCS1 ADDRESS
8508	035702	010164	000010		MOV	R1, RMCS2(R4)	;SELECT DRIVE
8509	035706	016246	000012		MOV	12(R2), -(SP)	;DESIRED CYLINDER ADDRESS
8510	035712	004037	041360		JSR	RO, WRT.RM	
8511	035716	000034			RMDC		
8512	035720	036412			CI7		
8513	035722	116203	000010		MOV	10(R2), R3	;PICKUP SECTOR ADDRESS
8514					SUB	MXWINDW, R3	;BACKUP BY MAX. SEARCH FOR I/O WINDOW
8515					BGE	1\$	
8516					ADD	#32, R3	
8517	035726	010346			MOV	R3, -(SP)	;COMBINE THE ADJUSTED SECTOR WITH
8518	035730	042716	177740		BIC	#177740, (SP)	;CHOP OF ALL EXENTED BITS, IF ANY
8519	035734	116266	000011	000001	MOV	11(R2), 1(SP)	;THE DESIRED TRACK
8520	035742	004037	041360		JSR	RO, WRT.RM	;LOAD DESIRED TRACK & SECTOR
8521	035746	000006			RMDA		
8522	035750	036412			CI7		
8523	035752	012746	000131		MOV	#131, -(SP)	;START A SEARCH

;COMMAND INITIATOR

;CALL

CI1:

CI3:

1\$:



8524	035756	004037	041360		JSR	RO,WRT.RM	
8525	035762	000008			RMCS1		
8526	035764	036412			CI7		
8527	035766	156137	034304	034232	BISB	ATABIT(R1),SRCHWT	;SET "SEARCH WAIT" KEY
8528	035774	000567			BR	CI5	
8529	035776	013704	034316		MOV	RMAOR,R4	;RMCS1 ADDRESS
8530	036002	010164	000010		MOV	R1,RMCS2(R4)	;SELECT DRIVE
8531	036006	116203	000002		MOVB	2(R2),R3	;PICKUP THE REQUESTED COMMAND
8532	036012	122703	000131		CMPB	#131,R3	;IS IT A SEARCH COMMAND?
8533	036016	001007			BNE	1\$	;BRANCH IF NO
8534	036020	016246	000010		MOV	10(R2),-(SP)	;LOAD DESIRED TRACK & SECTOR
8535	036024	004037	041360		JSR	RO,WRT.RM	
8536	036030	000006			RMDA		
8537	036032	036412			CI7		
8538	036034	000403			BR	2\$	;GO LOAD CYLINDER
8539	036036	122703	000105		CMPB	#105,R3	;IS IT A SEEK COMMAND
8540	036042	001007			BNE	3\$	;BRANCH IF NO
8541	036044	016246	000012		MOV	12(R2),-(SP)	;LOAD DESIRED CYLINDER
8542	036050	004037	041360		JSR	RO,WRT.RM	
8543	036054	000034			RMDC		
8544	036056	036412			CI7		
8545	036060	000546			BR	CI6	
8546	036062	122703	000115		CMPB	#115,R3	;IS IT AN "OFFSET" COMMAND?
8547	036066	001013			BNE	4\$	;BR IF NO
8548	036070	004037	041204		JSR	RO,RO.RM	;MERGE THE OFFSET VALUE INTO RMOF
8549	036074	000032			RMOF		;BUT DON'T CHANGE THE UPPER
8550	036076	036412			CI7		
8551	036100	116216	000001		MOVB	1(R2),(SP)	;BYTE WHEN LOADING THE
8552	036104	004037	041360		JSR	RO,WRT.RM	;REGISTER (RMOF)
8553	036110	000032			RMOF		
8554	036112	036412			CI7		
8555	036114	000530			BR	CI6	;GO START THE COMMAND
8556	036116	122703	000107		CMPB	#107,R3	;IS IT A "RECALIBRATE" COMMAND?
8557	036122	001525			BEQ	CI6	;BRANCH IF YES
8558	036124	122703	000117		CMPB	#117,R3	;IS IT A RETURN TO CENTER?
8559	036130	001522			BEQ	CI6	;BRANCH IF YES
8560	036132	122703	000103		CMPB	#103,R3	;IS IT AN "UNLOAD" COMMAND?
8561	036136	001016			BNE	5\$	;BRANCH IF NO
8562	036140	112761	000001	034160	MOVB	#1,DRVACT(R1)	;SET THE DRIVE ACTIVE INDICATOR
8563	036146	105061	034170		CLRB	DRVSTA(R1)	;PUT DRIVE STATUS TO OFFLINE
8564	036152	112761	000001	034236	MOVB	#1,ULDFLG(R1)	;SET "UNLOAD IN PROGRESS" FLAG
8565	036160	010346			MOV	R3,-(SP)	;START THE "UNLOAD" COMMAND
8566	036162	004037	041360		JSR	RO,WRT.RM	
8567	036166	000000			RMCS1		
8568	036170	036412			CI7		
8569	036172	000207			RTS	PC	;RETURN TO USER
8570	036174	122703	000143		CMPB	#143,R3	;IS IT A "SET FORMAT" COMMAND?
8571	036200	001014			BNE	6\$	;BRANCH IF NO
8572	036202	004037	041204		JSR	RO,RO.RM	;READ THE OFFSET REGISTER
8573	036206	000032			RMOF		
8574	036210	036412			CI7		
8575	036212	116266	000001	000001	MOVB	1(R2),1(SP)	;COMBINE "FMT22", "ECI", AND "HCI"
8576	036220	004037	041360		JSR	RO,WRT.RM	;LOAD "FMT22", "ECI", AND/OR "HCI".
8577	036224	000032			RMOF		
8578	036226	036412			CI7		
8579	036230	000436			BR	12\$	

# E13

MD-11-DZRMBA AO/00 RMO3 PERFORMANCE EXERCISER MACY11 30(1046) 27-JUL-77 08:07 PAGE 160  
 DZRMBA.P11 27-JUL-77 08:04 SINGLE/DUAL PORT RH70/RMO3 DRIVER (REV 1.0)

SEQ 0159

8580	036232	122703	000141		6S:	CMPB	#141,R3	; IS IT A "GET REGISTER" COMMAND?
8581	036236	001023				BNE	10S	; BRANCH IF NO
8582	036240	016203	000006		7S:	MOV	6(R2),R3	; POINTS TO 1ST ADDRESS OF WHERE
8583								; TO PUT THE REGISTER(S)
8584	036244	116237	000010	036262		MOVB	10(R2),9S	; INIT. THE INDEX FOR THE FIRST REG.
8585	036252	116205	000011			MOVB	11(R2),R5	; INDEX OF LAST REG. TO MOVE
8586	036256	004037	041204		8S:	JSR	RO,RO.RM	; READ RH70/RMO3 REGISTER
8587	036262	000000			9S:	RMCS1		; INDEX OF REG. TO READ
8588	036264	036412				CI7		
8589	036266	012623				MOV	(SP)+,(R3)+	; GET THE CONTENTS OF RH70//RMO3 REG.
8590	036270	023705	036262			CMP	9S,R5	; LAST REG. BEEN READ?
8591	036274	001414				BEQ	12S	; GET OUT IF YES
8592	036276	062737	000002	036262		ADD	#2,9S	; INCREASE THE INDEX BY 2
8593	036304	000764				BR	8S	; LOOP--MORE TO READ
8594	036306	122703	000145		10S:	CMPB	#145,R3	; IS IT A "SELECT DRIVE" COMMAND?
8595	036312	001405				BEQ	12S	; BRANCH IF YES
8596	036314	010346			11S:	MOV	R3,-(SP)	; LOAD THE COMMAND
8597	036316	004037	041360			JSR	RO,WRT.RM	
8598	036322	000000				RMCS1		
8599	036324	036412				CI7		
8600	036326	004737	042424		12S:	JSR	PC,POPQUE	; REMOVE REG. FROM QUEUE
8601	036332	052762	000200	000016		BIS	#BIT07,16(R2)	; SET THE "DONE" BIT
8602	036340	005737	034256			TST	SAVEFG	; SAVE THE RH70/RMO3 REGISTERS?
8603	036344	100002				BPL	13S	; BRANCH IF NO
8604	036346	004737	041546			JSR	PC,SVRH70	; YES--GO SAVE THE REGISTERS
8605	036352	000207			13S:	RTS	PC	; RETURN TO USER
8606	036354	006301			CI5:	ASL	R1	
8607	036356	012761	001750	034262		MOV	#1000.,TIMER(R1)	; SET A ONE SECOND TIMER
8608	036364	006201				ASR	R1	
8609	036366	112761	000001	034160		MOVB	#1,DRVACT(R1)	; SET THE DRIVE ACTIVE
8610	036374	000207				RTS	PC	; RETURN TO THE USER
8611	036376	010346			CI6:	MOV	R3,-(SP)	; LOAD THE COMMAND
8612	036400	004037	041360			JSR	RO,WRT.RM	
8613	036404	000000				RMCS1		
8614	036406	036412				CI7		
8615	036410	000761				BR	CI5	
8616	036412	032764	010000	000010	CI7:	BIT	#BIT12,RMCS2(R4)	; DRIVE NON-EXISTENT ?
8617	036420	001034				BNE	CI8	; BR IF YES
8618	036422	005702			1S:	TST	R2	; ANYTHING IN QUEUE ?
8619	036424	001405				BEQ	CI7B	; BR IF NOT
8620	036426	012762	104000	000016		MOV	#BIT15:BIT11,16(R2)	; SET "PARITY" ERROR INDICATOR
8621	036434	004737	041546			JSR	PC,SVRH70	; GO SAVE THE RH70/RMO3 REGISTERS
8622	036440	012746	000111		CI7B:	MOV	#111,-(SP)	; DO A "DRIVE CLEAR"
8623	036444	004037	041360			JSR	RO,WRT.RM	
8624	036450	000000				RMCS1		
8625	036452	036512				CI8		
8626	036454	004737	042306			JSR	PC,EMPTYQ	; EMPTY THE QUEUE
8627	036460	105061	034236			CLRB	ULDFLG(R1)	; CLEAR THE UNLOAD IN QUEUE FLAG
8628	036464	105061	034160			CLRB	DRVACT(R1)	; DRIVE IS IDLE
8629	036470	020137	034302			CMP	R1,DTUW	; IF THIS DRIVE HAD AN I/O REQUEST
8630	036474	001005				BNE	1S	; IN PROGRESS CLEAR ALL OF THE FLAGS
8631	036476	005037	034230			CLR	TRNSWT	
8632	036502	012737	177777	034302		MOV	#-1,DTUW	
8633	036510	000207			1S:	RTS	PC	
8634	036512	104412			CI8:	SAVREG		; SAVE RO - R5
8635	036514	032764	010000	000010		BIT	#BIT12,RMCS2(R4)	; IS 'NED' SET ?

```

8636 036522 001002          BNE      1$          ;BR IF YES
8637 036524 005001          CLR      R1
8638 036526 005003          CLR      R3
8639 036530 105761 034160  1$:  TSTB    DRVACT(R1)  ;DRIVE ACTIVE?
8640 036534 001443          BEQ      5$          ;BRANCH IF NO
8641 036536 013702 034230  MOV      TRNSWT,R2  ;GET THE "TRANSFER WAIT" QUEUE
8642 036542 020137 034302  CMP      R1,DTUM    ;DID THIS DRIVE HAVE AN I/O IN PROGRESS?
8643 036546 001402          BEQ      2$          ;BRANCH IF YES
8644 036550 004737 042402  JSR      PC,GETREQ  ;GET THE DPB POINTER
8645 036554 005702          TST      R2         ;QUEUE ENTRY FOR DRIVE ?
8646 036556 001415          BEQ      4$          ;BR IF NOT
8647 036560 032764 010000 000010 BIT      #BIT12,RMCS2(R4) ;'NED' SET ?
8648 036566 001404          BEQ      3$          ;BR IF NOT
8649 036570 012762 100002 000016 MOV      #BIT15:BIT01,16(R2) ;SET 'DRIVE NON-EXISTENT' INDICATOR
8650 036576 000405          BR       4$         ;CONTINUE
8651 036600 012762 102000 000016 3$:  MOV      #BIT15:BIT10,16(R2) ;SET "NON-CLEARABLE PARITY" ERROR INDICATOR
8652 036606 004737 041546  JSR      PC,SVRH70  ;SAVE RH70/RM03 REGISTERS
8653 036612 012763 177777 034262 4$:  MOV      #-1,TIMER(R3) ;STOP THE TIMER
8654 036620 105061 034160  CLR      DRVACT(R1) ;SET "DRIVE ACTIVE" TO IDLE
8655 036624 020137 034302  CMP      R1,DTUM    ;IS THIS DRIVE SETUP FOR A TRANSFER
8656 036630 001005          BNE      5$          ;BR IF NOT
8657 036632 012737 177777 034302 MOV      #-1,DTUM   ;RESET THE INDICATOR
8658 036640 005037 034230  CLR      TRNSWT     ;CLEAR THE TRANSFER QUEUE
8659 036644 105061 034236  CLR      ULDFLG(R1) ;CLEAR UNLOAD FLAG
8660 036650 032764 010000 000010 5$:  BIT      #BIT12,RMCS2(R4) ;'NED' SET ?
8661 036656 001021          BNE      6$          ;BR IF YES
8662 036660 005201          INC      R1         ;MOVE TO THE NEXT DRIVE
8663 036662 062703 000002  ADD      #2,R3
8664 036666 042701 177770  BIC      #1<7,R1
8665 036672 001316          BNE      1$          ;BRANCH IF MORE DRIVES
8666 036674 012737 177777 034302 MOV      #-1,DTUM   ;NO DATA TRANSFERS UNDERWAY
8667 036702 005037 034230  CLR      TRNSWT     ;CLEAR THE 'TRANSFER WAIT' QUEUE
8668 036706 004737 042230  JSR      PC,CLRQUE  ;CLEAR ALL OF THE REQUEST QUEUES
8669 036712 012764 000040 000010 MOV      #BIT05,RMCS2(R4) ;DO A MASSBUS INIT.
8670 036720 000406          BR       7$         ;CONTINUE
8671 036722 004737 042306 6$:  JSR      PC,EMPTYQ  ;CLEAR THE DRIVE'S QUEUE
8672 036726 105061 034170  CLR      DRVSTA(R1) ;SET DRIVE TO OFFLINE
8673 036732 105061 034200  CLR      DRVTP(R1)  ;CLEAR THE DRIVE TYPE INDICATOR
8674 036736 004737 041664 7$:  JSR      PC,SET.IE  ;SET "IE" WITHOUT "TRE"
8675 036742 104413  RESREG   ;RESTORE R0 - R5
8676 036744 000207  RTS      PC         ;RETURN
8677
8678 ;LOOK AHEAD ROUTINE
8679 ;CALL
8680 ;
8681 ;   MOV      #DRVNUM,R1  ;DRIVE NUMBER
8682 ;   MOV      #DPB,R2    ;POINT TO DPB
8683 ;   JSR      RO,LA      ;GO CHECK THE WINDOW
8684 ;   RETURN1  ;ERROR RETURN
8685 ;   RETURN2  ;START A SEARCH
8686 ;   RETURN3  ;START A DATA TRANSFER
8687 ;
8688 LA:  MOV      RMADR,R4  ;GET RMCS1'S ADDRESS
8689     MOV      R1,RMCS2(R4) ;SELECT DRIVE
8690     JSR      RO,RO.RM  ;READ DRIVE STATUS
8691

```

8692	036764	037114			4\$		; ERROR RETURN ADDRESS
8693	036766	042716	157577		BIC	#1C020200, (SP)	; ON CYLINDER ?
8694	036772	022726	000200		CMP	#200, (SP)+	; PIP=0, DRY=1?
8695	036776	001044			BNE	3\$	; NO
8696	037000	105261	034246		INCB	LACNT(R1)	; INCREMENT THE LOOK AHEAD COUNT
8697	037004	126137	034246	034324	CMPB	LACNT(R1), MXLACT	; EXCEED MAX?
8698	037012	003033			BGT	2\$	; BRANCH IF YES
8699	037014	116203	000010		MOVB	10(R2), R3	; GET DESIRED SECTOR ADDRESS AND
8700	037020	000303			SWAB	R3	; MULT. BY 64--ALIGN WITH
8701	037022	006203			ASR	R3	; LOOK AHEAD REGISTER
8702	037024	006203			ASR	R3	
8703	037026	012737	000340	177776	MOV	#340, 2#PS	; PRIORITY LEVEL "7"
8704	037034	004037	041204	6\$:	JSR	RD, RD.RM	; READ LOOK AHEAD REGISTER
8705	037040	000020			RMLA		
8706	037042	037114			4\$		
8707	037044	021664	000020		CMP	(SP), RMLA(R4)	; CORRECT LA NUMBER ?
8708	037050	001402			BEQ	7\$	; YES
8709	037052	005726			TST	(SP)+	; NO, CLEAR STACK
8710	037054	000415			BR	3\$	
8711	037056	162603		7\$:	SUB	(SP)+, R3	; CALCULATE THE DELTA
8712	037060	002002			BGE	1\$	
8713	037062	062703	004000		ADD	#(32.*64.), R3	; MAKE THE DELTA POSITIVE
8714	037066	023703	034326	1\$:	CMP	MXDLTA, R3	; CHECK THE DELTA TO SEE
8715	037072	002406			BLT	3\$	; IF IT IS WITHIN THE
8716	037074	023703	034330		CMP	MNDLTA, R3	; WINDOW---IF YES, ZERO
8717	037100	002003			BGE	3\$	; THE LOOK AHEAD COUNT
8718	037102	105061	034246	2\$:	CLRB	LACNT(R1)	; AND TAKE THE I/O EXIT
8719	037106	005720			TST	(RD)+	
8720	037110	005720		3\$:	TST	(RD)+	; ADJUST THE RETURN ADDRESS
8721	037112	000402			BR	5\$	; EXIT
8722	037114	004737	036412	4\$:	JSR	PC, CI7	; PROCESS THE ERROR
8723	037120	000200		5\$:	RTS	RD	; RETURN
8724							
8725							
8726							
8727	037122	112737	000001	034234	ISR:	MOV B #1, ACTDRV	; SET "ACTIVE DRIVER" FLAG
8728	037130	104412			SAVREG		; SAVE RD - R5
8729	037132	013704	034316		MOV	RMADR, R4	; ADDRESS OF RHSCSI
8730	037136	013701	034302		MOV	DTUW, R1	; GET "DATA TRANSFER UNDERWAY" INDICATOR
8731	037142	002403			BLT	1\$	; BRANCH IF NO DATA TRANSFER UNDERWAY
8732	037144	004737	037166		JSR	PC, TD	; CALL TRANSFER DONE
8733	037150	000402			BR	2\$	; EXIT
8734	037152	004737	037442	1\$:	JSR	PC, SC	; CALL SPECIAL CONDITIONS
8735	037156	104413		2\$:	RESREG		; RESTORE RD - R5
8736	037160	105037	034234		CLRB	ACTDRV	; CLEAR "ACTIVE DRIVER" FLAG
8737	037164	000002			RTI		; RETURN
8738							
8739							
8740							
8741	037166	105061	034160		TD:	CLRB DRVACT(R1)	; SET DRIVE ACTIVE INDICATOR TO IDLE
8742	037172	012737	177777	034302	MOV	#-1, DTUW	; NO DATA TRANSFERS UNDERWAY
8743	037200	006301			ASL	R1	
8744	037202	012761	177777	034262	MOV	#-1, TIMER(R1)	; CANCEL TIMEOUT
8745	037210	006201			ASR	R1	
8746	037212	013702	034230		MOV	TRNSWT, R2	; GET "DPB" ADDRESS FROM THE
8747	037216	005037	034230		CLR	TRNSWT	; TRANSFER WAIT QUEUE--CLEAR QUEUE

```

8748 037222 052762 000200 000016      BIS      #BIT07,16(R2)  ;SET DONE
8749 037230 010164 000010      MOV      R1,RMCS2(R4) ;SELECT THE DRIVE
8750 037234 004037 041204      JSR      RO,RD.RM    ;TRANSFER ERROR(TRE=1)?
8751 037240 000000      RMCS1
8752 037242 036412      CI7
8753 037244 006126      ROL      (SP)+
8754 037246 100421      BMI     3$          ;BR IF YES
8755 037250 005737 034256      TST     SAVEFG      ;SAVE THE RH70/RMO3 REGISTERS?
8756 037254 100002      BPL     1$          ;BRANCH IF NO
8757 037256 004737 041546      JSR     PC,SVRH70   ;YES--SAVE THE REGISTERS
8758 037262 004737 037342      1$:    JSR     PC,WC.HK ;SEE IF WRITE CHECK TO BE PUT IN QUEUE
8759 037266 004737 042402      JSR     PC,GETREQ   ;GET DPB POINTER
8760 037272 005702      TST     R2          ;ENTRY FOR DRIVE ?
8761 037274 001403      BEQ     2$          ;BR IF NOT
8762 037276 004737 035332      JSR     PC,OPT      ;CALL OPTIMIZER
8763 037302 000457      BR      SC          ;CHECK OTHER DRIVES
8764                                     ;THE RELEASE DRIVE COMMAND IS FORECD TO ENTER FOR DUAL PORT OPERATION
8765 037304 012714 000113      2$:    MOV     #113,(R4) ;RELEASE THE DRIVE
8766 037310 000454      BR      SC          ;CHECK FOR OTHER DRIVES
8767 037312 052762 100100 000016 3$:    BIS     #BIT15:BIT06,16(R2) ;SET DATA ERROR FLAG
8768 037320 004737 042306      JSR     PC,EMPTYQ   ;EMPTY THE "DRIVE'S WAIT" QUEUE
8769 037324 004737 041546      JSR     PC,SVRH70   ;SAVE THE RH70/RMO3 REGISTERS
8770 037330 012714 040111      MOV     #40111,(R4) ;ISSUE A "DRIVE CLEAR"
8771 037334 012714 000113      MOV     #113,(R4)   ;ISSUE A RELEASE TO THE DRIVE
8772 037340 000440      BR      SC          ;CHECK FOR OTHER DRIVES
8773
8774
8775 037342 122762 000002 000024 WC.HK: CMPB    #2,$CODE(R2) ;LAST OPERATION WRITE DATA ?
8776 037350 001404      BEQ     1$          ;BR IF IT WAS
8777 037352 122762 000003 000024      CMPB    #3,$CODE(R2) ;LAST OPERATION WRITE HEADER & DATA ?
8778 037360 001027      BNE     2$          ;BR IF NOT
8779 037362 004037 042326      1$:    JSR     RO,DRVQUE ;PUT THE OPERATION IN THE QUEUE
8780 037366 000424      BR      2$          ;QUEUE IS FULL
8781 037370 005062 000016      CLR     16(R2)      ;CLEAR 'DONE' BIT IN DPB
8782 037374 116262 000234 000027      MOVB    $RMCS1(R2),$PREV0(R2) ;SAVE WRITE OPERATION CODE
8783 037402 016262 000012 000034      MOV     $CYL(R2),$PREVA+2(R2) ;SAVE CYLINDER
8784 037410 016262 000010 000032      MOV     $SEC(R2),$PREVA(R2) ;SAVE SECTOR AND TRACK ADDRESSES
8785 037416 142762 000002 000024      BICB    #2,$CODE(R2) ;CHANGE WRITE TO CHECK
8786 037424 142762 000020 000002      BICB    #20,$COMND(R2) ;CHANGE DRIVER CODE TO WRITE CHECK
8787 037432 152762 000010 000002      BISB    #10,$COMND(R2) ;FINISH CHANGING CODE TO WRITE CHECK
8788 037440 000207      2$:    RTS     PC      ;EXIT
8789
8790                                     ;SPECIAL CONDITION ROUTINE
8791
8792 037442 116403 000016      SC:    MOVB    RMA5(R4),R3 ;READ "RMA5"
8793 037446 001012      BNE     2$          ;BRANCH IF ANY 'ATA' BITS SET
8794 037450 004037 041204      JSR     RO,RD.RM    ;READ CONTROL AND STATUS REGISTER
8795 037454 000000      RMCS1
8796 037456 036512      CI8
8797 037460 106126      ROLB    (SP)+
8798 037462 100403      BMI     1$          ;IS "IE"=1?
8799 037464 104001      ERROR   1          ;YES, NO DRIVES TO CHECK
8800 037466 004737 041664      JSR     PC,SET.IE   ;REPORT AN ILLEGAL INTERRUPT
8801 037472 000207      1$:    RTS     PC      ;SET INTERRUPT ENABLE
8802 037474 005046      2$:    CLR     -(SP)    ;RETURN
8803 037476 110316      MOVB    R3,(SP)    ;PROCESS ALL DRIVES THAT HAVE
                                     ;AN "ATA"=1
    
```

8804	037500	012703	000001		MOV	#1,R3	
8805	037504	005001			CLR	R1	
8806	037506	030316		SC3:	BIT	R3,(SP)	:ATA=1?
8807	037510	001005			BNE	SC5	:YES--BRANCH
8808	037512	005201		SC4:	INC	R1	:MOVE TO THE NEXT DRIVE
8809	037514	106303			ASLB	R3	
8810	037516	001373			BNE	SC3	:BRANCH IF MORE TO CHECK?
8811	037520	005726			TST	(SP)+	:CLEAN OFF THE STACK
8812	037522	000207			RTS	PC	:RETURN TO USER
8813	037524	105761	034210	SC5:	TSTB	DPINT(R1)	:INITIALIZING THE DRIVE ?
8814	037530	001402			BEQ	1\$	:BR IF NOT
8815	037532	000137	040440		JMP	SC13	:PROCESS THE DRIVE
8816	037536	105761	034220	1\$:	TSTB	DPRQS(R1)	:PORT REQUEST OUTSTANDING ?
8817	037542	001402			BEQ	2\$	:BR IF NOT
8818	037544	000137	040440		JMP	SC13	:START THE OUTSTANDING COMMAND
8819	037550	105761	034170	2\$:	TSTB	DRVSTA(R1)	:CHECK THE DRIVE STATUS
8820	037554	003025			BGT	5\$	:BRANCH IF ONLINE
8821	037556	105761	034236		TSTB	ULDFLG(R1)	:UNLOAD IN PROGRESS?
8822	037562	003422			BLE	5\$	:BRANCH IF NOT
8823	037564	004737	042402		JSR	PC,GETREQ	:GET DPB POINTER
8824	037570	004737	041546		JSR	PC,SVRH70	:SAVE THE RH70/RMO3 REGISTERS
8825	037574	004737	040370		JSR	PC,SC12	:SAVE RMD5, RMR1, RMR2, AND RMMR2
8826							:ALSO DO A DRIVE INIT (DRVINT)
8827	037600	105761	034170		TSTB	DRVSTA(R1)	:DID DRIVE COME ONLINE?
8828	037604	003416			BLE	6\$	:NO---BRANCH
8829	037606	032737	040000	034150	BIT	#BIT14,RMERRS	:WAS THERE AN ERROR?
8830	037614	001002			BNE	3\$	:BR IF ERROR
8831	037616	000137	040260		JMP	SC11	:NO ERROR
8832	037622	013705	034152	3\$:	MOV	RMERRS+2,R5	:YES -- PICKUP RMR1 AND
8833	037626	000476			BR	SC6A	:GO PROCESS THE ERROR
8834	037630	105761	034160	5\$:	TSTB	DRVACT(R1)	:DRIVE ACTIVE WITH COMMAND OR ERROR RECOVERY ?
8835	037634	001027			BNE	SC6	:BR IF EITHER
8836	037636	004737	040370		JSR	PC,SC12	:SAVE RMD5, RMR1, RMR2, AND RMMR2
8837							:ALSO DO A DRVINT
8838	037642	105761	034210	6\$:	TSTB	DPINT(R1)	:TRYING TO INIT THE DRIVE ?
8839	037646	001321			BNE	SC4	:BR IF YES, CHECK ON MORE DRIVES
8840	037650	105761	034170		TSTB	DRVSTA(R1)	:CHECK ON DRIVE'S STATUS
8841	037654	100412			BMI	7\$	:BR IF UNSAFE
8842	037656	032737	020000	034154	BIT	#BIT13,RMERRS+4	:ADDRESS PLUG CHANGED ?
8843	037664	001011			BNE	8\$	:BR IF YES
8844	037666	012746	000113		MOV	#113,-(SP)	:RELEASE COMMAND
8845	037672	004037	041360		JSR	RD,WRT.RM	:WRITE THE COMMAND INTO RMCS1
8846	037676	000000			RMCS1		:REGISTER INDEX
8847	037700	040230			SC8		:PARITY EXIT ADDRESS
8848	037702	011605		7\$:	MOV	(SP),R5	:PICKUP (RMAS) BEFORE THE ERROR CALL
8849	037704	104002			ERROR	2	:REPORT THE UNEXPECTED ATTENTION
8850	037706	000701			BR	SC4	:GO CHECK FOR MORE ATA'S
8851	037710			8\$:			
8852	037710	104005			ERROR	5	:REPORT THE ADDRESS PLUG CHANGE
8853	037712	000677			BR	SC4	:CHECK FOR MORE DRIVES
8854	037714	006301		SC6:	ASL	R1	:SETUP TO ADDRESS WORDS
8855	037716	012761	177777	034262	MOV	#-1,TIMER(R1)	:STOP THE TIMER
8856	037724	006201			ASR	R1	:RESTORE THE DRIVE ADDRESS
8857	037726	004737	042402		JSR	PC,GETREQ	:GET THE DPB POINTER FROM THE QUEUE
8858	037732	010164	000010		MOV	R1,RMCS2(R4)	:SELECT DRIVE
8859	037736	004037	041204		JSR	RD,RD.RM	:READ THE RMO3'S STATUS REG.

8860	037742	000012				RMDS		
8861	037744	040230				SC8		
8862	037746	011605				MOV	(SP),R5	;AND PUT IT IN R5
8863	037750	006126				ROL	(SP)↓	;WAS THERE AN ERROR?
8864	037752	100407				BMI	1\$	;BR IF ERROR
8865	037754	105761	034160			TSTB	DRVACT(R1)	;CHECK DRIVE'S STATE
8866	037760	003137				BGT	SC11	;BR IF DRIVE ACTIVE WITH ORDER
8867	037762	052762	100210	000016		BIS	#BIT15!BIT07!BIT03,16(R2)	;INFORM USER OF ERROR RECOVER COMPLETION
8868	037770	000470				BR	SC7	
8869	037772	004037	041204		1\$:	JSR	RO,RD.RM	;READ ERROR REGISTER #1
8870	037776	000014				RMER1		
8871	040000	040230				SC8		
8872	040002	012605				MOV	(SP)+,R5	;AND SAVE IT IN R5
8873	040004	004737	041546			JSR	PC,SVRH70	;SAVE RH70/RMO3 REGISTERS
8874	040010	012746	000111			MOV	#111,-(SP)	;ISSUE A DRIVE CLEAR
8875	040014	004037	041360			JSR	RO,WRT.RM	
8876	040020	000000				RMCS1		
8877	040022	040230				SC8		
8878	040024	006105			SC6A:	ROL	R5	;WAS "UNSAFE" CONDITION =1?
8879	040026	100406				BMI	1\$	;BRANCH IF YES
8880	040030	005702				TST	R2	;ANYTHING IN QUEUE ?
8881	040032	001447				BEQ	SC7	;BR IF NOT
8882	040034	052762	100240	000016		BIS	#BIT15!BIT07!BIT05,16(R2)	;INFORM USER OF ERROR
8883	040042	000443				BR	SC7	
8884	040044	004037	041204		1\$:	JSR	RO,RD.RM	;READ DRIVE STATUS REG. #1
8885	040050	000012				RMDS		
8886	040052	040230				SC8		
8887	040054	011605				MOV	(SP),R5	;SAVE RMDS IN R5
8888	040056	006126				ROL	(SP)↓	; "ERR"=1?
8889	040060	100011				BPL	2\$	;BR IF NO--UNSAFE CLEARED
8890	040062	112761	177777	034170		MOVB	#-1,DRVSTA(R1)	;DRIVE IS UNSAFE
8891	040070	004737	041546			JSR	PC,SVRH70	;SAVE RH70/RMO3 REGISTERS
8892	040074	052762	110000	000016		BIS	#BIT15!BIT12,16(R2)	;INFORM USER OF UNSAFE ERROR
8893	040102	000423				BR	SC7	
8894	040104	032705	010000		2\$:	BIT	#BIT12,R5	; "MOL" = 1 ?
8895	040110	001015				BNE	3\$	;BR IF YES
8896	040112	112761	177777	034160		MOVB	#-1,DRVACT(R1)	;ACTIVE ERROR RECOVER
8897	040120	112761	000001	034170		MOVB	#1,DRVSTA(R1)	;ONLINE
8898	040126	006301				ASL	R1	
8899	040130	012761	072460	034262		MOV	#30000.,TIMER(R1)	;START 30 SECOND TIMER
8900	040136	006201				ASR	R1	
8901	040140	000137	037512			JMP	SC4	
8902	040144	052762	100220	000016	3\$:	BIS	#BIT15!BIT07!BIT04,16(R2)	;INFORM USER OF ERROR
8903	040152	105061	034160		SC7:	CLR8	DRVACT(R1)	;DRIVE IS IDLE
8904	040156	004737	042306			JSR	PC,EMPTYQ	;DUMP THE QUEUE
8905	040162	105761	034236			TSTB	ULDFLG(R1)	;UNLOAD IN RMOPGRESS OR QUEUE?
8906	040166	003002				BGT	1\$	;BR IF NOT
8907	040170	105061	034236			CLR8	ULDFLG(R1)	;CLEAR UNLOAD FLAG
8908	040174	116164	034304	000016	1\$:	MOVB	ATABIT(R1),RMAS(R4)	;CLEAR ATTENTION BIT
8909	040202	105761	034170			TSTB	DRVSTA(R1)	;IS THE DRIVE UNSAFE ?
8910	040206	100406				BMI	2\$	;BR IF IT IS
8911	040210	012746	000113			MOV	#113,-(SP)	;RELEASE COMMAND
8912	040214	004037	041360			JSR	RO,WRT.RM	;WRITE THE COMMAND INTO RPCS1
8913	040220	000000				RMCS1		;REGISTER INDEX
8914	040222	040230				SC8		;PARITY EXIT ADDRESS
8915	040224	000137	037512		2\$:	JMP	SC4	;CHECK FOR MORE DRIVES

8916	040230	105761	034160		SC8:	TSTB	DRVACT(R1)		; IS DRIVE IDLE?
8917	040234	001405				BEQ	1\$		; YES--BRANCH
8918	040236	004737	042402			JSR	PC,GETREQ		; GET DPB POINTER
8919	040242	004737	036412			JSR	PC,CI7		; PROCESS THE PARITY ERROR
8920	040246	000402				BR	2\$		; CONTINUE
8921	040250	004737	036440		1\$:	JSR	PC,CI7B		; PROCESS THE UNCORRECTABLE PARITY ERROR
8922	040254	000137	037512		2\$:	JMP	SC4		; CHECK MORE DRIVES
8923	040260	105761	034236		SC11:	TSTB	ULDFLG(R1)		; "UNLOAD IN PROGRESS"?
8924	040264	003402				BLE	1\$		; BRANCH IF NO
8925	040266	105061	034236			CLRB	ULDFLG(R1)		; CLEAR UNLOAD FLAG
8926	040272	105061	034160		1\$:	CLRB	DRVACT(R1)		; SET DRIVE IDLE
8927	040276	136137	034304	034232		BITB	ATABIT(R1),SRCHWT		; DOING A SEARCH OPERATION FOR ; AN I/O COMMAND?
8928									
8929	040304	001012				BNE	2\$		; BRANCH IF YES
8930	040306	004737	042424			JSR	PC,POPQUE		; REMOVE REQUEST FROM QUEUE
8931	040312	052762	000200	000016		BIS	#BIT07,16(R2)		; SET "DONE" BIT
8932	040320	005737	034256			TST	SAVEFG		; SAVE THE REGISTERS?
8933	040324	100002				BPL	2\$		; BRANCH IF NO
8934	040326	004737	041546			JSR	PC,SVRH70		; YES--SAVE ALL OF THE RH70/RMO3 REG'S
8935	040332	116164	034304	000016	2\$:	MOVB	ATABIT(R1),RMAS(R4)		; CLEAR ATTENTION BIT
8936	040340	146137	034304	034232		BICB	ATABIT(R1),SRCHWT		; CLEAR IMPLIED SEEK SET
8937	040346	006301				ASL	R1		; WORD INDEX
8938	040350	012761	177777	034262		MOV	#-1,TIMER(R1)		; STOP CLOCK
8939	040356	006201				ASR	R1		; RESTORE R1
8940	040360	004737	035332			JSR	PC,OPT		; START A REQUEST
8941	040364	000137	037512			JMP	SC4		; CHECK FOR MORE DRIVES
8942	040370	010164	000010		SC12:	MOV	R1,RMCS2(R4)		; SELECT DRIVE
8943	040374	016437	000012	034150		MOV	RMDS(R4),RMERRS		; SAVE THE FOUR REGISTERS THAT
8944	040402	016437	000014	034152		MOV	RMER1(R4),RMERRS+2		; WILL TELL US SOMETHING
8945	040410	016437	000042	034154		MOV	RMER2(R4),RMERRS+4		
8946	040416	016437	000040	034156		MOV	RMMR2(R4),RMERRS+6		
8947	040424	004037	034546			JSR	RO,DRVINT		; INIT. THE STATE OF THE DRIVE
8948	040430	000401				BR	1\$		; TAKE ERROR EXIT
8949	040432	000207				RTS	PC		; RETURN
8950	040434	005726			1\$:	TST	(SP)+		; POP PC OFF OF THE STACK
8951	040436	000674				BR	SC8		; PROCESS THE PARITY ERROR
8952	040440	006301			SC13:	ASL	R1		; SETUP TO ADDRESS WORDS
8953	040442	012761	177777	034262		MOV	#-1,TIMER(R1)		; STOP THE TIMER
8954	040450	006201				ASR	R1		
8955	040452	010164	000010			MOV	R1,RMCS2(R4)		; SELECT THE DRIVE
8956	040456	116164	034304	000016		MOVB	ATABIT(R1),RMAS(R4)		; CLEAR THE ATTENTION BIT
8957	040464	105761	034210		1\$:	TSTB	DPINT(R1)		; INITIALIZING THE DRIVE ?
8958	040470	001424				BEQ	2\$		; BR IF NOT
8959	040472	105061	034210			CLRB	DPINT(R1)		; CLEAR THE INIT INDICATOR
8960	040476	004037	034546			JSR	RO,DRVINT		; GO INIT THE DRIVE
8961	040502	000240				NOP			; DUMMY PARITY ERROR RETURN
8962	040504	105761	034170			TSTB	DRVSTA(R1)		; DRIVE ONLINE ?
8963	040510	003014				BGT	2\$		; BR IF YES -- START ORDER
8964	040512	005702				TST	R2		; QUEUE ENTRY FOR THE DRIVE
8965	040514	001426				BEQ	3\$		; BR IF NOT
8966	040516	004737	042402			JSR	PC,GETREQ		; GET DPB ADDRESS
8967	040522	052762	140000	000016		BIS	#BIT15:BIT14,16(R2)		; INFORM USER THAT DRIVE OFFLINE
8968	040530	004737	041546			JSR	PC,SVRH70		; SAVE THE REGISTERS
8969	040534	004737	042306			JSR	PC,EMPTYQ		; EMPTY THE REQUEST QUEUE
8970	040540	000414				BR	3\$		
8971	040542	032764	004000	000000	2\$:	BIT	#BIT11,RMCS1(R4)		; DVA SET ?



```

8972 040550 001006          BNE      4$          ;SET THEN CALL OPT
8973 040552 006301          ASL      R1
8974 040554 012761 023420 034262  MOV      #10000.,TIMER(R1)
8975 040562 006201          ASR      R1
8976 040564 000402          BR       3$
8977 040566 004737 035332 4$: JSR      PC,OPT      ;START THE PENDING REQUEST
8978 040572 000137 037512 3$: JMP      SC4        ;PROCESS OTHER DRIVES
8979
8980          ;/RM03 TIMER ROUTINE
8981          ;CALL
8982          ;
8983          ;      MOV      #TIME, -(SP)      ;ELAPSED TIME IN MILLISECONDS ON THE STACK
8984          ;      JSR      PC,RPTMR        ;CALL RM03 TIME ROUTINE
8985 040576 005737 034234  RPTMR: TST      ACTDRV      ;CHECK "ACTDRV & ACTSTR"
8986 040602 001027          BNE      4$          ;IF NON ZERO EXIT
8987 040604 112737 000001 034235  MOVB     #1,ACTSTR    ;SET "ACTSTR"
8988 040612 104412          SAVREG
8989 040614 005001          CLR      R1          ;SAVE RD - R5
8990 040616 005003          CLR      R3          ;START WITH DRIVE 0
8991 040620 005763 034262  1$: TST      TIMER(R3)   ;IS THE TIMER RUNNING?
8992 040624 002406          BLT      2$          ;BRANCH IF NO
8993 040626 166663 000002 034262  SUB      2(SP),TIMER(R3) ;COUNT THE INTERVAL
8994 040634 003002          BGT      2$          ;BR IF NO SOFTWARE TIMEOUT
8995 040636 004737 040666  JSR      PC,STO      ;CALL SOFTWARE TIMEOUT ROUTINE
8996 040642 005201 2$: INC      R1          ;MOVE TO NEXT DRIVE
8997 040644 005723          TST      (R3)+
8998 040646 022701 000010  CMP      #8.,R1      ;OUT OF DRIVES?
8999 040652 003362          BGT      1$          ;BRANCH IF NO
9000 040654 104413 3$: RESREG      ;RESTORE RD - R5
9001 040656 105037 034235  CLRB     ACTSTR      ;ZERO ACTIVE SOFTWARE TIMEOUT ROUTINE FLAG
9002 040662 012616 4$: MOV      (SP)+,(SP)  ;ADJUST THE STACK
9003 040664 000207          RTS       PC         ;RETURN
9004
9005          ;SOFTWARE TIMEOUT ROUTINE
9006
9007          ;NOTE: THIS ROUTINE MUST BE ENTERED AT PRIORITY 6
9008          ;OR GREATER
9009
9010          ;CALL:
9011          ;      STO
9012          ;      MOV      #DRVNUM,R1      ;DRIVE NUMBER
9013          ;      JSR      PC,STO          ;CALL
9014          ;      RETURN
9015 040666 010146  STO:  MOV      R1, -(SP)      ;SAVE R1
9016 040670 010246          MOV      R2, -(SP)      ;SAVE R2
9017 040672 010346          MOV      R3, -(SP)      ;SAVE R3
9018 040674 010446          MOV      R4, -(SP)      ;SAVE R4
9019 040676 013704 034316  MOV      RMADR,R4     ;GET ADDRESS OF "RMCS1"
9020 040702 010164 000010  MOV      R1,RMCS2(R4)  ;SELECT THE DRIVE
9021 040706 004037 041204  JSR      RO,RD.RM     ;READ "DRIVE STATUS REG"
9022 040712 000012          RMD5
9023 040714 041066          STOS
9024 040716 105726          TSTB     (SP)+        ;IS "DRY"=1?
9025 040720 100434          BMI
9026 040722 105761 034210  ST01: TSTB     DPINT(R1) ;BR IF YES
9027 040726 001031          BNE      ST02        ;TRYING TO INTIALIZE THE DRIVE ?
          ;BR IF YES
    
```

## M13

MD-11-DZRMBA AO/00, RMO3 PERFORMANCE EXERCISER MACY11 30(1046) 27-JUL-77 08:07 PAGE 168  
 DZRMBA.P11 27-JUL-77 08:04 SINGLE/DUAL PORT RH70/RMO3 DRIVER (REV 1.0)

SEQ 0167

```

9028 040730 105761 034220      TSTB  DPRQS(R1)      ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
9029 040734 001026                BNE   ST02          ;BR IF YES
9030 040736 013702 034230      MOV   TRNSWT,R2    ;PICKUP TRANSFER WAIT QUEUE
9031 040742 020137 034302      CMP   R1,DTUM      ;TRANSFER UNDERWAY ON THIS DRIVE?
9032 040746 001404                BEQ   1$           ;BRANCH IF YES
9033 040750 000137 041172      JMP   ST09         ;IF NOT DON'T BOTHER DRIVES
9034 040754 004737 042402      JSR   PC,GETREQ    ;GET DPB ADDRESS
9035 040760 052762 101000 000016 1$:  BIS   #BIT15:BIT09,16(R2) ;SET THE ERROR FLAGS
9036 040766 004737 041546      JSR   PC,SVRH70    ;SAVE RH70/RMO3 REGISTERS
9037 040772 012764 000040 000010  MOV   #BIT05,RMCS2(R4) ;"INIT" THE MASS BUS
9038 041000 105061 034160      CLRB  DRVACT(R1)   ;DRIVE IS IDLE
9039 041004 105061 034236      CLRB  ULDFLG(R1)  ;CLEAR THE UNLOAD FLAG
9040 041010 000470                BR    ST09         ;DON'T BOTHER OTHER DRIVES
9041 041012 116405 000016      ST02: MOVB  RMA5(R4),R5 ;READ ATTENTION REG
9042 041016 136105 034304      BITB  ATABIT(R1),R5 ;IS ATTENTION FOR THIS DRIVE UP ?
9043 041022 001007                BNE  ST03         ;YES--BRANCH
9044 041024 105761 034210      TSTB  DPINT(R1)    ;TRYING TO INITIALIZE THE DRIVE ?
9045 041030 001021                BNE  ST06         ;BR IF YES - DRIVE NOT ONLINE
9046 041032 105761 034220      TSTB  DPRQS(R1)    ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
9047 041036 001035                BNE  ST07         ;BR IF YES - NO RESPONSE TO REQUEST
9048 041040 000454                BR    ST09         ;OTHER WISE EXIT
9049 041042 105761 034210      ST03: TSTB  DPINT(R1) ;INITIALIZING THE DRIVE ?
9050 041046 001003                BNE  1$           ;BR IF INIT PENDING
9051 041050 105761 034220      TSTB  DPRQS(R1)    ;PORT REQUEST PENDING ?
9052 041054 001446                BEQ  ST09         ;BR IF NOT
9053 041056 012763 177777 034262 1$:  MOV   #-1,TIMER(R3) ;STOP THE TIMER
9054 041064 000442                BR    ST09         ;EXIT
9055 041066 004737 036512      ST05: JSR   PC,C18    ;GO HANDLE THE PARITY ERROR
9056 041072 000437                BR    ST09
9057 041074 105061 034210      ST06: CLRB  DPINT(R1) ;CLEAR THE INITIALIZE INDICATOR
9058 041100 105061 034170      CLRB  DRVSTA(R1)  ;SET UNIT OFFLINE
9059 041104 012763 177777 034262  MOV   #-1,TIMER(R3) ;STOP THE TIMER
9060 041112 004737 042402      JSR   PC,GETREQ    ;GET THE DPB ADDRESS
9061 041116 005702                TST  R2           ;REQUEST IN QUEUE ?
9062 041120 001424                BEQ  ST09         ;BR IF NOT
9063 041122 052762 140000 000016  BIS   #BIT15:BIT14,16(R2) ;INFORM THE USER DRIVE NOT AVAILABLE
9064 041130 000414                BR    ST08        ;FINISH
9065 041132 012763 177777 034262  ST07: MOV   #-1,TIMER(R3) ;STOP THE TIMER
9066 041140 105061 034220      CLRB  DPRQS(R1)    ;CLEAR PORT REQUEST INDICATOR
9067 041144 004737 042402      JSR   PC,GETREQ    ;GET DPB ADDRESS
9068 041150 005702                TST  R2           ;QUEUE ENTRY FOR DRIVE ?
9069 041152 001407                BEQ  ST09         ;BR IF NONE
9070 041154 012762 100004 000016  MOV   #BIT15:BIT2,16(R2) ;INFORM USER OF PORT REQUEST ERROR
9071 041162 004737 042306      ST08: JSR   PC,EMPTYQ ;CLEAR THE QUEUE FOR THE DRIVE
9072 041166 004737 041546      JSR   PC,SVRH70    ;SAVE THE REGISTERS
9073 041172 012604      ST09: MOV   (SP)+,R4    ;RESTORE R4
9074 041174 012603      MOV   (SP)+,R3    ;RESTORE R3
9075 041176 012602      MOV   (SP)+,R2    ;RESTORE R2
9076 041200 012601      MOV   (SP)+,R1    ;RESTORE R1
9077 041202 000207      RTS   PC          ;RETURN
9078
9079 ;ROUTINE TO READ A RH70/RMO3 REGISTER
9080 ;
9081 ;CALL
9082 ;   JSR   RO,RD,RM ;GO READ A REGISTER
9083 ;   INDEX ;REG. INDEX FROM BASE

```

```

9084 ; ERRADR ; ERROR ADDRESS--PROCESS ERROR STARTING
9085 ; ; AT THIS ADDRESS
9086 ; RETURN ; CONTENTS OF REG. IS ON THE STACK
9087 ;
9088 041204 013737 034314 041346 RD.RM: MOV MCPEMX,RD.RM2 ; MAX. RETRYS ALLOWED
9089 041212 011646 MOV (SP)-,(SP) ; SAVE RD FOR RETURN
9090 041214 013737 034316 041230 MOV RMADR,RD.ADR ; FORM THE DESIRED ADDRESS
9091 041222 062037 041230 ADD (RD)+,RD.ADR ; USING THE BASE AND THE INDEX
9092 041226 013727 RD.RM1: MOV @PC+,(PC)+ ; READ THE DESIRED REGISTER OF THE RMO3
9093 041230 000000 RD.ADR: .WORD 0 ; ADDRESS IS FORMED HERE
9094 041232 000000 RD.WRD: .WORD 0 ; REG. CONTENTS PUT HERE
9095 041234 013766 041232 000002 MOV RD.WRD,2(SP) ; RETURN IT TO THE USER
9096 041242 013746 034316 MOV RMADR,-(SP) ; PUT THE ADDRESS ON THE STACK
9097 041246 062716 000010 ADD #RMCS2,(SP) ; FORM THE ADDRESS OF RMCS2
9098 041252 032736 010000 BIT #BIT12,@(SP)+ ; CHECK THE 'NEI' BIT
9099 041256 001035 BNE RD.RM3 ; BR IF DRIVE NON-EXISTENT
9100 041260 017746 173032 MOV @RMADR,-(SP) ; READ RMCS1
9101 041264 032716 020000 BIT #BIT13,(SP) ; DID MCPE SET?
9102 041270 001002 BNE 1$ ; BRANCH IF YES
9103 041272 022620 CMP (SP)+,(RD)+ ; ADJUST FOR RETURN
9104 041274 000430 BR RD.RM4 ; EXIT
9105 041276
9106 1$: 041276 104003 ERROR 3 ; REPORT "MCPE" ERROR
9107 041300 005737 034302 TST DTUW ; DATA TRANSFER UNDERWAY?
9108 041304 100405 BMI 2$ ; NO--BRANCH
9109 041306 032716 040000 BIT #BIT14,(SP) ; NO--"TRE"=1?
9110 041312 001402 BEQ 2$ ; NO--BRANCH
9111 041314 005726 TST (SP)+ ; YES--CLEAN OFF THE STACK AND
9112 041316 000415 BR RD.RM3 ; TAKE THE FATAL ERROR EXIT
9113 041320 052716 040000 2$: BIS #BIT14,(SP) ; CLEAR "MCPE" BY SENDING A "1" TO "TRE"
9114 041324 000316 SWAB (SP) ; POSITION BEFORE WRITING
9115 041326 013737 034316 041342 MOV RMADR,3$ ; FORM ADDRESS OF HIGH BYTE
9116 041334 005237 041342 INC 3$
9117 041340 112637 MOVB (SP)+,@(PC)+ ; WRITE THE HIGH BYTE OF RMCS1
9118 041342 000000 3$: .WORD 0 ; ADDRESS STORAGE
9119 041344 005327 DEC (PC)+ ; EXCEEDED MAX. RETRYS
9120 041346 000003 RD.RM2: .WORD 3
9121 041350 002326 BGE RD.RM1 ; BRANCH IF NO
9122 041352 011000 RD.RM3: MOV (RD),RD ; FATAL ERROR EXIT
9123 041354 012616 MOV (SP)+,(SP)
9124 041356 000200 RD.RM4: RTS RD
9125
9126 ; ROUTINE TO WRITE A REGISTER
9127 ;
9128 ; CALL
9129 ;
9130 ; MOV DATA,-(SP) ; DATA TO BE LOADED ON THE STACK
9131 ; JSR RD,WRT.RM ; CALL THE ROUTINE TO LOAD(WRITE) THE REG.
9132 ; INDEX ; INDEX OF THE REGISTER TO BE LOADED
9133 ; ERRADR ; ADDRESS TO RETURN TO ON AN ERROR
9134 ; RETURN ; ERROR FREE RETURN
9135 041360 013737 034314 041532 WRT.RM: MOV MCPEMX,WRT.R2 ; MAX RETRYS ALLOWED
9136 041366 016637 000002 041446 MOV 2(SP),WRT.WD ; SAVE THE WORD TO WRITE
9137 041374 012616 MOV (SP)+,(SP) ; ADJUST THE STACK
9138 041376 012037 041450 MOV (RD)+,WRT.AD ; GET INDEX OF REGISTER TO BE WRITTEN
9139 041402 001015 BNE 1$ ; BRANCH IF NOT RMCS1
    
```

```

9140 041404 122737 000150 041446 CMPB #150,WRT.WD ;IS THE COMMAND FOR DATA TRANSFERS?
9141 041412 002411 BLT 1$ ;YES--DON'T GET THE OLD A16 & A17, & PSEL
9142 041414 004037 041204 JSR RO,RO.RM ;NO---COMBINE A16&A17, & PSEL WITH
9143 041420 000000 RMCS1 ;THE COMMAND BEFORE SENDING IT TO
9144 041422 041536 WRT.R3 ;THE RH70/RMO3
9145 041424 000316 SWAB (SP)
9146 041426 042716 177770 BIC #+C7,(SP)
9147 041432 112637 041447 MOVB (SP)+,WRT.WD+1
9148 041436 063737 034316 041450 1$: ADD RMADR,WRT.AD ;FORM THE ADDRESS OF THE DISK REG.
9149 041444 012737 WRT.R1: MOV (PC)+,2(PC)+ ;LOAD THE DESIRED REG.
9150 041446 000000 WRT.WD: .WORD 0 ;WORD TO WRITE GOES HERE
9151 041450 000000 WRT.AD: .WORD 0 ;ADDRESS IS FORMED HERE
9152 041452 013746 034316 MOV RMADR,-(SP) ;PUT THE ADDRESS ON THE STACK
9153 041456 062716 000010 ADD #RMCS2,(SP) ;FORM THE ADDRESS OF RMCS2
9154 041462 032736 010000 BIT #BIT12,2(SP)+ ;CHECK THE 'NED' BIT
9155 041466 001023 BNE WRT.R3 ;BR IF DRIVE NON-EXISTENT
9156 041470 004037 041204 JSR RO,RO.RM ;CHECK FOR PARITY ERROR ON WRITE
9157 041474 000014 RMER1
9158 041476 041536 WRT.R3
9159 041500 032726 000010 BIT #BIT03,(SP)+
9160 041504 001416 BEQ WRT.R4 ;BRANCH IF "PAR=0"
9161 041506 016037 177776 041520 MOV -2(RO),1$ ;PICKUP THE INDEX
9162 041514 004037 041204 JSR RO,RO.RM ;READ THE REG.
9163 041520 000000 1$: .WORD 0 ;REG. INDEX
9164 041522 041536 WRT.R3 ;RETURN TO THIS ADDRESS ON ERROR
9165 041524 104004 ERROR 4 ;REPORT THE PARITY ON WRITE ERROR
9166 041526 005726 TST (SP)+ ;CLEAR OFF THE STACK
9167 041530 005327 DEC (PC)+ ;DECREMENT THE ERROR COUNT
9168 041532 000003 WRT.R2: .WORD 3 ;RETRY COUNTER
9169 041534 002343 9GE WRT.R1 ;TRY AGAIN IF NOT FINISHED
9170 041536 011000 WRT.R3: MOV (RO),RO ;TAKE THE "PARITY ON WRITE" ERROR EXIT
9171 041540 000401 BR WRT.R5 ;EXIT
9172 041542 005720 WRT.R4: TST (RO)+ ;ADJUST FOR ERROR FREE EXIT
9173 041544 000200 WRT.R5: RTS RO
9174
9175 ;ROUTINE TO SAVE THE RH70/RP04/5/RMO3 REGISTERS AS PER DPB+14
9176 ;CALL
9177 ;
9178 ; MOV #DPBNUM,R2 ;DPB POINTER TO R2
9179 ; JSR PC,SVRH70 ;SAVE THE DRIVES REG'S
9180
9181 SVRH70: SAVREG ;SAVE RO - R5
9182 041550 005702 TST R2 ;QUEUE ENTRY FOR THE DRIVE ?
9183 041552 001442 BEQ 6$ ;BR IF NONE
9184 041554 013704 034316 MOV RMADR,R4
9185 041560 111264 000010 MOVB (R2),RMCS2(R4) ;SELECT DRIVE
9186 041564 016203 000014 MOV 14(R2),R3 ;GET THE ERROR TABLE POINTER
9187 041570 001433 BEQ 6$ ;EXIT IF NO ADDRESS
9188 041572 005037 041626 CLR 3$ ;COUNTER & POINTER
9189 041576 023727 041626 000022 1$: CMP 3$,#RMOB ;REACHED THE BUFFER REGISTER ?
9190 041604 001006 BNE 2$ ;BR IF NOT
9191 041606 032764 000200 000010 BIT #BIT07,RMCS2(R4) ;'OR' SET ?
9192 041614 001002 BNE 2$ ;BR IF SET
9193 041616 005023 CLR (R3)+ ;STORE RMOB AS ZEROES
9194 041620 000405 BR 4$ ;CONTINUE
9195 041622 004037 041204 2$: JSR RO,RO.RM ;READ THE SELECTED REGISTER
    
```

```

9196 041626 000000      3$:  .WORD  0      ;REGISTER INDEX
9197 041630 041654      5$:  .WORD  0      ;ERROR RETURN ADDRESS
9198 041632 012623      MOV  (SP)+,(R3)+  ;STORE THE REGISTER CONTENTS
9199 041634 023727 041626 000046 4$:  CMP  3$,#RMEC2  ;REACHED THE END ?
9200 041642 001406      BEQ  6$          ;BR IF YES
9201 041644 062737 000002 041626  ADD  #2,3$      ;INCREMENT THE REGISTER INDEX
9202 041652 000751      BR   1$          ;CONTINUE READING THE REGISTERS
9203 041654 004737 036412 5$:  JSR  PC,C17    ;PROCESS THE UNCORRECTABLE PARITY ERROR
9204 041660 104413      6$:  RESREG      ;RESTORE R0 - R5
9205 041662 000207      RTS   PC        ;RETURN
9206
9207      ;ROUTINE TO SET THE INTERRUPT WITHOUT GETTING A "TRE"
9208      ;CALL
9209      ;      MOV  #DRVNUM,R1      ;DRIVE NUMBER TO R1
9210      ;      JSR  PC,SET.IE     ;SET "IE"
9211      ;
9212      ;
9213 041664 010446      SET.IE: MOV  R4,-(SP)   ;SAVE R4
9214 041666 013704 034316  MOV  RMADR,R4   ;PICKUP ADDRESS OF RMCS1
9215 041672 010164 000010  MOV  R1,RMCS2(R4) ;SELECT DRIVE
9216 041676 011446      MOV  (R4),-(SP) ;READ RMCS1
9217 041700 052716 040000  BIS  #BIT14,(SP) ;SET THE "TRE" BIT OF THE WORD READ
9218 041704 000316      SWAB (SP)      ;ADJUST FOR DATO
9219 041706 112714 000100  MOVB #BIT06,(R4) ;SET "IE"
9220 041712 032764 010000 000010  BIT  #BIT12,RMCS2(R4) ;IS "NED"=1?
9221 041720 001002      BNE  1$        ;YES--CLEAR "TRE"
9222 041722 005726      TST  (SP)+     ;CLEAN OFF THE STACK
9223 041724 000402      BR   2$
9224 041726 112664 000001 1$:  MOVB (SP)+,1(R4) ;CLEAR "TRE"
9225 041732 012604      2$:  MOV  (SP)+,R4  ;RESTORE R4
9226 041734 000207      RTS   PC      ;RETURN TO CALLER
9227
9228      ;QUEUE COUNT
9229 041736 000      QCNT: .BYTE  0      ;DRIVE 0
9230 041737 000      .BYTE  0      ;DRIVE 1
9231 041740 000      .BYTE  0      ;DRIVE 2
9232 041741 000      .BYTE  0      ;DRIVE 3
9233 041742 000      .BYTE  0      ;DRIVE 4
9234 041743 000      .BYTE  0      ;DRIVE 5
9235 041744 000      .BYTE  0      ;DRIVE 6
9236 041745 000      .BYTE  0      ;DRIVE 7
9237
9238      ;QUEUE INPUT POINTERS
9239
9240 041746 042030  QINPT: .WORD  QDRV0  ;DRIVE 0
9241 041750 042050  .WORD  QDRV1  ;DRIVE 1
9242 041752 042070  .WORD  QDRV2  ;DRIVE 2
9243 041754 042110  .WORD  QDRV3  ;DRIVE 3
9244 041756 042130  .WORD  QDRV4  ;DRIVE 4
9245 041760 042150  .WORD  QDRV5  ;DRIVE 5
9246 041762 042170  .WORD  QDRV6  ;DRIVE 6
9247 041764 042210  .WORD  QDRV7  ;DRIVE 7
9248
9249      ;QUEUE OUTPUT POINTERS
9250
9251 041766 042030  QOUTPT: .WORD  QDRV0 ;DRIVE 0
    
```

```

9252 041770 042050 .WORD QDRV1 ;DRIVE 1
9253 041772 042070 .WORD QDRV2 ;DRIVE 2
9254 041774 042110 .WORD QDRV3 ;DRIVE 3
9255 041776 042130 .WORD QDRV4 ;DRIVE 4
9256 042000 042150 .WORD QDRV5 ;DRIVE 5
9257 042002 042170 .WORD QDRV6 ;DRIVE 6
9258 042004 042210 .WORD QDRV7 ;DRIVE 7
9259
9260 042006 042030 QSTART: .WORD QDRV0 ;DRIVE 0 START ADDRESS
9261 042010 042050 QSTOP: .WORD QDRV1 ;DRIVE 0 STOP ADDRESS & DRIVE 1 START ADDRESS
9262 042012 042070 .WORD QDRV2 ;STOP DRIVE 1--START DRIVE 2
9263 042014 042110 .WORD QDRV3 ;STOP DRIVE 2--START DRIVE 3
9264 042016 042130 .WORD QDRV4 ;STOP DRIVE 3--START DRIVE 4
9265 042020 042150 .WORD QDRV5 ;STOP DRIVE 4--START DRIVE 5
9266 042022 042170 .WORD QDRV6 ;STOP DRIVE 5--START DRIVE 6
9267 042024 042210 .WORD QDRV7 ;STOP DRIVE 6--START DRIVE 7
9268 042026 042230 .WORD QTERM ;STOP DRIVE 7
9269
9270 ;DRIVE REQUEST QUEUES
9271
9272 042030 000010 QDRV0: .BLKW 10
9273 042050 000010 QDRV1: .BLKW 10
9274 042070 000010 QDRV2: .BLKW 10
9275 042110 000010 QDRV3: .BLKW 10
9276 042130 000010 QDRV4: .BLKW 10
9277 042150 000010 QDRV5: .BLKW 10
9278 042170 000010 QDRV6: .BLKW 10
9279 042210 000010 QDRV7: .BLKW 10
9280 042230 000010 QTERM=.
9281
9282 ;ROUTINE TO CLEAR ALL OF THE REQUEST QUEUES
9283
9284 ;CALL
9285 ; JSR PC,CLRQUE
9286
9287 042230 104412 CLRQUE: SAVREG ;SAVE R0 - R5
9288 042232 012702 041736 MOV #QCNT,R2 ;ZERO THE QUEUE COUNTS
9289 042236 005022 CLR (R2)+ ;DRIVES 0 & 1
9290 042240 005022 CLR (R2)+ ;DRIVES 2 & 3
9291 042242 005022 CLR (R2)+ ;DRIVES 4 & 5
9292 042244 005022 CLR (R2)+ ;DRIVES 6 & 7
9293 042246 012703 000010 MOV #8,R3 ;MOVE THE STARTING
9294 042252 012701 042006 MOV #QSTART,R1 ;ADDRESS OF THE QUEUE INTO
9295 042256 012122 1S: MOV (R1)+,(R2)+ ;THE QUEUE INPUT POINTER
9296 042260 005303 DEC R3
9297 042262 001375 BNE 1S
9298 042264 012703 000010 MOV #8,R3 ;MOVE THE STARTING ADDRESS
9299 042270 012701 042006 MOV #QSTART,R1 ;OF THE QUEUE INTO THE
9300 042274 012122 2S: MOV (R1)+,(R2)+ ;QUEUE OUTPUT POINTER
9301 042276 005303 DEC R3
9302 042300 001375 BNE 2S
9303 042302 104413 RESREG ;RESTORE R0 - R5
9304 042304 000207 RTS PC
9305
9306 ;EMPTY THE QUEUE SPECIFIED BY R1
9307 ;

```

```

9308          ;CALL
9309          ;      MOV      DRVNUM,R1      ;DRIVE NUMBER TO R1
9310          ;      JSR      PC,EMPTYQ
9311          ;
9312 042306 105061 041736  EMPTYQ: CLRB   QCNT(R1)      ;CLEAR NUMBER OF ITEMS IN QUEUE
9313 042312 006301          ASL      R1
9314 042314 016161 041746 041766  MOV     QINPT(R1),QOUTPT(R1) ;SET OUTPUT QUEUE POINTER=INPUT POINTER
9315 042322 006201          ASR      R1
9316 042324 000207          RTS       PC
9317
9318          ;ROUTINE TO PUT A REQUEST IN QUEUE
9319          ;CALL
9320          ;      MOV      #DRVNUM,R1      ;DRIVE NUMBER
9321          ;      MOV      #DPB,R2        ;ADDRESS OF PARAMETER BLOCK
9322          ;      JSR      RO,DRVQUE      ;GO PUT REQUEST IN QUEUE
9323          ;      RETURN1      ;RETURN HERE IF QUEUE IS FULL
9324          ;      RETURN2      ;RETURN HERE IF REQUEST IS IN QUEUE
9325          ;
9326          ;
9327 042326 122761 000010 041736  DRVQUE: CMPB   #10,QCNT(R1)  ;IS QUEUE FULL?
9328 042334 001421          BEQ     2$          ;BR IF YES-TAKE RETURN1
9329 042336 105261 041736          INCB   QCNT(R1)      ;INCREMENT QUEUE COUNT
9330 042342 006301          ASL      R1
9331 042344 010271 041746          MOV     R2,QINPT(R1)  ;PUT THIS REQUEST IN QUEUE
9332 042350 062761 000002 041746  ADD     #2,QINPT(R1)  ;UPDATE THE QUEUE POINTER
9333 042356 026161 041746 042010  CMP     QINPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER
9334 042364 001003          BNE     1$          ;BRANCH IF NO
9335 042366 016161 042006 041746  MOV     QSTART(R1),QINPT(R1) ;YES--RESET POINTER
9336 042374 006201          1$:   ASR      R1
9337 042376 005720          TST     (R0)+        ;TAKE RETURN 2
9338 042400 000200          2$:   RTS       RO      ;RETURN TO USER
9339
9340          ;ROUTINE TO GET THE "DPB" ADDRESS OF NEXT REQUEST IN QUEUE
9341          ;CALL
9342          ;      MOV      #DRVNUM,R1      ;DRIVE NUMBER TO R1
9343          ;      JSR      PC,GETREQ      ;GO GET THE REQUEST
9344          ;      RETURN      ;R2="DPB" ADDRESS OF THE REQUEST
9345          ;      ;R2=0 IF NO REQUEST IN QUEUE
9346          ;
9347          ;
9348 042402 005002          GETREQ: CLR     R2
9349 042404 105761 041736          TSTB   QCNT(R1)      ;IS THERE ANY REQUEST IN QUEUE?
9350 042410 001404          BEQ     2$          ;NO---BRANCH
9351 042412 006301          1$:   ASL      R1
9352 042414 017102 041766          MOV     QOUTPT(R1),R2 ;PICKUP "DPB" POINTER FOR THIS DRIVE
9353 042420 006201          ASR      R1
9354 042422 000207          2$:   RTS       PC      ;RETURN TO USER
9355
9356          ;ROUTINE TO "POP" THE REQUEST FROM QUEUE
9357          ;CALL
9358          ;      MOV      #DRVNUM,R1      ;DRIVE NUMBER TO R1
9359          ;      JSR      PC,POPQUE      ;CALL TO REMOVE REQUEST
9360          ;      RETURN      ;R2=ADDRESS OF DPB REMOVED
9361          ;
9362          ;
9363 042424 105361 041736  POPQUE: DECB   QCNT(R1)  ;DECREMENT QUEUE COUNT

```

```

9364 042430 006301          ASL      R1
9365 042432 017102 041766   MOV      QOUTPT(R1),R2 ;GET THE "DPB" POINTER
9366 042436 005071 041766   CLR      QOUTPT(R1) ;REMOVE DPB ADDRESS FROM THE QUEUE
9367 042442 062761 000002 041766   ADD      #2,QOUTPT(R1) ;UPDATE THE QUEUE POINTER
9368 042450 026161 041766 042010   CMP      QOUTPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER?
9369 042456 001003          BNE      IS ;NO--BRANCH TO EXIT
9370 042460 016161 042006 041766   MOV      QSTART(R1),QOUTPT(R1) ;YES--RESET THE POINTER
9371 042466 006201          IS:    ASR      R1
9372 042470 000207          RTS      PC ;RETURN TO USER
9373
9374
9375
9376
9377
9378
9379
9380
9381
9382
9383
9384
9385
9386
9387
9388
9389
9390
9391
9392
9393
9394
9395
9396
9397
9398
9399
9400
9401
9402
9403
9404
9405
9406
9407
9408
9409
9410
9411
9412
9413
9414
9415
9416
9417
9418
9419
    
```

;;\*\*\*\*\*

.SBTTL DATA, CONTROL, & STATUS BLOCKS

;;\*\*\*\*\*

;BLOCK LOCATION EQUATE STATEMENTS

```

9383          000001          $FMT      =          1          ;FMT,HCI,ECI OR OFFSET CODE
9384          000002          $COMND     =          $FMT+1          ;OPERATION CODE
9385          000003          $PSEL      =          $FMT+2          ;PORT SELECT & BITS A16, A17
9386          000004          $WRDM      =          $FMT+3          ;WORD COUNT (2'S COMP)
9387          000006          $BUF       =          $FMT+5          ;BUFFER ADDR OR REGISTER TABLE POINTER
9388          000010          $SEC       =          $FMT+7          ;SECTOR ADDRESS OR 1ST REG ADDR
9389          000011          $TRK      =          $FMT+10         ;TRACK ADDRESS OF LAST REG ADDR
9390          000012          $CYL      =          $FMT+11         ;CYLINDER ADDR
9391          000014          $REG       =          $FMT+13         ;REGISTER STORAGE (IF ERROR)
9392          000016          $STATUS    =          $FMT+15         ;STATUS WORD (SET BY DRIVER)
    
```

;DRIVE'S HISTORY AND CURRENT INDICATOR STORAGE EQUATES

```

9396          000020          $WRDL     =          $FMT+17         ;WORD COUNT (NOT 2'S COMP)
9397          000022          $$SEC     =          $WRDL+2         ;SECTOR SIZE FOR CURRENT OPERATION
9398          000024          $CODE     =          $WRDL+4         ;PRESENT COMMAND SELECTION CODE
9399          000026          $PACK     =          $WRDL+6         ;WRITE DATA PACK INDICATOR
9400          000027          $PREVO    =          $WRDL+7         ;PREVIOUS COMMAND SELECTION CODE
9401          000030          $PATTC    =          $WRDL+10        ;PATTERN CODE
9402          000032          $PREVA    =          $WRDL+12        ;PREVIOUS ADDRESS - TRACK, SECTOR, CYLINDER
9403          000036          $OPERC    =          $WRDL+16        ;OPERATION COUNT
9404          000042          $POSIT    =          $WRDL+22        ;SEEK COUNT
9405          000046          $TRANS    =          $WRDL+26        ;TOTAL BITS XFERED COUNT (R & W)
9406          000052          $READ     =          $WRDL+32        ;TOTAL BITS READ COUNT
9407          000056          $TOTAL    =          $WRDL+36        ;TOTAL ERRORS (ALL TYPES) COUNT
9408          000060          $$SOFT    =          $WRDL+40        ;'SOFT' ERROR COUNT
9409          000062          $HARD     =          $WRDL+42        ;'HARD' ERROR COUNT
9410          000064          $SKI      =          $WRDL+44        ;'SKI' OR 'OCYL' ERROR COUNT
9411          000066          $MISPO   =          $WRDL+46        ;PROG DETECTED MISPOSITIONING ERROR S COUNT
9412          000070          $PASSC   =          $WRDL+50        ;PASS COUNTER
9413          000072          $FAIR    =          $WRDL+52        ;OPERATION QUEUE 'FAIRNESS' COUNT
    
```

;INDEX EQUATES TO THE NEXT OPERATION PARAMETERS

```

9417          000074          $NCODE   =          $WRDL+54        ;NEXT OPERATION CODE
9418          000075          $NPATC   =          $NCODE+1        ;NEXT PATTERN
9419          000076          $NSEC    =          $NCODE+2        ;NEXT SECTOR
    
```



```

9420      000077      SNTRK   =      $NCODE+3      ;NEXT TRACK
9421      000100      SNCYL   =      $NCODE+4      ;NEXT CYLINDER
9422      000102      SNWRDL  =      $NCODE+6      ;NEXT BUFFER SIZE
9423      000104      $NEXT   =      $NCODE+10     ;PARAMETER SELECTION INDICATOR
9424
9425      ;INDEX EQUATES FOR MAXIMUM/MINIMUM ADDRESSES
9426
9427      000106      MAXCYL  =      $NCODE+12     ;MAXIMUM CYLINDER ADDRESS
9428      000110      MINCYL  =      MAXCYL+2      ;MINIMUM CYLINDER ADDRESS
9429      000112      MAXTRK  =      MAXCYL+4      ;MAXIMUM TRACK ADDRESS
9430      000114      MINTRK  =      MAXCYL+6      ;MINIMUM TRACK ADDRESS
9431      000116      MAXSEC  =      MAXCYL+10     ;MAXIMUM SECTOR ADDRESS
9432      000120      MINSEC  =      MAXCYL+12     ;MINIMUM SECTOR ADDRESS
9433      000122      $FIRST  =      MAXCYL+14     ;FIRST OPERATION INDICATOR
9434
9435      ;BAD SECTOR/TRACK ADDRESS STORAGE AREA INDEX EQUATE
9436
9437      000124      $BDSEC  =      MAXCYL+16     ;BAD SECTOR STORAGE TABLE
9438
9439      ;DRIVE ID AREA INDEX EQUATE
9440
9441      000224      $DRVID  =      $BDSEC+100    ;DRIVE ID
9442
9443      ;RH11/RMO3 REGISTER EQUATES
9444
9445      000234      $RMCS1  =      $DRVID+10     ;RMO3 REGISTER STORAGE
9446      000236      $RMWC   =      $RMCS1+2
9447      000240      $RMBA   =      $RMCS1+4
9448      000242      $RMDB   =      $RMCS1+6
9449      000244      $RMCS2  =      $RMCS1+10
9450      000246      $RMDS   =      $RMCS1+12
9451      000250      $RMER1  =      $RMCS1+14
9452      000252      $RMAS   =      $RMCS1+16
9453      000254      $RMLA   =      $RMCS1+20
9454      000256      $RMDB   =      $RMCS1+22
9455      000260      $RMMR1  =      $RMCS1+24
9456      000262      $RMDB   =      $RMCS1+26
9457      000264      $RMSN   =      $RMCS1+30
9458      000266      $RMOF   =      $RMCS1+32
9459      000270      $RMDC   =      $RMCS1+34
9460      000272      $RMHR   =      $RMCS1+36
9461      000274      $RMMR2  =      $RMCS1+40
9462      000276      $RMER2  =      $RMCS1+42
9463      000300      $RMEC1  =      $RMCS1+44
9464      000302      $RMEC2  =      $RMCS1+46
9465
9466
9467      ;BLOCK FOR DRIVE 0
9468
9469      042472      000      000      DRIVED: .BYTE 0,0      ;DRIVE NUMBER
9470      042474      000005      .BLKW 5
9471      042506      042726      .WORD  +$RMCS1-$REG
9472      042510      000266      .BLKB  $RMEC2-$REG
9473
9474
9475      ;BLOCK FOR DRIVE 1
    
```

```

9476
9477 042776 001 000 DRIVE1: .BYTE 1,0 ;DRIVE NUMBER
9478 043000 000005 .BLKW 5
9479 043012 043232 .WORD .+$RMCS1-$REG
9480 043014 000266 .BLKB $RMEC2-$REG
9481
9482
9483 ;BLOCK FOR DRIVE 2
9484
9485 043302 002 000 DRIVE2: .BYTE 2,0 ;DRIVE NUMBER
9486 043304 000005 .BLKW 5
9487 043316 043536 .WORD .+$RMCS1-$REG
9488 043320 000266 .BLKB $RMEC2-$REG
9489
9490
9491 ;BLOCK FOR DRIVE 3
9492
9493 043606 003 000 DRIVE3: .BYTE 3,0 ;DRIVE NUMBER
9494 043610 000005 .BLKW 5
9495 043622 044042 .WORD .+$RMCS1-$REG
9496 043624 000266 .BLKB $RMEC2-$REG
9497
9498
9499 ;BLOCK FOR DRIVE 4
9500
9501 044112 004 000 DRIVE4: .BYTE 4,0 ;DRIVE NUMBER
9502 044114 000005 .BLKW 5
9503 044126 044346 .WORD .+$RMCS1-$REG
9504 044130 000266 .BLKB $RMEC2-$REG
9505
9506
9507 ;BLOCK FOR DRIVE 5
9508
9509 044416 005 000 DRIVES: .BYTE 5,0 ;DRIVE NUMBER
9510 044420 000005 .BLKW 5
9511 044432 044652 .WORD .+$RMCS1-$REG
9512 044434 000266 .BLKB $RMEC2-$REG
9513
9514
9515 ;BLOCK FOR DRIVE 6
9516
9517 044722 006 000 DRIVE6: .BYTE 6,0 ;DRIVE NUMBER
9518 044724 000005 .BLKW 5
9519 044736 045156 .WORD .+$RMCS1-$REG
9520 044740 000266 .BLKB $RMEC2-$REG
9521
9522
9523 ;BLOCK FOR DRIVE 7
9524
9525 045226 007 000 DRIVE7: .BYTE 7,0 ;DRIVE NUMBER
9526 045230 000005 .BLKW 5
9527 045242 045462 .WORD .+$RMCS1-$REG
9528 045244 000266 .BLKB $RMEC2-$REG
9529
9530
9531 ;GENERAL PURPOSE DPB - USED BY 'READHD', 'RECALT', 'OFFSET', & 'RTNCTR'
  
```

```

9532
9533 045532 000000 000000 177776 GENDPB: .WORD 0,0,-2,CYLDER
9534 045540 056150
9535 045542 000000 000000 045552 .WORD 0,0,GENREG,0
9536 045550 000000
9537 045552 000024 GENREG: .BLKW 24 ;REGISTER STORAGE IF ERROR
9538
9539 ;*****
9540 .SBTTL ERROR MESSAGES
9541 ;*****
9542
9543 .NLIST BEX
9544
9545
045622 044122 030067 030450 EM1: .ASCIZ /RH70(11) INTERRUPT OCCURRED (RMAS = 0)/
045671 125 042516 050130 EM2: .ASCIZ /UNEXPECTED ATTENTION OCCURRED/
045727 115 051501 041123 EM3: .ASCIZ /MASSBUS PARITY ERROR (MCPE=1)/
045765 115 051501 041123 EM4: .ASCIZ /MASSBUS PARITY ERROR (PAR=1)/
046022 042101 051104 051505 EM5: .ASCIZ /ADDRESS PLUG CHANGE BIT SET/
046056 044122 030067 030450 EM6: .ASCIZ /RH70(11) DIDN'T RESPOND TO ADDRESSING/
046124 047125 047503 051122 EM10: .ASCIZ /UNCORRECTABLE MASSBUS PARITY ERROR/
046167 106 052101 046101 EM11: .ASCIZ /FATAL MASSBUS PARITY ERROR/
046222 042520 051522 051511 EM12: .ASCIZ /PERSISTENT DEVICE UNSAFE/
046253 117 042520 040522 EM13: .ASCIZ /OPERATION NOT COMPLETED WITHIN TIME LIMIT/
046325 104 044522 042526 EM14: .ASCIZ /DRIVE WENT OFFLINE/
046350 047516 051040 051505 EM15: .ASCIZ /NO RESPONSE TO PORT REQUEST/
046404 042510 042101 051105 EM20: .ASCIZ /HEADER CRC ERROR/
046425 104 052101 020101 EM21: .ASCIZ /DATA CHECK ('DCK') ERROR/
046456 051127 052111 020105 EM22: .ASCIZ /WRITE CHECK ERROR - DATA CHECK ('DCK') SET/
046531 127 044522 042524 EM23: .ASCIZ /WRITE CHECK ERROR - DATA CHECK ('DCK') NOT SET/
046610 042510 042101 051105 EM24: .ASCIZ /HEADER READ ERROR - 'FMT' BIT DROPPED/
046656 042510 042101 051105 EM25: .ASCIZ /HEADER READ ERROR - HEADER COMPARE ('HCE') ERROR/
046737 106 051117 040515 EM26: .ASCIZ /FORMAT ERROR ('FER')/
046764 042510 042101 051105 EM27: .ASCIZ /HEADER COMPARE ('HCE') ERROR/
047021 115 051511 042503 EM30: .ASCIZ /MISCELLANEOUS DRIVE ERROR/

```

```

047053      117  042520  040522  EM31:  .ASCIZ  /OPERATION INCOMPLETE ('OPI') ERROR/
047116  051104  053111  020105  EM32:  .ASCIZ  /DRIVE TIMING ('DTE') ERROR/
047151      120  051101  052111  EM33:  .ASCIZ  /PARITY ('PAR') ERROR AFTER OPERATION STARTED/
047226  051127  052111  020105  EM34:  .ASCIZ  /WRITE CLOCK FAILURE ('WCF') ERROR/
047270  047111  040526  044514  EM35:  .ASCIZ  /INVALID ADDRESS ('IAE') ERROR/
047326  051127  052111  020105  EM36:  .ASCIZ  /WRITE LOCK ('WLE') ERROR/
047357      104  052101  020101  EM37:  .ASCIZ  /DATA CHECK ('DCK') SET DURING WRITE CHECK COMMAND/
047441      122  030510  020061  EM40:  .ASCIZ  /RH11 OR UNIBUS TRANSFER ERROR/
047477      102  051525  040440  EM41:  .ASCIZ  /BUS ADDRESS OR WORD COUNT INCORRECT/
047543      104  052101  020101  EM42:  .ASCIZ  /DATA COMPARE ERRORS - NO OTHER ERROR(S) DETECTED/
047624  040503  023516  020124  EM43:  .ASCIZ  /CAN'T MATCH DATA READ WITH A PATTERN/
047671      105  051122  051117  EM44:  .ASCIZ  /ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH11/
047755      105  041503  046040  EM45:  .ASCIZ  /ECC LOGIC FAILURE - POSITION REGISTER VALUE NOT VALID/
050043      102  051525  040440  EM46:  .ASCIZ  /BUS ADDRESS AND WORD COUNT NOT CONSISTENT/
050115      123  042505  020113  EM50:  .ASCIZ  /SEEK INCOMPLETE ('SKI') ERROR/
050153      120  047522  051107  EM51:  .ASCIZ  /PROGRAM DETECTED POSITIONING ERROR/
050216  051104  053111  020105  EM60:  .ASCIZ  /DRIVE UNSAFE ERROR/
050241      122  040515  000123  DH1:   .ASCIZ  /RMAS/
050246  051104  053111  020105  DH2:   .ASCIZ  /DRIVE  RMDS  RMER1  RMER2  RMMR2  RMAS/
050322  051104  053111  020105  DH3:   .ASCIZ  /DRIVE  REG ADR  DATA/
050350  051104  053111  020105  DH4:   .ASCIZ  /DRIVE  REG ADR  GOOD  BAD/
050407      044  046522  042101  DH6:   .ASCIZ  /$RMADR/
050416  051104  020126  046522  DH14:  .ASCII  /DRV RMCS1  RMCS2  RMDS  -RMER1  /
050462  046522  051115  020062  .ASCIZ  /RMMR2  RMER2  RMEC1  RMEC2/<CR><LF>
050521      122  053515  020103  DH15:  .ASCII  /RMWC  RMBA  RMDA  RMAS  RMLA  /
050571      122  042115  020102  .ASCIZ  /RMDB  RMMR1  RMDT/<CR><LF>
050620  046522  047123  020040  DH16:  .ASCIZ  /RMSN  RMOF  RMDC  RMMR2  STATUS/<CR><LF>
      050672  .EVEN
      .LIST  BEX
    
```

9546										
9547	050672	001342	000000		DT1:	.WORD	ATTN,0			
9548										
9549	050676	001216	034150	034152	DT2:	.WORD	DRIVE, RMERRS, RMERRS+2, RMERRS+4, RMERRS+6, ATTN,0			
9550	050704	034154	034156	001342						
9551	050712	000000								
9552										
9553	050714	001216	041230	041232	DT3:	.WORD	DRIVE, RD.ADR, RD.WRD,0			
9554	050722	000000								
9555										
9556	050724	001216	041450	041446	DT4:	.WORD	DRIVE, WRT.AD, WRT.WD, RD.WRD,0			
9557	050732	041232	000000							
9558										
9559	050736	001270	000000		DT6:	.WORD	\$RMADR,0			
9560										
9561	050742	000234	000244	000246	DT14:	.WORD	\$RMCS1, \$RMCS2, \$RMDS, \$RMER1, \$RMMR2, \$RMER2, \$RMEC1, \$RMEC2,0			
9562	050750	000250	000274	000276						
9563	050756	000300	000302	000000						
9564										
9565	050764	000236	000240	000242	DT15:	.WORD	\$RMWC, \$RMBA, \$RMDA, \$RMAS, \$RMLA, \$RMDB, \$RMMR1, \$RMDT,0			
9566	050772	000252	000254	000256						
9567	051000	000260	000262	000000						
9568										
9569	051006	000264	000266	000270	DT16:	.WORD	\$RMSN, \$RMOF, \$RMDC, \$RMMR2, \$STATUS,0			
9570	051014	000274	000016	000000						
9571										
9572										
9573										

.NLIST BEX

051022	051120	051505	047105	LIN2C:	.ASCIZ	/PRESENT ORDER = /
051043	040	050040	042522	LIN2P:	.ASCIZ	/ PREVIOUS ORDER = /
051067	052	042440	051122	LIN2S:	.ASCIZ	@* ERROR AT BAD TRACK/SECTOR@
051123	105	051122	051117	LINM3:	.ASCIZ	/ERROR AT C/
051136	052040	000		T:	.ASCIZ	/ T/
051141	120	042522	042523	LINN3:	.ASCIZ	/PRESENT ADDR = C/
051162	051440	000		S:	.ASCIZ	/ S/
051165	040	020040	051120	LINP3:	.ASCIZ	/ PREV ADDR = C/
051206	052123	051101	020124	LINS3:	.ASCIZ	/START CYL = /
051223	040	042440	042116	LINEN3:	.ASCIZ	/ END CYL = /
051240	020040	041501	052524	LINA3:	.ASCIZ	/ ACTUAL CYL = /
051260	020040	051124	020113	LINT3:	.ASCIZ	/ TRK = /
051271	040	046522	041504	LINCA3:	.ASCIZ	/ RMDC = /
051302	046522	040504	036440	LINDA3:	.ASCIZ	/RMDA = /
051312	046522	040502	036440	LINB3:	.ASCIZ	/RMBA = /
051322	020040	046522	041527	LINW3:	.ASCIZ	/ RMWC = /
051334	052123	051101	020124	LINST3:	.ASCIZ	/START TRK = /
051351	123	040524	052122	LINSS3:	.ASCIZ	/START SEC = /
051366	052502	043106	051105	LINM4:	.ASCIZ	/BUFFER ADDR = /
051405	040	051440	055111	LINS4:	.ASCIZ	/ SIZE = /
051417	040	040440	052103	LINX4:	.ASCIZ	/ ACTUAL NMBR WRDS XFRD = /
051452	047507	042117	042040	LIND5:	.ASCIZ	/GOOD DATA = /
051467	040	041040	042101	LINB5:	.ASCIZ	/ BAD DATA = /
051505	040	051440	041505	LINP5:	.ASCIZ	/ SECT POS = /
051523	110	040505	042504	LINS5:	.ASCIZ	/HEADER FROM ERROR SECTOR = /
051557	122	042515	030503	LINEP5:	.ASCIZ	/RMEC1 = /
051570	051040	042515	031103	LINE05:	.ASCIZ	/ RMEC2 = /

```

051602 042523 052103 051117 LINB6: .ASCIZ /SECTOR IS ECC CORRECTABLE /
051635 123 041505 047524 LINC6: .ASCIZ /SECTOR READ CORRECTLY /
051664 047503 051122 041505 LING6: .ASCIZ /CORRECTED ON /
051702 051040 052105 044522 LINR6: .ASCIZ / RETRIES/
051713 125 041516 051117 LINU06: .ASCIZ /UNCORRECTABLE AFTER /
051740 020040 047524 040524 LIN7M: .ASCIZ / TOTAL MISPOS ERR = /
051766 051117 042504 051522 LIN7O: .ASCIZ /ORDERS:/
051776 052040 052117 046101 LIN7P: .ASCIZ / TOTAL SEEKS = /
052016 052040 052117 046101 LIN7S: .ASCIZ / TOTAL SKI ERR = /
052040 020040 051105 047522 LIN7T: .ASCIZ / ERRORS:/
052052 020040 051127 051504 LIN7X: .ASCIZ / WRDS XFR:/
052066 020040 051127 051504 LIN7R: .ASCIZ / WRDS READ:/
052103 105 051122 051117 LIN8M: .ASCIZ /ERROR DURING RETRY/
052126 040504 040524 041440 LIN9B: .ASCIZ /DATA COMPARISON ERRORS/
052155 040 020040 020040 LIN9H: .ASCII / GOOD BAD/<CR><LF>
052203 114 041517 020040 .ASCIZ /LOC DATA DATA/<CR><LF>
052233 114 041517 020040 LIN9I: .ASCIZ /LOC DATA/<CR><LF>
052253 124 052117 046101 LIN9E: .ASCIZ /TOTAL COMPARE ERRORS = /
052303 124 042510 042040 LIN9G: .ASCIZ /THE DATA COMPARED OK/<CR><LF>
052332 051105 047522 020122 LIN10A: .ASCIZ /ERROR BURST BEGINS AT WORD /
052366 044440 020116 040504 LIN10B: .ASCIZ / IN DATA FIELD OF ERROR SECTOR/<CR><LF>
052427 105 051122 051117 LIN10C: .ASCII /ERROR WAS NOT IN THE DATA READ - /<CR><LF>
052472 041505 020103 047503 .ASCIZ /ECC CORRECTION CAN'T BE PERFORMED/
052534 041505 020103 047503 LIN10H: .ASCII /ECC CORRECTION RESULTS/<CR><LF>
052564 042101 051104 020040 .ASCIZ /ADDR BAD CORRECTED /<CR><LF>
052621 103 047117 042524 LIN11H: .ASCIZ /CONTENTS OF ERROR SECTOR (REPORTED ABOVE)/<CR><LF>
052675 101 042104 020122 .ASCIZ /ADDR DATA/<CR><LF>
052714 020040 LIN4SP: .ASCII / /
052716 040 LINS: .ASCII / /
052717 040 000 LINSPO: .ASCIZ / /
052721 122 052105 044522 LINX5: .ASCIZ /RETRIEVED BY A RDHD COMMAND/

```

.SBTTL TELETYPE MESSAGES

```

052755 104 044522 042526 UNTMSG: .ASCIZ /DRIVE/
052763 040 043117 046106 UNTOFF: .ASCIZ / OFFLINE/
052774 047440 046116 047111 UNTON: .ASCIZ / ONLINE/
053004 047040 052117 041040 UNTNOT: .ASCIZ / NOT BEING TESTED/
053026 040440 051114 040505 UNTASN: .ASCIZ / ALREADY BEING TESTED/
053054 047040 052117 040440 NOTRM: .ASCIZ / NOT AN RMO3/
053071 040 047516 020124 NOTPRS: .ASCIZ / NOT PRESENT/
053106 047040 052117 040440 NOTAVL: .ASCIZ / NOT AVAILABLE/
053125 040 047125 040523 NOTSAF: .ASCIZ / UNSAFE/
053135 125 044516 020124 SYSTAT: .ASCIZ /UNIT STATUS:/<CR><LF><LF>
053155 122 030115 000063 RMO3A: .ASCIZ /RMO3/
053162 051104 053111 020105 STATHD: .ASCII /DRIVE PERFORMANCE SUMMARY/<CR><LF>
053215 104 053122 050040 .ASCIZ /DRV PASS ORDERS SEEKS WRDS XFER WRDS READ /
053275 123 043117 020124 .ASCIZ /SOFT HARD SKI MISP OTHER/<CR><LF>
053331 104 047117 006505 PDONE: .ASCIZ /DONE/<CR><LF><LF>
053341 007 043077 052101 DROPNG: .ASCIZ <07>/?FATAL OR EXCESSIVE ERRORS/
053375 105 042116 047440 ENDPAS: .ASCIZ /END OF PASS/
053411 015 042412 042116 ENDTST: .ASCIZ <CR><LF>/END OF TEST/
053427 015 042012 044522 DEASSG: .ASCIZ <CR><LF>/DRIVE DEASSIGNED/
053452 005015 025052 025052 DRNUM: .ASCIZ <CR><LF>/***** DRIVE #/
053477 040 052123 051101 ASGND: .ASCIZ / STARTED/<CR><LF>
053512 005015 020077 046047 NEDCLK: .ASCIZ <CR><LF>/? 'L' OR 'P' CLOCK REQUIRED ON SYSTEM/<CR><LF>

```

```

053564 000056 PERIOD: .ASCIZ /./
053566 000077 QUES: .ASCIZ /?/
053570 047111 040526 044514 INVLD: .ASCIZ /INVALID COMMAND/<CR><LF>
053612 005015 047105 042524 ENTCOM: .ASCIZ <CR><LF>/ENTER COMMANDS: /<CR><LF>
053637 105 052116 051105 ENTDRV: .ASCIZ /ENTER I.D. FOR DRV #/
053664 005015 047105 042524 ENTLMT: .ASCIZ <CR><LF>/ENTER ADDRESS LIMITS FOR DRV #/
053725 105 052116 051105 ENTADR: .ASCIZ &ENTER BAD TRK/SEC ADRS FOR DRV #&
053766 000072 COLON: .ASCIZ /:/
053770 005015 040504 042524 DATEIS: .ASCIZ <CR><LF>/DATE: /
054001 015 047412 042520 IDIS: .ASCIZ <CR><LF>/OPERATOR I.D.: /
054023 015 005012 051104 HEDLIN: .ASCIZ <CR><LF><LF>/DRV DRV I.D./<CR><LF>
054046 047516 042516 005015 NONE: .ASCIZ /NONE/<CR><LF>
054055 077 044440 053116 BADENT: .ASCIZ /? INVALID ENTRY/<CR><LF>
054077 123 051531 042524 BUSY: .ASCIZ /SYSTEM BUSY.../<CR><LF>
054120 005015 051120 043517 INTDON: .ASCII <CR><LF>/PROGRAM INITIALIZATION COMPLETE/
054161 015 052012 050131 .ASCIZ <CR><LF>/TYPE A 'CONTROL C' TO ENTER COMMANDS/<CR><LF><LF>
054233 015 043012 044501 MERR1: .ASCIZ <CR><LF>/FAIL TO RETRIEVE BAD SPOT FILE ON /
054301 015 047412 042526 MERR2: .ASCIZ <CR><LF>/OVER 16 BAD SECTORS ARE DETECTED ON /

```

```

054352 .EVEN
.LIST BEX

```

9574  
9575  
9576  
9577  
9578  
9579  
9580  
9581  
9582  
9583  
9584  
9585  
9586  
9587  
9588  
9589  
9590  
9591  
9592

;PARAMETER ENTRY TABLE

```

PARLST: .WORD PAR1,8192.,MAXDL
          .WORD PAR2,-1,INTRVL
          .WORD PAR19,-1,PASCNT
          .WORD PAR3,15.,PATTEN
          .WORD PAR11,1,WCSEL
          .WORD PAR14,7,RATIO
          .WORD PAR16,1,ENDET
          .WORD PAR10,1,FORMAT
          .WORD PAR15,1,AUTOCK
          .WORD PAR20,1,NOTPRT
          .WORD PAR21,1,HEADER ;RANDOM ADDRESS FLAG
          .WORD 0 ;TABLE TERMINATOR

```

.NLIST BEX

```

054450 047105 042524 020122 ASKPAR: .ASCIZ /ENTER PARAMETERS: /
054474 027440 000040 SLASH: .ASCIZ @ / @

054500 044523 042532 020040 PAR1: .ASCIZ /SIZE /
054510 044515 052516 042524 PAR2: .ASCIZ /MINUTE /
054520 040520 052124 051105 PAR3: .ASCIZ /PATTERN/
054530 040515 041530 046131 PAR4: .ASCIZ /MAXCYL /
054540 044515 041516 046131 PAR5: .ASCIZ /MINCYL /
054550 040515 052130 045522 PAR6: .ASCIZ /MAXTRK /
054560 044515 052116 045522 PAR7: .ASCIZ /MINTRK /
054570 040515 051530 041505 PAR8: .ASCIZ /MAXSEC /
054600 044515 051516 041505 PAR9: .ASCIZ /MINSEC /
054610 047506 046522 052101 PAR10: .ASCIZ /FORMAT /
054620 040522 042116 046517 PAR11: .ASCIZ /RANDOM /

```

054630	040522	044524	020117	PAR14:	.ASCIZ	/RATIO	/
054640	044103	041505	020113	PAR15:	.ASCIZ	/CHECK	/
054650	047105	044504	043516	PAR16:	.ASCIZ	/ENDING	/
054660	040520	051523	051505	PAR19:	.ASCIZ	/PASSES	/
054670	042515	051523	043501	PAR20:	.ASCIZ	/MESSAGE	/
054700	042510	042101	051105	PAR21:	.ASCIZ	/HEADER	/

.EVEN

.LIST BEX

;PARAMETER TABLE POINTERS FOR ADDRESS LIMITS

9593									
9594									
9595									
9596									
9597	054710	054730		TABLE:	.WORD	TABLE0		;PARAMETER TABLE FOR DRIVE	0
9598	054712	054776			.WORD	TABLE1		;PARAMETER TABLE FOR DRIVE	1
9599	054714	055044			.WORD	TABLE2		;PARAMETER TABLE FOR DRIVE	2
9600	054716	055112			.WORD	TABLE3		;PARAMETER TABLE FOR DRIVE	3
9601	054720	055160			.WORD	TABLE4		;PARAMETER TABLE FOR DRIVE	4
9602	054722	055226			.WORD	TABLE5		;PARAMETER TABLE FOR DRIVE	5
9603	054724	055274			.WORD	TABLE6		;PARAMETER TABLE FOR DRIVE	6
9604	054726	055342			.WORD	TABLE7		;PARAMETER TABLE FOR DRIVE	7
9605									
9606									
9607									

;PARAMETER TABLE FOR ADDRESS LIMITS

9608	054730	054540	000000	042602	TABLE0:	.WORD	PAR5,0,MINCYL+DRIVED		
9609	054736	054530	000000	042600		.WORD	PAR4,0,MAXCYL+DRIVED		
9610	054744	054560	000004	042606		.WORD	PAR7,4,MINTRK+DRIVED		
9611	054752	054550	000004	042604		.WORD	PAR6,4,MAXTRK+DRIVED		
9612	054760	054600	000037	042612		.WORD	PAR9,31,MINSEC+DRIVED		
9613	054766	054570	000037	042610		.WORD	PAR8,31,MAXSEC+DRIVED,0		
9614	054774	000000							
9615									

9616	054776	054540	000000	043106	TABLE1:	.WORD	PAR5,0,MINCYL+DRIVE1		
9617	055004	054530	000000	043104		.WORD	PAR4,0,MAXCYL+DRIVE1		
9618	055012	054560	000004	043112		.WORD	PAR7,4,MINTRK+DRIVE1		
9619	055020	054550	000004	043110		.WORD	PAR6,4,MAXTRK+DRIVE1		
9620	055026	054600	000037	043116		.WORD	PAR9,31,MINSEC+DRIVE1		
9621	055034	054570	000037	043114		.WORD	PAR8,31,MAXSEC+DRIVE1,0		
9622	055042	000000							
9623									

9624	055044	054540	000000	043412	TABLE2:	.WORD	PAR5,0,MINCYL+DRIVE2		
9625	055052	054530	000000	043410		.WORD	PAR4,0,MAXCYL+DRIVE2		
9626	055060	054560	000004	043416		.WORD	PAR7,4,MINTRK+DRIVE2		
9627	055066	054550	000004	043414		.WORD	PAR6,4,MAXTRK+DRIVE2		
9628	055074	054600	000037	043422		.WORD	PAR9,31,MINSEC+DRIVE2		
9629	055102	054570	000037	043420		.WORD	PAR8,31,MAXSEC+DRIVE2,0		
9630	055110	000000							
9631									

9632	055112	054540	000000	043716	TABLE3:	.WORD	PAR5,0,MINCYL+DRIVE3		
9633	055120	054530	000000	043714		.WORD	PAR4,0,MAXCYL+DRIVE3		
9634	055126	054560	000004	043722		.WORD	PAR7,4,MINTRK+DRIVE3		
9635	055134	054550	000004	043720		.WORD	PAR6,4,MAXTRK+DRIVE3		
9636	055142	054600	000037	043726		.WORD	PAR9,31,MINSEC+DRIVE3		
9637	055150	054570	000037	043724		.WORD	PAR8,31,MAXSEC+DRIVE3,0		



```

9638 055156 000000
9639
9640 055160 054540 000000 044222 TABLE4: .WORD PAR5,0,MINCYL+DRIVE4
9641 055166 054530 000000 044220 .WORD PAR4,0,MAXCYL+DRIVE4
9642 055174 054560 000004 044226 .WORD PAR7,4,MINTRK+DRIVE4
9643 055202 054550 000004 044224 .WORD PAR6,4,MAXTRK+DRIVE4
9644 055210 054600 000037 044232 .WORD PAR9,31,MINSEC+DRIVE4
9645 055216 054570 000037 044230 .WORD PAR8,31,MAXSEC+DRIVE4,0
9646 055224 000000

```

```

9647
9648 055226 054540 000000 044526 TABLE5: .WORD PAR5,0,MINCYL+DRIVES
9649 055234 054530 000000 044524 .WORD PAR4,0,MAXCYL+DRIVES
9650 055242 054560 000004 044532 .WORD PAR7,4,MINTRK+DRIVES
9651 055250 054550 000004 044530 .WORD PAR6,4,MAXTRK+DRIVES
9652 055256 054600 000037 044536 .WORD PAR9,31,MINSEC+DRIVES
9653 055264 054570 000037 044534 .WORD PAR8,31,MAXSEC+DRIVES,0
9654 055272 000000

```

```

9655
9656 055274 054540 000000 045032 TABLE6: .WORD PAR5,0,MINCYL+DRIVE6
9657 055302 054530 000000 045030 .WORD PAR4,0,MAXCYL+DRIVE6
9658 055310 054560 000004 045036 .WORD PAR7,4,MINTRK+DRIVE6
9659 055316 054550 000004 045034 .WORD PAR6,4,MAXTRK+DRIVE6
9660 055324 054600 000037 045042 .WORD PAR9,31,MINSEC+DRIVE6
9661 055332 054570 000037 045040 .WORD PAR8,31,MAXSEC+DRIVE6,0
9662 055340 000000

```

```

9663
9664 055342 054540 000000 045336 TABLE7: .WORD PAR5,0,MINCYL+DRIVE7
9665 055350 054530 000000 045334 .WORD PAR4,0,MAXCYL+DRIVE7
9666 055356 054560 000004 045342 .WORD PAR7,4,MINTRK+DRIVE7
9667 055364 054550 000004 045340 .WORD PAR6,4,MAXTRK+DRIVE7
9668 055372 054600 000037 045346 .WORD PAR9,31,MINSEC+DRIVE7
9669 055400 054570 000037 045344 .WORD PAR8,31,MAXSEC+DRIVE7,0
9670 055406 000000

```

```

9671
9672
9673
9674 ;*****
9675 ;ROUTINE TO GET THE DATE AND THE OPERATOR FROM THE OPERATOR
9676 ;CALL:
9677 ;       JSR   PC,OPRDAT
9678 ;       RETURN
9679
9680 ;NOTE: THIS ROUTINE IS ENTERED ONLY AT INITIAL START
9681
9682

```

```

9683 055410 104401 055532 OPRDAT: TYPE ,ENTDAT ;'ENTER DATE'
9684 055414 104411 RDLIN ;READ THE ENTRY
9685 055416 012605 MOV (SP)+,R5 ;PUT THE ENTRY ADDRESS INTO R5
9686 055420 112537 001320 MOVB (R5)+,DATE ;STORE THE DATE
9687 055424 112537 001321 MOVB (R5)+,DATE+1 ;STORE THE DATE
9688 055430 112537 001322 MOVB (R5)+,DATE+2 ;STORE THE DATE
9689 055434 112537 001323 MOVB (R5)+,DATE+3 ;STORE THE DATE
9690 055440 112537 001324 MOVB (R5)+,DATE+4 ;STORE THE DATE
9691 055444 112537 001325 MOVB (R5)+,DATE+5 ;STORE THE DATE
9692 055450 112537 001326 MOVB (R5)+,DATE+6 ;STORE THE DATE
9693 055454 112537 001327 MOVB (R5)+,DATE+7 ;STORE THE DATE

```

```

9694 055460 005037 001330 CLR DATE+8. ;SET TERMINATOR
9695 055464 104401 055551 TYPE ,ENTID ;'ENTER OPERATOR I.D.'
9696 055470 104411 RDLIN ;READ THE ENTRY
9697 055472 012605 MOV (SP)+,R5 ;ENTRY ADDRESS
9698 055474 112537 001332 MOVB (R5)+,OPERID ;STORE THE I.D.
9699 055500 112537 001333 MOVB (R5)+,OPERID+1 ;STORE THE I.D.
9700 055504 112537 001334 MOVB (R5)+,OPERID+2 ;STORE THE I.D.
9701 055510 112537 001335 MOVB (R5)+,OPERID+3 ;STORE THE I.D.
9702 055514 112537 001336 MOVB (R5)+,OPERID+4 ;STORE THE I.D.
9703 055520 112537 001337 MOVB (R5)+,OPERID+5 ;STORE THE I.D.
9704 055524 005037 001340 CLR OPERID+6 ;SET TERMINATOR
9705 055530 000207 RTS PC ;RETURN
9706
9707 055532 005015 047105 042524 ENTDAT: .ASCIZ <CR><LF>/ENTER DATE: /
9708 055540 020122 040504 042524
9709 055546 020072 000
9710 055551 105 052116 051105 ENTID: .ASCIZ /ENTER OPERATOR I.D.: /
9711 055556 047440 042520 040522
9712 055564 047524 020122 027111
9713 055572 027104 020072 000
9714 055600 .EVEN
9715
9716 .SBTTL ROUTINE TO SIZE MEMORY
9717
9718 ;*****
9719 ;*CALL:
9720 ;* JSR PC,$SIZE
9721 ;* RETURN
9722 ;*$LSTAD WILL CONTAIN THE LAST AVAILABLE MEMORY LOCATION
9723
9724 055600 010046 $SIZE: MOV RO,-(SP) ;;SAVE RO ON THE STACK
9725 055602 010146 MOV R1,-(SP) ;;SAVE R1 ON THE STACK
9726 055604 013746 000004 MOV @#ERRVEC,-(SP) ;;SAVE PRESENT ERROR VECTOR PS & PC
9727 055610 013746 000006 MOV @#ERRVEC+2,-(SP)
9728 055614 010600 MOV SP,RO ;;SAVE THE STACK POINTER
9729 ;;SET THE ERRVEC PS TO THE PRESENT PS
9730 055616 104400 TRAP ;;PUSH OLD PSW AND PC ON STACK
9731 055620 012637 000006 MOV (SP)+,@#ERRVEC+2 ;;SAVE THE PSW IN @#ERRVEC+2
9732 055624 012737 055644 000004 MOV #2$,@#ERRVEC ;;SET FOR TIMEOUT
9733 055632 012701 020000 MOV #20000,R1 ;;FIRST ADDRESS
9734 055636 005711 1$: TST (R1) ;;TEST THIS ADDRESS
9735 055640 005721 TST (R1)+ ;;STEP TO NEXT ADDRESS
9736 055642 000775 BR 1$ ;;TRY ANOTHER
9737 055644 162701 000002 2$: SUB #2,R1 ;;DROP BACK
9738 055650 010006 MOV RO,SP ;;RESTORE THE STACK
9739 055652 012637 000006 MOV (SP)+,@#ERRVEC+2 ;;RESTORE ERROR VECTOR
9740 055656 012637 000004 MOV (SP)+,@#ERRVEC
9741 055662 010137 055674 MOV R1,$LSTAD ;;LAST ADDRESS
9742 055666 012601 MOV (SP)+,R1 ;;RESTORE R1
9743 055670 012600 MOV (SP)+,RO ;;RESTORE RO
9744 055672 000207 RTS PC
9745 055674 000000 $LSTAD: .WORD 0 ;;CONTAINS THE LAST ADDRESS
9746
9747 .SBTTL BUSADR - GET BUS ADDRESS AND VECTOR ADDRESS FOR RH11
9748 ;THIS ROUTINE IS USED TO INSURE THE BUS ADDRESS
9749 ;OF THE RH11 IS SETUP FOR THE PROPER ADDRESS.

```

```

9750 ; IT WILL ALSO READ THE ADDRESS FROM THE TTY IF
9751 ; REQUIRED.
9752 ; NOTE: THIS ROUTINE DESTROYS R0-R4
9753 ; CALL
9754 ;
9755 ; JSR PC,BUSADR
9756 ; RETURN
9757 ;
9758 055676 005737 001356 BUSADR: TST CHGADR ; INPUT FROM TTY REQUESTED?
9759 055702 002036 BGE 3$ ; NO--BRANCH
9760 055704 005037 001356 CLR CHGADR ; YES--CLEAR THE REQUEST FLAG
9761 055710 104401 001201 TYPE $CRLF ; TYPE A CR-LF
9762 055714 012700 001270 1$: MOV $RMADR,R0 ; FIRST ADDRESS
9763 055720 104401 056016 TYPE MRMCSI ; "RMCSI="
9764 055724 011046 MOV (R0),-(SP) ; PRESENT RMCSI ADDRESS
9765 055726 104402 TYPOC ; TYPE IT
9766 055730 104401 052716 TYPE ,LINSP ; 2 SPACES
9767 055734 104411 RDLIN ; GET THE ENTRY
9768 055736 012601 MOV (SP)+,R1 ; ADDRESS OF ASCII TEXT
9769 055740 004537 056040 JSR R5,CK.NUM ; ENTER AND STORE THE NEW ADDRESS
9770 055744 000763 BR 1$ ; ERROR EXIT
9771 055746 012700 001272 2$: MOV $RMVEC,R0 ; VECTOR ADDRESS
9772 055752 104401 056027 TYPE MRHVEC ; "RHVEC="
9773 055756 011046 MOV (R0),-(SP) ; PRESENT RH11 VECTOR ADDRESS ON THE STACK
9774 055760 104402 TYPOC ; TYPE IT
9775 055762 104401 052716 TYPE ,LINSP ; 2 SPACES
9776 055766 104411 RDLIN ; READ THE ENTRY
9777 055770 012601 MOV (SP)+,R1 ; ASCII TEXT ADDRESS
9778 055772 004537 056040 JSR R5,CK.NUM ; ENTER AND STORE NEW ADDRESS
9779 055776 000763 BR 2$ ; ERROR EXIT
9780 056000 012700 001270 3$: MOV $RMADR,R0 ; FIRST ADDRESS OF NEW PARAMETERS
9781 056004 012701 034316 MOV $RMADR,R1 ; FIRST ADDRESS OF WHERE TO PUT THEM
9782 056010 012021 MOV (R0)+,(R1)+ ; BUS ADDRESS
9783 056012 012021 MOV (R0)+,(R1)+ ; VECTOR ADDRESS
9784 056014 000207 RTS PC ; RETURN
9785
9786 056016 046522 051503 020061 MRMCSI: .ASCIZ @RMCSI = @
9787 056024 020075 000
9788 056027 122 053110 041505 MRHVEC: .ASCIZ @RHVEC = @
9789 056034 036440 000040
9790
9791 .SBTTL CK.NUM - CHECK NUMBER (OCTAL)
9792 ; THIS ROUTINE CHECKS AN ASCIZ STRING FOR LEGAL CHARACTERS
9793 ; AND FORMS AN OCTAL NUMBER IN R2
9794 ; CALL:
9795 ; MOV $ADR,R1 ; ADDRESS OF ASCIZ STRING
9796 ; JSR R5,CK.NUM ; R5 CHANGED
9797 ; RET ; ERROR EXIT
9798 ; RET ; NORMAL EXIT
9799 056040 010246 CK.NUM: MOV R2,-(SP) ; SAVE R2
9800 056042 010346 MOV R3,-(SP) ; SAVE R3
9801 056044 010446 MOV R4,-(SP) ; SAVE R4
9802 056046 012703 000006 MOV #6,R3 ; MAX OCTAL DIGITS IN THE NUMBER
9803 056052 005002 CLR R2 ; FINAL OCTAL VALUE
9804 056054 112104 1$: MOV (R1)+,R4 ; GET CURRENT POINTED BYTE
9805 056056 001424 BEQ 3$ ; BRANCH, IF TERMINATOR DETECTED
    
```

9806	056060	120427	000060	CMPB	R4,#'0	;SMALLER THAN ASCII-0 ?
9807	056064	103425		BLO	5\$	;YES,ERROR EXIT
9808	056066	120427	000067	CMPB	R4,#'7	;LARGER THAN ASCII-7 ?
9809	056072	101022		BHI	5\$	;YES,ERROR EXIT
9810	056074	006302		ASL	R2	;SHIFT LEFT
9811	056076	103420		BCS	5\$	
9812	056100	006302		ASL	R2	;ONE
9813	056102	103416		BCS	5\$	
9814	056104	006302		ASL	R2	;OCTAL DIGIT
9815	056106	103414		BCS	5\$	;ERROR IF CARRY BIT SET
9816	056110	042704	177770	BIC	#177770,R4	;CHOP OFF HIGHER BITS
9817	056114	060402		ADD	R4,R2	;APPENDING CURRENT DIGIT TO NUMBER
9818	056116	005303		DEC	R3	;DECREMENT BYTE COUNT
9819	056120	001401		BEQ	2\$	;BRANCH,IF LAST BYTE
9820	056122	000754		BR	1\$	;LOOPING BACK
9821	056124	112104		2\$: MOVB	(R1)+,R4	;CHECK TERMINATOR
9822	056126	001004		BNE	5\$	;ERROR EXIT
9823	056130	005702		3\$: TST	R2	;FINAL VALUE = 0
9824	056132	001401		BEQ	4\$	;YES,THEN NOT REPLACE THE ORIGINAL VALUE
9825	056134	010210		MOV	R2,(R0)	;REPLACE THE ORIGINAL VALUE
9826	056136	005725		4\$: TST	(R5)+	;ADJUST FOR NORMAL RETURN
9827	056140	012604		5\$: MOV	(SP)+,R4	;RESTORE R4
9828	056142	012603		MOV	(SP)+,R3	;RESTORE R3
9829	056144	012602		MOV	(SP)+,R2	;RESTORE R2
9830	056146	000205		RTS	R5	;EXIT

CYLDER: .BLKW 256. ;ONE SECTOR WORD CTR MAX SIZE  
ENDPGM = .

.NLIST BEX

057150	005015	040515	047111	TITLE:	.ASCII	<CR><LF>/MAINDEC-11-DZRM8/<CR><LF>
057174	046522	031460	050040		.ASCIZ	ARM03 PERFORMANCE EXERCISER 3<CR><LF><LF>
057233	015	052012	020117	LOADRV:	.ASCII	<CR><LF>/TO TEST DRIVE 0, REPLACE THE 'XXDP' PACK ON DRIVE 0/<CR><LF>
057322	044527	044124	040440		.ASCII	/WITH ANOTHER PACK, CLEAR MEMORY LOCATION 40,/<CR><LF>
057400	047101	020104	042522		.ASCIZ	/AND RESTART THE PROGRAM/<CR><LF>
057432	005015	054523	052123	NOLOAD:	.ASCIZ	<CR><LF>/SYSTEM HAS 16K MEMORY, 'XXDP' LOADER WILL BE OVERWRITTEN/<CR><L

.LIST BEX

9838 000001 .END  
9839

ABASE = 176700	2271#	2561	2602			
ABNRM 026674	3652	6681#				
ACDW1 = 000000	2561	2604				
ACDW2 = 000000	2561	2605				
ACK = 000123	2456#					
ACPUOP= 000000	2561	2576				
ACTDRV 034234	8090#	8358*	8409*	8727*	8736*	8985
ACTSTR 034235	8096#	8987*	9001*			
ADDW0 = 000000	2561					
ADDW1 = 000000	2561					
ADDW10= 000000	2561					
ADDW11= 000000	2561					
ADDW12= 000000	2561					
ADDW13= 000000	2561					
ADDW14= 000000	2561					
ADDW15= 000000	2561					
ADDW2 = 000000	2561					
ADDW3 = 000000	2561					
ADDW4 = 000000	2561					
ADDW5 = 000000	2561					
ADDW6 = 000000	2561					
ADDW7 = 000000	2561					
ADDW8 = 000000	2561					
ADDW9 = 000000	2561					
ADEVCT= 000000	2561	2567				
ADEVN = 000000	2561	2603				
AENV = 000000	2561	2572				
AENVN = 000000	2561	2573				
AFATAL= 000000	2561	2564				
AMADR1= 000000	2561	2589				
AMADR2= 000000	2561	2593				
AMADR3= 000000	2561	2596				
AMADR4= 000000	2561	2599				
AMAMS1= 000000	2561	2583				
AMAMS2= 000000	2561	2591				
AMAMS3= 000000	2561	2594				
AMAMS4= 000000	2561	2597				
AMSGAD= 000000	2561	2569				
AMSGLG= 000000	2561	2570				
AMSGTY= 000000	2561	2563				
AMTYP1= 000000	2561	2584				
AMTYP2= 000000	2561	2592				
AMTYP3= 000000	2561	2595				
AMTYP4= 000000	2561	2598				
AOE = 001000	2361#					
APASS = 000000	2561	2566				
APRIOR= 000000	2561					
APTCSU= 000040	7340	7446#				
APTENV= 000001	7248	7333	7402		7444#	
APTSIZ= 000200	3312	7443#				
APTSP0= 000100	7335	7404	7445#			
ASGND 053477	3588	9573#				
ASGN1 024250	6210#					
ASGN2 024324	3473	6209	6222#			
ASGN3 024406	6219	6230	6237#			
ASGN4 024520	6238	6260#				

ASGN6	024522	6245	6251#												
ASGN7	024534	6244	6263#												
ASKPAR	054450	3407	9592#												
ASNERR	026544	6221	6235	6262	6272	6298	6318	6638#							
ASNLST	001544	2751#	3544	3595*	5902	5909	6212	6228	6237	6287	6289*	6311	6320	6334	
		6657*	6671	6753*	6756										
ASNMSG	026564	6211#	6216*	6227*	6261*	6266*	6268*	6270*	6297*	6317*	6646#				
ASSIGN	024242	6208#	6277	6360	6365	6369									
ASWREG=	000000	2561	2574												
ATA =	100000	2348#													
ATABIT	034304	3595	5909	6212	6228	6237	6287	6289	6311	6334	6657	6753	8162#	8325	
		8421	8527	8908	8927	8935	8936	8956	9042						
AATESTN=	000000	2561	2565												
ATTN	001342	2627#	7228*	9547	9549										
ATO =	000001	2374#													
AT1 =	000002	2375#													
AT2 =	000004	2376#													
AT3 =	000010	2377#													
AT4 =	000020	2378#													
AT5 =	000040	2379#													
AT6 =	000100	2380#													
AT7 =	000200	2381#													
AUNIT =	000000	2561	2568												
AUSWR =	000000	2561	2575												
AUTOCK	001502	2704#													
AVAIL	001612	2761#	3547	3589	3593*	3605	3608	3631	3655						
AVECT1=	000254	2272#	2561	2600											
AVECT2=	000000	2561	2601												
A16 =	000400	2284#													
A17 =	001000	2285#													
BADENT	054055	6621	9573#												
BADSEC	001362	2636#	3651*	5377*	5449	6030	6042	6054	6066	6078					
BAI =	000010	2302#													
BEGCOD	001516	2732#	6398	6399											
BEGPAT	001514	2731#	6401												
BEGSIZ	001520	2739#	6403	6404											
BIT0 =	000001	2256#	6534	6563											
BIT00 =	000001	2246#	2256	4353	4989	5110	6285								
BIT01 =	000002	2245#	2255	3728	4856	8401	8649								
BIT02 =	000004	2244#	2254	3455	4402	4985	5138	5145	6432	6440					
BIT03 =	000010	2243#	2253	3821	4188	8867	9159								
BIT04 =	000020	2242#	2252	3821	3833	8902									
BIT05 =	000040	2241#	2251	4289	8252	8669	8882	9037							
BIT06 =	000100	2240#	2250	3902	3903	3993	4008	4848	5620	6202	7107	8334	8392	8466	
		8767	9219												
BIT07 =	000200	2239#	2249	3714	3836	4848	8334	8601	8748	8867	8882	8902	8931	9191	
BIT08 =	000400	2238#	2248	3830	8334										
BIT09 =	001000	2237#	2247	3726	9035										
BIT1 =	000002	2255#	6559	6573											
BIT10 =	002000	2236#	3724	3848	3856	7236	8651								
BIT11 =	004000	2235#	3722	3851	8299	8428	8620	8971							
BIT12 =	010000	2234#	3720	3859	3902	3903	3922	4114	4992	5608	8294	8316	8334	8403	
		8436	8616	8635	8647	8660	8892	8894	9098	9154	9220				
BIT13 =	020000	2233#	3839	3865	4160	4256	6933	7243	8386	8842	9101				
BIT14 =	040000	2232#	3701	3703	3728	3824	3827	3865	3983	4034	4078	4118	4224	4239	
		8398	8433	8829	8967	9063	9109	9113	9217						



CMPRX	013420	4438	4478	4483	4499	4507	4510#							
CMSEC	001414	2653#	4416*	4434	4488*	4489	4491*	4503						
CMSTR	012734	4419#												
CMSTR2	013052	4433	4436	4440#	4502	4505								
CMTRK	001415	2654#	4492*	4493	4495*									
COLON	053766	6095	6100	9573#										
COMTBL	002122	2816#	5238	6400										
CR =	000015	2171#	2608#	7203	7379	7389	9545	9573	9707	9837				
CRLF =	000200	2172#	7350	7389										
CYLDER	056150	4105*	4106	4109*	4143*	5607	5662	5665	6539	9533	9832#			
CYLIMT	001446	2667#	3507	5096*	5102	5106	6439*	6446	6454	6455				
DATAPK	025150	6182	6359#											
DATA0	002542	2913	2929	2932#										
DATA1	002602	2914	2915	2916	2917	2918	2919	2920	2921	2922	2923	2924	2925	2926
		2927	2928	2930	2949#									
DATE	001320	2622#	6324	6327	9686*	9687*	9688*	9689*	9690*	9691*	9692*	9693*	9694*	
DATEIS	053770	6326	9573#											
DCK =	100000	2367#												
DCKER	007312	3864	3875#											
DCKER1	007432	3898#	4178											
DDISP =	177570	2178#	2544	3300										
DEASGN	024606	6172	6281#											
DEASSG	053427	3562	9573#											
DH1	050241	3224	9545#											
DH14	050416	5454	9545#											
DH15	050521	5463	9545#											
DH16	050620	5466	9545#											
DH2	050246	3231	3252	9545#										
DH3	050322	3238	9545#											
DH4	050350	3245	9545#											
DH6	050407	3259	9545#											
DISPLA	001156	2544#	3300*	3308*	7235*									
DISPLY=	104414	3746	3780	3800	3811	3883	3897	3918	3955	3965	3987	4029	4054	4074
		4114	4140	4155	4177	4183	4201	4211	4220	4235	4251	4271	4282	4301
		4319	4324	4325	4326	4329	4332	4335	4338	4341	4344	4347	4350	4374
		4392	4539	4544	4545	4546	4559	4562	4565	4574	4577	4633	4638	4670
		4673	4676	4679	4682	4685	4688	4691	4693	4694	4717	4723	4728	4730
		4839	5398	5401	5418	5444	5446	5451	5452	5453	5454	5455	5458	5463
		5466	5477	5478	5491	5494	5500	5506	5513	5527	5530	5533	5539	5542
		5543	5547	5548	5552	5560	5563	5564	5567	5575	5578	5580	5583	5587
		5591	5596	5599	5606	5610	5614	5622	5625	5628	5633	5639	5643	5652
		5654	5661	5664	5667	5668	5669	5675	5678	5679	5682	5688	5689	5695
		5701	5707	5713	5720	5722	5730	5731	5737	5742	5745	5750	5755	5756
		5765	5770	5775	5778	5781	5782	5791	5805	6912	7979#			
DISPRE	000174	2475#	3308											
DLT =	100000	2314#												
DONE	007004	3716	3821#											
DPE =	020000	2433#												
DPINT	034210	8050#	8263	8266	8342*	8368	8813	8838	8957	8959*	9026	9044	9049	9057*
DPR =	000400	2341#												
DPROS	034220	8063#	8374	8422*	8460*	8816	9028	9046	9051	9066*				
DRIVE =	001216	2626#	7229*	9549	9553	9556								
DRIVED	042472	2807	6333	9469#	9608	9609	9610	9611	9612	9613				
DRIVE1	042776	2808	9477#	9616	9617	9618	9619	9620	9621					
DRIVE2	043302	2809	9485#	9624	9625	9626	9627	9628	9629					
DRIVE3	043606	2810	9493#	9632	9633	9634	9635	9636	9637					



































SPREVA= 000032	5026	5226*	5227*	5230*	5231*	5232*	5297*	5298*	5299*	5581	5585	5589	5597
	8783*	8784*	9402*										
SPREVO= 000027	5222*	5223*	5241	5248	5295*	5428	8782*	9400*					
SPSEL = 000003	9385*												
SPWRAD 032216	7485*												
SPWRDN 032056	3291	7452*	7480										
SPWRMG 032212	7483*												
SPWRUP 032130	7462	7468*											
SQUES 001200	2554*	7186	7261	7389	7708								
SRAND 033350	5038	5129	5209	5287	7760*								
SRDCHR 033174	7721*	7975											
SRDDEC= ***** U	7977												
SRDLIN 030510	7146*	7976											
SRDOCT= ***** U	7977												
SRDSZ = 000001	7742*												
SREAD = 000052	4862*	4863*	5751	6700	6703	9406*							
SREG = 000014	6389	9391*	9471	9472	9479	9480	9487	9488	9495	9496	9503	9504	9511
	9512	9519	9520	9527	9528								
SRESRE 033510	7819*	7978											
SRETRY 015134	3887	3973	4041	4086	4126	4162	4190	4260	4290	4306	4815*	4833	
SRMADR 001270	2610*	3345*	3346	3352	9559	9762	9780						
SRMAS = 000252	9452*	9565											
SRMBA = 000240	4389	4609	4640	4661	4701	4721	4850	5475	5528	5629	5640*	5641	9447*
	9565												
SRMCS1= 000234	3699	3701	4365	5222	5295	5422	8782	9445*	9446	9447	9448	9449	9450
	9451	9452	9453	9454	9455	9456	9457	9458	9459	9460	9461	9462	9463
	9464	9471	9479	9487	9495	9503	9511	9519	9527	9561			
SRMCS2= 000244	3824	3983	4034	4078	4118	4224	4239	4256	4367	9449*	9561		
SRMDA = 000242	5053	5300	5561	5612	5843	5844	9448*	9565					
SRMDB = 000256	5644	9454*	9565										
SRMDC = 000270	3678	4106	4864	5054	5301	5565	5600	5845	9459*	9569			
SRMDS = 000246	3703	3827	3856	9450*	9561								
SRMDT = 000262	6443*	9456*	9565										
SRMEC1= 000300	3875	3877	4625	5676	9463*	9561							
SRMEC2= 000302	3879	4643	5680	6351	6394	9464*	9472	9480	9488	9496	9504	9512	9520
	9528	9561											
SRMER1= 000250	3830	3833	3836	3839	3842	3845	3848	3851	3854	3859	3862	3903	3920
	3922	3962	3993	4006	4008	4063	4098	4369	4826	4829	9451*	9561	
	3865	3867	4371	9462*	9561								
SRMER2= 000276	9460*												
SRMHR = 000272	9453*	9565											
SRMLA = 000254	9455*	9565											
SRMHR1= 000260	9461*	9561	9569										
SRMHR2= 000274	9458*	9569											
SRMOF = 000266	9457*	9569											
SRMSN = 000264	2611*	3342*	3347	3353	9771								
SRMVEC 001272	4384	4412	4610	4703	5472	5531	5646	9446*	9565				
SRMWC = 000236	6779*												
SRTNAD 027272	7979												
SR2A = ***** U	7803*	7977											
SSAVRE 033452	7461*	7469	7470*	7471*	7489*								
SSAVR6 032226	4636	5818	5964	5994	5999	6004	6009	6018	6092	6097	6102	7075*	
SSB2D 030246	5802	7092*											
SSB2O 030276	4416	4792*	4994	5174	5227	5253*	5300*	5308*	5550	6459*	6524*	6531*	6532
SSEC = 000010	6561*	8784	9388*										
SSETUP= 000156	3263*	3286	3287	3289	3291	3293	3295	3327	6762	7227	7258	7260	7645





B01

\$4OCAT= \*\*\*\*\* U  
= 057527

7245													
2470#	2474#	2486	2487#	2489#	2491#	2492#	2498	2499#	2501#	2503#	2515	2522#	
2557	2841#	2894#	2900#	3284	3341	3344	3606	3626	3822	3825	3831	3834	
3837	3840	3843	3846	3849	3852	3860	3863	4641	6780	6852	7202#	7205#	
7231	7261	7308#	7389	7442#	7464	7488	7638#	7643	7748	7893#	7933#	7980	
9272#	9273#	9274#	9275#	9276#	9277#	9278#	9279#	9280	9470#	9471	9472#	9478#	
9479	9480#	9486#	9487	9488#	9494#	9495	9496#	9502#	9503	9504#	9510#	9511	
9512#	9518#	9519	9520#	9526#	9527	9528#	9537#	9545#	9573#	9714#	9832#	9833	

.\$ASTA= \*\*\*\*\* U  
.\$X = 001100

7394 7397  
2498# 2503



DO1

.SCATC	2128#	2468
.SCHTA	2128#	2516
.SDB2D	2128#	7832
.SDB2O	2128#	7895
.SEOP	2128#	6690
.SERRO	2128#	7213
.SERRT	2128#	7262
.SPOME	2128#	7448
.SRAND	2128#	7749
.SREAO	2128#	7640
.SSAVE	2128#	7786
.SSIZE	2128#	9716
.STRAP	2128#	7935
.STYPD	2128#	7572
.STYPE	2128#	7310
.STYPO	2128#	7494

. ABS. 057527 000

ERRORS DETECTED: 0

DSKZ:DZRMBA,DSKZ:DZRMBA,SEQ/NL:MD:MC:CND:TOC/DOC/SOL/CRF=DSKM:RMDRV4.P11,DSKM:DZRMBA.P11  
RUN-TIME: 35 27 2 SECONDS  
RUN-TIME RATIO: 282/65=4.3  
CORE USED: 42K (83 PAGES)

DOCUMENT PAGES: 209