

IDENTIFICATION

B 1

SEQ 0001

PRODUCT CODE: AC-C644B-MC
PRODUCT NAME: CEMKABO 11/70 MAIN MEMORY DIAG
DATE CREATED: 31-JUL-79
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: KAY R. FISHER

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1978, 1979 BY DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1.0 GENERAL PROGRAM I
NFORMATION

- 1.1 Program Purpose (Abstract)
- 1.2 System Requirements
- 1.3 R
elated Documents And Standards
- 1.4 Diagnostic Hierarchy Prerequisites
- 1.5 As
sumptions

2.0 OPERATING INSTRUCTIONS

- 2.1 Loading Starting Procedures
- 2.2 Special Environments
- 2.3 Program Options
- 2.4 Execution Times

3.0
ERROR INFORMATION

- 3.1 Error Reporting
- 3.2 Error Abbreviations
- 3.3 Error
Halts

4.0 PROGRESS REPORTS

5.0 DEVICE INFORMATION TABLES (CSR'S)

- 5.1 Address(s) Of The CSR
- 5.2 Allocation Of CSR Bits
- 5.3 CSR Bit Summary

6.0 SUB-TEST SUMMARIES

- 6.1 Tests
- 6.2 Patterns
- 6.3 Multiport Tests

7.0 PROGRAM FEATURES

- 7.1 Fast Data Access Rates
- 7.2 Bank Zero Testing
- 7.3 Differences In Core Testing With 0-2 MEG (DEMJA)
- 7.4 Memory Configuratio
n Map
- 7.5 Everything You've Always Wanted To Know About SUPERMAC ...

7.6 Ban
7.5 Boards (MK11)
7.7 Memory Management Mapping
7.8 Listing Format

8.0
MULTIPOINT SYSTEM ORGANIZATION

8.1 Starting Slaves
8.2 Multipoint Testing

9.0 FLOW CHARTS

1.0 GENERAL PROGRAM INFORMATION

1.1 Program Purpose (Abstract)

- a. Intended for use on all PDP-11/70's and PDP-11/74's including multi-processor multiported MKA11 configurations.
- b. This program will be used by system managers and operators to determine the correct operation of main memory and also it will be primarily used by field service and manufacturing to isolate failures to the memory and to isolate failures within the memory to the correct box and array.
- c. The object of this software is to functionally test and verify all main memory functions as fast as possible.
- d. There is the capability of testing mixed configurations (MJ11 MK11 & MKA11) on a variable number of CPU's (1-4).
- e. This program will functionally test MK11's, MKA11's, & MJ11's.
- f. It has special a maintenance mode (Field Service Mode) to provide specific functional capabilities.

1.2 System Requirements

1.2.1 Hardware Requirements -

1.2.1.1 Single Port Tests -

PDP-11/70 or PDP-11/74 (PU and 64k (16 Bit Words) of Memory

SEU 0005

1.2.1.2 Multiport Test -

Each CPU must have a KW11L, a IIST, and a Multiprocessor Boot.

The use of the IIST and Multiprocessor Boot may be bypassed via sta

rt at 200.

Additionally each system will have the following minimum memory requirements.

<u># of CPU's</u>	<u>MKA11 Memory</u>
1	64K (16 Bit Words)
2	64K (16 Bit Words)
3	80K (16 Bi
4	96K (16 Bit Words)

There must be no UNIBUS response to U NIBUS Address 752100 thru 752136.

If a special device or memory (other than MK 11) resides there it must be removed in order to run this diagnostic. The lower 16K of physical memory must have no uncorrectable errors (DBE's).

1.2.2 Software Requirements -

This program is designed to run stand alone or under any of the following monitors:

- XXDP
- ACT
- APT

1.3 Related Documents and Standards

1. PDP-11/70 Processor Handbook
2. PDP-11/70 Processor Handbook
3. MJ11 Maintenance Manual
4. MK11 Maintenance Manual
5. MKA11 Maintenance Manual
6. Programming Practices (175-003-009-02)
7. System Macro Manual (MAINDEC-11-DXQAC-C-D)
8. SUPER-MAC Reference Guide (130-380-007-00)
9. AP
T11.MAN (APT/11-317-07-09)
10. ACT11.MAN (AUTOCAT-11-QZAUB-B-D)

1.4 Diagnostic Hierarchy Prerequisites

If the program hangs, dies, goes out to lunch, heads west, hiccups, vomits, eats itself, stutters, bombs, or in any way misbehaves, then:

1. Try it again with Cache off (reference Section 2.3.3.1)
2. Inhibit relocation (reference section 2.3.1)
- 3
Try CPU diagnostics
4. Try Memory Management Diagnostics
5.
Try Cache Diagnostics
6. Try UNIBUS MAP Diagnostics

1.5 Assumptions

This program assumes the correct operation of the (CPU, Memory Management, Cache, and the UNIBUS Map. This program occupies (initially) Bank 0 (0-16K). The XXDP loaders are in bank 1.

2.0 OPERATING INSTRUCTIONS

2.1 Loading & Starting Procedures

2.1.1 Quick Starting -

1. Load address 200
2. Set switch register for options (normally 0)
3. Start

2.1.2 Stopping -

1. Set SW8. or
2. Type control 'C' (Reference section 2.3.4.1).

2.1.3 Restarting (Preserve Configuration Table) -

1. Load address 202
2. Set s

witch register for options (Normally 0)

SEQ 0010

3. Start

2.1.4 Starting (w
ith Multiprocessor and NO IIST or Boot) -

1. Load address 204
2. Set switch register for options (Normally 0)
3. Start

2.1.
5 Switch Register Options -

SWITCH	USE
15	HALT ON ERROR
14	LOOP ON TEST
13	INHIBIT ERROR TYPEOUTS
12	INHIBIT RELOCATION
11	
10	QUICK VERIFY / INHIBIT MARGIN TESTING BELL ON ERROR
9	LOOP ON ERROR
8	HALT PROGRAM (UNRELOCATED & RESTORE L OADER'S)
7	DETAILED ERROR REPORTS
6	PRINT CONFIGURATI
5	LIMIT MAX ERRORS PER BANK
4	FAT TERMINAL (1 ON MAP
32	COLUMNS OR BETTER)
3	TEST MODE - SEE DOCUMENT
2	T
1	EST MODE - SEE DOCUMENT
0	TEST MODE - SEE DOCUMENT
	DETECT SINGLE BIT ERRORS

2.2 Special Environments

2.2.1 xxDP -

The first pass will be a quick verify pass if and only if it is in chain mode.

2.2.2 ACT & APT Automatic Mode -

The program will not create double bit errors (DBE's) after the 1st pass.

The first pass will be a quick verify pass

2.2.3 NO SBE Free Banks -

If the program cannot find any SBE (Single Bit Error) free locations (in non-protected MK11 memory) it will print out an error message and continue testing by-passing the CSR tests.

2.2.4 Mixed Core & MOS Configurations -

The program will function normally in mixed environments. The sequence of testing may seem strange due to the recursive test mode algorithm (reference sections 2.3.1.1, 2.3.1.2, & 2.3.1.3).

PAGE 9

2.3 Program Options

2.3.1 Switch Register Details -

If a hardware switch register is not available then the software switch register is in location 176. If under APT if BIT7 is set in the E-TABLE symbolic location 'SENVM' the APT software switch register will be used (located on \$SWREG).

To change the software switch register contents: Type 'control G'. This will cause display the current value of the SWR and prompt for the octal input of the new SWR value from the terminal. This routine will ignore you (not respond to control 'G') if you have a hardware switch register.

SW15 - HALT ON ERROR
(100000)

Continuing from this halt will first check for a change in the software switch register ('Control G' in the TTY input buffer) then it will continue testing.

SW14 = LOOP ON TEST
(40000)

This will cause looping on the present test or pattern (back to last scope trap). If in a pattern then the looping will be for an entire bank of 16K addresses.

SW13 = INHIBIT
ERROR TYPEOUTS
(20000)

This will cause returns from the error routine without the typed messages. Other on error functions are not

affected.

SW12
LOCATION

INHIBIT REL
(10000)

This prevents the program from
 moving and consequently
 prevents the program from testing at l
 east 16K of memo-
 ry - in the case of MK11 memory up to 128K o
 f memory
 may be bypassed because of PROTECTION POINTER coverag
 e
 (reference section 5.2.4).

SW11 - QUICK VERIFY/INHIB
 IT MARGIN TESTING
 (4000)

Each pass of the diagnostic normally runs all margins and checks all combinations of SBE's & DBE's. If this switch is selected no margins are run (shortening pattern tests by a factor of 5) and approximately one 64th of the possible combinations of SBE's & DBE's are tested.

Each pass complete typeout will indicate this mode by preceding the pass number with 'QV'.

SW10
 BELL ON ERROR
 (2000)

This causes a bell (or beep or click) on each error trap

SW9
 LOOP ON ERROR
 (1000)

This will cause looping from failure point back to the last correctly initialized area of the current test. This loop will frequently be too large for scoping purposes. Tighter loops are provided for in Field Service Mode reference section 2.3.4.5.10.

SW8 = HALT PROGRAM
 (400)

This initiates the following sequence:

1. clears margins in 'MAINT' REGISTER
2. if program is relocated it moves back to bank

zero

D 2

SEQ 0016

3. flush out all possible DBE's.

4. turns off memory management

5. restore l

oaders

6. unmap the Unibus Map

7.

Halt if under APT or ACT branch sel.

SW7 - DETAILED ERROR REPORTS

(200)

After any normal error report is typed this option causes the contents of the following registers to be

typed:

R0, R1, R2, R3, R4, R5, SP, 'MEMERR', 'MAINT', 'CONTROL', 'LOADRS', 'HIADRS', 'CPUERR'

SW6 - PRINT CONFIGURATION MAP
(100)

This prints a map showing the memory configuration - reference section 7.4.

SW5 - LIMIT MAX ERRORS PER BANK
(40)

This will limit the number of error timeouts per bank.

The default is 10. DECIMAL, however this can be changed by changing location 'ERRMAX' manually or with OTT (T-reference Section 2.3.4.2).

SW4 - FAT TERMINAL
(20)

This informs the program that the console terminal has a width of at least 132 columns (LA36 with wide paper).

SW3-1
TEST MODE

be used Test modes determine the recursion algorithm to during pattern tests.

DESCRIPTION	MODE NAME	D
(0)	0	BAFPAF Banks forward, patterns forward
(2)	1	BAFPAR Banks forward, patterns reverse
(4)	2	BAWPAF Banks worst first, patterns forward.
(6)	3	BAWPAR Banks worst first, patterns reverse.
(10)	4	PAFBAF Patterns forward, banks forward
(12)	5	PAFBAW Patterns forward, banks worst first
(14)	6	PARBAF Patterns reverse, banks forward
(16)	7	PARBAW Patterns reverse, banks worst first.

NOTE: Margins follow patterns

Forward is (0,2,3,4,5)
Reverse is (5,4,3,

2,0)

For more details reference section 2.3.1.1 and 2.3.1.2.

SW0
DETECT SINGLE BIT ERRORS (SBI's)
(1)

For manufacturing purposes this switch should always be on. For field service purposes this switch should always be off.

This switch will allow all MK11 Single Bit errors to be reported by disabling error correction.

Error p

Printouts of SBE's are not distinguishable from
DBE's.

SFO 0014

2.3.1.
Test Mode Example -

Example analysis of mode 5 'PAFBAW'. Assume Banks 0 & 1 are MJ11 (core) and Banks 2,3,4,& 5 are MK11 (MOS).

Assume also that Bank 3 is known bad by the program (via the sizing routine or previous runs reference section 3.1 and 6.1 test 22). The testing sequence would be as follows:

```
;TEST MK11 MEMORY TYPES FIRST
;TEST KNOWN BAD MEMORY (BANK 3)
```

```
PAT
TERN 17,      BANK 3,      MARGIN 0
PATTERN 17,   BANK 3,      MARGIN 2
PATTERN 17,   BANK 3,
MARGIN 3
PATTERN 7,    BANK 3,      MARGIN 0
PATTERN 7,    BANK 3,      MARGIN ?
PATTERN
7,           BANK 3,      MARGIN 3
PATTERN 1,    BANK 3,      MARGIN 0
PATTERN 1,    BANK 3,      MARGIN
N 2
PATTERN 1,    BANK 3,      MARGIN 3
PATTERN 2,    BANK 3,      MARGIN 0
PATTERN 2,    B
ANK 3,      MARGIN 2
PATTERN 2,    BANK 3,      MARGIN 3
PATTERN 4,    BANK 3,      MARGIN 0
PATTERN 4,    BANK 3,      MARGIN 2
PATTERN 4,    BANK 3,      MARGIN 3
PATTERN 5,    BANK 3,
MARGIN 0
PATTERN 5,    BANK 3,      MARGIN 2
PATTERN 5,    BANK 3,      MARGIN 3
PATTER
RN 21,   BANK 3,      MARGIN 0
PATTERN 21,   BANK 3,      MARGIN 2
PATTERN 21,   BANK 3,      MA
RC:N 3
PATTERN 20,   BANK 3,      MARGIN 0
PATTERN 20,   BANK 3,      MARGIN 2
PATTERN 20
BANK 3,      MARGIN 3
PATTERN 22,   BANK 3,      MARGIN 0
PATTERN 22,   BANK 3,      MARGIN
2
PATTERN 22,   BANK 3,      MARGIN 3
```


PATTERN 26.	BANK 3.	MARGIN 0
PATTERN 26.	BANK	
K 3.	MARGIN 2	
PATTERN 26.	BANK 3.	MARGIN 3

:TEST PRESUMED GOOD MEMORY (BANKS 2,4,5)

PATTERN 17.	BANK 2.	MARGIN 0
PATTERN 17.	BANK 2.	MARGIN 2
PAT		
TERN 17.	BANK 2.	MARGIN 3
PATTERN 17.	BANK 4.	MARGIN 0
PATTERN 17.	BANK 4.	
MARGIN 2		
PATTERN 17.	BANK 4.	MARGIN 3
PATTERN 17.	BANK 5.	MARGIN 0
PATTERN 17.	BANK 5.	MARGIN 2

PATTERN 1,	BANK 5,	MARGIN 3
PATTERN 7,	BANK 2,	MARG
IN 0		
PATTERN 7,	BANK 2,	MARGIN 2
PATTERN 7,	BANK 2,	MARGIN 3
PATTERN 7,		
BANK 4,	MARGIN 0	
PATTERN 7,	BANK 4,	MARGIN 2
PATTERN 7,	BANK 4,	MARGIN 3
PATTERN 7,	BANK 5,	MARGIN 0
PATTERN 7,	BANK 5,	MARGIN 2
PATTERN 7,	BANK	
5,	MARGIN 3	
PATTERN 1,	BANK 2,	MARGIN 0
PATTERN 1,	BANK 2,	MARGIN 2
PATT		
ERN 1,	BANK 2,	MARGIN 3
PATTERN 1,	BANK 4,	MARGIN 0
PATTERN 1,	BANK 4,	M
MARGIN 2		
PATTERN 1,	BANK 4,	MARGIN 3
PATTERN 1,	BANK 5,	MARGIN 0
PATTERN		
1,	BANK 5,	MARGIN 2
PATTERN	BANK 5,	MARGIN 3
PATTERN 2,	BANK 2,	MARGIN
0		
PATTERN 2,	BANK 2,	MARGIN 2
PATTERN 2,	BANK 2,	MARGIN 3
PATTERN 2,	BA	
NK 4,	MARGIN 0	
PATTERN 2,	BANK 4,	MARGIN 2
PATTERN 2,	BANK 4,	MARGIN 3
P		
ATTEN 2,	BANK 5,	MARGIN 0
PATTERN 2,	BANK 5,	MARGIN 2
PATTERN 2,	BANK 5,	
	MARGIN 3	
PATTERN 4,	BANK 2,	MARGIN 0
PATTERN 4,	BANK 2,	MARGIN 2
PATTER		
N 4,	BANK 2,	MARGIN 3
PATTERN 4,	BANK 4,	MARGIN 0
PATTERN 4,	BANK 4,	MAR
GIN 2		
PATTERN 4,	BANK 4,	MARGIN 3
PATTERN 4,	BANK 5,	MARGIN 0
PATFRN		
4,		
	BANK 5,	MARGIN 2
PATTERN 4,	BANK 5,	MARGIN 3
PATTERN 5,	BANK 2,	MARGIN 0
PATTERN 5,	BANK 2,	MARGIN 2

PATTERN 5.	BANK 2.	MARGIN 3
PATTERN 5.	BANK	
4.	MARGIN 0	
PATTERN 5.	BANK 4.	MARGIN 2
PATTERN 5.	BANK 4.	MARGIN 3
PAT		
TERN 5.	BANK 5.	MARGIN 0
PATTERN 5.	BANK 5.	MARGIN 2
PATTERN 5.	BANK 5.	
MARGIN 3		
PATTERN 21.	BANK 2.	MARGIN 0
PATTERN 21.	BANK 2.	MARGIN 2
PATTERN		
21.	BANK 2.	MARGIN 3
PATTERN 21.	BANK 4.	MARGIN 0
PATTERN 21.	BANK 4.	MARGIN 1
N 2		
PATTERN 21.	BANK 4.	MARGIN 3
PATTERN 21.	BANK 5.	MARGIN 0

PATTERN 21,			
BANK 5,	MARGIN 2		
PATTERN 21,	BANK 5,	MARGIN 3	
PATTERN 20,	BANK 2,	MARGIN 0	
PATTERN 20,	BANK 2,	MARGIN 2	
PATTERN 20,	BANK 2,	MARGIN 3	
PATTERN 20,	BANK		
4,	MARGIN 0		
PATTERN 20,	BANK 4,	MARGIN 2	
PATTERN 20,	BANK 4,	MARGIN 3	
PATT			
ERN 20, BANK 5,		MARGIN 0	
PATTERN 20,	BANK 5,	MARGIN 2	
PATTERN 20,	BANK 5,	M	
ARGIN 3			
PATTERN 22,	BANK 2,	MARGIN 0	
PATTERN 22,	BANK 2,	MARGIN 2	
PATTERN 2			
2,	BANK 2,	MARGIN 3	
PATTERN 22,	BANK 4,	MARGIN 0	
PATTERN 22,	BANK 4,	MARGIN	
2			
PATTERN 22,	BANK 4,	MARGIN 3	
PATTERN 22,	BANK 5,	MARGIN 0	
PATTERN 22,	BA		
NK 5,	MARGIN 2		
PATTERN 22,	BANK 5,	MARGIN 3	
PATTERN 26,	BANK 2,	MARGIN 0	
P			
ATTERN 26,	BANK 2,	MARGIN 2	
PATTERN 26,	BANK 2,	MARGIN 3	
PATTERN 26,	BANK 4,		
	MARGIN 0		
PATTERN 26,	BANK 4,	MARGIN 2	
PATTERN 26,	BANK 4,	MARGIN 3	
PATTER			
N 26, BANK 5,		MARGIN 0	
PATTERN 26,	BANK 5,	MARGIN 2	
PATTERN 26,	BANK 5,	MAR	
GIN 3			

;RELOCATE TEST PROGRAM SPACE (BANK 0 & 1)

PATTERN 1,	BANK		
0,	MARGIN 0		
PATTERN 1,	BANK 0,	MARGIN 2	
PATTERN 1,	BANK 0,	MARGIN 3	
PATT			
ERN 1, BANK 0,		MARGIN 4	
PATTERN 1,	BANK 0,	MARGIN 5	
PATTERN 2,	BANK 0,	M	

ARGIN C			
PATTERN 2.	BANK 0.	MARGIN 2	
PATTERN 2.	BANK 0.	MARGIN 3	
PATTERN 2.	BANK 0.	MARGIN 4	
PATTERN 2.	BANK 0.	MARGIN 5	
PATTERN 3.	BANK 0.	MARGIN	
0			
PATTERN 3.	BANK 0.	MARGIN 2	
PATTERN 3.	BANK 0.	MARGIN 3	
PATTERN 3.	BA		
NK 0.	MARGIN 4		
PATTERN 3.	BANK 0.	MARGIN 5	
PATTERN 4.	BANK 0.	MARGIN 0	
P			
ATTERN 4.	BANK 0.	MARGIN 2	
PATTERN 4.	BANK 0.	MARGIN 3	
PATTERN 4.	BANK 0.		
	MARGIN 4		

PATTERN 4.	BANK 0.	MARGIN 5
PATTERN 5.	BANK 0.	MARGIN 0
PATTE		
RN 5.	BANK 0.	MARGIN 2
PATTERN 5.	BANK 0.	MARGIN 3
PATTERN 5.	BANK 0.	MA
RGIN 4		
PATTERN 5.	BANK 0.	MARGIN 5
PATTERN 26.	BANK 0.	MARGIN 0
PATTERN 26		
	BANK 0.	MARGIN 2
PATTERN 26.	BANK 0.	MARGIN 3
PATTERN 26.	BANK 0.	MARGIN
4		
PATTERN 26.	BANK 0.	MARGIN 5
PATTERN:	BANK 1.	MARGIN 0
PATTERN 1.	BAN	
K 1.	MARGIN 2	
PATTERN 1.	BANK 1.	MARGIN 3
PATTERN 1.	BANK 1.	MARGIN 4
PA		
TTERN 1.	BANK 1.	MARGIN 5
PATTERN 2.	BANK 1.	MARGIN 0
PATTERN 2.	BANK 1.	
	MARGIN 2	
PATTERN 2.	BANK 1.	MARGIN 3
PATTERN 2.	BANK 1.	MARGIN 4
PATTERN		
2.	BANK 1.	MARGIN 5
PATTERN 3.	BANK 1.	MARGIN 0
PATTERN 3.	BANK 1.	MAR
GIN 2		
PATTERN 3.	BANK 1.	MARGIN 3
PATTERN 3.	BANK 1.	MARGIN 4
PATTERN 3.		
	BANK 1.	MARGIN 5
PATTERN 4.	BANK 1.	MARGIN 0
PATTERN 4.	BANK 1.	MARGIN 2
PATTERN 4.	BANK 1.	MARGIN 3
PATTERN 4.	BANK 1.	MARGIN 4
PATTERN 4.	BANK	
1.	MARGIN 5	
PATTERN 5.	BANK 1.	MARGIN 0
PATTERN 5.	BANK 1.	MARGIN 2
PAT		
TTERN 5.	BANK 1.	MARGIN 3
PATTERN 5.	BANK 1.	MARGIN 4
PATTERN 5.	BANK 1.	
MARGIN 5		
PATTERN 26.	BANK 1.	MARGIN 0
PATTERN 26.	BANK 1.	MARGIN 2
PATTE V		
26.	BANK 1.	MARGIN 3

PATTERN 26,
PATTERN 26,
N 5

BANK 1,
BANK 1,

MARGIN 4
MARGI

B 3

SEQ 0027

NOTE

This is an exam
ple & not an actual se-
quence.

The pattern sequence was forward (the simple patterns first, complex patterns last) sequence of patterns (MK11 = 17, 7, 1, 2, 4, 5, 21, 20, 22, 26) (MJ11 = 1, 2, 3, 4, 5, 26).

Since the patterns were forward so were the margins (0,2,3,4,5).

If the patterns were run in reverse (MK11=26,22,20,21,5,4,2,1,7,17) (MJ11=26,5,4,3,2,1,) then the margins would also have been in reverse (5,4,3,2,0)

If the bank selection is forward the banks will be tested in the following order:

1. MK11 banks that are not protected or program space (from 0 to 167).

2. MJ11 banks that are not program space (from 0 to 167).

3. The program now relocates & tests:

4. MK11 banks that were protected or program space (from 0 to 167).

5. MJ11 banks that were program space (from 0 to 167).

If bank selection is worst first the configuration table will be consulted and banks will be tested in the following order.

1. MK11 banks that are known bad and are not protected or program space (from 0 to 167).

2. MJ11 banks that are known bad and are not program space (from 0 to 167).

3. MK11 banks that are presumed good and are not protected or program space (from 0 to 167)

- 0 3
4. MJ11 banks that are presumed good and are not program space
(from 0 to 167).
 5. The program now relocates & tests:
 6. MK11 banks that are known bad and were protected or program space
(from 0 to 167).
 7. MJ11 banks that are known bad and were program space
(from 0 to 167).
 8. MK11 banks that are presumed good and were protected or program space (from 0 to 167).
 9. MJ11 banks that are presumed good and were program space
(from 0 to 167).

2.3.1.2 Test Mode Details -

MODE 0 = 'BAFPAF' banks forward, patterns forward

This is the default and simplest mode.

This mode tests each bank completely from 0 to 167 except those requiring relocation*.

While testing each bank the patterns are run with the simple ones first building to the more complex.

MODE 1 - 'BAFPAR' = banks forward, patterns reverse

This mode tests each bank completely from 0 to 167 except those requiring relocation*.

While testing each bank the patterns are run with the most complex ones first, working to the simple ones.

MODE 2 - 'BAWPAF' = Banks worst first, patterns forward

This mode first tests each known bad bank completely from 0 to 167 except those requiring relocation*, then presumed good banks are tested from 0 to 167 except those requiring relocation*.

While testing each bank the patterns are run with the simple ones first, building to the more complex.

MODE 3 - 'BAWPAR' - Banks worst first, patterns reverse

This mode first tests each known bad bank completely from 0 to 167 except those requiring relocation*, then

presumed good banks are tested from 0 to 167 except those requiring relocation.

While testing each bank the patterns are run with the most complex ones first, working to the simple ones.

MODE 4 - 'PAFBAF' = Patterns forward, banks forward

This mode tests each pattern completely with the simple ones first, building on to the more complex.

While testing each pattern the banks are run from 0 to 167 except those requiring relocation.

E 19

MODE 5 'PAFBAW' = Patterns forward, banks worst first

This mode tests each pattern completely with the simple ones first, building to the more complex.

While testing each pattern first each known bad bank from 0 to 167 except those requiring relocation* is run, then presumed good banks are run from 0 to 167 except those requiring relocation*.

MODE 6 'PARBAF' - Patterns Reverse, Banks forward

This mode tests each pattern completely with the most complex ones first, working to the simple ones.

While testing each pattern the banks are run from 0 to 167 except those requiring relocation*.

MODE 7 'PARBAW' - Patterns Reverse, Banks Worst First

This mode tests each pattern completely with the most complex ones first, working to the simple ones.

While testing each pattern first each known bad bank from 0 to 167 except those that require relocation* is run, then presumed good banks are run from 0 to 167 except those requiring relocation*.

NOTE

* Relocation is required to test the bank(s) in program space and also to test any MK11 banks protected by diagnostic checkmode with the inhibit mode

pointer off (zero):

SE0 0033

2.3.1.3 Memory Mode Applications -

1. To verify correct operation of the memory system use Mode 0 'BAFPAF'.

Advantages: Easy to understand.

Disadvantages: In case of a failing Bank, it may take a long time to find the failure.

2. To get detailed error information on known bad Banks (found by sizing routine) use Mode 2 'BAWPAF'.

Advantages: Seeks Bad Banks. Easy to understand.

Disadvantages: Failures other than zeros & ones may take a long time to find.

3. To get good error info on any memory problem fast use Mode 4 'PAFBFAF'.

Advantages: Covers all banks fast. Easy to understand.

Disadvantages: Failures from only complex patterns may take a long time to find.

4. To find any problem fast use Mode 7 'PARBAW'.

Advantages: Covers all Banks fast.

Disadvantages: Difficult to understand failures reported are not necessarily the most basic failure modes.

2.3.2 Display Register -

A software display register exists in location 174 in addition to any hardware display existence.

Display fields are as follows:

```

      15 : 14 13 12 11 10 9 8
      : 7 6 5 : 4 3 2 1
relocated !      Bank #      ! Margins . P
altern
:-----:
=====

```

OR

In the case of multiprocessor tests the entire display register is used to represent the two's complement of the multiprocessor test #.

PATTERN # The number of the pattern presently being run. All

patterns are described in section 6.2. Any pattern can be found in the Diagnostic Tag List. The pattern # is agnostic by looking up the symbolic tags 'MTONN' and 'MTPNN' - where 'NN' is the Pattern number.

MTONN refers to the routine that sets up for the test

Pattern whereas MTPNN is the actual pattern itself.

NOTE

The pattern # is not necessarily an indication of degree of difficulty.

MARGINS The 3 bit value loaded into the Maintenance register (17777750) Bits (3:1). Margins are decoded as follows:

Margin	MJ11(core)	MK11(MOS)
--------	------------	-----------

0	Normal Operation	Normal Operation
2	Early Strobe	Early MDR L

3	Late Strobe	Late Refresh
4	Low Current	Reserved
5	High Current	Reserved (Normal)

Margin 1 = Forces 'wrong address parity' error

BANK = The number of the Bank (16K) of memory under test (0-167).
 these bits directly map to physical address bits (21:15).

If the Bank # is above 167 octal this entire display is in Multiprocessor mode - see above.

RELOCATED = This BIT indicates that the program is relocated and no longer in Bank 0. It will be relocated to the first known good non-protected memory bank indicated on the configuration map (reference section 7.4).

2.3.3 Special Memory Locations -

2.3.3.1 CACHE Constant -

The CACHE constant is located at symbolic location 'CACHE' and is used to enable CACHE.

If you desire to run with group 0 disabled change this CACHE constant to 4 or 5, if you desire to run with group 1 disabled change the CACHE constant to 10 or 11, if you desire to disable all of CACHE change the CACHE constant to 14 or 15.

NOTE

Bit 0 in the CACHE constant has no effect since it is unconditionally set by the program whenever it tries to enable CACHE.

2.3.3.2 Configuration Table

The configuration table is located at symbolic location 'CONFIG' and
 as the following format:

CONFIG: First 16K Configuration words (3 each)

nd 16K Configuration words (3 each)

.....
 167th 16k
 configuration words (3 each)

Configuration Words:

VE FACTOR	LOW:	BIT 0-2	INTERLEAVE
		BIT 3	EXTERNAL INTERLEAVE
EXISTS)		BIT 4	MASTER CAN ACCESS (MEMORY
		BIT 5	SLAVE #1 CAN ACCESS (SHARED)
(SHARED)		BIT 6	SLAVE #2 CAN ACCESS
)		BIT 7	SLAVE #3 CAN ACCESS (SHARED)
		BIT 8-10	BOX NUMBER (0-7)
		BIT 11	ERRORS PRESENT
		BIT 12	PROTECTED REGION OF A MK11 BOX
T 13-14		BIT	
MEMORY TYPE;0		BIT 15	PROTECTED (PROGRAM SPACE)
	MED:		
BIT 0-5	NOT USED	BIT 6-8	MK11 CSR ADDRESS
		BIT 9-11	NOT USED
		BIT	
T 12	INTERNAL INTERLEAVE	BIT 13	'BACKGROUND PATTERN VALID' FLAG
		BIT	
14	BANK SELECTED FOR TEST BY FIELD SERVICE MODE	BIT 15	LOADERS HOME BANK
	HIGH:	BIT 0	INDICATES BANK IS ADDRESSED BY CSR 172100
S BANK IS ADDRESSED BY CSR 172104		BIT 1	INDICATE
172110		BIT 2	INDICATES BANK IS ADDRESSED BY CSR
		BIT 3	INDICATES BANK IS ADDRESSED BY CSR 172114
TES BANK IS ADDRESSED BY CSR 172120		BIT 4	INDICA
SR 172124		BIT 5	INDICATES BANK IS ADDRESSED BY C
		BIT 6	INDICATES BANK IS ADDRESSED BY CSR 172130
		BIT 7	INDI

CATES BANK IS ADDRESSED BY CSR 172134
BIT 8-15 NUMBER OF ERRORS

N 3

SEO 0039

This table is used as the source for the configuration Map (reference, section 7.4).

2.3.4 Terminal Commands -

2.3.4.1 Control 'C' -

This command will

:

1. Clear any margin conditions.
2. Unrelocate if program was relocated.
3. Flush out any DBE's.
4. Turn off Memory management.
5. Attempt to Boot RK05 Drive 0.
6. Failing 5, attempt to Boot RK05 Drive 1.
7. Failing 6, go to 5.

This command will only be recognized at the completion of the current test or pattern.

2.3.4.2 Control 'D' (Debug) -

This command will enter a modified version of ODT.

This is a subset of the ODT as documented in the RT11 System Reference Manual with the addition of Control 'C', Control 'F', & control 'E' which function as outlined here.

NOTE

It is advisable not to enter ODT when the program is relocated.

2.3.4.3 Control 'E' (procEEd) -

This command will allow you to exit ODT. It is the reverse of the control 'D' command. If you type control 'E' after a Breakpoint - you're on your own!

2.3.4.4 Control 'T' (Tell me what's happening) -

This command will print out the information encoded in the display register. This is mainly intended for CPU's without a hardware display register.

Example:

RELOCATED BANK- 23 MAR- 3 PAT= 26

2.3.4.5 Control 'S' (Stop) -

This command will stop typeout (soon) and will wait for a Control 'D'.

2.3.4.6 Control 'Q' (Continue) -

This command will continue typing that has been stopped by Control 'S'. If there has been no Control 'S' typed then this command is ignored.

2.3.4.7

Control 'F' (Field service mode) -

This command will cause you to enter a mode looking for sub commands.

When the program is looking for a sub command any number that is not a legal command will cause a mini help message to be typed. Therefore when in doubt type 99 (CR) and you will get help.

NOTE

Typing just carriage return is a default command 0.

2.3.4.7.1 Field Service Command 0 (Exit) -

This command will exit Field Services Mode and return to whatever task it was in prior to typing control 'F'. Note typing just carriage return is a default 0.

2.3.4.7.2 Field Service Command 1 (Read CSR) -

This command will typeout the contents of the MK11 CSR.

If there is more than one CSR on the CPU (or if the program has not yet determined the CSR status yet), it will ask you 'WHICH CSR(0-7)' to which you must respond with an Octal number from 0 to 7. Note typing just carriage return is a default 0.

If the CSR you select causes a trap to 4 the program will type 'THIS CSR DOES NOT EXIST'.

NOTE

E 4

SEQ 0043

CSR refer
ences are done in accordance
with section 5.1.

2.3.4.7.

Field Service Command 2 (Load CSR) -

This command will enable you to load the MK11 CSR.

If there is more than one CSR on the CPU (or if the program has not yet determined the CSR status yet) it will ask you 'WHICH CSR(0-7)'' to which you must respond with an Octal number from 0 to 7. Note typing just carriage return is a default 0.

If the CSR you select causes a trap to 4 the program will type 'THIS CSR DOES NOT EXIST''.

The CSR will be read and displayed as in command 1.

The program will then ask you for the 'FIRST CSR WORD' to which you must respond with an Octal number. Note typing just carriage return is a default 0.

The program will then ask you for the '2ND CSR WORD' to which you must respond with an Octal number.

The program will then load the CSR and Read it again displaying its new contents.

2.3.4.7.4

Field Service Command 3 (Examine Memory) -

This command will allow you to examine any physical address and does the necessary memory management mapping for you.

The program will ask you for the 'PHYSICAL ADDRESS (0-1677776)'' to which you must respond with an Octal number.

If the address access causes a trap to 4 the program will type 'TIME-OUT TRAP''. If the address access causes a trap to 114 the program will type 'PARITY ABORT''.

The contents of
your physical address will be typed.

2.3.4.7.5 Field Service Command 4 (Modify Memory) -

This command allows you to modify any physical address and does the necessary memory management mapping for you.

The program will ask you for the 'PHYSICAL ADDRESS (0-1677776)' to which you must respond with an Octal number.

If the address access causes a trap to 4 the program will type 'TIME-OUT TRAP'. If the address access causes a trap to 114 the program will type 'PARITY ABORT'.

The program will type 'OLD DATA WAS' and the contents of your physical address.

The program will then type 'INPUT NEW DATA' to which you must respond with an Octal number. Note typing just carriage return is a default 0.

The program will attempt to write this new data into your physical address after which it will read it again and type 'DATA IS NOW' and the new contents of your physical address.

NOTE

If you can't change the data, that would indicate that you have a double bit error in that double word pair.

2.3.4.7.6 Field Service Command 5 (Select Bank, Margin & Pattern) -

This command allows you to run any bank at any margin with any pattern forever.

The program will ask you 'BANK(0-167)' to which you must respond with an Octal number. If the bank is not accessible. The program will type 'BANK NOT ACCESSIBLE' and ask question over.

The program will then ask 'PATTERN (0-37)' to which you must respond with an Octal number.

Any pattern can be run including those that are not part of the

A
PT E-TABLE defaults (reference section 6.2.1). If you select Pattern 0, the program will ask 'PATTERN 0 DATA IS?' to which you must respond with an Octal number.

The program will then ask 'MARGIN (0,2,3,4,5)?' to which you must respond with an Octal number of the set (0,2,3,4,5). If SW5 is set in the Switch register the program will type 'MARGINS INHIBITED BY SW5' and ask you for the margin again. You must then either turn off SW5 or select a margin of 0.

If the Bank you selected requires relocation the program will type 'BANK REQUIRES RELOCATION' and exit this command. Note normally this is true for Bank 0.

The program will then arm the console keyboard for interrupts and type 'TO ESCAPE TYPE ANY KEY.'.

The test pattern will be entered and run until a console key is de-

pressed to escape this loop.

J 4

8400 015

2.3.4.7.7 Field Service Com
mand 6 (Type Configuration Map) -

This command types the configuration map.

This is useful after a long run (overnight) to see all the banks that are marked as bad. (Especially if your console is a video terminal).

For a detailed explanation of the map reference section 7.4.

2.3.4.7.8 Field Service
Command 7 (Battery Backup Test) -

This command will check that memory does not forget while powered down.

It will write and check the address pattern in every non-protected Memory Bank.

It will then prompt with 'REMOVE SYSTEM POWER FOR 10 SECONDS MAX!'

If you change your mind and do not wish to power down the system type any character and the program will think that it has gone thru a power fail/auto restart sequence.

The program will then read check each non-protected bank for the address pattern and when done type 'TEST COMPLETE' and exit this command.

2.3.4.7.9 Field Service Co
mmand 8 (SOB-A-LONG TEST) -

This command allows execution of the SOB-A-LONG Test on all non-protected Banks reference Section 6.2.2.26. Operation is identical to command 5 except that no Pattern or Bank is entered and each pass causes a Bell.

2.3.4.7.10 Field Service Command 9 (Super Tight scope loop) -

This command allows super tight scope loops on any physical address with any margin setting.

The program will ask for 'PHYSICAL ADDRESS' to which you must respond with an octal number.

The program will then ask 'MARGIN (0,2,3,4,5)?' to which you must respond with an Octal number of the set (0,2,3,4,5). If SW5 is set in the Switch register the program will type 'MARGIN INHIBITED BY SW5' and ask you for the margin again. You must then either turn off SW5 or select a margin of 0.

The program will then type 'SW R ---> MEM, MEM ---> DISPLAY' indicating that it will move the switch register into the physical address, move the physical address into the Display Register, and loop.

The program arms the console keyboard for interrupts and types 'TO ESCAPE TYPE ANY KEY!'.

The program now enters a loop at symbolic location 'CMD9LOOP' which consists of the following code:

```

CMD9LOOP:      MOV     @SWR,(
RO)           ;WRITE SWITCH REGISTER INTO MEMORY
              MOV     (RO),@DISPLAY ;READ MEMORY INTO DI
DISPLAY REGISTER
              BR     CMD9LOOP      ;LOOP TILL KEYBOARD INTERRUPT

```

Typing any key will exit this command.

2.3.4.7.11 Field Service Command 10 (Error Summary)

This command types out the number of passes and the total number of errors. If there were any errors it will type out the Banks and the number of errors per bank up to 255 DECIMAL.

This becomes useful after long runs (all night) on systems with a video console terminal.

2.3.4.7.12 Field Service Command 11 (Refresh TEST) -

This command allows execution of the Refresh Test on all non-protected Banks reference Section 6.2.2.19. Operation is identical to command 5 except that no Pattern or Bank is entered and each pass causes a Bell.

2.3.4.7.13 Field Service Command 12 (Set Fill Count) -

This command allows setting of the terminal fill count (necessary for LA30's, ASR33's, and VT05's). It is normally set to zero for LA36's, VT52's, VT61's, etc.

2.3.4.7.14 Field Service Command 13 (Enter Kamikaze Mode) -

This command allows you to run patterns that are normally not executed unless under APT or ACT. They are usually very time consuming and can result in failures that are fatal to the program. In effect you are trying to find a hardware failure regardless of the consequences. Note that most crashes do not wipe out the display information which is telling you what the program was doing just prior to failure.

There are two ways to die here - Impatience and Crashes.

SEQ 0052

2.3.4.7.15 Field Service Command 14 (Exit Kamikaze Mode) -

Return to the default mode of testing (undo Command 13).

2.3.4.7.16 Field Service Command 15 (Turn Cache Off) -

This changes the Cache constant to bypass cache (reference section 2.3.3.1).

2.3.4.7.17 Field Service Command 16 (Turn Cache On) -

This changes the Cache constant to use cache (reference section 2.3.3.1).

2.3.4.7.18 Field Service Command 17 (Run Only Multiport Tests) -

Single Port Testing will be disabled. This is used to extensively test only logic that is unique to the Multiprocessors.

2.3.4.7.19 Field Service Command 18 (Resume Running Both Single and Multiport Tests) -

Return to the default mode of testing (undo Command 17).

•
2.3.4.7.20 Field Service Command 19 (Test Only Selected Banks) -

This command allows you to center the test effort on only those banks that you are troubleshooting. You may also test banks that require relocation and were inaccessible via command 5.

2.3.4.7.21 Field Service Command 2

C (Resume Testing All Banks) -

Return to the default mode of testing (undo C
command 19).

AGE 34

2.4 Execution Times

2.4.1 Typical (System) -

Execution time depends on many variables however here are some measured times.

	CEMKAB(70 MEM)	DEMJA (OLD 0-2 MEG)
128K of MJ11 (core) Memory		
Normal Pass	2 Min 45 Sec	11 Min 41 Sec
Quick Verify	33 Sec	2 Min
1		
28K of MK11 (MOS) Memory		
Normal Pass	2 Min 52 Sec	11 Min 41 Sec
Quick Verify	45 Sec	2 Min
Kamikaze Mode	29 Min	
Kamikaze QV	9 Min 35 Sec	

2.4.2 Calculations (System) -

Normal Pass (all margins)

Add
 14 Sec per MK11 Box (CSR)
 Add 20 Sec per BANK of MOS
 Add 21 Sec per BANK of
 Core

Quick Verify Pass

Add 5 Sec per BANK of MOS
 Add 4 Sec per BANK of
 Core

Kamikaze Mode

Multiply above times by 10.

2.4.3 Typical (Patterns)

Pattern	Time	Description
MT0000	<1 SEC	DATA PATTERN TEST
MT0001	<1 SEC	ADDRESS TEST
MT0002	<1 SEC	COMPLEMENT ADDRESS TEST
MT0003	1 SEC	3 XOR 9 WORST CASE NOISE TEST
MT0004	1 SEC	ROTATING ZEROS TEST
MT0005	1 SEC	ROTATING ONES TEST
MT0006	<1 SEC	INITIAL DATA TEST
MT0007	<1 SEC	ADDRESS BIT TEST
MT0010	<1 SEC	BYTE ADDRESSING TEST
MT0011	<2 SEC	CREATE SINGLE BIT ERROR TEST
MT0012	<1 SEC	WRITE BYTE CLEARS S
MT0013	1 SEC	CREATE DOUBLE BIT ERROR TEST
MT0014	1 SEC	WRITE INHIBIT DURING DATIP WITH DBE
MT0015	1 SEC	WRITE INHIBIT OF BYTE WITH DBE
MT0016	<1 SEC	WRITE INHIBIT OF WORD WITH DBE
MT0017	<1 SEC	HOLDING 1'S 0'S TEST
MT0020	<1 SEC	MARCHING 1'S 0'S IN CHECK BITS
MT0021	1 SEC	MARCHING 0'S 1'S TEST
MT0022	10 SEC	REFRESH TEST
MT0023	10 SEC	SHIFTING DIAGONAL TEST
MT0024	20 SEC	FAST GALLOPING PATTERN TEST
MT0025	<1 SEC	INTERRUPT ENABLE TEST
MT0026	<1 SEC	RANDOM DATA TEST
MT0027	1 SEC	UNIQUE BANK TEST
MT0030	1 SEC	FLUSH OUT DBE'S TEST
MT0031	3 SEC	SOB-A-LONG TEST
MT0032	<1 SEC	SKEWED UP ADDRESS TEST
MT0033	<1 SEC	WRITE RECOVERY TEST
MT0034	35 SEC	BRANCH GOBBLE TEST
MT0035	<1 SEC	SOFT ERROR TEST

7. ERROR INFORMATION

3.1 Error Reporting

Most errors are reported using the EMT trap and handler provided by SYSMAC.SML. Most errors will be of the 'MEMORY DATA ERROR' type which will be described here. MEMORY DATA ERRORS will also cause the bank to be marked as Bad in the configuration table.

Other errors are best explained by referencing the specific typeout and if necessary the program listing.

Example:

```

MEMORY DATA ERROR
PC      BANK  VADD      PADD      GOOD      B
AD      XOR  MAR BOX MTYPE INT PAT ARRAY
022132  37  060006  03700006  000000  0
00100  000100  0  0  MK11  0  06  15
022132  37  060006  03700006  000000  0
00100  000100  0  0  MK11  0  06  15
022132  37  060006  03700006  000000  0
00100  000100  0  0  MK11  0  06  15
022132  37  060006  03700006  000000  0
00100  000100  0  0  MK11  0  06  15

```

While testing Bank 37 at virtual address 60006 (virtual addresses are always between 60000 and 157776 for mapping purposes), physical address 3700006 (that's Bank 37 physical 6 within the Bank) with Pattern 6 (Initial Data Test), the good data expected was 0 but the data actually read (BAD) was 100, the exclusive OR at Good & Bad yields 100 which indicates only failing bit(s) (Bit 6). The margins were at 0 (no margin) and the memory resides in Box 0, it is an MK11 (MOS) Memory and its interleave factor is 0 (not interleaved). The CSR identified an error in slot A1 (reference Section 7.6).

NOTE

Subsequent errors of the same test do not type a ne

w heading.

The Box Interleave and slot would be a "?" if the memory type was MJ11 (Core).

If an MJ11 (Core) gives Parity Aborts then the Bad Data & XOR will be "?????".

If no MJ11 has no CSR with a SBE or DBE then slot will be a "??".

3.2 Error Abbreviations

The following is a list of all abbreviations used in error reports.

# OF ERRORS	Number of Errors that were detected.
1ST ADD	First Address that failed.
ARRAY	The array number that was locked up in the MK11 CSR.
APT#	The # of CPU's APT expects on the system.
APTCORE	APT Core size.
APTMOS	APT MOS size.
BAD	Bad data.
BAD-WD1	Bad Word #1 of a double word data value.
BAD-WD2	Bad Word #2 of a double word data value.
BAD-CHK	Bad Check Code Bits.
BANK	The Bank number. Banks are 16K words long.
BD-CC	Bad Check Code Bits.
BDSWITCH	Bad Switch setting in binary.
BOX	The number of the Box in the system. MJ11 boxes have no numbers.
CHKBITS	The 7 bit value of the Check Code Bits.
CONTRL	The CACHE Control register.
CPUERR	CPU Error register.
CSR	Control and Status Register.
CSR+2	The 2nd half the the MK11 double word CSR.
CSRNUM	CSR NUMBER (0-7).
DBE	Double Bit Error (uncorrectable error).
DEV ADD	Device Address.
ECC	Error Correction.
GD-CC	Good Check Code Bits.
GD-CHK	Good Check Code Bits.
GD-WD1	Good Word #1 of a double word data value.
GD-WD2	Good Word #2 of a double word data value.
GDSWITCH	Good Sw
GOOD	Good data.
HIADRS	High Address error register.
IIST	Inter-processor Interrupt and Sanity Timer.
INT	Interleave total including internal and external.
INTRLV	Interleave total including internal and external.

1 5

LOADRS Low Address error register.
 MAINT Maintenance register.
 MAR M
 argin. Bits 5-1 of the PDP-11/70 Maintenance Register.
 MASTER The Master CPU.

MEMERR Memory Error register.
 MJ11 Size.
 MK11 Size.

MEMRO Memory Management Register #0.
 MMR1 Memory Management Register #1.
 MMR2 Memory Management Register #2.
 MMR3 Memory Management Register #3.
 MTYPE Memory
 Type (MJ11 or MK11).
 PADD Physical Address (asserted by the program after mapping).
 PAT Pattern number.
 PC Program Counter at the time the error occurred.

REAL# The # of CPU's actually on the system.
 SBE Single Bit Error (correctable error).
 SLAVE# The Slave CPU Number.
 SLAVE1 The 1st Slave CPU.
 SLAVE2 The 2nd Slave CPU.
 SLAVE3 The 3rd Slave CPU.
 VADD Virtual Address (asserted by the program before mapping).

SEU 0060

WRITE1 The data that was written into the 1st
 half of a double word.
WRITE2 The data that was written into the 2nd half of
 a double word.
XOR Exclusive OR of the good and bad data. Shows the bad bits.

3.3 Error Halts

There are several Halts in the program.

All unused trap vectors contain a trap catcher (.WORD .+2,HALT).

An undefined TRAP instruction halts at symbolic location '\$HALT2'.

The APT down load sequence will halt at symbolic location 'APTHLT'.

Slave CPU's that did not get permission from the master CPU to proceed will halt at symbolic location '\$HALT'.

If any CPU detects that multiple CPU's are assuming master status then that CPU will halt itself at symbolic location 'MHALT1', 'MHALT2', or 'MHALT3'.

Halt on Error option (SW15 Set) at symbolic location '\$HALT'.

Halt program (SW8 Set) at symbolic location '\$EXHALT'.

Power Fail will normally halt at the end of the shut down sequence (symbolic location '\$DOWN').

Power Fail has a fatal Halt at symbolic location '\$ILLUP' which can be caused by power up occurring before power down sequence completed or by power down before a power up sequence is completed.

4.0 PROGRESS REPORTS

Pass complete typeouts as follows:

END PASS	#	1
END PASS	#	2
END PASS	#QV	3

NOTE

L 5

SEO 0063

Pass 2 was flagged as a Quick Verify
Pass. (Because of a change in SW5)

5.0 DEVICE INFORMATION TABLES
(CSR's)

1st Word

15	:	14	13	12	11	10	9	8	:	7	6	5	
4	:	3	:	2	:	1	:	0	:				
DBE	:	Check/Syndrome/Capacity						:	Bad array				
	:	SBE	:	Protect	:	DIAG	:	ECC	:	ENA	:		
	:		:	Pointer	:	CHECK	:	DIS	:	PAR	:		
	:		:		:		:		:		:	TRAP	

2nd Word

15	:	1																
4	:	13	12	11	:	10	:	9	:	8	7	6	5	4	3	2	1	0
DBE	:	Interleave or . Bad . Starting Address																
	:	Interleave	:		:	IS	:		:		:		:		:		:	
	:	Starting Add	:	control.	:	Load	:		:		:		:		:		:	

5.1
Address(s) Of The CSR

The CSR is accessed as a 32-bit word on the 11/70 main memory bus.
(To the processor, the CSR looks like two consecutive 16 bit words.)

A switch on the M8158 address buffer module selects one of two options for CSR address access, either Direct or Indirect.

5.1.1 Direct Address

(For this option the 11/70 processor requires modification.) Switches on the M8158 address buffer module select one of the following eight CSR (double word) locations (octal addresses):

- 177772100
- 177772104
- 177772110
- 177772114
- 177772120
- 177772124
- 177772130
- 177772134

5.1.2 Indirect Address

(No 11/70 modifications required for this option but its use is quite complex.) Switches on the M8158 address buffer module select one of the following eight CSR (double word) locations (octal addresses):

- 17772100
- 17772104

- 17772110
- 17772114
- 17772120
- 17772124
- 17772130
- 17772134

NOTE

* These addresses are in the upper 128
word section of the existing 11/70 2M
address space. Normally this is
word reserved address space never
implemented in memory and not directly accessible by
the processor.

However, these CSR locations may be accessed for diagnostic purposes through the unibus map with cache turned off. It is not recommended to use this method in an operating system environment since the unibus map is required if other NPR activity is present. One cookbook method of implementing a CSR access (within this diagnostic program) is:

1. Halt all NPR activity on the system.
2. Turn cache off.
3. Par 6 <---
177400 (other Par's Normal)
4. Enable memory management in 22 bit mode
5. Map 36 <--- 17760000 (other Maps - 0).
6. Turn on Unibus Map.
7. Access virtual 152100 through 152136 as CSR's.

5.1.2.1 Historical Note -

This indirect path to the CSR's was discovered in early 1977 by an expedition consisting of my three brothers and myself.

Field Service Engineer, Memory Engineer, System Engineer, and myself Software Engineer,

departed the CPU on our search for the CSR's. Memory Engineer promised that at CSR's would conditionally reside in the shadow of a giant memory depending on whether or not they felt switched.

We began our search for the first CSR believing that if we found one, that the rest of the tribe would surely be nearby. Our task was clear, find CSR 17772100 behind the giant memory 0 through 16777776 (2 Meg words).

Field Service Engineer suggested that since we could arrive in the east by heading west, then surely we could find 17772100 by heading for 152100. This didn't make too much sense to my other brothers and myself, however, since Field Service was willing to pay for the expedition, we all left CPU city in search of 152100.

The first village we came upon was managed by an old experienced relocater named Kay Tee. We told old Mr. Tee of our expedition and our high expectations of finding 17772100 by looking for 152100. He expressed doubt that the feat could be accomplished, but he said since our three most significant bits were six that perhaps his most trusted friend Six (one of the Par brothers) could help us. So we proceeded to see Six Par.

We found Six Par at a busy highway control center directing traffic with his brothers. He greeted us warmly and assured us that we had come to the right place. Six said that his older brother Seven was

not to be trusted since he preferred devices to people. Also, Six told us how his younger brothers were much too inexperienced to guide us and that they usually only do 1 to 1 relocations. So, at Six Par's highway we were given 177400 which he said to multiply by 64 and add to our 12100 (152100 less 3 M SB's). Thus, we were leaving Kay Tee's village with a total address of 17752100.

At the outskirts of the village there were two toll gates one to Cash and one to Uni. We decided to take the Cash route at System Engineer's suggestion that 'Cash makes no enemies'. However, the gate guard would not let us pass because he thought we were a device. We tried to explain but he insisted that unless our most significant bits were 16, we could not pass. Reluctantly, we decided to try the Uni gate. Here the guard was more negotiable and he let us pass charging only four bits. Just outside the gate we boarded a Unibus with address 752100.

PAGE 44

The bus trip was supposed to be quite long with many stops, however, it turned out the first stop was the last stop for anybody without a device address. Here we departed the Unibus to find a long row of 36 checkout girls at special registers called Maps. Each Map register had a number 0 through 36 and a checkout girl with a matching bust size. We all agreed to visit Map register 36. The checkout girl was very cordial and went on to say that she preferred customers whose most significant five bits were 36 also. She charged us our five most significant bits and added her favorite number 17760000 to our address of 12100 and we departed with 17772100, which Memory Engineer promised would lead to the CSR.

Next we came to the cash highway, but since the cash register was turned off, we were declared amiss and allowed to pass all the way down the highway toll free where we arrived at the Memory bus. We gave the driver our address of 17772100 and proceeded on our way. The driver warned us that no one ever goes there and he waited for us at our stop as it was not a regular part of his route.

Here waiting at the bus stop with open arms, we found the CSR and the entire tribe. We briefly exchanged data and climbed back on the Memory bus as we had to return to CPU city before the last Unibus timed out.

The journey home was without incident. It is interesting to note that once home none of the engineers including myself, could remember what the checkout girl's face looked like.

5.1.3 Indirect Manual Mode: -

1. Turn off Cache 17777
746 <--- 14
2. Set up MAPO 17770200 <--- 170000
 17770202 <--- 77
3. Turn on Unibus Map 17772516
<--- 40
4. Turn display switch to CONS PHY
5. Examine or
deposit 17002100 through 17002136 as CSR's

5.2 Allocation of CSR Bits

5.2.1 Enable Parity Traps (Bit0 - of 1st Word) -

If this bit is set, it allows bad parity to be asserted (for a READ operation) if a double error occurs or a single error occurs with ECC disabled. Section 5.2.5 summarizes the operation of this bit along with other control bits. This bit is set on power up and can be written or read by the main memory bus.

5.2.2 ECC Disable (Bit1 - 1st Word) -

If this bit is set, the error correction circuits are disabled and no single bit error correction will occur. However, error detection circuitry is enabled and any single or double bit error may still be detected on a READ operation and correct check bits are still written into memory on a write operation.

This is a diagnostic aid to allow writing and reading data from memory without interference from the error correction logic. This is a READ/WRITE bit cleared on power up.

5.2.3 Diagnostic Check (Bit2 - 1st Word) -

This mode allows a means of writing data stored in CSR Bits (14:8) into the MOS chips used for check bit storage. A READ cycle to memory will read the check bits from MOS storage into CSR bits (14:8).

This allows an integrity check on the check bit storage chips and a

new on the error correction logic.

This bit is cleared on power up and can be written or read by the main memory bus.

5.2.4 Protection Pointer (Bit3 - 1st Word) -

This bit selects the 16K section of memory which will be protected (not be affected by ECC disable and diagnostic check). This 16K section will contain the diagnostic program. When this bit is unasserted, the first 16K associated with each control card is protected. When this bit is asserted the second 16K associated with each control card will be protected. This is a READ/WRITE bit cleared on power up.

5.2.5 Summary of Bits(3:0) of 1st Word -

CSR	BIT3	BIT2	BIT1	BIT0	FUNCTION
Parity trap, disable	0	0	0	0	Parity trap, disable (Normal Mode)
Trap from power up	0	0	0	1	Enable traps on DBE's (Initialized value from power up)
Traps on SBE's	0	0	1	0	Disable error correction traps
Traps on SBE's	0	0	1	1	Enable traps on SBE's
Used by program	0	1	0	0	R/W checkbits
Used by program	0	1	0	1	Not used by program
Used by program	0	1	1	0	Not used by program
Bits (14:8) of 1st word	1	0	0	?	Read Box Capacity in Bit
Program relocated	1	0	1	0	Disable error correction traps (Program relocated)
Program relocated	1	0	1	1	Enable traps on SBE's (Program relocated)
Program relocated	1	1	0	0	R/W Checkbits (Program relocated)
Program relocated	1	1	0	1	Not used by program
Program relocated	1	1	1	0	Not used by program
Program relocated	1	1	1	1	Not used by program

? : DON'T CARE

5.2.6 Single Bit Error Indication (Bit4 - 1st Word) -

On a READ cycle to memory, if a single bit error occurs, this bit is set. Simultaneously, the syndrome bits are latched into CSR Bits (14:8) and the array identification and controller selected are latched into CSR (Bits [7:5] 1st word) and Bit9 2nd word.

An examination of the CSR can thus be performed to see if a single bit error had occurred and the array that failed if such error occurred. This is a READ/WRITE bit cleared on power up.

5.2.7 Array Select (Bits (7:5) 1st Word) -

During a READ cycle to memory, latched address bits on the selected control board will be stored in these locations upon an error. Any DBE will rewrite these bits & SBE's from protected memory will not be latched.

5.2.8 Check Bit/Syndrome Bit Storage/Box Capacity (Bits (14:8) 1st Word) -

5.2.8.1 Check Bit Storage (DIAG CK = 1) -

During a diagnostic check, bits are read from or written into memory as described in Section 5.2.3.

5.2.8.2 Syndrome Bit Storage -

If a single bit error occurs on a read cycle, then the syndrome bits indicating what bit failed are stored into those CSR bits.

These CSR bits can be written or read by the main memory bus. They are neither set nor reset on power up.

5.2.8.3 Hamming Code Matrix -

Each check bit (C1-C32) is the result of odd parity generated on the data bits designated by X.

$$\begin{aligned}
 C1 &= f(1,3,5,7,9,11,13,15,17,19,21,23,25,27,29,31) \\
 C2 &= f(2,3,6,7,10,11,14,15,18,19,22,23,26,27,30,31) \\
 C4 &= f(4,7,12,15,20,23,28,31) \\
 C8 &= f(8,15,24,31) \\
 C16 &= f(16,31) \\
 C32 &= f(32)
 \end{aligned}$$

Check bit CT (check total) is the result of even parity generated on the data bits.

$$CT = f(0,3,5,6,8,11,13,14,16,19,21,22,25,26,28,31)$$

Syndrome bits (S1-ST) are formed by a comparison of the check bits read from memory and new check bits generated on the data read from memory.

A single error will cause an odd number of syndrome bits to go high. If Bit 4 should fail S16, S8, & S4 would be set.

An examination of the syndrome bits can disclose the failing bit.

If there are more than one syndrome bits set and still an odd number of bits then the following simplification exists. S4-S1 indicate in octal the failing Bit (0-7). S32-S8 indicate the Bad Byte. The cleared bit in S32-S8 indicates which Byte from left to right. S32-S8 = 3 = Byte 0; 5 = Byte 1; 6 = byte 2; and all set = 7 - Byte 3. ST (Syndrome total) should be set or cleared to produce an odd number of syndrome.

If only one syndrome bit is set it directly indicates which check bit is bad.

If an even number of syndrome bits are set
something is wrong with the
hardware.

N 6

SEQ 1074

SYNDROME BITS

		BIT		ST	S32	S16	S8	S4	S2	S1
/	0	x	x	1			x	x		x
			/	2						
		x	x	3	x	x	x		x	x
		BYTE 0								
	L	4		4	x	x				
x			L	5	x		x	x		
			L	6	x		x	x	x	
			L	7			x	x	x	x
		/	8	8		x				
			/	9		x	x			x
10		x	x	10	x	x			x	x
		BYTE 1								
			L	12		x		x		
x			L	13	x	x		x	x	
			L	14	x	x		x	x	
x			L	15		x		x	x	
			/	16	x	x	x			
			/	17		x	x			x
18		x	x	18	x				x	x
		BYTE 2								
			L	19	x	x	x		x	x
			L	20		x	x		x	
			L	21	x	x	x		x	x
L	22	x	x	22	x	x			x	x
			L	23		x	x		x	x
/	24		x	24	x	x	x			x
			/	25						
			/	26						
x	x	x	x	26						
		BYTE 3								
			/	27		x	x	x		x
			L	28	x	x	x	x		
			L	29		x	x	x		x
L	30	x	x	30	x	x			x	x
			L	31	x	x	x	x	x	x
/	c1				x					

C 7

SEO 0080

CHECK BITS /

C2
C4
C8

X X X

L C16
L C32
L CT

X X X

5.2.8.4 Box Capacity

Multiplexed with the locations for reading and/or writing check bits or reading syndrome bits is the ability to read the total number of 16K X 32 sections (double blocks) in memory. In order to read this box capacity, the special code as indicated in Section 5.2.5 (bits (3:1) = 1,0,0) will have to be loaded into the CSR 1st word prior to performing the READ cycle.

(Note that if ECC is manually disabled, writing a Zero into CSR Bit2 1st word is overridden and a One remains. In order to read the box capacity for this case, an internal flip-flop is used whose state is what was written into CSR Bit2 1st word. Hence writing Bits(3:1) = 1,0,0 1st word will still allow box capacity to be read even though CSR BIT2 1st word is still a One.)

5.2.9 Double Error Indication (Bit 15 of 1st or 2nd Word) -

On a READ cycle, these bits are set if a double error occurs. Simultaneously the array select bits latched on the control board selected are stored into CSR Bits (7:5) 1st word and the latched control is stored in Bit 9 2nd word. It should be noted that Bits 15 of 1st & 2nd word are separate and independent. (Clearing one bit via a write to that byte will not affect the other. They are however asserted by the addressed controller simultaneously. These are READ/WRITE bits reset on power up.

5.2.10 Starting Address (A24-A16) (Bits (8:0) 2nd Word) -

These bits are used to load a starting box address through t

the CSR on a WRITE cycle or can be used to read the starting address of the memory box if the address is set by switches on the data interface card or remotely from the processor. The starting address can be reconfigured on a 32K word segment. These bits are READ/WRITE. On power up the switch settings on the data interface card are loaded into these CSR locations. In order to load the starting address Bit 10 2nd word must accompany the load.

5.2.11

Control Select (Bit 9 2nd Word) -

If a single or double bit error occurs during a READ cycle, then the address of the controller selected is stored in this CSR bit location.

This bit is read only and cleared on power up.

5.2.12 Starting Address Selector (Bit 10 2nd Word) -

This bit controls selection of the starting address & External Interleave loaded into the CSR or the starting address and external interleave dictated by the switches on the data buffer board or control panel. A Zero in this bit indicates selection of the switches, a One indicates selection of the starting address loaded into CS R bits (8:0) 2nd word and External Interleave bits (14-12) 2nd word!

(Note that a READ operation to the CSR will always give the actual box starting address in Bits (8:0) 2nd word regardless of its origin.)

This is a READ/WRITE bit cleared on power up. (However, a switch on the data buffer board can hold this bit cleared, thereby defeating any attempt at loading the starting address and External Interleave through the CSR.)

5.2.13 Internal Interleaving (Bit 11 2nd Word) -

This bit indicates if there is internal interleaving within a memory box. If this bit is cleared there is no internal interleaving and if it is set, there is internal interleaving.

NOTE

Only if each controller has identical memory capacity is this bit capable of being set. However, writing a Zero to this bit disables all possible internal interleaving. This is a READ/WRITE bit

set on power up if each of the two control card sets has as identical memory capacity.

5.2.14 External Interleaving (Between Boxes) (Bits (14:11) 2nd word) -

These bits indicate how the system is configured for external interleaving as follows:

BIT 14	BIT 12	BIT 13	NUMBER OF WAYS EXTERNALLY INTERLEAVED
0	0	0	No External Interleaving
1	0	0	Not Used
0	1	0	2 Way: Memory Responds to Even Double Words
1	0	0	: Memory Responds to Odd Double Words
0	0	1	4 Way: Memory Selected If: A02=0; A03=0
1	0	1	: Memory Selected If: A02=1; A03=0
0	1	1	: Memory Selected If: A02=0; A03=1
1	1	1	: Memory Selected If: A02=1; A03=1

The bits will be treated in a similar manner to the Start Address as described in Section 5.2: i.e., CSR Bit10 2nd word will determine the origin. Also, on power up the corresponding switch settings will be loaded into these CSR bit locations.

5.2.15 Interleave Summary -

BIT14	BIT13	BIT12	BIT11	DESCRIPTION
0	0	0	0	No Interleave
0	0	0	1	Internal 2-1
0	0	1	0	External 2-1 Even Double Words
0 1 Int	0	1	1	Ext 2- Even Double Words
0	1 Ext 4-1	0	0	A3=0 A2=0
0 -1 INT	1	0	1	Ext 4 A3=0 A2=0
0 1	1	1	0	Ext 4- A3=1 A2=0
0	1	1	1	Ext 4-1 Int A3=1 A2=0
1 RROR)	0	0	0	Impossible (E
1	0	0	1	Impossible (ERROR)
1	0	1	0	Ext 2-1 Odd Double Wor ds
1	0	1	1	Ext 2-1 Int Odd Doub le Words
1 1	1	0	0	Ext 4-1 A3=0,A2

1 1 0 1 Ext 4-1 Int
 A3=0,A2=

1 1 1 0 Ext 4-1
 A3=1,A2=1

: 1 1 1 Ext 4-1 Int
 A3=1,A2=1

5.3 CSR Bit Summary

CSR BIT ALLOCATION - AS
DESIGNED COMMENTS

1st word Bit
 0 Enable Parity Traps : Set on Power Up (Read/Write)
 Bit1 ECC Disable :
 (clear on Power Up (R/W)
 Bit2 Diagnostic Check : Clear on Power Up (R/W)

Bit3 Protection Pointer : Clear on Power Up (R/W)
 Bit4 Single Bit Error Ind
 ication : Clear on Power Up (R/W)
 Bit5 Array Sel A01 : Clear on Power Up
 (Read Only)
 Bit6 Array Sel A02 : Clear on Power Up (Read Only)
 Bit7 Arr
 ay Sel A03 : Clear on Power Up (Read Only)
 Bit8 CK Bit1/Syndrome 1/Capacit
 y 1 : (Read/Write) Bits, Neither
 Bit9 CK Bit2/Syndrome 2/Capacity 2 : Set n
 or Reset on Power
 Bit10 CK Bit4/Syndrome 4/Capacity 4 : Up; Based on CSR Bit
 2 bit3 Check
 Bit11 CK Bit8/Syndrome 8/Capacity 8 : Bits Alone are Read from
 or
 Bit12 CK Bit16/Syndrome 16/Capacity16 : Written into these Locations

Bit13 CK Bit32/Syndrome 32/Capacity32 : Otherwise Syndromes are Written on 'SBE'
 s
 Bit14 CK Bit T/Syndrome T/Capacity64
 Bit15 Double Bit Error Indication
 : Clear on Power Up (R/W)

2nd word Bit0 Start Address (A16) : (Read/Write) B
 its Capable of
 Bit1 Start Address (A17) : Being Loaded via the Main Data

Bit2 Start Address (A18) : Bus or Switches on the Data
 Bit3 Start Address
 (A19) : Card. On Power Up, the switch
 Bit4 Start Address (A20) : Settings
 are loaded into
 Bit5 Start Address (A21) : These Locations.
 Bit6 Start
 Address (A22)

Bit7 Start Address (A23)
 Bit8 Start Address (A24)
 Bit9 Co
 ntroller Select : Cleared on Power Up (Read Only)
 Bit10 Start Address Selec
 tor : Loaded on Power Up (Read/Write)

Bit11 Internal Interleaving : Load
 d on Power Up (Read/Write)
 Bit12 Two Way : Loaded Same as Bits (8:0) 2nd
 word
 Bit13 Four Way : Loaded Same as Bits (8:0) 2nd word
 Bit14 Ext A02 : Loaded Same as Bits (8:0) 2nd word
 Bit15 Double Bit Error Indications :
 (Clear on Power Up (R/W))

6.0 SUB-TEST SUMMARIES

6.1 Tests

TEST 1
ANALYZE CONFIGURATION
(CSR Access may cause wrong Type of Traps)

TEST 2
TEST BANK 0 ACCESSES
Failures are fatal.

TEST 3
TEST BANKS 1-167 (OCTAL) FOR ZEROS ONES
Errors are not typed here - only logged in
the configuration table

TEST 4
MK11 PROTECTION POINTER TEST

TEST 5
DIAGNOSTIC MODE DISPATCH ROUTINE
This test runs all the patterns in the
mode selected.

TEST 6
UNIQUE BANK TEST
Pattern 27 is run

TEST 7
FORCE ADDRESS PARITY ERRORS
Insures that no bank responds when there
is an address parity error.

6.2 Patterns

6.2.1 General Pattern Information -

Actual patterns are identified by symbolic locations 'MTPXY'
 where X
 may be any sub program indicator (A,B,C,etc) or 0 and YY will be the
 number of the pattern.

Setup procedures for each pattern are identified by
 symbolic locations
 'MTOOYY' where YY will be the number of the pattern.

Patterns reside in 4 scripts that are scanned for execution. Symbolic
 location
 'MKCSRT' is a table of patterns that can run once for each
 MK11 controller (twice per MK11 Box). Symbolic location 'MKPAT' is a
 table of patterns that can
 run on each Bank of MK11 memory. Symbolic
 location 'MJPAT' is a table of pat
 terns that can run on each Bank of
 MJ11 memory. Symbolic location 'FSPAT'
 is a table of patterns that
 can be run in Field Service Mode (command 5).

The 1st 3 scripts are completely controlled by the APT E-table (even
 if not
 running under APT). Modifications to this table can be made
 (1) with APT, (2)
 manually, or (3) with ODT reference Section 2.3.4.2.

Example E-table Segment:

```

:THE FOLLOWING LOCATIONS SPECIFY WHICH PATTERNS
:ARE TO BE RUN FOR PARTICULAR MEMORIES
:
:REFERENCE THE TABLE LISTED BELOW TO RELATE BITS TO PATTERNS.
:
:BITO SET WILL RUN THE FIRST ENTRY IN THE TABLE, BITO SET
:IN THE SECOND WORD
:WILL RUN THE 17TH ENTRY IN THE TABLE...
:
:NOTE**NULL TESTS DO NOT TAKE ANY TIME

```



```

SDDW0: .WORD 177777 ;MK11 CSR TESTS      TABLE - MKCSRT:
SDDW1: .WORD 177777 ;MK11 CSR TESTS      TABLE - MKCSRT:
7
SDDW2: .WORD 177777 ;MK11 PATTERNS      TABLE -
MKPAT:
SDDW3: .WORD 177777 ;MK11 PATTERNS      TABLE MKPAT:
SDDW4: .WORD 177777 ;MK11 PATTERNS      TABLE MKPAT:
.MJ11 PATTERNS      TABLE = MJPAT:
SDDW5: .WORD 177777 ;MJ11 PATTERNS      TABLE = MJPA
T:

```

6.2.2 Specific Patterns -

6.2.2.1 Pattern 0 Basic Data Test -

Writes & Reads R2 into a 16K Bank.

This is used for Zeros and Ones testing and in Field Service Mode for any console selected pattern.

It executes out of the USER Instruction PAR's.

N

OTE

It is frequently modified dynamically such that (1) it returns after writing only (the 1st NOP is replaced with a RE-^STURN) or (2) it only counts Errors (the code PERRO2 and NOP are replaced with INC @PATERR)

6.2.2.2 Pattern 1 Address Test -

Writes & Reads an incrementing pattern equivalent to physical address into a 16K Bank.

It executes out of the USER Instruction PAR's.

6.2.2.3 Pattern 2 Complement Address Test -

Writes the complement of the physical address from high addresses to

low (write down) and reads from low addresses to high (read up).

SEQ 0095

This provides the complement of the coverage of Pattern 1 in both data pattern and addressing sequence.

It executes out of the USER instruction PAR'
5.

6.2.2.4 Pattern 3 3 XOR 9 -

writes & Reads a pattern that complements as address bits 4 and 10 change. This is because the PDP-11/70 fetches double words therefore a classical 3 XOR 9 in a small PDP-11 must look like a 4 XOR 10 in a PDP-11/70.

This pattern is run 4 times (1) with Zeros & Ones, (2) with Ones & Zeros, (3) with 401 & Ones, and (4) with Ones & 401. The pattern of the 401 is to force a the parity bits to become involved.

It executes out of the USER Data PDR's, the User Instruction PAR's, the Kernel Data PAR's and the Supervisor Data PAR's.

6.2.2.5 Pattern 4 Rota
ting Zeros Test -

Writes a background pattern of Ones. Rotates a Zero Carry Bit left thru each pair of bytes (18 times) and then checks that the carry is Zero and the word (2 bytes) is still all Ones.

It executes out of the User Data PAR's and the Kernel Data PAR's.

NOTE

It is not uncommon to observe the good data equal to the bad data. This indicates that the carry was not clear after 18 ROLB's.

6.2.2.6 Pattern 5 Rotating Ones Test -

Writes a background pattern of Zeros. Rotates a One carry bit left thru each pair of bytes (18 times) and then checks that the Carry is a One and the Word (2 Bytes) is still all Zeros.

This provides the complement of the coverage of Pattern 4 in data.

It executes out of the User Data PAR's and the Kernel Data PAR's.

NOTE

It is not uncommon to observe the good data equal to the bad data. This indicates that the Carry was not set after 18 ROLB's.

PAGE 60

6.2.2.7 Pattern 6 Initial Data Test -

Writes & Reads a double word first with all bits 0 except 1 (for every bit position), Second with all bits 1 except 1 (for every bit position).

This is a very quick check of the data paths.

6.2.2.8 Pattern 7 Address Bit Test -

Writes a background of all Zeros.

Read Address 1 for a 0 Byte.

te.

Complement Address 1.

Read Address 1 for a non 0 Byte.

For each Address B

it position from Bit 1:

Virtual (2, 4, 10, 20, 40, 100, 200, 400, 1000, 2000,

4000, 10000,

60000, 20000)

Physical (60002, 60004, 60010, 60020, 60040,

60100, 60200, 60400,

61000, 62000, 64000, 70000, 140000, 100000)

Read Addr

ess for a 0 word.

Complement Address contents.

Read Address for a non-zero

word.

This is a very quick check of the address bit uniqueness.

6.2

6.2.9 Pattern 10 Byte Addressing Test -

With ECC Disabled.

Writes all 0

nes to a double word.

For each of the 4 Bytes in the Double Word.

(Clears one

byte.

Reads all 4 bytes from double word.

Checks for only proper byte cle

ar.

All other bytes set to all ones.

This is only done on one double word
address.

1 8

SFU 1972

6.2.2.10 Pattern 11 Single Bit Error Test -

1. Create a Single Bit Error.
2. Read data Uncorrected (with ECC Disable).
3. Read First Word of data corrected (with ECC Enabled)
4. Check that the CSR Single Bit Error Flag was set.
5. Clear SBE Flag.
6. Read Second word of data corrected (with ECC Enabled).
7. Check that the CSR Single Bit Error Flag was set.
8. Do (1-7) for a Single Bit Error in each of 32 positions of a double word.
i.e. (32 Times)
9. If not in Quick Verify Mode then Do (1-8) for data consisting of 1 bit set in each of 32 positions of a double word.
i.e. (32 x 32 = 1024 Times)
10. Do (1-9) for complemented data (1 Bit clear in each of 32 positions of a double word).
i.e. (1024 x 2 - 2048 Times)
or (32 x 2 = 64 Times (Quick Verify))
11. Clear any errors out of test locations.

This insures that all Single Bit Errors can be corrected and detected.

6.2.2.11 Pattern 12 Write Byte Clears SBE Test -

1. Create a Single Bit Error.
2. Write a Byte of Double Word to Ones.
3. Read a Byte of Double Word.
4. If Byte that had SBE then the SBE Flag should be OFF.
If Byte that did not have SBE then SBE Flag should be set.
5. Byte should have been equal to Ones.
6. Do (1-5) for each of the 4 Bytes of the Double Word
7. Do (1-6) for a Single Bit Error in each of 32 positions of a Double Word
i.e. (32 Times)
8. If not in Quick Verify Mode then do (1-7) for data consisting of 1 Bit set in each of 32 positions of a double word.
i.e. (32 X 32 = 1024 Times)
9. Clear any errors out of test locations.

This insures that single bit errors in the data portion (not in check-bits) can be cleared by writing the corresponding byte and that writing any other byte does not change the existing single bit error.

6.2.2.
12 Pattern 13 (create Double Bit Error Test -

1. Create a Double Bit Error.
2. Access the Data (TST instruction).
3. Check that the CSR DBE Flags are both set.
4. Initialize CSR to allow parity traps on DBE's.
5. Access the Data (TST Instruction).
6. Check that a parity trap occurred.
7. Do (1-6) for the 2nd Bit of each Double Bit Error in each of 32 positions of a double word less the one position of the 1st Bad Bit.
i.e. (31 Times)
8. If not in Quick Verify Mode then Do (1-7) for the 1st Bit of each of Double Bit Error in each of 32 positions of a double word.
i.e. (31 x 32 = 992 Times)
9. Do (1-8) for complemented data (Ones versus Zeros in Double Word)
i.e. (992 x 2 = 1984 Times)
or (31 x 2 = 62 Times (Quick Verify))
10. Clear any errors out of test locations.

This insures that all Double Bit Errors can be created and detected and cause traps.

NOTE

This test is only run during the first
(QV) PASS when un
der ACT or APT.

6.2.2.13 Pattern 14 Write Inhibit During DATIP With DBE Test -

1. Create a Double Bit Error.
2. Do ASRB on Test Location.
3. Check that Double word is STILL Bad (Unchanged-with DBE).
4. Do (2-3) on all 4 Bytes of Double Word.
5. Do (1-4) for the 2nd bit of each Double Bit Error in each of 32 positions of a Double Word less the one position of the 1st Bad Bit.
i.e. (31 Times)
6. If not in Quick Verify Mode then Do (1-5) for the 1st Bit of each Double Bit Error in each of 32 positions of a double word.
i.e. (32 X 32 = 922 Times)
7. Do (1-6) for complemented data (Ones versus Zeros in Double Word).
i.e. (922 X 2 = 1984 Times)
or (31 X 2 = 62 Times (Quick Verify))
8. Clear any errors out of test locations.

This insures that the Double Bit Error can be cleared by a DATIP to any affected Byte.

NOTE

This test is only run during the first (QV) pass when under ACT or APT.

6.2.14 Pattern 15 wr
 the Inhibit Of Byte with DBE -

1. Create a Double Bit Error.
2. Do a MOV8 immediate to test byte.
3. Check that Double Word is still Bad (unchanged-with DBE).
4. Do (2-3) on all 4 Bytes of Double word.
5. Do (1-4) for the 2nd Bit of each Double Bit Error in each of 32 positions of a double word less the one position of the 1st Bad Bit.
 i.e. (31 Times)
6. If not in Quick Verify Mode then Do (1-5) for the 1st Bit of each Double Bit Error in each of 32 positions of a Double Word.
 i.e. (31 X 32 = 992 Times)
7. Do (1-6) for Complemented Data (Ones versus Zeros in Double Word).
 i.e. (992 X 2 = 1984 times)
 or (31 X 2 = 62 Times (Quick Verify))
8. Clear any errors out of test locations.

This insures that no Double Bit Error can be cleared by a MOV8 to any affected Byte.

NOTE

This test is only run during the first (QV) pass when under ACT or APT.

6.
2.2.15 Pattern 16 Write Inhibit Of Word With DBE Test -

1. Create a Double Bit Error.
2. Do MOV IMMEDIATE on test location.
3. Check that Double Word is STILL Bad (unchanged-with DBE).
4. Do (2-3) on both Double Words.
5. Do (1-4) for the 2nd Bit of each Double Bit Error in each of 32 positions of a Double Word less the one position of the 1st Bad Bit.
i.e. (31 Times)
6. If not in Quick Verify Mode then Do (1-5) for the 1st Bit of each Double Bit Error in each of 32 positions of a Double Word.
i.e. (32 X 32 = 992 Times)
7. Do (1-6) for Complemented Data (Ones versus Zeros in Double Word).
i.e. (992 X 2 = 1984 Times)
or (31 X 2 = 62 Times (Quick Verify))
8. Clear any errors out of test locations.

This insures that no Double Bit Error can be cleared by a MOV to any affected word.

NOTE

This test is only run during the first (QV) pass when under ACT or APT.

6.2.2.16 Pattern 17 Holding 1's & 0's Test -

1. Write a 16K Bank with alternating Bytes of Zeros & Ones writing a Byte at a time.

2. Read each Word for correct pattern.

3. Do (1-2) again for a complement pattern.

This checks the memory for the capability of holding 0's & 1's.

6.2.2.17 Pattern 20 Marching 0's & 1's In Check Bits Test -

1. Write Double Words of 000000,,100000 which causes check bits to equal 100 while addressing increments.
(Write Up/100 --> check bits)
 2. If in Quick Verify Mode then Go to Step (5).
 3. REad Double Words & check while writing Zeros and addressing decrements.
(Down / 100 --> 077)
This flips all the checkbit
 4. Read Double Words & check while writing 000000,,100000 while addressing increments.
(Up / 077 --> 100)
 5. Read Double Words & check while writing Zeros & addressing increments.
(Up / 100 --> 077)
 6. Read Double Words & check while writing 000000,,100000 while addressing decrements.
(Down / 077 --> 100)
 7. Read Double Words & check while Addressing increments.
(Up / 100)
- This checks the integrity of the MOS chips that store the checkbits

6.2.2.18 Pattern 21 Marching 0's & 1's Test -

1. Write a Background of alternating Bytes of Zeros & Ones

2. For the 16K Bank addressing Down
 (a) Read check a word
 (b) Byte Swap a word

(c) Read check a word

3. For the 16K Bank addressing Up

(a) Read check a word
 (b) Byte Swap a word
 (c) Read check a

word

4. For the 16K Bank addressing Up

(a) Read check a word

(b) Byte Swap a word
 (c) Read check a word

5. For the 16K Bank addressing Down
 (a) Read check a word
 (b) Byte Swap a word
 (c) Read check a word

This checks the integrity of the 32 Bit Double Words.

It executes out of the User Data PAR's.

NOTE

It is not uncommon to see a misleading error typeout because the second test in each case is based upon a byteswap of the first test which may or may not have failed. If the error report indicates errors in pairs with the bad bit in the second report being the same bit posi-

ould

tion relative to a byte then you s
ignore the second error report.

6.2.2.19 Pattern 22
Refresh Test -

1. Write a diagonal pattern of ones on every KDIAG (TH) stripe & write zeros elsewhere.

This pattern is on addresses not bit positions.

Example:

Address	MSB's
1 0 0 0 1 0	----- LSB's : 0 0 0 1 0 0 0 1 : 0 0
0	: 0 1 0 0 0 1 0 0 : 1 0 0 0 1 0 0 0 : 0 0 0 1 0 0 0 1 : 0 0 1 0 0 0 1 0 : 0 1 0 0 0 1 0 : 1 0 0 0 1 0 0 0

NOTE

Example uses KDIAG of value 4 more typical is a value of 8. Consult the symbolic definition of 'KDIAG' in the program listing to be sure.

2. Disturb each row for > 3.2ms
3. Read check diagonal pattern
4. Do (1-3) KDIAG times moving the placement of the diagonal stripe to cover all address positions.
5. Do (1-4) for a complement pattern (zeros in a background of ones)

NOTE

This
test is not normally executed ex-
cept under APT or ACT.
It may be in-
voked via Field Service Command 13 (Ka-
mikaze Mode).

6.2.2.20 Pattern 23 Shifting Diagonal Pattern Test

Similar in overall operation to pattern 22 except it does not delay for refresh and disturb rows.

NOTE

This test is not normally executed except under APT or ACT. It may be invoked VIA Field Service Command 13 (Ka-mikaze Mode).

6.2.2.21 Pattern 24 Fast Galloping Pattern Test -

This does a classical galloping pattern except that addressing is incremented by 400 Octal (every 64th double word)

NOTE

This test is not normally executed except under APT or ACT. It may be invoked VIA Field Service Command 13 (Ka-mikaze Mode).

6.2

.2.22 Pattern 25 Interrupt Enable Test -

1. Set CSR to Allow DBE Traps.
2. Access Test Double Words.
3. Check for no Double Bit Error Trap.
4. Enable CSR for SBE Traps.
5. Access Test Double Words.
6. Check for no SBE Trap.
7. Write a SBE in 1 Byte.
8. Disable CSR for Parity Traps.
9. Access Test Double Words.
10. Check for no Traps.
11. Enable CSR for SBE Traps.
12. Access Test Double Words.
13. Check to Insure Trap Occurred.
14. do (7-13) for the 3 other Bytes in the Double Word.
15. Create a DBE in 1 Byte.
16. Disable CSR for Parity Traps.
17. Access the Test Double Word.
18. Check for no Traps.
19. Enable CSR for DBE Traps.
20. Access the Test Double Word.
21. Check to Insure Trap Occu

rred.

22. Enable CSR for SBE Traps.

23. Access the Test Double Word.

24. Check to Insure Trap Occurred.

25. Do (15-24) for the 3
other Bytes in the Double Word.

This insures that SBE's & DBE's give the correct type of traps.

6.2.2.23 Pattern 26 Random Data Test -

Write Random Data in a 16K Bank while incrementing the Addresses.

Read check Random Data

This routine regenerates the same random numbers by using the same seed as the write sequence. After the read check the seed is updated so that the next use of this pattern will not invoke the same sequence of random numbers.

If you wish to change the random sequence so that it is different than any other run in the same configuration then there are 2 ways of doing so.

1. Modify symbolic locations 'SEEDHI' and 'SEEDLO' to any number like you like.
2. Enter Field Service Mode and execute this pattern (command 5) on some (any good) bank for a short time (30 sec or so).

This executes out of the User Data PAR's, the Kernel Data PAR's, and the Supervisor Data PAR's.

6.2.2.24 Pattern 27 Unique Bank Test -

This pattern uses Pattern 0 to write & read the Bank number in each bank.

It does not test Banks that require relocation to test.

It does not run as part of any script but rather is always run after normal pattern tests are complete.

6.2.2.25 Pattern 30 Flush Out DBE's Test -

This Reads each location then
moves the old value back in. This is
done with ECC Disabled and therefor
e corrects any DBE's or SBE's (if
possible).

It does not run as part of any
script but rather is always run just
prior to the End of Pass Code, as pa
rt of a Control 'C' (Boot) com-
mand, as part of End of Pass shutdown for ACT o
r XXDP Chain Mode, as
part of hanging sequence after an error if under ACT
or APT, and as
part of a shutdown sequence directed by Switch 8 (Halt Program)

6.2.7.26 Pattern 3' SOB-A-LONG Test -

Rationalization

In order to concentrate the memory cycles of a test into a particular address, we must cut the overhead cycles to a minimum. Frequently, the instruction itself may provide adequate data or set up a background in which any complemented bit may find it hard to survive.

The SOB instruction is the only PDP-11 instruction that is (1) a single operand, (2) can be repeatedly executed at the same PC and, (3) can escape this repetitious loop.

Hence, I believe it is possible to SOB a MOS cell to death (or at least brain wash him), and to SOB a core into over-heating (or at least warm discomfort).

The SOB Routine will be loaded and called with R0 set equal to the SOB constant 'SOBK', R1 set equal to the complement of a 'SOB R0..' Instruction '100776'.

Simplified SOB Example:

```

1$: SOB R0,1$ ;SOB till R0 underflows
M
OV R1,1$ ;Write complement of SOB
CMP R1,1$ ;Read check not SOB
BEQ 2$ ;
Skip if OK
SOBFAIL ;Trap report error
2$: SOBMOV1 ;Code to get self moved
SOBMOV2 ;forward 1 word and run again
SOBMOV3
SOBMOV4
SOBMOV...
    
```

The value of the SOB constant can be found at symbolic location 'SOBK' (typical 25 decimal).

This test is not in the normal script of execution but may be added

via the APT E-TABLE, reference symbolic locations 'MKPAT', 'MJPAT'.
Field Service Mode command 8 is the normal method of running this pattern.

SEO 0119

NOTE

This test is not normally executed except under APT or ACT. It may be invoked VIA Field Service Command 13 (Kamikaze Mode).

PAGE 74

6.2.2.27 Pattern 32 Skewed Up Address Test -

Referen
ce the Multiport section

6.2.2.28 Pattern 33 Write Recovery Test -

This test causes a WRITE, READ, WRITE, READ, ... to occur in memory and if the 1st, 3rd, 5th, ... READ is bad the program may bomb or if the 2nd, 4th, 6th, ... READ is bad the program will gracefully type out the error.

W
RITE RECOVERY TEST
THIS TEST DIFFERS FROM OTHER TESTS IN THAT IT CONSISTS OF A SMALL TEST PROGRAM ACTUALLY RUNNING IN THE BANK UNDER TEST. THE PROGRAM IS SELF MODIFYING AND MAY BE DIFFICULT TO DEBUG. TO AID IN THE DEBUG, REMEMBER THAT THE BANK AND MARGIN ARE BEING DISPLAYED. THIS WILL ALLOW THE USER TO AT LEAST SEE WHICH MEMORY BANK FAILED. THE TEST CONSISTS OF 1/2 OF THE BANK STORED WITH 'MOV R2, -(PC)'' AND THE OTHER 1/2 CONTAINING '177667'. '177667' IS THE COMPLEMENT OF 'JMP (R0)'' INSTRUCTION. R2 CONTAINS 'COM -(R1)'' INSTRUCTION ON ENTRY TO THE BANK AND R1 CONTAINS THE HIGHEST TEST ADDRESS IN THAT BANK.

IF YOU UNDERSTAND THIS SO FAR THE REST IS EASY.
THE TEST EXECUTION IS A

S FOLLOWS:

1. THE 'MOV R2, -(PC)'' INSTRUCTION EXECUTES STORING THE CONTENTS OF R2 IN THE ADDRESS IT VACATED (DUE TO -(PC)).
2. SINCE R2 CONTAINS A 'COM -(R1)'' INSTRUCTION IT COMPLEMENTS THE HIGHEST ADDRESS UNDER TEST. THIS ADDRESS CONTAINED '177667' SO AFTER THE COM -(R1) IT EQUALS 110 CLEVERLY THIS IS THE 'JMP (R0)'' INSTRUCTION.
3. THIS SEQUENCE CONTINUES UNTIL THE 'MOV R2, -(PC)''

INSTRUCTIONS REACH THE MIDDLE OF THE TEST BANK.
THEN THE "J"
MP (RO)" INSTRUCTION IS MET
AND EXECUTED. RO CONTAINED THE RETURN ADDRESS B
ACK

TO TEST 13.
4. THESE STEPS ARE REPEATED FOR EACH BANK UNDER TEST.

NOTE

This test is not normally executed except under APT or ACT. It may be invoked VIA Field Service Command 13 (Kamikaze Mode).

GE 75

6.2.2.29 Pattern 34 Branch Gobble Test -

This test loads a small routine into the memory under test. The routine moves itself along in memory one word after each pass so that when it reaches the end every instruction has executed from every location with the exception of the beginning and end of each test area.

The Branch Gobble's general format after you eliminate setup code and code to move the program along is as follows.

```

BGTES
T:          0          ;TEST WORD
BRGOBB: SEC
          ADCB      BGTEST      ;INC LOW BYTE
          BMI       1$          ;END LOOP
AFTER 128 TIMES
          INCB      BGTEST+1    ;INC HIGH BYTE
          BR        BRGOBB      ;LOOP 128 TIMES
1$:
          BVS       2$          ;BRANCH IF V-BIT SET (SHOULD BE)
          ERROR
2$:
          CLV
R V-BIT
          INCB      BGTEST      ;INC HIGH BYTE ONE LAST TIME
          BCS       3$          ;BRANCH IF C-BIT S
ET (SHOULD NOT BE)
          BVC       3$          ;BRANCH IF V-BIT CLEAR (SHOULD NOT BE)
          BMI       4$          ;B
RANCH IF N-BIT SET (SHOULD BE)
3$:      ERROR          ;ERROR TRAP
4$:      RETURN

```

This code originally came from the PDP-11 Family Instruction Exerciser DZQKA-A.

The first MOS memorys fell succetable to this section of that diagnostic and it has been an important memory exerciser ever since.

NOTE

This test is not normally executed except under APT or ACT. It may be invoked

VIA Field Service (Command 13 (ka-
mikaze Mode).

G 10

SEO 0123

6.2.2.30 Pattern 35 Soft Error Test -

Rationalization

MOS chips have a failure mode in which they can randomly pick or drop bits. This is caused by Alpha particles bombarding the cell. If the cell is very small (and they are) then the electrons displaced by the Alpha particle are sufficient to cause the cell to change from a one to a zero or from a zero to a one.

This test is controlled by the main program so that it is used to create a pattern of 125252 and 52525 on alternate passes of the program. The configuration table is used to flag banks that have the pattern invalidated because another pattern was written over this background.

This pattern is nothing more than a clever use of pattern 0.

6.2.2.31 Pattern 999 Null Test -

This is an instant return added to preserve the software structure.

This pattern replaces any real patterns when the APT E-Table does not specify a pattern to be run.

77

7.0 Program Features

7.1 Fast Data Access Rates

One of the main areas of concern in testing memory in systems environments is speed

It is my belief that one of the prime reasons that system programs like RSI, S, IAS and PUMPS can crash due to memory failures not detectable by memory diagnostics (0-124k, 0-2 MEG, etc.) is because of multiple NPR devices contending for the bus. After some delay a NPR device becomes bus master with his s ilo backed up (perhaps only 3-8 words) and does several memory transfers at memory data rates.

On the other hand most diagnostics when writing reading and/or checking patterns spend most of their time fetching instructions and operands out of their program space and proportionally little time accessing the memory under test.

I have attempted to optimize this diagnostic's error detecting abilities around the primary design criteria of speed. To this end I have taken the following steps.

7.1.1 Fast City -

Utilization of Memory Management Registers as Non Memory Bus, Non UNIBUS, Bipolar

Memory. Since user mode is only used for relocation and data space is never used then subroutines can be executed from the UIPAR's, UDPAR's, KDPAR's, SDPAR's and with some Bit Pattern restrictions the UIPDR's, UDPDR's, KDPDR's, and SDPDR's.

The program runs in kernel mode and Patterns are executed in Su

pervi-
sor mode for mapping purposes. All core patterns and some MOS Pat-
terns are subroutines that are moved to this Bipolar region referred
to in th
e program as Fast City.

PAGE 78

7.1.2 SOB's -

Utilization of the PDP-11/70 Instruction Set to speed pattern algorithms (principally the SOB). No attempt is made to support anything less than a PDP-11/70.

7.1.3 CACHE -

CACHE is used between pattern tests to decrease program pass times. CACHE can be defeated or partially disabled by the operator (reference section 2.3.3.1)

7.2 Bank Zero Testing

Bank Zero has been traditionally neglected by memory diagnostics for the following reason.

The vector space exists there and ALL traps must not access test pattern data. If the area is tested the diagnostic must not use any traps and it is against the rules for power to fail.

Systems with memory management can overcome this because all traps are in Kernel Virtual space even power fail (caution must be observed because power up goes to physical address 24 (because the Memory Management Unit comes up off)).

However, Catch 22 is that the diagnostic is not APT compatible in this mode because APT Accesses Physical Memory Locations.

PDP-11/70 Systems can overcome this because the UNIBUS MAP can fool APT.

Because of the previous arguments this program does not relocate in the true sense of the word (i.e. no position independent code was

written (at least not on purpose), but rather this program moves and remaps (hereafter referred to as relocates). This enables the complete testing of Bank Zero or any other program space or privileged space exactly as all other banks are tested. (The conditional test to see if a bank is protected is complemented when relocated).

7
7.3 Differences In Core Testing With 0-2 MEG (DEMJA)

7.3.1 Delta Noise
Test Only Performed With 3 XOR 9 Test -

Reason: DEMJA performed the delta noise test with constant data however, it will only have an adverse effect if performed with a worst-case pattern.

7.3.2 8 XOR 13 Test Deleted -

Reason: Designed for a PDP11-20 Memory not presently in use.

7.3.3 3 XOR 9 Rewritten -

Reason: was actually a 4 XOR 9 and should have been a 4 XOR 10 for PDP-11/70's to account for reading Double Words.

4. Memory Configuration Map

This map is printed out immediately after sizing the memory if SW6 is set (reference section 2.3.1). It can also be printed at any later time in Field Service Mode (reference section 2.3,4,3,7)

Example:

```

          MEMORY CONFIGURATION MAP

          16K BANKS
                1      2      3      4      5      6      7
012345670123456701234567012345670123456
7012345670123
ERRORS                XX
CPU MAP 111111111111111111111111111111111111
11100000000000000000000000000000000000
INTRLV 222222222222222222222222222222222222??????
????????????????????
MEMTYPE KKKKKKKKKKKKKKKKKKKKKKKKKKKKKKK000000000000000000
000000000000
BOX      00000000000000000000000000000000000000000000000000000000
?
PROTECT P P
          0      1      2      3      4      5      6
          4567012345670123456
70123456701234567012345670123456701234567
ERRORS
ACCESSED000000000000000000000000000000
00000000000000000000000000000000000000000000000000000000000000
INTRLV  ?????????????????????????????????????????????????????
????????????????????????????????????
MEMTYPE 00000000000000000000000000000000000000000000000000000000
000000000000000000
BOX      ?????????????????????????????????????????????????????????
????????
PROTECT

```

Displayed are Banks 0-167 Octal (2 meg words). If the Fat Terminal Switch was set (reference section 2.3.1) then all Banks would fit on one line.

The sizing routine could not write zeros and ones in Banks 20 & 21 hence they are marked as bad with X's.

The only CPU was able to access banks 0-37 (512 K words). If more CPU's were present this would be

a Hexadecimal number indicating which
 (PU's (SLAVE3,SLAVE2,SLAVE1,MASTER) coul
 d access each bank.

The interleaving on Banks 0-37 is 2 way. This may be ext
 ernal with no
 internal or internal with no external - however since there is
 only
 one box of MDS (BOX 0) it must be internal interleave.

Banks 0-37 are
 Memory Type K (MK11) and Banks 40-167 do not exist.
 Memory Type J would ind
 icate MJ11 memory.

Banks 0-37 are located in box 0. Boxes are assigned to CS
 R locations
 in order and MJ11 Boxes will never have a Box number only a ques
 tion
 mark.

Banks 0 and 2 are protected because they are program space. Ba
 nk 0
 and 2 are also protected because they are in the bottom 16K of an MK11
 c
 ontroller. The protection is hierarchical and program space oversha-
 dows MK11
 protection. Banks 0 and 2 will not be tested until the pro-
 gram relocates.

If any bank is protected by MK11 and not because it
 is in program space it wi
 ll have a 'X' typed in this row.

7.5 Everything You've Always Wanted To Know About SUPERMAC ...

SUPER-MAC is a set of structured programming macros that allows programs to be written in a high level, easily understood language.

As a general rule, most SUPER-MAC statements can be single-line statements or multiple-line (nested) block statements. A single-line statement must be completed on one source line; no continuation lines are allowed. Single-line statements should be as short and simple as possible. Comments may also be included on a source line. All the general rules, conditions, etc., that govern MACRO-11 also govern SUPER-MAC. Spacing on a source line is very important. The elements should be separated by a comma or a space. Tabs should never be used for spacing. For example: The expression $A+B$ is interpreted differently than $A + B$.

All the conditional statements can be written as multiple-line nested blocks. Each level of nesting within a block must be terminated with an associated END statement. Each level of nesting should be indented two spaces.

User written macros or assembly language instructions may be included in a program if desired. As a debugging aid, if the symbol LST\$\$ is defined, it will cause generated code and labels to be listed. All programs must begin with the macro call SMACIT. This call initializes SUPER-MAC. All legal PDP-11 source and destination operands are legal in SUPER-MAC.

7.5.

1 Sample Source File -

```
.ENABL ABS
.ENABL AMA
.MCALL .SUPER
.SUPER
;L
```

STSS-0

```
BIT5=40
A: 0
B: 0
C: 0
D: 0
E: 0
F: 0
G: 0
H: 0
I: 0
J: 0
;L
```

ET EXAMPLES

```
LET RO := A
LET B := C + D
LET E := F + #1
LET G := H + #2
```

```
LET J := J + #01
LET A :B B
```

:IF EXAMPLES

```
IF A IS TRUE
MOV #23,D
END ;OF IF A
IF B IS FALSE
MOV #34,E
END ;OF IF B
IF A EQ B THEN LET
```

C :- D

```
IF A LT B
MOV C,D
ELSE
MOV E,D
END ;OF IF A
IF A EQ B AN
```

D C NE D

```
MOV F,G
END ;OF IF A
IF A EQ B OR C NE D
MOV F,G
END ;OF
```

IF A

```
IFB A EQ B AND C EQ #1
MOV H,J
ELSE
MOV E..
```

```
END ;OF IFB A
IFB A EQ B ANDB C EQ #1
  MOV H,C
ELSE
  MOV E,J
END ;OF IFB A
IF RES
ULT IS EQ
  MOV A,B
END ;OF IF RESULT
IF #BITS SET.IN A
  MOV B,C
END
;OF IF #BITS
```

```

IF #BITS OFF IN A
MOV C,D
END ;OF IF #BITS
:ON.ERROR
IS LIKE AN IF STATEMENT ON THE C-BIT
:ON.ERROR EXAMPLES
ON.ERROR
MOV A,B

ELSE
MOV C,B
END ;OF ON.ERROR
ON.NOERROR
MOV C,B
ELSE
MOV A,

E
END ;OF ON.NOERROR
ON.ERROR THEN LET A :B :B
:FOR EXAMPLES
FOR I :- #-
5 TO #23
INC A
END ;OF FOR I
FOR RO :- #0 TO #140 BY #4
DEC A(RO)

END ;OF FOR RO
FOR I : #133 DOWNT0 #3 BY #2
ADD A,B
END ;OF FOR

I
:BEGIN EXAMPLES
BEGIN ALPHA
FOR RO : #0 TO #167
MOVB A(RO),B
IF B LT #0 THEN LEAVE ALPHA
END ;OF FOR RO
FOR RO :- #400 TO #567

IF B GE #0 THEN LEAVE ALPHA
END ;OF FOR RO
END ALPHA
:RETURN EXAM
PLES
$RETURN
$RETURN ERROR
$RETURN NOERROR
:CASE EXAMPLES
MOV A,RC
CA
SF RO
A
B

```

DEF
END :OF CASE RO
.END

7.5.2 S

Example Listing File (with no expanded macros) - -

```

1 000000          .ENABL AB
S
2              .ENABL AMA
3              .MCALL .SUPER
R 4 000000          .SUPE
5              :LST$$=0
6              BITS=40
7 000000 000040
A: 8 000002 000000          B: 0
9 000004 000000          C: 0
10 0000
11 000000          D: 0
12 000010 000000          E: 0
13 000014 000000          F: 0
14 000016 000000          G: 0
15 000020 00          H: 0
0000 16 000022 000000 I: 0
18              J: 0
19              ;LET EXAMPLES
000024          LET RO := A
20 000030          LET B := C + D
21 000044          LE
TE := F + #1
22 000056          LET G := H + #2
23 000072          LET J :
J + #01
24 000100          LET A :B- B
25              ;IF EXAMPLES
106 27 000114 012737 000023 000006 IF A IS TRUE
                MOV #23,D
28          000122          END ;OF IF A
29 000122          IF B IS FALSE
30 000130 01          MOV #34,E
2737 31 000034 000010          END ;OF IF B
32 00          IF A EQ B THEN LET C := D
0136 33 000154          IF A LT B
34 000164          MOV C,D
013737 35 000172 000004 000006          ELSF
737 36 000174 013          MOV E,D
37 000010 000006          END ;OF IF A
38 000202

```

39	000222	013737	000012	000014	IF A EQ B AND C NE D MOV F,G
40	000230				END ;OF IF A
41	000230				IF A EQ B OR C NE D
42	0				
00250	013737	000012	000014		MOV F,G
43	000256				END ;OF IF A
44	000256				IFB A EQ B AND C EQ #1
45	000276	013737	000016	000022	
MOV	H,J				ELSE
46	000304				MOV
47	000306	013737	000010	000022	
	E,J				END ;OF IFB A
48	000314				IFB A EQ B ANDB C EQ
49	000314				
#1					MOV H,J
50	000334	013737	000016	000022	ELSE
51	000342				
52	000344	013737	000010	000022	MOV E,J
53	000352				END ;OF I
IF A					IF RESULT IS EQ
54	000352				
55	000354	013737	000000	000002	
	MOV A,B				END ;OF IF RESULT
56	000362				IF #BIT5
57	000362				
SET IN A					MOV B,C
58	000372	013737	000002	000004	
59	000400				
END ;OF IF	#BIT5				

97 000636
 98 000640
 99 000644
 100
 101 000650 000000
 102 000654 000000
 103 000664 000000
 104 000666 000002
 105 000670 000004
 106 00
 0672 000006
 107 000674 000010
 108 000676 000012
 109 000700
 110
 111 000001

A

\$RETURN
 \$RETURN ERROR
 \$RETURN NOERROR
 ;CASE EXAMPLES
 MOV A,RO
 CASE RO
 B
 C
 D
 E
 END ;OF CASE RO
 .END

0672

f

7.5.3

```

Sample Listing File (with expanded macros) - -
S 1 000000 .ENABL AB
2 .ENABL AMA
3 .MCALL .SUPER
R 4 000000 .SUPE
5 000000 LST$$=0
6 000040 BITS=40
7 000000 000000
00 8 000002 000000 A: 0 B: 0
9 000004 000000 C: 0
1 000006 000000 D: 0
0 11 000010 000000 E: 0
12 000012 000000
F: 0
13 000014 000000 G: 0
14 000016 000000 H: 0
15 000
020 16 000000 I: 0
17 000022 000000 J: 0
18 ;LET EXAMPLES
19 000024 LET RO := A MOV A,RO
000024 013700 000000
20 000030 LET B := C + D MOV C,B
000030 013737 000004 000002
00 00 ADD D,B
0036 21 063737 000006 000002
000044 LET E := F + #
1 000044 013737 000012 000010 MOV F,E
000052 005237 000010
22 000056 013737 000016 000014 INC E
000056 LET G := H + #2 MOV H,G
23 000064 062737 000002 000014 ADD #2,G
0000 72 23 0000 LET J := J + #01 ADD #01,J
000072 062737 000001 000022
24 000100 LET A :=B= B MOVB B,A
000100 113737 000002 000000
25 .IF EXAMPLES
26 000106 IF A IS TRUE
000106 005737 000000 TST A
000112 001403 BEQ LG

```

```

3 27 000114 012737 00002
    000006      MOV #23,D
28 000122      END ;OF IF A
    000122
.....
29 000122      IF B IS FALSE
    000122 005737 000002
                                TST B
                                BNE L1
30 000126 001003
    000130 012737 000034 000010      MO
V #34,E
31 000136      END ;OF IF B
    000136
                                L1:.....
32 000136      IF A EQ B THEN LET C := D
P A,B 000136 023737 00000C 000002
                                CM
                                BNE L2
    000144 001003
    000146 013737 000006 000004
                                MOV D,C
    000154
33 000154      IF A LT B
    000154 023
737 000000      CMP A,B
    000162 002004
                                BGE L3
34 000164 013737 000004 000006      MOV C,D
000172      ELSE
35 000172 0004
                                BR L4
03 000174
36 000174 013737 000010
    000006      MOV E,D
                                L3:.....

```

```

37 000202          END ;OF IF A          L4:****
   000202
::
38 000202          IF A EQ B AND C NE D
   000202 023737 000000 000002      CMP A,B          BNE L5
   000210 001007
   000212 023737 000004 000006          CMP C,D          BEQ L5
   000220 001403
39 000222 013737 000012          MOV F,I          END ;OF IF A
   000014
40 000230          END ;OF IF A          L5:****
   000230
::
41 000230          IF A EQ B OR C NE D
   000230 023737 000000 000002      CMP A,B          BEQ L6
   000236 001404
   000240 023737 000004 000006          CMP C,D          BEQ L7
   000246 001403          L6:*****
   000250
42 000250 013737 000012 000014      MOV F,G
43 000256          END ;OF IF          L7:*****
   000256
A
44 000256          IFB A EQ B AND C EQ #1
   000          CMPB A,B          BNE L10
256 123737 000000 000002
   000264 001010          CMP C,#1
   000266 023727 000004 000001          BNE
   000274 001004
L10
45 000276 013737 000016 000022      MOV H,J
46 000304          ELSE          BR L11
   000304 000403          L10:*****
   000306
47 000306          MOV E,J
   013737 000010 000022      MOV E,J          END ;OF IFB A
48 000314          END ;OF IFB A          L11:*****
   000314
   000314          IFB A EQ B AND B C EQ #1
49 000314 123737          CMPB A,B          BNE L12
   000314 000000
   000322 001010          CMPB C,#1
   000324 1          BNE L12
23727 000004 000001
   000332 001004

```

50 000334 013737 000016 000022
 51 000342
 000342
 000403
 000344
 52 000344 013737
 000022
 53 000352
 000352
 L13:::~::~
 54 000352
 000352 001003
 4
 55 000354 013737 000000 000002
 56 000362
 IF RESULT
 000362
 57 000362
 000362 032737 000040 000000
 000370 001403
 BEQ L15
 58 000372 013737 000002 000004
 59 000400
 ND ;OF IF #BITS
 000400
 60 000400
 .IN A
 000400 032737 000040 000000
 000406 001003
 61 000410 013737 000004 000006
 62 000416

MOV H,J
 ELSE
 MOV E,J
 END ;OF IFB A
 IF RESULT IS EQ
 MOV A,B
 END ;OF
 IF #BITS SET.IN A
 MOV B,C
 E
 IF #BITS OFF
 BNE L16
 MOV C,D
 END ;OF IF #BITS

BR L13
 L12:::~::~

BNE L1

L14:::~::~

BIT #BITS,A

L15:::~::~

BIT #BITS,A

```

        000416                                L16:*****
63      AN IF STATEMENT ON THE C-BIT          :ON.ERROR IS
64      00041                                :ON.ERROR EXAMPLES
65      00041                                ON.ERROR
66      000416 103004                          BCC L17
66      000420 013737 000000
        000002      MOV A,B
67      000426                                ELSE
        000426 000403                          BR L20
68      000430 013737 000004 000002          MOV C,B
69      000436                                END ;OF ON.ERROR
        000436                                L17:*****
70      000                                L20:*****
436    000436 103404                          BCS L21
71      000440 013737 00
0004    000002      MOV C,B
72      000446                                ELSE
        000446 000403                          BR
L22    000450                                L21:*****
73      000450 013737 000000 000002          MOV
74      000456                                END ;OF ON.NOERROR
        000456                                L22:*****
75      000456                                ON.ERROR THEN LET A :B= B
        000456 103003                          BCC L23
460    113737 000002 000000
        000466                                MOV B,A
        000466                                L23:*****
76      ;FOR EXAMPLES
77      000466                                FOR I := #-5 TO #23
        000466 012737
        177773 000020                                MOV #-5,I
        000474                                B0:*****
78      000474                                INC A
005237 000000
79      000500                                END ;OF FOR I
        000500 005237 000                                INC I
020    000504 023727 000020 000023          CMP I,#23
        000512                                BLE B0
003770                                E0:*****
80      000514                                FOR R
0 :    #0 TO #140 BY #4
        000514 005000                                CLR R0

```

```

000516
.....
81 000516 005360 000000
82 000522
FOR RO
000522 062700 000004
000526 020027 000140
000532 003771
000534
83 000534
000534 012737 000133
000020
000542
84 000542 063737
000000 000002
85 000550
000550 162737 0
00002 000020
000556 023727 000020 000003
3
000564 002366
000566
86
BEGIN EXAMPLES
87 000566
000566
88 000566
000566 005000
000
570

```

```

DEC A(R0)
END ;0
CMP R0,#140
FOR I : #133 DOWNT0 #3 BY #2
MOV #133,I
ADD A,R
END ;OF FOR I
SUB #2,I
BEGIN ALPHA
FOR RO := #0 TO #167

```

```

ADD #4,R0
BLE B1
E1:.....
B2:.....
CMP I,#
BGE B2
E2:.....
B3:.....
CLR R0
B4:.....

```

PAGE 89

```

      89 000570 116037 000000 000002      MOVB      A(R0)
      90 000576 005737 000002      IF B LT #0 THEN LEAVE ALPHA
      000602 002415      TST B
      91 000604      END ;OF F      BLT E3
OR RO 000604 005200      INC RO
      000606 020027 000167      CMP RO
      #167 000612 003766      BLE B4
      000614 0      E4:*****
      92 0      FOR RO : #400 TO #567
00614 000614 012700 000400      MOV #400,
RO 000620      B5:*****
      93 000620      IF B GE #0 THEN LEAVE AL
PHA 000620 005737 000002      TST B
      000624 002004      BGE E3
      94 000626      END ;OF FOR RO
      000626 005200      INC RO
      000630 02      CMP RO,#567
0027 000634 003771      BLE B5
      000636      ES:*****
      95 000636      END ALPHA      E3:*****
      000636
      96      ;$RETURN EXAMPLES
      97 000636      $RETURN
      000636 000207      RTS PC
      98 000640      $RETURN ERROR      SEC
      000640 000261
      00      RTS PC
0642 000207
      99 000644      $RETURN NOERROR
      000644 00024      CLC
      1      000646 000207      RTS PC
      100      ;CASE EXAMPLES
      101 000650 013700 000000      MOV      A,R0
      102 000654      CASE RO
      000654 0
10046 000656 006316      MOV RO,-(SP)
      000660 004737      ASL @SP
      000700      JSR PC,L24
      103 000664 000000      A

```

```

002 104 000666 000
      105 000670 000004
      106 000672 000006
      1
07 107 000674 000010
    108 000676 000012
    109 000700
:OF CASE R0
      000700
      000700 062616
SP 000702 013646
    000704 004736
.a(SP)+
  110
  111 000001
      .END

```

```

C
D
E
F
END

```

```

L24:.....
      ADD (SP)+,a
      R0V a(SP)+,-(SP)
      JSR PC

```


7.6 Banks & Boards (MK11)

Board
s with 4K MOS chips are 32K words each.
Boards with 16K MOS chips are 128K word
s each.

Imagine that the front view of the memory box is as follows:

BL 15
,13,11,9,7,5,3,1,CB,CA,DA,BL,AD,BL,CA,CB,0,2,4,6,8,10,12,14,BL

Where 0 thru 1
5 are the MOS array cards. CB is Control 'B'. CA is
Control 'A'. DA is t
he Data Interface. AD is the Address Interface.
BL is a Blank (unwired) slot i
n the backplane.

4k Parts with No Interleave

Array 15,13,11, 9, 7, 5, 3,
 1, 0, 2, 4, 6, 8,10,12,14
 Banks 36 32 26 22 16 12 6 2 0 4 10 14 20 24 30 34
 37 33 27 23 17 13 7 3 1 5 11 15 21 25 31 35

4k Parts with Internal Interleave

Array 15,13,11, 9, 7, 5, 3, 1, 0, 2, 4, 6, 8,10,12,14
 Banks 34 30
 24 20 14 10 4 0 0 4 10 14 20 24 30 34
 35 31 25 21 15 11 5 1 1 5 11 15
 21 25 31 35
 36 32 26 22 16 12 6 2 2 6 12 16 22 26 32 36
 37 33 27 23 17
 3 7 3 3 7 13 17 23 27 33 37

4k Parts with 2-1 External No Internal Interleave

Array 15,13,11, 9, 7, 5, 3, 1, 0, 2, 4, 6, 8,10,12,14
 Banks 74
 64 54 44 34 24 14 4 0 10 20 30 40 50 60 70
 75 65 55 45 35 25 15 5 1 11 21
 31 41 51 61 71
 76 66 56 46 36 26 16 6 2 12 22 32 42 52 62 72
 77 67 57 47 37
 7 27 17 7 3 13 23 33 43 53 63 73

4k Parts with 2-1 External Internal Interleave

Array 15,13,11, 9, 7, 5, 3, 1, 0, 2, 4, 6, 8,10,12,14
 Banks 70 6
 0 50 40 30 20 10 0 0 10 20 30 40 50 60 70
 71 61 51 41 31 21 11 1 1 11 21 3
 1 41 51 61 71
 72 62 52 42 32 22 12 2 2 12 22 32 42 52 62 72
 73 63 53 43 33
 3 23 13 3 3 13 23 33 43 53 63 73
 74 64 54 44 34 24 14 4 4 14 24 34 44 54 6
 4 74
 75 65 55 45 35 25 15 5 5 15 25 35 45 55 65 75
 76 66 56 46 36 26 16 6
 6 16 26 36 46 56 66 76
 77 67 57 47 37 27 17 7 7 17 27 37 47 57 67 77

4k Parts with 4-1 External No Internal Interleave

4k Parts with
erleave

4-1 External Internal Int

Array 15, 13, 11, 9, 7, 5, 3, 1, 0, 2, 4, 6, 8, 10, 12, 14

Banks 160 140 120 100 60 40 20 0 0 20 40 60 100 120 140 160

161 1

41 121 101 61 41 21 1 1 21 41 61 101 121 141 161

162 142 122 102 6

2 42 22 2 2 22 42 62 102 122 142 162

163 143 133 103 63 43 23 3

3 23 43 63 103 123 143 163

164 144 124 104 64 44 24 4 4 24 44

64 104 124 144 164

165 145 125 105 65 45 25 5 5 25 45 65 105 125

145 165

166 146 126 106 66 46 26 6 6 26 46 66 106 126 146 166

167

147 127 107 67 47 27 7 7 27 47 67 107 127 147 167

150 130 110

70 50 30 10 10 30 50 70 110 130 150

151 131 111 71 51 31 11

11 31 51 71 111 131 151

152 132 112 72 52 32 12 12 32 52 72 1

12 132 152

153 133 113 73 53 33 13 13 33 53 73 113 133 153

154 134 114 74 54 34 14 14 34 54 74 114 134 154

155 135 115 75

55 35 15 15 35 55 75 115 135 155

156 136 116 76 56 36 16 16 3

6 56 76 116 136 156

157 137 117 77 57 37 17 17 37 57 77 117 13

7 157

16K Parts with
No Interleave

Array 15, 13, 11, 9, 7, 5, 3, 1

0, 2, 4, 6, 8, 10, 12, 14

Banks 150 130 110 70 50 30 10 0 20

40 60 100 120 140 160

151 131 111 71 51 31 11 1 21 41 61 101 12

1 141 161

152 132 112 72 52 32 12 2 22 42 62 102 122 142 162

153 133 113 73 53 33 13 3 23 43 63 103 123 143 163

154 134 114

74 54 34 14 4 24 44 64 104 124 144 164

155 135 115 75 55 35 15

5 25 45 65 105 125 145 165

156 136 116 76 56 36 16 6 26 46

66 106 126 146 166

157 137 117 77 57 37 17 7 27 47 67 107 127 14

16x Parts with		Internal Interleave															
Array	15, 13, 11, 9, 7,																
5, 3, 1, 0, 2, 4, 6, 8, 10, 12, 14																	
Banks	160 140 120 100 60 40 20 0																
0	20 40 60 100 120 140 160																
61	101	161 141 121 101 61 41 21 1 1 21 41															
2	162	162 142 122 102 62 42 22 2 2 22 42 62 102 122 14															
4	124	163 143 123 103 63 43 23 3 3 23 43 63 103 123 143 163															
45	25	164 14 165 145 125 105 65 5 5 25 45 65 105 125 145 165															
26	46	166 146 126 106 66 46 26 6 6 167 147 127 107 67 47 27 7 7 27 47 67															
107	127	147 167 150 130 110 70 50 30 10 10 30 50 70 110 130 150															
52	32	151 131 111 71 51 31 11 11 31 51 71 111 131 151															
33	53	152 132 112 72 52 32 12 12 32 52 72 112 132 152															
4	154	153 133 113 73 53 33 13 13 154 134 114 74 54 34 14 14 34 54 74 114 13															
6	116	155 135 115 75 55 35 15 15 35 55 75 115 135 155															
17	17	156 13 157 137 117 77 57 37															

						160	120	60	20	20	60	120	160
21	21	61	121	161		161	121	61					
						162	122	62	22	22	62	122	162
63	123	163				163	123	63	23	23			
						164	124	64	24	24	64	124	164
165						165	125	65	25	25	65	125	
						166	126	66	26	26	66	126	166
						167	127	67	27	27	67	127	167
	130	70	30	30	70	130							
						131	71	31	31	71	131		
32	72	132				132	72	32					
						133	73	33	33	73	133		
						134	74	34	34	74	134		
	135	75	35	35	75	135							
						136	76	36	36	76	136		
37	77	137				137	77	37					

16K Parts with 4-1 External and No Internal Interleave

Array Banks	15	13	11	9	7	5	3	1	0	2	4	6	8	10	12	14
40	0	100					140									
							141	41	1	101						
							142	42	2	102						
							143	43	3	103						
	144	44	4	104												
							145	45	5	105						
							146	46	6	106						
							147	47	7	107						
							150	50	10	110						
							151	51	11	111						
							152	52	12	112						
							153	53	13							
113																
							154	54	14	114						
							155	55	15	115						
							156	56	16	116						
							157	57								
17	117															
							160	60	20	120						
							161	61	21	121						
							162	62	22	122						
							163									
63	23	123														
							164	64	24	124						
							165	65	25	125						
							166	66	26	126						
167	67	27	127													
							70	30	130							
							71	31	131							
							72	32	132							
							73	33	133							
							74	34	134							
							75	35	135							
							76	36	1							
36																
							77	37	137							

16K Parts with 4-1 External and Internal Interleaving

Array Banks 15, 13, 11, 9, 7, 5, 3, 1, 0, 2, 4, 6, 8, 10, 12, 14

		100	0	0	100
		101	1	1	101
		102	2	2	102
		103	3	3	1
03					
		104	4	4	104
		105	5	5	105
		106	6	6	106
		107	7		
7	107				
		110	10	10	110
		111	11	11	111
		112	12	12	112
		113	1		
3	13	113			
		114	14	14	114
		115	15	15	115
		116	16	16	116
		1			
17	17	17	117		
		120	20	20	120
		121	21	21	112
		122	22	22	122
		123	23	123	
		124	24	24	124
		125	25	25	125
		126	26	26	12
6					
		127	27	27	127
		130	30	30	130
		131	31	31	131
		132	32	32	
		133	33	33	133
		134	34	34	134
		135	35	35	135
		136	36		
36	136				
		137	37	37	137
		140	40	40	140
		141	41	41	141
		14			
2	42	42	142		
		143	43	43	143
		144	44	44	144
		145	45	45	145

146 46 46 146

147 47 47 147
150 50 50 150
151 51 51 151

152 52 52 152
153 53 53 153
154 54 54 154
155 55 55

156 56 56 156
157 57 57 157

155

PAGE 96

61	161	160	60	60	160
		161	61		
		162	62	62	162
		163	63	63	163
		164	64	64	164
		16			
5	65	65	165	166	66
				167	67
				70	70
71	71			72	72
				73	73
				74	74
				75	75
76	76				
				77	77

7.7 Memory Management Mapping

PAR NEL ----	SUPERVISOR USER -----	KER -----	----
0 Mem	Program	Program	Src Bk/Fst
1	Program	Program	Src Bk/Fst Mem
2 st Mem	Program	Program	Src Bk/F
3	Test Area	Program	Src Bk/Fst Mem
4 Bk/Fst Mem	Test Area	Program	Dst
5	Test Area	Program	Dst Bk/Fst Mem
6	Test Area	Map to CSR	
's	Dst Bk/Fst Mem		
7	Perif Page	Perif Page	Dst Bk/Fst Mem

7.8 Listing format

The program listing is in two parts. The first part is a complete listing the way it was used by the author. Macros are not expanded and an effort was made to keep each section on one or two pages. The second part is a complete listing with all macros expanded to show all generated code in a program locations. This last listing is for those who have a need to look at the actual assembly language code and the generated binary.

You see -
you can have your cake and eat it too.

8.0 MULTIPORT SYSTEM ORGANIZATION

The multiport section of the MKAII Diagnostic runs after the completion of testing as a single port system but before the end-of-pass code.

The tests are performed on a Master-slave basis with the Master being the CPU that the diagnostic is started at.

8.1 Starting Slaves

The Master will use the IIST and Multiprocessor boot to start and identify all slave CPU's with software locks to insure that only one CPU runs at a time (not ASRB locks). If the IIST or Multiprocessor Boot is not available they may be bypassed by starting at address 204 and following the dialogue for manual intervention.

8.1.1 Starting Code -

As each slave starts it executes shared code with the master using its own unique stack. The master has set the 'CPUBIT' to indicate slave status and loops until the slave started places his unique IIST ID number (or System ID number if IIST's are bypassed) in the port directory. This is done for each slave, after which the master sets the 'CPUBIT' to indicate master status.

Each slave when started sizes memory indicating accessed banks via a Bit Set of the 'CPUBIT' into the configuration table. If IIST's are in use it enables interrupts on its IIST, lowers its priority to 4 and executes a WAIT until the master wakes it up. If IIST's are by-

passed it moves a little program into the User PAR's and Jumps to it.

This program waits for the master to write a countdown from 10 to 0 in the slaves pseudo I/O buffer location. Either way this is known as the Sleep state.

SEO 0143

After all slaves have been put to sleep the master checks the port directory of ID numbers and insures that each CPU has a unique number.

Testing is now started as in a normal single port environment. Each slave remains dormant during this time.

8.2 Multiport Testing

The master wakes each slave via a interrupt with the IIST (or if IIST's are bypassed via a countdown).

The master then orders each slave to run the MK11 (SR tests. The master now orders each slave to relocate to a unique memory bank that has no errors. Usually this is puts slave 1 in Bank 1, slave 2 in Bank 3 and slave 3 in bank 4).

The master then directs each slave and also himself in the execution of the following tests.

	Access Paths Test
Address Test	Asynchronous Access Address Un
iqueness Test	Skewed Up Address Test
Port Arbitration Symmetry test	I/O Priority T
est	Execution Contention Test
ASRB Test	CACHE Flush Test

Next the master orders each slave to stop and each slave will map back into bank 0 (shared code area), lower it's priority to 4 and execute a wait instruction thereby sleeping until the next pass.

The master then returns to single port testing just prior to the end-of-pass code.

8.2.1 Access Paths Test -

The master causes each CPU (making himself a slave when necessary) to write into memory and all other CPU's to simultaneously read.

This is done as follows:

```
FOR EACH CPU
  FOR EACH BANK
    IF BANK IS ACCESSABLE & NOT PROGRAM SPACE
      FOR EACH OF 5 PATTERNS
        SELECTED CPU WRITES
        ALL OTHER CPU'S READ
        NEXT PATTERN
      NEXT BANK
    NEXT CPU
```

8.2.2 Address Test -

The master causes each CPU (making himself a slave when necessary) to write an address pattern into memory and all other CPU's to simultaneously read.

This is done as follows:

```

      FOR EACH CPU
        FOR EACH BANK
          IF BANK IS ACCESSABLE
            & NOT PROGRAM SPACE
              FOR EACH ADDRESS PATTERN
                --AND COMPLEMENT ADDRESS PATTERN
                  SELECTED CPU WRITES
                    ALL OTHER CPU'S READ
                  NEXT PATTERN
                  NEXT BANK
                NEXT CPU

```

8.2.3 Asynchronous Access Address Uniqueness Test -

The master causes each CPU (making himself a slave when necessary) to test 5 patterns on 1/4 bank simultaneously. This insures that no address errors will allow corruption of another CPU's data.

This is done as follows:


```

      FOR EACH BANK
        IF BANK IS ACCESSABLE & NO
          * PROGRAM SPACE
            FOR EACH OF 4 STARTING ADDRESSES
              FOR EACH OF 5 PATTERNS
                EACH CP
                  U TESTS 5 PATTERNS ASYNCHRONOUSLY
                    NEXT PATTERN
              NEXT STARTING ADDRESS
            NEXT BANK

```

8.2.4
Skewed Up Address Test -

The master causes each CPU (making himself a slave when necessary) to write and read there IIST ID number in every 4th address - skewed by 1 address and offset by there IIST ID number. Assuming a 4 CPU system then example data would be.



This is done as follows:

```

EACH BANK      FOR
                IF BANK IS ACCESSABLE & NOT PROGRAM SPACE
                FOR EACH OF 4 STARTING ADDRESSES
EACH CPU RUNS THE SKEWED UP ADDRESS TEST
                --OFFSET BY

```

IT'S IIST ID

M 13

NEXT STARTING ADDRESS

SEQ 0148

NEXT BANK

8.2.5 Port Arbitration Symmetry Test -

The master causes each
 (PU (making himself a slave when necessary) to
 access (with memory fetches o
 f MOV R5,R5 instructions) the same loca-
 tion 64K times. Each slave executes o
 ut of the memory bank under test
 thereby increasing the probability of conten-
 tion. While this access
 loop is executing each slave is counting tics of
 the line clock
 (KILL) under interrupt control.

After each slave completes
 his access test he passes his tic count
 back to the master for analysis.

The master checks every bodies tic count against his own and if any
 differ
 by more than 2 tics he reports an error.

This is done as follows:

```

        FOR EACH BANK
          IF BANK IS ACCESSABLE &
NOT PROGRAM SPACE
            ALL CPU'S RUN CONTENTION TEST
            CHECK TIC COUNTER FOR BALANCE
            NEXT BANK
    
```

8.2.6 I/O Priority Test -

This tests the ability of the memory port to give I/O higher priority than CPU accesses.

Since the difference is difficult to measure on small configurations this test is only run when there are 4 CPU's present.

The master causes each CPU (except one) to raise his priority to that of I/O. This is done by setting a margin of 6 in the maintenance register of the PDP11-70.

The master causes all CPU's to run the same access test as the 'Port arbitration symmetry test'. In the symmetry test the master checks for a balance. In this test the master checks for an lack of balance.

This is done as follows:

FOR EACH BANK

IF BANK IS ACCESSABLE & NOT PROGRAM SPACE

FOR EACH CPU BEING LOW PRIORITY

ALL CPU'S BUT ONE S

SET FOR I/O PRIORITY

ALL CPU'S RUN CONTENTION TEST

CHECK TIC COUNTER FOR LACK OF BALANCE

-----NEXT CPU-----

NEXT BANK

8.2.7 Execution Contention Test -

The master causes each CPU (making himself a slave when necessary) to execute random instructions (INC (R0) or TST (R0)) simultaneously out of shared program space.

Success is indicated by survival & correct count in location pointed to by R0.

This is done as follows:

```

FOR EACH BANK
    IF BANK IS ACCESSABLE & NOT PROGRAM SPACE
        SETUP RANDOM INSTRUCTIONS
        ALL
CPU's EXECUTE IN BANK
    CHECK COUNTERS FOR ALL EQUAL
NEXT BANK

```

8.2.8 ASRB Test -

In a multi-processor system, certain portions of main memory must be capable of locking out all other references during the DATIP-DATO cycle. This is accomplished through a hardware and software LOCK process

8.2.8.1 Software Lock -

The Arithmetic Shift Right Byte (ASRB) instruction is used to attempt ownership of a particular block of shared data and/or code which may include I/O routines, data dependent routines, and etc. The ASRB instruction changes the state, (the UNLOCKED state or free state is defined as a binary 1 and the LOCKED state is defined as a binary 0), of

the control byte's destination location associated with the data structure/code being accessed; if that location is in the UNLOCKed state. The C bit of the PSW will store the information (0 if LOCK, 1 if UNLOCK) resulting from data manipulation during the LOCK/UNLOCK routine. The ASRB instruction is followed by a BCS (Branch if Carry Bit is Set) instruction which will branch and execute the desired code. When finished the LOCK routine will move a 1 back into the low order bit of the control byte's destination location; indicating to the other processors that this memory block is UNLOCKed. The ASRB instruction maintains its identity as a normal shift instruction.

8.2.8.2 Hardware Lock -

The PDP11/70 multiprocessor modifications treat the ASRB as a DATIP-DATO cycle to main memory bypassing CACHE.

PAGE 107

8.2.8.3 ASRB Test Structure -

The master causes each CPU (making himself a slave when necessary) to attempt to lock location zero of a bank under test simultaneously. After each attempt the master insures that one and only one CPU was allowed to lock the test location. This test is repeated 1000 times to insure that all CPUs are able to lock the test location is relatively even distribution (+ or - 256. locks of the master). To insure that the test does not synchronize with the memory arbitration scheme every time test is repeated the previous losers (non lockers) are given a head start in a chain of NOP instructions and the previous winner is defaulted to the entire chain.

This is done as follows:

```

FOR EACH BANK
  IF BANK IS ACCESSABLE & NOT P
    FOR ALL 8 POSSIBLE INTERLEAVE ADDRESSES
      FOR 1000 TRIES
        UNLOCK TEST
        LOCATION
          ALL CPUS ATTEMPT LOCK
        RECORD WINNER
          REARRANGE PRIORITIES
          CHECK FOR ONE AND ONLY ONE WINNER
        NEXT TRY
          NEXT INTERLEAVE ADDRESS
        NEXT BANK
          CHECK FOR EVEN DISTRIBUTION
  
```

8.2.9 CACHE FLUSH Test -

The master causes each CPU (making himself a slave when necessary) to write fresh data into a double word and all other CPU's to simultaneously change the data in that double word - thereby creating stale data in the 1st CPU's CACHE. The 1st CPU then insures that stale data exists then initiates a CACHE Flush and insures that the data is no longer stale.

This is done as follows:

```

WATOR          IF CACHE IS NOT DISABLED BY THE OPE
                FOR EACH CPU
                FOR EACH BANK
                    IF BANK IS ACCESSABLE & NOT PROGRAM SPACE
                        SELECTED CPU WRITES FRESH DATA
                        ALL OTHER CPU'S MAKE DATA STALE
                        SELECTED CPU VERIFYS STALE DATA
                        SELECTED CPU DOES CACHE FLUSH
                        SELECTED CPU VERIFYS NON-STALE DATA
NEXT BANK      NEXT CPU

```


BANKS

I

TEST

PROTECTION

POINTER

I

TEST

SYSTEM SIZE

REGISTER

I

I

.....

.

*
* TYPE *

* CONFIGURATION *

.....

I

.....

* RUN BANK *

. LEVEL *

TESTS *

.....

.....

I

.....

. RUN SYSTEM *

* LEVEL
* TESTS *

.....

I

.....

* FLUSH *

* OUT *

. DBE'S *

.....

I

.....

. END OF *

PASS *

*
*
* CODE *

.....

9.1.1 Initialize -

```

*****
/      SETUP      /
/      STACK      /
TFR    /          / POIN
*****
I
*****
CLEAR *          *
          *      ZERO      *
          *  VARIABLES  *
*****
I
*****
          * CLEAR ANY NON *
          * PROGRAM SPACE *
          * IN BANK 0 *
*****
I
          * SET UP *
          * NON-ZERO *
* VARIABLES *
*****
I
*****
SE *UP *          *
          *      VECTORS  *

```

I

HN *

- * SETUP PATTE
- * SCRIPTS FROM *
- * APT 'E-TABLE' *

I

- * CLEAR *

* CONFIGURATION *

- * TABLE *

I

- * SETUP, SWITCH *

- * REG TYPE *

- * (HARD

OR SOFT) *

I

I

* SETUP FOR *

* APT, ACT, *

* XXDP *

I

PRINT

* TITLE

I

*

* GO TO NEXT TEST *

9.1.2 Test Hardcore Hardware -

```

*****
* DETERMINES *
R *
* MK11 CS
* ACCESS METHOD *
*****
I
*****
* PROJECT *
* BANK 0 *
*****
I
*****
* MAP *
* KERNEL *
* SUPERVISOR *
*****
I
*****
* SETUP SUPER- *
* VISOR STACK *
* POINTER *
*****
I
*****
* SETUP USER *
STACK *
* POINTER *
*****
I

```

```

*****
RF      *   GET SOFTWA
        *   SWITCH REG
        *   IF NECESSARY

```

```

*****
I
        *****
        *   SETUP
        *   UNIBUS
        *   MAP

```

```

*****
I
        *****
        *   MAP
        *   KERNEL
RVISOR *   SUPE

```

```

I
*****
GO TO  *
        *   NEXT TEST
        *****

```

9.1.3 Analyze Configuration -

```

*****
/      SELEC
/      1ST /
/      CSR /
*****
-I      I<-----
-----
NO      I /      DOES      L
-----/      I      CSR      I
L      I /
I      EXIST?      L      I
I      I
I      I      YES
I      I      *****
I      I      I      SET BIT      *
I      I      *      I      I
N      I      *
I      *      'MKCSRS'      *
I      I
*****
I      I
I      I      YES
I      I      INTERNAL      I
L----->I
/      INTERLEAVE      L      I      I
I      I      /      ?      L      *****
I      I      I
I      I      NO I      *      SE
I      I      I
I      I      *      IN 'MKCSRS'      *
I      I

```

```

.....
[<-----]
.....
*
*   SAVE
* INTER
LEAVE *
.....
I
I /
I /
I /
L GETSIZE L /
-----
I
I
I *****
I *   SELECT
*
I 1ST BANK *
I *   OF CSR *
I
I *****
I I<-----
I *****
I *   UPDATE
CONFIG *
I *   TABLE OF BANK *
I *   * W/INTERLEAVE,MK11 ID*
I
I *****
I
I
I
I
I

```


SIZE? L

I

I NO

i

----->I

I

i

I

I

* SELECT *
I
* NEXT

I

CSR

I

I

I

I

NO

I

/ LAST

L---

CS

/

?

L

I YES

* GO TO NEXT TEST *

R

L

9.1.4 Size & Test 0's & 1's On Each Bank -

```

I
.....
*   ENABLE   *   YES   /
/ NO *   ENABLE CSR *
*   CSR FOR *-----/
SWO /----->*   FOR DBE *
*   SBE TRAPS *   TRAPS *
  SET   /
.....

I           I
I           I
I           I-----
-----I

I
V
.....
*   SETUP TRAPS *
*   TO COUNT *
*   ERRORS *
.....
I
.....
*   CLEAR *
*   ERROR *
*   COUNTS *
.....
I
*   CACHE *
TURN

```

• OFF •

.....

I

.....

.....

• DO 'TST' •

• INSTRUCTION •

• ON BANK 0 •

.....

I

.....

• TURN •

• CACHE •

• ON •

.....

I

YES

ANY

ERRO

FATAL

TRAP

RS

L

/

?

L

/

L

•

I

I NO

.....
ESSED *

* SET ACC
* BIT FOR *
* BANK 0 *

.....

I

.....

* CLEAR *

* 'BANK', *

* 'LASTBANK' *

.....

I

.....

* SETUP TRAPS *

* TO COUNT *

ERRORS *

.....

I

I

.....

* MOVE MODIFIED *

U TO *

* PATTERN
* FASTCITY *

.....

I

...

A

...

PAGE 115

A

I

J

.....

INCREMENT

BANK

.....

I

YES

L

LAS

/

BANK?

I

.....

*

CLEAR

NO

BANK

*

I

YES

I

/ IS THIS BANK

L

/ IN PROTECTED

L

/ PROGRAM SPACES

L

I NO

.....

CLEAR

I

ERROR

COUNTS

RESET PARITY

ACTION TO

RESET

TRAPS

TO 4

MAL

SUPERVISOR

TO BANK
/ GO TO

NEXT

TEST

MODIFY PATTERN
TO STOP

AFTER WRITE

SETUP

FOR
PATTERN 0

I

 * TURN *
 * CACHE *
 * OFF *

I

 * ENTER *
 * SUPERVISOR *
 * MODE *

I

 * WRITE *
 * ZEROS *

I

 * EN *
 * TER KERNEL *
 * TURN CACHE *
 * ON *

I
 ----- YES
 / ANY L-----

 / NON-EXISTENT L
 I
 / MEM TRAPS? L

I

 I NO
 THIS THE L
 I

.....
 I
 * TURN *
 I
 * CACHE *
 I


V
 I
 / IS
 / 1ST MISSING L-----
 / BANK L

I

• "A"

•
.....

9.1.5 Determine Protected Banks Of MK11 -



AN MK11 BANK? L----->-----I

I YES

* MAP *

* SUPERVIS *

* *

* ENTER *

* SUPERVISOR *

* MODE *

* CREATE A *

* DBE IN *

* BANK *

OR

TO BANK *

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

I

• ENTER •
• KERNEL MODE •

I<-----

I

• •

INCREMENT •

• BANK •

I

I NO / BANK L YES ••

I-----/ GREATER THAN L-----

CLEAR •

• BANK

/ 167? L

I

•

• CLEAR •

• CSR'S •

I

I

V

• GO TO

• NEXT I

EST •

9.1
.6 Test MK11 Protection Pointer -

```

*****
ET / / S
/ / BANK /
/ TO 0 /
*****
|-----|
| I |
| * CALL * |
| / BANK * L EXBANK * |
| / YES |
| ***** | / GRE
ATER THAN |-----|
I / 167? L I
|-----|
| I |
| / I L NO |
| / IS T |
HIS BANK MK11 L-----| I
| I / I L |
| : |-----| I
| I YES V I |
| I |-----| I NO
| I I I |
| / IS THE BANK L I |
*****
ACCESSIBLE |----->|

```

I

I 16

0205

• INCREMENT BANK •

BY CPU?

L

I

I

I YES

.....

I

/ IS THE KPFLAG L

I

/ SET?

L

NO

I

L-----

I

----->.....

I

I YES

GO TO

• <-----]

NEXT TEST


.....

.....

• ERROR TRAP •

.....

2.1.7 Test System Size Register -



• GO TO •

• NEXT TEST •

.....

• SETUP •

• ERROR INFO •


.....

I

.....

• ERROR TRAP •

.....



```

.....
*MKSIZE:=MKSIZE *
.....
I
.....
*MJSIZE: MJSIZE * 16. *
.....
I
.....
I: MJSIZE + MKSIZE
.....
I
PRINT * I: 'K OF MEMORY' *
.....
I
PRINT *
* MJSIZE;'K OF MJ11' *
.....
I
PRINT *
* MKSIZE;'K OF MK1

```

.....

I

/

L

/ GO TO NEXT TEST L

/

L

Run Bank eye Tests -

```

*****
/      CLEAR      /
/      CONTFLAG   /
/                  /
*****
I
I
*****
* GET TEST *
* MODE FROM *
*   SWR    *
*****
I
-----
I
I
DISPATCH BY TEST MODE (0 - 7)
I
-----0-----
-1-----2-----3-----4-----5-----6-----
-----7-----
I
I
*****
** I ***** I ***** I
* CALL *
* I *
* I BAFPAF * I CALL * I CALL
* I *
* I CALL * I BAWPAF *
* I *

```

```

I . PAFBAF . I . PARBAF . I
..... I ..... I .....
I I I I I I I I I
I I I I I I I I I
I ..... I ..... I .....
I ..... I ..... I .....
I . CALL I . CALL I . CALL .
I . CALL . I . CALL .
PAFBAW I . PAFFPAR . I . BAWPAR . I .
PAFBAW I . PARBAW . I
..... I ..... I .....
I I I I I I I I I
I I I I I I I I I
I I I I I I I I I
I I I I I I I I I
I I I I I I I I I
.....
.....

```

```

I
I
V
.....
.
.
. GO TO .
. NEXT TEST .
.....
.....

```

9.1.10 Run System Level Tests -

```
*****  
/ /  
/ CALL MTO027 /  
/(UNIQUE BANK TEST)/  
*****
```

I

```
****  
*  
* SE  
* A  
****
```

```
*****  
*  
TUP RG FOR *  
DDPAR CALL *  
*****
```

```
*****  
* SETUP PARITY  
* ACTION TO  
* COUNT ERRORS  
*****
```

```
I  
*  
*  
*  
*  
*  
*
```

I

```
*****  
* MOVE ADDPAR *  
* SUBROUTINE TO *  
* FASTCITY *  
*****
```

I

```
*****  
*  
*
```



• CLEAR BANK •

G 1

SEO-0213



I



I

I YES

I NO

I

I

.....

• RESET PARITY •

• ACTION TO •
ERROR L

• DEFAULT •

TRAF

L

.....

I

/ L

/ CALL MTO030 L

/ (

FLUSH OUT DBE'S) L

I

/ GO TO L

/ NEXT L

/ TEST

L

v
.....

* PRINT \$PASS *

*
.....

I
.....

* MOVE CONTENTS *

* OF 42 TO R0 *

I

```

          I
          -----
          /      /      L      YES
          /      /      WAS IT  L-----
-----
          /      /      A ZERO?  L
I
          -----
          I NO
          -----
          /      /      V
          /      /      L
          /      /      RO EQUAL  L-----YES----> *
GO TO RUN *      /      #STACK    L      * BANK LEV
EL *
          -----
          /      /      * TESTS? *
          -----
          I
          I NO
          *****
          *
          *      CALL      *
          *
          SHUTUP
          *
          *****
          I
          -----
          *****
          /      /      IS      L      YES      *      C
          /      /      XXDPCHAIN  L----->*      LOC
          /      /      FLAG SET?  L      *
          -----
          *****
          I
          I<-----I
          I

```


N 1
NOP

SEQ 0220

!

* GO TO RUN *

* BANK LEVEL *

* TESTS *

5-	90	OPERATIONAL SWITCH SETTINGS	
5-	91	:SWITCH REGISTER DEFINITIONS	
5-	92	..	
5-	93	..	SWITCH
5-	94	..	-----
5-	95	..	15
5-	96	..	14
5-	97	..	13
5-	98	..	12
5-	99	..	11
5-	100	..	10
5-	101	..	9
5-	102	..	8
5-	103	..	7
5-	104	..	6
5-	105	..	5
5-	106	..	4
5-	107	..	3
5-	108	..	2
5-	109	..	1
5-	110	..	0
9-	136	DEFINE	TRAPS
11-	252	DEFINE	BASIC PDP11 STUFF
11-	334	DEFINE	CACHE REGISTERS
11-	342	DEFINE	CPU REGISTERS
11-	350	DEFINE	MEMORY MANAGEMENT REGISTERS
13-	480	DEFINE	UNIBUS MAP REGISTERS
13-	548	DEFINE	SOFTWARE SWITCH & DISPLAY REGISTERS
13-	552	DEFINE	MK11 REGISTERS
13-	555	DEFINE	PARAMETERS
13-	560	DEFINE	MASTER & SLAVE BITS
15-	568	MACRO	FATAL
15-	588	MACRO	TYPE
17-	606	MACRO	NEWST
19-	656	MACRO	\$\$NEWTEST
19-	677	MACRO	SUBTST
19-	696	MACRO	\$\$SUBTST
21-	711	MACRO	TYPOCT
23-	751	MACRO	TYPOCS
25-	807	MACRO	TYPDEC
26-	849	MACRO	BMOV
28-	915	MACRO	MAP
30-	954	MACRO	SUPERVISOR
30-	975	MACRO	USER
32-	997	MACRO	SET4 & RES4
34-	1039	MACRO	DLEFT
36-	1063	TRAP	CATCHER
36-	1071	ACT11	HOOKS
36-	1090	APT11	HOOKS
38-	1111	VARIABLES	INITIALIZED TO ZERO
40-	1294	MULTI	PORT VARIABLES
42-	1314	VARIABLES	INITIALIZED TO NON ZERO
44-	1361	CONFIGURATION	TABLE
45-	1402	*****	MAIN *****
45-	1403	INITIALIZE	VARIABLES TO ZERO
45-	1420	CLEAR	NON-PROGRAM SPACE
47-	1443	INITIALIZE	VARIABLES TO NON ZERO

47-	1456	INITIALIZE VECTORS	
50-	1479	CLEAR THE CONFIGURATION TABLE	
50-	1491	SIZE FOR A HARDWARE SWITCH REGISTER	
50-	1508	FIND OUT IF ANY LINE CLOCK IS PRESENT	
52-	1516	SETUP ACT, APT, & XXDP	
54-	1542	INITIALIZE PATTERNS	
54-	1567	SUBR PLUG IN NULL PATTERNS	
56-	1578	PROTECT PROGRAM & LOADERS	
56-	1584	MULTIPOINT DETERMINATION ROUTINE	
58-	1618	SLAVES START HERE	
60-	1630	DETERMINE MK11 ACCESS METHOD	
60-	1647	SETUP USER & SUPERVISOR STACK	
62-	1664	GET SOFTWARE SWITCH REGISTER IF NECESSARY	
62-	1674	SETUP UNIBUS MAP	
62-	1681	GET MEMORY MANAGEMENT READY	
64-	1689	T1 ANALYZE CONFIGURATION	
65-	1796	T2 TEST BANK 0 ACCESSES	
65-	1825	ENABLE MK11 FOR CORRECT TRAPS	
67-	1833	T3 TEST BANKS 1-167 (OCTAL) FOR ZEROS & ONES	
69-	1937	DETERMINE PROTECTED BANKS	
71-	2031	T4 MK11 PROTECTION POINTER TEST	
73-	2046	CHECK SYSTEM SIZE REGISTER	
81-	2201	MOVE LOADERS IF NECESSARY	
83-	2242	MULTIPOINT HOOK	
85-	2305	SLAVES WAIT FOR MASTER TO COUNT DOWN	
87-	2319	BOOT UP ALL EXISTING CPU'S	
92-	2512	CHECK FOR UNIQUE CPU ID NUMBERS	
92-	2532	PRINT MULTIPOINT DIRECTORY	
92-	2546	LOAD CSR'S FROM E-TABLE \$CDW1 & \$CDW2	
94-	2562	LEGAL CONFIGURATION CHECK	
96-	2626	PRINT CONFIGURATION DETAILS	
98-	2664	CHECK APT SIZING	
99-	2710	T5 DIAGNOSTIC MODE DISPATCH ROUTINE	
102-	2730	T6 UNIQUE BANK TEST	
102-	2740	T7 FORCE ADDRESS PARITY ERRORS	
104-	2784	FLUSH OUT DBE'S	
107-	2789	END OF PASS ROUTINE	
109-	2843	WRITE BACKGROUND PATTERNS	
111-	2857	MTEST MODES	
111-	2859	BANKS FORWARD,PATTERNS FORWARD	**RECURSIVE**
113-	2893	BANKS FORWARD,PATTERNS REVERSE	**RECURSIVE**
115-	2927	BANKS WORST FIRST,PATTERNS FORWARD	**RECURSIVE**
117-	2968	BANKS WORST FIRST,PATTERNS REVERSE	**RECURSIVE**
120-	3010	PATTERNS FORWARD,BANKS FORWARD	**RECURSIVE**
122-	3052	PATTERNS FORWARD,BANKS WORST FIRST	**RECURSIVE**
124-	3101	PATTERNS REVERSE,BANKS FORWARD	**RECURSIVE**
126-	3143	PATTERNS REVERSE,BANKS WORST FIRST	**RECURSIVE**
129-	3193	SUBR SETUP MEMORY TEST	
131-	3214	SUBR TEST MK11 CONTROLLER LOGIC DISPATCH	
133-	3284	IS ECC ON?	
135-	3306	CHECK FOR SBE FREE LOCATIONS	
137-	3384	SETUP INTERLEAVE INFO	
139-	3421	SUBR GET SIZE FROM CSR	
142-	3448	CSR PATTERN CASE STATEMENT	
144-	3490	DETERMINE ADDRESSING ACCORDING TO INTERLEAVE	
146-	3624	DETERMINE IF BANK BELONGS TO CORRECT SIDE	
149-	3653	SUBR MK11 TEST DISPATCH	

EMKABO 1170 MAIN MEMORY DIAG 1 MACRO M1113 01-AUG-79 07:12
 TABLE OF CONTENTS

151-	3724	SUBR	MJ11 TEST DISPATCH
152-	3778		PATTERNS
152-	3780	MEMORY	TEST SETUP ROUTINES
152-	3781	MT0000	SETUP DATA PATTERN TEST
152-	3789	MT0001	SETUP ADDRESS TEST
152-	3798	MT0002	SETUP COMPLEMENT ADDRESS TEST
154-	3811	MT0003	SETUP 3 XOR 9 WORST CASE NOISE TEST
154-	3836	MT0004	SETUP ROTATING ZEROS TEST
154-	3847	MT0005	SETUP ROTATING ONES TEST
156-	3860	MT0006	SETUP INITIAL DATA TEST
156-	3867	MT0007	SETUP ADDRESS BIT TEST
156-	3877	MT0010	SETUP BYTE ADDRESSING TEST
158-	3886	MT0011	SETUP CREATE SINGLE BIT ERROR TEST
158-	3895	MT0012	SETUP WRITE BYTE CLEARS SBE TEST
158-	3904	MT0013	SETUP CREATE DOUBLE BIT ERROR TEST
158-	3913	MT0014	SETUP WRITE INHIBIT DURING DATIP WITH DBE
160-	3924	MT0015	SETUP WRITE INHIBIT OF BYTE WITH DBE
160-	3933	MT0016	SETUP WRITE INHIBIT OF WORD WITH DBE
160-	3942	MT0017	SETUP HOLDING 1'S & 0'S
162-	3949	MT0020	SETUP MARCHING 0'S & 1'S IN CHECKBITS TEST
164-	4021	MT0021	SETUP MARCHING 0'S & 1'S TEST
164-	4046	MT0022	SETUP REFRESH & SHIFTING DIAGONAL TEST
164-	4054	MT0023	SHIFTING DIAGONAL TEST
165-	4064	MT0024	SETUP FAST GALLOPING PATTERN TEST
165-	4090	MT0025	SETUP INTERRUPT ENABLE TEST
167-	4100	MT0026	SETUP RANDOM DATA TEST
169-	4123	MT0027	UNIQUE BANK TEST
171-	4179	MT0030	SETUP FLUSH OUT DBE'S TEST
173-	4218	MT0031	SETUP SOB-A-LONG TEST
175-	4238	MT0033	SETUP WRITE RECOVERY TEST
177-	4276	MT0034	SETUP BRANCH GOBBLE TEST
177-	4297	MT0035	SOFT ERROR - BACKGROUND PATTERN TEST
179-	4320	MT0999	SETUP NULL TEST
179-	4325		CHECK FOR KAMIKAZE MODE
182-	4334	SUBR	EXECUTE PATTERN IN SUPERVISOR
188-	4403	MEMORY	TEST PATTERN ROUTINES
188-	4413	MTP000	BASIC DATA TEST
188-	4424	MTP001	ADDRESS TEST
188-	4436	MTP002	COMPLEMENT ADDRESS TEST (WRITE DOWN, READ UP)
191-	4451	MTPA03	3 XOR 9 WORST CASE NOISE TEST (WRITE)
191-	4476	MTPB03	3 XOR 9 WORST CASE NOISE TEST (READ)
193-	4494	MTPC03	TEST DATA SUBPROGRAM
193-	4503	MTPD03	TEST DATA SUBSUBPROGRAM
195-	4513	MTPA04	ROTATING ZEROS TEST
195-	4526	MTPB04	SUBR ROTATING BIT
195-	4535	MTP005	ROTATION ONES TEST
198-	4550	MTP006	INITIAL DATA TEST
201-	4594	MTP007	ADDRESS BIT TEST
203-	4634	MTP010	BYTE ADDRESSING TEST
206-	4671	MPT011	SINGLE BIT ERROR TEST
209-	4782	MTP012	WRITE BYTE CLEARS SBE TEST
212-	4860	MTP013	CREATE DOUBLE BIT ERROR TEST
217-	4929	MTP014	WRITE INHIBIT DURING DATIP WITH DBE TEST
220-	5010	MTP015	WRITE INHIBIT OF BYTE WITH DBE
223-	5087	MTP016	WRITE INHIBIT OF WORD WITH DBE
228-	5167	MTP017	HOLDING 1'S & 0'S TEST
231-	5201	MTP020	MARCHING 1'S & 0'S IN CHECK BITS TEST

236-	5279	MTPA20	SLOW MARCHING 1'S & 0'S IN CHECK BITS TEST
243-	5416	MTPA21	MARCHING 1'S & 0'S PATTERN TEST
248-	5487	MTP022	REFRESH & SHIFTING DIAGONAL TEST
250-	5559	SUBR	REFRESH DELAY
253-	5582	MTPA24	FAST GALLOPING PATTERN TEST
255-	5626	MTPB24	FAST GALLOP PART B
255-	5634	MTPC24	FAST GALLOP PART C
258-	5645	MTP025	INTERRUPT ENABLE TEST
263-	5738	MTPA26	RANDOM DATA (WRITE)
263-	5745	MTPB26	RANDOM DATA (READ)
263-	5763		RANDOM NUMBER SUBPROGRAM
263-	5776		RANDOM NUMBER SUBSUBPROGRAM
265-	5784	MTO030	FLUSH OUT DBE'S
265-	5790	MTP031	SOB-A-LONG TEST
267-	5816	MTPA32	SKEWED UP ADDRESS TEST (WRITE)
267-	5826	MTPB32	SKEWED UP ADDRESS TEST (READ)
267-	5839	MTP033	WRITE RECOVERY TEST
269-	5859	MTP034	BRANCH GOBBLE TEST
270-	5905		MISC SUBROUTINES
270-	5907	SUBR	COPY R0 TO R4, R1 TO R3, & R2 TO R5
270-	5913	FLIP	WARNING CONSTANTS IN WORST CASE NOISE TESTS
270-	5940	SUBR	WRITE BACKGROUND
273-	5953	SUBR	PRINT CONFIGURATION MAP
276-	6002	SUBR	TYPE CONFIGURATION
281-	6154	TRAP	PARITY ERROR HANDLER
283-	6200	TRAP	NON-EXISTANT MEMORY (HOLES) HANDLER
283-	6222	TRAP	TIMEOUT (TRAP TO 4) HANDLER
283-	6226	TRAP	MEMORY MANAGEMENT (TRAP TO 250) HANDLER
283-	6229	TRAP	RESERVED INSTRUCTION HANDLER
283-	6233		UNEXPECTED IIST TRAP HANDLER
283-	6237		FIND BAD SP, PC, & PSW FROM STACK
285-	6245	TRAP	KERNEL TRAP HANDLER
285-	6253	TRAP	ENERGIZE TRAP HANDLER
285-	6257	TRAP	DEENERGIZE TRAP HANDLER
285-	6261	TRAP	CACHON TRAP HANDLER
285-	6266	TRAP	CACHOFF TRAP HANDLER
288-	6273	TRAP	LOAD CSR TRAP HANDLER
290-	6302	TRAP	READ CSR TRAP HANDLER
290-	6321	TRAP	TEST (R1) & READ CSR CAREFULLY
293-	6354	TRAP	ECC DISABLE ALL CSR'S TRAP HANDLER
293-	6360	TRAP	ECC DISABLE OF 1 SELECTED CSR TRAP HANDLER
293-	6366	TRAP	MK11 INITIALIZE ALL CSR'S TRAP HANDLER
293-	6371	TRAP	MK11 INITIALIZE 1 SELECTED CSR TRAP HANDLER
293-	6376	TRAP	ENABLE SBE PARITY TRAPS ON ALL CSR'S
293-	6382	TRAP	ENABLE SBE PARITY TRAPS ON 1 SELECTED CSR
293-	6388	TRAP	WRITE CHECKBITS THRU ALL CSR'S TRAP HANDLER
293-	6395	TRAP	WRITE CHECKBITS THRU 1 SELECTED CSR TRAP HANDLER
296-	6405	TRAP	WAS THERE A SBE ON ANY CSR TRAP HANDLER
296-	6430	TRAP	WAS THERE A SBE IN 1 SELECTED CSR TRAP HANDLER
298-	6440	TRAP	WAS THERE A DBE ON ANY CSR TRAP HANDLER
298-	6465	TRAP	WAS THERE A DBE ON 1 SELECTED CSR TRAP HANDLER
300-	6479	TRAP	CLEAR ALL MK11 CSR'S TRAP HANDLER
300-	6483	TRAP	CLEAR 1 SELECTED MK11 CSR TRAP HANDLER
300-	6487	TRAP	ECC DISABLE, CHECH MODE, & WRITE CHECKBITS IN ALL CSR'S TRAP HANDLER
300-	6494	TRAP	ECC DISABLE, CHECH MODE, & WRITE CHECKBITS IN 1 SELECTED CSR
302-	6503	SUBR	WRITE IN ALL CSR'S
302-	6518	TRAP	INVALIDATE BACKGROUND PATTERN

305-	6528	SUBR	GENERATE CHECK BITS
310-	6595	SUBR	MAPPER
310-	6627	TRAP	MAP KERNEL (ALMOST 1 TO 1) TRAP HANDLER
313-	6649		RELOCATE PROGRAM
317-	6718		UNRELOCATE PROGRAM
317-	6754		SETUP LOWER 16K OF UNIBUS MAP
319-	6767		MOVE BANKS
321-	6815	SUBR	MAP USER TO NEW BANK
321-	6835	SUBR	SETUP KERNEL PAR'S FOR NEW BANK
321-	6848	SUBR	SETUP KERNEL PAR'S FOR NEW LOADER BANK
324-	6861	SUBR	EXAMINE BANK
327-	6918	SUBR	BANK OK?
327-	6929	SUBR	INCREMENT PATTERN TESTING MK11'S
327-	6937	SUBR	SET HIGHEST PATTERN TESTING TYPE
327-	6941	SUBR	INCREMENT BANK & TEST
329-	6948	SUBR	INCREMENT MARGINS & TEST
329-	6976		DECREMENT MARGINS & TEST
331-	6989	SUBR	SET HIGHEST MARGIN
331-	7006	SUBR	REWRITE CORE HISTORY
333-	7024		BOOTSTRAP ROUTINE
335-	7053		HALT PROGRAM
335-	7062		SHUTDOWN DIAGNOSTIC
335-	7085		APT SHUTDOWN SEQUENCE
337-	7095		BLOCK MOVE SUBROUTINE
338-	7122		FIELD SERVICE MODE
338-	7124	SUBR	FIELD SERVICE COMMAND MODE
340-	716)	COMMAND 0	EXIT
340-	7187	FS	COMMAND 1 READ CSR
342-	7202	FS	COMMAND 2 LOAD CSR
344-	7231	FS	COMMAND 3 EXAMINE MEMORY
346-	7270	FS	COMMAND 4 MODIFY MEMORY
348-	7322	FS	COMMAND 5 SELECT BANK, MARGIN, & PATTERN
348-	7440	FS	COMMAND 6 TYPE CONFIGURATION MAP
351-	7447	FS	COMMAND 7 BATTERY BACKUP TEST
353-	7496	FS	COMMAND 8 SOB-A-LONG TEST
355-	7550	FS	COMMAND 9 SUPER TIGHT SCOPE LOOP
355-	7618	FS	COMMAND 10 ERROR SUMMARY
357-	7645	FS	COMMAND 11 REFRESH TEST
359-	7700	FS	COMMAND 12 SET FILL COUNT
359-	7710	FS	COMMAND 13 ENTER KAMIKAZE MODE
359-	7715	FS	COMMAND 14 EXIT KAMIKAZE MODE
359-	7721	FS	COMMAND 15 TURN CACHE OFF
359-	7727	FS	COMMAND 16 TURN CACHE ON
359-	7733	FS	COMMAND 17 RUN ONLY MULTIPOINT TESTS
361-	7739	FS	COMMAND 18 RESUME RUNNING BOTH SINGLE & MULTIPOINT TESTS
361-	7744	FS	COMMAND 19 TEST ONLY SELECTED BANKS
361-	7763	FS	COMMAND 20 RESUME TESTING ALL BANKS
363-	7775	SUBR	DETERMINE CORRECT CSR
365-	3		MULTIPROCESSOR SLAVE DISPATCHER
367-	66		MOVE PROGRAM TO NEW BANK
367-	80		WRITE ONLY PATTERN IN HI BYTE
369-	100		READ ONLY PATTERN IN HI BYTE
369-	130		SLAVE PATTERNS
371-	145		EXECUTION CONTENTION TEST
373-	164		PORT ARBITRATION SYMMETRY TEST
375-	219		STOP SLAVE PROGRAM
375-	226		WRITE ONLY ADDRESS PATTERN IN HI BYTE

375-	230	READ ONLY ADDRESS PATTERN IN HI BYTE
377-	262	RUN FIVE PATTERNS IN DESIGNATED 1/4 BANK
377-	279	WRITE & READ A SKEWED UP ADDRESS TEST
379-	301	SETUP FOR ASRB TEST
381-	338	RECOVER FROM TASK13 - TRAP FROM IIST
383-	356	RESET FROM ASRB TEST
383-	361	RUN SLAVE IN CSR TESTS
383-	365	SET MARGIN 6, CPU HAS I/O PRIORITY
383-	370	CREATE STALE DATA TEST
385-	385	CACHE FLUSH TEST
385-	422	CACHE FLUSH TEST (FOR PAR'S)
387-	434	SETUP EXECUTION CONTENTION TEST
389-	458	MULTIPORT ASRB TEST (IN SUPERVISOR SPACE)
391-	541	BALANCE TEST
393-	568	ERROR DATA (SUPERVISOR) SETUP STUFF
393-	582	DATA WAS 3 WORDS
395-	614	GET DATA FROM ABORTED AREA IF POSSIBLE
397-	634	POWER FAIL AUTO RESTART
397-	635	ROUTINE POWER DOWN AND UP
403-	788	MULTIPLE CPU'S POWERING UP
403-	795	POWER FAIL WHILE RELOCATED
405-	820	POWER UP FROM BANK 0 TO RELOCATION
407-	858	IO SUBROUTINES
407-	860	ROUTINE TYPE
408-	949	MULTIPORT SLAVE STARTER
410-	1032	HAVE SLAVES RUN CSR TESTS
412-	1064	MOVE SLAVES TO THEIR OWN BANKS
414-	1111	RUN NORMAL MULTIPROCESSOR TESTS
416-	1187	INITIALIZE THE IIST
416-	1207	INIT IIST & DISABLE BOOTS & INTERRUPTS
418-	1221	SLAVES MAP
420-	1241	MULTIPORT ACCESS PATHS TEST
423-	1306	MULTIPORT ADDRESS TEST
425-	1369	MULTIPORT ASYNCHRONOUS ADDRESS UNIQUENESS TEST
427-	1417	MULTIPORT SKEWED UP ADDRESS TEST
429-	1458	MULTIPORT PORT ARBITRATION SYMMETRY TEST
431-	1506	MULTIPORT PORT I/O PRIORITY TEST
435-	1575	CHECK FOR PROPER SKEWING OF ACCESSES
435-	1600	WAIT FOR 5 SECONDS FOR A SLAVE
437-	1615	MULTIPORT EXECUTION CONTENTION TEST
437-	1662	MULTIPORT ASRB TEST
439-	1666	MULTIPORT CACHE FLUSH TEST
441-	1717	STOP SLAVES
443-	1739	ERROR DATA SETUP
448-	1988	DATA WAS A WORD
448-	2000	DATA WAS A BYTE
450-	2013	DATA WAS A 7 BIT BYTE
450-	2028	DETERMINE XOR OF GOOD & BAD
452-	2037	LOG ERROR ON BAD BANK
456-	2120	ROUTINE SCOPE HANDLER
457-	2176	SUBR DISPLAY
459-	2199	ROUTINE ERROR HANDLER
462-	2282	ROUTINE ERROR MESSAGE TYPEOUT
475-	2581	SUBR WHO'S BOX IS THIS?
477-	2645	SUBR DETAILED ERROR REPORT
483-	2754	QUE MESSAGES FROM SLAVE CPU'S
485-	2789	ROUTINE BINARY TO OCTAL (ASCII) AND TYPE

TABLE OF CONTENTS

486-	2867	ROUTINE CONVERT BINARY TO DECIMAL AND TYPE
487-	2924	ROUTINE TTY INPUT
489-	3007	CONTROL Y
489-	3033	CONTROL S & CONTROL Q
491-	3147	ROUTINE READ AN OCTAL NUMBER FROM THE TTY
491-	3196	ROUTINE READ A DECIMAL NUMBER FROM THE TTY
492-	3255	ROUTINE SAVE AND RESTORE R0-R5
493-	3291	ROUTINE RANDOM NUMBER GENERATOR
495-	3321	ROUTINE DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT
496-	3363	TABLES
496-	3365	APT MAILBOX-ETABLE
497-	3444	ROUTINE TRAP DECODER
499-	3471	TRAP TABLE
501-	3571	ODT (CEMKA) DATA AREA
548-	4403	TABLE ERROR POINTER
560-	4699	ERROR DATA TAGS (DT)
562-	4728	ERROR DATA FORMATS (DF)
564-	4746	ERROR MESSAGES (EM)
566-	4806	ERROR DATA HEADERS (DH)
568-	4838	MESSAGES

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33

.TITLE CEMKABO 1170 MAIN MEMORY DIAG 1
.IDENT /X01.60/

IDENTIFICATION

PRODUCT CODE: AC-C644B-MC
PRODUCT NAME: CEMKABO 1170 MAIN MEMORY DIAG
PRODUCT DATE: 31 JUL 1979
MAINTAINER: PRODUCT ENHANCEMENT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTFR SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1978,1979 DIGITAL EQUIPMENT CORPORATION

36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88

REVISION HISTORY
=====

REVISION	VERSION	DATE	AUTHOR	CHANGES
=====	=====	=====	-----	-----
CEMKA	V03.00	24-FEB-78	KAY R. FISHER	NONE - NEW PROGRAM
CEMKAB	V09.00	9-OCT-78	KAY R. FISHER	1. ADD MULTIPROCESSOR CAPABILITIES 2. ADD SOFT ERROR TEST FOR ALPHA PARTICLES IN MOS CHIPS 3. ADD THE FOLLOWING FIELD SERVICE COMMANDS A. KAMIKAZE MODE B. CACHE ON/OFF C. SELECT ONLY MULTIPOINT TESTS D. TEST ONLY SELECTED BANKS 4. EXPAND DETAILED ERROR REPORT TO INCLUDE ALL CSR'S AND SP AT TIME OF ERROR 5. SPEED UP GALLOPING PATTERN BY EXECUTING OUT OF THE PAR'S 6. OPTIMIZE THE SHIFTING DIAGONAL PATTERN BY SHARING CODE WITH THE REFRESH PATTERN 7. ADD BRANCH GOBBLE PATTERN 8. ADD WRITE RECOVERY PATTERN 9. REPAIRED THE FOLLOWING BUGS A. UNDER APT FIELD SERVICE COMMANDS 1 & 2 B. UNDER APT USE OF ENVIRONMENTAL MODE DID NOT MEET APT SPEC C. FATAL PARITY ERRORS AT LOAD TIME THAT WERE CAUSED BY .BLKW STATEMENTS D. RESTART AT 202 CLEARS ERROR ACCOUNTING E. INTERMITTANT SINGLE BIT ERRORS IN CHECKBITS NOT DETECT F. ERROR COUNT WAS MOD 32K G. ODT HANGS AFTER 256 OPENS H. WRONG PC PRINTED ON SOME ERROR I. HIADRS LOADRS REG'S NOT CLEARE AFTER SIZING J. ACT MEMORY SIZE DEPENDENT BIT DEFINED WRONG K. UNABLE TO RUN WITHOUT A LINE CLOCK

	.SBTTL	OPERATIONAL SWITCH SETTINGS		
90	.SBTTL	:*		
91	.SBTTL	:*		
92	.SBTTL	:*		
93	.SBTTL	:*	SWITCH	USE
94	.SBTTL	:*	----	-----
95	.SBTTL	:*	15	AL ON ERROR
96	.SBTTL	:*	14	LOOP ON TEST
97	.SBTTL	:*	13	INHIBIT ERROR TYPEOUTS
98	.SBTTL	:*	12	INHIBIT RELOCATION
99	.SBTTL	:*	11	QUICK VERIFY / INHIBIT MARGIN TESTING
100	.SBTTL	:*	10	BELL ON ERROR
101	.SBTTL	:*	9	LOOP ON ERROR
102	.SBTTL	:*	8	HALT PROGRAM (UNRELOCATED & RESTORE LOADERS)
103	.SBTTL	:*	7	DETAILED ERROR REPORTS
104	.SBTTL	:*	6	PRINT CONFIGURATION MAP
105	.SBTTL	:*	5	LIMIT MAX ERRORS PER BANK
106	.SBTTL	:*	4	FAT TERMINAL (132 COLUMNS OR BETTER)
107	.SBTTL	:*	3	TEST MODE - SEE DOCUMENT
108	.SBTTL	:*	2	TEST MODE - SEE DOCUMENT
109	.SBTTL	:*	1	TEST MODE - SEE DOCUMENT
110	.SBTTL	:*	0	DETECT SINGLE BIT ERRORS

```
113 000000 .ENABL ABS
114 .ENABL AMA
115 .DSABL GBL
116 ;NOTE: CEMKAB.SML IS THE SUPER.MAC SOURCE AND IS RELEASED WITH
117 ;THIS PROGRAM. ALL THESE .MCALL STATEMENTS REFERENCE THAT FILE.
118 .MCALL SMACIT,..PUSH,..POP,..TAG,..BRAN,..EMIT,..EMITN,..EMITL,..EMITR
119 .MCALL .IFOPR,..IS,..GENBR,..OPADD,..OPSUB,CLEAR,SET,CLEARB,SETB
120 .MCALL RNE,REQ,RLT,RGE,RGT,RLE,RPL,RMI,RHI,RLOS,RHIS,RLO,RCS,RCC
121 .MCALL IF,..OR,..IFARI,..LEAVE,..GOTO,OR,AND,THEN,ELSE,WHILE,CASE
122 .MCALL FOR,TO,DOWNT0,REPEAT,UNTIL,THRU,END,BEGIN
123 .MCALL $$END,LEAVE,JUMPT0,GOTO,PUSH,POP,LET
124 .MCALL .SIMPLE,..ARITH,ORB,ANDB,IFB,UNTILB,WHILEB,ON.ERROR,ON.NOERROR
125 .MCALL $CALL,$RETURN
126
127 .NLIST TTM ;I WANT FAT PAPER:
128 .LIST MC,SYM ;LIST MACRO CALLS, SYMBOL TABLE
129 .NLIST MD,CND,ME ;DON'T LIST MACRO DEFS & CONDITIONALS & EXPANSIONS
130 ;LST$$= 0 ;DEFINED TO LIST SUPERMAC EXPANSIONS
131 163000 $SWR= 163000 ;USE THESE SYSMAC SWITCHES
132 000001 $TN= 1 ;FIRST TEST NUMBER TO ONE(1)
133 000000 SMACIT
```

```

136 .SBTTL DEFINE TRAPS
137 :ALL ENTRIES HERE MUST HAVE A CORRESPONDING ENTRY IN THE
138 :TRAP TABLE '$TRPAD' (NEAR END OF PROGRAM).
139 :*TRAP DEFINITIONS
140 :
141 :HERE IS HOW TRAPS WORK IN THIS PROGRAM
142 :
143 :ALL TRAPS EXECUTE A 'TRAP' INSTRUCTION WHICH TAKES THE PROGRAM
144 :TO SYMBOLIC LOCATION '$TRAP'
145 :
146 :AT $TRAP THE PROGRAM PICKS UP THE RIGHT BYTE OF THE TRAP INSTRUCTION
147 :AND INDEXES INTO A TABLE AT LOCATION '$TRPAD' WHICH SENDS THE PROGRAM TO
148 :THE SPECIFIC ROUTINE TO HANDLE THAT SPECIFIC TRAPS TASK.
149 :
150 :THE ULTIMATE DESTINATION OF A TRAP INSTRUCTION CAN BE GUESSED AT AS FOLLOWS
151 :
152 :EXAMPLE:      NOP
153 :              NOP
154 :              NOP
155 :              KERNEL          ;ENTER KERNEL MODE
156 :              NOP
157 :
158 :              ADD A DOLLAR SIGN TO THE SYMBOLIC NAME AND CHECK THE CRF FOR SOMETHING CLOSE
159 :              IS THIS CASE THE CRF HAS $KERNE LISTED AS 032546
160 :              AT LOCATION 32546 YOU FIND THE ROUTINE $KERNEL
161 :
162 :              NOTE THAT CRF SYMBOLS ARE TRUCNATED TO 6 CHARACTERS
163 :              SYMBOLIC NAMES GREATER THAT 6 CHARACTERS ARE USED SO I CAN
164 :              REMEMBER WHAT THEY MEAN!
165 :
166 :              ALL GOOD TRAP ROUTINES RETURN VIA AN 'RTI' INSTRUCTION
167 :
168 :              TYPEIT= 104401      ;;TTY TYPEOUT ROUTINE
169 :              TYPOC= 104402      ;;TYPE OCTAL NUMBER (WITH LEADING ZEROS)
170 :              TYPOS= 104403      ;;TYPE OCTAL NUMBER (NO LEADING ZEROS)
171 :              TYPON= 104404      ;;TYPE OCTAL NUMBER (AS PER LAST CALL)
172 :              TYPDS= 104405      ;;TYPE DECIMAL NUMBER (WITH SIGN)
173 :              TYPBN= 104406      ;;TYPE BINARY (ASCII) NUMBER
174 :
175 :              GTSWR= 104407      ;;GET SOFT-SWR SETTING
176 :              CKSWR= 104410      ;;TEST FOR CHANGE IN SOFT-SWR
177 :
178 :              RDCHR= 104411      ;;TTY TYPEIN CHARACTER ROUTINE
179 :              RDLIN= 104412      ;;TTY TYPEIN STRING ROUTINE
180 :              RDOCT= 104413      ;;READ AN OCTAL NUMBER FROM TTY
181 :              RDDEC= 104414      ;;READ A DECIMAL NUMBER FROM TTY
182 :
183 :              SAVREG= 104415     ;;SAVE R0-R5 ROUTINE
184 :              RESREG= 104416     ;;RESTORE R0-R5 ROUTINE
185 :
186 :              KERNEL= 104417     ;ENTER KERNEL MODE
187 :
188 :              ENERGIZE=104420    ;TURN ON MEMORY MANAGEMENT & TRAPS
189 :              DEENERGIZE=104421 ;TURN OFF MEMORY MANAGEMENT & TRAPS
190 :
191 :              KMAP= 104422      ;MAP KERNEL 1 TO 1
192 :
193 :              CACHON= 104423    ;TURN ON CACHE
    
```

193	104424	CACHOFF=104424	:TURN OFF CACHE
194			
195	104425	LOADCSR=104425	:LOAD CORRECT CSR
196	104426	READCSR=104426	:READ CORRECT CSR
197			
198	104427	PERR01= 104427	:PROGRAM DETECTED ERROR
199	104430	PERR02= 104430	:PROGRAM DETECTED ERROR
200	104431	PERR03= 104431	:PROGRAM DETECTED ERROR
201	104432	PERR04= 104432	:PROGRAM DETECTED ERROR
202	104433	PERR07= 104433	:PROGRAM DETECTED ERROR
203	104434	PERR10= 104434	:PROGRAM DETECTED ERROR
204	104435	PERR11= 104435	:PROGRAM DETECTED ERROR
205	104436	PERR12= 104436	:PROGRAM DETECTED ERROR
206	104437	PERR13= 104437	:PROGRAM DETECTED ERROR
207	104440	PERR14= 104440	:PROGRAM DETECTED ERROR
208	104441	PERR15= 104441	:PROGRAM DETECTED ERROR
209	104442	PERR16= 104442	:PROGRAM DETECTED ERROR
210	104443	PERR17= 104443	:PROGRAM DETECTED ERROR
211	104444	PERR20= 104444	:PROGRAM DETECTED ERROR
212	104445	PERR21= 104445	:PROGRAM DETECTED ERROR
213	104446	PERR22= 104446	:PROGRAM DETECTED ERROR
214	104447	PERR23= 104447	:PROGRAM DETECTED ERROR
215	104450	PERR24= 104450	:PROGRAM DETECTED ERROR
216	104451	PERR25= 104451	:PROGRAM DETECTED ERROR
217	104452	PERR26= 104452	:PROGRAM DETECTED ERROR
218	104453	PERR27= 104453	:PROGRAM DETECTED ERROR
219	104454	PERR30= 104454	:PROGRAM DETECTED ERROR
220	104455	PERR31= 104455	:PROGRAM DETECTED ERROR
221	104456	PERR32= 104456	:PROGRAM DETECTED ERROR
222	104457	PERR33= 104457	:PROGRAM DETECTED ERROR
223	104460	PERR34= 104460	:PROGRAM DETECTED ERROR
224	104461	PERR35= 104461	:PROGRAM DETECTED ERROR
225	104462	PERR36= 104462	:PROGRAM DETECTED ERROR
226	104463	PERR37= 104463	:PROGRAM DETECTED ERROR
227	104464	PERR40= 104464	:PROGRAM DETECTED ERROR
228	104465	PERR41= 104465	:PROGRAM DETECTED ERROR
229	104466	PERR42= 104466	:PROGRAM DETECTED ERROR
230	104467	PERR43= 104467	:PROGRAM DETECTED ERROR
231			
232	104470	ECCDIS= 104470	:DISABLE ECC ON ALL CSR'S
233	104471	ECC1DIS=104471	:DISABLE ECC ON 1 SELECTED CSR
234	104472	ECCINIT=104472	:INITIALIZE ALL MK11 CSR'S
235	104473	ECC1INIT=104473	:INITIALIZE 1 SELECTED MK11 CSR
236	104474	CBCSR= 104474	:WRITE GENERATED CHECKBITS IN ALL CSR'S
237	104475	CB1CSR= 104475	:WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
238	104476	WASSBE= 104476	:WAS THERE A SBE ON ANY CSR?
239	104477	WAS1SBE=104477	:WAS THERE A SBE ON 1 SELECTED CSR?
240	104500	WASDBE= 104500	:WAS THERE A DBE ON ANY CSR?
241	104501	WAS1DBE=104501	:WAS THERE A DBE ON 1 SELECTED CSR?
242	104502	CLRCSR= 104502	:CLEAR ALL CSR'S
243	104503	CLR1CSR=104503	:CLEAR 1 SELECTED CSR
244	104504	CHKDIS= 104504	:DISABLE ECC & WRITE CHECKBITS FROM ALL CSR'S
245	104505	CHK1DIS=104505	:DISABLE ECC & WRITE CHECKBITS FROM 1 SELECTED CSR
246	104506	ENASBE= 104506	:ENABLE TRAPS ON SBE'S FROM ALL CSR'S
247	104507	ENA1SBE=104507	:ENABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
248	104510	TSTREAD=104510	:TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
249	104511	INVALID=104511	:INVALIDATE BACKGROUND PATTERN ON 'BANK'

```

252                                     .SBTTL DEFINE BASIC PDP11 STUFF
253
254                                     ;*INITIAL ADDRESS OF THE STACK POINTER
255         002000         STACK= 2000         ;;FIRST ADDRESS OF THE STACK
256         002000         KERSTK= STACK      ;;KERNEL STACK
257         000740         SUPSTK= 740        ;;SUPERVISOR STACK
258         000700         USESTK= 700        ;;USER STACK
259         104000         ERROR=EMT         ;;BASIC DEFINITION OF ERROR CALL
260         000004         SCOPE=IOT         ;;BASIC DEFINITION OF SCOPE CALL
261         177776         PSW= 177776       ;;PROCESSOR STATUS WORD
262                                     ;STKLMT=177774        ;;STACK LIMIT REGISTER
263                                     ;PIRQ= 177772         ;;PROGRAM INTERRUPT REQUEST REGISTER
264         177570         DSWR= 177570      ;;HARDWARE SWITCH REGISTER
265         177570         DDISP= 177570    ;;HARDWARE DISPLAY REGISTER
266         177546         LKS= 177546      ;;LINE CLOCK (KW11-L) STATUS REGISTER
267
268                                     ;*MISCELLANEOUS DEFINITIONS
269         000011         HT= 11            ;;CODE FOR HORIZONTAL TAB
270         000012         LF= 12           ;;CODE LINE FEED
271         000015         CR= 15           ;;CODE CARRIAGE RETURN
272         000200         CRLF= 200        ;;CODE FOR CARRIAGE RETURN-LINE FEED
273
274                                     ;*GENERAL PURPOSE REGISTER DEFINITIONS
275                                     ;SP=R6                ;;STACK POINTER
276                                     ;KSP=SP              ;;KERNEL STACK POINTER
277         000006         SSP=SP           ;;SUPERVISOR STACK POINTER
278         000006         USP=SP          ;;USER STACK POINTER
279                                     ;PC=R7                ;;PROGRAM COUNTER
280
281                                     ;*'SWITCH REGISTER' SWITCH DEFINITIONS
282         100000         SW15= 100000
283         040000         SW14= 40000
284         020000         SW13= 20000
285         010000         SW12= 10000
286         004000         SW11= 4000
287         002000         SW10= 2000
288         001000         SW9= 1000
289         000400         SW8= 400
290         000200         SW7= 200
291         000100         SW6= 100
292         000040         SW5= 40
293         000020         SW4= 20
294         000010         SW3= 10
295         000004         SW2= 4
296         000002         SW1= 2
297         000001         SW0= 1
298
299                                     ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
300         100000         BIT15= 100000
301         040000         BIT14= 40000
302         020000         BIT13= 20000
303         010000         BIT12= 10000
304         004000         BIT11= 4000
305         002000         BIT10= 2000
306         001000         BIT9= 1000
307         000400         BIT8= 400
308         000200         BIT7= 200
    
```

```

309      000100      BIT6= 100
310      000040      BIT5= 40
311      000020      BIT4= 20
312      000010      BIT3= 10
313      000004      BIT2= 4
314      000002      BIT1= 2
315      000001      BIT0= 1
316
317      ;*BASIC "CPU" TRAP VECTOR ADDRESSES
318      000004      ERRVEC= 4      ;; TIME OUT AND OTHER ERRORS
319      000010      RESVEC= 10     ;; RESERVED AND ILLEGAL INSTRUCTIONS
320      ;TBITVEC=14      ;; 'T' BIT
321      ;TRTVEC=      14      ;; TRACE TRAP
322      ;BPTVEC=      14      ;; BREAKPOINT TRAP (BPT)
323      000020      IOTVEC= 20     ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
324      000024      PWRVEC= 24     ;; POWER FAIL
325      000030      EMTVEC= 30     ;; EMULATOR TRAP (EMT) **ERROR**
326      000034      TRAPVEC=34    ;; 'TRAP' TRAP
327      000060      TKVEC= 60     ;; TTY KEYBOARD VECTOR
328      ;TPVEC= 64      ;; TTY PRINTER VECTOR
329      ;LKVEC= 100     ;; LINE CLOCK (KW11-1) VECTOR
330      000114      CACHVEC=114    ;; CACHE ERROR INTERRUPT VECTOR
331      000114      PARVEC=CACHVEC
332      ;PIRQVEC=240    ;; PROGRAM INTERRUPT REQUEST VECTOR
333      000250      MMVEC= 250     ;; MEMORY MANAGEMENT VECTOR
334      .SBTTL DEFINE CACHE REGISTERS
335      177740      LOADRS = 177740 ;; LOWER 16 BITS OF ADDRESS THAT CAUSED ERROR
336      177742      HIADRS = 177742 ;; UPPER SIX BITS OF ADDRESS THAT CAUSED ERROR
337      177744      MEMERR = 177744 ;; CACHE ERROR REGISTER
338      177746      CONTRL = 177746 ;; MEMORY CONTROL REGISTER
339      177750      MAINT = 177750 ;; MEMORY MAINTENANCE REGISTER
340      ;HITMIS = 177752      ;; HIT MISS REGISTER 'T' IMPLIES HIT IN CACHE
341
342      .SBTTL DEFINE CPU REGISTERS
343      177760      SIZELO = 177760 ;; MEMORY SIZE REGISTER NUMBER TO PUT INTO A PAR
344      ;SIZEHI = 177762      ;; TO GET TO THE LAST 32 WORDS OF MEMORY
345      ;SIZEHI = 177762      ;; HIGH SIZE REGISTER, RESERVED FOR FUTURE USE
346      ;CURRENTLY ALL ZERO
347      177764      SYSTID = 177764 ;; SYSTEM ID REGISTER
348      177766      CPUERR = 177766 ;; CPU ERROR REGISTER HOLDS CONDITION THAT CAUSED
349
350      .SBTTL DEFINE MEMORY MANAGEMENT REGISTERS
351      ;*MEMORY MANAGEMENT STATUS REGISTER ADDRESSES
352      177572      MMR0= 177572
353      177574      MMR1= 177574
354      177576      MMR2= 177576
355      172516      MMR3= 172516
356
357      ;*USER "I" PAGE DESCRIPTOR REGISTERS
358      177600      UIPDR0= 177600
359      ;UIPDR1= 177602
360      ;UIPDR2= 177604
361      ;UIPDR3= 177606
362      ;UIPDR4= 177610
363      ;UIPDR5= 177612
364      ;UIPDR6= 177614
365      ;UIPDR7= 177616
    
```



```
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
```

```

;*USER 'D' PAGE DESCRIPTOR REGISTERS
:UDPDR0= 177620
:UDPDR1= 177622
:UDPDR2= 177624
:UDPDR3= 177626
:UDPDR4= 177630
:UDPDR5= 177632
:UDPDR6= 177634
UDPDR7= 177636

;*USER 'I' PAGE ADDRESS REGISTERS
FASTCITY=UIPAR0
UIPAR0= 177640
:UIPAR1= 177642
UIPAR2= 177644
UIPAR3= 177646
UIPAR4= 177650
UIPAR5= 177652
UIPAR6= 177654
UIPAR7= 177656
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE

;*USER 'D' PAGE ADDRESS REGISTERS
UDPAR0= 177660
UDPAR1= 177662
:UDPAR2= 177664
:UDPAR3= 177666
:UDPAR4= 177670
:UDPAR5= 177672
:UDPAR6= 177674
UDPAR7= 177676
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE
:PATTERN PROGRAM SPACE

;*SUPERVISOR 'I' PAGE DESCRIPTOR REGISTERS
SIPDR0= 172200
:SIPDR1= 172202
:SIPDR2= 172204
:SIPDR3= 172206
:SIPDR4= 172210
:SIPDR5= 172212
:SIPDR6= 172214
:SIPDR7= 172216

;*SUPERVISOR 'D' PAGE DESCRIPTOR REGISTERS
:SDPDR0= 172220
:SDPDR1= 172222
:SDPDR2= 172224
:SDPDR3= 172226
:SDPDR4= 172230
:SDPDR5= 172232
:SDPDR6= 172234
SDPDR7= 172236

;*SUPERVISOR 'I' PAGE ADDRESS REGISTERS
SIPAR0= 172240
:SIPAR1= 172242
:SIPAR2= 172244
SIPAR3= 172246
:TEST AREA
```

```

423          :SIPAR4=      172250          :TEST AREA
424          :SIPAR5=      172252          :TEST AREA
425          :SIPAR6=      172254          :TEST AREA
426          :SIPAR7=      172256
427
428          :*SUPERVISOR 'D' PAGE ADDRESS REGISTERS
429          172260      SDPAR0= 172260
430          :SDPAR1=      172262
431          :SDPAR2=      172264
432          :SDPAR3=      172266
433          :SDPAR4=      172270
434          :SDPAR5=      172272
435          :SDPAR6=      172274
436          172276      SDPAR7= 172276
437
438          :*KERNEL 'I' PAGE DESCRIPTOR REGISTERS
439          172300      KIPDR0= 172300
440          :KIPDR1=      172302
441          :KIPDR2=      172304
442          :KIPDR3=      172306
443          :KIPDR4=      172310
444          :KIPDR5=      172312
445          :KIPDR6=      172314
446          :KIPDR7=      172316
447
448          :*KERNEL 'D' PAGE DESCRIPTOR REGISTERS
449          :KDPDR0=      172320
450          :KDPDR1=      172322
451          :KDPDR2=      172324
452          :KDPDR3=      172326
453          :KDPDR4=      172330
454          :KDPDR5=      172332
455          :KDPDR6=      172334
456          172336      KDPDR7= 172336
457
458          :*KERNEL 'I' PAGE ADDRESS REGISTERS
459          172340      KIPAR0= 172340
460          :KIPAR1=      172342
461          :KIPAR2=      172344
462          :KIPAR3=      172346
463          172350      KIPAR4= 172350
464          172352      KIPAR5= 172352
465          172354      KIPAR6= 172354
466          172356      KIPAR7= 172356
467
468          :*KERNEL 'D' PAGE ADDRESS REGISTERS
469          172360      KDPAR0= 172360
470          :KDPAR1=      172362
471          :KDPAR2=      172364
472          :KDPAR3=      172366
473          :KDPAR4=      172370
474          :KDPAR5=      172372
475          :KDPAR6=      172374
476          172376      KDPAR7= 172376
477
    
```

DEFINE UNIBUS MAP REGISTERS

```
480          .SBTTL DEFINE UNIBUS MAP REGISTERS
481          ;*THE LOWER 16 BITS OF THE MAP REGISTERS ARE LABELED 'MAPLXX'
482          ;*THE UPPER 6 BITS OF THE MAP REGISTERS ARE LABELED 'MAPHXX'
483          170200      MAPL0 = 170200
484          170202      MAPH0 = 170202
485          170204      MAPL1 = 170204
486          ;MAPH1 = 170206
487          ;MAPL2 = 170210
488          ;MAPH2 = 170212
489          ;MAPL3 = 170214
490          ;MAPH3 = 170216
491          ;MAPL4 = 170220
492          ;MAPH4 = 170222
493          ;MAPL5 = 170224
494          ;MAPH5 = 170226
495          ;MAPL6 = 170230
496          ;MAPH6 = 170232
497          ;MAPL7 = 170234
498          ;MAPH7 = 170236
499          ;MAPL10 = 170240
500          ;MAPH10 = 170242
501          ;MAPL11 = 170244
502          ;MAPH11 = 170246
503          ;MAPL12 = 170250
504          ;MAPH12 = 170252
505          ;MAPL13 = 170254
506          ;MAPH13 = 170256
507          ;MAPL14 = 170260
508          ;MAPH14 = 170262
509          ;MAPL15 = 170264
510          ;MAPH15 = 170266
511          ;MAPL16 = 170270
512          ;MAPH16 = 170272
513          ;MAPL17 = 170274
514          ;MAPH17 = 170276
515          ;MAPL20 = 170300
516          ;MAPH20 = 170302
517          ;MAPL21 = 170304
518          ;MAPH21 = 170306
519          ;MAPL22 = 170310
520          ;MAPH22 = 170312
521          ;MAPL23 = 170314
522          ;MAPH23 = 170316
523          ;MAPL24 = 170320
524          ;MAPH24 = 170320
525          ;MAPL25 = 170324
526          ;MAPH25 = 170326
527          ;MAPL26 = 170330
528          ;MAPH26 = 170332
529          ;MAPL27 = 170334
530          ;MAPH27 = 170336
531          ;MAPL30 = 170340
532          ;MAPH30 = 170342
533          ;MAPL31 = 170344
534          ;MAPH31 = 170346
535          ;MAPL32 = 170350
536          ;MAPH32 = 170352
```

```
537          :MAPL33 = 170354
538          :MAPH33 = 170356
539          :MAPL34 = 170360
540          :MAPH34 = 170362
541          :MAPL35 = 170364
542          :MAPH35 = 170366
543          170370 :MAPL36 = 170370
544          170372 :MAPH36 = 170372
545          :MAPL37 = 170374
546          170376 :MAPH37 = 170376
547
548          .SBTTL DEFINE SOFTWARE SWITCH & DISPLAY REGISTERS
549          000174 DISPREG=174
550          000176 SWREG= 176
551
552          .SBTTL DEFINE MK11 REGISTERS
553          172100 MK11ADD=172100
554
555          .SBTTL DEFINE PARAMETERS
556          060000 FIRST=60000          ;START OF THE 16K TEST PATTERN AREA
557          157776 LAST=157776         ;END OF THE 16K TEST PATTERN AREA
558          040000 SIZE=40000          ;SIZE OF THE 16K TEST PATTERN AREA (FOR SOB INSTRUCTIONS)
559          011661 SECONDS=11661       ;CONSTANT FOR LENGTH OF TIME FOR HUNG CPU TEST
560          .SBTTL DEFINE MASTER & SLAVE BITS
561          000020 MASTER=20
562          000040 SLAVE1=40
563          000100 SLAVE2=100
564          000200 SLAVE3=200
```

567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603

```
.LIST MD ;BE NICE TO SEE MY DEFINITIONS
.SBTTL MACRO FATAL
***** FATAL *****
FATAL IS USED TO REPORT FATAL ERRORS (ERRORS THAT PREVENT
THE PROGRAM FROM CONTINUING).
*****
.MACRO FATAL ARG ;**MACRO**MACRO**MACRO**
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
INC FATAL$ ;SET FATAL INDICATOR
ERROR +ARG
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM FATAL

.SBTTL MACRO TYPE
.MACRO TYPE ARG
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
.IF B ARG
TYPEIT
.IFF
TYPEIT ,ARG
.ENDC
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM TYPE
```

606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653

```
.SBTTL MACRO NEWTST
:***** NEWTST *****
:NEWTST IS USED AS THE FIRST INSTRUCTION OF A TEST.
:IT WILL:
:1) GENERATE A TEST NUMBER FOR THE LABEL OF THIS TEST
:2) PUT STARS BEFORE AND AFTER A MESSAGE
:ARGUMENTS
:1) ASCII -- THIS IS THE MESSAGE THAT WILL APPEAR
:           ON THE LISTING
:2) ICOUNT -- IF NON-BLANK AND BIT 11 OF $SWR = 1 IT WILL BE
:             THE NUMBER OF ITERATIONS TO MAKE ON THIS TEST
:3) RETURN -- IF NON-BLANK WILL BE THE ADDRESS TO
:             WHICH THE NEXT SCOPE STATEMENT WILL
:             LOOP BACK TO.
:4) COMAND -- IF NON-BLANK WILL BE THE FIRST
:             INSTRUCTION OF THE TEST
:             IF BLANK SCOPE WILL BE THE
:             FIRST INSTRUCTION
:*****
.MACRO NEWTST ASCII,ICOUNT,RETURN,COMAND
$STN=1
$NWTST=0
.NLIST MC
.IF B <COMAND>
$$NEWTST \ $TN,<ASCII> ,SCOPE
.IFF
$$NEWTST \ $TN,<ASCII> ,<COMAND>
.ENDC
.NLIST
.LIST ME
.LIST
.IF NE 4000B$SWR
.IF NB ICOUNT
.IF LE <ICOUNT-1>
MOV #1,$TIMES ;;DO 1 ITERATION
.IFF
MOV #ICOUNT,$TIMES ;;DO ICOUNT ITERATIONS
.ENDC
.ENDC
.IF NB RETURN
MOV #RETURN,$LPADR ;;SET SCOPE LOOP ADDRESS
.ENDC
.ENDC
.NLIST
.LIST MC
.LIST
.NLIST ME
.ENDM NEWTST
```

656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708

```
.SBTTL MACRO $$NEWTEST
.MACRO $$NEWTEST A,ASC,COMND
.IRP ASCI,<ASC>
.IF EQ $NWTST
$NWTST=1
.SBTTL T'A' ASCI
.NLIST
.LIST ME
.LIST
:*****
:*TEST A ASCI
.IFF
ASCI
.ENDC
.ENDM
:*****
TST'A: COMND
.NLIST ME
$TN=$TN+1
.ENDM $$NEWTEST

.SBTTL MACRO SUBTST
:***** SUBTST *****
:
:THIS MACRO WILL FORMAT A SUBTEST HEADING WITH STARS
:A .SBTTL WILL BE FORCED & .NLISTED FOR THE TABLE OF CONTENTS.
:
:ARGUMENT:
:1) TXT -- THIS IS THE MESSAGE THAT WILL APPEAR IN THE TABLE OF CONTENTS & LISTING.
:
:EXAMPLE: SUBTST <<THIS IS A FUN SUBTST>>
:
:*****

.MACRO SUBTST ASCII
.NLIST MC
$SUBTST <ASCII>
.LIST MC
.ENDM SUBTST

.SBTTL MACRO $SUBTST
.MACRO $SUBTST ASC
.IRP ASCI,<ASC>
.SBTTL ASCI
.NLIST
.LIST ME
.LIST
:*****
:*SUBTEST ASCI
.ENDM
:*****
.NLIST ME
.ENDM $SUBTST
```

MACRO TYPOCT

711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748

```

.SBTTL MACRO TYPOCT
***** TYPOCT *****
:TYPOCT IS USED TO CHANGE A BINARY NUMBER
: TO A 6 DIGIT OCTAL NUMBER AND TYPE IT
:ARGUMENTS:
:1) NUM THE NUMBER TO BE TYPED
:2) REMARK ALLOWS A COMMENT TO BE MADE
:ROUTINES REQUIRED
:1) CONVERT BINARY TO OCTAL AND TYPE (.$TYPOCT)
:2) TYPE AN ASCIZ STRING (.$TYPE)
:EXAMPLES:
:1) TYPOCT HILMT,<TYPES THE CONTENTS OF HILMT>
:2) TYPOCT #5,<TYPES '000005'>
*****

.MACRO TYPOCT NUM,REMARK
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
MOV NUM, -(SP) ;;SAVE NUM FOR TYPEOUT
.IIF NB <REMARK>, ;;REMARK
TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM TYPOCT

```


751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804

```
.SBTTL MACRO TYPOCS
***** TYPOCS *****
TYPOCS IS USED TO CHANGE A BINARY NUMBER TO AN OCTAL
NUMBER AND TYPE 1 TO 6 DIGITS
WITH OR WITHOUT LEADING ZEROS.

ARGUMENTS:
1) NUM NUMBER TO BE TYPED
2) REMARK ALLOWS A COMMENT TO BE MADE
3) N NUMBER OF DIGITS (1 TO 6) TO BE TYPED
4) Z BLANK=SUPPRESS LEADING ZEROS (TYPES SPACES)
NON-BLANK=TYPE LEADING ZEROS

ROUTINES REQUIRED
1) CONVERT BINARY TO OCTAL AND TYPE (.$TYPOCT)
2) TYPE AN ASCIZ STRING (.$TYPE)

EXAMPLES:
1) TYPOCS #12345,<TYPES '5'>,1
2) TYPOCS #004,<TYPES '04'>,2,X
3) TYPOCS #004,<TYPES ' 4'>,2
*****

.MACRO TYPOCS NUM,REMARK,N,Z
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
MOV NUM,-(SP) ;;SAVE NUM FOR TYPEOUT
.IIF NB <REMARK>, ;;REMARK
TYPOS ;;GO TYPE--OCTAL ASCII
.IF NB N
.BYTE N ;;TYPE N DIGIT(S)
.IFF
.BYTE 6 ;;TYPE 6 DIGITS
.ENDC
.IF NB Z
.BYTE 1 ;;TYPE LEADING ZEROS
.IFF
.BYTE 0 ;;SUPPRESS LEADING ZEROS
.ENDC
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM TYPOCS
```

MACRO TYPDEC

807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847

```

.SBTTL MACRO TYPDEC
***** TYPDEC *****
:TYPDEC IS USE TO CHANGE A BINARY NUMBER TO A SIGNED
:DECIMAL NUMBER AND TYPE IT REPLACING LEADING ZERO
:WITH SPACES.
:NOTE: IF THE NUMBER IS NEGATIVE A
:MUNUS SIGN WILL BE TYPED.
:
:ARGUMENTS:
:1) NUM NUMBER TO BE TYPED
:2) REMARK ALLOWS A COMMENT TO BE MADE
:
:ROUTINES REQUIRED
:1) CONVERT BINARY TO DECIMAL AND TYPE (.$TYPDEC)
:2) TYPE AN ASCIZ STRING (.$TYPE)
:
:EXAMPLES
:1) TYPDEC SIZE,<TYPE THE CONTENTS OF SIZE>
:2) TYPDEC #-10.,<TYPE A MINUS TEN>
*****

.MACRO TYPDEC NUM,REMARK
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
MOV NUM,-(SP) ;;SAVE NUM FOR TYPEOUT
.IIF NB <REMARK>, ;;REMARK
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM TYPDEC

```

849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905

```

.SBTTL MACRO BMOV
***** BMOV *****
: THIS MACRO MOVES A BLOCK OF DATA.
: ARGUMENTS:
: 1) FROMHERE THE FIRST ADDRESS OF THE SOURCE BLOCK.
: 2) TOHERE THE FIRST ADDRESS OF THE DESTINATION BLOCK.
: IF BLANK THE 1ST ADDRESS OF THE USER INSTRUCTION
: PAR'S IS USED (FASTCITY).
: 3) SIZE THE SIZE OF THE SOURCE BLOCK.
: IF BLANK A 16 WORD TRANSFER IS ASSUMED.
: 'WHY DEFAULT TO 16 WORDS?' YOU ASK!
: 'BECAUSE THAT'S HOW MANY WORDS TO THE USER PAR
: REGISTERS & THAT'S WHERE I INTEND TO MOVE LOTS
: OF STUFF.' I REPLY!
*****

.MACRO BMOV FROMHERE,TOHERE,SIZE
. IF B TOHERE
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
JSR R5,BLOCK1
FROMHERE
.DSABL CRF
.IIF DF 1ST$$ .NLIST ME
.ENABL CRF
.MEXIT
.ENDC
. IF B SIZE
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
JSR R5,BLOCK2
TOHERE
FROMHERE
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.MEXIT
. IFF
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
JSR R5,BLOCK3
SIZE

```

MACRO BMOV

906
907
908
909
910
911
912

TOHERE
FROMHERE
.DSABL CRF
.IIF DF LST\$\$.NLIST ME
.ENABL CRF
.ENDC
.ENDM BMOV

MACRO MAP

915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951

```

.SBTTL MACRO MAP
***** MAP *****
: THIS MACRO MAPS A MEMORY BANK (16K) INTO THE
: TEST PATTERN AREA (SUPERVISOR VIRTUAL (60000-15777)).
: ARGUMENTS:
: 1) BANK THE BANK OF 16K WORDS TO BE MAPPED.
: THERE ARE 120 BANKS OF 16K WORDS
: EXAMPLES
: MAP LOC ;LOCATION 'LOC' CONTAINS THE # OF THE BANK 'O MAP
: MAP #28. ;BANK 34 (OCTAL) WILL BE MAPPED
*****

.MACRO MAP BANK
PUSH R3
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
.IF B BANK
MOV #120.,R3
.IFF
MOV BANK,R3
.ENDC
CALL MAPPER
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
POP R3
.ENDM MAP

```

954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994

```

.SBTTL MACRO SUPERVISOR
***** SUPERVISOR *****
: THIS MACRO SWITCHES TO SUPERVISOR MODE.
: ARGUMENTS: NONE.
*****

.MACRO SUPERVISOR
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
BIS #BIT14,PSW ;DO IT TO IT!
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM SUPERVISOR

.SBTTL MACRO USER
***** USER *****
: THIS MACRO SWITCHES TO USER MODE.
: ARGUMENTS: NONE.
*****

.MACRO USER
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
BIS #BIT15:BIT14,PSW ;DO IT TO IT!
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM USER

```

997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036

```
.SBTTL MACRO SET4 & RES4  
***** SET4 & RES4 *****  
: THESE MACROS SET & RESTORE VECTOR 4 (TIMEOUT TRAP)  
: IN IT'S RESTORED MODE TRAPS ARE REPORTED AS SUCH.  
: ARGUMENTS: LOC ;THE LOCATION TO VECTOR TO (ONLY USED IN 'SET4' NOT 'RES4')  
: I USE THE SET4 AND RES4 MACROS AROUND CODE THAT I EXPECT TO TRAP TO 4  
: LIKE LOOKING FOR ALL POSSIBLE CSR'S AND ETC. WHENEVER CODE IS NOT  
: SURROUNDED BY SET4 AND RES4 THEN ANY TRAPS TO 4 WILL CAUSE AN ERROR  
: PRINTOUT THAT SAYS 'UNEXPECTED TRAP TO 4' AND ALL THE ASSOCIATED REGISTER JUNK  
: *****  
  
.MACRO SET4 ARG  
.NLIST  
.DSABL CRF  
.IIF DF LST$$ .LIST ME  
.ENABL CRF  
.LIST  
MOV ARG,4  
.DSABL CRF  
.IIF DF LST$$ .NLIST ME  
.ENABL CRF  
.ENDM SET4  
  
.MACRO RES4  
.NLIST  
.DSABL CRF  
.IIF DF LST$$ .LIST ME  
.ENABL CRF  
.LIST  
MOV #TIMEOUT,4  
CLR CPUERR ;CLEAR OUT THE CPU ERROR REGISTER BITS  
;THAT A EXPECTED TRAP COULD HAVE SET  
  
.DSABL CRF  
.IIF DF LST$$ .NLIST ME  
.ENABL CRF  
.ENDM RES4
```

MACRO DLEFT

1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060

```

.SBTL MACRO DLEFT
***** DLEFT *****
: THIS MACRO DOES A DOUBLE WORD LEFT SHIFT
: ARGUMENTS: LOC ;THE LOCATION TO BE SHIFTED LEFT (CARRY TO LOC+2)
*****

.MACRO DLEFT ARG
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
ROL ARG
ROL ARG+2
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM DLEFT
.NLIST MD ;DON'T NEED TO SEE THEM ANY MORE

```



```

1063
1064
1065 000000 000000 000000
1066 000177
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086 000046 000046
1087 000046 015000
1088 000052 000052
1089 000052 040000
1090
1091 000024 000024
1092 000024 000200
1093 000042 000042
1094 000042 002000
1095 000044 000044
1096 000044 075236
1097 000200 000200
1098 000200 000437
1099 000202 000442
1100 000204 000446
1101 000300 000300
1102 000300 005037 002752
1103 000304 000137 004352
1104 000310 000137 004352
1105 000316 000137 004352
1106 000322 000137 000300
1107 000330 000137 000300
1108 002000
  
```

```

.SBTTL TRAP CATCHER
.-0
.WORD 0,0
.REPT 177      ;.WORD .+2,HALT

.SBTTL ACT11 HOOKS
*THE HOOKS REQUIRED BY ACT11 ARE DEFINED AND SETUP BELOW:
DEFINITIONS:
1)LOC.46      'END-OF-PASS' HOOK
              -ADDRESS OF END OF PASS ROUTINE
              MODIFIED BY ACT11.
2)LOC.52      PROGRAM NEEDS HOOK
              BIT 15=1 PROGRAM SHOULD BE POWER
              FAILED WHILE RUNNING
              =0 NO POWER FAIL
              BIT 14=1 PROGRAM MEMORY SIZE DEPENDENT
              -0 NOT MEMORY SIZE DEPENDENT
              BIT 13=1 PROGRAM REQUIRES MANUAL INTERVENTION
              =0 MANUAL INTERVENTION NOT REQUIRED
              BITS 12=0 MUST BE ZERO'S

              ;:1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
              ;:2)SET LOC.52 TO INDICATE MEMORY SIZE DEPENDANT

.=46
SENDAD
.=52
.WORD BIT14
.SBTTL APT11 HOOKS
.=24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
200      ;;FOR APT START UP

.=42
STACK      ;SO RT11 CAN START WITH RUN COMMAND
.=44      ;;POINT TO APT INDIPECT ADDRESS PNTR.
$APTHDR   ;;POINT TO APT HEADER BLOCK
. 200

START3: BR   START1      ;'NORMAL' START
        BR   START2      ;RESTART (SAVE ERROR ACCOUNTING)
        BR   START4      ;'RUN MULTIPROCESSOR TESTS WITHOUT THE IIS' START

. 300

START1: CLR   RESTART
        JMP   START
START2: SET   RESTART
        JMP   START
START4: SET   NOI1ST
        JMP   START1

. STACK
  
```

Address	Value	Variable Name	Value	Description
1111		.SBTTL VARIABLES INITIALIZED TO ZERO		
1112		:*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS		
1113		:*USED IN THE PROGRAM.		
1114	002000	\$CMTAG:	0	::START OF COMMON TAGS
1115	002000	BADCSR:	0	::CSR DETERMINED TO HAVE AN ERROR BY BAD BOX ROUTINE
1116	002002	SELONLY:	0	::SELECT ONLY BANKS MARKED BY FIELD SERVICE MODE FLAG
1117	002004	MULTIONLY:	0	::RUN ONLY MULTI;PORT TESTS FLAG
1118	002006	DIAGFLAG:	0	::SET FOR SHIFTING DIAGONAL TEST
1119	002010	KAMIKAZE:	0	::SET FOR KAMIKAZE MODE TESTING
1120	002012	SKIPKAMI:	0	::USED TO SKIP RESTORING KAMIKAZE MODE WHEN MODIFIED
1121		:NEXT TWO BYTES ARE DISPLAYED IN THE DISPLAY REGISTER		
1122	002014	\$PATMAR:	.BYTE 0	::PATTERN NUMBER & MARGIN VALUE
1123	002015	\$BANK:	.BYTE 0	::BANK & SIGN = MARGIN INDICATOR
1124	002016	\$ERFLG:	.BYTE 0	::CONTAINS ERROR FLAG
1125	002017	\$ITEMB:	.BYTE 0	::CONTAINS ITEM CONTROL BYTE
1126	002020	LASTERROR:	.WORD 0	::NUMBER OF ERRORS ON LAST PASS
1127	002022	SBFLAG:	.WORD 0	::A SINGLE BIT ERROR HAS OCCURED THIS PASS
1128	002024	ERRPC:	.WORD 0	::CONTAINS PC OF ERROR FOR TYPEOUT
1129	002026	BADPC:	.WORD 0	::CONTAINS PC OF ERROR
1130	002030	ERRSP:	.WORD 0	::CONTAINS SP OF ERROR FOR TYPEOUT
1131	002032	BADSP:	.WORD 0	::CONTAINS SP OF ERROR
1132	002034	ERRPSW:	.WORD 0	::CONTAINS PSW OF ERROR FOR TYPEOUT
1133	002036	BADPSW:	.WORD 0	::CONTAINS PSW OF ERROR
1134	002040	ADDRESS:	.WORD 0	::CONTAINS ADDRESS OF 'BAD' DATA
1135	002042	PADDRESS:	.WORD 0	::ADDRESS OF PARITY ERROR
1136	002044	PHYADD:	.WORD 0,0	::22 BIT PHYSICAL ADDRESS
1137	002050	GOOD:	.WORD 0	::CONTAINS 'GOOD' DATA
1138	002052	GOOD2:	.WORD 0	::CONTAINS 'GOOD2' DATA
1139	002054	GOOD3:	.WORD 0	::CONTAINS 'GOOD3' DATA
1140	002056	BAD:	.WORD 0	::CONTAINS 'BAD' DATA
1141	002060	BAD2:	.WORD 0	::CONTAINS 'BAD2' DATA
1142	002062	BAD3:	.WORD 0	::CONTAINS 'BAD3' DATA
1143	002064	BADXOR:	.WORD 0	::XOR OF GOOD & BAD = BAD BITS'
1144	002066	\$AUTO:	.WORD 0	::AUTOMATIC MODE INDICATOR FOR APT,ACT, & XXDP
1145	002070	FATALS:	.WORD 0	::FATAL ERROR INDICATOR
1146	002072	NEMCNT:	0	::NON-EXISTANT MEMORY COUNTER (HOLES)
1147	002074	PARCNT:	0	::PARITY ERROR COUNTER
1148	002076	PATERR:	0	::PATTERN ERROR COUNTER
1149	002100	NOPAR:	0	::NO PARITY ERROR MODE INDICATOR
1150	002102	NONEM:	0	::NO NON-EXISTANT MEMORY (HOLES) MODE INDICATOR
1151	002104	NOCLOCK:	0	::NO LINE CLOCK IS ON THIS SYSTEM
1152	002106	BANK:	0	::MEMORY BANK UNDER TEST
1153	002110	BANKINDEX:	0	::USED TO INDEX INTO CONFIG TABLE
1154	002112	MARGIN:	0	::INDICATES WHICH MARGIN IS IN PROGRESS
1155	002114	CPUBIT:	0	::CONTAINS 1 BIT TO IDENTIFY CPU TO CONFIGURATION TABLE
1156	002116	MUT:	0	::MEMORY UNDER TEST FLAG
1157	002120	PATTERN:	0	::PATTERN NUMBER UNDER TEST
1158	002122	KPFLAG:	0	::BANK IS PROTECTED REGION OF MK11
1159	002124	ACFLAG:	0	::BANK CAN BE ACCESSED BY THIS CPU
1160	002126	MKFLAG:	0	::IF SET INDICATES MK11 UNDER TEST
1161	002130	PFLAG:	0	::BANK IS IN PROGRAM SPACE
1162	002132	RRFLAG:	0	::BANK IS WHERE PROGRAM RELOCATION IS REQUIRED TO TEST
1163	002134	RLFLAG:	0	::PROGRAM IS RELOCATED FLAG
1164	002136	BMFLAG:	0	::'BANK IS IDENTIFIED AS BAD MEMORY'' FLAG
1165	002140	TMFLAG:	0	::'TYPE OF MEMORY TO TEST'' FLAG; 0 - MK11
1166	002142	ABORTFLAG:	0	::'ABORT OCCURED'' FLAG
1167	002144	CSR:	.WORD 0,0	::DATA TO OR FROM CSR

```

1168 002150 000000 000000 SBECRS: .WORD 0,0 ;CSR STORED HERE ON MK11 DETECTED SBE'S
1169 002154 000000 000000 000000 CSRO: .WORD 0,0,0,0,0,0,0,0 ;SAVE CSR'S AFTER GETSIZE CALL
      002162 000000 000000 000000
1170 002170 000000 000000
      002174 000000 000000 000000 CSR2: .WORD 0,0,0,0,0,0,0,0 ;SAVE CSR+2'S AFTER GETSIZE CALL
      002202 000000 000000 000000
      002210 000000 000000
1171 002214 000000 000000 000000 CSRFB: .WORD 0,0,0,0,0,0,0,0 ;SAVE FIRSTB'S AFTER GETSIZE CALL
      002222 000000 000000 000000
      002230 000000 000000
1172 002234 000000 000000 000000 CSRFB: .WORD 0,0,0,0,0,0,0,0 ;SAVE LASTB'S AFTER GETSIZE CALL
      002242 000000 000000 000000
      002250 000000 000000
1173 002254 000000 CSRREL: .WORD 0 ;CSR'S ARE RELOCATED TO SHADOW MEMORY FLAG
1174 002256 000000 CSRNO: 0 ;CSR ADDRESS NUMBER (3 LSB'S)
1175 002260 000000 FIRSTB: 0 ;FIRST BANK CONTROLLED BY THIS CSR
1176 002262 000000 LASTB: 0 ;LAST BANK CONTROLLED BY THIS CSR
1177 002264 000000 INTERL: 0 ;INTERLEAVE FACTOR (0,1,2,3)
1178 ;THESE LOCATIONS STORE GPR'S DURING SUPERVISOR TESTS
1179 002266 000000 SUPDR0: 0
1180 002270 000000 SUPDR1: 0
1181 002272 000000 SUPDR2: 0
1182 002274 000000 SUPDR3: 0
1183 002276 000000 SUPDR4: 0
1184 002300 000000 SUPDR5: 0
1185 002302 000000 SUPDR6: 0
1186 002304 000000 DUMMY: 0 ;DUMMY LOCATION FOR ADDRESS PASSING
1187 ;THESE LOCATIONS STORE GPR'S & PSW DURING DETAILED ERROR PRINTOUTS
1188 002306 000000 DETR0: 0
1189 002310 000000 DETR1: 0
1190 002312 000000 DETR2: 0
1191 002314 000000 DETR3: 0
1192 002316 000000 DETR4: 0
1193 002320 000000 DETR5: 0
1194 002322 000000 DETSP: 0
1195 002324 000000 DETPSW: 0
1196 002326 000000 DETFLAG: 0 ;DETAILED REPORT FLAG
1197 002330 000000 PENDBOX: 0 ;1 BIT PER EXISTING CSR THAT STARTS AT A BANK ABOVE 166
1198 ;CSR'S 0,1,2,3,4,5,6,7 REPRESENTED BY BITS
1199 ;7,6,5,4,3,2,1,0 RESPECTIVELY
1200 002332 000000 CONTFLAG: 0 ;MK11 CONTROL'S HAVE BEEN TESTED FLAG
1201 002334 000000 MKCSRS: .WORD 0 ;LO BYTE: 1 BIT PER EXISTING CSR
1202 ;CSR'S 0,1,2,3,4,5,6,7 REPRESENTED BY BITS
1203 ;7,6,5,4,3,2,1,0 RESPECTIVELY
1204 ;HI BYTE: 1 BIT PER EXISTING CSR WITH INTERNAL INTERLEAVE
1205 ;INTERNAL INTERLEAVE REPRESENTED BY BITS
1206 ;15,14,13,12,11,10,9,8 RESPECTIVELY
1207 002336 000000 CSRFIRST: 0 ;FIRST ADDRESS UNDER CONTROL OF THIS CSR
1208 002340 000000 000000 DATBUF: .WORD 0,0 ;TWO WORD DATA BUFFER
1209 002344 000000 000000 TSTDAT: .WORD 0,0 ;TWO WORD TEST DATA
1210 002350 000000 000000 SBEMSK: .WORD 0,0 ;TWO WORD SINGLE BIT ERROR MASK
1211 002354 000000 000000 DBEMSK: .WORD 0,0 ;TWO WORD DOUBLE BIT ERROR MASK
1212 002360 000000 SUPDOADD: 0 ;ADDRESS OF SUBROUTINE TO EXECUTE IN SUPERVISOR MODE
1213 002362 000 PASFLG: .BYTE 0 ;LOCAL LOOP PASS CONTROL
1214 002363 000 UPPFLG: .BYTE 0 ;LOCAL LOOP PASS CONTROL
1215 002364 000000 STRTDI: 0 ;LOAD STRTDI WITH THE STARTING ADDRESS OF THE DIAGONAL
1216 002366 000000 REALPAT: 0 ;REAL PATTERN UNDER TEST
    
```

1217	002370	000000	OLDCACHE:0	:BACKED UP VALUE OF CACHE CONTROL REGISTER
1218	002372	000000	PARTHERE:0	:PARITY TRAPS SOMETIMES GO TO ADDRESS STORED HERE
1219	002374	000000	FSSTACK:0	:STACK SAVED HERE IF IN FIELD SERVICE MODE
1220	002376	000000	GLDMARGIN:0	:BACKED UP VALUE OF LAST MARGIN SETTING
1221	002400	000000	NEWBANK:0	:USED FOR RELOCATION TO A NEW BANK
1222	002402	000000	SOURCE: .WORD 0	:SOURCE OF DATA WORDS FOR CHECKBIT GENERATION SUBROUTINE
1223	002404	000000	CHECK: .WORD 0	:CHECKBITS TO BE LOADED INTO CSR
1224	002406	000000	PCBUMP: .WORD 0	:VALUE TO BUMP THE PC BY TO RECOVER AFTER A PARITY TRAP
1225	002410	000000	CSRFBANK:0	:FIRST BANK OWNED (AT LEAST IN PART) BY THIS CSR
1226	002412	000000	CSRLBANK:0	:LAST BANK OWNED (AT LEAST IN PART) BY THIS CSR
1227	002414	000000	CSRINC: 0	:VALUE TO INCREMENT ADDRESS BY TO REMAIN IN THE SAME CSR
1228	002416	000	CSRINDEX: .BYTE 0	:AN INDEX VARIABLE FOR A CSR LOOP
1229	002417	000	CSROINDEX: .BYTE 0	:AN INDEX VARIABLE FOR A CSR LOOP
1230	002420	000000	CSRLOOP:0	:LOOP CONTROL FOR CSR TESTING
1231	002422	000000	SIDE: 0	:INDEX VARIABLE FOR EACH SIDE (CONTROLLER) OF A CSR
1232	002424	000000	SUCCESS:0	:FLAG SET BY SUCCESSFULL TASK OR SUBROUTINE
1233	002426	000000	ZERO: 0	:FOR AID IN 'MOV' INSTRUCTIONS
1234	002430	000000	ZEROS: 0	:FOR AID IN 'MOV' INSTRUCTIONS
1235	002432	000000	SPECIAL:0	:FLAG FOR SPECIAL CASE OF NO INTERNAL INTERLEAVE
1236	002434	000000	TIME: 0	:SECONDS THAT BATTERIES SHOULD LAST
1237	002436	000000	NULLFLAG:0	:SET WHEN RUNNING NULL PATTERNS
1238	002440	000000	QVFLAG: 0	:FLAGS QUICK VERIFY PASS UNDER APT, ACT, OR XXDP CHAIN MODE
1239	002442	000000	ACTFLAG:0	:FLAGS ACT AUTOMATIC MODE PROGRAMMING RULES
1240	002444	000000	APTFLAG:0	:FLAGS APT AUTOMATIC MODE PROGRAMMING RULES
1241	002446	000000	XXDPCHAIN:0	:FLAGS XXDP CHAIN MODE PROGRAMMING RULES
1242			:NOTE: THESE TWO BYTES MUST STAY TOGETHER	
1243	002450	000	\$NULL: .BYTE 0	::CONTAINS NULL CHARACTER FOR FILLS
1244	002451	000	\$FILLS: .BYTE 0	:CONTAINS # OF FILL CHARACTERS
1245	002452	000	\$TPFLG: .BYTE 0	::'TERMINAL NOT AVAILABLE' FLAG
1246			.EVEN	
1247	002454	000000	\$ESCAPE:0	::ESCAPE ON ERROR ADDRESS
1248	002456	000000	EVEN: 0	:USED FOR ALTERNATE DATA PATTERNS
1249	002460	000000	STRIPES:0	:COUNTS DIAGONAL STRIPES
1250	002462	000000	COUNT: 0	:BACKED UP COPY OF STRIPES
1251	002464	000000	NOTAB: 0	:NO TABLE BEING PRINTED - NOW
1252	002466	000000	MJSIZE: 0	:SIZE OF MJ11 MEMORY IN K WORDS
1253	002470	000000	MKSIZE: 0	:SIZE OF MK11 MEMORY IN K WORDS
1254	002472	000000	TOOMANY:0	:FLAGS WHEN TOO MANY ERRORS HAVE BEEN PRINTED FOR A BANK
1255	002474	000000	NOECCFLAG:0	:ECC CAPABILITY DISABLED ON THE CONTROL PANEL
1256	002476	000000	GDSWITCH:0	:GOOD VALUE FOR SOME SWITCHES
1257	002500	000000	BDSWITCH:0	:BAD VALUE FOR SOME SWITCHES
1258	002502	000000	WRITEONLY:0	:FLAG TO PATTERNS TO WRITE ONLY
1259	002504	000000	READONLY:0	:FLAG TO PATTERNS TO READ ONLY
1260	002506	000000	TESTADD:0	:THE ADDRESS TO RUN CSR TESTS ON
1261	002510	000000	ALLCPUS:0	:CPUBIT'S FOR ALL CPU'S PRESENT
1262	002512	000000	HIBANK: 0	:HIGHEST BANK OF MEMORY
1263	002514	000000	HIACBANK:	:1ST INACCESSABLE BANK OF MEMORY
*1264	002516	000000	UNITOP: 0	:HIGHEST ACCESSABLE BANK OF MEMORY THRU UNIBUS MAP
1265	002520	000000	STOPOK: 0	:FLAG TO ALLOW STOPPING WITH SWITCH REGISTER
1266	002522	000000	APTCORE:0	:AMOUNT OF CORE MEMORY ACCORDING TO APT
1267	002524	000000	APTMO5: 0	:AMOUNT OF MOS MEMORY ACCORDING TO APT
1268	002526	000000	NOFSMODE:0	:FLAG TO DISABLE FIELD SERVICE MODE
1269	002530	000000	NOERROR:0	: 'THIS IS NOT AN ERROR' FLAG
1270	002532	000000	LOADBANK:0	:BANK LOADERS ARE RELOCATED TO
*1271	002534	000000	TEMP: 0	:USED FOR JUNK
1272	002536	000000	QUICK: 0	:QUICK STOP FLAG FOR APT POWER FAIL
1273	002540	000000	NOSCOPE:0	: 'NO SCOPE LOOP ALLOWED' FLAG

1274 002542 000000	FSINFLAG:0	;'FIELD SERVICE - NO INTERNAL INTERLEAVE'' FLAG
1275 002544 000000	APTSIZE:0	;APT SIZING INFO FLAG
1276 002546 000000	FS7FLAG:0	;TRUE WHEN IN FIELD SERVICE COMMAND 7
1277 002550 000000	K10: 0	;SAVED KIPAR0 TO PASS CORRECT VALUE TO SLAVE
1278 002552 000000	K11: 0	;SAVED KIPAR1 TO PASS CORRECT VALUE TO SLAVE
1279 002554 000000	K12: 0	;SAVED KIPAR2 TO PASS CORRECT VALUE TO SLAVE
1280 002556 000000	K13: 0	;SAVED KIPAR3 TO PASS CORRECT VALUE TO SLAVE
1281 002560 000000	K14: 0	;SAVED KIPAR4 TO PASS CORRECT VALUE TO SLAVE
1282 002562 000000	K15: 0	;SAVED KIPAR5 TO PASS CORRECT VALUE TO SLAVE
1283 002564 000000	K16: 0	;SAVED KIPAR6 TO PASS CORRECT VALUE TO SLAVE
1284 002566 000000	K17: 0	;SAVED KIPAR7 TO PASS CORRECT VALUE TO SLAVE
1285 002570 000000	SLAERROR:0	;SLAVE HAD AN ERROR FLAG
1286 002572 000000	HUNGMSB:0	;USED FOR TIMES OVER 13 SECONDS
1287 002574 000000	HUNGTIME:0	;TIME TO ALLOW THE SYSTEM TO BE HUNG (MAX 13. SEC)
1288 002576 000000	CONFERROR:0	;CONFIGURATION ERROR FLAG
1289 002600 000000	TWOCSRS:0	;TO FLAG LOADCSR TRAP TO LOAD TWO CSR'S
1290 002602 000000	I: 0	;USED FOR GENERAL PURPOSE INDEXING
1291 002604 000000	J: 0	;USED FOR GENERAL PURPOSE INDEXING

MULTIPORT VARIABLES

```

1294
1295
1296
1297
1298
1299
1300 002606 000000 000000 000000 PORTDIR: .WORD 0,0,0,0
      002614 000000
1301 002616 000000 000000 000000 TASK: .WORD 0,0,0,0
      002624 000000
1302 002626 000000 000000 000000 PTYFLAG: .WORD 0,0,0,0
      002634 000000
1303 002636 000000 000000 000000 PTYBUF: .WORD 0,0,0,0
      002644 000000
1304 002646 000000 000000 000000 PORTCOUNT: .WORD 0,0,0,0
      002654 000000
1305 002656 000000 000000 000000 SLFLAG: .WORD 0,0,0,0
      002664 000000
1306 002666 000000 MINDEX: 0 ;MASTER CPU'S INDEX # TO TABLES ABOVE
1307 002670 000000 LOCK: 0 ;MULTIPROCESSOR LOCK
1308 002672 000000 ACK: 0 ;ACKNOWLEDGE FLAG (USED FOR STARTING SLAVES)
1309 002674 000000 MASWR: 0 ;MASTER'S SWR
1310 002676 000000 MDISPLAY: 0 ;MASTER CPU DISPLAY WHEN RUNNING MULTIPROCESSOR TESTS
1311 002700 $CMTGE: ;*END OF COMMON TAGS

```

SBTTL MULTIPORT VARIABLES

;MULTIPORT DIRECTORY

;PORTDIR: MASTER IIST ID NUMBER OR SYSTEM ID NUMBER IF IIST DISABLED BY OPERATOR

; SLAVE IIST ID NUMBER OR SYSTEM ID NUMBER IF IIST DISABLED BY OPERATOR

; SLAVE IIST ID NUMBER OR SYSTEM ID NUMBER IF IIST DISABLED BY OPERATOR

; SLAVE IIST ID NUMBER OR SYSTEM ID NUMBER IF IIST DISABLED BY OPERATOR

```

1314                                     .SBTTL  VARIABLES  INITIALIZED TO NON ZERO
1315 002700 000001  CACHK: 1 ;CACHE CONSTANT (MOVED TO CONTRL TO TURN ON CACHE)
1316 002702 000012  ERRMAX: 10. ;MAX # OF ERRORS PER BANK WITH SW11
1317 002704 000031  SOBK: 25. ;SOB CONSTANT
1318 002706 002000  KSTACK: STACK ;STACK BEGINNING (USED TO KEEP SLAVES STACKS SEGREGATED)
1319 002710 000001  LOADHOME:1 ;HOME BANK OF LOADERS
1320 002712 177777  WORST: 177777 ;SET IF TESTING BANKS IN WORST FIRST MODE(1ST PASS)
1321 002714 176543  SEEDHI: 176543 ;WORKING SEED HI (USED FOR RANDOM NUMBER GENERATOR)
1322 002716 123456  SEEDLO: 123456 ;WORKING SEED LO (USED FOR RANDOM NUMBER GENERATOR)
1323 002720 176543  MSEEDH: 176543 ;MASTER SEED HI (USED FOR RANDOM NUMBER GENERATOR)
1324 002722 123456  MSEEDL: 123456 ;MASTER SEED LO (USED FOR RANDOM NUMBER GENERATOR)
1325 002724 177777  HEADER: 177777 ;USED TO PRINT HEADINGS ONLY ONCE
1326 002726 177777  ONES: 177777 ;FOR AID IN 'MOV' INSTRUCTIONS
1327 002730 000000  SLAVES: 0 ;# OF SLAVE CPU'S
1328 002732 000000  ONCE: 0 ;FLAG FOR TYPING TITLE ONLY ONCE
1329 002734 000003  FLIPLOC:3 ;COUNTER FOR FLIPING DATA ON WORST CASE NOISE TEST
1330 002736 177500  IISTACR:177500 ;ADDRESS OF THE IIST ACR (WAS 166000)
1331 002740 177502  IISTADR:177502 ;ADDRESS OF THE IIST ADR (WAS 166002)
1332 002742 000260  IISTVEC:260 ;ADDRESS OF THE IIST VECTOR (WAS 170)
1333 002744 052525  SOFTPAT:52525 ;PATTERN FOR SOFT ERROR BACKGROUND TESTS
1334 002746 000000  $LPADR: .WORD 0 ;CONTAINS SCOPE LOOP ADDRESS
1335 002750 000000  $LPERR: .WORD 0 ;CONTAINS SCOPE RETURN FOR ERRORS
1336 002752 000000  RESTART:0 ;RESTART (START ADD 202) FLAG
1337 002754 000000  $ERTTL: .WORD 0 ;CONTAINS TOTAL ERRORS
1338 002756 000000  NOIIST: 0 ;NO IIST IS TO BE USED DURING MULTIPOST TESTS
1339 002760 000000  PWLOCK: 0 ;MULTIPROCESSOR LOCK FOR POWER FAILURE
1340
1341 ;***** NOTE THESE TWO LOCATIONS MUST STAY TOGETHER *****
1342 002762 000377  BAKPAT: .WORD 377 ;BACKGROUND PATTERN *
1343 002764 177400  SWAPAT: .WORD 177400 ;SWAPPED BAKPAT *
1344 ;*****
1345
1346 002766 177570  SWR: .WORD DSWR ;:ADDRESS OF SWITCH REGISTER
1347 002770 177570  DISPLAY: .WORD DDISP ;:ADDRESS OF DISPLAY REGISTER
1348 002772 177560  $TKS: 177560 ;:TTY KBD STATUS
1349 002774 177562  $TKB: 177562 ;:TTY KBD BUFFER
1350 002776 177564  $TPS: 177564 ;:TTY PRINTER STATUS REG. ADDRESS
1351 003000 177566  $TPB: 177566 ;:TTY PRINTER BUFFER REG. ADDRESS
1352 003002 012 $FILLC: .BYTE 12 ;:INSERT FILL CHARS. AFTER A 'LINE FEED''
1353 003003 207 377 377 $BELL: .ASCIIZ <207><377><377> ;:CODE FOR BELL
1354 003006 000
1354 003007 077 $QUES: .ASCII /?/ ;:QUESTION MARK
1355 003010 015 $CRLF: .ASCII <15> ;:CARRIAGE RETURN
1356 003011 012 000 $LF: .ASCIIZ <12> ;:LINE FEED
1357 .EVEN
1358 003014 000000  MULTIPOST:0 ;MULTIPROCESSING FLAG
    
```

1361
 1362
 1363
 1364
 1365
 1366
 1367
 1368
 1369
 1370
 1371
 1372
 1373
 1374
 1375
 1376
 1377
 1378
 1379
 1380
 1381
 1382
 1383
 1384
 1385
 1386
 1387
 1388
 1389
 1390
 1391
 1392
 1393
 1394
 1395
 1398
 1399
 1400

```

.SBTTL CONFIGURATION TABLE
:CONFIG:FIRST 16K CONFIGURATION WORDS (3 EACH)
      2ND 16K CONFIGURATION WORDS (3 EACH)
      16TH 16K CONFIGURATION WORDS (3 EACH)
:CONFIGURATION WORDS:
      LOW:  BIT 0-2  INTERLEAVE FACTOR
            BIT 3  EXTERNAL INTERLEAVE
            BIT 4  MASTER CAN ACCESS (MEMORY EXISTS)
            BIT 5  SLAVE #1 CAN ACCESS (SHARED)
            BIT 6  SLAVE #2 CAN ACCESS (SHARED)
            BIT 7  SLAVE #3 CAN ACCESS (SHARED)
            BIT 8-10 BOX NUMBER (0-7)
            BIT 11  ERRORS PRESENT
            BIT 12  PROTECTED REGION OF A MK11 BOX
            BIT 13-14 MEMORY TYPE; 0=MJ11; 1=MK11
            BIT 15  PROTECTED (PROGRAM SPACE)
      MED:  BIT 0-5  NOT USED
            BIT 6-8  MK11 CSR ADDRESS
            BIT 9-11 NOT USED
            BIT 12  INTERNAL INTERLEAVE
            BIT 13  'BACKGROUND PATTERN VALID' FLAG
            BIT 14  BANK SELECTED FOR TEST BY FIELD SERVICE MODE
            BIT 15  LOADERS HOME BANK
      HIGH: BIT 0  INDICATES BANK IS ADDRESSED BY CSR 172100
            BIT 1  INDICATES BANK IS ADDRESSED BY CSR 172104
            BIT 2  INDICATES BANK IS ADDRESSED BY CSR 172110
            BIT 3  INDICATES BANK IS ADDRESSED BY CSR 172114
            BIT 4  INDICATES BANK IS ADDRESSED BY CSR 172120
            BIT 5  INDICATES BANK IS ADDRESSED BY CSR 172124
            BIT 6  INDICATES BANK IS ADDRESSED BY CSR 172130
            BIT 7  INDICATES BANK IS ADDRESSED BY CSR 172134
            BIT 8-15 NUMBER OF ERRORS
CONFIG: .REPT 170
CONF IEND .WORD 0,0,0,0,0,0 ;THESE WORDS SHOULD NEVER GET WRITTEN INTO
;IF THEY DO THE PROGRAM IS OVERFLOWING IT'S
;CONFIGURATION TABLE (SOFTWARE BUG)
    
```

```

003016 000170
004336 000000 000000 000000
004344 000000 000000 000000
    
```



```

1402          .SBTTL ***** MAIN *****
1403 004352  START: SUBTST <<INITIALIZE VARIABLES TO ZERO>>
:*****
:*SUBTEST    INITIALIZE VARIABLES TO ZERO
:*****
1404 004352          SET    ACK          ;ACKNOWLEDGE THAT I HAVE STARTED (IN CASE I'M A SLAVE)
1405 004360 000005  RESET
1406 004362 013706 002706  MOV    KSTACK,SP          ;;SETUP THE STACK POINTER
1407 004366          IF MULTIPORT EQ ONES AND CPUBIT NE #MASTER
1408          ;WAIT FOR ACK TO CLEAR OR TIMEOUT & HALT
1409 004406 005004          CLR R4
1410 004410 1$:          IF ACK IS TRUE
1411 004416          SOB R4,1$
1412 004420 000000  SHALT:    HALT          ;THE MASTER WOULD NOT ALLOW THIS SLAVE TO PROCEED
1413 004422          END ;OF IF ACK IS TRUE
1414 004422 000137 005752  JMP BEGIN
1415 004426          END ;OF IF MULTIPORT
1416 004426 012700 002000  MOV    #SCMTAG,R0          ;;FIRST LOCATION TO BE CLEARED
1417 004432 005020 1$:          CLR    (R0)+          ;;CLEAR MEMORY LOCATION
1418 004434 022700 002700  CMP    #SCMTGE,R0          ;;DONE?
1419 004440 001374          BNE    1$          ;LOOP BACK IF NO
1420 004442          SUBTST <<CLEAR NON-PROGRAM SPACE>>
:*****
:*SUBTEST    CLEAR NON-PROGRAM SPACE
:*****
1421          ;THIS ATTEMPS TO GET RID OF ANY PARITY ERRORS BY WRITING INTO
1422          ;EVERY LOCATION THAT IS NOT LOADED INTO BY THE PROGRAM OR ALLOCATED
1423          ;TO THE XXDP LOADERS
1424 004442 012737 000004 002100  MOV    #4,NOPAR          ;PARITY ACTION = COUNT & IGNORE
1425 004450 012700 001000          MOV    #1000,R0
1426 004454 012737 000015 177746  MOV    #15,CONTRL          ;DISABLE CACHE & ABORTS
1427 004462 012720 000000          MOV    #0,(R0)+          ;CLEAR THE STACK AREA
1428 004466 020027 002000 9$:    CMP    R0,#STACK
1429 004472 103773          BLO    9$
1430 004474 012700 117146          MOV    #END+2,R0
1431 004500 012720 000000 8$:    MOV    #0,(R0)+          ;CLEAR FROM THE END OF THE PROGRAM TO THE XXDP LOADE
1432 004504 020027 137776          CMP    R0,#157776-3192.
1433 004510 103773          BLO    8$
1434 004512 005037 002100          CLR    NOPAR          ;RESTORE DEFAULT PARITY ACTION
1435          ;
1436 004516 005237 002670          INC    LOCK          ;ONLY ALLOW ONE CPU AT A TIME TO GO THRU HERE
1437 004522          IF LOCK NE #1
1438 004532 000000  MHALT1:  HALT          ;MULTIPLE MASTER CPU'S ARE RUNNING
1439 004534 000776          BR    MHALT1
1440 004536          END ;OF IF LOCK
    
```

1443 004536

SUBTST <<INITIALIZE VARIABLES TO NON ZERO>>

: *SUBTEST INITIALIZE VARIABLES TO NON ZERO

1444 004536
 1445 004544 012737 000003 002734
 1446 004552
 1447 004560 012737 176543 002720
 1448 004566 012737 123456 002722
 1449 004574 013737 002720 002714
 1450 004602 013737 002722 002716
 1451 004610 012737 000377 002762
 1452 004616 012737 177400 002764
 1453 004624 012737 052525 002744
 1454 004632 012737 005752 002746
 1455 004640 012737 005752 002750
 1456 004646

SET WORST
 MOV #3,FLIPLOC
 SET HEADER
 MOV #176543,MSEEDH
 MOV #123456,MSEEDL
 MOV MSEEDH,SEEDHI ;PRIME THE RANDOM NUMBER GENERATOR
 MOV MSEEDL,SEEDLO ;BOTH HIGH AND LOW WORDS
 MOV #377,BAKPAT
 MOV #177400,SWAPAT
 MOV #52525,SOFPAT
 MOV #BEGIN,\$LPADR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
 MOV #BEGIN,\$LPERR ;;SETUP THE ERROR LOOP ADDRESS
 SUBTST <<INITIALIZE VECTORS>>

: *SUBTEST INITIALIZE VECTORS

1457 004646 012737 066232 000020
 1458 004654 012737 000340 000022
 1459 004662 012737 066662 000030
 1460 004670 012737 000340 000032
 1461 004676 012737 075252 000034
 1462 004704 012737 000340 000036
 1463 004712 012737 055160 000024
 1464 004720 012737 000340 000026
 1465 004726 012737 036454 000114
 1466 004734 012737 000340 000116
 1467 004742 012737 036752 000010
 1468 004750 012737 000340 000012
 1469 004756 012737 036726 000004
 1470 004764 012737 000340 000006
 1471 004772 012737 036740 000250
 1472 005000 012737 000340 000252
 1473 005006 012737 036764 000170
 1474 005014 012737 000340 000172
 1475 005022 104423

MOV #SCOPE,IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
 MOV #340,IOTVEC+2 ;;LEVEL 7
 MOV #ERROR,EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
 MOV #340,EMTVEC+2 ;;LEVEL 7
 MOV #STRAP,TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
 MOV #340,TRAPVEC+2;LEVEL 7
 MOV #SPWRDN,PRVVEC ;;POWER FAILURE VECTOR
 MOV #340,PRVVEC+2 ;;LEVEL 7
 MOV #PARITY,PARVEC;GET READY FOR PARITY ERRORS
 MOV #340,PARVEC+2
 MOV #PDP1105,RESVEC;RESERVED INSTRUCTION TRAP
 MOV #340,RESVEC+2
 MOV #TIMEOUT,ERRVEC;SETUP TIMEOUT ERRORS
 MOV #340,ERRVEC+2 ;SET PRIORITY OF ERROR TRAPS
 MOV #MMTRAP,MMVEC ;VECTOR FOR MEMORY MANAGEMENT
 MOV #340,MMVEC+2
 MOV #IITRAP,170 ;SET UP FOR UNEXPECTED IIST TRAPS
 MOV #340,172
 CACHON ;TURN CACHE ON

1479 005024

SUBTST <<CLEAR THE CONFIGURATION TABLE>>

: *SUBTEST CLEAR THE CONFIGURATION TABLE

1480

: THIS ZEROS (UNLESS WE STARTED AT ADDRESS 202) THE CONFIG TABLE
: WHICH IS FULLY DISCRIBED AT LOCATION 'CONFIG'.

1481

.ENABLE LSB

1482

IF RESTART IS FALSE

1483 005024

MOV #CONFIG,RO

1484 005032 012700 003016

1\$: CLR (RO)+

1485 005036 005020

CMP #CONFIEND,RO

1486 005040 022700 004336

BNE 1\$

1487 005044 001374

END ;OF IF RESTART

1488 005046

.DSABL LSB

1489

MOV #MASTER,CPUBIT ;SET ID BIT

1490 005046 012737 000020 002114

SUBTST <<SIZE FOR A HARDWARE SWITCH REGISTER>>

1491 005054

: *SUBTEST SIZE FOR A HARDWARE SWITCH REGISTER

1492

:: IF NOT FOUND OR IT IS

1493

:: EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.

1494

.ENABL LSB

1495 005054

SET4 #3\$;TRAPS TO 4 GOTO 3\$

1496 005062 012737 177570 002766

MOV #DSWR,SWR ;:SETUP FOR A HARDWARE SWITCH REGISTER

1497 005070 012737 177570 002770

MOV #DDISP,DISPLAY ;:AND A HARDWARE DISPLAY REGISTER

1498 005076

IF #-1 EQ @SWR ;:IF NO TRAP FROM REFERENCE TO @SWR AND @SWR #-1

1499 005106 000403

BR 2\$;:BRANCH IF NO TIMEOUT

1500 005110 012716 005116

3\$: MOV #2\$, (SP) ;:SET UP FOR TRAP RETURN

1501 005114 000002

2\$: RES4 ;:RESET TRAPS TO 4 TO DEFAULT

1503 005130 012737 000176 002766

MOV #SWREG,SWR ;:POINT TO SOFTWARE SWR

1504 005136 012737 000174 002770

MOV #DISPREG,DISPLAY

1505 005144

END ;OF IF #-1

1506

.DSABL LSB

1507

SUBTST <<FIND OUT IF ANY LINE CLOCK IS PRESENT>>

1508 005144

: *SUBTEST FIND OUT IF ANY LINE CLOCK IS PRESENT

1509 005144

SET4 #4\$

1510 005152 005737 177546

TST LKS

1511 005156 000403

BR 5\$;:IF NO TRAP SKIP

1512 005160

4\$: SET NOCLOCK ;:SET NO LINE CLOCK FLAG

1513 005166

5\$: RES4 ;:RESTORE TRAPS TO 4 TO DEFAULT

1516 005200

SUBAAB: SUBTST <<SETUP ACT, APT, & XXDP>>

:*****
:*SUBTEST SETUP ACT, APT, & XXDP
:*****

1517

: THIS SETS UP A BUNCH OF FLAGS TO TELL THE PROGRAM EVERYTHING

1518

: IT CARES TO KNOW ABOUT APT, ACT, & XXDP.

1519 005200 005037 075142

CLR \$PASS ; CLEAR PASS COUNT

1520 005204

IFB #BITS SET. IN \$ENVM

1521 005214

SET \$TFPLG ; INDICATE NO TERMINAL

1522 005222

END ; OF IFB #BITS

1523 005222

IFB #BIT7 SET. IN \$ENVM

1524 005232

SET APTSIZE

1525 005240 012737 075156 002766

MOV #\$\$SWREG, SWR ; USE APT SWR

1526 005246

END ; OF IFB #BIT7

1527 005246

IFB \$ENV EQ #1

1528 005256

SET APTFLAG, QVFLAG, \$AUTO, QUICK

1529 005306 012737 043640 000024

MOV #APTDOWN, PWRVEC

1530 005314

ELSE

1531 005316

IF 42 NE #STACK AND 42 NE #0

1532 005334

SET QVFLAG, \$AUTO

1533 005350

IF 42 EQ #SENDAD

1534 005360

SET ACTFLAG

1535 005366

ELSE

1536 005370

SET XXDPCHAIN

1537 005376

END ; OF IF 42

1538 005376

END ; OF IF 42

1539 005376

END ; OF IFB \$ENV

1542 005376

SUBTST <<INITIALIZE PATTERNS>>

```

*****
: *SUBTEST      INITIALIZE PATTERNS
*****
    
```

1543
 1544
 1545
 1546
 1547 005376
 1548 005404 012700 075220
 1549 005410 012001
 1550 005412 012703 020124
 1551 005416 004737 005472
 1552 005422 012001
 1553 005424 004737 005472
 1554 005430 012001
 1555 005432 012703 021402
 1556 005436 004737 005472
 1557 005442 012001
 1558 005444 004737 005472
 1559 005450 012001
 1560 005452 012703 021600
 1561 005456 004737 005472
 1562 005462 012001
 1563 005464 004737 005472
 1564 005470
 1565 005470 000420
 1566
 1567 005472

```

; THE APT E-TABLE DETERMINES WHICH PATTERNS ARE GOING TO BE RUN.
; EACH BIT SET REPRESENTS A PATTERN TABLE ENTRY THAT IS TO BE LEFT
; ALONE (TO BE RUN). EACH BIT CLEARED REPRESENTS A PATTERN TABLE ENTRY
; THAT IS TO BE OVERLAYED WITH THE ADDRESS OF A NULL PATTERN.
IF APTFLAG IS TRUE
    MOV  #DDWO,R0
    MOV  (R0)+,R1
    MOV  #MKCSRT,R3
    CALL PATPLUG
    MOV  (R0)+,R1
    CALL PATPLUG
    MOV  (R0)+,R1
    MOV  #MKPAT,R3
    CALL PATPLUG
    MOV  (R0)+,R1
    CALL PATPLUG
    MOV  #MJPAT,R3
    CALL PATPLUG
    MOV  (R0)+,R1
    CALL PATPLUG
END ;OF IF APTFLAG IS TRUE
BR     SUBAAA
    
```

PATPLUG:SUBTST <<SUBR PLUG IN NULL PATTERNS>>

```

*****
: *SUBTEST      SUBR      PLUG IN NULL PATTERNS
*****
    
```

1568 005472
 1569 005500 006001
 1570 005502
 1571 005504 012713 025772
 1572 005510
 1573 005510 062703 000002
 1574 005514
 1575 005530 000207

```

FOR I := #1 TO #16.
    ROR  R1
    ON.NOERROR      ;IF CARRY CLEAR
        MOV #MT0999,(R3)
    END ;OF ON.ERROR
    ADD #2,R3
END ;OF FOR
RETURN
    
```

```

1578 005532          SUBAAA: SUBST  <<PROTECT PROGRAM & LOADERS>>
:*****
:*SUBTEST          PROTECT PROGRAM & LOADERS
:*****
1579 005532 052737 100000 003016      BIS  #BIT15,CONFIG          ;PROTECT PROGRAM SPACE (BANK 0)
1580 005540 052737 000000 003024      BIS  #BIT15,CONFIG+6       ;PROTECT LOADER SPACE (BANK 1)
1581 005546                                     IF #SENDAD NE 42 AND ONCE IS FALSE ;NOT ACT-11 AND NOT DONE ONCE?
1582 005564                                     TYPE MSG000                ;TYPE PROGRAM TITLE
1583 005570                                     END ;OF IF #SENDAD
1584 005570          SUBST  <<MULTIPOINT DETERMINATION ROUTINE>>
:*****
:*SUBTEST          MULTIPOINT DETERMINATION ROUTINE
:*****
1585                                     :DETERMINE
1586                                     :1. IF WE ARE MULTIPROCESSING
1587                                     :2. IF WE CAN USE THE IIST INTERFACE
1588                                     :3. EACH CPU'S ID (IIST NUMBER OR SYSTEM ID REGISTER)
1589                                     .ENABL LSB
1590 005570          IF NOIIST IS TRUE
1591 005576          IF ONCE IS FALSE
1592 005604          1$: TYPE      MSG080          ;ENTER # OF SLAVE CPU'S (0-3)?
1593 005610          104413          RDOCT          ;READ AN OCTAL NUMBER ONTO THE STACK
1594 005612          POP SLAVES
1595 005616          END ;OF IF ONCE
1596 005616          IF SLAVES LT #0 OR SLAVES GT #3
1597 005634          000763          BR 1$
1598 005636          END ;OF IF SLAVES
1599 005636          IF SLAVES EQ #0 THEN GOTO 2$
1600 005644          013737 177764 002606      MOV  SYSTID,PORTDIR
1601 005652          ELSE
1602 005654          SET4  #2$          ;TRAPS TO 4 GOTO 2$
1603 005662          012777 100000 175046      MOV  #BIT15,@IISTACR      ;IS THERE AN IIST?
1604 005670          017700 175042          MOV  @IISTACR,R0          ;YES - GET ID
1605 005674          072027 177770          ASH  #-8,R0
1606 005700          042700 177774          BIC  #^C3,R0
1607 005704          010037 002606          MOV  R0,PORTDIR          ;IDENTIFY MASTER
1608 005710          005777 175024          TST  @IISTADR            ;SEE IF 2ND IIST REGISTER TRAPS
1609 005714          END ;OF IF NOIIST
1610 005714          SET  MULTIPOINT          ;MULTIPOINTING!
1611 005722          013706 002706          2$: MOV  KSTACK,SP
1612 005726          RES4          ;RESET TRAPS TO 4 TO DEFAULT
1613 005740          SET  ONCE
1614 005746          005037 002670          CLR  LOCK
1615                                     .DSABL LSB
    
```

16'8 005752

1619 005752 000240
1620 005754 005237 002670
1621 005760
1622 005770 000000
1623 005772 000776
1624 005774
1625 005774
1626 006004 004737 061244
1627 006010

```
BEGIN: SUBTST <<SLAVES START HERE>>  
:.....  
:*SUBTEST SLAVES START HERE  
:.....  
NOP  
INC LOCK ; ONLY ONE CPU AT A TIME IS ALLOWED HERE  
IF LOCK NE #1  
MHALT2: HALT ; MULTIPLE CPU'S EXECUTING SAME CODE  
BR MHALT2  
END ; OF IF LOCK  
IF CPUBIT NE #MASTER ; IF I'M A SLAVE  
CALL SLAVEMAP  
END ; OF IF CPUBIT
```

1630 006010

```

SUBTST <<DETERMINE MK11 ACCESS METHOD>>
:*****
:*SUBTEST DETERMINE MK11 ACCESS METHOD
:*****
;DETERMINE HOW WE ACCESS THE MK11 CSR'S.
;IF I CAN'T ACCESS THE CSR'S NORMALLY THEN I ASSUME THAT I MUST
;RELOCATE THRU THE UNIBUS MAP SO I SET THE "CSR'S RELOCATED" FLAG (CSRREL)
;NOTE: I DON'T REALLY KNOW AT THIS POINT IF THERE IS ANY MK11 MEMORY YET
; I ONLY DETERMINE HOW I WILL HAVE TO ACCESS IT IF THERE IS ANY'
SET4 #5$ ;TRAPS TO 4 GOTO 5$
MOV #8,R0 ;TEST FOR 8 CSR'S
MOV #MK11ADD,R2 ;R2 = CSR ADDRESS
4$: TST (R2) ;ANSWER R0 TRAP
CLR CSRREL ;ANSWER - CSR'S NOT RELOCATED
BR 6$ ;BRANCH - OUT
5$: ADD #4,SP ;FIX STACK FROM TRAP
ADD #4,R2 ;NEXT CSR = LAST CSR + 4
SOB R0,4$ ;LOOP TILL DONE
SET CSRREL
6$: RES4 ;RESET TRAPS TO 4 TO DEFAULT
SUBTST <<SETUP USER & SUPERVISOR STACK>>

```

1631
1632
1633
1634
1635
1636 006010
1637 006016 012700 000010
1638 006022 012702 172100
1639 006026 005712
1640 006030 005037 002254
1641 006034 000410
1642 006036 062706 000004
1643 006042 062702 000004
1644 006046 077011
1645 006050
1646 006056
1647 006070

```

:*****
:*SUBTEST SETUP USER & SUPERVISOR STACK
:*****
DEENERGIZE ;TURN OFF MEMORY MANAGEMENT
;SET PREVIOUS MODE TO SUPERVISOR
BIC #BIT13:BIT12,PSW
BIS #BIT12,PSW
PUSH #SUPSTK
MTP! SSP
;SET PREVIOUS MODE TO USER
BIS #BIT13:BIT12,PSW
PUSH #USESTK
MTP! USP

```

1648 006070 104421
1649
1650
1651 006072 042737 030000 177776
1652 006100 052737 010000 177776
1653
1654 006106
1655 006112 006606
1656
1657
1658 006114 052737 030000 177776
1659
1660 006122
1661 006126 006606


```
1664 006150          SUBTST <<GET SOFTWARE SWITCH REGISTER IF NECESSARY>>
:*****
:*SUBTEST          GET SOFTWARE SWITCH REGISTER IF NECESSARY
:*****
1665 006130          IF CPUBIT EQ #MASTER AND SAUTO IS FALSE ;IF MASTER & NOT (APT OR ACT)
1666 006146          IF SWR EQ #SWREG ;IF SOFTWARE SWITCH REG SELECTED
1667 006156 104407   GTSWR ;;GET SOFT-SWR SETTINGS
1668 006160          END ;OF IF SWR
1669 006160          END ;OF IF CPUBIT
1670
1671 006160 012737 000020 172516  MOV #20,MMR3 ;SET 22 BIT MODE
1672 006166 005037 177750  CLR MAINT ;CLEAR MARGINS
1673
1674 006172          SUBTST <<SETUP UNIBUS MAP>>
:*****
:*SUBTEST          SETUP UNIBUS MAP
:*****
1675 006172 012737 000077 170372  MOV #77,MAPH36 ;MAP36 IS USED TO ACCESS MK11 CSR'S ON PDP11-70'S
1676 006200 012737 160000 170370  MOV #160000,MAPL36 ;THAT DO NOT HAVE THE MULTIPROCESSOR MODIFICATIONS.
1677 006206          CLEAR MAPH0,MAPL0 ;MAP0 IS USED FOR APT TO LOOK AT THE MAILBOX THRU.
1678 006216 004737 042026          CALL LOWMAP ;SETUP LOWER UNIBUS MAP
1679 006222 052737 000040 172516  BIS #BITS,MMR3 ;ENERGIZE UNIBUS MAP
1680
1681 006230          SUBTST <<GET MEMORY MANAGEMENT READY>>
:*****
:*SUBTEST          GET MEMORY MANAGEMENT READY
:*****
1682 006230          IF CPUBIT EQ #MASTER
1683 006240 104422   KMAP ;MAP KERNEL SPACE 1 TO 1
1684 006242          END ;OF IF CPUBIT
1685 006242          MAP ;MAP SUPERVISOR SPACE (TEST AREA) 1 TO 1
1686 006256 104420   ENERGIZE ;TURN ON MEMORY MANAGEMENT
```

1689 006260

NEWTST <<ANALIZE CONFIGURATION>>

 :*TEST 1 ANALIZE CONFIGURATION

006260 000004
 1690
 1691
 1692
 1693
 1694
 1695
 1696
 1697
 1698
 1699
 1700
 1701
 1702
 1703 006262 005037 002256
 1704 006266
 1705 006272
 1706 006300 010637 006754
 1707 006304 006337 002334
 1708 006310 006337 002330
 1709 006314 104426
 1710 006316 052737 000001 002334
 1711 006324 005001
 1712 006326 013700 002146
 1713 006332 072027 177765
 1714 006336 042700 177770
 1715 006342
 1716 006356
 1717 006366 006756
 1718 006370 006760
 1719 006372 006760
 1720 006374 006766
 1721 006376 006766
 1722 006400 006774
 1723 006402 006766
 1724 006404 006774
 1725 006406
 1726 006414 010137 002264
 1727 006420 004737 017736
 1728
 1729 006424 013701 002256
 1730 006430 006201
 1731 006432 013761 002144 002154
 1732 006440 013761 002146 002174
 1733 006446 013761 002260 002214
 1734 006454
 1735 006464 052737 000001 002330
 1736 006472 000137 006712
 1737 006476
 1738 006476 013761 002262 002234
 1739 006504 013701 002260
 1740 006510 070127 000006
 1741 006514 010137 002110

```

TST1: SCOPE
:THIS CODE DOES THE FOLLOWING FOR MK11 CSR'S
:1. FINDS ANY EXISTING CSR'S - SETTING BITS IN LOC 'MKCSRS' FOR
:   EACH ONE PRESENT.
:2. SETS A BIT IN LOC 'MKCSRS' FOR ANY MK11 THAT IS INTERNALLY INTERLEAVED
:3. DETERMINES THE INTERLEAVE FACTOR & STARTING ADDRESS. USING THIS
:   WE DETERMINE THE FIRST & LAST BANK INCLUDED IN THIS CSR. USING THAT
:   THE CONFIGURATION TABLE IS UPDATED TO
:   A. IDENTIFY BANKS WITHIN THE RANGE AS MK11 MEMORY.
:   B. IDENTIFY BANKS WITHIN THE RANGE WITH INTERLEAVE FACTOR.
:   C. IF NO EXTERNAL INTERLEAVE IDENTIFY BANKS WITHIN THE RANGE
:   AS CONTROLLED BY THIS CSR
:   D. IDENTIFY BANKS WITHIN THE RANGE BY A SPECIFIC BIT POSITION
:   FOR THIS CSR
CLR   CSRNO           ;1ST CSR IS 0
PUSH  CONTRL         ;SAVE CACHE STATUS
SET4  #CONFGT        ;TRAPS TO 4 GOTO CONFGT
MOV   SP,CONFGT      ;SAVE STACK
CONFG1: ASL   MKCSRS
ASL   PENDBOX
READCSR           ;TRAP IF IT DOES NOT EXIST
BIS   #1,MKCSRS    ;MARK CSR AS PRESENT
CLR   R1
MOV   CSR+2,R0
ASH   #-11,R0
BIC   #^C7,R0
IF #BIT0 SET.IN R0 THEN LET MKCSRS := MKCSRS SET.BY #BIT8
CASE R0
  INTER0
  INTER1
  INTER2
  INTER3
  INTER4
  INTER5
  INTER6
  INTER7
END ;OF CASE R0
MOV   R1,INTERL     ;SET INTERLEAVE FACTOR
CALL  GETSIZE
:THE NEXT 6 LINES SAVE THE READ STATUS OF THE BOX CAPACITY
MOV   CSRNO,R1
ASR   R1
MOV   CSR,CSR0(R1)
MOV   CSR+2,CSR2(R1)
MOV   FIRSTB,CSRFB(R1)
IF FIRSTB GT #167
  BIS #BIT0,PENDBOX
  JMP  CONFG5
END ;OF IF FIRSTB
MOV   LASTB,CSRLB(R1)
MOV   FIRSTB,R1
MUL   #6,R1         ;R1  BANK * 6
MOV   R1,BANKINDEX
    
```

```

ANALIZE CONFIGURATION

1742 006520 013701 002110          CONFIG3: MOV     BANKINDEX,R1          ;GET NEXT INDEX (SAME FIRST TIME)
1743 006524 053761 002264 003016    BIS     INTERL,CONFIG(R1)          ;SETUP INTERLEAVE BITS
1744 006532 052761 020000 003016    BIS     #BIT13,CONFIG(R1)          ;IDENTIFY AS MK11
1745 006540 042761 040000 003016    BIC     #BIT14,CONFIG(R1)
1746 006546                          IF #BIT8 SET.IN MKCSRS
1747 006556 052761 010000 003020    BIS     #BIT12,CONFIG+2(R1)
1748 006564                          END ;OF IF #BIT8
1749 006564 013700 002256                          MOV     CSRNO,R0                    ;GET CSR LSB'S
1750 006570 072027 177776                          ASH     #2,R0                       ;MAKE (0-7)
1751 006574                          IF #BIT13!BIT12 SET.IN CSR+2      ;ANY EXTERNAL INTERLEAVE?
1752 006604 052761 000010 003016    BIS     #BIT3,CONFIG(R1)          ;IDENTIFY IT
1753 006612                          ELSE
1754 006614                          PUSH    R0
1755 006616 072027 000010                          ASH     #8,R0                       ;MOVE TO BITS 10-8
1756 006622 050061 003016                          BIS     R0,CONFIG(R1)              ;IDENTIFY AS CSR & BOX NUMBER
1757 006626                          POP     R0
1758 006630                          END ;OF IF #BIT13!BIT12
1759 006630 012702 000001                          MOV     #1,R2
1760 006634 072200                          ASH     R0,R2                       ;R2 = 1,2,4,10,20,40,100, OR 200
1761 006636 050261 003022                          BIS     R2,CONFIG+4(R1)            ;SETUP CSR WORD
1762 006642 062737 000006 002110    ADD     #6,BANKINDEX                ;NEXT TABLE ENTRY
1763 006650 005237 002260                          INC     FIRSTB
1764 006654 023737 002260 002262    CMP     FIRSTB,LASTB                ;DONE?
1765 006662 101716                          BLOS   CONFIG3                     ;NO - LOOP
1766 006664 000412                          BR     CONFIG5
1767 006666 013706 006754          CONFIG4: MOV     CONFSP,SP           ;FIX STACK FROM MULTIPLE TRAP
1768 006672                          IF #BIT4 OFF.IN CPUERR
1769 006702                          LET GOOD := #BIT4
1770 006710 104037                          ERROR +37
1771 006712                          END ;OF IF CPUERR
1772 006712 062737 000004 002256    CONFIG5: ADD     #4,CSRNO             ;BUMP CSR
1773 006720                          IF CSRNO NE #40 THEN JUMPTO CONFIG1
1774 006734                          RES4
1775 006746                          POP     CONTRL                      ;RESET TRAPS TO 4 TO DEFAULT
1776 006752 000413                          BR     SUBAAS                        ;RESTORE CACHE STATUS
1777 006754 000000          CONFIGSP: 0                          ;STACK SAVED HERE!
1778
1779                          ;TOTAL INTERLEAVE (0, 2-1, 4-1, OR 8-1)
1780 006756 000207          INTER0: RETURN                       ;NO INTERLEAVE
1781
1782 006760          INTER1:
1783 006760 012701 000001          INTER2: MOV     #1,R1                 ;2 WAY INTERLEAVE
1784 006764 000207          RETURN
1785
1786 006766          INTER3:
1787 006766          INTER4:
1788 006766 012701 000002          INTER6: MOV     #2,R1                 ;4 WAY INTERLEAVE
1789 006772 000207          RETURN
1790
1791 006774          INTER5:
1792 006774 012701 000004          INTER7: MOV     #4,R1                 ;8 WAY INTERLEAVE
1793 007000 000207          RETURN

```

```

1795 007002 104472      SUBAAS: ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
1796 007004              NEWTST <<TEST BANK 0 ACCESSES>>
;*****
;*TEST 2          TEST BANK 0 ACCESSES
;*****
007004 000004      TST2:  SCOPE
1797              ;THIS DOES A 'TST' INSTRUCTION ON EVERY LOCATION IN BANK #0 TO SEE
1798              ;IF IT GETS ANY PARITY TRAPS.
1799              ;SINCE EVERY LOCATION IS EITHER LOADED OR WRITTEN INTO BY THE PROGRAM
1800              ;PRIOR TO THIS POINT - THEN A PARITY ERROR IMPLIES THAT THERE IS A
1801              ;HARDWARE FAILURE IN THE MEMORY.
1802              ;THESE ERRORS ARE COUNTED AND A FATAL ACTION IS TAKEN
1803 007006 005037 002074 CLR    PARCNT          ;CLEAR PARITY ERROR COUNTER
1804 007012 012737 000001 002100 MOV    #1,NOPAR        ;SET THE NO PARITY ERROR FLAG
1805 007020 005037 002072 CLR    NEMCNT          ;CLEAR NON-EXISTANT MEMORY ERROR COUNTER
1806 007024 012737 000001 002102 MOV    #1,NONEM        ;SET THE NON-EXISTANT MEMORY ERROR MODE TO COUNT
1807 007032          SET4   #NONEXIST          ;TRAPS TO 4 GOTO NONEXIST
1808 007040 005000          CLR    R0
1809 007042 012701 040000          MOV    #SIZE,R1
1810 007046 104424          CACHOFF          ;TURN CACHE OFF
1811 007050 005720          1$:  TST    (R0)+          ;SEE IF I CAN DO A READ ACCESS WITHOUT A PARITY TRAP
1812 007052 077102          SOB    R1,1$
1813 007054 104423          CACHON          ;TURN CACHE ON
1814              ;SEE IF ANY FAILURES
1815 007056 005737 002074 TST    PARCNT          ;ANY PARITY ERRORS?
1816 007062 001403          BEQ    2$          ;NO - SKIP
1817 007064          FATAL  3
1818 007072 005737 002072          2$:  TST    NEMCNT          ;ANY NON-EXISTANT MEMORY (HOLE$)?
1819 007076 001406          BEQ    3$          ;SKIP IF EQUAL
1820 007100 162737 000002 002040 SUB    #2,ADDRESS      ;UPDATE 1ST ADDRESS FAILURE FROM AUTO INCREMENT #
1821 007106          FATAL  4
1822 007114 053737 002114 003016 3$:  BIS    CPUBIT,CONFIG    ;SET CORRECT ACCESSED BIT ON BANK 0
1823 007122          RES4          ;RESET TRAPS TO 4 TO DEFAULT
1824
1825 007134          SUBTST <<ENABLE MK11 FOR CORRECT TRAPS>>
;*****
;*SUBTEST          ENABLE MK11 FOR CORRECT TRAPS
;*****
1826 007134          IF #SW0 SET.IN @SWR OR ACTFLAG IS TRUE
1827 007152 104506          ENASBE          ;TRAP ON SINGLE BIT ERRORS
1828 007154          ELSE
1829 007156 104472          ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
1830 007160          END ;OF IF #SW0
  
```

1833 007160

NEWST <<TEST BANKS 1-167 (OCTAL) FOR ZEROS & ONES>>

 :*TEST 3 TEST BANKS 1-167 (OCTAL) FOR ZEROS & ONES

007160 000004

```
TST3: SCOPE
;EACH BANK IS TESTED FOR EXISTANCE AND IF IT EXISTS
;THEN IS IS TESTED FOR ZEROS & ONES.
;EXCEPT -
;
;   PROTECTED BANKS (WHERE THE PROGRAM IS) ARE ONLY TESTED BY
;   'TST' INSTRUCTIONS LIKE BANK #0
;
;ANY BAD BANKS ARE LOGGED IN THE CONFIGURATION TABLE.
;ANY ERROR HERE WILL FORCE THE CONFIGURATION TABLE TYPEOUT'
;THIS ROUTINE IS ONLY DOING A SMART SIZE - NOT ACTUAL TESTING
CLR   BANK
MOV   #1,NOPAR           ;SET NO PARITY ERROR FLAG
MOV   #2,NONEM          ;SET NON-EXISTANT MEMORY MODE TO EXIT TEST LOOP
SET4  #NONEXIST         ;TRAPS TO 4 GOTO NONEXIST
BMOV  MTP000            ;PUT IN FAST MEMORY
MOV   #005237,UIPAR6    ;PUT 'INC ' INSTRUCTION IN SUBROUTINE
MOV   #PATERR,UIPAR7    ;PUT IN ADDRESS OF OPERAND FOR ABOVE
TAG9$: INC  BANK
CMP   #120, BANK        ;DONE?
BEQ   TAG2$             ;YES - SKIP TO NEXT TEST
MOV   BANK,R1
MUL   #6,R1              ;BANK*3*2
MOV   R1,BANKINDEX
CLR   PATERR             ;CLEAR PATTERN ERROR COUNTER
CLR   PARCNT             ;CLEAR PARITY ERROR COUNTER
CLR   NEMCNT             ;CLEAR NON-EXISTANT MEMORY COUNTER (HOLES)
MAP   BANK               ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
TST   CONFIG(R1)        ;IS THIS BANK PROTECTED?
BMI   TSTBANK            ;YES - GO TEST BANK SPECIAL
MOV   #207,UIPAR2       ;PUT 'RETURN' INSTRUCTION AFTER WRITE ROUTINE
MOV   #FIRST,RO
MOV   RO,R4
MOV   #SIZE,R1
MOV   R1,R3
CLR   R2                  ;DATA IS ZEROS
CACHOFF                    ;TURN CACHE OFF
SUPERVISOR                 ;ENTER SUPERVISOR MODE
CALL  FASTCITY            ;CALL TO THE USER INSTRUCTION PAR'S
KERNEL                    ;ENTER KERNEL MODE
CACHON                     ;TURN CACHE ON
BR   TAG3$                ;SKIP NEXT INSTRUCTION
TAG2$: CLR  BANK
RES4                      ;RESET TRAPS TO 4 TO DEFAULT
CLR   NOPAR              ;INDICATE DEFAULT PARITY ACTION
BR   SUBAAQ
TAG3$: TST  NEMCNT        ;ANY TRAPS?
BEQ   1$                  ;NO - SKIP
BR   TAC9$                ;NOW - TRY NEXT BANK
1$: CACHOFF                ;TURN CACHE OFF
SUPERVISOR                 ;ENTER SUPERVISOR MODE
CALL  UIPAR3              ;FINISH PATTERN
KERNEL                    ;ENTER KERNEL MODE
CACHON                     ;TURN CACHE ON
TST   PATERR              ;ANY PATTERN ERRORS
```

1834
 1835
 1836
 1837
 1838
 1839
 1840
 1841
 1842 007162 005037 002106
 1843 007166 012737 000001 002100
 1844 007174 012737 000002 002102
 1845 007202
 1846 007210
 1847 007216 012737 005237 177654
 1848 007224 012737 002076 177656
 1849 007232 005237 002106
 1850 007236 022737 000170 002106
 1851 007244 001450
 1852 007246 013701 002106
 1853 007252 070127 000006
 1854 007256 010137 002110
 1855 007262 005037 002076
 1856 007266 005037 002074
 1857 007272 005037 002072
 1858 007276
 1859 007312 005761 003016
 1860 007316 100533
 1861 007320 012737 000207 177644 WARN1:
 1862 007326 012700 060000
 1863 007332 010004
 1864 007334 012701 040000
 1865 007340 010103
 1866 007342 005002
 1867 007344 104424
 1868 007346
 1869 007354 004737 177640
 1870 007360 104417
 1871 007362 104423
 1872 007364 000412
 1873 007366 005037 002106
 1874 007372
 1875 007404 005037 002100
 1876 007410 000543
 1877 007412 005737 002072
 1878 007416 001401
 1879 007420 000704
 1880 007422 104424
 1881 007424
 1882 007432 004737 177646
 1883 007436 104417
 1884 007440 104423
 1885 007442 005737 002076

```

1886 007446 001031      BNE      2$      ;YES - SKIP
1887 007450 005737 002074  TST      PARCNT  ;ANY PARITY ERRORS
1888 007454 001026      BNE      2$      ;YES - SKIP
1889 007456 005737 002072  TST      NEMCNT  ;ANY NON EXISTANT MEMORY
1890 007462 001023      BNE      2$      ;YES - SKIP
1891 007464 012700 060000  MOV      #FIRST,R0
1892 007470 010004      MOV      R0,R4
1893 007472 012701 040000  MOV      #SIZE,R1
1894 007476 010103      MOV      R1,R3
1895 007500 013702 002726  MOV      ONES,R2      ;DATA IS ONES
1896 007504 012737 000240 177644  MOV      #000240,UIPAR2 ;PUT 'NOP' INSTRUCTION BACK IN SUBROUTINE
1897 007512 104424      CACHOFF      ;TURN CACHE OFF
1898 007514      SUPERVISOR    ;ENTER SUPERVISOR MODE
1899 007522 004737 177640  CALL     FASTCITY ;CALL TO THE USER INSTRUCTION PAR'S
1900 007526 104417      KERNEL      ;ENTER KERNEL MODE
1901 007530 104423      CACHON      ;TURN CACHE ON
1902 007532 013700 002110      2$: MOV      BANKINDEX,R0
1903 007536 005737 002076  TST      PATERR  ;ANY PATTERN ERRORS?
1904 007542 001006      BNE      3$      ;YES - SKIP
1905 007544 005737 002074  TST      PARCNT  ;ANY PARITY ERRORS?
1906 007550 001003      BNE      3$      ;YES - SKIP
1907 007552 005737 002072  TST      NEMCNT  ;ANY HOLES?
1908 007556 001406      BEQ      4$      ;NONE - SKIP
1909 007560 052760 004000 003016 3$: BIS      #BIT11,CONFIG(R0) ;SET ERROR BIT IN THIS BANK
1910 007566      SET      CONFGERROR ;FORCE PRINTING OF CONFIGURATION TABLE
1911 007574 053760 002114 003016 4$: BIS      (PUBIT,CONFIG(R0)) ;SET ACCESSED BIT
1912 007602 000137 007232  JMP      TAG9$
1913
1914      ;TEST A PROTECTED BANK
1915 007606      TSTBANK: PUSH     R1
1916 007610 012737 000001 002102  MOV      #1,NONEM      ;SET NON-EXISTANT MEMORY TO COUNT
1917 007616 012700 060000      MOV      #FIRST,R0
1918 007622 012701 040000      MOV      #SIZE,R1
1919 007626 104424      CACHOFF      ;TURN CACHE OFF
1920 007630      SUPERVISOR    ;ENTER SUPERVISOR MODE
1921 007636 005720      4$: TST      (R0)+
1922 007640 077102      SOB      R1,4$
1923 007642 104417      KERNEL      ;ENTER KERNEL MODE
1924 007644 104423      CACHON      ;TURN CACHE ON
1925 007646 012737 000002 002102  MOV      #2,NONEM      ;RESET NON-EXISTANT MEMORY TO EXIT TEST LOOP
1926 007654      POP      R1
1927 007656      IF PARCNT NE #0
1928 007664 052761 004000 003016  BIS      #BIT11,CONFIG(R1) ;ERROR BANK
1929 007672      SET      CONFGERROR ;FORCE PRINTING OF CONFIGURATION TABLE
1930 007700      END ;OF IF PARCNT
1931 007700      IF NEMCNT EQ #0
1932 007706 053761 002114 003016  BIS      (PUBIT,CONFIG(R1)) ;ACCESSED BANK
1933 007714      END ;OF IF NEMCNT
1934 007714 000137 007232  JMP      TAG9$
    
```

1937 007720

SUBAAG: SUBST <<DETERMINE PROTECTED BANKS>>

*SUBTEST DETERMINE PROTECTED BANKS

1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990

007720 000004
007722 104424
007724 005037 002122
007730 012701 060000
007734 005004
007736
007742 013703 002106
007746 070327 000006
007752 010337 002110
007756
007766
010006
010022 005037 002144
010026
010034
010044 104504
010046 010411
010050 010461 000002
010054 104502
010056 005711
010060 104500
010062
010064 005037 002144
010070 104504
010072 013711 002726
010076 013761 002726 000002
010104 104502
010106 005711
010110 104500
010112
010114 012737 007400 002144
010122 104504
010124 010411
010126 010461 000002

:THE MK11 INHIBITS ECC DISABLE (AND OTHER THINGS) ON THE BOTTOM
:16K WORDS OF EACH CONTROLLER (2 PER BOX).
:THIS IS CONSIDERED TO BE A PROTECTED BANK BY THE PROGRAM.
:USUALLY (ON A SINGLE BOX SYSTEM WITH 4K MOS RAMS) THIS IS BANKS #0 & #2
:HOWEVER IT MAY BE QUITE COMPLEX TO DETERMINE ON A GIVEN SYSTEM
:CONFIGURATION (MIXED MK11,MJ11; MIXED 4K MOS, 16K MOS; MULTIPLE MK11
:BOXES; MIXED INTERLEAVE SCHEMES) WHICH BANKS ARE PROTECTED.
:SO
:THIS ROUTINE ATTEMPS TO CREATE A DOUBLE BIT ERROR IN ADDRESS #0 & #2
:OF EVERY MK11 BANK. MK11 HARDWARE WILL PREVENT THIS FROM HAPPENING
:IN PROTECTED BANKS WHICH SHOULD ALWAYS INCLUDE BANK ZERO - WHERE THE
:PROGRAM IS.
:
:WARNING:!!!!!!
: IN CASE OF HARDWARE FAILURE IT IS COMMON THAT A DOUBLE BIT ERROR
: WILL BE CREATED ON THE KERNEL STACK & 'CRASH' THE DIAGNOSTIC DURING
: THIS ROUTINE. YOUR ONLY CLUE IS THAT YOU CAN GET AS FAR AS THIS
: ROUTINE BUT NOT PAST IT!
:SCOPE
:CACHOFF ;TURN CACHE OFF
:CLR KPFLAG
:MOV #FIRST,R1
:CLR R4
:FOR BANK := #0 TO #167
:MOV BANK,R3
:MUL #6,R3
:MOV R3,BANKINDEX
:IF (PUBIT SET.IN CONFIG(R3) ;IF ACCESSABLE
:IF #BIT13 SET.IN CONFIG(R3) AND #BIT14 OFF.IN CONFIG(R3) ;IF MK11
:MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
:CLR CSR
:SUPERVISOR ;ENTER SUPERVISOR MODE
:PUSH FIRST,FIRST+2 ;SAVE TWO TEST LOCATIONS
:CHKDIS ;DISABLE ECC & WRITE CHECKBITS FROM ALL CSR'S
:MOV R4,(R1) ;WRITE CHECKBITS (ALL ZEROS)
:MOV R4,2(R1)
:CLRCSR ;CLEAR MK11 CSRS
:TST (R1) ;READ CHECKBITS INTO REAL CSR
:WASDBE ;WAS THERE A DOUBLE BIT ERROR
:THIS MAKES SURE THAT SBE'S DON'T LOOK LIKE PROTECTED AREAS
:ON.NOERROR :1
:CLR CSR
:CHKDIS ;DISABLE ECC & WRITE CHECKBITS FROM ALL CSR'S
:MOV ONES,(R1)
:MOV ONES,2(R1)
:CLRCSR ;CLEAR MK11 CSRS
:TST (R1)
:WASDBE ;WAS THERE A DOUBLE BIT ERROR
:ON.NOERROR :2
:MOV #7400,CSR
:CHKDIS ;DISABLE ECC & WRITE CHECKBITS FROM ALL CSR'S
:MOV R4,(R1)
:MOV R4,2(R1)

DETERMINE PROTECTED BANKS

```

1991 010132 104502          CLRCR          ;CLEAR MK11 CSRS
1992 010134 005711          TST (R1)
1993 010136 104500          WASDBE          ;WAS THERE A DOUBLE BIT ERROR
1994 010140
1995 010142 012737 074000 002144  ON,NOERROR ;3
1996 010150 104504          MOV #74000,CSR
1997 010152 010411          CHKDIS          ;DISABLE ECC & WRITE CHECKBITS FROM ALL CSR
1998 010154 010461 000002          MOV R4,(R1)
1999 010160 104502          MOV R4,2(R1)
2000 010162 005711          CLRCR          ;CLEAR MK11 CSRS
2001 010164 104500          TST (R1)
2002 010166          WASDBE          ;WAS THERE A DOUBLE BIT ERROR
2003 010166          END ;OF ON,NOERROR ;3
2004 010166          END ;OF ON,NOERROR ;2
2005 010166          END ;OF ON,NOERROR ;1
2006          ON,NOERROR
2007 010170 013703 002110          ;MARK PROTECTED BANK
2008 010174 052763 010000 003016  MOV BANKINDEX,R3
2009 010202          BIS #BIT12,CONFIG(R3)          ;IDENTIFY AS PROTECTED BY MK11
2010 010202 104470          END ;OF ON,NOERROR
2011 010204 010411          ECCDIS          ;DISABLE ERROR CORRECTION
2012 010206 010461 000002          MOV R4,(R1)          ;CLEAR OUT DOUBLE BIT ERROR
2013 010212 104502          MOV R4,2(R1)          ;CLEAR OUT DOUBLE BIT ERROR
2014 010214          CLRCR
2015 010224 104417          POP FIRST+2,FIRST          ;RESTORE TWO TEST LOCATIONS
2016 010226          KERNEL          ;ENTER KERNEL MODE
2017 010226          END ;OF IF #BIT3
2018 010226          END ;OF IF CPUBIT
2019 010242          END ;OF FOR BANK
2020 010256 005037 002106  MAP          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
2021          CLR BANK
2022 010262          IF #SW0 SET.IN @SWR OR ACTFLAG IS TRUE
2023 010300 104506          ENASBE          ;TRAP ON SINGLE BIT ERRORS
2024 010302          ELSE
2025 010304 104472          ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
2026 010306          END ;OF IF #SW0
2027
2028 010306 104425          CACHON          ;TURN CACHE ON

```



```

2031 010310
      010310 000004
2032
2033 010312
2034 010312
2035 010316 004737 042422
2036 010322
2037 010336
2038 010344 104040
2039 010346
2040 010346
2041 010350
2042 010350
2043 010364

```

```

NEWST <<MK11 PROTECTION POINTER TEST>>
:.....
:*TEST 4      MK11 PROTECTION POINTER TEST
:.....
TST4:  SCOPE
      ;INSURE THAT BOTTOM OF MK11 WAS PROTECTED WITH PROTECTION POINTER CLEAR
      BEGIN PROTECTIONTEST
      FOR BANK := #0 TO #167
      CALL EXBANK
      IF MKFLAG IS TRUE AND ACFLAG IS TRUE
      IF KPFLAG IS FALSE
      ERROR      +40      ;MK11 PROTECTION POINTER FAILURE - DID NOT PROTECT BANK
      END ;OF IF KPFLAG
      LEAVE PROTECTIONTEST
      END ;OF IF MKFLAG
      END ;OF FOR BANK
      END PROTECTIONTEST

```

2046 010364

SUBSTST <<CHECK SYSTEM SIZE REGISTER>>

:SUBTEST CHECK SYSTEM SIZE REGISTER

:THIS CHECKS THE SYSTEM SIZE REGISTER TO INSURE IT IS CORRECT
:AND PROGRAMS ANY MK11 BOXES ON LINE THAT ARE NOT INHIBITED.

:NOTE: IF THE SYSTEM SIZE REGISTER IS SET TO INDICATE A VERY SMALL
:MEMORY THE PROGRAM MAY NOT BE ABLE TO FUNCTION.
:IF THE MK11 BOX STARTING ADDRESS LOGIC MALFUNCTIONS THE PROGRAM
:WILL EITHER CRASH BECAUSE OF DUAL ADDRESSING PROBLEMS OR
:WILL HAVE HOLES IN MEMORY (NON-EXISTANT BANKS).

:THE TEST FUNCTIONS AS FOLLOWS

- :1. THE PROGRAM CHECKS FOR MEMORY ON 16K WORD (BANK) BOUNDRIES
:THRU THE UNIBUS MAP (SO THAT THE SYSTEM SIZE REGISTER IS BYPASSED).
:LOCATION 'UNITOP' IS ASSIGNED THE NUMBER OF THE LAST BANK THAT WAS
:ACCESSABLE VIA THE UNIBUS MAP.
- :2. LOCATION 'HIBANK' IS SET TO THE HIGHEST BANK THAT IS EITHER
:(1) DIRECTLY ACCESSABLE VIA THE MEMORY BUS OR
:(2) AN MK11 CSR CLAIMS THAT IT EXISTS.
- :3. LOCATION 'HIACBANK' IS ASSIGNED THE NUMBER OF THE HIGHEST BANK
:THAT IS DIRECTLY ACCESSABLE VIA THE MEMORY BUS.
- :4. IF THE HIGHEST ACCESSABLE BANK IS LESS THAN #170
:IF ANY BOX STARTING ADDRESSES WERE ABOVE BANK #167
:TRY TO PROGRAM THE STARTING ADDRESS OF THE PENDING BOX
:IF IT DOES PROGRAM DOWN AND THEREFORE ADD MEMORY TO THE SYSTEM
:RESTART THE PROGRAM
:NEXT PENDING BOX
- :5. RO IS SET TO THE HIGHEST BANK NUMBER OF HIBANK OR UNITOP
- :6. IF THE SYSTEM SIZE REGISTER DOES NOT EQUAL RO'S BANK THEN PRINT THE ERROR

2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079

2082					: FIND UNITOP	
2083	010364	104424			CACHOFF	: TURN CACHE OFF
2084	010366	005037	170372		CLR MAPH36	: SET MAP TO BANK 1
2085	010372	012737	100000	170370	MOV #100000,MAPL36	
2086	010400				SET4 #2\$: TRAPS TO 4 GOTO 2\$
2087	010406	012737	000004	002100	MOV #4,NOPAR	: PARITY ACTION = COUNT & IGNORE
2088	010414	012700	140000		MOV #140000,R0	: PAR6 SELECTED
2089	010420	005710			TST (R0)	: TRAP IF NON-EXISTANT
2090	010422	062737	100000	170370	ADD #100000,MAPL36	: BUMP 1 BANK
2091	010430	005537	170372		ADC MAPH36	
2092	010434	022737	000073	170372	CMP #73,MAPH36	: INTO 128K SHADOW MEMORY?
2093	010442	001366			BNE 1\$: NO - LOOP
2094	010444	000402			BR 3\$	
2095	010446	062706	000004		ADD #4,SP	: FIX STACK FROM TRAP
2096	010452	162737	100000	170370	SUB #100000,MAPL36	
2097	010460	005637	170372		SBC MAPH36	
2098	010464				RES4	: RESET TRAPS TO 4 TO DEFAULT
2099	010476	005037	002100		CLR NOPAR	: RESTORE DEFAULT PARITY ACTION
2100	010502	006137	170370		ROL MAPL36	
2101	010506	006137	170372		ROL MAPH36	
2102	010512	013737	170372	002516	MCMV MAPH36,UNITOP	
2103						
2104					: FIND HIBANK	
2105	010520	012737	000077	170372	MOV #77,MAPH36	: RESTORE MAP36
2106	010526	012737	160000	170370	MOV #160000,MAPL36	
2107	010534	104423			CACHON	: TURN CACHE ON
2108	010536				PUSH SLAVES	
2109	010542	012737	000003	002730	MOV #3,SLAVES	: FAKE OUT THE EXBANK ROUTINE
2110	010550				BEGIN MEMSIZELOOP	
2111	010550				FOR BANK := #0 TO #167	
2112	010554	004737	042422		CALL EXBANK	
2113	010560				IF ACFLAG IS FALSE AND MKFLAG IS FALSE	
2114	010574				LEAVE MEMSIZELOOP	
2115	010576				END ;OF IF ACFLAG	
2116	010576				END ;OF FOR BANK	
2117	010612				END MEMSIZELOOP	
2118	010612	013700	002106		MOV BANK,R0	
2119	010616	005300			DEC R0	
2120	010620	010037	002512		MOV R0,HIBANK	

```

2123      ;FIND HIACBANK
2124 010624 CLEAR BANK,HIACBANK
2125 010634 SET ACFLAG
2126 010642 WHILE ACFLAG IS TRUE AND BANK LT #167
2127 010660 005237 002106 INC BANK
2128 010664 004737 042422 CALL EXBANK
2129 010670 END ;OF WHILE ACFLAG
2130 010672 POP SLAVES ;RESTORE FROM FAKE OUT
2131 010676 013737 002106 002514 MOV BANK,HIACBANK
2132
2133      ;PROGRAM ON ANY BOXES SETUP FOR ALLOW PROGRAM
2134      ;& HI (100) STARTING ADDRESSES
2135 010704 IF HIACBANK LT #170
2136 010714 IF PENDBOX IS TRUE
2137 010722 013701 002330 MOV PENDBOX,R1
2138 010726 FOR CSRNO := #0 TO #34 BY #4
2139 010732 106301 ASLB R1
2140 010734 ON.ERROR
2141 010736 SET TWOCSRS
2142 010744 012737 000001 002144 MOV #1,CSR
2143 010752 013737 002514 002146 MOV HIACBANK,CSR+2
2144 010760 000241 CLC
2145 010762 006037 002146 ROR CSR+2
2146 010766 005537 002146 ADC CSR+2 ;IF NOT 32K WORD BOUND LEAVE A WHOLE IN MEM
2147 010772 052737 002000 002146 BIS #BIT10,CSR+2 ;LOAD START ADD & INTERLEAVE BIT
2148 011000 104425 LOADCSR
2149 011002 CLEAR CSR,CSR+2,TWOCSRS
2150 011016 012737 000010 002144 MOV #BIT3,CSR
2151 011024 104425 LOADCSR
2152 011026 104426 READCSR
2153 011030 013702 002146 MOV CSR+2,R2
2154 011034 042702 177000 BIC #177000,R2
2155 011040 006302 ASL R2
2156 011042 IF R2 LT #167 ;IF I CHANGED IT'S STARTING ADDRESS
2157 011050 005037 002670 CLR LOCK
2158 011054 000137 004352 JMP START
2159 011060 END ;OF IF R2
2160 011060 END ;OF ON.ERROR
2161 011060 END ;OF FOR CSRNO
2162 011076 END ;OF IF PENDBOX
2163 011076 END ;OF IF HIACBANK
    
```

J 6

```

2166                                     :RO := MAX(HIBANK,UNITOP)
2167 011076                             IF RO LT UNITOP THEN LET RO := UNITOP
2168
2169                                     :CHECK SYSTEM SIZE REGISTER
2170 011110 072027 000011              ASH #9,RO
2171 011114 052700 000777              BIS #777,RO ;RO = LAST GOOD ADDRESS (LESS 6 LSB'S)
2172 011120 020037 177760              CMP RO,SIZELO ;IS IT RIGHT?
2173 011124 001503
2174 011126 012737 177760 002040      MOV #SIZELO,ADDRESS
2175 011134 010037 002050              MOV RO,GOOD
2176 011140 013737 177760 002056      MOV SIZELO,BAD
2177 011146 000300
2178 011150 004737 011210              SWAB RO
2179 011154 010137 002476              CALL SYSSIZE
2180 011160 013700 177760              MOV R1,GDSWITCH
2181 011164 000300
2182 011166 004737 011210              MOV SIZELO,R0
2183 011172 010137 002500              SWAB RO
2184 011176 104023
2185 011200 013737 002754 002020      CALL SYSSIZE
2186 011206 000452                      MOV R1,BDSWITCH
2187                                     ERROR +23
2188                                     MOV $ERTTL,LASTERROR ;DON'T COUNT AS 'DETECTED BUT NOT ISOLATED'
2189                                     BR SUBAAT
2189 011210 005001                      :DETERMINE SWITCH SETTINGS IN R1 FROM ADDRESS IN R0
SYSSIZE: CLR R1
2190 011212                              IF #BIT0 SET.IN R0 THEN LET R1 := R1 SET.BY #BIT2
2191 011224                              IF #BIT1 SET.IN R0 THEN LET R1 := R1 SET.BY #BIT0
2192 011236                              IF #BIT2 SET.IN R0 THEN LET R1 := R1 SET.BY #BIT4
2193 011250                              IF #BIT3 SET.IN R0 THEN LET R1 := R1 SET.BY #BIT7
2194 011262                              IF #BIT4 SET.IN R0 THEN LET R1 := R1 SET.BY #BIT3
2195 011274                              IF #BIT5 SET.IN R0 THEN LET R1 := R1 SET.BY #BIT1
2196 011306                              IF #BIT6 SET.IN R0 THEN LET R1 := R1 SET.BY #BIT5
2197 011320                              IF #BIT7 SET.IN R0 THEN LET R1 := R1 SET.BY #BIT6
2198 011332 000207                      RETURN
    
```

```

2201 011334          SUBAAT: SUBTST <<MOVE LOADERS IF NECESSARY>>
:*****
:*SUBTEST          MOVE LOADERS IF NECESSARY
:*****
2202                ;THE TOP 16K OF THE PROGRAM (WHICH INCLUDES LOADERS) WILL BE MOVED
2203                ;TO AN MK11 PROTECTED AREA IF IT IS NOW IN MK11 MEMORY.
2204                ;IF IT IS IN CORE IT WILL BE LEFT ALONE.
2205 011334          IF CPUBIT EQ #MASTER
2206 011344 042737 100000 003024      BIC #BIT15,CONFIG+6          ;UNPROTECT OLD LOADER SPACE
2207 011352          BEGIN FIRSTPROTECT
2208 011352          FOR BANK := #1 TO #167
2209 011360 004737 042422          CALL EXBANK
2210 011364          IF ACFLAG IS TRUE AND BMFLAG IS FALSE
2211 011400          IF KPFLAG IS TRUE OR MKFLAG IS FALSE
2212 011414          LEAVE FIRSTPROTECT
2213 011416          END ;OF IF KPFLAG
2214 011416          END ;OF IF ACFLAG
2215 011416          END ;OF FOR BANK
2216 011432 012737 000001 002106      MOV #1,BANK
2217 011440 004737 042422          CALL EXBANK
2218 011444          END FIRSTPROTECT
2219 011444 013737 002106 002710      MOV BANK,LOADHOME
2220 011452 013700 002110          MOV BANKINDEX,R0
2221 011456 052760 100000 003016      BIS #BIT15,CONFIG(R0)
2222 011464          IF LOADHOME NE #1
2223 011474 012737 000004 002100      MOV #4,NOPAR          ;PARITY ACTION COUNT & IGNORE
2224 011502 013700 002710          MOV LOADHOME,R0      ;DESTINATION BANK
2225 011506 012701 000001          MOV #1,R1          ;SOURCE BANK
2226 011512 00473 042072          CALL BANKMOV
2227 011516 004737 042370          CALL NEWLOAD      ;MAP KERNEL TO NEW LOADER BANK
2228 011522 005037 002100          CLR NOPAR
2229 011526 005037 002074          CLR PARCNT
2230 011532          END ;OF IF LOADHOME
2231                ;COPY MAPPING FOR ANY SLAVES
2232 011532 012700 172340          MOV #KIPAR0,R0
2233 011536 012701 002550          MOV #KIO,R1
2234 011542 012705 000010          MOV #8,R5
2235 011546 012021          MOV (R0)+,(R1)+
2236 011550 077502          SOB R5,1$
2237 011552          END ;OF IF CPUBIT
2238                SET STOPOK
2239 011552
    
```

2242 011560

SUBTST <<MULTIPOINT HOOK>>

```

*****
*SUBTEST MULTIPOINT HOOK
*****
    
```

2243
 2244
 2245
 2246
 2247
 2248
 2249
 2250
 2251
 2252
 2253
 2254
 2255 011560 104424
 2256 011562
 2257 011574
 2258 011604 012700 000002
 2259 011610 000137 011656
 2260 011614
 2261 011614
 2262 011624 012700 000004
 2263 011630 000137 011656
 2264 011634
 2265 011634
 2266 011644 012700 000006
 2267 011650 000137 011656
 2268 011654
 2269 011654 005000
 2270
 2271 011656
 2272 011664 013702 177764
 2273 011670
 2274 011672 012777 100000 171036
 2275 011700 017702 171032
 2276 011704 072227 177770
 2277 011710 042702 177774
 2278 011714
 2279 011714 010260 002606
 2280
 2281
 2282 011720 010003
 2283 011722
 2284 011730
 2285 011734 052760 100000 002616
 2286 011742
 2287 011750 005337 002670
 2288 011754 062700 002636
 2289
 2290
 2291 011760 000137 177640
 2292 011764
 2293 011766 004737 061074
 2294 011772
 2295 011776 012777 000001 170732

```

;THIS IS WHERE WE SEPARATE THE MASTER FROM THE SLAVES.
;THE MASTER IS THE PROCESSOR RUNNING WITH LOCATION 'CPUBIT'
;EQUAL TO #MASTER (BIT4).
;
;SLAVES ARE STOPPED HERE.
;IF THERE IS AN IIST AND FIELD SERVICE IS ALLOWING US TO USE IT
; THE SLAVE LOWERS HIS PRIORITY AND WAITS FOR AN INTERRUPT
; FROM THE MASTER'S IIST.
;ELSE
; THE SLAVE MOVES INTO THE UIPAR'S AND EXECUTES A LITTLE PROGRAM
; THAT LOOKS FOR A COUNT PATTERN '10,9,8,7,6,5,4,3,2,1,0' IN HIS
; PSEUDO TTY BUFFER (PTYBUF+ID).
CACHOFF ;TURN CACHE OFF
IF CPUBIT IS FALSE THEN JUMPTO SUBAAR
IF CPUBIT EQ #SLAVE1
    MOV #2,R0
    JMP CPUID
END ;OF IF CPUBIT
IF CPUBIT EQ #SLAVE2
    MOV #4,R0
    JMP CPUID
END ;OF IF CPUBIT
IF CPUBIT EQ #SLAVE3
    MOV #6,R0
    JMP CPUID
END ;OF IF CPUBIT
CLR R0 ;MUST BE MASTER THEN

CPUID: IF NOIIST IS TRUE
    MOV SYSTID,R2
ELSE
    MOV #BIT15,@IISTACR
    MOV @IISTACR,R2
    ASH #-8,R2
    BIC #^C3,R2
END ;OF IF NOIIST
MOV R2,PORTDIR(R0)

;THIS IS WHERE THE SLAVES COME TO STOP
STOPCPU:MOV R0,R3
IF NOIIST IS TRUE
    IF R0 EQ #0 THEN GOTO MP1 ;SKIP IF I'M THE MASTER
    BIS #BIT15,TASK(R0)
    BMOV WAITSTUFF
    DEC LOCK ;ALLOW OTHERS TO RUN
    ADD #PTYBUF,R0 ;R0 POINTS TO COUNT DOWN LOCATION
;WAIT FOR MASTER TO COUNT DOWN!
;CALL TO THE USER INSTRUCTION PAR'S
    JMP FASTCITY
ELSE
    CALL IISTINIT
    IF R0 EQ #0 THEN GOTO MP1 ;SKIP IF I'M THE MASTER
    MOV #1,@IISTACR
    
```

```
2296 012004 012777 000004 170726      MOV  #BIT2,@IISTADR      ;ENABLE INTERRUPTS
2297 012012 000234                SPL  4
2298 012014 052760 100000 002616      BIS  #BIT15,TASK(R0)
2299 012022 005337 002670                DEC  LOCK                ;ALLOW OTHERS TO RUN
2300 012026 000001                WAIT                       ;WAIT IF I'M A SLAVE
2301 012030 000137 050726      JMP  TASKDO
2302 012034                END ;OF IF NOIIST
```


2305 012034

WAITSTUFF:SUBTST <<SLAVES WAIT FOR MASTER TO COUNT DOWN>>
:*****
:*SUBTEST SLAVES WAIT FOR MASTER TO COUNT DOWN
:*****

2306 012034 012702 000014
2307 012040 012701 000013
2308 012044 005302
2309 012046 005301
2310 012050 020210
2311 012052 001776
2312 012054 020110
2313 012056 001366
2314 012060 005701
2315 012062 001370
2316 012064 000137 061216

1\$: MOV #12.,R2 ;V177640
MOV #11.,R1 ;V177644
2\$: DEC R2 ;V177650
DEC R1 ;V177652
3\$: CMP R2,(R0) ;V177654
BEQ 3\$;V177656
CMP R1,(R0) ;V177660
BNE 1\$;V177662
4\$: TST R1 ;V177664
BNE 2\$;V177666
JMP SLAVUP ;V177670

2319 012070

2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363

```
MP1:  SUBST <<BOOT UP ALL EXISTING CPU'S>>
:*****
:*SUBTEST  BOOT UP ALL EXISTING CPU'S
:*****
:ALL SLAVES ARE BOOTED AS FOLLOWS
:
:SETUP A SOFTWARE SWITCH REGISTER.
:IF WE ARE USING IIST'S.
:  BEGIN BOOTLOOP
:    FOR EACH OF 4 POSSIBLE CPU'S.
:      SETUP STACK VALUE LESS THAN PREVIOUS CPU.
:      CLEAR ACKNOWLEDGE.
:      POINT IIST INTERRUPT VECTOR TO START.
:MP2:  WAIT FOR THE MASTER'S IIST TO BE READY (SHOULD ALREADY BE).
:      INITIALIZE THE MASTER'S IIST (DISABLE BOOTS & INTERRUPTS).
:      WAIT FOR THE WINDOW IN THE BOOT THAT ALLOWS INTERRUPTS.
:      INITIATE THE IIST INTERRUPT OF THE SELECTED CPU.
:      WAIT FOR THE SLAVE TO ACKNOWLEDGE STARTING.
:      IF THE CPU DOES NOT ACKNOWLEDGE
:        IF THE CPU SELECTED IS NOT THE MASTER
:          LEAVE BOOTLOOP.
:        ELSE
:          GOTO MP2.
:      END OF IF THE CPU SELECTED IS NOT THE MASTER.
:    ELSE
:      WAIT FOR TASK DONE FROM SLAVE (TASK=START).
:      UPDATE SLAVE COUNT (THIS SLAVE IS THE HIGHEST # SO FAR).
:      IF THIS WAS THE 4TH CPU THEN LEAVE BOOTLOOP.
:    END OF IF THE CPU DOES NOT ACKNOWLEDGE.
:  END OF FOR EACH OF 4 POSSIBLE CPU'S.
:END OF BOOTLOOP.
:IF THERE WERE NO SLAVES
:  CLEAR THE MULTIPROCESSING FLAG 'MULTIPORT'.
:  SET THE IIST VECTOR TO LOOK FOR UNEXPECTED TRAPS.
:END OF IF THERE WERE NO SLAVES.
:ELSE
:  FOR EACH SLAVE
:    SETUP STACK VALUE LESS THAN PREVIOUS CPU.
:    TYPE 'START SLAVE #N AT ADDRESS 200'.
:    WAIT FOR TASK DONE FROM SLAVE (TASK=START).
:  END OF FOR EACH SLAVE.
:END OF IF WE ARE USING IIST'S.
:RESTORE THE MASTER TO THE NORMAL SWITCH REGISTER
:WAIT A SECOND.
:MAKE SURE I'M THE ONLY PROCESSOR RUNNING.
:SETUP STACK VALUE BACK TO MASTER'S DEFAULT.
:TURN CACHE ON.
```

```

2366
2367
2368 012070 005337 002670      .ENABL  LSB
2369                                DEC  LOCK
2370 012074 013737 002766 002674 ;PASS PSEUDO SWR TO SLAVE ;ALLOW ONE SLAVE TO RUN
2371 012102 012737 000176 002766 MOV SWR,MASWR ;SAVE REAL SWR
2372 012110 017777 170560 170650 MOV #SWREG,SWR ;SETUP SOFTWARE SWR
2373 012116                                MOV @MASWR,@SWR ;FILL IT WITH REAL SWR STUFF
2374 012130 012702 000400      IF NOIST IS TRUE THEN JUMPTO MP4
2375 012134 012703 000001      MOV #BIT8,R2 ;BOOT = BITS 11,10,9,8
2376 012140                                MOV #1,R3 ;INTERRUPT = BITS 3,2,1,0
2377 012140      BEGIN BOOTLOOP
2378 012144 162737 000200 002706 FOR R1 := #1 TO #3
2379 012152 013737 002706 000J00 SUB #200,KSTACK ;SLAVES - PLEASE USE YOUR OWN STACK
2380 012160 012700 000020 MOV KSTACK,0 ;PUT IN LOC 0 FOR BOOTSTRAP
2381 012164 072001 MOV #MASTER,R0 ;SET FIRST CPU ID BIT
2382 012166 010037 002114 ASH R1,R0 ;SHIFT IT TO CORRECT SPOT
2383 012172 010100 MOV R0,CPUBIT ;CPUBIT = BITS 5 OR BIT 6 OR BIT 7
2384 012174 006300 ASL R0 ;CPU # ---> R0
2385 012176 005037 002672 CLR ACK ;R0 := 2 OR 4 OR 6 ;INDEX VALUE
2386 012202 013704 002742 MOV IISTVEC,R4 ;ALLOW ONLY ONE CPU AT A TIME
2387 012206 012724 004352 MOV #START,(R4)+ ;INTERRUPT VECTOR TO START
2388 012212 012714 000340 MOV #340,(R4) ;HIGH PRIORITY
2389
2390 ;WAIT FOR IIST READY
2391 012216 012737 061165 002574 MOV #5*SECONDS,HUNGTIME
2392 012224 012777 000001 170504 MP2: MOV #1,@IISTACR
2393 012232 004737 072154 CALL QUE
2394 012236 ON.ERROR
2395 012240 104061 ERROR +61 ;IIST IS HANGING SYSTEM!
2396 012242 005037 002730 CLR SLAVES
2397 012246 LEAVE BOOTLOOP
2398 012250 END ;OF ON.ERROR
2399 012250 032777 004000 170462 BIT #BIT11,@IISTADR
2400 012256 001762 BEQ MP2
2401
2402 012260 004737 061174 CALL IISTOFF ;INITIALIZE THE IIST & DISABLE BOOTS & INTERRUPTS
2403 012264 012777 000000 170444 MOV #0,@IISTACR ;SELECT THE ACCESS CONTROL REGISTER
2404 012272 010277 170442 MOV R2,@IISTADR ;BOOT SOME CPU
2405 012276 012777 000001 170434 MOV #1,@IISTADR ;NOW!
2406 ;THIS DELAY IS GOOD ONLY FOR THE M9312 MULTIPROCESSOR BOOT
2407 ;THIS DELAY ALSO ASSUMES THAT CACHE IS OFF
2408 012304 012704 140000 MOV #140000,R4 ;THIS DELAY TAKES APPROX 3/4 SECOND
2409 012310 000240 3$: NOP
2410 012312 000240 NOP
2411 012314 000240 NOP
2412 012316 000240 NOP
2413 012320 005237 000110 INC 110 ;CHANGE MOVING LOCATION - SEE BOOT LISTING
2414 ;THIS STOPS THE BOOT FROM RUNNING THE MEMORY
2415 ;DIAGNOSTIC AND BLOWING UP MY SOFTWARE
2416 012324 077407 SOB R4,3$
    
```

2418 012326 012777 000000 170402
 2419 012334 010377 170400
 2420 012340 012777 000001 170372
 2421
 2422 012346 012705 000003
 2423 012352 005004
 2424 012354
 2425 012362 005237 000110
 2426
 2427
 2428 012366 077406
 2429 012370 077507
 2430 012372
 2431 012372
 2432 012400 006302
 2433 012402 006303
 2434 012404
 2435 012412
 2436 012414
 2437 012416
 2438 012420
 2439 012420
 2440 012422 005037 002672
 2441 012426 012737 000005 002572
 2442 012434 012737 177777 002574
 2443 012442 004737 072154
 2444 012446
 2445 012450 162737 000001 002572
 2446 012456
 2447 012460 010137 002056
 2448 012464 104060
 2449 012466 005037 002730
 2450 012472
 2451 012474
 2452 012474
 2453 012474 005760 002616
 2454 012500 100360
 2455 012502 010137 002730
 2456 012506
 2457 012514
 2458 012514 006302
 2459 012516 006303
 2460 012520
 2461 012530
 2462 012530
 2463 012536 005037 003014
 2464 012542 012777 036764 170172
 2465 012550
 2466 012550 000462
 2467 012552
 2468 012556 012700 000020
 2469 012562 072001
 2470 012564 010037 002114
 2471 012570 162737 000200 002706
 2472 012576 010100
 2473 012600 006300
 2474 012602

```

MOV #0,@IISTACR ;SELECT THE ACCESS CONTROL REGISTER
MOV R3,@IISTADR ;INTERRUPT SOME CPU
MOV #1,@IISTADR ;NOW!
;WAIT FOR ACK OR TIMEOUT
MOV #3,R5 ;THIS IS APPROX A 3 SECOND DELAY
CLR R4
1$: IF ACK IS FALSE ;CHANGE MOVING LOCATION - SEE BOOT LISTING
    INC 110 ;THIS STOPS THE BOOT FROM RUNNING THE MEMORY
                ;DIAGNOSTIC AND BLOWING UP MY SOFTWARE.
                SOB R4,1$
                SOB R5,1$
END ;OF IF ACK IS FALSE
IF ACK IS FALSE ;IF THERE IS NO SLAVE AT THIS IISTID #
    ASL R2
    ASL R3
    IF R3 EQ #BIT4
        LEAVE BOOTLOOP
    ELSE
        GOTO MP2
    END ;OF IF R3
ELSE
    CLR ACK ;ALLOW SLAVE TO PROCEED
    MOV #5,HUNGMSB
    MOV #-1,HUNGTIME
    CALL QUE
    ON.ERROR
    SUB #1,HUNGMSB
    ON.ERROR
    MOV R1,BAD
    ERROR +60 ;SLAVE IS HANGING SYSTEM!
    CLR SLAVES
    LEAVE BOOTLOOP
END ;OF ON.ERROR
END ;OF ON.ERROR
TST TASK(R0)
BPL 2$
MOV R1,SLAVES ;COUNT OF SLAVES WAS IN R1
IF R3 EQ #BIT3 THEN LEAVE BOOTLOOP
END ;OF IF ACK
ASL R2
ASL R3
END ;OF FOR R1
END BOOTLOOP
IF SLAVES EQ #0
    CLR MULTIPOINT
    MOV #IITRAP,@IISTVEC ;RESTORE UNEXPECTED IIST TRAP
END ;OF IF SLAVES
BR MP3
MP4: FOR R1 := #1 TO SLAVES
    MOV #BIT4,R0
    ASH R1,R0
    MOV R0,CPUBIT ;CPUBIT = BITS OR BIT6 OR BIT7
    SUB #200,KSTACK
    MOV R1,R0
    ASL R0 ;R0 = 2 OR 4 OR 6
    TYPE MSG081 ;START SLAVE #
  
```

```

2475 012606          TYPOCS          R1,,1
2476 012614          TYPE MSG082          ;AT ADDRESS 200
2477 012620 012737 000031 002572      MOV #25.,HUNGMSB
2478 012626 012737 177777 002574      MOV #-1,HUNGTIME
2479 012634 005037 002672          5$: CLR ACK          ;ALLOW SLAVE TO PROCEED
2480 012640 004737 072154          CALL QUE
2481 012644          ON.ERROR
2482 012646 162737 000001 002572      SUB #1,HUNGMSB
2483 012654          ON.ERROR
2484 012656 010137 002056          MOV R1,BAD
2485 012662 104060          ERROR +60          ;SLAVE IS HANGING SYSTEM
2486 012664          CLEAR SLAVES,MULTIPORT
2487 012674 000137 012716          JMP MP3
2488 012700          END ;OF ON.ERROR
2489 012700          END ;OF ON.ERROR
2490 012700 005760 002616      TST TASK(R0)
2491 012704 100353          BPL 5$
2492 012706          END ;OF FOR R1
2493          ;POINT THE MASTER BACK TO THE NORMAL SWR
2494 012716 013737 002674 002766      MP3: MOV MASWR,SWR
2495 012724 012737 000020 002114      MOV #MASTER,CPUBIT
2496 012732 052737 000020 002510      BIS #MASTER,ALLCPUS
2497          ;WAIT A SECOND
2498 012740 005000          CLR R0
2499 012742 077001          4$: SOB R0,4$
2500          ;STOP ANY CONFUSED MASTER (ME)
2501 012744 005237 002670          INC LOCK
2502 012750          IF LOCK NE #1
2503 012760 000000          MHALT3: HALT
2504 012762 000776          BR MHALT3
2505 012764          END ;OF IF LOCK
2506 012764 012737 000020 002114      MP5: MOV #MASTER,CPUBIT          ;BACK TO MASTER
2507 012772 012737 002000 002706      MOV #STACK,KSTACK
2508 013000 104423          CACHON          ;TURN CACHE ON
2509          .DSABL LSB

```

2512 013002

SUBTST <<CHECK FOR UNIQUE CPU ID NUMBERS>>

```

:*****
:*SUBTEST    CHECK FOR UNIQUE CPU ID NUMBERS
:*****
    
```

2513 013002 104424
 2514 013004
 2515 013004 013702 002730
 2516 013010 006302
 2517 013012
 2518 013014
 2519 013016
 2520 013022
 2521 013032 104041
 2522 013034
 2523 013040
 2524 013042 005037 003014
 2525 013046
 2526 013046
 2527 013046
 2528 013056
 2529 013066
 2530 013066 104423
 2531
 2532 013070

```

CACHOFF                ;TURN CACHE OFF
BEGIN SAMESAME
MOV    SLAVES,R2
ASL    R2
FOR RO := #0 TO R2 BY #2
  FOR R1 := #0 TO R2 BY #2
    IF RO NE R1
      IF PORTDIR(RO) EQ PORTDIR(R1)
        ERROR +41
        TYPE    MSG084                ;PROCEEDING AS A SINGLE PORT TEST
      LEAVE SAMESAME
      CLR    MULTIPOINT
    END ;OF IF PORTDIR(RO)
  END ;OF IF RO
END ;OF FOR R1
END ;OF FOR RO
END SAMESAME
CACHON                ;TURN CACHE ON
    
```

SUBTST <<PRINT MULTIPOINT DIRECTORY>>

```

:*****
:*SUBTEST    PRINT MULTIPOINT DIRECTORY
:*****
    
```

2533 013070
 2534 013076
 2535 013102
 2536 013112 112737 000060 115753
 2537 013120
 2538 013124 010001
 2539 013126 006301
 2540 013130 105237 115753
 2541 013134
 2542 013140
 2543 013150
 2544 013160
 2545
 2546 013160

```

IF MULTIPOINT IS TRUE
  TYPE MSG086
  TYPOCS PORTDIR
  MOVB #'0,MSG087
  FOR RO := #1 TO SLAVES
    MOV RO,R1
    ASL R1
    INCB    MSG087
    TYPE    MSG087
    TYPOCS PORTDIR(R1)
  END ;OF FOR RO
END ;OF IF MULTIPOINT
    
```

SUBAAR: SUBTST <<LOAD CSR'S FROM E-TABLE \$CDW1 & \$CDW2>>

```

:*****
:*SUBTEST    LOAD CSR'S FROM E-TABLE $CDW1 & $CDW2
:*****
    
```

2547 013160
 2548 013174 013701 002334
 2549 013200 013737 075214 002144
 2550 013206 013737 075216 002146
 2551 013214
 2552 013220 106301
 2553 013222
 2554 013224 104425
 2555 013226
 2556 013226
 2557 013244 005237 075142
 2558 013250 000137 015050
 2559 013254

```

IF $CDW1 NE #0 OR $CDW2 NE #0
  MOV    MKCSRS,R1
  MOV    $CDW1,CSR
  MOV    $CDW2,CSR+2
  FOR CSRN0 := #0 TO #34 BY #2
    ASLB    R1
    ON.ERROR
    LOADCSR
  END ;OF ON.ERROR
  END ;OF FOR CSRN0
  INC    $PASS
  JMP    APTHANG                ;GO LOOP FOREVER KEEPING APT ALIVE
END ;OF IF $CDW1
    
```

```

2562 013254
2563 013254
2564 013264
2565 013270 004737 042422
2566 013274 013700 002110
2567
2568
2569 013300
2570
2571 013306
2572 013316 013737 002510 002114
2573 013324 004737 042422
2574 013330 012737 000020 002114
2575
2576 013336
2577 013352
2578 013360
2579 013400
2580 013416
2581 013434
2582 013452
2583 013470 104063
2584 013472
2585 013472
2586 013472
2587
2588
2589 013472 004737 042422
2590 013476
2591 013512 016001 003016
2592 013516 042701 177770
2593 013522
2594 013532 006301
2595 013534
2596 013534
2597
2598
2599
2600
2601
2602
2603
2604
2605
2606
2607
2608
2609 013542 005004
2610 013544 116002 003022
2611 013550 012703 000010
2612 013554 006002
2613 013556 005504
2614 013560 077303
2615

```

```

SUBST <<LEGAL CONFIGURATION CHECK>>
*****
:SUBTEST LEGAL CONFIGURATION CHECK
*****
IF CPUBIT EQ #MASTER
FOR BANK := #0 TO #167
CALL EXBANK
MOV BANKINDEX,R0

;MAKE SURE THAT EVERYBODY CAN ACCESS EVERY BANK
IF MKFLAG IS TRUE
;IF ANYBODY CAN ACCESS
IF #MASTER.SLAVE1!SLAVE2!SLAVE3 SET.IN CONFIG(R0)
MOV ALLCPUS,CPUBIT
CALL EXBANK
MOV #MASTER,CPUBIT
;IF EVERYBODY CAN'T ACCESS
IF ACFLAG IS FALSE AND CONFGERROR IS FALSE
SET CONFGERROR
CLEAR SLFLAG,SLFLAG+2,SLFLAG+4,SLFLAG+6
IF #MASTER SET.IN CONFIG(R0) THEN LET SLFLAG := ONES
IF #SLAVE1 SET.IN CONFIG(R0) THEN LET SLFLAG+2 := ONES
IF #SLAVE2 SET.IN CONFIG(R0) THEN LET SLFLAG+4 := ONES
IF #SLAVE3 SET.IN CONFIG(R0) THEN LET SLFLAG+6 := ONES
ERROR +63
END ;OF IF ACFLAG
END ;OF IF #MASTER!SLAVE1!SLAVE2!SLAVE3
END ;OF IF MKFLAG IS TRUE

;MAKE SURE (IF I CAN) THAT EACH BOX HAS ONE & ONLY ONE CSR
CALL EXBANK
IF ACFLAG IS TRUE AND MKFLAG IS TRUE
MOV CONFIG(R0),R1
BIC #C7,R1 ;R1 = 0 OR 1 OR 2 OR 4
IF #BIT12 OFF.IN CONFIG+2(R0) ;IF NO INTERNAL INTERLEAVE
ASL R1 ;R1 = 0 OR 2 OR 4
END ;OF IF #BIT12
IF R1 EQ #0 THEN LET R1 := R1 + #1
;NOW
;INTERLEAVE R1 INTERLEAVE FACTOR
-----
:4 TO 1 EXT & INTERNAL 4 8
:4 TO 1 EXT & NO INT 4 4
:2 TO 1 EXT & INTERNAL 2 4
:2 TO 1 EXT & NO INT 2 2
: NO EXT & INTERNAL 1 2
: NO EXT & NO INT 1 0
;
;SO
;R1 - 1 OR 2 OR 4 = '# OF CSR'S ON THIS BANK'
CLR R4
MOVB CONFIG+4(R0),R2
MOV #8.,R3
ROR R2 ;COUNT CSR'S IN THIS BANK
ADC R4
SOB R3,1$

```

1\$:

2616
2617 013562
2618 013574
2619 013602 104064
2620 013604
2621 013604
2622 013604
2623 013620

;IF # OF CSR'S IS WRONG.
IF R4 NE R1 AND CONFGERROR IS FALSE
SET CONFGERROR
ERROR +64
END ;OF IF R4
END ;OF IF ACFLAG
END ;OF FOR BANK
END ;OF IF CPUBIT

2626 013620

2627 013620 005037 002466
2628 013624 005037 002470
2629 013630
2630 013632
2631 013642
2632 013656
2633 013676
2634 013702
2635 013702
2636 013702
2637 013714 006337 002466
2638 013720 006337 002466
2639 013724 006337 002466
2640 013730 006337 002466
2641 013734 006337 002470
2642 013740 006337 002470
2643 013744 006337 002470
2644 013750 006337 002470
2645 013754 005237 002516
2646 013760 006337 002516
2647 013764 006337 002516
2648 013770 006337 002516
2649 013774 006337 002516
2650 014000
2651 014014
2652 014032
2653 014036
2654 014044
2655 014050
2656 014056
2657 014062
2658 014070
2659 014074
2660 014112 004737 035402
2661 014116

```
SUBSTST <<PRINT CONFIGURATION DETAILS>>  
:.....  
: *SUBTEST PRINT CONFIGURATION DETAILS  
:.....  
CLR MJSIZE  
CLR MKSIZE  
FOR R1 := #0 TO #167*3*2 BY #6  
  IF (PUBIT SET.IN CONFIG(R1)  
    IF #BIT14!BIT13 OFF.IN CONFIG(R1) THEN LET MJSIZE := MJSIZE + #1  
    IF #BIT14 OFF.IN CONFIG(R1) AND #BIT13 SET.IN CONFIG(R1)  
      LET MKSIZE := MKSIZE + #1  
    END ;OF IF MK11 MEMORY  
  END ;OF IF ACCESSABLE BY CPU  
END ;OF FOR ALL BANKS IN TABLE  
ASL MJSIZE  
ASL MJSIZE  
ASL MJSIZE  
ASL MJSIZE ;MJSIZE := MJSIZE * 16.  
ASL MKSIZE  
ASL MKSIZE  
ASL MKSIZE ;MKSIZE := MKSIZE * 16.  
INC UNITOP  
ASL UNITOP  
ASL UNITOP  
ASL UNITOP  
ASL UNITOP ;UNITOP := UNITOP * 16.  
LET I := MJSIZE + MKSIZE  
IF I LT UNITOP THEN LET I := UNITOP  
TYPE $CRLF  
TYPDEC I  
TYPE MSG070  
TYPDEC MJSIZE  
TYPE MSG071  
TYPDEC MKSIZE  
TYPE MSG072  
IF #SW6 SET.IN @SWP OR CONFGERROR IS TRUE  
  CALL PCONFIG  
END ;OF IF #SW6
```

2664 014116
 2665 014116
 2666 014132 005037 002534
 2667 014136 012700 075164
 2668 014142
 2669 014144
 2670 014152 111001
 2671 014154 042701 177400
 2672 014160
 2673 014166 000261
 2674 014170
 2675 014172 000241
 2676 014174
 2677 014174 006101
 2678 014176 005201
 2679 014200 006301
 2680 014202 006301
 2681 014204 006301
 2682 014206 006301
 2683 014210 163701 002534
 2684 014214 010137 002534
 2685 014220
 2686 014230 060137 002522
 2687 014234
 2688 014234
 2689 014244 060137 002524
 2690 014250
 2691 014250 062700 000004
 2692 014254
 2693 014254
 2694 014264
 2695 014304 104051
 2696 014306
 2697
 2698
 2699 014306 013700 002730
 2700 014312 005200
 2701 014314
 2702 014322 010037 002050
 2703 014326 013737 075234 002056
 2704 014334 104065
 2705 014336
 2706 014336
 2707
 2708 014336 004737 015104

```

SUBTST <<CHECK APT SIZING>>
:*****
:*SUBTEST    CHECK APT SIZING
:*****
IF APTFLAG IS TRUE AND APTSIZE IS TRUE
  CLR    TEMP
  MOV    #SMAMS1,R0
  FOR R2 := #0 TO #4
    IFB 1(R0) NE #0
      MOVB (R0),R1
      BIC    #177400,R1
      IF 2(R0) LT #0
        SEC
      ELSE
        CLC
      END ;OF IF 2(R0)
      ROL    R1
      INC    R1
      ASL    R1
      ASL    R1
      ASL    R1
      ASL    R1
      SUB    TEMP,R1
      MOV    R1,TEMP
      IFB 1(R0) EQ #1
        ADD    R1,APTCORE
      END ;OF IFB 1(R0)
      IFB 1(R0) EQ #4
        ADD    R1,APTMOS
      END ;OF IFB 1(R0)
      ADD    #4,R0
      END ;OF IFB 1(R0)
    END ;OF FOR R2
  IF APTCORE NE MJSIZE OR APTMOS NE MKSIZE
    ERROR    +51
  END ;OF IF APTCORE

;CHECK FOR CORRECT NUMBER OF CPU'S
MOV    SLAVES,R0
INC R0
IF $DDW6 NE R0
  MOV R0,GOOD
  MOV $DDW6,BAD
  ERROR +65
END ;OF $DDW6
END ;OF IF APTFLAG

CALL    DOBACK
;WRITE BACKGROUND PATTERN
    
```

;TO COMPENSATE FOR 4 BANKS BEING (0-3)

;R0 = 1, 2, 3, OR 4

2710 014342
2711 014344 000004 002332
2712 014350 017700 166412
2713 014354 042700 177761
2714 014360 004770 014370
2715 014364 000137 014410
2716 014370 015204
2717 014372 015320
2718 014374 015434
2719 014376 015572
2720 014400 015730
2721 014402 016066
2722 014404 016246
2723 014406 016404
2724
2725

```
LOOP: NEWTST <<DIAGNOSTIC MODE DISPATCH ROUTINE>>
:*****
:*TEST 5      DIAGNOSTIC MODE DISPATCH ROUTINE
:*****
TST5:  SCOPE
      CLR      CONTFLAG
      MOV      @SWR,R0      ;GET SWITCHES
      BIC      #^C16,R0     ;MASK TO ONLY MODE BITS
      CALL     @DISPTBL(R0) ;DISPATCH TO ROUTINE THROUGH NEXT TABLE
      JMP      MEMDONE      ;GO TO NEXT TEST
DISPTBL:BAFPAF ;MODE 0;BANKS FORWARD, PATTERNS FORWARD
        BAFPAR ;MODE 1;BANKS FORWARD, PATTERNS REVERSE
        BAWPAF ;MODE 2;BANKS WORST FIRST, PATTERNS FORWARD
        BAWPAR ;MODE 3;BANKS WORST FIRST, PATTERNS REVERSE
        PAFBAF ;MODE 4;PATTERNS FORWARD, BANKS FORWARD
        PAFBAW ;MODE 5;PATTERNS FORWARD, BANKS WORST FIRST
        PARBAF ;MODE 6;PATTERNS REVERSE, BANKS FORWARD
        PARBAW ;MODE 7;PATTERNS REVERSE, BANKS WORST FIRST
        ;**NOTE** MARGINS FOLLOW PATTERNS (FORWARD IS (0,2,3,4,5))
        ;(REVERSE IS (5,4,3,2,0))
```

2729 014410 004737 015104
 2730 014414

MEMDONE:CALL DOBACK ;CHECK BACKGROUND PATTERN
 NEWTST<<UNIQUE BANK TEST>>

 :*TEST 6 UNIQUE BANK TEST

014414 000004
 2731
 2732
 2733 014416
 2734 014424
 2735 014440 004737 024370
 2736 014444
 2737 014452 005037 002116
 2738 014456
 2739
 2740 014456

TST6: SCOPE
 ;MAKE SURE THAT EACH BANK CAN HAVE UNIQUE DATA
 ;WRITE AND READ THE BANK NUMBER IN EACH BANK (EXCEPT WHERE THE PROGRAM IS)
 IF SELONLY IS FALSE
 SET HEADER,MU1
 CALL MTOO27
 SET HEADER
 CLR MUT
 END ;OF IF SELONLY

NEWTST <<FORCE ADDRESS PARITY ERRORS>>

 :*TEST 7 FORCE ADDRESS PARITY ERRORS

014456 000004
 2741
 2742
 2743
 2744
 2745
 2746
 2747
 2748 014460
 2749 014466 012700 060000
 2750 014472 012737 000004 002100
 2751 014500
 2752 014506
 2753 014512 004737 042422
 2754 014516
 2755 014524 005037 002074
 2756 014530 004737 026042
 2757 014534
 2758 014544 104035
 2759 014546
 2760 014546
 2761 014546
 2762 014562 005037 002100
 2763 014566
 2764 014566 000405
 2765
 2766
 2767
 2768 014570 012737 000002 177750 ADDPAR: MOV #BIT1,MAINT
 2769 014576 005710 TST (R0)
 2770 014600 000207 RETURN

TST7: SCOPE
 ;THIS MAKES SURE THAT ALL ACCESSABLE MEMORY LOCATIONS WILL GIVE A
 ;PARITY TRAP IF I FORCE A MEMORY BUSS ADDRESS PARITY ERROR BY
 ;USING THE MAINTENANCE REGISTER.
 ;
 ;WHEN DONE EVERY ADDRESS PARITY ERROR LED IN EVERY MEMORY BOX
 ;:(MK11'S, MKA11'S, AND MJ11'S) SHOULD BE LITE.
 ;YOU CAN ONLY TURN THEM OFF BY TURNING OFF POWER TO THE BOX'S.
 IF SELONLY IS FALSE
 MOV #FIRST,R0
 MOV #4,NOPAR ;INDICATE PARITY ACTION
 BMOV ADDPAR
 FOR BANK := #0 TO #167
 CALL EXBANK
 IF ACFLAG IS TRUE
 CLR PARCNT
 CALL SUPD01
 IF PARCNT NE #1
 ERROR +35
 END ;OF IF PARCNT
 END ;OF IF ACFLAG
 END ;OF FOR BANK
 CLR NOPAR ;INDICATE PARITY ACTION
 END ;OF IF SELONLY
 BR SUBAAU
 ;THESE 3 INSTRUCTIONS ARE MOVED TO THE USER PAR'S IN ORDER TO
 ;CAUSE ABORTS FROM THE BANK UNDER TEST VICE THE PROGRAM SPACE
 ADDPAR: MOV #BIT1,MAINT ;V177640 ;CREATE ADDRESS PARITY ERROR
 TST (R0) ;V177646 ;THIS WILL ABORT & INCREMENT PARCNT
 RETURN ;V177650

2773 014602
2774 014610
2775 014620 104050
2776 014622
2777 014622
2778
2779 014622
2780 014630 005137 002744
2781 014634 004737 015104
2782 014640 005037 002502
2783 014644
2784 014656

2785 014656 004737 024754

```
SUBAAU: IF SBFLAG IS TRUE
        IF LASTERROR EQ $ERTL
          ERROR +50
        END ;OF IF LASTERROR
      END ;OF IF SBFLAG

      SET WRITEONLY
      COM SOFTPAT
      CALL DOBACK ;RESTORE BACKGROUND PATTERN
      CLR WRITEONLY
      IF MULTIPOST IS TRUE THEN JUMPTO MAST01
FLUSH: SUBTST <<FLUSH OUT DBE'S>>
:*****
:*SUBTEST FLUSH OUT DBE'S
:*****
      CALL MT0030
```

```

2789          .SBTTL  END OF PASS ROUTINE
2790          :*****
2791          :*INCREMENT THE PASS NUMBER ($PASS)
2792          :*INDICATE END-OF-PROGRAM AFTER EACH PASSES THRU THE PROGRAM
2793          :*TYPE 'END PASS #XXXXX' (WHERE XXXXX IS A DECIMAL NUMBER)
2794          :*IF THERES A MONITOR GO TO IT
2795          :*IF THERE ISN'T JUMP TO LOOP
2796 014662 005037 002022  $EOP:  CLR      SBFLAG
2797 014666 005037 002542      CLR      FSINFLAG
2798 014672 013737 002754 002020  MOV      $ERTTL, LASTERROR
2799 014700 005237 075142      INC      $PASS          ;; INCREMENT THE PASS NUMBER
2800 014704 042737 100000 075142  BIC      #100000, $PASS ;; DON'T ALLOW A NEG. NUMBER
2801 014712      TYPE  MSG077          ;; TYPE 'END PASS #'
2802 014716      IF #SW11 SET. IN @SWR OR QVFLAG IS TRUE
2803 014734      TYPE  MSG035          ;QV
2804 014740 005037 002440      CLR      QVFLAG
2805 014744      END ;OF IF SW11
2806 014744      TYPDEC $PASS
2807 014752 013700 000042      MOV      42, RO          ;; GET MONITOR ADDRESS
2808 014756 001430      BEQ     $DOAGAIN        ;; BRANCH IF NO MONITOR
2809 014760 022700 002000  $ZAP42: CMP      #STACK, RO    ;ARE WE UNDER RT11
2810 014764 001425      BEQ     $DOAGAIN        ;YES - BRANCH
2811      ;WE ARE UNDER (HEAVEN HELP US) XXDP!
2812 014766      PUSH   RO
2813 014770 004737 043554      CALL   SHUTUP
2814 014774      POP    RO
2815 014776 000005      RESET          ;; CLEAR THE WORLD
2816 015000 004710      $ENDAD: CALL   (RO)          ;; GO TO MONITOR
2817 015002 000240      NOP           ;; SAVE ROOM
2818 015004 000240      NOP           ;; FOR
2819 015006 000240      NOP           ;; ACT11
2820 015010      $DOAGN: ;UNDO SHUTUP STUFF
2821      ; RESTORE STACK
2822      ; ENERGIZE UNIBUS MAP & 22 BIT ADDRESSING
2823      ; ENERGIZE MEMORY MANAGEMENT
2824      ; PUT LOADERS BACK HOME
2825 015010 013706 002706      MOV     KSTACK, SP
2826 015014 052737 000060 172516  BIS     #BIT5!BIT4, MMR3
2827 015022 104420      ENERGIZE          ;TURN ON MEMORY MANAGEMENT
2828 015024 013700 002710      MOV     LOADHOME, RO    ;DESTINATION BANK
2829 015030 012701 000001      MOV     #1, R1          ;SOURCE BANK
2830 015034 004737 042072      CALL   BANKMOV
2831 015040      $DOAGAIN: IF $USWR EQ $PASS ;IF APT LIMITING # OF PASSES
2832 015050 012701 000050  APHANG: MOV   #50, R1
2833 015054 077001 2$:      SOB    RO, 2$
2834 015056 062737 000001 075144  ADD    #1, $DEVCT
2835 015064 005537 075146      ADC    $UNIT
2836 015070 077107      SOB    R1, 2$
2837 015072 005237 075142      INC    $PASS
2838 015076 000764      BR     APHANG
2839 015100      END ;OF IF $USWR
2840 015100 000137 014342      JMP    LOOP          ;RETURN
    
```

2843 015104

DOBACK: SUBST <<WRITE BACKGROUND PATTERNS>>

: *SUBTEST WRITE BACKGROUND PATTERNS

2844 015104 005037 002120
2845 015110
2846 015114 004737 042422
2847 015120
2848 015134
2849 015150 004737 021222
2850 015154 005037 002116
2851 015160
2852 015166
2853 015166
2854 015202 000207

CLR PATTERN
FOR BANK := #0 TO #167
CALL EXBANK
IF ACFLAG IS TRUE AND PFLAG IS FALSE
SET HEADER,MUT
CALL MKTEST ;CALL MJTEST WOULD ALSO WORK
CLR MUT
SET HEADERR
END ;OF IF ACFLAG
END ;OF FOR BANK
RETURN

```

2857
2858
2859 015204

2860 015204 005037 002106
2861
2862 015210 004737 042422
2863 015214 005737 002124
2864 015220 001417
2865 015222 005737 002132
2866 015226 001014
2867 015230 005037 002120
2868
2869 015234 005037 002112
2870
2871 015240 004737 016564
2872
2873 015244 004737 043006
2874 015250 001373
2875
2876 015252 004737 042746
2877 015256 001366
2878
2879 015260 004737 042772
2880 015264 001351
2881
2882 015266 005737 002134
2883 015272 001401
2884 015274 000207
2885 015276 004737 041130
2886 015302
2887
2888 015306 004737 015204
2889 015312 004737 041604
2890 015316 000207

```

```

.SBTTL MTEST MODES
BAFPAF: SUBST <<BANKS FORWARD,PATTERNS FORWARD **RECURSIVE**>>
:*****
:*SUBTEST BANKS FORWARD,PATTERNS FORWARD **RECURSIVE**
:*****
CLR BANK ;SET BANK TO 0
:START OF BANK LOOP
1$: CALL EXBANK ;EXAMINE BANK
TST ACFLAG ;CAN WE ACCESS THIS BANK?
BEQ 4$ ;NO - GO TO BANK LOOP TERMINATION
TST RRFLAG ;RELOCATION REQUIRED?
BNE 4$ ;YES - GO TO BANK LOOP TERMINATION
CLR PATTERN ;SET PATTERN TO 0
:START OF PATTERN LOOP
2$: CLR MARGIN ;SET MARGIN TO 0
:START OF MARGIN LOOP
3$: CALL MTEST ;GO TEST CORRECT MEMORY
:TERMINATION OF MARGIN LOOP
CALL INCMAR ;NEXT HIGHER MARGIN
BNE 3$ ;IF NOT DONE - LOOP ON ' MARGIN
:TERMINATION OF PATTERN LOOP
CALL INCPAT ;GO SEE IF THIS IS THE LAST PATTERN
BNE 2$ ;NO - LOOP ON THIS PATTERN
:TERMINATION OF BANK LOOP
4$: CALL INCBNK ;NEXT HIGHER BANK
BNE 1$ ;IF NOT DONE - LOOP ON THIS BANK
:END OF LOOPS
TST RLFLAG ;HAVE WE BEEN RELOCATED?
BEQ 5$ ;NO - SKIP
RETURN ;YES - RETURN
5$: CALL RELOCATE ;MOVE & MAP PROGRAM
ON.ERROR THEN $RETURN
:**NOTE** RECURSIVE CALL
CALL BAFPAF ;CALL SELF
CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM
RETURN

```


2893 015320

BAFPAR: SUBST <<BANKS FORWARD,PATTERNS REVERSE **RECURSIVE**>>
:*****
:SUBTEST BANKS FORWARD,PATTERNS REVERSE **RECURSIVE**
:*****

2894 015320 005037 002106
2895
2896 015324 004737 042422
2897 015330 005737 002124
2898 015334 001417
2899 015336 005737 002132
2900 015342 001014
2901 015344 004737 042762
2902
2903 015350 004737 043212
2904
2905 015354 004737 016564
2906
2907 015360 004737 043152
2908 015364 100373
2909
2910 015366 005337 002120
2911 015372 100366
2912
2913 015374 004737 042772
2914 015400 001351
2915
2916 015402 005737 002134
2917 015406 001401
2918 015410 000207
2919 015412 004737 041130
2920 015416
2921
2922 015422 004737 015320
2923 015426 004737 041604
2924 015432 000207

CLR BANK ;SET BANK TO 0
:START OF BANK LOOP
1\$: CALL EXBANK ;EXAMINE BANK
TST ACFLAG ;CAN WE ACCESS THIS BANK?
BEQ 4\$;NO - GO TO BANK LOOP TERMINATION
TST RRFLAG ;RELOCATION REQUIRED?
BNE 4\$;YES - GO TO BANK LOOP TERMINATION
CALL SETPAT ;SET HIGH PATTERN FOR CORRECT MEMORY
:START OF PATTERN LOOP
2\$: CALL SETMAR ;SET HIGH MARGINS (IF NOT INHIBITED)
:START OF MARGIN LOOP
3\$: CALL MTEST ;GO TEST CORRECT MEMORY
:TERMINATION OF MARGIN LOOP
CALL DECMAR ;NEXT LOWER MARGIN
BPL 3\$;IF NOT DONE - LOOP ON THIS MARGIN
:TERMINATION OF PATTERN LOOP
DEC PATTERN ;IS THIS THE LAST PATTERN?
BPL 2\$;NO - LOOP ON THIS PATTERN
:TERMINATION OF BANK LOOP
4\$: CALL INCBNK ;NEXT HIGHER BANK
BNE 1\$;IF NOT DONE - LOOP ON THIS BANK
:END OF LOOPS
TST RLFLAG ;HAVE WE BEEN RELOCATED?
BEQ 5\$;NO - SKIP
RETURN ;YES - RETURN
5\$: CALL RELOCATE ;MOVE & MAP PROGRAM
ON.ERROR THEN \$RETURN
:**NOTE** RECURSIVE CALL
CALL BAFPAR ;CALL SELF
CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM
RETURN

2927 015434

BAWPAF: SUBTST <<BANKS WORST FIRST,PATTERNS FORWARD **RECURSIVE**>>
:*****
: *SUBTEST BANKS WORST FIRST,PATTERNS FORWARD **RECURSIVE**
:*****

2928 015434 005037 002106
2929
2930 015440 004737 042422
2931 015444 005737 002124
2932 015450 001422
2933 015452 005737 002136
2934 015456 001417
2935 015460 005737 002132
2936 015464 001014
2937 015466 005037 002120
2938
2939 015472 005037 002112
2940
2941 015476 004737 016564
2942
2943 015502 004737 043006
2944 015506 001373
2945
2946 015510 004737 042746
2947 015514 001366
2948
2949 015516 004737 042772
2950 015522 001346
2951
2952 015524 005137 002712
2953 015530 001003
2954
2955 015532 004737 015434
2956 015536 000207
2957 015540 005737 002134
2958 015544 001401
2959 015546 000207
2960 015550 004737 041130
2961 015554
2962
2963 015560 004737 015434
2964 015564 004737 041604
2965 015570 000207

CLR BANK ;SET BANK TO 0
:START OF BANK LOOP
1\$: CALL EXBANK ;EXAMINE BANK
TST ACFLAG ;CAN WE ACCESS THIS BANK?
BEQ 4\$;NO - GO TO BANK LOOP TERMINATION
TST BMFLAG ;IS THIS BAD MEMORY (WORST FIRST)?
BEQ 4\$;NO - GO TO BANK LOOP TERMINATION
TST RRFLAG ;RELOCATION REQUIRED?
BNE 4\$;YES - GO TO BANK LOOP TERMINATION
CLR PATTERN ;SET PATTERN TO 0
:START OF PATTERN LOOP
2\$: CLR MARGIN ;SET MARGIN TO 0
:START OF MARGIN LOOP
3\$: CALL MTEST ;GO TFST CORRECT MEMORY
:TERMINATION OF MARGIN LOOP
CALL INCMAR ;NEXT HIGHER MARGIN
BNE 3\$;IF NOT DONE - LOOP ON THIS MARGIN
:TERMINATION OF PATTERN LOOP
CALL INCPAT ;GO SEE IF THIS IS THE LAST PATTERN
BNE 2\$;NO - LOOP ON THIS PATTERN
:TERMINATION OF BANK LOOP
4\$: CALL INCBNK ;NEXT HIGHER BANK
BNE 1\$;IF NOT DONE - LOOP ON THIS BANK
:END OF LOOPS
COM WORST ;IS THIS AN EVEN NUMBERED PASS?
BNE 5\$;YES - SKIP
: **NOTE** RECURSIVE CALL
CALL BAWPAF ;CALL SELF
RETURN
5\$: TST RLFLAG ;HAVE WE BEEN RELOCATED?
BEQ 6\$;NO - SKIP
RETURN ;YES - RETURN
6\$: CALL RELOCATE ;MOVE & MAP PROGRAM
ON.ERROR THEN \$RETURN
: **NOTE** RECURSIVE CALL
CALL BAWPAF ;CALL SELF
CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM
RETURN

2968 015572

BAWPAR: SUBST <<BANKS WORST FIRST,PATTERNS REVERSE **RECURSIVE**>>
:*****
:SUBTEST BANKS WORST FIRST,PATTERNS REVERSE **RECURSIVE**
:*****

2969 015572 005037 002106

CLR BANK ;SET BANK TO 0

2970

;START OF BANK LOOP

2971 015576 004737 042422

1\$:

CALL EXBANK ;EXAMINE BANK

2972 015602 005737 002124

TST ACFLAG ;CAN WE ACCESS THIS BANK?

2973 015606 001422

BEQ 4\$;NO - GO TO BANK LOOP TERMINATION

2974 015610 005737 002136

TST BMFLAG ;IS THIS BAD MEMORY (WORST FIRST)

2975 015614 001417

BEQ 4\$;NO - GO TO BANK LOOP TERMINATION

2976 015616 005737 002132

TST RRFLAG ;RELOCATION REQUIRED?

2977 015622 001014

BNE 4\$;YES - GO TO BANK LOOP TERMINATION

2978 015624 004737 042762

CALL SETPAT ;SET HIGH PATTERN FOR CORRECT MEMORY

2979

;START OF PATTERN LOOP

2980 015630 004737 043212

2\$:

CALL SETMAR ;SET HIGH MARGINS (IF NOT INHIBITED)

2981

;START OF MARGIN LOOP

2982 015634 004737 016564

3\$:

CALL MTEST ;GO TEST CORRECT MEMORY

2983

;TERMINATION OF MARGIN LOOP

2984 015640 004737 043152

CALL DECMAR ;NEXT LOWER MARGIN

2985 015644 100373

BPL 3\$;IF NOT DONE - LOOP ON THIS MARGIN

2986

;TERMINATION OF PATTERN LOOP

2987 015646 005337 002120

DEC PATTERN ;IS THIS THE LAST PATTERN?

2988 015652 100366

BPL 2\$;NO - LOOP ON THIS PATTERN

2989

;TERMINATION OF BANK LOOP

2990 015654 004737 042772

4\$:

CALL INCBNK ;NEXT HIGHER BANK

2991 015660 001346

BNE 1\$;IF NOT DONE - LOOP ON THIS BANK

2992

;END OF LOOPS

2993 015662 005137 002712

COM WORST ;IS THIS AN EVEN NUMBERED PASS?

2994 015666 001003

BNE 5\$;YES - SKIP

2995

***NOTE** RECURSIVE CALL

2996 015670 004737 015572

CALL BAWPAR ;CALL SELF

2997 015674 000207

RETURN

2998 015676 005737 002134

5\$:

TST RLFLAG ;HAVE WE BEEN RELOCATED?

2999 015702 001401

BEQ 6\$;NO - SKIP

3000 015704 000207

RETURN ;YES - RETURN

3001 015706 004737 041130

6\$:

CALL RELOCATE ;MOVE & MAP PROGRAM

3002 015712

ON.ERROR THEN \$RETURN

3003

***NOTE** RECURSIVE CALL

3004 015716 004737 015572

CALL BAWPAR ;CALL SELF

3005 015722 004737 041604

CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM

3006 015726 000207

RETURN

```

3010 015730      PAFBAF: SUBTST  <<PATTERNS FORWARD,BANKS FORWARD      **RECURSIVE***>>
:*****
:*SUBTST      PATTERNS FORWARD,BANKS FORWARD      **RECURSIVE**
:*****
3011 015730 005037 002120      CLR      PATTERN      ;SET PATTERN TO 0
3012      ;START OF PATTERN LOOP
3013 015734 005037 002106      1$: CLR      BANK      ;SET BANK TO 0
3014      ;START OF BANK LOOP
3015 015740 004737 042422      2$: CALL     EXBANK     ;EXAMINE BANK
3016 015744 004737 042730      CALL     BANKOK      ;CORRECT MEMORY FOR THIS BANK?
3017 015750 001015      BNE      4$          ;NO - GO TO BANK LOOP TERMINATOR
3018 015752 005737 002124      TST     ACFLAG      ;CAN WE ACCESS THIS BANK?
3019 015756 001412      BEQ      4$          ;NO - GO TO BANK LOOP TERMINATION
3020 015760 005737 002132      TST     RRFLAG      ;RELOCATION REQUIRED?
3021 015764 001007      BNE      4$          ;YES - GO TO BANK LOOP TERMINATION
3022 015766 005037 002112      CLR     MARGIN      ;SET MARGIN TO 0
3023      ;START OF MARGIN LOOP
3024 015772 004737 016564      3$: CALL     MTEST     ;GO TEST CORRECT MEMORY
3025      ;TERMINATION OF MARGIN LOOP
3026 015776 004737 043006      CALL     INCMAR     ;NEXT HIGHER MARGIN
3027 016002 001373      BNE     3$          ;IF NOT DONE - LOOP ON THIS MARGIN
3028      ;TERMINATION OF BANK LOOP
3029 016004 004737 042772      4$: CALL     INCBANK   ;NEXT HIGHER BANK
3030 016010 001353      BNE     2$          ;IF NOT DONE - LOOP ON THIS BANK
3031      ;TERMINATION OF PATTERN LOOP
3032 016012 004737 042746      CALL     INCRPT     ;NEXT HIGHER PATTERN
3033 016016 001346      BNE     1$          ;OK - LOOP; ELSE CONTINUE
3034      ;END OF LOOPS
3035 016020 005137 002140      COM     TMFLAG      ;COMPLEMENT TYPE OF MEMORY
3036      ;IS THIS AN EVEN NUMBER PASS?
3037 016024 001403      BEQ     5$          ;YES - SKIP
3038      ;**NOTE** RECURSIVE CALL
3039 016026 004737 015730      CALL     PAFBAF     ;CALL SELF
3040 016032 000207      RETURN
3041 016034 005737 002134      5$: TST     RLFLAG     ;HAVE WE BEEN RELOCATED?
3042 016040 001401      BEQ     6$          ;NO - SKIP
3043 016042 000207      RETURN             ;YES - RETURN
3044 016044 004737 041130      6$: CALL     RELOCATE  ;MOVE & MAP PROGRAM
3045 016050      ON.ERROR THEN $RETURN
3046      ;**NOTE** RECURSIVE CALL
3047 016054 004737 015730      CALL     PAFBAF     ;CALL SELF
3048 016060 004737 041604      CALL     UNRELOCATE ;UNMOVE & UNMAP PROGRAM
3049 016064 000207      RETURN
    
```

```

3052 016066 PAFBAW: SUBST <<PATTERNS FORWARD,BANKS WORST FIRST **RECURSIVE***>>
:*****
:*SUBTEST PATTERNS FORWARD,BANKS WORST FIRST **RECURSIVE**
:*****
3053 016066 005037 002120 CLR PATTERN ;SET PATTERN TO 0
3054 :START OF PATTERN LOOP
3055 016072 005037 002106 1$: CLR BANK ;SET BANK TO 0
3056 :START OF BANK LOOP
3057 016076 004737 042422 2$: CALL EXBANK ;EXAMINE BANK
3058 016102 004737 042730 CALL BANKOK ;CORRECT MEMORY FOR THIS BANK?
3059 016106 001020 BNE 4$ ;NO - GO TO BANK LOOP TERMINATOR
3060 016110 005737 002124 TST ACFLAG ;CAN WE ACCESS THIS BANK?
3061 016114 001415 BEQ 4$ ;NO - GO TO BANK LOOP TERMINATION
3062 016116 005737 002136 TST BMFLAG ;IS THIS BAD MEMORY (WORST FIRST)
3063 016122 001412 BEQ 4$ ;NO - GO TO BANK LOOP TERMINATION
3064 016124 005737 002132 TST RRFLAG ;RELOCATION REQUIRED?
3065 016130 001007 BNE 4$ ;YES - GO TO BANK LOOP TERMINATION
3066 016132 005037 002112 CLR MARGIN ;SET MARGIN TO 0
3067 :START OF MARGIN LOOP
3068 016136 004737 016564 3$: CALL MTEST ;GO TEST CORRECT MEMORY
3069 :TERMINATION OF MARGIN LOOP
3070 016142 004737 043006 CALL INCMAR ;NEXT HIGHER MARGIN
3071 016146 001373 BNE 3$ ;IF NOT DONE - LOOP ON THIS MARGIN
3072 :TERMINATION OF BANK LOOP
3073 016150 004737 042772 4$: CALL INCBNK ;NEXT HIGHER BANK
3074 016154 001350 BNE 2$ ;IF NOT DONE - LOOP ON THIS BANK
3075 :TERMINATION OF PATTERN LOOP
3076 016156 004737 042746 CALL INCRPT ;NEXT HIGHER PATTERN
3077 016162 001343 BNE 1$ ;OK - LOOP; ELSE CONTINUE
3078 :END OF LOOPS
3079 016164 005137 002140 COM TMFLAG ;COMPLEMENT TYPE OF MEMORY
3080 :IS THIS AN EVEN NUMBER PASS?
3081 016170 001403 BEQ 5$ ;YES - SKIP
3082 :**NOTE** RECURSIVE CALL
3083 016172 004737 016066 CALL PAFBAW ;CALL SELF
3084 016176 000207 RETURN
3085 016200 005137 002712 5$: COM WORST ;4TH PASS?
3086 016204 001003 BNE 6$ ;YES - SKIP
3087 :**NOTE** RECURSIVE CALL
3088 016206 004737 016066 CALL PAFBAW ;CALL SELF
3089 016212 000207 RETURN
3090 016214 005737 002134 6$: TST RLFLAG ;HAVE WE BEEN RELOCATED?
3091 016220 001401 BEQ 7$ ;NO - SKIP
3092 016222 000207 RETURN ;YES - RETURN
3093 016224 004737 041130 7$: CALL RELOCATE ;MOVE & MAP PROGRAM
3094 016230 ON.ERROR THEN $RETURN
3095 :**NOTE** RECURSIVE CALL
3096 016234 004737 016066 CALL PAFBAW ;CALL SELF
3097 016240 004737 041604 CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM
3098 016244 000207 RETURN
    
```

3101 016246
 3102 016246 004737 042762
 3103
 3104 016252 005037 002106
 3105
 3106 016256 004737 042422
 3107 016262 004737 042730
 3108 016266 001015
 3109 016270 005737 002124
 3110 016274 001412
 3111 016276 005737 002132
 3112 016302 001007
 3113 016304 004737 043212
 3114
 3115 016310 004737 016564
 3116
 3117 016314 004737 043152
 3118 016320 100373
 3119
 3120 016322 004737 042772
 3121 016326 001353
 3122
 3123 016330 005337 002120
 3124 016334 100346
 3125
 3126 016336 005137 002140
 3127
 3128 016342 001403
 3129
 3130 016344 004737 016246
 3131 016350 000207
 3132 016352 005737 002134
 3133 016356 001401
 3134 016360 000207
 3135 016362 004737 041130
 3136 016366
 3137
 3138 016372 004737 016246
 3139 016376 004737 041604
 3140 016402 000207

```

PARBAF: SUBST <<PATTERNS REVERSE,BANKS FORWARD **RECURSIVE**>>
:*****
:*SUBTEST PATTERNS REVERSE,BANKS FORWARD **RECURSIVE**
:*****
CALL HIPAT ;SET HIGHEST PATTERNS
:START OF PATTERN LOOP
1$: CLR BANK ;SFT BANK TO 0
:START OF BANK LOOP
2$: CALL EXBANK ;EXAMINE BANK
CALL BANKOK ;CORRECT MEMORY FOR THIS BANK?
BNE 4$ ;NO - GO TO BANK LOOP TERMINATOR
TST ACFLAG ;CAN WE ACCESS THIS BANK?
BEQ 4$ ;NO - GO TO BANK LOOP TERMINATION
TST RRFLAG ;RELOCATION REQUIRED?
BNE 4$ ;YES - GO TO BANK LOOP TERMINATION
CALL SETMAR ;SET HIGH MARGINS (IF NOT INHIBITED)
:START OF MARGIN LOOP
3$: CALL MTEST ;GO TEST CORRECT MEMORY
:TERMINATION OF MARGIN LOOP
CALL DECMAR ;NEXT LOWER MARGIN
BPL 3$ ;IF NOT DONE - LOOP ON THIS MARGIN
:TERMINATION OF BANK LOOP
4$: CALL INCBNK ;NEXT HIGHER BANK
BNE 2$ ;IF NOT DONE - LOOP ON THIS BANK
:TERMINATION OF PATTERN LOOP
DEC PATTERN ;NEXT LOWER PATTERN
BPL 1$ ;OK - LOOP; ELSE CONTINUE
:END OF LOOPS
COM TMFLAG ;COMPLEMENT TYPE OF MEMORY
BEQ 5$ ;IS THIS AN EVEN NUMBER PASS?
;YES - SKIP
:***NOTE** RECURSIVE CALL
CALL PARBAF ;CALL SELF
RETURN
5$: TST RLFLAG ;HAVE WE BEEN RELOCATED?
BEQ 6$ ;NO - SKIP
RETURN ;YES - RETURN
6$: CALL RELOCATE ;MOVE & MAP PROGRAM
ON.ERROR THEN $RETURN
:***NOTE** RECURSIVE CALL
CALL PARBAF ;CALL SELF
CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM
RETURN
    
```

3143 016404

```

PARBAW: SUBTST <<PATTERNS REVERSE,BANKS WORST FIRST **RECURSIVE**>>
:*****
:SUBTST PATTERNS REVERSE,BANKS WORST FIRST **RECURSIVE**
:*****
3144 016404 004737 042762 CALL HIPAT ;SET HIGHEST PATTERN
3145 :START OF PATTERN LOOP
3146 016410 005037 002106 1$: CLR BANK ;SET BANK TO 0
3147 :START OF BANK LOOP
3148 016414 004737 042422 2$: CALL EXBANK ;EXAMINE BANK
3149 016420 004737 042730 CALL BANKOK ;CORRECT MEMORY FOR THIS BANK?
3150 016424 001020 BNE 4$ ;NO - GO TO BANK LOOP TERMINATOR
3151 016426 005737 002124 TST ACFLAG ;CAN WE ACCESS THIS BANK?
3152 016432 001415 BEQ 4$ ;NO - GO TO BANK LOOP TERMINATION
3153 016434 005737 002136 TST BMFLAG ;IS THIS BAD MEMORY (WORST FIRST)
3154 016440 001412 BEQ 4$ ;NO - GO TO BANK LOOP TERMINATION
3155 016442 005737 002132 TST RRFLAG ;RELOCATION REQUIRED?
3156 016446 001007 BNE 4$ ;YES - GO TO BANK LOOP TERMINATION
3157 016450 004737 043212 CALL SETMAR ;SET HIGH MARGINS (IF NOT INHIBITED)
3158 :START OF MARGIN LOOP
3159 016454 004737 016564 3$: CALL MTEST ;GO TEST CORRECT MEMORY
3160 :TERMINATION OF MARGIN LOOP
3161 016460 004737 043152 CALL DECMAR ;NEXT LOWER MARGIN
3162 016464 100373 BPL 3$ ;IF NOT DONE - LOOP ON THIS MARGIN
3163 :TERMINATION OF BANK LOOP
3164 016466 004737 042772 4$: CALL INCBNK ;NEXT HIGHER BANK
3165 016472 001350 BNE 2$ ;IF NOT DONE - LOOP ON THIS BANK
3166 :TERMINATION OF PATTERN LOOP
3167 016474 005337 002120 DEC PATTERN ;NEXT LOWER PATTERN
3168 016500 100343 BPL 1$ ;OK - LOOP; ELSE CONTINUE
3169 :END OF LOOPS
3170 016502 005137 002140 COM TMFLAG ;COMPLEMENT TYPE OF MEMORY
3171 :IS THIS AN EVEN NUMBER PASS?
3172 016506 001403 BEQ 5$ ;YES - SKIP
3173 :**NOTE** RECURSIVE CALL
3174 016510 004737 016404 CALL PARBAW ;CALL SELF
3175 016514 000207 RETURN
3176 016516 005137 002712 5$: COM WORST ;4TH PASS?
3177 016522 001003 BNE 6$ ;YES - SKIP
3178 :**NOTE** RECURSIVE CALL
3179 016524 004737 016404 CALL PARBAW ;CALL SELF
3180 016530 000207 RETURN
3181 016532 005737 002134 6$: TST RLFLAG ;HAVE WE BEEN RELOCATED?
3182 016536 001401 BEQ 7$ ;NO - SKIP
3183 016540 000207 RETURN ;YES - RETURN
3184 016542 004737 041130 7$: CALL RELOCATE ;MOVE & MAP PROGRAM
3185 016546 ON.ERROR THEN $RETURN
3186 :**NOTE** RECURSIVE CALL
3187 016552 004737 016404 CALL PARBAW ;CALL SELF
3188 016556 004737 041604 CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM
3189 016562 000207 RETURN
    
```

```

3193 016564          MTEST: SUBTST <<SUBR SETUP MEMORY TEST>>
:*****
:*SUBTEST          SUBR    SETUP MEMORY TEST
:*****
3194 016564 015700 002112      MOV     MARGIN,RO
3195 016570 006300              ASL     RO
3196 016572 010037 177750      MOV     RO,MAINT          ;SET MARGINS
3197 016576              SET     HEADER           ;INITIALIZE HEADER MESSAGE TYPEOUT
3198 016604              SET     MUT              ;INDICATE THERE IS A MEMORY UNDER TEST
3199 016612 005037 002362      CLR     PASFLG
3200 016616 005737 002126      TST     MKFLAG           ;MK11?
3201 016622 001410              BEQ     2$               ;NO - SKIP
3202              ;IF CONTFLAG IS FALSE THEN CALL MKCONTROL
3203 016624 005737 002332      TST     CONTFLAG
3204 016630 001002              BNE     1$
3205 016632 004737 016664      CALL    MKCONTROL
3206 016636 004737 021222      1$:    CALL    MKTEST          ;YES - DO MK11 TESTS
3207 016642 000402              BR      3$
3208 016644 004737 021512      2$:    CALL    MJTEST          ;DO MJ11 TESTS
3209 016650 005037 002116      3$:    CLR     MUT              ;NOW - NO MEMORY UNDER TEST
3210 016654              SET     HEADER           ;ALLOW HEADERS NORMAL
3211 016662 000207              RETURN
    
```


3214 016664
 3215
 3216
 3217
 3218
 3219
 3220
 3221
 3222
 3223
 3224
 3225
 3226
 3227 016664
 3228 016674
 3229 016700 112737 000200 002416
 3230 016706 112737 000001 002417
 3231 016714
 3232 016722
 3233 016732 004737 017300
 3234 016736
 3235 016744 004737 017610
 3236 016750
 3237 016750 005037 002424
 3238 016754
 3239 016762 004737 042422
 3240 016766
 3241 017002
 3242 017016 104511
 3243 017020 000241
 3244 017022
 3245 017034
 3246 017036
 3247 017044 004737 017374
 3248 017050
 3249 017052 104424
 3250 017054
 3251 017060 005037 002100
 3252 017064
 3253 017072 005037 002362
 3254 017076
 3255 017102 004737 020114
 3256 017106
 3257 017122 104423
 3258 017124
 3259 017132
 3260 017134
 3261 017134
 3262 017152
 3263 017152
 3264 017152
 3265 017166
 3266 017166
 3267 017174 113737 002420 113625

```

MKCONTROL:SUBTST      <<SUBR TEST MK11 CONTROLLER LOGIC DISPATCH>>
:*****
:*SUBTEST SUBR TEST MK11 CONTROLLER LOGIC DISPATCH
:*****
:THIS MODULE AND THE NEXT FEW PAGES SOLVE THE PROBLEM OF
:HOW TO RUN THE CSR TESTS ON EACH MK11 MEMORY
:
:IN ORDER TO TEST EACH CONTROLLER (2 PER BOX) I MUST DO
:  EACH EXISTING BOX
:    IF ECC IS NOT DISABLED
:      EACH SIDE OF EACH BOX
:        FIND THE ADDRESS OF THIS SIDE (DEPENDS ON INTERLEAVE)
:        FIND A LOCATION THAT HAS NO SINGLE BIT ERRORS
:        RUN ALL CSR TESTS
:      NEXT SIDE
:    NEXT BOX
:  IF SELONLY IS TRUE THEN $RETURN
:  PUSH BANK
:  MOVB #200,CSRINDEX      ;SET BIT FOR CONTROLLER
:  MOVB #1,CSRODEX        ;SET BIT FOR CONTROLLER
:  FOR CSRLOOP := #'0 TO #'7
:    IFB CSRINDEX SET IN MKCSRS
:    CALL ISECCON
:    FOR SIDE := #'0 TO #'1
:      CALL INTKRAP
:      BEGIN CSRSTUFF
:      CLR SUCCESS
:      FOR BANK := CSRIBANK DOWNT0 CSRFBANK
:        CALL EXBANK
:        IF ACFLAG IS TRUE AND RRFLAG IS FALSE
:          MAP BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
:          INVALIDATE        ;INVALIDATE BACKGROUND PATTERN ON 'BANK'
:          CLC
:          IF SPECIAL IS TRUE THEN $CALL SIDEOK
:          ON.NOERROR
:            FOR TESTADD := CSRFIRST TO #LAST BY CSRINC
:              CALL SBTEST
:            ON.NOERROR
:              CACHOFF          ;TURN CACHE OFF
:              FOR I := #0 TO #37
:                CLR NOPAR      ;INDICATE PARITY ACTION
:                SET HEADER
:                CLR PASFLG
:                LET RO := 1
:                CALL CSRCASE
:              END ;OF FOR I
:            CACHON          ;TURN CACHE ON
:            SET SUCCESS
:            LEAVE CSRSTUFF
:          END ;OF ON.NOERROR
:        END ;OF FOR TESTADD
:      END ;OF ON.NOERROR
:    END ;OF IF
:  END ;OF FOR BANK
:  END CSRSTUFF
:  IF SUCCESS IS FALSE
:    MOVB CSRLOOP,MSG434      ;SETUP CSR NUMBER
  
```

```

3268 017202 113737 002422 113642      MOVB   SIDE,MSGB34      ;SETUP SIDE (0 OR 1)
3269 017210                                TYPE   MSG034
3270 017214                                END ;OF IF SUCCESS
3271 017214                                END ;OF FOR SIDE
3272 017230                                END ;OF IFB CSRINDEX
3273 017230 000241                          CLC
3274 017232 106037 002416                    RORB   CSRINDEX        ;CHANGE TO NEXT CONTROLLER
3275 017236 106337 002417                    ASLB   CSROUDEX        ;CHANGE TO NEXT CONTROLLER
3276 017242                                END ;OF FOR CSRLOOP
3277 017256 104472                          ECCINIT ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
3278 017260                                SET    CONTFLAG
3279 017266                                POP    BANK
3280 017272 004737 042422                    CALL   EXBANK
3281 017276 000207                          RETURN

```

3284 017300

```
ISECCON:SUBTST <<IS ECC ON?>>
:*****
:*SUBTEST IS ECC ON?
:*****
```

3285

3286 017300 005000
3287 017302 113702 002417

```
:SETUP CSR NUMBER
CLR R0 ;START A ZERO
MOVB CSROUDEX,R2 ;GET CSR INDEX #2
1$: RO RB R2 ;GET CSR BIT IN CARRY (MAYBE)
BCS 2$ ;I GOT IT - SKIP
ADD #4,R0 ;BUMP CSR ADDRESS LSB'S BY 4
BR 1$ ;LOOP TILL I FIND THE CSR
2$: MOV R0,CSRNO ;UPDATE CSR NUMBER
CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
READCSR
```

3288 017306 106002
3289 017310 103403

3290 017312 062700 000004
3291 017316 000773

3292 017320 010037 002256
3293 017324 104503

3294 017326 104426
3295 017330

3296 017340
3297 017344 113737 002420 112134

3298 017352
3299 017356

3300 017364
3301 017366 005037 002474

3302 017372
3303 017372 000207

```
IF #BIT1 SET,IN CSR
TYPE MSG078 ;WARNING! ECC IS DISABLED ON BOX
MOVB CSRLOOP,MSG015
TYPE MSG015
SET NOECCFLAG
ELSE
CLR NOECCFLAG
END ;OF IF #BIT1
RETURN
```

3306 017374

SBETEST:SUBST <<CHECK FOR SBE FREE LOCATIONS>>
:*****
:SUBTEST CHECK FOR SBE FREE LOCATIONS
:*****

3307
3308
3309
3310
3311
3312
3313
3314
3315
3316
3317
3318
3319
3320
3321
3322
3323
3324
3325
3326
3327
3328
3329
3330
3331
3332
3333
3334
3335
3336
3337
3338
3339
3340
3341
3342
3343
3344
3345
3346
3347
3348
3349
3350
3351
3352
3353
3354
3355
3356
3357
3358
3359

017374 013701 002506
017400
017406 104424
017410 104471
017412
017420 005711
017422 001061
017424 005761 000002
017430 001056
017432 104503
017434
017442 005711
017444 001050
017446 005761 000002
017452 001045
017454 104510
017456
017466 104471
017470 005111
017472 005161 000002
017476 023711 002726
017502 001031
017504 023761 002726 000002
017512 001025
017514 104503

:IN ORDER TO DETERMINE IF A LOCATION IS SBE FREE I DO THIS
:
:WRITE ZEROS WITH ECC DISABLE
:READ ZEROS BACK
:IF NOT ZEROS THEN RETURN ERROR
:
:WRITE ZEROS WITH ECC ENABLED BUT TRAPS DISABLED
:READ ZEROS BACK
:IF NOT ZEROS THEN RETURN ERROR
:
:TEST THE LOCATION FROM THE PAR'S (WITH NO PROGRAM FETCHES)
:IF THERE WERE ANY SBE'S OR DBE'S THEN RETURN ERROR
:
:COMPLIMENT ZEROS TO ONES WITH ECC DISABLE
:READ ONES BACK
:IF NOT ONES THEN RETURN ERROR
:
:WRITE 100,100000,00000 (CHECKBITS COMPLIMENT OF BEFORE)
: WITH ECC ENABLED BUT TRAPS DISABLED
:TEST THE LOCATION FROM THE PAR'S (WITH NO PROGRAM FETCHES)
:IF THERE WERE ANY SBE'S OR DBE'S THEN RETURN ERROR
:
:IF NONE OF THE ABOVE FORCES A RETURN ERROR THEN RETURN NO.ERROR
:ENABL LSB
MOV TESTADD,R1
SUPERVISOR ;ENTER SUPERVISOR MODE
CACHOFF ;TURN CACHE OFF
ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
CLEAR (R1),2(R1)
TST (R1)
BNE 1\$
TST 2(R1)
BNE 1\$
CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
CLEAR (R1),2(R1)
TST (R1)
BNE 1\$
TST 2(R1)
BNE 1\$
TSTREAD ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
IF #BIT15:BIT4 SET.IN CSR THEN GOTO 1\$
ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
COM (R1)
COM 2(R1)
CMP ONES,(R1)
BNE 1\$
CMP ONES,2(R1)
BNE 1\$
CLR1CSR ;CLEAR 1 SELECTED MK11 CSR

```

3360 017516 005011          CLR      (R1)
3361 017520 012761 100000 000002      MOV      #BIT15,2(R1)
3362 017526 005711          TST      (R1)
3363 017530 001016          BNE      1$
3364 017532 022761 100000 000002      CMP      #BIT15,2(R1)
3365 017540 001012          BNE      1$
3366
3367 017542 104510          TSTREAD          :TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
3368 017544          IF #BIT15:BIT4 SET.IN CSR THEN GOTO 1$
3369
3370 017554 104417          KERNEL          :ENTER KERNEL MODE
3371 017556 104473          ECC1INIT        :INITIALIZE 1 SELECTED MK11 CSR
3372 017560 104423          CACHON          :TURN CACHE ON
3373 017562          $RETURN NOERROR
3374
3375 017566 104503          1$: CLR1CSR          :CLEAR 1 SELECTED MK11 CSR
3376 017570          CLEAR      (R1),2(R1)
3377 017576 104417          KERNEL          :ENTER KERNEL MODE
3378 017600 104473          ECC1INIT        :INITIALIZE 1 SELECTED MK11 CSR
3379 017602 104423          CACHON          :TURN CACHE ON
3380 017604          $RETURN ERROR
3381          .DSABL  LSB
    
```

3384 017610

INTKRAP:SUBST <<SETUP INTERLEAVE INFO>>

 :*SUBTEST SETUP INTERLEAVE INFO

3385

:BASED ON THE STARTING ADDRESS, BOX CAPACITY, INTERLEAVE, AND SIDE

3386

:SETUP VARIABLES TO DETERMINE

3387

:(1) THE STARTING ADDRESS OF THIS CONTROLLER

3388

:(2) THE NUMBER TO ADD TO EACH ADDRESS TO STAY IN THIS CONTROLLER

3389

:(3) THE LAST ADDRESS OF THIS CONTROLLER

3390 017610

PUSH RO

3391 017612 004737 017736

CALL GETSIZE

3392 017616 013737 002260 002410

MOV FIRSTB,CSRFBANK

3393 017624 013737 002262 002412

MOV LASTB,CSRLBANK

3394 017632 005037 002432

CLR SPECIAL

3395 017636 104426

READCSR

:READ CSR

3396 017640 013700 002146

MOV CSR+2,RO

3397 017644 072027 177765

ASH #-11,RO

3398 017650 042700 177760

BIC #^C17,RO

:RO = (0..17) = BITS 14,13,12,11 OF CSR+2
 :IF RO = 0 CALL NEXT; IF RO = 1 CALL NEXT+2, ETC.

3399 017654

CASE RO

3400 017664 020234

INT..0

3401 017666 020260

INT..1

3402 017670 020324

INT..2

3403 017672 020350

INT..3

3404 017674 020414

INT..4

3405 017676 020440

INT..5

3406 017700 020504

INT..6

3407 017702 020530

INT..7

3408 017704 020574

INT..10

3409 017706 020574

INT..11

3410 017710 020616

INT..12

3411 017712 020642

INT..13

3412 017714 020706

INT..14

3413 017716 020732

INT..15

3414 017720 020776

INT..16

3415 017722 021022

INT..17

3416 017724

END

:OF CASE

3417 017732

POP RO

3418 017734 000207

RETURN

SETUP INTERLEAVE INFO

3421 017736

```

GETSIZE:SUBTST <<SUBR GET SIZE FROM CSR>>
:*****
:SUBTEST SUBR GET SIZE FROM CSR
:*****

```

3422

3423 017736

3424 017740

3425 017746

3426 017754

3427 017756

3428 017760

3429 017766

3430 017772

3431 017774

3432 020000

3433

3434 020004

3435 020016

3436 020030

3437 020034

3438 020036

3439 020042

3440 020050

3441 020054

3442 020072

3443 020110

3444 020112

052737 000010 002144
042737 000006 002144
104425
104426
042737 000010 002144
113700 002145
006300
110037 002262
013700 002146

042700 177000
006300
010037 002260
063737 002260 002262
005337 002262

000207

```

:SETUP FIRSTB AND LASTB
PUSH RO
BIS #BIT3,CSR ;GET SET TO READ CSR
BIC #BIT2!BIT1,CSR
LOADCSR
READCSR
BIC #BIT3,CSR ;RESTORE THIS FROM "SIZE" MODE
MOVB CSR+1,RO ;GET SIZE
ASL RO ;RO = # OF BANKS
MOVB RO,LASTB
MOV CSR+2,RO
:CORRECT LAST BANK FOR EXTERNAL INTERLEAVE
IF #BIT12 SET.IN RO THEN LET LASTB := LASTB L.SHIFT 1
IF #BIT13 SET.IN RO THEN LET LASTB := LASTB L.SHIFT 1
BIC #177000,RO
ASL RO
MOV RO,FIRSTB
ADD FIRSTB,LASTB
DEC LASTB
IF FIRSTB HI #167 THEN LET FIRSTB := #170
IF LASTB HI #167 THEN LET LASTB := #167
POP RO
RETURN

```


3490 020234

SUBSTST <<DETERMINE ADDRESSING ACCORDING TO INTERLEAVE>>

: *SUBTEST DETERMINE ADDRESSING ACCORDING TO INTERLEAVE

3491
3492
3493
3494
3495
3496
3497
3498
3499 020234
3500 020242
3501 020250
3502 020256 000207
3503
3504
3505 020260
3506 020266
3507 020276
3508 020304
3509 020306
3510 020314
3511 020314
3512 020322 000207
3513
3514
3515 020324
3516 020332
3517 020340
3518 020346 000207
3519
3520
3521 020350
3522 020356
3523 020366
3524 020374
3525 020376
3526 020404
3527 020404
3528 020412 000207
3529
3530
3531 020414
3532 020422
3533 020430
3534 020436 000207
3535
3536
3537 020440
3538 020446
3539 020456
3540 020464
3541 020466
3542 020474
3543 020474

:CSRFBANK := THE FIRST BANK OF THIS CONTROLLER OF THIS CSR
:CSRLBANK := THE LAST BANK OF THIS CONTROLLER OF THIS CSR
:CSRFIRST := THE FIRST ADDRESS OF THIS CONTROLLER OF THIS CSR
:CSRINC := THE NUMBER TO ADD TO THE ADDRESS PAIR
: TO RETURN TO THIS CONTROLLER OF THIS CSR
:SPECIAL := A FLAG SET IF THIS BOX IS NOT INTERNALLY INTERLEAVED

:NO INTERNAL INTERLEAVE, NO EXTERNAL INTERLEAVE

INT..0: LET CSRFIRST := #FIRST
SET SPECIAL
LET CSRINC := #4
RETURN

:INTERNAL INTERLEAVE, NO EXTERNAL INTERLEAVE

INT..1: LET CSRFBANK := FIRSTB
IFB SIDE EQ #'0
LET CSRFIRST := #FIRST
ELSE
LET CSRFIRST := #FIRST+4
END :OF IFB
LET CSRINC := #10
RETURN

:NO INTERNAL INTERLEAVE, 2-1 EXTERNAL INTERLEAVE (WITH EVEN DOUBLE WORDS SELECTED?)

INT..2: LET CSRFIRST := #FIRST
SET SPECIAL
LET CSRINC := #10
RETURN

:INTERNAL INTERLEAVE, 2-1 EXTERNAL INTERLEAVE (WITH EVEN DOUBLE WORDS SELECTED?)

INT..3: LET CSRFBANK := FIRSTB
IFB SIDE EQ #'0
LET CSRFIRST := #FIRST
ELSE
LET CSRFIRST := #FIRST+10
END :OF IFB
LET CSRINC := #20
RETURN

:NO INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=0,A02=0)

INT..4: LET CSRFIRST := #FIRST
SET SPECIAL
LET CSRINC := #20
RETURN

:INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=0,A02=0)

INT..5: LET CSRFBANK := FIRSTB
IFB SIDE EQ #'0
LET CSRFIRST := #FIRST
ELSE
LET CSRFIRST := #FIRST+20
END :OF IFB
LET CSRINC := #40

```

3544 020502 000207          RETURN
3545
3546
3547 020504          INT..6: ;NO INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=1,A02=0)
3548 020512          LET CSRFIRST := #FIRST+10
3549 020520          SET SPECIAL
3550 020526 000207          LET CSRINC := #20
3551          RETURN
3552
3553 020530          INT..7: ;INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=1,A02=0)
3554 020536          LET CSRFBANK := FIRSTB
3555 020546          IFB SIDE EQ #0
3556 020554          LET CSRFIRST := #FIRST+10
3557 020556          ELSE
3558 020564          LET CSRFIRST := #FIRST+30
3559 020564          END ;OF IFB
3560 020572 000207          LET CSRINC := #40
3561          RETURN
3562
3563          ;IMPOSSIBLE CONDITION
3564 020574          INT.10: ;NO INTERNAL INTERLEAVE, NO EXTERNAL INTERLEAVE (WITH ODD DOUBLE WORDS SELECTED?)
3565          ;FALL THRU TO INT.11
3566
3567          ;IMPOSSIBLE CONDITION
3568 020574          INT.11: ;INTERNAL INTERLEAVE, NO EXTERNAL INTERLEAVE (WITH ODD DOUBLE WORDS SELECTED?)
3569 020602          IF FSINFLAG IS FALSE
3570 020610          SET FSINFLAG
3571 020614          TYPE MSG097
3572 020614          END ;OF IF FSINFLAG
3573          GOTO INT..1
3574
3575 020616          INT.12: ;NO INTERNAL INTERLEAVE, 2-1 EXTERNAL INTERLEAVE (WITH ODD DOUBLE WORDS SELECTED?)
3576 020624          LET CSRFIRST := #FIRST+4
3577 020632          SET SPECIAL
3578 020640 000207          LET CSRINC := #10
3579          RETURN
3580
3581 020642          INT.13: ;INTERNAL INTERLEAVE, 2-1 EXTERNAL INTERLEAVE (WITH ODD DOUBLE WORDS SELECTED?)
3582 020650          LET CSRFBANK := FIRSTB
3583 020660          IFB SIDE EQ #0
3584 020666          LET CSRFIRST := #FIRST+4
3585 020670          ELSE
3586 020676          LET CSRFIRST := #FIRST+14
3587 020676          END ;OF IFB
3588 020704 000207          LET CSRINC := #20
3589          RETURN
3590
3591 020706          INT.14: ;NO INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=0,A02=1)
3592 020714          LET CSRFIRST := #FIRST+4
3593 020722          SET SPECIAL
3594 020730 000207          LET CSRINC := #20
3595          RETURN
3596
3597 020732          INT.15: ;INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=0,A02=1)
3598 020740          LET CSRFBANK := FIRSTB
3599 020750          IFB SIDE EQ #0
3600 020756          LET CSRFIRST := #FIRST+4
          ELSE
    
```

```
3601 020760          LET CSRFIRST := #FIRST+24
3602 020766          END :OF IFB
3603 020766          LET CSRINC := #40
3604 020774 000207   RETURN
3605
3606                :NO INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=1,A02=1)
3607 020776 INT.16: LET CSRFIRST := #FIRST+14
3608 021004          SET SPECIAL
3609 021012          LET CSRINC := #20
3610 021020 000207   RETURN
3611
3612                :INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=1,A02=1)
3613 021022 INT.17: LET CSRFBANK := FIRSTB
3614 021030          IFB SIDE EQ #0
3615 021040          LET CSRFIRST := #FIRST+14
3616 021046          ELSE
3617 021050          LET CSRFIRST := #FIRST+34
3618 021056          END :OF IFB
3619 021056          LET CSRINC := #40
3620 021064 000207   RETURN
3621
```

3624 021066

```
SIDEOK: SUBTST <<DETERMINE IF BANK BELONGS TO CORRECT SIDE>>  
:*****  
:*SUBTST DETERMINE IF BANK BELONGS TO CORRECT SIDE  
:*****  
;RETURN ERROR IF NOT.
```

3625

3626

3627 021066 005037 002404

3628 021072 013702 002336

3629 021076 104475

3630 021100

3631 021106 104424

3632 021110 012722 000000

3633 021114 012712 000000

3634 021120 104503

3635 021122 005712

3636 021124 104426

3637 021126 013701 002146

3638

3639

3640 021132 104471

3641 021134 013712 002430

3642 021140 013742 002430

3643 021144 104503

3644 021146 104417

3645 021150 104423

3646

3647 021152

3648 021174

3649 021216

```
CLR CHECK  
MOV CSRFIRST,R2  
CB1CSR ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR  
SUPERVISOR ;ENTER SUPERVISOR MODE  
CACHOFF ;TURN CACHE OFF  
MOV #0,(R2)+  
MOV #0,(R2)  
CLR1CSR ;CLEAR 1 SELECTED MK11 CSR  
TST (R2)  
READCSR  
MOV CSR+2,R1  
;ELIMINATE DBE  
ECCDIS ;DISABLE ECC ON 1 SELECTED CSR  
MOV ZEROS,(R2)  
MOV ZEROS,-(R2)  
CLR1CSR ;CLEAR 1 SELECTED MK11 CSR  
KERNEL ;ENTER KERNEL MODE  
CACHON ;TURN CACHE ON  
IF #BIT9 OFF. IN R1 AND SIDE EQ #'0 THEN $RETURN NOERROR  
IF #BIT9 SET. IN R1 AND SIDE EQ #'1 THEN $RETURN NOERROR  
$RETURN ERROR
```

```

3653 021222      MKTEST: SUBTST <<SUBR MK11 TEST DISPATCH>>
:*****
:*SUBTEST      SUBR      MK11 TEST DISPATCH
:*****
3654 021222      IF MULTIONLY IS TRUE THEN $RETURN
3655 021232      IF #SWO SET.IN @SWR OR ACTFLAG IS TRUE
3656 021250      104470      ECCDIS          ;DISABLE ERROR CORRECTION
3657 021252      ELSE
3658 021254      104502      CLRCR          ;CLEAR MK11 CSRS
3659 021256      END ;OF IF
3660 021256      012737 000002 002100      MOV #2,NOPAR      ;INDICATE PARITY ACTION
3661 021264      012737 000002 002406      MOV #2,PCBUMP     ;TRAPS ADD 2 TO PC
3662 021272      013700 002120      MOV PATTERN,R0   ;GET PATTERN NUMBER
3663 021276      006300          ASL R0           ;MAKE IT A WORD ADDRESS
3664 021300      IF MKPAT(R0) NE #MT0035 AND MKPAT(R0) NE #MT0999
3665 021320      104511      INVALIDATE        ;INVALIDATE BACKGROUND PATTERN ON 'BANK'
3666 021322      END ;OF IF MKPAT(R0)
3667 021322      004770 021402      CALL @MKPAT(R0)   ;INDEX OFF TABLE
3668 021326      IF #SWO SET.IN @SWR OR ACTFLAG IS TRUE
3669 021344      104476      WASSBE          ;WAS THERE ANY SINGLE BIT ERRORS
3670 021346      ON.ERROR
3671 021350      SET SBFLAG
3672 021356      013737 002144 002150      MOV CSR,SBCSR
3673 021364      013737 002146 002152      MOV CSR+2,SBCSR+2
3674 021372      END ;OF ON.ERROR
3675 021372      END ;OF IF #SWO
3676 021372      104472      ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
3677 021374      005037 002100      CLR NOPAR       ;INDICATE PARITY ACTION
3678 021400      000207      RETURN
3679
3680      ;WARNING IF YOU CHANGE THIS TABLE ALSO
3681      ;CHANGE '$DDWO' - '$DDW5' (THE PATTERN BIT MAP)
3682
3683      ;PAT      TIME      DISCRPTION
3684 021402      MKPAT: ;NOTE MT0035 MUST BE FIRST & LAST
3685 021402      025652      MT0035 :<1 SEC      ;SOFT ERROR - BACKGROUND PATTERN TEST
3686 021404      023134      MT0017 :<1 SEC      ;HOLDING 1'S & 0'S TEST
3687 021406      022414      MT0007 :<1 SEC      ;ADDRESS BIT TEST
3688 021410      021740      MT0001 :<1 SEC      ;ADDRESS TEST
3689 021412      022000      MT0002 :<1 SEC      ;COMPLEMENT ADDRESS TEST
3690 021414      022216      MT0004 : 1 SEC      ;ROTATING ZEROS TEST
3691 021416      022300      MT0005 : 1 SEC      ;ROTATING ONES TEST
3692 021420      023612      MT0021 : 1 SEC      ;MARCHING 0'S & 1'S TEST
3693 021422      023156      MT0020 :<1 SEC      ;MARCHING 1'S & 0'S IN CHECK BITS
3694 021424      023734      MT0022 :10 SEC      ;REFRESH & SHIFTING DIAGONAL TEST
3695 021426      024240      MT0026 :<1 SEC      ;RANDOM DATA TEST
3696 021430      024032      MT0024 :20 SEC      ;FAST GALLOPING PATTERN TEST
3697 021432      025214      MT0031 : 3 SEC      ;SOB-A-LONG TEST
3698 021434      025340      MT0033 :<1 SEC      ;WRITE RECOVERY TEST
3699 021436      025530      MT0034 :35 SEC      ;BRANCH GOBBLE TEST
3700 021440      025652      MT0035 :<1 SEC      ;SOFT ERROR - BACKGROUND PATTERN TEST
3701      ;NOTE MT0035 MUST BE FIRST & LAST
3702 021442      025772      MT0999 : 0 SEC      ;NULL TEST
3703 021444      025772      MT0999 : 0 SEC      ;NULL TEST
3704 021446      025772      MT0999 : 0 SEC      ;NULL TEST
3705 021450      025772      MT0999 : 0 SEC      ;NULL TEST
3706 021452      025772      MT0999 : 0 SEC      ;NULL TEST
    
```

3707	021454	025772	MT0999	:	0	SEC	:	NULL	TEST
3708	021456	025772	MT0999	:	0	SEC	:	NULL	TEST
3709	021460	025772	MT0999	:	0	SEC	:	NULL	TEST
3710	021462	025772	MT0999	:	0	SEC	:	NULL	TEST
3711	021464	025772	MT0999	:	0	SEC	:	NULL	TEST
3712	021466	025772	MT0999	:	0	SEC	:	NULL	TEST
3713	021470	025772	MT0999	:	0	SEC	:	NULL	TEST
3714	021472	025772	MT0999	:	0	SEC	:	NULL	TEST
3715	021474	025772	MT0999	:	0	SEC	:	NULL	TEST
3716	021476	025772	MT0999	:	0	SEC	:	NULL	TEST
3717	021500	025772	MT0999	:	0	SEC	:	NULL	TEST
3718	021502	025772	MT0999	:	0	SEC	:	NULL	TEST
3719	021504	025772	MT0999	:	0	SEC	:	NULL	TEST
3720	021506	025772	MT0999	:	0	SEC	:	NULL	TEST
3721	021510	025772	MT0999	:	0	SEC	:	NULL	TEST

3778
 3779
 3780
 3781 021704

3782 021704 005037 002366
 3783 021710 012700 060000
 3784 021714 012701 040000
 3785 021720 004737 035204
 3786 021724
 3787 021732 004737 026042
 3788 021736 000207
 3789 021740

3790 021740 012737 000001 002366
 3791 021746 012700 060000
 3792 021752 012701 040000
 3793 021756 005002
 3794 021760 004737 035204
 3795 021764
 3796 021772 004737 026042
 3797 021776 000207
 3798 022000

3799 022000 012737 000002 002366
 3800 022006 012700 160000
 3801 022012 012701 040000
 3802 022016 012702 000001
 3803 022022 010103
 3804 022024 012704 060000
 3805 022030 012705 100001
 3806 022034
 3807 022042 004737 026042
 3808 022046 000207

```

.SBTTL PATTERNS

.SBTTL MEMORY TEST SETUP ROUTINES
MT0000: SUBTST <<MT0000      SETUP DATA PATTERN TEST>>
:*****
:*SUBTEST      MT0000      SETUP DATA PATTERN TEST
:*****
      CLR      REALPAT      ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
      MOV      #FIRST,R0
      MOV      #SIZE,R1
      CALL     REGCOPY
      BMOV     MTP000
      CALL     SUPD01      ;DO IT IN SUPERVISOR MODE
      RETURN

MT0001: SUBTST <<MT0001      SETUP ADDRESS TEST>>
:*****
:*SUBTEST      MT0001      SETUP ADDRESS TEST
:*****
      MOV      #1,REALPAT      ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
      MOV      #FIRST,R0
      MOV      #SIZE,R1
      CLR      R2
      CALL     REGCOPY
      BMOV     MTP001
      CALL     SUPD01      ;DO IT IN SUPERVISOR MODE
      RETURN

MT0002: SUBTST <<MT0002      SETUP COMPLEMENT ADDRESS TEST>>
:*****
:*SUBTEST      MT0002      SETUP COMPLEMENT ADDRESS TEST
:*****
      MOV      #2,REALPAT      ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
      MOV      #LAST+2,R0
      MOV      #SIZE,R1
      MOV      #1,R2
      MOV      R1,R3
      MOV      #FIRST,R4
      MOV      #100001,R5
      BMOV     MTP002
      CALL     SUPD01
      RETURN
    
```


381' 022050

3812 022050 012737 000003 002366

3813 022056 005037 002406

3814 022062 004737 035214

3815 022066 012701 060000

3816 022072 005000

3817 022074 160001

3818 022076 012703 020000

3819 022102 072327 177770

3820 022106 012702 000004

3821 022112 012705 000100

3822 022116

3823 022130 104415

3824 022132 012737 177636 002360

3825 022140 004737 026220

3826 022144

3827 022152

3828 022164

3829 022176 104416

3830 022200 004737 026056

3831 022204 022737 000003 002734

3832

3833 022212 001323

3834 022214 000207

3835

3836 022216

```

MT0003: SUBST <<MT0003      SETUP 3 XOR 9 WORST CASE NOISE TEST>>
:*****
:*SUBTEST      MT0003      SETUP 3 XOR 9 WORST CASE NOISE TEST
:*****
      MOV      #3,REALPAT      ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
      CLR      PCBUMP          ;TRAPS DO NOT ADD TO PC
1$:   CALL     FLIPWARN        ;SETUP WARNING CONSTANTS & R2
2$:   MOV      #FIRST,R1      ;R1 <-- STARTING ADDRESS
      CLR      R0              ;INTERLEAVE ADDRESS CONSTANT
      SUB      R0,R1          ;CORRECT FOR ADD BEFORE USE MODE
      MOV      #SIZE/2,R3     ;INTERLEAVE SIZE (8K,4K,2K,OR 1K (DOUBLE WORDS))
      ASH     #-8,R3         ;R3 <-- R3 / 256.
      MOV      #4,R2         ;SMALL LOOP SIZE
      MOV      #64,R5        ;MEDIUM LOOP SIZE
      BMOV     MTPA03,UDPDR7,17.
      SAVREG
      MOV      #FASTCITY-2,SUPDOADD
      CALL     SUPD03
      BMOV     MTPB03
      BMOV     MTPC03,KDPAR0,8.
      BMOV     MTPD03,SDPAR0,8.
      RESREG
      CALL     SUPD02
      CMP      #3,FLIPL0C     ;DONE WITH 4 PATTERNS
      BNE     1$             ;[(0,177777);(177777,0);(401,177777);(177777,401)]?
      RETURN                    ;NO - LOOP

```

3837 022216 012737 000004 002366

3838 022224 012737 000004 002406

3839 022232 013702 002726

3840 022236 004737 035344

3841 022242 012700 060000

3842 022246 012701 040000

3843 022252

3844 022260

3845 022272 004737 026056

3846 022276 000207

3847 022300

```

MT0004: SUBST <<MT0004      SETUP ROTATING ZEROS TEST>>
:*****
:*SUBTEST      MT0004      SETUP ROTATING ZEROS TEST
:*****
      MOV      #4,REALPAT     ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
      MOV      #4,PCBUMP      ;TRAPS ADD 4 TO PC
      MOV      ONES,R2
      CALL     BACKGND        ;WRITE BACKGROUND OF ONES
      MOV      #FIRST,R0
      MOV      #SIZE,R1
      BMOV     MTPA04
      BMOV     MTPB04,KDPAR0,8.
      CALL     SUPD02
      RETURN

```

3848 022300 012737 000005 002366

3849 022306 012737 000004 002406

3850 022314 005002

3851 022316 004737 035344

3852 022322 012700 060000

3853 022326 012701 040000

3854 022332

3855 022340

3856 022352 004737 026056

3857 022356 000207

```

MT0005: SUBST <<MT0005      SETUP ROTATING ONES TEST>>
:*****
:*SUBTEST      MT0005      SETUP ROTATING ONES TEST
:*****
      MOV      #5,REALPAT     ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
      MOV      #4,PCBUMP      ;TRAPS ADD 4 TO PC
      CLR      R2
      CALL     BACKGND        ;WRITE BACKGROUND OF ZEROS
      MOV      #FIRST,R0
      MOV      #SIZE,R1
      BMOV     MTP005
      BMOV     MTPB04,KDPAR0,8.
      CALL     SUPD02
      RETURN

```

3860 022360

MT0006: SUBTST <<MT0006 SETUP INITIAL DATA TEST>>

: *SUBTEST MT0006 SETUP INITIAL DATA TEST

3861 022360 012737 000006 002366
3862 022366 012737 000004 002406
3863 022374 013701 002506
3864 022400 012737 026760 002360
3865 022406 004737 026220
3866 022412 000207
3867 022414

MOV #6,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV #4,PCBUMP ;TRAPS ADD 4 TO PC
MOV TESTADD,R1
MOV #MTP006,SUPDOADD
CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

MT0007: SUBTST <<MT0007 SETUP ADDRESS BIT TEST>>

: *SUBTEST MT0007 SETUP ADDRESS BIT TEST

3868 022414 012737 000007 002366
3869 022422 005002
3870 022424 004737 035344
3871 022430 012701 060000
3872 022434 012702 000001
3873 022440 050201
3874 022442 012737 027150 002360
3875 022450 004737 026220
3876 022454 000207
3877 022456

MOV #7,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
CLR R2
CALL BACKGND ;OF ZEROS
MOV #FIRST,R1
MOV #1,R2
BIS R2,R1
MOV #MTP007,SUPDOADD
CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

MT0010: SUBTST <<MT0010 SETUP BYTE ADDRESSING TEST>>

: *SUBTEST MT0010 SETUP BYTE ADDRESSING TEST

3878 022456 012737 000010 002366
3879 022464 012737 000004 002406
3880 022472 013704 002506
3881 022476 012737 027250 002360
3882 022504 004737 026220
3883 022510 000207

MOV #10,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV #4,PCBUMP ;TRAPS ADD 4 TO PC
MOV TESTADD,R4
MOV #MTP010,SUPDOADD
CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

3886 022512

MT0011: SUBTST <<MT0011 SETUP CREATE SINGLE BIT ERROR TEST>>
:*****
:*SUBTEST MT0011 SETUP CREATE SINGLE BIT ERROR TEST
:*****

3887 022512

IF NOECCFLAG IS TRUE THEN \$RETURN
IF ACTFLAG IS TRUE OR APTFLAG IS TRUE
IF \$PASS NE #0 THEN \$RETURN

3888 022522

END ;OF IF ACTFLAG
MOV #11,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

3889 022536

012737 000011 002366

3890 022546

012737 027356 002360

3891 022546

3892 022554

004737 026220

3893 022562

3894 022566

000207

CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

MT0012: SUBTST <<MT0012 SETUP WRITE BYTE CLEARS SBE TEST>>
:*****
:*SUBTEST MT0012 SETUP WRITE BYTE CLEARS SBE TEST
:*****

3896 022570

IF NOECCFLAG IS TRUE THEN \$RETURN
IF ACTFLAG IS TRUE OR APTFLAG IS TRUE
IF \$PASS NE #0 THEN \$RETURN

3897 022600

END ;OF IF ACTFLAG
MOV #12,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

3898 022614

012737 000012 002366

3899 022624

012737 027766 002360

3900 022624

3901 022632

004737 026220

3902 022640

3903 022644

000207

CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

MT0013: SUBTST <<MT0013 SETUP CREATE DOUBLE BIT ERROR TEST>>
:*****
:*SUBTEST MT0013 SETUP CREATE DOUBLE BIT ERROR TEST
:*****

3905 022646

IF ACTFLAG IS TRUE OR APTFLAG IS TRUE
IF \$PASS NE #0 THEN \$RETURN

3906 022662

END ;OF IF ACTFLAG
MOV #13,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

3907 022672

012737 000013 002366

3908 022672

012737 030344 002360

3909 022700

3910 022706

012737 000003 002100

3911 022714

3912 022720

004737 026220

3913 022722

CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

MT0014: SUBTST <<MT0014 SETUP WRITE INHIBIT DURING DATIP WITH DBE>>
:*****
:*SUBTEST MT0014 SETUP WRITE INHIBIT DURING DATIP WITH DBE
:*****

3914 022722

IF NOECCFLAG IS TRUE THEN \$RETURN
IF ACTFLAG IS TRUE OR APTFLAG IS TRUE
IF \$PASS NE #0 THEN \$RETURN

3915 022732

END ;OF IF ACTFLAG
MOV #14,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

3916 022746

012737 000014 002366

3917 022756

012737 030716 002360

3918 022756

3919 022764

004737 026220

3920 022772

3921 022776

000207

CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

3924 023000

MT0015: SUBTST <<MT0015 SETUP WRITE INHIBIT OF BYTE WITH DBE>>

: *SUBTEST MT0015 SETUP WRITE INHIBIT OF BYTE WITH DBE

3925 023000

IF NOECCFLAG IS TRUE THEN \$RETURN

3926 023010

IF ACTFLAG IS TRUE OR APTFLAG IS TRUE

3927 023024

IF \$PASS NE #0 THEN \$RETURN

3928 023034

END ;OF IF ACTFLAG

3929 023034 012737 000015 002366

MOV #15,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

3930 023042 012737 031312 002360

MOV #MTP015,SUPDOADD

3931 023050 004737 026220

CALL SUPD03 ;DO IT IN SUPERVISOR MODE

3932 023054 000207

RETURN

3933 023056

MT0016: SUBTST <<MT0016 SETUP WRITE INHIBIT OF WORD WITH DBE>>

: *SUBTEST MT0016 SETUP WRITE INHIBIT OF WORD WITH DBE

3934 023056

IF NOECCFLAG IS TRUE THEN \$RETURN

3935 023066

IF ACTFLAG IS TRUE OR APTFLAG IS TRUE

3936 023102

IF \$PASS NE #0 THEN \$RETURN

3937 023112

END ;OF IF ACTFLAG

3938 023112 012737 000016 002366

MOV #16,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

3939 023120 012737 031700 002360

MOV #MTP016,SUPDOADD

3940 023126 004737 026220

CALL SUPD03 ;DO IT IN SUPERVISOR MODE

3941 023132 000207

RETURN

3942 023134

MT0017: SUBTST <<MT0017 SETUP HOLDING 1'S & 0'S>>

: *SUBTEST MT0017 SETUP HOLDING 1'S & 0'S

3943 023134 012737 000017 002366

MOV #17,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

3944 023142 012737 032302 002360

MOV #MTP017,SUPDOADD

3945 023150 004737 026220

CALL SUPD03 ;DO IT IN SUPERVISOR MODE

3946 023154 000207

RETURN

3949 023156

3950 023156
 3951 023172
 3952 023202
 3953 023202 012737 000020 002366
 3954 023210 005037 002100
 3955 023214 012737 032572 002360
 3956 023222 0137 002334
 3957 023226
 3958 023232 013737 023320 002256
 3959 023240 106300
 3960 023242
 3961 023244 112737 000060 002422
 3962 023252 004737 07610
 3963 023256
 3964 023264 006237 002414
 3965 023270
 3966
 3967 023270
 3968 023272 004737 023322
 3969 023276
 3970 023300
 3971 023300
 3972 023316 000207
 3973 023320 000000
 3974
 3975 023322 013700 002336
 3976 023326 010001
 3977 023330 013702 002414
 3978 023334 005003
 3979 023336 012704 100000
 3980 023342 012705 160000
 3981 023346 104503
 3982 023350
 3983 023356 004737 026042
 3984 023362
 3985 023400
 3986 023402
 3987 023402
 3988 023410 004737 026056
 3989 023414
 3990 023432 104477
 3991 023434
 3992 023436
 3993 023436
 3994 023444 004737 026056
 3995 023450
 3996 023466 104477
 3997 023470
 3998 023472
 3999 023472 013701 002336
 4000 023476
 4001 023504 004737 026056
 4002 023510

```

MT0020: SUBST <<MT0020      SETUP MARCHING 0'S & 1'S IN CHECKBITS TEST>>
:*****
:*SUBTEST      MT0020      SETUP MARCHING 0'S & 1'S IN CHECKBITS TEST
:*****
      IF ACTFLAG IS TRUE OR APTFLAG IS TRUE
      IF $PASS NE #0 THEN $RETURN
END ;OF IF ACTFLAG
MOV      #20,REALPAT      ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
CLR      NOPAR      ;INDICATE PARITY ACTION
MOV      #MTPA20,SUPDOADD
MOV      MKCSRS,R0
FOR MTV020 := #0 TO #34 BY #4
  MOV      MTV020,CSRNO
  ASLB   R0
  ON.ERROR
  MOV     #'0,SIDE
  CALL   INTKRAP
  IF SPECIAL IS FALSE
    ASR   CSRINC
  END ;OF IF SPECIAL
  ;NOW CSRFIRST & CSRINC ARE SETUP
  PUSH  R0
  CALL  MTO20Z
  POP   R0
END ;OF ON.ERROR
END ;OF FOR CSRNO
RETURN

MTV020: 0      ;VARIABLE FOR PAT 20

MTO20Z: MOV     CSRFIRST,R0
        MOV     R0,R1
        MOV     CSRINC,R2
        CLR     R3
        MOV     #BIT15,R4
        MOV     #LAST+2,R5
        CLR1CSR      ;CLEAR 1 SELECTED MK11 CSR
        BMOV    MTP20A
        CALL    SUPD01
        IF #SW11 SET.IN @SWR OR QVFLAG IS TRUE
          GOTO  MTO20Y
        END ;OF IF #SW11
        BMOV    MTP20B
        CALL    SUPD02
        IF #SW0 SET.IN @SWR OR ACTFLAG IS TRUE
          WAS1SBE      ;WAS THERE ANY SINGLE BIT ERRORS ON 1 SELECTED CSR
          ON.ERROR THEN GOTO MTO20X
        END ;OF IF #SW0
        BMOV    MTP20C
        CALL    SUPD02
        IF #SW0 SET.IN @SWR OR ACTFLAG IS TRUE
          WAS1SBE      ;WAS THERE ANY SINGLE BIT ERRORS ON 1 SELECTED CSR
          ON.ERROR THEN GOTO MTO20X
        END ;OF IF #SW0
MTO20Y: MOV     CSRFIRST,R1
        BMOV    MTP20D
        CALL    SUPD02
        IF #SW0 SET.IN @SWR OR ACTFLAG IS TRUE

```

EMKABC 117C MAIN MEMORY DIAG 1 MACRO M1113 01-AUG-79 07:12 PAGE 162-1
MT0020 SETUP MARCHING 0'S & 1'S IN CHECKBITS TEST

SEQ 0330

```

4003 023526 104477          WAS1SBE          ;WAS THERE ANY SINGLE BIT ERRORS ON 1 SELECTED CSR
4004 023530          ON.ERROR THEN GOTO MT020X
4005 023532          END ;OF IF #SW0
4006 023532          BMOV MTP20E
4007 023540 004737 026056  CALL SUPD02
4008 023544          IF #SW0 SET.IN @SWR OR ACTFLAG IS TRUE
4009 023562 104477          WAS1SBE          ;WAS THERE ANY SINGLE BIT ERRORS ON 1 SELECTED CSR
4010 023564          ON.ERROR THEN GOTO MT020X
4011 023566          END ;OF IF #SW0
4012 023566          BMOV MTP20F
4013 023574 004737 026056  CALL SUPD02
4014 023600 104503          CLR1CSR          ;CLEAR 1 SELECTED MK11 CSR
4015 023602 000207          RETURN
4016
4017 023604 004737 026234  MT020X: CALL SUPD04
4018 023610 000207          RETURN

```

```
4021 023612          MT0021: SUBTST <<MT0021      SFTUP MARCHING 0'S & 1'S TEST>>
:*****
:*SUBTEST          MT0021  SETUP MARCHING 0'S & 1'S TEST
:*****
4022 023612          SET NOSCOPE
4023 023620 012737 000021 002366  MOV #21,REALPAT          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
4024 023626 013702 002762          MOV BAKPAT,R2
4025 023632 004737 035344          CALL BACKGND
4026 023636 010203          MOV R2,R3
4027 023640 000303          SWAB R3
4028 023642 012701 160000          MOV #LAST+2,R1
4029 023646 010105          MOV R1,R5
4030 023650 012704 060000          MOV #FIRST,R4
4031 023654          BMOV MTPA21
4032 023662 004737 026042          CALL SUPD01
4033
4034 023666          BMOV MTPB21
4035 023674 004737 026056          CALL SUPD02
4036
4037 023700 010401          MOV R4,R1
4038 023702          BMOV MTPC21
4039 023710 004737 026056          CALL SUPD02
4040
4041 023714          BMOV MTPD21
4042 023722 004737 026056          CALL SUPD02
4043 023726 005037 002540          CLR NOSCOPE
4044 023732 000207          RETURN
4045
4046 023734          MT0022: SUBTST <<MT0022      SETUP REFRESH & SHIFTING DIAGONAL TEST>>
:*****
:*SUBTEST          MT0022  SETUP REFRESH & SHIFTING DIAGONAL TEST
:*****
4047 023734 004737 026006          CALL KAMITEST          ;CHECK FOR KAMIKAZE MODE
4048 023740          ON.ERROR THEN $RETURN          ;IF NOT IN KAMIKAZE MODE RETURN
4049 023744 012737 000022 002366  MOV #22,REALPAT          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
4050 023752 012737 033404 002360  MOV #MTP022,SUPDOADD
4051 023760 004737 026220          CALL SUPD03          ;DO IT IN SUPERVISOR MODE
4052 023764 000207          RETURN
4053
4054 023766          MT0023: SUBTST <<MT0023      SHIFTING DIAGONAL TEST>>
:*****
:*SUBTEST          MT0023  SHIFTING DIAGONAL TEST
:*****
4055 023766 004737 026006          CALL KAMITEST          ;CHECK FOR KAMIKAZE MODE
4056 023772          ON.ERROR THEN $RETURN          ;IF NOT IN KAMIKAZE MODE RETURN
4057 023776 012737 000023 002366  MOV #23,REALPAT          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
4058 024004 012737 033404 002360  MOV #MTP022,SUPDOADD
4059 024012          SET DIAGFLAG          ;IDENTIFY DIAGONAL TEST TO MTP022
4060 024020 004737 026220          CALL SUPD03          ;DO IT IN SUPERVISOR MODE
4061 024024 005037 002006          CLR DIAGFLAG
4062 024030 000207          RETURN
```

4064 024032

MT0024: SUBTST <<MT0024 SETUP FAST GALLOPING PATTERN TEST>>

: *SUBTEST MT0024 SETUP FAST GALLOPING PATTERN TEST

4065 024032 004737 026006
4066 024036
4067 024042
4068 024050 012737 000024 002366
4069 024056 013702 002762
4070 024062 004737 035344
4071 024066 010203
4072 024070 010304
4073 024072 000304
4074 024074 012701 060000
4075 024100 012705 157776
4076 024104 104415
4077 024106
4078 024114
4079 024126
4080 024140 012737 172260 002360
4081 024146 004737 026234
4082
4083
4084 024152 104416
4085 024154 000302
4086 024156 000303
4087 024160 004737 026234
4088 024164 005037 002540
4089 024170 000207
4090 024172

CALL KAMITEST ;CHECK FOR KAMIKAZE MODE
ON.ERROR THEN \$RETURN ;IF NOT IN KAMIKAZE MODE RETURN
SET NOSCOPE
MOV #24,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV BAKPAT,R2
CALL BACKGND
MOV R2,R3
MOV R3,R4
SWAB R4
MOV #FIRST,R1
MOV #LAST,R5
SAVREG
BMOV MTPA24
BMOV MTPB24,SDPAR0,8.
BMOV MTPC24,KDPAR0,8.
MOV #SDPAR0,SUPDOADD
CALL SUPD04

;DO IT AGAIN FOR COMPLEMENT DATA
RESREG
SWAB R2
SWAB R3
CALL SUPD04
CLR NOSCOPE
RETURN

MT0025: SUBTST <<MT0025 SETUP INTERRUPT ENABLE TEST>>

: *SUBTEST MT0025 SETUP INTERRUPT ENABLE TEST

4091 024172
4092 024206
4093 024216
4094 024216 012737 000025 002366
4095 024224 012737 034152 002360
4096 024232 004737 026220
4097 024236 000207

IF ACTFLAG IS TRUE OR APTFLAG IS TRUE
IF \$PASS NE #0 THEN \$RETURN
END ;OF IF ACTFLAG
MOV #25,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV #MTP025,SUPDOADD
CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

4100 024240

MT0026: SUBTST <<MT0026 SETUP RANDOM DATA TEST>>

:SUBTEST MT0026 SETUP RANDOM DATA TEST

4101 024240 012737 000026 002366
4102 024246 005037 002406
4103 024252 013703 002716
4104 024256 013702 002714
4105 024262 010305
4106 024264 010204
4107 024266 012701 060000
4108 024272 012700 020000
4109 024276 104415
4110 024300
4111 024306
4112 024320
4113 024332 004737 026042
4114 024336 005037 034626
4115 024342
4116 024350 104416
4117 024352 004737 026042
4118 024356 010337 002716
4119 024362 010237 002714
4120 024366 000207

MOV #26,REALPAT
CLR PCBUMP ;TRAPS DO NOT ADD TO THE PC
MOV SEEDLO,R3 ;INITIALIZE RANDOM NUMBERS
MOV SEEDHI,R2
MOV R3,R5
MOV R2,R4
MOV #FIRST,R1
MOV #SIZE/2,R0
SAVREG
BMOV MTPA26 ;WRITE ROUTINE TO FAST MEMORY
BMOV MTPC26,KDPAR0,8. ;RANDOM SUBPROGRAM TO FAST MEMORY
BMOV MTPD26,SDPAR0,8. ;RANDOM SUBSUBPROGRAM TO FAST MEMORY
CALL SUPD01 ;WRITE RANDOM DATA
CLR RANODD ;FOR ERROR REPORTING
BMOV MTPB26 ;READ ROUTINE TO FAST MEMORY
RESREG
CALL SUPD01 ;READ RANDOM DATA
MOV R3,SEEDLO ;UPDATE FOR NEW RANDOM NUMBERS
MOV R2,SEEDHI
RETURN

4123 024370

MTO027: SUBSTST <<MTO027 UNIQUE BANK TEST>>

:*****
:*SUBTEST MTO027 UNIQUE BANK TEST
:*****

4124
4125
4126 024370 012737 000027 002366
4127 024376
4128 024406 104502
4129 024410
4130 024416 012737 000207 177644
4131 024424 012737 177646 002360
4132 024432
4133 024440
4134 024446
4135 024452 004737 :2422
4136 024456
4137 024472 104511
4138 024474
4139 024500 012700 060000
4140 024504 010004
4141 024506 012701 040000
4142 024512 010103
4143 024514
4144 024524 004737 026042
4145 024530
4146 024530
4147 024540 004737 026220
4148 024544
4149 024544
4150 024544
4151 024560
4152 024574
4153 024602 005037 002526
4154 024606 000207
4155 024610
4156 024610
4157 024616
4158 024624 004737 042422
4159 024630
4160 024644
4161 024650 005102
4162 024652 012700 060000
4163 024656 010004
4164 024660 012701 040000
4165 024664 010103
4166 024666
4167 024676 004737 026042
4168 024702
4169 024702
4170 024712 004737 026220
4171 024716
4172 024716
4173 024716
4174 024732
4175 024746 005037 002526
4176 024752 000207

:MAKE SURE THAT EACH BANK CAN HAVE UNIQUE DATA
:WRITE AND READ THE BANK NUMBER IN EACH BANK (EXCEPT WHERE THE PROGRAM IS)
MOV #27,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
CLEAR MARGIN,MAINT ;CLEAR MARGINS
CLRCSR ;CLEAR MK11 CSRS
BMOV MTP000
MOV #207,UIPAR2 ;PUT 'RETURN' INSTRUCTION AFTER WRITE ROUTINE
MOV #UIPAR3,SUPDOADD
SET NOFSMODE
FOR I := #1 TO #2
FOR BANK := #0 TO #167
CALL EXBANK
IF ACFLAG IS TRUE AND RRFLAG IS FALSE
INVALIDATE ;INVALIDATE BACKGROUND PATTERN ON 'BANK'
LET R2 := BANK
MOV #FIRST,R0
MOV R0,R4
MOV #SIZE,R1
MOV R1,R3
IF I EQ #1
CALL SUPD01
END ;OF IF
IF I EQ #2
CALL SUPD03
END ;OF IF
END ;OF IF
END ;OF FOR BANK
END ;OF FOR I
IF FS7FLAG IS TRUE
CLR NOFSMODE
RETURN
END ;OF IF FS7FLAG
FOR I := #1 TO #2
FOR BANK := #167 DOWNT0 #0
CALL EXBANK
IF ACFLAG IS TRUE AND RRFLAG IS FALSE
LET R2 := BANK
COM R2
MOV #FIRST,R0
MOV R0,R4
MOV #SIZE,R1
MOV R1,R3
IF I EQ #1
CALL SUPD01
END ;OF IF
IF I EQ #2
CALL SUPD03
END ;OF IF
END ;OF IF
END ;OF FOR BANK
END ;OF FOR I
CLR NOFSMODE
RETURN

4179 024754

4180 024754 005037 002362

4181 024760 012737 000030 002366

4182 024766

4183 024776 012737 000001 002100

4184 025004

4185 025012 104470

4186 025014

4187 025030

4188 025034 004737 042422

4189 025040

4190 025046

4191 025062 012701 040000

4192 025066 012700 060000

4193 025072 004737 026042

4194 025076

4195 025076

4196 025076

4197 025112

4198 025120

4199 025126 104502

4200 025130 004737 041130

4201 025134

4202 025136 104472

4203 025140

4204 025150 000207

4205 025152

4206 025152 013737 002400 002106

4207 025160 004737 042422

4208 025164 004737 024760

4209 025170 104472

4210 025172 004737 041604

4211 025176 000207

4212 025200

4213 025200 104472

4214 025202

4215 025212 000207

```

MT0030: SUBTST <<MT0030      SETUP FLUSH OUT DBE'S TEST>>
:*****
:*SUBTEST      MT0030      SETUP FLUSH OUT DBE'S TEST
:*****
MTA030: CLR      PASFLG
MOV      #30,REALPAT      ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
CLEAR   MARGIN,MAINT     ;CLEAR MARGINS
MOV      #1,NOPAR        ;INDICATE COUNT PARITY ERRORS
BMOV    MTP030
ECCDIS                      ;DISABLE ERROR CORRECTION
SET     NOFSMODE,NOSCOPE
FOR BANK := #0 TO #167
CALL   EXBANK
IF MKFLAG IS TRUE
IF ACFLAG IS TRUE AND RRFLAG IS FALSE
MOV     #SIZE,R1
MOV     #FIRST,R0
CALL   SUPD01
END ;OF IF ACFLAG
END ;OF IF MKFLAG
END ;OF FOR
IF PASFLG IS FALSE
SET PASFLG
CLRCR                      ;CLEAR MK11 CSRS
CALL RELOCATE
ON.ERROR
ECCINIT                      ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
CLEAR   NOFSMODE,NOSCOPE
RETURN
END ;OF ON.ERROR
MOV     NEWBANK,BANK
CALL   EXBANK
CALL   MTA030
ECCINIT                      ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
CALL   UNRELOCATE
RETURN
END ;OF IF PASFLG
ECCINIT                      ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
CLEAR   NOFSMODE,NOSCOPE
RETURN

```

4218 025214

MT0031: SUBTST <<MT0031 SETUP SOB-A-LONG TEST>>

:SUBTEST MT0031 SETUP SOB-A-LONG TEST

4219 025214 004737 026006
4220 025220
4221 025224
4222 025232 012737 000031 002366
4223 025240 005037 002100
4224 025244
4225 025260
4226 025266
4227 025300 104417
4228 025302 013702 002704
4229 025306 010200
4230 025310 012701 100776
4231 025314 012705 060056
4232 025320 012737 060002 002360
4233 025326 004737 026234
4234 025332 005037 002540
4235 025336 000207

CALL KAMITEST ;CHECK FOR KAMIKAZE MODE
ON.ERROR THEN \$RETURN ;IF NOT IN KAMIKAZE MODE RETURN
SET NOSCOPE
MOV #31,REALPAT ;SETUP PATTERN NUMBER FOR TYPFOUT & DISPLAY
CLR NOPAR ;SETUP PARITY ACTION
MAP BANK ;MAP FIRST SO BLOCK MOVE WORKS
SUPERVISOR ;ENTER SUPERVISOR MODE
BMOV MTP031,FIRST,SOBLENGTH/2
KERNEL ;ENTER KERNEL MODE
MOV SOBK,R2
MOV R2,R0
MOV #100776,R1 ;COMPLEMENT OF INSTRUCTION "SOB R0,DOT"
MOV #FIRST+SOBLENGTH,R5
CALL SUPD04
CLR NOSCOPE
RETURN

4238 025340

MT0033: SUBST <<MT0033 SETUP WRITE RECOVERY TEST>>

 ;*SUBTEST MTOU33 SETUP WRITE RECOVERY TEST

4239	025340	004737	026006		CALL	KAMITEST		;CHECK FOR KAMIKAZE MODE
4240	025344				ON_ERROR	THEN \$RETURN		;IF NOT IN KAMIKAZE MODE RETURN
4241	025350				SET	NOSCOPE		
4242	025356	012737	000033	002366	MOV	#33,REALPAT		;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
4243	025364	005037	002100		CLR	NOPAR		;SETUP PARITY ACTION
4244	025370				MAP	BANK		;MAP FIRST SO THAT THE BLOCK MOVE WORKS
4245	025404	012700	010247		MOV	#10247,R0		;OPP CODE OF INSTRUCTION 'MOV R2,-(PC)'
4246	025410	012701	177667		MOV	#177667,R1		;OPP CODE OF COMPLEMENT OF INSTRUCTION 'JMP (R0)'
4247	025414	012702	020000		MOV	#SIZE/2,R2		;USED FOR 1/2 BANK LOOP
4248	025420	012703	060000		MOV	#FIRST,R3		
4249	025424	012704	160000		MOV	#LAST+2,R4		
4250								
4251	025430				SUPERVISOR			;ENTER SUPERVISOR MODE
4252								;MOVE TEST TO MEMORY UNDER TEST
4253	025436	010023		1\$:	MOV	R0,(R3)+		
4254	025440	010144			MOV	R1,-(R4)		
4255	025442	077203			SOB	R2,1\$		
4256								
4257								;MOVE LAST PART OF TEST TO FASTCITY
4258	025444				BMOV	MTO33		
4259	025452	104417			KERNEL			;ENTER KERNEL MODE
4260								
4261	025454	012702	005141		MOV	#5141,R2		;OPP CODE OF INSTRUCTION 'COM -(R1)'
4262	025460	012700	025526		MOV	#2\$,R0		;ADDRESS TO RETURN TO IN R0
4263	025464	012701	160000		MOV	#LAST+2,R1		;TOP OF BANK
4264	025470	012737	060000	002360	MOV	#FIRST,SUPDOADD		
4265	025476	004737	026234		CALL	SUPDO4		
4266	025502	012703	020000		MOV	#SIZE/2,R3		
4267	025506	012705	000110		MOV	#110,R5		
4268	025512	012704	060000		MOV	#FIRST,R4		
4269	025516	004737	026056		CALL	SUPDO2		
4270	025522	005037	002540		CLR	NOSCOPE		
4271	025526	000207		2\$:	RETURN			;THIS RETURN ACTS AS A NORMAL RETURN FROM MTO033 ;ALSO A RETURN FROM THE 'CALL SUPDO4' ABOVE
4272								
4273								

4276 025530

MT0034: SUBTST <<MT0034 SETUP BRANCH GOBBLE TEST>>

:*****
:*SUBTEST MT0034 SETUP BRANCH GOBBLE TEST
:*****

4277 025530 004737 026006
4278 025534
4279 025540
4280 025546 012737 000034 002366
4281 025554 005037 002100
4282 025560

CALL KAMITEST ;CHECK FOR KAMIKAZE MODE
ON.ERROR THEN \$RETURN ;IF NOT IN KAMIKAZE MODE RETURN
SET NOSCOPE
MOV #34,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
CLR NOPAR ;SETUP PARITY ACTION
MAP BANK ;MAP FIRST SO THAT BLOCK MOVE WORKS

4283
4284 025574
4285 025602
4286 025614 104417

SUPERVISOR ;ENTER SUPERVISOR MODE
BMOV MTP034,FIRST,GBLENGTH/2
KERNEL ;ENTER KERNEL MODE

4287
4288 025616 012705 060076
4289 025622 012737 060004 002360
4290 025630 012701 060002
4291 025634 012702 060003

MOV #FIRST+GBLENGTH,R5
MOV #FIRST+4,SUPDOADD
MOV #FIRST+2,R1
MOV #FIRST+3,R2

4292
4293 025640 004737 026234
4294 025644 005037 002540
4295 025650 000207

CALL SUPD04
CLR NOSCOPE
RETURN

4296
4297 025652

MT0035: SUBTST <<MT0035 SOFT ERROR - BACKGROUND PATTERN TEST>>

:*****
:*SUBTEST MT0035 SOFT ERROR - BACKGROUND PATTERN TEST
:*****

4298 025652 012737 000035 002366
4299 025660 012700 060000
4300 025664 012701 040000
4301 025670 013702 002744
4302 025674 010103
4303 025676 013705 002106
4304 025702 070527 000006
4305 025706 010004

MOV #35,REALPAT
MOV #FIRST,R0
MOV #SIZE,R1
MOV SOFTPAT,R2
MOV R1,R3
MOV BANK,R5
MUL #6,R5
MOV R0,R4
BMOV MTP000

4306 025710
4307 025716 012737 000207 177644
4308 025724 012737 177646 002360
4309 025732

MOV #207,UIPAR2 ;PUT RETURN INSTRUCTION AFTER WRITE ROUTINE
MOV #UIPAR3,SUPDOADD
IF #BIT13 SET.IN CONFIG+2(R5) AND WRITEONLY IS FALSE

4310
4311 025750 004737 026220
4312 025754
4313

;BACKGROUND PATTERN IS VALID
CALL SUPD03 ;READ IT
ELSE

4314 025756 004737 026042
4315 025762 052765 020000 003020
4316 025770
4317 025770 000207

;BACKGROUND PATTERN HAS BEEN INVALIDATED
CALL SUPD01 ;WRITE IT
BIS #BIT13,CONFIG+2(R5) ;VALIDATE IT
END ;OF IF #BIT13
RETURN

4320 025772

MT0999: SUBTST <<MT0999 SETUP NULL TEST>>
:*****
:*SUBTEST MT0999 SETUP NULL TEST
:*****

4321 025772 005037 002366

4322 025776

4323 026004 000207

4324

4325 026006

CLR REALPAT
SET NULLFLAG
RETURN

KAMITEST:SUBTST <<CHECK FOR KAMIKAZE MODE>>
:*****
:*SUBTEST CHECK FOR KAMIKAZE MODE
:*****

4326 026006

4327 026030

4328 026034

4329 026036

4330 026042

IF KAMIKAZE IS TRUE OR ACTFLAG IS TRUE OR APTFLAG IS TRUE
\$RETURN NOERROR ;RUN THE TEST
ELSE
\$RETURN ERROR ;DON'T RUN THE TEST
END ;OF IF KAMIKAZE

4334 026042

4335 026042
 4336 026056 004737 066514
 4337 026062
 4338 026072 010037 002266
 4339 026076 012700 00227C
 4340 026102 010120
 4341 026104 010220
 4342 026106 010320
 4343 026110 010420
 4344 026112 010520
 4345 026114 010620
 4346 026116 013700 002266
 4347 026122 012737 026136 002746
 4348 026130 013737 002746 002750
 4349 026136 012700 002304
 4350 026142 014006
 4351 026144 014005
 4352 026146 014004
 4353 026150 014003
 4354 026152 014002
 4355 026154 014001
 4356 026156 014000
 4357 026160
 4358 026166 012706 000740
 4359 026172 104424
 4360 026174 004737 177640
 4361 026200 104423
 4362 026202 104417
 4363 026204 000004
 4364 026206
 4365 026216 000207

```

SUPD01: SUBTST <<SUBR EXECUTE PATTERN IN SUPERVISOR>>
:*****
:*SUBTEST SUBR EXECUTE PATTERN IN SUPERVISOR
:*****
MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
SUPD02: CALL GETDIS
PUSH $LPERR,$LPADR
MOV R0,SUPDRO
MOV #SUPDR1,R0
MOV R1,(R0)+
MOV R2,(R0)+
MOV R3,(R0)+
MOV R4,(R0)+
MOV R5,(R0)+
MOV SP,(R0)+
MOV SUPDRO,R0
MOV #TAG4,$LPADR
TAG4$: MOV $LPADR,$LPERR
MOV #SUPDR6+2,R0
MOV -(R0),SP
MOV -(R0),R5
MOV -(R0),R4
MOV -(R0),R3
MOV -(R0),R2
MOV -(R0),R1
MOV -(R0),R0
SUPERVISOR ;ENTER SUPERVISOR MODE
MOV #SUPSTK,SSP
CACHOFF ;TURN CACHE OFF
CALL FASTCITY ;CALL TO THE USER INSTRUCTION PAR'S
CACHON ;TURN CACHE ON
KERNEL ;ENTER KERNEL MODE
SCOPE
POP $LPADR,$LPERR
RETURN
  
```



```

4369 026220
4370 026234 004737 066514
4371 026240
4372 026250 010037 002266
4373 026254 012700 002270
4374 026260 010120
4375 026262 010220
4376 026264 010320
4377 026266 010420
4378 026270 010520
4379 026272 010620
4380 026274 013700 002266
4381 026300 012737 026314 002746
4382 026306 013737 002746 002750
4383 026314 012700 002304
4384 026320 014006
4385 026322 014005
4386 026324 014004
4387 026326 014003
4388 026330 014002
4389 026332 014001
4390 026334 014000
4391 026336
4392 026344 012706 000740
4393 026350 104424
4394 026352 004777 15400
4395 026356 104423
4396 026360 104417
4397 026362 000004
4398 026364
4399 026374 000207

SUPD03: MAP BANK
SUPD04: CALL GETDIS ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
PUSH $LPERR,$LPADR
MOV R0,SUPDR0
MOV #SUPDR1,R0
MOV R1,(R0)+
MOV R2,(R0)+
MOV R3,(R0)+
MOV R4,(R0)+
MOV R5,(R0)+
MOV SP,(R0)+
MOV SUPDR0,R0
MOV #TBG4$, $LPADR
MOV $LPADR,$LPERR
TBG4$: MOV #SUPDR6+2,R0
MOV -(R0),SP
MOV -(R0),R5
MOV -(R0),R4
MOV -(R0),R3
MOV -(R0),R2
MOV -(R0),R1
MOV -(R0),R0
SUPERVISOR ;ENTER SUPERVISOR MODE
MOV #SUPSTK,SSP
CACHOFF ;TURN CACHE OFF
CALL @SUPDOADD
CACHON ;TURN CACHE ON
KERNEL ;ENTER KERNEL MODE
SCOPE
POP $LPADR,$LPERR
RETURN

```

4403
4404
4405
4406
4407
4408
4409
4410
4411
4412
4413 026376

```
.SBTTL MEMORY TEST PATTERN ROUTINES
*****
PATTERN REGISTER CONVENTIONS
R0 FIRST ADDRESS OF PATTERN (FIRST, LAST+2, ETC)
R1 NUMBER OF ADDRESSES IN PATTERN (SIZE)
R2 DATA FOR PATTERN (ONES, 52525, ETC)
R3 COPY OF R1 (IF NECESSARY)
R4 COPY OF R0 (IF NECESSARY)
R5 COPY OF R2 (IF NECESSARY)
*****
```

4414 026376 010220
4415 026400 077102
4416 026402 000240
4417 026404 012401
4418 026406 020102
4419 026410 001402
4420 026412 104430
4421 026414 000240
4422 026416 077306
4423 026420 000207
4424 026422

```
MTP000: SUBTST <<MTP000 BASIC DATA TEST>>
*****
*SUBTEST MTP000 BASIC DATA TEST
*****
1$: MOV R2,(R0)+ :V177640
SOB R1,MTP000 :V177642
NOP :V177644
2$: MOV (R4)+,R1 :V177646
CMP R1,R2 :V177650
BEQ 3$ :V177652
PERRO2 :V177654
NOP :V177656
3$: SOB R3,2$ :V177660
RETURN :V177662
```

4425 026422 010220
4426 026424 062702 000002
4427 026430 077104
4428 026432 000240
4429 026434 012400
4430 026436 020005
4431 026440 001401
4432 026442 104427
4433 026444 062705 000002
4434 026450 077307
4435 026452 000207
4436 026454

```
MTP001: SUBTST <<MTP001 ADDRESS TEST>>
*****
*SUBTEST MTP001 ADDRESS TEST
*****
3$: MOV R2,(R0)+ :V177640
ADD #2,R2 :V177642
SOB R1,3$ :V177646
NOP :V177650
1$: MOV (R4)+,R0 :V177652
CMP R0,R5 :V177654
BEQ 2$ :V177656
PERRO1 :V177660
2$: ADD #2,R5 :V177662
SOB R3,1$ :V177666
RETURN :V177672
```

4437 026454 010540
4438 026456 062705 000002
4439 026462 077104
4440 026464 000240
4441 026466 162702 000002
4442 026472 012401
4443 026474 020102
4444 026476 001401
4445 026500 104430
4446 026502 077307
4447 026504 000207

```
MTP002: SUBTST <<MTP002 COMPLEMENT ADDRESS TEST (WRITE DOWN, READ UP)>>
*****
*SUBTEST MTP002 COMPLEMENT ADDRESS TEST (WRITE DOWN, READ UP)
*****
3$: MOV R5,-(R0) :V177640
ADD #2,R5 :V177642
SOB R1,3$ :V177646
NOP :V177650
1$: SUB #2,R2 :V177652
MOV (R4)+,R1 :V177656
CMP R1,R2 :V177660
BEQ 2$ :V177662
PERRO2 :V177664
2$: SOB R3,1$ :V177666
RETURN :V177670
```

4451 026506

MTPA03: SUBST <<MTPA03 3 XOR 9 WORST CASE NOISE TEST (WRITE)>>
:*****
:*SUBTEST MTPA03 3 XOR 9 WORST CASE NOISE TEST (WRITE)
:*****

4452 :R0 = INTERLEAVE FACTOR
4453 :R1 = ADDRESS
4454 :R2 = SMALL LOOP CONSTANT
4455 :R3 = NUM OF ADD TO TEST (LARGE LOOP)
4456 :R4 = GOOD DATA
4457 :R5 = MEDIUM LOOP CONSTANT

4458 .ENABL LSB
4459 026506 060001 1\$. ADD R0,R1 :V177636 ADD INTERLEAVE FACTOR
4460 026510 010421 MOV R4,(R1)+ :V177640
4461 026512 010421 MOV R4,(R1)+ :V177642
4462 026514 077204 SOB R2,1\$:V177644
4463 026516 005104 COM R4 :V177646
4464 026520 052704 BIS (PC)+,R4 :V177650
4465 026522 000401 WARN2: 401 :V177652 WARNING LOCATION IS MODIFIED BEFORE LOADING
4466 026524 012702 000004 MOV #4,R2 :V177654
4467 026530 077512 SOB R5,1\$:V177660
4468 026532 005104 COM R4 :V177662
4469 026534 052704 BIS (PC)+,R4 :V177664
4470 026536 000401 WARN3: 401 :V177666 WARNING LOCATION IS MODIFIED BEFORE LOADING
4471 026540 012705 000100 MOV #64,R5 :V177670
4472 026544 077320 SOB R3,1\$:V177674
4473 026546 000207 RETURN :V177676
4474 .DSABL LSB
4475

4476 026550

MTPB03: SUBST <<MTPB03 3 XOR 9 WORST CASE NOISE TEST (READ)>>
:*****
:*SUBTEST MTPB03 3 XOR 9 WORST CASE NOISE TEST (READ)
:*****

4477 .ENABL LSB
4478 026550 000137 172360 1\$: JMP KDPAR0 :V177640 GO TO V172360
4479 026554 077203 SOB R2,1\$:V177644
4480 026556 005104 COM R4 :V177646
4481 026560 052704 BIS (PC)+,R4 :V177650
4482 026562 000401 WARN4: 401 :V177652 WARNING LOCATION IS MODIFIED BEFORE LOADING
4483 026564 012702 000004 MOV #4,R2 :V177654
4484 026570 077517 SOB R5,1\$:V177660
4485 026572 005104 COM R4 :V177662
4486 026574 052704 BIS (PC)+,R4 :V177664
4487 026576 000401 WARN5: 401 :V177666 WARNING LOCATION IS MODIFIED BEFORE LOADING
4488 026600 012705 000100 MOV #64,R5 :V177670
4489 026604 077317 SOB R3,1\$:V177674
4490 026606 000207 RETURN :V177676
4491 .DSABL LSB

4494 026610

MTPC03: SUBSTST <<MTPC03 TEST DATA SUBPROGRAM>>
:*****

:*SUBTEST MTPC03 TEST DATA SUBPROGRAM
:*****

4495 026610 060001
4496 026612 020421
4497 026614 001401
4498 026616 104431
4499 026620 005141
4500 026622 005111
4501 026624 000137 172260

```

      ADD    R0,R1          :V172360
      CMP    R4,(R1)+       :V172362
      BEQ    1$             :V172364
      PERRO3 :V172366
1$:   COM    -(R1)          :V172370
      COM    (R1)           :V172372
      JMP    SDPAR0         :V174372          GO TO V172260

```

4502
4503 026630

MTPD03: SUBSTST <<MTPD03 TEST DATA SUBSUBPROGRAM>>
:*****

:*SUBTEST MTPD03 TEST DATA SUBSUBPROGRAM
:*****

4504 026630 020421
4505 026632 001401
4506 026634 104431
4507 026636 005127
4508 026640 000000
4509 026642 001033
4510 026644 000137 177644

```

      CMP    R4,(R1)+       :V172260
      BEQ    1$             :V172262
      PERRO3 :V172264
1$:   COM    (PC)+         :V172266
      O      :V172270
      BNE   .+70           :V172272          GO TO V172362
      JMP   UIPAR2        :V172274          GO TO V177644

```

4513 026650

```

MTPA04: SUBTST <<MTPA04      ROTATING ZEROS TEST>>
:*****
:*SUBTEST      MTPA04  ROTATING ZEROS TEST
:*****
1$:  MOV      #8,R5          :V177640
      MOV      R5,R4          :V177644
      CLC                      :V177646
      JMP      KDPAR0 ;V177650
      MOV      -2(R0),R4       :V177654
      BCS      2$              :V177660
      CMP      R2,R4          :V177662
      BEQ      3$              :V177664
2$:  PERRO4                     :V177666
3$:  SOB      R1,1$           :V177670
      RETURN                     :V177672
    
```

4514 026650 012705 000010
4515 026654 010504
4516 026656 000241
4517 026660 000137 172360
4518 026664 016004 177776
4519 026670 103402
4520 026672 020204
4521 026674 001401
4522 026676 104432
4523 026700 077115
4524 026702 000207
4525
4526 026704

```

MTPB04: SUBTST <<MTPB04      SUBR      ROTATING BIT>>
:*****
:*SUBTEST      MTPB04  SUBR      ROTATING BIT
:*****
1$:  ROLB     (R0)           :V172360
      SOB     R5,1$          :V172362
4527 026704 106110  

4528 026706 077502  

4529 026710 106120  

4530 026712 106110  

4531 026714 077402  

4532 026716 106120  

4533 026720 000137 177654  

4534  

4535 026724
2$:  ROLB     (R0)           :V172366
      SOB     R4,2$          :V172370
      ROLB     (R0)+         :V172372
      JMP     UIPAR6         :V172374
    
```

```

MTP005: SUBTST <<MTP005      ROTATION ONES TEST>>
:*****
:*SUBTEST      MTP005  ROTATION ONES TEST
:*****
1$:  MOV      #8,R5          :V177640
      MOV      R5,R4          :V177644
      SEC                      :V177646
      JMP      KDPAR0 ;V177650
      MOV      -2(R0),R4       :V177654
      BCC      2$              :V177660 IF THIS HAPPENS THE GOOD & BAD MATCH
      CMP      R2,R4          :V177662
      BEQ      3$              :V177664
2$:  PERRO4                     :V177666
3$:  SOB      R1,1$           :V177670
      RETURN                     :V177672
    
```

4536 026724 012705 000010
4537 026730 010504
4538 026732 000261
4539 026734 000137 172360
4540 026740 016004 177776
4541 026744 103002
4542 026746 020204
4543 026750 001401
4544 026752 104432
4545 026754 077115
4546 026756 000207

```

4550 026760          MTP006: SUBTST <<MTP006      INITIAL DATA TEST>>
:*****
:SUBTEST          MTP006  INITIAL DATA TEST
:*****
:          THIS TEST CHECKS THE DI/DO LINES BY
:          SHIFTING A 1 THROUGH THE WORD.
4551          :
4552          :
4553 026760 012737 000001 002340      MOV      #1,DATBUF      ;SET THE FIRST TEST BIT
4554 026766 005037 002342              CLR      DATBUF+2      ;CLEAR 2ND WORD
4555 026772 013711 002340      1$:      MOV      DATBUF,(R1)    ;WRITE TEST WORD 1
4556 026776 013761 002347 000002      MOV      DATBUF+2,2(R1) ;AND TEST WORD 2
4557 027004 011102              MOV      (R1),R2
4558 027006 023702 002340      CMP      DATBUF,R2     ;NOW READ THEM
4559 027012 001401              BEQ      2$            ;BR IF FIRST 16 OK
4560 027014 104433              PERR07   ;ERROR TRAP
4561          :
4562 027016 016102 000002      2$:      MOV      2(R1),R2
4563 027022 023702 002342      CMP      DATBUF+2,R2   ;NOW READ SECOND WORD
4564 027026 001401              BEQ      3$            ;BR IF OK
4565 027030 104434              PERR10   ;ERROR TRAP
4566          :
4567 027032 005737 002342      3$:      TST      DATBUF+2     ;HAS LAST BIT BEEN TESTED ?
4568 027036 100405              BMI      4$            ;MINUS MEANS BIT 31
4569 027040              DLEFT   DATBUF        ;NO, SHIFT TEST BIT LEFT
4570 027050 000750              BR       1$            ;GO WRITE NEW TEST DATA
4571          :
4572 027052 012737 177776 002340      4$:      MOV      #177776,DATBUF ;PUT A 0 IN BIT 0
4573 027060 012737 177777 002342      MOV      #-1,DATBUF+2  ;AND 1'S IN ALL OTHERS
4574 027066 013711 002340      5$:      MOV      DATBUF,(R1)    ;WRITE THE DATA
4575 027072 013761 002342 000002      MOV      DATBUF+2,2(R1) ;2 WORDS WORTH
4576 027100 011102              MOV      (R1),R2
4577 027102 023702 002340      CMP      DATBUF,R2     ;NOW READ FIRST WORD
4578 027106 001401              BEQ      6$            ;BR IF OK
4579 027110 104433              PERR07
4580          :
4581 027112 016102 000002      6$:      MOV      2(R1),R2
4582 027116 023702 002342      CMP      DATBUF+2,R2   ;NOW, READ SECOND WORD
4583 027122 001401              BEQ      7$            ;BR IF OK
4584 027124 104434              PERR10
4585          :
4586 027126 005737 002342      7$:      TST      DATBUF+2     ;TESTED BIT 31 YET?
4587 027132 100005              BPL      8$            ;BR IF YES, WE'RE DONE
4588 027134              DLEFT   DATBUF
4589 027144 000750              BR       5$            ;KEEP GOING
4590 027146 000207      8$:      RETURN

```

4594 027150

MTP007. SUBTST <<MTP007 ADDRESS BIT TEST>>

:SUBTEST MTP007 ADDRESS BIT TEST

```

4595
4596
4597
4598
4599 027150 111100      MOVB   (R1),R0
4600 027152 105700      TSTB   R0           ;READ AND COMPARE FOR ZEROS
4601 027154 001401      BEQ    1$           ;BR IF OK
4602 027156 104435      PERR11
4603
4604 027160 105111      1$:   COMB   (R1)           ;COMPLEMENT THE BYTE
4605 027162 111100      MCVB   (R1),R0
4606 027164 105700      TSTB   R0           ;READ FOR NON ZEROS
4607 027166 001001      BNE    2$           ;BR IF OK
4608 027170 104436      PERR12
4609
4610 027172 040201      2$:   BIC    R2,R1       ;MASK OFF THE ASSERTED BIT
4611 027174 006302      ASL    R2           ;SHIFT R2 FOR NEXT BIT
4612 027176 050201      BIS    R2,R1       ;SET THE NEW BIT INTO R1
4613 027200 011100      MOV    (R1),R0
4614 027202 005700      TST    R0           ;READ THE NEW ADDRESS
4615 027204 001401      BEQ    3$           ;READ FOR ZEROS
4616 027206 104437      PERR13
4617
4618 027210 005111      3$:   COM    (R1)           ;COMPL THE WORD
4619 027212 011100      MOV    (R1),R0
4620 027214 005700      TST    R0           ;READ IT AGAIN
4621 027216 001001      BNE    4$           ;
4622 027220 104440      PERR14
4623
4624 027222 022702 100000      4$:   CMP    #100000,R2
4625 027226 001407      BEQ    5$
4626 027230 022702 010000      CMP    #10000,R2    ;CHECK FOR MSB IN 4K BANK
4627 027234 001356      BNE    2$           ;NOT LAST BIT, BRANCH
4628 027236 006302      ASL    R2
4629 027240 012701 160000      MOV    #160000,R1
4630 027244 000752      BR    2$
4631 027246 000207      5$:   RETURN

```

4634 027250

MTP010: SUBST <<MTP010 BYTE ADDRESSING TEST>>
 :*****
 :*SUBTEST MTP010 BYTE ADDRESSING TEST
 :*****

```

4635                                     :TEST 3 THIS TEST CHECKS FOR PROPER
4636                                     :      BYTE ADDRESSING WITH ECC DISABLED
4637 027250 010402      MOV      R4,R2      ;R4 HAS LOWEST ADDRESS
4638 027252 010403      MOV      R4,R3      ;PUT IT IN R3 ALSO
4639 027254 062702 000004  ADD      #4,R2      ;POINT R2 TO LAST BYTE +1
4640 027260 012713 177777  MOV      #-1,(R3)     ;WRITE ALL ONES IN
4641 027264 012763 177777 000002  MOV      #-1,2(R3)    ;THE 4 TEST BYTES
4642 027272 105013      1$:      CLRB     (R3)      ;CLEAR A BYTE
4643 027274 010401      MOV      R4,R1      ;INITIALIZE R1 FOR EACH PASS
4644 027276 020201      2$:      CMP      R2,R1      ;IF EQUAL, JUST READ LAST BYTE
4645 027300 001420      BEQ      6$          ;BR IF EQUAL
4646 027302 020301      CMP      R3,R1      ;IS THIS THE BYTE OF ZEROS
4647 027304 001007      BNE      4$          ;BR IF NOT
4648 027306 111100      MOVB     (R1),R0
4649                                     ;WARNING IF YOU OPTIMIZE CHANGE THE PCBUMP FOR THIS ERROR INCASE OF TRAPS
4650 027310 022700 000000  CMP      #0,R0      ;IT IS, COMPARE FOR ZEROS
4651 027314 001401      BEQ      3$
4652 027316 104435      PERR11
4653
4654 027320 005201      3$:      INC      R1          ;NEXT BYTE
4655 027322 000765      BR       2$          ;RETURN
4656 027324 111100      4$:      MOVB     (R1),R0
4657 027326 122700 177777  CMPB     #-1,R0      ;ITS NOT THE BYTE OF 0'S, READ 1'S
4658 027332 001401      BEQ      5$
4659 027334 104436      PERR12
4660
4661 027336 005201      5$:      INC      R1          ;MOVE TO NEXT BYTE
4662 027340 000756      BR       2$
4663 027342 112713 177777  6$:      MOVB     #-1,(R3)   ;RESTORE 1'S TO BYTE JUST TESTED
4664 027346 005203      INC      R3          ;INC TO NEXT BYTE
4665 027350 020302      CMP      R3,R2      ;WAS THAT JUST THE LAST ONE?
4666 027352 001347      BNE      1$          ;BR IF NO
4667 027354 000207      RETURN
    
```


4671 027356

```
MTP011: SUBTST <<MPT011 SINGLE BIT ERROR TEST>>
:*****
:*SUBTEST MPT011 SINGLE BIT ERROR TEST
:*****
```

4672
4673
4674
4675
4676
4677
4678
4679
4680
4681
4682
4683
4684
4685
4686
4687
4688 027356 104503
4689
4690 027360 012737 000001 002340 1\$:
4691 027366 005037 002342
4692
4693 027372 012737 000001 002350 2\$:
4694 027400 005037 002352
4695
4696 027404 013737 002340 002344 3\$:
4697 027412 013737 002342 002346
4698 027420 105737 002362
4699 027424 001404
4700 027426 005137 002344
4701 027432 005137 002346
4702 027436 013702 002344 4\$:
4703 027442 013703 002346
4704 027446 012737 002344 002402
4705 027454 004737 040540
4706
4707
4708
4709 027460 013701 002350
4710 027464 074137 002344
4711 027470 013701 002352
4712 027474 074137 002346
4713 027500 013701 002506 5\$:
4714 027504 104471
4715 027506 013721 002344
4716 027512 104475
4717 027514 013711 002346
4718
4719
4720
4721 027520 104471
4722 027522 014100
4723 027524 020037 002344
4724 027530 001401

```
:(1) CREATE A SINGLE BIT ERROR
:(2) READ BACK SBE UNCORRECTED (WITH ECC DISABLE)
:(3) ENABLE ECC & READ CORRECTED DATA
:(4) CHECK THAT THE SBE FLAG WAS SET FORM THE LAST READ
:(5) DO (1-4) FOR DATA CONSISTING OF 1 BIT SET IN EACH OF 32
POSITIONS OF A DOUBLE WORD
THEN DO IT AGAIN FOR 1 BIT CLEARED IN EACH OF 32 POSITIONS OF
A DOUBLE WORD
IE (64 TIMES)
:(6) DO (1-5) FOR A SBE IN EACH OF 32 BIT POSITIONS
IE (RUN TEST 64 * 32 = 2048 TIMES)
CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
;BIG LOOP
MOV #1,DATBUF ;INITIAL DATA
CLR DATBUF+2 ;32 BITS WORTH
;MEDIUM LOOP
MOV #1,SBEMSK ;INITIAL ERROR MASK
CLR SBEMSK+2 ;32 BITS WORTH
;LITTLE LOOP
MOV DATBUF,TSTDAT ;
MOV DATBUF+2,TSTDAT+2;TO SAVE ORIG DATA
TSTB PASFLG ;COMP DATA ON SECOND PASSONLY
BEQ 4$ ;BR IF FIRST PASS
COM TSTDAT ;SECOND PASS, COMP BOTH WORDS
COM TSTDAT+2
4$: MOV TSTDAT,R2
MOV TSTDAT+2,R3
MOV #TSTDAT,SOURCE ;SET UP ADDRESS FOR CHKGEN
CALL CHKGEN ;GEN CHECKBITS ON TSTDAT
:*****
:** CREATE A SINGLE BIT ERROR **
:*****
MOV SBEMSK,R1
XOR R1,TSTDAT
MOV SBEMSK+2,R1
XOR R1,TSTDAT+2
5$: MOV TESTADD,R1 ;FIRST TEST ADDRESS
ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
MOV TSTDAT,(R1)+ ;WRITE FIRST 16 BITS
CB1CSR ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
MOV TSTDAT+2,(R1) ;WRITE SECOND 16 BITS AND
;CHECK BITS. WE NOW HAVE CHECKBITS
;GENERATED ON DATBUF AND DATA WITH
;ONE BIT IN ERROR (AS PER SBEMSK).
;DISABLE ECC ON 1 SELECTED CSR
ECC1DIS
MOV -(R1),R0
CMP R0,TSTDAT ;READ THE LOW WORD (UNCORRECTED)
BEQ 6$ ;BR IF OK
```

```

4725 027532 104455          PERR31
4726
4727 027534 062701 000002    6$:  ADD    #2,R1          ;POINT R1 TO SECOND 16 BITS
4728 027540 011100          MOV    (R1),R0
4729 027542 020037 002346    CMP    R0,TSTDAT+2      ;READ THE HIGH WORD (UNCORRECTED)
4730 027546 001401          BEQ    7$              ;BR IF OK
4731 027550 104455          PERR31
4732
4733 027552 104503          7$:  CLR1CSR          ;CLEAR 1 SELECTED MK11 CSR
4734 027554 014100          MOV    -(R1),R0
4735 027556 020002          CMP    R0,R2          ;SEE IF ITS BEEN CORRECTED
4736 027560 001401          BEQ    8$              ;IT SHOULD HAVE BEEN
4737 027562 104456          PERR32
4738
4739 027564 104510          8$:  TSTREAD          ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
4740 027566 103411          BCS    9$              ;BR IF IT IS SET
4741 027570          SET    HEADER          ;ENABLE PRINTING OF ERROR HEADER INFO
4742 027576 010137 002040    MOV    R1,ADDRESS
4743 027602 104460          PERR34
4744 027604          SET    HEADER          ;ENABLE PRINTING OF ERROR HEADER INFO
4745
4746 027612 104503          9$:  CLR1CSR          ;CLEAR 1 SELECTED MK11 CSR
4747 027614 062701 000002    ADD    #2,R1          ;POINT TO HIGH WORD
4748 027620 011100          MOV    (R1),R0
4749 027622 020003          CMP    R0,R3          ;SEE IF ITS BEEN CORRECTED
4750 027624 001401          BEQ    10$             ;BR IF OK
4751 027626 104456          PERR32
4752
4753 027630 104510          10$: TSTREAD          ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
4754 027632 103411          BCS    11$            ;BR IF YES
4755 027634          SET    HEADER          ;ENABLE PRINTING OF ERROR HEADER INFO
4756 027642 010137 002040    MOV    R1,ADDRESS
4757 027646 104460          PERR34
4758 027650          SET    HEADER          ;ENABLE PRINTING OF ERROR HEADER INFO
4759 027656 005737 002352    11$: TST    SBEMSK+2      ;TEST FOR LAST MASK BIT
4760 027662 100405          BMI    12$            ;MINUS MEANS BIT 31
4761 027664          DLEFT SBEMSK
4762 027674 000643          BR     3$
4763 027676          12$: IF #SW11 SET. IN @SWR THEN GOTO 13$
4764 027706          IF QVFLAG IS TRUE THEN GOTO 13$
4765 027714 005737 002342    TST    DATBUF+2        ;LAST DATA BIT ?
4766 027720 100405          BMI    13$            ;WHICH IS BIT 31
4767 027722          DLEFT DATBUF
4768 027732 000617          BR     2$
4769 027734 105737 002362    13$: TSTB    PASFLG      ;FIRST OR SECOND PASS ?
4770 027740 001003          BNE    14$            ;NON ZERO MEANS WE'RE DONE
4771 027742 105237 002362    INCB   PASFLG          ;NOT DONE, GO DO SECOND PASS
4772 027746 000604          BR     1$
4773          ;CLEAR OUT ANY DBE'S OR SBE'S
4774 027750 104471          14$: ECC1DIS          ;DISABLE ECC ON 1 SELECTED CSR
4775 027752 013701 002506    MOV    TESTADD,R1
4776 027756          CLEAR (R1)+,(R1)
4777 027762 104503          CLR1CSR          ;CLEAR 1 SELECTED MK11 CSR
4778 027764 000207          RETURN

```

4782 027766

MTP012: SUBST <<MTP012 WRITE BYTE CLEARS SBE TEST>>
:*****
:*SUBTEST MTP012 WRITE BYTE CLEARS SBE TEST
:*****

```

4783 ;SINGLE BIT ERROR TEST TO INSURE THAT A WRITE
4784 ;BYTE CLEARS SINGLE BIT ERRORS.
4785 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
4786 027766 104503 MOV #1,DATBUF ;INITIAL DATA
4787 027770 012737 000001 002340 CLR DATBUF+2 ;32 BITS WORTH
4788 030002 012737 000001 002350 1$: MOV #1,SBEMSK ;INITIAL ERROR MASK
4789 030010 005037 002352 CLR SBEMSK+2 ;32 BITS WORTH
4790 030014 013737 002340 002344 2$: MOV DATBUF,TSTDAT ;SAVE ORIGINAL DATA
4791 030022 013737 002342 002346 MOV DATBUF+2,TSTDAT+2 ;BOTH WORDS
4792 030030 012737 002344 002402 MOV #TSTDAT,SOURCE ;NEED ADDRESS FOR CHKGEN
4793 030036 004737 040540 CALL CHKGEN ;GENERATE CHECK BITS
4794 030042 013701 002350 MOV SBEMSK,R1
4795 030046 074137 002344 XOR R1,TSTDAT
4796 030052 013701 002352 MOV SBEMSK+2,R1
4797 030056 074137 002346 XOR R1,TSTDAT+2
4798 030062 013704 002506 3$: MOV TESTADD,R4 ;FIRST TEST ADDRESS
4799 030066 010401 MOV R4,R1 ;PUT IT IN R1 ALSO
4800 030070 104471 ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
4801 030072 013721 002344 MOV TSTDAT,(R1)+ ;WRITE 16 BITS
4802 030076 104475 CB1CSR ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
4803 030080 013711 002346 MOV TSTDAT+2,(R1) ;WRITE HIGH WORD+CHECKBITS
4804 030104 104503 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
4805 ;IT'S DANGEROUS IF WE DON'T
4806 030106 012702 002350 MOV #SBEMSK,R2 ;ADDRESS OF ERROR MASK
4807 030112 162701 000002 SUB #2,R1 ;ADJUST ADDRESS
4808 030116 112711 177777 4$: MOVB #-1,(R1) ;WRITE A BYTE OF 1'S
4809 030122 132712 177777 BITB #-1,(R2) ;DID THIS BYTE HAVE THE BAD BIT IN IT?
4810 030126 001420 BEQ 6$ ;NO - BRANCH
4811 030130 104510 TSTREAD ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
4812 030132 103011 BCC 5$ ;NO - SKIP
4813 030134 SET HEADER ;ENABLE PRINTING OF ERROR HEADER INFO
4814 030142 010137 002040 MOV R1,ADDRESS
4815 030146 104017 ERROR +17
4816 030150 SET HEADER ;ENABLE PRINTING OF ERROR HEADER INFO
4817
4818 030156 111100 5$: MOVB (R1),R0
4819 030160 122700 177777 MPB #-1,R0 ;CHECK DATA
4820 030164 001414 BEQ 7$ ;BR IF OK
4821 030166 104457 PERR33
4822
4823 030170 104510 6$: TSTREAD ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
4824 ;READ THE BYTE
4825 ;SBE ERROR BIT ONLY SET ?
4826 030172 103771 BCS 5$ ;SHOULD BE SET, BR IF OK
4827 030174 SET HEADER ;ENABLE PRINTING OF ERROR HEADER INFO
4828 030202 010137 002040 MOV R1,ADDRESS
4829 030206 104460 PERR34
4830 030210 SET HEADER ;ENABLE PRINTING OF ERROR HEADER INFO
4831
4832 030216 132712 177777 7$: BITB #-1,(R2) ;CHECK FOR LAST BYTE
4833 030222 001012 BNE 8$ ;
4834 030224 005202 INC R2 ;
4835 030226 005201 INC R1 ;MOVE TO NEXT BYTE

```

```

4836 030230 013704 002506      MOV     TESTADD,R4      ;FIRST TEST ADDRESS
4837 030234 032701 00000?      BIT     #2,R1          ;TEST FOR LOWER WORD
4838 030240 001726              BEQ     4$             ;BR IF IT'S LOW 16 BITS
4839 030242 062704 000002      ADD     #2,R4          ;ADJUST POINTER FOR ERROR REPT.
4840 030246 000723              BR      4$
4841 030250 005737 002352      8$:    TST     SBEMSK+2    ;LAST ERROR BIT ?
4842 030254 100405              BMI     9$            ;MINUS MEANS BIT 31
4843 030256              DLEFT  SBEMSK
4844 030266 000652              BR      2$
4845 030270              9$:    IF #SW11 SET.IN @SWR THEN GOTO 10$
4846 030300              IF QVFLAG IS TRUE THEN GOTO 10$
4847 030306 005737 002342      TST     DATBUF+2      ;LAST DATA BIT?
4848 030312 100405              BMI     10$           ;MINUS = BIT 31
4849 030314              DLEFT  DATBUF
4850 030324 000626              BR      1$
4851              ;CLEAR OUT ANY DBE'S OR SBE'S
4852 030326 104471              10$:   ECC1DIS          ;DISABLE ECC ON 1 SELECTED CSR
4853 030330 013701 002506      MOV     TESTADD,R1
4854 030334              CLEAR  (R1)+,(R1)
4855 030340 104503              CLR1CSR          ;CLEAR 1 SELECTED MK11 CSR
4856 030342 00020?              RETURN

```

4860 030344

```

MTP013: SUBST <<MTP013      CREATE DOUBLE BIT ERROR TEST>>
:*****
:*SUBTEST      MTP013 CREATE DOUBLE BIT ERROR TEST
:*****
;DOUBLE BIT ERROR FORCE TO CHECK DOUBLE ERROR LOGIC
;CLEAR 1 SELECTED MK11 CSR
CLR1CSR
MOV TESTADD,R1
1$: CLR DATBUF ;MAKE INITIAL DATA
CLR DATBUF+2 ;ALL ZEROS
2$: MOV #1,SBEMSK ;INITIAL SINGLE ERROR MASK
CLR SBEMSK+2 ;SECOND WORD
3$: MOV #1,DBEMSK ;INITIAL DOUBLE ERROR MASK
CLR DBEMSK+2 ;32 BITS HERE ALSO
4$: MOV DATBUF,TSTDAT
MOV DATBUF+2,TSTDAT+2
TSTB PASFLG ;NO COMPLEMENTING FIRST PASS
BEQ 5$
COM TSTDAT ;COMP FIRST WORD
COM TSTDAT+2 ;SECOND WORD
5$: CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
CMP SBEMSK,DBEMSK ;CAN'T HAVE THE SAME ERROR BIT SET
6$: BNE 6$ ;IN BOTH MASKS
CMP SBEMSK+2,DBEMSK+2 ;COULD BE EQUAL IN SECOND WORD
BEQ 9$ ;GO MAKE THEM NOT EQUAL
7$: MOV #TSTDAT,SOURCE ;SOURCE ADDRESS FOR CHKGEN
CALL CHKGEN ;GO GENERATE CHECK BITS
MOV SBEMSK,R2
XOR R2,TSTDAT
MOV SBEMSK+2,R2
XOR R2,TSTDAT+2
MOV DBEMSK,R2
XOR R2,TSTDAT
MOV DBEMSK+2,R2
XOR R2,TSTDAT+2
ECC1DIS ;DISABLE ELC ON 1 SELECTED CSR
8$: MOV TSTDAT,(R1)+ ;WRITE 16 BITS
CB1CSR ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
MOV TSTDAT+2,(R1) ;WRITE HIGH WORD
CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
SUB #2,R1 ;ADJUST TEST ADDRESS
TST (R1) ;READ THE LOCATION
WAS1DBE ;WAS THERE ANY DOUBLE BIT ERRORS ON 1 SELECTED CSR
9$: BCS 9$ ;IT SHOULD BE SET
SET HEADER
MOV R1,ADDRESS
ERROR +30
SET HEADER

```

4861
4862 030344 104503
4863 030346 013701 002506
4864 030352 005037 002340
4865 030356 005037 002342
4866 030362 012737 000001 002350
4867 030370 005037 002352
4868 030374 012737 000001 002354
4869 030402 005037 002356
4870 030406 013737 002340 002344
4871 030414 013737 002342 002346
4872 030422 105737 002362
4873 030426 001404
4874 030430 005137 002344
4875 030434 005137 002346
4876 030440 104503
4877 030442 023737 002350 002354
4878 030450 001004
4879 030452 023737 002352 002356
4880 030460 001452
4881 030462 012737 002344 002402
4882 030470 004737 040540
4883 030474 013702 002350
4884 030500 074237 002344
4885 030504 013702 002352
4886 030510 074237 002346
4887 030514 013702 002354
4888 030520 074237 002344
4889 030524 013702 002356
4890 030530 074237 002346
4891 030534 104471
4892 030536 013721 002344
4893 030542 104475
4894 030544 013711 002346
4895 030550 104503
4896 030552 162701 000002
4897 030556 005711
4898 030560 104501
4899 030562 103411
4900 030564
4901 030572 010137 002040
4902 030576 104030
4903 030600

```

4906 030606 005737 002356      9$:  TST    DBEMSK+2      ;CHECK MASK FOR LAST BIT
4907 030612 100405                BMI    10$           ;MINUS = BIT31
4908 030614                DLEFT  DBEMSK
4909 030624 000670                BR     4$
4910 030626                10$:  IF #SW11 SET.IN @SWR THEN GOTO 11$
4911 030636                IF QVFLAG IS TRUE THEN GOTO 11$
4912 030644 005737 002352      TST    SBEMSK+2      ;CHECK SINGLE ERROR MASK TOO
4913 030650 100405                BMI    11$           ;BR IF DONE
4914 030652                DLEFT  SBEMSK
4915 030662 000644                BR     3$
4916 030664 105737 002362      11$:  TSTB   PASFLG ;FIRST PASS
4917 030670 001003                BNE    12$           ;NON ZERO MEANS WE'RE DONE
4918 030672 105237 002362      INCB   PASFLG ;FIRST PASS, NOT DONE
4919                ;CLEAR OUT ANY DBE'S OR SBE'S
4920 030676 000625                BR     1$           ;KEEP GOING
4921 030700 104471                12$:  ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
4922 030702 013701 002506      MOV    TESTADD,R1
4923 030706                CLEAR  (R1)+,(R1)
4924 030712 104503                CLR1CSR ;CLEAR 1 SELECTED MK'1 CSR
4925 030714 000207                RETURN

```

4929 030716

MTP014: SUBTST <<MTP014 WRITE INHIBIT DURING DATIP WITH DBE TEST>>

4930
4931
4932
4933
4934
4935
4936
4937
4938
4939
4940
4941
4942
4943
4944
4945
4946
4947
4948
4949
4950
4951
4952
4953
4954
4955
4956
4957
4958
4959
4960
4961
4962
4963
4964
4965
4966
4967
4968
4969
4970
4971
4972
4973
4974
4975
4976
4977
4978
4979
4980
4981
4982

030716 005037 002340
030722 005037 002342
030726 012737 000001
030734 005037 002352
030740 012737 000001
030746 005037 002356
030752 013737 002340
030760 013737 002342
030766 105737 002362
030772 001404
030774 005137 002344
031000 005137 002346
031004 104503
031006 023737 002354
031014 001004
031016 023737 002356
031024 001466
031026 012737 002344
031034 004737 040540
031040 013701 002350
031044 074137 002344
031050 013701 002352
031054 074137 002346
031060 013701 002354
031064 074137 002344
031070 013701 002356
031074 074137 002346
031100 013701 002506
031104 104471
031106 013721 002344
031112 104475
031114 013711 002346
031120 105037 002363
031124 013703 002506
031130 104503
031132 106223
031134 014100
031136 023700 002344
031142 001401
031144 104455
031146 062701 000002
031152 011100
031154 023700 002346
031160 001401
031162 104455

002350
002354
002344
002346
002350
002352
002402
002506
002506

```

:*****
:*SUBTST      MTP014  WRITE INHIBIT DURING DATIP WITH DBE TEST
:*****
:THIS TEST CHECKS THE WRITE INHIBIT ON DOUBLE
:BIT ERRORS DURING A DATIP OPERATION BY USE
:OF AN 'ASRB' INSTRUCTION.
:
:NOTE: THIS IS ONLY A USEFULL TEST ON PDP11/70 WITH THE MULTIPORT ECO
:IE THOSE THAT DO A DATIP ON THE ASRB (LOCK) INSTRUCTION.
1$: CLR      DATBUF      ;INITIAL DATA
   CLR      DATBUF+2    ;2 WORDS WORTH
2$: MOV      #1,SBEMSK  ;INITIAL ERROR MASK
   CLR      SBEMSK+2    ;
3$: MOV      #1,DBEMSK  ;DOUBLE ERROR MASK
   CLR      DBEMSK+2    ;2 WORDS
4$: MOV      DATBUF,TSTDAT ;PRESERVE ORIG DATA
   MOV      DATBUF+2,TSTDAT+2
   TSTB     PASFLG     ;SECOND PASS YET ?
   BEQ      5$        ;BR IF NO
   COM      TSTDAT     ;COMPL DATA ON SECOND PASS
   COM      TSTDAT+2
5$: CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
   CMP      DBEMSK,SBEMSK ;CHECK FOR SAME MASKS
   BNE      6$        ;BR IF OK
   CMP      DBEMSK+2,SBEMSK+2
   BEQ      11$       ;BR IF THEY'RE EQUAL
6$: MOV      #TSTDAT,SOURCE ;SET UP ADDRESS FOR CHKGEN
   CALL     CHKGEN     ;GENERATE CHECK BITS
   MOV      SBEMSK,R1
   XOR      R1,TSTDAT
   MOV      SBEMSK+2,R1
   XOR      R1,TSTDAT+2
   MOV      DBEMSK,R1
   XOR      R1,TSTDAT
   MOV      DBEMSK+2,R1
   XOR      R1,TSTDAT+2
7$: MOV      TESTADD,R1 ;TEST ADDRESS
   ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
   MOV      TSTDAT,(R1)+ ;WRITE FIRST 16 BITS
   CBICSR  ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
   MOV      TSTDAT+2,(R1) ;SECOND 16 BITS+CHECKBITS
   CLR     UPPFLG     ;INDICATE LOWER WORD
   MOV      TESTADD,R3 ;TEST ADDRESS
8$: CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
   ASRB    (R3)+     ;SPECIAL DATIP INSTRUCTION
   MOV     -(R1),R0
   CMP     TSTDAT,R0 ;CHECK FOR UNCHANGED DATA
   BEQ     9$        ;SHOULD BE UNCHANGED
   PERR31
9$: ADD     #2,R1     ;POINT TO UPPER WORD
   MOV     (R1),R0
   CMP     TSTDAT+2,R0 ;READ IT
   BEQ     10$       ;BR IF UNCHANGED
   PERR31

```

```

4983 031164 122737 000003 002363 10$: CMPB #3,UPPFLG ;LOWER WORD
4984 031172 001403 BEQ 11$ ;BR IF NO
4985 031174 105237 002363 INCB UPPFLG
4986 031200 000753 BR 8$
4987 031202 005737 002356 11$: TST DBEMSK+2 ;LAS' BIT IN MASK ?
4988 031206 100405 BMI 12$ ;BR IF BIT 31
4989 031210 DLEFT DBEMSK
4990 031220 000654 BR 4$
4991 031222 12$: IF #SW11 SET. IN @SWR THEN GOTO 13$
4992 031232 IF OVFLAG IS TRUE THEN GOTO 13$
4993 031240 005737 002352 TST SBEMSK+2 ;LAST BIT IN SINGLE ERROR MASK
4994 031244 100405 BMI 13$ ;BR IF YES
4995 031246 DLEFT SBEMSK
4996 031256 000630 BR 3$
4997 031260 105737 002362 13$: TSTB PASFLG ;WHICH PASS
4998 031264 001003 BNE 14$ ;BR IF WE'RE DONE
4999 031266 105237 002362 INCB PASFLG ;INDICATE SECOND PASS COMING
5000 ;CLEAR OUT ANY DBE'S OR SBE'S
5001 031272 000611 BR 1$ ;GO DO IT!
5002 031274 104471 14$: ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
5003 031276 013701 002506 MOV TESTADD,R1
5004 031302 CLEAR (R1)+,(R1) ;CLEAR 1 SELECTED MK11 CSR
5005 031306 104503 CLR1CSR
5006 031310 000207 RETURN
  
```



```

501 031312
MTP015: SUBTST <<MTP015 WRITE INHIBIT OF BYTE WITH DBE>>
*****
: *SUBTEST MTP015 WRITE INHIBIT OF BYTE WITH DBE
*****
5011 ;CHECK FOR WRITE INHIBIT DURING A WRITE BYTE.
5012 ;CHECKS FOR UNCORRECTED DATA.
5013 031312 005037 002340 1$: CLR DATBUF ;INITIAL DATA
5014 031316 005037 002342 CLR DATBUF+2 ;32 BITS WORTH
5015 031322 012737 000001 002350 2$: MOV #1,SBEMSK ;SINGLE ERROR MASK
5016 031330 005037 002352 CLR SBEMSK+2 ;
5017 031334 012737 000001 002354 3$: MOV #1,DBEMSK ;DOUBLE ERROR MASK
5018 031342 005037 002356 CLR DBEMSK+2 ;
5019 031346 013737 002340 002344 4$: MOV DATBUF,TSTDAT ;PRESERVE ORIG DATA
5020 031354 013737 002342 002346 MOV DATBUF+2,TSTDAT+2
5021 031362 105737 002362 TSTB PASFLG ;WHICH PASS ?
5022 031366 001404 BEQ 5$ ;FIRST PASS, NO COMPLEMENTING
5023 031370 005137 002344 COM TSTDAT
5024 031374 005137 002346 COM TSTDAT+2 ;SECOND PASS, COMPLEMENT TSTDAT
5025 031400 104503 5$: CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
5026 031402 023737 002350 002354 CMP SBEMSK,DBEMSK ;CHECK FOR SAME MASKS
5027 031410 001004 BNE 6$ ;BR IF NOT EQUAL
5028 031412 023737 002352 002356 CMP SBEMSK+2,DBEMSK+2 ;SECOND WORD ALSO
5029 031420 001463 BEQ 11$ ;BR TO MAKE THEM NOT EQUAL
5030 031422 012737 002344 002402 6$: MOV #TSTDAT,SOURCE ;ADDRESS FOR CHKGEN
5031 031430 004737 040540 CALL CHKGEN ;GO GENERATE CHECK BITS
5032 031434 013701 002350 MOV SBEMSK,R1
5033 031440 074137 002344 XOR R1,TSTDAT
5034 031444 013701 002352 MOV SBEMSK+2,R1
5035 031450 074137 002346 XOR R1,TSTDAT+2
5036 031454 013701 002354 MOV DBEMSK,R1
5037 031460 074137 002344 XOR R1,TSTDAT
5038 031464 013701 002356 MOV DBEMSK+2,R1
5039 031470 074137 002346 XOR R1,TSTDAT+2
5040 031474 013701 002506 7$: MOV TESTADD,R1 ;TEST LOCATION
5041 031500 104471 ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
5042 031502 013721 002344 MOV TSTDAT,(R1)+ ;WRITE FIRST 16 BITS
5043 ;LOAD CSR WITH IMAGE FROM R2
5044 031506 104475 CB1CSR ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
5045 031510 013711 002346 MOV TSTDAT+2,(R1) ;WRITE SECOND 16 BITS + CHECKBITS
5046 031514 104503 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
5047 031516 013702 002506 MOV TESTADD,R2 ;GET ADDRESS OF TEST LOC
5048 031522 010203 MOV R2,R3 ;R2 DESIGNATES FIRST BYTE
5049 031524 062703 000003 ADD #3,R3 ;R3 DESIGNATES LAST BYTE
5050 031530 112722 000360 8$: MOV #360,(R2)+ ;TRY WRITING A BYTE
5051 031534 013701 002506 MOV TESTADD,R1
5052 031540 012100 MOV (R1)+,R0
5053 031542 023700 002344 CMP TSTDAT,R0 ;CHECK FOR UNCHANGED DATA
5054 031546 001401 BEQ 9$ ;BR IF OK
5055 031550 104455 PERR31
5056
5057 031552 011100 9$: MOV (R1),R0
5058 031554 023700 002346 CMP TSTDAT+2,R0 ;READ SECOND WORD
5059 031560 001401 BEQ 10$ ;BR IF UNCHANGED
5060 031562 104455 PERR31
5061
5062 031564 020203 10$: CMP R2,R3 ;TESTED LAST BYTE
5063 031566 001360 BNE 8$ ;BR IF NO

```

```

5064 031570 005737 002356      11$:  TST    DBEMSK+2      .CHECKING FOR LAST ERROR BIT
5065 031574 100405              BMI    12$           ;BR IF DONE HERE
5066 031576              DLEFT  DBEMSK
5067 031606 000657              BR     4$
5068 031610              12$:  IF #SW11 SET.IN @SWR THEN GOTO 13$
5069 031620              IF QVFLAG IS TRUE THEN GOTO 13$
5070 031626 005737 002352      TST    SBEMSK+2      ;LAST SBE MASK
5071 031632 100405              BMI    13$           ;BR IF DONE WITH THIS PASS
5072 031634              DLEFT  SBEMSK
5073 031644 000633              BR     3$
5074 031646 105737 002362      13$:  TSTB   PASFLG ;TEST PASS FLAG
5075 031652 001003              BNE    14$           ;NON ZERO MEANS WE'RE DONE
5076 031654 105237 002362      INCB   PASFLG ;NOT DONR
5077 031660 000614              BR     1$
5078 031662 104471              14$:  ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
5079 031664 013701 002506      MOV    TESTADD,R1   ;TEST LOCATION
5080 031670              (CLEAR (R1)+,(R1) ;TO ERASE ANY DBE'S FROM TESTING
5081              ;RESTORE CSR
5082 031674 104503              CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
5083 031676 000207              RETURN
  
```

5087 031700

MTP016: SUBST <<MTP016 WRITE INHIBIT OF WORD WITH DBE>>

: *SUBTEST MTP016 WRITE INHIBIT OF WORD WITH DBE

5088

:DOUBLE BIT ERROR WRITE CANCEL WITH

5089

:WORD WRITE.

5090

:CHECKS WRITE INHIBIT WITH WORD WRITES TO

5091

:WORD WITH DOUBLE ERROR.

5092 031700 005037 002340

T12A: CLR DATBUF ;BACKGROUND FOR DOUBLE ERRORS

5093 031704 005037 002342

CLR DATBUF+2 ;2 WORDS WORTH

5094 031710 012737 000001 002350

MOV #1,SBEMSK ;SINGLE ERROR MASK

5095 031716 005037 002352

CLR SBEMSK+2 ;

5096 031722 012737 000001 002354

T12B: MOV #1,DBEMSK ;DOUBLE ERROR MASK

5097 031730 005037 002356

CLR DBEMSK+2 ;

5098 031734 013737 002340 002344

1\$: MOV DATBUF,TSTDAT ;DATA FOR TEST

5099 031742 013737 002342 002346

MOV DATBUF+2,TSTDAT+2 ;BOTH WORDS

5100 031750 105737 002362

TSTB PASFLG ;COMP DATA ON SECOND PASS ONLY

5101 031754 001404

BEQ 2\$;BR IF FIRST PASS

5102 031756 005137 002344

COM TSTDAT ;COMP FIRST WORD

5103 031762 005137 002346

COM TSTDAT+2 ;NOW SECOND WORD

5104 031766 023737 002350 002354

2\$: CMP SBEMSK,DBEMSK ;CHECK FOR IDENTICAL MASKS

5105 031774 001004

BNE 3\$;BR IF DIFFERENT

5106 031776 023737 002352 002356

CMP SBEMSK+2,DBEMSK+2 ;UPPER WORD TOO

5107 032004 001470

BEQ 8\$;BR TO MAKE THEM NOT EQUAL

5108 032006 012737 002344 002402

3\$: MOV #TSTDAT,SOURCE ;NEED ADDR OF DATA FOR CHKGEN

5109 032014 004737 040540

CALL CHKGEN ;GO GENERATE CHECK BITS

5110 032020 013701 002350

MOV SBEMSK,R1

5111 032024 074137 002344

XOR R1,TSTDAT

5112 032030 013701 002352

MOV SBEMSK+2,R1

5113 032034 074137 002346

XOR R1,TSTDAT+2

5114 032040 013701 002354

MOV DBEMSK,R1

5115 032044 074137 002344

XOR R1,TSTDAT

5116 032050 013701 002356

MOV DBEMSK+2,R1

5117 032054 074137 002346

XOR R1,TSTDAT+2

5118 032060 013701 002506

4\$: MOV TESTADD,R1 ;FIRST TEST ADDRESS

5119 032064 104471

ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR

5120 032066 013721 002344

MOV TSTDAT,(R1)+ ;WRITE FIRST 16 BITS

5121 032072 104475

CB1CSR ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR

5122 032074 013711 002346

MOV TSTDAT+2,(R1) ;WRITE SECOND 16 BITS + CHECKBITS

5123 032100 105037 002363

CLRB UPPFLG ;SET FOR 2 LOOPS

5124 032104 162701 000002

SUB #2,R1 ;POINT TO LOW WORD

5125 032110 104503

5\$: CLR1CSR ;CLEAR 1 SELECTED MK11 CSR

5126 032112 012711 177400

MOV #177400,(R1) ;TRY WRITING LOCATION

5127 032116 013701 002506

MOV TESTADD,R1

5128 032122 011100

MOV (R1),R0

5129 032124 023700 002344

CMP TSTDAT,R0 ;CHECK FOR ORIGINAL DATA

5130 032130 001401

BEQ 6\$;SHOULD BE UNCHANGED

5131 032132 104455

PERR31

5132

5133 032134 062701 000002

6\$: ADD #2,R1

5134 032140 011100

MOV (R1),R0

5135 032142 023700 002346

CMP TSTDAT+2,R0 ;THIS SHOULD BE UNCHANGED ALSO

5136 032146 001401

BEQ 7\$

5137 032150 104455

PERR31

```

5140 032152 105737 002363      7$:  TSTB  UPPFLG      ;WHICH LOOP ?
5141 032156 001003              BNE   8$           ;SECOND, BR OUT
5142 032160 105237 002363      INCB  UPPFLG      ;FIRST, KEEP GOING
5143 032164 000751              BR    5$
5144 032166 005737 002356      8$:  TST   DBEMSK+2  ;LAST BIT ?
5145 032172 100405              BMI   9$           ;MINUS - BIT 31
5146 032174              DLEFT DBEMSK
5147 032204 000653              BR    1$
5148 032206              9$:  IF #SW11 SET.IN @SWR THEN GOTO 10$
5149 032216              IF QVFLAG IS TRUE THEN GOTO 10$
5150 032224 005737 002352      TST   SBEMSK+2    ;LAST BIT IN THIS MASK ?
5151 032230 100406              BMI   10$         ;BR IF LAST BIT
5152 032232              DLEFT SBEMSK
5153 032242 000137 031722      JMP   T12B
5154 032246 105737 002362      10$: TSTB  PASFLG     ;FIRST PASS ?
5155 032252 001004              BNE   11$         ;BR IF SECOND
5156 032254 105237 002362      INCB  PASFLG     ;INDICATE SECOND PASS COMING
5157 032260 000137 031700      JMP   T12A
5158 032264 104471              11$: ECC1DIS      ;DISABLE ECC ON 1 SELECTED CSR
5159 032266 013701 002506      MOV   TESTADD,R1 ;RESTORE TEST ADDRESS
5160 032272 005021              CLR   (R1)+      ;CLEAR ANY DBE'S FROM TEST
5161 032274 005011              CLR   (R1)
5162 032276 104503              CLR1CSR          ;CLEAR 1 SELECTED MK11 CSR
5163 032300 000207              RETURN

```

5167 032302

MTP017: SUBTST <<MTP017 HOLDING 1'S & 0'S TEST>>

:*SUBTEST MTP017 HOLDING 1'S & 0'S TEST

```

5168      :*(1) THIS TEST CHECKS THE MEMORY FOR THE CAPABILITY
5169      :*   OF HOLDING 1'S AND 0'S BY WRITING A BACKGROUND
5170      :*   OF 000377 AND READING IT
5171      :*(2) MEMORY IS WRITTEN USING A BYTE AT A TIME
5172      :*(3) STEPS 1 & 2 ARE REPEATED WITH A SWAPPED BACKGROUND PATTERN
5173      ;NOTE: THIS TEST WRITES BYTES & READS WORDS
5174 032302 012701 060000  MOV    #FIRST,R1
5175 032306 010104        MOV    R1,R4
5176 032310 012705 160000  MOV    #LAST+2,R5
5177 032314 012700 000377  MOV    #377,R0      ;GET THE PATTERN INTO R0
5178 032320 010003        MOV    R0,R3
5179 032322 000303        SWAB   R3
5180 032324 110021 1$:   MOVB   R0,(R1)+      ;WRITE A BYTE
5181 032326 110321        MOVB   R3,(R1)+      ;WRITE THE MEMORY WITH THE BYTE STORED IN BAKPAT+1
5182 032330 020105        CMP    R1,R5        ;COMPARE TEST LOC TO TOP + 2
5183 032332 103774        BLO   1$           ;BRANCH IF LOWER
5184
5185 032334 014102 2$:   MOV    -(R1),R2
5186 032336 020002        CMP    R0,R2        ;TEST THE MEMORY TO SEE IF IT CONTAINS
5187                                ;THE WORD STORED IN BAKPAT
5188 032340 001401        BEQ   3$
5189 032342 104446        PERR2
5190
5191 032344 020104 3$:   CMP    R1,R4        ;KEEP ON TESTING THE MEMORY UNTIL
5192 032346 101372        BHI   2$           ;R1 EQUALS THE LOWEST ADDRESS
5193 032350 000303        SWAB   R3          ;CHANGE THE DATA PATTERN
5194 032352 000300        SWAB   R0
5195 032354 001763        BEQ   1$           ;IF THE DATA PATTERN DOES NOT HAVE LOW
5196                                ; BYTE =0 THEN FALL THRU
5197 032356 000207        RETURN

```

5201 032360

```
MTP020: SUBTST <<MTP020      MARCHING 1'S & 0'S IN CHECK BITS TEST>>
:*****
:*SUBTEST      MTP020      MARCHING 1'S & 0'S IN CHECK BITS TEST
:*****
:*THIS TEST IS CONCERNED ONLY WITH THE INTEGRITY
:*OF THE MOS RAMS THAT STORE THE CHECKBITS.
```

```
5202
5203
5204
5205
5206 032360 010311
5207 032362 010461 000002
5208 032366 060201
5209 032370 020105
5210 032372 103772
5211 032374 000207
5212
5213
5214 032376 160201
5215 032400 020461 000002
5216 032404 001002
5217 032406 005711
5218 032410 001401
5219 032412 104452
5220 032414 010361 000002
5221 032420 010311
5222 032422 020100
5223 032424 001364
5224 032426 000207
5225
5226
5227 032430 005711
5228 032432 001003
5229 032434 005761 000002
5230 032440 001401
5231 032442 104453
5232 032444 010311
5233 032446 010461 000002
5234 032452 060201
5235 032454 020105
5236 032456 103764
5237 032460 000207
5238
5239
5240 032462 005711
5241 032464 001003
5242 032466 020461 000002
5243 032472 001401
5244 032474 104452
5245 032476 010311
5246 032500 010361 000002
5247 032504 060201
5248 032506 020105
5249 032510 103764
5250 032512 000207
```

```

:WRITE UP      ;100 --> CHECKBITS
MTP20A: MOV     R3,(R1)      ;V177640
        MOV     R4,2(R1)    ;V177642
        ADD     R2,R1       ;V177646
        CMP     R1,R5       ;V177650      ;TOP + 2 ?
        BLO    MTP20A      ;V177652      ;BR IF NOT
        RETURN            ;V177654

:100 --> 077 DOWN
MTP20B: SUB     R2,R1       ;V177640
        CMP     R4,2(R1)    ;V177642      ;2ND WORD OK?
        BNE    21$         ;V177646      ;NO - SKIP
        TST    (R1)        ;V177650      ;1ST WORD OK?
        BEQ    3$          ;V177652      ;YES - SKIP
        PERR26            ;V177654      ;GOOD=000000,,100000,,100
21$:   MOV     R3,2(R1)     ;V177656
3$:   MOV     R3,(R1)      ;V177662
        MOV     R3,(R1)     ;V177662
        CMP     R1,R0       ;V177664
        BNE    MTP20B      ;V177666
        RETURN            ;V177670

:077 --> 100 UP
MTP20C: TST     (R1)        ;V177640      ;1ST WORD OK?
        BNE    41$         ;V177642      ;NO - SKIP
        TST    2(R1)       ;V177644      ;2ND WORD OK?
        BEQ    5$          ;V177650      ;YES - SKIP
        PERR27            ;V177652      ;GOOD=000000,,000000,,077
41$:   MOV     R3,(R1)     ;V177654      ;WRITE 1ST WORD
5$:   MOV     R4,2(R1)     ;V177656      ;WRITE 2ND WORD
        ADD     R2,R1       ;V177662
        CMP     R1,R5       ;V177664
        BLO    MTP20C      ;V177666      ;TOP + 2 YET?
        RETURN            ;V177670      ;NO - LOOP

:100 --> 077 UP
MTP20D: TST     (R1)        ;V177640      ;1ST WORD OK?
        BNE    61$         ;V177642      ;NO - SKIP
        CMP     R4,2(R1)    ;V177644      ;2ND WORD OK?
        BEQ    7$          ;V177650      ;YES - SKIP
        PERR26            ;V177652
61$:   MOV     R3,(R1)     ;V177654
7$:   MOV     R3,2(R1)     ;V177656
        MOV     R3,(R1)     ;V177656
        ADD     R2,R1       ;V177662
        CMP     R1,R5       ;V177664
        BLO    MTP20D      ;V177666      ;TOP + 2 YET?
        RETURN            ;V177670      ;NO - LOOP
```

5253					:077 --> 100 DOWN		
5254	032514	160201		MTP20E:	SUB R2,R1	:V177640	
5255	032516	005761	000002		TST 2(R1)	:V177642	
5256	032522	001002			BNE 81\$:V177646	2ND WORD OK?
5257	032524	005711			TST (R1)	:V177650	NO - SKIP
5258	032526	001401			BEQ 9\$:V177652	1ST WORD OK?
5259	032530	104453		81\$:	PERR27	:V177654	YES - SKIP
5260	032532	010461	000002	9\$:	MOV R4,2(R1)	:V177656	WRITE 2ND WORD
5261	032536	010311			MOV R3,(R1)	:V177662	WRITE 1ST WORD
5262	032540	020100			CMP R1,R0	:V177664	BOTTOM YET?
5263	032542	001364			BNE MTP20E	:V177666	NO - LOOP
5264	032544	000207			RETURN	:V177670	
5265							
5266					:100 UP		
5267	032546	005711		MTP20F:	TST (R1)	:V177640	1ST WORD OK?
5268	032550	001003			BNE 101\$:V177642	NO - SKIP
5269	032552	020461	000002		CMP R4,2(R1)	:V177642	2ND WORD OK?
5270	032556	001401			BEQ 11\$:V177646	YES - SKIP
5271	032560	104452		101\$:	PERR26	:V177650	
5272	032562	060201		11\$:	ADD R2,R1	:V177652	
5273	032564	020105			CMP R1,R5	:V177654	TOP + 2 YET?
5274	032566	103767			BLO MTP20F	:V177656	NO - LOOP
5275	032570	000207			RETURN	:V177660	

5279 032572

MTPA20: SUBST <<MTPA20 SLOW MARCHING 1'S & 0'S IN CHECK BITS TEST>>

: *SUBTEST MTPA20 SLOW MARCHING 1'S & 0'S IN CHECK BITS TEST
: *****

5280
5281
5282 032572
5283 032600 013737 002144 002150
5284 032606 013737 002146 002152
5285 032614 013701 002336
5286 032620 013702 002414
5287 032624 010103
5288 032626 005004
5289 032630 012705 160000
5290 032634 005037 002144
5291 032640 104505

: *THIS TEST IS CONCERNED ONLY WITH THE INTEGRITY
: *OF THE MOS RAMS THAT STORE THE CHECKBITS.
SET SBFLAG
MOV CSR,SBECR
MOV CSR+2,SBECR+2
MOV CSRFIRST,R1 ;FIRST TEST LOC
MOV CSRINC,R2
MOV R1,R3
CLR R4
MOV #LAST+2,R5
CLR CSR
CHK1DIS ;DISABLE ECC & WRITE CHECKBITS FROM 1 SELECTED CSR

5292
5293
5294 032642 010411
5295 032644 060201
5296 032646 020105
5297 032650 103774
5298
5299

2\$: MOV R4,(R1) ;WRITE CHECKBITS BY WRITING LOC * WRITE UP
ADD R2,R1 ;POINT TO NEXT WORD * 0'S --> CHK BITS
CMP R1,R5 ;TOP + 2 *
BLO 2\$;BR IF NOT *

5300
5301 032652 160201
5302 032654 005711
5303 032656 104426
5304 032660 032737 077400 002144
5305 032666 001406
5306 032670 013700 002144
5307 032674 000300
5308 032676 042700 000200
5309 032702 104435

3\$: SUB R2,R1 ;ADJUST R1 *
TST (R1) ;READ *
READCSR ; *
BIT #77400,@CSR ;SHOULD BE ALL ZEROS *
BEQ 4\$;BR IF OK *
MOV CSR,R0 ; *
SWAB R0 ; *
BIC #200,R0 ; *
PERR11 ; *

5310
5311 032704 012737 077400 002144 4\$:
5312 032712 104505
5313 032714 005104
5314 032716 010411
5315 032720 020103
5316 032722 001353
5317
5318

MOV #77400,@CSR ;MAKE CHECKBITS ALL 1'S *0'S --> 1'S
CHK1DIS ;DSABL ECC & WRITE CHKBITS FROM 1 CSR * DOWN
COM R4 ;COMP THE DATA *
MOV R4,(R1) ;WRITE THE CHECKBITS *
CMP R1,R3 ;BOTTOM YET? *
BNE 3\$;BR IF NO *

5319 032724 005037 002144
5320 032730 104505

CLR CSR
CHK1DIS ;DISABLE ECC & WRITE CHECKBITS FROM 1 SELECTED CSR


```

5323          :*****
5324 032732 005711          5$:  TST      (R1)          ;READ THE LOC AGAIN
5325 032734 104426          READCSR
5326 032736 013700 002144  MOV     @#CSR,R0      ;GET CSR CONTENTS INTO R0
5327 032742 042700 100377  BIC     #100377,R0    ;ONLY WANT BITS 11-5
5328 032746 022700 077400  CMP     #77400,R0     ;READ FOR ALL 1'S
5329 032752 001404          BEQ     6$            ;BR IF OK
5330 032754 000300          SWAB    R0
5331 032756 042700 000200  BIC     #200,R0
5332 032762 104445          PERR21
5333          :*****
5334 032764 005037 002144  6$:  CLR     CSR
5335 032770 104505          CHK1DIS ;DSABL ECC & WRITE CHKBITS FROM 1 CSR
5336 032772 005104          COM     R4
5337 032774 010411          MOV     R4,(R1)      ;ACCESS THE LOC
5338 032776 060201          ADD     R2,R1        ;POINT TO NEXT ADDRESS
5339 033000 020105          CMP     R1,R5        ;TOP+2 YET?
5340 033002 103753          BLO     5$            ;BR IF NOT
5341          :*****
5342          MOV     R3,R1
5343 033004 010301
5344
5345          :*****
5346 033006 005711          7$:  TST      (R1)          ;READ
5347 033010 104426          READCSR
5348 033012 032737 077400 002144  BIT     #77400,@#CSR ;CHECKBITS SHOULD BE ZERO
5349 033020 001404          BEQ     8$            ;BR IF OK
5350 033022 013700 002144  MOV     CSR,R0
5351 033026 000300          SWAB    R0
5352 033030 042700 000200  BIC     #200,R0
5353 033034 104435          PERR11
5354          :*****
5355 033036 012737 077400 002144  8$:  MOV     #77400,@#CSR ;COMP CHECKBITS
5356 033044 104505          CHK1DIS ;DSABL ECC & WRITE CHKBITS FROM 1 CSR
5357 033046 005104          COM     R4
5358 033050 010411          MOV     R4,(R1)      ;WRITE THE LOC
5359 033052 060201          ADD     R2,R1        ;POINT TO NEXT ADDRESS
5360 033054 020105          CMP     R1,R5        ;TOP+2 YET?
5361 033056 103753          BLO     7$            ;BR IF NOT
5362          :*****
5363
5364 033060 005037 002144  CLR     CSR
5365 033064 104505          CHK1DIS ;DISABLE ECC & WRITE CHECKBITS FROM 1 SELECTED CSR

```

*1'S --> 0'S
* UP

*0'S --> 1'S
* UP

```

5368
5369 033066 160201          09$: SUB R2,R1          :ADJUST R1
5370 033070 005711          TST (R1)          :READ
5371 033072 104426          READCSR
5372 033074 013700 002144  MOV @#CSR,R0      :GET CSR CONTENTS
5373 033100 042700 100377  BIC #100377,R0    :ONLY WANT CHECKBITS
5374 033104 022700 077400  CMP #77400,R0     :ALL 1'S?
5375 033110 001404          BEQ 10$           :BR IF OK
5376 033112 000300          SWAB R0
5377 033114 042700 000200  BIC #200,R0
5378 033120 104445          PERR21
5379
5380 033122 005037 002144  10$: CLR CSR
5381 033126 104505          CHK1DIS          :DSABL ECC & WRITE CHKBTS FROM 1 CSR
5382 033130 005104          COM R4           :COMP THE DATA
5383 033132 010411          MOV R4,(R1)      :WRITE THE CHECKBITS
5384 033134 020103          CMP R1,R3        :BOTTOM YET?
5385 033136 001353          BNE 9$           :BR IF NO
5386
5387
5388
5389 033140 005711          11$: TST (R1)          :READ
5390 033142 104426          READCSR
5391 033144 032737 077400 002144  BIT #77400,@#CSR  :SHOULD BE ALL 0'S
5392 033152 001406          BEQ 12$           :BR IF OK
5393 033154 013700 002144  MOV CSR,R0
5394 033160 000300          SWAB R0
5395 033162 042700 000200  BIC #200,R0
5396 033166 104435          PERR11
5397
5398 033170 060201          12$: ADD R2,R1          :POINT TO NEXT WORD
5399 033172 005037 002144  CLR CSR
5400 033176 104505          CHK1DIS          :DSABL ECC & WRITE CHKBTS FROM 1 CSR
5401 033200 020105          CMP R1,R5        :TOP + 2 YET?
5402 033202 103756          BLO 11$          :BR IF NOT
5403
5404
5405
5406 033204          :FLUSH OUT ALL THESE DBE'S
5407 033212 012700 060000  BMOV MTP030
5408 033216 012701 040000  MOV #FIRST,R0
5409 033222 104471          MOV #SIZE,R1
5410 033224 004737 177640  ECC1DIS          :DISABLE ECC ON 1 SELECTED CSR
5411 033230 104503          CALL FASTCITY    :CALL TO THE USER INSTRUCTION PAR'S
5412 033232 000207          CLR1CSR         :CLEAR 1 SELECTED M#11 CSR
                    RETURN

```

*1'S --> 0'S
*DOWN

*0'S
*UP

5416 033234

MTPA21: SUBST <<MTPA21 MARCHING 1'S & 0'S PATTERN TEST>>
:*****
:SUBTEST MTPA21 MARCHING 1'S & 0'S PATTERN TEST
:*****

5417
5418 033234 014100
5419 033236 020200
5420 033240 001401
5421 033242 104443
5422

:READ,BYTESWAP-MODIFY,READ,DOWN
1\$: MOV -(R1),R0 :V177640
CMP R2,R0 :V177642
BEQ 2\$:V177644
PERR17 :V177646

5423 033244 000311
5424 033246 011100
5425 033250 020300
5426 033252 001401
5427 033254 104444
5428

2\$: SWAB (R1) :V177650
MOV (R1),R0 :V177652
CMP R3,R0 :V177654
BEQ 3\$:V177656
PERR20 :V177660

5429 033256 020401
5430 033260 001365
5431 033262 000207
5432

3\$: CMP R4,R1 :V177662 :DONE?
BNE 1\$:V177664 :NO - LOOP
RETURN :V177666 :YES - RETURN

5433 033264
5434 033266 011100
5435 033266 020300
5436 033270 001401
5437 033272 104444
5438

MTPB21: :READ,BYTESWAP-MODIFY,READ,UP
1\$: MOV (R1),R0 :V177640
CMP R3,R0 :V177642
BEQ 2\$:V177644
PERR20 :V177646

5439 033274 000311
5440 033276 011100
5441 033300 020200
5442 033302 001401
5443 033304 104443
5444

2\$: SWAB (R1) :V177650
MOV (R1),R0 :V177652
CMP R2,R0 :V177654
BEQ 3\$:V177656
PERR17 :V177660

5445 033306 062701 000002
5446 033312 020501
5447 033314 001363
5448 033316 000207
5449

3\$: ADD #2,R1 :V177662
CMP R5,R1 :V177666 :DONE?
BNE 1\$:V177670 :NO - LOOP
RETURN :V177672 :YES - RETURN

5450 033320
5451 033320 011100
5452 033322 020200
5453 033324 001401
5454 033326 104443
5455

MTPC21: :READ,BYTESWAP-MODIFY,READ,UP
1\$: MOV (R1),R0 :V177640
CMP R2,R0 :V177642
BEQ 2\$:V177644
PERR17 :V177646

5456 033330 000311
5457 033332 011100
5458 033334 020300
5459 033336 001401
5460 033340 104444
5461

2\$: SWAB (R1) :V177650
MOV (R1),R0 :V177652
CMP R3,R0 :V177654
BEQ 3\$:V177656
PERR20 :V177660

5462 033342 062701 000002
5463 033346 020501
5464 033350 001363
5465 033352 000207

3\$: ADD #2,R1 :V177662
CMP R5,R1 :V177666 :DONE?
BNE 1\$:V177670 :NO - LOOP
RETURN :V177672 :YES - RETURN

5468 033354
 5469 033354 014100
 5470 033356 020300
 5471 033360 001401
 5472 033362 104444
 5473
 5474 033364 000311
 5475 033366 011100
 5476 033370 020200
 5477 033372 001401
 5478 033374 104443
 5479
 5480 033376 020401
 5481 033400 001365
 5482 033402 000207
 5483

MTPD21: ;READ,BYTESWAP-MODIFY,READ,DOWN

1\$: MOV -(R1),R0 ;V177640
 CMP R3,R0 ;V177642
 BEQ 2\$;V177644
 PERR20 ;V177646

2\$: SWAB (R1) ;V177650
 MOV (R1),R0 ;V177652
 CMP R2,R0 ;V177654
 BEQ 3\$;V177656
 PERR17 ;V177660

3\$: CMP R4,R1 ;V177662 ;DONE?
 BNE 1\$;V177664 ;NO - LOOP
 RETURN ;V177666 ;YES - RETURN

5487 033404

```

MTP022: SUBST <<MTP022 REFRESH & SHIFTING DIAGONAL TEST>>
:*****
:*SUBTEST MTP022 REFRESH & SHIFTING DIAGONAL TEST
:*****
:(1) WE WRITE A DIAGONAL PATTERN IN MEMORY (WITH CACHE ON).
:(2) IF A REFRESH TEST WE DISTURB ALL ROWS FOR > 2 MS (WITH CACHE ON).
:(3) WE READ & CHECK FOR CORRECTNESS THE DIAGONAL PATTERN
: (WITH CACHE OFF).
KDIAG=8. ;HOW OFTEN A DIAGONAL STRIPE OCCURS (MUST BE A POWER OF 2)
FOR EVEN := #1 TO #2 ;FOR DATA & COMPLEMENT DATA
IF EVEN EQ #1
LET R2 := ZEROS
LET R3 := ONES
ELSE
LET R2 := ONES
LET R3 := ZEROS
END ;OF IF EVEN
FOR STRIPES := #0 TO #KDIAG-1 ;FOR THE NUMBER OF STRIPES
;WRITE LOOP
CACHON ;TURN CACHE ON
LET COUNT := STRIPES
LET R1 := #FIRST
WHILE R1 LOS #LAST
IF COUNT LT #0 THEN LET COUNT := #KDIAG-1
IF #374 OFF IN R1 THEN LET COUNT := COUNT - #1
IF COUNT NE #0
LET (R1) := R2
LET 2(R1) := R2
ELSE
LET (R1) := R3
LET 2(R1) := R3
END ;OF IF COUNT
LET COUNT := COUNT - #1
LET R1 := R1 + #4
END ;OF WHILE
;END OF WRITE LOOP
IF DIAGFLAG IS FALSE THEN SCALL REFRESH
  
```

5488
 5489
 5490
 5491
 5492 000010
 5493 033404
 5494 033412
 5495 033422
 5496 033426
 5497 033432
 5498 033434
 5499 033440
 5500 033444
 5501 033444
 5502
 5503
 5504 033450 104423
 5505 033452
 5506 033460
 5507 033464
 5508 033472
 5509 033506
 5510 033520
 5511 033526
 5512 033530
 5513 03353
 5514 033536
 5515 033540
 5516 033544
 5517 033544
 5518 033550
 5519 033554
 5520
 5521
 5522 033556

```

5525                                     :READ LOOP
5526 033570                             LET COUNT := STRIPES
5527 033576                             LET R1 := #FIRST
5528 033602 104424                       CACHOFF                               :TURN CACHE OFF
5529 033604                             WHILE R1 LOS #LAST
5530 033612                             IF COUNT LT #0 THEN LET COUNT := #KDIAG-1
5531 033626                             IF #374 OFF.IN R1 THEN LET COUNT := COUNT - #1
5532 033640                             IF COUNT NE #0
5533 033646                             LET RO := (R1)
5534 033650                             IF R2 NE RO
5535 033654 104443                       PERR17
5536 033656                             END :OF IF R2
5537 033656                             LET RO := 2(R1)
5538 033662                             IF R2 NE RO
5539 033666 104443                       PERR17
5540 033670                             END :OF IF R2
5541 033670                             ELSE
5542 033672                             LET RO := (R1)
5543 033674                             IF R3 NE RO
5544 033700 104444                       PERR20
5545 033702                             END :OF IF R3
5546 033702                             LET RO := 2(R1)
5547 033706                             IF R3 NE RO
5548 033712 104444                       PERR20
5549 033714                             END :OF IF R3
5550 033714                             END :OF IF COUNT
5551 033714                             LET COUNT := COUNT - #1
5552 033720                             LET R1 := R1 + #4
5553 033724                             END :OF WHILE
5554                                     :END OF READ LOOP
5555
5556 033726                             END :OF FOR STRIPES
5557 033742                             END :OF FOR EVEN
5558 033756 000207                       RETURN
5559 033760
REFRESH:SUBST <<SUBR REFRESH DELAY>>
:*****
:*SUBTEST SUBR REFRESH DELAY
:*****
5560                                     :DISTURB EACH ROW FOR > 3.2 MS
5561 033760 004737 034030               FOR RO := #FIRST TO #FIRST+374 BY #4
5562 033764                             CALL REFSUB
5563 033770                             END :OF FOR RO
5564 034002                             LET RO := #FIRST+BIT14
5565 034006                             WHILE RO LOS #LAST+BIT14+374
5566 034014 004737 034030               CALL REFSUB
5567 034020                             LET RO := RO + #4
5568 034024                             END :OF WHILE
5569 034026 000207                       RETURN
5570 034030 012704 000640               REFSUB: MOV #640,R4                               :TIME FOR A 3.2 MS LOOP
5571 034034 062700 000002               ADD #2,R0
5572 034040 005140                       1$: COM -(R0)
5573 034042 005120                       COM (R0)+
5574 034044 005110                       COM (R0)
5575 034046 005110                       COM (R0)
5576 034050 077405                       SOB R4,1$
5577 034052 162700 000002               SUB #2,R0
5578 034056 000207                       RETURN

```

5582 034060

MTPA24: SUBTST <<MTPA24 FAST GALLOPING PATTERN TEST>>

.....
:SUBTEST MTPA24 FAST GALLOPING PATTERN TEST
.....

```

5583 :THE TOTAL TEST (INCLUDING SETUP) IS AS FOLLOWS
5584 :*(1) THIS TEST WRITES THE MEMORY WITH A BACK GROUND PATTERN
5585 :* STORED AT LOCATION BAKPAT
5586 :*(2) TEST BEGINS AT LOWEST LOCATION BEING TESTED
5587 :* (LETS NAME IT 'A')
5588 :*(3) LETS NAME THE 1ST LOCATION IN THE ROW/COLUMN UNDER TEST AS 'B'.
5589 :*(4) SWAPS BYTES FOR LOCATION 'A'.
5590 :*(5) READS 'A', READS 'B'
5591 :*(6) 'B' = 'B'+400 (ADDS 64 DOUBLE WORDS TO 'B')
5592 :*(7) REPEATS STEPS 5 AND 6 UNTIL 'B' IS GREATER THAN THE
5593 :*(8) END OF THE BANK A+2
5594 :*(9) REPEATS STEPS 3-8 UNTILL 'A' REACHES THE END OF THE BANK
5595 :*(10) AFTER EXECUTING THE TEST DATA IS COMPLEMENTED
5596 :* AND STEPS 1-9 ARE REPEATED
5597 :REGISTERS ARE USED AS FOLLOWS
5598 :R0 TEST DATA
5599 :R1 'A'
5600 :R2 'B'
5601 :R3 BAKPAT
5602 :R4 SWAPAT
5603 :R5 LAST

```

:NOTE THE PATTERN STARTS AT MTPB24!!!!!!!!!!!!!!!!!!!!

```

5607 :UIPAR'S
5608 034060 011100 1$: MOV (R1),R0 :V177640 :READ 'A'
5609 034062 020004 CMP R0,R4 :V177642 :CHECK 'A'
5610 034064 001401 BEQ 2$ :V177644 :BR IF OK
5611 034066 104447 PERR23 :V177646 :REPORT ERROR
5612
5613 034070 011200 2$: MOV (R2),R0 :V177650 :READ 'B'
5614 034072 020003 CMP R0,R3 :V177652 :CHECK 'B'
5615 034074 001401 BEQ 3$ :V177654 :BR IF OK
5616 034076 104450 PERR24 :V177656 :REPORT ERROR
5617
5618 034100 062702 000400 3$: ADD #400,R2 :V177660 :BUMP 'B'
5619 034104 020205 CMP R2,R5 :V177664 :AT END YET?
5620 034106 101764 BLOS 1$ :V177666 :BR IF NO
5621
5622 034110 062701 000002 ADD #2,R1 :V177670 :BUMP 'A'
5623 034114 000137 172260 JMP @WSDPAR0 :V177674 :GOTO V177260

```

5626 034120

MTPB24: SUBTST <<MTPB24 FAST GALLOP PART B>>

: *SUBTEST MTPB24 FAST GALLOP PART B

5627
5628 034120 010411
5629 034122 020105
5630 034124 001001
5631 034126 000207
5632 034130 000137 172360
5633
5634 034134

```

;SDPAR'S
MOV R4,(R1) ;V172260 ;WRITE 'A'
CMP R1,R5 ;V172262 ;DONE?
BNE 1$ ;V172264 ;BR IF NO
RETURN ;V172266 ;YES - RETURN
1$: JMP @#KDPARO ;V172270 ;GOTO V172360

```

MTPC24: SUBTST <<MTPC24 FAST GALLOP PART C>>

: *SUBTEST MTPC24 FAST GALLOP PART C

5635
5636 034134 010102
5637 034136 011100
5638 034140 020004
5639 034142 001401
5640 034144 104447
5641 034146 000137 177660

```

;KDPAR'S
MOV R1,R2 ;V172360 ;RESET 'B' <--- 'A'
MOV (R1),R0 ;V172362 ;READ 'A'
CMP R0,R4 ;V172364 ;CHECK 'A'
BEQ 1$ ;V172366 ;BR IF OK
PERR23 ;V172370 ;REPORT ERROR
1$: JMP @#UDPARO ;V172372 ;GOTO V177660

```


5645 034152

```

MTP025: SUBST <<MTP025      INTERRUPT ENABLE TEST>>
:*****
:*SUBTEST      MTP025      INTERRUPT ENABLE TEST
:*****
5646 034152 005037 002344      CLR      TSTDAT      ;GENERATE CHECKBITS ON 0,,0
5647 034156 005037 002346      CLR      TSTDAT+2
5648 034162 012737 002344 002402      MOV      #TSTDAT,SOURCE
5649 034170 004737 040540      CALL     CHKGEN
5650 034174 012737 000003 002100      MOV      #3,NOPAR      ;SETUP PARITY ACTION
5651 034202 013701 002506      MOV      TESTADD,R1      ;FIRST TEST ADDRESS
5652 034206 012737 034242 002372      MOV      #1$,PARTHERE      ;SETUP TRAP DESTINATION
5653 034214 004737 034464      CALL     MTPA25      ;WRITE DATA & CHECKBITS
5654 034220 104473      ECC1INIT      ;INITIALIZE 1 SELECTED MK11 CSR
5655 034222 005711      TST      (R1)      ;ACCESS LOCATIONS FOR DBE TRAPS
5656 034224 005761 000002      TST      2(R1)
5657      ;NONE - GOOD - ACCESS FOR SBE TRAPS
5658 034230 104507      ENA1SBE      ;DISABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
5659 034232 005711      TST      (R1)
5660 034234 005761 000002      TST      2(R1)
5661 034240 000404      BR       2$      ;NONE - GOOD - SKIP
5662 034242 104426 1$: READCSR
5663 034244      FATAL      27
5664 034252 005237 002344 2$: INC      TSTDAT      ;CHECK FOR CORRECT ACTION ON SBE'S
5665 034256 004737 034412      CALL     MTPD25      ;IN ALL 4 BYTES
5666 034262 012737 000400 002344      MOV      #400,TSTDAT
5667 034270 004737 034412      CALL     MTPD25
5668 034274 005037 002344      CLR      TSTDAT
5669 034300 005237 002346      INC      TSTDAT+2
5670 034304 004737 034412      CALL     MTPD25
5671 034310 012737 000400 002346      MOV      #400,TSTDAT+2
5672 034316 004737 034412      CALL     MTPD25
5673
5674 034322 005037 002346      CLR      TSTDAT+2      ;CHECK FOR CORRECT ACTION ON DBE'S
5675 034326 012737 000003 002344      MOV      #3,TSTDAT      ;IN ALL 4 BYTES
5676 034334 004737 034434      CALL     MTPE25
5677 034340 012737 001400 002344      MOV      #1400,TSTDAT
5678 034346 004737 034434      CALL     MTPE25
5679 034352 005037 002344      CLR      TSTDAT
5680 034356 012737 000003 002346      MOV      #3,TSTDAT+2
5681 034364 004737 034434      CALL     MTPE25
5682 034370 012737 001400 002346      MOV      #1400,TSTDAT+2
5683 034376 004737 034434      CALL     MTPE25
5684 034402 104503      CLR1CSR      ;CLEAR 1 SELECTED MK11 CSR
5685 034404 005037 002100      CLR      NOPAR      ;INDICATE PARITY ACTION
5686 034410 000207      RETURN
5687
5688 034412 004737 034464      MTPD25: CALL     MTPA25      ;WRITE DATA & CHECKBITS
5689 034416 104471      ECC1DIS      ;DISABLE ECC ON 1 SELECTED CSR
5690 034420 004737 034504      CALL     MTPB25      ;CHECK FOR NO TRAPS
5691 034424 104507      ENA1SBE      ;DISABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
5692 034426 004737 034536      CALL     MTPC25      ;CHECK FOR EXPECTED TRAP
5693 034432 000207      RETURN

```

```

5696 034434 004737 034464      MTP25: CALL      MTPA25          ;WRITE DATA & CHECKBITS
5697 034440 104471              ECCIDIS          ;DISABLE ECC ON 1 SELECTED CSR
5698 034442 004737 034504      CALL      MTPB25          ;CHECK FOR NO TRAPS
5699                               ;ENABLE DBE TRAPS
5700 034446 104473              ECCINIT         ;INITIALIZE 1 SELECTED MK11 CSR
5701 034450 004737 034536      CALL      MTPC25          ;CHECK FOR EXPECTED TRAP
5702 034454 104507              ENA1SBE        ;DISABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
5703 034456 004737 034536      CALL      MTPC25          ;CHECK FOR EXPECTED TRAP
5704 034462 000207              RETURN
5705
5706                               ;WRITE TSTDAT & TSTDAT+2 & CHECKBITS
5707 034464 104471              MTPA25: ECCIDIS          ;DISABLE ECC ON 1 SELECTED CSR
5708 034466 013711 002344      MOV      TSTDAT,(R1)      ;WRITE FIRST 16 BITS
5709 034472 104475              CB1CSR         ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
5710 034474 013761 002346 000002  MOV      TSTDAT+2,2(R1)   ;WRITE 2ND 16 BITS & CHECKBITS
5711 034502 000207              RETURN
5712
5713                               ;CHECK FOR NO TRAP OCCURING CONDITION
5714 034504 012737 034522 002372  MTPB25: MOV      #1$,PARTHERE ;SETUP TRAP DESTINATION
5715 034512 005711              TST      (R1)           ;ACCESS LOCATIONS
5716 034514 005761 000002      TST      2(R1)
5717 034520 000207              RETURN                  ;NO TRAP - GOOD - RETURN
5718
5719 034522 104426              1$:  READCSR
5720 034524 104024              ERROR   +24
5721 034526              SET     HEADER
5722 034534 000207              RETURN
5723
5724                               ;TRAP SHOULD OCCURE TEST
5725 034536 012737 034550 002372  MTPC25: MOV      #1$,PARTHERE ;SETUP TRAP DESTINATION
5726 034544 005711              TST      (R1)           ;ACCESS 1ST LOCATION
5727 034546 000405              BR       2$             ;NO TRAP - BAD NEWS - SKIP
5728 034550 012737 034574 002372  1$:  MOV      #3$,PARTHERE ;SETUP TRAP DESTINATION
5729 034556 005761 000002      TST      2(R1)           ;ACCESS 2ND LOCATION
5730 034562 104426              2$:  READCSR             ;NO TRAP - BAD NEWS
5731 034564 104025              ERROR   +25
5732 034566              SET     HEADER
5733 034574 000207              3$:  RETURN
5734
  
```

5738 034576
 5739 034576 000137 172360
 5740 034602 010221
 5741 034604 010321
 5742 034606 077005
 5743 034610 000207
 5744
 5745 034612

```

MTPA26: SUBTST <<MTPA26      RANDOM DATA (WRITE)>>
:*****
:*SUBTEST      MTPA26  RANDOM DATA (WRITE)
:*****
1$:      JMP      KDPARO      ;V177640      GOTO V172360
         MOV      R2,(R1)+   ;V177644
         MOV      R3,(R1)+   ;V177646
         SOB      R0,1$      ;V177650
         RETURN    ;V177652
  
```

5746
 5747
 5748 034612 000137 172360
 5749 034616 020221
 5750 034620 001401
 5751 034622 104451
 5752 034624 005127
 5753 034626 000000
 5754 034630 020321
 5755 034632 001401
 5756 034634 104451
 5757 034636 005167 177764
 5758 034642 077015
 5759 034644 000207
 5760
 5761
 5762
 5763 034646

```

MTPB26: SUBTST <<MTPB26      RANDOM DATA (READ)>>
:*****
:*SUBTEST      MTPB26  RANDOM DATA (READ)
:*****
1$:      JMP      @WKDPARO   ;V177640      GOTO V172360
         CMP      R2,(R1)+   ;V177644
         BEQ      2$        ;V177646
         PERR25   ;V177650
2$:      COM      (PC)+     ;V177652
         RANODD: 0        ;V177654      FOR ERROR REPORTING
         CMP      R3,(R1)+   ;V177656
         BEQ      3$        ;V177660
         PERR25   ;V177662
3$:      COM      RANODD    ;V177664
         SOB      R0,1$      ;V177670
         RETURN    ;V177672
         .DSABL  LSB
         .ENABL  AMA
  
```

5764
 5765
 5766
 5767
 5768
 5769 034646 073427 000007
 5770 034652 060305
 5771 034654 005504
 5772 034656 060204
 5773 034660 062705 001057
 5774 034664 000730
 5775
 5776 034666

```

MTPC26: SUBTST <<RANDOM NUMBER SUBPROGRAM>>
:*****
:*SUBTEST      RANDOM NUMBER SUBPROGRAM
:*****
:CALLER MUST SETUP
:      MOV      SEEDLO,R3
:      MOV      SEEDHI,R2
:      MOV      R3,R5
:      MOV      R2,R4
ASHC    #7,R4      ;V172360
ADD     R3,R5      ;V172364
ADC     R4         ;V172366
ADD     R2,R4      ;V172370
ADD     #1057,R5   ;V172372
BR      -116      ;V172376      GOTO V172260
  
```

5777 034666 005504
 5778 034670 062704 047401
 5779 034674 010503
 5780 034676 010402
 5781 034700 000137 177644

```

MTPD26: SUBTST <<RANDOM NUMBER SUBSUBPROGRAM>>
:*****
:*SUBTEST      RANDOM NUMBER SUBSUBPROGRAM
:*****
ADC     R4         ;V172260
ADD     #47401,R4  ;V172262
MOV     R5,R3      ;V172266
MOV     R4,R2      ;V172270
JMP     UIPAR2     ;V172272      GOTO V177644
  
```

5784 034704

```

MTP030: SUBST <<MTP030      FLUSH OUT DBE'S>>
:*****
:*SUBTEST      MTP030      FLUSH OUT DBE'S
:*****
1$:  MOV      (R0),R2      ;V177640
      MOV      R2,(R0)+    ;V177642
      SOB      R1,1$      ;V177644
      RETURN                     ;V177646
    
```

5785 034704 011002
 5786 034706 010220
 5787 034710 077103
 5788 034712 000207
 5789
 5790 034714

```

MTP031: SUBST <<MTP031      SOB-A-LONG TEST>>
:*****
:*SUBTEST      MTP031      SOB-A-LONG TEST
:*****
    
```

5791
 5792 034714 000000
 5793 034716 077001
 5794 034720 005167 177772
 5795 034724 020167 177766
 5796 034730 001403
 5797 034732 104454
 5798 034734 010167 177756
 5799 034740 005167 177752
 5800 034744 010200
 5801
 5802 034746 010503
 5803 034750 005725
 5804 034752 010504
 5805 034754 020527 160000
 5806 034760 001001
 5807 034762 000207
 5808
 5809 034764 014344
 5810 034766 001376
 5811 034770 000752
 5812 000056
 5813

```

      .DSABL  AMA
      0
1$:  SOB      R0,1$      ;MOVE TERMINATOR
      COM      1$      ;SOB TILL R0 UNDERFLOWS
      CMP      R1,1$      ;WRITE COMPLEMENT OF SOB
      BEQ      2$      ;READ & CHECK FOR NOT 'SOB R0,DOT'
      PERR30
      MOV      R1,1$
2$:  COM      1$      ;CORRECT SOB INSTRUCTION
      MOV      R2,R0      ;REINITIALIZE SOB CONSTANT
      .UPDATE MOVE REGISTERS
      MOV      R5,R3
      TST      (R5)+      ;BUMP (SAFELY) BY 2
      MOV      R5,R4
      CMP      R5,#LAST+2
      BNE      3$      ;DONE?
      RETURN                     ;NO - SKIP
      ;YES
3$:  MOV      -(R3),-(R4)
      BNE      3$
      BR      1$
SOBLENGTH=-MTP031
      .ENABL  AMA
    
```

5816 034772
5817 034772 062704 000006
5818 034776 042704 177771
5819 035002 010301
5820 035004 060401
5821 035006 010011
5822 035010 062703 000010
5823 035014 077512
5824 035016 000207
5825
5826 035020

```
MTPA32: SUBST <<MTPA32 SKEWED UP ADDRESS TEST (WRITE)>>
:*****
:*SUBTEST MTPA32 SKEWED UP ADDRESS TEST (WRITE)
:*****
1$: ADD #6,R4 ;V177640 ;ADD OFFSET TO OFFSET COUNTER
BIC #^C6,R4 ;V177644 ;MASK TO (0,2,4,6)
MOV R3,R1 ;V177650 ;PUT IN LSB'S OF ADDRESS
ADD R4,R1 ;V177652 ;PUT IN MSB'S OF ADDRESS
MOV R0,(R1) ;V177654 ;WRITE DATA IN R0 INTO MEMORY
ADD #10,R3 ;V177656 ;BUMP ADDRESS MSB TO NEXT BLOCK OF 4 WORDS
SOB R5,1$ ;V177662 ;LOOP TILL DONE
RETURN ;V177664
```

5827 035020 062704 000006
5828 035024 042704 177771
5829 035030 010301
5830 035032 060401
5831 035034 011102
5832 035036 020200
5833 035040 001401
5834 035042 104446
5835 035044 062703 000010
5836 035050 077515
5837 035052 000207
5838
5839 035054

```
MTPB32: SUBST <<MTPB32 SKEWED UP ADDRESS TEST (READ)>>
:*****
:*SUBTEST MTPB32 SKEWED UP ADDRESS TEST (READ)
:*****
1$: ADD #6,R4 ;V177640 ;ADD OFFSET TO OFFSET COUNTER
BIC #^C6,R4 ;V177644 ;MASK TO (0,2,4,6)
MOV R3,R1 ;V177650 ;PUT IN LSB'S OF ADDRESS
ADD R4,R1 ;V177652 ;PUT IN MSB'S OF ADDRESS
MOV (R1),R2 ;V177654 ;READ DATA INTO R0
CMP R2,R0 ;V177656 ;IS IT CORRECT?
BEQ 2$ ;V177660 ;YES - SKIP
PERR22 ;V177662 ;NO - PRINT ERROR
2$: ADD #10,R3 ;V177664 ;BUMP ADDRESS MSB TO NEXT BLOCK OF 4 WORDS
SOB R5,1$ ;V177666 ;LOOP TILL DONE
RETURN ;V177670
```

5840
5841
5842
5843
5844
5845 035054 012401
5846 035056 020102
5847 035060 001401
5848 035062 104430
5849 035064 077305
5850 035066 012703 020000
5851 035072 012400
5852 035074 020005
5853 035076 001401
5854 035100 104427
5855 035102 077305
5856 035104 000207

```
MTP033: SUBST <<MTP033 WRITE RECOVERY TEST>>
:*****
:*SUBTEST MTP033 WRITE RECOVERY TEST
:*****
;THE TEST ACTUALLY EXECUTED ALREADY IN THE MEMORY UNDER TEST.
;THIS CODE INSURES THAT IT CHANGED MEMORY TO HAVE
;1/2 BANK OF #5141 WHICH IS A "COM -(R1)" INSTRUCTION AND
;1/2 BANK OF #110 WHICH IS A "JMP (R0)" INSTRUCTION.
1$: MOV (R4)+,R1 ;V177640 ;GET DATA FROM LOWER 1/2 BANK
CMP R1,R2 ;V177642 ;IS IT #5141?
BEQ 2$ ;V177644 ;YES - SKIP
PERR02 ;V177646 ;NO - TAKE ERROR TRAP
2$: SOB R3,1$ ;V177650 ;LOOP FOR 1/2 BANK
MOV #SIZE/2,R3 ;V177652 ;RESTORE LOOP SIZE
3$: MOV (R4)+,R0 ;V177656 ;GET DATA FROM UPPER 1/2 BANK
CMP R0,R5 ;V177660 ;IS IT #110?
BEQ 4$ ;V177662 ;YES - SKIP
PERR01 ;V177664 ;NO- TAKE ERROR TRAP
4$: SOB R3,3$ ;V177666 ;LOOP FOR 1/2 BANK
RETURN
```

5859 035106

MTP034: SUBST <<MTP034 BRANCH GOBBLE TEST>>
 :*****
 :*SUBTEST MTP034 BRANCH GOBBLE TEST
 :*****

5860
 5861 035106 000000
 5862 035110 000000
 5863 035112 000261
 5864 035114 105511
 5865 035116 100402
 5866 035120 105212
 5867 035122 000773
 5868
 5869
 5870 035124 102401
 5871 035126 104461
 5872
 5873 035130 000242
 5874 035132 105212
 5875 035134 103402
 5876 035136 102001
 5877 035140 100401
 5878 035142 104461
 5879
 5880
 5881
 5882 035144 010701
 5883 035146 162701 000036
 5884 035152 010102
 5885 035154 005202
 5886
 5887
 5888 035156 010503
 5889 035160 005725
 5890 035162 010504
 5891
 5892
 5893 035164 020527 160000
 5894 035170 001001
 5895 035172 000207
 5896
 5897
 5898 035174 014344
 5899 035176 001376
 5900 035200 005011
 5901 035202 000743
 5902 000076
 5903

```

      .DSABL  AMA
      0
BGTEST: 0 ;MOVE TERMINATOR
BRGOBB: SEC ;TEST WORD (TWO BYTES)
      ADCB (R1) ;SET CARRY (TO BE ADDED TO 'BGTEST')
      BMI 1$ ;INCREMENT LOW BYTE OF 'BGTEST'
      INCB (R2) ;BRANCH WHEN BIT7 IS SET
      BR BRGOBB ;INCREMENT HIGH BYTE OF 'BGTEST'
      ;LOOP 128 TIMES

1$: ;NOW CHECK FOR CORRECT CONDITION CODES
      BVS 2$ ;BR IF V-BIT SET (SHOULD BE)
      PERR35 ;NO - REPORT ERROR AND ABORT TEST
      ;COND CODES NOT EQUAL TO 1010

2$: CLV ;CLEAR V-BIT
      INCB (R2) ;INCREMENT HIGH BYTE OF 'BGTEST' ONCE MORE
      BCS 3$ ;BR IF C-BIT SET (SHOULD NOT BE)
      BVC 3$ ;BR IF V-BIT CLEAR (SHOULD NOT BE)
      BMI 4$ ;BR IF N-BIT SET (SHOULD BE)
      PERR35 ;NO - REPORT ERROR AND ABORT TEST
      ;COND CODES NOT EQUAL TO 1010

4$: ;UPDATE TEST POINTERS
      MOV PC,R1
5$: SUB #5$-BGTEST,R1
      MOV R1,R2
      INC R2

;UPDATE MOVE REGISTERS
      MOV R5,R3
      TST (R5)+ ;BUMP (SAFELY) BY 2
      MOV R5,R4

;DONE?
      CMP R5,#LAST+2 ;DONE?
      BNE 6$ ;NO - SKIP
      RETURN ;YES - RETURN

6$: ;MOVE CODE 1 LOCATION
      MOV -(R3),-(R4)
      BNE 6$
      CLR (R1) ;CLEAR TEST WORD 'BGTEST'
      BR BRGOBB ;RUN MOVED CODE AGAIN

GBLENGTH--MTP034
      .ENABL AMA
  
```

MISC SUBROUTINES

5905
5906
5907 035204

.SBIT !SC SUBROUTINES

REGCOPY:SUBTS <<SUBR COPY R0 TO R4,R1 TO R3, & R2 TO R5>>

:*****
: *SUBTEST SUBR COPY R0 TO R4,R1 TO R3, & R2 TO R5
:*****

5908 035204 010004
5909 035206 010103
5910 035210 010205
5911 035212 000207
5912
5913 035214

MOV R0,R4
MOV R1,R3
MOV R2,R5
RETURN

FLIPWARN:SUBTST <<FLIP WARNING CONSTANTS IN WORST CASE NOISE TESTS>>

:*****
: *SUBTEST FLIP WARNING CONSTANTS IN WORST CASE NOISE TESTS
:*****

5914 035214
5915 035216 005237 002734
5916 035222 042737 177774 002734
5917 035230 022737 000001 002734
5918 035236 001414
5919 035240 022737 000002 002734
5920 035246 001413
5921 035250 022737 000003 002734
5922 035256 001414
5923 035260 005000
5924 035262 013704 002726
5925 035266 000414
5926 035270
5927 035274 000411
5928 035276 012700 000401
5929 035302 013704 002726
5930 035306 000404
5931 035310 012700 000401
5932 035314 012704 000401
5933 035320 010037 026522
5934 035324 010037 026536
5935 035330 010037 026562
5936 035334 010037 026576
5937 035340
5938 035342 000207
5939
5940 035344

PUSH R0
INC FLIPLOC
BIC #*C3,FLIPLOC
CMP #1,FLIPLOC
BEQ 1\$
CMP #2,FLIPLOC
BEQ 2\$
CMP #3,FLIPLOC
BEQ 3\$
CLR R0
MOV ONES,R4
BR 4\$
1\$: CLEAR R0,R4
BR 4\$
2\$: MOV #401,R0
MOV ONES,R4
BR 4\$
3\$: MOV #401,R0
MOV #401,R4
4\$: MOV R0,WARN2
MOV R0,WARN3
MOV R0,WARN4
MOV R0,WARN5
POP R0
RETURN

BACKGND:SUBTST <<SUBR WRITE BACKGROUND>>

:*****
: *SUBTEST SUBR WRITE BACKGROUND
:*****

5941
5942 035344 104415
5943 035346 012700 060000
5944 035352 012701 040000
5945 035356
5946 035364 012737 000207 177644
5947 035372 004737 026042
5948 035376 104416
5949 035400 000207

:WRITES DATA FROM R2
SAVREG
MOV #FIRST,R0
MOV #SIZE,R1
BMOV MTP000
MOV #207,UIPAR2
CALL SUPD01
RESREG
RETURN

;WARNING PUTTING 'RETURN' INSTRUCTION AFTER WRITE

5953 035402

PCONFIG:SUBTST <<SUBR PRINT CONFIGURATION MAP>>

: *SUBTEST SUBR PRINT CONFIGURATION MAP

5954 035402

PUSH TKVEC,TKVEC+2,R0

5955 035414 010637 035662

MOV SP,PCONFS ;SAVE LAST GOOD SP

5956 035420 012737 035630 000060

MOV #PCONF2,TKVEC

5957 035426 012737 000340 000062

MOV #340,TKVEC+2

5958 035434 017700 145334

MOV @STKB,R0 ;KILL ANY OLD INTERRUPT

5959 035440 042737 000200 177776

BIC #BIT7,PSW ;LOWER CPU PRIORITY TO 140

5960 035446 052777 000100 145316

BIS #BIT6,@STKS ;ENABLE KEYBOARD INTERRUPTS

5961

TYPE MSG001

5962 035454

TYPE MSG002

5963 035460

TYPE MSG003

5964 035464

;IF FAT PAPER ON TERMINAL GOTO 1\$

5965

IF #SW4 SET.IN @SWR THEN JUMPTO PCONF1

5966 035470

MOV #60.,R0

5967 035504 012700 000074

MOV R0,R4

5968 035510 010004

CLEAR R1,R3

5969 035512

TYPE MSG004

5970 035516

CALL TCONFIG ;GO TYPE CONFIGURATION (1ST HALF)

5971 035522 004737 035664

TYPE \$CRLF

5972 035526

TYPE MSG017 ;PRINT SPACE(S)

5973 035532

TYPE MSG011

5974 035536

TYPE \$CRLF

5975 035542

TYPE MSG017 ;PRINT SPACE(S)

5976 035546

TYPE MSG012

5977 035552

MOV #60.*2*3,R1

5978 035556 012701 000550

MOV R1,R3

5979 035562 010103

CALL TCONFIG

5980 035564 004737 035664

BR PCONF2

5981 035570 000417

5982

PCONF1: MOV #120.,R0

5983 035572 012700 000170

MOV R0,R4

5984 035576 010004

CLEAR R1,R3

5985 035600

TYPE MSG014 ;SPACE

5986 035604

TYPE MSG011

5987 035610

TYPE MSG004

5988 035614

TYPE MSG012

5989 035620

CALL TCONFIG

5990 035624 004737 035664

5991

PCONF2: MOV PCONFS,SP ;RESTORE STACK

5992 035630 013706 035662

BIC #BIT6,@STKS

5993 035634 042777 000100 145130

MOVB @STKB,R0 ;READ CHAR TO KILL FLAG

5994 035642 117700 145126

POP R0,TKVEC+2,TKVEC

5995 035646 000207

RETURN

5996 035660

PCONFS: 0 ;STACK SAVED HERE.

5997

5998 035662 000000

6002 035664

SUBSTST <<SUBR TYPE CONFIGURATION>>

```

*****
*SUBTEST      SUBR      TYPE CONFIGURATION
*****
:CALL:  MOV      #N,R0      ;N=NUMBER OF CHARACTERS
:        MOV      R0,R4      ;BACKUP
:        MOV      #K,R1      ;INDEX CONSTANT
:        MOV      R1,R3      ;BACKUP
:        CALL     TCONFIG     ;ACTUAL CALL
:        RETURN     ;ONLY RETURN
*****

```

6003
6004
6005
6006
6007
6008
6009
6010
6011
6012
6013
6014
6015
6016
6017
6018
6019
6020
6021
6022
6023
6024
6025
6026
6027
6028
6029
6030
6031
6032
6033
6034
6035
6036
6037
6038
6039
6040
6041
6042
6043

035664
035670 032761 004000 003016
035676 001403
035700
035704 000402
035706
035712 062701 000006
035716 077014
035720 010400
035722 010301

035724
035730 016105 003016
035734 072527 177774
035740 042705 177760
035744 022705 000012
035750 100003
035752 062705 000067
035756 000402
035760 062705 000060
035764 110537 112134
035770
035774 062701 000006
036000 077025
036002 010400
036004 010301

```

*****
** ERROR **
*****
TCONFIG:TYPE  MSG005
1$: BIT      #BIT11,CONFIG(R1)  ;ERROR ON THIS BANK?
   BEQ      2$                  ;NO - SKIP
   TYPE     MSG013              ;PRINT 'X'
   BR       3$
2$: TYPE     MSG014              ;PRINT SPACE
3$: ADD     #6,R1                ;BUMP POINTER
   SOB     R0,1$                ;LOOP TILL DONE
   MOV     R4,R0
   MOV     R3,R1

*****
** CPU'S **
*****
TYPE  MSG008
4$: MOV  CONFIG(R1),R5
   ASH  #-4,R5                ;GET CPU BITS
   BIC  #^C17,R5              ;CLEAR NON INTERESTING BITS
   CMP  #10.,R5
   BPL  8$
   ADD  #67,R5                ;MAKE NUMBERS OVER 9 HEX
   BR   9$
8$: ADD  #60,R5                ;MAKE ASCII
9$: MOVB R5,MSG015            ;PLUG INTO MEMORY
   TYPE  MSG015
   ADD  #6,R1                ;BUMP POINTER
   SOB  R0,4$                ;LOOP TILL DONE
   MOV  R4,R0
   MOV  R3,R1

```

```

6046
6047
6048
6049 036006
6050
6051 036012 016105 003016
6052 036016 072527 177763
6053 036022 042705 177774
6054 036026 005705
6055 036030 001004
6056 036032 112737 000077 112134
6057 036040 000435
6058 036042 016105 003016
6059 036046 042705 177770
6060 036052 022705 000001
6061 036056 001002
6062 036060 006305
6063 036062 000420
6064 036064 022705 000002
6065 036070 001002
6066 036072 006305
6067 036074 000413
6068 036076 022705 000004
6069 036102 001003
6070 036104 012705 000010
6071 036110 000405
6072 036112 005705
6073 036114 001403
6074 036116 012705 000077
6075 036122 000402
6076 036124 062705 000060
6077 036130 110537 112134
6078 036134
6079 036140
6080 036150 062701 000006
6081 036154 077062
6082 036156 010400
6083 036160 010301
6084
6085
6086
6087
6088
6089 036162
6090 036166 016105 003016
6091 036172 072527 177763
6092 036176 042705 177774
6093 036202
6094 036210 112737 000113 112134
6095 036216
6096 036220
6097 036230 112737 000112 112134
6098 036236
6099 036240 112737 000060 112134
6100 036246
6101 036246
6102 036246

```

```

:*****
:** INTERLEAVE **
:*****
TYPE MSG007
:THIS IS AN ENTRY POINT FROM ERROR REPORTS
TCFIG1: MOV CONFIG(R1),R5
ASH #13.,R5 ;GET MEMORY TYPE
BIC #^C3,R5 ;CLEAR NON INTERESTING BITS
TST R5
BNE 1$
MOVB #'?,MSG015
BR 7$
1$: MOV CONFIG(R1),R5
BIC #^C7,R5 ;GET INTERLEAVE BITS
CMP #1,R5
BNE 2$
ASL R5 ;2 TO 1
BR 5$
2$: CMP #2,R5
BNE 3$
ASL R5 ;4 TO 1
BR 5$
3$: CMP #4,R5
BNE 4$
MOV #8.,R5 ;8 TO 1
BR 5$
4$: TST R5
BEQ 5$
MOV #'?,R5
BR 6$
5$: ADD #60,R5 ;MAKE ASCII
6$: MOVB R5,MSG015 ;PLUG INTO MEMORY
7$: TYPE MSG015
IF NOTAB NE #0 THEN $RETURN
ADD #6,R1 ;BUMP POINTER
SOB R0,TCFIG1 ;LOOP TILL DONE
MOV R4,R0
MOV R3,R1
:*****
:** MEMORY TYPE **
:*****
:ENABL LSB
8$: TYPE MSG009
MOV CONFIG(R1),R5
ASH #13.,R5 ;GET MEMORY TYPE
BIC #^C3,R5 ;CLEAR NON INTERESTING BITS
IF R5 EQ #1
MOVB #'K,MSG015
ELSE
IF #SLAVE3.SLAVE2.SLAVE1.MASTER SET.IN CONFIG(R1)
MOVB #'J,MSG015
ELSE
MOVB #'O,MSG015
END ;OF IF #SLAVE3.SLAVE2.SLAVE1.MASTER
END ;OF IF R5
TYPE MSG015

```

```

6103 036252 062701 000006      ADD    #6,R1      ;BUMP POINTER
6104 036256 077035              SOB    R0,8$     ;LOOP TILL DONE
6105 036260 010400              MOV    R4,R0
6106 036262 010301              MOV    R3,R1
6107                          .DSABL 1$B
6108
6109                          ;*****
6110                          ;** BOX **
6111                          ;*****
6112 036264              TYPE  MSG016
6113 036270 016105 003016      9$:  MOV    CONFIG(R1),R5
6114 036274 032705 000010      BIT    #BIT3,R5      ;EXTERNAL INTERLEAVE?
6115 036300 001404              BEQ    10$          ;NO - SKIP
6116 036302 112737 000115 112134  MOVB   #'M,MSG015    ;INDICATE MULTIPLE BOXES
6117 036310 000417              BR     12$
6118 036312 032705 020014      10$: BIT    #BIT13:14,R5 ;MJ11?
6119 036316 001004              BNE   11$          ;NO - SKIP
6120 036320 112737 000077 112134  MOVB   #'?,MSG015    ;I DON'T KNOW HOW MJ11'S INTERLEAVE
6121 036326 000410              BR     12$
6122 036330 072527 177770      11$: ASH    #-8,,R5     ;GET BOX NUMBER
6123 036334 042705 177774      BIC    #^C3,R5     ;CLEAR NON INTERESTING BITS
6124 036340 062705 000060      ADD    #60,R5      ;MAKE ASCII
6125 036344 110537 112134      MOVB   R5,MSG015    ;PLUG INTO MEMORY
6126 036350              TYPE  MSG015
6127 036354 062701 000006      ADD    #6,R1      ;BUMP POINTER
6128 036360 077035              SOB    R0,9$     ;LOOP TILL DONE
6129 036362 010400              MOV    R4,R0
6130 036364 010301              MOV    R3,R1
6131
6132                          ;*****
6133                          ;** PROTECTED **
6134                          ;*****
6135 036366              TYPE  MSG010
6136 036372 005761 003016      13$: TST    CONFIG(R1)  ;BANK PROTECTED?
6137 036376 100004              BPL   14$          ;NO - SKIP
6138 036400 112737 000120 112134  MOVB   #'P,MSG015
6139 036406 000407              BR     15$
6140 036410 032761 010000 003016 14$: BIT    #BIT12,CONFIG(R1) ;PROTECTED REGION OF MK11 BOX?
6141 036416 001406              BEQ    16$          ;NO - SKIP
6142 036420 112737 000113 112134  MOVB   #'K,MSG015
6143 036426              TYPE  MSG015
6144 036432 000402              BR     17$
6145 036434              TYPE  MSG014
6146 036440 062701 000006      16$: ADD    #6,R1      ;PRINT SPACE
6147 036444 077026              SOB    R0,13$     ;BUMP POINTER
6148 036446 010400              MOV    R4,R0     ;LOOP TILL DONE
6149 036448 010301              MOV    R3,R1
6150 036452 000207              RETURN

```

```

        .SBTTL TRAP PARITY ERROR HANDLER
        .....
        VECTOR TO HERE FROM TRAPS TO 114
        IGNORE ERRORS BUT COUNT IF NOPAR FLAG = 1.
        .....
        CODE ACTION
        ---0--- PRINT UNEXPECTED PARITY TRAP
        1 COUNT ERROR & SAVE 1ST IN 'PADDRESS'
        2 SET 'ABORT' / SETUP 'BADPC' / RETURN VIA PCBUMP
        3 RETURN VIA 'PARTHERE'
        4 COUNT ERROR & SAVE 1ST IN 'PADDRESS' REGARDLESS OF ERROR REGISTER
        .....
        6154
        6155
        6156
        6157
        6158
        6159
        6160
        6161
        6162
        6163
        6164
        6165
        6166
        6167
        6168 036454 022737 000001 002100 PARITY: CMP #1,NOPAR ;COUNTING PARITY ERRORS?
        6169 036462 001023 BNE 3$ ;NO - SKIP
        6170 036464 032737 000001 177744 BIT #BIT0,MEMERR ;MEMORY TIMEOUT?
        6171 036472 001402 BEQ 1$ ;NO - SKIP
        6172 036474 000137 036646 JMP NONEXIST ;YES - SIMULATE A TRAP TO 4
        6173 036500 005237 002074 1$: INC PARCNT ;PARITY ERROR COUNTER + 1
        6174 036504 022737 000001 002074 CMP #1,PARCNT ;FIRST PARITY ERROR?
        6175 036512 001003 BNE 2$ ;NO - SKIP
        6176 036514 013737 177740 002042 MOV LOADRS,PADDRESS ;SAVE 1ST BAD PARITY ADDRESS
        6177 036522 013737 177744 177744 2$: MOV MEMERR,MEMERR ;CLEAR ERROR BITS
        6178 036530 000002 RTI
        6179 036532 022737 000002 002100 3$: CMP #2,NOPAR ;ACTION CODE - 2 ?
        6180 036540 001016 BNE 6$ ;NO - SKIP
        6181 036542 SET ABORTFLAG ;YES
        6182 036550 004737 036770 CALL BADSTACK ;FIND BAD SP,PC,PSW OFF STACK
        6183 036554 063716 002406 ADD PCBUMP,(SP) ;UPDATE RETURN PC
        6184 036560 013737 177744 177744 MOV MEMERR,MEMERR ;CLEAR ERROR BITS
        6185 036566 042766 000004 000002 BIC #BIT2,2(SP) ;SHOW FAILURE BY .NE.
        6186 036574 000002 RTI
        6187 036576 022737 000003 002100 6$: CMP #3,NOPAR ;ACTION CODE - 3 ?
        6188 036604 001006 BNE 7$ ;NO - SKIP
        6189 036606 013716 002372 MOV PARTHERE,(SP)
        6190 036612 013737 177744 177744 MOV MEMERR,MEMERR ;CLEAR ERROR BITS
        6191 036620 000002 RTI
        6192 036622 022737 000004 002100 7$: CMP #4,NOPAR
        6193 036630 001001 BNE 8$
        6194 036632 000722 BR 1$
        6195
        6196 036634 004737 036770 8$: CALL BADSTACK ;FIND BAD SP,PC,PSW OFF STACK
        6197 036640 FATAL 32
    
```

```

6200 .SBTTL TRAP NON-EXISTANT MEMORY (HOLES) HANDLER
6201 :*****
6202 :VECTOR TO HERE (SOMETIMES) FROM TRAPS TO 4
6203 :
6204 : CODE IN NONEM DETERMINES ACTION AS FOLLOWS:
6205 : 1) IGNORE ERRORS BUT COUNT IF NONEM (NO NON-EXISTANT MEMORY) FLAG = 1.
6206 : 2) TO EXIT PATTERN 0 DURING SIZING IF NON-EXIST MEM ERROR
6207 :*****
6208 036646 022737 000001 002102 NONEXIST: CMP #1, NONEM ;COUNTING NON-EXISTANT MEMORY ERRORS?
6209 036654 001014 BNE 2$ ;NO - SKIP
6210 036656 005237 002072 INC NEMCNT ;BUMP NON-EXISTANT MEMORY COUNTER
6211 036662 022737 000001 002072 CMP #1, NEMCNT ;FIRST ERROR?
6212 036670 001005 BNE 1$ ;NO - SKIP
6213 036672 010037 002040 MOV R0, ADDRESS ;ASSUME R0 CONTAINS THE ADDRESS ACCESSED
6214 036676 013737 177744 177744 MOV MEMERR, MEMERR ;CLEAR OUT HIADRS & LOADRS REG'S
6215 036704 000002 1$: RTI
6216 036706 005237 002072 2$: INC NEMCNT ;BUMP NON-EXISTANT MEMORY COUNTER
6217 036712 012701 000001 MOV #1, R1 ;DUMMY UP R1 FOR A FORCED SOB EXIT
6218 036716 013737 177744 177744 MOV MEMERR, MEMERR ;CLEAR OUT HIADRS & LOADRS REG'S
6219 036724 000002 RTI
6220
6221 :*****
6222 .SBTTL TRAP TIMEOUT (TRAP TO 4) HANDLER
6223 036726 004737 036770 TIMEOUT: CALL BADSTACK ;FIND BAD SP, PC, PSW OFF STACK
6224 036732 FATAL 6
6225 :*****
6226 .SBTTL TRAP MEMORY MANAGEMENT (TRAP TO 250) HANDLER
6227 036740 004737 036770 MMTRAP: CALL BADSTACK ;FIND BAD SP, PC, PSW OFF STACK
6228 036744 FATAL 7
6229 :*****
6230 036752 004737 036770 PDP1105: .SBTTL TRAP RESERVED INSTRUCTION HANDLER
6231 036756 CALL BADSTACK ;FIND BAD SP, PC, PSW OFF STACK
6232 FATAL 5
6233 036764 IITRAP: SUBSTST <<UNEXPECTED IIST TRAP HANDLER>>
6234 :*****
6235 036766 104057 *SUBTEST UNEXPECTED IIST TRAP HANDLER
6236 000002 ERROR +57
6237 036770 RTI
6238 :*****
6239 036774 062737 000002 002032 BADSTACK: SUBSTST <<FIND BAD SP, PC, & PSW FROM STACK>>
6240 037002 016637 000002 002026 :*****
6241 037010 016637 000004 002036 *SUBTEST FIND BAD SP, PC, & PSW FROM STACK
6242 037016 000207 :*****
MOV SP, BADSP
ADD #2, BADSP
MOV 2(SP), BADPC
MOV 4(SP), BADPSW
RETURN

```

```

6245          .SBTTL TRAP   KERNEL TRAP HANDLER
6246          ;*****
6247          ;KERNEL IS A TRAP THAT COMES HERE
6248          ;*****
6249
6250 037020 042766 140000 000002 $KERNEL   BIC   #140000,2(SP)
6251 037026 000002          RTI
6252          ;*****
6253          .SBTTL TRAP   ENERGIZE TRAP HANDLER
6254 037030 052737 001001 177572 $ENERGIZE:BIS  #BIT9.BIT0,MMRO
6255 037036 000002          RTI
6256          ;*****
6257          .SBTTL TRAP   DEENERGIZE TRAP HANDLER
6258 037040 042737 001001 177572 $DEENERGIZE:BIC #BIT9.BIT0,MMRO
6259 037046 000002          RTI
6260          ;*****
6261          .SBTTL TRAP   CACHON TRAP HANDLER
6262 037050 013737 002700 177746 $(CACHN: MOV  CACHK,CONTRL ;SETUP CACHE AS PER CONSTANT (USUALLY 1 FULLY ON)
6263 037056 052737 000001 177746   BIS  #BIT0,CONTRL  ;DISABLE TRAPS (BUT NOT ABORTS)
6264 037064 000002          RTI
6265          ;*****
6266          .SBTTL TRAP   CACHOFF TRAP HANDLER
6267          ;DISABLE TRAPS (NOT ABORTS), FORCE MISSES, FLUSH, BYPASS
6268 037066 052737 001415 177746 $CACHF: BIS  #BIT0!BIT2!BIT3!BIT8.BIT9,CONTRL
6269 037074 000002          RTI

```

6273					.SBTTL TRAP LOAD CSR TRAP HANDLER
6274					;LOAD CORRECT CSR WITH DATA IN CSR & CSR+2
6275	037076				\$LOADC: PUSH RO
6276	037100	012700	172100		MOV #MK11ADD,RO ;CREATE CSR ADDRESS
6277	037104	063700	002256		ADD CSRNO,RO
6278	037110	005737	002254		TST CSRREL ;CSR'S RELOCATED?
6279	037114	001014			BNE \$LOAD1 ;YES - SKIP
6280	037116	013720	002144		MOV CSR,(RO)+ ;LOAD IT
6281	037122				IF TWOCSRS IS TRUE
6282	037130	013710	002146		MOV CSR+2,(RO)
6283	037134				ELSE
6284	037136	042710	100000		BIC #BIT15,(RO)
6285	037142				END ;OF IF TWOCSRS
6286	037142				POP RO
6287	037144	000002			RTI
6288	037146	04270C	020000		\$LOAD1: BIC #20000,RO
6289	037152	013737	177746	002370	MOV CONTRL,OLDCACHE ;SAVE CACHE STATUS
6290	037160	104424			CACHOFF ;TURN CACHE OFF
6291	037162	013720	002144		MOV CSR,(RO)+ ;LOAD IT
6292	037166				IF TWOCSRS IS TRUE
6293	037174	013710	002146		MOV CSR+2,(RO)
6294	037200				ELSE
6295	037202	042710	100000		BIC #BIT15,(RO)
6296	037206				END ;OF IF TWOCSRS
6297	037206	013737	002370	177746	MOV OLDCACHE,CONTRL ;RESTORE CACHE
6298	037214				POP RO
6299	037216	000002			RTI

```

6302          .SBTTL TRAP READ CSR TRAP HANDLER
6303          ;READ THE CORRECT CSR INTO LOCATIONS CSR & CSR+2
6304 037220   $READC: PUSH    RO
6305 037222   012700 172100   MOV    #MK11ADD,RO      ;CREATE CSR ADDRESS
6306 037226   063700 002256   ADD    CSRNO,RO
6307 037232   005737 002254   TST    CSRREL          ;CSR'S RELOCATED?
6308 037236   001095          BNE    1$              ;YES - SKIP
6309 037240   012077 002144   MOV    (RO)+,CSR      ;READ IT
6310 037244   011037 002146   MOV    (RO),CSR+2     ;READ IT
6311 037250   000415          BR     2$
6312 037252   042700 020000   1$:  BIC    #20000,RO
6313 037256   013737 177746 002370   MOV    CONTRL,OLDCACHE ;SAVE CACHE STATUS
6314 037264   104424          CACHOFF                ;TURN CACHE OFF
6315 037266   012037 002144   MOV    (RO)+,CSR      ;READ IT
6316 037272   011037 002146   MOV    (RO),CSR+2     ;READ IT
6317 037276   013737 002370 177746   MOV    OLDCACHE,CONTRL ;RESTORE CACHE
6318 037304   6319 037306 000002   2$:  POP    RO
6320          RTI
6321          .SBTTL TRAP TEST (R1) & READ CSR CAREFULLY
6322 037310   $TSTRD: PUSH    RO
6323 037312   BMOV   TSTRD1
6324 037320   012700 172100   MOV    #MK11ADD,RO      ;CREATE CSR ADDRESS
6325 037324   063700 002256   ADD    CSRNO,RO
6326 037330   005737 002254   TST    CSRREL          ;CSR'S RELOCATED?
6327 037334   001003          BNE    1$              ;YES - SKIP
6328 037336   004737 177640   CALL   FASTCITY        ;CALL TO THE USER INSTRUCTION PAR'S
6329 037342   000413          BR     2$
6330 037344   042700 020000   1$:  BIC    #20000,RO
6331 037350   013737 177746 002370   MOV    CONTRL,OLDCACHE ;SAVE CACHE STATUS
6332 037356   104424          CACHOFF                ;TURN CACHE OFF
6333 037360   004737 177640   CALL   FASTCITY        ;CALL TO THE USER INSTRUCTION PAR'S
6334 037364   013737 002370 177746   MOV    OLDCACHE,CONTRL ;RESTORE CACHE
6335          ;IF SINGLE BIT ERROR ONLY - SET CARRY BIT
6336 037372   2$:  POP    RO
6337 037374   IF #BIT4 SET.IN CSR AND #BIT15 OFF.IN CSR
6338 037414   052766 000001 000002   BIS    #BIT0,2(SP)
6339 037422   ELSE
6340 037424   042766 000001 000002   BIC    #BIT0,2(SP)
6341 037432   END ;OF IF #BIT4
6342 037432   000002   RTI
6343
6344 037434   005010   TSTRD1: CLR    (RO)          ;V177640
6345 037436   SUPERVISOR ;V177642 ;ENTER SUPERVISOR MODE
6346 037444   105711   TSTB   (R1)          ;V177646
6347 037446   042737 140000 177776   BIC    #BIT15:BIT14,PSW ;V177650
6348 037454   012037 002144   MOV    (RO)+,CSR      ;V177656
6349 037460   011037 002146   MOV    (RO),CSR+2     ;V177662
6350 037464   000207   RETURN                ;V177666

```



```

6354 .SBTTL TRAP ECC DISABLE ALL CSR'S TRAP HANDLER
6355 037466 012737 000002 002144 $ECCDIS:MOV #BIT1,CSR
6356 037474 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
6357 037510 005037 002146 CLR CSR+2
6358 037514 004737 040442 CALL CSROUT
6359 037520 000002 RTI
6360 .SBTTL TRAP ECC DISABLE OF 1 SELECTED CSR TRAP HANDLER
6361 037522 012737 000002 002144 $ECC1DIS:MOV #BIT1,CSR
6362 037530 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
6363 037544 005037 002146 CLR CSR+2
6364 037550 104425 LOADCSR
6365 037552 000002 RTI
6366 .SBTTL TRAP MK11 INITIALIZE ALL CSR'S TRAP HANDLER
6367 037554 012737 000001 002144 $ECCINIT:MOV #BIT0,CSR
6368 037562 005037 002146 CLR CSR+2
6369 037566 004737 040442 CALL CSROUT
6370 037572 000002 RTI
6371 .SBTTL TRAP MK11 INITIALIZE 1 SELECTED CSR TRAP HANDLER
6372 037574 012737 000001 002144 $ECC1INIT:MOV #BIT0,CSR
6373 037602 005037 002146 CLR CSR+2
6374 037606 104425 LOADCSR
6375 037610 000002 RTI
6376 .SBTTL TRAP ENABLE SBE PARITY TRAPS ON ALL CSR'S
6377 037612 012737 000003 002144 $ENASBE:MOV #BIT0!BIT1,CSR
6378 037620 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
6379 037634 005037 002146 CLR CSR+2
6380 037640 004737 040442 CALL CSROUT
6381 037644 000002 RTI
6382 .SBTTL TRAP ENABLE SBE PARITY TRAPS ON 1 SELECTED CSR
6383 037646 012737 000003 002144 $ENA1SBE:MOV #BIT0!BIT1,CSR
6384 037654 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
6385 037670 005037 002146 CLR CSR+2
6386 037674 104425 LOADCSR
6387 037676 000002 RTI
6388 .SBTTL TRAP WRITE CHECKBITS THRU ALL CSR'S TRAP HANDLER
6389 037700 013737 002404 002144 $CBCSR:MOV CHECK,CSR ;BITS 14-8
6390 037706 052737 000006 002144 BIS #BIT1!BIT2,CSR ;CHECK MODE
6391 037714 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
6392 037730 005037 002146 CLR CSR+2
6393 037734 004737 040442 CALL CSROUT
6394 037740 000002 RTI
6395 .SBTTL TRAP WRITE CHECKBITS THRU 1 SELECTED CSR TRAP HANDLER
6396 037742 013737 002404 002144 $CB1CSR:MOV CHECK,CSR ;BITS 14-8
6397 037750 052737 000006 002144 BIS #BIT1!BIT2,CSR ;CHECK MODE
6398 037756 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
6399 037772 005037 002146 CLR CSR+2
6400 037776 104425 LOADCSR
6401 040000 000002 RTI

```

```

6405 .SBTTL TRAP WAS THERE A SBE ON ANY CSR TRAP HANDLER
6406 040002 $WASSBE: PUSH R1,R4
6407 040006 013701 002334 MOV MKCSRS,R1 ;GET CSR'S BYTE
6408 040012 005004 CLR R4
6409 040014 BEGIN LWSBE
6410 040014 FOR CSRNO := #0 TO #34 BY #4
6411 040020 106301 ASLB R1
6412 040022 ON.ERROR
6413 040024 104426 READCSR
6414 040026 IF #BIT4 SET.IN CSR
6415 040036 SET R4
6416 040042 LEAVE LWSBE
6417 040044 END :OF IF #BIT4
6418 040044 END :OF ON.ERROR
6419 040044 IFB R1 EQ #0 THEN LEAVE LWSBE
6420 040050 END :OF FOR CSRNO
6421 040066 END LWSBE
6422 040066 006004 ROR R4 ;SET C BIT FOR ERROR
6423 040070 POP R4,R1
6424 040074 ON.ERROR
6425 040076 052766 000001 000002 BIS #BIT0,2(SP)
6426 040104 ELSE
6427 040106 042766 000001 000002 BIC #BIT0,2(SP)
6428 040114 END :OF ON.ERROR
6429 040114 000002 RTI
6430 .SBTTL TRAP WAS THERE A SBE IN 1 SELECTED CSR TRAP HANDLER
6431 :ON RETURN IF CARRY IS SET THERE WAS A SBE
6432 040116 104426 $WAS1SBE: READCSR
6433 040120 042766 000001 000002 BIC #BIT0,2(SP) ;CLR C BIT ON STACK
6434 040126 032737 000020 002144 BIT #BIT4,CSR
6435 040134 001403 BEQ 1$
6436 040136 052766 000001 000002 BIS #BIT0,2(SP) ;SET C BIT ON STACK
6437 040144 000002 1$: RTI

```

```

6440 .SBTTL TRAP WAS THERE A DBE ON ANY CSR TRAP HANDLER
6441 040146 $WASDBE: PUSH R1,R4
6442 040152 013701 002334 MOV MKCSRS,R1 ;GET CSR'S BYTE
6443 040156 005004 CLR R4
6444 040160 BEGIN LWDBE
6445 040160 FOR CSRNO :- #0 TO #34 BY #4
6446 040164 106301 ASLB R1
6447 040166 ON.ERROR
6448 040170 104426 READCSR
6449 040172 IF #BIT15 SET.IN CSR
6450 040202 SET R4
6451 040206 LEAVE LWDBE
6452 040210 END :OF IF #BIT15
6453 040210 END :OF ON.ERROR
6454 040210 IFB R1 EQ #0 THEN LEAVE LWDBE
6455 040214 FND :OF FOR CSRNO
6456 040232 END LWDBE
6457 040232 006004 ROR R4 ;SET C BIT FOR ERROR
6458 040234 POP R4,R1
6459 040240 ON.ERROR
6460 040242 052766 000001 000002 BIS #BIT0,2(SP)
6461 040250 ELSE
6462 040252 042766 000001 000002 BIC #BIT0,2(SP)
6463 040260 END :OF ON.ERROR
6464 040260 000002 RTI

```

```

6465 .SBTTL TRAP WAS THERE A DBE ON 1 SELECTED CSR TRAP HANDLER
6466 ;ON RETURN IF CARRY IS SET THERE WAS A DBE
6467 040262 104426 $WAS1DBE: READCSR
6468 040264 005737 002144 TST CSR ;DBE?
6469 040270 100010 BPL 3$ ;NO - SKIP
6470 040272 005737 002146 TST CSR+2 ;DBE IN OTHER WORD?
6471 040276 100401 BMI 2$ ;YES - SKIP
6472 040300 104021 ERROR +21 ;NO - ONLY ONE FLAG POPPED UP
6473 040302 052766 000001 000002 2$: BIS #BIT0,2(SP) ;SET C BIT ON STACK
6474 040310 000002 RTI
6475 040312 042766 000001 000002 3$: BIC #BIT0,2(SP) ;CLR C BIT ON STACK
6476 040320 000002 RTI

```

```

6479                                     .SBTTL TRAP CLEAR ALL MK11 CSR'S TRAP HANDLER
6480 040322 $CLRCSR: CLEAR CSR,CSR+2
6481 040332 004737 040442 CALL CSROUT
6482 040336 000002 RTI
6483                                     .SBTTL TRAP CLEAR 1 SELECTED MK11 CSR TRAP HANDLER
6484 040340 $CLR1CSR: CLEAR CSR,CSR+2
6485 040350 104425 LOADCSR
6486 040352 000002 RTI
6487                                     .SBTTL TRAP ECC DISABLE, CHECK MODE, & WRITE CHECKBITS IN ALL CSR'S TRAP HANDLER
6488                                     :CHECKBITS ALREADY IN LOC "CSR"
6489 040354 052737 000006 002144 $CHKDIS: BIS #BIT1!BIT2,CSR ;ECC DISABLE & DIAG CHECK MODE
6490 040362 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
6491 040376 005037 002146 CLR CSR+2
6492 040402 004737 040442 CALL CSROUT
6493 040406 000002 RTI
6494                                     .SBTTL TRAP ECC DISABLE, CHECK MODE, & WRITE CHECKBITS IN 1 SELECTED CSR
6495                                     :CHECKBITS ALREADY IN LOC "CSR"
6496 040410 052737 000006 002144 $CHK1DIS: BIS #BIT1!BIT2,CSR ;ECC DISABLE & DIAG CHECK MODE
6497 040416 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
6498 040432 005037 002146 CLR CSR+2
6499 040436 104425 LOADCSR
6500 040440 000002 RTI

```

```

6503 040442          CSROUT: SUBTST <<SUBR WRITE IN ALL CSR'S>>
:.....
:*SUBTEST          SUBR WRITE IN ALL CSR'S
:.....
6504 040442          PUSH R1
6505 040444 013701 002334  MOV MKCSRS,R1 ;GET CSR'S BYTE
6506 040450          BEGIN LCSROUT
6507 040450          FOR CSRNO : #0 TO #34 BY #4
6508 040454 106301      ASLB R1
6509 040456          ON.ERROR
6510 040460 104425      LOADCSR
6511 040462          END ;OF ON.ERROR
6512 040462          IFB R1 EQ #0 THEN LEAVE LCSROUT
6513 040466          END ;OF FOR CSRNO
6514 040504          END LCSROUT
6515 040504          POP R1
6516 040506 000207      RETURN
6517
6518
6519 040510          .SBTTL TRAP INVALIDATE BACKGROUND PATTERN
6520 040514 013701 002106 $INVALID: PUSH RO,R1
6521 040520 070127 000006  MOV BANK,R1
6522 040524 042761 020000 003020  MUL #6,R1
6523 040532          BIC #BIT13,CONF:G+2(R1)
6524 040536 000002          POP R1,RO
RTI

```

6528 040540

```
CHKGEN: SUBTST<<SUBR GENERATE CHECK BITS>>
:*****
:*SUBTEST SUBR GENERATE CHECK BITS
:*****
```

6529
 6530
 6531
 6532
 6533
 6534
 6535
 6536 040540
 6537 040554 012702 000077
 6538 040560 012703 040640
 6539 040564 013705 002402
 6540 040570 012501
 6541 040572 011500
 6542
 6543 040574 006704
 6544 040576 142304
 6545 040600 074402
 6546 040602 073027 000007
 6547 040606 001372
 6548
 6549 040610 042702 177600
 6550 040614 000302
 6551 040616 010237 002404
 6552 040622
 6553 040636 000207

```
:CHECK BIT GENERATOR ROUTINE
:CALLING SEQUENCE IS:
:      MOV #WORD1,SOURCE ;SOURCE = ADDRESS OF DATA
:      CALL CHKGEN
:
:CHECK BITS RETURNED IN BITS 14-8 OF LOCATION CHECK
:
:      PUSH R0,R1,R2,R3,R4,R5
:      MOV #77,R2 ;DEFAULT CHECKBITS FOR DOUBLE WORD OF ZEROS
:      MOV #CHKTAB,R3 ;ADDRESS OF CHECKBIT TABLE
:      MOV SOURCE,R5 ;GET SOURCE ADDRESS
:      MOV (R5)+,R1 ;GET LSB'S
:      MOV (R5),R0 ;GET MSB'S
:
:      SXT R4 ;EXTEND SIGN OF DOUBLE WORD TO R4
:      BICB (R3)+,R4 ;ELIMINATE BITS THAT DON'T COUNT
:      XOR R4,R2 ;COMPLEMENT MASKED BITS IN CHECKBITS
:      ASHC #1,R0 ;DOUBLE PRECISION LEFT SHIFT R0,,R1
:      BNE 1$ ;LOOP TILL ALL BITS ARE CHECKED
:
:      BIC #C177,R2 ;KILL ALL JUNK BITS
:      SWAB R2 ;POSITION CHECKBITS IN BITS 14-8
:      MOV R2,CHECK
:      POP R5,R4,R3,R2,R1,R0
:      RETURN
```

Address	Hex	Dec	CHKTAB	Bit
6556	040640		:BYTE #3	
6557	040640	200	.BYTE ^C177	:BIT 31
6558	040641	301	.BYTE ^C076	:BIT 30
6559	040642	302	.BYTE ^C075	:BIT 29
6560	040643	203	.BYTE ^C174	:BIT 28
6561	040644	304	.BYTE ^C073	:BIT 27
6562	040645	205	.BYTE ^C172	:BIT 26
6563	040646	206	.BYTE ^C171	:BIT 25
6564	040647	307	.BYTE ^C070	:BIT 24
6565			:BYTE #2	
6566	040650	310	.BYTE ^C067	:BIT 23
6567	040651	211	.BYTE ^C166	:BIT 22
6568	040652	212	.BYTE ^C165	:BIT 21
6569	040653	313	.BYTE ^C064	:BIT 20
6570	040654	214	.BYTE ^C163	:BIT 19
6571	040655	315	.BYTE ^C062	:BIT 18
6572	040656	316	.BYTE ^C061	:BIT 17
6573	040657	217	.BYTE ^C160	:BIT 16
6574			:BYTE #1	
6575	040660	320	.BYTE ^C057	:BIT 15
6576	040661	221	.BYTE ^C156	:BIT 14
6577	040662	222	.BYTE ^C155	:BIT 13
6578	040663	323	.BYTE ^C054	:BIT 12
6579	040664	224	.BYTE ^C153	:BIT 11
6580	040665	325	.BYTE ^C052	:BIT 10
6581	040666	326	.BYTE ^C051	:BIT 9
6582	040667	227	.BYTE ^C150	:BIT 8
6583			:BYTE #0	
6584	040670	340	.BYTE ^C037	:BIT 7
6585	040671	241	.BYTE ^C136	:BIT 6
6586	040672	242	.BYTE ^C135	:BIT 5
6587	040673	343	.BYTE ^C034	:BIT 4
6588	040674	244	.BYTE ^C133	:BIT 3
6589	040675	345	.BYTE ^C032	:BIT 2
6590	040676	346	.BYTE ^C031	:BIT 1
6591	040677	247	.BYTE ^C130	:BIT 0

6595 040700

SUBSTST<<SUBR MAPPER>>

6596
6597
6598
6599
6600
6601
6602
6603
6604 040700
6605 040712 012700 172340
6606 040716 012701 172240
6607 040722 012702 077406
6608 040726 012704 172200
6609 040732 012705 000010
6610 040736 012021
6611 040740 010224
6612 040742 077503
6613 040744 012741 177600
6614
6615
6616 040750 022703 000170
6617 040754 001412
6618 040756 072327 000010
6619
6620 040762 012701 172246
6621 040766 012702 000004
6622 040772 010321
6623 040774 062703 000200
6624 041000 077204
6625 041002
6626 041014 000207
6627
6628 041016
6629 041030 005000
6630 041032 012701 172340
6631 041036 012702 077406
6632 041042 012703 172300
6633 041046 012704 000010
6634 041052 010021
6635 041054 010223
6636 041056 062700 000200
6637 041062 077405
6638 041064 012741 177600
6639 041070 012741 177400
6640 041074
6641 041104 013700 002710
6642 041110 004737 042370
6643 041114
6644 041114
6645 041126 000002

```

.....
:SUBTEST SUBR MAPPER
.....
:THIS SUBROUTINE MAPS THE MEMORY BANK (16K WORDS = 1 BANK)
:IN R3 TO THE TEST PATTERN AREA (SUPERVISOR VIRTUAL (60000 - 157777)).
:CALL MOV BANKNO,R3 ;SET UP BANK ARGUEMENT
:CALL MAPPER ;ACTUAL CALL
:RETURN ;ONLY RETURN

:SET SUPERVISOR UP FOR 1 TO 1 MAP
MAPPER: PUSH R0,R1,R2,R4,R5
MOV #KIPAR0,R0 ;FIRST AREA TO MAP TO
MOV #SIPAR0,R1 ;FIRST ADDRESS REGISTER
MOV #77406,R2 ;CONSTANT FOR 4K PAGE, UP, R/W
MOV #SIPDR0,R4 ;FIRST DISCRIPTOR REGISTER
MOV #8.,R5 ;COUNTER
1$: MOV (R0)+,(R1)+ ;PUT IN SUPERVISOR ADDRESS
MOV R2,(R4)+ ;PUT IN SUPERVISOR DISCRIPTOR
SOB R5,1$ ;LOOP TILL DONE
MOV #177600,-(R1) ;CORRECT LAST FIELD FOR PERIPHERALS PAGE

:SET UP SUPERVISOR FOR TEST AREA
CMP #120.,R3 ;MAP NOTHING (1 TO 1)?
BEQ 3$ ;YES - SKIP
ASH #9.,R3 ;BANK 1 STARTS AT 100,000 LESS 6 LSB'S
;FOR MEMORY MANAGEMENT - 1000
MOV #SIPAR3,R1 ;SETUP FOR AUTO INCREMENTING
MOV #4,R2 ;COUNTER
2$: MOV R3,(R1)+ ;PLUG IN PAR INFO
ADD #200,R3 ;BUMP ADDRESS 4K
SOB R2,2$ ;LOOP TILL DONE
3$: POP R5,R4,R2,R1,R0
RETURN
$KMAP: .SBTTL TRAP MAP KERNEL (ALMOST 1 TO 1) TRAP HANDLER
PUSH R0,R1,R2,R3,R4
CLR R0 ;1ST AREA TO MAP TO
MOV #KIPAR0,R1 ;FIRST ADDRESS
MOV #77406,R2 ;CONSTANT FOR 4K PAGE,UP,R/W
MOV #KIPDR0,R3 ;1ST PAGE DISCRIPTOR REGISTER
MOV #8.,R4 ;COUNTER
1$: MOV R0,(R1)+ ;PUT IN KERNEL ADDRESS
MOV R2,(R3)+ ;PUT IN KERNEL DISCRIPTOR
ADD #200,R0 ;ADD ADDRESS CONSTANT FOR 4K CHANGE
SOB R4,1$ ;LOOP TILL DONE
MOV #177600,-(R1) ;THE PERIPHERALS PAGE TO KIPAR7
MOV #177400,-(R1) ;AND NEXT LOWER PAGE TO KIPAR6
IF CPUBIT NE #MASTER ;IF I'M NOT THE MASTER
MOV LOADHOME,R0 ;MAP TO LOADERS LIKE THE MASTER DID.
CALL NEWLOAD
END ;OF IF CPUBIT
POP R4,R3,R2,R1,R0
RTI
    
```


6649 041130
6650 041130
6651 041144
6652 041144
6653 041152 004737 042422
6654 041156
6655 041200 013700 002106
6656 041204 010037 002532
6657 041210 013701 002710
6658 041214 004737 042072
6659 041220 004737 042370
6660 041224 013701 002110
6661 041230 052761 100000 003020
6662 041236 042761 020000 003020
6663 041244
6664 041246
6665 041246
6666 041262
6667 041272
6668 041276
6669 041276
6670 041302
6671 041302
6672 041302
6673 041306
6674 041316
6675 041326
6676 041336
6677 041346
6678 041366
6679
6680 041406
6681 041410
6682 041410
6683 041410
6684 041410
6685 041410
6686 041410
6687 041422
6688 041432
6689 041436
6690 041436
6691 041442 042761 020000 003020
6692 041442 005000
6693 041450 071027 000006
6694 041452

```

RELOCATE:SUBST <<RELOCATE PROGRAM>>
:.....
:SUBTEST RELOCATE PROGRAM
:.....
IF #SW12 SET.IN @SWR THEN $RETURN ERROR
BEGIN LOADERBANK
FOR BANK :- #1 TO #167
CALL EXBANK
IF ACFLAG IS TRUE AND PFLAG IS FALSE AND BMFLAG IS FALSE
MOV BANK,RO
MOV RO,LOADBANK
MOV LOADHOME,R1
CALL BANKMOV
CALL NEWLOAD ;MAP NEW LOADER BANK IN KERNEL
MOV BANKINDEX,R1
BIS #BIT15,CONFIG+2(R1) ;MARK LOADER
BIC #BIT13,CONFIG+2(R1) ;INVALIDATE BACKGROUND PATTERN
LEAVE LOADERBANK
END ;OF IF ACFLAG
END ;OF FOR BANK
IF #SW13 OFF.IN @SWR
TYPE MSG075 ;RELOCATION NOT POSSIBLE
END ;OF IF #SW13
$RETURN ERROR
END LOADERBANK
BEGIN FINDBANK
FOR R1 : #3*2 TO #167*3*2 BY #6
IF #BIT11'BIT15 OFF.IN CONFIG(R1) ;IF NO ERRORS & NOT PROGRAM SPACE
IF #BIT15 OFF.IN CONFIG+2(R1) ;IF NOT LOADER BANK
IF CPUBIT SET.IN CONFIG(R1) ;IF ACCESSABLE
IF #BIT13!BIT14 OFF.IN CONFIG(R1) THEN LEAVE FINDBANK ;IF M11
IF #BIT13 SET.IN CONFIG(R1) AND #BIT14 OFF.IN CONFIG(R1) ;IF M11
IF #BIT12 SET.IN CONFIG-6(R1) AND #BIT12 OFF.IN CONFIG(R1)
;IF 1ST UNPROTECTED M11 BANK
LEAVE FINDBANK
END ;OF IF #BIT12
END ;OF IF #BIT13
END ;OF IF CPUBIT
END ;OF IF #BIT15
END ;OF IF #BIT11
END ;OF FOR
IF #SW13 OFF.IN @SWR
TYPE MSG075 ;RELOCATION NOT POSSIBLE
END ;OF IF #SW13
$RETURN ERROR
END FINDBANK
BIC #BIT13,CONFIG+2(R1) ;INVALIDATE BACKGROUND PATTERN
CLR RO
DIV #6,RO

```

6697	041456			
6698	041462	004737	042240	
6699	041466			
6700	041474			
6701	041506	104417		
6702	041510	042737	000040	172516
6703	041516	013700	002400	
6704	041522	006200		
6705	041524			
6706	041526	012737	100000	170200
6707	041534			
6708	041534	010037	170202	
6709	041540	004737	042026	
6710	041544	052737	000040	172516
6711	041552	042737	001001	177572
6712	041560	004737	042322	
6713	041564	052737	001001	177572
6714	041572			
6715	041600			

```

RELOC1: LET NEWBANK : R0
        CALL USERMAP
        USER
        BMOV 0,100000,SIZE
        KERNEL
        BIC #BIT5,MMR3
        MOV NEWBANK,R0
        ASR R0
        ON.ERROR
        MOV #BIT15,MAPLO
        END :OF ON.ERROR
        MOV R0,MAPH0
        CALL LOWMAP
        BIS #BIT5,MMR3
        BIC #BIT9:BIT0,MMR0
        CALL NEWKERNEL
        BIS #BIT9:BIT0,MMR0
        SET RLFLAG
        $RETURN NOERROR

```

```

;MAP NEWBANK TO USER PAH
;ENTER USER MODE
;MOVE PROGRAM
;ENTER KERNEL MODE
;TURN OFF UNIBUS MAP

;SETUP LOWER 16K IN UNIBUS MAP
;ENERGIZE UNIBUS MAP
;DEENERGIZE MEMORY MANAGEMENT - BUT DON'T TRAP

;ENERGIZE MEMORY MANAGEMENT - BUT DON'T TRAP

```

RELOCATE PROGRAM

6718 04 604

UNRELOCATE:SUBTST <<UNRELOCATE PROGRAM>>

:*****
:*SUBTEST UNRELOCATE PROGRAM
:*****

6719
6720 041604
6721 041606 013701 002532
6722 041612 013700 002710
6723 041616 004737 042072
6724 041622 004737 042370
6725 041626
6726 041632 013737 002532 002106
6727 041640 004737 042422
6728 041644 013701 002110
6729 041650 042761 100000 003020
6730 041656 013737 002710 002106
6731 041664 004737 042422
6732 041670 013701 002110
6733 041674 042761 020000 003020
6734 041702
6735
6736
6737 041706 042737 020000 003020
6738 041714
6739 041720 004737 042240
6740 041724
6741 041732
6742 041744 104417
6743 041746 042737 001001 177572
6744 041754 004737 042322
6745 041760 052737 001001 177572
6746 041766 005037 002134
6747 041772 042737 000040 172516
6748 042000
6749 042010 004737 042026
6750 042014 052737 000040 172516
6751 042022
6752 042024 000207
6753
6754 042026

```

:RESTORE LOADERS
PUSH RO
MOV LOADBANK,R1
MOV LOADHOME,RO
CALL BANKMOV
CALL NEWLOAD ;MAP NEW LOADER BANK IN KERNEL SPACE
PUSH BANK
MOV LOADBANK,BANK
CALL EXBANK
MOV BANKINDEX,R1
BIC #BIT15,CONFIG+2(R1) ;CLEAR LOADER FLAG
MOV LOADHOME,BANK
CALL EXBANK
MOV BANKINDEX,R1
BIC #BIT13,CONFIG+2(R1) ;INVALIDATE BACKGROUND PATTERN
POP BANK

:RESTORE BANK 0
BIC #BIT13,CONFIG+2 ;INVALIDATE BACKGROUND PATTERN
LET NEWBANK := #0
CALL USERMAP ;MAP NEWBANK TO USER PAR
USER ;ENTER USER MODE
BMOV 0,100000,SIZE ;MOVE PROGRAM
KERNEL ;ENTER KERNEL MODE
BIC #BIT9:BIT0,MMR0 ;DEENERGIZE MEMORY MANAGEMENT - BUT DON'T TRAP
CALL NEWKERNEL
BIS #BIT9:BIT0,MMR0 ;ENERGIZE MEMORY MANAGEMENT - BUT DON'T TRAP
CLR RLFLAG
BIC #BIT5,MMR3 ;TURN OFF UNIBUS MAP
CLEAR MAPLO,MAPHO
CALL LOWMAP ;SETUP LOWER 16K OF UNIBUS MAP
BIS #BIT5,MMR3 ;ENERGIZE UNIBUS MAP
POP RO
RETURN

```

LOWMAP: SUBTST <<SETUP LOWER 16K OF UNIBUS MAP>>

:*****
:*SUBTEST SETUP LOWER 16K OF UNIBUS MAP
:*****

6755 042026
6756 042034 012700 170200
6757 042040 012701 170204
6758 042044 012702 000003
6759 042050 012011
6760 042052 062721 020000
6761 042056 012021
6762 042060 077205
6763 042062
6764 042070 000207

```

PUSH RO,R1,R2
MOV #MAPLO,RO
MOV #MAPL1,R1
MOV #3,R2
1$: MOV (RO)+,(R1)
ADD #BIT13,(R1)+
MOV (RO)+,(R1)+
SOB R2,1$
POP R2,R1,RO
RETJRN

```

6767 042072

BANKMOV:SUBTST <<MOVE BANKS>>

 :*SUBTEST MOVE BANKS

```

6768           :MOVE 3/4 OF A BANK
6769           :CALLING SEQUENCE
6770           :R0 = DESTINATION BANK
6771           :R1 = SOURCE BANK
6772 042072 104415 SAVREG
6773 042074 004737 042240 CALL USERMAP
6774 042100 104416 RESREG
6775 042102 104415 SAVREG
6776 042104 072027 000011 ASH #9,R0
6777 042110 072127 000011 ASH #9,R1
6778 042114 012702 177650 MOV #UIPAR4,R2
6779 042120 012703 000200 MOV #200,R3
6780
6781 042124 010122 MOV R1,(R2)+ ;MAP 1ST HALF BANK
6782 042126 060301 ADD R3,R1 ;BUMP BY 4K
6783 042130 010122 MOV R1,(R2)+
6784 042132 060301 ADD R3,R1
6785
6786 042134 010022 MOV R0,(R2)+
6787 042136 060300 ADD R3,R0
6788 042140 010022 MOV R0,(R2)+
6789 042142 060300 ADD R3,R0
6790
6791 042144 USER
6792 042152 BMOV 100000,140000,SIZE/2 ;MOV 1ST HALF BANK
6793 042164 104417 KERNEL ;ENTER KERNEL MODE
6794
6795 042166 012702 177650 MOV #UIPAR4,R2
6796
6797 042172 010122 MOV R1,(R2)+ ;MAP 2ND HALF BANK
6798 042174 060301 ADD R3,R1 ;BUMP BY 4K
6799 042176 010122 MOV R1,(R2)+
6800 042200 060301 ADD R3,R1
6801
6802 042202 010022 MOV R0,(R2)+
6803 042204 060300 ADD R3,R0
6804 042206 010022 MOV R0,(R2)+
6805 042210 060300 ADD R3,R0
6806
6807 042212 USER
6808 042220 BMOV 100000,140000,SIZE/4 ;MOV 3RD FOURTH OF BANK
6809 042232 104417 KERNEL ;ENTER KERNEL MODE
6810
6811 042234 104416 RESREG
6812 042236 000207 RETURN
    
```

MOVE BANKS

6815 042240

USERMAP:SUBTST <<SUBR MAP USER TO NEW BANK>>

*SUBTEST SUBR MAP USER TO NEW BANK

6816 042240 012701 177640
 6817 042244 012702 172340
 6818 042250 012703 177600
 6819 042254 012704 172300
 6820 042260 012705 000004
 6821 042264 012221
 6822 042266 011423
 6823 042270 077503

```

MOV #UIPAR0,R1 ;COPY KERNEL PAR'S & PDR'S (0-3)
MOV #KIPAR0,R2
MOV #UIPDR0,R3
MOV #KIPDR0,R4
MOV #4,R5
1$: MOV (R2),(R1)+
    MOV (R4),(R3)+
    SOB R5,1$

```

6824
 6825 042272 013700 002400
 6826 042275 072027 000011
 6827
 6828 042302 012705 000004
 6829 042306 010021
 6830 042310 062700 000200
 6831 042314 011423
 6832 042316 077505
 6833 042320 000207
 6834

```

MOV NEWBANK,R0
ASH #9,R0 ;BANK 1 STARTS AT 100,000 LESS 6 LSB'S
;FOR MEMORY MANAGEMENT = 1000
MOV #4,R5
2$: MOV R0,(R1)+ ;SETUP UIPAR(4-7)
    ADD #200,R0 ;BUMP ADDRESS 4K
    MOV (R4),(R3)+ ;SETUP UIPDR(4-7)
    SOB R5,2$
RETURN

```

6835 042322

NEWKERNEL:SUBTST <<SUBR SETUP KERNEL PAR'S FOR NEW BANK>>

*SUBTEST SUBR SETUP KERNEL PAR'S FOR NEW BANK

6836 042322
 6837 042330 012700 172340
 6838 042334 013701 002400
 6839 042340 072127 000011
 6840
 6841 042344 012705 000004
 6842 042350 010120
 6843 042352 062701 000200
 6844 042356 077504
 6845 042360
 6846 042366 000207
 6847

```

PUSH R0,R1,R5
MOV #KIPAR0,R0
MOV NEWBANK,R1
ASH #9,R1 ;BANK 1 STARTS AT 100,000 LESS 6 LSB'S
;FOR MEMORY MANAGEMENT = 1000
MOV #4,R5
1$: MOV R1,(R0)+ ;SETUP KIPAR(0-3)
    ADD #200,R1
    SOB R5,1$
POP R5,R1,R0
RETURN

```

6848 042370

NEWLOAD:SUBTST <<SUBR SETUP KERNEL PAR'S FOR NEW LOADER BANK>>

*SUBTEST SUBR SETUP KERNEL PAR'S FOR NEW LOADER BANK

6849
 6850 042370
 6851 042374 012701 172350
 6852 042400 072027 000011
 6853 042404 010021
 6854 042406 062700 000200
 6855 042412 010021
 6856 042414
 6857 042420 000207

```

;R0 CONTAINS THE DESTINATION BANK
PUSH R0,R1
MOV #KIPAR4,R1
ASH #9,R0 ;BANK 1 STARTS AT 1000000 LESS 6 LSB'S (1000)
MOV R0,(R1)+ ;SETUP KIPAR4
ADD #200,R0
MOV R0,(R1)+ ;SETUP KIPAR5
POP R1,R0
RETURN

```

6861 042422

EXBANK: SUBST <<SUBR EXAMINE BANK>>

*SUBTEST SUBR EXAMINE BANK

6862

: DOES THE FOLLOWING:

6863

: (1) SETS UP 'BANKINDEX' AND R0 BASED ON VALUE OF 'BANK'

6864

: (2) SETS THE 'MKFLAG' IF THE BANK IS AN MK11

6865

: (3) SETS THE 'KPFLAG' IF THE BANK IS THE PROTECTED REGION OF MK11 MEMORY

6866

: (4) SETS THE 'ACFLAG' IF THE BANK CAN BE ACCESSED BY THIS CPU

6867

: (5) SETS THE 'PFLAG' IF THE BANK IS IN PROGRAM SPACE

6868

: (6) SETS THE 'RRFLAG' IF RELOCATION IS REQUIRED TO TEST THIS BANK

6869

: HOWEVER, IT COMPLEMENTS THIS FLAG IF THE RELOCATION FLAG 'RLFLAG' IS SET

6870

: (THIS IS NECESSARY FOR THE USE OF THE RECURSIVE 'MODE' SUBROUTINES)

6871

: BUT! THE 'RRFLAG' IS ALWAYS SET TO DISABLE TESTING IF FIELD SERVICE MODE

6872

: 'SELECTED BANKS' ARE BEING TESTED AND THIS BANK IS NOT SELECTED.

6873

: (7) SETS THE 'BMFLAG' IF THE BANK IS A BAD MEMORY

6874

: HOWEVER, IT COMPLEMENTS THIS FLAG IF THE 'WORST' FLAG IS NOT SET

6875

: (THIS IS NECESSARY FOR THE USE OF THE RECURSIVE 'MODE' SUBROUTINES)

6876 042422

: PUSH R0,R1,R2

6877 042430

: CLEAR MKFLAG,KPFLAG

6878 042440

: SET ACFLAG

6879 042446

: CLEAR PFLAG,RRFLAG,BMFLAG

6880 042462 013701 002106

: MOV BANK,R1

6881 042466 070127 000006

: MUL #6,R1

:RO - BANK * 6

6882 042472 010137 002110

: MOV R1,BANKINDEX

6883 042476 032761 010000 003016

: BIT #BIT12,CONFIG(R1)

:PROTECTED REGION OF MK11 MEMORY?

6884 042504 001406

: BEQ 1\$

:NO - SKIP

6885 042506

: SET KPFLAG,RRFLAG

6886 042522 012700 000020

1\$:

: MOV #MASTER,R0

6887 042526

: FOR R2 := #0 TO SLAVES

6888 042530

: IF R0 SET.IN CPUBIT AND R0 OFF.IN CONFIG(R1)

6889 042544 005037 002124

: CLR ACFLAG

6890 042550

: END ;OF IF R0

6891 042550 006300

: ASL R0

6892 042552

: END ;OF FOR R2

6893 042562 016100 003016

2\$:

: MOV CONFIG(R1),R0

6894 042566 042700 117777

: BIC #*C60000,R0

:GET MEMORY TYPE BITS

6895 042572 022700 020000

: CMP #20000,R0

:IS IT AN MK11?

6896 042576 001003

: BNE 3\$

:NO - SKIP

6897 042600

: SET MKFLAG

6898 042606 032761 100000 003016

3\$:

: BIT #BIT15,CONFIG(R1)

:BANK = PROGRAM SPACE?

6899 042614 001406

: BEQ 5\$

:NO - SKIP

6900 042616

: SET PFLAG,RRFLAG

6901 042632 005737 002134

5\$:

: TST RLFLAG

:IS PROGRAM RELOCATED?

6902 042636 001402

: BEQ 6\$

:NO - SKIP

6903 042640 005137 002132

: COM RRFLAG

:YES - COMPLEMENT RELOCATION REQUIRED FLAG

6904 042644 032761 004000 003016

6\$:

: BIT #BIT11,CONFIG(R1)

:ERRORS PRESENT IN THIS BANK?

6905 042652 001403

: BEQ 8\$

:NO - SKIP

6906 042654

: SET BMFLAG

6907 042662 005737 002712

8\$:

: TST WORST

:IS THIS A WORST FIRST PASS?

6908 042666 001002

: BNE 9\$

:YES - SKIP

6909 042670 005137 002136

9\$:

: COM BMFLAG

:NO - COMPLEMENT BAD MEMORY FLAG

6910 042674

: IF SELONLY IS TRUE AND #BIT14 OFF.IN CONFIG+2(R1)

6911 042712

: SET RRFLAG

6912 042720

: END ;OF IF SELONLY

6913 042720

: POP R2,R1,R0

6914 042726 000207

: RETURN

SUBR EXAMINE BANK

SEQ 0403

6918 042730

BANKOK: SUBTST <<SUBR BANK OK?>>

:*****
:*SUBTEST SUBR BANK OK?
:*****

6919

:TEST TO INSURE THAT THE TYPE OF MEMORY IN THE PRESENT BANK

6920

:IS OF THE TYPE WE ARE TESTING 'TMFLAG'.

6921

:RESULT IS RETURNED IN THE CONDITION CODES (OK = (=0)).

6922 042730 013700 002140

MOV TMFLAG,R0

6923 042734 005100

COM R0

6924 042736 013701 002126

MOV MKFLAG,R1

6925 042742 074001

XOR R0,R1

6926 042744 000207

RETURN

;OK - (=OK)

6927

6928 042746

INCRPT:

6929 042746

INCPAT: SUBTST <<SUBR INCREMENT PATTERN TESTING MK11'S>>

:*****
:*SUBTEST SUBR INCREMENT PATTERN TESTING MK11'S
:*****

6930

:INCREMENT THE PATTERN & SET UP THE CONDITION CODES

6931

:RESULT - Z BIT SFT INDICATES OVERFLOW

6932 042746 005237 002120

INC PATTERN

6933 042752 022737 000040 002120

CMP #40,PATTERN

;SET UP CONDITION CODES

6934 042760 000207

RETURN

;NOT EQUAL TO ZERO IS GOOD (NO OVERFLOW)

6935

6936 042762

SETPAT:

6937 042762

HIPAT: SUBTST <<SUBR SET HIGHEST PATTERN TESTING TYPE>>

:*****
:*SUBTEST SUBR SET HIGHEST PATTERN TESTING TYPE
:*****

6938 042762 012737 000037 002120

MOV #37,PATTERN

;SET HIGHEST PATTERN

6939 042770 000207

RETURN

6940

6941 042772

INCBNK: SUBTST <<SUBR INCREMENT BANK & TEST>>

:*****
:*SUBTEST SUBR INCREMENT BANK & TEST
:*****

6942

:RESULTS RETURNED IN CONDITION CODES

6943 042772 005237 002106

INC BANK

6944 042776 022737 000170 002106

CMP #120.,BANK

;TOO FAR?

6945 043004 000207

RETURN

6948 043006

```
INCMAR: SUBTST <<SUBR INCREMENT MARGINS & TEST>>
:*****
:*SUBTEST SUBR INCREMENT MARGINS & TEST
:*****
```

6949
 6950
 6951
 6952 043006
 6953 043024
 6954 043026
 6955 043026 013737 002112 002376
 6956 043034 005037 002112
 6957 043040 004737 043300
 6958 043044 000435
 6959 043046 013737 002112 002376 1\$:
 6960 043054 005237 002112
 6961 043060 022737 000001 002112
 6962 043066 001002
 6963 043070 005237 002112
 6964 043074
 6965 043112
 6966 043114
 6967 043114
 6968 043132
 6969 043134
 6970 043134 005037 002112
 6971 043140 004737 043300
 6972 043144 005737 002112
 6973 043150 000207
 6974
 6975
 6976 043152

```
;SKIPS THE SPECIAL CASE (MARGIN CANNOT = 1)
;RETURNS THE RESULT OF MARGIN OVERFLOW IN THE CONDITION CODES
.ENABL LSB
IF #SW11 OFF.IN @SWR AND QVFLAG IS FALSE
GOTO 1$
END ;OF IF #SW11
MOV MARGIN,OLDMARGIN
CLR MARGIN ;YES - SET MARGIN TO ZERO
CALL COREHISTORY
BR 3$
MOV MARGIN,OLDMARGIN
INC MARGIN
CMP #1,MARGIN ;SPECIAL CASE?
BNE 2$ ;NO - SKIP
INC MARGIN ;YES - SET MARGIN TO '2'
2$: IF MKFLAG IS FALSE AND MARGIN NE #6
GOTO 3$
END ;OF IF MKFLAG
IF MKFLAG IS TRUE AND MARGIN NE #4
GOTO 3$
END ;OF IF MKFLAG
CLR MARGIN ;YES - SET MARGIN TO ZERO
3$: CALL COREHISTORY
TST MARGIN ;SET CONDITION CODE - DONE IF Z BIT SET
RETURN
.DSABL LSB
```

```
DECMAR: SUBTST <<DECREMENT MARGINS & TEST>>
:*****
:*SUBTEST DECREMENT MARGINS & TEST
:*****
```

6977
 6978
 6979 043152 013737 002112 002376
 6980 043160 005337 002112
 6981 043164 022737 000001 002112
 6982 043172 001002
 6983 043174 005337 002112
 6984 043200 004737 043300
 6985 043204 005737 002112
 6986 043210 000207

```
;SKIPS THE SPECIAL CASE (MARGIN CANNOT = 1)
;RETURNS THE RESULT OF MARGIN UNDERFLOW IN THE CONDITION CODES
MOV MARGIN,OLDMARGIN
DEC MARGIN
CMP #1,MARGIN ;SPECIAL CASE?
BNE 1$ ;NO - SKIP
DEC MARGIN ;YES - SET MARGIN TO '0'
1$: CALL COREHISTORY
TST MARGIN ;SETUP CONDITION CODES - NEGATIVE IS UNDERFLOW
RETURN
```


6989 043212

```

SETMAR: SUBTST <<SUBR SET HIGHEST MARGIN>>
:*****
:SUBTEST SUBR SET HIGHEST MARGIN
:*****

```

6990
6991

```

;RECOGNIZES THE 'INHIBIT MARGINS SWITCH'
.ENABL LSB
IF #SW11 SET.IN @SWR OR QVFLAG IS TRUE

```

6992 043212
6993 043230
6994 043232
6995 043232 013737 002112 002376
6996 043240
6997 043246 012737 000005 002112
6998 043254
6999 043256 012737 000003 002112

```

GOTO 1$
END ;OF IF #SW11
MOV MARGIN,OLDMARGIN
IF MKFLAG IS FALSE
MOV #5,MARGIN ;HIGHEST MJ11 MARGIN
ELSE
MOV #3,MARGIN ;HIGHEST MK11 MARGIN
END ;OF IF MKFLAG

```

7000 043264
7001 043264 004737 043300
7002 043270 000402
7003 043272 005037 002112
7004 043276 000207
7005
7006 043300

```

CALL COREHISTORY
BR 2$ ;SKIP
1$: CLR MARGIN ;SET MARGIN TO '0'
2$: RETURN
.DSABL LSB

```

```

COREHISTORY: SUBTST <<SUBR REWRITE CORE HISTORY>>
:*****
:SUBTEST SUBR REWRITE CORE HISTORY
:*****

```

7007 043300
7008 043314
7009 043324
7010 043364 013700 002112
7011 043370 006300
7012 043372 010037 177750
7013
7014 043376
7015 043402 004737 035344
7016 043406 104511
7017 043410
7018 043410
7019 043410
7020 043410 005037 002436
7021 043414 000207

```

IF MKFLAG IS FALSE AND NULLFLAG IS FALSE
IF OLDMARGIN NE MARGIN
IF OLDMARGIN EQ #4 OR OLDMARGIN EQ #5 OR MARGIN EQ #4 OR MARGIN EQ #5
MOV MARGIN,RO
ASL RO
MOV RO,MAINT ;SET MARGINS
LET R2 -- ONES
CALL BACKGND
INVALIDATE
END ;OF IF
END ;OF IF
END ;OF IF
CLR NULLFLAG
RETURN

```

```

7024 043416          BOOT:  SUBST  <<BOOTSTRAP ROUTINE>>
:*****
:*SUBTEST          BOOTSTRAP ROUTINE
:*****
7025                ;INITIALIZE ALL CSR'S
7026                ;CLEAR ANY MARGINS
7027                ;UNRELOCATE IF NECESSARY
7028                ;FLUSH OUT ANY DBE'S
7029                ;TURN OFF MEMORY MANAGEMENT
7030                ;TURN OFF THE UNIBUS MAP
7031                ;BOOT RKO OR RK1
7032 043416 104472  ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
7033 043420          SET4          #BOOT1          ;TRAPS TO 4 GOTO BOOT1
7034 043426 005037 177750  CLR          MAINT
7035 043432          IF RLFLAG IS TRUE THEN $CALL UNRELOCATE
7036 043444 004737 024754  CALL          MT0030          ;FLUSH OUT DBE'S
7037 043450 104421          DEENERGIZE          ;TURN OFF MEMORY MANAGEMENT
7038 043452 042737 000040 172516  BIC          #BITS,MMR3          ;TURN OFF THE UNIBUS MAP
7039 043460 005001          BOOT1:  CLR          R1
7040 043462 000005          1$:  RESET
7041 043464 012700 177406  MOV          #177406,R0
7042 043470 010160 000004  MOV          R1,4(R0)
7043 043474 012710 177400  MOV          #177400,(R0)
7044 043500 012740 000005  MOV          #5,-(R0)
7045 043504 105710          2$:  TSTB         (R0)
7046 043506 100376          BPL          2$
7047 043510 062701 020000  ADD          #BIT13,R1
7048 043514 005710          TST          (R0)
7049 043516 100761          BMI          1$
7050 043520 005007          CLR          PC

```

7053 043522
 7054 043522 004737 043554
 7055 043526
 7056 043542 000777
 7057 043544
 7058 043546 000000
 7059 043550 000137 004352
 7060 043554
 7061
 7062 043554

```

EXIT:  SUBTST <<HALT PROGRAM>>
:*****
:*SUBTEST  HALT PROGRAM
:*****
      CALL  SHUTUP
EXIT2:  IF APTFLAG IS TRUE OR ACTFLAG IS TRUE
      BR
      ELSE
$EXHALT: HALT
      JMP  START
      END ;OF IF APTFLAG
  
```

7063
 7064
 7065
 7066
 7067
 7068
 7069
 7070
 7071 043554 104472
 7072 043556 005037 177750
 7073 043562
 7074 043574
 7075 043602 004737 024754
 7076 043606
 7077 043606 012700 000001
 7078 043612 013701 002710
 7079 043616 004737 042072
 7080 043622 104421
 7081 043624 042737 000040 172516
 7082 043632 005037 002670
 7083 043636 000207
 7084
 7085 043640

```

SHUTUP: SUBTST <<SHUTDOWN DIAGNOSTIC>>
:*****
:*SUBTEST  SHUTDC IN DIAGNOSTIC
:*****
      :INITIALIZE ALL CSR'S
      :CLEAR MARGINS
      :UNRELOCATE
      :FLUSH OUT DBE'S
      :RESTORE LOADERS
      :TURN OFF MEMORY MANAGEMENT
      :UNMAP THE UNIBUS MAP
      :CLEAR MULTIPROCESSING LOCK
ECCINIT ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
CLR  MAINT
IF RLFLAG IS TRUE THEN $CALL UNRELOCATE
IF QUICK IS FALSE
      CALL MT0030 ;FLUSH OUT DBE'S
END ;OF IF QUICK
MOV  #1,R0 ;DESTINATION BANK
MOV  LOADHOME,R1 ;SOURCE BANK
CALL BANKMOV
DEENERGIZE ;TURN OFF MEMORY MANAGEMENT
BIC  #BITS5,MMR3 ;TURN OFF UNIBUS MAP
CLR  LOCK
RETURN
  
```

7086 043640
 7087 043654
 7088 043662 012737 043640 060024
 7089 043670 012737 000340 060026
 7090 043676 012737 000000 123640
 7091 043704 104417
 7092 043706 000000

```

APTDOWN: SUBTST <<APT SHUTDOWN SEQUENCE>>
:*****
:*SUBTEST  APT SHUTDOWN SEQUENC-
:*****
      MAP  #0 ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #
SUPERVISOR ;ENTER SUPERVISOR MODE
MOV  #APTDOWN,FIRST+24
MOV  #340,FIRST+26
MOV  #0,FIRST+APTDOWN
KERNEL ;ENTER KERNEL MODE
APTHLT: HALT
  
```

7095 043710

```

SUBTST <<BLOCK MOVE SUBROUTINE >>
:*****
:SUBTEST   BLOCK MOVE SUBROUTINE
:*****
:BLOCK3 HAS 3 ARGUEMENTS
:BLOCK2 HAS 2 ARGUEMENTS
:BLOCK1 HAS 1 ARGUEMENTS
:
:ALL ARE CALLED BY THE BMOV MACRO
.ENABL   LSB
BLOCK1:  PUSH   R0,R1,R2
         MOV    #FASTCITY,R2
         MOV    #16.,R1
         BR     3$
BLOCK2:  PUSH   R0,R1,R2
         MOV    #16.,R1
         BR     2$
BLOCK3:  PUSH   R0,R1,R2
         MOV    (R5)+,R1
2$:      MOV    (R5)+,R2
3$:      MOV    (R5)+,R0
1$:      MOV    (R0)+,(R2)+
         SOB   R1,1$
         POP   R2,R1,R0
         RTS   R5
         .DSABL  LSB
  
```

```

7096
7097
7098
7099
7100
7101
7102 043710
7103 043716 012702 177640
7104 043722 012701 000020
7105 043726 000413
7106
7107 043730
7108 043736 012701 000020
7109 043742 000404
7110
7111 043744
7112 043752 012501
7113 043754 012502
7114 043756 012500
7115
7116 043760 012022
7117 043762 077102
7118 043764
7119 043772 000205
7120
  
```

7122
 7123
 7124 043774

 7125 043774 104415
 7126 043776
 7127
 7128 044002
 7129 044016
 7130 044022 104416
 7131 044024 000207
 7132 044026
 7133 044026
 7134 044042 104424
 7135 044044
 7136 044052
 7137 044056 104414
 7138 044060
 7139 044062 020027 000024
 7140 044066 101403
 7141 044070
 7142 044074 000766
 7143 044076
 7144 044106 044170
 7145 044110 044256
 7146 044112 044346
 7147 044114 044520
 7148 044116 044764
 7149 044120 045274
 7150 044122 046152
 7151 044124 046160
 7152 044126 046510
 7153 044130 047104
 7154 044132 047550
 7155 044134 047734
 7156 044136 050330
 7157 044140 050356
 7158 044142 050400
 7159 044144 050420
 7160 044146 050436
 7161 044150 050454
 7162 044152 050470
 7163 044154 050502
 7164 044156 050566
 7165 044160
 7166 044166 000731

```

.SBTTL FIELD SERVICE MODE
FIELDSERVICE:SUBTST <<SUBR FIELD SERVICE COMMAND MODF>>
:*****
:SUBTEST SUBR FIELD SERVICE COMMAND MODE
:*****
    SAVREG
    TYPE MSG020 ;FIELD SERVICE COMMAND MODE
    IF RLFLAG IS TRUE OR NOFSMODE IS TRUE
    TYPE MSG048 ;NOT AVAILABLE NOW - TRY LATER
    RESREG
    RETURN
    END ;OF IF RLFLAG
    PUSH CONTRL,CSRNO,KAMIKAZE ;SAVE CACHE STATUS
    CACHOFF ;TURN CACHE OFF
    SET KAMIKAZE
    FS1: TYPE MSG026 ;COMMAND:
    RDDEC ;READ A DECIMAL NUMBER
    POP RO ;COMMAND --> RO
    CMP RO,#20.
    BLOS 1$
    TYPE MSG021
    BR FS1
    1$: CASE RO
    FSCMD0 ;EXIT FIELD SERVICE COMMANDS
    FSCMD1 ;READ CSR
    FSCMD2 ;LOAD CSR
    FSCMD3 ;EXAMINE MEMORY
    FSCMD4 ;MODIFY MEMORY
    FSCMD5 ;SELECT BANK,MARGIN, & PATTERN
    FSCMD6 ;TYPE CONFIGURATION MAP
    FSCMD7 ;BATTERY BACKUP - P/F TEST
    FSCMD8 ;SOB-A-LONG TEST
    FSCMD9 ;SUPER TIGHT SCOPE LOOP
    FSCMD10 ;ERROR SUMMARY
    FSCMD11 ;REFRESH TEST
    FSCMD12 ;SET FILL COUNT
    FSCMD13 ;ENTER KAMIKAZE MODE
    FSCMD14 ;EXIT KAMIKAZE MODE
    FSCMD15 ;TURN CACHE OFF
    FSCMD16 ;TURN CACHE ON
    FSCMD17 ;RUN ONLY MULTIPORT TESTS
    FSCMD18 ;RESUME RUNNING BOTH SINGLE & MULTIPORT TESTS
    FSCMD19 ;TEST ONLY SELECTED BANKS
    FSCMD20 ;RESUME TESTING ALL BANKS
    END ;OF CASE
    BR FS1
    
```

7169 044170
7170 044170
7171 044174 062706 000002
7172 044200
7173 044206 062706 000002
7174 044212 005037 002012
7175 044216
7176 044220
7177 044224
7178 044224
7179 044230
7180 044240 062706 000002
7181 044244
7182 044246
7183 044252
7184 044252 104416
7185 044254 000207
7186
7187 044256

```
FSCMD0: SUBTST <<COMMAND 0 EXIT>>
:*****
:*SUBTEST COMMAND 0 EXIT
:*****
TYPE MSG103 ;LEAVING FIELD SERVICE MODE
ADD #2,SP
IF SKIPKAMI IS TRUE
ADD #2,SP ;THROW AWAY OLD KAMIKAZE FLAG
CLR SKIPKAMI
ELSE
POP KAMIKAZE ;RESTORE OLD KAMIKAZE FLAG
END ;OF IF SKIPKAMI
POP CSRNQ
IF CACHK EQ #BIT0.BIT2.BIT3.BIT8!BIT9 ;IF CACHE IS OFF
ADD #2,SP ;THROW AWAY CACHE STATUS
ELSE
POP CONTRL ;RESTORE CACHE STATUS
END ;OF IF CACHK
RESREG
RETURN
```

7188 044256 004737 050630
7189 044262 010637 002374
7190 044266
7191 044274 104426
7192 044276
7193 044304 104026
7194 044306
7195 044320 000207
7196 044322
7197 044326 013706 002374
7198 044332
7199 044344 000207

```
FSCMD1: SUBTST <<FS COMMAND 1 READ CSR>>
:*****
:*SUBTEST FS COMMAND 1 READ CSR
:*****
CALL WHICHCSR
MOV SP,FSSTACK
SET4 #1$ ;TRAPS TO 4 GOTO 1$
READCSR
SET NOERROR
ERROR +26 ;USE ERROR ROUTINE FOR PRINTOUT
RES4 ;RESET TRAPS TO 4 TO DEFAULT
RETURN
1$: TYPE MSG025 ;THIS CSR DOES NOT EXIST
MOV FSSTACK,SP
RES4 ;RESET TRAPS TO 4 TO DEFAULT
RETURN
```

7202 044346

```

FSCMD2: SUBST <<FS COMMAND 2 LOAD CSR>>
:*****
:SUBTEST FS COMMAND 2 LOAD CSR
:*****
  
```

```

7203 044346 004737 050630
7204 044352 010637 002374
7205 044356
7206 044364 104426
7207 044366
7208 044372
7209 044400 104026
7210 044402
7211 044414
7212 044420 104413
7213 044422
7214 044426
7215 044432 104413
7216 044434
7217 044440
7218 044446 104425
7219 044450 005037 002600
7220 044454 104426
7221 044456
7222 044462
7223 044470 104026
7224 044472 000207
7225 044474
7226 044500 013706 002374
7227 044504
7228 044516 000207
  
```

```

CALL WHICHCSR
MOV SP,FSSTACK
SET4 #1$ ;TRAPS TO 4 GOTO 1$
READCSR
TYPE MSG027
SET NOERROR
ERROR +26 ;USE ERROR ROUTINE FOR PRINTOUT
RES4 ;RESET TRAPS TO 4 TO DEFAULT
TYPE MSG023 ;FIRST CSR WORD
RDOCT ;READ AN OCTAL NUMBER
FOP CSR ;PUT IN IN LOC 'CSR'
TYPE MSG024 ;2ND CSR WORD
RDOCT ;READ AN OCTAL NUMBER
POP CSR+2 ;PUT IN IN LOC 'CSR+2'
SET TWOCSRS
LOADCSR
CLR TWOCSRS
READCSR
TYPE MSG028
SET NOERROR
ERROR +26 ;USE FOR PRINTOUT - NOT AN ERROR
RETURN
1$: TYPE MSG025 ;THIS CSR DOES NOT EXIST
MOV FSSTACK,SP ;RESET TRAPS TO 4 TO DEFAULT
RES4
RETURN
  
```

7231 044520

FSCMD3: SUBST <<FS COMMAND 3 EXAMINE MEMORY>>
:*****
:SUBTEST FS COMMAND 3 EXAMINE MEMORY
:*****

7232 044520
7233 044540 012737 000002 002100

PUSH BANK,NOPAR,PARTHERE,4
MOV #2,NOPAR ;INDICATE PARITY ACTION

7234 044546
7235 044552 1\$: TYPE MSG029 ;EXAMINE MEMORY

TYPE MSG031 ;PHYSICAL ADDRESS (0-16777776)??

7236 044556 104413
7237 044560 013737 074434 002106

RDOCT ;READ OCTAL NUMBER ONTO STACK & \$SHIOCT
MOV \$SHIOCT,BANK ;PUT MSB'S IN BANK

7238 044566
7239 044570 000241
7240 044572 006100

POP RO ;PUT LSB'S IN RO
CLC
ROL RO

7241 044574 006137 002106
7242 044600 000241

ROL BANK
CLC
ROR RO

7243 044602 006000
7244 044604
7245 044614 062700 060000

IF BANK GT #167 THEN GOTO 1\$;CHECK FOR BANK TOO HIGH
ADD #FIRST,RO

7246 044620
7247 044626
7248 044634 012737 044706 002372

IF #BIT0 SET.IN RO THEN GOTO 1\$;CHECK FOR ODD ADDRESS
IF RO HI #LAST THEN COTO 1\$;CHECK FOR ADDRESS OVFR 16K

7249 044642
7250 044650
7251 044664

MOV #3\$,PARTHERE ;INCASE OF ABORTS
SET4 #4\$;TRAPS TO 4 GOTO 4\$

7252 044672 011001
7253 044674 104417

MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
SUPERVISOR ;ENTER SUPERVISOR MODE

7254 044676
7255 044704 000410
7256

MOV (RO),R1
KERNEL
TYPOCS R1 ;ENTER KERNEL MODE

7257 044706 3\$: TYPE MSG032 ;PARITY ABORT

BR EXCMD3

7258 044712 000405
7259

ADD #4,SP ;FIX STACK

7260 044714 062706 000004
7261 044720
7262 044724 000400

TYPE MSG033 ;TIMEOUT TRAP
BR EXCMD3

7263
7264 044726 104417

EXCMD3: KERNEL ;ENTER KERNEL MODE
POP 4,PARTHERE,NOPAR,BANK

7265 044730
7266 044750
7267 044762 060207

RES4 ;RESET TRAPS TO 4 TO DEFAULT
RETURN


```

7270 044764      FSCMD4: SUBST  <<FS  COMMAND 4  MODIFY MEMORY>>
:*****
:*SUBTEST      FS  COMMAND 4  MODIFY MEMORY
:*****
7271 044764      PUSH  BANK,NOPAR,PARHERE,4
7272 045004 012737 000003 002100  MOV  #3,NOPAR ;INDICATE PARITY ACTION
7273 045012      TYPE  MSG036 ;MODIFY MEMORY
7274 045016 1$:      TYPE  MSG031 ;PHYSICAL ADDRESS (0-1677776)??
7275 045022 104413  RDOCT ;READ OCTAL NUMBER ONTO STACK & $HIOCT
7276 045024 013737 074434 002106  MOV  $HIOCT,BANK ;PUT MSB'S IN BANK
7277 045032      POP   RO ;PUT LSB'S IN RO
7278 045034      CLC
7279 045036      ROL  RO
7280 045040 006137 002106  ROL  BANK
7281 045044      CLC
7282 045046 006000      ROR  RO
7283 045050      IF BANK GT #167 THEN GOTO 1$ ;CHECK FOR BANK TOO HIGH
7284 045060 062700 060000  ADD  #FIRST,RO
7285 045064      IF #BIT0 SET. IN RO THEN GOTO 1$ ;CHECK FOR ODD ADDRESS
7286 045072      IF RO HI #LAST THEN GOTO 1$ ;CHECK FOR ADDRESS OVER 16K
7287 045100 012737 045146 002372  MOV  #3$,PARHERE ;INCASE OF ABORTS
7288 045106      SFT4 #4$ ;TRAPS TO 4 GOTO 4$
7289 045114      MAP  BANK ;MAP SUPERVISOR SPACF (TEST AREA) TO BANK
7290 045130 104511  INVALIDATE
7291 045132      SUPERVISOR ;ENTER SUPERVISOR MODE
7292 045140 011001  MOV  (RO),R1
7293      ;GETTING HERE MEANS WE GOT LUCKY - NO TRAPS
7294 045142 104417  KERNEL ;ENTER KERNEL MODE
7295 045144 000410  BR   5$
7296
7297 045146 3$:      TYPE  MSG032 ;PARITY ABORT
7298 045152 000431  BR   EXCMD4 ;EXIT
7299
7300 045154 062706 000004 4$:      ADD  #4,SP ;FIX STACK
7301 045160      TYPE  MSG033 ;TIMEOUT TRAP
7302 045164 000424  BR   EXCMD4 ;EXIT
7303
7304 045166 5$:      TYPE  MSG037 ;OLD DATA WAS
7305 045172      TYPOCS R1 ;PRINT IT
7306 045200      TYPE  MSG039 ;INPUT NEW DATA
7307 045204 104413  RDOCT ;READ OCTAL NUMBER ONTO THE STACK
7308 045206      POP   R1 ;GET NEW NUMBER
7309 045210      SUPERVISOR ;ENTER SUPERVISOR MODE
7310 045216 010110  MOV  R1,(RO) ;PUT IT IN MEMORY
7311 045220 011001  MOV  (RO),R1 ;READ IT AGAIN
7312 045222 104417  KERNEL ;ENTER KERNEL MODE
7313 045224      TYPE  MSG038 ;DATA IS NOW
7314 045230      TYPOCS R1 ;PRINT IT
7315
7316 045236 104417  EXCMD4: KERNEL ;ENTER KERNEL MODE
7317 045240      POP  4,PARHERE,NOPAR,BANK
7318 045260      RES4 ;RESET TRAPS TO 4 TO DEFAULT
7319 045272 000207  RETURN
  
```

```

7322 045274          FSCMD5: SUBTST <<FS  COMMAND 5  SELECT BANK,MARGIN, & PATTERN>>
:*****
:*SUBTEST          FS  COMMAND 5  SELECT BANK,MARGIN, & PATTERN
:*****
7323 045274          PUSH  BANK,PATTERN,MARGIN,CSRFIRST,PCBUMP,TKVEC,TKVEC+2
7324 045330 013737 002112 002376  MOV  MARGIN,OLDMARGIN
7325 045336 010637 002374          MOV  SP,FSSTACK ;SAVE LAST GOOD STACK POINTER
7326 045342          TYPE  MSG040 ;SELECT BANK, MARGIN, & PATTERN TEST
7327 045346          1$: TYPE  MSG030 ;BANK(0-167)?
7328 045352 104413          RDOCT ;READ AN OCTAL NUMBER ONTO THE STACK
7329 045354          POP  BANK ;PUT IT IN BANK
7330 045360          IF BANK GT #167 THEN GOTO 1$ ;CHECK FOR BANK TO HIGH
7331
7332 045370 013701 002106          MOV  BANK,R1
7333 045374 070127 000006          MUL  #6,R1
7334 045400          IF CPUBIT OFF.IN CONFIG(R1)
7335 045410          TYPE  MSG041 ;BANK NOT ACCESSABLE
7336 045414          GOTO 1$
7337 045416          END ;OF IF
7338
7339 045416          2$: TYPE  MSG042 ;PATTERN(0-37)?
7340 045422 104413          RDOCT ;READ AN OCTAL NUMBER ONTO THE STACK
7341 045424          POP  PATTERN ;PUT IT IN PATTERN
7342 045430          IF PATTERN GT #37 THEN GOTO 2$ ;CHECK FOR PATTERN TO HIGH
7343 045440          IF PATTERN EQ #0
7344 045446          TYPE  MSG043 ;PATTERN 0 DATA IS?
7345 045452 104413          RDOCT ;READ AN OCTAL NUMBER ONTO THE STACK
7346 045454          POP  R2 ;PUT IT IN R2
7347 045456          END ;OF IF
7348
7349 045456          CMD5A: TYPE  MSG044 ;MARGIN(0,2,3,4,5)?
7350 045462 104413          RDOCT ;READ AN OCTAL NUMBER ONTO THE STACK
7351 045464          POP  MARGIN ;PUT IN IN MARGIN
7352 045470          IF MARGIN GT #5 OR MARGIN EQ #1
7353 045510          GOTO CMD5A
7354 045512          END ;OF IF
7355 045512          IF MARGIN NE #0 AND #SW11 SET.IN @SWR
7356 045530          TYPE  MSG045 ;MARGINS INHIB TED BY SW11
7357 045534          GOTO CMD5A
7358 045536          END ;OF IF MARGIN
7359
7360 045536          MAP  BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
7361 045552 104511          INVALIDATE
7362 045554 004737 042422          CALL  EXBANK ;SET NEW MARGINS
7363 045560          IF RRFLAG IS TRUE
7364 045566          TYPE  MSG049 ;BANK REQUIRES RELOCATION
7365 045572          GOTO CMD5C
7366 045574          END ;OF IF RRFLAG
7367 045574 004737 043300          CALL  COREHISTORY
7368 045600          TYPE  MSG046 ;TO ESCAPE TYPE ANY KEY.
7369 045604 012737 046052 000060          MOV  #CMD5C,TKVEC
7370 045612 012737 000340 000062          MOV  #340,TKVEC+2
7371 045620 017700 135150          MOV  @STKB,R0
7372 045624 042737 000200 177776          BIC  #BIT7,PSW ;KILL ANY OLD INTERRUPT
7373 045632 052777 000100 135132          BIS  #BIT6,@STKS ;LOWER CPU PRIORITY TO 140
7374
7375 045640 013700 002112          MOV  MARGIN,R0 ;ENABLE KEYBOARD INTERRUPTS
;SET MARGINS
  
```

```

7376 045644 006300 ASL RO ;SET MARGINS
7377
7378 045646 010037 177750 MOV RO,MAINT
7379
7380 045652 SET HEADER,MUT
7381 045666 005037 002362 CMD5B: CLR PASFLG
7382 045672 012737 060000 002336 MOV #FIRST,CSRFIRST
7383 045700 IF #SWO SET.IN @SWR
7384 045710 104470 ECCDIS ;DISABLE ERROR CORRECTION
7385 045712 ELSE
7386 045714 104502 CLRCSR ;CLEAR MK11 CSRS
7387 045716 END ;OF IF
7388 045716 012737 000002 002100 MOV #2,NOPAR ;PARITY ACTION
7389 045724 012737 000002 002406 MOV #2,PCBUMP ;TRAPS ADD 2 TO PC
7390 045732 013700 002120 MOV PATTERN,RO
7391 045736 006300 ASL RO
7392 045740 004770 045752 CALL @FSPAT(RO)
7393 045744 005037 002100 CLR NOPAR
7394 045750 000746 BR CMD5B ;LOOP TILL KEYBOARD INTERRUPT
7395
7396 045752 021704 FSPAT: MT0000 ;<1 SEC DATA PATTERN TEST
7397 045754 021740 MT0001 ;<1 SEC ADDRESS TEST
7398 045756 022000 MT0002 ;<1 SEC COMPLEMENT ADDRESS TEST
7399 045760 022050 MT0003 ; 1 SEC 3 XOR 9 WORST CASE NOISE TEST
7400 045762 022216 MT0004 ; 1 SEC ROTATING ZEROS TEST
7401 045764 022300 MT0005 ; 1 SEC ROTATING ONES TEST
7402 045766 022360 MT0006 ;<1 SEC INITIAL DATA TEST
7403 045770 022414 MT0007 ;<1 SEC ADDRESS BIT TEST
7404 045772 022456 MT0010 ;<1 SEC BYTE ADDRESSING TEST
7405 045774 022512 MT0011 ;<2 SEC CREATE SINGLE BIT ERROR TEST
7406 045776 022570 MT0012 ;<1 SEC WRITE BYTE CLEARS SBE TEST
7407 046000 022646 MT0013 ; 1 SEC CREATE DOUBLE BIT ERROR TEST
7408 046002 022722 MT0014 ; 1 SEC WRITE INHIBIT DURING DATIP WITH DBE
7409 046004 023000 MT0015 ; 1 SEC WRITE INHIBIT OF BYTE WITH DBE
7410 046006 023056 MT0016 ;<1 SEC WRITE INHIBIT OF WORD WITH DBE
7411 046010 023134 MT0017 ;<1 SEC HOLDING 1'S & 0'S TEST
7412 046012 023156 MT0020 ;<1 SEC MARCHING 1'S & 0'S IN CHECK BITS
7413 046014 023612 MT0021 ; 1 SEC MARCHING 0'S & 1'S TEST
7414 046016 023734 MT0022 ;10 SEC REFRESH & SHIFTING DIAGONAL TEST
7415 046020 023766 MT0023 ;10 SEC SHIFTING DIAGONAL TEST
7416 046022 024032 MT0024 ;20 SEC FAST GALLOPING PATTERN TEST
7417 046024 024172 MT0025 ;<1 SEC INTERRUPT ENABLE TEST
7418 046026 024240 MT0026 ;<1 SEC RANDOM DATA TEST
7419 046030 024370 MT0027 ; 1 SEC UNIQUE BANK TEST
7420 046032 024754 MT0030 ; 1 SEC FLUSH OUT DBE'S TEST
7421 046034 025214 MT0031 ; 3 SEC SOB-A-LONG TEST
7422 046036 025772 MT0999;MT0032
7423 046040 025340 MT0033 ;<1 SEC WRITE RECOVERY TEST
7424 046042 025530 MT0034 ;35 SEC BRANCH GOBBLE TEST
7425 046044 025772 MT0999;MT0035
7426 046046 025772 MT0999;MT0036
7427 046050 025772 MT0999;MT0037
7428
7429 046052 013706 002374 CMD5C: MOV FSSTACK,SP ;RECOVER OLD STACK POINTER
7430 046056 042777 000100 134706 BIC #BIT6,@STKS
7431 046064 POP TKVEC+2,TKVEC
7432 046074 117700 134674 MOV @STKB,R0 ;GET CHARACTER TO GET RID OF FLAG
  
```

```
7433 046100          POP      PCBUMP,CSRFIRST,MARGIN
7434 046114 004737 043300 CALL    COREHISTORY          ;RESTORE OLD MARGINS
7435 046120          POP      PATTERN,BANK
7436 046130          MAP      BANK          ;REMAP OLD BANK
7437 046144 004737 042422 CALL    EXBANK
7438 046150 000207          RETURN
7439
7440 046152          FSCMD6: SUBTST <<FS  COMMAND 6  TYPE CONFIGURATION MAP>>
:*****
:*SUBTEST          FS  COMMAND 6  TYPE CONFIGURATION MAP
:*****
7441 046152 004737 035402          CALL    PCONFIG
7442 046156 000207          RETURN
7443
```

```

7447 046160 FSCMD7: SUBTST <<FS COMMAND 7 BATTERY BACKUP TEST>>
:*****
:*SUBTEST FS COMMAND 7 BATTERY BACKUP TEST
:*****
7448 046160 PUSH BANK,PATTERN,MARGIN,CSRNO,TKVEC,TKVEC+2
7449 046210 SET FS7FLAG
7450 046216 IF #SWO SET.IN @SWR
7451 046226 104470 ECCDIS ;DISABLE ERROR CORRECTION
7452 046230 ELSE
7453 046232 104502 CLRCSR ;CLEAR MK11 CSRS
7454 046234 END ;OF IF
7455 046234 TYPE MSG050 ;BATTERY BACKUP TEST
7456 ;WRITING & CHECKING ADDRESS PATTERN AS BACKGROUND
7457 046240 004737 024370 CALL MT0027 ;CREATE & CHECK BACKGROUND
7458 046244 012737 000012 002434 MOV #1^,TIME
7459 046252 TYPE MSG052 ;REMOVE SYSTEM POWER FOR
7460 046256 TYPDEC TIME
7461 046264 TYPE MSG053 ;SECONDS MAX!
7462 046270 TYPE MSG046 ;TO ESCAPE TYPE ANY KEY
7463 046274 012737 046336 000060 MOV #CMD7A,TKVEC
7464 046302 012737 000340 000062 MOV #340,TKVEC+2
7465 046310 017700 134460 MOV @STKB,R0 ;KILL ANY OLD INTERRUPT
7466 046314 042737 000200 177776 BIC #BIT7,PSW ;LOWER CPU PRIORITY TO 140
7467 046322 052777 000100 134442 BIS #BIT6,@STKS ;ENABLE KEYBOARD INTERRUPTS
7468 046330 010637 002374 MOV SP,FSSTACK
7469
7470 046334 000001 WAIT
7471
7472 046336 013706 002374 CMD7A: MOV FSSTACK,SP ;RECOVER OLD STACK POINTER
7473 046342 042777 000100 134422 BIC #BIT6,@STKS
7474 046350 POP TKVEC+2,TKVEC
7475 046360 117700 134410 MOVB @STKB,R0 ;GET CHARACTER TO GET RID OF FLAG
7476 046364 TYPE MSG054 ;NOW STARTING READ TEST OF MEMORY BANKS
7477 046370 FOR BANK := #0 TO #167
7478 046374 004737 042422 CALL EXBANK
7479 046400 IF ACFLAG IS TRUE AND RRFLAG IS FALSE
7480 046414 104511 INVALIDATE
7481 046416 LET R2 := BANK
7482 046422 012700 060000 MOV #FIRST,R0
7483 046426 010004 MOV R0,R4
7484 046430 012701 040000 MOV #SIZE,R1
7485 046434 010103 MOV R1,R3
7486 046436 004737 026220 CALL SUPD03
7487 046442 END ;OF IF ACFLAG
7488 046442 END ;OF FOR BANK
7489 046456 TYPE MSG047 ;TEST COMPLETE
7490 046462 005037 002546 CLR FS7FLAG
7491 046466 POP CSRNO,MARGIN,PATTERN,BANK
7492 046506 000207 RETURN
7493
  
```

```

7496 046510      FSCMDB: SUBTST <<FS      COMMAND 8      SOB-A-LONG TEST>>
:*****
:*SUBTEST      FS      COMMAND 8      SOB-A-LONG TEST
:*****
7497 046510      PUSH      BANK,PATTERN,MARGIN,TKVEC,TKVEC+2,NOPAR
7498 046540 010637 002374      MOV      SP,FSSTACK      ;SAVE LAST GOOD STACK POINTER
7499 046544      TYPE      MSG055      ;SOB-A-LONG TEST
7500 046550      CMD8A: TYPE      MSG044      ;MARGIN(0,2,3,4,5)?
7501 046554 104413      RDOCT      ;READ AN OCTAL NUMBER ONTO THE STACK
7502 046556      POP      MARGIN      ;PUT IN IN MARGIN
7503 046562      IF MARGIN GT #5 OR MARGIN EQ #1
7504 046602      GOTO CMD8A
7505 046604      END ;OF IF
7506 046604      IF MARGIN NE #0 AND #SW11 SET.IN @SWR
7507 046622      TYPE      MSG045      ;MARGINS INHIBITED BY SW11
7508 046626      GOTO CMD8A
7509 046630      END ;OF IF MARGIN
7510
7511 046630      IF #SW0 SET.IN @SWR
7512 046640 104470      ECCDIS      ;DISABLE ERROR CORRECTION
7513 046642      ELSE
7514 046644 1045Q?      CLRCSR      ;CLEAR MK11 CSRS
7515 046646      END ;OF IF
7516 046646      TYPE      MSG056      ;BELL = EACH PASS COMPLETE
7517
7518 046652      TYPE      MSG046      ;TO ESCAPE TYPE ANY KEY!
7519 046656 012737 047014 000060      MOV      #CMD8C,TKVEC
7520 046664 012737 000340 000062      MOV      #340,TKVEC+2
7521 046672 017700 134076      MOV      @STKB,RO      ;KILL ANY OLD INTERRUPT
7522 046676 042737 000200 177776      BIC      #BIT7,PSW      ;LOWER CPU PRIORITY TO 140
7523 046704 052777 000100 134060      BIS      #BIT6,@STKS      ;ENABLE KEYBOARD INTERRUPTS
7524
7525 046712 013700 002112      MOV      MARGIN,RO      ;SET MARGINS
7526 046716 006300      ASL      RO      ;SET MARGINS
7527 046720 010037 177750      MOV      RO,MAINT
7528
7529 046724      SET      HEADER,MUT
7530
7531 046740      CMD8B: FOR BANK := #0 TO #167
7532 046744 004737 042422      CALL EXBANK
7533 046750      IF ACFLAG IS TRUE AND RRFLAG IS FALSE
7534 046764 104511      INVALIDATE
7535 046766 004737 025214      CALL MTO031
7536 046772      END ;OF IF ACFLAG
7537 046772      END ;OF FOR BANK
7538 047006      TYPE      $BELL      ;RING BELL
7539 047012      GOTO      CMD8B
7540
7541 047014 013706 002374      CMD8C: MOV      FSSTACK,SP      ;RECOVER OLD STACK POINTER
7542 047020 042777 000100 133744      BIC      #BIT6,@STKS
7543 047026 117700 133742      MOVVB   @STKB,RO      ;READ CHAR TO KILL FLAG
7544 047032      POP      NOPAR,TKVEC+2,TKVEC,MARGIN,PATTERN,BANK
7545 047062      MAP      BANK      ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
7546 047076 004737 042422      CALL      EXBANK
7547 047102 000207      RETURN

```

```

7550 047104 FSCMD9: SUBTST <<FS COMMAND 9 SUPER TIGHT SCOPE LOOP>>
:*****
:*SUBTEST FS COMMAND 9 SUPER TIGHT SCOPE LOOP
:*****
7551 047104 PUSH BANK,MARGIN,TKVEC,TKVEC+2,NOPAR
7552 047130 010637 002374 MOV SP,FSSTACK ;SAVE LAST GOOD STACK
7553 047134 TYPE MSG059 ;SUPER TIGHT SCOPE LOOP
7554 047140 IF #SW0 SET.IN @SWR
7555 047150 104470 ECCDIS ;DISABLE ERROR CORRECTION
7556 047152 ELSE
7557 047154 104502 CLRCSR ;CLEAR MK11 CSRS
7558 047156 END ;OF IF
7559 047156 1$: TYPE MSG031 ;PHYSICAL ADDRESS (0-1677776)??
7560 047162 104413 RDOCT ;READ OCTAL NUMBER ONTO STACK & $HIOCT
7561 047164 013737 074434 002106 MOV $HIOCT,BANK ;PUT MSB'S IN BANK
7562 047172 POP RO ;PUT LSB'S IN RO
7563 047174 000241 CLC
7564 047176 006100 ROL RO
7565 047200 006137 002106 ROL BANK
7566 047204 000241 CLC
7567 047206 006000 ROR RO
7568 047210 IF BANK GT #167 THEN GOTO 1$ ;CHECK FOR BANK TOO HIGH
7569 047220 062700 060000 ADD #FIRST,RO
7570 047224 IF #BIT0 SET.IN RO THEN GOTO 1$ ;CHECK FOR ODD ADDRESS
7571 047232 IF RO HI #LAST THEN GOTO 1$ ;CHECK FOR ADDRESS OVER 16K
7572
7573 047240 CMD9A: TYPE MSG044 ;MARGIN(0,2,3,4,5)?
7574 047244 104413 RDOCT ;READ AN OCTAL NUMBER ONTO THE STACK
7575 047246 POP MARGIN ;PUT IN IN MARGIN
7576 047252 IF MARGIN GT #5 OR MARGIN EQ #1
7577 047272 GOTO CMD9A
7578 047274 END ;OF IF
7579 047274 IF MARGIN NE #0 AND #SW11 SET.IN @SWR
7580 047312 TYPE MSG045 ;MARGINS INHIBITED BY SW11
7581 047316 GOTO CMD9A
7582 047320 END ;OF IF MARGIN
7583
7584 047320 012737 000003 002100 MOV #3,NOPAR ;PARITY ACTION
7585 047326 012737 047444 002372 MOV #CMD9LOOP,PARHERE
7586 047334 SET4 #CMD9B ;TRAPS TO 4 GOTO CMD9B
7587 047342 MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
7588 047356 104511 INVALIDATE
7589 047360 TYPE MSG060 ;SWR ----> MEM, MEM ----> DISPLAY
7590
7591 047364 TYPE MSG046 ;TO ESCAPE TYPE ANY KEY!
7592 047370 012737 047464 000060 MOV #CMD9C,TKVEC
7593 047376 012737 000340 000062 MOV #340,TKVEC+2
7594 047404 017701 133364 MOV @STKB,R1 ;KILL ANY OLD INTERRUPT
7595 047410 042737 000200 177776 BIC #BIT7,PSW ;LOWER CPU PRIORITY TO 140
7596 047416 052777 000100 133346 BIS #BIT6,@STKS ;ENABLE KEYBOARD INTERRUPTS
7597
7598 047424 013701 002112 MOV MARGIN,R1 ;SET MARGINS
7599 047430 006301 ASL R1 ;SET MARGINS
7600 047432 010137 177750 MOV R1,MAINT
7601
7602 047436 SUPERVISOR ;ENTER SUPERVISOR MODE
7603 047444 017710 133316 CMD9LOOP:MOV @SWR,(RO) ;WRITE SWITCH REGISTER INTO MEMOR
  
```

```

7604 047450 011077 133314      MOV      (R0),@DISPLAY      ;READ MEMORY INTO DISPLAY REGISTER
7605 047454 000773              BR          CMD9LOOP        ;LOOP TILL KEYBOARD INTERRUPT
7606
7607 047456 012716 047444      CMD9B:  MOV      #CMD9LOOP,(SP)
7608 047462 000002              RTI
7609
7610 047464 013706 002374      CMD9C:  MOV      FSSTACK,SP      ;RECOVER OLD STACK POINTER
7611 047470 042777 000100 133274 BIC      #BIT6,@$TKS
7612 047476 117700 133272      MOV      @TKB,R0          ;READ CHAR TO KILL FLAG
7613 047502              POP      NOPAR,TKVEC+2,TKVEC,MARGIN,BANK
7614 047526              MAP      BANK              ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
7615 047542 004737 042422      CALL    EXBANK
7616 047546 000207              RETURN
7617
7618 047550
  
```

```

FCMD10: SUBTST <<FS COMMAND 10 ERROR SUMMARY>>
:*****
:*SUBTEST FS COMMAND 10 ERROR SUMMARY
:*****
  
```

```

7619 047550      PUSH     R0,R2,R3,BANK
7620 047562      TYPDEC  $ERTTL
7621 047570      TYPE   MSG079          ;ERROR(S) DETECTED
7622 047574      IF $ERTTL NE #0
7623 047602 005037 002424      CLR     SUCCESS
7624 047606      FOR BANK := #0 TO #167
7625 047612 013703 002106      MOV     BANK,R3
7626 047616 070327 000006      MUL    #6,R3
7627 047622 062703 000005      ADD    #5,R3
7628 047626      IFB CONFIG(R3) NE #0
7629 047634      IF SUCCESS IS FALSE
7630 047642      TYPE   MSG076          ;BANK ERRORS
7631 047646      SET SUCCESS
7632 047654      END ;OF IF SUCCESS
7633 047654      TYPCS  BANK,3
7634 047664 116300 003016      MOV     CONFIG(R3),R0
7635 047670 042700 177400      BIC    #^C377,R0
7636 047674      TYPDEC  R0
7637 047700      TYPE   $CRLF
7638 047704      END ;OF IFB CONFIG(R3)
7639 047704      END ;OF FOR BANK
7640 047720      END ;OF IF $ERTTL
7641 047720      POP    BANK,R3,R2,R0
7642 047732 000207      RETURN
  
```



```

7645 047734          FCMD11: SUBTST <<FS      COMMAND 11      REFRESH TEST>>
:*****
: *SUBTEST          FS      COMMAND 11      REFRESH TEST
:*****
7646 047734          PUSH   BANK,PATTERN,MARGIN,TKVEC,TKVEC+2,NOPAR
7647 047764 010637 002374  MOV    SP,FSSTACK ;SAVE LAST GOOD STACK POINTER
7648 047770          TYPE   MSG073 ;REFRESH TEST
7649 047774          CMD11A: TYPE  MSG044 ;MARGIN(C,2,3,4,S)?
7650 050000 104413  RDOCT ;READ AN OCTAL NUMBER ONTO THE STACK
7651 050002          POP    MARGIN ;PUT IN IN MARGIN
7652 050006          IF MARGIN GT #5 OR MARGIN EQ #1
7653 050026          GOTO  CMD11A
7654 050030          END ;OF IF
7655 050030          IF MARGIN NE #0 AND #SW11 SET.IN @SWR
7656 050046          TYPE   MSG045 ;MARGINS INHIBITED BY SW11
7657 050052          GOTO  CMD11A
7658 050054          END ;OF IF MARGIN
7659
7660 050054          IF #SW0 SET.IN @SWR
7661 050064 104470  ECCDIS ;DISABLE ERROR CORRECTION
7662 050066          ELSE
7663 050070 104502  CLRCSR ;CLEAR MK11 CSRS
7664 050072          END ;OF IF
7665 050072          TYPE   MSG056 ;BELL = EACH PASS COMPLETE
7666
7667 050076          TYPE   MSG046 ;TO ESCAPE TYPE ANY KEY!
7668 050102 012737 050240 000060  MOV    #CMD11C,TKVEC
7669 050110 012737 000340 000062  MOV    #340,TKVEC+2
7670 050116 017700 132652          MOV    @STKB,RO ;KILL ANY OLD INTERRUPT
7671 050122 042737 000200 177776  BIC    #BIT7,PSW ;LOWER CPU PRIORITY TO 140
7672 050130 052777 000100 132634  BIS    #BIT6,@STKS ;ENABLE KEYBOARD INTERRUPTS
7673
7674 050136 013700 002112          MOV    MARGIN,RO ;SET MARGINS
7675 050142 006300          ASL    RO ;SET MARGINS
7676 050144 010037 177750          MOV    RO,MAINT
7677
7678 050150          SET    HEADER,MUT
7679
7680 050164          CMD11B: FOR BANK := #0 TO #167
7681 050170 004737 042422          CALL  EXBANK
7682 050174          IF ACFLAG IS TRUE AND RRFLAG IS FALSE
7683 050210 104511          INVALIDATE
7684 050212 004737 023734          CALL  MTO022
7685 050216          END ;OF IF ACFLAG
7686 050216          END ;OF FOR BANK
7687 050232          TYPE   $BELL ;RING BELL
7688 050236          GOTO  CMD11B
7689
7690 050240 013706 002374          CMD11C: MOV    FSSTACK,SP ;RECOVER OLD STACK POINTER
7691 050244 042777 000100 132520  BIC    #BIT6,@STKS
7692 050252 117700 132516          MOV    @STKB,RO ;READ CHAR TO KILL FLAG
7693 050256          POP    NOPAR,TKVEC+2,TKVEC,MARGIN,PATTERN,BANK
7694 050306          MAP    BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
7695 050322 004737 042422          CALL  EXBANK
7696 050326 000207          RETURN
7697

```

```
7700 050330 FCMD12: SUBTST <<FS COMMAND 12 SET FILL COUNT>>
:*****
:*SUBTEST FS COMMAND 12 SET FILL COUNT
:*****
7701 050330 PUSH RO
7702 050332 TYPE MSG085 ;FILL COUNT(OCTAL)?
7703 050336 104413 RDOCT
7704 050340 POP RO
7705 050342 042700 177760 BIC #^C17,RO
7706 050346 110037 002451 MOVB RO,$FILLS
7707 050352 POP RO
7708 050354 000207 RETURN
7709
7710 050356 FCMD13: SUBTST <<FS COMMAND 13 ENTER KAMIKAZE MODE>>
:*****
:*SUBTEST FS COMMAND 13 ENTER KAMIKAZE MODE
:*****
7711 050356 TYPE MSG101 ;ENTERING KAMIKAZE MODE
7712 050362 SET KAMIKAZE,SKIPKAMI
7713 050376 000207 RETURN
7714
7715 050400 FCMD14: SUBTST <<FS COMMAND 14 EXIT KAMIKAZE MODE>>
:*****
:*SUBTEST FS COMMAND 14 EXIT KAMIKAZE MODE
:*****
7716 050400 TYPE MSG102 ;LEAVING KAMIKAZE MODE
7717 050404 005037 002010 CLR KAMIKAZE
7718 050410 SET SKIPKAMI
7719 050416 000207 RETURN
7720
7721 050420 FCMD15: SUBTST <<FS COMMAND 15 TURN CACHE OFF>>
:*****
:*SUBTEST FS COMMAND 15 TURN CACHE OFF
:*****
7722 050420 TYPE MSG106 ;CACHE IS OFF
7723 050424 012737 001415 002700 MOV #BIT0!BIT2!BIT3!BIT8!BIT9,CACHK
7724 050432 104424 CACHOFF ;TURN CACHE OFF
7725 050434 000207 RETURN
7726
7727 050436 FCMD16: SUBTST <<FS COMMAND 16 TURN CACHE ON>>
:*****
:*SUBTEST FS COMMAND 16 TURN CACHE ON
:*****
7728 050436 TYPE MSG107 ;CACHE IS ON (EXCEPT DURING ACTUAL PATTERNS)
7729 050442 012737 000001 002700 MOV #BIT0,CACHK
7730 050450 104423 CACHON ;TURN CACHE ON
7731 050452 000207 RETURN
7732
7733 050454 FCMD17: SUBTST <<FS COMMAND 17 RUN ONLY MULTIPOINT TESTS>>
:*****
:*SUBTEST FS COMMAND 17 RUN ONLY MULTIPOINT TESTS
:*****
7734 050454 TYPE MSG108 ;ONLY MULTIPOINT TESTS WILL BE RUN
7735 050460 SET MULTIONLY
7736 050466 000207 RETURN
```

```

7739 050470          FCMD18: SUBTST <<FS  COMMAND 18  RESUME RUNNING BOTH SINGLE & MULTIPORT TESTS>>
:*****
:*SUBTEST          FS  COMMAND 18  RESUME RUNNING BOTH SINGLE & MULTIPORT TESTS
:*****
          TYPE  MSG109          ;BOTH SINGLE & MULTIPORT TESTS WILL BE RUN
7741 050474  005037  002004  CLR  MULTIONLY
7742 050500  000207          RETURN
7743
7744 050502          FCMD19: SUBTST <<FS  COMMAND 19  TEST ONLY SELECTED BANKS>>
:*****
:*SUBTEST          FS  COMMAND 19  TEST ONLY SELECTED BANKS
:*****
          TYPE  MSG105          ;ENTER BANKS IN OCTAL - USE NUMBER OUTSIDE RANGE TO TERMINAT
7745 050502          CALL  CMD20A          ;ERASE OLD SELECTIONS
7746 050506  004737  050576  BEGIN CMD19LOOP
7747 050512          REPEAT
7748 050512          TYPE  MSG030          ;BANK(0-167)?
7749 050512          RDOCT          ;READ AN OCTAL NUMBER ONTO THE STACK
7750 050516  104413          POP R1          ;PUT IT IN R1
7751 050520          IF R1 GT #167 OR R1 LT #0
7752 050522          LEAVE CMD19LOOP
7753 050534          END ;OF IF R1
7754 050536          MUL #6,R1
7755 050536  070127  000006  BIS #BIT14,CONFIG+2(R1)
7756 050542  052761  040000  003020  END ;OF REPEAT
7757 050550          END CMD20LOOP
7758 050552          TYPE  MSG110          ;ONLY SELECTED BANKS WILL BE TESTED
7759 050552          SET  SELONLY
7760 050556          RETURN
7761 050564  000207
7762
7763 050566          FCMD20: SUBTST <<FS  COMMAND 20  RESUME TESTING ALL BANKS>>
:*****
:*SUBTEST          FS  COMMAND 20  RESUME TESTING ALL BANKS
:*****
          TYPE  MSG111          ;ALL BANKS WILL BE TESTED
7764 050566          CLR  SELONLY
7765 050572  005037  002002
7766
7767          ;ENTRY POINT FROM CMD19
7768 050576  CMD20A: FOR R1 := #0 TO #167*3*2 BY #6
7769 050600  042761  040000  003020  BIC #BIT14,CONFIG+2(R1)          ;DESELECT BANK
7770 050606  042761  020000  003020  BIC #BIT13,CONFIG+2(R1)          ;INVALIDATE BACKGROUND PATTERN
7771 050614          END ;OF FOR R1
7772 050626  000207          RETURN
    
```

7775 050630
 7776 050630 013700 002334
 7777 050634 122700 000200
 7778 050640 001003
 7779 050642 005037 002256
 7780 050646 000207
 7781
 7782 050650
 7783 050654 104413
 7784 050656
 7785 050660 020027 000007
 7786 050664 101371
 7787 050666 012701 177774
 7788 050672 005200
 7789 050674 062701 000004
 7790 050700 077003
 7791 050702 010137 002256
 7792 050706 000207
 7793

```

WHICHCSR:SUBTST <<SUBR DETERMINE CORRECT CSR>>
:*****
:SUBTEST SUBR DETERMINE CORRECT CSR
:*****
MOV MKCSRS,R0 ;GET CSR'S FLAG
CMPB #BIT7,R0 ;CSR 0?
BNE 1$ ;NO - SKIP
CLR CSRNO ;YES - SET IT UP
RETURN

1$: TYPE MSG022 ;WHICH CSR(0-7)
RDOCT ;GET OCTAL NUMBER
POP R0 ;PUT IN R0
CMP R0,#7 ;CHECK LIMIT
BHI 1$ ;IF BAD LOOP TILL HE TYPES IT RIGHT
MOV #-4,R1
INC R0
2$: ADD #4,R1
SOB R0,2$
MOV R1,CSRNO
RETURN
  
```

```

1          .TITLE  CEMKABO 1170 MAIN MEMORY DIAG 2
2          .IDENT  /X01.60/
3          .SBTTL  MULTIPROCESSOR SLAVE DISPATCHER
4 050710   TASKRET:IF #MASTER NE CPUBIT
5 050720   BR      TASKDO
6 050722   ELSE
7 050724   RETURN
8 050726   END; OF IF #MASTER
9
10 050726 104424  TASKDO: CACHOFF          ;TURN CACHE OFF
11 050730   MAP      #0          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
12 050744   SET      R0
13 050750   FOR R1 := #0 TO #6 BY #2
14 050752   IF R0 EQ ONES
15 050760     IF NOIIST IS TRUE
16 050766 013702 177764   MOV      SYSTID,R2
17 050772     ELSE
18 050774 017702 131736   MOV      @IISTACR,R2
19 051000 072227 177770   ASH     #-8.,R2
20 051004 042702 177774   BIC     #^C3,R2
21 051010     END ;OF IF NOIIST
22 051010     SUPERVISOR          ;ENTER SUPERVISOR MODE
23 051016     IF FIRST+PORTDIR(R1) EQ R2 THEN LET R0 := R1
24 051026 104417     KERNEL          ;ENTER KERNEL MODE
25 051030     END ;OF IF R0
26 051030   END ;OF FOR R1
27 051042   IF R0 EQ ONES
28 051050     FATAL 41
29 051056   END ;OF IF R0
30 051056   SUPERVISOR          ;ENTER SUPERVISOR MODE
31 051064 005760 062616 1$: TST     FIRST+TASK(R0)          ;WAIT FOR COMMAND
32 051070 003775   BLE     1$
33 051072 013737 062676 002676   MOV     FIRST+MDISPLAY,MDISPLAY
34 051100 013777 002676 131662   MOV     MDISPLAY,@DISPLAY
35 051106 116001 062616   MOVB   FIRST+TASK(R0),R1          ;GET COMMAND
36 051112 104417   KERNEL          ;ENTER KERNEL MODE
37 051114   PUSH    R0
38 051116   CASE    R1
39 051126 051234   TASK00          ;0 IS NOT A COMMAND
40 051130 051236   TASK01          ;MOVE PROGRAM TO BANK
41 051132 051330   TASK02          ;WRITE ONLY PATTERN IN HI BYTE
42 051134 051430   TASK03          ;READ ONLY PATTERN IN HI BYTE
43 051136 051664   TASK04          ;EXECUTION CONTENTION TEST
44 051140 051774   TASK05          ;PORT ARBITRATION SYMMETRY TEST
45 051142 052300   TASK06          ;STOP PROGRAM
46 051144 052326   TASK07          ;WRITE ONLY ADDRESS PATTERN
47 051146 052336   TASK10          ;READ ONLY ADDRESS PATTERN
48 051150 052536   TASK11          ;ASYNCHRONOUS ADDRESS UNIQUENESS TEST
49 051152 052644   TASK12          ;SKEWED UP ADDRESS TEST
50 051154 052726   TASK13          ;SETUP FOR ASRB TEST
51 051156 053276   TASK14          ;RESET FROM ASRB TEST
52 051160 053310   TASK15          ;RUN CSR TESTS
53 051162 053316   TASK16          ;SET MARGIN 6, CPU HAS I/O PRIORITY
54 051164 053334   TASK17          ;CREATE STALE DATA TEST
55 051166 053422   TASK20          ;CACHE FLUSH TEST
56 051170   END ;OF CASE R1
57 051176   POP     R0
    
```

MULTIPROCESSOR SLAVE DISPATCHER

58 051200
59 051214
60 051222 052760 100000 062616
61 051230 104417
62 051232 000626
63 051234 000207

MAP #0
SUPERVISOR
BIS #BIT15, FIRST+TASK(RO)
KERNEL
BR TASKRET
TASK00: RETURN

;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
;ENTER SUPERVISOR MODE
;INDICATE DONE
;ENTER KERNEL MODE

66 051236

TASK01: SUBTST <<MOVE PROGRAM TO NEW BANK>>

*SUBTEST MOVE PROGRAM TO NEW BANK

67 051236
68 051244 013700 062106
69 051250 104417
70 051252 004737 041456
71 051256 012737 002000 002706
72 051264
73 051270 013706 002706
74 051274
75 051300
76 051314 005037 002134
77 051320
78 051326 000207
79
80 051330

SUPERVISOR ;ENTER SUPERVISOR MODE
MOV FIRST+BANK,R0
KERNEL ;ENTER KERNEL MODE
CALL RELOC1
MOV #STACK,KSTACK
POP R1,R0 ;GET OLD RETURN & RO
MOV KSTACK,SP
PUSH RO,R1 ;PUT BACK RO & RETURN
MAP #0 ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
CLR RLFLAG
SET NOSCOPE ;NO SCOPE LOOPS ALLOWED IN MULTIPROCESSOR TESTS
RETURN

TASK02: SUBTST <<WRITE ONLY PATTERN IN HI BYTE>>

*SUBTEST WRITE ONLY PATTERN IN HI BYTE

81 051330
82 051336 116005 062617
83 051342 013737 062106 002106
84 051350 104417
85 051352
86 051360 012700 060000
87 051364 012701 040000
88 051370
89 051400 051530
90 051402 051534
91 051404 051542
92 051406 051550
93 051410 051556
94 051412 051564
95 051414
96 051422 005037 002502
97 051426 000207

SUPERVISOR ;ENTER SUPERVISOR MODE
MOVB FIRST+TASK+1(RO),R5
MOV FIRST+BANK,BANK
KERNEL ;ENTER KERNEL MODE
SET WRITEONLY
MOV #FIRST,R0
MOV #SIZE,R1
CASE R5
SLPAT0 ;ZEROS
SLPAT1 ;ONES
SLPAT2 ;125252
SLPAT3 ;52525
SLPAT4 ;377
SLPAT5 ;177400
END ;OF CASE R5
CLR WRITEONLY
RETURN

100 051430

TASK03: SUBTST <<READ ONLY PATTERN IN HI BYTE>>

 :*SUBTEST READ ONLY PATTERN IN HI BYTE

101 051430
 102 051436 116005 062617
 103 051442 013737 062106 002106
 104 051450 104417
 105 051452
 106 051460 012700 060000
 107 051464 012701 040000
 108 051470
 109 051500 051530
 110 051502 051534
 111 051504 051542
 112 051506 051550
 113 051510 051556
 114 051512 051564
 115 051514
 116 051522 005037 002504
 117 051526 000207
 118
 119 051530 005002
 120 051532 000416
 121 051534
 122 051540 000413
 123 051542 012702 125252
 124 051546 000410
 125 051550 012702 052525
 126 051554 000405
 127 051556 012702 000377
 128 051562 000402
 129 051564 012702 177400
 130 051570

SUPERVISOR ;ENTER SUPERVISOR MODE
 MOVB FIRST+TASK+1(R0),R5
 MOV FIRST+BANK,BANK
 KERNEL ;ENTER KERNEL MODE
 SET READONLY
 MOV #FIRST,R0
 MOV #SIZE,R1
 CASE R5
 SLPAT0 ;ZEROS
 SLPAT1 ;ONES
 SLPAT2 ;125252
 SLPAT3 ;52525
 SLPAT4 ;377
 SLPAT5 ;177400
 END ;OF CASE R5
 CLR READONLY
 RETURN

SLPAT0: CLR R2
 BR SLPAT
 SLPAT1: SET R2
 BR SLPAT
 SLPAT2: MOV #125252,R2
 BR SLPAT
 SLPAT3: MOV #52525,R2
 BR SLPAT
 SLPAT4: MOV #377,R2
 BR SLPAT
 SLPAT5: MOV #177400,R2
 SLPAT: SUBTST <<SLAVE PATTERNS>>

 :*SUBTEST SLAVE PATTERNS

131 051570
 132 051600 104502
 133 051602
 134 051610 012737 000207 177644
 135 051616 012737 177646 002360
 136 051624 004737 035204
 137 051630 104415
 138 051632
 139 051644
 140 051656 104416
 141 051660 104424
 142 051662 000207

CLEAR MARGIN,MAINT
 CLRCSR ;CLEAR MK11 CSRS
 BMOV MTP000
 MOV #207,UIPAR2 ;PUT RETURN INST AFTER WRITE ROUTINE
 MOV #UIPAR3,SUPDOADD
 CALL REGCOPY
 SAVREG
 IF WRITEONLY IS TRUE THEN \$CALL SUPD01
 IF READONLY IS TRUE THEN \$CALL SUPD03
 RESREG
 CACHOFF ;TURN CACHE OFF
 RETURN

145 051664
146 051664
147 051672 013737 062106 002106
148 051700 104417
149 C 1702 005060 002636
150 051706 012737 000037 002366
151 051714 012737 060000 002360
152 051722
153 051724 062700 002636
154 051730 004737 026220
155 051734 104424
156 051736
157 051752
158 051754
159 051762 016060 002636 062636
160 051770 104417
161 051772 000207

```
TASK04: SUBTST <<EXECUTION CONTENTION TEST>>  
:*****  
:*SUBTEST EXECUTION CONTENTION TEST  
:*****  
SUPERVISOR ;ENTER SUPERVISOR MODE  
MOV FIRST+BANK,BANK  
KERNEL ;ENTER KERNEL MODE  
CLR PTYBUF(RO)  
MOV #37,REALPAT  
MOV #FIRST,SUPDOADD  
PUSH RO  
ADD #PTYBUF,RO ;RO - PTYBUF + INDEX FOR CPU  
CALL SUPDO3  
CACHOFF ;TURN CACHE OFF  
MAP #0 ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0  
POP RO  
SUPERVISOR ;ENTER SUPERVISOR MODE  
MOV PTYBUF(RO),FIRST+PTYBUF(RO)  
KERNEL ;ENTER KERNEL MODE  
RETURN
```


119 052300
 220 052300 012706 000700
 221 052304 042737 001001 177572
 222 052312 005037 002676
 223 052316 005077 130446
 224 052322 000137 011720
 225
 226 052326
 227 052326
 228 052334 000403
 229
 230 052336
 231 052336
 232 052344
 233 052352 116001 062617
 234 052356 013737 062106 002106
 235 052364 104417
 236 052366
 237 052372
 238 052400 012700 060000
 239 052404 005002
 240 052406 010004
 241 052410 010205
 242 052412
 243 052414
 244 052422 012700 160000
 245 052426 012702 000001
 246 052432 012704 060000
 247 052436 012705 100001
 248 052442
 249 052442 012701 040000
 250 052446 010103
 251 052450 012737 000207 177650
 252 052456 012737 177652 002360
 253 052464
 254 052474 104502
 255 052476
 256 052510
 257 052522 104424
 258 052524
 259 052534 000207

```

TASK06: SUBTST <<STOP SLAVE PROGRAM>>
:*****
:*SUBTEST      STOP SLAVE PROGRAM
:*****
MOV      #USESTK,SP
BIC      #BIT9!BIT0,MMRO      ;DEENERGIZE MEMORY MANAGEMENT
CLR      MDISPLAY
CLR      @DISPLAY
JMP      STOPCPU

TASK07: SUBTST <<WRITE ONLY ADDRESS PATTERN IN HI BYTE>>
:*****
:*SUBTEST      WRITE ONLY ADDRESS PATTERN IN HI BYTE
:*****
SET      WRITEONLY
BR       TASK7A

TASK10: SUBTST <<READ ONLY ADDRESS PATTERN IN HI BYTE>>
:*****
:*SUBTEST      READ ONLY ADDRESS PATTERN IN HI BYTE
:*****
SET      READONLY

TASK7A: SUPERVISOR      ;ENTER SUPERVISOR MODE
MOV      FIRST+TASK+1(RO),R1
MOV      FIRST+BANK,BANK
KERNEL      ;ENTER KERNEL MODE
IF R1 EQ #0
    BMOV  MTP001      ;ADDRESS PATTERN
    MOV   #FIRST,R0
    CLR  R2
    MOV  R0,R4
    MOV  R2,R5
ELSE
    BMOV  MTP002      ;COMPLEMENT ADDRESS PATTERN
    MOV   #LAST+2,R0
    MOV   #1,R2
    MOV   #FIRST,R4
    MOV   #100001,R5
END ;OF IF R1
MOV      #SIZE,R1
MOV      R1,R3
MOV      #207,UIPAR4      ;RETURN INSTRUCTION
MOV      #UIPAR5,SUPDOADD ;READ ONLY STARTING ADDRESS
CLEAR    MARGIN,MAINT
CLRCSR      ;CLEAR MK11 CSRS
IF WRITEONLY IS TRUE THEN $CALL SUPD01
IF READONLY IS TRUE THEN $CALL SUPD03
CACHOFF      ;TURN CACHE OFF
CLEAR    READONLY,WRITEONLY
RETURN
    
```

262 052536
 263 052536
 264 052544 116001 062617
 265 052550 013737 062106 002106
 266 052556 104417
 267 052560 072127 000011
 268 052564 010100
 269 052566 012701 010000
 270 052572
 271 052606 004737 051530
 272 052612 004737 051534
 273 052616 004737 051542
 274 052622 004737 051550
 275 052626 004737 051556
 276 052632
 277 052642 000207
 278
 279 052644

```
TASK11: SUBTST <<RUN FIVE PATTERNS IN DESIGNATED 1/4 BANK>>
:*****
:*SUBTEST      RUN FIVE PATTERNS IN DESIGNATED 1/4 BANK
:*****
SUPERVISOR      ;ENTER SUPERVISOR MODE
MOVB FIRST+TASK+1(R0),R1
MOV FIRST+BANK,BANK
KERNEL          ;ENTER KERNEL MODE
ASH #9.,R1
MOV R1,R0
MOV #SIZE/4,R1
SET WRITEONLY,READONLY
CALL SLPAT0
CALL SLPAT1
CALL SLPAT2
CALL SLPAT3
CALL SLPAT4
CLEAR WRITEONLY,READONLY
RETURN
```

280 052644
 281 052652 116001 062617
 282 052656 104417
 283
 284
 285
 286
 287 052660 010004
 288 052662 060104
 289
 290 052664 012705 010000
 291 052670 012703 060000
 292 052674
 293 052702 104415
 294 052704 004737 026042
 295 052710
 296 052716 104416
 297 052720 004737 026056
 298 052724 000207

```
TASK12: SUBTST <<WRITE & READ A SKEWED UP ADDRESS TEST>>
:*****
:*SUBTEST      WRITE & READ A SKEWED UP ADDRESS TEST
:*****
SUPERVISOR      ;ENTER SUPERVISOR MODE
MOVB FIRST+TASK+1(R0),R1
KERNEL          ;ENTER KERNEL MODE
;PAY ATTENTION NOW!
;R0 = MULTIPOINT ID # (0,2,4,6)
;R1 = OFFSET STARTING ADDRESS (0,2,4,6)
MOV R0,R4
ADD R1,R4          ,R4 IS NOW UNIQUE AMONST THE 4 CPU'S
MOV #SIZE/4,R5
MOV #FIRST,R3
BMOV MTPA32
SAVREG
CALL SUPD01
BMOV MTPB32
RESREG
CALL SUPD02
RETURN
```

```

301 052726
302 052726
303 052734 012777 177640 130000
304 052742
305 052750 013737 062106 002106
306 052756 052760 100000 062616
307 052764 104417
308 052766
309 053002
310 053012
311 053016
312 053024
313 053032 005737 060002
314 053036 001775
315
316 053040 017701 127676
317 053044 004711
318 053046
319 053062
320 053074 104417
321 053076
322 053076 000207
323
324 053100 000240
325 053102 000240
326 053104 000240
327 053106 000240
328 053110 000240
329 053112 000240
330 053114 000240
331 053116 000240
332 053120 000240
333 053122
334 053130 106212
335 053132 000137 053136
    
```

```

TASK13: SUBTST <<SETUP FOR ASRB TEST>>
*****
: *SUBTEST      SETUP FOR ASRB TEST
*****
BMOV   TSK13A
MOV    #UIPAR0,@IISTVEC      ;CAUSE WE SIMULATE TRAPS
SUPERVISOR                      ;ENTER SUPERVISOR MODE
MOV    FIRST+BANK,BANK
BIS    #BIT15,FIRST+TASK(R0) ;ACK
KERNEL                      ;ENTER KERNEL MODE
MAP    BANK                   ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
IF (PUBIT NE #MASTER
FOR R2 := #FIRST TO #FIRST+34 BY #4
FOR I := #1 TO #1000.
SUPERVISOR                      ;ENTER SUPERVISOR MODE
1$:  TST    FIRST+2
     BEQ    1$
     ;DISPATCH THRU THE IIST VECTOR
     MOV    @IISTVEC,R1
     CALL   (R1)
     END ;OF FOR I
     END ;OF FOR R2
KERNEL                      ;ENTER KERNEL MODE
END ;OF IF (PUBIT
RETURN

TSK13A: NOP                    ;V177640
      NOP                    ;V177642
      NOP                    ;V177644
      NOP                    ;V177646
      NOP                    ;V177650
      NOP                    ;V177652
      NOP                    ;V177654
      NOP                    ;V177656
      NOP                    ;V177660
      SUPERVISOR              ;V177662 ;ENTER SUPERVISOR MODE
      ASRB (R2)                ;V177670
      JMP   TSK13A            ;V177672
    
```

338 053136

TSK13B: SUBTST <<RECOVER FROM TASK13 - TRAP FROM IIST>>
:*****
:*SUBTST RECOVER FROM TASK13 - TRAP FROM IIST
:*****

339 053136

ON.ERROR

340 053140

SET SLFLAG(RO) ;I LOCKED IT...

341 053146

163777 002730 127566

SUB SLAVES,@IISTVEC

342 053154

163777 002730 127560

SUB SLAVES,@IISTVEC

343 053162

IF @IISTVEC LO #UIPAR0 THEN LET @IISTVEC := #UIPAR0

344 053200

ELSE

345 053202

005060 002656

CLR SLFLAG(RO) ;IT WAS LOCKED BY SOMEONE ELSE

346 053206

062777 000002 127526

ADD #2,@IISTVEC

347 053214

IF @IISTVEC HI #UDPAR1 THEN LET @IISTVEC := #UDPAR1

348 053232

END ;OF ON.NOERROR

349 053232

MAP #0 ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0

350 053246

016060 002656 062656

MOV SLFLAG(RO),FIRST+SLFLAG(RO)

351 053254

MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK

352 053270

005037 060002

CLR FIRST+2

353 053274

RETURN

```

356 053276          TASK14: SUBTST <<RESET FROM ASRB TEST>>
:*****
:*SUBTEST          RESET FROM ASRB TEST
:*****
357 053276 000237          SPL          7
358 053300 012777 061216 127434      MOV          #SLAVUP,@IISTVEC
359 053306 000207          RETURN
360
361 053310          TASK15: SUBTST <<RUN SLAVE IN CSR TESTS>>
:*****
:*SUBTEST          RUN SLAVE IN CSR TESTS
:*****
362 053310 004737 016664          CALL          MKCONTROL
363 053314 000207          RETURN
364
365 053316          TASK16: SUBTST <<SET MARGIN 6, CPU HAS I/O PRIORITY>>
:*****
:*SUBTEST          SET MARGIN 6, CPU HAS I/O PRIORITY
:*****
366 053316 012737 000014 177750      MOV          #14,MAINT
367 053324 012737 000006 002112      MOV          #6,MARGIN
368 053332 000207          RETURN
369
370 053334          TASK17: SUBTST <<CREATE STALE DATA TEST>>
:*****
:*SUBTEST          CREATE STALE DATA TEST
:*****
371 053334          SUPERVISOR
372 053342 013737 062106 002106      MOV          FIRST+BANK,BANK
373 053350 104417          KERNEL
374 053352          MAP          BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
375 053366          SUPERVISOR          ;ENTER SUPERVISOR MODE
376 053374 012700 060000          MOV          #FIRST,R0
377 053400 012701 060004          MOV          #FIRST+4,R1
378 053404 022711 047507          CMP          #'GO,(R1)
379 053410 001375          BNE          1$          ;TIME TO GO?
380 053412 012710 177777          MOV          #-1,(R0)          ;NO - LOOP
381 053416 104417          KERNEL          ;WRITE WORD
382 053420 000207          RETURN          ;ENTER KERNEL MODE
    
```

385 053422

TASK20: SUBTST <<CACHE FLUSH TEST>>
 :*****
 :*SUBTEST CACHE FLUSH TEST
 :*****

386 053422
 387 053430
 388 053436 013737 062106 002106
 389 053444 104417
 390 053446
 391 053462 012700 060000
 392 053466 012701 060004
 393 053472 005002

BMOV TSK20A
 SUPERVISOR ;ENTER SUPERVISOR MODE
 MOV FIRST+*BANK,BANK
 KERNEL ;RETURN TO KERNEL MODE
 MAP BANK
 MOV #FIRST,R0
 MOV #FIRST+4,R1
 CLR R2

394
 395
 396 053474 077201
 397

1\$: ;WAIT FOR ANY FLUSH TO FINISH
 SOB R2,1\$

398 053476
 399 053504 004737 177640
 400 053510 005060 000004
 401 053514 104417

SUPERVISOR ;ENTER SUPERVISOR MODE
 CALL FASTCITY
 CLR 4(R0) ;KILL THE GO SIGNAL
 KERNEL ;ENTER KERNEL MODE

402
 403
 404 053516 022701 000000
 405 053522 001411
 406 053524 012737 000000 002050
 407 053532 010137 002056
 408 053536 012737 060000 002040
 409 053544 104055

;VERIFY STALE DATA
 CMP #0,R1 ;CHECK FOR STALE DATA
 BEQ 2\$;OK - SKIP
 MOV #0,GOOD ;REPORT ERROR
 MOV R1,BAD
 MOV #FIRST,ADDRESS
 ERROR +55

410
 411
 412 053546 022702 177777
 413 053552 001411
 414 053554 012737 177777 002050
 415 053562 010237 002056
 416 053566 012737 060000 002040
 417 053574 104056

2\$: ;VERIFY THAT FLUSHING GETS RID OF STALE DATA
 CMP #-1,R2 ;CHECK FOR GOOD DATA
 BEQ 5\$;OK - SKIP
 MOV #-1,GOOD ;REPORT ERROR
 MOV R2,BAD
 MOV #FIRST,ADDRESS
 ERROR +56

418
 419 053576 104424
 420 053600 000207
 421
 422 053602

5\$: CACHOFF ;TURN CACHE OFF
 RETURN

TSK20A: SUBTST <<CACHE FLUSH TEST (FOR PAR'S)>>
 :*****
 :*SUBTEST CACHE FLUSH TEST (FOR PAR'S)
 :*****

423 053602 012737 000401 177746
 424 053610 012710 000000
 425 053614 005710
 426 053616 012711 047507
 427 053622 077201
 428 053624 011001
 429 053626 012737 000401 177746
 430 053634 011002
 431 053636 000207

1\$: MOV #BIT8!BIT0,CONTRL ;V177640 ;TURN ON CACHE & FLUSH IT!
 MOV #0,(R0) ;V177646 ;WRITE FRESH DATA
 TST (R0) ;V177652 ;READ - CREATING A CACHE HIT
 MOV #'GO,(R1) ;V177654 ;SIGNAL SLAVES TO MAKE STALE DATA
 SOB R2,1\$;V177660 ;WAIT FOR SLAVES TO FINISH
 MOV (R0),R1 ;V177662 ;STALE DATA ----> R1
 MOV #BIT8!BIT0,CONTRL ;V177664 ;FLUSH CACHE AGAIN
 MOV (R0),R2 ;V177672 ;FRESH DATA ----> R2
 RETURN ;V177674

434 053640

```

MRUNSETUP:SUBTST      <<SETUP EXECUTION CONTENTION TEST>>
:*****
:*SUBTEST      SETUP EXECUTION CONTENTION TEST
:*****
      MAP      BANK      ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
      MOV      #FIRST,R0
      WHILE R0 LO #LAST
      CALL     $RAND
      MOV      SEEDHI,R1
      MOV      #16.,R2
      SUPERVISOR      ;ENTER SUPERVISOR MODE
      THRU R2
      ROL R1
      ON.ERROR
      MOV      #5210,(R0)+      ;INC (R0) INSTRUCTION
      ELSE
      MOV      #5710,(R0)+      ;TST (R0) INSTRUCTION
      END ;OF ON.ERROR
      FND ;OF THRU R2
      KERNEL      ;ENTER KERNEL MODE
      END ;OF WHILE R0
      SUPERVISOR      ;ENTER SUPERVISOR MODE
      MOV      #207,-(R0)      ;RETURN INSTRUCTION
      KERNEL      ;ENTER KERNEL MODE
      RETURN
    
```

435 053640
 436 053654 012700 060000
 437 053660
 438 053666 004737 074720
 439 053672 013701 002714
 440 053676 012702 000020
 441 053702
 442 053710
 443 053710 006101
 444 053712
 445 053714 012720 005210
 446 053720
 447 053722 012720 005710
 448 053726
 449 053726
 450 053730 104417
 451 053732
 452 053734
 453 053742 012740 000207
 454 053746 104417
 455 053750 000207

458 053752
 459
 460 053752 012737 177765 002676
 461 053760 013777 002676 127002
 462 053766
 463 053774 013737 002510 002114
 464 054002 004737 042422
 465 054006 012737 000020 002114
 466 054014
 467 054030
 468 054044
 469 054052
 470 054076 104417
 471 054100
 472 054102 010001
 473 054104 006301
 474 054106 012761 000013 002616
 475 054114
 476 054124 004737 050726
 477 054130
 478 054144
 479 054146 010001
 480 054150 006301
 481 054152 012737 061165 002574
 482 054160 004737 072154 2\$:
 483 054164
 484 054166 010037 002056
 485 054172 104060
 486 054174
 487 054200
 488 054200 005761 002616
 489 054204 100365
 490 054206
 491
 492 054216 005000
 493 054220 077001 1\$:
 494 054222
 495 054226
 496 054234
 497 054242 012712 000001
 498 054246 004737 054544
 499
 500
 501 054252 005000
 502 054254
 503 054256
 504 054264 005261 002646
 505 054270 005200
 506 054272
 507 054272
 508
 509
 510 054304
 511 054312 104033

```

SUMP13: SUBTST <<MULTI PORT ASRB TEST (IN SUPERVISOR SPACE)>>
:*****
:*SUBTEST MULTI PORT ASRB TEST (IN SUPERVISOR SPACE)
:*****
.ENABL LSB
MOV #-13,MDISPLAY
MOV MDISPLAY,@DISPLAY
FOR BANK := #1 TO #167
MOV ALLCPUS,CPUBIT
CALL EXBANK
MOV #MASTER,CPUBIT
IF PFLAG IS FALSE AND ACFLAG IS TRUE
MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
SUPERVISOR ;ENTER SUPERVISOR
CLEAR PORTCOUNT,PORTCOUNT+2,PORTCOUNT+4,PORTCOUNT+6,FIRST+2
KERNEL ;ENTER KERNEL MODE
FOR RO := #0 TO SLAVES
MOV RO,R1
ASL R1
MOV #13,TASK(R1) ;ORDERS TO SETUP FOR ASRB TEST
END ;OF FOR RO
CALL TASKDO
MAP BANK
FOR RO := #0 TO SLAVES
MOV RO,R1
ASL R1
MOV #5*SECONDS,HUNGTIME
CALL QUE
ON.ERROR
MOV RO,BAD
ERROR +60 ;SLAVE HUNG SYSTEM!
$RETURN ERROR
END ;OF ON.ERROR
TST TASK(R1)
BPL 2$
END ;OF FOR RO
;I ASSUME THEY HAVE FINISHED COMPLETELY AFTER THIS DELAY
CLR RO
SOB RO,1$
FOR R2 := #FIRST TO #FIRST+34 BY #4
FOR I := #1 TO #1000.
SUPERVISOR ;ENTER SUPERVISOR MODE
MOV #1,(R2) ;UNLOCK TEST LOCATION
CALL WAKEUP
;RECORD WINNER(S)
CLR RO
FOR R1 := #0 TO #6 BY #2
IF SLFLAG(R1) IS TRUE
INC PORTCOUNT(R1)
INC RO
END ;OF IF SLFLAG
END ;OF FOR R1
;CHECK FOR ONE & ONLY ONE LOCK
IF RO NE #1
ERROR +33
    
```

```
512 054314          END ;OF IF RC
513 054314          END ;OF FOR I
514 054330          END ;OF FOR R2
515 054342 104417   KERNEL
516 054344 004737 054472  CALL M13BAL ;CALL BALANCE TEST
517 054350          END ;OF IF PFLAG
518 054350          FND ;OF FOR BANK
519 054364          FOR RO := #1 TO SLAVES
520 054370 010001   MOV RO,R1
521 054372 006301   ASL R1
522 054374 012761 000014 002616  MOV #14,TASK(R1) ;ORDERS TO RESET FROM ASRB TEST
523 054402          END ;OF FOR PO
524 054412          FOR RO := #1 TO SLAVES
525 054416 010001   MOV RO,R1
526 054420 006301   ASL R1
527 054422 012737 061165 002574 3$: MOV #5*SECONDS,HUNGTIME
528 054430 004737 072154  CALL QUE
529 054434          ON.ERROR
530 054436 010037 002056   MOV RO,BAD
531 054442 104060   ERROR +60 ;SLAVE HUNG SYSTEM!
532 054444          $RETURN ERROR
533 054450          END ;OF ON.ERROR
534 054450 005761 002616   TST TASK(R1) ;WAIT FOR ALL CPU'S DONE
535 054454 100365   BPL 3$
536 054456          END ;OF FOR RO
537 054466          $RETURN NOERROR
538          .DSABL LSB
```

541 054472

M13BAL: SUBST <<BALANCE TEST>>

:*SUBTEST BALANCE TEST

542 054472

BEGIN ASRBALANCE

543 054472

FOR R0 := #0 TO SLAVES

544 054474 010001

MOV R0,R1

545 054476 006301

ASL R1

546 054500 013702 002646

MOV PORTCOUNT,R2

547 054504 166102 002646

SUB PORTCOUNT(R1),R2

548 054510 062702 000400

ADD #256.,R2

;# HERE & IN NEXT INST IS + OR - COUNT SPEC

549 054514

IF R2 LT #0 OR R2 GT #256.*2

550 054526 104053

ERROR +53

551 054530

LEAVE ASRBALANCE

552 054532

END :OF IF R2

553 054532

END :OF FOR R0

554 054542

END ASRBALANCE

555 054542 000207

RETURN

556

557

:WAKE UP EVERY CPU

558 054544

WAKEUP: SET FIRST+2

559

:INCLUDING MYSELF

560 054552 000240

NOP

561 054554 000240

NOP

562 054556 005000

CLR R0

563 054560 017701 126156

MOV @IISTVEC,R1

564 054564 004711

CALL (R1)

565 054566 000207

RETURN

```
568 .SBTTL ERROR DATA (SUPERVISOR) SETUP STUFF
569 054570 $PER25: LET ADDRESS := R1 - #2
570 054602 IF ABORTFLAG IS FALSE
571 054610 SUPERVISOR ;ENTER SUPERVISOR MODE
572 054616 LET BAD := -2(R1)
573 054624 104417 KERNEL ;ENTER KERNEL MODE
574 054626 END :OF IF ABORTFLAG
575 054626 IF 177654 EQ #0
576 054634 LET GOOD := R2
577 054640 ELSE
578 054642 LET GOOD := R3
579 054646 END :OF IF
580 054646 000137 065330 JMP PERRAW
581
582 054652 PERRA3: SUBST <<DATA WAS 3 WORDS>>
;*****
;*SUBTEST DATA WAS 3 WORDS
;*****
583 054652 IF BADPC EQ #0 THEN $CALL BADSTACK
584 054664 PUSH RO
585 054666 104505 CHKDIS ;DISABLE ECC & WRITE CHECKBITS FROM 1 SELECTED CSR
586 054670 104426 READCSR
587 054672 013700 002144 MOV CSR,RO
588 054676 000300 SWAB RO
589 054700 042700 177600 BIC #*C177,RO
590 054704 104503 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
591 054706 LET ADDRESS := R1
592 054712 005037 002050 CLR GOOD
593 054716 SUPERVISOR ;ENTER SUPERVISOR MODE
594 054724 011137 002056 MOV (R1),BAD
595 054730 016137 000002 002060 MOV 2(R1),BAD2
596 054736 104417 KERNEL ;ENTER KERNEL MODE
597 054740 110037 002062 MOVB RO,BAD3
598 054744 105037 002063 CLRB BAD3+1
599 054750 004737 065564 CALL PERBANK
600 054754 104034 ERROR +34
601 054756 POP RO
602 054760 000002 RTI
```

605 054762
 606 054766
 607 055000
 608 055006
 609 055014
 610 055022 104417
 611 055024
 612 055024 000137 065330
 613
 614 055030

```

$PER30: LET GOOD : R1
        LET ADDRESS : (SP) - 1b
        IF ABORTFLAG IS FALSE
        SUPERVISOR ;ENTER SUPERVISOR MODE
        LET BAD := @ADDRESS
        KERNEL ;ENTER KERNEL MODE
        END ;OF IF ABORTFLAG
        JMP PERRAW
    
```

```

GETDATA:SUBTST <<GET DATA FROM ABORTED AREA IF POSSIBLE>>
:*****
:*SUBTEST GET DATA FROM ABORTED AREA IF POSSIBLE
:*****
    
```

615 055030
 616 055042 010637 055156
 617 055046 012737 055122 000004
 618 055054 012737 055122 000114
 619 055062 013700 002040
 620 055066 052737 000001 177750
 621 055074 052737 004000 177746
 622 055102
 623 055110 011037 002056
 624 055114 104417
 625 055116 005037 002142
 626 055122 013706 055156
 627 055126 042737 004000 177746
 628 055134 042737 000001 177750
 629 055142
 630 055154 000207
 631 055156 000000

```

        PUSH RO,4,114
        MOV SP,GETDA1
        MOV #1$,4
        MOV #1$,114
        MOV ADDRESS,RO
        BIS #BIT0,MAINT
        BIS #BIT11,CONTRL ;DISABLE ABORTS
        SUPERVISOR
        MOV (RO),BAD
        KERNEL
        CLR ABORTFLAG
        1$: MOV GETDA1,SP ;RESTORE KNOWN GOOD STACK POINTER
        BIC #BIT11,CONTRL ;ENABLE ABORTS
        BIC #BIT0,MAINT
        POP 114,4,RO
        RETURN
    GETDA1: 0
    
```

```

634
635
636
637
638 055160
639 055170 000000
640 055172 000776
641 055174
642 055174 012737 000376 002760
643
644 055202
645 055212 104423
646 055214 012737 056134 000024
647 055222 012737 000340 000026
648 055230
649
650 055250 012700 177700
651 055254 012701 000021
652 055260
653 055262 077102
654
655 055264 012700 172300
656 055270 012701 000020
657 055274
658 055276 077102
659 055300
660
661 055312 012700 172300
662 055316 012701 177600
663 055322 012702 172200
664 055326 012703 000040
665 055332 011021
666 055334 012022
667 055336 077303
    
```

```

.SBTTL POWER FAIL AUTO RESTART
.SBTTL ROUTINE POWER DOWN AND UP
:*****
:POWER DOWN ROUTINE
$PWRDN: IF CPUBIT NE #MASTER
DNSLAV: HALT
        BR      DNSLAV
END ;OF IF CPUBIT
MOV     #376,PWLOCK
;SAVE CACHE & MARGIN STATUS
PUSH   CONTRL,MAINT
        LACHON
MOV     #$ILLUP,PWRVEC ;TURN CACHE ON
MOV     #340,PWRVEC+2 ;SET FOR FAST UP
        ;:PRIO:7
PUSH   R0,R1,R2,R3,R4,R5,CSRNO
;SAVE USER PAR'S & PDR7
MOV     #177700,R0
MOV     #17.,R1
1$:    PUSH   -(R0)
        SOB   R1,1$
;SAVE SUPERVISOR PAR'S
MOV     #172300,R0
MOV     #16.,R1
2$:    PUSH   -(R0)
        SOB   R1,2$
        IF RLFLAG IS TRUE THEN $CALL WOOPS
;COPY KERNEL MAP TO USER & SUPERVISOR
MOV     #KIPDR0,R0
MOV     #UIPDR0,R1
MOV     #SIPDR0,R2
MOV     #32.,R3
3$:    MOV     (R0),(R1)+
        MOV     (R0)+,(R2)+
        SOB   R3,3$
    
```

```

669 ;SAVE USER & SUPERVISOR STACK POINTERS
670 USER
671 055346 010600 MOV USP,R0
672 055350 104417 KERNEL ;ENTER KERNEL MODE
673 055352 PUSH R0
674 055354 SUPERVISOR ;ENTER SUPERVISOR MODE
675 055362 010600 MOV SSP,R0
676 055364 104417 KERNEL ;ENTER KERNEL MODE
677 055366 PUSH R0
678 ;SAVE MK11 REGISTERS
679 055370 013701 002334 MOV MKCSRS,R1 ;GET CSR'S BYTE
680 055374 BEGIN LCSRSAVE
681 055374 FOR CSRNO := #0 TO #34 BY #4
682 055400 106301 ASLB R1
683 055402 ON.ERROR
684 055404 104426 READCSR
685 055406 PUSH CSR,CSR+2
686 055416 END ;OF ON.ERROR
687 055416 IFB R1 EQ #0 THEN LEAVE LCSRSAVE
688 055422 END ;OF FOR CSRNO
689 055440 END LCSRSAVE
690 ;SAVE MMR0,1,2,3
691 055440 PUSH MMR0,MMR1,MMR2,MMR3
692 ;SAVE KERNEL PAR'S
693 055460 012700 172400 MOV #172400,R0
694 055464 012701 000020 MOV #16.,R1
695 055470 4$: PUSH -(R0)
696 055472 077102 SOB R1,4$
697 ;SAVE UNIBUS MAP REGISTERS
698 055474 PUSH MAPH36,MAPL36,MAPH0,MAPL0
699 ;SAVE POSSIBLE SOFTWARE SWITCH REGISTER
700 055514 PUSH @SWR
701 ;SAVE STACK POINTER
702 055520 010637 056140 MOV SP,$SAVR6 ;;SAVE SP
703 ;NOW SET UP REAL VECTOR
704 055524 012737 055536 000024 MOV $SPURUP,PWRVEC ;;SET UP VECTOR
705 055532 000000 $DOWN: HALT
706 055534 000776 BR $DOWN ;;HANG UP
    
```



```

709
710 :*****
711 055536 :POWER UP ROUTINE
712 055550 012737 056134 000024 $PWRUP: IF MULTIPOST IS TRUE THEN JUMPTO MULTIUP
713 :RESTORE STACK POINTER
714 055556 013706 056140 MOV $SAVR6,SP ;;GET SP
715 055562 005037 056140 CLR $SAVR6 ;;WAIT LOOP FOR THE TTY
716 055566 005237 056140 1$: INC $SAVR6 ;;WAIT FOR THE INC
717 055572 001375 BNE 1$ ;;OF A WORD
718 :RESTORE POSSIBLE SOFTWARE SWITCH REGISTER
719 055574 POP @SWR
720 :RESTORE UNIBUS MAP
721 055600 POP MAPLO,MAPHO,MAPL36,MAPH36
722 055620 004737 042026 CAL LOWMAP ;;SETUP LOWER 16K OF UNIBUS MAP
723 :RESTORE KERNEL PAR'S & PDR'S
724 055624 012700 172340 MOV #172340,R0
725 055630 012702 172300 MOV #KIPDR0,R2
726 055634 012701 000020 MOV #16.,R1
727 055640 6$: POP (R0)+
728 055642 012722 077406 MOV #77406,(R2)+
729 055646 077104 SOB R1,6$
730 :RESTORE MMR3,2,1,0
731 055650 POP MMR3,MMR2,MMR1,MMR0
732 :RESTORE MK11 REGISTERS
733 055670 013701 002334 MOV MKCSRS,R1 ;;GET CSR'S BYTE
734 055674 042701 177400 BIC #177400,R1
735 055700 BEGIN LCSRSTORE
736 055700 FOR CSRNO := #34 DOWNT0 #0 BY #4
737 055706 106201 ASRB R1
738 055710 ON.ERROR
739 055712 POP CSR+2,CSR
740 055722 104425 LOADCSR
741 055724 END ;OF ON.ERROR
742 055724 IFB R1 EQ #0 THEN LEAVE LCSRSTORE
743 055730 END ;OF FOR CSRNO
744 055746 END LCSRSTORE
745 :COPY KERNEL MAP TO USER & SUPERVISOR
746 055746 012700 172300 MOV #KIPDR0,R0
747 055752 012701 177600 MOV #UIPDR0,R1
748 055756 012702 172200 MOV #SIPDR0,R2
749 055762 012703 000040 MOV #32.,R3
750 055766 011021 3$: MOV (R0),(R1)+
751 055770 012022 MOV (R0)+,(R2)+
752 055772 077303 SOB R3,3$
    
```

```

754      ;RESTORE SUPERVISOR & USER STACK POINTERS
755 055774 POP      R0
756 055776 SUPERVISOR      ;ENTER SUPERVISOR MODE
757 056004 010006 MOV      R0,SSP
758 056006 104417 KERNEL      ;ENTER KERNEL MODE
759 056010 POP      R0
760 056012 USER
761 056020 010006 MOV      R0,USP
762 056022 104417 KERNEL      ;ENTER KERNEL MODE
763      ;RESTORE SUPERVISOR PAR'S
764 056024 012700 172240 MOV      #172240,R0
765 056030 012701 000020 MOV      #16.,R1
766 056034      7$: POP      (R0)+
767 056036 077102 SOB      R1,7$
768      ;RESTORE USER PAR'S & PDR7
769 056040 012700 177636 MOV      #177636,R0
770 056044 012701 000021 MOV      #17.,R1
771 056050      8$: POP      (R0)+
772 056052 077102 SOB      R1,8$
773      ;RESTORE POSSIBLE SOFTWARE DISPLAY REGISTER
774 056054 013777 002014 124706 MOV      $PATMAR,@DISPLAY
775 056062 013737 002014 000174 MOV      $PATMAR,DISPREG
776 056070 POP      CSRNO,R5,R4,R3,R2,R1,R0
777 056110 012737 055160 000024 MOV      #$PWRDN,PWRVEC ;;SET UP THE POWER DOWN VECTOR
778 056116 TYPE      MSG051 ;REPORT THE POWER FAILURE
779      ;RESTORE MARGIN & CACHE STATUS
780 056122 POP      MAINT,CONTRL
781 056132 000002 RTI
782 056134 000000 $ILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
783 056136 000776 BR      $ILLUP ;; BEFORE THE POWER DOWN WAS COMPLETE
784 056140 000000 $SAVR6: 0 ;;PUT THE SP HERE
785      .EVEN
    
```

ROUTINE POWER DOWN AND UP

788 056142

```

MULTIUP:SUBST <<MULTIPLE CPU'S POWERING UP>>
:*****
:SUBTEST      MULTIPLE CPU'S POWERING UP
:*****

```

```

789 056142 106237 002760
790 056146 103002
791 056150 000000
792 056152 000776
793 056154 006137 004352
794
795 056160

```

```

          ASRB  PWLOCK
          BCC   UP2
MULHLT:  HALT                    ;BECAUSE I'VE BEEN LOCKED OUT
          BR    MULHLT
UP2:     JMP    START

```

```

WOOPS:  SUBST <<POWER FAIL WHILE RELOCATED>>
:*****
:SUBTEST      POWER FAIL WHILE RELOCATED
:*****

```

```

796 056160
797 056164 005037 002106
798 056170
799 056204
800 056212 013737 060024 056542
801 056220 013737 060026 056544
802 056226
803 056240 012737 056336 060024
804 056246 012737 000340 060026
805 056254
806 056266 012700 172340
807 056272 012701 136512
808 056276 012702 000010
809 056302 012021
810 056304 077202
811 056306 013721 172516
812 056312 013721 177576
813 056316 013721 177574
814 056322 013721 177572
815 056326 104417
816 056330
817 056334 000207

```

```

          PUSH  BANK
          CLR  BANK
          MAP  BANK                    ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
SUPERVISOR ;ENTER SUPERVISOR MODE
MOV      FIRST+PWRVEC,WOOPSAV
MOV      FIRST+PWRVEC+2,WOOPSAV+2
BMOV     FIRST+WOOPUP,WOOPSAV+4,WOOPEND-WOOPUP/2+12.
MOV      #WOOPUP,FIRST+PWRVEC
MOV      #340,FIRST+PWRVEC+2
BMOV     WOOPUP,FIRST+WOOPUP,WOOPEND-WOOPUP/2
MOV      #KIPAR0,R0
MOV      #FIRST+WOOPEND,R1
MOV      #8.,R2
1$:      MOV   (R0)+,(R1)+
          SOB  R2,1$
          MOV  MMR3,(R1)+
          MOV  MMR2,(R1)+
          MOV  MMR1,(R1)+
          MOV  MMRO,(R1)+
          KERNEL ;ENTER KERNEL MODE
          POP  BANK
          RETURN

```

820 056336

```

WOOPUP: SUBST <<POWER UP FROM BANK 0 TO RELOCATION>>
:*****
: *SUBTEST POWER UP FROM BANK 0 TO RELOCATION
:*****
      MOV #WOOPEND,R0
      MOV #KIPAR0,R1
      MOV #KIPDR0,R3
      MOV #8.,R2
1$:   MOV (R0)+,(R1)+
      MOV #77406,(R3)+
      SOB R2,1$
      MOV (R0)+,MMR3
      MOV (R0)+,MMR2
      MOV (R0)+,MMR1
      MOV (R0)+,MMR0
      MOV $$SAVR6,SP
      PUSH BANK
      CLR BANK
      MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
      SUPERVISOR ;ENTER SUPERVISOR MODE
      MOV WOOPSAV,FIRST+PWRVEC
      MOV WOOPSAV+2,FIRST+PWRVEC+2
      ;SIMULATE THE FOLLOWING BLOCK MOV BUT WITH NO STACK ACCESSES
      ;BMOV WOOPSAV+4,FIRST+WOOPUP,WOOPEND-WOOPUP/2+12.
      MOV #WOOPSAV+4,R0
      MOV #WOOPEND-WOOPUP/2+12.,R1
      MOV #FIRST+WOOPUP,R2
2$:   MOV (R0)+,(R2)+
      SOB R1,2$
      KERNEL ;ENTER KERNEL MODE
      POP BANK
      JMP $PWRUP
WOOPEND: .REPT 12.
WOOPSAV: .REPT WOOPEND-WOOPUP/2+12.+2
    
```

821 056336 012700 056512
 822 056342 012701 172340
 823 056346 012703 172300
 824 056352 012702 000010
 825 056356 012021
 826 056360 012723 077406
 827 056364 077204
 828 056366 012037 172516
 829 056372 012037 177576
 830 056376 012037 177574
 831 056402 012037 177572
 832 056406 013706 056140
 833 056412
 834 056416 005037 002106
 835 056422
 836 056436
 837 056444 013737 056542 060024
 838 056452 013737 056544 060026
 839
 840
 841 056460 012700 056546
 842 056464 012701 000102
 843 056470 012702 136336
 844 056474 012022
 845 056476 077102
 846
 847 056500 104417
 848 056502
 849 056506 000137 055536
 850 056512 000014
 853 056542 000104

```

858 .SBTTL IO SUBROUTINES
859
860 .SBTTL ROUTINE TYPE
861
862 *****
863 *ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
864 *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
865 *NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
866 *NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
867 *NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
868 *
869 *CALL:
870 *1) USING A TRAP INSTRUCTION
871 * TYPE MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
872 *OR
873 * TYPE
874 * MESADR
875 *
876
877 056752 105737 002452 $TYPE: TSTB $TPFLG ;; IS THERE A TERMINAL?
878 056756 100407 BMI 6$ ;; BR IF NO
879 056760 010046 1$: MOV RO,-(SP) ;; SAVE RO
880 056762 017600 000002 MOV @2(SP),RO ;; GET ADDRESS OF ASCIZ STRING
881 056766 112046 4$: MOVB (RO)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
882 056770 001005 BNE 7$ ;; BR IF IT ISN'T THE TERMINATOR
883 056772 005726 TST (SP)+ ;; IF TERMINATOR POP IT OFF THE STACK
884 056774 012600 5$: MOV (SP)+,RO ;; RESTORE RO
885 056776 062716 6$: ADD #2,(SP) ;; ADJUST RETURN PC
886 057002 000002 RTI ;; RETURN
887 057004 122716 7$: CMPB #HT,(SP) ;; BRANCH IF NOT <HT>
888 057010 001002 BNE 11$ 11$
889 057012 112716 000040 MOVB #' ,(SP) ;; REPLACE TAB WITH SPACE
890 057016 122716 000200 11$: CMPB #CRLF,(SP) ;; BRANCH IF NOT <CRLF>
891 057022 001006 BNE 8$ 8$
892 057024 005726 TST (SP)+ ;; POP <CR><LF> EQUIV
893 057026 TYPE ;; TYPE A CR AND LF
894 057030 003010 $CRLF
895 057032 105037 057356 CLRB $CHARCNT ;; CLEAR CHARACTER COUNT
896 057036 000753 BR 4$ ;; GET NEXT CHARACTER
897 057040 004737 057076 8$: CALL $TYPEC ;; GO TYPE THIS CHARACTER
898 057044 123726 003002 9$: CMPB $FILLC,(SP)+ ;; IS IT TIME FOR FILLER CHARS.?
899 057050 001346 BNE 4$ ;; IF NO GO GET NEXT CHAR.
900 057052 013746 002450 MOV $NULL,-(SP) ;; GET # OF FILLER CHARS. NEEDED
901 ;; AND THE NULL CHAR.
902 057056 105366 000001 10$: DECB 1(SP) ;; DOES A NULL NEED TO BE TYPED?
903 057062 002770 BLT 9$ ;; BR IF NO--GO POP THE NULL OFF OF STACK
904 057064 004737 057076 CALL $TYPEC ;; GO TYPE A NULL
905 057070 105337 057356 DECB $CHARCNT ;; DO NOT COUNT AS A COUNT
906 057074 000770 BR 10$ ;; LOOP
907 057076 $TYPEC: PUSH R1
908 057100 116601 000004 MOVB 4(SP),R1
909 057104 PUSH RO,CONTRL
910 057112 104424 CACHOFF ;; TURN CACHE OFF
911 057114 IF MULTIPOST IS TRUE
912 057122 IF NOIIST IS TRUE
913 057130 013700 177764 MOV SYSTID,RO
914 057134 ELSE
  
```

```

915 057136 017700 123574      MOV @IISTACR,R0
916 057142 072027 177770      ASH #-8.,R0
917 057146 042700 177774      BIC #^C3,R0
918 057152                      END :OF IF NOIIST
919 057152                      END :OF IF MULTIPOINT
920 057152                      IF PORTDIR NE R0 AND MULTIPOINT IS TRUE ;IF I,M NOT THE MASTER IN A MULTIPOINT SYSTEM
921 057166                      IF CPUBIT EQ #SLAVE1 THEN LET RO := #2
922 057202                      IF CPUBIT EQ #SLAVE2 THEN LET RO := #4
923 057216                      IF CPUBIT EQ #SLAVE3 THEN LET RO := #6
924 057232                      MAP #0 ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
925 057246                      SUPERVISOR ;ENTER SUPERVISOR MODE
926 057254 005760 062626      2$: TST FIRST+PTYFLAG(R0)
927 057260 100775                      BMI 2$
928 057262 110160 062636      MOVB R1,FIRST+PTYBUF(R0)
929 057266                      SET FIRST+PTYFLAG(R0)
930 057274                      MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
931 057310 104417                      KERNEL ;ENTER KERNEL MODE
932 057312                      ELSE ;IF I AM THE MASTER OR WE'RE NOT MULTIPOINTING
933 057314 105777 123456      3$: TSTB @STPS ;WAIT UNTIL PRINTER IS READY
934 057320 100375                      BPL 3$
935 057322 110177 123452      MOVB R1,@STPB ;LOAD CHAR TO BE TYPED INTO DATA REG.
936 057326                      END :OF IF PORTDIR
937 057326 122766 000015 000002      CMPB #CR,2(SP) ;:IS CHARACTER A CARRIAGE RETURN?
938 057334 001003                      BNE 1$ ;:BRANCH IF NO
939 057336 105037 057356      CLRB $CHARCNT ;:YES--CLEAR CHARACTER COUNT
940 057342 000406                      BR $TYPEX ;:EXIT
941 057344 122766 000012 000002 1$: CMPB #LF,2(SP) ;:IS CHARACTER A LINE FEED?
942 057352 001402                      BEQ $TYPEX ;:BRANCH IF YES
943 057354 105227                      INCB (PC)+ ;:COUNT THE CHARACTER
944 057356 000000      $CHARCNT: .WORD 0 ;:CHARACTER COUNT STORAGE
945 057360                      $TYPEX: POP CONTRL,R0,R1
946 057370 000207                      RETURN
947 057372      SUPLIMIT:;!!!!!!THIS IS THE LIMIT ON SUPERVISOR MAPPED TO MUT SPACE
    
```

```

949 057372          MAST01: SUBST <<MULTIPOINT SLAVE STARTER>>
:*****
:*SUBTEST          MULTIPOINT SLAVE STARTER
:*****
950                .ENABL  LSB
951 057372 104424   CACHOFF                    ;TURN CACHE OFF
952 057374        SET  NOSCOPE                    ;NO SCOPE LOOPS IN MULTIPROCESSOR TESTS
953 057402 012737 177777 002676   MOV  #-1,MDISPLAY
954 057410 013777 002676 123352   MOV  MDISPLAY,@DISPLAY
955                :PASS PSEUDO SWR TO SLAVE
956 057416 013737 002766 002674   MOV  SWR,MASWR                    ;SAVE REAL SWR
957 057424 012737 000176 002766   MOV  #SWREG,SWR                    ;SETUP SOFTWARE SWR
958 057432 017777 123236 123326   MOV  @MASWR,@SWR                    ;FILL IT WITH REAL SWR STUFF
959 057440        IF NOIIST IS TRUE
960 057446        FOR R0 := #1 TO SLAVES
961 057452 005037 002670        CLR LOCK
962 057456 162737 000200 002706   SUB  #200,KSTACK
963 057464 010001        MOV  R0,R1
964 057466 006301        ASL  R1
965 057470        FOR R2 := #10, DOWNT0 #0
966 057474 010261 002636        MOV  R2,PTYBUF(R1)
967 057500 012703 000200        MOV  #200,R3 ;DELAY FOR THE SLAVE TO GAIN ACCES TO CNT-DOWN
968 057504 077301 1$:        SOB  R3,1$
969 057506        END ;OF FOR R2
970 057516 012703 000200        MOV  #200,R3 ;DELAY FOR THE SLAVE TO SETUP HIS STACK
971 057522 077301 2$:        SOB  R3,2$
972 057524 012737 023542 002574   MOV  #2*SECONDS,HUNGTIME
973 057532 004737 072154 4$:        CALL  QUE
974 057536        ON.ERROR
975 057540 010037 002056        MOV  R0,BAD
976 057544 104060        ERROR  +60                    ;SLAVE HUNG SYSTEM.
977 057546 005037 003014        CLR  MULTIPOINT
978 057552 012737 002000 002706   MOV  #STACK,KSTACK
979 057560 000137 060746        JMP  MULTIEXIT
980 057564        END ;OF ON.ERROR
981 057564 005761 002616        TST  TASK(R1)
982 057570 100360        BPL  4$
983 057572        END ;OF FOR R0
984 057602        ELSE
985 057604 013700 002742        MOV  IISTVEC,R0
986 057610 012720 061216        MOV  #SLAVUP,(R0)+
987 057614 012710 000340        MOV  #340,(R0)
988 057620        FOR R0 := #0 TO #3
989 057622 005037 002670        CLR LOCK
990 057626 162737 000200 002706   SUB  #200,KSTACK
991 057634 012701 000001        MOV  #1,R1
992 057640 072100        ASH  R0,R1
993 057642 004737 061174        CALL  IISTOFF                    ;INIT IIST & DISABLE BOOTS & INTERRUPTS
994 057646 012777 000000 123062   MOV  #0,@IISTACR
995 057654 010177 123060        MOV  R1,@IISTADR                    ;INTERRUPT SOME CPU
996 057660 012777 000001 123052   MOV  #1,@IISTADR                    ;NOW!
997
998                ;WAIT FOR READY FLAG
999 057666 012737 061165 002574   MOV  #5*SECONDS,HUNGTIME
1000 057674 012777 000001 123034 6$:  MOV  #1,@IISTACR
1001 057702        ON.ERROR
1002 057704 104061        ERROR  +61                    ;IIST HUNG SYSTEM.
    
```

MULTIPOINT SLAVE STARTER

```

1003 057706 005037 003014
1004 057712 012737 002000 002706
1005 057720 000137 060746
1006 057724
1007 057724 032777 004000 123006
1008 057732 001760
1009 057734 012703 000200
1010 057740 077301 3$:
1011 057742
1012 057752
1013 057756 010001
1014 057760 006301
1015 057762 012737 061165 002574
1016 057770 004737 072154 5$:
1017 057774
1018 057776 010037 002056
1019 060002 104060
1020 060004 005037 003014
1021 060010 012737 002000 002706
1022 060016 000137 060746
1023 060022
1024 060022 005761 002616
1025 060026 100360
1026 060030
1027 060040
1028 060040 012737 002000 002706
1029

```

```

CLR      MULTIPOINT
MOV      #STACK,KSTACK
JMP      MULTIEXIT
END ;OF ON.ERROR
BIT      #BIT11,@IISTADR
BEQ      6$
MOV      #200,R3 ;DELAY FOR THE IIST TO REALLY BE READY
SOB      R3,3$ ;AND FOR SLAVE TO GO THRU VECTOR AND SETUP HIS STACK
END ;OF FOR RO
FOR RO := #1 TO SLAVES
MOV      RO,R1
ASL      R1
MOV      #5*SECONDS,HUNGTIME
CALL     QUE
ON.ERROR
MOV      RO,BAD
ERROR    +60 ;SLAVE HUNG SYSTEM.
CLR      MULTIPOINT
MOV      #STACK,KSTACK
JMP      MULTIEXIT
END ;OF ON.ERROR
TST      TASK(R1)
BPL      5$
END ;OF FOR RO
END ;OF IF NOIIST
MOV      #STACK,KSTACK
.DSABL   LSB

```


1032 060046

MAST02: SUBST <<HAVE SLAVES RUN CSR TESTS>>

:*****
:*SUBTEST HAVE SLAVES RUN CSR TESTS
:*****

1033

1034 060046 012737 000000 002676
 1035 060054 012777 177776 122706
 1036 060062 005037 002670
 1037 060066
 1038 060072 012701 000020
 1039 060076 072100
 1040 060100 010137 002114
 1041 060104 010001
 1042 060106 006301
 1043 060110 012761 000015 002616
 1044 060116 012737 000031 002572
 1045 060124 012737 177777 002574
 1046 060132 004737 072154
 1047 060136
 1048 060140 162737 000001 002572
 1049 060146
 1050 060150 010037 002056
 1051 060154 012737 000020 002114
 1052 060162 104060
 1053 060164 005037 003014
 1054 060170 000137 060746
 1055 060174
 1056 060174
 1057 060174 005761 002616
 1058 060200 100354
 1059 060202
 1060 060212 012737 000020 002114
 1061

```

.ENABL LSB
MOV #0,MDISPLAY ;LET SLAVES SHOW INDIVIDUAL CSR TESTS IN DISPLAY
MOV #-2,@DISPLAY ;FAKE OUT MASTER'S DISPLAY (NOT SLAVES)
CLR LOCK
FOR R0 := #1 TO SLAVES
  MOV #BIT4,R1
  ASH R0,R1
  MOV R1,CPUBIT
  MOV R0,R1
  ASL R1
  MOV #15,TASK(R1) ;RUN CSR TESTS COMMAND
  MOV #25.,HUNGMSB
  MOV #-1,HUNGTIME ;13 SECONDS
1$: CALL QUE
  ON.ERROR
  SUB #1,HUNGMSB
  ON.ERROR
  MOV RO,BAD
  MOV #MASTER,CPUBIT
  ERROR +60 ;SLAVE HUNG SYSTEM!
  CLR MULTIPOINT
  JMP MULTIEXIT
END ;OF ON.ERROR
END ;OF ON.ERROR
TST TASK(R1)
BPL 1$
END ;OF FOR R0
MOV #MASTER,CPUBIT ;SET UP AS MASTER AGAIN
.DSABL LSB

```

1064 060220

MAST03: SUBTST <<MOVE SLAVES TO THERE OWN BANKS>>

```

1065
1066 060220 012737 177775 002676
1067 060226 013777 002676 122534
1068 060234 005037 002670
1069 060240
1070 060244 012701 000020
1071 060250 072100
1072 060252 010137 002114
1073 060256
1074 060256
1075 060264 004737 042422
1076 060270
1077 060312 104511
1078 060314 010001
1079 060316 006301
1080 060320 012761 000001 002616
1081 060326 012737 061165 002574
1082 060334 004737 072154
1083 060340
1084 060342 010037 002056
1085 060346 012737 000020 002114
1086 060354 104060
1087 060356 005037 003014
1088 060362 000137 060746
1089 060366
1090 060366 005761 002616
1091 060372 100360
1092 060374 013701 002110
1093 060400 052761 100000 003016
1094 060406 042761 020000 003020
1095 060414
1096 060416
1097 060416
1098 060432 010037 002056
1099 060436 104062
1100
1101 060440 005037 003014
1102 060444 000137 060746
1103 060450
1104 060450
1105 060460 012737 002000 002706
1106
1107 060466 013737 002674 002766
1108
    
```

```

*****
; *SUBTEST      MOVE SLAVES TO THERE OWN BANKS
*****
.ENABL  LSB
MOV     #-3,MDISPLAY
MOV     MDISPLAY,@DISPLAY
CLR     LOCK
FOR RO := #1 TO SLAVES
    MOV  #BIT4,R1
    ASH  RO,R1
    MOV  R1,CPUBIT
    BEGIN MOVELOOP
        FOR BANK := #1 TO #167
            CALL EXBANK
            IF PFLAG IS FALSE AND ACFLAG IS TRUE AND BMFLAG IS FALSE
                INVALIDATE
                MOV     RO,R1
                ASL     R1           ;R1 = 2 OR 4 OR 6
                MOV     #1,TASK(R1) ;MOVE COMMAND
                MOV     #5*SECONDS,HUNGTIME
                CALL    QUE
                ON.ERROR
                    MOV     RO,BAD
                    MOV     #MASTER,CPUBIT
                    ERROR  +60      ;SLAVE HUNG SYSTEM
                    CLR     MULTIPOINT
                    JMP     MULTIEXIT
                END ;OF ON.ERROR
                TST     TASK(R1)
                BPL     1$
                MOV     BANKINDEX,R1
                BIS     #BIT15,CONFIG(R1)
                BIC     #BIT13,CONFIG+2(R1) ;INVALIDATE BACKGROUND PATTERN
                LEAVE MOVELOOP
            END ;OF IF PFLAG
        END ;CF FOR BANK
        MOV RO,BAD
        ERROR +62 ;NOT ENOUGH GOOD MEMORY TO TEST SLAVES
                    ;ABORTING MULTIPROCESSOR TESTS
    CLR MULTIPOINT
    JMP MULTIEXIT
    END MOVELOOP
END ;OF FOR RO
MOV     #STACK,KSTACK
;POINT THE MASTER BACK TO THE NORMAL SWR
MOV     MASWR,SWR
.DSABL  LSB
    
```

1\$:

1111 060474

```

SUBSTST <<RUN NORMAL MULTIPROCESSOR TESTS>>
:*****
:*SUBTEST      RUN NORMAL MULTIPROCESSOR TESTS
:*****
MOV      #MASTER,CPUBIT
BIS      #BIT4,ALLCPUS
FOR RO :- #1 TO SLAVES
  ASL    ALLCPUS
  BIS    #BIT4,ALLCPUS
END ;OF FOR RO
CALL    MAST04          ;ACCESS PATHS TEST
ON.ERROR
  CLR    MULTIPOINT
  JMP    MULTIEXIT
END ;OF ON.ERROR
CALL    MAST05          ;ADDRESS TEST
ON.ERROR
  CLR    MULTIPOINT
  JMP    MULTIEXIT
END ;OF ON.ERROR
CALL    MAST06          ;ASYNCHRONOUS ADDRESS UNIQUENESS TEST
ON.ERROR
  CLR    MULTIPOINT
  JMP    MULTIEXIT
END ;OF ON.ERROR
CALL    MAST07          ;SKEWED UP ADDRESS TEST
ON.ERROR
  CLR    MULTIPOINT
  JMP    MULTIEXIT
END ;OF ON.ERROR
CALL    MAST10         ;PORT ARBITRATION SYMMETRY TEST
ON.ERROR
  CLR    MULTIPOINT
  JMP    MULTIEXIT
END ;OF ON.ERROR
CALL    MAST11         ;I/O PRIORITY TEST
ON.ERROR
  CLR    MULTIPOINT
  JMP    MULTIEXIT
END ;OF ON.ERROR
CALL    MAST12         ;EXECUTION CONTENTION TEST
ON.ERROR
  CLR    MULTIPOINT
  JMP    MULTIEXIT
END ;OF ON.ERROR
CALL    MAST13         ;ASRB TEST
ON.ERROR
  CLR    MULTIPOINT
  JMP    MULTIEXIT
END ;OF ON.ERROR
CALL    MAST14         ;CACHE FLUSH TEST
ON.ERROR
  CLR    MULTIPOINT
  JMP    MULTIEXIT
END ;OF ON.ERROR
CALL    MAST15         ;STOP SLAVES
ON.ERROR
```

1112 060474 012737 000020 002114
1113 060502 052737 000020 002510
1114 060510
1115 060514 006337 002510
1116 060520 052737 000020 002510
1117 060526
1118 060536 004737 061322
1119 060542
1120 060544 005037 003014
1121 060550 000137 060746
1122 060554
1123 060554 004737 061706
1124 060560
1125 060562 005037 003014
1126 060566 000137 060746
1127 060572
1128 060572 004737 062270
1129 060576
1130 060600 005037 003014
1131 060604 000137 060746
1132 060610
1133 060610 004737 062550
1134 060614
1135 060616 005037 003014
1136 060622 000137 060746
1137 060626
1138 060626 004737 062776
1139 060632
1140 060634 005037 003014
1141 060640 000137 060746
1142 060644
1143 060644 004737 063260
1144 060650
1145 060652 005037 003014
1146 060656 000137 060746
1147 060662
1148 060662 004737 063732
1149 060666
1150 060670 005037 003014
1151 060674 000137 060746
1152 060700
1153 060700 004737 064200
1154 060704
1155 060706 005037 003014
1156 060712 000137 060746
1157 060716
1158 060716 004737 064204
1159 060722
1160 060724 005037 003014
1161 060730 000137 060746
1162 060734
1163 060734 004737 064472
1164 060740

```

1165 060742 005037 003014
1166 060746
1167 060746
1168 060754 004737 042422
1169 060760 013701 002110
1170 060764 042761 100000 003016
1171 060772
1172
*173
1174 061006 013737 002710 002:06
1175 061014 004737 042422
1176 061020 013701 002110
1177 061024 052761 100000 003016
*178
1179 061032 005037 002676
1180 061036 005077 121726
1181 061042
1182 061050 004737 015104
1183 061054
1184 061070 000137 014656

```

```

CLR MULTIPORT
END ;OF ON.ERROR
MULTIEXIT:FOR BANK := #1 TO #167
CALL EXBANK
MOV BANKINDEX,R1
BIC #BIT15,CONFIG(R1)
END ;OF FOR BANK

;MARK THE LOADERS AS PROTECTED AGAIN
MOV LOADHOME,BANK
CALL EXBANK
MOV BANKINDEX,R1
BIS #BIT15,CONFIG(R1)

CLR MDISPLAY
CLR @DISPLAY
SET WRITEONLY
CALL DOBACK ;REWRITE BACKGROUND PATTERN
CLEAR NOSCOPE,LOCK,WRITEONLY
JMP FLUSH

```

1187 061074

```
IISTINIT:SUBTST <<INITIALIZE THE IIST>>  
:*****  
:*SUBTEST INITIALIZE THE IIST  
:*****
```

1188

1189 061074 012777 100000 121634
1190 061102 012777 000005 121626
1191 061110 013777 002726 121622
1192 061116 013777 002726 121614
1193 061124 012737 061165 002574
1194 061132 012777 000001 121576 2\$:
1195 061140
1196 061150
1197 061152 104061
1198 061154 005037 003014
1199 061160 000207
1200 061162
1201 061162
1202 061162 032777 004000 121550
1203 061170 001760
1204 061172 000207
1205
1206
1207 061174

```
.ENABL LSB  
MOV #BIT15,@IISTACR  
MOV #5,@IISTACR  
MOV ONES,@IISTADR  
MOV ONES,@IISTADR  
MOV #5*SECONDS,HUNGTIME  
MOV #1,@IISTACR  
IF CPUBIT EQ #MASTER  
ON.ERROR  
ERROR +61 ;IIST HUNG SYSTEM.  
CLR MULTIPORT  
RETURN  
END ;OF ON.ERROR  
END ;OF IF CPUBIT  
BIT #BIT11,@IISTADR  
BEQ 2$  
RETURN  
.DSABL LSB
```

```
IISTOFF:SUBTST <<INIT IIST & DISABLE BOOTS & INTERRUPTS>>  
:*****  
:*SUBTEST INIT IIST & DISABLE BOOTS & INTERRUPTS  
:*****
```

1208 061174 004737 061074
1209 061200 012777 000004 121530
1210 061206 013777 002726 121524
1211 061214 000207
1212
1213 061216 013706 002706
1214 061222 004737 061244
1215 061226 104420
1216 061230 000237
1217 061232 052763 100000 002616
1218 061240 000137 050726

```
CALL IISTINIT  
MOV #4,@IISTACR  
MOV ONES,@IISTADR  
RETURN  
SLAVUP: MOV KSTACK,SP  
CALL SLAVEMAP  
ENERGIZE ;TURN ON MEMORY MANAGEMENT  
SPL 7  
BIS #BIT15,TASK(R3)  
JMP TASKDO
```

1221 061244

SLAVEMAP:SUBTST <<SLAVES MAP>>

.....
:*SUBTEST SLAVES MAP
.....

1222

:MAP KERNEL

1223 061244 104415
1224 061246 012700 002550
1225 061252 012701 172340
1226 061256 012702 077406
1227 061262 012703 172300
1228 061266 012705 000006
1229 061272 012021
1230 061274 010223
1231 061276 077503
1232 061300 012721 177400
1233 061304 010223
1234 061306 012711 177600
1235 061312 010213
1236 061314 104420
1237 061316 104416
1238 061320 000207

SAVREG
MOV #K10,R0
MOV #KIPAR0,R1
MOV #77406,R2
MOV #KIPDR0,R3
MOV #6,R5
1\$: MOV (R0)+,(R1)+
MOV R2,(R3)+
SOB R5,1\$
MOV #177400,(R1)+
MOV R2,(R3)+
MOV #177600,(R1)
MOV R2,(R3)
ENERGIZE
RESREG
RETURN

```

1241 061322
1242
1243 061322 012737 177774 002676
1244 061330 013777 002676 121432
1245 061336
1246 061340 010001
1247 061342 006301
1248 061344
1249 061352 013737 002510 002114
1250 061360 004737 042422
1251 061364 012737 000020 002114
1252 061372
1253 061406 104511
1254 061410
1255 061412 010502
1256 061414 000302
1257 061416 062702 000002
1258 061422 010261 002616
1259 061426
1260 061432
1261 061442 004737 050726
1262 061446
1263 061456
1264 061456 012737 061165 002574
1265 061464 004737 072154
1266 061470
1267 061472 010037 002056
1268 061476 104060
1269 061500
1270 061504
1271 061504 005761 002616
1272 061510 100365
1273 061512 062702 000001
1274 061516
1275 061520 010304
1276 061522 006304
1277 061524 010264 002616
1278 061530
1279 061540
1280 061552 004737 050726
1281 061556
1282 061570
1283 061572 010304
1284 061574 006304
1285 061576
1286 061602 012737 061165 002574
1287 061610 004737 072154
1288 061614
1289 061616 010337 002056
1290 061622 104060
1291 061624
1292 061630
1293 061630 005764 002616
1294 061634 100365
    
```

```

MAST04: SUBSTST <<MULTIPOINT ACCESS PATHS TEST>>
:*****
:*SUBTEST      MULTIPOINT ACCESS PATHS TEST
:*****
      .ENABL  LSB
      MOV    #-4,MDISPLAY
      MOV    MDISPLAY,@DISPLAY
      FOR R0 := #0 TO SLAVES
      MOV    R0,R1
      ASL    R1
      FOR BANK := #1 TO #167
      MOV    ALLCPUS,CPUBIT
      CALL   EXBANK
      MOV    #MASTER,CPUBIT
      IF PFLAG IS FALSE AND ACFLAG IS TRUE
      INVALIDATE
      FOR R5 := #0 TO #5 ;FOR PATTERNS 0-5
      MOV    R5,R2
      SWAB   R2
      ADD    #2,R2          ;WRITE ONLY PATTERN COMMAND
      MOV    R2,TASK(R1)   ;SET TASK ORDER
      IF R1 EQ #0
      PUSH   R0,R1,R2,R5
      CALL   TASKDO
      POP    R5,R2,R1,R0
      END ;OF IF R1
      MOV    #5*SECONDS,HUNGTIME
      CALL   QUE
      ON.ERROR
      MOV    R0,BAD
      ERROR +60           ;SLAVE HUNG SYSTEM.
      $RETURN ERROR
      END ;OF ON.ERROR
      TST    TASK(R1)
      BPL    1$
      ADD    #1,R2          ;CHANGE ORDER TO READ ONLY
      FOR R3 := #0 TO SLAVES
      MOV    R3,R4
      ASL    R4
      MOV    R2,TASK(R4)
      END ;OF FOR R3
      PUSH   R0,R1,R3,R4,R5
      CALL   TASKDO
      POP    R5,R4,R3,R1,R0
      FOR R3 := #0 TO SLAVES
      MOV    R3,R4
      ASL    R4
      IF R4 NE R1
      MOV    #5*SECONDS,HUNGTIME
      CALL   QUE
      ON.ERROR
      MOV    R3,BAD
      ERROR +60           ;SLAVE HUNG SYSTEM.
      $RETURN ERROR
      END ;OF ON.ERROR
      TST    TASK(R4)
      BPL    2$
    
```

1295 061636
1296 061636
1297 061646
1298 061656
1299 061656
1300 061672
1301 061702
1302

END ;OF IF R4
END ;OF FOR R3
END ;OF FOR R5
END ;OF IF PFLAG
END ;OF FOR BANK
END ;OF FOR R0
\$RETURN NOERROR
.DSABL LSB

1306 061706

MAST05: SUBTST <<MULTIPORT ADDRESS TEST>>

1307

```

1308 061706 012737 177773 002676
1309 061714 013777 002676 121046
1310 061722
1311 061724 010001
1312 061726 006301
1313 061730
1314 061736 013737 002510 002114
1315 061744 004737 042422
1316 061750 012737 000020 002114
1317 061756
1318 061772
1319 061774 010502
1320 061776 000302
1321 062000 062702 000007
1322 062004 010261 002616
1323 062010
1324 062014
1325 062024 004737 050726
1326 062030
1327 062040
1328 062040 012737 061165 002574
1329 062046 004737 072154
1330 062052
1331 062054 010037 002056
1332 062060 104060
1333 062062
1334 062066
1335 062066 005761 002616
1336 062072 100365
1337 062074 062702 000001
1338 062100
1339 062102 010304
1340 062104 006304
1341 062106 010264 002616
1342 062112
1343 062122
1344 062134 004737 050726
1345 062140
1346 062152
1347 062154 010304
1348 062156 006304
1349 062160
1350 062164 012737 061165 002574
1351 062172 004737 072154
1352 062176
1353 062200 010337 002056
1354 062204 104060
1355 062206
1356 062212
1357 062212 005764 002616
1358 062216 100365
1359 062220
    
```

```

:*****
: *SUBTEST      MULTIPORT ADDRESS TEST
:*****
    
```

```

      .ENABL  LSB
      MOV    #-5,MDISPLAY
      MOV    MDISPLAY,@DISPLAY
      FOR R0 := #0 TO SLAVES
      MOV    R0,R1
      ASL   R1
      FOR BANK := #1 TO #167
      MOV ALLCPUS,CPUBIT
      CALL  EXBANK
      MOV #MASTER,CPUBIT
      IF PFLAG IS FALSE AND ACFLAG IS TRUE
      FOR R5 := #0 TO #1 ;FOR ADDRESS & COMPLEMENT ADDRESS PATTERNS
      MOV    R5,R2
      SWAB  R2
      ADD   #7,R2           ;WRITE ONLY ADDRESS PATTERN
      MOV   R2,TASK(R1)    ;SET TASK ORDER
      IF R1 EQ #0
      PUSH  R0,R1,R2,R5
      CALL  TASKDO
      POP   R5,R2,R1,R0
      END ;OF IF R1
      MOV  #5*SECONDS,HUNGTIME
      CALL  QUE
      ON .ERROR
      MOV  R0,BAD
      ERROR +60           ;SLAVE HUNG SYSTEM
      $RETURN ERROR
      END ;OF ON.ERROR
      TST  TASK(R1)
      BPL  1$
      ADD  #1,R2           ;CHANGE ORDER TO READ ADDRESS PATTERNS ONLY
      FOR R3 := #0 TO SLAVES
      MOV  R3,R4
      ASL  R4
      MOV  R2,TASK(R4)
      END ;OF FOR R3
      PUSH R0,R1,R3,R4,R5
      CALL TASKDO
      POP  R5,R4,R3,R1,R0
      FOR R3 := #0 TO SLAVES
      MOV  R3,R4
      ASL  R4
      IF R4 NE R1
      MOV #5*SECONDS,HUNGTIME
      CALL  QUE
      ON .ERROR
      MOV  R3,BAD
      ERROR +60           ;SLAVE HUNG SYSTEM.
      $RETURN ERROR
      END ;OF ON.ERROR
      TST  TASK(R4)
      BPL  2$
      END ;OF IF R4
    
```

1360 062220
1361 062230
1362 062240
1363 062240
1364 062254
1365 062264
1366

END ;OF FOR R3
END ;OF FOR R5
END ;OF IF PFLAG
END ;OF FOR BANK
END ;OF FOR R0
\$RETURN NOERROR
.DSABL LSB

```

1369 062270
1370
1371 062270 012737 177772 002676
1372 062276 013777 002676 120464
1373 062304
1374 062312 013737 002510 002114
1375 062320 004737 042422
1376 062324 012737 000020 002114
1377 062332
1378 062346
1379 062350 010003
1380 062352 072327 000015
1381 062356 062703 060000
1382 062362
1383 062364 062703 020000
1384 062370
1385 062402
1386 062404 000241
1387 062406 006003
1388 062410 010201
1389 062412 006301
1390 062414 062703 000011
1391 062420 010361 002616
1392 062424
1393 062426
1394 062436
1395 062440 004737 050726
1396 062444
1397 062446
1398 062450 010201
1399 062452 006301
1400 062454 012737 061165 002574
1401 062462 004737 072154 1$:
1402 062466
1403 062470 010237 002056
1404 062474 104060
1405 062476
1406 062502
1407 062502 005761 002616
1408 062506 100365
1409 062510
1410 062520
1411 062530
1412 062530
1413 062544
1414

```

```

MAST06: SUBTST <<MULTIPOINT ASYNCHRONOUS ADDRESS UNIQUENESS TEST>>
:*****
: *SUBTEST MULTIPOINT ASYNCHRONOUS ADDRESS UNIQUENESS TEST
:*****
.ENABL LSB
MOV #6,MDISPLAY
MOV MDISPLAY,@DISPLAY
FOR BANK := #1 TO #167
MOV ALLCPUS,CPUBIT
CALL EXBANK
MOV #MASTER,CPUBIT
IF PFLAG IS FALSE AND AFLAG IS TRUE
FOR R0 := #0 TO #3 ;R0 := STARTING ADDRESS INDEX
MOV R0,R3
ASH #13,R3
ADD #FIRST,R3
FOR R2 := #0 TO SLAVES
ADD #SIZE/2,R3
IF R3 EQ #LAST+2 THEN LET R3 := #FIRST
PUSH R3
CLC
ROR R3
MOV R2,R1
ASL R1 ;R1 := SLAVE #
ADD #11,R3
MOV R3,TASK(R1) ;ORDER FOR ASYNCHRONOUS ADD UNIQUE TEST
POP R3
END ;OF FOR R2
PUSH R0
CALL TASKDO ;MASTER ASSUMES THE SLAVES ROLE
POP R0
FOR R2 := #0 TO SLAVES
MOV R2,R1
ASL R1
MOV #5*SECONDS,HUNGTIME
CALL QUE
ON.ERROR
MOV R2,BAD
ERROR +60 ;SLAVE HUNG SYSTEM!
$RETURN ERROR
END ;OF ON.ERROR
TST TASK(R1)
BPL 1$
END ;OF FOR R2
END ;OF FOR R0
END ;OF IF PFLAG
END ;OF FOR BANK
$RETURN NOERROR
.DSABL LSB

```

1417 062550

```

MAST07: SUBTST <<MULTIPORT SKEWED UP ADDRESS TEST>>
:*****
:*SUBTEST     MULTIPORT SKEWED UP ADDRESS TEST
:*****
    
```

```

1418
1419 062550 012737 177771 002676
1420 062556 013777 002676 120204
1421 062564
1422 062572 013737 002510 002114
1423 062600 004737 042422
1424 062604 012737 000020 002114
1425 062612
1426 062626
1427 062630
1428 062632 010001
1429 062634 006301
1430 062636 010203
1431 062640 000303
1432 062642 062703 000012
1433 062646 010361 002616
1434 062652
1435 062662
1436 062664 004737 050726
1437 062670
1438 062672
1439 062674 010001
1440 062676 006301
1441 062700 012737 061165 002574
1442 062706 004737 072154
1443 062712
1444 062714 010037 002056
1445 062720 104060
1446 062722
1447 062726
1448 062726 005761 002616
1449 062732 100365
1450 062734
1451 062744
1452 062756
1453 062756
1454 062772
1455
    
```

```

        .ENABL  LSB
        MOV     #-7,MDISPLAY
        MOV     MDISPLAY,@DISPLAY
        FOR BANK := #1 TO #167
        MOV     ALLCPUS,CPUBIT
        CALL    EXBANK
        MOV     #MASTER,CPUBIT
        IF PFLAG IS FALSE AND ACFLAG IS TRUE
        FOR R2 := #0 TO #6 BY #2
        FOR R0 := #0 TO SLAVES
        MOV     R0,R1
        ASL    R1
        MOV     R2,R3
        SWAB   R3
        ADD    #12,R3
        MOV     R3,TASK(R1)
        END ;OF FOR R0
        PUSH   R2
        CALL   TASKDO
        POP    R2
        FOR R0 :- #0 TO SLAVES
        MOV     R0,R1
        ASL    R1
        MOV     #5*SECONDS,HUNGTIME
        CALL   QUE
        ON.ERROR
        MOV     R0,BAD
        ERROR  +60
        $RETURN ERROR
        END ;OF ON.ERROR
        TST    TASK(R1)
        BPL    1$
        END ;OF FOR R0
        END ;OF FOR R2
        END ;OF IF PFLAG
        END ;OF FOR BANK
        $RETURN NOERROR
        .DSABL  LSB
    
```

;ADDRESS OFFSET (0,2,4,6)

;ORDER SKEWED UP ADDRESS TEST

;SLAVE HUNG SYSTEM!

1\$:

1458 062776

1459
1460 062776
1461 063010 012737 177770 002676
1462 063016 013777 002676 117744
1463 063024
1464 063032 013737 002510 002114
1465 063040 004737 042422
1466 063044 012737 000020 002114
1467 063052
1468 063066
1469 063070 010001
1470 063072 006301
1471 063074 012761 000405 002616
1472 063102
1473 063112 004737 050726
1474 063116
1475 063120 010001
1476 063122 006301
1477 063124 012737 061165 002574
1478 063132 004737 072154 1\$:
1479 063136
1480 063140 010037 002056
1481 063144 104060
1482 063146
1483 063152
1484 063152 005761 002616
1485 063156 100365
1486 063160
1487 063170
1488 063170
1489 063172 010001
1490 063174 006301
1491 063176 013702 002646
1492 063202 166102 002646
1493 063206 062702 000006
1494 063212
1495 063224 104036
1496 063226
1497 063230
1498 063230
1499 063240
1500 063240
1501 063240
1502 063254
1503

```

MAST10: SUBST <<MULTIPOINT PORT ARBITRATION SYMMETRY TEST>>
:*****
:*SUBTEST MULTIPOINT PORT ARBITRATION SYMMETRY TEST
:*****
.ENABL LSB
IF NOCLOCK IS TRUE THEN $RETURN NOERROR
MOV #-10,MDISPLAY
MOV MDISPLAY,@DISPLAY
FOR BANK := #1 TO #167
MOV ALLCPUS,CPUBIT
CALL EXBANK
MOV #MASTER,CPUBIT
IF PFLAG IS FALSE AND ACFLAG IS TRUE
FOR R0 := #0 TO SLAVES
MOV R0,R1
ASL R1
MOV #405,TASK(R1) ;ORDERS FOR PORT ARBITRATION SYMMETRY TEST
END ;OF FOR R0
CALL TASKDO
FOR R0 := #0 TO SLAVES
MOV R0,R1
ASL R1
MOV #5*SECONDS,HUNGTIME
CALL QUE
ON.ERROR
MOV R0,BAD
ERROR +60 ;SLAVE HUNG SYSTEM!
$RETURN ERROR
END ;OF ON.ERROR
TST TASK(R1)
BPL 1$
END ;OF FOR R0
BEGIN BALANCE
FOR R0 := #0 TO SLAVES
MOV R0,R1
ASL R1
MOV PORTCOUNT,R2
SUB PORTCOUNT(R1),R2
ADD #6,R2 ;SPECKED FOR + OR - 6 - 5%
IF R2 LT #0 OR R2 GT #12.
ERROR +36
LEAVE BALANCE
END ;OF IF R2
END ;OF FOR R0
END BALANCE
END ;OF IF PFLAG
END ;OF FOR BANK
$RETURN NOERROR
.DSABL LSB

```

1506 063260

MAST11: SUBTST <<MULTIPOINT PORT I/O PRIORITY TEST>>

:SUBTEST MULTIPOINT PORT I/O PRIORITY TEST

1507

:THIS TESTS THE ABILITY OF THE MEMORY PORT TO GIVE I/O HIGHER
:PRIORITY THEN CPU ACCESSES

1508

1509

1510

:IT DOES THIS BY USING MARGIN #6 IN THE CPU'S MAINT REGISTER
:TO RAISE THE CPU PRIORITY TO THAT OF I/O.

1511

1512

:EACH CPU (EXCEPT ONE) HAS HIS PRIORITY RAISED AND
:A TEST IS PERFORMED TO INSURE THAT THESE CPUS ARE GRANTED MORE
:CYCLES THEN THE OTHER CPU.

1513

1514

1515

1516

:NEED LINE CLOCK
IF NOCLOCK IS TRUE THEN \$RETURN NOERROR

1517

1518 063260

1519

:CAN'T DO UNLESS 4 CPU'S
IF SLAVES LT #3 THEN \$RETURN NOERROR

1520

1521 063272

1522

1523 063306 012737 177767 002676

MOV #-11,MDISPLAY
MOV MDISPLAY,@DISPLAY

1524 063314 013777 002676 117446

```

1527
1528 063322
1529 063330 013737 002510 002114
1530 063336 004737 042422
1531 063342 012737 000020 002114
1532 063350 013701 002110
1533 063354
1534 063364
1535
1536
1537 063400
1538 063404
1539 063410
1540 063420 013701 002604
1541 063424 006301
1542 063426 012761 000016 002616
1543 063434
1544 063442 004737 050726
1545 063446
1546 063450 004737 063674
1547 063454
1548 063454
1549 063454
1550
1551
1552 063470
1553 063472 010001
1554 063474 006301
1555 063476 012761 000005 002616
1556 063504
1557 063514 004737 050726
1558
1559
1560 063520
1561 063522 010001
1562 063524 006301
1563 063526 004737 063674
1564 063532
1565
1566
1567 063542 004737 063602
1568 063546
1569 063562
1570 063562
1571 063562
1572 063576

```

```

;FOR EACH BANK THAT IS ACCESSABLE BY ALL CPU'S
FOR BANK := #1 TO #167
MOV ALLCPUS,CPUBIT
CALL EXBANK
MOV #MASTER,CPUBIT
MOV BANKINDEX,R1
IF #BITS OFF.IN CONFIG(R1) ;IF NO EXTERNAL INTERLEAVE
IF PFLAG IS FALSE AND ACFLAG IS TRUE

;EACH CPU HAS LOW PRIORITY ONCE
FOR I := #0 TO SLAVES
FOR J := #0 TO SLAVES
IF I NE J ;IF NOT THE LOW PRIORITY CPU
MOV J,R1
ASL R1
MOV #16,TASK(R1) ;ORDER MARGIN #6
IF J EQ #0
CALL TASKDO
ELSE
CALL WAITS
END ;OF IF J EQ #0
END ;OF IF I NE J
END ;OF FOR J := #0 TO SLAVES

;EVERY CPU WILL DO PORT ARBITRATION TEST
FOR RO := #0 TO SLAVES
MOV RO,R1
ASL R1
MOV #5,TASK(R1) ;ORDER PORT ARBITRATION TEST
END ;OF FOR RO
CALL TASKDO

;WAIT FOR DONE
FOR RO := #0 TO SLAVES
MOV RO,R1
ASL R1
CALL WAITS
END ;OF FOR RO

;CHECK RESULTS FOR PROPER SKEWING
CALL MST11A
END ;OF FOR I := #0 TO SLAVES
END ;OF IF PFLAG
END ;OF IF #BITS OFF.IN CONFIG(R1)
END ;OF FOR BANK
$RETURN NOERROR

```

1575 063602

1576 063602
1577
1578 063602
1579 063604 010001
1580 063606 006301
1581 063610 013703 002602
1582 063614 006303
1583 063616 016302 002646
1584 063622 016104 002646
1585 063626 160402
1586 063630 006204
1587 063632 006204
1588 063634 006204
1589 063636
1590 063644
1591 063650 013737 002602 002056
1592 063656 104066
1593 063660
1594 063662
1595 063662
1596 063662
1597 063672
1598 063672 000207
1599
1600 063674

```
MST11A: SUBST <<CHECK FOR PROPER SKEWING OF ACCESSES>>
:*****
:*SUBTEST CHECK FOR PROPER SKEWING OF ACCESSES
:*****
BEGIN NOBALANCE
;FOR EACH CPU
FOR R0 := #0 TO SLAVES
MOV R0,R1
ASL R1
MOV I,R3
ASL R3
MOV PORTCOUNT(R3),R2 ;LOW PRIORITY PORT
MOV PORTCOUNT(R1),R4 ;HIGH PRIORITY PORT
SUB R4,R2
ASR R4
ASR R4
ASR R4 ;R4 = 12.5% OF HIGH PRIORITY PORT
IF R0 NE I ;IF THE CPU SELECTED IS NOT THE LOW PRIORITY ONE
IF R2 LT R4
MOV I,BAD
ERROR +66
LEAVE NOBALANCE
END ;OF IF R2
END ;OF IF R0 NE I
END ;OF FOR R0
END NOBALANCE
RETURN
```

1601
1602 063674 012737 061165 002574
1603 063702 004737 072154
1604 063706
1605 063710 010037 002056
1606 063714 104060
1607 063716
1608 063722
1609 063722 005761 002616
1610 063726 100365
1611 063730 000207
1612

```
WAIT5: SUBST <<WAIT FOR 5 SECONDS FOR A SLAVE>>
:*****
:*SUBTEST WAIT FOR 5 SECONDS FOR A SLAVE
:*****
.ENABL LSB
MOV #5*SECONDS,HUNGTIME
1$: CALL QUE
ON.ERROR
MOV R0,BAD
ERROR +60 ;SLAVE HUNG SYSTEM!
$RETURN ERROR
END ;OF ON.ERROR
TST TASK(R1)
BPL 1$
RETURN
.DISABL LSB
```


1615 063732

1616

1617 063732 012737 177766 002676

1618 063740 013777 002676 117022

1619 063746

1620 063754 013737 002510 002114

1621 063762 004737 042422

1622 063766 012737 000020 002114

1623 063774

1624 064010 004737 053640

1625 064014

1626 064016 010001

1627 064020 006301

1628 064022 005061 002636

1629 064026 012761 000004 002616

1630 064034

1631 064044 004737 050726

1632 064050

1633 064052 010001

1634 064054 006301

1635 064056 012737 061165 002574

1636 064064 004737 072154 1\$:

1637 064070

1638 064072 010037 002056

1639 064076 104060

1640 064100

1641 064104

1642 064104 005761 002616

1643 064110 100365

1644 064112

1645 064122

1646 064122

1647 064124 010001

1648 064126 006301

1649 064130 013702 002636

1650 064134 166102 002636

1651 064140

1652 064144 104052

1653 064146

1654 064150

1655 064150

1656 064160

1657 064160

1658 064160

1659 064174

1660

1661

1662 064200

```

MAST12: SUBTST <<MULTIPOINT EXECUTION CONTENTION TEST>>
:*****
:*SUBTEST MULTIPOINT EXECUTION CONTENTION TEST
:*****
.ENABL LSB
MOV #-12,MDISPLAY
MOV MDISPLAY,@DISPLAY
FOR BANK := #1 TO #167
MOV ALLCPUS,CPUBIT
CALL EXBANK
MOV #MASTER,CPUBIT
IF PFLAG IS FALSE AND ACFLAG IS TRUE
CALL MRUNSETUP
FOR RO := #0 TO SLAVES
MOV RO,R1
ASL R1
CLR PTYBUF(R1) ;CLEAR INC COUNTER
MOV #4,TASK(R1) ;ORDER FOR EXECUTION CONTENTION TEST
END ;OF FOR RO
CALL TASKDO
FOR RO := #0 TO SLAVES
MOV RO,R1
ASL R1
MOV #5*SECONDS,HUNGTIME
CALL QUE
ON.ERROR
MOV RO,BAD
ERROR +60 ;SLAVE HUNG SYSTEM!
$RETURN ERROR
END ;OF ON.ERROR
TST TASK(R1)
BPL 1$
END ;OF FOR RO
BEGIN RUNCOUNT
FOR RO := #0 TO SLAVES
MOV RO,R1
ASL R1
MOV PTYBUF,R2
SUB PTYBUF(R1),R2
IF R2 NE #0
ERROR +52
LEAVE RUNCOUNT
END ;OF IF R2
END ;OF FOR RO
END RUNCOUNT
END ;OF IF PFLAG
END ;OF FOR BANK
$RETURN NOERROR
.DSABL LSB
    
```

1663 064200 000137 053752

```

MAST13: SUBTST <<MULTIPOINT ASRB TEST>>
:*****
:*SUBTEST MULTIPOINT ASRB TEST
:*****
JMP SUPM13 ;ACTUAL ROUTINE MUST BE IN SUPERVISOR SPACE
    
```

1666 064204

1667
1668
1669
1670 064204
1671 064224
1672 064230
1673
1674 064230 012737 177764 002676
1675 064236 013777 002676 116524
1676
1677 064244
1678 064246 010001
1679 064250 006301
1680 064252
1681 064260 013737 002510 002114
1682 064266 004737 042422
1683 064272 012737 000020 002114
1684 064300
1685 064314
1686 064316 010304
1687 064320 006304
1688 064322
1689 064326 012764 000020 002616
1690 064334
1691 064336 012764 000017 002616
1692 064344
1693 064344
1694 064354
1695 064360 004737 050726
1696 064364
1697 064370
1698 064372 010304
1699 064374 006304
1700 064376 012737 061165 002574
1701 064404 004737 072154 2\$:
1702 064410
1703 064412 010337 002056
1704 064416 104060
1705 064420
1706 064424
1707 064424 005764 002616
1708 064430 100365
1709 064432
1710 064442
1711 064442
1712 064456
1713 064466
1714

```
MAST14: SUBTST <<MULTIPOINT CACHE FLUSH TEST>>
:*****
:*SUBTEST MULTIPOINT CACHE FLUSH TEST
:*****
:WARNING FAILURES HERE ARE USUALLY DUE TO A CACHE PROBLEM
:NOT A MAIN MEMORY PROBLEM.....
.ENABL LSB
IF #BIT3 SET.IN CACHK OR #BIT2 SET.IN CACHK
$RETURN NOERROR ;OPERATOR HAS DISABLED PART OF CACHE
END ;OF IF #BIT3

MOV #-14,MDISPLAY
MOV MDISPLAY,@DISPLAY

FOR R0 := #0 TO SLAVES
MOV R0,R1
ASL R1
FOR BANK :- #1 TO #167
MOV ALLCPUS,CPUBIT
CALL EXBANK
MOV #MASTER,CPUEIT
IF PFLAG IS FALSE AND ACFLAG IS TRUE
FOR R3 := #0 TO SLAVES
MOV R3,R4
ASL R4
IF R4 EQ R1
MOV #20,TASK(R4) ;CACHE FLUSH TEST COMMAND
ELSE
MOV #17,TASK(R4) ;CREATE STALE DATA COMMAND
END ;OF IF R4
END ;OF FOR R3
PUSH R0,R1
CALL TASKDO
POP R1,R0
FOR R3 := #0 TO SLAVES
MOV R3,R4
ASL R4
MOV #5*SECONDS,HUNGTIME
CALL QUE
ON.ERROR
MOV R3,BAD
ERROR +60 ;SLAVE HUNG SYSTEM!
$RETURN ERROR
END ;OF ON.ERROR
TST TASK(R4)
BPL 2$
END ;OF FOR R3
END ;OF IF PFLAG
END ;OF FOR BANK
END ;OF FOR R0
$RETURN NOERROR
.DSABL LSB
```

1717 064472

MAST15: SUBST <<STOP SLAVES>>
:.....
:*SUBTEST STOP SLAVES
:.....

1718
1719 064472 012737 177763 002676
1720 064500 013777 002676 116262
1721 064506
1722 064512 010001
1723 064514 006301
1724 064516 012761 000006 002616
1725 064524 012737 023542 002574
1726 064532 004737 072154
1727 064536
1728 064540 010037 002056
1729 064544 104060
1730 064546
1731 064552
1732 064552 005761 002616
1733 064556 100365
1734 064560
1735 064570
1736

.ENABL LSB
MOV #-15,MDISPLAY
MOV MDISPLAY,@DISPLAY
FOR RO := #1 TO SLAVES
MOV RO,R1
ASL R1
MOV #6,TASK(R1) ;ORDER STOP TASK
MOV #2*SECONDS,HUNGTIME
1\$: CALL QUE
ON.ERROR
MOV RO,BAD
ERROR +60 ;SLAVE HUNG SYSTEM!
\$RETURN ERROR
END ;OF ON.ERROR
TST TASK(R1)
BPL 1\$
END ;OF FOR RO
\$RETURN NOERROR
.DSABI LSB

ERROR DATA SETUP

1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795

```
.SBTTL ERROR DATA SETUP
USE THIS      IF THIS CONDITION DESCRIBES THE ERROR
PERR01        TRAP
                BAD DATA IN R0 UNLESS ABORTED
                THEN BAD DATA IS POINTED TO BY -(R4)
                GOOD DATA IN R5
PERR02        TRAP
                BAD DATA IN R1 UNLESS ABORTED
                THEN BAD DATA IS POINTED TO BY -(R4)
                GOOD DATA IN R2
PERR03        TRAP
                BAD DATA IS POINTED TO BY -(R1)
                GOOD DATA IN R4
PERR04        TRAP
                BAD DATA IN R4 UNLESS ABORTED
                THEN BAD DATA IS POINTED TO BY -2(R0)
                GOOD DATA IN R2
PERR05        JSR      PC
                BAD DATA IS POINTED TO BY -(R0)
                GOOD DATA IN R2
                RETURN AFTER SETTING UP GOOD,BAD,ADDRESS
PERR06        JSR      PC
                BAD DATA IS POINTED TO BY -(R0)
                GOOD DATA IS ZERO
                RETURN AFTER SETTING UP GOOD,BAD,ADDRESS
PERR07        TRAP
                BAD DATA IN R2 UNLESS ABORTED
                THEN BAD DATA IS POINTED TO BY (R1)
                GOOD DATA IN DATBUF
PERR10        TRAP
                BAD DATA IN R2 UNLESS ABORTED
                THEN BAD DATA IS POINTED TO BY 2(R1)
                GOOD DATA IN DATBUF+2
PERR11        TRAP
                BYTE TEST
                BAD DATA IN RIGHT BYTE OF R0 UNLESS ABORTED
                THEN BAD DATA IS POINTED TO BY (R1)
                GOOD DATA IS A ZERO BYTE
PERR12        TRAP
                BYTE TEST
                BAD DATA IN RIGHT BYTE OF R0 UNLESS ABORTED
                THEN BAD DATA IS POINTED TO BY (R1)
                GOOD DATA IS A BYTE OF ONES
PERR13        TRAP
                BAD DATA IN R0 UNLESS ABORTED
```



```
1853  
1854  
1855  
1856  
1857  
1858  
1859  
1860  
1861  
1862  
1863  
1864  
1865  
1866  
1867  
1868  
1869  
1870  
1871  
1872  
1873  
1874  
1875  
1876  
1877  
1878  
1879  
1880
```

CALLING SEQUENCE FOR TRAP TYPES
BEQ 2\$;NO - ERROR,BRANCH FOR CARD
PERRXX ;TRAP TO ERROR ROUTINE
NEXT INSTRUCTION ;CONTINUE TESTING

```
..... PERR27 TRAP  
BAD DATA IS DOUBLE WORD POINTED TO BY R1 AND IN LOW 7 BITS OF R0  
GOOD DATA IS 000000,,000000,,077  
..... PERR30 TRAP  
BAD DATA IS POINTED TO BY -16(SP)  
GOOD DATA IS IN R1  
..... PERR31 TRAP  
SPECIAL ECC FAILURE HANDLER  
..... PERR32 TRAP  
SPECIAL ECC FAILURE HANDLER  
..... PERR33 TRAP  
SPECIAL ECC FAILURE HANDLER  
..... PERR34 TRAP  
SPECIAL ECC FAILURE HANDLER  
..... PERR35 TRAP  
SPECIAL BRANCH GOBBLE FAILURE HANDLER
```

```

1883 064574 010437 002040          $PER01: MOV    R4,ADDRESS
1884 064600 162737 000002 002040    SUB    #2,ADDRESS
1885 064606 010037 002056          MOV    R0,BAD
1886 064612 010537 002050          MOV    R5,GOOD
1887 064616 000137 065330          JMP   PERRAW
1888
1889 064622 010437 002040          $PER02: MOV    R4,ADDRESS
1890 064626 162737 000002 002040    SUB    #2,ADDRESS
1891 064634 010137 002056          MOV    R1,BAD
1892 064640 010237 002050          MOV    R2,GOOD
1893 064644 000137 065330          JMP   PERRAW
1894
1895 064650 010137 002040          $PER03: MOV    R1,ADDRESS
1896 064654 162737 000002 002040    SUB    #2,ADDRESS
1897 064662 010437 002050          MOV    R4,GOOD
1898 064666 016137 177776 002056    MOV    -2(R1),BAD
1899 064674 000137 065330          JMP   PERRAW
1900
1901 064700 010037 002040          $PER04: MOV    R0,ADDRESS
1902 064704 162737 000002 002040    SUB    #2,ADDRESS
1903 064712 010437 002056          MOV    R4,BAD
1904 064716 010237 002050          MOV    R2,GOOD
1905 064722 000137 065330          JMP   PERRAW
1906
1907 064726 010237 002050          PERR05: MOV    R2,GOOD
1908 064732 014037 002056          PERRA05: MOV   -(R0),BAD
1909 064736 010037 002040          MOV    R0,ADDRESS
1910 064742 062700 000002          ADD    #2,R0          ;RESTORE R0
1911 064746 004737 036770          CALL  BADSTACK
1912 064752 000207          RETURN
1913
1914 064754 005037 002050          PERR06: CLR    GOOD
1915 064760 000764          BR     PERRA05
1916
1917 064762 010137 002040          $PER07: MOV    R1,ADDRESS
1918 064766 010237 002056          MOV    R2,BAD
1919 064772 013737 002340 002050    MOV    DATBUF,GOOD
1920 065000 000137 065330          JMP   PERRAW
1921
1922 065004          $PER10: LET ADDRESS := R1 + #2
1923 065016          LET BAD := R2
1924 065022          LET GOOD := DATBUF+2
1925 065030 000137 065330          JMP   PERRAW
1926
1927 065034          $PER11: LET ADDRESS := R1
1928 065040          LET BAD := R0
1929 065044          LET GOOD := #0
1930 065050 000137 065402          JMP   PERRAB
1931
1932 065054          $PER12: LET ADDRESS := R1
1933 065060          LET BAD := R0
1934 065064          LET GOOD := #377
1935 065072 000137 065402          JMP   PERRAB
    
```

1938 065076
1939 065102
1940 065106
1941 065112 000137 065330
1942
1943 065116
1944 065122
1945 065126
1946 065134 000137 065330
1947
1948 065140
1949 065144
1950 065150
1951 065156 000137 065330
1952
1953 065162
1954 065166
1955 065172
1956 065200 000453
1957
1958 065202
1959 065206
1960 065212
1961 065216 000444
1962
1963 065220
1964 065224
1965 065230
1966 065234 000435
1967
1968 065236
1969 065242
1970 065246
1971 065254 000477
1972
1973 065256
1974 065262
1975 065266
1976 065272 000416
1977
1978 065274
1979 065300
1980 065304
1981 065310 000407
1982
1983 065312
1984 065316
1985 065322
1986 065326 000400

\$PER13: LET ADDRESS := R1
LET BAD := R0
LET GOOD := #0
JMP PERRAW

\$PER14: LET ADDRESS := R1
LET BAD := R0
LET GOOD := ONES
JMP PERRAW

\$PER15: LET ADDRESS := R1
LET BAD := R0
LET GOOD := TSTDAT
JMP PERRAW

\$PER16: LET ADDRESS := R1
LET BAD := R0
LET GOOD := TSTDAT+2
BR PERRAW

\$PER17: LET ADDRESS := R1
LET BAD := R0
LET GOOD := R2
BR PERRAW

\$PER20: LET ADDRESS := R1
LET BAD := R0
LET GOOD := R3
BR PERRAW

\$PER21: LET ADDRESS := R1
LET BAD := R0
LET GOOD := #177
BR PERRAW

\$PER22: LET ADDRESS := R1
LET BAD := R2
LET GOOD := R0
BR PERRAW

\$PER23: LET ADDRESS := R1
LET BAD := R0
LET GOOD := R4
BR PERRAW

\$PER24: LET ADDRESS := R2
LET BAD := R0
LET GOOD := R3
BR PERRAW

1988 065330
1989 065330 004737 065564
1990 065334
1991 065346
1992 065360 004737 065540
1993 065364
1994 065372 104011
1995 065374
1996 065376 104012
1997 065400
1998 065400 000002
1999
2000 065402

```
PERRAW: SUBTST <<DATA WAS A WORD>>  
:*****  
:*SUBTEST DATA WAS A WORD  
:*****  
CALL PERBANK  
IF ABORTFLAG IS TRUE THEN $CALL GETDATA  
IF BADPC EQ #0 THEN $CALL BADSTACK  
CALL PERXOR  
IF ABORTFLAG IS FALSE  
ERROR +11  
ELSE  
ERROR +12  
END ;OF IF ABORTFLAG  
RTI
```

2001 065402 004737 065564
2002 065406
2003 065420
2004 065432 004737 065540
2005 065436
2006 065444 104014
2007 065446
2008 065450 104015
2009 065452
2010 065452 000002

```
PERRAB: SUBTST <<DATA WAS A BYTE>>  
:*****  
:*SUBTEST DATA WAS A BYTE  
:*****  
CALL PERBANK  
IF ABORTFLAG IS TRUE THEN $CALL GETDATA  
IF BADPC EQ #0 THEN $CALL BADSTACK  
CALL PERXOR  
IF ABORTFLAG IS FALSE  
ERROR +14  
ELSE  
ERROR +15  
END ;OF IF ABORTFLAG  
RTI
```

2013 065454

PERRA7: SUBTST <<DATA WAS A 7 BIT BYTE>>
:*****
:*SUBTEST DATA WAS A 7 BIT BYTE
:*****

2014 065454
2015 065466 004737 065540
2016 065472 004737 065564
2017 065476 104022
2018 065500 000002

IF BADPC EQ #0 THEN \$CALL BADSTACK
CALL PERXOR
CALL PERBNK
ERROR +22
RTI

2019
2020 065502
2021 065510
2022 065516 000137 054652

\$PER26: LET GOOD2 := #100000
LET GOOD3 := #100
JMP PERRA3

2023
2024 065522 005037 002052
2025 065526
2026 065534 000137 054652

\$PER27: CLR GOOD2
LET GOOD3 := #077
JMP PERRA3

2027
2028 065540

PERXOR: SUBTST <<DETERMINE XOR OF GOOD & BAD>>
:*****
:*SUBTEST DETERMINE XOR OF GOOD & BAD
:*****

2029 065540
2030 065542 013700 002050
2031 065546 013737 002056 002064
2032 065554 074037 002064
2033 065560
2034 065562 000207

PUSH RO
MOV GOOD,RO
MOV BAD,BADXOR
XOR RO,BADXOR
POP RO
RETURN

2037 065564

PERBANK: SUBST<<LOG ERROR ON BAD BANK>>
:*****
:*SUBTEST LOG ERROR ON BAD BANK
:*****

2038

:WHILE WE'RE HERE LET'S MARK THE BAD BANK IN THE CONFIGURATION TABLE

2039 065564
2040 065570 013701 002106
2041 065574 070127 000006
2042 065600 052761 004000 003016
2043 065606 062701 000005
2044 065612 105261 003016
2045 065616 001002
2046 065620 105361 003016
2047 065624 126137 003016 002702
2048 065632 101403
2049 065634
2050 065642
2051 065646 000207
2052

PUSH R0,R1
MOV BANK,R1
MUL #6,R1
BIS #BIT11,CONFIG(R1)
ADD #5,R1 :POINT TO MAX ERROR BYTE
INCB CONFIG(R1) :BUMP BANK COUNTER
BNE 12\$:NO OVERFLOW - SKIP
DECB CONFIG(R1) :SET BACK TO 255.
2\$: CMPB CONFIG(R1),ERRMAX :IS IT PAST MAX?
BLOS 11\$:NO - SKIP
SET TOOMANY :YES
11\$: POP R1,R0
RETURN

2053 065650 010137 002040
2054 065654 010037 002056
2055 065660
2056 065666 013737 002344 002050
2057 065674
2058 065676 013737 002346 002050
2059 065704
2060 065704 004737 065540
2061 065710
2062 065716 000207
2063

PERECC: MOV R1,ADDRESS
MOV R0,BAD
IF R1 EQ TESTADD
MOV TSTDAT,GOOD
ELSE
MOV TSTDAT+2,GOOD
END ;OF IF R1
CALL PERXOR
SET HEADER
RETURN

2064 065720
2065 065732 004737 065650
2066 065736
2067 065746 104042
2068 065750
2069 065750
2070 065760 104045
2071 065762
2072 065762
2073 065772 104046
2074 065774
2075 065774
2076 066004 104047
2077 066006
2078 066006
2079 066014 000002

\$PER31: IF BADPC EQ #0 THEN \$CALL BADSTACK
CALL PERECC
IF REALPAT EQ #11
ERROR +42
END ;OF IF REALPAT
IF REALPAT EQ #14
ERROR +45
END ;OF IF REALPAT
IF REALPAT EQ #15
ERROR +46
END ;OF IF REALPAT
IF REALPAT EQ #16
ERROR +47
END ;OF IF REALPAT
SET HEADER
RTI

2082	066016				\$PER32: IF BADPC EQ #0 THEN \$CALL BADSTACK
2083	066030	010137	002040		MOV R1,ADDRESS
2084	066034	010037	002056		MOV R0,BAD
2085	066040	010237	00205C		MOV R2,GOOD
2086	066044				SET HEADER
2087	066052	104043			ERROR +43
2088	066054				SET HEADER
2089	066062	000002			RTI
2090					
2091	066064				\$PER33: IF BADPC EQ #0 THEN \$CALL BADSTACK
2092	066076	010137	002040		MOV R1,ADDRESS
2093	066102	010037	002056		MOV R0,BAD
2094	066106	105037	002057		CLRB BAD+1
2095	066112	012737	000377	002050	MOV #377,GOOD
2096	066120	004737	065540		CALL PERXOR
2097	066124				SET HEADER
2098	066132	104044			ERROR +44
2099	066134				SET HEADER
2100	066142	000002			RTI
2101					
2102	066144				\$PER34: IF BADPC EQ #0 THEN \$CALL BADSTACK
2103	066156				IF #BIT15!BIT4 OFF.IN CSR
2104	066166	104016			ERROR +16 ;NO SBE OR DBE
2105	066170				ELSE
2106	066172	104001			ERROR +1 ;EXPECTED SBE SO DBE MUST HAVE GOTTEN SET
2107	066174				END ;OF IF #BIT15.BIT4
2108	066174	000002			RTI
2109					
2110					;DURING BRANCH GOBBLE THE CONDITION CODES WERE WRONG
2111	066176	004737	065564		\$PER35: CALL PERBANK
2112	066202	004737	036770		CALL BADSTACK
2113	066206	013737	002036	002056	MOV BADPSW,BAD
2114	066214	012737	000012	002050	MOV #12,GOOD
2115	066222	104054			ERROR +54
2116	066224	062706	000004		ADD #4,SP ;FIX STACK FROM TRAP
2117	066230	000207			RETURN ;ABORTING TEST

```

2120 .SBTTL ROUTINE SCOPE HANDLER
2121 :*****
2122 :*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
2123 :*AND LOAD THE DISPLAY DATA INTO THE DISPLAY REGISTER
2124 :*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
2125 :*SW14=1 LOOP ON TEST
2126 :*SW9=1 LOOP ON ERROR
2127 :*CALL
2128 :* SCOPE ;.SCOPE=IOT
2129 066232 005237 075144 $SCOPE: INC $DEVCT ;TELL APT WE ARE ALIVE
2130 066236 IF RESULT IS LT
2131 066240 005037 075144 CLR $DEVCT
2132 066244 105237 075146 INCB $UNIT
2133 066250 END ;OF IF RESULT
2134 066250 104410 CKSWR ;:TEST FOR CHANGE IN SOFT-SWR
2135 066252 IF CPUBIT EQ #MASTER ;IF I'M THE MASTER
2136 066262 IF PTYFLAG IS TRUE OR PTYFLAG+2 IS TRUE OR PTYFLAG+4 IS TRUE OR PTYFLAG+6 IS TRUE
2137 066312 004737 072154 CALL QUE
2138 066316 END ;OF IF PTYFLAG
2139 066316 END ;OF IF CPUBIT
2140 066316 IF STOPOK IS TRUE AND #SW8 SET.IN @SWR
2141 066334 005037 002520 CLR STOPOK
2142 066340 TYPE MSG112 ;PROGRAM HALTING BECAUSE OF SWITCH #8
2143 066344 000137 043522 JMP EXIT
2144 066350 END ;OF IF STOPOK
2145 066350 IF NOSCOPE IS TRUE
2146 066356 000002 RTI
2147 066360 END ;OF IF NOSCOPE
2148 066360 1$: IF #SW14 SET.IN @SWR THEN GOTO $OVER
2149 :*****START OF CODE FOR THE XOR TESTER*****
2150 066370 000421 $XTSTR: BR 2$ ;:IF RUNNING ON THE 'XOR' TESTER CHANGE
2151 ;:THIS INSTRUCTION TO A 'NOP' (NOP=240)
2152 066372 013746 000004 MOV ERRVEC,-(SP) ;:SAVE THE CONTENTS OF THE ERROR VECTOR
2153 066376 012737 066416 000004 MOV #1$,ERRVEC ;:SET FOR TIMEOUT
2154 066404 005737 177060 TST 177060 ;:TIME OUT ON XOR?
2155 066410 012637 000004 MOV (SP)+,ERRVEC ;:RESTORE THE ERROR VECTOR
2156 066414 000424 BR $SVLAD ;:GO TO THE NEXT TEST
2157 066416 062706 000004 1$: ADD #4,SP ;:FIX STACK FROM TRAP
2158 066422 005037 177766 CLR CPUERR ;:RESET CPU ERROR REGISTER
2159 066426 012637 000004 MOV (SP)+,ERRVEC ;:RESTORE THE ERROR VECTOR
2160 066432 000407 BR 4$ ;:LOOP ON THE PRESENT TEST
2161 066434 2$: ;*****END OF CODE FOR THE XOR TESTER*****
2162 066434 105737 002016 3$: TSTB $ERFLG ;:HAS AN ERROR OCCURRED?
2163 066440 001412 BEQ $SVLAD ;:BR IF NO
2164 066442 032777 001000 114316 BIT #SW9,@SWR ;:LOOP ON ERROR?
2165 066450 001404 BEQ 5$ ;:BR IF NO
2166 066452 013737 002750 002746 4$: MOV $LPERR,$LPADR ;:SET LOOP ADDRESS TO LAST SCOPE
2167 066460 000410 BR $OVER
2168 066462 105037 002016 5$: CLRB $ERFLG ;:ZERO THE ERROR FLAG
2169 066466 011637 002746 $SV AD: MOV (SP),$LPADR ;:SAVE SCOPE LOOP ADDRESS
2170 066472 011637 002750 MOV (SP),$LPERR ;:SAVE ERROR LOOP ADDRESS
2171 066476 005037 002454 CLR $ESCAPE ;:CLEAR THE ESCAPE FROM ERROR ADDRESS
2172 066502 004737 066514 $OVER: CALL GETDIS
2173 066506 013716 002746 MOV $LPADR,(SP) ;:FUDGE RETURN ADDRESS
2174 066512 000002 RTI ;:FIXES PS
    
```

2176 066514

GETDIS: SUB*ST <<SUBR DISPLAY>>

: *SUBTEST SUBR DISPLAY

2177 066514 113737 002106 002015
2178 066522 113737 002366 002014
2179 066530
2180 066536
2181 066544 005000
2182 066546 013700 177750
2183 066552 072027 000004
2184 066556 000402
2185 066560 062706 000004
2186 066564 042700 177437
2187 066570 150037 002014
2188 066574 005737 002134
2189 066600 001403
2190 066602 052737 100000 002014
2191 066610
2192 066624 013777 002014 114136
2193 066632 013737 002014 000174
2194 066640
2195 066646
2196 066660 000207

MOV BANK,\$BANK
MOVB REALPAT,\$PATMAR
PUSH R0,4
SET4 #2\$;TRAPS TO 4 GOTO 2\$
CLR R0
MOV MAINT,R0
ASH #4,R0
BR 3\$
2\$: ADD #4,SP ;FIX STACK FROM TRAP
3\$: BIC #^C340,R0
BISB R0,\$PATMAR
TST RLFLAG ;ARE WE RELOCATED?
BEQ 1\$;NO - SKIP
BIS #BIT15,\$PATMAR ;YES - SET MSB
1\$: IF MDISPLAY NE #0 THEN LET \$PATMAR := MDISPLAY
MOV \$PATMAR,@DISPLAY
MOV \$PATMAR,DISPREG ;SOFTWARE DISPLAY REGISTER
POP 4,R0
RES4 ;RESTORE TRAPS TO 4 TO DEFAULT
RETURN

```

2199          .SBTTL ROUTINE ERROR HANDLER
2200          ;*****
2201          ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
2202          ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
2203          ;*AND GO TO $ERRTYP ON ERROR
2204          ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
2205          ;*SW15=1      HALT ON ERROR
2206          ;*SW13=1      INHIBIT ERROR TYPEOUTS
2207          ;*SW10=1      BELL ON ERROR
2208          ;*SW9=1       LOOP ON ERROR
2209          ;*CALL
2210          ;*      ERROR      N      ;;ERROR EMT AND N-ERROR ITEM NUMBER
2211
2212          .ENABL  LSB
2213          $ERROR: IF NOERROR IS FALSE
2214          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
2215          INCB $ERFLG    ;;SET THE ERROR FLAG
2216          BEQ 1$        ;;DON'T LET THE FLAG GO TO ZERO
2217          CALL GETDIS    ;;SETUP DISPLAY STUFF
2218          MOV $PATMAR,$TESTN ;;FOR APT
2219          BIT #SW10,@SWR ;;BELL ON ERROR?
2220          BEQ 2$        ;;NO - SKIP
2221          TYPE $BELL     ;;RING BELL
2222          TYPE MSG014    ;;CONTROL Z
2223          INC $ERTTL     ;;COUNT THE NUMBER OF ERRORS
2224
2225          IF RESULT IS MI
2226          MOV #77777,$ERTTL
2227          END ;OF IF RESULT
2228          END ;OF IF NOERROR
2229          MOV (SP),ERRPC   ;;GET ADDRESS OF ERROR INSTRUCTION
2230          SUB #2,ERRPC
2231          MOV SP,ERRSP
2232          MOV 2(SP),ERRPSW
2233          MOVB @ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
2234          IF NOERROR IS FALSE
2235          IF BADPC NE #0
2236          MOV BADPC,ERRPC
2237          SUB #2,ERRPC
2238          MOV BADSP,ERRSP
2239          MOV BADPSW,ERRPSW
2240          CLR BADPC
2241          END ;IF
2242          MOV ERRPC,$FATAL ;;FOR APT
2243          IF #SW13 SET.IN @SWR OR SLAVERERROR IS TRUE
2244          BR 3$
2245          END ;OF IF #SW13
2246          IF #SW5 SET.IN @SWR AND TOOMANY IS TRUE
2247          GOTO 3$
2248          END ;OF IF #SW5
2249          END ;OF IF NOERROR
          CALL $ERRTYP      ;;GO TO USER ERROR ROUTINE

```

2213	066662				
2214	066670	104410			
2215	066672	105237	002016		
2216	066676	001775			
2217	066700	004737	066514		
2218	066704	013737	002014	075140	
2219	066712	032777	002000	114046	
2220	066720	001404			
2221	066722				
2222	066726				
2223	066732	005237	002754		
2224	066736				
2225	066740	012737	077777	002754	
2226	066746				
2227	066746				
2228	066746	011637	002024		
2229	066752	162737	000002	002024	
2230	066760	010637	002030		
2231	066764	016637	000002	002034	
2232	066772	117737	113026	002017	
2233	067000				
2234	067006				
2235	067014	013737	002026	002024	
2236	067022	162737	000002	002024	
2237	067030	013737	002032	002030	
2238	067036	013737	002036	002034	
2239	067044	005037	002026		
2240	067050				
2241	067050	013737	002024	075136	
2242	067056				
2243	067074	000412			
2244	067076				
2245	067076				
2246	067114				
2247	067116				
2248	067116				
2249	067116	004737	067324		

```

2251 067122
2252 067130 005777 *13632
2253 067134 100002
2254 067136 000000
2255 067140 104410
2256 067142
2257 067160 013716 002750
2258 067164
2259 067164 005737 002454
2260 067170 001402
2261 067172 013716 002454
2262 067176
2263 067204
2264 067226 012737 000001 075134
2265 067234 000137 043522
2266 067240
2267 067240
2268 067256
2269 067262 013700 000042
2270 067266 005037 000042
2271 067272 000137 014760
2272 067276
2273 067276
2274 067276
2275 067300
2276 067306
2277 067306
2278 067322 000002
2279

3$: IF NOERROR IS FALSE
    TST @SWR                ;;HALT ON ERROR
    BPL 7$                  ;;SKIP IF CONTINUE
$HALT: HALT                  ;;HALT ON ERROR!
        CKSWR                ;;TEST FOR CHANGE IN SOFT-SWR
7$: IF NOSCOPE IS FALSE AND #SW9 SET IN @SWR
    MOV $LPERR,(SP)        ;;FUDGE RETURN FOR LOOPING
    END ;OF IF NOSCOPE
    TST $ESCAPE            ;;CHECK FOR AN ESCAPE ADDRESS
    BEQ 9$                  ;;BR IF NONE
    MOV $ESCAPE,(SP)      ;;FUDGE RETURN ADDRESS FOR ESCAPE
9$: IF DETFLAG IS FALSE
    IF ACTFLAG IS TRUE OR APTFLAG IS TRUE OR FATAL$ IS TRUE
        MOV #1,$MSGTY      ;FOR APT
        JMP EXIT
    END ;OF IF ACTFLAG
    IF XXDPCHAIN IS TRUE AND $ERTTL HI #20
        TYPE MSG066        ;ERROR COUNT EXCEEDED 20 - ABORTING FOR XXDP CHAIN
        MOV 42,R0
        CLR 42
        JMP $ZAP42
    END ;OF IF XXDPCHAIN
    END ;OF IF DETFLAG
ELSE
    SET HEADER
    END ;OF IF NOERROR
10$: CLEAR TOOMANY,CPUERR,NOERROR
    RTI                      ;;RETURN
.DSABL LSB
    
```



```

2282
2283
2284
2285
2286
2287
2288
2289 067324 104415
2290 067326
2291 067332 005000
2292 067334 153700 002017
2293 067340 001004
2294
2295 067342
2296 067350 000512
2297 067352 005300
2298 067354 006300
2299 067356 006300
2300 067360 006300
2301 067362 062700 101372
2302 067366 012037 067424
2303 067372 001417
2304 067374 005737 002530
2305 067400 001003
2306 067402 005737 002724
2307 067406 100011
2308 067410 005737 002070
2309 067414 001402
2310 067416
2311 067422
2312 067424 000000
2313 067426
2314 067432 012037 067456
2315 067436 001412
2316 067440 005737 002530
2317 067444 001003
2318 067446 005737 002724
2319 067452 100004
2320 067454
2321 067456 000000
2322 067460
2323 067464 012001
2324 067466 001436
2325 067470 012002

```

.SBTTL ROUTINE ERROR MESSAGE TYPEOUT

```

*****
*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB ,
*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
*****
ERRRYP:SAVREG
TYPE $CRLF ;;'CARRIAGE RETURN' & 'LINE FEED'
CLR R0 ;;PICKUP THE ITEM INDEX
BISB $ITEMB,R0
BNE 1$ ;;IF ITEM NUMBER IS ZERO, JUST
;;TYPE THE PC OF THE ERROR
TYOCT ERRPC,<ERROR ADDRESS>
BR 11$ ;;GET OUT
1$: DEC R0 ;;ADJUST THE INDEX SO THAT IT WILL
;; WORK FOR THE ERROR TABLE
ASL R0
ASL R0
ASL R0
ADD #ERRTB,R0 ;;FORM TABLE POINTER
MOV (R0)+,3$ ;;PICKUP "ERROR MESSAGE" POINTER
BEQ 4$ ;;SKIP TYPEOUT IF NO POINTER
TST NOERROR ;;IS THIS REALLY AN ERROR?
BNE 12$ ;;YES - SKIP
TST HEADER ;;TYPE HEADER?
BPL 4$ ;;NO - SKIP
12$: TST FATAL$ ;;WAS IT A FATAL ERROR?
BEQ 2$ ;;NO - SKIP
TYPE MSG067 ;;FATAL
2$: TYPE ;;TYPE THE "ERROR MESSAGE"
3$: .WORD 0 ;;"ERROR MESSAGE" POINTER GOES HERE
TYPE $CRLF ;;'CARRIAGE RETURN' & 'LINE FEED'
4$: MOV (R0)+,5$ ;;PICKUP "DATA HEADER" POINTER
BEQ 6$ ;;SKIP TYPEOUT IF 0
TST NOERROR ;;IS THIS REALLY AN ERROR?
BNE 13$ ;;YES - SKIP
TST HEADER ;;TYPE HEADER?
BPL 6$ ;;NO - SKIP
13$: TYPE ;;TYPE THE "DATA HEADER"
5$: .WORD 0 ;;"DATA HEADER" POINTER GOES HERE
TYPE $CRLF ;;'CARRIAGE RETURN' & 'LINE FEED'
6$: MOV (R0)+,R1 ;;PICKUP "DATA TABLE" POINTER
BEQ 10$ ;;BR IF NO DATA TO BE TYPED
MOV (R0)+,R2 ;;PICKUP "DATA FORMAT" POINTER

```

```

2328 067472 112203          7$:  MOVB  (R2)+,R3
2329 067474 006303          ASL   R3                ;MAKE IT A WORD ADDRESS
2330 067476 004773 067504    CALL  @8$(R3)
2331 067502 000421          BR    9$
2332 067504 067636          8$:  TAG70$
2333 067506 067646          TAG71$
2334 067510 067656          TAG72$
2335 067512 067722          TAG73$
2336 067514 067730          TAG74$
2337 067516 067742          TAG75$
2338 067520 067754          TAG76$
2339 067522 067776          TAG77$
2340 067524 070000          TAG78$
2341 067526 070006          TAG79$
2342 067530 070066          TAG80$
2343 067532 070100          TAG81$
2344 067534 070122          TAG82$
2345 067536 070324          TAG83$
2346 067540 070410          TAG84$
2347 067542 070502          TAG85$
2348 067544 070612          TAG86$
2349 067546 062701 000002    9$:  ADD   #2,R1            ;UPDATE DATA TABLE POINTER
2350 067552 005711          TST  (R1)              ;; IS THERE ANOTHER NUMBER?
2351 067554 001403          BEQ  10$              ;;BR IF NO
2352 067556          TYPE  MSG018         ;TYPE 2 SPACES
2353 067562 000743          BR   7$               ;;LOOP
2354
2355 067564 005737 002116    10$: TST  MUT              ;IS THERE A MEMORY UNDER TEST
2356 067570 001402          BEQ  11$              ;NO - SKIP
2357 067572 005237 002724    INC  HEADER           ;YES - BUMP HEADER FLAG
2358 067576 104416          11$: RESREG
2359 067600          IF #SW7 SET.IN @SWR AND DETFLAG IS FALSE AND NOERROR IS FALSE
2360 067624 004737 071364    CALL  DETAIL
2361 067630          END ;OF IF #SW7
2362 067630          TYPE  MSG104        ;CONTROL Z
2363 067634 000207          RETURN
  
```

```

2366 :*****
2367 :*** OCTAL ***
2368 :*****
2369 067636 TAG70$: TYPOCT @(R1) ;:TYPE AN OCTAL NUMBER
2370 067644 000207 RETURN
2371 :*****
2372 :*** DECIMAL ***
2373 :*****
2374 067646 TAG71$: TYPDEC @(R1) ;:TYPE A DECIMAL NUMBER
2375 067654 000207 RETURN
2376 067654 000207
2377 :*****
2378 :*** INTERLEAVE ***
2379 :*****
2380 :*****
2381 067656 TAG72$: PUSH R1,R5
2382 067662 013701 002106 MOV BANK,R1
2383 067666 070127 000006 MUL #6,R1
2384 067672 SET NOTAB ;INDICATE NO TABLE TO BE PRINTED - NOW
2385 067700 004737 036012 CALL TCFIG1
2386 067704 005037 002464 CLR NOTAB
2387 067710 POP R5,R1
2388 067714 TYPE MSG014 ;:1 SPACE
2389 067720 000207 RETURN
2390 :*****
2391 :*** BOX ***
2392 :*****
2393 :*****
2394 067722 004737 070672 TAG73$: CALL WHOBOX
2395 067726 000207 RETURN
2396 :*****
2397 :*** PATTERN ***
2398 :*****
2399 :*****
2400 067730 TAG74$: TYPOCS REALPAT,<TYPE (0-77)>,2,Z
2401 067740 000207 RETURN
2402 :*****
2403 :*** BANK ***
2404 :*****
2405 :*****
2406 067742 TAG75$: TYPOCS BANK,<TYPE (0-167)>,3
2407 067752 000207 RETURN
2408 :*****
2409 :*** MTYPE ***
2410 :*****
2411 :*****
2412 067754 005737 002126 TAG76$: TST MKFLAG
2413 067760 001003 BNE 1$
2414 067762 TYPE MSG068 ;MJ11
2415 067766 000207 RETURN
2416 067770 1$: TYPE MSG069 ;MK11
2417 067774 000207 RETURN
  
```

```

2420 :*****
2421 :*** SPARE FUNCTION ***
2422 :*****
2423 067776 000207 TAG77$: RETURN
2424
2425 :*****
2426 :*** UNKNOWN DATA ***
2427 :*****
2428 070000 TAG78$: TYPE MSG061
2429 070004 000207 RETURN
2430
2431 :*****
2432 :*** PHYSICAL ADDRESS ***
2433 :*****
2434 070006 013737 002040 002044 TAG79$: MOV ADDRESS,PHYADD
2435 070014 162737 060000 002044 SUB #FIRST,PHYADD
2436 070022 013737 002106 002046 MOV BANK,PHYADD+2
2437 070030 006237 002046 ASR PHYADD+2
2438 070034 103003 BCC 1$
2439 070036 052737 100000 002044 BIS #BIT15,PHYADD
2440 070044 012746 002044 1$: MOV #PHYADD,-(SP) ;POINTER TO DOUBLE WORD ON STACK
2441 070050 004737 075014 CALL $DB20 ;CALL DOUBLE PRECISION CONVERSION ROUTINE
2442 070054 062706 000002 ADD #2,SP ;FIX STACK
2443 070060 TYPE $OCT8
2444 070064 000207 RETURN
2445 :*****
2446 :*** MARGIN ***
2447 :*****
2448 070066 TAG80$: TYPOCS MARGIN,<TYPE (0,2,3,4, OR 5)>,1
2449 070076 000207 RETURN
2450
2451 :*****
2452 :*** OCTAL BYTE ***
2453 :*****
2454 070100 TAG81$: TYPE MSG018 ;2 SPACES
2455 070104 TYPOCS @(R1),<TYPE BYTE>,3,2
2456 070114 TYPE MSG014 ;SPACE
2457 070120 000207 RETURN
    
```

```

2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472 070122 012737 037477 115336 TAG828: MOV #'??,MSG074
2473 070130 IF MKFLAG IS TRUE
2474 070136 PUSH CSR,CSR+2,R0,R1,R2,CSRNO
2475 070160 013737 002000 002256 MOV BADCSR,CSRNO
2476 070166 SET R2
2477 070172 104426 READCSR
2478 070174 IF #BIT15!BIT4 SET.IN CSR
2479 070204 013702 002144 MOV CSR,R2
2480 070210 072227 177774 ASH #-4,R2
2481 070214 042702 177761 BIC #^C16,R2
2482 070220 IF #BIT9 SET.IN CSR+2 THEN LFT R2 : R2 SET.BY #BIT0
2483 070234 END :OF IF #BIT15.BIT4
2484 070234 IF R2 GE #0
2485 070240 IF R2 GT #9.
2486 0702'6 162702 000012 SUB #10.,R2
2487 0702>2 000302 SWAB R2
2488 070254 062702 030061 ADD #'10,R2
2489 070260 ELSE
2490 070262 000302 SWAB R2
2491 070264 062702 030040 ADD #'0,R2
2492 070270 END :OF IF #BIT3
2493 070270 010237 115336 MOV R2,MSG074
2494 070274 END :OF IF R2
2495 070274 POP CSRNO,R2,R1,R0,CSR+2,CSR
2496 070316 END :OF IF MKFLAG
2497 070316 TYPE MSG074
2498 070322 000207 RETURN

```

2501
2502
2503
2504 070324
2505 070330
2506 070334 017100 000000
2507 070340
2508 070344 106100
2509 070346
2510 070350 112737 000061 112134
2511 070356
2512 070360 112737 000060 112134
2513 070366
2514 070366
2515 070372
2516 070402
2517 070406 000207
2518
2519
2520
2521
2522 070410
2523 070414
2524 070420 017100 000000
2525 070424 012702 000004
2526 070430 072002
2527 070432
2528 070436 106100
2529 070440
2530 070442 112737 000061 112134
2531 070450
2532 070452 112737 000060 112134
2533 070460
2534 070460
2535 070464
2536 070474
2537 070500 000207

```
*****  
*** BINARY BYTE ***  
*****  
TAG83$: PUSH R0,R2  
TYPE MSG018 ;2 SPACES  
MOV @ (R1),R0  
FOR R2 := #1 TO #8.  
ROLB R0  
ON.ERROR  
MOVB #'1,MSG015  
ELSE  
MOVB #'0,MSG015  
END ;OF ON.ERROR  
TYPE MSG015  
END ;OF FOR R2  
POP R2,R0  
RETURN
```

```
*****  
*** 4 BINARY BITS ***  
*****  
TAG84$: PUSH R0,R2  
TYPE MSG018 ;2 SPACES  
MOV @ (R1),R0  
MOV #4,R2  
ASH R2,R0 ;SHIFT 4 PLACES LEFT  
FOR R2 := #1 TO #4  
ROLB R0  
ON.ERROR  
MOVB #'1,MSG015  
ELSE  
MOVB #'0,MSG015  
END ;OF ON.ERROR  
TYPE MSG015  
END ;OF FOR R2  
POP R2,R0  
RETURN
```

```

2540
2541
2542
2543 070502
2544 070504 012737 037477 115336
2545 070512 013702 002150
2546 070516 072227 177774
2547 070522 042702 177761
2548 070526
2549 070542
2550 070546
2551 070554 162702 000012
2552 070560 000302
2553 070562 062702 030061
2554 070566
2555 070570 000302
2556 070572 062702 030040
2557 070576
2558 070576 010237 115336
2559 070602
2560 070602
2561 070606
2562 070610 000207
2563
2564
2565
2566
2567 070612
2568 070620
2569 070624
2570 070624
2571 070634
2572 070640
2573 070640
2574 070650
2575 070654
2576 070654
2577 070664
2578 070670
2579 070670 000207

```

```

:*****
:*** ARRAY FROM SBE FROM OLD CSR ***
:*****
TAGB5$: PUSH R2
MOV #'??,MSG074
MOV SBECR,R2
ASH #-4,R2
BIC #^C16,R2
IF #BIT9 SET.IN SBECR+2 THEN LET R2 := R2 SET.BY #BIT0
IF R2 GE #0
IF R2 GT #9.
SUB #10.,R2
SWAB R2
ADD #'10,R2
ELSE
SWAB R2
ADD #'0,R2
END ;OF IF #BIT3
MOV R2,MSG074
END ;OF IF R2
TYPE MSG074
POP R2
RETURN

:*****
:*** MASTER OR SLAVE1 OR SLAVE2 OR SLAVE3 FROM BAD
:*****
TAGB6$: IF BAD EQ #0
TYPE MSG113 ;MASTER
END IF
IF BAD EQ #1
TYPE MSG114 ;SLAVE1
END IF
IF BAD EQ #2
TYPE MSG115 ;SLAVE2
END IF
IF BAD EQ #3
TYPE MSG116 ;SLAVE3
END IF
RETURN

```

2581 070672

WHOBX: SUBTST <<SUBR WHO'S BOX IS THIS?>>
:*****
:*SUBTEST SUBR WHO'S BOX IS THIS?
:*****

2582 070672 005737 002126

2583 070676 001003

2584

2585 070700

2586 070704 000207

2587

2588 070706

2589 070722 005037 002424

2590 070726 012703 000200

2591 070732 012701 000060

2592 070736

2593 070736

2594 070740

2595 070746 016437 002214 002260

2596 070754 016437 002234 002262

2597 070762 010437 002000

2598 070766 006337 002000

2599 070772

2600 071012 016402 002174

2601 071016 072227 177764

2602 071022 042702 177770

2603 071026

2604 071036 071152

2605 071040 071162

2606 071042 071202

2607 071044 071232

2608 071046 071262

2609 071050 071264

2610 071052 071304

2611 071054 071334

2612 071056

2613 071064

2614 071072

2615 071072

2616 071072 006003

2617 071074 005201

2618 071076

2619 071110

2620 071110

2621 071116 110137 114717

2622 071122

2623 071122

2624 071126 112737 000077 114717

2625 071134

2626 071150 000207

TST MKFLAG ;MK11?
BNE 1\$;YES - SKIP
;NO - MJ11 - DON'T KNOW ABOUT BOX NUMBERS
TYPE MSG057 ; ?
RETURN

1\$: PUSH CSRNO,R1,R2,R3,R4
CLR SUCCESS
MOV #200,R3
MOV #'0,R1
BEGIN WHODUNIT
FOR R4 := #0 TO #16 BY #2
IFB R3 SET.IN MKCSRS
MOV CSRFB(R4),FIRSTB
MOV CSRLB(R4),LASTB
MOV R4,BADCSR
ASL BADCSR
IF FIRSTB LE BANK AND LASTB GE BANK
MOV CSR2(R4),R2
ASH #-12.,R2
BIC #^C7,R2
CASE R2
ADD..0
ADD..1
ADD..2
ADD..3
ADD..4
ADD..5
ADD..6
ADD..7
END ;OF CASE R2
IF SUCCESS IS TRUE THEN LEAVE WHODUNIT
END ;OF IF FIRSTB
END ;OF IFB R3
ROR R3
INC R1
END ;OF FOR CSRNO
END WHODUNIT
IF SUCCESS IS TRUE
MOVB R1,MSG057+1
END ;OF IF SUCCESS
TYPE MSG057
MOVB #'?,MSG057+1
POP R4,R3,R2,R1,CSRNO
RETURN

2629 071152
 2630 071160 000207
 2631 071162
 2632 071200 000207
 2633 071202
 2634 071230 000207
 2635 071232
 2636 071260 000207
 2637 071262 000207
 2638 071264
 2639 071302 000207
 2640 071304
 2641 071332 000207
 2642 071334
 2643 071362 000207
 2644
 2645 071364

ADD..0: SET SUCCESS
 RETURN
 ADD..1: IF #BIT2 OFF.IN ADDRESS THEN LET SUCCESS := ONES
 RETURN
 ADD..2: IF #BIT3 OFF.IN ADDRESS AND #BIT2 OFF.IN ADDRESS THEN LET SUCCESS := ONES
 RETURN
 ADD..3: IF #BIT3 SET.IN ADDRESS AND #BIT2 OFF.IN ADDRESS THEN LET SUCCESS := ONES
 RETURN
 ADD..4: RETURN
 ADD..5: IF #BIT2 SET.IN ADDRESS THEN LET SUCCESS := ONES
 RETURN
 ADD..6: IF #BIT3 OFF.IN ADDRESS AND #BIT2 SET.IN ADDRESS THEN LET SUCCESS := ONES
 RETURN
 ADD..7: IF #BIT3 SET.IN ADDRESS AND #BIT2 SET.IN ADDRESS THEN LET SUCCESS := ONES
 RETURN

DETAIL: SUBST <<SUBR DETAILED ERROR REPORT>>

 ;*SUBTEST SUBR DETAILED ERROR REPORT
 ;*****

2646 071364 005237 002326
 2647 071370 022737 000003 002326
 2648 071376 101465
 2649 071400 022737 000002 002326
 2650 071406 001435
 2651 071410
 2652 071420
 2653 071426 005037 002116
 2654 071432 010037 002306
 2655 071436 012700 002310
 2656 071442 010120
 2657 071444 010220
 2658 071446 010320
 2659 071450 010420
 2660 071452 010520
 2661 071454 013720 002030
 2662 071460 013720 002034
 2663 071464 013700 002306
 2664 071470
 2665 071476 104013
 2666 071500 000415
 2667 071502
 2668 071512
 2669 071520 005037 002116
 2670 071524
 2671 071532 104031
 2672 071534
 2673
 2674 071544 004737 071364
 2675 071550 000207

INC DETFLAG
 CMP #3,DETFLAG
 BLOS 4\$
 CMP #2,DETFLAG
 BEQ 2\$
 PUSH HEADER,MUT
 SET HEADER
 CLR MUT
 MOV R0,DETRO
 MOV #DETR1,R0
 MOV R1,(R0)+
 MOV R2,(R0)+
 MOV R3,(R0)+
 MOV R4,(R0)+
 MOV R5,(R0)+
 MOV ERRSP,(R0)+
 MOV ERRPSW,(R0)+
 MOV DETRO,R0
 SET NOERROR
 ERROR +13
 BR 1\$
 2\$: PUSH HEADER,MUT
 SET HEADER
 CLR MUT
 SET NOERROR
 ERROR +31
 1\$: POP MUT,HEADER
 ;WARNING RECURSIVE
 CALL DETAIL
 RETURN

```
2678  
2679 071552 004737 073404 4S: ;SIMULATE CONTROL 'T'  
2680 ;CALL CONT ;DISPLAY 'DISPLAY' INFO  
2681 ;TYPE CONTENTS OF ALL CSR'S  
2682 071556 PUSH CSR,CSR+2,CSRNO,R1  
2683 071574 TYPE MSG058  
2684 071600 TYPE $CRLF  
2685 071604 013701 002334 MOV MKCSRS,R1  
2686 071610 BEGIN DUMPCSRLOOP  
2687 071610 FOR CSRNO := #0 TO #34 BY #4  
2688 071614 106301 ASLB R1  
2689 071616 ON.ERROR  
2690 071620 104426 READCSR  
2691 071622 TYPOCT CSR  
2692 071630 TYPE MSG018 ;2 SPACES  
2693 071634 TYPOCT CSR+2  
2694 071642 TYPE MSG018 ;2 SPACES  
2695 071646 END ;OF ON.ERROR  
2696 071646 IFB R1 EQ #0 THEN LEAVE DUMPCSRLOOP  
2697 071652 END ;OF FOR CSRNO  
2698 071670 END DUMPCSRLOOP  
2699 071670 POP R1,CSRNO,CSR+2,CSR
```

```

2702 ;TYPE STACKS
2703 071706 PUSH RO,R1
2704
2705 ;TYPE KERNEL STACK
2706 071712 TYPE MSG088 ;KERNEL STACK
2707 071716 013701 002706 MOV KSTACK,R1
2708 071722 162701 000002 SUB #2,R1
2709 071726 FOR RO := SP TO R1 BY #2
2710 071730 TYPE $CRLF
2711 071734 TYPOCT RO
2712 071740 TYPE MSG018 ;2 SPACES
2713 071744 TYPOCT (RO)
2714 071750 END ;OF FOR RO
2715
2716 ;TYPE SUPERVISOR STACK
2717 071760 042737 030000 177776 BIC #BIT13!BIT12,PSW ;SET PREVIOUS MODE TO SUPERVISOR
2718 071766 052737 010000 177776 BIS #BIT12,PSW
2719 071774 006506 MFPI SSP
2720 071776 POP RO
2721 072000 TYPE MSG089 ;SUPERVISOR STACK
2722 072004 IF RO LT #SUPSTK
2723 072012 FOR RO := RO TO #SUPSTK-2 BY #2
2724 072012 TYPE $CRLF
2725 072016 TYPOCT RO
2726 072022 TYPE MSG018 ;2 SPACES
2727 072026 TYPOCT (RO)
2728 072032 END ;OF FOR RO
2729 072044 ELSE
2730 072046 TYPE MSG091 ;IS EMPTY
2731 072052 END ;OF IF RO
2732
2733 ;TYPE USER STACK
2734 072052 052737 030000 177776 BIS #BIT13!BIT12,PSW ;SET PREVIOUS MODE TO USER
2735 072060 006506 MFPI USP
2736 072062 POP RO
2737 072064 TYPE MSG090 ;USER STACK
2738 072070 IF RO LT #USESTK
2739 072076 FOR RO := RO TO #USESTK-2 BY #2
2740 072076 TYPE $CRLF
2741 072102 TYPOCT RO
2742 072106 TYPE MSG018 ;2 SPACES
2743 072112 TYPOCT (RO)
2744 072116 END ;OF FOR RO
2745 072130 ELSE
2746 072132 TYPE MSG091 ;IS EMPTY
2747 072136 END ;OF IF RO
2748 072136 TYPE $CRLF
2749 072142 005037 002326 CLR DETFLAG
2750 072146 POP R1,RO
2751 072152 000207 RETURN
    
```

2754 072154
 2755 072154 104410
 2756 072156
 2757 072166 104424
 2758 072170
 2759 072174
 2760 072202 010001
 2761 072204 006201
 2762 072206 062701 000060
 2763 072212 110137 116242
 2764 072216
 2765 072222
 2766 072232
 2767 072236 005060 002626
 2768 072242 004737 057076
 2769 072246 062706 000002
 2770 072252 005760 002626
 2771 072256 100375
 2772 072260
 2773 072262
 2774 072264
 2775 072270 005060 002626
 2776 072274
 2777 072302
 2778 072310 104000
 2779 072312 005037 002570
 2780 072316
 2781 072316
 2782 072316
 2783 072316
 2784 072330
 2785 072340 162737 000001 002574
 2786 072346 000207

```

QUE:  SUBTST <<QUE MESSAGES FROM SLAVE CPU'S>>
:*****
:*SUBTEST  QUE MESSAGES FROM SLAVE CPU'S
:*****
      CKSWR
      PUSH  RO,R1,CONTRL
      CACHOFF  ;TURN CACHE OFF
      FOR RO :- #2 TO #6 BY #2
      IF PTYFLAG(RO) IS TRUE
      MOV     RO,R1
      ASR    R1
      ADD    #'0,R1
      MOVB   R1,MSG098
      TYPE   MSG098           ;SLAVEN>           ;WHERE N = 1,2, OR 3
      IFB PTYBUF(RO) NE #32   ;CONTROL Z?
      PUSH   PTYBUF(RO)
      CLR    PTYFLAG(RO)
      CALL   $TYPEC
      ADD    #2,SP           ;FIX STACK
      TST   PTYFLAG(RO)
      BPL   1$
      GOTO  QUE1
      ELSE
      TYPE   MSG099           ;MASTER>
      CLR    PTYFLAG(RO)
      IF RLFLAG IS TRUE
      SET    SLAERROR
      ERROR  ;LOG ERROR
      CLR    SLAERROR
      END ;OF IF RLFLAG IS TRUE
      END ;OF IF PTYBUF(RO)
      END ;OF IF PTYFLAG(RO)
      END ;OF FOR RO
      POP    CONTRL,R1,RO
      SUB    #1,HUNGTIME     ;CARRY IS ERROR FLAG ON RETURN
      RETURN
    
```

.SBTTL ROUTINE BINARY TO OCTAL (ASCII) AND TYPE

```

2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803
2804
2805
2806
2807
2808
2809
2810
2811
2812
2813
2814 072350 017646 000000
2815 072354 116637 000001 072573
2816 072362 112637 072575
2817 072366 062716 000002
2818 072372 000406
2819 072374 112737 000001 072573
2820 072402 112737 000006 072575
2821 072410 112737 000005 072572
2822 072416 010346
2823 072420 010446
2824 072422 010546
2825 072424 113704 072575
2826 072430 005404
2827 072432 062704 000006
2828 072436 110437 072574
2829 072442 113704 072573
2830 072446 016605 000012
2831 072452 005003
2832 072454 006105
2833 072456 000404
2834 072460 006105
2835 072462 006105
2836 072464 006105
2837 072466 010503
2838 072470 006103
2839 072472 105337 072574
2840 072476 100016
2841 072500 042703 177770
2842 072504 001002
2843 072506 005704
2844 072510 001403
2845 072512 005204

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS                ;;CALL FOR TYPEOUT
*   .BYTE N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*$STYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*(CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON                ;;CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*(CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC               ;;CALL FOR TYPEOUT
*$TYPOS: MOV @ (SP),-(SP) ;;PICKUP THE MODE
MOVB 1(SP), $OFILL ;;LOAD ZERO FILL SWITCH
MOV (SP)+, $OMODE+1 ;;NUMBER OF DIGITS TO TYPE
ADD #2, (SP) ;;ADJUST RETURN ADDRESS
BR $TYPON
*$TYPOC: MOVB #1, $OFILL ;;SET THE ZERO FILL SWITCH
MOV #6, $OMODE+1 ;;SET FOR SIX(6) DIGITS
*$TYPON: MOVB #5, $OCNT ;;SET THE ITERATION COUNT
MOV R3, -(SP) ;;SAVE R3
MOV R4, -(SP) ;;SAVE R4
MOV R5, -(SP) ;;SAVE R5
MOV $OMODE+1, R4 ;;GET THE NUMBER OF DIGITS TO TYPE
NEG R4
ADD #6, R4 ;;SUBTRACT IT FOR MAX. ALLOWED
MOV $OFILL, R4 ;;SAVE IT FOR USE
MOV $OFILL, R4 ;;GET THE ZERO FILL SWITCH
MOV 12(SP), R5 ;;PICKUP THE INPUT NUMBER
CLR R3 ;;CLEAR THE OUTPUT WORD
1$: ROL R5 ;;ROTATE MSB INTO 'C'
BR 3$ ;;GO DO MSB
2$: ROL R5 ;;FORM THIS DIGIT
ROL R5
MOV R5, R3
3$: ROL R3 ;;GET LSB OF THIS DIGIT
DECB $OMODE ;;TYPE THIS DIGIT?
BPI 6$ ;;BR IF NO
BIC #177770, R3 ;;GET RID OF JUNK
4$: BNE 4$ ;;TEST FOR 0
TS+ R4 ;;SUPPRESS THIS 0?
5$: BEQ 5$ ;;BR IF YES
4$: INC R4 ;;DON'T SUPPRESS ANYMORE 0'S
    
```

```

2846 072514 052703 000060          BIS      #'0,R3      ;;MAKE THIS DIGIT ASCII
2847 072520 052703 000040          BIS      #' ,R3      ;;MAKE ASCII IF NOT ALREADY
2848 072524 110337 072570          MOVB    R3,8$      ;;SAVE FOR TYPING
2849 072530          TYPE      8$      ;;GO TYPE THIS DIGIT
2850 072534 105337 072572          DECB   $OCNT      ;;COUNT BY 1
2851 072540 003347          BGT     2$      ;;BR IF MORE TO DO
2852 072542 002402          BLT     7$      ;;BR IF DONE
2853 072544 005204          INC     R4      ;;INSURE LAST DIGIT ISN'T A BLANK
2854 072546 000744          BR      2$      ;;GO DO THE LAST DIGIT
2855 072550 012605          7$.    MOV    (SP)+,R5      ;;RESTORE R5
2856 072552 012604          MOV    (SP)+,R4      ;;RESTORE R4
2857 072554 012603          MOV    (SP)+,R3      ;;RESTORE R3
2858 072556 016666 000002 000004  MOV    2(SP),4(SP)    ;;SET THE STACK FOR RETURNING
2859 072564 012616          MOVB   (SP)+,(SP)
2860 072566 000002          RTI      ;;RETURN
2861 072570          8$.    .BYTE 0      ;;STORAGE FOR ASCII DIGIT
2862 072571          .BYTE 0      ;;TERMINATOR FOR TYPE ROUTINE
2863 072572          $OCNT: .BYTE 0  ;;OCTAL DIGIT COUNTER
2864 072573          $OFILL: .BYTE 0 ;;ZERO FILL SWITCH
2865 072574 000000          $OMODE: .WORD 0  ;;NUMBER OF DIGITS TO TYPE

```

```

2867          .SBTTL  ROUTINE CONVERT BINARY TO DECIMAL AND TYPE
2868          ;*****
2869          ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
2870          ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT, DEPENDING ON WHETHER THE
2871          ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
2872          ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
2873          ;*REPLACED WITH SPACES.
2874          ;*CALL:
2875          ;*      MOV      NUM,-(SP)          ;;PUT THE BINARY NUMBER ON THE STACK
2876          ;*      TYPDS   ;;GO TO THE ROUTINE
2877          $TYPDS: PUSH  R0,R1,R2,R3,R5
2878          MOV      #20200,-(SP)          ;;SET BLANK SWITCH AND SIGN
2879          MOV      20(SP),R5            ;;GET THE INPUT NUMBER
2880          BPL      1$                    ;;BR IF INPUT IS POS.
2881          NEG      R5                    ;;MAKE THE BINARY NUMBER POS.
2882          MOVB     #'-,1(SP)            ;;MAKE THE ASCII NUMBER NEG.
2883          CLR      R0                    ;;ZERO THE CONSTANTS INDEX
2884          MOV      #$DBLK,R3            ;;SETUP THE OUTPUT POINTER
2885          MOVB     #' ,(R3)+            ;;SET THE FIRST CHARACTER TO A BLANK
2886          CLR      R2                    ;;CLEAR THE BCD NUMBER
2887          MOV      $DTBL(R0),R1        ;;GET THE CONSTANT
2888          SUB      R1,R5                ;;FORM THIS BCD DIGIT
2889          BLT      4$                    ;;BR IF DONE
2890          INC      R2                    ;;INCREASE THE BCD DIGIT BY 1
2891          BR       3$
2892          ADD      R1,R5                ;;ADD BACK THE CONSTANT
2893          TST      R2                    ;;CHECK IF BCD DIGIT=0
2894          BNE      5$                    ;;FALL THROUGH IF 0
2895          TSTB     (SP)                  ;;STILL DOING LEADING 0'S?
2896          BMI      7$                    ;;BR IF YES
2897          ASLB     (SP)                  ;;MSD?
2898          BCC      6$                    ;;BR IF NO
2899          MOVB     1(SP),-1(R3)          ;;YES--SET THE SIGN
2900          BIS      #'0,R2                ;;MAKE THE BCD DIGIT ASCII
2901          BIS      #' ,R2                ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
2902          MOVB     R2,(R3)+            ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
2903          TST      (R0)+                ;;JUST INCREMENTING
2904          CMP      R0,#10                ;;CHECK THE TABLE INDEX
2905          BLT      2$                    ;;GO DO THE NEXT DIGIT
2906          BGT      8$                    ;;GO TO EXIT
2907          MOV      R5,R2                ;;GET THE LSD
2908          BR       6$                    ;;GO CHANGE TO ASCII
2909          TSTB     (SP)+                ;;WAS THE LSD THE FIRST NON-ZERO?
2910          BPL      9$                    ;;BR IF NO
2911          MOVB     -1(SP),-2(R3)          ;;YES--SET THE SIGN FOR TYPING
2912          CLRB     (R3)                  ;;SET THE TERMINATOR
2913          POP      R5,R3,R2,R1,R0
2914          TYPE     $DBLK                ;;NOW TYPE THE NUMBER
2915          MOV      2(SP),4(SP)          ;;ADJUST THE STACK
2916          MOV      (SP)+,(SP)
2917          RTI                          ;;RETURN TO USER
2918          $DTBL: 10000.
2919                1000.
2920                100.
2921                10.
2922          $DBLK: .WORD 0,0,0,0
    
```


2981	073274	001403			BEQ	10\$::BRANCH IF YES
2982	073276	016677	000002	107462	MOV	2(SP),@SWR	::SAVE NEW SWR
2983	073304	062706	000006		10\$: ADD	#6,SP	::CLEAR UP STACK
2984	073310				TYPE	\$CRLF	::ECHO <CR> AND <LF>
2985	073314	000002			12\$: RTI		::RETURN
2986	073316	062706	000002		CKEND: ADD	#2,SP	::FIX STACK
2987	073322	000002			RTI		::RETURN
2988	073324	004737	057076		13\$: CALL	\$TYPEC	::ECHO CHAR
2989	073330	021627	000060		CMF	(SP),#60	::CHAR < 0?
2990	073334	002420			BLT	15\$::BRANCH IF YES
2991	073336	021627	000067		CMF	(SP),#67	::CHAR > 7?
2992	073342	003015			BGT	15\$::BRANCH IF YES
2993	073344	042726	000060		BIC	#60,(SP)+	::STRIP-OFF ASCII
2994	073350	005766	000002		TST	2(SP)	::IS THIS THE FIRST CHAR
2995	073354	001403			BEQ	14\$::BRANCH IF YES
2996	073356	006316			ASL	(SP)	::NO, SHIFT PRESENT
2997	073360	006316			ASL	(SP)	:: CHAR OVER TO MAKE
2998	073362	006316			ASL	(SP)	:: ROOM FOR NEW ONE.
2999	073364	005266	000002		14\$: INC	2(SP)	::KEEP COUNT OF CHAR
3000	073370	056616	177776		BIS	-2(SP),(SP)	::SET IN NEW CHAR
3001	073374	000702			BR	4\$::GET THE NEXT ONE
3002	073376				15\$: TYPE	\$QUES	::TYPE ?<CR><LF>
3003	073402	000724			BR	8\$::SIMULATE CONTROL-U
3004					.DSABL	LSB	

3007 073404

CONT: SUBST <<CONTROL T>>
:*****
:*SUBTEST CONTROL T
:*****

3008 073404
3009 073406
3010 073412
3011
3012 073430 013700 002676
3013 073434 005400
3014 073436
3015 073442
3016 073450
3017 073452
3018 073460
3019 073464
3020 073464
3021 073470
3022 073500
3023 073504 013700 177750
3024 073510 006200
3025 073512 042700 177770
3026 073516
3027 073524
3028 073530
3029 073540
3030 073540
3031 073542 000207
3032
3033 073544

PUSH RO
TYPE \$CRLF
IF MDISPLAY LT #0 AND MDISPLAY GT #-256.
;WE ARE IN MULTIPROCESSOR MODE
MOV MDISPLAY,RO
NEG RO
TYPE MSG100 ;MULTIPROCESSOR TEST #
TYPOCS RO,,3 ;TYPE 3 DIGITS
ELSE
IF RLFLAG IS TRUE
TYPE MSG092 ;RELOCATED
END ;OF IF RLFLAG
TYPE MSG093 ;BANK=
TYPOCS BANK,,3 ;TYPE 3 DIGITS
TYPE MSG094 ;MAR=
MOV MAINT,RO
ASR RO
BIC #^C7,RO
TYPOCS RO,,1 ;TYPE 1 DIGIT
TYPE MSG095 ;PAT=
TYPOCS REALPAT,,2 ;TYPE 2 DIGITS
END ;OF IF @DISPLAY
POP RO
RETURN

CONTS: SUBST <<CONTROL S & CONTROL Q>>
:*****
:*SUBTEST CONTROL S & CONTROL Q
:*****

3034 073544
3035 073546 105777 107220
3036 073552 100375
3037 073554 117716 107214
3038 073560 042716 177600
3039 073564
3040 073572 000137 073052
3041 073576
3042 073600 000762
3043 073602

CONTS2: POP RO ;GET RID OF RETURN ADDRESS FROM STACK
TSTB @STKS ;WAIT FOR CHARACTER
BPL CONTS2
MOVB @STKB,(SP) ;REPLACE OVER OLD CHARACTER ON STACK
BIC #^C177,(SP) ;STRIP ALL BUT ASCII
IF (SP) EQ #21 ;IF IT IS A CONTROL Q
JMP CONTS1
ELSE
BR CONTS2
END ;OF IF (SP)

```

3045
3046
3047
3048
3049
3050
3051
3052
3053 073602 011646
3054 073604 016666 000004 000C02
3055 073612 105777 107154
3056 073616 100375
3057 073620 117766 107150 000004
3058 073626 042766 177600 000004
3059 073634 026627 000004 000023
3060 073642 001013
3061 073644 105777 107122
3062 073650 100375
3063 073652 117746 107116
3064 073656 042716 177600
3065 073662 022627 000021
3066 073666 001366
3067 073670 000750
3068 073672 026627 000004 000140
3069 073700 002407
3070 073702 026627 000004 000175
3071 073710 003003
3072 073712 042766 000040 000004
3073 073720 000002
3074
3075
3076
3077
3078
3079
3080 073722 010346
3081 073724 005046
3082 073726 012703 074200
3083 073732 022703 074224
3084 073736 101467
3085 073740 104411
3086 073742 112613
3087 073744 122713 000003
3088 073750 001006
3089 073752
3090 073756 005726
3091 073760 012603
3092 073762 000137 043416
3093 073766 122713 000177
3094 073772 001022
3095 073774 005716
3096 073776 001007
3097 074000 112737 000134 074176
3098 074006
3099 074012 012716 177777
3100 074016 005303
3101 074020 020327 074200

```

```

*****
*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
*CALL:
*      RDCHR          ;; INPUT A SINGLE CHARACTER FROM THE TTY
*      RETURN HERE   ;; CHARACTER IS ON THE STACK
*                  ;; WITH PARITY BIT STRIPPED OFF
*
$RDCHR: MOV      (SP),-(SP)      ;; PUSH DOWN THE PC
        MOV      4(SP),2(SP)    ;; SAVE THE PS
1$:     TSTB     @STKS          ;; WAIT FOR
        BPL      1$             ;; A CHARACTER
        MOVB     @STKB,4(SP)    ;; READ THE TTY
        BIC      #'C<177>,4(SP) ;; GET RID OF JUNK IF ANY
        CMP      4(SP),#23     ;; IS IT A CONTROL-S?
        BNE      3$            ;; BRANCH IF NO
        TSTB     @STKS          ;; WAIT FOR A CHARACTER
2$:     BPL      2$             ;; LOOP UNTIL ITS THERE
        MOVB     @STKB,-(SP)    ;; GET CHARACTER
        BIC      #'C177,(SP)   ;; MAKE IT 7-BIT ASCII
        CMP      (SP)+,#21     ;; IS IT A CONTROL-Q?
        BNE      2$            ;; IF NOT DISCARD IT
        BR       1$            ;; YES, RESUME
3$:     CMP      4(SP),#140     ;; IS IT UPPER CASE?
        BLT      4$            ;; BRANCH IF YES
        CMP      4(SP),#175    ;; IS IT A SPECIAL CHAR?
        BGT      4$            ;; BRANCH IF YES
        BIC      #40,4(SP)     ;; MAKE IT UPPER CASE
4$:     RTI                    ;; GO BACK TO USER
*****
*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
*CALL:
*      RDLIN         ;; INPUT A STRING FROM THE TTY
*      RETURN HERE   ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
*                  ;; TERMINATOR WILL BE A BYTE OF ALL 0'S
*
$RDLIN: MOV      R3,-(SP)       ;; SAVE R3
        CLR      -(SP)         ;; CLEAR THE RUBOUT KEY
1$:     MOV      #$TTYIN,R3    ;; GET ADDRESS
2$:     CMP      #$TTYIN+20.,R3 ;; BUFFER FULL?
        BLOS    8$            ;; BR IF YES
        RDCHR    ;; GO READ ONE CHARACTER FROM THE TTY
        MOVB     (SP)+,(R3)    ;; GET CHARACTER
        CMPB     #3,(R3)      ;; IS IT A CONTROL-C?
        BNE      3$            ;; BRANCH IF NO
        TYPE     $CNTLC       ;; TYPE A CONTROL-C (^C)
        TST      (SP)+        ;; CLEAN RUBOUT KEY OFF OF THE STACK
        MOV      (SP)+,R3     ;; RESTORE R3
        JMP      BOOT         ;; GOTO CONTROL-C RESTART
3$:     CMPB     #177,(R3)     ;; IS IT A RUBOUT
        BNE      5$            ;; BR IF NO
        TST      (SP)         ;; IS THIS THE FIRST RUBOUT?
        BNE      4$            ;; BR IF NO
        MOVB     #'\\,10$     ;; TYPE A BACK SLASH
        TYPE     10$
        MOV      #-1,(SP)     ;; SET THE RUBOUT KEY
4$:     DEC      R3           ;; BACKUP BY ONE
        CMP      R3,$TTYIN   ;; STACK EMPTY?

```

```

3102 074024 103434          BLO      8$          ;;BR IF YES
3103 074026 111337 074176  MOVB    (R3),10$    ;;SETUP TO TYPEOUT THE DELETED CHAR.
3104 074032          TYPE    10$          ;;GO TYPE
3105 074036 000735          BR      2$          ;;GO READ ANOTHER CHAR.
3106 074040 005716          5$:  TST    (SP)      ;;RUBOUT KEY SET?
3107 074042 001406          BEQ    6$          ;;BR IF NO
3108 074044 112737 000134 074176  MOVB    #' \ ,10$   ;;TYPE A BACK SLASH
3109 074052          TYPE    10$          ;;
3110 074056 005016          CLR    (SP)        ;;CLEAR THE RUBOUT KEY
3111 074060 122713 000025  6$:  CMPB   #25,(R3)   ;;IS CHARACTER A CTRL U?
3112 074064 001003          BNE    7$          ;;BR IF NO
3113 074066          TYPE    $CNTLU     ;;TYPE A CONTROL 'U'
3114 074072 000715          BR      1$          ;;GO START OVER
3115 074074 122713 000022  7$:  CMPB   #22,(R3)   ;;IS CHARACTER A '^R'?
3116 074100 001011          BNE    9$          ;;BRANCH IF NO
3117 074102 105013          CLRB   (R3)        ;;CLEAR THE CHARACTER
3118 074104          TYPE    $CRLF     ;;TYPE A 'CR' & 'LF'
3119 074110          TYPE    $TTYIN    ;;TYPE THE INPUT STRING
3120 074114 000706          BR      2$          ;;GO PICKUP ANOTHER CHACTER
3121 074116          TYPE    $QUES     ;;TYPE A '?'
3122 074122 000701          BR      1$          ;;CLEAR THE BUFFER AND LOOP
3123 074124 111337 074176  9$:  MOVB    (R3),10$   ;;ECHO THE CHARACTER
3124 074130          TYPE    10$          ;;
3125 074134 122723 000015  CMPB   #15,(R3)+   ;;CHECK FOR RETURN
3126 074140 001274          BNE    2$          ;;LOOP IF NOT RETURN
3127 074142 105063 177777  CLRB   -1(R3)      ;;CLEAR RETURN (THE 15)
3128 074146          TYPE    $LF        ;;TYPE A LINE FEED
3129 074152 005726          TST    (SP)+       ;;CLEAN RUBOUT KEY FROM THE STACK
3130 074154 012603          MOV    (SP)+,R3    ;;RESTORE R3
3131 074156 011646          MOV    (SP)-,(SP)  ;;ADJUST THE STACK AND PUT ADDRESS OF THE
3132 074160 016666 000004 000002  MOV    4(SP),2(SP)  ;; FIRST ASCII CHARACTER ON IT
3133 074166 012766 074200 000004  MOV    #$TTYIN,4(SP)
3134 074174 000002          RTI                    ;;RETURN
3135 074176 000          10$: .BYTE 0          ;;STORAGE FOR ASCII CHAR. TO TYPE
3136 074177 000          .BYTE 0          ;;TERMINATOR
3137 074200 000024          $TTYIN: .REPT 20.  ;;RESERVE SIZE BYTES FOR TTY INPUT
3140 074224 136 103 015 $CNTLC: .ASCIZ /^C/<15><12> ;;CONTROL 'C'
3141 074227 012 000          074227 012 000
3141 074231 136 125 015 $CNTLU: .ASCIZ /^U/<15><12> ;;CONTROL 'U'
3142 074234 012 000          074234 012 000
3142 074236 136 107 015 $CNTLG: .ASCIZ /^G/<15><12> ;;CONTROL 'G'
3143 074241 012 000          074241 012 000
3143 074243 015 012 123 $MSWR: .ASCIZ <15><12>/SWR = /
3143 074246 127 122 040
3143 074251 075 040 000
3144 074254 040 040 116 $MNEW: .ASCIZ / NEW = /
3144 074257 105 127 040
3145 074262 075 040 000
3145          .EVEN

```

```

3147          .SBTTL ROUTINE READ AN OCTAL NUMBER FROM THE TTY
3148          ;*****
3149          ;*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
3150          ;*CHANGE IT TO BINARY.
3151          ;*THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
3152          ;*OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A '?' WILL BE TYPED
3153          ;*FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
3154          ;*THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
3155          ;*CALL:
3156          ;*      RDOCT          ;;READ AN OCTAL NUMBER
3157          ;*      RETURN HERE   ;;LOW ORDER BITS ARE ON TOP OF THE STACK
3158          ;*                  ;;HIGH ORDER BITS ARE IN $HIOCT
3159 074266 011646 $RDOCT: MOV      (SP),-(SP) ;;PROVIDE SPACE FOR THE
3160 074270 016666 000004 000002 MOV      4(SP),2(SP) ;;INPUT NUMBER
3161 074276          PUSH      RO,R1,R2
3162 074304 104412 1$:      RDLIN          ;;READ AN ASCII LINE
3163 074306 012600          MOV      (SP)+,RO      ;;GET ADDRESS OF 1ST CHARACTER
3164 074310 010037 074414          MOV      RO,$$          ;;AND SAVE IT
3165 074314 005001          CLR      R1          ;;CLEAR DATA WORD
3166 074316 005002          CLR      R2
3167 074320 112046 2$:      MOVB     (RO)+,-(SP) ;;PICKUP THIS CHARACTER
3168 074322 001420          BEQ      3$          ;;IF ZERO GET OUT
3169 074324 122716 000060          CMPB     #'0,(SP) ;;MAKE SURE THIS CHARACTER
3170 074330 003026          BGT      4$          ;;IS AN OCTAL DIGIT
3171 074332 122716 000067          CMPB     #'7,(SP)
3172 074336 002423          BLT      4$
3173 074340 006301          ASL      R1          ;;*2
3174 074342 006102          ROL      R2
3175 074344 006301          ASL      R1          ;;*4
3176 074346 006102          ROL      R2
3177 074350 006301          ASL      R1          ;;*8
3178 074352 006102          ROL      R2
3179 074354 042716 177770          BIC      #'C7,(SP) ;;STRIP THE ASCII JUNK
3180 074360 062601          ADD      (SP)+,R1 ;;ADD IN THIS DIGIT
3181 074362 000756          BR       2$          ;;LOOP
3182 074364 005726 3$:      TST      (SP)+          ;;CLEAN TERMINATOR FROM STACK
3183 074366 010166 0G0012          MOV      R1,12(SP) ;;SAVE THE RESULT
3184 074372 010237 074434          MOV      R2,$HIOCT
3185 074376          POP      R2,R1,RO
3186 074404 000002          RTI          ;;RETURN
3187 074406 005726 4$:      TST      (SP)+          ;;CLEAN PARTIAL FROM STACK
3188 074410 105010          CLRB     (RO)      ;;SET A TERMINATOR
3189 074412          TYPE          ;;TYPE UP THRU THE BAD CHAR.
3190 074414 000000 5$:      .WORD    0
3191 074416          TYPE    MSG062          ;INPUT MUST BE A
3192 074422          TYPE    MSG063          ;N OCTAL
3193 074426          TYPE    MSG064          ;NUMBER
3194 074432 000724          BR       1$          ;;TRY AGAIN
3195 074434 000000 $HIOCT: .WORD    0          ;;HIGH ORDER BITS GO HERE
3196          .SBTTL ROUTINE READ A DECIMAL NUMBER FROM THE TTY
3197          ;*****
3198          ;*THIS ROUTINE WILL READ A DECIMAL (ASCII) NUMBER FROM THE TTY AND
3199          ;*CHANGE IT TO BINARY. IF TOO MANY CHARACTERS OR ANY ILLEGAL CHARACTERS
3200          ;*ARE READ A '?' FOLLOWED BY A CARRIAGE RETURN-LINE FEED WILL BE TYPED.
3201          ;*THE COMPLETE NUMBER MUST BE RETYPED. THE INPUT IS TERMINATED BY THE
3202          ;*USER TYPING A CARRIAGE RETURN. THE RANGE OF THE INPUT NUMBER IS
3203

```

```

3204          : *POSITIVE 32767 TO NEGATIVE 32768.
3205          : *CALL:
3206          : *      RDDEC          ::READ A DECIMAL NUMBER
3207          : *      RETURN HERE    ::NUMBER IS ON TOP OF THE STACK
3208          :
3209          :
3210 074436 011646          SRDDEC: MOV      (SP),-(SP)      ::PROVIDE SPACE FOR
3211 074440 016666 000004 000002  MOV      4(SP),2(SP)    ::THE INPUT NUMBER
3212 074446          PUSH      R0,R1,R2
3213 074454 104412          1$:  RDLIN          ::READ AN ASCIZ LINE
3214 074456 012600          MOV      (SP)+,R0      ::ADDRESS OF 1ST CHAR.
3215 074460 010037 074604  MOV      R0,6$      ::SAVE INCASE OF BAD INPUT
3216 074464 005046          CLR      -(SP)      ::CLEAR DATA WORD
3217 074466 005002          CLR      R2          ::SIGN SET POSITIVE
3218 074470 122710 000055  CMPB     #'-',(R0)    ::SEE IF A MINUS SIGN WAS TYPED
3219 074474 001001          BNE     2$          ::BR IF NO MINUS SIGN
3220 074476 112002          MOVB    (R0)+,R2    ::SAVE FOR LATER USE
3221 074500 112001          2$:  MOVB    (R0)+,R1    ::PICKUP THIS CHARACTER
3222 074502 001424          BEQ     3$          ::GET OUT IF ZERO
3223 074504 122701 000060  CMPB     #'0,R1      ::MAKE SURE THIS CHARACTER
3224 074510 003032          BGT     5$          ::IS A DIGIT BETWEEN 0 & 9
3225 074512 122701 000071  CMPB     #'9,R1
3226 074516 002427          BLT     5$
3227 074520 032716 170000  BIT      #'C7777,(SP) ::DON'T LET NUMBER GET TO BIG
3228 074524 001024          BNE     5$          ::BR IF NUMBER WOULD OVERFLOW
3229 074526 006316          ASL     (SP)        ::*2
3230 074530 011646          MOV     (SP),-(SP)  ::SAVE FOR LATER
3231 074532 006316          ASL     (SP)        ::*4
3232 074534 006316          ASL     (SP)        ::*8
3233 074536 062616          ADD     (SP)+,(SP)  ::*10
3234 074540 102416          BVS     5$          ::OVERFLOW ISN'T ALLOWED
3235 074542 162701 000060  SUB     #'0,R1      ::STRIP AWAY THE ASCII JUNK
3236 074546 060116          ADD     R1,(SP)    ::ADD IN THIS DIGIT
3237 074550 102412          BVS     5$          ::OVERFLOW ISN'T ALLOWED
3238 074552 000752          BR      2$          ::LOOP
3239 074554 005702          3$:  TST     R2          ::CHECK IF NUMBER IS NEG
3240 074556 001401          BEQ     4$          ::BR IF NO
3241 074560 005416          NEG     (SP)        ::YES--NEGATE THE NUMBER
3242 074562 012666 000012  4$:  MOV     (SP)+,12(SP) ::SAVE THE RESULT
3243 074566          POP     R2,R1,R0
3244 074574 000002          RTI          ::RETURN
3245          :
3246 074576 005726          5$:  TST     (SP)+      ::CLEAN PARTIAL NUMBER FROM STACK
3247 074600 105010          CLRB   (R0)        ::SET A TERMINATOR
3248 074602          TYPE          ::TYPE THE INPUT UP TO BAD CHAR.
3249 074604 000000          6$:  .WORD  0          ::POINTER GOES HERE
3250 074606          TYPE  MSG0L2    ::INPUT MUSST BE A
3251 074612          TYPE  MSG065    ::DECIMAL
3252 074616          TYPE  MSG064    ::NUMBER
3253 074622 000714          BR      1$          ::TRY AGAIN

```

3255
 3256
 3257
 3258
 3259
 3260
 3261
 3262
 3263
 3264
 3265
 3266
 3267
 3268
 3269
 3270
 3271
 3272 074624
 3273 074624
 3274 074640 016646 000022
 3275 074644 016646 000022
 3276 074650 016646 000022
 3277 074654 016646 000022
 3278 074660 000002
 3279
 3280
 3281
 3282
 3283 074662
 3284 074662 012666 000022
 3 3 074666 012666 000022
 3286 074672 012666 000022
 3287 074676 012666 000022
 3288 074702
 3289 074716 000002

.SBTTL ROUTINE SAVE AND RESTORE R0-R5

```

*****
*SAVE R0-R5
*CALL:
*   SAVREG
*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
*
*TOP---(+16)
* +2---(+18)
* +4---R5
* +6---R4
* +8---R3
*+10---R2
*+12---R1
*+14---R0

$SAVREG:
PUSH  R0,R1,R2,R3,R4,R5
MOV   22(SP),-(SP)  ;;SAVE PS OF MAIN FLOW
MOV   22(SP),-(SP)  ;;SAVE PC OF MAIN FLOW
MOV   22(SP),-(SP)  ;;SAVE PS OF CALL
MOV   22(SP),-(SP)  ;;SAVE PC OF CALL
RTI

*RESTORE R0-R5
*CALL:
*   RESREG
$RESREG:
MOV   (SP)+,22(SP)  ;;RESTORE PC OF CALL
MOV   (SP)+,22(SP)  ;;RESTORE PS OF CALL
MOV   (SP)+,22(SP)  ;;RESTORE PC OF MAIN FLOW
MOV   (SP)+,22(SP)  ;;RESTORE PS OF MAIN FLOW
POP   R5,R4,R3,R2,R1,R0
RTI
    
```

.SBTTL ROUTINE RANDOM NUMBER GENERATOR

3291
3292
3293
3294
3295
3296
3297
3298
3299
3300
3301
3302
3303
3304
3305
3306
3307
3308
3309
3310
3311
3312
3313
3314
3315
3316
3317
3318

074720
074726 013700 002716
074732 013701 002714
074736 012702 000007
074742 006300
074744 006101
074746 077203
074750 063700 002716
074754 005501
074756 063701 002714
074762 062700 001057
074766 005501
074770 062701 047401
074774 010037 002716
075000 010137 002714
075004
075012 000207

```

*****
*THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
*WITH A RANGE OF 0 TO 2**(+33)-1.
*CALL:
*      CALL  $RAND          ;;CALL THE ROUTINE
*      RETURN              ;;RETURN HERE THE RANDOM
*                          ;;NUMBER WILL BE IN
*                          ;;$HINUM,$LONUM
*
$RAND:  PUSH  R0,R1,R2      ;SET R0 WITH LOW
        MOV   SEEDLO,R0    ;SET R1 WITH HIGH
        MOV   SEEDHI,R1    ;SET SHIFT COUNT
        MOV   #7,R2        ;;SHIFT R0 LEFT AND
1$      ASL  R0              ;;ROTATE CARRY INTO R1 AND
        ROL  R1
        SOB  R2,1$
        ADD  SEEDLO,R0     ;ADD NUMBER TO MAKE X 129
        ADC  R1             ;;PROPOGATE CARRY
        ADD  SEEDHI,R1     ;ADD NUMBER TO MAKE X 129
        ADD  #1057,R0      ;;ADD LOW CONSTANT
        ADC  R1             ;;PROPOGATE CARRY
        ADD  #47401,R1     ;;ADD HIGH CONSTANT
        MOV  R0,SEEDLO     ;SAVE R0
        MOV  R1,SEEDHI    ;SAVE R1
        POP  R2,R1,R0
        RETURN

```



```

3321          .SBTTL ROUTINE DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT
3322          :*****
3323          :*THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
3324          :*UNSIGNED OCTAL ASCII NUMBER.
3325          :*CALL
3326          :*   MOV   #PNTR,-(SP)   ;; POINTER TO LOW WORD OF BINARY NUMBER
3327          :*   CALL  $DB20      ;; CALL THE ROUTINE
3328          :*   RETURN          ;; THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK
3329
3330
3331 075014 104415          $DB20: SAVREG          ;; SAVE ALL REGISTERS
3332 075016 016601 000002  MOV   2(SP),R1      ;; PICKUP THE POINTER TO LOW WORD
3333 075022 012705 075133  MOV   #$OCTVL+13.,R5  ;; POINTER TO DATA TABLE
3334 075026 012704 000014  MOV   #12.,R4         ;; DO ELEVEN CHARACTERS
3335 075032 012703 177770  MOV   #^C7,R3        ;; MASK
3336 075036 012100          MOV   (R1)+,R0        ;; LOWER WORD
3337 075040 012101          MOV   (R1)+,R1        ;; HIGH WORD
3338 075042 005002          CLR   R2              ;; TERMINATOR
3339 075044 110245          1$: MOVB  R2,-(R5)      ;; PUT CHARACTER IN DATA TABLE
3340 075046 010002          MOV   R0,R2          ;; GET THIS DIGIT
3341 075050 005304          DEC   R4             ;; COUNT THIS CHARACTER
3342 075052 003007          BGT  3$             ;; BR IF NOT THE LAST DIGIT
3343 075054 001405          BEQ  2$             ;; BR IF IT IS THE LAST DIGIT
3344 075056 005205          INC   R5            ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
3345 075060 010566 000002  MOV   R5,2(SP)       ;; ASCII CHAR. & PUT IT ON THE STACK
3346 075064 104416          RESREG          ;; RESTORE ALL REGISTERS
3347 075066 000207          RETURN          ;; RETURN TO USER
3348 075070 006203          2$: ASR   R3         ;; POSITION THE MASK FOR THE LAST DIGIT
3349 075072 006001          3$: ROR   R1         ;; POSITION THE BINARY NUMBER FOR
3350 075074 006000          ROR   R0            ;; THE NEXT OCTAL DIGIT
3351 075076 006001          ROR   R1
3352 075100 006000          ROR   R0
3353 075102 006001          ROR   R1
3354 075104 006000          ROR   R0
3355 075106 040302          BIC   R3,R2         ;; MASK OUT ALL JUNK
3356 075110 062702 000060  ADD   #^0,R2        ;; MAKE THIS CHAR. ASCII
3357 075114 000753          BR    1$           ;; GO PUT IT IN THE DATA TABLE
3358 075116 000016          $OCTVL: .REPT 14.  ;; RESERVE DATA TABLE
3361          $OCT8=$OCTVL*4  ;; POINTER TO 11 DIGIT NUMBER
    
```

TABLES

3363
 3364
 3365
 3366 075134
 3367 075134 000000
 3368 075136 000000
 3369 075140 000000
 3370 075142 000000
 3371 075144 000000
 3372 075146 000000
 3373 075150 000000
 3374 075152 000000
 3375 075154
 3376 075154 000
 3377 075155 000
 3378
 3379 075156 000001
 3380 075160 000000
 3381 075162 030400
 3382
 3383
 3384
 3385
 3386
 3387
 3388 075164 001
 3389 075165 004
 3390
 3391
 3392
 3393
 3394
 3395 075166 177776
 3396
 3397 075170 000
 3398 075171 000
 3399 075172 000000
 3400 075174 000
 3401 075175 000
 3402 075176 000000
 3403 075200 000
 3404 075201 000
 3405 075202 000000
 3406 075204 000000
 3407 075206 000000
 3408 075210 000000
 3409 075212 000000
 3410
 3411
 3412
 3413 075214 000000
 3414 075216 000000
 3415
 3416
 3417
 3418
 3419

.SBTTL TABLES

.SBTTL APT MAILBOX-ETABLE

SMAIL:
 \$MSGTY: .WORD 0 ;;MESSAGE TYPE CODE
 \$FATAL: .WORD 0 ;;FATAL ERROR NUMBER (ERROR PC)
 \$TESTN: .WORD 0 ;;TEST NUMBER (DISPLAY REGISTER)
 \$PASS: .WORD 0 ;;PASS COUNT
 \$DEVCT: .WORD 0 ;;DEVICE COUNT
 \$UNIT: .WORD 0 ;;I/O UNIT NUMBER
 \$MSGAD: .WORD 0 ;;MESSAGE ADDRESS
 \$MSGLG: .WORD 0 ;;MESSAGE LENGTH
 \$ETABLE: ;;APT ENVIRONMENT TABLE
 \$ENV: .BYTE 0 ;;ENVIRONMENT BYTE ;SET TO A 1 FOR APT AUTO MODE
 \$ENVM: .BYTE 0 ;;ENVIRONMENT MODE
 ;;BIT7(200)=USE APT SIZE INFO ;BIT5(40)=NO CONSOLE
 ;;APT SWITCH REGISTER
 ;;USED TO LIMIT THE NUMBER OF PASSES
 \$CPUOP: .WORD 30400 ;;CPU TYPE,OPTIONS
 ;;BITS 15-11=CPU TYPE
 ;; 11/04=01,11/05=02,11/20=03,11/40 04,11/45 05
 ;; 11/70=06,PDQ=07,Q=10
 BIT 10=REAL TIME CLOCK
 BIT 9=FLOATING POINT PROCESSOR
 BIT 8=MEMORY MANAGEMENT
 \$MAMS1: .BYTE 1 ;;HIGH ADDRESS,M.S. BYTE ;DEFAULT 64K
 \$MTYP1: .BYTE 4 ;;MEM. TYPE,BLK#1
 ;;MEM. TYPE BYTE -- (HIGH BYTE)
 ;; 900 NSEC CORE=001
 ;; 300 NSEC BIPOLAR=002
 ;; 500 NSEC MOS=003
 ;; MK11 ERROR CORRECTING MOS 004
 \$MADR1: .WORD 177776 ;;HIGH ADDRESS,BLK#1
 ;; MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE
 \$MAMS2: .BYTE 0 ;;HIGH ADDRESS,M.S. BYTE
 \$MTYP2: .BYTE 0 ;;MEM. TYPE,BLK#2
 \$MADR2: .WORD 0 ;;MEM.LAST ADDRESS,BLK#2
 \$MAMS3: .BYTE 0 ;;HIGH ADDRESS,M.S. BYTE
 \$MTYP3: .BYTE 0 ;;MEM. TYPE,BLK#3
 \$MADR3: .WORD 0 ;;MEM.LAST ADDRESS,BLK#3
 \$MAMS4: .BYTE 0 ;;HIGH ADDRESS,M.S. BYTE
 \$MTYP4: .BYTE 0 ;;MEM. TYPE,BLK#4
 \$MADR4: .WORD 0 ;;MEM.LAST ADDRESS,BLK#4
 \$VECT1: .WORD 0 ;;INTERRUPT VECTOR#1,BUS PRIORITY#1
 \$VECT2: .WORD 0 ;;INTERRUPT VECTOR#2BUS PRIORITY#2
 \$BASE: .WORD 0 ;;BASE ADDRESS OF EQUIPMENT UNDER TEST
 \$DEVN: .WORD 0 ;;DEVICE MAP
 ;IF EITHER OF THESE 2 WORDS ARE NOW ZERO
 ;THEY WILL BE LOADED INTO ALL CSR'S & THE PROGRAM WILL STOP
 \$CDW1: .WORD 0 ;CSR
 \$CDW2: .WORD 0 ;CSR+2
 ;THE FOLLOWING LOCATIONS SPECIFY WHICH PATTERNS
 ;ARE TO BE RUN FOR PARTICULAR MEMORIES
 ;
 ;REFERENCE THE TABLE LISTED BELOW TO RELATE BITS TO PATTERNS.

```

3420
3421
3422
3423
3424
3425 075220 177777
3426 075222 177777
3427 075224 102777
3428 075226 177777
3429 075230 103777
3430 075232 177777
3431 075234 000001
3432 075236
3433
3434
3435
3436 075236
3437 075236 000000
3438 075240 075134
3439 075242 000010
3440 075244 000144
3441 075246 0003'0
3442 075250 000041

:BITO SET WILL RUN THE FIRST ENTRY IN THE TABLE, BITO SET
:IN THE SECOND WORD WILL RUN THE 17TH ENTRY IN THE TABLE ...
:
:NOTE** NULL TESTS DO NOT TAKE ANY TIME
:
$DDW0: .WORD 177777 ;MK11 CSR TESTS TABLE = MKCSRT:
$DDW1: .WORD 177777 ;MK11 CSR TESTS TABLE = MKCSRT:
$DDW2: .WORD 102777 ;MK11 PATTERNS TABLE = MKPAT:
$DDW3: .WORD 177777 ;MK11 PATTERNS TABLE = MKPAT:
$DDW4: .WORD 103777 ;MJ11 PATTERNS TABLE = MJPAT:
$DDW5: .WORD 177777 ;MJ11 PATTERNS TABLE = MJPAT:
$DDW6: .WORD 1 ;NUMBER OF CPU'S
$ETEND:
:SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
:INTERFACE SPEC.

$APTHD:
$HIBTS: .WORD 0 ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBADR: .WORD $MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)
$STMT: .WORD 8. ;;RUN TIM OF LONGEST TEST
$PASTM: .WORD 100. ;;RUN TIME IN SECS. OF 1ST PASS ON 128k (QUICK VERIFY)
$UNITM: .WORD 200. ;;ADDITIONAL RUN TIME OF A PASS FOR EACH ADDITIONAL 128k
.WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE (WORDS)

```

```

3444                                     .SBTTL ROUTINE TRAP DECODER
3445
3446                                     :*****
3447                                     :*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
3448                                     :*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
3449                                     :*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
3450                                     :*GO TO THAT ROUTINE.
3451
3452 075252 010046                       $TRAP: MOV      R0,-(SP)           ;;SAVE R0
3453 075254 016600 000002               MOV      2(SP),R0          ;;GET TRAP ADDRESS
3454 075260 005740                       TST      -(R0)            ;;BACKUP BY 2
3455 075262 111000                       MOV      (R0),R0         ;;GET RIGHT BYTE OF TRAP
3456 075264 006300                       ASL      R0               ;;POSITION FOR INDEXING
3457 075266 016000 075314               MOV      $TRPAD(R0),R0   ;;INDEX TO TABLE
3458 075272 000200                       RTS      R0               ;;GO TO ROUTINE
3459
3460
3461                                     ;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
3462
3463 075274 011646                       $TRAP2: MOV     (SP),-(SP) ;;MOVE THE PC DOWN
3464 075276 016666 000004 000002        MOV     4(SP),2(SP)      ;;MOVE THE PSW DOWN
3465 075304 000002                       RTI                      ;;RESTORE THE PSW
3466
3467 075306                               $NOTRAP:TYPE  MSG006      ;UNDEFINED TRAP INSTRUCTION
3468 075312 000000                       $HALT2: HALT
    
```

TRAP TABLE

.SBTTL TRAP TABLE

.*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
 .*BY THE 'TRAP' INSTRUCTION.

3471
 3472
 3473
 3474
 3475
 3476
 3477
 3478
 3479
 3480
 3481
 3482
 3483
 3484
 3485
 3486
 3487
 3488
 3489
 3490
 3491
 3492
 3493
 3494
 3495
 3496
 3497
 3498
 3499
 3500
 3501
 3502
 3503
 3504
 3505
 3506
 3507
 3508
 3509
 3510
 3511
 3512
 3513
 3514
 3515
 3516
 3517
 3518
 3519
 3520
 3521
 3522
 3523
 3524
 3525
 3526
 3527

075314 075274
 075316 056752
 075320 072374
 075322 072350
 075324 075306
 075326 072576
 075330 075306
 075332 073160
 075334 073022
 075336 073602
 075340 073722
 075342 074266
 075344 074436
 075346 074624
 075350 074662
 075352 037020
 075354 037030
 075356 037040
 075360 041016
 075362 037050
 075364 037066
 075366 037076
 075370 037220
 075372 064574
 075374 064622
 075376 064650
 075400 064700
 075402 064762
 075404 065004
 075406 065034
 075410 065054
 075412 065076
 075414 065116
 075416 065140
 075420 065162
 075422 065202
 075424 065220
 075426 065236
 075430 065256
 075432 065274
 075434 065312
 075436 054570

```

ROUTINE
-----
$TRPAD: .WORD $TRAP2
$TYPE :CALL=TYPEIT TRAP+1(104401) TTY TYPEOUT ROUTINE
$TYPOC :CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
$TYPOS :CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
$NOTRAP:$TYPON :CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
$TYPDS :CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
$NOTRAP:$TYPBN :CALL=TYPBN TRAP+6(104406) TYPE BINARY (ASCII) NUMBER

$GTSWR :CALL=GTSWR TRAP+7(104407) GET SOFT-SWR SETTING
$CKSWR :CALL=CKSWR TRAP+10(104410) TEST FOR CHANGE IN SOFT-SWR

$RDCHR :CALL=RDCHR TRAP+11(104411) TTY TYPEIN CHARACTER ROUTINE
$RDLIN :CALL=RDLIN TRAP+12(104412) TTY TYPEIN STRING ROUTINE
$RDOCT :CALL=RDOCT TRAP+13(104413) READ AN OCTAL NUMBER FROM TTY
$RDDEC :CALL=RDDEC TRAP+14(104414) READ A DECIMAL NUMBER FROM TTY

$SAVREG :CALL=SAVREG TRAP+15(104415) SAVE R0-R5 ROUTINE
$RESREG :CALL=RESREG TRAP+16(104406) RESTORE R0-R5 ROUTINE

$KERNEL :CALL=KERNEL TRAP+17(104417) ENTER KERNEL MODE
$ENERGIZE:CALL=ENERGIZETRAP+20(104420) TURN ON MEMORY MANAGEMENT & TRAPS
$DEENERGI:CALL=DEENERGITRAP+21(104421) TURN OFF MEMORY MANAGEMENT & TRAPS

$KMAP :CALL=KMAP TRAP+22(104422) MAP KERNEL 1 TO 1

$CACHN :CALL=CACHON TRAP+23(104423) TURN CACHE ON
$CACHF :CALL=CACHOFF TRAP+24(104424) TURN CACHE OFF

$LOADC :CALL=LOADCSR TRAP+25(104425) LOAD CORRECT CSR
$READC :CALL=READCSR TRAP+26(104426) READ CORRECT CSR

$PER01 :CALL=PERR01 TRAP+27(104427) PROGRAM DETECTED ERROR
$PER02 :CALL=PERR02 TRAP+30(104430) PROGRAM DETECTED ERROR
$PER03 :CALL=PERR03 TRAP+31(104431) PROGRAM DETECTED ERROR
$PER04 :CALL=PERR04 TRAP+32(104432) PROGRAM DETECTED ERROR
$PER07 :CALL=PERR07 TRAP+33(104433) PROGRAM DETECTED ERROR
$PER10 :CALL=PERR10 TRAP+34(104434) PROGRAM DETECTED ERROR
$PER11 :CALL=PERR11 TRAP+35(104435) PROGRAM DETECTED ERROR
$PER12 :CALL=PERR12 TRAP+36(104436) PROGRAM DETECTED ERROR
$PER13 :CALL=PERR13 TRAP+37(104437) PROGRAM DETECTED ERROR
$PER14 :CALL=PERR14 TRAP+40(104440) PROGRAM DETECTED ERROR
$PER15 :CALL=PERR15 TRAP+41(104441) PROGRAM DETECTED ERROR
$PER16 :CALL=PERR16 TRAP+42(104442) PROGRAM DETECTED ERROR
$PER17 :CALL=PERR17 TRAP+43(104443) PROGRAM DETECTED ERROR
$PER20 :CALL=PERR20 TRAP+44(104444) PROGRAM DETECTED ERROR
$PER21 :CALL=PERR21 TRAP+45(104445) PROGRAM DETECTED ERROR
$PER22 :CALL=PERR22 TRAP+46(104446) PROGRAM DETECTED ERROR
$PER23 :CALL=PERR23 TRAP+47(104447) PROGRAM DETECTED ERROR
$PER24 :CALL=PERR24 TRAP+50(104450) PROGRAM DETECTED ERROR
$PER25 :CALL=PERR25 TRAP+51(104451) PROGRAM DETECTED ERROR
    
```

TRAP TABLE

3528	075440	065502	\$PER26	:CALL=PERR26	TRAP+52(104452)	PROGRAM DETECTED ERROR
3529	075442	065522	\$PER27	:CALL=PERR27	TRAP+53(104453)	PROGRAM DETECTED ERROR
3530	075444	054762	\$PER30	:CALL=PERR30	TRAP+54(104454)	PROGRAM DETECTED ERROR
3531	075446	065720	\$PER31	:CALL=PERR31	TRAP+55(104455)	PROGRAM DETECTED ERROR
3532	075450	066016	\$PER32	:CALL=PERR32	TRAP+56(104456)	PROGRAM DETECTED ERROR
3533	075452	066064	\$PER33	:CALL=PERR33	TRAP+57(104457)	PROGRAM DETECTED ERROR
3534	075454	066144	\$PER34	:CALL=PERR34	TRAP+60(104460)	PROGRAM DETECTED ERROR
3535	075456	066176	\$PER35	:CALL=PERR35	TRAP+61(104461)	PROGRAM DETECTED ERROR
3536	075460	075306	\$NOTRAP	:CALL=PERR36	TRAP+62(104462)	PROGRAM DETECTED ERROR
3537	075462	075306	\$NOTRAP	:CALL=PERR37	TRAP+63(104463)	PROGRAM DETECTED ERROR
3538	075464	075306	\$NOTRAP	:CALL=PERR40	TRAP+64(104464)	PROGRAM DETECTED ERROR
3539	075466	075306	\$NOTRAP	:CALL=PERR41	TRAP+65(104465)	PROGRAM DETECTED ERROR
3540	075470	075306	\$NOTRAP	:CALL=PERR42	TRAP+66(104466)	PROGRAM DETECTED ERROR
3541	075472	075306	\$NOTRAP	:CALL=PERR43	TRAP+67(104467)	PROGRAM DETECTED ERROR
3542						
3543	075474	037466	\$ECCDIS	:CALL=ECCDIS	TRAP+70(104470)	DISABLE ECC ON ALL CSR'S
3544	075476	037522	\$ECC1DIS	:CALL=ECC1DIS	TRAP+71(104471)	DISABLE ECC ON 1 SELECTED CSR
3545	075500	037554	\$ECCINIT	:CALL=ECCINIT	TRAP+72(104472)	INITIALIZE ALL MK11 CSR'S
3546	075502	037574	\$ECC1INIT	:CALL=ECC1INIT	TRAP+73(104473)	INITIALIZE 1 SELECTED MK11 CSR
3547	075504	037700	\$CBCSR	:CALL=CBCSR	TRAP+74(104474)	WRITE GENERATED CHECKBITS IN ALL CSR'S
3548	075506	037742	\$CB1CSR	:CALL=CB1CSR	TRAP+75(104475)	WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
3549	075510	040002	\$WASSBE	:CALL=WASSBE	TRAP+76(104476)	WAS THERE A SBE ON ANY CSR?
3550	075512	040116	\$WAS1SBE	:CALL=WAS1SBE	TRAP+77(104477)	WAS THERE A SBE ON 1 SELECTED CSR?
3551	075514	040146	\$WASDBE	:CALL=WASDBE	TRAP+100(104500)	WAS THERE A DBE ON ANY CSR?
3552	075516	040262	\$WAS1DBE	:CALL=WAS1DBE	TRAP+101(104501)	WAS THERE A DBE ON 1 SELECTED CSR?
3553	075520	040322	\$CLRCSR	:CALL=CLRCSR	TRAP+102(104502)	CLEAR ALL CSR'S
3554	075522	040340	\$CLR1CSR	:CALL=CLR1CSR	TRAP+103(104503)	CLEAR 1 SELECTED CSR
3555	075524	040354	\$CHKDIS	:CALL=CHKDIS	TRAP+104(104504)	DISABLE ECC & WRITE CKBITS FROM ALL CSR'S
3556	075526	040410	\$CHK1DIS	:CALL=CHK1DIS	TRAP+105(104505)	DISABLE ECC & WRITE CKBITS FROM 1 CSR
3557	075530	037612	\$ENASBE	:CALL=ENASBE	TRAP+106(104506)	ENABLE TRAPS ON SBE'S FROM ALL CSR'S
3558	075532	037646	\$ENA1SBE	:CALL=ENA1SBE	TRAP+107(104507)	ENABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
3559	075534	037310	\$TSTRD	:CALL=TSTRD	TRAP+110(104510)	TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES
3560	075536	040510	\$INVALID	:CALL=INVALID	TRAP+111(104511)	INVALIDATE BACKGROUND PATTERN ON BANK
3561	075540	075306	\$NOTRAP			
3562	075542	075306	\$NOTRAP			
3563	075544	075306	\$NOTRAP			
3564	075546	075306	\$NOTRAP			
3565	075550	075306	\$NOTRAP			
3566	075552	075306	\$NOTRAP			
3567	075554	075306	\$NOTRAP			
3568	075556	075306	\$NOTRAP			

			.SBTTL ODT (CEMKA) DATA AREA	
3571		ST	-	177776 ;STATUS REGISTER
3572	177776	O.BKP	=	16 ;NUMBER OF BREAKPOINTS-1 MULT. BY 2
3573	000016	O.TVEC	=	14 ;TRT VECTOR LOCATION
3574	000014	O.STM	-	340 ;PRIORITY MASK - STATUS REGISTER
3575	000340	O.TBT	-	20 ;T-BIT MASK - STATUS REGISTER
3576	000020	TRT	=	000003 ;TRT INSTRUCTION
3577	000003	O.RDB	=	177562 ;R DATA BUFFER
3578	177562	O.RCSR	-	177560 ;R C/SR
3579	177560	O.TDB	-	177566 ;T DATA BUFFER
3580	177566	O.TCSR	-	177564 ;T C/SR
3581	177564			

3585	075560	000000	O.CAD:	0	:	CURRENT ADDRESS
3586	075562	000000	O.DOT:	0	:	ORIGIN ADDRESS
3587	075564	000000	O.XXX:	.WORD 0	:	TEMPORARY STORAGE
3588	075566	000000	O.BW:	.WORD 0	:	=0 - ALL CLOSED
3589					:	=1 - BYTE OPEN,
3590					:	=2 - WORD OPEN
3591	075570	000	O.SEQ:	.BYTE 0	:	CHANGE SEQUENCE INDICATOR
3592	075571	000	O.S:	.BYTE 0	:	SINGLE INSTRUCTION FLAG
3593					:	0 IF NOT ACTIVE
3594					:	-1 IF ACTIVE
3595					:	NO BREAK POINTS MAY BE SET WHILE IN
3596					:	SINGLE INSTRUCTION MODE
3597	075572	000	O.T:	.BYTE 0	:	T-BIT FLAG
3598	075573	000	O.P:	.BYTE 0	:	PROCEED FLAG = -2 IF MANUAL ENTRY
3599					:	-1 IF NO PROCEED ALLOWED
3600					:	0-7 IF PCEED ALLOWED
3601	075574	000	O.CSR1:	.BYTE 0	:	SAVE CELL - R C/SR
3602	075575	000	O.CSR2:	.BYTE 0	:	SAVE CELL - T C/SR
3603	075576	000000	O.FIL:	0	:	FILL COUNTER
3604	075600	000	O.CMFD:	.BYTE 0	:	COMMA FOUND SWITCH, -0 NO COMMA FOUND
3605					:	1 COMMA FOUND
3606	075601	000	O.SMFD:	.BYTE 0	:	SEMICOLON FOUND SWITCH
3607					:	=0 NO SEMICOLON FOUND
3608					:	=1 SEMICOLON FOUND
3609	075602	000	O.SCRN:	.BYTE 0	:	FLAG; 1=PASS SPACES ON FROM TTY
3610					:	ALSO, IF =1, <LF> IS ECHOED
3611	075603	000	O.MINS:	.BYTE 0	:	MINUS SIGN TYPED (SWITCH)
3612					:	0=NO MINUS TYPED; 1-MINUS SIGN TYPED
3613	075604	000000	O.BIAS:	.WORD 0	:	CURRENT RELOCATION BIAS


```

3642      : INITIALIZE ODT
3643      : USE O.ODT FOR A NORMAL ENTRY
3644      : USE O.ODT+2 TO RESTART ODT - WIPING OUT ALL BREAKPOINTS
3645      : USE O.ODT+4 TO RE-ENTER (I.E. - FAKE A BREAKPOINT)
3646
3647 075774 000421      0.ODT: BR      2$      ;NORMAL ENTRY
3648 075776 000440      BR      3$      ;RESTART
3649 076000 004737 101172 1$: JSR    PC,O.RRST ;RE-ENTER -- SAVE STATUS
3650 076004 013746 000016      MOV    O.TVEC+2,-(SP) ;SET UP LOCAL STATUS
3651 076010 004737 101202      JSR    PC,O.WST
3652 076014 010746      MOV    PC,-(SP)      ;FAKE THE PC
3653 076016 012637 075700      MOV    (SP)+,O.UPC
3654 076022 112737 177777 075573      MOVB  #-1,O.P      ;DISALLOW PROCEED
3655 076030 105037 075571      CLRB  O.S
3656 076034 000137 100060      JMP   O.BK1
3657
3658      ;RUN AT CURRENT STATUS
3659 076040 004537 100500      2$: JSR    5,O.SVTT ;SAVE TTY STATUS
3660 076044 012737 076000 073114      MOV    #1$,O.CONTP+2
3661 076052 004037 100360      JSR    O,O.SVR ;SAVE REGISTERS (MAINLY SP)
3662 076056 012706 075662      MOV    #O.URO,SP ;SET UP STACK
3663 076062 012704 101300      MOV    #O.ID,R4 ;TYPE ID
3664 076066 012703 101315      MOV    #O.IDND,R3
3665 076072 004537 101126      JSR    5,O.TYPE
3666 076076 000414      BR      4$
3667 076100 004037 100360      3$: JSR    O,O.SVR ;SAVE REGISTERS
3668 076104 004537 100602      JSR    5,O.REM ;REMOVE ALL BREAKPOINTS
3669 076110 113704 075704      MOVB  O.PRI,R4 ;GET ODT PRIORITY
3670 076114 106004      RORB  R4 ;SHIFT
3671 076116 106004      RORB  R4 ; INTO
3672 076120 106004      RORB  R4 ; POSITION
3673 076122 010446      MOV    R4,-(SP) ;STORE IN STATUS
3674 076124 004737 101202      JSR    PC,O.WST
3675 076130 105037 075571      4$: CLRB  O.S ;DISABLE SINGLE INSTRUCTION FOR NOW
3676 076134 112737 177777 075573      MOVB  #-1,O.P ;DISALLOW PROCEED
3677 076142 012737 000340 000016      MOV    #O.STM,O.TVEC+2 ;STATUS WORD TO TRT VECTOR+2
3678 076150 012737 100042 000014      MOV    #O.BRK,O.TVEC ;PC TO TRT VECTOR
3679 076156 000137 077430      JMP   O.RALL ;CLEAR BRK PT TABLES
3680
3681      :
3682      :O.CTLC
3683      :
3684      :
3685 076162 013706 075676      0.CTLC: MOV    O.USP,SP ;RESTORE USER STACK
3686 076166 012704 076206      MOV    #1$,R4
3687 076172 012703 076207      MOV    #2$,R3
3688 076176 004537 101126      JSR    R5,O.TYPE ;ECHO '^C'
3689 076202 000137 043416      JMP   BOOT
3690 076206      1$: .BYTE 'A'
3691 076207      2$: .BYTE 'C'

```

```

3694
3695 076210 013706 075676
3696 076214 012704 076240
3697 076220 012703 076241
3698 076224 004537 101126
3699 076230 004737 043774
3700 076234 000137 075774
3701 076240 136
3702 076241 106
3703
3704
3705 076242 012704 076266
3706 076246 012703 076267
3707 076252 004537 101126
3708 076256 012705 073116
3709 076262 000137 077624
3710 076266 136
3711 076267 105
3712
3713
3714
3715
3716 076270 004537 101006
3717 076274 012704 101345
3718 076300 120024
3719 076302 001414
3720 076304 022704 101365
3721 076310 101373
3722 076312 042700 177770
3723 076316 010004
3724 076320 006304
3725 076322 062704 075662
3726 076326 005202
3727 076330 000137 076554
3728 076334 162704 101336
3729 076340 000767
    
```

```

;CONTROL F PROCESSING
O.CTLF: MOV O.USP,SP ;RESTORE USER STACK
        MOV #1$,R4
        MOV #2$,R3
        JSR R5,O.TYPE ;ECHO ^F
        CALL FIELDSERVICE
        JMP O.ODT
1$: .BYTE '^'
2$: .BYTE 'F'

;CONTROL E PROCESSING
O.CTLE: MOV #1$,R4
        MOV #2$,R3
        JSR R5,O.TYPE ;ECHO ^E
        MOV #CONTP+4,R5
        JMP O.GOGO
1$: .BYTE '^'
2$: .BYTE 'E'

; SPECIAL NAME HANDLER
; DEPENDS UPON THE EXPLICIT ORDER OF THE TWO TABLES O.TL AND O.URO
O.REGT: JSR S,O.GET ;SPECIAL NAME, GET ONE MORE CHARACTER
        MOV #O.TL,R4 ;TABLE START ADDRESS
1$: CMPB R0,(R4)+ ;IS THIS THE CORRECT CHARACTER?
     BEQ 3$ ;JUMP IF YES
     CMP #O.TL+O.LG,R4 ;IS THE SEARCH DONE?
     BHI 1$ ;BRANCH IF NOT
     BIC #177770,R0 ;MASK OFF OCTAL
     MOV R0,R4
2$: ASL R4
     ADD #O.URO,R4 ;GENERATE ADDRESS
     INC R2 ;SET FOUND FLAG
     JMP O.SCAN ;GO FIND NEXT CHARACTER
3$: SUB #O.TL-7,R4 ;GO FIND NEXT CHARACTER
     BR 2$
    
```

```

3732          : 'BACKARROW' HANDLER - OPEN INDEXED ON THE PC (BACK ARROW)
3733          .ENABL  LSB
3734 076342 004537 076416 0.ORPC: JSR 5,2$          ;TEST WORD MODE AND CLOSE
3735 076346 061202          ADD @R2,R2          ;COMPUTE
3736 076350 005202          INC R2
3737 076352 005202          INC R2          ; NEW ADDRESS
3738 076354 010237 075560 1$: MOV R2,0,CAD      ;UPDATE CAD
3739 076360 000137 077226  JMP 0,OP2A        ;GO FINISH UP
3740 076364 004537 076416 0.OPAB: JSR 5,2$          ;TEST WORD MODE AND CLOSE
3741 076370 011202          MOV @R2,R2        ;GET ABSOLUTE ADDRESS
3742 076372 000770          BR 1$
3743 076374 004537 076416 0.ORRB: JSR 5,2$          ;TEST AND CLOSE
3744 076400 011201          MOV @R2,R1        ;COMPUTE NEW ADDRESS
3745 076402 110101          MOVB R1,R1        ;EXTEND THE SIGN
3746 076404 006301          ASL R1          ;R2=2(@R2)
3747 076406 005201          INC R1          ; +2
3748 076410 005201          INC R1
3749 076412 060102          ADD R1,R2        ; +PL
3750 076414 000757          BR 1$
3751 076416 004737 101214 2$: JSR PC,0,CLSE      ;CLOSE CURRENT CELL
3752 076422 022737 000002 075566  CMP #2,0,BW      ;ONLY WORD MODE ALLOWED
3753 076430 001003          BNE 3$          ;BRANCH IF ERROR
3754 076432 013702 075560  MOV 0,CAD,P2     ;CURRENT ADDRESS IN R2
3755 076436 000205          RTS R5
3756 076440 005726 3$: TST (SP)+
3757 076442 000137 076510 0.TCL2: JMP 0,ERR          ;POP A WORD AND SHOW THE ERROR
3758          .DSABL  LSB
3759
3760          : PROCESS S - SINGLE INSTRUCTION MODE
3761 076446 105737 075601 0.SNGL: TSTB 0,SMFD      ;DONT REACT IF ; NOT TYPED
3762 076452 001773          BEQ 0,TCL2
3763 076454 005702          TST R2          ;SEE IF TURN ON OR TURN OFF
3764 076456 001004          BNE 1$          ;BRANCH IF TURNING IT ON
3765 076460 105037 075571  CLRB 0,S          ;CLEAR THE FLAG
3766 076464 000137 076520  JMP 0,DCD        ;CONTINUE THE SCAN
3767 076470 112737 177777 075571 1$: MOVB #-1,0,S      ;SET THE FLAG
3768 076476 000137 076520  JMP 0,DCD
    
```

```

3771
3772
3773
3774 076502 105237 075603
3775 076506 000420
3776
3777
3778
3779
3780
3781 076510 012700 000077
3782 076514 004537 100730
3783 076520 005037 075566
3784 076524 004537 101254
3785 076530 105037 075601
3786 076534 105037 075600
3787 076540 105037 075603
3788 076544 005003
3789 076546 005005
3790 076550 005004
3791 076552 005002
3792 076554 004537 101006
3793 076560 022700 000060
3794 076564 101013
3795 076566 022700 000067
3796 076572 103410
3797 076574 042700 177770
3798 076600 006304
3799 076602 006304
3800 076604 006304
3801 076606 060004
3802 076610 005202
3803 076612 000760
3804 076614 005001
3805 076616 120061 101321
3806 076622 001405
3807 076624 005201
3808 076626 020127 000024
3809 076632 103326
3810 076634 000770
3811 076636 105737 075603
3812 076642 001401
3813 076644 005404
3814 076646 105737 075600
3815 076652 001402
3816 076654 063704 075604
3817 076660 105037 075603
3818 076664 006301
3819 076666 000171 076672

; MINUS PROCESSING
;
O.MIN: INCB O.MINS ; SET MINUS FOUND SWITCH ON
BR O.DCD1

; COMMAND DECODER - ODT11X
; ALL REGISTERS MAY BE USED (R0-R5),
O.ERR: MOV #'?,R0 ; ? TO BE TYPED
JSR S.O.FTYP ; OUTPUT ?
O.DCD: CLR O.BW ; CLOSE ALL
JSR S.O.CRLS ; TYPE <CR><LF>*
O.DCD3: CLRB O.SMFD ; SEMICOLON FOUND FLAG
CLRB O.CMFD ; COMMA FOUND FLAG
CLRB O.MINS ; MINUS SIGN FOUND FLAG
CLR R3 ; R3 IS A SAVE REGISTER FOR R2
CLR R5 ; R5 IS A SAVE REGISTER FOR R4
O.DCD1: CLR R4 ; R4 CONTAINS THE CONVERTED OCTAL
CLR R2 ; R2 IS THE NUMBER FOUND FLAG
O.SCAN: JSR S.O.GET ; GET A CHAR, RETURN IN R0
CMP #'0,R0 ; COMPARE WITH ASCII 0
BHI S$ ; CHECK LEGALITY IF NON-NUMERIC
CMP #'7,R0 ; COMPARE WITH ASCII 7
BLO S$ ; CHECK LEGALITY IF NOT OCTAL
BIC #177770,R0 ; CONVERT TO BCD
ASL R4 ; MAKE ROOM
ASL R4 ; IN
ASL R4 ; R4
ADD R0,R4 ; PACK THREE BITS IN R4
INC R2 ; R2 HAS NUMERIC FLAG
BR O.SCAN ; AND TRY AGAIN
S$: CLR R1 ; CLEAR INDEX
1$: CMPB R0,O.LGCH(R1) ; DO THE CODES MATCH?
BEQ 2$ ; JUMP IF YES
INC R1 ; SET INDEX FOR NEXT SEARCH
CMP R1,#O.CLGT ; IS THE SEARCH DONE?
BHI S$ ; OOPS!
BR 1$ ; RE-LOOP
2$: TSTB O.MINS ; IF MINUS WAS NOT TYPED
BEQ 4$ ; DO NOT NEGATE K
NEG R4 ; OTHERWISE, TAKE 2'S COMPLEMENT.
4$: TSTB O.CMFD ; IF A COMMA NOT TYPED,
BEQ 3$ ; SKIP NEXT INSTRUCTION.
ADD O.BIAS,R4 ; OTHERWISE, ADD RELOC. BIAS TO (R4)
3$: CLRB O.MINS ; REINITIALIZE MINUS-TYPED SWITCH FOR NXT SCAN
ASL R1 ; MULTIPLY BY TWO
JMP @C$(R1) ; GO TO PROPER ROUTINE
    
```

3822	076672	076742	68:	O.SEMI	:	.	SEMICOLON
3823	076674	076760		O.WRD	:	/	OPEN WORD
3824	076676	076772		O.BYT	:	\	OPEN BYTE -BACK SLASH
3825	076700	077140		O.CRET	:		CARRIAGE RETURN CLOSE
3826	076702	076270		O.REGT	:	\$	REGISTER OPS
3827	076704	077576		O.GO	:	G	GO TO ADDRESS K
3828	076706	077160		O.OP1	:	<LF>	MODIFY, CLOSE, OPEN NEXT
3829	076710	076342		O.ORPC	:	'BACKARROW'	OPEN RELATED, INDEX - PC (BACK ARROW)
3830	076712	077154		O.OLD	:	<	RETURN TO OLD SEQUENCE AND OPEN
3831	076714	077302		O.BACK	:	^	OPEN PREVIOUS (UP ARROW)
3832	076716	077466		O.OFST	:	O	OFFSET
3833	076720	077324		O.BKPT	:	B	BREAKPOINTS
3834	076722	077732		O.PROC	:	P	PROCEED
3835	076724	076364		O.ORAB	:	@	OPEN RELATED, ABSOLUTE
3836	076726	076374		O.ORRB	:	>	OPEN RELATED, REL. BRANCH
3837	076730	076446		O.SNGL	:	S	SINGLE INSTRUCTION MODE
3838	076732	076502		O.MIN	:	-	MINUS, NEGATES NUMBER TYPED IN
3839	076734	076162		O.CTLC	:	^C	EXIT TO MONITOR
3840	076736	076210		O.CTLF	:	^F	EXIT TO FIELD SERVICE MODE
3841	076740	076242		O.CTLE	:	^E	PROCEED FROM ^D

```

3844
3845           ; SEMI-COLON PROCESSOR
3846
3847 076742 010203           0.SEMI: MOV     R2,R3           ;A SEMI-COLON HAS BEEN RECEIVED
3848 076744 010405           MOV     R4,R5           ;NUMERIC FLAG TO R3, CONTENTS TO R5
3849 076746 105237 075601   INCB   0.SMFD           ;SET SEMICOLON FOUND FLAG
3850 076752 105037 075600   CLRB  0.CMFD           ;RESET COMMA FOUND FLAG
3851 076756 000674           BR     0.DCD1           ;GO BACK FOR MORE
3852
3853           ; PROCESS / AND \ - OPEN WORD OR BYTE
3854
3855           ;INPUT - IF R2 IS NON-ZERO A NEW RFXP HAS BEEN TYPED IN
3856           ;INPUT - -ADDRESS OF WORD TO BE OPENED IS IN R4
3857           .ENABL  LSB
3858 076760 012737 000002 075566 0.WRD: MOV     #2,0.BW           ;OPEN WORD
3859 076766 000404           BR     11$
3860 076770 006104           1$:   ROL     R4           ;GET THE ADDRESS BACK
3861 076772 012737 000001 075566 0.BYT: MOV     #1,0.BW           ;OPEN BYTE
3862 077000 005702           11$:  TST     R2           ;GET VALUE IF R2 IS NON-ZERO
3863 077002 001011           BNE   14$           ;BRANCH IF NUMBER INPUT
3864 077004 105737 075600   TSTB  0.CMFD           ;TEST FOR ',' 'AND' ':'
3865 077010 001402           BEQ   12$
3866 077012 000137 076510   13$:  JMP     0.ERR           ;ERROR IF PRESENT WITHOUT NUMBER.
3867 077016 105737 075601   12$:  TSTB  0.SMFD
3868 077022 001373           BNE   13$
3869 077024 000404           BR     0.WRD1           ;NO NUMBER - REOPEN PREVIOUS LOCATION
3870 077026 010437 075562   14$:  MOV     R4,0.DOT           ;PUT VALUE IN DOT
3871 077032 010437 075560   MOV     R4,0.CAD           ; ALSO IN CAD
3872 077036 022737 000001 075566 0.WRD1: CMP     #1,0.BW           ;CHECK BYTE MODE
3873 077044 001407           BEQ   22$           ;JUMP IF BYTE
3874 077046 013704 075560   MOV     0.CAD,R4
3875 077052 006204           ASR   R4           ;MOVE ONE BIT TO CARRY
3876 077054 103745           BCS   1$           ;JUMP IF ODD ADDRESS
3877 077056 017700 176476   MOV     @0.CAD,R0           ;GET CONTENTS OF WORD
3878 077062 000402           BR     23$
3879 077064 117700 176470   22$:  MOVB   @0.CAD,R0           ;GET CONTENTS OF BYTE
3880 077070 004537 100634   23$:  JSR   5,0.CADV           ;GO GET AND TYPE OUT @CAD
3881 077074 022737 000001 075566   CMP     #1,0.BW           ;CHECK IF BYTE MODE.
3882 077102 001212           BNE   0.DCD3           ;IF NOT WE'RE DONE. ELSE:
3883 077104 112700 000075   MOVB   #'',R0           ;TYP '' AND THEN THE ASCII BYTE
3884 077110 004537 100730   JSR   5,0.FTYP
3885 077114 117700 176440   MOVB   @0.CAD,R0
3886 077120 004537 100730   JSR   5,0.FTYP
3887 077124 112700 000040   MOVB   #'',R0
3888 077130 004537 100730   JSR   5,0.FTYP
3889 077134 000137 076530   JMP   0.DCD3           ;GO BACK TO DECODER
3890           .DSABL  LSB
    
```

```

3893          : PROCESS CARRIAGE RETURN
3894 077140 004737 101214  O.CRET: JSR    PC,O.CLSE  ;CLOSE LOCATION
3895 077144 000137 076520  O.DCDA: JMP    O.DCD    ;RETURN TO DECODER
3896
3897 077150 000137 076510  O.ERR3: JMP    O.ERR    ; INTERMEDIATE HELP
3898
3899          : PROCESS <LF>, OPEN NEXT WORD
3900
3901 077154 105237 075570  O.OLD:  INCB   O.SEQ    ;SET FLAG TO LATER RESTORE CAD
3902 077160 005737 075566  O.OP1:  TST    O.BW    ;<LF> RECEIVED
3903 077164 001771          O.ERR2: BEQ    O.ERR3   ;ERROR IF NOTHING IS OPEN
3904 077166 004737 101214  JSR     PC,O.CLSE  ;CLOSE PRESENT CELL
3905 077172 105737 075570  TSTB   O.SEQ    ;SHOULD CAD BE RESTORED?
3906 077176 001405          BEQ     1$        ;BRANCH IF NOT
3907 077200 013737 075562 075560  MOV    O.DOT,O.CAD ;RESTORE PREVIOUS SEQUENCE
3908 077206 105037 075570  CLRB   O.SEQ    ;RESET FLAG; NO LONGER NEEDED
3909 077212 063737 075566 075560  1$:   ADD    O.BW,O.CAD ;GENERATE NEW ADDRESS
3910 077220 013737 075560 075562  O.OP2:  MOV    O.CAD,O.DOT ;INITIALIZE DOT
3911 077226 004537 101246  O.OP2A: JSR    5,O.CRLF ;<CR><LF>
3912 077232 013746 075566          MOV    O.BW,-(SP) ;SAVE BW
3913 077236 012737 000002 075566  MOV    #2,O.BW   ;SET TO TYPE FULL WORD ADDRESS
3914 077244 013700 075560          MOV    O.CAD,RO  ;NUMBER TO TYPE
3915 077250 004537 101272          JSR    5,O.RORA  ; CHECK FORMAT
3916 077254 011637 075566          MOV    @SP,O.BW  ;RESTORE BW
3917 077260 012700 027534          MOV    #27534,RO ;PUT '/' IN RO
3918 077264 022726 000001          CMP    #1,(SP)+ ;IS IT BYTE MODE?
3919 077270 001401          BEQ    1$        ;JUMP IF YES
3920 077272 000300          SWAB   RO       ;TYPE A /
3921 077274 004537 100730  1$:   JSR    5,O.FTYP ;TYPE THE LOW BYTE OF RO
3922 077300 000656          BR     O.WRD1   ;GO PROCESS IT
3923

```



```

3926
3927 ; PROCESS ^, OPEN PREVIOUS WORD
3928
3929 077302 005737 075566 O.BACK: TST O.BW ; ^ RECEIVED
3930 077306 001726 BEQ O.ERR2 ; ERROR IF NOTHING OPEN
3931 077310 004737 101214 JSR PC,O.CLSE
3932 077314 163737 075566 075560 SUB O.BW,O.CAD ; GENERATE NEW ADDRESS
3933 077322 000736 BR O.OP2 ; GO DO THE REST
3934
3935 ; B HANDLER - SET AND REMOVE BREAKPOINTS
3936
3937 077324 012700 101370 O.BKPT: MOV #O.TRTC,R0
3938 077330 006304 ASL R4 ; MULTIPLY NUMBER BY TWO
3939 077332 005703 TST R3
3940 077334 001423 BEQ 3$ ; IF R3 IS ZERO GO REMOVE BREAKPOINT
3941 077336 006205 ASR R5 ; GET ONE BIT TO CARRY
3942 077340 103514 BCS O.ERR1 ; BADNESS IF ODD ADDRESS
3943 077342 006305 ASL R5 ; RESTORE ONE BIT
3944 077344 062704 075706 ADD #O.ADR1,R4
3945 077350 005702 TST R2
3946 077352 001007 BNE 1$ ; JUMP IF SPECIFIC CELL
3947 077354 020014 2$: CMP R0,@R4 ; IS THIS CELL FREE?
3948 077356 001405 BEQ 1$ ; JUMP IF YES
3949 077360 020427 075724 CMP R4,#O.BKP+O.ADR1 ; ARE WE AT THE END OF OUR ROPE
3950 077364 103102 BHIS O.ERR1 ; YES, THERE IS NOTHING FREE
3951 077366 005724 TST (R4)+ ; INCREMENT BY TWO
3952 077370 000771 BR 2$
3953 077372 020427 075724 1$: CMP R4,#O.BKP+O.ADR1
3954 077376 101075 BHI O.ERR1 ; ERROR IF TOO LARGE
3955 077400 010514 MOV R5,@R4 ; SET BREAKPOINT
3956 077402 000660 BR O.DCDA ; RETURN
3957 077404 005702 3$: TST R2
3958 077406 001410 BEQ O.RALL ; GO REMOVE ALL
3959 077410 020427 000016 CMP R4,#O.BKP
3960 077414 101066 BHI O.ERR1 ; JUMP IF NUMBER TOO LARGE
3961 077416 010064 075706 MOV R0,O.ADR1(R4) ; CLEAR BREAKPOINT
3962 077422 005064 075730 CLR O.CT(R4) ; CLEAR COUNT ALSO
3963 077426 000646 BR O.DCDA
3964 077430 005004 O.RALL: CLR R4
3965 077432 012700 101370 MOV #O.TRTC,R0
3966 077436 020427 000020 1$: CMP R4,#O.BKP+2 ; ALL DONE?
3967 077442 101240 BHI O.DCDA ; JUMP IF YES
3968 077444 010064 075706 MOV R0,O.ADR1(R4) ; RESET BKPT
3969 077450 012764 000003 075752 MOV #TRT,O.UIN(R4) ; RESET CONTENTS OF TABLE
3970 077456 005064 075730 CLR O.CT(R4) ; CLEAR COUNT
3971 077462 005724 TST (R4)+ ; INCREMENT BY TWO
3972 077464 000764 BR 1$
3973

```

```

3976
3977
3978
3979 077466 022737 000002 075566 0.OFST: CMP #2,O.BW ;CHECK WORD MODE
3980 077474 001036 BNE O.ERR1 ;ERROR IF NOT CORRECT MODE
3981 077476 012700 000040 MOV #1,R0 ;TYPE ONE BLANK
3982 077502 004537 100730 JSR S,O.FTYP ; AS A SEPARATOR
3983 077506 005703 TST R3 ;WAS SEMI-COLON TYPED?
3984 077510 001430 BEQ O.ERR1 ;NO, CALL IT AN ERROR
3985 077512 163705 075560 SUB O.CAD,R5 ;COMPUTE
3986 077516 005305 DEC R5
3987 077520 005305 DEC R5 ; 16 BIT OFFSET
3988 077522 010500 MOV R5,R0 ;NUMBER IN R0 - WORD MODE
3989 077524 004537 100634 JSR S,O.CADV
3990 077530 010500 MOV R5,R0
3991 077532 006200 ASR R0 ;DIVIDE BY TWO
3992 077534 103414 BCS 1$ ;ERROR IF ODD
3993 077536 022700 177600 CMP #-200,R0 ;COMPARE WITH -200
3994 077542 003011 BGT 1$ ;DO NOT TYPE IF OUT OF RANGE
3995 077544 022700 000177 CMP #177,R0 ;COMPARE WITH +177
3996 077550 002406 BLT 1$ ;DO NOT TYPE IF OUT OF RANGE
3997 077552 005337 075566 DEC O.BW ;SET TEMPORARY BYTE MODE
3998 077556 004537 100634 JSR S,O.CADV ;NUMBER IN R0 - BYTE MODE
3999 077562 005237 075566 INC O.BW ;RESTORE WORD MODE
4000 077566 000137 076530 1$: JMP O.DCD3 ;ALL DONE
4001
4002 077572 000137 076510 0.ERR1: JMP O.ERR ;INTERMEDIATE HELP
    
```

```

4005                : PROCESS G - GO
4006
4007 077576 105737 075601      0.GO:  TSTB  O.SMFD      :WAS ':' TYPED?
4008 077602 001773              BEQ  O.ERR1      :BR IF NOT TYPED
4009 077604 005703              TST  R3           :WAS K; TYPED?
4010 077606 001771              BEQ  O.ERR1      : TYPE ?<CR,LF> IF NOT
4011 077610 112737 000021 075573  MOVB #O.BKP+3,O.P :CLEAR PROCEED
4012 077616 006205              ASR  R5           :CHECK LOW ORDER BIT
4013 077620 103764              BCS  O.ERR1      :ERROR IF ODD NUMBER
4014 077622 006305              ASL  R5           :RESTORE WORD
4015 077624 010537 075700      0.GOGO: MOV  R5,O.UPC   :SET UP NEW PC
4016 077630 012746 000340      MOV  #O.STM,-(SP) :SET HIGH PRIORITY
4017 077634 004737 101202      JSR  PC,O.WST
4018 077640 004537 100534      JSR  S,O.RSTT    :RESTORE TELETYPE
4019 077644 105037 075572      0.TBIT: CLR B O.T   :CLEAR
4020 077650 052737 000020 075702  BIS  #O.TBT,O.UST : BOTH T-BIT FLAGS
4021 077656 105737 075571      TSTB O.S         :SEE IF WE NEED A T BIT
4022 077662 001005              BNE  O.G02       :IF NOT GO NOW
4023 077664 042737 000020 075702  BIC  #O.TBT,O.UST :CLEAR THE T BIT
4024 077672 004537 100450      JSR  S,O.RSB     :RESTORE BREAKPOINTS
4025 077676 004037 100416      0.G02: JSR  O,O.RSR   :RESTORE REGISTERS
4026 077702 013746 075702      MOV  O.UST,-(SP) : AND STATUS
4027 077706 013746 075700      MOV  O.UPC,-(SP) : AND PC
4028 077712 000240              NOP
4029 077714 013746 075702      MOV  O.UST,-(SP) : CHANGE TO HALT FOR DEBUGGING
4030 077720 042716 177420      BIC  #O.TBT.177400,(SP) : MOV IN STATUS FIRST W/O T BIT
4031 077724 004737 101202      JSR  PC,O.WST    : SO INTERRUPTS CAN HAPPEN BEFORE
4032 077730 000006              RTT              : RTT TURNS ON THE T BIT.
    
```

```

4035 ; PROCESS P - PROCEED
4036 ; ONLY ALLOWED AFTER A BREAKPOINT
4037
4038 077732 105737 075601 O.PROC: TSTB O.SMFD ;WAS ':' TYPED?
4039 077736 001715 BEQ O.ERR1 ;BR IF NOT TYPED
4040 077740 113700 075573 MOVB O.P,RO
4041 077744 105700 TSTB R0 ;CHECK LEGALITY OF PROCEED
4042 077746 002711 BLT O.ERR1 ;NOT LEGAL
4043 077750 005702 TST R2 ;CHECK FOR ILLEGAL COUNT
4044 077752 001307 BNE O.ERR1 ;JUMP IF ILLEGAL
4045 077754 005703 TST R3 ;WAS COUNT SPECIFIED?
4046 077756 001402 BEQ O.PR1 ;NO
4047 077760 010560 075730 MOV R5,O.CT(RO) ;YES, PUT AWAY COUNT
4048 077764 012746 000340 O.PR1: MOV #O.STM,-(SP) ;FORCE HIGH PRIORITY
4049 077770 004737 101202 JSR PC,O.WST
4050 077774 004537 100534 JSR S,O.RSTT
4051 100000 123727 075573 000016 O.C1: CMPB O.P,#O.BKP ;RESTORE TTY
4052 100006 003316 BGT O.TBIT ;SEE IF A REAL ONE OR A FAKE
4053 100010 105737 075571 TSTB O.S ;BRANCH IF FAKE
4054 100014 001313 BNE O.TBIT ;SEE IF SINGLE INSTRUCTION MODE
4055 100016 012746 000340 MOV #O.STM,-(SP) ;IF SO EXIT NOW
4056 100022 004737 101202 JSR PC,O.WST ;SET HIGH PRIORITY
4057 100026 105237 075572 INCB O.T ;SET T-BIT FLAG
4058 100032 052737 000020 075702 BIS #O.TBT,O.UST ;SET T-BIT
4059 100040 000716 BR O.G02

```

```

4062          : BREAKPOINT HANDLER
4063 100042 012637 075700 0.BRK: MOV (SP)+,0.UPC ;PRIORITY IS 7 UPON ENTRY
4064 100046 012637 075702      MOV (SP)+,0.UST ;SAVE STATUS AND PC
4065 100052 112737 00G021 075573 MOVB #0.BKP+3,0.P ;TELL ;P THAT WE CAN CONTINUE
4066 100060 004037 100360      JSR 0,0.SVR ;SAVE VARIOUS REGISTERS
4067 100064 105737 075572      TSTB 0.T ;CHECK FOR T-BIT SET
4068 100070 001265          BNE 0.TBIT ;JUMP IF SET
4069 100072 004537 100602      JSR 5,0.REM ;REMOVE BREAKPOINTS
4070 100076 105737 075704      TSTB 0.PRI ;CHECK IF PRIORITY
4071 100102 100003          BPL 2$ ; IS AS SAME AS USER PGM
4072 100104 113705 075702      MOVB 0.UST,R5 ;PICK UP USER UST IF SO
4073 100110 000407          BR 3$
4074 100112 113705 075704      2$: MOVB 0.PRI,R5 ;OTHERWISE PICK UP ACTUAL PRIORITY
4075 100116 000257          CCC ;CLEAR CARRY
4076 100120 106005          RORB R5 ;SHIFT LOW ORDER BITS
4077 100122 106005          RORB R5 ; INTO
4078 100124 106005          RORB R5 ; HIGH ORDER
4079 100126 106005          RORB R5 ; POSITION
4080 100130 042705 177420      3$: BIC #0.TBT!177400,R5 ;CLEAR POSSIBLE T BIT (S/I MODE)
4081 100134 010546          MOV R5,-(SP) ;PUT THE STATUS AWAY WHERE IT BELONGS
4082 100136 004737 101202      JSR PC,0.WST
4083 100142 013705 075700      MOV 0.UPC,R5 ;GET PC, IT POINTS TO THE TRT
4084 100146 105737 075571      TSTB 0.S ;SEE IF IT WAS SINGLE INSTRUCTION FUN
4085 100152 100432          BMI 14$ ;IF SO HANDLE THERE
4086 100154 005745          TST -(R5)
4087 100156 010537 075700      MOV R5,0.UPC
4088 100162 012704 000016      MOV #0.BKP,R4 ;GET A COUNTER
4089 100166 020564 075706      11$: CMP R5,0.ADR1(R4) ;COMPARE WITH LIST
4090 100172 001426          BEQ 12$ ;JUMP IF FOUND
4091 100174 005304          DEC R4
4092 100176 005304          DEC R4
4093 100200 002372          BGE 11$ ;RE-LOOP UNTIL FOUND
4094 100202 004537 100500      JSR 5,0.SVTT ;SAVE TELETYPE STATUS
4095 100206 004537 101246      JSR 5,0.CRLF
4096 100212 012704 101366      MOV #0.BD,R4 ;ERROR, NOTHING FOUND
4097 100216 012703 101367      MOV #0.BD+1,R3
4098 100222 004537 101126      JSR 5,0.TYPE ;OUTPUT 'BE' FOR BAD ENTRY
4099 100226 010500          MOV R5,R0
4100 100230 062737 000002 075700 ADD #2,0.UPC ;POP OVER THE ADJUSTMENT ABOVE
4101 100236 000444          BR 13$ ; OR CONTINUE
    
```

4104	100240	112704	000020		14\$:	MOVB	#0.BKP+2,R4	:	SET BREAK POINT HIGH + 1
4105	100244	010564	075706			MOV	R5,O.ADR1(R4)	:	STORE NEXT PC VALUE FOR TYPE OUT
4106	100250	110437	075573		12\$:	MOVB	R4,O.P	:	ALLOW PROCEED
4107	100254	005364	075730			DEC	O.CT(R4)		
4108	100260	003247				BGT	O.C1	:	JUMP IF REPEAT
4109	100262	012764	000001	075730		MOV	#1,O.CT(R4)	:	RESET COUNT TO 1
4110	100270	004537	100500			JSR	5,O.SVTT	:	SAVE TELETYPE STATUS, R4 IS SAFE
4111	100274	012700	000102			MOV	#'B',R0		
4112	100300	004537	100730			JSR	5,O.FTYP	:	TYPE 'B'
4113	100304	113700	075573			MOVB	O.P,R0	:	CONVERT BREAKPOINT NUMBER TO ASCII
4114	100310	062700	000140			ADD	#140,R0		
4115	100314	006200				ASR	R0		
4116	100316	004537	100730			JSR	5,O.FTYP		
4117	100322	012700	000073			MOV	#',R0		
4118	100326	004537	100730			JSR	5,O.FTYP	:	TYPE
4119	100332	012737	000002	075566		MOV	#2,O.BW	:	SET WORD MODE
4120	100340	113704	075573			MOVB	O.P,R4		
4121	100344	016400	075706			MOV	O.ADR1(R4),R0	:	GET ADDRESS OF BREAK
4122	100350	004537	101272		13\$:	JSR	5,O.RORA	:	CHECK FORMAT
4123	100354	000137	076520			JMP	O.DCD	:	GO TO DECODER

```

4126                : SAVE REGISTERS R0-R6
4127                :   INTERNAL STACK
4128
4129 100360 012637 075564  O.SVR: MOV   (SP)+,O.XXX  ;PICK REGISTER FROM STACK AND SAVE
4130 100364 010637 075676      MOV   SP,O.USP  ;SAVE USER STACK ADDRESS
4131 100370 012706 075676      MOV   #O.USP,SP ;SET TO INTERNAL STACK
4132 100374 010546      MOV   R5,-(SP)  ;SAVE
4133 100376 010446      MOV   R4,-(SP)  ; REGISTERS
4134 100400 010346      MOV   R3,-(SP)  ; 1
4135 100402 010246      MOV   R2,-(SP)  ; THRU
4136 100404 010146      MOV   R1,-(SP)  ; 5
4137 100406 013746 075564      MOV   O.XXX,-(SP) ;PUT SAVED REGISTER ON STACK
4138 100412 005746      TST   -(SP)
4139 100414 000200      RTS   R0
4140
4141                : RESTORE REGISTERS R0-R6
4142
4143 100416 005726  O.RSR: TST   (SP)+      ;POP THE EXTRA CELL
4144 100420 012637 075564      MOV   (SP)+,O.XXX ;GET R0 FROM STACK
4145 100424 012601      MOV   (SP)+,R1    ;RESTORE
4146 100426 012602      MOV   (SP)+,R2    ; REGISTERS
4147 100430 012603      MOV   (SP)+,R3    ; 1
4148 100432 012604      MOV   (SP)+,R4    ; THRU
4149 100434 012605      MOV   (SP)+,R5    ; 5
4150 100436 013706 075676      MOV   O.USP,SP   ;RESTORE USER STACK
4151 100442 013746 075564      MOV   O.XXX,-(SP) ;PUT R0 ON USER STACK
4152 100446 000200      RTS   R0

```

```

4155                                     : RESTORE BREAKPOINTS 0-7
4156
4157 100450 012704 000016 0.RSB: MOV #0.BKP,R4 ;RESTORE ALL BREAKPOINTS
4158 100454 017464 075706 075752 1$: MOV @0.ADR1(R4),0.UIN(R4);SAVE CONTENTS
4159 100462 013774 101370 075706 MOV 0.TRTC,@0.ADR1(R4);REPLACE WITH TRAP
4160 100470 005304 DEC R4
4161 100472 005304 DEC R4
4162 100474 002367 BGE 1$ ;RE-LOOP UNTIL DONE
4163 100476 000205 RTS R5 ; THEN QUIT
4164
4165                                     : SAVE TELETYPE STATUS
4166
4167 100500 113737 177560 075574 0.SVTT: MOVB 0.RCSR,0.CSR1 ;SAVE R C/SR
4168 100506 113737 177564 075575 MOVB 0.TCSR,0.CSR2 ;SAVE T C/SR
4169 100514 105037 177560 CLRB 0.RCSR ;CLEAR ENABLE AND MAINTENANCE
4170 100520 105037 177564 CLRB 0.TCSR ; BITS IN BOTH C/SR
4171 100524 105737 177564 1$: TSTB 0.TCSR ;LOOP UNTIL READY BIT COMES ON
4172 100530 100375 BPL 1$ ;BR IF BIT NOT ON
4173 100532 000205 RTS R5
4174
4175                                     : RESTORE TELETYPE STATUS
4176 100534 004537 101246 0.RSTT: JSR 5.0.CRLF
4177 100540 105737 177564 TSTB 0.TCSR ;WAIT READY
4178 100544 100375 BPL -4 ; ON PRINTER
4179 100546 032737 004000 177560 BIT #4000,0.RCSR ;CHECK BUSY FLAG
4180 100554 001403 BEQ 1$ ;SKIP READY LOOP IF NOT BUSY
4181 100556 105737 177560 TSTB 0.RCSR ;WAIT READY
4182 100562 100375 BPL -4 ; ON READER
4183 100564 113737 075574 177560 1$: MOVB 0.CSR1,0.RCSR ;RESTORE
4184 100572 113737 075575 177564 MOVB 0.CSR2,0.TCSR ; THE STATUS REGISTERS
4185 100600 000205 RTS R5
4186
4187                                     : REMOVE BREAKPOINTS 0-7
4188                                     : IN THE OPPOSITE ORDER OF SETTING
4189
4190 100602 105737 075571 0.REM: TSTB 0.S ;SEE IF SINGLE INSTRUCTION IS GOING
4191 100606 001011 BNE 2$ ;EXIT IF SO
4192 100610 005004 CLR R4 ;REMOVE ALL BREAKPOINTS
4193 100612 016474 075752 075706 1$: MOV 0.UIN(R4),@0.ADR1(R4) ;CLEAR BREAKPOINT
4194 100620 005204 INC R4
4195 100622 005204 INC R4
4196 100624 020427 000016 CMP R4,#0.BKP
4197 100630 003770 BLE 1$ ;RE-LOOP UNTIL DONE
4198 100632 000205 2$: RTS R5 ;THEN QUIT

```



```

4201 ; TYPE OUT CONTENTS OF WORD OR BYTE WITH ONE TRAILING SPACE
4202 ; WORD IS IN R0
4203
4204 100634 012703 000006 O.CADV: MOV #6,R3 ;# OF DIGITS
4205 100640 012704 177776 MOV #-2,R4 ;# OF BITS FIRST-3
4206 100644 022737 000001 075566 CMP #1,0,BW ;SEE IF WORD MODE
4207 100652 001004 BNE 3$ ;BRANCH IF SO
4208 100654 162703 000003 SUB #3,R3 ;ONLY DO 3 DIGITS
4209 100660 005204 INC R4 ;DO 2 BITS FIRST
4210 100662 000300 SWAB R0 ;AND TURN R0 AROUND
4211 100664 010046 3$: MOV R0,-(SP) ;SAVE R0
4212 100666 062704 000003 2$: ADD #3,R4 ;COMPUTE THE NUMBER OF BITS TO DO
4213 100672 005000 CLR R0
4214 100674 006116 1$: ROL (SP) ;GET A BIT
4215 100676 006100 ROL R0 ;STORE IT AWAY
4216 100700 005304 DEC R4 ;DECREMENT COUNTER
4217 100702 003374 BGT 1$ ;LOOP IF MORE BITS NEEDED
4218 100704 062700 000060 ADD #'0,R0 ;CONVERT TO ASCII
4219 100710 004537 100730 JSR R5,0,FTYP ;TYPE IT
4220 100714 005303 DEC R3 ;SEE IF MORE DIGITS TO DO
4221 100716 003363 BGT 2$ ;LOOP IF SO
4222 100720 112700 000040 MOVB #' ,R0 ;SET UP FOR TRAILING SPACE
4223 100724 005726 TST (SP)+ ;GET RID OF JUNK
4224 100726 000400 BR 0,FTYP
4225
4226
4227 ; TYPE ONLY ONE CHARACTER (CONTAINED IN R0)
4228
4229 100730 105737 177564 O,FTYP: TSTB 0,TCSR
4230 100734 100375 BPL 0,FTYP
4231 100736 042700 177400 BIC #177400,R0 ;CLEAR HIGH BYTE,SHOULD NOT
;CONTAIN INPORTANT INFO.
4232
4233 BEQ 3$
4234 100744 022700 000176 CMP #176,R0 ;PRINT ? FOR 177:16-37
4235 100750 103411 BLO 2$ ; 1-10 AND 200-377.
4236 100752 022700 000037 CMP #37,R0
4237 100756 103410 BLO 3$
4238 100760 022700 000015 CMP #15,R0
4239 100764 103403 BLO 2$
4240 100766 022700 000010 CMP #10,R0
4241 100772 103402 BLO 3$
4242 100774 012700 000077 2$: MOV #'?,R0
4243 101000 110037 177566 3$: MOVB R0,0,TDB
4244 101004 000205 O,TYP1: RTS R5

```

```
4247 : GENERAL CHARACTER INPUT ROUTINE -- OD'11X
4248 : CHARACTER INPUT GOES TO R0
4249
4250 101006 105737 177560 0.GET: TSTB 0.RCSR ;WAIT FOR
4251 101012 100375 BPL 0.GET ; INPUT FROM KBD
4252 101014 113700 177562 MOVB 0.RDB,R0 ;GET CHARACTER - STRIP OFF PARITY
4253 101020 042700 177600 BIC #177600,R0 ;STRIP OFF PARITY FROM CHARACTER
4254 101024 122700 000003 CMPB #3,R0 ;IS IT ^C?
4255 101030 001435 BEQ 3$ ;IF SO, DO NOT ECHO
4256 101032 122700 000006 CMPB #6,R0 ;IS IT ^F?
4257 101036 001432 BEQ 3$ ;IF SO, DO NOT ECHO
4258 101040 122700 000005 CMPB #5,R0 ;IS IT ^E?
4259 101044 001427 BEQ 3$ ;IF SO, DO NOT ECHO
4260 101046 105737 075602 TSTB 0.SCRN ;SHOULD WE ECHO <LF>?
4261 101052 001003 BNE 2$ ;BR IF YES
4262 101054 120027 000012 CMPB R0,#012 ;SEE IF A <LF>
4263 101060 001421 BEQ 3$ ;IF SO SAVE THE PAPER
4264 101062 120027 000173 2$: CMPB R0,#173
4265 101066 002005 BGE 1$
4266 101070 122700 000140 CMPB #140,R0 ;TEST FOR LOWER CASE
4267 101074 002002 BGE 1$
4268 101076 162700 000040 SUB #40,R0 ;CHAR IS LC-CONVERT TO UPPER CASE
4269 101102 004537 100730 1$: JSR 5.O.FTYP ;ECHO CHARACTER
4270 101106 001737 BEQ 0.GET ;IGNORE NULLS
4271 101110 105737 075602 TSTB 0.SCRN ;SHOULD WE PASS ON SPACES?
4272 101114 001003 BNE 3$ ;BR IF YES
4273 101116 122700 000040 CMPB #40,R0 ;CHECK FOR SPACES
4274 101122 001731 BEQ 0.GET ;IGNORE SPACES
4275 101124 000205 3$: RTS R5
```

```

4278 ; GENERAL CHARACTER OUTPUT ROUTINE - ODT11X
4279 ; ADDRESS OF FIRST BYTE IN R4,
4280 ; ADDRESS OF LAST BYTE IN R3, (R3)>(R4)
4281 ; EXPECTS LOCS 56,57 TO BE INITIALIZED BY MONITOR FOR FILL
4282 ; CHARACTERISTICS OF TERMINAL
4283 ; 56=CHAR TO BE FILLED AFTER
4284 ; 57=# OF NULLS TO FILL WITH
4285
4286 101126 020304 0.TYPE: CMP R3,R4 ;CHECK FOR COMPLETION
4287 101130 103725 BLO 0.TYP1 ; EXIT WHEN DONE
4288 101132 112400 MOVB (R4)+,R0 ;GET A CHARACTER
4289 101134 004537 100730 JSR 5,0.FTYP ;TYPE ONE CHARACTER
4290 101140 120037 003002 CMPB R0,@#SFILLC ;COMPARE CHAR AGAINST FILL REQUIREMENT
4291 101144 001370 BNE 0.TYPE ;NO FILL NEEDED
4292 101146 113737 002451 075576 MOVB @#SFILLS,0.FIL ;FILL COUNT INTO TEMP
4293 101154 005000 CLR R0 ;FILL WITH NULLS
4294 101156 004537 100730 2$: JSR R5,0.FTYP ;TYPE NULLS
4295 101162 105337 075576 DECB 0.FIL ;DECREASE COUNT
4296 101166 003373 BGT 2$ ;BRANCH IF NOT DONE
4297 101170 000756 BR 0.TYPE ;LOOP UNTIL DONE
    
```

```

4300                :SUBROUTINE TO READ THE PS INDEPENDENT OF MACHINE
4301
4302 101172 013737 177776 075702 0.RRST: MOV    ST,0.UST    ;STORE THE STATUS IN USER
4303                ;STATUS AREA.FOR AN LSI
4304                ;THIS IS CHANGED TO
4305                ;MFPS 0.UST
4306 101200 000207                RTS    PC
4307
4308                :SUBROUTINE TO WRITE PS INDEPENDENT OF MACHINE
4309                ;CALL ROUTINE WITH PS VALUE
4310                ;ON THE STACK
4311
4312 101202 016637 000002 177776 0.WS*: MOV    2(SP),ST    ;STORE NEW PS VALUE
4313                ;THIS INSTRUCTION IS CHANGED FOR LSI
4314                ;TO MTPS 2(SP)
4315 101210 012616                MOV    (SP)+,(SP)    ;PUT RETURN PC OVER SUB. ARGUMENT
4316 101212 000207                RTS    PC                ;TO RETURN WITHOUT IT ON THE STACK
4317                ; CLOSE WORD OR BYTE AND EXIT,
4318                ; UPON ENTERING, R2 HAS NUMERIC FLAG, R4 HAS CONTENTS
4319
4320                .ENABL  LSB
4321 101214 005702 0.CLSE: TST    R2                ;IF NO NUMBER WAS TYPED THERE IS
4322 101216 001412                BEQ    1$                ;NO CHANGE TO THE OPEN CELL
4323 101220 022737 000001 075566    CMP    #1,0.BW
4324 101226 001404                BEQ    2$                ;JUMP IF BYTE MODE
4325 101230 101005                BHI    1$                ;JUMP IF ALREADY CLOSED
4326 101232 010477 174322                MOV    R4,@0.CAD    ;STORE WORD
4327 101236 000402                BR    1$
4328 101240 110477 174314                2$:  MOVB   R4,@0.CAD    ;STORE BYTE
4329 101244 000207                1$:  RTS    PC
4330 101246 012703 101317                0.CRLF: MOV    #0.CR+1,R3    ;LWA <CR,LF>
4331 101252 000402                BR    3$
4332 101254 012703 101320                0.CRLS: MOV    #0.CR+2,R3    ;LWA <CR,LF>*
4333 101260 012704 101316                3$:  MOV    #0.CR,R4        ;FWA
4334 101264 004537 101126                JSR    S,0.TYPE    ;TYPE SOMETHING
4335 101270 000205                RTS    R5
4336                .DSABL  LSB
    
```

ODT (CEMKA) DATA AREA

```

4339      :SUBROUTINE O.RORA
4340      :FUNCTION:
4341      :ADDRESS WILL BE PRINTED IN ABSOLUTE FORM
4342      :INPUT: THE ADDRESS TO BE PRINTED IS IN RO.
4343      :DATA SAVED: RO CONTAINING THE ADDRESS TO BE
4344      :PRINTED, AND LOCATION O.CAD CONTAINING
4345      :THE CURRENT ADDRESS WERE SAVED AND RESTORED.
4346      :CALLED: JSR 5,O.RORA
4347
4348 101272 004537 100634 O.RORA: JSR 5,O.CADV ;PRINT ABSOLUTE ADDRESS
4349 101276 000205      :RTS R5
4350 101300      012 O.ID: .BYTE 012
4351 101301      015      .BYTE 015
4352 101302      040      .BYTE 40
4353 101303      117      .ASCII /ODT (CEMKA)/
         101306      040      104 124
         101311      105      050 103
         101314      101      115 113
         101315      051
4354      101315 O.IDND--1
4355 101316      015 O.CR: .BYTE 015 ; <CR>
4356 101317      012      .BYTE 012 ; <LF>
4357 101320      052      .BYTE '*' ; *
4358
4359 101321      073 O.LGCH: .BYTE ':' ;
4360 101322      057      .BYTE '/' ; /
4361 101323      134      .BYTE '\ ' ; \ (BACK SLASH)
4362 101324      015      .BYTE 015 ; CARRIAGE RETURN
4363 101325      044      .BYTE '$' ; $
4364 101326      107      .BYTE 'G' ; G
4365 101327      012      .BYTE 012 ; <LF>
4366 101330      137      .BYTE '<' ; (BACK ARROW)
4367 101331      074      .BYTE '^' ; ^
4368 101332      136      .BYTE '^' ; (UP ARROW)
4369 101333      117      .BYTE 'O' ; O
4370 101334      102      .BYTE 'B' ; B
4371 101335      120      .BYTE 'P' ; P
4372 101336      100      .BYTE '@' ; @
4373 101337      076      .BYTE '>' ; >
4374 101340      123      .BYTE 'S' ; S
4375 101341      055      .BYTE '-' ; -
4376 101342      003      .BYTE 003 ;CTRL C
4377 101343      006      .BYTE 006 ;CTRL F
4378 101344      005      .BYTE 005 ;CTRL E
4379      000024 O.CLGT .-O.LGCH ;TABLE LENGTH
4380
4381 101345      123 O.TL: .BYTE 'S' ;DG 1
4382 101346      120      .BYTE 'P' ;NOT 2
4383 101347      115      .BYTE 'M' ;CHANGE 3
4384 101350      000      .BYTE 0 ;THE 4
4385 101351      000      .BYTE 0 ;ORDER 5
4386 101352      103      .BYTE 'C' ; 6
4387 101353      106      .BYTE 'F' ; 7
4388 101354      122      .BYTE 'R' ; 10
4389 101355      000      .BYTE 0 ; 11
4390 101356      000      .BYTE 0 ; 12
4391 101357      000      .BYTE 0 ; 13
4392 101360      000      .BYTE 0 ; 14

```

4393	101361	000	.BYTE	0	:	15
4394	101362	000	.BYTE	0	:	16
4395	101363	000	.BYTE	0	:	17
4396	101364	102	.BYTE	'B	:	20
4397	000020		O.LG	=	.-O.TL	
4398				.EVEN		
4399	101366	042502	O.BD:	.WORD	'BE	
4400	101370	000003	O.TRTC:	TRT		:TRACE TRAP PROTOTYPE

TABLE ERROR POINTER

.SBTTL TABLE ERROR POINTER

4403
4404
4405
4406
4407
4408
4409
4410
4411
4412
4413
4414
4415
4416
4417 101372
4418 101372 104530
4419 101374 110307
4420 101376 102504
4421 101400 103103
4422
4423 101402 103220
4424 101404 107366
4425 101406 102252
4426 101410 102743
4427
4428 101412 103256
4429 101414 107446
4430 101416 102302
4431 101420 103071
4432
4433 101422 103311
4434 101424 107446
4435 101426 102312
4436 101430 103071
4437
4438 101432 103357
4439 101434 107507
4440 101436 102322
4441 101440 102743
4442
4443 101442 103434
4444 101444 107507
4445 101446 102322
4446 101450 102743
4447
4448 101452 103461
4449 101454 107507
4450 101456 102322
4451 101460 102743
4452
4453 101462 103633
4454 101464 107366
4455 101466 102252
4456 101470 102743

.*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
.*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
.*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
.*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (ERRPC).
.*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

.* EM ::POINTS TO THE ERROR MESSAGE
.* DH ::POINTS TO THE DATA HEADER
.* DT ::POINTS TO THE DATA
.* DF ::POINTS TO THE DATA FORMAT

\$ERRTB: :ERROR 1
EM24
DH13
DT13
DF11
:ERROR 2
EM2
DH1
DT1
DF2
:ERROR 3
EM3
DH3
DT3
DF9
:ERROR 4
EM4
DH3
DT4
DF9
:ERROR 5
EM5
DH5
DT5
DF2
:ERROR 6
EM6
DH5
DT5
DF2
:ERROR 7
EM7
DH5
DT5
DF2
:ERROR 10
EM10
DH1
DT1
DF2

TABLE ERROR POINTER

4459			:ERROR	11
4460	101472	103677	EM11	
4461	101474	107664	DH7	
4462	101476	102362	DT7	
4463	101500	102767	DF3	
4464			:ERROR	12
4465	101502	103677	EM11	
4466	101504	107664	DH7	
4467	101506	102362	DT7	
4468	101510	103004	DF4	
4469			:ERROR	13
4470	101512	103721	EM12	
4471	101514	110145	DH10	
4472	101516	102444	DT10	
4473	101520	102743	DF2	
4474			:ERROR	14
4475	101522	103677	EM11	
4476	101524	107664	DH7	
4477	101526	102362	DT7	
4478	101530	103021	DF5	
4479			:ERROR	15
4480	101532	103677	EM11	
4481	101534	107664	DH7	
4482	101536	102362	DT7	
4483	101540	103036	DF6	
4484			:ERROR	16
4485	101542	103745	EM13	
4486	101544	110307	DH13	
4487	101546	102504	DT13	
4488	101550	103103	DF11	
4489			:ERROR	17
4490	101552	103777	EM14	
4491	101554	110307	DH13	
4492	101556	102504	DT13	
4493	101560	103103	DF11	
4494			:ERROR	20
4495	101562	104043	EM15	
4496	101564	110307	DH13	
4497	101566	102504	DT13	
4498	101570	103103	DF11	
4499			:ERROR	21
4500	101572	104111	EM16	
4501	101574	110243	DH11	
4502	101576	102466	DT11	
4503	101600	102743	DF2	
4504			:ERROR	22
4505	101602	104137	EM17	
4506	101604	107664	DH7	
4507	101606	102362	DT7	
4508	101610	103021	DF5	
4509			:ERROR	23
4510	101612	104177	EM18	
4511	101614	110006	DH8	
4512	101616	102416	DT8	
4513	101620	103076	DF10	

TABLE ERROR POINTER

4516			:ERROR	24	
4517	101622	104256	EM19		
4518	101624	110307	DH13		
4519	101626	102504	DT13		
4520	101630	103103	DF11		
4521			:ERROR	25	
4522	101632	104333	EM20		
4523	101634	110307	DH13		
4524	101636	102504	DT13		
4525	101640	103103	DF11		
4526			:ERROR	26	
4527	101642	000000	0		;NO MESSAGE
4528	101644	10272	DH12		
4529	101646	102476	DT12		
4530	101650	102743	DF2		
4531			:ERROR	27	
4532	101652	104415	EM21		
4533	101654	110243	DH11		
4534	101656	102466	DT11		
4535	101660	102743	DF2		
4536			:ERROR	30	
4537	101662	104454	EM22		
4538	101664	110307	DH13		
4539	101666	102504	DT13		
4540	101670	103103	DF11		
4541			:ERROR	31	
4542	101672	000000	0		;NO MESSAGE
4543	101674	110415	DH14		
4544	101676	102530	DT14		
4545	101700	102743	DF2		
4546			:ERROR	32	
4547	101702	104501	EM23		
4548	101704	107507	DH5		
4549	101706	102322	DT5		
4550	101710	102743	DF2		
4551			:ERROR	33	
4552	101712	106025	EM38		
4553	101714	110672	DH17		
4554	101716	102264	DT2		
4555	101720	103116	DF13		
4556			:ERROR	34	
4557	101722	104607	EM25		
4558	101724	110533	DH15		
4559	101726	102556	DT16		
4560	101730	103053	DF7		
4561			:ERROR	35	
4562	101732	104634	EM26		
4563	101734	110655	DH16		
4564	101736	102610	DT17		
4565	101740	102767	DF3		
4566			:ERROR	36	
4567	101742	103521	EM8		
4568	101744	110672	DH17		
4569	101746	102616	DT18		
4570	101750	103116	DF13		

4573			:ERROR 37
4574	101752	103556	EM9
4575	101754	110106	DH9
4576	101756	102432	DT9
4577	101760	102743	DF2
4578			:ERROR 40
4579	101762	104705	EM27
4580	101764	110655	DH16
4581	101766	102610	DT17
4582	101770	103067	DF8
4583			:ERROR 41
4584	101772	104774	EM28
4585	101774	110672	DH17
4586	101776	102634	DT19
4587	102000	103116	DF13
4588			:ERROR 42
4589	102002	105624	EM35
4590	102004	107664	DH7
4591	102006	102362	DT7
4592	102010	102767	DF3
4593			:ERROR 43
4594	102012	105027	EM29
4595	102014	107664	DH7
4596	102016	102362	DT7
4597	102020	102767	DF3
4598			:ERROR 44
4599	102022	105111	EM30
4600	102024	107664	DH7
4601	102026	102362	DT7
4602	102030	103021	DF5
4603			:ERROR 45
4604	102032	105230	EM31
4605	102034	107664	DH7
4606	102036	102362	DT7
4607	102040	102767	DF3
4608			:ERROR 46
4609	102042	105330	EM32
4610	102044	107664	DH7
4611	102046	102362	DT7
4612	102050	102767	DF3
4613			:ERROR 47
4614	102052	105435	EM33
4615	102054	107664	DH7
4616	102056	102362	DT7
4617	102060	102767	DF3
4618			:ERROR 50
4619	102062	105543	EM34
4620	102064	111023	DH19
4621	102066	102700	DT22
4622	102070	103114	DF12
4623			:ERROR 51
4624	102072	105711	EM36
4625	102074	107615	DH6
4626	102076	102346	DT6
4627	102100	102743	DF2

TABLE ERROR POINTER

4630			:ERROR	52
4631	102102	105760	EM37	
4632	102104	110672	DH17	
4633	102106	102616	DT18	
4634	102110	103116	DF13	
4635			:ERROR	53
4636	102112	106133	EM39	
4637	102114	110672	DH17	
4638	102116	102616	DT18	
4639	102120	103116	DF13	
4640			:ERROR	54
4641	102122	106220	EM40	
4642	102124	107423	DH2	
4643	102125	102652	DT20	
4644	102130	102743	DF2	
4645			:ERROR	55
4646	102132	106272	EM41	
4647	102134	110746	DH18	
4648	102136	102662	DT21	
4649	102140	103103	DF11	
4650			:ERROR	56
4651	102142	106374	EM42	
4652	102144	110746	DH18	
4653	102146	102662	DT21	
4654	102150	103103	DF11	
4655			:ERROR	57
4656	102152	103134	EM1	
4657	102154	000000	0	
4658	102156	000000	0	
4659	102160	000000	0	
4660			:ERROR	60
4661	102162	106477	EM43	
4662	102164	111037	DH20	
4663	102166	102706	DT23	
4664	102170	102743	DF2	
4665			:ERROR	61
4666	102172	106575	EM44	
4667	102174	111056	DH21	
4668	102176	102714	DT24	
4669	102200	102743	DF2	
4670			:ERROR	62
4671	102202	106672	EM45	
4672	102204	111037	DH20	
4673	102206	102706	DT23	
4674	102210	102743	DF2	
4675			:ERROR	63
4676	102212	106773	EM46	
4677	102214	110672	DH17	
4678	102216	102264	DT2	
4679	102220	103116	DF13	
4680			:ERROR	64
4681	102222	107062	EM47	
4682	102224	110655	DH16	
4683	102226	102610	DT17	
4684	102230	102767	DF3	

TABLE ERROR POINTER		
4687		:ERROR 65
4688	102232	EM48
4689	102234	DH22
4690	102236	DT20
4691	102240	DF2
4692		:ERROR 66
4693	102242	EM49
4694	102244	DH23
4695	102246	DT25
4696	102250	DF14

4699						.SBTTL	ERROR DATA TAGS (DT)
4700	102252	002024	002040	002050	DT1:	.WORD	ERRPC,ADDRESS,GOOD,BAD,0
	102260	002056	000000				
4701	102264	002024	002304	002656	DT2:	.WORD	ERRPC,DUMMY,SLFLAG,SLFLAG+2,SLFLAG+4,SLFLAG+6,0
	102272	002660	002662	002664			
	102300	000000					
4702	102302	002024	002042	002074	DT3:	.WORD	ERRPC,PADDRESS,PARCNT,0
	102310	000000					
4703	102312	002024	002040	002072	DT4:	.WORD	ERRPC,ADDRESS,NEMCNT,0
	102320	000000					
4704	102322	002024	177766	177744	DT5:	.WORD	ERRPC,CPUERR,MEMERR,HIADRS,LOADRS,MMR0,MMR1,MMR2,MMR3,0
	102330	177742	177740	177572			
	102336	177574	177576	172516			
	102344	000000					
4705	102346	002024	002522	002466	DT6:	.WORD	ERRPC,APTCORE,MJSIZE,APTMOS,MKSIZE,0
	102354	002524	002470	000000			
4706	102362	002024	002304	002040	DT7:	.WORD	ERRPC,DUMMY,ADDRESS,DUMMY,GOOD,BAD,BAD XOR
	102370	002304	002050	002056			
	102376	002064					
4707	102400	002304	002304	002304		.WORD	DUMMY,DUMMY,DUMMY,DUMMY,DUMMY,DUMMY,0
	102406	002304	002304	002304			
	102414	000000					
4708	102416	002040	002050	002056	DT8:	.WORD	ADDRESS,GOOD,BAD,GDSWITCH,BDSWITCH,0
	102424	002476	002500	000000			
4709	102432	002024	177766	177744	DT9:	.WORD	ERRPC,CPUERR,MEMERR,CSRNO,0
	102440	002256	000000				
4710	102444	002306	002310	002312	DT10:	.WORD	DETRO,DETR1,DETR2,DETR3,DETR4,DETR5,DETSR,DETPSW,0
	102452	002314	002316	002320			
	102460	002322	002324	000000			
4711	102466	002024	002144	002146	DT11:	.WORD	ERRPC,CSR,CSR+2,0
	102474	000000					
4712	102476	002144	002146	000000	DT12:	.WORD	CSR,CSR+2,0
4713	102504	002024	002304	002040	DT13:	.WORD	ERRPC,DUMMY,ADDRESS,DUMMY,TSTDAT,TSTDAT+2,CHECK,CSR,CSR+2,0
	102512	002304	002344	002346			
	102520	002404	002144	002146			
	102526	000000					
4714	102530	177744	177750	177746	DT14:	.WORD	MEMERR,MAINT,CONTRL,HIADRS,LOADRS,CPUERR,MMR0,MMR1,MMR2,MMR3,0
	102536	177742	177740	177766			
	102544	177572	177574	177576			
	102552	172516	000000				
4715	102556	002024	002304	002304	DT16:	.WORD	ERRPC,DUMMY,DUMMY,GOOD,GOOD2,GOOD3
	102564	002050	002052	002054			
4716	102572	002056	002060	002062		.WORD	BAD,BAD2,BAD3,DUMMY,DUMMY,DUMMY,0
	102600	002304	002304	002304			
	102606	000000					
4717	102610	002024	002304	000000	DT17:	.WORD	ERRPC,DUMMY,0
4718	102616	002024	002304	002646	DT18:	.WORD	ERRPC,DUMMY,PORTCOUNT,PORTCOUNT+2,PORTCOUNT+4,PORTCOUNT+6,0
	102624	002650	002652	002654			
	102632	000000					
4719	102634	002024	002304	002606	DT19:	.WORD	ERRPC,DUMMY,PORTDIR,PORTDIR+2,PORTDIR+4,PORTDIR+6,0
	102642	002610	002612	002614			
	102650	000000					
4720	102652	002024	002050	002056	DT20:	.WORD	ERRPC,GOOD,BAD,0
	102660	000000					
4721	102662	002024	002304	002040	DT21:	.WORD	ERRPC,DUMMY,ADDRESS,DUMMY,GOOD,BAD,0
	102670	002304	002050	002056			
	102676	000000					

4722	102700	002024	002304	000000	DT22:	.WORD	ERRPC,DUMMY,0
4723	102706	002024	002056	000000	DT23:	.WORD	ERRPC,BAD,0
4724	102714	002024	000000		DT24:	.WORD	ERRPC,0
4725	102720	002024	002304	002646	DT25:	.WORD	ERRPC,DUMMY,PORTCOUNT,PORTCOUNT+2,PORTCOUNT+4,PORTCOUNT+6,BAD,0
	102726	002650	002652	0C2654			
	102734	002056	000000				

ERROR DATA FORMATS (DF)

```

4728          .SBTTL  ERROR DATA FORMATS (DF)
4729 102740      000      016      016  DF1:  .BYTE  0,14.,14.
4730 102743      000      000      000  DF2:  .BYTE  0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
      102746      000      000      000
      102751      000      000      000
      102754      000      000      000
      102757      000      000      000
      102762      000      000      000
      102765      000      000      000
4731 102767      000      005      000  DF3:  .BYTE  0,5,0,9.,0,0,0,10.,3,6,2,4,12.
      102772      011      000      000
      102775      000      012      003
      103000      006      002      004
      103003      014
4732 103004      000      005      000  DF4:  .BYTE  0,5,0,9.,0,8.,8.,10.,3,6,2,4,12.
      103007      011      000      010
      103012      010      012      003
      103015      006      002      004
      103020      014
4733 103021      000      005      000  DF5:  .BYTE  0,5,0,9.,11.,11.,11.,10.,3,6,2,4,12.
      103024      011      013      013
      103027      013      012      003
      103032      006      002      004
      103035      014
4734 103036      000      005      000  DF6:  .BYTE  0,5,0,9.,11.,8.,8.,10.,3,6,2,4,12.
      103041      011      013      010
      103044      010      012      003
      103047      006      002      004
      103052      014
4735 103053      000      005      011  DF7:  .BYTE  0,5,9.,0,0,11.,0,0,11.,10.,2,4
      103056      000      000      013
      103061      000      000      013
      103064      012      002      004
4736 103067      000      005      000  DF8:  .BYTE  0,5
4737 103071      000      001      001  DF9:  .BYTE  0,1,1,1,1
      103074      001      001
4738 103076      000      000      000  DF10: .BYTE  0,0,0,13.,13.
      103101      015      015
4739 103103      000      005      000  DF11: .BYTE  0,5,0,9.,0,0,0,0,0
      103106      011      000      000
      103111      000      000      000
4740 103114      000      017      000  DF12: .BYTE  0,15.
4741 103116      000      005      000  DF13: .BYTE  0,5,0,0,0,0,0,0
      103121      000      000      000
      103124      000
4742 103125      000      005      000  DF14: .BYTE  0,5,0,0,0,0,16.
      103130      000      000      000
      103133      020
4743          .EVEN

```

Address	Bank	Code	EM	Description
4746				.SBTTL ERROR MESSAGES (EM)
4752	103134	125	116	105 EM1: .ASCIZ /UNEXPECTED TRAP TO 170 (IIST) - PROGRAM CONTINUING./
4753	103220	103	101	116 EM2: .ASCIZ /CAN'T SET 22 BIT MODE IN MMR3/
4754	103256	120	101	122 EM3: .ASCIZ /PARITY ERROR(S) IN BANK 0/
4755	103311	116	117	116 EM4: .ASCIZ /NON-EXISTANT MEMORY (HOLES) IN BANK 0/
4756	103357	111	114	114 EM5: .ASCIZ /ILLEGAL OR RESERVED INSTRUCTION (TRAP TO 10)/
4757	103434	125	116	105 EM6: .ASCIZ /UNEXPECTED TRAP TO 4/
4758	103461	115	105	115 EM7: .ASCIZ /MEMORY MANAGEMENT (TRAP TO 250)/
4759	103521	120	117	122 EM8: .ASCIZ /PORT CONTENTION NOT BALANCED/
4760				
4761	103556	116	117	116 EM9: .ASCIZ /NON-EXISTANT CSR CAUSED INCORRECT ERROR TRAP/
4762	103633	111	116	103 EM10: .ASCIZ /INCORRECT DATA FROM DEVICE REGISTER/
4763	103677	115	105	115 EM11: .ASCIZ /MEMORY DATA ERROR/
4764	103721	104	105	124 EM12: .ASCIZ /DETAILED ERROR DUMP/
4765	103745	115	111	123 EM13: .ASCIZ /MISSING EXPECTED SBE FLAG/
4766	103777	127	122	111 EM14: .ASCIZ /WRITE BYTE FAILED TO CLEAR SBE FLAG/
4767	104043	106	101	111 EM15: .ASCIZ /FAILED TO GET INTERRUPT WITH DBE FLAG/
4768	104111	117	116	114 EM16: .ASCIZ /ONLY ONE DBE FLAG SET/
4769	104137	115	105	115 EM17: .ASCIZ /MEMORY DATA ERROR IN CHECK BITS/
4770	104177	123	131	123 EM18: .ASCIZ /SYSTEM SIZE REGISTER LOW DOES NOT MATCH MEMORY/
4771	104256	123	102	105 EM19: .ASCIZ /SBE OR DBE CAUSED PARITY TRAP WHEN INHIBITED/
4772	104333	123	102	105 EM20: .ASCIZ /SBE OR DBE DID NOT CAUSE PARITY TRAP WHEN ENABLED/
4773	104415	123	102	105 EM21: .ASCIZ /SBE OR DBE ON MASTER TEST WORD/
4774	104454	115	111	123 EM22: .ASCIZ /MISSING EXPECTED DBE/
4775	104501	125	116	105 EM23: .ASCIZ /UNEXPECTED PARITY TRAP/
4776	104530	122	105	103 EM24: .ASCIZ /RECEIVED DBE FLAG WHEN EXPECTING ONLY SBE FLAG/
4777	104607	103	110	105 EM25: .ASCIZ /CHECK BIT DATA ERROR/
4778	104634	101	104	104 EM26: .ASCIZ /ADDRESS PARITY ERROR DID NOT CAUSE ABORT/
4779	104705	115	113	061 EM27: .ASCIZ /MK11 PROTECTION POINTER FAILURE - DID NOT PROTECT BANK/
4780	104774	103	120	125 EM28: .ASCIZ /CPU IDENTIFICATION FAILURE/
4781	105027	103	117	122 EM29: .ASCIZ /CORRECTION FAILURE WITH ECC ENABLED ON FORCED SBE/
4782	105111	127	122	111 EM30: .ASCIZ /WRITE BYTE (MOVB) WITH ECC ENABLED FAILED TO CLEAR DATA AT/<<CRLF>
4783	105204	106	117	122 .ASCIZ /FORCED SBE LOCATION/
4784	105230	101	123	122 EM31: .ASCIZ /ASRB (R3)+ WITH ECC ENABLED CHANGED DATA AT FORCED DBE LOCATION/
4785	105330	115	117	126 EM32: .ASCIZ /MOVB #360,(R2)+ WITH ECC ENABLED CHANGED DATA AT FORCED DBE LOCATION/
4786	105435	115	117	126 EM33: .ASCIZ /MOV #177400,(R1) WITH ECC ENABLED CHANGED DATA AT FORCED DBE LOCATION/
4787	105543	123	102	105 EM34: .ASCIZ /SBE DETECTED BY MK11 BUT NOT ISOLATED BY PROGRAM/
4788	105624	125	116	105 EM35: .ASCIZ /UNEXPECTED CORRECTION WITH ECC DISABLE ON FORCED SBE/
4789	105711	101	120	124 EM36: .ASCIZ /APT SIZE DISAGREES WITH PROGRAM SIZING/
4790	105760	122	125	116 EM37: .ASCIZ /RUNNING CONTENTION INCREMENT FAILURE/
4791	106025	101	123	122 EM38: .ASCIZ /ASRB LOCK FAILURE (1 & ONLY 1 CPU SHOULD HAVE LOCKED) (LOCKED = ONES)/
4792	106133	101	123	122 EM39: .ASCIZ /ASRB LOCK BALANCE FAILURE (# OF LOCKS PER CPU BELOW)/
4793	106220	102	122	101 EM40: .ASCIZ /BRANCH GOBBLE FAILED CONDITION CODES TEST/
4794	106272	123	124	101 EM41: .ASCIZ /STALE DATA COULD NOT BE CREATED - CACHE FAILURE NOT MAIN MEMORY. /
4795	106374	103	101	103 EM42: .ASCIZ /CACHE COULD NOT FLUSH STALE DATA - CACHE FAILURE NOT MAIN MEMORY. /
4796	106477	123	114	101 EM43: .ASCIZ /SLAVE DID NOT RESPOND IN TIME - ABORTING MULTIPROCESSOR TESTS/
4797	106575	111	111	123 EM44: .ASCIZ /IIST DID NOT RESPOND IN TIME - ABORTING MULTIPROCESSOR TESTS/
4798	106672	116	117	124 EM45: .ASCIZ /NOT ENOUGH GOOD MEMORY FOR SLAVE - ABORTING MULTIPROCESSOR TESTS/
4799	106773	101	114	114 EM46: .ASCIZ /ALL CPUS NOT SHARING A MEMORY BANK (ACCESSABLE = ONES)/
4800	107062	103	123	122 EM47: .ASCIZ /CSR CONFIGURATION ERROR - PROBABLY CSR SWITCHES IN BOX ARE SET WRONG /
4801	107170	101	120	124 EM48: .ASCIZ /APT EXPECTS DIFFERENT NUMBER OF CPU'S THAN DIAGNOSTIC CAN BOOT/
4802	107267	120	117	122 EM49: .ASCIZ /PORT CONTENTION BALANCED WITH 3 CPU'S RAISED TO HIGH PRIORITY/
4803				.EVEN

ERROR DATA HEADERS (DH)

```

4806          .SBTTL ERROR DATA HEADERS (DH)
4807 107366    040    040    120 DH1:  .ASCIZ / PC DEV ADD GOOD BAD/
4808 107423    040    040    120 DH2:  .ASCIZ / PC GD-CC BD-CC/
4809 107446    040    040    120 DH3:  .ASCIZ / PC 1ST ADD # OF ERRORS/
4810 107502    040    040    120 DH4:  .ASCIZ / PC/
4811 107507    040    040    120 DH5:  .ASCII / PC CPUERR MEMERR HIADRS LOADRS/
4812 107555    040    040    040      .ASCIZ / MMR0 MMR1 MMR2 MMR3/
4813 107615    040    040    120 DH6:  .ASCIZ / PC APTCORE MJSIZE APTMOS MKSIZE/
4814 107664    040    040    120 DH7:  .ASCII / PC BANK VADD PADD GOOD/
4815 107730    040    040    040      .ASCIZ / BAD XOR MAR BOX MTYPE INT PAT ARRAY/
4816 110006    104    105    126 DH8:  .ASCIZ / DEV ADD GOOD BAD GDSWITCH BDSWITCH NOTE. (OFF - 1)/
4817 110106    040    040    120 DH9:  .ASCIZ / PC CPUERR MEMERR CSRNUM/
4818 110145    040    040    122 DH10: .ASCIZ / RO R1 R2 R3 R4 R5 SP Psw/
4819 110243    040    040    120 DH11: .ASCIZ / PC CSR CSR+2/
4820 110272    040    103    123 DH12: .ASCIZ / CSR CSR+2/
4821 110307    040    040    120 DH13: .ASCII / PC BANK VADD PADD WROTE1 WROTE2/
4822 110364    040    103    110      .ASCIZ / CHKBITS CSR CSR+2/
4823 110415    115    105    115 DH14: .ASCII / MEMERR MAINT CONTRL HIADRS LOADRS (PUERR/
4824 110473    040    040    040      .ASCIZ / MMR0 MMR1 MMR2 MMR3/
4825 110533    040    040    120 DH15: .ASCII / PC BANK VADD PADD GD-WD1 GD-WD2 GD-CHK/
4826 110610    040    102    101      .ASCIZ / BAD-WD1 BAD-WD2 BAD-CHK MAR INT PAT/
4827 110655    040    040    120 DH16: .ASCIZ / PC BANK/
4828 110672    040    040    120 DH17: .ASCIZ / PC BANK MASTER SLAVE1 SLAVE2 SLAVE3/
4829 110746    040    040    120 DH18: .ASCIZ / PC BANK VADD PADD GOOD BAD/
4830 111023    040    040    120 DH19: .ASCIZ / PC ARRAY/
4831 111037    040    040    120 DH20: .ASCIZ / PC SLAVE#/
4832 111056    040    040    120 DH21: .ASCIZ / PC/
4833 111063    040    040    120 DH22: .ASCIZ / PC REAL# APT#/
4834 111111    040    040    120 DH23: .ASCIZ / PC BANK MASTER SLAVE1 SLAVE2 SLAVE3 LOW-CPU/
4835          .EVEN

```

MESSAGES

```

4838 .SBTTL MESSAGES
4839 111176 200 103 105 MSG000: .ASCIZ <CRLF>/CEMKABO 1170 MAIN MEMORY DIAGNOSTIC <V14-00>/
4840 111254 200 040 040 MSG001: .ASCIZ <CRLF>/
4841 111336 200 040 040 MSG002: .ASCIZ <CRLF>/
4842 111413 200 040 040 MSG003: .ASCIZ <CRLF>/
4843 111455 040 040 040 .ASCIZ / 1 2 3/
4844 111520 200 040 040 MSG004: .ASCIZ <CRLF>/ 4 5 6 7 /
4845 111561 060 061 062 .ASCIZ /012345670123456701234567/
4846 111626 200 105 122 MSG005: .ASCIZ <CRLF>/ERRORS /
4847 111640 200 125 116 MSG006: .ASCIZ <CRLF>/UNDEFINED TRAP INSTRUCTION/<32>
4848 111675 200 111 116 MSG007: .ASCIZ <CRLF>/INTRLV /
4849 111707 200 103 120 MSG008: .ASCIZ <CRLF>/CPU MAP / ;HEXADECIMAL(1=MASTER;2=SLAVE1;4=SLAVE2;8=SLAVE3)
4850 111721 200 115 105 MSG009: .ASCIZ <CRLF>/MEMTYPE / ;MEMORY TYPE (0=MJ11;1=MK11)
4851 111733 200 120 122 MSG010: .ASCIZ <CRLF>/PROTECT / ;MEMORY PROTECTED
4852 111745 040 040 040 MSG011: .ASCIZ / 0 1 2 3 4 5 6/
4853 112033 064 065 066 MSG012: .ASCIZ /45670123456701234567012345670123456701234567/
4854 112130 130 000 MSG013: .ASCIZ /X/
4855 112132 040 000 MSG014: .ASCIZ / / ;SPACE
4856 112134 000 000 MSG015: .BYTE 0,0 ;FOR SINGLE ASCII CHARACTERS & TERMINATOR
4857 112136 200 102 117 MSG016: .ASCIZ <CRLF>/BOX /
4858 112150 040 040 040 MSG017: .ASCIZ / / ;8 SPACES
4859 112161 040 040 000 MSG018: .ASCIZ / / ;2 SPACES
4860 112164 040 040 040 MSG019: .ASCIZ / / ;3 SPACES
4861 112170 200 106 111 MSG020: .ASCIZ <CRLF>/FIELD SERVICE COMMAND MODE/
4862 112224 200 103 117 MSG021: .ASCIZ <CRLF>/COMMANDS AVAILABLE ARE:/
4863 112254 200 060 040 .ASCIZ <CRLF>/0 = EXIT FIELD SERVICE COMMANDS/
4864 112314 200 061 040 .ASCIZ <CRLF>/1 = READ CSR/
4865 112331 200 062 040 .ASCIZ <CRLF>/2 = LOAD CSR/
4866 112346 200 063 040 .ASCIZ <CRLF>/3 = EXAMINE MEMORY/
4867 112371 200 064 040 .ASCIZ <CRLF>/4 = MODIFY MEMORY/
4868 112413 200 065 040 .ASCIZ <CRLF>/5 = SELECT BANK, MARGIN, & PATTERN/
4869 112455 200 066 040 .ASCIZ <CRLF>/6 = TYPE CONFIGURATION MAP/
4870 112510 200 067 040 .ASCIZ <CRLF>/7 = BATTERY BACKUP - P/F TEST''
4871 112546 200 070 040 .ASCIZ <CRLF>/8 = SOB-A-LONG TEST/
4872 112572 200 071 040 .ASCIZ <CRLF>/9 = SUPER TIGHT SCOPE LOOP/
4873 112625 200 061 060 .ASCIZ <CRLF>/10= ERROR SUMMARY/
4874 112647 200 061 061 .ASCIZ <CRLF>/11= REFRESH TEST/
4875 112670 200 061 062 .ASCIZ <CRLF>/12= SET FILL COUNT/
4876 112713 200 061 063 .ASCIZ <CRLF>/13= ENTER KAMIKAZE MODE/
4877 112743 200 061 064 .ASCIZ <CRLF>/14= EXIT KAMIKAZE MODE/
4878 112772 200 061 065 .ASCIZ <CRLF>/15= TURN CACHE OFF/
4879 113015 200 061 066 .ASCIZ <CRLF>/16= TURN CACHE ON/
4880 113037 200 061 067 .ASCIZ <CRLF>/17= RUN ONLY MULTIPOINT TESTS/
4881 113074 200 061 070 .ASCIZ <CRLF>/18= RESUME RUNNING BOTH SINGLE & MULTIPOINT TESTS/
4882 113155 200 061 071 .ASCIZ <CRLF>/19= TEST ONLY SELECTED BANKS/
4883 113212 200 062 060 .ASCIZ <CRLF>/20= RESUME TESTING ALL BANKS/
4884 113247 015 012 000 .BYTE 15,12,0
4885 113252 200 127 110 MSG022: .ASCIZ <CRLF>/WHICH CSR(0-7)? /
4886 113274 200 103 123 MSG023: .ASCIZ <CRLF>/CSR - 1ST WORD? /
4887 113316 200 103 123 MSG024: .ASCIZ <CRLF>/CSR - 2ND WORD? /
4888 113340 200 124 110 MSG025: .ASCIZ <CRLF>/THIS CSR DOES NOT EXIST/
4889 113371 200 103 117 MSG026: .ASCIZ <CRLF>/COMMAND:/
4890 113403 200 117 114 MSG027: .ASCIZ <CRLF>/OLD CSR WAS/
4891 113420 200 103 123 MSG028: .ASCIZ <CRLF>/CSR IS NOW/
4892 113434 200 105 130 MSG029: .ASCIZ <CRLF>/EXAMINE MEMORY/
4893 113454 200 102 101 MSG030: .ASCIZ <CRLF>/BANK(0-167)? /
4894 113473 200 120 110 MSG031: .ASCIZ <CRLF>/PHYSICAL ADDRESS(0-1677776)

```

4895	113533	200	120	101	MSG032:	.ASCIZ	<CRLF>/PARITY ABORT/<32>
4896	113552	200	124	111	MSG033:	.ASCIZ	<CRLF>/TIMEOUT TRAP/<32>
4897	113571	200	102	131	MSG034:	.ASCII	<CRLF>/BYPASSING CSR TESTS ON BOX /
4898	113625	000			MSG034:	.BYTE	0
4899	113626	040	103	117		.ASCII	/ CONTROLLER /
4900	113642	000			MSG034:	.BYTE	0
4901	113643	200	104	125		.ASCIZ	<CRLF>/DUE TO LACK OF SBE FREE LOCATIONS/<32>
4902	113707	121	126	000	MSG035:	.ASCIZ	/QV/
4903	113712	200	115	117	MSG036:	.ASCIZ	<CRLF>/MODIFY MEMORY/
4904	113731	200	117	114	MSG037:	.ASCIZ	<CRLF>/OLD DATA WAS /
4905	113750	200	104	101	MSG038:	.ASCIZ	<CRLF>/DATA IS NOW /
4906	113766	200	111	116	MSG039:	.ASCIZ	<CRLF>/INPUT NEW DATA? /
4907	114010	200	123	105	MSG040:	.ASCIZ	<CRLF>/SELECT BANK, MARGIN, & PATTERN TEST/
4908	114055	200	102	101	MSG041:	.ASCIZ	<CRLF>/BANK NOT ACCESSABLE/
4909	114102	200	120	101	MSG042:	.ASCIZ	<CRLF>/PATTERN(0-3)? /
4910	114123	200	120	101	MSG043:	.ASCIZ	<CRLF>/PATTERN 0 DATA !S? /
4911	114150	200	115	101	MSG044:	.ASCIZ	<CRLF>/MARGIN(0,2,3,4,5)? /
4912	114175	200	115	101	MSG045:	.ASCIZ	<CRLF>/MARGINS INHIBITED BY SW11! /
4913	114231	200	124	117	MSG046:	.ASCIZ	<CRLF>/TO ESCAPE TYPE ANY KEY/<CRLF><12><12>
4914	114264	200	124	105	MSG047:	.ASCIZ	<CRLF>/TEST COMPLETE/
4915	114303	040	116	117	MSG048:	.ASCIZ	/ NOT AVAILABLE NOW - TRY LATER! /
4916	114343	200	102	101	MSG049:	.ASCIZ	<CRLF>/BANK REQUIRES RELOCATION/
4917	114375	200	102	101	MSG050:	.ASCII	<CRLF>/BATTERY BACKUP TEST/
4918	114421	200	127	122		.ASCIZ	<CRLF>/WRITING & CHECKING ADDRESS PATTERN AS BACKGROUND/
4919	114503	200	120	117	MSG051:	.ASCIZ	<CRLF>/POWER RECOVERY/
4920	114523	200	122	105	MSG052:	.ASCIZ	<CRLF>/REMOVE SYSTEM POWER FOR/
4921	114554	040	123	105	MSG053:	.ASCIZ	/ SECONDS MAX! /
4922	114572	200	116	117	MSG054:	.ASCIZ	<CRLF>/NOW STARTING READ TEST OF MEMORY BANKS/
4923	114642	200	123	117	MSG055:	.ASCIZ	<CRLF>/SOB-A-LONG TEST/
4924	114663	200	102	105	MSG056:	.ASCIZ	<CRLF>/BELL - EACH PASS COMPLETE/
4925	114716	040	077	040	MSG057:	.ASCIZ	/ ? /
4926	114722	200	040	040	MSG058:	.ASCIZ	<CRLF>/ CSR CSR+2 CSR CSR+2 ... /
4927	114766	200	123	125	MSG059:	.ASCIZ	<CRLF>/SUPER TIGHT SCOPE LOOP/
4928	115016	200	123	127	MSG060:	.ASCIZ	<CRLF>/SWREG ----> MEM, MEM ----> DISPLAY/
4929	115060	077	077	077	MSG061:	.ASCIZ	/??????/
4930	115067	111	116	120	MSG062:	.ASCIZ	/INPUT MUST BE A/
4931	115107	116	040	117	MSG063:	.ASCIZ	/N OCTAL /
4932	115120	116	125	115	MSG064:	.ASCIZ	/NUMBER/<CRLF>
4933	115130	040	104	105	MSG065:	.ASCIZ	/ DECIMAL /
4934	115142	200	105	122	MSG066:	.ASCIZ	<CRLF>/ERROR COUNT EXCEEDED 20 - ABORTING FOR XXDP CHAIN/
4935	115225	106	101	124	MSG067:	.ASCIZ	/FATAL /
4936	115234	115	112	061	MSG068:	.ASCIZ	/MJ11/
4937	115241	115	113	061	MSG069:	.ASCIZ	/MK11/
4938	115246	113	040	127	MSG070:	.ASCIZ	/K WORDS OF MEMORY/<CRLF>
4939	115271	113	040	117	MSG071:	.ASCIZ	/K OF MJ11/<CRLF>
4940	115304	113	040	117	MSG072:	.ASCIZ	/K OF MK11/<CRLF>
4941	115317	200	122	105	MSG073:	.ASCIZ	<CRLF>/REFRESH TEST/
4942						.EVEN	;THIS STAYS WITH MSG074
4943	115336	077	077	000	MSG074:	.ASCIZ	/???
4944	115341	200	122	105	MSG075:	.ASCIZ	<CRLF>/RELOCATION NOT POSSIBLE/<32>
4945	115373	200	040	040	MSG076:	.ASCIZ	<CRLF>/ BANK ERRORS/<CRLF>
4946	115414	200	105	116	MSG077:	.ASCIZ	<CRLF>/END PASS #/
4947	115430	200	127	101	MSG078:	.ASCIZ	<CRLF>/WARNING. ECC IS DISABLED ON BOX /<32>
4948	115474	040	105	122	MSG079:	.ASCIZ	/ ERROR(S) DETECTED/<CRLF>
4949	115520	200	105	116	MSG080:	.ASCIZ	<CRLF>/ENTER # OF SLAVE CPU'S (0-3)? /
4950	115560	200	123	124	MSG081:	.ASCIZ	<CRLF>/START SLAVE #/
4951	115577	040	101	124	MSG082:	.ASCIZ	/ AT ADDRESS 200/

MESSAGES

```

4952 115617      200      120      122 MSG084: .ASCIZ <CRLF>/PROCEEDING AS A SINGLE PORT TEST/
4953 115661      200      106      111 MSG085: .ASCIZ <CRLF>/FILL COUNT(OCTAL)? /
4954 115706      200      115      125 MSG086: .ASCII <CRLF>/MULTIPOINT DIRECTORY/
4955 115732      200      115      101 .ASCIZ <CRLF>/MASTER - /
4956 115745      200      123      114 MSG087: .ASCII <CRLF>/SLAVE/
4957 115753      060      114      MSGA87: .BYTE '0
4958 115754      040      075      040 .ASCIZ '/ = /
4959 115760      200      113      105 MSG088: .ASCIZ <CRLF>/KERNEL STACK/
4960 115776      200      123      125 MSG089: .ASCIZ <CRLF>/SUPERVISOR STACK/
4961 116020      200      125      123 MSG090: .ASCIZ <CRLF>/USER STACK/
4962 116034      040      111      123 MSG091: .ASCIZ / IS EMPTY/
4963 116046      122      105      114 MSG092: .ASCIZ /RELOCATED /
4964 116062      102      101      116 MSG093: .ASCIZ /BANK=/
4965 116070      040      040      115 MSG094: .ASCIZ / MAR=/
4966 116077      040      040      120 MSG095: .ASCIZ / PAT=/
4967 116106      200      114      117 MSG096: .ASCIZ <CRLF>/LOADERS BEING DESTROYED/
4968 116137      200      127      101 MSG097: .ASCIZ <CRLF>/WARNING. ILLEGAL INTERLEAVE SELECTED (FIELD SERVICE ONLY)/<32>
4969 116234      200      123      114 MSG098: .ASCII <CRLF>/SLAVE/
4970 116242      000      114      MSGA98: .BYTE 0
4971 116243      076      000      .ASCIZ />/
4972 116245      200      115      101 MSG099: .ASCIZ <CRLF>/MASTER>/
4973 116256      200      115      125 MSG100: .ASCIZ <CRLF>/MULTIPROCESSOR TEST #/
4974 116305      200      105      116 MSG101: .ASCIZ <CRLF>/ENTERING KAMIKAZE MODE/
4975 116335      200      114      105 MSG102: .ASCIZ <CRLF>/LEAVING KAMIKAZE MODE/
4976 116364      200      114      105 MSG103: .ASCIZ <CRLF>/LEAVING FIELD SERVICE MODE/<CRLF>
4977 116421      032      000      MSG104: .BYTE 32,0 ;CONTROL Z
4978 116423      200      105      116 MSG105: .ASCIZ <CRLF>/ENTER BANKS IN OCTAL - USE NUMBER OUTSIDE RANGE TO TERMINATE (177)/
4979 116527      200      103      101 MSG106: .ASCIZ <CRLF>/CACHE IS OFF/
4980 116545      200      103      101 MSG107: .ASCIZ <CRLF>/CACHE IS ON (EXCEPT DURING ACTUAL PATTERNS)/
4981 116622      200      117      116 MSG108: .ASCIZ <CRLF>/ONLY MULTIPOINT TESTS WILL BE RUN/
4982 116664      200      102      117 MSG109: .ASCIZ <CRLF>/BOTH SINGLE & MULTIPOINT TESTS WILL BE RUN/
4983 116737      200      117      116 MSG110: .ASCIZ <CRLF>/ONLY SELECTED BANKS WILL BE TESTED/
4984 117003      200      101      114 MSG111: .ASCIZ <CRLF>/ALL BANKS WILL BE TESTED/
4985 117035      200      120      122 MSG112: .ASCIZ <CRLF>/PROGRAM HALTING BECAUSE OF SWITCH #8/
4986 117103      040      115      101 MSG113: .ASCIZ / MASTER/
4987 117113      040      123      111 MSG114: .ASCIZ / SLAVE1/
4988 117123      040      123      114 MSG115: .ASCIZ / SLAVE2/
4989 117133      040      123      114 MSG116: .ASCIZ / SLAVE3/
4990 .EVEN
4996 117144      .$$END
4997 117144      END:
4998 117144      000406 .PRINT 60000-SUPLIMIT ;SUPERVISOR ADDRESSES LEFT
5003 117144      002004 .PRINT 100000-SLAVEND ;ADDRESSES LEFT IN SLAVE UNIQUE CODE
5008 117144      020634 .PRINT 140000-END ;ADDRESSES LEFT IN 24K
5012 .000200 .END START3

```

SYMBOL TABLE

ABORTF	002142	BIT4	= 000020	B144	062364	B36	024446	CMD20A	050576
ACFLAG	002124	BIT5	= 000040	B145	062450	B37	024452	CMD5A	045456
ACK	002672	BIT6	= 000100	B146	062572	B4	010550	CMD5B	045666
ACTFLA	002442	BIT7	= 000200	B147	062630	B40	024616	CMD5C	046052
ADDPAR	014570	BIT8	= 000400	B15	013004	B41	024624	CMD7A	046336
ADDRES	002040	BIT9	= 001000	B150	062632	B42	025034	CMD8A	046550
ADD..0	071152	BLOCK1	043710	B151	062674	B43	033412	CMD8B	046740
ADD..1	071162	BLOCK2	043730	B152	063032	B44	033450	CMD8C	047014
ADD..2	071202	BLOCK3	043744	B153	063070	B45	033464	CMD9A	047240
ADD..3	071232	BMFLAG	002136	B154	063120	B46	033604	CMD9B	047456
ADD..4	071262	BOOT	043416	B155	063170	B47	033764	CMD9C	047464
ADD..5	071264	BOOTLO=	000012	B156	063172	B5	010554	CMD9LO	047444
ADD..6	071304	BOOT1	043460	B157	063330	B50	034006	CONFGE	002576
ADD..7	071334	BARGOBB	035112	B16	013014	B51	040014	CONFGT	006666
ALLCPU	002510	B0	005500	B160	063404	B52	040020	CONF G1	006304
APTCOR	002522	B1	007742	B161	063410	B53	040160	CONF G3	006520
APTDOW	043640	B10	011352	B162	063472	B54	040164	CONF G5	006712
APTFLA	002444	B100	053774	B163	063522	B55	040450	CONF IE	004336
APTHAN	015050	B101	054102	B164	063602	B56	040454	CONF IG	003016
APTHLT	043706	B102	054146	B165	063604	B57	041144	CONF SP	006754
APTMOS	002524	B103	054226	B166	063754	B6	010642	CONTF L	002332
APTSIZ	002544	B104	054234	B167	064016	B60	041152	CONTP	073112
ASRBAL -	000110	B105	054256	B17	013016	B61	041302	CONTR L=	177746
A3	000002	B106	054370	B170	064052	B62	041306	CONTS	073544
BACKGN	035344	B107	054416	B171	064122	B63	042530	CONTS1	073052
BAD	002056	B11	011360	B172	064124	B64	046374	CONTS2	073546
BADCSR	002000	B110	054472	B173	064246	B65	046744	CONTT	073404
BADPC	002026	B111	054474	B174	064260	B66	047612	COREHI	043300
BADPSW	002036	B112	055374	B175	064316	B67	050170	COUNT	002462
BADSP	002032	B113	055400	B176	064372	B7	010732	CPUBIT	002114
BADSTA	036770	B114	055700	B177	064512	B70	050512	CPUERR=	177766
BAD XOR	002064	B115	055706	B2	010312	B71	050512	CPUID	011656
BAD2	002060	B116	057452	B20	013124	B72	050600	CR	= 000015
BAD3	002062	B117	057474	B200	070344	B73	050752	CRLF	= 000200
BAFPAF	015204	B12	012140	B201	070436	B74	053016	CSR	002144
BAFPAR	015320	B120	057622	B202	070736	B75	053024	CSRCAS	020114
BAKPAT	002762	B121	057756	B203	070740	B76	053660	CSRFB	002214
BALANC -	000155	B122	060072	B204	071610	B77	053710	CSRFB A	002410
BANK	002106	B123	060244	B205	071614	CACHK	002700	CSRFR	002336
BANKIN	002110	B124	060256	B206	071730	CACHOF=	104424	CSRINC	002414
BANKMO	042072	B125	060264	B207	072012	CACHON=	104423	CSRIND	002416
BANKOK	042730	B126	060514	B21	013220	CACHVE=	000114	CSRLB	002234
BAWPAF	015434	B127	060754	B210	072076	CBCSR =	104474	CSRLBA	002412
BAWPAR	015572	B13	012144	B211	072174	CB1CSR=	104475	CSRLOO	002420
BDSWIT	002500	B130	061340	B22	013270	CHECK	002404	CSRNO	002256
BEGIN	005752	B131	061352	B23	013632	CHKDIS=	104504	CSROUD	002417
BGTEST	035110	B132	061412	B24	014144	CHKGEN	040540	CSROUT	040442
BIT0	= 000001	B133	061520	B25	014512	CHKTAB	040640	CSRREL	002254
BIT1	= 000002	B134	061572	B26	015114	CHKTDI=	104505	CSRSTU=	000031
BIT10	= 002000	B135	061724	B27	016722	CKEND	073316	CSRO	002154
BIT11	= 004000	B136	061736	B3	010316	CKSWR =	104410	CSR2	002174
BIT12	= 010000	B137	061774	B30	016744	CLRC SR=	104502	DATBUF	002340
BIT13	= 020000	B14	012556	B31	016750	CLRTCS=	104503	DBEMSK	002354
BIT14	= 040000	B140	062102	B32	016762	CMD11A	047774	DDISP =	177570
BIT15	= 100000	B141	062154	B33	017044	CMD11B	050164	DECMAR	043152
BIT2	= 000004	B142	062312	B34	017060	CMD11C	050240	DEENER -	104421
BIT3	= 000010	B143	062350	B35	023232	CMD19L=	000070	DETAIL	071364

SYMBOL TABLE

DEFLA	002326	DT13	102504	EM37	105760	E121	060040	E203	071110
DEIPSW	002324	DT14	102530	EM38	106025	E122	060212	E204	071670
DETR0	002306	DT16	102556	EM39	106133	E123	060460	E205	071670
DETR1	002310	DT17	102610	EM4	103311	E124	060450	E206	071760
DETR2	002312	DT18	102616	EM40	106220	E125	060432	E207	072044
DETR3	002314	DT19	102634	EM41	106272	E126	060536	E21	013244
DETR4	002316	DT2	102264	EM42	106374	E127	061006	E210	072130
DETR5	002320	DT20	102652	EM43	106477	E13	012530	E211	072330
DETRSP	002322	DT21	102662	EM44	106575	E130	061702	E22	013620
DF1	102740	DT22	102700	EM45	106672	E131	061672	E23	013714
DF10	103076	DT23	102706	EM46	106773	E132	061656	E24	014264
DF11	103103	DT24	102714	EM47	107062	E133	061540	E25	014562
DF12	103114	DT25	102720	EM48	107170	E134	061646	E26	015202
DF13	103116	DT3	102302	EM49	107267	E135	062264	E27	017256
DF14	103125	DT4	102312	EM5	103357	E136	062254	E3	010364
DF2	102743	DT5	102322	EM6	103434	E137	062240	E30	017230
DF3	102767	DT6	102346	EM7	103461	E14	012716	E31	017166
DF4	103004	DT7	102362	EM8	103521	E140	062122	E32	017166
DF5	103021	DT8	102416	EM9	103556	E141	062230	E33	017152
DF6	103036	DT9	102432	ENASBE=	104506	E142	062544	E34	017122
DF7	103053	DUMMY	002304	ENA1SB=	104507	E143	062530	E35	023316
DF8	103067	DUMPCS=	000204	END	117144	E144	062436	E36	024574
DF9	103071	ECCDIS=	104470	ENERGI=	104420	E145	062520	E37	024560
DH1	107366	ECCINI=	104472	ERRMAX	002702	E146	062772	E4	010612
DH10	110145	ECC1D1=	104471	ERROR =	104000	E147	062756	E40	024746
DH11	110243	ECC1IN=	104473	ERRPC	002024	E15	013066	E41	024732
DH12	110272	EMTVEC=	000030	ERRPSW	002034	E150	062662	E42	025112
DH13	110307	EM1	103134	ERRSP	002030	E151	062744	E43	033756
DH14	110415	EM10	103633	ERRVEC=	000004	E152	063254	E44	033742
DH15	110533	EM11	103677	EVEN	002456	E153	063112	E45	033556
DH16	110655	EM12	103721	EXBANK	042422	E154	063170	E46	033726
DH17	110672	EM13	103745	EXCMD3	044726	E155	063240	E47	034002
DH18	110746	EM14	103777	EXCMD4	045236	E156	063240	E5	010612
DH19	111023	EM15	104043	EXIT	043522	E157	063576	E50	034026
DH2	107423	EM16	104111	EXIT2	043526	E16	013066	E51	040066
DH20	111037	EM17	104137	E0	005530	E160	063562	E52	040066
DH21	111056	EM18	104177	E1	010242	E161	063470	E53	040232
DH22	111063	EM19	104256	E10	011444	E162	063514	E54	040232
DH23	111111	EM2	103220	E100	054364	E163	063542	E55	040504
DH3	107446	EM20	104333	E101	054124	E164	063672	E56	040504
DH4	107502	EM21	104415	E102	054216	E165	063672	E57	041302
DH5	107507	EM22	104454	E103	054342	E166	064174	E6	010672
DH6	107615	EM23	104501	E104	054330	E167	064044	E60	041262
DH7	107664	EM24	104530	E105	054304	E17	013056	E61	041442
DH8	110006	EM25	104607	E106	054412	E170	064122	E62	041422
DH9	110106	EM26	104634	E107	054466	E171	064160	E63	042562
DIAGFL	002006	EM27	104705	E11	011432	E172	064160	E64	046456
DISPLA	002770	EM28	104774	E110	054542	E173	064466	E65	047006
DISPRE=	000174	EM29	105027	E111	054542	E174	064456	E66	047720
DISPTB	014370	EM3	103256	E112	055440	E175	064354	E67	050232
DNSLAV	055170	EM30	105111	E113	055440	E176	064442	E7	011076
DOBACK	015104	EM31	105230	E114	055746	E177	064570	E70	050552
DSWR =	177570	EM32	105330	E115	055746	E2	010364	E71	050552
DT1	102252	EM33	105435	E116	057602	E20	013160	E72	050626
DT10	102444	EM34	105543	E117	057516	E200	070402	E73	051042
DT11	102466	EM35	105624	E12	012530	E201	070474	E74	053074
DT12	102476	EM36	105711	E120	057752	E202	071110	E75	053062

SYMBOL TABLE

E76	053734	IIII =	177777	K12	002554	L1017	070542	L13	005376
E77	053730	IISTAC	002736	K13	002556	L102	011414	L130	012700
FASTCI=	177640	IISTAD	002740	K14	002560	L1020	070602	L131	012764
FATALS	002070	IISTIN	061074	K15	002562	L1021	070570	L132	013046
FCMD10	047550	IISTOF	061174	K16	002564	L1022	070576	L133	013046
FCMD11	047734	IISTVE	002742	K17	002566	L1023	070624	L134	013160
FCMD12	050330	IITRAP	036764	KMAP =	104422	L1024	070640	L135	013174
FCMD13	050356	INCBNK	042772	KPFLAG	002122	L1025	070654	L136	013254
FCMD14	050400	INCMAR	043006	KSTACK	002706	L1026	070670	L137	013226
FCMD15	050420	INCPAT	042746	LAST =	157776	L1027	071072	L14	005470
FCMD16	050436	INCRPT	042746	LASTB	002262	L103	011416	L140	013620
FCMD17	050454	INTERL	002264	LASTER	002020	L1030	071072	L141	013472
FCMD18	050470	INTER0	006756	LBSL0 =	001057	L1031	071056	L142	013472
FCMD19	050502	INTER1	006760	LBSL1 =	001055	L1032	071122	L143	013472
FCMD20	050566	INTER2	006760	LBSL10=	000223	L1033	071200	L144	013416
FIELDS	043774	INTER3	006766	LBSL11=	000034	L1034	071230	L145	013434
FINDBA=	000061	INTER4	006766	LBSL2 =	001050	L1035	071260	L146	013452
FIRST =	060000	INTER5	006774	LBSL3 =	001051	L1036	071302	L147	013470
FIRSTB	002260	INTER6	006766	LBSL4 =	001032	L1037	071332	L15	005510
FIRSTP=	000010	INTER7	006774	LBSL5 =	000712	L104	011532	L150	013604
FLIPLO	002734	INTKRA	017610	LBSL6 =	000714	L1040	071362	L151	013534
FLIPWA	035214	INT..0	020234	LBSL7 =	000033	L1041	071646	L152	013542
FLUSH	014656	INT..1	020260	LCSROU=	000055	L1042	072046	L153	013604
FSCMD0	044170	INT..2	020324	LCSRRE=	000114	L1043	072052	L154	013702
FSCMD1	044256	INT..3	020350	LCSRSA=	000112	L1044	072132	L155	013656
FSCMD2	044346	INT..4	020414	LF =	000012	L1045	072136	L156	013702
FSCMD3	044520	INT..5	020440	LKS =	177546	L1046	072316	L157	014032
FSCMD4	044764	INT..6	020504	LOADBA	002532	L1047	072264	L16	005570
FSCMD5	045274	INT..7	020530	LOADCS=	104425	L105	011574	L160	014112
FSCMD6	046152	INT..10	020574	LOADER=	000057	L1050	072316	L161	014116
FSCMD7	046160	INT..11	020574	LOADHO	002710	L1051	072316	L162	014336
FSCMD8	046510	INT..12	020616	LOADRS=	177740	L1052	073034	L163	014254
FSCMD9	047104	INT..13	020642	LOCK	002670	L1053	073452	L164	014172
FSINFL	002542	INT..14	020706	LOOP	014342	L1054	073540	L165	014174
FSPAT	045752	INT..15	020732	LOWMAP	042026	L1055	073464	L166	014234
FSSTAC	002374	INT..16	020776	LWDBE =	000053	L1056	073600	L167	014250
FS1	044052	INT..17	021022	LWSBE =	000051	L1057	073602	L17	005654
FS7FLA	002546	INVALI=	104511	L0	004426	L106	011614	L170	014304
GBLENG=	000076	IOTVEC=	000020	L1	004422	L107	011634	L171	014306
GDSWIT	002476	ISECCO	017300	L10	005376	L11	005376	L172	014336
GETDAT	055030	J	002604	L100	011552	L110	011654	L173	014456
GETDA1	055156	KAMIKA	002010	L1000	067226	L111	011672	L174	014566
GETDIS	066514	KAMITE	026006	L1001	067240	L112	011714	L175	014546
GETSIZ	017736	KDIAG =	000010	L1002	067276	L113	011766	L176	014546
GOOD	002050	KDPAR0=	172360	L1003	067306	L114	012034	L177	014622
GOOD2	002052	KDPAR7=	172376	L1004	067630	L115	012130	L2	004536
GOOD3	002054	KDPDR7=	172336	L1005	070316	L116	012250	L20	005616
GTSWR =	104407	KERNEL=	104417	L1006	070234	L117	012372	L200	014622
HEADER	002724	KERSTK=	002000	L1007	070234	L12	005370	L201	014656
HIACBA	002514	KIPAR0=	172340	L101	011416	L120	012422	L202	014734
HIADRS=	177742	KIPAR4=	172350	L1010	070274	L121	012416	L203	014744
HIBANK	002512	KIPAR5=	172352	L1011	070262	L122	012420	L204	015100
HIPAT	042762	KIPAR6=	172354	L1012	070270	L123	012514	L205	015166
HT =	000011	KIPAR7=	172356	L1013	070360	L124	012474	L206	015306
HUNGMS	002572	KIPDR0=	172300	L1014	070366	L125	012474	L207	015422
HUNGTI	002574	KIO	002550	L1015	070452	L126	012550	L21	005634
:	002602	KI1	002552	L1016	070460	L127	012700	L210	015560

SYMBOL TABLE

SEQ 0556

L211	015716	L274	022600	L356	025152	L44	007700	L521	045714
L212	016054	L275	022614	L357	025224	L440	040210	L522	045716
L213	016234	L276	022624	L36	006630	L441	040252	L523	046232
L214	016372	L277	022624	L360	025350	L442	040260	L524	046234
L215	016552	L3	005046	L361	025540	L443	040376	L525	046442
L216	016674	L30	006242	L362	025756	L444	040432	L526	046602
L217	017230	L300	022662	L363	025770	L445	040462	L527	046604
L22	005636	L301	022672	L364	026030	L446	041114	L53	010202
L220	017152	L302	022672	L365	026036	L447	041144	L530	046630
L221	017034	L303	022732	L366	026042	L45	007714	L531	046644
L222	017152	L304	022746	L367	033434	L450	041246	L532	046646
L223	017134	L305	022756	L37	006712	L451	041276	L533	046772
L224	01721	L306	022756	L370	033444	L452	041410	L534	047154
L225	017366	L307	023010	L371	033556	L453	041410	L535	047156
L226	017372	L31	006356	L372	033506	L454	041410	L536	047272
L227	017724	L310	023024	L373	033520	L455	041410	L537	047274
L23	005714	L311	023034	L374	033536	L456	041410	L54	010300
L230	020016	L312	023034	L375	033544	L457	041436	L540	047320
L231	020030	L313	023066	L376	033570	L46	010226	L541	047720
L232	020072	L314	023102	L377	033726	L460	041534	L542	047704
L233	020110	L315	023112	L4	005144	L461	042550	L543	047654
L234	020224	L316	023112	L40	006734	L462	042720	L544	050026
L235	020306	L317	023172	L400	033626	L463	043026	L545	050030
L236	020314	L32	006406	L401	033640	L464	043114	L546	050054
L237	020376	L320	023202	L402	033672	L465	043134	L547	050070
L24	005774	L321	023202	L403	033656	L466	043230	L55	010304
L240	020404	L322	023300	L404	033670	L467	043232	L550	050072
L241	020466	L323	023270	L405	033714	L47	010226	L551	050216
L242	020474	L324	023400	L406	033702	L470	043256	L552	050534
L243	020556	L325	023402	L407	033714	L471	043264	L553	050536
L244	020564	L326	023432	L41	007152	L472	043410	L554	050724
L245	020614	L327	023436	L410	034026	L473	043410	L555	050726
L246	020670	L33	006476	L411	035504	L474	043364	L556	051030
L247	020676	L330	023466	L412	036150	L475	043410	L557	050774
L25	006010	L331	023472	L413	036220	L476	043444	L56	010306
L250	020760	L332	023526	L414	036246	L477	043542	L560	051010
L251	020766	L333	023532	L415	036240	L5	005222	L561	051026
L252	021050	L334	023562	L416	036246	L50	010166	L562	051056
L253	021056	L335	023566	L417	037136	L500	043546	L563	051170
L254	021174	L336	023744	L42	007156	L501	043554	L564	051414
L255	021216	L337	023776	L420	037142	L502	043574	L565	051514
L256	021232	L34	006564	L421	037202	L503	043606	L566	051644
L257	021250	L340	024042	L422	037206	L504	044016	L567	051656
L26	006160	L341	024206	L423	037424	L505	044026	L57	010350
L260	021254	L342	024216	L424	037432	L506	044160	L570	052414
L261	021256	L343	024216	L425	037510	L507	044220	L571	052442
L262	021322	L344	024544	L426	037544	L51	010166	L572	052510
L263	021344	L345	024530	L427	037634	L510	044224	L573	052522
L264	021372	L346	024544	L43	007160	L511	044246	L574	053076
L265	021372	L347	024610	L430	037670	L512	044252	L575	053202
L266	021522	L35	006614	L431	037730	L513	045416	L576	053200
L267	021566	L350	024716	L432	037772	L514	045456	L577	053232
L27	006160	L351	024702	L433	040044	L515	045510	L6	005246
L270	022522	L352	024716	L434	040044	L516	045512	L60	010346
L271	022536	L353	025076	L435	040106	L517	045536	L600	053232
L272	022546	L354	025076	L436	040114	L52	010166	L601	053734
L273	022546	L355	025200	L437	040210	L520	045574	L602	053722

L603	053726	L666	061630	L75	011306	MHALT3	012760	MSG025	113340
L604	054350	L667	062240	L750	065774	MINDEX	002666	MSG026	113371
L605	054200	L67	011110	L751	066006	MJPAT	021600	MSG027	113403
L606	054272	L670	062040	L752	066030	MJSIZE	002466	MSG028	113420
L607	054314	L671	062066	L753	066076	MJTEST	021512	MSG029	113434
L61	010576	L672	062220	L754	066156	MKCONT	016664	MSG030	113454
L610	054450	L673	062212	L755	066172	MKCSRS	002334	MSG031	113473
L611	054526	L674	062530	L756	066174	MKCSRT	020124	MSG032	113533
L612	054532	L675	062402	L757	066250	MKFLAG	002126	MSG033	113552
L613	054626	L676	062502	L76	011320	MKPAT	021402	MSG034	113571
L614	054642	L677	062756	L760	066316	MKSIZE	002470	MSG035	113707
L615	054646	L7	005316	L761	066312	MKTEST	021222	MSG036	113712
L616	054664	L70	011224	L762	066316	MK11AD=	172100	MSG037	113731
L617	055024	L700	062726	L763	066350	MMR0 =	177572	MSG038	113750
L62	010672	L701	063010	L764	066360	MMR1 =	177574	MSG039	113766
L620	055174	L702	063240	L765	066624	MMR2 =	177576	MSG040	114010
L621	055312	L703	063152	L766	066746	MMR3 =	172516	MSG041	114055
L622	055416	L704	063224	L767	066746	MMTRAP	036740	MSG042	114102
L623	055550	L705	063230	L77	011332	MMVEC =	000250	MSG043	114123
L624	055724	L706	063272	L770	067116	MOVELO=	000124	MSG044	114150
L625	057152	L707	063306	L771	067050	MP1	012070	MSG045	114175
L626	057136	L71	011236	L772	067074	MP2	012224	MSG046	114231
L627	057152	L710	063562	L773	067076	MP3	012716	MSG047	114264
L63	011076	L711	063562	L774	067116	MP4	012552	MSG048	114303
L630	057314	L712	063454	L775	067300	MP5	012764	MSG049	114343
L631	057202	L713	063450	L776	067164	MRUNSE	053640	MSG050	114375
L632	057216	L714	063454	L777	067276	MSEEDH	002720	MSG051	114503
L633	057232	L715	063662	MAINT =	177750	MSEEDL	002722	MSG052	114523
L634	057326	L716	063662	MAPHO =	170202	MSG34	113625	MSG053	114554
L635	057604	L717	063722	MAPH36=	170372	MSG87	115753	MSG054	114572
L636	057564	L72	011250	MAPH37=	170376	MSG98	116242	MSG055	114642
L637	060040	L720	064160	MAPLO =	170200	MSGB34	113642	MSG056	114663
L64	011076	L721	064104	MAPL1 =	170204	MSG000	111176	MSG057	114716
L640	057724	L722	064150	MAPL36=	170370	MSG001	111254	MSG058	114722
L641	060022	L723	064224	MAPPER	040700	MSG002	111336	MSG059	114766
L642	060174	L724	064230	MARGIN	002112	MSG003	111413	MSG060	115016
L643	060174	L725	064442	MASTER=	000020	MSG004	111520	MSG061	115060
L644	060416	L726	064336	MAST01	057372	MSG005	111626	MSG062	115067
L645	060366	L727	064344	MAST02	060046	MSG006	111640	MSG063	115107
L646	060554	L73	011262	MAST03	060220	MSG007	111675	MSG064	115120
L647	060572	L730	064424	MAST04	061322	MSG008	111707	MSG065	115130
L65	011060	L731	064552	MAST05	061706	MSG009	111721	MSG066	115142
L650	060610	L732	065346	MAST06	062270	MSG010	111733	MSG067	115225
L651	060626	L733	065360	MAST07	062550	MSG011	111745	MSG068	115234
L652	060644	L734	065376	MAST10	062776	MSG012	112033	MSG069	115241
L653	060662	L735	065400	MAST11	063260	MSG013	112130	MSG070	115246
L654	060700	L736	065420	MAST12	063732	MSG014	112132	MSG071	115271
L655	060716	L737	065432	MAST13	064200	MSG015	112134	MSG072	115304
L656	060734	L74	011274	MAST14	064204	MSG016	112136	MSG073	115317
L657	060746	L740	065450	MAST15	064472	MSG017	112150	MSG074	115336
L66	011060	L741	065452	MASWR	002674	MSG018	112161	MSG075	115341
L660	061162	L742	065466	MDISPL	002676	MSG019	112164	MSG076	115373
L661	061162	L743	065676	MEMDON	014410	MSG020	112170	MSG077	115414
L662	061656	L744	065704	MEMERR=	177744	MSG021	112224	MSG078	115430
L663	061456	L745	065732	MEMSIZ=	000004	MSG022	113252	MSG079	115474
L664	061504	L746	065750	MHALT1	004532	MSG023	113274	MSG080	115520
L665	061636	L747	065762	MHALT2	005770	MSG024	113316	MSG081	115560

SYMBOL TABLE

SEQ 0558

MSG082	115577	MTPD03	026630	MT0030	024754	O.CT	075730	O.SVR	100360
MSG084	115617	MTPD21	033354	MT0031	025214	O.CTLC	076162	O.SVTT	100500
MSG085	115661	MTPD25	034412	MT0033	025340	O.CTLE	076242	O.T	075572
MSG086	115706	MTPD26	034666	MT0034	025530	O.CTLF	076210	O.TBIT	077644
MSG087	115745	MTPD25	034434	MT0035	025652	O.CI	100000	O.TBT =	000020
MSG088	115760	MTP000	026376	MT020X	023604	O.DCD	076520	O.TCL2	076442
MSG089	115776	MTP001	026422	MT020Y	023472	O.DCDA	077144	O.TCSR=	177564
MSG090	116020	MTP002	026454	MT020Z	023322	O.DCD1	076550	O.TDB =	177566
MSG091	116034	MTP005	026724	MT0999	025772	O.DCD3	076530	O.TL	101345
MSG092	116046	MTP006	026760	MULHLT	056150	O.DOT	075562	O.TRTC	101370
MSG093	116062	MTP007	027150	MULTIE	060746	O.ERR	076510	O.TVEC=	000014
MSG094	116070	MTP010	027250	MULTIO	002004	O.ERR1	077572	O.TYPE	101126
MSG095	116077	MTP011	027356	MULTIP	003014	O.ERR2	077164	O.TYP1	101004
MSG096	116106	MTP012	027766	MULTIU	056142	O.ERR3	077150	O.UIN	075752
MSG097	116137	MTP013	030344	MUT	002116	O.FIL	075576	O.UPC	075700
MSG098	116234	MTP014	030716	MUTBAL	054472	O.FTYP	100730	O.UR0	075662
MSG099	116245	MTP015	031312	NEMCNT	002072	O.GET	101006	O.USP	075676
MSG100	116256	MTP016	031700	NEWBAN	002400	O.GO	077576	O.UST	075702
MSG101	116305	MTP017	032302	NEWKER	042322	O.GOGO	077624	O.WRD	076760
MSG102	116335	MTP020	032360	NEWLOA	042370	O.G02	077676	O.WRD1	077036
MSG103	116364	MTP022	033404	NOBALA=	000164	O.ID	101300	O.WST	101202
MSG104	116421	MTP025	034152	NOCLOC	002104	O.IDND=	101315	O.XXX	075564
MSG105	116423	MTP030	034704	NOECCF	002474	O.LG =	000020	PADDRE	002042
MSG106	116527	MTP031	034714	NOERRO	002530	O.LGCH	101321	PAFBAF	015730
MSG107	116545	MTP033	035054	NOFSMO	002526	O.MIN	076502	PAFBAW	016066
MSG108	116622	MTP034	035106	NOJIST	002756	O.MINS	075603	PARBAF	016246
MSG109	116664	MTP20A	032360	NONEM	002102	O.ODT	075774	PARBAW	016404
MSG110	116737	MTP20B	032376	NONEXI	036646	O.OFST	077466	PARCNT	002074
MSG111	117003	MTP20C	032430	NOPAR	002100	O.OLD	077154	PARITY	036454
MSG112	117035	MTP20D	032462	NOSCOF	002540	O.OP1	077160	PARTHE	002372
MSG113	117103	MTP20E	032514	NOTAB	002464	O.OP2	077220	PARVEC=	000114
MSG114	117113	MTP20F	032546	NULLFL	002436	O.OP2A	077226	PASFLG	002362
MSG115	117123	MTV020	023320	OLDCAC	002370	O.ORAB	076364	PATERR	002076
MSG116	117133	MT0000	021704	OLDMAR	002376	O.ORPC	076342	PATPLU	005472
MST11A	063602	MT0001	021740	ONCE	002732	O.ORRB	076374	PATTER	002120
MTA030	024760	MT0002	022000	ONES	002726	O.OP	075573	PCBUMP	002406
MTEST	016564	MT0003	022050	O.ADR1	075706	O.PRI	075704	PCONF1	035402
MTPA03	026506	MT0004	022216	O.BACK	077302	O.PROC	077732	PCONFS	035662
MTPA04	026650	MT0005	022300	O.BD	101366	O.PR1	077764	PCONF1	035572
MTPA20	032572	MT0006	022360	O.BIAS	075604	O.RALL	077430	PCONF2	035630
MTPA21	033234	MT0007	022414	O.BKP =	000016	O.RCSR=	177560	PDP110	036752
MTPA24	034060	MT0010	022456	O.BKPT	077324	O.RDB =	177562	PENDBO	002330
MTPA25	034464	MT0011	022512	O.BK1	100060	O.REGT	076270	PERA05	064732
MTPA26	034576	MT0012	022570	O.BRK	100042	O.REM	100602	PERBnk	065564
MTPA32	034772	MT0013	022646	O.BW	075566	O.RORA	101272	PERECC	065650
MTPB03	026550	MT0014	022722	O.BYT	076772	O.RRST	101172	PERRAB	065402
MTPB04	026704	MT0015	023000	O.CAD	075560	O.RSB	100450	PERRAW	065330
MTPB21	033264	MT0016	023056	O.CADV	100634	O.RSR	100416	PERRA3	054652
MTPB24	034120	MT0017	023134	O.CLGT=	000024	O.RSTT	100534	PERRA7	065454
MTPB25	034504	MT0020	023156	O.CLSE	101214	O.S	075571	PERR01=	104427
MTPB26	034612	MT0021	023612	O.CMFD	075600	O.SCAN	076554	PERR02=	104430
MTPB32	035020	MT0022	023734	O.CR	101316	O.SCRN	075602	PERR03=	104431
MTPC03	026610	MT0023	023766	O.CRET	077140	O.SEMI	076742	PERR04=	104432
MTPC21	033320	MT0024	024032	O.CRLF	101246	O.SEQ	075570	PERR05	064726
MTPC24	034134	MT0025	024172	O.CRLS	101254	O.SMFD	075601	PERR06	064754
MTPC25	034536	MT0026	024240	O.CSR1	075574	O.SNGL	076446	PERR07=	104433
MTPC26	034646	MT0027	024370	O.CSR2	075575	O.STM =	000340	PERR10=	104434

PERR11=	104435	RESVEC=	000010	START2	000310	TAG73\$	067722	TST2	007004
PERR12=	104436	RLFLAG	002134	START3	000200	TAG74\$	067730	TST3	007160
PERR13=	104437	RRFLAG	002132	START4	000322	TAG75\$	067742	TST4	010310
PERR14=	104440	RTNVAL=	%000000	STOPCP	011720	TAG76\$	067754	TST5	014342
PERR15=	104441	RUNCOU=	000171	STOPOK	002520	TAG77\$	067776	TST6	014414
PERR16=	104442	SAMESA=	000015	STRIPE	002460	TAG78\$	070000	TST7	014456
PERR17=	104443	SAVREG=	104415	STRTDI	002364	TAG79\$	070006	TWDCSR	002600
PERR20=	104444	SBEC SR	002150	SUBAAA	005532	TAG80\$	070066	TYPDS =	104405
PERR21=	104445	SBFLA	002022	SUBAAB	005200	TAG81\$	070100	TYPEIT=	104401
PERR22=	104446	SBEMSK	002350	SUBAAQ	007720	TAG82\$	070122	TYPOC =	104402
PERR23=	104447	SBETES	017374	SUBAAR	013160	TAG83\$	070324	TYPOS =	104403
PERR24=	104450	SCOPE =	000004	SUBAAS	007002	TAG84\$	070410	TYPS0 =	000000
PERR25=	104451	SDPAR0=	172260	SUBAAT	011334	TAG85\$	070502	TYPS1 =	000000
PERR26=	104452	SDPAR7=	172276	SUBAAU	014602	TAG86\$	070612	TYPS10=	000000
PERR27=	104453	SDPDR7=	172236	SUCCESS	002424	TAG9\$	007232	TYPS11=	000002
PERR30=	104454	SECOND=	011661	SUPDOA	002360	TASK	002616	TYPS2 =	000000
PERR31=	104455	SEEDHI	002714	SUPDO1	026042	TASKDO	050726	TYPS3 =	000000
PERR32=	104456	SEEDLO	002716	SUPDO2	026056	TASKRE	050710	TYPS4 =	000000
PERR33=	104457	SELONL	002002	SUPDO3	026220	TASK00	051234	TYPS5 =	000000
PERR34=	104460	SETPAR	043212	SUPDO4	026234	TASK01	051236	TYPS6 =	000000
PERR35=	104461	SETPAT	042762	SUPDRO	002266	TASK02	051330	TYPS7 =	000002
PERR36=	104462	SHALT	004420	SUPDR1	002270	TASK03	051430	T12A	031700
PERR37=	104463	SHUTUP	043554	SUPDR2	002272	TASK04	051664	T12B	031722
PERR40=	104464	SIDE	002422	SUPDR3	002274	TASK05	051774	UDPAR0=	177660
PERR41=	104465	SIDEOK	021066	SUPDR4	002276	TASK06	052300	UDPAR1=	177662
PERR42=	104466	SIPAR0=	172240	SUPDR5	002300	TASK07	052326	UDPAR7=	177676
PERR43=	104467	SIPAR3=	172246	SUPDR6	002302	TASK10	052336	UDPDR7=	177636
PERXOR	065540	SIPDR0=	172200	SUPLIM	057372	TASK11	052536	UIPAR0=	177640
PFLAG	002130	SIZE =	040000	SUPM13	053752	TASK12	052644	UIPAR2=	177644
PHYADD	002044	SIZELO=	177760	SUPSTK=	000740	TASK13	052726	UIPAR3=	177646
PORTCO	002646	SKIPKA	002012	SWAPAT	002764	TASK14	053276	UIPAR4=	177650
PORTDI	002606	SLAVEM	061244	SWR	002766	TASK15	053310	UIPAR5=	177652
PROTEC-	000002	SLAVEN	075774	SWREG =	000176	TASK16	053316	UIPAR6=	177654
PSW	177776	SLAVER	002570	SW0 =	000001	TASK17	053334	UIPAR7=	177656
PTYBUF	002636	SLAVES	002730	SW1 =	000002	TASK20	053422	UIPDR0=	177600
PTYFLA	002626	SLAVE1=	000040	SW10 =	002000	TASK7A	052344	UNITOP	002516
PWLOCK	002760	SLAVE2=	000100	SW11 =	004000	TBG4\$	026314	UNRELO	041604
PWRVEC=	000024	SLAVE3=	000200	SW12 =	010000	TCFIG1	036012	UPPFLG	002363
QUE	072154	SLAVUP	061216	SW13 =	020000	TCONF I	035664	UP2	056154
QUE1	072222	SLFLAG	002656	SW14 =	040000	TEMP	002534	USERMA	042240
QUICK	002536	SLPAT	051570	SW15 =	100000	TESTAD	002506	USESTK=	000700
QVFLAG	002440	SLPAT0	051530	SW2 =	000004	TIME	002434	USP =	%000006
RANODD	034626	SLPAT1	051534	SW3 =	000010	TIMEOU	036726	WAITST	012034
RDCHR =	104411	SLPAT2	051542	SW4 =	000020	TKVEC =	000060	WAIT5	063674
RDDEC	104414	SLPAT3	051550	SW5 =	000040	TMFLAG	002140	WAKEUP	054544
RDLIN =	104412	SLPAT4	051556	SW6 =	000100	TOOMAN	002472	WARN1	007320
RDOCT =	104413	SLPAT5	051564	SW7 =	000200	TRAPVE=	000034	WARN2	026522
RFADCS=	104426	SOBK	002704	SW8 =	000400	TRT =	000003	WARN3	026536
READON	002504	SOBLEN=	000056	SW9 =	001000	TSK05A	052240	WARN4	026562
REALPA	002366	SOFTPA	002744	SYSSIZ	011210	TSK13A	053100	WARN5	026576
REFRES	033760	SOURCE	002402	SYSTID=	177764	TSK13B	053136	WARN6	035364
REFSUB	034030	SPECIA	002432	TAG2\$	007366	TSK20A	053602	WARN7	024416
REGCOP	035204	SSP =	%000006	TAG3\$	007412	TSTBAN	007606	WASDBE=	104500
RELOCA	041130	ST =	177776	TAG4\$	026136	TSTDAT	002344	WASSBE=	104476
RELOC1	041456	STACK =	002000	TAG70\$	067636	TSTRD1	037434	WAS1DB=	104501
RESREG	104416	START	004352	TAG71\$	067646	TSTREA=	104510	WAS1SB=	104477
RESTAR	002752	START1	000300	TAG72\$	067656	TST1	006260	WHICHC	050630

SYMBOL TABLE

WHOBOX	070672	\$DDW6	075234	\$KERNE	037020	\$PER02	064622	\$SWR	= 163000
WHODUN=	000202	\$DEENE	037040	\$KMAP	041016	\$PER03	064650	\$SWREG	075156
WOOPEN	056512	\$DEVCT	075144	\$KS\$	= 000204	\$PER04	064700	\$T	= 001060
WOOPS	056160	\$DEVPM	075212	\$L	= 000212	\$PER07	064762	\$TESTN	075140
WOOPSA	056542	\$DIDDO=	000000	\$LF	003011	\$PER10	065004	\$TKB	002774
WOOPUP	056336	\$DOAGA	015040	\$LL	= 000210	\$PER11	065034	\$TKS	002772
WORST	002712	\$DOAGN	015070	\$LOADC	037076	\$PER12	065054	\$TN	= 000010
WRITEO	002502	\$DOWN	055532	\$LOAD1	037146	\$PER13	065076	\$TPB	003000
XXDPCH	002446	\$DTBL	073002	\$LPADR	002746	\$PER14	065116	\$TPFLG	002452
ZERO	002426	\$ECCDI	037466	\$LPERR	002750	\$PER15	065140	\$TPS	002776
ZEROS	002430	\$ECCIN	037554	\$LS\$	= 000000	\$PER16	065162	\$TRAP	075252
\$APTHD	075236	\$ECC1D	037522	\$MADR1	075166	\$PER17	065202	\$TRAP2	075274
\$AUTO	002066	\$ECC1I	037574	\$MADR2	075172	\$PER20	065220	\$TRPAD	075314
\$BANK	002015	\$ENASE	037612	\$MADR3	075176	\$PER21	065236	\$TSTM	075242
\$BASE	075210	\$ENATS	037646	\$MADR4	075202	\$PER22	065256	\$TSTRD	037310
\$BELL	003003	\$ENDAD	015000	\$MAIL	075134	\$PER23	065274	\$TTYIN	074200
\$CACHF	037066	\$ENERG	037030	\$MAMS1	075164	\$PER24	065312	\$TYPDS	072576
\$CACHN	037050	\$ENV	075154	\$MAMS2	075170	\$PER25	054570	\$TYPE	056752
\$CBCSR	037700	\$ENVM	075155	\$MAMS3	075174	\$PER26	065502	\$TYPEC	057076
\$CB1CS	037742	\$EOP	014662	\$MAMS4	075200	\$PER27	065522	\$TYPEX	057360
\$CDW1	075214	\$ERFLG	002016	\$MBADR	075240	\$PER30	054762	\$TYPOC	072374
\$CDW2	075216	\$ERROR	066662	\$MNEW	074254	\$PER31	065720	\$TYPON	072410
\$CHARC	057356	\$ERRTB	101372	\$MSGAD	075150	\$PER32	066016	\$TYPOS	072350
\$CHKDI	040354	\$ERRTY	067324	\$MSGLG	075152	\$PER33	066064	\$T1	= 000000
\$CHK1D	040410	\$ERTTL	002754	\$MSGTY	075134	\$PER34	066144	\$T2	= 001057
\$CKSWR	073022	\$ESCAP	002454	\$MSWR	074243	\$PER35	066176	\$UNIT	075146
\$CLRCS	040322	\$ETABL	075154	\$MTYP1	075165	\$PWDRN	055160	\$UNITM	075246
\$CLR1C	040340	\$ETEND	075236	\$MTYP2	075171	\$PWUP	055536	\$USWR	075160
\$CMTAG	002000	\$EXHAL	043546	\$MTYP3	075175	\$QUES	003007	\$VECT1	075204
\$CMTGE	002700	\$ES	- 000001	\$MTYP4	075201	\$R	= 177777	\$JECT2	075206
\$CNTLC	074224	\$FATAL	075136	\$NOTRA	075306	\$RAND	074720	\$WASDB	040146
\$CNTLG	074236	\$FILLC	003002	\$NULL	002450	\$RDCHR	073602	\$WASSB	040002
\$CNTLU	074231	\$FILLS	002451	\$NWTST=	000001	\$RDDEC	074436	\$WAS1D	040262
\$CPUOP	075162	\$F\$	= 000000	\$OCNT	072572	\$RDLIN	073722	\$WAS1S	040116
\$CRLF	003010	\$GTSWR	073160	\$OCTVL	075116	\$RDOCT	074266	\$XTSTR	066370
\$DBLK	073012	\$HALT	067136	\$OCTB =	075122	\$READC	037220	\$YS	= 000000
\$DB2O	075014	\$HALT2	075312	\$OMODE	072574	\$RESRE	074662	\$ZAP42	014760
\$DDW0	075220	\$HIBTS	075236	\$OVER	066502	\$SAVRE	074624	\$Z\$	= 000000
\$DDW1	075222	\$HIOCT	074434	\$OS\$	= 000000	\$SAVR6	056140	\$S\$	= 000000
\$DDW2	075224	\$ILLUP	056134	\$PASS	075142	\$SCOPE	066232	\$ST	001040
\$DDW3	075226	\$INVAL	040510	\$PASTM	075244	\$STN =	000001	\$STT	001042
\$DDW4	075230	\$ITEMB	002017	\$PATMA	002014	\$SVLAD	066466	\$OFILL	072573
\$DDW5	075232	\$IS\$	- 000001	\$PER01	064574	\$SV\$	- 000000		

. ABS. 117144 000
000000 001
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 30712 WORDS (120 PAGES)
DYNAMIC MEMORY: 21560 WORDS (82 PAGES)
ELAPSED TIME: 01:51:14

CEMKAB.BIC,CEMKAB.LS1/CRF:SYM/-SP,CEMKAB.MLB/ML,CEMKAB.MA1,CEMKAB.MA2

CEMKAB		CREATED BY MACRO ON 1-AUG-79 AT 07:46		PAGE 1		E 12					
SYMBOL	CROSS REFERENCE	VALUE	REFERENCES	CRFF	V01						SEQ 0561
ABORTF	002142	#38-1166	*281-6181	393-570	595-607	*395-625	448-1990	448-1993	448-2002	448-2005	
ACFLAG	002124	#38-1159	71-2036	75-2113	*77-2125	77-2126	81-2210	94-2576	94-2590	102-2754	
		109-2847	111-2863	113-2897	115-2931	117-2972	120-3018	122-3060	124-3109	126-3151	
		131-3240	169-4136	169-4159	171-4190	313-6654	*324-6878	*324-6889	351-7479	353-7533	
		357-7682	389-466	412-1076	420-1252	423-1317	425-1377	427-1425	429-1467	433-1534	
		437-1623	439-1684								
ACK	002672	#40-1308	*45-1404	45-1410	*89-2385	90-2424	90-2431	*90-2440	*90-2479		
ACTFLA	002442	#38-1239	*52-1534	65-1826	69-2022	149-3655	149-3668	158-3888	158-3897	158-3905	
		158-3915	160-3926	160-3935	162-3950	162-3989	162-3995	162-4002	162-4008	165-4091	
		179-4326	335-7055	460-2263							
		102-2751	#102-2768								
ADDPAR	014570	#38-1134	*65-1820	*79-2174	*206-4742	*206-4756	*209-4814	*209-4828	*212-4901	*283-6213	
ADDRES	002040	*385-408	*385-416	*393-569	*393-569	*393-591	*395-606	*395-606	395-609	395-619	
		*445-1883	*445-1884	*445-1889	*445-1890	*445-1895	*445-1896	*445-1901	*445-1902	*445-1909	
		*445-1917	*445-1922	*445-1922	*445-1927	*445-1932	*447-1938	*447-1943	*447-1948	*447-1953	
		*447-1958	*447-1963	*447-1968	*447-1973	*447-1978	*447-1983	*452-2053	*454-2083	*454-2092	
		468-2434	477-2631	477-2633	477-2633	477-2635	477-2635	477-2638	477-2640	477-2640	
		477-2642	477-2642	560-4700	560-4703	560-4706	560-4708	560-4713	560-4721		
ADD..0	071152	#475-2604	#477-2629								
ADD..1	071162	475-2605	#477-2631								
ADD..2	071202	475-2606	#477-2633								
ADD..3	071232	475-2607	#477-2635								
ADD..4	071262	475-2608	#477-2637								
ADD..5	071264	475-2609	#477-2638								
ADD..6	071304	475-2610	#477-2640								
ADD..7	071334	475-2611	#477-2642								
ALLCPU	002510	#38-1261	*90-2496	94-2572	389-463	*414-1113	*414-1115	*414-1116	420-1249	423-1314	
		425-1374	427-1422	429-1464	433-1529	437-1620	439-1681				
APT COR	002522	#38-1266	*98-2686	98-2694	560-4705						
APTDOW	043640	52-1529	#335-7085	335-7088	*335-7090						
APTFLA	002444	#38-1240	*52-1528	54-1547	98-2665	158-3888	158-3897	158-3905	158-3915	160-3926	
		160-3935	162-3950	165-4091	179-4326	335-7055	460-2263				
		92-2558	#107-2832	107-2838							
APTHAN	015050	#335-7092									
APHTLT	043706	#38-1267	*98-2689	98-2694	560-4705						
APT MOS	002524	#38-1275	*52-1524	98-2665							
APTSIZ	002544	154-3840	154-3851	156-3870	164-4025	165-4070	#270-5940	331-7015			
BACKGN	035344	#38-1140	*79-2176	*90-2447	*90-2484	*98-2703	*385-407	*385-415	*389-484	*389-530	
BAD	002056	*393-572	*393-594	*395-609	*395-623	*408-975	*408-1018	*410-1050	*412-1084	*412-1098	
		*420-1267	*420-1289	*423-1331	*423-1353	*425-1403	*427-1444	*429-1480	*435-1591	*435-1605	
		*437-1638	*439-1703	*441-1728	*445-1885	*445-1891	*445-1898	*445-1903	*445-1908	*445-1918	
		*445-1923	*445-1928	*445-1933	*447-1939	*447-1944	*447-1949	*447-1954	*447-1959	*447-1964	
		*447-1969	*447-1974	*447-1979	*447-1984	450-2031	*452-2054	*454-2084	*454-2093	*454-2094	
		*454-2113	474-2567	474-2570	474-2573	474-2576	560-4700	560-4706	560-4708	560-4716	
		560-4720	560-4721	560-4723	560-4725						
BADCSR	002000	#38-1115	470-2475	*475-2597	*475-2598						
BADPC	002026	#38-1129	*283-6240	393-583	448-1991	448-2003	450-2014	452-2064	454-2082	454-2091	
		454-2102	459-2234	459-2235	*459-2239						
BADPSW	002036	#38-1133	*283-6241	454-2113	459-2238						
BADSP	002032	#38-1131	*283-6238	*283-6239	459-2237						
BADSTA	036770	281-6182	281-6196	283-6223	283-6227	283-6230	#283-6237	393-583	445-1911	448-1991	
		448-2003	450-2014	452-2064	454-2082	454-2091	454-2102	454-2112			

CEMKAB
SYMBOL
SYMBOL
BADXOR
BAD2
BAD3
BAFPAF
BAFPAF
BAFPAF
BANK

CREATED BY MACRO ON 1-AUG-79 AT 07:46
CROSS REFERENCE
VALUE

REFERENCES

PAGE 2
CREF V01

		#38-1143	*450-2031	*450-2032	560-4706								
		#38-1141	*393-595	560-4716									
		#38-1142	*393-597	*393-598	560-4716								
		99-2716	#111-2859	111-2888									
		99-2717	#113-2893	113-2922									
		#42-1342	*47-1451	164-4024	165-4069								
		#38-1152	*67-1842	*67-1849	67-1850	67-1852	67-1858	*67-1873	*69-1961	69-1962			
		69-1967	*69-2018	69-2018	*69-2020	*71-2034	*71-2042	71-2042	*75-2111	*75-2116			
		75-2116	75-2118	*77-2124	77-2126	*77-2127	77-2131	*81-2208	*81-2215	81-2215			
		*81-2216	81-2219	*94-2564	*94-2622	*102-2752	*102-2761	102-2761	*109-2845				
		*109-2853	109-2853	*111-2860	*113-2894	*115-2928	*117-2969	*120-3013	*122-3055	*124-3104			
		*126-3146	131-3228	*131-3238	131-3241	*131-3264	131-3264	*131-3279	*169-4134	169-4138			
		*169-4150	169-4150	*169-4157	169-4160	*169-4173	169-4173	*171-4187	*171-4196	171-4196			
		*171-4206	173-4224	175-4244	177-4282	177-4303	182-4335	185-4369	302-6520	*313-6652			
		313-6655	*313-6665	313-6665	317-6725	*317-6726	*317-6730	*317-6734	324-6880	*327-6943			
		327-6944	344-7232	*344-7237	*344-7241	344-7244	344-7250	*344-7265	346-7271	*346-7276			
		*346-7280	346-7283	346-7289	*346-7317	348-7323	*348-7329	348-7330	348-7332	348-7360			
		*348-7435	348-7436	351-7448	*351-7477	351-7481	*351-7488	351-7488	*351-7491	353-7497			
		*353-7531	*353-7537	353-7537	*353-7544	353-7545	355-7551	*355-7561	*355-7565	355-7568			
		355-7587	*355-7613	355-7614	*355-7619	*355-7624	355-7625	*355-7633	*355-7639	355-7639			
		*355-7641	357-7646	*357-7680	*357-7686	357-7686	*357-7693	357-7694	367-68	367-83			
		*367-83	369-103	*369-103	371-147	*371-147	373-166	*373-166	373-168	375-234			
		*375-234	377-265	*377-265	379-305	*379-305	379-308	381-351	383-372	*383-372			
		383-374	385-388	*385-388	385-390	387-435	*389-462	389-467	389-477	*389-519			
		389-518	403-796	*403-797	403-798	*403-816	405-833	*405-834	405-835	*405-848			
		407-930	*412-1074	*412-1097	412-1097	*414-1167	*414-1171	414-1171	*414-1174	*420-1248			
		*420-1299	420-1299	*423-1313	*423-1363	423-1363	*425-1373	*425-1412	425-1412	*427-1421			
		*427-1453	427-1453	*429-1463	*429-1501	429-1501	*433-1528	*433-1571	433-1571	*437-1619			
		*437-1658	437-1658	*439-1680	*439-1711	439-1711	452-2040	457-2177	466-2382	466-2406			
		468-2436	475-2599	475-2599	489-3021								
BANK IN	002110	#38-1153	*64-1741	64-1742	*64-1762	*67-1854	67-1902	*69-1964	69-2007	81-2220			
		94-2566	313-6660	317-6728	317-6732	*324-6882	412-1092	414-1169	414-1176	433-1532			
BANKMO	042072	81-2226	107-2830	313-6658	317-6723	*319-6767	335-7079						
BANKOK	042730	120-3016	122-3058	124-3107	126-3149	*327-6918							
BAWPAF	015434	99-2718	#115-2927	115-2955	115-2963								
BAWPAR	015572	99-2719	#117-2968	117-2996	117-3004								
BDSWIT	002500	#38-1257	*79-2183	560-4708									
BEGIN	005752	45-1414	47-1454	47-1455	#58-1618								
BGTEST	035110	#269-5862	269-5883										
BIT0	- 000001	#11-315	64-1715	64-1735	79-2190	79-2191	281-6170	285-6254	285-6258	285-6263			
		285-6268	290-6338	290-6340	293-6367	293-6372	293-6377	293-6383	296-6425	296-6427			
		296-6433	296-6436	298-6460	298-6462	298-6473	298-6475	315-6711	315-6713	317-6743			
		317-6745	340-7179	344-7246	346-7285	355-7570	359-7723	359-7729	375-221	385-423			
		385-429	395-620	395-628	470-2482	474-2548							
BIT1	- 000002	#11-314	79-2191	79-2195	102-2768	133-3295	139-3425	293-6355	293-6361	293-6377			
		293-6383	293-6390	293-6397	300-6489	300-6496							
BIT10	- 002000	#11-305	77-2147										
BIT11	- 004000	#11-304	67-1909	67-1928	89-2399	276-6016	313-6673	324-6904	395-621	395-627			
		408-1007	416-1202	452-2042									
BIT12	- 010000	#11-303	60-1651	60-1652	60-1658	64-1747	64-1751	69-2008	94-2593	139-3434			
		278-6140	313-6678	313-6678	324-6883	481-2717	481-2718	481-2734					
BIT13	- 020000	#11-302	60-1651	60-1658	64-1744	64-1751	69-1966	96-2631	96-2632	139-3435			

EMKAB SYMBOL	CREATED BY	MACRO	ON	DATE	TIME	PAGE	CREF	V01	G 12		SEQ
SYMBOL	CROSS REFERENCE VALUE	REFERENCES									0563
BIT14	= 040000	#11-301	177-4309	278-6118	302-6522	313-6662	313-6676	313-6677	313-6692	317-6733	
		96-2631	317-6737	333-7047	361-7770	412-1094	481-2717	481-2734			
		250-5564	36-1089	64-1745	67-1868	67-1881	67-1898	67-1920	69-1966	69-1969	
		319-6807	96-2632	135-3332	146-3630	173-4225	175-4251	177-4284	182-4357	185-4391	
		365-22	250-5565	290-6345	290-6347	313-6676	313-6677	315-6699	317-6740	319-6791	
		373-169	324-6910	335-7087	344-7251	346-7291	346-7309	355-7602	361-7756	361-7769	
		383-375	365-30	365-59	367-67	367-81	369-101	371-146	371-158	373-165	
		395-608	373-190	375-232	377-263	377-280	379-304	379-312	379-333	383-371	
		#11-300	385-387	385-398	387-441	387-452	389-468	389-496	393-571	393-593	
		135-3349	395-622	398-670	398-674	401-756	401-760	403-799	405-836	407-925	
		298-6449	56-1579	56-1580	56-1603	81-2206	81-2221	83-2274	83-2285	83-2298	
		319-6807	135-3361	135-3364	135-3368	162-3979	288-6284	288-6295	290-6337	290-6347	
		416-1189	313-6661	313-6673	313-6674	315-6699	315-6706	317-6729	317-6740	319-6791	
		#11-313	324-6898	365-60	379-306	398-670	401-760	412-1093	414-1170	414-1177	
		300-6489	416-1217	454-2103	457-2190	468-2439	470-2478				
		477-2640	79-2190	79-2192	83-2296	139-3425	281-6185	285-6268	293-6390	293-6397	
		#11-312	300-6496	340-7179	359-7723	439-1670	477-2631	477-2633	477-2635	477-2638	
		285-6268	477-2642	77-2150	79-2193	79-2194	90-2456	139-3424	139-3428	278-6114	
		340-7179	64-1752	293-6356	293-6378	293-6384	293-6391	293-6398	300-6490	300-6497	
		#11-311	359-7723	433-1533	439-1670	477-2633	477-2635	477-2640	477-2642		
		135-3368	64-1768	64-1769	79-2192	79-2194	90-2434	90-2468	107-2826	135-3349	
		470-2478	290-6337	296-6414	296-6434	410-1038	412-1070	414-1113	414-1116	454-2103	
		#11-310	52-1520	62-1679	79-2195	79-2196	107-2826	315-6702	315-6710	317-6747	
		317-6750	333-7038	335-7081							
		#11-309	79-2196	79-2197	273-5960	273-5993	348-7373	348-7430	351-7467	351-7473	
		353-7523	353-7542	355-7596	355-7611	357-7672	357-7691	373-177			
		#11-308	52-1523	79-2193	79-2197	273-5959	348-7372	351-7466	353-7522	355-7595	
		357-7671	363-7777								
		#11-307	64-1715	64-1746	89-2374	285-6268	340-7179	359-7723	385-423	385-429	
		#11-306	146-3647	146-3648	285-6254	285-6258	285-6268	315-6711	315-6713	317-6743	
		317-6745	340-7179	359-7723	375-221	470-2482	474-2548				
		67-1846	83-2286	102-2751	152-3786	152-3795	152-3806	154-3826	154-3843	154-3854	
		162-3982	162-3987	162-3993	162-4000	162-4006	162-4012	164-4031	164-4034	164-4038	
		164-4041	165-4077	167-4110	167-4115	169-4129	171-4184	175-4258	177-4306	240-5406	
		270-5945	290-6323	#337-7102	369-133	375-237	375-243	377-292	377-295	379-302	
		385-386									
		#337-7107	373-170								
		154-3822	154-3827	154-3828	154-3844	154-3855	165-4078	165-4079	167-4111	167-4112	
		173-4226	177-4285	315-6700	317-6741	319-6792	319-6808	#337-7111	403-802	403-805	
		#38-1164	81-2210	115-2933	117-2974	122-3062	126-3153	313-6654	*324-6879	*324-6906	
		*324-6909	412-1076								
		#333-7024	487-2972	490-3092	508-3689						
		333-7033	#333-7039								
		#269-5863	269-5867	269-5901							
		#42-1315	285-6262	340-7179	*359-7723	*359-7729	439-1670	439-1670			
		#9-193	65-1810	67-1867	67-1880	67-1897	67-1919	69-1957	75-2083	83-2255	
		92-2513	131-3249	135-3333	146-3631	182-4359	185-4393	250-5528	288-6290	290-6314	
		290-6332	338-7134	359-7724	365-10	369-141	371-155	373-183	373-187	#375-257	
		385-419	407-910	408-951	483-2757						
		#9-192	47-1475	65-1813	67-1871	67-1884	67-1901	67-1924	69-2028	75-2107	

EMKAB SYMBOL	CROSS REFERENCE VALUE	MACRO ON 1-AUG-79 AT 07:46	REFERENCES	PAGE 4 CREF	V01	H 12					SEQ 0564	
			90-2508	92-2530	131-3257	135-3372	135-3379	146-3645	182-4361	185-4395	248-5504	
			359-7730	397-645								
			#11-330	11-331								
CACHVE	= 000114		#9-236									
CBCSR	= 104474		#9-237	146-3629	206-4716	209-4802	212-4893	217-4966	220-5044	223-5121	260-5709	
CBTCR	= 104475		#38-1223	*146-3627	293-6389	293-6396	*305-6551	560-4713				
CHECK	002404		#9-244	69-1971	69-1980	69-1988	69-1996					
CHKDIS	= 104504		206-4705	209-4793	212-4882	217-4954	220-5031	223-5109	258-5649	#305-6528		
CHKGEN	040540		305-6538	#307-6556								
CHKTAB	040640		#9-245	236-5291	236-5312	236-5320	238-5335	238-5356	238-5365	240-5381	240-5400	
CHK'DI	= 104505		393-585									
CKEND	073316		487-2953	487-2955	487-2957	#487-2986						
CKSWR	- 104410		#9-175	456-2134	459-2214	460-2255	483-2755					
CLRCR	= 104502		#9-242	69-1974	69-1983	69-1991	69-1999	69-2013	#149-3658	169-4128	171-4199	
			#348-7386	#351-7453	#353-7514	#355-7557	#357-7663	369-132	375-254			
CLRTCS	= 104503		#9-243	133-3293	135-3341	135-3359	135-3375	146-3634	146-3643	162-3981	162-4014	
			206-4688	206-4733	206-4746	206-4777	209-4785	209-4804	209-4855	212-4862	212-4876	
			212-4895	214-4924	217-4948	217-4970	217-5005	220-5025	220-5046	220-5082	223-5125	
			225-5162	240-5411	258-5684	393-590						
CMD11A	047774		#357-7649	357-7653	357-7657							
CMD11B	050164		#357-7680	357-7688								
CMD11C	050240		357-7668	#357-7690								
CMD20A	050576		361-7746	#361-7768								
CMD5A	045456		#348-7349	348-7353	348-7357							
CMD5B	045666		#348-7381	348-7394								
CMD5C	046052		348-7365	348-7369	#348-7429							
CMD7A	046336		351-7463	#351-7472								
CMD8A	046550		#353-7500	353-7504	353-7508							
CMD8B	046740		#353-7531	353-7539								
CMD8C	047014		353-7519	#353-7541								
CMD9A	047240		#355-7573	355-7577	355-7581							
CMD9B	047456		355-7586	#355-7607								
CMD9C	047464		355-7592	#355-7610								
CMD9LO	047444		355-7585	#355-7603	355-7605	355-7607						
CONFGE	002576		#38-1288	*67-1910	*67-1929	94-2576	*94-2577	94-2617	*94-2618	96-2659		
CONFGT	006666		64-1705	#64-1767								
CONFG1	006304		#64-1707	64-1773								
CONFG3	006520		#64-1742	64-1765								
CONFG5	006712		64-1736	64-1766	#64-1772							
CONFIE	004336		#44-1398	50-1486								
CONFIG	003016		#44-1395	50-1484	*56-1579	*56-1580	*64-1743	*64-1744	*64-1745	*64-1747	*64-1752	
			*64-1756	*64-1761	*65-1822	67-1859	*67-1909	*67-1911	*67-1928	*67-1932	69-1965	
			69-1966	69-1966	*69-2008	*81-2206	*81-2221	94-2571	94-2579	94-2580	94-2581	
			94-2582	94-2591	94-2593	94-2610	96-2630	96-2631	96-2632	96-2632	177-4309	
			*177-4315	276-6016	276-6030	278-6051	278-6058	278-6090	278-6096	278-6113	278-6136	
			278-6140	*302-6522	*313-6661	*313-6662	313-6673	313-6674	313-6675	313-6676	313-6677	
			313-6677	313-6678	313-6678	*313-6692	*317-6729	*317-6733	*317-6737	324-6883	324-6888	
			324-6893	324-6898	324-6904	324-6910	348-7334	355-7628	355-7634	*361-7756	*361-7769	
			*361-7770	*412-1093	*412-1094	*414-1170	*414-1177	433-1533	*452-2042	*452-2044	*452-2046	
			452-2047									
CONFSP	006754		*64-1706	64-1767	#64-1777							
CONFTE	003332		#38-1200	*99-2711	129-3203	*131-3278						

CEMKAB SYMBOL	CROSS REFERENCE VALUE	REFERENCES								
CSRFB	002214	#38-1171 *64-1733 475-2595								
CSRFBA	002410	#38-1225 131-3264 *137-3392 *144-3505 *144-3521 *144-3537 *144-3553 *144-3581 *144-3597								
		*144-3613								
CSRFIR	002336	#38-1207 131-3246 *144-3499 *144-3507 *144-3509 *144-3515 *144-3523 *144-3525 *144-3531								
		*144-3539 *144-3541 *144-3547 *144-3555 *144-3557 *144-3575 *144-3583 *144-3585 *144-3591								
		*144-3599 *144-3601 *144-3607 *144-3615 *144-3617 146-3628 162-3975 162-3999 236-5285								
		348-7323 *348-7382 *348-7433								
CSRINC	002414	#38-1227 131-3261 *144-3501 *144-3511 *144-3517 *144-3527 *144-3533 *144-3543 *144-3549								
		*144-3559 *144-3577 *144-3587 *144-3593 *144-3603 *144-3609 *144-3619 *162-3964 162-3977								
		236-5286								
CSRIND	002416	#38-1228 *131-3229 131-3232 *131-3274								
CSRLB	002234	#38-1172 *64-1738 475-2596								
CSRLBA	002412	#38-1226 131-3238 *137-3393								
CSRLOO	002420	#38-1230 *131-3231 131-3267 *131-3276 131-3276 133-3297								
CSRNO	002256	#38-1174 *64-1703 64-1729 64-1749 *64-1772 64-1773 *77-2138 *77-2161 77-2161								
		*92-2551 *92-2556 92-2556 *133-3292 *162-3958 288-6277 290-6306 290-6325 *296-6410								
		*296-6420 296-6420 *298-6445 *298-6455 298-6455 *302-6507 *302-6513 302-6513 338-7133								
		*340-7178 351-7448 *351-7491 *363-7779 *363-7791 397-648 *398-681 *398-688 398-688								
		*400-736 *400-743 400-743 *401-776 470-2474 *470-2475 *470-2495 475-2588 *475-2625								
		479-2682 *479-2687 *479-2697 *479-2697 *479-2699 560-4709								
CSROUD	002417	#38-1229 *131-3230 *131-3275 133-3287								
CSROUT	040442	293-6358 293-6369 293-6380 293-6393 300-6481 300-6492 #302-6503								
CSREL	002254	#38-1173 *60-1640 *60-1645 288-6278 290-6307 290-6326								
CSRO	002154	#38-1169 *64-1731								
CSR2	002174	#38-1170 *64-1732 475-2600								
DATBUF	002340	#38-1208 *198-4553 *198-4554 198-4555 198-4556 198-4558 198-4563 198-4567 *198-4569								
		*198-4569 *198-4572 *198-4573 198-4574 198-4575 198-4577 198-4582 198-4586 *198-4588								
		*198-4588 *206-4690 *206-4691 206-4696 206-4697 206-4765 *206-4767 *206-4767 *209-4786								
		*209-4787 209-4790 209-4791 209-4847 *209-4849 *209-4849 *212-4864 *212-4865 212-4870								
		212-4871 *217-4936 *217-4937 217-4942 217-4943 *220-5013 *220-5014 220-5019 220-5020								
		*223-5092 *223-5093 223-5098 223-5099 445-1919 445-1924								
DBFMSK	002354	#38-1211 *212-4868 *212-4869 212-4877 212-4879 212-4887 212-4889 214-4906 *214-4908								
		*214-4908 *217-4940 *217-4941 217-4949 217-4951 217-4959 217-4961 217-4987 *217-4989								
		*217-4989 *220-5017 *220-5018 220-5026 220-5028 220-5036 220-5038 220-5064 *220-5066								
		*220-5066 *223-5096 *223-5097 223-5104 223-5106 223-5114 223-5116 225-5144 *225-5146								
DDISP	177570	#11-265 42-1347 50-1497								
DECMAR	043152	113-2907 117-2984 124-3117 126-3161 #329-6976								
DEENER	= 104421	#9-188 60-1648 333-7037 335-7080								
DETAIL	071364	464-2360 #477-2645 477-2674								
DETFLA	002326	#38-1196 460-2262 464-2359 *477-2646 477-2647 477-2649 *481-2749								
DETPSW	002324	#38-1195 560-4710								
DETR0	002306	#38-1188 *477-2654 477-2663 560-4710								
DETR1	002310	#38-1189 477-2655 560-4710								
DETR2	002312	#38-1190 560-4710								
DETR3	002314	#38-1191 560-4710								
DETR4	002316	#38-1192 560-4710								
DETR5	002320	#38-1193 560-4710								
DETPS	002322	#38-1194 560-4710								
DF1	102740	#562-4729								
DF10	103076	550-4513 #562-4738								
DF11	103103	548-4421 550-4488 550-4493 550-4498 552-4520 552-4525 552-4540 556-4649 556-4654								

CEMKAB SYMBOL	CROSS REFERENCE	MACRO	ON	DATE	TIME										
SYMBOL	VALUE	REFERENCES													
DT14	102530	552-4544 #560-4714													
DT16	102556	552-4559 #560-4715													
DT17	102610	552-4564 554-4581 556-4683 #560-4717													
DT18	102616	552-4569 556-4633 556-4638 #560-4718													
DT19	102634	554-4586 #560-4719													
DT2	102264	552-4554 556-4678 #560-4701													
DT20	102652	556-4643 558-4690 #560-4720													
DT21	102662	556-4648 556-4653 #560-4721													
DT22	102700	554-4621 #560-4722													
DT23	102706	556-4663 556-4673 #560-4723													
DT24	102714	556-4668 #560-4724													
DT25	102720	558-4695 #560-4725													
DT3	102302	548-4430 #560-4702													
DT4	102312	548-4435 #560-4703													
DT5	102322	548-4440 548-4445 548-4450 552-4549 #560-4704													
DT6	102346	554-4626 #560-4705													
DT7	102362	550-4462 550-4467 550-4477 550-4482 550-4507 554-4591 554-4596 554-4601 554-4606													
		554-4611 554-4616 #560-4706													
DT8	102416	550-4512 #560-4708													
DT9	102432	554-4576 #560-4709													
DUPPY	002304	#38-1186 560-4701 560-4706 560-4706 560-4707 560-4707 560-4707 560-4707 560-4707 560-4707 560-4707 560-4707													
		560-4707 560-4713 560-4713 560-4715 560-4715 560-4716 560-4716 560-4716 560-4716 560-4716 560-4716 560-4717													
		560-4718 560-4719 560-4721 560-4721 560-4722 560-4725 560-4725 560-4725 560-4725 560-4725 560-4725 560-4725													
ECCDIS =	104470	#9-232 69-2010 149-3656 171-4185 348-7384 351-7451 353-7512 355-7555 357-7661													
ECCINT =	104472	#9-234 65-1795 #65-1829 #69-2025 131-3277 149-3676 171-4202 171-4209 171-4213													
		333-7032 335-7071													
ECC1DI =	104471	#9-233 135-3334 135-3351 146-3640 206-4714 206-4721 206-4774 209-4800 209-4852													
		212-4891 214-4921 217-4964 217-5002 220-5041 220-5078 223-5119 225-5158 240-5409													
		258-5689 260-5697 260-5707													
ECC1IN	104473	#9-235 135-3371 135-3378 258-5654 260-5700													
EMTVEC -	000030	#11-325 *47-1459 *47-1460													
EM1	103134	556-4656 #564-4752													
EM10	103633	548-4453 #564-4762													
EM11	103677	550-4460 550-4465 550-4475 550-4480 #564-4763													
EM12	103721	550-4470 #564-4764													
EM13	103745	550-4485 #564-4765													
EM14	103777	550-4490 #564-4766													
EM15	104043	550-4495 #564-4767													
EM16	104111	550-4500 #564-4768													
EM17	104137	550-4505 #564-4769													
EM18	104177	550-4510 #564-4770													
EM19	104256	552-4517 #564-4771													
EM2	103220	548-4423 #564-4753													
EM20	104333	552-4522 #564-4772													
EM21	104415	552-4532 #564-4773													
EM22	104454	552-4537 #564-4774													
EM23	104501	552-4547 #564-4775													
EM24	104530	548-4418 #564-4776													
EM25	104607	552-4557 #564-4777													
EM26	104634	552-4562 #564-4778													
EM27	104705	554-4579 #564-4779													
EM28	104774	554-4584 #564-4780													

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
EM29		105027	554-4594 #564-4781
EM3		103256	548-4428 #564-4754
EM30		105111	554-4599 #564-4782
EM31		105230	554-4604 #564-4784
EM32		105330	554-4609 #564-4785
EM33		105435	554-4614 #564-4786
EM34		105543	554-4619 #564-4787
EM35		105624	554-4589 #564-4788
EM36		105711	554-4624 #564-4789
EM37		105760	556-4631 #564-4790
EM38		106025	552-4552 #564-4791
EM39		106133	556-4636 #564-4792
EM4		103311	548-4433 #564-4755
EM40		106220	556-4641 #564-4793
EM41		106272	556-4646 #564-4794
EM42		106374	556-4651 #564-4795
EM43		106477	556-4661 #564-4796
EM44		106575	556-4666 #564-4797
EM45		106672	556-4671 #564-4798
EM46		106773	556-4676 #564-4799
EM47		107062	556-4681 #564-4800
EM48		107170	558-4688 #564-4801
EM49		107267	558-4693 #564-4802
EM5		103357	548-4438 #564-4756
EM6		103434	548-4443 #564-4757
EM7		103461	548-4448 #564-4758
EM8		103521	552-4567 #564-4759
EM9		103556	554-4574 #564-4761
ENASBE	=	104506	#9-246 65-1827 69-2023
ENASB	=	104507	#9-247 258-5658 258-5691 260-5702
END		117144	45-1430 #568-4997 568-5007 568-5008
ENERGI	=	104420	#9-187 62-1686 107-2827 416-1215 418-1236
ERRMAX		002702	#42-1316 452-2047
ERROR	-	104000	#11-259 64-1770 65-1817 65-1821 71-2038 79-2184 89-2395 90-2448 90-2485
			92-2521 #94-2583 94-2619 98-2695 98-2704 102-2758 104-2775 209-4815 212-4902
			258-5663 260-5720 260-5731 281-6197 283-6224 283-6228 283-6231 283-6234 298-6472
			340-7193 342-7209 342-7223 365-28 385-409 385-417 389-485 389-511 389-531
			391-550 393-600 408-976 408-1002 408-1019 410-1052 412-1086 412-1099 416-1197
			420-1268 420-1290 423-1332 423-1354 425-1404 427-1445 429-1481 429-1495 435-1592
			435-1606 437-1639 437-1652 439-1704 441-1729 448-1994 #448-1996 448-2006 #448-2008
			450-2017 452-2067 452-2070 452-2073 452-2076 454-2087 454-2098 454-2104 #454-2106
			454-2115 477-2665 477-2671 483-2778
ERRPC	002024		#38-1128 *459-2228 *459-2229 459-2232 *459-2235 *459-2236 459-2241 462-2295 560-4700
			560-4701 560-4702 560-4703 560-4704 560-4705 560-4706 560-4709 560-4711 560-4713
			560-4715 560-4717 560-4718 560-4719 560-4720 560-4721 560-4722 560-4723 560-4724
			560-4725
ERRPSW	002034		#38-1132 *459-2231 *459-2238 477-2662
ERRSP	002030		#38-1130 *459-2230 *459-2237 477-2661
ERRVEC	=	000004	#11-318 *47-1469 *47-1470 456-2152 *456-2153 *456-2155 *456-2159
EVEN	002456		#38-1248 *248-5493 248-5494 *250-5557 250-5557
EXBANK	042422		71-2035 75-2112 77-2128 81-2209 81-2217 94-2565 94-2573 94-2580 102-2753
			109-2846 111-2862 113-2896 115-2930 117-2971 120-3015 122-3057 124-3106 126-3148

CEMKAB
SYMBOL CROSS REFERENCE
SYMBOL VALUE

CREATED BY MACRO ON 1-AUG-79 AT 07:46

PAGE 10
CREF V01

N 12

SEQ 0570

REFERENCES

EXCMD3	044726	131-3239	131-3280	169-4135	169-4158	171-4188	171-4207	313-6653	317-6727	317-6731
EXCMD4	045236	#324-6861	348-7362	348-7437	351-7478	353-7532	353-7546	355-7615	357-7681	357-7695
EXIT	043522	389-464	412-1075	414-1168	414-1175	420-1250	423-1315	425-1375	427-1423	429-1465
EXIT2	043526	433-1530	437-1621	439-1682						
FASTCI =	177640	344-7255	344-7258	344-7262	#344-7264					
FATALS	002070	346-7298	346-7302	#346-7316						
FCMD10	047550	#355-7053	456-2143	460-2265						
FCMD11	047734	#11-378	67-1869	67-1899	83-2291	154-3824	182-4360	240-5410	290-6328	290-6333
FCMD12	050330	337-7103	385-399							
FCMD13	050356	#38-1145	*65-1817	*65-1821	*258-5663	*281-6197	*283-6224	*283-6228	*283-6231	*365-28
FCMD14	050400	460-2263	462-2308							
FCMD15	050420	338-7154	#355-7618							
FCMD16	050436	338-7155	#357-7645							
FCMD17	050454	338-7156	#359-7700							
FCMD18	050470	338-7157	#359-7710							
FCMD19	050502	338-7158	#359-7715							
FCMD20	050566	338-7159	#359-7721							
FIELDS	043774	338-7160	#359-7727							
FIRST =	060000	338-7161	#359-7733							
		338-7162	#361-7739							
		338-7163	#361-7744							
		338-7164	#361-7763							
		#338-7124	487-2940	510-3699						
		#13-556	67-1862	67-1891	67-1917	69-1959	69-1970	69-1970	*69-2014	*69-2014
		102-2749	144-3499	144-3507	144-3509	144-3515	144-3523	144-3525	144-3531	144-3539
		144-3541	144-3547	144-3555	144-3557	144-3575	144-3583	144-3585	144-3591	144-3599
		144-3601	144-3607	144-3615	144-3617	152-3783	152-3791	152-3804	154-3815	154-3841
		154-3852	156-3871	164-4030	165-4074	167-4107	169-4139	169-4162	171-4192	173-4226
		173-4231	173-4232	175-4248	175-4264	175-4268	177-4285	177-4288	177-4289	177-4290
		177-4291	177-4299	228-5174	240-5407	248-5506	250-5527	250-5561	250-5563	250-5564
		270-5943	*335-7088	*335-7089	*335-7090	344-7245	346-7284	348-7382	351-7482	355-7569
		365-23	365-31	365-33	365-35	*365-60	367-68	367-82	367-83	367-86
		369-102	369-103	369-106	371-147	371-151	*371-159	373-166	373-170	373-179
		373-181	*373-191	375-233	375-234	375-238	375-246	377-264	377-265	377-281
		377-291	379-305	*379-306	379-310	379-313	379-319	*381-350	*381-352	383-372
		383-376	383-377	385-388	385-391	385-392	385-408	385-416	387-436	*389-469
		389-494	389-514	*391-558	403-800	403-801	403-802	*403-803	*403-804	403-805
		403-807	*405-837	*405-838	405-843	407-926	*407-928	*407-929	425-1381	425-1384
		468-2435								
FIRSTB	002260	#38-1175	64-1733	64-1734	64-1739	*64-1763	64-1764	137-3392	*139-3438	139-3439
		139-3441	*139-3441	144-3505	144-3521	144-3537	144-3553	144-3581	144-3597	144-3613
		*475-2595	475-2599							
FLIPLO	002734	#42-1329	*47-1445	154-3831	*270-5915	*270-5916	270-5917	270-5919	270-5921	
FLIPWA	035214	154-3814	#270-5913							
FLUSH	014656	#104-2784	414-1184							
FSCMD0	044170	#338-7144	#340-7169							
FSCMD1	044256	338-7145	#340-7187							
FSCMD2	044346	338-7146	#342-7202							
FSCMD3	044520	338-7147	#344-7231							
FSCMD4	044764	338-7148	#346-7270							
FSCMD5	045274	338-7149	#348-7322							

CEMKAB SYMBOL	CROSS REFERENCE VALUE	REFERENCES								
FSCMD6	046152	338-7150	#348-7440							
FSCMD7	046160	338-7151	#351-7447							
FSCMD8	046510	338-7152	#353-7496							
FSCMD9	047104	338-7153	#355-7550							
FSINF	002542	#38-1274	*107-2797	144-3568	*144-3569					
FSPAT	045752	348-7392	#348-7396							
FSSTAC	002374	#38-1219	*340-7189	340-7197	*342-7204	342-7226	*348-7325	348-7429	*351-7468	351-7472
		*353-7498	353-7541	*355-7552	355-7610	*357-7647	357-7690			
FS1	044052	#338-7136	338-7142	338-7166						
FS7FLA	002546	#38-1276	169-4152	*351-7449	*351-7490					
GBLENG	= 000076	177-4285	177-4288	#269-5902						
GDSWIT	002476	#38-1256	*79-2179	560-4708						
GETDAT	055030	#395-614	448-1990	448-2002						
GETDA1	055156	*395-616	395-626	#395-631						
GETDIS	066514	182-4336	185-4370	456-2172	#457-2176	459-2217				
GETSIZ	017736	64-1727	137-3391	#139-3421						
GOOD	002050	#38-1137	*64-1769	*79-2175	*98-2702	*385-406	*385-414	*393-576	*393-578	*393-592
		*395-605	*445-1886	*445-1892	*445-1897	*445-1904	*445-1907	*445-1914	*445-1919	*445-1924
		*445-1929	*445-1934	*447-1940	*447-1945	*447-1950	*447-1955	*447-1960	*447-1965	*447-1970
		*447-1975	*447-1980	*447-1985	450-2030	*452-2056	*452-2058	*454-2085	*454-2095	*454-2114
		560-4700	560-4706	560-4708	560-4715	560-4720	560-4721			
GOOD2	002052	#38-1138	*450-2020	*450-2024	560-4715					
GOOD3	002054	#38-1139	*450-2021	*450-2025	560-4715					
GTSWR	- 104407	#9-174	62-1667							
HEADER	002724	*42-1325	*47-1446	*102-2734	*102-2736	*109-2848	*109-2851	*129-3197	*129-3210	*131-3252
		*206-4741	*206-4744	*206-4755	*206-4758	*209-4813	*209-4816	*209-4827	*209-4830	*212-4900
		*212-4903	*260-5721	*260-5732	*348-7380	*353-7529	*357-7678	*452-2061	*452-2078	*454-2086
		*454-2088	*454-2097	*454-2099	*460-2275	462-2306	462-2318	*464-2357	477-2651	*477-2652
		477-2667	*477-2668	*477-2672						
HIACBA	002514	#38-1263	*77-2124	*77-2131	77-2135	77-2143				
HIADRS	= 177742	#11-336	560-4704	560-4714						
HIBANK	002512	#38-1262	*75-2120							
HIPAT	042762	124-3102	126-3144	#327-6937						
HT	= 000011	#11-269	407-887							
HUNGMS	002572	#38-1286	*90-2441	*90-2445	*90-2477	*90-2482	*410-1044	*410-1048		
HUNGTI	002574	#38-1287	*89-2391	*90-2442	*90-2478	*389-481	*389-527	*408-972	*408-999	*408-1015
		*410-1045	*412-1081	*416-1193	*420-1264	*420-1286	*423-1328	*423-1350	*425-1400	*427-1441
		*429-1477	*435-1602	*437-1635	*439-1700	*441-1725	*483-2785			
I	002602	#38-1290	*54-1568	*54-1574	54-1574	*96-2650	*96-2650	96-2651	*96-2651	96-2653
		*131-3250	131-3254	*131-3256	131-3256	*169-4133	169-4143	169-4146	*169-4151	169-4151
		*169-4156	169-4166	169-4169	*169-4174	169-4174	*379-311	*379-318	379-318	*389-495
		*389-513	389-513	*433-1537	433-1539	*433-1568	433-1568	435-1581	435-1589	435-1591
IISTAC	002736	#42-1330	56-1603	56-1604	83-2274	83-2275	83-2295	89-2392	89-2403	90-2418
		365-18	407-915	408-994	408-1000	416-1189	416-1190	416-1194	416-1209	
IISTAD	002740	#42-1331	56-1608	83-2296	89-2399	89-2404	89-2405	90-2419	90-2420	408-995
		408-996	408-1007	416-1191	416-1192	416-1202	416-1210			
IISTIN	061074	83-2293	#416-1187	416-1208						
IISTOF	061174	89-2402	408-993	#416-1207						
IISTVE	002742	#42-1332	89-2386	90-2464	379-303	379-316	381-341	381-342	381-343	381-343
		381-346	381-347	381-347	383-358	391-563	408-985			
IITRAP	036764	47-1473	90-2464	#283-6233						
INCBK	042772	111-2879	113-2913	115-2949	117-2990	120-3029	122-3073	124-3120	126-3164	#327-6941

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
KIPAR6	=	172354	#11-465
KIPAR7	=	172356	#11-466
KIPDR0	=	172300	#11-439 310-6632 321-6819 397-661 400-725 400-746 405-823 418-1227
K10		002550	#38-1277 81-2233 418-1224
K11		002552	#38-1278
K12		002554	#38-1279
K13		002556	#38-1280
K14		002560	#38-1281
K15		002562	#38-1282
K16		002564	#38-1283
K17		002566	#38-1284
KMAP	=	104422	#9-190 62-1683
KPFLAG		002122	#38-1158 *69-1958 71-2037 81-2211 293-6356 293-6362 293-6378 293-6384 293-6391
KSTACK		002706	293-6398 300-6490 *324-6877 *324-6885
			#42-1318 45-1406 56-1611 *89-2378 89-2379 *90-2471 *90-2507 107-2825 *367-71
			367-73 *408-962 *408-978 *408-990 *408-1004 *408-1021 *408-1028 *412-1105 416-1213
LAST		*57776	481-2707
			#13-557 131-3261 152-3800 162-3980 164-4028 165-4075 175-4249 175-4263 228-5176
			236-5289 248-5507 250-5529 250-5565 265-5805 269-5893 344-7247 346-7286 355-7571
LASTB		002262	375-244 387-437 425-1384
			#38-1176 64-1738 64-1764 137-3393 *139-3431 *139-3434 *139-3435 *139-3439 *139-3440
LASTER		002020	139-3442 *139-3442 *475-2596 475-2599
LF	-	000012	#38-1126 *79-2185 104-2774 *107-2798
LKS	-	177546	#11-270 407-941
LOADBA		002532	#11-266 50-1510 *373-177 *373-184
LOADCS		104425	#38-1270 *313-6656 317-6721 317-6726
LOADHO		002710	#9-195 77-2148 77-2151 92-2554 139-3426 293-6364 293-6374 293-6386 293-6400
			300-6485 300-6499 302-6510 342-7218 400-740
			#42-1319 *81-2219 81-2222 81-2224 107-2828 310-6641 313-6657 317-6722 317-6730
LOADRS	-	177740	335-7078 414-1174
LOCK		002670	#11-335 281-6176 560-4704 560-4714
LOOP		014342	#40-1307 *45-1436 45-1437 *56-1614 *58-1620 58-1621 *77-2157 *83-2287 *83-2299
			*89-2368 *90-2501 90-2502 *335-7082 *408-961 *408-989 *410-1036 *412-1068 *414-1183
			#99-2710 107-2840
LOWMAP		042026	62-1678 315-6709 317-6749 #317-6754 400-722
MAINT	-	177750	#11-339 *62-1672 *102-2768 *129-3196 *169-4127 *171-4182 *331-7012 *333-7034 *335-7072
MAPHO		170202	*348-7378 *353-7527 *355-7600 *357-7676 *369-131 *373-193 *375-253 *383-366 *395-620 *395-628 397-644 *401-780 457-2182 489-3023 560-4714
			#13-484 *62-1677 *315-6708 *317-6748 398-698 *400-721
			#13-544 *62-1675 *75-2084 *75-2091 75-2092 *75-2097 *75-2101 75-2102 *75-2105
MAPH36	=	170372	398-698 *400-721
MAPH37	=	170376	#13-546
MAPLO	=	170200	#13-483 *62-1677 *315-6706 *317-6748 317-6756 398-698 *400-721
MAPL1		170204	#13-485 317-6757
MAPL36	-	170370	#13-543 *62-1676 *75-2085 *75-2090 *75-2096 *75-2100 *75-2106 398-698 *400-721
MAPPER		040700	62-1685 67-1858 69-1967 69-2019 131-3241 173-4224 175-4244 177-4282 182-4335
MARGIN		002112	185-4369 #310-6604 335-7086 344-7250 346-7289 348-7360 348-7436 353-7545 355-7587
			355-7614 357-7694 365-11 365-58 367-75 371-156 373-168 373-188 379-308
			381-349 381-351 383-374 385-390 387-435 389-467 389-477 403-798 405-835
			407-924 407-930
			#38-1154 *111-2869 *115-2939 *120-3022 *122-3066 129-3194 *169-4127 *171-4182 329-6955
			*329-6956 329-6959 *329-6960 329-6961 *329-6963 329-6964 329-6967 *329-6970 329-6972

CEMKAB SYMBOL	CROSS REFERENCE VALUE	REFERENCES	329-6979	*329-6980	329-6981	*329-6983	329-6985	331-6995	*331-6997	*331-6999	*331-7003
			331-7008	331-7009	331-7009	331-7010	348-7323	348-7324	*348-7351	348-7352	348-7352
			348-7355	348-7375	*348-7433	351-7448	*351-7491	353-7497	*353-7502	353-7503	353-7503
			353-7506	353-7525	*353-7544	355-7551	*355-7575	355-7576	355-7576	355-7579	355-7598
			*355-7613	357-7646	*357-7651	357-7652	357-7652	357-7655	357-7674	*357-7693	*369-131
			*373-193	*375-253	*383-367	468-2448					
MASTER	= 000020		#13-561	45-1407	50-1490	58-1625	62-1665	62-1682	81-2205	89-2380	90-2495
			90-2496	90-2506	94-2563	94-2571	94-2574	94-2579	278-6096	310-6640	324-6886
			365-4	379-309	389-465	397-638	410-1051	410-1060	412-1085	414-1112	416-1195
			420-1251	423-1316	425-1376	427-1424	429-1466	433-1531	437-1622	439-1683	456-2135
			487-2931								
MAST01	057372		104-2783	#408-949							
MAST02	060046		#410-1032								
MAST03	060220		#412-1064								
MAST04	061322		414-1118	#420-1241							
MAST05	061706		414-1123	#423-1306							
MAST06	062270		414-1128	#425-1369							
MAST07	062550		414-1133	#427-1417							
MAST10	062776		414-1138	#429-1458							
MAST11	063260		414-1143	#431-1506							
MAST12	063732		414-1148	#437-1615							
MAST13	064200		414-1153	#437-1662							
MAST14	064204		414-1158	#439-1666							
MAST15	064472		414-1163	#441-1717							
MASWR	002674		#40-1309	*89-2370	89-2372	90-2494	*408-956	408-958	412-1107		
MDISPL	002676		#40-1310	365-33	*365-33	365-34	*375-222	*389-460	389-461	*408-953	408-954
			*410-1034	*412-1066	412-1067	*414-1179	*420-1243	420-1244	*423-1308	423-1309	*425-1371
			425-1372	*427-1419	427-1420	*429-1461	429-1462	*431-1523	431-1524	*437-1617	437-1618
			*439-1674	439-1675	*441-1719	441-1720	457-2191	457-2191	489-3010	489-3010	489-3012
			99-2715	#102-2729							
MEMDON	014410		#11-337	281-6170	281-6177	*281-6177	281-6184	*281-6184	281-6190	*281-6190	283-6214
MEMERR	- 77744		*283-6214	283-6218	*283-6218	560-4704	560-4709	560-4714			
			#45-1438	45-1439							
MHALT1	004532		#58-1622	58-1623							
MHALT2	005770		#90-2503	90-2504							
MHALT3	012760		#40-1306								
MINDEX	002666		54-1560	151-3730	151-3730	151-3733	#151-3741				
MJPAT	021600		#38-1252	*96-2627	*96-2631	*96-2637	*96-2638	*96-2639	*96-2640	96-2650	96-2655
MJSIZE	002466		98-2694	560-4705							
MJTEST	021512		129-3208	#151-3724							
MKCONT	016664		129-3205	#131-3214	383-362						
MKCSRS	002334		#38-1201	*64-1707	*64-1710	*64-1715	64-1746	92-2548	131-3232	162-3956	296-6407
			298-6442	302-6505	363-7776	398-679	400-733	475-2594	479-2685		
MKCSRT	020124		54-1550	#142-3454							
MKFLAG	002126		#38-1160	71-2036	75-2113	81-2211	94-2569	94-2590	129-3200	171-4189	*324-6877
			*324-6897	327-6924	329-6964	329-6967	331-6996	331-7007	466-2412	470-2473	475-2582
MKPAT	021402		54-1555	149-3664	149-3664	149-3667	#149-3684				
MKSIZE	002470		#38-1253	*96-2628	*96-2633	*96-2641	*96-2642	*96-2643	*96-2644	96-2650	96-2657
			98-2694	560-4705							
MKTEST	021222		109-2849	129-3206	#149-3653						
MK11AD	= 172100		#13-553	60-1638	288-6276	290-6305	290-6324				
MMRO	- 177572		#11-352	*285-6254	*285-6258	*315-6711	*315-6713	*317-6743	*317-6745	*375-221	398-691

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
MMR1		177574	*400-731 403-814 *405-831 560-4704 560-4714
MMR2		177576	#11-353 398-691 *400-731 403-813 *405-830 560-4704 560-4714
MMR3		172516	#11-354 398-691 *400-731 403-812 *405-829 560-4704 560-4714
			*11-355 *62-1671 *62-1679 *107-2826 *315-6702 *317-6747 *317-6750 *333-7038
			*335-7081 398-691 *400-731 403-811 *405-828 560-4704 560-4714
MMTRAP		036740	47-1471 #283-6227
MMVEC		000250	#11-333 *47-1471 *47-1472
MP1		012070	83-2284 83-2294 #87-2319
MP2		012224	#89-2392 89-2400 90-2437
MP3		012716	90-2466 90-2487 #90-2494
MP4		012552	89-2373 #90-2467
MP5		012764	#90-2506
MRLUNSE		053640	#387-434 437-1624
MSEEDH		002720	#42-1323 *47-1447 47-1449
MSEEDL		002722	#42-1324 *47-1448 47-1450
MSG34		113625	*131-3267 #568-4898
MSG87		115753	*92-2536 *92-2540 #568-4957
MSG98		116242	*483-2763 #568-4970
MSGB34		113642	*131-3268 #568-4900
MSG000		111176	56-1582 #568-4839
MSG001		111254	273-5962 #568-4840
MSG002		111336	273-5963 #568-4841
MSG003		111413	273-5964 #568-4842
MSG004		111520	273-5970 #568-4844
MSG005		111626	276-6015 #568-4846
MSG006		111640	497-3467 #568-4847
MSG007		111675	278-6049 #568-4848
MSG008		111707	276-6029 #568-4849
MSG009		111721	278-6089 #568-4850
MSG010		111733	278-6135 #568-4851
MSG011		111745	273-5974 273-5987 #568-4852
MSG012		112033	273-5977 273-5989 #568-4853
MSG013		112130	276-6018 #568-4854
MSG014		112132	273-5986 276-6020 278-6145 459-2222 466-2388 468-2456 #568-4855
MSG015		112134	*133-3297 133-3298 *276-6038 276-6039 *278-6056 *278-6077 278-6078 *278-6094 *278-6097
			*278-6099 278-6102 *278-6116 *278-6120 *278-6125 278-6126 *278-6138 *278-6142 278-6143
			*472-2510 *472-2512 472-2514 *472-2530 *472-2532 472-2534 #568-4856
MSG016		112136	278-6112 #568-4857
MSG017		112150	273-5973 273-5976 #568-4858
MSG018		112161	464-2352 468-2454 472-2505 472-2523 479-2692 479-2694 481-2712 481-2726 481-2742
			#568-4859
MSG019		112164	#568-4860
MSG020		112170	338-7126 #568-4861
MSG021		112224	338-7141 #568-4862
MSG022		113252	363-7782 #568-4885
MSG023		113274	342-7211 #568-4886
MSG024		113316	342-7214 #568-4887
MSG025		113340	340-7196 342-7225 #568-4888
MSG026		113371	338-7136 #568-4889
MSG027		113403	342-7207 #568-4890
MSG028		113420	342-7221 #568-4891
MSG029		113434	344-7234 #568-4892

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES						
MSG030		113454	348-7327	361-7749	#568-4893				
MSG031		113473	344-7235	346-7274	355-7559	#568-4894			
MSG032		113533	344-7257	346-7297	#568-4895				
MSG033		113552	344-7261	346-7301	#568-4896				
MSG034		113571	131-3269	#568-4897					
MSG035		113707	107-2803	#568-4902					
MSG036		113712	346-7273	#568-4903					
MSG037		113731	346-7304	#568-4904					
MSG038		113750	346-7313	#568-4905					
MSG039		113766	346-7306	#568-4906					
MSG040		114010	348-7326	#568-4907					
MSG041		114055	348-7335	#568-4908					
MSG042		114102	348-7339	#568-4909					
MSG043		114123	348-7344	#568-4910					
MSG044		114150	348-7349	353-7500	355-7573	357-7649	#568-4911		
MSG045		114175	348-7356	353-7507	355-7580	357-7656	#568-4912		
MSG046		114231	348-7368	351-7462	353-7518	355-7591	357-7667	#568-4913	
MSG047		114264	351-7489	#568-4914					
MSG048		114303	338-7129	#568-4915					
MSG049		114343	348-7364	#568-4916					
MSG050		114375	351-7455	#568-4917					
MSG051		114503	401-778	#568-4919					
MSG052		114523	351-7459	#568-4920					
MSG053		114554	351-7461	#568-4921					
MSG054		114572	351-7476	#568-4922					
MSG055		114642	353-7499	#568-4923					
MSG056		114663	353-7516	357-7665	#568-4924				
MSG057		114716	475-2585	*475-2621	475-2623	*475-2624	#568-4925		
MSG058		114722	479-2683	#568-4926					
MSG059		114766	355-7553	#568-4927					
MSG060		115016	355-7589	#568-4928					
MSG061		115060	468-2428	#568-4929					
MSG062		115067	491-3191	491-3250	#568-4930				
MSG063		115107	491-3192	#568-4931					
MSG064		115120	491-3193	491-3252	#568-4932				
MSG065		115130	491-3251	#568-4933					
MSG066		115142	460-2268	#568-4934					
MSG067		115225	462-2310	#568-4935					
MSG068		115234	466-2414	#568-4936					
MSG069		115241	466-2416	#568-4937					
MSG070		115246	96-2654	#568-4938					
MSG071		115271	96-2656	#568-4939					
MSG072		115304	96-2658	#568-4940					
MSG073		115317	357-7648	#568-4941					
MSG074		115336	*470-2472	*470-2493	470-2497	*474-2544	*474-2558	474-2560	#568-4943
MSG075		115341	313-6667	313-6688	#568-4944				
MSG076		115373	355-7630	#568-4945					
MSG077		115414	107-2801	#568-4946					
MSG078		115430	133-3296	#568-4947					
MSG079		115474	355-7621	#568-4948					
MSG080		115520	56-1592	#568-4949					
MSG081		115560	90-2474	#568-4950					

SYMBOL	CROSS REFERENCE VALUE	REFERENCES						
MSG082	115577	90-2476	#568-4951					
MSG084	115617	92-2522	#568-4952					
MSG085	115661	359-7702	#568-4953					
MSG086	115706	92-2534	#568-4954					
MSG087	115745	92-2541	#568-4956					
MSG088	115760	481-2706	#568-4959					
MSG089	115776	481-2721	#568-4960					
MSG090	116020	481-2737	#568-4961					
MSG091	116034	481-2730	481-2746	#568-4962				
MSG092	116046	489-3018	#568-4963					
MSG093	116062	489-3020	#568-4964					
MSG094	116070	489-3022	#568-4965					
MSGC95	116077	489-3027	#568-4966					
MSG096	116106	#568-4967						
MSG097	116137	144-3570	#568-4968					
MSG098	116234	483-2764	#568-4969					
MSG099	116245	483-2774	#568-4972					
MSG100	116256	489-3014	#568-4973					
MSG101	116305	359-7711	#568-4974					
MSG102	116335	359-7716	#568-4975					
MSG103	116364	340-7170	#568-4976					
MSG104	116421	464-2362	#568-4977					
MSG105	116423	361-7745	#568-4978					
MSG106	116527	359-7722	#568-4979					
MSG107	116545	359-7728	#568-4980					
MSG108	116622	359-7734	#568-4981					
MSG109	116664	361-7740	#568-4982					
MSG110	116737	361-7759	#568-4983					
MSG111	117003	361-7764	#568-4984					
MSG112	117035	456-2142	#568-4985					
MSG113	117103	474-2568	#568-4986					
MSG114	117113	474-2571	#568-4987					
MSG115	117123	474-2574	#568-4988					
MSG116	117133	474-2577	#568-4989					
MST11A	063602	433-1567	#435-1575					
MTA030	024760	#171-4181	171-4208					
MTEST	016564	111-2871	113-2905	115-2941	117-2982	120-3024	122-3068	124-3115 126-3159 #129-3193
MTPA03	026506	154-3822	#191-4451					
MTPA04	026650	154-3843	#195-4513					
MTPA20	032572	162-3955	#236-5279					
MTPA21	033234	164-4031	#243-5416					
MTPA24	034060	165-4077	#253-5582					
MTPA25	034464	258-5653	258-5688	260-5696	#260-5707			
MTPA26	034576	167-4110	#263-5738					
MTPA32	034772	#267-5816	377-292					
MTPB03	026550	154-3826	#191-4476					
MTPB04	026704	154-3844	154-3855	#195-4526				
MTPB21	033264	164-4034	#243-5433					
MTPB24	034120	165-4078	#255-5626					
MTPB25	034504	258-5690	260-5698	#260-5714				
MTPB26	034612	167-4115	#263-5745					
MTPB32	035020	#267-5826	377-295					

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
MTPC03		026610	154-3827 #193-4494
MTPC21		033320	164-4038 #243-5450
MTPC24		034134	165-4079 #255-5634
MTPC25		034536	258-5692 260-5701 260-5703 #260-5725
MTPC26		034646	167-4111 #263-5763
MTPD03		026630	154-3828 #193-4503
MTPD21		033354	164-4041 #245-5468
MTPD25		034412	258-5665 258-5667 258-5670 258-5672 #258-5688
MTPD26		034666	167-4112 #263-5776
MTPE25		034434	258-5676 258-5678 258-5681 258-5683 #260-5696
MTP000		026376	67-1846 152-3786 169-4129 177-4306 #188-4413 188-4415 270-5945 369-133
MTP001		026422	152-3795 #188-4424 375-237
MTP002		026454	152-3806 #188-4436 375-243
MTP005		026724	154-3854 #195-4535
MTP006		026760	156-3864 #198-4550
MTP007		027150	156-3874 #201-4594
MTP010		027250	156-3881 #203-4634
MTP011		027356	158-3892 #206-4671
MTP012		027766	158-3901 #209-4782
MTP013		030344	158-3909 #212-4860
MTP014		030716	158-3919 #217-4929
MTP015		031312	160-3930 #220-5010
MTP016		031700	160-3939 #223-5087
MTP017		032302	160-3944 #228-5167
MTP020		032360	#231-5201
MTP022		033404	164-4050 164-4058 #248-5487
MTP025		034152	165-4095 #258-5645
MTP030		034704	171-4184 240-5406 #265-5784
MTP031		034714	173-4226 #265-5790 265-5812
MTP033		035054	175-4258 #267-5839
MTP034		035106	177-4285 #269-5859 269-5902
MTP20A		032360	162-3982 #231-5206 231-5210
MTP20B		032376	162-3987 #231-5214 231-5223
MTP20C		032430	162-3993 #231-5227 231-5236
MTP20D		032462	162-4000 #231-5240 231-5249
MTP20E		032514	162-4006 #233-5254 233-5263
MTP20F		032546	162-4012 #233-5267 233-5274
MTV020		023320	*162-3957 162-3958 *162-3971 162-3971 #162-3973
MT0000		0217C	#152-3781 348-7396
MT0001		021740	149-3688 151-3745 #152-3789 348-7397
MT0002		022000	149-3689 151-3746 #152-3798 348-7398
MT0003		022050	151-3747 #154-3811 348-7399
MT0004		022216	149-3690 151-3748 #154-3836 348-7400
MT0005		022300	149-3691 151-3749 #154-3847 348-7401
MT0006		022360	142-3454 #156-3860 348-7402
MT0007		022414	149-3687 151-3744 #156-3867 348-7403
MT0010		022456	142-3455 #156-3877 348-7404
MT0011		022512	142-3457 #158-3886 348-7405
MT0012		022570	142-3458 #158-3895 348-7406
MT0013		022646	142-3459 #158-3904 348-7407
MT0014		022722	142-3460 #158-3913 348-7408
MT0015		023000	142-3461 #160-3924 348-7409

CEMKAB SYMBOL	CROSS REFERENCE VALUE	REFERENCES	*102-2750	*102-2762	*131-3251	*149-3660	*149-3677	*151-3726	*151-3734	*158-3910
		*81-2228	*102-2750	*102-2762	*131-3251	*149-3660	*149-3677	*151-3726	*151-3734	*158-3910
		*162-3954	*171-4183	*173-4223	*175-4243	*177-4281	*258-5650	*258-5685	281-6168	281-6179
		281-6187	281-6192	344-7232	*344-7233	*344-7265	346-7271	*346-7272	*346-7317	*348-7388
		*348-7393	353-7497	*353-7544	355-7551	*355-7584	*355-7613	357-7646	*357-7693	
NOSCOPI	002540	*38-1273	*164-4022	*164-4043	*165-4067	*165-4088	*171-4186	*171-4203	*171-4214	*173-4221
		*173-4234	*175-4241	*175-4270	*177-4279	*177-4294	*367-77	*408-952	*414-1183	456-2145
		460-2256								
NOTAB	002464	*38-1251	278-6079	*466-2384	*466-2386					
NULLFL	002436	*38-1237	*179-4322	331-7007	*331-7020					
OLDCAC	002370	*38-1217	*288-6289	288-6297	*290-6313	290-6317	*290-6331	290-6334		
OLDMAR	002376	*38-1220	*329-6955	*329-6959	*329-6979	*331-6995	331-7008	331-7009	331-7009	*348-7324
ONCE	002732	*42-1328	56-1581	56-1591	*56-1613					
ONES	002726	*42-1326	45-1407	67-1895	69-1981	69-1982	94-2579	94-2580	94-2581	94-2582
		135-3354	135-3356	154-3839	248-5496	248-5498	270-5924	270-5929	331-7014	365-14
		365-27	416-1191	416-1192	416-1210	447-1945	477-2631	477-2633	477-2635	477-2638
		477-2640	477-2642							
O.ADR1	075706	*506-3633	522-3944	522-3949	522-3953	*522-3961	*522-3968	530-4089	*532-4105	532-4121
		536-4158	536-4159	536-4193						
O.BACK	077302	516-3831	*522-3929							
O.BD	101366	530-4096	530-4097	*546-4399						
U.BIAS	075604	*504-3613	514-3816							
O.BKP	000016	*501-3573	506-3634	506-3636	506-3638	522-3949	522-3953	522-3959	522-3966	526-4011
		528-4051	530-4065	530-4088	532-4104	536-4157	536-4196			
O.BKPT	077324	516-3833	*522-3937							
O.BK1	100060	508-3656	*530-4066							
O.BRK	100042	508-3678	*530-4063							
O.BW	075566	*504-3588	512-3752	*514-3783	*518-3858	*518-3861	518-3872	518-3881	520-3902	520-3909
		520-3912	*520-3913	*520-3916	522-3929	522-3932	524-3979	*524-3997	*524-3999	*532-4119
		538-4206	544-4323							
O.BYT	076772	516-3824	*518-3861							
O.CAD	075560	*504-3585	*512-3738	512-3754	*518-3871	518-3874	518-3877	518-3879	518-3885	*520-3907
		*520-3909	520-3910	520-3914	*522-3932	524-3985	544-4326	544-4328		
O.CADV	100634	518-3880	524-3989	524-3998	*538-4204	546-4348				
O.CLGT	000024	514-3808	*546-4379							
O.CLSE	101214	512-3751	520-3894	520-3904	522-3931	*544-4321				
O.CMFD	075600	*504-3604	*514-3786	514-3814	*518-3850	518-3864				
O.CR	101316	544-4330	544-4332	544-4333	*546-4355					
O.CRET	077140	516-3825	*520-3894							
O.CRLF	101246	520-3911	530-4095	536-4176	*544-4330					
O.CRLS	101254	514-3784	*544-4332							
O.CSR1	075574	*504-3601	*536-4167	536-4183						
O.CSR2	075575	*504-3602	*536-4168	536-4184						
O.CT	075730	*506-3635	*522-3962	*522-3970	*528-4047	*532-4107	*532-4109			
O.CTLC	076162	*508-3685	516-3839							
O.CTLE	076242	*510-3705	516-3841							
O.CTLF	076210	*510-3695	516-3840							
O.C1	100000	*528-4051	532-4108							
O.DCD	076520	512-3766	512-3768	*514-3783	520-3895	532-4123				
O.DCDA	077144	*520-3895	522-3956	522-3963	522-3967					
O.DCD1	076550	514-3775	*514-3790	518-3851						
O.DCD3	076530	*514-3785	518-3882	518-3889	524-4000					
O.DOT	075562	*504-3586	*518-3870	520-3907	*520-3910					

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
O.ERR		076510	512-3757 #514-3781 514-3809 518-3866 520-3897 524-4002
O.ERR1		077572	522-3942 522-3950 522-3954 522-3960 524-3980 524-3984 #524-4002 526-4008 526-4010
			526-4013 528-4039 528-4042 528-4044
O.ERR2		077164	#520-3903 522-3930
O.ERR3		077150	#520-3897 520-3903
O.FIL		075576	#504-3603 *542-4292 *542-4295
O.FTYP		160730	514-3782 518-3884 518-3886 518-3888 520-3921 524-3982 532-4112 532-4116 532-4118
			538-4219 538-4224 #538-4229 538-4230 540-4269 542-4289 542-4294
O.GET		101006	510-3716 514-3792 #540-4250 540-4251 540-4270 540-4274
O.GO		077576	516-3827 #526-4007
O.GOGO		077624	510-3709 #526-4015
O.GO2		077676	526-4022 #526-4025 528-4059
O.ID		101300	508-3663 #546-4350
O.IDND =		101315	508-3664 #546-4354
O.LG =		000020	510-3720 #546-4397
O.LGCH		101321	514-3805 #546-4359 546-4379
O.MIN		076502	#514-3774 516-3838
O.MINS		075603	#504-3611 *514-3774 *514-3787 514-3811 *514-3817
O.ODT		075774	487-2948 #508-3647 510-3700
O.OFST		077466	516-3832 #524-3979
O.OLD		077154	516-3830 #520-3901
O.OP1		077160	516-3828 #520-3902
O.OP2		077220	#520-3910 522-3933
O.OP2A		077226	512-3739 #520-3911
O.ORAB		076364	#512-3740 516-3835
O.ORPC		076342	#512-3734 516-3829
O.ORRB		076374	#512-3743 516-3836
O.P		075573	#504-3598 *508-3654 *508-3676 *526-4011 528-4040 528-4051 *530-4065 *532-4106 532-4113
			532-4120
O.PRI		075704	#506-3629 508-3669 530-4070 530-4074
O.PROC		077732	516-3834 #528-4038
O.PR1		077764	528-4046 #528-4048
O.RALL		077430	508-3679 522-3958 #522-3964
O.RCSR -		177560	#501-3579 536-4167 *536-4169 536-4179 536-4181 *536-4183 540-4250
O.RDB		177562	#501-3578 540-4252
O.REGT		076270	#510-3716 516-3826
O.REM		100602	508-3668 530-4069 #536-4190
O.RORA		101272	520-3915 532-4122 #546-4348
O.RRST		101172	508-3649 #544-4302
O.RSB		100450	526-4024 #536-4157
O.RSR		100416	526-4025 #534-4143
O.RSTT		100534	526-4018 528-4050 #536-4176
O.S		075571	#504-3592 *508-3655 *508-3675 *512-3765 *512-3767 526-4021 528-4053 530-4084 536-4190
O.SCAN		076554	510-3727 #514-3792 514-3803
O.SCRN		075602	#504-3609 540-4260 540-4271
O.SEMI		076742	516-3822 #518-3847
O.SEQ		075570	#504-3591 *520-3901 520-3905 *520-3908
O.SMFD		075601	#504-3606 512-3761 *514-3785 *518-3849 518-3867 526-4007 528-4038
O.SNGL		076446	#512-3761 516-3837
O.STM =		000340	#501-3575 508-3677 526-4016 528-4048 528-4055
O.SVR		100360	508-3661 508-3667 530-4066 #534-4129
O.SVTT		100500	508-3659 530-4094 532-4110 #536-4167

CEMKAB SYMBOL	CREATED BY	CROSS REFERENCE VALUE	MACRO ON 1-AUG-79 AT 07:46	REFERENCES	PAGE 22 (REF V01)	M 13	SEQ 0582
O.T		075572		#504-3597 *526-4019 *528-4057	530-4067		
O.TBIT		077644		#526-4019 528-4052 528-4054	530-4068		
O.TBT	=	000020		#501-3576 526-4020 526-4023	526-4030	528-4058	530-4080
O.TCL2		076442		#512-3757 512-3762			
O.TCSR	-	177564		#501-3581 536-4168 *536-4170	536-4171	536-4177	*536-4184 538-4229
O.TDB	=	177566		#501-3580 *538-4243			
O.TL		101345		510-3717 510-3720 510-3728	#546-4381	546-4397	
O.TRTC		101370		522-3937 522-3965 536-4159	#546-4400		
O.TVEC	=	000014		#501-3574 508-3650 *508-3677	*508-3678		
O.TYPE		101126		508-3665 508-3688 510-3698	510-3707	530-4098	#542-4286 542-4291 542-4297 544-4334
O.TYP1		101004		#538-4244 542-4287			
O.UIN		075752		#506-3637 *522-3969 *536-4158	536-4193		
O.UPC		075700		#506-3627 *508-3653 *526-4015	526-4027	*530-4063	530-4083 *530-4087 *530-4100
O.URO		075662		#506-3620 508-3662 510-3725			
O.USP		075676		#506-3626 508-3685 510-3695	*534-4130	534-4131	534-4150
O.UST		075702		#506-3628 *526-4020 *526-4023	526-4026	526-4029	*528-4058 *530-4064 530-4072 *544-4302
O.WRD		076760		516-3823 #518-3858			
O.WRD1		077036		518-3869 #518-3872	520-3922		
O.WST		101202		508-3651 508-3674 526-4017	526-4031	528-4049	528-4056 530-4082 #544-4312
O.XXX		075564		#504-3587 *534-4129 534-4137	*534-4144	534-4151	
PADDRE		002042		#38-1135 *281-6176 560-4702			
PAFBAF		015730		99-2720 #120-3010 120-3039	120-3047		
PAFBAW		016066		99-2721 #122-3052 122-3083	122-3088	122-3096	
PARBAF		016246		99-2722 #124-3101 124-3130	124-3138		
PARBAW		016404		99-2723 #126-3143 126-3174	126-3179	126-3187	
PARCNT		002074		#38-1147 *65-1803 65-1815	*67-1856	67-1887	67-1905 67-1927 *81-2229 *102-2755
PARITY		036454		102-2757 *281-6173 281-6174	560-4702		
PARTHE		002372		47-1465 #281-6168			
PARVEC		000114		#38-1218 *258-5652 *260-5714	*260-5725	*260-5728	281-6189 344-7232 *344-7248 *344-7265
PASFLG		002362		346-7271 *346-7287 *346-7317	*355-7585		
PATERR		002076		#11-331 *47-1465 *47-1466			
PATPLU		005472		#38-1213 *129-3199 *131-3253	*171-4180	171-4197	*171-4198 206-4698 206-4769 *206-4771
PATTER		002120		212-4872 214-4916 *214-4918	217-4944	217-4997	*217-4999 220-5021 220-5074 *220-5076
PCBUMP		002406		223-5100 225-5154 *225-5156	*348-7381		
PCONF1		035402		#38-1148 67-1848 *67-1855	67-1885	67-1903	
PCONF5		035662		54-1551 54-1553 54-1556	54-1558	54-1561	54-1563 #54-1567
PCONF1		035572		#38-1157 *109-2844 *111-2867	*113-2910	*115-2937	*117-2987 *120-3011 *122-3053 *124-3123
PCONF2		035630		*126-3167 149-3662 151-3728	*327-6932	327-6933	*327-6938 348-7323 *348-7341 348-7342
PDP110		036752		348-7343 348-7390 *348-7435	351-7448	*351-7491	353-7497 *353-7544 357-7646 *357-7693
PENDBO		002330		#38-1224 *149-3661 *151-3727	*154-3813	*154-3838	*154-3849 *156-3862 *156-3879 *167-4102
PERA05		064732		281-6183 348-7323 *348-7389	*348-7433		
PERBANK		065564		96-2660 #273-5953 348-7441			
PERECC		065650		*273-5955 273-5992 #273-5998			
PERRAB		065402		273-5966 #273-5983			
PERRAW		065330		273-5956 273-5981 #273-5992			
				47-1467 #283-6230			
				#38-1197 *64-1708 *64-1735	77-2136	77-2137	
				#445-1908 445-1915			
				393-599 448-1989 448-2001	450-2016	#452-2037	454-2111
				#452-2053 452-2065			
				445-1930 445-1935 #448-2000			
				393-580 395-612 445-1887	445-1893	445-1899	445-1905 445-1920 445-1925 447-1941

CEMKAB SYMBOL	CREATED BY	MACRO	ON	DATE	TIME	PAGE	N	REF	V01	SEQ	0583
SYMBOL	CROSS REFERENCE VALUE	REFERENCES					13				
PERRA3	054652	447-1946	447-1951	447-1956	447-1961	447-1966	447-1976	447-1981	447-1986	#448-1988	
PERRA7	065454	#393-582	450-2022	450-2026							
PERR01	= 04427	447-1971	#450-2013								
PERR02	= 104430	#9-198	188-4432	267-5854							
PERR03	= 104431	#9-199	188-4420	188-4445	267-5848						
PERR04	= 104432	#9-200	193-4498	193-4506							
PERR05	064726	#9-201	195-4522	195-4544							
PERR06	064754	#445-1907									
PERR07	= 104433	#445-1914									
PERR10	= 104434	#9-202	198-4560	198-4579							
PERR11	= 104435	#9-203	198-4565	198-4584							
PERR12	= 104436	#9-204	201-4602	203-4652	236-5309	238-5353	240-5396				
PERR13	= 104437	#9-205	201-4608	203-4659							
PERR14	= 104440	#9-206	201-4616								
PERR15	= 104441	#9-207	201-4622								
PERR16	= 104442	#9-208									
PERR17	= 104443	#9-209									
PERR20	= 104444	#9-210	243-5421	243-5443	243-5454	245-5478	250-5535	250-5539			
PERR21	= 104445	#9-211	243-5427	243-5437	243-5460	245-5472	250-5544	250-5548			
PERR22	= 104446	#9-212	238-5332	240-5378							
PERR23	= 104447	#9-213	228-5189	267-5834							
PERR24	= 104450	#9-214	253-5611	255-5640							
PERR25	= 104451	#9-215	253-5616								
PERR26	= 104452	#9-216	263-5751	263-5756							
PERR27	= 104453	#9-217	231-5219	231-5244	233-5271						
PERR30	= 104454	#9-218	231-5231	233-5259							
PERR31	= 104455	#9-219	265-5797								
PERR32	104456	#9-220	206-4725	206-4731	217-4975	217-4981	220-5055	220-5060	223-5131	223-5137	
PERR33	- 104457	#9-221	206-4737	206-4751							
PERR34	= 104460	#9-222	209-4821								
PERR35	= 104461	#9-223	206-4743	206-4757	209-4829						
PERR36	- 104462	#9-224	269-5871	269-5878							
PERR37	= 104463	#9-225									
PERR40	= 104464	#9-226									
PERR41	= 104465	#9-227									
PERR42	= 104466	#9-228									
PERR43	= 104467	#9-229									
PERXOR	065540	#9-230									
PFLAG	002130	448-1992	448-2004	450-2015	#450-2028	452-2060	454-2096				
PHYADD	002044	#38-1161	109-2847	313-6654	*324-6879	*324-6900	389-466	412-1076	420-1252	423-1317	
PORTCO	002646	425-1377	427-1425	429-1467	433-1534	437-1623	439-1684				
		#38-1136	*468-2434	*468-2435	*468-2436	*468-2437	*468-2439	468-2440			
		#40-1304	*373-172	373-191	*373-191	*373-198	*389-469	*389-469	*389-469	*389-469	
		*389-504	391-546	391-547	429-1491	429-1492	435-1583	435-1584	560-4718	560-4718	
		560-4718	560-4718	560-4725	560-4725	560-4725	560-4725				
PORTDI	002606	#40-1300	*56-1600	*56-1607	*83-2279	92-2520	92-2520	92-2535	92-2542	365-23	
		407-920	560-4719	560-4719	560-4719	560-4719					
PSW	- 177776	#11-261	*60-1651	*60-1652	*60-1658	*67-1868	*67-1881	*67-1898	*67-1920	*69-1969	
		*135-3332	*146-3630	*173-4225	*175-4251	*177-4284	*182-4357	*185-4391	*273-5959	*290-6345	
		*290-6347	*315-6699	*317-6740	*319-6791	*319-6807	*335-7087	*344-7251	*346-7291	*346-7309	
		*348-7372	*351-7466	*353-7522	*355-7595	*355-7602	*357-7671	*365-22	*365-30	*365-59	
		*367-67	*367-81	*369-101	*371-146	*371-158	*373-165	*373-169	*373-190	*375-232	

CEMKAB
SYMBOL CROSS REFERENCE
SYMBOL VALUE

CREATED BY MACRO ON 1-AUG-79 AT 07:46

PAGE 24
CREF V01

B 14

SEQ 0584

REFERENCES

		*377-263	*377-280	*379-304	*379-312	*379-333	*383-371	*383-375	*385-387	*385-398
		*387-441	*387-452	*389-468	*389-496	*393-571	*393-593	*395-608	*395-622	*398-670
		*398-674	*401-756	*401-760	*403-799	*405-836	*407-925	*481-2717	*481-2718	*481-2734
PTYBUF	002636	#40-1303	83-2288	*371-149	371-153	371-159	*371-159	*407-928	*408-966	*437-1628
		437-1649	437-1650	483-2765	483-2766					
PTYFLA	002626	#40-1302	407-926	*407-929	456-2136	456-2136	456-2136	456-2136	483-2759	*483-2767
		483-2770	*483-2775							
PWLOCK	002760	#42-1339	*397-642	*403-789						
PWRVEC	= 000024	#11-324	*47-1463	*47-1464	*52-1529	*397-646	*397-647	*398-704	*400-712	*401-777
		403-800	403-801	*403-803	*403-804	*405-837	*405-838			
QUE	072154	89-2393	90-2443	90-2480	389-482	389-528	408-973	408-1016	410-1046	412-1082
		420-1265	420-1287	423-1329	423-1351	425-1401	427-1442	429-1478	435-1603	437-1636
		439-1701	441-1726	456-2137	#483-2754					
QUE1	072222	#483-2765	483-2772							
QUICK	002536	#38-1272	*52-1528	335-7074						
QVFLAG	002440	#38-1238	*52-1528	*52-1532	107-2802	*107-2804	162-3984	206-4764	209-4846	214-4911
		217-4992	220-5069	225-5149	329-6952	331-6992				
RANODD	034626	*167-4114	#263-5753	*263-5757						
RDCHR	= 104411	#9-177	490-3085							
RDDEC	= 104414	#9-180	338-7137							
RDLIN	104412	#9-178	491-3162	491-3213						
RDOCT	= 104413	#9-179	56-1593	342-7212	342-7215	344-7236	346-7275	346-7307	348-7328	348-7340
		348-7345	348-7350	353-7501	355-7560	355-7574	357-7650	359-7703	361-7750	363-7783
READCS	- 104426	#9-196	64-1709	77-2152	133-3294	137-3395	139-3427	146-3636	236-5303	238-5325
		238-5347	240-5371	240-5390	258-5662	260-5719	260-5730	296-6413	296-6432	298-6448
		298-6467	340-7191	342-7206	342-7220	393-586	398-684	470-2477	479-2690	
READON	002504	#38-1259	*369-105	*369-116	369-139	*375-231	375-256	*375-258	*377-270	*377-276
REALPA	002366	#38-1216	*152-3782	*152-3790	*152-3799	*154-3812	*154-3837	*154-3848	*156-3861	*156-3868
		*156-3878	*158-3891	*158-3900	*158-3908	*158-3918	*160-3929	*160-3938	*160-3943	*162-3953
		*164-4023	*164-4049	*164-4057	*165-4068	*165-4094	*167-4101	*169-4126	*171-4181	*173-4222
		*175-4242	*177-4280	*177-4298	*179-4321	*371-150	452-2066	452-2069	452-2072	452-2075
		457-2178	466-2400	489-3028						
REFRES	033760	248-5522	#250-5559							
REFSUB	034030	250-5562	250-5566	#250-5570						
REGCOP	035204	152-3785	152-3794	#270-5907	369-136					
RELOCA	041130	111-2885	113-2919	115-2960	117-3001	120-3044	122-3093	124-3135	126-3184	171-4200
		#313-6649								
RELOC1	041456	#315-6697	367-70							
RESREG	= 104416	#9-183	154-3829	165-4084	167-4116	270-5948	319-6774	319-6811	338-7130	340-7184
		#369-140	377-296	418-1237	464-2358	495-3346				
RESTAR	002752	*36-1102	*36-1104	#42-1336	50-1483					
RESVEC	= 000010	#11-319	*47-1467	*47-1468						
RLFLAG	002134	#38-1163	111-2882	113-2916	115-2957	117-2998	120-3041	122-3090	124-3132	126-3181
		*315-6714	*317-6746	324-6901	333-7035	335-7073	338-7128	*367-76	397-659	457-2188
		483-2776	489-3017							
RRFLAG	002132	#38-1162	111-2865	113-2899	115-2935	117-2976	120-3020	122-3064	124-3111	126-3155
		131-3240	169-4136	169-4159	171-4190	*324-6879	*324-6885	*324-6900	*324-6903	*324-6911
		348-7363	351-7479	353-7533	357-7682					
SAVREG	- 104415	#9-182	154-3823	165-4076	167-4109	270-5942	319-6772	319-6775	338-7125	369-137
		377-293	418-1223	462-2289	495-3331					
SBECSR	002150	#38-1168	*149-3672	*149-3673	*236-5283	*236-5284	474-2545	474-2548		
SBEFLA	002022	#38-1127	104-2773	*107-2796	*149-3671	*236-5282				

SYMBOL CROSS REFERENCE

REF V01

SYMBOL	VALUE	REFERENCES	206-4693	206-4694	206-4709	206-4711	206-4759	*206-4761	*206-4761	*209-4788
SBEMSK	002350	#38-1210	*206-4693	*206-4694	206-4709	206-4711	206-4759	*206-4761	*206-4761	*209-4788
		*209-4789	209-4794	209-4796	209-4806	209-4841	*209-4843	*209-4843	*212-4866	*212-4867
		212-4877	212-4879	212-4883	212-4885	214-4912	*214-4914	*214-4914	*217-4938	*217-4939
		217-4949	217-4951	217-4955	217-4957	217-4993	*217-4995	*217-4995	*220-5015	*220-5016
		220-5026	220-5028	220-5032	220-5034	220-5070	*220-5072	*220-5072	*223-5094	*223-5095
		223-5104	223-5106	223-5110	223-5112	225-5150	*225-5152	*225-5152		
SBETES	017374	131-3247	#135-3306							
SCOPE	= 000004	#11-260	64-1689	65-1796	67-1833	69-1956	71-2031	99-2710	102-2730	102-2740
		182-4363	185-4397							
SDPAR0	= 172260	#11-429	154-3828	165-4078	165-4080	167-4112	193-4501	253-5623		
SDPAR7	= 172276	#11-436								
SDPDR7	= 172236	#11-416								
SECOND	= 011661	#13-559	89-2391	389-481	389-527	408-972	408-999	408-1015	412-1081	416-1193
		420-1264	420-1286	423-1328	423-1350	425-1400	427-1441	429-1477	435-1602	437-1635
		439-1700	441-1725							
SEEDHI	002714	#42-1321	*47-1449	167-4104	*167-4119	387-439	493-3304	493-3311	*493-3316	
SEEDLG	002716	#42-1322	*47-1450	167-4103	*167-4118	493-3303	493-3309	*493-3315		
SELONL	002002	#38-1116	102-2733	102-2748	131-3227	324-6910	*361-7760	*361-7765		
SETPAR	043212	113-2903	117-2980	124-3113	126-3157	#331-6989				
SETPAT	042762	113-2901	117-2978	#327-6936						
SHALT	004420	#45-1412								
SHUTUP	043554	107-2813	335-7054	#335-7062						
SIDE	002422	#38-1231	*131-3234	131-3268	*131-3271	131-3271	144-3506	144-3522	144-3538	144-3554
		144-3582	144-3598	144-3614	146-3647	146-3648	*162-3961			
SIDEOK	021066	131-3244	#146-3624							
SIPARO	= 172240	#11-419	310-6606							
SIPAR3	= 172246	#11-422	310-6620							
SIPDRO	= 172200	#11-399	310-6608	397-663	400-748					
SIZE	= 040000	#13-558	65-1809	67-1864	67-1893	67-1918	152-3784	152-3792	152-3801	154-3818
		154-3842	154-3853	167-4108	169-4141	169-4164	171-4191	175-4247	175-4266	177-4300
		240-5408	267-5850	270-5944	315-6700	317-6741	319-6792	319-6808	351-7484	367-87
		369-107	375-249	377-269	377-290	425-1383				
SIZELO	= 177760	#11-343	79-2172	79-2174	79-2176	79-2180				
SKIPKA	002012	#38-1120	340-7172	*340-7174	*359-7712	*359-7718				
SLAVEM	061244	58-1626	416-1214	#418-1221						
SLAVEN	075774	#506-3639	568-5002	568-5003						
SLAVER	002570	#38-1285	459-2242	*483-2777	*483-2779					
SLAVES	002730	#42-1327	*56-1594	56-1596	56-1596	56-1599	75-2108	*75-2109	*77-2130	*89-2396
		*90-2449	*90-2455	90-2462	*90-2486	90-2492	92-2515	92-2543	98-2699	324-6892
		381-341	381-342	389-475	389-490	389-523	389-536	391-553	408-983	408-1026
		410-1059	412-1104	414-1117	420-1278	420-1296	420-1300	423-1342	423-1360	423-1364
		425-1393	425-1409	427-1434	427-1450	429-1472	429-1486	429-1498	431-1521	433-1549
		433-1556	433-1564	433-1568	435-1596	437-1630	437-1644	437-1655	439-1693	439-1709
		439-1712	441-1734							
SLAVE1	= 000040	#13-562	83-2257	94-2571	94-2580	278-6096	407-921			
SLAVE2	= 000100	#13-563	83-2261	94-2571	94-2581	278-6096	407-922			
SLAVE3	= 000200	#13-564	83-2265	94-2571	94-2582	278-6096	407-923			
SLAVUP	061216	85-2316	383-358	408-986	#416-1213					
SLFLAG	002656	#40-1305	*94-2578	*94-2578	*94-2578	*94-2578	*94-2579	*94-2580	*94-2581	*94-2582
		*381-340	*381-345	381-350	*381-350	389-503	560-4701	560-4701	560-4701	560-4701
		369-120	369-122	369-124	369-126	369-128	#369-130			
SLPAT	051570	369-120	369-122	369-124	369-126	369-128	#369-130			
SLPATO	051530	#367-89	#369-109	#369-119	377-271					

SYMBOL CROSS REFERENCE

CREF V01

SYMBOL	VALUE	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES
SLPAT1	051534	367-90	369-110	#369-121	377-272					
SLPAT2	051542	367-91	369-111	#369-123	377-273					
SLPAT3	051550	367-92	369-112	#369-125	377-274					
SLPAT4	051556	367-93	369-113	#369-127	377-275					
SLPAT5	051564	367-94	369-114	#369-129						
SOBK	002704	#42-1317	173-4228							
SOBLEN	= 000056	173-4226	173-4231	#265-5812						
SOFTPA	002744	#42-1333	*47-1453	*104-2780	177-4301					
SOURCE	002402	#38-1222	*206-4704	*209-4792	*212-4881	*217-4953	*220-5030	*223-5108	*258-5648	305-6539
SPECIA	002432	#38-1235	131-3244	*137-3394	*144-3500	*144-3516	*144-3532	*144-3548	*144-3576	*144-3592
		*144-3608	162-3963							
SSP	-%000006	#11-277	*60-1655	*182-4358	*185-4392	398-675	*401-757	481-2719		
ST	- 177776	#501-3572	544-4302	*544-4312						
STACK	= 002000	#11-255	11-256	36-1094	36-1108	42-1318	45-1428	52-1531	90-2507	107-2809
		367-71	408-978	408-1004	408-1021	408-1028	412-1105			
START	004352	36-1103	36-1105	#45-1403	77-2158	89-2387	335-7059	403-793		
START1	000300	36-1098	#36-1102	36-1107						
START2	000310	36-1099	#36-1104							
START3	000200	#3 -1098	568-5012							
START4	000322	36-1100	#36-1106							
STOPCP	011720	#83-2282	375-224							
STOPOK	002570	#38-1265	*81-2239	456-2140	*456-2141					
STRIPE	002460	#38-1249	*248-5501	248-5505	250-5526	*250-5556	250-5556			
STRTDI	002364	#38-1215								
SUBAAA	005532	54-1565	#56-1578							
SUBAAB	005200	#52-1516								
SUBAAQ	007720	67-1876	#69-1937							
SUBAAR	013160	83-2256	#92-2546							
SUBAAS	007002	64-1776	#65-1795							
SUBAAT	011334	79-2173	79-2186	#81-2201						
SUBAAU	014602	102-2764	#104-2773							
SUCCESS	002424	#38-1232	*131-3237	*131-3258	131-3266	*355-7623	355-7629	*355-7631	*475-2589	475-2613
		475-2620	*477-2629	*477-2631	*477-2633	*477-2635	*477-2638	*477-2640	*477-2642	
SUPDUA	002360	#38-1212	*154-3824	*156-3864	*156-3874	*156-3881	*158-3892	*158-3901	*158-3909	*158-3919
		*160-3930	*160-3939	*160-3944	*162-3955	*164-4050	*164-4058	*165-4080	*165-4095	*169-4131
		*173-4232	*175-4264	*177-4289	*177-4308	185-4394	*369-135	*371-151	*373-181	*375-252
SUPD01	026042	102-2756	152-3787	152-3796	152-3807	162-3983	164-4032	167-4113	167-4117	169-4144
		169-4167	171-4193	177-4314	#182-4334	270-5947	369-138	375-255	377-294	
SUPD02	026056	154-3830	154-3845	154-3856	162-3988	162-3994	162-4001	162-4007	162-4013	164-4035
		164-4039	164-4042	175-4269	#182-4336	377-897				
SUPD03	026220	154-3825	156-3865	156-3875	156-3882	158-3893	158-3902	158-3911	158-3920	160-3931
		160-3940	160-3945	164-4051	164-4060	165-4096	169-4147	169-4170	177-4311	#185-4369
		351-7486	369-139	371-154	375-256					
SUPD04	026234	162-4017	165-4081	165-4087	173-4233	175-4265	177-4293	#185-4370	373-182	373-186
SUPDR0	002266	#38-1179	*182-4338	182-4346	*185-4372	185-4380				
SUPDR1	002270	#38-1180	182-4339	185-4373						
SUPDR2	002272	#38-1181								
SUPDR3	002274	#38-1182								
SUPDR4	002276	#38-1183								
SUPDR5	002300	#38-1184								
SUPDR6	002302	#38-1185	182-4349	185-4383						
SUPLIM	057372	#407-947	568-4997	568-4998						

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
SUPM13		053752	#389-458 437-1663
SUPSTK	=	000740	#11-257 60-1654 182-4358 185-4392 481-2722 48'-2728
SWAPAT		002764	#42-1343 *47-1452
SWR		002766	#42-1346 *50-1496 50-1498 *50-1503 *52-1525 62-1666 65-1826 69-2022 89-2370
			*89-2371 89-2372 *90-2494 96-2659 99-2712 107-2802 149-3655 149-3668 162-3984
			162-3989 162-3995 162-4002 162-4008 206-4763 209-4845 214-4910 217-4991 220-5068
			225-5148 273-5966 313-6650 313-6666 313-6687 329-6952 331-6992 348-7355 348-7383
			351-7450 353-7506 353-7511 355-7554 355-7579 355-7603 357-7655 357-7660 398-700
			400-719 408-956 *408-957 408-958 *412-1107 456-2140 456-2148 456-2164 459-2219
			459-2242 459-2245 460-2252 460-2256 464-2359 487-2952 487-2960 487-2982
SWREG	=	000176	#13-550 50-1503 62-1666 89-2371 408-957 487-2952
SWO	=	000001	#11-297 65-1826 69-2022 149-3655 149-3668 162-3989 162-3995 162-4002 162-4008
			348-7383 351-7450 353-7511 355-7554 357-7660
SW1	=	000002	#11-296
SW10	=	002000	#11-287 459-2219
SW11	=	004000	#11-286 107-2802 162-3984 206-4763 209-4845 214-4910 217-4991 220-5068 225-5148
			329-6952 331-6992 348-7355 353-7506 355-7579 357-7655
SW12	=	010000	#11-285 313-6650
SW13	=	020000	#11-284 313-6666 313-6687 459-2242
SW14	=	040000	#11-283 456-2148
SW15	=	100000	#11-282
SW2	=	000004	#11-295
SW3	=	000010	#11-294
SW4	=	000020	#11-293 273-5966
SW5	=	000040	#11-292 459-2245
SW6	=	000100	#11-291 96-2659
SW7	=	000200	#11-290 464-2359
SW8	=	000400	#11-289 456-2140
SW9	=	001000	#11-288 456-2164 460-2256
SYSS1Z		011210	79-2178 79-2182 #79-2189
SYSTID	=	177764	#11-347 56-1600 83-2272 365-16 407-913
TAG2\$		007366	67-1851 #67-1873
TAG3\$		007412	67-1872 #67-1877
TAG4\$		026136	182-4347 #182-4349
TAG70\$		067636	464-2332 #466-2369
TAG71\$		067646	464-2333 #466-2375
TAG72\$		067656	464-2334 #466-2381
TAG73\$		067722	464-2335 #466-2394
TAG74\$		067730	464-2336 #466-2400
TAG75\$		067742	464-2337 #466-2406
TAG76\$		067754	464-2338 #466-2412
TAG77\$		067776	464-2339 #468-2423
TAG78\$		070000	464-2340 #468-2428
TAG79\$		070006	464-2341 #468-2434
TAG80\$		070066	464-2342 #468-2448
TAG81\$		070100	464-2343 #468-2454
TAG82\$		070122	464-2344 #470-2472
TAG83\$		070324	464-2345 #472-2504
TAG84\$		070410	464-2346 #472-2522
TAG85\$		070502	464-2347 #474-2543
TAG86\$		070612	464-2348 #474-2567
TAG9\$		007232	#67-1849 67-1879 67-1912 67-1934

CEM KAB SYMBOL	CROSS REFERENCE VALUE	REFERENCES										
TASK	002616	#40-1301	*83-2285	*83-2298	90-2453	90-2490	365-31	365-35	*365-60	367-82		
		369-102	375-233	377-264	377-281	*379-306	*389-474	389-488	*389-522	389-534		
		408-981	408-1024	*410-1043	410-1057	*412-1080	412-1090	*416-1217	*420-1258	420-1271		
		*420-1277	420-1293	*423-1322	423-1335	*423-1341	423-1357	*425-1391	425-1407	*427-1433		
		427-1448	*429-1471	429-1484	*433-1542	*433-1555	435-1609	*437-1629	437-1642	*439-1689		
		*439-1691	439-1707	*441-1724	441-1732							
TASKDO	050726	83-2301	365-5	*365-10	389-476	416-1218	420-1261	420-1280	423-1325	423-1344		
		425-1395	427-1436	429-1473	433-1544	433-1557	437-1631	439-1695				
TASKRE	050710	#365-4	365-62									
TASK00	051234	#365-39	*365-63									
TASK01	051236	365-40	*367-66									
TASK02	051330	365-41	*367-80									
TASK03	051430	365-42	*369-100									
TASK04	051664	365-43	*371-145									
TASK05	051774	365-44	*373-164									
TASK06	052300	365-45	*375-219									
TASK07	052326	365-46	*375-226									
TASK10	052336	365-47	*375-230									
TASK11	052536	365-48	*377-262									
TASK12	052644	365-49	*377-279									
TASK13	052726	365-50	*379-301									
TASK14	053276	365-51	*383-356									
TASK15	053310	365-52	*383-361									
TASK16	053316	365-53	*383-365									
TASK17	053334	365-54	*383-370									
TASK20	053422	365-55	*385-385									
TASK7A	052344	375-228	*375-232									
TBG4B	026314	185-4381	*185-4383									
TCFIG1	036012	#278-6051	278-6081	466-2385								
TCNFI	035664	273-5971	273-5980	273-5990	#276-6015							
TEMP	002534	#38-1271	*98-2666	98-2683	*98-2684							
TESTAD	002506	#38-1260	*131-3246	*131-3261	131-3261	135-3331	156-3863	156-3880	206-4713	206-4775		
		209-4798	209-4836	209-4853	212-4863	214-4922	217-4963	217-4969	217-5003	220-5040		
		220-5047	220-5051	220-5079	223-5118	223-5127	225-5159	258-5651	452-2055			
TIME	002434	#38-1236	*351-7458	351-7460								
TIMEOU	036726	47-1469	50-1502	50-1513	56-1612	60-1646	64-1774	65-1823	67-1874	75-2098		
		#283-6223	340-7194	340-7198	342-7210	342-7227	344-7266	346-7318	457-2195			
TKVEC	000060	#11-327	273-5954	273-5954	*273-5956	*273-5957	*273-5995	*273-5995	348-7323	348-7323		
		*348-7369	*348-7370	*348-7431	*348-7431	351-7448	351-7448	*351-7463	*351-7464	*351-7474		
		*351-7474	353-7497	353-7497	*353-7519	*353-7520	*353-7544	*353-7544	355-7551	355-7551		
		*355-7592	*355-7593	*355-7613	*355-7613	357-7646	357-7646	*357-7668	*357-7669	*357-7693		
		*357-7693										
TMFLAG	002140	#38-1165	*120-3035	*122-3079	*124-3126	*126-3170	327-6922					
TOOMAN	002472	#38-1254	*452-2049	459-2245	*460-2277							
TRAPVE	000034	#11-326	*47-1461	*47-1462								
TRT	000003	#501-3577	522-3969	546-4400								
TSK05A	052240	373-170	*373-201	373-215								
TSK13A	053100	379-302	*379-324									
TSK13B	053136	379-335	*381-338									
TSK20A	053602	385-386	*385-422									
TSTBAN	007606	67-1860	*67-1915									
TSTDAT	002344	#38-1209	*206-4696	*206-4697	*206-4700	*206-4701	206-4702	206-4703	206-4704	*206-4711		

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
UDPAR7	=	177676	#11-396
UDPDR7	=	177636	#11-375 154-3822
UIPAR0	=	177640	11-378 #11-379 321-6816 379-303 381-343
UIPAR2	=	177644	#11-381 *67-1861 *67-1896 *169-4130 *177-4307 381-343
UIPAR3	=	177646	#11-382 67-1882 169-4131 177-4308 369-135
UIPAR4	=	177650	#11-383 319-6778 319-6795 *375-251
UIPAR5	=	177652	#11-384 375-252
UIPAR6	=	177654	#11-385 *67-1847 195-4533
UIPAR7	=	177656	#11-386 *67-1848
UIPDRO	=	177600	#11-358 321-6818 397-662 400-747
UNITOP	002516		#38-1264 *75-2102 79-2167 79-2167 *96-2645 *96-2646 *96-2647 *96-2648 *96-2649
			96-2651 96-2651
UNRELO	041604		111-2889 113-2923 115-2964 117-3005 120-3048 122-3097 124-3139 126-3188 171-4210
			#317-6718 333-7035 335-7073
UPPFLG	002363		#38-1214 *217-4968 217-4983 *217-4985 *223-5123 225-5140 *225-5142
UP2	056154		403-790 #403-793
USERMA	042240		315-6698 317-6739 319-6773 #321-6815
USESTK	000700		#11-258 60-1660 375-220 481-2744
USP	=X000006		#11-278 *60-1661 398-671 *401-761 481-2735
WAITST	012034		83-2286 #85-2305
WAITS	063674		433-1546 433-1563 #435-1600
WAKEUP	054544		389-498 #391-558
WARN1	007320		#67-1861
WARN2	026522		#191-4465 *270-5933
WARN3	026536		#191-4470 *270-5934
WARN4	026562		#191-4482 *270-5935
WARN5	026576		#191-4487 *270-5936
WARN6	035364		#270-5946
WARN7	024416		#169-4130
WASDBE	- 104500		#9-240 69-1976 69-1985 69-1993 69-2001
WASSBE	- 104476		#9-238 149-3669
WAS1DB	- 104501		#9-241 212-4898
WAS1SB	104477		#9-239 162-3990 162-4003 162-4009
WHICH	050630		340-7188 342-7203 #363-7775
WHOBOX	070672		466-2394 #475-2581
WOOPEN	056512		403-802 403-805 403-807 405-821 405-842 #405-850 405-853
WOOPS	056160		397-659 #403-795
WOOPSA	056542		*403-800 *403-801 403-802 405-837 405-838 405-841 #405-853
WOOPUP	056336		403-802 403-802 403-803 403-805 403-805 403-805 #405-820 405-842 405-843
			405-853
WORST	002712		#42-1320 *47-1444 *115-2952 *117-2993 *122-3085 *126-3176 324-6907
WRITEO	002502		#38-1258 *104-2779 *104-2782 177-4309 *367-85 *367-96 369-138 *375-227 375-255
			*375-258 *377-270 *377-276 *414-1181 *414-1183
			#38-1241 *52-1536 460-2267
XXDPCH	002446		#38-1233
ZERO	002426		#38-1234 146-3641 146-3642 248-5495 248-5499
ZEROS	002430		#38-1234 36-1096 #496-3436
\$APTHD	075236		#38-1144 *52-1528 *52-1532 62-1665 487-2956
\$AUTO	002066		#38-1123 *457-2177
\$BANK	002015		#38-1123
\$BASE	075210		#496-3408
\$BELL	003003		#42-1353 353-7538 357-7687 459-2221
\$CACHF	037066		#285-6268 499-3504

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES								
\$CACHN		037050	#285-6262	499-3503							
\$CBCSR		037700	#293-6389	499-3547							
\$CB1CS		037742	#293-6396	499-3548							
\$CDW1		075214	92-2547	92-2549	#496-3413						
\$CDW2		075216	92-2547	92-2550	#496-3414						
\$CHARC		057356	*407-895	*407-905	*407-939	#407-944					
\$CHKDI		040354	#300-6489	499-3555							
\$CHK1D		040410	#300-6496	499-3556							
\$CKSWR		073022	#487-2931	499-3487							
\$CLRCS		040322	#300-6480	499-3553							
\$CLR1C		040340	#300-6484	499-3554							
\$CMTAG		002000	#38-1114	45-1416							
\$CMTGE		002700	#40-1311	45-1418							
\$CNTLC		074224	487-2970	490-3089	#490-3140						
\$CNTLG		074236	487-2958	#490-3142							
\$CNTLU		074231	487-2975	490-3113	#490-3141						
\$CPUOP		075162	#496-3381								
\$CRLF		003010	#42-1355	96-2652	273-5972	273-5975	355-7637	407-894	462-2290	462-2313	462-2322
			479-2684	481-2710	481-2724	481-2740	481-2748	487-2984	489-3009	490-3118	
\$DBLK		073012	486-2884	486-2914	#486-2922						
\$DB20		075014	468-2441	#495-3331							
\$DDW0		075220	54-1548	#496-3425							
\$DDW1		075222	#496-3426								
\$DDW2		075224	#496-3427								
\$DDW3		075226	#496-3428								
\$DDW4		075230	#496-3429								
\$DDW5		075232	#496-3430								
\$DDW6		075234	98-2701	98-2703	#496-3431						
\$DEENE		037040	#285-6258	499-3499							
\$DEVCT		075144	*107-2834	*456-2129	*456-2131	#496-3371					
\$DEVIM		075212	#496-3409								
\$DOAGA		015040	107-2808	107-2810	#107-2831						
\$DOAGN		015010	#107-2820								
\$DOWN		055532	#398-705	398-706							
\$DTBL		073002	486-2887	#486-2918							
\$ECCDI		037466	#293-6355	499-3543							
\$ECCIN		037554	#293-6367	499-3545							
\$ECC1D		037522	#293-6361	499-3544							
\$ECC1I		037574	#293-6372	499-3546							
\$ENASH		037612	#293-6377	499-3557							
\$ENATS		037646	#293-6383	499-3558							
\$ENDAD		015000	36-1087	52-1533	56-1581	#107-2816					
\$ENERG		037030	#285-6254	499-3498							
\$ENV		075154	52-1527	#496-3376							
\$ENVIM		075155	52-1520	52-1523	#496-3377						
\$EOP		014662	#107-2796								
\$ERFLG		002016	#38-1124	456-2162	*456-2168	*459-2215					
\$ERROR		066662	47-1459	#459-2213							
\$ERRTB		101372	462-2301	#548-4417							
\$ERRTY		067324	459-2249	#462-2289							
\$ERTTL		002754	#42-1337	79-2185	104-2774	107-2798	355-7620	355-7622	*459-2223	*459-2225	460-2267
\$ESCAP		002454	#38-1247	*456-2171	460-2259	460-2261					

EMKAB CREATED BY MACRO ON -AUG-79 AT 07:40

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
SETABL		075154	#496-3375
SETEND		075236	#496-3432 496-3442
SEXHAL		043546	#335-7058
SFATAL		075136	*459-2241 #496-3368
SFILLC		003002	#42-1352 407-898 542-4290
SFILLS		002451	#38-1244 *359-7706 542-4292
SGTSWR		073160	#487-2959 499-3486
SHALT		067136	#460-2254
SHALT2		075312	#497-3468
SHIBTS		075236	#496-3437
SHIOCT		074434	344-7237 346-7276 355-7561 *491-3184 #491-3195
SILLUP		056134	397-646 400-712 #401-782 401-783
SINVAL		040510	#302-6519 499-3560
SITEMB		002017	#38-1125 *459-2232 462-2292
SKERNE		037020	#285-6250 499-3497
SKMAP		041016	#310-6628 499-3501
SLF		003011	#42-1356 490-3128
SLOADC		037076	#288-6275 499-3506
SLOAD1		037146	288-6279 #288-6288
SLPADP		002746	#42-1334 *47-1454 182-4337 *182-4347 182-4348 *182-4364 185-4371 *185-4381 185-4382 *185-4398 *456-2166 *456-2169 456-2173 #42-1335 *47-1455 182-4337 *182-4348 *182-4364 185-4371 *185-4382 *185-4398 456-2166 *456-2170 460-2257
SLPERR		002750	
SMADR1		075166	#496-3395
SMADR2		075172	#496-3399
SMADR3		075176	#496-3402
SMADR4		075202	#496-3405
SMAIL		075134	#496-3366 496-3438 496-3442
SMAMS1		075164	98-2667 #496-3388
SMAMS2		075170	#496-3397
SMAMS3		075174	#496-3400
SMAMS4		075200	#496-3403
SMBADR		075240	#496-3438
SMNEW		074254	487-2961 #490-3144
SMSGAD		075150	#496-3373
SMSGLG		075152	#496-3374
SMSGTY		075134	*460-2264 #496-3367
SMSWR		074243	487-2959 #490-3143
SMTYP1		075165	#496-3389
SMTYP2		075171	#496-3398
SMTYP3		075175	#496-3391
SMTYP4		075201	#496-3404
SNOTRA		075306	#497-3467 499-3482 499-3484 499-3536 499-3537 499-3538 499-3539 499-3540 499-3541 499-3561 499-3562 499-3563 499-3564 499-3565 499-3566 499-3567 499-3568
SNULL		002450	#38-1243 407-900
SNWTST	-	000001	#64-1689 64-1689 #64-1689 #65-1796 65-1796 #65-1796 #67-1833 67-1833 #67-1833 #71-2031 71-2031 #71-2031 #99-2710 99-2710 #99-2710 #102-2730 102-2730 #102-2730 #102-2740 102-2740 #102-2740
SOCNT		072572	*485-2821 *485-2850 #485-2863
SOCTVL		075116	495-3333 #495-3358 495-3361
SOCTB	=	075122	468-2443 #495-3361
SOMODE		072574	*485-2816 *485-2820 485-2825 *485-2828 *485-2839 #485-2865

CEMKAB SYMBOL	CREATED BY	MACRO ON	-AUG-79 AT 07:46		PAGE 33	K 14					
SYMBOL	CROSS REFERENCE VALUE	REFERENCES			REF	V01	SEQ 0593				
\$OVER	066502	456-2148	456-2167	#456-2172							
\$PASS	075142	*52-1519	*92-2557	*107-2799	*107-2800	107-2806	107-2831	*107-2837	158-3889	158-3898	
		158-3906	158-3916	160-3927	160-3936	162-3951	165-4092	#496-3370			
\$PASTM	075244	#496-3440									
\$PATMA	002014	#38-1122	401-774	401-775	*457-2178	*457-2187	*457-2190	*457-2191	457-2192	457-2193	
		459-2218									
\$PER01	064574	#445-1883	499-3509								
\$PER02	064622	#445-1889	499-3510								
\$PER03	064650	#445-1895	499-3511								
\$PER04	064700	#445-1901	499-3512								
\$PER07	064762	#445-1917	499-3513								
\$PER10	065004	#445-1922	499-3514								
\$PER11	065034	#445-1927	499-3515								
\$PER12	065054	#445-1932	499-3516								
\$PER13	065076	#447-1938	499-3517								
\$PER14	065116	#447-1943	499-3518								
\$PER15	065140	#447-1948	499-3519								
\$PER16	065162	#447-1953	499-3520								
\$PER17	065202	#447-1958	499-3521								
\$PER20	065220	#447-1963	499-3522								
\$PER21	065236	#447-1968	499-3523								
\$PER22	065256	#447-1973	499-3524								
\$PER23	065274	#447-1978	499-3525								
\$PER24	065312	#447-1983	499-3526								
\$PER25	054570	#393-569	499-3527								
\$PER26	065502	#450-2020	499-3528								
\$PER27	065522	#450-2024	499-3529								
\$PER30	054762	#395-605	499-3530								
\$PER31	065720	#452-2064	499-3531								
\$PER32	066016	#454-2082	499-3532								
\$PER33	066064	#454-2091	499-3533								
\$PER34	066144	#454-2102	499-3534								
\$PER35	066176	#454-2111	499-3535								
\$PWDRN	055160	47-1463	#397-638	401-777							
\$PWRLP	055536	398-704	#400-711	405-849							
\$QUES	003007	#42-1354	487-3002	490-3121							
\$RAND	074720	387-438	#493-3302								
\$RDCHR	073602	#490-3053	499-3489								
\$RDDEC	074436	#491-3210	499-3492								
\$RDLIN	073722	#490-3080	499-3490								
\$RDOCT	074266	#491-3159	499-3491								
\$READC	037220	#290-6304	499-3507								
\$RESRE	074662	#492-3283	499-3495								
\$SAVRE	074624	#492-3272	499-3494								
\$SAVR6	056140	*398-702	400-714	*400-715	*400-716	#401-784	405-832				
\$SCOPE	066232	47-1457	#456-2129								
\$STN	000001	#64-1689	#65-1796	#67-1833	#71-2031	#99-2710	#102-2730	#102-2740			
\$SVLAD	066466	456-2156	456-2163	#456-2169							
\$SWR	163000	#7-131	64-1689	65-1796	67-1833	71-2031	99-2710	102-2730	102-2740		
\$SWREG	075156	52-1525	#496-3379								
\$TESTN	075140	*459-2218	#496-3369								
\$TKB	002774	#42-1349	273-5958	273-5994	348-7371	348-7432	351-7465	351-7475	353-7521	353-7543	

EMKAB SYMBOL	CREATED BY	CROSS REFERENCE	MACRO ON	DATE	TIME	PAGE	REF	SEQ			
			1-AUG-79	AT	07.46	34	V01	0594			
		VALUE	REFERENCES								
\$TKS		002772	355-7594	355-7612	357-7670	357-7692	487-2936	487-2966	489-3037	490-3057	490-3063
\$TN	=	000010	#42-1348	273-5960	273-5993	348-7373	348-7430	351-7467	351-7473	353-7523	353-7542
			355-7596	355-7611	357-7672	357-7691	487-2934	487-2964	489-3035	490-3055	490-3061
			#7-132	64-1689	64-1689	#64-1689	65-1796	65-1796	#65-1796	67-1833	67-1833
			#67-1833	71-2031	71-2031	#71-2031	99-2710	99-2710	#99-2710	102-2730	102-2730
			#102-2730	102-2740	102-2740	#102-2740					
\$TPB		003000	#42-1351	407-935							
\$TPFLG		002452	#38-1245	*52-1521	407-877						
\$TPS		002776	#42-1350	407-933							
\$TRAP		075252	47-1461	#497-3452							
\$TRAP2		075274	#497-3463	499-3478							
\$TRPAD		075314	497-3457	#499-3478							
\$TSTM		075242	#496-3439								
\$TSTRD		037310	#290-6322	499-3559							
\$TTYIN		074200	490-3082	490-3083	490-3101	490-3119	490-3133	#490-3137			
\$TYPDS		072576	#486-2877	499-3483							
\$TYPE		056752	#407-877	499-3479							
\$TYPEC		057076	407-897	407-904	#407-907	483-2768	487-2988				
\$TYPEX		057360	407-940	407-942	#407-945						
\$TYPOC		072374	#485-2819	499-3480							
\$TYPON		072410	485-2818	#485-2821							
\$TYPOS		072350	#485-2814	499-3481							
\$UNIT		075146	*107-2835	*456-2132	#496-3372						
\$UNITM		075246	#496-3441								
\$USWR		075160	107-2831	#496-3380							
\$VECT1		075204	#496-3406								
\$VECT2		075206	#496-3407								
\$WASDB		040146	#298-6441	499-3551							
\$WASSB		040002	#296-6406	499-3549							
\$WAS1D		040262	#298-6467	499-3552							
\$WAS1S		040116	#296-6432	499-3550							
\$XTSTR		066370	#456-2150								
\$ZAP42		014760	#107-2809	460-2271							
\$OFILL		072573	*485-2815	*485-2819	485-2829	#485-2864					

48- 1456	INITIALIZE VECTORS	
51- 1479	CLEAR THE CONFIGURATION TABLE	
51- 1491	SIZE FOR A HARDWARE SWITCH REGISTER	
51- 1508	FIND OUT IF ANY LINE CLOCK IS PRESENT	
53- 1516	SETUP ACT, APT, & XXDP	
55- 1542	INITIALIZE PATTERNS	
55- 1567	SUBR PLUG IN NULL PATTERNS	
57- 1578	PROTECT PROGRAM & LOADERS	
57- 1584	MULTIPOINT DETERMINATION ROUTINE	
59- 1618	SLAVES START HERE	
61- 1630	DETERMINE MK11 ACCESS METHOD	
61- 1647	SETUP USER & SUPERVISOR STACK	
63- 1664	GET SOFTWARE SWITCH REGISTER IF NECESSARY	
63- 1674	SETUP UNIBUS MAP	
63- 1681	GET MEMORY MANAGEMENT READY	
65- 1689	T1 ANALYZE CONFIGURATION	
66- 1796	T2 TEST BANK 0 ACCESSES	
66- 1825	ENABLE MK11 FOR CORRECT TRAPS	
68- 1833	T3 TEST BANKS 1-167 (OCTAL) FOR ZEROS & ONES	
70- 1937	DETERMINE PROTECTED BANKS	
72- 2031	T4 MK11 PROTECTION POINTER TEST	
74- 2046	CHECK SYSTEM SIZE REGISTER	
82- 2201	MOVE LOADERS IF NECESSARY	
84- 2242	MULTIPOINT HOOK	
86- 2305	SLAVES WAIT FOR MASTER TO COUNT DOWN	
88- 2319	BOOT UP ALL EXISTING CPU'S	
93- 2512	CHECK FOR UNIQUE CPU ID NUMBERS	
93- 2532	PRINT MULTIPOINT DIRECTORY	
93- 2546	LOAD CSR'S FROM E-TABLE \$CDW1 & \$CDW2	
95- 2562	LEGAL CONFIGURATION CHECK	
97- 2626	PRINT CONFIGURATION DETAILS	
99- 2664	CHECK APT SIZING	
100- 2710	T5 DIAGNOSTIC MODE DISPATCH ROUTINE	
103- 2730	T6 UNIQUE BANK TEST	
103- 2740	T7 FORCE ADDRESS PARITY ERRORS	
105- 2784	FLUSH OUT DBE'S	
108- 2789	END OF PASS ROUTINE	
110- 2843	WRITE BACKGROUND PATTERNS	
112- 2857	MTEST MODES	
112- 2859	BANKS FORWARD,PATTERNS FORWARD	**RECURSIVE**
114- 2893	BANKS FORWARD,PATTERNS REVERSE	**RECURSIVE**
116- 2927	BANKS WORST FIRST,PATTERNS FORWARD	**RECURSIVE**
118- 2968	BANKS WORST FIRST,PATTERNS REVERSE	**RECURSIVE**
121- 3010	PATTERNS FORWARD,BANKS FORWARD	**RECURSIVE**
123- 3052	PATTERNS FORWARD,BANKS WORST FIRST	**RECURSIVE**
125- 3101	PATTERNS REVERSE,BANKS FORWARD	**RECURSIVE**
127- 3143	PATTERNS REVERSE,BANKS WORST FIRST	**RECURSIVE**
130- 3193	SUBR SETUP MEMORY TEST	
132- 3214	SUBR TEST MK11 CONTROLLER LOGIC DISPATCH	
134- 3284	IS ECC ON?	
136- 3306	CHECK FOR SBE FREE LOCATIONS	
138- 3384	SETUP INTERLEAVE INFO	
140- 3421	SUBR GET SIZE FROM CSR	
143- 3448	CSR PATTERN CASE STATEMENT	
145- 3490	DETERMINE ADDRESSING ACCORDING TO INTERLEAVE	
147- 3624	DETERMINE IF BANK BELONGS TO CORRECT SIDE	
150- 3653	SUBR MK11 TEST DISPATCH	

152- 3724	SUBR	MJ11 TEST DISPATCH
153- 3778		PATTERNS
153- 3780	MEMORY	TEST SETUP ROUTINES
153- 3781	MT0000	SETUP DATA PATTERN TEST
153- 3789	MT0001	SETUP ADDRESS TEST
153- 3798	MT0002	SETUP COMPLEMENT ADDRESS TEST
155- 3811	MT0003	SETUP 3 XOR 9 WORST CASE NOISE TEST
155- 3836	MT0004	SETUP ROTATING ZEROS TEST
155- 3847	MT0005	SETUP ROTATING ONES TEST
157- 3860	MT0006	SETUP INITIAL DATA TEST
157- 3867	MT0007	SETUP ADDRESS BIT TEST
157- 3877	MT0010	SETUP BYTE ADDRESSING TEST
159- 3886	MT0011	SETUP CREATE SINGLE BIT ERROR TEST
159- 3895	MT0012	SETUP WRITE BYTE CLEARS SBE TEST
159- 3904	MT0013	SETUP CREATE DOUBLE BIT ERROR TEST
159- 3913	MT0014	SETUP WRITE INHIBIT DURING DATIP WITH DBE
161- 3924	MT0015	SETUP WRITE INHIBIT OF BYTE WITH DBE
161- 3933	MT0016	SETUP WRITE INHIBIT OF WORD WITH DBE
161- 3942	MT0017	SETUP HOLDING 1'S & 0'S
163- 3949	MT0020	SETUP MARCHING 0'S & 1'S IN CHECKBITS TEST
165- 4021	MT0021	SETUP MARCHING 0'S & 1'S TEST
165- 4046	MT0022	SETUP REFRESH & SHIFTING DIAGONAL TEST
165- 4054	MT0023	SHIFTING DIAGONAL TEST
166- 4064	MT0024	SETUP FAST GALLOPING PATTERN TEST
166- 4090	MT0025	SETUP INTERRUPT ENABLE TEST
168- 4100	MT0026	SETUP RANDOM DATA TEST
170- 4123	MT0027	UNIQUE BANK TEST
172- 4179	MT0030	SETUP FLUSH OUT DBE'S TEST
174- 4218	MT0031	SETUP SOB-A-LONG TEST
176- 4238	MT0033	SETUP WRITE RECOVERY TEST
178- 4276	MT0034	SETUP BRANCH GOBBLE TEST
178- 4297	MT0035	SOFT ERROR - BACKGROUND PATTERN TEST
180- 4320	MT0999	SETUP NULL TEST
180- 4325		CHECK FOR KAMIKAZE MODE
183- 4334	SUBR	EXECUTE PATTERN IN SUPERVISOR
189- 4403	MEMORY	TEST PATTERN ROUTINES
189- 4413	MTP000	BASIC DATA TEST
189- 4424	MTP001	ADDRESS TEST
189- 4436	MTP002	COMPLEMENT ADDRESS TEST (WRITE DOWN, READ UP)
192- 4451	MTPA03	3 XOR 9 WORST CASE NOISE TEST (WRITE)
192- 4476	MTPB03	3 XOR 9 WORST CASE NOISE TEST (READ)
194- 4494	MTPC03	TEST DATA SUBPROGRAM
194- 4503	MTPD03	TEST DATA SUBSUBPROGRAM
196- 4513	MTPA04	ROTATING ZEROS TEST
196- 4526	MTPB04	SUBR ROTATING BIT
196- 4535	MTP005	ROTATION ONES TEST
199- 4550	MTP006	INITIAL DATA TEST
202- 4594	MTP007	ADDRESS BIT TEST
204- 4634	MTP010	BYTE ADDRESSING TEST
207- 4671	MPT011	SINGLE BIT ERROR TEST
210- 4782	MTP012	WRITE BYTE CLEARS SBE TEST
213- 4860	MTP013	CREATE DOUBLE BIT ERROR TEST
218- 4929	MTP014	WRITE INHIBIT DURING DATIP WITH DBE TEST
221- 5010	MTP015	WRITE INHIBIT OF BYTE WITH DBE
224- 5087	MTP016	WRITE INHIBIT OF WORD WITH DBE
229- 5167	MTP017	HOLDING 1'S & 0'S TEST
232- 5201	MTP020	MARCHING 1'S & 0'S IN CHECK BITS TEST

TABLE OF CONTENTS

237-	5279	MTPA20	SLOW MARCHING 1'S & 0'S IN CHECK BITS TEST
244-	5416	MTPA21	MARCHING 1'S & 0'S PATTERN TEST
249-	5487	MTP022	REFRESH & SHIFTING DIAGONAL TEST
251-	5559	SUBR	REFRESH DELAY
254-	5582	MTPA24	FAST GALLOPING PATTERN TEST
256-	5626	MTPB24	FAST GALLOP PART B
256-	5634	MTPC24	FAST GALLOP PART C
259-	5645	MTP025	INTERRUPT ENABLE TEST
264-	5738	MTPA26	RANDOM DATA (WRITE)
264-	5745	MTPB26	RANDOM DATA (READ)
264-	5763	RANDOM	NUMBER SUBPROGRAM
264-	5776	RANDOM	NUMBER SUBSUBPROGRAM
266-	5784	MTO030	FLUSH OUT DBE'S
266-	5790	MTP031	SOB-A-LONG TEST
268-	5816	MTPA32	SKEWED UP ADDRESS TEST (WRITE)
268-	5826	MTPB32	SKEWED UP ADDRESS TEST (READ)
268-	5839	MTP033	WRITE RECOVERY TEST
270-	5859	MTP034	BRANCH GOBBLE TEST
271-	5905	MISC	SUBROUTINES
271-	5907	SUBR	COPY R0 TO R4, R1 TO R3, & R2 TO R5
271-	5913	FLIP	WARNING CONSTANTS IN WORST CASE NOISE TESTS
271-	5940	SUBR	WRITE BACKGROUND
274-	5953	SUBR	PRINT CONFIGURATION MAP
277-	6002	SUBR	TYPE CONFIGURATION
282-	6154	TRAP	PARITY ERROR HANDLER
284-	6200	TRAP	NON-EXISTANT MEMORY (HOLES) HANDLER
284-	6222	TRAP	TIMEOUT (TRAP TO 4) HANDLER
284-	6226	TRAP	MEMORY MANAGEMENT (TRAP TO 250) HANDLER
284-	6229	TRAP	RESERVED INSTRUCTION HANDLER
284-	6233	UNEXPECTED	IIST TRAP HANDLER
284-	6237	FIND	BAD SP, PC, & PSW FROM STACK
286-	6245	TRAP	KERNEL TRAP HANDLER
286-	6253	TRAP	ENERGIZE TRAP HANDLER
286-	6257	TRAP	DEENERGIZE TRAP HANDLER
286-	6261	TRAP	CACHON TRAP HANDLER
286-	6266	TRAP	CACHOFF TRAP HANDLER
289-	6273	TRAP	LOAD CSR TRAP HANDLER
291-	6302	TRAP	READ CSR TRAP HANDLER
291-	6321	TRAP	TEST (R1) & READ CSR CAREFULLY
294-	6354	TRAP	ECC DISABLE ALL CSR'S TRAP HANDLER
294-	6360	TRAP	ECC DISABLE OF 1 SELECTED CSR TRAP HANDLER
294-	6366	TRAP	MK11 INITIALIZE ALL CSR'S TRAP HANDLER
294-	6371	TRAP	MK11 INITIALIZE 1 SELECTED CSR TRAP HANDLER
294-	6376	TRAP	ENABLE SBE PARITY TRAPS ON ALL CSR'S
294-	6382	TRAP	ENABLE SBE PARITY TRAPS ON 1 SELECTED CSR
294-	6388	TRAP	WRITE CHECKBITS THRU ALL CSR'S TRAP HANDLER
294-	6395	TRAP	WRITE CHECKBITS THRU 1 SELECTED CSR TRAP HANDLER
297-	6405	TRAP	WAS THERE A SBE ON ANY CSR TRAP HANDLER
297-	6430	TRAP	WAS THERE A SBE IN 1 SELECTED CSR TRAP HANDLER
299-	6440	TRAP	WAS THERE A DBE ON ANY CSR TRAP HANDLER
299-	6465	TRAP	WAS THERE A DBE ON 1 SELECTED CSR TRAP HANDLER
301-	6479	TRAP	CLEAR ALL MK11 CSR'S TRAP HANDLER
301-	6483	TRAP	CLEAR 1 SELECTED MK11 CSR TRAP HANDLER
301-	6487	TRAP	ECC DISABLE, CHECH MODE, & WRITE CHECKBITS IN ALL CSR'S TRAP HANDLER
301-	6494	TRAP	ECC DISABLE, CHECH MODE, & WRITE CHECKBITS IN 1 SELFCTED CSR
303-	6503	SUBR	WRITE IN ALL CSR'S
303-	6518	TRAP	INVALIDATE BACKGROUND PATTERN

306-	6528	SUBR	GENERATE CHECK BITS
311-	6595	SUBR	MAPPER
311-	6627	TRAP	MAP KERNEL (ALMOST 1 TO 1) TRAP HANDLER
314-	6649		RELOCATE PROGRAM
318-	6718		UNRELOCATE PROGRAM
318-	6754		SETUP LOWER 16K OF UNIBUS MAP
320-	6767		MOVE BANKS
322-	6815	SUBR	MAP USER TO NEW BANK
322-	6835	SUBR	SETUP KERNEL PAR'S FOR NEW BANK
322-	6848	SUBR	SETUP KERNEL PAR'S FOR NEW LOADER BANK
325-	6861	SUBR	EXAMINE BANK
328-	6918	SUBR	BANK OK?
328-	6929	SUBR	INCREMENT PATTERN TESTING MK11'S
328-	6937	SUBR	SET HIGHEST PATTERN TESTING TYPE
328-	6941	SUBR	INCREMENT BANK & TEST
330-	6948	SUBR	INCREMENT MARGINS & TEST
330-	6976		DECREMENT MARGINS & TEST
332-	6989	SUBR	SET HIGHEST MARGIN
332-	7006	SUBR	REWRITE CORE HISTORY
334-	7024		BOOTSTRAP ROUTINE
336-	7053		HALT PROGRAM
336-	7062		SHUTDOWN DIAGNOSTIC
336-	7085		APT SHUTDOWN SEQUENCE
338-	7095		BLOCK MOVE SUBROUTINE
339-	7122		FIELD SERVICE MODE
339-	7124	SUBR	FIELD SERVICE COMMAND MODE
341-	7169	COMMAND 0	EXIT
341-	7187	FS	COMMAND 1 READ CSR
343-	7202	FS	COMMAND 2 LOAD CSR
345-	7231	FS	COMMAND 3 EXAMINE MEMORY
347-	7270	FS	COMMAND 4 MODIFY MEMORY
349-	7322	FS	COMMAND 5 SELECT BANK, MARGIN, & PATTERN
349-	7440	FS	COMMAND 6 TYPE CONFIGURATION MAP
352-	7447	FS	COMMAND 7 BATTERY BACKUP TEST
354-	7496	FS	COMMAND 8 SOB-A-LONG TEST
356-	7550	FS	COMMAND 9 SUPER TIGHT SCOPE LOOP
356-	7618	FS	COMMAND 10 ERROR SUMMARY
358-	7645	FS	COMMAND 11 REFRESH TEST
360-	7700	FS	COMMAND 12 SET FILL COUNT
360-	7710	FS	COMMAND 13 ENTER KAMIKAZE MODE
360-	7715	FS	COMMAND 14 EXIT KAMIKAZE MODE
360-	7721	FS	COMMAND 15 TURN CACHE OFF
360-	7727	FS	COMMAND 16 TURN CACHE ON
360-	7733	FS	COMMAND 17 RUN ONLY MULTIPOINT TESTS
362-	7739	FS	COMMAND 18 RESUME RUNNING BOTH SINGLE & MULTIPOINT TESTS
362-	7744	FS	COMMAND 19 TEST ONLY SELECTED BANKS
362-	7763	FS	COMMAND 20 RESUME TESTING ALL BANKS
364-	7775	SUBR	DETERMINE CORRECT CSR
366-	3		MULTIPROCESSOR SLAVE DISPATCHER
368-	66		MOVE PROGRAM TO NEW BANK
368-	80		WRITE ONLY PATTERN IN HI BYTE
370-	100		READ ONLY PATTERN IN HI BYTE
370-	130		SLAVE PATTERNS
372-	145		EXECUTION CONTENTION TEST
374-	164		PORT ARBITRATION SYMMETRY TEST
376-	219		STOP SLAVE PROGRAM
376-	226		WRITE ONLY ADDRESS PATTERN IN HI BYTE

376-	230	READ ONLY ADDRESS PATTERN IN HI BYTE
378-	262	RUN FIVE PATTERNS IN DESIGNATED 1/4 BANK
378-	279	WRITE & READ A SKEWED UP ADDRESS TEST
380-	301	SETUP FOR ASRB TEST
382-	338	RECOVER FROM TASK13 - TRAP FROM IIST
384-	356	RESET FROM ASRB TEST
384-	361	RUN SLAVE IN CSR TESTS
384-	365	SET MARGIN 6, CPU HAS I/O PRIORITY
384-	370	CREATE STALE DATA TEST
386-	385	CACHE FLUSH TEST
386-	422	CACHE FLUSH TEST (FOR PAR'S)
388-	434	SETUP EXECUTION CONTENTION TEST
390-	458	MULTIPORT ASRB TEST (IN SUPERVISOR SPACE)
392-	541	BALANCE TEST
394-	568	ERROR DATA (SUPERVISOR) SETUP STUFF
394-	582	DATA WAS 3 WORDS
396-	614	GET DATA FROM ABORTED AREA IF POSSIBLE
398-	634	POWER FAIL AUTO RESTART
398-	635	ROUTINE POWER DOWN AND UP
404-	788	MULTIPLE CPU'S POWERING UP
404-	795	POWER FAIL WHILE RELOCATED
406-	820	POWER UP FROM BANK 0 TO RELOCATION
408-	858	IO SUBROUTINES
408-	860	ROUTINE TYPE
409-	949	MULTIPORT SLAVE STARTER
411-	1032	HAVE SLAVES RUN CSR TESTS
413-	1064	MOVE SLAVES TO THEIR OWN BANKS
415-	1111	RUN NORMAL MULTIPROCESSOR TESTS
417-	1187	INITIALIZE THE IIST
417-	1207	INIT IIST & DISABLE BOOTS & INTERRUPTS
419-	1221	SLAVES MAP
421-	1241	MULTIPORT ACCESS PATHS TEST
424-	1306	MULTIPORT ADDRESS TEST
426-	1369	MULTIPORT ASYNCHRONOUS ADDRESS UNIQUENESS TEST
428-	1417	MULTIPORT SKEWED UP ADDRESS TEST
430-	1458	MULTIPORT PORT ARBITRATION SYMMETRY TEST
432-	1506	MULTIPORT PORT I/O PRIORITY TEST
436-	1575	CHECK FOR PROPER SKEWING OF ACCESSES
436-	1600	WAIT FOR 5 SECONDS FOR A SLAVE
438-	1615	MULTIPORT EXECUTION CONTENTION TEST
438-	1662	MULTIPORT ASRB TEST
440-	1666	MULTIPORT CACHE FLUSH TEST
442-	1717	STOP SLAVES
444-	1739	ERROR DATA SETUP
449-	1988	DATA WAS A WORD
449-	2000	DATA WAS A BYTE
451-	2013	DATA WAS A 7 BIT BYTE
451-	2028	DETERMINE XOR OF GOOD & BAD
453-	2037	LOG ERROR ON BAD BANK
457-	2120	ROUTINE SCOPE HANDLER
458-	2176	SUBR DISPLAY
460-	2199	ROUTINE ERROR HANDLER
463-	2282	ROUTINE ERROR MESSAGE TYPEOUT
476-	2581	SUBR WHO'S BOX IS THIS?
478-	2645	SUBR DETAILED ERROR REPORT
484-	2754	QUE MESSAGES FROM SLAVE CPU'S
486-	2789	ROUTINE BINARY TO OCTAL (ASCII) AND TYPE

FMKABO 1170 MAIN MEMORY DIAG 2 MACRO M1115 03-AUG-79 16:50
TABLE OF CONTENTS

FO 0601

487-	2867	ROUTINE CONVERT BINARY TO DECIMAL AND TYPE
488-	2924	ROUTINE ITTY INPUT
490-	3007	CONTROL T
490-	3033	CONTROL S & CONTROL Q
492-	3147	ROUTINE READ AN OCTAL NUMBER FROM THE ITTY
492-	3196	ROUTINE READ A DECIMAL NUMBER FROM THE ITTY
493-	3255	ROUTINE SAVE AND RESTORE R0-R5
494-	3291	ROUTINE RANDOM NUMBER GENERATOR
496-	3321	ROUTINE DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT
497-	3363	TABLES
497-	3365	APT MAILBOX-ETABLE
498-	3444	ROUTINE TRAP DECODER
500-	3471	TRAP TABLE
502-	3571	ODT (CEMKA) DATA AREA
549-	4403	TABLE ERROR POINTER
561-	4699	ERROR DATA TAGS (DT)
563-	4728	ERROR DATA FORMATS (DF)
565-	4746	ERROR MESSAGES (EM)
567-	4806	ERROR DATA HEADERS (DH)
569-	4838	MESSAGES

1

000000

LST\$\$ 0

:

.TITLE CEMKABO 1170 MAIN MEMORY DIAG 1
.IDENT /X01.60/

2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33

IDENTIFICATION

PRODUCT CODE: AC-C644B-MC
PRODUCT NAME: CEMKABO 1170 MAIN MEMORY DIAG
PRODUCT DATE: 31 JUL 1979
MAINTAINER: PRODUCT ENHANCEMENT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1978,1979 DIGITAL EQUIPMENT CORPORATION

36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88

REVISION HISTORY
=====

REVISION	VERSION	DATE	AUTHOR	CHANGES
=====	=====	=====	=====	-----
CEMKA	V03.00	24-FEB-78	KAY R. FISHER	NONE = NEW PROGRAM
CEMKAB	V09.00	9-OCT-78	KAY R. FISHER	1. ADD MULTIPROCESSOR CAPABILITIES 2. ADD SOFT ERROR TEST FOR ALPHA PARTICLES IN MOS CHIPS 3. ADD THE FOLLOWING FIELD SERVICE COMMANDS A. KAMIKAZE MODE B. CACHE ON/OFF C. SELECT ONLY MULTIPORT TESTS D. TEST ONLY SELECTED BANKS 4. EXPAND DETAILED ERROR REPORT TO INCLUDE ALL CSR'S AND SP AT TIME OF ERROR 5. SPEED UP GALLOPING PATTERN BY EXECUTING OUT OF THE PAR'S 6. OPTIMIZE THE SHIFTING DIAGONAL PATTERN BY SHARING CODE WITH THE REFRESH PATTERN 7. ADD BRANCH GOBBLE PATTERN 8. ADD WRITE RECOVERY PATTERN 9. REPAIRED THE FOLLOWING BUGS A. UNDER APT FIELD SERVICE COMMANDS 1 & 2 B. UNDER APT USE OF ENVIRONMENTAL MODE DID NOT MEET APT SPEC . FATAL PARITY ERRORS AT LOAD TIME THAT WERE CAUSED BY .BLKW STATEMENTS D. RESTART AT 202 CLEARS ERROR ACCOUNTING E. INTERMITTANT SINGLE BIT ERRORS IN CHECKBITS NOT DETECT F. ERROR COUNT WAS MOD 32K G. ODT HANGS AFTER 256 OPENS H. WRONG PC PRINTED ON SOME ERROR I. HIADRS LOADRS REG'S NOT CLEARE AFTER SIZING J. ACT MEMORY SIZE DEPENDENT BIT DEFINED WRONG K. UNABLE TO RUN WITHOUT A LINE CLOCK

90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110

.SBTTL OPERATIONAL SWITCH SETTINGS
.SBTTL SWITCH REGISTER DEFINITIONS

	SWITCH	USE
.SBTTL	*	
.SBTTL	*	
.SBTTL	*	
.SBTTL	*	
.SBTTL	15	HALT ON ERROR
.SBTTL	14	LOOP ON TEST
.SBTTL	13	INHIBIT ERROR TYPEOUTS
.SBTTL	12	INHIBIT RELOCATION
.SBTTL	11	QUICK VERIFY / INHIBIT MARGIN TESTING
.SBTTL	10	BELL ON ERROR
.SBTTL	9	LOOP ON ERROR
.SBTTL	8	HALT PROGRAM (UNRELOCATED & RESTORE LOADERS)
.SBTTL	7	DETAILED ERROR REPORTS
.SBTTL	6	PRINT CONFIGURATION MAP
.SBTTL	5	LIMIT MAX ERRORS PER BANK
.SBTTL	4	FAT TERMINAL (132 COLUMNS OR BETTER)
.SBTTL	3	TEST MODE - SEE DOCUMENT
.SBTTL	2	TEST MODE - SEE DOCUMENT
.SBTTL	1	TEST MODE - SEE DOCUMENT
.SBTTL	0	DETECT SINGLE BIT ERRORS

113 000000
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131 163000
132 000001
133 000000

```

.ENABL ABS
.ENABL AMA
.DSABL GBL
;NOTE: CEMKAB.SML IS THE SUPER.MAC SOURCE AND IS RELEASED WITH
;THIS PROGRAM. ALL THESE .MCALL STATEMENTS REFERENCE THAT FILE.
.MCALL SMACIT,..PUSH,..POP,..TAG,..BRAN,..EMIT,..EMITN,..EMITL,..EMITR
.MCALL .IFOPR,..IS,..GENBR,..OPADD,..OPSUB,CLEAR,SET,CLEARB,SETB
.MCALL RNE,REQ,RLT,RGE,RGT,RLE,RPL,RMI,RHI,RLOS,RHIS,RLO,RCS,RCC
.MCALL IF,..OR,..IFARI,..LEAVE,..GOTO,OR,AND,THEN,ELSE,WHILE,CASE
.MCALL FOR,TO,DOWNTO,REPEAT,UNTIL,THRU,END,BEGIN
.MCALL $$END,LEAVE,JUMPTO,GOTO,PUSH,POP,LET
.MCALL .SIMPLE,..ARITH,ORB,ANDB,IFB,UNTILB,WHILEB,ON.ERROR,ON.NOERROR
.MCALL $CALL,$RETURN

.NLIST TTM ;I WANT FAT PAPER!
.LIST MC,SYM ;LIST MACRO CALLS, SYMBOL TABLE
.NLIST MD,CND,ME ;DON'T LIST MACRO DEFS & CONDITIONALS & EXPANSIONS
;LST$$- 0 ;DEFINED TO LIST SUPERMAC EXPANSIONS
$SWR= 163000 ;USE THESE SYSMAC SWITCHES
$TN= 1 ;FIRST TEST NUMBER TO ONE(1)
SMACIT

```

DEFINE TRAPS

136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192

```

.SBTTL DEFINE TRAPS
:ALL ENTRIES HERE MUST HAVE A CORRESPONDING ENTRY IN THE
:TRAP TABLE '$TRPAD' (NEAR END OF PROGRAM).
:*TRAP DEFINITIONS
:
:HERE IS HOW TRAPS WORK IN THIS PROGRAM
:
:ALL TRAPS EXECUTE A 'TRAP' INSTRUCTION WHICH TAKES THE PROGRAM
:TO SYMBOLIC LOCATION '$TRAP'
:
:AT $TRAP THE PROGRAM PICKS UP THE RIGHT BYTE OF THE TRAP INSTRUCTION
:AND INDEXES INTO A TABLE AT LOCATION '$TRPAD' WHICH SENDS THE PROGRAM TO
:THE SPECIFIC ROUTINE TO HANDLE THAT SPECIFIC TRAPS TASK.
:
:THE ULTIMATE DESTINATION OF A TRAP INSTRUCTION CAN BE GUESSED AT AS FOLLOWS
:
:EXAMPLE:      NOP
:              NOP
:              NOP
:              KERNEL           ;ENTER KERNEL MODE
:              NOP
:
:      ADD A DOLLAR SIGN TO THE SYMBOLIC NAME AND CHECK THE CRF FOR SOMETHING CLOSE
:      IS THIS CASE THE CRF HAS $KERNE LISTED AS 032546
:      AT LOCATION 32546 YOU FIND THE ROUTINE $KERNEL
:
:      NOTE THAT CRF SYMBOLS ARE TRUCNATED TO 6 CHARACTERS
:      SYMBOLIC NAMES GREATER THAT 6 CHARACTERS ARE USED SO I CAN
:      REMEMBER WHAT THEY MEAN!
:
:      ALL GOOD TRAP ROUTINES RETURN VIA AN 'RTI' INSTRUCTION
TYPEIT= 104401      ;;TTY TYPEOUT ROUTINE
TYPOC= 104402      ;;TYPE OCTAL NUMBER (WITH LEADING ZEROS)
TYPUS= 104403      ;;TYPE OCTAL NUMBER (NO LEADING ZEROS)
:TYPON= 104404      ;;TYPE OCTAL NUMBER (AS PER LAST CALL)
TYPDS= 104405      ;;TYPE DECIMAL NUMBER (WITH SIGN)
:TYPBN= 104406      ;;TYPE BINARY (ASCII) NUMBER
:
GTSWR= 104407      ;;GET SOFT-SWR SETTING
CKSWR= 104410      ;;TEST FOR CHANGE IN SOFT-SWR
:
RDCHR= 104411      ;;TTY TYPEIN CHARACTER ROUTINE
RDLIN= 104412      ;;TTY TYPEIN STRING ROUTINE
RDOCT= 104413      ;;READ AN OCTAL NUMBER FROM TTY
RDDEC= 104414      ;;READ A DECIMAL NUMBER FROM TTY
:
SAVREG= 104415     ;;SAVE R0-R5 ROUTINE
RESREG= 104416     ;;RESTORE R0-R5 ROUTINE
:
KERNEL= 104417     ;ENTER KERNEL MODE
:
ENERGIZE 104420     ;TURN ON MEMORY MANAGEMENT & TRAPS
DEENERGIZE 104421 ;TURN OFF MEMORY MANAGEMENT & TRAPS
:
KMAP 104422        ;MAP KERNEL 1 TO 1
:
CACHON 104423      ;TURN ON CACHE

```

DEFINE TRAPS

```

193      104424      CACHOFF=104424      ;TURN OFF CACHE
194
195      104425      LOADCSR=104425      ;LOAD CORRECT CSR
196      104426      READCSR=104426      ;READ CORRECT CSR
197
198      104427      PERR01= 104427      ;PROGRAM DETECTED ERROR
199      104430      PERR02= 104430      ;PROGRAM DETECTED ERROR
200      104431      PERR03= 104431      ;PROGRAM DETECTED ERROR
201      104432      PERR04= 104432      ;PROGRAM DETECTED ERROR
202      104433      PERR07= 104433      ;PROGRAM DETECTED ERROR
203      104434      PERR10= 104434      ;PROGRAM DETECTED ERROR
204      104435      PERR11= 104435      ;PROGRAM DETECTED ERROR
205      104436      PERR12= 104436      ;PROGRAM DETECTED ERROR
206      104437      PERR13= 104437      ;PROGRAM DETECTED ERROR
207      104440      PERR14= 104440      ;PROGRAM DETECTED ERROR
208      104441      PERR15= 104441      ;PROGRAM DETECTED ERROR
209      104442      PERR16= 104442      ;PROGRAM DETECTED ERROR
210      104443      PERR17= 104443      ;PROGRAM DETECTED ERROR
211      104444      PERR20= 104444      ;PROGRAM DETECTED ERROR
212      104445      PERR21= 104445      ;PROGRAM DETECTED ERROR
213      104446      PERR22= 104446      ;PROGRAM DETECTED ERROR
214      104447      PERR23= 104447      ;PROGRAM DETECTED ERROR
215      104450      PERR24= 104450      ;PROGRAM DETECTED ERROR
216      104451      PERR25= 104451      ;PROGRAM DETECTED ERROR
217      104452      PERR26= 104452      ;PROGRAM DETECTED ERROR
218      104453      PERR27= 104453      ;PROGRAM DETECTED ERROR
219      104454      PERR30= 104454      ;PROGRAM DETECTED ERROR
220      104455      PERR31= 104455      ;PROGRAM DETECTED ERROR
221      104456      PERR32= 104456      ;PROGRAM DETECTED ERROR
222      104457      PERR33= 104457      ;PROGRAM DETECTED ERROR
223      104460      PERR34= 104460      ;PROGRAM DETECTED ERROR
224      104461      PERR35= 104461      ;PROGRAM DETECTED ERROR
225      104462      PERR36= 104462      ;PROGRAM DETECTED ERROR
226      104463      PERR37= 104463      ;PROGRAM DETECTED ERROR
227      104464      PERR40= 104464      ;PROGRAM DETECTED ERROR
228      104465      PERR41= 104465      ;PROGRAM DETECTED ERROR
229      104466      PERR42= 104466      ;PROGRAM DETECTED ERROR
230      104467      PERR43= 104467      ;PROGRAM DETECTED ERROR
231
232      104470      ECCDIS= 104470      ;DISABLE ECC ON ALL CSR'S
233      104471      ECC1DIS=104471      ;DISABLE ECC ON 1 SELECTED CSR
234      104472      ECCINIT=104472      ;INITIALIZE ALL MK11 CSR'S
235      104473      ECC1INIT=104473      ;INITIALIZE 1 SFLECTED MK11 CSR
236      104474      CBCSR= 104474      ;WRITE GENERATED CHECKBITS IN ALL CSR'S
237      104475      CB1CSR= 104475      ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
238      104476      WASSBE= 104476      ;WAS THERE A SBE ON ANY CSR?
239      104477      WAS1SBE=104477      ;WAS THERE A SBE ON 1 SELECTED CSR?
240      104500      WASDBE= 104500      ;WAS THERE A DBE ON ANY CSR?
241      104501      WAS1DBE=104501      ;WAS THERE A DBE ON 1 SELECTED CSR?
242      104502      CLRCSR= 104502      ;CLEAR ALL CSR'S
243      104503      CLR1CSR=104503      ;CLEAR 1 SELECTED CSR
244      104504      CHKDIS= 104504      ;DISABLE ECC & WRITE CHECKBITS FROM ALL CSR'S
245      104505      CHK1DIS=104505      ;DISABLE ECC & WRITE CHECKBITS FROM 1 SELECTED CSR
246      104506      ENASBE= 104506      ;ENABLE TRAPS ON SBE'S FROM ALL CSR'S
247      104507      ENA1SBE=104507      ;ENABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
248      04510      TSTREAD=104510      ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
249      104511      INVALID=104511      ;INVALIDATE BACKGROUND PATTERN ON 'BANK'

```

DEFINE BASIC PDP11 STUFF

```

252          .SBTTL DEFINE BASIC PDP11 STUFF
253
254          ;*INITIAL ADDRESS OF THE STACK POINTER
255          STACK= 2000          ;;FIRST ADDRESS OF THE STACK
256          KERSTK= STACK       ;;KERNEL STACK
257          SUPSTK= 740         ;;SUPERVISOR STACK
258          USESTK= 700         ;;USER STACK
259          ERROR=EMT           ;;BASIC DEFINITION OF ERROR CALL
260          SCOPE=IOT           ;;BASIC DEFINITION OF SCOPE CALL
261          PSW= 177776         ;;PROCESSOR STATUS WORD
262          ;STKLM=177774       ;;STACK LIMIT REGISTER
263          ;PIRQ= 177772       ;;PROGRAM INTERRUPT REQUEST REGISTER
264          DSWR= 177570        ;;HARDWARE SWITCH REGISTER
265          DDISP= 177570       ;;HARDWARE DISPLAY REGISTER
266          LKS= 177546        ;;LINE CLOCK (KW11-L) STATUS REGISTER
267
268          ;*MISCELLANEOUS DEFINITIONS
269          HT= 11              ;;CODE FOR HORIZONTAL TAB
270          LF= 12              ;;CODE LINE FEED
271          CR= 15              ;;CODE CARRIAGE RETURN
272          CRLF= 200           ;;CODE FOR CARRIAGE RETURN-LINE FEED
273
274          ;*GENERAL PURPOSE REGISTER DEFINITIONS
275          ;SP=R6               ;;STACK POINTER
276          ;KSP=SP             ;;KERNEL STACK POINTER
277          SSP=SP              ;;SUPERVISOR STACK POINTER
278          USP=SP              ;;USER STACK POINTER
279          ;PC=R7              ;;PROGRAM COUNTER
280
281          ;*'SWITCH REGISTER' SWITCH DEFINITIONS
282          SW15= 100000
283          SW14= 40000
284          SW13= 20000
285          SW12= 10000
286          SW11= 4000
287          SW10= 2000
288          SW9= 1000
289          SW8= 400
290          SW7= 200
291          SW6= 100
292          SW5= 40
293          SW4= 20
294          SW3= 10
295          SW2= 4
296          SW1= 2
297          SW0= 1
298
299          ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
300          BIT15= 100000
301          BIT14= 40000
302          BIT13= 20000
303          BIT12= 10000
304          BIT11= 4000
305          BIT10= 2000
306          BIT9= 1000
307          BIT8= 400
308          BIT7= 200

```

```

309      000100      BIT6= 100
310      000040      BIT5= 40
311      000020      BIT4= 20
312      000010      BIT3= 10
313      000004      BIT2= 4
314      000002      BIT1= 2
315      000001      BIT0= 1
316
317      : *BASIC "CPU" TRAP VECTOR ADDRESSES
318      000004      ERRVEC= 4      :: TIME OUT AND OTHER ERRORS
319      000010      RESVEC= 10     :: RESERVED AND ILLEGAL INSTRUCTIONS
320      : TBITVEC= 14      :: 'T' BIT
321      : TRTVEC= 14      :: TRACE TRAP
322      : BPTVEC= 14      :: BREAKPOINT TRAP (BPT)
323      000020      IOTVEC= 20     :: INPUT/OUTPUT TRAP (IOT) **SCOPE**
324      000024      PWRVEC= 24     :: POWER FAIL
325      000030      EMTVEC= 30     :: EMULATOR TRAP (EMT) **ERROR**
326      000034      TRAPVEC= 34    :: 'TRAP' TRAP
327      000060      TKVEC= 60      :: TTY KEYBOARD VECTOR
328      : TPVEC= 64      :: TTY PRINTER VECTOR
329      : LKVEC= 100     :: LINE CLOCK (KW11-L) VECTOR
330      000114      CACHVEC= 114   :: CACHE ERROR INTERRUPT VECTOR
331      000114      PARVEC= CACHVEC
332      : PIRQVEC= 240    :: PROGRAM INTERRUPT REQUEST VECTOR
333      000250      MMVEC= 250     :: MEMORY MANAGEMENT VECTOR
334      : SBTTL DEFINE CACHE REGISTERS
335      177740      LOADRS = 177740 :: LOWER 16 BITS OF ADDRESS THAT CAUSED ERROR
336      177742      HIADRS = 177742 :: UPPER SIX BITS OF ADDRESS THAT CAUSED ERROR
337      177744      MEMERR = 177744 :: CACHE ERROR REGISTER
338      177746      CONTRL = 177746 :: MEMORY CONTROL REGISTER
339      177750      MAINT = 177750 :: MEMORY MAINTENANCE REGISTER
340      : HITMIS - 177752      :: HIT MISS REGISTER '1' IMPLIES HIT IN CACHE
341
342      : SBTTL DEFINE CPU REGISTERS
343      177760      SIZELO - 177760 :: MEMORY SIZE REGISTER NUMBER TO PUT INTO A PAR
344      : TO GET TO THE LAST 32 WORDS OF MEMORY
345      : SIZEHI = 177762      :: HIGH SIZE REGISTER, RESERVED FOR FUTURE USE
346      : CURRENTLY ALL ZERO
347      177764      SYSTID = 177764 :: SYSTEM ID REGISTER
348      177766      CPUERR - 177766 :: CPU ERROR REGISTER HOLDS CONDITION THAT CAUSED
349
350      : SBTTL DEFINE MEMORY MANAGEMENT REGISTERS
351      : *MEMORY MANAGEMENT STATUS REGISTER ADDRESSES
352      177572      MMR0= 177572
353      177574      MMR1= 177574
354      177576      MMR2= 177576
355      172516      MMR3= 172516
356
357      : *USER 'I' PAGE DESCRIPTOR REGISTERS
358      177600      UIPDR0= 177600
359      : UIPDR1= 177602
360      : UIPDR2= 177604
361      : UIPDR3= 177606
362      : UIPDR4= 177610
363      : UIPDR5= 177612
364      : UIPDR6= 177614
365      : UIPDR7= 177616
    
```

DEFINE MEMORY MANAGEMENT REGISTERS

```

366
367      ;*USER 'D' PAGE DESCRIPTOR REGISTERS
368      :UDPDR0      177620
369      :UDFDR1=    177622
370      :UDPDR2=    177624
371      :UDPDR3=    177626
372      :UDPDR4=    177630
373      :UDPDR5=    177632
374      :UDPDR6=    177634
375      177636      :UDPDR7= 177636
376
377      ;*USER 'I' PAGE ADDRESS REGISTERS
378      FASTCITY=UIPAR0
379      177640      UIPAR0= 177640      ;PATTERN PROGRAM SPACE
380      :UIPAR1=    177642      ;PATTERN PROGRAM SPACE
381      177644      UIPAR2= 177644      ;PATTERN PROGRAM SPACE
382      177646      UIPAR3= 177646      ;PATTERN PROGRAM SPACE
383      177650      UIPAR4= 177650      ;PATTERN PROGRAM SPACE
384      177652      UIPAR5= 177652      ;PATTERN PROGRAM SPACE
385      177654      UIPAR6= 177654      ;PATTERN PROGRAM SPACE
386      177656      UIPAR7= 177656      ;PATTERN PROGRAM SPACE
387
388      ;*USER 'D' PAGE ADDRESS REGISTERS
389      177660      UDPAR0= 177660      ;PATTERN PROGRAM SPACE
390      177662      UDPAR1= 177662      ;PATTERN PROGRAM SPACE
391      :UDPAR2=    177664      ;PATTERN PROGRAM SPACE
392      :UDPAR3=    177666      ;PATTERN PROGRAM SPACE
393      :UDPAR4=    177670      ;PATTERN PROGRAM SPACE
394      :UDPAR5=    177672      ;PATTERN PROGRAM SPACE
395      :UDPAR6=    177674      ;PATTERN PROGRAM SPACE
396      177676      UDPAR7= 177676      ;PATTERN PROGRAM SPACE
397
398      ;*SUPERVISOR 'I' PAGE DESCRIPTOR REGISTERS
399      172200      SIPDR0= 172200
400      :SIPDR1=    172202
401      :SIPDR2=    172204
402      :SIPDR3=    172206
403      :SIPDR4=    172210
404      :SIPDR5=    172212
405      :SIPDR6=    172214
406      :SIPDR7=    172216
407
408      ;*SUPERVISOR 'D' PAGE DESCRIPTOR REGISTERS
409      :SDPDR0=    172220
410      :SDPDR1=    172222
411      :SDPDR2=    172224
412      :SDPDR3=    172226
413      :SDPDR4=    172230
414      :SDPDR5=    172232
415      :SDPDR6=    172234
416      172236      SDPDR7= 172236
417
418      ;*SUPERVISOR 'I' PAGE ADDRESS REGISTERS
419      172240      SIPAR0= 172240
420      :SIPAR1=    172242
421      :SIPAR2=    172244
422      172246      SIPAR3= 172246      ;TEST AREA

```

```
423 :SIPAR4= 172250 :TEST AREA
424 :SIPAR5= 172252 :TEST AREA
425 :SIPAR6= 172254 :TEST AREA
426 :SIPAR7= 172256
427
428 ;*SUPERVISOR 'D' PAGE ADDRESS REGISTERS
429 172260 SDPAR0= 172260
430 :SDPAR1= 172262
431 :SDPAR2= 172264
432 :SDPAR3= 172266
433 :SDPAR4= 172270
434 :SDPAR5= 172272
435 :SDPAR6= 172274
436 172276 SDPAR7= 172276
437
438 ;*KERNEL 'I' PAGE DESCRIPTOR REGISTERS
439 172300 KIPDR0= 172300
440 :KIPDR1= 172302
441 :KIPDR2= 172304
442 :KIPDR3= 172306
443 :KIPDR4= 172310
444 :KIPDR5= 172312
445 :KIPDR6= 172314
446 :KIPDR7= 172316
447
448 ;*KERNEL 'D' PAGE DESCRIPTOR REGISTERS
449 :KDPDR0= 172320
450 :KDPDR1= 172322
451 :KDPDR2= 172324
452 :KDPDR3= 172326
453 :KDPDR4= 172330
454 :KDPDR5= 172332
455 :KDPDR6= 172334
456 172336 KDPDR7= 172336
457
458 ;*KERNEL 'I' PAGE ADDRESS REGISTERS
459 172340 KIPAR0= 172340
460 :KIPAR1= 172342
461 :KIPAR2= 172344
462 :KIPAR3= 172346
463 172350 KIPAR4= 172350
464 172352 KIPAR5= 172352
465 172354 KIPAR6= 172354
466 172356 KIPAR7= 172356
467
468 ;*KERNEL 'D' PAGE ADDRESS REGISTERS
469 172360 KDPAR0= 172360
470 :KDPAR1= 172362
471 :KDPAR2= 172364
472 :KDPAR3= 172366
473 :KDPAR4= 172370
474 :KDPAR5= 172372
475 :KDPAR6= 172374
476 172376 KDPAR7= 172376
477
```



```

480          .SBTTL DEFINE UNIBUS MAP REGISTERS
481          :*THE LOWER 16 BITS OF THE MAP REGISTERS ARE LABELED 'MAPLXX'
482          :*THE UPPER 6 BITS OF THE MAP REGISTERS ARE LABELED 'MAPHXX'
483          170200      MAPL0 = 170200
484          170202      MAPH0 = 170202
485          170204      MAPL1 = 170204
486          :MAPH1 = 170206
487          :MAPL2 = 170210
488          :MAPH2 = 170212
489          :MAPL3 = 170214
490          :MAPH3 = 170216
491          :MAPL4 = 170220
492          :MAPH4 = 170222
493          :MAPL5 = 170224
494          :MAPH5 = 170226
495          :MAPL6 = 170230
496          :MAPH6 = 170232
497          :MAPL7 = 170234
498          :MAPH7 = 170236
499          :MAPL10 = 170240
500          :MAPH10 = 170242
501          :MAPL11 = 170244
502          :MAPH11 = 170246
503          :MAPL12 = 170250
504          :MAPH12 = 170252
505          :MAPL13 = 170254
506          :MAPH13 = 170256
507          :MAPL14 = 170260
508          :MAPH14 = 170262
509          :MAPL15 = 170264
510          :MAPH15 = 170266
511          :MAPL16 = 170270
512          :MAPH16 = 170272
513          :MAPL17 = 170274
514          :MAPH17 = 170276
515          :MAPL20 = 170300
516          :MAPH20 = 170302
517          :MAPL21 = 170304
518          :MAPH21 = 170306
519          :MAPL22 = 170310
520          :MAPH22 = 170312
521          :MAPL23 = 170314
522          :MAPH23 = 170316
523          :MAPL24 = 170320
524          :MAPH24 = 170320
525          :MAPL25 = 170324
526          :MAPH25 = 170326
527          :MAPL26 = 170330
528          :MAPH26 = 170332
529          :MAPL27 = 170334
530          :MAPH27 = 170336
531          :MAPL30 = 170340
532          :MAPH30 = 170342
533          :MAPL31 = 170344
534          :MAPH31 = 170346
535          :MAPL32 = 170350
536          :MAPH32 = 170352

```

```

537      :MAPL33 = 170354
538      :MAPH33 = 170356
539      :MAPL34 = 170360
540      :MAPH34 = 170362
541      :MAPL35 = 170364
542      :MAPH35 = 170366
543      170370      :MAPL36 = 170370
544      170372      :MAPH36 = 170372
545      :MAPL37 = 170374
546      170376      :MAPH37 = 170376

```

.SBTTL DEFINE SOFTWARE SWITCH & DISPLAY REGISTERS

```

548      000174      DISPREG=174
549      000176      SWREG= 176
550      000176

```

.SBTTL DEFINE MK11 REGISTERS

```

552      172100      MK11ADD=172100
553      172100

```

.SBTTL DEFINE PARAMETERS

```

556      060000      FIRST=60000      ;START OF THE 16K TEST PATTERN AREA
557      157776      LAST=157776      ;END OF THE 16K TEST PATTERN AREA
558      040000      SIZE=40000      ;SIZE OF THE 16K TEST PATTERN AREA (FOR SOB INSTRUCTIONS)
559      011661      SECONDS=11661    ;CONSTANT FOR LENGTH OF TIME FOR HUNG CPU TEST

```

.SBTTL DEFINE MASTER & SLAVE BITS

```

560      000020      MASTER=20
561      000020
562      000040      SLAVE1=40
563      000100      SLAVE2=100
564      000200      SLAVE3=200

```

567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603

```

.LIST MD ;BE NICE TO SEE MY DEFINITIONS
.SBTTL MACRO FATAL
***** FATAL *****
:FATAL IS USED TO REPORT FATAL ERRORS (ERRORS THAT PREVENT
THE PROGRAM FROM CONTINUING).
*****
.MACRO FATAL ARG ;***MACRO***MACRO***MACRO***
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
INC FATAL$ ;SET FATAL INDICATOR
ERROR +ARG
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM FATAL

.SBTTL MACRO TYPE
.MACRO TYPE ARG
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
.IF B ARG
TYPEIT
.IFF
TYPEIT ,ARG
.ENDC
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM TYPE

```

MACRO NEWTST

606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653

```

.SBTTL MACRO NEWTST
***** NEWTST *****
:NEWTST IS USED AS THE FIRST INSTRUCTION OF A TEST.
:IT WILL:
:1) GENERATE A TEST NUMBER FOR THE LABEL OF THIS TEST
:2) PUT STARS BEFORE AND AFTER A MESSAGE
:ARGUMENTS
:1) ASCII -- THIS IS THE MESSAGE THAT WILL APPEAR
:           ON THE LISTING
:2) ICOUNT -- IF NON-BLANK AND BIT 11 OF $SWR = 1 IT WILL BE
:           THE NUMBER OF ITERATIONS TO MAKE ON THIS TEST
:3) RETURN -- IF NON-BLANK WILL BE THE ADDRESS TO
:           WHICH THE NEXT SCOPE STATEMENT WILL
:           LOOP BACK TO.
:4) COMAND -- IF NON-BLANK WILL BE THE FIRST
:           INSTRUCTION OF THE TEST
:           IF BLANK SCOPE WILL BE THE
:           FIRST INSTRUCTION
*****
.MACRO NEWTST ASCII,ICOUNT,RETURN,COMAND
$STN=1
$NWTST=0
.NLIST MC
.IF B <COMAND>
$$NEWTST \ $TN,<ASCII>,<SCOPE>
.IFF
$$NEWTST \ $TN,<ASCII>,<COMAND>
.ENDC
.NLIST
.LIST ME
.LIST
.IF NE 4000&$SWR
.IF NB ICOUNT
.IF LE <ICOUNT-1>
MOV #1,$TIMES ;;DO 1 ITERATION
.IFF
MOV #ICOUNT,$TIMES ;;DO ICOUNT ITERATIONS
.ENDC
.ENDC
.IF NB RETURN
MOV #RETURN,$LPADR ;;SET SCOPE LOOP ADDRESS
.ENDC
.ENDC
.NLIST
.LIST MC
.LIST ME
.NLIST ME
.ENDM NEWTST

```

```
656 .SBTTL MACRO $$NEWTEST
657 .MACRO $$NEWTEST A,ASC,COMND
658 .IRP ASCII,<ASC>
659 .IF EQ $NWST
660 $NWST=1
661 .SBTTL T'A' ASCII
662 .NLIST
663 .LIST ME
664 .LIST
665 .....
666 :*TEST A ASCII
667 .IFF
668 ASCII
669 .ENDC
670 .ENDM
671 .....
672 TST'A: COMND
673 .NLIST ME
674 $TN=$TN+1
675 .ENDM $$NEWTEST
676
677 .SBTTL MACRO SUBTST
678 ..... SUBTST .....
679
680 :THIS MACRO WILL FORMAT A SUBTEST HEADING WITH STARS
681 :A .SBTTL WILL BE FORCED & .NLISTED FOR THE TABLE OF CONTENTS.
682
683 :ARGUMENT:
684 :1) TXT -- THIS IS THE MESSAGE THAT WILL APPEAR IN THE TABLE OF CONTENTS & LISTING.
685
686 :EXAMPLE: SUBTST <<THIS IS A FUN SUBTST>>
687
688 .....
689
690 .MACRO SUBTST ASCII
691 .NLIST MC
692 $$SUBTST <ASCII>
693 .LIST MC
694 .ENDM SUBTST
695
696 .SBTTL MACRO $$SUBTST
697 .MACRO $$SUBTST ASC
698 .IRP ASCII,<ASC>
699 .SBTTL ASCII
700 .NLIST
701 .LIST ME
702 .LIST
703 .....
704 :*SUBTEST ASCII
705 .ENDM
706 .....
707 .NLIST ME
708 .ENDM $$SUBTST
```

711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748

```
.SBTTL MACRO TYPOCT
:***** TYPOCT *****
:TYPOCT IS USED TO CHANGE A BINARY NUMBER
:   TO A 6 DIGIT OCTAL NUMBER AND TYPE IT
:
:ARGUMENTS:
:1)   NUM   THE NUMBER TO BE TYPED
:2)   REMARK  ALLOWS A COMMENT TO BE MADE
:
:ROUTINES REQUIRED
:1)   CONVERT BINARY TO OCTAL AND TYPE (.$TYPOCT)
:2)   TYPE AN ASCII STRING (.$TYPE)
:
:EXAMPLES:
:1)   TYPOCT HILMT,<TYPES THE CONTENTS OF HILMT>
:2)   TYPOCT #5,<TYPES '00005'>
:*****
:
:MACRO TYPOCT NUM,REMARK
:NLIST
:DSABL CRF
:.IIF DF LST$$ .LIST ME
:FNABL CRF
:.LIST
:MOV   NUM,-(SP)           ;;SAVE NUM FOR TYPEOUT
:.IIF NB <REMARK>,        ;;REMARK
:TYPOC                               ;;CO TYPE--OCTAL ASCII(ALL DIGITS)
:DSABL CRF
:.IIF DF LST$$ .NLIST ME
:ENABL CRF
:ENDM TYPOCT
```

751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804

```

.SBTTL MACRO TYPOCS
***** TYPOCS *****
TYPOCS IS USED TO CHANGE A BINARY NUMBER TO AN OCTAL
NUMBER AND TYPE 1 TO 6 DIGITS
WITH OR WITHOUT LEADING ZEROS.

:ARGUMENTS:
:1) NUM NUMBER TO BE TYPED
:2) REMARK ALLOWS A COMMENT TO BE MADE
:3) N NUMBER OF DIGITS (1 TO 6) TO BE TYPED
:4) Z BLANK=SUPPRESS LEADING ZEROS (TYPES SPACES)
NON-BLANK-TYPE LEADING ZEROS

:ROUTINES REQUIRED
:1) CONVERT BINARY TO OCTAL AND TYPE (.$TYPOCT)
:2) TYPE AN ASCIZ STRING (.$TYPE)

:EXAMPLES:
:1) TYPOCS #12345,<TYPES '5'>,1
:2) TYPOCS #004,<TYPES '04'>,2,X
:3) TYPOCS #004,<TYPES '4'>,2
*****

.MACRO TYPOCS NUM,REMARK,N,Z
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
MOV NUM, -(SP) ;;SAVE NUM FOR TYPEOUT
.IIF NB <REMARK>, ;;REMARK
TYPOS ;;GO TYPE--OCTAL ASCII
.IF NB N
.BYTE N ;;TYPE N DIGIT(S)
.IFF
.BYTE 6 ;;TYPE 6 DIGITS
.ENDC
.IF NB Z
.BYTE 1 ;;TYPE LEADING ZEROS
.IFF
.BYTE 0 ;;SUPPRESS LEADING ZEROS
.ENDC
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM TYPOCS

```

807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847

```
.SBTTL MACRO TYPDEC
***** TYPDEC *****
TYPDEC IS USE TO CHANGE A BINARY NUMBER TO A SIGNED
DECIMAL NUMBER AND TYPE IT REPLACING LEADING ZERO
WITH SPACES.
NOTE: IF THE NUMBER IS NEGATIVE A
MINUS SIGN WILL BE TYPED.
ARGUMENTS:
1) NUM NUMBER TO BE TYPED
2) REMARK ALLOWS A COMMENT TO BE MADE
ROUTINES REQUIRED
1) CONVERT BINARY TO DECIMAL AND TYPE (.$TYPDEC)
2) TYPE AN ASCIZ STRING (.$TYPE)
EXAMPLES
1) TYPDEC SIZE,<TYPE THE CONTENTS OF SIZE>
2) TYPDEC #-10.,<TYPE A MINUS TEN>
*****

.MACRO TYPDEC NUM,REMARK
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
MOV NUM,-(SP) ;;SAVE NUM FOR TYPEOUT
.IIF NB <REMARK>, ;;REMARK
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM TYPDEC
```


MACRO BMOV

849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905

```
.SBTTL MACRO BMOV
***** BMOV *****
: THIS MACRO MOVES A BLOCK OF DATA.
: ARGUMENTS:
: 1) FROMHERE THE FIRST ADDRESS OF THE SOURCE BLOCK.
: 2) TOHERE THE FIRST ADDRESS OF THE DESTINATION BLOCK.
: IF BLANK THE 1ST ADDRESS OF THE USER INSTRUCTION
: PAR'S IS USED (FASTCITY).
: 3) SIZE THE SIZE OF THE SOURCE BLOCK.
: IF BLANK A 16 WORD TRANSFER IS ASSUMED.
: 'WHY DEFAULT TO 16 WORDS?' YOU ASK.
: 'BECAUSE THAT'S HOW MANY WORDS TO THE USER PAR
: REGISTERS & THAT'S WHERE I INTEND TO MOVE LOTS
: OF STUFF.' I REPLY!
*****
```

```
.MACRO BMOV FROMHERE,TOHERE,SIZE
  .IF B TOHERE
    .NLIST
    .DSABL CRF
    .IIF DF LST$$ .LIST ME
    .ENABL CRF
    .LIST
    JSR R5,BLOCK1
    FROMHERE
    .DSABL CRF
    .IIF DF LST$$ .NLIST ME
    .ENABL CRF
    .MEXIT
  .ENDC
  .IF B SIZE
    .NLIST
    .DSABL CRF
    .IIF DF LST$$ .LIST ME
    .ENABL CRF
    .LIST
    JSR R5,BLOCK2
    TOHERE
    FROMHERE
    .DSABL CRF
    .IIF DF LST$$ .NLIST ME
    .ENABL CRF
    .MEXIT
  .IFF
    .NLIST
    .DSABL CRF
    .IIF DF LST$$ .LIST ME
    .ENABL CRF
    .LIST
    JSR R5,BLOCK3
  SIZE
```

906
907
908
909
910
911
912

TOHERE
FROMHERE
.DSABL CRF
.IIF DF LST\$\$.NLIST ME
.ENABL CRF
.ENDC
.ENDM BMOV

915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951

```
.SBTTL MACRO MAP
***** MAP *****
THIS MACRO MAPS A MEMORY BANK (16K) INTO THE
TEST PATTERN AREA (SUPERVISOR VIRTUAL (60000-157777)).
ARGUEMENTS:
1) BANK THE BANK OF 16K WORDS TO BE MAPPED.
THERE ARE 120 BANKS OF 16K WORDS
EXAMPLES
MAP LOC ;LOCATION 'LOC' CONTAINS THE # OF THE BANK TO MAP
MAP #28. ;BANK 34 (OC'AL) WILL BE MAPPED
*****
.MACRO MAP BANK
PUSH R3
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
.IF B BANK
MOV #120.,R3
.IFF
MOV BANK,R3
.ENDC
CALL MAPPER
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
POP R3
.ENDM MAP
```

954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994

```
.SBTTL MACRO SUPERVISOR  
***** SUPERVISOR *****  
: THIS MACRO SWITCHES TO SUPERVISOR MODE.  
: ARGUMENTS: NONE.  
*****
```

```
.MACRO SUPERVISOR  
.NLIST  
.DSABL CRF  
.IIF DF LST$$ .LIST ME  
.ENABL CRF  
.LIST  
BIS #BIT14,PSW ;DO IT TO IT!  
.DSABL CRF  
.IIF DF LST$$ .NLIST ME  
.ENABL CRF  
.ENDM SUPERVISOR
```

```
.SBTTL MACRO USER  
***** USER *****  
: THIS MACRO SWITCHES TO USER MODE.  
: ARGUMENTS: NONE.  
*****
```

```
.MACRO USER  
.NLIST  
.DSABL CRF  
.IIF DF LST$$ .LIST ME  
.ENABL CRF  
.LIST  
BIS #BIT15:BIT14,PSW ;DO IT TO IT!  
.DSABL CRF  
.IIF DF LST$$ .NLIST ME  
.ENABL CRF  
.ENDM USER
```

997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036

```
.SBTTL MACRO SET4 & RES4  
***** SET4 & RES4 *****  
: THESE MACROS SET & RESTORE VECTOR 4 (TIMEOUT TRAP)  
: IN IT'S RESTORED MODE TRAPS ARE REPORTED AS SUCH.  
: ARGUMENTS: LOC ;THE LOCATION TO VECTOR TO (ONLY USED IN "SET4" NOT "RES4")  
: I USE THE SET4 AND RES4 MACROS AROUND CODE THAT I EXPECT TO TRAP TO 4  
: LIKE LOOKING FOR ALL POSSIBLE CSR'S AND ETC. WHENEVER CODE IS NOT  
: SURROUNDED BY SET4 AND RES4 THEN ANY TRAPS TO 4 WILL CAUSE AN ERROR  
: PRINTOUT THAT SAYS 'UNEXPECTED TRAP TO 4' AND ALL THE ASSOCIATED REGISTER J  
*****
```

```
.MACRO SET4 ARG  
.NLIST  
.DSABL CRF  
.IIF DF LST$$ .LIST ME  
.ENABL CRF  
.LIST  
MOV ARG,4  
.DSABL CRF  
.IIF DF LST$$ .NLIST ME  
.ENABL CRF  
.ENDM SET4  
  
.MACRO RES4  
.NLIST  
.DSABL CRF  
.IIF DF LST$$ .LIST ME  
.ENABL CRF  
.LIST  
MOV #TIMEOUT,4  
CLR CPUERR ;CLEAR OUT THE CPU ERROR REGISTER BITS  
;THAT A EXPECTED TRAP COULD HAVE SET  
  
.DSABL CRF  
.IIF DF LST$$ .NLIST ME  
.ENABL CRF  
.ENDM RES4
```

MACRO DLEFT

1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060

```

.SBTL MACRO DLEFT
***** DLEFT *****
: THIS MACRO DOES A DOUBLE WORD LEFT SHIFT
: ARGUMENTS: LOC ;THE LOCATION TO BE SHIFTED LEFT (CARRY TO LOC+2)
*****

.MACRO DLEFT ARG
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
ROL ARG
ROL ARG+2
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM DLEFT
.NLIST MD ;DON'T NEED TO SEE THEM ANY MORE

```

```

1063          .SBTTL TRAP CATCHER
1064          .=0
1065 000000 000000 000000  .WORD 0,0
1066          000177          .REPT 177          ;.WORD .+2,HALT
1070
1071          .SBTTL ACT11 HOOKS
1072          ;*THE HOOKS REQUIRED BY ACT11 ARE DEFINED AND SETUP BELOW:
1073          ;*DEFINITIONS:
1074          ;*1)LOC.46      'END-OF-PASS' HOOK
1075          ;*              =ADDRESS OF END OF PASS ROUTINE
1076          ;*              MODIFIED BY ACT11.
1077          ;*2)LOC.52      PROGRAM NEEDS HOOK
1078          ;*              BIT 15=1 PROGRAM SHOULD BE POWER
1079          ;*              FAILED WHILE RUNNING
1080          ;*              =0 NO POWER FAIL
1081          ;*              BIT 14=1 PROGRAM MEMORY SIZE DEPENDENT
1082          ;*              =0 NOT MEMORY SIZE DEPENDENT
1083          ;*              BIT 13=1 PROGRAM REQUIRES MANUAL INTERVENTION
1084          ;*              =0 MANUAL INTERVENTION NOT REQUIRED
1085          ;*              BITS 12-0 MUST BE ZERO'S
1086          ;*=46
1087 000046 015000  SENDAD          ;:1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
1088          ;*=52
1089 000052 040000  .WORD BIT14          ;:2)SET LOC.52 TO INDICATE MEMORY SIZE DEPENDANT
1090          .SBTTL APT11 HOOKS
1091          ;*-24          ;:SET POWER FAIL TO POINT TO START OF PROGRAM
1092 000024 000200  200          ;:FOR APT START UP
1093          ;*=42
1094 000042 002000  STACK          ;SO RT11 CAN START WITH RUN COMMAND
1095          ;*-44          ;:POINT TO APT INDIRECT ADDRESS PNTR.
1096 000044 075236  $APTHDR       ;:POINT TO APT HEADER BLOCK
1097          ;*=200
1098 000200 000437  START3: BR     START1          ;'NORMAL' START
1099 000202 000442  BR     START2          ;RESTART (SAVE ERROR ACCOUNTING)
1100 000204 000446  BR     START4          ;'RUN MULTIPROCESSOR TESTS WITHOUT THE IIST' START
1101          ;*-300
1102 000300 005037 002752  START1: CLR    RESTART
1103 000304 000137 004352  JMP     START
1104 000310 012737 177777 002752  START2: SET    RESTART
1105 000316 000137 004352  JMP     START
1106 000322 012737 177777 002756  START4: SET    NOIIST
1107 000330 000137 000300  JMP     START1
1108          . STACK
1108          002000
  
```

		.SBTTL VARIABLES		INITIALIZED TO ZERO
1111				: THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
1112				: USED IN THE PROGRAM.
1113				
1114	002000			: START OF COMMON TAGS
1115	002000	000000		: CSR DETERMINED TO HAVE AN ERROR BY BAD BOX ROUTINE
1116	002002	000000		: SELECT ONLY BANKS MARKED BY FIELD SERVICE MODE FLAG
1117	002004	000000		: RUN ONLY MULTIPOINT TESTS FLAG
1118	002006	000000		: SET FOR SHIFTING DIAGONAL TEST
1119	002010	000000		: SET FOR KAMIKAZE MODE TESTING
1120	002012	000000		: USED TO SKIP RESTORING KAMIKAZE MODE WHEN MODIFIED
1121				: NEXT TWO BYTES ARE DISPLAYED IN THE DISPLAY REGISTER
1122	002014	000		: PATTERN NUMBER & MARGIN VALUE
1123	002015	000		: BANK & SIGN = MARGIN INDICATOR
1124	002016	000		: CONTAINS ERROR FLAG
1125	002017	000		: CONTAINS ITEM CONTROL BYTE
1126	002020	000000		: NUMBER OF ERRORS ON LAST PASS
1127	002022	000000		: A SINGLE BIT ERROR HAS OCCURED THIS PASS
1128	002024	000000		: CONTAINS PC OF ERROR FOR TIMEOUT
1129	002026	000000		: CONTAINS PC OF ERROR
1130	002030	000000		: CONTAINS SP OF ERROR FOR TIMEOUT
1131	002032	000000		: CONTAINS SP OF ERROR
1132	002034	000000		: CONTAINS PSW OF ERROR FOR TIMEOUT
1133	002036	000000		: CONTAINS PSW OF ERROR
1134	002040	000000		: CONTAINS ADDRESS OF 'BAD' DATA
1135	002042	000000		: ADDRESS OF PARITY ERROR
1136	002044	000000	000000	: 22 BIT PHYSICAL ADDRESS
1137	002050	000000		: CONTAINS 'GOOD' DATA
1138	002052	000000		: CONTAINS 'GOOD2' DATA
1139	002054	000000		: CONTAINS 'GOOD3' DATA
1140	002056	000000		: CONTAINS 'BAD' DATA
1141	002060	000000		: CONTAINS 'BAD2' DATA
1142	002062	000000		: CONTAINS 'BAD3' DATA
1143	002064	000000		: XOR OF GOOD & BAD = BAD BITS.
1144	002066	000000		: AUTOMATIC MODE INDICATOR FOR APT,ACT, & XXDP
1145	002070	000000		: FATAL ERROR INDICATOR
1146	002072	000000		: NON-EXISTANT MEMORY COUNTER (HOLES)
1147	002074	000000		: PARITY ERROR COUNTER
1148	002076	000000		: PATTERN ERROR COUNTER
1149	002100	000000		: NO PARITY ERROR MODE INDICATOR
1150	002102	000000		: NO NON-EXISTANT MEMORY (HOLES) MODE INDICATOR
1151	002104	000000		: NO LINE CLOCK IS ON THIS SYSTEM
1152	002106	000000		: MEMORY BANK UNDER TEST
1153	002110	000000		: USED TO INDEX INTO CONFIG TABLE
1154	002112	000000		: INDICATES WHICH MARGIN IS IN PROGRESS
1155	002114	000000		: CONTAINS 1 BIT TO IDENTIFY CPU TO CONFIGURATION TABLE
1156	002116	000000		: MEMORY UNDER TEST FLAG
1157	002120	000000		: PATTERN NUMBER UNDER TEST
1158	002122	000000		: BANK IS PROTECTED REGION OF MK11
1159	002124	000000		: BANK CAN BE ACCESSED BY THIS CPU
1160	002126	000000		: IF SET INDICATES MK11 UNDER TEST
1161	002130	000000		: BANK IS IN PROGRAM SPACE
1162	002132	000000		: BANK IS WHERE PROGRAM RELOCATION IS REQUIRED TO TEST
1163	002134	000000		: PROGRAM IS RELOCATED FLAG
1164	002136	000000		: 'BANK IS IDENTIFIED AS BAD MEMORY' FLAG
1165	002140	000000		: 'TYPE OF MEMORY TO TEST' FLAG; 0 = MK11
1166	002142	000000		: 'ABORT OCCURED' FLAG
1167	002144	000000	000000	: DATA TO OR FROM CSR


```

1168 002150 000000 000000 LOCATED TO SBADSR:MEMOR FLAGO          :CSR STORED HERE ON MK11 DETECTED SB3 002254 000000
1174 002256 000000          CSRNO: 0                    :CSR ADDRESS NUMBER (3 LSB'S)
1175 002260 000000          FIRSTB: 0                   :FIRST BANK CONTROLLED BY THIS CSR
1176 002262 000000          LASTB: 0                    :LAST BANK CONTROLLED BY THIS CSR
1177 002264 000000          INTERL: 0                   :INTERLEAVE FACTOR (0,1,2,3)
1178          :THESE LOCATIONS STORE GPR'S DURING SUPERVISOR TESTS
1179 002266 000000          SUPDR0: 0
1180 002270 000000          SUPDR1: 0
1181 002272 000000          SUPDR2: 0
1182 002274 000000          SUPDR3: 0
1183 002276 000000          SUPDR4: 0
1184 002300 000000          SUPDR5: 0
1185 002302 000000          SUPDR6: 0
1186 002304 000000          DUMMY: 0                    :DUMMY LOCATION FOR ADDRESS PASSING
1187          :THESE LOCATIONS STORE GPR'S & PSW DURING DETAILED ERROR PRINTOUTS
1188 002306 000000          DETR0: 0
1189 002310 000000          DETR1: 0
1190 002312 000000          DETR2: 0
1191 002314 000000          DETR3: 0
1192 002316 000000          DETR4: 0
1193 002320 000000          DETR5: 0
1194 002322 000000          DETSP: 0
1195 002324 000000          DETPSW: 0
1196 002326 000000          DETFLAG: 0
1197 002330 000000          PENDBOX: 0
1198          :DETAILED REPORT FLAG
1199          :1 BIT PER EXISTING CSR THAT STARTS AT A BANK ABOVE 166
1200 002332 000000          :CSR'S 0,1,2,3,4,5,6,7 REPRESENTED BY BITS
1201 002334 000000          :7,6,5,4,3,2,1,0 RESPECTIVELY
1202          :MK11 CONTROL'S HAVE BEEN TESTED FLAG
1203          :LO BYTE: 1 BIT PER EXISTING CSR
1204          :CSR'S 0,1,2,3,4,5,6,7 REPRESENTED BY BITS
1205          :7,6,5,4,3,2,1,0 RESPECTIVELY
1206          :HI BYTE: 1 BIT PER EXISTING CSR WITH INTERNAL INTERLEAVE
1207 002336 000000          :INTERNAL INTERLEAVE REPRESENTED BY BITS
1208 002340 000000 000000          :15,14,13,12,11,10,9,8 RESPECTIVELY
1209 002344 000000 000000          :FIRST ADDRESS UNDER CONTROL OF THIS CSR
1210 002350 000000 000000          :TWO WORD DATA BUFFER
1211 002354 000000 000000          :TWO WORD TEST DATA
1212 002360 000000          :TWO WORD SINGLE BIT ERROR MASK
1213 002362 000          :TWO WORD DOUBLE BIT ERROR MASK
1214 002363 000          :ADDRESS OF SUBROUTINE TO EXECUTE IN SUPERVISOR MODE
1215 002364 000000          :LOCAL LOOP PASS CONTROL
1216 002366 000000          :LOCAL LOOP PASS CONTROL
          STRTDI: 0          :LOAD STRTDI WITH THE STARTING ADDRESS OF THE DIAGNAL
          REALPAT: 0        :REAL PATTERN UNDER TEST
    
```

1217	002370	000000	OLDCACHE:0	:BACKED UP VALUE OF CACHE CONTROL REGISTER
1218	002372	000000	PARTHERE:0	:PARITY TRAPS SOMETIMES GO TO ADDRESS STORED HERE
1219	002374	000000	FSSTACK:0	:STACK SAVED HERE IF IN FIELD SERVICE MODE
1220	002376	000000	OLDMARGIN:0	:BACKED UP VALUE OF LAST MARGIN SETTING
1221	002400	000000	NEWBANK:0	:USED FOR RELOCATION TO A NEW BANK
1222	002402	000000	SOURCE: .WORD 0	:SOURCE OF DATA WORDS FOR CHECKBIT GENERATION SUBROUTINE
1223	002404	000000	CHECK: .WORD 0	:CHECKBITS TO BE LOADED INTO CSR
1224	002406	000000	PCBUMP: .WORD 0	:VALUE TO BUMP THE PC BY TO RECOVER AFTER A PARITY TRAP
1225	002410	000000	CSRFBANK:0	:FIRST BANK OWNED (AT LEAST IN PART) BY THIS CSR
1226	002412	000000	CSRLBANK:0	:LAST BANK OWNED (AT LEAST IN PART) BY THIS CSR
1227	002414	000000	CSRINC: 0	:VALUE TO INCREMENT ADDRESS BY TO REMAIN IN THE SAME CSR
1228	002416	000	CSRINDEX: .BYTE 0	:AN INDEX VARIABLE FOR A CSR LOOP
1229	002417	000	CSROUDEX: .BYTE 0	:AN INDEX VARIABLE FOR A CSR LOOP
1230	002420	000000	CSRLOOP:0	:LOOP CONTROL FOR CSR TESTING
1231	002422	000000	SIDE: 0	:INDEX VARIABLE FOR EACH SIDE (CONTROLLER) OF A CSR
1232	002424	000000	SUCCESS:0	:FLAG SET BY SUCCESSFULL TASK OR SUBROUTINE
1233	002426	000000	ZERO: 0	:FOR AID IN 'MOV' INSTRUCTIONS
1234	002430	000000	ZEROS: 0	:FOR AID IN 'MOV' INSTRUCTIONS
1235	002432	000000	SPECIAL:0	:FLAG FOR SPECIAL CASE OF NO INTERNAL INTERLEAVE
1236	002434	000000	TIME: 0	:SECONDS THAT BATTERIES SHOULD LAST
1237	002436	000000	NULLFLAG:0	:SET WHEN RUNNING NULL PATTERNS
1238	002440	000000	QVFLAG: 0	:FLAGS QUICK VERIFY PASS UNDER APT, ACT, OR XXDP CHAIN MODE
1239	002442	000000	ACTFLAG:0	:FLAGS ACT AUTOMATIC MODE PROGRAMMING RULES
1240	002444	000000	APTFLAG:0	:FLAGS APT AUTOMATIC MODE PROGRAMMING RULES
1241	002446	000000	XXDPCHAIN:0	:FLAGS XXDP CHAIN MODE PROGRAMMING RULES
1242			:NOTE: THESE TWO BYTES MUST STAY TOGETHER	
1243	002450	000	\$NULL: .BYTE 0	:CONTAINS NULL CHARACTER FOR FILLS
1244	002451	000	\$FILLS: .BYTE 0	:CONTAINS # OF FILL CHARACTERS
1245	002452	000	\$TFPLG: .BYTE 0	: 'TERMINAL NOT AVAILABLE' FLAG
1246			.EVEN	
1247	002454	000000	\$ESCAPE:0	:ESCAPE ON ERROR ADDRESS
1248	002456	000000	EVEN: 0	:USED FOR ALTERNATE DATA PATTERNS
1249	002460	000000	STRIPES:0	:COUNTS DIAGONAL STRIPES
1250	002462	000000	COUNT: 0	:BACKED UP COPY OF STRIPES
1251	002464	000000	NOTAB: 0	:NO TABLE BEING PRINTED - NOW
1252	002466	000000	MJSIZE: 0	:SIZE OF MJ11 MEMORY IN K WORDS
1253	002470	000000	MKSIZE: 0	:SIZE OF MK11 MEMORY IN K WORDS
1254	002472	000000	TOOMANY:0	:FLAGS WHEN TOO MANY ERRORS HAVE BEEN PRINTED FOR A BANK
1255	002474	000000	NOECCFLAG:0	:ECC CAPABILITY DISABLED ON THE CONTROL PANEL
1256	002476	000000	GDSWITCH:0	:GOOD VALUE FOR SOME SWITCHES
1257	002500	000000	BDSWITCH:0	:BAD VALUE FOR SOME SWITCHES
1258	002502	000000	WRITEONLY:0	:FLAG TO PATTERNS TO WRITE ONLY
1259	002504	000000	READONLY:0	:FLAG TO PATTERNS TO READ ONLY
1260	002506	000000	TESTADD:0	:THE ADDRESS TO RUN CSR TESTS ON
1261	002510	000000	ALLCPUS:0	:CPUBIT'S FOR ALL CPU'S PRESENT
1262	002512	000000	HIBANK: 0	:HIGHEST BANK OF MEMORY
1263	002514	000000	HIACBANK: 0	:1ST INACCESSABLE BANK OF MEMORY
1264	002516	000000	UNITOP: 0	:HIGHEST ACCESSABLE BANK OF MEMORY THRU UNIBUS MAP
1265	002520	000000	STOPOK: 0	:FLAG TO ALLOW STOPPING WITH SWITCH REGISTER
1266	002522	000000	APTCORE:0	:AMOUNT OF CORE MEMORY ACCORDING TO APT
1267	002524	000000	APTMOB: 0	:AMOUNT OF MOB MEMORY ACCORDING TO APT
1268	002526	000000	NOFSMODE:0	:FLAG TO DISABLE FIELD SERVICE MODE
1269	002530	000000	NOERROR:0	: 'THIS IS NOT AN ERROR' FLAG
1270	002532	000000	LOADBANK:0	:BANK LOADERS ARE RELOCATED TO
1271	002534	000000	TEMP: 0	:USED FOR JUNK
1272	002536	000000	QUICK: 0	:QUICK STOP FLAG FOR APT POWER FAIL
1273	002540	000000	NOSCOPE:0	: 'NO SCOPE LOOP ALLOWED' FLAG

1274	002542	000000	F'SINFLAG:0	;'FIELD SERVICE - NO INTERNAL INTERLEAVE'' FLAG
1275	002544	000000	APTSIZE:0	;APT SIZING INFO FLAG
1276	002546	000000	FS7FLAG:0	;TRUE WHEN IN FIELD SERVICE COMMAND 7
1277	002550	000000	K10: 0	;SAVED KIPAR0 TO PASS CORRECT VALUE TO SLAVE
1278	002552	000000	K11: 0	;SAVED KIPAR1 TO PASS CORRECT VALUE TO SLAVE
1279	002554	000000	K12: 0	;SAVED KIPAR2 TO PASS CORRECT VALUE TO SLAVE
280	002556	000000	K13: 0	;SAVED KIPAR3 TO PASS CORRECT VALUE TO SLAVE
1281	002560	000000	K14: 0	;SAVED KIPAR4 TO PASS CORRECT VALUE TO SLAVE
1282	002562	000000	K15: 0	;SAVED KIPAR5 TO PASS CORRECT VALUE TO SLAVE
1283	002564	000000	K16: 0	;SAVED KIPAR6 TO PASS CORRECT VALUE TO SLAVE
1284	002566	000000	K17: 0	;SAVED KIPAR7 TO PASS CORRECT VALUE TO SLAVE
1285	002570	000000	SLAERROR:0	;SLAVE HAD AN ERROR FLAG
1286	002572	000000	HUNGMSB:0	;USED FOR TIMES OVER 13 SECONDS
1287	002574	000000	HUNGTIME:0	;TIME TO ALLOW THE SYSTEM TO BE HUNG (MAX 13. SEC)
1288	002576	000000	CONFERROR:0	;CONFIGURATION ERROR FLAG
1289	002600	000000	TWOCSRS:0	;TO FLAG LOADCSR TRAP TO LOAD TWO CSR'S
1290	002602	000000	I: 0	;USED FOR GENERAL PURPOSE INDEXING
1291	002604	000000	.. 0	;USFD FOR GENERAL PURPOSE INDEXING

```

1294          .SBTTL MULTIPORT VARIABLES
1295          ;MULTIPORT DIRECTORY
1296          ;PORTDIR:MASTER IIST ID NUMBER OR SYSTEM ID NUMBER IF IIST DISABLED BY OPERATOR
1297          :      SLAVE IIST ID NUMBER OR SYSTEM ID NUMBER IF IIST DISABLED BY OPERATOR
1298          :      SLAVE IIST ID NUMBER OR SYSTEM ID NUMBER IF IIST DISABLED BY OPERATOR
1299          :      SLAVE IIST ID NUMBER OR SYSTEM ID NUMBER IF IIST DISABLED BY OPERATOR
1300 002606 000000 000000 000000 PORTDIR:.WORD 0,0,0,0
1301 002614 000000
1301 002616 000000 000000 000000 TASK: .WORD 0,0,0,0
1301 002624 000000
1302 002626 000000 000000 000000 PTYFLAG:.WORD 0,0,0,0
1302 002634 000000
1303 002636 000000 000000 000000 PTYBUF: .WORD 0,0,0,0
1303 002644 000000
1304 002646 000000 000000 000000 PORTCOUNT:.WORD 0,0,0,0
1304 002654 000000
1305 002656 000000 000000 000000 SLFLAG: .WORD 0,0,0,0
1305 002664 000000
1306 002666 000000 MINDEX: 0 ;MASTER CPU'S INDEX # TO TABLES ABOVE
1307 002670 000000 LOCK: 0 ;MULTIPROCESSOR LOCK
1308 002672 000000 ACK: 0 ;ACKNOWLEDGE FLAG (USED FOR STARTING SLAVES)
1309 002674 000000 MASWR: 0 ;MASTER'S SWR
1310 002676 000000 MDISPLAY:0 ;MASTER CPU DISPLAY WHEN RUNNING MULTIPROCESSOR TESTS
1311 002700 $CMTGE: ;*END OF COMMON TAGS
```

1314				.SBTTL	VARIABLES	INITIALIZED TO NON ZERO
1315	002700	000001		CACHK:	1	:CACHE CONSTANT (MOVED TO CONTRL TO TURN ON CACHE)
1316	002702	000012		ERRMAX:	10.	:MAX # OF ERRORS PER BANK WITH SW11
1317	002704	000031		SOBK:	25.	:SOB CONSTANT
1318	002706	002000		KSTACK:	STACK	:STACK BEGINNING (USED TO KEEP SLAVES STACKS SEGREGATED)
1319	002710	000001		LOADHOME:	1	:HOME BANK OF LOADERS
1320	002712	177777		WORST:	177777	:SET IF TESTING BANKS IN WORST FIRST MODE(1ST PASS)
1321	002714	176543		SEEDHI:	176543	:WORKING SEED HI (USED FOR RANDOM NUMBER GENERATOR)
1322	002716	123456		SEEDLO:	123456	:WORKING SEED LO (USED FOR RANDOM NUMBER GENERATOR)
1323	002720	176543		MSEEDH:	176543	:MASTER SEED HI (USED FOR RANDOM NUMBER GENERATOR)
1324	002722	123456		MSEEDL:	123456	:MASTER SEED LO (USED FOR RANDOM NUMBER GENERATOR)
1325	002724	177777		HEADER:	177777	:USED TO PRINT HEADINGS ONLY ONCE
1326	002726	177777		ONES:	177777	:FOR AID IN 'MOV' INSTRUCTIONS
1327	002730	000000		SLAVES:	0	:# OF SLAVE CPU'S
1328	002732	000000		ONCE:	0	:FLAG FOR TYPING TITLE ONLY ONCE
1329	002734	000003		FLIPLOC:	3	:COUNTER FOR FLIPING DATA ON WORST CASE NOISE TEST
1330	002736	177500		IISTACR:	177500	:ADDRESS OF THE IIST ACR (WAS 166000)
1331	002740	177502		IISTADR:	177502	:ADDRESS OF THE IIST ADR (WAS 166002)
1332	002742	000260		IISTVEC:	260	:ADDRESS OF THE IIST VECTOR (WAS 170)
1333	002744	052525		SOFTPAT:	52525	:PATTERN FOR SOFT ERROR BACKGROUND TESTS
1334	002746	000000		\$LPADR:	.WORD 0	::CONTAINS SCOPE LOOP ADDRESS
1335	002750	000000		\$LPERR:	.WORD 0	::CONTAINS SCOPE RETURN FOR ERRORS
1336	002752	000000		RESTART:	0	:RESTART (START ADD 202) FLAG
1337	002754	000000		\$ERTTL:	.WORD 0	::CONTAINS TOTAL ERRORS
1338	002756	000000		NOIIST:	0	:NO IIST IS TO BE USED DURING MULTIPOST TESTS
1339	002760	000000		PWLOCK:	0	:MULTIPROCESSOR LOCK FOR POWER FAILURE
1340						
1341						:***** NOTE THESE TWO LOCATIONS MUST STAY TOGETHER *****
1342	002762	000377		BAKPAT:	.WORD 377	:BACKGROUND PATTERN *
1343	002764	177400		SWAPAT:	.WORD 177400	:SWAPPED BAKPAT *
1344						:*****
1345						
1346	002766	177570		SWR:	.WORD DSWR	::ADDRESS OF SWITCH REGISTER
1347	002770	177570		DISPLAY:	.WORD DDISP	::ADDRESS OF DISPLAY REGISTER
1348	002772	177560		\$TKS:	177560	::TTY KBD STATUS
1349	002774	177562		\$TKB:	177562	::TTY KBD BUFFER
1350	002776	177564		\$TPS:	177564	::TTY PRINTER STATUS REG. ADDRESS
1351	003000	177566		\$TPB:	177566	::TTY PRINTER BUFFER REG. ADDRESS
1352	003002	012		\$FILLC:	.BYTE 12	::INSERT FILL CHARS. AFTER A 'LINE FEED'
1353	003003	207	377	\$BELL:	.ASCIZ <207><377><377>	::CODE FOR BELL
	003006	000				
1354	003007	077		\$QUES:	.ASCII /?/	::QUESTION MARK
1355	003010	015		\$CRLF:	.ASCII <15>	::CARRIAGE RETURN
1356	003011	012	000	\$LF:	.ASCIZ <12>	::LINE FEED
1357					.EVEN	
1358	003014	000000		MULTIPOST:	0	:MULTIPROCESSING FLAG

```

1361 .SBTTL CONFIGURATION TABLE
1362 :CONFIG:FIRST 16K CONFIGURATION WORDS (3 EACH)
1363 2ND 16K CONFIGURATION WORDS (3 EACH)
1364 167TH 16K CONFIGURATION WORDS (3 EACH)
1365
1366 :CONFIGURATION WORDS:
1367 LOW: BIT 0-2 INTERLEAVE FACTOR
1368 BIT 3 EXTERNAL INTERLEAVE
1369 BIT 4 MASTER CAN ACCESS (MEMORY EXISTS)
1370 BIT 5 SLAVE #1 CAN ACCESS (SHARED)
1371 BIT 6 SLAVE #2 CAN ACCESS (SHARED)
1372 BIT 7 SLAVE #3 CAN ACCESS (SHARED)
1373 BIT 8-10 BOX NUMBER (0-7)
1374 BIT 11 ERRORS PRESENT
1375 BIT 12 PROTECTED REGION OF A MK11 BOX
1376 BIT 13-14 MEMORY TYPE;0=MJ11;1=MK11
1377 BIT 15 PROTECTED (PROGRAM SPACE)
1378 MED: BIT 0-5 NOT USED
1379 BIT 6-8 MK11 CSR ADDRESS
1380 BIT 9-11 NOT USED
1381 BIT 12 INTERNAL INTERLEAVE
1382 BIT 13 'BACKGROUND PATTERN VALID' FLAG
1383 BIT 14 BANK SELECTED FOR TEST BY FIELD SERVICE MODE
1384 BIT 15 LOADERS HOME BANK
1385 HIGH: BIT 0 INDICATES BANK IS ADDRESSED BY CSR 172100
1386 BIT 1 INDICATES BANK IS ADDRESSED BY CSR 172104
1387 BIT 2 INDICATES BANK IS ADDRESSED BY CSR 172110
1388 BIT 3 INDICATES BANK IS ADDRESSED BY CSR 172114
1389 BIT 4 INDICATES BANK IS ADDRESSED BY CSR 172120
1390 BIT 5 INDICATES BANK IS ADDRESSED BY CSR 172124
1391 BIT 6 INDICATES BANK IS ADDRESSED BY CSR 172130
1392 BIT 7 INDICATES BANK IS ADDRESSED BY CSR 172134
1393 BIT 8-15 NUMBER OF ERRORS
1394
1395 003016 000170 CONFIG: .REPT 170
1396 004336 000000 000000 000000 CONFIEND: .WORD 0,0,0,0,0
1397 004344 000000 000000 000000 ;THESE WORDS SHOULD NEVER GET WRITTEN INTO
1398
1399 ;IF THEY DO THE PROGRAM IS OVERFLOWING IT'S
1400 ;CONFIGURATION TABLE (SOFTWARE BUG)!
    
```

```

1402          .SBTTL ***** MAIN *****
1403 004352  START: SUBTST <<INITIALIZE VARIABLES TO ZERO>>
:*****
:*SUBTEST    INITIALIZE VARIABLES TO ZERO
:*****
1404 004352          SET    ACK                ;ACKNOWLEDGE THAT I HAVE STARTED (IN CASE I'M A SLAVE)
      004352 012737 177777 002672          MOV    #-1,ACK
1405 004360          RESET
      004360 000005
1406 004362          MOV    KSTACK,SP        ;;SETUP THE STACK POINTER
      013706 002706          IF MULTIPORT EQ ONES AND CPUBIT NE #MASTER
1407 004366          IF MULTIPORT EQ ONES AND CPUBIT NE #MASTER
      004366 023737 003014 002726          CMP    MULTIPORT,ONES
      004374 001014          BNE    L0
      004376 023727 002114 000020          CMP    CPUBIT,#MASTER
      004404 001410          BEQ    L0
1408          ;WAIT FOR ACK TO CLEAR OR TIMEOUT & HALT
1409 004406 005004          CLR    R4
1410 004410          1$:          IF ACK IS TRUE
      004410 005737 002672          TST    ACK
      004414 001402          BEQ    L1
1411 004416 077404          SOB    R4,1$
1412 004420 000000          SHALT:        HALT                ;THE MASTER WOULD NOT ALLOW THIS SLAVE TO PROCEED
1413 004422          END ;OF IF ACK IS TRUE
      004422          L1:::
1414 004422 000137 005752          JMP    BEGIN
1415 004426          END ;OF IF MULTIPORT
      004426          L0:::
1416 004426 012700 002000          MOV    #SCMTAG,R0        ;;FIRST LOCATION TO BE CLEARED
1417 004432 005020          1$:          CLR    (R0)+          ;;CLEAR MEMORY LOCATION
1418 004434 022700 002700          CMP    #SCMTGE,R0        ;;DONE?
1419 004440 001374          BNE    1$          ;LOOP BACK IF NO
1420 004442          SUBTST <<CLEAR NON-PROGRAM SPACE>>
:*****
:*SUBTEST    CLEAR NON-PROGRAM SPACE
:*****
1421          ;THIS ATTEMPS TO GET RID OF ANY PARITY ERRORS BY WRITING INTO
1422          ;EVERY LOCATION THAT IS NOT LOADED INTO BY THE PROGRAM OR ALLOCATED
1423          ;TO THE XXDP LOADERS
1424 004442 012737 000004 002100          MOV    #4,NOPAR        ;PARITY ACTION - COUNT & IGNORE
1425 004450 012700 001000          MOV    #1000,R0
1426 004454 012737 000015 177746          MOV    #15,CONTRL        ;DISABLE CACHE & ABORTS
1427 004462 012720 000000          9$:          MOV    #0,(R0)+          ;CLEAR THE STACK AREA
1428 004466 020027 002000          CMP    R0,#STACK
1429 004472 103773          BLO    9$
1430 004474 012700 117146          MOV    #END+2,R0
1431 004500 012720 000000          8$:          MOV    #0,(R0)+          ;CLEAR FROM THE END OF THE PROGRAM TO THE XXDP LOADE
1432 004504 020027 137776          CMP    R0,#157776-8192.
1433 004510 103773          BLO    8$
1434 004512 005037 002100          CLR    NOPAR          ;RESTORE DEFAULT PARITY ACTION
1435
1436 004516 005237 002670          INC    LOCK            ;ONLY ALLOW ONE CPU AT A TIME TO GO THRU HERE
1437 004522          IF    LOCK NE #1
      004522 023727 002670 000001          CMP    LOCK,#1
      004530 001402          BEQ    L2
1438 004532 000000          MHALT1:        HALT                ;MULTIPLE MASTER CPU'S ARE RUNNING
1439 004534 000776          BR    MHALT1
1440 004536          END ;OF IF LOCK
      004536          L2:::
    
```

```

1443 004536          SUBTST <<INITIALIZE VARIABLES TO NON ZERO>>
:*****
:*SUBTEST          INITIALIZE VARIABLES TO NON ZERO
:*****
1444 004536          SET          WORST
1445 004536 012737 177777 002712          MOV          #3,FLIPLOC          MOV #1,WORST
1446 004552 012737 177777 002724          SET          HEADER          MOV #1,HEADER
1447 004560 012737 176543 002720          MOV          #176543,MSEEDH
1448 004566 012737 123456 002722          MOV          #123456,MSEEDL
1449 004574 013737 002720 002714          MOV          MSEEDH,SEEDHI      ;PRIME THE RANDOM NUMBER GENERATOR
1450 004602 013737 002722 002716          MOV          MSEEDL,SEEDLO     ;BOTH HIGH AND LOW WORDS
1451 004610 012737 000377 002762          MOV          #377,BAKPAT
1452 004616 012737 177400 002764          MOV          #177400,SWAPAT
1453 004624 012737 052525 002744          MOV          #52525,SOFTPAT
1454 004632 012737 005752 002746          MOV          #BEGIN,$LPADR     ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
1455 004640 012737 005752 002750          MOV          #BEGIN,$LPERR     ;:SETUP THE ERROR LOOP ADDRESS
1456 004646          SUBTST <<INITIALIZE VECTORS>>
:*****
:*SUBTEST          INITIALIZE VECTORS
:*****
1457 004646 012737 066232 000020          MOV          #SCOPE,IOTVEC ;:IOT VECTOR FOR SCOPE ROUTINE
1458 004654 012737 000340 000022          MOV          #340,IOTVEC+2 ;:LEVEL 7
1459 004662 012737 066662 000030          MOV          #ERROR,EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
1460 004670 012737 000340 000032          MOV          #340,EMTVEC+2 ;:LEVEL 7
1461 004676 012737 075252 000034          MOV          #STRAP,TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
1462 004704 012737 000340 000036          MOV          #340,TRAPVEC+2 ;:LEVEL 7
1463 004712 012737 055160 000024          MOV          #SPWRDN,PWRVEC ;:POWER FAILURE VECTOR
1464 004720 012737 000340 000026          MOV          #340,PWRVEC+2 ;:LEVEL 7
1465 004726 012737 036454 000114          MOV          #PARITY,PARVEC ;:GET READY FOR PARITY ERRORS
1466 004734 012737 000340 000116          MOV          #340,PARVEC+2
1467 004742 012737 036752 000010          MOV          #PDP1105,RESVEC ;:RESERVED INSTRUCTION TRAP
1468 004750 012737 000340 000012          MOV          #340,RESVEC+2
1469 004756 012737 036726 000004          MOV          #TIMEOUT,ERRVEC ;:SETUP TIMEOUT ERRORS
1470 004764 012737 000340 000006          MOV          #340,ERRVEC+2 ;:SET PRIORITY OF ERROR TRAPS
1471 004772 012737 036740 000250          MOV          #MMTRAP,MIVVEC ;:VECTOR FOR MEMORY MANAGEMENT
1472 005000 012737 000340 000252          MOV          #340,MIVVEC+2
1473 005006 012737 036764 000170          MOV          #IITRAP,170 ;:SET UP FOR UNEXPECTED IIST TRAPS
1474 005014 012737 000340 000172          MOV          #340,i72
1475 005022 104423          CACHON ;:TURN CACHE ON
    
```



```

1479 005024          SUBTST <<CLEAR THE CONFIGURATION TABLE>>
:*****
:*SUBTEST          CLEAR THE CONFIGURATION TABLE
:*****
1480                ;THIS ZEROS (UNLESS WE STARTED AT ADDRESS 202) THE CONFIG TABLE
1481                ;WHICH IS FULLY DISCRIBED AT LOCATION 'CONFIG'.
1482                .ENABLE LSB
1483 005024          IF RESTART IS FALSE
005024 005737 002752                                TST RESTART
005030 001006                                BNE L3
1484 005032 012700 003016
1485 005036 005020
1486 005040 022700 004536
1487 005044 001374
1488 005046
005046
1489
1490 005046 012737 000020 002114
1491 005054
          .DSABL LSB
          MOV #MASTER,CPUBIT ;SET ID BIT
          SUBTST <<SIZE FOR A HARDWARE SWITCH REGISTER>>
:*****
:*SUBTEST          SIZE FOR A HARDWARE SWITCH REGISTER
:*****
1492                ;; IF NOT FOUND OR IT IS
1493                ;; EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.
1494                .ENABL LSB
1495 005054          SET4 #3$ ;TRAPS TO 4 GOTO 3$
005054 012737 005110 000004
          MOV #3$,4
          .DSABL CRF
1496 005062 012737 177570 002766
1497 005070 012737 177570 002770
1498 005076          MOV #DSWR,SWR ;:SETUP FOR A HARDWARE SWITCH REGISTER
005076 022777 177777 175662
005104 001017          MOV #DDISP,DISPLAY ;:AND A HARDWARE DISPLAY REGISTER
          IF #-1 EQ @SWR ;:IF NO TRAP FROM REFERENCE TO @SWR AND @SWR #-1
          CMP #-1,@SWR
          BNE L4
1499 005106 000403
1500 005110 012716 005116
1501 005114 000002
1502 005116          BR 2$ ;:BRANCH IF NO TIMEOUT
005116 012737 036726 000004
005124 005037 177766
          MOV #TIMEOUT,4 ;:SET UP FOR TRAP RETURN
          CLR CPUERR ;:RESET TRAPS TO 4 TO DEFAULT
          ;:CLEAR OUT THE CPU ERROR REGISTER BITS
          ;:THAT A EXPECTED TRAP COULD HAVE SET
          .DSABL CRF
1503 005130 012737 000176 002766
1504 005136 012737 000174 002770
1505 005144          MOV #SWREG,SWR ;:POINT TO SOFTWARE SWR
005144          MOV #DISPREG,DISPLAY
          END ;OF IF #-1
1506
1507                L4:*****
1508 005144          .DSABL LSB
          SUBTST <<FIND OUT IF ANY LINE CLOCK IS PRESENT>>
:*****
:*SUBTEST          FIND OUT IF ANY LINE CLOCK IS PRESENT
:*****
1509 005144          SET4 #4$
005144 012737 005160 000004
          MOV #4$,4
          .DSABL CRF
1510 005152 005737 177546
1511 005156 000403
1512 005160          TST LKS
          BR 5$ ;:IF NO TRAP SKIP
          SET NOCLOCK ;:SET NO LINE CLOCK FLAG
    
```

```
00516C 012737 177777 002104          MOV #1,NOERR  
513 005166 012737 036726 000004  SS:  RES4          :RESTORE TRAPS TO 4 TO DFFAULT  
005166 012737 036726 000004  MOV #TIMEOUT,4  
005174 005037 177766          CLR CPUERR      :CLEAR OUT THE CPU ERROR REGISTER BITS  
                                     :THAT A EXPECTED TRAP COULD HAVE SET  
                                     .DSABL CRF
```

```

1516 005200          SUBAAB: SUBST <<SETUP ACT, APT, & XXDP>>
:*****
: *SUBTEST          SETUP ACT, APT, & XXDP
:*****
1517                ;THIS SETS UP A BUNCH OF FLAGS TO TELL THE PROGRAM EVERYTHING
1518                ;IT CARES TO KNOW ABOUT APT, ACT, & XXDP.
1519 005200 005037 075142 CLR $PASS ;CLEAR PASS COUNT
1520 005204 132737 000040 075155 IFB #BITS SET.IN $ENVM
                                BITB #BITS,$ENVM
                                BEQ L5
1521 005214 005212 001403          SET $TPFLG ;INDICATE NO TERMINAL
                                MOV #-1,$TPFLG
1522 005222 012737 177777 002452 END ;OF IFB #BITS
                                L5:*****
1523 005222 005222 000200 075155 IFB #BIT7 SET.IN $ENVM
                                BITB #BIT7,$ENVM
                                BEQ L6
1524 005232 005232 012737 177777 002544 SET APTSIZE
                                MOV #-1,APTSIZE
1525 005240 012737 075156 002766 MOV #$$SWREG,$SWR ;USE APT SWR
1526 005246 005246 012737 075156 002766 END ;OF IFB #BIT7
                                L6:*****
1527 005246 005246 123727 075154 000001 IFB $ENV EQ #1
                                CMPB $ENV,#1
                                BNE L7
1528 005256 005256 001020          SET APTFLAG,QVFLAG,$AUTO,QUICK
                                MOV #-1,APTFLAG
                                MOV #-1,QVFLAG
                                MOV #-1,$AUTO
                                MOV #-1,QUICK
1529 005306 012737 043640 000024 MOV #APTDOWN,$PURVEC
530 005314 005314 000430          ELSE
                                BR L10
1531 005316 005316 023727 000042 002000 IF 42 NE #STACK AND 42 NE #0
                                L7:*****
                                CMP 42,#STACK
                                BEQ L11
                                TST 42
                                BEQ L11
1532 005334 005334 012737 177777 002440 SET QVFLAG,$AUTO
                                MOV #-1,QVFLAG
                                MOV #-1,$AUTO
1533 005350 005350 023727 000042 015000 IF 42 EQ #SENDAD
                                CMP 42,#SENDAD
                                BNE L12
1534 005360 005360 012737 177777 002442 SET ACTFLAG
                                MOV #-1,ACTFLAG
1535 005366 005366 000403          ELSE
                                BR L13
1536 005370 005370 012737 177777 002446 SET XXDPCHAIN
                                MOV #-1,XXDPCHAIN
1537 005376 005376 005376 005376 005376 END ;OF IF 42
                                L12:*****
1538 005376 005376 005376 005376 005376 END ;OF IF 42
                                L13:*****
1539 005376 005376 005376 005376 005376 END ;OF IFB $ENV
                                L11:*****
    
```

005376

L10:::~::~



1542 005376

SUBST <<INITIALIZE PATTERNS>>

 :*SUBTEST INITIALIZE PATTERNS

1543
 1544
 1545
 1546
 1547

:THE APT E-TABLE DETERMINES WHICH PATTERNS ARE GOING TO BE RUN.
 :EACH BIT SET REPRESENTS A PATTERN TABLE ENTRY THAT IS TO BE LEFT
 :ALONE (TO BE RUN). EACH BIT CLEARED REPRESENTS A PATTERN TABLE ENTRY
 :THAT IS TO BE OVERLAYED WITH THE ADDRESS OF A NULL PATTERN.
 IF APTFLAG IS TRUE

005376 005737 002444
 005402 001432
 1548 005404 012700 07>220
 1549 005410 012001
 1550 005412 012703 020124
 1551 005416 004737 005472
 1552 005422 012001
 1553 005424 004737 005472
 1554 005430 012001
 1555 005432 012703 021402
 1556 005436 004737 005472
 1557 005442 012001
 1558 005444 004737 005472
 1559 005450 012001
 1560 005452 012703 021600
 1561 005456 004737 005472
 1562 005462 012001
 1563 005464 004737 005472
 1564 005470
 005470
 1565 005470 000420
 1566
 1567 005472

TST APTFLAG
 BEQ L14
 MOV #SDDW0,R0
 MOV (R0)+,R1
 MOV #MKCSRT,R3
 CALL PATPLUG
 MOV (R0)+,R1
 CALL PATPLUG
 MOV (R0)+,R1
 MOV #MKPAT,R3
 CALL PATPLUG
 MOV (R0)+,R1
 CALL PATPLUG
 MOV #MJPAT,R3
 CALL PATPLUG
 MOV (R0)+,R1
 CALL PATPLUG
 END :OF IF APTFLAG IS TRUE
 BR SUBAAA L14:::~::~

PATPLUG:SUBST <<SUBR PLUG IN NULL PATTERNS>>

 :*SUBTEST SUBR PLUG IN NULL PATTERNS

1568 005472
 005472 012737 000001 002602
 005500
 1569 005500 006001
 1570 005502
 005502 103402
 1571 005504 012713 025772
 1572 005510
 005510
 1573 005510 062703 000002
 1574 005514
 005514 005237 002602
 005520 023727 002602 000020
 005526 003764
 005530
 1575 005530 000207

FOR I : #1 TO #16.
 MOV #1,I
 B0:::~::~
 ROR R1
 ON.NOERROR ;IF CARRY CLEAR
 BCS L15
 MOV #MT0999,(R3)
 END :OF ON.ERROR
 L15:::~::~
 ADD #2,R3
 END :OF FOR
 INC I
 CMP I,#16.
 BLE B0
 E0:::~::~
 RETURN

```

1578 005532          SUBAAA: SUBST <<PROTECT PROGRAM & LOADERS>>
:*****
:SUBTEST          PROTECT PROGRAM & LOADERS
:*****
1579 005532 052737 100000 003016      BIS      #BIT15,CONFIG          ;PROTECT PROGRAM SPACE (BANK 0)
1580 005540 052737 100000 003024      BIS      #BIT15,CONFIG+6      ;PROTECT LOADER SPACE (BANK 1)
1581 005546          IF #SENDAD NE 42 AND ONCE IS FALSE ;NOT ACT-11 AND NOT DONE ONCE?
      005546 022737 015000 000042      CMP      #SENDAD,+2
      005554 001405          BEQ      L16
      005556 005737 002732          TST     ONCE
      005562 001002          BNE     L16
1582 005564          .TYPE MSG000          ;TYPE PROGRAM TITLE
      005564 104401 111176      .TYPEIT ,MSG000
      .DSABL CRF
1583 005570          END ;OF IF #SENDAD
      005570
1584 005570          SUBST <<MULTIPOINT DETERMINATION ROUTINE>>
:*****
:SUBTEST          MULTIPOINT DETERMINATION ROUTINE
:*****
1585          ;DETERMINE
1586          :1. IF WE ARE MULTIPROCESSING
1587          :2. IF WE CAN USE THE IIST INTERFACE
1588          :3. EACH CPU'S ID (IIST NUMBER OR SYSTEM ID REGISTER)
1589          .ENABL LSB
1590 005570          IF NOIIST IS TRUE
      005570 005737 002756          TST     NOIIST
      005574 001427          BEQ     L17
1591 005576          IF ONCE IS FALSE
      005576 005737 002732          TST     ONCE
      005602 001005          BNE     L20
1592 005604          1$: .TYPE          MSG080          ;ENTER # OF SLAVE CPU'S (0-3)?
      005604 104401 115520      .TYPEIT ,MSG080
      .DSABL CRF
1593 005610 104413          RDOCT          ;READ AN OCTAL NUMBER ONTO THE STACK
1594 005612          POP SLAVES
      005612 012637 002730          MOV     (SP)+,SLAVES
1595 005616          END ;OF IF ONCE
      005616          L20:*****
1596 005616          IF SLAVES LT #0 OR SLAVES GT #3
      005616 005737 002730          TST     SLAVES
      005622 002404          BLT    L21
      005624 023727 002730 000003      CMP     SLAVES,#3
      005632 003401          BLE    L22
1597 005634          BR 1$
      005634 000763          L21:*****
1598 005636          END ;OF IF SLAVES
      005636          L22:*****
1599 005636          IF SLAVES EQ #0 THEN GOTO 2$
      005636 005737 002730          TST     SLAVES
      005642 001427          BEQ    2$
1600 005644 013737 177764 002606      MOV     SYSTID,PORTDIR
1601 005652          ELSE
      005652 000420          BR     L23
      005654          L17:*****
1602 005654          SET4 #2$          ;TRAPS TO 4 GOTO 2$
      005654 012737 005722 000004      MOV     #2$,4
    
```

```

MULTIPOINT DETERMINATION ROUTINE

1603 005662 012777 100000 175046      .DSABL CRF
1604 005670 017700 175042      MOV #BIT15,@IISTACR ;IS THERE AN IIST?
1605 005674 072027 177770      MOV @IISTACR,R0 ;YES - GET ID
1606 005700 042700 177774      ASH #-8,R0
1607 005704 010037 002606      BIC #^C3,R0
1608 005710 005777 175024      MOV R0,PORTDIR ;IDENTIFY MASTER
1609 005714      TST @IISTADR ;SEE IF 2ND IIST REGISTER TRAPS
005714      END ;OF IF NOIIST

1610 005714      SET MULTIPOINT ;MULTIPOINTING!
005714 012737 177777 003014      MOV #-1,MULTIPOINT
1611 005722 013706 002706      2$: MOV KSTACK,SP
1612 005726      RES4 ;RESET TRAPS TO 4 TO DEFAULT
005726 012737 036726 000004      MOV #TIMEOUT,4
005734 005037 177766      CLR CPUERR ;CLEAR OUT THE CPU ERROR REGISTER BITS
;THAT A EXPECTED TRAP COULD HAVE SET

1613 005740      .DSABL CRF
005740 012737 177777 002732      SET ONCE
1614 005746 005037 002670      CLR LOCK
1615      .DSABL LSB
    
```

```
1618 0C5752          BEGIN: SUBTST <<SLAVES START HERE>>
:*****
:*SUBTEST          SLAVES START HERE
:*****
1619 005752 000240          NOP
1620 005754 005237 002670          INC     LOCK           ;ONLY ONE CPU AT A TIME IS ALLOWED HERE
1621 005760          IF LOCK NE #1
      005760 023727 002670 000001          ;
      005766 001402          ;
1622 005770 000000          MHALT2: HALT           ;MULTIPLE CPU'S EXECUTING SAME CODE
1623 005772 000776          BR     MHALT2
1624 005774          END ;OF IF LOCK
      005774          ;IF I'M A SLAVE
1625 005774          IF CPUBIT NE #MASTER
      005774 023727 002114 000020          ;
      006002 001402          ;
1626 006004 004737 061244          CALL  SLAVEMAP
1627 006010          END ;OF IF CPUBIT
      006010          ;
                               L24:::
                               CMP CPUBIT,#MASTER
                               BEQ L24
                               L25:::
                               BEQ L25
```



```

1630 006010          SUBTST <<DETERMINE MK11 ACCESS METHOD>>
:*****
:*SUBTEST          DETERMINE MK11 ACCESS METHOD
:*****
1631                ;DETERMINE HOW WE ACCESS THE MK11 CSR'S.
1632                ;IF I CAN'T ACCESS THE CSR'S NORMALLY THEN I ASSUME THAT I MUST
1633                ;RELOCATE THRU THE UNIBUS MAP SO I SET THE 'CSR'S RELOCATED' FLAG (CSRREL)
1634                ;NOTE: I DON'T REALLY KNOW AT THIS POINT IF THERE IS ANY MK11 MEMORY YET
1635                ;      I ONLY DETERMINE HOW I WILL HAVE TO ACCESS IT IF THERE IS ANY.
1636 006010          SET4   #5$           ;TRAPS TO 4 GOTO 5$
          006010 012737 006036 000004      MOV    #5$,4
          .DSABL CRF
1637 006016 012700 000010          MOV    #8,R0           ;TEST FOR 8 CSR'S
1638 006022 012702 172100          MOV    #MK11ADD,R2      ;R2 = CSR ADDRESS
1639 006026 005712          4$: TST    (R2)           ;ANSWER R0 TRAP
1640 006030 005037 002254          CLR    CSRREL          ;ANSWER - CSR'S NOT RELOCATED
1641 006034 000410          BR     6$             ;BRANCH - OUT
1642 006036 062706 000004          5$: ADD    #4,SP        ;FIX STACK FROM TRAP
1643 006042 062702 000004          ADD    #4,R2          ;NEXT CSR = LAST CSR + 4
1644 006046 077011          SOB    R0,4$         ;LOOP TILL DONE
1645 006050          SET    CSRREL
          006050 012737 177777 002254      MOV    #-1,CSRREL
1646 006056          6$: RES4           ;RESET TRAPS TO 4 TO DEFAULT
          006056 012737 036726 000004      MOV    #TIMEOUT,4
          006064 005037 177766          CLR    CPUERR        ;CLEAR OUT THE CPU ERROR REGISTER BITS
          ;THAT A EXPECTED TRAP COULD HAVE SET
          .DSABL CRF
1647 006070          SUBTST <<SETUP USER & SUPERVISOR STACK>>
:*****
:*SUBTEST          SETUP USER & SUPERVISOR STACK
:*****
1648 006070 104421          DEENERGIZE          ;TURN OFF MEMORY MANAGEMENT
1649
1650                ;SET PREVIOUS MODE TO SUPERVISOR
1651 006072 042137 030000 177776      BIC    #BIT13!BIT12,PSW
1652 006100 052737 010000 177776      BIS    #BIT12,PSW
1653
1654 006106          PUSH    #SUPSTK
          006106 012746 000740          MTPJ   SSP           MOV #SUPSTK,-(SP)
1655 006112 006606
1656
1657                ;SET PREVIOUS MODE TO USER
1658 006114 052737 030000 177776      BIS    #BIT13!BIT12,PSW
1659
1660 006122          PUSH    #USESTK
          006122 012746 000700          MTPJ   USP           MOV #USESTK,-(SP)
1661 006126 006606
    
```

```

1664 006130          SUBTST <<GET SOFTWARE SWITCH REGISTER IF NECESSARY>>
:*****
:*SUBTEST          GET SOFTWARE SWITCH REGISTER IF NECESSARY
:*****
1665 006130          IF CPUBIT EQ #MASTER AND $AUTO IS FALSE ;IF MASTER & NOT (APT OR ACT)
    006130 023727 002114 000020          CMP CPUBIT,#MASTER
    006136 001010          BNE L26
    006140 005737 002066          TST $AUTO
    006144 001005          BNE L26
1666 006146          IF SWR EQ #SWREG          ;IF SOFTWARE SWITCH REG SELECTED
    006146 023727 002766 000176          CMP SWR,#SWREG
    006154 001001          BNE L27
1667 006156          GTSWR          ;;GET SOFT-SWR SETTINGS
    104407          END ;OF IF SWR
1668 006160          END ;OF IF CPUBIT          L27:;;;;;
1669 006160          L26:;;;;;
    006160
1670
1671 006160 012737 000020 172516          MOV #20,MMR3          ;SET 22 BIT MODE
1672 006166 005037 177750          CLR MAINT          ;CLEAR MARGINS
1673
1674 006172          SUBTST <<SETUP UNIBUS MAP>>
:*****
:*SUBTEST          SETUP UNIBUS MAP
:*****
1675 006172 012737 000077 170372          MOV #77,MAPH36          ;MAP36 IS USED TO ACCESS MK11 CSR'S ON PDP11-70'S
1676 006200 012737 160000 170370          MOV #160000,MAPL36          ;THAT DO NOT HAVE THE MULTIPROCESSOR MODIFICATIONS.
1677 006206 005037 170202          CLEAR MAPH0,MAPL0          ;MAP0 IS USED FOR APT TO LOOK AT THE MAILBOX THRU.
    006206 005037 170200          CLR MAPH0
    006212 005037 170200          CLR MAPL0
1678 006216 004737 042026          CALL LOWMAP          ;SETUP LOWER UNIBUS MAP
1679 006222 052737 000040 172516          BIS #BITS,MMR3          ;ENERGIZE UNIBUS MAP
1680
1681 006230          SUBTST <<GET MEMORY MANAGEMENT READY>>
:*****
:*SUBTEST          GET MEMORY MANAGEMENT READY
:*****
1682 006230          IF CPUBIT EQ #MASTER
    006230 023727 002114 000020          CMP CPUBIT,#MASTER
    006236 001001          BNE L30
1683 006240 104422          KMAP          ;MAP KERNEL SPACE 1 TO 1
1684 006242          END ;OF IF CPUBIT
1685 006242          MAP          ;MAP SUPERVISOR SPACE (TEST AREA) 1 TO 1
    006242 010346          MOV R3,-(SP)
    006244 012703 000170          MOV #120,R3
    006250 004737 040700          CALL MAPPER
    .DSABL CRF
1686 006254 012603          MOV (SP)+,R3
    104420          ENERGIZE          ;TURN ON MEMORY MANAGEMENT
    
```

1689 006260

NEWST <<ANALIZE CONFIGURATION>>

 :*TEST 1 ANALIZE CONFIGURATION

1690 006260 000004
 1690
 1691
 1692
 1693
 1694
 1695
 1696
 1697
 1698
 1699
 1700
 1701
 1702
 1703 006262 005037 002256
 1704 006266 013746 177746
 1705 006272 012737 006666 000004
 1706 006300 010637 006754
 1707 006304 006337 002334
 1708 006310 006337 002330
 1709 006314 104426
 1710 006316 052737 000001 002334
 1711 006324 005001
 1712 006326 013700 002146
 1713 006332 072027 177765
 1714 006336 042700 177770
 1715 006342 032700 000001
 006346 001403
 006350 052737 000400 002334
 006356
 1716 006356 010046
 006360 006316
 006362 004737 006406
 1717 006366 006756
 1718 006370 006760
 1719 006372 006760
 1720 006374 006766
 1721 006376 006766
 1722 006400 006774
 1723 006402 006766
 1724 006404 006774
 1725 006406
 006406
 006406 062616
 006410 013646
 006412 004736
 1726 006414 010137 002264
 1727 006420 004737 017736

```

TST1: SCOPE
:THIS CODE DOES THE FOLLOWING FOR MK11 CSR'S
:1. FINDS ANY EXISTING CSR'S - SETTING BITS IN LOC 'MKCSRS' FOR
:   EACH ONE PRESENT.
:2. SETS A BIT IN LOC 'MKCSRS' FOR ANY MK11 THAT IS INTERNALLY INTERLEAVED
:3. DETERMINES THE INTERLEAVE FACTOR & STARTING ADDRESS. USING THIS
:   WE DETERMINE THE FIRST & LAST BANK INCLUDED IN THIS CSR. USING THAT
:   THE CONFIGURATION TABLE IS UPDATED TO
:   A. IDENTIFY BANKS WITHIN THE RANGE AS MK11 MEMORY.
:   B. IDENTIFY BANKS WITHIN THE RANGE WITH INTERLEAVE FACTOR.
:   C. IF NO EXTERNAL INTERLEAVE IDENTIFY BANKS WITHIN THE RANGE
:   AS CONTROLLED BY THIS CSR
:   D. IDENTIFY BANKS WITHIN THE RANGE BY A SPECIFIC BIT POSITION
:   FOR THIS CSR
CLR   CSRNO           ;1ST CSR IS 0
PUSH  CONTRL         ;SAVE CACHE STATUS
MOV   CONTRL,-(SP)
1705  SET4   #CONFGT   ;TRAPS TO 4 GOTO CONFGT
      MOV   #CONFGT,4
      .DSABL CRF
      MOV   SP,CONFGT ;SAVE STACK
CONFG1: ASL   MKCSRS
        ASL   PENDBOX
        READCSR      ;TRAP IF IT DOES NOT EXIST
        BIS   #1,MKCSRS ;MARK CSR AS PRESENT
        CLR   R1
        MOV   CSR+2,R0
        ASH   #-11.,R0
        BIC   #^C7,R0
        IF #BIT0 SET.IN R0 THEN LET MKCSRS := MKCSRS SET.BY #BIT8
                                BIT #BIT0,R0
                                BEQ L31
                                BIS #BIT8,MKCSRS
                                L31:::::
1716  CASE R0
                                MOV R0,-(SP)
                                ASL @SP
                                JSR PC,L32
                                INTER0
                                INTER1
                                INTER2
                                INTER3
                                INTER4
                                INTER5
                                INTER6
                                INTER7
                                END ;OF CASE R0
                                L32:::::
                                ADD (SP)+,@SP
                                MOV @SP+,-(SP)
                                JSR PC,@SP+
1726  MOV   R1,INTERL   ;SET INTERLEAVE FACTOR
1727  CALL  GETSIZE
    
```

```

1728 ;THE NEXT 6 LINES SAVE THE READ STATUS OF THE BOX CAPACITY
1729 006424 013701 002256 MOV CSRNO,R1
1730 006430 006201 ASR R1
1731 006432 013761 002144 002154 MOV CSR,CSRO(R1)
1732 006440 013761 002146 002174 MOV CSR+2,CSR2(R1)
1733 006446 013761 002260 002214 MOV FIRSTB,CSRFB(R1)
1734 006454 IF FIRSTB GT #167
                                CMP FIRSTB,#167
                                BLE L33
1735 006462 023727 002260 000167
                                BIS #BIT0,PENDBOX
1736 006464 052737 000001 002330 JMP CONFG5
1737 006472 000137 006712 END ;OF IF FIRSTB
                                L33:::
1738 006476 013761 002262 002234 MOV LASTB,CSRLB(R1)
1739 006504 013701 002260 MOV FIRSTB,R1
1740 006510 070127 000006 MUL #6,R1 ;R1 = BANK * 6
1741 006514 010137 002110 MOV R1,BANKINDEX
1742 006520 013701 002110 CONF G3: MOV BANKINDEX,R1 ;GET NEXT INDEX (SAME FIRST TIME)
1743 006524 053761 002264 003016 BIS INTERL,CONFIG(R1) ;SETUP INTERLEAVE BITS
1744 006532 052761 020000 003016 BIS #BIT13,CONFIG(R1) ;IDENTIFY AS MK11
1745 006540 042761 040000 003016 BIC #BIT14,CONFIG(R1)
1746 006546 IF #BIT8 SET.IN MKCSRS
                                BIT #BIT8,MKCSRS
                                BEQ L34
1747 006556 032737 000400 002334 BIS #BIT12,CONFIG+2(R1)
1748 006564 001403 010000 003020 END ;OF IF #BIT8
                                L34:::
1749 006564 013700 002256 MOV CSRNO,R0 ;GET CSR LSB'S
1750 006570 072027 177776 ASH #-2,R0 ;MAKE (0-7)
1751 006574 IF #BIT13!BIT12 SET.IN CSR+2 ;ANY EXTERNAL INTERLEAVE?
                                BIT #BIT13!BIT12,CSR+2
                                BEQ L35
1752 006602 032737 030000 002146 BIS #BIT3,CONFIG(R1) ;IDENTIFY IT
1753 006604 052761 000010 003016 ELSE
                                BR L36
1754 006612 000406 L35:::
                                PUSH R0
                                MOV R0,-(SP)
1755 006614 010046 ASH #8,R0 ;MOVE TO BITS 10-8
1756 006616 072027 000010 ;IDENTIFY AS CSR & BOX NUMBER
1757 006622 050061 003016 BIS R0,CONFIG(R1)
1758 006626 012600 POP R0 ;MOV (SP)+,R0
1759 006630 012702 000001 END ;OF IF #BIT13!BIT12
                                L36:::
1760 006634 072200 MOV #1,R2 ;R2 = 1,2,4,10,20,40,100, OR 200
1761 006636 050261 003022 ASH R0,R2 ;SETUP CSR WORD
1762 006642 062737 000006 002110 BIS R2,CONFIG+4(R1) ;NEXT TABLE ENTRY
1763 006650 005237 002260 ADD #6,BANKINDEX
1764 006654 023737 002260 002262 INC FIRSTB
1765 006662 101716 CMP FIRSTB,LASTB ;DONE?
1766 006664 000412 BLOS CONFG3 ;NO - LOOP
1767 006666 013706 006754 CONF G4: MOV CONFG5,SP ;FIX STACK FROM MULTIPLE TRAP
1768 006672 032737 000020 177766 IF #BIT4 OFF.IN CPUERR
                                BIT #BIT4,CPUERR
                                BNE L37
1769 006702 LET GOOD :- #BIT4
    
```

ANALYZE CONFIGURATION

```

006702 012737 000020 002050
1770 006710 104037
1771 006712
006712
1772 006712 062737 000004 002256 CONFIG5: ADD #4,CSRNO ;BUMP CSR
1773 006720 023727 002256 000040 IF CSRNO NE #40 THEN JUMPTO CONFIG1
006720 001402
006726 001402
006730 000137 006304
006734
1774 006734 RES4 ;RESET TRAPS TO 4 TO DEFAULT
006734 012737 036726 000004 MOV #TIMEOUT,4
006742 005037 177766 CLR CPUERR ;CLEAR OUT THE CPU ERROR REGISTER BITS
;THAT A EXPECTED TRAP COULD HAVE SET

.DSABL CRF
POP CONTRL ;RESTORE CACHE STATUS
MOV (SP)+,CONTRL

BR SUBAAS
CONFSP: 0 ;STACK SAVED HERE!

;TOTAL INTERLEAVE (0, 2-1, 4-1, OR 8-1)
INTER0: RETURN ;NO INTERLEAVE

INTER1:
INTER2: MOV #1,R1 ;2 WAY INTERLEAVE
RETURN

INTER3:
INTER4:
INTER6: MOV #2,R1 ;4 WAY INTERLEAVE
RETURN

INTER5:
INTER7: MOV #4,R1 ;8 WAY INTERLEAVE
RETURN
    
```

```

1795 007002 104472          SUBAAS: ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
1796 007004                NEWTST <<TEST BANK 0 ACCESSES>>
:*****
:*TEST 2          TEST BANK 0 ACCESSES
:*****
007004 000004          TST2: SCOPE
1797                ;THIS DOES A 'TST' INSTRUCTION ON EVERY LOCATION IN BANK #0 TO SEE
1798                ;IF IT GETS ANY PARITY TRAPS.
1799                ;SINCE EVERY LOCATION IS EITHER LOADED OR WRITTEN INTO BY THE PROGRAM
1800                ;PRIOR TO THIS POINT - THEN A PARITY ERROR IMPLIES THAT THERE IS A
1801                ;HARDWARE FAILURE IN THE MEMORY.
1802                ;THESE ERRORS ARE COUNTED AND A FATAL ACTION IS TAKEN
1803 007006 005037 002074 CLR PARCNT          ;CLEAR PARITY ERROR COUNTER
1804 007012 012737 000001 002100 MOV #1,NOPAR        ;SET THE NO PARITY ERROR FLAG
1805 007020 005037 002072 CLR NEMCNT          ;CLEAR NON-EXISTANT MEMORY ERROR COUNTER
1806 007024 012737 000001 002102 MOV #1,NONEM        ;SET THE NON-EXISTANT MEMORY ERROR MODE TO COUNT
1807 007032 007032 012737 036646 000004 SET4 #NONEXIST     ;TRAPS TO 4 GOTO NONEXIST
      007032 012737 036646 000004 MOV #NONEXIST,4
      .DSABL CRF
1808 007040 005000 CLR RO
1809 007042 012701 040000 MOV #SIZE,R1
1810 007046 104424 CACHOFF           ;TURN CACHE OFF
1811 007050 005720 1$: TST (R0)+           ;SEE IF I CAN DO A READ ACCESS WITHOUT A PARITY TRAP
1812 007052 077102 SOB R1,1$
1813 007054 104423 CACHON           ;TURN CACHE ON
1814                ;SEE IF ANY FAILURES
1815 007056 005737 002074 TST PARCNT          ;ANY PARITY ERRORS?
1816 007062 001403 BEQ 2$           ;NO - SKIP
1817 007064 FATAL 3
      007064 005237 002070 INC FATAL$         ;SET FATAL INDICATOR
      007070 104003 ERROR +3
1818 007072 005737 002072 2$: TST NEMCNT          ;ANY NON-EXISTANT MEMORY (HOLES)?
1819 007076 001406 BEQ 3$           ;SKIP IF EQUAL
1820 007100 162737 000002 002040 SUB #2,ADDRESS     ;UPDATE 1ST ADDRESS FAILURE FROM AUTO INCREMENT #
1821 007106 FATAL 4
      007106 005237 002070 INC FATAL$         ;SET FATAL INDICATOR
      007112 104004 ERROR +4
1822 007114 053737 002114 003016 3$: BIS CPUBIT,CONFIG ;SET CORRECT ACCESSED BIT ON BANK 0
1823 007122 007122 012737 036726 000004 RES4           ;RESET TRAPS TO 4 TO DEFAULT
      007130 005037 177766 MOV #TIMEOUT,4
      CLR CPUERR          ;CLEAR OUT THE CPU ERROR REGISTER BITS
      ;THAT A EXPECTED TRAP COULD HAVE SET
      .DSABL CRF
1824
1825 007134          SUBTST <<ENABLE MK11 FOR CORRECT TRAPS>>
:*****
:*SUBTEST          ENABLE MK11 FOR CORRECT TRAPS
:*****
1826 007134          IF #SW0 SET.IN @SWR OR ACTFLAG IS TRUE
      007134 032777 000001 173624 BIT #SW0,@SWR
      007142 001003 BNE L41
      007144 005737 002442 TST ACTFLAG
      007150 001402 BEQ L42
      007152
1827 007152 104506          ENASBE          ;TRAP ON SINGLE BIT ERRORS
  
```

L41:::~::~

1828 007154
007154 000401
007156
1829 007156 104472
1830 007160
007160

ELSE

ECCINIT
END ;OF IF #SWO

BR L43
L42::: L43
;TRAP ON DOUBLE BIT ERRORS (NORMAL)

L43::: L43

1833 007160

NEWST <<TEST BANKS 1-167 (OCTAL) FOR ZEROS & ONES>>

 :*TEST 3 TEST BANKS 1-167 (OCTAL) FOR ZEROS & ONES

1834 007160 000004
 1834 007162 005037 002106
 1843 007166 012737 000001 002100
 1844 007174 012737 000002 002102
 1845 007202 012737 036646 000004
 1846 007210 004537 043710
 007210 026376
 007214
 1847 007216 012737 005237 177654
 1848 007224 012737 002076 177656
 1849 007232 005237 002106
 1850 007236 022737 000170 002106
 1851 007244 001450
 1852 007246 013701 002106
 1853 007252 070127 000006
 1854 007256 010137 002110
 1855 007262 005037 002076
 1856 007266 005037 002074
 1857 007272 005037 002072
 1858 007276 010346
 007300 013703 002106
 007304 004737 040700
 007310 012603
 1859 007312 005761 003013
 1860 007316 100533
 1861 007320 012737 000207 177644 WARN1:
 1862 007326 012700 060000
 1863 007332 010004
 1864 007334 012701 040000
 1865 007340 010103
 1866 007342 005002
 1867 007344 104424
 1868 007346 052737 040000 177776
 007346
 1869 007354 004737 177640
 1870 007360 104417
 1871 007362 104423
 1872 007364 000412
 1873 007366 005037 002106

TST3: SCOPE
 :EACH BANK IS TESTED FOR EXISTANCE AND IF IT EXISTS
 :THEN IS IS TESTED FOR ZEROS & ONES.
 :EXCEPT -
 :
 : PROTECTED BANKS (WHERE THE PROGRAM IS) ARE ONLY TESTED BY
 : 'TST' INSTRUCTIONS LIKE BANK #0
 :
 :ANY BAD BANKS ARE LOGGED IN THE CONFIGURATION TABLE.
 :ANY ERROR HERE WILL FORCE THE CONFIGURATION TABLE TYPEOUT.
 :THIS ROUTINE IS ONLY DOING A SMART SIZE - NOT ACTUAL TESTING
 CLR BANK
 MOV #1,NOPAR ;SET NO PARITY ERROR FLAG
 MOV #2,NONEM ;SET NON-EXISTANT MEMORY MODE TO EXIT TEST LOOP
 SET4 #NONEXIST ;TRAPS TO 4 GOTO NONEXIST
 MOV #NONEXIST,4
 .DSABL CRF
 BMOV MTP000 ;PUT IN FAST MEMORY
 JSR R5,BLOCK1
 MTP000
 .DSABL CRF
 MOV #005237,UIPAR6 ;PUT 'INC ' INSTRUCTION IN SUBROUTINE
 MOV #PATERR,UIPAR7 ;PUT IN ADDRESS OF OPERAND FOR ABOVE
 TAG9\$: INC BANK
 CMP #120,BANK ;DONE?
 BEQ TAG2\$;YES - SKIP TO NEXT TEST
 MOV BANK,R1
 MUL #6,R1 ;BANK*3*2
 MOV R1,BANKINDEX
 CLR PATERR ;CLEAR PATTERN ERROR COUNTER
 CLR PARCNT ;CLEAR PARITY ERROR COUNTER
 CLR NEMCNT ;CLEAR NON-EXISTANT MEMORY COUNTER (HOLE)
 MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
 MOV R3,-(SP)
 MOV BANK,R3
 CALL MAPPER
 .DSABL CRF
 MOV (SP)+,R3
 TST CONFIG(R1) ;IS THIS BANK PROTECTED?
 BMI TSTBANK ;YES - GO TEST BANK SPECIAL
 MOV #207,UIPAR2 ;PUT 'RETURN' INSTRUCTION AFTER WRITE ROUTINE
 MOV #FIRST,R0
 MOV R0,R4
 MOV #SIZE,R1
 MOV R1,R3
 CLR R2 ;DATA IS ZEROS
 CACHOFF ;TURN CACHE OFF
 SUPERVISOR ;ENTER SUPERVISOR MODE
 BIS #BIT14,PSW ;DO IT TO IT!
 .DSABL CRF
 CALL FASTCITY ;CALL TO THE USER INSTRUCTION PAR'S
 KERNEL ;ENTER KERNEL MODE
 CALHON ;TURN CACHE ON
 BR TAG3\$;SKIP NEXT INSTRUCTION
 TAG2\$: CLR BANK


```

1874 007372          RES4          ;RESET TRAPS TO 4 TO DEFAULT
      007372 012737 036726 000004  MOV      #TIMEOUT,4
      007400 005037 177766          CLR      CPUERR          ;CLEAR OUT THE CPU ERROR REGISTER BITS
                                   ;THAT A EXPECTED TRAP COULD HAVE SET

      .DSABL CRF
1875 007404 005037 002100          CLR      NOPAR          ;INDICATE DEFAULT PARITY ACTION
1876 007410 000543          BR       SUBAAQ
1877 007412 005737 002072          TAG3$: TST     NEMCNT          ;ANY TRAPS?
1878 007416 001401          BEQ     1$              ;NO - SKIP
      007420 000704          BR       TAG9$          ;NOW - TRY NEXT BANK
1880 007422          1$: CACHOFF          ;TURN CACHE OFF
      007424 052737 040000 177776  SUPERVISOR ;ENTER SUPERVISOR MODE
                                   ;DO IT TO IT.

      .DSABL CRF
1882 007432 004737 177646          CALL    UIPAR3          ;FINISH PATTERN
1883 007436 104417          KERNEL ;ENTER KERNEL MODE
1884 007440 104423          CACHON          ;TURN CACHE ON
1885 007442 005737 002076          TST     PATERR          ;ANY PATTERN ERRORS
1886 007446 001031          BNE     2$              ;YES - SKIP
1887 007450 005737 002074          TST     PARCNT          ;ANY PARITY ERRORS
1888 007454 001026          BNE     2$              ;YES - SKIP
1889 007456 005737 002072          TST     NEMCNT          ;ANY NON EXISTANT MEMORY
1890 007462 001023          BNE     2$              ;YES - SKIP
1891 007464 012700 060000          MOV     #FIRST,R0
1892 007470 010004          MOV     R0,R4
1893 007472 012701 040000          MOV     #SIZE,R1
1894 007476 010103          MOV     R1,R3
1895 007500 013702 002726          MOV     ONES,R2          ;DATA IS ONES
1896 007504 012737 000240 177644  MOV     #000240,UIPAR2 ;PUT 'NOP' INSTRUCTION BACK !N SUBROUTINE
1897 007512 104424          CACHOFF          ;TURN CACHE OFF
1898 007514 052737 040000 177776  SUPERVISOR ;ENTER SUPERVISOR MODE
                                   ;DO IT TO IT!

      .DSABL CRF
1899 007522 004737 177640          CALL    FASTCITY        ;CALL TO THE USER INSTRUCTION PAR'S
1900 007526 104417          KERNEL ;ENTER KERNEL MODE
1901 007530 104423          CACHON          ;TURN CACHE ON
1902 007532 013700 002110          2$: MOV     BANKINDEX,R0
1903 007536 005737 002076          TST     PATERR          ;ANY PATTERN ERRORS?
1904 007542 001006          BNE     3$              ;YES - SKIP
1905 007544 005737 002074          TST     PARCNT          ;ANY PARITY ERRORS?
1906 007550 001003          BNE     3$              ;YES - SKIP
1907 007552 005737 002072          TST     NEMCNT          ;ANY HOLES?
1908 007556 001406          BEQ     4$              ;NONE - SKIP
1909 007560 052760 004000 003016  3$: BIS     #BIT11,CONFIG(R0) ;SET ERROR BIT IN THIS BANK
1910 007566          SET     CONFGERROR      ;FORCE PRINTING OF CONFIGURATION TABLE
                                   MOV     #-1,CONFGERROR
1911 007574 053760 002114 003016  4$: BIS     (PUBIT,CONFIG(R0) ;SET ACCESSED BIT
1912 007602 000137 007232          JMP     TAG9$

1913
1914          ;TEST A PROTECTED BANK
1915 007606          TSTBANK:PUSH R1
                                   MOV R1,-(SP)
1916 007610 010146 000001 002102  MOV     #1,NONEM          ;SET NON-EXISTANT MEMORY TO COUNT
1917 007616 012700 060000          MOV     #FIRST,R0
1918 007622 012701 040000          MOV     #SIZE,R1
1919 007626 104424          CACHOFF          ;TURN CACHE OFF
1920 007630          SUPERVISOR ;ENTER SUPERVISOR MODE
  
```

```

007630 052737 040000 177776      BIS    #BIT14,PSW          ;DO IT TO IT
                                .DSABL  (RF)
1921 007636 005720                48:   TST    (R0),
1922 007640 077102                SOB    R1,48
1923 007642 104417                KERNEL
1924 007644 104423                CACHON          ;ENTER KERNEL MODE
1925 007646 012737 000002 002102  MOV    #2,NONEM      ;TURN CACHE ON
1926 007654                POP    R1           ;RESET NON-EXISTANT MEMORY TO EXIT TEST LOOP
                                MOV (SP)+,R1
1927 007656                IF PARCNT NE #0
                                TST PARCNT
                                BEQ L44
1928 007664 005737 002074          BIS    #BIT11,CONFIG(R1)  ;ERROR BANK
1929 007672 052761 004000 003016  SET    CONFGERROR      ;FORCE PRINTING OF CONFIGURATION TABLE
                                MOV #-1,CONFGERROR
1930 007700                END ;OF IF PARCNT
                                L44:*****
1931 007700                IF NEMCNT EQ #0
                                TST NEMCNT
                                BNE L45
1932 007706 005737 002072          BIS    (PUBIT,CONFIG(R1) ;ACCESSED BANK
1933 007714 053761 002114 003016  END ;OF IF NEMCNT
                                L45:*****
1934 007714 000137 007232          JMP    TAG9$
    
```



```
010226 005237 002106
010232 025727 002106 000167
010240 003640
2019 010242
010242 010346
010244 012703 000170
010250 004737 040700
010254 012603
2020 010256 005037 002106
2021
2022 010262
010262 032777 000001 172476
010270 001003
010272 005737 002442
010276 001402
010300
2023 010300 104506
2024 010302
010302 000401
010304
2025 010304 104472
2026 010306
010306
2027
2028 010306 104423
```

```
INC BANK
CMP BANK,#167
BLE B1
E1:
;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
MOV R3,-(SP)
MOV (SP)+,R3
CLR BANK
IF #SWO SET.IN @SWR OR ACTFLAG IS TRUE
BIT #SWO,@SWR
BNE L54
TST ACTFLAG
BEQ L55
L54:
ENASBE ;TRAP ON SINGLE BIT ERRORS
ELSE
BR L56
L55:
ECCINIT ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
END ;OF IF #SWO
L56:
CACHON ;TURN CACHE ON
```

2031 010310
2032 010312
2033 010312
2034 010312
2035 010316
2036 010322
2037 010336
2038 010344
2039 010346
2040 010346
2041 010350
2042 010350
2043 010364

000004
005037 002106
004737 042422
005737 002126
001410
005737 002124
001405
005737 002122
001001
104040
000406
005237 002106
023727 002106 000167
003755

```
NEWST <<MK11 PROTECTION POINTER TEST>>
:.....
:TEST 4      MK11 PROTECTION POINTER TEST
:.....
TST4:  SCOPE
      ;INSURE THAT BOTTOM OF MK11 WAS PROTECTED WITH PROTECTION POINTER CLEAR
      BEGIN PROTECTIONTEST
      FOR BANK := #0 TO #167
      CALL EXBANK
      IF MKFLAG IS TRUE AND ACFLAG IS TRUE
      TST MKFLAG
      BEQ L57
      TST ACFLAG
      BEQ L57
      IF KPFLAG IS FALSE
      TST KPFLAG
      BNE L60
      ERROR +40 ;MK11 PROTECTION POINTER FAILURE - DID NOT PROTECT BANK
      END ;OF IF KPFLAG
      LEAVE PROTECTIONTEST
      END ;OF IF MKFLAG
      END ;OF FOR BANK
      INC BANK
      CMP BANK,#167
      BLE B3
      END PROTECTIONTEST
```

B2:.....
CLR BANK
B3:.....
L60:.....
BR E2
L57:.....
E3:.....
E2:.....

2046 C10364

SUBTST <<CHECK SYSTEM SIZE REGISTER>>
:*****
:SUBTEST CHECK SYSTEM SIZE REGISTER
:*****

2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079

: THIS CHECKS THE SYSTEM SIZE REGISTER TO INSURE IT IS CORRECT
: AND PROGRAMS ANY MK11 BOXES ON LINE THAT ARE NOT INHIBITED.
:
: NOTE: IF THE SYSTEM SIZE REGISTER IS SET TO INDICATE A VERY SMALL
: MEMORY THE PROGRAM MAY NOT BE ABLE TO FUNCTION.
: IF THE MK11 BOX STARTING ADDRESS LOGIC MALFUNCTIONS THE PROGRAM
: WILL EITHER CRASH BECAUSE OF DUAL ADDRESSING PROBLEMS OR
: WILL HAVE HOLES IN MEMORY (NON-EXISTANT BANKS).
:
: THE TEST FUNCTIONS AS FOLLOWS
:
: 1. THE PROGRAM CHECKS FOR MEMORY ON 16K WORD (BANK) BOUNDRIES
: THRU THE UNIBUS MAP (SO THAT THE SYSTEM SIZE REGISTER IS BYPASSED).
: LOCATION 'UNITOP' IS ASSIGNED THE NUMBER OF THE LAST BANK THAT WAS
: ACCESSABLE VIA THE UNIBUS MAP.
:
: 2. LOCATION 'HIBANK' IS SET TO THE HIGHEST BANK THAT IS EITHER
: (1) DIRECTLY ACCESSABLE VIA THE MEMORY BUS OR
: (2) AN MK11 CSR CLAIMS THAT IT EXISTS.
:
: 3. LOCATION 'HIACBANK' IS ASSIGNED THE NUMBER OF THE HIGHEST BANK
: THAT IS DIRECTLY ACCESSABLE VIA THE MEMORY BUS.
:
: 4. IF THE HIGHEST ACCESSABLE BANK IS LESS THAN #170
: IF ANY BOX STARTING ADDRESSES WERE ABOVE BANK #167
: TRY TO PROGRAM THE STARTING ADDRESS OF THE PENDING BOX
: IF IT DOES PROGRAM DOWN AND THEREFORE ADD MEMORY TO THE SYSTEM
: RESTART THE PROGRAM
: NEXT PENDING BOX
:
: 5. R0 IS SET TO THE HIGHEST BANK NUMBER OF HIBANK OR UNITOP
:
: 6. IF THE SYSTEM SIZE REGISTER DOES NOT EQUAL R0'S BANK THEN PRINT THE ERROR

```

2082                                ;FIND UNITOP
2083 010364 104424                   CACHOFF
2084 010366 005037 170372           CLR     MAPH36                   ;TURN CACHE OFF
2085 010372 012737 100000 170370   MOV     #100000,MAPL36          ;SET MAP TO BANK 1
2086 010400 010400 012737 010446 000004
                                MOV     #2$,4                   ;TRAPS TO 4 GOTO 2$
                                .DSABL CRF
2087 010406 012737 000004 002100   MOV     #4,NOPAR                ;PARITY ACTION = COUNT & IGNORE
2088 010414 012700 140000           MOV     #140000,R0              ;PAR6 SELECTED
2089 010420 005710 170370 1$:      TST     (R0)                   ;TRAP IF NON-EXISTANT
2090 010422 062737 100000 170370   ADD     #100000,MAPL36         ;BUMP 1 BANK
2091 010430 005537 170372           ADC     MAPH36
2092 010434 022737 000073 170372   CMP     #73,MAPH36             ;INTO 128K SHADOW MEMORY?
2093 010442 001366 170372           BNE     1$                     ;NO - LOOP
2094 010444 000402 170372           BR      3$
2095 010446 062706 000004           ADD     #4,SP                  ;FIX STACK FROM TRAP
2096 010452 162737 100000 170370 3$:   SUB     #100000,MAPL36
2097 010460 005637 170372           SBC     MAPH36
2098 010464 010464 012737 036726 000004
                                RES4
                                MOV     #TIMEOUT,4           ;RESET TRAPS TO 4 TO DEFAULT
                                CLR     CPUERR
                                ;CLEAR OUT THE CPU ERROR REGISTER BITS
                                ;THAT A EXPECTED TRAP COULD HAVE SET
2099 010476 005037 002100           .DSABL CRF
2100 010502 006137 170370           CLR     NOPAR                  ;RESTORE DEFAULT PARITY ACTION
2101 010506 006137 170372           ROL     MAPL36
2102 010512 013737 170372 002516   ROL     MAPH36
2103                                MOV     MAPH36,UNITOP
2104                                ;FIND HIBANK
2105 010520 012737 000077 170372   MOV     #77,MAPH36             ;RESTORE MAP36
2106 010526 012737 160000 170370   MOV     #160000,MAPL36
2107 010534 104423 170372           CACHON
2108 010536 013746 002730 002730   PUSH   SLAVES                 ;TURN CACHE ON
                                MOV     SLAVES,-(SP)
2109 010542 012737 000003 002730   MOV     #3,SLAVES              ;FAKE OUT THE EXBANK ROUTINE
2110 010550 010550 000000 000000   BEGIN MEMSIZELOOP
2111 010550 010550 000000 000000   FOR BANK := #0 TO #167
                                B4:::
2112 010550 005037 002106 002106   CLR     BANK
                                B5:::
2113 010554 004737 042422 042422   CALL    EXBANK
                                IF ACFLAG IS FALSE AND MKFLAG IS FALSE
2114 010560 005737 002124 002124   TST     ACFLAG
2115 010564 001004 002126 002126   BNE     L61
2116 010566 005737 002126 002126   TST     MKFLAG
2117 010572 001001 002126 002126   BNE     L61
2118 010574 000406 002126 002126   LEAVE  MEMSIZELOOP
                                BR     E4
2119 010576 000406 002126 002126   END ;OF IF ACFLAG
                                L61:::
2120 010576 000406 002126 002126   END ;OF FOR BANK
                                INC     BANK
2121 010576 005237 002106 002106   CMP     BANK,#167
2122 010602 023727 002106 000167   BLE     B5
2123 010610 003761 002106 000167   E5:::
2124 010612 003761 002106 000167   E4:::
2125 010612 003761 002106 000167   END MEMSIZELOOP
    
```


CHECK SYSTEM SIZE REGISTER

2118	010612	013700	002106	MOV	BANK,RO
2119	010616	005300		DEC	RO
2120	010620	010037	002512	MOV	RO,HIBANK

```

2123                                     ;FIND HIACBANK
2124 010624 CLEAR BANK,HIACBANK
      010624 005037 002106
      010630 005037 002514
2125 010634 SET ACFLAG
      010634 012737 177777 002124
2126 010642 WHILE ACFLAG IS TRUE AND BANK LT #167
      010642
      010642 005737 002124
      010646 001411
      010650 023727 002106 000167
      010656 002005
2127 010660 INC BANK
2128 010664 CALL EXBANK
2129 010670 END ;OF WHILE ACFLAG
      010670 000764
      010672
      010672
2130 010672 POP SLAVES ;RESTORE FROM FAKE OUT
      010672 012637 002730
2131 010676 013737 002106 002514 MOV BANK,HIACBANK
2132                                     ;PROGRAM ON ANY BOXES SETUP FOR ALLOW PROGRAM
2133                                     ;& HI (100) STARTING ADDRESSES
2134                                     IF HIACBANK LT #170
2135 010704
      010704 023727 002514 000170
      010712 002071
2136 010714 IF PENDBOX IS TRUE
      010714 005737 002330
      010720 001466
2137 010722 013701 002330
2138 010726 MOV PENDBOX,R1
      010726 005037 002256 FOR CSRNO := #0 TO #34 BY #4
      010732
2139 010732 ASLB R1
2140 010734 ON.ERROR
      010734 103051
2141 010736 SET TWOCRS
      010736 012737 177777 002600
2142 010744 MOV #1,CSR
      010744 012737 000001 002144
2143 010752 MOV HIACBANK,CSR+2
      010752 013737 002514 002146
2144 010760 CLC
2145 010762 ROR CSR+2
      010762 006037 002146
2146 010766 ADC CSR+2 ;IF NOT 32K WORD BOUND LEAVE A WHOLE IN MEM
      010766 005537 002146
2147 010772 BIS #BIT10,CSR+2 ;LOAD START ADD & INTERLEAVE BIT
      010772 052737 002000 002146
2148 011000 LOADCSR
2149 011002 CLEAR CSR,CSR+2,TWOCRS
      011002 005037 002144
      011006 005037 002146
      011012 005037 002600
2150 011016 MOV #BIT13,CSR
      011016 012737 000010 002144
2151 011024 LOADCSR
2152 011026 READCSR
      011026 104425
2153 011030 MOV CSR+2,R2
      011030 013702 002146
2154 011034 BIC #177000,R2
      011034 042702 177000
2155 011040 ASL R2
      011040 006302
2156 011042 IF R2 LT #167 ;IF I CHANGED IT'S STARTING ADDRESS
    
```

011042 020227 000167
011046 002004
2157 011050 005037 002670
2158 011054 000137 004352
2159 011060
011060
2160 011060
011060
2161 011060
011060 062737 000004 002256
011066 023727 002256 000034
011074 003716
011076
2162 011076
011076
2163 011076
011076

CLR LOCK
JMP START
END ;OF IF R2

END ;OF ON.ERROR

END ;OF FOR CSRNO

END ;OF IF PENDBOX
END ;OF IF HIACBANK

CMP R2,#167
BGE L66

L66:.....

L65:.....

ADD #4,CSRNO
CMP CSRNO,#34
BLE B7

E7:.....

L64:.....

L63:.....


```
011306
2196 011306 032700 000100 IF #BIT6 SET..IN R0 THEN LET R1 := R1 SET.BY #BIT5 L75:.....
011306 001402 BIT #BIT6,R0
011312 001402 BEQ L76
011314 052701 000040 BIS #BIT5,R1
011320
2197 011320 032700 000200 IF #BIT7 SET.. R0 THEN LET R1 := R1 SET.BY #BIT6 L76:.....
011320 001402 BIT #BIT7,R0
011324 001402 BEQ L77
011326 052701 000100 BIS #BIT6,R1
011332
2198 011332 000207 RETURN L77:.....
```



```
011532
2231
2232 011532 012700 172340
2233 011536 012701 002550
2234 011542 012705 000010
2235 011546 012021
2236 011550 077502
2237 011552
011552
2238
2239 011552
011552 012737 177777 002520

;COPY MAPPING FOR ANY SLAVES
MOV #KIPAR0,R0
MOV #K10,R1
MOV #8,R5
MOV (R0)+,(R1)+
SOB R5,1$
END ;OF IF CPUBIT

L104:
L100:
SE* STOPOK
MOV #-1,STOPOK
```



```

MULTI PORT HOOK
011714
2279 011714 010260 002606      MOV     R2,PORTDIR(R0)
2280
2281
2282 011720 010003      ;THIS IS WHERE THE SLAVES COME TO STOP
2283 011722      STOPCPU:MOV     RO,R3
011722 005737 002756      IF NOIIST IS TRUE
011726 001417
2284 011730      IF RO EQ #0 THEN GOTO MP1      ;SKIP IF I'M THE MASTER
011730 005700
011732 001456
2285 011734 052760 100000 002616      BIS     #BIT15,TASK(RO)
2286 011742      BMOV    WAITSTUFF
011742 004537 043710      JSR     R5,BLOCK1
011746 012034      WAITSTUFF
      .DSABL     CRF
2287 011750 005337 002670      DEC     LOCK      ;ALLOW OTHERS TO RUN
2288 011754 062700 002636      ADD     #PTYBUF,RO ;RO POINTS TO COUNT DOWN LOCATION
2289
2290
2291 011760 000137 177640      JMP     FASTCITY   ;WAIT FOR MASTER TO COUNT DOWN!
2292 011764      ELSE              ;CALL TO THE USER INSTRUCTION PAR'S
011764 000423
011766
2293 011766 004737 061074      CALL    IISTINIT
2294 011772      IF RO EQ #0 THEN GOTO MP1      ;SKIP IF I'M THE MASTER
011772 005700
011774 001435
2295 011776 012777 000001 170732      MOV     #1,@IISTACR
2296 012004 012777 000004 170726      MOV     #BIT2,@IISTADR
2297 012012 000234      SPL     4          ;ENABLE INTERRUPTS
2298 012014 052760 100000 002616      BIS     #BIT15,TASK(RO)
2299 012022 005337 002670      DEC     LOCK      ;ALLOW OTHERS TO RUN
2300 012026 000001      WAIT      ;WAIT IF I'M A SLAVE
2301 012030 000137 050726      JMP     TASKDO
2302 012034      END ;OF IF NOIIST
012034
L112:
BR L114
L113:
TST RO
BEQ MP1
L114:

```

2305 012034

WAITSTUFF:SUBTST <<SLAVES WAIT FOR MASTER TO COUNT DOWN>>
:.....
: *SUBTEST SLAVES WAIT FOR MASTER TO COUNT DOWN
:.....

2306 012034 012702 000014
2307 012040 012701 000013
2308 012044 005302
2309 012046 005301
2310 012050 020210
2311 012052 001776
2312 012054 020110
2313 012056 001366
2314 012060 005701
2315 012062 001370
2316 012064 000137 061216

1\$: MOV #12.,R2 ;V177640
MOV #11.,R1 ;V177644
2\$: DEC R2 ;V177650
DEC R1 ;V177652
3\$: CMP R2,(R0) ;V177654
BEQ 3\$;V177656
CMP R1,(R0) ;V177660
BNE 1\$;V177662
4\$: TST R1 ;V177664
BNE 2\$;V177666
JMP SLAVUP ;V177670

2319 012070

```
MP1:  SUBST <<BOOT UP ALL EXISTING CPU'S>>
:*****
:SUBTEST  BOOT UP ALL EXISTING CPU'S
:*****
:ALL SLAVES ARE BOOTED AS FOLLOWS
:
:SETUP A SOFTWARE SWITCH REGISTER.
:IF WE ARE USING IIST'S.
:  BEGIN BOOTLOOP
:    FOR EACH OF 4 POSSIBLE CPU'S.
:      SETUP STACK VALUE LESS THAN PREVIOUS CPU.
:      CLEAR ACKNOWLEDGE.
:      POINT IIST INTERRUPT VECTOR TO START.
:MP2:  WAIT FOR THE MASTER'S IIST TO BE READY (SHOULD ALREADY BE).
:      INITIALIZE THE MASTER'S IIST (DISABLE BOOTS & INTERRUPTS).
:      INITIATE THE IIST BOOT OF THE SELECTED CPU.
:      WAIT FOR THE WINDOW IN THE BOOT THAT ALLOWS INTERRUPTS.
:      INITIATE THE IIST INTERRUPT OF THE SELECTED CPU.
:      WAIT FOR THE SLAVE TO ACKNOWLEDGE STARTING.
:      IF THE CPU DOES NOT ACKNOWLEDGE
:        IF THE CPU SELECTED IS NOT THE MASTER
:          LEAVE BOOTLOOP.
:        ELSE
:          GOTO MP2.
:      END OF IF THE CPU SELECTED IS NOT THE MASTER.
:    ELSE
:      WAIT FOR TASK DONE FROM SLAVE (TASK=START).
:      UPDATE SLAVE COUNT (THIS SLAVE IS THE HIGHEST # SO FAR).
:      IF THIS WAS THE 4TH CPU THEN LEAVE BOOTLOOP.
:    END OF IF THE CPU DOES NOT ACKNOWLEDGE.
:  END OF FOR EACH OF 4 POSSIBLE CPU'S.
:END OF BOOTLOOP.
:IF THERE WERE NO SLAVES
:  CLEAR THE MULTIPROCESSING FLAG 'MULTIPORT'.
:  SET THE IIST VECTOR TO LOOK FOR UNEXPECTED TRAPS.
:END OF IF THERE WERE NO SLAVES.
:ELSE
:  FOR EACH SLAVE
:    SETUP STACK VALUE LESS THAN PREVIOUS CPU.
:    TYPE 'START SLAVE #N AT ADDRESS 200'.
:    WAIT FOR TASK DONE FROM SLAVE (TASK=START).
:  END OF FOR EACH SLAVE.
:END OF IF WE ARE USING IIST'S.
:RESTORE THE MASTER TO THE NORMAL SWITCH REGISTER
:WAIT A SECOND.
:MAKE SURE I'M THE ONLY PROCESSOR RUNNING.
:SETUP STACK VALUE BACK TO MASTER'S DEFAULT.
:TURN CACHE ON.
```

2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363

```

2366
2367
2368 012070 005337 002670      .ENABL  LSB
                                DEC  LOCK      ;ALLOW ONE SLAVE TO RUN
2369                                :PASS PSEUDO SWR TO SLAVE
2370 012074 013737 002766 002674  MOV  SWR,MASWR      ;SAVE REAL SWR
2371 012102 012737 000176 002766  MOV  #SWREG,SWR     ;SETUP SOFTWARE SWR
2372 012110 017777 170560 170650  MOV  @MASWR,@SWR    ;FILL IT WITH REAL SWR STUFF
2373 012116                                IF NOIIST IS TRUE THEN JUMPTO MP4
                                TST NOIIST
                                BEQ L115
                                JMP MP4
                                L115:::
2374 012130 012702 000400      MOV  #BIT8,R2      ;BOOT = BITS 11,10,9,8
2375 012134 012703 000001      MOV  #1,R3        ;INTERRUPT = BITS 3,2,1,0
2376 012140                                BEGIN BOOTLOOP
                                B12:::
2377 012140                                FOR R1 := #1 TO #3
                                MOV #1,R1
                                B13:::
2378 012144 162737 000200 002706  SUB  #200,KSTACK  ;SLAVES - PLEASE USE YOUR OWN STACK
2379 012152 013737 002706 000000  MOV  KSTACK,0     ;PUT IN LOC 0 FOR BOOTSTRAP
2380 012160 012700 000020      MOV  #MASTER,R0  ;SET FIRST CPU ID BIT
2381 012164 072001      ASH  R1,R0        ;SHIFT IT TO CORRECT SPOT
2382 012166 010037 002114      MOV  R0,CPUBIT   ;CPUBIT = BIT5 OR BIT6 OR BIT7
2383 012172 010100      MOV  R1,R0        ;CPU # ----> R0
2384 012174 006300      ASL  R0           ;R0 := 2 OR 4 OR 6 ;INDEX VALUE
2385 012176 005037 002672      CLR  ACK         ;ALLOW ONLY ONE CPU AT A TIME
2386 012202 013704 002742      MOV  IISTVEC,R4  ;INTERRUPT VECTOR TO START
2387 012206 012724 004352      MOV  #START,(R4)+ ;HIGH PRIORITY
2388 012212 012714 000340      MOV  #340,(R4)
2389
2390                                ;WAIT FOR IIST READY
2391 012216 012737 061165 002574  MOV  #5*SECONDS,HUNGTIME
2392 012224 012777 000001 170504  MP2:  MOV  #1,@IISTACR
2393 012232 004737 072154      CALL QUE
2394 012236                                ON.ERROR
                                BCC L116
2395 012240 103004                                ERROR +61      ;IIST IS HANGING SYSTEM!
2396 012242 005037 002730      CLR SLAVES
2397 012246                                LEAVE  BOOTLOOP
                                BR E12
2398 012250                                END ;OF ON.ERROR
                                L116:::
2399 012250 032777 004000 170462  BIT  #BIT11,@IISTADR
2400 012256 001762      BEQ  MP2
2401
2402 012260 004737 061174      CALL  IISTOFF    ;INITIALIZE THE IIST & DISABLE BOOTS & INTERRUPTS
2403 012264 012777 000000 170444  MOV  #0,@IISTACR ;SELECT THE ACCESS CONTROL REGISTER
2404 012272 010277 170442      MOV  R2,@IISTADR ;BOOT SOME CPU
2405 012276 012777 000001 170434  MOV  #1,@IISTADR ;NOW!
2406                                ;THIS DELAY IS GOOD ONLY FOR THE M9312 MULTIPROCESSOR BOOT
2407                                ;THIS DELAY ALSO ASSUMES THAT CACHE IS OFF
2408 012304 012704 140000      MOV  #140000,R4  ;THIS DELAY TAKES APPROX 3/4 SECOND
2409 012310 000240      3$:  NOP
2410 012312 000240      NOP
2411 012314 000240      NOP
2412 012316 000240      NOP

```

2413 012320 005237 000110
2414
2415
2416 012324 077407

INC 110
SOB R4,38

;CHANGE MOVING LOCATION - SEE BOOT LISTING
;THIS STOPS THE BOOT FROM RUNNING THE MEMORY
;DIAGNOSTIC AND BLOWING UP MY SOFTWARE'

```

2418 012326 012777 000000 170402      MOV  #0,@IISTACR      ;SELECT THE ACCESS CONTROL REGISTER
2419 012334 010377 170400      MOV  R3,@IISTADR     ;INTERRUPT SOME CPU
2420 012340 012777 000001 170372      MOV  #1,@IISTADR     ;NOW!
2421                                ;WAIT FOR ACK OR TIMEOUT
2422 012346 012705 000003      MOV  #3,R5           ;THIS IS APPROX A 3 SECOND DELAY
2423 012352 005004      CLR  R4
2424 012354      1$:      IF ACK IS FALSE
                                TST ACK
                                BNE L117
2425 012362 005237 000110      INC  110             ;CHANGE MOVING LOCATION - SEE BOOT LISTING
                                ;THIS STOPS THE BOOT FROM RUNNING THE MEMORY
                                ;DIAGNOSTIC AND BLOWING UP MY SOFTWARE.
2426                                SOB  R4,1$
2427                                SOB  R5,1$
2428 012366 077406      END ;OF IF ACK IS FALSE
2429 012370 077507
2430 012372      IF ACK IS FALSE
                                ;IF THERE IS NO SLAVE AT THIS IISTID #
                                L117:;
                                TST ACK
                                BNE L120
2431 012372 005737 002672      ASL  R2
                                ASL  R3
                                IF R3 EQ #BIT4
2432 012400 006302      CMP  R3,#BIT4
2433 012402 006303      BNE  L121
2434 012404 020327 000020      LEAVE BOOTLOOP
                                BR  E12
2435 012412 000446      ELSE
                                BR  L122
2436 012414 000401      GOTO MP2
                                L121:;
                                BR  MP2
2437 012416 000702      END ;OF IF R3
                                L122:;
2438 012420      ELSE
                                BR  L123
2439 012420 000435      CLR  ACK             ;ALLOW SLAVE TO PROCEED
                                L120:;
2440 012422 005037 002672      MOV  #5,HUNGMSB
2441 012426 012737 000005 002572      MOV  #-1,HUNGTIME
2442 012434 012737 177777 002574      CALL  QUE
2443 012442 004737 072154      ON.ERROR
                                BCC  L124
2444 012446 103012
2445 012450 162737 000001 002572      SUB  #1,HUNGMSB
2446 012456 103006      ON.ERROR
                                BCC  L125
2447 012460 010137 002056      MOV  R1,BAD
2448 012464 104060      ERROR +60
                                ;SLAVE IS HANGING SYSTEM'
2449 012466 005037 002730      CLR  SLAVES
2450 012472 000416      LEAVE BOOTLOOP
                                BR  E12
2451 012474      END ;OF ON.ERROR
                                L125:;
2452 012474      END ;OF ON.ERROR
                                L124:;
2453 012474 005760 002616      TST  TASK(R0)
2454 012500 100360      BPL  2$
2455 012502 010137 002730      MOV  R1,SLAVES      ;COUNT OF SLAVES WAS IN R1
    
```

```

2456 012506          IF R3 EQ #BIT3 THEN LEAVE BOOTLOOP
      012506 020327 C00010          CMP R3,#BIT3
      012512 001406          BEQ E12
2457 012514          END ;OF IF ACK
      012514          L123:::
2458 012514 006302          ASL R2
2459 012516 006303          ASL R3
2460 012520          END ;OF FOR R1
      012520 005201          INC R1
      012522 020127 000003      CMP R1,#3
      012526 003606          BLE B13
      012530          E13:::
2461 012530          END BOOTLOOP
      012530          E12:::
2462 012530          IF SLAVES EQ #0
      012530 005737 002730          TST SLAVES
      012534 001005          BNE L126
2463 012536 005037 003014      CLR MULTIPOST
2464 012542 012777 036764 170172  MOV #IITRAP,@IISTVEC ;RESTORE UNEXPECTED IIST TRAP
2465 012550          END ;OF IF SLAVES
      012550          L126:::
2466 012550 000462          BR MP3
2467 012552          FOR R1 := #1 TO SLAVES
      012552 012701 000001      MOV #1,R1
      012556          B14:::
2468 012556 012700 000020      MOV #BIT4,R0
2469 012562 072001          ASH R1,R0
2470 012564 010037 002114      MOV R0,CPUBIT ;CPUBIT = BIT5 OR BIT6 OR BIT7
2471 012570 162737 000200 002706  SUB #200,KSTACK
2472 012576 010100          MOV R1,R0
2473 012600 006300          ASL R0 ;R0 = 2 OR 4 OR 6
2474 012602          TYPE MSG081 ;START SLAVE #
      012602 104401 115560      TYPEIT ,MSG081
      .DSABL CRF
2475 012606          TYP0CS R1,,1
      012606 010146      MOV R1,-(SP) ;SAVE R1 FOR TYPEOUT
      012610 104403      TYP0S ;GO TYPE--OCTAL ASCII
      012612 001 ;TYPE 1 DIGIT(S)
      012613 000 ;SUPPRESS LEADING ZEROS
      .DSABL CRF
      TYPE MSG082 ;AT ADDRESS 200
2476 012614 104401 115577      TYPEIT ,MSG082
      .DSABL CRF
2477 012620 012737 000031 002572      MOV #25.,HUNGMSB
2478 012626 012737 177777 002574      MOV #-1,HUNGTIME
2479 012634 005037 002672          CLR ACK ;ALLOW SLAVE TO PROCEED
2480 012640 004737 072154          CALL QUE
2481 012644          ON.ERROR
      012644 103015          BCC L127
2482 012646 162737 000001 002572      SUB #1,HUNGMSB
2483 012654          ON.ERROR
      012654 103011          BCC L130
2484 012656 010137 002056          MOV R1,BAD
2485 012662 104060          ERROR +60 ;SLAVE IS HANGING SYSTEM!
2486 012664          CLEAR SLAVES,MULTIPOST
      012664 005037 002730          CLR SLAVES
      012670 005037 003014          CLR MULTIPOST
    
```

```

2487 012674 000137 012716          JMP      MP3
2488 012700          END ;OF ON.ERROR
      012700
2489 012700          END ;OF ON.ERROR
      012700
2490 012700 005760 002616          IST     TASK(R0)
2491 012704 100353          BPL     S$
2492 012706          END ;OF FOR R1
      012706 005201
      012710 020137 002730
      012714 003720
      012716
      INC R1
      CMP R1,SLAVES
      BLE B14
      E14:
2493          ;POINT THE MASTER BACK TO THE NORMAL SWR
2494 012716 013737 002674 002766 MP3:  MOV     MASWR,SWR
2495 012724 012737 000020 002114  MOV     #MASTER,CPUBIT
2496 012732 052737 000020 002510  BIS     #MASTER,ALLCPUS
2497          ;WAIT A SECOND
2498 012740 005000          CLR     RO
2499 012742 077001          SOB     RO,4$
2500          ;STOP ANY CONFUSED MASTER (ME)
2501 012744 005237 002670          INC     LOCK
2502 012750          IF LOCK NE #1
      012750 023727 002670 000001          CMP     LOCK,#1
      012756 001402          BEQ     L131
2503 012760 000000          MHALT3: HALT
2504 012762 000776          BR     MHALT3
2505 012764          END ;OF IF LOCK
      012764
2506 012764 012737 000020 002114 MP5:  MOV     #MASTER,CPUBIT          ;BACK TO MASTER
2507 012772 012737 002000 002706  MOV     #STACK,KSTACK
2508 013000 104423          CACHON          ;TURN CACHE ON
2509          .DSABL  LSB
    
```

L130:

L127:

E14:

CMP LOCK,#1
 BEQ L131

L131:


```
2512 013002          SUBSTST <<CHECK FOR UNIQUE CPU ID NUMBERS>>
:*****
:*SUBTEST          CHECK FOR UNIQUE CPU ID NUMBERS
:*****
2513 013002 104424   CACHOFF          ;TURN CACHE OFF
2514 013004          BEGIN SAMESAME
013004
2515 013004 013702 002730  MOV    SLAVES,R2          B15:*****
2516 013010 006302     ASL    R2
2517 013012          FOR R0 := #0 TO R2 BY #2
013012 005000
013014          CLR R0
2518 013014          FOR R1 := #0 TO R2 BY #2          B16:*****
013014 005001
013016          CLR R1
2519 013016          IF R0 NE R1          B17:*****
013016 020001          CMP R0,R1
013020 001412          BEQ L132
2520 013022          IF PORTDIR(R0) EQ PORTDIR(R1)
013022 026061 002606 002606  (CMP PORTDIR(R0),PORTDIR(R1))
013030 001006          BNE L133
2521 013032 104041     ERROR    +41
2522 013034          TYPE    MSG084          ;PROCEEDING AS A SINGLE PORT TEST
013034 104401 115617   TYPEIT ,MSG084
.DSABL CRF
LEAVE SAMESAME
2523 013040          BR E15
013040 000412
2524 013042 005037 003014  CLR    MULTIPORT
2525 013046          END ;OF IF PORTDIR(R0)
013046
2526 013046          END ;OF IF R0          L133:*****
013046          END ;OF FOR R1          L132:*****
2527 013046 062701 000002     ADD #2,R1
013052 020102     CMP R1,R2
013054 003760     BLE B17
013056          E17:*****
2528 013056          END ;OF FOR R0
013056 062700 000002     ADD #2,R0
013062 020002     CMP R0,R2
013064 003753     BLE B16
013066          E16:*****
2529 013066          END SAMESAME          E15:*****
2530 013066 104423   CACHON          ;TURN CACHE ON
2531
2532 013070          SUBSTST <<PRINT MULTIPOINT DIRECTORY>>
:*****
:*SUBTEST          PRINT MULTIPOINT DIRECTORY
:*****
2533 013070          IF MULTIPOINT IS TRUE
013070 005737 003014     TST MULTIPOINT
013074 001431     BEQ L134
2534 013076          TYPE    MSG086
013076 104401 115706   TYPEIT ,MSG086
.DSABL CRF
TYPOCS          PORTDIR
2535 013102
```

```

013102 013745 002606      MOV    PORTDIR,-(SP)    ;;SAVE PORTDIR FOR TYPEOUT
013106 104403              TYPOS                    ;;GO TYPE--OCTAL ASCII
013110 006                  .BYTE 6                  ;;TYPE 6 DIGITS
013111 000                  .BYTE 0                  ;;SUPPRESS LEADING ZEROS
                                .DSABL CRF
2536 013112 112737 000060 115753      MOVB  #'0,MSGAB7
2537 013120 012700 000001              FOR RO := #1 TO SLAVES
                                MOV #1,R0
                                B20:*****
2538 013124 010001              MOV RO,R1
2539 013126 006301              ASL R1
2540 013130 105237 115753          INCB  MSGAB7
2541 013134 104401 115745          TYPE  MSGAB7
                                MSG087
                                TYPEIT ,MSG087
                                .DSABL CRF
2542 013140 016146 002606          TYPOCS PORTDIR(R1)
013140 104403              MOV    PORTDIR(R1),-(SP)  ;;SAVE PORTDIR(R1) FOR TYPEOUT
013144 006                  TYPOS                    ;;GO TYPE--OCTAL ASCII
013146 000                  .BYTE 6                  ;;TYPE 6 DIGITS
013147 000                  .BYTE 0                  ;;SUPPRESS LEADING ZEROS
                                .DSABL CRF
2543 013150 005200              END ;OF FOR RO
013150 020037 002730              INC RO
013152 003762              CMP RO,SLAVES
013160 000                  BLE B20
2544 013160              END ;OF IF MULTIPOINT
                                E20:*****
                                L134:*****
2545 013160
2546 013160
                                SUBAAR: SUBST <<LOAD CSR'S FROM E-TABLE $CDW1 & $CDW2>>
                                ;*****
                                ;*SUBTEST LOAD CSR'S FROM E-TABLE $CDW1 & $CDW2
                                ;*****
2547 013160 005737 075214              IF $CDW1 NE #0 OR $CDW2 NE #0
013160 001003              TST $CDW1
013164 005737 075216              BNE L135
013172 001430              TST $CDW2
013174 000                  BEQ L136
                                L135:*****
2548 013174 013701 002334          MOV  MKCSRS,R1
2549 013200 013737 075214 002144      MOV  $CDW1,CSR
2550 013206 013737 075216 002144      MOV  $CDW2,CSR+2
2551 013214 005037 002256          FOR CSRNO := #0 TO #34 BY #2
                                CLR CSRNO
                                B21:*****
2552 013220 106301              ASLB  R1
2553 013222 103001              ON.ERROR
                                BCC L137
2554 013224 104425              LOADCSR
2555 013226 000002 002256          END ;OF ON.ERROR
                                L137:*****
2556 013226 062737 000002 002256          END ;OF FOR CSRNO
013226 023727 002256 000034          ADD #2,CSRNO
013242 003766              CMP CSRNO,#34
013244 000                  RLE B21
2557 013244 005237 075142          INC  $PASS
                                E21:*****
    
```

2558 013250 000137 015050
2559 013254
013254

JMP APTHANG
END :OF IF \$CDW1

;GO LOOP FOREVER KEEPING APT ALIVE

L136:::~::~

```

2562 013254          SUBTST <<LEGAL CONFIGURATION CHECK>>
:*****
:SUBTEST          LEGAL CONFIGURATION CHECK
:*****
IF CPUBIT EQ #MASTER
                                CMP CPUBIT,#MASTER
                                BNE L140
2563 013254 023727 002114 000020
013254 001156
2564 013264          FOR BANK : #0 TO #167
013264 005037 002106
013270
                                CLR BANK
2565 013270 004737 042422
2566 013274 013700 002110
                                B22:*****
2567
2568
2569 013300          ;MAKE SURE THAT EVERYBODY CAN ACCESS EVERY BANK
013300 005737 002126
013304 001472
                                TST MKFLAG
                                BEQ L141
2570
2571 013306          ;IF ANYBODY CAN ACCESS
013306 032760 000360 003016
013314 001466
                                IF #MASTER!SLAVE1!SLAVE2!SLAVE3 SET.IN CONFIG(R0)
2572 013316 013737 002510 002114
2573 013324 004737 042422
2574 013330 012737 000020 002114
                                MOV ALLCPUS,CPUBIT
                                CALL EXBANK
                                MOV #MASTER,CPUBIT
2575
2576 013336          ;IF EVERYBODY CAN'T ACCESS
013336 005737 002124
013342 001053
                                IF ACFLAG IS FALSE AND CONFGERROR IS FALSE
013344 005737 002576
013350 001050
                                TST ACFLAG
                                BNE L143
                                TST CONFGERROR
                                BNE L143
2577 013352          SET CONFGERROR
013352 012737 177777 002576
                                MOV #-1,CONFGERROR
2578 013360          CLEAR SLFLAG,SLFLAG+2,SLFLAG+4,SLFLAG+6
013360 005037 002656
013364 005037 002660
                                CLR SLFLAG
013370 005037 002662
                                CLR SLFLAG+2
013374 005037 002664
                                CLR SLFLAG+4
                                CLR SLFLAG+6
2579 013400          IF #MASTER SET.IN CONFIG(R0) THEN LET SLFLAG := ONES
013400 032760 000020 003016
013406 001403
                                BIT #MASTER,CONFIG(R0)
013410 013737 002726 002656
                                BEQ L144
                                MOV ONES,SLFLAG
2580 013416          IF #SLAVE1 SET.IN CONFIG(R0) THEN LET SLFLAG+2 := ONES
013416 032760 000040 003016
013424 001403
                                L144:*****
                                BIT #SLAVE1,CONFIG(R0)
013426 013737 002726 002660
                                BEQ L145
                                MOV ONES,SLFLAG+2
2581 013434          IF #SLAVE2 SET.IN CONFIG(R0) THEN LET SLFLAG+4 := ONES
013434 032760 000100 003016
013442 001403
                                L145:*****
                                BIT #SLAVE2,CONFIG(R0)
013444 013737 002726 002662
                                BEQ L146
                                MOV ONES,SLFLAG+4
2582 013452          IF #SLAVE3 SET.IN CONFIG(R0) THEN LET SLFLAG+6 := ONES
013452 032760 000200 003016
013460 001403
                                L146:*****
                                BIT #SLAVE3,CONFIG(R0)
013462 013737 002726 002664
                                BEQ L147
                                MOV ONES,SLFLAG+6
2583 013470
                                L147:*****
  
```

```

2583 013470 104063          ERROR +63
2584 013472          END ;OF IF ACFLAG
2585 013472          END ;OF IF #MASTER.SLAVE1.SLAVE2:SLAVE3
2586 013472          END ;OF IF MKFLAG IS TRUE
2587 013472
2588 013472
2589 013472 004737 042422  ;MAKE SURE (IF I CAN) THAT EACH BOX HAS ONE & ONLY ONE CSR
2590 013476 005737 002124  CALL EXBANK
013502 001440          ;IF ACFLAG IS TRUE AND MKFLAG IS TRUE
013504 005737 002126          TST ACFLAG
013510 001435          BEQ L150
2591 013512 016001 003016          MOV CONFIG(R0),R1
2592 013516 042701 177770          BIC #^C7,R1 ;R1 0 OR 1 OR 2 OR 4
2593 013522 010000 003020          IF #BIT12 OFF.IN CONFIG+2(R0) ;IF NO INTERNAL INTERLEAVE
013530 001001          BIT #BIT12,CONFIG+2(R0)
013532 006301          BNE L151
2594 013532
2595 013534          ASL R1 ;R1 - 0 OR 2 OR 4
013534          END ;OF IF #BIT3
2596 013534          IF R1 EQ #0 THEN LEI R1 := R1 + #1
013534 005701          TST R1
013536 001001          BNE L152
013540 005201          INC R1
013542
2597          ;NOW
2598          ;INTERLEAVE
2599          ;-----
2600          ;4 TO 1 EXT & INTERNAL          4          8
2601          ;4 TO 1 EXT & NO INT          4          4
2602          ;2 TO 1 EXT & INTERNAL          2          4
2603          ;2 TO 1 EXT & NO INT          2          2
2604          ; NO EXT & INTERNAL          1          2
2605          ; NO EXT & NO INT          1          0
2606
2607          ;SO
2608          ;R1 = 1 OR 2 OR 4 = '# OF CSR'S ON THIS BANK'
2609 013542 005004          CLR R4
2610 013544 116002 003022          MOV# CONFIG+4(R0),R2
2611 013550 012703 000010          MOV #8.,R3
2612 013554 006002          ROR R2 ;COUNT CSR'S IN THIS BANK
2613 013556 005504          ADC R4
2614 013560 077303          SOB R3,1$
2615
2616          ;IF # OF CSR'S IS WRONG!
2617 013562          IF R4 NE R1 AND CONFGERROR IS FALSE
013562 020401          CMP R4,R1
013564 001407          BEQ L153
013566 005737 002576          TST CONFGERROR
013572 001004          BNE L153
2618 013574          SET CONFGERROR
013574 012737 177777 002576          MOV #-1,CONFGERROR
2619 013602 104064
2620 013604          ERROR +64
          END ;OF IF R4
    
```

L143:.....
 L142:.....
 L141:.....

TST ACFLAG
 BEQ L150
 TST MKFLAG
 BEQ L150

;R1 0 OR 1 OR 2 OR 4
 ;IF NO INTERNAL INTERLEAVE
 BIT #BIT12,CONFIG+2(R0)
 BNE L151
 ;R1 - 0 OR 2 OR 4
 L151:.....

TST R1
 BNE L152
 INC R1
 L152:.....

INTERLEAVE	R1	INTERLEAVE FACTOR
4 TO 1 EXT & INTERNAL	4	8
4 TO 1 EXT & NO INT	4	4
2 TO 1 EXT & INTERNAL	2	4
2 TO 1 EXT & NO INT	2	2
NO EXT & INTERNAL	1	2
NO EXT & NO INT	1	0

```

;SO
;R1 = 1 OR 2 OR 4 = '# OF CSR'S ON THIS BANK'
CLR R4
MOV# CONFIG+4(R0),R2
MOV #8.,R3
ROR R2 ;COUNT CSR'S IN THIS BANK
ADC R4
SOB R3,1$
    
```

```

;IF # OF CSR'S IS WRONG!
IF R4 NE R1 AND CONFGERROR IS FALSE
CMP R4,R1
BEQ L153
TST CONFGERROR
BNE L153
SET CONFGERROR
MOV #-1,CONFGERROR
    
```

```

ERROR +64
END ;OF IF R4
    
```

2621 013604 END ;OF IF ACFLAG
 013604
2622 013604 END ;OF FOR BANK
 013604 005237 002106
 013610 023727 002106 000167
 013616 003624
 013620
2623 013620 END ;OF IF CPUBIT
 013620

L153:.....
L150:.....
 INC BANK
 CMP BANK,#167
 BLE B22
E22:.....
L140:.....

```

2626 013620
2627 013620 005037 002466
2628 013624 005037 002470
2629 013630 005001
2630 013632 033761 002114 003016
2631 013642 032761 060000 003016
2632 013656 032761 040000 003016
2633 013676 005237 002470
2634 013702
2635 013702
2636 013702 062701 000006
2637 013714 006337 002466
2638 013720 006337 002466
2639 013724 006337 002466
2640 013730 006337 002466
2641 013734 006337 002470
2642 013740 006337 002470
2643 013744 006337 002470
2644 013750 006337 002470
2645 013754 005237 002516
2646 013760 006337 002516
2647 013764 006337 002516
2648 013770 006337 002516
2649 013774 006337 002516
2650 014000 013737 002466 002602
2651 014014 023737 002602 002516
2652 014032 104401 003010

```

```

SUBSTST <<PRINT CONFIGURATION DETAILS>>
*****
*SUBTEST PRINT CONFIGURATION DETAILS
*****
CLR MJSIZE
CLR MKSIZE
FOR R1 := #0 TO #167*3*2 BY #6
    CLR R1
    B23:*****
    IF CPUBIT SET.IN CONFIG(R1)
        BIT CPUBIT,CONFIG(R1)
        BEQ L154
        IF #BIT14.BIT13 OFF.IN CONFIG(R1) THEN LET MJSIZE := MJSIZE + #1
        BIT #BIT14:BIT13,CONFIG(R1)
        BNE L155
        INC MJSIZE
        L155:*****
        IF #BIT14 OFF.IN CONFIG(R1) AND #BIT13 SET.IN CONFIG(R1)
            BIT #BIT14,CONFIG(R1)
            BNE L156
            BIT #BIT13,CONFIG(R1)
            BEQ L156
            LET MKSIZE := MKSIZE + #1
            INC MKSIZE
        END ;OF IF MK11 MEMORY
        L156:*****
    END ;OF IF ACCESSABLE BY CPU
    L154:*****
END ;OF FOR ALL BANKS IN TABLE
    ADD #6,R1
    CMP R1,#167*3*2
    BLE B23
    E23:*****
ASL MJSIZE
ASL MJSIZE
ASL MJSIZE
ASL MJSIZE ;MJSIZE := MJSIZE * 16.
ASL MKSIZE
ASL MKSIZE
ASL MKSIZE ;MKSIZE := MKSIZE * 16.
INC UNITOP
ASL UNITOP
ASL UNITOP
ASL UNITOP
ASL UNITOP ;UNITOP := UNITOP * 16.
LET I := MJSIZE + MKSIZE
MOV MJSIZE,I
ADD MKSIZE,I
IF I LT UNITOP THEN LET I := UNITOP
CMP I,UNITOP
BGE L157
MOV UNITOP,I
L157:*****
TYPE $CRLF
TYPEIT $CRLF
.DSABL CRF

```

2653	014036				TYPDEC	I		
	014036	013746	002602		MOV	I,-(SP)	::SAVE I FOR TYPEOUT	
	014042	104405			TYPDS		::GO TYPE--DECIMAL ASCII WITH SIGN	
					.DSABL	CRF		
2654	014044				TYPE	MSG070		
	014044	104401	115246		TYPEIT	,MSG070		
					.DSABL	CRF		
2655	014050				TYPDEC	MJSIZE		
	014050	013746	002466		MOV	MJSIZE,-(SP)	::SAVE MJSIZE FOR TYPEOUT	
	014054	104405			TYPDS		::GO TYPE--DECIMAL ASCII WITH SIGN	
					.DSABL	CRF		
2656	014056				TYPE	MSG071		
	014056	104401	115271		TYPEIT	,MSG071		
					.DSABL	CRF		
2657	014062				TYPDEC	MKSIZE		
	014062	013746	002470		MOV	MKSIZE,-(SP)	::SAVE MKSIZE FOR TYPEOUT	
	014066	104405			TYPDS		::GO TYPE--DECIMAL ASCII WITH SIGN	
					.DSABL	CRF		
2658	014070				TYPE	MSG072		
	C14070	104401	115304		TYPEIT	,MSG072		
					.DSABL	CRF		
2659	014074				IF #SW6	SET.IN @SWR OR CONFGERRR IS TRUE		
	014074	032777	000100	166664				
	014102	001003						
	014104	005737	002576					
	014110	001402						
	014112							
2660	014112	004737	035402		CALL	PCONFIG		
2661	014116				END	:OF IF #SW6		
	014116							

```

BIT #SW6,@SWR
BNE L160
TST CONFGERRR
BEQ L161
L160:
L161:
    
```


2664 014116

SUBTST <<CHECK APT SIZING>>

: *SUBTEST CHECK APT SIZING
: *****

IF APTFLAG IS TRUE AND APTSIZE IS TRUE

2665 014116 005737 002444
014122 001505
014124 005737 002544
014130 001502
2666 014132 005037 002534
2667 014136 012700 075164
2668 014142 005002

CLR TEMP
MOV #SMAMS1,R0
FOR R2 := #0 TO #4

TST APTFLAG
BEQ L162
TST APTSIZE
BEQ L162

2669 014144 105760 000001
014150 001441
2670 014152 111061
2671 014154 042701 177400
2672 014160 005760 000002
014164 002002
2673 014166 000261
2674 014170 000401

IFB 1(R0) NE #0

MOVB (R0),R1
BIC #177400,R1
IF 2(R0) LT #0

CLR R2
B24:*****
TSTB 1(R0)
BEQ L163

2675 014172 000241
2676 014174 000241

SEC
ELSE

CLC
END ;OF IF 2(R0)

TST 2(R0)
BGE L164
BR L165
L164:*****

2677 014174 006101
2678 014176 005201
2679 014200 006301
2680 014202 006301
2681 014204 006301
2682 014206 006301
2683 014210 163701 002534
2684 014214 010137 002534
2685 014220 126027 000001 000001

ROL R1
INC R1
ASL R1
ASL R1
ASL R1
ASL R1
SUB TEMP,R1
MOV R1,TEMP
IFB 1(R0) EQ #1

;TO COMPENSATE FOR 4 BANKS BEING (0-3)

L165:*****
CMPB 1(R0),#1
BNE L166

2686 014230 060137 002522
2687 014234 126027 000001 000004

ADD R1,APT(CORE)
END ;OF IFB 1(R0)

IFB 1(R0) EQ #4

L166:*****
CMPB 1(R0),#4
BNE L167

2688 014234 001002
2689 014244 060137 002524
2690 014250 062700 000004

ADD R1,APT(MOS)
END ;OF IFB 1(R0)

ADD #4,R0
END ;OF IFB 1(R0)

L167:*****

2691 014250 000004
2692 014254 005202
2693 014254 020227 000004
014262 003730
014264

END ;OF FOR R2

L163:*****
INC R2
CMP R2,#4
BLE B24
E24:*****

```
2694 014264          IF APTCORE NE MJSIZE OR APTMOS NE MKSIZE
      014264          023737 002522 002466
      014272          001004
      014274          023737 002524 002470
      014302          001401
      014304
2695 014304          104051          ERROR          +51
2696 014306          014306          END ;OF IF APTCORE
      014306
2697
2698
2699 014306          013700 002730          ;CHECK FOR CORRECT NUMBER OF CPU'S
2700 014312          005200          MOV SLAVES,RO
2701 014314          014314          023700 075234          INC RO          ;RO = 1, 2, 3, OR 4
      014320          001406          IF $DDW6 NE RO
      014322          010037 002050          MOV RO,GOOD
2703 014326          013737 075234 002056          MOV $DDW6,BAD
2704 014334          104065          ERROR +65
2705 014336          014336          END ;OF $DDW6
      014336
2706 014336          014336          END ;OF IF APTFLAG
      014336
2707
2708 014336          004737 015104          CALL DOBACK          ;WRITE BACKGROUND PATTERN

      CMP APTCORE,MJSIZE
      BNE L170
      CMP APTMOS,MKSIZE
      BEQ L171
L170:
      L171:
      CMP $DDW6,RO
      BEQ L172
L172:
      L162:
```

2710 014342

014342 000004
2711 014344 005037 002332
2712 014350 017700 166412
2713 014354 042700 177761
2714 014360 004770 014370
2715 014364 000137 014410
2716 014370 015204
2717 014372 015320
2718 014374 015434
2719 014376 015572
2720 014400 015730
2721 014402 016056
2722 014404 016246
2723 014406 016404
2724
2725

```
LOOP: NEWTST <<DIAGNOSTIC MODE DISPATCH ROUTINE>>
;*****
;*TEST 5      DIAGNOSTIC MODE DISPATCH ROUTINE
;*****
TST5:  SCOPE
      CLR      CONTFLAG
      MOV      @SWR,R0      ;GET SWITCHES
      BIC      #^C16,R0     ;MASK TO ONLY MODE BITS
      CALL     @DISPTBL(R0) ;DISPATCH TO ROUTINE THROUGH NEXT TABLE
      JMP      MEMDONE      ;GO TO NEXT TEST
DISPTBL:BAFPAF ;MODE 0:BANKS FORWARD, PATTERNS FORWARD
        BAFPAR ;MODE 1:BANKS FORWARD, PATTERNS REVERSE
        BAWPAF ;MODE 2:BANKS WORST FIRST, PATTERNS FORWARD
        BAWPAR ;MODE 3:BANKS WORST FIRST, PATTERNS REVERSE
        PAFBAF ;MODE 4:PATTERNS FORWARD, BANKS FORWARD
        PAFBAW ;MODE 5:PATTERNS FORWARD, BANKS WORST FIRST
        PARBAF ;MODE 6:PATTERNS REVERSE, BANKS FORWARD
        PARBAW ;MODE 7:PATTERNS REVERSE, BANKS WORST FIRST
;**NOTE** MARGINS FOLLOW PATTERNS (FORWARD IS (0,2,3,4,5))
;(REVERSE IS (5,4,3,2,0))
```

```

2729 014410 004737 015104 MEMDONE:CALL DOBACK ;CHECK BACKGROUND PATTERN
2730 014414 NEWTST<<UNIQUE BANK TEST>>
;*****
;*TEST 6 UNIQUE BANK TEST
;*****
TST6: SCOPE
;MAKE SURE THAT EACH BANK CAN HAVE UNIQUE DATA
;WRITE AND READ THE BANK NUMBER IN EACH BANK (EXCEPT WHERE THE PROGRAM IS)
IF SELONLY IS FALSE
TST SELONLY
BNF L173
2731 014414 000004
2732 014416 005737 002002
2733 014422 001015
2734 014424 012737 177777 002724 SET HEADER,MUT
2735 014432 012737 177777 002116 MOV #-1,HEADER
2736 014440 004737 024370 MOV #-1,MUT
2737 014444 012737 177777 002724 MOV #-1,HEADER
2738 014452 005037 002116 CLR MUT
2739 014456 END ;OF IF SELONLY
L173:;;;;;

NEWTST <<FORCE ADDRESS PARITY ERRORS>>
;*****
;*TEST 7 FORCE ADDRESS PARITY ERRORS
;*****
TST7: SCOPE
;THIS MAKES SURE THAT ALL ACCESSABLE MEMORY LOCATIONS WILL GIVE A
;PARITY TRAP IF I FORCE A MEMORY BUSS ADDRESS PARITY ERROR BY
;USING THE MAINTENANCE REGISTER.
;
;WHEN DONE EVERY ADDRESS PARITY ERROR LED IN EVERY MEMORY BOX
;(MK11'S, MKA11'S, AND MJ11'S) SHOULD BE LITE.
;YOU CAN ONLY TURN THEM OFF BY TURNING OFF POWER TO THE BOX'S.
IF SELONLY IS FALSE
TST SELONLY
BNF L174
2741 014456 000004
2742 014460 005737 002002
2743 014464 001040
2744 014466 012700 060000 MOV #FIRST,R0
2745 014472 012737 000004 002100 MOV #4,NOPAR ;INDICATE PARITY ACTION
2746 014500 BMOV ADDPAR
2747 014504 004537 043710 JSR R5,BLOCK1
2748 014504 014570 ADDPAR
;DSABL CRF
FOR BANK := #0 TO #167
2749 014506 005037 002106 CLR BANK
2750 014512 004737 042422 B25:;;;;;
2751 014516 005737 002124 TST ACFLAG
2752 014522 001411 BEQ L175
2753 014524 005037 002074 CLR PARCNT
2754 014530 004737 026042 CALL SUPD01
2755 014534 023727 002074 000001 IF PARCNT NE #1
2756 014542 001401 CMP PARCNT,#1
2757 014544 104035 BEQ L176
2758 014546 ERROR +35
2759 014546 END ;OF IF PARCNT
L176:;;;;;

```

```
2760 014546          END ;OF IF ACFLAG
      014546
2761 014546          END ;OF FOR BANK
      014546 005237 002106
      014552 023727 002106 000167
      014560 003754
      014562
2762 014562 005037 002100
2763 014566          CLR  NOPAR          ;INDICATE PARITY ACTION
      014566          END ;OF IF SELONLY
2764 014566 000405   BR    SUBAAU
2765
2766          ;THESE 3 INSTRUCTIONS ARE MOVED TO THE USER PAR'S IN ORDER TO
2767          ;CAUSE ABORTS FROM THE BANK UNDER TEST VICE THE PROGRAM SPACE
2768 014570 012737 000002 177750 ADDPAR: MOV  #BIT1,MAIN  ;V177640 ;CREATE ADDRESS PARITY ERROR
2769 014576 005710          TST  (R0)          ;V177646 ;THIS WILL ABORT & INCREMENT PARCNT
2770 014600 000207          RETURN          ;V177650
```

```
2773 014602          SUBAAU: IF SBFLAG IS TRUE
      014602 005737 002022
      014606 001405
      2774 014610          IF LASTERROR EQ $ERTTL
      014610 023737 002020 002754
      014616 001001
      2775 014620 104050
      2776 014622          ERROR          +50
      014622          END ;OF IF LASTERROR
      2777 014622          END ;OF IF SBFLAG
      014622
      2778
      2779 014622          SET      WRITEONLY
      014622 012737 177777 002502
      2780 014630 005137 002744          MOV # -1,WRITEONLY
      2781 014634 004737 015104          COM      SOFTPAT
      2782 014640 005037 002502          CALL   DOBACK          ;RESTORE BACKGROUND PATTERN
      2783 014644          CLR      WRITEONLY
      014644 005737 003014          IF MULTIPOST IS TRUE THEN JUMPTO MAST01
      014650 001402
      014652 000137 057372          TST  MULTIPOST
      014656          BEO  L201
      2784 014656          JMP  MAST01
      FLUSH: SUBTST <<FLUSH OUT DBE'S>>
      ;*****
      ;*SUBTEST      FLUSH OUT DBE'S
      ;*****
      2785 014656 004737 024754          CALL   MTO030
      L200:*****
      L177:*****
      L201:*****
```

```

2789          .SBTTL  END OF PASS ROUTINE
2790          *****
2791          : *INCREMENT THE PASS NUMBER ($PASS)
2792          : *INDICATE END-OF-PROGRAM AFTER EACH PASSES THRU THE PROGRAM
2793          : *TYPE 'END PASS #XXXXX' (WHERE XXXXX IS A DECIMAL NUMBER)
2794          : *IF THERES A MONITOR GO TO IT
2795          : *IF THERE ISN'T JUMP TO LOOP
2796 014662 005037 002022      $EOP:  CLR      SBFLAG
2797 014666 005037 002542      CLR      FSINFLAG
2798 014672 013737 002754 002020  MOV      $ERTTL,LASTEROR
2799 014700 005237 075142      INC      $PASS          ;; INCREMENT THE PASS NUMBER
2800 014704 042737 100000 075142  BIC      #100000,$PASS  ;; DON'T ALLOW A NEG. NUMBER
2801 014712          TYPE      MSG077          ;; TYPE 'END PASS #'
      014712 104401 115414      TYPEIT  ,MSG077
      .DSABL CRF
      IF #SW11 SET.IN @SWR OR QVFLAG IS TRUE
2802 014716          BIT #SW11,@SWR
      014716 032777 004000 166042  BNE L202
      014724 001003          BNE L202
      014726 005737 002440          TST QVFLAG
      014732 001404          BEQ L203
      014734          L202:*****
2803 014734          TYPE      MSG035          ;QV
      014734 104401 113707      TYPEIT  ,MSG035
      .DSABL CRF
2804 014740 005037 002440      CLR      QVFLAG
2805 014744          END ;OF IF SW11          L203:*****
2806 014744          TYPDEC  $PASS
      014744 013746 075142      MOV      $PASS,-(SP)  ;; SAVE $PASS FOR TYPEOUT
      014750 104405          TYPDS          ;; GO TYPE--DECIMAL ASCII WITH SIGN
      .DSABL CRF
2807 014752 013700 000042      MOV      42,R0          ;; GET MONITOR ADDRESS
2808 014756 001430          BEQ          ;; BRANCH IF NO MONITOR
2809 014760 022700 002000      $ZAP42: CMP      #STACK,R0          ;ARE WE UNDER RT11
2810 014764 001425          BEQ      $DOAGAIN          ;YES - BRANCH
2811          ;WE ARE UNDER (HEAVEN HELP US) XXDP'
2812 014766          PUSH     R0
      014766 010046          MOV R0,-(SP)
2813 014770 004737 043554      CALL     SHUTUP
2814 014774          POP      R0
      014774 012600          MOV (SP)+,R0
2815 014776 000005          RESET          ;; CLEAR THE WORLD
2816 015000 004710      $ENDAD: CALL     (R0)          ;; GO TO MONITOR
2817 015002 000240          NOP          ;; SAVE ROOM
2818 015004 000240          NOP          ;; FOR
2819 015006 000240          NOP          ;; ACT11
2820 015010      $DOAGN: ;UNDO SHUTUP STUFF
2821          ;
2822          ; RESTORE STACK
2823          ; ENERGIZE UNIBUS MAP & 22 BIT ADDRESSING
2824          ; ENERGIZE MEMORY MANAGEMENT
2825          ; PUT LOADERS BACK HOME
2825 015010 013706 002706      MOV      KSTACK,SP
2826 015014 052737 000060 172516  BIS      #BIT5:BIT4,MMR3
2827 015022 104420          ENERGIZ #1,R1          ;TURN ON MEMORY MANAGEMENT
2828 015024 013700 002710      MOV      LOADHOME,R0          ;DESTINATION BANK
2829 015030 012701 000001      MOV      #1,R1          ;SOURCE BANK
2830 015034 004737 042072      CALL     BANKMOV

```

```

2831 015040          $DOAGAIN:IF $USWR EQ $PASS          ;IF APT LIMITING # OF PASSES
      015040 023737 075160 075142
      015046 001014
2832 015050 012701 000050
2833 015054 077001
2834 015056 062737 000001 075144
2835 015064 005537 075146
2836 015070 077107
2837 015072 005237 075142
2838 015076 000764
2839 015100
      015100
2840 015100 000137 014342

```

```

APTHANG: MOV #50,R1
2$:      SOB R0,2$
        ADD #1,$DEVCT
        ADC $UNIT
        SOB R1,2$
        INC $PASS
        BR APTHANG
END :OF IF $USWR

```

```

CMP $USWR,$PASS
BNE L204

```

```

L204:*****

```

```

JMP LOOP          ;RETURN

```



```

2843 015104          DOBACK: SUBTST <<WRITE BACKGROUND PATTERNS>>
:*****
:*SUBTEST          WRITE BACKGROUND PATTERNS
:*****
2844 015104 005037 002120          CLR          PATTERN
2845 015110          FOR BANK := #0 TO #167
                                CLR BANK
                                B26:*****
2846 015114 005037 002106          CALL EXBANK
2847 015120          IF ACFLAG IS TRUE AND PFLAG IS FALSE
                                TST ACFLAG
                                BEQ L205
                                TST PFLAG
                                BNE L205
2848 015134          SET          HEADER,MUT
                                MOV #-1,HEADER
                                MOV #-1,MUT
2849 015150 004737 021222          CALL          MKTEST          ;CALL MJTEST WOULD ALSO WORK
2850 015154 005037 002116          CLR          MUT
2851 015160          SET          HEADERR
                                MOV #-1,HEADERR
2852 015166          END ;OF IF ACFLAG
                                L205:*****
2853 015166          END ;OF FOR BANK
                                INC BANK
                                CMP BANK,#167
                                BLE B26
2854 015202 000207          RETURN
                                E26:*****
  
```

MTEST MODES

```

2857
2858
2859 015204

2860 015204 005037 002106
2861
2862 015210 004737 042422
2863 015214 005737 002124
2864 015220 001417
2865 015222 005737 002132
2866 015226 001014
2867 015230 005037 002120
2868
2869 015234 005037 002112
2870
2871 015240 004737 016564
2872
2873 015244 004737 043006
2874 015250 001373
2875
2876 015252 004737 042746
2877 015256 001366
2878
2879 015260 004737 042772
2880 015264 001351
2881
2882 015266 005737 002134
2883 015272 001401
2884 015274 000207
2885 015276 004737 041130
2886 015302
      015302 103001
      015304 000207
      015306

2887
2888 015306 004737 015204
2889 015312 004737 041604
2890 015316 000207
    
```

.SBTTL MTEST MODES

```

BAFPAF: SUBST <<BANKS FORWARD,PATTERNS FORWARD      **RECURSIVE**>>
:*****
:*SUBTEST      BANKS FORWARD,PATTERNS FORWARD      **RECURSIVE**
:*****
      CLR      BANK          ;SET BANK TO 0
      ;START OF BANK LOOP
1$:  CALL      EXBANK        ;EXAMINE BANK
      TST      ACFLAG        ;CAN WE ACCESS THIS BANK?
      BEQ      4$            ;NO - GO TO BANK LOOP TERMINATION
      TST      RRFLAG        ;RELOCATION REQUIRED?
      BNE      4$            ;YES - GO TO BANK LOOP TERMINATION
      CLR      PATTERN       ;SET PATTERN TO 0
      ;START OF PATTERN LOOP
2$:  CLR      MARGIN        ;SET MARGIN TO 0
      ;START OF MARGIN LOOP
3$:  CALL      MTEST         ;GO TEST CORRECT MEMORY
      ;TERMINATION OF MARGIN LOOP
      CALL      INCMAR       ;NEXT HIGHER MARGIN
      BNE      3$            ;IF NOT DONE - LOOP ON THIS MARGIN
      ;TERMINATION OF PATTERN LOOP
      CALL      INCPAT       ;GO SEE IF THIS IS THE LAST PATTERN
      BNE      2$            ;NO - LOOP ON THIS PATTERN
      ;TERMINATION OF BANK LOOP
4$:  CALL      INCBNK        ;NEXT HIGHER BANK
      BNE      1$            ;IF NOT DONE - LOOP ON THIS BANK
      ;END OF LOOPS
      TST      RLFLAG        ;HAVE WE BEEN RELOCATED?
      BEQ      5$            ;NO - SKIP
      RETURN                ;YES - RETURN
5$:  CALL      RELOCATE       ;MOVE & MAP PROGRAM
      ON.ERROR THEN $RETURN

      ;**NOTE** RECURSIVE CALL
      CALL      BAFPAF        ;CALL SELF
      CALL      UNRELOCATE    ;UNMOVE & UNMAP PROGRAM
      RETURN
    
```

BCC L206
RTS PC
L206:::~:~:

```

2893 015320      BAFPAR: SUBTST <<BANKS FORWARD,PATTERNS REVERSE      **RECURSIVE**>>
:*****
:*SUBTEST      BANKS FORWARD,PATTERNS REVERSE      **RECURSIVE**
:*****
2894 015320 005037 002106      CLR      BANK      ;SET BANK TO 0
2895      ;START OF BANK LOOP
2896 015324 004737 042422      1$: CALL      EXBANK      ;EXAMINE BANK
2897 015330 005737 002124      TST      ACFLAG      ;CAN WE ACCESS THIS BANK?
2898 015334 001417      BEQ      4$      ;NO - GO TO BANK LOOP TERMINATION
2899 015336 005737 002132      TST      RRFLAG      ;RELOCATION REQUIRED?
2900 015342 001014      BNE      4$      ;YES - GO TO BANK LOOP TERMINATION
2901 015344 004737 042762      CALL     SETPAT      ;SET HIGH PATTERN FOR CORRECT MEMORY
2902      ;START OF PATTERN LOOP
2903 015350 004737 043212      2$: CALL     SETMAR      ;SET HIGH MARGINS (IF NOT INHIBITED)
2904      ;START OF MARGIN LOOP
2905 015354 004737 016564      3$: CALL     MTEST      ;GO TEST CORRECT MEMORY
2906      ;TERMINATION OF MARGIN LOOP
2907 015360 004737 043152      CALL     DECMAR      ;NEXT LOWER MARGIN
2908 015364 100373      BPL      3$      ;IF NOT DONE - LOOP ON THIS MARGIN
2909      ;TERMINATION OF PATTERN LOOP
2910 015366 005337 002120      DEC     PATTERN      ;IS THIS THE LAST PATTERN?
2911 015372 100366      BPL      2$      ;NO - LOOP ON THIS PATTERN
2912      ;TERMINATION OF BANK LOOP
2913 015374 004737 042772      4$: CALL     INCBNK      ;NEXT HIGHER BANK
2914 015400 001351      BNE     1$      ;IF NOT DONE - LOOP ON THIS BANK
2915      ;END OF LOOPS
2916 015402 005737 002134      TST     RLFLAG      ;HAVE WE BEEN RELOCATED?
2917 015406 001401      BEQ     5$      ;NO - SKIP
2918 015410 000207      RETURN      ;YES - RETURN
2919 015412 004737 041130      5$: CALL     RELOCATE      ;MOVE & MAP PROGRAM
2920 015416      ON.ERROR THEN $RETURN
      015416 103001
      015420 000207
      015422
2921      ;**NOTE** RECURSIVE CALL
2922 015422 004737 015320      CALL     BAFPAR      ;CALL SELF
2923 015426 004737 041604      CALL     UNRELOCATE      ;UNMOVE & UNMAP PROGRAM
2924 015432 000207      RETURN
    
```

BCC L207
 RTS PC
 L207:::~::~

```

2927 015434      BAWPAF: SUBTST <<BANKS WORST FIRST,PATTERNS FORWARD **RECURSIVE**>>
:*****
:*SUBTEST      BANKS WORST FIRST,PATTERNS FORWARD **RECURSIVE**
:*****
2928 015434 005037 002106      CLR      BANK      ;SET BANK TO 0
2929      ;START OF BANK LOOP
2930 015440 004737 042422      1$: CALL      EXBANK      ;EXAMINE BANK
2931 015444 005737 002124      TST      ACFLAG      ;CAN WE ACCESS THIS BANK?
2932 015450 001422      BEQ      4$          ;NO - GO TO BANK LOOP TERMINATION
2933 015452 005737 002136      TST      BMFLAG      ;IS THIS BAD MEMORY (WORST FIRST)?
2934 015456 001417      BEQ      4$          ;NO - GO TO BANK LOOP TERMINATION
2935 015460 005737 002132      TST      RRFLAG      ;RELOCATION REQUIRED?
2936 015464 001014      BNE      4$          ;YES - GO TO BANK LOOP TERMINATION
2937 015466 005037 002120      CLR      PATTERN     ;SET PATTERN TO 0
2938      ;START OF PATTERN LOOP
2939 015472 005037 002112      2$: CLR      MARGIN     ;SET MARGIN TO 0
2940      ;START OF MARGIN LOOP
2941 015476 004737 016564      3$: CALL      MTEST      ;GO TEST CORRECT MEMORY
2942      ;TERMINATION OF MARGIN LOOP
2943 015502 004737 043006      CALL      INCMAR      ;NEXT HIGHER MARGIN
2944 015506 001373      BNE      3$          ;IF NOT DONE - LOOP ON THIS MARGIN
2945      ;TERMINATION OF PATTERN LOOP
2946 015510 004737 042746      CALL      INCPAT      ;GO SEE IF THIS IS THE LAST PATTERN
2947 015514 001366      BNE      2$          ;NO - LOOP ON THIS PATTERN
2948      ;TERMINATION OF BANK LOOP
2949 015516 004737 042772      4$: CALL      INCBANK     ;NEXT HIGHER BANK
2950 015522 001346      BNE      1$          ;IF NOT DONE - LOOP ON THIS BANK
2951      ;END OF LOOPS
2952 015524 005137 002712      COM      WORST      ;IS THIS AN EVEN NUMBERED PASS?
2953 015530 001003      BNE      5$          ;YES - SKIP
2954      ;**NOTE** RECURSIVE CALL
2955 015532 004737 015434      CALL      BAWPAF      ;CALL SELF
2956 015536 000207      RETURN
2957 015540 005737 002134      5$: TST      RLFLAG      ;HAVE WE BEEN RELOCATED?
2958 015544 001401      BEQ      6$          ;NO - SKIP
2959 015546 000207      RETURN      ;YES - RETURN
2960 015550 004737 041130      6$: CALL      RELOCATE     ;MOVE & MAP PROGRAM
2961 015554      ON.ERROR THEN $RETURN
      015554 103001
      015556 000207
      015560
      BCC L210
      RTS PC
      L210:::
2962      ;**NOTE** RECURSIVE CALL
2963 015560 004737 015434      CALL      BAWPAF      ;CALL SELF
2964 015564 004737 041604      CALL      UNRELOCATE   ;UNMOVE & UNMAP PROGRAM
2965 015570 000207      RETURN
    
```

```

2968 015572      BAWPAR: SUBST  <<BANKS WORST FIRST,PATTERNS REVERSE  **RECURSIVE**>>
:*****
:*SUBTEST      BANKS WORST FIRST,PATTERNS REVERSE  **RECURSIVE**
:*****
2969 015572  005037  002106      CLR      BANK      ;SET BANK TO 0
2970          ;START OF BANK LOOP
2971 015576  004737  042422      1$: CALL    EXBANK    ;EXAMINE BANK
2972 015602  005737  002124      TST     ACFLAG    ;CAN WE ACCESS THIS BANK?
2973 015606  001422          BEQ     4$        ;NO - GO TO BANK LOOP TERMINATION
2974 015610  005737  002136      TST     BMFLAG    ;IS THIS BAD MEMORY (WORST FIRST)
2975 015614  001417          BEQ     4$        ;NO - GO TO BANK LOOP TERMINATION
2976 015616  005737  002132      TST     RRFLAG    ;RELOCATION REQUIRED?
2977 015622  001014          BNE     4$        ;YES - GO TO BANK LOOP TERMINATION
2978 015624  004737  042762      CALL    SETPAT    ;SET HIGH PATTERN FOR CORRECT MEMORY
2979          ;START OF PATTERN LOOP
2980 015630  004737  043212      2$: CALL    SETMAR    ;SET HIGH MARGINS (IF NOT INHIBITED)
2981          ;START OF MARGIN LOOP
2982 015634  004737  016564      3$: CALL    MTEST    ;GO TEST CORRECT MEMORY
2983          ;TERMINATION OF MARGIN LOOP
2984 015640  004737  043152      CALL    DECMAR    ;NEXT LOWER MARGIN
2985 015644  100373          BPL     3$        ;IF NOT DONE - LOOP ON THIS MARGIN
2986          ;TERMINATION OF PATTERN LOOP
2987 015646  005337  002120      DEC     PATTERN    ;IS THIS THE LAST PATTERN?
2988 015652  100366          BPL     2$        ;NO - LOOP ON THIS PATTERN
2989          ;TERMINATION OF BANK LOOP
2990 015654  004737  042772      4$: CALL    INCBNK    ;NEXT HIGHER BANK
2991 015660  001346          BNE     1$        ;IF NOT DONE - LOOP ON THIS BANK
2992          ;END OF LOOPS
2993 015662  005137  002712      COM     WORST     ;IS THIS AN EVEN NUMBERED PASS?
2994 015666  001003          BNE     5$        ;YES - SKIP
2995          ;**NOTE** RECURSIVE CALL
2996 015670  004737  015572      CALL    BAWPAR    ;CALL SELF
2997 015674  000207          RETURN
2998 015676  005737  002134      5$: TST     RLFLAG    ;HAVE WE BEEN RELOCATED?
2999 015702  001401          BEQ     6$        ;NO - SKIP
3000 015704  000207          RETURN          ;YES - RETURN
3001 015706  004737  041130      6$: CALL    RELOCATE ;MOVE & MAP PROGRAM
3002 015712          ON.ERROR THEN $RETURN
      015712  103001
      015714  000207
      015716
3003          ;**NOTE** RECURSIVE CALL
3004 015716  004737  015572      CALL    BAWPAR    ;CALL SELF
3005 015722  004737  041604      CALL    UNRELOCATE ;UNMOVE & UNMAP PROGRAM
3006 015726  000207          RETURN
    
```

BCC L211
 RTS PC
 L211:::~::~

3010 015730
 3011 015730 005037 002120
 3012
 3013 015734 005037 002106
 3014
 3015 015740 004737 042422
 3016 015744 004737 042730
 3017 015750 001015
 3018 015752 005737 002124
 3019 015756 001412
 3020 015760 005737 002132
 3021 015764 001007
 3022 015766 005037 002112
 3023
 3024 015772 004737 016564
 3025
 3026 015776 004737 043006
 3027 016002 001373
 3028
 3029 016004 004737 042772
 3030 016010 001353
 3031
 3032 016012 004737 042746
 3033 016016 001346
 3034
 3035 016020 005137 002140
 3036
 3037 016024 001403
 3038
 3039 016026 004737 015730
 3040 016032 000207
 3041 016034 005737 002134
 3042 016040 001401
 3043 016042 000207
 3044 016044 004737 041130
 3045 016050
 016050 103001
 016052 000207
 016054
 3046
 3047 016054 004737 015730
 3048 016060 004737 041604
 3049 016064 000207

```

PAFBAF: SUBTST <<PATTERNS FORWARD,BANKS FORWARD      **RECURSIVE**>>
:*****
:*SUBTEST      PATTERNS FORWARD,BANKS FORWARD      **RECURSIVE**
:*****
      CLR      PATTERN      ;SET PATTERN TO 0
      ;START OF PATTERN LOOP
1$:   CLR      BANK        ;SET BANK TO 0
      ;START OF BANK LOOP
2$:   CALL     EXBANK      ;EXAMINE BANK
      CALL     BANKOK     ;CORRECT MEMORY FOR THIS BANK?
      BNE     4$          ;NO - GO TO BANK LOOP TERMINATOR
      TST     ACFLAG     ;CAN WE ACCESS THIS BANK?
      BEQ     4$          ;NO - GO TO BANK LOOP TERMINATION
      TST     RRFLAG     ;RELOCATION REQUIRED?
      BNE     4$          ;YES - GO TO BANK LOOP TERMINATION
      CLR     MARGIN     ;SET MARGIN TO 0
      ;START OF MARGIN LOOP
3$:   CALL     MTEST      ;GO TEST CORRECT MEMORY
      ;TERMINATION OF MARGIN LOOP
      CALL     INCMAR    ;NEXT HIGHER MARGIN
      BNE     3$          ;IF NOT DONE - LOOP ON THIS MARGIN
      ;TERMINATION OF BANK LOOP
4$:   CALL     INCBNK    ;NEXT HIGHER BANK
      BNE     2$          ;IF NOT DONE - LOOP ON THIS BANK
      ;TERMINATION OF PATTERN LOOP
      CALL     INCRPT    ;NEXT HIGHER PATTERN
      BNE     1$          ;OK - LOOP; ELSE CONTINUE
      ;END OF LOOPS
      COM     TMFLAG     ;COMPLEMENT TYPE OF MEMORY
      ;IS THIS AN EVEN NUMBER PASS?
      BEQ     5$          ;YES - SKIP
      ;**NOTE** RECURSIVE CALL
      CALL    PAFBAF     ;CALL SELF
      RETURN
5$:   TST     RLFLAG     ;HAVE WE BEEN RELOCATED?
      BEQ     6$          ;NO - SKIP
      RETURN          ;YES - RETURN
6$:   CALL     RELOCATE  ;MOVE & MAP PROGRAM
      ON.ERROR THEN $RETURN
      ;**NOTE** RECURSIVE CALL
      CALL    PAFBAF     ;CALL SELF
      CALL    UNRELOCATE ;UNMOVE & UNMAP PROGRAM
      RETURN
    
```

BCC L212
 RTS PC
 L212:.....

```

3052 016066      PAFBAW: SUBTST <<PATTERNS FORWARD,BANKS WORST FIRST **RECURSIVE**>>
:*****
:*SUBTEST      PATTERNS FORWARD,BANKS WORST FIRST **RECURSIVE**
:*****
3053 016066 005037 002120      CLR      PATTERN      ;SET PATTERN TO 0
3054          ;START OF PATTERN LOOP
3055 016072 005037 002106      1$: CLR      BANK      ;SET BANK TO 0
3056          ;START OF BANK LOOP
3057 016076 004737 042422      2$: CALL     EXBANK     ;EXAMINE BANK
3058 016102 004737 042730      CALL     BANKOK      ;CORRECT MEMORY FOR THIS BANK?
3059 016106 001020          BNE      4$          ;NO - GO TO BANK LOOP TERMINATOR
3060 016110 005737 002124      TST     ACFLAG      ;CAN WE ACCESS THIS BANK?
3061 016114 001415          BEQ     4$          ;NO - GO TO BANK LOOP TERMINATION
3062 016116 005737 002136      TST     BMFLAG      ;IS THIS BAD MEMORY (WORST FIRST)
3063 016122 001412          BEQ     4$          ;NO - GO TO BANK LOOP TERMINATION
3064 016124 005737 002132      TST     RRFLAG      ;RELOCATION REQUIRED?
3065 016130 001007          BNE      4$          ;YES - GO TO BANK LOOP TERMINATION
3066 016132 005037 002112      CLR     MARGIN      ;SET MARGIN TO 0
3067          ;START OF MARGIN LOOP
3068 016136 004737 016564      3$: CALL     MTEST     ;GO TEST CORRECT MEMORY
3069          ;TERMINATION OF MARGIN LOOP
3070 016142 004737 043006      CALL     INCMAR      ;NEXT HIGHER MARGIN
3071 016146 001373          BNE      3$          ;IF NOT DONE - LOOP ON THIS MARGIN
3072          6176      000207      RETURN
3085 016200 005137 002712      5$: COM     WORST     ;4TH PASS?
3086 016204 001003          BNE      6$          ;YES - SKIP
3087          ;**NOTE** RECURSIVE CALL
3088 016206 004737 016066      CALL     PAFBAW      ;CALL SELF
3089 016212 000207          RETURN
3090 016214 005737 002134      6$: TST     RLFLAG      ;HAVE WE BEEN RELOCATED?
3091 016220 001401          BEQ     7$          ;NO - SKIP
3092 016222 000207          RETURN              ;YES - RETURN
3093 016224 004737 041130      7$: CALL     RELOCATE   ;MOVE & MAP PROGRAM
3094 016230          ON.ERROR THEN $RETURN
      016230 103001
      016232 000207
      016234
3095          ;**NOTE** RECURSIVE CALL
3096 016234 004737 016066      CALL     PAFBAW      ;CALL SELF
3097 016240 004737 041604      CALL     UNRELOCATE  ;UNMOVE & UNMAP PROGRAM
3098 016244 000207          RETURN
    
```

BCC L213
 RTS PC
 L213:*****

```

3101 016246      PARBAF : SUBST  <<PATTERNS REVERSE,BANKS FORWARD      **RECURSIVE**>>
:*****
:*SUBTEST      PATTERNS REVERSE,BANKS FORWARD      **RECURSIVE**
:*****
3102 016246 004737 042762      CALL  HIPAT      ;SET HIGHEST PATTERNS
3103      ;START OF PATTERN LOOP
3104 016252 005037 002106      1$: CLR  BANK      ;SET BANK TO 0
3105      ;START OF BANK LOOP
3106 016256 004737 042422      2$: CALL  EXBANK      ;EXAMINE BANK
3107 016262 004737 042730      CALL  BANKOK      ;CORRECT MEMORY FOR THIS BANK?
3108 016266 001015      BNE  4$      ;NO - GO TO BANK LOOP TERMINATOR
3109 016270 005737 002124      TST  ACFLAG      ;CAN WE ACCESS THIS BANK?
3110 016274 001412      BEQ  4$      ;NO - GO TO BANK LOOP TERMINATION
3111 016276 005737 002132      TST  RRFLAG      ;RELOCATION REQUIRED?
3112 016302 001007      BNE  4$      ;YES - GO TO BANK LOOP TERMINATION
3113 016304 004737 043212      CALL  SETMAR      ;SET HIGH MARGINS (IF NOT INHIBITED)
3114      ;START OF MARGIN LOOP
3115 016310 004737 016564      3$: CALL  MTEST      ;GO TEST CORRECT MEMORY
3116      ;TERMINATION OF MARGIN LOOP
3117 016314 004737 043152      CALL  DECMAR      ;NEXT LOWER MARGIN
3118 016320 100373      BPL  3$      ;IF NOT DONE - LOOP ON THIS MARGIN
3119      ;TERMINATION OF BANK LOOP
3120 016322 004737 042722      4$: CALL  INCBNK      ;NEXT HIGHER BANK
3121 016326 001353      BNE  2$      ;IF NOT DONE - LOOP ON THIS BANK
3122      ;TERMINATION OF PATTERN LOOP
3123 016330 005337 002120      DEC  PATTERN      ;NEXT LOWER PATTERN
3124 016334 100346      BPL  1$      ;OK - LOOP; ELSE CONTINUE
3125      ;END OF LOOPS
3126 016336 005137 002140      COM  TMFLAG      ;COMPLEMENT TYPE OF MEMORY
3127      ;IS THIS AN EVEN NUMBER PASS?
3128 016342 001403      BEQ  5$      ;YES - SKIP
3129      ;**NOTE** RECURSIVE CALL
3130 016344 004737 016246      CALL  PARBAF      ;CALL SELF
3131 016350 000207      RETURN
3132 016352 005737 002134      5$: TST  RLFLAG      ;HAVE WE BEEN RELOCATED?
3133 016356 001401      BEQ  6$      ;NO - SKIP
3134 016360 000207      RETURN      ;YES - RETURN
3135 016362 004737 041130      6$: CALL  RELOCATE      ;MOVE & MAP PROGRAM
3136 016366      ON.ERROR THEN $RETURN
      016366
      016370 000207
      016372
3137      ;**NOTE** RECURSIVE CALL
3138 016372 004737 016246      CALL  PARBAF      ;CALL SELF
3139 016376 004737 041604      CALL  UNRELOCATE      ;UNMOVE & UNMAP PROGRAM
3140 016402 000207      RETURN

```

BCC L214
RTS PC
L214:::~::~


```

3143 016404      PARBAW: SUBST  <<PATTERNS REVERSE, BANKS WORST FIRST  **RECURSIVE**>>
:*****
:*SUBTEST      PATTERNS REVERSE, BANKS WORST FIRST  **RECURSIVE**
:*****
3144 016404 004737 042762      CALL      HIPAT          ;SET HIGHEST PATTERN
3145      ;START OF PATTERN LOOP
3146 016410 005037 002106      1$: CLR      BANK          ;SET BANK TO 0
3147      ;START OF BANK LOOP
3148 016414 004737 042422      2$: CALL     EXBANK       ;EXAMINE BANK
3149 016420 004737 042730      CALL     BANKOK        ;CORRECT MEMORY FOR THIS BANK?
3150 016424 001020      BNE      4$            ;NO - GO TO BANK LOOP TERMINATOR
3151 016426 005737 002124      TST     ACFLAG        ;CAN WE ACCESS THIS BANK?
3152 016432 001415      BEQ     4$            ;NO - GO TO BANK LOOP TERMINATION
3153 016434 005737 002136      TST     BMFLAG        ;IS THIS BAD MEMORY (WORST FIRST)
3154 016440 001412      BEQ     4$            ;NO - GO TO BANK LOOP TERMINATION
3155 016442 005737 002132      TST     RRFLAG        ;RELOCATION REQUIRED?
3156 016446 001007      BNE     4$            ;YES - GO TO BANK LOOP TERMINATION
3157 016450 004737 043212      CALL     SETMAR        ;SET HIGH MARGINS (IF NOT INHIBITED)
3158      ;START OF MARGIN LOOP
3159 016454 004737 016564      3$: CALL     MTEST       ;GO TEST CORRECT MEMORY
3160      ;TERMINATION OF MARGIN LOOP
3161 016460 004737 043152      CALL     DECMAR        ;NEXT LOWER MARGIN
3162 016464 100373      BPL     3$            ;IF NOT DONE - LOOP ON THIS MARGIN
3163      ;TERMINATION OF BANK LOOP
3164 016466 004737 042772      4$: CALL     INCBNK      ;NEXT HIGHER BANK
3165 016472 001350      BNE     2$            ;IF NOT DONE - LOOP ON THIS BANK
3166      ;TERMINATION OF PATTERN LOOP
3167 016474 005337 002120      DEC     PATTERN        ;NEXT LOWER PATTERN
3168 016500 100343      BPL     1$            ;OK - LOOP; ELSE CONTINUE
3169      ;END OF LOOPS
3170 016502 005137 002140      COM     TMFLAG         ;COMPLEMENT TYPE OF MEMORY
3171      ;IS THIS AN EVEN NUMBER PASS?
3172 016506 001403      BEQ     5$            ;YES - SKIP
3173      ;**NOTE** RECURSIVE CALL
3174 016510 004737 016404      CALL     PARBAW        ;CALL SELF
3175 016514 000207      RETURN
3176 016516 005137 002712      5$: COM     WORST        ;4TH PASS?
3177 016522 001003      BNE     6$            ;YES - SKIP
3178      ;**NOTE** RECURSIVE CALL
3179 016524 004737 016404      CALL     PARBAW        ;CALL SELF
3180 016530 000207      RETURN
3181 016532 005737 002134      6$: TST     RLFLAG        ;HAVE WE BEEN RELOCATED?
3182 016536 001401      BEQ     7$            ;NO - SKIP
3183 016540 000207      RETURN                ;YES - RETURN
3184 016542 004737 041130      7$: CALL     RELOCATE     ;MOVE & MAP PROGRAM
3185 016546      ON.ERROR THEN $RETURN
      016546 103001
      016550 000207
      016552
3186      ;**NOTE** RECURSIVE CALL
3187 016552 004737 016404      CALL     PARBAW        ;CALL SELF
3188 016556 004737 041604      CALL     UNRELOCATE    ;UNMOVE & UNMAP PROGRAM
3189 016562 000207      RETURN

```

BCC L215
RTS PC
L215:::~::~

3193 016564

MTEST: SUBTST <<SUBR SETUP MEMORY TEST>>

:*****
:*SUBTEST SUBR SETUP MEMORY TEST
:*****

3194	016564	013700	002112		MOV	MARGIN,RO				
3195	016570	006300			ASL	RO				
3196	016572	010037	177750		MOV	RO,MAINT			;SET MARGINS	
3197	016576				SET	HEADER			;INITIALIZE HEADER MESSAGE TYPEOUT	
3198	016576	012737	177777	002724					MOV #-1,HEADER	
3198	016604				SET	MUT			;INDICATE THERE IS A MEMORY UNDER TEST	
3198	016604	012737	177777	002116					MOV #-1,MUT	
3199	016612	005037	002362		CLR	PASFLG				
3200	016616	005737	002126		TST	MKFLAG			;MK11?	
3201	016622	001410			BEG	2\$;NO - SKIP	
3202									;IF CONTFLAG IS FALSE THEN CALL MKCONTROL	
3203	016624	005737	002332		TST	CONTFLAG				
3204	016630	001002			BNE	1\$				
3205	016632	004737	016664		CALL	MKCONTROL				
3206	016636	004737	021222		CALL	MKTEST			;YES - DO MK11 TESTS	
3207	016642	000402		1\$:	BR	3\$				
3208	016644	004737	021512		CALL	MJTEST			;DO MJ11 TESTS	
3209	016650	005037	002116		CLR	MUT			;NOW - NO MEMORY UNDER TEST	
3210	016654			3\$:	SET	HEADER			;ALLOW HEADERS NORMAL	
3211	016654	012737	177777	002724					MOV #-1,HEADER	
3211	016662	000207			RETURN					

3214 016664

MKCONTROL:SUBTST <<SUBR TEST MK11 CONTROLLER LOGIC DISPATCH>>
:*****
:SUBTEST SUBR TEST MK11 CONTROLLER LOGIC DISPATCH
:*****

3215
3216
3217
3218
3219
3220
3221
3222
3223
3224
3225
3226
3227

:THIS MODULE AND THE NEXT FEW PAGES SOLVE THE PROBLEM OF
:HOW TO RUN THE CSR TESTS ON EACH MK11 MEMORY
:
:IN ORDER TO TEST EACH CONTROLLER (2 PER BOX) I MUST DO
: EACH EXISTING BOX
: IF ECC IS NOT DISABLED
: EACH SIDE OF EACH BOX
: FIND THE ADDRESS OF THIS SIDE (DEPENDS ON INTERLEAVE)
: FIND A LOCATION THAT HAS NO SINGLE BIT ERRORS
: RUN ALL CSR TESTS
: NEXT SIDE
: NEXT BOX
: IF SELONLY IS TRUE THEN \$RETURN

016664
016664 005737 002002
016670 001401
016672 000297
016674

3228
3229
3230
3231

016674
016674 013746 002106
016700 112737 000200 002416
016706 112737 000001 002417
016714
016714 012737 000060 002420
016722

PUSH BANK
MOV B #200,CSRINDEX ;SET BIT FOR CONTROLLER
MOV B #1,CSROUDEX ;SET BIT FOR CONTROLLER
FOR CSRLOOP := #'0 TO #'7

TST SELONLY
BEQ L216
RTS PC
L216:::~::~

3232
3233
3234

016722
016722 133737 002416 002334
016730 001537
016732 004737 017300
016736
016736 012737 000060 002422
016744

IFB CSRINDEX SET.IN MKCSRS
CALL ISECCON
FOR SIDE := #'0 TO #'1

MOV #'0,CSRLOOP
B27:::~::~
BITB CSRINDEX,MKCSRS
BEQ L217

3235
3236
3237
3238

016744
016744 004737 017610
016750
016750 005037 002424
016754
016754 013737 002412 002106
016762

CALL INTKRAP
BEGIN CSRSTUFF
CLR SUCCESS
FOR BANK := CSRLBANK DOWNT0 CSRFBANK

MOV #'0,SIDE
B30:::~::~
B31:::~::~

3239
3240

016762 004737 042422
016766
016766 005737 002124
016772 001467
016774 005737 002132
017000 001064

CALL EXBANK
IF ACFLAG IS TRUE AND RRFLAG IS FALSE

MOV CSRLBANK,BANK
B32:::~::~
TST ACFLAG
BEQ L220
TST RRFLAG
BNE L220
;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
MOV R3,-(SP)

3241

017002
017002 010346
017004 013703 002106
017010 004737 040700

MAP BANK
MOV BANK,R3
CALL MAPPER
.DSABL CRF

3242
3243
3244

017014 012603
017016 104511
017020 000241
017022

INVALIDATE ;INVALIDATE BACKGROUND PATTERN ON "BANK"
CLC
IF SPECIAL IS TRUE THEN \$CALL SIDEOK

MOV (SP)+,R3

F 7

```

017022 005737 002432
017026 001402
017030 004737 021066
017034
3245 017034 ON.NOERROR L221:
017034 103446 BCS L222
3246 017036 FOR TESTADD := CSRFIRST TO #LAST BY CSRINC MOV CSRFIRST,TESTADD
017036 013737 002336 002506 B33:
017044
3247 017044 004737 017374 CALL SBTEST
3248 017050 ON.NOERROR
017050 103431
3249 017052 104424 CACHOFF ;TURN CACHE OFF
3250 017054 FOR I := #0 TO #37
017054 005037 002602 CLR I
017060 B34:
3251 017060 005037 002100 CLR NOPAR ;INDICATE PARITY ACTION
3252 017064 SET HEADER MOV #-1,HEADER
017064 012737 177777 002724 CLR PASFLG
3253 017072 005037 002362 LET RO := I
3254 017076 MOV I,RO
017076 013700 002602 CALL CSRCASE
3255 017102 004737 020114 END ;OF FOR I
3256 017106 INC I
017106 005237 002602 CMP I,#37
017112 023727 002602 000037 BLE B34
017120 003757
017122 E34:
3257 017122 104423 CACHON ;TURN CACHE ON
3258 017124 SET SUCCESS MOV #-1,SUCCESS
017124 012737 177777 002424 LEAVE CSRSTUFF
3259 017132 BR E31
017132 000415 END ;OF ON.NOERROR
3260 017134 L223:
017134 END ;OF FOR TESTADD
017134 063737 002414 002506 ADD CSRFIRST,TESTADD
017142 023727 002506 157776 CMP TESTADD,#LAST
017150 003735 BLE B33
017152 E33:
3262 017152 END ;OF ON.NOERROR L222:
017152 END ;OF IF L220:
3263 017152 END ;OF FOR BANK
017152 005337 002106 DEC BANK
017156 023737 002106 002410 CMP BANK,CSRFIBANK
017164 002276 BGE B32
017166 E32:
3265 017166 END CSRSTUFF E31:
017166 IF SUCCESS IS FALSE
017166 005737 002424 TST SUCCESS
017172 001010 BNE L224
3267 017174 113737 002420 113625 MOVB CSRLOOP,MSGA34 ;SETUP CSR NUMBER
3268 017202 113737 002422 113642 MOVB SIDE,MSGB34 ;SETUP SIDE (0 OR 1)
3269 017210 TYPE MSGO34
    
```

```
017210 104401 113571
3270 017214
017214
3271 017214
017214 005237 002422
017220 023727 002422 000061
017226 003646
017230
3272 017230
017230
3273 017230 000241
3274 017232 106037 002416
3275 017236 106337 002417
3276 017242
017242 005237 002420
017246 023727 002420 000067
017254 003622
017256
3277 017256 104472
3278 017260
017260 012737 177777 002332
3279 017266
017266 012637 002106
3280 017272 004737 042422
3281 017276 000207

TYPEIT ,MSG034
.DSABL CRF
END ;OF IF SUCCESS
L224:::
INC SIDE
CMP SIDE,#'1
BLE B30
E30:::
L217:::
CLC
RORB CSINDEX ;CHANGE TO NEXT CONTROLLER
ASLB CSROUDEX ;CHANGE TO NEXT CONTROLLER
END ;OF FOR CSRLOOP
INC CSRLOOP
CMP CSRLOOP,#'7
BLE B27
E27:::
ECCINIT ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
SET CONFLAG
MOV #-1,CONFLAG
POP BANK
MOV (SP)+,BANK
CALL EXBANK
RETURN
```

```

3284 017300 ISECCON:SUBTST <<IS ECC ON?>>
:*****
:*SUBTEST IS ECC ON?
:*****
3285 :SETUP CSR NUMBER
3286 017300 005000 CLR R0 ;START A ZERO
3287 017302 113702 002417 MOVB CSRODEX,R2 ;GET CSR INDEX #2
3288 017306 106002 1%: RORB R2 ;GET CSR BIT IN CARRY (MAYBE)
3289 017310 103403 BCS 2% ;I GOT IT - SKIP
3290 017312 062700 000004 ADD #4,R0 ;BUMP CSR ADDRESS LSB'S BY 4
3291 017316 000773 BR 1% ;LOOP TILL I FIND THE CSR
3292 017320 010037 002256 2%: MOV R0,CSRNO ;UPDATE CSR NUMBER
3293 017324 104503 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
3294 017326 104426 READCSR
3295 017330 IF #BIT1 SET,IN CSR
017330 032737 000002 002144 BIT #BIT1,CSR
017336 001413 BEQ L225
3296 017340 TYPE MSG078 ;WARNING! ECC IS DISABLED ON BOX
017340 104401 115430 TYPEIT ,MSG078
.DSABL CRF
3297 017344 113737 002420 112134 MOVB CSRLOOP,MSG015
3298 017352 TYPE MSG015
017352 104401 112134 TYPEIT ,MSG015
.DSABL CRF
3299 017356 SET NOECCFLAG
017356 012737 177777 002474 MOV #-1,NOECCFLAG
3300 017364 ELSE
017364 000402 BR L226
017366 L225:*****
3301 017366 005037 002474 CLR NOECCFLAG
3302 017372 END ;OF IF #BIT1
017372 L226:*****
3303 017372 000207 RETURN
  
```

3306 017374

SBETEST:SUBTST <<CHECK FOR SBE FREE LOCATIONS>>
 :*****
 :*SUBTEST CHECK FOR SBE FREE LOCATIONS
 :*****

3307
 3308
 3309
 3310
 3311
 3312
 3313
 3314
 3315
 3316
 3317
 3318
 3319
 3320
 3321
 3322
 3323
 3324
 3325
 3326
 3327
 3328
 3329
 3330

:IN ORDER TO DETERMINE IF A LOCATION IS SBE FREE I DO THIS
 :
 :WRITE ZEROS WITH ECC DISABLE
 :READ ZEROS BACK
 :IF NOT ZEROS THEN RETURN ERROR
 :
 :WRITE ZEROS WITH ECC ENABLED BUT TRAPS DISABLED
 :READ ZEROS BACK
 :IF NOT ZEROS THEN RETURN ERROR
 :
 :TEST THE LOCATION FROM THE PAR'S (WITH NO PROGRAM FETCHES)
 :IF THERE WERE ANY SBE'S OR DBE'S THEN RETURN ERROR
 :
 :COMPLIMENT ZEROS TO ONES WITH ECC DISABLE
 :READ ONES BACK
 :IF NOT ONES THEN RETURN ERROR
 :
 :WRITE 100,100000,00000 (CHECKBITS COMPLIMENT OF BEFORE)
 : WITH ECC ENABLED BUT TRAPS DISABLED
 :TEST THE LOCATION FROM THE PAR'S (WITH NO PROGRAM FETCHES)
 :IF THERE WERE ANY SBE'S OR DBE'S THEN RETURN ERROR
 :
 :IF NONE OF THE ABOVE FORCES A RETURN ERROR THEN RETURN NO.ERROR
 .ENABL LSB

3331 017374 013701 002506
 3332 017400
 017400 052737 040000 177776
 3333 017406 104424
 3334 017410 104471
 3335 017412
 017412 005011
 017414 005061 000002
 3336 017420 005711
 3337 017422 001061
 3338 017424 005761 000002
 3339 017430 001056
 3340
 3341 017432 104503
 3342 017434
 017434 005011
 017436 005061 000002
 3343 017442 005711
 3344 017444 001050
 3345 017446 005761 000002
 3346 017452 001045
 3347
 3348 017454 104510
 3349 017456
 017456 032737 100020 002144
 017464 001040
 3350
 3351 017466 104471

MOV TFSTADD,R1
 SUPERVISOR ;ENTER SUPERVISOR MODE
 BIS #BIT14,PSW ;DO IT TO IT!
 .DSABL CRF
 CACHOFF ;TURN CACHE OFF
 ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
 CLEAR (R1),2(R1)
 CLR (R1)
 CLR 2(R1)
 TST (R1)
 BNE 1\$
 TST 2(R1)
 BNE 1\$
 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
 CLEAR (R1),2(R1)
 CLR (R1)
 CLR 2(R1)
 TST (R1)
 BNE 1\$
 TST 2(R1)
 BNE 1\$
 TSTREAD ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
 IF #BIT15!BIT4 SET.IN CSR THEN GOTO 1\$
 BIT #BIT15!BIT4.CSR
 BNE 1\$
 ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR

```

3352 017470 005111          COM      (R1)
3353 017472 005161 000002  COM      2(R1)
3354 017476 023711 002726  CMP      ONES,(R1)
3355 017502 001031          BNE      1$
3356 017504 023761 002726 000002  CMP      ONES,2(R1)
3357 017512 001025          BNE      1$
3358
3359 017514 104503          CLR1CSR          ;CLEAR 1 SELECTED MK11 CSR
3360 017516 005011          CLR      (R1)
3361 017520 012761 100000 000002  MOV      #BIT15,2(R1)
3362 017526 005711          TST      (R1)
3363 017530 001016          BNE      1$
3364 017532 022761 100000 000002  CMP      #BIT15,2(R1)
3365 017540 001012          BNE      1$
3366
3367 017542 104510          TSTREAD          ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
3368 017544          IF #BIT15:BIT4 SET.IN CSR THEN GOTO 1$
    017544 032737 100020 002144          BIT #BIT15:BIT4,CSR
    017552 001005          BNE 1$
3369
3370 017554 104417          KERNEL          ;ENTER KERNEL MODE
3371 017556 104473          ECCTINIT          ;INITIALIZE 1 SELECTED MK11 CSR
3372 017560 104423          CACHON          ;TURN CACHE ON
3373 017562          $RETURN NOERROR
    017562 000241          CLC
    017564 000207          RTS PC
3374
3375 017566 104503          1$: CLR1CSR          ;CLEAR 1 SELECTED MK11 CSR
3376 017570          CLEAR (R1),2(R1)
    017570 005011          CLR (R1)
    017572 005061 000002  CLR 2(R1)
3377 017576 104417          KERNEL          ;ENTER KERNEL MODE
3378 017600 104473          ECCTINIT          ;INITIALIZE 1 SELECTED MK11 CSR
3379 017602 104423          CACHON          ;TURN CACHE ON
3380 017604          $RETURN ERROR
    017604 000261          SEC
    017606 000207          RTS PC
3381          .DSABL LSB
    
```


3384 017610

INTKRAP:SUBTST <<SETUP INTERLEAVE INFO>>

3385
3386
3387
3388
3389

 :SUBTEST SETUP INTERLEAVE INFO

3390 017610

:BASED ON THE STARTING ADDRESS, BOX CAPACITY, INTERLEAVE, AND SIDE
 :SETUP VARIABLES TO DETERMINE
 :(1) THE STARTING ADDRESS OF THIS CONTROLLER
 :(2) THE NUMBER TO ADD TO EACH ADDRESS TO STAY IN THIS CONTROLLER
 :(3) THE LAST ADDRESS OF THIS CONTROLLER
 PUSH R0

3391 017612
3392 017616
3393 017624
3394 017632
3395 017636
3396 017640
3397 017644
3398 017650
3399 017654

010046
004737 017736
013737 002260 002410
013737 002262 002412
005037 002432

CALL GETSIZE
 MOV FIRSTB,CSRFBANK
 MOV LASTB,CSRLBANK
 CLR SPECIAL
 READCSR ;READ CSR
 MOV CSR+2,R0
 ASH #11,R0
 BIC #^C17,R0
 CASE R0

MOV R0,-(SP)
 ;RO (0..17) = BITS 14,13,12,11 OF CSR+2
 ;IF RO = 0 CALL NEXT; IF RO = 1 CALL NEXT+2, ETC.
 MOV R0,-(SP)
 ASL @SP
 JSR PC,-227

3400 017664
3401 017666
3402 017670
3403 017672
3404 017674
3405 017676
3406 017700
3407 017702
3408 017704
3409 017706
3410 017710
3411 017712
3412 017714
3413 017716
3414 017720
3415 017722
3416 017724

010046
006316
004737 017724

INT..0
 INT..1
 INT..2
 INT..3
 INT..4
 INT..5
 INT..6
 INT..7
 INT..10
 INT..11
 INT..12
 INT..13
 INT..14
 INT..15
 INT..16
 INT..17

:OF CASE

3417 017732
3418 017734

017724 062616
017726 013646
017730 004736
017732 012600
017734 000207

END
 POP R0
 RETURN

L227:.....
 ADD (SP)+,@SP
 MOV @ (SP)+,-(SP)
 JSR PC,@(SP)+
 MOV (SP)+,R0

```

3421 017736      GETSIZE:SUBTST  <<SUBR GET SIZE FROM CSR>>
:*****
:*SUBTEST      SUBR  GET SIZE FROM CSR
:*****
3422            ;SETUP FIRSTB AND LASTB
3423 017736      PUSH      RO
017736 010046      MOV      RO,-(SP)
3424 017740 052737 000010 002144  BIC      #BIT3,CSR      ;GET SET TO READ CSR
3425 017746 042737 000006 002144  BIC      #BIT2!BIT1,CSR
3426 017754 104425      LOADCSR
3427 017756 104426      READCSR
3428 017760 042737 000010 002144  BIC      #BIT3,CSR      ;RESTORE THIS FROM 'SIZE' MODE
3429 017766 113700 002145      MOV      CSR+1,RO      ;GET SIZE
3430 017772 006300      ASL      RO      ;RO = # OF BANKS
3431 017774 110037 002262      MOV      RO,LASTB
3432 020000 013700 002146      MOV      CSR+2,RO
3433            ;CORRECT LAST BANK FOR EXTERNAL INTERLEAVE
3434 020004      IF #BIT12 SET.IN RO THEN LET LASTB := LASTB L.SHIFT 1
020004 032700 010000      BIT      #BIT12,RO
020010 001402      BEQ      L230
020012 006337 002262      ASL      LASTB
020016      L230:*****
3435 020016      IF #BIT13 SET.IN RO THEN LET LASTB := LASTB L.SHIFT 1
020016 032700 020000      BIT      #BIT13,RO
020022 001402      BEQ      L231
020024 006337 002262      ASL      LASTB
020030      L231:*****
3436 020030 042700 177000      BIC      #177000,RO
3437 020034 006300      ASL      RO
3438 020036 010037 002260      MOV      RO,FIRSTB
3439 020042 063737 002260 002262  ADD      FIRSTB,LASTB
3440 020050 005337 002262      DEC      LASTB
3441 020054      IF FIRSTB HI #167 THEN LET FIRSTB := #170
020054 023727 002260 000167      CMP      FIRSTB,#167
020062 101403      BLOS      L232
020064 012737 000170 002260      MOV      #170,FIRSTB
020072      L232:*****
3442 020072      IF LASTB HI #167 THEN LET LASTB := #167
020072 023727 002262 000167      CMP      LASTB,#167
020100 101403      BLOS      L233
020102 012737 000167 002262      MOV      #167,LASTB
020110      L233:*****
3443 020110      POP      RO
020110 012600      MOV      (SP)+,RO
3444 020112 000207      RETURN
    
```

```
3448 020114
3449 020114      010046
      020116      006316
      020120      004737 020224
```

```
CSR CASE:SUBST <<CSR PATTERN CASE STATEMENT>>
:*****
:*SUBTEST      CSR PATTERN CASE STATEMENT
:*****
```

```
MOV RO,-(SP)
ASL @SP
JSR PC,L234
```

```
:WARNING IF YOU CHANGE THIS TABLE ALSO
:CHANGE '$DDW0' - '$DDW5' (THE PATTERN BIT MAP)
```

3450

```
3451
3452
3453
3454 020124 022360
3455 020126 022456
3456 020130 024172
3457 020132 022512
3458 020134 022570
3459 020136 022646
3460 020140 022722
3461 020142 023000
3462 020144 023056
3463 020146 025772
3464 020150 025772
3465 020152 025772
3466 020154 025772
3467 020156 025772
3468 020160 025772
3469 020162 025772
3470 020164 025772
3471 020166 025772
3472 020170 025772
3473 020172 025772
3474 020174 025772
3475 020176 025772
3476 020200 025772
3477 020202 025772
3478 020204 025772
3479 020206 025772
3480 020210 025772
3481 020212 025772
3482 020214 025772
3483 020216 025772
3484 020220 025772
3485 020222 025772
```

MKCSRT:		:PAT TIME	DISCRIPTION
	MT0006	:<1 SEC	INITIAL DATA TEST
	MT0010	:<1 SEC	BYTE ADDRESSING TEST
	MT0025	:<1 SEC	INTERRUPT ENABLE TEST
	MT0011	:<2 SEC	CREATE SINGLF BIT ERROR TEST
	MT0012	:<1 SEC	WRITE BYTE CLEARS SBE TEST
	MT0013	: 1 SEC	CREATE DOUBLE BIT ERROR TEST
	MT0014	: 1 SEC	WRITE INHIBIT DURING DATIP WITH DBE
	MT0015	: 1 SEC	WRITE INHIBIT OF BYTE WITH DBE
	MT0016	:<1 SEC	WRITE INHIBIT OF WORD WITH DBE
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST
	MT0999	: 0 SEC	NULL TEST

END ;OF CASE R0

```
L234:::~::~:
      ADD (SP)+,@SP
      MOV @ (SP)+,-(SP)
      JSR PC,@(SP)+
```

```
3486 020224
      020224      062616
      020226      013646
      020230      004736
3487 020232      000207      RETURN
```

```

3490 020234          SUBST <<DETERMINE ADDRESSING ACCORDING TO INTERLEAVE>>
:*****
:*SUBTEST          DETERMINE ADDRESSING ACCORDING TO INTERLEAVE
:*****
3491                :CSRFBANK := THE FIRST BANK OF THIS CONTROLLER OF THIS CSR
3492                :CSRLBANK := THE LAST BANK OF THIS CONTROLLER OF THIS CSR
3493                :CSRFBANK := THE FIRST BANK OF THIS CONTROLLER OF THIS CSR
3494                :CSRFBANK := THE FIRST BANK OF THIS CONTROLLER OF THIS CSR
3495                :CSRFBANK := THE FIRST BANK OF THIS CONTROLLER OF THIS CSR
3496                :CSRFBANK := THE FIRST BANK OF THIS CONTROLLER OF THIS CSR
3497                :CSRFBANK := THE FIRST BANK OF THIS CONTROLLER OF THIS CSR
3498                :CSRFBANK := THE FIRST BANK OF THIS CONTROLLER OF THIS CSR
3499 020234 012737 060000 002336 INT..0: LET CSRFBANK := FIRSTB
3500 020242 012737 177777 002432          SET SPECIAL
3501 020250 012737 000004 002414          LET CSRINC := #4
3502 020256 000207          RETURN
3503
3504                :INTERNAL INTERLEAVE, NO EXTERNAL INTERLEAVE
3505 020260 013737 002260 002410 INT..1: LET CSRFBANK := FIRSTB
3506 020266 123727 002422 000060          IFB SIDE EQ #'0
3507 020276 012737 060000 002336          LET CSRFBANK := FIRSTB
3508 020304 000403          ELSE
3509 020306 012737 060004 002336          LET CSRFBANK := FIRSTB+4
3510 020314 012737 000010 002414          END ;OF IFB
3511 020314 012737 000010 002414          LET CSRINC := #10
3512 020322 000207          RETURN
3513
3514                :NO INTERNAL INTERLEAVE, 2-1 EXTERNAL INTERLEAVE (WITH EVEN DOUBLE WORDS SELECTED?)
3515 020324 012737 060000 002336 INT..2: LET CSRFBANK := FIRSTB
3516 020332 012737 177777 002432          SET SPECIAL
3517 020340 012737 000010 002414          LET CSRINC := #10
3518 020346 000207          RETURN
3519
3520                :INTERNAL INTERLEAVE, 2-1 EXTERNAL INTERLEAVE (WITH EVEN DOUBLE WORDS SELECTED?)
3521 020350 013737 002260 002410 INT..3: LET CSRFBANK := FIRSTB
3522 020356 123727 002422 000060          IFB SIDE EQ #'0
3523 020366 012737 060000 002336          LET CSRFBANK := FIRSTB
3524 020374          ELSE
  
```

```

020374 000403
020376
3525 020376 012737 060010 002336 LET CSRFIRST := #FIRST+10
020404 012737 060010 002336 END ;OF IFB
3526 020404 012737 000020 002414 LET CSRINC := #20
020412 000207 RETURN
3528 020412 000207
3529
3530 ;NO INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=0,A02=0)
3531 020414 INT..4: LET CSRFIRST := #FIRST
020414 012737 060000 002336 MOV #FIRST,CSRFIRST
020422 012737 177777 002432 SET SPECIAL
020430 012737 000020 002414 LET CSRINC := #20
020436 000207 RETURN MOV #20,CSRINC
3533 020430
3534 020436 000207
3535
3536 ;INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=0,A02=0)
3537 020440 INT..5: LET CSRFBANK := FIRSTB
020440 013737 002260 002410 MOV FIRSTB,CSRFBANK
020446 123727 002422 000060 IFB SIDE EQ #'0
020454 001004 CMPB SIDE, #'0
3539 020456 012737 060000 002336 LET CSRFIRST := #FIRST BNE L241
020464 000403 ELSE MOV #FIRST,CSRFIRST
020466 BR L242
3541 020466 LET CSRFIRST := #FIRST+20
020466 012737 060020 002336 MOV #FIRST+20,CSRFIRST
3542 020474 END ;OF IFB
3543 020474 LET CSRINC := #40
020474 012737 000040 002414 RETURN MOV #40,CSRINC
3544 020502 000207
3545
3546 ;NO INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=1,A02=0)
3547 020504 INT..6: LET CSRFIRST := #FIRST+10
020504 012737 060010 002336 MOV #FIRST+10,CSRFIRST
3548 020512 012737 177777 002432 SET SPECIAL
020520 012737 000020 002414 LET CSRINC := #20
020526 000207 RETURN MOV #20,CSRINC
3550 020526
3551
3552 ;INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=1,A02=0)
3553 020530 INT..7: LET CSRFBANK := FIRSTB
020530 013737 002260 002410 MOV FIRSTB,CSRFBANK
020536 123727 002422 000060 IFB SIDE EQ #'0
020544 001004 CMPB SIDE, #'0
3555 020546 012737 060010 002336 LET CSRFIRST := #FIRST+10 BNE L243
020554 000403 ELSE MOV #FIRST+10,CSRFIRST
3556 020554 BR L244

```

```

3557 020556          LET CSRFIRST := #FIRST+30          L243:.....
      020556 012737 060030 002336          MOV #FIRST+30,CSRFIRST
3558 020564          END ;OF IFB
      020564          L244:.....
3559 020564          LET CSRINC := #40
      020564 012737 000040 002414          MOV #40,CSRINC
      020572 000207          RETURN
3560 020572          ;IMPOSSIBLE CONDITION
3561          ;NO INTERNAL INTERLEAVE, NO EXTERNAL INTERLEAVE (WITH ODD DOUBLE WORDS SELECTED?)
3562          INT.10: ;FALL THRU TO INT.11
3563          ;IMPOSSIBLE CONDITION
3564 020574          ;INTERNAL INTERLEAVE, NO EXTERNAL INTERLEAVE (WITH ODD DOUBLE WORDS SELECTED?)
3565          INT.11: IF FSINFLAG IS FALSE
3566          TST FSINFLAG
3567          BNE L245
3568 020574 005737 002542          SET FSINFLAG
      020600 001005          MOV #-1,FSINFLAG
3569 020602          TYPE MSG097
      020602 012737 177777 002542          TYPEIT ,MSG097
3570 020610          .DSABL CRF
      020610 104401 116137          END ;OF IF FSINFLAG
3571 020614          GOTO INT..1          L245:.....
3572 020614          BR INT..1
      020614 000621          ;NO INTERNAL INTERLEAVE, 2-1 EXTERNAL INTERLEAVE (WITH ODD DOUBLE WORDS SELECTED?)
3573          INT.12: LET CSRFIRST := #FIRST+4
3574          MOV #FIRST+4,CSRFIRST
3575 020616 012737 060004 002336          SET SPECIAL
      020624 012737 177777 002432          MOV #-1,SPECIAL
3576 020624          LET CSRINC := #10
      020632 012737 000010 002414          MOV #10,CSRINC
3577 020632          RETURN
3578 020640          ;INTERNAL INTERLEAVE, 2-1 EXTERNAL INTERLEAVE (WITH ODD DOUBLE WORDS SELECTED?)
3579          INT.13: LET CSRFBANK := FIRSTB
3580          MOV FIRSTB,CSRFBANK
3581 020642 013737 002260 002410          IFB SIDE EQ #'0
      020642 013737 002260 002410          CMPB SIDE, #'0
3582 020650          BNE L246
      020650 123727 002422 000060          LET CSRFIRST := #FIRST+4
3583 020660 012737 060004 002336          MOV #FIRST+4,CSRFIRST
3584 020666          ELSE
      020666 000403          BR L247
      020670          L246:.....
3585 020670          LET CSRFIRST := #FIRST+14
      020670 012737 060014 002336          MOV #FIRST+14,CSRFIRST
3586 020676          END ;OF IFB
      020676          L247:.....
3587 020676          LET CSRINC := #20
      020676 012737 000020 002414          MOV #20,CSRINC
3588 020704          RETURN
3589          ;NO INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=0,A02=1)
3590
    
```

```

3591 020706          INT.14: LET CSRFIRST := #FIRST+4
      020706 012737 060004 002336          MOV #FIRST+4,CSRFIRST
3592 020714          SET SPECIAL
      020714 012737 177777 002432          MOV #-1,SPECIAL
3593 020722          LET CSRINC := #20
      020722 012737 000020 002414          MOV #20,CSRINC
3594 020730          RETURN
3595
3596
3597 020732          ;INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=0,A02=1)
      020732 013737 002260 002410          INT.15: LET CSRFBANK := FIRSTB          MOV FIRSTB,CSRFBANK
3598 020740          IFB SIDE EQ #'0
      020740 123727 002422 000060          CMPB SIDE,#'0
      020746 001004          BNE L250
3599 020750          LET CSRFIRST := #FIRST+4
      020750 012737 060004 002336          MOV #FIRST+4,CSRFIRST
3600 020756          ELSE
      020756 000403          BR L251
3601 020760          LET CSRFIRS . #FIRST+24
      020760 012737 060024 002336          MOV #FIRST+24,CSRFIRST
3602 020766          END ;OF IFB
      020766          L250:~~~~~
3603 020766          LET CSRINC :- #40
      020766 012737 000040 002414          MOV #40,CSRINC
3604 020774          RETURN
3605
3606
3607 020776          ;NO INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=1,A02=1)
      020776 012737 060014 002336          INT.16: LET CSRFIRST :- #FIRST+14          MOV #FIRST+14,CSRFIRST
3608 021004          SET SPECIAL
      021004 012737 177777 002432          MOV #-1,SPECIAL
3609 021012          LET CSRINC :- #20
      021012 012737 000020 002414          MOV #20,CSRINC
3610 021020          RETURN
3611
3612
3613 021022          ;INTERNAL INTERLEAVE, 4-1 EXTERNAL INTERLEAVE (WITH A03=1,A02=1)
      021022 013737 002260 002410          INT.17: LET CSRFBANK := FIRSTB          MOV FIRSTB,CSRFBANK
3614 021030          IFB SIDE EQ #'0
      021030 123727 002422 000060          CMPB SIDE,#'0
      021036 001004          BNE L252
3615 021040          LET CSRFIRST := #FIRST+14
      021040 012737 060014 002336          MOV #FIRST+14,CSRFIRST
3616 021046          ELSE
      021046 000403          BR L253
3617 021050          LET CSRFIRST := #FIRST+34
      021050 012737 060034 002336          MOV #FIRST+34,CSRFIRST
3618 021056          END ;OF IFB
      021056          L252:~~~~~
3619 021056          LET CSRINC :- #40
      021056 012737 000040 002414          MOV #40,CSRINC
3620 021064          RETURN
3621
    
```

3624 021066

```

SIDEOK: SUBST <<DETERMINE IF BANK BELONGS TO CORRECT SIDE>>
:*****
:*SUBTEST DETERMINE IF BANK BELONGS TO CORRECT SIDE
:*****
;RETURN ERROR IF NOT!

```

3625

3626

3627 021066 005037 002404

3628 021072 013702 002336

3629 021076 104475

3630 021100

021100 052737 040000 177776

```

CLR CHECK
MOV CSRFIRST,R2
CB1CSR ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
SUPERVISOR ;ENTER SUPERVISOR MODE
BIS #BIT14,PSW ;DO IT TO IT
.DSABL CRF
CACHOFF ;TURN CACHE OFF

```

3631 021106 104424

3632 021110 012722 000000

3633 021114 012712 000000

3634 021120 104503

3635 021122 005712

3636 021124 104426

3637 021126 013701 002146

3638

3639

3640 021132 104471

3641 021134 013712 002430

3642 021140 013742 002430

3643 021144 104503

3644 021146 104417

3645 021150 104423

3646

3647 021152

021152 032701 001000

021156 001006

021160 023727 002422 000060

021166 001002

021170 000241

021172 000207

021174

3648 021174

021174 032701 001000

021200 001406

021202 023727 002422 000061

021210 001002

021212 000241

021214 000207

021216

3649 021216

021216 000261

021220 000207

```

MOV #0,(R2)+
MOV #0,(R2)
CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
TST (R2)
READCSR
MOV CSR+2,R1
;ELIMINATE DBE
ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
MOV ZEROS,(R2)
MOV ZEROS,-(R2)
CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
KERNEL ;ENTER KERNEL MODE
CACHON ;TURN CACHE ON

```

IF #BIT9 OFF.IN R1 AND SIDE EQ #0 THEN \$RETURN NOERROR

```

BIT #BIT9,R1
BNE L254
CMP SIDE,#0
BNE L254
CLC
RTS PC

```

L254:::~::~

IF #BIT9 SET.IN R1 AND SIDE EQ #1 THEN \$RETURN NOERROR

```

BIT #BIT9,R1
BEQ L255
CMP SIDE,#1
BNE L255
CLC
RTS PC

```

L255:::~::~

\$RETURN ERROR

```

SEC
RTS PC

```



```

3653 021222          MKTEST: SUBTST <<SUBR MK11 TEST DISPATCH>>
:*****
:SUBTEST          SUBR      MK11 TEST DISPATCH
:*****
          IF MULTIONLY IS TRUE THEN $RETURN

3654 021222          TST MULTIONLY
021222 005737 002004      BEQ L256
021226 001401              RTS PC
021230 000207              L256:*****
021232

3655 021232          IF #SWO SET.IN @SWR OR ACTFLAG IS TRUE
021232 032777 000001 161526      BIT #SWO,@SWR
021240 001003              BNE L257
021242 005737 002442              TST ACTFLAG
021246 001401              BEQ L260
021250              L257:*****

3656 021250 104470      ECCDIS          ;DISABLE ERROR CORRECTION
3657 021252          ELSE
021252 000401              BR L261
021254              L260:*****

3658 021254 104502      CLRCSR          ;CLEAR MK11 CSRS
3659 021256          END ;OF IF
021256              L261:*****

3660 021256 012737 000002 002100      MOV #2,NOPAR          ;INDICATE PARITY ACTION
3661 021264 012737 000002 002406      MOV #2,PCBUMP        ;TRAPS ADD 2 TO PC
3662 021272 013700 002120      MOV PATTERN,RO      ;GET PATTERN NUMBER
3663 021276 006300          ASL RO          ;MAKE IT A WORD ADDRESS
3664 021300          IF MKPAT(RO) NE #MT0035 AND MKPAT(RO) NE #MT0999
021300 026027 021402 025652      CMP MKPAT(RO),#MT0035
021306 001405              BEQ L262
021310 026027 021402 025772      CMP MKPAT(RO),#MT0999
021316 001401              BEQ L262

3665 021320 104511      INVALIDATE      ;INVALIDATE BACKGROUND PATTERN ON "BANK"
3666 021322          END ;OF IF MKPAT(RO)
021322              L262:*****

3667 021322 004770 021402      CALL @MKPAT(RO)      ;INDEX OFF TABLE
3668 021326          IF #SWO SET.IN @SWR OR ACTFLAG IS TRUE
021326 032777 000001 161432      BIT #SWO,@SWR
021334 001003              BNE L263
021336 005737 002442              TST ACTFLAG
021342 001413              BEQ L264
021344              L263:*****

3669 021344 104476      WASSBE          ;WAS THERE ANY SINGLE BIT ERRORS
3670 021346          ON.ERROR
021346 103011              BCC L265
021350              MOV #-1,SBFLAG

3671 021350          SET SBFLAG
021350 012737 177777 002022      MOV CSR,SBECRS
3672 021356 013737 002144 002150      MOV CSR+2,SBECRS+2
3673 021364 013737 002146 002152      END ;OF ON.ERROR
3674 021372          L265:*****
021372          END ;OF IF #SWO
021372              L264:*****

3676 021372 104472      ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
3677 021374 005037 002100      CLR NOPAR          ;INDICATE PARITY ACTION
3678 021400 000207      RETURN
3679
3680          ;WARNING IF YOU CHANGE THIS TABLE ALSO

```

```

3681                                     :CHANGE 'SDDW0' - 'SDDW5' (THE PATTERN BIT MAP)
3682
3683
3684 021402                               MKPAT: :PAT      TIME      DISCRPTION
3685 021402 025652                       :NOTE MT0035 MUST BE FIRST & LAST
3686 021404 023134                       MT0035   :<1 SEC   :SOFT ERROR - BACKGROUND PATTERN TEST
3687 021406 022414                       MT0017   :<1 SEC   :HOLDING 1'S & 0'S TEST
3688 021410 021740                       MT0007   :<1 SEC   :ADDRESS BIT TEST
3689 021412 022000                       MT0001   :<1 SEC   :ADDRESS TEST
3690 021414 022216                       MT0002   :<1 SEC   :COMPLEMENT ADDRESS TEST
3691 021416 022300                       MT0004   : 1 SEC   :ROTATING ZEROS TEST
3692 021420 023612                       MT0005   : 1 SEC   :ROTATING ONES TEST
3693 021422 023156                       MT0021   : 1 SEC   :MARCHING 0'S & 1'S TEST
3694 021424 023734                       MT0020   :<1 SEC   :MARCHING 1'S & 0'S IN CHECK BITS
3695 021426 024240                       MT0022   :10 SEC   :REFRESH & SHIFTING DIAGONAL TEST
3696 021430 024032                       MT0026   :<1 SEC   :RANDOM DATA TEST
3697 021432 025214                       MT0024   :20 SEC   :FAST GALLOPING PATTERN TEST
3698 021434 025340                       MT0031   : 3 SEC   :SOB-A-LONG TEST
3699 021436 025530                       MT0033   :<1 SEC   :WRITE RECOVERY TEST
3700 021440 025652                       MT0034   :35 SEC   :BRANCH GOBBLE TEST
3701                                     MT0035   :<1 SEC   :SOFT ERROR - BACKGROUND PATTERN TEST
3702 021442 025772                       :NOTE MT0035 MUST BE FIRST & LAST
3703 021444 025772                       MT0999   : 0 SEC   :NULL TEST
3704 021446 025772                       MT0999   : 0 SEC   :NULL TEST
3705 021450 025772                       MT0999   : 0 SEC   :NULL TEST
3706 021452 025772                       MT0999   : 0 SEC   :NULL TEST
3707 021454 025772                       MT0999   : 0 SEC   :NULL TEST
3708 021456 025772                       MT0999   : 0 SEC   :NULL TEST
3709 021460 025772                       MT0999   : 0 SEC   :NULL TEST
3710 021462 025772                       MT0999   : 0 SEC   :NULL TEST
3711 021464 025772                       MT0999   : 0 SEC   :NULL TEST
3712 021466 025772                       MT0999   : 0 SEC   :NULL TEST
3713 021470 025772                       MT0999   : 0 SEC   :NULL TEST
3714 021472 025772                       MT0999   : 0 SEC   :NULL TEST
3715 021474 025772                       MT0999   : 0 SEC   :NULL TEST
3716 021476 025772                       MT0999   : 0 SEC   :NULL TEST
3717 021500 025772                       MT0999   : 0 SEC   :NULL TEST
3718 021502 025772                       MT0999   : 0 SEC   :NULL TEST
3719 021504 025772                       MT0999   : 0 SEC   :NULL TEST
3720 021506 025772                       MT0999   : 0 SEC   :NULL TEST
3721 021510 025772                       MT0999   : 0 SEC   :NULL TEST

```

3724 021512

```

MJTEST: SUBTS* <<SUBR MJ11 TEST DISPATCH>>
:.....
:SUBTEST SUBR MJ11 TEST DISPATCH
:.....
IF MULTIONLY IS TRUE THEN $RFTURN
  
```

3725 021512

021512 005737 002004
 021516 001401
 021520 000207
 021522

TST MULTIONLY
 BEQ L266
 RTS PC

3726 021522 012737 000002 002100
 3727 021530 012737 000002 002406
 3728 021536 013700 002120
 3729 021542 006300
 3730 021544

```

MOV #2,NOPAR ;INDICATE PARITY ACTION
MOV #2,PCBUMP ;TRAPS ADD 2 TO PC
MOV PATTERN,R0 ;GET PATTERN NUMBER
ASL R0 ;MAKE IT A WORD ADDRESS
IF MJPAT(R0) NE #MT0035 AND MJPAT(R0) NE #MT0999
  
```

L266:::~::~

021544 026027 021600 025652
 021552 001405
 021554 026027 021600 025772
 021562 001401

CMP MJPAT(R0),#MT0035
 BEQ L267
 CMP MJPAT(R0),#MT0999
 BEQ L267

3731 021564 104511

```

INVALIDATE ;INVALIDATE BACKGROUND PATTERN ON 'BANK'
END ;OF IF MJPAT(R0)
  
```

3732 021566

021566 004770 021600
 3733 021566 005037 002100
 3734 021572 000207
 3735 021576

```

CALL @MJPAT(R0) ;INDEX OFF TABLE
CLR NOPAR ;INDICATE PARITY ACTION
RETURN
  
```

L267:::~::~

3736
 3737
 3738
 3739
 3740

```

;WARNING IF YOU CHANGE THIS TABLE ALSO
;CHANGE '$DDW0' - '$DDW5' (THE PATTERN BIT MAP)
  
```

3741 021600

```

MJPAT: ;PAT TIME DISCIPTION
;NOTE MT0035 MUST BE FIRST & LAST
MT0035 :<1 SEC ;SOFT ERROR - BACKGROUND PATTERN TEST
MT0017 :<1 SEC ;HOLDING 1'S & 0'S TEST
MT0007 :<1 SEC ;ADDRESS BIT TEST
MT0001 :<1 SEC ;ADDRESS TEST
MT0002 :<1 SEC ;COMPLEMENT ADDRESS TEST
MT0003 : 1 SEC ;3 XOR 9 WORST CASE NOISE TEST
MT0004 : 1 SEC ;ROTATING ZEROS TEST
MT0005 : 1 SEC ;ROTATING ONES TEST
MT0021 : 1 SEC ;MARCHING 0'S & 1'S TEST
MT0023 :10 SEC ;SHIFTING DIAGONAL TEST
MT0026 :<1 SEC ;RANDOM DATA TEST
MT0024 :20 SEC ;FAST GALLOPING PATTERN TEST
MT0031 : 3 SEC ;SOB-A-LONG TEST
MT0033 :<1 SEC ;WRITE RECOVERY TEST
MT0034 :35 SEC ;BRANCH GOBBLE TEST
MT0035 :<1 SEC ;SOFT ERROR - BACKGROUND PATTERN TEST
;NOTE MT0035 MUST BE FIRST & LAST
MT0999 : 0 SEC ;NULL TEST
MT0999 : 0 SEC ;NULL TEST
MT0999 : 0 SEC ;NULL TEST
MT0999 : 0 SEC ;NULL TEST
MT0999 : 0 SEC ;NULL TEST
MT0999 : 0 SEC ;NULL TEST
MT0999 : 0 SEC ;NULL TEST
MT0999 : 0 SEC ;NULL TEST
MT0999 : 0 SEC ;NULL TEST
MT0999 : 0 SEC ;NULL TEST
MT0999 : 0 SEC ;NULL TEST
  
```

3742 021600 025652
 3743 021602 023134
 3744 021604 022414
 3745 021606 021740
 3746 021610 022000
 3747 021612 022050
 3748 021614 022216
 3749 021616 022300
 3750 021620 023612
 3751 021622 023766
 3752 021624 024240
 3753 021626 024032
 3754 021630 025214
 3755 021632 025340
 3756 021634 025530
 3757 021636 025652
 3758
 3759 021640 025772
 3760 021642 025772
 3761 021644 025772
 3762 021646 025772
 3763 021650 025772
 3764 021652 025772
 3765 021654 025772
 3766 021656 025772
 3767 021660 025772
 3768 021662 025772

3769	021664	025772	MT0999	:	0	SEC	:	NULL	TEST
3770	021666	025772	MT0999	:	0	SEC	:	NULL	TEST
3771	021670	025772	MT0999	:	0	SEC	:	NULL	TEST
3772	021672	025772	MT0999	:	0	SEC	:	NULL	TEST
3773	021674	025772	MT0999	:	0	SEC	:	NULL	TEST
3774	021676	025772	MT0999	:	0	SEC	:	NULL	TEST
3775	021700	025772	MT0999	:	0	SEC	:	NULL	TEST
3776	021702	025772	MT0999	:	0	SEC	:	NULL	TEST

3778
 3779
 3780
 3781 021704

3782 021704 005037 002366
 3783 021710 012700 060000
 3784 021714 012701 040000
 3785 021720 004737 035204
 3786 021724
 021724 004537 043710
 021730 026376

3787 021732 004737 026042
 3788 021736 000207
 3789 021740

3790 021740 012737 000001 002366
 3791 021746 012700 060000
 3792 021752 012701 040000
 3793 021756 005002
 3794 021760 004737 035204
 3795 021764
 021764 004537 043710
 021770 026422

3796 021772 004737 026042
 3797 021776 000207
 3798 022000

3799 022000 012737 000002 002366
 3800 022006 012700 160000
 3801 022012 012701 040000
 3802 022016 012702 000001
 3803 022022 010103
 3804 022024 012704 060000
 3805 022030 012705 100001
 3806 022034
 022034 004537 043710
 022040 026454

3807 022042 004737 026042
 3808 022046 000207

```

.SBTTL PATTERNS
.SBTTL MEMORY TEST SETUP ROUTINES
MT0000: SUBTST <<MT0000     SETUP DATA PATTERN TEST>>
:*****
:*SUBTEST     MT0000     SETUP DATA PATTERN TEST
:*****
        CLR     REALPAT           ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
        MOV     #FIRST,R0
        MOV     #SIZE,R1
        CALL    REGCOPY
        BMOV    MTP000
                JSR R5,BLOCK1
                MTP000
                .DSABL           CRF
        CALL    SUPD01           ;DO IT IN SUPERVISOR MODE
        RETURN
MT0001: SUBTST <<MT0001     SETUP ADDRESS TEST>>
:*****
:*SUBTEST     MT0001     SETUP ADDRESS TEST
:*****
        MOV     #1,REALPAT       ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
        MOV     #FIRST,R0
        MOV     #SIZE,R1
        CLR     R2
        CALL    REGCOPY
        BMOV    MTP001
                JSR R5,BLOCK1
                MTP001
                .DSABL           CRF
        CALL    SUPD01           ;DO IT IN SUPERVISOR MODE
        RETURN
MT0002: SUBTST <<MT0002     SETUP COMPLEMENT ADDRESS TEST>>
:*****
:*SUBTEST     MT0002     SETUP COMPLEMENT ADDRESS TEST
:*****
        MOV     #2,REALPAT       ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
        MOV     #LAST+2,R0
        MOV     #SIZE,R1
        MOV     #1,R2
        MOV     R1,R3
        MOV     #FIRST,R4
        MOV     #100001,R5
        BMOV    MTP002
                JSR R5,BLOCK1
                MTP002
                .DSABL           CRF
        CALL    SUPD01
        RETURN
    
```

```

3811 022050          MT0003: SUBTST <<MT0003          SETUP 3 XOR 9 WORST CASE NOISE TEST>>
:*****
:*SUBTEST          MT0003 SETUP 3 XOR 9 WORST CASE NOISE TEST
:*****
3812 022050 012737 000003 002366      MOV      #3,REALPAT          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
3813 022056 005037 002406              CLR      PCBUMP             ;TRAPS DO NOT ADD TO PC
3814 022062 004737 035214              1$: CALL  FLIPWARN          ;SETUP WARNING CONSTANTS & R2
3815 022066 012701 060000              2$: MOV   #FIRST,R1         ;R1 <-- STARTING ADDRESS
3816 022072 005000                      CLR      R0                 ;INTERLEAVE ADDRESS CONSTANT
3817 022074 160001                      SUB     R0,R1                ;CORRECT FOR ADD BEFORE USE MODE
3818 022076 012703 020000              MOV     #SIZE/2,R3           ;INTERLEAVE SIZE (8K,4K,2K,OR 1K (DOUBLE WORDS))
3819 022102 072327 177770              ASH    #-8,R3                ;R3 <-- R3 / 256.
3820 022106 012702 000004              MOV     #4,R2                ;SMALL LOOP SIZE
3821 022112 012705 000100              MOV     #64,R5               ;MEDIUM LOOP SIZE
3822 022116          BMOV    MTPA03,UDPDR7,17.
      022116 004537 043744              JSR    R5,BLOCK3
      022122 000021                      17.
      022124 177636                      UDPDR7
      022126 026506                      MTPA03
      .DSABL          CRF
3823 022130 104415                      SAVREG
3824 022132 012737 177636 002360      MOV     #FASTCITY-2,SUPDOADD
3825 022140 004737 026220              CALL   SUPD03
3826 022144          BMOV    MTPB03
      022144 004537 043710              JSR    R5,BLOCK1
      022150 026550                      MTPB03
      .DSABL          CRF
3827 022152          BMOV    MTPC03,KDPAR0,8.
      022152 004537 043744              JSR    R5,BLOCK3
      022156 000010                      8.
      022160 172360                      KDPAR0
      022162 026610                      MTPC03
      .DSABL          CRF
3828 022164          BMOV    MTPD03,SDPAR0,8.
      022164 004537 043744              JSR    R5,BLOCK3
      022170 000010                      8.
      022172 172260                      SDPAR0
      022174 026630                      MTPD03
      .DSABL          CRF
3829 022176 104416                      RESREG
3830 022200 004737 026056              CALL   SUPD02
3831 022204 022737 000003 002734      CMP     #3,FLIPLOC          ;DONE WITH 4 PATTERNS
3832                                ;[(0,177777):(177777,0):(401,177777):(177777,401)]?
3833 022212 001323                      BNE    1$                   ;NO - LOOP
3834 022214 000207                      RETURN
3835
3836 022216          MT0004: SUBTST <<MT0004          SETUP ROTATING ZEROS TEST>>
:*****
:*SUBTEST          MT0004 SETUP ROTATING ZEROS TEST
:*****
3837 022216 012737 000004 002366      MOV     #4,REALPAT          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
3838 022224 012737 000004 002406      MOV     #4,PCBUMP           ;TRAPS ADD 4 TO PC
3839 022232 013702 002726              MOV     ONES,R2
3840 022236 004737 035344              CALL   BACKGND              ;WRITE BACKGROUND OF ONES
3841 022242 012700 060000              MOV     #FIRST,R0
3842 022246 012701 040000              MOV     #SIZE,R1
3843 022252          BMOV    MTPA04
    
```

022252 004537 043710
 022256 026650
 3844 022260
 022260 004537 043744
 022264 000010
 022266 172360
 ,022270 026704
 3845 022272 004737 026056
 3846 022276 000207
 3847 022300

JSR R5,BLOCK1
 MTPA04
 .DSABL CRF
 BMOV MTPB04,KDPAR0,8.
 JSR R5,BLOCK3
 8.
 KDPAR0
 MTPB04
 .DSABL CRF
 CALL SUPD02
 RETURN
 MT0005: SUBTST <<MT0005 SETUP ROTATING ONES TEST>>

 ;*SUBTEST MT0005 SETUP ROTATING ONES TEST
 ;*****

3848 022300 012737 000005 002366
 3849 022306 012737 000004 002406
 3850 022314 005002
 3851 022316 004737 035344
 3852 022322 012700 060000
 3853 022326 012701 040000
 3854 022332
 022332 004537 043710
 022336 026724
 3855 022340
 022340 004537 043744
 022344 000010
 022346 172360
 022350 026704
 3856 022352 004737 026056
 3857 022356 000207

MOV #5,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
 MOV #4,PCBUMP ;TRAPS ADD 4 TO PC
 CLR R2
 CALL BACKGND ;WRITE BACKGROUND OF ZEROS
 MOV #FIRST,R0
 MOV #SIZE,R1
 BMOV MTP005
 JSR R5,BLOCK1
 MTP005
 .DSABL CRF
 BMOV MTPB04,KDPAR0,8.
 JSR R5,BLOCK3
 8.
 KDPAR0
 MTPB04
 .DSABL CRF
 CALL SUPD02
 RETURN

3860 022360

MT0006: SUBTST <<MT0006 SETUP INITIAL DATA TEST>>
:*****
:*SUBTEST MT0006 SETUP INITIAL DATA TEST
:*****

3861 022360 012737 000006 002366
3862 022366 012737 000004 002406
3863 022374 013701 002506
3864 022400 012737 026760 002360
3865 022406 004737 026220
3866 022412 000207
3867 022414

MOV #6,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV #4,PCBUMP ;TRAPS ADD 4 TO PC
MOV TESTADD,R1
MOV #MTP006,SUPDOADD
CALL SUPDO3 ;DO IT IN SUPERVISOR MODE
RETURN

MT0007: SUBTST <<MT0007 SETUP ADDRESS BIT TEST>>
:*****
:*SUBTEST MT0007 SETUP ADDRESS BIT TEST
:*****

3868 022414 012737 000007 002366
3869 022422 005002
3870 022424 004737 035344
3871 022430 012701 060000
3872 022434 012702 C00001
3873 022440 050201
3874 022442 012737 027150 002360
3875 022450 004737 026220
3876 022454 000207
3877 022456

MOV #7,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
CLR R2
CALL BACKGND ;OF ZEROS
MOV #FIRST,R1
MOV #1,R2
BIS R2,R1
MOV #MTP007,SUPDOADD
CALL SUPDO3 ;DO IT IN SUPERVISOR MODE
RETURN

MT0010: SUBTST <<MT0010 SETUP BYTE ADDRESSING TEST>>
:*****
:*SUBTEST MT0010 SETUP BYTE ADDRESSING TEST
:*****

3878 022456 012737 000010 002366
3879 022464 012737 000004 002406
3880 022472 013704 002506
3881 022476 012737 027250 002360
3882 022504 004737 026220
3883 022510 000207

MOV #10,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV #4,PCBUMP ;TRAPS ADD 4 TO PC
MOV TESTADD,R4
MOV #MTP010,SUPDOADD
CALL SUPDO3 ;DO IT IN SUPERVISOR MODE
RETURN


```

3886 022512          MT0011: SUBTST <<MT0011      SETUP CREATE SINGLE BIT ERROR TEST>>
:*****
:*SUBTEST          MT0011 SETUP CREATE SINGLE BIT ERROR TEST
:*****
3887 022512          IF NOECCFLAG IS TRUE THEN $RETURN
022512 005737 002474          TST NOECCFLAG
022516 001401          BEQ L270
022520 000207          RTS PC
                                L270:*****
3888 022522          IF ACTFLAG IS TRUE OR APTFLAG IS TRUE
022522 005737 002442          TST ACTFLAG
022526 001003          BNE L271
022530 005737 002444          TST APTFLAG
022534 001404          BEQ L272
                                L271:*****
3889 022536          IF $PASS NE #0 THEN $RETURN
022536 005737 075142          TST $PASS
022542 001401          BEQ L273
022544 000207          RTS PC
                                L273:*****
3890 022546          END ;OF IF ACTFLAG
                                L272:*****
3891 022546 012737 000011 002366  MOV #11,REALPAT          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
3892 022554 012737 027356 002360  MOV #MTP011,SUPDOADD
3893 022562 004737 026220          CALL SUPD03          ;DO IT IN SUPERVISOR MODE
3894 022566 000207          RETURN
3895 022570          MT0012: SUBTST <<MT0012      SETUP WRITE BYTE CLEARS SBE TEST>>
:*****
:*SUBTEST          MT0012 SETUP WRITE BYTE CLEARS SBE TEST
:*****
3896 022570          IF NOECCFLAG IS TRUE THEN $RETURN
022570 005737 002474          TST NOECCFLAG
022574 001401          BEQ L274
022576 000207          RTS PC
                                L274:*****
3897 022600          IF ACTFLAG IS TRUE OR APTFLAG IS TRUE
022600 005737 002442          TST ACTFLAG
022604 001003          BNE L275
022606 005737 002444          TST APTFLAG
022612 001404          BEQ L276
                                L275:*****
3898 022614          IF $PASS NE #0 THEN $RETURN
022614 005737 075142          TST $PASS
022620 001401          BEQ L277
022622 000207          RTS PC
                                L277:*****
3899 022624          END ;OF IF ACTFLAG
                                L276:*****
3900 022624 012737 000012 002366  MOV #12,REALPAT          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
3901 022632 012737 027766 002360  MOV #MTP012,SUPDOADD
3902 022640 004737 026220          CALL SUPD03          ;DO IT IN SUPERVISOR MODE
3903 022644 000207          RETURN
3904 022646          MT0013: SUBTST <<MT0013      SETUP CREATE DOUBLE BIT ERROR TEST>>
:*****
:*SUBTEST          MT0013 SETUP CREATE DOUBLE BIT ERROR TEST
:*****
3905 022646          IF ACTFLAG IS TRUE OR APTFLAG IS TRUE

```

```

022646 005737 002442
022652 001003
022654 005737 002444
022660 001404
022662
3906 022662 IF $PASS NE #0 THEN $RETURN
022662 005737 075142
022666 001401
022670 000207
022672
3907 022672 END ;OF IF ACTFLAG
022672
3908 022672 012737 000013 002366 MOV #13,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
3909 022700 012737 030344 002360 MOV #MTP013,SUPDOADD
3910 022706 012737 000003 002100 MOV #3,NOPAR ;INDICATE PARITY ACTION
3911 022714 004737 026220 CALL SUPDO3 ;DO IT IN SUPERVISOR MODE
3912 022720 000207 RETURN
3913 022722
MT0014: SUBST <<MTO014 SETUP WRITE INHIBIT DURING DATIP WITH DBE>>
:*****
:*SUBTEST MT0014 SETUP WRITE INHIBIT DURING DATIP WITH DBE
:*****
3914 022722 IF NOECCFLAG IS TRUE THEN $RETURN
022722 005737 002474
022726 001401
022730 000207
022732
3915 022732 IF ACTFLAG IS TRUE OR APTFLAG IS TRUE
022732 005737 002442
022736 001003
022740 005737 002444
022744 001404
022746
3916 022746 IF $PASS NE #0 THEN $RETURN
022746 005737 075142
022752 001401
022754 000207
022756
3917 022756 END ;OF IF ACTFLAG
022756
3918 022756 012737 000014 002366 MOV #14,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
3919 022764 012737 030716 002360 MOV #MTP014,SUPDOADD
3920 022772 004737 026220 CALL SUPDO3 ;DO IT IN SUPERVISOR MODE
3921 022776 000207 RETURN
    
```

```

TST ACTFLAG
BNE L300
TST APTFLAG
BEQ L301
L300:*****
    
```

```

TST $PASS
BEQ L302
RTS PC
L302:*****
    
```

```

L301:*****
:*****
    
```

```

TST NOECCFLAG
BEQ L303
RTS PC
L303:*****
    
```

```

TST ACTFLAG
BNE L304
TST APTFLAG
BEQ L305
L304:*****
    
```

```

TST $PASS
BEQ L306
RTS PC
L306:*****
    
```

```

L305:*****
:*****
    
```

```
3924 023000          MT0015: SUBTST <<MT0015      SETUP WRITE INHIBIT OF BYTE WITH DBE>>
:*****
: *SUBTEST          MT0015  SETUP WRITE INHIBIT OF BYTE WITH DBE
:*****
3925 023000          IF NOECCFLAG IS TRUE THEN $RETURN
023000 005737 002474          TST NOECCFLAG
023004 001401          BEQ L307
023006 000207          RTS PC
023010          L307:*****
3926 023010          IF ACTFLAG IS TRUE OR APTFLAG IS TRUE
023010 005737 002442          TST ACTFLAG
023014 001003          BNE L310
023016 005737 002444          TST APTFLAG
023022 001404          BEQ L311
023024          L310:*****
3927 023024          IF $PASS NE #0 THEN $RETURN
023024 005737 075142          TST $PASS
023030 001401          BEQ L312
023032 000207          RTS PC
023034          L312:*****
3928 023034          END ;OF IF ACTFLAG
023034          L311:*****
3929 023034 012737 000015 002366  MOV #15,REALPAT          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
3930 023042 012737 031312 002360  MOV #MT0015,SUPDOADD
3931 023050 004737 026220          CALL SUPD03          ;DO IT IN SUPERVISOR MODE
3932 023054 000207          RETURN
3933 023056          MT0016: SUBTST <<MT0016      SETUP WRITE INHIBIT OF WORD WITH DBE>>
:*****
: *SUBTEST          MT0016  SETUP WRITE INHIBIT OF WORD WITH DBE
:*****
3934 023056          IF NOECCFLAG IS TRUE THEN $RETURN
023056 005737 002474          TST NOECCFLAG
023062 001401          BEQ L313
023064 000207          RTS PC
023066          L313:*****
3935 023066          IF ACTFLAG IS TRUE OR APTFLAG IS TRUE
023066 005737 002442          TST ACTFLAG
023072 001003          BNE L314
023074 005737 002444          TST APTFLAG
023100 001404          BEQ L315
023102          L314:*****
3936 023102          IF $PASS NE #0 THEN $RETURN
023102 005737 075142          TST $PASS
023106 001401          BEQ L316
023110 000207          RTS PC
023112          L316:*****
3937 023112          END ;OF IF ACTFLAG
023112          L315:*****
3938 023112 012737 000016 002366  MOV #16,REALPAT          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
3939 023120 012737 031700 002360  MOV #MT0016,SUPDOADD
3940 023126 004737 026220          CALL SUPD03          ;DO IT IN SUPERVISOR MODE
3941 023132 000207          RETURN
3942 023134          MT0017: SUBTST <<MT0017      SETUP HOLDING 1'S & 0'S>>
:*****
: *SUBTEST          MT0017  SETUP HOLDING 1'S & 0'S
:*****
3943 023134 012737 000017 002366  MOV #17,REALPAT          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
```

CEMKABO 1170 MAIN MEMORY DIAG 1 MACRO M1113 03-AUG-79 16:50 PAGE 161-1
M*0017 SETUP HOLDING 1'S & 0'S

SEQ 0728

3944 023142 012737 032302 002360
3945 023150 004737 026220
3946 023154 000207

MOV #MTP017,SUPDOADD
CALL SUPD03
RETURN

;DO IT IN SUPERVISOR MODE

3949 023156

MT0020: SUBST <<MT0020 SETUP MARCHING 0'S & 1'S IN CHECKBITS TEST>>

 :SUBTEST MT0020 SETUP MARCHING 0'S & 1'S IN CHECKBITS TEST

IF ACTFLAG IS TRUE OR APTFLAG IS TRUE

3950 023156 005737 002442
 023162 001003
 023164 005737 002444
 023170 001404
 023172

TST ACTFLAG
 BNE L317
 TST APTFLAG
 BEQ L320

L317:*****

3951 023172 005737 075142
 023176 001401
 023200 000207
 023202

IF \$PASS NE #0 THEN \$RETURN

TST \$PASS
 BEQ L321
 RTS PC

L321:*****

3952 023202 023202

END ;OF IF ACTFLAG

L320:*****

3953 023202 012737 000020 002366
 3954 023210 005037 002100
 3955 023214 012737 032572 002360
 3956 023222 013700 002334
 3957 023226 005037 023320

MOV #20,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
 CLR NOPAR ;INDICATE PARITY ACTION
 MOV #MTPA20,SUPDOADD
 MOV MKCSRS,R0
 FOR MTV020 := #0 TO #34 BY #4

CLR MTV020
 B35:*****

3958 023232 013737 023320 002256
 3959 023240 106300
 3960 023242 103016

MOV MTV020,CSRNO
 ASLB R0
 ON.ERROR

BCC L322

3961 023244 112737 000060 002422
 3962 023252 004737 017610
 3963 023256 005737 002432

MOVB #'0,SIDE
 CALL INTKRAP
 IF SPECIAL IS FALSE

TST SPECIAL
 BNE L323

023262 001002
 3964 023264 006237 002414
 3965 023270 023270

ASR CSRINC
 END ;OF IF SPECIAL

L323:*****

3966 023270 010046
 3967 023272 004737 023322
 3968 023276 012600
 3969 023300

;NOW CSRFIRST & CSRINC ARE SETUP
 PUSH R0
 CALL MT020Z
 POP R0

MOV R0,-(SP)

MOV (SP)+,R0

3970 023300 023300
 3971 023300 062737 000004 023320
 023306 023727 023320 000034
 023314 003746
 023316

END ;OF ON.ERROR

L322:*****

END ;OF FOR CSRNO

ADD #4,MTV020
 CMP MTV020,#34
 BLE B35

E35:*****

3972 023316 000207
 3973 023320 000000
 3974

RETURN
 MTV020: 0

;VARIABLE FOR PAT 20

3975 023322 013700 002336
 3976 023326 010001
 3977 023330 013702 002414
 3978 023334 005003
 3979 023336 012704 100000

MT020Z: MOV CSRFIRST,R0
 MOV R0,R1
 MOV CSRINC,R2
 CLR R3
 MOV #BIT15,R4

```

3980 023342 012705 160000      MOV      #LAST+2,R5
3981 023346 104503              CLR1CSR      ;CLEAR 1 SELECTED MK11 CSR
3982 023350              BMOV      MTP20A
      023350 004537 043710      JSR R5,BLOCK1
      023354 032360      MTP20A
      .DSABL      CRF
3983 023356 004737 026042      CALL SUPD01
3984 023362              IF #SW11 SET.IN @SWR OR QVFLAG IS TRUE
      023362 032777 004000 157376      BIT #SW11,@SWR
      023370 001003      BNE L324
      023372 005737 002440      TST QVFLAG
      023376 001401      BEQ L325
      023400              L324:::
3985 023400              GOTO MT020Y
      023400 000434              BR MT020Y
3986 023402              END ;OF IF #SW11
      023402              L325:::
3987 023402              BMOV      MTP20B
      023402 004537 043710      JSR R5,BLOCK1
      023406 032376      MTP20B
      .DSABL      CRF
3988 023410 004737 026056      CALL SUPD02
3989 023414              IF #SW0 SET.IN @SWR OR ACTFLAG IS TRUE
      023414 032777 000001 157344      BIT #SW0,@SWR
      023422 001003      BNE L326
      023424 005737 002442      TST ACTFLAG
      023430 001402      BEQ L327
      023432              L326:::
3990 023432 104477              WAS1SBE      ;WAS THERE ANY SINGLE BIT ERRORS ON 1 SELECTED CSR
3991 023434              ON.ERROR THEN GOTO MT020X
      023434 103463              BCS MT020X
3992 023436              END ;OF IF #SW0
      023436              L327:::
3993 023436              BMOV      MTP20C
      023436 004537 043710      JSR R5,BLOCK1
      023442 032430      MTP20C
      .DSABL      CRF
3994 023444 004737 026056      CALL SUPD02
3995 023450              IF #SW0 SET.IN @SWR OR ACTFLAG IS TRUE
      023450 032777 000001 157310      BIT #SW0,@SWR
      023456 001003      BNE L330
      023460 005737 002442      TST ACTFLAG
      023464 001402      BEQ L331
      023466              L330:::
3996 023466 104477              WAS1SBE      ;WAS THERE ANY SINGLE BIT ERRORS ON 1 SELECTED CSR
3997 023470              ON.ERROR THEN GOTO MT020X
      023470 103445              BCS MT020X
3998 023472              END ;OF IF #SW0
      023472              L331:::
3999 023472 013701 002336      MT020Y: MOV      CSRFIRST,R1
4000 023476              BMOV      MTP20D
      023476 004537 043710      JSR R5,BLOCK1
      023502 032462      MTP20D
      .DSABL      CRF
4001 023504 004737 026056      CALL SUPD02
4002 023510              IF #SW0 SET.IN @SWR OR ACTFLAG IS TRUE
      023510 032777 000001 157250      BIT #SW0,@SWR

```

```

023516 001003
023520 005737 002442
023524 001402
023526
4003 023526 104477 WAS1SBE ;WAS THERE ANY SINGLE BIT ERRORS ON 1 SELECTED CSR
4004 023530 ON.ERROR THEN GOTO MTO20X
023530 103425
4005 023532 END ;OF IF #SWO
023532
4006 023532 BMOV MTP20E L333:
023532 004537 043710 JSR R5,BLOCK1
023536 032514 MTP20E
.DSABL CRF
4007 023540 004737 026056 CALL SUPD02
4008 023544 IF #SWO SET.IN @SWR OR ACTFLAG IS TRUE
023544 032777 000001 157214 BIT #SWO,@SWR
023552 001003 BNE L334
023554 005737 002442 TST ACTFLAG
023560 001402 BEO L335
023562
4009 023562 104477 WAS1SBE ;WAS THERE ANY SINGLE BIT ERRORS ON 1 SELECTED CSR
4010 023564 ON.ERROR THEN GOTO MTO20X
023564 103407
4011 023566 END ;OF IF #SWO
023566
4012 023566 BMOV MTP20F L335:
023566 004537 043710 JSR R5,BLOCK1
023572 032546 MTP20F
.DSABL CRF
4013 023574 004737 026056 CALL SUPD02
4014 023600 104503 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
4015 023602 000207 RETURN
4016
4017 023604 004737 026234 MTO20X: CALL SUPD04
4018 023610 000207 RETURN
    
```

```

4021 023612          MT0021: SUBST <<MT0021          SETUP MARCHING 0'S & 1'S TEST>>
:*****
: *SUBTEST          MT0021 SETUP MARCHING 0'S & 1'S TEST
:*****
4022 023612          SET NOSCOPE
023612 012737 177777 002540          MOV #1,NOSCOPE
4023 023620 012737 000021 002366          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
4024 023626 013702 002762          MOV BAKPAT,R2
4025 023632 004737 035344          CALL BACKGND
4026 023636 010203          MOV R2,R3
4027 023640 000303          SWAB R3
4028 023642 012701 160000          MOV #LAST+2,R1
4029 023646 010105          MOV R1,R5
4030 023650 012704 060000          MOV #FIRST,R4
4031 023654          BMOV MTPA21
023654 004537 043710          JSR R5,BLOCK1
023660 033234          MTPA21
          .DSABL CRF
4032 023662 004737 026042          CALL SUPD01
4033
4034 023666          BMOV MTPB21
023666 004537 043710          JSR R5,BLOCK1
023672 033264          MTPB21
          .DSABL CRF
4035 023674 004737 026056          CALL SUPD02
4036
4037 023700 010401          MOV R4,R1
4038 023702          BMOV MTPC21
023702 004537 043710          JSR R5,BLOCK1
023706 033320          MTPC21
          .DSABL CRF
4039 023710 004737 026056          CALL SUPD02
4040
4041 023714          BMOV MTPD21
023714 004537 043710          JSR R5,BLOCK1
023720 033354          MTPD21
          .DSABL CRF
4042 023722 004737 026056          CALL SUPD02
4043 023726 005037 002540          CLR NOSCOPE
4044 023732 000207          RETURN
4045
4046 023734          MT0022: SUBST <<MT0022          SETUP REFRESH & SHIFTING DIAGONAL TEST>>
:*****
: *SUBTEST          MT0022 SETUP REFRESH & SHIFTING DIAGONAL TEST
:*****
4047 023734 004737 026006          CALL KAMITEST          ;CHECK FOR KAMIKAZE MODE
4048 023740          ON.ERROR THEN $RETURN          ;IF NOT IN KAMIKAZE MODE RETURN
023740 103001          BCC L336
023742 000207          RTS PC
023744          L336:::
4049 023744 012737 000022 002366          MOV #22,REALPAT          ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
4050 023752 012737 033404 002360          MOV #MTP022,SUPDOADD
4051 023760 004737 026220          CALL SUPD03          ;DO IT IN SUPERVISOR MODE
4052 023764 000207          RETURN
4053
4054 023766          MT0023: SUBST <<MT0023          SHIFTING DIAGONAL TEST>>
:*****

```



```

: *SUBTEST      MT0023 SHIFTING DIAGONAL TEST
: .....
4055 023766 004737 026006      CALL      KAMITEST      ;CHECK FOR KAMIKAZE MODE
4056 023772      ON.ERROR THEN $RETURN      ;IF NOT IN KAMIKAZE MODE RETURN
      023772 103001      BCC L337
      023774 000207      RTS PL
      023776      L337:.....
4057 023776 012737 000023 002366      MOV      #23,REALPAT      ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
4058 024004 012737 033404 002360      MOV      #MTPO22,SUPDOADD
4059 024012      SET      DIAGFLAG      ;IDENTIFY DIAGONAL TEST TO MTPO22
      024012 012737 177777 002006      MOV      #-1,DIAGFLAG
4060 024020 004737 026220      CALL      SUPDO3      ;DO IT IN SUPERVISOR MODE
4061 024024 005037 002006      CLR      DIAGFLAG
4062 024030 000207      RETURN

```

4064 024032
 4065 024032 004737 026006
 4066 024036 103001 024040 000207
 4067 024042
 4068 024050 012737 177777 002540
 4069 024056 013702 000024 002366
 4070 024062 004737 035344
 4071 024066 010203
 4072 024070 010304
 4073 024072 000304
 4074 024074 012701 060000
 4075 024100 012705 157776
 4076 024104 104415
 4077 024106
 024106 004537 043710
 024112 034060
 4078 024114
 024114 004537 043744
 024120 000010
 024122 172260
 024124 034120
 4079 024126
 024126 004537 043744
 024132 000010
 024134 172360
 024136 034134
 4080 024140 012737 172260 002360
 4081 024146 004737 026234
 4082
 4083
 4084 024152 104416
 4085 024154 000302
 4086 024156 000303
 4087 024160 004737 026234
 4088 024164 005037 002540
 4089 024170 000207
 4090 024172

```

MTO024: SUBST <<MTO024      SETUP FAST GALLOPING PATTERN TEST>>
:*****
:*SUBTEST      MTO024  SETUP FAST GALLOPING PATTERN TEST
:*****
      CALL      KAMITEST      ;CHECK FOR KAMIKAZE MODE
      ON.ERROR THEN $RETURN   ;IF NOT IN KAMIKAZE MODE RETURN
                                   BCC L340
                                   RTS PC
                                   L340:*****
      SET      NOSCOPE
                                   MOV #-1,NOSCOPE
                                   ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
      MOV      #24,REALPAT
      MOV      BAKPAT,R2
      CALL     BACKGND
      MOV      R2,R3
      MOV      R3,R4
      SWAB    R4
      MOV      #FIRST,R1
      MOV      #LAST,R5
      SAVREG
      BMOV     MTPA24
      JSR     R5,BLOCK1
      MTPA24
      .DSABL   CRF
      BMOV     MTPB24,SDPAR0,8.
      JSR     R5,BLOCK3
      8.
      SDPAR0
      MTPB24
      .DSABL   CRF
      BMOV     MTPC24,KDPAR0,8.
      JSR     R5,BLOCK3
      8.
      KDPAR0
      MTPC24
      .DSABL   CRF
      MOV      #SDPAR0,SUPDOADD
      CALL     SUPD04
      ;DO IT AGAIN FOR COMPLEMENT DATA
      RESREG
      SWAB    R2
      SWAB    R3
      CALL     SUPD04
      CLR     NOSCOPE
      RETURN
MTO025: SUBST <<MTO025      SETUP INTERRUPT ENABLE TEST>>
:*****
:*SUBTEST      MTO025  SETUP INTERRUPT ENABLE TEST
:*****
      IF ACTFLAG IS TRUE OR APTFLAG IS TRUE

```

4091 024172
 024172 005737 002442
 024176 001003
 024200 005737 002444
 024204 001404
 024206
 4092 024206

```

      TST ACTFLAG
      BNE L341
      TST APTFLAG
      BEQ L342
      L341:*****
      IF $PASS NE #0 THEN $RETURN

```

024206 005737 075142
024212 001401
024214 000207
024216
4093 024216
024216
4094 024216 012737 000025 002366
4095 024224 012737 034152 002360
4096 024232 004737 026220
4097 024236 000207

END ;OF IF ACTFLAG
MOV #25,REALPAT
MOV #MTP025,SUPDOADD
CALL SUPDOS
RETURN

TST SPASS
BEQ L343
RTS PC
L343:::;
L342:::;
;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
;DO IT IN SUPERVISOR MODE

4100 024240

MT0026: SUBSTST <<MT0026 SETUP RANDOM DATA TEST>>

 :SUBSTEST MT0026 SETUP RANDOM DATA TEST

4101	024240	012737	000026	002366	MOV	#26,REALPAT	
4102	024246	005037	002406		CLR	PCBUMP	; TRAPS DO NOT ADD TO THE PC
4103	024252	013703	002716		MOV	SEEDLO,R3	; INITIALIZE RANDOM NUMBERS
4104	024256	013702	002714		MOV	SEEDHI,R2	
4105	024262	010305			MOV	R3,R5	
4106	024264	010204			MOV	R2,R4	
4107	024266	012701	060000		MOV	#FIRST,R1	
4108	024272	012700	020000		MOV	#SIZE/2,R0	
4109	024276	104415			SAVREG		
4110	024300				BMOV	MTPA26	; WRITE ROUTINE TO FAST MEMORY
	024300	004537	043710		JSR	R5,BLOCK1	
	024304	034576			MTPA26		
					.DSABL	CRF	
4111	024306				BMOV	MTPC26,KDPAR0,8.	; RANDOM SUBPROGRAM TO FAST MEMORY
	024306	004537	043744		JSR	R5,BLOCK3	
	024312	000010			8.		
	024314	172360			KDPAR0		
	024316	034646			MTPC26		
					.DSABL	CRF	
4112	024320				BMOV	MTPD26,SDPAR0,8.	; RANDOM SUBSUBPROGRAM TO FAST MEMORY
	024320	004537	043744		JSR	R5,BLOCK3	
	024324	000010			8.		
	024326	172260			SDPAR0		
	024330	034666			MTPD26		
					.DSABL	CRF	
4113	024332	004737	026042		CALL	SUPD01	; WRITE RANDOM DATA
4114	024336	005037	034626		CLR	RANODD	; FOR ERROR REPORTING
4115	024342				BMOV	MTPB26	; READ ROUTINE TO FAST MEMORY
	024342	004537	043710		JSR	R5,BLOCK1	
	024346	034612			MTPB26		
					.DSABL	CRF	
4116	024350	104416			RESREG		
4117	024352	004737	026042		CALL	SUPD01	; READ RANDOM DATA
4118	024356	010337	002716		MOV	R3,SEEDLO	; UPDATE FOR NEW RANDOM NUMBERS
4119	024362	010237	002714		MOV	R2,SEEDHI	
4120	024366	000207			RETURN		

4123 024370

MT0027: SUBST <<MT0027 UNIQUE BANK TEST>>

:SUBTEST MT0027 UNIQUE BANK TEST

4124
4125

:MAKE SURE THAT EACH BANK CAN HAVE UNIQUE DATA
:WRITE AND READ THE BANK NUMBER IN EACH BANK (EXCEPT WHERE THE PROGRAM IS)
MOV #27,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
CLEAR MARGIN,MAINT ;CLEAR MARGINS

4126 024370 012737 000027 002366
4127 024376

CLR MARGIN
CLR MAINT

024376 005037 002112
024402 005037 177750
4128 024406 104502

CLRCR ;CLEAR MK11 CSRS

4129 024410
024410 004537 043710
024414 026376

BMOV MTP000
JSR R5,BLOCK1
MTP000
.DSABL CRF

4130 024416 012737 000207 177644
4131 024424 012737 177646 002360
4132 024432

WARN7: MOV #207,UIPAR2 ;PUT 'RETURN' INSTRUCTION AFTER WRITE ROUTINE
MOV #UIPAR3,SUPDOADD
SET NOFSMODE

4133 024440
024440 012737 000001 002602
024446

FOR I := #1 TO #2

MOV #-1,NOFSMODE
MOV #1,I

4134 024446
024446 005037 002106
024452

FOR BANK := #0 TO #167

B36:*****
CLR BANK
B37:*****

4135 024452 004737 042422
4136 024456

CALL EXBANK
IF ACFLAG IS TRUE AND RRFLAG IS FALSE

024456 005737 002124
024462 001430
024464 005737 002132
024470 001025

TST ACFLAG
BEQ L344
TST RRFLAG
BNE L344

4137 024472 104511
4138 024474

INVALIDATE ;INVALIDATE BACKGROUND PATTERN ON 'BANK'
LET R2 := BANK

4139 024500 013702 002106
4140 024504 010004 060000

MOV BANK,R2

4141 024506 012701 040000
4142 024512 010103

MOV #FIRST,R0
MOV R0,R4
MOV #SIZE,R1
MOV R1,R3
IF I EQ #1

4143 024514
024514 023727 002602 000001
024522 001002

CMP I,#1
BNE L345

4144 024524 004737 026042
4145 024530

CALL SUPD01
END ;OF IF

4146 024530
024530 023727 002602 000002
024536 001002

IF I EQ #2

CMP I,#2
BNE L346

4147 024540 004737 026220
4148 024544

CALL SUPD03
END ;OF IF

4149 024544
024544

END ;OF IF

L346:*****
L344:*****

4150 024544
024544 005237 002106
024550 023727 002106 000167
024556 003735

END :OF FOR BANK

INC BANK
CMP BANK,#167
BLE B37

024560

E37:*****

4151	024560			END ;OF FOR I	
	024560	005237	002602		INC I
	024564	023727	002602	000002	CMP I,#2
	024572	003725			BLE B36
	024574				E36:.....
4152	024574			IF FS7FLAG IS TRUE	
	024574	005737	002546		TST FS7FLAG
	024600	001403			BEQ L347
4153	024602	005037	002526	CLR NOFSMODE	
4154	024606	000207		RETURN	
4155	024610			END ;OF IF FS7FLAG	L347:.....
	024610			FOR I := #1 TO #2	
4156	024610	012737	000001	002602	MOV #1,I
	024616				B40:.....
4157	024616			FOR BANK := #167 DOWNTD #0	
	024616	012737	000167	002106	MOV #167,BANK
	024624				B41:.....
4158	024624	004737	042422	CALL EXBANK	
4159	024630			IF ACFLAG IS TRUE AND RRFLAG IS FALSE	
	024630	005737	002124		TST ACFLAG
	024634	001430			BEQ L350
	024636	005737	002132		TST RRFLAG
	024642	001025			BNE L350
4160	024644			LET R2 := BANK	MOV BANK,R2
	024644	013702	002106		
4161	024650	005102		COM R2	
4162	024652	012700	060000	MOV #FIRST,R0	
4163	024656	010004		MOV R0,R4	
4164	024660	012701	040000	MOV #SIZE,R1	
4165	024664	010103		MOV R1,R3	
4166	024666			IF I EQ #1	
	024666	023727	002602	000001	CMP I,#1
	024674	001002			BNE L351
4167	024676	004737	026042	CALL SUPD01	
4168	024702			END ;OF IF	L351:.....
	024702			IF I EQ #2	
4169	024702				
	024702	023727	002602	000002	CMP I,#2
	024710	001002			BNE L352
4170	024712	004737	026220	CALL SUPD03	
4171	024716			END ;OF IF	L352:.....
	024716			END ;OF IF	L350:.....
4172	024716			END ;OF FOR BANK	
4173	024716				
	024716	005337	002106		DEC BANK
	024722	023727	002106	000000	CMP BANK,#0
	024730	002335			BGE B41
	024732				E41:.....
4174	024732			END ;OF FOR I	
	024732	005237	002602		INC I
	024736	023727	002602	000002	CMP I,#2
	024744	003724			BLE B40
	024746				E40:.....
4175	024746	005037	002526	CLR NOFSMODE	
4176	024752	000207		RETURN	

```

MT0030: SUBTST <<MT0030      SETUP FLUSH OUT DBE'S TEST>>
:*****
:*SUBTEST      MT0030      SETUP FLUSH OUT DBE'S TEST
:*****
4180 024754 005037 002362
4181 024760 012737 000030 002366 MTA030: CLR      PASFLG
4182 024766 005037 002112          MOV      #30,REALPAT      ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
      024772 005037 177750          CLEAR     MARGIN,MAINT    ;CLEAR MARGINS
      024776 012737 000001 002100          MOV      #1,NOPAR          ;INDICATE COUNT PARITY ERRORS
4183 024776 012737 000001 002100          BMOV     MTP030
4184 025004 004537 043710          JSR     R5,BLOCK1
      025004 034704          MTP030
      025010          DSABL      CRF
4185 025012 104470          ECCDIS          ;DISABLE ERROR CORRECTION
4186 025014 012737 177777 002526          SET      NOFSMODE,NOSCOPE
      025014 012737 177777 002540          MOV      #-1,NOFSMODE
      025022 012737 177777 002540          MOV      #-1,NOSCOPE
4187 025030 005037 002106          FOR BANK := #0 TO #167
      025030 005037 002106          CLR     BANK
      025034          B42:*****
4188 025034 004737 042422          CALL    EXBANK
4189 025040 005737 002126          IF MKFLAG IS TRUE
      025044 001414          TST    MKFLAG
      025046          BEQ   L353
4190 025046 005737 002124          IF ACFLAG IS TRUE AND RRFLAG IS FALSE
      025046 005737 002124          TST    ACFLAG
      025052 001411          BEQ   L354
      025054 005737 002132          TST    RRFLAG
      025060 001006          BNE   L354
4191 025062 012701 040000          MOV     #SIZE,R1
4192 025066 012700 060000          MOV     #FIRST,R0
4193 025072 004737 026042          CALL    SUPD01
4194 025076 005076          END ;OF IF ACFLAG
      025076          L354:*****
4195 025076 005076          END ;OF IF MKFLAG
      025076          L353:*****
4196 025076 005237 002106          END ;OF FOR
      025076 005237 002106          INC    BANK
      025102 023727 002106 000167          CMP    BANK,#167
      025110 003751          BLE   B42
      025112          E42:*****
4197 025112 005737 002362          IF PASFLG IS FALSE
      025112 005737 002362          TST    PASFLG
      025116 001030          BNE   L355
4198 025120 012737 177777 002362          SET    PASFLG
      025120 012737 177777 002362          MOV     #-1,PASFLG
4199 025126 104502          CLRCSR          ;CLEAR MK11 CSRS
4200 025130 004737 041130          CALL    RELOCATE
4201 025134 005037 002526          ON.ERROR
      025134 103006          BCC   L356
4202 025136 104472          ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
4203 025140 005037 002526          CLEAR     NOFSMODE,NOSCOPE
      025140 005037 002526          CLR     NOFSMODF
      025144 005037 002540          CLR     NOSCOPE
4204 025150 000207          RETURN
4205 025152          END ;OF ON.ERROR

```

L356:.....

```
4206 025152 013737 002400 002106      MOV  NEWBANK,BANK
4207 025160 004737 042422              CALL  EXBANK
4208 025164 004737 024760              CALL  MTA030
4209 025170 104472                      ECCINIT ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
4210 025172 004737 041604              CALL  UNRELOCATE
4211 025176 000207                      RETURN
4212 025200                      END ;OF IF PASFLG
```

L355:.....

```
4213 025200 104472                      ECCINIT ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
4214 025202                      CLEAR  NOFSMODE,NOSCOPE
      025202 005037 002526                      CLR  NOFSMODE
      025206 005037 002540                      CLR  NOSCOPE
4215 025212 000207                      RETURN
```


4218 025214

MTG031: SUBTST <<MT0031 SETUP SOB-A-LONG TEST>>

 :*SUBTST MT0031 SETUP SOB-A-LONG TEST

4219 025214 004737 026006

CALL KAMITEST ;CHECK FOR KAMIKAZE MODE RETURN
 ON.ERROR THEN \$RETURN ;IF NOT IN KAMIKAZE MODE RETURN
 BCC L357
 RTS PC
 L357:::~::~

4220 025220 103001
 025222 000207
 025224

4221 025224 012737 177777 002540

SET NOSCOPE
 MOV #-1,NOSCOPE
 ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
 CLR NOPAR ;SETUP PARITY ACTION
 MAP BANK ;MAP FIRST SO BLOCK MOVE WORKS
 MOV R3,-(SP)

4222 025232 012737 000031 002366

4223 025240 005037 002100

4224 025244 010346

MOV BANK,R3
 CALL MAPPER
 .DSABL CRF

025246 013703 002106

025252 004737 040700

025256 012603

4225 025260 052737 040000 177776

SUPERVISOR ;ENTER SUPERVISOR MODE
 BIS #BIT14,PSW ;DO IT TO IT
 .DSABL CRF
 MOV (SP)+,R3

4226 025266 004537 043744

BMOV MTP031,FIRST,SOBLENGTH/2
 JSR R5,BLOCK3
 SOBLENGTH/2
 FIRST
 MTP031
 .DSABL CRF

025272 000027

025274 060000

025276 034714

4227 025300 104417

KERNEL ;ENTER KERNEL MODE

4228 025302 013702 002704

4229 025306 010200

4230 025310 012701 100776

MOV SOBK,R2
 MOV R2,R0
 MOV #100776,R1 ;COMPLEMENT OF INSTRUCTION "SOB R0,DOT"
 MOV #FIRST+SOBLENGTH,R5
 MOV #FIRST+2,SUPDOADD

4232 025320 012737 060002 002360

4233 025326 004737 026234

4234 025332 005037 002540

CALL SUPDO4
 CLR NOSCOPE
 RETURN

4235 025336 000207

4276 025530

MTO034: SUBTST <<MTO034 SETUP BRANCH GOBBLE TEST>>

 : *SUBTEST MTO034 SETUP BRANCH GOBBLE TEST
 : *****

4277 025530 004737 026006

4278 025534 103001
 025536 000207
 025540

CALL KAMITEST ;CHECK FOR KAMIKAZE MODE
 ON.ERROR THEN \$RETURN ;IF NOT IN KAMIKAZF MODE RETURN
 BCC L361
 RTS PC
 L361:::~::~

4279 025540 012737 177777 002540
 4280 025546 012737 000034 002366

4281 025554 005037 002100
 4282 025560 010346
 025562 013703 002106
 025566 004737 040700

SET NOSCOPE
 MOV #34,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
 CLR NOPAR ;SETUP PARITY ACTION
 MAP BANK ;MAP FIRST SO THAT BLOCK MOVE WORKS
 MOV R3,-(SP)

025572 012603

4283 025574
 4284 025574 052737 040000 177776

MOV (SP)+,R3

SUPERVISOR ;ENTER SUPERVISOR MODE
 BIS #BIT14,PSW ;DO IT TO IT!
 .DSABL CRF

4285 025602 004537 043744
 025602 000037
 025606 060000
 025610 035106

BMOV MTP034,FIRST,GBLENGTH/2
 JSR R5,BLOCK3
 GBLENGTH/2
 FIRST
 MTP034
 .DSABL CRF

4286 025614 104417

4287 025616 012705 060076 002360
 4288 025622 012737 060004
 4289 025630 012701 060002
 4290 025634 012702 060003

KERNEL ;ENTER KERNEL MODE

MOV #FIRST+GBLENGTH,R5
 MOV #FIRST+4,SUPDOADD
 MOV #FIRST+2,R1
 MOV #FIRST+3,R2

4293 025640 004737 026234
 4294 025644 005037 002540
 4295 025650 000207

CALL SUPD04
 CLR NOSCOPE
 RETURN

4297 025652

MTO035: SUBTST <<MTO035 SOFT ERROR - BACKGROUND PATTERN TEST>>

 : *SUBTEST MTO035 SOFT ERROR - BACKGROUND PATTERN TEST
 : *****

4298 025652 012737 000035 002366

4299 025660 012700 060000
 4300 025664 012701 040000
 4301 025670 013702 002744
 4302 025674 010103
 4303 025676 013705 002106
 4304 025702 070527 000006
 4305 025706 010004
 4306 025710 004537 043710
 025714 026376

MOV #35,REALPAT
 MOV #FIRST,R0
 MOV #SIZE,R1
 MOV SOFTPAT,R2
 MOV R1,R3
 MOV BANK,R5
 MUL #6,R5
 MOV R0,R4
 BMOV MTP000
 JSR R5,BLOCK1
 MTP000
 .DSABL CRF

4307 025716 012737 000207 177644

MOV #207,UIPAR2 ;PUT RETURN INSTRUCTION AFTER WRITE ROUTINE

```
4308 025724 012737 177646 002360      MOV    #UIPAR3,SUPDOADD
4309 025732      IF #BIT13 SET.IN (CONFIG+2(R5) AND WRITEONLY IS FALSE
      025732 032765 020000 003020
      025740 001406
      025742 005737 002502
      025746 001003
      BIT #BIT13,(CONFIG+2(R5)
      BEQ L362
      TST WRITEONLY
      BNE L362
4310      :BACKGROUND PATTERN IS VALID
4311 025750 004737 026220      CALL  SUPD03      :READ IT
4312 025754 000405      ELSE
      BR L363
4313      :BACKGROUND PATTERN HAS BEEN INVALIDATED
      L362:::
4314 025756 004737 026042      CALL  SUPD01      :WRITE IT
4315 025762 052765 020000 003020      BIS   #BIT13,(CONFIG+2(R5) :VALIDATE IT
4316 025770      END :OF IF #BIT13
      L363:::
4317 025770 000207      RETURN
```

```

4320 025772          MT0999: SUBTST <<MT0999      SETUP NULL TEST>>
:.....
:*SUBTEST          MT0999 SETUP NULL TEST
:.....
4321 025772 005037 002366          CLR      REALPAT
4322 025776          SET      NULLFLAG
4323 025776 012737 177777 002436          MOV     #-1, NULL FLAG
4324 026004 000207          RETURN
4325 026006          KAMITEST: SUBTST <<CHECK FOR KAMIKAZE MODE>>
:.....
:*SUBTEST          CHECK FOR KAMIKAZE MODE
:.....
4326 026006          IF KAMIKAZE IS TRUE OR ACTFLAG IS TRUE OR APTFLAG IS TRUE
026006 005737 002010          TST KAMIKAZE
026012 001006          BNE L364
026014 005737 002442          TST ACTFLAG
026020 001003          BNE L364
026022 005737 002444          TST APTFLAG
026026 001403          BEQ L365
026030          L364:.....
4327 026030          $RETURN NOERROR          ;RUN THE TEST          CLC
026030 000241          RTS PC
026032 000207          ELSE
4328 026034          $RETURN ERROR          ;DON'T RUN THE TEST
026034 000402          SEC
026036          BR L366
4329 026036          END ;OF IF KAMIKAZE          L365:.....
026036 000261          RTS PC
026040 000207          L366:.....
4330 026042
026042
    
```

```

4334 026042          SUPD01: SUBST  <<SUBR EXECUTE PATTERN IN SUPERVISOR>>
:.....
: *SUBTEST          SUBR   EXECUTE PATTERN IN SUPERVISOR
:.....
4335 026042          MAP          BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
026042 010346          MOV          BANK,R3          MOV R3,-(SP)
026044 013703          CALL         MAPPER
026050 004737 040700   .DSABL      CRF
                                MOV (SP)+,R3
4336 026054 012603          SUPD02: CALL         GETDIS
4337 026056 004737 066514   PUSH        $LPERR,$LPADR
                                MOV $LPERR,-(SP)
                                MOV $LPADR,-(SP)
                                MOV R0,SUPDR0
                                MOV #SUPDR1,R0
                                MOV R1,(R0)+
                                MOV R2,(R0)+
                                MOV R3,(R0)+
                                MOV R4,(R0)+
                                MOV R5,(R0)+
                                MOV SP,(R0)+
                                MOV SUPDR0,R0
                                MOV #TAG4$, $LPADR
                                MOV $LPADR,$LPERR
                                TAG4$: MOV #SUPDR6+2,R0
                                MOV -(R0),SP
                                MOV -(R0),R5
                                MOV -(R0),R4
                                MOV -(R0),R3
                                MOV -(R0),R2
                                MOV -(R0),R1
                                MOV -(R0),R0
                                SUPERVISOR
                                BIS #BIT14,PSW          ;ENTER SUPERVISOR MODE
                                .DSABL      CRF          ;DO IT TO IT'
                                MOV #SUPSTK,SSP
                                CACHOFF
                                CALL         FASTCITY          ;TURN CACHE OFF
                                CACHON
                                KERNEL
                                SCOPE
                                POP          $LPADR,$LPERR          ;CALL TO THE USER INSTRUCTION PAR'S
                                MOV (SP)+,$LPADR
                                MOV (SP)+,$LPERR
4338 026072 010037 002266   MOV          R0,SUPDR0
4339 026076 012700 002270   MOV          #SUPDR1,R0
4340 026102 010120          MOV          R1,(R0)+
4341 026104 010220          MOV          R2,(R0)+
4342 026106 010320          MOV          R3,(R0)+
4343 026110 010420          MOV          R4,(R0)+
4344 026112 010520          MOV          R5,(R0)+
4345 026114 010620          MOV          SP,(R0)+
4346 026116 013700 002266   MOV          SUPDR0,R0
4347 026122 012737 026136 002746   MOV          #TAG4$, $LPADR
4348 026130 013737 002746 002750   MOV          $LPADR,$LPERR
4349 026136 012700 002304   TAG4$: MOV #SUPDR6+2,R0
4350 026142 014006          MOV          -(R0),SP
4351 026144 014005          MOV          -(R0),R5
4352 026146 014004          MOV          -(R0),R4
4353 026150 014003          MOV          -(R0),R3
4354 026152 014002          MOV          -(R0),R2
4355 026154 014001          MOV          -(R0),R1
4356 026156 014000          MOV          -(R0),R0
4357 026160          SUPERVISOR
026160 052737 040000 177776   BIS #BIT14,PSW          ;ENTER SUPERVISOR MODE
                                .DSABL      CRF          ;DO IT TO IT'
4358 026166 012706 000740   MOV #SUPSTK,SSP
4359 026172 104424          CACHOFF
4360 026174 004737 177640   CALL         FASTCITY          ;TURN CACHE OFF
4361 026200 104423          CACHON
4362 026202 104417          KERNEL
4363 026204 000004          SCOPE
4364 026206          POP          $LPADR,$LPERR          ;CALL TO THE USER INSTRUCTION PAR'S
026206 012637 002746          MOV (SP)+,$LPADR
026212 012637 002750          MOV (SP)+,$LPERR
4365 026216 000207          RETURN

```

```

4369 026220          SUPD03: MAP      BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
      026220 010346          MOV      BANK,R3          MOV R3,-(SP)
      026222 013703 002106  CALL     MAPPER
      026226 004737 040700  .DSABL  CRF

      026232 012603          MOV (SP)+,R3
4370 026234 004737 066514  SUPD04: CALL  GETDIS
4371 026240          PUSH     $LPERR,$LPADR
      026240 013746 002750  MOV     R0,SUPDR0
      026244 013746 002746  MOV     #SUPDR1,R0
4372 026250 010037 002266  MOV     R1,(R0)+
4373 026254 012700 002270  MOV     R2,(R0)+
4374 026260 010120          MOV     R3,(R0)+
4375 026262 010220          MOV     R4,(R0)+
4376 026264 010320          MOV     R5,(R0)+
4377 026266 010420          MOV     SP,(R0)+
4378 026270 010520          MOV     SUPDR0,R0
4379 026272 010620          MOV     #TBG4$,$LPADR
4380 026274 013700 002266  MOV     $LPADR,$LPERR
4381 026300 012737 026314 002746  TBG4$: MOV     #SUPDR6+2,R0
4382 026306 013737 002746 002750  MOV     -(R0),SP
4383 026314 012700 002304  MOV     -(R0),R5
4384 026320 014006          MOV     -(R0),R4
4385 026322 014005          MOV     -(R0),R3
4386 026324 014004          MOV     -(R0),R2
4387 026326 014003          MOV     -(R0),R1
4388 026330 014002          MOV     -(R0),R0
4389 026332 014001          SUPERVISOR
4390 026334 014000          BIS     #BIT14,PSW          ;ENTER SUPERVISOR MODE
4391 026336          .DSABL  CRF                ;DO IT TO IT.
      026336 052737 040000 177776  MOV     #SUPSTK,SSP
4392 026344 012706 000740  CACHOFF
4393 026350 104424          CALL   @SUPDOADD          ;TURN CACHE OFF
4394 026352 004777 154002  CACHON
4395 026356 104423          KERNEL
4396 026360 104417          SCOPE
4397 026362 000004          POP     $LPADR,$LPERR
4398 026364          MOV (SP)+,$LPADR
      026364 012637 002746  MOV (SP)+,$LPERR
      026370 012637 002750
4399 026374 000207          RETURN
  
```

4403
4404
4405
4406
4407
4408
4409
4410
4411
4412
4413 026376

```
.SBTTL MEMORY TEST PATTERN ROUTINES
*****
: PATTERN REGISTER CONVENTIONS
: R0 FIRST ADDRESS OF PATTERN (FIRST, LAST+2, ETC)
: R1 NUMBER OF ADDRESSES IN PATTERN (SIZE)
: R2 DATA FOR PATTERN (ONES, 52525, ETC)
: R3 COPY OF R1 (IF NECESSARY)
: R4 COPY OF R0 (IF NECESSARY)
: R5 COPY OF R2 (IF NECESSARY)
*****
```

```
MTP000: SUBTST <<MTP000 BASIC DATA TEST>>
*****
: *SUBTEST MTP000 BASIC DATA TEST
*****
```

4414 026376 010220
4415 026400 077102
4416 026402 000240
4417 026404 012401
4418 026406 020102
4419 026410 001402
4420 026412 104427
4421 026414 00024
4422 026416 077307
4423 026420 000207
4424 026422

```
1$: MOV R2, (R0)+ :V177640
SOB R1, MTP000 :V177642
NOP :V177644
2$: MOV (R4)+, R1 :V177646
CMP R1, R2 :V177650
BEQ 3$ :V177652
PERR02 :V177654
NOP :V177656
3$: SOB R3, 2$ :V177660
RETURN :V177662
```

```
MTP001: SUBTST <<MTP001 ADDRESS TEST>>
*****
: *SUBTEST MTP001 ADDRESS TEST
*****
```

4425 026422 010220
4426 026424 062702 000002
4427 026430 077104
4428 026432 000240
4429 026434 012400
4430 026436 020005
4431 026440 001401
4432 026442 104427
4433 026444 062705 000002
4434 026450 077307
4435 026452 000207
4436 026454

```
3$: MOV R2, (R0)+ :V177640
ADD #2, R2 :V177642
SOB R1, 3$ :V177646
NOP :V177650
1$: MOV (R4)+, R0 :V177652
CMP R0, R5 :V177654
BEQ 2$ :V177656
PERR01 :V177660
2$: ADD #2, R5 :V177662
SOB R3, 1$ :V177666
RETURN :V177672
```

```
MTP002: SUBTST <<MTP002 COMPLEMENT ADDRESS TEST (WRITE DOWN, READ UP) >>
*****
: *SUBTEST MTP002 COMPLEMENT ADDRESS TEST (WRITE DOWN, READ UP)
*****
```

4437 026454 010540
4438 026456 062705 000002
4439 026462 077104
4440 026464 000240
4441 026466 162702 000002
4442 026472 012401
4443 026474 020102
4444 026476 001401
4445 026500 104430
4446 026502 077307
4447 026504 000207

```
3$: MOV R5, -(R0) :V177640
ADD #2, R5 :V177642
SOB R1, 3$ :V177646
NOP :V177650
1$: SUB #2, R2 :V177652
MOV (R4)+, R1 :V177656
CMP R1, R2 :V177660
BEQ 2$ :V177662
PERR02 :V177664
2$: SOB R3, 1$ :V177666
RETURN :V177670
```


4451 026506

MTPA03: SUBST <<MTPA03 3 XOR 9 WORST CASE NOISE TEST (WRITE)>>
:*****
:*SUBTEST MTPA03 3 XOR 9 WORST CASE NOISE TEST (WRITE)
:*****

4452
4453
4454
4455
4456
4457
4458

:R0 = INTERLEAVE FACTOR
:R1 = ADDRESS
:R2 = SMALL LOOP CONSTANT
:R3 = NUM OF ADD TO TEST (LARGE LOOP)
:R4 = GOOD DATA
:R5 = MEDIUM LOOP CONSTANT
.ENABL LSB

4459 026506 060001
4460 026510 010421
4461 026512 010421
4462 026514 077204
4463 026516 005104
4464 026520 052704
4465 026522 000401
4466 026524 012702 000004
4467 026530 077512
4468 026532 005104
4469 026534 052704
4470 026536 000401
4471 026540 012705 000100
4472 026544 077320
4473 026546 000207
4474
4475

1\$: ADD R0,R1 ;V177636 ADD INTERLEAVE FACTOR
MOV R4,(R1)+ ;V177640
MOV R4,(R1)+ ;V177642
SOB R2,1\$;V177644
COM R4 ;V177646
BIS (PC)+,R4 ;V177650
WARN2: 401 ;V177652 WARNING LOCATION IS MODIFIED BEFORE LOADING
MOV #4,R2 ;V177654
SOB R5,1\$;V177660
COM R4 ;V177662
BIS (PC)+,R4 ;V177664
WARN3: 401 ;V177666 WARNING LOCATION IS MODIFIED BEFORE LOADING
MOV #64,R5 ;V177670
SOB R3,1\$;V177674
RETURN ;V177676
.DSABL LSB

4476 026550

MTPB03: SUBST <<MTPB03 3 XOR 9 WORST CASE NOISE TEST (READ)>>
:*****
:*SUBTEST MTPB03 3 XOR 9 WORST CASE NOISE TEST (READ)
:*****

4477

4478 026550 000137 172360
4479 026554 077203
4480 026556 005104
4481 026560 052704
4482 026562 000401
4483 026564 012702 000004
4484 026570 077511
4485 026572 005104
4486 026574 052704
4487 026576 000401
4488 026600 012705 000100
4489 026604 077317
4490 026606 000207
4491

1\$: .ENABL LSB
JMP KDPARO ;V177640 GO TO V172360
SOB R2,1\$;V177644
COM R4 ;V177646
BIS (PC)+,R4 ;V177650
WARN4: 401 ;V177652 WARNING LOCATION IS MODIFIED BEFORE LOADING
MOV #4,R2 ;V177654
SOB R5,1\$;V177660
COM R4 ;V177662
BIS (PC)+,R4 ;V177664
WARN5: 401 ;V177666 WARNING LOCATION IS MODIFIED BEFORE LOADING
MOV #64,R5 ;V177670
SOB R3,1\$;V177674
RETURN ;V177676
.DSABL LSB

4494 026610

MTPC03: SUBTST <<MTPC03 TEST DATA SUBPROGRAM>>
:*****
:*SUBTEST MTPC03 TEST DATA SUBPROGRAM
:*****

4495 026610 060001
4496 026612 020421
4497 026614 001401
4498 026616 104431
4499 026620 005141
4500 026622 005111
4501 026624 000137 172260
4502
4503 026630

ADD R0,R1 :V172360
CMP R4,(R1)+ :V172362
BEQ 1\$:V172364
PERR03 :V172366
1\$: COM -(R1) :V172370
COM (R1) :V172372
JMP SDPAR0 :V174372 GO TO V172260

MTPD03: SUBTST <<MTPD03 TEST DATA SUBSUBPROGRAM>>
:*****
:*SUBTEST MTPD03 TEST DATA SUBSUBPROGRAM
:*****

4504 026630 020421
4505 026632 001401
4506 026634 104431
4507 026636 005127
4508 026640 000000
4509 026642 001033
4510 026644 000137 177644

CMP R4,(R1)+ :V172260
BEQ 1\$:V172262
PERR03 :V172264
1\$: COM (PC)+ :V172266
0 :V172270
BNE .+70 :V172272 GO TO V172362
JMP UIPAR2 :V172274 GO TO V177644

4513 026650

```

MTPA04: SUBST <<MTPA04 ROTATING ZEROS TEST>>
:*****
:*SUBTEST MTPA04 ROTATING ZEROS TEST
:*****
1$: MOV #8,R5 ;V177640
MOV R5,R4 ;V177644
CLC ;V177646
JMP KDPARO ;V177650
MOV -2(R0),R4 ;V177654
BCS 2$ ;V177660
CMP R2,R4 ;V177662
BEQ 3$ ;V177664
2$: PERRO4 ;V177666
3$: SOB R1,1$ ;V177670
RETURN ;V177672
    
```

4514 026650 012705 000010
4515 026654 010504
4516 026656 000241
4517 026660 000137 172360
4518 026664 016004 177776
4519 026670 103402
4520 026672 020204
4521 026674 001401
4522 026676 104432
4523 026700 077115
4524 026702 000207
4525
4526 026704

```

MTPB04: SUBST <<MTPB04 SUBR ROTATING BIT>>
:*****
:*SUBTEST MTPB04 SUBR ROTATING BIT
:*****
1$: ROLB (R0) ;V172360
SOB R5,1$ ;V172362
ROLB (R0)+ ;V172364
2$: ROLB (R0) ;V172366
SOB R4,2$ ;V172370
ROLB (R0)+ ;V172372
JMP UIPAR6 ;V172374
    
```

4527 026704 106110
4528 026706 077502
4529 026710 106120
4530 026712 106110
4531 026714 077402
4532 026716 106120
4533 026720 000137 177654
4534
4535 026724

```

MTP005: SUBST <<MTP005 ROTATION ONES TEST>>
:*****
:*SUBTEST MTP005 ROTATION ONES TEST
:*****
1$: MOV #8,R5 ;V177640
MOV R5,R4 ;V177644
SEC ;V177646
JMP KDPARO ;V177650
MOV -2(R0),R4 ;V177654
BCC 2$ ;V177660 IF THIS HAPPENS THE GOOD & BAD MATCH
CMP R2,R4 ;V177662
BEQ 3$ ;V177664
2$: PERRO4 ;V177666
3$: SOB R1,1$ ;V177670
RETURN ;V177672
    
```

4536 026724 012705 000010
4537 026730 010504
4538 026732 000261
4539 026734 000137 172360
4540 026740 016004 177776
4541 026744 103002
4542 026746 020204
4543 026750 001401
4544 026752 104432
4545 026754 077115
4546 026756 000207

4550 026760

MTP006: SUBST <<MTP006 INITIAL DATA TEST>>

: *SUBTEST MTP006 INITIAL DATA TEST

4551

: THIS TEST CHECKS THE DI/DO LINES BY
: SHIFTING A 1 THROUGH THE WORD.

4552

4553 026760 012737 000001 002340

MOV #1,DATBUF ;SET THE FIRST TEST BIT

4554 026766 005037 002342

CLR DATBUF+2 ;CLEAR 2ND WORD

4555 026772 013711 002340

1\$: MOV DATBUF,(R1) ;WRITE TEST WORD 1

4556 026776 013761 002342 000002

MOV DATBUF+2,2(R1) ;AND TEST WORD 2

4557 027004 011102

MOV (R1),R2

4558 027006 023702 002340

CMP DATBUF,R2 ;NOW READ THEM

4559 027012 001401

BEQ 2\$;BR IF FIRST 16 OK

4560 027014 104433

PERR07 ;ERROR TRAP

4561

4562 027016 016102 000002

2\$: MOV 2(R1),R2

4563 027022 023702 002342

CMP DATBUF+2,R2 ;NOW READ SECOND WORD

4564 027026 001401

BEQ 3\$;BR IF OK

4565 027030 104434

PERR10 ;ERROR TRAP

4566

4567 027032 005737 002342

3\$: TST DATBUF+2 ;HAS LAST BIT BEEN TESTED ?

4568 027036 100405

BMI 4\$;MINUS MEANS BIT 3;

4569 027040

DLEFT DATBUF ;NO, SHIFT TEST BIT LEFT

027040 006137 002340

ROL DATBUF

027044 006137 002342

ROL DATBUF+2

4570 027050 000750

.DSABL CRF

4571

BR 1\$;GO WRITE NEW TEST DATA

4572 027052 012737 177776 002340

4\$: MOV #177776,DATBUF ;NOW GOING TO SHIFT A 0 IN DATA DIRECTION

4573 027060 012737 177777 002342

MOV #-1,DATBUF+2 ;PUT A 0 IN BIT 0

4574 027066 013711 002340

5\$: MOV DATBUF,(R1) ;AND 1'S IN ALL OTHERS

4575 027072 013761 002342 000002

MOV DATBUF+2,2(R1) ;WRITE THE DATA

4576 027100 011102

MOV (R1),R2 ;2 WORDS WORTH

4577 027102 023702 002340

CMP DATBUF,R2 ;NOW READ FIRST WORD

4578 027106 001401

BEQ 6\$;BR IF OK

4579 027110 104433

PERR07

4580

4581 027112 016102 000002

6\$: MOV 2(R1),R2

4582 027116 023702 002342

CMP DATBUF+2,R2 ;NOW, READ SECOND WORD

4583 027122 001401

BEQ 7\$;BR IF OK

4584 027124 104434

PERR10

4585

4586 027126 005737 002342

7\$: TST DATBUF+2 ;TESTED BIT 31 YET?

4587 027132 100005

BPL 8\$;BR IF YES, WE'RE DONE

4588 027134

DLEFT DATBUF

027134 006137 002340

ROL DATBUF

027140 006137 002342

ROL DATBUF+2

4589 027144 000750

.DSABL CRF

4590 027146 000207

BR 5\$;KEEP GOING

8\$: RETURN

4594 027150

MTP007: SUBTST <<MTP007 ADDRESS BIT TEST>>

:*SUBTEST MTP007 ADDRESS BIT TEST

4595
4596
4597
4598
4599 027150 111100
4600 027152 105700
4601 027154 001401
4602 027156 104435
4603
4604 027160 105111
4605 027162 111100
4606 027164 105700
4607 027166 001001
4608 027170 104436
4609
4610 027172 040201
4611 027174 006302
4612 027176 050201
4613 027200 011100
4614 027202 005700
4615 027204 001401
4616 027206 104437
4617
4618 027210 005111
4619 027212 011100
4620 027214 005700
4621 027216 001001
4622 027220 104440
4623
4624 027222 022702 100000
4625 027226 001407
4626 027230 022702 010000
4627 027234 001356
4628 027236 006302
4629 027240 012701 160000
4630 027244 000752
4631 027246 000207

```

: THIS TEST CHECKS TO SEE THAT EACH ADDRESS
: BIT IN EACH 16K BANK CAN BE ASSERTED UNIQUELY.
: IT CHECKS FOR ADDRESS BITS THAT MAY BE STUCK
: HIGH, STUCK LOW OR STUCK TOGETHER.
:
: MOVB (R1),R0
: TSTB R0 ;READ AND COMPARE FOR ZEROS
: BEQ 1$ ;BR IF OK
: PERR11
:
1$: COMB (R1) ;COMPLEMENT THE BYTE
: MOVB (R1),R0
: TSTB R0 ;READ FOR NON ZEROS
: BNE 2$ ;BR IF OK
: PERR12
:
2$: BIC R2,R1 ;MASK OFF THE ASSERTED BIT
: ASL R2 ;SHIFT R2 FOR NEXT BIT
: BIS R2,R1 ;SET THE NEW BIT INTO R1
: MOV (R1),R0
: TST R0 ;READ THE NEW ADDRESS
: BEQ 3$ ;READ FOR ZEROS
: PERR13
:
3$: COM (R1) ;COMPL THE WORD
: MOV (R1),R0
: TST R0 ;READ IT AGAIN
: BNE 4$
: PERR14
:
4$: CMP #100000,R2
: BEQ 5$
: CMP #10000,R2 ;CHECK FOR MSB IN 4K BANK
: BNE 2$ ;NOT LAST BIT, BRANCH
: ASL R2
: MOV #160000,R1
: BR 2$
:
5$: RETURN

```

```

4634 027250          MTP010: SUBTST <<MTP010      BYTE ADDRESSING TEST>>
:*****
:*SUBTEST          MTP010  BYTE ADDRESSING TEST
:*****
4635                ;TEST 3 THIS TEST CHECKS FOR PROPER
4636                ;          BYTE ADDRESSING WITH ECC DISABLED
4637 027250 010402   MOV      R4,R2          ;R4 HAS LOWEST ADDRESS
4638 027252 010403   MOV      R4,R3          ;PUT IT IN R3 ALSO
4639 027254 062702 000004 ADD      #4,R2          ;POINT R2 TO LAST BYTE +1
4640 027260 012713 177777 MOV      #-1,(R3)       ;WRITE ALL ONES IN
4641 027264 012763 177777 000002 MOV      #-1,2(R3)     ;THE 4 TEST BYTES
4642 027272 105013          CLR      (R3)          ;CLEAR A BYTE
4643 027274 010401   MOV      R4,R1          ;INITIALIZE R1 FOR EACH PASS
4644 027276 020201   CMP      R2,R1          ;IF EQUAL, JUST READ LAST BYTE
4645 027300 001420   BEQ      6$            ;BR IF EQUAL
4646 027302 020301   CMP      R3,R1          ;IS THIS THE BYTE OF ZEROS
4647 027304 001007   BNE      4$            ;BR IF NOT
4648 027306 111100   MOV      (R1),R0
4649                ;WARNING IF YOU OPTOMIZE CHANGE THE PCBUMP FOR THIS ERROR INCASE OF TRAPS
4650 027310 022700 000000 CMP      #0,R0          ;IT IS, COMPARE FOR ZEROS
4651 027314 001401   BEQ      3$
4652 027316 104435   PERR11
4653
4654 027320 005201   3$: INC      R1          ;NEXT BYTE
4655 027322 000765   BR      2$            ;RETURN
4656 027324 111100          4$: MOV      (R1),R0
4657 027326 122700 177777   CMP      #-1,R0       ;ITS NOT THE BYTE OF 0'S, READ 1'S
4658 027332 001401   BEQ      5$
4659 027334 104436   PERR12
4660
4661 027336 005201   5$: INC      R1          ;MOVE TO NEXT BYTE
4662 027340 000756   BR      2$
4663 027342 112713 177777   6$: MOV      #-1,(R3)   ;RESTORE 1'S TO BYTE JUST TESTED
4664 027346 005203   INC      R3            ;INC TO NEXT BYTE
4665 027350 020302   CMP      R3,R2          ;WAS THAT JUST THE LAST ONE?
4666 027352 001347   BNE      1$            ;BR IF NO
4667 027354 000207   RETURN

```

```

4671 027356      MTP011: SUBTST <<MPT011      SINGLE BIT ERROR TEST>>
:*****
:*SUBTEST      MPT011  SINGLE BIT ERROR TEST
:*****
4672      : (1)  CREATE A SINGLE BIT ERROR
4673      :
4674      : (2)  READ BACK SBE UNCORRECTED (WITH ECC DISABLE)
4675      :
4676      : (3)  ENABLE ECC & READ CORRECTED DATA
4677      :
4678      : (4)  CHECK THAT THE SBE FLAG WAS SET FORM THE LAST READ
4679      :
4680      : (5)  DO (1-4) FOR DATA CONSISTING OF 1 BIT SET IN EACH OF 32
4681      :       POSITIONS OF A DOUBLE WORD
4682      :       THEN DO IT AGAIN FOR 1 BIT CLEARED IN EACH OF 32 POSITIONS OF
4683      :       A DOUBLE WORD
4684      :       IE (64 TIMES)
4685      :
4686      : (6)  DO (1-5) FOR A SBE IN EACH OF 32 BIT POSITIONS
4687      :       IE (RUN TEST 64 * 32 = 2048 TIMES)
4688 027356 104503 CLR1CSR      ;CLEAR 1 SELECTED MK11 CSR
4689      :BIG LOOP
4690 027360 012737 000001 002340 1$: MOV #1,DATBUF ;INITIAL DATA
4691 027366 005037 002342 CLR DATBUF+2 ;32 BITS WORTH
4692      :MEDIUM LOOP
4693 027372 012737 000001 002350 2$: MOV #1,SBEMSK ;INITIAL ERROR MASK
4694 027400 005037 002352 CLR SBEMSK+2 ;32 BITS WORTH
4695      :LITTLE LOOP
4696 027404 013737 002340 002344 3$: MOV DATBUF,TSTDAT ;
4697 027412 013737 002342 002346 MOV DATBUF+2,TSTDAT+2;TO SAVE ORIG DATA
4698 027420 105737 002362 TSTB PASFLG ;COMP DATA ON SECOND PASSONLY
4699 027424 001404 BEQ 4$ ;BR IF FIRST PASS
4700 027426 005137 002344 COM TSTDAT ;SECOND PASS, COMP BOTH WORDS
4701 027432 005137 002346 COM TSTDAT+2
4702 027436 013702 002344 4$: MOV TSTDAT,R2
4703 027442 013703 002346 MOV TSTDAT+2,R3
4704 027446 012737 002344 002402 MOV #TSTDAT,SOURCE ;SET UP ADDRESS FOR CHKGEN
4705 027454 004737 040540 CALL CHKGEN ;GEN CHECKBITS ON TSTDAT
4706      :*****
4707      :** CREATE A SINGLE BIT ERROR **
4708      :*****
4709 027460 013701 002350 MOV SBEMSK,R1
4710 027464 074137 002344 XOR R1,TSTDAT
4711 027470 013701 002352 MOV SBEMSK+2,R1
4712 027474 074137 002346 XOR R1,TSTDAT+2
4713 027500 013701 002506 5$: MOV TESTADD,R1 ;FIRST TEST ADDRESS
4714 027504 104471 ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
4715 027506 013721 002344 MOV TSTDAT,(R1)+ ;WRITE FIRST 16 BITS
4716 027512 104475 CB1CSR ;WRITE GENERATED CHECKBITS IN 1 SELF TED CSR
4717 027514 013711 002346 MOV TSTDAT+2,(R1) ;WRITE SECOND 16 BITS AND
4718      :CHECK BITS. WE NOW HAVE CHECKBITS
4719      :GENERATED ON DATBUF AND DATA WITH
4720      :ONE BIT IN ERROR (AS PER SBEMSK).
4721 027520 104471 ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
4722 027522 014100 MOV -(R1),R0
4723 027524 020037 002344 CMP R0,TSTDAT ;READ THE LOW WORD (UNCORRECTED)
4724 027530 001401 BEQ 6$ ;BR IF OK

```

```

4725 027532 104455 PERR31
4726
4727 027534 062701 000002 6$: ADD #2,R1 ;POINT R1 TO SECOND 16 BITS
4728 027540 011100 MOV (R1),R0
4729 027542 020037 002346 CMP R0,TSTDAT+2 ;READ THE HIGH WORD (UNCORRECTED)
4730 027545 001401 BEQ 7$ ;BR IF OK
4731 027550 104455 PERR31
4732
4733 027552 104503 7$: CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
4734 027554 014100 MOV -(R1),R0
4735 027556 020002 CMP R0,R2 ;SEE IF ITS BEEN CORRECTED
4736 027560 001401 BEQ 8$ ;IT SHOULD HAVE BEEN
4737 027562 104456 PERR32
4738
4739 027564 104510 8$: TSTREAD ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
4740 027566 103411 BCS 9$ ;BR IF IT IS SET
4741 027570 012737 177777 002724 SET HEADER ;ENABLE PRINTING OF ERROR HEADER INFO
4742 027576 010137 002040 MOV R1,ADDRESS MOV #-1,HEADER
4743 027602 104460 PERR34
4744 027604 012737 177777 002724 SET HEADER ;ENABLE PRINTING OF ERROR HEADER INFO
4745 027604 012737 177777 002724 MOV #-1,HEADER
4746 027612 104503 9$: CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
4747 027614 062701 000002 ADD #2,R1 ;POINT TO HIGH WORD
4748 027620 011100 MOV (R1),R0
4749 027622 020003 CMP R0,R3 ;SEE IF ITS BEEN CORRECTED
4750 027624 001401 BEQ 10$ ;BR IF OK
4751 027626 104456 PERR32
4752
4753 027630 104510 10$: TSTREAD ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
4754 027632 103411 BCS 11$ ;BR IF YES
4755 027634 012737 177777 002724 SET HEADER ;ENABLE PRINTING OF ERROR HEADER INFO
4756 027642 010137 002040 MOV R1,ADDRESS MOV #-1,HEADER
4757 027646 104460 PERR34
4758 027650 012737 177777 002724 SET HEADER ;ENABLE PRINTING OF ERROR HEADER INFO
4759 027656 005737 002352 11$: TST SBEMSK+2 ;TEST FOR LAST MASK BIT
4760 027662 100405 BMI 12$ ;MINUS MEANS BIT 31
4761 027664 006137 002350 DLEFT SBEMSK
027664 006137 002350 ROL SBEMSK
027670 006137 002352 ROL SBEMSK+2
.DSABL CRF
BR 3$
4762 027674 000643 12$: IF #SW!1 SET.IN @SWR THEN GOTO 13$
4763 027676 032777 004000 153062 BIT #W11,@SWR
027676 001013 BNE 13$
027704 001013
4764 027706 IF QVFLAG IS TRUE THEN GOTO 13$
027706 005737 002440 TST QVFLAG
027712 001010 BNE 13$
4765 027714 005737 002342 TST DATBUF+2 ;LAST DATA BIT ?
4766 027720 100405 BMI 13$ ;WHICH IS BIT 31
4767 027722 006137 002340 DLEFT DATBUF
027722 006137 002340 ROL DATBUF
027726 006137 002342 ROL DATBUF+2
.DSABL CRF
  
```


4768 027732 000617
 4769 027734 105737 002362
 4770 027740 001003
 4771 027742 105237 002362
 4772 027746 000604
 4773
 4774 027750 104471
 4775 027752 013701 002506
 4776 027756
 027756 005021
 027760 005011
 4777 027762 104503
 4778 027764 000207

13\$: BR 2\$
 TSTB PASFLG ;FIRST OR SECOND PASS ?
 BNE 14\$;NON ZERO MEANS WE'RE DONE
 INCB PASFLG ;NOT DONE, GO DO SECOND PASS
 BR 1\$
 ;CLEAR OUT ANY DBE'S OR SBE'S
 14\$: ECCDIS ;DISABLE ECC ON 1 SELECTED CSR
 MOV TESTADD,R1
 CLEAR (R1)+,(R1)

 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
 RETURN

CLR (R1)+
 CLR (R1)

```

4783 027766 MTP012: SUBST <<MTP012 WRITE BYTE CLEARS SBE TEST>>
:*****
: *SUBTEST MTP012 WRITE BYTE CLEARS SBE TEST
:*****
4783 :SINGLE BIT ERROR TEST TO INSURE THAT A WRITE
4784 :BYTE CLEARS SINGLE BIT ERRORS.
4785 027766 104503 CLR1CSR :CLEAR 1 SELECTED MK11 CSR
4786 027770 012737 000001 002340 MOV #1,DATBUF :INITIAL DATA
4787 027776 005037 002342 CLR DATBUF+2 :32 BITS WORTH
4788 030002 012737 000001 002350 1$: MOV #1,SBEMSK :INITIAL ERROR MASK
4789 030010 005037 002352 CLR SBEMSK+2 :32 BITS WORTH
4790 030014 013737 002340 002344 2$: MOV DATBUF,TSDAT :SAVE ORIGINAL DATA
4791 030022 013737 002342 002346 MOV DATBUF+2,TSDAT+2 :BOTH WORDS
4792 030030 012737 002344 002402 MOV #TSDAT,SOURCE :NEED ADDRESS FOR CHKGEN
4793 030036 004737 040540 CALL CHKGEN :GENERATE CHECK BITS
4794 030042 013701 002350 MOV SBEMSK,R1
4795 030046 074137 002344 XOR R1,TSDAT
4796 030052 013701 002352 MOV SBEMSK+2,R1
4797 030056 074137 002346 XOR R1,TSDAT+2
4798 030062 013704 002506 3$: MOV TESTADD,R4 :FIRST TEST ADDRESS
4799 030066 010401 MOV R4,R1 :PUT IT IN R1 ALSO
4800 030070 104471 ECC1DIS :DISABLE ECC ON 1 SELECTED CSR
4801 030072 013721 002344 MOV TSDAT,(R1)+ :WRITE 16 BITS
4802 030076 104475 CB1CSR :WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
4803 030100 013711 002346 MOV TSDAT+2,(R1) :WRITE HIGH WORD+CHECKBITS
4804 030104 104503 CLR1CSR :CLEAR 1 SELECTED MK11 CSR
4805 :IT'S DANGEROUS IF WE DON'T
4806 030106 012702 002350 MOV #SBEMSK,R2 :ADDRESS OF ERROR MASK
4807 030112 162701 000002 SUB #2,R1 :ADJUST ADDRESS
4808 030116 112711 177777 4$: MOVB #-1,(R1) :WRITE A BYTE OF 1'S
4809 030122 132712 177777 BITB #-1,(R2) :DID THIS BYTE HAVE THE BAD BIT IN IT?
4810 030126 001420 BEQ 6$ :NO - BRANCH
4811 030130 104510 TSTREAD :TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
4812 030132 103011 BCC 5$ :NO - SKIP
4813 030134 SET HEADER :ENABLE PRINTING OF ERROR HEADER INFO
4814 030142 010137 002040 002724 MOV #1,HEADER
4815 030146 104017 ERROR +17
4816 030150 SET HEADER :ENABLE PRINTING OF ERROR HEADER INFO
4817 030150 012737 177777 002724 MOV #1,HEADER
4818 030156 111100 5$: MOVB (R1),R0
4819 030160 122700 177777 CMPB #-1,R0 :CHECK DATA
4820 030164 001414 BEQ 7$ :BR IF OK
4821 030166 104457 PERR33
4822 4823 030170 104510 6$: TSTREAD :TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
4824 :READ THE BYTE
4825 :SBE ERROR BIT ONLY SET ?
4826 030172 103771 BCS 5$ :SHOULD BE SET, BR IF OK
4827 030174 SET HEADER :ENABLE PRINTING OF ERROR HEADER INFO
4828 030174 012737 177777 002724 MOV #1,HEADER
4829 030202 010137 002040 MOV R1,ADDRESS
4830 030206 104460 PERR34
4831 030210 SET HEADER :ENABLE PRINTING OF ERROR HEADER INFO
4832 030210 012737 177777 002724 MOV #1,HEADER

```

```

4832 030214 132712 177777 7$: BITB #1,(R2) ;CHECK FOR LAST BYTE
4833 030222 001012 BNE 8$ ;
4834 030224 005202 INC R2
4835 030226 005201 INC R1 ;MOVE TO NEXT BYTE
4836 030230 013704 002506 MOV TESTADD,R4 ;FIRST TEST ADDRESS
4837 030234 032701 000002 BIT #2,R1 ;TEST FOR LOWER WORD
4838 030240 001726 BEQ 4$ ;BR IF IT'S LOW 16 BITS
4839 030242 062704 000002 ADD #2,R4 ;ADJUST POINTER FOR ERROR REPT.
4840 030246 000723 BR 4$
4841 030250 005737 002352 8$: TST SBEMSK+2 ;LAST ERROR BIT ?
4842 030254 100405 BMI 9$ ;MINUS MEANS BIT 31
4843 030256 DLEFT SBEMSK
030256 006137 002350 ROL SBEMSK
030262 006137 002352 ROL SBEMSK+2
.DSABL CRF
BR 2$
4844 030266 000652
4845 030270 9$: IF #SW11 SET.IN @SWR THEN GOTO 10$
030270 032777 004000 152470 BIT #SW11,@SWR
030276 001013 BNE 10$
4846 030300 IF QVFLAG IS TRUE THEN GOTO 10$
030300 005737 002440 TST QVFLAG
030304 001010 BNE 10$
4847 030306 005737 002342 TST DATBUF+2 ;LAST DATA BIT?
4848 030312 100405 BMI 10$ ;MINUS = BIT 31
4849 030314 DLEFT DATBUF
030314 006137 002340 ROL DATBUF
030320 006137 002342 ROL DATBUF+2
.DSABL CRF
BR 1$
4850 030324 000626 ;CLEAR OUT ANY DBE'S OR SBE'S
4851 ECCDIS ;DISABLE ECC ON 1 SELECTED CSR
4852 030326 104471 10$: MOV TESTADD,R1
4853 030330 013701 002506 CLEAR (R1)+,(R1)
4854 030334 005021 CLR (R1)+
030336 005011 CLR (R1)
4855 030340 104503 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
4856 030342 000207 RETURN
  
```

4860 030344

MTP013: SUBTST <<MTP013 CREATE DOUBLE BIT ERROR TEST>>

: *SUBTEST MTP013 CREATE DOUBLE BIT ERROR TEST
: *****

: DOUBLE BIT ERROR FORCE TO CHECK DOUBLE ERROR LOGIC

: CLEAR 1 SELECTED MK11 CSR

4861						CLR1CSR		
4862	030344	104503				MOV	TESTADD,R1	
4863	030346	013701	002506			CLR	DATBUF	: MAKE INITIAL DATA
4864	030352	005037	002340	1\$:		CLR	DATBUF+2	: ALL ZEROS
4865	030356	005037	002342			MOV	#1,SBEMSK	: INITIAL SINGLE ERROR MASK
4866	030362	012737	000001	002350	2\$:	CLR	SBEMSK+2	: SECOND WORD
4867	030370	005037	002352			MOV	#1,DBEMSK	: INITIAL DOUBLE ERROR MASK
4868	030374	012737	000001	002354	3\$:	CLR	DBEMSK+2	: 32 BITS HERE ALSO
4869	030402	005037	002356			MOV	DATBUF,TSTDAT	
4870	030406	013737	002340	002344	4\$:	MOV	DATBUF+2,TSTDAT+2	
4871	030414	013737	002342	002346		TSTB	PASFLG	: NO COMPLEMENTING FIRST PASS
4872	030422	105737	002362			BEQ	5\$	
4873	030426	001404				COM	TSTDAT	: COMP FIRST WORD
4874	030430	005137	002344			COM	TSTDAT+2	: SECOND WORD
4875	030434	005137	002346			CLR1CSR		: CLEAR 1 SELECTED MK11 CSR
4876	030440	104503		5\$:		CMF	SBEMSK,DBEMSK	: CAN'T HAVE THE SAME ERROR BIT SET
4877	030442	023737	002350	002354		BNE	6\$: IN BOTH MASKS
4878	030450	001004				CMF	SBEMSK+2,DBEMSK+2	: COULD BE EQUAL IN SECOND WORD
4879	030452	023737	002352	002356		BEQ	9\$: GO MAKE THEM NOT EQUAL
4880	030460	001452				MOV	#TSTDAT,SOURCE	: SOURCE ADDRESS FOR CHKGEN
4881	030462	012737	002344	002402	6\$:	CALL	CHKGEN	: GO GENERATE CHECK BITS
4882	030470	004737	040540			MOV	SBEMSK,R2	
4883	030474	013702	002350			XOR	R2,TSTDAT	
4884	030500	074237	002344			MOV	SBEMSK+2,R2	
4885	030504	013702	002352			XOR	R2,TSTDAT+2	
4886	030510	074237	002346			MOV	DBEMSK,R2	
4887	030514	013702	002354			XOR	R2,TSTDAT	
4888	030520	074237	002344			MOV	DBEMSK+2,R2	
4889	030524	013702	002356			XOR	R2,TSTDAT+2	
4890	030530	074237	002346			ECC1DIS		: DISABLE ECC ON 1 SELECTED CSR
4891	030534	104471				MOV	TSTDAT,(R1)+	: WRITE 16 BITS
4892	030536	013721	002344			CB1CSR		: WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
4893	030542	104475				MOV	TSTDAT+2,(R1)	: WRITE HIGH WORD
4894	030544	013711	002346			CLR1CSR		: CLEAR 1 SELECTED MK11 CSR
4895	030550	104503				SUB	#2,R1	: ADJUST TEST ADDRESS
4896	030552	162701	000002			TST	(R1)	: READ THE LOCATION
4897	030556	005711				WAS1DBE		: WAS THERE ANY DOUBLE BIT ERRORS ON 1 SELECTED CSR
4898	030560	104501				BCS	9\$: IT SHOULD BE SET
4899	030562	103411				SET	HEADER	
4900	030564							
	030564	012737	177777	002724				MOV #1,HEADER
4901	030572	010137	002040			MOV	R1,ADDRESS	
4902	030576	104030				ERROR	+30	
4903	030600					SET	HEADER	
	030600	012737	177777	002724				MC #1,HEADER

```

4906 030606 005737 002356      9$:  TST    DBEMSK+2      ;CHECK MASK FOR LAST BIT
4907 030612 100405                BMI    10$           ;MINUS = BIT31
4908 030614                DLEFT  DBEMSK
      030614 006137 002354        ROL    DBEMSK
      030620 006137 002356        ROL    DBEMSK+2
      .DSABL CRF
4909 030624 000670                BR     4$
4910 030626                10$:  IF #SW11 SET.IN @SWR THEN GOTO 11$
      030626 032777 004000 152132
      030634 001013
4911 030636                IF QVFLAG IS TRUE THEN GOTO 11$
      030636 005737 002440
      030642 001010
4912 030644 005737 002352        TST    SBEMSK+2      ;CHECK SINGLE ERROR MASK TOO
4913 030650 100405                BMI    11$           ;BR IF DONE
4914 030652                DLEFT  SBEMSK
      030652 006137 002350        ROL    SBEMSK
      030656 006137 002352        ROL    SBEMSK+2
      .DSABL CRF
4915 030662 000644                BR     3$
4916 030664 105737 002362        11$:  TSTB   PASFLG ;FIRST PASS
4917 030670 001003                BNE    12$           ;NON ZERO MEANS WE'RE DONE
4918 030672 105237 002362        INCB   PASFLG ;FIRST PASS, NOT DONE
4919                                ;CLEAR OUT ANY DBE'S OR SBE'S
4920 030676 000625                BR     1$           ;KEEP GOING
4921 030700 104471                12$:  ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
4922 030702 013701 002506        MOV    TESTADD,R1
4923 030706                CLEAR  (R1)+,(R1)
      030706 005021
      030710 005011
4924 030712 104503                CLR    (R1)+
4925 030714 000207                CLR    (R1)
      CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
      RETURN

```

4929 030716

MTP014: SUBST <<MTP014 WRITE INHIBIT DURING DATIP WITH DBE TEST>>

:SUBTEST MTP014 WRITE INHIBIT DURING DATIP WITH DBE TEST

:THIS TEST CHECKS THE WRITE INHIBIT ON DOUBLE
:BIT ERRORS DURING A DATIP OPERATION BY USE
:OF AN 'ASRB' INSTRUCTION.

:NOTE: THIS IS ONLY A USEFULL TEST ON PDP11/70 WITH THE MULTIPORT ECO
:IE THOSE THAT DO A DATIP ON THE ASRB (LOCK) INSTRUCTION.

4930
4931
4932
4933
4934
4935
4936
4937
4938
4939
4940
4941
4942
4943
4944
4945
4946
4947
4948
4949
4950
4951
4952
4953
4954
4955
4956
4957
4958
4959
4960
4961
4962
4963
4964
4965
4966
4967
4968
4969
4970
4971
4972
4973
4974
4975
4976
4977
4978
4979
4980
4981
4982

030716 005037 002340
030722 005037 002342
030726 012737 000001 002350
030734 005037 002352
030740 012737 000001 002354
030746 005037 002356
030752 013737 002340 002344
030760 013737 002342 002346
030766 105737 002362
030772 001404
030774 005137 002344
031000 005137 002346
031004 104503
031006 023737 002354 002350
031014 001004
031016 023737 002356 002352
031024 001466
031026 012737 002344 002402
031034 004737 040540
031040 013701 002350
031044 074137 002344
031050 013701 002352
031054 074137 002346
031060 013701 002354
031064 074137 002344
031070 013701 002356
031074 074137 002346
031100 013701 002506
031104 104471
031106 013721 002344
031112 104475
031114 013711 002346
031120 105037 002363
031124 013703 002506
031130 104503
031132 106223
031134 014100
031136 023700 002344
031142 001401
031144 104455
031146 062701 000002
031152 011100
031154 023700 002346
031160 001401
031162 104455

1\$:
2\$:
3\$:
4\$:
5\$:
6\$:
7\$:
8\$:
9\$:

CLR DATBUF ;INITIAL DATA
CLR DATBUF+2 ;2 WORDS WORTH
MOV #1,SBEMSK ;INITIAL ERROR MASK
CLR SBEMSK+2 ;
MOV #1,DBEMSK ;DOUBLE ERROR MASK
CLR DBEMSK+2 ;2 WORDS
MOV DATBUF,TSTDAT ;PRESERVE ORIG DATA
MOV DATBUF+2,TSTDAT+2
TSTB PASFLG ;SECOND PASS YET ?
BEQ 5\$;BR IF NO
COM TSTDAT ;COMPL DATA ON SECOND PASS
COM TSTDAT+2
5\$: CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
CMP DBEMSK,SBEMSK ;CHECK FOR SAME MASKS
BNE 6\$;BR IF OK
CMP DBEMSK+2,SBEMSK+2
BEQ 11\$;BR IF THEY'RE EQUAL
6\$: MOV #TSTDAT,SOURCE ;SET UP ADDRESS FOR CHKGEN
CALL CHKGEN ;GENERATE CHECK BITS
MOV SBEMSK,R1
XOR R1,TSTDAT
MOV SBEMSK+2,R1
XOR R1,TSTDAT+2
MOV DBEMSK,R1
XOR R1,TSTDAT
MOV DBEMSK+2,R1
XOR R1,TSTDAT+2
7\$: MOV TESTADD,R1 ;TEST ADDRESS
ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
MOV TSTDAT,(R1)+ ;WRITE FIRST 16 BITS
CB1CSR ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
MOV TSTDAT+2,(R1) ;SECOND 16 BITS+CHECKBITS
CLRB UPPFLG ;INDICATE LOWER WORD
MOV TESTADD,R3 ;TEST ADDRESS
8\$: CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
ASRB (R3)+ ;SPECIAL DATIP INSTRUCTION
MOV -(R1),R0
CMP TSTDAT,R0 ;CHECK FOR UNCHANGED DATA
BEQ 9\$;SHOULD BE UNCHANGED
PERR31
9\$: ADD #2,R1 ;POINT TO UPPER WORD
MOV (R1),R0
CMP TSTDAT+2,R0 ;READ IT
BEQ 10\$;BR IF UNCHANGED
PERR31

```

4983 031164 127737 000003 002363 10$: CMPB #3,UPPFLG ;LOWER WORD
4984 031172 001403 BEQ 11$ ;BR IF NO
4985 031174 105237 002363 INCB UPPFLG
4986 031200 000753 BR 8$
4987 031202 005737 002356 11$: TST DBEMSK+2 ;LAST BIT IN MASK ?
4988 031206 100405 BMI 12$ ;BR IF BIT 31
4989 031210 DLEFT DBEMSK
031210 006137 002354 ROL DBEMSK
031214 006137 002356 ROL DBEMSK+2
.DSABL CRF
BR 4$
4990 031220 000654
4991 031222 151536 12$: IF #SW11 SET.IN @SWR THEN GOTO 13$
031222 032777 004000 BIT #SW11,@SWR
031230 001013 BNE 13$
4992 031232 IF QVFLAG IS TRUE THEN GOTO 13$
031232 005737 002440 TST QVFLAG
031236 001010 BNE 13$
4993 031240 005737 002352 TST SBEMSK+2 ;LAST BIT IN SINGLE ERROR MASK ?
4994 031244 100405 BMI 13$ ;BR IF YES
4995 031246 DLEFT SBEMSK
031246 006137 002350 ROL SBEMSK
031252 006137 002352 ROL SBEMSK+2
.DSABL CRF
BR 3$
4996 031256 000630
4997 031260 105737 002362 13$: TSTB PASFLG ;WHICH PASS
4998 031264 001003 BNE 14$ ;BR IF WE'RE DONE
4999 031266 105237 002362 INCB PASFLG ;INDICATE SECOND PASS COMING
5000 ;CLEAR OUT ANY DBE'S OR SBE'S
5001 031272 000611 BR 1$ ;GO DO IT!
5002 031274 104471 14$: ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
5003 031276 013701 002506 MOV TESTADD,R1
5004 031302 CLEAR (R1)+,(R1)
031302 005021 CLR (R1)+
031304 005011 CLR (R1)
5005 031306 104503 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
5006 031310 000207 RETURN

```

```

5010 031312          MTP015: SUBST <<MTP015          WRITE INHIBIT OF BYTE WITH DBE>>
:*****
:*SUBTEST          MTP015 WRITE INHIBIT OF BYTE WITH DBE
:*****
5011                :CHECK FOR WRITE INHIBIT DURING A WRITE BYTE.
5012                :CHECKS FOR UNCORRECTED DATA.
5013 031312 005037 002340 1$: CLR DATBUF ;INITIAL DATA
5014 031316 005037 002342 CLR DATBUF+2 ;32 BITS WORTH
5015 031322 012737 000001 002350 2$: MOV #1,SBEMSK ;SINGLE ERROR MASK
5016 031330 005037 002352 CLR SBEMSK+2 ;
5017 031334 012737 000001 002354 3$: MOV #1,DBEMSK ;DOUBLE ERROR MASK
5018 031342 005037 002356 CLR DBEMSK+2 ;
5019 031346 013737 002340 002344 4$: MOV DATBUF,TSTDAT ;PRESERVE ORIG DATA
5020 031354 013737 002342 002346 MOV DATBUF+2,TSTDAT+2
5021 031362 105737 002362 TSTB PASFLG ;WHICH PASS ?
5022 031366 001404 BEQ 5$ ;FIRST PASS, NO COMPLEMENTING
5023 031370 005137 002344 COM TSTDAT
5024 031374 005137 002346 COM TSTDAT+2 ;SECOND PASS, COMPLEMENT TSTDAT
5025 031400 104503 5$: CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
5026 031402 023737 002350 002354 CMP SBEMSK,DBEMSK ;CHECK FOR SAME MASKS
5027 031410 001004 BNE 6$ ;BR IF NOT EQUAL
5028 031412 023737 002352 002356 CMP SBEMSK+2,DBEMSK+2 ;SECOND WORD ALSO
5029 031420 001463 BEQ 11$ ;BR TO MAKE THEM NOT EQUAL
5030 031422 012737 002344 002402 6$: MOV #TSTDAT,SOURCE ;ADDRESS FOR CHKGEN
5031 031430 004737 040540 CALL CHKGEN ;GO GENERATE CHECK BITS
5032 031434 013701 002350 MOV SBEMSK,R1
5033 031440 074137 002344 XOR R1,TSTDAT
5034 031444 013701 002352 MOV SBEMSK+2,R1
5035 031450 074137 002346 XOR R1,TSTDAT+2
5036 031454 013701 002354 MOV DBEMSK,R1
5037 031460 074137 002344 XOR R1,TSTDAT
5038 031464 013701 002356 MOV DBEMSK+2,R1
5039 031470 074137 002346 XOR R1,TSTDAT+2
5040 031474 013701 002506 7$: MOV TESTADD,R1 ;TEST LOCATION
5041 031500 104471 ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
5042 031502 013721 002344 MOV TSTDAT,(R1)+ ;WRITE FIRST 16 BITS
5043 ;LOAD CSR WITH IMAGE FROM R2
5044 031506 104475 CB1CSR ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
5045 031510 013711 002346 MOV TSTDAT+2,(R1) ;WRITE SECOND 16 BITS + CHECKBITS
5046 031514 104503 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
5047 031516 013702 002506 MOV TESTADD,R2 ;GET ADDRESS OF TEST LOC
5048 031522 010203 MOV R2,R3 ;R2 DESIGNATES FIRST BYTE
5049 031524 062703 ADD #3,R3 ;R3 DESIGNATES LAST BYTE
5050 031530 112722 000360 8$: MOVB #360,(R2)+ ;TRY WRITING A BYTE
5051 031534 013701 002506 MOV TESTADD,R1
5052 031540 012100 MOV (R1)+,R0
5053 031542 023700 002344 CMP TSTDAT,R0 ;CHECK FOR UNCHANGED DATA
5054 031546 001401 BEQ 9$ ;BR IF OK
5055 031550 104455 PERR31
5056
5057 031552 011100 9$: MOV (R1),R0
5058 031554 023700 002346 CMP TSTDAT+2,R0 ;READ SECOND WORD
5059 031560 001401 BEQ 10$ ;BR IF UNCHANGED
5060 031562 104455 PERR31
5061
5062 031564 020203 10$: CMP R2,R3 ;TESTED LAST BYTE ?
5063 031566 001360 BNE 8$ ;BR IF NO

```



```

5064 031570 005737 002356      11$:  TST      DBEMSK+2      ;CHECKING FOR LAST ERROR BIT
5065 031574 100405                BMI      12$           ;BR IF DONE HERE
5066 031576 006137 002354      DLEFT   DBEMSK
      031576 006137 002354      ROL     DBEMSK
      031602 006137 002356      ROL     DBEMSK+2
      .DSABL CRF
5067 031606 000657                BR      4$
5068 031610 032777 004000 151150    12$:  IF #SW11 SET.IN @SWR THEN GOTO 13$
      031616 001013                BIT #SW11,@SWR
      031620 005737 002440                BNE 13$
      031624 001010                IF QVFLAG IS TRUE THEN GOTO 13$
      031626 005737 002352                TST     SBEMSK+2      ;LAST SBE MASK
5070 031632 100405                BMI     13$           ;BR IF DONE WITH THIS PASS
5071 031634 006137 002350      DLEFT   SBEMSK
5072 031634 006137 002352      ROL     SBEMSK
      031640 006137 002352      ROL     SBEMSK+2
      .DSABL CRF
5073 031644 000633                BR      3$
5074 031646 105737 002362      13$:  TSTB     PASFLG      ;TEST PASS FLAG
5075 031652 001003                BNE     14$           ;NON ZERO MEANS WE'RE DONE
5076 031654 105237 002362      INCB    PASFLG      ;NOT DONR
5077 031660 000614                BR      1$
5078 031662 104471                14$:  ECC1DIS  ;DISABLE ECC ON 1 SELECTED CSR
5079 031664 013701 002506      MOV     TESTADD,R1   ;TEST LOCATION
5080 031670 005021                CLEAR   (R1)+,(R1)   ;TO ERASE ANY DBE'S FROM TESTING
      031672 005011                CLR    (R1)+
      031672 005011                CLR    (R1)
5081                ;RESTORE CSR
5082 031674 104503                CLR1CSR
5083 031676 000207                RETURN                ;CLEAR 1 SELECTED MK11 CSR

```

```

5087 031700          MTP016: SUBTST <<MTP016      WRITE INHIBIT OF WORD WITH DBE>>
:*****
:*SUBTEST          MTP016 WRITE INHIBIT OF WORD WITH DBE
:*****
5088                :DOUBLE BIT ERROR WRITE CANCEL WITH
5089                :WORD WRITE.
5090                :CHECKS WRITE INHIBIT WITH WORD WRITES TO
5091                :WORD WITH DOUBLE ERROR.
5092 031700 005037 002340          T12A: CLR   DATBUF          ;BACKGROUND FOR DOUBLE ERRORS
5093 031704 005037 002342          CLR   DATBUF+2        ;2 WORDS WORTH
5094 031710 012737 000001 002350  MOV   #1,SBEMSK      ;SINGLE ERROR MASK
5095 031716 005037 002352          CLR   SBEMSK+2        ;
5096 031722 012737 000001 002354  T12B: MOV   #1,DBEMSK      ;DOUBLE ERROR MASK
5097 031730 005037 002356          CLR   DBEMSK+2        ;
5098 031734 013737 002340 002344  1$:  MOV   DATBUF,TSTDAT  ;DATA FOR TEST
5099 031742 013737 002342 002346  MOV   DATBUF+2,TSTDAT+2;BOTH WORDS
5100 031750 105737 002362          TSTB  PASFLG ;COMP DATA ON SECOND PASS ONLY
5101 031754 001404          BEQ   2$             ;BR IF FIRST PASS
5102 031756 005137 002344          COM   TSTDAT         ;COMP FIRST WORD
5103 031762 005137 002346          COM   TSTDAT+2       ;NOW SECOND WORD
5104 031766 023737 002350 002354  2$:  CMP   SBEMSK,DBEMSK  ;CHECK FOR IDENTICAL MASKS
5105 031774 001004          BNE   3$             ;BR IF DIFFERENT
5106 031776 023737 002352 002356  CMP   SBEMSK+2,DBEMSK+2;UPPER WORD TOO
5107 032004 001470          BEQ   8$             ;BR TO MAKE THEM NOT EQUAL
5108 032006 012737 002344 002402  3$:  MOV   #TSTDAT,SOURCE ;NEED ADDR OF DATA FOR CHKGEN
5109 032014 004737 040540          CALL  CHKGEN         ;GO GENERATE CHECK BITS
5110 032020 013701 002350          MOV   SBEMSK,R1
5111 032024 074137 002344          XOR   R1,TSTDAT
5112 032030 013701 002352          MOV   SBEMSK+2,R1
5113 032034 074137 002346          XOR   R1,TSTDAT+2
5114 032040 013701 002354          MOV   DBEMSK,R1
5115 032044 074137 002344          XOR   R1,TSTDAT
5116 032050 013701 002356          MOV   DBEMSK+2,R1
5117 032054 074137 002346          XOR   R1,TSTDAT+2
5118 032060 013701 002506          4$:  MOV   TESTADD,R1    ;FIRST TEST ADDRESS
5119 032064 104471          ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
5120 032066 013721 002344          MOV   TSTDAT,(R1)+  ;WRITE FIRST 16 BITS
5121 032072 104475          CB1CSR ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
5122 032074 013711 002346          MOV   TSTDAT+2,(R1) ;WRITE SECOND 16 BITS + CHECKBITS
5123 032100 105037 002363          CLR#  UPFLG         ;SET FOR 2 LOOPS
5124 032104 162701 000002          SUB   #2,R1         ;POINT TO LOW WORD
5125 032110 104503          5$:  CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
5126 032112 012711 177400          MOV   #177400,(R1) ;TRY WRITING LOCATION
5127 032116 013701 002506          MOV   TESTADD,R1
5128 032122 011100          MOV   (R1),R0
5129 032124 023700 002344          CMP   TSTDAT,R0    ;CHECK FOR ORIGINAL DATA
5130 032130 001401          BEQ   6$             ;SHOULD BE UNCHANGED
5131 032132 104455          PERR31
5132
5133 032134 062701 000002          6$:  ADD   #2,R1
5134 032140 011100          MOV   (R1),R0
5135 032142 023700 002346          CMP   TSTDAT+2,R0  ;THIS SHOULD BE UNCHANGED ALSO
5136 032146 001401          BEQ   7$
5137 032150 104455          PERR31

```

```

5140 032152 105737 002363      7$:  TSTB  UPPFLG      ;WHICH LOOP ?
5141 032156 001003              BNE   8$           ;SECOND, BR OUT
5142 032160 105237 002363      INCB  UPPFLG      ;FIRST, KEEP GOING
5143 032164 000751              BR    5$
5144 032166 005737 002356      8$:  TST  DBEMSK+2   ;LAST BIT ?
5145 032172 100405              BMI  9$           ;MINUS = BIT 31
5146 032174              DLEFT DBEMSK
      032174 006137 002354      ROL  DBEMSK
      032200 006137 002356      ROL  DBEMSK+2
      .DSABL CRF
5147 032204 000653              BR   1$
5148 032206              IF #SW11 SET.IN @SWR THEN GOTO 10$
      032206 032777 004000 150552
      032214 001014
5149 032216              IF QVFLAG IS TRUE THEN GOTO 10$
      032216 005737 002440
      032222 001011
5150 032224 005737 002352      TST  SBEMSK+2     ;LAST BIT IN THIS MASK ?
5151 032230 100406              BMI  10$          ;BR IF LAST BIT
5152 032232              DLEFT SBEMSK
      032232 006137 002350      ROL  SBEMSK
      032236 006137 002352      ROL  SBEMSK+2
      .DSABL CRF
      JMP  T12B
5153 032242 000137 031722      10$: TSTB  PASFLG     ;FIRST PASS ?
5154 032246 105737 002362      BNE  11$          ;BR IF SECOND
5155 032252 001004              INCB  PASFLG     ;INDICATE SECOND PASS COMING
5156 032254 105237 002362      JMP  T12A
5157 032260 000137 031700      11$: ECC1DIS      ;DISABLE ECC ON 1 SELECTED CSR
5158 032264 104471              MOV   TESTADD,R1 ;RESTORE TEST ADDRESS
5159 032266 013701 002506      CLR  (R1)+       ;CLEAR ANY DBE'S FROM TEST
5160 032272 005021              CLR  (R1)
5161 032274 0050*1              CLR1CSR          ;CLEAR 1 SELECTED MK11 CSR
5162 032276 104503
5163 032300 000207      RETURN

```

```

BIT #SW11,@SWR
BNE 10$

TST QVFLAG
BNE 10$

```

5167 032302

MTP017: SUBTST <<MTP017 HOLDING 1'S & 0'S TEST>>
:*****
:*SUBTEST MTP017 HOLDING 1'S & 0'S TEST
:*****

5168
5169
5170
5171
5172
5173
5174 032302 012701 060000
5175 032306 010104
5176 032310 012705 160000
5177 032314 012700 000377
5178 032320 010003
5179 032322 000303
5180 032324 110021
5181 032326 110321
5182 032330 020105
5183 032332 103774
5184
5185 032334 014*02
5186 032336 020002
5187
5188 032340 001401
5189 032342 104446
5190
5191 032344 020104
5192 032346 101372
5193 032350 000303
5194 032352 00030C
5195 032354 001763
5196
5197 032356 000207

```

:*(1) THIS TEST CHECKS THE MEMORY FOR THE CAPABILITY
:* OF HOLDING 1'S AND 0'S BY WRITING A BACKGROUND
:* OF 000377 AND READING IT
:*(2) MEMORY IS WRITTEN USING A BYTE AT A TIME
:*(3) STEPS 1 & 2 ARE REPEATED WITH A SWAPPED BACKGROUND PATTERN
;NOTE: THIS TEST WRITES BYTES & READS WORDS
MOV #FIRST,R1
MOV R1,R4
MOV #LAST+2,R5
MOV #377,R0 ;GET THE PATTERN INTO R0
MOV R0,R3
SWAB R3
1$: MOVB R0,(R1)+ ;WRITE A BYTE
MOVB R3,(R1)+ ;WRITE THE MEMORY WITH THE BYTE STORED IN BAKPAT
CMP R1,R5 ;COMPARE TEST LOC TO TOP + 2
BLO 1$ ;BRANCH IF LOWER

2$: MOV -(R1),R2
CMP R0,R2 ;TEST THE MEMORY TO SEE IF IT CONTAINS
;THE WORD STORED IN BAKPAT

BEQ 3$
PERR22

3$: CMP R1,R4 ;KEEP ON TESTING THE MEMORY UNTIL
BHI 2$ ;R1 EQUALS THE LOWEST ADDRESS
SWAB R3 ;CHANGE THE DATA PATTERN
SWAB R0
BEQ 1$ ;IF THE DATA PATTERN DOES NOT HAVE LOW
;BYTE -0 THEN FALL THRU

RETURN

```

5201 032360
5202
5203
5204
5205
5206 032360 010311
5207 032362 010461 000002
5208 032366 060201
5209 032370 020105
5210 032372 103772
5211 032374 000207
5212
5213
5214 032376 160201
5215 032400 020461 000002
5216 032404 001002
5217 032406 005711
5218 032410 001401
5219 032412 104452
5220 032414 010361 000002
5221 032420 010311
5222 032422 020100
5223 032424 001364
5224 032426 000207
5225
5226
5227 032430 005711
5228 032432 001003
5229 032434 005761 000002
5230 032440 001401
5231 032442 104453
5232 032444 010311
5233 032446 010461 000002
5234 032452 060201
5235 032454 020105
5236 032456 103764
5237 032460 000207
5238
5239
5240 032462 005711
5241 032464 001003
5242 032466 020461 000002
5243 032472 001401
5244 032474 104452
5245 032476 010311
5246 032500 010361 000002
5247 032504 060201
5248 032506 020105
5249 032510 103764
5250 032512 000207

```

MTP020: SUBTST <<MTP020      MARCHING 1'S & 0'S IN CHECK BITS TEST>>
:*****
:*SUBTEST      MTP020  MARCHING 1'S & 0'S IN CHECK BITS TEST
:*****
: *THIS TEST IS CONCERNED ONLY WITH THE INTEGRITY
: *OF THE MOS RAMS THAT STORE THE CHECKBITS.

:WRITE UP      :100 --> CHECKBITS
MTP20A: MOV     R3,(R1)      :V177640
        MOV     R4,2(R1)    :V177642
        ADD     R2,R1       :V177646
        CMP     R1,R5       :V177650      ;TOP + 2 ?
        BLO    MTP20A      :V177652      ;BR IF NOT
        RETURN              :V177654

:100 --> 077 DOWN
MTP20B: SUB     R2,R1       :V177640
        CMP     R4,2(R1)    :V177642      ;2ND WORD OK?
        BNE    21$         :V177646      ;NO - SKIP
        TST    (R1)        :V177650      ;1ST WORD OK?
        BEQ    3$          :V177652      ;YES - SKIP
21$:   PERR26              :V177654      ;GOOD=000000,,100000,,100
3$:   MOV     R3,2(R1)     :V177656
        MOV     R3,(R1)     :V177662
        CMP     R1,R0       :V177664
        BNE    MTP20B      :V177666
        RETURN              :V177670

:077 --> 100 UP
MTP20C: TST     (R1)       :V177640      ;1ST WORD OK?
        BNE    41$         :V177642      ;NO - SKIP
        TST    2(R1)       :V177644      ;2ND WORD OK?
        BEQ    5$          :V177650      ;YES - SKIP
41$:   PERR27              :V177652      ;GOOD=000000,,000000,,077
5$:   MOV     R3,(R1)     :V177654      ;WRITE 1ST WORD
        MOV     R4,2(R1)    :V177656      ;WRITE 2ND WORD
        ADD     R2,R1       :V177662
        CMP     R1,R5       :V177664      ;TOP + 2 YET?
        BLO    MTP20C      :V177666      ;NO - LOOP
        RETURN              :V177670

:100 --> 077 UP
MTP20D: TST     (R1)       :V177640      ;1ST WORD OK?
        BNE    61$         :V177642      ;NO - SKIP
        CMP     R4,2(R1)    :V177644      ;2ND WORD OK?
        BEQ    7$          :V177650      ;YES - SKIP
61$:   PERR26              :V177652
7$:   MOV     R3,(R1)     :V177654
        MOV     R3,2(R1)    :V177656
        ADD     R2,R1       :V177662
        CMP     R1,R5       :V177664      ;TOP + 2 YET?
        BLO    MTP20D      :V177666      ;NO - LOOP
        RETURN              :V177670
    
```

5253								
5254	032514	160201		MTP20E:	:077 --> 100 DOWN			
5255	032516	005761	000002		SUB R2,R1	:V177640		
5256	032522	001002			TST 2(R1)	:V177642	:2ND WORD OK?	
5257	032524	005711			BNE 81\$:V177646	:NO - SKIP	
5258	032526	001401			TST (R1)	:V177650	:1ST WORD OK?	
5259	032530	104453		81\$:	BEQ 9\$:V177652	:YES - SKIP	
5260	032532	010461	000002	9\$:	PERR27	:V177654		
5261	032536	010311			MOV R4,2(R1)	:V177656	:WRITE 2ND WORD	
5262	032540	020100			MOV R3,(R1)	:V177662	:WRITE 1ST WORD	
5263	032542	001364			CMP R1,R0	:V177664	:BOTTOM YET?	
5264	032544	000207			BNE MTP20E	:V177666	:NO - LOOP	
5265					RETURN	:V177670		
5266								
5267	032546	005711		MTP20F:	:100 UP			
5268	032550	001003			TST (R1)	:V177640	:1ST WORD OK?	
5269	032552	020461	000002		BNE 101\$:V177642	:NO - SKIP	
5270	032556	001401			CMP R4,2(R1)	:V177642	:2ND WORD OK?	
5271	032560	104452			BEQ 11\$:V177646	:YES - SKIP	
5272	032562	060201		101\$:	PERR26	:V177650		
5273	032564	020105		11\$:	ADD R2,R1	:V177652		
5274	032566	103767			CMP R1,R5	:V177654	:TOP + 2 YET?	
5275	032570	000207			BLO MTP20F	:V177656	:NO - LOOP	
					RETURN	:V177660		

5279 032572

MTPA20: SUBST <<MTPA20 SLOW MARCHING 1'S & 0'S IN CHECK BITS TEST>>
:.....
: *SUBTEST MTPA20 SLOW MARCHING 1'S & 0'S IN CHECK BITS TEST
:.....

5280
5281
5282 032572 012737 177777 002022

: *THIS TEST IS CONCERNED ONLY WITH THE INTEGRITY
: *OF THE MOS RAMS THAT STORE THE CHECKBITS.
SET SBFLAG
MOV #-1,SBFLAG

5283 032600 013737 002144 002150
5284 032606 013737 002146 002152

MOV CSR,SBECR
MOV CSR+2,SBECR+2
MOV CSRFIRST,R1 ;FIRST TEST LOC

5285 032614 013701 002336
5286 032620 013702 002414
5287 032624 010103

MOV CSRINC,R2
MOV R1,R3
CLR R4

5288 032626 005004
5289 032630 012705 160000
5290 032634 005037 002144

MOV #LAST+2,R5
CLR CSR
CHK1DIS ;DISABLE ECC & WRITE CHECKBITS FROM 1 SELECTED CSR

5292
5293
5294 032642 010411

:.....
2\$: MOV R4,(R1) ;WRITE CHECKBITS BY WRITING LOC * WRITE UP
ADD R2,R1 ;POINT TO NEXT WORD * 0'S --> CHK BITS
CMP R1,R5 ;TOP + 2 *
BLO 2\$;BR IF NOT *
:.....

5295 032644 060201
5296 032646 020105
5297 032650 103774

5298
5299
5300

:.....
3\$: SUB R2,R1 ;ADJUST R1 *
TST (R1) ;READ *
READCSR
BIT #77400,@CSR ;SHOULD BE ALL ZEROS *
BEQ 4\$;BR IF OK *
MOV CSR,R0
SWAB R0
BIC #200,R0
PERR11
:.....

5301 032652 160201
5302 032654 005711

5303 032656 104426
5304 032660 032737 077400 002144
5305 032666 001406

5306 032670 013700 002144
5307 032674 000300
5308 032676 042700 000200
5309 032702 104435

:.....
4\$: MOV #77400,@CSR ;MAKE CHECKBITS ALL 1'S *0'S --> 1'S
CHK1DIS ;DSABL ECC & WRITE CHKBITS FROM 1 CSR * DOWN
COM R4 ;COMP THE DATA *
MOV R4,(R1) ;WRITE THE CHECKBITS *
CMP R1,R3 ;BOTTOM YET? *
BNE 3\$;BR IF NO *
:.....

5310
5311 032704 012737 077400 002144
5312 032712 104505

5313 032714 005104
5314 032716 010411
5315 032720 020103
5316 032722 001353

5317
5318
5319 032724 005037 002144
5320 032730 104505

CLR CSR
CHK1DIS ;DISABLE ECC & WRITE CHKBITS FROM 1 SELECTED CSR

```

5323
5324 032732 005711          58:  TST      (R1)          :READ THE LOC AGAIN
5325 032734 104426          READCSR
5326 032736 013700 002144  MOV      @CSR,R0          :GET CSR CONTENTS INTO R0
5327 032742 042700 100377  BIC      #100377,R0       :ONLY WANT BITS 11-5
5328 032746 022700 077400  CMP      #77400,R0        :READ FOR ALL 1'S
5329 032752 001404          BEQ      6$              :BR IF OK
5330 032754 000300          SWAB     R0
5331 032756 042700 000200  BIC      #200,R0
5332 032762 104445          PERR21
5333
5334 032764 005037 002144  68:  CLR      CSR
5335 032770 104505          CHK1DIS :DSABL ECC & WRITE CHKBITS FROM 1 CSR
5336 032772 005104          COM      R4
5337 032774 010411          MOV      R4,(R1)        :ACCESS THE LOC
5338 032776 060201          ADD      R2,R1          :POINT TO NEXT ADDRESS
5339 033000 020105          CMP      R1,R5          :TOP+2 YET?
5340 033002 103753          BLO      5$              :BR IF NOT
5341
5342
5343 033004 010301          MOV      R3,R1
5344
5345
5346 033006 005711          78:  TST      (R1)          :READ
5347 033010 104426          READCSR
5348 033012 032737 077400 002144  BIT      #77400,@CSR      :CHECKBITS SHOULD BE ZERO
5349 033020 001404          BEQ      8$              :BR IF OK
5350 033022 013700 002144  MOV      CSR,R0
5351 033026 000300          SWAB     R0
5352 033030 042700 000200  BIC      #200,R0
5353 033034 104435          PERR11
5354
5355 033036 012737 077400 002144  88:  MOV      #77400,@CSR     :COMP CHECKBITS
5356 033044 104505          CHK1DIS :DSABL ECC & WRITE CHKBITS FROM 1 CSR
5357 033046 005104          COM      R4
5358 033050 010411          MOV      R4,(R1)        :WRITE THE LOC
5359 033052 060201          ADD      R2,R1          :POINT TO NEXT ADDRESS
5360 033054 020105          CMP      R1,R5          :TOP+2 YET?
5361 033056 103753          BLO      7$              :BR IF NOT
5362
5363
5364 033060 005037 002144  CLR      CSR
5365 033064 104505          CHK1DIS :DISABLE ECC & WRITE CHECKBITS FROM 1 SELECTED CSR
  
```

1'S --> 0'S

0'S --> 1'S
 JP


```

5368
5369 033066 160201          9$: SUB R2,R1          :ADJUST R1
5370 033070 005711          TST (R1)          :READ
5371 033072 104426          READCSR
5372 033074 013700 002144  MOV @CSR,R0       :GET CSR CONTENTS
5373 033100 042700 100377  BIC #100377,R0    :ONLY WANT CHECKBITS
5374 033104 022700 077400  CMP #77400,R0     :ALL 1'S?
5375 033110 001404          BEQ 10$          :BR IF OK
5376 033112 000300          SWAB R0
5377 033114 042700 000200  BIC #200,R0
5378 033120 104445          PERR21
5379
5380 033122 005037 002144  10$: CLR CSR
5381 033126 104505          CHK1DIS          :DSABL ECC & WRITE CHKBITS FROM 1 CSR
5382 033130 005104          COM R4           :COMP THE DATA
5383 033132 010411          MOV R4,(R1)      :WRITE THE CHECKBITS
5384 033134 020103          CMP R1,R3        :BOTTOM YET?
5385 033136 001353          BNE 9$           :BR IF NO
5386
5387
5388
5389 033140 005711          11$: TST (R1)          :READ
5390 033142 104426          READCSR
5391 033144 032737 077400 002144  BIT #77400,@CSR   :SHOULD BE ALL 0'S
5392 033152 001406          BEQ 12$          :BR IF OK
5393 033154 013700 002144  MOV CSR,R0
5394 033160 000300          SWAB R0
5395 033162 042700 000200  BIC #200,R0
5396 033166 104435          PERR11
5397
5398 033170 060201          12$: ADD R2,R1          :POINT TO NEXT WORD
5399 033172 005037 002144  CLR CSR
5400 033176 104505          CHK1DIS          :DSABL ECC & WRITE CHKBITS FROM 1 CSR
5401 033200 020105          CMP R1,R5        :TOP + 2 YET?
5402 033202 103756          BLO 11$          :BR IF NOT
5403
5404
5405
5406 033204          :FLUSH OUT ALL THESE DBE'S
033204 004537 043710  BMOV MTP030
033210 034704          JSR R5,BLOCK1
          MTP030
          .DSABL CRF

5407 033212 012700 060000  MOV #FIRST,PO
5408 033216 012701 040000  MOV #SIZE,R1
5409 033222 104471          ECC1DIS
5410 033224 004737 177640  CALL FASTCITY    :DISABLE ECC ON 1 SELECTED CSR
5411 033230 104503          CLR1CSR          :CALL TO THE USER INSTRUCTION PAR'S
5412 033232 000207          RETJRN          :CLEAR 1 SELECTED #K11 CSR

```

*1'S -> 0'S
*DOWN

*0'S
*UP

5416 033234

MTPA21: SUBST <<MTPA21 MARCHING 1'S & 0'S PATTERN TEST>>
:*****
:SUBTEST MTPA21 MARCHING 1'S & 0'S PATTERN TEST
:*****

5417
5418 033234 014100
5419 033236 020200
5420 033240 001401
5421 033242 104443
5422
5423 033244 000311
5424 033246 011100
5425 033250 020300
5426 033252 001401
5427 033254 104444
5428
5429 033256 020401
5430 033260 001365
5431 033262 000207
5432

:READ,BYTESWAP-MODIFY,READ,DOWN
1\$: MOV -(R1),R0 :V177640
CMP R2,R0 :V177642
BEQ 2\$:V177644
PERR17 :V177646
2\$: SWAB (R1) :V177650
MOV (R1),R0 :V177652
CMP R3,R0 :V177654
BEQ 3\$:V177656
PERR20 :V177660
3\$: CMP R4,R1 :V177662 :DONE?
BNE 1\$:V177664 :NO - LOOP
RETURN :V177666 :YES - RETURN

5433 033264
5434 033264 011100
5435 033266 020300
5436 033270 001401
5437 033272 104444
5438
5439 033274 000311
5440 033276 011100
5441 033300 020200
5442 033302 001401
5443 033304 104443
5444
5445 033306 062701 000002
5446 033312 020501
5447 033314 001363
5448 033316 000207
5449

MTPB21: :READ,BYTESWAP-MODIFY,READ,UP
1\$: MOV (R1),R0 :V177640
CMP R3,R0 :V177642
BEQ 2\$:V177644
PERR20 :V177646
2\$: SWAB (R1) :V177650
MOV (R1),R0 :V177652
CMP R2,R0 :V177654
BEQ 3\$:V177656
PERR17 :V177660
3\$: ADD #2,R1 :V177662
CMP R5,R1 :V177666 :DONE?
BNE 1\$:V177670 :NO - LOOP
RETURN :V177672 :YES - RETURN

5450 033320
5451 033320 011100
5452 033322 020200
5453 033324 001401
5454 033326 104443
5455
5456 033330 000311
5457 033332 011100
5458 033334 020300
5459 033336 001401
5460 033340 104444
5461
5462 033342 062701 000002
5463 033346 020501
5464 033350 001363
5465 033352 000207

MTPC21: :READ,BYTESWAP-MODIFY,READ,UP
1\$: MOV (R1),R0 :V177640
CMP R2,R0 :V177642
BEQ 2\$:V177644
PERR17 :V177646
2\$: SWAB (R1) :V177650
MOV (R1),R0 :V177652
CMP R3,R0 :V177654
BEQ 3\$:V177656
PERR20 :V177660
3\$: ADD #2,R1 :V177662
CMP R5,R1 :V177666 :DONE?
BNE 1\$:V177670 :NO - LOOP
RETURN :V177672 :YES - RETURN

5468 033354
 5469 033354 014100
 5470 033356 020300
 5471 033360 001401
 5472 033362 104444
 5473
 5474 033364 000311
 5475 033366 011100
 5476 033370 020200
 5477 033372 001401
 5478 033374 104443
 5479
 5480 033376 020401
 5481 033400 001365
 5482 033402 000207
 5483

MTPD21: ;READ,BYTESWAP-MODIFY,READ,DOWN
 1\$: MOV -(R1),R0 ;V177640
 CMP R3,R0 ;V177642
 BEQ 2\$;V177644
 PERR20 ;V177646

 2\$: SWAB (R1) ;V177650
 MOV (R1),R0 ;V177652
 CMP R2,R0 ;V177654
 BEQ 3\$;V177656
 PERR17 ;V177660

 3\$: CMP R4,R1 ;V177662
 BNE 1\$;V177664
 RET JRN ;V177666

;DONE?
 ;NO - LOOP
 ;YES - RETURN

5487 033404

MTP022: SUBST <<MTP022 REFRESH & SHIFTING DIAGONAL TEST>>

 :*SUBTEST MTP022 REFRESH & SHIFTING DIAGONAL TEST

5488 : (1) WE WRITE A DIAGONAL PATTERN IN MEMORY (WITH CACHE ON).
 5489 : (2) IF A REFRESH TEST WE DISTURB ALL ROWS FOR > 2 MS (WITH CACHE ON).
 5490 : (3) WE READ & CHECK FOR CORRECTNESS THE DIAGONAL PATTERN
 5491 : (WITH CACHE OFF).

5492 000010 KD!AG=8. ;HOW OFTEN A DIAGONAL STRIPE OCCURS (MUST BE A POWER OF 2)
 5493 033404 012737 000001 002456 FOR EVEN := #1 TO #2 ;FOR DATA & COMPLEMENT DATA

033412 MOV #1,EVEN
 5494 033412 IF EVEN EQ #1 B43:*****

033420 023727 002456 000001 CMP EVEN,#1
 033422 001005 BNE L367

5495 033422 LET R2 := ZEROS MOV ZEROS,R2
 033422 013702 002430

5496 033426 LET R3 := ONES MOV ONES,R3
 033426 013703 002726

5497 033432 ELSE BR L370
 033432 000404 L367:*****

5498 033434 LET R2 := ONES MOV ONES,R2
 033434 013702 002726

5499 033440 LET R3 := ZEROS MOV ZEROS,R3
 033440 013703 002430

5500 033444 END ;OF IF EVEN L370:*****

5501 033444 FOR STRIPES := #0 TO #KDIAG-1 ;FOR THE NUMBER OF STRIPES
 033444 005037 002460 CLR STRIPES
 033450 B44:*****

5502 :WRITE LOOP
 5503 CACHON ;TURN CACHE ON

5504 033450 104423 LET COUNT := STRIPES MOV STRIPES,COUNT
 5505 033452 013737 002460 002462

5506 033460 LET R1 := #FIRST MOV #FIRST,R1
 033460 012701 060000

5507 033464 WHILE R1 LOS #LAST B45:*****
 033464 020127 157776
 033464 020127 157776
 033464 101032

5508 033472 IF COUNT LT #0 THEN LET COUNT := #KDIAG-1 TST COUNT
 033472 005737 002462 BGE L372
 033476 002003 MOV #KDIAG-1,COUNT

033500 012737 000007 002462 L372:*****
 033506

5509 033506 IF #374 OFF. IN R1 THEN LET COUNT := COUNT - #1 BIT #374,R1
 033506 032701 000374 BNE L373
 033512 001002 DEC COUNT

033514 005337 002462 L373:*****
 033520

5510 033520 IF COUNT NE #0 TST COUNT
 033520 005737 002462 BEQ L374

033524 001404 LET (R1) := R2 MOV R2,(R1)
 5511 033526 010211


```

5525 ;READ LOOP
5526 033570 LET COUNT := STRIPES MOV STRIPES,COUNT
033570 013737 002460 002462
5527 033576 LET R1 := #FIRST MOV #FIRST,R1
033576 012701 060000
5528 033602 CACHOFF ;TURN CACHE OFF
5529 033604 WHILE R1 LOS #LAST
033604
033604 020127 157776 B46:::
033610 101046 CMP R1,#LAST
033612 IF COUNT LT #0 THEN LET COUNT := #KDIAG-1 BHI L377
5530 033612 005737 002462 TST COUNT
033616 002003 BGE L400
033620 012737 000007 002462 MOV #KDIAG-1,COUNT
033626 L400:::
5531 033626 IF #374 OFF.IN R1 THEN LET COUNT :- COUNT - #1
033626 032701 000374 BIT #374,R1
033632 001002 BNE L401
033634 005337 002462 DEC COUNT
033640 L401:::
5532 033640 IF COUNT NE #0
033640 005737 002462 TST COUNT
033644 001412 BEQ L402
5533 033646 LET R0 := (R1) MOV (R1),R0
033646 011100
5534 033650 IF R2 NE R0
033650 020200 CMP R2,R0
033652 001401 BEQ L403
5535 033654 PERR17
5536 033656 END ;OF IF R2
033656 L403:::
5537 033656 LET R0 := 2(R1) MOV 2(R1),R0
033656 016100 000002
5538 033662 IF R2 NE R0
033662 020200 CMP R2,R0
033664 001401 BEQ L404
5539 033666 PERR17
5540 033670 END ;OF IF R2
033670 L404:::
5541 033670 ELSE BR L405
033670 000411 L402:::
033672 LET R0 := (R1) MOV (R1),R0
5542 033672 011100
5543 033674 IF R3 NE R0
033674 020300 CMP R3,R0
033676 001401 BEQ L406
5544 033700 PERR20
5545 033702 END ;OF IF R3
033702 L406:::
5546 033702 LET R0 := 2(R1) MOV 2(R1),R0
033702 016100 000002
5547 033706 IF R3 NE R0
033706 020300 CMP R3,R0
033710 001401 BEQ L407
5548 033712 PERR20
5549 033714 END ;OF IF R3

```

```

5550 033714          END ;OF IF COUNT          L407:.....
5551 033714          LET COUNT := COUNT - #1    L405:.....
5552 033714 005337 062462          DEC COUNT
5553 033720 062701 000004          LET R1 := R1 + #4          ADD #4,R1
5554 033724 000727          END ;OF WHILE          BR B46
5555 033726          ;END OF READ LOOP          L377:.....
5556 033726          END ;OF FOR STRIPES          E46:.....
5557 033726 005237 002460 000007          INC STRIPES
5558 033732 023727 002460 000007          CMP STRIPES,#KDIAG-1
5559 033740 003643          BLE B44          E44:.....
5560 033742          END ;OF FOR EVEN          INC EVEN
5561 033742 005237 002456 000002          CMP EVEN,#2
5562 033746 023727 002456 000002          BLE B43          E43:.....
5563 033754 003616          RETURN
5564 033756 000207          REFRESH:SUBST <<SUBR REFRESH DELAY>>
5565 033760          ;*****
5566 033760          ;*SUBTEST      SUBR      REFRESH DELAY
5567 033760          ;*****
5568 033760          ;DISTURB EACH ROW FOR > 3.2 MS
5569 033760          FOR RO := #FIRST TO #FIRST+374 BY #4
5570 033760 012700 060000          MOV #FIRST,RO          B47:.....
5571 033764 004737 034030          CALL REFSUB
5572 033770 062700 000004          END ;OF FOR RO
5573 033774 020027 060374          ADD #4,RO
5574 034000 003771          CMP RO,#FIRST+374
5575 034002          BLE B47          E47:.....
5576 034002 012700 120000          LET RO := #FIRST+BIT14          MOV #FIRST+BIT14,RO
5577 034006 034006          WHILE RO LOS #LAST+BIT14+374          B50:.....
5578 034006 020027 020372          CMP RO,#LAST+BIT14+374
5579 034012 101005          BHI L410
5580 034014 004737 034030          CALL REFSUB
5581 034020 062700 000004          LET RO := RO + #4          ADD #4,RO
5582 034024 000770          END ;OF WHILE          BR B50
5583 034026          L410:.....
5584 034026          E50:.....
5585 034026 000207          RETURN
5586 034030 012704 000640          REFSUB: MOV #640,R4          ;TIME FOR A > 3.2 MS LOOP
5587 034034 062700 000002          ADD #2,R0
5588 034040 005140          1$: COM -(R0)
5589 034042 005120          COM (R0)+
5590 034044 005110          COM (R0)

```

SUBR REFRESH DELAY

SEQ 0780

5575 034046 005110
5576 034050 077405
5577 034052 162700 000002
5578 034056 000207

COM (R0)
SOB R4.1\$
SUB #2,R0
RETURN

5582 034060

```

MTPA24: SUBST <<MTPA24      FAST GALLOPING PATTERN TEST>>
:*****
:*SUBTEST      MTPA24 FAST GALLOPING PATTERN TEST
:*****

```

5583
5584
5585
5586
5587
5588
5589
5590
5591
5592
5593
5594
5595
5596
5597
5598
5599
5600
5601
5602
5603
5604
5605
5606
5607
5608
5609
5610
5611
5612
5613
5614
5615
5616
5617
5618
5619
5620
5621
5622
5623

034060 011100
034062 020004
034064 001401
034066 104447

034070 011200
034072 020003
034074 001401
034076 104450

034100 062702 000400
034104 020205
034106 101764

034110 062701 000002
034114 000137 172260

```

:THE TOTAL TEST (INCLUDING SETUP) IS AS FOLLOWS
:*(1) THIS TEST WRITES THE MEMORY WITH A BACK GROUND PATTERN
:*      STORED AT LOCATION BAKPAT
:*(2) TEST BEGINS AT LOWEST LOCATION BEING TESTED
:*      (LETS NAME IT 'A')
:*(3) LETS NAME THE 1ST LOCATION IN THE ROW/COLUMN UNDER TEST AS 'B'.
:*(4) SWAPS BYTES FOR LOCATION 'A'.
:*(5) READS 'A', READS 'B'
:*(6) 'B' = 'B'+400 (ADDS 64 DOUBLE WORDS TO 'B')
:*(7) REPEATS STEPS 5 AND 6 UNTIL 'B' IS GREATER THAN THE
:*(8) END OF THE BANK A+2
:*(9) REPEATS STEPS 3-8 UNTILL 'A' REACHES THE END OF THE BANK
:*(10) AFTER EXECUTING THE TEST DATA IS COMPLEMENTED
:*      AND STEPS 1-9 ARE REPEATED
:REGISTERS ARE USED AS FOLLOWS
:R0      TEST DATA
:R1      'A'
:R2      'B'
:R3      BAKPAT
:R4      SWAPAT
:R5      LAST

```

```

:NOTE THE PATTERN STARTS AT MTPB24.
:UIPAR'S
1$:  MOV      (R1),R0      :V177640      :READ 'A'
     CMP      R0,R4      :V177642      :CHECK 'A'
     BEQ      2$         :V177644      :BR IF OK
     PERR23   :V177646      :REPORT ERROR

2$:  MOV      (R2),R0      :V177650      :READ 'B'
     CMP      R0,R3      :V177652      :CHECK 'B'
     BEQ      3$         :V177654      :BR IF OK
     PERR24   :V177656      :REPORT ERROR

3$:  ADD      #400,R2      :V177660      :BUMP 'B'
     CMP      R2,R5      :V177664      :AT END YET?
     BLOS    1$         :V177666      :BR IF NO

     ADD      #2,R1       :V177670      :BUMP 'A'
     JMP     @SDPARO     :V177674      :GOTO V177260

```

5626 034120

MTPB24: SUBST <<MTPB24 FAST GALLOP PART B>>

: *SUBTEST MTPB24 FAST GALLOP PART B

5627

:SDPAR'S

5628 034120 010411
5629 034122 020105
5630 034124 001001
5631 034126 000207
5632 034130 000137 172360
5633
5634 034134

MOV R4,(R1) :V172260 :WRITE 'A'
CMP R1,R5 :V172262 :DONE?
BNE 1\$:V172264 :BR IF NO
RETURN :V172266 :YES - RETURN
1\$: JMP @#KDPAR0 :V172270 :GOTO V172360

MTPC24: SUBST <<MTPC24 FAST GALLOP PART C>>

: *SUBTEST MTPC24 FAST GALLOP PART C

5635

:KDPAR'S

5636 034134 010102
5637 034136 011100
5638 034140 020004
5639 034142 001401
5640 034144 104447
5641 034146 000137 177660

MOV R1,R2 :V172360 :RESET 'B' <--- 'A'
MOV (R1),R0 :V172362 :READ 'A'
CMP R0,R4 :V172364 :CHECK 'A'
BEQ 1\$:V172366 :BR IF OK
PERR23 :V172370 :REPORT ERROR
1\$: JMP @#UDPAR0 :V172372 :GOTO V177660

```

5645 034152          MTP025: SUBTST <<MTP025      INTERRUPT ENABLE TEST>>
:.....
: *SUBTEST          MTP025 INTERRUPT ENABLE TEST
:.....
5646 034152 005037 002344          CLR      TSTDAT          ;GENERATE CHECKBITS ON 0,,0
5647 034156 005037 002346          CLR      TSTDAT+2
5648 034162 012737 002344 002402  MOV      #TSTDAT,SOURCE
5649 034170 004737 040540          CALL     CHKGEN
5650 034174 012737 000003 002100  MOV      #3,NOPAR          ;SETUP PARITY ACTION
5651 034202 013701 002506          MOV      TESTADD,R1      ;FIRST TEST ADDRESS
5652 034206 012737 034242 002372  MOV      #1$,PARTHERE    ;SETUP TRAP DESTINATION
5653 034214 004737 034464          CALL     MTPA25          ;WRITE DATA & CHECKBITS
5654 034220 104473          ECC1INIT          ;INITIALIZE 1 SELECTED MK11 CSR
5655 034222 005711          TST      (R1)          ;ACCESS LOCATIONS FOR DBE TRAPS
5656 034224 005761 0J000?          TST      2(R1)
5657          ;NONE - GOOD - ACCESS FOR SBE TRAPS
5658 034230 104507          ENA1SBE          ;DISABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
5659 034232 005711          TST      (R1)
5660 034234 005761 0G0002          TST      2(R1)
5661 034240 000404          BR       2$          ;NONE - GOOD - SKIP
5662 034242 104426          1$: READCSR
5663 034244          FATAL 27
034244 005237 002070          INC      FATAL$          ;SET FATAL INDICATOR
034250 104027          ERROR +27
          .DSABL CRF
5664 034252 005237 002344          2$: INC      TSTDAT          ;CHECK FOR CORRECT ACTION ON SBE'S
5665 034256 004737 034412          CALL     MTPD25          ;IN ALL 4 BYTES
5666 034262 012737 000400 002344  MOV      #400,TSTDAT
5667 034270 004737 034412          CALL     MTPD25
5668 034274 005037 002344          CLR      TSTDAT
5669 034300 005237 002346          INC      TSTDAT+2
5670 034304 004737 034412          CALL     MTPD25
5671 034310 012737 000400 002346  MOV      #400,TSTDAT+2
5672 034316 004737 034412          CALL     MTPD25
5673
5674 034322 005037 002346          CLR      TSTDAT+2          ;CHECK FOR CORRECT ACTION ON DBE'S
5675 034326 012737 000003 002344  MOV      #3,TSTDAT          ;IN ALL 4 BYTES
5676 034334 004737 034434          CALL     MTPE25
5677 034340 012737 001400 002344  MOV      #1400,TSTDAT
5678 034346 004737 034434          CALL     MTPE25
5679 034352 005037 002344          CLR      TSTDAT
5680 034356 012737 000003 002346  MOV      #3,TSTDAT+2
5681 034364 004737 034434          CALL     MTPE25
5682 034370 012737 001400 002346  MOV      #1400,TSTDAT+2
5683 034376 004737 034434          CALL     MTPE25
5684 034402 104503          CLR1CSR          ;CLEAR 1 SELECTED MK11 CSR
5685 034404 005037 002100          CLR      NOPAR          ;INDICATE PARITY ACTION
5686 034410 000207          RETURN
5687
5688 034412 004737 034464          MTPD25: CALL     MTPA25          ;WRITE DATA & CHECKBITS
5689 034416 104471          ECC1DIS          ;DISABLE ECC ON 1 SELECTED CSR
5690 034420 004737 034504          CALL     MTPB25          ;CHECK FOR NO TRAPS
5691 034424 104507          ENA1SBE          ;DISABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
5692 034426 004737 034536          CALL     MTPC25          ;CHECK FOR EXPECTED TRAP
5693 034432 000207          RETURN

```

MTPG25 INTERRUPT ENABLE TEST

```

5696 034434 004737 034464      MTPG25: CALL      MTPA25      ;WRITE DATA & CHECKBITS
5697 034440 104471              ECCIDIS      ;DISABLE ECC ON 1 SELECTED CSR
5698 034442 004737 034504      CALL      MTPB25      ;CHECK FOR NO TRAPS
5699              ;ENABLE DBE TRAPS
5700 034446 104473              ECCINIT      ;INITIALIZE 1 SELECTED MK11 CSR
5701 034450 004737 034536      CALL      MTPC25      ;CHECK FOR EXPECTED TRAP
5702 034454 104507              ENATSBE      ;DISABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
5703 034456 004737 034536      CALL      MTPC25      ;CHECK FOR EXPECTED TRAP
5704 034462 000207              RETURN
5705
5706              ;WRITE TSTDAT & TSTDAT+2 & CHECKBITS
5707 034464 104471      MTPA25: ECCIDIS      ;DISABLE ECC ON 1 SELECTED CSR
5708 034466 013711 002344      MOV      TSTDAT,(R1) ;WRITE FIRST 16 BITS
5709 034472 104475              CBICSR      ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
5710 034474 013761 002346 000002  MOV      TSTDAT+2,2(R1) ;WRITE 2ND 16 BITS & CHECKBITS
5711 034502 000207              RETURN
5712
5713              ;CHECK FOR NO TRAP OCCURING CONDITION
5714 034504 012737 034522 002372  MTPB25: MOV      #1$,PARTHERE ;SETUP TRAP DESTINATION
5715 034512 005711              TST      (R1)      ;ACCESS LOCATIONS
5716 034514 005761 000002              TST      2(R1)
5717 034520 000207              RETURN      ;NO TRAP - GOOD - RETURN
5718
5719 034522 104426      1$:  READCSR
5720 034524 104024      ERROR      +24
5721 034526              SET      HEADER
5722 034526 012737 177777 002724      MOV      #-1,HEADER
5723 034534 000207              RETURN
5724
5725 034536 012737 034550 002372  MTPC25: ;TRAP SHOULD OCCURE TEST
5726 034544 005711      MOV      #1$,PARTHERE ;SETUP TRAP DESTINATION
5727 034546 000405      TST      (R1)      ;ACCESS 1ST LOCATION
5728 034550 012737 034574 002372  1$:  BR      2$      ;NO TRAP - BAD NEWS - SKIP
5729 034556 005761 000002      MOV      #3$,PARTHERE ;SETUP TRAP DESTINATION
5730 034562 104426      TST      2(R1)      ;ACCESS 2ND LOCATION
5731 034564 104025      2$:  READCSR      ;NO TRAP - BAD NEWS
5732 034566              ERROR      +25
5733 034566 012737 177777 002724      SET      HEADER      MOV      #-1,HEADER
5734 034574 000207      3$:  RETURN

```

5738 034576

```

MTPA26: SUBST <<MTPA26      RANDOM DATA (WRITE)>>
:*****
:*SUBTEST      MTPA26  RANDOM DATA (WRITE)
:*****
1$:  JMP      KDPARO      ;V177640      GOTO V172360
     MOV      R2,(R1)+    ;V177644
     MOV      R3,(R1)+    ;V177646
     SOB      R0,1$       ;V177650
     RETURN     ;V177652

```

5739 034576 000137 172360
5740 034602 010221
5741 034604 010321
5742 034606 077005
5743 034610 000207
5744
5745 034612

```

MTPB26: SUBST <<MTPB26      RANDOM DATA (READ)>>
:*****
:*SUBTEST      MTPB26  RANDOM DATA (READ)
:*****
     .DSABL   AMA
     .ENABL   LSB
1$:  JMP      @MKDPARO    ;V177640      GOTO V172360
     CMP      R2,(R1)+    ;V177644
     BEQ      2$         ;V177646
     PERR25   ;V177650
2$:  COM      (PC)+      ;V177652
     RANODD:  0          ;V177654      FOR ERROR REPORTING
     CMP      R3,(R1)+    ;V177656
     BEQ      3$         ;V177660
     PERR25   ;V177662
3$:  COM      RANODD     ;V177664
     SOB      R0,1$       ;V177670
     RETURN     ;V177672
     .DSABL   LSB
     .ENABL   AMA

```

5746
5747
5748 034612 000137 172360
5749 034616 020221
5750 034620 001401
5751 034622 104451
5752 034624 005127
5753 034626 000000
5754 034630 020321
5755 034632 001401
5756 034634 104451
5757 034636 005167 177764
5758 034642 077015
5759 034644 000207
5760
5761
5762
5763 034646

```

MTPC26: SUBST <<RANDOM NUMBER SUBPROGRAM>>
:*****
:*SUBTEST      RANDOM NUMBER SUBPROGRAM
:*****
     :CALLER MUST SETUP
     :
     :      MOV      SEEDLO,R3
     :      MOV      SEEDHI,R2
     :      MOV      R3,R5
     :      MOV      R2,R4
5769 034646 073427 000007      ASHC      #7,R4      ;V172360
5770 034652 060305              ADD      R3,R5      ;V172364
5771 034654 005504              ADC      R4          ;V172366
5772 034656 060204              ADD      R2,R4      ;V172370
5773 034660 062705 001057      ADD      #1057,R5   ;V172372
5774 034664 000730              BR       -.116      ;V172376      GOTO V172260
5775
5776 034666

```

5764
5765
5766
5767
5768
5769 034646 073427 000007
5770 034652 060305
5771 034654 005504
5772 034656 060204
5773 034660 062705 001057
5774 034664 000730
5775
5776 034666

```

MTPD26: SUBST <<RANDOM NUMBER SUBSUBPROGRAM>>
:*****
:*SUBTEST      RANDOM NUMBER SUBSUBPROGRAM
:*****
     ADC      R4          ;V172260
     ADD      #47401,R4   ;V172262
     MOV      R5,R3      ;V172266
     MOV      R4,R2      ;V172270
     MP       JIPAR2     ;V172272      GOTO V177644

```

5777 034666 005504
5778 034670 062704 047401
5779 034674 010503
5780 034676 010402
5781 034700 000137 177644

5784 034704

MTP030: SUBST <<MTP030 FLUSH OUT DBE'S>>
:*****
:*SUBTEST MTP030 FLUSH OUT DBE'S
:*****

5785 034704 011002
5786 034706 010220
5787 034710 077103
5788 034712 000207
5789
5790 034714

1\$: MOV (R0),R2 :V177640
MOV R2,(R0)+ :V177642
SOB R1,1\$:V177644
RETURN :V177646

MTP031: SUBST <<MTP031 SOB-A-LONG TEST>>
:*****
:*SUBTEST MTP031 SOB-A-LONG TEST
:*****

5791
5792 034714 000000
5793 034716 077001
5794 034720 005167 177772
5795 034724 020167 177766
5796 034730 001403
5797 034732 104454
5798 034734 010167 177756
5799 034740 005167 177752
5800 034744 010200
5801
5802 034746 010503
5803 034750 005725
5804 034752 010504
5805 034754 020527 160000
5806 034760 001001
5807 034762 000207
5808
5809 034764 014344
5810 034766 001376
5811 034770 000752
5812 000056
5813

.DSABL AMA
0
1\$: SOB R0,1\$;MOVE TERMINATOR
COM 1\$;SOB TILL RO UNDERFLOWS
CMP R1,1\$;WRITE COMPLEMENT OF SOB
BEQ 2\$;READ & CHECK FOR NOT 'SOB RO,DOT'
PERR30 ;OK - SKIP
2\$: MOV R1,1\$
COM 1\$;CORRECT SOB INSTRUCTION
MOV R2,R0 ;REINITIALIZE SOB CONSTANT
;UPDATE MOVE REGISTERS
MOV R5,R3
TST (R5)+ ;BUMP (SAFELY) BY 2
MOV R5,R4
CMP R5,#LAST+2 ;DONE?
BNE 3\$;NO - SKIP
RETURN ;YES
3\$: MOV -(R3),-(R4)
BNE 3\$
BR 1\$
SOBLENGTH=-MTP031
.ENABL AMA

MTP031 SOB-A-LONG TEST

5816 034772

```

MTPA32: SUBST <<MTPA32      SKEWED UP ADDRESS TEST (WRITE)>>
:*****
:*SUBTEST      MTPA32 SKEWED UP ADDRESS TEST (WRITE)
:*****
1$:  ADD      #6,R4          ;V177640      ;ADD OFFSET TO OFFSET COUNTER
    BIC      #^C6,R4       ;V177644      ;MASK TO (0,2,4,6)
    MOV      R3,R1         ;V177650      ;PUT IN LSB'S OF ADDRESS
    ADD      R4,R1         ;V177652      ;PUT IN MSB'S OF ADDRESS
    MOV      R0,(R1)       ;V177654      ;WRITE DATA IN R0 INTO MEMORY
    ADD      #10,R3        ;V177656      ;BUMP ADDRESS MSB TO NEXT BLOCK OF 4 WORDS
    SOB      R5,1$        ;V177662      ;LOOP TILL DONE
    RETURN                     ;V177664

```

5817 034772 062704 000006
5818 034776 042704 177771
5819 035002 010301
5820 035004 060401
5821 035006 010011
5822 035010 062703 000010
5823 035014 077512
5824 035016 000207
5825
5826 035020

```

MTPB32: SUBST <<MTPB32      SKEWED UP ADDRESS TEST (READ)>>
:*****
:*SUBTEST      MTPB32 SKEWED UP ADDRESS TEST (READ)
:*****
1$:  ADD      #6,R4          ;V177640      ;ADD OFFSET TO OFFSET COUNTER
    BIC      #^C6,R4       ;V177644      ;MASK TO (0,2,4,6)
    MOV      R3,R1         ;V177650      ;PUT IN LSB'S OF ADDRESS
    ADD      R4,R1         ;V177652      ;PUT IN MSB'S OF ADDRESS
    MOV      (R1),R2       ;V177654      ;READ DATA INTO R0
    CMP      R2,R0         ;V177656      ;IS IT CORRECT?
    BEQ      2$            ;V177660      ;YES - SKIP
    PERR22                     ;V177662      ;NO - PRINT ERROR
2$:  ADD      #10,R3        ;V177664      ;BUMP ADDRESS MSB TO NEXT BLOCK OF 4 WORDS
    SOB      R5,1$        ;V177666      ;LOOP TILL DONE
    RETURN                     ;V177670

```

5827 035020 062704 000006
5828 035024 042704 177771
5829 035030 010301
5830 035032 060401
5831 035034 011102
5832 035036 020200
5833 035040 001401
5834 035042 104446
5835 035044 062703 000010
5836 035050 077515
5837 035052 000207
5838
5839 035054

```

MTP033: SUBST <<MTP033      WRITE RECOVERY TEST>>
:*****
:*SUBTEST      MTP033 WRITE RECOVERY TEST
:*****
:THE TEST ACTUALLY EXECUTED ALREADY IN THE MEMORY UNDER TEST.
:THIS CODE INSURES THAT IT CHANGED MEMORY TO HAVE
:1/2 BANK OF #5141      WHICH IS A 'COM -(R1)' INSTRUCTION AND
:1/2 BANK OF #110      WHICH IS A 'JMP (R0)' INSTRUCTION.
1$:  MOV      (R4)+,R1      ;V177640      ;GET DATA FROM LOWER 1/2 BANK
    CMP      R1,R2         ;V177642      ;IS IT #5141?
    BEQ      2$            ;V177644      ;YES - SKIP
    PERR02                     ;V177646      ;NO - TAKE ERROR TRAP
2$:  SOB      R3,1$        ;V177650      ;LOOP FOR 1/2 BANK
    MOV      #SIZE/2,R3    ;V177652      ;RESTORE LOOP SIZE
3$:  MOV      (R4)+,R0      ;V177656      ;GET DATA FROM UPPER 1/2 BANK
    CMP      R0,R5         ;V177660      ;IS IT #110?
    BEQ      4$            ;V177662      ;YES - SKIP
    PERR01                     ;V177664      ;NO - TAKE ERROR TRAP
4$:  SOB      R3,3$        ;V177666      ;LOOP FOR 1/2 BANK
    RETURN

```

5840
5841
5842
5843
5844
5845 035054 012401
5846 035056 020102
5847 035060 001401
5848 035062 104430
5849 035064 077305
5850 035066 012703 020000
5851 035072 012400
5852 035074 020005
5853 035076 001401
5854 035100 104427
5855 035102 077305
5856 035104 000207

5859 035106

MTP034: SUBST <<MTP034 BRANCH GOBBLE TEST>>

:SUBTEST MTP034 BRANCH GOBBLE TEST

5860
5861 035106 000000
5862 035110 000000
5863 035112 000261
5864 035114 105511
5865 035116 100402
5866 035120 105212
5867 035122 000773

.DSABL AMA
0
BGTEST: 0 ;MOVE TERMINATOR
BRGOBB: SEC ;TEST WORD (TWO BYTES)
ADCB (R1) ;SET CARRY (TO BE ADDED TO 'BGTEST')
BMI 1\$;INCREMENT LOW BYTE OF 'BGTEST'
INCB (R2) ;BRANCH WHEN BIT7 IS SET
BR BRGOBB ;INCREMENT HIGH BYTE OF 'BGTEST'
;LOOP 128 TIMES

5868
5869
5870 035124 102401
5871 035126 104461
5872
5873 035130 000242
5874 035132 105212
5875 035134 103402
5876 035136 102001
5877 035140 100401
5878 035142 104461

;NOW CHECK FOR CORRECT CONDITION CODES
1\$: BVS 2\$;BR IF V-BIT SET (SHOULD BE)
PERR35 ;NO - REPORT ERROR AND ABORT TEST
;COND CODES NOT EQUAL TO 1010
2\$: CLV ;CLEAR V-BIT
INCB (R2) ;INCREMENT HIGH BYTE OF 'BGTEST' ONCE MORE
BCS 3\$;BR IF C-BIT SET (SHOULD NOT BE)
BVC 3\$;BR IF V-BIT CLEAR (SHOULD NOT BE)
BMI 4\$;BR IF N-BIT SET (SHOULD BE)
3\$: PERR35 ;NO - REPORT ERROR AND ABORT TEST
;COND CODES NOT EQUAL TO 1010

5879
5880
5881
5882 035144 010701
5883 035146 162701 000036
5884 035152 010102
5885 035154 005202
5886

;UPDATE TEST POINTERS
4\$: MOV PC,R1
5\$: SUB #5\$-BGTEST,R1
MOV R1,R2
INC R2

5887
5888 035156 010503
5889 035160 005725
5890 035162 010504
5891

;UPDATE MOVE REGISTERS
MOV R5,R3
TST (R5)+ ;BUMP (SAFELY) BY 2
MOV R5,R4

5892
5893 035164 020527 160000
5894 035170 001001
5895 035172 000207
5896

;DONE?
CMP R5,#LAST+2 ;DONE?
BNE 6\$;NO - SKIP
RETURN ;YES - RETURN

5897
5898 035174 014344
5899 035176 001376
5900 035200 005011
5901 035202 000743
5902 000076
5903

;MOVE CODE 1 LOCATION
6\$: MOV -(R3),-(R4)
BNE 6\$
CLR (R1) ;CLEAR TEST WORD 'BGTEST'
BR BRGOBB ;RUN MOVED CODE AGAIN
GBLENGTH-.-MTP034
.ENABL AMA

5905
5906
5907 035204

5908 035204 010004
5909 035206 010103
5910 035210 010205
5911 035212 000207
5912
5913 035214

5914 035214
035214 010046
5915 035216 005237 002734
5916 035222 042737 177774 002734
5917 035230 022737 000001 002734
5918 035236 001414
5919 035240 022737 000002 002734
5920 035246 001413
5921 035250 022737 000003 002734
5922 035256 001414
5923 035260 005000
5924 035262 013704 002726
5925 035266 000414
5926 035270
035270 005000
035272 005004
5927 035274 000411
5928 035276 012700 000401
5929 035302 013704 002726
5930 035306 000404
5931 035310 012700 000401
5932 035314 012704 000401
5933 035320 010037 026522
5934 035324 010037 026536
5935 035330 010037 026562
5936 035334 010037 026576
5937 035340
035340 012600
5938 035342 000207
5939
5940 035344

```

.SBTTL MISC SUBROUTINES
REGCOPY:SUBTST <<SUBR COPY R0 TO R4,R1 TO R3, & R2 TO R5>>
:*****
:*SUBTEST SUBR COPY R0 TO R4,R1 TO R3, & R2 TO R5
:*****
MOV R0,R4
MOV R1,R3
MOV R2,R5
RETURN

FLIPWARN:SUBTST <<FLIP WARNING CONSTANTS IN WORST CASE NOISE TESTS>>
:*****
:*SUBTEST FLIP WARNING CONSTANTS IN WORST CASE NOISE TESTS
:*****
PUSH R0
MOV RO,-(SP)
INC FLIPLOC
BIC #^C3,FLIPLOC
CMP #1,FLIPLOC
BEQ 1$
CMP #2,FLIPLOC
BEQ 2$
CMP #3,FLIPLOC
BEQ 3$
CLR R0
MOV ONES,R4
BR 4$
1$: CLEAR R0,R4
CLR R0
CLR R4
BR 4$
2$: MOV #401,R0
MOV ONES,R4
BR 4$
3$: MOV #401,R0
MOV #401,R4
4$: MOV R0,WARN2
MOV R0,WARN3
MOV R0,WARN4
MOV R0,WARN5
POP R0
MOV (SP)+,R0
RETURN

BACKGND:SUBTST <<SUBR WRITE BACKGROUND>>
:*****
:*SUBTEST SUBR WRITE BACKGROUND
:*****
;WRITES DATA FROM R2
SAVREG
MOV #FIRST,R0
MOV #SIZE,R1
BMOV MTP000
JSR R5,BLOCK1
MTP000
.DSABL CRF

```

5946	035364	012737	000207	177644	WARN6:	MOV	#207,UIPAR2
5947	035372	004737	026042			CALL	SUPD01
5948	035376	104416				RESREG	
5949	035400	000207				RETURN	

;WARNING PUTTING 'RETURN' INSTRUCTION AFTER WRITE

;


```

5978 035556 012701 000550      MOV    #60.,R1
5979 035562 010103      MOV    R1,R3
5980 035564 004737 035664      CALL  TCONFIG
5981 035570 000417      BR    PCONF2
5982
5983 035572 012700 000170      PCONF1: MOV  #120.,R0
5984 035576 010004      MOV    R0,R4
5985 035600      CLEAR  R1,R3
           035600 005001      CLR   R1
           035602 005003      CLR   R3
5986 035604      TYPE  MSG014      ;SPACE
           035604 104401 112132      TYPEIT ,MSG014
           .DSABL CRF
5987 035610      TYPE  MSG011
           035610 104401 111745      TYPEIT ,MSG011
           .DSABL CRF
5988 035614      TYPE  MSG004
           035614 104401 111520      TYPEIT ,MSG004
           .DSABL CRF
5989 035620      TYPE  MSG012
           035620 104401 112033      TYPEIT ,MSG012
           .DSABL CRF
5990 035624 004737 035664      CALL  TCONFIG
5991
5992 035630 013706 035662      PCONF2: MOV  PCONFS,SP      ;RESTORE STACK
5993 035634 042777 000100 145130      BIC   #BIT6,@STKS
5994 035642 117700 145126      MOVB  @STKB,R0      ;READ CHAR TO KILL FLAG
5995 035646      POP   R0,TKVEC+2,TKVEC
           035646 012600      MOV  (SP)+,R0
           035650 012637 000062      MOV  (SP)+,TKVEC+2
           035654 012637 000060      MOV  (SP)+,TKVEC
5996 035660 000207      RETURN
5997
5998 035662 000000      PCONFS: 0      ;STACK SAVED HERE!
    
```

6002 035664

SUBTST <<SUBR TYPE CONFIGURATION>>

```

*****
*SUBTE          SUBR      TYPE CONFIGURATION
*****
:CALL:          MOV      #N,R0          ;N=NUMBER OF CHARACTERS
:               MOV      R0,R4          ;BACKUP
:               MOV      #K,R1          ;INDEX CONSTANT
:               MOV      R1,R3          ;BACKUP
:               CALL     TCONFIG        ;ACTUAL CALL
:               RETURN     ;ONLY RETURN
*****
    
```

6003
6004
6005
6006
6007
6008
6009
6010
6011
6012
6013
6014

```

*****
** ERROR **
*****
    
```

6015 035664 104401 111626
 035664

```

TCONFIG:TYPE      MSG005
TYPEIT      ,MSG005
.DSABL      CRF
1$: BIT      #BIT11,CONFIG(R1)      ;ERROR ON THIS BANK?
        BEQ      2$                  ;NO - SKIP
        TYPE     MSG013
        TYPEIT   ,MSG013
        .DSABL   CRF
        BR       3$
2$: TYPE     MSG014
        TYPEIT   ,MSG014
        .DSABL   CRF
3$: ADD      #6,R1                    ;BUMP POINTER
        SOB      R0,1$                ;LOOP TILL DONE
        MOV      R4,R0
        MOV      R3,R1
    
```

6016 035670 032761 004000 003016
 6017 035676 001403
 6018 035700 104401 112130
 035700
 6019 035704 000402
 6020 035706 104401 112132
 035706
 6021 035712 062701 000006
 6022 035716 077014
 6023 035720 010400
 6024 035722 010301

```

*****
** CPU'S **
*****
    
```

6025
6026
6027
6028
6029 035724 104401 111707
 035724

```

TYPE      MSG008
TYPEIT    ,MSG008
.DSABL    CRF
4$: MOV     CONFIG(R1),R5
        ASH   #-4,R5                ;GET CPU BITS
        BIC   #^C17,R5             ;CLEAR NON INTERESTING BITS
        CMP   #10.,R5
        BPL   8$
        ADD   #67,R5                ;MAKE NUMBERS OVER 9 HEX
        BR    9$
8$: ADD   #60,R5                    ;MAKE ASCII
9$: MOVB   R5,MSG015                ;PLUG INTO MEMORY
        TYPE   MSG015
        TYPEIT ,MSG015
        .DSABL CRF
        ADD   #6,R1                    ;BUMP POINTER
        SOB   R0,4$                  ;LOOP TILL DONE
        MOV   R4,R0
        MOV   R3,R1
    
```

6030 035730 016105 003016
 6031 035734 072527 177774
 6032 035740 042705 177760
 6033 035744 022705 000012
 6034 035750 100003
 6035 035752 062705 000067
 6036 035756 000402
 6037 035760 062705 000060
 6038 035764 110537 112134
 6039 035770 104401 112134
 035770
 6040 035774 062701 000006
 6041 036000 077025
 6042 036002 010400
 6043 036004 010301

```

6046
6047
6048
6049 036006 104401 111675
036006
6050
6051 036012 016105 003016 TCFIG1: MOV CONFIG(R1),R5
6052 036016 072527 177763 ASH #-13,R5 ;GET MEMORY TYPE
6053 036022 042705 177774 BIC #^C3,R5 ;CLEAR NON INTERESTING BITS
6054 036026 005705 TST R5
6055 036030 001004 BNE 1$
6056 036032 112737 000077 112134 MOVB #'?,MSG015
6057 036040 000435 BR 7$
6058 036042 016105 003016 1$: MOV CONFIG(R1),R5
6059 036046 042705 177770 BIC #^C7,R5 ;GET INTERLEAVE BITS
6060 036052 022705 000001 CMP #1,R5
6061 036056 001002 BNE 2$
6062 036060 006305 ASL R5 ;2 TO 1
6063 036062 000420 BR 5$
6064 036064 022705 000002 2$: CMP #2,R5
6065 036070 001002 BNE 3$
6066 036072 006305 ASL R5 ;4 TO 1
6067 036074 000413 BR 5$
6068 036076 022705 000004 3$: CMP #4,R5
6069 036102 001003 BNE 4$
6070 036104 012705 000010 MOV #8.,R5 ;8 TO 1
6071 036110 000405 BR 5$
6072 036112 005705 4$: TST R5
6073 036114 001403 BEQ 5$
6074 036116 012705 000077 MOV #'?,R5
6075 036122 000402 BR 6$
6076 036124 062705 000060 5$: ADD #60,R5 ;MAKE ASCII
6077 036130 110537 112134 6$: MOVB R5,MSG015 ;PLUG INTO MEMORY
6078 036134 036134 104401 112134 7$: TYPE MSG015
TYPEIT ,MSG015
.DSABL CRF
IF NOTAB NE #0 THEN $RETURN
6079 036140
036140 005737 002464
036144 001401
036146 000207
036150
6080 036150 062701 000006 ADD #6,R1 ;BUMP PCINTER
6081 036154 077062 SOB R0,TCFIG1 ;LOOP TILL DONE
6082 036156 010400 MOV R4,R0
6083 036160 010301 MOV R3,R1
6084
6085
6086
6087
6088
6089 036162
036162 104401 111721
ENABL LSB
TYPE MSG009
TYPEIT ,MSG009
.DSABL CRF
6090 036166 016105 003016 8$: MOV CONFIG(R1),R5
6091 036172 072527 177763 ASH #-13.,R5 ;GET MEMORY TYPE
6092 036176 042705 177774 BIC #^C3,R5 ;CLEAR NON INTERESTING BITS

```

TST NOTAB
BEQ L412
RTS PC
L412:.....

```

6093 036202          IF R5 EQ #1
      036202 020527 000001          (MP R5,#1
      036206 001004          BNE L413
6094 036210 112737 000113 112134    MOVB #'K,MSG015
6095 036216          ELSE
      036216 000413          BR L414
      036220          L413:*****
6096 036220          IF #SLAVE3.SLAVE2:SLAVE1.MASTER SET.IN CONFIG(R1)
      036220 032761 000360 003016    BIT #SLAVE3:SLAVE2:SLAVE1:MA
      036226 001404          BEQ L415
6097 036230 112737 000112 112134    MOVB #'J,MSG015
6098 036236          ELSE
      036236 000403          BR L416
      036240          L415:*****
6099 036240 112737 000060 112134    MOVB #'O,MSG015
6100 036246          END :OF IF #SLAVE3:SLAVE2:SLAVE1:MASTER
      036246          L416:*****
6101 036246          END :OF IF R5
      036246          L414:*****
6102 036246          TYPE MSG015
      036246 104401 112134          TYPEIT ,MSG015
      .DSABL CRF
6103 036252 062701 000006          ADD #6,R1          :BUMP POINTER
6104 036256 077035          SOB R0,8$        :LOOP TILL DONE
6105 036260 010400          MOV R4,R0
6106 036262 010301          MOV R3,R1
6107          .DSABL LSB
6108
6109          :*****
6110          **: BOX **
6111          :*****
6112 036264          TYPE MSG016
      036264 104401 112136          TYPEIT ,MSG016
      .DSABL CRF
6113 036270 016105 003016          9$: MOV CONFIG(R1),R5
6114 036274 032705 000010          BIT #BIT3,R5          :EXTERNAL INTERLEAVE?
6115 036300 001404          BEQ 10$          :NO - SKIP
6116 036302 112737 000115 112134    MOVB #'M,MSG015      :INDICATE MULTIPLE BOXES
6117 036310 000417          BR 12$
6118 036312 032705 020014          10$: BIT #BIT13:14,R5
6119 036316 001004          BNE 11$          :M11?
6120 036320 112737 000077 112134    MOVB #'?,MSG015     :I DON'T KNOW HOW M11'S INTERLEAVE
6121 036326 000410          BR 12$
6122 036330 072527 177770          11$: ASH #-8,R5          :GET BOX NUMBER
6123 036334 042705 177774          BIC #^C3,R5         :CLEAR NON INTERESTING BITS
6124 036340 062705 000060          ADD #60,R5          :MAKE ASCII
6125 036344 110537 112134          MOVB R5,MSG015     :PLUG INTO MEMORY
6126 036350          12$: TYPE MSG015
      036350 104401 112134          TYPEIT ,MSG015
      .DSABL CRF
6127 036354 062701 000006          ADD #6,R1          :BUMP POINTER
6128 036360 077035          SOB R0,9$        :LOOP TILL DONE
6129 036362 010400          MOV R4,R0
6130 036364 010301          MOV R3,R1
6131
6132          :*****
6133          **: PROTECTED **

```

6134									
6135	036366								
	036366	104401	111733						
6136	036372	005761	003016						
6137	036376	100004							
6138	036400	112737	000120	112134					
6139	036406	000407							
6140	036410	032761	010000	003016	14\$:				
6141	036416	001406							
6142	036420	112737	000113	112134					
6143	036426								
	036426	104401	112134						
6144	036432	000402							
6145	036434								
	036434	104401	112132						
6146	036440	062701	000006						
6147	036444	077026							
6148	036446	010400							
6149	036450	010301							
6150	036452	000207							

```

*****
TYPE MSG010
TYPEIT ,MSG010
.DSABL CRF
TST CONFIG(R1) ;BANK PROTECTED?
BPL 14$ ;NO - SKIP
MOVB #'P,MSG015
BR 15$
BIT #BIT12,CONFIG(R1) ;PROTECTED REGION OF MK11 BOX?
BEQ 16$ ;NO - SKIP
MOVB #'K,MSG015
TYPE MSG015
TYPEIT ,MSG015
.DSABL CRF
BR 17$
TYPE MSG014 ;PRINT SPACE
TYPEIT ,MSG014
.DSABL CRF
ADD #6,R1 ;BUMP POINTER
SOB R0,13$ ;LOOP TILL DONE
MOV R4,R0
MOV R3,R1
RETURN
  
```


6154
6155
6156
6157
6158
6159
6160
6161
6162
6163
6164
6165
6166
6167

.SBTTL TRAP PARITY ERROR HANDLER

.....
:VECTOR TO HERE FROM TRAPS TO 114
:IGNORE ERRORS BUT COUNT IF NOPAR FLAG - 1.
:.....

CODE ACTION

--0-- PRINT UNEXPECTED PARITY TRAP
1 COUNT ERROR & SAVE 1ST IN 'PADDRESS'
2 SET 'ABORT' / SETUP 'BADPC' / RETURN VIA PCBUMP
3 RETURN VIA 'PARTHERE'
4 COUNT ERROR & SAVE 1ST IN 'PADDRESS' REGARDLESS OF ERROR REGISTER

6168	036454	022737	000001	002100	PARITY:	CMP	#1,NOPAR	:COUNTING PARITY ERRORS?
6169	036462	001023				BNE	3\$:NO - SKIP
6170	036464	032737	000001	177744		BIT	#BIT0, MEMERR	:MEMORY TIMEOUT?
6171	036472	001402				BEQ	1\$:NO - SKIP
6172	036474	000137	036646			JMP	NONEXIST	:YES - SIMULATE A TRAP TO 4
6173	036500	005237	002074		1\$:	INC	PARCNT	:PARITY ERROR COUNTER + 1
6174	036504	022737	000001	002074		CMP	#1,PARCNT	:FIRST PARITY ERROR?
6175	036512	001003				BNE	2\$:NO - SKIP
6176	036514	013737	177740	002042		MOV	LOADRS,PADDRESS	:SAVE 1ST BAD PARITY ADDRESS
6177	036522	013737	177744	177744	2\$:	MOV	MEMERR, MEMERR	:CLEAR ERROR BITS
6178	036530	000002				RTI		
6179	036532	022737	000002	002100	3\$:	CMP	#2,NOPAR	:ACTION CODE = 2 ?
6180	036540	001016				BNE	6\$:NO - SKIP
6181	036542					SET	ABORTFLAG	:YES
6182	036542	012737	177777	002142				MOV #-1,ABORTFLAG
6182	036550	004737	036770			CALL	BADSTACK	:FIND BAD SP,PC,PSW OFF STACK
6183	036554	063716	002406			ADD	PCBUMP,(SP)	:UPDATE RETURN PC
6184	036560	013737	177744	177744		MOV	MEMERR, MEMERR	:CLEAR ERROR BITS
6185	036566	042766	000004	000002		BIC	#BIT2,2(SP)	:SHOW FAILURE BY .NE.
6186	036574	000002				RTI		
6187	036576	022737	000003	002100	6\$:	CMP	#3,NOPAR	:ACTION CODE - 3 ?
6188	036604	001006				BNE	7\$:NO - SKIP
6189	036606	013716	002372			MOV	PARTHERE,(SP)	
6190	036612	013737	177744	177744		MOV	MEMERR, MEMERR	:CLEAR ERROR BITS
6191	036620	000002				RTI		
6192	036622	022737	000004	002100	7\$:	CMP	#4,NOPAR	
6193	036630	001001				BNE	8\$	
6194	036632	000722				BR	1\$	
6195								
6196	036634	004737	036770		8\$:	CALL	BADSTACK	:FIND BAD SP,PC,PSW OFF STACK
6197	036640					FATAL	32	
	036640	005237	002070			INC	FATAL\$:SET FATAL INDICATOR
	036644	104032				ERROR	+32	
						.DSABL	CRF	

```

6200          .SBTTL TRAP NON-EXISTANT MEMORY (HOLES) HANDLER
6201          :*****
6202          :VECTOR TO HERE (SOMETIMES) FROM TRAPS TO 4
6203          : CODE IN NONEM DETERMINES ACTION AS FOLLOWS:
6204          : 1) IGNORE ERRORS BUT COUNT IF NONEM (NO NON-EXISTANT MEMORY) FLAG = 1.
6205          : 2) TO EXIT PATTERN 0 DURING SIZING IF NON-EXIST MEM ERROR
6206          :*****
6207
6208 036646 022737 000001 002102 NONEXIST: CMP #1, NONEM ;COUNTING NON-EXISTANT MEMORY ERRORS?
6209 036654 001014          BNE 2$ ;NO - SKIP
6210 036656 005237 002072 INC NEMCNT ;BUMP NON-EXISTANT MEMORY COUNTER
6211 036662 022737 000001 002072 CMP #1, NEMCNT ;FIRST ERROR?
6212 036670 001005          BNE 1$ ;NO - SKIP
6213 036672 010037 002040 MOV R0, ADDRESS ;ASSUME R0 CONTAINS THE ADDRESS ACCESSED
6214 036676 013737 177744 177744 MOV MEMERR, MEMERR ;CLEAR OUT HIADRS & LOADRS REG'S
6215 036704 000002          1$: RTI
6216 036706 005237 002072          2$: INC NEMCNT ;BUMP NON-EXISTANT MEMORY COUNTER
6217 036712 012701 000001 MOV #1, R1 ;DUMMY UP R1 FOR A FORCED SOB EXIT
6218 036716 013737 177744 177744 MOV MEMERR, MEMERR ;CLEAR OUT HIADRS & LOADRS REG'S
6219 036724 000002          RTI
6220
6221          :*****
6222          .SBTTL TRAP TIMEOUT (TRAP TO 4) HANDLER
6223 036726 004737 036770 TIMEOUT: CALL BADSTACK ;FIND BAD SP, PC, PSW OFF STACK
6224 036732          FATAL 6
6224 036732 005237 002070 INC FATALS ;SET FATAL INDICATOR
6224 036736 104006          ERROR +6
6224          .DSABL CRF
6225
6226          :*****
6227          .SBTTL TRAP MEMORY MANAGEMENT (TRAP TO 250) HANDLER
6227 036740 004737 036770 MMTRAP: CALL BADSTACK ;FIND BAD SP, PC, PSW OFF STACK
6228 036744          FATAL 7
6228 036744 005237 002070 INC FATALS ;SET FATAL INDICATOR
6228 036750 104007          ERROR +7
6228          .DSABL CRF
6229
6230          .SBTTL TRAP RESERVED INSTRUCTION HANDLER
6230 036752 004737 036770 PDP1105: CALL BADSTACK ;FIND BAD SP, PC, PSW OFF STACK
6231 036756          FATAL 5
6231 036756 005237 002070 INC FATALS ;SET FATAL INDICATOR
6231 036762 104005          ERROR +5
6231          .DSABL CRF
6232
6233 036764          IITRAP: SUBTST <<UNEXPECTED IIST TRAP HANDLER>>
6233          :*****
6233          :*SUBTEST UNEXPECTED IIST TRAP HANDLER
6233          :*****
6234 036764 104057          ERROR +57
6235 036766 000002          RTI
6236
6237 036770          BADSTACK: SUBTST <<FIND BAD SP, PC, & PSW FROM STACK>>
6237          :*****
6237          :*SUBTEST FIND BAD SP, PC, & PSW FROM STACK
6237          :*****
6238 036770 010637 002032          MOV SP, BADSP
6239 036774 062737 000002 002032 ADD #2, BADSP
6240 037002 016637 000002 002026 MOV 2(SP), BADPC
6241 037010 016637 000004 002036 MOV 4(SP), BADPSW
  
```

6242 037016 000207

RETURN

```

6245          .SBTTL TRAP   KERNEL TRAP HANDLER
6246          :*****
6247          :KERNEL IS A TRAP THAT COMES HERE
6248          :*****
6249
6250 037020 042766 140000 000002 $KERNEL:      BIC      #140000,2(SP)
6251 037026 000002          RTI
6252          :*****
6253          .SBTTL TRAP   ENERGIZE TRAP HANDLER
6254 037030 052737 001001 177572 $ENERGIZE: BIS  #BIT9,BIT0,MMRO
6255 037036 000002          RTI
6256          :*****
6257          .SBTTL TRAP   DEENERGIZE TRAP HANDLER
6258 037040 042737 001001 177572 $DEENERGIZE: BIC #BIT9,BIT0,MMRO
6259 037046 000002          RTI
6260          :*****
6261          .SBTTL TRAP   CACHON TRAP HANDLER
6262 037050 013737 002700 177746 $CACHN:  MOV   CACHK,CONTRL ;SETUP CACHE AS PER CONSTANT (USUALLY 1 = FULLY ON)
6263 037056 052737 000001 177746      BIS   #BIT0,CONTRL ;DISABLE TRAPS (BUT NOT ABORTS)
6264 037064 000002          RTI
6265          :*****
6266          .SBTTL TRAP   CACHOFF TRAP HANDLER
6267          :DISABLE TRAPS (NOT ABORTS), FORCE MISSES, FLUSH, BYPASS
6268 037066 052737 001415 177746 $CACHF:  BIS   #BIT0,BIT2,BIT3,BIT8,BIT9,CONTRL
6269 037074 000002          RTI

```

```

6273          .SBTTL TRAP LOAD CSR TRAP HANDLER
6274          :LOAD CORRECT CSR WITH DATA IN CSR & CSR+2
6275 037076   $LOADC: PUSH RO
6276 037076 010046          MOV #MK11ADD,RO          ;CREATE CSR ADDRESS
6277 037100 012700 172100  ADD CSRNO,RO
6278 037104 063700 002256  TST CSRREL          ;CSR'S RELOCATED?
6279 037110 005737 002254  BNE $LOAD1          ;YES - SKIP
6280 037114 001014          MOV CSR,(RO)+          ;LOAD IT
6281 037116 013720 002144  IF TWOCSRS IS TRUE
6281 037122 005737 002600          TST TWOCSRS
6281 037126 001403          BEQ L417
6282 037130 013710 002146          MOV CSR+2,(RO)
6283 037134          ELSE
6283 037134 000402          BR L420
6284 037136 042710 100000          L417:
6285 037142          BIC #BIT15,(RO)
6285 037142          END ;OF IF TWOCSRS
6285 037142          L420:
6286 037142          POP RO
6286 037142 012600          MOV (SP)+,RO
6287 037144 000002          RTI
6288 037146 042700 020000          $LOAD1: BIC #20000,RO
6289 037152 013737 177746 002370  MOV CONTRL,OLDCACHE ;SAVE CACHE STATUS
6290 037160 104424          CACHOFF ;TURN CACHE OFF
6291 037162 013720 002144          MOV CSR,(RO)+ ;LOAD IT
6292 037166          IF TWOCSRS IS TRUE
6292 037166 005737 002600          TST TWOCSRS
6292 037172 001403          BEQ L421
6293 037174 013710 002146          MOV CSR+2,(RO)
6294 037200          ELSE
6294 037200 000402          BR L422
6295 037202 042710 100000          L421:
6296 037206          BIC #BIT15,(RO)
6296 037206          END ;OF IF TWOCSRS
6296 037206          L422:
6297 037206 013737 002370 177746  MOV OLDCACHE,CONTRL ;RESTORE CACHE
6298 037214          POP RO
6298 037214 012600          MOV (SP)+,RO
6299 037216 000002          RTI

```

TRAP READ CSR TRAP HANDLER

```

6302          .SBTTL TRAP READ CSR TRAP HANDLER
6303          :READ THE CORRECT CSR INTO LOCATIONS CSR & CSR+2
6304 037220   $READC: PUSH      RO
                   037220 010046
6305 037222 012700 172100      MOV      #MK11ADD,RO      ;CREATE CSR ADDRESS      MOV RO,-(SP)
6306 037226 063700 002256      ADD      CSRNO,RO
6307 037232 005737 002254      TST      CSRREL      ;CSR'S RELOCATED?
6308 037236 001005              BNE      1$           ;YES - SKIP
6309 037240 012037 002144      MOV      (RO)+,CSR    ;READ IT
6310 037244 011037 002146      MOV      (RO),CSR+2  ;READ IT
6311 037250 000415              BR       2$
6312 037252 042700 020000 1$:  BIC      #20000,RO
6313 037256 013737 177746 002370  MOV      CONTRL,OLDCACHE ;SAVE CACHE STATUS
6314 037264 104424              CACHOFF ;TURN CACHE OFF
6315 037266 012037 002144      MOV      (RO)+,CSR    ;READ IT
6316 037272 011037 002146      MOV      (RO),CSR+2  ;READ IT
6317 037276 013737 002370 177746  MOV      OLDCACHE,CONTRL ;RESTORE CACHE
6318 037304 2$:  POP      RO
                   037304 012600
6319 037306 000002              RTI
                   037310
6320
6321          .SBTTL TRAP TEST (R1) & READ CSR CAREFULLY
6322 037310   $TSTRD: PUSH      RO
                   037310 010046
6323 037312              BMOV     TSTRD1
                   037312 004537 043710      JSR     R5,BLOCK1
                   037316 037434              TSTRD1
                   .DSABL      CRF
6324 037320 012700 172100      MOV      #MK11ADD,RO      ;CREATE CSR ADDRESS
6325 037324 063700 002256      ADD      CSRNO,RO
6326 037330 005737 002254      TST      CSRREL      ;CSR'S RELOCATED?
6327 037334 001003              BNE      1$           ;YES - SKIP
6328 037336 004737 17640       CALL     FASTCITY      ;CALL TO THE USER INSTRUCTION PAR'S
6329 037342 000413              BR       2$
6330 037344 042700 020000 1$:  BIC      #20000,RO
6331 037350 013737 177746 002370  MOV      CONTRL,OLDCACHE ;SAVE CACHE STATUS
6332 037356 104424              CACHOFF ;TURN CACHE OFF
6333 037360 004737 177640      CALL     FASTCITY      ;CALL TO THE USER INSTRUCTION PAR'S
6334 037364 013737 002370 177746  MOV      OLDCACHE,CONTRL ;RESTORE CACHE
6335          ;IF SINGLE BIT ERROR ONLY - SET CARRY BIT
6336 037372 2$:  POP      RO
                   037372 012600
6337 037374              IF #BIT4 SET.IN CSR AND #BIT15 OFF.IN CSR      MOV (SP)+,RO
                   037374 032737 000020 002144      BIT     #BIT4,CSR
                   037402 001410              BEQ     L423
                   037404 032737 100000 002144      BIT     #BIT15,CSR
                   037412 001004              BNE     L423
6338 037414 052766 000001 000002      BIS     #BIT0,2(SP)
6339 037422              ELSE
                   037422 000403              BR     L424
                   037424
6340 037424 042766 000001 000002      BIC     #BIT0,2(SP)
6341 037432              END ;OF IF #BIT4
                   037432
6342 037432 000002              RTI
6343
6344 037434 005010   TSTRD1: CLR      (RO)      ;v177640

```

6345 037436
 037436 052737 040000 177776
 6346 037444 105711
 6347 037446 042737 140000 177776
 6348 037454 012037 002144
 6349 037460 011037 002146
 6350 037464 000207

SUPERVISOR
 BIS #BIT14,PSW
 .DSABL CRF
 TSTB (R1)
 BIC #BIT15!BIT14,PSW
 MOV (R0)+,CSR
 MOV (R0),CSR+2
 RETURN

;V177642 ;ENTER SUPERVISOR MODE
 ;DO IT TO IT.
 ;V177646
 ;V177650
 ;V177656
 ;V177662
 ;V177666

TRAP ECC DISABLE ALL CSR'S TRAP HANDLER

```

6354 .SBTTL TRAP ECC DISABLE ALL CSR'S TRAP HANDLER
6355 037466 012737 000002 002144 $ECCDIS:MOV #BIT1,CSR
6356 037474 005737 002122 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
                                TST KPFLAG
                                BEQ L425
                                BIS #BIT3,CSR
                                L425:.....
6357 037510 005037 002146 CLR CSR+2
6358 037514 004737 040442 CALL CSROUT
6359 037520 000002 RTI
6360 .SBTTL TRAP ECC DISABLE OF 1 SELECTED CSR TRAP HANDLER
6361 037522 012737 000002 002144 $ECC1DIS:MOV #BIT1,CSR
6362 037530 005737 002122 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
                                TST KPFLAG
                                BEQ L426
                                BIS #BIT3,CSR
                                L426:.....
6363 037544 005037 002146 CLR CSR+2
6364 037550 104425 LOADCSR
6365 037552 000002 RTI
6366 .SBTTL TRAP MK11 INITIALIZE ALL CSR'S TRAP HANDLER
6367 037554 012737 000001 002144 $ECCINIT:MOV #BIT0,CSR
6368 037562 005037 002146 CLR CSR+2
6369 037566 004737 040442 CALL CSROUT
6370 037572 000002 RTI
6371 .SBTTL TRAP MK11 INITIALIZE 1 SELECTED CSR TRAP HANDLER
6372 037574 012737 000001 002144 $ECC1INIT:MOV #BIT0,CSR
6373 037602 005037 002146 CLR CSR+2
6374 037606 104425 LOADCSR
6375 037610 000002 RTI
6376 .SBTTL TRAP ENABLE SBE PARITY TRAPS ON ALL CSR'S
6377 037612 012737 000003 002144 $ENASBE:MOV #BIT0!BIT1,CSR
6378 037620 005737 002122 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
                                TST KPFLAG
                                BEQ L427
                                BIS #BIT3,CSR
                                L427:.....
6379 037634 005037 002146 CLR CSR+2
6380 037640 004737 040442 CALL CSROUT
6381 037644 000002 RTI
6382 .SBTTL TRAP ENABLE SBE PARITY TRAPS ON 1 SELECTED CSR
6383 037646 012737 000003 002144 $ENA1SBE:MOV #BIT0!BIT1,CSR
6384 037654 005737 002122 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
                                TST KPFLAG
                                BEQ L430
                                BIS #BIT3,CSR
                                L430:.....
6385 037670 005037 002146 CLR CSR+2
6386 037674 104425 LOADCSR
6387 037676 000002 RTI
6388 .SBTTL TRAP WRITE CHECKBITS THRU ALL CSR'S TRAP HANDLER
6389 037700 013737 002404 002144 $CBCSR:MOV CHECK,CSR ;BITS 14-8
6390 037706 052737 000006 002144 BIS #BIT1!BIT2,CSR ;CHECK MODE
6391 037714 005737 002122 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
                                TST KPFLAG
                                BEQ L431
                                BIS #BIT3,CSR
                                L431:.....
6392 037720 001403
6393 037722 052737 000010 002144

```


TRAP WRITE CHECKBITS THRU ALL CSR'S TRAP HANDLER

SEQ 0805

L431:.....

```

037730
6392 037730 005037 002146 CLR CSR+2
6393 037734 004737 040442 CALL CSROUT
6394 037740 000002 RTI
6395 .SBTTL TRAP WRITE CHECKBITS THRU 1 SFLECTED CSR TRAP HANDLER
6396 037742 013737 002404 002144 $CB1CSR:MOV CHECK,CSR ;BITS 14-8
6397 037750 052737 000006 002144 BIS #BIT1!BIT2,CSR ;CHECK MODE
6398 037756 IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3

```

```

TST KPFLAG
BEQ L432
BIS #BIT3,CSR

```

L432:.....

```

037756 005737 002122
037762 001403
037764 052737 000010 002144
037772
6399 037772 005037 002146 CLR CSR+2
6400 037776 104425 LOADCSR
6401 040000 000002 RTI

```

*RAP WAS THERE A SBE ON ANY CSR TRAP HANDLER

```

6405          .SBTTL TRAP WAS THERE A SBE ON ANY CSR TRAP HANDLER
6406 040002          $WASSBE: PUSH R1,R4
        040002 010146          MOV R1,-(SP)
        040004 010446          MOV R4,-(SP)
6407 040006 013701 002334      MOV MKCSRS,R1 ;GET CSR'S BYTE
6408 040012 005004          CLR R4
6409 040014          BEGIN LWSBE
        040014          FOR CSRNO :- #0 TO #34 BY #4
6410 040014 005037 002256          CLR CSRNO
        040020          B52:*****
6411 040020 106301          ASLB R1
6412 040022          ON.ERROR
        040022 103010          BCC L433
6413 040024 104426          READCSR
6414 040026          IF #BIT4 SET.IN CSR
        040026 032737 000020 002144      BIT #BIT4,CSR
        040034 001403          BEQ L434
6415 040036          SET R4
        040036 012704 177777          MOV #-1,R4
6416 040042          LEAVE LWSBE
        040042 000411          BR E51
6417 040044          END ;OF IF #BIT4
        040044          L434:*****
6418 040044          END ;OF ON.ERROR
        040044          L433:*****
6419 040044          IFB R1 EQ #0 THEN LEAVE LWSBE
        040044 105701          TSTB R1
        040046 001407          BEQ E51
6420 040050          END ;OF FOR CSRNO
        040050 062737 000004 002256      ADD #4,CSRNO
        040056 023727 002256 000034      CMP CSRNO,#34
        040064 003755          BLE B52
6421 040066          END LWSBE
        040066          E52:*****
6422 040066 006004          ROR R4
        040070          POP R4,R1 ;SET C BIT FOR ERROR
        040072          E51:*****
6423 040070 012604          MOV (SP)+,R4
        040072 012601          MOV (SP)+,R1
6424 040074          ON.ERROR
        040074 103004          BCC L435
6425 040076 052766 000001 000002      BIS #BIT0,2(SP)
6426 040104          ELSE
        040104 000403          BR L436
        040106          L435:*****
6427 040106 042766 000001 000002      BIC #BIT0,2(SP)
6428 040114          END ;OF ON.ERROR
        040114          L436:*****
6429 040114 000002          RTI
6430          .SBTTL TRAP WAS THERE A SBE IN 1 SELECTED CSR TRAP HANDLER
6431          ;ON RETURN IF CARRY IS SET THERE WAS A SBE
6432 040116 104426          $WAS1SBE: READCSR
6433 040120 042766 000001 000002      BIC #BIT0,2(SP) ;CLR C BIT ON STACK
6434 040126 032737 000020 002144      BIT #BIT4,CSR
6435 040134 001403          BEQ 1$
6436 040136 052766 000001 000002      BIS #BIT0,2(SP) ;SET C BIT ON STACK

```

6437 140144 000002

18: RTI

```

6440          .SBTTL TRAP WAS THERE A DBE ON ANY CSR TRAP HANDLER
6441 040146          $WASDBE: PUSH R1,R4
        040146 010146          MOV R1,-(SP)
        040150 010446          MOV R4,-(SP)
6442 040152 013701 002334      MOV MKCSRS,R1 ;GET CSR'S BYTE
6443 040156 005004          CLR R4
6444 040160          BEGIN LWDBE
        040160          FOR CSRNO := #0 TO #34 BY #4
6445 040160 005037 002256      CLR CSRNO
        040164          B53:*****
        040164 106301          ASLB R1
6446 040166          ON.ERROR          B54:*****
        040166 103010          READCSR
6448 040170 104426          IF #BIT15 SET.IN CSR          BCC L437
6449 040172 032737 100000 002144  BIT #BIT15,CSR
        040200 001403          BEQ L440
6450 040202          SET R4
        040202 012704 177777      MOV #-1,R4
6451 040206          LEAVE LWDBE
        040206 000411          BR E53
6452 040210          END ;OF IF #BIT15
        040210          L440:*****
6453 040210          END ;OF ON.ERROR
        040210          L437:*****
6454 040210          IFB R1 EQ #0 THEN LEAVE LWDBE
        040210 105701          TSTB R1
        040212 001407          BEQ E53
6455 040214          END ;OF FOR CSRNO
        040214 062737 000004 002256  ADD #4,CSRNO
        040222 023727 002256 000034  CMP CSRNO,#34
        040230 003755          BLE B54
6456 040232          END LWDBE
        040232          E54:*****
6457 040232 006004          ROR R4
        040234          POP R4,R1 ;SET C BIT FOR ERROR
        040234 012604          MOV (SP)+,R4
        040236 012601          MOV (SP)+,R1
6459 040240          ON.ERROR
        040240 103004          BCC L441
6460 040242 052766 000001 000002  BIS #BIT0,2(SP)
6461 040250          ELSE
        040250 000403          BR L442
        040252          L441:*****
6462 040252 042766 000001 000002  BIC #BIT0,2(SP)
6463 040260          END ;OF ON.ERROR
        040260          L442:*****
6464 040260 000002          RTI
6465          .SBTTL TRAP WAS THERE A DBE ON 1 SELECTED CSR TRAP HANDLER
6466          ;ON RETURN IF CARRY IS SET THERE WAS A DBE
6467 040262 104426          $WAS1DBE: READCSR
6468 040264 005737 002144      TST CSR ;DBE?
6469 040270 100010          BPL 3$ ;NO - SKIP
6470 040272 005737 002146      TST CSR+2 ;DBE IN OTHER WORD?
6471 040276 100401          BMI 2$ ;YES - SKIP

```

6472	040300	104021				ERROR	+21		:NO - ONLY ONE FLAG POPPED UP
6473	040302	052766	000001	000002	28:	BIS	#BIT0,2(SP)		:SET C BIT ON STACK
6474	040310	000002				RTI			
6475	040312	042766	000001	000002	38:	BIC	#BIT0,2(SP)		:CLR C BIT ON STACK
6476	040320	000002				RTI			

```

6479                                     .SBTTL TRAP CLEAR ALL MK11 CSR'S TRAP HANDLER
6480 040322 $CLRCSR: CLEAR CSR,CSR+2
      040322 005037 002144                                     CLR CSR
      040326 005037 002146                                     CLR CSR+2
6481 040332 004737 040442                                     CALL CSROUT
6482 040336 000002                                     RTI
6483                                     .SBTTL TRAP CLEAR 1 SELECTED MK11 CSR TRAP HANDLER
6484 040340 $CLR1CSR: CLEAR CSR,CSR+2
      040340 005037 002144                                     CLR CSR
      040344 005037 002146                                     CLR CSR+2
6485 040350 104425                                     LOADCSR
6486 040352 000002                                     RTI
6487                                     .SBTTL TRAP ECC DISABLE, CHECK MODE, & WRITE CHECKBITS IN ALL CSR'S TRAP HANDLER
6488                                     :CHECKBITS ALREADY IN LOC "CSR"
6489 040354 052737 000006 002144 $CHKDIS: BIS #BIT1!BIT2,CSR ;ECC DISABLE & DIAG CHECK MODE
6490 040362 005737 002122                                     IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
      040366 001403                                     TST KPFLAG
      040370 052737 000010 002144                                     BEQ L443
      040376                                     BIS #BIT3,CSR
      L443:*****
6491 040376 005037 002146                                     CLR CSR+2
6492 040402 004737 040442                                     CALL CSROUT
6493 040406 000002                                     RTI
6494                                     .SBTTL TRAP ECC DISABLE, CHECK MODE, & WRITE CHECKBITS IN 1 SELECTED CSR
6495                                     :CHECKBITS ALREADY IN LOC "CSR"
6496 040410 052737 000006 002144 $CHK1DIS: BIS #BIT1!BIT2,CSR ;ECC DISABLE & DIAG CHECK MODE
6497 040416 005737 002122                                     IF KPFLAG IS TRUE THEN LET CSR := CSR SET.BY #BIT3
      040422 001403                                     TST KPFLAG
      040424 052737 000010 002144                                     BEQ L444
      040432                                     BIS #BIT3,CSR
      L444:*****
6498 040432 005037 002146                                     CLR CSR+2
6499 040436 104425                                     LOADCSR
6500 040440 000002                                     RTI

```

```

6503 040442          CSROUT: SUBTST <<SUBR WRITE IN ALL CSR'S>>
:.....
: *SUBTEST          SUBR   WRITE IN ALL CSR'S
:.....
6504 040442          PUSH   R1
6505 040444 010146    MOV    MKCSRS,R1      ;GET CSR'S BYTE
6506 040450 013701 002334 BEGIN LCSROUT
6507 040450          FOR CSRNO :- #0 TO #34 BY #4
6508 040454 005037 002256 ASLB   R1
6509 040456 106301    ON.ERROR
6510 040460 103001    LOADCSR
6511 040462 104425    END ;OF ON.ERROR
6512 040462          IFB R1 EQ #0 THEN LEAVE LCSROUT
6513 040466 105701    END ;OF FOR CSRNO
6514 040468 062737 000004 002256 ADD #4,CSRNO
6515 040474 023727 002256 000034 CMP CSRNO,#34
6516 040502 003764    BLE B56
6517 040504          E56:.....
6518 040504          E55:.....
6519 040510          MOV (SP)+,R1
6520 040514 010046    MOV R0,-(SP)
6521 040520 013701 002106    MOV R1,-(SP)
6522 040524 070127 000006    MOV R0,-(SP)
6523 040532 042761 020000 003020 BIC #BIT13,CONFIG+2(R1)
6524 040536 012601    MOV (SP)+,R1
        012600    MOV (SP)+,R1
        000002    RTI
  
```

6528 040540

CHKGEN: SUBTST<<SUBR GENERATE CHECK BITS>>

 :*SUBTEST SUBR GENERATE CHECK BITS

6529
 6530
 6531
 6532
 6533
 6534
 6535
 6536

:CHECK BIT GENERATOR ROUTINE
 :CALLING SEQUENCE IS:
 : MOV #WORD1,SOURCE ;SOURCE = ADDRESS OF DATA
 : CALL CHKGEN
 :CHECK BITS RETURNED IN BITS 14-8 OF LOCATION CHECK
 : PUSH R0,R1,R2,R3,R4,R5

040540 010046
 040542 010146
 040544 010246
 040546 010346
 040550 010446
 040552 010546
 6537 040554 012702 000077
 6538 040560 012703 040640
 6539 040564 013705 002402
 6540 040570 012501
 6541 040572 011500
 6542
 6543 040574 006704
 6544 040576 142304
 6545 040600 074402
 6546 040602 073027 000001
 6547 040606 001372
 6548
 6549 040610 042702 177600
 6550 040614 000302
 6551 040616 010237 002404
 6552 040622
 040622 012605
 040624 012604
 040626 012603
 040630 012602
 040632 012601
 040634 012600
 6552 040636 000207

MOV R0,-(SP)
 MOV R1,-(SP)
 MOV R2,-(SP)
 MOV R3,-(SP)
 MOV R4,-(SP)
 MOV R5,-(SP)
 MOV #77,R2 ;DEFAULT CHECKBITS FOR DOUBLE WORD OF ZEROS
 MOV #CHKTAB,R3 ;ADDRESS OF CHECKBIT TABLE
 MOV SOURCE,R5 ;GET SOURCE ADDRESS
 MOV (R5)+,R1 ;GET LSB'S
 MOV (R5),R0 ;GET MSB'S
 *S: SXT R4 ;EXTEND SIGN OF DOUBLE WORD TO R4
 BICB (R3)+,R4 ;ELIMINATE BITS THAT DON'T COUNT
 XOR R4,R2 ;COMPLEMENT MASKED BITS IN CHECKBITS
 ASHC #1,R0 ;DOUBLE PRECISION LEFT SHIFT R0,,R1
 BNE 1\$;LOOP TILL ALL BITS ARE CHECKED
 BIC #C177,R2 ;KILL ALL JUNK BITS
 SWAB R2 ;POSITION CHECKBITS IN BITS 14-8
 MOV R2,CHECK
 POP R5,R4,R3,R2,R1,R0
 MOV (SP)+,R5
 MOV (SP)+,R4
 MOV (SP)+,R3
 MOV (SP)+,R2
 MOV (SP)+,R1
 MOV (SP)+,R0
 RETURN

Address	Hex	Dec	CHKTAB	Bit
6556	040640		:BYTE #3	
6557	040640	200	.BYTE ^C177	:BIT 31
6558	040641	301	.BYTE ^C076	:BIT 30
6559	040642	302	.BYTE ^C075	:BIT 29
6560	040643	203	.BYTE ^C174	:BIT 28
6561	040644	304	.BYTE ^C073	:BIT 27
6562	040645	205	.BYTE ^C172	:BIT 26
6563	040646	206	.BYTE ^C171	:BIT 25
6564	040647	307	.BYTE ^C070	:BIT 24
6565			:BYTE #2	
6566	040650	310	.BYTE ^C067	:BIT 23
6567	040651	211	.BYTE ^C166	:BIT 22
6568	040652	212	.BYTE ^C165	:BIT 21
6569	040653	313	.BYTE ^C064	:BIT 20
6570	040654	214	.BYTE ^C163	:BIT 19
6571	040655	315	.BYTE ^C062	:BIT 18
6572	040656	316	.BYTE ^C061	:BIT 17
6573	040657	217	.BYTE ^C160	:BIT 16
6574			:BYTE #1	
6575	040660	320	.BYTE ^C057	:BIT 15
6576	040661	221	.BYTE ^C156	:BIT 14
6577	040662	222	.BYTE ^C155	:BIT 13
6578	040663	323	.BYTE ^C054	:BIT 12
6579	040664	224	.BYTE ^C153	:BIT 11
6580	040665	325	.BYTE ^C052	:BIT 10
6581	040666	326	.BYTE ^C051	:BIT 9
6582	040667	227	.BYTE ^C150	:BIT 8
6583			:BYTE #0	
6584	040670	340	.BYTE ^C037	:BIT 7
6585	040671	241	.BYTE ^C136	:BIT 6
6586	040672	242	.BYTE ^C135	:BIT 5
6587	040673	343	.BYTE ^C034	:BIT 4
6588	040674	244	.BYTE ^C133	:BIT 3
6589	040675	345	.BYTE ^C032	:BIT 2
6590	040676	346	.BYTE ^C031	:BIT 1
6591	040677	247	.BYTE ^C130	:BIT 0

6595 040700

SUBSTST<<SUBR MAPPER>>

 *SUBTEST SUBR MAPPER

6596
 6597
 6598
 6599
 6600
 6601
 6602
 6603
 6604

: THIS SUBROUTINE MAPS THE MEMORY BANK (16K WORDS = 1 BANK)
 : IN R3 TO THE TEST PATTERN AREA (SUPERVISOR VIRTUAL (60000 - 157777)).
 :
 : CALL MOV BANKNO,R3 ;SET UP BANK ARGUEMENT
 : CALL MAPPER ;ACTUAL CALL
 : RETURN ;ONLY RETURN

: SET SUPERVISOR UP FOR 1 TO 1 MAP
 MAPPER: PUSH R0,R1,R2,R4,R5

040700 010046
 040702 010146
 040704 010246
 040706 010446
 040710 010546
 6605 040712 012700 172340
 6606 040716 012701 172240
 6607 040722 012702 077406
 6608 040726 012704 172200
 6609 040732 012705 000010
 6610 040736 012021
 6611 040740 010224
 6612 040742 077503
 6613 040744 012741 177600

MOV R0,-(SP)
 MOV R1,-(SP)
 MOV R2,-(SP)
 MOV R4,-(SP)
 MOV R5,-(SP)
 MOV #KIPAR0,R0 ;FIRST AREA TO MAP TO
 MOV #SIPAR0,R1 ;FIRST ADDRESS REGISTER
 MOV #77406,R2 ;CONSTANT FOR 4K PAGE, UP, R/W
 MOV #SIPDR0,R4 ;FIRST DISCRIPTOR REGISTER
 MOV #8.,R5 ;COUNTER
 1\$: MOV (R0)+,(R1)+ ;PUT IN SUPERVISOR ADDRESS
 MOV R2,(R4)+ ;PUT IN SUPERVISOR DISCRIPTOR
 SOB R5,1\$;LOOP TILL DONE
 MOV #177600,-(R1) ;CORRECT LAST FIELD FOR PERIPHERALS PAGE

6614
 6615
 6616 040750 022703 000170
 6617 040754 001412
 6618 040756 072327 000011
 6619
 6620 040762 012701 172246
 6621 040766 012702 000004
 6622 040772 010321
 6623 040774 062703 000200
 6624 041000 077204
 6625 041002

: SET UP SUPERVISOR FOR TEST AREA
 CMP #120.,R3 ;MAP NOTHING (1 TO 1)?
 BEQ 3\$;YES - SKIP
 ASH #9.,R3 ;BANK 1 STARTS AT 100,000 LESS 6 LSB'S
 ;FOR MEMORY MANAGEMENT = 1000
 MOV #SIPAR3,R1 ;SETUP FOR AUTO INCREMENTING
 MOV #4,R2 ;COUNTER
 2\$: MOV R3,(R1)+ ;PLUG IN PAR INFO
 ADD #200,R3 ;BUMP ADDRESS 4K
 SOB R2,2\$;LOOP TILL DONE
 3\$: POP R5,R4,R2,R1,R0

041002 012605
 041004 012604
 041006 012602
 041010 012601
 041012 012600
 6626 041014 000207

MOV (SP)+,R5
 MOV (SP)+,R4
 MOV (SP)+,R2
 MOV (SP)+,R1
 MOV (SP)+,R0
 RETURN

6627

.SBTTL TRAP MAP KERNEL (ALMOST 1 TO 1) TRAP HANDLER
 \$KMAP: PUSH R0,R1,R2,R3,R4

6628 041016
 041016 010046
 041020 010146
 041022 010246
 041024 010346
 041026 010446
 6629 041030 005000
 6630 041032 012701 172340
 6631 041036 012702 077406
 6632 041042 012703 172300
 6633 041046 012704 000010

MOV R0,-(SP)
 MOV R1,-(SP)
 MOV R2,-(SP)
 MOV R3,-(SP)
 MOV R4,-(SP)
 CLR R0 ;1ST AREA TO MAP TO
 MOV #KIPAR0,R1 ;FIRST ADDRESS
 MOV #77406,R2 ;CONSTANT FOR 4K PAGE,UP,R/W
 MOV #KIPDR0,R3 ;1ST PAGE DISCRIPTOR REGISTER
 MOV #8.,R4 ;COUNTER

```

6634 041052 010021          1$:  MOV    R0,(R1)+      ;PUT IN KERNEL ADDRESS
6635 041054 010223          MOV    R2,(R3)+      ;PUT IN KERNEL DISCRIPTOR
6636 041056 062700 000200  ADD    #200,R0       ;ADD ADDRESS CONSTANT FOR 4K CHANGE
6637 041062 077405          SOB    R4,1$        ;LOOP TILL DONE
6638 041064 012741 177600  MOV    #177600,-(R1) ;THE PERIPHERALS PAGE TO KIPAR7
6639 041070 012741 177400  MOV    #177400,-(R1) ;AND NEXT LOWER PAGE TO KIPAR6
6640 041074          IF CPUBIT NE #MASTER ;IF I'M NOT THE MASTER
        041074 023727 002114 000020      CMP CPUBIT,#MASTER
        041102 001404          BEQ L446
6641 041104 013700 002710      MOV    LOADHOME,R0   ;MAP TO LOADERS LIKE THE MASTER DID!
6642 041110 004737 042370      CALL  NEWLOAD
6643 041114          END ;OF IF CPUBIT
        041114          POP    R4,R3,R2,R1,R0      L446:;;;;;;;;
        041114 012604          MOV (SP)+,R4
        041116 012603          MOV (SP)+,R3
        041120 012602          MOV (SP)+,R2
        041122 012601          MOV (SP)+,R1
        041124 012600          MOV (SP)+,R0
6645 041126 000002          RTI

```


RELOCATE PROGRAM

```

6673 041306          B62:.....
      041306 032761 104000 003016      IF #BIT11!BIT15 OFF.IN CONFIG(R1) ;IF NO ERRORS & NOT PROGRAM SPACE
      041314 001035                      BIT #BIT11!BIT15,CONFIG(R1)
6674 041316          BNE L452
      041316 032761 100000 003020      IF #BIT15 OFF.IN CONFIG+2(R1) ;IF NOT LOADER BANK
      041324 001031                      BIT #BIT15,CONFIG+2(R1)
6675 041326          BNE L453
      041326 033761 002114 003016      IF CPUBIT SET.IN CONFIG(R1) ;IF ACCESSABLE
      041334 001425                      BIT CPUBIT,CONFIG(R1)
6676 041336          BEQ L454
      041336 032761 060000 003016      IF #BIT13!BIT14 OFF.IN CONFIG(R1) THEN LEAVE FINDBANK ;IF M11
      041344 001436                      BIT #BIT13!BIT14,CONFIG(R1)
6677 041346          BEQ E61
      041346 032761 020000 003016      IF #BIT13 SET.IN CONFIG(R1) AND #BIT14 OFF.IN CONFIG(R1) ;IF M11
      041354 001415                      BIT #BIT13,CONFIG(R1)
      041356 032761 040000 003016      BIT #BIT14,CONFIG(R1)
      041364 001011                      BNE L455
6678 041366          IF #BIT12 SET.IN CONFIG-6(R1) AND #BIT12 OFF.IN CONFIG(R1)
      041366 032761 010000 003010      BIT #BIT12,CONFIG-6(R1)
      041374 001405                      BEQ L456
      041376 032761 010000 003016      BIT #BIT12,CONFIG(R1)
      041404 001001                      BNE L456
6679                                     ;IF 1ST UNPROTECTED M11 BANK
6680 041406          LEAVE FINDBANK
      041406 000415                      BR E61
6681 041410          END ;OF IF #BIT12
6682 041410          END ;OF IF #BIT13
6683 041410          END ;OF IF CPUBIT
6684 041410          END ;OF IF #BIT15
6685 041410          END ;OF IF #BIT11
6686 041410          END ;OF FOR
      041410 062701 000006          ADD #6,R1
      041414 020127 001312          CMP R1,#167*3+2
      041420 003732          BLE B62
      041422          E62:.....
6687 041422          IF #SW13 OFF.IN @SWR
      041422 032777 020000 141336      BIT #SW13,@SWR
      041430 001002          BNE L457
6688 041432          TYPE MSG075 ;RELOCATION NOT POSSIBLE
      041432 104401 115341          TYPEIT ,MSG075
      .DSABL CRF
      END ;OF IF #SW13
6689 041436          L457:.....
6690 041436          $RETURN ERROR
      041436 000261          SEC
      041440 000207          RTS PC
6691 041442          END FINDBANK
6692 041442          BIC #BIT13,CONFIG+2(R1) ;INVALIDATE BACKGROUND PATTERN
6693 041450          CLR R0
6694 041452          DIV #6,R0
    
```

RELOCATE PROGRAM

```

6697 041456
      041456 010037 002400
6698 041462 004737 042240
6699 041466
      041466 052737 140000 177776

6700 041474
      041474 004537 043744
      041500 040000
      041502 100000
      041504 000000

6701 041506 104417
6702 041510 042737 000040 172516
6703 041516 013700 002400
6704 041522 006200
6705 041524
      041524 103003
6706 041526 012737 100000 170200
6707 041534
      041534

6708 041534 010037 170202
6709 041540 004737 042026
6710 041544 052737 000040 172516
6711 041552 042737 001001 177572
6712 041560 004737 042322
6713 041564 052737 001001 177572
6714 041572
      041572 012737 177777 002134
6715 041600
      041600 000241
      041602 000207

```

RELOC1: LET NEWBANK :- RO

```

CALL USERMAP
USER
BIS #BIT15,BIT14,PSW
.DSABL CRF
BMOV 0,100000,SIZE
      JSR R5,BLOCK3
      SIZE
      100000
      0
      .DSABL CRF
KERNEL
BIC #BIT5,MMR3
MOV NEWBANK,RO
ASR RO
ON.ERROR

MOV #BIT15,MAPLO
END ;OF ON.ERROR

MOV RO,MAPHO
CALL LOWMAP
BIS #BIT5,MMR3
BIC #BIT9:BIT0,MMR0
CALL NEWKERNEL
BIS #BIT9:BIT0,MMR0
SET RLFLAG

$RETURN NOERROR

```

```

MOV RO,NEWBANK
;MAP NEWBANK TO USER PAR
;ENTER USER MODE
;DO IT TO IT!

;MOVE PROGRAM

;ENTER KERNEL MODE
;TURN OFF UNIBUS MAP

BCC L460

L460:;;;;;

;SETUP LOWER 16K IN UNIBUS MAP
;ENERGIZE UNIBUS MAP
;DEENERGIZE MEMORY MANAGEMENT - BUT DON'T TRAP
;ENERGIZE MEMORY MANAGEMENT - BUT DON'T TRAP

MOV #-1,RLFLAG

CLC
RTS PC

```

6718 041604

```
UNRELOCATE: SUBTST      <<UNRELOCATE PROGRAM>>
:*****
:*SUBTEST      UNRELOCATE PROGRAM
:*****
```

```
6719
6720 041604          :RESTORE LOADERS
      041604 010046   PUSH      RO
                                MOV RO,-(SP)
6721 041606 013701   MOV      LOADBANK,R1
6722 041612 013700 002532 MOV      LOADHOME,R0
6723 041616 004737 042072 CALL     BANKMOV
6724 041622 004737 042370 CALL     NEWLOAD      ;MAP NEW LOADER BANK IN KERNEL SPACE
6725 041626          PUSH     BANK
                                MOV BANK,-(SP)
      041626 013746 002106 MU.      LOADBANK,BANK
6726 041632 013737 002532 002106 CA      EXBANK
6727 041640 004737 042422 MUV     BANKINDEX,R1
6728 041644 013701 002110 BIC     #BIT15,CONFIG+2(R1) ;CLEAR LOADER FLAG
6729 041650 042761 100000 003020 MOV     LOADHOME,BANK
6730 041656 013737 002710 002106 CALL    EXBANK
6731 041664 004737 042422 MOV     BANKINDEX,R1
6732 041670 013701 002110 BIC     #BIT13,CONFIG+2(R1) ;INVALIDATE BACKGROUND PATTERN
6733 041674 042761 020000 003020 POP     BANK
6734 041702          MOV (SP)+,BANK
      041702 012637 002106
6735
6736          :RESTORE BANK 0
6737 041706 042737 020000 003020 BIC     #BIT13,CONFIG+2 ;INVALIDATE BACKGROUND PATTERN
6738 041714          LET NEWBANK := #0
                                CLR NEWBANK
      041714 005037 002400 CALL     USERMAP      ;MAP NEWBANK TO USER PAR
6739 041720 004737 042240 USER     ;ENTER USER MODE
6740 041724          BIS      #BIT15:BIT14,PSW ;DO IT TO IT:
      041724 052737 140000 177776 .DSABL  CRF
6741 041732          BMOV     0,100000,SIZE ;MOVE PROGRAM
      041732 004537 043744 JSR     R5,BLOCK3
      041736 040000          SIZE
      041740 100000          100000
      041742 000000          0
                                .DSABL  CRF
6742 041744 104417          KERNEL ;ENTER KERNEL MODE
6743 041746 042737 001001 177572 BIC     #BIT9:BIT0,MMR0 ;DEENERGIZE MEMORY MANAGEMENT - BUT DON'T TRAP
6744 041754 004737 042322 CALL     NEWKERNEL
6745 041760 052737 001001 177572 BIS     #BIT9:BIT0,MMR0 ;ENERGIZE MEMORY MANAGEMENT - BUT DON'T TRAP
6746 041766 005037 002134 CLR     RLFLAG
6747 041772 042737 000040 172516 BIC     #BITS,MMR3 ;TURN OFF UNIBUS MAP
6748 042000          CLEAR    MAPLO,MAPHO
      042000 005037 170200          CLR MAPLO
      042004 005037 170202          CLR MAPHO
6749 042010 004737 042026 CALL     LOWMAP      ;SETUP LOWER 16K OF UNIBUS MAP
6750 042014 052737 000040 172516 BIS     #BITS,MMR3 ;ENERGIZE UNIBUS MAP
6751 042022          POP     RO
                                MOV (SP)+,RO
      042022 012600
6752 042024 000207          RETURN
6753
6754 042026
```

```
LOWMAP: SUBTST <<SETUP LOWER 16K OF UNIBUS MAP>>
:*****
:*SUBTEST      SETUP LOWER 16K OF UNIBUS MAP
:*****
```

6755	042026	010046		PUSH	R0,R1,R2		
	042030	010146				MOV R0,-(SP)	
	042032	010246				MOV R1,-(SP)	
6756	042034	012700	170200	MOV	#MAPL0,R0	MOV R2,-(SP)	
6757	042040	012701	170204	MOV	#MAPL1,R1		
6758	042044	012702	000003	MOV	#3,R2		
6759	042050	012011		1\$:	MOV	(R0)+,(R1)	
6760	042052	062721	020000	ADD	#BIT13,(R1)+		
6761	042056	012021		MOV	(R0)+,(R1)+		
6762	042060	077205		SOB	R2,1\$		
6763	042062	012602		POP	R2,R1,R0		
	042064	012601				MOV (SP)+,R2	
	042066	012600				MOV (SP)+,R1	
6764	042070	000207		RETURN		MOV (SP)+,R0	

6767 042072

BANKMOV:SUBST <<MOVE BANKS>>
:.....
: *SUBTEST MOVE BANKS
:.....

6768
6769
6770
6771
6772 042072 104415
6773 042074 004737 042240
6774 042100 104416
6775 042102 104415
6776 042104 072027 000011
6777 042110 072127 000011
6778 042114 012702 177650
6779 042120 012703 000200

:MOVE 3/4 OF A BANK
:CALLING SEQUENCE
:R0 = DESTINATION BANK
:R1 = SOURCE BANK
SAVREG
CALL USERMAP
RESREG
SAVREG
ASH #9.,R0
ASH #9.,R1
MOV #UIPAR4,R2
MOV #200,R3

6780
6781 042124 010122
6782 042126 060301
6783 042130 010122
6784 042132 060301
6785
6786 042134 010022
6787 042136 060300
6788 042140 010022
6789 042142 060300

MOV R1,(R2)+ ;MAP 1ST HALF BANK
ADD R3,R1 ;BUMP BY 4K
MOV R1,(R2)+
ADD R3,R1
MOV R0,(R2)+
ADD R3,R0
MOV R0,(R2)+
ADD R3,R0

6790
6791 042144
042144 052737 140000 177776

USER
BIS #BIT15:BIT14,PSW ;DO IT TO IT.
.DSABL CRF

6792 042152
042152 004537 043744
042156 020000
042160 140000
042162 100000

BMOV 10000,140000,SIZE/2 ;MOV 1ST HALF BANK
JSR R5,BLOCK3
SIZE/2
140000
100000
.DSABL CRF

6793 042164 104417
6794

KERNEL CRF ;ENTER KERNEL MODE

6795 042166 012702 177650
6796
6797 042172 010122
6798 042174 060301
6799 042176 010122
6800 042200 060301

MOV #UIPAR4,R2
MOV R1,(R2)+ ;MAP 2ND HALF BANK
ADD R3,R1 ;BUMP BY 4K
MOV R1,(R2)+
ADD R3,R1

6801
6802 042202 010022
6803 042204 060300
6804 042206 010022
6805 042210 060300
6806

MOV R0,(R2)+
ADD R3,R0
MOV R0,(R2)+
ADD R3,R0

6807 042212
042212 052737 140000 177776

USER
BIS #BIT15:BIT14,PSW ;DO IT TO IT.
.DSABL CRF

6808 042220
042220 004537 043744
042224 010000
042226 140000

BMOV 10000,140000,SIZE/4 ;MOV 3RD FOURTH OF BANK
JSR R5,BLOCK3
SIZE/4
140000

	042230	100000		100000	
				.DSABL	CRF
6809	042232	104417	KERNEL		;ENTER KERNEL MODE
6810					
6811	042234	104416	RESREG		
6812	042236	000207	RETURN		

6815 04224

```
USERMAP:SUBTST <<SUBR MAP USER TO NEW BANK>>
:*****
:*SUBTEST SUBR MAP USER TO NEW BANK
:*****
```

```
6816 042240 012701 177640
6817 042244 012702 172340
6818 042250 012703 177600
6819 042254 012704 172300
6820 042260 012705 000004
6821 042264 012221
6822 042266 011423
6823 042270 077503
6824
6825 042272 013700 002400
6826 042276 072027 000011
6827
6828 042302 012705 000004
6829 042306 010021
6830 042310 062700 000200
6831 042314 011423
6832 042316 077505
6833 042320 000207
6834
6835 042322
```

```
MOV #UIPAR0,R1 ;COPY KERNEL PAR'S & PDR'S (0-3)
MOV #KIPAR0,R2
MOV #UIPDR0,R3
MOV #KIPDR0,R4
MOV #4,R5
%: MOV (R2)+,(R1)+
MOV (R4),(R3)+
SOB R5,1$
MOV NEWBANK,R0
ASH #9.,R0 ;BANK 1 STARTS AT 100,000 LESS 6 LSB'S
;FOR MEMORY MANAGEMENT = 1000
MOV #4,R5
%: MOV R0,(R1)+ ;SETUP UIPAR(4-7)
ADD #200,R0 ;BUMP ADDRESS 4K
MOV (R4),(R3)+ ;SETUP UIPDR(4-7)
SOB R5,2$
RETURN
```

```
NEWKERNEL:SUBTST <<SUBR SETUP KERNEL PAR'S FOR NEW BANK>>
:*****
:*SUBTEST SUBR SETUP KERNEL PAR'S FOR NEW BANK
:*****
```

```
6836 042322
042322 010046
042324 010146
042326 010546
6837 042330 012700 172340
6838 042334 013701 002400
6839 042340 072127 000011
6840
6841 042344 012705 000004
6842 042350 010120
6843 042352 062701 000200
6844 042356 077504
6845 042360
042360 012605
042362 012601
042364 012600
6846 042366 000207
6847
6848 042370
```

```
PUSH R0,R1,R5
MOV R0,-(SP)
MOV R1,-(SP)
MOV R5,-(SP)
MOV #KIPAR0,R0
MOV NEWBANK,R1
ASH #9.,R1 ;BANK 1 STARTS AT 100,000 LESS 6 LSB'S
;FOR MEMORY MANAGEMENT = 1000
MOV #4,R5
%: MOV R1,(R0)+ ;SETUP KIPAR(0-3)
ADD #200,R1
SOB R5,1$
POP R5,R1,R0
MOV (SP)+,R5
MOV (SP)+,R1
MOV (SP)+,R0
RETURN
```

```
NEWLOAD:SUBTST <<SUBR SETUP KERNEL PAR'S FOR NEW LOADER BANK>>
:*****
:*SUBTEST SUBR SETUP KERNEL PAR'S FOR NEW LOADER BANK
:*****
```

```
6849
6850 042370
042370 010046
042372 010146
6851 042374 012701 172350
6852 042400 072027 000011
6853 042404 010021
6854 042406 062700 000200
```

```
;R0 CONTAINS THE DESTINATION BANK
PUSH R0,R1
MOV R0,-(SP)
MOV R1,-(SP)
MOV #KIPAR4,R1
ASH #9.,R0 ;BANK 1 STARTS AT 1000000 LESS 6 LSB'S (1000)
MOV R0,(R1)+ ;SETUP KIPAR4
ADD #200,R0
```

6855 042412 010021
6856 042414
042414 012601
042416 012600
6857 042420 000207

MOV R0,(R1)+
POP R1,R0

RETURN

;SETUP KIPARS

MOV (SP)+,R1
MOV (SP)+,R0

6861 042422

EXBANK: SUBST <<SUBR EXAMINE BANK>>

 *SUBTEST SUBR EXAMINE BANK

6862
 6863
 6864
 6865
 6866
 6867
 6868
 6869
 6870
 6871
 6872
 6873
 6874
 6875
 6876

DOES THE FOLLOWING:
 (1) SETS UP 'BANKINDEX' AND R0 BASED ON VALUE OF 'BANK'
 (2) SETS THE 'MKFLAG' IF THE BANK IS AN MK11
 (3) SETS THE 'KPFLAG' IF THE BANK IS THE PROTECTED REGION OF MK11 MEMORY
 (4) SETS THE 'ACFLAG' IF THE BANK CAN BE ACCESSED BY THIS CPU
 (5) SETS THE 'PFLAG' IF THE BANK IS IN PROGRAM SPACE
 (6) SETS THE 'RRFLAG' IF RELOCATION IS REQUIRED TO TEST THIS BANK
 HOWEVER, IT COMPLEMENTS THIS FLAG IF THE RELOCATION FLAG 'RLFLAG' IS SET
 (THIS IS NECESSARY FOR THE USE OF THE RECURSIVE 'MODE' SUBROUTINES)
 BUT, THE 'RRFLAG' IS ALWAYS SET TO DISABLE TESTING IF FIELD SERVICE MODE
 'SELECTED BANKS' ARE BEING TESTED AND THIS BANK IS NOT SELECTED.
 (7) SETS THE 'BMFLAG' IF THE BANK IS A BAD MEMORY
 HOWEVER, IT COMPLEMENTS THIS FLAG IF THE 'WORST' FLAG IS NOT SET
 (THIS IS NECESSARY FOR THE USE OF THE RECURSIVE 'MODE' SUBROUTINES)

042422
 042424
 042426
 6877 042430
 042430
 042434
 6878 042440
 042440
 6879 042446
 042446
 042452
 042456
 6880 042462
 6881 042466
 6882 042472
 6883 042476
 6884 042504
 6885 042506
 042506
 042514
 6886 042522
 6887 042526
 042526
 042530
 6888 042530
 042530
 042534
 042536
 042542
 6889 042544
 6890 042550
 042550
 6891 042550
 6892 042552
 042552
 042554
 042560
 042562

010046
 010146
 010246
 005037 002126
 005037 002122
 012737 177777 002124
 005037 002130
 005037 002132
 005037 002136
 013701 002106
 070127 000006
 010137 002110
 032761 010000 003016
 001406
 012737 177777 002122
 012737 177777 002132
 012700 000020
 005002
 030037 002114
 001405
 030061 003016
 001002
 005037 002124
 042550
 006300
 042552
 005202
 020237 002730
 003763

PUSH R0,R1,R2
 CLEAR MKFLAG,KPFLAG
 SET ACFLAG
 CLEAR PFLAG,RRFLAG,BMFLAG
 MOV BANK,R1
 MUL #6,R1 ;R0 - BANK * 6
 MOV R1,BANKINDEX
 BIT #BIT12,CONFIG(R1) ;PROTECTED REGION OF MK11 MEMORY?
 BEQ 1\$;NO - SKIP
 SET KPFLAG,RRFLAG
 1\$: MOV #MASTER,R0
 FOR R2 :- #0 TO SLAVES
 CLR R2
 B63:.....
 IF R0 SET.IN CPUBIT AND R0 OFF.IN CONFIG(R1)
 BIT R0,CPUBIT
 BEQ L461
 BIT R0,CONFIG(R1)
 BNE L461
 CLR ACFLAG
 END ;OF IF R0
 L461:.....
 ASL R0
 END ;OF FOR R2
 INC R2
 CMP R2,SLAVES
 BLE B63
 E63:.....

SUBR EXAMINE BANK

```

6893 042562 016100 003016 2$: MOV CONFIG(R1),R0
6894 042566 042700 117777 BIC #*(60000,R0 ;GET MEMORY TYPE BITS
6895 042572 022700 020000 CMP #20000,R0 ;IS IT AN MK11?
6896 042576 001003 BNE 3$ ;NO - SKIP
6897 042600 SET MKFLAG
042600 012737 177777 002126 MOV #-1,MKFLAG
6898 042606 032761 100000 003016 3$: BIT #BIT15,CONFIG(R1) ;BANK = PROGRAM SPACE?
6899 042614 001406 5$ BEQ ;NO - SKIP
6900 042616 SET PFLAG,RRFLAG
042616 012737 177777 002130 MOV #-1,PFLAG
042624 012737 177777 002132 MOV #-1,RRFLAG
6901 042632 005737 002134 5$: TST RLFLAG ;IS PROGRAM RELOCATED?
6902 042636 001402 6$ BEQ ;NO - SKIP
5903 042640 005137 002132 COM RRFLAG ;YES - COMPLEMENT RELOCATION REQUIRED FLAG
6904 042644 032761 004000 003016 6$: BIT #BIT11,CONFIG(R1) ;ERRORS PRESENT IN THIS BANK?
6905 042652 001403 8$ BEQ ;NO - SKIP
6906 042654 SET BMFLAG
042654 012737 177777 002136 MOV #-1,BMFLAG
6907 042662 005737 002712 8$: TST WORST ;IS THIS A WORST FIRST PASS?
6908 042666 001002 9$ BNE ;YES - SKIP
6909 042670 005137 002136 COM BMFLAG ;NO - COMPLEMENT BAD MEMORY FLAG
6910 042674 9$: IF SELONLY IS TRUE AND #BIT14 OFF, IN CONFIG+2(R1)
042674 005737 002002 TST SELONLY
042700 001407 BEQ L462
042702 032761 040000 003020 BIT #BIT14,CONFIG+2(R1)
042710 001003 BNE L462
6911 042712 SET RRFLAG MOV #-1,RRFLAG
042712 012737 177777 002132
6912 042720 END ;OF IF SELONLY
042720 POP R2,R1,R0 L462:::
6913 042720 POP R2,R1,R0 MOV (SP)+,R2
042720 012602 MOV (SP)+,R1
042722 012601 MOV (SP)+,R0
042724 012600
6914 042726 000207 RETURN

```

```
6918 042730 BANKOK: SUBST <<SUBR BANK OK?>>
:*****
:*SUBTEST SUBR BANK OK?
:*****
6919 :TEST TO INSURE THAT THE TYPE OF MEMORY IN THE PRESENT BANK
6920 :IS OF THE TYPE WE ARE TESTING 'TMFLAG'.
6921 :RESULT IS RETURNED IN THE CONDITION CODES (OK - (-0)).
6922 042730 013700 002140 MOV TMFLAG,R0
6923 042734 005100 COM R0
6924 042736 013701 002126 MOV MKFLAG,R1
6925 042742 074001 XOR R0,R1
6926 042744 000207 RETURN ;OK = (=OK)
6927
6928 042746 INCRPT:
6929 042746 INCPAT: SUBST <<SUBR INCREMENT PATTERN TESTING MK11'S>>
:*****
:*SUBTEST SUBR INCREMENT PATTERN TESTING MK11'S
:*****
6930 :INCREMENT THE PATTERN & SET UP THE CONDITION CODES
6931 :RESULT - Z BIT SET INDICATES OVERFLOW
6932 042746 005237 002120 INC PATTERN
6933 042752 022737 000040 002120 CMP #40,PATTERN ;SET UP CONDITION CODES
6934 042760 000207 RETURN ;NOT EQUAL TO ZERO IS GOOD (NO OVERFLOW)
6935
6936 042762 SETPAT:
6937 042762 HIPAT: SUBST <<SUBR SET HIGHEST PATTERN TESTING TYPE>>
:*****
:*SUBTEST SUBR SET HIGHEST PATTERN TESTING TYPE
:*****
6938 042762 012737 000037 002120 MOV #37,PATTERN ;SET HIGHEST PATTERN
6939 042770 000207 RETURN
6940
6941 042772 INCBNK: SUBST <<SUBR INCREMENT BANK & TEST>>
:*****
:*SUBTEST SUBR INCREMENT BANK & TEST
:*****
6942 :RESULTS RETURNED IN CONDITION CODES
6943 042772 005237 002106 INC BANK
6944 042776 022737 000170 002106 CMP #120.,BANK ;TOO FAR?
6945 043004 000207 RETURN
```

6948 043006

INCMAR: SUBST <<SUBR INCREMENT MARGINS & TEST>>
:*****
:SUBTEST SUBR INCREMENT MARGINS & TEST
:*****

6949
6950
6951
6952 043006 032777 004000 137752
043006 001004
043014 005737 002440
043016 001001
6953 043024
043024 000410
6954 043026
043026 013737 002112 002376
6955 043034 005037 002112
6956 043040 004737 043300
6957 043044 000435
6958 043046 013737 002112 002376 1\$:
6959 043054 005237 002112
6960 043060 022737 000001 002112
6961 043066 001002
6962 043070 005237 002112
6963 043074
6964 043074 005737 002126
043100 001005
043102 023727 002112 000006
043110 001401
6965 043112
043112 000412
6966 043114
043114
6967 043114
043114 005737 002126
043120 001405
043122 023727 002112 000004
043130 001401
6968 043132
043132 000402
6969 043134
043134
6970 043134 005037 002112
6971 043140 004737 043300
6972 043144 005737 002112
6973 043150 000207
6974
6975
6976 043152

:SKIPS THE SPECIAL CASE (MARGIN CANNOT = 1)
:RETURNS THE RESULT OF MARGIN OVERFLOW IN THE CONDITION CODES
.ENABL LSB
IF #SW11 OFF.IN @SWR AND QVFLAG IS FALSE

BIT #SW11,@SWR
BNE L463
TST QVFLAG
BNE L463

GOTO 1\$

BR 1\$

END ;OF IF #SW11

L463:;;;;;

MOV MARGIN,OLDMARGIN
CLR MARGIN ;YES - SET MARGIN TO ZERO

CALL COREHISTORY

BR 3\$

MOV MARGIN,OLDMARGIN

INC MARGIN

CMP #1,MARGIN ;SPECIAL CASE?

BNE 2\$;NO - SKIP

INC MARGIN ;YES - SET MARGIN TO '2'

2\$: IF MKFLAG IS FALSE AND MARGIN NE #6

TST MKFLAG
BNE L464
CMP MARGIN,#6
BEQ L464

GOTO 3\$

BR 3\$

END ;OF IF MKFLAG

L464:;;;;;

IF MKFLAG IS TRUE AND MARGIN NE #4

TST MKFLAG
BEQ L465
CMP MARGIN,#4
BEQ L465

GOTO 3\$

BR 3\$

END ;OF IF MKFLAG

L465:;;;;;

3\$: CLR MARGIN ;YES - SET MARGIN TO ZERO

CALL COREHISTORY

TST MARGIN

;SET CONDITION CODE - DONE IF 2 BIT SET

RETURN

.DSABL LSB

DECMAR: SUBST <<DECREMENT MARGINS & TEST>>
:*****
:SUBTEST DECREMENT MARGINS & TEST
:*****

6977
6978
6979 043152 013737 002112 002376
6980 043160 005337 002112

:SKIPS THE SPECIAL CASE (MARGIN CANNOT = 1)
:RETURNS THE RESULT OF MARGIN UNDERFLOW IN THE CONDITION CODES

MOV MARGIN,OLDMARGIN

DEC MARGIN

6981 043164 022737 090001 002112
6982 043172 001002
6983 043174 005337 002112
6984 043200 004737 043300
6985 043204 005737 002112
6986 043210 000207

18:

OMP #1,MARGIN
BNE 18
DEC MARGIN
CALL COREHISTORY
TST MARGIN
RETURN

:SPECIAL CASE?
:NO - SKIP
:YES - SET MARGIN TO '0'
:SETUP CONDITION CODES - NEGATIVE IS UNDERFLOW

```

6989 043212 SETMAR: SUBTST <<SUBR SET HIGHEST MARGIN>>
;*****
;*SUBTEST SUBR SET HIGHEST MARGIN
;*****
6990 ;RECOGNIZES THE "INHIBIT MARGINS SWITCH"
6991 .ENABL LSB
6992 043212 IF #SW11 SET.IN @SWR OR QVFLAG IS TRUE
043212 032777 004000 137546 BIT #SW11,@SWR
043220 001003 BNE L466
043222 005737 002440 TST QVFLAG
043226 001401 BEQ L467
043230 L466:*****
6993 043230 GOTO 1$ BR 1$
043230 000420
6994 043232 END ;OF IF #SW11 L467:*****
043232
6995 043232 013737 002112 002376 MOV MARGIN,OLDMARGIN
6996 043240 005737 002126 IF MKFLAG IS FALSE TST MKFLAG
043244 001004 BNE L470
6997 043246 012737 000005 002112 MOV #5,MARGIN ;HIGHEST MJ11 MARGIN
6998 043254 ELSE BR L471
043254 000403 L470:*****
6999 043256 012737 000003 002112 MOV #3,MARGIN ;HIGHEST MK11 MARGIN
7000 043264 END ;OF IF MKFLAG L471:*****
043264
7001 043264 004737 043300 CALL COREHISTORY
7002 043270 000402 BR 2$ ;SKIP
7003 043272 005037 002112 1$: CLR MARGIN ;SET MARGIN TO '0'
7004 043276 000207 2$: RETURN
7005 .DSABL LSB
7006 043300 COREHISTORY:SUBTST <<SUBR REWRITE CORE HISTORY>>
;*****
;*SUBTEST SUBR REWRITE CORE HISTORY
;*****
7007 043300 IF MKFLAG IS FALSE AND NULLFLAG IS FALSE
043300 005737 002126 *ST MKFLAG
043304 001041 BNE L472
043306 005737 002436 TST NULLFLAG
043312 001036 BNE L472
7008 043314 IF OLDMARGIN NE MARGIN
043314 023737 002376 002112 CMP OLDMARGIN,MARGIN
043322 001432 BEQ L473
7009 043324 IF OLDMARGIN EQ #4 OR OLDMARGIN EQ #5 OR MARGIN EQ #4 OR MARGIN EQ #5
043324 023727 002376 000004 CMP OLDMARGIN,#4
043332 001414 BEQ L474
043334 023727 002376 000005 CMP OLDMARGIN,#5
043342 001410 BEQ L474
043344 023727 002112 000004 CMP MARGIN,#4
043352 001404 BEQ L474
043354 023727 002112 000005 CMP MARGIN,#5
043362 001012 BNE L475
043364 L474:*****
7010 043364 013700 002112 MOV MARGIN,RO
7011 043370 006300 ASL RO
7012 043372 010037 177750 MOV RO,MAINT ;SET MARGINS
    
```

```
7013  
7014 043376          LET R2 := ONES  
          043376 013702 002726          MOV ONES,R2  
7015 043402 004737 035344          CALL    BACKGND  
7016 043406 104511          INVALIDATE  
7017 043410          END ;OF IF  
          043410  
7018 043410          END ;OF IF  
          043410  
7019 043410          END ;OF IF  
          043410  
7020 043410 005037 002436          CLR    NULLFLAG  
7021 043414 000207          RETURN  
L475:.....  
L473:.....  
L472:.....
```

```

7024 043416      BOOT:  SUBST <<BOOTSTRAP ROUTINE>>
:*****
:SUBTEST      BOOTSTRAP ROUTINE
:*****
7025              :INITIALIZE ALL CSR'S
7026              :CLEAR ANY MARGINS
7027              :UNRELOCATE IF NECESSARY
7028              :FLUSH OUT ANY DBE'S
7029              :TURN OFF MEMORY MANAGEMENT
7030              :TURN OFF THE UNIBUS MAP
7031              :BOOT RKO OR RK1
7032 043416 104472  ECCINIT      ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
7033 043420          SET4      #BOOT1      ;TRAPS TO 4 GOTO BOOT1
       043420 012737 043460 000004  MOV      #BOOT1,4
7034 043426 005037 177750  .DSABL   CRF
7035 043432          CLR      MAINT
       043432 005737 002134  IF RLFLAG IS TRUE THEN $CALL UNRELOCATE
       043436 001402          TST   RLFLAG
       043440 004737 041604  BEQ   L476
       043444          JSR   PC,UNRELOCATE
                                L476:*****
7036 043444 004737 024754  CALL    M10030      ;FLUSH OUT DBE'S
7037 043450 104421  DEENERGIZE      ;TURN OFF MEMORY MANAGEMENT
7038 043452 042737 000040 172516  BIC    #BIT5,MMR3      ;TURN OFF THE UNIBUS MAP
7039 043460 005001  BOOT1: CLR    R1
7040 043462 000005  1$:   RESET
7041 043464 012700 177406  MOV    #177406,R0
7042 043470 010160 000004  MOV    R1,4(R0)
7043 043474 012710 177400  MOV    #177400,(R0)
7044 043500 012740 000005  MOV    #5,-(R0)
7045 043504 105710  2$:   TSTB  (R0)
7046 043506 100376  BPL    2$
7047 043510 062701 020000  ADD    #BIT13,R1
7048 043514 005710  TST    (R0)
7049 043516 100761  BMI    1$
7050 043520 005007  CLR    PC
  
```

```

7053 043522
7054 043522 004737 043554
7055 043526 005737 002444
      043532 001003
      043534 005737 002442
      043540 001402
      043542
7056 043542 000777
7057 043544
      043544 000403
      043546
7058 043546 000000
7059 043550 000137 004352
7060 043554
      043554
7061
7062 043554

7063
7064
7065
7066
7067
7068
7069
7070
7071 043554 104472
7072 043556 005037 177750
7073 043562
      043562 005737 002134
      043566 001402
      043570 004737 041604
      043574
7074 043574
      043574 005737 002536
      043600 001002
7075 043602 004737 024754
7076 043606
      043606
7077 043606 012700 000001
7078 043612 013701 002710
7079 043616 004737 042072
7080 043622 104421
7081 043624 042737 000040 172516
7082 043632 005037 002670
7083 043636 000207
7084
7085 043640

```

```

EXIT:  SUBTST  <<HALT PROGRAM>>
:*****
:*SUBTEST    HALT PROGRAM
:*****
      CALL    SHUTUP
EXIT2:  IF APTFLAG IS TRUE OR ACTFLAG IS TRUE

      TST APTFLAG
      BNE L477
      TST ACTFLAG
      BEQ L500
L477:*****

      BR L501
      ELSE
L500:*****

$EXHALT: HALT
        JMP   START
        END ;OF IF APTFLAG
L501:*****

SHUTUP: SUBTST  <<SHUTDOWN DIAGNOSTIC>>
:*****
:*SUBTEST    SHUTDOWN DIAGNOSTIC
:*****
      :INITIALIZE ALL CSR'S
      :CLEAR MARGINS
      :UNRELOCATE
      :FLUSH OUT DBE'S
      :RESTORE LOADERS
      :TURN OFF MEMORY MANAGEMENT
      :UNMAP THE UNIBUS MAP
      :CLEAR MULTIPROCESSING LOCK
      ECCINIT      ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
      CLR         MAINT
      IF RLFLAG IS TRUE THEN $CALL UNRELOCATE

      TST RLFLAG
      BEQ L502
      JSR PC,UNRELOCATE
L502:*****

      IF QUICK IS FALSE

      TST QUICK
      BNE L503
L503:*****

      CALL MT0030      ;FLUSH OUT DBE'S
      END ;OF IF QUICK

      MOV #1,R0        ;DESTINATION BANK
      MOV LOADHOME,R1 ;SOURCE BANK
      CALL BANKMOV
      DEENERGIZE      ;TURN OFF MEMORY MANAGEMENT
      BIC #BITS5,MMR3 ;TURN OFF UNIBUS MAP
      CLR LOCK
      RETURN

APTDOWN:SUBTST  <<APT SHUTDOWN SEQUENCE>>
:*****
:*SUBTEST    APT SHUTDOWN SEQUENCE
:*****

```

```
7086 043640      MAP      #0      ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
      043640      010346
      043642      012703      000000
      043646      004737      040700
      MOV      #0,R3
      CALL     MAPPER
      .DSABL   CRF
      MOV      (SP)+,R3

7087 043652      012603
      043654      052737      040000      177776
      SUPERVISOR
      BIS      #BIT14,PSW      ;ENTER SUPERVISOR MODE
      .DSABL   CRF      ;DO IT TO IT

7088 043662      012737      043640      060024
7089 043670      012737      00034C      06002E
7090 043676      012737      000000      123640
7091 043704      104417
7092 043706      000000
      MOV      #APTDOWN,FIRST+24
      MOV      #340,FIRST+26
      MOV      #0,FIRST+APTDOWN
      KERNEL
      APTHLT: HALT      ;ENTER KERNEL MODE
```

7095 043710

```

SUBTST <<BLOCK MOVE SUBROUTINE>>
:.....
:SUBTEST   BLOCK MOVE SUBROUTINE
:.....
:BLOCK3 HAS 3 ARGUEMENTS
:BLOCK2 HAS 2 ARGUEMENTS
:BLOCK1 HAS 1 ARGUEMENTS
:
:ALL ARE CALLED BY THE BMOV MACRO
:ENABL   LSB
BLOCK1: PUSH   R0,R1,R2
:
:MOV     #FASTCITY,R2
:MOV     #16.,R1
:BR      3$
:
BLOCK2: PUSH   R0,R1,R2
:
:MOV     #16.,R1
:BR      2$
:
BLOCK3: PUSH   R0,R1,R2
:
:MOV     (R5)+,R1
2$: MOV     (R5)+,R2
3$: MOV     (R5)+,R0
:
1$: MOV     (R0)+,(R2)+
:SOB    R1,1$
:POP    R2,R1,R0
:
:MOV     (SP)+,R2
:MOV     (SP)+,R1
:MOV     (SP)+,R0
:
:RTS    R5
:DSABL  LSB
  
```

7096
 7097
 7098
 7099
 7100
 7101
 7102 043710 010046
 043710 010046
 043712 010146
 043714 010246
 7103 043716 012702 177640
 7104 043722 012701 000020
 7105 043726 000413
 7106
 7107 043730
 043730 010046
 043732 010146
 043734 010246
 7108 043736 012701 000020
 7109 043742 000404
 7110
 7111 043744
 043744 010046
 043746 010146
 043750 010246
 7112 043752 012501
 7113 043754 012502
 7114 043756 012500
 7115
 7116 043760 012022
 7117 043762 077102
 7118 043764
 043764 012602
 043766 012601
 043770 012600
 7119 043772 000205
 7120

7122
 7123
 7124 043774

.SBTTL FIELD SERVICE MODE

FIELDSERVICE:SUBSTST <<SUBR FIELD SERVICE COMMAND MODE>>
 :*****
 :*SUBTEST SUBR FIELD SERVICE COMMAND MODE
 :*****

7125 043774 104415
 7126 043776 104401 112170
 043776 104401

SAVREG
 TYPE MSG020 ;FIELD SERVICE COMMAND MODE
 TYPEIT ,MSG020
 .DSABL CRF

7127
 7128 044002 005737 002134
 044006 001003
 044010 005737 002526
 044014 001404
 044016

IF RLFLAG IS TRUE OR NOFSMODE IS TRUE
 TST RLFLAG
 BNE L504
 TST NOFSMODE
 BEQ L505

7129 044016 104401 114303
 044016

TYPE MSG048 ;NOT AVAILABLE NOW - TRY LATER!
 TYPEIT ,MSG048
 .DSABL CRF

7130 044022 104416
 7131 044024 000207
 7132 044026 044026

RESREG
 RETURN
 END ;OF IF RLFLAG

7133 044026 013746 177746
 044032 013746 002256
 044036 013746 002010

PUSH CONTRL,CSRNO,KAMIKAZE ;SAVE CACHE STATUS

L504:::~::~
 MOV CONTRL,-(SP)
 MOV CSRNO,-(SP)
 MOV KAMIKAZE,-(SP)

7134 044042 104424
 7135 044044 012737 177777 002010

CACHOFF ;TURN CACHE OFF
 SET KAMIKAZE

7136 044052 104401 113371

FS1: TYPE MSG026 ;COMMAND:
 TYPEIT ,MSG026
 .DSABL CRF

7137 044056 104414
 7138 044060 012600 000024
 044060 020027

RDDEC ;READ A DECIMAL NUMBER
 POP RO ;COMMAND --> RO

MOV (SP)+,RO

7139 044062 101403
 7140 044070 104401 112224
 044070

CMP RO,#20.
 BLOS 1\$
 TYPE MSG021
 TYPEIT ,MSG021
 .DSABL CRF
 BR FS1

7142 044074 000766
 7143 044076 010046 006316 044160
 044100 004737
 044102 044170

FS: CASE RO

MOV RO,-(SP)
 ASL @SP
 JSR PC,L506

7144 044106 044256
 7145 044112 044346
 7146 044114 044520
 7147 044116 044764
 7148 044120 045274
 7149 044122 046152
 7150 044124 046160
 7151 044126 046510
 7152 044130 047104

FSCMD0 ;EXIT FIELD SERVICE COMMANDS
 FSCMD1 ;READ CSR
 FSCMD2 ;LOAD CSR
 FSCMD3 ;EXAMINE MEMORY
 FSCMD4 ;MODIFY MEMORY
 FSCMD5 ;SELECT BANK,MARGIN, & PATTERN
 FSCMD6 ;TYPE CONFIGURATION MAP
 FSCMD7 ;BATTERY BACKUP - P/F TEST
 FSCMD8 ;SOB-A-LONG TEST
 FSCMD9 ;SUPER TIGHT SCOPE LOOP

7154 044132 047550
7155 044134 047734
7156 044136 050330
7157 044140 050356
7158 044142 050400
7159 044144 050420
7160 044146 050436
7161 044150 050454
7162 044152 050470
7163 044154 050502
7164 044156 050566
7165 044160
044160
044160 062616
044162 013646
044164 004736
7166 044166 000731

FCMD10
FCMD11
FCMD12
FCMD13
FCMD14
FCMD15
FCMD16
FCMD17
FCMD18
FCMD19
FCMD20
END ;OF CASE

;ERROR SUMMARY
;REFRESH TEST
;SET FILL COUNT
;ENTER KAMIKAZE MODE
;EXIT KAMIKAZE MODE
;TURN CACHE OFF
;TURN CACHE ON
;RUN ONLY MULTIPOST TESTS
;RESUME RUNNING BOTH SINGLE & MULTIPOST TESTS
;TEST ONLY SELECTED BANKS
;RESUME TESTING ALL BANKS

L506:::~::~
ADD (SP)+,@SP
MOV @ (SP)+,-(SP)
JSR PC,@(SP)+

BR F51

```

7169 044170          FSCMD0: SUBTST <<COMMAND 0      EXIT>>
:*****
: *SUBTEST          COMMAND 0      EXIT
:*****
7170 044170          TYPE          MSG103          ;LEAVING FIELD SERVICE MODE
044170 104401 116364 TYPEIT          ,MSG103
7171 044174 062706 000002 .DSABL          CRF
7172 044200 005737 002012 ADD          #2,SP
044204 001405          IF SKIPKAMI IS TRUE
7173 044206 062706 000002          ADD #2,SP          ;THROW AWAY OLD KAMIKAZE FLAG
7174 044212 005037 002012          CLR          SKIPKAMI
7175 044216 000402          ELSE
044216 000402          BR L510
7176 044220          POP          KAMIKAZE          ;RESTORE OLD KAMIKAZE FLAG
044220 012637 002010          ;L507:::
7177 044224          END ;OF IF SKIPKAMI          MOV (SP)+,KAMIKAZE
044224          L510:::
7178 044224          POP          CSRNO
044224 012637 002256          MOV (SP)+,CSRNO
7179 044230          IF CACHK EQ #BIT0!BIT2!BIT3.BIT8.BIT9 ;IF CACHE IS OFF
044230 023727 002700 001415          CMP CACHK,#BIT0!BIT2!BIT3!BI
044236 001003          BNE L511
7180 044240 062706 000002          ADD #2,SP          ;THROW AWAY CACHE STATUS
7181 044244 000402          ELSE
044244 000402          BR L512
7182 044246          POP          CONTRL          ;RESTORE CACHE STATUS
044246 012637 177746          ;L511:::
7183 044252          END ;OF IF CACHK          MOV (SP)+,CONTRL
044252          L512:::
7184 044252 104416          RESREG
7185 044254 000207          RETURN
7186
7187 044256          FSCMD1: SUBTST <<FS      COMMAND 1      READ CSR>>
:*****
: *SUBTEST          FS      COMMAND 1      READ CSR
:*****
7188 044256 004737 050630          CALL          WHICHCSR
7189 044262 010637 002374          MOV          SP,FSSTACK
7190 044266 012737 044322 000004          SET4          #1$          ;TRAPS TO 4 GOTO 1$
044266          MOV          #1$,4
7191 044274 104426          .DSABL          CRF
7192 044276          READCSR
044276 012737 177777 002530          SET          NOERROR
7193 044304 104026          ERROR          +26          MOV #-1,NOERROR
7194 044306          RES4          ;USE ERROR ROUTINE FOR PRINTOUT
044306 012737 036726 000004          MOV          #TIMEOUT,4          ;RESET TRAPS TO 4 TO DEFAULT
044314 005037 177766          CLR          CPUERR          ;CLEAR OUT THE CPU ERROR REGISTER BITS
;THAT A EXPECTED TRAP COULD HAVE SET
7195 044320 000207          .DSABL          CRF
7196 044322          RETURN
044322 104401 113340          1$:          TYPE          MSG025          ;THIS CSR DOES NOT EXIST
044322          TYPEIT          ,MSG025
  
```

7197 044326 013706 002374
7198 044332
044332 012737 036726 000004
044340 005037 177766

7199 044344 000207

.DSABL CRF
MOV FSSTACK,SP
RES4
MOV #TIMEOUT,4
CLR CPUERR

.DSABL CRF
RETURN

:RESET TRAPS TO 4 TO DEFAULT
:CLEAR OUT THE CPU ERROR REGISTER BITS
:THAT A EXPECTED TRAP COULD HAVE SET

FS COMMAND 1 READ CSR

7202 044346

FSCMD2: SUBST <<FS COMMAND 2 LOAD CSR>>

 :*SUBTEST FS COMMAND 2 LOAD CSR

7203 044346 004737 050630
 7204 044352 010637 002374
 7205 044356 012737 044474 000004

CALL WHICHCSR
 MOV SP,FSSTACK
 SET4 #1\$;TRAPS TO 4 GOTO 1\$
 MOV #1\$,4
 .DSABL CRF

7206 044364 104426
 7207 044366 104401 113403

READCSR
 TYPE MSG027
 TYPEIT ,MSG027
 .DSABL CRF
 SET NOERROR

7208 044372 012737 177777 002530
 7209 044400 104026
 7210 044402 012737 036726 000004
 044410 005037 177766

MOV #-1,NOERROR
 ERROR +26 ;USE ERROR ROUTINE FOR PRINTOUT
 RES4 ;RESET TRAPS TO 4 TO DEFAULT
 MOV #TIMEOUT,4
 CLR CPUERR ;CLEAR OUT THE CPU ERROR REGISTER BITS
 ;THAT A EXPECTED TRAP COULD HAVE SET

7211 044414 104401 113274

.DSABL CRF
 TYPE MSG023 ;FIRST CSR WORD
 TYPEIT ,MSG023

7212 044420 104413
 7213 044422 012637 002144
 7214 044426 104401 113316

RDOCT ;READ AN OCTAL NUMBER
 POP CSR ;PUT IN IN LOC 'CSR'
 TYPE MSG024 ;2ND CSR WORD
 TYPEIT ,MSG024
 .DSABL CRF

7215 044432 104413
 7216 044434 012637 002146
 7217 044440 012737 177777 002600

RDOCT ;READ AN OCTAL NUMBER
 POP CSR+2 ;PUT IN IN LOC 'CSR+2'
 SET TWOCSRS
 MOV (SP)+,CSR
 MOV #-1,TWOCSRS

7218 044446 104425
 7219 044450 005037 002600
 7220 044454 104426
 7221 044456 104401 113420

LOADCSR
 CLR TWOCSRS
 READCSR
 TYPE MSG028
 TYPEIT ,MSG028
 .DSABL CRF
 SET NOERROR

7222 044462 012737 177777 002530
 7223 044470 104026
 7224 044472 000207
 7225 044474 104401 113340

MOV #-1,NOERROR
 ERROR +26 ;USE FOR PRINTOUT - NOT AN ERROR
 RETURN
 TYPE MSG025 ;THIS CSR DOES NOT EXIST
 TYPEIT ,MSG025
 .DSABL CRF

7226 044500 013706 002374
 7227 044504 012737 036726 000004
 044512 005037 177766

MOV FSSTACK,SP
 RES4 ;RESET TRAPS TO 4 TO DEFAULT
 MOV #TIMEOUT,4
 CLR CPUERR ;CLEAR OUT THE CPU ERROR REGISTER BITS
 ;THAT A EXPECTED TRAP COULD HAVE SET

7228 044516 000207

.DSABL CRF
 RETURN

```

7231 044520          FSCMD3: SUBST  <<FS  COMMAND 3  EXAMINE MEMORY>>
:.....
: *SUBTEST  FS  COMMAND 3  EXAMINE MEMORY
:.....
7232 044520          PUSH  BANK,NOPAR,PARHERE,4
044520 013746 002106          MOV BANK,-(SP)
044524 013746 002100          MOV NOPAR,-(SP)
044530 013746 002372          MOV PARTHERE,-(SP)
044534 013746 000004          MOV 4,-(SP)
7233 044540 012737 000002 002100  MOV #2,NOPAR ;INDICATE PARITY ACTION
7234 044546 104401 113434          TYPE MSG029 ;EXAMINE MEMORY
                                .DSABL CRF
7235 044552 104401 113473          1$: TYPE MSG031 ;PHYSICAL ADDRESS (0-16777776)??
                                TYPEIT ,MSG031
                                .DSABL CRF
7236 044556 104413          RDOCT ;READ OCTAL NUMBER ONTO STACK & SHIOCT
7237 044560 013737 074434 002106  MOV $SHIOCT,BANK ;PUT MSB'S IN BANK
7238 044566 012600          POP RO ;PUT LSB'S IN RO
                                CLC
7239 044570 000241          CLC
7240 044572 006100          ROL RO
7241 044574 006137 002106          ROL BANK
7242 044600 000241          CLC
7243 044602 006000          ROR RO
7244 044604          IF BANK GT #167 THEN GOTO 1$ ;CHECK FOR BANK TOO HIGH
                                CMP BANK,#167
                                BGT 1$
044604 023727 002106 000167          ADD #FIRST,RO
044612 003357          IF #BIT0 SET.IN RO THEN GOTO 1$ ;CHECK FOR ODD ADDRESS
7245 044614 062700 060000          BIT #BIT0,RO
7246 044620 032700 000001          BNE 1$
                                16K
044624 001352          IF RO HI #LAST THEN GOTO 1$ ;CHECK FOR ADDRESS OVER
                                CMP RO,#LAST
                                BHI 1$
7247 044626 020027 157776          MOV #3$,PARTHERE ;INCASE OF ABORTS
044632 101347          SET4 #4$ ;TRAPS TO 4 GOTO 4$
7248 044634 012737 044706 002372  MOV #4$,4
7249 044642 012737 044714 000004  .DSABL CRF
                                MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
                                MOV R3,-(SP)
7250 044650 010346          MOV BANK,R3
044652 013703 002106          CALL MAPPER
044656 004737 040700          .DSABL CRF
                                MOV (SP)+,R3
7251 044662 012603          SUPERVISOR ;ENTER SUPERVISOR MODE
044664 052737 040000 177776  BIS #BIT14,PSW ;DO IT TO IT!
                                .DSABL CRF
7252 044672 011001          MOV (RO),R1
7253 044674 104477          KERNEL ;ENTER KERNEL MODE
7254 044676 010146          TYPOCS R1
                                MOV R1,-(SP) ;:SAVE R1 FOR TYPEOUT
                                TYPOS ;:GO TYPE--OCTAL ASCII
                                .BYTE 6 ;:TYPE 6 DIGITS
                                .BYTE 0 ;:SUPPRESS LEADING ZEROS
                                .DSABL CRF
7255 044704 000410          BR EXCMD3
  
```

```

7256
7257 044706          38:  TYPE      MSG032          :PARITY ABORT
      044706  104401  113533  TYPEIT  ,MSG032
      .DSABL  CRF
      BR      EXCMD3
7258 044712  000405
7259
7260 044714  062706  000004  48:  ADD      #4,SP          :FIX STACK
7261 044720          TYPE      MSG033          :TIMEOUT TRAP
      044720  104401  113552  TYPEIT  ,MSG033
      .DSABL  CRF
      BR      EXCMD3
7262 044724  000400
7263
7264 044726  104417  EXCMD3: KERNEL          :ENTER KERNEL MODE
7265 044730          POP      4,PARTHERE,NOPAR,BANK
      044730  012637  000004          MOV (SP)+,4
      044734  012637  002372          MOV (SP)+,PARTHERE
      044740  012637  002100          MOV (SP)+,NOPAR
      044744  012637  002106          MOV (SP)+,BANK
7266 044750          RES4          :RESET TRAPS TO 4 TO DEFAULT
      044750  012737  036726  000004  MOV      #TIMEOUT,4
      044756  005037  177766  CLR      CPUERR          :CLEAR OUT THE CPU ERROR REGISTER BITS
                              :THAT A EXPECTED TRAP COULD HAVE SET
                              .DSABL  CRF
7267 044762  000207  RETURN
  
```

```

7270 044764      FSCMD4: SUBTST <<FS  COMMAND 4  MODIFY MEMORY>>
:*****
: *SUBTEST      FS  COMMAND 4  MODIFY MEMORY
:*****
7271 044764      PUSH  BANK,NOPAR,PARTHERE,4
044764 013746 002106      MOV BANK,-(SP)
044770 013746 002100      MOV NOPAR,-(SP)
044774 013746 002372      MOV PARTHERE,-(SP)
045000 013746 000004      MOV 4,-(SP)
7272 05004 012737 000003 002100      MOV #3,NOPAR ;INDICATE PARITY ACTION
7273 045012      TYPE MSG036 ;MODIFY MEMORY
045012 104401 113712      TYPEIT ,MSG036
                                .DSABL CRF
7274 045016      1$: TYPE MSG031 ;PHYSICAL ADDRESS (0-1677776)::?
045016 104401 113473      TYPEIT ,MSG031
                                .DSABL CRF
7275 045022 104413      RDOCT ;READ OCTAL NUMBER ONTO STACK & $HIOCT
7276 045024 013737 074434 002106      MOV $HIOCT,BANK ;PUT MSB'S IN BANK
7277 045032      POP RO ;PUT LSB'S IN RO
045032 012600      MOV (SP)+,RO
7278 045034 000241      CLC
7279 045036 006100      ROL RO
7280 045040 006137 002106      ROL BANK
7281 045044 000241      CLC
7282 045046 006000      ROR RO
7283 045050      IF BANK GT #167 THEN GOTO 1$ ;CHECK FOR BANK TOO HIGH
045050 023727 002106 000167      CMP BANK,#167
045056 003357      BGT 1$
7284 045060 062700 060000      ADD #FIRST,RO
7285 045064      IF #BIT0 SET.IN RO THEN GOTO 1$ ;CHECK FOR ODD ADDRESS
045064 032700 000001      BIT #BIT0,RO
045070 001352      BNE 1$
7286 045072      IF RO HI #LAST THEN GOTO 1$ ;CHECK FOR ADDRESS OVER
045072 020027 157776      16K
045076 101347      CMP RO,#LAST
7287 045100 012737 045146 002372      MOV #3$,PARTHERE ;INCASE OF ABORTS
7288 045106      SET4 #4$ ;TRAPS TO 4 GOTO 4$
045106 012737 045154 000004      MOV #4$,4
                                .DSABL CRF
7289 045114      MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
045114 010346      MOV R3,-(SP)
045116 013703 002106      MOV BANK,R3
045122 004737 040700      CALL MAPPER
                                .DSABL CRF
                                MOV (SP)+,R3
7290 045130 104511      INVALIDATE
7291 045132      SUPERVISOR ;ENTER SUPERVISOR MODE
045132 052737 040000 177776      BIS #BIT14,PSW ;DO IT TO IT.
                                .DSABL CRF
7292 045140 011001      MOV (RO),R1
7293      ;GETTING HERE MEANS WE GOT LUCKY - NO TRAPS
7294 045142 104417      KERNEL ;ENTER KERNEL MODE
7295 045144 000410      BR 5$
7296
7297 045146      3$: TYPE MSG032 ;PARITY ABORT
045146 104401 113533      TYPEIT ,MSG032
                                .DSABL CRF
    
```

```

7298 045152 000431          BR      EXCMD4          ;EXIT
7299
7300 045154 062706 000004    4S:    ADD      #4,SP          ;FIX STACK
7301 045160 104401 113552    TYPEIT ,MSG033      ;TIMEOUT TRAP
      045160 104401 113552    .DSABL CRF
      BR      EXCMD4          ;EXIT
7302 045164 000424
7303
7304 045166 104401 113731    5S:    TYPE      MSG037      ;OLD DATA WAS
      TYPEIT ,MSG037
      .DSABL CRF
      TYPOCS R1          ;PRINT IT
      MOV      R1,-(SP)    ;;SAVE R1 FOR TYPEOUT
      TYPOS    ;;GO TYPE--OCTAL ASCII
      .BYTE    6          ;;TYPE 6 DIGITS
      .BYTE    0          ;;SUPPRESS LEADING ZEROS
      .DSABL CRF
7306 045200 104401 113766    TYPE      MSG039      ;INPUT NEW DATA
      TYPEIT ,MSG039
      .DSABL CRF
7307 045204 104413
7308 045206 012601          RDOCT          ;READ ON OCTAL NUMBER ONTO THE STACK
      POP      R1          ;GET NEW NUMBER
7309 045210 052737 040000 177776 SUPERVISOR      ;ENTER SUPERVISOR MODE
      BIS      #BIT14,PSW ;DO IT TO IT!
      .DSABL CRF
7310 045216 010110          MOV      R1,(R0)      ;PUT IT IN MEMORY
7311 045220 011001          MOV      (R0),R1      ;READ IT AGAIN
7312 045222 104417          KERNEL        ;ENTER KERNEL MODE
7313 045224 104401 113750    TYPE      MSG038      ;DATA IS NOW
      TYPEIT ,MSG038
      .DSABL CRF
7314 045230 010146          TYPOCS R1          ;PRINT IT
      MOV      R1,-(SP)    ;;SAVE R1 FOR TYPEOUT
      TYPOS    ;;GO TYPE--OCTAL ASCII
      .BYTE    6          ;;TYPE 6 DIGITS
      .BYTE    0          ;;SUPPRESS LEADING ZEROS
      .DSABL CRF
7315
7316 045236 104417    EXCMD4: KERNEL  ;ENTER KERNEL MODE
7317 045240          POP      4,PARTHERE,NOPAR,BANK
      045240 012637 000004          MOV (SP)+,4
      045244 012637 002372          MOV (SP)+,PARTHERE
      045250 012637 002100          MOV (SP)+,NOPAR
      045254 012637 002106          MOV (SP)+,BANK
7318 045260          RES4          ;RESET TRAPS TO 4 TO DEFAULT
      045260 012737 036726 000004 MOV      #TIMEOUT,4
      045266 005037 177766          CLR      CPUERR      ;CLEAR OUT THE CPU ERROR REGISTER BITS
      ;THAT A EXPECTED TRAP COULD HAVE SET
      .DSABL CRF
7319 045272 000207          RETURN

```


FS COMMAND 4 MODIFY MEMORY

```

7322 045274          FSCMDS: SUBST <<FS  COMMAND 5  SELECT BANK,MARGIN, & PATTERN>>
:*****
:SUBTEST  FS  COMMAND 5  SELECT BANK,MARGIN, & PATTERN
:*****
7323 045274          PUSH  BANK,PATTERN,MARGIN,CSRFIRST,PCBUMP,TKVEC,TKVEC+2
045274 013746 002106          MOV BANK,-(SF)
045300 013746 002120          MOV PATTERN,-(SP)
045304 013746 002112          MOV MARGIN,-(SP)
045310 013746 002336          MOV (CSRFIRST,-(SP)
045314 013746 002406          MOV PCBUMP,-(SP)
045320 013746 000060          MOV TKVEC,-(SP)
045324 013746 000062          MOV TKVEC+2,-(SP)
7324 045330 013737 002112 002376  MOV  MARGIN,OLDMARGIN
7325 045336 010637 002374  MOV  SP,FSSTACK ;SAVE LAST GOOD STACK POINTER
7326 045342          TYPE  MSG040 ;SELECT BANK, MARGIN, & PATTERN TEST
045342 104401 114010  TYPEIT ,MSG040
          .DSABL CRF
7327 045346          1$: TYPE  MSG030 ;BANK(0-167)?
045346 104401 113454  TYPEIT ,MSG030
          .DSABL CRF
7328 045352 104413          RDOCT ;READ AN OCTAL NUMBER ONTO THE STACK
7329 045354          POP  BANK ;PUT IT IN BANK
045354 012637 002106          IF BANK GT #167 THEN GOTO 1$ ;CHECK FOR BANK TO HIGH
7330 045360          MOV (SP)+,BANK
045360 023727 002106 000167  CMP BANK,#167
045366 003367          BGT 1$
7331          MOV  BANK,R1
7332 045370 013701 002106  MOV  #6,R1
7333 045374 070127 000006  MUL  #6,R1
7334 045400          IF (PUBIT OFF.IN CONFIG(R1)
045400 033761 002114 003016          BIT (PUBIT,CONFIG(R1)
045406 001003          BNE L513
7335 045410          TYPE  MSG041 ;BANK NOT ACCESSABLE
045410 104401 114055  TYPEIT ,MSG041
          .DSABL CRF
          GOTO 1$
7336 045414          BR 1$
045414 000754          END ;OF IF
7337 045416          L513:*****
045416          2$: TYPE  MSG042 ;PATTERN(0-37)?
7339 045416 104401 114102  TYPEIT ,MSG042
          .DSABL CRF
7340 045422 104413          RDOCT ;READ AN OCTAL NUMBER ONTO THE STACK
7341 045424          POP  PATTERN ;PUT IT IN PATTERN
045424 012637 002120          MOV (SP)+,PATTERN
7342 045430          IF PATTERN GT #37 THEN GOTO 2$ ;CHECK FOR PATTERN TO HIGH
045430 023727 002120 000037  CMP PATTERN,#37
045436 003367          BGT 2$
7343 045440          IF PATTERN EQ #0
045440 005737 002120          TST PATTERN
045444 001004          BNE L514
7344 045446          TYPE  MSG043 ;PATTERN 0 DATA IS?
045446 104401 114123  TYPEIT ,MSG043
          .DSABL CRF
7345 045452 104413          RDOCT ;READ AN OCTAL NUMBER ONTO THE STACK
7346 045454          POP  R2 ;PUT IT IN R2

```

```

7347 045454 012602                                MOV (SP)+,R2
045456                                END ;OF IF
045456                                L514:::
7348
7349 045456 104401 114150          CMD5A: TYPE MSG044          ;MARGIN(0,2,3,4,5)?
045456                                TYPEIT ,MSG044
                                .DSABL CRF
7350 045462 104413                                RDOCT          ;READ AN OCTAL NUMBER ONTO THE STACK
7351 045464 012637 002112          POP MARGIN      ;PUT IN IN MARGIN
045464 012637 002112                                MOV (SP)+,MARGIN
7352 045470                                IF MARGIN GT #5 OR MARGIN EQ #1
045470 023727 002112 000005                                CMP MARGIN,#5
045476 003004                                BGT L515
045500 023727 002112 000001                                CMP MARGIN,#1
045506 001001                                BNE L516
045510                                L515:::
7353 045510                                GOTO CMD5A
045510 000762                                BR CMD5A
7354 045512                                END ;OF IF
045512                                L516:::
7355 045512                                IF MARGIN NE #0 AND #SW11 SET.IN @SWR
045512 005737 002112                                TST MARGIN
045516 001407                                BEQ L517
045520 032777 004000 135240          BIT #SW11,@SWR
045526 001403                                BEQ L517
7356 045530                                TYPE MSG045          ;MARGINS INHIBITED BY SW11
045530 104401 114175          TYPEIT ,MSG045
                                .DSABL CRF
                                GOTO CMD5A
7357 045534                                BR CMD5A
045534 000750
7358 045536                                END ;OF IF MARGIN
045536                                L517:::
7359
7360 045536                                MAP BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
045536 010346                                MOV R3,-(SP)
045540 013703 002106          MOV BANK,R3
045544 004737 040700          CALL MAPPER
                                .DSABL CRF
                                MOV (SP)+,R3
7361 045550 012603          INVALIDATE
7362 045552 104511          CALL EXBANK      ;SET NEW MARGINS
7363 045554 004737 042422          IF RRFLAG IS TRUE
045560 005737 002132          TST RRFLAG
045564 001403          BEQ L520
7364 045566                                TYPE MSG049          ;BANK REQUIRES RELOCATION
045566 104401 114343          TYPEIT ,MSG049
                                .DSABL CRF
                                GOTO CMD5C
7365 045572                                BR CMD5C
045572 000527
7366 045574                                END ;OF IF RRFLAG
045574                                L520:::
7367 045574 004737 043300          CALL COREHISTORY
7368 045600                                TYPE MSG046          ;TO ESCAPE TYPE ANY KEY.
045600 104401 114231          TYPEIT ,MSG046
                                .DSABL CRF
7369 045604 012737 046052 000060          MOV #CMD5C,TKVEC
7370 045612 012737 000340 000062          MOV #340,TKVEC+2
  
```

```

7371 045620 017700 135150      MOV    @STKB,RO      :KILL ANY OLD INTERRUPT
7372 045624 042737 000200 177776  BIC    #BIT7,PSW    :LOWER CPU PRIORITY TO 140
7373 045632 052777 000100 135132  BIS    #BIT6,@STKS  :ENABLE KEYBOARD INTERRUPTS
7374
7375 045640 013700 002112      MOV    MARGIN,RO    :SET MARGINS
7376 045644 006300      ASL    RO           :SET MARGINS
7377
7378 045646 010037 177750      MOV    RO,MAINT
7379
7380 045652      SET    HEADER,MUT
                                MOV    #-1,HEADER
                                MOV    #-1,MUT
                                045652 012737 177777 002724
                                045660 012737 177777 002116
7381 045666 005037 002362      CMD5B: CLR    PASFLG
7382 045672 012737 060000 002336  MOV    #FIRST,CSRFIRST
7383 045700      IF #SWO SET.IN @SWR
                                BIT #SWO,@SWR
                                BEQ L521
                                045700 032777 000001 135060
                                045706 001402
7384 045710      ECCDIS           :DISABLE ERROR CORRECTION
                                104470
7385 045712      ELSE
                                BR L522
                                045712 000401
                                045714
7386 045714 104502      CLRCR           :CLEAR MK11 CSRS
7387 045716      END ;OF IF
                                L521:::
                                L522:::
7388 045716 012737 000002 002100  MOV    #2,NOPAR    :PARITY ACTION
7389 045724 012737 000002 002406  MOV    #2,PCBUMP   :TRAPS ADD 2 TO PC
7390 045732 013700 002120      MOV    PATTERN,RO
7391 045736 006300      ASL    RO
7392 045740 004770 045752  CALL   @FSPAT(RO)
7393 045744 005037 002100      CLR    NOPAR
7394 045750 000746      BR     CMD5B
                                :LOOP TILL KEYBOARD INTERRUPT
7395
FSPAT: MT0000 :<1 SEC DATA PATTERN TEST
7396 045752 021704      MT0001 :<1 SEC ADDRESS TEST
7397 045754 021740      MT0002 :<1 SEC COMPLEMENT ADDRESS TEST
7398 045756 022000      MT0003 : 1 SEC 3 XOR 9 WORST CASE NOISE TEST
7399 045760 022050      MT0004 : 1 SEC ROTATING ZEROS TEST
7400 045762 022216      MT0005 : 1 SEC ROTATING ONES TEST
7401 045764 022300      MT0006 :<1 SEC INITIAL DATA TEST
7402 045766 022360      MT0007 :<1 SEC ADDRESS BIT TEST
7403 045770 022414      MT0010 :<1 SEC BYTE ADDRESSING TEST
7404 045772 022456      MT0011 :<2 SEC CREATE SINGLE BIT ERROR TEST
7405 045774 022512      MT0012 :<1 SEC WRITE BYTE CLEARS SBE TEST
7406 045776 022570      MT0013 : 1 SEC CREATE DOUBLE BIT ERROR TEST
7407 046000 022646      MT0014 : 1 SEC WRITE INHIBIT DURING DATIP WITH DBE
7408 046002 022722      MT0015 : 1 SEC WRITE INHIBIT OF BYTE WITH DBE
7409 046004 023000      MT0016 :<1 SEC WRITE INHIBIT OF WORD WITH DBE
7410 046006 023056      MT0017 :<1 SEC HOLDING 1'S & 0'S TEST
7411 046010 023134      MT0020 :<1 SEC MARCHING 1'S & 0'S IN CHECK BITS
7412 046012 023156      MT0021 : 1 SEC MARCHING 0'S & 1'S TEST
7413 046014 023612      MT0022 :10 SEC REFRESH & SHIFTING DIAGONAL TEST
7414 046016 023734      MT0023 :10 SEC SHIFTING DIAGONAL TEST
7415 046020 023766      MT0024 :20 SEC FAST GALLOPING PATTERN TEST
7416 046022 024032      MT0025 :<1 SEC INTERRUPT ENABLE TEST
7417 046024 024172      MT0026 :<1 SEC RANDOM DATA TEST
7418 046026 024240      MT0027 : 1 SEC UNIQUE BANK TEST
7419 046030 024370      MT0030 : 1 SEC FLUSH OUT DBE'S TEST
7420 046032 024754
    
```

```

7421 046034 025214      MT0031 : 3 SEC      SOB-A-LONG TEST
7422 046036 025772      MT0999:MT0032
7423 046040 025340      MT0033 : <1 SEC    WRITE RECOVERY TEST
7424 046042 025530      MT0034 : 35 SEC    BRANCH GOBBLE TEST
7425 046044 025772      MT0999:MT0035
7426 046046 025772      MT0999:MT0036
7427 046050 025772      MT0999:MT0037
7428
7429 046052 013706 002374  CMD5C: MOV    FSSTACK,SP      ;RECOVER OLD STACK POINTER
7430 046056 042777 000100 134706 BIC    #BIT6,@$TKS
7431 046064      POP    TKVEC+2,TKVEC
      MOV (SP)+,TKVEC+2
      MOV (SP)+,TKVEC
      046064 012637 000062
      046070 012637 000060
7432 046074 117700 134674  MOVB  @$TKB,R0      ;GET CHARACTER TO GET RID OF FLAG
7433 046100      POP    PCBUMP,CSRFIRST,MARGIN
      MOV (SP)+,PCBUMP
      MOV (SP)+,CSRFIRST
      MOV (SP)+,MARGIN
      046100 012637 002406
      046104 012637 002336
      046110 012637 002112
7434 046114 004737 043300  CALL  COREHISTORY    ;RESTORE OLD MARGINS
7435 046120      POP    PATTERN,BANK
      MOV (SP)+,PATTERN
      MOV (SP)+,BANK
      046120 012637 002120
      046124 012637 002106
7436 046130      MAP    BANK      ;REMAP OLD BANK
      MOV R3,-(SP)
      046130 010346
      046132 013703 002106
      046136 004737 040700
      MOV  BANK,R3
      CALL MAPPER
      .DSABL CRF
      MOV (SP)+,R3
      046142 012603
7437 046144 004737 042422  CALL  EXBANK
7438 046150 000207
7439
7440 046152  FSCMD6: SUBST <<FS  COMMAND 6  TYPE CONFIGURATION MAP>>
      ;*****
      ;*SUBTEST  FS  COMMAND 6  TYPE CONFIGURATION MAP
      ;*****
      CALL PCONFIG
      RETURN
7441 046152 004737 035402
7442 046156 000207
7443
  
```

```

7447 046160          FS:CMD7: SUBTST <<FS  COMMAND 7  BATTERY BACKUP TEST>>
:.....
:SUBTEST  FS  COMMAND 7  BATTERY BACKUP TEST
:.....
7448 046160          PUSH  BANK,PATTERN,MARGIN,CSRNO,TKVEC,TKVEC+2
046160 013746 002106          MOV  BANK,-(SP)
046164 013746 002120          MOV  PATTERN,-(SP)
046170 013746 002112          MOV  MARGIN,-(SP)
046174 013746 002256          MOV  CSRNO,-(SP)
046200 013746 000060          MOV  TKVEC,-(SP)
046204 013746 000062          MOV  TKVEC+2,-(SP)
7449 046210          SET   FS7FLAG
046210 012737 177777 002546          MOV  #-1,FS7FLAG
7450 046216          IF  #SWO SET.IN @SWR
046216 032777 000001 134542          BIT  #SWO,@SWR
046224 001402          BEQ  L523
7451 046226          ECCDIS          ;DISABLE ERROR CORRECTION
7452 046230          ELSE
046230 000401          BR   L524
046232          L523:.....
7453 046232 104502          CLRCR          ;CLEAR MK11 CSRS
7454 046234          END ;OF IF          L524:.....
7455 046234          TYPE  MSG050          ;BATTERY BACKUP TEST
046234 104401 114375          TYPEIT ,MSG050
.DSABL CRF
7456          ;WRITING & CHECKING ADDRESS PATTERN AS BACKGROUND
7457 046240 004737 024370          CALL  MT0027          ;CREATE & CHECK BACKGROUND
7458 046244 012737 000012 002434          MOV  #10,TIME
7459 046252          TYPE  MSG052          ;REMOVE SYSTEM POWER FOR
046252 104401 114523          TYPEIT ,MSG052
.DSABL CRF
7460 046256          TYPDEC TIME
046256 013746 002434          MOV  TIME,-(SP)          ;;SAVE TIME FOR TYPEOUT
046262 104405          TYPDS          ;;GO TYPE--DECIMAL ASCII WITH SIGN
.DSABL CRF
7461 046264          TYPE  MSG053          ;SECONDS MAX.
046264 104401 114554          TYPEIT ,MSG053
.DSABL CRF
7462 046270          TYPE  MSG046          ;TO ESCAPE TYPE ANY KEY
046270 104401 114231          TYPEIT ,MSG046
.DSABL CRF
7463 046274 012737 046336 000060          MOV  #CMD7A,TKVEC
7464 046302 012737 000340 000062          MOV  #340,TKVEC+2
7465 046310 017700 134460          MOV  @STKB,RO          ;KILL ANY OLD INTERRUPT
7466 046314 042737 000200 177776          BIC  #BIT7,PSW          ;LOWER CPU PRIORITY TO 140
7467 046322 052777 000100 134442          BIS  #BIT6,@STKS          ;ENABLE KEYBOARD INTERRUPTS
7468 046330 010637 002374          MOV  SP,FSSTACK
7469
7470 046334 000001          WAIT
7471
7472 046336 013706 002374          CMD7A: MOV  FSSTACK,SP          ;RECOVER OLD STACK POINTER
7473 046342 042777 000100 134422          BIC  #BIT6,@STKS
7474 046350          POP  TKVEC+2,TKVEC
046350 012637 000062          MOV  (SP)+,TKVEC+2
046354 012637 000060          MOV  (SP)+,TKVEC
7475 046360 117700 134410          MOVB  @STKB,RO          ;GET CHARACTER TO GET RID OF FLAG
  
```

```

7476 046364 104401 114572      TYPE MSG054      ;NOW STARTING READ TEST OF MEMORY BANKS
      046364      TYPEIT ,MSG054
      .DSABL CRF
      FOR BANK := #0 TO #167

7477 046370 005037 002106      CLR BANK
      046370      B64:.....
      046374
7478 046374 004737 042422      CALL EXBANK
7479 046400 005737 002124      IF ACFLAG IS TRUE AND RRFLAG IS FALSE
      046404 001416
      046406 005737 002132      TST ACFLAG
      046412 001013      BEQ L525
      7480 046414 104511      INVALIDATE
      7481 046416      LET R2 := BANK
      046416 013702 002106      MOV BANK,R2
7482 046422 012700 060000      MOV #FIRST,R0
7483 046426 010004      MOV R0,R4
7484 046430 012701 040000      MOV #SIZE,R1
7485 046434 010103      MOV R1,R3
7486 046436 004737 026220      CALL SUPD03
7487 046442      END ;OF IF ACFLAG
      046442      L525:.....
7488 046442 005237 002106      END ;OF FOR BANK
      046446 023727 002106 000167      INC BANK
      046454 003747      CMP BANK,#167
      046456      BLE B64
7489 046456 104401 114264      TYPE MSG047      ;TEST COMPLETE
      046456      TYPEIT ,MSG047
      .DSABL CRF
7490 046462 005037 002546      CLR FS7FLAG
7491 046466 012637 002256      POP CSRNO,MARGIN,PATTERN,BANK
      046472 012637 002112      MOV (SP)+,CSRNO
      046476 012637 002120      MOV (SP)+,MARGIN
      046502 012637 002106      MOV (SP)+,PATTERN
7492 046506 000207      MOV (SP)+,BANK
7493
      RETURN
  
```

```

7496 046510          FSCMDB: SUBTST <<FS  COMMAND 8  SOB-A-LONG TEST>>
:.....
: SUBTST          FS  COMMAND 8  SOB-A-LONG TEST
:.....
7497 046510          PUSH  BANK,PATTERN,MARGIN,TKVEC,TKVEC+2,NOPAR
046510 013746 002106          MOV BANK,-(SP)
046514 013746 002120          MOV PATTERN,-(SP)
046520 013746 002112          MOV MARGIN,-(SP)
046524 013746 000060          MOV TKVEC,-(SP)
046530 013746 000062          MOV TKVEC+2,-(SP)
046534 013746 002100          MOV NOPAR,-(SP)
7498 046540 010637 002374          MOV SP,FSSTACK          ;SAVE LAST GOOD STACK POINTER
7499 046544 104401 114642          TYPE MSG055          ;SOB-A-LONG TEST
046544          TYPEIT ,MSG055
7500 046550          CMD8A:          ;MARGIN(0,2,3,4,5)
046550 104401 114150          .DSABL CRF
          TYPE MSG044
          TYPEIT ,MSG044
          .DSABL CRF
7501 046554 104413          RDOCT          ;READ AN OCTAL NUMBER ONTO THE STACK
7502 046556 012637 002112          POP MARGIN          ;PUT IN IN MARGIN
7503 046562          IF MARGIN GT #5 OR MARGIN EQ #1          MOV (SP)+,MARGIN
046562 023727 002112 000005          CMP MARGIN,#5
046570 003004          BGT L526
046572 023727 002112 000001          CMP MARGIN,#1
046600 001001          BNE L527
046602          L526:::
7504 046602          GOTO CMD8A
046602 000762          BR CMD8A
7505 046604          END ;OF IF          L527:::
7506 046604          IF MARGIN NE #0 AND #SW11 SET.IN @SWR
046604 005737 002112          TST MARGIN
046610 001407          BEQ L530
046612 032777 004000 134146          BIT #SW11,@SWR
046620 001403          BEQ L530
7507 046622          TYPE MSG045          ;MARGINS INHIBITED BY SW11
046622 104401 114175          TYPEIT ,MSG045
          .DSABL CRF
          GOTO CMD8A
7508 046626 000750          BR CMD8A
7509 046630          END ;OF IF MARGIN
046630          L530:::
7510 046630          IF #SW0 SET.IN @SWR
7511 046630 032777 000001 134130          BIT #SW0,@SWR
046636 001402          BEQ L531
7512 046640 104470          ECCDIS          ;DISABLE ERROR CORRECTION
7513 046642          ELSE
046642 000401          BR L532
046644          L531:::
7514 046644 104502          CLRCSR          ;CLEAR MK11 CSRS
7515 046646          END ;OF IF
046646          L532:::
7516 046646          TYPE MSG056          ;BELL - EACH PASS COMPLETE
046646 104401 114663          TYPEIT ,MSG056
          .DSABL CRF
    
```

```

7517
7518 046652          TYPE MSG046          ;TO ESCAPE TYPE ANY KEY
      046652 104401 114231      TYPEIT ,MSG046
      .DSABL CRF
7519 046656 012737 047014 000060      MOV #CMD8C,TKVEC
7520 046664 012737 000340 000062      MOV #340,TKVEC+2
7521 046672 017700 134076      MOV @STKB,R0          ;KILL ANY OLD INTERRUPT
7522 046676 042737 000200 177776      BIC #BIT7,PSW        ;LOWER CPU PRIORITY TO 140
7523 046704 052777 000100 134060      BIS #BIT6,@STKS     ;ENABLE KEYBOARD INTERRUPTS
7524
7525 046712 013700 002112      MOV MARGIN,R0        ;SET MARGINS
7526 046716 006300          ASL R0                ;SET MARGINS
7527 046720 010037 177750      MOV R0,MAINT
7528
7529 046724          SET HEADER,MUT
      046724 012737 177777 002724      MOV #-1,HEADER
      046732 012737 177777 002116      MOV #-1,MIT
7530
7531 046740          CMD8B: FOR BANK == #0 TO #167
      046740 005037 002106          CLR BANK
      046744          B65:.....
7532 046744 004737 042422          CALL EXBANK
7533 046750          IF ACFLAG IS TRUE AND RRFLAG IS FALSE
      046750 005737 002124          TST ACFLAG
      046754 001406          BEQ L533
      046756 005737 002132          TST RRFLAG
      046762 001003          BNE L533
7534 046764 104511          INVALIDATE
7535 046766 004737 025214          CALL MTO031
7536 046772          END ;OF IF ACFLAG
      046772          L533:.....
7537 046772          END ;OF FOR BANK
      046772 005237 002106          INC BANK
      046776 023727 002106 000167      CMP BANK,#167
      047004 003757          BLE B65
      047006          E65:.....
7538 047006          TYPE $BELL          ;RING BELL
      047006 104401 003003      TYPEIT , $BELL
      .DSABL CRF
7539 047012          GOTO CMD8B
      047012 000752          BR CMD8B
7540
7541 047014 013706 002374          CMD8C: MOV FSSTACK,SP          ;RECOVER OLD STACK POINTER
7542 047020 042777 000100 133744      BIC #BIT6,@STKS
7543 047026 117700 133742          MOV @STKB,R0          ;READ CHAR TO KILL FLAG
7544 047032          POP NOPAR,TKVEC+2,TKVEC,MARGIN,PATTERN,BANK
      047032 012637 002100          MOV (SP)+,NOPAR
      047036 012637 000062          MOV (SP)+,TKVEC+2
      047042 012637 000060          MOV (SP)+,TKVEC
      047046 012637 002112          MOV (SP)+,MARGIN
      047052 012637 002120          MOV (SP)+,PATTERN
      047056 012637 002106          MOV (SP)+,BANK
7545 047062          MAP BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
      047062 010346          MOV BANK,R3
      047064 013703 002106          CALL MAPPER
      047070 004737 040700          .DSABL CRF
  
```


047074 012603
7546 047076 004737 042422
7547 047102 000207

CALL EXBANK
RETURN

MOV (SP)+,R3

```

7550 047104          FSCMD9: SUBST <<FS  COMMAND 9  SUPER TIGHT SCOPE LOOP>>
:*****
:SUBTEST           FS  COMMAND 9  SUPER TIGHT SCOPE LOOP
:*****
7551 047104          PUSH  BANK,MARGIN,TKVEC,TKVEC+2,NOPAR
047104 013746 002106          MOV BANK,-(SP)
047110 013746 002112          MOV MARGIN,-(SP)
047114 013746 000060          MOV TKVEC,-(SP)
047120 013746 000062          MOV TKVEC+2,-(SP)
047124 013746 002100          MOV NOPAR,-(SP)
7552 047130 010637 002374      MOV SP,FSSTACK          ;SAVE LAST GOOD STACK
7553 047134          TYPE MSG059             ;SUPER TIGHT SCOPE LOOP
047134 104401 114766          TYPEIT ,MSG059
.DSABL CRF
IF #SWO SET.IN @SWR
7554 047140          ECCDIS          ;DISABLE ERROR CORRECTION
047140 032777 000001 133620      ELSE
047146 001402          BIT #SWO,@SWR
7555 047150 104470          BEQ L534
7556 047152          BR L535
047152 000401          L534:::
047154          CLRCR          ;CLEAR MK11 CSRS
7557 047154 104502          END ;OF IF
047156          L535:::
7559 047156          1$: TYPE MSG031          ;PHYSICAL ADDRESS (0-1677776)?
047156 104401 113473          TYPEIT ,MSG031
.DSABL CRF
7560 047162 104413          RDOCT          ;READ OCTAL NUMBER ONTO STACK & $HIOCT
7561 047164 013737 074434 002106      MOV $HIOCT,BANK      ;PUT MSB'S IN BANK
7562 047172          POP RO          ;PUT LSB'S IN RO
047172 012600          MOV (SP)+,RO
7563 047174 000241          CLC
7564 047176 006100          ROL RO
7565 047200 006137 002106          ROL BANK
7566 047204 000241          CLC
7567 047206 006000          ROR RO
7568 047210          IF BANK GT #167 THEN GOTO 1$      ;CHECK FOR BANK TOO HIGH
047210 023727 002106 000167          CMP BANK,#167
047216 003357          BGT 1$
7569 047220 062700 060000          ADD #FIRST,RO
7570 047224          IF #BITO SET.IN RO THEN GOTO 1$ ;CHECK FOR ODD ADDRESS
047224 032700 000001          BIT #BITO,RO
047230 001352          BNE 1$
7571 047232          IF RO HI #LAST THEN GOTO 1$      ;CHECK FOR ADDRESS OVER
047232 020027 157776          CMP RO,#LAST
047236 101347          BHI 1$
7572 047240          CMD9A: TYPE MSG044          ;MARGIN(0,2,3,4,5)?
7573 047240 104401 114150          TYPEIT ,MSG044
.DSABL CRF
7574 047244 104413          RDOCT          ;READ AN OCTAL NUMBER ONTO THE STACK
7575 047246          POP MARGIN      ;PUT IN IN MARGIN
047246 012637 002112          MOV (SP)+,MARGIN
7576 047252          IF MARGIN GT #5 OR MARGIN EQ #1
047252 023727 002112 000005          CMP MARGIN,#5
047260 003004          BGT L536
047262 023727 002112 000001          CMP MARGIN,#1
  
```

```

047270 001001
7577 047272          GOTO CMD9A
047272 000762
7578 047274          END ;OF IF
047274
7579 047274          IF MARGIN NE #0 AND #SW11 SET.IN @SWR
047274 005737 002112
047300 001407
047302 032777 004000 133456
7580 047310 001403
047312          TYPE MSG045          ;MARGINS INHIBITED BY SW11
047312 104401 114175      TYPEIT ,MSG045
          .DSABL CRF
          GOTO CMD9A
7581 047316
047316 000750
7582 047320          END ;OF IF MARGIN
047320
7583
7584 047320 012737 000003 002100      MOV #3,NOPAR          ;PARITY ACTION
7585 047326 012737 047444 002372      MOV #CMD9LOOP,PARHERE
7586 047334          SET4 #CMD9B          ;TRAPS TO 4 GOTO CMD9B
047334 012737 047456 000004      MOV #CMD9B,4
          .DSABL CRF
7587 047342          MAP BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
047342 010346          MOV R3,-(SP)
047344 013703 002106
047350 004737 040700      CALL MAPPER
          .DSABL CRF
047354 012603          MOV (SP)+,R3
7588 047356 104511
7589 047360          INVALIDATE
047360 104401 115016      TYPE MSG060          ;SWR ----> MEM, MEM ----> DISPLAY
          TYPEIT ,MSG060
          .DSABL CRF
7590
7591 047364          TYPE MSG046          ;TO ESCAPE TYPE ANY KEY.
047364 104401 114231      TYPEIT ,MSG046
          .DSABL CRF
7592 047370 012737 047464 000060      MOV #CMD9C,TKVEC
7593 047376 012737 000340 000062      MOV #340,TKVEC+2
7594 047404 017701 133364          MOV @STKB,R1          ;KILL ANY OLD INTERRUPT
7595 047410 042737 000200 177776      BIC #BIT7,PSW        ;LOWER CPU PRIORITY TO 140
7596 047416 052777 000100 133346      BIS #BIT6,@STKS     ;ENABLE KEYBOARD INTERRUPTS
7597
7598 047424 013701 002112          MOV MARGIN,R1        ;SET MARGINS
7599 047430 006301          ASL R1              ;SET MARGINS
7600 047432 010137 177750          MOV R1,MAINT
7601
7602 047436          SUPERVISOR          ;ENTER SUPERVISOR MODE
047436 052737 040000 177776      BIS #BIT14,PSW      ;DO IT TO IT!
          .DSABL CRF
7603 047444 017710 133316          CMD9LOOP:MOV @SWR,(R0) ;WRITE SWITCH REGISTER INTO MEMORY
7604 047450 011077 133314          MOV (R0),@DISPLAY  ;READ MEMORY INTO DISPLAY REGISTER
7605 047454 000773          BR CMD9LOOP        ;LOOP TILL KEYBOARD INTERRUPT
7606
7607 047456 012716 047444          CMD9B:MOV #CMD9LOOP,(SP)
7608 047462 000002          RTI
  
```

```

7609
7610 047464 013706 002374          CMD9C:  MOV    FSSTACK,SP          ;RECOVER OLD STACK POINTER
7611 047470 042777 000100 133274  BIC    #BIT6,@STKS
7612 047476 117700 133272          MOVVB  @STKB,R0          ;READ CHAR TO KILL FLAG
7613 047502          POP    NOPAR,TKVEC+2,TKVEC,MARGIN,BANK
      MOV (SP)+,NOPAR
      MOV (SP)+,TKVEC+2
      MOV (SP)+,TKVEC
      MOV (SP)+,MARGIN
      MOV (SP)+,BANK
7614 047526          MAP    BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
      MOV R3,-(SP)
      MOV 047526 010346
      MOV 047530 013703 002106      MOV    BANK,R3
      CALL 047534 004737 040700     CALL  MAPPER
      .DSABL CRF
      MOV 047540 012603
      MOV 047542 004737 042422      CALL  EXBANK
      MOV (SP)+,R3
      MOV 047546 000207
      MOV 047548 047550
      FCMD10: SUBTST <<FS  COMMAND 10  ERROR SUMMARY>>
      :*****
      :*SUBTEST  FS  COMMAND 10  ERROR SUMMARY
      :*****
      PUSH  R0,R2,R3,BANK
      MOV R0,-(SP)
      MOV R2,-(SP)
      MOV R3,-(SP)
      MOV BANK,-(SP)
7619 047550
      TYPDEC $ERTTL
      MOV $ERTTL,-(SP)  ;;SAVE $ERTTL FOR TYPEOUT
      TYPDS  ;;GO TYPE--DECIMAL ASCII WITH SIGN
      .DSABL CRF
      TYPE  MSG079          ;ERROR(S) DETECTED
      TYPEIT ,MSG079
      .DSABL CRF
      IF $ERTTL NE #0
      TST $ERTTL
      BEQ L541
7620 047562
      CLR SUCCESS
      FOR BANK := #0 TO #167
      CLR BANK
      B66:::
7621 047570
      MOV BANK,R3
      MUL #6,R3
      ADD #5,R3
      IFB CONFIG(R3) NE #0
      TSTB CONFIG(R3)
      BEQ L542
7622 047574
      IF SUCCESS IS FALSE
      TST SUCCESS
      BNE L543
7623 047602
      TYPE  MSG076          ;BANK ERRORS
      TYPEIT ,MSG076
      .DSABL CRF
      SET SUCCESS
      MOV #-1,SUCCESS
7624 047606
      END ;OF IF SUCCESS
7625 047612 013703 002106
7626 047616 070327 000006
7627 047622 062703 000005
7628 047626
      MOV 047626 105763 003016
      MOV 047632 001424
7629 047634
      MOV 047634 005737 002424
      MOV 047640 001005
7630 047642
      MOV 047646 012737 177777 002424
      MOV 047654

```

L543:.....

7633 047654
 047654 013746 002106
 047660 104403
 047662 006
 047663 000
 7634 047664 116300 003016
 7635 047670 042700 177400
 7636 047674
 047674 010046
 047676 104405
 7637 047700
 047700 104401 003010
 7638 047704
 047704
 7639 047704
 047704 005237 002106
 047710 023727 002106 000167
 047716 003735
 047720
 7640 047720
 047720
 7641 047720
 047720 012637 002106
 047724 012603
 047726 012602
 047730 012600
 7642 047732 000207

```

    TYPDCS BANK,3
MOV   BANK,-(SP)      ::SAVE BANK FOR TYPEOUT
    ::3
    TYPDCS           ::GO TYPE--OCTAL ASCII
    .BYTE 6          ::TYPE 6 DIGITS
    .BYTE 0          ::SUPPRESS LEADING ZEROS
    .DSABL CR
    MOVB CONFIG(R3),R0
    BIC #*C377,R0
    TYPDEC RO
MOV   RO,-(SP)        ::SAVE RO FOR TYPEOUT
    TYPDS           ::GO TYPE--DECIMAL ASCII WITH SIGN
    .DSABL CRF
    TYPE           $CRLF
TYPEIT $CRLF
    .DSABL CRF
    END ;OF IFB CONFIG(R3)

    END ;OF FOR BANK

    END ;OF If $ERTTL

POP   BANK,R3,R2,RO

RETURN
  
```

L542:.....

```

INC BANK
CMP BANK,#167
BLE B66
  
```

E66:.....

L541:.....

```

MOV (SP)+,BANK
MOV (SP)+,R3
MOV (SP)+,R2
MOV (SP)+,RO
  
```

```

7645 047734          FCMD11: SUBST  <<FS  COMMAND 11  REFRESH TEST>>
:.....
: *SUBTEST      FS  COMMAND 11  REFRESH TEST
:.....
7646 047734          PUSH  BANK,PATTERN,MARGIN,TKVEC,TKVEC+2,NOPAR
047734 013746 002106          MOV  BANK,-(SP)
047740 013746 002120          MOV  PATTERN,-(SP)
047744 013746 002112          MOV  MARGIN,-(SP)
047750 013746 000060          MOV  TKVEC,-(SP)
047754 013746 000062          MOV  TKVEC+2,-(SP)
047760 013746 002100          MOV  NOPAR,-(SP)
7647 047764 010637 002374  MOV  SP,FSSTACK          :SAVE LAST GOOD STACK POINTER
7648 047770          TYPE  MSG073          :REFRESH TEST
047770 104401 115317          .DSABL CRF
7649 047774          CMD11A: TYPE  MSG044          :MARGIN(0,2,3,4,5)?
047774 104401 114150          TYPEIT ,MSG044
          .DSABL CRF
7650 050000 104413          RDOCT          :READ AN OCTAL NUMBER ONTO THE STACK
7651 050002          POP  MARGIN          :PUT IN IN MARGIN
050002 012637 002112          MOV  (SP)+,MARGIN
7652 050006          IF MARGIN GT #5 OR MARGIN EQ #1
050006 023727 002112 000005          CMP  MARGIN,#5
050014 003004          BGT  L544
050016 023727 002112 000001          CMP  MARGIN,#1
050024 001001          BNE  L545
050026          L544:.....
7653 050026          GOTO CMD11A          BR  CMD11A
050026 000762
7654 050030          END ;OF IF          L545:.....
050030
7655 050030          IF MARGIN NE #0 AND #SW11 SET.IN @SWR
050030 005737 002112          TST  MARGIN
050034 001407          BEQ  L546
050036 032777 004000 132722          BIT  #SW11,@SWR
050044 001403          BEQ  L546
7656 050046          TYPE  MSG045          :MARGINS INHIBITED BY SW11
050046 104401 114175          TYPEIT ,MSG045
          .DSABL CRF
7657 050052          GOTO CMD11A          BR  CMD11A
050052 000750
7658 050054          END ;OF IF MARGIN          L546:.....
050054
7659 050054          IF #SW0 SET.IN @SWR
7660 050054 032777 000001 132704          BIT  #SW0,@SWR
050062 001402          BEQ  L547
7661 050064 104470          ECCDIS          :DISABLE ERROR CORRECTION
7662 050066          ELSE
050066 000401          BR  L550
050070          L547:.....
7663 050070 104502          CLRCR          :CLEAR MK11 CSRS
7664 050072          END ;OF IF          L550:.....
050072
7665 050072          TYPE  MSG056          :BELL - EACH PASS COMPLETE
050072 104401 114663          TYPEIT ,MSG056
          .DSABL CRF
  
```

COMPIAND 11 REFRESH TEST

```

7666
7667 050076          TYPE      MSG046          ;TO ESCAPE TYPE ANY KEY:
      050076 104401 114231  TYPEIT    ,MSG046
      .DSABL      CRF
7668 050102 012737 050240 000060  MOV      #CMD11C,TKVEC
7669 050110 012737 000340 000062  MOV      #340,TKVEC+2
7670 050116 017700 132652          MOV      @STKB,RO          ;KILL ANY OLD INTERRUPT
7671 050122 042737 000200 177776  BIC      #BIT7,PSW          ;LOWER CPU PRIORITY TO 140
7672 050130 052777 000100 132634  BIS      #BIT6,@STKS          ;ENABLE KEYBOARD INTERRUPTS
7673
7674 050136 013700 002112          MOV      MARGIN,RO          ;SET MARGINS
7675 050142 006300          ASL      RO          ;SET MARGINS
7676 050144 010037 177750          MOV      RO,MAINT
7677
7678 050150          SET      HEADER,MUT
      050150 012737 177777 002724          MOV      #-1,HEADER
      050156 012737 177777 002116          MOV      #-1,MUT
7679
7680 050164          CMD11B: FOR BANK := #0 TO #167
      050164 005037 002106          CLR      BANK
      050170          B67:;;;;;
7681 050170 004737 042422          CALL     EXBANK
7682 050174          IF ACFLAG IS TRUE AND RRFLAG IS FALSE
      050174 005737 002124          TST     ACFLAG
      050200 001406          BEQ     L551
      050202 005737 002132          TST     RRFLAG
      050206 001003          BNE     L551
7683 050210 104511          INVALIDATE
7684 050212 004737 023734          CALL     MTO022
7685 050216          END ;OF IF ACFLAG
      050216          L551:;;;;;
7686 050216          END ;OF FOR BANK
      050216 005237 002106          INC     BANK
      050222 023727 002106 000167          CMP     BANK,#167
      050230 003757          BLE     B67
      050232          E67:;;;;;
7687 050232          TYPE      $BELL          ;RING BELL
      050232 104401 003003  TYPEIT    , $BELL
      .DSABL      CRF
7688 050236          GOTO     CMD11B
      050236 000752          BR      CMD11B
7689
7690 050240 013706 002374          CMD11C: MOV     FSSTACK,SP          ;RECOVER OLD STACK POINTER
7691 050244 042777 000100 132520  BIC      #BIT6,@STKS
7692 050252 117700 132516          MOV     @STKB,RO          ;READ CHAR TO KILL FLAG
7693 050256          POP     NOPAR,TKVEC+2,TKVEC,MARGIN,PATTERN,BANK
      050256 012637 002100          MOV     (SP)+,NOPAR
      050262 012637 000062          MOV     (SP)+,TKVEC+2
      050266 012637 000060          MOV     (SP)+,TKVEC
      050272 012637 002112          MOV     (SP)+,MARGIN
      050276 012637 002120          MOV     (SP)+,PATTERN
      050302 012637 002106          MOV     (SP)+,BANK
7694 050306          MAP     BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
      050306 010346          MOV     BANK,R3
      050310 013703 002106          CALL    MAPPER
      050314 004737 040700          .DSABL  CRF

```

7695 050320 012603
7696 050322 004737 042424
7697 050326 000207

CALL EXBANK
RETURN

MOV (SP),R3


```

7700 050330          FCMD12: SUBTST <<FS  COMMAND 12  SET FILL COUNT>>
:*****
:*SUBTEST          FS  COMMAND 12  SET FILL COUNT
:*****
7701 050330          PUSH  RO
050330 010046
7702 050332          TYPE  MSG085          ;FILL COUNT(OCTAL)?
050332 104401 115661  TYPEIT ,MSG085
          .DSABL CRF
7703 050336 104413  RDCCT
7704 050340          POP  RO
050340 012600          MOV (SP)+,RO
7705 050342 042700 177760 BIC  #*C17,RO
7706 050346 110037 002451 MOVB RO,$FILLS
7707 050352          POP  RO
050352 012600          MOV (SP)+,RO
7708 050354 000207          RETURN
7709
7710 050356          FCMD13: SUBTST <<FS  COMMAND 13  ENTER KAMIKAZE MODE>>
:*****
:*SUBTEST          FS  COMMAND 13  ENTER KAMIKAZE MODE
:*****
7711 050356          TYPE  MSG101          ;ENTERING KAMIKAZE MODE
050356 104401 116305  TYPEIT ,MSG101
          .DSABL CRF
7712 050362          SET  KAMIKAZE,SKIPKAMI
050362 012737 177777 002010 MOV #-1,KAMIKAZE
050370 012737 177777 002012 MOV #-1,SKIPKAMI
7713 050376 000207          RETURN
7714
7715 050400          FCMD14: SUBTST <<FS  COMMAND 14  EXIT KAMIKAZE MODE>>
:*****
:*SUBTEST          FS  COMMAND 14  EXIT KAMIKAZE MODE
:*****
7716 050400          TYPE  MSG102          ;LEAVING KAMIKAZE MODE
050400 104401 116335  TYPEIT ,MSG102
          .DSABL CRF
7717 050404 005037 002010 CLR  KAMIKAZE
7718 050410          SET  SKIPKAMI
050410 012737 177777 002012 MOV #-1,SKIPKAMI
7719 050416 000207          RETURN
7720
7721 050420          FCMD15: SUBTST <<FS  COMMAND 15  TURN CACHE OFF>>
:*****
:*SUBTEST          FS  COMMAND 15  TURN CACHE OFF
:*****
7722 050420          TYPE  MSG106          ;CACHE IS OFF
050420 104401 116527  TYPEIT ,MSG106
          .DSABL CRF
7723 050424 012737 001415 002700 MOV  #BIT0:BIT2:BIT3:BIT8:BIT9,CACHK
7724 050432 104424          CACHOFF          ;TURN CACHE OFF
7725 050434 000207          RETURN
7726
7727 050436          FCMD16: SUBTST <<FS  COMMAND 16  TURN CACHE ON>>
:*****
:*SUBTEST          FS  COMMAND 16  TURN CACHE ON
:*****

```

7728 050436 104401 116545
7729 050442 012737 000001 002700
7730 050450 104423
7731 050452 000207
7732
7733 050454

TYPE MSG107
TYPEIT ,MSG107
.DSABL CRF
MOV #BITO,CACHK
CACHON
RETURN

:CACHE IS ON (EXCEPT DURING ACTUAL PATTERNS)

:TURN CACHE ON

FCMD17: SUBTST <<FS COMMAND 17 RUN ONLY MULTIPOST TESTS>>
:.....
: *SUBTEST FS COMMAND 17 RUN ONLY MULTIPOST TESTS
:.....

7734 050454 104401 116622
7735 050460 012737 177777 002004
7736 050466 000207

TYPE MSG108
TYPEIT ,MSG108
.DSABL CRF
SET MULTIONLY
RETURN

:ONLY MULTIPOST TESTS WILL BE RUN

MOV #-1,MULTIONLY

```

7739 050470          *CMD18: SUBTST <<FS  COMMAND 18  RESUME RUNNING BOTH SINGLE & MULTIPORT TESTS>>
:*****
:*SUBTEST          FS  COMMAND 18  RESUME RUNNING BOTH SINGLE & MULTIPORT TESTS
:*****
7740 050470          TYPE  MSG109          ;BOTH SINGLE & MULTIPORT TESTS WILL BE RUN
050470 104401 116664 TYPEIT ,MSG109
                                .DSABL CRF
7741 050474 005037 002004 CLR  MULTIONLY
7742 050500 000207 RETURN
7743
7744 050502          FCMD19: SUBTST <<FS  COMMAND 19  TEST ONLY SELECTED BANKS>>
:*****
:*SUBTEST          FS  COMMAND 19  TEST ONLY SELECTED BANKS
:*****
7745 050502          TYPE  MSG105          ;ENTER BANKS IN OCTAL - USE NUMBER OUTSIDE RANGE TO TERMINAT
050502 104401 116423 TYPEIT ,MSG105
                                .DSABL CRF
7746 050506 004737 050576 CALL  CMD20A          ;ERASE OLD SELECTIONS
7747 050512 BEGIN  CMD19LOOP
050512 REPEAT          B70:*****
7748 050512 REPEAT          B71:*****
050512          TYPE  MSG030          ;BANK(0-16)?
7749 050512 104401 113454 TYPEIT ,MSG030
                                .DSABL CRF
7750 050516 104413 RDOCT          ;READ AN OCTAL NUMBER ONTO THE STACK
7751 050520 012601 POP R1          ;PUT IT IN R1
                                MOV (SP)+,R1
7752 050522          IF R1 GT #167 OR R1 LT #0
050522 020127 000167          CMP R1,#167
050526 003002          BGT L552
050530 005701          TST R1
050532 002001          BGE L553
050534          L552:*****
7753 050534          LEAVE CMD19LOOP
050534 000406          BR E70
7754 050536          END ;OF IF R1
050536          L553:*****
7755 050536 070127 000006 MUL #6,R1
7756 050542 052761 040000 003020 BIS #BIT14,CONFIG+2(R1)
7757 050550          END ;OF REPEAT
050550 000760          BR B71
050552          E71:*****
7758 050552          END CMD20LOOP
050552          E70:*****
7759 050552          TYPE  MSG110          ;ONLY SELECTED BANKS WILL BE TESTED
050552 104401 116737 TYPEIT ,MSG110
                                .DSABL CRF
7760 050556          SET  SELONLY
050556 012737 177777 002002 MOV # -1,SELONLY
7761 050564 000207 RETURN
7762
7763 050566          FCMD20: SUBTST <<FS  COMMAND 20  RESUME TESTING ALL BANKS>>
:*****
:*SUBTEST          FS  COMMAND 20  RESUME TESTING ALL BANKS
:*****
7764 050566          TYPE  MSG111          ;ALL BANKS WILL BE TESTED
    
```

```
050566 104401 117003          TYPEIT  ,MSG111
                                .DSABL  CRF
7765 050572 005037 002002      CLR      SELONLY
7766
7767                                :ENTRY POINT FROM CMD19
7768 050576                                CMD20A: FOR R1 :- #0 TO #167*3*2 BY #6
050576 005001
050600
7769 050600 042761 040000 003020      BIC  #BIT14,CONFIG*2(R1)
7770 050606 042761 020000 003020      BIC  #BIT13,CONFIG*2(R1)
7771 050614                                END ;OF FOR R1
050614 062701 000006
050620 020127 001312
050624 003765
7772 050626 000207          RETURN
```

```
                                CLR R1
                                B72:.....:
;DESELECT BANK
;INVALIDATE BACKGROUND PATTERN
                                ADD #6,R1
                                CMP R1,#167*3*2
                                BLE B72
                                E72:.....:
```

7775 050630

WHICHCSR:SUBTST <<SUBR DETERMINE CORRECT CSR>>

.....
 :*SUBTST SUBR DETERMINE CORRECT CSR
 :.....

7776 050630 013700 002334
 7777 050634 122700 000200
 7778 050640 001003
 7779 050642 005037 002256
 7780 050646 000207

MOV MKCSRS,R0 ;GET CSR'S FLAG
 CMPS #BIT7,R0 ;CSR 0?
 BNE 1\$;NO - SKIP
 CLR CSRNO ;YES - SET IT UP
 RETURN

7781
 7782 050650
 050650 104401 113252

1\$: TYPE MSG022 ;WHICH CSR(0-7)
 TYPEIT ,MSG022
 .DSABL CRF

7783 050654 104413
 7784 050656

RDOCT ;GET OCTAL NUMBER
 POP R0 ;PUT IN R0

7785 050660 012600 000007

CMP R0,#7 ;CHECK LIMIT MOV (SP)+,R0

7786 050664 101371
 7787 050666 012701 177774

BHI 1\$;IF BAD LOOP TILL HE TYPES IT RIGHT

7788 050672 005200
 7789 050674 062701 000004

2\$: INC R0
 ADD #4,R1
 SOB R0,2\$
 MOV R1,CSRNO

7790 050700 077003
 7791 050702 010137 002256

7792 050706 000207
 7793

RETURN

```

1          .TITLE  CEMKABO 1170 MAIN MEMORY DIAG 2
2          .IDENT  /X01.60/
3          .SBTTL  MULTIPROCESSOR SLAVE DISPATCHER
4 050710   TASKRET:IF #MASTER NE CPUBIT
050710   022737 000020 002114          CMP #MASTER,CPUBIT
050716   001402          BEQ L554
5 050720   000402          BR    TASKDO
6 050722   ELSE
050722   000401          BR L555
050724   000207          L554:.....
8 050726   RETURN
050726   END; OF IF #MASTER          L555:.....
9
10 050726   104424          TASKDO: CACHOFF          ;TURN CACHE OFF
11 050730   MAP #0          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
050730   010346          MOV R3,-(SP)
050732   012703 000000          MOV #0,R3
050736   004737 040700          CALL MAPPER
                                .DSABL CRF
                                MOV (SP)+,R3
12 050742   012603          SET R0
050744   012700 177777          FOR R1 : #0 TO #6 BY #2
13 050750   005001          CLR R1
050752   B73:.....
14 050752   IF R0 EQ ONES          CMP R0,ONES
050752   020037 002726          BNE L556
050756   001024          IF NOIIST IS TRUE
15 050760   005737 002756          TST NOIIST
050764   001403          BEQ L557
16 050766   013702 177764          MOV SYSTID,R2
17 050772   ELSE
050772   000406          BR L560
050774   L557:.....
18 050774   017702 131736          MOV @IISTACR,R2
19 051000   072227 177770          ASH #-8,R2
20 051004   042702 177774          BIC #^C3,R2
21 051010   END ;OF IF NOIIST
051010   L560:.....
22 051010   SUPERVISOR          ;ENTER SUPERVISOR MODE
051010   052737 040000 177776          BIS #BIT14,PSW          ;DO IT TO IT!
                                .DSABL CRF
                                IF FIRST+PORTDIR(R1) EQ R2 THEN LET RO := R1
23 051016   026102 062606          CMP FIRST+PORTDIR(R1),R2
051022   001001          BNE L561
051024   010100          MOV R1,R0
051026   L561:.....
24 051026   104417          KERNEL          ;ENTER KERNEL MODE
25 051030   END ;OF IF RO          L566:.....
26 051030   END ;OF FOR R1
051030   ADD #2,R1
051034   062701 000002          CMP R1,#6
051034   020127 000006          BLE B73
051040   003744          E73:.....
051042

```

```

27 051042                IF RO EQ ONES
    051042 020037 002726                CMP RO,ONES
    051046 001003                BNE L562
28 051050                FATAL 41
    051050 005237 002070                INC FATAL$                ;SET FATAL INDICATOR
    051054 104041                ERROR +41
    .DSABL CRF
    END ;OF IF RO
29 051056
    051056
30 051056                SUPERVISOR                ;ENTER SUPERVISOR MODE L562::::::::::
    051056 052737 040000 177776        BIS #BIT14,PSW                ;DO IT TO IT!
    .DSABL CRF
31 051064 005760 062616                1$: TST FIRST+TASK(R0)                ;WAIT FOR COMMAND
32 051070 003775
33 051072 013737 062676 002676        MOV FIRST+MDISPLAY,MDISPLAY
34 051100 013777 002676 131662        MOV MDISPLAY,@DISPLAY
35 051106 116001 062616                MOV#B FIRST+TASK(R0),R1                ;GET COMMAND
36 051112 104417                KERNEL
37 051114                PUSH RO                ;ENTER KERNEL MODE
    051114 010046                MOV RO,-(SP)
38 051116                CASE R1
    051116 010146                MOV R1,-(SP)
    051120 006316                ASL @SP
    051122 004737 051170                JSR PC,L563
39 051126 051234                TASK00                ;0 IS NOT A COMMAND
40 051130 051236                TASK01                ;MOVE PROGRAM TO BANK
41 051132 051330                TASK02                ;WRITE ONLY PATTERN IN HI BYTE
42 051134 051430                TASK03                ;READ ONLY PATTERN IN HI BYTE
43 051136 051664                TASK04                ;EXECUTION CONTENTION TEST
44 051140 051774                TASK05                ;PORT ARBITRATION SYMMETRY TEST
45 051142 052300                TASK06                ;STOP PROGRAM
46 051144 052326                TASK07                ;WRITE ONLY ADDRESS PATTERN
47 051146 052336                TASK10                ;READ ONLY ADDRESS PATTERN
48 051150 052536                TASK11                ;ASYNCHRONOUS ADDRESS UNIQUENESS TEST
49 051152 052644                TASK12                ;SKEWED UP ADDRESS TEST
50 051154 052726                TASK13                ;SETUP FOR ASRB TEST
51 051156 053276                TASK14                ;RESET FROM ASRB TEST
52 051160 053310                TASK15                ;RUN CSR TESTS
53 051162 053316                TASK16                ;SET MARGIN 6, CPU HAS I/O PRIORITY
54 051164 053334                TASK17                ;CREATE STALE DATA TEST
55 051166 053422                TASK20                ;CACHE FLUSH TEST
56 051170                END ;OF CASE R1
    051170                L563::::::::::
    051170 062616                ADD (SP)+,@SP
    051172 013646                MOV @ (SP)+,-(SP)
    051174 004736                JSR PC,@(SP)+
57 051176                POP RO
58 051200                MAP #0                ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
    051200 010346                MOV (SP)+,RO
    051202 012703 000000                MOV R3,-(SP)
    051206 004737 040700                CALL MAPPER
    .DSABL CRF
59 051212 012603                MOV (SP)+,R3
    051214                SUPERVISOR                ;ENTER SUPERVISOR MODE
    051214 052737 040000 177776        BIS #BIT14,PSW                ;DO IT TO IT!
    .DSABL CRF
    
```

MULTIPROCESSOR SLAVE DISPATCHER

60	051222	052760	100000	062616
61	051230	104417		
62	051232	000626		
63	051234	000207		

BIS	#BIT15, FIRST+TASK(RO)	:INDICATE DONE
KERNEL		:ENTER KERNEL MODE
BR	TASKRET	
TASK00:	RETURN	

C 4

```

66 051236          TASK01: SUBTST <<MOVE PROGRAM TO NEW BANK>>
:*****
: *SUBTEST      MOVE PROGRAM TO NEW BANK
:*****
67 051236          SUPERVISOR          ;ENTER SUPERVISOR MODE
051236 052737 040000 177776  BIS #BIT14,PSW          ;DO IT TO IT
      .DSABL CRF
68 051244 013700 062106  MOV FIRST+BANK,R0
69 051250 104417  KERNEL          ;ENTER KERNEL MODE
70 051252 004737 041456  CALL RELOC1
71 051256 012737 002000 002706  MOV #STACK,KSTACK
72 051264          POP R1,R0          ;GET OLD RETURN & RO
      MOV (SP)+,R1
      MOV (SP)+,R0
051264 012601
051266 012600
73 051270 013706 002706  MOV KSTACK,SP
74 051274          PUSH RO,R1          ;PUT BACK RO & RETURN
      MOV RO,-(SP)
      MOV R1,-(SP)
      MOV R3,-(SP)
75 051300          MAP #0          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
051300 010346
051302 012703 000000
051306 004737 040700  MOV #0,R3
      CALL MAPPEP
      .DSABL CRF
      MOV (SP)+,R3
051312 012603
76 051314 005037 002134  CLR RLFLAG
77 051320          SET NOSCOPE          ;NO SCOPE LOOPS ALLOWED IN MULTIPROCESSOR TESTS
051320 012737 177777 002540  MOV #-1,NOSCOPE
78 051326 000207  RETURN
79
80 051330          TASK02: SUBTST <<WRITE ONLY PATTERN IN HI BYTE>>
:*****
: *SUBTEST      WRITE ONLY PATTERN IN HI BYTE
:*****
81 051330          SUPERVISOR          ;ENTER SUPERVISOR MODE
051330 052737 040000 177776  BIS #BIT14,PSW          ;DO IT TO IT!
      .DSABL CRF
82 051336 116005 062617  MOV#B FIRST+TASK+1(RO),R5
83 051342 013737 062106 002106  MOV FIRST+BANK,BANK
84 051350 104417  KERNEL          ;ENTER KERNEL MODE
85 051352          SET WRITEONLY
      MOV #-1,WRITEONLY
86 051360 012737 177777 002502  MOV #FIRST,R0
87 051364 012701 040000  MOV #SIZE,R1
88 051370          CASE R5
051370 010546          MOV R5,-(SP)
051372 006316          ASL @SP
051374 004737 051414  JSR PC,L564
89 051400 051530          SLPAT0          ;ZEROS
90 051402 051534          SLPAT1          ;ONES
91 051404 051542          SLPAT2          ;125252
92 051406 051550          SLPAT3          ;52525
93 051410 051556          SLPAT4          ;377
94 051412 051564          SLPAT5          ;177400
95 051414          END ;OF CASE R5
051414
051414 062616
051416 013646
L564:::
ADD (SP)+,@SP
MOV @ (SP)+,-(SP)

```

051420 004736
96 051422 005037 002502
97 051426 000207

CLR WRITEONLY
RETURN

JSR PC,@(SP)+

WRITE ONLY PATTERN IN HI BYTE

SEQ 0871

```

100 051430          TASK03: SUBTST <<READ ONLY PATTERN IN HI BYTE>>
:*****
:*SUBTEST          READ ONLY PATTERN IN HI BYTE
:*****
101 051430          SUPERVISOR          :ENTER SUPERVISOR MODE
051430 052737 040000 177776      BIS      #BIT14,PSW          ;DO IT TO IT
      .DSABL CRF
102 051436 116005 062617      MOV      FIRST+TASK+1(R0),R5
103 051442 013737 062106 002106      MOV      FIRST+BANK,BANK
104 051450 104417          KERNEL          :ENTER KERNEL MODE
105 051452          SET      READONLY
      MOV      #-1,READONLY
051452 012737 177777 002504      MOV      #FIRST,R0
106 051460 012700 060000      MOV      #SIZE,R1
107 051464 012701 040000      CASE      R5
108 051470          MOV      R5,-(SP)
051470 010546          ASL @SP
051472 006316          JSR PC,L565
051474 004737 051514
109 051500 051530          SLPAT0          :ZEROS
110 051502 051534          SLPAT1          :ONES
111 051504 051542          SLPAT2          :125252
112 051506 051550          SLPAT3          :52525
113 051510 051556          SLPAT4          :377
114 051512 051564          SLPAT5          :177400
115 051514          END ;OF CASE R5
051514          L565:;
051514 062616          ADD (SP)+,@SP
051516 013646          MOV @ (SP)+,-(SP)
051520 004736          JSR PC,@(SP)+
116 051522 005037 002504      CLR      READONLY
117 051526 000207          RETURN
118
119 051530 005002          SLPAT0: CLR      R2
120 051532 000416          BR      SLPAT
121 051534          SLPAT1: SET      R2
051534 012702 177777          MOV      #-1,R2
122 051540 000413          BR      SLPAT
123 051542 012702 125252      SLPAT2: MOV      #125252,R2
124 051546 000410          BR      SLPAT
125 051550 012702 052525      SLPAT3: MOV      #52525,R2
126 051554 000405          BR      SLPAT
127 051556 012702 000377      SLPAT4: MOV      #377,R2
128 051562 000402          BR      SLPAT
129 051564 012702 177400      SLPAT5: MOV      #177400,R2
130 051570          SLPAT: SUBTST <<SLAVE PATTERNS>>
:*****
:*SUBTEST          SLAVE PATTERNS
:*****
131 051570          CLEAR      MARGIN,MAINT
051570 005037 002112          CLR      MARGIN
051574 005037 177750          CLR      MAINT
132 051600 104502          CLRCR      ;CLEAR MK11 CSRS
133 051602          BMOV      MTP000
051602 004537 043710          JSR R5,BLOCK1
051606 026376          MTP000
      .DSABL CRF
134 051610 012737 000207 177644      MOV      #207,U!PAR2          ;PUT RETURN INST AFTER WRITE ROUTINE

```

SLAVE PATTERNS

135 051616 012737 177646 00236G
 136 051624 004737 035204
 137 051630 104415
 138 051632
 051632 005737 002502
 051636 001402
 051640 004737 026042
 051644
 139 051644
 051644 005737 002504
 051650 001402
 051652 004737 026220
 051656
 140 051656 104416
 141 051660 104424
 142 051662 000207

MOV #L.PAR3,SUPDOADD
 CALL REGCOPY
 SAVREG
 IF WRITEONLY IS TRUE THEN \$CALL SUPD01

 IF READONLY IS TRUE THEN \$CALL SUPD03

 RESREG
 CACHOFF ;TURN CACHE OFF
 RETURN

TST WRITEONLY
 BEQ L566
 JSR PC,SUPD01
 L566:.....

 TST READONLY
 BEQ L567
 JSR PC,SUPD03
 L567:.....

```

145 051664          TASK04: SUBST <<EXECUTION CONTENTION TEST>>
:*****
: *SUBTEST      EXECUTION CONTENTION TEST
:*****
146 051664          SUPERVISOR          ;ENTER SUPERVISOR MODE
    051664 052737 040000 177776  BIS #BIT14,PSW          ;DO IT TO IT.
    .DSABL CRF
147 051672 013737 062106 002106  MOV FIRST+BANK,BANK
148 051700 104417          KERNEL          ;ENTER KERNEL MODE
149 051702 005060 002636          CLR PTYBUF(R0)
150 051706 012737 000037 002366  MOV #37,REALPAT
151 051714 012737 060000 002360  MOV #FIRST,SUPDOADD
152 051722          PUSH R0
    051722 010046          MOV R0,-(SP)
153 051724 062700 002636          ADD #PTYBUF,R0          ;R0 - PTYBUF + INDEX FOR CPU
154 051730 004737 026220          CALL SUPDO3
155 051734 104424          CACHOFF          ;TURN CACHE OFF
156 051736          MAP #0          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
    051736 010346          MOV R3,-(SP)
    051740 012703 000000          MOV #0,R3
    051744 004737 040700          CALL MAPPER
    .DSABL CRF
    051750 012603          MOV (SP)+,R3
157 051752          POP R0          MOV (SP)+,R0
    051752 012600
158 051754          SUPERVISOR          ;ENTER SUPERVISOR MODE
    051754 052737 040000 177776  BIS #BIT14,PSW          ;DO IT TO IT
    .DSABL CRF
159 051762 016060 002636 062636  MOV PTYBUF(R0),FIRST+PTYBUF(R0)
160 051770 104417          KERNEL          ;ENTER KERNEL MODE
161 051772 000207          RETURN
    
```

```

164 051774          TASK05: SUBST  <<PORT ARBITRATION SYMMETRY TEST>>
:.....
: *SUBTEST          PORT ARBITRATION SYMMETRY TEST
:.....
165 051774          SUPERVISOR          ;ENTER SUPERVISOR MODE
051774 052737 040000 177776  BIS #BIT14,PSW          ;DO IT TO IT
      .DSABL CRF
166 052002 013737 062106 002106  MOV FIRST+BANK,BANK
167 052010 104417          KERNEL          ;ENTER KERNEL MODE
168 052012          MAP BANK
      MOV BANK,R3          MOV R3,-(SP)
      052012 010346
      052014 013703 002106
      052020 004737 040700  CALL MAPPER
      .DSABL CRF
      MOV (SP)+,R3
169 052024 012603          SUPERVISOR          ;ENTER SUPERVISOR MODE
052026 052737 040000 177776  BIS #BIT14,PSW          ;DO IT TO IT
      .DSABL CRF
170 052034          BMOV TSK05A,FIRST+2
      052034 004537 043730  JSR R5,BLOCK2
      052040 060002  FIRST+2
      052042 052240  TSK05A
      .DSABL CRF
171 052044 104417          KERNEL          ;ENTER KERNEL MODE
172 052046 005060 002646  CLR PORTCOUNT(RO)
173 052052 010004          MOV RO,R4
174 052054          PUSH 100,102
      MOV 100,-(SP)
      052054 013746 000100  MOV 102,-(SP)
      052060 013746 000102
175 052064 012737 052224 000100  MOV #15,100
176 052072 012737 000340 000102  MOV #340,102
177 052100 012737 000100 177546  MOV #BIT6,LKS          ;ENABLE INTERRUPTS
178 052106 005000          CLR RO
179 052110 012701 060000          MOV #FIRST,R1
180 052114 000235          SPL 5
181 052116 012737 060002 002360  MOV #FIRST+2,SUPDOADD
182 052124 004737 026234  CALL SUPD04
183 052130 104424          CACHOFF          ;TURN CACHE OFF
184 052132 005037 177546  CLR LKS
185 052136 000237          SPL 7
186 052140 004737 026234  CALL SUPD04          ;DO TEST AS BACKGND WHILE OTHERR CPU'S FINISH
187 052144 104424          CACHOFF
188 052146          MAP #0          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
      MOV R3,-(SP)
      052146 010346
      052150 012703 000000  MOV #0,R3
      052154 004737 040700  CALL MAPPER
      .DSABL CRF
      MOV (SP)+,R3
189 052160 012603          MOV R4,RO
190 052162 010400          SUPERVISOR          ;ENTER SUPERVISOR MODE
052164 052737 040000 177776  BIS #BIT14,PSW          ;DO IT TO IT
      .DSABL CRF
191 052172 016060 002646 062646  MOV PORTCOUNT(RO),FIRST+PORTCOUNT(RO)
192 052200 104417          KERNEL          ;ENTER KERNEL MODE
193 052202          CLEAR MARGIN,MAINT
      052202 005037 002112  CLR MARGIN
      052206 005037 177750  CLR MAIN
    
```

194	052212		POP	102,100	
	052212	012637			MOV (SP)+,102
	052216	012637			MOV (SP)+,100
195	052222	000207			
196	052224		RETURN		
	052224	010046	PUSH	R0	MOV R0,-(SP)
197	052226	010400	MOV	R4,R0	
198	052230	005260	INC	PORTCOUNT(R0)	
199	052234		POP	R0	
	052234	012600			MOV (SP)+,R0
200	052236	000002	RTI		
201	052240	010505	TSK05A. MOV	R5,R5	
202	052242	010505	MOV	R5,R5	
203	052244	010505	MOV	R5,R5	
204	052246	010505	MOV	R5,R5	
205	052250	010505	MOV	R5,R5	
206	052252	010505	MOV	R5,R5	
207	052254	010505	MOV	R5,R5	
208	052256	010505	MOV	R5,R5	
209	052260	010505	MOV	R5,R5	
210	052262	010505	MOV	R5,R5	
211	052264	010505	MOV	R5,R5	
212	052266	010505	MOV	R5,R5	
213	052270	010505	MOV	R5,R5	
214	052272	010505	MOV	R5,R5	
215	052274	077017	SOS	R0,TSK05A	
216	052276	000207	RETURN		

```

219 052300          TASK06: SUBTST <<STOP SLAVE PROGRAM>>
:*****
:*SUBTEST          STOP SLAVE PROGRAM
:*****
220 052300 012706 000700          MOV    #USESTK,SP
221 052304 042737 001001 177572    BIC    #BIT9!BIT0,MMRO          ;DEENERGIZE MEMORY MANAGEMENT
222 052312 005037 002676          CLR    @DISPLAY
223 052316 005077 130446          CLR    @DISPLAY
224 052322 000137 011720          JMP    STOPCPU
225
226 052326          TASK07: SUBTST <<WRITE ONLY ADDRESS PATTERN IN HI BYTE>>
:*****
:*SUBTEST          WRITE ONLY ADDRESS PATTERN IN HI BYTE
:*****
227 052326          SET    WRITEONLY
228 052326 012737 177777 002502    MOV    #-1,WRITEONLY
228 052334 000403          BR     TASK7A
229
230 052336          TASK10: SUBTST <<READ ONLY ADDRESS PATTERN IN HI BYTE>>
:*****
:*SUBTEST          READ ONLY ADDRESS PATTERN IN HI BYTE
:*****
231 052336          SET    READONLY
231 052336 012737 177777 002504    MOV    #-1,READONLY
232 052344          TASK7A: SUPERVISOR          ;ENTER SUPERVISOR MODE
232 052344 052737 040000 177776    BIS    #BIT14,PSW          ;DO IT TO IT
          .DSABL CRF
233 052352 116001 062617          MOV    FIRST+TASK+1(R0),R1
234 052356 013737 062106 002106    MOV    FIRST+BANK,BANK
235 052364 104417          KERNEL          ;ENTER KERNEL MODE
236 052366          IF R1 EQ #0
236 052366 005701          TST R1
236 052370 001011          BNE L570
237 052372          BMOV MTP001          ;ADDRESS PATTERN
237 052372 004537 043710    JSR R5,BLOCK1
237 052376 026422    MTP001
          .DSABL CRF
238 052400 012700 060000          MOV    #FIRST,R0
239 052404 005002          CLR    R2
240 052406 010004          MOV    R0,R4
241 052410 010205          MOV    R2,R5
242 052412          ELSE
242 052412 000413          BR L571
242 052414          L570:*****
243 052414          BMOV MTP002          ;COMPLEMENT ADDRESS PATTERN
243 052414 004537 043710    JSR R5,BLOCK1
243 052420 026454    MTP002
          .DSABL CRF
244 052422 012700 160000          MOV    #LAST+2,R0
245 052426 012702 000001          MOV    #1,R2
246 052432 012704 060000          MOV    #FIRST,R4
247 052436 012705 100001          MOV    #100001,R5
248 052442          END ;OF IF R1
248 052442          L571:*****
249 052442 012701 040000          MOV    #SIZE,R1
250 052446 010103          MOV    R1,R3
251 052450 012737 000207 177650    MOV    #207,UIPAR4          ;RETURN INSTRUCTION
    
```


252	052456	012737	177652	002360	MOV #UJPARS,SUPDOADD	:READ ONLY STARTING ADDRESS	
253	052464				CLEAR MARGIN,MAINT		CLR MARGIN
	052464	005037	002112				CLR MAINT
	052470	005037	177750				
254	052474	104502			CLRCR	:CLEAR MK11 CSRS	
255	052476				IF WRITEONLY IS TRUE THEN \$CALL SUPD01		
	052476	005737	002502				TST WRITEONLY
	052502	001402					BEQ L572
	052504	004737	026042				JSR PC,SUPD01
	052510						L572::::::::::
256	052510				IF READONLY IS TRUE THEN \$CALL SUPD03		
	052510	005737	002504				TST READONLY
	052514	001402					BEQ L573
	052516	004737	026220				JSR PC,SUPD03
	052522						L573::::::::::
257	052522	104424			CACHOFF	:TURN CACHE OFF	
258	052524				CLEAR READONLY,WRITEONLY		
	052524	005037	002504				CLR READONLY
	052530	005037	002502				CLR WRITEONLY
259	052534	000207			RETURN		

262 052536
 263 052536 052737 040000 177776
 264 052544 116001 062617
 265 052550 013737 062106 002106
 266 052556 104417
 267 052560 072127 000011
 268 052564 010100
 269 052566 012701 010000
 270 052572 052572 012737 177777 002502
 052600 012737 177777 002504
 271 052606 004737 051530
 272 052612 004737 051534
 273 052616 004737 051542
 274 052622 004737 051550
 275 052626 004737 051556
 276 052632 052632 005037 002502
 052636 005037 002504
 277 052642 000207
 278
 279 052644

```
TASK11: SUBTST <<RUN FIVE PATTERNS IN DESIGNATED 1/4 BANK>>
:*****
:*SUBTEST      RUN FIVE PATTERNS IN DESIGNATED 1/4 BANK
:*****
SUPERVISOR          ;ENTER SUPERVISOR MODE
BIS      #BIT14,PSW      ;DO IT TO IT.
.DSABL   CRF
MOVB    FIRST+TASK+1(R0),R1
MOV     FIRST+BANK,BANK
KERNEL          ;ENTER KERNEL MODE
ASH     #9.,R1
MOV     R1,R0
MOV     #SIZE/4,R1
SET     WRITEONLY,READONLY

MOV     #-1,WRITEONLY
MOV     #-1,READONLY

CALL    SLPAT0
CALL    SLPAT1
CALL    SLPAT2
CALL    SLPAT3
CALL    SLPAT4
CLEAR   WRITEONLY,READONLY

CLR     WRITEONLY
CLR     READONLY

RETURN
```

```
TASK12: SUBTST <<WRITE & READ A SKEWED UP ADDRESS TEST>>
:*****
:*SUBTEST      WRITE & READ A SKEWED UP ADDRESS TEST
:*****
SUPERVISOR          ;ENTER SUPERVISOR MODE
BIS      #BIT14,PSW      ;DO IT TO IT!
.DSABL   CRF
MOVB    FIRST+TASK+1(R0),R1
KERNEL          ;ENTER KERNEL MODE

;PAY ATTENTION NOW.
;R0 - MULTIPORT ID # (0,2,4,6)
;R1 = OFFSET STARTING ADDRESS (0,2,4,6)
MOV     R0,R4
ADD     R1,R4          ;R4 IS NOW UNIQUE AMONST THE 4 CPU'S

MOV     #SIZE/4,R5
MOV     #FIRST,R3
BMOV    MTPA32
JSR     R5,BLOCK1
MTPA32
.DSABL   CRF

SAVREG
CALL    SUPD01
BMOV    MTPB32
JSR     R5,BLOCK1
MTPB32
.DSABL   CRF

RESREG
CALL    SUPD02
RETURN
```

```

301 052726          TASK13: SUBTST <<SETUP FOR ASRB TEST>>
:*****
:*SUBTEST          SETUP FOR ASRB TEST
:*****
302 052726          BMOV          TSK13A
052726 004537 043710 JSR R5,BLOCK1
052732 053100          TSK13A
                                .DSABL          CRF
303 052734 012777 177640 130000 MOV          #UIPARO,@IISTVEC          ;CAUSE WE SIMULATE TRAPS
304 052742          SUPERVISOR          ;ENTER SUPERVISOR MODE
052742 052737 040000 177776 BIS          #BIT14,PSW          ;DO IT TO IT!
                                .DSABL          CRF
305 052750 013737 062106 002106 MOV          FIRST+BANK,BANK
306 052756 052760 100000 062616 BIS          #BIT15,FIRST+*ASK(R0)          ;ACK
307 052764 104417          KERNEL          ;ENTER KERNEL MODE
308 052766          MAP          BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
052766 010346          MOV R3,-(SP)
052770 013703 002106          MOV          BANK,R3
052774 004737 040700          CALL          MAPPER
                                .DSABL          CRF
                                MOV (SP)+,R3
309 053000 012603          IF CPUBIT NE #MASTER          CMP CPUBIT,#MASTER
053002 023727 002114 000020          BEQ L574
053010 001432          FOR R2 := #FIRST TO #FIRST+34 BY #4          MOV #FIRST,R2
310 053012 012702 060000          FOR I := #1 TO #1000.          B74:*****
053016          MOV #1,I
311 053016 012737 000001 002602          SUPERVISOR          ;ENTER SUPERVISOR MODE
053024          BIS          #BIT14,PSW          ;DO IT TO IT!
312 053024 052737 040000 177776          .DSABL          CRF
053032 005737 060002          1$:          TST          FIRST+2
314 053036 001775          BEQ          1$
315          ;DISPATCH THRU THE IIST VECTOR
316 053040 017701 127676          MOV          @IISTVEC,R1
317 053044 004711          CALL          (R1)
318 053046          END ;OF FOR I
053046 005237 002602          INC I
053052 023727 002602 001750          CMP I,#1000.
053060 003761          BLE B75
053062          E75:*****
319 053062          END ;OF FOR R2
053062 062702 000004          ADD #4,R2
053066 020227 060034          CMP R2,#FIRST+34
053072 003751          BLE B74
053074          E74:*****
320 053074 104417          KERNEL          ;ENTER KERNEL MODE
321 053076          END ;OF IF CPUBIT
053076          L574:*****
322 053076 000207          RETURN
323
324 053100 000240          TSK13A: NOP          ;V177640
325 053102 000240          NOP          ;V177642
326 053104 000240          NOP          ;V177644
327 053106 000240          NOP          ;V177646
    
```

328	053110	000240		NOP		:V177650
329	053112	000240		NOP		:V177652
330	053114	000240		NOP		:V177654
331	053116	000240		NOP		:V177656
332	053120	000240		NOP		:V177660
333	053122			SUPERVISOR		:V177662
	053122	052737	040000	177776	BIS #BIT14,PSW	:ENTER SUPERVISOR MODE
					.DSABL CRF	:DO IT TO IT!
334	053130	106212		ASRB (R2)		:V177670
335	053132	000137	053136	JMP TSK13B		:V177672

```

338 053136          TSK138: SUBTST <<RECOVER FROM TASK13 - TRAP FROM IIST>>
:*****
: *SUBTEST          RECOVER FROM TASK13 - TRAP FROM IIST
:*****
          ON.ERROR
339 053136          BCC L575
          053136 103021
340 053140          SET SLFLAG(R0)          ;I LOCKED IT!!!
          053140 012760 177777 002656          MOV #-1,SLFLAG(R0)
341 053146          SUB SLAVES,@IISTVEC
          053146 163777 002730 127566          SUB SLAVES,@IISTVEC
342 053154          SUB SLAVES,@IISTVEC
          053154 163777 002730 127560          IF @IISTVEC LO #UIPARO THEN LET @IISTVEC := #UIPARO
343 053162          CMP @IISTVEC,#UIPARO
          053162 027727 127554 177640          BHS L576
          053170 103003          MOV #UIPARO,@IISTVEC
          053172 012777 177640 127542          L576:::::
          053200          ELSE
344 053200          BR L577
          053200 000414          L575:::::
          053202          ;IT WAS LOCKED BY SOMEONE ELSE
345 053202          CLR SLFLAG(R0)
          053202 005060 002656          ADD #2,@IISTVEC
346 053206          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
          053206 062777 000002 127526          IF @IISTVEC HI #UDPAR1 THEN LET @IISTVEC := #UDPAR1
347 053214          CMP @IISTVEC,#UDPAR1
          053214 027727 127522 177662          BLOS L600
          053222 101403          MOV #UDPAR1,@IISTVEC
          053224 012777 177662 127510          L600:::::
348 053232          END ;OF ON.NOERROR
          053232          L577:::::
349 053232          MAP #0          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
          053232 010346          MOV R3,-(SP)
          053234 012703 000000          MOV #0,R3
          053240 004737 040700          CALL MAPPER
          .DSABL CRF
          MOV (SP)+,R3
350 053244          MOV SLFLAG(R0),FIRST+SLFLAG(R0)
          053244 012603          MAP BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
351 053254          MOV R3,-(SP)
          053254 010346          MOV BANK,R3
          053256 013703 002106          CALL MAPPER
          053262 004737 040700          .DSABL CRF
          MOV (SP)+,R3
          053266 012603
352 053270          CLR FIRST+2
          053270 005037 060002          RETURN
353 053274          000207
    
```

```

356 053276          TASK14: SUBTST <<RESET FROM ASRB TEST>>
:*****
:*SUBTEST          RESET FROM ASRB TEST
:*****
357 053276 000237          SPL          7
358 053300 012777 061216 127434      MOV          #SLAVUP,@IISTVEC
359 053306 000207          RETURN
360
361 053310          TASK15: SUBTST <<RUN SLAVE IN CSR TESTS>>
:*****
:*SUBTEST          RUN SLAVE IN CSR TESTS
:*****
362 053310 004737 016664          CALL          MKCONTROL
363 053314 000207          RETURN
364
365 053316          TASK16: SUBTST <<SET MARGIN 6, CPU HAS I/O PRIORITY>>
:*****
:*SUBTEST          SET MARGIN 6, CPU HAS I/O PRIORITY
:*****
366 053316 012737 000014 177750      MOV          #14,MAINT
367 053324 012737 000006 002112      MOV          #6,MARGIN
368 053332 000207          RETURN
369
370 053334          TASK17: SUBTST <<CREATE STALE DATA TEST>>
:*****
:*SUBTEST          CREATE STALE DATA TEST
:*****
371 053334          SUPERVISOR
053334 052737 040000 177776      BIS          #BIT14,PSW          ;DO IT TO IT.
                                .DSABL CRF
372 053342 013737 062106 002106      MOV          FIRST+BANK,BANK
373 053350 104417          KERNEL
374 053352          MAP          BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
                                MOV R3,-(SP)
                                053352 010346
                                053354 013703 002106
                                053360 004737 040700
                                MOV          BANK,R3
                                CALL         MAPPER
                                .DSABL CRF
                                MOV (SP)+,R3
375 053364 012603          SUPERVISOR
053366 052737 040000 177776      BIS          #BIT14,PSW          ;ENTER SUPERVISOR MODE
                                .DSABL CRF          ;DO IT TO IT.
                                MOV          #FIRST,R0
376 053374 012700 060000          MOV          #FIRST+4,R1
377 053400 012701 060004          MOV          #FIRST+4,R1
378 053404 022711 047507          1$: CMP          #'GO,(R1)          ;TIME TO GO?
379 053410 001375          BNE         1$          ;NO - LOOP
380 053412 012710 177777          MOV          #-1,(R0)          ;WRITE WORD
381 053416 104417          KERNEL
382 053420 000207          RETURN          ;ENTER KERNEL MODE
    
```

```

385 053422          TASK20: SUBTST <<CACHE FLUSH TEST>>
:*****
:*SUBTEST          CACHE FLUSH TEST
:*****
386 053422          BMOV   TSK20A
053422 004537 043710 JSR   R5,BLOCK1
053426 053602          TSK20A
                          .DSABL   CRF
387 053430          SUPERVISOR          ;ENTER SUPERVISOR MODE
053430 052737 040000 177776 BIS   #BIT14,PSW          ;DO IT TO IT
                          .DSABL   CRF
388 053436 013737 062106 002106 MOV   FIRST+BANK,BANK
389 053444 104417          KERNEL          ;RETURN TO KERNEL MODE
390 053446          MAP   BANK
053446 010346          MOV   BANK,R3          MOV R3,-(SP)
053450 013703 002106          CALL  MAPPER
053454 004737 040700          .DSABL  CRF
053460 012603          MOV   #FIRST,R0          MOV (SP)+,R3
391 053462 012700 060000          MOV   #FIRST+4,R1
392 053466 012701 060004          CLR   R2
393 053472 005002          ;WAIT FOR ANY FLUSH TO FINISH
394          SOB   R2,1$
395          SUPERVISOR          ;ENTER SUPERVISOR MODE
396 053474 077201          BIS   #BIT14,PSW          ;DO IT TO IT.
397          .DSABL  CRF
398 053476 052737 040000 177776 CALL  FASTCITY
053476 052737 040000 177776 CLR   4(R0)          ;KILL THE GO SIGNAL
399 053504 004737 177640          KERNEL          ;ENTER KERNEL MODE
400 053510 005060 000004          ;VERIFY STALE DATA
401 053514 104417          CMP   #0,R1          ;CHECK FOR STALE DATA
402          BEQ   2$          ;OK - SKIP
403          MOV   #0,GOOD          ;REPORT ERROR
404 053516 022701 000000          MOV   R1,BAD
405 053522 001411          MOV   #FIRST,ADDRESS
406 053524 012737 000000 002050 ERROR  +55
407 053532 010137 002056          ;VERIFY THAT FLUSHING GETS RID OF STALE DATA
408 053536 012737 060000 002040 CMP   #-1,R2          ;CHECK FOR GOOD DATA
409 053544 104055          BEQ   5$          ;OK - SKIP
410          MOV   #-1,GOOD          ;REPORT ERROR
411          MOV   R2,BAD
412 053546 022702 177777          MOV   #FIRST,ADDRESS
413 053552 001411          ERROR  +56
414 053554 012737 177777 002050          CACHOFF          ;TURN CACHE OFF
415 053562 010237 002056          RETURN
416 053566 012737 060000 002040
417 053574 104056
418
419 053576 104424          TSK20A: SUBTST <<CACHE FLUSH TEST (FOR PAR'S)>>
420 053600 000207          :*****
421          :*SUBTEST          CACHE FLUSH TEST (FOR PAR'S)
422 053602          :*****
053602 012737 000401 177746 MOV   #BIT8!BIT0,CONTRL          ;V177640 ;TURN ON CACHE & FLUSH IT

```

424	053610	012710	000000		MOV	#0,(R0)		:V177646	:WRITE FRESH DATA
425	053614	005710			TST	(R0)		:V177652	:READ - CREATING A CACHE HIT
426	053616	012711	047507		MOV	#'GO,(R1)		:V177654	:SIGNAL SLAVES TO MAKE STALE DATA
427	053622	077201		1\$:	SOB	R2,1\$:V177660	:WAIT FOR SLAVES TO FINISH
428	053624	011001			MOV	(R0),R1		:V177662	:STALE DATA ----> R1
429	053626	012737	000401	177746	MOV	#BIT8:BIT0,CONTRL		:V177664	:FLUSH CACHE AGAIN
430	053634	011002			MOV	(R0),R2		:V177672	:FRESH DATA ----> R2
431	053636	000207			RETURN			:V177674	

434 053640

MRUNSETUP:SUBTST <<SETUP EXECUTION CONTENTION TEST>>

 :SUBTEST SETUP EXECUTION CONTENTION TEST

435 053640

MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
 MOV R3,-(SP)

053640 010346
 053642 013703 002106
 053646 004737 040700

MOV BANK,R3
 CALL MAPPER
 .DSABL CRF

436 053652

053652 012603
 053654 012700 060000

MOV #FIRST,R0
 WHILE R0 LO #LAST

MOV (SP)+,R3

437 053660

053660
 053660 020027 157776
 053664 103023

B76:*****
 CMP R0,#LAST
 BHIS L601

438 053666

053666 004737 074720
 439 053672 013701 002714
 440 053676 012702 000020

CALL \$RAND
 MOV SEEDHI,R1
 MOV #16,R2
 SUPERVISOR ;ENTER SUPERVISOR MODE
 BIS #BIT14,PSW ;DO IT TO IT.
 .DSABL CRF
 THRU R2

442 053710

053710
 443 053710 006101
 444 053712

RGL R1
 ON.ERROR

B77:*****

445 053714

053714 012720 005210
 446 053720

MOV #5210,(R0)+ ;INC (R0) INSTRUCTION
 ELSE

BCC L602

447 053722

053722 012720 005710
 448 053726

MOV #5710,(R0)+ ;TST (R0) INSTRUCTION
 END ;OF ON.ERROR

L602:*****

449 053726

053726 077210
 053730

END ;OF THRU R2

L603:*****

450 053730

053730 104417
 451 053732

KERNEL ;ENTER KERNEL MODE
 END ;OF WHILE R0

SOB R2,B77 ; **** EIS INST.
 E77:*****

452 053734

053734 052737 040000 177776
 053734
 053734

SUPERVISOR ;ENTER SUPERVISOR MODE
 BIS #BIT14,PSW ;DO IT TO IT.
 .DSABL CRF

BR B76

453 053742

053742 012740 000207
 454 053746 104417
 455 053750 000207

MOV #207,-(R0) ;RETURN INSTRUCTION
 KERNEL ;ENTER KERNEL MODE
 RETURN

L601:*****

E76:*****


```

481 054152 012737 061165 002574      MOV      #5*SECONDS,MUNGTIME
482 054160 004737 072154      2$:     CALL      QUE
483 054164 103005      ON.ERROR
                                           BCC L605
484 054166 010037 002056      MOV      RO,BAD
485 054172 104060      ERROR    +60      ;SLAVE MUNG SYSTEM!
486 054174 000261      $RETURN  ERROR
                                           SEC
487 054200 000207      END ;OF ON.ERROR
                                           RTS PC
                                           L605:::
488 054200 005761 002616      TST      TASK(R1)
489 054204 100365      BPL      2$
490 054206 005200      END ;OF FOR RO
                                           INC RO
                                           CMP RO,SLAVES
                                           BLE B102
                                           E102:::
491 054216 005000      ;I ASSUME THEY HAVE FINISHED COMPLETELY AFTER THIS DELAY
492 054220 077001      CLR RO
493 054222 012702 060000      SOB RO,1$
494 054222 012702 060000      FOR R2 : #FIRST TO #FIRST+34 BY #4
                                           MOV #FIRST,R2
                                           B103:::
495 054226 012737 000001 002602      FOR I := #1 TO #1000.
                                           MOV #1,I
                                           B104:::
496 054234 052737 040000 177776      BIS      SUPERVISOR
                                           ;ENTER SUPERVISOR MODE
                                           ;DO IT TO IT!
                                           .DSABL  CRF
497 054242 012712 000001      MOV      #1,(R2)      ;UNLOCK TEST LOCATION
498 054246 004737 054544      CALL     WAKEUP
500      ;RECORD WINNER(S)
501 054252 005000      CLR      RO
502 054254 005001      FOR R1 := #0 TO #6 BY #2
                                           CLR R1
                                           B105:::
503 054256 005761 002656      IF SLFLAG(R1) IS TRUE
                                           TST SLFLAG(R1)
                                           BEQ L606
504 054264 005261 002646      INC PORTCOUNT(R1)
505 054270 005200      INC RO
506 054272 005200      END ;OF IF SLFLAG
                                           L606:::
507 054272 062701 000002      END ;OF FOR R1
                                           ADD #2,R1
                                           CMP R1,#6
                                           BLE B105
                                           E105:::
508 054304 020027 000001      ;CHECK FOR ONE & ONLY ONE LOCK
509 054304 001401      IF RO NE #1
                                           CMP RO,#1
                                           BEQ L607
511 054312 104033      ERROR +33
512 054314      END ;OF IF RO
    
```

```

513 054314          END ;OF FOR I
      054314          005237 002602
      054320          023727 002602 001750
      054326          003742
      054330
514 054330          END ;OF FOR R2
      054330          062702 000004
      054334          020227 060034
      054340          003732
      054342
515 054342          KERNEL
516 054344          CALL      M13BAI
517 054350          END ;OF IF PFLAG
      054350
518 054350          END ;OF FOR BANK
      054350          005237 002106
      054354          023727 002106 000167
      054362          003604
      054364
519 054364          FOR RO : #1 TO SLAVES
      054364          012700 000001
      054370
520 054370          MOV      RO,R1
521 054372          ASL      R1
522 054374          MOV      #14,TASK(R1)
523 054402          END ;OF FOR RO
      054402          005200
      054404          020037 002730
      054410          003767
      054412
524 054412          FOR RO := #1 TO SLAVES
      054412          012700 000001
      054416
525 054416          MOV      RO,R1
526 054420          ASL      R1
527 054422          MOV      #5*SECONDS,HUNGTIME
528 054430          CALL     QUE
529 054434          ON.ERROR
      054434          103005
530 054436          MOV     RO,BAD
531 054442          ERROR   +60
532 054444          $RETURN  ERROR
      054444          000261
      054446          000207
533 054450          END ;OF ON.ERROR
      054450
534 054450          TST     TASK(R1)
535 054454          BPL     3$
536 054456          END ;OF FOR RO
      054456          005200
      054460          020037 002730
      054464          003754
      054466
537 054466          $RETURN NOERROR
      054466          000241
      054470          000207
  
```

```

L607:.....
      INC I
      CMP !,#1000.
      BLE B104
E104:.....
      ADD #4,R2
      CMP R2,#FIRST+34
      BLE B103
E103:.....
:CALL BALANCE TEST
L604:.....
      INC BANK
      CMP BANK,#167
      BLE B100
.E100:.....
      MOV #1,RO
B106:.....
:ORDERS TO RESET FROM ASRB TEST
      INC RO
      CMP RO,SLAVES
      BLE B106
E106:.....
      MOV #1,RO
B107:.....
      BCC L610
:SLAVE HUNG SYSTEM!
      SEC
      RTS PC
L610:.....
:WAIT FOR ALL CPU'S DONE
      INC RO
      CMP RO,SLAVES
      BLE B107
E107:.....
      CLC
      RTS PC
  
```

530

.DSABL LSB

```

541 054472 M3BAL: SUBTST <<BALANCE TEST>>
:*****
:SUBTEST BALANCE TEST
:*****
542 054472 BEGIN ASRBALANCE
543 054472 FOR R0 :- #0 TO SLAVES B110:*****
054472 005000 CLR R0
054474 B111:*****
544 054474 010001 MOV R0,R1
545 054476 006301 ASL R1
546 054500 013702 002646 MOV PORTCOUNT,R2
547 054504 166102 002646 SUB PORTCOUNT(R1),R2
548 054510 062702 000400 ADD #256.,R2 ;# HERE & IN NEXT INST IS + OR - COUNT SPEC
549 054514 IF R2 LT #0 OR R2 GT #256.*2
054514 005702 TST R2
054516 002403 BLT L611
054520 020227 001000 CMP R2,#256.*2
054524 003402 BLE L612
054526 L611:*****
550 054526 104053 ERROR LEAVE +53 ASRBALANCE
551 054530 000404 BR E110
552 054532 END ;OF IF R2
054532 L612:*****
553 054532 END ;OF FOR R0
054532 005200 INC R0
054534 020037 002730 CMP R0,SLAVES
054540 003755 BLE B111
054542 E111:*****
554 054542 END ASRBALANCE E110:*****
054542 RETURN
555 054542 000207
556
557
558 054544 WAKEUP: ;WAKE UP EVERY CPU
054544 012737 177777 060002 SET FIRST+2 MOV #-1,FIRST+2
559 ;INCLUDING MYSELF
560 054552 000240 NOP
561 054554 000240 NOP
562 054556 005000 CLR R0
563 054560 017701 126156 MOV @IISTVEC,R1
564 054564 004711 CALL (R1)
565 054566 000207 RETURN

```

```

568 .SBTTL ERROR DATA (SUPERVISOR) SETUP STUFF
569 054570 010137 002040 $PER25: LET ADDRESS := R1 - #2
    054570 162737 000002 002040 MOV R1,ADDRESS
    054574 162737 000002 002040 SUB #2,ADDRESS
570 054602 IF ABORTFLAG IS FALSE
    054602 005737 002142 TST ABORTFLAG
    054606 001007 BNE L613
571 054610 SUPERVISOR ;ENTER SUPERVISOR MODE
    054610 052737 040000 177776 BIS #BIT14,PSW ;DO IT TO IT!
    .DSABL CRF
    LET BAD : -2(R1)
572 054616 016137 177776 002056 MOV -2(R1),BAD
    054616 104417 177776 002056 ;ENTER KERNEL MODE
573 054624 KERNEL
574 054626 END ;OF IF ABORTFLAG
    054626 005737 177654 IF 177654 EQ #0 L613:;;;;;
    054632 001003 TST 177654
    054634 LET GOOD :- R2 BNE L614
    054634 010237 002050 MOV R2,GOOD
577 054640 ELSE BR L615
    054640 000402 L614:;;;;;
    054642 LET GOOD := R3 MOV R3,GOOD
578 054642 010337 002050 END ;OF IF L615:;;;;;
579 054646 JMP PERRAW
580 054646 000137 065330
581
582 054652 PERRA3: SUBTST <<DATA WAS 3 WORDS>>
    ;*****
    ;*SUBTEST DATA WAS 3 WORDS
    ;*****
    054652 005737 002026 IF BADPC EQ #0 THEN $CALL BADSTACK
    054656 001002 TST BADPC
    054660 004737 036770 BNE L616
    054664 JSR PC,BADSTACK
584 054664 PUSH R0 L616:;;;;;
    054666 010046 MOV R0,-(SP)
585 054666 104505 CHK1DIS ;DISABLE ECC & WRITE CHECKBITS FROM 1 SELECTED CSR
586 054670 104426 READCSR
587 054672 013700 002144 MOV (CSR,R0)
588 054676 000300 SWAB R0
589 054700 042700 177600 BIC #*C177,R0
590 054704 104503 CLR1CSR ;CLEAR 1 SELECTED MK11 CSR
591 054706 LET ADDRESS :- R1
    054706 010137 002040 MOV R1,ADDRESS
592 054712 005037 002050 CLR GOOD
593 054716 SUPERVISOR ;ENTER SUPERVISOR MODE
    054716 052737 040000 177776 BIS #BIT14,PSW ;DO IT TO IT!
    .DSABL CRF
    MOV (R1),BAD
    MOV 2(R1),BAD2
594 054724 011137 002056 MOV (R1),BAD
595 054730 016137 000002 002060 MOV 2(R1),BAD2
596 054736 104417 177600 ;ENTER KERNEL MODE
597 054740 110037 002062 MOVB R0,BAD3
598 054744 105037 002063 CLRB BAD3+1
    
```

599 054750 004737 065564
600 054754 104034
601 054756
 054756 012600
602 054760 000002

CALL PERBANK
ERROR +34
POP R0

RTI

MOV (SP)+,R0


```

605 054762          SPER30: LET GOOD := R1
      054762 010137 002050
606 054766          LET ADDRESS : (SP) - 16
      054766 011637 002040
      054772 163737 000016 002040
607 055000          IF ABORTFLAG IS FALSE
      055000 005737 002142
      055004 001007
608 055006          SUPERVISOR          ;ENTER SUPERVISOR MODE
      055006 052737 040000 177776    BIS      #BIT14,PSW          ;DO IT TO IT.
      .DSABL CRF
      LET BAD :- @ADDRESS
609 055014          KERNEL          ;ENTER KERNEL MODE
      055014 017737 125020 002056    END ;OF IF ABORTFLAG
610 055022          JMF PERRAW          L617:;:;:;:
      055022 104417
611 055024
      055024
612 055024 000137 065330
613
614 055030          GETDATA:SUBST <<GET DATA FROM ABORTED AREA IF POSSIBLE>>
      ;*****
      ;*SUBTEST      GET DATA FROM ABORTED AREA IF POSSIBLE
      ;*****
      PUSH      RO,4,114
615 055030          MOV RO,-(SP)
      055030 010046          MOV 4,-(SP)
      055032 013746 000004          MOV 114,-(SP)
      055036 013746 000114
616 055042 010637 055156          MOV SP,GETDA1
617 055046 012737 055122 000004    MOV #1$,4
618 055054 012737 055122 000114    MOV #1$,114
619 055062 013700 002040          MOV ADDRESS,RO
620 055066 052737 000001 177750    BIS #BIT0,MAINT
621 055074 052737 004000 177746    BIS #BIT11,CONTRL ;DISABLE ABORTS
622 055102          SUPERVISOR
      055102 052737 040000 177776    BIS #BIT14,PSW          ;DO IT TO IT!
      .DSABL CRF
      MOV (RO),BAD
623 055110 011037 002056          KERNEL
624 055114 104417
625 055116 005037 002142          CLR ABORTFLAG
626 055122 013706 055156          1$: MOV GETDA1,SP          ;RESTORE KNOWN GOOD STACK POINTER
627 055126 042737 004000 177746    BIC #BIT11,CONTRL      ;ENABLE ABORTS
628 055134 042737 000001 177750    BIC #BIT0,MAINT
629 055142          POP 114,4,RO
      055142 012637 000114          MOV (SP)+,114
      055146 012637 000004          MOV (SP)+,4
      055152 012600          MOV (SP)+,RO
630 055154 000207          RETURN
631 055156 000000          GETDA1: 0
  
```

```

634 .SBTTL POWER FAIL AUTO RESTART
635 .SBTTL ROUTINE POWER DOWN AND UP
636 :*****
637 :POWER DOWN ROUTINE
638 SPURDN: IF CPUBIT NE #MASTER
                                CMP CPUBIT,#MASTER
                                BEQ L620
055160 023727 002114 000020
055166 001402
639 055170 000000
640 055172 000776
641 055174
        DNSLAV: HALT
                BR     DNSLAV
                END ;OF IF CPUBIT
055174 012737 000376 002760
        MOV     #376,PWLOCK
        ;SAVE CACHE & MARGIN STATUS
        PUSH   CONTRL,MAINT
                                L620:::
                                MOV CONTRL,-(SP)
                                MOV MAINT,-(SP)
055202 013746 177746
055206 013746 177750
645 055212 104423
        CACHON ;TURN CACHE ON
646 055214 012737 056134 000024
        MOV     #511LLUP,PWRVEC ;:SET FOR FAST UP
647 055222 012737 000340 000026
        MOV     #340,PWRVEC+2 ;:PRIO:7
648 055230
        PUSH   R0,R1,R2,R3,R4,R5,CSRNO
                                MOV R0,-(SP)
                                MOV R1,-(SP)
                                MOV R2,-(SP)
                                MOV R3,-(SP)
                                MOV R4,-(SP)
                                MOV R5,-(SP)
                                MOV CSRNO,-(SP)
055230 010046
055232 010146
055234 010246
055236 010346
055240 010446
055242 010546
055244 013746 002256
        ;SAVE USER PAR'S & PDR7
649 055250 012700 177700
        MOV     #177700,R0
650 055254 012701 000021
        MOV     #17.,R1
651 055260
        PUSH   -(R0)
                                MOV -(R0),-(SP)
055260 014046
653 055262 077102
        SOB    R1,1$
        ;SAVE SUPERVISOR PAR'S
654 055264 012700 172300
        MOV     #172300,R0
655 055270 012701 000020
        MOV     #16.,R1
656 055274
        PUSH   -(R0)
                                MOV -(R0),-(SP)
055274 014046
658 055276 077102
        SOB    R1,2$
        IF RLFLAG IS TRUE THEN $CALL WOOPS
659 055300
                                TST RLFLAG
                                BEQ L621
                                JSR PC,WOOPS
055300 005737 002134
055304 001402
055306 004737 056160
                                L621:::
055312
        ;COPY KERNEL MAP TO USER & SUPERVISOR
660 055312 012700 172300
        MOV     #KIPDRO,R0
661 055316 012701 177600
        MOV     #UIPDRO,R1
662 055322 012702 172200
        MOV     #SIPDRO,R2
663 055326 012703 000040
        MOV     #32.,R3
664 055332 011021
        MOV     (R0),(R1)+
665 055334 012022
        MOV     (R0)+,(R2)+
666 055336 077303
        SOB    R3,3$
    
```

```

669 ;SAVE USER & SUPERVISOR STACK POINTERS
670 055340 USER
055340 052757 140000 177776 BIS #BIT15:BIT14,PSW ;DO IT TO IT!
.DSABL CRF
MOV USP,R0
671 055346 010600 KERNFL ;ENTER KERNEL MODE
672 055350 104417 PUSH R0
673 055352 010046 SUPERVISOR ;ENTER SUPERVISOR MODE
055352 010046 BIS #BIT14,PSW ;DO IT TO IT!
.DSABL CRF
MOV SSP,R0
674 055354 052737 040000 177776 KERNFL ;ENTER KERNEL MODE
055354 010046 PUSH R0
MOV RO,-(SP)
675 055362 010400 ;SAVE MK11 REGISTERS
676 055364 104417 MOV MKCSRS,R1 ;GET CSR'S BYTE
677 055366 010046 BEGIN LCSRSAVE
MOV RO,-(SP)
678 ;SAVE MK11 REGISTERS
679 055370 013701 002334 MOV MKCSRS,R1 ;GET CSR'S BYTE
680 055374 BEGIN LCSRSAVE
FOR CSRNO := #0 TO #34 BY #4 B112:;;;;;
055374 005037 002256 CLR CSRNO
055400 B113:;;;;;
682 055400 106301 ASLB R1
683 055402 103005 ON.ERROR
BCC L622
684 055404 104426 READCSR
685 055406 013746 002144 PUSH CSR,CSR+2
MOV CSR,-(SP)
055412 013746 002146 MOV CSR+2,-(SP)
686 055416 END ;OF ON.ERROR
L622:;;;;;
055416 IFB R1 EQ #0 THEN LEAVE LCSRSAVE
TSTB R1
687 055416 105701 BEQ E112
055420 001407
688 055422 062737 000004 002256 END ;OF FOR CSRNO
ADD #4,CSRNO
055430 023727 002256 000034 CMP CSRNO,#34
055436 003760 BLE B113
689 055440 END LCSRSAVE
E113:;;;;;
055440 E112:;;;;;
690 ;SAVE MMR0,1,2,3
691 055440 PUSH MMR0,MMR1,MMR2,MMR3
MOV MMR0,-(SP)
055440 013746 177572 MOV MMR1,-(SP)
055444 013746 177574 MOV MMR2,-(SP)
055450 013746 177576 MOV MMR3,-(SP)
055454 013746 172516
692 ;SAVE KERNEL PAR'S
693 055460 012700 172400 MOV #172400,R0
694 055464 012701 000020 MOV #16,R1
695 055470 014046 4$: PUSH -(R0)
MOV -(R0),-(SP)
696 055472 077102 SOB R1,4$
697 ;SAVE UNIBUS MAP REGISTERS
698 055474 013746 170372 PUSH MAPH36,MAPL36,MAPH0,MAPL0
MOV MAPH36,-(SP)
055474 013746 170370 MOV MAPL36,-(SP)
055500 013746 170370

```

```

055504 013746 170202
055510 013746 17020C
699
700 055514 ;SAVE POSSIBLE SOFTWARE SWITCH REGISTER
      PUSH @SWR
701 055514 017746 125246
      ;SAVE STACK POINTER
702 055520 010637 056140
      MOV SP,$SAVR6 ;;SAVE SP
703 ;NOW SET UP REAL VECTOR
704 055524 012737 055536 000024
      MOV #SPWRUP,PWRVEC ;;SET UP VECTOR
705 055532 000000
      SDOWN: HALT
706 055534 000776
      BR $DOWN ;;HANG UP

```

```

MOV MAPMO,-(SP)
MOV MAPLO,-(SP)

MOV @SWR,-(SP)

```


743 055730
055730 162737 000004 002256
055736 023727 002256 000000
055744 002360
055746

END :OF FOR CSRNO

SUB #4, CSRNO
CMP CSRNO, #0
BGE B115

744 055746
055746

END LCSRRESTORE

E115:.....

745
746 055746 012700 172300
747 055752 012701 177600
748 055756 012702 172200
749 055762 012703 000040
750 055766 011021
751 055770 012022
752 055772 077303

;COPY KERNEL MAP TO USER & SUPERVISOR

E114:.....

3\$:

MOV #KIPDR0,R0
MOV #UIPDR0,R1
MOV #SIPDR0,R2
MOV #32,R3
MOV (R0),(R1)+
MOV (R0)+,(R2)+
SOB R3,3\$

```

754      ;RESTORE SUPERVISOR & USER STACK POINTERS
755 055774      POP      RO
755 055774      012600      MOV (SP)+,RO
756 055776      052737      040000      177776      SUPERVISOR      ;ENTER SUPERVISOR MODE
756 055776      052737      040000      177776      BIS      #BIT14,PSW      ;DO IT TO IT.
757 056004      010006      .DSABL      CRF
758 056006      104417      MOV      RO,SSP
759 056010      056010      012600      KERNEL      ;ENTER KERNEL MODE
759 056010      056010      012600      POP      RO
760 056012      056012      052737      140000      177776      USER
760 056012      056012      052737      140000      177776      BIS      #BIT15.BIT14,PSW      ;DO IT TO IT.
761 056020      010006      .DSABL      CRF
762 056022      104417      MOV      RO,USP
763 056024      012700      172240      KERNEL      ;ENTER KERNEL MODE
764 056030      012701      000020      ;RESTORE SUPERVISOR PAR'S
765 056034      056034      012620      MOV      #172240,RO
766 056036      077102      7$:      MOV      #16.,R1
767 056036      077102      POP      (RO)+
768 056040      012700      177636      SOB      R1,7$
769 056044      012701      000021      ;RESTORE USER PAR'S & PDR7
770 056050      012620      MOV      #177636,RO
771 056052      077102      8$:      MOV      #17.,R1
772 056054      013777      002014      124706      POP      (RO)+
773 056062      013737      002014      000174      SOB      R1,8$
774 056070      012637      002256      ;RESTORE POSSIBLE SOFTWARE DISPLAY REGISTER
775 056074      012605      MOV      $PATMAR,@DISPLAY
776 056076      012604      MOV      $PATMAR,DISPREG
777 056100      012603      POP      (CSRNO,R5,R4,R3,R2,R1,RO)
777 056110      012737      055160      000024      MOV (SP)+,CSRNO
778 056116      104401      114503      MOV (SP)+,R5
779 056122      012637      177750      MOV (SP)+,R4
780 056122      012637      177746      MOV (SP)+,R3
781 056132      000002      MOV (SP)+,R2
782 056134      000000      MOV (SP)+,R1
783 056136      000776      MOV (SP)+,RO
784 056140      000000      ;SET UP THE POWER DOWN VECTOR
784 056140      000000      ;REPORT THE POWER FAILURE
784 056140      000000      ;RESTORE MARGIN & CACHE STATUS
784 056140      000000      ;THE POWER UP SEQUENCE WAS STARTED
784 056140      000000      ;BEFORE THE POWER DOWN WAS COMPLETE
784 056140      000000      ;PUT THE SP HERE
784 056140      000000      RTI
784 056140      000000      $ILLUP: HALT
784 056140      000000      BR      $ILLUP
784 056140      000000      $SAVR6: 0
784 056140      000000      .EVEN
    
```

```

788 056142          MULT!UP:SUBST <<MULTIPLE CPU'S POWERING UP>>
:*****
:*SUBTEST          MULTIPLE CPU'S POWERING UP
:*****

789 056142 106237 002760          ASRF  PWLOCK
790 056146 103002                   BCC  UP2
791 056150 000000          MULHLT: HALT                   ;BECAUSE I'VE BEEN LOCKED OUT
792 056152 000776          BR    MULHLT
793 056154 000137 004352          UP2:  JMP    START
794
795 056160          WOOPS: SUBST <<POWER FAIL WHILE RELOCATED>>
:*****
:*SUBTEST          POWER FAIL WHILE RELOCATED
:*****

796 056160          PUSH  BANK
797 056160 013746 002106          MOV  BANK,-(SP)
798 056164 005037 002106          CLR  BANK
798 056170          MAP  BANK                   ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
056170 010346          MOV  R3,-(SP)
056172 013703 002106          MOV  BANK,R3
056176 004737 040700          CALL MAPPER
                                .DSABL CRF

056202 012603          MOV  (SP)+,R3
799 056204          SUPERVISOR                   ;ENTER SUPERVISOR MODE
056204 052737 040000 177776          BIS  #BIT14,PSW                   ;DO IT TO IT
                                .DSABL CRF
800 056212 013737 060024 056542          MOV  FIRST+PWRVEC,WOOPSAV
801 056220 013737 060026 056544          MOV  FIRST+PWRVEC+2,WOOPSAV+2
802 056226          BMOV  FIRST+WOOPUP,WOOPSAV+4,WOOPEND-WOOPUP/2+12.
056226 004537 043744          JSR  R5,BLOCK3
056232 000102          WOOPEND-WOOPUP/2+12.
056234 056546          WOOPSAV+4
056236 136336          FIRST+WOOPUP
                                .DSABL CRF
803 056240 012737 056336 060024          MOV  #WOOPUP,FIRST+PWRVEC
804 056246 012737 000340 060026          MOV  #340,FIRST+PWRVEC+2
805 056254          BMOV  WOOPUP,FIRST+WOOPUP,WOOPEND-WOOPUP/2
056254 004537 043744          JSR  R5,BLOCK3
056260 000066          WOOPEND-WOOPUP/2
056262 136336          FIRST+WOOPUP
056264 056336          WOOPUP
                                .DSABL CRF
806 056266 012700 172340          MOV  #KIPARO,R0
807 056272 012701 136512          MOV  #FIRST+WOOPEND,R1
808 056276 012702 000010          MOV  #8,R2
809 056302 012021          1$: MOV  (R0)+,(R1)+
810 056304 077202          SOB  R2,1$
811 056306 013721 172516          MOV  MMR3,(R1)+
812 056312 013721 177576          MOV  MMR2,(R1)+
813 056316 013721 177574          MOV  MMR1,(R1)+
814 056322 013721 177572          MOV  MMR0,(R1)+
815 056326 104417          KERNEL                   ;ENTER KERNEL MODE
816 056330          POP  BANK
056330 012637 002106          MOV  (SP)+,RANK
817 056334 000207          RETURN
  
```


R21 056336

WOOPUP: SUBTST <<POWER UP FROM BANK 0 TO RELOCATION>>
 :.....
 :+SUBTEST POWER UP FROM BANK 0 TO RELOCATION
 :.....

821 056336 012700 056512
 822 056342 012701 172340
 823 056346 012703 172300
 824 056352 012702 006010
 825 056356 012021
 826 056360 012723 077406
 827 056364 077204
 828 056366 012037 172516
 829 056372 012037 177576
 830 056376 012037 177574
 831 056402 012037 177572
 832 056406 013706 056140
 833 056412
 834 056416 013746 002106
 835 056422 005037 002106
 056422 010346
 056424 013703 002106
 056430 004737 040700
 056434 012603
 836 056436 052737 040000 177776
 837 056444 013737 056542 060024
 838 056452 013737 056544 060026
 839
 840
 841 056460 012700 056546
 842 056464 012701 000102
 843 056470 012702 136336
 844 056474 012022
 845 056476 077102
 846
 847 056500 104417
 848 056502
 056502 012637 002106
 849 056506 000137 055536
 850 056512 000014
 853 056542 000104

```

MOV #WOOPEND,R0
MOV #KIPAR0,R1
MOV #KIPDR0,R3
MOV #8.,R2
?$: MOV (R0)+,(R1)+
MOV #77406,(R3)+
SOB R2,1$
MOV (R0)+,MMR3
MOV (R0)+,MMR2
MOV (R0)+,MMR1
MOV (R0)+,MMR0
MOV $SAVR6,SP
PUSH BANK
MOV BANK,-(SP)
CLR BANK
MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
MOV R3,-(SP)
MOV (SP)+,R3
SUPERVISOR ;ENTER SUPERVISOR MODE
BIS #BIT14,PSW ;DO IT TO IT.
.DSABL CRF
MOV WOOPSAV,FIRST+PWRVEC
MOV WOOPSAV+2,FIRST+PWRVEC+2
;SIMULATE THE FOLLOWING BLOCK MOV BUT WITH NO STACK ACCESSES
;BMOV WOOPSAV+4,FIRST+WOOPUP,WOOPEND-WOOPUP/2+12.
MOV #WOOPSAV+4,R0
MOV #WOOPEND-WOOPUP/2+12.,R1
MOV #FIRST+WOOPUP,R2
?$: MOV (R0)+,(R2)+
SOB R1,2$
KERNEL ;ENTER KERNEL MODE
POP BANK
MOV (SP)+,BANK
JMP $PWRUP
WOOPEND: .REPT 12.
WOOPSAV: .REPT WOOPEND-WOOPUP/2+12.+?
    
```

```

858 .SBTTL ID SUBROUTINES
859 .SBTTL ROUTINE TYPE
860
861
862 *****
863 ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
864 ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
865 ;*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
866 ;*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
867 ;*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
868
869 ;*
870 ;*CALL:
871 ;*1) USING A TRAP INSTRUCTION
872 ;* TYPE MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
873 ;*OR
874 ;* TYPE
875 ;* MESADR
876 ;*
877 056752 105737 002452 $TYPE: TSTB $TPFLG ;;IS THERE A TERMINAL?
878 056756 100407 BMI 6$ ;;BR IF NO
879 056760 010046 1$: MOV RO,-(SP) ;;SAVE RO
880 056762 017600 000002 MOV @2(SP),RO ;;GET ADDRESS OF ASCIZ STRING
881 056766 112046 4$: MOVB (RO)+,-(SP) ;;PUSH CHARACTER TO BE TYPED ONTO STACK
882 056770 001005 BNE 7$ ;;BR IF IT ISN'T THE TERMINATOR
883 056772 005726 TST (SP)+ ;;IF TERMINATOR POP IT OFF THE STACK
884 056774 012600 5$: MOV (SP)+,RO ;;RESTORE RO
885 056776 062716 000002 6$: ADD #2,(SP) ;;ADJUST RETURN PC
886 057002 000002 RTI ;;RETURN
887 057004 122716 000011 7$: CMPB #HT,(SP) ;;BRANCH IF NOT <HT>
888 057010 001002 BNE 11$
889 057012 112716 000040 MOVB #' ,(SP) ;;REPLACE TAB WITH SPACE
890 057016 122716 000200 11$: CMPB #CR,F,(SP) ;;BRANCH IF NOT <CR>
891 057022 001006 BNE 8$
892 057024 005726 TST (SP)+ ;;POP <CR><LF> EQUIV
893 057026 TYPE ;;TYPE A CR AND LF
894 057030 003010 .DSABL CRF
895 057032 105037 057356 $CRLF
896 057036 000753 CLRB $CHARCNT ;;CLEAR CHARACTER COUNT
897 057040 004737 057076 BR 4$ ;;GET NEXT CHARACTER
898 057044 123726 003002 8$: CALL $TYPEC ;;GO TYPE THIS CHARACTER
899 057050 001346 9$: CMPB $FILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?
900 057052 013746 002450 BNE 4$ ;;IF NO GO GET NEXT CHAR.
901 MOV $NULL,-(SP) ;;GET # OF FILLER CHARS. NEEDED
902 057056 105366 000001 10$: DECB 1(SP) ;;AND THE NULL CHAR.
903 057062 002770 BLT 9$ ;;DOES A NULL NEED TO BE TYPED?
904 057064 004737 057076 CALL $TYPEC ;;BR IF NO--GO POP THE NULL OFF OF STACK
905 057070 105337 057356 DECB $CHARCNT ;;GO TYPE A NULL
906 057074 000770 BR 10$ ;;DO NOT COUNT AS A COUNT
907 057076 $TYPEC: PUSH R1 ;;LOOP
908 057100 116601 000004 MOV R1,-(SP)
909 057104 010046 177746 PUSH RO,CONTRL MOV RO,-(SP)
057106 013746 MOV CONTRL,-(SP)

```

```

910 057112 104424          CACHOFF          ;TURN CACHE OFF
911 057114          IF MULTIPOST IS TRUE          TST MULTIPOST
      057114 005737 003014          BEQ L625
      057120 001414
912 057122          IF NOIIST IS TRUE          TST NOIIST
      057122 005737 002756          BEQ L626
      057126 001403
913 057130 013700 177764          MOV SYSTID,R0
914 057134          ELSE
      057134 000406          BR L627
      057136          L626:::
915 057136 017700 123574          MOV @IISTACR,R0
916 057142 072027 177770          ASH #-8.,R0
917 057146 042700 177774          BIC #^C3,R0
918 057152          END ;OF IF NOIIST          L627:::
      057152          END ;OF IF MULTIPOST          L625:::
919 057152          IF PORTDIR NE R0 AND MULTIPOST IS TRUE ;IF I,M NOT THE MASTER IN A MULTIPOST SYSTEM
      057152 023700 002606          CMP PORTDIR,R0
      057156 001456          BEQ L630
      057160 005737 003014          TST MULTIPOST
      057164 001453          BEQ L630
921 057166          IF CPUBIT EQ #SLAVE1 THEN LET R0 := #2          CMP CPUBIT,#SLAVE1
      057166 023727 002114 000040          BNE L631
      057174 001002          MOV #2,R0
      057176 012700 000002          L631:::
      057202          IF CPUBIT EQ #SLAVE2 THEN LET R0 : #4          CMP CPUBIT,#SLAVE2
922 057202 023727 002114 000100          BNE L632
      057210 001002          MOV #4,R0
      057212 012700 000004          L632:::
      057216          IF CPUBIT EQ #SLAVE3 THEN LET R0 :- #6          CMP CPUBIT,#SLAVE3
923 057216 023727 002114 000200          BNE L633
      057224 001002          MOV #6,R0
      057226 012700 000006          L633:::
      057232          MAP #0          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
924 057232 010346          MOV #0,R3
      057234 012703 000000          CALL MAPPER
      057240 004737 040700          .DSABL CRF
      MOV (SP)+,R3
925 057244 012603          SUPERVISOR          ;ENTER SUPERVISOR MODE
      057246 052737 040000 177776          BIS #BIT14,PSW          ;DO IT TO IT!
      .DSABL CRF
926 057254 005760 062626          2$: TST FIRST+PTYFLAG(R0)
927 057260 100775          BMI 2$
928 057262 110160 062636          MOVB R1,FIRST+PTYBUF(R0)
929 057266          SET FIRST+PTYFLAG(R0)
930 057274 012760 177777 062626          MAP BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
      057274 010346          MOV #-1,FIRST+PTYFLAG(R0)
      057276 013703 002106          MOV R3,-(SP)
      057302 004737 040700          MOV BANK,R3
      CALL MAPPER
      .DSABL CRF
  
```

```

ROUTINE TYPE
057306 012603
931 057310 104417
932 057312 000405
057312 000405
057314
933 057314 105777 123456 3$: TSTB @$IPS ;:WAIT UNTIL PRINTER IS READY L630:::
934 057320 100375 BPL 3$ ;:IF I AM THE MASTER OR WE'RE NOT MULTIPORTING BR L634
935 057322 110177 123452 MOV# R1,$TPB ;:LOAD CHAR TO BE TYPED INTO DATA REG.
936 057326 END ;OF IF PORTDIR
057326
937 057326 122766 000015 000002 (MPB #CR,2(SP) ;:IS CHARACTER A CARRIAGE RETURN? L634:::
938 057334 001003 BNE 1$ ;:BRANCH IF NO
939 057336 105037 057356 CLRB $CHARCNT ;:YES--CLEAR CHARACTER COUNT
940 057342 000406 BR $TYPEX ;:EXIT
941 057344 122766 000012 000002 1$: (MPB #LF,2(SP) ;:IS CHARACTER A LINE FEED?
942 057352 001402 BEQ $TYPEX ;:BRANCH IF YES
943 057354 105227 INCB (PC)+ ;:COUNT THE CHARACTER
944 057356 000000 $CHARCNT: .WORD 0 ;:CHARACTER COUNT STORAGE
945 057360 $TYPEX: POP CONTRL,R0,R1
057360 012637 177746 MOV (SP)+,CONTRL
057364 012600 MOV (SP)+,R0
057366 012601 MOV (SP)+,R1
946 057370 000207
947 057372 RETURN
SUPLIMIT:;! . . . . .THIS IS THE LIMIT ON SUPERVISOR MAPPED TO MUT SPACE

```

949 057372

MAST01: SUBTST <<MULTIPOINT SLAVE STARTER>>

 :SUBTEST MULTIPOINT SLAVE STARTER

950
 951 057372 104424
 952 057374 057374 012737 177777 002540
 953 057402 012737 177777 002676
 954 057410 013777 002676 123352
 955
 956 057416 013737 002766 002674
 957 057424 012737 000176 002766
 958 057432 017777 123236 123326
 959 057440
 057440 005737 002756
 057444 001457
 960 057446
 057446 012700 000001
 057452
 961 057452 005037 002670
 962 057456 162737 000200 002706
 963 057464 010001
 964 057466 006301
 965 057470
 057470 012702 000012
 057474
 966 057474 010261 002636
 967 057500 012703 000200
 968 057504 077301
 969 057506
 057506 005302
 057510 020227 000000
 057514 002367
 057516
 970 057516 012703 000200
 971 057522 077301
 972 057524 012737 023542 002574
 973 057532 004737 072154
 974 057536
 057536 103012
 975 057540 010037 002056
 976 057544 104060
 977 057546 005037 003014
 978 057552 012737 002000 002706
 979 057560 000137 060746
 980 057564
 057564
 981 057564 005761 002616
 982 057570 100360
 983 057572
 057572 005200
 057574 020037 002730
 057600 003724
 057602
 984 057602
 057602 000516

```

    .ENABL  LSB
    CACHOFF
    SET  NOSCOPE
    MOV  #-1,MDISPLAY
    MOV  MDISPLAY,@DISPLAY
    ;PASS PSEUDO SWR TO SLAVE
    MOV  SWR,MASWR
    MOV  #SWREG,SWR
    MOV  @MASWR,@SWR
    IF NOIIST IS TRUE
    TST NOIIST
    BEQ L635
    FOR R0 : #1 TO SLAVES
    MOV #1,R0
    B116:
    CLR LOCK
    SUB #200,KSTACK
    MOV R0,R1
    ASL R1
    FOR R2 := #10. DOWNT0 #0
    MOV #10.,R2
    B117:
    MOV R2,PTYBUF(R1)
    MOV #200,R3 ;DELAY FOR THE SLAVE TO GAIN ACCESS TO CNT-DOWN
    SOB R3,1$
    END ;OF FOR R2
    DEC R2
    CMP R2,#0
    BGE B117
    E117:
    MOV #200,R3 ;DELAY FOR THE SLAVE TO SETUP HIS STACK
    SOB R3,2$
    MOV #2*SECONDS,HUNGTIME
    CALL QUE
    ON.ERROR
    BCC L636
    MOV R0,BAD
    ERROR +60 ;SLAVE HUNG SYSTEM!
    CLR MULTIPOINT
    MOV #STACK,KSTACK
    JMP MULTIEXIT
    END ;OF ON.ERROR
    L636:
    TST TASK(R1)
    BPL 4$
    END ;OF FOR R0
    INC R0
    CMP R0,SLAVES
    BLE B116
    E116:
    ELSE
    BR L637
    
```

```

057604
985 057604 013700 002742      MOV  IISTVEC,R0
986 057610 012720 061216      MOV  #SLAVUP,(R0)+
987 057614 012710 000340      MOV  #340,(R0)
988 057620      FOR R0 := #0 TO #3
    057620 005000
    057622
989 057622 005037 002670      CLR LOCK
990 057626 162737 000200 002706  SUB  #200,KSTACK
991 057634 012701 000001      MOV  #1,R1
992 057640 072100      ASH  R0,R1
993 057642 004737 061174      CALL IISTOFF ;INIT IIST & DISABLE BOOTS & INTERRUPTS
994 057646 012777 000000 123062  MOV  #0,@IISTACR
995 057654 010177 123060      MOV  R1,@IISTADR ;INTERRUPT SOME CPU
996 057660 012777 000001 127052  MOV  #1,@IISTADR ;NOW.
997
998      ;WAIT FOR READY FLAG
999 057666 012737 061165 002574  MOV  #5*SECONDS,HUNGTIME
1000 057674 012777 000001 123034 6$:  MOV  #1,@IISTACR
1001 057702      ON.ERROR
    057702 103010
1002 057704 104061      ERROR +61 ;IIST HUNG SYSTEM.
1003 057706 005037 003014      CLR  MULTIPOINT
1004 057712 012737 002000 002706  MOV  #STACK,KSTACK
1005 057720 000137 060746      JMP  MULTIEXIT
1006 057724      END ;OF ON.ERROR
    057724
1007 057724 032777 004000 123006  BIT  #BI111,@IISTADR
1008 057732 001760      BEQ  6$
1009 057734 012703 000200      MOV  #200,R3 ;DELAY FOR THE IIST TO REALLY BE READY
1010 057740 077301      SOB  R3,3$ ;AND FOR SLAVE TO GO THRU VECTOR AND SETUP HIS STACK
1011 057742      END ;OF FOR R0
    057742 005200
    057744 020027 000003      INC  R0
    057750 003724      CMP  R0,#3
    057752      BLE  B120
1012 057752      FOR R0 : #1 TO SLAVES
    057752 012700 000001      MOV  #1,R0
    057756
1013 057756 010001      MOV  R0,R1
1014 057760 006301      ASL  R1
1015 057762 012737 061165 002574  MOV  #5*SECONDS,HUNGTIME
1016 057770 004737 072154 5$:  CALL  QUE
1017 057774      ON.ERROR
    057774 103012
1018 057776 010037 002056      MOV  R0,BAD
1019 060002 104060      ERROR +60 ;SLAVE HUNG SYSTEM!
1020 060004 005037 003014      CLR  MULTIPOINT
1021 060010 012737 002000 002706  MOV  #STACK,KSTACK
1022 060016 000137 060746      JMP  MULTIEXIT
1023 060022      END ;OF ON.ERROR
    060022
1024 060022 005761 002616      TST  TASK(R1)
1025 060026 100360      BPL  5$
1026 060030      END ;OF FOR R0
    060030 005200
    060032 020037 002730      INC  R0
    ;CMP R0,SLAVES

```

L635:::~::~

CLR R0
B120:::~::~

BCC L640

L640:::~::~

E120:::~::~

MOV #1,R0
B121:::~::~

BCC L641

L641:::~::~

INC R0
CMP R0,SLAVES

060036 003747
060040
1027 060040
060040
1028 060040 012737 002000 002706
1029

END ;OF IF NOIIST
MOV #STACK,KSTACK
.DSABL LSB

BLE B121
E121:.....
L637:.....

```

1032 060046          MAST02: SUBTST  <<HAVE SLAVES RUN CSR TESTS>>
:*****
: *SUBTEST          HAVE SLAVES RUN CSR TESTS
:*****
1033                .ENABL  LSB
1034 060046 012737 000000 002676      MOV   #0,MDISPLAY      ;LET SLAVES SHOW INDIVIDUAL CSR TESTS IN DISPLAY
1035 060054 012777 177776 122706      MOV   #-2,@DISPLAY    ;FAKE OUT MASTER'S DISPLAY (NOT SLAVES)
1036 060062 005037 002670                CLR   LOCK
1037 060066                FOR RO := #1 TO SLAVES
                                MOV #1,RO
                                B122:;;;;;
1038 060072 012701 000020                MOV   #BIT4,R1
1039 060076 072100                ASH  RO,R1
1040 060100 010137 002114                MOV   R1,CPUBIT
1041 060104 010001                MOV   RO,R1
1042 060106 006301                ASL  R1
1043 060110 012761 000015 002616      MOV   #15,TASK(R1)    ;RUN CSR TESTS COMMAND
1044 060116 012737 000031 002572      MOV   #25,HUNGMSB
1045 060124 012737 177777 002574      MOV   #-1,HUNGTIME   ;13 SECONDS
1046 060132 004737 072154      1$: CALL  QUE
1047 060136 060136 103016                ON.ERROR
                                BCC L642
1048 060140 162737 000001 002572      SUB  #1,HUNGMSB
1049 060146 060146 103012                ON.ERROR
                                BCC L643
1050 060150 010037 002056                MOV   RO,BAD
1051 060154 012737 000020 002114      MOV   #MASTER,CPUBIT
1052 060162 104060                ERROR  +60            ;SLAVE HUNG SYSTEM!
1053 060164 005037 003014                CLR   MULTIPORT
1054 060170 000137 060746                JMP   MULTIEEXIT
1055 060174                END ;OF ON.ERROR
                                L643:;;;;;
1056 060174                END ;OF ON.ERROR
                                L642:;;;;;
1057 060174 005761 002616                TST  TASK(R1)
1058 060200 100354                BPL  1$
1059 060202                END ;OF FOR RO
                                INC RO
                                CMP RO,SLAVES
                                BLE B122
1060 060212 012737 000020 002114      MOV   #MASTER,CPUBIT ;SET UP AS MASTER AGAIN
1061 060212 012737 000020 002114      .DSABL LSB
                                E122:;;;;;

```



```
1099 060436 104062          ERROR          +62          ;NOT ENOUGH GOOD MEMORY TO TEST SLAVES
1100                                     ;ABORTING MULTIPROCESSOR TESTS
1101 060440 005037 003014    CLR MULTIPORT
1102 060444 000137 060746    JMP MULTIEXIT
1103 060450          END MOVELOOP
1104 060450          END ;OF FOR R0
      060450 005200
      060452 020037 002730
      060456 003672
      060460
1105 060460 012737 002000 002706  MOV #STACK,KSTACK
1106                                     ;POINT THE MASTER BACK TO THE NORMAL SWR
1107 060466 013737 002674 002766  MOV MASWR,SWR
1108                                     .DSABL LSB

      E124:::
      INC R0
      CMP R0,SLAVES
      BLE B123
      E123:::

```

1111 060474

SUBSTST <<RUN NORMAL MULTIPROCESSOR TESTS>>

*SUBSTEST RUN NORMAL MULTIPROCESSOR TESTS

1112 060474 012737 000020 002114
1113 060502 052737 000020 002510
1114 060510 012700 000001

MOV #MASTER,CPLBIT
BIS #BIT4,ALLCPUS
FOR RO .- #1 TO SLAVES

MOV #1,RO
B126:::~::~

1115 060514 006337 002510
1116 060520 052737 000020 002510
1117 060526 005200 002730

ASL ALLCPUS
BIS #BIT4,ALLCPUS
END ;OF FOR RO

INC RO
CMP RO,SLAVES
BLE B126

1118 060536 004737 061322
1119 060542 103004 003014
1120 060544 005037 060746

CALL MAST04 ;ACCESS PATHS TEST
ON.ERROR

E126:::~::~

BCC L646

1121 060550 000137 060746
1122 060554 004737 061706
1123 060560 103004 003014

CLR MULTIPOINT
JMP MULTIEXIT
END ;OF ON.ERROR

L646:::~::~

BCC L647

1124 060562 005037 003014
1125 060566 000137 060746
1126 060572 004737 062270

CALL MAST05 ;ADDRESS TEST
ON.ERROR

L647:::~::~

BCC L650

1127 060572 103004 003014
1128 060576 005037 060746
1129 060576 004737 062550

CLR MULTIPOINT
JMP MULTIEXIT
END ;OF ON.ERROR

;ASYNCHRONOUS ADDRESS UNIQUENESS TEST

BCC L651

1130 060600 103004 003014
1131 060604 005037 060746
1132 060610 004737 062550

CLR MULTIPOINT
JMP MULTIEXIT
END ;OF ON.ERROR

L650:::~::~

;SKEWED UP ADDRESS TEST

BCC L652

1133 060610 103004 003014
1134 060614 005037 060746
1135 060622 000137 060746

CALL MAST07
ON.ERROR

L651:::~::~

;PORT ARBITRATION SYMMETRY TEST

BCC L653

1136 060626 004737 062776
1137 060632 103004 003014
1138 060632 005037 060746

CALL MAST10
ON.ERROR

L652:::~::~

;I/O PRIORITY TEST

1139 060632 004737 063260
1140 060644 103004 003014
1141 060640 005037 060746

CLR MULTIPOINT
JMP MULTIEXIT
END ;OF ON.ERROR

1142 060644 004737 063260
1143 060650 103004 003014
1144 060652 005037 060746

CALL MAST11
ON.ERROR

1145 060652 004737 063260
1146 060656 103004 003014
1147 060662 005037 060746

CLR MULTIPOINT
JMP MULTIEXIT
END ;OF ON.ERROR

```

1148 060662 004737 063732 CALL MAST12 ;EXECUTION CONTENTION TEST L653:::
1149 060666 ON.ERROR BCC L654
      060666 103004
1150 060670 005037 003014 CLR MULTIPOINT
1151 060674 000137 060746 JMP MULTIEXIT
1152 060700 END ;OF ON.ERROR
      060700
1153 060700 004737 064200 CALL MAST13 ;ASRB TEST L654:::
1154 060704 ON.ERROR BCC L655
      060704 103004
1155 060706 005037 003014 CLR MULTIPOINT
1156 060712 000137 060746 JMP MULTIEXIT
1157 060716 END ;OF ON.ERROR
      060716
1158 060716 004737 064204 CALL MAST14 ;CACHE FLUSH TEST L655:::
1159 060722 ON.ERROR BCC L656
      060722 103004
1160 060724 005037 003014 CLR MULTIPOINT
1161 060730 000137 060746 JMP MULTIEXIT
1162 060734 END ;OF ON.ERROR
      060734
1163 060734 004737 064472 CALL MAST15 ;STOP SLAVES L656:::
1164 060740 ON.ERROR BCC L657
      060740 103002
1165 060742 005037 003014 CLR MULTIPOINT
1166 060746 END ;OF ON.ERROR
      060746
1167 060746 MULTIEXIT:FOR BANK := #1 TO #167 L657:::
      060746 012737 000001 002106 MOV #1,BANK
      060754 B127:::
1168 060754 004737 042422 CALL EXBANK
1169 060760 013701 002110 MOV BANKINDEX,R1
1170 060764 042761 100000 003016 BIC #BIT15,CONFIG(R1)
1171 060772 END ;OF FOR BANK
      060772 005237 002106 INC BANK
      060776 023727 002106 000167 CMP BANK,#167
      061004 003763 BLE B127
      061006 E127:::
1172
1173 ;MARK THE LOADERS AS PROTECTED AGAIN
1174 061006 013737 002710 002106 MOV LOADHOME,BANK
1175 061014 004737 042422 CALL EXBANK
1176 061020 013701 002110 MOV BANKINDEX,R1
1177 061024 052761 100000 003016 BIS #BIT15,CONFIG(R1)
1178
1179 061032 005037 002676 CLR MDISPLAY
1180 061036 005077 121726 CLR @DISPLAY
1181 061042 SET WRITEONLY
      061042 012737 177777 002502 MOV #-1,WRITEONLY
1182 061050 004737 015104 CALL DOBACK ;REWRITE BACKGROUND PATTERN
1183 061054 CLEAR NOSCOPE,LOCK,WRITEONLY
      061054 005037 002540 CLR NOSCOPE
      061060 005037 002670 CLR LOCK
      061064 005037 002502 CLR WRITEONLY
1184 061070 000137 014656 JMP FLUSH
    
```

```

1187 061074      IISTINIT:SUBTST <<INITIALIZE THE IIST>>
:*****
:*SUBTEST      INITIALIZE THE IIST
:*****
1188            .ENABL  LSB
1189 061074 012777 100000 121634      MOV    #BIT15,@IISTACR
1190 061102 012777 000005 121626      MOV    #5,@IISTACR
1191 061110 013777 002726 121622      MOV    ONES,@IISTADR
1192 061116 013777 002726 121614      MOV    ONES,@IISTADR
1193 061124 012737 061165 002574      MOV    #5*SECONDS,HUNGTIME
1194 061132 012777 000001 121576 2$:  MOV    #1,@IISTACR
1195 061140            IF CPUBIT EQ #MASTER
061140 023727 002114 000020            (MP CPUBIT,#MASTER
061146 001005            BNE L660
1196 061150            ON.ERROR
061150 103004            BCC L661
1197 061152 104061            ERROR      +61
1198 061154 005037 003014      CLR MULTIPORT      ;IIST HUNG SYSTEM
1199 061160 000207            RETURN
1200 061162            END ;OF ON.ERROR
061162            L661:*****
1201 061162            END ;OF IF CPUBIT
061162            L660:*****
1202 061162 032777 004000 121550      BIT    #BIT11,@IISTADR
1203 061170 001760      BEQ    2$
1204 061172 000207      RETURN
1205            .DSABL  LSB
1206
1207 061174      IISTOFF:SUBTST <<INIT IIST & DISABLE BOOTS & INTERRUPTS>>
:*****
:*SUBTEST      INIT IIST & DISABLE BOOTS & INTERRUPTS
:*****
1208 061174 004737 061074      CALL   IISTINIT
1209 061200 012777 000004 121530      MOV    #4,@IISTACR
1210 061206 013777 002726 121524      MOV    ONES,@IISTADR
1211 061214 000207      RETURN
1212
1213 061216 013706 002706      SLAVJP: MOV    KSTACK,SP
1214 061222 004737 061244      CALL   SLAVEMAP
1215 061226 104420            ENERGIZE      ;TURN ON MEMORY MANAGEMENT
1216 061230 000237      SPL    7
1217 061232 052763 100000 002616      BIS    #BIT15,TASK(R3)
1218 061240 000137 050726      JMP    TASKDO
    
```

1221 *1244

SLAVEMAP:SUBTST <<SLAVES MAP>>

.....
: *SUBTEST SLAVES MAP
:

1222
1223 061244 104415
1224 061246 012700 002550
1225 061252 012701 172340
1226 061256 012702 077406
1227 061262 012703 172300
1228 061266 012705 000006
1229 061272 012021
1230 061274 010223
1231 061276 077503
1232 061300 012721 177400
1233 061304 010223
1234 061306 012711 177600
1235 061312 010213
1236 061314 104420
1237 061316 104416
1238 061320 000207

:MAP KERNEL
SAVREG
MOV #K10,R0
MOV #KIPAR0,R1
MOV #77406,R2
MOV #KIPDR0,R3
MOV #6,R5
1\$: MOV (R0)+,(R1)+
MOV R2,(R3)+
SOB R5,1\$
MOV #177400,(R1)+
MOV R2,(R3)+
MOV #177600,(R1)
MOV R2,(R3)
ENERGIZE
RESREG
RETURN

1241 061322

MAST04: SUBTST <<MULTIPOINT ACCESS PATHS TEST>>
 :*****
 :*SUBTEST MULTIPOINT ACCESS PATHS TEST
 :*****

1242
 1243 061322 012737 177774 002676
 1244 061330 013777 002676 121432
 1245 061336
 061336 005000
 061340
 1246 061340 010001
 1247 061342 006301
 1248 061344
 061344 012737 000001 002106
 061352
 1249 061352 013737 002510 002114
 1250 061360 004737 042422
 1251 061364 012737 000020 002114
 1252 061372
 061372 005737 002130
 061376 001127
 061400 005737 002124
 061404 001524
 1253 061406 104511
 1254 061410
 061410 005005
 061412
 1255 061412 010502
 1256 061414 000302
 1257 061416 062702 000002
 1258 061422 010261 002616
 1259 061426
 061426 005701
 061430 001012
 1260 061432
 061432 010046
 061434 010146
 061436 010246
 061440 010546
 1261 061442 004737 050726
 1262 061446
 061446 012605
 061450 012602
 061452 012601
 061454 012600
 1263 061456
 061456
 1264 061456 012737 061165 002574
 1265 061464 004737 072154 1\$:
 1266 061470
 061470 103005
 1267 061472 010037 002056
 1268 061476 104060
 1269 061500
 061500 000261
 061502 000207
 1270 061504

```

.ENABL  LSB
MOV     #-4,MDISPLAY
MOV     MDISPLAY,MDISPLAY
FOR R0 := #0 TO SLAVES

                                CLR R0
                                B130:::

MOV     R0,R1
ASL    R1
FOR BANK := #1 TO #167

                                MOV #1,BANK
                                B131:::

MOV ALLCPUS,CPUBIT
CALL   EXBANK
MOV #MASTER,CPUBIT
IF PFLAG IS FALSE AND ACFLAG IS TRUE

                                TST PFLAG
                                BNE L662
                                TST ACFLAG
                                BEQ L662

INVALIDATE
FOR R5 := #0 TO #5 ;FOR PATTERNS 0-5

                                CLR R5
                                B132:::

MOV     R5,R2
SWAB   R2
ADD    #2,R2 ;WRITE ONLY PATTERN COMMAND
MOV    R2,TASK(R1) ;SET TASK ORDER
IF R1 EQ #0

                                TST R1
                                BNE L663

                                PUSH R0,R1,R2,R5

                                MOV R0,-(SP)
                                MOV R1,-(SP)
                                MOV R2,-(SP)
                                MOV R5,-(SP)

                                CALL TASKDO
                                POP  R5,R2,R1,R0

                                MOV (SP)+,R5
                                MOV (SP)+,R2
                                MOV (SP)+,R1
                                MOV (SP)+,R0

                                END ;OF IF R1
                                L663:::

MOV     #5*SECONDS,HUNGTIME
CALL   QUE
ON.ERROR

                                MOV R0,BAD
                                ERROR +60 ;SLAVE HUNG SYSTEM.
                                $RETURN ERROR

                                SEC
                                RTS PC

                                END ;OF ON.ERROR
    
```

```

1271 061504 005761 002616          TST    TASK(R1)          L664:.....
1272 061510 100365                   BPL    1$
1273 061512 062702 000001          ADD    #1,R2             ;CHANGE ORDER TO READ ONLY
1274 061516 005003                   FOR R3 :- #0 TO SLAVES
                                CLR R3
                                B133:.....
1275 061520 010304                   MOV    R3,R4
1276 061522 006304                   ASL    R4
1277 061524 010264 002616          MOV    R2,TASK(R4)
1278 061530 005203                   END ;OF FOR R3
                                INC R3
                                CMP R3,SLAVES
                                BLE B133
                                E133:.....
1279 061540 010046                   PUSH   R0,R1,R3,R4,R5
                                MOV R0,-(SP)
                                MOV R1,-(SP)
                                MOV R3,-(SP)
                                MOV R4,-(SP)
                                MOV R5,-(SP)
1280 061552 004737 050726          CALL   TASKDO
1281 061556 012605                   POP    R5,R4,R3,R1,R0
                                MOV (SP)+,R5
                                MOV (SP)+,R4
                                MOV (SP)+,R3
                                MOV (SP)+,R1
                                MOV (SP)+,R0
1282 061570 005003                   FOR R3 := #0 TO SLAVES
                                CLR R3
                                B134:.....
1283 061572 010304                   MOV    R3,R4
1284 061574 006304                   ASL    R4
1285 061576 020401                   IF R4 NE R1
                                CMP R4,R1
                                BEQ L665
1286 061602 012737 061165 002574          MOV #5*SECONDS,HUNGTIME
1287 061610 004737 072154 2$:          CALL   QUE
1288 061614 103005                   ON.ERROR
                                BCC L666
1289 061616 010337 002056          MOV    R3,BAD
1290 061622 104060                   ERROR  +60
1291 061624 000261                   $RETURN ERROR
                                ;SLAVE HUNG SYSTEM!
                                SEC
                                RTS PC
1292 061630 000207                   END ;OF ON.ERROR
                                L666:.....
1293 061630 005764 002616          TST    TASK(R4)
1294 061634 100365                   BPL    2$
1295 061636 010264 002616          END ;OF IF R4
                                L665:.....
1296 061636 005203                   END ;OF FOR R3
                                INC R3
                                CMP R3,SLAVES
                                BLE B134
                                E134:.....
1297 061646 020337 002730          END ;OF FOR R5

```


061646 005205
061650 020527 000005
061654 003656
1298 061656
061656
1299 061656
061656 005237 002106
061662 023727 002106 000167
061670 003630
1300 061672
061672 005200
061674 020037 002730
061700 003617
1301 061702
061702 000241
061704 000207
1302

END ;OF IF PFLAG
END ;OF FOR BANK
END ;OF FOR RO
\$RETURN NOERROR
.DSABL LSB

INC R5
CMP R5,#5
BLE B132
E132:::~::~
L662:::~::~
INC BANK
CMP BANK,#167
BLE B131
E131:::~::~
INC RO
CMP RO,SLAVES
BLE B130
E130:::~::~
CLC
RTS PC

```

1306 061706          MAST05: SUBTST  <<MULTIPOINT ADDRESS TEST>>
:*****
:*SUBTEST          MULTIPOINT ADDRESS TEST
:*****
1307                .ENABL  LSB
1308 061706 012737 177773 002676      MOV    #-5,MDISPLAY
1309 061714 013777 002676 121046      MOV    MDISPLAY,@DISPLAY
1310 061722                FOR R0 := #0 TO SLAVES
                                CLR R0
                                B135:*****
1311 061724 010001                MOV    R0,R1
1312 061726 006301                ASL   R1
1313 061730                FOR BANK : #1 TO #167
                                MOV #1,BANK
                                B136:*****
1314 061736 013737 002510 002114      MOV ALLCPUS,CPUBIT
1315 061744 004737 042422          CALL   EXBANK
1316 061750 012737 000020 002114      MOV #MASTER,CPUBIT
1317 061756                IF PFLAG IS FALSE AND ACFLAG IS TRUE
                                TST PFLAG
                                BNE L667
                                TST ACFLAG
                                BEQ L667
                                FOR R5 := #0 TO #1 ;FOR ADDRESS & COMPLEMENT ADDRESS PATTERNS
                                CLR R5
                                B137:*****
1318 061772 005005                FOR R5 := #0 TO #1 ;FOR ADDRESS & COMPLEMENT ADDRESS PATTERNS
                                CLR R5
                                B137:*****
1319 061774 010502                MOV    R5,R2
1320 061776 000302                SWAB  R2
1321 062000 062702 000007          ADD   #7,R2                ;WRITE ONLY ADDRESS PATTERN
1322 062004 010261 002616          MOV   R2,TASK(R1)        ;SET TASK ORDER
1323 062010                IF R1 EQ #0
                                TST R1
                                BNE L670
1324 062014                PUSH  R0,R1,R2,R5
                                MOV R0,-(SP)
                                MOV R1,-(SP)
                                MOV R2,-(SP)
                                MOV R5,-(SP)
1325 062024 004737 050726          CALL  TASKDO
1326 062030                POP   R5,R2,R1,R0
                                MOV (SP)+,R5
                                MOV (SP)+,R2
                                MOV (SP)+,R1
                                MOV (SP)+,R0
1327 062040                END ;OF IF R1
                                L670:*****
1328 062040 012737 611165 002574      MOV   #5*SECONDS,HUNGTIME
1329 062046 004737 072154          CALL  QUE
1330 062052                ON.ERROR
                                BCC L671
1331 062054 010037 002056          MOV   R0,BAD
1332 062060 104060                ERROR +60                ;SLAVE HUNG SYSTEM!
1333 062062                $RETURN ERROR
                                SEC
                                RTS PC
1334 062066                END ;OF ON.ERROR
                                L671:*****

```

```

1335 062066 005761 002616      TST     TASK(R1)
1336 062072 100365              BPL     1$
1337 062074 062702 000001      ADD     #1,R2      ;CHANGE ORDER TO READ ADDRESS PATTERNS ONLY
1338 062100              FOR R3 := #0 TO SLAVES
                                CLR R3
                                B140:;;;;;;
1339 062102 010304              MOV     R3,R4
1340 062104 006304              ASL     R4
1341 062106 010264 002616      MOV     R2,TASK(R4)
1342 062112              END ;OF FOR R3
                                INC R3
                                CMP R3,SLAVES
                                BLE B140
                                E140:;;;;;;
1343 062122              PUSH    R0,R1,R3,R4,R5
                                MOV R0,-(SP)
                                MOV R1,-(SP)
                                MOV R3,-(SP)
                                MOV R4,-(SP)
                                MOV R5,-(SP)
1344 062134 004737 050726      CALL    TASKDO
1345 062140              POP     R5,R4,R3,R1,R0
                                MOV (SP)+,R5
                                MOV (SP)+,R4
                                MOV (SP)+,R3
                                MOV (SP)+,R1
                                MOV (SP)+,R0
1346 062152              FOR R3 := #0 TO SLAVES
                                CLR R3
                                B141:;;;;;;
1347 062154 010304              MOV     R3,R4
1348 062156 006304              ASL     R4
1349 062160              IF R4 NE R1
                                CMP R4,R1
                                BEQ L672
1350 062164 012737 061165 002574      MOV #5*SECONDS,HUNGTIME
1351 062172 004737 072154      CALL    QUE
1352 062176              ON.ERROR
                                BCC L673
1353 062200 010337 002056      MOV     R3,BAD
1354 062204 104050              ERROR  +60
1355 062206              $RETURN ERROR
                                ;SLAVE HUNG SYSTEM!
                                SEC
                                RTS PC
1356 062212              END ;OF ON.ERROR
                                L673:;;;;;;
1357 062212 005764 002616      TST     TASK(R4)
1358 062216 100365              BPL     2$
1359 062220              END ;OF IF R4
                                L672:;;;;;;
1360 062220              END ;OF FOR R3
                                INC R3
                                CMP R3,SLAVES
                                BLE B141
                                E141:;;;;;;
1361 062230              END ;OF FOR R5
                                INC R5
062230 005205

```

062232 020527 C50001
062236 003656
1362 062240
062240
1363 062240
062240 005237 002106
062244 023727 002106 000167
062252 003631
1364 062254
062254 005200
062256 020037 002730
062262 003620
1365 062264
062264 000241
062266 000207
1366

END ;OF IF PFLAG
END ;OF FOR BANK
END ;OF FOR RO
\$RETURN NOERROR
.DSABL LSB

CMP R5,#1
BLE B137
E137:::~::~
L667:::~::~
INC BANK
CMP BANK,#167
BLE B136
E136:::~::~
INC RO
CMP RO,SLAVES
BLE B135
E135:::~::~
CLC
RTS PC

1369 062270

MAST06: SUBTST <<MULTIPORT ASYNCHRONOUS ADDRESS UNIQUENESS TEST>>
 :*****
 :*SUBTEST MULTIPORT ASYNCHRONOUS ADDRESS UNIQUENESS TEST
 :*****

1370
 1371 062270 012737 177772 002676
 1372 062276 013777 002676 120464
 1373 062304
 062304 012737 000001 002106
 062312
 1374 062312 013737 002510 002114
 1375 062320 004737 042422
 1376 062324 012737 000020 002114
 1377 062332
 062332 005737 002130
 062336 001074
 062340 005737 002124
 062344 001471
 1378 062346
 062346 005000
 062350
 1379 062350 010003
 1380 062352 072327 000015
 1381 062356 062703 060000
 1382 062362
 062362 005002
 062364
 1383 062364 062703 020000
 1384 062370
 062370 020327 160000
 062374 001002
 062376 012703 060000
 062402
 1385 062402
 062402 010346
 1386 062404 000241
 1387 062406 006003
 1388 062410 010201
 1389 062412 006301
 1390 062414 062703 000011
 1391 062420 010361 007616
 1392 062424
 062424 012603
 1393 062426
 062426 005202
 062430 020237 002730
 062434 003753
 062436
 1394 062436
 062436 010046
 1395 062440 004737 050726
 1396 062444
 062444 012600
 1397 062446
 062446 005002
 062450
 1398 062450 010201

```

.ENABL LSB
MOV #6,MDISPLAY
MOV MDISPLAY,MDISPLAY
FOR BANK := #1 TO #167
                                MOV #1,BANK
                                B142:*****
MOV ALLCPUS,CPUBIT
CALL EXBANK
MOV #MASTER,CPUBIT
IF PFLAG IS FALSE AND ACFLAG IS TRUE
                                TST PFLAG
                                BNE L674
                                TST ACFLAG
                                BEQ L674
                                CLR R0
                                ;R0 := STARTING ADDRESS INDEX
                                B143:*****
FOR R0 := #0 TO #3
MOV R0,R3
ASH #13,R3
ADD #FIRST,R3
FOR R2 :- #0 TO SLAVES
                                CLR R2
                                B144:*****
                                ADD #SIZE/2,R3
                                IF R3 EQ #LAST+2 THEN LET R3 : #FIRST
                                CMP R3,#LAST+2
                                BNE L675
                                MOV #FIRST,R3
                                L675:*****
                                PUSH R3
                                MOV R3,-(SP)
                                CLR R3
                                RGR R3
                                MOV R2,R1
                                ASL R1
                                ADD #11,R3
                                MOV R3,TASK(R1)
                                ;R1 := SLAVE #
                                ;ORDER FOR ASYNCHRONOUS ADD UNIQUE TEST
                                POP R3
                                MOV (SP)+,R3
                                END ;OF FOR R2
                                INC R2
                                CMP R2,SLAVES
                                BLE B144
                                E144:*****
                                PUSH R0
                                MOV R0,-(SP)
                                ;MASTER ASSUMES THE SLAVES ROLE
                                CALL TASKDO
                                MOV (SP)+,R0
                                POP R0
                                FOR R2 :- #0 TO SLAVES
                                CLR R2
                                B145:*****
                                MOV R2,R1
    
```


1417 062550

MAST07: SUBTST <<MULTIPOINT SKEWED UP ADDRESS TEST>>

.....
: *SUBTEST MULTIPOINT SKEWED UP ADDRESS TEST
:

1418

1419 062550 012737 177771 002676

.ENABL LSB
MOV #-7,MDISPLAY
MOV MDISPLAY,@DISPLAY
FOR BANK :- #1 TO #167

1420 062556 013777 002676 120204

1421 062564 012737 000001 002106

062572

1422 062572 013737 002510 002114

1423 062600 004737 042422

1424 062604 012737 000020 002114

1425 062612

062612 005737 002130

062616 001057

062620 005737 002124

062624 001454

1426 062626

062626 005002

062630

1427 062630

062630 005000

062632

1428 062632 010001

1429 062634 006301

1430 062636 010203

1431 062640 000303

1432 062642 062703 000012

1433 062646 010361 002616

1434 062652

062652 005200

062654 020037 002730

062660 003764

062662

1435 062662

062662 010246

1436 062664 004737 050726

1437 062670

062670 012602

1438 062672

062672 005000

062674

1439 062674 010001

1440 062676 006301

1441 062700 012737 061165 002574

1442 062706 004737 072154

1443 062712

062712 103005

1444 062714 010037 002056

1445 062720 104060

1446 062722

062722 000261

1447 062724 000207

062726

1448 062726 005761 002616

MOV ALLCPUS,CPUBIT
CALL EXBANK
MOV #MASTER,CPUBIT
IF PFLAG IS FALSE AND ACFLAG IS TRUE

FOR R2 : #0 TO #6 BY #2

FOR RC := #0 TO SLAVES

MOV R0,R1
ASL R1
MOV R2,R3
SWAB R3
ADD #12,R3
MOV R3,TASK(R1)
END ;OF FOR R0

PUSH R2

CALL TASKDO
POP R2

FOR R0 : #0 TO SLAVES

MOV RC,R1
ASL R1
MOV #5*SECONDS,HUNGTIME
CALL QUE
ON.ERROR

MOV R0,BAD
ERROR +60
\$RETURN ERROR

END ;OF ON.ERROR

TST TASK(R1)

MOV #1,BANK
B146:.....

TST PFLAG
BNE L677
TST ACFLAG
BEQ L677

CLR R2
B147:.....

CLR R0
B150:.....

;ADDRESS OFFSET (0,2,4,6)

;ORDER SKEWED UP ADDRESS TEST

INC R0
CMP R0,SLAVES
BLE B150
E150:.....

MOV R2,-(SP)

MOV (SP)+,R2

CLR R0
B151:.....

BCC L700

;SLAVE HUNG SYSTEM.

SEC
RTS PC

L700:.....

1449 062732 100365
1450 062734 005200
062736 020037 002730
062742 003754
062744
1451 062744 062702 000002
062750 020227 000006
062754 003725
062756
1452 062756
062756
1453 062756 005237 002106
062762 023727 002106 000167
062770 003700
062772
1454 062772 000241
062774 000207
1455

BPL 1\$
END ;OF FOR R0

END ;OF FOR R2

END ;OF IF PFLAG
END ;OF FOR BANK

\$RETURN NOERROR

.DSABL LSB

INC R0
CMP R0,SLAVES
BLE B151
E151:.....

ADD #2,R2
CMP R2,#6
BLE B147
E147:.....

L677:.....

INC BANK
CMP BANK,#167
BLE B146
E146:.....

CLC
RTS PC

1458 062776

MAST10: SUBST <<MULTIPOINT PORT ARBITRATION SYMMETRY TEST>>

*SUBTEST MULTIPOINT PORT ARBITRATION SYMMETRY TEST

1459

1460

062776 005737 002104

063002 001402

063004 000241

063006 000207

063010

1461

063010 012737 177770 002676

1462

063016 013777 002676 117744

1463

063024 012737 000001 002106

063032

1464

063032 013737 002510 002114

1465

063040 004737 042422

1466

063044 012737 000020 002114

1467

063052 005737 002130

063056 001070

063060 005737 002124

063064 001465

1468

063066 005000

063066 005000

1469

063070 010001

1470

063072 006301

1471

063074 012761 000405 002616

1472

063102 005200

063104 020037 002730

063110 003767

063112

1473

063112 004737 050726

1474

063116 005000

063116 005000

1475

063120 010001

1476

063122 006301

1477

063124 012737 061165 002574

1478

063132 004737 072154 1\$:

1479

063136 103005

063136 010037 002056

1480

063140 104060

1481

063144 000261

1482

063146 000207

063150 000207

1483

063152

063152 005761 002616

1484

063152 100365

1485

063156

1486

063160 005200

063160 020037 002730

063162

ENABL LSB
IF NOCLOCK IS TRUE THEN \$RETURN NOERROR

TST NOCLOCK
BEQ L701
CLC
RTS PC
L701:::~::~

MOV #-10,MDISPLAY
MOV MDISPLAY,@DISP
FOR BANK := #1 TO #167

MOV #1,BANK
B152:::~::~

MOV ALLCPUS,CPUBIT
CALL EXBANK
MOV #MASTER,CPUBIT
IF PFLAG IS FALSE AND ACFLAG IS TRUE

TST PFLAG
BNE L702
TST ACFLAG
BEQ L702

FOR RO := #0 TO SLAVES

CLR RO
B153:::~::~

MOV RO,R1
ASL R1
MOV #405,TASK(R1)
END ;OF FOR RO

;ORDERS FOR PORT ARBITRATION SYMMETRY TEST

INC RO
CMP RO,SLAVES
BLE B153
E153:::~::~

CALL TASKDO
FOR RO := #0 TO SLAVES

CLR RO
B154:::~::~

MOV RO,R1
ASL R1
MOV #5*SECONDS,HUNGTIME
CALL QUE
ON.ERROR

BCC L703

MOV RO,BAD
ERROR +60
\$RETURN ERROR

;SLAVE HUNG SYSTEM!

SEC
RTS PC

END ;OF ON.ERROR

L703:::~::~

TST TASK(R1)
BPL 1\$
END ;OF FOR RO

INC RO
CMP RO,SLAVES

1506 063260

```
MAST11: SUBST <<MULTIPORT PORT I/O PRIORITY TEST>>
:.....
:SUBTEST      MULTIPORT PORT I/O PRIORITY TEST
:.....
```

1507
 1508
 1509
 1510
 1511
 1512
 1513
 1514
 1515
 1516
 1517

```
:THIS TESTS THE ABILITY OF THE MEMORY PORT TO GIVE I/O HIGHER
: PRIORITY THEN CPU ACCESSES
:
:IT DOES THIS BY USING MARGIN #6 IN THE CPU'S MAINT REGISTER
: TO RAISE THE CPU PRIORITY TO THAT OF I/O.
:
: EACH CPU (EXCEPT ONE) HAS HIS PRIORITY RAISED AND
: A TEST IS PERFORMED TO INSURE THAT THESE CPUS ARE GRANTED MORE
: CYCLES THEN THE OTHER CPU.
:
: NEED LINE CLOCK
: IF NOCLOCK IS TRUE THEN $RETURN NOERROR
```

1518 063260 005737 002104
 063260 001402
 063264 000241
 063270 000207
 063272

```
TST NOCLOCK
BEQ L706
CLC
RTS PC
L706:::~::~
```

1519

```
:CAN'T DO UNLESS 4 CPU'S
: IF SLAVES LT #3 THEN $RETURN NOERROR
```

1520
 1521 063272 023727 002730 000003
 063272 002002
 063300 000241
 063302 000207
 063304
 063306

```
CMP SLAVES,#3
BGE L707
CLC
RTS PC
L707:::~::~
```

1522

1523 063306 012737 177767 002676
 1524 063314 013777 002676 117446

```
MOV #11,MDISPLAY
MOV MDISPLAY,@DISPLAY
```

J 8

```

1527
1528 063322 012737 000001 002106
      063322
      063330
1529 063330 013737 002510 002114
1530 063336 004737 042422
1531 063342 012737 000020 002114
1532 063350 013701 002110
1533 063354 032761 000010 003016
      063354 001077
1534 063364 005737 002130
      063370 001074
      063372 005737 002124
      063376 001471
1535
1536
1537 063400 005037 002602
      063400
      063404
1538 063404 005037 002604
      063410
1539 063410 023737 002602 002604
      063416 001416
1540 063420 013701 002604
1541 063424 006301
1542 063426 012761 000016 002616
1543 063434 005737 002604
      063440 001003
1544 063442 004737 050726
1545 063446 000402
      063450
1546 063450 004737 063674
1547 063454
      063454
1548 063454
      063454
1549 063454 005237 002604
      063460 023737 002604 002730
      063466 003750
      063470
1550
1551
1552 063470 005000
      063470
      063472
1553 063472 010001
1554 063474 006301
1555 063476 012761 000005 002616
1556 063504 005200

```

```

;FOR EACH BANK THAT IS ACCESSABLE BY ALL CPU'S
FOR BANK := #1 TO #167

```

```

MOV #1,BANK
B157:.....

```

```

MOV ALLCPUS,CPUBIT
CALL EXBANK
MOV #MASTER,CPUBIT
MOV BANKINDEX,R1
IF #BITS OFF.IN CONFIG(R1) ;IF NO EXTERNAL INTERLEAVE

```

```

BIT #BITS,CONFIG(R1)
BNE L710

```

```

IF PFLAG IS FALSE AND ACFLAG IS TRUE

```

```

TST PFLAG
BNE L711
TST ACFLAG
BEQ L711

```

```

;EACH CPU HAS LOW PRIORITY ONCE
FOR I := #0 TO SLAVES

```

```

CLR I
B160:.....

```

```

FOR J := #0 TO SLAVES

```

```

CLR J
B161:.....

```

```

IF I NE J ;IF NOT THE LOW PRIORITY CPU

```

```

CMP I,J
BEQ L712

```

```

MOV J,R1
ASL R1
MOV #16,TASK(R1)
IF J EQ #0

```

```

;ORDER MARGIN #6

```

```

TST J
BNE L713

```

```

CALL TASKDO
ELSE

```

```

BR L714
L713:.....

```

```

CALL WAIT5
END ;OF IF J EQ #0

```

```

L714:.....

```

```

END ;OF IF I NE J

```

```

L712:.....

```

```

END ;OF FOR J : #0 TO SLAVES

```

```

INC J
CMP J,SLAVES
BLE B161

```

```

E161:.....

```

```

;EVERY CPU WILL DO PORT ARBITRATION TEST
FOR R0 := #0 TO SLAVES

```

```

CLR R0
B162:.....

```

```

MOV R0,R1
ASL R1
MOV #5,TASK(R1)
END ;OF FOR R0

```

```

;ORDER PORT ARBITRATION TEST

```

```

INC R0

```

```
063506 020037 002730
063512 003767
063514
1557 063514 004737 050726 CALL TASKDO
1558
1559 ;WAIT FOR DONE
1560 063520 FOR RO := #0 TO SLAVES
063520 005000
063522
1561 063522 010001 MOV RO,R1
1562 063524 006301 ASL R1
1563 063526 004737 063674 CALL WAIT5
1564 063532 END ;OF FOR RO
063532 005200
063534 020037 002730
063540 003770
063542
1565
1566 ;CHECK RESULTS FOR PROPER SKEWING
1567 063542 004737 063602 CALL MST11A
1568 063546 END ;OF FOR I : #0 TO SLAVES
063546 005237 002602
063552 023737 002602 002730
063560 003711
063562
1569 063562 END ;OF IF PFLAG
063562
1570 063562 END ;OF IF #BIT3 OFF.IN CONFIG(R1)
063562
1571 063562 END ;OF FOR BANK
063562 005237 002106
063566 023727 002106 000167
063574 003655
063576
1572 063576 $RETURN NOERROR
063576 000241
063600 000207
```

CMP RO,SLAVES
BLE B162
E162:::~::~

CLR RO
B163:::~::~

INC RO
CMP RO,SLAVES
BLE B163
E163:::~::~

INC I
CMP I,SLAVES
BLE B160
E160:::~::~

L711:::~::~

L710:::~::~

INC BANK
CMP BANK,#167
BLE B157
E157:::~::~

CLC
RTS PC

1575 063602

```
MST11A: SUBST <<CHECK FOR PROPER SKEWING OF ACCESSES>>
:*****
:*SUBTEST CHECK FOR PROPER SKEWING OF ACCESSES
:*****
```

1576 063602
 063602

BEGIN NOBALANCE

B164:::~::~

1577

```
;FOR EACH CPU
FOR RO :- #0 TO SLAVES
```

CLR RO

1578 063602

063602 005000

B165:::~::~

063604

1579 063604

010001

MOV RO,R1

1580 063606

006301

ASL R1

1581 063610

013703

002602

MOV I,R3

1582 063614

006303

ASL R3

1583 063616

016302

002646

MOV PORTCOUNT(R3),R2

;LOW PRIORITY PORT

1584 063622

016104

002646

MOV PORTCOUNT(R1),R4

;HIGH PRIORITY PORT

1585 063626

160402

SUB R4,R2

1586 063630

006204

ASR R4

1587 063632

006204

ASR R4

1588 063634

006204

ASR R4

;R4 = 12.5% OF HIGH PRIORITY PORT

1589 063636

063636 020037

002602

IF RO NE I

;IF THE CPU SELECTED IS NOT THE LOW PRIORITY ONE

CMP RO,I
 BEQ L715

063642 001407

1590 063644

063644 020204

IF R2 LT R4

CMP R2,R4
 BGE L716

063646 002005

1591 063650

013737

002602

002056

MOV I,BAD

1592 063656

104066

ERROR +66

1593 063660

063660 000404

LEAVE NOBALANCE

BR E164

1594 063662

063662

END ;OF IF R2

L716:::~::~

1595 063662

063662

END ;OF IF RO NE I

L715:::~::~

1596 063662

063662 005200

END ;OF FOR RO

INC RO
 CMP RO,SLAVES
 BLE B165

063664 020037

002730

E165:::~::~

063670 003745

1597 063672

063672

END NOBALANCE

E164:::~::~

1598 063672

000207

RETURN

1599

1600 063674

```
WAIT5: SUBST <<WAIT FOR 5 SECONDS FOR A SLAVE>>
:*****
:*SUBTEST WAIT FOR 5 SECONDS FOR A SLAVE
:*****
```

1601

1602 063674

012737

061165

002574

.ENABL LSB

1603 063702

004737

072154

1\$.

MOV #5*SECONDS,HUNGTIME

1604 063706

063706 103005

CALL QUE

BCC L717

1605 063710

010037

002056

ON.ERROR

MOV RO,BAD

;SLAVE HUNG SYSTEM.

1606 063714

104060

ERROR +60

1607 063716

063716 000261

\$RETURN ERROR

SEC
 RTS PC

063720 000207

1608 063722
063722
1609 063722 005761 002616
1610 063726 100365
1611 063730 000207
1612

END ;OF ON.ERROR
TST TASK(R1)
BPL 1\$
RETURN
.DSABL LSB

L717:.....

1615 063732
 1616
 1617 063732 012737 177766 002676
 1618 063740 013777 002676 117022
 1619 063746 012737 000001 002106
 063754
 1620 063754 013737 002510 002114
 1621 063762 004737 042422
 1622 063766 012737 000020 002114
 1623 063774 005737 002130
 064000 001067
 064002 005737 002124
 064006 001464
 1624 064010 004737 053640
 1625 064014 005000
 064016
 1626 064016 010001
 1627 064020 006301
 1628 064022 005061 002636
 1629 064026 012761 000004 002616
 1630 064034 005200
 064036 020037 002730
 064042 003765
 064044
 1631 064044 004737 050726
 1632 064050 005000
 064052
 1633 064052 010001
 1634 064054 006301
 1635 064056 012737 061165 002574
 1636 064064 004737 072154 1\$:
 1637 064070 103005
 064072 010037 002056
 1638 064072 010037 002056
 1639 064076 104060
 1640 064100 000261
 064102 000207
 1641 064104
 064104
 1642 064104 005761 002616
 1643 064110 100365
 1644 064112 005200
 064114 020037 002730
 064120 003754
 064122
 1645 064122
 064122

```

MAST12: SUBST <<MULTIPOINT EXECUTION CONTENTION TEST>>
:*****
:SUBTEST MULTIPOINT EXECUTION CONTENTION TEST
:*****
      .ENABL  LSB
      MOV     #-12,MDISPLAY
      MOV     MDISPLAY,@DISPLAY
      FOR BANK := #1 TO #167

      MOV #1,BANK
      B166:*****

      MOV  ALLCPUS,CPUBIT
      CALL EXBANK
      MOV  #MASTER,CPUBIT
      IF PFLAG IS FALSE AND ACFLAG IS TRUE

      TST PFLAG
      BNE L720
      TST ACFLAG
      BEQ L720

      CALL  MRUNSETUP
      FOR RO := #0 TO SLAVES

      CLR RO
      B167:*****

      MOV  R0,R1
      ASL  R1
      CLR  PTYBUF(R1)
      MOV  #4,TASK(R1)
      END ;OF FOR RO

      ;CLEAR INC COUNTER
      ;ORDER FOR EXECUTION CONTENTION TEST

      INC RO
      CMP RO,SLAVES
      BLE B167
      E167:*****

      CALL  TASKDO
      FOR RO : #0 TO SLAVES

      CLR RO
      B170:*****

      MOV  R0,R1
      ASL  R1
      MOV  #5*SECONDS,HUNGTIME
      CALL QUE
      ON.ERROR

      BCC L721

      MOV  R0,BAD
      ERROR +60
      $RETURN ERROR

      ;SLAVE HUNG SYSTEM!

      SEC
      RTS PC

      END ;OF ON.ERROR

      L721:*****

      TST  TASK(R1)
      BPL  1$
      END ;OF FOR RO

      INC RO
      CMP RO,SLAVES
      BLE B170
      E170:*****

      BEGIN RUNCOUNT

      B171:*****
    
```



```

1646 064122          FOR R0 := #0 TO SLAVES
      064122 005000
      064124
1647 064124 010001          MOV    R0,R1
      064124 006301          ASL   R1
1648 064126 006301          MOV    PTYBUF,R2
1649 064130 013702 002636    SUB   PTYBUF(R1),R2
1650 064134 166102 002636    IF R2 NE #0
1651 064140
      064140 005702          TST  R2
      064142 001402          BEQ  L722
1652 064144 104052          ERROR +52
1653 064146          LEAVE RUNCOUNT
      064146 000404          BR  E171
1654 064150          END ;OF IF R2
      064150
1655 064150          END ;OF FOR R0
      064150 005200          INC  R0
      064152 020037 002730    CMP  R0,SLAVES
      064156 003762          BLE  B172
      064160          E172:::
1656 064160          END RUNCOUNT
      064160          E171:::
1657 064160          END ;OF IF PFLAG
      064160          L720:::
1658 064160          END ;OF FOR BANK
      064160 005237 002106    INC  BANK
      064164 023727 002106 000167  CMP  BANK,#167
      064172 003670          BLE  B166
      064174          E166:::
1659 064174          $RETURN NOERROR
      064174 000241          CLC
      064176 000207          RTS  PC
1660          .DSABL  LSB
1661
1662 064200          MAST13: SUBST <<MULTIPORT ASRB TEST>>
      ;*****
      ;*SUBTEST      MULTIPORT ASRB TEST
      ;*****
1663 064200 000137 053752    JMP   SUPM13          ;ACTUAL ROUTINE MUST BE IN SUPERVISOR SPACE

```

1666 064204

MAST14: SUBSTST <<MULTIPORT CACHE FLUSH TEST>>
 :*****
 :*SUBTEST MULTIPORT CACHE FLUSH TEST
 :*****

1667
 1668
 1669

:WARNING FAILURES HERE ARE USUALLY DUE TO A CACHE PROBLEM
 :NOT A MAIN MEMORY PROBLEM!
 .ENABL LSB
 IF #BIT3 SET.IN CACHK OR #BIT2 SET.IN CACHK

1670 064204 032737 000010 002700
 064204 001004
 064212 032737 000004 002700
 064222 001402
 064224
 1671 064224 000241
 064224 000207
 1672 064230
 064230

\$RETURN NOERROR ;OPERATOR HAS DISABLED PART OF CACHE
 CLC
 RTS PC
 END ,OF IF #BIT3

BIT #BIT3,CACHK
 BNE L723
 BIT #BIT2,CACHK
 BEQ L724
 L723:::~::~
 L724:::~::~

1673
 1674 064230 012737 177764 002676
 1675 064236 013777 002676 116524
 1676

MOV #-14,MDISPLAY
 MOV MDISPLAY,@DISPLAY

1677 064244 005000
 064244
 064246
 1678 064246 010001
 1679 064250 006301
 1680 064252

FOR R0 : #0 TO SLAVES
 MOV R0,R1
 ASL R1
 FOR BANK := #1 TO #167

CLR R0
 B173:::~::~
 MOV #1,BANK
 B174:::~::~

064252 012737 000001 002106
 064260
 1681 064260 013737 002510 002114
 1682 064266 004737 042422
 1683 064272 012737 000020 002114
 1684 064300 005737 002130
 064304 001056
 064306 005737 002124
 064312 001453

MOV ALLCPUS,CPUBIT
 CALL EXBANK
 MOV #MASTER,CPUBIT
 IF PFLAG IS FALSE AND ACFLAG IS TRUE

1685 064314 005003
 064314
 064316
 1686 064316 010304
 1687 064320 006304
 1688 064322 020401
 064324 001004

FOR R3 : #0 TO SLAVES
 MOV R3,R4
 ASL R4
 IF R4 EQ R1

TST PFLAG
 BNE L725
 TST ACFLAG
 BEQ L725
 CLR R3
 B175:::~::~
 CMP R4,R1
 BNE L726

1689 064326 012764 000020 002616
 1690 064334 000403
 064336

MOV #20,TASK(R4) ;CACHE FLUSH TEST COMMAND
 ELSE

1691 064336 012764 000017 002616
 1692 064344
 064344

MOV #17,TASK(R4) ;CREATE STALE DATA COMMAND
 END ;OF IF R4

1693 064344 005203
 064344 020337 002730
 064346
 064352 003761

END ;OF FOR R3

BR L727
 L726:::~::~
 L727:::~::~
 INC R3
 CMP R3,SLAVES
 BLE B175

```

1694 064354          PUSH      R0,R1          E175:.....
      064354 010046          MOV R0,-(SP)
      064356 010146          MOV R1,-(SP)
1695 064360 004737 050726  CALL      TASKDO
1696 064364          POP       R1,R0
      064364 012601          MOV (SP)+,R1
      064366 012600          MOV (SP)+,R0
1697 064370          FOR R3 := #0 TO SLAVES
      064370 005003
      064372
1698 064372 010304          MOV      R3,R4
1699 064374 006304          ASL     R4
1700 064376 012737 061165 002574  MOV     #5*SECONDS,HUNGTIME
1701 064404 004737 072154 2$:    CALL   QUE
1702 064410          ON.ERROR
      064410 103005
1703 064412 010337 002056          MOV     R3,BAD
1704 064416 104060          ERROR +60
1705 064420          $RETURN ERROR          ;SLAVE HUNG SYSTEM!
      064420 000261          SEC
      064422 000207          RTS PC
1706 064424          END ;OF ON.ERROR
      064424
1707 064424 005764 002616          TST     TASK(R4)
1708 064430 100365          BPL     2$
1709 064432          END ;OF FOR R3
      064432 005203
      064434 020337 002730
      064440 003754
      064442
1710 064442          END ;OF IF PFLAG
      064442
1711 064442          END ;OF FOR BANK
      064442 005237 002106
      064446 023727 002106 000167
      064454 003701
      064456
1712 064456          END ;OF FOR R0
      064456 005200
      064460 020037 002730
      064464 003670
      064466
1713 064466          $RETURN NOERROR
      064466 000241
      064470 000207
1714          .DSABL  LSB

```

```

E175:.....
MOV R0,-(SP)
MOV R1,-(SP)
MOV (SP)+,R1
MOV (SP)+,R0
CLR R3
B176:.....
BCC L730
;SLAVE HUNG SYSTEM!
SEC
RTS PC
L730:.....
INC R3
CMP R3,SLAVES
BLE B176
E176:.....
L725:.....
INC BANK
CMP BANK,#167
BLE B174
E174:.....
INC R0
CMP R0,SLAVES
BLE B173
E173:.....
CLC
RTS PC

```

1717 064472

MAST15: SUBTST <<STOP SLAVES>>

.....
: *SUBTEST STOP SLAVES
:

1718

1719 064472 012737 177763 002676

.ENABL LSB
MOV #-15,MDISPLAY
MOV MDISPLAY,@DISPLAY
FOR RO :- #1 TO SLAVES

1720 064500 013777 002676 116262

1721 064506 012700 000001

MOV #1,R0
B177:.....

1722 064512 010001

MOV R0,R1
ASL R1
MOV #6,TASK(R1)
MOV #2*SECONDS,HUNGTIME
CALL QUE
ON.ERROR

:ORDER STOP TASK

1723 064514 006301

1724 064516 012761 000006 002616

1725 064524 012737 023542 002574

1726 064532 004737 072154

1\$

BCC L731

1727 064536 103005

1728 064540 010037 002056

MOV R0,BAD
ERROR +60
\$RETURN ERROR

:SLAVE HUNG SYSTEM!

1729 064544 104060

1730 064546 000261

SEC
RTS PC

1731 064552 000207

END ;OF ON.ERROR

L731:.....

1732 064552 005761 002616

1733 064556 100365

1734 064560 005200

TST TASK(R1)
BPL 1\$
END ;OF FOR RO

INC R0
CMP R0,SLAVES
BLE B177

1735 064570 000241

1736 064572 000207

\$RETURN NOERROR

E177:.....

CLC
RTS PC

.DSABL LSB

1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795

.SBTTL ERROR DATA SETUP

USE THIS IF THIS CONDITION DESCRIBES THE ERROR

PERR01 TRAP
BAD DATA IN R0 UNLESS ABORTED
THEN BAD DATA IS POINTED TO BY -(R4)
GOOD DATA IN R5

PERR02 TRAP
BAD DATA IN R1 UNLESS ABORTED
THEN BAD DATA IS POINTED TO BY -(R4)
GOOD DATA IN R2

PERR03 TRAP
BAD DATA IS POINTED TO BY -(R1)
GOOD DATA IN R4

PERR04 TRAP
BAD DATA IN R4 UNLESS ABORTED
HEN BAD DATA IS POINTED TO BY -2(R0)
GOOD DAIA IN R2

PERR05 JSR PC
BAD DATA IS POINTED TO BY -(R0)
GOOD DATA IN R2
RETURN AFTER SETTING UP GOOD,BAD,ADDRESS

PERR06 JSR PC
BAD DATA IS POINTED TO BY -(R0)
GOOD DATA IS ZERO
RETURN AFTER SETTING UP GOOD,BAD,ADDRESS

PERR07 TRAP
BAD DATA IN R2 UNLESS ABORTED
THEN BAD DATA IS POINTED TO BY (R1)
GOOD DATA IN DATBUF

PERR10 TRAP
BAD DATA IN R2 UNLESS ABORTED
THEN BAD DATA IS POINTED TO BY 2(R1)
GOOD DATA IN DATBUF+2

PERR11 TRAP
BYTE TEST
BAD DATA IN RIGHT BYTE OF R0 UNLESS ABORTED
THEN BAD DATA IS POINTED TO BY (R1)
GOOD DATA IS A ZERO BYTE

PERR12 TRAP
BYTE TEST
BAD DATA IN RIGHT BYTE OF R0 UNLESS ABORTED
THEN BAD DATA IS POINTED TO BY (R1)
GOOD DATA IS A BYTE OF ONES

PERR13 TRAP
BAD DATA IN R0 UNLESS ABORTED

1796	:		THEN BAD DATA IS POINTED TO BY (R1)
1797	:		GOOD DATA IS ZERO
1798	:		
1799	:	PERR14	TRAP
1800	:		BAD DATA IN R0 UNLESS ABORTED
1801	:		THEN BAD DATA IS POINTED TO BY (R1)
1802	:		GOOD DATA IS ONES
1803	:		
1804	:	PERR15	TRAP
1805	:		BAD DATA IN R0 UNLESS ABORTED
1806	:		THEN BAD DATA IS POINTED TO BY (R1)
1807	:		GOOD DATA IN TSTDAT
1808	:		
1809	:	PERR16	TRAP
1810	:		BAD DATA IN R0 UNLESS ABORTED
1811	:		THEN BAD DATA IS POINTED TO BY (R1)
1812	:		GOOD DATA IN TSTDAT+2
1813	:		
1814	:	PERR17	TRAP
1815	:		BAD DATA IN R0 UNLESS ABORTED
1816	:		THEN BAD DATA IS POINTED TO BY (R1)
1817	:		GOOD DATA IN R2
1818	:		
1819	:	PERR20	TRAP
1820	:		BAD DATA IN R0 UNLESS ABORTED
1821	:		THEN BAD DATA IS POINTED TO BY (R1)
1822	:		GOOD DATA IN R3
1823	:		
1824	:	PERR21	TRAP
1825	:		7 BIT BYTE TEST
1826	:		BAD DATA IN RIGHT BYTE OF R0 UNLESS ABORTED
1827	:		THEN BAD DATA IS POINTED TO BY (R1)
1828	:		GOOD DATA IS A 7 BIT BYTE ON ONES
1829	:		
1830	:	PERR22	TRAP
1831	:		BAD DATA IN R2 UNLESS ABORTED
1832	:		THEN BAD DATA IS POINTED TO BY (R1)
1833	:		GOOD DATA IN R0
1834	:		
1835	:	PERR23	TRAP
1836	:		BAD DATA IN R0 UNLESS ABORTED
1837	:		THEN BAD DATA IS POINTED TO BY (R1)
1838	:		GOOD DATA IN R4
1839	:		
1840	:	PERR24	TRAP
1841	:		BAD DATA IN R0 UNLESS ABORTED
1842	:		THEN BAD DATA IS POINTED TO BY (R2)
1843	:		GOOD DATA IN R3
1844	:		
1845	:	PERR25	TRAP
1846	:		BAD DATA POINTED TO BY -(R1)
1847	:		GOOD DATA IN R2 UNLESS LOC V177654 IS SET
1848	:		THEN GOOD DATA IS IN R3
1849	:		
1850	:	PERR26	TRAP
1851	:		BAD DATA IS DOUBLE WORD POINTED TO BY R1 AND IN LOW 7 BITS OF R0
1852	:		GOOD DATA IS 000000,,100000,,100

1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880

```

: PERR27 TRAP
: BAD DATA IS DOUBLE WORD POINTED TO BY R1 AND IN LOW 7 BITS OF R0
: GOOD DATA IS 000000..000000..077
:
: PERR30 TRAP
: BAD DATA IS POINTED TO BY -16(SP)
: GOOD DATA IS IN R1
:
: PERR31 TRAP
: SPECIAL ECC FAILURE HANDLER
:
: PERR32 TRAP
: SPECIAL ECC FAILURE HANDLER
:
: PERR33 TRAP
: SPECIAL ECC FAILURE HANDLER
:
: PERR34 TRAP
: SPECIAL ECC FAILURE HANDLER
:
: PERR35 TRAP
: SPECIAL BRANCH GOBBLE FAILURE HANDLER
:
: CALLING SEQUENCE FOR TRAP TYPES
: BEQ 2$ ;NO - ERROR,BRANCH FOR CARD
: PERRXX ;TRAP TO ERROR ROUTINE
:2$: NEXT INSTRUCTION ;CONTINUE TESTING

```

```

1883 064574 010437 002040          $PER01: MOV    R4,ADDRESS
1884 064600 162737 000002 002040      SUB    #2,ADDRESS
1885 064606 010437 002056          MOV    R0,BAD
1886 064612 010537 002050          MOV    R5,GOOD
1887 064616 000137 065330          JMP   PERRAW
1888
1889 064622 010437 002040          $PER02: MOV    R4,ADDRESS
1890 064626 162737 000002 002040      SUB    #2,ADDRESS
1891 064634 010137 002056          MOV    R1,BAD
1892 064640 010237 002050          MOV    R2,GOOD
1893 064644 000137 065330          JMP   PERRAW
1894
1895 064650 010137 002040          $PER03: MOV    R1,ADDRESS
1896 064654 162737 000002 002040      SUB    #2,ADDRESS
1897 064662 010437 002050          MOV    R4,GOOD
1898 064666 016137 177776 002056      MOV    -2(R1),BAD
1899 064674 000137 065330          JMP   PERRAW
1900
1901 064700 010037 002040          $PER04: MOV    R0,ADDRESS
1902 064704 162737 000002 002040      SUB    #2,ADDRESS
1903 064712 010437 002056          MOV    R4,BAD
1904 064716 010237 002050          MOV    R2,GOOD
1905 064722 000137 065330          JMP   PERRAW
1906
1907 064726 010237 002050          PERR05: MOV    R2,GOOD
1908 064732 014037 002056          PERA05: MOV    -(R0),BAD
1909 064736 010037 002040          MOV    R0,ADDRESS
1910 064742 062700 000002          ADD    #2,R0          ;RESTORE R0
1911 064746 004737 036770          CALL  BADSTACK
1912 064752 000207          RETURN
1913
1914 064754 005037 002050          PERR06: CLR    GOOD
1915 064760 000764          BR     PERA05
1916
1917 064762 010137 002040          $PER07: MOV    R1,ADDRESS
1918 064766 010237 002056          MOV    R2,BAD
1919 064772 013737 002340 002050      MOV    DATBUF,GOOD
1920 065000 000137 065330          JMP   PERRAW
1921
1922 065004          $PER10: LET ADDRESS :- R1 + #2
1923 065004 010137 002040          MOV R1,ADDRESS
1924 065010 062737 000002 002040      ADD #2,ADDRESS
1925 065016          LET BAD : R2
1926 065016 010237 002056          MOV R2,BAD
1927 065022          LET GOOD : DATBUF+2
1928 065022 013737 002342 002050      MOV DATBUF+2,GOOD
1929 065030 000137 065330          JMP   PERRAW
1930
1931 065034          $PER11: LET ADDRESS : R1
1932 065034 010137 002040          MOV R1,ADDRESS
1933 065040          LET BAD := R0
1934 065040 010037 002056          MOV R0,BAD
1935 065044          LET GOOD : #0
1936 065044 005037 002050          CLR GOOD
1937 065050 000137 065402          JMP   PERRAB
1938
1939 065054          $PER12: LET ADDRESS : R1

```


ERROR DATA SETUP

1933 065054 010137 002040
065060
1934 065060 010037 002056
065064
065064 012737 000377 002050
1955 065072 000137 065402

LET BAD := R0
LET GOOD := #377
JMP PERRAB

MOV R1,ADDRESS
MOV R0,BAD
MOV #377,GOOD

1938	065076			\$PER13: LET ADDRESS :- R1	
	065076	010137	002040		MOV R1,ADDRESS
1939	065102			LET BAD :- R0	
	065102	010037	002056		MOV R0,BAD
1940	065106			LET GOOD :- #0	
	065106	005037	002050		CLR GOOD
1941	065112	000137	065330	JMP PERRAW	
1942					
1943	065116			\$PER14: LET ADDRESS :- R1	
	065116	010137	002040		MOV R1,ADDRESS
1944	065122			LET BAD := R0	
	065122	010037	002056		MOV R0,BAD
1945	065126			LET GOOD : ONES	
	065126	013737	002726 002050		MOV ONES,GOOD
1946	065134	000137	065330	JMP PERRAW	
1947					
1948	065140			\$PER15: LET ADDRESS := R1	
	065140	010137	002040		MOV R1,ADDRESS
1949	065144			LET BAD :- R0	
	065144	010037	002056		MOV R0,BAD
1950	065150			LET GOOD : TSTDAT	
	065150	013737	002344 002050		MOV TSTDAT,GOOD
1951	065156	000137	065330	JMP PERRAW	
1952					
1953	065162			\$PER16: LET ADDRESS :- R1	
	065162	010137	002040		MOV R1,ADDRESS
1954	065166			LET BAD := R0	
	065166	010037	002056		MOV R0,BAD
1955	065172			LET GOOD := TSTDAT+2	
	065172	013737	002346 002050		MOV TSTDAT+2,GOOD
1956	065200	000453		BR PERRAW	
1957					
1958	065202			\$PER17: LET ADDRESS : R1	
	065202	010137	002040		MOV R1,ADDRESS
1959	065206			LET BAD := R0	
	065206	010037	002056		MOV R0,BAD
1960	065212			LET GOOD := R2	
	065212	010237	002050		MOV R2,GOOD
1961	065216	000444		BR PERRAW	
1962					
1963	065220			\$PER20: LET ADDRESS : R1	
	065220	010137	002040		MOV R1,ADDRESS
1964	065224			LET BAD :- R0	
	065224	010037	002056		MOV R0,BAD
1965	065230			LET GOOD :- R3	
	065230	010337	002050		MOV R3,GOOD
1966	065234	000435		BR PERRAW	
1967					
1968	065236			\$PER21: LET ADDRESS : R1	
	065236	010137	002040		MOV R1,ADDRESS
1969	065242			LET BAD :- R0	
	065242	010037	002056		MOV R0,BAD
1970	065246			LET GOOD :- #177	
	065246	012737	000177 002050		MOV #177,GOOD
1971	065254	000477		BR PERRAW	
1972					
1973	065256			\$PER22: LET ADDRESS :- R1	

ERROR DATA SETUP

1974	065256	010137	002040			
	065262			LET BAD :- R2		MOV R1,ADDRESS
	065262	010237	002056			MOV R2,BAD
1975	065266			LET GOOD :- R0		
	065266	010037	002050			MOV R0,GOOD
1976	065272	000416		BR PERRAW		
1977						
1978	065274			\$PER23: LET ADDRESS : R1		
	065274	010137	002040			MOV R1,ADDRESS
1979	065300			LET BAD :- R0		
	065300	010037	002056			MOV R0,BAD
1980	065304			LET GOOD :- R4		
	065304	010437	002050			MOV R4,GOOD
1981	065310	000407		BR PERRAW		
1982						
1983	065312			\$PER24: LET ADDRESS : R2		
	065312	010237	002040			MOV R2,ADDRESS
1984	065316			LET BAD :- R0		
	065316	010037	002056			MOV R0,BAD
1985	065322			LET GOOD :- R3		
	065322	010337	002050			MOV R3,GOOD
1986	065326	000400		BR PERRAW		

```
1988 065330          PERRAW: SUBTST <<DATA WAS A WORD>>
;*****
;*SUBTEST          DATA WAS A WORD
;*****
1989 065330 004737 065564          CALL PERBANK
1990 065334          IF ABORTFLAG IS TRUE THEN $CALL GETDATA
065334 005737 002142          TST ABORTFLAG
065340 001402          BEQ L732
065342 004737 055030          JSR PC,GETDATA
065346          L732:*****
1991 065346          IF BADPC EQ #0 THEN $CALL BADSTACK
065346 005737 002026          TST BADPC
065352 001002          BNE L733
065354 004737 036770          JSR PC,BADSTACK
065360          L733:*****
1992 065360 004737 065540          CALL PERXOR
1993 065364          IF ABORTFLAG IS FALSE
065364 005737 002142          TST ABORTFLAG
065370 001002          BNE L734
1994 065372 104011          ERROR +11
1995 065374          ELSE
065374 000401          BR L735
065376          L734:*****
1996 065376 104012          ERROR +12
1997 065400          END ;OF IF ABORTFLAG
065400          L735:*****
1998 065400 000002          RTI
1999
2000 065402          PERRAB: SUBTST <<DATA WAS A BYTE>>
;*****
;*SUBTEST          DATA WAS A BYTE
;*****
2001 065402 004737 065564          CALL PERBANK
2002 065406          IF ABORTFLAG IS TRUE THEN $CALL GETDATA
065406 005737 002142          TST ABORTFLAG
065412 001402          BEQ L736
065414 004737 055030          JSR PC,GETDATA
065420          L736:*****
2003 065420          IF BADPC EQ #0 THEN $CALL BADSTACK
065420 005737 002026          TST BADPC
065424 001002          BNE L737
065426 004737 036770          JSR PC,BADSTACK
065432          L737:*****
2004 065432 004737 065540          CALL PERXOR
2005 065436          IF ABORTFLAG IS FALSE
065436 005737 002142          TST ABORTFLAG
065442 001002          BNE L740
2006 065444 104014          ERROR +14
2007 065446          ELSE
065446 000401          BR L741
065450          L740:*****
2008 065450 104015          ERROR +15
2009 065452          END ;OF IF ABORTFLAG
065452          L741:*****
2010 065452 000002          RTI
```

```

2013 065454          PERRA7: SUBTST <<DATA WAS A 7 BIT BYTE>>
;*****
;*SUBTEST          DATA WAS A 7 BIT BYTE
;*****
                IF BADPC EQ #0 THEN $CALL BADSTACK

2014 065454          005737 002026          TST BADPC
065460 001002          BNE L742
065462 004737 036770          JSR PC,BADSTACK
065466          L742:::
2015 065466 004737 065540          CALL PERXOR
2016 065472 004737 065564          CALL PERBANK
2017 065476 104022          ERROR +22
2018 065500 000002          RTI
2019
2020 065502          $PER26: LET GOOD2 : #100000
065502 012737 100000 002052          MOV #100000,GOOD2
2021 065510          LET GOOD3 : #100
065510 012737 000100 002054          MOV #100,GOOD3
2022 065516 000137 054652          JMP PERRA3
2023
2024 065522 005037 002052          $PER27: CLR GOOD2
2025 065526          LET GOOD3 :- #077
065526 012737 000077 002054          MOV #077,GOOD3
2026 065534 000137 054652          JMP PERRA3
2027
2028 065540          PERRA7: SUBTST <<DETERMINE XOR OF GOOD & BAD>>
;*****
;*SUBTEST          DETERMINE XOR OF GOOD & BAD
;*****
                PUSH R0
0229 065540          010046          MOV R0,-(SP)
0230 065542 013700 002050          MOV GOOD,R0
0231 065546 013737 002056 002064          MOV BAD,BADXOR
0232 065554 074037 002064          XOR R0,BADXOR
0233 065560          POP R0
065560 012600          MOV (SP)+,R0
0234 065562 000207          RETURN
    
```

2037 065564

PERBANK: SUBST<<LOG ERROR ON BAD BANK>>

:SUBTEST LOG ERROR ON BAD BANK

2038

:WHILE WE'RE HERE LET'S MARK THE BAD BANK IN THE CONFIGURATION TABLE

2039

PUSH R0,R1

MOV R0,-(SP)

MOV R1,-(SP)

065564 010046

065566 010146

2040 065570 013701 002106

MOV BANK,R1

2041 065574 070127 000006

MUL #6,R1

2042 065600 052761 004000 003016

BIS #BIT11,CONFIG(R1)

2043 065606 062701 000005

ADD #5,R1

;POINT TO MAX ERROR BYTE

2044 065612 105261 003016

INCB CONFIG(R1)

;BUMP BANK COUNTER

2045 065616 001002

BNE 12\$

;NO OVERFLOW - SKIP

2046 065620 105361 003016

DECB CONFIG(R1)

;SET BACK TO 255.

2047 065624 126137 003016 002702 12\$:

CMPB CONFIG(R1),ERRMAX

;IS IT PAST MAX?

2048 065632 101403

BLOS 11\$

;NO - SKIP

2049 065634

SET TOOMANY

;YES

065634 012737 177777 002472

11\$:

POP R1,R0

MOV #-1,TOOMANY

2050 065642

065642 012601

11\$:

POP R1,R0

MOV (SP)+,R1

065644 012600

MOV (SP)+,R0

2051 065646 000207

RETURN

2052

2053 065650 010137 002040

PERECC: MOV R1,ADDRESS

2054 065654 010037 002056

MOV R0,BAD

2055 065660

IF R1 EQ TESTADD

065660 020137 002506

CMP R1,TESTADD

065664 001004

BNE L743

2056 065666 013737 002344 002050

MOV TSTDAT,GOOD

2057 065674

ELSE

065674 000403

BR L744

065676

L743:*****

2058 065676 013737 002346 002050

MOV TSTDAT+2,GOOD

2059 065704

END ;OF IF R1

L744:*****

065704

2060 065704 004737 065540

CALL PERXOR

2061 065710

SET HEADER

MOV #-1,HEADER

065710 012737 177777 002724

2062 065716 000207

RETURN

2063

2064 065720

\$PER3: IF BADPC EQ #0 THEN \$CALL BADSTACK

065720 005737 002026

TST BADPC

065724 001002

BNE L745

065726 004737 036770

JSR PC,BADSTACK

065732

L745:*****

2065 065732 004737 065650

CALL PERECC

2066 065736

IF REALPAT EQ #11

065736 023727 002366 000011

CMP REALPAT,#11

065744 001001

BNE L746

2067 065746 104042

ERROR +42

2068 065750

END ;OF IF REALPAT

L746:*****

065750

2069 065750

IF REALPAT EQ #14

065750 023727 002366 000014

CMP REALPAT,#14

065756 001001

BNE L747

2070 065760 104045

ERROR +45

2071 065762
 065762
 2072 065762
 065762 023727 002366 000015
 065770 001001
 2073 065772 104046
 2074 065774
 065774
 2075 065774
 065774 023727 002366 000016
 066002 001001
 2076 066004 104047
 2077 066006
 066006
 2078 066006
 066006 012737 177777 002724
 2079 066014 000002

END ;OF IF REALPAT
 IF REALPAT EQ #15
 ERROR +46
 END ;OF IF REALPAT
 IF REALPAT EQ #16
 ERROR +47
 END ;OF IF REALPAT
 SET HEADER
 RTI

L747:::~::~
 CMP REALPAT,#15
 BNE L750
 L750:::~::~
 CMP REALPAT,#16
 BNE L751
 L751:::~::~
 MOV #-1,HEADER

```

2082 066016          $PER32: IF BADPC EQ #0 THEN $CALL BADSTACK
      066016 005737 002026          TST BADPC
      066022 001002          BNE L752
      066024 004737 036770          JSR PC,BADSTACK
      066030          L752:~~~~~
2083 066030          MOV      R1,ADDRESS
2084 066034          MOV      R0,BAD
2085 066040          MOV      R2,GOOD
2086 066044          SET      HEADER
      066044 012737 177777 002724    MOV  #-1,HEADER
2087 066052          ERROR   +43
2088 066054          SET      HEADER
      066054 012737 177777 002724    MOV  #-1,HEADER
2089 066062          RTI

```

```

2091 066064          $PER33: IF BADPC EQ #0 THEN $CALL BADSTACK
      066064 005737 002026          TST BADPC
      066070 001002          BNE L753
      066072 004737 036770          JSR PC,BADSTACK
      066076          L753:~~~~~
2092 066076          MOV      R1,ADDRESS
2093 066102          MOV      R0,BAD
2094 066106          CLR#   BAD+1
2095 066112          MOV      #377,GOOD
2096 066120          CALL   PERXOR
2097 066124          SET      HEADER
      066124 012737 177777 002724    MOV  #-1,HEADER
2098 066132          ERROR   +44
2099 066134          SET      HEADER
      066134 012737 177777 002724    MOV  #-1,HEADER
2100 066142          RTI

```

```

2102 066144          $PER34: IF BADPC EQ #0 THEN $CALL BADSTACK
      066144 005737 002026          TST BADPC
      066150 001002          BNE L754
      066152 004737 036770          JSR PC,BADSTACK
      066156          L754:~~~~~
2103 066156          IF #BIT15!BIT4 OFF.IN CSR
      066156 032737 100020 002144    BIT  #BIT15!BIT4,CSR
      066164 001002          BNE L755
2104 066166          ERROR   +16          ;NO SBE OR DBE
2105 066170          ELSE
      066170 000401          BR L756
      066172          L755:~~~~~
2106 066172          ERROR   +1          ;EXPECTED SBE SO DBE MUST HAVE GOTTEN SET
2107 066174          END :OF IF #BIT15.BIT4
      066174          L756:~~~~~
2108 066174          RTI

```

```

2110          ;DURING BRANCH GOBBLE THE CONDITION CODES WERE WRONG
2111 066176 004737 065564          $PER35: CALL  PERBANK
2112 066202 004737 036770          CALL  BADSTACK
2113 066206 013737 002036 002056    MOV   BADPSW,BAD
2114 066214 012737 000012 002050    MOV   #12,GOOD
2115 066222 104054          ERROR  +54
2116 066224 062706 000004          ADD   #4,SP
2117 066230 000207          RETURN          ;FIX STACK FROM TRAP
                                     ;ABORTING TEST

```



```

2120 .SBTTL ROUTINE SCOPE HANDLER
2121 .....
2122 :*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
2123 :*AND LOAD THE DISPLAY DATA INTO THE DISPLAY REGISTER
2124 :*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
2125 :*SW14=1 LOOP ON TEST
2126 :*SW9=1 LOOP ON ERROR
2127 :*CALL
2128 :* SCOPE ::SCOPE IOT
2129 066232 005237 075144 $SCOPE: INC $DEVCT ;TELL APT WE ARE ALIVE
2130 066236 IF RESULT IS LT
2131 066236 002004 CLR $DEVCT BGE L757
2132 066240 005037 075144 INCB $UNIT
2133 066244 105237 075146 END ;OF IF RESULT
2134 066250 L757:::
2135 066252 104410 CKSWR ::TEST FOR CHANGE IN SOFT-SWR
2136 066252 023727 002114 000020 IF CPUBIT EQ #MASTER ;IF I'M THE MASTER
2137 066260 001016 CMP CPUBIT,#MASTER
2138 066262 005737 002626 BNE L760
2139 066266 001011 TST PTYFLAG
2140 066270 005737 002630 BNE L761
2141 066274 001006 TST PTYFLAG+2
2142 066276 005737 002632 BNE L761
2143 066302 001003 TST PTYFLAG+4
2144 066304 005737 002634 BNE L761
2145 066310 001402 TST PTYFLAG+6
2146 066312 004737 072154 BEQ L762
2147 066316 CALL QUE
2148 066316 END ;OF IF PTYFLAG
2149 066316 END ;OF IF CPUBIT
2150 066316 L760:::
2151 066316 IF STOPOK IS TRUE AND #SW8 SET.IN @SWR
2152 066316 005737 002520 TST STOPOK
2153 066322 001412 BEQ L763
2154 066324 032777 000400 114434 BIT #SW8,@SWR
2155 066332 001406 BEQ L763
2156 066334 005037 002520 CLR STOPOK
2157 066340 066340 104401 117035 TYPE MSG112 ;PROGRAM HALTING BECAUSE OF SWITCH #8
2158 066344 000137 043522 TYPEIT ,MSG112
2159 066350 .DSABL CRF
2160 066350 JMP EXIT
2161 066350 066350 066350 END ,OF IF STOPOK
2162 066350 L763:::
2163 066350 005737 002540 IF NOSCOPE IS TRUE
2164 066354 001401 TST NOSCOPE
2165 066356 000002 BEQ L764
2166 066360 RTI
2167 066360 END ;OF IF NOSCOPE
2168 066360 L764:::
2169 066360 032777 040000 114400 IS: IF #SW14 SET.IN @SWR THEN GOTO $OVER
2170 066366 001045 BIT #SW14,@SWR
2171 BNE $OVER
2172 ;*****START OF CODE FOR THE XOR TESTER*****
    
```

ROUTINE SCOPE HANDLER

```

2150 066370 000421          $XSTR: BR      2$          ;; IF RUNNING ON THE 'XOR' TESTER (CHANGE
2151                                ;; THIS INSTRUCTION TO A 'NOP' (NOP=240)
2152 066372 013746 000004          MOV      ERRVEC, -(SP)          ;; SAVE THE CONTENTS OF THE ERROR VECTOR
2153 066376 012737 066416          MOV      #1$, ERRVEC          ;; SET FOR TIMEOUT
2154 066404 005737 177060          TST     177060          ;; TIME OUT ON XOR?
2155 066410 012637 000004          MOV      (SP)+, ERRVEC          ;; RESTORE THE ERROR VECTOR
2156 066414 000424          BR      $SVLAD          ;; GO TO THE NEXT TEST
2157 066416 062706 000004          $:      ADD      #4, SP          ;; FIX STACK FROM TRAP
2158 066422 005037 177766          CLR     CPUERR          ;; RESET CPU ERROR REGISTER
2159 066426 012637 000004          MOV      (SP)+, ERRVEC          ;; RESTORE THE ERROR VECTOR
2160 066432 000407          BR      4$          ;; LOOP ON THE PRESENT TEST
2161 066434          2$: ; #####END OF CODE FOR THE XOR TESTER#####
2162 066434 105737 002016          3$:      TSTB     $ERFLG          ;; HAS AN ERROR OCCURRED?
2163 066440 001412          BEQ     $SVLAD          ;; BR IF NO
2164 066442 032777 001000 114316          BIT     #SW9, @SWR          ;; LOOP ON ERROR?
2165 066450 001404          BEQ     5$          ;; BR IF NO
2166 066452 013737 002750 002746 4$:      MOV     $LPERR, $LPADR          ;; SET LOOP ADDRESS TO LAST SCOPE
2167 066460 000410          BR      $OVER          ;;
2168 066462 105037 002016          5$:      CLRB     $ERFLG          ;; ZERO THE ERROR FLAG
2169 066466 011637 002746          $SVLAD: MOV     (SP), $LPADR          ;; SAVE SCOPE LOOP ADDRESS
2170 066472 011637 002750          MOV     (SP), $LPERR          ;; SAVE ERROR LOOP ADDRESS
2171 066476 005037 002454          CLR     $ESCAPE          ;; CLEAR THE ESCAPE FROM ERROR ADDRESS
2172 066502 004737 066514          $OVER:  CALL    GETDIS          ;;
2173 066506 013716 002746          MOV     $LPADR, (SP)          ;; FUDGE RETURN ADDRESS
2174 066512 000002          RTI          ;; FIXES PS

```

```

2176 066514          GETDIS. SUBTST: <<SUBR DISPLAY>>
:.....
: *SUBTST          SUBR    DISPLAY
:.....
2177 066514 113737 002106 002015          MOVB  BANK,$BANK
2178 066522 113737 002366 002014          MOVB  REALPAT,$PATMAR
2179 066530          PUSH  R0,4
                                MOV R0,-(SP)
                                MOV 4,-(SP)
2180 066536 010046 000004          SET4  #2$                ;TRAPS TO 4 GOTO 2$
                                MOV  #2$,4
                                .DSABL CRF
                                CLR   R0
2181 066544 005000          MOV  MAINT,R0
2182 066546 013700 177750          ASH  #4,R0
2183 066552 072027 000004          BR   3$
2184 066556 000402          ADD  #4,SP                ;FIX STACK FROM TRAP
2185 066560 062706 000004          BIC  #^C340,R0
2186 066564 042700 177437          BISB R0,$PATMAR
2187 066570 150037 002014          TST  RLFLAG                ;ARE WE RELOCATED?
2188 066574 005737 002134          BEQ  1$                    ;NO - SKIP
2189 066600 001403          BIS  #BIT15,$PATMAR        ;YES - SET MSB
2190 066602 052737 100000 002014          IF MDISPLAY NE #0 THEN LET $PATMAR : MDISPLAY
2191 066610 005737 002676          TST MDISPLAY
                                BEQ  L765
                                MOV  MDISPLAY,$PATMAR
                                L765:::
2192 066624 013777 002014 114136          MOV  $PATMAR,MDISPLAY
2193 066632 013737 002014 000174          MOV  $PATMAR,DISPREG        ;SOFTWARE DISPLAY REGISTER
2194 066640          POP   4,R0
                                MOV (SP)+,4
                                MOV (SP)+,RC
2195 066646          RES4                ;RESTORE TRAPS TO 4 TO DEFAULT
                                MOV  #TIMEOUT,4
                                CLR   CPUERR                ;CLEAR OUT THE CPU ERROR REGISTER BITS
                                .DSABL CRF                    ;THAT A EXPECTED TRAP COULD HAVE SET
2196 066660 000207          RETURN

```

```

2139
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213 066662
      066662 005737 002530
      066666 001027
2214 066670 104410
2215 066672 105237 002016
2216 066676 001775
2217 066700 004737 066514
2218 066704 013737 002014 075140
2219 066712 032777 002000 114046
2220 066720 001404
2221 066722
      066722 104401 003003
2222 066726
      066726 104401 112132
2223 066732 005237 002754
2224 066736
      066736 100003
2225 066740 012737 077777 002754
2226 066746
      066746
2227 066746
      066746
2228 066746 011637 002024
2229 066752 162737 000002 002024
2230 066760 010637 002030
2231 066764 016637 000002 002034
2232 066772 117737 113026 002017
2233 067000
      067000 005737 002530
      067004 001044
2234 067006
      067006 005737 002026
      067012 001416
2235 067014 013737 002026 002024
2236 067022 162737 000002 002024
2237 067030 013737 002032 002030
2238 067036 013737 002036 002034
2239 067044 005037 002026
2240 067050
      067050
2241 067050 013737 002024 075136
  
```

```

.SBTL ROUTINE ERROR HANDLER
.....
*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT.
*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
*AND GO TO SERRTYP ON ERROR
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW15=1 HALT ON ERROR
*SW13=1 INHIBIT ERROR TYPEOUTS
*SW10=1 BELL ON ERROR
*SW9=1 LOOP ON ERROR
*CALL
*      ERROR N      ;;ERROR EMT AND N ERROR ITEM NUMBER

.ENABL LSB
$ERROR: IF NOERROR IS FALSE

                                TST NOERROR
                                BNE L766

1$:   CKSWR                      ;;TEST FOR CHANGE IN SOFT-SWR
      INCB $ERFLG                ;;SET THE ERROR FLAG
      BEQ 1$                      ;;DON'T LET THE FLAG GO TO ZERO
      CALL GETDIS                 ;;SETUP DISPLAY STUFF
      MOV $PATMAR,$TESTN          ;;FOR APT
      BIT #SW10,@SWR             ;;BELL ON ERROR?
      BEQ 2$                      ;;NO - SKIP
      TYPE $BELL                 ;;RING BELL
      TYPEIT , $BELL
      .DSABL CRF
      TYPE MSG014                ;CONTROL Z
      TYPEIT ,MSG014
      .DSABL CRF

2$:   INC $ERTTL                 ;;COUNT THE NUMBER OF ERRORS
      IF RESULT IS MI
                                BPL L767

      MOV #77777,$ERTT
      END ;OF IF RESULT
                                L767:::
      END ;OF IF NOERROR
                                L766:::
      MOV (SP),ERRPC             ;;GET ADDRESS OF ERROR INSTRUCTION
      SUB #2,ERRPC
      MOV SP,ERRSP
      MOV 2(SP),ERRPSW
      MOVB @ERRPC,$ITEMB        ;;STRIP AND SAVE THE ERROR ITEM CODE
      IF NOERROR IS FALSE
                                TST NOERROR
                                BNE L770

      IF BADPC NE #0
                                TST BADPC
                                BEQ L771

      MOV BADPC,ERRPC
      SUB #2,ERRPC
      MOV BADSP,ERRSP
      MOV BADPSW,ERRPSW
      CLR BADPC
      END ;IF
                                L771:::

      MOV ERRPC,$FATAL          ;FOR APT
  
```

INF ERROR HANDLER

```

2242 067056          IF #SW13 SET.IN @SWR OR SLAERROR IS TRUE
      067056 032777 020000 113702
      067064 001003
      067066 005737 002570
      067072 001401
      067074
2243 067074 000412          BR 3$
2244 067076          END ;OF IF #SW13
      067076
2245 067076          IF #SW5 SET.IN @SWR AND TOOMANY IS TRUE
      067076 032777 000040 13662
      067104 001404
      067106 005737 002472
      067112 001401
2246 067114          GOTO 3$
      067114 000402
2247 067116          END ;OF IF #SW5
      067116
2248 067116          END ;OF IF NOERROR
      067116
2249 067116 004737 067324    CALL $ERRTYP          ;;GO TO USER ERROR ROUTINE

```

```

BIT #SW13,@SWR
BNE L772
TST SLAERROR
BEQ L773

```

L772:.....

L773:.....

```

BIT #SW5,@SWR
BEQ L774
TST TOOMANY
BEQ L774

```

BR 3\$

L774:.....

L770:.....

```

2251 067122          3$:   IF NOERROR IS FALSE
      067122 005737 002530
      067126 001064
2252 067130          TST  @SWR          ;;HALT ON ERROR
      067130 005777 113632          BPL  ?$          ;;SKIP IF CONTINUE
2253 067134 100002          $HALT:  HALT          ;;HALT ON ERROR!
2254 067136 000000          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
2255 067140 104410          7$:   IF NOSCOPE IS FALSE AND #SW9 SET.IN @SWR
2256 067142          TST  NOSCOPE
      067142 005737 002540          BNE  L776
      067146 001006          BIT  #SW9,@SWR
      067150 032777 001000 113610      BEQ  L776
      067156 001402
2257 067160 013716 002750          MOV  $LPERR,(SP)  ;;FUDGE RETURN FOR LOOPING
2258 067164          END ;OF IF NOSCOPE
      067164          L776:::
2259 067164 005737 002454          TST  $ESCAPE     ;;CHECK FOR AN ESCAPE ADDRESS
2260 067170 001402          BEQ  9$          ;;BR IF NONE
2261 067172 013716 002454          MOV  $ESCAPE,(SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
2262 067176          9$:   IF DETFLAG IS FALSE
      067176 005737 002326          TST  DETFLAG
      067202 001035          BNE  L777
2263 067204          IF ACTFLAG IS TRUE OR APTFLAG IS TRUE OR FATAL$ IS TRUE
      067204 005737 002442          TST  ACTFLAG
      067210 001006          BNE  L1000
      067212 005737 002444          TST  APTFLAG
      067216 001003          BNE  L1000
      067220 005737 002070          TST  FATAL$
      067224 001405          BEQ  L1001
      067226          L1000:::
2264 067226 012737 000001 075134          MOV  #1,$MSGTY  ;FOR APT
2265 067234 000137 043522          JMP  EXIT
2266 067240          END ;OF IF ACTFLAG
      067240          L1001:::
2267 067240          IF XXDPCHAIN IS TRUE AND $ERTTL HI #20
      067240 005737 002446          TST  XXDPCHAIN
      067244 001414          BEQ  L1002
      067246 023727 002754 000020      CMP  $ERTTL,#20
      067254 101410          BLOS L1002
2268 067256          TYPE  MSG066          ;ERROR COUNT EXCEEDED 20 - ABORTING FOR XXDP CHAIN
      067256 104401 115142          TYPEIT ,MSG066
      .DSABL CRF
      MOV  42,R0
      CLR  42
      JMP  $ZAP42
      END ;OF IF XXDPCHAIN
      L1002:::
2269 067262 013700 000042          END ;OF IF DETFLAG
2270 067266 005037 000042          L777:::
2271 067272 000137 014760          ELSE
2272 067276          BR  L1003
      067276          L775:::
2273 067276          SET  HEADER
      067276 000403          MOV  #-1,HEADER
2274 067300          END ;OF IF NOERROR
2275 067300 012737 177777 002724          L1003:::
2276 067306          CLEAR  TOOMANY,CPUERR,NOERROR
      067306          CLR  TOOMANY
2277 067306
      067306 005037 002472
  
```

067312 005037 177766
067316 005037 002530
2278 067322 000002
2279

RTI
.DSABL LSB

::RETURN

LF PUERR
LF NOERROR

2282
 2283
 2284
 2285
 2286
 2287
 2288
 2289 067324 104415
 2290 067326 104401 003010
 2291 067332 005000
 2292 067334 153700 002017
 2293 067340 001004
 2294
 2295 067342 013746 002024
 067346 104402
 2296 067350 000512
 2297 067352 005300
 2298 067354 006300
 2299 067356 006300
 2300 067360 006300
 2301 067362 062700 101372
 2302 067366 012037 067424
 2303 067372 001417
 2304 067374 005737 002530
 2305 067400 001003
 2306 067402 005737 002724
 2307 067406 100011
 2308 067410 005737 002070
 2309 067414 001402
 2310 067416 104401 115225
 067416
 2311 067422 104401
 067422
 2312 067424 000000
 2313 067426 104401 003010
 067426
 2314 067432 012037 067456
 2315 067436 001412
 2316 067440 005737 002530
 2317 067444 001003
 2318 067446 005737 002724
 2319 067452 100004
 2320 067454 104401
 067454
 2321 067456 000000
 2322 067460 104401 003010
 067460

.SBTTL ROUTINE ERROR MESSAGE TYPEOUT

```

*****
; *THIS ROUTINE USES THE 'ITEM CONTROL BYTE' ($ITEMB) TO DETERMINE WHICH
; *ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE 'ERROR TABLE' ($ERRTB),
; *AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
*****
$ERRTYP: SAVREG
TYPE          $CRLF          ;; 'CARRIAGE RETURN' & 'LINE FEED'
TYPEIT        , $CRLF
.DSABL        CRF
CLR           RO             ;; PICKUP THE ITEM INDEX
BISB         $ITEMB, RO
BNE          1$             ;; IF ITEM NUMBER IS ZERO, JUST
                          ;; TYPE THE PC OF THE ERROR
TYPOCT       ERRPC, <ERROR ADDRESS>
MOV          ERRPC, -(SP)   ;; SAVE ERRPC FOR TYPEOUT
                          ;; ERROR ADDRESS
                          ;; GO TYPE--OCTAL ASCII (ALL DIGITS)
.DSABL        CRF
BR           11$           ;; GET OUT
1$: DEC       RO             ;; ADJUST THE INDEX SO THAT IT WILL
ASL          RO             ;; WORK FOR THE ERROR TABLE
ASL          RO
ASL          RO
ADD          # $ERRTB, RO   ;; FORM TABLE POINTER
MOV          (RO)+, 3$      ;; PICKUP 'ERROR MESSAGE' POINTER
BEQ          4$             ;; SKIP TYPEOUT IF NO POINTER
TST         NOERROR        ;; IS THIS REALLY AN ERROR?
BNE          12$           ;; YES - SKIP
TST         HEADER         ;; TYPE HEADER?
BPL          4$             ;; NO - SKIP
12$: TST      FATAL$        ;; WAS IT A FATAL ERROR?
BEQ          2$             ;; NO - SKIP
TYPE        MSG067         ;; FATAL
TYPEIT      , MSG067
.DSABL      CRF
2$: TYPE
TYPEIT
.DSABL      CRF
3$: .WORD    0              ;; 'ERROR MESSAGE' POINTER GOES HERE
TYPE       $CRLF          ;; 'CARRIAGE RETURN' & 'LINE FEED'
TYPEIT     , $CRLF
.DSABL     CRF
4$: MOV     (RO)+, 5$      ;; PICKUP 'DATA HEADER' POINTER
BEQ        6$             ;; SKIP TYPEOUT IF 0
TST        NOERROR        ;; IS THIS REALLY AN ERROR?
BNE        13$           ;; YES - SKIP
TST        HEADER         ;; TYPE HEADER?
BPL        6$             ;; NO - SKIP
13$: TYPE
TYPEIT
.DSABL     CRF
5$: .WORD    0              ;; 'DATA HEADER' POINTER GOES HERE
TYPE       $CRLF          ;; 'CARRIAGE RETURN' & 'LINE FEED'
TYPEIT     , $CRLF
.DSABL     CRF
  
```



```
2323 067464 012001      6S:  MOV  (R0)+,R1      ::PICKUP 'DATA TABLE' POINTER  
2324 067466 001436      BEQ  10$        ::BR IF NO DATA TO BE TYPED  
2325 067470 012002      MOV  (R0)+,R2      ::PICKUP 'DATA FORMAT' POINTER
```

```

2328 067472 112203          7$:  MOVB   (R2)+,R3
2329 067474 006303          ASL    R3           ;MAKE IT A WORD ADDRESS
2330 067476 004773 067504     CALL   @B$(R3)
2331 067502 000421          BR     9$
2332 067504 067636          8$:  TAG70$
2333 067506 067646          TAG71$
2334 067510 067656          TAG72$
2335 067512 067722          TAG73$
2336 067514 067730          TAG74$
2337 067516 067742          TAG75$
2338 067520 067754          TAG76$
2339 067522 067776          TAG77$
2340 067524 070000          TAG78$
2341 067526 070006          TAG79$
2342 067530 070066          TAG80$
2343 067532 070100          TAG81$
2344 067534 070122          TAG82$
2345 067536 070324          TAG83$
2346 067540 070410          TAG84$
2347 067542 070502          TAG85$
2348 067544 070612          TAG86$
2349 067546 062701 000002     9$:  ADD    #2,R1       ;UPDATE DATA TABLE POINTER
2350 067552 005711          TST   (R1)        ;;IS THERE ANOTHER NUMBER?
2351 067554 001403          BEQ   10$         ;;BR IF NO
2352 067556 104401 112161     TYPE  MSG018      ;TYPE 2 SPACES
                TYPEIT ,MSG018
                .DSABL CRF
                BR     7$           ;;LOOP
2353 067562 000743
2354
2355 067564 005737 002116     10$: TST   MUT        ;IS THERE A MEMORY UNDER TEST
2356 067570 001402          BEQ   11$         ;NO - SKIP
2357 067572 005237 002724     INC   HEADER      ;YES - BUMP HEADER FLAG
2358 067576 104416          11$: RESREG
2359 067600          IF #SW7 SET.IN @SWR AND DETFLAG IS FALSE AND NOERROR IS FALSE
                BIT #SW7,@SWR
                BEQ L1004
                TST DETFLAG
                BNE L1004
                TST NOERROR
                BNE L1004
                067600 032777 000200 113160
                067606 001410
                067610 005737 002326
                067614 001005
                067616 005737 002530
                067622 001002
2360 067624 004737 071364          CALL  DETAIL
2361 067630          END ;OF IF #SW7
                067630
2362 067630          TYPE  MSG104      ;CONTROL Z
                TYPEIT ,MSG104
                .DSABL CRF
                RETURN
                067634 000207
                L1004:::~::~

```

```

2366
2367
2368
2369 067636 017146 000000
      067636 104402
      067642
TAG70$: TYPOCT @ (R1)          ;; TYPE AN OCTAL NUMBER
        MOV @ (R1),-(SP)      ;; SAVE @ (R1) FOR TYPEOUT
        TYPOC
        .DSABL CRF
        RETURN

2370 067644 000207
2371
2372
2373
2374
2375 067646 017146 000000
      067646 104405
      067652
TAG71$: TYPDEC @ (R1)         ;; TYPE A DECIMAL NUMBER
        MOV @ (R1),-(SP)      ;; SAVE @ (R1) FOR TYPEOUT
        TYPDS
        .DSABL CRF
        RETURN

2376 067654 000207
2377
2378
2379
2380
2381 067656 010146
      067656 010546
      067660 013701 002106
2382 067662 070127 000006
      067666
2383 067672 012737 177777 002464
      067672 004737 036012
2385 067700 005037 002464
      067704
2386 067710 012605
      067710 012601
2387 067714 104401 112132
      067714
TAG72$: PUSH R1,R5
        MOV R1,-(SP)
        MOV R5,-(SP)
        MOV BANK,R1
        MUL #6,R1
        SET NOTAB
        CALL TCFIG1
        CLR NOTAB
        POP R5,R1
        MOV (SP)+,R5
        MOV (SP)+,R1
        TYPE MSG014 ;1 SPACE
        TYPEIT ,MSG014
        .DSABL CRF
        RETURN

2389 067720 000207
2390
2391
2392
2393
2394 067722 004737 070672
2395 067726 000207
2396
2397
2398
2399
2400 067730 013746 002366
      067730 104403
      067734 002
      067736 001
      067737
TAG74$: TYPOCS REALPAT,<TYPE (0-77)>,2,Z
        MOV REALPAT,-(SP)    ;; SAVE REALPAT FOR TYPEOUT
        TYPOS
        .BYTE 2 ;; TYPE (0-77)
        .BYTE 1 ;; GO TYPE--OCTAL ASCII
        .BYTE 1 ;; TYPE 2 DIGIT(S)
        .DSABL CRF ;; TYPE LEADING ZEROS
        RETURN

2401 067740 000207
2402
2403

```

2404
2405
2406 067742 015746 002106
067746 104403
067750 003
067751 000
2407 067752 000207
2408
2409
2410
2411
2412 067754 005737 002126
2413 067760 001003
2414 067762 104401 115234
067762 104401 115234
2415 067766 000207
2416 067770 104401 115241
067770 104401 115241
2417 067774 000207

```
***** BANK ****  
*****  
TAG75$: TYPOCS BANK,<TYPE (0-167)>,3  
MOV BANK,-(SP) ;:SAVE BANK FOR TYPEOUT  
;:TYPE (0-167)  
TYPOS ;:GO TYPE--OCTAL ASCII  
.BYTE 3 ;:TYPE 3 DI IT(S)  
.BYTE 0 ;:SUPPRESS LEADING ZEROS  
.DSABL CRF  
RETURN  
  
***** MTYPE ****  
*****  
TAG76$: IST MKFLAG  
BNE 1$  
TYPE MSG068 ;MJ11  
TYPEIT ,MSG068  
.DSABL CRF  
RETURN  
$: TYPE MSG069 ;MK11  
TYPEIT ,MSG069  
.DSABL CRF  
RETURN
```

```

2420
2421
2422
2423 067776 000207
2424
2425
2426
2427
2428 070000
070000 104401 15060
2429 070004 000207
2430
2431
2432
2433
2434 070006 013737 002040 002044
2435 070014 162737 060000 002044
2436 070022 013737 002106 002046
2437 070030 006237 002046
2438 070034 103003
2439 070036 052737 100000 002044
2440 070044 012746 002044
2441 070050 004737 075014
2442 070054 062706 000002
2443 070060
070060 104401 075122
2444 070064 000207
2445
2446
2447
2448 070066
070066 013746 002112
070072 104403
070074 001
070075 000
2449 070076 000207
2450
2451
2452
2453
2454 070100
070100 104401 112161
2455 070104
070104 017146 000000
070110 104403
070112 003
070113 001
2456 070114
070114 104401 112132

```

```

:*****
:*** SPARE FUNCTION ***
:*****
TAG77$: RETURN
:*****
:*** UNKNOWN DATA ***
:*****
TAG78$: TYPE      MSG061
TYPEIT  ,MSG061
.DSABL  CRF
RETURN
:*****
:*** PHYSICAL ADDRESS ***
:*****
TAG79$: MOV      ADDRESS,PHYADD
SUB      #FIRST,PHYADD
MOV      BANK,PHYADD+2
ASR      PHYADD+2
BCC      1$
BIS      #BIT15,PHYADD
1$: MOV      #PHYADD,-(SP)          ;POINTER TO DOUBLE WORD ON STACK
CALL     $DB20                    ;CALL DOUBLE PRECISION CONVERSION ROUTINE
ADD      #2,SP                    ;FIX STACK
TYPE     $OCT8
TYPEIT  ,OCT8
.DSABL  CRF
RETURN
:*****
:*** MARGIN ***
:*****
TAG80$: TYPOCS  MARGIN,<TYPE (0,2,3,4, OR 5)>,1
MOV      MARGIN,-(SP)             ;;SAVE MARGIN FOR TYPEOUT
;;TYPE (0,2,3,4, OR 5)
TYPOS    ;;GO TYPE--OCTAL ASCII
.BYTE    1                        ;;TYPE 1 DIGIT(S)
.BYTE    0                        ;;SUPPRESS LEADING ZEROS
.DSABL  CRF
RETURN
:*****
:*** OCTAL BYTE ***
:*****
TAG81$: TYPE     MSG018           ;2 SPACES
TYPEIT  ,MSG018
.DSABL  CRF
TYPOCS  @(R1),<TYPE BYTE>,3,2
MOV      @(R1),-(SP)             ;;SAVE @(R1) FOR TYPEOUT
;;TYPE BYTE
TYPOS    ;;GO TYPE--OCTAL ASCII
.BYTE    3                        ;;TYPE 3 DIGIT(S)
.BYTE    1                        ;;TYPE LEADING ZEROS
.DSABL  CRF
TYPE     MSG014                 ;SPACE
TYPEIT  ,MSG014
.DSABL  CRF

```

2457 070120 000207

RETURN

```

2460 .....
2461 *** ARRAY ***
2462 .....
2463 ;SOMETIMES THE ARRAY INFORMATION MAY BE MISLEADING
2464 ; IF YOU ARE LOOKING FOR SBE'S (SWITCH 0 IS UP)
2465 ; IF AN ERROR IS BEING REPORTED AND THE CODE THAT TYPES THE
2466 ; ERROR HAS A SINGLE BIT ERROR
2467 ; THE OLD SBE INFORMATION WILL BE WRITTEN OVER AND THE ARRAY
2468 ; TYPED MAY BE THE ARRAY THAT HAS THE ERROR REPORT CODE IN IT
2469 ; AND NOT THE ARRAY THAT WAS UNDER TEST AND THAT THE REST
2470 ; OF THE ERROR REPORT IS TALKING ABOUT.
2471 ; HOWEVER THE ARRAY IS STILL BAD (IF YOU'RE LOOKING FOR SBE'S).
2472 070122 012737 037477 115336 TAG82$: MOV #'??',MSG074
2473 070130 IF MKFLAG IS TRUE
070130 005737 002126 TST MKFLAG
070134 001470 BEQ L1005
2474 070136 PUSH CSR,CSR+2,R0,R1,R2,CSRNO
070136 013746 002144 MOV CSR,-(SP)
070142 013746 002146 MOV CSR+2,-(SP)
070146 010046 MOV R0,-(SP)
070150 010146 MOV R1,-(SP)
070152 010246 MOV R2,-(SP)
2475 070160 013737 002256 002256 MOV BADCSR,CSRNO
2476 070166 SET R2 MOV CSRNO,-(SP)
070166 012702 177777 MOV #-1,R2
2477 070172 104426 READCSR
2478 070174 IF #BIT15.BIT4 SET.IN CSR
070174 032737 100020 002144 BIT #BIT15 BIT4,CSR
070202 001414 BEQ L1006
2479 070204 013702 002144 MOV CSR,R2
2480 070210 072227 177774 ASH #-4,R2
2481 070214 042702 177761 BIC #*C16,R2
2482 070220 IF #BIT9 SET.IN CSR+2 THEN LET R2 := R2 SET.BY #BIT0
070220 032737 001000 002146 BIT #BIT9,CSR+2
070226 001402 BEQ L1007
070230 052702 000001 BIS #BIT0,R2
2483 070234 END ;OF IF #BIT15.BIT4 L1007:.....
070234 IF R2 GE #0 L1006:.....
2484 070234 005702 TST R2
070236 002416 BLT L1010
2485 070240 IF R2 GT #9.
070240 020227 000011 CMP R2,#9.
070244 003406 BLE L1011
2486 070246 162702 000012 SUB #10.,R2
2487 070252 000302 SWAB R2
2488 070254 062702 030061 ADD #*10,R2
2489 070260 ELSE
070260 000403 BR L1012
070262 L1011:.....
2490 070262 000302 SWAB R2
2491 070264 062702 030040 ADD #*0,R2
2492 070270 END ;OF IF #BIT3
070270 L1012:.....
2493 070270 010237 115336 MOV R2,MSG074

```

2494 070274
 070274
 2495 070274
 070274 012637 002256
 070300 012602
 070302 012601
 070304 012600
 070306 012637 002146
 070312 012637 002144
 2496 070316
 070316
 2497 070316
 070316 104401 115336
 2498 070322 000207

END :OF IF R2
 POP (SRND,R2,R1,RO,(SR+2),SR
 END :OF IF MKFLAG
 TYPE MSG074
 TYPEIT ,MSG074
 .DSABL CRF
 RETURN

L1010:.....

MOV (SP), (SRND)
 MOV (SP), R2
 MOV (SP), R1
 MOV (SP), RO
 MOV (SP), (SR+2)
 MOV (SP), (SR)

L1005:.....


```
2501 .....  
2502 *** BINARY BYTE ***  
2503 .....  
2504 TAG83$: PUSH R0,R2  
070324 010046 MOV R0,-(SP)  
070326 010246 MOV R2,-(SP)  
2505 070330 TYPE MSG018 :2 SPACES  
070330 104401 112161 TYPEIT ,MSG018  
.DSABL CRF  
MOV @ (R1),R0  
FOR R2 : #1 TO #8.  
2506 070334 017100 000000 ROLB R0  
2507 070340 012702 000001 ON.ERROR  
070344 B200:.....  
2508 070344 106100 MOV #1,R2  
2509 070346 103004 BCC L1013  
070346 112737 000061 112134 MOVB #1,MSG015  
2510 070350 000403 ELSE  
2511 070356 070360 BR L1014  
070360 L1013:.....  
2512 070360 112737 000060 112134 MOVB #0,MSG015  
2513 070366 END :OF ON.ERROR  
070366 L1014:.....  
2514 070366 104401 112134 TYPE MSG015  
070366 TYPEIT ,MSG015  
.DSABL CRF  
END :OF FOR R2  
2515 070372 005202 INC R2  
070372 020227 000010 CMP R2,#8.  
070400 003761 BLE B200  
070402 E200:.....  
2516 070402 POP R2,R0  
070402 012602 MOV (SP)+,R2  
070404 012600 MOV (SP)+,R0  
2517 070406 000207 RETURN  
2518 .....  
2519 *** 4 BINARY BITS ***  
2520 .....  
2521 .....  
2522 TAG84$: PUSH R0,R2  
070410 010046 MOV R0,-(SP)  
070412 010246 MOV R2,-(SP)  
2523 070414 TYPE MSG018 :2 SPACES  
070414 104401 112161 TYPEIT ,MSG018  
.DSABL CRF  
MOV @ (R1),R0  
MOV #4,R2  
ASH R2,R0 :SHIFT 4 PLACES LEFT  
FOR R2 := #1 TO #4  
2524 070420 017100 000000 MOV #1,R2  
2525 070424 012702 000004 B201:.....  
2526 070430 072002 ROLB R0  
2527 070432 012702 000001 ON.ERROR  
070436 BCC L1015  
2528 070436 106100 MOVB #1,MSG015  
2529 070440 103004 ELSE  
070440 112737 000061 112134  
2530 070442 000403 BR L1016  
2531 070450 070450 000403
```

532	070452	112737	000060	112134	MOV8	#'0,MSG015	L1015:::~::~
533	070460				END	:OF ON.ERROR	
534	070460				TYPE	MSG015	L1016:::~::~
	070460	104401	112134		TYPEIT	,MSG015	
	070464				.DSABL	CRF	
	070464	005202			END	:OF FOR R2	
	070466	020227	000004				INC R2
	070472	003761					CMP R2,#4
	070474						BLE B201
535	070474				POP	R2,R0	E201:::~::~
	070474	012602					MOV (SP),R2
	070476	012600					MOV (SP),R0
537	070500	000207			RETURN		


```
2572 070640          END IF
      070640
2573 070640          IF BAD EQ #2
      070640 023727 002056 000002
      070646 001002
      070650          TYPE MSG115
      070650 104401 117123          :SLAVE2
      070650          TYPEIT ,MSG115
      070650          .DSABL CRF
      070650          END IF
      070654          L1024:.....
      070654          IF BAD EQ #3
      070654 023727 002056 000003
      070662 001002
      070664          TYPE MSG116
      070664 104401 117133          :SLAVE3
      070664          TYPEIT ,MSG116
      070664          .DSABL CRF
      070670          END IF
      070670          L1025:.....
      070670          CMP BAD,#3
      070670          BNE L1026
      070670          L1026:.....
      070670 000207          RETURN
```

ROUTINE ERROR MESSAGE TYPEOUT

2581 070672

WHOBOX: SUBST <<SUBR WHO'S BOX IS THIS?>>

.....
:SUBTEST SUBR WHO'S BOX IS THIS?
.....

2582 070672 005737 002126

2583 070676 001003

2584

2585 070700 104401 114716
070700

TST MKFLAG :MK1?
BNE 1\$:YES - SKIP
:NO - MJ11 - DON'T KNOW ABOUT BOX NUMBERS
TYPE MSG057 : ?
TYPEIT ,MSG057
.DSABL CRF
RETURN

2586 070704 000207

2587

2588 070706 013746 002256
070706

1\$: PUSH CSRNO,R1,R2,R3,R4

MOV CSRNO,-(SP)
MOV R1,-(SP)
MOV R2,-(SP)
MOV R3,-(SP)
MOV R4,-(SP)

070712 010146

070714 010246

070716 010346

070720 010446

2589 070722 005037 002424

2590 070726 012703 000200

2591 070732 012701 000060

2592 070736

CLR SUCCESS
MOV #200,R3
MOV #'0,R1
BEGIN WHODUNIT

070736

2593 070736 005004

FOR R4 := #0 TO #16 BY #2

B202:::~::~

070740

2594 070740

IFB R3 SET.JN MKCSRS

CLR R4
B203:::~::~

070740 130337 002334

070744 001452

2595 070746 016437 002214 002260

2596 070754 016437 002234 002262

2597 070762 010437 002000

2598 070766 006337 002000

2599 070772

MOV CSRFB(R4),FIRSTB
MOV CSRLB(R4),LASTB
MOV R4,BADCSR
ASL BADCSR
IF FIRSTB LE BANK AND LASTB GE BANK

070772 023737 002260 002106

071000 003034

071002 023737 002262 002106

071010 002430

2600 071012 016402 002174

2601 071016 072227 177764

2602 071022 042702 177770

2603 071026

MOV CSR2(R4),R2
ASH #-12.,R2
BIC #^C7,R2
CASE R2

071026 010246

071030 006316

071032 004737 071056

CMF FIRSTB,BANK
BGT L1030
CMP LASTB,BANK
BLT L1030

2604 071036 071152

2605 071040 071162

2606 071042 071202

2607 071044 071232

2608 071046 071262

2609 071050 071264

2610 071052 071304

2611 071054 071334

2612 071056

ADD..0
ADD..1
ADD..2
ADD..3
ADD..4
ADD..5
ADD..6
ADD..7
END ;OF CASE R2

071056 062616

071060 013646

L1031:::~::~
ADD (SP)+,@SP
MOV @ (SP)+,-(SP)

2613	071062	004736							
	071064				IF SUCCESS IS TRUE THEN LEAVE WHODUNIT			JSR PC,@(SP)+	
	071064	005737	002424					IST SUCCESS	
	071070	001007						BNE E202	
2614	071072				END ;OF IF FIRSTB				
	071072							L1030:::~::~	
2615	071072				END ;OF IFB R3				
	071072							L1027:::~::~	
2616	071072	006003			ROR R3				
2617	071074	005201			INC R1				
2618	071076				END ;OF FOR CSRNO				
	071076	062704	000002						
	071102	020427	000016					ADD #2,R4	
	071106	003714						CMP R4,#16	
	071110							BLE B203	
2619	071110				END WHODUNIT			E203:::~::~	
	071110							E202:::~::~	
2620	071110				IF SUCCESS IS TRUE				
	071110	005737	002424					TST SUCCESS	
	071114	001402						BEQ L1032	
2621	071116	110137	114717		MOVB R1,MSG057+1				
2622	071122				END ;OF IF SUCCESS				
	071122							L1032:::~::~	
2623	071122				TYPE MSG057				
	071122	104401	114716		TYPEIT ,MSG057				
					.DSABL CRF				
2624	071126	112737	000077	114717	MOVB #'?,MSG057+1				
2625	071134				POP R4,R3,R2,R1,CSRNO				
	071134	012604						MOV (SP)+,R4	
	071136	012603						MOV (SP)+,R3	
	071140	012602						MOV (SP)+,R2	
	071142	012601						MOV (SP)+,R1	
	071144	012637	002256					MOV (SP)+,CSRNO	
2626	071150	000207			RETURN				

```

2629 071152 012737 177777 002424 ADD..0: SET SUCCESS MOV #-1,SUCCESS
      071152 000207 RETURN
2630 071160 032737 000004 002040 ADD..1: IF #BIT2 OFF.IN ADDRESS THEN LET SUCCESS := ONES
2631 071162 032737 000004 002040 BIT #BIT2,ADDRESS
      071170 001003 BNE L1033
      071172 013737 002726 002424 MOV ONES,SUCCESS
      071200 L1033:::
2632 071200 000207 RETURN
2633 071202 032737 000010 002040 ADD..2: IF #BIT3 OFF.IN ADDRESS AND #BIT2 OFF.IN ADDRESS THEN LET SUCCESS := ONES
      071210 001007 BIT #BIT3,ADDRESS
      071212 032737 000004 002040 BNE L1034
      071220 001003 BIT #BIT2,ADDRESS
      071222 013737 002726 002424 BNE L1034
      071230 MOV ONES,SUCCESS
      L1034:::
2634 071230 000207 RETURN
2635 071232 032737 000010 002040 ADD..3: IF #BIT3 SET.IN ADDRESS AND #BIT2 OFF.IN ADDRESS THEN LET SUCCESS := ONES
      071240 001407 BIT #BIT3,ADDRESS
      071242 032737 000004 002040 BEQ L1035
      071250 001003 BIT #BIT2,ADDRESS
      071252 013737 002726 002424 BNE L1035
      071260 MOV ONES,SUCCESS
      L1035:::
2636 071260 000207 RETURN
2637 071262 000207 ADD..4: RETURN
2638 071264 032737 000004 002040 ADD..5: IF #BIT2 SET.IN ADDRESS THEN LET SUCCESS := ONES
      071272 001403 BIT #BIT2,ADL .SS
      071274 013737 002726 002424 BEQ L1036
      071302 MOV ONES,SUCCESS
      L1036:::
2639 071302 000207 RETURN
2640 071304 032737 000010 002040 ADD..6: IF #BIT3 OFF.IN ADDRESS AND #BIT2 SET.IN ADDRESS THEN LET SUCCESS := ONES
      071312 001007 BIT #BIT3,ADDRESS
      071314 032737 000004 002040 BNE L1037
      071322 001403 BIT #BIT2,ADDRESS
      071324 013737 002726 002424 BEQ L1037
      071332 MOV ONES,SUCCESS
      L1037:::
2641 071332 000207 RETURN
2642 071334 032737 000010 002040 ADD..7: IF #BIT3 SET.IN ADDRESS AND #BIT2 SET.IN ADDRESS THEN LET SUCCESS := ONES
      071342 001407 BIT #BIT3,ADDRESS
      071344 032737 000004 002040 BEQ L1040
      071352 001403 BIT #BIT2,ADDRESS
      071354 013737 002726 002424 BEQ L1040
      071362 MOV ONES,SUCCESS
      L1040:::
2643 071362 000207 RETURN
2644
2645 071364
      DETAIL: SUBTST <<SUBR DETAILED ERROR REPORT>>
      :*****
      :*SUBTEST SUBR DETAILED ERROR REPORT
      :*****
2646 071364 005237 002326 INC DETFLAG
2647 071370 022737 000003 002326 CMP #3,DETFLAG
2648 071376 101465 BLOS 4$
2649 071400 022737 000002 002326 CMP #2,DETFLAG
  
```

SUBR DETAILED ERROR REPORT

2650	071406	001435		BEQ	2\$		
2651	071410			PUSH	HEADER,MUT		
	071410	013746	002724				MOV HEADER,-(SP)
	071414	013746	002116				MOV MUT,-(SP)
2652	071420			SET	HEADER		
	071420	012737	177777			002724	MOV #-1,HEADER
2653	071426	005037	002116	CLR	MUT		
2654	071432	010037	002306	MOV	R0,DETRO		
2655	071436	012700	002310	MOV	#DETR1,R0		
2656	071442	010120		MOV	R1,(R0)+		
2657	071444	010220		MOV	R2,(R0)+		
2658	071446	010320		MOV	R3,(R0)+		
2659	071450	010420		MOV	R4,(R0)+		
2660	071452	010520		MOV	R5,(R0)+		
2661	071454	013720	002030	MOV	ERRSP,(R0)+		
2662	071460	013720	002034	MOV	ERRPSW,(R0)+		
2663	071464	013700	002306	MOV	DETRO,R0		
2664	071470			SET	NOERROR		
	071470	012737	177777			002530	MOV #-1,NOERROR
2665	071476	104013		ERROR	+13		
2666	071500	000415		BR	1\$		
2667	071502			PUSH	HEADER,MUT		
	071502	013746	002724				MOV HEADER,-(SP)
	071506	013746	002116				MOV MUT,-(SP)
2668	071512			SET	HEADER		
	071512	012737	177777			002724	MOV #-1,HEADER
2669	071520	005037	002116	CLR	MUT		
2670	071524			SET	NOERROR		
	071524	012737	177777			002530	MOV #-1,NOERROR
2671	071532	104031		ERROR	+31		
2672	071534			POP	MUT,HEADER		
	071534	012637	002116				MOV (SP)+,MUT
	071540	012637	002124				MOV (SP)+,HEADER
2673				;WARNING RECURSIVE			
2674	071544	004737	071364	CALL	DETAIL		
2675	071550	000207		RETURN			


```

2678                                     :SIMULATE CONTROL 'T''
2679 071552 004737 073404      4S:   CALL      CONTT                :DISPLAY 'DISPLAY' INFO
2680
2681                                     :TYPE CONTENTS OF ALL CSR'S
2682 071556                                     PUSH     CSR,CSR+2,CSRNO,R1
      071556 013746 002144                                     MOV (SR,-(SP)
      071562 013746 002146                                     MOV (SR+2,-(SP)
      071566 013746 002256                                     MOV (SRNO,-(SP)
      071572 010146                                     MOV R1,-(SP)
2683 071574                                     TYPE     MSG058
      071574 104401 114722      TYPEIT    ,MSG058
      .DSABL CRF
      TYPE     $CRLF
      TYPEIT    , $CRLF
      .DSABL CRF
      MOV      MKCSRS,R1
      BEGIN DUMPCSRLOOP
                                     B204::::::::::
                                     CLR CSRNO
                                     B205::::::::::
      ASLB     R1
      ON.ERROR
                                     BCC L1041
      READCSR
      TYPOCT   (SR
      MOV      CSR,-(SP)      ;;SAVE CSR FOR TYPEOUT
      TYPOC
      .DSABL CRF      ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
      TYPE     MSG018      :2 SPACES
      TYPEIT    ,MSG018
      .DSABL CRF
      TYPOCT   (CSR+2
      MOV      CSR+2,-(SP)  ;;SAVE CSR+2 FOR TYPEOUT
      TYPOC
      .DSABL CRF      ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
      TYPE     MSG018      :2 SPACES
      TYPEIT    ,MSG018
      .DSABL CRF
      END ;OF ON.ERROR
                                     L1041::::::::::
      IFB R1 EQ #0 THEN LEAVE DUMPCSRLOOP
      TSTB R1
      BEQ E204
      END ;OF FOR CSRNO
      ADD #4,CSRNO
      CMP (SRNO,#34
      BLE B205
      E205::::::::::
      END DUMPCSRLOOP
      E204::::::::::
      POP      R1,CSRNO,CSR+2,CSR
      MOV (SP)+,R1
      MOV (SP)+,CSRNO
      MOV (SP)+,CSR+2
      MOV (SP)+,CSR

```

```

2702                                     ;TYPE STACKS
2703 071706                               PUSH   RO,R1
      071706 010046
      071710 010146
                                     MOV RO,-(SP)
                                     MOV R1,-(SP)

2704
2705
2706 071712                               ;TYPE KERNEL STACK
      071712 104401 115760             TYPE   MSG08B           ;KERNEL STACK
                                     TYPEIT ,MSG08B
                                     .DSABL CRF
MOV   KSTACK,R1
SUB   #2,R1
FOR   RO : SP TO R1 BY #2
                                     MOV SP,RO
                                     B206:::

2710 071730                               TYPE   $CRLF
      071730 104401 003010             TYPEIT ,CRLF
                                     .DSABL CRF
                                     TYPOCT RO
MOV   RO,-(SP)           ;;SAVE RO FOR TYPEOUT
TYPOC                               ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
.DSABL CRF
TYPE   MSG018           ;2 SPACES
TYPEIT ,MSG018
.DSABL CRF
TYPOCT (RO)
MOV   (RO),-(SP)       ;;SAVE (RO) FOR TYPEOUT
TYPOC                               ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
.DSABL CRF
END ;OF FOR RO
                                     ADD #2,RO
                                     CMP RO,R1
                                     BLE B206
                                     E206:::

2714 071750                               ;TYPE SUPERVISOR STACK
      071750 062700 000002 177776     BIC   #BIT13!BIT12,PSW ;SET PREVIOUS MODE TO SUPERVISOR
      071754 020001 177776           BIS   #BIT12,PSW
      071756 003764
      071760
                                     MFPJ SSP
                                     POP   RO
                                     MOV (SP)+,RO

2721 072000                               TYPE   MSG089           ;SUPERVISOR STACK
      072000 104401 115776             TYPEIT ,MSG089
                                     .DSABL CRF
IF RO LT #SUPSTK
                                     CMP RO,#SUPSTK
                                     BGE L1042

2722 072004                               FOR RO := RO TO #SUPSTK-2 BY #2
      072004 020027 000740
      072010 002016
2723 072012
      072012 104401 003010
2724 072012
      072012 104401 003010
                                     TYPE   $CRLF
                                     TYPEIT ,CRLF
                                     .DSABL CRF
                                     TYPOCT RO
MOV   RO,-(SP)           ;;SAVE RO FOR TYPEOUT
TYPOC                               ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
.DSABL CRF
TYPE   MSG018           ;2 SPACES
TYPEIT ,MSG018
2725 072016
      072016 010046
      072020 104402
2726 072022
      072022 104401 112161

```


2747 072136
072136
2748 072136 104401 003010
072136
2749 072142 005037 002326
2750 072146
072146 012601
072150 012600
2751 072152 000207

END ;OF IF RO
TYPE \$CRLF
TYPEIT .SCLF
.DSABL CRF
CLR DETFLAG
POP R1,RO
RETURN

0045:.....

MOV (SP),R1
MOV (SP),RO

072322	020027	000006		
072326	003722			
072330				
0784 072330			POP	CONTRL,R1,R0
072330	012637	177746		
072334	012601			
072336	012600			
0785 072340	162737	000001	002574	SUB #1,HUNGTIME
0786 072346	000207			RETURN

CMP R0,#6
BLE B211
E211:::~::~
MOV (SP),,CONTR
MOV (SP),,R1
MOV (SP),,R0
;CARRY IS ERROR FLAG ON RETURN

2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803
2804
2805
2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835
2836
2837
2838
2839
2840
2841
2842
2843
2844
2845

.SBTTL ROUTINE BINARY TO OCTAL (ASCII) AND TYPE

```

.....
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
OCTAL (ASCII) NUMBER AND TYPE IT.
*STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS   N              ;;CALL FOR TYPEOUT
*   .BYTE   N              ;;N 1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE   M              ;;M=1 OR 0
*                               ;;1-TYPE LEADING ZEROS
*                               ;;0-SUPPRESS LEADING ZEROS
*
*STYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*STYPOS OR $TYPOC
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON   N              ;;CALL FOR TYPEOUT
*
*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC   N              ;;CALL FOR TYPEOUT
*
*STYPOS: MOV     @ (SP),-(SP)  ;;PICKUP THE MODE
*        MOVVB  1(SP), $OFILL ;;LOAD ZERO FILL SWITCH
*        MOVVB  (SP)+, $OMODE+1 ;;NUMBER OF DIGITS TO TYPE
*        ADD    #2, (SP)      ;;ADJUST RETURN ADDRESS
*        BR     $TYPON
*STYPOC: MOVVB  #1, $OFILL    ;;SET THE ZERO FILL SWITCH
*        MOVVB  #6, $OMODE+1  ;;SET FOR SIX(6) DIGITS
*STYPON: MOVVB  #5, $OCNT     ;;SET THE ITERATION COUNT
*        MOV    R3,-(SP)      ;;SAVE R3
*        MOV    R4,-(SP)      ;;SAVE R4
*        MOV    R5,-(SP)      ;;SAVE R5
*        MOVVB  $OMODE+1, R4  ;;GET THE NUMBER OF DIGITS TO TYPE
*        NEG    R4
*        ADD    #6, R4        ;;SUBTRACT IT FOR MAX. ALLOWED
*        MOV    R4, $OMODE    ;;SAVE IT FOR USE
*        MOVVB  $OFILL, R4    ;;GET THE ZERO FILL SWITCH
*        MOV    12(SP), R5    ;;PICKUP THE INPUT NUMBER
*        CLR    R3           ;;CLEAR THE OUTPUT WORD
*1$:     ROL    R5           ;;ROTATE MSB INTO 'C'
*        BR    3$           ;;GO DO MSB
*2$:     ROL    R5           ;;FORM THIS DIGIT
*        ROL    R5
*        ROL    R5
*        MOV    R5, R3
*3$:     ROL    R3           ;;GET LSB OF THIS DIGIT
*        DECB  $OMODE        ;;TYPE THIS DIGIT?
*        BPL   6$           ;;BR IF NO
*        BIC   #177770, R3   ;;GET RID OF JUNK
*        BNE   4$           ;;TEST FOR 0
*        TST  R4           ;;SUPPRESS THIS 0?
*        BEQ  5$           ;;BR IF YES
*4$:     INC   R4           ;;DON'T SUPPRESS ANYMORE 0'S

```

017646 000000
116637 000001 072573
112637 072575
062716 000002
000406
112737 000001 072573
112737 000006 072575
112737 000005 072572
010346
072420 010446
010546
113704 072575
005404
062704 000006
110437 072574
113704 072573
016605 000012
005003
072454 006105 1\$:
072456 000404
072460 006105 2\$:
006105
006105
010503
072470 006103 3\$:
105337 072574
100016
042703 177770
001002
005704
001403
005204 4\$:

2846	072514	052703	000060		BIS	#'0,R3	::MAKE THIS DIGIT ASCII
2847	072520	052703	000040	5\$:	BIS	#' ,R3	::MAKE ASCII IF NOT ALREADY
2848	072524	110337	072570		MOVB	R3,R5	::SAVE FOR TYPING
2849	072530				TYPE	8\$::GO TYPE THIS DIGIT
	072530	104401	072570		TYPEIT	.8\$	
					.DSABL	(RF	
2850	072534	105337	072572	6\$:	DECB	\$CNT	::COUNT BY 1
2851	072540	003347			BGT	2\$::BR IF MORE 10 DO
2852	072542	002402			BLT	7\$::BR IF DONE
2853	072544	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
2854	072546	000744			BR	2\$::GO DO THE LAST DIGIT
2855	072550	012605		7\$:	MOV	(SP)+,R5	::RESTORE R5
2856	072552	012604			MOV	(SP)+,R4	::RESTORE R4
2857	072554	012603			MOV	(SP)+,R3	::RESTORE R3
2858	072556	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
2859	072564	012616			MOV	(SP)+,(SP)	
2860	072566	000002			RTI		::RETURN
2861	072570	000		8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
2862	072571	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
2863	072572	000		\$CNT:	.BYTE	0	::OCTAL DIGIT COUNTER
2864	072573	000		\$OFILL:	.BYTF	0	::ZERO FILL SWITCH
2865	072574	000000		\$OMODF:	.WORD	0	::NUMBER OF DIGITS TO TYPE


```

2867          .SBTTL ROUTINE CONVERT BINARY TO DECIMAL AND TYPE
2868          .....
2869          *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
2870          *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
2871          *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
2872          *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
2873          *REPLACED WITH SPACES.
2874          *CALL:
2875          *      MOV      NUM,-(SP)          ;;PUT THE BINARY NUMBER ON THE STACK
2876          *      TYPDS   TYPDS             ;;GO TO THE ROUTINE
2877          $TYPDS: PUSH  R0,R1,R2,R3,R5
                                     MOV R0,-(SP)
                                     MOV R1,-(SP)
                                     MOV R2,-(SP)
                                     MOV R3,-(SP)
                                     MOV R5,-(SP)
2878          072576 010046
2879          072600 010146
2880          072602 010246
2881          072604 010346
2882          072606 010546
2883          072610 012746 020200      MOV      #20200,-(SP)          ;;SET BLANK SWITCH AND SIGN
2884          072614 016605 000020      MOV      20(SP),R5          ;;GET THE INPUT NUMBER
2885          072620 100004              BPL          ;;BR IF INPUT IS POS.
2886          072622 005405              NEG      R5                ;;MAKE THE BINARY NUMBER POS.
2887          072624 112766 000055 000001  MOVB     #'-,1(SP)          ;;MAKE THE ASCII NUMBER NEG.
2888          072632 005000              CLR      R0                ;;ZERO THE CONSTANTS INDEX
2889          072634 012703 073012      MOV      #$DBLK,R3         ;;SETUP THE OUTPUT POINTER
2890          072640 112723 000040      MOVB     #'',(R3)+         ;;SET THE FIRST CHARACTER TO A BLANK
2891          072644 005002              CLR      R2                ;;CLEAR THE BCD NUMBER
2892          072646 016001 073002      MOV      $DTBL(R0),R1     ;;GET THE CONSTANT
2893          072652 160105              SUB      R1,R5             ;;FORM THIS BCD DIGIT
2894          072654 002402              BLT      4$                ;;BR IF DONE
2895          072656 005202              INC      R2                ;;INCREASE THE BCD DIGIT BY 1
2896          072660 000774              BR       3$                ;;
2897          072662 060105              ADD      R1,R5             ;;ADD BACK THE CONSTANT
2898          072664 005702              TST      R2                ;;CHECK IF BCD DIGIT=0
2899          072666 001002              BNE      5$                ;;FALL THROUGH IF 0
2900          072670 105716              TSTB    (SP)              ;;STILL DOING LEADING 0'S?
2901          072672 100407              BMI      7$                ;;BR IF YES
2902          072674 106316              ASLB    (SP)              ;;MSD?
2903          072676 103003              BCC      6$                ;;BR IF NO
2904          072700 116663 000001 177777  MOVB     1(SP),-1(R3)      ;;YES--SET THE SIGN
2905          072706 052702 000060      BIS      #'0,R2           ;;MAKE THE BCD DIGIT ASCII
2906          072712 052702 000040      BIS      #' ,R2           ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
2907          072716 110223              MOVB     R2,(R3)+         ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
2908          072720 005720              TST      (R0)+           ;;JUST INCREMENTING
2909          072722 020027 000010      CMP      R0,#10           ;;CHECK THE TABLE INDEX
2910          072726 002746              BLT      2$                ;;GO DO THE NEXT DIGIT
2911          072730 003002              BGT      8$                ;;GO TO EXIT
2912          072732 010502              MOV      R5,R2           ;;GET THE LSD
2913          072734 000764              BR       6$                ;;GO CHANGE TO ASCII
2914          072736 105726              8$: TSTB    (SP)+         ;;WAS THE LSD THE FIRST NON-ZERO?
2915          072740 100003              BPL      9$                ;;BR IF NO
2916          072742 116663 177777 177776  MOVB     -1(SP),-2(R3)    ;;YES--SET THE SIGN FOR TYPING
2917          072750 105013              9$: CLRB   (R3)           ;;SET THE TERMINATOR
2918          072752              POP      R5,R3,R2,R1,R0
                                     MOV (SP)+,R5
                                     MOV (SP)+,R3
                                     MOV (SP)+,R2
                                     MOV (SP)+,R1
                                     MOV (SP)+,R0

```



```

ROUTINE TTY INPUT
2924 .SBTTL ROUTINE TTY INPUT
2925 :*****
2926 :*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
2927 :*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
2928 :*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
2929 :*WHEN OPERATING IN TTY FLAG MODE.
2930 .ENABLE LSB
2931 $CKSWR: IF CPUBIT NE #MASTER ;SLAVES DON'T GET KEYBOARDS!
073022 023727 002114 000020 CMP CPUBIT,#MASTER
073030 001401 BEQ L1052
2932 073032 000002 RTI
2933 073034 END ;OF IF CPUBIT
073034 L1052:::
2934 073034 105777 107732 TSTB @STKS ;:CHAR THERE?
2935 073040 100125 BPL 12$ ;:IF NO, DON'T WAIT AROUND
2936 073042 117746 107726 MOVB @STKB,-(SP) ;:SAVE THE CHAR
2937 073046 042716 177600 BIC #^C177,(SP) ;:STRIP-OFF THE ASCII
2938 073052 022716 000006 CONTS1: CMP #6,(SP) ;:IS IT CONTROL F?
2939 073056 001002 BNE 1$ ;:NO SKIP
2940 073060 004737 043774 CALL FIELDSERVICE
2941 073064 022716 000024 1$: CMP #24,(SP) ;:IS IT CONTROL T?
2942 073070 001002 BNE 16$ ;:NO - SKIP
2943 073072 004737 073404 CALL CONTT ;:YES - CALL CONTROL T ROUTINE
2944 073076 022716 000003 16$: CMP #3,(SP) ;:IS IT CONTROL C?
2945 073102 001451 BEQ 5$ ;:YES EXIT *****NOTE***** STACK IS SCREWED UP.
2946 073104 022716 000004 CMP #4,(SP) ;:IS IT CONTROL D?
2947 073110 001002 BNE 2$ ;:NO - SKIP
2948 073112 000137 075774 CONTP: JMP @NO.ODT ;:YES - GO TO ODT
2949 073116 022716 000023 2$: CMP #23,(SP) ;:IS IT CONTROL S?
2950 073122 001002 BNE 6$ ;:NO - SKIP
2951 073124 004737 073544 CALL CONTS ;:YES - CALL CONTROL S ROUTINE
2952 073130 022737 000176 002766 6$: CMP #SWREG,SWR ;:IS THE SOFT-SWR SELECTED?
2953 073136 001067 BNE CKEND ;:BRANCH IF NO
2954 073140 022726 000007 CMP #7,(SP)+ ;:IS IT A CONTROL G?
2955 073144 001064 BNE CKEND ;:NO, RETURN TO USER
2956 073146 005737 002066 TST $AUTO ;:ARE WE RUNNING IN AUTO-MODE?
2957 073152 001061 BNE CKEND ;:BRANCH IF YES
2958 073154 104401 074236 TYPE $CNTLG ;:ECHO THE CONTROL-G (^G)
TYPEIT , $CNTLG
.DSABL CRF
2959 073160 $GTSWR: TYPE $MSWR ;:TYPE CURRENT CONTENTS
073160 104401 074243 TYPEIT , $MSWR
.DSABL CRF
2960 073164 TYPOCT @SWR ;:OF THE SWR
073164 017746 107576 MOV @SWR,-(SP) ;:SAVE @SWR FOR TYPEOUT
073170 104402 TYPOC ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
.DSABL CRF
2961 073172 TYPE $MNEW ;:PROMPT FOR NEW SWR
073172 104401 074254 TYPEIT , $MNEW
.DSABL CRF
2962 073176 005046 3$: CLR -(SP) ;:CLEAR COUNTER
2963 073200 005046 CLR -(SP) ;:THE NEW SWR
2964 073202 105777 107564 4$: TSTB @STKS ;:CHAR THERE?
2965 073206 100375 BPL 4$ ;:IF NOT TRY AGAIN
2966 073210 117746 107560 MOVB @STKB,-(SP) ;:PICK UP CHAR
2967 073214 042716 177600 BIC #^C177,(SP) ;:MAKE IT 7-BIT ASCII
2968 073220 021627 000003 CMP (SP),#3 ;:IS IT A CONTROL-C?

```

2969	073224	00'006			BNE	7\$::BRANCH IF NOT
2970	073226			5\$:	TYPE	\$CNTLC	::YES, ECHO CONTROL-C (^C)
	073226	104401	074224		TYPEIT	,\$CNTLC	
					.DSABL	CRF	
2971	073232	062706	000006		ADD	#6,SP	::CLEAN UP STACK
2972	073236	000137	043416		JMP	BOOT	::CONTROL-C RESTART
2973	073242	021627	000025	7\$:	CMP	(SP),#25	::IS IT A CONTROL-U?
2974	073246	001005			BNE	9\$::BRANCH IF NOT
2975	073250				TYPE	\$CNTLU	::YES, ECHO CONTROL-U (^U)
	073250	104401	074231		TYPEIT	,\$CNTLU	
					.DSABL	CRF	
2976	073254	062706	000006	8\$:	ADD	#6,SP	::IGNORE PREVIOUS INPUT
2977	073260	000746			BR	3\$::LET'S TRY IT AGAIN
2978	073262	021627	000015	9\$:	CMP	(SP),#15	::IS IT A <CR>?
2979	073266	001016			BNE	13\$::BRANCH IF NO
2980	073270	005766	000004		TST	4(SP)	::YES, IS IT THE FIRST CHAR?
2981	073274	001403			BEQ	10\$::BRANCH IF YES
2982	073276	016677	000002	107462	MOV	2(SP),@SWR	::SAVE NEW SWR
2983	073304	062706	000006	10\$:	ADD	#6,SP	::CLEAR UP STACK
2984	073310				TYPE	\$CRLF	::ECHO <CR> AND <LF>
	073310	104401	003010		TYPEIT	,\$CRLF	
					.DSABL	CRF	
2985	073314	000002		12\$:	RTI		::RETURN
2986	073316	062706	000002	CKEND:	ADD	#2,SP	::FIX STACK
2987	073322	000002			RTI		::RETURN
2988	073324	004737	057076	13\$:	CALL	\$TYPEC	::ECHO CHAR
2989	073330	021627	000060		CMP	(SP),#60	::CHAR < 0?
2990	073334	002420			BLT	15\$::BRANCH IF YES
2991	073336	021627	000067		CMP	(SP),#67	::CHAR > 7?
2992	073342	003015			BGT	15\$::BRANCH IF YES
2993	073344	042726	000060		BIC	#60,(SP)+	::STRIP-OFF ASCII
2994	073350	005766	000002		TST	2(SP)	::IS THIS THE FIRST CHAR
2995	073354	001403			BEQ	14\$::BRANCH IF YES
2996	073356	006316			ASL	(SP)	::NO, SHIFT PRESENT
2997	073360	006316			ASL	(SP)	:: CHAR OVER TO MAKE
2998	073362	006316			ASL	(SP)	:: ROOM FOR NEW ONE.
2999	073364	005266	000002	14\$:	INC	2(SP)	::KEEP COUNT OF CHAR
3000	073370	056616	177776		BIS	-2(SP),(SP)	::SET IN NEW CHAR
3001	073374	000702			BR	4\$::GET THE NEXT ONE
3002	073376			15\$:	TYPE	\$QUES	::TYPE ?<CR><LF>
	073376	104401	003007		TYPEIT	,\$QUES	
					.DSABL	CRF	
3003	073402	000724			BR	8\$::SIMULATE CONTROL-U
3004					.DSABL	LSB	

3007 073404

CONT: SUBST <<CONTROL T>>

*SUBTEST CONTROL T

3008 073404

073404 010046

PUSH R0

MOV R0,-(SP)

3009 073406

073406 104401 003010

TYPE \$CRLF
TYPEIT \$CRLF
.DSABL CRF

IF MDISPLAY LT #0 AND MDISPLAY GT #-256.

3010 073412

073412 005737 002676
073416 002015
073420 023727 002676 177400
073426 003411

TST MDISPLAY
BGE L1053
CMP MDISPLAY,#-256.
BLE L1053

3011

;WE ARE IN MULTIPROCESSOR MODE

3012 073430

073430 013700 002676

MOV MDISPLAY,R0

3013 073434

073434 005400

NEG R0

3014 073436

073436 104401 116256

TYPE MSG100
TYPEIT ,MSG100
.DSABL CRF

;MULTIPROCESSOR TEST #

3015 073442

073442 010046
073444 104403
073446 003
073447 000

TYPOCS R0,,3

;TYPE 3 DIGITS

MOV R0,-(SP)

::SAVE R0 FOR TYPEOUT

TYPOS

::GO TYPE--OCTAL ASCII

.BYTE 3

::TYPE 3 DIGIT(S)

.BYTE 0

::SUPPRESS LEADING ZEROS

.DSABL CRF

ELSE

3016 073450

073450 000433

BR L1054

3017 073452

073452 005737 002134

IF RLFLAG IS TRUE

L1053:*****

3018 073460

073460 104401 116046

TYPE MSG092

;RELOCATED

TYPEIT ,MSG092

.DSABL CRF

END ;OF IF RLFLAG

TST RLFLAG
BEQ L1055

3019 073464

073464

3020 073464

073464 104401 116062

TYPE MSG093

;BANK=

TYPEIT ,MSG093

.DSABL CRF

3021 073470

073470 013746 002106

TYPOCS BANK,,3

;TYPE 3 DIGITS

MOV BANK,-(SP)

::SAVE BANK FOR TYPEOUT

TYPOS

::GO TYPE--OCTAL ASCII

.BYTE 3

::TYPE 3 DIGIT(S)

.BYTE 0

::SUPPRESS LEADING ZEROS

.DSABL CRF

3022 073500

073500 104401 116070

TYPE MSG094

;MAR-

TYPEIT ,MSG094

.DSABL CRF

3023 073504

073504 013700 177750

MOV MAINT,R0

3024 073510

073510 006200

ASR R0

3025 073512

073512 042700 177770

BIC #^C7,R0

3026 073516

073516 010046

TYPOCS R0,,1

;TYPE 1 DIGIT

MOV R0,-(SP)

::SAVE R0 FOR TYPEOUT

TYPOS

::GO TYPE--OCTAL ASCII

.BYTE 1

::TYPE 1 DIGIT(S)

.BYTE 0

::SUPPRESS LEADING ZEROS

073522 001

073523 000

```

3027 073524      .DSABL CRF
      073524 104401 116077      TYPE MSG095          ;PAT-
      .DSABL CRF
3028 073530      TYPOCS          REALPAT,,2          ;TYPE 2 DIGITS
      073530 013746 002366      MOV REALPAT,-(SP)    ;;SAVE REALPAT FOR TYPEOUT
      073534 104403          TYPOS          ;;GO TYPE--OCTAL ASCII
      073536          .BYTE 2          ;;TYPE 2 DIGIT(S)
      073537          .BYTE 0          ;;SUPPRESS LEADING ZEROS
      .DSABL CRF
3029 073540      END ;OF IF @DISPLAY
      073540
      073540          POP R0          L1054:::
3030 073540          RETURN          MOV (SP)+,R0
3031 073542 0012600
3032 073542 000207
3033 073544
CONTS: SUBST <<CONTROL S & CONTROL Q>>
*****
;*SUBTEST CONTROL S & CONTROL Q
*****
3034 073544      POP R0          ;GET RID OF RETURN ADDRESS FROM STACK
      073544 012600          MOV (SP)+,R0
3035 073546 105777 107220
3036 073552 100375
3037 073554 117716 107214
3038 073560 042716 177600
3039 073564      IF (SP) EQ #21          ;IF IT IS A CONTROL Q
      073564 021627 000021          CMP (SP),#21
      073570 001003          BNE L1056
3040 073572 000137 073052          JMP CONTS1
3041 073576      ELSE
      073576 000401
      073600          BR L1057
3042 073600 000762          L1056:::
3043 073602          END ;OF IF (SP)          L1057:::
      073602

```

```

3045 .....
3046 *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
3047 *CALL:
3048 *      RDCHR                ;; INPUT A SINGLE CHARACTER FROM THE TTY
3049 *      RETURN HERE         ;; CHARACTER IS ON THE STACK
3050 *                          ;; WITH PARITY BIT STRIPPED OFF
3051 *
3052 *
3053 073602 011646          $RDCHR: MOV      (SP),-(SP)        ;; PUSH DOWN THE PC
3054 073604 016666 000004 000002  MOV      4(SP),2(SP)    ;; SAVE THE PS
3055 073612 105777 107154 1$:  TSTB     @$TKS          ;; WAIT FOR
3056 073616 100375          BPL      1$             ;; A CHARACTER
3057 073620 117766 107150 000004  MOVB    @$TKB,4(SP)     ;; READ THE TTY
3058 073626 042766 177600 000004  BIC     #'C<177>,4(SP) ;; GET RID OF JUNK IF ANY
3059 073634 026627 000004 000023  CMP     4(SP),#23      ;; IS IT A CONTROL-S?
3060 073642 001013          BNE     3$             ;; BRANCH IF NO
3061 073644 105777 107122 2$:  TSTB     @$TKS          ;; WAIT FOR A CHARACTER
3062 073650 100375          BPL      2$             ;; LOOP UNTIL ITS THERE
3063 073652 117746 107116  MOVB    @$TKB,-(SP)     ;; GET CHARACTER
3064 073656 042716 177600  BIC     #'C177,(SP)    ;; MAKE IT 7-BIT ASCII
3065 073662 022627 000021  CMP     (SP)+,#21      ;; IS IT A CONTROL-Q?
3066 073666 001366          BNE     2$             ;; IF NOT DISCARD IT
3067 073670 000750          BR      1$             ;; YES, RESUME
3068 073672 026627 000004 000140 3$:  CMP     4(SP),#140     ;; IS IT UPPER CASE?
3069 073700 002407          BLT     4$             ;; BRANCH IF YES
3070 073702 026627 000004 000175  CMP     4(SP),#175     ;; IS IT A SPECIAL CHAR?
3071 073710 003003          BGT     4$             ;; BRANCH IF YES
3072 073712 042766 000040 000004  BIC     #40,4(SP)      ;; MAKE IT UPPER CASE
3073 073720 000002 4$:  RTI                ;; GO BACK TO USER
3074 .....
3075 *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
3076 *CALL:
3077 *      RDLIN                ;; INPUT A STRING FROM THE TTY
3078 *      RETURN HERE         ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
3079 *                          ;; TERMINATOR WILL BE A BYTE OF ALL 0'S
3080 073722 010346          $RDLIN: MOV      R3,-(SP)        ;; SAVE R3
3081 073724 005046          CLR     -(SP)         ;; CLEAR THE RUBOUT KEY
3082 073726 012703 074200 1$:  MOV     #$TTYIN,R3     ;; GET ADDRESS
3083 073732 022703 074224 2$:  CMP     #$TTYIN+20.,R3 ;; BUFFER FULL?
3084 073736 101467          BLOS   8$             ;; BR IF YES
3085 073740 104411          RDCHR                ;; GO READ ONE CHARACTER FROM THE TTY
3086 073742 112613          MOVB   (SP)+(R3)      ;; GET CHARACTER
3087 073744 122713 000003  CMPB   #3,(R3)         ;; IS IT A CONTROL-C?
3088 073750 001006          BNE     3$             ;; BRANCH IF NO
3089 073752          TYPE   $CNTLC          ;; TYPE A CONTROL-C (^C)
3089 073752 104401 074224  TYPEIT  ,CNTLC
3089 073752          _DSABL  CRF
3090 073756 005726          TST    (SP)+          ;; CLEAN RUBOUT KEY OFF OF THE STACK
3091 073760 012603          MOV    (SP)+,R3       ;; RESTORE R3
3092 073762 000137 043416          JMP    BOOT           ;; GOTO CONTROL-C RESTART
3093 073766 122713 000177 3$:  CMPB   #177,(R3)      ;; IS IT A RUBOUT
3094 073772 001022          BNE     5$             ;; BR IF NO
3095 073774 005716          TST    (SP)           ;; IS THIS THE FIRST RUBOUT?
3096 073776 001007          BNE     4$             ;; BR IF NO
3097 074000 112737 000134 074176  MOVB   #'\\,10$       ;; TYPE A BACK SLASH
3098 074006          TYPE   10$
3098 074006 104401 074176  TYPEIT  ,10$

```

3099	074012	012716	177777		.DSABL	CRF			
3100	074016	005303		4\$:	MOV	#-1,(SP)	::SET THE RUBOUT KEY		
3101	074020	020327	074200		DEC	R3	::BACKUP BY ONE		
3102	074024	103434			CMP	R3,#STTYIN	::STACK EMPTY?		
3103	074026	111337	074176		BLO	8\$::BR IF YES		
3104	074032				MOVB	(R3),10\$::SETUP TO TYPEOUT THE DELETED CHAR.		
	074032	104401	074176		TYPE	10\$::GO TYPE		
	074032				TYPEIT	,10\$			
					.DSABL	CRF			
3105	074036	000735			BR	2\$::GO READ ANOTHER CHAR.		
3106	074040	005716		5\$:	TST	(SP)	::RUBOUT KEY SET?		
3107	074042	001406			BEQ	6\$::BR IF NO		
3108	074044	112737	000134	074176	MOVB	#'\,10\$::TYPE A BACK SLASH		
3109	074052				TYPE	10\$			
	074052	104401	074176		TYPEIT	,10\$			
					.DSABL	CRF			
3110	074056	005016			CLR	(SP)	::CLEAR THE RUBOUT KEY		
3111	074060	122713	000025	6\$:	CMPB	#25,(R3)	::IS CHARACTER A CTRL L?		
3112	074064	001003			BNE	7\$::BR IF NO		
3113	074066				TYPE	\$CNTLU	::TYPE A CONTROL 'U'		
	074066	104401	074231		TYPEIT	,CNTLU			
					.DSABL	CRF			
3114	074072	000715			BR	1\$::GO START OVER		
3115	074074	122713	000022	7\$:	CMPB	#22,(R3)	::IS CHARACTER A 'R'?		
3116	074100	001011			BNE	9\$::BRANCH IF NO		
3117	074102	105013			CLRB	(R3)	::CLEAR THE CHARACTER		
3118	074104				TYPE	\$CRLF	::TYPE A 'CR' & 'LF'		
	074104	104401	003010		TYPEIT	,CRLF			
					.DSABL	CRF			
3119	074110				TYPE	\$TTYIN	::TYPE THE INPUT STRING		
	074110	104401	074200		TYPEIT	,TTYIN			
					.DSABL	CRF			
3120	074114	000706			BR	2\$::GO PICKUP ANOTHER CHACTER		
3121	074116			8\$:	TYPE	\$QUES	::TYPE A '?'		
	074116	104401	003007		TYPEIT	,QUES			
					.DSABL	CRF			
3122	074122	000701			BR	1\$::CLEAR THE BUFFER AND LOOP		
3123	074124	111337	074176	9\$:	MOVB	(R3),10\$::ECHO THE CHARACTER		
3124	074130				TYPE	10\$			
	074130	104401	074176		TYPEIT	,10\$			
					.DSABL	CRF			
3125	074134	122723	000015		CMPB	#15,(R3)+	::CHECK FOR RETURN		
3126	074140	001274			BNE	2\$::LOOP IF NOT RETURN		
3127	074142	105063	177777		CLRB	-1(R3)	::CLEAR RETURN (THE 15)		
3128	074146				TYPE	\$LF	::TYPE A LINE FEED		
	074146	104401	003011		TYPEIT	,LF			
					.DSABL	CRF			
3129	074152	005726			TST	(SP)+	::CLEAN RUBOUT KEY FROM THE STACK		
3130	074154	012603			MOV	(SP)+,R3	::RESTORE R3		
3131	074156	011646			MOV	(SP),-(SP)	::ADJUST THE STACK AND PUT ADDRESS OF THE		
3132	074160	016666	000004	000002	MOV	4(SP),2(SP)	::FIRST ASCII CHARACTER ON IT		
3133	074166	012766	074200	000004	MOV	#STTYIN,4(SP)			
3134	074174	000002			RTI		::RETURN		
3135	074176	000		10\$:	.BYTE	0	::STORAGE FOR ASCII CHAR. TO TYPE		
3136	074177	000			.BYTE	0	::TERMINATOR		
3137	074200	000024			\$TTYIN:	.REPT	20.	::RESERVE SIZE BYTES FOR TTY INPUT	
3140	074224	136	103	015	\$CNTLC:	.ASCIIZ	/'C/(<15><12>	::CONTROL 'C'	

3141	074227	012	000	015	SCNTLU: .ASCIZ /^U/<15><12>	::CONTROL 'U'
	074231	136	125			
	074234	012	000			
3142	074236	136	107	015	SCNTLG: .ASCIZ /^G/<15><12>	::CONTROL 'G'
	074241	012	000			
3143	074243	015	012	123	SMSWR: .ASCIZ <15><12>/SWR /	
	074246	127	122	040		
	074251	075	040	000		
3144	074254	040	040	116	SMNEW: .ASCIZ / NEW : /	
	074257	105	127	040		
	074262	075	040	000		
3145					.EVEN	

```

3147          .SBTTL ROUTINE READ AN OCTAL NUMBER FROM THE TTY
3148          .....
3149          *THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
3150          *CHANGE IT TO BINARY.
3151          *THE INPUT CHARACTERS WILL BE CHECKED TO INSURE THEY ARE LEGAL
3152          *OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A '?' WILL BE TYPED
3153          *FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
3154          *THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
3155          *CALL:
3156          *
3157          *      RDOCT          ::READ AN OCTAL NUMBER
3158          *      RETURN HERE  ::LOW ORDER BITS ARE ON TOP OF THE STACK
3159          *                   ::HIGH ORDER BITS ARE IN $HI OCT
3159 074266 011646          $RDOCT: MOV      (SP),-(SP)  ::PROVIDE SPACE FOR THE
3160 074270 016666 000004 000002  MOV      4(SP),2(SP)  ::INPUT NUMBER
3161 074276          PUSH      R0,R1,R2
3162          *                   MOV R0,-(SP)
3163          *                   MOV R1,-(SP)
3164          *                   MOV R2,-(SP)
3162 074300 010046          1$:  RD IN          ::READ AN ASCII LINE
3163 074306 012600          MOV      (SP)+,R0      ::GET ADDRESS OF 1ST CHARACTER
3164 074310 010037 074414  MOV      R0,$$        ::AND SAVE IT
3165 074314 005001          CLR      R1            ::CLEAR DATA WORD
3166 074316 005002          CLR      R2
3167 074320 112046          2$:  MOVB     (R0)+,-(SP)  ::PICKUP THIS CHARACTER
3168 074322 001420          BEQ     3$            ::IF ZERO GET OUT
3169 074324 122716 000060  CMPB    #'0,(SP)      ::MAKE SURE THIS CHARACTER
3170 074330 003026          BGT     4$            ::IS AN OCTAL DIGIT
3171 074332 122716 000067  CMPB    #'7,(SP)
3172 074336 002423          BLT     4$
3173 074340 006301          ASL     R1            ::*2
3174 074342 006102          ROL     R2
3175 074344 006301          ASL     R1            ::*4
3176 074346 006102          ROL     R2
3177 074350 006301          ASL     R1            ::*8
3178 074352 006102          ROL     R2
3179 074354 042716 177770  BIC     #'C7,(SP)     ::STRIP THE ASCII JUNK
3180 074360 062601          ADD     (SP)+,R1      ::ADD IN THIS DIGIT
3181 074362 000756          BR      2$           ::LOOP
3182 074364 005726          3$:  TST      (SP)+      ::CLEAN TERMINATOR FROM STACK
3183 074366 010166 000012  MOV     R1,12(SP)     ::SAVE THE RESULT
3184 074372 010237 074434  MOV     R2,$HI OCT
3185 074376          POP      R2,R1,R0
3186          *                   MOV (SP)+,R2
3187          *                   MOV (SP)+,R1
3188          *                   MOV (SP)+,R0
3186 074400 012601          RTI
3187 074404 000002          4$:  TST      (SP)+      ::RETURN
3188 074410 105010          CLRB    (R0)         ::CLEAN PARTIAL FROM STACK
3189 074412          TYPE          ::SET A TERMINATOR
3190          *                   TYPE UP THRU THE BAD CHAR.
3190 074414 000000          5$:  .DSABL   CRF
3191 074416          .WORD    0
3192          *                   ;INPUT MUST BE A
3192 074422          TYPE     MSG062
3193          *                   ;N OCTAL
3193 074422 104401 115107  TYPEIT  ,MSG062
3194          *                   .DSABL   CRF
3195          *                   TYPE     MSG063
3196          *                   TYPEIT  ,MSG063

```

```

3193 074426          .DSABL CRF
      074426 104401 115120 TYPE MSG064          :NUMBER
                                TYPEIT ,MSG064
                                .DSABL CRF
3194 074432 000724   BR 1$          ::TRY AGAIN
3195 074434 000000   $*IOCT: .WORD 0          ::HIGH ORDER BITS GO HERE
3196          .SBTTL ROUTINE READ A DECIMAL NUMBER FROM THE TTY
3197
3198
3199
3200
3201
3202
3203
3204
3205
3206
3207
3208
3209
3210 074436 011646   $RDDEC: MOV (SP),-(SP)      ::PROVIDE SPACE FOR
3211 074440 016666 000004 000002 MOV 4(SP),2(SP)      ::THE INPUT NUMBER
3212 074446          PUSH R0,R1,R2
                                MOV R0,-(SP)
                                MOV R1,-(SP)
                                MOV R2,-(SP)
3213 074454 104412   1$: RDLIN          ::READ AN ASCII LINE
3214 074456 012600   MOV (SP)+,R0      ::ADDRESS OF 1ST CHAR.
3215 074460 010037 074604   MOV R0,6$      ::SAVE IN CASE OF BAD INPUT
3216 074464 005046   CLR -(SP)      ::CLEAR DATA WORD
3217 074466 005002   CLR R2          ::SIGN SET POSITIVE
3218 074470 122710 000055   CMPB #'-,(R0)    ::SEE IF A MINUS SIGN WAS TYPED
3219 074474 001001   BNE 2$          ::BR IF NO MINUS SIGN
3220 074476 112002   MOVB (R0)+,R2     ::SAVE FOR LATER USE
3221 074500 112001   2$: MOVB (R0)+,R1     ::PICKUP THIS CHARACTER
3222 074502 001424   BEQ 3$          ::GET OUT IF ZERO
3223 074504 122701 000060   CMPB #'0,R1     ::MAKE SURE THIS CHARACTER
3224 074510 003032   BGT 5$          ::IS A DIGIT BETWEEN 0 & 9
3225 074512 122701 000071   CMPB #'9,R1
3226 074516 002427   BLT 5$
3227 074520 032716 170000   BIT #'(7777),(SP) ::DON'T LET NUMBER GET TO BIG
3228 074524 001024   BNE 5$          ::BR IF NUMBER WOULD OVERFLOW
3229 074526 006316   ASL (SP)        ::*2
3230 074530 011646   MOV (SP),-(SP)  ::SAVE FOR LATER
3231 074532 006316   ASL (SP)        ::*4
3232 074534 006316   ASL (SP)        ::*8
3233 074536 062616   ADD (SP)+,(SP)  ::*10
3234 074540 102416   BVS 5$          ::OVERFLOW ISN'T ALLOWED
3235 074542 162701 000060   SUB #'0,R1      ::STRIP AWAY THE ASCII JUNK
3236 074546 060116   ADD R1,(SP)     ::ADD IN THIS DIGIT
3237 074550 102412   BVS 5$          ::OVERFLOW ISN'T ALLOWED
3238 074552 000752   BR 5$          ::LOOP
3239 074554 005702   3$: TST R2      ::CHECK IF NUMBER IS NEG
3240 074556 001401   BEQ 4$          ::BR IF NO
3241 074560 005416   NEG (SP)        ::YES--NEGATE THE NUMBER
3242 074562 012666 000010   4$: MOV (SP)+,12(SP) ::SAVE THE RESULT
3243 074566          POP R2,R1,R0

```


3255
3256
3257
3258
3259
3260
3261
3262
3263
3264
3265
3266
3267
3268
3269
3270
3271
3272
3273
3274
3275
3276
3277
3278
3279
3280
3281
3282
3283
3284
3285
3286
3287
3288
3289

074624
074624 010046
074626 010146
074630 010246
074632 010346
074634 010446
074636 010546
074640 016646 000022
074644 016646 000022
074650 016646 000022
074654 016646 000022
074660 000002
074662
074662 012666 000022
074666 012666 000022
074672 012666 000022
074676 012666 000022
074702 012605
074704 012604
074706 012603
074710 012602
074712 012601
074714 012600
074716 000002

```
.SBTTL ROUTINE SAVE AND RESTORE R0-R5
.....
*SAVE R0-R5
*CALL:
* SAVREG
*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
*
*TOP---(+16)
* +2---(+18)
* +4---R5
* +6---R4
* +8---R3
*+10---R2
*+12---R1
*+14---R0

$SAVREG:
PUSH R0,R1,R2,R3,R4,R5

MOV R0,-(SP)
MOV R1,-(SP)
MOV R2,-(SP)
MOV R3,-(SP)
MOV R4,-(SP)
MOV R5,-(SP)

MOV 22(SP),-(SP) ;;SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PS OF CALL
MOV 22(SP),-(SP) ;;SAVE PC OF CALL
RTI

*RESTORE R0-R5
*CALL:
* RESREG
$RESREG:
MOV (SP)+,22(SP) ;;RESTORE PC OF CALL
MOV (SP)+,22(SP) ;;RESTORE PS OF CALL
MOV (SP)+,22(SP) ;;RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP) ;;RESTORE PS OF MAIN FLOW
POP R5,R4,R3,R2,R1,R0

MOV (SP)+,R5
MOV (SP)+,R4
MOV (SP)+,R3
MOV (SP)+,R2
MOV (SP)+,R1
MOV (SP)+,R0

RTI
```

ROUTINE RANDOM NUMBER GENERATOR

```

3291 .SBTTL ROUTINE RANDOM NUMBER GENERATOR
3292
3293 *****
3294 :*THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
3295 :*WITH A RANGE OF 0 TO 2**(+33)-1.
3296 :*CALL:
3297 :* CALL $RAND ;:CALL THE ROUTINE
3298 :* RETURN ;:RETURN HERE THE RANDOM
3299 :* ;:NUMBER WILL BE IN
3300 :* ;:$HINUM,$LONUM
3301
3302 $RAND: PUSH R0,R1,R2
3303 074720 010046
3304 074722 010146 MOV R0,-(SP)
3305 074724 010246 MOV R1,-(SP)
3306 074726 013700 002716 MOV R2,-(SP)
3307 074728 013701 002714
3308 074730 012702 000007
3309 074732 006300
3310 074734 006101
3311 074736 077203
3312 074738 063700 002716
3313 074740 005501
3314 074742 063701 002714
3315 074744 062700 001057
3316 074746 005501
3317 074748 062701 047401
3318 074750 010037 002716
3319 074752 010137 002714
3320 075004 012602
3321 075006 012601
3322 075008 012600
3323 075010 000207
3324 075012
3325
3326
3327
3328
3329
3330
3331
3332
3333
3334
3335
3336
3337
3338
3339
3340
3341
3342
3343
3344
3345
3346
3347
3348
3349
3350
3351
3352
3353
3354
3355
3356
3357
3358
3359
3360
3361
3362
3363
3364
3365
3366
3367
3368
3369
3370
3371
3372
3373
3374
3375
3376
3377
3378
3379
3380
3381
3382
3383
3384
3385
3386
3387
3388
3389
3390
3391
3392
3393
3394
3395
3396
3397
3398
3399
3400
3401
3402
3403
3404
3405
3406
3407
3408
3409
3410
3411
3412
3413
3414
3415
3416
3417
3418
3419
3420
3421
3422
3423
3424
3425
3426
3427
3428
3429
3430
3431
3432
3433
3434
3435
3436
3437
3438
3439
3440
3441
3442
3443
3444
3445
3446
3447
3448
3449
3450
3451
3452
3453
3454
3455
3456
3457
3458
3459
3460
3461
3462
3463
3464
3465
3466
3467
3468
3469
3470
3471
3472
3473
3474
3475
3476
3477
3478
3479
3480
3481
3482
3483
3484
3485
3486
3487
3488
3489
3490
3491
3492
3493
3494
3495
3496
3497
3498
3499
3500
3501
3502
3503
3504
3505
3506
3507
3508
3509
3510
3511
3512
3513
3514
3515
3516
3517
3518
3519
3520
3521
3522
3523
3524
3525
3526
3527
3528
3529
3530
3531
3532
3533
3534
3535
3536
3537
3538
3539
3540
3541
3542
3543
3544
3545
3546
3547
3548
3549
3550
3551
3552
3553
3554
3555
3556
3557
3558
3559
3560
3561
3562
3563
3564
3565
3566
3567
3568
3569
3570
3571
3572
3573
3574
3575
3576
3577
3578
3579
3580
3581
3582
3583
3584
3585
3586
3587
3588
3589
3590
3591
3592
3593
3594
3595
3596
3597
3598
3599
3600
3601
3602
3603
3604
3605
3606
3607
3608
3609
3610
3611
3612
3613
3614
3615
3616
3617
3618
3619
3620
3621
3622
3623
3624
3625
3626
3627
3628
3629
3630
3631
3632
3633
3634
3635
3636
3637
3638
3639
3640
3641
3642
3643
3644
3645
3646
3647
3648
3649
3650
3651
3652
3653
3654
3655
3656
3657
3658
3659
3660
3661
3662
3663
3664
3665
3666
3667
3668
3669
3670
3671
3672
3673
3674
3675
3676
3677
3678
3679
3680
3681
3682
3683
3684
3685
3686
3687
3688
3689
3690
3691
3692
3693
3694
3695
3696
3697
3698
3699
3700
3701
3702
3703
3704
3705
3706
3707
3708
3709
3710
3711
3712
3713
3714
3715
3716
3717
3718
3719
3720
3721
3722
3723
3724
3725
3726
3727
3728
3729
3730
3731
3732
3733
3734
3735
3736
3737
3738
3739
3740
3741
3742
3743
3744
3745
3746
3747
3748
3749
3750
3751
3752
3753
3754
3755
3756
3757
3758
3759
3760
3761
3762
3763
3764
3765
3766
3767
3768
3769
3770
3771
3772
3773
3774
3775
3776
3777
3778
3779
3780
3781
3782
3783
3784
3785
3786
3787
3788
3789
3790
3791
3792
3793
3794
3795
3796
3797
3798
3799
3800
3801
3802
3803
3804
3805
3806
3807
3808
3809
3810
3811
3812
3813
3814
3815
3816
3817
3818
3819
3820
3821
3822
3823
3824
3825
3826
3827
3828
3829
3830
3831
3832
3833
3834
3835
3836
3837
3838
3839
3840
3841
3842
3843
3844
3845
3846
3847
3848
3849
3850
3851
3852
3853
3854
3855
3856
3857
3858
3859
3860
3861
3862
3863
3864
3865
3866
3867
3868
3869
3870
3871
3872
3873
3874
3875
3876
3877
3878
3879
3880
3881
3882
3883
3884
3885
3886
3887
3888
3889
3890
3891
3892
3893
3894
3895
3896
3897
3898
3899
3900
3901
3902
3903
3904
3905
3906
3907
3908
3909
3910
3911
3912
3913
3914
3915
3916
3917
3918
3919
3920
3921
3922
3923
3924
3925
3926
3927
3928
3929
3930
3931
3932
3933
3934
3935
3936
3937
3938
3939
3940
3941
3942
3943
3944
3945
3946
3947
3948
3949
3950
3951
3952
3953
3954
3955
3956
3957
3958
3959
3960
3961
3962
3963
3964
3965
3966
3967
3968
3969
3970
3971
3972
3973
3974
3975
3976
3977
3978
3979
3980
3981
3982
3983
3984
3985
3986
3987
3988
3989
3990
3991
3992
3993
3994
3995
3996
3997
3998
3999
4000

```

```

3321 .SBTTL ROUTINE DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT
3322 .....
3323 *THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
3324 *UNSIGNED OCTAL ASCII NUMBER.
3325 *CALL
3326 *      MOV      #PNTR,-(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
3327 *      CALL     $DB20           ;; CALL THE ROUTINE
3328 *      RETURN                    ;; THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK
3329
3330
3331 075014 104415      $DB20: SAVREG                ;; SAVE ALL REGISTERS
3332 075016 016601      MOV      2(SP),R1          ;; PICKUP THE POINTER TO LOW WORD
3333 075022 012705      MOV      #SOCTVL+13.,R5    ;; POINTER TO DATA TABLE
3334 075026 012704      MOV      #12.,R4         ;; DO ELEVEN CHARACTERS
3335 075032 012703      MOV      #^C7,R3         ;; MASK
3336 075036 012100      MOV      (R1)+,R0        ;; LOWER WORD
3337 075040 012101      MOV      (R1)+,R1        ;; HIGH WORD
3338 075042 005002      CLR      R2                ;; TERMINATOR
3339 075044 110245      1$: MOVB   R2,-(R5)        ;; PUT CHARACTER IN DATA TABLE
3340 075046 010002      MOV      R0,R2           ;; GET THIS DIGIT
3341 075050 005304      DEC      R4              ;; COUNT THIS CHARACTER
3342 075052 003007      BGT     3$              ;; BR IF NOT THE LAST DIGIT
3343 075054 001405      BEQ     2$              ;; BR IF IT IS THE LAST DIGIT
3344 075056 005205      INC      R5              ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
3345 075060 010566      MOV      R5,2(SP)        ;; ASCII CHAR. & PUT IT ON THE STACK
3346 075064 104416      RESREG                ;; RESTORE ALL REGISTERS
3347 075066 000207      RETURN                 ;; RETURN TO USER
3348 075070 006203      2$: ASR     R3            ;; POSITION THE MASK FOR THE LAST DIGIT
3349 075072 006001      3$: ROR     R1            ;; POSITION THE BINARY NUMBER FOR
3350 075074 006000      ROR     R0              ;; THE NEXT OCTAL DIGIT
3351 075076 006001      ROR     R1
3352 075100 006000      ROR     R0
3353 075102 006001      ROR     R1
3354 075104 006000      ROR     R0
3355 075106 040302      BIC     R3,R2           ;; MASK OUT ALL JUNK
3356 075110 062702      ADD     #'0,R2         ;; MAKE THIS CHAR. ASCII
3357 075114 000753      BR     1$              ;; GO PUT IT IN THE DATA TABLE
3358 075116 000016      $OCTVL: .REPT          ;; RESERVE DATA TABLE
3361      075122      $OCT8-$OCTVL+4       ;; POINTER TO 11 DIGIT NUMBER

```

TABLES

```

3363                .SBTTL TABLES
3364
3365                .SBTTL APT MAILBOX-ETABLE
3366 075154          $MAIL:
3367 075134 000000  $MSGTY: .WORD 0      ;;MESSAGE TYPE CODE
3368 075136 000000  $FATAL: .WORD 0      ;;FATAL ERROR NUMBER (ERROR PC)
3369 075140 000000  $TESTN: .WORD 0     ;;TEST NUMBER (DISPLAY REGISTER)
3370 075142 000000  $PASS: .WORD 0     ;;PASS COUNT
3371 075144 000000  $DEVCT: .WORD 0   ;;DEVICE COUNT
3372 075146 000000  $UNIT: .WORD 0   ;;I/O UNIT NUMBER
3373 075150 000000  $MSGAD: .WORD 0  ;;MESSAGE ADDRESS
3374 075152 000000  $MSGLG: .WORD 0  ;;MESSAGE LENGTH
3375 075154          $ETABLE:
3376 075154 000     $ENV: .BYTE 0      ;;ENVIRONMENT BYTE ;SET TO A 1 FOR APT AUTO MODE
3377 075155 000     $ENVM: .BYTE 0    ;;ENVIRONMENT MODE
3378                ;BIT7(200)=USE APT SIZE INFO ;BIT5(40)=NO CONSOLE
3379 075156 000001  $$WREG: .WORD 1   ;;APT SWITCH REGISTER
3380 075160 000000  $USWR: .WORD 0   ;;USED TO LIMIT THE NUMBER OF PASSES
3381 075162 030400  $CPUOP: .WORD 30400 ;;CPU TYPE,OPTIONS
3382                ;*
3383                ;*
3384                ;*
3385                ;*
3386                ;*
3387                ;*
3388 075164 001     $MAMS1: .BYTE 1  ;;HIGH ADDRESS,M.S. BYTE ;DEFAULT 64K
3389 075165 004     $MTYP1: .BYTE 4  ;;MEM. TYPE,BLK#1
3390                ;*
3391                ;*
3392                ;*
3393                ;*
3394                ;*
3395 075166 177776  $MADR1: .WORD 177776 ;;HIGH ADDRESS,BLK#1
3396                ;*
3397 075170 000     $MAMS2: .BYTE 0  ;;HIGH ADDRESS,M.S. BYTE
3398 075171 000     $MTYP2: .BYTE 0  ;;MEM. TYPE,BLK#2
3399 075172 000000  $MADR2: .WORD 0  ;;MEM.LAST ADDRESS,BLK#2
3400 075174 000     $MAMS3: .BYTE 0  ;;HIGH ADDRESS,M.S.BYTE
3401 075175 000     $MTYP3: .BYTE 0  ;;MEM. TYPE,BLK#3
3402 075176 000000  $MADR3: .WORD 0  ;;MEM.LAST ADDRESS,BLK#3
3403 075200 000     $MAMS4: .BYTE 0  ;;HIGH ADDRESS,M.S.BYTE
3404 075201 000     $MTYP4: .BYTE 0  ;;MEM. TYPE,BLK#4
3405 075202 000000  $MADR4: .WORD 0  ;;MEM.LAST ADDRESS,BLK#4
3406 075204 000000  $VECT1: .WORD 0  ;;INTERRUPT VECTOR#1,BUS PRIORITY#1
3407 075206 000000  $VECT2: .WORD 0  ;;INTERRUPT VECTOR#2BUS PRIORITY#2
3408 075210 000000  $BASE: .WORD 0   ;;BASE ADDRESS OF EQUIPMENT UNDER TEST
3409 075212 000000  $DEVMT: .WORD 0  ;;DEVICE MAP
3410
3411                ;IF EITHER OF THESE 2 WORDS ARE NON ZERO
3412                ;THEY WILL BE LOADED INTO ALL CSR'S & THE PROGRAM WILL STOP
3413 075214 000000  $CDW1: .WORD 0   ;;CSR
3414 075216 000000  $CDW2: .WORD 0   ;;CSR+2
3415
3416                ;THE FOLLOWING LOCATIONS SPECIFY WHICH PATTERNS
3417                ;ARE TO BE RUN FOR PARTICULAR MEMORIES
3418                ;
3419                ;REFERENCE THE TABLE LISTED BELOW TO RELATE BITS TO PATTERNS.

```



```

3420
3421
3422
3423
3424
3425 075220 177777
3426 075222 177777
3427 075224 102777
3428 075226 177777
3429 075230 103777
3430 075232 177777
3431 075234 000001
3432 075236
3433
3434
3435
3436 075236
3437 075236 000000
3438 075240 075134
3439 075242 000010
3440 075244 000144
3441 075246 000310
3442 075250 000041

```

```

;BIT0 SET WILL RUN THE FIRST ENTRY IN THE TABLE, BIT0 SET
;IN THE SECOND WORD WILL RUN THE 17TH ENTRY IN THE TABLE ...
;NOTE** NULL TESTS DO NOT TAKE ANY TIME
$DDW0: .WORD 177777 ;MK11 CSR TESTS TABLE = MKCSRT:
$DDW1: .WORD 177777 ;MK11 CSR TESTS TABLE = MKCSRT:
$DDW2: .WORD 102777 ;MK11 PATTERNS TABLE = MKPAT:
$DDW3: .WORD 177777 ;MK11 PATTERNS TABLE = MKPAT:
$DDW4: .WORD 103777 ;MJ11 PATTERNS TABLE = MJPAT:
$DDW5: .WORD 177777 ;MJ11 PATTERNS TABLE = MJPAT:
$DDW6: .WORD 1 ;NUMBER OF CPU'S
SETEND:
;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
;INTERFACE SPEC.
$APTHD:
$HIBTS: .WORD 0 ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBADR: .WORD $MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)
$STMT: .WORD 8. ;;RUN TIM OF LONGEST TEST
$PASTM: .WORD 100. ;;RUN TIME IN SECS. OF 1ST PASS ON 128K (QUICK VERIFY)
$UNITM: .WORD 200. ;;ADDITIONAL RUN TIME OF A PASS FOR EACH ADDITIONAL 128K
.WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE (WORDS)

```

.SBTTL ROUTINE TRAP DECODER

3444
3445
3446
3447
3448
3449
3450
3451
3452
3453
3454
3455
3456
3457
3458
3459
3460
3461
3462
3463
3464
3465
3466
3467
3468

075252 010046
075254 016600 000002
075260 005740
075262 111000
075264 006300
075266 016000 075314
075272 000200

075274 011646
075276 016666 000004 000002
075304 000002

075306
075306 104401 111640

075312 000000

```

:*****
:*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
:*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
:*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
:*GO TO THAT ROUTINE.

$TRAP:  MOV    RO,-(SP)      ;;SAVE R0
        MOV    2(SP),RO    ;;GET TRAP ADDRESS
        TST    -(RO)       ;;BACKUP BY 2
        MOVB   (RO),RO     ;;GET RIGHT BYTE OF TRAP
        ASL    RO          ;;POSITION FOR INDEXING
        MOV    $TRPAD(RO),RO ;;INDEX TO TABLE
        RTS    RO          ;;GO TO ROUTINE

;;THIS IS USE TO HANDLE THE "GETPRI" MACRO

$TRAP2: MOV    (SP),-(SP)   ;;MOVE THE PC DOWN
        MOV    4(SP),2(SP) ;;MOVE THE PSW DOWN
        RTI                    ;;RESTORE THE PSW

$NOTRAP:TYPE  MSG006      ;;UNDEFINED TRAP INSTRUCTION
        TYPEIT ,MSG006
        .DSABL CRF

$HALT2: HALT
```

.SBTTL TRAP TABLE

.*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
.*BY THE 'TRAP' INSTRUCTION.

3471
3472
3473
3474
3475
3476
3477
3478
3479
3480
3481
3482
3483
3484
3485
3486
3487
3488
3489
3490
3491
3492
3493
3494
3495
3496
3497
3498
3499
3500
3501
3502
3503
3504
3505
3506
3507
3508
3509
3510
3511
3512
3513
3514
3515
3516
3517
3518
3519
3520
3521
3522
3523
3524
3525
3526
3527

075314 075274
075316 056752
075320 072374
075322 072350
075324 075306
075326 072576
075330 075306

075332 073160
075334 073022

075336 073602
075340 073722
075342 074266
075344 074436

075346 074624
075350 074662

075352 037020
075354 037030
075356 037040

075360 041016

075362 037050
075364 037066

075366 037076
075370 037220

075372 064574
075374 064622
075376 064650
075400 064700
075402 064762
075404 065004
075406 065034
075410 065054
075412 065076
075414 065116
075416 065140
075420 065162
075422 065202
075424 065220
075426 065236
075430 065256
075432 065274
075434 065312
075436 054570

ROUTINE	WORD	STRPAD:	TRAP	DESCRIPTION
STYPAD	STYPAD			
STYPE	:CALL=TYPEIT		TRAP+1(104401)	TTY TYPEOUT ROUTINE
STYPOC	:CALL=TYPOC		TRAP+2(104402)	TYPE OCTAL NUMBER (WITH LEADING ZEROS)
STYPOS	:CALL=TYPOS		TRAP+3(104403)	TYPE OCTAL NUMBER (NO LEADING ZEROS)
SNOTRAP	:CALL=TYPON		TRAP+4(104404)	TYPE OCTAL NUMBER (AS PER LAST CALL)
STYPDS	:CALL=TYPDS		TRAP+5(104405)	TYPE DECIMAL NUMBER (WITH SIGN)
SNOTRAP	:CALL=TYPBN		TRAP+6(104406)	TYPE BINARY (ASCII) NUMBER
SGTSWR	:CALL=GTSWR		TRAP+7(104407)	GET SOFT-SWR SETTING
SCKSWR	:CALL=CKSWR		TRAP+10(104410)	TEST FOR CHANGE IN SOFT-SWR
SRDCHR	:CALL=RDCHR		TRAP+11(104411)	TTY TYPEIN CHARACTER ROUTINE
SRDLIN	:CALL=RDLIN		TRAP+12(104412)	TTY TYPEIN STRING ROUTINE
SRDOCT	:CALL=RDOCT		TRAP+13(104413)	READ AN OCTAL NUMBER FROM TTY
SRDDEC	:CALL=RDDEC		TRAP+14(104414)	READ A DECIMAL NUMBER FROM TTY
SSAVREG	:CALL=SAVREG		TRAP+15(104415)	SAVE R0-R5 ROUTINE
SRESREG	:CALL=RESREG		TRAP+16(104406)	RESTORE R0-R5 ROUTINE
SKERNEL	:CALL=KERNEL		TRAP+17(104417)	ENTER KERNEL MODE
SENERGIZE	:CALL=ENERGIZE		TRAP+20(104420)	TURN ON MEMORY MANAGEMENT & TRAPS
SDEENERGI	:CALL=DEENERGI		TRAP+21(104421)	TURN OFF MEMORY MANAGEMENT & TRAPS
SKMAP	:CALL=KMAP		TRAP+22(104422)	MAP KERNEL 1 TO 1
SCACHN	:CALL=CACHON		TRAP+23(104423)	TURN CACHE ON
SCACHF	:CALL=CACHOFF		TRAP+24(104424)	TURN CACHE OFF
SLOADC	:CALL=LOADCSR		TRAP+25(104425)	LOAD CORRECT CSR
SREADC	:CALL=READCSR		TRAP+26(104426)	READ CORRECT CSR
\$PER01	:CALL=PERR01		TRAP+27(104427)	PROGRAM DETECTED ERROR
\$PER02	:CALL=PERR02		TRAP+30(104430)	PROGRAM DETECTED ERROR
\$PER03	:CALL=PERR03		TRAP+31(104431)	PROGRAM DETECTED ERROR
\$PER04	:CALL=PERR04		TRAP+32(104432)	PROGRAM DETECTED ERROR
\$PER07	:CALL=PERR07		TRAP+33(104433)	PROGRAM DETECTED ERROR
\$PER10	:CALL=PERR10		TRAP+34(104434)	PROGRAM DETECTED ERROR
\$PER11	:CALL=PERR11		TRAP+35(104435)	PROGRAM DETECTED ERROR
\$PER12	:CALL=PERR12		TRAP+36(104436)	PROGRAM DETECTED ERROR
\$PER13	:CALL=PERR13		TRAP+37(104437)	PROGRAM DETECTED ERROR
\$PER14	:CALL=PERR14		TRAP+40(104440)	PROGRAM DETECTED ERROR
\$PER15	:CALL=PERR15		TRAP+41(104441)	PROGRAM DETECTED ERROR
\$PER16	:CALL=PERR16		TRAP+42(104442)	PROGRAM DETECTED ERROR
\$PER17	:CALL=PERR17		TRAP+43(104443)	PROGRAM DETECTED ERROR
\$PER20	:CALL=PERR20		TRAP+44(104444)	PROGRAM DETECTED ERROR
\$PER21	:CALL=PERR21		TRAP+45(104445)	PROGRAM DETECTED ERROR
\$PER22	:CALL=PERR22		TRAP+46(104446)	PROGRAM DETECTED ERROR
\$PER23	:CALL=PERR23		TRAP+47(104447)	PROGRAM DETECTED ERROR
\$PER24	:CALL=PERR24		TRAP+50(104450)	PROGRAM DETECTED ERROR
\$PER25	:CALL=PERR25		TRAP+51(104451)	PROGRAM DETECTED ERROR

TRAP TABLE

3528	075440	065502	\$PER26	: CALL=PERR26	TRAP+52(104452)	PROGRAM DETECTED ERROR
3529	075442	065522	\$PER27	: CALL=PERR27	TRAP+53(104453)	PROGRAM DETECTED ERROR
3530	075444	054762	\$PER30	: CALL=PERR30	TRAP+54(104454)	PROGRAM DETECTED ERROR
3531	075446	065720	\$PER31	: CALL=PERR31	TRAP+55(104455)	PROGRAM DETECTED ERROR
3532	075450	066016	\$PER32	: CALL=PERR32	TRAP+56(104456)	PROGRAM DETECTED ERROR
3533	075452	066064	\$PER33	: CALL=PERR33	TRAP+57(104457)	PROGRAM DETECTED ERROR
3534	075454	066144	\$PER34	: CALL=PERR34	TRAP+60(104460)	PROGRAM DETECTED ERROR
3535	075456	066176	\$PER35	: CALL=PERR35	TRAP+61(104461)	PROGRAM DETECTED ERROR
3536	075460	075306	\$NOTRAP	: CALL=PERR36	TRAP+62(104462)	PROGRAM DETECTED ERROR
3537	075462	075306	\$NOTRAP	: CALL=PERR37	TRAP+63(104463)	PROGRAM DETECTED ERROR
3538	075464	075306	\$NOTRAP	: CALL=PERR40	TRAP+64(104464)	PROGRAM DETECTED ERROR
3539	075466	075306	\$NOTRAP	: CALL=PERR41	TRAP+65(104465)	PROGRAM DETECTED ERROR
3540	075470	075306	\$NOTRAP	: CALL=PERR42	TRAP+66(104466)	PROGRAM DETECTED ERROR
3541	075472	075306	\$NOTRAP	: CALL=PERR43	TRAP+67(104467)	PROGRAM DETECTED ERROR
3542						
3543	075474	037466	\$ECCDIS	: CALL=ECCDIS	TRAP+70(104470)	DISABLE ECC ON ALL CSR'S
3544	075476	037522	\$ECC1DIS	: CALL=ECC1DIS	TRAP+71(104471)	DISABLE ECC ON 1 SELECTED CSR
3545	075500	037554	\$ECCINIT	: CALL=ECCINIT	TRAP+72(104472)	INITIALIZE ALL MK11 CSR'S
3546	075502	037574	\$ECC1INIT	: CALL=ECC1INIT	TRAP+73(104473)	INITIALIZE 1 SELECTED MK11 CSR
3547	075504	037700	\$CBCSR	: CALL=CBCSR	TRAP+74(104474)	WRITE GENERATED CHECKBITS IN ALL CSR'S
3548	075506	037742	\$CB1CSR	: CALL=CB1CSR	TRAP+75(104475)	WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
3549	075510	040002	\$WASSBE	: CALL=WASSBE	TRAP+76(104476)	WAS THERE A SBE ON ANY CSR?
3550	075512	040116	\$WAS1SBE	: CALL=WAS1SBE	TRAP+77(104477)	WAS THERE A SBE ON 1 SELECTED CSR?
3551	075514	040146	\$WASDBE	: CALL=WASDBE	TRAP+100(104500)	WAS THERE A DBE ON ANY CSR?
3552	075516	040262	\$WAS1DBE	: CALL=WAS1DBE	TRAP+101(104501)	WAS THERE A DBE ON 1 SELECTED CSR?
3553	075520	040322	\$CLRCSR	: CALL=CLRCSR	TRAP+102(104502)	CLEAR ALL CSR'S
3554	075522	040340	\$CLR1CSR	: CALL=CLR1CSR	TRAP+103(104503)	CLEAR 1 SELECTED CSR
3555	075524	040354	\$CHKDIS	: CALL=CHKDIS	TRAP+104(104504)	DISABLE ECC & WRITE CKBITS FROM ALL CSR'S
3556	075526	040410	\$CHK1DIS	: CALL=CHK1DIS	TRAP+105(104505)	DISABLE ECC & WRITE CKBITS FROM 1 CSR
3557	075530	037612	\$ENASBE	: CALL=ENASBE	TRAP+106(104506)	ENABLE TRAPS ON SBE'S FROM ALL CSR'S
3558	075532	037646	\$ENA1SBE	: CALL=ENA1SBE	TRAP+107(104507)	ENABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
3559	075534	037310	\$TSTRD	: CALL=TSTRD	TRAP+110(104510)	TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES
3560	075536	040510	\$INVALID	: CALL=INVALID	TRAP+111(104511)	INVALIDATE BACKGROUND PATTERN ON BANK
3561	075540	075306	\$NOTRAP			
3562	075542	075306	\$NOTRAP			
3563	075544	075306	\$NOTRAP			
3564	075546	075306	\$NOTRAP			
3565	075550	075306	\$NOTRAP			
3566	075552	075306	\$NOTRAP			
3567	075554	075306	\$NOTRAP			
3568	075556	075306	\$NOTRAP			

DATA AREA

Address	Value	Symbol	Value	Description
3571	177776	ST	177776	:STATUS REGISTER
3572	000016	C.BKP	16	:NUMBER OF BREAKPOINTS-1 MULT. BY 2
3573	000014	O.TVEC	14	:TRT VECTOR LOCATION
3574	000340	O.STM	340	:PRIORITY MASK - STATUS REGISTER
3575	000020	O.TBT	20	:T-BIT MASK - STATUS REGISTER
3576	000003	TRT	000003	:TRT INSTRUCTION
3577	177562	O.RDB	177562	:R DATA BUFFER
3578	177560	O.RCSR	177560	:R C/SR
3579	177566	O.TDB	177566	:T DATA BUFFER
3580	177564	O.TCSR	177564	:T C/SR

EMKABU DATA AREA

0.1 .BYTE

```

3598 075573 000      O.P: .BYTE 0
3599
3600
3601 075574 000      O.CSR1: .BYTE 0
3602 075575 000      O.CSR2: .BYTE 0
3603 075576 000000   O.FIL: 0
3604 075600 000      O.CMFD: .BYTE 0
3605
3606 075601 000      O.SMFD: .BYTE 0
3607
3608
3609 075602 000      O.SCRN: .BYTE 0
3610
3611 075603 000      O.MINS: .BYTE 0
3612
3613 075604 000000   O.BIAS: .WORD 0
    
```

```

:PROCEED FLAG = -2 IF MANUAL ENTRY
                -1 IF NO PROCEED ALLOWED
                0-7 IF PCEED ALLOWED
:
:SAVE CELL - R C/SR
:SAVE CELL - T C/SR
:FILL COUNTER
:COMMA FOUND SWITCH, =0 NO COMMA FOUND
                  =1 COMMA FOUND
:SEMICOLON FOUND SWITCH
:=0 NO SEMICOLON FOUND
:=1 SEMICOLON FOUND
:FLAG; 1=PASS SPACES ON FROM TTY
:ALSO, IF =1, <LF> IS ECHOED
:MINUS SIGN TYPED (SWITCH)
:0=NO MINUS TYPED; 1=MINUS SIGN TYPED
:CURRENT RELOCATION BIAS
    
```

3616
3617 C00026
3620 075662 000000
3621 075664 000000
3622 075666 000000
3623 075670 000000
3624 075672 000000
3625 075674 000000
3626 075676 000000
3627 075700 000000
3628 075702 000000
3629 075704 000007
3630
3631
3632
3633 075706
3634 075730
3635 075730
3636 075752
3637 075752
3638 075774
3639 075774

:THE ORDER OF THE FOLLOWING ENTRIES IS CRITICAL
REPT 26
O.UR0: 0 :USER R0
0 :R1
0 :R2
0 :R3
0 :R4
0 :R5
O.USP: 0 :USER SP
O.UPC: 0 :USER PC
O.UST: 0 :USER ST
O.PRI: 7 :ODT PRIORITY
; BREAK POINT LISTS, ADR1 - ADDRESS OF BREAKPOINT, CT = COUNT,
; UIN = CONTENTS
O.ADR1:
. = +O.BKP+4
O.CT:
. = +O.BKP+4
O.UIN:
. = +O.BKP+4
SLAVEND: :..... THIS IS THE LIMIT OF SLAVE UNIQUE CODE

```

3647 075774 000421
3648 075776 000440
3649 076000 004737 101172
3650 076004 013746 000016
3651 076010 004737 101202
3652 076014 010746
3653 076016 012637 075700
3654 076022 112737 177777 075573
3655 076030 105037 075571
3656 076034 000137 100060
3657
3658
3659 076040 004537 100500
3660 076044 012737 076000 073114
3661 076052 004037 100360
3662 076056 012706 075662
3663 076062 012704 101300
3664 076066 012703 101315
3665 076072 004537 101126
3666 076076 000414
3667 076100 004037 100360
3668 076104 004537 100602
3669 076110 113704 075704
3670 076114 106004
3671 076116 106004
3672 076120 106004
3673 076122 010446
3674 076124 004737 101202
3675 076130 105037 075571
3676 076134 112737 177777 075573
3677 076142 012737 000340 000016
3678 076150 012737 100042 000014
3679 076156 000137 077430
3680
3681
3682
3683
3684
3685 076162 013706 075676
3686 076166 012704 076206
3687 076172 012703 076207
3688 076176 004537 101126
3689 076202 000137 043416
3690 076206 136
3691 076207 103

: INITIALIZE ODT
: USE O.ODT FOR A NORMAL ENTRY
: USE O.ODT+2 TO RESTART ODT - WIPING OUT ALL BREAKPOINTS
: USE O.ODT+4 TO RE-ENTER (I.E. - FAKE A BREAKPOINT)

0.ODT: BR 2$ ;NORMAL ENTRY
        BR 3$ ;RESTART
1$: JSR PC,O.BRST ;RE-ENTER -- SAVE STATUS
     MOV O.TVEC+2,-(SP) ;SET UP LOCAL STATUS
     JSR PC,C.WST
     MOV PC,-(SP) ;FAKE THE PC
     MOV (SP)+,O.UPC
     MOVB #-1,O.P ;DISALLOW PROCEED
     CLRB O.S
     JMP O.BK1

: RUN AT CURRENT STATUS
2$: JSR 5,O.SVTT ;SAVE TTY STATUS
     MOV #1$,O.CONTP+2
     JSR O,O.SVR ;SAVE REGISTERS (MAINLY SP)
     MOV #O,URO,SP ;SET UP STACK
     MOV #O,ID,R4 ;TYPE ID
     MOV #O,IDND,R3
     JSR 5,O.TYPE
     BR 4$
3$: JSR O,O.SVR ;SAVE REGISTERS
     JSR 5,O.REM ;REMOVE ALL BREAKPOINTS
     MOVB O,PRI,R4 ;GET ODT PRIORITY
     RORB R4 ;SHIFT
     RORB R4 ; INTO
     RORB R4 ; POSITION
     MOV R4,-(SP) ;STORE IN STATUS
     JSR PC,O.WST
4$: CLRB O.S ;DISABLE SINGLE INSTRUCTION FOR NOW
     MOVB #-1,O.P ;DISALLOW PROCEED
     MOV #O,STM,O.TVEC+2 ;STATUS WORD TO TRT VECTOR+2
     MOV #O,BRK,O.TVEC ;PC TO TRT VECTOR
     JMP O.RALL ;CLEAR BRK PT TABLES

: O.CTLC
: AC PROCESSING. RETURN TO KEYBOARD MONITOR
:
: O.CTLC: MOV O,USP,SP ;RESTORE USER STACK
        MOV #1$,R4
        MOV #2$,R3
        JSR R5,C.TYPE ;ECHO '^C'
        JMP BOOT
1$: .BYTE 'A'
2$: .BYTE 'C'

```



```

3694
3695 076210 C13706 075676
3696 076214 012704 076240
3697 076220 012703 076241
3698 076224 004537 101126
3699 076230 004737 043774
3700 076234 000137 075774
3701 076240 136
3702 076241 106
3703
3704
3705 076242 012704 076266
3706 076246 012703 076267
3707 076252 004537 101126
3708 076256 012705 073116
3709 076262 000137 077624
3710 076266 136
3711 076267 105
3712
3713
3714
3715
3716 076270 004537 101006
3717 076274 012704 101345
3718 076300 120024
3719 076302 001414
3720 076304 022704 101365
3721 076310 101373
3722 076312 042700 177770
3723 076316 010004
3724 076320 006304
3725 076322 062704 075662
3726 076326 005202
3727 076330 000137 076554
3728 076334 162704 101336
3729 076340 000767
    
```

```

:CONTROL F PROCESSING
O.CTLF: MOV O.USP,SF :RESTORE USER STACK
        MOV #1$,R4
        MOV #2$,R3
        JSR R5,O.TYPE :ECHO ^F
        CALL FIELDSERVICE
        JMP O.ODT
1$: .BYTE 'A'
2$: .BYTE 'F'
    
```

```

:CONTROL E PROCESSING
O.CTLE: MOV #1$,R4
        MOV #2$,R3
        JSR R5,O.TYPE :ECHO ^E
        MOV #CONT+4,R5
        JMP O.GOGO
1$: .BYTE 'A'
2$: .BYTE 'E'
    
```

```

: SPECIAL NAME HANDLER
: DEPENDS UPON THE EXPLICIT ORDER OF THE TWO TABLES O.TL AND O.URO
    
```

```

O.REGT: JSR 5,O.GET :SPECIAL NAME, GET ONE MORE CHARACTER
        MOV #O.TL,R4 :TABLE START ADDRESS
1$: CMPB R0,(R4)+ :IS THIS THE CORRECT CHARACTER?
        BEQ 3$ :JUMP IF YES
        CMP #O.TL+O.LG,R4 :IS THE SEARCH DONE?
        BHI 1$ :BRANCH IF NOT
        BIC #177770,R0 :MASK OFF OCTAL
2$: MOV R0,R4
        ASL R4
        ADD #O.URO,R4 :GENERATE ADDRESS
        INC R2 :SET FOUND FLAG
        JMP O.SCAN :GO FIND NEXT CHARACTER
3$: SUB #O.TL-7,R4 :GO FIND NEXT CHARACTER
        BR 2$
    
```

```

3732 ; 'BACKARROW' HANDLER - OPEN INDEXED ON THE PC (BACK ARROW)
3733 ; .ENABL LSB
3734 076342 004537 076416 0.0RPC: JSR 5.2$ ;TEST WORD MODE AND CLOSE
3735 076346 061202 ADD @R2,R2 ;COMPUTE
3736 076350 005202 INC R2
3737 076352 005202 INC R2 ; NEW ADDRESS
3738 076354 010237 075560 1$: MOV R2,0.CAD ;UPDATE CAD
3739 076360 000137 077226 JMP 0.OP2A ;GO FINISH UP
3740 076364 004537 076416 0.0RAB: JSR 5.2$ ;TEST WORD MODE AND CLOSE
3741 076370 011202 MOV @R2,R2 ;GET ABSOLUTE ADDRESS
3742 076372 000770 BR 1$
3743 076374 004537 076416 0.0RRB: JSR 5.2$ ;TEST AND CLOSE
3744 076400 011201 MOV @R2,R1 ;COMPUTE NEW ADDRESS
3745 076402 110101 MOVB R1,R1 ;EXTEND THE SIGN
3746 076404 006301 ASL R1 ;R2=2(@R2)
3747 076406 005201 INC R1 ; +2
3748 076410 005201 INC R1
3749 076412 060102 ADD R1,R2 ; +PC
3750 076414 000757 BR 1$
3751 076416 004737 101214 075566 2$: JSR PC,0.CLSE ;CLOSE CURRENT CELL
3752 076422 022737 000002 CMP #2,0.BW ;ONLY WORD MODE ALLOWED
3753 076430 001003 BNE 3$ ;BRANCH IF ERROR
3754 076432 013702 075560 MOV 0.CAD,R2 ;CURRENT ADDRESS IN R2
3755 076436 000205 RTS R5
3756 076440 005726 3$: TST (SP)+
3757 076442 000137 076510 0.TCL2: JMP 0.ERR ;POP A WORD AND SHOW THE ERROR
3758 ; .DSABL LSB
3759
3760 ; PROCESS S - SINGLE INSTRUCTION MODE
3761 076446 105737 075601 0.SNGL: TSTB 0.SMFD ;DONT REACT IF ; NOT TYPED
3762 076452 001773 BEQ 0.TCL2
3763 076454 005702 TST R2 ;SEE IF TURN ON OR TURN OFF
3764 076456 001004 BNE 1$ ;BRANCH IF TURNING IT ON
3765 076460 105037 075571 CLRB 0.S ;CLEAR THE FLAG
3766 076464 000137 076520 JMP 0.DCD ;CONTINUE THE SCAN
3767 076470 112737 177777 075571 1$: MOVB #-1,0.S ;SET THE FLAG
3768 076476 000137 076520 JMP 0.DCD

```

3771								
3772								
3773								
3774	076502	105237	075603					
3775	076506	000420						
3776								
3777								
3778								
3779								
3780								
3781	076510	012700	000077					
3782	076514	004537	100730					
3783	076520	005037	075566					
3784	076524	004537	101254					
3785	076530	105037	075601					
3786	076534	105037	075600					
3787	076540	105037	075603					
3788	076544	005003						
3789	076546	005005						
3790	076550	005004						
3791	076552	005002						
3792	076554	004537	101006					
3793	076560	022700	000060					
3794	076564	101013						
3795	076566	022700	000067					
3796	076572	103410						
3797	076574	042700	177770					
3798	076600	006304						
3799	076602	006304						
3800	076604	006304						
3801	076606	060004						
3802	076610	005202						
3803	076612	000760						
3804	076614	005001						
3805	076616	120061	101321					
3806	076622	001405						
3807	076624	005201						
3808	076626	020127	000024					
3809	076632	103326						
3810	076634	000770						
3811	076636	105737	075603					
3812	076642	001401						
3813	076644	005404						
3814	076646	105737	075600					
3815	076652	001402						
3816	076654	063704	075604					
3817	076660	105037	075603					
3818	076664	006301						
3819	076666	000171	076672					

```

; MINUS PROCESSING
;
; O.MIN: INCB      O.MINS      ; SET MINUS FOUND SWITCH ON
;         BR       C.DCD1
;
; COMMAND DECODER - ODT11X
;
; ALL REGISTERS MAY BE USED (R0-R5),
;
O.ERR: MOV      #'?,R0      ; ? TO BE TYPED
        JSR      5,O.FTYP    ; OUTPUT ?
O.DCD: CLR      O.BW        ; CLOSE ALL
        JSR      5,O.CRLS    ; TYPE <CR><LF>*
O.DCD3: CLRB    O.SMFD       ; SEMICOLON FOUND FLAG
        CLRB    O.CMFD       ; COMMA FOUND FLAG
        CLRB    O.MINS       ; MINUS SIGN FOUND FLAG
        CLR     R3           ; R3 IS A SAVE REGISTER FOR R2
        CLR     R5           ; R5 IS A SAVE REGISTER FOR R4
O.DCD1: CLR     R4           ; R4 CONTAINS THE CONVERTED OCTAL
        CLR     R2           ; R2 IS THE NUMBER FOUND FLAG
O.SCAN: JSR     5,O.GET      ; GET A CHAR, RETURN IN R0
        CMP     #'0,R0       ; COMPARE WITH ASCII 0
        BHI     5$          ; CHECK LEGALITY IF NON-NUMERIC
        CMP     #'7,R0       ; COMPARE WITH ASCII 7
        BLO     5$          ; CHECK LEGALITY IF NOT OCTAL
        BIC     #177770,R0   ; CONVERT TO BCD
        ASL     R4           ; MAKE ROOM
        ASL     R4           ; IN
        ASL     R4           ; R4
        ADD     R0,R4        ; PACK THREE BITS IN R4
        INC     R2           ; R2 HAS NUMERIC FLAG
        BR     O.SCAN       ; AND TRY AGAIN
5$: CLR     R1              ; CLEAR INDEX
1$: CMPB    R0,O.LGCH(R1)   ; DO THE CODES MATCH?
        BEQ     2$          ; JUMP IF YES
        INC     R1          ; SET INDEX FOR NEXT SEARCH
        CMP     R1,#O.CLGT  ; IS THE SEARCH DONE?
        BR     O.ERR       ; OOPS!
2$: TSTB   O.MINS          ; RE-LOOP
        BEQ     4$          ; IF MINUS WAS NOT TYPED
        NEG     R4          ; DO NOT NEGATE K
        BEQ     3$          ; OTHERWISE, TAKE 2'S COMPLEMENT.
        TSTB   O.CMFD       ; IF A COMMA NOT TYPED,
        BEQ     3$          ; SKIP NEXT INSTRUCTION.
        ADD     O.BIAS,R4    ; OTHERWISE, ADD RELOC. BIAS TO (R4)
3$: CLRB    O.MINS         ; REINITIALIZE MINUS-TYPED SWITCH FOR NEXT SCAN
        ASL     R1          ; MULTIPLY BY TWO
        JMP     @6$(R1)     ; GO TO PROPER ROUTINE
    
```

(T (CEMKA) DATA AREA

3822	076672	076742	CS:	C.SEMI	:	:	SEMICOLON
3823	076674	076760		O.WRD	:	/	OPEN WORD
3824	076676	076772		O.BYT	:	\	OPEN BYTE -BACK SLASH
3825	076700	077140		O.CRET	:		CARRIAGE RETURN CLOSE
3826	076702	076270		O.REGT	:	\$	REGISTER OPS
3827	076704	077576		O.GO	:	G	GO TO ADDRESS K
3828	076706	077160		O.OP1	:	<LF>	MODIFY, CLOSE, OPEN NEXT
3829	076710	076342		O.ORPC	:	'BACKARROW'	OPEN RELATED, INDEX - PC (BACK ARROW)
3830	076712	077154		O.OLD	:	<	RETURN TO OLD SEQUENCE AND OPEN
3831	076714	077302		O.BACK	:	^	OPEN PREVIOUS (UP ARROW)
3832	076716	077466		O.OFST	:	O	OFFSET
3833	076720	077324		O.BKPT	:	B	BREAKPOINTS
3834	076722	077732		O.PROC	:	P	PROCEED
3835	076724	076364		O.ORAB	:	@	OPEN RELATED, ABSOLUTE
3836	076726	076374		O.ORRB	:	>	OPEN RELATED, REL. BRANCH
3837	076730	076446		O.SNGL	:	S	SINGLE INSTRUCTION MODE
3838	076732	076502		O.MIN	:	-	MINUS, NEGATES NUMBER TYPED IN
3839	076734	076162		O.CTLC	:	^C	EXIT TO MONITOR
3840	076736	076210		O.CTLF	:	^F	EXIT TO FIELD SERVICE MODE
3841	076740	076242		O.CTLE	:	^E	PROCEED FROM ^D

```

3844
3845
3846 ; SEMI-COLON PROCESSOR
3847 076742 010203 0. SEMI: MOV R2,R3 ;A SEMI-COLON HAS BEEN RECEIVED
3848 076744 010405 MOV R4,R5 ;NUMERIC FLAG TO R3, CONTENTS TO R5
3849 076746 105237 075601 INCB 0.SMFD ;SET SEMICOLON FOUND FLAG
3850 076752 105037 075600 CLRB 0.CMFD ;RESET COMMA FOUND FLAG
3851 076756 000674 BR 0.DCD1 ;GO BACK FOR MORE
3852
3853 ; PROCESS / AND \ - OPEN WORD OR BYTE
3854
3855 ;INPUT - IF R2 IS NON-ZERO A NEW REXP HAS BEEN TYPED IN
3856 ;INPUT - -ADDRESS OF WORD TO BE OPENED IS IN R4
3857 .ENABL LSB
3858 076760 012737 000002 075566 0. WRD: MOV #2,0.BW ;OPEN WORD
3859 076766 000404 BR 11$
3860 076770 006104 1$: ROL R4 ;GET THE ADDRESS BACK
3861 076772 012737 000001 075566 0. BYT: MOV #1,0.BW ;OPEN BYTE
3862 077000 005702 11$: TST R2 ;GET VALUE IF R2 IS NON-ZERO
3863 077002 001011 BNE 14$ ;BRANCH IF NUMBER INPUT
3864 077004 105737 075600 TSTB 0.CMFD ;TEST FOR ',' AND ';'
3865 077010 001402 BEQ 12$
3866 077012 000137 076510 13$: JMP 0.ERR ;ERROR IF PRESENT WITHOUT NUMBER.
3867 077016 105737 075601 12$: TSTB 0.SMFD
3868 077022 001373 BNE 13$
3869 077024 000404 BR 0.WRD1 ;NO NUMBER - REOPEN PREVIOUS LOCATION
3870 077026 010437 075562 14$: MOV R4,0.DOT ;PUT VALUE IN DOT
3871 077032 010437 075560 MOV R4,0.CAD ; ALSO IN CAD
3872 077036 022737 000001 075566 0. WRD1: CMP #1,0.BW ;CHECK BYTE MODE
3873 077044 001407 BEQ 22$ ;JUMP IF BYTE
3874 077046 013704 075560 MOV 0.CAD,R4
3875 077052 006204 ASR R4 ;MOVE ONE BIT TO CARRY
3876 077054 103745 BCS 1$ ;JUMP IF ODD ADDRESS
3877 077056 017700 176476 MOV @0.CAD,RO ;GET CONTENTS OF WORD
3878 077062 000402 BR 23$
3879 077064 117700 176470 22$: MOVB @0.CAD,RO ;GET CONTENTS OF BYTE
3880 077070 004537 100634 23$: JSR 5,0.CADV ;GO GET AND TYPE OUT @CAD
3881 077074 022737 000001 075566 CMP #1,0.BW ;CHECK IF BYTE MODE.
3882 077102 001212 BNE 0.DCD3 ;IF NOT WE'RE DONE. ELSE:
3883 077104 112700 000075 MOVB #' ,RO ;TYP ' ' AND THEN THE ASCII BYTE
3884 077110 004537 100730 JSR 5,0.FTYP
3885 077114 117700 176440 MOVB @0.CAD,RO
3886 077120 004537 100730 JSR 5,0.FTYP
3887 077124 112700 000040 MOVB #' ,RO
3888 077130 004537 100730 JSR 5,0.FTYP
3889 077134 000137 076530 JMP 0.DCD3 ;GO BACK TO DECODER
3890 .DSABL LSB

```

ODT (CEMKA) DATA AREA

```

3893 ; PROCESS CARRIAGE RETURN
3894 077140 004737 101214 O.CRET: JSR PC.O.CLSE ;CLOSE LOCATION
3895 077144 000137 076520 O.DCDA: JMP O.DCD ;RETURN TO DECODER
3896
3897 077150 000137 076510 O.ERR3: JMP O.ERR ; INTERMEDIATE HELP
3898
3899 ; PROCESS <LF>, OPEN NEXT WORD
3900
3901 077154 105237 075570 O.OLD: INCB O.SEQ ;SET FLAG TO LATER RESTORE CAD
3902 077160 005737 075566 O.OP1: TST O.BW ;<LF> RECEIVED
3903 077164 001771 O.ERR2: BEQ O.ERR3 ;ERROR IF NOTHING IS OPEN
3904 077166 004737 101214 JSR PC.O.CLSE ;CLOSE PRESENT CELL
3905 077172 105737 075570 TSTB O.SEQ ;SHOULD CAD BE RESTORED?
3906 077176 001405 BEQ 1$ ;BRANCH IF NOT
3907 077200 013737 075562 075560 MOV O.DOT,O.CAD ;RESTORE PREVIOUS SEQUENCF
3908 077206 105037 075570 CLRB O.SEQ ;RESET FLAG; NO LONGER NEEDED
3909 077212 063737 075566 075560 1$: ADD O.BW,O.CAD ;GENERATE NEW ADDRESS
3910 077220 013737 075560 075562 O.OP2: MOV O.CAD,O.DOT ;INITIALIZE DOT
3911 077226 004537 101246 O.OP2A: JSR 5.O.CRLF ;<CR><LF>
3912 077232 013746 075566 MOV O.BW,-(SP) ;SAVE BW
3913 077236 012737 000002 075566 MOV #2,O.BW ;SET TO TYPE FULL WORD ADDRESS
3914 077244 013700 075560 MOV O.CAD,RO ;NUMBER TO TYPE
3915 077250 004537 101272 JSR 5.O.RORA ; CHECK FORMAT
3916 077254 011637 075566 MOV @SP,O.BW ;RESTORE BW
3917 077260 012700 027534 MOV #27534,RO ;PUT '\ ' IN RO
3918 077264 027226 000001 CMP #1,(SP)+ ;IS IT BYTE MODE?
3919 077270 001401 BEQ 1$ ;JUMP IF YES
3920 077272 000300 RO ;TYPE A /
3921 077274 004537 100730 1$: JSR 5.O.FTYP ;TYPE THE LOW BYTE OF RO
3922 077300 000656 BR O.WRD1 ;GO PROCESS IT
3923

```

```

3926
3927 ; PROCESS ^, OPEN PREVIOUS WORD
3928
3929 077302 005737 075566 O.BACK- TST O.BW ; ^ RECEIVED
3930 077306 001726 BEQ O.ERR2 ;ERROR IF NOTHING OPEN
3931 077310 004737 101214 JSR PL,O.CLSE
3932 077314 163737 075566 075560 SUB O.BW,O.CAD ;GENERATE NEW ADDRESS
3933 077322 000736 BR O.OP2 ;GO DO THE REST
3934
3935 ; B HANDLER - SET AND REMOVE BREAKPOINTS
3936
3937 077324 012700 101370 O.BKPT: MOV #O.TRTC,R0
3938 077330 006304 ASL R4 ;MULTIPLY NUMBER BY TWO
3939 077332 005703 TST R3
3940 077334 001423 BEQ 3$ ;IF R3 IS ZERO GO REMOVE BREAKPOINT
3941 077336 006205 ASR R5 ;GET ONE BIT TO CARRY
3942 077340 103514 BCS O.ERR1 ;BADNESS IF ODD ADDRESS
3943 077342 006305 ASL R5 ;RESTORE ONE BIT
3944 077344 062704 075706 ADD #O.ADR1,R4
3945 077350 005702 TST R2
3946 077352 001007 BNE 1$ ;JUMP IF SPECIFIC CELL
3947 077354 020014 2$: CMP R0,R4 ;IS THIS CELL FREE?
3948 077356 001405 BEQ 1$ ;JUMP IF YES
3949 077360 020427 075724 CMP R4,#O.BKP+O.ADR1 ;ARE WE AT THE END OF OUR ROPE
3950 077364 103102 BHIS O.ERR1 ;YES, THERE IS NOTHING FREE
3951 077366 005724 TST (R4)+ ;INCREMENT BY TWO
3952 077370 000771 BR 2$
3953 077372 020427 075724 1$: CMP R4,#O.BKP+O.ADR1
3954 077376 101075 BHI O.ERR1 ;ERROR IF TOO LARGE
3955 077400 010514 MOV R5,R4 ;SET BREAKPOINT
3956 077402 000660 BR O.DCDA ;RETURN
3957 077404 005702 3$: TST R2
3958 077406 001410 BEQ O.RALL ;GO REMOVE ALL
3959 077410 020427 000016 CMP R4,#O.BKP
3960 077414 101066 BHI O.ERR1 ;JUMP IF NUMBER TOO LARGE
3961 077416 010064 075706 MOV R0,O.ADR1(R4) ;CLEAR BREAKPOINT
3962 077422 005064 075730 CLR O.CT(R4) ;CLEAR COUNT ALSO
3963 077426 000646 BR O.DCDA
3964 077430 005004 O.RALL: CLR R4
3965 077432 012700 101370 MOV #O.TRTC,R0
3966 077436 020427 000020 1$: CMP R4,#O.BKP+2 ;ALL DONE?
3967 077442 101240 BHI O.DCDA ;JUMP IF YES
3968 077444 010064 075706 MOV R0,O.ADR1(R4) ;RESET BKPT
3969 077450 012764 000003 075752 MOV #TRT,O.UIN(R4) ;RESET CONTENTS OF TABLE
3970 077456 005064 075730 CLR O.CT(R4) ;CLEAR COUNT
3971 077462 005724 TST (R4)+ ;INCREMENT BY TWO
3972 077464 000764 BR 1$
3973
    
```

```

3976
3977          ; PROCESS 0, COMPUTE OFFSET
3978
3979 077466 022737 000002 075566 0.OFST: CMP      #2,O.BW      ;CHECK WORD MODE
3980 077474 001036          BNE      0.ERR1    ;ERROR IF NOT CORRECT MODE
3981 077476 012700 000040          MOV      #' ,RO    ;TYPE ONE BLANK
3982 077502 004537 100730          JSR      5,O.FTYP  ; AS A SEPARATOR
3983 077506 005703          TST      R3       ;WAS SEMI-COLON TYPED?
3984 077510 001430          BEQ      0.ERR1    ;NO, CALL IT AN ERROR
3985 077512 163705 075560          SUB      0,CAD,R5 ;COMPUTE
3986 077516 005305          DEC      R5
3987 077520 005305          DEC      R5      ; 16 BIT OFFSET
3988 077522 010500          MOV      R5,RO
3989 077524 004537 100634          JSR      5,O.CADV ;NUMBER IN RO - WORD MODE
3990 077530 010500          MOV      R5,RO
3991 077532 006200          ASR      RO      ;DIVIDE BY TWO
3992 077534 103414          BCS      1$      ;ERROR IF ODD
3993 077536 022700 177600          CMP      #-200,RO ;COMPARE WITH -200
3994 077542 003011          BGT      1$      ;DO NOT TYPE IF OUT OF RANGE
3995 077544 022700 000177          CMP      #177,RO ;COMPARE WITH +177
3996 077550 002406          BLT      1$      ;DO NOT TYPE IF OUT OF RANGE
3997 077552 005337 075566          DEC      0.BW    ;SET TEMPORARY BYTE MODE
3998 077556 004537 100634          JSR      5,O.CADV ;NUMBER IN RO - BYTE MODE
3999 077562 005237 075566          INC      0.BW    ;RESTORE WORD MODE
4000 077566 000137 076530          1$:      JMP      0.DCD3 ;ALL DONE
4001
4002 077572 000137 076510          0.ERR1: JMP      0.ERR  ;INTERMEDIATE HELP
  
```



```

4005          : PROCESS G - GO
4006
4007 077576 105737 07560* 0.GO: TSTB 0.SMFD ;WAS "" TYPED?
4008 077602 001773 BEQ 0.ERR1 ;BR IF NOT TYPED
4009 077604 005703 TST R3 ;WAS K: TYPED?
4010 077606 001771 BEQ 0.ERR1 ; TYPE ?<CR,LF> IF NOT
4011 077610 112737 000021 075573 MOV#B #0.BKP+3,0.P ;CLEAR PROCEED
4012 077616 006205 ASR R5 ;CHECK LOW ORDER BIT
4013 077620 103764 BCS 0.ERR1 ;ERROR IF ODD NUMBER
4014 077622 006305 ASL R5 ;RESTORE WORD
4015 077624 010537 075700 0.GOGO: MOV R5,0.UPC ;SET UP NEW PC
4016 077630 012746 000340 MOV #0.STM,-(SP) ;SET HIGH PRIORITY
4017 077634 004737 101202 JSR PC,0.WST
4018 077640 004537 100534 JSR S,0.RSTT ;RESTORE TELETYPE
4019 077644 105037 075572 0.TBIT: CLRB 0.T ;CLEAR
4020 077650 052737 000020 075702 BIS #0.TBT,0.UST ; BOTH T-BIT FLAGS
4021 077656 105737 075571 TSTB 0.S ;SEE IF WE NEED A T BIT
4022 077662 001005 BNE 0.G02 ;IF NOT GO NOW
4023 077664 042737 000020 075702 BIC #0.TBT,0.UST ;CLEAR THE T BIT
4024 077672 004537 100450 JSR S,0.RSB ;RESTORE BREAKPOINTS
4025 077676 004037 100416 0.G02: JSR 0,0.RSR ;RESTORE REGISTERS
4026 077702 013746 075702 MOV 0.UST,-(SP) ; AND STATUS
4027 077706 013746 075700 MOV 0.UPC,-(SP) ; AND PC
4028 077712 000240 NOP ; CHANGE TO HALT FOR DEBUGGING
4029 077714 013746 075702 MOV 0.UST,-(SP) ; MOV IN STATUS FIRST W/O T Bit
4030 077720 042716 177420 BIC #0.TBT:177400,(SP); SO INTERRUPTS CAN HAPPEN BEFORE
4031 077724 004737 101202 JSR PC,0.WST ; RTT TURNS ON THE T BIT.
4032 077730 000006 RTT

```

```

4035                                     ; PROCESS P - PROCEED
4036                                     ; ONLY ALLOWED AFTER A BREAKPOINT
4037
4038 077732 105737 075601      O.PROC: TSTB      O.SMFD      ; WAS '''' TYPED?
4039 077736 001715              BEQ          O.ERR1      ; BR IF NOT TYPED
4040 077740 113700 075573      MOVB         O.P,RO
4041 077744 105700              TSTB         RO          ; CHECK LEGALITY OF PROCEED
4042 077746 002711              BLT          O.ERR1      ; NOT LEGAL
4043 077750 005702              TST          R2          ; CHECK FOR ILLEGAL COUNT
4044 077752 001307              BNE          O.ERR1      ; JUMP IF ILLEGAL
4045 077754 005703              TST          R3          ; WAS COUNT SPECIFIED?
4046 077756 001402              BEQ          O.PR1      ; NO
4047 077760 010560 075730      MOV          R5,O,CT(RO) ; YES, PUT AWAY COUNT
4048 077764 012746 000340      O.PR1: MOV     #O,STM,-(SP) ; FORCE HIGH PRIORITY
4049 077770 004737 101202      JSR         PC,O,WST
4050 077774 004537 100534      JSR         S,O,RSTT    ; RESTORE TTY
4051 100000 123727 075573 000016 O.C1: CMPB     O,P,#O,BKP    ; SEE IF A REAL ONE OR A FAKE
4052 100006 003316              BGT          O.TBIT     ; BRANCH IF FAKE
4053 100010 105737 075571      TSTB         O,S        ; SEE IF SINGLE INSTRUCTION MODE
4054 100014 001313              BNE          O.TBIT     ; IF SO EXIT NOW
4055 100016 012746 000340      MOV          #O,STM,-(SP) ; SET HIGH PRIORITY
4056 100022 004737 101202      JSR         PC,O,WST
4057 100026 105237 075572      INCB         O,T        ; SET T-BIT FLAG
4058 100032 052737 000020 075702 BIS          #O,TBIT,O,UST ; SET T-BIT
4059 100040 000716              BR           O,G02
    
```

```

4062          : BREAKPOINT HANDLER
4063 100042 012637 075700 0.BRK: MOV (SP)+,0.UPC :PRIORITY IS 7 UPON ENTRY
4064 100046 012637 075702      MOV (SP)+,0.UST :SAVE STATUS AND PC
4065 100052 112737 000021 075573 MOV#B #0.BKP+3,0.P :TELL :P THAT WE CAN CONTINUE
4066 100060 004037 100360 0.BK1: JSR 0,0.SVR :SAVE VARIOUS REGISTERS
4067 100064 105737 075572      TSTB 0,T :CHECK FOR T-BIT SET
4068 100070 001265      BNE 0,TBIT :JUMP IF SET
4069 100072 004537 100602      JSR 5,0.REM :REMOVE BREAKPOINTS
4070 100076 105737 075704      TSTB 0,PRI :CHECK IF PRIORITY
4071 100102 100003      BPL 2$ : IS AS SAME AS USER PGM
4072 100104 113705 075702      MOV#B 0,UST,R5 :PICK UP USER UST IF SO
4073 100110 000407      BR 3$
4074 100112 113705 075704 2$: MOV#B 0,PRI,R5 :OTHERWISE PICK UP ACTUAL PRIORITY
4075 100116 000257      CCC :CLEAR CARRY
4076 100120 106005      RORB R5 :SHIFT LOW ORDER BITS
4077 100122 106005      RORB R5 : INTO
4078 100124 106005      RORB R5 : HIGH ORDER
4079 100126 106005      RORB R5 : POSITION
4080 100130 042705 177420 3$: BIC #0.TBT,177400,R5 :CLEAR POSSIBLE T BIT (S/I MODE)
4081 100134 010546      MOV R5,-(SP) :PUT THE STATUS AWAY WHERE IT BELONGS
4082 100136 004737 101202      JSR PC,0,WST
4083 100142 013705 075700      MOV 0,UPC,R5 :GET PC, IT POINTS TO THE TRT
4084 100146 105737 075571      TSTB 0,S :SEE IF IT WAS SINGLE INSTRUCTION FUN
4085 100152 100432      BMI 14$ :IF SO HANDLE THERE
4086 100154 005745      TST -(R5)
4087 100156 010537 075700      MOV R5,0,UPC
4088 100162 012704 000016      MOV #0.BKP,R4 :GET A COUNTER
4089 100166 020564 075706 11$: CMP R5,0,ADR1(R4) :COMPARE WITH LIST
4090 100172 001426      BEQ 12$ :JUMP IF FOUND
4091 100174 005304      DEC R4
4092 100176 005304      DEC R4
4093 100200 002372      BGE 11$ :RE-LOOP UNTIL FOUND
4094 100202 004537 100500      JSR 5,0.SVTF :SAVE TELETYPE STATUS
4095 100206 004537 101246      JSR 5,0.CRLF
4096 100212 012704 101366      MOV #0.BD,R4 :ERROR, NOTHING FOUND
4097 100216 012703 101367      MOV #0.BD+1,R3
4098 100222 004537 101126      JSR 5,0.TYPE :OUTPUT 'BE' FOR BAD ENTR+
4099 100226 010500      MOV R5,R0
4100 100230 062737 000002 075700      ADD #2,0,UPC :POP OVER THE ADJUSTMENT ABOVE
4101 100236 000444      BR 13$ : OR CONTINUE

```

EMK (EMKA) DATA AREA

4104	100240	112704	000020		148:	MOVB	#0,BKP+2,R4	:	SET BREAK POINT HIGH + 1
4105	100244	010564	075706			MOV	R5,O.ADR1(R4)	:	STORE NEXT PC VALUE FOR TYPE OUT
4106	100250	110437	075573		128:	MOVB	R4,O.P	:	ALLOW PROCEED
4107	100254	005364	075730			DEC	O.CT(R4)		
4108	100260	003247				BGT	O.C1	:	JUMP IF REPEAT
4109	100262	012764	000001	075730		MOV	#1,O.CT(R4)	:	RESET COUNT TO 1
4110	100270	004537	100500			JSR	S,O.SVTT	:	SAVE TELETYPE STATUS, R4 IS SAFE
4111	100274	012700	000102			MOV	#'B',R0		
4112	100300	004537	100730			JSR	S,O.FTYP	:	TYPE 'B'
4113	100304	113700	075573			MOVB	O.P,R0	:	CONVERT BREAKPOINT NUMBER TO ASCII
4114	100310	062700	000140			ADD	#140,R0		
4115	100314	006200				ASR	R0		
4116	100316	004537	100730			JSR	S,O.FTYP		
4117	100322	012700	000073			MOV	#1,R0		
4118	100326	004537	100730			JSR	S,O.FTYP	:	TYPE
4119	100332	012737	000002	075566		MOV	#2,O.BW	:	SET WORD MODE
4120	100340	113704	075573			MOVB	O.P,R4		
4121	100344	016400	075706			MOV	O.ADR1(R4),R0	:	GET ADDRESS OF BREAK
4122	100350	004537	101272		138:	JSR	S,O.RORA	:	CHECK FORMAT
4123	100354	000137	076520			JMP	O.DCD	:	GO TO DECODER

```

4126 ; SAVE REGISTERS R0-R6
4127 ; INTERNAL STACK
4128
4129 100360 012637 075564 C.SVR: MOV (SP)+,0,XXX :PICK REGISTER FROM STACK AND SAVE
4130 100364 010637 075676 MOV SP,0,USP :SAVE USER STACK ADDRESS
4131 100370 012706 075676 MOV #0,USP,SP :SET TO INTERNAL STACK
4132 100374 010546 MOV R5,-(SP) :SAVE
4133 100376 010446 MOV R4,-(SP) :REGISTERS
4134 100400 010346 MOV R3,-(SP) :1
4135 100402 010246 MOV R2,-(SP) :THRU
4136 100404 010146 MOV R1,-(SP) :5
4137 100406 013746 075564 MOV 0,XXX,-(SP) :PUT SAVED REGISTER ON STACK
4138 100412 005746 TST -(SP)
4139 100414 000200 RTS R0
4140
4141 ; RESTORE REGISTERS R0-R6
4142
4143 100416 005726 O.RSR: TST (SP)+
4144 100420 012637 075564 MOV (SP)+,0,XXX :POP THE EXTRA CELL
4145 100424 012601 MOV (SP)+,R1 :GET R0 FROM STACK
4146 100426 012602 MOV (SP)+,R2 :RESTORE
4147 100430 012603 MOV (SP)+,R3 :REGISTERS
4148 100432 012604 MOV (SP)+,R4 :1
4149 100434 012605 MOV (SP)+,R5 :THRU
4150 100436 013706 075676 MOV 0,USP,SP :5
4151 100442 013746 075564 MOV 0,XXX,-(SP) :RESTORE USER STACK
4152 100446 000200 RTS R0 :PUT R0 ON USER STACK
    
```

```

: RESTORE BREAKPOINTS 0-7
4157 100450 012704 000016 075752 075706 075752 075706 0.RSB: MOV #0.BKP,R4 :RESTORE ALL BREAKPOINTS
4158 100454 017464 075706 075752 1$: MOV @0.ADR1(R4),0.UIN(R4);SAVE CONTENTS
4159 100462 013774 101370 075706 MOV 0.TRT(@0.ADR1(R4));REPLACE WITH TRAP
4160 100470 005304 DEC R4
4161 100472 005304 DEC R4
4162 100474 002367 BGE 1$ :RE-LOOP UNTIL DONE
4163 100476 000205 RTS R5 : THEN QUIT
4164
4165 : SAVE TELETYPE STATUS
4166
4167 100500 113737 177560 075574 0.SVTT: MOVB 0.RCSR,0.CSR1 :SAVE R C/SR
4168 100506 113737 177564 075575 MOVB 0.TCSR,0.CSR2 :SAVE T C/SR
4169 100514 105037 177560 CLRB 0.RCSR :CLEAR ENABLE AND MAINTENANCE
4170 100520 105037 177564 CLRB 0.TCSR : BITS IN BOTH C/SR
4171 100524 105737 177564 1$: TSTB 0.TCSR :LOOP UNTIL READY BIT COMES ON
4172 100530 100375 BPL 1$ :BR IF BIT NOT ON
4173 100532 000205 RTS R5
4174
4175 : RESTORE TELETYPE STATUS
4176 100534 004537 101246 0.RSTT: JSR 5,0.CRLF
4177 100540 105737 177564 TSTB 0.TCSR :WAIT READY
4178 100544 100375 BPL -4 : ON PRINTER
4179 100546 032737 004000 177560 BIT #4000,0.RCSR :CHECK BUSY FLAG
4180 100554 001403 BEQ 1$ :SKIP READY LOOP IF NOT BUSY
4181 100556 105737 177560 TSTB 0.RCSR :WAIT READY
4182 100562 100375 BPL -4 : ON READER
4183 100564 113737 075574 177560 1$: MOVB 0.CSR1,0.RCSR :RESTORE
4184 100572 113737 075575 177564 MOVB 0.CSR2,0.TCSR : THE STATUS REGISTERS
4185 100600 000205 RTS R5
4186
4187 : REMOVE BREAKPOINTS 0-7
4188 : IN THE OPPOSITE ORDER OF SETTING
4189
4190 100602 105737 075571 0.REM: TSTB 0.S :SEE IF SINGLE INSTRUCTION IS GOING
4191 100606 001011 BNE 2$ :EXIT IF SO
4192 100610 005004 CLR R4 :REMOVE ALL BREAKPOINTS
4193 100612 016474 075752 075706 1$: MOV 0.UIN(R4),@0.ADR1(R4) :CLEAR BREAKPOINT
4194 100620 005204 INC R4
4195 100622 005204 INC R4
4196 100624 020427 000016 CMP R4,#0.BKP
4197 100630 003770 BLE 1$ :RE-LOOP UNTIL DONE
4198 100632 000205 2$. RTS R5 :THEN QUIT

```

```

4201 : TYPE OUT CONTENTS OF WORD OR BYTE WITH ONE TRAILING SPACE
4202 : WORD IS IN R0
4203
4204 100634 012703 000006 0.CADV: MOV #6,R3 :# OF DIGITS
4205 100640 012704 177776 MOV #-2,R4 :# OF BITS FIRST-3
4206 100644 022737 000001 075566 CMP #1,0,BW :SEE IF WORD MODE
4207 100652 001004 BNE 3$ :BRANCH IF SO
4208 100654 162703 000003 SUB #3,R3 :ONLY DO 3 DIGITS
4209 100660 005204 INC R4 :DO 2 BITS FIRST
4210 100662 000300 SWAB R0 :AND TURN R0 AROUND
4211 100664 010046 3$: MOV R0,-(SP) :SAVE R0
4212 100666 062704 000003 2$: ADD #3,R4 :COMPUTE THE NUMBER OF BITS TO DO
4213 100672 005000 CLR R0
4214 100674 006116 1$: ROL (SP) :GET A BIT
4215 100676 006100 ROL R0 :STORE IT AWAY
4216 100700 005304 DEC R4 :DECREMENT COUNTER
4217 100702 003374 BGT 1$ :LOOP IF MORE BITS NEEDED
4218 100704 062700 000060 ADD #'0,R0 :CONVERT TO ASCII
4219 100710 004537 100730 JSR R5,0,FTYP :TYPE IT
4220 100714 005303 DEC R3 :SEE IF MORE DIGITS TO DO
4221 100716 003363 BGT 2$ :LOOP IF SO
4222 100720 112700 000040 MOVB #' ,R0 :SET UP FOR TRAILING SPACE
4223 100724 005726 TST (SP)+ :GET RID OF JUNK
4224 100726 000400 BR 0,FTYP
4225
4226
4227 : TYPE ONLY ONE CHARACTER (CONTAINED IN R0)
4228
4229 100730 105737 177564 0,FTYP: TSTB 0,TCSR
4230 100734 100375 BPL 0,FTYP
4231 100736 042700 177400 BIC #177400,R0 :CLEAR HIGH BYTE, SHOULD NOT
:CONTAIN INPORTANT INFO.
4232
4233 100742 001416 BEQ 3$
4234 100744 022700 000176 CMP #176,R0 :PRINT ? FOR 177:16-37
4235 100750 103411 BLO 2$ : 1-10 AND 200-377.
4236 100752 022700 000037 CMP #37,R0
4237 100756 103410 BLO 3$
4238 100760 022700 000015 CMP #15,R0
4239 100764 103403 BLO 2$
4240 100766 022700 000010 CMP #10,R0
4241 100772 103402 BLO 3$
4242 100774 012700 000077 2$: MOV #'?,R0
4243 101000 110037 177566 3$: MOVB R0,0,IDB
4244 101004 000205 0,TYPE1: RTS R5
    
```

```

4247                                     ; GENERAL CHARACTER INPUT ROUTINE -- ODT'1x
4248                                     ; CHARACTER INPUT GOES TO RO
4249
4250 101006 105737 177560 0.GET:  TSTB  0.RCSR           ;WAIT FOR
4251 101012 100375          BPL  0.GET           ; INPUT FROM KBD
4252 101014 113700 177562  MOVB  0.RDB,RO      ;GET CHARACTER - STRIP OFF PARITY
4253 101020 042700 177600  BIC  #177600,RO    ;STRIP OFF PARITY FROM CHARACTER
4254 101024 122700 000003  CMPB  #3,RO        ;IS IT ^C?
4255 101030 001435          BEQ  3$              ;IF SO, DO NOT ECHO
4256 101032 122700 000006  CMPB  #6,RO        ;IS IT ^F?
4257 101036 001432          BEQ  3$              ;IF SO, DO NOT ECHO
4258 101040 122700 000005  CMPB  #5,RO        ;IS IT ^E?
4259 101044 001427          BEQ  3$              ;IF SO, DO NOT ECHO
4260 101046 105737 075602  TSTB  0.SCRN      ;SHOULD WE ECHO <LF>?
4261 101052 001003          BNE  2$              ;BR IF YES
4262 101054 120027 000012  CMPB  RO,#012     ;SEE IF A <LF>
4263 101060 001421          BEQ  3$              ;IF SO SAVE THE PAPER
4264 101062 120027 000173 2$:  CMPB  RO,#173
4265 101066 002005          BGE  1$              ;TEST FOR LOWER CASE
4266 101070 122700 000140  CMPB  #140,RO
4267 101074 002002          BGE  1$
4268 101076 162700 000040  SUB  #40,RO       ;CHAR IS LC-CONVERT TO UPPER CASE
4269 101102 004537 100730 1$:  JSR  5,O.FTYP   ;ECHO CHARACTER
4270 101106 001737          BEQ  0.GET         ;IGNORE NULLS
4271 101110 105737 075602  TSTB  0.SCRN      ;SHOULD WE PASS ON SPACES?
4272 101114 001003          BNE  3$              ;BR IF YES
4273 101116 122700 000040  CMPB  #40,RO     ;CHECK FOR SPACES
4274 101122 001731          BEQ  0.GET         ;IGNORE SPACES
4275 101124 000205          3$:  RTS  R5
    
```



```

4278          : GENERAL CHARACTER OUTPUT ROUTINE - ODT11X
4279          : ADDRESS OF FIRST BYTE IN R4,
4280          : ADDRESS OF LAST BYTE IN R3, (R3)>(R4)
4281          : EXPECTS LOCS 56,57 TO BE INITIALIZED BY MONITOR FOR FILL
4282          : CHARACTERISTICS OF TERMINAL
4283          : 56=CHAR TO BE FILLED AFTER
4284          : 57=# OF NULLS TO FILL WITH
4285
4286 101126 020304      O.TYPE: CMP      R3,R4          :CHECK FOR COMPLETION
4287 101130 103725      BLO      0.TYP1         : EXIT WHEN DONE
4288 101132 112400      MOVSB   (R4)+,R0       :GET A CHARACTER
4289 101134 004537 100730 JSR      5,O.FTYP        :TYPE ONE CHARACTER
4290 101140 120037 003002 CMPSB   R0,@%SFILLC     :COMPARE CHAR AGAINST FILL REQUIREMENT
4291 101144 001370      BNE      0.TYPE          :NO FILL NEEDED
4292 101146 113737 002451 075576 MOVSB   @%SFILLS,O.FIL  :FILL COUNT INTO TEMP
4293 101154 005000      CLR      R0              :FILL WITH NULLS
4294 101156 004537 100730 2$: JSR      R5,O.FTYP        :TYPE NULLS
4295 101162 105337 075576 DECB   0.FIL           :DECREASE COUNT
4296 101166 003373      BGT     2$              :BRANCH IF NOT DONE
4297 101170 000756      BR      0.TYPE          :LOOP UNTIL DONE
  
```

```

4300 ;SUBROUTINE TO READ THE PS INDEPENDENT OF MACHINE
4301
4302 101172 013737 177776 075702 0.RRST: MOV ST,0.UST ;STORE THE STATUS IN USER
4303 ;STATUS AREA.FOR AN LSI
4304 ;THIS IS CHANGED TO
4305 ;MFPS 0.UST
4306 101200 000207 RTS PC
4307
4308 ;SUBROUTINE TO WRITE PS INDEPENDENT OF MACHINE
4309 ;CALL ROUTINE WITH PS VALUE
4310 ;ON THE STACK
4311
4312 101202 016637 000002 177776 0.WS*: MOV 2(SP),ST ;STORE NEW PS VALUE
4313 ;THIS INSTRUCTION IS CHANGED FOR LSI
4314 ;TO MTPS 2(SP)
4315 101210 012616 MOV (SP)+,(SP) ;PUT RETURN PC OVER SUB. ARGUMENT
4316 101212 000207 RTS PC ;TO RETURN WITHOUT IT ON THE STACK
4317 ; CLOSE WORD OR BYTE AND EXIT,
4318 ; UPON ENTERING, R2 HAS NUMERIC FLAG, R4 HAS CONTENTS
4319
4320 .ENABL LSB
4321 101214 005702 0.CLSE: TST R2 ;IF NO NUMBER WAS TYPED THERE IS
4322 101216 001412 BEQ 1$ ;NO CHANGE TO THE OPEN CELL
4323 101220 022737 000001 075566 CMP #1,0.BW
4324 101226 001404 BEQ 2$ ;JUMP IF BYTE MODE
4325 101230 101005 BHI 1$ ;JUMP IF ALREADY CLOSED
4326 101232 010477 174322 MOV R4,@0.CAD ;STORE WORD
4327 101236 000402 BR 1$
4328 101240 110477 174314 2$: MOVB R4,@0.CAD ;STORE BYTE
4329 101244 000207 1$: RTS PC
4330 101246 012703 101317 0.CRLF: MOV #0.CR+1,R3 ;LWA <CR,LF>
4331 101252 000402 BR 3$
4332 101254 012703 101320 0.CRLS: MOV #0.CR+2,R3 ;LWA <CR,LF>*
4333 101260 012704 101316 3$: MOV #0.CR,R4 ;FWA
4334 101264 004537 101126 JSR 5,0.TYPE ;TYPE SOMETHING
4335 101270 000205 RTS R5
4336 .DSABL LSB
    
```

```

4339          :SUBROUTINE O.RORA
4340          :FUNCTION:
4341          :ADDRESS WILL BE PRINTED IN ABSOLUTE FORM
4342          :INPUT: THE ADDRESS TO BE PRINTED IS IN RO.
4343          :DATA SAVED: RO CONTAINING THE ADDRESS TO BE
4344          :PRINTED, AND LOCATION O.CAD CONTAINING
4345          :THE CURRENT ADDRESS WERE SAVED AND RESTORED.
4346          :CALLED: JSR 5,O.RORA
4347
4348 101272 004537 100634 O.RORA: JSR 5,O.CADV ;PRINT ABSOLUTE ADDRESS
4349 101276 000205      RTS R5
4350 101300      012 O.ID: .BYTE 012
4351 101301      015      .BYTE 015
4352 101302      040      .BYTE 40
4353 101303      117      .ASCII /ODT (CEMKA)/
4354 101306      040      104      124
4355 101311      105      050      103
4356 101314      101      115      113
4357 101314      051
4358
4359 101315 O.IDND -1
4360 101316 015 O.CR: .BYTE 015 ; <CR>
4361 101317 012 .BYTE 012 ; <LF>
4362 101320 052 .BYTE '*' ; *
4363
4364 101321 073 O.LGCH: .BYTE ':' ;
4365 101322 057 .BYTE '/' ; /
4366 101323 134 .BYTE '\ ' ; \ (BACK SLASH)
4367 101324 015 .BYTE 015 ; CARRIAGE RETURN
4368 101325 044 .BYTE '$' ; $
4369 101326 107 .BYTE 'G' ; G
4370 101327 012 .BYTE 012 ; <LF>
4371 101330 137 .BYTE ' ' ; (BACK ARROW)
4372 101331 074 .BYTE '<' ; <
4373 101332 136 .BYTE '^' ; ^ (UP ARROW)
4374 101333 117 .BYTE 'O' ; O
4375 101334 102 .BYTE 'B' ; B
4376 101335 120 .BYTE 'P' ; P
4377 101336 100 .BYTE '@' ; @
4378 101337 076 .BYTE '>' ; >
4379 101340 123 .BYTE 'S' ; S
4380 101341 055 .BYTE '-' ; -
4381 101342 003 .BYTE 003 ; CTRL C
4382 101343 006 .BYTE 006 ; CTRL F
4383 101344 005 .BYTE 005 ; CTRL E
4384 000024 O.CLGT = -O.LGCH ;TABLE LENGTH
4385
4386 101345 123 O.TL: .BYTE 'S' ;DO 1
4387 101346 120 .BYTE 'P' ;NOT 2
4388 101347 115 .BYTE 'M' ;CHANGE 3
4389 101350 000 .BYTE 0 ;THE 4
4390 101351 000 .BYTE 0 ;ORDER 5
4391 101352 103 .BYTE 'C' ; 6
4392 101353 106 .BYTE 'F' ; 7
4393 101354 122 .BYTE 'R' ; 10
4394 101355 000 .BYTE 0 ; 11
4395 101356 000 .BYTE 0 ; 12
4396 101357 000 .BYTE 0 ; 13
4397 101360 000 .BYTE 0 ; 14
    
```

4393 101361 000
4394 101362 000
4395 101363 000
4396 101364 102
4397 000020
4398
4399 101366 042502
4400 101370 0000C3

.BYTE 0 : 15
.BYTE 0 : 16
.BYTE 0 : 17
.BYTE 'B : 20
O.LG = -.O.TL
O.BD: .EVEN
O.TRTC: .WORD 'BE
O.TRTC: TRT

:TRACE TRAP PROTOTYPE

TABLE ERROR POINTER

.SBTTL TABLE ERROR POINTER

4403
 4404
 4405
 4406
 4407
 4408
 4409
 4410
 4411
 4412
 4413
 4414
 4415
 4416
 4417 101372
 4418 101372 104530
 4419 101374 110307
 4420 101376 102504
 4421 101400 103103
 4422
 4423 101402 103220
 4424 101404 107366
 4425 101406 102252
 4426 101410 102743
 4427
 4428 101412 103256
 4429 101414 107446
 4430 101416 102302
 4431 101420 103071
 4432
 4433 101422 103311
 4434 101424 107446
 4435 101426 102312
 4436 101430 103071
 4437
 4438 101432 103357
 4439 101434 107507
 4440 101436 102322
 4441 101440 102743
 4442
 4443 101442 103434
 4444 101444 107507
 4445 101446 102322
 4446 101450 102743
 4447
 4448 101452 103461
 4449 101454 107507
 4450 101456 102322
 4451 101460 102743
 4452
 4453 101462 103633
 4454 101464 107366
 4455 101466 102252
 4456 101470 102743

*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 *THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 *LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 *NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (ERRPC).
 *NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS.

* EM ::POINTS TO THE ERROR MESSAGE
 * DH ::POINTS TO THE DATA HEADER
 * DT ::POINTS TO THE DATA
 * DF ::POINTS TO THE DATA FORMAT

\$ERRTB: :ERROR 1
 EM24
 DH13
 DT13
 DF11
 :ERROR 2
 EM2
 DH1
 DT1
 DF2
 :ERROR 3
 EM3
 DH3
 DT3
 DF9
 :ERROR 4
 EM4
 DH3
 DT4
 DF9
 :ERROR 5
 EM5
 DH5
 DT5
 DF2
 :ERROR 6
 EM6
 DH5
 DT5
 DF2
 :ERROR 7
 EM7
 DH5
 DT5
 DF2
 :ERROR 10
 EM10
 DH1
 DT1
 DF2

4459			:ERROR	11
4460	101472	103677	EM11	
4461	101474	107664	DH7	
4462	101476	102362	DT7	
4463	101500	102767	DF3	
4464			:ERROR	12
4465	101502	103677	EM11	
4466	101504	107664	DH7	
4467	101506	102362	DT7	
4468	101510	103004	DF4	
4469			:ERROR	13
4470	101512	103721	EM12	
4471	101514	110145	DH10	
4472	101516	102444	DT10	
4473	101520	102743	DF2	
4474			:ERROR	14
4475	101522	103677	EM11	
4476	101524	107664	DH7	
4477	101526	102362	DT7	
4478	101530	103021	DF5	
4479			:ERROR	15
4480	101532	103677	EM11	
4481	101534	107664	DH7	
4482	101536	102362	DT7	
4483	101540	103036	DF6	
4484			:ERROR	16
4485	101542	103745	EM13	
4486	101544	110307	DH13	
4487	101546	102504	DT13	
4488	101550	103103	DF11	
4489			:ERROR	17
4490	101552	103777	EM14	
4491	101554	110307	DH13	
4492	101556	102504	DT13	
4493	101560	103103	DF11	
4494			:ERROR	20
4495	101562	104043	EM15	
4496	101564	110307	DH13	
4497	101566	102504	DT13	
4498	101570	103103	DF11	
4499			:ERROR	21
4500	101572	104111	EM16	
4501	101574	110243	DH11	
4502	101576	102466	DT11	
4503	101600	102743	DF2	
4504			:ERROR	22
4505	101602	104137	EM17	
4506	101604	107664	DH7	
4507	101606	102362	DT7	
4508	101610	103021	DF5	
4509			:ERROR	23
4510	101612	104177	EM18	
4511	101614	110006	DH8	
4512	101616	102416	DT8	
4513	101620	103076	DF10	

TABLE		ERROR POINTER	
4516			:ERROR 24
4517	101622	104256	EM19
4518	101624	110307	DH13
4519	101626	102504	DT13
4520	101630	103103	DF11
4521			:ERROR 25
4522	101632	104333	EM20
4523	101634	110307	DH13
4524	101636	102504	DT13
4525	101640	103103	DF11
4526			:ERROR 26
4527	101642	000000	0 ;NO MESSAGE
4528	101644	110272	DH12
4529	101646	102476	DT12
4530	101650	102743	DF2
4531			:ERROR 27
4532	101652	104415	EM21
4533	101654	110243	DH11
4534	101656	102466	DT11
4535	101660	102743	DF2
4536			:ERROR 30
4537	101662	104454	EM22
4538	101664	110307	DH13
4539	101666	102504	DT13
4540	101670	103103	DF11
4541			:ERROR 31
4542	101672	000000	0 ;NO MESSAGE
4543	101674	110415	DH14
4544	101676	102530	DT14
4545	101700	102743	DF2
4546			:ERROR 32
4547	101702	104501	EM23
4548	101704	107507	DH5
4549	101706	102322	DT5
4550	101710	102743	DF2
4551			:ERROR 33
4552	101712	106025	EM38
4553	101714	110672	DH17
4554	101716	102264	DT2
4555	101720	103116	DF13
4556			:ERROR 34
4557	101722	104607	EM25
4558	101724	110533	DH15
4559	101726	102556	DT16
4560	101730	103053	DF7
4561			:ERROR 35
4562	101732	104634	EM26
4563	101734	110655	DH16
4564	101736	102610	DT17
4565	101740	102767	DF3
4566			:ERROR 36
4567	101742	103521	EM8
4568	101744	110672	DH17
4569	101746	102616	DT18
4570	101750	103116	DF13

TABLE ERROR POINTER

4573			:ERROR	37
4574	101752	103556	EM9	
4575	101754	110106	DH9	
4576	101756	102432	DT9	
4577	101760	102743	DF2	
4578			:ERROR	40
4579	101762	104705	EM27	
4580	101764	110655	DH16	
4581	101766	102610	DT7	
4582	101770	103067	DF8	
4583			:ERROR	41
4584	101772	104774	EM28	
4585	101774	110672	DH17	
4586	101776	102634	DT19	
4587	102000	103116	DF13	
4588			:ERROR	42
4589	102002	105624	EM35	
4590	102004	107664	DH7	
4591	102006	102362	DT7	
4592	102010	102767	DF3	
4593			:ERROR	43
4594	102012	105027	EM29	
4595	102014	107664	DH7	
4596	102016	102362	DT7	
4597	102020	102767	DF3	
4598			:ERROR	44
4599	102022	105111	EM30	
4600	102024	107664	DH7	
4601	102026	102362	DT7	
4602	102030	103021	DF5	
4603			:ERROR	45
4604	102032	105230	EM31	
4605	102034	107664	DH7	
4606	102036	102362	DT7	
4607	102040	102767	DF3	
4608			:ERROR	46
4609	102042	105330	EM32	
4610	102044	107664	DH7	
4611	102046	102362	DT7	
4612	102050	102767	DF3	
4613			:ERROR	47
4614	102052	105435	EM33	
4615	102054	107664	DH7	
4616	102056	102362	DT7	
4617	102060	102767	DF3	
4618			:ERROR	50
4619	102062	105543	EM34	
4620	102064	111023	DH19	
4621	102066	102700	DT22	
4622	102070	103114	DF12	
4623			:ERROR	51
4624	102072	105711	EM36	
4625	102074	107615	DH6	
4626	102076	102346	DT6	
4627	102100	102743	DF2	

4630			:ERROR	52
4631	102102	105750	EM37	
4632	102104	110672	DH17	
4633	102106	102616	DT18	
4634	102110	103116	DF13	
4635			:ERROR	53
4636	102112	106133	EM39	
4637	102114	110672	DH17	
4638	102116	102616	DT18	
4639	102120	103116	DF13	
4640			:ERROR	54
4641	102122	106220	EM40	
4642	102124	107423	DH2	
4643	102126	102652	DT20	
4644	102130	107743	DF2	
4645			:ERROR	55
4646	102132	106272	EM41	
4647	102134	110746	DH18	
4648	102136	102662	DT21	
4649	102140	103103	DF11	
4650			:ERROR	56
4651	102142	106374	EM42	
4652	102144	110746	DH18	
4653	102146	102662	DT21	
4654	102150	103103	DF11	
4655			:ERROR	57
4656	102152	103134	EM1	
4657	102154	000000	0	
4658	102156	000000	0	
4659	102160	000000	0	
4660			:ERROR	60
4661	102162	106477	EM43	
4662	102164	111037	DH20	
4663	102166	102706	DT23	
4664	102170	102743	DF2	
4665			:ERROR	61
4666	102172	106575	EM44	
4667	102174	111056	DH21	
4668	102176	102714	DT24	
4669	102200	102743	DF2	
4670			:ERROR	62
4671	102202	106672	EM45	
4672	102204	111037	DH20	
4673	102206	102706	DT23	
4674	102210	102743	DF2	
4675			:ERROR	63
4676	102212	106773	EM46	
4677	102214	110672	DH17	
4678	102216	102264	DT2	
4679	102220	103116	DF13	
4680			:ERROR	64
4681	102222	107062	EM47	
4682	102224	110655	DH16	
4683	102226	102610	DT17	
4684	102230	102767	DF3	

TABLE ERROR POINTER

4687			:ERROR	65
4688	102232	107170	EM48	
4689	102234	111063	DM22	
4690	102236	102652	DT20	
4691	102240	102743	DF2	
4692			:ERROR	66
4693	102242	107267	EM49	
4694	102244	111111	DM23	
4695	102246	102720	DT25	
4696	102250	103125	DF14	

ERROR DATA TAG (DT)

4699						.SBTTL	ERROR DATA TAGS (DT)
4700	102252	002024	002040	002050	DT1:	.WORD	ERRPC,ADDRESS,GOOD,BAD,0
	102260	002056	000000				
4701	102264	002024	002304	002656	DT2:	.WORD	ERRPC,DUMMY,SLFLAG,SLFLAG+2,SLFLAG+4,SLFLAG+6,0
	102272	002660	002662	002664			
	102300	000000					
4702	102302	002024	002042	002074	DT3:	.WORD	ERRPC,PADDRESS,PARCNT,0
	102310	000000					
4703	102312	002024	002040	002072	DT4:	.WORD	ERRPC,ADDRESS,NEMCNT,0
	102320	000000					
4704	102322	002024	177766	177744	DT5:	.WORD	ERRPC,CPUERR,MEMERR,HIADRS,LOADRS,MMR0,MMR1,MMR2,MMR3,0
	102330	177742	177740	177572			
	102336	177574	177576	172516			
	102344	000000					
4705	102346	002024	002522	002466	DT6:	.WORD	ERRPC,APTCORE,MJSIZE,APTMOS,MKSIZE,0
	102354	002524	002470	000000			
4706	102362	002024	002304	002040	DT7:	.WORD	ERRPC,DUMMY,ADDRESS,DUMMY,GOOD,BAD,BADXOR
	102370	002304	002050	002056			
	102376	002064					
4707	102400	002304	002304	002304		.WORD	DUMMY,DUMMY,DUMMY,DUMMY,DUMMY,DUMMY,0
	102406	002304	002304	002304			
	102414	000000					
4708	102416	002040	002050	002056	DT8:	.WORD	ADDRESS,GOOD,BAD,GDSWITCH,BDSWITCH,0
	102424	002476	002500	000000			
4709	102432	002024	177766	177744	DT9:	.WORD	ERRPC,CPUERR,MEMERR,CSRNO,0
	102440	002256	000000				
4710	102444	002306	002310	002312	DT10:	.WORD	DETRO,DETR1,DETR2,DETR3,DETR4,DETR5,DETPSW,0
	102452	002314	002316	002320			
	102460	002322	002324	000000			
4711	102466	002024	002144	002146	DT11:	.WORD	ERRPC,CSR,CSR+2,0
	102474	000000					
4712	102476	002144	002146	000000	DT12:	.WORD	CSR,CSR+2,0
4713	102504	002024	002304	002040	DT13:	.WORD	ERRPC,DUMMY,ADDRESS,DUMMY,TSTDAT,TSTDAT+2,CHECK,CSR,CSR+2,0
	102512	002304	002344	002346			
	102520	002404	002144	002146			
	102526	000000					
4714	102530	177744	177750	177746	DT14:	.WORD	MEMERR,MAINT,CONTRL,HIADRS,LOADRS,CPUERR,MMR0,MMR1,MMR2,MMR3,0
	102536	177742	177740	177766			
	102544	177572	177574	177576			
	102552	172516	000000				
4715	102556	002024	002304	002304	DT16:	.WORD	ERRPC,DUMMY,DUMMY,GOOD,GOOD2,GOOD3
	102564	002050	002052	002054			
4716	102572	002056	002060	002062		.WORD	BAD,BAD2,BAD3,DUMMY,DUMMY,DUMMY,0
	102600	002304	002304	002304			
	102606	000000					
4717	102610	002024	002304	000000	DT17:	.WORD	ERRPC,DUMMY,0
4718	102616	002024	002304	002646	DT18:	.WORD	ERRPC,DUMMY,PORTCOUNT,PORTCOUNT+2,PORTCOUNT+4,PORTCOUNT+6,0
	102624	002650	002652	002654			
	102632	000000					
4719	102634	002024	002304	002606	DT19:	.WORD	ERRPC,DUMMY,PORTDIR,PORTDIR+2,PORTDIR+4,PORTDIR+6,0
	102642	002610	002612	002614			
	102650	000000					
4720	102652	002024	002050	002056	DT20:	.WORD	ERRPC,GOOD,BAD,0
	102660	000000					
4721	102662	002024	002304	002040	DT21:	.WORD	ERRPC,DUMMY,ADDRESS,DUMMY,GOOD,BAD,0
	102670	002304	002050	002056			
	102676	000000					

4722	102700	002024	002304	000000	DT22:	.WORD	ERRPC,DUMMY,0
4723	102706	002024	002056	000000	DT23:	.WORD	ERRPC,BAD,0
4724	102714	002024	000000		DT24:	.WORD	ERRPC,0
4725	102720	002024	002304	002646	DT25:	.WORD	ERRPC,DUMMY,PORTCOUNT,PORTCOUNT*,PORTCOUNT**,,PORTCOUNT***,HA,
	102726	002650	002652	002654			
	102734	002056	000000				

ERROR MESSAGES (EM)

	103401	104	040	111	
	103404	116	123	124	
	103407	122	125	103	
	103412	124	111	117	
	103415	116	040	050	
	103420	124	122	101	
	103423	120	040	124	
	103426	117	040	061	
	103431	060	051	000	
4757	103434	125	116	105	EM6: .ASCIZ /UNEXPECTED TRAP TO 4/
	103437	130	120	105	
	103442	103	124	105	
	103445	104	040	124	
	103450	122	101	120	
	103453	040	124	117	
	103456	040	064	000	
4758	103461	115	105	115	EM7: .ASCIZ /MEMORY MANAGEMENT (TRAP TO 250)/
	103464	117	122	131	
	103467	040	115	101	
	103472	116	101	107	
	103475	105	115	105	
	103500	116	124	040	
	103503	050	124	122	
	103506	101	120	040	
	103511	124	117	040	
	103514	062	065	060	
	103517	051	000		
4759	103521	120	117	122	EM8: .ASCIZ /PORT CONTENTION NOT BALANCED/
	103524	124	040	103	
	103527	117	116	124	
	103532	105	116	124	
	103535	111	117	116	
	103540	040	116	117	
	103543	124	040	102	
	103546	101	114	101	
	103551	116	103	105	
	103554	104	000		
4760					
4761	103556	116	117	116	EM9: .ASCIZ /NON-EXISTANT CSR CAUSED INCORRECT ERROR TRAP/
	103561	055	105	130	
	103564	111	123	124	
	103567	101	116	124	
	103572	040	103	123	
	103575	122	040	103	
	103600	101	125	123	
	103603	105	104	040	
	103606	111	116	103	
	103611	117	122	122	
	103614	105	103	124	
	103617	040	105	122	
	103622	122	117	122	
	103625	040	124	122	
	103630	101	120	000	
4762	103633	111	116	103	EM10: .ASCIZ /INCORRECT DATA FROM DEVICE REGISTER/
	103636	117	122	122	
	103641	105	103	124	
	103644	040	104	101	

	103647	124	101	040		
	103652	106	122	117		
	103655	115	040	104		
	103660	105	126	111		
	103663	103	105	040		
	103666	122	105	107		
	103671	111	123	124		
	103674	105	122	000		
4763	103677	115	105	115	EM11:	.ASCIZ /MEMORY DATA ERROR/
	103702	117	122	131		
	103705	040	104	101		
	103710	124	101	040		
	103713	105	122	122		
	103716	117	122	000		
4764	103721	104	105	124	EM12:	.ASCIZ /DETAILED ERROR DUMP/
	103724	101	111	114		
	103727	105	104	040		
	103732	105	122	122		
	103735	117	122	040		
	103740	104	125	115		
	103743	120	000			
4765	103745	115	111	123	EM13:	.ASCIZ /MISSING EXPECTED SBE FLAG/
	103750	123	111	116		
	103753	107	040	105		
	103756	130	120	105		
	103761	103	124	105		
	103764	104	040	123		
	103767	102	105	040		
	103772	106	114	101		
	103775	107	000			
4766	103777	127	122	111	EM14:	.ASCIZ /WRITE BYTE FAILED TO CLEAR SBE FLAG/
	104002	124	105	040		
	104005	102	131	124		
	104010	105	040	106		
	104013	101	111	114		
	104016	105	104	040		
	104021	124	117	040		
	104024	103	114	105		
	104027	101	122	040		
	104032	123	102	105		
	104035	040	106	114		
	104040	101	107	000		
4767	104043	106	101	111	EM15:	.ASCIZ /FAILED TO GET INTERRUPT WITH DBE FLAG/
	104046	114	105	104		
	104051	040	124	117		
	104054	040	107	105		
	104057	124	040	111		
	104062	116	124	105		
	104065	122	122	125		
	104070	120	124	040		
	104073	127	111	124		
	104076	110	040	104		
	104101	102	105	040		
	104104	106	114	101		
	104107	107	000			
4768	104111	117	116	114	EM16:	.ASCIZ /ONLY ONE DBE FLAG SET/
	104114	131	040	117		

ERROR MESSAGES (EM)

	104117	116	105	040	
	104122	104	102	105	
	104125	040	106	114	
	104130	101	107	040	
	104133	123	105	124	
4769	104136	000			
	104137	115	105	115	EM17: .ASCIZ /MEMORY DATA ERROR IN CHECK BITS/
	104142	117	122	131	
	104145	040	104	101	
	104150	124	101	040	
	104153	105	122	122	
	104156	117	122	040	
	104161	111	116	040	
	104164	103	110	105	
	104167	103	113	040	
	104172	102	111	124	
	104175	123	000		
4770	104177	123	131	123	EM18: .ASCIZ /SYSTEM SIZE REGISTER LOW DOES NOT MATCH MEMORY/
	104202	124	105	115	
	104205	040	123	111	
	104210	132	105	040	
	104213	122	105	107	
	104216	111	123	124	
	104221	105	122	040	
	104224	114	117	127	
	104227	040	104	117	
	104232	105	123	040	
	104235	116	117	124	
	104240	040	115	101	
	104243	124	103	110	
	104246	040	115	105	
	104251	115	117	122	
	104254	131	000		
4771	104256	123	102	105	EM19: .ASCIZ /SBE OR DBE CAUSED PARITY TRAP WHEN INHIBITED/
	104261	040	117	122	
	104264	040	104	102	
	104267	105	040	103	
	104272	101	125	123	
	104275	105	104	040	
	104300	120	101	122	
	104303	111	124	131	
	104306	040	124	122	
	104311	101	120	040	
	104314	127	110	105	
	104317	116	040	111	
	104322	116	110	111	
	104325	102	111	124	
	104330	105	104	000	
4772	104333	123	102	105	EM20: .ASCIZ /SBE OR DBE DID NOT CAUSE PARITY TRAP WHEN ENABLED/
	104336	040	117	122	
	104341	040	104	102	
	104344	105	040	104	
	104347	111	104	040	
	104352	116	117	124	
	104355	040	103	101	
	104360	125	123	105	
	104363	040	120	101	

	104366	122	111	124	
	104371	131	040	124	
	104374	122	101	120	
	104377	040	127	110	
	104402	105	116	040	
	104405	105	116	101	
	104410	102	114	105	
	104413	104	000		
4773	104415	123	102	105	EM21: .ASCIZ /SBE OR DBE ON MASTER TEST WORD/
	104420	040	117	122	
	104423	040	104	102	
	104426	105	040	117	
	104431	116	040	115	
	104434	101	123	124	
	104437	105	122	040	
	104442	124	105	123	
	104445	124	040	127	
	104450	117	122	104	
	104453	000			
4774	104454	115	111	123	EM22: .ASCIZ /MISSING EXPECTED DBE/
	104457	123	111	116	
	104462	107	040	105	
	104465	130	120	105	
	104470	103	124	105	
	104473	104	040	104	
	104476	102	105	000	
4775	104501	125	116	105	EM23: .ASCIZ /UNEXPECTED PARITY TRAP/
	104504	130	120	105	
	104507	103	124	105	
	104512	104	040	120	
	104515	101	122	111	
	104520	124	131	040	
	104523	124	122	101	
	104526	120	000		
4776	104530	122	105	103	EM24: .ASCIZ /RECEIVED DBE FLAG WHEN EXPECTING ONLY SBE FLAG/
	104533	105	111	126	
	104536	105	104	040	
	104541	104	102	105	
	104544	040	106	114	
	104547	101	107	040	
	104552	127	110	105	
	104555	116	040	105	
	104560	130	120	105	
	104563	103	124	111	
	104566	116	107	040	
	104571	117	116	114	
	104574	131	040	123	
	104577	102	105	040	
	104602	106	114	101	
	104605	107	000		
4777	104607	103	110	105	EM25: .ASCIZ /CHECK BIT DATA ERROR/
	104612	103	113	040	
	104615	102	111	124	
	104620	040	104	101	
	104623	124	101	040	
	104626	105	122	122	
	104631	117	122	000	

ERROR MESSAGES (EM)

4778	104634	101	104	104	EM26: .ASCIZ /ADDRESS PARITY ERROR DID NOT CAUSE ABORT/
	104637	122	105	123	
	104642	123	040	120	
	104645	101	122	111	
	104650	124	131	040	
	104653	105	122	122	
	104656	117	122	040	
	104661	104	111	104	
	104664	040	116	117	
	104667	124	040	103	
	104672	101	125	123	
	104675	105	040	101	
	104700	102	117	122	
	104703	124	000		

4779	104705	115	113	061	EM27: .ASCIZ /MK11 PROTECTION POINTER FAILURE - DID NOT PROTECT BANK/
	104710	061	040	120	
	104713	122	117	124	
	104716	105	103	124	
	104721	111	117	116	
	104724	040	120	117	
	104727	111	116	124	
	104732	105	122	040	
	104735	106	101	111	
	104740	114	125	122	
	104743	105	040	055	
	104746	040	104	111	
	104751	104	040	116	
	104754	117	124	040	
	104757	120	122	117	
	104762	124	105	103	
	104765	124	040	102	
	104770	101	116	113	
	104773	000			

4780	104774	103	120	125	EM28: .ASCIZ /CPU IDENTIFICATION FAILURE/
	104777	040	111	104	
	105002	105	116	124	
	105005	111	106	111	
	105010	103	101	124	
	105013	111	117	116	
	105016	040	106	101	
	105021	111	114	125	
	105024	122	105	000	

4781	105027	103	117	122	EM29: .ASCIZ /CORRECTION FAILURE WITH ECC ENABLED ON FORCED SBE/
	105032	122	105	103	
	105035	124	111	117	
	105040	116	040	106	
	105043	101	111	114	
	105046	125	122	105	
	105051	040	127	111	
	105054	124	110	040	
	105057	105	103	103	
	105062	040	105	116	
	105065	101	102	114	
	105070	105	104	040	
	105073	117	116	040	
	105076	106	117	122	
	105101	103	105	104	

	105104	040	123	102	
	105107	105	000		
4782	105111	127	122	111	EM30: .ASCII /WRITE BYTE (MOVB) WITH ECC ENABLED FAILED TO CLEAR DATA AT/<CRLF>
	105114	124	105	040	
	105117	102	131	124	
	105122	105	040	050	
	105125	115	117	126	
	105130	102	051	040	
	105133	127	111	124	
	105136	110	040	105	
	105141	103	103	040	
	105144	105	116	101	
	105147	102	114	105	
	105152	104	040	106	
	105155	101	111	114	
	105160	105	104	040	
	105163	124	117	040	
	105166	103	114	105	
	105171	101	122	040	
	105174	104	101	124	
	105177	101	040	101	
4783	105202	124	200		
	105204	106	117	122	.ASCIIZ /FORCED SBE LOCATION/
	105207	103	105	104	
	105212	040	123	102	
	105215	105	040	114	
	105220	117	103	101	
	105223	124	111	117	
4784	105226	116	000		
	105230	101	123	122	EM31: .ASCIIZ /ASRB (R3)+ WITH ECC ENABLED CHANGED DATA AT FORCED DBE LOCATION/
	105233	102	040	050	
	105236	122	063	051	
	105241	053	040	127	
	105244	111	124	110	
	105247	040	105	103	
	105252	103	040	105	
	105255	116	101	102	
	105260	114	105	104	
	105263	040	103	110	
	105266	101	116	107	
	105271	105	104	040	
	105274	104	101	124	
	105277	101	040	101	
	105302	124	040	106	
	105305	117	122	103	
	105310	105	104	040	
	105313	104	102	105	
	105316	040	114	117	
	105321	103	101	124	
	105324	111	117	116	
4785	105327	000			
	105330	115	117	126	EM32: .ASCIIZ /MOVB #360,(R2)+ WITH ECC ENABLED CHANGED DATA AT FORCED DBE LOCATION/
	105333	102	040	043	
	105336	063	066	060	
	105341	054	050	122	
	105344	062	051	053	
	105347	040	127	111	

ERROR MESSAGES (EM)

	105352	124	110	040
	105355	105	103	103
	105360	040	105	116
	105363	101	102	114
	105366	105	104	040
	105371	103	110	101
	105374	116	107	105
	105377	104	040	104
	105402	101	124	101
	105405	040	101	124
	105410	040	106	117
	105413	122	103	105
	105416	104	040	104
	105421	102	105	040
	105424	114	117	103
	105427	101	124	111
	105432	117	116	000
4786	105435	115	117	126
	105440	040	043	061
	105443	067	067	064
	105446	060	060	054
	105451	050	122	061
	105454	051	040	127
	105457	111	124	110
	105462	040	105	103
	105465	103	040	105
	105470	116	101	102
	105473	114	105	104
	105476	040	103	110
	105501	101	116	107
	105504	105	104	040
	105507	104	101	124
	105512	101	040	101
	105515	124	040	106
	105520	117	122	103
	105523	105	104	040
	105526	104	102	105
	105531	040	114	117
	105534	103	101	124
	105537	111	117	116
	105542	000		
4787	105543	123	102	105
	105546	040	104	105
	105551	124	105	103
	105554	124	105	104
	105557	040	102	131
	105562	040	115	113
	105565	061	061	040
	105570	102	125	124
	105573	040	116	117
	105576	124	040	111
	105601	123	117	114
	105604	101	124	105
	105607	104	040	102
	105612	131	040	120
	105615	122	117	107
	105620	122	101	115

EM33: .ASCIZ /MOV #177400,(R1) WITH ECC ENABLED CHANGED DATA AT FORCED DBE LOCATION/

EM34: .ASCIZ /SBE DETECTED BY MK11 BUT NOT ISOLATED BY PROGRAM/



ERROR MESSAGES (EM)

	105623	000			
4788	105624	125	116	105	EM35: .ASCIZ /UNEXPECTED CORRECTION WITH ECC DISABLE ON FORCED SBE/
	105627	130	120	105	
	105632	103	124	105	
	105635	104	040	103	
	105640	117	122	122	
	105643	105	103	124	
	105646	111	117	116	
	105651	040	127	111	
	105654	124	110	040	
	105657	105	103	103	
	105662	040	104	111	
	105665	123	101	102	
	105670	114	105	040	
	105673	117	116	040	
	105676	106	117	122	
	105701	103	105	104	
	105704	040	123	102	
	105707	105	000		
4789	105711	101	120	124	EM36: .ASCIZ /APT SIZE DISAGREES WITH PROGRAM SIZING/
	105714	040	123	111	
	105717	132	105	040	
	105722	104	111	123	
	105725	101	107	122	
	105730	105	105	123	
	105733	040	127	111	
	105736	124	110	040	
	105741	120	122	117	
	105744	107	122	101	
	105747	115	040	123	
	105752	111	132	111	
	105755	116	107	000	
4790	105760	122	125	116	EM37: .ASCIZ /RUNNING CONTENTION INCREMENT FAILURE/
	105763	116	111	116	
	105766	107	040	103	
	105771	117	116	124	
	105774	105	116	124	
	105777	111	117	116	
	106002	040	111	116	
	106005	103	122	105	
	106010	115	105	115	
	106013	124	040	106	
	106016	101	111	114	
	106021	125	122	105	
	106024	000			
4791	106025	101	123	122	EM38: .ASCIZ /ASRB LOCK FAILURE (1 & ONLY 1 CPU SHOULD HAVE LOCKED) (LOCKED - ONES)/
	106030	102	040	114	
	106033	117	103	113	
	106036	040	106	101	
	106041	111	114	125	
	106044	122	105	040	
	106047	050	061	040	
	106052	046	040	117	
	106055	116	114	131	
	106060	040	061	040	
	106063	103	120	125	
	106066	040	123	110	

	106071	117	125	114	
	106074	104	040	110	
	106077	101	126	105	
	106102	040	114	117	
	106105	103	113	105	
	106110	104	051	040	
	106113	050	114	117	
	106116	103	113	105	
	106121	104	040	075	
	106124	040	117	116	
	106127	105	123	051	
	106132	000			
4.792	106133	101	123	122	EM39: .ASCIZ /ASRB LOCK BALANCE FAILURE (# OF LOCKS PER CPU BELOW)/
	106136	102	040	114	
	106141	117	103	113	
	106144	040	102	101	
	106147	114	101	116	
	106152	103	105	040	
	106155	106	101	111	
	106160	114	125	122	
	106163	105	040	050	
	106166	043	040	117	
	106171	106	040	114	
	106174	117	103	113	
	106177	123	040	120	
	106202	105	122	040	
	106205	103	120	125	
	106210	040	102	105	
	106213	114	117	127	
	106216	051	000		
4.793	106220	102	122	101	EM40: .ASCIZ /BRANCH GOBBLE FAILED CONDITION CODES TEST/
	106223	116	103	110	
	106226	040	107	117	
	106231	102	102	114	
	106234	105	040	106	
	106237	101	111	114	
	106242	105	104	040	
	106245	103	117	116	
	106250	104	111	124	
	106253	111	117	116	
	106256	040	103	117	
	106261	104	105	123	
	106264	040	124	105	
	106267	123	124	000	
4.794	106272	123	124	101	EM41: .ASCIZ /STALE DATA COULD NOT BE CREATED - CACHE FAILURE NOT MAIN MEMORY.../
	106275	114	105	040	
	106300	104	101	124	
	106303	101	040	103	
	106306	117	125	114	
	106311	104	040	116	
	106314	117	124	040	
	106317	102	105	040	
	106322	103	122	105	
	106325	101	124	105	
	106330	104	040	055	
	106333	040	103	101	
	106336	103	110	105	

106341	040	106	101
106344	111	114	125
106347	122	105	040
106352	116	117	124
106355	040	115	101
106360	111	116	040
106363	115	105	115
106366	117	122	131
106371	041	041	000
106374	103	101	103
106377	110	105	040
106402	103	117	125
106405	114	104	040
106410	116	117	124
106413	040	106	114
106416	125	123	110
106421	040	123	124
106424	101	114	105
106427	040	104	101
106432	124	101	040
106435	055	040	103
106440	101	103	110
106443	105	040	106
106446	101	111	114
106451	125	122	105
106454	040	116	117
106457	124	040	115
106462	101	111	116
106465	040	115	105
106470	115	117	122
106473	131	041	041
106476	000		
106477	123	114	101
106502	126	105	040
106505	104	111	104
106510	040	116	117
106513	124	040	122
106516	105	123	120
106521	117	116	104
106524	040	111	116
106527	040	124	111
106532	115	105	040
106535	055	040	101
106540	102	117	122
106543	124	111	116
106546	107	040	115
106551	125	114	124
106554	111	120	122
106557	117	103	105
106562	123	123	117
106565	122	040	124
106570	105	123	124
106573	123	000	
106575	111	111	123
106600	124	040	104
106603	111	104	040
106606	116	117	124

4795 EM42: .ASCIZ /CACHE COULD NOT FLUSH STALE DATA - CACHE FAILURE NOT MAIN MEMORY /

4796 EM43: .ASCIZ /SLAVE DID NOT RESPOND IN TIME - ABORTING MULTIPROCESSOR TESTS/

4797 EM44: .ASCIZ /IIST DID NOT RESPOND IN TIME - ABORTING MULTIPROCESSOR TESTS/

	106611	040	122	105	
	106614	123	120	117	
	106617	116	104	040	
	106622	111	116	040	
	106625	124	111	115	
	106630	105	040	055	
	106633	040	101	102	
	106636	117	122	124	
	106641	111	116	107	
	106644	040	115	125	
	106647	114	124	111	
	106652	120	122	117	
	106655	103	105	123	
	106660	123	117	122	
	106663	040	124	105	
	106666	123	124	123	
	106671	000			
4798	106672	116	117	124	EM45: .ASCIZ /NOT ENOUGH GOOD MEMORY FOR SLAVE - ABORTING MULTIPROCESSOR TESTS/
	106675	040	105	116	
	106700	117	125	107	
	106703	110	040	107	
	106706	117	117	104	
	106711	040	115	105	
	106714	115	117	122	
	106717	131	040	106	
	106722	117	122	040	
	106725	123	114	101	
	106730	126	105	040	
	106733	055	040	101	
	106736	102	117	122	
	106741	124	111	116	
	106744	107	040	115	
	106747	125	114	124	
	106752	111	120	122	
	106755	117	103	105	
	106760	123	123	117	
	106763	122	040	124	
	106766	105	123	124	
	106771	123	000		
4799	106773	101	114	114	EM46: .ASCIZ /ALL CPUS NOT SHARING A MEMORY BANK (ACCESSABLE ONES)/
	106776	040	103	120	
	107001	125	123	040	
	107004	116	117	124	
	107007	040	123	110	
	107012	101	122	111	
	107015	116	107	040	
	107020	101	040	115	
	107023	105	115	117	
	107026	122	131	040	
	107031	102	101	116	
	107034	113	040	050	
	107037	101	103	103	
	107042	105	123	123	
	107045	101	102	114	
	107050	105	040	075	
	107053	040	117	116	
	107056	105	123	051	

4800	107061	000				
	107062	103	123	122	EM47:	.ASCIZ /CSR CONFIGURATION ERROR - PROBABLY CSR SWITCHES IN BOX ARE SET WRONG./
	107065	040	103	117		
	107070	116	106	111		
	107073	107	125	122		
	107076	101	124	111		
	107101	117	116	040		
	107104	105	122	122		
	107107	117	122	040		
	107112	055	040	120		
	107115	122	117	102		
	107120	101	102	114		
	107123	131	040	103		
	107126	123	122	040		
	107131	123	127	111		
	107134	124	103	110		
	107137	105	123	040		
	107142	111	116	040		
	107145	102	117	130		
	107150	040	101	122		
	107153	105	040	123		
	107156	105	124	040		
	107161	127	122	117		
	107164	116	107	041		
	107167	000				
4801	107170	101	120	124	EM48:	.ASCIZ /APT EXPECTS DIFFERENT NUMBER OF CPU'S THAN DIAGNOSTIC CAN BOOT/
	107173	040	105	130		
	107176	120	105	103		
	107201	124	123	040		
	107204	104	111	106		
	107207	106	105	122		
	107212	105	116	124		
	107215	040	116	125		
	107220	115	102	105		
	107223	122	040	117		
	107226	106	040	103		
	107231	120	125	047		
	107234	123	040	124		
	107237	110	101	116		
	107242	040	104	111		
	107245	101	107	116		
	107250	117	123	124		
	107253	111	103	040		
	107256	103	101	116		
	107261	040	102	117		
	107264	117	124	000		
4802	107267	120	117	122	EM49:	.ASCIZ /PORT CONTENTION BALANCED WITH 3 CPU'S RAISED TO HIGH PRIORITY/
	107272	124	040	103		
	107275	117	116	124		
	107300	105	116	124		
	107303	111	117	116		
	107306	040	102	101		
	107311	114	101	116		
	107314	103	105	104		
	107317	040	127	111		
	107322	124	110	040		
	107325	063	040	103		

107330	120	125	047
107333	123	040	122
107336	101	111	123
107341	105	104	040
107344	124	117	040
107347	110	111	107
107352	110	040	120
107355	122	111	117
107360	122	111	124
107363	131	000	

4803

.EVEN

Address	PC	DEV	ADD	GOOD	BAD/
4806					
4807	107366	040	040	120	DH1: .SBTIL ERROR DATA HEADERS (DH)
	107371	103	040	040	.ASCIZ / PC DEV ADD GOOD BAD/
	107374	040	104	105	
	107377	126	040	101	
	107402	104	104	040	
	107405	040	040	107	
	107410	117	117	104	
	107413	040	040	040	
	107416	040	102	101	
	107421	104	000		
4808	107423	040	040	120	DH2: .ASCIZ / PC GD-CC BD-CC/
	107426	103	040	040	
	107431	040	107	104	
	107434	055	103	103	
	107437	040	102	104	
	107442	055	103	103	
	107445	000			
4809	107446	040	040	120	DH3: .ASCIZ / PC 1ST ADD # OF ERRORS/
	107451	103	040	040	
	107454	040	061	123	
	107457	124	040	101	
	107462	104	104	040	
	107465	040	043	040	
	107470	117	106	040	
	107473	105	122	122	
	107476	117	122	123	
	107501	000			
4810	107502	040	040	120	DH4: .ASCIZ / PC/
	107505	103	000		
4811	107507	040	040	120	DH5: .ASCII / PC CPUERR MEMERR HIADRS LGADRS/
	107512	103	040	040	
	107515	040	040	103	
	107520	120	125	105	
	107523	122	122	040	
	107526	040	115	105	
	107531	115	105	122	
	107534	122	040	040	
	107537	110	111	101	
	107542	104	122	123	
	107545	040	040	114	
	107550	117	101	104	
	107553	122	123		
4812	107555	040	040	040	.ASCIZ / MMR0 MMR1 MMR2 MMR3/
	107560	115	115	122	
	107563	060	040	040	
	107566	040	040	115	
	107571	115	122	061	
	107574	040	040	040	
	107577	040	115	115	
	107602	122	062	040	
	107605	040	040	040	
	107610	115	115	122	
	107613	063	000		
4813	107615	040	040	120	DH6: .ASCIZ / PC APTCORE MJSIZE APTMOS MKSIZE/
	107620	103	040	040	
	107623	040	101	120	

4832	111056	040	040	120	DH21:	.ASCIZ	/	PC/						
	111061	103	000											
4833	111063	040	040	120	DH22:	.ASCIZ	/	PC	REAL#	APT#				
	111066	103	040	040										
	111071	040	040	122										
	111074	105	101	114										
	111077	043	040	040										
	111102	040	040	101										
	111105	120	124	043										
	111110	000												
4834	111111	040	040	120	DH23:	.ASCIZ	/	PC	BANK MASTER	SLAVE1	SLAVE2	SLAVE3	LOW-CPU/	
	111114	103	040	040										
	111117	040	040	102										
	111122	101	116	113										
	111125	040	115	101										
	111130	123	124	105										
	111133	122	040	040										
	111136	123	114	101										
	111141	126	105	061										
	111144	040	040	123										
	111147	114	101	126										
	111152	105	062	040										
	111155	040	123	114										
	111160	101	126	105										
	111163	063	040	040										
	111166	114	117	127										
	111171	055	103	120										
	111174	125	000											
4835									.EVEN					

MESSAGES

4838

4839	111176	200	103	105
	111201	115	113	101
	111204	102	060	040
	111207	061	061	067
	111212	060	040	115
	111215	101	111	116
	111220	040	115	105
	111223	115	117	122
	111226	131	040	104
	111231	111	101	107
	111234	116	117	123
	111237	124	111	103
	111242	040	074	126
	111245	061	064	055
	111250	060	060	076
	111253	000		

.SBTTL MESSAGES

MSG000: .ASCIZ <CRLF>/CEMKABO 1170 MAIN MEMORY DIAGNOSTIC <V14-00>/

4840

111254	200	040	040
111257	040	040	040
111262	040	040	040
111265	040	040	040
111270	040	040	040
111273	040	040	040
111276	040	040	040
111301	040	040	040
111304	040	115	105
111307	115	117	122
111312	131	040	103
111315	117	116	106
111320	111	107	125
111323	122	101	124
111326	111	117	116
111331	040	115	101
111334	120	000	

MSG001: .ASCIZ <CRLF>/

MEMORY CONFIGURATION MAP/

4841

111336	200	040	040
111341	040	040	040
111344	040	040	040
111347	040	040	040
111352	040	040	040
111355	040	040	040
111360	040	040	040
111363	040	040	040
111366	040	040	040
111371	040	040	040
111374	061	066	113
111377	040	127	117
111402	122	104	040
111405	102	101	116
111410	113	123	000

MSG002: .ASCIZ <CRLF>/

16K WORD BANKS/

4842

111413	200	040	040
111416	040	040	040
111421	040	040	040
111424	040	040	040
111427	040	040	040
111432	040	040	061
111435	040	040	040
111440	040	040	040

MSG003: .ASCII <CRLF>/

1 2 3/

MESSAGE

	111443	040	062	040					
	111446	040	040	040					
	111451	040	040	040					
	111454	063							
4843	111455	040	040	040	.ASCIZ /	4	5	6	7 /
	111460	040	040	040					
	111463	040	064	040					
	111466	040	040	040					
	111471	040	040	040					
	111474	065	040	040					
	111477	040	040	040					
	111502	040	040	066					
	111505	040	040	040					
	111510	040	040	040					
	111513	040	067	040					
	111516	040	000						
4844	111520	200	040	040	MSG004: .ASCII <CRLF>/				012345670123456701234567/
	111523	040	040	040					
	111526	040	040	040					
	111531	060	061	062					
	111534	063	064	065					
	111537	066	067	060					
	111542	061	062	063					
	111545	064	065	066					
	111550	067	060	061					
	111553	062	063	064					
	111556	065	066	067					
4845	111561	060	061	062	.ASCIZ /				012345670123456701234567012345670123/
	111564	063	064	065					
	111567	066	067	060					
	111572	061	062	063					
	111575	064	065	066					
	111600	067	060	061					
	111603	062	063	064					
	111606	065	066	067					
	111611	060	061	062					
	111614	063	064	065					
	111617	066	067	060					
	111622	061	062	063					
	111625	000							
4846	111626	200	105	122	MSG005: .ASCIZ <CRLF>/ERRORS /				
	111631	122	117	122					
	111634	123	040	040					
	111637	000							
4847	111640	200	125	116	MSG006: .ASCIZ <CRLF>/UNDEFINED TRAP INSTRUCTION/<32>				
	111643	104	105	106					
	111646	111	116	105					
	111651	104	040	124					
	111654	122	101	120					
	111657	040	111	116					
	111662	123	124	122					
	111665	125	103	124					
	111670	111	117	116					
	111673	032	000						
4848	111675	200	111	116	MSG007: .ASCIZ <CRLF>/INTRLV /				
	111700	124	122	114					
	111703	126	040	040					

	112144	040	040	040	
	112147	000			
4858	112150	040	040	040	MSG017: .ASCIZ / / :8 SPACES
	112153	040	040	040	
	112156	040	040	000	
4859	112161	040	040	000	MSG018: .ASCIZ / / :2 SPACES
4860	112164	040	040	040	MSG019: .ASCIZ / / :3 SPACES
	112167	000			
4861	112170	200	106	111	MSG020: .ASCIZ <CRLF>/FIELD SERVICE COMMAND MODE/
	112173	105	114	104	
	112176	040	123	105	
	112201	122	126	111	
	112204	103	105	040	
	112207	103	117	115	
	112212	115	101	116	
	112215	104	040	115	
	112220	117	104	105	
	112223	000			
4862	112224	200	103	117	MSG021: .ASCII <CRLF>/COMMANDS AVAILABLE ARE:/
	112227	115	115	101	
	112232	116	104	123	
	112235	040	101	126	
	112240	101	111	114	
	112243	101	102	114	
	112246	105	040	101	
	112251	122	105	072	
4863	112254	200	060	040	.ASCII <CRLF>/0 = EXIT FIELD SERVICE COMMANDS/
	112257	075	040	105	
	112262	130	111	124	
	112265	040	106	111	
	112270	105	114	104	
	112273	040	123	105	
	112276	122	126	111	
	112301	103	105	040	
	112304	103	117	115	
	112307	115	101	116	
	112312	104	123		
4864	112314	200	061	040	.ASCII <CRLF>/1 = READ CSR/
	112317	075	040	122	
	112322	105	101	104	
	112325	040	103	123	
	112330	122			
4865	112331	200	062	040	.ASCII <CRLF>/2 = LOAD CSR/
	112334	075	040	114	
	112337	117	101	104	
	112342	040	103	123	
	112345	122			
4866	112346	200	063	040	.ASCII <CRLF>/3 - EXAMINE MEMORY/
	112351	075	040	105	
	112354	130	101	115	
	112357	111	116	105	
	112362	040	115	105	
	112365	115	117	122	
	112370	131			
4867	112371	200	064	040	.ASCII <CRLF>/4 MODIFY MEMORY/
	112374	075	040	115	
	112377	117	104	111	

	112402	106	131	040	
	112405	115	105	115	
	112410	117	122	131	
4868	112413	200	065	040	.ASCII <CRLF>/5 = SELECT BANK, MARGIN, & PATTERN/
	112416	075	040	123	
	112421	105	114	105	
	112424	103	124	040	
	112427	102	101	116	
	112432	113	054	115	
	112435	101	122	107	
	112440	111	116	054	
	112443	040	046	040	
	112446	120	101	124	
	112451	124	105	122	
	112454	116			
4869	112455	200	066	040	.ASCII <CRLF>/6 = TYPE CONFIGURATION MAP/
	112460	075	040	124	
	112463	131	120	105	
	112466	040	103	117	
	112471	116	106	111	
	112474	107	125	122	
	112477	101	124	111	
	112502	117	116	040	
	112505	115	101	120	
4870	112510	200	067	040	.ASCII <CRLF>'7 - BATTERY BACKUP - P/F TEST''
	112513	075	040	102	
	112516	101	124	124	
	112521	105	122	131	
	112524	040	102	101	
	112527	103	113	125	
	112532	120	040	055	
	112535	040	120	057	
	112540	106	040	124	
	112543	105	123	124	
4871	112546	200	070	040	.ASCII <CRLF>/8 = SOB-A-LONG TEST/
	112551	075	040	123	
	112554	117	102	055	
	112557	101	055	114	
	112562	117	116	107	
	112565	040	124	105	
	112570	123	124		
4872	112572	200	071	040	.ASCII <CRLF>/9 - SUPER TIGHT SCOPE LOOP/
	112575	075	040	123	
	112600	125	120	105	
	112603	122	040	124	
	112606	111	107	110	
	112611	124	040	123	
	112614	103	117	120	
	112617	105	040	114	
	112622	117	117	120	
4873	112625	200	061	060	.ASCII <CRLF>/10= ERROR SUMMARY/
	112630	075	040	105	
	112633	122	122	117	
	112636	122	040	123	
	112641	125	115	115	
	112644	101	122	131	
4874	112647	200	061	061	.ASCII <CRLF>/11- REFRESH TEST/

	112652	075	040	122	
	112655	105	106	122	
	112660	105	123	110	
	112663	040	124	105	
	112666	123	124		
4875	112670	200	061	062	.ASCII <CRLF>/12= SET FILL COUNT/
	112673	075	040	123	
	112676	105	124	040	
	112701	106	111	114	
	112704	114	040	103	
	112707	117	125	116	
	112712	124			
4876	112713	200	061	063	.ASCII <CRLF>/13= ENTER KAMIKAZE MODE/
	112716	075	040	105	
	112721	116	124	105	
	112724	122	040	113	
	112727	101	115	111	
	112732	113	101	132	
	112735	105	040	115	
	112740	117	104	105	
4877	112743	200	061	064	.ASCII <CRLF>/14= EXIT KAMIKAZE MODE/
	112746	075	040	105	
	112751	130	111	124	
	112754	040	113	101	
	112757	115	111	113	
	112762	101	132	105	
	112765	040	115	117	
	112770	104	105		
4878	112772	200	061	065	.ASCII <CRLF>/15= TURN CACHE OFF/
	112775	075	040	124	
	113000	125	122	116	
	113003	040	103	101	
	113006	103	110	105	
	113011	040	117	106	
	113014	106			
4879	113015	200	061	066	.ASCII <CRLF>/16= TURN CACHE ON/
	113020	075	040	124	
	113023	125	122	116	
	113026	040	103	101	
	113031	103	110	105	
	113034	040	117	116	
4880	113037	200	061	067	.ASCII <CRLF>/17= RUN ONLY MULTIPOINT TESTS/
	113042	075	040	122	
	113045	125	116	040	
	113050	117	116	114	
	113053	131	040	115	
	113056	125	114	124	
	113061	111	120	117	
	113064	122	124	040	
	113067	124	105	123	
	113072	124	123		
4881	113074	200	061	070	.ASCII <CRLF>/18 RESUME RUNNING BOTH SINGLE & MULTIPOINT TESTS/
	113077	075	040	122	
	113102	105	123	125	
	113105	115	105	040	
	113110	122	125	116	
	113113	116	111	116	

	113116	107	040	102	
	113121	117	124	110	
	113124	040	123	111	
	113127	116	107	114	
	113132	105	040	046	
	113135	040	115	125	
	113140	114	124	111	
	113143	120	117	122	
	113146	124	040	124	
	113151	105	123	124	
	113154	123			
4882	113155	200	061	071	.ASCII <CRLF>/19= TEST ONLY SELECTED BANKS/
	113160	075	040	124	
	113163	105	123	124	
	113166	040	117	116	
	113171	114	131	040	
	113174	123	105	114	
	113177	105	103	124	
	113202	105	104	040	
	113205	102	101	116	
	113210	113	123		
4883	113212	200	062	060	.ASCII <CRLF>/20= RESUME TESTING ALL BANKS/
	113215	075	040	122	
	113220	105	123	125	
	113223	115	105	040	
	113226	124	105	123	
	113231	124	111	116	
	113234	107	040	101	
	113237	114	114	040	
	113242	102	101	116	
	113245	113	123		
4884	113247	015	012	000	.BYTE 15,12,0
4885	113252	200	127	110	MSG022: .ASCIZ <CRLF>/WHICH CSR(0-7)? /
	113255	111	103	110	
	113260	040	103	123	
	113263	122	050	060	
	113266	055	067	051	
	113271	077	040	000	
4886	113274	200	103	123	MSG023: .ASCIZ <CRLF>/CSR - 1ST WORD? /
	113277	122	040	055	
	113302	040	061	123	
	113305	124	040	127	
	113310	117	122	104	
	113313	077	040	000	
4887	113316	200	103	123	MSG024: .ASCIZ <CRLF>/CSR - 2ND WORD? /
	113321	122	040	055	
	113324	040	062	116	
	113327	104	040	127	
	113332	117	122	104	
	113335	077	040	000	
4888	113340	200	124	110	MSG025: .ASCIZ <CRLF>/THIS CSR DOES NOT EXIST/
	113343	111	123	040	
	113346	103	123	122	
	113351	040	104	117	
	113354	105	123	040	
	113357	116	117	124	
	113362	040	105	130	

4898	113625	000			MSG034: .BYTE 0
4899	113626	040	103	117	.ASCII / CONTROLLER /
	113631	116	124	122	
	113634	117	114	114	
	113637	105	122	040	
4900	113642	000			MSG034: .BYTE 0
4901	113643	200	104	125	.ASCIIZ <CRLF>/DUE TO LACK OF SBE FREE LOCATIONS/<32>
	113646	105	040	124	
	113651	117	040	114	
	113654	101	103	113	
	113657	040	117	106	
	113662	040	123	102	
	113665	105	040	106	
	113670	122	105	105	
	113673	040	114	117	
	113676	103	101	124	
	113701	111	117	116	
	113704	123	032	000	
4902	113707	121	126	000	MSG035: .ASCIIZ /QV/
4903	113712	200	115	117	MSG036: .ASCIIZ <CRLF>/MODIFY MEMORY/
	113715	104	111	106	
	113720	131	040	115	
	113723	105	115	117	
	113726	122	131	000	
4904	113731	200	117	114	MSG037: .ASCIIZ <CRLF>/OLD DATA WAS /
	113734	104	040	104	
	113737	101	124	101	
	113742	040	127	101	
	113745	123	040	000	
4905	113750	200	104	101	MSG038: .ASCIIZ <CRLF>/DATA IS NOW /
	113753	124	101	040	
	113756	111	123	040	
	113761	116	117	127	
	113764	040	000		
4906	113766	200	111	116	MSG039: .ASCIIZ <CRLF>/INPUT NEW DATA? /
	113771	120	125	124	
	113774	040	116	105	
	113777	127	040	104	
	114002	101	124	101	
	114005	077	040	000	
4907	114010	200	123	105	MSG040: .ASCIIZ <CRLF>/SELECT BANK, MARGIN, & PATTERN TEST/
	114013	114	105	103	
	114016	124	040	102	
	114021	101	116	113	
	114024	054	040	115	
	114027	101	122	107	
	114032	111	116	054	
	114035	040	046	040	
	114040	120	101	124	
	114043	124	105	122	
	114046	116	040	124	
	114051	105	123	124	
	114054	000			
4908	114055	200	102	101	MSG041: .ASCIIZ <CRLF>/BANK NOT ACCESSABLE/
	114060	116	113	040	
	114063	116	117	124	
	114066	040	101	103	

	114071	103	105	123	
	114074	123	101	102	
	114077	114	105	000	
4909	114102	200	120	101	MSG042: .ASCIZ <CRLF>/PATTERN(0-37)? /
	114105	124	124	105	
	114110	122	116	050	
	114113	060	055	063	
	114116	067	051	077	
	114121	040	000		
4910	114123	200	120	101	MSG043: .ASCIZ <CRLF>/PATTERN 0 DATA IS? /
	114126	124	124	105	
	114131	122	116	040	
	114134	060	040	104	
	114137	101	124	101	
	114142	040	111	123	
	114145	077	040	000	
4911	114150	200	115	101	MSG044: .ASCIZ <CRLF>/MARGIN(0,2,3,4,5)? /
	114153	122	107	111	
	114156	116	050	060	
	114161	054	062	054	
	114164	063	054	064	
	114167	054	065	051	
	114172	077	040	000	
4912	114175	200	115	101	MSG045: .ASCIZ <CRLF>/MARGINS INHIBITED BY SW11! /
	114200	122	107	111	
	114203	116	123	040	
	114206	111	116	110	
	114211	111	102	111	
	114214	124	105	104	
	114217	040	102	131	
	114222	040	123	127	
	114225	061	061	041	
	114230	000			
4913	114231	200	124	117	MSG046: .ASCIZ <CRLF>/TO ESCAPE TYPE ANY KEY/<CRLF><12><12>
	114234	040	105	123	
	114237	103	101	120	
	114242	105	040	124	
	114245	131	120	105	
	114250	040	101	116	
	114253	131	040	113	
	114256	105	131	200	
	114261	012	012	000	
4914	114264	200	124	105	MSG047: .ASCIZ <CRLF>/TEST COMPLETE /
	114267	123	124	040	
	114272	103	117	115	
	114275	120	114	105	
	114300	124	105	000	
4915	114303	040	116	117	MSG048: .ASCIZ / NOT AVAILABLE NOW - TRY LATER. /
	114306	124	040	101	
	114311	126	101	111	
	114314	114	101	102	
	114317	114	105	040	
	114322	116	117	127	
	114325	040	055	040	
	114330	124	122	131	
	114333	040	114	101	
	114336	124	105	122	

	114341	041	000		
4916	114343	200	102	101	MSG049: .ASCIZ <CRLF>/BANK REQUIRES RELOCATION/
	114346	116	113	040	
	114351	122	105	121	
	114354	125	111	122	
	114357	105	123	040	
	114362	122	105	114	
	114365	117	103	101	
	114370	124	111	117	
	114373	116	000		
4917	114375	200	102	101	MSG050: .ASCII <CRLF>/BATTERY BACKUP TEST/
	114400	124	124	105	
	114403	122	131	040	
	114406	102	101	103	
	114411	113	125	120	
	114414	040	124	105	
	114417	123	124		
4918	114421	200	127	122	.ASCIZ <CRLF>/WRITING & CHECKING ADDRESS PATTERN AS BACKGROUND/
	114424	111	124	111	
	114427	116	107	040	
	114432	046	040	103	
	114435	110	105	103	
	114440	113	111	116	
	114443	107	040	101	
	114446	104	104	122	
	114451	105	123	123	
	114454	040	120	101	
	114457	124	124	105	
	114462	122	116	040	
	114465	101	123	040	
	114470	102	101	103	
	114473	113	107	122	
	114476	117	125	116	
	114501	104	000		
4919	114503	200	120	117	MSG051: .ASCIZ <CRLF>/POWER RECOVERY/
	114506	127	105	122	
	114511	040	122	105	
	114514	103	117	126	
	114517	105	122	131	
	114522	000			
4920	114523	200	122	105	MSG052: .ASCIZ <CRLF>/REMOVE SYSTEM POWER FOR/
	114526	115	117	126	
	114531	105	040	123	
	114534	131	123	124	
	114537	105	115	040	
	114542	120	117	127	
	114545	105	122	040	
	114550	106	117	122	
	114553	000			
4921	114554	040	123	105	MSG053: .ASCIZ / SECONDS MAX./
	114557	103	117	116	
	114562	104	123	040	
	114565	115	101	130	
	114570	041	000		
4922	114572	200	116	117	MSG054: .ASCIZ <CRLF>/NOW STARTING READ TEST OF MEMORY BANKS/
	114575	127	040	123	
	114600	124	101	122	

	114603	124	111	16	
	114606	107	040	122	
	114611	105	101	104	
	114614	040	124	105	
	114617	123	124	040	
	114622	117	106	040	
	114625	115	105	115	
	114630	117	122	131	
	114633	040	102	101	
	114636	116	113	123	
4923	114641	000			
	114642	200	123	117	MSG055: .ASCIZ <CRLF>/SOB-A-LONG TEST/
	114645	102	055	101	
	114650	055	114	117	
	114653	116	107	040	
	114656	124	105	123	
	114661	124	000		
4924	114663	200	102	105	MSG056: .ASCIZ <CRLF>/BELL = EACH PASS COMPLETE/
	114666	114	114	040	
	114671	075	040	105	
	114674	101	103	110	
	114677	040	120	101	
	114702	123	123	040	
	114705	103	117	115	
	114710	120	114	105	
	114713	124	105	000	
4925	114716	040	077	040	MSG057: .ASCIZ / ? /
	114721	000			
4926	114722	200	040	040	MSG058: .ASCIZ <CRLF>/ CSR CSR+2 CSR CSR+2 .../
	114725	103	123	122	
	114730	040	040	040	
	114733	040	103	123	
	114736	122	053	062	
	114741	040	040	040	
	114744	040	103	123	
	114747	122	040	040	
	114752	040	040	103	
	114755	123	122	053	
	114760	062	040	056	
	114763	056	056	000	
4927	114766	200	123	125	MSG059: .ASCIZ <CRLF>/SUPER TIGHT SCOPE LOOP/
	114771	120	105	122	
	114774	040	124	111	
	114777	107	110	124	
	115002	040	123	103	
	115005	117	120	105	
	115010	040	114	117	
	115013	117	120	000	
4928	115016	200	123	127	MSG060: .ASCIZ <CRLF>/SWREG ----> MEM, MEM ----> DISPLAY/
	115021	122	105	107	
	115024	040	055	055	
	115027	055	076	040	
	115032	115	105	115	
	115035	054	040	115	
	115040	105	115	040	
	115043	055	055	055	
	115046	076	040	104	

	115051	111	123	120	
	115054	114	101	131	
	115057	000			
4929	115060	077	077	077	MSG061: .ASCIZ /??????/
	115063	077	077	077	
	115066	000			
4930	115067	111	116	120	MSG062: .ASCIZ /INPUT MUST BE A/
	115072	125	124	040	
	115075	115	125	123	
	115100	124	040	102	
	115103	105	040	101	
	115106	000			
4931	115107	116	040	117	MSG063: .ASCIZ /N OCTAL /
	115112	103	124	101	
	115115	114	040	000	
4932	115120	116	125	115	MSG064: .ASCIZ /NUMBER/<CRLF>
	115123	102	105	122	
	115126	200	000		
4933	115130	040	104	105	MSG065: .ASCIZ / DECIMAL /
	115133	103	111	115	
	115136	101	114	040	
	115141	000			
4934	115142	200	105	122	MSG066: .ASCIZ <CRLF>/ERROR COUNT EXCEEDED 20 - ABORTING FOR XXDP CHAIN/
	115145	122	117	122	
	115150	040	103	117	
	115153	125	116	124	
	115156	040	105	130	
	115161	103	105	105	
	115164	104	105	104	
	115167	040	062	060	
	115172	040	055	040	
	115175	101	102	117	
	115200	122	124	111	
	115203	116	107	040	
	115206	106	117	122	
	115211	040	130	130	
	115214	104	120	040	
	115217	103	110	101	
	115222	111	116	000	
4935	115225	106	101	124	MSG067: .ASCIZ /FATAL /
	115230	101	114	040	
	115233	000			
4936	115234	115	112	061	MSG068: .ASCIZ /MJ11/
	115237	061	000		
4937	115241	115	113	061	MSG069: .ASCIZ /MK11/
	115244	061	000		
4938	115246	113	040	127	MSG070: .ASCIZ /K WORDS OF MEMORY/<CRLF>
	115251	117	122	104	
	115254	123	040	117	
	115257	106	040	115	
	115262	105	115	117	
	115265	122	131	200	
	115270	000			
4939	115271	113	040	117	MSG071: .ASCIZ /K OF MJ11/<CRLF>
	115274	106	040	115	
	115277	112	061	061	
	115302	200	000		

4940	115304	113	040	117	MSG072: .ASCIZ /K OF MK11/<CRLF>
	115307	106	040	115	
	115312	113	061	061	
	115315	200	000		
4941	115317	200	122	105	MSG073: .ASCIZ <CRLF>/REFRESH TEST/
	115322	106	122	105	
	115325	123	110	040	
	115330	124	105	123	
	115333	124	000		
4942					.EVEN ;THIS STAYS WITH MSG074
4943	115336	077	077	000	MSG074: .ASCIZ /??/
4944	115341	200	122	105	MSG075: .ASCIZ <CRLF>/RELOCATION NOT POSSIBLE/<32>
	115344	114	117	103	
	115347	101	124	111	
	115352	117	116	040	
	115355	116	117	124	
	115360	040	120	117	
	115363	123	123	111	
	115366	102	114	105	
	115371	032	000		
4945	115373	200	040	040	MSG076: .ASCIZ <CRLF>/ BANK ERRORS/<CRLF>
	115376	102	101	116	
	115401	113	040	040	
	115404	105	122	122	
	115407	117	122	123	
	115412	200	000		
4946	115414	200	105	116	MSG077: .ASCIZ <CRLF>/END PASS #/
	115417	104	040	120	
	115422	101	123	123	
	115425	040	043	000	
4947	115430	200	127	101	MSG078: .ASCIZ <CRLF>/WARNING. ECC IS DISABLED ON BOX /<32>
	115433	122	116	111	
	115436	116	107	041	
	115441	040	040	105	
	115444	103	103	040	
	115447	111	123	040	
	115452	104	111	123	
	115455	101	102	114	
	115460	105	104	040	
	115463	117	116	040	
	115466	102	117	130	
	115471	040	032	000	
4948	115474	040	105	122	MSG079: .ASCIZ / ERROR(S) DETECTED/<CRLF>
	115477	122	117	122	
	115502	050	123	051	
	115505	040	104	105	
	115510	124	105	103	
	115513	124	105	104	
	115516	200	000		
4949	115520	200	105	116	MSG080: .ASCIZ <CRLF>/ENTER # OF SLAVE CPU'S (0-3)? /
	115523	124	105	122	
	115526	040	043	040	
	115531	117	106	040	
	115534	123	114	101	
	115537	126	105	040	
	115542	103	120	125	
	115545	047	123	040	

MESSAGES

	115550	050	060	050	
	115553	063	051	077	
	115556	040	000		
4950	115560	200	123	124	MSG081: .ASCIZ <CRLF>/START SLAVE #/
	115563	101	122	124	
	115566	040	123	114	
	115571	101	126	105	
	115574	040	043	000	
4951	115577	040	101	124	MSG082: .ASCIZ / AT ADDRESS 200/
	115602	040	101	104	
	115605	104	122	105	
	115610	123	123	040	
	115613	062	060	060	
	115616	000			
4952	115617	200	120	122	MSG084: .ASCIZ <CRLF>/PROCEEDING AS A SINGLE PORT TEST/
	115622	117	103	105	
	115625	105	104	111	
	115630	116	107	040	
	115633	101	123	040	
	115636	101	040	123	
	115641	111	116	107	
	115644	114	105	040	
	115647	120	117	122	
	115652	124	040	124	
	115655	105	123	124	
	115660	000			
4953	115661	200	106	111	MSG085: .ASCIZ <CRLF>/FILL COUNT(OCTAL)? /
	115664	114	114	040	
	115667	103	117	125	
	115672	116	124	050	
	115675	117	103	124	
	115700	101	114	051	
	115703	077	040	000	
4954	115706	200	115	125	MSG086: .ASCIZ <CRLF>/MULTIPOINT DIRECTORY/
	115711	114	124	111	
	115714	120	117	122	
	115717	124	040	104	
	115722	111	122	105	
	115725	103	124	117	
	115730	122	131		
4955	115732	200	115	101	.ASCIZ <CRLF>/MASTER = /
	115735	123	124	105	
	115740	122	040	075	
	115743	040	000		
4956	115745	200	123	114	MSG087: .ASCII <CRLF>/SLAVE/
	115750	101	126	105	
4957	115753	060			MSG087: .BYTE '0
4958	115754	040	075	040	.ASCIZ / = /
	115757	000			
4959	115760	200	113	105	MSG088: .ASCIZ <CRLF>/KERNEL STACK/
	115763	122	116	105	
	115766	114	040	123	
	115771	124	101	103	
	115774	113	000		
4960	115776	200	123	125	MSG089: .ASCIZ <CRLF>/SUPERVISOR STACK/
	116001	120	105	122	
	116004	126	111	123	

	116007	117	122	040	
	116012	123	124	101	
	116015	103	113	000	
4961	116020	200	125	123	MSG090: .ASCIZ <CRLF>/USER STACK/
	116023	105	122	040	
	116026	123	124	101	
	116031	103	113	000	
4962	116034	040	111	123	MSG091: .ASCIZ / IS EMPTY/
	116037	040	105	115	
	116042	120	124	131	
	116045	000			
4963	116046	122	105	114	MSG092: .ASCIZ /RELOCATED /
	116051	117	103	101	
	116054	124	105	104	
	116057	040	040	000	
4964	116062	102	101	116	MSG093: .ASCIZ /BANK-/
	116065	113	075	000	
4965	116070	040	040	115	MSG094: .ASCIZ / MAR-/
	116073	101	122	075	
	116076	000			
4966	116077	040	040	120	MSG095: .ASCIZ / PAT=/
	116102	101	124	075	
	116105	000			
4967	116106	200	114	117	MSG096: .ASCIZ <CRLF>/LOADERS BEING DESTROYED/
	116111	101	104	105	
	116114	122	123	040	
	116117	102	105	111	
	116122	116	107	040	
	116125	104	105	123	
	116130	124	122	117	
	116133	131	105	104	
	116136	000			
4968	116137	200	127	101	MSG097: .ASCIZ <CRLF>/WARNING. ILLEGAL INTERLEAVE SELECTED (FIELD SERVICE ONLY)/<32>
	116142	122	116	111	
	116145	116	107	041	
	116150	040	040	111	
	116153	114	114	105	
	116156	107	101	114	
	116161	040	111	116	
	116164	124	105	122	
	116167	114	105	101	
	116172	126	105	040	
	116175	123	105	114	
	116200	105	103	111	
	116203	105	104	040	
	116206	050	106	111	
	116211	105	114	104	
	116214	040	123	105	
	116217	122	126	111	
	116222	103	105	040	
	116225	117	116	114	
	116230	131	051	032	
	116233	000			
4969	116234	200	123	114	MSG098: .ASCII <CRLF>/SLAVE/
	116237	101	126	105	
4970	116242	000			MSG098: .BYTE 0
4971	116243	076	000		.ASCIZ />/

4972	116245	200	115	101	MSG099: .ASCIZ <CRLF>/MASTER>/
	116250	123	124	105	
	116253	122	076	000	
4973	116256	200	115	125	MSG100: .ASCIZ <CRLF>/MULTIPROCESSOR TEST #/
	116261	114	124	111	
	116264	120	122	117	
	116267	103	105	123	
	116272	123	117	122	
	116275	040	124	105	
	116300	123	124	040	
	116303	043	000		
4974	116305	200	105	116	MSG101: .ASCIZ <CRLF>/ENTERING KAMIKAZE MODE/
	116310	124	105	122	
	116313	111	116	107	
	116316	040	113	101	
	116321	115	111	113	
	116324	101	132	105	
	116327	040	115	117	
	116332	104	105	000	
4975	116335	200	114	105	MSG102: .ASCIZ <CRLF>/LEAVING KAMIKAZE MODE/
	116340	101	126	111	
	116343	116	107	040	
	116346	113	101	115	
	116351	111	113	101	
	116354	132	105	040	
	116357	115	117	104	
	116362	105	000		
4976	116364	200	114	105	MSG103: .ASCIZ <CRLF>/LEAVING FIELD SERVICE MODE/<CRLF>
	116367	101	126	111	
	116372	116	107	040	
	116375	106	111	105	
	116400	114	104	040	
	116403	123	105	122	
	116406	126	111	103	
	116411	105	040	115	
	116414	117	104	105	
	116417	200	000		
4977	116421	032	000		MSG104: .BYTE 32,0 :CONTROL Z
4978	116423	200	105	116	MSG105: .ASCIZ <CRLF>/ENTER BANKS IN OCTAL - USE NUMBER OUTSIDE RANGE TO TERMINATE (177)/
	116426	124	105	122	
	116431	040	102	101	
	116434	116	113	123	
	116437	040	111	116	
	116442	040	117	103	
	116445	124	101	114	
	116450	040	055	040	
	116453	125	123	105	
	116456	040	116	125	
	116461	115	102	105	
	116464	122	040	117	
	116467	125	124	123	
	116472	111	104	105	
	116475	040	122	101	
	116500	116	107	105	
	116503	040	124	117	
	116506	040	124	105	
	116511	122	115	111	

	116514	116	101	124	
	116517	105	040	050	
	116522	061	067	067	
	116525	051	000		
4979	116527	200	103	101	MSG106: .ASCIZ <CRLF>/CACHE IS OFF/
	116532	103	110	105	
	116535	040	111	123	
	116540	040	117	106	
	116543	106	000		
4980	116545	200	103	101	MSG107: .ASCIZ <CRLF>/CACHE IS ON (EXCEPT DURING ACTUAL PATTERNS)/
	116550	103	110	105	
	116553	040	111	123	
	116556	040	117	116	
	116561	040	050	105	
	116564	130	103	105	
	116567	120	124	040	
	116572	104	125	122	
	116575	111	116	107	
	116600	040	101	103	
	116603	124	125	101	
	116606	114	040	120	
	116611	101	124	124	
	116614	105	122	116	
4981	116617	123	051	000	MSG108: .ASCIZ <CRLF>/ONLY MULTIPOINT TESTS WILL BE RUN/
	116622	200	117	116	
	116625	114	131	040	
	116630	115	125	114	
	116633	124	111	120	
	116636	117	122	124	
	116641	040	124	105	
	116644	123	124	123	
	116647	040	127	111	
	116652	114	114	040	
	116655	102	105	040	
	116660	122	125	116	
	116663	000			
4982	116664	200	102	117	MSG109: .ASCIZ <CRLF>/BOTH SINGLE & MULTIPOINT TESTS WILL BE RUN/
	116667	124	110	040	
	116672	123	111	116	
	116675	107	114	105	
	116700	040	046	040	
	116703	115	125	114	
	116706	124	111	120	
	116711	117	122	124	
	116714	040	124	105	
	116717	123	124	123	
	116722	040	127	111	
	116725	114	114	040	
	116730	102	105	040	
	116733	122	125	116	
	116736	000			
4983	116737	200	117	116	MSG110: .ASCIZ <CRLF>/ONLY SELECTED BANKS WILL BE TESTED/
	116742	114	131	040	
	116745	123	105	114	
	116750	105	103	124	
	116753	105	104	040	
	116756	102	101	116	

MESSAGES

	116761	113	123	040	
	116764	127	111	114	
	116767	114	040	102	
	116772	105	040	124	
	116775	105	123	124	
	117000	105	104	000	
4984	117003	200	101	114	MSG111: .ASCIZ <CRLF>/ALL BANKS WILL BE TESTED/
	117006	114	040	102	
	117011	101	116	113	
	117014	123	040	127	
	117017	111	114	114	
	117022	040	102	105	
	117025	040	124	105	
	117030	123	124	105	
	117033	104	000		
4985	117035	200	120	122	MSG112: .ASCIZ <CRLF>/PROGRAM HALTING BECAUSE OF SWITCH #8/
	117040	117	107	122	
	117043	101	115	040	
	117046	110	101	114	
	117051	124	111	116	
	117054	107	040	102	
	117057	105	103	101	
	117062	125	123	105	
	117065	040	117	106	
	117070	040	123	127	
	117073	111	124	103	
	117076	110	040	043	
	117101	070	000		
4986	117103	040	115	101	MSG113: .ASCIZ / MASTER/
	117106	123	124	105	
	117111	122	000		
4987	117113	040	123	114	MSG114: .ASCIZ / SLAVE1/
	117116	101	126	105	
	117121	061	000		
4988	117123	040	123	114	MSG115: .ASCIZ / SLAVE2/
	117126	101	126	105	
	117131	062	000		
4989	117133	040	123	114	MSG116: .ASCIZ / SLAVE3/
	117136	101	126	105	
	117141	063	000		
4990					.EVEN
4996	117144				\$\$END
4997	117144				END:
4998	117144	000406			.PRINT 60000-SUPLIMIT ;SUPERVISOR ADDRESSES LEFT
5003	117144	002004			.PRINT 100000-SLAVEND ;ADDRESSES LEFT IN SLAVE UNIQUE CODE
5008	117144	020634			.PRINT 140000-END ;ADDRESSES LEFT IN 24K
5012		000200			.END START3

SYMBOL TABLE								
ABORTF	002142	BIT4	= 000020	B144	062364	B36	024446	
ACFLAG	002124	BIT5	= 000040	B145	062450	B37	024452	
ACK	002672	BIT6	= 000100	B146	062572	B4	010550	
ACTFLA	002442	BIT7	= 000200	B147	062630	B40	024616	
ADDPAR	014570	BIT8	= 000400	B15	013004	B41	024624	
ADDRES	002040	BIT9	= 001000	B150	062632	B42	025034	
ADD..0	071152	BLOCK1	043710	B151	062674	B43	033412	
ADD..1	071162	BLOCK2	043730	B152	063032	B44	033450	
ADD..2	071202	BLOCK3	043744	B153	063070	B45	033464	
ADD..3	071232	BMFLAG	002136	B154	063120	B46	033604	
ADD..4	071262	BOOT	043416	B155	063170	B47	033764	
ADD..5	071264	BOOTLO=	000012	B156	063172	B5	010554	
ADD..6	071304	BOOT1	043460	B157	063330	B50	034006	
ADD..7	071334	BRGOBB	035112	B16	013014	B51	040014	
ALLCPU	002510	B0	005500	B160	063404	B52	040020	
APTCOR	002522	B1	007742	B161	063410	B53	040160	
APTDOW	043640	B10	011352	B162	063472	B54	040164	
APTFLA	002444	B100	053774	B163	063522	B55	040450	
APTHAN	015050	B101	054102	B164	063602	B56	040454	
APTHLT	043706	B102	054146	B165	063604	B57	041144	
APTMOS	002574	B103	054226	B166	063754	B6	010642	
APTSIZ	002544	B104	054234	B167	064016	B60	041152	
ASRBAL=	000110	B105	054256	B17	013016	B61	041302	
A3 =	000002	B106	054370	B170	064052	B62	041306	
BACKGN	035344	B107	054416	B171	064122	B63	042530	
BAD	002056	B11	011360	B172	064124	B64	046374	
BADCSR	002000	B110	054472	B173	064246	B65	046744	
BADPC	002026	B111	054474	B174	064260	B66	047612	
BADPSW	002036	B112	055374	B175	064316	B67	050170	
BADSP	002032	B113	055400	B176	064372	B7	010732	
BADSTA	036770	B114	055700	B177	064512	B70	050512	
BADXOR	002064	B115	055706	B2	010312	B71	050512	
BAD2	002060	B116	057452	B20	013124	B72	050600	
BAD3	002062	B117	057474	B200	070344	B73	050752	
BAFPAF	015204	B12	012140	B201	070436	B74	053016	
BAFPAR	015320	B120	057622	B202	070736	B75	053024	
BAKPAT	002762	B121	057756	B203	070740	B76	053660	
BALANC-	000155	B122	060072	B204	071610	B77	053710	
BANK	002106	B123	060244	B205	071614	CACHK	002700	
BANKIN	002110	B124	060256	B206	071730	CACHOF=	104424	
BANKMO	042072	B125	060264	B207	072012	CACHON=	104423	
BANKOK	042730	B126	060514	B21	013220	CACHVE=	000114	
BAWPAF	015434	B127	060754	B210	072076	CBCSR =	104474	
BAWPAR	015572	B13	012144	B211	072174	CB1CSR=	104475	
BDSWIT	002500	B130	061340	B22	013270	CHECK	002404	
BEGIN	005752	B131	061352	B23	013632	CHKDIS=	104504	
BGTEST	035110	B132	061412	B24	014144	CHKGEN	040540	
BIT0 =	000001	B133	061520	B25	014512	CHKTAB	040640	
BIT1 =	000002	B134	061572	B26	015114	CHK1DI=	104505	
BIT10 =	002000	B135	061724	B27	016722	CKEND	073316	
BIT11 =	004000	B136	061736	B3	010316	CKSWR =	104410	
BIT12 =	010000	B137	061774	B30	016744	CLRCR=	104502	
BIT13 =	020000	B14	012556	B31	016750	CLR1CS=	104503	
BIT14 =	040000	B140	062102	B32	016762	CMD11A	047774	
BIT15 =	100000	B141	062154	B33	017044	CMD11B	050164	
BIT2 =	000004	B142	062312	B34	017060	CMD11C	050240	
BIT3 =	000010	B143	062350	B35	023232	CMD19L=	000070	
							CMD20A	050576
							CMD5A	045456
							CMD5B	045666
							CMD5C	046052
							CMD7A	046336
							CMD8A	046550
							CMD8B	046740
							CMD8C	047014
							CMD9A	047240
							CMD9B	047456
							CMD9C	047464
							CMD9LO	047444
							CONFGE	002576
							CONFGT	006666
							CONF1	006304
							CONF3	006520
							CONF5	006712
							CONFIE	004336
							CONF IG	003016
							CONF SP	006754
							CONTFI	002332
							CONTP	073112
							CONTRL=	177746
							CONTS	073544
							CONTS1	073052
							CONTS2	073546
							CONT	073404
							COREHI	043300
							COUNT	002462
							CPUBIT	002114
							CPUERR=	177766
							CPUID	011656
							CR =	000015
							CRLF =	000200
							CSR	002144
							CSRCAS	020114
							CSRFB	002214
							CSRFB A	002410
							CSRFR	002336
							CSRINC	002414
							CSRIND	002416
							CSRLB	002234
							CSRLBA	002412
							CSRL00	002420
							CSRNO	002256
							CSROUD	002417
							CSROUT	040442
							CSRREL	002254
							CSRSTU=	000031
							CSRO	002154
							CSR2	002174
							DATBUF	002340
							DBEMSK	002354
							DDISP =	177570
							DECMAR	043152
							DEEMER=	104421
							DETAIL	071364

SYMBOL TABLE							
E76	053734	IIII =	177777	K12	002554	L1016	070460
E77	053730	IISTAC	002736	K13	002556	L1017	070542
FASTCI=	177640	IISTAD	002740	K14	002560	L102	011414
FATALS	002070	IISTIN	061074	K15	002562	L1020	070602
FCMD10	047530	IISTOF	061174	K16	002564	L1021	070570
FCMD11	047734	IISTVE	002742	K17	002566	L1022	070576
FCMD12	050330	IITRAP	036764	KMAP =	104422	L1023	070624
FCMD13	050356	INCBNK	042772	KPFLAG	002122	L1024	070640
FCMD14	050400	INCMAR	043006	KSTACK	002706	L1025	070654
FCMD15	050420	INCPAT	042746	LAST =	157776	L1026	070670
FCMD16	050436	INCRPT	042746	LASTB	002262	L1027	071072
FCMD17	050454	INTERL	002264	LASTER	002020	L103	011416
FCMD18	050470	INTER0	006756	LBLS0 =	001057	L1030	071072
FCMD19	050502	INTER1	006760	LBLS1 =	001055	L1031	071056
FCMD20	050566	INTER2	006760	LBLS10=	000223	L1032	071122
FIELDS	043774	INTER3	006766	LBLS11=	000034	L1033	071200
FINDBA=	000061	INTER4	006766	LBLS2 =	001050	L1034	071230
FIRST -	060000	INTER5	006774	LBLS3 =	001051	L1035	071260
FIRSTB	002260	INTER6	006766	LBLS4 =	001032	L1036	071302
FIRSTP=	000010	INTER7	006774	LBLS5 =	000712	L1037	071332
FLIPLO	002734	INTKRA	017610	LBLS6 =	000714	L104	011532
FLIPWA	035214	INT..0	020234	LBLS7 =	000033	L1040	071362
FLUSH	014656	INT..1	020260	LCSROU=	000055	L1041	071646
FSCMD0	044170	INT..2	020324	LCSRRE=	000114	L1042	072046
FSCMD1	044256	INT..3	020350	LCSRSA=	000112	L1043	072052
FSCMD2	044346	INT..4	020414	LF =	000012	L1044	072132
FSCMD3	044520	INT..5	020440	LKS =	177546	L1045	072136
FSCMD4	044764	INT..6	020504	LOADBA	002532	L1046	072316
FSCMD5	045274	INT..7	020530	LOADCS=	104425	L1047	072264
FSCMD6	046152	INT..10	020574	LOADER=	000057	L105	011574
FSCMD7	046160	INT..11	020574	LOADHO	002710	L1050	072316
FSCMD8	046510	INT..12	020616	LOADRS=	177740	L1051	072316
FSCMD9	047104	INT..13	020642	LOCK	002670	L1052	073034
FSINFL	002542	INT..14	020706	LOOP	014342	L1053	073452
FSPAT	045752	INT..15	020732	LOWMAP	042026	L1054	073540
FSSIAC	002374	INT..16	020776	LSTSS =	000000	L1055	073464
FS1	044052	INT..17	021022	LWDBE =	000053	L1056	073600
FS7FLA	002546	INVALI=	104511	LWSBE =	000051	L1057	073602
GBLENG=	000076	IOTVEC=	000020	L0	004426	L106	011614
GDSWIT	002476	ISECCO	017300	L1	004422	L107	011634
GETDAT	055030	J	002604	L10	005376	L11	005376
GETDA1	055156	KAMIKA	002010	L100	011552	L110	011654
GETDIS	066514	KAMITE	026006	L1000	067226	L111	011672
GETSI2	017736	KDIAG =	000010	L1001	067240	L112	011714
GOOD	002050	KDPAR0=	172360	L1002	067276	L113	011766
GOOD2	002052	KDPAR7=	172376	L1003	067306	L114	012034
GOOD3	002054	KDPDR7=	172336	L1004	067630	L115	012130
GTSWR =	104407	KERNEL=	104417	L1005	070316	L116	012250
HEADER	002724	KERSTK=	002000	L1006	070234	L117	012372
HIACBA	002514	KIPAR0=	172340	L1007	070234	L12	005370
HIADRS=	177742	KIPAR4=	172350	L101	011416	L120	012422
HIBANK	002512	KIPAR5=	172352	L1010	070274	L121	012416
HIPAT	042762	KIPAR6=	172354	L1011	070262	L122	012420
HT	000011	KIPAR7=	172356	L1012	070270	L123	012514
HUNGMS	002572	KIPDR0=	172300	L1013	070360	L124	012474
HUNGTI	002574	KI0	002550	L1014	070366	L125	012474
:	002602	KI1	002552	L1015	070452	L126	012550
						L127	012700
						L13	005376
						L130	012700
						L131	012764
						L132	013046
						L133	013046
						L134	013160
						L135	013174
						L136	013254
						L137	013226
						L14	005470
						L140	013620
						L141	013472
						L142	013472
						L143	013472
						L144	013416
						L145	013434
						L146	013452
						L147	013470
						L15	005510
						L150	013604
						L151	013534
						L152	013542
						L153	013604
						L154	013702
						L155	013656
						L156	013702
						L157	014032
						L16	005570
						L160	014112
						L161	014116
						L162	014336
						L163	014254
						L164	014172
						L165	014174
						L166	014234
						L167	014250
						L17	005654
						L170	014304
						L171	014306
						L172	014336
						L173	014456
						L174	014566
						L175	014546
						L176	014546
						L177	014622
						L2	004536
						L20	005616
						L200	014622
						L201	014656
						L202	014734
						L203	014744
						L204	015100
						L205	015166
						L206	015306
						L207	015422
						L21	005634

SYMBOL TABLE

L210	015560	L273	022546	L355	025200	L437	040210	L520	045574
L211	015716	L274	022600	L356	025152	L44	007700	L521	045714
L212	016054	L275	022614	L357	025224	L440	040210	L522	045716
L213	016234	L276	022624	L36	006630	L441	040252	L523	046232
L214	016372	L277	022624	L360	025350	L442	040260	L524	046234
L215	016552	L3	005046	L361	025540	L443	040376	L525	046442
L216	016674	L30	006242	L362	025756	L444	040432	L526	046602
L217	017230	L300	022662	L363	025770	L445	040462	L527	046604
L22	005636	L301	022672	L364	026030	L446	041114	L53	010202
L220	017152	L302	022672	L365	026036	L447	041144	L530	046630
L221	017034	L303	022732	L366	026042	L45	007714	L531	046644
L222	017152	L304	022746	L367	033434	L450	041246	L532	046646
L223	017134	L305	022756	L37	006712	L451	041276	L533	046772
L224	017214	L306	022756	L370	033444	L452	041410	L534	047154
L225	017366	L307	023010	L371	033556	L453	041410	L535	047156
L226	017372	L31	006356	L372	033506	L454	041410	L536	047272
L227	017724	L310	023024	L373	033520	L455	041410	L537	047274
L23	005714	L311	023034	L374	033536	L456	041410	L54	010300
L230	020016	L312	023034	L375	033544	L457	041436	L540	047320
L231	020030	L313	023066	L376	033570	L46	010226	L541	047720
L232	020072	L314	023102	L377	033726	L460	041534	L542	047704
L233	020110	L315	023112	L4	005144	L461	042550	L543	047654
L234	020224	L316	023112	L40	006734	L462	042720	L544	050026
L235	020306	L317	023172	L400	033626	L463	043026	L545	050030
L236	020314	L32	006406	L401	033640	L464	043114	L546	050054
L237	020376	L320	023202	L402	033672	L465	043134	L547	050070
L24	005774	L321	023202	L403	033656	L466	043230	L55	010304
L240	020404	L322	023300	L404	033670	L467	043232	L550	050072
L241	020466	L323	023270	L405	033714	L47	010226	L551	050216
L242	020474	L324	023400	L406	033702	L470	043256	L552	050534
L243	020556	L325	023402	L407	033714	L471	043264	L553	050536
L244	020564	L326	023432	L41	007152	L472	043410	L554	050724
L245	020614	L327	023436	L410	034026	L473	043410	L555	050726
L246	020670	L33	006476	L411	035504	L474	043364	L556	051030
L247	020676	L330	023466	L412	036150	L475	043410	L557	050774
L25	006010	L331	023472	L413	036220	L476	043444	L56	010306
L250	020760	L332	023526	L414	036246	L477	043542	L560	051010
L251	020766	L333	023532	L415	036240	L5	005222	L561	051026
L252	021050	L334	023562	L416	036246	L50	010166	L562	051056
L253	021056	L335	023566	L417	037136	L500	043546	L563	051170
L254	021174	L336	023744	L42	007156	L501	043554	L564	051414
L255	021216	L337	023776	L420	037142	L502	043574	L565	051514
L256	021232	L34	006564	L421	037202	L503	043606	L566	051644
L257	021250	L340	024042	L422	037206	L504	044016	L567	051656
L26	006160	L341	024206	L423	037424	L505	044026	L57	010350
L260	021254	L342	024216	L424	037432	L506	044160	L570	052414
L261	021256	L343	024216	L425	037510	L507	044220	L571	052442
L262	021322	L344	024544	L426	037544	L51	010166	L572	052510
L263	021344	L345	024530	L427	037634	L510	044224	L573	052522
L264	021372	L346	024544	L43	007160	L511	044246	L574	053076
L265	021372	L347	024610	L430	037670	L512	044252	L575	053202
L266	021522	L35	006614	L431	037730	L513	045416	L576	053200
L267	021566	L350	024716	L432	037772	L514	045456	L577	053232
L27	006160	L351	024702	L433	040044	L515	045510	L6	005246
L270	022522	L352	024716	L434	040044	L516	045512	L60	010346
L271	022536	L353	025076	L435	040106	L517	045536	L600	053232
L272	022546	L354	025076	L436	040114	L52	010166	L601	053734

SYMBOL TABLE

L602	053722	L665	061636	L747	065762	MHALT2	005770	MSG024	113316
L603	053726	L666	061630	L75	011306	MHALT3	012760	MSG025	113340
L604	054350	L667	062240	L750	065774	MINDEX	002666	MSG026	113371
L605	054200	L67	011110	L751	066006	MJPAT	021600	MSG027	113403
L606	054272	L670	062040	L752	066030	MJSIZE	002466	MSG028	113420
L607	054314	L671	062066	L753	066076	MJTEST	021512	MSG029	113434
L61	010576	L672	062220	L754	066156	MKCONT	016664	MSG030	113454
L610	054450	L673	062212	L755	066172	MKCSRS	002334	MSG031	113473
L611	054526	L674	062530	L756	066174	MKCSRT	020124	MSG032	113533
L612	054532	L675	062402	L757	066250	MKFLAG	002126	MSG033	113552
L613	054626	L676	062502	L76	011320	MKPAT	021402	MSG034	113571
L614	054642	L677	062756	L760	066316	MKSIZE	002470	MSG035	113707
L615	054646	L7	005316	L761	066312	MKTEST	021222	MSG036	113712
L616	054664	L70	011224	L762	066316	MK11AD=	172100	MSG037	113731
L617	055024	L700	062726	L763	066350	MMRO	= 177572	MSG038	113750
L62	010672	L701	063010	L764	066360	MMR1	= 177574	MSG039	113766
L620	055174	L702	063240	L765	066624	MMR2	= 177576	MSG040	114010
L621	055312	L703	063152	L766	066746	MMR3	= 172516	MSG041	114055
L622	055416	L704	063224	L767	066746	MMTRAP	036740	MSG042	114102
L623	055550	L705	063230	L77	011332	MMVEC	= 000250	MSG043	114123
L624	055724	L706	063272	L770	067116	MOVELO=	000124	MSG044	114150
L625	057152	L707	063306	L771	067050	MP1	012070	MSG045	114175
L626	057136	L71	011236	L772	067074	MP2	012224	MSG046	114231
L627	057152	L710	063562	L773	067076	MP3	012716	MSG047	114264
L63	011076	L711	063562	L774	067116	MP4	012552	MSG048	114303
L630	057314	L712	063454	L775	067300	MP5	012764	MSG049	114343
L631	057202	L713	063450	L776	067164	MRUNSE	053640	MSG050	114375
L632	057216	L714	063454	L777	067276	MSEEDH	002720	MSG051	114503
L633	057232	L715	063662	MAINT	= 177750	MSEEDL	002722	MSG052	114523
L634	057326	L716	063662	MAPHO	= 170202	MSGA34	113625	MSG053	114554
L635	057604	L717	063722	MAPH36=	170372	MSGAB7	115753	MSG054	114572
L636	057564	L72	011250	MAPH37=	170376	MSGA98	116242	MSG055	114642
L637	060040	L720	064160	MAPLO	= 170200	MSGB34	113642	MSG056	114663
L64	011076	L721	064104	MAPL1	= 170204	MSG000	111176	MSG057	114716
L640	057724	L722	064150	MAPL36=	170370	MSG001	111254	MSG058	114722
L641	060022	L723	064224	MAPPER	040700	MSG002	111336	MSG059	114766
L642	060174	L724	064230	MARGIN	002112	MSG003	111413	MSG060	115016
L643	060174	L725	064442	MASTER-	000020	MSG004	111520	MSG061	115060
L644	060416	L726	064336	MAST01	057372	MSG005	111626	MSG062	115067
L645	060366	L727	064344	MAST02	060046	MSG006	111640	MSG063	115107
L646	060554	L73	011262	MAST03	060220	MSG007	111675	MSG064	115120
L647	060572	L730	064424	MAST04	061322	MSG008	111707	MSG065	115130
L65	011060	L731	064552	MAST05	061706	MSG009	111721	MSG066	115142
L650	060610	L732	065346	MAST06	062270	MSG010	111733	MSG067	115225
L651	060626	L733	065360	MAST07	062550	MSG011	111745	MSG068	115234
L652	060644	L734	065376	MAST10	062776	MSG012	112033	MSG069	115241
L653	060662	L735	065400	MAST11	063260	MSG013	112130	MSG070	115246
L654	060700	L736	065420	MAST12	063732	MSG014	112132	MSG071	115271
L655	060716	L737	065432	MAST13	064200	MSG015	112134	MSG072	115304
L656	060734	L74	011274	MAST14	064204	MSG016	112136	MSG073	115317
L657	060746	L740	065450	MAST15	064472	MSG017	112150	MSG074	115336
L66	011060	L741	065452	MASWR	002674	MSG018	112161	MSG075	115341
L660	061162	L742	065466	MDISPL	002676	MSG019	112164	MSG076	115373
L661	061162	L743	065676	MEMDON	014410	MSG020	112170	MSG077	115414
L662	061656	L744	065704	MEMERR=	177744	MSG021	112224	MSG078	115430
L663	061456	L745	065732	MEMSIZ-	000004	MSG022	113252	MSG079	115474
L664	061504	L746	065750	MHALT1	004532	MSG023	113274	MSG080	115520

MSG081	115560	MTPC26	034646	MT0027	024370	O.CSR2	075575	O.STM =	000340
MSG082	115577	MTPD03	026630	MT0030	024754	O.CT	075730	O.SVR	100360
MSG084	115617	MTPD21	033354	MT0031	025214	O.CTLC	076162	O.SVTT	100500
MSG085	115661	MTPD25	034412	MT0033	025340	O.CTLE	076242	O.T	075572
MSG086	115706	MTPD26	034666	MT0034	025530	O.CTLF	076210	O.TBIT	077644
MSG087	115745	MTPD25	034434	MT0035	025652	O.C1	100000	O.TBT =	000020
MSG088	115760	MTP000	026376	MT020X	023604	O.DCD	076520	O.TCL2	076442
MSG089	115776	MTP001	026422	MT020Y	023472	O.DCDA	077144	O.TCSR =	177564
MSG090	116020	MTP002	026454	MT020Z	023322	O.DCD1	076550	O.TDB =	177566
MSG091	116034	MTP005	026724	MT0999	025772	O.DCD3	076530	O.TL	101345
MSG092	116046	MTP006	026760	MULHLT	056150	O.DOT	075562	O.TRTC	101370
MSG093	116062	MTP007	027150	MULTIE	060746	O.ERR	076510	O.TVEC =	000014
MSG094	116070	MTP010	027250	MULTIO	002004	O.ERR1	077572	O.TYPE	101126
MSG095	116077	MTP011	027356	MULTIP	003014	O.ERR2	077164	O.TYP1	101004
MSG096	116106	MTP012	027766	MULTIU	056142	O.ERR3	077150	O.UIN	075752
MSG097	116137	MTP013	030344	MUT	002116	O.FIL	075576	O.UPC	075700
MSG098	116234	MTP014	030716	M3BAL	054472	O.FTYP	100730	O.UR0	075662
MSG099	116245	MTP015	031312	NEMCNT	002072	O.GET	101006	O.USP	075676
MSG100	116256	MTP016	031700	NEWBAN	002400	O.GO	077576	O.UST	075702
MSG101	116305	MTP017	032302	NEWKER	042322	O.GOGO	077624	O.WRD	076760
MSG102	116335	MTP020	032360	NEWLOA	042370	O.G02	077676	O.WRD1	077036
MSG103	116364	MTP022	033404	NOBALA =	000164	O.ID	101300	O.WST	101202
MSG104	116421	MTP025	034152	NOCLOC	002104	O.IDND =	101315	O.XXX	075564
MSG105	116423	MTP030	034704	NOECFF	002474	O.LG =	000020	PADDRE	002042
MSG106	116527	MTP031	034714	NOERRO	002530	O.LGCH	101321	PAFBAF	015730
MSG107	116545	MTP033	035054	NOFSMO	002526	O.MIN	076502	PAFBAW	016066
MSG108	116622	MTP034	035106	NOLIST	002756	O.MINS	075603	PARBAF	016246
MSG109	116664	MTP20A	032360	NONEM	002102	O.ODT	075774	PARBAW	016404
MSG110	116737	MTP20B	032376	NONEXI	036646	O.OFST	077466	PARCNT	002074
MSG111	117003	MTP20C	032430	NOPAR	002100	O.OLD	077154	PARITY	036454
MSG112	117035	MTP20D	032462	NOSCOF	002540	O.OP1	077160	PARTHE	002372
MSG113	117103	MTP20E	032514	NOTAB	002464	O.OP2	077220	PARVEC =	000114
MSG114	117113	MTP20F	032546	NULLFL	002436	O.OP2A	077226	PASFLG	002362
MSG115	117123	MTV020	023320	OLDCAC	002370	O.ORAB	076364	PATERR	002076
MSG116	117133	MT0000	021704	OLDMAR	002376	O.ORPC	076342	PATPLU	005472
MST11A	063602	MT0001	021740	ONCE	002732	O.ORRB	076374	PATTER	002120
MTA030	024760	MT0002	022000	ONES	002726	O.P	075573	PCBUMP	002406
MTEST	016564	MT0003	022050	O.ADR1	075706	O.PRI	075704	PCONF1	035402
MTPA03	026506	MT0004	022216	O.BACK	077302	O.PROC	077732	PCONFS	035662
MTPA04	026650	MT0005	022300	O.BD	101366	O.PR1	077764	PCONF1	035572
MTPA20	032572	MT0006	022360	O.BIAS	075604	O.RALL	077430	PCONF2	035630
MTPA21	033234	MT0007	022414	O.BKP =	000016	O.RCSR =	177560	PDP110	036752
MTPA24	034060	MT0010	022456	O.BKPT	077324	O.RDB =	177562	PENDB0	002330
MTPA25	034464	MT0011	022512	O.BK1	100060	O.REGT	076270	PERA05	064732
MTPA26	034576	MT0012	022570	O.BRK	100042	O.REM	100602	PERBNK	065564
MTPA32	034772	MT0013	022646	O.BW	075566	O.RORA	101272	PERECC	065650
MTPB03	026550	MT0014	022722	O.BYT	076772	O.RRST	101172	PERRAB	065402
MTPB04	026704	MT0015	023000	O.CAD	075560	O.RSB	100450	PERRAW	065330
MTPB21	033264	MT0016	023056	O.CADV	100634	O.RSR	100416	PERRA3	054652
MTPB24	034120	MT0017	023134	O.CLGT =	000024	O.RSTT	100534	PERRA7	065454
MTPB25	034504	MT0020	023156	O.CLSE	101214	G.S	075571	PERR01 =	104427
MTPB26	034612	MT0021	023612	O.CMFD	075600	O.SCAN	076554	PERR02 =	104430
MTPB32	035020	MT0022	023734	O.CR	101316	O.SCRN	075602	PERR03 =	104431
MTPC03	026610	MT0023	023766	O.CRET	077140	O.SEMI	076742	PERR04 =	104432
MTPC21	033320	MT0024	024032	O.CRLF	101246	O.SEQ	075570	PERR05	064726
MTPC24	034134	MT0025	024172	O.CRLS	101254	O.SMFD	075601	PERR06	064754
MTPC25	034536	MT0026	024240	O.CSR1	075574	O.SNGL	076446	PERR07 =	104433

SYMBOL TABLE

PERR10=	104434	RESTAR	002752	START1	000300	TAG72\$	067656	TST1	006260
PERR11=	104435	RESVEC=	000010	START2	000310	TAG73\$	067722	TST2	007004
PERR12=	104436	RLFLAG	002134	START3	000200	TAG74\$	067730	TST3	007160
PERR13=	104437	RRFLAG	002132	START4	000322	TAG75\$	067742	TST4	010310
PERR14=	104440	RTNVAL=	X000000	STOPCP	011720	TAG76\$	067754	TST5	014342
PERR15=	104441	RUNCOU=	000171	STOPOK	002520	TAG77\$	067776	TST6	014414
PERR16=	104442	SAME SA=	000015	STR1PE	002460	TAG78\$	070000	TST7	014456
PERR17=	104443	SAVREG=	104415	STRTDI	002364	TAG79\$	070006	TWOCSR	002600
PERR20=	104444	SBEC SR	002150	SUBAAA	005532	TAG80\$	070066	TYPDS =	104405
PERR21=	104445	SBEFLA	002022	SUBAAB	005200	TAG81\$	070100	TYPEIT=	104401
PERR22=	104446	SBEMSK	002350	SUBAAQ	007720	TAG82\$	070122	TYPOC =	104402
PERR23=	104447	SBETES	017374	SUBAAR	013160	TAG83\$	070324	TYPOS =	104403
PERR24=	104450	SCOPE -	000004	SUBAAS	007002	TAG84\$	070410	TYPS0 =	000000
PERH25=	104451	SDPAR0=	172260	SUBAAT	011334	TAG85\$	070502	TYPS1 =	000000
PERR26=	104452	SDPAR7=	172276	SUBAAU	014602	TAG86\$	070612	TYPS10=	000000
PERR27=	104453	SDPDR7=	172236	SUCCE\$	002424	TAG9\$	007232	TYPS11=	000002
PERR30=	104454	SECOND=	011661	SUPDOA	002360	TASK	002616	TYPS2 =	000000
PERR31=	104455	SEEDHI	002714	SUPDO1	026042	TASKDO	050726	TYPS3 =	000000
PERR32=	104456	SEEDLO	002716	SUPDO2	026056	TASKRE	050710	TYPS4 =	000000
PERR33=	104457	SELONL	002002	SUPDO3	026220	TASK00	051234	TYPS5 -	000000
PERR34=	104460	SETMAR	043212	SUPDO4	026234	TASK01	051236	TYPS6 =	000000
PERR35=	104461	SETPAT	042762	SUPDRO	002266	TASK02	051330	TYPS7 =	000002
PERR36=	104462	SHALT	004420	SUPDR1	002270	TASK03	051430	T12A	031700
PERR37=	104463	SHUTUP	043554	SUPDR2	002272	TASK04	051664	T12B	031722
PERR40=	104464	SIDE	002422	SUPDR3	002274	TASK05	051774	UDPAR0=	177660
PERR41=	104465	SIDEOK	021066	SUPDR4	002276	TASK06	052300	UDPAR1=	177662
PERR42=	104466	SIPARO=	172240	SUPDR5	002300	TASK07	052326	UDPAR7=	177676
PERR43=	104467	SIPAR3=	172246	SUPDR6	002302	TASK10	052336	UDPDR7=	177636
PERXOR	065540	SIPDRO=	172200	SUPLIM	057372	TASK11	052536	UIPAR0=	177640
PFLAG	002130	SIZE =	040000	SUPM13	053752	TASK12	052644	UIPAR2=	177644
PHYADD	002044	SIZELO=	177760	SUPSTK=	000740	TASK13	052726	UIPAR3=	177646
PORTCO	002646	SKIPKA	002012	SWAPAT	002764	TASK14	053276	UIPAR4=	177650
PORTDI	002606	SLAVEM	061244	SWR	002766	TASK15	053310	UIPAR5=	177652
PROTEC=	000002	SLAVEN	075774	SWREG =	000176	TASK16	053316	UIPAR6=	177654
PSW =	177776	SLAVER	002570	SW0 =	000001	TASK17	053334	UIPAR7=	177656
PTYBUF	002636	SLAVES	002730	SW1 =	000002	TASK20	053422	UIPDRO=	177600
PTYFLA	002626	SLAVE1=	000040	SW10 =	002000	TASK7A	052344	UNITOP	002516
PWLOCK	002760	SLAVE2=	000100	SW11 =	004000	TBG4\$	026314	UNRELO	041604
PWRVEC=	000024	SLAVE3=	000200	SW12 =	010000	TCFIG1	036012	UPPFLG	002363
QUE	072154	SLAVUP	061216	SW13 =	020000	TCONF1	035664	UP2	056154
QUE1	072222	SLFLAG	002656	SW14 =	040000	TEMP	002534	USERMA	042240
QUICK	002536	SLPAT	051570	SW15 =	100000	TESTAD	002506	USESTK=	000700
QVFLAG	002440	SLPATO	051530	SW2 =	000004	TIME	002434	USP =	X000006
RANODD	034626	SLPAT1	051534	SW3 =	000010	TIMEOU	036726	WAITST	012034
RDCHR =	104411	SLPAT2	051542	SW4 =	000020	TKVEC =	000060	WAIT5	063674
RDDEC =	104414	SLPAT3	051550	SW5 =	000040	TFLAG	002140	WAKEUP	054544
RDLIN =	104412	SLPAT4	051556	SW6 =	000100	TOOMAN	002472	WARN1	007320
RDOCT =	104413	SLPAT5	051564	SW7 =	000200	TRAPVE=	000034	WARN2	026522
READCS=	104426	SOBK	002704	SW8 =	000400	TRT =	000003	WARN3	026536
READON	002504	SOBLEN=	000056	SW9 =	001000	TSK05A	052240	WARN4	026562
REALPA	002366	SOF TPA	002744	SYSSIZ	011210	TSK13A	053100	WARN5	026576
REFRES	033760	SOURCE	002402	SYSTID	177764	TSK13B	053136	WARN6	035364
REFSUB	034030	SPECIA	002432	TAG2\$	007366	TSK20A	053602	WARN7	024416
REGCOP	035204	SSP -	X000006	TAG3\$	007412	TSTBAN	007606	WASDBE=	104500
RELOCA	041130	ST -	177776	TAG4\$	026136	TSTDAT	002344	WASSBE=	104476
RELOC1	041456	STACK	002000	TAG70\$	067636	TSTRD1	037434	WAS1DB=	104501
RESREG	104416	STAR	004352	TAG71\$	067646	TSTREA-	104510	WAS1SB=	104477

WHICHL	050630	\$DDW5	075232	\$IS	000001	\$PER01	064574	\$SVS	= 000000
WHOB0X	070672	\$DDW6	075234	\$KERNE	037020	\$PER02	064622	\$SWR	= 163000
WHODUN=	000202	\$DEENE	037040	\$KMAP	041016	\$PER03	064650	\$SWREG	075156
WOOPEN	056512	\$DEVCT	075144	\$KS	= 000204	\$PER04	064700	\$T	= 001060
WOOPS	056160	\$DEVVM	075212	\$L	= 000212	\$PER07	064762	\$TESTN	075140
WOOPSA	056542	\$DIDDO=	000000	\$LF	003011	\$PER10	065004	\$TKB	002774
WOOPUP	056336	\$DOAGA	015040	\$LL	= 000210	\$PER11	065034	\$TKS	002772
WORST	002712	\$DOAGN	015010	\$LOADC	037076	\$PER12	065054	\$TN	= 000010
WRITEO	002502	\$DOWN	055532	\$LOAD1	037146	\$PER13	065076	\$TPB	003000
XXDPCH	002446	\$DTBL	073002	\$LPADR	002746	\$PER14	065116	\$TPFLG	002452
ZERO	002426	\$ECCDI	037466	\$LPERR	002750	\$PER15	065140	\$TPS	002776
ZEROS	002430	\$ECCIN	037554	\$LS	- 000000	\$PER16	065162	\$TRAP	075252
\$APTHD	075236	\$ECCID	037522	\$MADR1	075166	\$PER17	065202	\$TRAP2	075274
\$AUTO	002066	\$ECCI	037574	\$MADR2	075172	\$PER20	065220	\$TRPAD	075314
\$BANK	002015	\$ENASB	037612	\$MADR3	075176	\$PER21	065236	\$STSM	075242
\$BASE	075210	\$ENATS	037646	\$MADR4	075202	\$PER22	065256	\$STRD	037310
\$BELL	003003	\$ENDAD	015000	\$MAIL	075134	\$PER23	065274	\$TTYIN	074200
\$CACHF	037066	\$ENERG	037030	\$MAMS1	075164	\$PER24	065312	\$TYPDS	072576
\$CACHN	037050	\$ENV	075154	\$MAMS2	075170	\$PER25	054570	\$TYPE	056752
\$CBCSR	037700	\$ENVM	075155	\$MAMS3	075174	\$PER26	065502	\$TYPEC	057076
\$CB1CS	037742	\$EOP	014662	\$MAMS4	075200	\$PER27	065522	\$TYPEX	057360
\$CDW1	075214	\$ERFLG	002016	\$MBADR	075240	\$PER30	054762	\$TYPOC	072374
\$CDW2	075216	\$ERROR	066662	\$MNEW	074254	\$PER31	065720	\$TYPON	072410
\$CHARC	057356	\$ERRTB	101372	\$MSGAD	075150	\$PER32	066016	\$TYPOS	072350
\$CHKDI	040354	\$ERRTY	067324	\$MSGLG	075152	\$PER33	066064	\$T1	= 000000
\$CHKID	040410	\$ERTTL	002754	\$MSGTY	075134	\$PER34	066144	\$T2	= 001057
\$CKSWR	073022	\$ESCAP	002454	\$MSWR	074243	\$PER35	066176	\$UNIT	075146
\$CLRCS	040322	\$ETABL	075154	\$MTYP1	075165	\$PWDRN	055160	\$UNITM	075246
\$CLR1C	040340	\$ETEND	075236	\$MTYP2	075171	\$PWRRP	055536	\$USWR	075160
\$CMTAG	002000	\$EXHAL	043546	\$MTYP3	075175	\$QUES	003007	\$VECT1	075204
\$CMTGE	002700	\$ES	- 000001	\$MTYP4	075201	\$R	= 177777	\$VECT2	075206
\$CNTLC	074224	\$FATAL	075136	\$NOTRA	075306	\$RAND	074720	\$WASDB	040146
\$CNTLG	074236	\$FILLC	003002	\$NULL	002450	\$RDCHR	073602	\$WASSB	040002
\$CNTLU	074231	\$FILLS	002451	\$NWTST=	000001	\$RDDEC	074436	\$WASID	040262
\$CPUOP	075162	\$FS	= 000000	\$OCNT	072572	\$RDLIN	073722	\$WASTS	040116
\$CRLF	003010	\$GTSWR	073160	\$OCTVL	075116	\$RDOCT	074266	\$XTSTR	066370
\$DBLK	073012	\$HALT	067136	\$OCT8	= 075122	\$READC	037220	\$YS	= 000000
\$DB20	075014	\$HALT2	075312	\$OMODE	072574	\$RESRE	074662	\$ZAP42	014760
\$DDW0	075220	\$HIBTS	075236	\$OVER	066502	\$SAVRE	074624	\$ZS	= 000000
\$DDW1	075222	\$HIOCT	074434	\$OS	= 000000	\$SAVR6	056140	\$ZSS	000000
\$DDW2	075224	\$ILLUP	056134	\$PASS	075142	\$SCOPE	066232	\$ZST	= 001040
\$DDW3	075226	\$INVAL	040510	\$PASTM	075244	\$STN	= 000001	\$ZST	= 001042
\$DDW4	075230	\$ITEMB	002017	\$PATMA	002014	\$SVLAD	066466	\$ZOFILL	072573

. ABS. 117144 000
 000000 001
 ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 30717 WORDS (120 PAGES)
 DYNAMIC MEMORY: 21872 WORDS (84 PAGES)
 ELAPSED TIME: 01:51:56
 .CEMKAB.LS2/CRF:SYM/-SP=CEMKAB.BIG,CEMKAB.MLB/ML,CEMKAB.MA1,CEMKAB.MA2

EMKAB		CREATED BY MACRC ON 3-AUG-79 AT 17:42		PAGE		H 4				SFC 1041	
SYMBOL	CROSS REFERENCE	REFERENCES									
SYMBOL	VALUE										
ABORTF	002142	#39-1166	*282-6181	394-570	396-607	*396-625	449-1990	449-1993	449-2002	449-2005	
ACFLAG	002124	#39-1159	72-2036	76-2113	*78-2125	78-2126	82-2210	95-2576	95-2590	103-2754	
		110-2847	112-2863	114-2897	116-2931	118-2972	121-3018	123-3060	125-3109	127-3151	
		132-3240	170-4136	170-4159	172-4190	314-6654	*325-6878	*325-6889	352-7479	354-7533	
		358-7682	390-466	413-1076	421-1252	424-1317	426-1377	428-1425	430-1467	434-1534	
		438-1623	440-1684								
ACK	002672	#41-1308	*46-1404	46-1410	*90-2385	91-2424	91-2431	*91-2440	*91-2479		
ACTFLA	002442	#39-1239	*53-1534	66-1826	70-2022	150-3655	150-3668	159-3888	159-3897	159-3905	
		159-3915	161-3926	161-3935	163-3950	*63-3989	163-3995	163-4002	163-4008	166-4091	
		180-4326	336-7055	461-2263							
		103-2751	#103-2768								
ADDPAR	0*4570	#39-1134	*66-1820	*80-2174	*207-4742	*207-4756	*210-4814	*210-4828	*213-4901	*284-6213	
ADDRES	002040	*386-408	*386-416	*394-569	*394-564	*394-591	*396-606	*396-606	396-609	396-619	
		*446-1883	*446-1884	*446-1889	*446-1890	*446-1895	*446-1896	*446-1901	*446-1902	*446-1909	
		*446-1917	*446-1922	*446-1922	*446-1927	*446-1932	*448-1938	*448-1943	*448-1948	*448-1953	
		*448-1958	*448-1963	*448-1968	*448-1973	*448-1978	*448-1983	*453-2053	*455-2083	*455-2092	
		469-2434	478-2631	478-2633	478-2633	478-2635	478-2635	478-2638	478-2640	478-2640	
		478-2642	478-2642	561-4700	561-4703	561-4706	561-4708	561-4713	561-4721		
ADD..0	071152	#476-2604	#478-2629								
ADD..1	071162	476-2605	#478-2631								
ADD..2	071202	476-2606	#478-2633								
ADD..3	071232	476-2607	#478-2635								
ADD..4	071262	476-2608	#478-2637								
ADD..5	071264	476-2609	#478-2638								
ADD..6	071304	476-2610	#478-2640								
ADD..7	071334	476-2611	#478-2642								
ALLCPU	002510	#39-1261	*91-2496	95-2572	390-463	*415-1113	*415-1115	*415-1116	421-1249	424-1314	
		426-1374	428-1422	430-1464	434-1529	438-1620	440-1681				
APTCOP	002522	#39-1266	*99-2686	99-2694	561-4705						
APTDOW	043640	53-1529	#336-7085	336-7088	*336-7090						
APTFLA	002444	#39-1240	*53-1528	55-1547	99-2665	159-3888	159-3897	159-3905	159-3915	161-3926	
		161-3935	163-3950	166-4091	180-4326	336-7055	461-2263				
		93-2558	#108-2832	108-2838							
APTHAN	015050	#336-7092									
APTHLT	043706	#39-1267	*99-2689	99-2694	561-4705						
APTMOS	002524	#39-1275	*53-1524	99-2665							
APTSIZ	002544	155-3840	155-3851	157-3870	165-4025	166-4070	#271-5940	332-7015			
BACKGN	035344	#39-1140	*80-2176	*91-2447	*91-2484	*99-2703	*386-407	*386-415	*390-484	*390-530	
BAD	002056	*394-572	*394-594	*396-609	*396-623	*409-975	*409-1018	*411-1050	*413-1084	*413-1098	
		*421-1267	*421-1289	*424-1331	*424-1353	*426-1403	*428-1444	*430-1480	*436-1591	*436-1605	
		*438-1638	*440-1703	*442-1728	*446-1885	*446-1891	*446-1898	*446-1903	*446-1908	*446-1918	
		*446-1923	*446-1928	*446-1933	*448-1939	*448-1944	*448-1949	*448-1954	*448-1959	*448-1964	
		*448-1969	*448-1974	*448-1979	*448-1984	451-2031	*453-2054	*455-2084	*455-2093	*455-2094	
		*455-2113	475-2567	475-2570	475-2573	475-2576	561-4700	561-4706	561-4708	561-4716	
		561-4720	561-4721	561-4723	561-4725						
BADCSR	002000	#39-1115	471-2475	*476-2597	*476-2598						
BADPC	002026	#39-1129	*284-6240	394-583	449-1991	449-2003	451-2014	453-2064	455-2082	455-2091	
		455-2102	460-2234	460-2235	*460-2239						
BADPSW	002036	#39-1133	*284-6241	455-2113	460-2238						
BADSP	002032	#39-1131	*284-6238	*284-6239	460-2237						
BADSTA	036770	282-6182	282-6196	284-6223	284-6227	284-6230	#284-6237	394-583	446-1911	449-1991	
		449-2003	451-2014	453-2064	455-2082	455-2091	455-2102	455-2112			

CEMKAB
SYMBOL
SYMBOL
BADXOR
BAD2
BAD3
BAFPAF
BAFPAF
BAKPAT
BANK

CREATED BY MACRO ON 3-AUG-79 AT 17:42

PAGE 2
CREF V01

SYMBOL	VALUE	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES
BAD2	002060	#39-1143	*451-2031	*451-2032	561-4706					
BAD3	002062	#39-1141	*394-595	561-4716						
BAFPAF	015204	#39-1142	*394-597	*394-598	561-4716					
BAFPAF	015320	100-2716	#112-2859	112-2888						
BAKPAT	002762	100-2717	#114-2893	114-2922						
BANK	002106	#43-1342	*48-1451	165-4024	166-4069					
		#39-1152	*68-1842	*68-1849	68-1850	68-1852	68-1858	*68-1873	*70-1961	70-1962
		70-1967	*70-2018	70-2018	*70-2020	*72-2034	*72-2042	72-2042	*76-2111	*76-2116
		76-2116	76-2118	*78-2124	78-2126	*78-2127	78-2131	*82-2208	*82-2215	82-2215
		*82-2216	82-2219	*95-2564	*95-2622	95-2622	*103-2752	*103-2761	103-2761	*110-2845
		*110-2853	110-2853	*112-2860	*114-2894	*116-2928	*118-2969	*121-3013	*123-3055	*125-3104
		*127-3146	132-3228	*132-3238	132-3241	*132-3264	132-3264	*132-3279	*170-4134	170-4138
		*170-4150	170-4150	*170-4157	170-4160	*170-4173	170-4173	*172-4187	*172-4196	172-4196
		*172-4206	174-4224	176-4244	178-4282	178-4303	183-4335	186-4369	303-6520	*314-6652
		314-6655	*314-6665	314-6665	318-6725	*318-6726	*318-6730	*318-6734	325-6880	*328-6943
		328-6944	345-7232	*345-7237	*345-7241	345-7244	345-7250	*345-7265	347-7271	*347-7276
		*347-7280	347-7283	347-7289	*347-7317	349-7323	*349-7329	349-7330	349-7332	349-7360
		*349-7435	349-7436	352-7448	*352-7477	352-7481	*352-7488	352-7488	*352-7491	354-7497
		*354-7531	*354-7537	354-7537	*354-7544	354-7545	356-7551	*356-7561	*356-7565	356-7568
		356-7587	*356-7613	356-7614	356-7619	*356-7624	356-7625	356-7633	*356-7639	356-7639
		*356-7641	358-7646	*358-7680	*358-7686	358-7686	*358-7693	358-7694	368-68	368-83
		*368-83	370-103	*370-103	372-147	*372-147	374-166	*374-166	374-168	376-234
		*376-234	378-265	*378-265	380-305	*380-305	380-308	382-351	384-372	*384-372
		384-374	386-388	*386-388	386-390	388-435	*390-462	390-467	390-477	*390-518
		390-518	404-796	*404-797	404-798	*404-816	406-833	*406-834	406-835	*406-848
		408-930	*413-1074	*413-1097	413-1097	*415-1167	*415-1171	415-1171	*415-1174	*421-1248
		*421-1299	421-1299	*424-1313	*424-1363	424-1363	*426-1373	*426-1412	426-1412	*428-1421
		*428-1453	428-1453	*430-1463	*430-1501	430-1501	*434-1528	*434-1571	434-1571	*438-1619
		*438-1658	438-1658	*440-1680	*440-1711	440-1711	453-2040	458-2177	467-2382	467-2406
		469-2436	476-2599	476-2599	490-3021					
BANK IN	002110	#39-1153	*65-1741	65-1742	*65-1762	*68-1854	68-1902	*70-1964	70-2007	82-2220
		95-2566	314-6660	318-6728	318-6732	*325-6882	413-1092	415-1169	415-1176	434-1532
BANKMO	042072	82-2226	108-2830	314-6658	318-6723	*320-6767	336-7079			
BANKOK	042730	121-3016	123-3058	125-3107	127-3149	*328-6918				
BAWPAF	015434	100-2718	#116-2927	116-2955	116-2963					
BAWPAF	015572	100-2719	#118-2968	118-2996	118-3004					
BOSWIT	002500	#39-1257	*80-2183	561-4708						
BEGIN	005752	46-1414	48-1454	48-1455	#59-1618					
BGTEST	035110	#270-5862	270-5883							
BIT0	000001	#12-315	65-1715	65-1735	80-2190	80-2191	282-6170	286-6254	286-6258	286-6263
		286-6268	291-6338	291-6340	294-6367	294-6372	294-6377	294-6383	297-6425	297-6427
		297-6433	297-6436	299-6460	299-6462	299-6473	299-6475	316-6711	316-6713	318-6743
		318-6745	341-7179	345-7246	347-7285	356-7570	360-7723	360-7729	376-221	386-423
		386-429	396-620	396-628	471-2482	475-2548				
BIT1	000002	#12-314	80-2191	80-2195	103-2768	134-3295	140-3425	294-6355	294-6361	294-6377
		294-6383	294-6390	294-6397	301-6489	301-6496				
BIT10	= 002000	#12-305	78-2147							
BIT11	= 004000	#12-304	68-1909	68-1928	90-2399	277-6016	314-6673	325-6904	396-621	396-627
		409-1007	417-1202	453-2042						
BIT12	- 010000	#12-303	61-1651	61-1652	61-1658	65-1747	65-1751	70-2008	95-2593	140-3434
		279-6140	314-6678	314-6678	325-6883	482-2717	482-2718	482-2734		
BIT13	= 020000	#12-302	61-1651	61-1658	65-1744	65-1751	70-1966	97-2631	97-2632	140-3435

CEPKAB SYMBOL	CROSS REFERENCE VALUE	REFERENCES	178-4315	279-6118	303-6522	314-6662	314-6676	314-6677	314-6692	318-6733
BIT14	= 040000	178-4309	178-4315	279-6118	303-6522	314-6662	314-6676	314-6677	314-6692	318-6733
		318-6737	318-6760	334-7047	362-7770	413-1094	482-2717	482-2734		
		#12-301	37-1089	65-1745	68-1868	68-1881	68-1898	68-1920	70-1966	70-1969
		97-2631	97-2632	136-3332	147-3630	174-4225	176-4251	178-4284	183-4357	186-4391
		251-5564	251-5565	291-6345	291-6347	314-6676	314-6677	316-6599	318-6740	320-6791
		320-6807	325-6910	336-7087	345-7251	347-7291	347-7309	356-7602	362-7756	362-7769
		366-22	366-30	366-59	368-67	368-81	370-101	372-146	372-158	374-165
		374-169	374-190	376-232	378-263	378-280	380-304	380-312	380-333	384-371
		384-375	386-387	386-398	388-441	388-452	390-468	390-496	394-571	394-593
		396-608	396-622	399-670	399-674	402-756	402-760	404-799	406-836	408-925
BIT15	- 100000	#12-300	57-1579	57-1580	57-1603	82-2206	82-2221	84-2274	84-2285	84-2298
		136-3349	136-3361	136-3364	136-3368	163-3979	289-6284	289-6295	291-6337	291-6347
		299-6449	314-6661	314-6673	314-6674	316-6699	316-6706	318-6729	318-6740	320-6791
		320-6807	325-6898	366-60	380-306	399-670	402-760	413-1093	415-1170	415-1177
		417-1189	417-1217	455-2103	458-2190	469-2439	471-2478			
		#12-313	80-2190	80-2192	84-2296	140-3425	282-6185	286-6268	294-6390	294-6397
		301-6489	301-6496	341-7179	360-7723	440-1670	478-2631	478-2633	478-2635	478-2638
		478-2640	478-2642							
		#12-312	65-1752	78-2150	80-2193	80-2194	91-2456	140-3424	140-3428	279-6114
		286-6268	294-6356	294-6362	294-6378	294-6384	294-6391	294-6398	301-6490	301-6497
BIT4	- 000020	341-7179	360-7723	434-1533	440-1670	478-2633	478-2635	478-2640	478-2642	
		#12-311	65-1768	65-1769	80-2192	80-2194	91-2434	91-2468	108-2826	136-3349
BIT5	- 000040	136-3368	291-6337	297-6414	297-6434	411-1038	413-1070	415-1113	415-1116	
		471-2478								455-2103
BIT6	= 000100	#12-310	53-1520	63-1679	80-2195	80-2196	108-2826	316-6702	316-6710	318-6747
		318-6750	334-7038	336-7081						
BIT7	- 000200	#12-309	80-2196	80-2197	274-5960	274-5993	349-7373	349-7430	352-7467	352-7473
		354-7523	354-7542	356-7596	356-7611	358-7672	358-7691	374-177		
BIT8	- 000400	#12-308	53-1523	80-2193	80-2197	274-5959	349-7372	352-7466	354-7522	356-7595
		358-7671	364-7777							
BIT9	- 001000	#12-307	65-1715	65-1746	90-2374	286-6268	341-7179	360-7723	386-423	386-429
		#12-306	147-3647	147-3648	286-6254	286-6258	286-6268	316-6711	316-6713	318-6743
BLOCK1	043710	318-6745	341-7179	360-7723	376-221	471-2482	475-2548			
		68-1846	84-2286	103-2751	153-3786	153-3795	153-3806	155-3826	155-3843	155-3854
		163-3982	163-3987	163-3993	163-4000	163-4006	163-4012	165-4031	165-4034	165-4038
		165-4041	166-4077	168-4110	168-4115	170-4129	172-4184	176-4258	178-4306	241-5406
		271-5945	291-6323	#338-7102	370-133	376-237	376-243	378-292	378-295	380-302
BLOCK2	043730	#338-7107	374-170							
		155-3822	155-3827	155-3828	155-3844	155-3855	166-4078	166-4079	168-4111	168-4112
BLOCK3	043744	174-4226	178-4285	316-6700	318-6741	320-6792	320-6808	#338-7111	404-802	404-805
		#39-1164	82-2210	116-2933	118-2974	123-3062	127-3153	314-6654	*325-6879	*325-6906
EMFLAG	002136	*325-6909	413-1076							
		#334-7024	488-2972	491-3092	509-3689					
BOOT	043416	334-7033	#334-7039							
		043460	270-5867	270-5901						
BIRGOBB	035112	#43-1315	286-6262	341-7179	*360-7723	*360-7729	440-1670	440-1670		
		#10-193	66-1810	68-1867	68-1880	68-1897	68-1919	70-1957	76-2083	84-2255
CACHK	002700	93-2513	132-3249	136-3333	147-3631	183-4359	186-4393	251-5528	289-6290	291-6314
		291-6332	339-7134	360-7724	366-10	370-141	372-155	374-183	374-187	#376-257
CACHOF	- 104424	386-419	408-910	409-951	484-2757					
		#10-192	48-1475	66-1813	68-1871	68-1884	68-1901	68-1924	70-2028	76-2107

CEMKAB		CREATED BY MACRO ON 3-AUG-79 AT 17:42		PAGE 4		K 4				SEQ 1094
SYMBOL	CROSS REFERENCE	REFERENCES		CREF	V01					
SYMBOL	VALUE									
		91-2508	93-2530	132-3257	136-3372	136-3379	147-3645	183-4361	186-4395	249-5504
		360-7730	398-645							
CACHVE	= 000114	#12-330	12-331							
CBCSR	= 104474	#10-236								
CB1CSR	= 104475	#10-237	147-3629	207-4716	210-4802	213-4893	218-4966	221-5044	224-5121	261-5709
CHECK	002404	#39-1223	*147-3627	294-6389	294-6396	*306-6551	561-4713			
CHKDIS	= 104504	#10-244	70-1971	70-1980	70-1988	70-1996				
CHKGEN	040540	207-4705	210-4793	213-4882	218-4954	221-5031	224-5109	259-5649	#306-6528	
CHKTAB	040640	306-6538	#308-6556							
CHK1DI	= 104505	#10-245	237-5291	237-5312	237-5320	239-5335	239-5356	239-5365	241-5381	241-5400
		394-585								
CKEND	073316	488-2953	488-2955	488-2957	#488-2986					
CKSWR	= 104410	#10-175	457-2134	460-2214	461-2255	484-2755				
CLRCR	= 104502	#10-242	70-1974	70-1983	70-1991	70-1999	70-2013	#150-3658	170-4128	172-4199
		#349-7386	#352-7453	#354-7514	#356-7557	#358-7663	370-132	376-254		
CLR1CS	= 104503	#10-243	134-3293	136-3341	136-3359	136-3375	147-3634	147-3643	163-3981	163-4014
		207-4688	207-4733	207-4746	207-4777	210-4785	210-4804	210-4855	213-4862	213-4876
		213-4895	215-4924	218-4948	218-4970	218-5005	221-5025	221-5046	221-5082	224-5125
		226-5162	241-5411	259-5684	394-590					
		#358-7649	358-7653	358-7657						
CMD11A	047774	#358-7680	358-7688							
CMD11B	050164	358-7668	#358-7690							
CMD11C	050240	362-7746	#362-7768							
CMD20A	050576	#349-7349	349-7353	349-7357						
CMD5A	045456	#349-7381	349-7394							
CMD5B	045666	349-7365	349-7369	#349-7429						
CMD5C	046052	352-7463	#352-7472							
CMD7A	046336	#354-7500	354-7504	354-7508						
CMD8A	046550	#354-7531	354-7539							
CMD8B	046740	354-7519	#354-7541							
CMD8C	047014	#356-7573	356-7577	356-7581						
CMD9A	047240	356-7586	#356-7607							
CMD9B	047456	356-7592	#356-7610							
CMD9C	047464	356-7585	#356-7603	356-7605	356-7607					
CMD9LO	047444	#39-1288	*68-1910	*68-1929	95-2576	*95-2577	95-2617	*95-2618	97-2659	
CONFGE	002576	65-1705	#65-1767							
CONFGT	005666	#65-1707	65-1773							
CONFG1	006304	#65-1742	65-1765							
CONFG3	006520	65-1736	65-1766	#65-1772						
CONFG5	006712	#45-1398	51-1486							
CONFIE	004336	#45-1395	51-1484	*57-1579	*57-1580	*65-1743	*65-1744	*65-1745	*65-1747	*65-1752
CONFIG	003016	*65-1756	*65-1761	*66-1822	68-1859	*68-1909	*68-1911	*68-1928	*68-1932	70-1965
		70-1966	70-1966	*70-2008	*82-2206	*82-2221	95-2571	95-2579	95-2580	95-2581
		95-2582	95-2591	95-2593	95-2610	97-2630	97-2631	97-2632	97-2632	178-4309
		*178-4315	277-6016	277-6030	279-6051	279-6058	279-6090	279-6096	279-6113	279-6136
		279-6140	*303-6522	*314-6661	*314-6662	314-6673	314-6674	314-6675	314-6676	314-6677
		314-6677	314-6678	314-6678	*314-6692	*318-6729	*318-6733	*318-6737	325-6883	325-6888
		325-6893	325-6898	325-6904	325-6910	349-7334	356-7628	356-7634	*362-7756	*362-7769
		*362-7770	*413-1093	*413-1094	*415-1170	*415-1177	434-1533	*453-2042	*453-2044	*453-2046
		453-2047								
CONFSP	006754	*65-1706	65-1767	#65-1777						
CONFL	002332	#39-1200	*100-2711	130-3203	*132-3278					

CEMKAB
SYMBOL CROSS REFERENCE

CREATED BY MACRO ON 3-AUG-79 AT 17:42

PAGE 5
CREF V01

L 4

SEQ 1085

SYMBOL	VALUE	REFERENCES
CONTP	073112	#488-2948 *509-3660 511-3708
CONTRL	= 177746	#12-338 *46-1426 65-1704 *65-1775 *286-6262 *286-6263 *286-6268 289-6289 *289-6297
		291-6313 *291-6317 291-6331 *291-6334 339-7133 *341-7182 *386-423 *386-429 *396-621
		*396-627 398-644 *402-780 408-909 *408-945 484-2756 *484-2784 561-4714
CONTS	073544	488-2951 #490-3033
CONTS1	073052	#488-2938 490-3040
CONTS2	073546	#490-3035 490-3036 490-3042
CONIT	073404	480-2679 488-2943 #490-3007
COREHI	043300	330-6957 330-6971 330-6984 332-7001 #332-7006 349-7367 349-7434
COJNT	002462	*39-1250 *249-5508 *249-5509 249-5510 *249-5517 *251-5526 251-5530
		*251-5530 *251-5531 251-5532 *251-5551
CPUBIT	002114	#39-1155 46-1407 *51-1490 59-1625 63-1665 63-1682 66-1822 68-1911 68-1932
		70-1965 82-2205 84-2257 84-2261 84-2265 *90-2382 *91-2470 *91-2495 *91-2506
		95-2563 *95-2572 *95-2574 97-2630 311-6640 314-6675 325-6888 349-7334 366-4
		380-309 *390-463 *390-465 398-638 408-921 408-922 408-923 *411-1040 *411-1051
		*411-1060 *413-1072 *413-1085 *415-1112 417-1195 *421-1249 *421-1251 *424-1314 *424-1316
		*426-1374 *426-1376 *428-1422 *428-1424 *430-1464 *430-1466 *434-1529 *434-1531 *438-1620
		*438-1622 *440-1681 *440-1683 457-2135 488-2931
CPUERR	= 177766	#12-348 *51-1502 *51-1513 *57-1612 *61-1646 65-1768 *65-1774 *66-1823 *68-1874
		*76-2098 *341-7194 *341-7198 *343-7210 *343-7227 *345-7266 *347-7318 *457-2158 *458-2195
		*461-2277 561-4704 561-4709 561-4714
CPUID	011656	84-2259 84-2263 84-2267 #84-2271
CR	= 000015	#12-271 408-937
CRLF	- 000200	#12-272 408-890 565-4782 569-4839 569-4840 569-4841 569-4842 569-4844 569-4846
		569-4847 569-4848 569-4849 569-4850 569-4851 569-4857 569-4861 569-4862 569-4863
		569-4864 569-4865 569-4866 569-4867 569-4868 569-4869 569-4870 569-4871 569-4872
		569-4873 569-4874 569-4875 569-4876 569-4877 569-4878 569-4879 569-4880 569-4881
		569-4882 569-4883 569-4885 569-4886 569-4887 569-4888 569-4889 569-4890 569-4891
		569-4892 569-4893 569-4894 569-4895 569-4896 569-4897 569-4901 569-4903 569-4904
		569-4905 569-4906 569-4907 569-4908 569-4909 569-4910 569-4911 569-4912 569-4913
		569-4913 569-4914 569-4916 569-4917 569-4918 569-4919 569-4920 569-4922 569-4923
		569-4924 569-4926 569-4927 569-4928 569-4932 569-4934 569-4938 569-4939 569-4940
		569-4941 569-4944 569-4945 569-4945 569-4946 569-4947 569-4948 569-4949 569-4950
		569-4952 569-4953 569-4954 569-4955 569-4956 569-4959 569-4960 569-4961 569-4967
		569-4968 569-4969 569-4972 569-4973 569-4974 569-4975 569-4976 569-4976 569-4978
		569-4979 569-4980 569-4981 569-4982 569-4983 569-4984 569-4985
CSR	002144	#39-1167 65-1712 65-1731 65-1732 65-1751 *70-1968 *70-1979 *70-1987 *70-1995
		*78-2142 *78-2143 *78-2145 *78-2146 *78-2147 *78-2149 *78-2149 *78-2150 78-2153
		*93-2549 *93-2550 134-3295 136-3349 136-3368 138-3396 *140-3424 *140-3425 *140-3428
		140-3429 140-3432 147-3637 150-3672 150-3673 237-5283 237-5284 *237-5290 237-5304
		237-5306 *237-5311 *237-5319 239-5326 *239-5334 239-5348 239-5350 *239-5355 *239-5364
		241-5372 *241-5380 241-5391 241-5393 *241-5399 289-6280 289-6282 289-6291 289-6293
		*291-6309 *291-6310 *291-6315 *291-6316 291-6337 291-6337 *291-6348 *291-6349 *294-6355
		*294-6356 *294-6357 *294-6361 *294-6362 *294-6363 *294-6367 *294-6368 *294-6372 *294-6373
		*294-6377 *294-6378 *294-6379 *294-6383 *294-6384 *294-6385 *294-6389 *294-6390 *294-6391
		*294-6392 *294-6396 *294-6397 *294-6398 *294-6399 297-6414 297-6434 299-6449 299-6468
		299-6470 *301-6480 *301-6480 *301-6484 *301-6484 *301-6489 *301-6490 *301-6491 *301-6496
		*301-6497 *301-6498 *343-7213 *343-7216 394-587 399-685 399-685 *401-739 *401-739
		455-2103 471-2474 471-2474 471-2478 471-2479 471-2482 *471-2495 *471-2495 480-2682
		480-2682 480-2691 480-2693 *480-2699 *480-2699 561-4711 561-4711 561-4712 561-4712
		561-4713 561-4713
CSRCAS	020114	132-3255 #143-3448

CEMKAB SYMBOL	CREATED BY	MACRO	ON	3-AUG-79	AT	17:42	PAGE	6	M	4	CREF	V01	SEQ	1086
SYMBOL	CROSS REFERENCE	VALUE	REFERENCES											
CSRFB	002214	#39-1171	*65-1733	476-2595										
CSRFB	002410	#39-1225	132-3264	*138-3392	*145-3505	*145-3521	*145-3537	*145-3553	*145-3581	*145-3597				
		*145-3613												
CSRFR	002336	#39-1207	132-3246	*145-3499	*145-3507	*145-3509	*145-3515	*145-3523	*145-3525	*145-3531				
		*145-3539	*145-3541	*145-3547	*145-3555	*145-3557	*145-3575	*145-3583	*145-3585	*145-3591				
		*145-3599	*145-3601	*145-3607	*145-3615	*145-3617	147-3628	163-3975	163-3999	237-5285				
		349-7323	*349-7382	*349-7433										
CSRINC	002414	#39-1227	132-3261	*145-3501	*145-3511	*145-3517	*145-3527	*145-3533	*145-3543	*145-3549				
		*145-3559	*145-3577	*145-3587	*145-3593	*145-3603	*145-3609	*145-3619	*163-3964	163-3977				
		237-5286												
CSRIND	002416	#39-1228	*132-3229	132-3232	*132-3274									
CSRLB	002234	#39-1172	*65-1738	476-2596										
CSRLBA	002412	#39-1226	132-3238	*138-3393										
CSRLD	002420	#39-1230	*132-3231	132-3267	*132-3276	132-3276	134-3297							
CSRNO	002256	#39-1174	*65-1703	65-1729	65-1749	*65-1772	65-1773	*78-2138	*78-2161	78-2161				
		*93-2551	*93-2556	93-2556	*134-3292	*163-3958	289-6277	291-6306	291-6325	*297-6410				
		*297-6420	297-6420	*299-6445	*299-6455	299-6455	*303-6507	*303-6513	303-6513	339-7133				
		*341-7178	352-7448	*352-7491	*364-7779	*364-7791	398-648	*399-681	*399-688	399-688				
		*401-736	*401-743	401-743	*402-776	471-2474	*471-2475	*471-2495	476-2588	*476-2625				
		480-2682	*480-2687	*480-2697	480-2697	*480-2699	561-4709							
CSROUD	002417	#39-1229	*132-3230	134-3287										
CSROUT	040442	294-6358	294-6369	294-6380	294-6393	301-6481	301-6492	#303-6503						
CSRREL	002254	#39-1173	*61-1640	*61-1645	289-6278	291-6307	291-6326							
CSRO	002154	#39-1169	*65-1731											
CSR2	002174	#39-1170	*65-1732	476-2600										
DATBUF	002340	#39-1208	*199-4553	*199-4554	199-4555	199-4556	199-4558	199-4563	199-4567	*199-4569				
		*199-4569	*199-4572	*199-4573	199-4574	199-4575	199-4577	199-4582	199-4586	*199-4588				
		*199-4588	*207-4690	*207-4691	207-4696	207-4697	207-4765	*207-4767	*207-4767	*210-4786				
		*210-4787	210-4790	210-4791	210-4847	*210-4849	*210-4849	*213-4864	*213-4865	213-4870				
		213-4871	*218-4936	*218-4937	218-4942	218-4943	*221-5013	*221-5014	221-5019	221-5020				
		*224-5092	*224-5093	224-5098	224-5099	446-1919	446-1924							
DBEMSK	002354	#39-1211	*213-4868	*213-4869	213-4877	213-4879	213-4887	213-4889	215-4906	*215-4908				
		*215-4908	*218-4940	*218-4941	218-4949	218-4951	218-4959	218-4961	218-4987	*218-4989				
		*218-4989	*221-5017	*221-5018	221-5026	221-5028	221-5036	221-5038	221-5064	*221-5066				
		*221-5066	*224-5096	*224-5097	224-5104	224-5106	224-5114	224-5116	226-5144	*226-5146				
		226-5146												
DDISP	- 177570	#12-265	43-1347	51-1497										
DECMAR	043152	114-2907	118-2984	125-3117	127-3161	#330-6976								
DEENER	= 104421	#10-188	61-1648	334-7037	336-7080									
DETAIL	071364	465-2360	*478-2645	478-2674										
DETFLA	002326	#39-1196	461-2262	465-2359	*478-2646	478-2647	478-2649	*482-2749						
DETPSW	002324	#39-1195	561-4710											
DETRO	002306	#39-1188	*478-2654	478-2663	561-4710									
DETR1	002310	#39-1189	478-2655	561-4710										
DETR2	002312	#39-1190	561-4710											
DETR3	002314	#39-1191	561-4710											
DETR4	002316	#39-1192	561-4710											
DETR5	002320	#39-1193	561-4710											
DETRSP	002322	#39-1194	561-4710											
DF1	102740	#563-4729												
DF10	103076	551-4513	#563-4738											
DF11	103103	549-4421	551-4488	551-4493	551-4498	553-4520	553-4525	553-4540	557-4649	557-4654				

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
DT14		102530	553-4544 #561-4714
DT16		102556	553-4559 #561-4715
DT17		102610	553-4564 555-4581 557-4683 #561-4717
DT18		102616	553-4569 557-4633 557-4638 #561-4718
DT19		102634	555-4586 #561-4719
DT2		102264	553-4554 557-4678 #561-4701
DT20		102652	557-4643 559-4690 #561-4720
DT21		102662	557-4648 557-4653 #561-4721
DT22		102700	555-4621 #561-4722
DT23		102706	557-4663 557-4673 #561-4723
DT24		102714	557-4668 #561-4724
DT25		102720	559-4695 #561-4725
DT3		102302	549-4430 #561-4702
DT4		102312	549-4435 #561-4703
DT5		102322	549-4440 549-4445 549-4450 553-4549 #561-4704
DT6		102346	555-4626 #561-4705
DT7		102362	551-4462 551-4467 551-4477 551-4482 551-4507 555-4591 555-4596 555-4601 555-4606
			555-4611 555-4616 #561-4706
DT8		102416	551-4512 #561-4708
DT9		102432	555-4576 #561-4709
DUMMY		002304	#39-1186 561-4701 561-4706 561-4706 561-4707 561-4707 561-4707 561-4707 561-4707 561-4707 561-4707 561-4707
			561-4707 561-4713 561-4713 561-4715 561-4715 561-4715 561-4716 561-4716 561-4716 561-4717 561-4717
			561-4718 561-4719 561-4721 561-4722 561-4725 561-4725 561-4725 561-4725 561-4725 561-4725 561-4725 561-4725
ECCDIS =	104470		#10-232 70-2010 150-3656 172-4185 349-7384 352-7451 354-7512 356-7555 358-7661
ECCINI -	104472		#10-234 66-1795 #66-1829 #70-2025 132-3277 150-3676 172-4202 172-4209 172-4213
			334-7032 336-7071
ECC1DI =	104471		#10-233 136-3334 136-3351 147-3640 207-4714 207-4721 207-4774 210-4800 210-4852
			213-4891 215-4921 218-4964 218-5002 221-5041 221-5078 224-5119 226-5158 241-5409
			259-5689 261-5697 261-5707
ECC1IN =	104473		#10-235 136-3371 136-3378 259-5654 261-5700
EMTVEC =	000030		#12-325 *48-1459 *48-1460
EM1		103134	557-4656 #565-4752
EM10		103633	549-4453 #565-4762
EM11		103677	551-4460 551-4465 551-4475 551-4480 #565-4763
EM12		103721	551-4470 #565-4764
EM13		103745	551-4485 #565-4765
EM14		103777	551-4490 #565-4766
EM15		104043	551-4495 #565-4767
EM16		104111	551-4500 #565-4768
EM17		104137	551-4505 #565-4769
EM18		104177	551-4510 #565-4770
EM19		104256	553-4517 #565-4771
EM2		103220	549-4423 #565-4753
EM20		104333	553-4522 #565-4772
EM21		104415	553-4532 #565-4773
EM22		104454	553-4537 #565-4774
EM23		104501	553-4547 #565-4775
EM24		104530	549-4418 #565-4776
EM25		104607	553-4557 #565-4777
EM26		104634	553-4562 #565-4778
FM27		104705	555-4579 #565-4779
FM28		104774	555-4584 #565-4780

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
EM29		105027	555-4594 #565-4781
EM3		103256	549-4428 #565-4754
EM30		105111	555-4599 #565-4782
EM31		105230	555-4604 #565-4784
EM32		105330	555-4609 #565-4785
EM33		105435	555-4614 #565-4786
EM34		105543	555-4619 #565-4787
EM35		105624	555-4589 #565-4788
EM36		105711	555-4624 #565-4789
EM37		105760	557-4631 #565-4790
EM38		106025	553-4552 #565-4791
EM39		106133	557-4636 #565-4792
EM4		103311	549-4433 #565-4755
EM40		106220	557-4641 #565-4793
EM41		106272	557-4646 #565-4794
EM42		106374	557-4651 #565-4795
EM43		106477	557-4661 #565-4796
EM44		106575	557-4666 #565-4797
EM45		106672	557-4671 #565-4798
EM46		106773	557-4676 #565-4799
EM47		107062	557-4681 #565-4800
EM48		107170	559-4688 #565-4801
EM49		107267	559-4693 #565-4802
EM5		103357	549-4438 #565-4756
EM6		103434	549-4443 #565-4757
EM7		103461	549-4448 #565-4758
EM8		103521	553-4567 #565-4759
EM9		103556	555-4574 #565-4761
ENASBE	=	104506	#10-246 66-1827 70-2023
ENATSB	=	104507	#10-247 259-5658 259-5691 261-5702
END		117144	46-1430 #569-4997 569-5007 569-5008
ENERGI	-	104420	#10-187 63-1686 108-2827 417-1215 419-1236
ERRMAX		002702	#43-1316 453-2047
ERROR	-	104000	#12-259 65-1770 66-1817 66-1821 72-2038 80-2184 90-2395 91-2448 91-2485
			93-2521 #95-2583 95-2619 99-2695 99-2704 103-2758 105-2775 210-4815 213-4902
			259-5663 261-5720 261-5731 282-6197 284-6224 284-6228 284-6231 284-6234 299-6472
			341-7193 343-7209 343-7223 366-28 386-409 386-417 390-485 390-511 390-531
			392-550 394-600 409-976 409-1002 409-1019 411-1052 413-1086 413-1099 417-1197
			421-1268 421-1290 424-1332 424-1354 426-1404 428-1445 430-1481 430-1495 436-1592
			436-1606 438-1639 438-1652 440-1704 442-1729 449-1994 #449-1996 449-2006 #449-2008
			451-2017 453-2067 453-2070 453-2073 453-2076 455-2087 455-2098 455-2104 #455-2106
			455-2115 478-2665 478-2671 484-2778
ERRPC	002024		#39-1128 *460-2228 *460-2229 460-2232 *460-2235 *460-2236 460-2241 463-2295 561-4700
			561-4701 561-4702 561-4703 561-4704 561-4705 561-4706 561-4709 561-4711 561-4713
			561-4715 561-4717 561-4718 561-4719 561-4720 561-4721 561-4722 561-4723 561-4724
			561-4725
ERRPSW	002034		#39-1132 *460-2231 *460-2238 478-2662
ERRSP	002030		#39-1130 *460-2230 *460-2237 478-2661
ERRVEC	= 000004		#12-318 *48-1469 *48-1470 457-2152 *457-2153 *457-2155 *457-2159
EVEN	002456		#39-1248 *249-5493 249-5494 *251-5557 251-5557
FXBANK	042422		72-2035 76-2112 78-2128 82-2209 82-2217 95-2565 95-2573 95-2589 103-2753
			110-2846 112-2862 114-2896 116-2930 118-2971 121-3015 123-3057 125-3106 127-3148

EMKAB
SYMBOL CROSS REFERENCE
SYMBOL VALUE

CREATED BY MACRO ON 3-AUG-79 AT 17:42

PAGE 10
CREF V01

SEQ 1090

REFERENCES

		132-3239	132-3280	170-4135	170-4158	172-4188	172-4207	314-6653	318-6727	318-6731
		#325-6861	349-7362	349-7437	352-7478	354-7532	354-7546	356-7615	358-7681	358-7695
		390-464	413-1075	415-1168	415-1175	421-1250	424-1315	426-1375	428-1423	430-1465
		434-1530	438-1621	440-1682						
EXCMD3	044726	345-7255	345-7258	345-7262	#345-7264					
EXCMD4	045236	347-7298	347-7302	#347-7316						
EXIT	043522	#336-7053	457-2143	461-2265						
EXIT2	043526	#336-7055								
FASTCI	= 177640	#12-378	68-1869	68-1899	84-2291	155-3824	183-4360	241-5410	291-6328	291-6333
		338-7103	386-399							
FATAL\$	002070	#39-1145	*66-1817	*66-1821	*259-5663	*282-6197	*284-6224	*284-6228	*284-6231	*366-28
		461-2263	463-2308							
FCMD10	047550	339-7154	#356-7618							
FCMD11	047734	339-7155	#358-7645							
FCMD12	050330	339-7156	#360-7700							
FCMD13	050356	339-7157	#360-7710							
FCMD14	050400	339-7158	#360-7715							
FCMD15	050420	339-7159	#360-7721							
FCMD16	050436	339-7160	#360-7727							
FCMD17	050454	339-7161	#360-7733							
FCMD18	050470	339-7162	#362-7739							
FCMD19	050502	339-7163	#362-7744							
FCMD20	050566	339-7164	#362-7763							
FIELDS	043774	#339-7124	488-2940	511-3699						
FIRST	060000	#14-556	68-1862	68-1891	68-1917	70-1959	70-1970	70-1970	*70-2014	*70-2014
		103-2749	145-3499	145-3507	145-3509	145-3515	145-3523	145-3525	145-3531	145-3539
		145-3541	145-3547	145-3555	145-3557	145-3575	145-3583	145-3585	145-3591	145-3599
		145-3601	145-3607	145-3615	145-3617	153-3783	153-3791	153-3804	155-3815	155-3841
		155-3852	157-3871	165-4030	166-4074	168-4107	170-4139	170-4162	172-4192	174-4226
		174-4231	174-4232	176-4248	176-4264	176-4268	178-4285	178-4288	178-4289	178-4290
		178-4291	178-4299	229-5174	241-5407	249-5506	251-5527	251-5561	251-5563	251-5564
		271-5943	*336-7088	*336-7089	*336-7090	345-7245	347-7284	349-7382	352-7482	356-7569
		366-23	366-31	366-33	366-35	*366-60	368-68	368-82	368-83	368-86
		370-102	370-103	370-106	372-147	372-151	*372-159	374-166	374-170	374-179
		374-181	*374-191	376-233	376-234	376-238	376-246	378-264	378-265	378-281
		378-291	380-305	*380-306	380-310	380-313	380-319	*382-350	*382-352	384-372
		384-376	384-377	386-388	386-391	386-392	386-408	386-416	388-436	*390-469
		390-494	390-514	*392-558	404-800	404-801	404-802	*404-803	*404-804	404-805
		404-807	*406-837	*406-838	406-843	408-926	*408-928	*408-929	426-1381	426-1384
		469-2435								
FIRSTB	002260	#39-1175	65-1733	65-1734	65-1739	*65-1763	65-1764	138-3392	*140-3438	140-3439
		140-3441	*140-3441	145-3505	145-3521	145-3537	145-3553	145-3581	145-3597	145-3613
		*476-2595	476-2599							
FLIPLO	002734	#43-1329	*48-1445	155-3831	*271-5915	*271-5916	271-5917	271-5919	271-5921	
FLIPWA	035214	155-3814	#271-5913							
FLUSH	014656	#105-2784	415-1184							
FSCMD0	044170	#339-7144	#341-7169							
FSCMD1	044256	339-7145	#341-7187							
FSCMD2	044346	339-7146	#343-7202							
FSCMD3	044520	339-7147	#345-7231							
FSCMD4	044764	339-7148	#347-7270							
FSCMD5	045274	339-7149	#349-7322							

CEPKAB		CREATED BY MACRO ON 3-AUG-79 AT 17:42		PAGE '1		E 5			
SYMBOL	CROSS REFERENCE	VALUE	REFERENCES	CREF	VC1	SEQ 1091			
FSCMD6		046152	339-7150 #349-7440						
FSCMD7		046160	339-7151 #352-7447						
FSCMD8		046510	339-7152 #354-7496						
FSCMD9		047104	339-7153 #356-7550						
FSINFL		002542	#39-1274 *108-2797 145-3568	*145-3569					
FSPAT		045752	349-7392 #349-7396						
FSSAC		002374	#39-1219 *341-7189 341-7197	*343-7204	343-7226	*349-7325	349-7429	*352-7468	352-7472
			*354-7498 354-7541	*356-7552	356-7610	*358-7647			
FS1		044052	#339-7136 339-7142 339-7166						
FS7FLA		002546	#39-1276 170-4152	*352-7449	*352-7490				
GBLENG	=	000076	178-4285 178-4288	#270-5902					
GDSWIT		002476	#39-1256 *80-2179 561-4708						
GETDAT		055030	#396-614 449-1990 449-2002						
GETDA1		055156	*396-616 396-626	#396-631					
GETDIS		066514	183-4336 186-4370 457-2172	#458-2176	460-2217				
GETSIZ		017736	65-1727 138-3391	#140-3421					
GOOD		002050	#39-1137 *65-1769 *80-2175	*99-2702	*386-406	*386-414	*394-576	*394-578	*394-592
			*396-605 *446-1886 *446-1892	*446-1897	*446-1904	*446-1907	*446-1914	*446-1919	*446-1924
			*446-1929 *446-1934 *448-1940	*448-1945	*448-1950	*448-1955	*448-1960	*448-1965	*448-1970
			*448-1975 *448-1980 *448-1985	451-2030	*453-2056	*453-2058	*455-2085	*455-2095	*455-2114
			561-4700 561-4706 561-4708	561-4715	561-4720	561-4721			
GOOD2		002052	#39-1138 *451-2020 *451-2024						
GOOD3		002054	#39-1139 *451-2021 *451-2025						
GTSWR		104407	#10-174 63-1667						
HEADER		002724	#43-1325 *48-1446 *103-2734	*103-2736	*110-2848	*110-2851	*130-3197	*130-3210	*132-3252
			*207-4741 *207-4744 *207-4755	*207-4758	*210-4813	*210-4816	*210-4827	*210-4830	*213-4900
			*213-4903 *261-5721 *261-5732	*349-7380	*354-7529	*358-7678	*453-2061	*453-2078	*455-2086
			*455-2088 *455-2097 *455-2099	*461-2275	463-2306	463-2318	*465-2357	478-2651	*478-2652
			478-2667 *478-2668 *478-2672						
HIACBA		002514	#39-1263 *78-2124 *78-2131	78-2135	78-2143				
HIADRS		177742	#12-336 561-4704 561-4714						
HIBANK		002512	#39-1262 *76-2120						
HIPAT		042762	125-3102 127-3144	#328-6937					
HT		000011	#12-269 408-887						
HUNGMS		002572	#39-1286 *91-2441 *91-2445	*91-2477	*91-2422	*411-1044	*411-1048		
HUNGTI		002574	#39-1287 *90-2391 *91-2442	*91-2478	*390-481	*390-527	*409-972	*409-999	*409-1015
			*411-1045 *413-1081 *417-1193	*421-1264	*421-1286	*424-1328	*424-1350	*426-1400	*428-1441
			*430-1477 *436-1602 *438-1635	*440-1700	*442-1725	*484-2785			
I		002602	#39-1290 *55-1568 *55-1574	55-1574	*97-2650	*97-2650	97-2651	*97-2651	97-2653
			*132-3250 132-3254 *132-3256	132-3256	*170-4133	170-4143	170-4146	*170-4151	170-4151
			*170-4156 170-4166 170-4169	*170-4174	170-4174	*380-311	*380-318	380-318	*390-495
			*390-513 390-513 *434-1537	434-1539	*434-1568	434-1568	436-1581	436-1589	436-1591
IISTAC		002736	#43-1330 57-1603 57-1604	84-2274	84-2275	84-2295	90-2392	90-2403	91-2418
			366-18 408-915 409-994	409-1000	417-1189	417-1190	417-1194	417-1209	
IISTAD		002740	#43-1331 57-1608 84-2296	90-2399	90-2404	90-2405	91-2419	91-2420	409-995
			409-996 409-1007 417-1191	417-1192	417-1202	417-1210			
IISTIN		061074	84-2293 #417-1187 417-1208						
IISTOF		061174	90-2402 409-993	#417-1207					
IISTVE		002742	#43-1332 90-2386 91-2464	380-303	380-316	382-341	382-342	382-343	382-343
			382-346 382-347 382-347	384-358	392-563	409-985			
IITRAP		036764	48-1473 91-2464	#284-6233					
INCBNK		042772	112-2879 114-2913 116-2949	118-2990	121-3029	123-3073	125-3120	127-3164	#328-6941

SYMBOL CROSS REFERENCE

CREF V01

SYMBOL	VALUE	REFERENCES
INCMAR	043006	112-2873 116-2943 121-3026 123-3070 #330-6948
INCPAT	042746	112-2876 116-2946 #328-6929
INCRPT	042746	121-3032 123-3076 #328-6928
INTERL	002264	#39-1177 *65-1726 65-1743
INTERO	006756	#65-1717 #65-1780
INTER1	006760	65-1718 #65-1782
INTER2	006760	65-1719 #65-1783
INTER3	006766	65-1720 #65-1786
INTER4	006766	65-1721 #65-1787
INTER5	006774	65-1722 #65-1791
INTER6	006766	65-1723 #65-1788
INTER7	006774	65-1724 #65-1792
INTKRA	017610	132-3235 #138-3384 163-3962
INT..0	020234	#138-3400 #145-3499
INT..1	020260	138-3401 #145-3505 145-3572
INT..2	020324	138-3402 #145-3515
INT..3	020350	138-3403 #145-3521
INT..4	020414	138-3404 #145-3531
INT..5	020440	138-3405 #145-3537
INT..6	020504	138-3406 #145-3547
INT..7	020530	138-3407 #145-3553
INT..10	020574	138-3408 #145-3564
INT..11	020574	138-3409 #145-3568
INT..12	020616	138-3410 #145-3575
INT..13	020642	138-3411 #145-3581
INT..14	020706	138-3412 #145-3591
INT..15	020732	138-3413 #145-3597
INT..16	020776	138-3414 #145-3607
INT..17	021022	138-3415 #145-3613
INVALI	- 104511	#10-249 132-3242 150-3665 152-3731 170-4137 332-7016 347-7290 349-7361 352-7480 354-7534 356-7588 358-7683 413-1077 421-1253
LOTVEC	- 000020	#12-323 *48-1457 *48-1458
ISECCO	017300	132-3233 #134-3284
J	002604	#39-1291 *434-1538 434-1539 434-1540 434-1543 *434-1549 434-1549
KAMIKA	002010	#39-1119 180-4326 339-7133 *339-7135 *341-7176 *360-7712 *360-7717
KAMITE	026006	165-4047 165-4055 166-4065 174-4219 176-4239 178-4277 #180-4325
KDIAG	= 000010	#249-5492 249-5508 251-5530 251-5556
KDPARO	- 172360	#12-469 155-3827 155-3844 155-3855 166-4079 168-4111 192-4478 196-4517 196-4539 256-5632 264-5739 264-5748
KDPAR7	= 172376	#12-476
KDPDR7	172336	#12-456
KERNEL	104417	#10-185 68-1870 68-1883 68-1900 68-1923 70-2015 136-3370 136-3377 147-3644 174-4227 176-4259 178-4286 183-4362 186-4396 316-6701 318-6742 320-6793 320-6809 336-7091 345-7253 345-7264 347-7294 347-7312 347-7316 #366-24 366-36 366-61 368-69 368-84 370-104 372-148 372-160 374-167 374-171 374-192 376-235 378-266 378-282 380-307 380-320 384-373 384-381 386-389 386-401 388-450 388-454 390-470 390-515 394-573 394-596 396-610 396-624 399-672 399-676 402-758 402-762 404-815 406-847 408-931
KERSTR	- 002000	#12-256
KIPARO	= 172340	#12-459 82-2232 311-6605 311-6630 322-6817 322-6837 404-806 406-822 419-1225
KIPAR4	172350	#12-463 322-6851
KIPAR5	172352	#12-464

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
KIPAR6	=	172354	#12-465
KIPAR7	=	172356	#12-466
KIPDR0	=	172300	#12-439 311-6632 322-6819 398-661 401-725 401-746 406-823 419-1227
KI0		002550	#39-1277 82-2233 419-1224
KI1		002552	#39-1278
KI2		002554	#39-1279
KI3		002556	#39-1280
KI4		002560	#39-1281
KI5		002562	#39-1282
KI6		002564	#39-1283
KI7		002566	#39-1284
KMAP	-	104422	#10-190 63-1683
KPFLAG		002122	#39-1158 *70-1958 72-2037 82-2211 294-6356 294-6362 294-6378 294-6384 294-6391
KSTACK		002706	294-6398 301-6490 *325-6877 *325-6885 #43-1318 46-1406 57-1611 *90-2378 90-2379 *91-2471 *91-2507 108-2825 *368-71 368-73 *409-962 *409-978 *409-990 *409-1004 *409-1021 *409-1028 *413-1105 417-1213 482-2707
LAST	-	157776	#14-557 132-3261 153-3800 163-3980 165-4028 166-4075 176-4249 176-4263 229-5176 237-5289 249-5507 251-5529 251-5565 266-5805 270-5893 345-7247 347-7286 356-7571 376-244 388-437 426-1384
LASTB		002262	#39-1176 65-1738 65-1764 138-3393 *140-3431 *140-3434 *140-3435 *140-3439 *140-3440 140-3442 *140-3442 *476-2596 476-2599
LASTER		002020	#39-1126 *80-2185 105-2774 *108-2798
LF		000012	#12-270 408-941
LKS	=	177546	#12-266 51-1510 *374-177 *374-184
LOADBA		002532	#39-1270 *314-6656 318-6721 318-6726
LOADCS	-	104425	#10-195 78-2148 78-2151 93-2554 140-3426 294-6364 294-6374 294-6386 294-6400 301-6485 301-6499 303-6510 343-7218 401-740 #43-1319 *82-2219 82-2222 82-2224 108-2828 311-6641 314-6657 318-6722 318-6730 336-7078 415-1174
LOADRS	-	177740	#12-335 282-6176 561-4704 561-4714
LOCK		002670	#41-1307 *46-1436 46-1437 *57-1614 *59-1620 59-1621 *78-2157 *84-2287 *84-2299 *90-2368 *91-2501 91-2502 *336-7082 *409-961 *409-989 *411-1036 *413-1068 *415-1183
LOOP		014342	#100-2710 108-2840
LOWMAP		042026	63-1678 316-6709 318-6749 #318-6754 401-722
LSTSS	-	000000	#1-1
MAINT	-	177750	#12-339 *63-1672 *103-2768 *130-3196 *170-4127 *172-4182 *332-7012 *334-7034 *336-7072 *349-7378 *354-7527 *356-7600 *358-7676 *370-131 *374-193 *376-253 *384-366 *396-620 *396-628 398-644 *402-780 458-2182 490-3023 561-4714 #14-484 *63-1677 *316-6708 *318-6748 399-698 *401-721 #14-544 *63-1675 *76-2084 *76-2091 76-2092 *76-2097 *76-2101 76-2102 *76-2105 399-698 *401-721
MAPHO	=	170202	#14-546
MAPH36	=	170372	#14-483 *63-1677 *316-6706 *318-6748 318-6756 399-698 *401-721 #14-485 318-6757
MAPH37	=	170376	#14-543 *75-2085 *76-2090 *76-2096 *76-2100 *76-2106 399-698 *401-721
MAPLO	=	170200	63-1685 68-1858 70-1967 70-2019 132-3241 174-4224 176-4244 178-4282 183-4335
MAPL1	=	170204	186-4369 #311-6604 336-7086 345-7250 347-7289 349-7360 349-7436 354-7545 356-7587
MAPL36	=	170370	356-7614 358-7694 366-11 366-58 368-75 372-156 374-168 374-188 380-308
MAPPER		040700	382-349 382-351 384-374 386-390 388-435 390-467 390-477 404-798 406-835 408-924 408-930
MARGIN		002112	#39-1154 *112-2869 *116-2939 *121-3022 *123-3066 130-3194 *170-4127 *172-4182 330-6955

CEMKAB
SYMBOL
SYMBOL

(CREATED BY MACRO ON 3-AUG-79 AT 17:42

PAGE 14
M 5
CREF V01

CROSS REFERENCE
VALUE

REFERENCES

MASTER	000020	*330-6956	330-6959	*330-6960	330-6961	*330-6963	330-6964	330-6967	*330-6970	330-6972
		330-6979	*330-6980	330-6981	*330-6983	330-6985	332-6995	*332-6997	*332-6999	*332-7003
		332-7008	332-7009	332-7009	332-7010	349-7323	349-7324	*349-7351	349-7352	349-7352
		349-7355	349-7375	*349-7433	352-7448	*352-7491	354-7497	*354-7502	354-7503	354-7503
		354-7506	354-7525	*354-7544	356-7551	*356-7575	356-7576	356-7576	356-7579	356-7598
		*356-7613	358-7646	*358-7651	358-7652	358-7652	358-7655	358-7674	*358-7693	*370-131
		*374-193	*376-253	*384-367	469-2448					
		#14-561	46-1407	51-1490	59-1625	63-1665	63-1662	82-2205	90-2380	91-2495
		91-2496	91-2506	95-2563	95-2571	95-2574	95-2579	279-6096	311-6640	325-6886
		366-4	380-309	390-465	398-638	411-1051	411-1060	413-1085	415-1112	417-1195
		421-1251	424-1316	426-1376	428-1424	430-1466	434-1531	438-1622	440-1683	457-2135
		488-2931								
MAST01	057372	105-2783	#409-949							
MAST02	060046	#411-1032								
MAST03	060220	#413-1064								
MAST04	061322	415-1118	#421-1241							
MAST05	061706	415-1123	#424-1306							
MAST06	062270	415-1128	#426-1369							
MAST07	062550	415-1133	#428-1417							
MAST10	062776	415-1138	#430-1458							
MAST11	063260	415-1143	#432-1506							
MAST12	063732	415-1148	#438-1615							
MAST13	064200	415-1153	#438-1662							
MAST14	064204	415-1158	#440-1666							
MAST15	064472	415-1163	#442-1717							
MASWR	002674	#41-1309	*90-2370	90-2372	91-2494	*409-956	409-958	413-1107		
MDISPL	002676	#41-1310	366-33	*366-33	366-34	*376-222	*390-460	390-461	*409-953	409-954
		*411-1034	*413-1066	413-1067	*415-1179	*421-1243	421-1244	*424-1308	424-1309	*426-1371
		426-1372	*428-1419	428-1420	*430-1461	430-1462	*432-1523	432-1524	*438-1617	438-1618
		*440-1674	440-1675	*442-1719	442-1720	458-2191	458-2191	490-3010	490-3010	490-3012
MEMDON	014410	100-2715	#103-2729							
MEMERR	177744	#12-337	282-6170	282-6177	*282-6177	282-6184	*282-6184	282-6190	*282-6190	284-6214
		*284-6214	284-6218	*284-6218	561-4704	561-4709	561-4714			
MHALT1	004532	#46-1438	46-1439							
MHALT2	005770	#59-1622	59-1623							
MHALT3	012760	#91-2503	91-2504							
MINDFX	002666	#41-1306								
MJPAT	021600	55-1560	152-3730	152-3730	152-3733	#152-3741				
MJSIZE	002466	#39-1252	*97-2627	*97-2631	*97-2637	*97-2638	*97-2639	*97-2640	97-2650	97-2655
		99-2694	561-4705							
MJTEST	021512	130-3208	#152-3724							
MKCONT	016664	130-3205	#132-3214	384-362						
MKCSRS	002334	#39-1201	*65-1707	*65-1710	*65-1715	65-1746	93-2548	132-3232	163-3956	297-6407
		299-6442	303-6505	364-7776	399-679	401-733	476-2594	480-2685		
MKCSRT	020124	55-1550	#143-3454							
MKFLAG	002126	#39-1160	72-2036	76-2113	82-2211	95-2569	95-2590	130-3200	172-4189	*325-6877
		*325-6897	328-6924	330-6964	330-6967	332-6996	332-7007	467-2412	471-2473	476-2582
MKPAT	021402	55-1555	150-3664	150-3664	150-3667	#150-3684				
MKSIZE	002470	#39-1253	*97-2628	*97-2633	*97-2641	*97-2642	*97-2643	*97-2644	97-2650	97-2657
		99-2694	561-4705							
MKTEST	021222	110-2849	130-3206	#150-3653						
MK11AD	172100	#14-553	61-1638	289-6276	291-6305	291-6324				

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
MSG029		113434	345-7234 #569-4892
MSG030		113454	349-7327 362-7749 #569-4893
MSG031		113473	345-7235 347-7274 356-7559 #569-4894
MSG032		113533	345-7257 347-7297 #569-4895
MSG033		113552	345-7261 347-7301 #569-4896
MSG034		113571	132-3269 #569-4897
MSG035		113707	108-2803 #569-4902
MSG036		113712	347-7273 #569-4903
MSG037		113731	347-7304 #569-4904
MSG038		113750	347-7313 #569-4905
MSG039		113766	347-7306 #569-4906
MSG040		114010	349-7326 #569-4907
MSG041		114055	349-7335 #569-4908
MSG042		114102	349-7339 #569-4909
MSG043		114123	349-7344 #569-4910
MSG044		114150	349-7349 354-7500 356-7573 358-7649 #569-4911
MSG045		114175	349-7356 354-7507 356-7580 358-7656 #569-4912
MSG046		114231	349-7368 352-7462 354-7518 356-7591 358-7667 #569-4913
MSG047		114264	352-7489 #569-4914
MSG048		114303	339-7129 #569-4915
MSG049		114343	349-7364 #569-4916
MSG050		114375	352-7455 #569-4917
MSG051		114503	402-778 #569-4919
MSG052		114523	352-7459 #569-4920
MSG053		114554	352-7461 #569-4921
MSG054		114572	352-7476 #569-4922
MSG055		114642	354-7499 #569-4923
MSG056		114663	354-7516 358-7665 #569-4924
MSG057		114716	476-2585 *476-2621 476-2623 *476-2624 #569-4925
MSG058		114722	480-2683 #569-4926
MSG059		114766	356-7553 #569-4927
MSG060		115016	356-7589 #569-4928
MSG061		115060	469-2428 #569-4929
MSG062		115067	492-3191 492-3250 #569-4930
MSG063		115107	492-3192 #569-4931
MSG064		115120	492-3193 492-3252 #569-4932
MSG065		115130	492-3251 #569-4933
MSG066		115142	461-2268 #569-4934
MSG067		115225	463-2310 #569-4935
MSG068		115234	467-2414 #569-4936
MSG069		115241	467-2416 #569-4937
MSG070		115246	97-2654 #569-4938
MSG071		115271	97-2656 #569-4939
MSG072		115304	97-2658 #569-4940
MSG073		115317	358-7648 #569-4941
MSG074		115336	*471-2472 *471-2493 471-2497 *475-2544 *475-2558 475-2560 #569-4943
MSG075		115341	314-6667 314-6688 #569-4944
MSG076		115373	356-7630 #569-4945
MSG077		115414	108-2801 #569-4946
MSG078		115430	134-3296 #569-4947
MSG079		115474	356-7621 #569-4948
MSG080		115520	57-1592 #569-4949

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES						
MSG081		115560	91-2474	#569-4950					
MSG082		115577	91-2476	#569-4951					
MSG084		115617	93-2522	#569-4952					
MSG085		115661	360-7702	#569-4953					
MSG086		115706	93-2534	#569-4954					
MSG087		115745	93-2541	#569-4956					
MSG088		115760	482-2706	#569-4959					
MSG089		115776	482-2721	#569-4960					
MSG090		116020	482-2737	#569-4961					
MSG091		116034	482-2730	#569-4962					
MSG092		116046	490-3018	#569-4963					
MSG093		116062	490-3020	#569-4964					
MSG094		116070	490-3022	#569-4965					
MSG095		116077	490-3027	#569-4966					
MSG096		116106	#569-4967						
MSG097		116137	145-3570	#569-4968					
MSG098		116234	484-2764	#569-4969					
MSG099		116245	484-2774	#569-4972					
MSG100		116256	490-3014	#569-4973					
MSG101		116305	360-7711	#569-4974					
MSG102		116335	360-7716	#569-4975					
MSG103		116364	341-7170	#569-4976					
MSG104		116421	465-2362	#569-4977					
MSG105		116423	362-7745	#569-4978					
MSG106		116527	360-7722	#569-4979					
MSG107		116545	360-7728	#569-4980					
MSG108		116622	360-7734	#569-4981					
MSG109		116664	362-7740	#569-4982					
MSG110		116737	362-7759	#569-4983					
MSG111		117003	362-7764	#569-4984					
MSG112		117035	457-2142	#569-4985					
MSG113		117103	475-2568	#569-4986					
MSG114		117113	475-2571	#569-4987					
MSG115		117123	475-2574	#569-4988					
MSG116		117133	475-2577	#569-4989					
MST11A		063602	434-1567	#436-1575					
MTA030		024760	#172-4181	172-4208					
MTEST		016564	112-2871	114-2905	116-2941	118-2982	121-3024	123-3068	125-3115 127-3159 #130-3193
MTPA03		026506	155-3822	#192-4451					
MTPA04		026650	155-3843	#196-4513					
MTPA20		032572	163-3955	#237-5279					
MTPA21		033234	165-4031	#244-5416					
MTPA24		034060	166-4077	#254-5582					
MTPA25		034464	259-5653	259-5688	261-5696	#261-5707			
MTPA26		034576	168-4110	#264-5738					
MTPA32		034772	#268-5816	378-292					
MTPB03		026550	155-3826	#192-4476					
MTPB04		026704	155-3844	155-3855	#196-4526				
MTPB21		033264	165-4034	#244-5433					
MTPB24		034120	166-4078	#256-5626					
MTPB25		034504	259-5690	261-5698	#261-5714				
MTPB26		034612	168-4115	#264-5745					

SYMBOL	VALUE	REFERENCES							
MTPB32	035020	#268-5826	378-295						
MTPC03	026610	155-3827	#194-4494						
MTPC21	033320	165-4038	#244-5450						
MTPC24	034134	166-4079	#256-5634						
MTPC25	034536	259-5692	261-5701	261-5703	#261-5725				
MTPC26	034646	168-4111	#264-5763						
MTPD03	026630	155-3828	#194-4503						
MTPD21	033354	165-4041	#246-5468						
MTPD25	034412	259-5665	259-5667	259-5670	259-5672	#259-5688			
MTPD26	034666	168-4112	#264-5776						
MTPD25	034434	259-5676	259-5678	259-5681	259-5683	#261-5696			
MTP000	026376	68-1846	153-3786	170-4129	178-4306	#189-4413	189-4415	271-5945	370-133
MTP001	026422	153-3795	#189-4424	376-237					
MTP002	026454	153-3806	#189-4436	376-243					
MTP005	026724	155-3854	#196-4535						
MTP006	026760	157-3864	#199-4550						
MTP007	027150	157-3874	#202-4594						
MTP010	027250	157-3881	#204-4634						
MTP011	027356	159-3892	#207-4671						
MTP012	027766	159-3901	#210-4782						
MTP013	030344	159-3909	#213-4860						
MTP014	030716	159-3919	#218-4929						
MTP015	031312	161-3930	#221-5010						
MTP016	031700	161-3939	#224-5087						
MTP017	032302	161-3944	#229-5167						
MTP020	032360	#232-5201							
MTP022	033404	165-4050	165-4058	#249-5487					
MTP025	034152	166-4095	#259-5645						
MTP030	034704	172-4184	241-5406	#266-5784					
MTP031	034714	174-4226	#266-5790	266-5812					
MTP033	035054	176-4258	#268-5839						
MTP034	035106	178-4285	#270-5859	270-5902					
MTP20A	032360	163-3982	#232-5206	232-5210					
MTP20B	032376	163-3987	#232-5214	232-5223					
MTP20C	032430	163-3993	#232-5227	232-5236					
MTP20D	032462	163-4000	#232-5240	232-5249					
MTP20E	032514	163-4006	#234-5254	234-5263					
MTP20F	032546	163-4012	#234-5267	234-5274					
M*V020	023320	*163-3957	163-3958	*163-3971	163-3971	#163-3973			
MT0000	021704	#153-3781	349-7396						
MT0001	021740	150-3688	152-3745	#153-3789	349-7397				
MT0002	022000	150-3689	152-3746	#153-3798	349-7398				
MT0003	022050	152-3747	#155-3811	349-7399					
MT0004	022216	150-3690	152-3748	#155-3836	349-7400				
MT0005	022300	150-3691	152-3749	#155-3847	349-7401				
MT0006	022360	143-3454	#157-3860	349-7402					
MT0007	022414	150-3687	152-3744	#157-3867	349-7403				
MT0010	022456	143-3455	#157-3877	349-7404					
MT0011	022512	143-3457	#159-3886	349-7405					
MT0012	022570	143-3458	#159-3895	349-7406					
MT0013	022646	143-3459	#159-3904	349-7407					
MT0014	022722	143-3460	#159-3913	349-7408					

CEMKAB
SYMBOL CROSS REFERENCE

CREATED BY MACRO ON 3-AUG-79 AT 17:42

PAGE 19
CREF V01

M 5

SEQ 1099

SYMBOL	VAL %	REFERENCES
MT0015	023000	143-3461 #161-3924 349-7409
MT0016	023056	143-3462 #161-3933 349-7410
MT0017	023134	150-3686 152-3743 #161-3942 349-7411
MT0020	023156	150-3693 #163-3949 349-7412
MT0021	023612	150-3692 152-3750 #165-4021 349-7413
MT0022	023734	150-3694 #165-4046 349-7414 358-7684
MT0023	023766	152-3751 #165-4054 349-7415
MT0024	024032	150-3696 152-3753 #166-4064 349-7416
MT0025	024172	143-3456 #166-4090 349-7417
MT0026	024240	150-3695 152-3752 #168-4100 349-7418
MT0027	024370	103-2735 #170-4123 349-7419 352-7457
MT0030	024754	105-2785 #172-4179 334-7036 336-7075 349-7420
MT0031	025214	150-3697 152-3754 #174-4218 349-7421 354-7535
MT0033	025340	150-3698 152-3755 #176-4238 349-7423
MT0034	025530	150-3699 152-3756 #178-4276 349-7424
MT0035	025652	150-3664 150-3685 150-3700 152-3730 152-3742 152-3757 #178-4297
MT020X	023604	163-3991 163-3997 163-4004 163-4010 #163-4017
MT020Y	023472	163-3985 #163-3999
MT020Z	023322	163-3968 #163-3975
MT0999	025772	55-1571 143-3463 143-3464 143-3465 143-3466 143-3467 143-3468 143-3469 143-3470 143-3471 143-3472 143-3473 143-3474 143-3475 143-3476 143-3477 143-3478 143-3479 143-3480 143-3481 143-3482 143-3483 143-3484 143-3485 150-3664 150-3702 150-3703 150-3704 150-3705 150-3706 150-3707 150-3708 150-3709 150-3710 150-3711 150-3712 150-3713 150-3714 150-3715 150-3716 150-3717 150-3718 150-3719 150-3720 150-3721 152-3730 152-3759 152-3760 152-3761 152-3762 152-3763 152-3764 152-3765 152-3766 152-3767 152-3768 152-3769 152-3770 152-3771 152-3772 152-3773 152-3774 152-3775 152-3776 #180-4320 349-7422 349-7425 349-7426 349-7427
MULTHT	056150	#404-791 404-792
MULTIE	060746	409-979 409-1005 409-1022 411-1054 413-1088 413-1102 415-1121 415-1126 415-1131 415-1136 415-1141 415-1146 415-1151 415-1156 415-1161 #415-1167
MULTIO	002004	#39-1117 150-3654 152-3725 *360-7735 *362-7741
MULTIP	003014	#43-1358 46-1407 *57-1610 84-2256 *91-2463 *91-2486 *93-2524 93-2533 105-2783 401-711 408-911 408-920 *409-977 *409-1003 *409-1020 *411-1053 *413-1087 *413-1101 *415-1120 *415-1125 *415-1130 *415-1135 *415-1140 *415-1145 *415-1150 *415-1155 *415-1160 *415-1165 *417-1198
MULTIU	056142	401-711 #404-788
MULT	002116	#39-1156 *103-2734 *103-2737 *110-2848 *110-2850 *130-3198 *130-3209 *349-7380 *354-7529 *358-7678 465-2355 478-2651 *478-2653 478-2667 *478-2669 *478-2672
M13BAL	054472	390-516 #392-541
NEMCNT	002072	#39-1146 *66-1805 66-1818 *68-1857 68-1877 68-1889 68-1907 68-1931 *284-6210 284-6211 *284-6216 561-4703
NEWBAN	002400	#39-1221 172-4206 *316-6697 316-6703 *318-6738 322-6825 322-6838
NEWKER	042322	316-6712 318-6744 #322-6835
NEWLOA	042370	82-2227 311-6642 314-6659 318-6724 #322-6848
NOCLOC	002104	#39-1151 *51-1512 430-1460 432-1518
NOECCF	002474	#39-1255 *134-3299 *134-3301 159-3887 159-3896 159-3914 161-3925 161-3934
NOERRO	002530	#39-1269 *341-7192 *343-7208 *343-7222 460-2213 460-2233 461-2251 *461-2277 463-2304 463-2316 465-2359 *478-2664 *478-2670
NOFSMD	002526	#39-1268 *170-4132 *170-4153 *170-4175 *172-4186 *172-4203 *172-4214 339-7128
NOIIST	002756	*37-1106 #43-1338 57-1590 84-2271 84-2283 90-2373 366-15 408-912 409-959
NONEM	002102	#39-1150 *66-1806 *68-1844 *68-1916 *68-1925 284-6208
NONEXI	036646	66-1807 68-1845 282-6172 #284-6208

CEMKAB
SYMBOL CROSS REFERENCE
SYMBOL VALUE

CREATED BY MACRO ON 3-AUG-79 AT 17:42

PAGE 21
CREF V01

B 6

SEQ 1101

SYMBOL	VALUE	REFERENCES
O.DOT	075562	#505-3586 *519-3870 521-3907 *521-3910
O.ERR	076510	513-3757 #515-3781 515-3809 519-3866
O.ERR1	077572	523-3942 523-3950 523-3954 523-3960 527-4013 529-4039 529-4042 529-4044
O.ERR2	077164	#521-3903 523-3930
O.ERR3	077150	#521-3897 521-3903
O.FIL	075576	#505-3603 *543-4295
O.F.TYP	100730	515-3782 519-3884 519-3886 519-3888 539-4219 539-4224 #539-4229 539-4230 541-4269 543-4289 543-4294 511-3716 515-3792 #541-4250 541-4251 541-4270 541-4274
O.GET	101006	517-3827 #527-4007
O.GO	077576	511-3709 #527-4015
O.GOGO	077624	527-4022 #527-4025 529-4059
O.GO2	077676	509-3663 #547-4350
O.ID	101300	509-3664 #547-4354
O.IDND =	101315	511-3720 #547-4397
O.LG =	000020	515-3805 #547-4359 547-4379
O.LGCH	101321	#515-3774 517-3838
O.MIN	076502	#505-3611 *515-3774 *515-3787 515-3811 *515-3817
O.MINS	075603	488-2948 #509-3647 511-3700
O.ODT	075774	517-3832 #525-3979
O.OFST	077466	517-3830 #521-3901
O.OLD	077154	517-3828 #521-3902
O.OP1	077160	#521-3910 523-3933
O.OP2	077220	513-3739 #521-3911
O.OP2A	077226	#513-3740 517-3835
O.ORAB	076364	#513-3734 517-3829
O.ORPC	076342	#513-3743 517-3836
O.ORRB	076374	#505-3598 *509-3654 *509-3676 *527-4011 529-4040 529-4051 *531-4065 *533-4106 533-4113
O.P	075573	533-4120 #507-3629 509-3669 531-4070 531-4074
O.PRI	075704	517-3834 #529-4038
O.PROC	077732	529-4046 #529-4048
O.PR1	077764	509-3679 523-3958 #523-3964
O.RALL	077430	#502-3579 537-4167 *537-4169 537-4179 537-4181 *537-4183 541-4250
O.RCSR =	177560	#502-3578 541-4252
O.RDB =	177562	#511-3716 517-3826
O.REGT	076270	509-3668 531-4069 #537-4190
O.REM	100602	521-3915 533-4122 #547-4348
O.RORA	101272	509-3649 #545-4302
O.RRST	101172	527-4024 #537-4157
O.RSB	100450	527-4025 #535-4143
O.RSR	100416	527-4018 529-4050 #537-4176
O.RST1	100534	#505-3592 *509-3655 *509-3675 *513-3765 *513-3767 527-4021 529-4053 531-4084 537-4190
O.S	075571	511-3727 #515-3792 515-3803
O.SCAN	076554	#505-3609 541-4260 541-4271
O.SCRN	075602	517-3822 #519-3847
O.SEMI	076742	#505-3591 *521-3901 521-3905 *521-3908
O.SEQ	075570	#505-3606 513-3761 *515-3785 *519-3849 519-3867 527-4007 529-4038
O.SMFD	075601	#513-3761 517-3837
O.SVGL	076446	#502-3575 509-3677 527-4016 529-4048 529-4055
O.STM -	000340	509-3661 509-3667 531-4067 #535-4129
O.SVR	100360	

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
O.SVTT		100500	509-3659 531-4094 533-4110 #537-4167
O.T		075572	#505-3597 *527-4019 *529-4057 531-4067
O.TBIT		077644	#527-4019 529-4052 529-4054 531-4068
O.TBT		- 000020	#502-3576 527-4020 527-4023 527-4030 529-4058 531-4080
O.TCL2		076442	#513-3757 513-3762
O.TCSR		= 177564	#502-3581 537-4168 *537-4170 537-4171 537-4177 *537-4184 539-4229
O.TDB		- 177566	#502-3580 *539-4243
O.TL		101345	511-3717 511-3720 511-3728 #547-4381 547-4397
O.TRTC		101370	523-3937 523-3965 537-4159 #547-4400
O.TVEC		= 000014	#502-3574 509-3650 *509-3677 *509-3678
O.TYPE		101126	509-3665 509-3688 511-3698 511-3707 531-4098 #543-4286 543-4291 543-4297 545-4334
O.TYP1		101004	#539-4244 543-4287
O.UIN		075752	#507-3637 *523-3969 *537-4158 537-4193
O.UPC		075700	#507-3627 *509-3653 *527-4015 527-4027 *531-4063 531-4083 *531-4087 *531-4100
O.URO		075662	#507-3620 509-3662 511-3725
O.USP		075676	#507-3626 509-3685 511-3695 *535-4130 535-4131 535-4150
O.UST		075702	#507-3628 *527-4020 *527-4023 527-4026 527-4029 *529-4058 *531-4064 531-4072 *545-4302
O.WRD		076760	517-3923 #519-3858
O.WRD1		077036	519-3839 #519-3872 521-3922
O.WST		101202	509-3651 509-3674 527-4017 527-4031 529-4049 529-4056 531-4082 #545-4312
O.XXX		075564	#505-3587 *535-4129 535-4137 *535-4144 535-4151
PADDRE		002042	#39-1135 *282-6176 561-4702
PAFBAF		015730	100-2720 #121-3010 121-3039 121-3047
PAFBAW		016066	100-2721 #123-3052 123-3083 123-3088 123-3096
PARBAF		016246	100-2722 #125-3101 125-3130 125-3138
PARBAW		016404	100-2723 #127-3143 127-3174 127-3179 127-3187
PARCNT		002074	#39-1147 *66-1803 66-1815 *68-1856 68-1887 68-1905 68-1927 *82-2229 *103-2755
			103-2757 *282-6173 282-6174 561-4702
PARITY		036454	48-1465 #282-6168
PARTHF		002372	#39-1218 *259-5652 *261-5714 *261-5725 *261-5728 282-6189 345-7232 *345-7248 *345-7265
			347-7271 *347-7287 *347-7317 *356-7585
PARVEC		000114	#12-331 *48-1465
PASFLG		002362	#39-1213 *130-3199 *132-3253 *172-4180 172-4197 *172-4198 207-4698 207-4769 *207-4771
			213-4872 215-4916 *215-4918 218-4944 218-4997 *218-4999 221-5021 221-5074 *221-5076
			224-5100 226-5154 *226-5156 *349-7381
PATERR		002076	#39-1148 68-1848 *68-1855 68-1885 68-1903
PATFLU		005472	55-1551 55-1553 55-1556 55-1558 55-1561 55-1563 #55-1567
PATTER		002120	#39-1157 *110-2844 *112-2867 *114-2910 *116-2937 *118-2987 *121-3011 *123-3053 *125-3123
			*127-3167 150-3662 152-3728 *328-6932 328-6933 *328-6938 349-7323 *349-7341 349-7342
			349-7343 349-7390 *349-7435 352-7448 *352-7491 354-7497 *354-7544 358-7646 *358-7693
PCBUMP		002406	#39-1224 *150-3661 *152-3727 *155-3813 *155-3838 *155-3849 *157-3862 *157-3879 *168-4102
			282-6183 349-7323 *349-7389 *349-7433
PCONF1		035402	97-2660 #274-5953 349-7441
PCONF5		035662	*274-5955 274-5992 #274-5998
PCONF1		035572	274-5966 #274-5983
PCONF2		035630	274-5956 274-5981 #274-5992
PDP110		036752	48-1467 #284-6230
PENDBO		002330	#39-1197 *65-1708 *65-1735 78-2136 78-2137
PERAOS		064732	#446-1908 446-1915
PERENK		065564	394-599 449-1989 449-2001 451-2016 #453-2037 455-2111
PERECC		065650	#453-2053 453-2065
PERRAB		065402	446-1930 446-1935 #449-2000

CEMKAB SYMBOL	CREATED BY	MACRO	ON	3-AUG-79	AT	17:42	PAGE	23	D	6	SEQ	1103
SYMBOL	CROSS REFERENCE	REFERENCES					CREF	V01				
SYMBOL	VALUE	REFERENCES										
PERRAW	065330	394-580	396-612	446-1887	446-1893	446-1899	446-1905	446-1920	446-1925	448-1941		
		448-1946	448-1951	448-1956	448-1961	448-1966	448-1976	448-1981	448-1986	#449-088		
PERRA3	054652	#394-582	451-2022	451-2026								
PERRA7	065454	448-1971	#451-2013									
PERR01	= 104427	#10-198	189-4432	268-5854								
PERR02	= 104430	#10-199	189-4420	189-4445	268-5848							
PERR03	= 104431	#10-200	194-4498	194-4506								
PERR04	= 104432	#10-201	196-4522	196-4544								
PERR05	064726	#446-1907										
PERR06	064754	#446-1914										
PERR07	= 104433	#10-202	199-4560	199-4579								
PERR10	= 104434	#10-203	199-4565	199-4584								
PERR11	= 104435	#10-204	202-4602	204-4652	237-5309	239-5353	241-5396					
PERR12	= 104436	#10-205	202-4608	204-4659								
PERR13	= 104437	#10-206	202-4616									
PERR14	= 104440	#10-207	202-4622									
PERR15	= 104441	#10-208										
PERR16	= 104442	#10-209										
PERR17	= 104443	#10-210	244-5421	244-5443	244-5454	246-5478	251-5535	251-5539				
PERR20	= 104444	#10-211	244-5427	244-5437	244-5460	246-5472	251-5544	251-5548				
PERR21	= 104445	#10-212	239-5332	241-5378								
PERR22	= 104446	#10-213	229-5189	268-5834								
PERR23	= 104447	#10-214	254-5611	256-5640								
PERR24	104450	#10-215	254-5616									
PERR25	= 104451	#10-216	264-5751	264-5756								
PERR26	= 104452	#10-217	232-5219	232-5244	234-5271							
PERR27	= 104453	#10-218	232-5231	234-5259								
PERR30	= 104454	#10-219	266-5797									
PERR31	= 104455	#10-220	207-4725	207-4731	218-4975	218-4981	221-5055	221-5060	224-5131	224-5137		
PERR32	= 104456	#10-221	207-4737	207-4751								
PERR33	= 104457	#10-222	210-4821									
PERR34	= 104460	#10-223	207-4743	207-4757	210-4829							
PERR35	= 104461	#10-224	270-5871	270-5878								
PERR36	104462	#10-225										
PERR37	= 104463	#10-226										
PERR40	= 104464	#10-227										
PERR41	104465	#10-228										
PERR42	= 104466	#10-229										
PERR43	104467	#10-230										
PERXOR	065540	449-1992	449-2004	451-2015	#451-2028	453-2060	455-2096					
PFLAG	002130	#39-1161	110-2847	314-6654	*325-6879	*325-6900	390-466	413-1076	421-1252	424-1317		
		426-1377	428-1425	430-1467	434-1534	438-1623	440-1684					
PHYADD	002044	#39-1136	*469-2434	*469-2435	*469-2436	*469-2437	*469-2439	469-2440				
PORTCO	002646	#41-1304	*374-172	374-191	*374-191	*374-198	*390-469	*390-469	*390-469	*390-469		
		*390-504	392-546	392-547	430-1491	430-1492	436-1583	436-1584	561-4718	561-4718		
		561-4718	561-4718	561-4725	561-4725	561-4725	561-4725					
PORTDI	002606	#41-1300	*57-1600	*57-1607	*84-2279	93-2520	93-2520	93-2535	93-2542	366-23		
		408-920	561-4719	561-4719	561-4719	561-4719						
PSW	= 177776	#12-261	*61-1651	*61-1652	*61-1658	*68-1868	*68-1881	*68-1898	*68-1920	*70-1969		
		*136-3332	*147-3630	*174-4225	*176-4251	*178-4284	*183-4357	*186-4391	*274-5959	*291-6345		
		*291-6347	*316-6699	*318-6740	*320-6791	*320-6807	*336-7087	*345-7251	*347-7291	*347-7309		
		*349-7372	*352-7466	*354-7522	*356-7595	*356-7602	*358-7671	*366-22	*366-30	*366-59		

CEMKAB SYMBOL	CROSS REFERENCE VALUE	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES
PTVBUF	002636	*368-67	*368-81	*370-101	*372-146	*372-158	*374-165	*374-169	*374-190	*376-232
		*378-263	*378-280	*380-304	*380-312	*380-333	*384-371	*384-375	*386-387	*386-398
		*388-441	*388-452	*390-468	*390-496	*394-571	*394-593	*396-608	*396-622	*399-670
		*399-674	*402-756	*402-760	*404-799	*406-836	*408-925	*482-2717	*482-2718	*482-2734
		#41-1303	84-2288	*372-149	372-153	372-159	*372-159	*408-928	*409-966	*438-1628
		438-1649	438-1650	484-2765	484-2766					
PTVFLA	002626	#41-1302	408-926	*408-929	457-2136	457-2136	457-2136	457-2136	484-2759	*484-2767
		484-2770	*484-2775							
PWLOCK	002760	#43-1339	*398-642	*404-789						
PWRVEC	= 000024	#12-324	*48-1463	*48-1464	*53-1529	*398-646	*398-647	*399-704	*401-712	*402-777
		404-800	404-801	*404-803	*404-804	*406-837	*406-838			
QUE	072154	90-2393	91-2443	91-2480	390-482	390-528	409-973	409-1016	411-1046	413-1082
		421-1265	421-1287	424-1329	424-1351	426-1401	428-1442	430-1478	436-1603	438-1636
		440-1701	442-1726	457-2137	#484-2754					
QUE1	072222	#484-2765	484-2772							
QUICK	002536	#39-1272	*53-1528	336-7074						
QVFLAG	002440	#39-1238	*53-1528	*53-1532	108-2802	*108-2804	163-3984	207-4764	210-4846	215-4911
		218-4992	221-5069	226-5149	330-6952	332-6992				
RANODD	034626	*168-4114	#264-5753	*264-5757						
RDCHR	= 104411	#10-177	491-3085							
RDDEC	= 104414	#10-180	339-7137							
RDLIN	= 104412	#10-178	492-3162	492-3213						
RDOCT	= 104413	#10-179	57-1593	343-7212	343-7215	345-7236	347-7275	347-7307	349-7328	349-7340
		349-7345	349-7350	354-7501	356-7560	356-7574	358-7650	360-7703	362-7750	364-7783
READCS	104426	#10-196	65-1709	78-2152	134-3294	138-3395	140-3427	147-3636	237-5303	239-5325
		239-5347	241-5371	241-5390	259-5662	261-5719	261-5730	297-6413	297-6432	299-6448
		299-6467	341-7191	343-7206	343-7220	394-586	399-684	471-2477	480-2690	
READON	002504	#39-1259	*370-105	*370-116	370-139	*376-231	376-256	*376-258	*378-270	*378-276
REALPA	002366	#39-1216	*153-3782	*153-3790	*153-3799	*155-3812	*155-3837	*155-3848	*157-3861	*157-3868
		*157-3878	*159-3891	*159-3900	*159-3908	*159-3918	*161-3929	*161-3938	*161-3943	*163-3953
		*165-4023	*165-4049	*165-4057	*166-4068	*166-4094	*168-4101	*170-4126	*172-4181	*174-4222
		*176-4242	*178-4280	*178-4298	*180-4321	*372-150	453-2066	453-2069	453-2072	453-2075
		458-2178	467-2400	490-3028						
		249-5522	#251-5559							
REFRES	033760	251-5562	251-5566	#251-5570						
REFSUB	034030	153-3785	153-3794	#271-5907	370-136					
REGCOP	035204	112-2885	114-2919	116-2960	118-3001	121-3044	123-3093	125-3135	127-3184	172-4200
RELOCA	041130	#314-6649								
RELOC1	041456	#316-6697	368-70							
RESREG	= 104416	#10-183	155-3829	166-4084	168-4116	271-5948	320-6774	320-6811	339-7130	341-7184
		#370-140	378-296	419-1237	465-2358	496-3346				
RESTAR	002752	*37-1102	*37-1104	#43-1336	51-1483					
RESVEC	= 000010	#12-319	*48-1467	*48-1468						
RLFLAG	002134	#39-1163	112-2882	114-2916	116-2957	118-2998	121-3041	123-3090	125-3132	127-3181
		*316-6714	*318-6746	325-6901	334-7035	336-7073	339-7128	*368-76	398-659	458-2188
		484-2776	490-3017							
RRFLAG	002132	#39-1162	112-2865	114-2899	116-2935	118-2976	121-3020	123-3064	125-3111	127-3155
		132-3240	170-4136	170-4159	172-4190	*325-6879	*325-6885	*325-6900	*325-6903	*325-6911
		349-7363	352-7479	354-7533	358-7682					
SAVREG	= 104415	#10-182	155-3823	166-4076	168-4109	271-5942	320-6772	320-6775	339-7125	370-137
		378-293	419-1223	463-2289	496-3331					
SBECSR	002150	#39-1168	*150-3672	*150-3673	*237-5283	*237-5284	475-2545	475-2548		

CEMKAB		CREATED BY	MACRO	ON	3-AUG-79	AT	17:42	PAGE	25	F	6
SYMBOL	CROSS REFERENCE	VALUE	REFERENCES					CREF	V01		
SBEFLA	002022		#39-1127	105-2773	*108-2796	*150-3671	*237-5282				
SBFMSK	002350		#39-1210	*207-4693	*207-4694	207-4709	207-4711	207-4759	*207-4761	*207-4761	*210-4788
			*210-4789	210-4794	210-4796	210-4806	210-4841	*210-4843	*210-4843	*213-4866	*213-4867
			213-4877	213-4879	213-4883	213-4885	215-4912	*215-4914	*215-4914	*218-4938	*218-4939
			218-4949	218-4951	218-4955	218-4957	218-4993	*218-4995	*218-4995	*221-5015	*221-5016
			221-5026	221-5028	221-5032	221-5034	221-5070	*221-5072	*221-5072	*224-5094	*224-5095
			224-5104	224-5106	224-5110	224-5112	226-5150	*226-5152	*226-5152		
SBE TES	017374		132-3247	#136-3306							
SCOPE	- 000004		#12-260	65-1689	66-1796	68-1833	70-1956	72-2031	100-2710	103-2730	103-2740
			183-4363	186-4397							
SDPAR0	- 172260		#12-429	155-3828	166-4078	166-4080	168-4112	194-4501	254-5623		
SDPAR7	= 172276		#12-436								
SDPDR7	= 172236		#12-416								
SECOND	- 011661		#14-559	90-2391	390-481	390-527	409-972	409-999	409-1015	413-1081	417-1193
			421-1264	421-1286	424-1328	424-1350	426-1400	428-1441	430-1477	436-1602	438-1635
			440-1700	442-1725							
SEFDHI	002714		#43-1321	*48-1449	168-4104	*168-4119	388-439	494-3304	494-3311	*494-3316	
SEEDLO	002716		#43-1322	*48-1450	168-4103	*168-4118	494-3303	494-3309	*494-3315		
SELONL	002002		#39-1116	103-2733	103-2748	132-3227	325-6910	*362-7760	*362-7765		
SETMAR	043212		114-2903	118-2980	125-3113	127-3157	#332-6989				
SETPAT	042762		114-2901	118-2978	#328-6936						
SHALT	004420		#46-1412								
SHUTUP	043554		108-2813	336-7054	#336-7062						
SIDE	002422		#39-1231	*132-3234	132-3268	*132-3271	132-3271	145-3506	145-3522	145-3538	145-3554
			145-3582	145-3598	145-3614	147-3647	147-3648	*163-3961			
SIDEOK	021066		132-3244	#147-3624							
SIPARO	= 172240		#12-419	311-6606							
SIPAR3	- 172246		#12-422	311-6620							
SIPDRO	- 172200		#12-399	311-6608	398-663	401-748					
SIZE	= 040000		#14-558	66-1809	68-1864	68-1893	68-1918	153-3784	153-3792	153-3801	155-3818
			155-3842	155-3853	168-4108	170-4141	170-4164	172-4191	176-4247	176-4266	178-4300
			241-5408	268-5850	271-5944	316-6700	318-6741	320-6792	320-6808	352-7484	368-87
			370-107	376-249	378-269	378-290	426-1383				
SIZELO	- 177760		#12-343	80-2172	80-2174	80-2176	80-2180				
SKIPKA	002012		#39-1120	341-7172	*341-7174	*360-7712	*360-7718				
SLAVEM	061244		59-1626	417-1214	#419-1221						
SLAVEN	075774		#507-3639	569-5002	569-5003						
SLAVER	002570		#39-1285	460-2242	*484-2777	*484-2779					
SLAVES	002730		#43-1327	*57-1594	57-1596	57-1596	57-1599	76-2108	*76-2109	*78-2130	*90-2396
			*91-2449	*91-2455	91-2462	*91-2486	91-2492	93-2515	93-2543	99-2699	325-6892
			382-341	382-342	390-475	390-490	390-523	390-536	392-553	409-983	409-1026
			411-1059	413-1104	415-1117	421-1278	421-1296	421-1300	424-1342	424-1360	424-1364
			426-1393	426-1409	428-1434	428-1450	430-1472	430-1486	430-1498	432-1521	434-1549
			434-1556	434-1564	434-1568	436-1596	438-1630	438-1644	438-1655	440-1693	440-1709
			440-1712	442-1734							
SLAVE1	- 000040		#14-562	84-2257	95-2571	95-2580	279-6096	408-921			
SLAVE2	- 000100		#14-563	84-2261	95-2571	95-2581	279-6096	408-922			
SLAVE3	= 000200		#14-564	84-2265	95-2571	95-2582	279-6096	408-923			
SLAVUP	061216		86-2316	384-358	409-986	#417-1213					
SLFLAG	002656		#41-1305	*95-2578	*95-2578	*95-2578	*95-2578	*95-2578	*95-2579	*95-2580	*95-2581
			*382-340	*382-345	382-350	*382-350	390-503	561-4701	561-4701	561-4701	561-4701
SLPAT	051570		370-120	370-122	370-124	370-126	370-128	#370-130			

EMKAB CREATED BY MACRO ON 3-AUG-79 AT 17:42

PAGE 26
CREF V01

SEQ 1106

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
SLPAT0		051530	#368-89 #370-109 #370-119 378-271
SLPAT1		051534	368-90 370-110 #370-121 378-27
SLPAT2		051542	368-91 370-111 #370-123 378-275
SLPAT3		051550	368-92 370-112 #370-125 378-274
SLPAT4		051556	368-93 370-113 #370-127 378-275
SLPAT5		051564	368-94 370-114 #370-129
SOBK		002704	#43-1317 174-4228
SOBLEN	=	000056	174-4226 174-4231 #266-5812
SOF TPA		002744	#43-1333 #48-1453 #105-2780 178-4301
SOURCE		002402	#39-1222 *207-4704 *210-4792 *213-4881 *218-4953 *221-5030 *224-5108 *259-5648 306-6539
SPECIA		002432	#39-1235 132-3244 *138-3394 *145-3500 *145-3516 *145-3532 *145-3548 *145-3576 *145-3592
SSP	=	%000006	*12-277 *61-1655 *183-4358 *186-4392 399-675 *402-757 482-2719
ST	-	177776	#502-3572 545-4302 *545-4312
STACK		002000	#12-255 12-256 37-1094 37-1108 43-1318 46-1428 53-1531 91-2507 108-2809
			368-71 409-978 409-1004 409-1021 409-1028 413-1105
START		004352	37-1103 37-1105 #46-1403 78-2158 90-2387 336-7059 404-793
START1		000300	37-1098 #37-1102 37-1107
START2		000310	37-1099 #37-1104
START3		000200	#37-1098 569-5012
START4		000322	37-1100 #37-1106
STOPCP		011720	#84-2282 376-224
STOPOK		002520	#39-1265 *82-2239 457-2140 *457-2141
STRIPE		002460	#39-1249 *249-5501 249-5505 251-5526 *251-5556 251-5556
STRTDI		002364	#39-1215
SUBAAA		005532	55-1565 #57-1578
SUBAAB		005200	#53-1516
SUBAAQ		007720	68-1876 #70-1937
SUBAAR		013160	84-2256 #93-2546
SUBAAS		007002	65-1776 #66-1795
SUBAAT		011334	80-2173 80-2186 #82-2201
SUBAAU		014602	103-2764 #105-2773
SUCCESS		002424	#39-1232 *132-3237 *132-3258 132-3266 *356-7623 356-7629 *356-7631 *476-2589 476-2613
			476-2620 *478-2629 *478-2631 *478-2633 *478-2635 *478-2638 *478-2640 *478-2642
SUPDOA		002360	#39-1212 *155-3824 *157-3864 *157-3874 *157-3881 *159-3892 *159-3901 *159-3909 *159-3919
			*161-3930 *161-3939 *161-3944 *163-3955 *165-4050 *165-4058 *166-4080 *166-4095 *170-4131
			*174-4232 *176-4264 *178-4289 *178-4308 186-4394 *370-135 *372-151 *374-181 *376-252
SUPDO1		026042	103-2756 153-3787 153-3796 153-3807 163-3983 165-4032 168-4113 168-4117 170-4144
			170-4167 172-4193 178-4314 #183-4334 271-5947 370-138 376-255 378-294
SUPDO2		026056	*55-3830 155-3845 155-3856 163-3988 163-3994 163-4001 163-4007 163-4013 165-4035
			165-4039 165-4042 176-4269 #183-4336 378-297
SUPDO3		026220	155-3825 157-3865 157-3875 157-3882 159-3893 159-3902 159-3911 159-3920 161-3931
			161-3940 161-3945 165-4051 165-4060 166-4096 170-4147 170-4170 178-4311 #186-4369
			352-7486 370-139 372-154 376-256
SUPDO4		026234	163-4017 166-4081 166-4087 174-4233 176-4265 178-4293 #186-4370 374-182 374-186
SUPDRO		002266	#39-1179 *183-4338 183-4346 *186-4372 186-4380
SUPDR1		002270	#39-1180 183-4339 186-4373
SUPDR2		002272	#39-1181
SUPDR3		002274	#39-1182
SUPDR4		002276	#39-1183
SUPDR5		002300	#39-1184
SUPDR6		002302	#39-1185 183-4349 186-4383

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
SUP1M		057372	#408-947 569-4997 509-4998
SUPM13		053752	#390-458 438-1663
SUPSTK	-	000740	#12-257 61-1654 183-4358 186-4392 482-2722 482-2728
SWAPAT		002764	#43-1343 *48-1452
SW4		002766	#43-1346 *51-1496 51-1498 *51-1503 *53-1525 63-1666 66-1826 70-2022 90-2370
			*90-2371 90-2372 *91-2494 97-2659 100-2712 108-2802 150-3655 150-3668 163-3984
			163-3989 163-3995 163-4002 163-4008 207-4763 210-4845 215-4910 218-4991 221-5068
			226-5148 274-5966 314-6650 314-6666 314-6687 330-6952 332-6992 349-7355 349-7383
			352-7450 354-7506 354-7511 356-7554 356-7579 356-7603 358-7655 358-7660 399-700
			401-719 409-956 *409-957 409-958 *413-1107 457-2140 457-2148 457-2164 460-2219
			460-2242 460-2245 461-2252 461-2256 465-2359 488-2952 488-2952 488-2960 488-2982
SUREG	-	000176	#14-550 51-1503 63-1666 90-2371 409-957 488-2952
SW0	=	000001	#12-297 66-1826 70-2022 150-3655 150-3668 163-3989 163-3995 163-4002 163-4008
			349-7383 352-7450 354-7511 356-7554 358-7660
SW1		000002	#12-296
SW10		002000	#12-287 460-2219
SW11	-	004000	#12-286 108-2802 163-3984 207-4763 210-4845 215-4910 218-4991 221-5068 226-5148
			330-6952 332-6992 349-7355 354-7506 356-7579 358-7655
SW12	-	010000	#12-285 314-6650
SW13	-	020000	#12-284 314-6666 314-6687 460-2242
SW14	-	040000	#12-283 457-2148
SW15		100000	#12-282
SW2		000004	#12-295
SW3		000010	#12-294
SW4		000020	#12-293 274-5966
SW5		000040	#12-292 460-2245
SW6	-	000100	#12-291 97-2659
SW7		000200	#12-290 465-2359
SW8		000400	#12-289 457-2140
SW9		001000	#12-288 457-2164 461-2256
SYSS1Z		011210	80-2178 80-2182 #80-2189
SYSTID		177764	#12-347 57-1600 84-2272 366-16 408-913
TAG2\$		007366	68-1851 #68-1873
TAG3\$		007412	68-1872 #68-1877
TAG4\$		026136	183-4347 #183-4349
TAG70\$		067636	465-2332 #467-2369
TAG71\$		067646	465-2333 #467-2375
TAG72\$		067656	465-2334 #467-2381
TAG73\$		067722	465-2335 #467-2394
TAG74\$		067730	465-2336 #467-2400
TAG75\$		067742	465-2337 #467-2406
TAG76\$		067754	465-2338 #467-2412
TAG77\$		067776	465-2339 #469-2423
TAG78\$		070000	465-2340 #469-2428
TAC79\$		070006	465-2341 #469-2434
TAG80\$		070066	465-2342 #469-2448
TAG81\$		070100	465-2343 #469-2454
TAG82\$		070122	465-2344 #471-2472
TAG83\$		070324	465-2345 #473-2504
TAG84\$		070410	465-2346 #473-2522
TAG85\$		070502	465-2347 #475-2543
TAG86\$		070612	465-2348 #475-2567

SYMBOL	VALUE	REFERENCES
TASK	007232 002616	#68-1849 68-1879 68-1912 68-1934 #41-1301 *84-2285 *84-2298 91-2453 91-2490 366-31 366-35 *366-60 368-82 370-102 376-233 378-264 378-281 *380-306 *390-474 390-488 *390-522 390-534 409-981 409-1024 *411-1043 411-1057 *413-1080 413-1090 *417-1217 *421-1258 421-1271 *421-1277 421-1293 *424-1322 424-1335 *424-1341 424-1357 *426-1391 426-1407 *428-1433 428-1448 *430-1471 430-1484 *434-1542 *434-1555 436-1609 *438-1629 438-1642 *440-1689 *440-1691 440-1707 *442-1724 442-1732 84-2301 366-5 #366-10 390-476 417-1218 421-1261 421-1280 424-1325 424-1344 426-1395 428-1436 430-1473 434-1544 434-1557 438-1631 440-1695
TASKDC	050726	#366-4 366-62 #366-39 #366-63 366-40 #368-66 366-41 #368-80 366-42 #370-100 366-43 #372-145 366-44 #374-164 366-45 #376-219 366-46 #376-226 366-47 #376-230 366-48 #378-262 366-49 #378-279 366-50 #380-301 366-51 #384-356 366-52 #384-361 366-53 #384-365 366-54 #384-370 366-55 #386-385 376-228 #376-232
TASKRE	050710	
TASK00	051234	
TASK01	051236	
TASK02	051330	
TASK03	051430	
TASK04	051664	
TASK05	051774	
TASK06	052300	
TASK07	052326	
TASK10	052336	
TASK11	052536	
TASK12	052644	
TASK13	052726	
TASK14	053276	
TASK15	053310	
TASK16	053316	
TASK17	053334	
TASK20	053422	
TASK7A	052344	
TBG4S	026314	186-4381 #186-4383
TCFIG1	036012	#279-6051 279-6081 467-2385
TCONF1	035664	274-5971 274-5980 274-5990 #277-6015
TEMP	002534	#39-1271 *99-2666 99-2683 *99-2684
TESTAD	002506	#39-1260 *132-3246 *132-3261 132-3261 136-3331 157-3863 157-3880 207-4713 207-4775 210-4798 210-4836 210-4853 213-4863 215-4922 218-4963 218-4969 218-5003 221-5040 221-5047 221-5051 221-5079 224-5118 224-5127 226-5159 259-5651 453-2055
TIME	002434	#39-1236 *352-7458 352-7460
TIMEOU	036726	48-1469 51-1502 51-1513 57-1612 61-1646 65-1774 66-1823 68-1874 76-2098 #284-6223 341-7194 341-7198 343-7210 343-7227 345-7266 347-7318 458-2195
TKVEC	- 000060	#12-327 274-5954 274-5954 *274-5956 *274-5957 *274-5995 *274-5995 349-7323 349-7323 *349-7369 *349-7370 *349-7431 *349-7431 352-7448 *352-7448 *352-7463 *352-7464 *352-7474 *352-7474 354-7497 354-7497 *354-7519 *354-7520 *354-7544 *354-7544 356-7551 356-7551 *356-7592 *356-7593 *356-7613 *356-7613 358-7646 358-7646 *358-7668 *358-7669 *358-7693
TMFLAG	002140	#39-1165 *121-3035 *123-3079 *125-3126 *127-3170 328-6922
TOOMAN	002472	#39-1254 *453-2049 460-2245 *461-2277
TRAPVE	- 000034	#12-326 *48-1461 *48-1462
TRT	= 000003	#502-3577 523-3969 547-4400
TSK05A	052240	374-170 #374-201 374-215
TSK13A	053100	380-302 #380-324
TSK13B	053136	380-335 #382-338
TSK20A	053602	386-386 #386-422
TSTBAN	007606	68-1860 #68-1915

CEMKAB
 SYMBOL CROSS REFERENCE
 SYMBOL VALUE
 TSTDAT 002344

CREATED BY MACRO ON 3-AUG-79 AT 17:42

PAGE 29
 CREF V01

J 6

SEQ 11

REFERENCES

TSTRD1	037434	#39-1209	*207-4696	*207-4697	*207-4700	*207-4701	207-4702	207-4703	207-4704	*207-4710
TSTREA	= 104510	*207-4712	207-4715	207-4717	207-4723	207-4729	*210-4790	*210-4791	210-4792	*210-4795
TST1	006260	*210-4797	210-4801	210-4803	*213-4870	*213-4871	*213-4874	*213-4875	213-4881	*213-4884
TST2	007004	*213-4886	*213-4888	*213-4890	213-4892	213-4894	*218-4942	*218-4943	*218-4946	*218-4947
TST3	007160	218-4953	*218-4956	*218-4958	*218-4960	*218-4962	218-4965	218-4967	218-4973	218-4979
TST4	010310	*221-5019	*221-5020	*221-5023	*221-5024	221-5030	*221-5033	*221-5035	*221-5037	*221-5039
TST5	014342	221-5042	221-5045	221-5053	221-5058	*224-5098	*224-5099	*224-5102	*224-5103	224-5108
TST6	014414	*224-5111	*224-5113	*224-5115	*224-5117	224-5120	224-5122	224-5129	224-5135	*259-5646
TST7	014456	*259-5647	259-5648	*259-5664	*259-5666	*259-5668	*259-5669	*259-5671	*259-5674	*259-5675
TWOCSR	002600	*259-5677	*259-5679	*259-5680	*259-5682	261-5708	261-5710	448-1950	448-1955	453-2056
TYPDS	104405	453-2058	561-4713	561-4713						
TYPEIT	- 104401	291-6323	#291-6344							
		#10-248	136-3348	136-3367	207-4739	207-4753	210-4811	210-4823		
		#65-1689								
		#66-1796								
		#68-1833								
		#72-2031								
		#100-2710								
		#103-2730								
		#103-2740								
		#59-1289	*78-2141	*78-2149	289-6281	289-6292	*343-7217	*343-7219		
		#10-171	97-2653	97-2655	97-2657	108-2806	352-7460	356-7620	356-7636	467-2375
		#10-167	57-1582	57-1592	91-2474	91-2476	93-2522	93-2534	93-2541	97-2652
		97-2654	97-2656	97-2658	108-2801	108-2803	132-3269	134-3296	134-3298	145-3570
		274-5962	274-5963	274-5964	274-5970	274-5972	274-5973	274-5974	274-5975	274-5976
		274-5977	274-5986	274-5987	274-5988	274-5989	277-6015	277-6018	277-6020	277-6029
		277-6039	279-6049	279-6078	279-6089	279-6102	279-6112	279-6126	279-6135	279-6143
		279-6145	314-6667	314-6688	339-7126	339-7129	339-7136	339-7141	341-7170	341-7196
		343-7207	343-7211	343-7214	343-7221	343-7225	345-7234	345-7235	345-7257	345-7261
		347-7273	347-7274	347-7297	347-7301	347-7304	347-7306	347-7313	349-7326	349-7327
		349-7335	349-7339	349-7344	349-7349	349-7356	349-7364	349-7368	352-7455	352-7459
		352-7461	352-7462	352-7476	352-7489	354-7499	354-7500	354-7507	354-7516	354-7518
		354-7538	356-7553	356-7559	356-7573	356-7580	356-7589	356-7591	356-7621	356-7630
		356-7637	358-7648	358-7649	358-7656	358-7665	358-7667	358-7687	360-7702	360-7711
		360-7716	360-7722	360-7728	360-7734	362-7740	362-7745	362-7749	362-7759	362-7764
		364-7782	402-778	408-893	457-2142	460-2221	460-2222	461-2268	463-2290	463-2310
		463-2311	463-2313	463-2320	463-2322	465-2352	465-2362	467-2388	467-2414	467-2416
		469-2428	469-2443	469-2454	469-2456	471-2497	473-2505	473-2514	473-2523	473-2534
		475-2560	475-2568	475-2571	475-2574	475-2577	476-2585	476-2623	480-2683	480-2684
		480-2692	480-2694	482-2706	482-2710	482-2712	482-2721	482-2724	482-2726	482-2730
		482-2737	482-2740	482-2742	482-2746	482-2748	484-2764	484-2774	486-2849	487-2914
		488-2958	488-2959	488-2961	488-2970	488-2975	488-2984	488-3002	490-3009	490-3014
		490-3018	490-3020	490-3022	490-3027	491-3089	491-3098	491-3104	491-3109	491-3113
		491-3118	491-3119	491-3121	491-3124	491-3128	492-3189	492-3191	492-3192	492-3193
		492-3248	492-3250	492-3251	492-3252	498-3467				
TYPOC	104402	#10-168	463-2295	467-2369	480-2691	480-2693	482-2711	482-2713	482-2725	482-2727
		482-2741	482-2743	488-2960						
TYPOS	104403	#10-169	91-2475	93-2535	93-2542	345-7254	347-7305	347-7314	356-7633	467-2400
		467-2406	469-2448	469-2455	490-3015	490-3021	490-3026	490-3028		
T12A	031700	#224-5092	226-5157							
T12B	031722	#224-5096	226-5153							
UDPARO	177660	#12-389	256-5641							

CEMKAB
SYMBOL CROSS REFERENCE

CREATED BY MACRO ON 3-AUG-79 AT 17:42

PAGE 30
CREF V01

K 6

SEQ 1110

SYMBOL	VALUE	REFERENCES
UDPAR1	= 177662	#12-390 382-347 382-347
UDPAR7	= 177676	#12-396
UDPDR7	= 177636	#12-375 155-3822
UIPAR0	= 177640	12-378 #12-379 322-6816 380-303 382-343 382-343
UIPAR2	= 177644	#12-381 *68-1861 *68-1896 *170-4130 *178-4307 194-4510 264-5781 *271-5946 *370-134
UIPAR3	= 177646	#12-382 68-1882 170-4131 178-4308 370-135
UIPAR4	= 177650	#12-383 320-6778 320-6795 *376-251
UIPAR5	= 177652	#12-384 376-252
UIPAR6	= 177654	#12-385 *68-1847 196-4533
UIPAR7	= 177656	#12-386 *68-1848
UIPDRO	= 177600	#12-358 322-6818 398-662 401-747
UNITOP	002516	#39-1264 *76-2102 80-2167 80-2167 *97-2645 *97-2646 *97-2647 *97-2648 *97-2649
UNRELO	041604	97-2651 97-2651 112-2889 114-2923 116-2964 118-3005 121-3048 123-3097 125-3139 127-3188 172-4210
UPPFLG	002363	#318-6718 334-7035 336-7073
UP2	056154	#39-1214 *218-4968 218-4983 *218-4985 *224-5123 226-5140 *226-5142
USERMA	042240	404-790 #404-793
USESTK	= 000700	316-6698 318-6739 320-6773 #322-6815
USP	= %000006	#12-258 61-1660 376-220 482-2738 482-2744
WAITST	012034	#12-278 *61-1661 399-671 *402-761 482-2735
WAITS	063674	84-2286 #86-2305
WAKEUP	054544	434-1546 434-1563 #436-1600
WARN1	007320	390-498 #392-558
WARN2	026522	#68-1861
WARN3	026536	#192-4465 *271-5933
WARN4	026562	#192-4470 *271-5934
WARN5	026576	#192-4482 *271-5935
WARN6	035364	#192-4487 *271-5936
WARN7	024416	#271-5946
WASDBE	- 104507	#170-4130
WASSBE	= 104476	#10-240 70-1976 70-1985 70-1993 70-2001
WAS1DB	- 104501	#10-238 150-3669
WAS1SB	= 104477	#10-241 213-4898
WHICHC	050630	#10-239 163-3990 163-4003 163-4009
WHOBOX	070672	341-7188 343-7203 #364-7775
WOOPEN	056512	467-2394 #476-2581
WOOPS	056160	404-802 404-805 404-807 406-821 406-842 #406-850 406-853
WOOPSA	056542	398-659 #404-795
WOOPUF	056336	*404-800 *404-801 404-802 406-837 406-838 406-841 #406-853
WORST	002712	404-802 404-803 404-805 404-805 404-805 #406-820 406-842 406-843
WRITEO	002502	406-853 #43-1320 *48-1444 *116-2952 *118-2993 *123-3085 *127-3176 325-6907
XXDPCH	002446	#39-1258 *105-2779 *105-2782 178-4309 *368-85 *368-96 370-138 *376-227 376-255
ZERO	002426	*376-258 *378-270 *378-276 *415-1181 *415-1183
ZEROS	002430	#39-1241 *53-1536 461-2267
\$APTHD	075236	#39-1233
\$AUTO	002066	#39-1234 147-3641 147-3642 249-5495 249-5499
\$BANK	002015	37-1096 #497-3436
\$BASE	075210	#39-1144 *53-1528 *53-1532 63- 565 488-2956
\$BELL	003003	#39-1123 *458-2177
		#497-3408
		#43-1353 354-7538 358-7687 460-2221

SYMBOL	CROSS REFERENCE VALUE	REFERENCES								
\$CACHF	037066	#286-6268	500-3504							
\$LACHN	037050	#286-6262	500-3503							
\$CBCSR	037700	#294-6389	500-3547							
\$CB1CS	037742	#294-6396	500-3548							
\$CDW1	075214	93-2547	93-2549	#497-3413						
\$CDW2	075216	93-2547	93-2550	#497-3414						
\$CHARC	057356	*408-895	*408-905	*408-939	#408-944					
\$CHKD1	040354	#301-6489	500-3555							
\$CHK1D	040410	#301-6496	500-3556							
\$CKSWR	073022	#488-2931	500-3487							
\$CLRCS	040322	#301-6480	500-3553							
\$CLR1C	040340	#301-6484	500-3554							
\$CMTAG	002000	#39-1114	46-1416							
\$CMTGE	002700	#41-1311	46-1418							
\$CNTLC	074224	488-2970	491-3089	#491-3140						
\$CNTLG	074236	488-2958	#491-3142							
\$CNTLU	074231	488-2975	491-3113	#491-3141						
\$CPUOP	075162	#497-3381								
\$CRLF	003010	#43-1355	97-2652	274-5972	274-5975	356-7637	408-894	463-2290	463-2313	463-2322
		480-2684	482-2710	482-2724	482-2740	482-2748	488-2984	490-3009	491-3118	
\$DBLK	073012	487-2884	487-2914	#487-2922						
\$DB20	075014	469-2441	#496-3331							
\$DDW0	075220	55-1548	#497-3425							
\$DDW1	075222	#497-3426								
\$DDW2	075224	#497-3427								
\$DDW3	075226	#497-3428								
\$DDW4	075230	#497-3429								
\$DDW5	075232	#497-3430								
\$DDW6	075234	99-2701	99-2703	#497-3431						
\$DEENE	037040	#286-6258	500-3499							
\$DEVCT	075144	*108-2834	*457-2129	*457-2131	#497-3371					
\$DEVVM	075212	#497-3409								
\$DOAGA	015040	108-2808	108-2810	#108-2831						
\$DOAGN	015010	#108-2820								
\$DOWN	055532	#399-705	399-706							
\$DTBL	073002	487-2887	#487-2918							
\$ECCDI	037466	#294-6355	500-3543							
\$ECCIN	037554	#294-6367	500-3545							
\$ECC1D	037522	#294-6361	500-3544							
\$ECC1I	037574	#294-6372	500-3546							
\$ENASB	037612	#294-6377	500-3557							
\$ENA1S	037646	#294-6383	500-3558							
\$ENDAD	015000	37-1087	53-1533	57-1581	#108-2816					
\$ENERG	037030	#286-6254	500-3498							
\$ENV	075154	53-1527	#497-3376							
\$ENVVM	075155	53-1520	53-1523	#497-3377						
\$EOP	014662	#108-2796								
\$ERFLG	002016	#39-1124	457-2162	*457-2168	*460-2215					
\$ERROR	066662	48-1459	#460-2213							
\$ERRTB	101372	463-2301	#549-4417							
\$ERRTY	067324	460-2249	#463-2289							
\$ERTTL	002754	#43-1337	80-2185	105-2774	108-2798	356-7620	356-7622	*460-2223	*460-2225	461-2267

CEMKAB SYMBOL	CROSS REFERENCE VALUE	REFERENCES								
\$OMODE	072574	*486-2816	*486-2820	486-2825	*486-2828	*486-2839	#486-2865			
\$OVER	066502	457-2148	457-2167	#457-2172						
\$PASS	075142	*53-1519	*93-2557	*108-2799	*108-2800	108-2806	108-2831	*108-2837	159-3889	159-3898
		159-3906	159-3916	161-3927	161-3936	163-3951	166-4092	#497-3370		
\$PASTM	075244	#497-3440								
\$PATMA	002014	#39-1122	402-774	402-775	*458-2178	*458-2187	*458-2190	*458-2191	458-2192	458-2193
		460-2218								
\$PER01	064574	#446-1883	500-3509							
\$PER02	064622	#446-1889	500-3510							
\$PER03	064650	#446-1895	500-3511							
\$PER04	064700	#446-1901	500-3512							
\$PER07	064762	#446-1917	500-3513							
\$PER10	065004	#446-1922	500-3514							
\$PER11	065034	#446-1927	500-3515							
\$PER12	065054	#446-1932	500-3516							
\$PER13	065076	#448-1938	500-3517							
\$PER14	065116	#448-1943	500-3518							
\$PER15	065140	#448-1948	500-3519							
\$PER16	065162	#448-1953	500-3520							
\$PER17	065202	#448-1958	500-3521							
\$PER20	065220	#448-1963	500-3522							
\$PER21	065236	#448-1968	500-3523							
\$PER22	065256	#448-1973	500-3524							
\$PER23	065274	#448-1978	500-3525							
\$PER24	065312	#448-1983	500-3526							
\$PER25	054570	#394-569	500-3527							
\$PER26	065502	#451-2020	500-3528							
\$PER27	065522	#451-2024	500-3529							
\$PER30	054762	#396-605	500-3530							
\$PER31	065720	#453-2064	500-3531							
\$PER32	066016	#455-2082	500-3532							
\$PER33	066064	#455-2091	500-3533							
\$PER34	066144	#455-2102	500-3534							
\$PER35	066176	#455-2111	500-3535							
\$PWRDN	055160	48-1463	#398-638	402-777						
\$PWUP	055536	399-704	#401-711	406-849						
\$QUES	003007	#43-1354	488-3002	491-3121						
\$RAND	074720	388-438	#494-3302							
\$RDCHR	073602	#491-3053	500-3489							
\$RDDEC	074436	#492-3210	500-3492							
\$RDLIN	073722	#491-3080	500-3490							
\$RDOCT	074266	#492-3159	500-3491							
\$READC	037220	#291-6304	500-3507							
\$RESRE	074662	#493-3283	500-3495							
\$SAVRE	074624	#493-3272	500-3494							
\$SAVR6	056140	*399-702	401-714	*401-715	*401-716	#402-784	406-832			
\$SCOPE	066232	48-1457	#457-2129							
\$STN	= 000001	#65-1689	#66-1796	#68-1833	#72-2031	#100-2710	#103-2730	#103-2740		
\$SVLAD	066466	457-2156	#457-2163	#457-2169						
\$SWR	= 163000	#8-131	65-1689	66-1796	68-1833	72-2031	100-2710	103-2730	103-2740	
\$SWREG	075156	53-1525	#497-3379							
\$TESTN	075140	*460-2218	#497-3369							

CEMKAB CREATED BY MACRO ON 3-AUG-79 AT 17:42

PAGE 34
CREF V01

500

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
\$TKR		002774	#43-1349 274-5958 274-5994 349-7371 349-7432 352-7465 352-7475 354-7521 354-7543
\$TKS		002772	356-7594 356-7612 358-7670 358-7692 488-2936 488-2966 490-3037 491-3057 491-3063
\$TN	=	000010	#43-1348 274-5960 274-5993 349-7373 349-7430 352-7467 352-7473 354-7523 354-7542
			356-7596 356-7611 358-7672 358-7691 488-2934 488-2964 490-3035 491-3055 491-3061
			#8-132 65-1689 65-1689 #65-1689 66-1796 66-1796 #66-1796 68-1833 68-1833
			#68-1833 72-2031 72-2031 #72-2031 100-2710 100-2710 #100-2710 103-2730 103-2730
			#103-2730 103-2740 103-2740 #103-2740
\$TPB		003000	#43-1351 408-935
\$TPFLG		002452	#39-1245 *53-1521 408-877
\$TPS		002776	#43-1350 408-933
\$TRAP		075252	48-1461 #498-3452
\$TRAP2		075274	#498-3463 500-3478
\$TRPAD		075314	498-3457 #500-3478
\$STM		075242	#497-3439
\$STRD		037310	#291-6322 500-3559
\$TTYIN		074200	491-3082 491-3083 491-3101 491-3119 491-3133 #491-3137
\$TYPDS		072576	#487-2877 500-3483
\$TYPE		056752	#408-877 500-3479
\$YPEC		057076	408-897 408-904 #408-907 484-2768 488-2988
\$YPEX		057360	408-940 408-942 #408-945
\$YPOC		072374	#486-2819 500-3480
\$YPON		072410	486-2818 #486-2821
\$YPOS		072350	#486-2814 500-3481
\$UNIT		075146	*108-2835 *457-2132 #497-3372
\$UNITM		075246	#497-3441
\$USWR		075160	108-2831 #497-3380
\$VECT1		075204	#497-3406
\$VECT2		075206	#497-3407
\$WASDB		040146	#299-6441 500-3551
\$WASDB		040002	#297-6406 500-3549
\$WAS1D		040262	#299-6467 500-3552
\$WAS1S		040116	#297-6432 500-3550
\$XTSTR		066370	#457-2150
\$ZAP42		014760	#108-2809 461-2271
\$OFILL		072573	*486-2815 *486-2819 486-2829 #486-2864