

IDENTIFICATION

PRODUCT CODE: AC-S439A-MC
PRODUCT NAME: CJFPAA0 FPF11 FLT PNT DIAG #1
DATE CREATED: JANUARY 1981
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: GUS PASQUANTONIO

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSIDERED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY OCCUR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1981 BY DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	HARDWARE
2.2	SOFTWARE
3.0	LOADING
4.0	STARTING
5.0	RUN TIME OPTIONS
6.0	ERROR HANDLING
7.0	RESTRICTIONS
8.0	MISCELLANEOUS
8.1	EXECUTION TIME
8.2	ACT, APT AND XXDP COMPATIBILITY
8.3	EXPANSION HOOKS
9.0	TEST DESCRIPTION
10.0	PROGRAM LISTING

1.0

ABSTRACT

=====

THE FPF11 DIAGNOSTIC PACKAGE CONSISTS OF TWO PROGRAMS
DESIGNED TO DETECT AND REPORT LOGIC FAULTS IN THE
LSI 11/23 FPF11 FLOATING POINT PROCESSOR (M8188).

THROUGH THE USE OF ALL ADDRESSING MODES, AND CAREFUL
SELECTION OF OPERANDS, ALL ROM MICRO STATES ARE EXECUTED
AND ALL BRANCH MICRO TESTS (BUT'S) ARE TAKEN PROVIDING
A THOROUGH VERIFICATION OF THE MICROCODE AND LOGIC.

PART 1 (CJFPAA) TESTS THE FOLLOWING FUNCTIONS:

LDFPS, STFPS, AND CFCC
SETF, SETD, SETI AND SETL
STST (DST MODE 0)
LDF AND LDD (ALL FSRC MODES)
STD (FDST MODE 0 AND 1)
ADD, ADDD AND SUBD
CMPD AND CMPF
DIVD AND DIVF
MULD AND MULF
MODD AND MODF

AND PART 2 (CJFPBA) FINISHES UP WITH:

STF AND STD (ALL FDST MODES)
STCFD AND STCDF
CLRD AND CLRF
NEGF AND NEGD
ABSF AND ABSD
TSTF AND TSTD
NEGF, ABSF AND TSTF (ALL FDST MODES)
NEGF, ABSF AND TSTF (ALL FDST MODES)
LDFPS (ALL SRC MODES)
LDCIF AND LDCLF
LDCID AND LDCLD
LDEXP
STFPS (ALL DST MODES)
STCFL AND STCFI
STCDL AND STCDI
STEXP
STST (DST MODE 1)

2.0 REQUIREMENTS

=====

2.1 HARDWARE

=====

LSI 11/23 CPU WITH A MINIMUM OF 16K MEMORY.
 CONSOLE TERMINAL.
 XXDP (OR XXDP+) SYSTEM DEVICE AND DIAGNOSTIC MEDIA.
 ONE (1) M8188 FPF11 MODULE (AND ASSOCIATED CABLE).

2.2 SOFTWARE

=====

THESE PROGRAMS ASSUME THAT THE 11/23 CPU IS FULLY OPERATIONAL.
 IF NOT (OR YOU DON'T KNOW), RUN ALL APPLICABLE 11/23 CPU
 DIAGNOSTICS.

3.0 LOADING

=====

THESE PROGRAMS ARE PROVIDED ON AN XXDP (XXDP+) MEDIA.
 USE STANDARD XXDP (XXDP+) LOADING PROCEDURES.

4.0 STARTING

=====

BOTH PROGRAMS START/RESTART AT ADDRESS 200.
 THE SWITCH REGISTER IS DISPLAYED AT START TIME, AND
 MAY BE ALTERED AS REQUIRED (SEE BELOW FOR SWR OPTIONS).

5.0 RUN TIME OPTIONS

=====

THE FOLLOWING SWITCH REGISTER OPTIONS ARE SUPPORTED:

SWITCH	OCTAL	FUNCTION
15	100000	HALT ON ERROR
14	040000	LOOP ON CURRENT TEST
13	020000	INHIBIT ERROR PRINTOUT
12	010000	PRINT TEST NUMBERS
11	004000	INHIBIT ITERATIONS (NA)
10	002000	RING BELL ON ERROR
09	001000	LOOP ON ERROR
08	000400	LOOP ON TEST IN SWR<6:0>
07	000200	RESERVED FOR LOGIC ANALYZER
06:00	0000NN	TEST NUMBER (FOR SWR<8>)

THE SWITCH REGISTER MAY BE ALTERED ON-THE-FLY BY TYPING
 CONTROL G <^G>. THE PROGRAM WILL DISPLAY THE CURRENT
 SWITCH SETTINGS AND WAIT FOR A NEW ONE. IF NO CHANGE,
 JUST TYPE A <CR> TO CONTINUE ON USING THE CURRENT SWITCHES.

6.0 ERROR HANDLING

=====

ALL ERRORS ARE REPORTED ON THE CONSOLE DEVICE AS THEY OCCUR (UNLESS INHIBITED), FOLLOWED BY RECOVERY ACTION AS DICTATED BY THE CURRENT SWITCH REGISTER SETTING.

NOTE THAT ERROR ANALYSIS ASSUMES A SINGLE FAULT CONDITION IN THE FPF11. MULTIPLE FAULTS MAY CAUSE MISLEADING ERROR SIGNATURES.

7.0 RESTRICTIONS

=====

NONE

8.0 MISCELLANEOUS

=====

8.1 EXECUTION TIME

=====

THE FOLLOWING ARE TYPICAL EXECUTION TIMES:

PART 1 -- 5 SECONDS PER PASS.

PART 2 -- 2 SECONDS PER PASS.

8.2 ACT, APT, XXDP, AND XXDP+ COMPATABILITY

=====

THESE PROGRAMS WERE ASSEMBLED USING THE TRADITIONAL SYSMAC MACRO PACKAGE AND AS SUCH, ARE FULLY COMPATABLE WITH ACT AND APT, AND ARE CHAINABLE UNDER THE XXDP MONITOR.

THEY ARE ALSO COMPATABLE WITH THE XXDP+ MONITOR, BUT NOT (REPEAT -- NOT) WITH THE XXDP+/APT SYSTEM.

8.3 EXPANSION HOOKS

=====

POSSIBLE FUTURE EXPANSION MAY INVOLVE THE ADDITION OF SOME CODE FOR SET-UP AND INITIALIZATION OF A PROGRAMMABLE LOGIC ANALYZER. A BLOCK OF MEMORY AND SWITCH REGISTER BIT 7 ARE RESERVED FOR THIS PURPOSE.

9.0 TEST DESCRIPTION (PART 1).

=====

9.1 TEST 1 -- LDFPS, STFPS, (SRC/DST MODE 0), AND DATA PATHS.

=====

THIS IS A TEST OF THE LDFPS (LOAD FP STATUS) AND STFPS (STORE FP STATUS) INSTRUCTIONS. A COUNT PATTERN IS GENERATED AND RUN THROUGH THE FLOATING POINT STATUS REGISTER. THIS WILL TEST THE 16-BIT TRI STATE BUS WHICH CONNECTS THE CPU WITH THE FPP AND ALSO RJNS INTERNALLY WITHIN THE FPP. SRC/DST MODE 0 IS USED. NOTE THAT BITS 12 AND 13 ARE UNUSED IN FPS AND ARE MASKED OFF.

TO PREVENT LOCKING OUT THE COMPLETION OF THE TEST BECAUSE OF AN EXCESSIVE NUMBER OF ERRORS, ONLY THE FIRST FIVE ERRORS WILL BE REPORTED THEN THE TEST WILL BE COMPLETED AND AN ERROR SUMMARY GIVEN, AS FOLLOWS:

A DYNAMIC RECORD OF THE LOGICAL 'AND' AND 'OR' OF THE FAILING DATA PATTERNS IS KEPT. THESE CAN BE VERY USEFUL IN DETERMINING STUCK BITS. WHEN THE TEST COMPLETES, THIS SUMMARY IS PRINTED IF ANY ERRORS WERE ENCOUNTERED.

9.2 TEST 2 -- COPY CONDITION CODES (CFCC).

=====

THIS IS A TEST OF THE COPY CONDITION CODES INSTRUCTION. INSURE THAT ONLY PSW<3:0> ARE AFFECTED BY THE CFCC, AND THAT THE FP STATUS REGISTER IS UNALTERED. NOTE: THE CPU IS IN 'USER MODE' DURING THIS TEST.

9.3 TEST 3 -- MODE SETUP (SETF, SETD, SETI, AND SETL).

=====

THIS IS A TEST OF THE SETF, SETD, SETI AND SETL INSTRUCTIONS. EACH INSTRUCTION IS EXECUTED WITH THE FPS CLEAR, AND THEN AGAIN WITH THE FPS CONTAINING ALL 1'S (147777). THE RESULTING FPS IS CHECKED IN EACH CASE.

9.4 TEST 4 -- ILLEGAL FP OP-CODE TRAP AND STST (DST MODE 0).

=====

THIS IS A TEST OF THE ILLEGAL FP OP-CODE TRAP FUNCTION. FP OPCODES 170003 THRU 170010 AND 170013 THRU 170077 ARE ILLEGAL (INVALID) AND SHOULD CAUSE A TRAP TO 244 (WHEN INTERRUPTS ARE ENABLED). WHEN ANY OF THE ABOVE OPCODES TRAP, THE FEC REGISTER SHOULD BE SET TO CODE 2, TO INDICATE AN OPCODE ERROR.

- 9.5 TEST 5 -- FP INTERRUPT DISABLE BIT (FID).
 =====
 THIS IS A TEST OF THE INTERRUPT DISABLE (FID) BIT.
 AN ILLEGAL INSTRUCTION IS EXECUTED WITH FID = 1.
 NO INTERRUPT SHOULD OCCUR.
- 9.6 TEST 6 -- LDD AND STD (FSRC MODE 1).
 =====
 THIS IS A TEST OF THE LOAD AND STORE DOUBLE INSTRUCTIONS.
 LDD (R0),ACO
 STD (ACO),(R0)
- 9.7 TEST 7 -- LDD AND LDF (FSRC MODE 0).
 =====
 THIS IS A TEST OF THE FSRC MODE 0, USING THE INSTRUCTIONS
 LDD AC1,ACO
 LDF AC1,ACO
- 9.10 TEST 10 -- STD AND STF (FDST MODE 0).
 =====
 THIS IS A TEST OF THE STORE INSTRUCTIONS, STD AND STF.
- 9.11 TEST 11 -- ACCUMULATORS WITH FLOATING DATA PATTERNS.
 =====
 THIS IS A TEST OF THE FLOATING POINT PROCESSOR ACCUMULATORS.
 EACH ACCUMULATOR IS TESTED IN TWO WAYS:
 1. A TEST PATTERN GENERATED BY FLOATING A ONE ACROSS
 A FIELD OF ZEROES.
 2. A TEST PATTERN GENERATED BY FLOATING A ZERO ACROSS
 A FIELD OF ONES.
 EACH OF ACCUMULATORS ACO THROUGH AC5 IS TESTED.
 NOTE THAT ACO IS USED TO ACCESS AC4 AND AC5.
- 9.12 TEST 12 -- ACCUMULATORS DUAL ADDRESSING.
 =====
 THIS TEST PERFORMS A DUAL ADDRESSING TEST ON THE ACCUMULATORS.
 NOTE THAT ACCUMULATOR ZERO IS USED TO ACCESS ALL THE OTHERS.
- 9.13 TEST 13 -- LDD AND ADD (FSRC MODE 0) USING AN ILLEGAL AC.
 =====
 THIS IS A TEST OF FSRC MODE 0 WITH ACCUMULATORS 6 AND 7.
 ANY ATTEMPT TO ACCESS EITHER AC6 OR AC7 SHOULD CAUSE A TRAP
 TO VECTOR 244, WITH FEC = 2 (ILLEGAL FPP INSTRUCTION).

- 9.14 TEST 14 -- LDD (FSRC MODE 2) AUTO-INCREMENT.
=====
- THIS IS A TEST OF FSRC MODE 2, AUTO-INCREMENT MODE.
- 9.15 TEST 15 -- LDD (FSRC MODE 4) AUTO-DECREMENT.
=====
- THIS IS A TEST OF FSRC MODE 4, AUTO-DECREMENT MODE.
- 9.16 TEST 16 -- LDF (FSRC MODE 2) AUTO-INCREMENT.
=====
- THIS IS A TEST OF FSRC MODE 2 (AUTO-INCREMENT) IN SINGLE PRECISION MODE (FD=0).
- 9.17 TEST 17 -- LDD (FSRC MODE 2 WITH R7) PC IMMEDIATE.
=====
- THIS IS A TEST OF FSRC MODE 2 USING GR7 (PC). THIS IS THE "IMMEDIATE" MODE.
- 9.20 TEST 20 -- LDD (FSRC MODE 3) AUTO-INCREMENT DEFERRED.
=====
- THIS IS A TEST OF FSRC MODE 3, AUTO INCREMENT DEFERRED.
- 9.21 TEST 21 -- LDD (FSRC MODE 5) AUTO-DECREMENT DEFERRED.
=====
- THIS IS A TEST OF FSRC MODE 5, AUTO DECREMENT DEFERRED.
- 9.22 TEST 22 -- LDD (FSRC MODE 6) INDEXED.
=====
- THIS IS A TEST OF FSRC MODE 6, INDEX MODE
- 9.23 TEST 23 -- LDD (FSRC MODE 7) INDEX DEFERRED.
=====
- THIS IS A TEST OF FSRC MODE 7, INDEX DEFERRED.
- 9.24 TEST 24 -- LDD AND TEST THE FZ, FN, AND FIUV BUTS.
=====
- THIS IS A TEST OF THE (BUT EZBT Y8) FORK, THE (BUT ENBT) FORK AND (BUT FIUV) FORK IN THE LOAD INSTRUCTION FLOWS. EACH OF THE PATTERNS 0, +NUM, -NUM AND -0 IS LOADED TWICE FIRST WITH INITIAL AC <> 0 AND AGAIN WITH AC = 0. THE FPS IS VERIFIED AFTER EACH LOAD FUNCTION.

- 9.25 TEST 25 -- ADDD/SUBD (FSRC MODE 1), BOTH OPERANDS = 0.
 =====
 THIS IS A TEST OF ADD AND SUB WITH BOTH OPERANDS = 0.
 $0 + 0 = 0$ (HOPEFULLY)
- 9.26 TEST 26 -- ADDD/SUBD (FSRC MODE 1), FSRC OPERAND = 0.
 =====
 THIS IS A TEST OF ADDD AND SUBD WITH JUST THE SRC = 0.
 $N + 0 = N$
 $N - 0 = N$
- 9.27 TEST 27 -- SUBD (FSRC MODE 1), FDST OPERAND = 0.
 =====
 THIS IS A TEST OF THE SUBD WITH THE DST OPERAND = 0.
 BOTH POSITIVE AND NEGATIVE SRC OPERANDS ARE TRIED.
 $0 - (+N) = -N$
 $0 - (-N) = +N$
- 9.30 TEST 30 -- ADDD (FSRC MODE 1), FDST OPERAND = 0.
 =====
 THIS IS A TEST OF THE ADDD WITH THE DST OPERAND = 0.
 BOTH POSITIVE AND NEGATIVE SRC OPERANDS ARE TRIED.
 $0 + (+N) = +N$
 $0 + (-N) = -N$
- 9.31 TEST 31 -- ADDD/ADDF, EQUAL EXPONENTS, AND ROUND/TRUNK (BUT FT).
 =====
 THIS IS A TEST OF THE ADD INSTRUCTIONS WITH THE OPERANDS
 HAVING EQUAL EXPONENTS (ALIGNMENT NOT REQUIRED).
 THE ROUND/TRUNCATE FLOW (BUT FT) IS ALSO TESTED HERE.
- 9.32 TEST 32 -- ADDD/ADDF, ALIGN WITH E(AC) LESS THAN E(FSRC).
 =====
 THIS IS A TEST OF THE ADDD AND ADDF INSTRUCTIONS
 AND THE ALIGN FDST EXPONENT ALGORITHM.
 THE ALIGNMENT CONSTANTS 25 FOR FLOATING, AND 57 FOR DOUBLE
 ARE VERIFIED.
 NOTE THAT E(AC) IS LESS THAN E(SRC) SO THE OPERAND IN AC
 (FDST) IS THE ONE TO BE ALIGNED.

- 9.33 TEST 33 -- ADDD/ADDF, ALIGN WITH E(AC) GREATER THAN E(FSRC).
 =====
 THIS IS A TEST OF THE ADDD AND ADDF INSTRUCTIONS
 AND THE ALIGN FSRC EXPONENT ALGORITHM.
 THIS IS THE SAME AS PRECEDING TEST EXCEPT THAT
 E(AC) IS GREATER THAN E(FSRC) SO THE FSRC OPERAND
 IS THE ONE TO BE ALIGNED.
- 9.34 TEST 34 -- ADDD USING POSITIVE AND NEGATIVE OPERANDS.
 =====
 THIS IS A TEST OF THE ADDD INSTRUCTION USING BOTH
 POSITIVE AND NEGATIVE OPERANDS.
- 9.35 TEST 35 -- SUBD USING POSITIVE AND NEGATIVE OPERANDS.
 =====
 THIS IS A TEST OF THE SUBD INSTRUCTION USING VARIOUS OPERANDS.
- 9.36 TEST 36 -- ADDD/SUBD AND CHECK FINAL NORMALIZATION.
 =====
 TEST THAT THE RESULTS OF AN ADD OR SUBTRACT ARE
 PROPERLY NORMALIZED IN ACO.
 DATA IS SELECTED TO TEST TWO CASES.
 FIRST THE MINIMUM SITUATION REQUIRING ONE
 LEFT SHIFT AND THEN THE MAXIMUM SITUATION
 REQUIRING 56 SHIFTS.
- 9.37 TEST 37 -- ADDD AND CHECK ROUND AND TRUNCATE.
 =====
 THIS IS A TEST OF THE ROUND AND TRUNCATE FLOWS.
 IN PARTICULAR TWO THINGS ARE TESTED:
 FIRST A CONDITION IN WHICH ROUNDING RESULTS
 IN THE NEED FOR RENORMALIZATION, AND
 SECOND, THAT THE FPS CONDITION CODES (N AND Z BITS)
 ARE CORRECTLY SET IN VARIOUS COMBINATIONS.
- 9.40 TEST 40 -- ADDD AND CHECK OVERFLOW AND UNDERFLOW.
 =====
 TEST THAT THE OVERFLOW/UNDERFLOW ALGORITHM CAN CORRECTLY
 DETECT THOSE CONDITIONS AND TAKE THE APPROPRIATE ACTION.
 EACH CONDITION IS TESTED TWICE, ONCE WITH TRAPS
 ENABLED (FIU AND FIV = 1), AND AGAIN WITH TRAPS
 DISABLED (FIU AND FIV = 0).
 WHEN TRAPS ARE ENABLED, THE RETURNED FEC IS ALSO TESTED.

- 9.41 TEST 41 -- LDCFD AND LDCDF (FSRC MODE 2).
=====
- TESTS THE LOAD CONVERTED FUNCTIONS.
- 9.42 TEST 42 -- CMPD (FSRC MODE 1).
=====
- TEST THE CMPD INSTRUCTION WITH A VARIETY OF OPERANDS.
A COMMON SUBROUTINE IS USED TO SET UP OPERANDS, EXECUTE THE
INSTRUCTION, AND CHECK THE RESULTS.
NOTE THAT ON ERROR, THE 'ERROR PC' REPORTED IS THE PC OF THE
OPERAND SET WHICH RESULTED IN THE ERROR AND NOT THAT OF THE
OFFENDING INSTRUCTION ITSELF.
- 9.43 TEST 43 -- DIVD (FSRC MODE 1), WITH DIVISOR = 0.
=====
- THIS IS A TEST OF THE DIVD INSTRUCTION WITH A
ZERO DIVISOR. THE CONDITION IS CHECKED WITH BOTH
TRAP ENABLED AND TRAPS DISABLED.
- 9.44 TEST 44 -- DIVF (FSRC MODE 1).
=====
- TEST THE DIVF INSTRUCTION WITH A VARIETY OF OPERANDS.
A COMMON SUBROUTINE IS USED TO SET UP OPERANDS, EXECUTE THE
INSTRUCTION, AND CHECK THE RESULTS.
NOTE THAT ON ERROR, THE 'ERROR PC' REPORTED IS THE PC OF THE
OPERAND SET WHICH RESULTED IN THE ERROR AND NOT THAT OF THE
OFFENDING INSTRUCTION ITSELF.
- 9.45 TEST 45 -- DIVD (FSRC MODE 1).
=====
- TEST THE DIVD INSTRUCTION WITH A VARIETY OF OPERANDS.
A COMMON SUBROUTINE IS USED AS DESCRIBED ABOVE.
- 9.46 TEST 46 -- MULF (FSRC MODE 1).
=====
- TEST THE MULF INSTRUCTION WITH A VARIETY OF OPERANDS.
A COMMON SUBROUTINE IS USED AS DESCRIBED ABOVE.
- 9.47 TEST 47 -- MULD (FSRC MODE 1).
=====
- TEST THE MULD INSTRUCTION WITH A VARIETY OF OPERANDS.
A COMMON SUBROUTINE IS USED AS DESCRIBED ABOVE.

9.50 TEST 50 -- MODF (FSRC MODE 1).

=====
THIS IS A TEST OF THE MODF INSTRUCTION.
A COMMON SUBROUTINE IS USED AS DESCRIBED ABOVE.

9.51 TEST 51 -- MODD (FSRC MODE 1).

=====
THIS IS A TEST OF THE MODD INSTRUCTION.
A COMMON SUBROUTINE IS USED AS DESCRIBED ABOVE.

10.0 PROGRAM LISTING

=====
THE PROGRAM LISTING FOLLOWS:

79	BASIC DEFINITIONS
100	TRAP CATCHER
(1)	STARTING ADDRESS(ES)
104	OPERATIONAL SWITCH SETTINGS
108	ACT11 HOOKS
110	APT PARAMETER BLOCK
112	COMMON TAGS
(2)	APT MAILBOX-ETABLE
(1)	ERROR POINTER TABLE
128	INITIALIZE THE COMMON TAGS
139	GET VALUE FOR SOFTWARE SWITCH REGISTER
149	COMMON SUBROUTINES
208	
209	FPF PART 1 TESTS
210	
232	T1 LDFPS, STFPS, AND DATA PATHS -- SRC AND DST MODE 0
286	T2 COPY CONDITION CODES
326	T3 SETF, SETD, SETI, AND SETL
392	T4 ILLEGAL FPP OP-CODE TRAP, AND STST -- DST MODE 0
445	T5 INTERRUPT DISABLE (FID) BIT
492	T6 LDD AND STD -- FSRC AND FDST MODE 1
688	T7 LDD AND LDF -- FSRC MODE 0
837	T10 STD AND STF -- FDST MODE 0
982	T11 ACCUMULATORS -- DATA PATTERNS
1078	T12 ACCUMULATORS -- DUAL ADDRESSING
1216	T13 LDD AND ADD -- FSRC MODE 0, WITH ILLEGAL ACCUMULATOR
1299	T14 LDD -- FSRC MODE 2 (AUTO-INCREMENT)
1356	T15 LDD -- FSRC MODE 4 (AUTO-DECREMENT)
1413	T16 LDF -- FSRC MODE 2 (AUTO-INCREMENT)
1469	T17 LDD -- FSRC MODE 2 WITH GR7 (PC IMMEDIATE)
1529	T20 LDD -- FSRC MODE 3 (AUTO-INCR DEFERRED)
1624	T21 LDD -- FSRC MODE 5 (AUTO-DECR DEFERRED)
1720	T22 LDD -- FSRC MODE 6 (INDEX)
1805	T23 LDD -- FSRC MODE 7 (INDEX DEFERRED)
1903	T24 TEST FZ, FN, AND FIUV BITS USING LDD
1996	T25 ADD AND SUB -- FSRC MODE 1, WITH BOTH OPERANDS = 0
2076	T26 ADD AND SUBD -- FSRC MODE 1, WITH SRC OPERAND = 0
2161	T27 SUBD -- FSRC MODE 1, WITH DST OPERAND = 0
2210	T30 ADD -- FSRC MODE 1, WITH DST OPERAND = 0
2257	T31 ADD AND ADDF (EPOXNENTS EQUAL), AND ROUND\TRUNK (BUT FT)
2369	T32 ADDF AND ADD WITH E(AC) LESS THAN E(FSRC)
2529	T33 ADDF AND ADD WITH E(AC) GREATER THAN E(FSRC)
2716	T34 ADD WITH POSITIVE AND NEGATIVE OPERANDS
2873	T35 SUBD WITH POSITIVE AND NEGATIVE OPERANDS
2974	T36 TEST NORMALIZE FLOW USING ADD AND SUBD
3085	T37 TEST ROUND\TRUNCATE USING ADD
3245	T40 TEST OVERFLOW\UNDERFLOW USING ADD
3408	T41 LDCFD AND LDCDF -- FSRC MODE 2
3555	T42 CMPD -- FSRC MODE 1
3729	T43 DIVD -- FSRC MODE 1, WITH DIVISOR = 0
3845	T44 DIVF -- FSRC MODE 1
4016	T45 DIVD -- FSRC MODE 1
4168	T46 MULF -- FSRC MODE 1
4353	T47 MJLD -- FSRC MODE 1
4485	T50 MODF -- FSRC MODE 1
4688	T51 MODD -- FSRC MODE 1

4929	
4930	END OF PASS ROUTINE
4932	SCOPE HANDLER ROUTINE
4962	TYPE ROUTINE
4975	GET VALUE FOR SOFTWARE SWITCH REGISTER
4979	BINARY TO OCTAL (ASCII) AND TYPE
4981	CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
4993	APT COMMUNICATIONS ROUTINE
4995	TTY INPUT ROUTINE
4997	TRAP DECODER
(3)	TRAP TABLE
5025	POWER DOWN AND UP ROUTINES
5027	ERROR HANDLER ROUTINE
5029	ERROR TYPE OUT ROUTINE
5132	ASCII TEXT AND ERROR MESSAGES.
5739	AREA RESERVED FOR LOGIC ANALYZER SET-UP CODE (NOT INCLUDED).

- 1
- 2
- 3
- 4
- 5
- 10
- 11
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- 12
- 13
- 14
- 15
- 16
- 17
- 18
- 19
- 20
- 21
- 22
- 23
- 24
- 28
- 37
- 45
- 57
- 67
- 77
- 78
- 79
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)
- (1)

```
.LIST ME
.NLIST MD,MC,CND

.ENABL ABS,AMA

.TITLE CJFPAA -- LSI11/23 FPF11 DIAGNOSTIC, PART 1
*COPYRIGHT (C) NOV 1980
*DIGITAL EQUIPMENT CORP.
*MAYNARD, MASS. 01754
*
*PROGRAM BY DIAG ENGINEERING
*
*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
*PACKAGE (MAINDEC- 1-DZQAC-C4), 31 JULY 1980.
*
$TN=1
$SWR=160000 ;:HALT ON ERROR, LOOP ON TEST, INHIBIT ERROR TYP0UT
*
* THESE PROGRAMS WERE ADAPTED FROM THE ORIGINAL 11/34 FP11-A
* DIAGNOSTICS WRITTEN BY ANTHONY S. VEZZA IN SEPTEMBER '76.
*
* FPF PART 1 INCLUDES ALL TESTS FOUND IN FP11-A, PARTS 1 AND 2.
* FPF PART 2 INCLUDES ALL TESTS FOUND IN FP11-A, PART 3.
* ERROR ANALYSIS AND REPORTING HAS BEEN REWORKED TO ACCOMMODATE
* THE 11/23 FPF11 MICROCODE AND MAINTENANCE PHILOSOPHY.
*
G.P. JAN '80
*
PRGSIz= ^H<LASTAD> ; PROGRAM SIZE IN 1/8 K UNITS (OCTAL).
:*****
.

.*****
.SBTTL BASIC DEFINITIONS

*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
.EQUIV EMT,ERROR ;:BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE ;:BASIC DEFINITION OF SCOPE CALL

*MISCELLANEOUS DEFINITIONS
HT= 11 ;:CODE FOR HORIZONTAL TAB
LF= 12 ;:CODE FOR LINE FEED
CR= 15 ;:CODE FOR CARRIAGE RETURN
CRLF= 200 ;:CODE FOR CARRIAGE RETURN-LINE FEED
PS- 177776 ;:PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLMT- 177774 ;:STACK LIMIT REGISTER
PIRQ- 177772 ;:PROGRAM INTERRUPT REQUEST REGISTER
DSWR- 177570 ;:HARDWARE SWITCH REGISTER
DDISP= 177570 ;:HARDWARE DISPLAY REGISTER
```

000001
160000

000142

001100

000011
000012
000015
000200
177776
177774
177772
177570
177570

```

(1)
(1)          ;*GENERAL PURPOSE REGISTER DEFINITIONS
(1)          000000 R0=  %0          ;;GENERAL REGISTER
(1)          000001 R1=  %1          ;;GENERAL REGISTER
(1)          000002 R2=  %2          ;;GENERAL REGISTER
(1)          000003 R3=  %3          ;;GENERAL REGISTER
(1)          000004 R4=  %4          ;;GENERAL REGISTER
(1)          000005 R5=  %5          ;;GENERAL REGISTER
(1)          000006 R6=  %6          ;;GENERAL REGISTER
(1)          000007 R7=  %7          ;;GENERAL REGISTER
(1)          000006 SP=  %6          ;;STACK POINTER
(1)          000007 PC=  %7          ;;PROGRAM COUNTER
(1)
(1)          ;*PRIORITY LEVEL DEFINITIONS
(1)          000000 PR0=  0          ;;PRIORITY LEVEL 0
(1)          000040 PR1=  40         ;;PRIORITY LEVEL 1
(1)          000100 PR2=  100        ;;PRIORITY LEVEL 2
(1)          000140 PR3=  140        ;;PRIORITY LEVEL 3
(1)          000200 PR4=  200        ;;PRIORITY LEVEL 4
(1)          000240 PR5=  240        ;;PRIORITY LEVEL 5
(1)          000300 PR6=  300        ;;PRIORITY LEVEL 6
(1)          000340 PR7=  340        ;;PRIORITY LEVEL 7
(1)
(1)          ;*'SWITCH REGISTER' SWITCH DEFINITIONS
(1)          100000 SW15= 100000
(1)          040000 SW14= 40000
(1)          020000 SW13= 20000
(1)          010000 SW12= 10000
(1)          004000 SW11= 4000
(1)          002000 SW10= 2000
(1)          001000 SW09= 1000
(1)          000400 SW08= 400
(1)          000200 SW07= 200
(1)          000100 SW06= 100
(1)          000040 SW05= 40
(1)          000020 SW04= 20
(1)          000010 SW03= 10
(1)          000004 SW02= 4
(1)          000002 SW01= 2
(1)          000001 SW00= 1
(1)          .EQUIV SW09,SW9
(1)          .EQUIV SW08,SW8
(1)          .EQUIV SW07,SW7
(1)          .EQUIV SW06,SW6
(1)          .EQUIV SW05,SW5
(1)          .EQUIV SW04,SW4
(1)          .EQUIV SW03,SW3
(1)          .EQUIV SW02,SW2
(1)          .EQUIV SW01,SW1
(1)          .EQUIV SW00,SW0
(1)
(1)          ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
(1)          100000 BIT15= 100000
(1)          040000 BIT14= 40000
(1)          020000 BIT13= 20000
(1)          010000 BIT12= 10000

```



```

(1)      004000      BIT11= 4000
(1)      002000      BIT10= 2000
(1)      001000      BIT09= 1000
(1)      000400      BIT08= 400
(1)      000200      BIT07= 200
(1)      000100      BIT06= 100
(1)      000040      BIT05= 40
(1)      000020      BIT04= 20
(1)      000010      BIT03= 10
(1)      000004      BIT02= 4
(1)      000002      BIT01= 2
(1)      000001      BIT00= 1
(1)      .EQUIV BIT09,BIT9
(1)      .EQUIV BIT08,BIT8
(1)      .EQUIV BIT07,BIT7
(1)      .EQUIV BIT06,BIT6
(1)      .EQUIV BIT05,BIT5
(1)      .EQUIV BIT04,BIT4
(1)      .EQUIV BIT03,BIT3
(1)      .EQUIV BIT02,BIT2
(1)      .EQUIV BIT01,BIT1
(1)      .EQUIV BIT00,BIT0
(1)      ;*BASIC 'CPU' TRAP VECTOR ADDRESSES
(1)      000004      ERRVEC= 4      ;;TIME OUT AND OTHER ERRORS
(1)      000010      RESVEC= 10     ;;RESERVED AND ILLEGAL INSTRUCTIONS
(1)      000014      TBITVEC=14     ;;'T' BIT
(1)      000014      TRTVEC= 14     ;;TRACE TRAP
(1)      000014      BPTVEC= 14     ;;BREAKPOINT TRAP (BPT)
(1)      000020      IOTVEC= 20     ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
(1)      000024      PWRVEC= 24     ;;POWER FAIL
(1)      000030      EMTVEC= 30     ;;EMULATOR TRAP (EMT) **ERROR**
(1)      000034      TRAPVEC=34     ;;'TRAP' TRAP
(1)      000060      TKVEC= 60      ;;TTY KEYBOARD VECTOR
(1)      000064      TPVEC= 64      ;;TTY PRINTER VECTOR
(1)      000240      PIRQVEC=240    ;;PROGRAM INTERRUPT REQUEST VECTOR
80      ;
81      ; FPF-11 DEFINITIONS.
82      ;
83      000244      FPVEC= 244      ; THE STANDARD FP VECTOR...
84      000000      AC0= %0         ;...AND ACCUMULATORS.
85      000001      AC1= %1
86      000002      AC2= %2
87      000003      AC3= %3
88      000004      AC4= %4
89      000005      AC5= %5
90      000006      AC6= %6
91      000007      AC7= %7
92      ;
93      ; MISCELLANEOUS DEFINITIONS.
94      ;
95      000011      TAB= HT
96      000401      SKP1= BR+1
97      000402      SKP2= BR+2
98      000403      SKP3= BR+3
99
    
```

```

100      .SBTTL TRAP CATCHER
(1)
(1)      000000      .=0
(1)      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A '+2,HALT'
(1)      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
(1)      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
(1)      000174      .=174
(1) 000174 000000  DISPRFG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
(1) 000176 000000  SWREG:   .WORD 0      ;;SOFTWARE SWITCH REGISTER
(1)      .SBTTL STARTING ADDRESS(ES)
(1) 000200 000137 003542  JMP      @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM
101
102      167400      $$SWR= 167400      ; RE-DEFINE SWITCH 12.
103      000200      $$SWRMK- 000200      ; RE-DEFINE TEST NUMBER FIELD.
104      .SBTTL OPERATIONAL SWITCH SETTINGS
(1)      ;*
(1)      ;*      SWITCH      USE
(1)      ;*      -----
(1)      ;*      15      HALT ON ERROR
(1)      ;*      14      LOOP ON TEST
(1)      ;*      13      INHIBIT ERROR TYPEOUTS
(1)      ;*      12      PRINT TEST NUMBERS
(1)      ;*      11      INHIBIT ITERATIONS
(1)      ;*      10      BELL ON ERROR
(1)      ;*      9      LOOP ON ERROR
(1)      ;*      8      LOOP ON TEST IN SWR<6:0>
105      ;*      7      ENABLE ANALYZER (RESERVED)
106
107      001000      .=1000
108      .SBTTL ACT11 HOOKS
(1)
(2)      ;*****
(1)      ;HOOKS REQUIRED BY ACT11
(1)      001000      $SVPC=.      ;SAVE PC
(1)      000046      .=46
(1) 000046 037464  $ENDAD      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
(1)      000052      .=52
(1) 000052 000000  .WORD 0      ;;2)SET LOC.52 TO ZERO
(1)      001000      .= $SVPC      ;; RESTORE PC
109
110      .SBTTL APT PARAMETER BLOCK
(1)
(2)      ;*****
(1)      ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
(2)      ;*****
(1)      001000      .$X=.      ;;SAVE CURRENT LOCATION
(1)      000024      .=24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
(1) 000024 000200  200      ;;FOR APT START UP
(1)      000044      .=44      ;;POINT TO APT INDIRECT ADDRESS PNTR.
(1) 000044 001000  $APTHDR ;;POINT TO APT HEADER BLOCK
(1)      001000      .=.$X      ;;RESET LOCATION COUNTER
(2)      ;*****
(1)      ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
(1)      ;INTERFACE SPEC.
(1)
(1) 001000  $APTHD:
    
```

(1)	001000	000000	\$HIBTS: .WORD	0	::TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
(1)	001002	001234	\$MBADR: .WORD	\$MAIL	::ADDRESS OF APT MAILBOX (BITS 0-15)
(1)	001004	000005	\$STSM: .WORD	5	::RUN TIM OF LONGEST TEST
(1)	001006	000010	\$PASTM: .WORD	10	::RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
(1)	001010	000000	\$UNITM: .WORD	0	::ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
(1)	001012	000027	.WORD	\$ETEND-\$MAIL/2	::LENGTH MAILBOX-ETABLE (WORDS)

111

```

112          .SBTTL COMMON TAGS
(1)
(2)          ::*****
(1)          :*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
(1)          :*USED IN THE PROGRAM.
(1)
(1)          001100          .=1100
(1) 001100          000000          $CMTAG:          ;;START OF COMMON TAGS
(1) 001102          000          $TSTNM: .BYTE 0          ;;CONTAINS THE TEST NUMBER
(1) 001103          000          $ERFLG: .BYTE 0          ;;CONTAINS ERROR FLAG
(1) 001104          000000          $ICNT: .WORD 0          ;;CONTAINS SUBTEST ITERATION COUNT
(1) 001106          000000          $LPADR: .WORD 0          ;;CONTAINS SCOPE LOOP ADDRESS
(1) 001110          000000          $LPERR: .WORD 0          ;;CONTAINS SCOPE RETURN FOR ERRORS
(1) 001112          000000          $ERTTL: .WORD 0          ;;CONTAINS TOTAL ERRORS DETECTED
(1) 001114          000          $ITEMB: .BYTE 0          ;;CONTAINS ITEM CONTROL BYTE
(1) 001115          001          $ERMAX: .BYTE 1          ;;CONTAINS MAX. ERRORS PER TEST
(1) 001116          000000          $ERRPC: .WORD 0          ;;CONTAINS PC OF LAST ERROR INSTRUCTION
(1) 001120          000000          $GDADR: .WORD 0          ;;CONTAINS ADDRESS OF 'GOOD' DATA
(1) 001122          000000          $BDADR: .WORD 0          ;;CONTAINS ADDRESS OF 'BAD' DATA
(1) 001124          000000          $GDDAT: .WORD 0          ;;CONTAINS 'GOOD' DATA
(1) 001126          000000          $BDDAT: .WORD 0          ;;CONTAINS 'BAD' DATA
(1) 001130          000000          .WORD 0          ;;RESERVED--NOT TO BE USED
(1) 001132          000000          .WORD 0
(1) 001134          000          $AUTOB: .BYTE 0          ;;AUTOMATIC MODE INDICATOR
(1) 001135          000          $INTAG: .BYTE 0          ;;INTERRUPT MODE INDICATOR
(1) 001136          000000          .WORD 0
(1) 001140          177570          $SWR: .WORD DSWR          ;;ADDRESS OF SWITCH REGISTER
(1) 001142          177570          $DISPLAY: .WORD DDISP          ;;ADDRESS OF DISPLAY REGISTER
(1) 001144          177560          $TKS: 177560          ;;TTY KBD STATUS
(1) 001146          177562          $TKB: 177562          ;;TTY KBD BUFFER
(1) 001150          177564          $TPS: 177564          ;;TTY PRINTER STATUS REG. ADDRESS
(1) 001152          177566          $TPB: 177566          ;;TTY PRINTER BUFFER REG. ADDRESS
(1) 001154          000          $NULL: .BYTE 0          ;;CONTAINS NULL CHARACTER FOR FILLS
(1) 001155          002          $FILLS: .BYTE 2          ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
(1) 001156          012          $FILLC: .BYTE 12          ;;INSERT FILL CHARS. AFTER A 'LINE FEED'
(1) 001157          000          $TPFLG: .BYTE 0          ;;'TERMINAL AVAILABLE' FLAG (BIT<07>-0 YES)
(3) 001160          000000          $TMP0: .WORD 0          ;;USER DEFINED
(3) 001162          000000          $TMP1: .WORD 0          ;;USER DEFINED
(3) 001164          000000          $TMP2: .WORD 0          ;;USER DEFINED
(3) 001166          000000          $TMP3: .WORD 0          ;;USER DEFINED
(3) 001170          000000          $TMP4: .WORD 0          ;;USER DEFINED
(3) 001172          000000          $TMP5: .WORD 0          ;;USER DEFINED
(3) 001174          000000          $TMP6: .WORD 0          ;;USER DEFINED
(3) 001176          000000          $TMP7: .WORD 0          ;;USER DEFINED
(3) 001200          000000          $TMP10: .WORD 0          ;;USER DEFINED
(3) 001202          000000          $TMP11: .WORD 0          ;;USER DEFINED
(3) 001204          000000          $TMP12: .WORD 0          ;;USER DEFINED
(3) 001206          000000          $TMP13: .WORD 0          ;;USER DEFINED
(3) 001210          000000          $TMP14: .WORD 0          ;;USER DEFINED
(3) 001212          000000          $TMP15: .WORD 0          ;;USER DEFINED
(3) 001214          000000          $TMP16: .WORD 0          ;;USER DEFINED
(3) 001216          000000          $TMP17: .WORD 0          ;;USER DEFINED
(1) 001220          000000          $TIMES: 0          ;;MAX. NUMBER OF ITERATIONS
(1) 001222          000000          $ESCAPE: 0          ;;ESCAPE ON ERROR ADDRESS
(1) 001224          177607          $BELL: .ASCII <207><377><377>          ;;CODE FOR BELL
    000377
    
```

```

(1) 001230 077 $QUES: .ASCII /?/ ;;QUESTION MARK
(1) 001231 015 $CRLF: .ASCII <15> ;;CARRIAGE RETURN
(1) 001232 000012 $LF: .ASCIIZ <12> ;;LINE FEED
(2) ;;*****
(2) .SBTTL APT MAILBOX-ETABLE
(2) ;;*****
(2) .EVEN
(2) 001234 $MAIL: ;;APT MAILBOX
(2) 001234 000000 $MSGTY: .WORD AMSGTY ;;MESSAGE TYPE CODE
(2) 001236 000000 $FATAL: .WORD AFATAL ;;FATAL ERROR NUMBER
(2) 001240 000000 $TESTN: .WORD ATESTN ;;TEST NUMBER
(2) 001242 000000 $PASS: .WORD APASS ;;PASS COUNT
(2) 001244 000000 $DEVCT: .WORD ADEVCT ;;DEVICE COUNT
(2) 001246 000000 $UNIT: .WORD AUNIT ;;I/O UNIT NUMBER
(2) 001250 000000 $MSGAD: .WORD AMSGAD ;;MESSAGE ADDRESS
(2) 001252 000000 $MSGLG: .WORD AMSGLG ;;MESSAGE LENGTH
(2) 001254 $ETABLE: ;;APT ENVIRONMENT TABLE
(2) 001254 000 $ENV: .BYTE AENV ;;ENVIRONMENT BYTE
(2) 001255 000 $ENVM: .BYTE AENVM ;;ENVIRONMENT MODE BITS
(2) 001256 000000 $SWREG: .WORD ASWREG ;;APT SWITCH REGISTER
(2) 001260 000000 $USWR: .WORD AUSWR ;;USER SWITCHES
(2) 001262 000000 $CPUOP: .WORD ACPUOP ;;CPU TYPE,OPTIONS
(2) ;;BITS 15-11=CPU TYPE
(2) ;; 11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
(2) ;; 11/70=06,PDQ=07,Q=10
(2) ;;BIT 10=REAL TIME CLOCK
(2) ;;BIT 9=FLOATING POINT PROCESSOR
(2) ;;BIT 8=MEMORY MANAGEMENT
(2) 001264 000 $MAMS1: .BYTE AMAMS1 ;;HIGH ADDRESS,M.S. BYTE
(2) 001265 000 $MTYP1: .BYTE AMTYP1 ;;MEM. TYPE,BLK#1
(2) ;;MEM.TYPE BYTE -- (HIGH BYTE)
(2) ;; 900 NSEC CORE=001
(2) ;; 300 NSEC BIPOLAR=002
(2) ;; 500 NSEC MOS=003
(2) 001266 000000 $MADR1: .WORD AMADR1 ;;HIGH ADDRESS,BLK#1
(2) ;;MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
(2) 001270 000 $MAMS2: .BYTE AMAMS2 ;;HIGH ADDRESS,M.S. BYTE
(2) 001271 000 $MTYP2: .BYTE AMTYP2 ;;MEM. TYPE,BLK#2
(2) 001272 000000 $MADR2: .WORD AMADR2 ;;MEM.LAST ADDRESS,BLK#2
(2) 001274 000 $MAMS3: .BYTE AMAMS3 ;;HIGH ADDRESS,M.S.BYTE
(2) 001275 000 $MTYP3: .BYTE AMTYP3 ;;MEM. TYPE,BLK#3
(2) 001276 000000 $MADR3: .WORD AMADR3 ;;MEM.LAST ADDRESS,BLK#3
(2) 001300 000 $MAMS4: .BYTE AMAMS4 ;;HIGH ADDRESS,M.S.BYTE
(2) 001301 000 $MTYP4: .BYTE AMTYP4 ;;MEM. TYPE,BLK#4
(2) 001302 000000 $MADR4: .WORD AMADR4 ;;MEM.LAST ADDRESS,BLK#4
(2) 001304 000000 $VECT1: .WORD AVECT1 ;;INTERRUPT VECTOR#1,BUS PRIORITY#1
(2) 001306 000000 $VECT2: .WORD AVECT2 ;;INTERRUPT VECTOR#2BUS PRIORITY#2
(2) 001310 000000 $BASE: .WORD ABASE ;;BASE ADDRESS OF EQUIPMENT UNDER TEST
(2) 001312 $ETEND:
(2) .MEXIT
    
```

```

(1) .SBTTL ERROR POINTER TABLE
(1)
(1) ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
(1) ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
(1) ;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
(1) ;*NOTE1: IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
(1) ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
(1)
(1) ;* EM ;:POINTS TO THE ERROR MESSAGE
(1) ;* DH ;:POINTS TO THE DATA HEADER
(1) ;* DT ;:POINTS TO THE DATA
(1) ;* DF ;:POINTS TO THE DATA FORMAT
(1)
(1) 001312 $ERRTB:
113 ;
114 ; SET UP THE ERROR TABLE POINTERS.
115 ; IF YOU ADD OR DELETE ANY ERRORS,
116 ; DON'T FORGET TO REDEFINE THE TOTAL ERROR COUNT !..
117 ;
118 000223 LASTEM= 223 ; 223 ERRORS TOTAL.
119
120 001312 044361 056340 057426 .WORD EM1, DH1, DT1, DF1 ; ERROR ITEM 1
(3) 001322 044411 056420 057450 .WORD EM2, DH2, DT2, DF2 ; ERROR ITEM 2
(3) 001332 044450 056506 057450 .WORD EM3, DH3, DT3, DF3 ; ERROR ITEM 3
(3) 001342 044502 056567 057450 .WORD EM4, DH4, DT4, DF4 ; ERROR ITEM 4
(3) 001352 044534 056653 057450 .WORD EM5, DH5, DT5, DF5 ; ERROR ITEM 5
(3) 001362 044570 056716 057472 .WORD EM6, DH6, DT6, DF6 ; ERROR ITEM 6
(3) 001372 044622 056716 057472 .WORD EM7, DH7, DT7, DF7 ; ERROR ITEM 7
(3) 001402 000000 000000 000000 .WORD 0,0,0,0
(3) 001412 000000 000000 000000 .WORD 0,0,0,0
(3) 001422 044655 056746 057450 .WORD EM12, DH12, DT12, DF12 ; ERROR ITEM 12
(3) 001432 000000 000000 000000 .WORD 0,0,0,0
(3) 001442 000000 000000 000000 .WORD 0,0,0,0
(3) 001452 000000 000000 000000 .WORD 0,0,0,0
(3) 001462 044723 057027 057450 .WORD EM16, DH16, DT16, DF16 ; ERROR ITEM 16
(3) 001472 044763 056746 057450 .WORD EM17, DH17, DT17, DF17 ; ERROR ITEM 17
(3) 001502 045034 057077 057450 .WORD EM20, DH20, DT20, DF20 ; ERROR ITEM 20
(3) 001512 000000 000000 000000 .WORD 0,0,0,0
(3) 001522 045105 056746 057450 .WORD EM22, DH22, DT22, DF22 ; ERROR ITEM 22
(3) 001532 045170 057077 057450 .WORD EM23, DH23, DT23, DF23 ; ERROR ITEM 23
(3) 001542 045253 057027 057450 .WORD EM24, DH24, DT24, DF24 ; ERROR ITEM 24
(3) 001552 045333 057156 057504 .WORD EM25, DH25, DT25, DF25 ; ERROR ITEM 25
(3) 001562 045403 057156 057532 .WORD EM26, DH26, DT26, DF26 ; ERROR ITEM 26
(3) 001572 000000 000000 000000 .WORD 0,0,0,0
(3) 001602 000000 000000 000000 .WORD 0,0,0,0
(3) 001612 045506 057156 057532 .WORD EM31, DH31, DT31, DF31 ; ERROR ITEM 31
(3) 001622 000000 000000 000000 .WORD 0,0,0,0
(3) 001632 000000 000000 000000 .WORD 0,0,0,0
(3) 001642 045611 057156 057554 .WORD EM34, DH34, DT34, DF34 ; ERROR ITEM 34
(3) 001652 045723 057156 057554 .WORD EM35, DH35, DT35, DF35 ; ERROR ITEM 35
(3) 001662 046035 057156 057554 .WORD EM36, DH36, DT36, DF36 ; ERROR ITEM 36
(3) 001672 046151 057156 057554 .WORD EM37, DH37, DT37, DF37 ; ERROR ITEM 37
(3) 001702 046265 057156 057554 .WORD EM40, DH40, DT40, DF40 ; ERROR ITEM 40
(3) 001712 046327 056746 057450 .WORD EM41, DH41, DT41, DF41 ; ERROR ITEM 41
(3) 001722 046376 057156 057532 .WORD EM42, DH42, DT42, DF42 ; ERROR ITEM 42
  
```

(3)	001732	046502	057156	057532	.WORD	EM43, DH43, DT43, DF43	: ERROR ITEM 43
(3)	001742	046606	057215	057602	.WORD	EM44, DH44, DT44, DF44	: ERROR ITEM 44
(3)	001752	000000	000000	000000	.WORD	0,0,0,0	
(3)	001762	046645	057215	057624	.WORD	EM46, DH46, DT46, DF46	: ERROR ITEM 46
(3)	001772	046717	057215	057472	.WORD	EM47, DH47, DT47, DF47	: ERROR ITEM 47
(3)	002002	047016	057215	057712	.WORD	EM50, DH50, DT50, DF50	: ERROR ITEM 50
(3)	002012	047124	057215	057712	.WORD	EM51, DH51, DT51, DF51	: ERROR ITEM 51
(3)	002022	047166	057156	057734	.WORD	EM52, DH52, DT52, DF52	: ERROR ITEM 52
(3)	002032	047222	057156	057532	.WORD	EM53, DH53, DT53, DF53	: ERROR ITEM 53
(3)	002042	047264	057156	057554	.WORD	EM54, DH54, DT54, DF54	: ERROR ITEM 54
(3)	002052	047330	057156	057734	.WORD	EM55, DH55, DT55, DF55	: ERROR ITEM 55
(3)	002062	047364	057156	057532	.WORD	EM56, DH56, DT56, DF56	: ERROR ITEM 56
(3)	002072	047426	057156	057554	.WORD	EM57, DH57, DT57, DF57	: ERROR ITEM 57
(3)	002102	047472	057156	057532	.WORD	EM60, DH60, DT60, DF60	: ERROR ITEM 60
(3)	002112	047534	057156	057554	.WORD	EM61, DH61, DT61, DF61	: ERROR ITEM 61
(3)	002122	047600	057156	057554	.WORD	EM62, DH62, DT62, DF62	: ERROR ITEM 62
(3)	002132	047716	057215	057712	.WORD	EM63, DH63, DT63, DF63	: ERROR ITEM 63
(3)	002142	050026	057246	057450	.WORD	EM64, DH64, DT64, DF64	: ERROR ITEM 64
(3)	002152	050070	057215	057472	.WORD	EM65, DH65, DT65, DF65	: ERROR ITEM 65
(3)	002162	050124	057215	057712	.WORD	EM66, DH66, DT66, DF66	: ERROR ITEM 66
(3)	002172	050170	057156	057734	.WORD	EM67, DH67, DT67, DF67	: ERROR ITEM 67
(3)	002202	050170	057156	057734	.WORD	EM70, DH70, DT70, DF70	: ERROR ITEM 70
(3)	002212	050273	057156	057554	.WORD	EM71, DH71, DT71, DF71	: ERROR ITEM 71
(3)	002222	050415	057156	057532	.WORD	EM72, DH72, DT72, DF72	: ERROR ITEM 72
(3)	002232	050460	057156	057554	.WORD	EM73, DH73, DT73, DF73	: ERROR ITEM 73
(3)	002242	050525	057156	057734	.WORD	EM74, DH74, DT74, DF74	: ERROR ITEM 74
(3)	002252	050525	057156	057734	.WORD	EM75, DH75, DT75, DF75	: ERROR ITEM 75
(3)	002262	050630	057156	057554	.WORD	EM76, DH76, DT76, DF76	: ERROR ITEM 76
(3)	002272	050752	057156	057532	.WORD	EM77, DH77, DT77, DF77	: ERROR ITEM 77
(3)	002302	051015	057156	057554	.WORD	EM100, DH100, DT100, DF100	: ERROR ITEM 100
(3)	002312	051062	057156	057734	.WORD	EM101, DH101, DT101, DF101	: ERROR ITEM 101
(3)	002322	051165	057156	057532	.WORD	EM102, DH102, DT102, DF102	: ERROR ITEM 102
(3)	002332	051231	057156	057554	.WORD	EM103, DH103, DT103, DF103	: ERROR ITEM 103
(3)	002342	051340	057156	057554	.WORD	EM104, DH104, DT104, DF104	: ERROR ITEM 104
(3)	002352	051406	057156	057734	.WORD	EM105, DH105, DT105, DF105	: ERROR ITEM 105
(3)	002362	051512	057156	057532	.WORD	EM106, DH106, DT106, DF106	: ERROR ITEM 106
(3)	002372	051557	057156	057554	.WORD	EM107, DH107, DT107, DF107	: ERROR ITEM 107
(3)	002402	051674	057156	057554	.WORD	EM110, DH110, DT110, DF110	: ERROR ITEM 110
(3)	002412	051743	057215	057472	.WORD	EM111, DH111, DT111, DF111	: ERROR ITEM 111
(3)	002422	052016	057215	057472	.WORD	EM112, DH112, DT112, DF112	: ERROR ITEM 112
(3)	002432	052072	056746	057450	.WORD	EM113, DH113, DT113, DF113	: ERROR ITEM 113
(3)	002442	052137	057077	057450	.WORD	EM114, DH114, DT114, DF114	: ERROR ITEM 114
(3)	002452	052204	056716	057472	.WORD	EM115, DH115, DT115, DF115	: ERROR ITEM 115
(3)	002462	000000	000000	000000	.WORD	0,0,0,0	
(3)	002472	000000	000000	000000	.WORD	0,0,0,0	
(3)	002502	000000	000000	000000	.WORD	0,0,0,0	
(3)	002512	052266	057215	057472	.WORD	EM121, DH121, DT121, DF121	: ERROR ITEM 121
(3)	002522	052365	057215	057712	.WORD	EM122, DH122, DT122, DF122	: ERROR ITEM 122
(3)	002532	052473	057215	057712	.WORD	EM123, DH123, DT123, DF123	: ERROR ITEM 123
(3)	002542	000000	000000	000000	.WORD	0,0,0,0	
(3)	002552	052535	056746	057752	.WORD	EM125, DH125, DT125, DF125	: ERROR ITEM 125
(3)	002562	052641	057215	057472	.WORD	EM126, DH126, DT126, DF126	: ERROR ITEM 126
(3)	002572	052762	057215	057472	.WORD	EM127, DH127, DT127, DF127	: ERROR ITEM 127
(3)	002602	053100	057077	057752	.WORD	EM130, DH130, DT130, DF130	: ERROR ITEM 130
(3)	002612	000000	000000	000000	.WORD	0,0,0,0	
(3)	002622	000000	000000	000000	.WORD	0,0,0,0	

(3)	002632	000000	000000	000C00	.WORD	0,0,0,0				
(3)	002642	000000	000000	000000	.WORD	0,0,0,0				
(3)	002652	000000	000000	000000	.WORD	0,0,0,0				
(3)	002662	000000	000000	000000	.WORD	0,0,0,0				
(3)	002672	000000	000000	000000	.WORD	0,0,0,0				
(3)	002702	053144	056746	060000	.WORD	EM140, DH140, DT140, DF140	:	ERROR ITEM 140		
(3)	002712	053225	056746	060000	.WORD	EM141, DH141, DT141, DF141	:	ERROR ITEM 141		
(3)	002722	000000	000000	000000	.WORD	0,0,0,0				
(3)	002732	000000	000000	000000	.WORD	0,0,0,0				
(3)	002742	000000	000000	000000	.WORD	0,0,0,0				
(3)	002752	053306	057324	060042	.WORD	EM145, DH145, DT145, DF145	:	ERROR ITEM 145		
(3)	002762	053345	057324	060042	.WORD	EM146, DH146, DT146, DF146	:	ERROR ITEM 146		
(3)	002772	053420	057324	060042	.WORD	EM147, DH147, DT147, DF147	:	ERROR ITEM 147		
(3)	003002	053470	057324	060042	.WORD	EM150, DH150, DT150, DF150	:	ERROR ITEM 150		
(3)	003012	053531	057324	060042	.WORD	EM151, DH151, DT151, DF151	:	ERROR ITEM 151		
(3)	003022	053572	057324	060042	.WORD	EM152, DH152, DT152, DF152	:	ERROR ITEM 152		
(3)	003032	053714	057324	060042	.WORD	EM153, DH153, DT153, DF153	:	ERROR ITEM 153		
(3)	003042	054036	057324	060042	.WORD	EM154, DH154, DT154, DF154	:	ERROR ITEM 154		
(3)	003052	054076	057324	060042	.WORD	EM155, DH155, DT155, DF155	:	ERROR ITEM 155		
(3)	003062	054145	057324	060042	.WORD	EM156, DH156, DT156, DF156	:	ERROR ITEM 156		
(3)	003072	000000	000000	000000	.WORD	0,0,0,0				
(3)	003102	054255	056746	060000	.WORD	EM160, DH160, DT160, DF160	:	ERROR ITEM 160		
(3)	003112	000000	000000	000000	.WORD	0,0,0,0				
(3)	003122	054376	056746	060000	.WORD	EM162, DH162, DT162, DF162	:	ERROR ITEM 162		
(3)	003132	054447	056746	060000	.WORD	EM163, DH163, DT163, DF163	:	ERROR ITEM 163		
(3)	003142	054522	056746	060000	.WORD	EM164, DH164, DT164, DF164	:	ERROR ITEM 164		
(3)	003152	054602	056716	060100	.WORD	EM165, DH165, DT165, DF165	:	ERROR ITEM 165		
(3)	003162	054656	056746	060000	.WORD	EM166, DH166, DT166, DF166	:	ERROR ITEM 166		
(3)	003172	054730	056746	060000	.WORD	EM167, DH167, DT167, DF167	:	ERROR ITEM 167		
(3)	003202	055004	056746	060000	.WORD	EM170, DH170, DT170, DF170	:	ERROR ITEM 170		
(3)	003212	055065	056716	060100	.WORD	EM171, DH171, DT171, DF171	:	ERROR ITEM 171		
(3)	003222	055142	057156	057532	.WORD	EM172, DH172, DT172, DF172	:	ERROR ITEM 172		
(3)	003232	055206	057324	060126	.WORD	EM173, DH173, DT173, DF173	:	ERROR ITEM 173		
(3)	003242	000000	000000	000000	.WORD	0,0,0,0				
(3)	003252	000000	000000	000000	.WORD	0,0,0,0				
(3)	003262	000000	000000	000000	.WORD	0,0,0,0				
(3)	003272	000000	000000	000000	.WORD	0,0,0,0				
(3)	003302	000000	000000	000000	.WORD	0,0,0,0				
(3)	003312	055254	056746	060160	.WORD	EM201, DH201, DT201, DF201	:	ERROR ITEM 201		
(3)	003322	055343	056746	060212	.WORD	EM202, DH202, DT202, DF202	:	ERROR ITEM 202		
(3)	003332	055405	057215	060244	.WORD	EM203, DH203, DT203, DF203	:	ERROR ITEM 203		
(3)	003342	055463	057362	060266	.WORD	EM204, DH204, DT204, DF204	:	ERROR ITEM 204		
(3)	003352	055537	057362	060266	.WORD	EM205, DH205, DT205, DF205	:	ERROR ITEM 205		
(3)	003362	055607	056746	060310	.WORD	EM206, DH206, DT206, DF206	:	ERROR ITEM 206		
(3)	003372	055664	056746	060310	.WORD	EM207, DH207, DT207, DF207	:	ERROR ITEM 207		
(3)	003402	055773	056746	060310	.WORD	EM210, DH210, DT210, DF210	:	ERROR ITEM 210		
(3)	003412	056050	056746	060310	.WORD	EM211, DH211, DT211, DF211	:	ERROR ITEM 211		
(3)	003422	000000	000000	000000	.WORD	0,0,0,0				
(3)	003432	000000	000000	000000	.WORD	0,0,0,0				
(3)	003442	000000	000000	000000	.WORD	0,0,0,0				
(3)	003452	000000	000000	000000	.WORD	0,0,0,0				
(3)	003462	000000	000000	000000	.WORD	0,0,0,0				
(3)	003472	000000	000000	000000	.WORD	0,0,0,0				
(3)	003502	056157	056746	060352	.WORD	EM220, DH220, DT220, DF220	:	ERROR ITEM 220		
(3)	003512	056232	056746	060352	.WORD	EM221, DH221, DT221, DF221	:	ERROR ITEM 221		
(3)	003522	000000	000000	000000	.WORD	0,0,0,0				

CJFPAA -- LS111/23 FPF11 DIAGNOSTIC. PART 1 MACY11 30G(1063) M 2
CJFPAA.P11 28-JAN-81 09:50 ERROR POINTER TABLE 28-JAN-81 10:06 PAGE 1-10

SEQ 0025

(3) 003532 000000 000000 000000 .WORD 0,0,0,0

```

122
123
124
126 003542
127 003542 000240
128
(1) 003544 012706 001100
(1) 003550 005026
(1) 003552 022706 001140
(1) 003556 001374
(1) 003560 012706 001100
(1)
(1) 003564 012737 037504 000020
(1) 003572 012737 000340 000022
(1) 003600 012737 042542 000030
(1) 003606 012737 000340 000032
(1) 003614 012737 042220 000034
(1) 003622 012737 000340 000036
(1) 003630 012737 042370 000024
(1) 003636 012737 000340 000026
(1) 003644 013737 037330 037322
(1) 003652 005037 001220
(1) 003656 005037 001222
(1) 003662 112737 000001 001115
(1) 003670 012737 003670 001106
(1) 003676 012737 003676 001110
(2)
(2)
(2) 003704 013746 000004
(2) 003710 012737 003744 000004
(2) 003716 012737 177570 001140
(2) 003724 012737 177570 001142
(2) 003732 022777 177777 175200
(2) 003740 001012
(2)
(2) 003742 000403
(2) 003744 012716 003752 64$:
(2) 003750 000002
(2) 003752 012737 000176 001140 65$:
(2) 003760 012737 000174 001142
(2) 003766 012637 000004 66$:
(1)
(2) 003772 005037 001242
(2) 003776 132737 000200 001255
(2) 004004 001403
(2) 004006 012737 001256 001140
(2) 004014
    
```

```

: INITIAL START/RESTART HERE.
START:RESTART:
NOP
.SBTTL INITIALIZE THE COMMON TAGS
::CLEAR THE COMMON TAGS ($CMTAG) AREA
MOV #SCMTAG,R6 ::FIRST LOCATION TO BE CLEARED
CLR (R6)+ ::CLEAR MEMORY LOCATION
CMP #SWR,R6 ::DONE?
BNE -6 ::LOOP BACK IF NO
MOV #STACK,SP ::SETUP THE STACK POINTER
::INITIALIZE A FEW VECTORS
MOV #SCOPE,@IOTVEC ::IOT VECTOR FOR SCOPE ROUTINE
MOV #340,@IOTVEC+2 ::LEVEL 7
MOV #ERROR,@EMTVEC ::EMT VECTOR FOR ERROR ROUTINE
MOV #340,@EMTVEC+2 ::LEVEL 7
MOV #STRAP,@TRAPVEC ::TRAP VECTOR FOR TRAP CALLS
MOV #340,@TRAPVEC+2::LEVEL 7
MOV #SPWRDN,@PWVEC ::POWER FAILURE VECTOR
MOV #340,@PWVEC+2 ::LEVEL 7
MOV $ENDCT,$EOPCT ::SETUP END-OF-PROGRAM COUNTER
CLR $TIMES ::INITIALIZE NUMBER OF ITERATIONS
CLR $ESCAPE ::CLEAR THE ESCAPE ON ERROR ADDRESS
MOVB #1,$ERMAX ::ALLOW ONE ERROR PER TEST
MOV #,$SLPADR ::INITIALIZE THE LOOP ADDRESS FOR SCOPE
MOV #,$SLPERR ::SETUP THE ERROR LOOP ADDRESS
::SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
::EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.
MOV @ERRVEC,-(SP) ::SAVE ERROR VECTOR
MOV #64$,@ERRVEC ::SET UP ERROR VECTOR
MOV #DSWR,SWR ::SETUP FOR A HARDWARE SWICH REGISTER
MOV #DDISP,DISPLAY ::AND A HARDWARE DISPLAY REGISTER
CMP #-1,@SWR ::TRY TO REFERENCE HARDWARE SWR
BNE 66$ ::BRANCH IF NO TIMEOUT TRAP OCCURRED
::AND THE HARDWARE SWR IS NOT - 1
BR 65$ ::BRANCH IF NO TIMEOUT
MOV #65$, (SP) ::SET UP FOR TRAP RETURN
RTI
MOV #SWREG,SWR ::POINT TO SOFTWARE SWR
MOV #DISPREG,DISPLAY
MOV (SP)+,@ERRVEC ::RESTORE ERROR VECTOR
CLR $PASS ::CLEAR PASS COUNT
BITB #APTSIZE,$ENVM ::TEST USER SIZE UNDER APT
BEQ 67$ ::YES,USE NON-APT SWITCH
MOV #SSWREG,SWR ::NO,USE APT SWITCH REGISTER
    
```

```

130
131
132
133
134 004014 005227 177777
135 004020 001032
136 004022 023727 000042 037464
137 004030 001426
138 004032 104401 004040
(1) 004036 000423
(1)
(1) 004106
139 004106
(1)
(1) 004106 005737 000042
(1) 004112 001012
(1) 004114 123727 001254 000001
(1) 004122 001406
(1) 004124 023727 001140 000176
(1) 004132 001005
(1) 004134 104406
(1) 004136 000403
(1) 004140 112737 000001 001134
(1) 004146
140
141
142
143 004146 012706 001100
144 004152 012737 004200 000244
145 004160 012737 004234 000010
146 004166 012737 004224 000004
147 004174 000137 004356

;
; TYPE NAME ON INITIAL PASS IF NOT ACT MODE.
; GET SWR IF NOT AUTO MODE (ACT, APT, OR XXDP CHAIN).
;
; INC #-1 ; INITIAL PASS ??
; BNE 1$ ; NO
; CMP 42,$SENDAD ; ACT-11 ??
; BEQ 1$ ; YES.
; TYPE ,69$ ' ; TYPE ASCIZ STRING
; BR 68$ ; GET OVER THE ASCIZ
;:69$: .ASCIZ <CRLF>'CJFPAA -- FPF11 DIAGNOSTIC, PART 1'<CRLF>
;:68$:
;:1$:
;SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
;TST @#42 ;:ARE WE RUNNING UNDER XXDP/ACT?
;BNE 70$ ;:BRANCH IF YES
;CMPB $ENV,#1 ;:ARE WE RUNNING UNDER APT?
;BEQ 70$ ;:BRANCH IF YES
;CMP SWR,#SWREG ;:SOFTWARE SWITCH REG SELECTED?
;BNE 71$ ;:BRANCH IF NO
;GTSWR ;:GET SOFT-SWR SETTINGS
;BR 71$
;:70$: MOVB #1,$AUTOB ;:SET AUTO-MODE INDICATOR
;:71$:
;
; CONTINUE HERE AFTER 'END-PASS'.
;
; LOOP: MOV #STACK,SP ; RESET STACK POINTER.
; MOV #TRP244,FPVEC ; RESET INTERRUPT VECTORS.
; MOV #TRP10,RESVEC
; MOV #TRP04,ERRVEC
; JMP TST1 ; GO START 'EM UP !!!!
    
```

```

149      .SBTTL COMMON SUBROUTINES
150      :
151      : THESE HANDLE UNEXPECTED TRAPS TO 244, 10, AND 4.
152      : REPORT APPROPRIATE ERROR AND ABORT THE CURRENT TEST.
153      :
154      .ENABL  LSB
155 004200 011637 001164 TRP244: MOV (SP),@#$TMP2 ; GET PC OF TRAP.
156 004204 170200      STFPS RO ;GET FPS
157 004206 010037 001166      MOV RO,@#$TMP3
158 004212 170300      STST RO ;GET FEC
159 004214 010037 001170      MOV RO,@#$TMP4
160 004220 104005      ERROR 5
161 004222 000407      BR 1$ ; COMMON EXIT.
162
163 004224 011637 001164 TRP04: MOV (SP),@#$TMP2 ; GET PC OF TRAP.
164 004230 104006      ERROR 6
165 004232 000403      BR 1$
166
167 004234 011637 001164 TRP10: MOV (SP),@#$TMP2 ; GET PC OF TRAP.
168 004240 104007      ERROR 7
169
170 004242 022626      1$: CMP (SP)+,(SP)+ ; COMMON EXIT, FIX STACK...
171 004244 104401 043341      TYPE ,ABORT ;...AND TELL THE MAN.
172 004250 123727 001102 000051      CMPB $TSTNM,#LASTST ; ON THE LAST TEST ??
173 004256 001002      BNE 2$ ; NO.
174 004260 000137 037274      JMP $EOP ; YES, END-PASS.
175 004264 113700 001102      2$: MOVB $TSTNM,RO ; GET TEST NUM...
176 004270 006300      ASL RO ;...SHIFT TO WORD INDEX.
177 004272 016001 040022      MOV $$W08TBL(RO),R1 ; GET NEXT TEST ADDRESS...
178 004276 000161 177776      JMP -2(R1) ;...AND GO THFRE.
179      .DSABL LSB
    
```

```

181
182      ; SUBROUTINE TO COMPARE 2 FLOATING OPERANDS.
183      ; RETURN WITH 'Z' = 1 IF EQUAL, 'Z' - 0 OTHERWISE.
184      ; CALL: JSR R5,CHECK2 ;OR CHECK4
185      ;       ADR1, ADR2
186      ;       BEQ   XX      ; OR BNE
187      ;
188      ; .ENABL  LSB
189 004302 012737 000002 004352 CHECK2: MOV   #2,3$      ; 32 BIT COMPARE.
190 004310 000403          SKP3
191 004312 012737 000004 004352 CHECK4: MOV   #4,3$      ; 64 BIT COMPARE.
192 004320 010046          MOV   R0,-(SP)    ; SAVE REGISTERS.
193 004322 010146          MOV   R1,-(SP)
194 004324 012500          MOV   (R5)+,R0    ; SET OPERAND ADDRESSES.
195 004326 012501          MOV   (R5)+,R1
196 004330 000240          NOP
197 004332 022021          1$:  CMP   (R0)+,(R1)+  ; COMPARE.
198 004334 001003          BNE   2$          ; EXIT IF NOT EQUAL.
199 004336 005337 004352  DEC   3$
200 004342 001373          BNE   1$
201 004344 012601          2$:  MOV   (SP)+,R1    ; RESTORE REGISTERS.
202 004346 012600          MOV   (SP)+,R0
203 004350 005727          TST   (PC)+
204 004352 000000          3$:  0          ; 0 IF EQUAL, NZ OTHERWISE.
205 004354 000205          RTS   R5
206          .DSABL  LSB
  
```

```

208 .SBTTL
209 .SBTTL          FPF PART 1 TESTS
210 .SBTTL
232 :*****
(3) :*TEST 1          LDFPS, STFPS, AND DATA PATHS -- SRC AND DST MODE 0
(4) :*
(4) :*THIS IS A TEST OF THE LDFPS (LOAD FP STATUS) AND STFPS
(4) :*(STORE FP STATUS) INSTRUCTIONS. A COUNT PATTERN IS GENERATED
(4) :*AND RUN THROUGH THE FLOATING POINT STATUS REGISTER.
(4) :*THIS WILL TEST THE 16-BIT TRI STATE BUS WHICH CONNECTS THE CPU
(4) :*WITH THE FPP AND ALSO RUNS INTERNALLY WITHIN THE FPP.
(4) :*SRC/DST MODE 0 IS USED.
(4) :*NOTE THAT BITS 12 AND 13 ARE UNUSED IN FiS AND ARE MASKED OFF.
(4) :*
(4) :*TO PREVENT LOCKING OUT THE COMPLETION OF THE TEST BECAUSE OF
(4) :*AN EXCESSIVE NUMBER OF ERRORS, ONLY THE FIRST FIVE ERRORS
(4) :*WILL BE REPORTED THEN THE TEST WILL BE COMPLETED AND
(4) :*AN ERROR SUMMARY GIVEN, AS FOLLOWS:
(4) :*
(4) :*A DYNAMIC RECORD OF THE LOGICAL 'AND' AND 'OR' OF THE FAILING
(4) :*DATA PATTERNS IS KEPT. THESE CAN BE VERY USEFUL IN DETERMINING
(4) :*STUCK BITS. WHEN THE TEST COMPLETES, THIS SUMMARY IS PRINTED
(4) :*IF ANY ERRORS WERE ENCOUNTERED.
(3) :*****
(2) 004356 000004 TST1: SCOPE
233 004360 005000 1$: CLR R0 ; INITIALIZE COUNT PATTERN.
234 004362 012702 177777 MOV #-1,R2 ; R2 IS THE 'AND' OF BAD DATA.
235 004366 005003 CLR R3 ; R3 IS THE 'OR' OF BAD DATA.
236 004370 012737 004406 001164 MOV #A2,$TMP2 ; ERROR PC.
237 004376 005037 001200 CLR $TMP10 ; ERROR COUNTER.
238 004402 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 - 1.
239 004404 010004 A1: MOV R0,R4
240 004406 170104 A2: LDFPS R4 ; R4 => FPS...
241 004410 012701 177777 MOV #-1,R1
242 004414 170201 STFPS R1 ;...AND FPS => R1.
243 004416 042704 030000 BIC #30000,R4 ; MASK OFF EXPD DATA <13:12>.
244 004422 020401 CMP R4,R1 ; CHECK EXP'D VS REC'D
245 004424 001421 BEQ 4$ ; BR IF OK.
246
247 004426 050103 3$: BIS R1,R3 ;MAKE 'OR' OF FAILING DATA.
248 004430 005101 COM R1
249 004432 040102 BIC R1,R2 ;MAKE 'AND' OF FAILING DATA.
250 004434 005101 COM R1
251 004436 023727 001200 000005 CMP $TMP10,#5 ; 5 ERRORS LOGGED ??
252 004444 103011 BHIS 4$ ; YES, DON'T REPORT ANY MORE.
253 004446 005237 001200 INC $TMP10 ; NOT YET, REPORT ERROR.
254 004452 010037 001166 MOV R0,@$TMP3 ; WROTE
255 004456 010137 001170 MOV R1,@$TMP4 ; READ
256 004462 010437 001172 MOV R4,@$TMP5 ; EXPD
257 004466 104001 ERROR 1
258 004470 077033 4$: SOB R0,A1 ; LOOP UNTIL DONE.
259
260 004472 005737 001200 5$: TST $TMP10 ; ALL DONE, ANY ERRORS ??
261 004476 001410 BEQ A3 ; BR IF NOT.
262 004500 013737 001200 001164 MOV $TMP10,$TMP2 ; OTHERWISE, GIVE AND/OR SUMMARY.
    
```

263 004506 010237 001166
264 004512 010337 001170
265 004516 104002
266
267
268
269
270
271
272 004520 170106
273 004522 000240 000240
274 004526 170107
275 004530 000240 000240
276 004534
(1) 004534 104412
(3) 004536 000400

MOV R2,STMP3 : 'AND' SUMMARY.
MOV R3,STMP4 : 'OR' SUMMARY.
ERROR 2
:
: NOW THE PC (R7) AND SP (R6) ARE VALID SRC ADDRESSES.
: CAN'T THINK WHY ANYONE WOULD WANT TO PUT THE PC OR STACK POINTER
: IN THE FPS -- BUT DO IT ANYWAY JUST TO TICK THAT MICROSTATE, AND
: SEE THAT IT DOESN'T TRAP FOR ANY REASON.
:
A3: LDFPS SP : R6 => FPS
240,240 : WE'RE HERE IF IT DIDN'T TRAP.
A4: LDFPS PC : R7 => FPS
240,240 : DITTO
ADONE:
CLRFP : : CLEAR FP STATUS...
BR TST2 : : ...AND PROCEED.

```

286
(3)
(4)
(4)
(4)
(4)
(4)
(4)
(3)
(2) 004540 000004
287 004542 012700 000017
288 004546 012737 0C4600 001164
289 004554 104411
290 004556 052737 140340 177776 B1:
291 004564 170100
292 004566 013701 177776
293 004572 042701 000017
294 004576 050001
295 004600 170000 B2:
296 004602 000240
297 004604 013702 177776
298 004610 170203
299
300 004612 020102
301 004614 001405
302 004616 010137 001170
303 004622 010237 001166
304 004626 104003
305
306 004630 020003
307 004632 001405
308 004634 010037 001166
309 004640 010337 001170
310 004644 104004
311
312 004646 005300
313 004650 100342
314
315 004652 005037 177776
316 004656 104412
(3) 004660 000400
    
```

```

*****
*TEST 2          COPY CONDITION CODES
*
*THIS IS A TEST OF THE COPY CONDITION CODES INSTRUCTION, CFCC.
*INSURE THAT ONLY PSW<3:0> ARE AFFECTED BY THE CFCC, AND THAT
*THE FP STATUS REGISTER IS UNALTERED.
* NOTE: THE CPU IS IN 'USER MODE' DURING THIS TEST.
*****
TST2:  SCOPE
      MOV #17,R0          ; FPS CODE PATTERN.
      MOV #B2,$TMP2      ; SET PC IN CASE OF ERROR.
      LUPERR              ; LOOP HERE ON ERROR IF SWR9 1.
      BIS #140340,PSW    ; SET 'USER MODE, PRI 7'.
      LDFPS R0           ; SET FPS.
      MOV PSW,R1
      BIC #17,R1
      BIS R0,R1          ; SET EXP'D PSW => R1.
      CFCC               ; XCT 'COPY CONDITION CODES'
      240
      MOV PSW,R2         ; GET FINAL PSW...
      STFPS R3           ; ...AND FPS.
      CMP R1,R2          ; PSW RIGHT ??
      BEQ 1$             ; BR IF SO.
      MOV R1,$TMP4
      MOV R2,$TMP3
      ERROR 3            ; *** PSW WRONG ***
1$:   CMP R0,R3          ; FPS RIGHT ??
      BEQ 2$             ; BR IF SO.
      MOV R0,$TMP3
      MOV R3,$TMP4
      ERROR 4            ; *** FPS ALTERED ***
2$:   DEC R0             ; NEXT CODE PATTERN.
      BPL B1             ; LOOP 'TIL DONE.
BDONE: CLR PSW           ; RESTORE KERNAL MODE, PRI 0.
      CLRFPS            ; CLEAR FP STATUS...
      BR TST3           ; ...AND PROCEED.
    
```



```

326 .....
(3) *TEST 3      SETF, SETD, SETI, AND SETL
(4) *
(4) *THIS IS A TEST OF THE SETF, SETD, SETI AND SETL INSTRUCTIONS.
(4) *EACH INSTRUCTION IS EXECUTED WITH THE FPS CLEAR, AND THEN
(4) *AGAIN WITH THE FPS CONTAINING ALL 1'S (147777).
(4) *THE RESULTING FPS IS CHECKED IN EACH CASE.
(4) *
(3) .....
(2) 004662 000004
327 004664 112737 000106 044704  TST3:  SCOPE
328 004672 012737 170001 005036  MOVB  #'F,EM12X
329 004700 005002  CLR      R2      ; EXPECT BOTH CLEAR 1ST...
330 004702 012703 147577  MOV     #147577,R3 ; ...THEN FD ONLY.
331 004706 004737 005022  JSR    PC,C1      ; TEST 'SETF'.
332
333 004712 112737 000104 044704  MOVB  #'D,EM12X
334 004720 012737 170011 005036  MOV   #SETD,C15
335 004726 012702 000200  MOV   #200,R2     ; EXPECT FD - 1...
336 004732 012703 147777  MOV   #147777,R3 ; ...THEN ALL.
337 004736 004737 005022  JSR   PC,C1      ; TEST 'SETD'.
338
339 004742 112737 000111 044704  MOVB  #'I,EM12X
340 004750 012737 170002 005036  MOV   #SETI,C15
341 004756 005002  CLR     R2      ; EXPECT BOTH CLEAR...
342 004760 012703 147677  MOV   #147677,R3 ; ...THEN FL ONLY.
343 004764 004737 005022  JSR   PC,C1      ; TEST 'SETI'.
344
345 004770 112737 000114 044704  MOVB  #'L,EM12X
346 004776 012737 170012 005036  MOV   #SETL,C15
347 005004 012702 000100  MOV   #100,R2     ; EXPECT FL ONLY...
348 005010 012703 147777  MOV   #147777,R3 ; ...THEN ALL.
349 005014 004737 005022  JSR   PC,C1      ; TEST 'SETL'.
350 005020 000443  BR     CDONE
351
352 ; CLEAR FPS AND TEST SET_, THEN SET 1'S AND TEST AGAIN.
353
354 005022 013737 005036 005076 C1:  MOV   C15,C25
355 005030 104411  LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.
356 005032 005000  CLR    R0
357 005034 170100  LDFPS  R0      ; 0'S TO FPS.
358 005036 170001  C15:  SETF   ; TEST INSTRUCTION.
359 005040 170201  STFPS  R1      ; GET RESULT.
360 005042 020102  CMP    R1,R2
361 005044 001410  BEQ    1$     ; BR IF 1ST PASS OK.
362 005046 012737 005036 001164  MOV   #C15,$TMP2
363 005054 010137 001166  MOV   R1,$TMP3
364 005060 010237 001170  MOV   R2,$TMP4
365 005064 104012  ERROR  12     ; *** SET_ FAILED ***
366
367 005066 1$:  LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.
(1) 005066 104411  MOV   #147777,R0
368 005070 012700 147777  LDFPS  R0      ; 1'S TO FPS.
369 005074 170100  C25:  SETF   ; TEST INSTRUCTION AGAIN.
370 005076 170001  STFPS  R1      ; GET RESULT
371 005100 170201

```

372 005102 020103
373 005104 001410
374 005106 012737 005076 001164
375 005114 010137 001166
376 005120 010337 001170
377 005124 104012
378 005126 000207
379
380 005130
(1) 005130 104412
(3) 005132 000400

1\$:

CDONE:

CMP R1,R3
BEQ 1\$: BR IF 2ND PASS OK.
MOV #C25,\$TMP2
MOV R1,\$TMP3
MOV R3,\$TMP4
ERROR 12 : *** SET_ FAILED ***
RTS PC

CLRFPS : : CLEAR FP STATUS...
BR TST4 : : ...AND PROCEED.

```

392 .....
(3) *TEST 4      ILLEGAL FPP OP-CODE TRAP, AND STST -- DST MODE 0
(4) *
(4) *THIS IS A TEST OF THE ILLEGAL FP OP-CODE TRAP FUNCTION.
(4) *FP OPCODES 170003 THRU 170010 AND 170013 THRU 170077 ARE
(4) *ILLEGAL (INVALID) AND SHOULD CAUSE A TRAP TO 244 (WHEN
(4) *INTERRUPTS ARE ENABLED).
(4) *WHEN ANY OF THE ABOVE OPCODES TRAP, THE FEC REGISTER SHOULD
(4) *BE SET TO CODE 2, TO INDICATE AN OPCODE ERROR.
(4) *
(3) .....
(2) 005134 000004
393 005136 012705 170003
394 005142 104411
395 005144 012737 005242 000244 D1:
396 005152 005002
397 005154 005001
398 005156 005000
399 005160 170100
400 005162 010537 005174
401 005166 012737 005174 001164
402 005174 170000
403 005176 000240
404
405 005200 170201
406 005202 013737 005174 001166
407 005210 010137 001170
408 005214 104016
409
410 005216 020527 170077
411 005222 001435
412 005224 005205
413 005226 020527 170011
414 005232 001002
415 005234 012705 170013
416 005240 000741
417
418
419
420 005242 022626
421 005244 170201
422 005246 020127 100000
423 005252 001406
424 005254 010137 001166
425 005260 012737 100000 001170
426 005266 104017
427
428 005270 170302
429 005272 020227 000002
430 005276 001406
431 005300 010237 001166
432 005304 012737 000002 001170
433 005312 104020
434 005314 000740
435
436 005316

```

```

TST4:  SCOPF
      MOV #170003,R5 ;INITIAL OP CODE.
      LUPERR ;: LOOP HERE ON ERROR IF SWR9 1.
      MOV #D244,@#FPVEC ; FOR OBSERVED FEC...
      CLR R2 ;...AND FPS.
      CLR R1
      CLR R0
      LDFPS R0 ;CLEAR FPS (INTERRUPT ENA).
      MOV R5,@#D2 ;SET AN ILLEGAL INSTRUCTION.
      MOV #D2,@#STMP2
D2: 170000 ; ILLEGAL OPCODES EXECUTED HERE.
     240
      STFPS R1 ; IT DIDN'T TRAP, GET FPS.
      MOV D2,$TMP3
      MOV R1,@#STMP4
      ERROR 16 ; *** OPCODE DIDN'T TRAP ***
D3:  CMP R5,#170077 ; LAST OPCODE DONE ??
     BEQ DDONE ; BR IF SO.
     INC R5 ; NO, SET NEXT ONE.
     CMP R5,#170011
     BNE 1$ ; LOOP FOR 03 THRU 10...
     MOV #170013,R5
     BR D1 ;...AND 13 THRU 77.
1$:
: WE'RE HERE ON TRAP TO 244.
D244: CMP (SP)+,(SP)+ ; FIX STACK.
      STFPS R1 ;GET THE FPS AND CHECK IT.
      CMP R1,#BIT15
      BEQ D4 ; BR IF FPS IS OK.
      MOV R1,@#STMP3
      MOV #BIT15,$TMP4
      ERROR 17 ; *** FPS WRONG ***
D4:  STST R2 ; GET THE FEC.
     CMP R2,#2
     BEQ 1$ ; BR IF FEC IS RIGHT.
     MOV R2,@#STMP3
     MOV #2,@#STMP4
     ERROR 20 ; *** FEC WRONG ***
1$:  BR D3
DDONE:

```

CJFPAA -- LSI11/23 FPF11 DIAGNOSTIC, PART 1
CJFPAA.P11 28-JAN-81 09:50 T4

MACY11 30G(1063) ^{K 3} 28-JAN-81 10:06 PAGE 2-6
ILLEGAL FPP OP-CODE TRAP, AND STST -- DST MODE 0

SEQ 0036

(1) 005316 104412
(3) 005320 000400

CLRFPS :: CLEAR FP STATUS...
BR TSTS ::...AND PROCEED.

```
445 ::*****
(3) : *TEST 5 INTERRUPT DISABLE (FID) BIT
(4) : *
(4) : *THIS IS A TEST OF THE INTERRUPT DISABLE (FID) BIT.
(4) : *AN ILLEGAL INSTRUCTION IS EXECUTED WITH FID - 1.
(4) : *NO INTERRUPT SHOULD OCCUR.
(4) : *
(3) : *****
(2) 005322 000004 TST5: SCOPE
446 005324 012737 005432 000244 MOV #E244,@#FPVEC ;SETUP FOR THE INTERRUPT.
447 005332 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.
448 005334 005002 E1: CLR R2 ;: FOR OBSERVED FEC...
449 005336 005001 CLR R1 ;:...AND FPS.
450 005340 012700 040000 MOV #BIT14,R0
451 005344 170100 LDFPS R0 ; SET FID BIT.
452 005346 012737 005354 001164 MOV #E2,@#STMP2
453 005354 170077 E2: 170077 ; XCT ILLEGAL OPCODE.
454 005356 000240 240
455
456 005360 170201 STFPS R1 ; GET FPS.
457 005362 020127 140000 CMP R1,#140000
458 005366 001406 BEQ 1$ ; BR IF FPS IS RIGHT.
459 005370 010137 001166 MOV R1,$STMP3
460 005374 012737 140000 001170 MOV #140000,$STMP4
461 005402 104022 ERROR 22 ; *** FPS WRONG ***
462
463 005404 170302 1$: STST R2 ; GET FEC.
464 005406 020227 000002 CMP R2,#2
465 005412 001406 BEQ 2$ ; BR IF FEC IS RIGHT.
466 005414 010237 001166 MOV R2,$STMP3
467 005420 012737 000002 001170 MOV #2,$STMP4
468 005426 104023 ERROR 23 ; *** FEC WRONG ***
469 005430 000412 2$: BR EDONE
470
471 : WE'RE HERE ON A TRAP -- FID = 1, WHAT THE HELL ?????
472
473 005432 011637 001164 E244: MOV (SP),$STMP2 ; SET TRAP PC.
474 005436 022626 CMP (SP)+,(SP)+
475 005440 013737 005354 001166 MOV E2,$STMP3
476 005446 170201 STFPS R1
477 005450 010137 001170 MOV R1,$STMP4
478 005454 104024 ERROR 24 ; *** TRAPPED WITH FID = 1 ***
479
480 EDONE:
(1) 005456 104412 CLRFPs ;: CLEAR FP STATUS...
(3) 005460 000400 BR TST6 ;:...AND PROCEED.
```

```

492          ;*****
(3)          ;*TEST 6          LDD AND STD -- FSRC AND FDST MODE 1
(4)          ;*
(4)          ;*THIS IS A TEST OF THE LOAD AND STORE DOUBLE INSTRUCTIONS.
(4)          ;*          LDD (R0),ACO AND STD ACO,(R0)
(4)          ;*
(4)          ;*NOTE THAT THIS IS THE FIRST ATTEMPT TO USE ACO. THIS IMPLIES
(4)          ;*THAT IT MAY NOT BE POSSIBLE TO ISOLATE A FAILURE TO EITHER THE
(4)          ;*AC ITSELF OR THE MICROCODE FLOW -- BUT WE'LL GIVE IT A TRY.
(4)          ;*
(3)          ;*****
(2) 005462 000004 TST6: SCOPE
493          ;
494          ; TEST THE LOAD FIRST.
495          ;
496 005464 F1:
(1) 005464 104411 LUPERR ;; LOOP HERE ON ERROR IF SWR9 = 1.
497 005466 170011 SETD ; SET DOUBLE.
498 005470 012701 006420 MOV #FDAT10,R1 ;SET UP THE LOAD DATA.
499 005474 012702 006460 MOV #FXDAT0,R2
500 005500 012703 000004 MOV #4,R3
501 005504 012221 1$: MOV (R2)+,(R1)+
502 005506 077302 SOB R3,1$
503
504 005510 012700 006420 MOV #FDAT10,R0 ;SETUP R0 FOR THE LDD (R0),ACO.
505 005514 012737 006224 000004 MOV #FERR20,ERRVEC ;IF THE SRC FLOWS FAIL THEN
506 ; A BUS-ERROR TRAP MAY OCCUR.
507 005522 012737 005536 001164 MOV #F3,@$STMP2 ; SET TEST PC FOR OUTPUT.
508 005530 010037 001166 MOV R0,$STMP3 ; AND SRC POINTER TOO.
509 005534 005003 CLR R3
510 005536 172410 F3: LDD (R0),ACO
511 005540 005203 F4: INC R3
512 005542 005203 INC R3
513
514 005544 020027 006420 CMP R0,#FDAT10 ;WAS SRC ADDRESS AFFECTED?
515 005550 001417 BEQ 3$ ; BR IF NOT.
516 005552 010037 001170 MOV R0,@$STMP4 ; SRC POINTER WAS ALTERED.
517 005556 022700 006410 CMP #FDAT10-10,R0 ;LOOK LIKE MODE 4?
518 005562 001003 BNE 1$ ; NO
519 005564 012737 000324 001172 MOV #324,@$STMP5 ; YES
520 005572 022700 006430 1$: CMP #FDAT10+10,R0 ;LOOK LIKE MODE 2?
521 005576 001003 BNE 2$ ; NO
522 005600 012737 000322 001172 MOV #322,@$STMP5 ; YES
523 005606 104026 2$: ERROR 26 ; R0 WRONG AFTER LDD.
524
525 005610 004537 004312 3$: JSR R5,CHECK4 ; WAS SRC DATA AFFECTED ??
526 005614 006460 006420 FXDAT0,FDAT10 ; EXP VS RECD.
527 005620 001407 BEQ 4$ ; BR IF NOT.
528 005622 012737 006460 001170 MOV #FXDAT0,$STMP4 ; SOURCE DATA ALTERED...
529 005630 012737 006420 001172 MOV #FDAT10,$STMP5 ;...BY THE LDD.
530 005636 104025 ERROR 25
531
532 005640 170201 4$: STFPS R1 ; GET FPS
533 005642 020127 000200 CMP R1,#200 ; IS IT RIGHT ??
534 005646 001406 BEQ F6 ; BR IF SO.
535 005650 010137 001166 MOV R1,$STMP3 ; FPS WRONG...

```

```

536 005654 012737 000200 001170      MOV    #200,$TMP4      ;...EXPECTED THIS.
537 005662 104041                      ERROR  41
538
539      ; NOW DO THE STORE INSTRUCTION.
540
541      ; F6:
541 005664                      LUPERR
(1) 005664 104411                      ;: LOOF HERE ON ERROR IF SWR9 - 1.
542 005666 012704 000004      MOV    #4,R4
543 005672 012705 006440      MOV    #FDAT00,R5      ;SET UP THE OUTPUT DATA BUFFER.
544 005676 012725 177777      1$:   MOV    #-1,(R5)+
545 005702 077403      SOB    R4,1$
546
547 005704 012700 006440      MOV    #FDAT00,R0      ;SET UP R0 FOR DST MODE 1 REG 0.
548 005710 012737 006316 000004      MOV    #FERR25,ERRVEC ;IF THE DST FLOWS FAIL
549                      ; A BUS-ERROR TRAP COULD OCCUR
550 005716 012737 005746 001164      MOV    #F10,@$TMP2    ; SET TEST PC.
551 005724 010037 001166      MOV    R0,$TMP3        ; AND DST POINTER.
552 005730 012737 006460 001170      MOV    #FXDAT0,$TMP4  ; EXP
553 005736 012737 006440 001172      MOV    #FDAT00,$TMP5  ; RECD
554 005744 005003                      CLR    R3
555 005746 174010      F10:  STD    ACO,(R0)    ;TEST INSTRUCTION.
556 005750 005203      F11:  INC    R3
557 005752 005203                      INC    R3
558
559 005754 020027 006440      CMP    R0,#FDAT00     ;WAS DST ADDRESS MODIFIED?
560 005760 001417                      BEQ    3$             ; BR IF NOT.
561 005762 010037 001170      MOV    R0,@$TMP4     ; DST POINTER WAS ALTERED.
562 005766 022700 006430      CMP    #FDAT00-10,R0 ;LOOK LIKE DST MODE 4?
563 005772 001003                      BNE    1$             ; NO
564 005774 012737 000644 001172      MOV    #644,@$TMP5   ; YES.
565 006002 022700 006450      1$:   CMP    #FDAT00+10,R0 ;LOOK LIKE DST MODE 2?
566 006006 001003                      BNE    2$             ; NO
567 006010 012737 000642 001172      MOV    #642,@$TMP5   ; YES
568 006016 104031      2$:   ERROR  31
569
570 006020 012701 006440      3$:   MOV    #FDAT00,R1
571 006024 012702 006460      MOV    #FXDAT0,R2
572 006030 022122                      CMP    (R1)+,(R2)+   ;SEE IF THE DATA IS OK.
573 006032 001072                      BNE    FERR10        ; BR IF 1ST WORD WRONG.
574 006034 022122                      CMP    (R1)+,(R2)+
575 006036 001020                      BNE    FERR6         ; BR IF 2ND WORD WRONG (BUT GR7 ??)..
576 006040 022122                      CMP    (R1)+,(R2)+
577 006042 001042                      BNE    FERR7        ; BR IF 3RD WORD WRONG (BUT FD ??).
578 006044 022122                      CMP    (R1)+,(R2)+
579 006046 001064                      BNE    FERR10        ; BR IF 4TH WORD WRONG.
580
581 006050 170201      4$:   STFPS  R1           ; GET FPS.
582 006052 020127 000200      CMP    R1,#200       ; IS IT RIGHT ??
583 006056 001406                      BEQ    5$             ; BR IF SO.
584 006060 010137 001166      MOV    R1,$TMP3      ; FPS WRONG AFTER STD.
585 006064 012737 000200 001170      MOV    #200,$TMP4
586 006072 104041                      ERROR  41
587 006074 000137 006470      5$:   JMP    @#FDONE      ; ALL DONE.
588
589 006100 012701 006442      FERR6: MOV    #FDAT01,R1 ;DID (BUT GR7) FAIL IN THE FDST FLOW ??
590 006104 012702 177777      MOV    #-1,R2

```

591	006110	012703	000003		MOV	#3,R3		
592	006114	020221		1\$:	CMP	R2,(R1)-		
593	006116	001003			BNE	2\$; NO	
594	006120	077303			SOB	R3,1\$		
595	006122	104034			ERROR	34	; BUT GR7, FDST FAILED.	
596	006124	000410			BR	4\$		
597								
598	006126	012701	006442	2\$:	MOV	#FDAT01,R1	;DID (BUT GR7) FAIL IN THE FSRC FLOW ?	
599	006132	012703	000003		MOV	#3,R3		
600	006136	005721		3\$:	TST	(R1)+		
601	006140	001027			BNE	FERR10	; NO.	
602	006142	077303			SOB	R3,3\$		
603	006144	104035			ERROR	5	; BUT GR7, FSRC FAILED.	
604	006146	000550		4\$:	BR	FDONE		
605								
606	006150	012701	006444	FERR7:	MOV	#FDAT02,R1	;DID (BUT FD) FAIL IN THE FDST FLOW ?	
607	006154	012702	177777		MOV	#-1,R2		
608	006160	012703	000002		MOV	#2,R3		
609	006164	020221		1\$:	CMP	R2,(R1)+		
610	006166	001003			BNE	2\$; NO	
611	006170	077303			SOB	R3,1\$		
612	006172	104036			ERROR	36	; BUT FD, FDST FAILED.	
613	006174	000410			BR	4\$		
614								
615	006176	012701	006444	2\$:	MOV	#FDAT02,R1	;DID (BUT FD) FAIL IN THE FSRC FLOW ?	
616	006202	012703	000002		MOV	#2,R3		
617	006206	005721		3\$:	TST	(R1)+		
618	006210	001003			BNE	FERR10	; NO	
619	006212	077303			SOB	R3,3\$		
620	006214	104037			ERROR	37	; BUT FD, FSRC FAILED.	
621	006216	000524		4\$:	BR	FDONE		
622								
623	006220	104040		FERR10:	ERROR	40	; DATA INCORRECT.	
624	006222	000522			BR	FDONE		
625								
626	006224	011637	001164	FERR20:	MOV	(SP),@#STMP2	; A FSRC FLOW FAILURE RESULTED	
627	006230	010037	001170		MOV	R0,\$STMP4	; IN A BUS-ERROR ON THE 'LDD'.	
628	006234	021627	005542		CMP	(SP),#F4+2	; LOOK LIKE MODE 6 OR 7 ??	
629	006240	001420			BEQ	3\$; YES.	
630	006242	020027	006416		CMP	R0,#FDAT10-2	; NO, LOOK LIKE MODE 5?	
631	006246	001405			BEQ	1\$; YES.	
632	006250	020027	006422		CMP	R0,#FDAT10+2	; NO, LOOK LIKE MODE 3?	
633	006254	001406			BEQ	2\$; YES.	
634	006256	000137	004224		JMP	@#TRP04	; NO -- WHAT THE HELL ????	
635								
636	006262	012737	000325	001172	1\$:	MOV	#325,@#STMP5	; REPORT MODE 5.
637	006270	000407			BR	4\$		
638	006272	012737	000323	001172	2\$:	MOV	#323,@#STMP5	; REPORT MODE 3.
639	006300	000403			BR	4\$		
640	006302	012737	000326	001172	3\$:	MOV	#326,@#STMP5	; REPORT MODE 6 OR 7.
641	006310	022626			4\$:	CMP	(SP)+,(SP)+	
642	006312	104042			ERROR	42		
643	006314	00044			BR	FDONE		
644								
645	006316	011637	001164	FERR25:	MOV	(SP),@#STMP2	; FDST FLOW FAILURE RESULTED	
646	006322	010037	001170		MOV	R0,\$STMP4	; IN A BUS-ERROR ON THE 'STD'.	

647	006326	021627	005752			CMP	(SP),#F11+2	:	LOOK LIKE FDST MODE 6 OR 7?
648	006332	001420				BEQ	3\$:	YES
649	006334	020027	006436			CMP	RO,#FDAT00-2	:	LOOK LIKE MODE 5?
650	006340	001405				BEQ	1\$:	YES
651	006342	020027	006442			CMP	RO,#FDAT00+2	:	LOOK LIKE MODE 3?
652	006346	001406				BEQ	2\$:	YES
653	006350	000137	004224			JMP	@WTRP04	:	NO. ??????????
654									
655	006354	012737	000645	001172	1\$:	MOV	#645,@#STMP5	:	REPORT MODE 5.
656	006362	000407				BR	4\$		
657	006364	012737	000643	001172	2\$:	MOV	#643,@#STMP5	:	REPORT MODE 3
658	006372	000403				BR	4\$		
659	006374	012737	000646	001172	3\$:	MOV	#646,@#STMP5	:	REPORT MODE 6 OR 7.
660	006402	022626			4\$:	CMP	(SP)+,(SP)+		
661	006404	104043				ERROR	43		
662	006406	000430				BR	FDONE		
663									
664	006410	177777	177777	177777		.WORD	-1,-1,-1,-1	:	INSURANCE FOR MODES 3 AND 5.
665	006420	177777				FDAT10:	-1		
666	006422	177777				FDAT11:	-1		
667	006424	177777				FDAT12:	-1		
668	006426	177777				FDAT13:	-1		
669	006430	177777	177777	177777		.WORD	-1,-1,-1,-1		
670	006440	177777				FDAT00:	-1		
671	006442	177777				FDAT01:	-1		
672	006444	177777				FDAT02:	-1		
673	006446	177777				FDAT03:	-1		
674	006450	177777	177777	177777		.WORD	-1,-1,-1,-1		
675	006460	052525				FXDAT0:	052525		
676	006462	031463				FXDAT1:	031463		
677	006464	007417				FXDAT2:	007417		
678	006466	000477				FXDAT3:	000477		
679									
680	006470					FDONE:			
(1)	006470	104412				CLRFPS		::	CLEAR FP STATUS...
(3)	006472	000400				BR	TST7	::	...AND PROCEED.

```

688
(3)
(4)
(4)
(4)
(4)
(3)
(2) 006474 000004
689
690
691
692 006476
(1) 006476 104411
693 006500 170011
694 006502 012700 007262
695 006506 012701 007232
696 006512 012702 000004
697 006516 012120
698 006520 077202
699
700 006522 012737 007046 000004
701 006530 012700 007262
(1) 006534 172510
702 006536 012700 007242
(1) 006542 172410
703 006544 012737 006574 001164
704 006552 012737 007262 001170
705 006560 012737 007252 001172
706 006566 012737 000104 001174
707 006574 172401
708 006576 000240
709 006600 000240
710 006602 012700 007252
(1) 006606 174010
711 006610 004537 004312
712 006614 007262 007252
713 006620 001422
714
715 006622 012700 007256
716 006626 012702 000002
717 006632 005720
718 006634 001002
719 006636 077203
720 006640 000551
721 006642 012700 007256
722 006646 012702 000002
723 006652 022720 177777
724 006656 001002
725 006660 077204
726 006662 000540
727 006664 000524
728
729
730
731 006666
(1) 006666 104411

```

```

*****
*TEST 7          LDD AND LDF -- FSRC MODE 0
*
*THIS IS A TEST OF THE FSRC MODE 0, USING THE INSTRUCTIONS
*  LDD AC1,ACO AND LDF AC1,ACO
*
*****
TST7:  SCOPE
:
: DO THE DOUBLE FIRST (FD=1)
:
I1:
      LUPERR          ;; LOOP HERE ON ERROR IF SWR9 - 1.
      SETD           ;SET FD.
      MOV #IDATIO,R0
      MOV #IPATIO,R1
      MOV #4,R2
1$:  MOV (R1)+,(R0)+ ;SET THE INPUT BUFFER.
      SOB R2,1$
      MOV #IERR0,#ERRVEC ;A BUS-ERROR TRAP MAY OCCUR.
      MOV #IDATIO,R0
      LDD (R0),AC1      ;; LOAD AC1
      MOV #IPATIO,R0
      LDD (R0),ACO      ;; LOAD ACO
      MOV #I3,#STMP2
      MOV #IDATIO,$TMP4 ; EXP DATA ADDRESS.
      MOV #IDATIO,$TMP5 ; RCD
      MOV #I'D,$TMP6    ; FOR ERROR MSG.
I3:  LDD AC1,ACO      ;TEST INSTRUCTION.
I4:  NOP
I5:  MOV #IDATIO,R0
      STD ACO,(R0)     ;; STORE ACO
      JSR R5,CHECK4   ; CHECK IT
      IDATIO,IDATIO
      BEQ I11         ; BR IF OK.
      MOV #IDATIO2,R0 ;SEE IF (BUT FD) FAILED.
      MOV #2,R2
2$:  TST (R0)+
      BNE 3$
      SOB R2,2$
      BR IERR2        ; BUT FD FAILED.
3$:  MOV #IDATIO2,R0
      MOV #2,R2
4$:  CMP #-1,(R0)+
      BNE 5$
      SOB R2,4$
      BR IERR2        ; BUT FD FAILED.
5$:  BR IERR1        ; DATA INCORRECT.
:
: NOW TEST THE LOAD INSTRUCTION WITH FD CLEAR.
:
I11:
      LUPERR          ;; LOOP HERE ON ERROR IF SWR9 - 1.

```

```

732 006670 012700 007232      MOV      #IPAT10,R0
733 006674 012701 007262      MOV      #IDATIO,R1
734 006700 012702 000004      MOV      #4,R2
735 006704 012021          1$:  MOV      (R0)+,(R1)+
736 006706 077202      SOB
737
738 006710 012700 007262      MOV      #IDATIO,R0
(1) 006714 172510          LDD      (R0),AC1      ;; LOAD AC1
739 006716 012700 007242      MOV      #IPAT20,R0
(1) 006722 172410          LDD      (R0),AC0      ;; LOAD AC0
740 006724 012701 000001      MOV      #1,R1
741 006730 012737 006746 001164  MOV      #I14,@#STMP2
742 006736 012737 000106 001174  MOV      #'F,$TMP6      ; FOR ERROR MSG.
743 006744 170001          SETF      ; CLEAR FD.
744 006746 172401          I14:  LDF      AC1,AC0      ; TEST INSTRUCTION.
745 006750 000240          I15:  NOP
746 006752 000240          I16:  NOP
747 006754 170200          STFPS    R0
748 006756 020027 000004      CMP      R0,#4
749 006762 001111          BNE      IERR4      ; FPS IS WRONG.
750
751 006764 170011          I17:  SETD      ; RETURN TO DOUBLE MODE.
752 006766 012700 007252      MOV      #IDATIO,R0
(1) 006772 174010          STD      AC0,(R0)      ;; STORE AC0
753 006774 012737 177777 007266  MOV      #-1,@#IDATI2
754 007002 012737 177777 007270  MOV      #-1,@#IDATI3
755 007010 004537 004312      JSR      R5,CHECK4      ; CHECK RETURN DATA.
756 007014 007262 007252      IDATIO, IDATIO
757 007020 001411          BEQ      1$      ; BR IF OK.
758
759 007022 023737 007256 007236  CMP      @#IDATO2,@#IPAT12      ; DID (BUT FD) FAIL?
760 007030 001042          BNE      IERR1      ; NO
761 007032 023737 007260 007240  CMP      @#IDATO3,@#IPAT13
762 007040 001036          BNE      IERR1      ; NO
763 007042 000452          BR       IERR3      ; YES, BUT FD FAILED.
764
765 007044 000512          1$:  BR       IDONE      ; NO ERRORS.
766
767          ; ON BUS-ERROR COME HERE TO ANALYZE THE FSRC FAILURE.
768
769 007046 022716 006576      IERR0:  CMP      #I4,(SP)      ; MAKE SURE THE TRAP OCCURRED ON
770 007052 001413          BEQ      1$      ; THE INSTRUCTION BEING TESTED.
771 007054 022716 006600      CMP      #I5,(SP)
772 007060 001410          BEQ      1$
773 007062 022716 006750      CMP      #I15,(SP)
774 007066 001405          BEQ      1$
775 007070 022716 006752      CMP      #I16,(SP)
776 007074 001402          BEQ      1$
777 007076 000137 004224      JMP      @#TRP04      ; ???
778 007102 011637 001164          1$:  MOV      (SP),@#STMP2      ; REPORT FAILURE.
779 007106 022626          CMP      (SP)+,(SP)+
780 007110 012737 000627 001166  MOV      #627,@#STMP3
781 007116 012737 000320 001170  MOV      #320,@#STMP4
782 007124 113737 001174 046721  MOVVB   $TMP6,EM47+2      ; 'F' OR 'D' IN TEXT.
783 007132 104047          2$:  ERROR  47      ; SRC MODE 0 TRAPS.
784 007134 000456          BR       IDONE
  
```

```
785  
786  
787  
788 007136 012737 007262 001170  
789 007144 012737 007252 001172  
790 007152 113737 001174 047126  
791 007160 104051  
792 007162 000443  
793  
794  
795  
796 007164 000240 000240  
797 007170 000240 000240  
798 007174 113737 001174 047020  
799 007202 104050  
800 007204 000432  
801  
802  
803  
804 007206 012737 006746 001164  
805 007214 010037 001166  
806 007220 012737 000004 001170  
807 007226 104041  
808 007230 000420  
809  
810 007232 000000  
811 007234 170360  
812 007236 016161  
813 007240 052525  
814  
815 007242 177777  
816 007244 177777  
817 007246 177777  
818 007250 177777  
819  
820 007252 000000  
821 007254 000000  
822 007256 000000  
823 007260 000000  
824  
825 007262 000000  
826 007264 000000  
827 007266 000000  
828 007270 000000  
829  
830 007272  
(1) 007272 104412  
(3) 007274 000400
```

```
      :  
      :REPORT DATA ERROR.  
      :  
IERR1: MOV      #IDATIO,@#STMP4  
      MOV      #IDAT00,@#STMP5  
      MOVSB   $TMP6,EM51+2 ; 'F' OR 'D' IN TEXT.  
1$:    ERROR   51  
      BR      IDONE  
      :  
      :REPORT FAILURE OF (BUT FD)  
      :  
IERR2: 240,240  
IERR3: 240,240  
      MOVSB   $TMP6,EM50+2 ; 'F' OR 'D' IN TEXT.  
1$:    ERROR   50  
      BR      IDONE  
      :  
      :REPORT INCORRECT FPS AFTER LOAD INSTRUCTION.  
      :  
IERR4: MOV      #I14,@#STMP2  
      MOV      R0,@#STMP3  
      MOV      #4,@#STMP4  
1$:    ERROR   41  
      BR      IDONE  
      :  
IPAT10: 0  
IPAT11: 170360  
IPAT12: 016161  
IPAT13: 052525  
      :  
IPAT20: -1  
IPAT21: -1  
IPAT22: -1  
IPAT23: -1  
      :  
IDAT00: 0  
IDAT01: 0  
IDAT02: 0  
IDAT03: 0  
      :  
IDAT10: 0  
IDAT11: 0  
IDAT12: 0  
IDAT13: 0  
      :  
IDONE:  
      CLRFPs  
      BR      TST10 ;: CLEAR FP STATUS...  
                        :...AND PROCEED.
```

```

837      ;*****
(3)      ;*TEST 10      STD AND STF -- FDST MODE 0
(4)      ;*
(4)      ;*THIS IS A TEST OF THE STORE INSTRUCTIONS, STD AND STF, WITH FDST MODE 0.
(4)      ;*
(3)      ;*****
(2) 007276 000004 TST10: SCOPE
838 007300 T1:
(1) 007300 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.
839 007302 170011 SETD ;SET FD
840 007304 012700 010004 MOV #TPAT10,R0
841 007310 012701 010034 MOV #TDAT10,R1
842 007314 012702 000004 MOV #4,R2
843 007320 012021 1$: MOV (R0)+,(R1)+ ;SET UP THE INPUT DATA BUFFER.
844 007322 077202 SOB R2,1$
845
846 007324 012737 007620 000004 MOV #TERRO,@MERRVEC ; A BUS-ERROR TRAP MAY RESULT.
847 007332 012700 010034 MOV #TDAT10,R0
(1) 007336 172410 LDD (R0),AC0 ;: LOAD AC0
848 007340 012700 010014 MCV #TPAT20,R0
(1) 007344 172510 LDD (R0),AC1 ;: LOAD AC1
849 007346 012737 007376 001164 MOV #T3,@$STMP2
850 007354 012737 010034 001170 MOV #TDAT10,$TMP4 ; EXP DATA ADDRESS.
851 007362 012737 010024 001172 MOV #TDAT00,$TMP5 ; RCD DATA ADDRESS.
852 007370 012737 000104 001174 MOV #D,$TMP6 ; FOR ERROR MSG.
853 007376 174001 T3: STD AC0,AC1
854 007400 000240 T4: NOP
855 007402 000240 T5: NOP
856 007404 012700 010024 MOV #TDAT00,R0
(1) 007410 174110 STD AC1,(R0) ;: STORE AC1
857 007412 004537 004312 JSR R5,CHECK4 ; CHECK IT.
858 007416 010034 010024 TDAT10,TDAT00
859 007422 001410 BEQ T11 ; BR IF OK.
860
861 007424 012703 010030 MOV #TDAT02,R3 ;DID (BUT FD) FAIL?
862 007430 012705 000002 MOV #2,R5
863 007434 005723 1$: TST (R3)+
864 007436 001124 BNE TERR1 ; NO, DATA INCORRECT.
865 007440 077503 SOB R5,1$
866 007442 000535 BR TERR2 ; YES, BUT FD FAILED.
867
868 ;NOW TEST THE STF AC0,AC1 INSTRUCTION.
869
870 007444 T11:
(1) 007444 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 1.
871 007446 012700 010004 MOV #TPAT10,R0 ;SET UP THE INPUT DATA BUFFER.
872 007452 012701 010034 MOV #TDAT10,R1
873 007456 012702 000004 MOV #4,R2
874 007462 012021 1$: MOV (R0)+,(R1)+
875 007464 077202 SOB R2,1$
876
877 007466 012700 010034 MOV #TDAT10,R0
(1) 007472 172410 LDD (R0),AC0 ;: LOAD AC0
878 007474 012700 010014 MOV #TPAT20,R0
(1) 007500 172510 LDD (R0),AC1 ;: LOAD AC1
879 007502 012737 007520 001164 MOV #T14,@$STMP2
  
```

880	007510	012737	000106	001174	MOV	#'F,\$TMP6	; FOR ERROR MSG.
881	007516	170001			STF		; CLEAR FD
882	007520	174001			T14:	STF	AC0,AC1
883	007522	000240			T15:	NOP	
884	007524	000240			T16:	NOP	
885	007526	170200			STFPS	RO	
886	007530	020027	000010		CMP	RO,#10	
887	007534	001111			BNE	TERR3	; FPS IS WRONG.
888							
889	007536	170011			SETD		; SET FD.
890	007540	012700	010024		MOV	#TDAT00,RO	
(1)	007544	174110			STD	AC1,(RO)	; STORE AC1
891	007546	012737	177777	010040	MOV	#-1,@TDAT12	
892	007554	012737	177777	010042	MOV	#-1,@TDAT13	
893	007562	004537	004312		JSR	R5,CHECK4	; CHECK DATA.
894	007566	010034	010024		TDAT10,TDAT00		
895	007572	001411			BEQ	T23	; BR IF OK.
896							
897	007574	023737	010030	010010	CMP	@TDAT02,@TPAT12	; DID (BUT FD) FAIL.
898	007602	001042			BNE	TERR1	; NO
899	007604	023737	010032	010012	CMP	@TDAT03,@TPAT13	
900	007612	001036			BNE	TERR1	; NO
901	007614	000452			BR	TERR4	; YES, BUT FD FAILED.
902							
903	007616	000512			T23:	BR	TDONE
904							
905							
906	007620	022716	007400		; TRAP HERE THROUGH VECTOR 4 IF A BUS-ERROR OCCURS.		
907	007624	001413			TERR0:	CMP	#T4,(SP)
908	007626	022716	007402			BEQ	1\$
909	007632	001410				CMP	#T5,(SP)
910	007634	022716	007522			BEQ	1\$
911	007640	001405				CMP	#T15,(SP)
912	007642	022716	007524			BEQ	1\$
913	007646	001402				CMP	#T16,(SP)
914	007650	000137	004224			BEQ	1\$
915						JMP	@TRP04
916	007654	011637	001164		1\$:	MOV	(SP),@STMP2
917	007660	022626				CMP	(SP)+,(SP)+
918	007662	012737	000527	001166		MOV	#527,@STMP3
919	007670	012737	000640	001170		MOV	#640,@STMP4
920	007676	113737	001174	052270		MOVB	\$TMP6,EM121+2 ; 'F' OR 'D' IN TEXT.
921	007704	104121			2\$:	ERROR	121
922	007706	000456				BR	TDONE
923							
924							
925							
926	007710	012737	010034	001170			
927	007716	012737	010024	001172	TERR1:	MOV	#TDAT10,@STMP4
928	007724	113737	001174	052475		MOV	#TDAT00,@STMP5
929	007732	104123				MOVB	\$TMP6,EM123+2 ; 'F' OR 'D' IN TEXT.
930	007734	000443			1\$:	ERROR	123
931						BR	TDONE
932							
933							
934	007736	000240	000240				
					TERR2:	240,240	

```
935 007742 000240 000240 TERR4: 240,240
936 007746 113737 C01174 052367 MOVB $TMP6,EM122+2 ; 'F' OR 'D' IN TEXT.
937 007754 104122 1$: ERROR 122
938 007756 000432 BR TDONE
939
940 ;REPORT INCORRECT FPS AFTER STORE INSTRUCTION.
941
942 007760 012737 007522 001164 TERR3: MOV #15,@$TMP2
943 007766 010037 001166 MOV R0,@$TMP3
944 007772 012737 000010 001170 MOV #10,@$TMP4
945 010000 104041 1$: ERROR 41
946 010002 000420 BR TDONE
947
948 010004 000000 TPAT10: 0
949 010006 170360 TPAT11: 170360
950 010010 016161 TPAT12: 016161
951 010012 052525 TPAT13: 052525
952
953 010014 177777 TPAT20: -1
954 010016 177777 TPAT21: -1
955 010020 177777 TPAT22: -1
956 010022 177777 TPAT23: -1
957
958 010024 000000 TDATA0: 0
959 010026 000000 TDATA1: 0
960 010030 000000 TDATA2: 0
961 010032 000000 TDATA3: 0
962
963 010034 000000 TDATA10: 0
964 010036 000000 TDATA11: 0
965 010040 000000 TDATA12: 0
966 010042 000000 TDATA13: 0
967
968 010044 TDONE:
(1) 010044 104412 CLRFPs ;: CLEAR FP STATUS...
(3) 010046 000400 BR TST11 ;:...AND PROCEED.
```

```

982
(3)
(4)
(4)
(4)
(4)
(4)
(4)
(4)
(4)
(4)
(4)
(3)
(2) 010050 000004
983
984 010052 170011 G1: SETD ; SET DOUBLE MODE.
985 010054 012737 010546 001166 MOV #GPAT,$TMP3 ; SET EXP...
986 010062 012737 010556 001170 MOV #GDAT,$TMP4 ; ...AND REC POINTERS.
987 010070 005003 CLR R3 ; AC NUMBER UNDER TEST.
988 010072 004737 010140 JSR PC,G2 ; TEST AC0.
989 010076 005203 INC R3
990 010100 004737 010140 JSR PC,G2 ; TEST AC1.
991 010104 005203 INC R3
992 010106 004737 010140 JSR PC,G2 ; TEST AC2.
993 010112 005203 INC R3
994 010114 004737 010140 JSR PC,G2 ; TEST AC3.
995 010120 005203 INC R3
996 010122 004737 010140 JSR PC,G2 ; TEST AC4.
997 010126 005203 INC R3
998 010130 004737 010140 JSR PC,G2 ; TEST AC5.
999 010134 000137 010566 JMP GDONE
1000
1001 010140 005037 010546 G2: CLR GPAT ; GO A FLOATING '1' FIRST...
1002 010144 005037 010550 CLR GPAT+2
1003 010150 005037 010552 CLR GPAT+4
1004 010154 012737 000001 010554 MOV #1,GPAT+6
1005 010162 000410 BR G4
1006 010164 005137 010546 G3: COM GPAT ; ...THEN A FLOATING '0'.
1007 010170 005137 010550 COM GPAT+2
1008 010174 005137 010552 COM GPAT+4
1009 010200 005137 010554 COM GPAT+6
1010 010204 012702 000100 G4: MOV #64.,R2 ; 64 BIT LOOP CONTROL.
1011 010210 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 1.
1012 010212 020327 000000 G5: CMP R3,#0
1013 010216 001011 BNE 1$
1014 010220 012737 010226 001164 MOV #.+6,$TMP2
1015 010226 012700 010546 MOV #GPAT,R0
(1) 010232 172410 LDD (R0),AC0 ;: LOAD AC0
1016 010234 012700 010556 MOV #GDAT,R0
(1) 010240 174010 STD AC0,(R0) ;: STORE AC0
1017 010242 020327 000001 1$: CMP R3,#1
1018 010246 001011 BNE 2$
1019 010250 012737 010256 001164 MOV #.+6,$TMP2
1020 010256 012700 010546 MOV #GPAT,R0
(1) 010262 172510 LDD (R0),AC1 ;: LOAD AC1
1021 010264 012700 010556 MOV #GDAT,R0

```


(1)	010270	174110			STD	AC1,(R0)	:: STORE AC1
1022	010272	020327	000002	2\$:	CMP	R3,#2	
1023	010276	001011			BNE	3\$	
1024	010300	012737	010306	001164	MOV	#.+6,\$TMP2	
1025	010306	012700	010546		MOV	#GPAT,R0	
(1)	010312	172610			LDD	(R0),AC2	:: LOAD AC2
1026	010314	012700	010556		MOV	#GDAT,R0	
(1)	010320	174210			STD	AC2,(R0)	:: STORE AC2
1027	010322	020327	000003	3\$:	CMP	R3,#3	
1028	010326	001011			BNE	4\$	
1029	010330	012737	010336	001164	MOV	#.+6,\$TMP2	
1030	010336	012700	010546		MOV	#GPAT,R0	
(1)	010342	172710			LDD	(R0),AC3	:: LOAD AC3
1031	010344	012700	010556		MOV	#GDAT,R0	
(1)	010350	174310			STD	AC3,(R0)	:: STORE AC3
1032	010352	020327	000004	4\$:	CMP	R3,#4	
1033	010356	001013			BNE	5\$	
1034	010360	012737	010366	001164	MOV	#.+6,\$TMP2	
1035	010366	012700	010546		MOV	#GPAT,R0	
(1)	010372	172410			LDD	(R0),AC0	
(1)	010374	174004			STD	AC0,AC4	:: LOAD AC4
1036	010376	012700	010556		MOV	#GDAT,R0	
(1)	010402	172404			LDD	AC4,AC0	
(1)	010404	174010			STD	AC0,(R0)	:: STORE AC4
1037	010406	020327	000005	5\$:	CMP	R3,#5	
1038	010412	001013			BNE	6\$	
1039	010414	012737	010422	001164	MOV	#.+6,\$TMP2	
1040	010422	012700	010546		MOV	#GPAT,R0	
(1)	010426	172410			LDD	(R0),AC0	
(1)	010430	174005			STD	AC0,AC5	:: LOAD AC5
1041	010432	012700	010556		MOV	#GDAT,R0	
(1)	010436	172405			LDD	AC5,AC0	
(1)	010440	174010			STD	AC0,(R0)	:: STORE AC5
1042							
1043	010442	004537	004312	6\$:	JSR	R5,CHECK4	: COMPARE...
1044	010446	010546	010556		GPAT,GDAT		:...EXP VS RECD.
1045	010452	001411			BEQ	7\$: BR IF OK.
1046	010454	010300			MOV	R3,R0	
1047	010456	062700	000060		ADD	#'0',R0	
1048	010462	110037	043377		MOVB	R0,EACN	: SET AC NUMBER.
1049	010466	110037	043417		MOVB	R0,RACN	
1050	010472	104044			ERROR	44	: AC BAD.
1051	010474	000420			BR	8\$	
1052							
1053	010476	012700	010546	7\$:	MOV	#GPA1,R0	: NOW ROTATE PATTERN LEFT.
1054	010502	006160	000006		ROL	6(R0)	
1055	010506	006160	000004		ROL	4(R0)	
1056	010512	006160	000002		ROL	2(R0)	
1057	010516	006110			ROL	(R0)	
1058	010520	042760	000001	000006	BIC	#1,6(R0)	
1059	010526	005560	000006		ADC	6(R0)	: BIT 63 TO BIT 0.
1060	010532	005302			DEC	R2	
1061	010534	001226			BNE	G5	: LOOP FOR 64 ROTATES.
1062							
1063	010536	005737	010546	8\$:	TST	GPAT	: FLOATING A '1' ??
1064	010542	001610			BEQ	G3	: YES, GO ROUND FOR A '0'.

```
1065 010544 000207          RTS    PC          : NO, THIS AC IS DONE, RETURN.
1066
1067 010546 000000 000000 000000 GPAT:  0,0,0,0          : FLOATING DATA PATTERN.
1068 010556 000000 000000 000000 GDAT:  0,0,0,0          : AC DATA RECEIVER.
1069
1070 010566          GDONE:
(1) 010566 104412          CLRFPs          ;; CLEAR FP STATUS...
(3) 010570 000400          BR      TST12    ;; ...AND PROCEED.
```

```

1078
(3)
(4)
(4)
(4)
(4)
(3)
(2) 010572 000004
1079 010574 012727 177777
1080 010600 177777
1081 010602 012700 011222
1082 010606 012701 011342
1083 010612 012703 000024
1084 010616 012120
1085 010620 077302
1086
1087 010622 012700 011222
1088 010626 012701 001166
1089 010632 012702 000012
1090 010636 010021
1091 010640 062700 000010
1092 010644 077204
1093
1094 010646 170011
1095 010650 012700 011222
(1) 010654 172510
1096 010656 012700 011232
(1) 010662 172610
1097 010664 012700 011242
(1) 010670 172710
1098 010672 012700 011252
(1) 010676 172410
(1) 010700 174004
1099 010702 012700 011262
(1) 010706 172410
(1) 010710 174005
1100
1101
1102
1103 010712 012700 011222
1104 010716 010001
1105 010720 012702 000004
1106 010724 005121
1107 010726 172410
1108 010730 174001
1109 010732 004737 011060
1110 010736 077206
1111
1112
1113
1114 010740 012702 000004
1115 010744 010100
1116 010746 005121
1117 010750 172410
1118 010752 174002
1119 010754 004737 011060
  
```

```

*****
*TEST 12 ACCUMULATORS -- DUAL ADDRESSING
*
*THIS TEST PERFORMS A DUAL ADDRESSING TEST ON THE FLOATING ACCUMULATORS.
*NOTE THAT ACCUMULATOR ZERO IS USED TO ACCESS ALL THE OTHERS.
*****
TST12: SCOPE
MOV #-1,(PC)+ ; LOOP FLAG.
H1: -1 ; INITIALIZE THE LOAD BUFFER.
MOV #HA1W,R0
MOV #HDAT1,R1
MOV #20,R3
1$: MOV (R1)+,(R0)+
SOB R3,1$

MOV #HA1W,R0
MOV #STMP3,R1
MOV #12,R2
2$: MOV R0,(R1)+ ; SET UP ERROR TEMPS (3 - 14).
ADD #10,R0
SOB R2,2$

H3: SETD ; INIT ALL AC'S.
MOV #HA1W,R0
LDD (R0),AC1 ;; LOAD AC1
MOV #HA2W,R0
LDD (R0),AC2 ;; LOAD AC2
MOV #HA3W,R0
LDD (R0),AC3 ;; LOAD AC3
MOV #HA4W,R0
LDD (R0),AC0
STD AC0,AC4 ;; LOAD AC4
MOV #HA5W,R0
LDD (R0),AC0
STD AC0,AC5 ;; LOAD AC5

; NOW COMPLIMENT EACH WORD IN AC1 AND RECHECK ALL AC'S.
MOV #HA1W,R0
MOV R0,R1
MOV #4,R2
1$: COM (R1)+ ; COMPLIMENT A WORD...
LDD (R0),AC0 ;...IN AC1.
STD AC0,AC1 ; CHECK RETURNED DATA.
JSR PC,HSTOR
SOB R2,1$

; DO THE SAME FOR AC2.
MOV #4,R2 ; RESET COUNT...
MOV R1,R0 ;...AND UPDATE SRC POINTER.
2$: COM (R1)+ ; COMPLIMENT...
LDD (R0),AC0
STD AC0,AC2
JSR PC,HSTOR ;...AND CHECK.
  
```

```

1120 010760 077206          SOB      R2,2$
1121                      :
1122                      : DITTO AC3.
1123                      :
1124 010762 012702 000004    MOV      #4,R2
1125 010766 010100          MOV      R1,R0
1126 010770 005121          3$:      COM      (R1)+
1127 010772 172410          LDD      (R0),AC0
1128 010774 174003          STD      AC0,AC3
1129 010776 004737 011060    JSR      PC,HSTOR
1130 011002 077206          SOB      R2,3$
1131                      :
1132                      : DITTO AC4.
1133                      :
1134 011004 012702 000004    MOV      #4,R2
1135 011010 010100          MOV      R1,R0
1136 011012 005121          4$:      COM      (R1)+
1137 011014 172410          LDD      (R0),AC0
1138 011016 174004          STD      AC0,AC4
1139 011020 004737 011060    JSR      PC,HSTOR
1140 011024 077206          SOB      R2,4$
1141                      :
1142                      : AND FINALLY, AC5.
1143                      :
1144 011026 012702 000004    MOV      #4,R2
1145 011032 010100          MOV      R1,R0
1146 011034 005121          5$:      COM      (R1)+
1147 011036 172410          LDD      (R0),AC0
1148 011040 174005          STD      AC0,AC5
1149 011042 004737 011060    JSR      PC,HSTOR
1150 011046 077206          SOB      R2,5$
1151                      :
1152 011050 005237 010600    INC      H1
1153 011054 001674          BEQ      H3          ; GO ROUND ONE MORE TIME...
1154 011056 000555          BR       HDONE      ; ...AND QUIT.
1155                      :
1156                      : STORE ALL ACCUMULATORS IN THE OUTPUT BUFFER.
1157                      : AND CHECK AGAINST EXPECTED CONTENTS.
1158                      :
1159 011060 011637 011202    HSTOR:  MOV      (SP),3$          ; COPY RETURN PC.
1160 011064 010016          MOV      R0,(SP)          ; SAVE R0.
1161 011066 004737 011204    JSR      PC,HCLR          ; CLEAR ALL OUTPUT BUFFERS.
1162 011072 012700 011272    MOV      #HA1R,R0
(1) 011076 174110          STD      AC1,(R0)          ;; STORE AC1
1163 011100 012700 011302    MOV      #HA2R,R0
(1) 011104 174210          STD      AC2,(R0)          ;; STORE AC2
1164 011106 012700 011312    MOV      #HA3R,R0
(1) 011112 174310          STD      AC3,(R0)          ;; STORE AC3
1165 011114 012700 011322    MOV      #HA4R,R0
(1) 011120 172404          LDD      AC4,AC0
(1) 011122 174010          STD      AC0,(R0)          ;; STORE AC4
1166 011124 012700 011332    MOV      #HA5R,R0
(1) 011130 172405          LDD      AC5,AC0
(1) 011132 174010          STD      AC0,(R0)          ;; STORE AC5
1167 011134 012600          MOV      (SP)+,R0          ; RESTORE R0.
1168 011136 012703 011222    MOV      #HA1W,R3
  
```

1169	011142	012704	011272		MOV	#HA1R,R4		
1170	011146	012705	000024		MOV	#20.,R5		
1171	011152	022324		1\$:	CMF	(R3)+,(R4)+	; TEST ALL RETURNED AC'S.	
1172	011154	001411			BEQ	2\$		
1173	011156	013737	011202	001164	MOV	3\$,\$TMP2		
1174	011164	162737	000010	001164	SUB	#10,\$TMP2	; SET ERROR PC...	
1175	011172	104046			ERROR	46	;...AND REPORT BAD AC(S).	
1176	011174	000401			SKP1			
1177	011176	077513			SOB	R5,1\$		
1178	011200	000137		2\$:	JMP	@(PC)+		
1179	011202	000000		3\$:		0		
1180					:			
1181					:	CLEAR THE DATA OUTPUT BUFFER.		
1182					:			
1183	011204	012703	011272		HCLR:	MOV	#HA1R,R3	
1184	011210	012704	000024			MOV	#20.,R4	
1185	011214	005023		1\$:	CLR	(R3)+		
1186	011215	077402			SOB	R4,1\$		
1187	011220	000207			RTS	PC		
1188								
1189	011222	000000	000000	000000	HA1W:	.WORD	0,0,0,0	
1190	011232	000000	000000	000000	HA2W:	.WORD	0,0,0,0	
1191	011242	000000	000000	000000	HA3W:	.WORD	0,0,0,0	
1192	011252	000000	000000	000000	HA4W:	.WORD	0,0,0,0	
1193	011262	000000	000000	000000	HA5W:	.WORD	0,0,0,0	
1194								
1195	011272	000000	000000	000000	HA1R:	.WORD	0,0,0,0	
1196	011302	000000	000000	000000	HA2R:	.WORD	0,0,0,0	
1197	011312	000000	000000	000000	HA3R:	.WORD	0,0,0,0	
1198	011322	000000	000000	000000	HA4R:	.WORD	0,0,0,0	
1199	011332	000000	000000	000000	HA5R:	.WORD	0,0,0,0	
1200								
1201	011342	073567	073567	073567	HDATA1:	.WORD	73567,73567,73567,73567	
1202	011352	063146	063146	063146	HDATA2:	.WORD	63146,63146,63146,63146	
1203	011362	010421	010421	010421	HDATA3:	.WORD	10421,10421,10421,10421	
1204	011372	031463	031463	031463	HDATA4:	.WORD	31463,31463,31463,31463	
1205	011402	042104	042104	042104	HDATA5:	.WORD	42104,42104,42104,42104	
1206								
1207	011412				HDONE:			
(1)	011412	104412			CLRFPS		:: CLEAR FP STATUS...	
(3)	011414	000400			BR	TST13	::...AND PROCEED.	

```
1216 .....  
(3) *TEST 13 LDD AND ADDD -- FSRC MODE 0, WITH ILLEGAL ACCUMULATOR  
(4) *  
(4) *THIS IS A TEST OF FSRC MODE 0 WITH ACCUMULATORS 6 AND 7.  
(4) *ANY ATTEMPT TO ACCESS EITHER AC6 OR AC7 SHOULD CAUSE A TRAP  
(4) *TO VECTOR 244, WITH FEC = 2 (ILLEGAL FPP INSTRUCTION).  
(4) *  
(3) .....  
(2) 011416 000004 TST13: SCOPE  
1217 :  
1218 : FIRST THE LOAD CLASS.  
1219 :  
1220 011420 012737 011642 000244 MOV #STRP1,@#FPVEC ; SET FP VECTOR.  
1221 011426 012737 011736 000004 MOV #STRP2,@#ERRVEC ; COULD TRAP TO 4 TOO (NON-EX MEM).  
1222 011434 104411 LUPERR ; LOOP HERE ON ERROR IF SWR9 = 1.  
1223 011436 012737 011462 001164 MOV #S1,$TMP2 ; SET ERROR PC.  
1224 011444 112737 000066 051751 MOVB #'6,EM111X ; AND TEXT.  
1225 011452 170011 SETD ; DOUBLE MODE.  
1226 011454 012700 011632 MOV #SDAT,R0  
(1) 011460 172410 LDD (R0),ACO ;: LOAD ACO  
1227 011462 172406 S1: LDD AC6,ACO ; ACCESS AC6 USING A LDD.  
1228 011464 000241 000241 241,241 ; WE'RE HERE IF IT DIDN'T TRAP !!!  
1229 011470 104111 ERROR 111  
1230 011472 000240 NOP  
1231 011474 012737 011520 001164 MOV #S2,$TMP2 ; CHANGE ERROR PC.  
1232 011502 112737 000067 051751 MOVB #'7,EM111X ; AND TEXT.  
1233 011510 170011 SETD  
1234 011512 012700 011632 MOV #SDAT,R0  
(1) 011516 172410 LDD (R0),ACO ;: LOAD ACO  
1235 011520 172407 S2: LDD AC7,ACO ; AGAIN WITH AC7.  
1236 011522 000241 000241 241,241  
1237 011526 104111 ERROR 111  
1238 011530 000240 NOP  
1239 :  
1240 : NOW THE NOT-LOAD CLASS USING ADDD.  
1241 :  
1242 011532 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.  
1243 011534 012737 011560 001164 MOV #S3,$TMP2 ; CHANGE ERROR PC.  
1244 011542 112737 000066 052025 MOVB #'6,EM112X ; AND TEXT.  
1245 011550 170011 SETD  
1246 011552 012700 011632 MOV #SDAT,R0  
(1) 011556 172410 LDD (R0),ACO ;: LOAD ACO  
1247 011560 172006 S3: ADDD AC6,ACO ; ACCESS AC6 USING ADDD.  
1248 011562 000241 000241 241,241  
1249 011566 104112 ERROR 112  
1250 011570 000240 NOP  
1251 011572 012737 011616 001164 MOV #S4,$TMP2  
1252 011600 112737 000067 052025 MOVB #'7,EM112X  
1253 011606 170011 SETD  
1254 011610 012700 011632 MOV #SDAT,R0  
(1) 011614 172410 LDD (R0),ACO ;: LOAD ACO  
1255 011616 172007 S4: ADDD AC7,ACO ; AGAIN WITH AC7.  
1256 011620 000241 000241 241,241  
1257 011624 104112 ERROR 112  
1258 011626 000240 NOP  
1259 011630 000452 BR SDONE
```

```
1260
1261 011632 010421 021042 031463 SDAT: 10421,21042,31463,42104 ; PRESET VALUE FOR ACO (POS NON-ZERO).
1262
1263
1264
1265 011642 027627 000000 000241 STRP1: CMP @ (SP),#241 ; TRAP ON OUR TEST OPCODE ???
1266 011650 001402 BEQ 1$ ; BR IF SO.
1267 011652 000137 004200 JMP @#TRP244 ; ??? WHAT-THE-HELL ???
1268 011656 170204 1$: STFPS R4 ; GET FPS.
1269 011660 020427 100200 CMP R4,#100200 ; FPS CORRECT ??
1270 011664 001406 BEQ 2$
1271 011666 012737 100200 001170 MOV #100200,$TMP4 ; EXPD...
1272 011674 010437 001166 MOV R4,$TMP3 ; ...AND OBSERVED FPS.
1273 011700 104113 ERROR 113
1274 011702 170304 2$: STST R4 ; GET FEC.
1275 011704 020427 000002 CMP R4,#2 ; FEC RIGHT ??
1276 011710 001406 BEQ 3$
1277 011712 012737 000002 001170 MOV #2,$TMP4
1278 011720 010437 001166 MOV R4,$TMP3
1279 011724 104114 ERROR 114
1280 011726 012604 3$: MOV (SP)+,R4 ; GET RETURN PC...
1281 011730 005726 TST (SP)+ ; ...POP THE STACK.
1282 011732 000164 000006 JMP 6(R4) ; ...AND CONTINUE.
1283
1284
1285
1286 011736 027627 000000 000241 STRP2: CMP @ (SP),#241 ; TRAP ON INSTRUCTION UNDER TEST ???
1287 011744 001402 BEQ 1$
1288 011746 000137 004224 JMP @#TRP04 ; NO, UNEXPECTED TRAP TO 4 !!!
1289 011752 104115 1$: ERROR 115
1290 011754 000400 BR SDONE
1291
1292 SDONE: CLRFPS ;: CLEAR FP STATUS...
(1) 011756 104412 BR TST14 ;: ...AND PROCEED.
(3) 011760 000400
```

```

1299          ;*****
(3)          ;*TEST 14      LDD -- FSRC MODE 2 (AUTO-INCREMENT)
(4)          ;*
(4)          ;* THIS IS A TEST OF FSRC MODE 2, AUTO-INCREMENT MODE.
(4)          ;*
(3)          ;*****
(2) 011762 000004 TST14: SCOPE
1300 011764 J1:
(1) 011764 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 1.
1301 011766 012737 012106 000004 MOV #JERR0,@#ERRVEC
1302 011774 170011 SETD ;:SET DOUBLE MODE
1303 011776 012700 012204 MOV #JDAT0,RO
(1) 012002 172410 LDD (RO),ACO ;: LOAD ACO
1304 012004 012737 012022 001164 MOV #J2,$TMP2
1305 012012 012700 012164 MOV #JDAT10,RO
1306 012016 010037 001166 MOV RO,$TMP3 ; RO BEFORE EXECUTION.
1307 012022 172420 J2: LDD (RO)+,ACO ;:TEST INSTRUCTION
1308 012024 000240 J3: NOP
1309 012026 000240 J4: NOP
1310 012030 010037 001170 MOV RO,$TMP4 ; RO AFTER.
1311 012034 012700 012174 MOV #JDAT00,RO
(1) 012040 174010 STD ACO,(RO) ;: STORE ACO
1312
1313 012042 023727 001170 012174 CMP $TMP4,#JDAT10+10 ; DID IT AUTO-INCR ??
1314 012050 001401 BEQ 1$ ; YES.
1315 012052 104053 ERROR 53 ; NO, ERROR.
1316
1317 012054 004537 004312 1$: JSR R5,CHECK4 ; DATA OK ??
1318 012060 012164 012174 JDAT10,JDAT00
1319 012064 001407 BEQ J7 ; YUP.
1320 012066 012737 012164 001170 MOV #JDAT10,$TMP4
1321 012074 012737 012174 001172 MOV #JDAT00,$TMP5
1322 012102 104054 ERROR 54 ; DATA INCORRECT.
1323
1324 012104 000443 J7: BR JDONE
1325
1326 ;:IF A TRAP THROUGH 4 OCCURS COME HERE
1327
1328 012106 021627 012024 JERR0: CMP (SP),#J3 ;SEE IF THE TRAP
1329 012112 001405 BEQ J10 ;OCCURRED ON THE
1330 012114 021627 012026 CMP (SP),#J4 ;TESTED INSTRUCTION
1331 012120 001402 BEQ J10
1332 012122 000137 004224 JMP @#TRP04
1333
1334 012126 012737 000762 001172 J10: MOV #762,@$TMP5 ;REPORT FSRC FLOW
1335 012134 012737 000322 001174 MOV #322,@$TMP6 ;FAILURE
1336 012142 011637 001164 MOV (SP),@$TMP2
1337 012146 022626 CMP (SP)+,(SP)+
1338 012150 104052 1$: ERROR 52
1339 012152 000420 BR JDONE
1340
1341 012154 010421 021042 042104 JBUF0: 010421,021042,042104,031463
1342
1343 012164 052525 114631 063146 JDAT10: 052525,114631,063146,073567
1344
1345 012174 000000 000000 000000 JDAT00: 0,0,0,0
  
```


1346
1347 012204 177777 177777 177777 JDAT0: -1,-1,-1,-1
1348
1349 012214 JDONE: CLRFP5 :: CLEAR FP STATUS...
(1) 012214 104412 BR TST15 ::...AND PROCEED.
(3) 012216 000400

```

1356          ;:*****
(3)          ;:TEST 15      LDD -- FSRC MODE 4 (AUTO-DECREMENT)
(4)          ;:
(4)          ;:* THIS IS A TEST OF FSRC MODE 4, AUTO-DECREMENT MODE.
(4)          ;:
(3)          ;:*****
(2) 012220 000004 1357: SCOPE
1357 012222 K1:
(1) 012222 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 - 1.
1358 012224 012737 012344 000004 MOV #KERR0,@#ERRVEC
1359 012232 170011 SETD ;: SET DOUBLE MODE
1360 012234 012700 012440 MOV #KPAT0,R0
(1) 012240 172410 LDD (R0),ACO ;: LOAD ACO
1361 012242 012737 012260 001164 MOV #K2,$TMP2
1362 012250 012700 012420 MOV #KBUF0,R0
1363 012254 010037 001166 MOV R0,$TMP3 ;: R0 BEFORE.
1364 012260 172440 K2: LDD -(R0),ACO ;: TEST INSTRUCTION
1365 012262 000240 K3: NOP
1366 012264 000240 K4: NOP
1367 012266 010037 001170 MOV R0,$TMP4 ;: R0 AFTER.
1368
1369 012272 012700 012430 MOV #KDAT00,R0
(1) 012276 174010 STD ACO,(R0) ;: STORE ACO
1370 012300 023727 001170 012410 CMP $TMP4,#KBUF0-10 ;: DID IT AUTO-DECR ??
1371 012306 001401 BEQ 1$ ;: YES.
1372 012310 104056 ERROR 56 ;: NO
1373
1374 012312 004537 004312 1$: JSR R5,CHECK4 ;: DATA CORRECT ??
1375 012316 012410 012430 KDAT10,KDAT00
1376 012322 001407 BEQ K7 ;: YES.
1377 012324 012737 012410 001170 MOV #KDAT10,$TMP4
1378 012332 012737 012430 001172 MOV #KDAT00,$TMP5
1379 012340 104057 ERROR 57 ;: DATA WRONG.
1380
1381 012342 000442 K7: BR KDONE
1382
1383 ;: TRAP HERE ON A BUS-ERROR.
1384
1385 012344 021627 012262 KERR0: CMP (SP),#K3 ;: SEE IF THE ERROR
1386 012350 001405 BEQ K10 ;: OCCURRED AT THE
1387 012352 021627 012264 CMP (SP),#K4 ;: INSTRUCTION TESTED.
1388 012356 001402 BEQ K10
1389 012360 000137 004224 JMP @#TRP04
1390
1391 012364 012737 000762 001172 K10: MOV #762,@#TMP5 ;: REPORT FAILURE IN
1392 012372 012737 000326 001170 MOV #326,@#TMP4 ;: FSRC FLOWS
1393 012400 011637 001164 MOV (SP),@#TMP2
1394 012404 104055 1$: ERROR 55
1395 012406 000420 BR KDONE
1396
1397 012410 052525 114631 063140 KDAT10: .WORD 052525,114631,063140,073567
1398
1399 012420 010421 031463 042104 KBUF0: 010421,031463,042104,021042
1400
1401 012430 000000 000000 00000C KDAT00: 0,0,0,0
1402

```

CJFFAA -- LS111/23 FPF11 DIAGNOSTIC, PART 1
CJFPAA.P11 28-JAN-81 09:50 T15

MACV11 30G(1063) 28-JAN-81 10:06 PAGE 2-29
LDD -- FSRC MODE 4 (AUTO-DECREMENT)

H 5

SEQ 0059

1403 012440 177777 177777 177777 KPATO:

-1,-1,-1,-1

1404

1405 012450 KDONE:

(1) 012450 104412
(3) 012452 000400

CLRFPS
BR TST16

:: CLEAR FP STATUS...
::...AND PROCEED.

1413
 (3)
 (4)
 (4)
 (4)
 (4)
 (3)
 (2) 012454 000004
 1414 012456
 (1) 012456 104411
 1415 012460 170011
 1416 012462 012700 012670
 1417 012466 012701 012660
 1418 012472 012702 000004
 1419 012476 012120
 1420 012500 077202
 1421
 1422 012502 012700 012650
 (1) 012506 172410
 1423 012510 012737 012530 001164
 1424 012516 012700 012670
 1425 012522 010037 001166
 1426 012526 170001
 1427 012530 172420
 1428 012532 000240
 1429 012534 000240
 1430 012536 010037 001170
 1431 012542 170011
 1432 012544 012700 012700
 (1) 012550 174010
 1433 012552 023727 001170 012674
 1434 012560 001401
 1435 012562 104060
 1436
 1437 012564 012737 177777 012674 1\$:
 1438 012572 012737 177777 012676
 1439 012600 004537 004312
 1440 012604 012670 012700
 1441 012610 001416
 1442 012612 012737 012670 001170
 1443 012620 012737 012700 001172
 1444 012626 004537 004312
 1445 012632 012660 012700
 1446 012636 001402
 1447 012640 104061
 1448 012642 000401
 1449 012644 104062 2\$:
 1450
 1451 012646 000420 L6: BR LDONE
 1452
 1453 012650 177777 177777 177777 LPAT10: .WORD -1,-1,-1,-1
 1454
 1455 012660 052525 114631 063142 LPAT20: 052525,114631,063142,073567
 1456
 1457 012670 000000 000000 000000 LDAT10: 0,0,0,0
 1458

```

*****
*TEST 16      LDF -- FSRC MODE 2 (AUTO-INCREMENT)
*
* THIS IS A TEST OF FSRC MODE 2 (AUTO-INCREMENT) IN
* SINGLE PRECISION MODE (FD=0).
*
*****
TST16: SCOPE
L1:
    LUPERR                ;; LOOP HERE ON ERROR IF SWR9 1.
    SETD                  ;; SET DOUBLE MODE
    MOV #LDAT10,R0        ;; SET UP THE INPUT BUFFER.
    MOV #LPAT20,R1
    MOV #4,R2
1$: MOV (R1)+,(R0)+
    SOB R2,1$

    MOV #LPAT10,R0
    LDD (R0),AC0          ;; LOAD ACO
    MOV #L2,$TMP2
    MOV #LDAT10,R0
    MOV R0,$TMP3          ; RO BEFORE.
    SETF
L2: LDF (R0)+,AC0
L3: NOP
    NOP
    MOV R0,$TMP4          ; RO AFTER.
    SETD                  ; SET FD
    MOV #LDAT00,R0
    STD ACO,(R0)          ;; STORE ACO
    CMP $TMP4,#LDAT10+4  ;; DID IT AUTO-INCR ??
    BEQ 1$                ; YES.
    ERROR 60              ; NO.

1$: MOV #-1,@#LDAT10+4
    MOV #-1,@#LDAT10+6
    JSR R5,CHECK4        ; DATA OK ??
    LDAT10,LDAT00
    BEQ L6                ; YES.
    MOV #LDAT10,$TMP4
    MOV #LDAT00,$TMP5
    JSR R5,CHECK4        ; DID BUT FD FAIL ??
    LPAT20,LDAT00
    BEQ 2$                ; YES.
    ERROR 61              ; NO, DATA WRONG.
    SKP1
2$: ERROR 62              ; BUT FD FAILED.

L6: BR LDONE
LPAT10: .WORD -1,-1,-1,-1
LPAT20: 052525,114631,063142,073567
LDAT10: 0,0,0,0
  
```

CJFPAA -- LS111/23 FPF11 DIAGNOSTIC, PART 1 MACY11 30G(1063) J 5 28-JAN-81 10:06 PAGE 2-31
CJFPAA.P11 28-JAN-81 09:50 T16 LDF -- FSRC MODE 2 (AUTO-INCREMENT)

SEQ 0061

1459 012700 000000 000000 000000 LDAT00: 0.0.0.0
1460
1461 012710 LDONE:
(1) 012710 104412 CLRFPs :: CLEAR FP STATUS...
(3) 012712 000400 BR TST17 ::...AND PROCEED.

```

1469          ;*****
(3)          ;*TEST 17      LDD -- FSRC MODE 2 WITH GR7 (PC IMMEDIATE)
(4)          ;*
(4)          ;* THIS IS A TEST OF FSRC MODE 2 USING GR7 (PC).
(4)          ;* THIS IS THE "IMMEDIATE" MODE.
(3)          ;*****
(2) 012714 000004 TST17: SCOPE
1470 012716 M1:
(1) 012716 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.
1471 012720 012737 013062 000004 MOV #MERR3,@#ERRVEC
1472 012726 170011 SETD
1473 012730 012700 013122 MOV #MPAT10,R0
(1) 012734 172410 LDD (R0),AC0 ;: LOAD AC0
1474 012736 012737 012750 001164 MOV #M2,$TMP2
1475 012744 012704 012762 MOV #M2+12,R4 ;: TO CALCULATE RETURN PC.
1476 012750 172427 M2: LDD (PC)+,AC0 ;: TEST INSTRUCTION
1477 012752 005744 TST -(R4) ;: 5744 (SHOULD SKIP THIS ONE)...
1478 012754 005744 TST -(R4) ;: ...AND EXECUTE NEXT 3.
1479 012756 005744 TST -(R4)
1480 012760 005744 TST -(R4)
1481 012762 020427 012754 CMP R4,#M2+4 ;: RETURN TO RIGHT PC ??
1482 012766 001406 BEQ 1$ ;: BR IF SO.
1483 012770 010437 001166 MOV R4,$TMP3
1484 012774 012737 012754 001170 MOV #M2+4,$TMP4
1485 013002 104064 ERROR 64 ;: PC WRONG.
1486
1487 013004 1$:
(1) 013004 012700 013142 MOV #MDAT00,R0
(1) 013010 174010 STD AC0,(R0) ;: STORE AC0
1488 013012 004537 004312 JSR R5,CHECK4 ;: DATA RIGHT ??
1489 013016 013132 013142 MPAT20,MDAT00
1490 013022 001416 BEQ 3$ ;: YES.
1491 013024 012737 013132 001170 MOV #MPAT20,$TMP4
1492 013032 012737 013142 001172 MOV #MDA*00,$TMP5
1493 013040 004537 004312 JSR R5,CHECK4 ;: DID BUT GR7 FAIL ??
1494 013044 012752 013142 M2+2,MDAT00
1495 013050 001402 BEQ 2$ ;: YES.
1496 013052 104066 ERROR 66 ;: NO, DATA INCORRECT.
1497 013054 000401 SKP1
1498 013056 104063 2$: ERROR 63 ;: BUT GR7 FAILED.
1499
1500 013060 000434 3$: BR MDONE
1501
1502 ;: TRAP TO HERE THROUGH 4.
1503
1504 013062 021627 012752 MERR3: CMP (SP),#M2+2 ;: TRAP ON OUR TEST ??
1505 013066 001405 BEQ 1$
1506 013070 021627 012754 CMP (SP),#M2+4
1507 013074 001402 BEQ 1$
1508 013076 000137 004224 JMP TRP04 ;: NO, UNFORSEEN TRAP ???
1509
1510 013102 011637 001166 1$: MOV (SP),@#$TMP3 ;: IF YES REPORT
1511 013106 012737 012754 001170 MOV #M2+4,@#$TMP4 ;: BAD CONSTANT
1512 013114 022626 CMP (SP)+,(SP)+
1513 013116 104065 2$: ERROR 65

```

CJFPAA -- LSI11/23 FPF11 DIAGNOSTIC, PART 1
CJFPAA.P11 28-JAN-81 09:50 T17

L 5
MACY11 30G(1063) 28-JAN-81 10:06 PAGE 2-33
LDD -- FSRC MODE 2 WITH GR7 (PC IMMEDIATE)

SEQ 0063

1514 013120 000414 BR MDONE
1515
1516 013122 177777 177777 177777 MPAT10: -1,-1,-1,-1
1517
1518 013132 005744 000000 000000 MPAT20: 5744,0,0,0
1519
1520 013142 000000 000000 000000 MDAT00: 0,0,0,0
1521
1522 013152 MDONE:
(1) 013152 104412 CLRFP5
(3) 013154 000400 BR TST20

:: CLEAR FP STATUS...
::...AND PROCEED.

```

1529 .....
(3) : *TEST 20 LDD -- FSRC MODE 3 (AUTO-INCR DEFERRED)
(4) : *
(4) : * THIS IS A TEST OF FSRC MODE 3, AUTO INCREMENT DEFERRED.
(4) : *
(3) : .....
(2) 013156 000004 TST20: SCOPE
1530 013160 N1:
(1) 013160 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.
1531 013162 012737 013354 000004 MOV #NERR0,@#ERRVEC ;: IN CASE OF BUS-ERROR.
1532 013170 170011 SETD ;: SET FD MODE
1533 013172 012737 013570 001170 MOV #NDATIO,$TMP4 ;: EXP DATA
1534 013200 012737 013526 001172 MOV #NDAT00,$TMP5 ;: RCD DATA.
1535 013206 012737 013232 001164 MOV #N2,$TMP2
1536 013214 012700 013560 MOV #NPAT10,RO
(1) 013220 172410 LDD (RO),AC0 ;: LOAD AC0
1537 013222 012700 013546 MOV #NPAT20,RO
1538 013226 010037 001166 MOV RO,$TMP3 ;: SAVE RO BEFORE.
1539 013232 172430 N2: LDD @ (RO)+,AC0 ;: TEST INSTRUCTION.
1540 013234 005203 N3: INC R3
1541 013236 005203 N4: INC R3
1542 013240 010046 MOV RO,-(SP) ;: SAVE RO AFTER.
1543 013242 012700 013526 MOV #NDAT00,RO
(1) 013246 174010 STD AC0,(RO) ;: STORE AC0
1544 013250 012600 MOV (SP)+,RO ;: AND RECALL RO.
1545
1546 013252 020027 013550 CMP RO,#NPAT20+2 ;: DID IT AUTO-INCREMENT RIGHT ??
1547 013256 001007 BNE N5 ;: NO, CHECK IJ OUT.
1548 013260 004537 004312 JSR R5,CHECK4 ;: DATA RIGHT ??
1549 013264 013570 013526 NDATIO,NDAT00
1550 013270 001401 BEQ 1$ ;: BR IF SO.
1551 013272 104073 ERROR 73 ;: DATA WRONG.
1552 013274 000541 1$: BR NDONE
1553
1554 013276 020027 013556 N5: CMP RO,#NPAT20+10 ;: DID IT DO MODE 2 ?
1555 013302 001462 BEQ NERR1 ;: YES.
1556 013304 020027 013536 CMP RO,#NPAT20-10 ;: DID IT DO MODE 4 ?
1557 013310 001463 BEQ NERR2 ;: YES.
1558 013312 020027 013546 CMP RO,#NPAT20 ;: MODE 0 OR 1 ??
1559 013316 001012 BNE 1$ ;: NO ???
1560
1561 013320 004537 004312 JSR R5,CHECK4 ;: DID IT DO MODE 0 ??
1562 013324 013560 013526 NPAT10,NDAT00
1563 013330 001457 BEQ NERR3 ;: YES.
1564 013332 004537 004312 JSR R5,CHECK4 ;: DID IT DO MODE 1 ??
1565 013336 013546 013526 NPAT20,NDAT00
1566 013342 001456 BEQ NERR4 ;: YES.
1567 013344 010037 001170 1$: MOV RO,$TMP4 ;: NONE OF THE ABOVE.
1568 013350 104072 ERROR 72 ;: RO WRONG, DON'T KNOW WHY !
1569 013352 000512 BR NDONE
1570
1571 : IF A BUS-ERROR TRAP OCCURS COME HERE
1572 : TO SEE IF THE FAILURE WAS IN THE FSRC FLOW.
1573
1574 013354 022716 013236 NERR0: CMP #N4,(SP) ;: FSRC MODE 6 OR ??
1575 013360 001410 BEQ NERR10 ;: YES.

```


1576	013362	022716	013234			CMP	#N3,(SP)	
1577	013366	001003				BNE	2\$	
1578	013370	020027	013544	1\$:		CMP	RO,#NPAT20-2	:FSRC MODE 5?
1579	013374	001407				BEQ	NERR11	: YES.
1580	013376	000137	004224	2\$:		JMP	@NTRP04	
1581								
1582	013402	011637	001164	NERR10:		MOV	(SP),@N\$TMP2	:WENT TO MODE 6 OR 7.
1583	013406	022626				CMP	(SP)+,(SP)+	
1584	013410	104067		1\$:		ERROR	67	
1585	013412	000472				BR	NDONE	
1586								
1587	013414	011637	001164	NERR11:		MOV	(SP),@N\$TMP2	:WENT TO MODE 5
1588	013420	022626				CMP	(SP)+,(SP)+	
1589	013422	012737	000627	001174		MOV	#627,\$TMP6	
1590	013430	012737	000323	001200		MOV	#323,\$TMP10	
1591	013436	012737	000325	001176		MOV	#325,@N\$TMP7	
1592	013444	104070			1\$:	ERROR	70	
1593	013446	000454				BR	NDONE	
1594								
1595	013450	012737	000322	001176	NERR1:	MOV	#322,@N\$TMP7	:FSRC MODE 2.
1596	013456	000403				SKP3		
1597	013460	012737	000324	001176	NERR2:	MOV	#324,@N\$TMP7	:FSRC MODE 4
1598	013466	000403				SKP3		
1599	013470	012737	000320	001176	NERR3:	MOV	#320,@N\$TMP7	:FSRC MODE 0
1600	013476	000403				SKP3		
1601	013500	012737	000321	001176	NERR4:	MOV	#321,@N\$TMP7	:FSRC MODE 1
1602	013506	012737	000627	001174		MOV	#627,@N\$TMP6	
1603	013514	012737	000323	001200		MOV	#323,@N\$TMP10	
1604	013522	104071			1\$:	ERROR	71	
1605	013524	000425				BR	NDONE	
1606								
1607	013526	000000	000000	000000	NDAT00:	0,0,0,0		
1608								
1609	013536	052525	052525	052525		52525,52525,52525,52525		
1610								
1611	013546	013570	070707	070707	NPAT20:	NDAT10,070707,070707,070707		
1612	013556	000001				.WORD	1	
1613	013560	177777	177777	177777	NPAT10:	-1,-1,-1,-1		
1614								
1615	013570	010421	021042	031463	NDAT10:	010421,021042,031463,042104		
1616								
1617	013600				NDONE:			
(1)	013600	104412				CLRFPS		:: CLEAR FP STATUS...
(3)	013602	000403				BR	TST21	::...AND PROCEED.

```

1624 .....
(3) *TEST 21 LDD -- FSRC MODE 5 (AUTO-DECR DEFERRED)
(4) *
(4) * THIS IS A TEST OF FSRC MODE 5, AUTO DECREMENT DEFERRED.
(4) *
(3) .....
(2) 013604 000004 TST21: SCOPE
1625 013606 01:
(1) 013606 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 - 1.
1626 013610 012737 014002 000004 MOV #OERR0,ERRVEC ;: SET BUS-ERROR TRAP.
1627 013616 170011 SETD ;: SET FD MODE
1628 013620 012737 013660 001164 MOV #O2,$TMP2
1629 013626 012737 014216 001170 MOV #ODATIO,$TMP4
1630 013634 012737 014154 001172 MOV #ODAT00,$TMP5
1631 013642 012700 014206 MOV #OPAT10,R0
(1) 013646 172410 LDD (R0),ACO ;: LOAD ACO
1632 013650 012700 014174 MOV #OPAT21,R0
1633 013654 010037 001166 MOV R0,$TMP3 ;: R0 BEFORE.
1634 013660 172450 02: LDD @-(R0),ACO ;: TEST INSTRUCTION
1635 013662 005203 03: INC R3
1636 013664 005203 04: INC R3
1637 013666 010046 MOV R0,-(SP) ;: SAVE FINAL R0.
1638 013670 012700 014154 MOV #ODAT00,R0
(1) 013674 174010 STD ACO,(R0) ;: STORE ACO
1639 013676 012600 MOV (SP)+,R0 ;: AND RECALL R0.
1640
1641 013700 020027 014172 CMP R0,#OPAT20 ;: WAS R0 DECREMENTED BY 2 ??
1642 013704 001007 BNE O5 ;: NO, CHECK IT OUT.
1643 013706 004537 004312 JSR R5,CHECK4 ;: YES, IS DATA RIGHT ??
1644 013712 014216 014154 ODAT10,ODAT00
1645 013716 001401 BEQ 1$ ;: BR IF SO.
1646 013720 104100 ERROR 100 ;: DATA INCORRECT.
1647 013722 000541 1$: BR ODONE
1648
1649 013724 020027 014204 05: CMP R0,#OPAT21+10 ;: FSRC MODE 2 ??
1650 013730 001462 BEQ OERR1 ;: YES.
1651 013732 020027 014164 CMP R0,#OPAT21-10 ;: FSRC MODE 4?
1652 013736 001463 BEQ OERR2 ;: YES.
1653 013740 020027 014174 CMP R0,#OPAT21 ;: MODE 0 OR 1 ??
1654 013744 001012 BNE 1$ ;: NO ???
1655
1656 013746 004537 004312 JSR R5,CHECK4 ;: IS IT MODE 0 ??
1657 013752 014206 014154 OPAT10,ODAT00
1658 013756 001457 BEQ OERR3 ;: YES.
1659 013760 004537 004312 JSR R5,CHECK4 ;: IS IT MODE 1 ??
1660 013764 014174 014154 OPAT21,ODAT00
1661 013770 001456 BEQ OERR4 ;: YES.
1662
1663 013772 010037 001170 1$: MOV R0,$TMP4 ;: NONE OF THE ABOVE...
1664 013776 104077 ERROR 77 ;: R0 WRONG.
1665 014000 000512 BR ODONE
1666
1667 ;: IF A BUS-ERROR TRAP OCCURS COME
1668 ;: HERE TO SEE IF THE FAILURE WAS IN THE FSRC FLOW.
1669
1670 014002 022716 013664 OERR0: CMP #O4,(SP) ;: FSRC MODE 6 OR ??

```

```

1671 014006 001410          BEQ    OERR10          ; YES.
1672 014010 022716 013662    CMP    #03,(SP)
1673 014014 001003          BNE    2$
1674 014016 020027 014176    1$:   CMP    RO,#OPAT21+2 ;FSRC MODE 3?
1675 014022 001407          BEQ    OERR11          ; YES.
1676 014024 000137 004224    2$:   JMP    @TRP04
1677
1678 014030 011637 001164    OERR10: MOV   (SP),@#STMP2 ;MODE 6 OR 7
1679 014034 022626          CMP    (SP)+,(SP)+
1680 014036 104074          1$:   ERROR 74
1681 014040 000472          BR    ODONE
1682
1683 014042 011637 001164    OERR11: MOV   (SP),@#STMP2 ;WENT TO FSRC MODE 3
1684 014046 022626          CMP    (SP)+,(SP)+
1685 014050 012737 000627 001176    MOV   #627,@#STMP7
1686 014056 012737 000325 001200    MOV   #325,@#STMP10
1687 014064 012737 000323 001174    MOV   #323,@#STMP6
1688 014072 104075          1$:   ERROR 75
1689 014074 000454          BR    ODONE
1690
1691 014076 012737 000322 001174    OERR1:  MOV   #322,@#STMP6 ;FSRC MODE2
1692 014104 000403          SKP3
1693 014106 012737 000324 001174    OERR2:  MOV   #324,@#STMP6 ;FSRC MODE 4
1694 014114 000403          SKP3
1695 014116 012737 000320 001174    OERR3:  MOV   #320,@#STMP6 ;FSRC MODE 0
1696 014124 000403          SKP3
1697 014126 012737 000321 001174    OERR4:  MOV   #321,@#STMP6 ;FSRC MODE 1
1698 014134 012737 000627 001176    MOV   #627,@#STMP7
1699 014142 012737 000325 001200    MOV   #325,@#STMP10
1700 014150 104076          1$:   ERROR 76
1701 014152 000425          BR    ODONE
1702
1703 014154 000000 000000 000000    ODAT00: .WORD 0,0,0,0
1704 014164 052525 052525 052525    .WORD 52525,52525,52525
1705
1706 014172 014216          OPAT20: .WORD ODAT10
1707 014174 070707 070707 070707    OPAT21: .WORD 070707,070707,070707,070707
1708 014204 000001          .WORD 1
1709 014206 177777 177777 177777    OPAT10: .WORD -1,-1,-1,-1
1710
1711 014216 073567 004210 114631    ODAT10: .WORD 073567,004210,114631,125252
1712
1713 014226          ODONE:
(1) 014226 104412          CLRFP5          ;; CLEAR FP STATUS...
(3) 014230 000400          BR    TST22     ;;...AND PROCEED.

```

```

1720 .....
(3) *TEST 22 LDD -- FSRC MODE 6 (INDEX)
(4) *
(4) * THIS IS A TEST OF FSRC MODE 6, INDEX MODE
(4) *
(3) .....
(2) 014232 000004 TST22: SCOPE
1721 014234 P1:
(1) 014234 104411 LUPERR ; LOOP HERE ON ERROR IF SWR9 1.
1722 014236 012737 014402 000004 MOV #PERRO,ERRVEC ; SET BUS-ERROR TRAP.
1723 014244 012737 014306 001164 MOV #P2,$TMP2
1724 014252 012737 014574 001170 MOV #PDATIO,$TMP4
1725 014260 012737 014604 001172 MOV #PDAT00,$TMP5
1726 014266 170011 SETD ;SET FD MODE
1727 014270 012700 014564 MOV #PPAT10,R0
(1) 014274 172410 LDD (R0),AC0 ; LOAD ACO
1728 014276 012700 014333 MOV #PDATIO-241,R0
1729 014302 010037 001166 MOV R0,$TMP3
1730 014306 172460 000241 P2: LDD 241(R0),AC0 ; TEST INSTRUCTION.
1731 014310 P3-P2+2
1732 014312 000241 P4: CLC
1733 014314 000241 CLC
1734 014316 010046 MOV R0,-(SP) ; SAVE R0 AFTER.
1735 014320 012700 014604 MOV #PDAT00,R0
(1) 014324 174010 STD ACO,(R0) ; STORE ACO
1736 014326 012600 MOV (SP)+,R0 ; AND RECALL R0.
1737
1738 014330 020027 014333 CMP R0,#PDATIO-241 ; R0 CORRECT ??
1739 014334 001404 BEQ 1$
1740 014336 010037 001170 MOV R0,$TMP4 ; NO
1741 014342 104102 FRROR 102
1742 014344 000415 BR 3$
1743
1744 014346 004537 004312 1$: JSR R5,CHECK4 ; DATA CORRECT ??
1745 014352 014574 014604 PDATIO,PDAT00
1746 014356 001410 BEQ 3$ ; BR IF SO.
1747 014360 004537 004312 JSR R5,CHECK4 ; NO, DID IT DO MODE 0.
1748 014364 014564 014604 PPAT10,PDAT00
1749 014370 001002 BNE 2$ ; NO.
1750 014372 104103 ERROR 103 ; YES, EXECUTED MODE 0.
1751 014374 000401 SKP1
1752 014376 104104 2$: ERROR 104 ; DATA INCORRECT.
1753 014400 000505 3$: BR PDONE
1754
1755 ;TRAP TO HERE ON A BUS-ERROR.
1756
1757 014402 021627 014310 PERRO: CMP (SP),#P3 ; DID IT INDEX AT ALL ??
1758 014406 001405 BEQ 10$ ; NO, CHECK IT OUT.
1759 014410 021627 014312 CMP (SP),#P4 ; YES, DID IT DO MODE 7?
1760 014414 001445 BEQ 7$ ; YES.
1761 014416 000137 004224 JMP @TRP04 ; ???
1762
1763 014422 020027 014333 10$: CMP R0,#PDATIO-241 ;WAS IT FSRC MODE 1
1764 014426 001414 BEQ 1$
1765 014430 020027 014343 CMP R0,#PDATIO-241+10 ;WAS IT FSRC MODE 2
1766 014434 001415 BEQ 2$

```

1767	014436	020027	014335			CMP	R0,#PDATIO-241+2		;WAS IT FSRC MODE 3
1768	014442	001416				BEQ	3\$		
1769	014444	020027	014323			CMP	R0,#PDATIO-241-10		;WAS IT FSRC MODE 4
1770	014450	001417				BEQ	4\$		
1771	014452	020027	014331			CMP	R0,#PDATIO-241-2		;WAS IT FSRC MODE 5
1772	014456	001420				BEQ	5\$		
1773									
1774	014460	012737	000321	001174	1\$:	MOV	#321,@#STMP6		
1775	014466	000403				SKP3			
1776	014470	012737	000322	001174	2\$:	MOV	#322,@#STMP6		
1777	014476	000403				SKP3			
1778	014500	012737	000323	001174	3\$:	MOV	#323,@#STMP6		
1779	014506	000403				SKP3			
1780	014510	012737	000324	001174	4\$:	MOV	#324,@#STMP6		
1781	014516	000403				SKP3			
1782	014520	012737	000325	001174	5\$:	MOV	#325,@#STMP6		
1783	014526	000403				SKP3			
1784	014530	012737	000327	001174	7\$:	MOV	#327,\$TMP6		
1785	014536	012737	000627	001176		MOV	#627,@#STMP7		;REPORT FSRC
1786	014544	012737	000326	001200		MOV	#326,@#STMP10		;FLOWS FAILURE.
1787	014552	011637	001164			MOV	(SP),@#STMP2		
1788	014556	022626				CMP	(SP)+,(SP)+		
1789	014560	104101				ERROR	101		
1790	014562	000414				BR	PDONE		
1791									
1792	014564	177777	177777	177777	PPAT10:	.WORD	-1,-1,-1,-1		
1793									
1794	014574	010421	031463	052525	PDATIO:	.WORD	010421,031463,052525,073567		
1795									
1796	014604	000000	000000	000000	PDAT00:	.WORD	0.0.0.0		
1797									
1798	014614				PDONE:				
(1)	014614	104412				CLRFPS			:: CLEAR FP STATUS...
(3)	014616	000400				BR	TS123		::...AND PROCEED.

```

1805 .....
(3) : *TEST 23      LDD -- FSRC MODE 7 (INDEX DEFERRED)
(4) : *
(4) : * THIS IS A TEST OF FSRC MODE 7, INDEX DEFERRED.
(4) : *
(3) : .....
(2) 014620 000004 TST23: SCOPE
1806 014622 Q1:
(1) 014622 104411 LUPERR ; LOOP HERE ON ERROR !F SWR9 = 1.
1807 014624 012737 015022 000004 MOV #QERRO,ERRVEC ; SET BUS TRAP.
1808 014632 170011 SETD
1809 014634 012737 014674 001164 MOV #Q2,$TMP2
1810 014642 012737 015206 001170 MOV #QDAT10,$TMP4
1811 014650 012737 015176 001172 MOV #QDAT00,$TMP5
1812 014656 012700 015156 MOV #QPAT10,RO
(1) 014662 172410 LDD (RO),AC0 ; LOAD AC0
1813 014664 012700 014725 MOV #QPAT20-241,RO
1814 014670 010037 001166 MOV RO,$TMP3
1815 014674 172470 000241 Q2: LDD @241(RO),AC0 ; TEST IT.
1816 014676 Q3=Q2+2
1817 014700 000241 Q4: CLC
1818 014702 000241 CLC
1819 014704 010046 MOV RO,-(SP) ; SAVE RO AFTER.
1820 014706 012700 015176 MOV #QDAT00,RO
(1) 014712 174010 STD AC0,(RO) ; STORE AC0
1821 014714 012600 MOV (SP)+,RO AND RECALL RO.
1822
1823 014716 020027 014725 CMP RO,#QPAT20-241 ; RO CORRECT ??
1824 014722 001404 BEQ 1$ ; BR IF SO.
1825 014724 010037 001170 MOV RO,$TMP4
1826 014730 104106 ERROR 106 ; RO INCORRECT.
1827 014732 000431 BR 4$
1828
1829 014734 004537 004312 1$: JSR R5,CHECK4 ; DATA RIGHT ??
1830 014740 015206 015176 QDAT10,QDAT00
1831 014744 001425 BEQ 5$ ; BR IF SO.
1832 014746 004537 004312 JSR R5,CHECK4 ; DID IT DO MODE 0 ??
1833 014752 015156 015176 QPAT10,QDAT00
1834 014756 001406 BEQ 2$ ; YES.
1835 014760 004537 004312 JSR R5,CHECK4 ; DID IT DO MODE 6 ??
1836 014764 015166 015176 QPAT20,QDAT00
1837 014770 001405 BEQ 3$ ; YES.
1838 014772 000411 BR 4$ ; BR IF NEITHER.
1839
1840 014774 012737 000320 001174 2$: MOV #320,$TMP6
1841 015002 000403 SKP3
1842 015004 012737 000326 001174 3$: MOV #326,$TMP6
1843 015012 104107 ERROR 107 ; EXECUTED MODE 0 OR 6.
1844 015014 000401 SKP1
1845 015016 104110 4$: ERROR 110 ; DATA INCORRECT.
1846 015020 000476 5$: BR QDONE
1847
1848 ; TRAP TO HERE ON A BUS-ERROR FAILURE
1849
1850 015022 021627 014676 QERRO: CMP (SP),#Q3
1851 015026 001402 BEQ 1$

```

1852	015030	000137	004224			JMP	@TRP04	
1853								
1854	015034	020027	014725		1\$:	CMP	R0,#QPAT20-241 ;WAS IT FSRC MODE 1 ??	
1855	015040	001003				BNE	2\$	
1856	015042	012737	000321	001174		MOV	#321,@#STMP6	
1857	015050	020027	014735		2\$:	CMP	R0,#QPAT20-241+10 ;WAS IT FSRC 2	
1858	015054	001003				BNE	3\$	
1859	015056	012737	000322	001174		MOV	#322,@#STMP6	
1860	015064	020027	014727		3\$:	CMP	R0,#QPAT20-241+2 ;WAS IT FSRC 3	
1861	015070	001003				BNE	4\$	
1862	015072	012737	000323	001174		MOV	#323,@#STMP6	
1863	015100	020027	014715		4\$:	CMP	R0,#QPAT20-241-10 ;WAS IT FSRC 4	
1864	015104	001003				BNE	5\$	
1865	015106	012737	000324	001174		MOV	#324,@#STMP6	
1866	015114	020027	014723		5\$:	CMP	R0,#QPAT20-241-2 ;WAS IT FSRC 5	
1867	015120	001003				BNE	6\$	
1868	015122	012737	000325	001174		MOV	#325,@#STMP6	
1869								
1870	015130	012737	000627	001176	6\$:	MOV	#627,@#STMP7 ;REPORT FSRC FAILURE	
1871	015136	012737	000327	001200		MOV	#327,@#STMP10	
1872	015144	011637	001164			MOV	(SP),@#STMP2	
1873	015150	022626				CMP	(SP)+,(SP)+	
1874	015152	104105				ERROR	105	
1875	015154	000420				BR	QDONE	
1876								
1877	015156	177777	177777	177777	QPAT10:	.WORD	-1,-1,-1,-1	
1878								
1879	015166	015206	052525	052525	QPAT20:	.WORD	QDAT10,052525,052525,052525	
1880								
1881	015176	000000	000000	000000	QDAT00:	.WORD	0,0,0,0	
1882								
1883	015206	073567	052525	031463	QDAT10:	.WORD	073567,052525,031463,010421	
1884								
1885	015216				QDONE:			
(1)	015216	104412				CLRFPS		:: CLEAR FP STATUS...
(3)	015220	000400				BR	TST24	::...AND PROCEED.

```

1903 .....
(3) *TEST 24 TEST FZ, FN, AND FIUV BITS USING LDD
(4) *
(4) * THIS IS A TEST OF THE (BUT EZBT Y8) FORK, THE
(4) * (BUT ENBT) FORK AND (BUT FIUV) FORK IN THE
(4) * LOAD INSTRUCTION FLOWS.
(4) * EACH OF THE PATTERNS:
(4) * 0
(4) * +NUM
(4) * -NUM
(4) * -0
(4) * IS LOADED TWICE, ONCE WITH AC<>0 THEN
(4) * WITH AC=0. AFTER EACH LOAD THE FPS IS
(4) * CHECK TO INSURE THAT CONTROL WAS PASSED
(4) * THROUGH WITH THE FORKS PROPERLY.
(4) *
(3) .....
(2) 015222 000004 TST24: SCOPE
1904 015224 012737 015532 000244 MOV #U24,FPVEC ; FOR THE FIUV PART.
1905 015232 012727 177777 MOV #-1,(PC)+
1906 015236 177777 U1: -1 ; LOOP FLAG.
1907 015240 012700 177777 MOV #-1,R0 ; BACKGROUND = 1'S FIRST...
1908 015244 000401 SKP1
1909 015246 005000 U2: CLR R0 ;...THEN 0'S.
1910 015250 010037 015550 MOV R0,UPATO
1911 015254 010037 015552 MOV R0,UPATO+2
1912 015260 010037 015554 MOV R0,UPATO+4
1913 015264 010037 015556 MOV R0,UPATO+6
1914
1915 015270 012737 015440 001164 MOV #U5,$TMP2
1916 015276 005003 CLR R3 ; USE AS TRAP FLAG.
1917 015300 012700 015560 MOV #UPAT1,R0 ; DATA = 0'S
1918 015304 012704 000204 MOV #204,R4 ; EXP D AND Z
1919 015310 004737 015416 JSR PC,U3
1920 015314 012700 015570 MOV #UPAT2,R0 ; DATA = +N
1921 015320 012704 000200 MOV #200,R4 ; EXP D ONLY.
1922 015324 004737 015416 JSR PC,U3
1923 015330 012700 015600 MOV #UPAT3,R0 ; DATA = -N
1924 015334 012700 000210 MOV #210,R0 ; EXP D AND N.
1925 015340 004737 015416 JSR PC,U3
1926 015344 012700 015610 MOV #UPAT4,R0 ; DATA = -0
1927 015350 012704 000214 MOV #214,R4 ; EXP D, N, AND Z (FIUV - 0).
1928 015354 004737 015416 JSR PC,U3
1929 015360 005237 015236 INC U1
1930 015364 001730 BEQ U2 ; GO 'ROUND AGAIN...
1931
1932 015366 172427 000000 LDD #0,ACO ; NOW, CLEAR ACO...
1933 015372 012701 004200 MOV #4200,R1 ;...AND SEE IF FIUV WILL...
1934 015376 170101 LDFPS R1 ;...TRAP ON -0.
1935 015400 012704 104214 MOV #104214,R4 ; EXP FPS ???
1936 015404 012703 000014 MOV #14,R3 ; EXP FEC ???
1937 015410 004737 015424 JSR PC,U4
1938 015414 000501 BR UDONE ;...THEN EXIT.
1939
1940 015416 012701 000200 U3: MOV #200,R1
1941 015422 170101 LDFPS R1 ; SET D ONLY.
  
```



```

1942 015424
(1) 015424 104411
1943 015426 012701 015550
1944 015432 172411
1945 015434 000240 000240
1946 015440 172410
1947 015442 000240 000240
1948 015446 005703
1949 015450 001014
1950 015452 170205
1951 015454 020405
1952 015456 001001
1953 015460 000207
1954
1955 015462 010037 001172
1956 015466 010437 001170
1957 015472 010537 001166
1958 015476 104125
1959 015500 000447
1960 015502 104126
1961 015504 000445
1962 015506 104127
1963 015510 000443
1964 015512 010037 001172
1965 015516 010337 001170
1966 015522 010237 001166
1967 015526 104130
1968 015530 000433
1969
1970 015532 022626
1971 015534 005703
1972 015536 001763
1973 015540 170302
1974 015542 020302
1975 015544 001362
1976 015546 000207
1977
1978 015550 000000 000000 000000 UPAT0: 0,0,0,0
1979
1980 015560 000000 000000 000000 UPAT1: 0,0,0,0 ; PATTERN 1 = U
1981
1982 015570 010421 114631 125252 UPAT2: 010421,114631,125252,177777 ; POS NUM.
1983
1984 015600 114631 135673 146314 UPAT3: 114631,135673,146314,167356 ; NEG NUM.
1985
1986 015610 100000 000000 000000 UPAT4: 100000,0,0,0 ; NEG ZERO.
1987
1988 015620
(1) 015620 104412
(3) 015622 000400
U4: LUPERR ; LOOP HERE ON ERROR IF SWR9 - 1.
MOV #UPAT0,R1
LDD (R1),ACO ; SET BACKGROUND.
240,240
U5: LDD (R0),ACO ; CHANGE TO DATA PATTERN.
240,240
TST R3 ; EXPECTING A UV TRAP ??
BNE UERR2 ; YES, BUT IT DIDN'T HAPPEN.
STFPS R5 ; NO, FPS => R5.
CMP R4,R5 ; FPS IS WRONG.
BNE UERR1
RTS PC

UERR1: MOV R0,$TMP5
MOV R4,$TMP4
MOV R5,$TMP3
ERROR 125 ; FPS INCORRECT ETC...
BR UDONE
UERR2: ERROR 126 ; -0 DIDN'T TRAP WITH FIUV = 1.
BR UDONE
UERR3: ERROR 127 ; -0 TRAPPED WITH FIUV = 0.
BR UDONE
UERR4: MOV R0,$TMP5
MOV R3,$TMP4
MOV R2,$TMP3
ERROR 130 ; FEC INCORRECT AFTER TRAP.
BR UDONE

U244: CMP (SP)+,(SP)+
TST R3 ; TRAP EXPECTED ??
BEQ UERR3 ; NO, ERROR.
2$: STST R2 ; YES, GET FEC => R2.
CMP R3,R2
BNE UERR4 ; BR IF IT'S WRONG.
3$: RTS PC

UPAT0: 0,0,0,0
UPAT1: 0,0,0,0 ; PATTERN 1 = U
UPAT2: 010421,114631,125252,177777 ; POS NUM.
UPAT3: 114631,135673,146314,167356 ; NEG NUM.
UPAT4: 100000,0,0,0 ; NEG ZERO.

UDONE:
CLR FPS ; CLEAR FP STATUS...
BR TST25 ;...AND PROCEED.
  
```

```

1996
(3)
(4)
(4)
(4)
(3)
(2) 015624 000004
1997 015626 012737 016156 001172
1998 015634 012737 016156 001176
1999 015642 012737 016166 001174
2000 015650 012737 016176 001200
2001 015656 170011
2002 015660 104411
2003 015662 012700 016156
(1) 015666 172410
2004 015670 012700 016166
2005 015674 172010
2006 015676 012737 015674 001164
2007 015704 004737 016026
2008
2009 015710 104411
2010 015712 012700 016156
(1) 015716 172410
2011 015720 012700 016166
2012 015724 170001
2013 015726 172010
2014 015730 012737 015726 001164
2015 015736 004737 016050
2016
2017 015742 104411
2018 015744 012700 016156
(1) 015750 172410
2019 015752 012700 016166
2020 015756 173010
2021 015760 012737 015756 001164
2022 015766 004737 016026
2023
2024 015772 104411
2025 015774 012700 016156
(1) 016000 172410
2026 016002 012700 016166
2027 016006 170001
2028 016010 173010
2029 016012 012737 016010 001164
2030 016020 004737 016050
2031
2032 016024 000470
2033
2034 016026
2035 016026 112737 000104 053211
2036 016034 112737 000104 053272
2037 016042 012704 000204
2038 016046 000410
2039 016050
2040 016050 112737 000106 053211

```

```

*****
*TEST 25      ADD AND SUB -- FSRC MODE 1, WITH BOTH OPERANDS = 0
*
* THIS IS A TEST OF ADD AND SUB WITH BOTH OPERANDS = 0.
*      0 + 0 = 0 (HOPEFULLY)
*
*****
TST25:  SCOPE
W1:     MOV      #WOP1,$TMP5      ; SET ERROR POINTERS.
        MOV      #WOP1,$TMP7
        MOV      #WOP2,$TMP6
        MOV      #WRES,$TMP10    ; ACTUAL RESULT.
        SETD     ; SET DOUBLE.
        LUPERR   ;; LOOP HERE ON ERROR IF SWR9 = 1.
        MOV      #WOP1,R0
        LDD      (R0),ACO        ;; LOAD ACO
        MOV      #WOP2,R0
1$:     ADDD     (R0),ACO        ; ADDD
        MOV      #1$, $TMP2
        JSR      PC,WERR1       ; CHECK FOR ERRORS.
        LUPERR   ;; LOOP HERE ON ERROR IF SWR9 1.
        MOV      #WOP1,R0
        LDD      (R0),ACO        ;; LOAD ACO
        MOV      #WOP2,R0
        SETF
2$:     ADDF     (R0),ACO        ; ADD FLOAT
        MOV      #2$, $TMP2
        JSR      PC,WERR2
        LUPERR   ;; LOOP HERE ON ERROR IF SWR9 1.
        MOV      #WOP1,R0
        LDD      (R0),ACO        ;; LOAD ACO
        MOV      #WOP2,R0
3$:     SUBD     (R0),ACO        ; SUB DOUBLE.
        MOV      #3$, $TMP2
        JSR      PC,WERR3
        LUPERR   ;; LOOP HERE ON ERROR IF SWR9 1.
        MOV      #WOP1,R0
        LDD      (R0),ACO        ;; LOAD ACO
        MOV      #WOP2,R0
        SETF
4$:     SUBF     (R0),ACO        ; SUB FLOATING.
        MOV      #4$, $TMP2
        JSR      PC,WERR4
        BR       WDONE
WERR1:
WERR3:  MOVB     #'D,EM140X      ; ERROR CHECK ADD...
        MOVB     #'D,EM141X      ; ...AND/OR SUB DOUBLE.
        MOV      #204,R4
        SKP3+3+2
WERR2:
WERR4:  MOVB     #'F,EM140X      ; ERROR CHECK ADD...

```

```

2041 016056 112737 000106 053272
2042 016064 012704 000004
2043
2044 016070 012637 016154
2045 016074 170205
2046 016076 170011
2047 016100 012700 016176
(1) 016104 174010
2048 016106 004537 004312
2049 016112 016156 016176
2050 016116 001002
2051 016120 020405
2052 016122 001413
2053 016124 010437 001166 2$:
2054 016130 010537 001170
2055 016134 027727 163024 173010
2056 016142 001402
2057 016144 104140
2058 016146 000401
2059 016150 104141
2060 016152 000137 3$:
2061 016154 000000 4$:
2062 0
2063 016156 000000 000000 000000 WOP1: .FLT4 0
2064 016166 000000 000000 000000 WOP2: .FLT4 0
2065 016176 000000 000000 000000 WRES: .FLT4 0 ; RECEIVED RESULT.
2066
2067 016206 WDONE:
(1) 016206 104412 CLRFPs ;: CLEAR FP STATUS...
(3) 016210 000400 BR TST26 ;: ...AND PROCEED.
  
```

```

MOVb #'F,EM141X ;...AND/OR SUB SINGLE.
MOV #4,R4
MOV (SP)+,4$ ; IN CASE LOOP IS SET.
STFPS R5 ; FPS => R5.
SETD ; RESTORE DOUBLE MODE.
MOV #WRES,R0
STD ACO,(R0) ;: STORE ACO
JSR R5,CHECK4 ;: COMPARE...
WOP1,WRES ;: ...EXPECTED VS RECEIVED.
BNE 2$ ;: BR IF WRONG.
CMP R4,R5 ;: CHECK FPS.
BEQ 3$
MOV R4,$TMP3
MOV R5,$TMP4
CMP @ $TMP2,#SUBD+10
BEQ +6
ERROR 140 ; ADD ERROR
SKP1
ERROR 141 ; SUB ERROR
JMP @ (PC)+
0
;: RECEIVED RESULT.
CLRFPs ;: CLEAR FP STATUS...
BR TST26 ;: ...AND PROCEED.
  
```

```

2076
(3)
(4)
(4)
(4)
(4)
(4)
(3)
(2) 016212 000004
2077 016214 012737 016556 001172
2078 016222 012737 016606 001200
2079 016230 112737 000104 053211
2080 016236 112737 000104 053272
2081 016244 170011
2082 016246 104411
2083 016250 012700 016566
(1) 016254 172410
2084 016256 010037 001174
2085 016262 010037 001176
2086 016266 012700 016556
2087 016272 172010
2088 016274 012737 016272 001164
2089 016302 004737 016450
2090
2091 016306 104411
2092 016310 012700 016576
(1) 016314 172410
2093 016316 010037 001174
2094 016322 010037 001176
2095 016326 012700 016556
2096 016332 172010
2097 016334 012737 016332 001164
2098 016342 004737 016456
2099
2100 016346 104411
2101 016350 012700 016566
(1) 016354 172410
2102 016356 010037 001174
2103 016362 010037 001176
2104 016366 012700 016556
2105 016372 173010
2106 016374 012737 016372 001164
2107 016402 004737 016450
2108
2109 016406 104411
2110 016410 012700 016576
(1) 016414 172410
2111 016416 010037 001174
2112 016422 010037 001176
2113 016426 012700 016556
2114 016432 173010
2115 016434 012737 016432 001164
2116 016442 004737 016456
2117
2118 016446 000463
2119

```

```

*****
*TEST 26      ADDD AND SUBD -- FSRC MODE 1, WITH SRC OPERAND = 0
*
* THIS IS A TEST OF ADDD AND SUBD WITH JUST THE SRC = 0.
*           N + 0 = N
*           N - 0 = N
*****
TST26:  SCOPE
X1:    MOV    #XOP1,$TMP5      ; SRC OPERAND.
      MOV    #XRES,$TMP10     ; ACTUAL RESULT.
      MOVB   #'D,EM140X
      MOVB   #'D,EM141X
      SE D                      ; SET DOUBLE.
      LUPERR                      ;; LOOP HERE ON ERROR IF SWR9 - 1.
      MOV    #XOP2,R0
      LDD    (R0),ACO          ;; LOAD ACO
      MOV    R0,$TMP6
      MOV    R0,$TMP7
      MOV    #XOP1,R0
1$:    ADDD   (R0),ACO          ; N + 0
      MOV    #1$, $TMP2
      JSR    PC,XERR1          ; CHECK FOR ERRORS.
      LUPERR                      ;; LOOP HERE ON ERROR IF SWR9 1.
      MOV    #XOP3,R0
      LDD    (R0),ACO          ;; LOAD ACO
      MOV    R0,$TMP6
      MOV    R0,$TMP7
      MOV    #XOP1,R0
2$:    ADDD   (R0),ACO          ; -N + 0
      MOV    #2$, $TMP2
      JSR    PC,XERR2
      LUPERR                      ;; LOOP HERE ON ERROR IF SWR9 1.
      MOV    #XOP2,R0
      LDD    (R0),ACO          ;; LOAD ACO
      MOV    R0,$TMP6
      MOV    R0,$TMP7
      MOV    #XOP1,R0
3$:    SUBD   (R0),ACO          ; N - 0
      MOV    #3$, $TMP2
      JSR    PC,XERR3
      LUPERR                      ;; LOOP HERE ON ERROR IF SWR9 1.
      MOV    #XOP3,R0
      LDD    (R0),ACO          ;; LOAD ACO
      MOV    R0,$TMP6
      MOV    R0,$TMP7
      MOV    #XOP1,R0
4$:    SUBD   (R0),ACO          ; -N - 0
      MOV    #4$, $TMP2
      JSR    PC,XERR4
      BR     XDONE

```

2120	016450				XERR1:				
2121	016450	012704	000200		XERR3:	MOV	#200,R4		; EXPECT POS NON-ZERO.
2122	016454	000402				SKP2			
2123	016456				XERR2:				
2124	016456	012704	000210		XERR4:	MOV	#210,R4		; EXPECT NEG NON-ZERO.
2125									
2126	016462	012637	016554			MOV	(SP)+,4\$; IN CASE LOOP IS SET.
2127	016466	170205				STFPS	R5		; FPS => R5.
2128	016470	170011				SETD			; INSURE DOUBLE MODE.
2129	016472	012700	016606			MOV	#XRES,R0		
(1)	016476	174010				STD	AC0,(R0)		:: STORE AC0
2130	016500	013737	001176	016512		MOV	\$TMP7,1\$; SET EXP POINTER.
2131	016506	004537	004312			JSR	R5,CHECK4		
2132	016512	000000	016606		1\$:	0,XRES			; EXP VS RECD.
2133	016516	001002				BNE	2\$		
2134	016520	020405				CMP	R4,R5		; CHECK FPS.
2135	016522	001413				BEQ	3\$		
2136	016524	010437	001166		2\$:	MOV	R4,\$TMP3		
2137	016530	010537	001170			MOV	R5,\$TMP4		
2138	016534	027727	162424	173010		CMP	@\$TMP2,#SUBD+10		
2139	016542	001402				BEQ	:+6		
2140	016544	104140				ERROR	140		; ADD ERROR
2141	016546	000401				SKP1			
2142	016550	104141				ERROR	141		; SUB ERROR
2143	016552	000137			3\$:	JMP	@(PC)+		
2144	016554	000000			4\$:	0			
2145									
2146	016556	000000	000000	000000	XOP1:	.FLT4	0		
2147	016566	010421	021042	031463	XOP2:	010421,021042,031463,042104			; POS N.
2148	016576	104210	114631	125252	XOP3:	104210,114631,125252,135673			; NEG NUM.
2149	016606	000000	000000	000000	XRES:	.FLT4	0		; RECEIVED RESULT.
2150									
2151	016616				XDONE:				
(1)	016616	104412				CLRFPS			:: CLEAR FP STATUS...
(3)	016620	000400				BR	TST27		::...AND PROCEED.

```

2161
(3)
(4)
(4)
(4)
(4)
(4)
(3)
(2) 016622 000004
2162 016624 012727 177777
2163 016630 177777
2164 016632 012737 000210 001170
2165 016640 012737 017032 001172
2166 016646 012737 017042 001176
2167 016654 000411
2168 016656 012737 000200 001170
2169 016664 012737 017042 001172
2170 016672 012737 017032 001176
2171
2172 016700 012737 017022 001174
2173 016706 012737 017052 001200
2174 016714 12737 000104 053272
2175 016722 104411
2176 016724 170011
2177 016726 172427 000000
2178 016732 013700 001172
2179 016736 173010
2180 016740 170205
2181 016742 012700 017052
(1) 016746 174010
2182 016750 013737 001176 016762
2183 016756 004537 004312
2184 016762 000000 017052
2185 016766 001003
2186 016770 023705 001170
2187 016774 001406
2188 016776 012737 016736 001164
2189 017004 010537 001166
2190 017010 104141
2191 017012 005237 016630
2192 017016 001717
2193 017020 000420
2194
2195 017022 000000 000000 000000
2196 017032 063146 052525 042104
2197 017042 163146 052525 042104
2198 017052 000000 000000 000000
2199
2200 017062
(1) 017062 104412
(3) 017064 000400

```

```

*****
*TEST 27      SUBD -- FSRC MODE 1, WITH DST OPERAND  0
*
* THIS IS A TEST OF THE SUBD WITH THE DST OPERAND - 0.
* BOTH POSITIVE AND NEGATIVE SRC OPERANDS ARE TRIED.
*   0 - (+N) = -N
*   0 - (-N) = +N
*****
TST27:  SCOPE
        MOV      #-1,(PC)+
Y1:     -1          ; LOOP FLAG.
        MOV      #210,$TMP4      ; EXPECT NEG NON-ZERO STATUS.
        MOV      #YOP1,$TMP5     ; POS NUM (SRC).
        MOV      #YOP2,$TMP7     ; NEG NUM (EXP RESULT).
        BR       Y3
Y2:     MOV      #200,$TMP4      ; EXPECT POS NON-ZERO STATUS.
        MOV      #YOP2,$TMP5     ; REVERSE THE VALUES.
        MOV      #YOP1,$TMP7
Y3:     MOV      #YOPO,$TMP6     ; DST OPERAND.
        MOV      #YRES,$TMP10    ; RECEIVED RESULT.
        MOV8     #D,EM141X
        LUPERR
        SETD
        LDD      #0,ACO
        MOV      $TMP5,R0
Y4:     SUBD     (R0),ACO        ; 0 - (+N) THEN 0 - (-N).
        STFPS   R5             ; STATUS => R5.
        MOV      #YRES,R0
        STD     ACO,(R0)
        MOV      $TMP7,1$
        JSR     R5,CHECK4
1$:     O,YRES
        RNE     2$
        CP      $TMP4,R5
        L 0
        MOV     #Y4,$TMP2
        MOV     R5,$TMP3
        ERROR   141
3:     INC     Y1
        BEQ    Y2
        BR     YDONE
        ; SUBD ERROR.
        ; REVERSE AND DO AGAIN...
        ;...AND QUIT.
YOPO:   .FLT4  0
YOP1:   063146,052525,042104,167356 ; POS NUM...
YOP2:   163146,052525,042104,167356 ; ...AND IT'S NEG.
YRES:   .FLT4  0 ; RECEIVED RESULT.
YDONE:
        CLRFP
        BR     TST30
        ; CLEAR FP STATUS...
        ;...AND PROCEED.

```

```
2210 *****  
(3) *TEST 30 ADD -- FSRC MODE 1, WITH DST OPERAND = 0  
(4) *  
(4) * THIS IS A TEST OF THE ADD WITH THE DST OPERAND = 0.  
(4) * BOTH POSITIVE AND NEGATIVE SRC OPERANDS ARE TRIED.  
(4) * 0 + (+N) = +N  
(4) * 0 + (-N) = -N  
(3) *****  
(2) 017066 000004 TST30: SCOPE  
2211 017070 012727 177777 MOV #-1,(PC)+  
2212 017074 177777 21: -1 ; LOOP FLAG.  
2213 017076 012737 000200 001170 MOV #200,$TMP4 ; EXPECT POS NON-ZERO STATUS.  
2214 017104 012737 017270 001172 MOV #ZOP1,$TMP5 ; POS NUM (SRC).  
2215 017112 000406 BR Z3  
2216 017114 012737 000210 001170 22: MOV #210,$TMP4 ; EXPECT NEG NON-ZERO STATUS.  
2217 017122 012737 017300 001172 MOV #ZOP2,$TMP5 ; REVERSE THE VALUES.  
2218  
2219 017130 012737 017260 001174 23: MOV #ZOPO,$TMP6 ; DST OPERAND.  
2220 017136 013737 001172 001176 MOV $TMP5,$TMP7 ; EXP RESULT.  
2221 017144 012737 017310 001200 MOV #ZRES,$TMP10 ; RECEIVED RESULT.  
2222 017152 112737 000104 053211 MOVB #'D,EM140X  
2223 017160 104411 LUPERR ; LOOP HERE ON ERROR IF SWR9 1.  
2224 017162 170011 SETD ; SET DOUBLE MODE.  
2225 017164 172427 000000 LDD #0,ACO ; CLEAR ACO.  
2226 017170 013700 001172 MOV $TMP5,R0  
2227 017174 172010 24: ADDD (R0),ACO ; 0 + (+N) THEN 0 + (-N).  
2228 017176 170205 STFPS R5 ; STATUS => R5.  
2229 017200 012700 017310 MOV #ZRES,R0  
(1) 017204 174010 STD ACO,(R0) ; STORE ACO  
2230 017206 013737 001176 017220 MOV $TMP7,1$  
2231 017214 004537 004312 JSR R5,CHECK4 ; COMPARE.  
2232 017220 000000 017310 1$: 0,ZRES ; EXP VS RECD.  
2233 017224 001003 BNE 2$  
2234 017226 023705 001170 CMP $TMP4,R5 ; CHECK FPS TOO.  
2235 017232 001406 BEQ 3$  
2236 017234 012737 017174 001164 2$: MOV #Z4,$TMP2  
2237 017242 010537 001166 MOV R5,$TMP3  
2238 017246 104140 ERROR 140 ; ADDD ERROR.  
2239 017250 005237 017074 3$: INC Z1  
2240 017254 001717 BEQ Z2 ; REVERSE AND DO AGAIN...  
2241 017256 000420 BR ZDONE ; ...AND QUIT.  
2242  
2243 017260 000000 000000 000000 ZOP0: .FLT4 0  
2244 017270 031463 010421 146314 ZOP1: 031463,010421,146314,156735 ; POS N.  
2245 017300 156735 167356 135673 ZOP2: 156735,167356,135673,146314 ; NEG N.  
2246 017310 000000 000000 000000 ZRES: .FLT4 0 ; RECEIVED RESULT.  
2247  
2248 017320 ZDONE:  
(1) 017320 104412 CLRFPS ; CLEAR FP STATUS...  
(3) 017322 000400 BR TST31 ; ...AND PROCEED.
```

2257
(3)
(4)
(4)
(4)
(4)
(3)
(2) 017324 000004
2258 017326
(1) 017326 104411
2259 017330 012700 000240
2260 017334 170100
2261 017336 012737 017766 001172
2262 017344 012737 017756 001176
2263 017352 012737 017400 001164
2264 017360 012700 017766
(1) 017364 172410
2265 017366 012700 017776
2266 017372 010037 001170
2267 017376 000240
2268 017400 172010
2269 017402 170205
2270 017404 010537 001166
2271 017410 170011
2272 017412 012700 017756
(1) 017416 174010
2273 017420 012737 020006 001174
2274 017426 004537 004312
2275 017432 020006 017756
2276 017436 001410
2277 017440 004537 004312
2278 017444 020016 017756
2279 017450 001402
2280 017452 104145
2281 017454 000401
2282 017456 104146
2283
2284
2285
2286 017460
(1) 017460 104411
2287 017462 012700 000200
2288 017466 170100
2289 017470 012737 017520 001164
2290 017476 112737 000104 053423
2291 017504 012700 017766
(1) 017510 172410
2292 017512 012700 017776
2293 017516 000240
2294 017520 172010
2295 017522 170205
2296 017524 010537 001166
2297 017530 170011
2298 017532 012700 017756
(1) 017536 174010

```
*****
*TEST 31      ADDD AND ADDF (EPOXNENTS EQUAL), AND ROUND\TRUNK (BUT FT)
*
* THIS IS A TEST OF THE ADD INSTRUCTIONS WITH THE OPERANDS
* HAVING EQUAL EXPONENTS (ALIGNMENT NOT REQUIRED).
* THE ROUND/TRUNCATE FLOW (BUT FT) IS ALSO TESTED HERE.
*****
TST31:  SCOPE
AA1:
LUPERR                                ;; LOOP HERE ON ERROR IF SWR9  1.
MOV      #240,R0
LDFPS   R0                            ; SET FD AND FT.
MOV      #AAOP0,$TMP5                 ; DST OPERAND FOR ERRORS.
MOV      #AASUM,$TMP7                 ; DITTO RECEIVED SUM.
MOV      #AA2,@$TMP2
MOV      #AAOP0,R0
LDD     (R0),AC0                       ;; LOAD ACO
MOV      #AAOP1,R0
MOV      R0,$TMP4                     ; SRC OPERAND.
NOP
AA2:  ADDD   (R0),AC0                  ; ADD OPO + OP1 AND TRUNCATE.
STFPS   R5
MOV      R5,$TMP3
SETD
MOV      #AASUM,R0
STD     ACO,(R0)                       ;; STORE ACO
MOV      #AAOP2,$TMP6                 ; EXP POINTER.
JSR     R5,CHECK4
AAOP2,AASUM                            ; EXP VS RECD.
BEQ     AA10                           ; BR IF OK.
JSR     R5,CHECK4                      ; IT'S NOT...
AAOP3,AASUM                            ;...DID TRUNCATE FAIL ??
BEQ     1$                             ; YES.
ERROR   145                            ; NO, SUM INCORRECT.
SKP1
1$:     ERROR  146                      ; DIDN'T TRUNCATE.
;
;NOW TEST DOUBLE FLOATING ROUND MODE.
AA10:
LUPERR                                ;; LOOP HERE ON ERROR IF SWR9  1.
MOV      #200,R0
LDFPS   R0                            ; CLEAR FT BIT.
MOV      #AA11,@$TMP2
MOVB    #'D,EM147+3                   ; FOR ERROR 147 TEXT.
MOV      #AAOP0,R0
LDD     (R0),AC0                       ;; LOAD ACO
MOV      #AAOP1,R0
NOP
AA11:  ADDD   (R0),AC0                  ; ADD OPO + OP1 AND ROUND.
STFPS   R5
MOV      R5,$TMP3
SETD
MOV      #AASUM,R0
STD     ACO,(R0)                       ;; STORE ACO
```


2299	017540	012737	020016	001174	MOV	#AOP3,\$TMP6	
2300	017546	004537	004312		JSR	R5,CHECK4	
2301	017552	020016	017756		AAOP3,AASUM		; EXP VS RECD.
2302	017556	001417			BEQ	AA20	; BR IF OK.
2303	017560	004537	004312		JSR	R5,CHECK4	; IT'S NOT...
2304	017564	020006	017756		AAOP2,AASUM		...DID IT TRUNCATE ??
2305	017570	001407			BEQ	1\$; YES.
2306	017572	004537	004312		JSR	R5,CHECK4	; NO, DID IT ROUND F MODE ??
2307	017576	020026	017756		AAOP4,AASUM		
2308	017602	001404			BEQ	2\$; YES.
2309	017604	104145			ERROR	145	; SUM INCORRECT.
2310	017606	000401			SKP1		
2311	017610	104147		1\$:	ERROR	147	; DIDN'T ROUND.
2312	017612	000401			SKP1		
2313	017614	104150		2\$:	ERROR	150	; ROUNDED IN F MODE.
2314							
2315							; NOW ADD AND ROUND IN F MODE.
2316							
2317	017616				AA20:		
(1)	017616	104411			LUPERR		:: LOOP HERE ON ERROR IF SWR9 1.
2318	017620	012700	000200		MOV	#200,RO	
2319	017624	170100			LDFPS	RO	; FT = 0
2320	017626	012737	017662	001164	MOV	#AA21,@#\$TMP2	
2321	017634	112737	000106	053423	MOVB	#'F,EM147+3	; FOR ERROR 147 TEXT.
2322	017642	012700	017766		MOV	#AOP0,RO	
(1)	017646	172410			LDD	(RO),ACO	:: LOAD ACO
2323	017650	012700	020036		MOV	#AOP5,RO	
2324	017654	010037	001170		MOV	RO,\$TMP4	; SRC OPERAND.
2325	017660	170001			SETF		
2326	017662	172010		AA21:	ADDF	(RO),ACO	;ADDF OPO + OP1 AND ROUND.
2327	017664	170205			STFPS	R5	
2328	017666	170011			SETD		;R'ET TO DOUBLE
2329	017670	012700	017756		MOV	#AASUM,RO	
(1)	017674	174010			STD	ACO,(RO)	:: STORE ACO
2330	017676	012737	020046	001174	MOV	#AOP6,\$TMP6	
2331	017704	004537	004312		JSR	R5,CHECK4	
2332	017710	020046	017756		AAOP6,AASUM		; EXP VE RECD.
2333	017714	001460			BEQ	AADONE	; BR IF OK.
2334	017716	004537	004312		JSR	R5,CHECK4	; IT'S NOT...
2335	017722	020006	017756		AAOP2,AASUM		...DID IT TRUNCATE ??
2336	017726	001407			BEQ	1\$; YES.
2337	017730	004537	004312		JSR	R5,CHECK4	; NO...
2338	017734	020016	017756		AAOP3,AASUM		...DID IT ROUND DOUBLE ??
2339	017740	001404			BEQ	2\$; YES.
2340	017742	104145			ERROR	145	; SUM INCORRECT.
2341	017744	000401			SKP1		
2342	017746	104147		1\$:	ERROR	147	; DIDN'T ROUND.
2343	017750	000401			SKP1		
2344	017752	104151		2\$:	ERROR	151	; ROUNDED IN D MODE.
2345	017754	000440			BR	AADONE	
2346							
2347	017756	000000	000000	000000	AASUM:	.FLT4 0	; RECEIVED SUM.
2348	017766	000200	000000	000000	AAOP0:	000200,0,0,0	; EXP 1, MANTISSA 0
2349	017776	000200	000000	000000	AAOP1:	000200,0,0,1	; EXP 1, MANTISSA 1.
2350	020006	000400	000000	000000	AAOP2:	000400,0,0,0	; DOUBLE SUM (0+1), TRUNCATED.
2351	020016	000400	000000	000000	AAOP3:	000400,0,0,1	; DOUBLE SUM (0+1), ROUNDED.

CJFPAA -- LSI11/23 FPF11 DIAGNOSTIC, PART 1
CJFPAA.P11 28-JAN-81 09:50 T31

E 7
MACY11 30G(1063) 28-JAN-81 10:06 PAGE 2-52
ADDD AND ADDF (EPOXNENTS EQUAL), AND ROUND\TRUNK (BUT FT)

SEQ 0082

2352 020026 000400 000000 100000 AAOP4: 000400,0,100000,0 ; DOUBLE SUM (0+1), ROUNDED F.
2353
2354 020036 000200 000001 000000 AAOP5: 000200,1,0,0 ; EXP 1, MANTISSA 1, SINGLE.
2355 020046 000400 000001 000000 AAOP6: 000400,1,0,0 ; SINGLE SUM (0+5), ROUNDED.
2356
2357 020056 AADONE:
(1) 020056 104412 CLRFP5 ;: CLEAR FP STATUS...
(3) 020060 000400 BR TST32 ;: ...AND PROCEED.

```
2369 .....  
(3) *TEST 32 ADDF AND ADDD WITH E(AC) LESS THAN E(FSRC)  
(4) *  
(4) *THIS IS A TEST OF THE ADDD AND ADDF INSTRUCTIONS  
(4) *AND THE ALIGN FDST EXPONENT ALGORITHM.  
(4) *THE ALIGNMENT CONSTANTS 25 FOR FLOATING, AND 57 FOR DOUBLE  
(4) *ARE VERIFIED.  
(4) *NOTE THAT E(AC) IS LESS THAN E(SRC) SO THE OPERAND IN AC  
(4) *(FDST) IS THE ONE TO BE ALIGNED.  
(4) *  
(3) .....  
(2) 020062 000004 TEST32: SCOPE  
2370 :  
2371 : FIRST EXPONENT DIFFERENCE = 58 (72 OCTAL).  
2372 : ALIGNMENT NOT POSSIBLE.  
2373 :  
2374 CC1: 020064  
(1) 020064 104411 LUPERR ;; LOOP HERE ON ERROR IF SWR9 - 1.  
2375 020066 112737 000104 053616 MOVB #'D,EM152X  
2376 020074 170011 SETD ; SET DOUBLE.  
2377 020076 012737 020126 001164 MOV #CC2,@$STMP2  
2378 020104 012700 020744 MOV #CCP0,R0  
(1) 020110 172410 LDD (R0),ACO ;; LOAD ACO  
2379 020112 010037 001172 MOV R0,$STMP5 ; DST OPERAND.  
2380 020116 012700 020764 MOV #CCP2,R0  
2381 020122 010037 001170 MOV R0,$STMP4 ; SRC OPERAND.  
2382 020126 172010 CC2: ADDD (R0),ACO ;TEST INSTRUCTION  
2383 020130 170205 STFPS R5 ;GET FPS  
2384 020132 010537 001166 MOV R5,$STMP3  
2385 020136 012700 020734 MOV #CCSUM,R0  
(1) 020142 174010 STD ACO,(R0) ;; STORE ACO  
2386 020144 004537 004312 JSR R5,CHECK4  
2387 020150 020764 020734 CCP2,CCSUM ; EXP VS RECD.  
2388 020154 001407 BEQ CC7 ; BR IF OK.  
2389 020156 012737 020764 001174 MOV #CCP2,$STMP6 ; EXPECTED.  
2390 020164 012737 020734 001176 MOV #CCSUM,$STMP7  
2391 020172 104152 ERROR 152 ; INCORRECT.  
2392 :  
2393 : NOW EXPONENT DIFF = 57 (71 OCT).  
2394 : MAXIMUM DOUBLE ALIGNMENT.  
2395 :  
2396 CC7: 020174  
(1) 020174 104411 LUPERR ;; LOOP HERE ON ERROR IF SWR9 1.  
2397 020176 170011 SETD ; SET DOUBLE.  
2398 020200 012737 020230 001164 MOV #CC8,@$STMP2  
2399 020206 012700 020744 MOV #CCP0,R0  
(1) 020212 172410 LDD (R0),ACO ;; LOAD ACO  
2400 020214 010037 001172 MOV R0,$STMP5 ;FSRC  
2401 020220 012700 020754 MOV #CCP1,R0  
2402 020224 010037 001170 MOV R0,$STMP4  
2403 020230 172010 CC8: ADDD (R0),ACO ;TEST INSTRUCTION  
2404 020232 170205 STFPS R5 ;GET FPS  
2405 020234 010537 001166 MOV R5,$STMP3  
2406 020240 012700 020734 MOV #CCSUM,R0  
(1) 020244 174010 STD ACO,(R0) ;; STORE ACO  
2407 020246 004537 004312 JSR R5,CHECK4
```

2408	020252	021034	020734		CCP7,CCSUM		: EXP VS RECD.
2409	020256	001407			BEQ CC13		: BR IF OK.
2410	020260	012737	021034	001174	MOV #CCP7,\$TMP6		
2411	020266	012737	020734	001176	MOV #CCSUM,\$TMP7		
2412	020274	104152			ERROR 152		: SUM INCORRECT.
2413							
2414							
2415							
2416							
2417	020276						
(1)	020276	104411			CC13:		
2418	020300	170011			LUPERR		:: LOOP HERE ON ERROR IF SWR9 = 1.
2419	020302	112737	000106	053616	SETD		
2420	020310	012737	020342	001164	MOVB #'F,EM152X		
2421	020316	012700	020744		MOV #CC14,@#\$TMP2		
(1)	020322	172410			MOV #CCP0,R0		
2422	020324	010037	001172		LDD (R0),ACC		:: LOAD ACO
2423	020330	012700	021024		MOV R0,\$TMP5		
2424	020334	010037	001170		MOV #CCP6,R0		:FSRC
2425	020340	170001			MOV R0,\$TMP4		
2426	020342	172010			SETF		: SET FLOAT.
2427	020344	170205			CC14: ADDF (R0),ACO		:TEST INSTRUCTION
2428	020346	010537	001166		STFPS R5		
2429	020352	170011			MOV R5,\$TMP3		
2430	020354	012700	020734		SETD		: RETURN TO DOUBLE.
(1)	020360	174010			MOV #CCSUM,R0		
2431	020362	004537	004312		STD ACO,(R0)		:: STORE ACO
2432	020366	021024	020734		JSR R5,CHECK4		
2433	020372	001407			CCP6,CCSUM		
2434	020374	012737	021024	001174	BEQ CC19		: BR IF OK.
2435	020402	012737	020734	001176	MOV #CCP6,\$TMP6		
2436	020410	104152			MOV #CCSUM,\$TMP7		
2437					ERROR 152		
2438							
2439							
2440	020412						
(1)	020412	104411			CC19:		
2441	020414	170011			LUPERR		:: LOOP HERE ON ERROR IF SWR9 1.
2442	020416	012737	020450	001164	SETD		
2443	020424	012700	020774		MOV #CC20,@#\$TMP2		
(1)	020430	172410			MOV #CCP3,R0		
2444	020432	010037	001172		LDD (R0),ACO		:: LOAD ACO
2445	020436	012700	021014		MOV R0,\$TMP5		
2446	020442	010037	001170		MOV #CCP5,R0		:FSRC
2447	020446	170001			MOV R0,\$TMP4		
2448	020450	172010			SETF		: FLOAT MODE.
2449	020452	170205			CC20: ADDF (R0),ACO		:TEST INSTRUCTION
2450	020454	010537	001166		STFPS R5		
2451	020460	170011			MOV R5,\$TMP3		
2452	020462	012700	020734		SETD		:REENTER DOUBLE MOVE
(1)	020466	174010			MOV #CCSUM,R0		
2453	020470	004537	004312		STD ACO,(R0)		:: STORE ACO
2454	020474	021044	020734		JSR R5,CHECK4		
2455	020500	001407			CCP10,CCSUM		
2456	020502	012737	021044	001174	BEQ CC25		: BR IF OK.
2457	020510	012737	020734	001176	MOV #CCP10,\$TMP6		
					MOV #CCSUM,\$TMP7		

2458 020516 104152
2459
2460
2461
2462
2463 020520
(1) 020520 104411
2464 020522 112737 000104 053616
2465 020530 170011
2466 020532 012737 020562 001164
2467 020540 012700 020744
(1) 020544 172410
2468 020546 010037 001172
2469 020552 012700 020774
2470 020556 010037 001170
2471 020562 172010
2472 020564 170205
2473 020566 010537 001166
2474 020572 012700 020734
(1) 020576 174010
2475 020600 004537 004312
2476 020604 021054 020734
2477 020610 001407
2478 020612 012737 021054 001174
2479 020620 012737 020734 001176
2480 020626 104152
2481
2482
2483
2484
2485 020630
(1) 020630 104411
2486 020632 170011
2487 020634 012737 020664 001164
2488 020642 012700 020744
(1) 020646 172410
2489 020650 010037 001172
2490 020654 012700 021024
2491 020660 010037 001170
2492 020664 172010
2493 020666 170205
2494 020670 010537 001166
2495 020674 012700 020734
(1) 020700 174010
2496 020702 004537 004312
2497 020706 021064 020734
2498 020712 001470
2499 020714 012737 021064 001174
2500 020722 012737 020734 001176
2501 020730 104152
2502 020732 000460
2503
2504 020734 000000 000000 000000
2505 020744 000200 000000 000000
2506 020754 016200 000000 000000
2507 020764 016400 000000 000000

ERROR 152
:
: NOW TRY A MINIMUM ALIGNMENT IN DOUBLE MODE.
: EXPONENT DIFF - 1.
:
:CC25:
LUPERR ;; LOOP HERE ON ERROR IF SWR9 1.
MOV8 #'D,EM152X
SETD
MOV #CC26,@#STMP2
MOV #CCP0,R0
LDD (R0),ACO ;; LOAD ACO
MOV R0,\$TMP5
MOV #CCP3,R0 ;FSRC
MOV R0,\$TMP4
:CC26: ADDD (R0),ACO ;TEST INSTRUCTION
STFPS R5 ;GET FPS
MOV R5,\$TMP3
MOV #CCSUM,R0
STD ACO,(R0) ;; STORE ACO
JSR R5,CHECK4
CCP11,CCSUM
BEQ CC31 ; BR IF OK.
MOV #CCP11,\$TMP6
MOV #CCSUM,\$TMP7
ERROR 152
:
: FINALLY, ONE BETWEEN MAX AND MIN.
: EXPONENT DIFF - 25, DOUBLE MODE.
:
:CC31:
LUPERR ;; LOOP HERE ON ERROR IF SWR9 1.
SETD
MOV #CC32,@#STMP2
MOV #CCP0,R0
LDD (R0),ACO ;; LOAD ACO
MOV R0,\$TMP5
MOV #CCP6,R0 ;FSRC
MOV R0,\$TMP4
:CC32: ADDD (R0),ACO ;TEST INSTRUCTION
STFPS R5 ;GET FPS
MOV R5,\$TMP3
MOV #CCSUM,R0
STD ACO,(R0) ;; STORE ACO
JSR R5,CHECK4
CCP12,CCSUM
BEQ CCDONE
MOV #CCP12,\$TMP6
MOV #CCSUM,\$TMP7
ERROR 152
BR CCDONE
:
:CCSUM: .FLT4 0
: CCP0: 000200,0,0,0 ; EXP = 1
: CCP1: 016200,0,0,0 ; EXP = 57. (71)
: CCP2: 016400,0,0,0 ; EXP = 58. (72)

2508	020774	000400	000000	000000	CCP3:	000400,0,0,0	:	EXP = 2
2509	021004	031200	000000	000000	CCP4:	031200,0,0,0	:	EXP = 101. (145)
2510	021014	006200	000000	000000	CCP5:	006200,0,0,0	:	EXP = 25. (31)
2511	021024	006400	000000	000000	CCP6:	006400,0,0,0	:	EXP = 26. (32)
2512								
2513	021034	016200	000000	000000	CCP7:	016200,0,0,1	:	DOUBLE SUM CCP0+CCP1
2514	021044	006200	000001	000000	CCP10:	006200,1,0,0	:	SINGLE SUM CCP0+CCP5
2515	021054	000500	000000	000000	CCP11:	000500,0,0,0	:	DOUBLE SUM CCP0+CCP3
2516	021064	006400	000000	040000	CCP12:	006400,0,40000,0	:	DOUBLE SUM CCP0+CCP6
2517								
2518	021074				CCDONE:			
(1)	021074	104412			CLRFP5		::	CLEAR FP STATUS...
(3)	021076	000400			BR TST33		::	...AND PROCEED.

```

2529 .....
(3) *TEST 33      ADDF AND ADDD WITH E(AC) GREATER THAN E(FSRC)
(4) *
(4) *THIS IS A TEST OF THE ADDD AND ADDF INSTRUCTIONS
(4) *AND THE ALIGN FSRC EXPONENT ALGORITHM.
(4) *THIS IS THE SAME AS PRECEDING TEST EXCEPT THAT
(4) *E(AC) IS GREATER THAN E(FSRC) SO THE FSRC OPERAND
(4) *IS THE ONE TO BE ALIGNED.
(4) *
(3) .....
(2) 021100 000004 TST33: SCOPE
2530 :
2531 : EXPONENT DIFF EQ OR GT 57. NO ALIGNMENT POSSIBLE.
2532 :
2533 BB1:
(1) 021102 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 - 1.
2534 021104 170011 SETD ;: DOUBLE.
2535 021106 012737 021144 001164 MOV #BB2,$TMP2
2536 021114 112737 000104 053740 MOVB #D,EM153X
2537 021122 012700 022212 MOV #BBP2,R0
(1) 021126 172410 LDD (R0),ACO ;: LOAD ACO
2538 021130 010037 001172 MOV R0,$TMP5
2539 021134 012700 022202 MOV #BBP1,R0 ;:FSRC
2540 021140 010037 001170 MOV R0,$TMP4
2541 021144 172010 BB2: ADDD (R0),ACO ;:TEST INSTRUCTION (EXP DIFF = 57.).
2542 021146 170205 STFPS R5
2543 021150 010537 001166 MOV R5,$TMP3
2544 021154 012700 022152 MOV #BBSUM,R0
(1) 021160 174010 STD ACO,(R0) ;: STORE ACO
2545 021162 004537 004312 JSR R5,CHECK4
2546 021166 022212 022152 BBP2,BBSUM
2547 021172 001407 BEQ BB3
2548 021174 012737 022212 001174 MOV #BBP2,$TMP6
2549 021202 012737 022152 001176 MOV #BBSUM,$TMP7
2550 021210 104153 ERROR 153
2551
2552 021212 012737 021242 001164 BB3: MOV #BB4,$TMP2
2553 021220 012700 022222 MOV #BBP2A,R0
(1) 021224 172410 LDD (R0),ACO ;: LOAD ACO
2554 021226 010037 001172 MOV R0,$TMP5 ;:FSRC
2555 021232 012700 022202 MOV #BBP1,R0
2556 021236 010037 001170 MOV R0,$TMP4
2557 021242 172010 BB4: ADDD (R0),ACO ;:TEST INSTRUCTION (EXP DIFF = 58.).
2558 021244 170205 STFPS R5
2559 021246 010537 001166 MOV R5,$TMP3
2560 021252 012700 022152 MOV #BBSUM,R0
(1) 021256 174010 STD ACO,(R0) ;: STORE ACO
2561 021260 004537 004312 JSR R5,CHECK4
2562 021264 022222 022152 BBP2A,BBSUM
2563 021270 001407 BEQ BB6
2564 021272 012737 022222 001174 MOV #BBP2A,$TMP6
2565 021300 012737 022152 001176 MOV #BBSUM,$TMP7
2566 021306 104153 ERROR 153
2567
2568 :
2569 : NOW EXPONENT DIFF = 56., MAXIMUM DOUBLE ALIGNMENT.

```


2619 021564 010537 001166
 2620 021570 170011
 2621 021572 012700 022152
 (1) 021576 174010
 2622 021600 004537 004312
 2623 021604 022172 022152
 2624 021610 001407
 2625 021612 012737 022172 001174
 2626 021620 012737 022152 001176
 2627 021626 104153
 2628
 2629
 2630
 2631 021630
 (1) 021630 104411
 2632 021632 170011
 2633 021634 012737 021666 001164
 2634 021642 012700 022232
 (1) 021646 172410
 2635 021650 010037 001172
 2636 021654 012700 022202
 2637 021660 010037 001170
 2638 021664 170001
 2639 021666 172010
 2640 021670 170205
 2641 021672 010537 001166
 2642 021676 170011
 2643 021700 012700 022152
 (1) 021704 174010
 2644 021706 004537 004312
 2645 021712 022262 022152
 2646 021716 001407
 2647 021720 012737 022262 001174
 2648 021726 012737 022152 001176
 2649 021734 104153
 2650
 2651
 2652
 2653 021736
 (1) 021736 104411
 2654 021740 170011
 2655 021742 012737 022000 001164
 2656 021750 112737 000104 053740
 2657 021756 012700 022252
 (1) 021762 172410
 2658 021764 010037 001172
 2659 021770 012700 022202
 2660 021774 010037 001170
 2661 022000 172010
 2662 022002 170205
 2663 022004 010537 001166
 2664 022010 012700 022152
 (1) 022014 174010
 2665 022016 004537 004312
 2666 022022 022302 022152
 2667 022026 001407

```

MOV      R5,$TMP3
SETD                               ;RETURN DOUBLE MODE.
MOV      #BBSUM,R0
STD      ACO,(R0)                  ;; STORE ACO
JSR      R5,CHECK4
BBPOA,BBSUM
BEQ      BB20                       ; BR IF OK.
MOV      #BBPOA,$TMP6
MOV      #BBSUM,$TMP7
ERROR    153

; NOW DIFF - 24, MAX SINGLE ALIGNMENT.
BB20:
LUPERR                               ;; LOOP HERE ON ERROR IF SWR9 - 1.
SETD
MOV      #BB21,@$TMP2
MOV      #BBP3,R0
LDD      (R0),ACO                  ;; LOAD ACO
MOV      R0,$TMP5
MOV      #BBP1,R0                  ;FSRC
MOV      R0,$TMP4
SETF                               ; FLOAT.
ADDF      (R0),ACO                 ;TEST INSTRUCTION
STFPS    R5
MOV      R5,$TMP3
SETD                               ;RETURN DOUBLE MODF
MOV      #BBSUM,R0
STD      ACO,(R0)                  ;; STORE ACO
JSR      R5,CHECK4
BBP7,BBSUM
BEQ      BB26
MOV      #BBP7,$TMP6
MOV      #BBSUM,$TMP7
ERROR    153

; NOW A MIMINUM ALIGNMENT IN D MODE
BB26:
LUPERR                               ;; LOOP HERE ON ERROR IF SWR9 1.
SETD
MOV      #BB27,@$TMP2
MOVB     #'D,EM153X
MOV      #BBP5,R0
LDD      (R0),ACO                  ;; LOAD ACO
MOV      R0,$TMP5
MOV      #BBP1,R0                  ;FSRC
MOV      R0,$TMP4
ADDD     (R0),ACO                 ;TEST INSTRUCTION
STFPS    R5
MOV      R5,$TMP3
MOV      #BBSUM,R0
STD      ACO,(R0)                  ;; STORE ACO
JSR      R5,CHECK4
BBP11,BBSUM
BEQ      BB32                       ; BR IF OK.

```

```

2668 022030 012737 022302 001174 MOV #BBP11,$TMP6
2669 022036 012737 022152 001176 MOV #BBSUM,$TMP7
2670 022044 104153 ERROR 153
2671
2672 ; NOW ONE IN THE MIDDLE, DIFF = 25, DOUBLE MODE.
2673
2674 022046 BB32: LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.
(1) 022046 104411 SETD
2675 022050 170011 MOV #BB33,@#$TMP2
2676 022052 012737 022102 001164 MOV #BBP0,R0
2677 022060 012700 022162 LDD (R0),AC0 ;: LOAD AC0
(1) 022064 172410 MOV R0,$TMP5 ;FSRC
2678 022066 010037 001172 MOV #BBP1,R0
2679 022072 012700 022202 MOV R0,$TMP4
2680 022076 010037 001170 BB33: ADDD (R0),AC0 ;:TEST INSTRUCTION
2681 022102 172010 STFPS R5
2682 022104 170205 MOV R5,$TMP3
2683 022106 010537 001166 MOV #BBSUM,R0
2684 022112 012700 022152 STD AC0,(R0) ;: STORE AC0
(1) 022116 174010 JSR R5,CHECK4
2685 022120 004537 004312 BBP12,BBSUM
2686 022124 022312 022152 BEQ BBDONE ; BR IF OK.
2687 022130 001474 MOV #BBP12,$TMP6
2688 022132 012737 022312 001174 MOV #BBSUM,$TMP7
2689 022140 012737 022152 001176 ERROR 153
2690 022146 104153 BR BBDONE
2691 022150 000464
2692
2693 022152 000000 000000 000000 BBSUM: .FLT4 0 ; RECEIVED SUM.
2694 022162 006400 000000 000000 BBP0: 006400,0,0,0 ; EXP = 26. (32)
2695 022172 006600 000000 000000 BBP0A: 006600,0,0,0 ; EXP = 27.
2696 022202 000200 000000 000000 BBP1: 000200,0,0,0 ; EXP = 1.
2697 022212 016400 000000 000000 BBP2: 016400,0,0,0 ; EXP = 58. (72)
2698 022222 016600 000000 000000 BBP2A: 016600,0,0,0 ; EXP = 59.
2699 022232 006200 000000 000000 BBP3: 006200,0,0,0 ; EXP = 25. (31)
2700 022242 016200 000000 000000 BBP4: 016200,0,0,0 ; EXP = 57. (71)
2701 022252 000400 000000 000000 BBP5: 000400,0,0,0 ; EXP = 2.
2702
2703 022262 006200 000001 000000 BBP7: 006200,1,0,0 ; SINGLE SUM 3+1
2704 022272 016200 000000 000000 BBP10: 016200,0,0,1 ; DOUBLE SUM 4+1
2705 022302 000500 000000 000000 BBP11: 000500,0,0,0 ; DOUBLE SUM 5+1
2706 022312 006400 000000 040000 BBP12: 006400,0,40000,0 ; DOUBLE SUM 1+0
2707
2708 BBDONE: CLRFPS ;: CLEAR FP STATUS...
(1) 022322 104412 BR TST34 ;:...AND PROCEED.
(3) 022324 000400

```

```

2716 .....
(3) *TEST 34      ADD WITH POSITIVE AND NEGATIVE OPERANDS
(4) *
(4) *THIS IS A TEST OF THE ADD INSTRUCTION USING BOTH
(4) *POSITIVE AND NEGATIVE OPERANDS.
(3) .....
(2) 022326 000004 TST34: SCOPE
2717 *
2718 * FIRST, BOTH OPERANDS NEGATIVE
2719 *
2720 DD1:
(1) 022330 LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.
2721 022332 104411 MOV #DDSUM,$TMP7 ;: SET RECEIVED POINTER.
2722 022340 170011 SETD ;: DOUBLE MODE.
2723 022342 012737 023204 001176 MOV #DD2,@$TMP2
2724 022350 012700 023224 MOV #DDP1,R0
(1) 022354 172410 LDD (R0),ACO ;: LOAD ACO
2725 022356 010037 001172 MOV R0,$TMP5
2726 022362 012700 023224 MOV #DDP1,R0 ;:ESRC
2727 022366 010037 001170 MOV R0,$TMP4
2728 022372 172010 DD2: ADDD (R0),ACO ;:TEST INSTRUCTION
2729 022374 170205 STFPS R5 ;:GET FPS
2730 022376 010537 001166 MOV R5,$TMP3
2731 022402 012700 023204 MOV #DDSUM,R0
(1) 022406 174010 STD ACO,(R0) ;: STORE ACO
2732 022410 004537 004312 JSR R5,CHECK4
2733 022414 023324 023204 DDP9,DDSUM
2734 022420 001404 BEQ DD7 ; BR IF CORRECT.
2735 022422 012737 023224 001174 MOV #DDP9,$TMP6
2736 022430 104154 ERROR 154
2737 *
2738 * AC POS, SRC NEG, EQUAL MAGNITUDE.
2739 *
2740 DD7:
(1) 022432 LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.
2741 022434 170011 SETD
2742 022436 012737 022466 001164 MOV #DD8,@$TMP2
2743 022444 012700 023234 MOV #DDP2,R0
(1) 022450 172410 LDD (R0),ACO ;: LOAD ACO
2744 022452 010037 001172 MOV R0,$TMP5
2745 022456 012700 023224 MOV #DDP1,R0 ;:FSPC
2746 022462 010037 001170 MOV R0,$TMP4
2747 022466 172010 DD8: ADDD (R0),ACO ;:TEST INSTRUCTION
2748 022470 170205 STFPS R5 ;:GET FPS
2749 022472 010537 001166 MOV R5,$TMP3
2750 022476 012700 023204 MOV #DDSUM,R0
(1) 022502 174010 STD ACO,(R0) ;: STORE ACO
2751 022504 004537 004312 JSR R5,CHECK4
2752 022510 023214 023204 DDPO,DDSUM
2753 022514 001404 BEQ DD12 ; BR IF OK.
2754 022516 012737 023214 001174 MOV #DDPO,$TMP6
2755 022524 104154 ERROR 154
2756 *
2757 * AC NEG, SRC POS, EQUAL MAGNITUDE.
2758 *

```

```
2759 022526 DD12: LUPERR ;; LOOP HERE ON ERROR IF SWR9 - 1.
(1) 022526 104411 SETD
2760 022530 170011 MOV #DD13,@#$TMP2
2761 022532 012737 022562 001164 MOV #DDP1,R0
2762 022540 012700 023224 LDD (R0),AC0 ;; LOAD AC0
(1) 022544 172410 MOV R0,$TMP5
2763 022546 010037 001172 MOV #DDP2,R0 ;FSRC
2764 022552 012700 023234 MOV R0,$TMP4
2765 022556 010037 001170 DD13: ADDD (R0),AC0 ;TEST INSTRUCTION
2766 022562 172010 STFPS R5 ;GET FPS
2767 022564 170205 MOV R5,$TMP3
2768 022566 010537 001166 MOV #DDSUM,R0
2769 022572 012700 023204 STD AC0,(R0) ;; STORE AC0
(1) 022576 174010 JSR R5,CHECK4
2770 022600 004537 004312 DDP0,DDSUM
2771 022604 023214 023204 BEQ DD16 ; BR IF OK.
2772 022610 001404 MOV #DDP0,$TMP6
2773 022612 012737 023214 001174 ERROR 154
2774 022620 104154
2775
2776 ;; AC POS, SRC NEG, AC > SRC
2777
2778 DD16: LUPERR ;; LOOP HERE ON ERROR IF SWR9 1.
(1) 022622 104411 SETD
2779 022624 170011 MOV #DD17,@#$TMP2
2780 022626 012737 022656 001164 MOV #DDP3,R0
2781 022634 012700 023244 LDD (R0),AC0 ;; LOAD AC0
(1) 022640 172410 MOV R0,$TMP5
2782 022642 010037 001172 MOV #DDP6,R0 ;ESPC
2783 022646 012700 023274 MOV R0,$TMP4
2784 022652 010037 001170 DD17: ADDD (R0),AC0 ;TEST INSTRUCTION
2785 022656 172010 STFPS R5 ;GET FPS
2786 022660 170205 MOV R5,$TMP3
2787 022662 010537 001166 MOV #DDSUM,R0
2788 022666 012700 023204 STD AC0,(R0) ;; STORE AC0
(1) 022672 174010 JSR R5,CHECK4
2789 022674 004537 004312 DDP7,DDSUM
2790 022700 023304 023204 BEQ DD22 ; BR IF OK.
2791 022704 001404 MOV #DDP7,$TMP6
2792 022706 012737 023304 001174 ERROR 154
2793 022714 104154
2794
2795 ;; AC NEG, SRC POS, AC < SRC
2796
2797 DD22: LUPERR ;; LOOP HERE ON ERROR IF SWR9 - 1.
(1) 022716 104411 SETD
2798 022720 170011 MOV #DD23,@#$TMP2
2799 022722 012737 022752 001164 MOV #DDP6,R0
2800 022730 012700 023274 LDD (R0),AC0 ;; LOAD AC0
(1) 022734 172410 MOV R0,$TMP5
2801 022736 010037 001172 MOV #DDP3,R0 ;FSPC
2802 022742 012700 023244 MOV R0,$TMP4
2803 022746 010037 001170 DD23: ADDD (R0),AC0 ;TEST INSTRUCTION
2804 022752 172010 STFPS R5 ;GET FPS
2805 022754 170205 MOV R5,$TMP3
2806 022756 010537 001166
```

2807	022762	012700	023204		MOV	#DDSUM,RO		
(1)	022766	174010			STD	ACO,(RO)	::	STORE ACO
2808	022770	004537	004312		JSR	R5,CHECK4		
2809	022774	023304	023204		DDP7,DDSUM			
2810	023000	001404			BEQ	DD30	:	BR IF OK.
2811	023002	012737	023304	001174	MOV	#DDP7,\$TMP6		
2812	023010	104154			ERROR	154		
2813					:			
2814					:	AC POS, SRC NEG, AC < SRC		
2815					:			
2816	023012				DD30:			
(1)	023012	104411			LUPERR		::	LOOP HERE ON ERROR IF SWR9 - 1.
2817	023014	170011			SETD			
2818	023016	012737	023046	001164	MOV	#DD31,@#\$TMP2		
2819	023024	012700	023254		MOV	#DDP4,RO		
(1)	023030	172410			LDD	(RO),ACO	::	LOAD ACO
2820	023032	010037	001172		MOV	RO,\$TMP5		
2821	023036	012700	023264		MOV	#DDP5,RO		;FSPC
2822	023042	010037	001170		MOV	RO,\$TMP4		
2823	023046	172010			DD31:	ADD (RO),ACO		;TEST INSTRUCTION
2824	023050	170205			STFPS	R5		;GET FPS
2825	023052	010537	001166		MOV	R5,\$TMP3		
2826	023056	012700	023204		MOV	#DDSUM,RO		
(1)	023062	174010			STD	ACO,(RO)	::	STORE ACO
2827	023064	004537	004312		JSR	R5,CHECK4		
2828	023070	023314	023204		DDP8,DDSUM			
2829	023074	001404			BEQ	DD36	:	BR IF OK.
2830	023076	012737	023314	001174	MOV	#DDP8,\$TMP6		
2831	023104	104154			ERROR	154		
2832					:			
2833					:	AC NEG, SRC POS, AC > SRC		
2834					:			
2835	023106				DD36:			
(1)	023106	104411			LUPERR		::	LOOP HERE ON ERROR IF SWR9 - 1.
2836	023110	170011			SETD			
2837	023112	012737	023142	001164	MOV	#DD37,@#\$TMP2		
2838	023120	012700	023264		MOV	#DDP5,RO		
(1)	023124	172410			LDD	(RO),ACO	::	LOAD ACO
2839	023126	010037	001172		MOV	RO,\$TMP5		
2840	023132	012700	023254		MOV	#DDP4,RO		;FSRC
2841	023136	010037	001170		MOV	RO,\$TMP4		
2842	023142	172010			DD37:	ADD (RO),ACO		;TEST INSTRUCTION
2843	023144	170205			STFPS	R5		;GET FPS
2844	023146	010537	001166		MOV	R5,\$TMP3		
2845	023152	012700	023204		MOV	#DDSUM,RO		
(1)	023156	174010			STD	ACO,(RO)	::	STORE ACO
2846	023160	004537	004312		JSR	R5,CHECK4		
2847	023164	023314	023204		DDP8,DDSUM			
2848	023170	001404			BEQ	1\$:	BR IF OK.
2849	023172	012737	023314	00 174	MOV	#DDP8,\$TMP6		
2850	023200	104154			ERROR	154		
2851	023202	000454			1\$:	BR		DDDONE
2852								
2853	023204	000000	000000	000000	DDSUM:	.FLT4 0		; RECEIVED SUM.
2854	023214	000000	000000	000000	DDP0:	.FLT4 0		; FLOATING 0.
2855	023224	100200	000000	000000	DDP1:	100200,0,0,0		; -P2.

2856	023234	000200	000000	000000	DDP2:	000200,0,0,0	
2857	023244	001100	000000	000000	DDP3:	001100,0,0,0	
2858	023254	000600	000000	000000	DDP4:	000600,0,0,0	
2859	023264	101100	000000	000000	DDP5:	101100,0,0,0	: -P3
2860	023274	100600	000000	000000	DDP6:	100600,0,0,0	: -P4
2861	023304	001000	000000	000000	DDP7:	001000,0,0,0	: SUM P3+P6
2862	023314	101000	000000	000000	DDP8:	101000,0,0,0	: SUM F5+P4
2863	023324	100400	000000	000000	DDP9:	100400,0,0,0	: SUM P1+P1
2864							
2865	023334				DDDONE:		
(1)	023334	104412			CLRFP5		:: CLEAR FP STATUS...
(3)	023336	000400			BR TST35		::...AND PROCEED.

2873
(3)
(4)
(4)
(4)
(4)
(3)
(2) 023340 000004
2874
2875
2876
2877 023342
(1) 023342 104411
2878 023344 012737 023732 001176
2879 023352 170011
2880 023354 012737 023404 001164
2881 023362 012700 023742
(1) 023366 172410
2882 023370 010037 001172
2883 023374 012700 023742
2884 023400 010037 001170
2885 023404 173010
2886 023406 170205
2887 023410 010537 001166
2888 023414 012700 023732
(1) 023420 174010
2889 023422 004537 004312
2890 023426 023762 023732
2891 023432 001404
2892 023434 012737 023762 001174
2893 023442 104155
2894
2895
2896
2897 023444
(1) 023444 104411
2898 023446 170011
2899 023450 012737 023500 001164
2900 023456 012700 023752
(1) 023462 172410
2901 023464 010037 001172
2902 023470 012700 023752
2903 023474 010037 001170
2904 023500 173010
2905 023502 170205
2906 023504 010537 001166
2907 023510 012700 023732
(1) 023514 174010
2908 023516 004537 004312
2909 023522 023762 023732
2910 023526 001404
2911 023530 012737 023762 001174
2912 023536 104155
2913
2914
2915

```
*****  
*TEST 35 SUBD WITH POSITIVE AND NEGATIVE OPERANDS  
* THIS IS A TEST OF THE SUBD INSTRUCTION USING VARIOUS OPERANDS..  
*  
*****  
TST35: SCOPE  
: N - N = 0  
: EE1:  
LUPERR ;; LOOP HERE ON ERROR IF SWR9 = 1.  
MOV #EEDIFF,$TMP7 ;; RECEIVED DIFF POINTER.  
SETD ;; DOUBLE MODE.  
MOV #1$,@$TMP2  
MOV #EEP1,R0  
LDD (R0),ACO ;; LOAD ACO  
MOV R0,$TMP5  
MOV #EEP1,R0 ;FSPC  
MOV R0,$TMP4  
1$: SUBD (R0),ACO ;TEST INSTRUCTION  
STFPS R5 ;GET FPS  
MOV R5,$TMP3  
MOV #EEDIFF,R0  
STD ACO,(R0) ;; STORE ACO  
JSR R5,CHECK4  
EEP3,EEDIFF ; EXP VS RECD.  
BEQ EE2 ; BR IF OK.  
MOV #EEP3,$TMP6  
ERROR 155  
: (-N) - (-N) = 0  
: EE2:  
LUPERR ;; LOOP HERE ON ERROR IF SWR9 = 1.  
SETD  
MOV #1$,@$TMP2  
MOV #EEP2,R0  
LDD (R0),ACO ;; LOAD ACO  
MOV R0,$TMP5  
MOV #EEP2,R0 ;FSPC  
MOV R0,$TMP4  
1$: SUBD (R0),ACO ;TEST INSTRUCTION  
STFPS R5 ;GET FPS  
MOV R5,$TMP3  
MOV #EEDIFF,R0  
STD ACO,(R0) ;; STORE ACO  
JSR R5,CHECK4  
EEP3,EEDIFF  
BEQ EE3 ; BR IF OK  
MOV #EEP3,$TMP6  
ERROR 155  
: NOW A MIXED NUMBER MINUS A WHOLE NUMBER.  
:
```

```

2916 023540          EE3:
(1) 023540 104411      LUPERR                ;; LOOP HERE ON ERROR IF SWR9 - 1.
2917 023542 170011      SETD
2918 023544 012737 023574 001164  MOV    #1$,@#STMP2
2919 023552 012700 023772  MOV    #EEP4,R0
(1) 023556 172410      LDD    (R0),ACO      ;; LOAD ACO
2920 023560 010037 001172  MOV    R0,$TMP5
2921 023564 012700 024002  MOV    #EEP5,R0      ;FSRC
2922 023570 010037 001170  MOV    R0,$TMP4
2923 023574 173010      1$:  SUBD   (R0),ACO      ;TEST INSTRUCTION
2924 023576 170205      STFPS  R5            ;GET FPS
2925 023600 010537 001166  MOV    R5,$TMP3
2926 023604 012700 023732  MOV    #EEDIFF,R0
(1) 023610 174010      STD   ACO,(R0)      ;; STORE ACO
2927 023612 004537 004312  JSR   R5,CHECK4
2928 023616 024012 023732  EEP6,EEDIFF
2929 023622 001404      BEQ   EE4            ; BR IF OK
2930 023624 012737 024012 001174  MOV    #EEP6,$TMP6
2931 023632 104155      ERROR 155
2932
2933      ; NOW A WHOLE NUMBER MINUS A MIXED NUMBER.
2934
2935 023634          EE4:
(1) 023634 104411      LUPERR                ;; LOOP HERE ON ERROR IF SWR9 1.
2936 023636 170011      SETD
2937 023640 012737 023670 001164  MOV    #1$,@#STMP2
2938 023646 012700 024002  MOV    #EEP5,R0
(1) 023652 172410      LDD    (R0),ACO      ;; LOAD ACO
2939 023654 010037 001172  MOV    R0,$TMP5
2940 023660 012700 023772  MOV    #EEP4,R0      ;FSRC
2941 023664 010037 001170  MOV    R0,$TMP4
2942 023670 173010      1$:  SUBD   (R0),ACO      ;TEST INSTRUCTION
2943 023672 170205      STFPS  R5            ;GET FPS
2944 023674 010537 001166  MOV    R5,$TMP3
2945 023700 012700 023732  MOV    #EEDIFF,R0
(1) 023704 174010      STD   ACO,(R0)      ;; STORE ACO
2946 023706 004537 004312  JSR   R5,CHECK4
2947 023712 024022 023732  EEP7,EEDIFF
2948 023716 001404      BEQ   EE5            ; BR IF OK
2949 023720 012737 024022 001174  MOV    #EEP7,$TMP6
2950 023726 104155      ERROR 155
2951 023730 000440      EE5:  BR     EEDONE
2952
2953 023732 000000 000000 000000  EEDIFF: .FLT4 0      ; RECEIVED DIFFERENCE.
2954 023742 000200 000001 000001  EEP1: 000200,1,1,1
2955 023752 100200 000001 000001  EEP2: 100200,1,1,1
2956 023762 000000 000000 000000  EEP3: 0,0,0,0      ; P1-P1 AND P2-P2
2957 023772 040600 144724 000000  EEP4: 040600,144724,0,0 ; MIXED NUMBER.
2958 024002 040600 000000 000000  EEP5: 040600,0,0,0    ; WHOLE NUMBER.
2959 024012 036711 152000 000000  EEP6: 036711,152000,0,0 ; P4-P5 (MIXED-WHOLE).
2960 024022 136711 152000 000000  EEP7: 136711,152000,0,0 ; P5-P4 (WHOLE-MIXED).
2961
2962 024032          EEDONE:
(1) 024032 104412      CLRFPS                ;; CLEAR FP STATUS...
(3) 024034 000400      BR     TST36          ;; ...AND PROCEED.

```


2974
(3)
(4)
(4)
(4)
(4)
(4)
(4)
(4)
(3)
(2) 024036 000004
2975
2976
2977
2978 024040 012700 054174
2979 024044 112720 000101
2980 024050 112720 000104
2981 024054 112720 000104
2982 024060 104411
2983 024062 170011
2984 024064 012737 024470 001176
2985 024072 012737 024122 001164
2986 024100 012700 024520
(1) 024104 172410
2987 024106 010037 001172
2988 024112 012700 024530
2989 024116 010037 001170
2990 024122 172010
2991 024124 170205
2992 024126 010537 001166
2993 024132 012700 024470
(1) 024136 174010
2994 024140 004537 004312
2995 024144 024540 024470
2996 024150 001404
2997 024152 012737 024540 001174
2998 024160 104156
2999
3000
3001
3002 024162
(1) 024162 104411
3003 024164 170011
3004 024166 012737 024216 001164
3005 024174 012700 024500
(1) 024200 172410
3006 024202 010037 001172
3007 024206 012700 024510
3008 024212 010037 001170
3009 024216 172010
3010 024220 170205
3011 024222 010537 001166
3012 024226 012700 024470
(1) 024232 174010
3013 024234 004537 004312

```
*****  
:TEST 36 TEST NORMALIZE FLOW USING ADDD AND SUBD  
:  
:* TEST THAT THE RESULTS OF AN ADD OR SUBTRACT ARE  
:* PROPERLY NORMALIZED IN ACO.  
:* DATA IS SELECTED TO TEST TWO CASES.  
:* FIRST THE MINIMUM SITUATION REQUIRING ONE  
:* LEFT SHIFT AND THEN THE MAXIMUM SITUATION  
:* REQUIRING 56 SHIFTS.  
:  
:*****  
TST36: SCOPE  
:  
: MIN CASE ADDING -- RESULT REQUIRES 1 SHIFT TO NORMALIZE.  
:  
FF1: MOV #EM156X,R0  
MOV #'A,(R0)+  
MOV #'D,(R0)+  
MOV #'D,(R0)+ ; PRIME ERROR TEXT ADD.  
LUPERR ;: LOOP HERE ON ERROR IF SWR9 1.  
SETD ; DOUBLE MODE.  
MOV #FFSUM,$TMP7  
MOV #1$,@$TMP2  
MOV #FFP2,R0  
LDD (R0),ACO ;: LOAD ACO  
MOV R0,$TMP5  
MOV #FFP3,R0 ;:FSPC  
MOV R0,$TMP4  
1$: ADDD (R0),ACO ;:TEST INSTRUCTION  
STFPS R5 ;:GET FPS  
MOV R5,$TMP3  
MOV #FFSUM,R0  
STD ACO,(R0) ;: STORE ACO  
JSR R5,CHECK4  
FFP4,FFSUM  
BEQ FF2 ; BR IF OK.  
MOV #FFP4,$TMP6  
ERROR 156  
:  
: MAX CASE ADDING -- RESULT REQUIRES 56 SHIFTS TO NORMALIZE.  
:  
FF2: LUPERR ;: LOOP HERE ON ERROR IF SWR9 1.  
SETD  
MOV #1$,@$TMP2  
MOV #FFP0,R0  
LDD (R0),ACO ;: LOAD ACO  
MOV R0,$TMP5  
MOV #FFP1,R0 ;:FSRC  
MOV R0,$TMP4  
1$: ADDD (R0),ACO ;:TEST INSTRUCTION  
STFPS R5 ;:GET FPS  
MOV R5,$TMP3  
MOV #FFSUM,R0  
STD ACO,(R0) ;: STORE ACO  
JSR R5,CHECK4
```

```

3014 024240 024540 024470      FFP4,FFSUM
3015 024244 001404      BEQ    FF3          ; BR IF OK.
3016 024246 012737 024540 001174  MOV    #FFP4,$TMP6
3017 024254 104156      ERROR  156
3018
3019      ; MIN CASE -- SUBTRACTING.
3020
3021 024256 012700 054174  FF3::  MOV    #EM156X,R0
3022 024262 112720 000123      MOVB  #'S,(R0)+
3023 024266 112720 000125      MOVB  #'U,(R0)+
3024 024272 112720 000102      MOVB  #'B,(R0)+          ; PRIME ERROR TEXT = SUB
3025 024276 104411      LUPERR          ;: LOOP HERE ON ERROR IF SWR9 - 1.
3026 024300 170011      SETD
3027 024302 012737 024332 001164  MOV    #1$,@$TMP2
3028 024310 012700 024520      MOV    #FFP2,R0
(1) 024314 172410      LDD    (R0),AC0          ;: LOAD AC0
3029 024316 010037 001172      MOV    R0,$TMP5
3030 024322 012700 024560      MOV    #FFP6,R0          ;FSRC
3031 024326 010037 001170      MOV    R0,$TMP4
3032 024332 173010 1$:  SUBD   (R0),AC0          ;TEST INSTRUCTION
3033 024334 170205      STFPS  R5              ;GET FPS
3034 024336 010537 001166      MOV    R5,$TMP3
3035 024342 012700 024470      MOV    #FFSUM,R0
(1) 024346 174010      STD    AC0,(R0)          ;: STORE AC0
3036 024350 004537 004312      JSR    R5,CHECK4
3037 024354 024540 024470      FFP4,FFSUM
3038 024360 001404      BEQ    FF4          ; BR IF OK.
3039 024362 012737 024540 001174  MOV    #FFP4,$TMP6
3040 024370 104156      ERROR  156
3041
3042      ; MAX CASE -- SUBTRACTING.
3043
3044 024372      FF4:
(1) 024372 104411      LUPERR          ;: LOOP HERE ON ERROR IF SWR9 - 1.
3045 024374 170011      SETD
3046 024376 012737 024426 001164  MOV    #1$,@$TMP2
3047 024404 012700 024500      MOV    #FFP0,R0
(1) 024410 172410      LDD    (R0),AC0          ;: LOAD AC0
3048 024412 010037 001172      MOV    R0,$TMP5
3049 024416 012700 024550      MOV    #FFP5,R0          ;FSRC
3050 024422 010037 001170      MOV    R0,$TMP4
3051 024426 173010 1$:  SUBD   (R0),AC0          ;TEST INSTRUCTION
3052 024430 170205      STFPS  R5              ;GET FPS
3053 024432 010537 001166      MOV    R5,$TMP3
3054 024436 012700 024470      MOV    #FFSUM,R0
(1) 024442 174010      STD    AC0,(R0)          ;: STORE AC0
3055 024444 004537 004312      JSR    R5,CHECK4
3056 024450 024540 024470      FFP4,FFSUM
3057 024454 001404      BEQ    FF5          ; BR IF OK.
3058 024456 012737 024540 001174  MOV    #FFP4,$TMP6
3059 024464 104156      ERROR  156
3060
3061 024466 000440      FF5:  BR    FFDONE
3062
3063 024470 000000 000000 000000  FF5SUM: .FLT4  0          ; RECEIVED SUM AND DIFF.
3064 024500 016000 000000 00G000  FFPO:  016000,0,0,1      ; EXP 70

```

FPAA -- LSI11/23 FPF11 DIAGNOSTIC, PART 1
FPAA.P11 28-JAN-81 09:50 T36

MACY11 30G(1063) 28-JAN-81 10:06 PAGE 2-69
TEST NORMALIZE FLOW USING ADDD AND SUBD

SEQ 0099

3065	024510	116000	000000	000000	FFP1:	116000,0,0,0	:	EXP 70 AND NEG SIGN.
3066	024520	000500	000000	000000	FFP2:	000500,0,0,0	:	EXP 2
3067	024530	100400	000000	000000	FFP3:	100400,0,0,0	:	EXP 2 AND NEG SIGN.
3068	024540	000200	000000	000000	FFP4:	00200,0,0,0	:	P0+P1 AND P2+P3...
3069							:	...ALSO P0-P5 AND P2-P6.
3070	024550	016000	000000	000000	FFP5:	016000,0,0,0	:	NEG OF P1.
3071	024560	000400	000000	000000	FFP6:	000400,0,0,0	:	NEG CF P3.
3072								
3073	024570				FFDONE:			
(1)	024570	104412			CLRFP5		::	CLEAR FP STATUS...
(3)	024572	000400			BR TST37		::	...AND PROCEED.

```

3085
(3)
(4)
(4)
(4)
(4)
(4)
(4)
(4)
(4)
(3)
(2) 024574 000004
3086 024576
(1) 024576 104411
3087 024600 012704 000200
3088 024604 170104
3089 024606 012737 024626 001164
3090 024614 012700 025456
(1) 024620 172410
3091 024622 012700 025466
3092 024626 172010
3093 024630 170205
3094 024632 012700 025446
(1) 024636 174010
3095 024640 020405
3096 024642 001005
3097 024644 004537 004312
3098 024650 025476 025446
3099 024654 001421
3100
3101 024656 010537 001166
3102 024662 010437 001170
3103 024666 012737 025466 001172
3104 024674 012737 025456 001174
3105 024702 012737 025476 001176
3106 024710 012737 025446 001200
3107 024716 104160
3108
3109
3110
3111
3112 024720
(1) 024720 104411
3113 024722 012704 000200
3114 024726 170104
3115 024730 012737 024750 001164
3116 024736 012700 025526
(1) 024742 172410
3117 024744 012700 025536
3118 024750 172010
3119 024752 170205
3120 024754 012700 025446
(1) 024760 174010
3121 024762 052704 000004
3122 024766 020405
3123 024770 001005
  
```

```

*****
*TEST 37      TEST ROUND\TRUNCATE USING ADDD
*
* THIS IS A TEST OF THE ROUND AND TRUNCATE FLOWS.
* IN PARTICULAR TWO THINGS ARE TESTED:
* FIRST A CONDITION IN WHICH ROUNDING RESULTS
* IN THE NEED FOR RENORMALIZATION.
* AND SECOND, THAT THE FPS CONDITION CODES (N AND Z BITS)
* ARE CORRECTLY SET IN VARIOUS COMBINATIONS.
*****
TST37: SCOPE
HH1:
      LUPERR                ;; LOOP HERE ON ERROR IF SWR9 = 1.
      MOV      #200,R4
      LDFPS   R4
      MOV      #HH2,@$TMP2
      MOV      #HHP0,R0
      LDD     (R0),ACO      ;; LOAD ACO
                          ;; SRC OPERAND.
      MOV      #HHP1,R0      ;; TEST INSTRUCTION
      ADDD    (R0),ACO      ;; GET FPS
      STFPS   R5
      MOV      #HHSUM,R0
      STD     ACO,(R0)      ;; STORE ACO
      CMP     R4,R5         ;; FPS RIGHT ??
      BNE     1$           ;; NO.
      JSR     R5,CHECK4     ;; YES, DATA CORRECT ??
      HHP2,HHSUM
      BEQ     HH7           ;; BR IF SO.

1$:   MOV      R5,$TMP3
      MOV      R4,$TMP4
      MOV      #HHP1,$TMP5
      MOV      #HHP0,$TMP6
      MOV      #HHP2,$TMP7
      MOV      #HHSUM,$TMP10
      ERROR   160          ;; SUM OR FPS BAD.

;
;TEST THAT NORMALIZE CAN PRODUCE A ZERO EXPONENT.
; AND THAT THE FPS Z BIT GETS SET.
;
HH7:
      LUPERR                ;; LOOP HERE ON ERROR IF SWR9 = 1.
      MOV      #200,R4
      LDFPS   R4
      MOV      #HH8,@$TMP2
      MOV      #HHP5,R0
      LDD     (R0),ACO      ;; LOAD ACO
                          ;; SRC OPERAND.
      MOV      #HHP6,R0      ;; TEST INSTRUCTION
      ADDD    (R0),ACO      ;; GET FPS
      STFPS   R5
      MOV      #HHSUM,R0
      STD     ACO,(R0)      ;; STORE ACO
      BIS     %4,R4         ;; SET EXP FPS.
      CMP     R4,R5         ;; FPS RIGHT ??
      BNE     1$           ;; NO.
  
```

```

3124 024772 004537 004312 JSR R5,CHECK4 ; YES, DATA RIGHT ??
3125 024776 025516 025446 HHP4,HHSUM
3126 025002 001421 BEQ HH11 ; BR IF SO.
3127
3128 025004 010537 001166 1$: MOV R5,$TMP3
3129 025010 010437 001170 MOV R4,$TMP4
3130 025014 012737 025536 001172 MOV #HHP6,$TMP5
3131 025022 012737 025526 001174 MOV #HHP5,$TMP6
3132 025030 012737 025516 001176 MOV #HHP4,$TMP7
3133 025036 012737 025446 001200 MOV #HHSUM,$TMP10
3134 025044 104160 ERROR 160 ; SUM OR FPS BAD.
3135
3136 ; THIS IS A TEST OF THE R/T ALGORITHM'S
3137 ; ABILITY TO SET BOTH N AND Z ON A -0 RESULT.
3138 ; NOTE THAT -0 IS AN UNDERFLOW CONDITION.
3139
3140 025046 HH11:
(1) 025046 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 - 1.
3141 025050 012704 042200 MOV #42200,R4
3142 025054 170104 LDFPS R4 ; SET FID AND FIU BITS.
3143 025056 012737 025076 001164 MOV #HH12,@#$TMP2
3144 025064 012700 025556 MOV #HHP8,R0
(1) 025070 172410 LDD (R0),AC0 ;: LOAD AC0
3145 025072 012700 025566 MOV #HHP9,R0 ;: SRC OPERAND.
3146 025076 172010 HH12: ADDD (R0),AC0 ;: TEST INSTRUCTION
3147 025100 170205 STFPS R5 ;: GET FPS
3148 025102 012700 025446 MOV #HHSUM,R0
(1) 025106 174010 STD AC0,(R0) ;: STORE AC0
3149 025110 052704 100014 BIS #100014,R4 ;: SET EXP FPS.
3150 025114 020405 CMP R4,R5 ; FPS RIGHT ??
3151 025116 001005 BNE 1$ ; NO.
3152 025120 004537 004312 JSR R5,CHECK4 ; YES, DATA RIGHT ??
3153 025124 025546 025446 HHP7,HHSUM
3154 025130 001421 BEQ HH17 ; BR IF SO.
3155
3156 025132 010537 001166 1$: MOV R5,$TMP3
3157 025136 010437 001170 MOV R4,$TMP4
3158 025142 012737 025566 001172 MOV #HHP9,$TMP5
3159 025150 012737 025556 001174 MOV #HHP8,$TMP6
3160 025156 012737 025546 001176 MOV #HHP7,$TMP7
3161 025164 012737 025446 001200 MOV #HHSUM,$TMP10
3162 025172 104160 ERROR 160
3163
3164 ; TEST THAT CC BITS ARE CLEARED BY R/T
3165
3166 025174 HH17:
(1) 025174 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 - 1.
3167 025176 012704 000200 MOV #200,R4
3168 025202 170104 LDFPS R4
3169 025204 012737 025224 001164 MOV #HH18,@#$TMP2
3170 025212 012700 025556 MOV #HHP8,R0
(1) 025216 172410 LDD (R0),AC0 ;: LOAD AC0
3171 025220 012700 025556 MOV #HHP8,R0 ;: SRC TOO.
3172 025224 172010 HH18: ADDD (R0),AC0 ;: TEST INSTRUCTION
3173 025226 170205 STFPS R5 ;: GET FPS
3174 025230 012700 025446 MOV #HHSUM,R0

```

```

(1) 025234 174010 STD ACO,(R0) ;; STORE ACO
3175 025236 020405 CMP R4,R5 ;; FPS RIGHT ??
3176 025240 001005 BNE 1$ ;; NO.
3177 025242 004537 004312 JSR R5,CHECK4 ;; YES, DATA RIGHT ??
3178 025246 025576 025446 HHP10,HHSUM
3179 025252 001421 BEQ HH21 ;; YES.
3180
3181 025254 010537 001166 1$: MOV R5,$TMP3
3182 025260 010437 001170 MOV R4,$TMP4
3183 025264 012737 025556 001172 MOV #HHP8,$TMP5
3184 025272 013737 001172 001174 MOV $TMP5,$TMP6
3185 025300 012737 025576 001176 MOV #HHP10,$TMP7
3186 025306 012737 025446 001200 MOV #HHSUM,$TMP10
3187 025314 104160 ERROR 160
3188
3189 ;;TEST THAT N BIT IS SET BY R17
3190
3191 025316 HH21:
(1) 025316 104411 LUPERR ;; LOOP HERE ON ERROR IF SWR9 = 1.
3192 025320 012704 000200 MOV #200,R4
3193 025324 170104 LDFPS R4
3194 025326 012737 025346 001164 MOV #HH22,@$TMP2
3195 025334 012700 025526 MOV #HHP5,R0
(1) 025340 172410 LDD (R0),ACO ;; LOAD ACO
3196 025342 012700 025526 MOV #HHP5,R0 ;; SRC TOO.
3197 025346 172010 HH22: ADDD (R0),ACO ;;TEST INSTRUCTION
3198 025350 170205 STFPS R5 ;;GET FPS
3199 025352 012700 025446 MOV #HHSUM,R0
(1) 025356 174010 STD ACO,(R0) ;; STORE ACO
3200 025360 052704 000010 BJS #10,R4 ;; SET EXP FPS.
3201 025364 020405 CMP R4,R5 ;; FPS RIGHT ??
3202 025366 001005 BNE 1$ ;; NO.
3203 025370 004537 004312 JSR R5,CHECK4 ;; YES, DATA RIGHT ??
3204 025374 025606 025446 HHP11,HHSUM
3205 025400 001421 BEQ 2$ ;; YES.
3206
3207 025402 010537 001166 1$: MOV R5,$TMP3
3208 025406 010437 001170 MOV R4,$TMP4
3209 025412 012737 025526 001172 MOV #HHP5,$TMP5
3210 025420 013737 001172 001174 MOV $TMP5,$TMP6
3211 025426 012737 025606 001176 MOV #HHP11,$TMP7
3212 025434 012737 025446 001200 MOV #HHSUM,$TMP10
3213 025442 104160 ERROR 160
3214 025444 000464 2$: BR HHDONE
3215
3216
3217 025446 000000 000000 000000 HHSUM: .FLT4 0
3218 025456 000452 125252 125252 HHP0: 000452,125252,125252,125253
3219 025466 000252 125252 125252 HHP1: 000252,125252,125252,125252
3220 025476 000600 000000 000000 HHP2: 000600,0,0,0 ;;HHP0 + HHP1 NORMALIZED.
3221 025506 000400 000000 000000 HHP3: 000400,0,0,0 ;;HHP0 + HHP1 WITH...
3222 ;;...BAD NORMALIZATION
3223 025516 000000 000000 000000 HHP4: 0,0,0,0
3224 025526 100200 000000 000000 HHP5: 100200,0,0,0
3225 025536 000300 000000 000000 HHP6: 000300,0,0,0
3226 025546 100000 000000 000000 HHP7: 100000,0,0,0 ;;HHP7 - HHP8 + HHP9 (NEG ZERO)

```

CJFPAA -- LSI11/23 FPF11 DIAGNOSTIC, PART 1
CJFPAA.P11 28-JAN-81 09:50 T37

M 8
MACY11 30G(1063) 28-JAN-81 10:06 PAGE 2-73
TEST ROUND\TRUNCATE USING ADDD

SEQ 0103

```
3227 ; - HHP5 + HHP6
3228 J25556 000200 000000 000000 HHP8: 000200,0,0,0
3229 025566 100300 000000 000000 HHP9: 100300,0,0,0
3230 025576 000400 000000 000000 HHP10: 000400,0,0,0 ;HHP10 = HHP8 + HHP8
3231 025606 100400 000000 000000 HHP11: 100400,0,0,0 ;HHP11 = HHP5 + HHP5
3232
3233 HMDONE:
(1) 025616 CLRFPs ;: CLEAR FP STATUS...
(3) 025620 104412 BR TST40 ;:...AND PROCEED.
000400
```

```

3245 .....
(3) *TEST 40 TEST OVERFLOW\UNDERFLOW USING ADD
(4) *
(4) * TEST THAT THE OVERFLOW/UNDERFLOW ALGORITHM CAN CORRECTLY
(4) * DETECT THOSE CONDITIONS AND TAKE THE APPROPRIATE ACTION.
(4) * EACH CONDITION IS TESTED TWICE, ONCE WITH TRAPS
(4) * ENABLED (FIU AND FIV = 1), AND AGAIN WITH TRAPS
(4) * DISABLED (FIU AND FIV = 0).
(4) * WHEN TRAPS ARE ENABLED, THE RETURNED FEC IS ALSO TESTED.
(3) .....
(2) 025622 000004 TST40: SCOPE
3246 : OVERFLOW WITH TRAP DISABLED (FIV = 0)
3247 :
3248 :
3249 025624 012737 026526 000244 GG1: MOV #GG244,FPVEC ; SET OUR TRAP CATCHER.
3250 025632 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.
3251 025634 012704 000200 MOV #200,R4 ; FIV = 0.
3252 025640 170104 LDFPS R4
3253 025642 052704 000006 BIS #6,R4
3254 025646 010437 001170 MOV R4,$TMP4 ; EXP FPS.
3255 025652 012737 026560 001172 MOV #GGP1,$TMP5 ; OPERANDS FOR OUTPUT.
3256 025660 012737 026570 001174 MOV #GGP2,$TMP6
3257 025666 012737 026550 001176 MOV #GGP0,$TMP7 ; EXP SUM
3258 025674 012737 026540 001200 MOV #GGSUM,$TMP10 ; RECD SUM
3259 025702 012737 025726 001164 MOV #1$,$TMP2
3260 025710 005037 026536 CLR GGFEC ; USE AS TRAP FLAG.
3261 025714 012700 026570 MOV #GGP2,R0
(1) 025720 172410 LDD (R0),ACO ;: LOAD ACO
3262 025722 012700 026560 MOV #GGP1,R0 ;: SRC TOO.
3263 025726 172010 1$: ADDD (R0),ACO ;: TEST INSTRUCTION...
3264 025730 000240 NOP ;: ...SHOULDN'T TRAP.
3265 025732 170205 STFPS R5 ;: GET FPS
3266 025734 010537 001166 MOV R5,$TMP3
3267 025740 012700 026540 MOV #GGSUM,R0
(1) 025744 174010 STD ACO,(R0) ;: STORE ACO
3268 025746 005737 026536 TST GGFEC ;: DID TRAP OCCUR ??
3269 025752 001013 BNE 4$ ;: YES, BAD NEWS !!
3270 :
3271 025754 023737 001166 001170 2$: CMP $TMP3,$TMP4 ;: NO, FPS RIGHT ??
3272 025762 001005 BNE 3$ ;: NO.
3273 025764 004537 004312 JSR R5,CHECK4 ;: YES, SUM = OVERFLOW ??
3274 025770 026550 026540 GGPO,GGSUM
3275 025774 001403 BEQ GG2 ;: YES, PROCEED.
3276 025776 104162 3$: ERROR 162 ;: OVER SUM OR FPS BAD.
3277 026000 000401 SKP1
3278 026002 104163 4$: ERROR 163 ;: TRAPPED WITH FIV = 0.
3279 :
3280 : SAME OPERANDS, TRAP ENABLED (FIV = 1).
3281 :
3282 026004 GG2:
(1) 026004 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 = 1.
3283 026006 012704 001200 MOV #1200,R4 ;: SET FIV.
3284 026012 170104 LDFPS R4
3285 026014 052704 100006 BIS #100006,R4
3286 026020 010437 001170 MOV R4,$TMP4 ;: EXP FPS.
  
```



```

3287 026024 012737 026620 001176      MOV      #GGP6,$TMP7      ; EXP SUM.
3288 026032 012737 026056 001164      MOV      #1$,$TMP2
3289 026040 005037 026536              CLR      GGFEC           ; CLEAR TRAP FLAG.
3290 026044 012700 026570              MOV      #GGP2,R0
(1) 026050 172410              LDD      (R0),ACO        ;; LOAD ACO
3291 026052 012700 026560              MOV      #GGP1,R0        ; SRC TOO.
3292 026056 172010              1$: ADDD   (R0),ACO        ; TEST INSTRUCTION...
3293 026060 000240              NOP
3294 026062 170205              STFPS   R5               ; ...SHOULD TRAP.
3295 026064 010537 001166              MOV      R5,$TMP3        ; GET FPS
3296 026070 012700 026540              MOV      #GGSUM,R0
(1) 026074 174010              STD     ACO,(R0)         ;; STORE ACO
3297 026076 005737 026536              TST     GGFEC           ; DID IT TRAP ??
3298 026102 001432              BEQ     4$              ; NO, BAD NEWS !!
3299
3300 026104 004537 004312              JSR     R5,CHECK4        ; YES, IS SUM RIGHT ??
3301 026110 026620 026540              GGP6,GGSUM
3302 026114 001401              BEQ     2$              ; BR IF SO.
3303 026116 104162              ERROR  162             ; SUM WRONG.
3304 026120 010437 001166              2$: MOV   R4,$TMP3        ; MOVE EXP FPS.
3305 026124 012737 000010 001170              MOV   #10,$TMP4        ; SET EXP' FEC.
3306 026132 170205              STFPS   R5               ; GET FPS AGAIN
3307 026134 020537 001166              CMP    R5,$TMP3        ; IS IT RIGHT ??
3308 026140 001004              BNE    3$              ; NO.
3309 026142 023737 026536 001170              CMP    GGFEC,$TMP4     ; FEC RIGHT (OVFLO) ??
3310 026150 001410              BEQ    3$              ; YES.
3311 026152 010537 001172              3$: MOV   R5,$TMP5
3312 026156 013737 026536 001174              MOV   GGFEC,$TMP6
3313 026164 104165              ERROR  165             ; FPS/FEC WRONG ON OVERFLOW.
3314 026166 000401              SKP1
3315 026170 104164              4$: ERROR 164          ; DIDN'T TRAP FIV - 1.
3316
3317 ;CHECK UNDER FLOW CONDITION WITH
3318 ;TRAPS DISABLED (FIU = 0)
3319 ;
3320 026172              GG3:
(1) 026172 104411              LUPERR
3321 026174 012704 000200              MOV   #200,R4          ;; LOOP HERE ON ERROR IF SWR9 1.
3322 026200 170104              LDFPS  R4              ; FIU - 0
3323 026202 052704 000004              BIS   #4,R4
3324 026206 010437 001170              MOV   R4,$TMP4        ; EXP FPS.
3325 026212 012737 026600 001172              MOV   #GGP3,$TMP5
3326 026220 012737 026610 001174              MOV   #GGP4,$TMP6
3327 026226 012737 026550 001176              MOV   #GGP0,$TMP7
3328 026234 012737 026260 001164              MOV   #1$,$TMP2
3329 026242 005037 026536              CLR   GGFEC           ; CLEAR TRAP FLAG.
3330 026246 012700 026610              MOV   #GGP4,R0
(1) 026252 172410              LDD   (R0),ACO        ;; LOAD ACO
3331 026254 012700 026600              MOV   #GGP3,R0        ; SRC OPERAND.
3332 026260 172010              1$: ADDD (R0),ACO        ; TEST INSTRUCTION...
3333 026262 000240              NOP
3334 026264 170205              STFPS  R5              ; ...SHOULDN'T TRAP.
3335 026266 010537 001166              MOV   R5,$TMP3        ; GET FPS
3336 026272 012700 026540              MOV   #GGSUM,R0
(1) 026276 174010              STD   ACO,(R0)         ;; STORE ACO
3337 026300 005737 026536              TST   GGFEC           ; DID IT TRAP ??

```

```

3338 026304 001013          BNE      4$          ; YES, ERROR.
3339
3340 026306 023737 001166 001170 2$:  CMP      $TMP3,$TMP4 ; FPS RIGHT ??
3341 026314 001005          BNE      3$          ; NO.
3342 026316 004537 004312          JSR      R5,CHECK4  ; YES, DATA RIGHT ??
3343 026322 026550 026540          GGPO,GGSUM
3344 026326 001403          BEQ      GG4          ; BR IF SO.
3345 026330 104166          3$:  ERROR   166        ; SUM OR FPS BAD ON UNDERFLOW.
3346 026332 000401          SKP1
3347 026334 104167          4$:  ERROR   167        ; TRAPPED WITH FIU = 0.
3348
3349          ; SAME OPERANDS, FIU - 1.
3350
3351          GG4:
(1) 026336 104411          LUPERR          ;; LOOP HERE ON ERROR IF SWR9 = 1.
3352 026340 012704 002200          MOV      #2200,R4  ; SET FIU.
3353 026344 170104          LDFPS      R4
3354 026346 052704 100000          BIS      #100000,R4
3355 026352 010437 001170          MOV      R4,$TMP4  ; EXP FPS.
3356 026356 012737 026630 001176          MOV      #GGP7,$TMP7 ; EXP RESULT.
3357 026364 012737 026410 001164          MOV      #1$,@#$TMP2
3358 026372 005037 026536          CLR      GGFEC      ; CLEAR TRAP FLAG.
3359 026376 012700 026610          MOV      #GGP4,R0
(1) 026402 172410          LDD      (R0),ACO  ;; LOAD ACO
3360 026404 012700 026600          MOV      #GGP3,R0  ; SRC OPERAND.
3361 026410 172010          1$:  ADDD      (R0),ACO ; TEST INSTRUCTION...
3362 026412 000240          NOP
3363 026414 170205          STFPS      R5      ; ...SHOULD TRAP.
3364 026416 010537 001166          MOV      R5,$TMP3  ; GET FPS.
3365 026422 012700 026540          MOV      #GGSUM,R0
(1) 026426 174010          STD      ACO,(R0)  ;; STORE ACO
3366 026430 005737 026536          TST      GGFEC      ; DID IT TRAP ??
3367 026434 001432          BEQ      4$          ; NO, ERROR.
3368 026436 004537 004312          JSR      R5,CHECK4  ; YES, SUM RIGHT ??
3369 026442 026630 026540          GGP7,GGSUM
3370 026446 001401          BEQ      2$          ; YES.
3371 026450 104166          ERROR   166        ; UNDERFLOW RESULT WRONG.
3372 026452 010437 001166 001170 2$:  MOV      R4,$TMP3  ; COPY EXP FPS.
3373 026456 012737 000012 001170          MOV      #12,$TMP4 ; AMD FEC.
3374 026464 170205          STFPS      R5      ; GET FPS AGAIN.
3375 026466 020537 001166          CMP      R5,$TMP3  ; FPS RIGHT ??
3376 026472 001004          BNE      3$          ; NO.
3377 026474 023737 026536 001170          CMP      GGFEC,$TMP4 ; FEC RIGHT (UFLO).
3378 026502 001410          BEQ      GG5          ; BR IF BOTH RIGHT.
3379 026504 010537 001172          MOV      R5,$TMP5
3380 026510 013737 026536 001174          MOV      GGFEC,$TMP6
3381 026516 104171          ERROR   171        ; FPS/FEC WRONG ON UNDERFLOW.
3382 026520 000401          SKP1
3383 026522 104170          4$:  ERROR   170        ; DIDN'T TRAP WITH FIU = 1
3384
3385 026524 000445          GG5:  BR      GGDONE
3386
3387 026526 170305          GG244: STST     R5      ; TRAPPED TO 244, GET FEC...
3388 026530 010537 026536          MOV      R5,GGFEC  ; ...AND SAVE IT.
3389 026534 000002          RTI
3390

```

3391	026536	000000			GGFEC:	0		; SAVED FEC CODE ON TRAP.
3392	026540	000000	000000	000000	GGSUM:	.FLT4 0		
3393	026550	000000	000000	000000	GGP0:	0,0,0,0		; RESULT WHEN FIU/FIV = 0.
3394	026560	077600	000000	000000	GGP1:	77600,0,0,0		
3395	026570	077601	000001	000001	GGP2:	77601,1,1,1		; 1 + 2 = OVERFLOW.
3396	026600	100200	000000	000000	GGP3:	100200,0,0,0		
3397	026610	000201	000001	000001	GGP4:	000201,1,1,1		; 3 + 4 = UNDERFLOW.
3398	026620	000000	100000	100000	GGP6:	0,100000,100000,100001		; SUM OF 1 + 2 (FIV = 1).
3399	026630	076400	000200	000200	GGP7:	76400,200,200,200		; SUM OF 3 + 4 (FIU = 1)
3400								
3401	026640				GGDONE:			
(1)	026640	104412			CLRFP			:: CLEAR FP STATUS...
(3)	026642	000400			BR	TST41		::...AND PROCEED.

3408
(3)
(4)
(4)
(4)
(3)
(2) 026644 000004
3409
3410
3411
3412 026646
(1) 026646 104411
3413 026650 012704 000200
3414 026654 170104
3415 026656 012737 026716 001164
3416 026664 012737 042106 055170
3417 026672 013737 055170 055236
3418 026700 012700 027526
(1) 026704 172410
3419 026706 012700 027536
3420 026712 010037 001166
3421 026716 177420
3422 026720 020027 027542
3423 026724 001407
3424 026726 010037 001170
3425 026732 012737 027542 001172
3426 026740 104172
3427 026742 000425
3428 026744 170205
3429 026746 010537 001166
3430 026752 012700 027516
(1) 026756 174010
3431 026760 004537 004312
3432 026764 027606 027516
3433 026770 001412
3434 026772 012737 027536 001170
3435 027000 012737 027606 001172
3436 027006 012737 027516 001174
3437 027014 104173
3438
3439
3440
3441 027016
(1) 027016 104411
3442 027020 012704 000200
3443 027024 170104
3444 027026 012737 027070 001164
3445 027034 012737 043104 055170
3446 027042 013737 055170 055236
3447 027050 012700 027526
(1) 027054 172410
3448 027056 170001
3449 027060 012700 027536
3450 027064 010037 001166
3451 027070 177420
3452 027072 020027 027546

```
*****
*TEST 41      LDCFD AND LDCDF -- FRSC MODE 2
*
*THIS IS A TEST OF LDCFD AND LDCDF.
*
*****
TST41: SCOPE
:TEST FOR CORRECT AUTO INCREMENT CONSTANT.
:
JJ1:
LUPERR          ;; LOOP HERE ON ERROR IF SWR9 - 1.
MOV #200,R4
LDFPS R4
MOV #JJ2,@$TMP2
MOV #'FD,EM172X
MOV EM172X,EM173X
MOV #JJP1,R0
LDD (R0),ACO    ;; LOAD ACO
MOV #JJP2,R0
MOV R0,$TMP3    ; RO BEFORE.
JJ2: LDCFD (R0)+,ACO ; CONVERT P2
CMP R0,#JJP2+4  ; IS RO CORRECT
BEQ 1$          ; YES.
MOV R0,$TMP4
MOV #JJP2+4,$TMP5
ERROR 172
BR JJ8
1$: STFPS R5      ;GET FPS
MOV R5,$TMP3
MOV #JJDAT,R0
STD ACO,(R0)    ;; STORE ACO
JSR R5,CHECK4  ; DATA RIGHT ??
JJP7,JJDAT
BEQ JJ8        ; YES.
MOV #JJP2,$TMP4 ; SRC DATA
MOV #JJP7,$TMP5 ; EXP
MOV #JJDAT,$TMP6
ERROR 173
:
: NOW AGAIN D TO F.
:
JJ8:
LUPERR          ;; LOOP HERE ON ERROR IF SWR9 = 1.
MOV #200,R4
LDFPS R4
MOV #JJ9,@$TMP2
MOV #'DF,EM172X
MOV EM172X,EM173X
MOV #JJP1,R0
LDD (R0),ACO    ;; LOAD ACO
SETF
MOV #JJP2,R0
MOV R0,$TMP3    ; RO BEFORE.
JJ9: LDCFD (R0)+,ACO ; CONVERT P2.
CMP R0,#JJP2+10 ; RO RIGHT ??
```

```

3453 027076 001407
3454 027100 010037 001170
3455 027104 012737 027546 001172
3456 027112 104172
3457 027114 000426
3458 027116 170205
3459 027120 010537 001166
3460 027124 170011
3461 027126 012700 027516
(1) 027132 174010
3462 027134 004537 004312
3463 027140 027616 027516
3464 027144 001412
3465 027146 012737 027536 001170
3466 027154 012737 027616 001172
3467 027162 012737 027516 001174
3468 027170 104173
3469
3470
3471
3472 027172
(1) 027172 104411
3473 027174 02704 000200
3474 027200 170104
3475 027202 012737 027230 001164
3476 027210 012737 042106 055236
3477 027216 012700 027526
(1) 027222 172410
3478 027224 012700 027536
3479 027230 177420
3480 027232 170205
3481 027234 010537 001166
3482 027240 012700 027516
(1) 027244 174010
3483 027246 004537 004312
3484 027252 027606 027516
3485 027256 001412
3486 027260 012737 027536 001170
3487 027266 012737 027606 001172
3488 027274 012737 027516 001176
3489 027302 104173
3490
3491
3492
3493 027304
(1) 027304 104411
3494 027306 012704 000200
3495 027312 170104
3496 027314 012737 027334 001164
3497 027322 012700 027576
(1) 027326 172410
3498 027330 012700 027556
3499 027334 177420
3500 027336 170205
3501 027340 010537 001166
3502 027344 012700 027516

```

```

BEQ 1$ ; YES.
MOV R0,$TMP4 ; NO
MOV #JJP2+10,$TMP5
ERROR 172
BR JJ17
1$: STFPS R5
MOV R5,$TMP3
SETD
MOV #JJDAT,R0
STD ACO,(R0) ;; STORE ACO
JSR R5,CHECK4 ; DATA RIGHT ??
JJP8,JJDAT
BEQ JJ17 ; YES.
MOV #JJP2,$TMP4 ; SRC DATA
MOV #JJP8,$TMP5 ; EXP
MOV #JJDAT,$TMP6 ; RECD.
ERROR 173

: CONVERT F TO D POSITIVE.
:
JJ17:
LUPERR ;; LOOP HERE ON ERROR IF SWR9 = 1.
MOV #200,R4
LDFPS R4
MOV #JJ18,@$TMP2
MOV #FD,EM173X
MOV #JJP1,R0
LDD (R0),ACO ;; LOAD ACO
MOV #JJP2,R0
JJ18: LDCFD (R0)+,ACO ; CONVERT P2.
STFPS R5
MOV R5,$TMP3
MOV #JJDAT,R0
STD ACO,(R0) ;; STORE ACO
JSR R5,CHECK4 ; IS IT RIGHT ??
JJP7,JJDAT
BEQ JJ21 ; YES.
MOV #JJP2,$TMP4
MOV #JJP7,$TMP5
MOV #JJDAT,$TMP7
ERROR 173

: CONVERT F TO D NEGATIVE.
:
JJ21:
LUPERR ;; LOOP HERE ON ERROR IF SWR9 = 1.
MOV #200,R4
LDFPS R4
MOV #JJ22,@$TMP2
MOV #JJP6,R0
LDD (R0),ACO ;; LOAD ACO
MOV #JJP4,R0
JJ22: LDCFD (R0)+,ACO ; CONVERT P4.
STFPS R5
MOV R5,$TMP3
MOV #JJDAT,R0

```

(1)	027350	174010			STD	AC0,(R0)	:: STORE AC0
3503	027352	004537	004312		JSR	R5,CHECK4	: IS IT RIGHT ??
3504	027356	027566	027516		JJP5,JJDAT		
3505	027362	001412			BEQ	JJ27	: YES.
3506	027364	012737	027556	001170	MOV	#JJP4,\$TMP4	
3507	027372	012737	027566	001172	MOV	#JJP5,\$TMP5	
3508	027400	012737	027516	001174	MOV	#JJDAT,\$TMP6	
3509	027406	104173			ERROR	173	
3510							
3511							
3512							
3513	027410						
(1)	027410	104411			JJ27:		
3514	027412	012704	000200		LUPERR		:: LOOP HERE ON ERROR IF SWR9 = 1.
3515	027416	170104			MOV	#200,R4	
3516	027420	012737	027440	001164	LDFPS	R4	
3517	027426	012700	027576		MOV	#JJ28,\$TMP2	
(1)	027432	172410			MOV	#JJP6,R0	
3518	027434	012700	027526		LDD	(R0),AC0	:: LOAD AC0
3519	027440	177420			MOV	#JJP1,R0	
3520	027442	170205			JJ28:	LDCFD (R0)+,AC0	: CONVERT P1.
3521	027444	010537	001166		STFPS	R5	
3522	027450	012700	027516		MOV	R5,\$TMP3	
(1)	027454	174010			MOV	#JJDAT,R0	
3523	027456	004537	004312		STD	AC0,(R0)	:: STORE AC0
3524	027462	027526	027516		JSR	R5,CHECK4	: GOT 0 ??
3525	027466	001412			JJP1,JJDAT		
3526	027470	012737	027526	001170	BEQ	JJ29	: YES.
3527	027476	012737	027526	001172	MOV	#JJP1,\$TMP4	
3528	027504	012737	027516	001174	MOV	#JJP1,\$TMP5	
3529	027512	104173			MOV	#JJDAT,\$TMP6	
3530					ERROR	173	
3531	027514	000444			JJ29:	BR	JJDONE
3532							
3533	027516	000000	000000	000000	JJDAT:	0,0,0,0	
3534	027526	000000	000000	000000	JJP1:	0,0,0,0	
3535	027536	000577	177776	177777	JJP2:	000577,177776,177777,177776	
3536	027546	005201	000000	000000	JJP3:	005201,0,0,0	
3537	027556	100577	177776	177777	JJP4:	100577,177776,177777,177776	
3538	027566	100577	177776	000000	JJP5:	100577,177776,0,0	
3539	027576	000252	125252	125252	JJP6:	000252,125252,125252,125252	
3540	027606	000577	177776	000000	JJP7:	000577,177776,0,0	
3541	027616	000577	177777	000000	JJP8:	000577,177777,0,0	
3542							
3543	027626				JJDONE:		
(1)	027626	104412			CLRFPS		:: CLEAR FP STATUS...
(3)	027630	000400			BR	TST42	::...AND PROCEED.

```
3555 .....  
(3) : *TEST 42      CMPD -- FSRC MODE 1  
(4) : *  
(4) : *TEST THE CMPD INSTRUCTION WITH A VARIETY OF OPERANDS.  
(4) : *A COMMON SUBROUTINE IS USED TO SET UP OPERANDS, EXECUTE THE  
(4) : *INSTRUCTION, AND CHECK THE RESULTS.  
(4) : *NOTE THAT ON ERROR, THE 'ERROR PC' REPORTED IS THE PC OF THE  
(4) : *OPERAND SET WHICH RESULTED IN THE ERROR AND NOT THAT OF THE  
(4) : *OFFENDING INSTRUCTION ITSELF.  
(4) : *  
(3) : .....  
(2) 027632 000004 TST42: SCOPE  
3556 :  
3557 : TEST THE CMPD INSTRUCTION WITH (FSRC=AC=0)  
3558 :  
3559 027634 004737 030326 KK1: JSR PC,KKSUB  
3560 027640 000000 000000 000000 0,0,0,0 :AC  
3561 027650 000000 000000 000000 0,0,0,0 :FSRC  
3562 027660 000204 204 : EXPECTED FPS AFTER EXECUTION.  
3563 027662 036440 .ASCII ' -' : RELATIONAL OPERATOR FOR ERROR.  
3564 :  
3565 : TEST CMPD WITH (AC=0) AND FSRC POSITIVE.  
3566 :  
3567 027664 004737 030326 KK2: JSR PC,KKSUB  
3568 027670 000000 000000 000000 0,0,0,0 :AC  
3569 027700 025252 052525 125252 25252,52525,125252,52525 :FSRC  
3570 027710 000200 200 : EXP FPS.  
3571 027712 037040 .ASCII ' >' : FSRC > AC  
3572 :  
3573 : TEST CMPD WITH (AC=0) AND FSRC NEGATIVE  
3574 :  
3575 027714 004737 030326 KK3: JSR PC,KKSUB  
3576 027720 000000 000000 000000 0,0,0,0 :AC  
3577 027730 125252 125252 052525 125252,125252,52525,125252 :FSRC  
3578 027740 000210 210 : EXP FPS.  
3579 027742 036040 .ASCII ' <' : FSRC < AC  
3580 :  
3581 : TEST CMPD WITH (FSRC=0) AND AC POSITIVE  
3582 :  
3583 027744 004737 030326 KK4: JSR PC,KKSUB  
3584 027750 025252 052525 125252 25252,52525,125252,52525 :AC  
3585 027760 000000 000000 000000 0,0,0,0 :FSRC  
3586 027770 000210 210 : EXP FPS.  
3587 027772 036040 .ASCII ' <' : FSRC < AC  
3588 :  
3589 : TEST CMPD WITH (FSRC=0) AND AC NEGATIVE  
3590 :  
3591 027774 004737 030326 KK5: JSR PC,KKSUB  
3592 030000 125252 125252 052525 125252,125252,52525,125252 :AC  
3593 030010 000000 000000 000000 0,0,0,0 :FSRC  
3594 030020 000200 200 : EXP FPS.  
3595 030022 037040 .ASCII ' >' : FSRC > AC  
3596 :  
3597 : TEST CMPD WITH AC POSITIVE AND FSRC NEGATIVE  
3598 :  
3599 030024 004737 030326 KK6: JSR PC,KKSUB
```

3600	030030	052525	125252	052525	52525,125252,52525,125252	: AC
3601	030040	125252	052525	125252	125252,52525,125252,52525	: FSRC
3602	030050	000210			210	: EXP FPS.
3603	030052	036040			.ASCII ' <'	: FSRC < AC
3604						
3605						
3606						
3607	030054	004737	030326		KK7: JSR PC,KKSUB	
3608	030060	125252	052525	125252	125252,52525,125252,52525	: AC
3609	030070	052525	125252	052525	52525,125252,52525,125252	: FSRC
3610	030100	000200			200	: EXP FPS.
3611	030102	037040			.ASCII ' >'	: FSRC > AC
3612						
3613						
3614						
3615						
3616	030104	004737	030326		KK8: JSR PC,KKSUB	
3617	030110	012345	067654	032101	12345,67654,32101,23456	: AC
3618	030120	023456	076543	021012	23456,76543,21012,34567	: FSRC
3619	030130	000200			200	: EXP FPS.
3620	030132	037040			.ASCII ' >'	: FSRC > AC
3621						
3622						
3623						
3624						
3625	030134	004737	030326		KK9: JSR PC,KKSUB	
3626	030140	045676	054321	012345	45676,54321,12345,67654	: AC
3627	030150	034567	065432	101234	34567,65432,101234,56765	: FSRC
3628	030160	000210			210	: EXP FPS.
3629	030162	036040			.ASCII ' <'	: FSRC < AC
3630						
3631						
3632						
3633	030164	004737	030326		KK10: JSR PC,KKSUB	
3634	030170	012345	067012	034567	12345,67012,34567,012345	: AC
3635	030200	012345	067012	034567	12345,67012,34567,012345	: FSRC
3636	030210	000204			204	: EXP FPS.
3637	030212	036440			.ASCII ' ='	: FSRC = AC
3638						
3639						
3640						
3641						
3642	030214	004737	030326		KK11: JSR PC,KKSUB	
3643	030220	012345	067012	034567	12345,67012,34567,012345	: AC
3644	030230	012345	070123	045670	12345,70123,45670,123456	: FSRC
3645	030240	000200			200	: EXP FPS.
3646	030242	037040			.ASCII ' >'	: FSRC > AC
3647						
3648						
3649						
3650						
3651	030244	004737	030326		KK12: JSR PC,KKSUB	
3652	030250	054321	076543	021076	54321,76543,21076,54321	: AC
3653	030260	054321	065432	107654	54321,65432,107654,32107	: FSRC
3654	030270	000210			210	: EXP FPS.
3655	030272	036040			.ASCII ' <'	: FSRC < AC


```

3656
3657
3658
3659
3660 030274 004737 030326
3661 030300 112345 043210 076543
3662 030310 112345 054321 007654
3663 030320 000210
3664 030322 036040
3665
3666 030324 000470
3667
3668
3669
3670
3671
3672
3673
3674
3675
3676
3677
3678
3679
3680
3681
3682
3683
3684
3685 030326 012637 001164
3686 030332 104411
3687 030334 013701 001164
3688 030340 012700 000217
3689 030344 170100
3690 030346 010100
3691 030350 172410
3692 030352 010037 001174
3693 030356 062700 000010
3694 030362 010037 001172
3695 030366 000240
3696 030370 173410
3697 030372 000240
3698 030374 170205
3699 030376 010537 001166
3700 030402 016137 000020 001170
3701 030410 012700 030476
(1) 030414 174010
3702 030416 010137 030426
3703 030422 004537 004312
3704 030426 000000 030476
3705 030432 001407
3706 030434 010137 001172
3707 030440 012737 030476 001174
3708 030446 104202
3709 030450 000410
3710
  
```

```

:TEST CMPD WITH AC NEGATIVE, FSRC NEGATIVE, EAC EQUAL TO EFSRC,
:AND AC GREATER THAN FSRC
KK13: JSR PC,KKSUB
      112345,43210,76543,21076 ; AC
      112345,54321,07654,32107 ; FSRC
      210 ; EXP FPS.
      .ASCII ' <' ; FSRC < AC
BR KKDONE ; FINALLY !.

:SUBROUTINE TO SET-UP, EXECUTE AND CHECK THE CMPD INSTRUCTION.
:CALL: JSR PC,KKSUB
: .WORD X,X,X,X ;AC OPERAND
: .WORD X,X,X,X ;FSRC OPERAND
: .WORD X ; EXPECTED FPS.
: .ASCII ' =' ; RELATIONAL OPERATOR...
: ;...FOR ERROR MESSAGE.
: ; RETURN TO CALLER+24

: OPERANDS ARE SELECTED FROM THE CALLING PC.
: THE FPS IS INITIALIZED TO DOUBLE MODE WITH ALL CONDITION CODE
: BITS SET (000217). THEN THE COMPARE INSTRUCTION IS EXECUTED.
: AFTER EXECUTION, THE AC OPERAND SHOULD BE UNCHANGED, AND THE
: FPS SHOULD EQUAL THE PREDICTED VALUE. IF SO RETURN.
: OTHERWISE, REPORT THE APPROPRIATE ERROR, AND RETURN.
KKSUB: MOV (SP)+,$TMP2 ; SAVE CALL PC AS ERROR PC...
      LUPERR ; ; LOOP HERE ON ERROR IF SWR9 1.
      MOV $TMP2,R1 ; ...AND USE AS ARG POINTER.
      MOV #217,R0
      LDFPS R0 ; INITIALIZE FPS.
      MOV R1,R0 ; LOAD UP...
      LDD (R0),ACO ; ...AC OPERAND
      MOV R0,$TMP6
      ADD #10,R0 ; POINT TO FSRC OPERAND.
      MOV R0,$TMP5
      NOP ;FOR SCOPING.
2$: CMPD (R0),ACO ;EXECUTE THE TEST INSTRUCTION.
      NOP
      STFPS R5 ;GET FPS AFTER INSTRUCTION.
      MOV R5,$TMP3
      MOV 20(R1),$TMP4 ; SET EXPECTED FPS.
      MOV #10$,R0
      STD ACO,(R0) ; ; STORE ACO
      MOV R1,3$ ; ORIGINAL AC ADDRESS.
3$: JSR R5,CHECK4
      O,10$ ; EXP VS RECD.
      BEQ 4$ ; BR IF AC IS STILL OK.
      MOV R1,$TMP5 ; AC BEFORE.
      MOV #10$,$TMP6 ; AC AFTER.
      ERROR 202 ; REPORT AC CHANGED.
      BR 5$
  
```

CJFPAA -- LSI11/23 FPF11 DIAGNOSTIC, PART 1
CJFPAA.P11 28-JAN-81 09:50 T42

MACY11 30G(1063) ^{K 9} 28-JAN-81 10:06 PAGE 2-84
CMPD -- FSRC MODE 1

SEQ 0114

3711	030452	023737	001166	001170	4\$:	CMP	\$TMP3,\$TMP4	:	FPS RIGHT ?:
3712	030460	001404				BEQ	5\$:	BR IF SO.
3713	030462	016137	000022	055332		MOV	22(R1),EM201X	:	SET CORRECT OPERATER IN ERR.
3714	030470	104201				ERROR	201	:	REPORT FPS WRONG.
3715									
3716	030472	000161	000024		5\$:	JMP	24(R1)	:	RETURN.
3717									
3718	030476	000000	000000	000000	10\$:	.WORD	0,0,0,0	:	TEMP DATA BUFFER.
3719									
3720	030506					KKDONE:			
(1)	030506	104412				CLRFPS		::	CLEAR FP STATUS...
(3)	030510	000400				BR	TST43	::	...AND PROCEED.

```
3729 .....  
(3) *TEST 43 DIVD -- FSRC MODE 1, WITH DIVISOR - 0  
(4) *  
(4) *THIS IS A TEST OF THE DIVD INSTRUCTION WITH A  
(4) *ZERO DIVISOR. THE CONDITION IS CHECKED WITH BOTH  
(4) *TRAP ENABLED AND TRAPS DISABLED.  
(4) *  
(3) .....  
(2) 030512 000004 TST43: SCOPE  
3730 .....  
3731 : FIRST BOTH DIVISOR AND DIVIDEND = 0, WITH TRAP DISABLED.  
3732 :  
3733 030514 012737 001172 001166 LL0: MOV #STMP5,$STMP3 ; EXPD STATS POINTER.  
3734 030522 012737 001176 001170 MOV #STMP7,$STMP4 ; RECD STATS POINTER.  
3735 030530 104411 LUPERR ; LOOP HERE ON ERROR IF SWR9 - 1.  
3736 030532 012704 040200 MOV #40200,R4 ; SET UP FPS...  
3737 030536 170104 LDFPS R4 ; ...WITH FID = 1.  
3738 030540 012737 030566 001164 MOV #20$,$STMP2  
3739 030546 012737 030640 000244 MOV #2$,$FPVEC ; SET TRAP CATCHER.  
3740 030554 012700 031144 MOV #LLP1,R0  
(1) 030560 172410 LDD (R0),ACO ; LOAD ACO  
3741 030562 012700 031144 MOV #LLP1,R0 ; DIVISOR = 0  
3742 030566 174410 20$: DIVD (R0),ACO ; 0/0 = ERROR.  
3743 030570 000240 240  
3744 030572 012737 140204 001172 MOV #140204,$STMP5 ; EXPECTED FPS...  
3745 030600 012737 000004 001174 MOV #4,$STMP6 ; ...AND FEC.  
3746 030606 170205 STFPS R5  
3747 030610 010537 001176 MOV R5,$STMP7 ; RECEIVED FPS...  
3748 030614 170304 STST R4  
3749 030616 010437 001200 MOV R4,$STMP10 ; ...AND FEC.  
3750 030622 004537 004302 JSR R5,CHECK2  
3751 030626 001172 001176 $STMP5,$STMP7  
3752 030632 001405 BEQ LL2 ; BR IF BOTH ARE RIGHT.  
3753  
3754 030634 104203 ERROR 203 ; FPS OR FEC WRONG.  
3755 030636 000403 BR LL2  
3756  
3757 030640 022626 2$: CMP (SP)+,(SP)+ ; IT TRAPPED ?????  
3758 030642 004737 031116 JSR PC,LL244 ; REPORT ERROR AND RETURN.  
3759 :  
3760 : NOW DIVIDE +N/0 WITH TRAP DISABLED.  
3761 :  
3762 LL2: LUPERR ; LOOP HERE ON ERROR IF SWR9 1.  
(1) 030646 104411  
3763 030650 012704 040200 MOV #40200,R4  
3764 030654 170104 LDFPS R4  
3765 030656 012737 030704 001164 MOV #20$,$STMP2  
3766 030664 012737 030756 000244 MOV #2$,$FPVEC  
3767 030672 012700 031154 MOV #LLP2,R0  
(1) 030676 172410 LDD (R0),ACO ; LOAD ACO  
3768 030700 012700 031144 MOV #LLP1,R0 ; DIVISOR = 0  
3769 030704 174410 20$: DIVD (R0),ACO ; +N/0 = ERROR.  
3770 030706 000240 240  
3771 030710 012737 140200 001172 MOV #140200,$STMP5 ; EXPECTED FPS...  
3772 030716 012737 000004 001174 MOV #4,$STMP6 ; ...AND FEC.  
3773 030724 170205 STFPS R5
```

```

3774 030726 010537 001176      MOV    R5,$TMP7      ; RECEIVED FPS...
3775 030732 170305              STST   R5
3776 030734 010537 001200      MOV    R5,$TMP10     ; ...AND FEC.
3777 030740 004537 004302      JSR    R5,CHECK2
3778 030744 001172 001176      $TMP5,$TMP7
3779 030750 001405              BEQ    LL4            ; BR IF BOTH OK.
3780
3781 030752 104203              ERROR  203           ; FPS OR FEC WRONG.
3782 030754 000403              BR     LL4
3783
3784 030756 022626 031116      2$:    CMP    (SP)+,(SP)+ ; IT TRAPPED, FIX STACK.
3785 030760 004737              JSR    PC,LL244      ; REPORT AND RETURN.
3786
3787      ; FINALLY, +N/O WITH TRAP ENABLED.
3788
3789 030764              LL4:
(1) 030764 104411              LUPERR ;: LOOP HERE ON ERROR IF SWR9 1.
3790 030766 012704 000200      MOV    #200,R4      ;: SET UP FPS. TRAP ENABLED.
3791 030772 170104              LDFPS  R4
3792 030774 012737 031022 001164      MOV    #20$, $TMP2
3793 031002 012737 031046 000244      MOV    #1$,FPVEC    ; SET TRAP VECTOR.
3794 031010 012700 031154              MOV    #LLP2,R0
(1) 031014 172410              LDD    (R0),ACO     ;: LOAD ACO
3795 031016 012700 031144              MOV    #LLP1,R0    ;: DIVISOR = 0
3796 031022 174410      20$:    DIVD  (R0),ACO    ; +N/O = ERROR AND TRAP.
3797 031024 000240              240
3798 031026 170205              STFPS  R5
3799 031030 010537 001176      MOV    R5,$TMP7
3800 031034 170305              STST   R5
3801 031036 010537 001200      MOV    R5,$TMP10
3802 031042 104204              ERROR  204
3803 031044 000447              BR     LLDONE        ; ...AND QUIT.
3804
3805 031046 022626 001172      1$:    CMP    (SP)+,(SP)+ ; TRAP SEEMS OK, FIX STACK.
3806 031050 012737 100200 001172      MOV    #100200,$TMP5 ; EXPECTED FPS...
3807 031056 012737 000004 001174      MOV    #4,$TMP6     ; ...AND FEC.
3808 031064 170205              STFPS  R5
3809 031066 010537 001176      MOV    R5,$TMP7    ; RECEIVED FPS...
3810 031072 170305              STST   R5
3811 031074 010537 001200      MOV    R5,$TMP10   ; ...AND FEC.
3812 031100 004537 004302      JSR    R5,CHECK2
3813 031104 001172 001176      $TMP5,$TMP7
3814 C31110 001401              BEQ    3$           ; BR IF BOTH OK.
3815
3816 031112 104203              ERROR  203           ; FPS OR FEC WRONG.
3817 031114 000423              3$:    BR     LLDONE
3818
3819      ; REPORT DIVIDE BY 0 TRAPPED WHEN FID = 1.
3820
3821 031116 170205              LL244: STFPS  R5
3822 031120 010537 001176      MOV    R5,$TMP7
3823 031124 170305              STST   R5
3824 031126 010537 001200      MOV    R5,$TMP10
3825 031132 012637 031142      MOV    (SP)+,1$    ; IN CASE LOOP IS SET.
3826 031136 104205              ERROR  205           ; TRAPPED WHEN IT SHOULDN'T.
3827 031140 000137              JMP    @PC+

```

CJIPAA -- LSI11/23 FPF11 DIAGNOSTIC, PART 1
CJIPAA.P11 28-JAN-81 09:50 T43

N 9
MACY11 30G(1063) 28-JAN-81 10:06 PAGE 2-87
DIVD -- FSRC MODE 1, WITH DIVISOR = 0

SFO 0117

3828 031142 000000 18: 0
3829
3830 031144 000000 000000 000000 LLP1: .WORD 0,0,0,0 : DIVISOR
3831 031154 012345 054321 023456 LLP2: .WORD 12345,54321,23456,76543
3832
3833 031164 LLDONE:
(1) 031164 104412 CLRFP5
(3) 031166 000400 BR TST44

:: CLEAR FP STATUS...
::...AND PROCEED.

3845
(3)
(4)
(4)
(4)
(4)
(4)
(4)
(4)
(3)
(2) 03117C 000004
3846
3847
3848
3849 031172 004737 031600
3850 031176 000000 0000C0
3851 031202 012345 067012
3852 031206 000000 000000
3853 031212 000017 000004
3854
3855
3856
3857 031216 004737 031600
3858 031222 065652 125252
3859 031226 065600 000000
3860 031232 040252 125252
3861 031236 000017 000000
3862
3863
3864
3865 031242 004737 031600
3866 031246 076400 000000
3867 031252 076400 000000
3868 031256 040200 000000
3869 031262 000017 000000
3870
3871
3872
3873 031266 004737 031600
3874 031272 056777 177777
3875 031276 054200 000000
3876 031302 042777 177777
3877 031306 000017 000000
3878
3879
3880
3881 031312 004737 031600
3882 031316 012377 177777
3883 031322 012300 000000
3884 031326 040252 125252
3885 031332 000017 000000
3886
3887
3888
3889 031336 004737 031600

```
*****
:TEST 44      DIVF -- FSRC MODE 1
:
:TEST THE DIVF INSTRUCTION WITH A VARIETY OF OPERANDS.
: A COMMON SUBROUTINE IS USED TO SET UP OPERANDS, EXECUTE THE
: INSTRUCTION, AND CHECK THE RESULTS.
: NOTE THAT ON ERROR, THE 'ERROR PC' REPORTED IS THE PC OF THE
: OPERAND SET WHICH RESULTED IN THE ERROR AND NOT THAT OF THE
: OFFENDING INSTRUCTION ITSELF.
:
:*****
TST44: SCOPE
:
:CHECK DIVF WITH (AC 0).
:
MM1:   JSR      PC,MMSUB
       .WORD    0,0           :AC
       .WORD    12345,67012  :FSRC
       .WORD    0,0           :EXP RESULT.
       .WORD    17,4         :FPS BEFORE AND AFTER.
:
:TEST DIVF WITH AC POSITIVE, FSRC POSITIVE AND IN ROUND MODE.
:
MM2:   JSR      PC,MMSUB
       .WORD    65652,125252 :AC
       .WORD    65600,0       :FSRC
       .WORD    40252,125252 :RES
       .WORD    17,0         :FPS BEFORE AND AFTER.
:
:TEST DIVF WITH AC POSITIVE, FSRC POSITIVE.
:
MM3:   JSR      PC,MMSUB
       .WORD    76400,0       :AC
       .WORD    76400,0       :FSRC
       .WORD    40200,0       :RES
       .WORD    17,0         :FPS'S.
:
:TEST DIVF WITH BOTH OPERANDS POSITIVE.
:
MM4:   JSR      PC,MMSUB
       .WORD    56777,177777 :AC
       .WORD    54200,0       :FSRC
       .WORD    42777,177777 :RES
       .WORD    17,0         :FPS'S
:
:TEST THE DIVF INSTRUCTION:
:
MM5:   JSR      PC,MMSUB
       .WORD    12377,177777 :AC
       .WORD    12300,0       :FSRC
       .WORD    40252,125252 :RES
       .WORD    17,0         :FPS'S
:
:TEST DIVIDE ALGORITHM. TEST ROUND CONSTANT.
:
MM6:   JSR      PC,MMSUB
```

3890 031342 064600 000001
3891 031346 066600 000000
3892 031352 036200 000001
3893 031356 000017 000000

.WORD 64600,1 ;AC
.WORD 66600,0 ;FSRC
.WORD 36200,1 ;RES
.WORD 17,0 ;FPS'S

:
:TEST DIVF.
:

3897 031362 004737 031600
3898 031366 034577 177776
3899 031372 023400 000000
3900 031376 051377 177776
3901 031402 000017 000000

MM7: JSR PC,MMSUB
.WORD 34577,177776 ;AC
.WORD 23400,0 ;FSRC
.WORD 51377,177776 ;RES
.WORD 17,0 ;FPS'S

:
:DIVF TEST.
:

3905 031406 004737 031600
3906 031412 067652 125252
3907 031416 056500 000000
3908 031422 051343 107070
3909 031426 000017 000000

MM8: JSR PC,MMSUB
.WORD 67652,125252 ;AC
.WORD 56500,0 ;FSRC
.WORD 51343,107070 ;RES
.WORD 17,0 ;FPS'S

:
:DIVF WITH AC NEGATIVE, FSRC NEGATIVE.
:

3913 031432 004737 031600
3914 031436 140400 000000
3915 031442 140500 000000
3916 031446 040052 125253
3917 031452 000017 000000

MM9: JSR PC,MMSUB
.WORD 140400,0 ;AC
.WORD 140500,0 ;FSRC
.WORD 040052,125253 ;RES
.WORD 17,0 ;FPS'S

:
:DIVF WITH AC NEGATIVE AND FSRC POSITIVE.
:

3921 031456 004737 031600
3922 031462 160077 000000
3923 031466 040277 000000
3924 031472 160000 000000
3925 031476 000017 000010

MM10: JSR PC,MMSUB
.WORD 160077,0 ;AC
.WORD 40277,0 ;FSRC
.WORD 160000,0 ;RES
.WORD 17,10 ;FPS'S.

:
:DIVF WITH AC POSITIVE AND FSRC NEGATIVE.
:

3929 031502 004737 031600
3930 031506 040400 000000
3931 031512 140500 000000
3932 031516 140052 125253
3933 031522 000017 000010

MM11: JSR PC,MMSUB
.WORD 40400,0 ;AC
.WORD 140500,0 ;FSRC
.WORD 140052,125253 ;RES
.WORD 17,10 ;FPS'S

:
:TEST DIVF BOTH OPERANDS POSITIVE AND TRUNCATE MODE.
:

3937 031526 004737 031600
3938 031532 060100 000001
3939 031536 040300 000000
3940 031542 060000 000000
3941 031546 000057 000040

MM12: JSR PC,MMSUB
.WORD 60100,1 ;AC
.WORD 40300,0 ;FSRC
.WORD 60000,0 ;RES
.WORD 57,40 ;FPS'S

:
:DIVF WITH POSITIVE OPERANDS AND ROUND MODE.
:

3945 031552 004737 031600

MM13: JSR PC,MMSUB

```

3946 031556 060100 000001 .WORD 60100,1 ;AC
3947 031562 040300 000000 .WORD 40300,0 ;FSRC
3948 031566 060000 000001 .WORD 60000,1 ;RES
3949 031572 000017 000000 .WORD 17,0 ;FPS'S
3950
3951 031576 000471 BR MMDONE ; WHEW !...!..
3952
3953 : SUBROUTINE TO SET-UP, EXECUTE, AND CHECK THE RESULTS OF DIVF.
3954
3955 : CALL:
3956 JSR PC,@MMSUB
3957 .WORD X,X ; AC OPERAND (DIVIDEND).
3958 .WORD X,X ; FSRC OPERAND (DIVISOR).
3959 .WORD X,X ; EXPECTED RESULT.
3960 .WORD X,X ; FPS BEFORE AND EXP FPS AFTER.
3961 : RETURN TO CALLER+20
3962
3963 : THE OPERANDS ARE SELECTED USING THE CALLERS PC.
3964 : AFTER EXECUTION, THE QUOTIENT, AND THE RESULTING FPS ARE
3965 : TESTED. IF BOTH OK, RETURN.
3966 : OTHERWISE, REPORT ERROR AND RETURN.
3967
3968 031600 02637 001164 MMSUB: MOV (SP)+,$TMP2 ; SAVE CALL PC AS ERROR PC...
3969 031604 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 1.
3970 031606 013701 001164 MOV $TMP2,R1 ;...AND USE TO GET ARGS.
3971 031612 170011 SETD
3972 031614 172427 000000 LDD #0,AC0 ; CLEAR ACO.
3973 031620 016100 000014 MOV 14(R1),R0
3974 031624 170100 LDFPS R0 ; SET INITIAL FPS (F MODE).
3975 031626 010100 MOV R1,R0
3976 031630 172410 LDF (R0),AC0 ; LOAD THE DIVIDEND.
3977 031632 010037 001172 MOV R0,$TMP5
3978 031636 010100 MOV R1,R0
3979 031640 062700 000004 ADD #4,R0 ;POINT TO DIVISOR.
3980 031644 010037 001174 MOV R0,$TMP6
3981 031650 174410 2$: DIVF (R0),AC0 ;TEST INSTRUCTION.
3982 031652 000240 NOP
3983 031654 170204 STFPS R4 ;GET THE FPS.
3984 031656 010437 001166 MOV R4,$TMP3
3985 031662 016137 000016 001170 MOV 16(R1),$TMP4 ; EXP FPS.
3986 031670 170011 SETD ; RETURN TO DOUBLE MODE.
3987 031672 012700 031752 MOV #20$,R0
(1) 031676 174010 STD ACO,(R0) ;: STORE ACO
3988 031700 010037 001200 MOV R0,$TMP10 ; POINTS TO REC'D RESULT.
3989 031704 010100 MOV R1,R0
3990 031706 062700 000010 ADD #10,R0
3991 031712 010037 001176 MOV R0,$TMP7 ; POINTS TO EXP RESULT.
3992 031716 010037 031726 MOV R0,$3$
3993 031722 004537 004302 JSR R5,CHECK2 ; RESULT CORRECT ??
3994 031726 000000 031752 3$: 0,20$
3995 031732 001004 BNE 4$ ; BR IF NOT.
3996 031734 023737 001166 001170 CMP $TMP3,$TMP4 ; FPS RIGHT ??
3997 031742 001401 BEQ 5$ ; RETURN IF BOTH OK.
3998 031744 104206 4$: ERROR 206 ; FPS OR RESULT INCORRECT.
3999
4000 031746 000161 000020 5$: JMP 20(R1) ; RETURN

```



```
4001  
4002 031752 000000 000000 000000 20%: .WORD 0,0,0,0 ; TMP DATA BUFFER.  
4003  
4004 031762 MMDONE:  
(1) 031762 104412 CLRFP5 ;: CLEAR FP STATUS...  
(3) 031764 000400 BR TST45 ;: ...AND PROCEED.
```

4016
(3)
(4)
(4)
(4)
(4)
(4)
(4)
(4)
(3)
(2) 031766 000004
4017
4018
4019
4020 031770 004737 032542
4021 031774 034277 000000 000000
4022 032004 040277 000000 000000
4023 032014 034200 000000 000000
4024 032024 000217 000200
4025
4026
4027
4028 032030 004737 032542
4029 032034 134277 000000 000000
4030 032044 040277 000000 000000
4031 032054 134200 000000 000000
4032 032064 000217 000210
4033
4034
4035
4036 032070 004737 032542
4037 032074 134200 000000 000000
4038 032104 140300 000000 000000
4039 032114 034200 000000 000000
4040 032124 000257 000240
4041
4042
4043
4044 032130 004737 032542
4045 032134 034300 000000 000000
4046 032144 140300 000000 000000
4047 032154 134200 000000 000000
4048 032164 000217 000210
4049
4050
4051
4052 032170 004737 032542
4053 032174 100400 000000 000000
4054 032204 000500 000000 000000
4055 032214 140052 125252 125252
4056 032224 000257 000250
4057
4058
4059
4060 032230 004737 032542

```
.....  
*TEST 45      DIVD -- FSRC MODE 1  
*  
*TEST THE DIVD INSTRUCTION WITH A VARIETY OF OPERANDS.  
*A COMMON SUBROUTINE IS USED TO SET UP OPERANDS, EXECUTE THE  
*INSTRUCTION, AND CHECK THE RESULTS.  
*NOTE THAT ON ERROR, THE 'ERROR PC' REPORTED IS THE PC OF THE  
*OPERAND SET WHICH RESULTED IN THE ERROR AND NOT THAT OF THE  
*OFFENDING INSTRUCTION ITSELF.  
*  
.....  
TST45: SCOPE  
:  
:DIVD TEST WITH POSITIVE OPERANDS AND IN ROUND MODE.  
:  
NN1:  JSR      PC,NNSUB  
      .WORD   34277,0,0,0      :AC  
      .WORD   40277,0,0,0      :FSRC  
      .WORD   34200,0,0,0      :RES  
      .WORD   217,200          :FPS BEFORE AND AFTER DIVD.  
:  
:DIVD WITH AC NEGATIVE AND FSRC POSITIVE IN ROUND MODE.  
:  
NN2:  JSR      PC,NNSUB  
      .WORD   134277,0,0,0     :AC  
      .WORD   40277,0,0,0     :FSRC  
      .WORD   134200,0,0,0    :RES  
      .WORD   217,210         :FPS BEFORE AND AFTER.  
:  
:DIVD TEST WITH OPERANDS BOTH NEGATIVE AND IN TRUNCATE MODE.  
:  
NN3:  JSR      PC,NNSUB  
      .WORD   134300,0,0,1    :AC  
      .WORD   140300,0,0,0    :FSRC  
      .WORD   34200,0,0,0     :RES  
      .WORD   257,240         :FPS BEFORE AND AFTER.  
:  
:DIVD WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.  
:  
NN4:  JSR      PC,NNSUB  
      .WORD   34300,0,0,1     :AC  
      .WORD   140300,0,0,0    :FSRC  
      .WORD   134200,0,0,1    :RES  
      .WORD   217,210         :FPS BEFORE AND AFTER.  
:  
:DIVD TEST. TRUNCATE.  
:  
NN5:  JSR      PC,NNSUB  
      .WORD   100400,0,0,0    :AC  
      .WORD   500,0,0,0       :FSRC  
      .WORD   140052,125252,125252,125252 :RES  
      .WORD   257,250         :FPS'S  
:  
:DIVD TEST WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.  
:  
NN6:  JSR      PC,NNSUB
```

```

4061 032234 000400 000000 000000 .WORD 400,0,0,0 ;AC
4062 032244 100500 000000 000000 .WORD 100500,0,0,0 ;FSRC
4063 032254 140052 125252 125252 .WORD 140052,125252,125252,125253 ;RES
4064 032264 000217 000210 .WORD 217,210 ;FPS'S
4065
4066 ; DIVD TEST. ROUND.
4067
4068 032270 004737 032542 NN7: JSR PC,MNSUB
4069 032274 170360 170360 170360 .WORD 170360,170360,170360,170360 ;AC
4070 032304 170360 170360 170360 .WORD 170360,170360,170360,170360 ;FSRC
4071 032314 040200 000000 000000 .WORD 40200,0,0,0 ;RES
4072 032324 000217 000200 .WORD 217,200 ;FPS'S
4073
4074 ; NOW AN OVERFLOW CASE (TWICE).
4075
4076 032330 004737 032532 NN8: JSR PC,MNSUB1
4077 032334 077777 177777 177777 .WORD 077777,-1,-1,-1 ; AC
4078 032344 040000 000000 000000 .WORD 040000,0,0,1 ; FSRC
4079 032354 000177 177777 177777 .WORD 000177,-1,-1,-3 ; RESULT (FIV = 1).
4080 032364 041217 141206 .WORD 41217,141206 ; FPS'S
4081
4082 032370 004737 032532 JSR PC,MNSUB1
4083 032374 077777 177777 177777 .WORD 077777,-1,-1,-1
4084 032404 040000 000000 000000 .WORD 040000,0,0,1
4085 032414 000000 000000 000000 .WORD 0,0,0,0 ; RESULT (FIV = 0).
4086 032424 000217 000206 .WORD 217,206
4087
4088 ; AND FINALLY, AND UNDERFLOW CASE (TWICE).
4089
4090 032430 004737 032532 NN9: JSR PC,MNSUB1
4091 032434 000200 000000 000000 .WORD 000200,0,0,0 ; AC
4092 032444 040200 000000 000000 .WORD 040200,0,0,1 ; FSRC
4093 032454 000177 177777 177777 .WORD 000177,-1,-1,-2 ; RESULT (FIU = 1).
4094 032464 042217 142204 .WORD 42217,142204 ; FPS'S.
4095
4096 032470 004737 032532 JSR PC,MNSUB1
4097 032474 000200 000000 000000 .WORD 000200,0,0,0
4098 032504 040200 000000 000000 .WORD 040200,0,0,1
4099 032514 000000 000000 000000 .WORD 0,0,0,0 ; RESULT (FIU = 0).
4100 032524 000217 000204 .WORD 217,204
4101
4102 032530 000474 BR MNDONE ; FINISHED.
4103
4104 ; SUBROUTINE TO SET-UP, EXECUTE, AND CHECK THE RESULTS OF DIVD.
4105
4106 ; CALL:
4107 JSR PC,MNSUB ; OR MNSUB1
4108 .WORD X,X,X,X ; AC OPERAND (DIVIDEND).
4109 .WORD X,X,X,X ; FSRC OPERAND (DIVISOR).
4110 .WORD X,X,X,X ; EXPECTED RESULT.
4111 .WORD X,X ; FPS BEFORE AND EXP FPS AFTER.
4112 ; RETURN TO CALLER+34
4113
4114 ; THE OPERANDS ARE SELECTED USING THE CALLERS PC.
4115 ; AFTER EXECUTION, THE QUOTIENT, AND THE RESULTING FPS ARE
4116 ; TESTED. IF BOTH OK, RETURN.

```

```

4117 ; OTHERWISE, REPORT ERROR AND RETURN.
4118 ;
4119 032532 112737 000040 055740 NNSUB1: MOVB #40,EM207X ; ENABLE...
4120 032540 000402 SKP2
4121 032542 105037 055740 NNSUB: CLRB EM207X ;...OR DISABLE MESSAGE EXTENSION.
4122 032546 012637 001164 MOV (SP)+,$TMP2 ; SAVE CALL PC AS ERROR PC...
4123 032552 104411 LUPERR ; ; LOOF HERE ON ERROR IF SWR9 - 1.
4124 032554 013701 001164 MOV $TMP2,R1 ;...AND USE TO GET ARGS.
4125 032560 016100 000030 MOV 30(R1),R0
4126 032564 170100 LDFPS R0 ; SET INITIAL FPS.
4127 032566 010100 MOV R1,R0
4128 032570 172410 LDD (R0),ACO ; LOAD THE DIVIDEND.
4129 032572 010037 001172 MOV R0,$TMP5
4130 032576 010100 MOV R1,R0
4131 032600 062700 000010 ADD #10,R0 ;POINT TO DIVISOR.
4132 032604 010037 001174 MOV R0,$TMP6
4133 032610 174410 2$: DIVD (R0),ACO ;TEST INSTRUCTION.
4134 032612 000240 NOP
4135 032614 170204 STFPS R4 ;GET THE FPS.
4136 032616 010437 001166 MOV R4,$TMP3
4137 032622 016137 000032 001170 MOV 32(R1),$TMP4 ; EXP FPS.
4138 032630 170011 SETD ; INSURE DOUBLE STILL SET.
4139 032632 012700 032712 MOV #20$,R0
(1) 032636 174010 STD ACO,(R0) ;; STORE ACO
4140 032640 010037 001200 MOV R0,$TMP10 ; POINTS TO REC'D RESULT.
4141 032644 010100 MOV R1,R0
4142 032646 062700 000020 ADD #20,R0
4143 032652 010037 001176 MOV R0,$TMP7 ; POINTS TO EXP RESULT.
4144 032656 010037 032666 MOV R0,3$
4145 032662 004537 004312 JSR R5,CHECK4 ; RESULT CORRECT ??
4146 032666 000000 032712 3$: 0,20$
4147 032672 001004 BNE 4$ ; BR IF NOT.
4148 032674 023737 001166 001170 CMP $TMP3,$TMP4 ; FPS RIGHT ??
4149 032702 001401 BEQ 5$ ; RETURN IF BOTH OK.
4150 032704 104207 4$: ERROR 207 ; FPS OR RESULT INCORRECT.
4151
4152 032706 000161 000034 5$: JMP 34(R1) ; RETURN
4153
4154 032712 000000 000000 000000 20$: .WORD 0,0,0,0 ; TMP DATA BUFFER.
4155
4156 032722 NNDONE:
(1) 032722 114412 CLRFPS ;; CLEAR FP STATUS...
(3) 032724 000400 BR TST46 ;...AND PROCEED.
    
```

4168
(3)
(4)
(4)
(4)
(4)
(4)
(4)
(4)
(3)
(2) 032726 000004
4169
4170
4171
4172 032730 004737 033406
4173 032734 000000 000000
4174 032740 000000 000000
4175 032744 000000 000000
4176 032750 000017 000004
4177
4178
4179
4180 032754 004737 033406
4181 032760 071625 034435
4182 032764 000000 000000
4183 032770 000000 000000
4184 032774 000017 000004
4185
4186
4187
4188 033000 004737 033406
4189 033004 000000 000000
4190 033010 071625 153443
4191 033014 000000 000000
4192 033020 000017 000004
4193
4194
4195
4196 033024 004737 033406
4197 033030 040200 000000
4198 033034 040177 177777
4199 033040 040177 177777
4200 033044 000017 000000
4201
4202
4203
4204 033050 004737 033406
4205 033054 040177 177777
4206 033060 040200 000000
4207 033064 040177 177777
4208 033070 000057 000040
4209
4210
4211
4212 033074 004737 033406

```
.....  
:TEST 46      MULF -- FSRC MODE 1  
:  
:TEST THE MULF INSTRUCTION WITH A VARIETY OF OPERANDS.  
:A COMMON SUBROUTINE IS USED TO SET UP OPERANDS, EXECUTE THE  
:INSTRUCTION, AND CHECK THE RESULTS.  
:NOTE THAT ON ERROR, THE 'ERROR PC' REPORTED IS THE PC OF THE  
:OPERAND SET WHICH RESULTED IN THE ERROR AND NOT THAT OF THE  
:OFFENDING INSTRUCTION ITSELF.  
:  
:.....  
TST46: SCOPE  
:  
:MULF WITH (FSRC=AC=0)  
:  
PP1:  JSR      PC,PPSUB  
:      .WORD   0,0           ;AC  
:      .WORD   0,0           ;FSRC  
:      .WORD   0,0           ;RES  
:      .WORD   17,4        ; FPS BEFORE AND AFTER MULF.  
:  
:MULF WITH (FSRC=0).  
:  
PP2:  JSR      PC,PPSUB  
:      .WORD   71625,34435  ;AC  
:      .WORD   0,0           ;FSRC  
:      .WORD   0,0           ;RES  
:      .WORD   17,4        ; FPS BEFORE AND AFTER.  
:  
:MULF WITH (AC=0)  
:  
PP3:  JSR      PC,PPSUB  
:      .WORD   0,0           ;AC  
:      .WORD   071625,153443 ;FSRC  
:      .WORD   0,0           ;RES  
:      .WORD   17,4        ; FPS'S  
:  
:MULF WITH AC POSITIVE AND FSRC POSITIVE IN ROUND MODE.  
:  
PP4:  JSR      PC,PPSUB  
:      .WORD   40200,0       ;AC  
:      .WORD   40177,-1     ;FSRC  
:      .WORD   40177,-1     ;RES  
:      .WORD   17,0        ; FPS'S.  
:  
:MULF WITH AC POSITIVE AND FSRC POSITIVE IN TRUNCATE MODE.  
:  
PP5:  JSR      PC,PPSUB  
:      .WORD   40177,-1     ;AC  
:      .WORD   40200,0       ;FSRC  
:      .WORD   40177,-1     ;RES  
:      .WORD   57,40       ; FPS'S  
:  
:MULF WITH BOTH OPERANDS POSITIVE NORMALIZE TEST.  
:  
PP6:  JSR      PC,PPSUB
```

4213 033100 040100 000000
4214 033104 040100 000000
4215 033110 040020 000000
4216 033114 000017 000000

.WORD 40100,0 ;AC
.WORD 40100,0 ;FSRC
.WORD 40020,0 ;RES
.WORD 17,0 ;FPS'S

:MULF WITH BOTH OPERANDS POSITIVE IN ROUND MODE.

4217
4218
4219
4220 033120 004737 033406
4221 033124 017500 000000
4222 033130 023652 125252
4223 033134 003177 177777
4224 033140 000017 000000

PP7: JSR PC,PPSUB
.WORD 17500,0 ;AC
.WORD 23652,125252 ;FSRC
.WORD 3177,-1 ;RES
.WORD 17,0 ;FPS'S

:MULF WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.

4225
4226
4227
4228 033144 004737 033406
4229 033150 040342 000000
4230 033154 176542 000000
4231 033160 176707 102000
4232 033164 000017 000010

PP8: JSR PC,PPSUB
.WORD 40342,0 ;AC
.WORD 176542,0 ;FSRC
.WORD 176707,102000 ;RES
.WORD 17,10 ;FPS'S.

:MULF WITH AC NEGATIVE AND FSRC POSITIVE IN ROUND MODE.

4233
4234
4235
4236 033170 004737 033406
4237 033174 140200 000000
4238 033200 007417 007417
4239 033204 107417 007417
4240 033210 000017 000010

PP9: JSR PC,PPSUB
.WORD 140200,0 ;AC
.WORD 7417,7417 ;FSRC
.WORD 107417,7417 ;RES
.WORD 17,10 ;FPS'S.

:MULF WITH BOTH OPERANDS NEGATIVE IN ROUND MODE.

4241
4242
4243
4244 033214 004737 033406
4245 033220 144600 000000
4246 033224 154000 000000
4247 033230 060400 000000
4248 033234 000017 000000

PP10: JSR PC,PPSUB
.WORD 144600,0 ;AC
.WORD 154000,0 ;FSRC
.WORD 60400,0 ;RES
.WORD 17,0 ;FPS'S

:MULF BOTH OPERANDS NEGATIVE IN ROUND MODE.

4249
4250
4251
4252 033240 004737 033406
4253 033244 140300 000000
4254 033250 160000 000001
4255 033254 060100 000002
4256 033260 000017 000000

PP11: JSR PC,PPSUB
.WORD 140300,0 ;AC
.WORD 160000,1 ;FSRC
.WORD 60100,2 ;RES
.WORD 17,0 ;FPS'S

:MULF WITH AC POSITIVE AND FSRC NEGATIVE IN TRUNCATE MODE.

4257
4258
4259
4260 033264 004737 033406
4261 033270 060000 000001
4262 033274 140300 000000
4263 033300 160100 000001
4264 033304 000057 000050

PP12: JSR PC,PPSUB
.WORD 60000,1 ;AC
.WORD 140300,0 ;FSRC
.WORD 160100,1 ;RES
.WORD 57,50 ;FPS'S

:MULF WITH AC POSITIVE AND FSRC POSITIVE IN ROUND MODE.

4265
4266
4267
4268 033310 004737 033406

PP13: JSR PC,PPSUB

4269 033314 040277 000000
 4270 033320 060000 000001
 4271 033324 060077 000001
 4272 033330 000017 000000
 4273
 4274
 4275
 4276 033334 004737 033406
 4277 033340 060252 125252
 4278 033344 060100 000000
 4279 033350 000177 177777
 4280 033354 041017 141006
 4281
 4282 033360 004737 033406
 4283 033364 020052 125252
 4284 033370 020300 000000
 4285 033374 000177 177777
 4286 033400 042017 142004
 4287
 4288 033404 000471
 4289
 4290
 4291
 4292
 4293
 4294
 4295
 4296
 4297
 4298
 4299
 4300
 4301
 4302
 4303
 4304
 4305 033406 012637 001164
 4306 033412 104411
 4307 033414 013701 001164
 4308 033420 170011
 4309 033422 172427 000000
 4310 033426 016100 000014
 4311 033432 170100
 4312 033434 010100
 4313 033436 172410
 4314 033440 010037 001172
 4315 033444 010100
 4316 033446 062700 000004
 4317 033452 010037 001174
 4318 033456 171010
 4319 033460 000240
 4320 033462 170204
 4321 033464 010437 001166
 4322 033470 016137 000016 001170
 4323 033476 170011
 4324 033500 012700 033560

```

: .WORD 40277,0 ; AC
: .WORD 60000,1 ; FSRC
: .WORD 60077,1 ; RES
: .WORD 17,0 ; FPS'S
:
: OVER AND UNDERFLOW (1 EACH).
PP14: JSR PC,PPSUB
: .WORD 060252,125252 ; AC
: .WORD 060100,0 ; FSRC
: .WORD 000177,-1
: .WORD 41017,141006 ; FPS'S (FIV = 1).
:
: JSR PC,PPSUB
: .WORD 020052,125252 ; AC
: .WORD 020300,0 ; FSRC
: .WORD 000177,-1
: .WORD 42017,142004 ; FPS'S (FIU = 1).
:
: BR PPDONE ; FINISHED.
:
: SUBROUTINE TO SET-UP, EXECUTE, AND CHECK THE RESULTS OF MULF.
: CALL:
: JSR PC,PPSUB
: .WORD X,X ; AC OPERAND (MULTIPLICAND).
: .WORD X,X ; FSRC OPERAND (MULTIPLIER).
: .WORD X,X ; EXPECTED PRODUCT.
: .WORD X,X ; FPS BEFORE AND EXP FPS AFTER.
: ; RETURN TO CALLER+20
:
: THE OPERANDS ARE SELECTED USING THE CALLERS PC.
: AFTER EXECUTION, THE PRODUCT, AND THE RESULTING FPS ARE
: TESTED. IF BOTH OK, RETURN.
: OTHERWISE, REPORT ERROR AND RETURN.
PPSUB: MOV (SP)+,$TMP2 ; SAVE CALL PC AS ERROR PC...
: LUPERR ;: LOOP HERE ON ERROR IF SWR9 - 1.
: MOV $TMP2,R1 ;...AND USE AS ARG POINTER.
: SETD
: LDD #0,ACO ; CLEAR ACO.
: MOV 14(R1),R0
: LDFPS R0 ; SET INITIAL FPS (F MODE).
: MOV R1,R0
: LDF (R0),ACO ; LOAD THE MULTIPLICAND.
: MOV R0,$TMP5
: MOV R1,R0
: ADD #4,R0 ; POINT TO MULTIPLIER.
: MOV R0,$TMP6
: 2$: MULF (R0),ACO ; TEST INSTRUCTION.
: NOP
: STFPS R4 ; GET THE FPS.
: MOV R4,$TMP3
: MOV 16(R1),$TMP4 ; EXP FPS.
: SETD ; RETURN TO DOUBLE MODE.
: MOV #20$,R0

```

(1)	033504	174010				STD	AC0,(R0)	:: STORE AC0
4325	033506	010037	001200			MOV	R0,\$TMP10	; POINTS TO REC'D RESULT.
4326	033512	010100				MOV	R1,R0	
4327	033514	062700	000010			ADD	#10,R0	
4328	033520	010037	001176			MOV	R0,\$TMP7	; POINTS TO EXP RESULT.
4329	033524	010037	033534			MOV	R0,3\$	
4330	033530	004537	004302			JSR	R5,CHECK2	; RESULT CORRECT ??
4331	033534	000000	033560		3\$:	O,20\$		
4332	033540	001004				BNE	4\$; BR IF NOT.
4333	033542	023737	001166	001170		CMF	\$TMP3,\$TMP4	; FPS RIGHT ??
4334	033550	001401				BEQ	5\$; RETURN IF BOTH OK.
4335	033552	104210			4\$:	ERROR	210	; FPS OR RESULT INCORRECT.
4336								
4337	033554	000161	000020		5\$:	JMP	20(R1)	; RETURN
4338								
4339	033560	000000	000000	000000	20\$:	.WORD	0,0,0,0	; TMP DATA BUFFER.
4340								
4341	033570				PPDONE:			
(1)	033570	104412				CLRFPS		:: CLEAR FP STATUS...
(3)	033572	000400				BR	1ST47	::...AND PROCEED.


```
4353 .....  
(3) *TEST 47 MULD -- FSRC MODE 1  
(4) *  
(4) *TEST THE MULD INSTRUCTION WITH A VARIETY OF OPERANDS.  
(4) *A COMMON SUBROUTINE IS USED TO SET UP OPERANDS, EXECUTE THE  
(4) *INSTRUCTION, AND CHECK THE RESULTS.  
(4) *NOTE THAT ON ERROR, THE 'ERROR PC' REPORTED IS THE PC OF THE  
(4) *OPERAND SET WHICH RESULTED IN THE ERROR AND NOT THAT OF THE  
(4) *OFFENDING INSTRUCTION ITSELF.  
(4) *  
(3) .....  
(2) 033574 000004 TST47: SCOPE  
4354 *MULD TEST WITH AC POSITIVE AND FSRC POSITIVE.  
4355  
4356  
4357 033576 004737 034250 QQ1: JSR PC,QQSUB  
4358 033602 040200 000000 000000 .WORD 40200,0,0,0 ;AC  
4359 033612 023777 177777 177777 .WORD 23777,-1,-1,-1 ;FSRC  
4360 033622 023777 177777 177777 .WORD 23777,-1,-1,-1 ;RES  
4361 033632 000217 000200 .WORD 217,200 ; FPS BEFORE AND AFTER MULD.  
4362  
4363 *MULD TEST WITH BOTH OPERANDS POSITIVE TRUNCATION TEST.  
4364  
4365 033636 004737 034250 QQ2 JSR PC,QQSUB  
4366 033642 065400 000000 000000 .WORD 65400,0,0,1 ;AC  
4367 033652 037577 177777 177777 .WORD 37577,-1,-1,-2 ;FSRC  
4368 033662 064777 177777 177777 .WORD 64777,-1,-1,-1 ;RES  
4369 033672 000257 000240 .WORD 257,240 ; FPS'S.  
4370  
4371 *MULD TEST WITH BOTH OPERANDS NEGATIVE IN ROUND MODE.  
4372  
4373 033676 004737 034250 QQ3: JSR PC,QQSUB  
4374 033702 137577 177777 177777 .WORD 137577,-1,-1,-2 ;AC  
4375 033712 165400 000000 000000 .WORD 165400,0,0,1 ;FSRC  
4376 033722 065000 000000 000000 .WORD 65000,0,0,0 ;RES  
4377 033732 000217 000200 .WORD 217,200 ; FPS'S.  
4378  
4379 *MULD TEST WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.  
4380  
4381 033736 004737 034250 QQ4: JSR PC,QQSUB  
4382 033742 017500 000000 000000 .WORD 17500,0,0,0 ;AC  
4383 033752 123652 125252 125252 .WORD 123652,125252,125252,125252 ;FSRC  
4384 033762 103177 177777 177777 .WORD 103177,-1,-1,-1 ;RES  
4385 033772 000217 000210 .WORD 217,210 ; FPS'S.  
4386  
4387 * OVERFLOW -- FINAL EXP > 128.  
4388  
4389 033776 004737 034240 QQ5: JSR PC,QQSUB1  
4390 034002 060252 125252 125252 .WORD 060252,125252,125252,125252 ; AC  
4391 034012 160300 000000 000000 .WORD 160300,0,0,0 ; FSRC  
4392 034022 100377 177777 177777 .WORD 100377,-1,-1,-1 ; RESULT (FIV - 1).  
4393 034032 041217 141212 .WORD 41217,141212 ; FPS'S.  
4394  
4395 * OVERFLOW -- FINAL EXP = 128.  
4396  
4397 034036 004737 034240 QQ6: JSR PC,QQSUB1
```

```

4398 034042 060252 125252 125252
4399 034052 160100 000000 000000
4400 034062 100177 177777 177777
4401 034072 041217 141216
4402
4403 034076 004737 034240
4404 034102 060252 125252 125252
4405 034112 160100 000000 000000
4406 034122 000000 000000 000000
4407 034132 000217 000206
4408
4409
4410
4411 034136 004737 034240
4412 034142 020052 125252 125252
4413 034152 020300 000000 000000
4414 034162 000177 177777 177777
4415 034172 042217 142204
4416
4417 034176 004737 034240
4418 034202 020052 125252 125252
4419 034212 020300 000000 000000
4420 034222 000000 000000 000000
4421 034232 000217 000204
4422
4423 034236 000474
4424
4425
4426
4427
4428
4429
4430
4431
4432
4433
4434
4435
4436
4437
4438
4439
4440 034240 112737 000040 056124
4441 034246 000402
4442 034250 105037 056124
4443 034254 012637 001164
4444 034260 104411
4445 034262 013701 001164
4446 034266 016100 000030
4447 034272 170100
4448 034274 010100
4449 034276 172410
4450 034300 010037 001172
4451 034304 010100
4452 034306 062700 000010
4453 034312 010037 001174

```

```

.WORD 060252,125252,125252,125252 ; AC
.WORD 160100,0,0,0 ; FSRC
.WORD 100177,-1,-1,-1 ; RESULT (FIV = 1).
.WORD 41217,141216 ; FPS'S.

JSR PC,QQSUB1 ; SAME OPERANDS, FIV = 0.
.WORD 060252,125252,125252,125252
.WORD 160100,0,0,0
.WORD 0,0,0,0 ; RESULT (FIV = 0)
.WORD 217,206

; AND FINALLY, AN UNDERFLOW CASE (TWICE).
007: JSR PC,QQSUB1
.WORD 20052,125252,125252,125252 ; AC
.WORD 20300,0,0,0 ; FSRC
.WORD 177,-1,-1,-1 ; RESULT (FIU = 1).
.WORD 42217,142204 ; FPS'S

JSR PC,QQSUB1
.WORD 20052,125252,125252,125252
.WORD 20300,0,0,0
.WORD 0,0,0,0 ; RESULT (FIU = 0).
.WORD 217,204

BR Q00DONE ; FINISHED.

; SUBROUTINE TO SET-UP, EXECUTE, AND CHECK THE RESULTS OF MULD.
CALL:
JSR PC,QQSUB ; OR QQSUB1
.WORD X,X,X,X ; AC OPERAND (MULTIPLICAND).
.WORD X,X,X,X ; FSRC OPERAND (MULTIPLIER).
.WORD X,X,X,X ; EXPECTED PRODUCT.
.WORD X,X ; FPS BEFORE AND EXP FPS AFTER.
; RETURN TO CALLER+34

; THE OPERANDS ARE SELECTED USING THE CALLERS PC.
; AFTER EXECUTION, THE PRODUCT, AND THE RESULTING FPS ARE
; TESTED. IF BOTH OK, RETURN.
; OTHERWISE, REPORT ERROR AND RETURN.

QQSUB1: MOVB #40,EM211X ; ENABLE MESSAGE EXTENSION.
SKP2
QQSUB: CLRB EM211X ; DISABLE MESSAGE EXTENSION.
MOV (SP)+,$TMP2 ; SAVE CALL PC AS ERROR PC...
LUPERR ; LOOP HERE ON ERROR IF SWR9 1.
MOV $TMP2,R1 ; ...AND USE AS ARG POINTER.
MOV 30(R1),R0
LDFPS R0 ; SET INITIAL FPS.
MOV R1,R0
LDD (R0),ACO ; LOAD THE MULTIPLICAND.
MOV R0,$TMP5
MOV R1,R0
ADD #10,R0 ; POINT TO MULTIPLIER.
MOV R0,$TMP6

```


4485
(3)
(4)
(4)
(4)
(4)
(3)
(2) 034434 000004
4486
4487
4488
4489 034436 004737 035160
4490 034442 000000 000000
4491 034446 000000 000000
4492 034452 000000 000000
4493 034456 000000 000000
4494 034462 000017 000004
4495
4496
4497
4498 034466 004737 035160
4499 034472 123456 076543
4500 034476 000000 000000
4501 034502 000000 000000
4502 034506 000000 000000
4503 034512 000017 000004
4504
4505
4506
4507 034516 004737 035160
4508 034522 000000 000000
4509 034526 076543 021234
4510 034532 000000 000000
4511 034536 000000 000000
4512 034542 000017 000004
4513
4514
4515
4516 034546 004737 035160
4517 034552 046252 125252
4518 034556 040300 000000
4519 034562 000000 000000
4520 034566 046377 177777
4521 034572 000017 000004
4522
4523
4524
4525 034576 004737 035160
4526 034602 077652 125252
4527 034606 040300 000000
4528 034612 000000 000000
4529 034616 077777 177777
4530 034622 000017 000004
4531
4532
4533

```
*****
*TEST 50      MODF -- FSRC MODE 1
*
*THIS IS A TEST OF THE MODF INSTRUCTION.
*A COMMON SUBROUTINE IS USED TO EXECUTE THE TEST AS BEFORE.
*
*****
TST50: SCOPE
:
:MODF WITH (FSRC=AC=0)
:
TT1:  JSR      PC,TTSUB
      .WORD   0,0           :AC
      .WORD   0,0           :FSRC
      .WORD   0,0           :FRACTIONAL RES.
      .WORD   0,0           :INTEGER RES.
      .WORD   17,4          :FPS BEFORE AND AFTER MODF.
:
:MODF TEST, WITH (FSRC=0)
:
TT2:  JSR      PC,TTSUB
      .WORD   123456,76543 :AC
      .WORD   0,0           :FSRC
      .WORD   0,0           :FRACTIONAL RES.
      .WORD   0,0           :INTEGER RESULT.
      .WORD   17,4          :FPS'S
:
:MODF TEST WITH (AC=0)
:
TT3:  JSR      PC,TTSUB
      .WORD   0,0           :AC
      .WORD   76543,21234   :FSRC
      .WORD   0,0           :FRACTIONAL RES.
      .WORD   0,0           :INTEGER RES.
      .WORD   17,4          :FPS'S
:
:MODF TEST WITH EXPONENT OF THE RESULT = 25
:
TT4:  JSR      PC,TTSUB
      .WORD   46252,125252 :AC
      .WORD   40300,0       :FSRC
      .WORD   0,0           :FRACTIONAL RES.
      .WORD   46377,-1     :INTEGER RES.
      .WORD   17,4          :FPS'S.
:
:MODF TEST WITH EXPONENT OF THE RESULT = 127
:
TT5:  JSR      PC,TTSUB
      .WORD   77652,125252 :AC
      .WORD   40300,0       :FSRC
      .WORD   0,0           :FRACTIONAL RES.
      .WORD   77777,-1     :INTEGER RES.
      .WORD   17,4          :FPS'S
:
:MODF TEST WITH EXPONENT OF RESULT = 25
:
*** THIS ONE FAILS UNDER MIMIC ???? ***
```

4534
4535 034626 004737 035160
4536 034632 046200 000001
4537 034636 040340 000000
4538 034642 000000 000000
4539 034646 046340 000001
4540 034652 000017 000004
4541
4542
4543
4544
4545 034656 004737 035160
4546 034662 046000 000001
4547 034666 040340 000000
4548 034672 040100 000000
4549 034676 046140 000001
4550 034702 000017 000000
4551
4552
4553
4554 034706 004737 035160
4555 034712 042577 177777
4556 034716 040200 000000
4557 034722 040177 176000
4558 034726 042577 140000
4559 034732 000017 000000
4560
4561
4562
4563 034736 004737 035160
4564 034742 042577 140001
4565 034746 040200 000000
4566 034752 034600 000000
4567 034756 042577 140000
4568 034762 000017 000000
4569
4570
4571
4572 034766 004737 035160
4573 034772 042377 100000
4574 034776 040200 000000
4575 035002 000000 000000
4576 035006 042377 100000
4577 035012 000017 000004
4578
4579
4580
4581 035016 004737 035160
4582 035022 040177 177777
4583 035026 040200 000000
4584 035032 040177 177777
4585 035036 000000 000000
4586 035042 000017 000000
4587
4588
4589

```

:IT6: JSR PC,TTSUB
      .WORD 46200,1      ;AC
      .WORD 40340,0      ;FSRC
      .WORD 0,0          ;FRACTIONAL RES.
      .WORD 46340,1      ;INTEGER RES.
      .WORD 17,4
:
:MODF TEST WITH EXPONENT OF THE RESULT = 24
:*** THIS ONE TOO, SOMFTIMES ??? ***
:
:IT7: JSR PC,TTSUB
      .WORD 46000,1      ;AC
      .WORD 40340,0      ;FSRC
      .WORD 40100,0      ;FRACTIONAL RES.
      .WORD 46140,1      ;INTEGER RESULT.
      .WORD 17,0        ;FPS'S
:
:MODF TEST WITH EXPONENT OF THE RESULT = 10
:
:IT8: JSR PC,TTSUB
      .WORD 42577,-1     ;AC
      .WORD 40200,0      ;FSRC
      .WORD 40177,176000 ;FRACTIONAL RES.
      .WORD 42577,140000 ;INTEGER RES.
      .WORD 17,0        ;FPS'S
:
:MODF TEST WITH THE EXPONENT OF THE RESULT = 10
:
:IT9: JSR PC,TTSUB
      .WORD 42577,140001 ;AC
      .WORD 40200,0      ;FSRC
      .WORD 34600,0      ;FRACTIONAL RES.
      .WORD 42577,140000 ;INTEGER RES.
      .WORD 17,0        ;FPS'S
:
:MODF TEST WITH EXPONENT OF THE RESULT = 9
:
:IT10: JSR PC,TTSUB
      .WORD 42377,100000 ;AC
      .WORD 40200,0      ;FSRC
      .WORD 0,0          ;FRACTIONAL RES.
      .WORD 42377,100000 ;INTEGER RES.
      .WORD 17,4        ;FPS'S
:
:MODF TEST WITH EXPONENT OF THE RESULT = 0
:
:IT11: JSR PC,TTSUB
      .WORD 40177,-1     ;AC
      .WORD 40200,0      ;FSRC
      .WORD 40177,-1     ;FRACTIONAL RES.
      .WORD 0,0          ;INTEGER RES.
      .WORD 17,0        ;FPS'S
:
:MODF TEST WITH EXPONENT OF THE RESULT = -15
:

```

4590 035046 004737 035160
4591 035052 034377 177777
4592 035056 040200 000000
4593 035062 034377 177777
4594 035066 000000 000000
4595 035072 000017 000000
4596
4597
4598
4599 035076 004737 035160
4600 035102 020000 000001
4601 035106 040300 000000
4602 035112 020100 000002
4603 035116 000000 000000
4604 035122 000017 000000
4605
4606
4607
4608 035126 004737 035160
4609 035132 142777 170000
4610 035136 040200 000000
4611 035142 140000 000000
4612 035146 142777 160000
4613 035152 000017 000010
4614
4615 035156 000517
4616
4617
4618
4619
4620
4621
4622
4623
4624
4625
4626
4627
4628
4629
4630
4631
4632
4633 035160 012637 001164
4634 035164 104411
4635 035166 013701 001164
4636 035172 170011
4637 035174 172427 000000
4638 035200 172527 000000
4639 035204 016100 000020
4640 035210 170100
4641 035212 010100
4642 035214 172410
4643 035216 010037 001172
4644 035222 010100
4645 035224 062700 000004

```
TT12: JSR PC,TTSUB
      .WORD 34377,-1 ;AC
      .WORD 40200,0 ;FSRC
      .WORD 34377,-1 ;FRACTIONAL RES.
      .WORD 0,0 ;INTEGER RES.
      .WORD 17,0 ;FPS'S
;
;MODF TEST WITH EXPONENT OF RESULT = -64, IN ROUND MODE
;
TT13: JSR PC,TTSUB
      .WORD 20000,1 ;AC
      .WORD 40300,0 ;FSRC
      .WORD 20100,2 ;FRACTIONAL RES.
      .WORD 0,0 ;INTEGER RES.
      .WORD 17,0 ;FPS'S
;
;MODF TEST WITH EXPONENT OF RESULT = 11
;
TT14: JSR PC,TTSUB
      .WORD 142777,170000 ;AC
      .WORD 40200,0 ;FSRC
      .WORD 140000,0 ;FRACTIONAL RES.
      .WORD 142777,160000 ;INTEGER RES.
      .WORD 17,10 ;FPS'S
;
BR TTDONE ; FINISHED.
;
SUBROUTINE TO SET-UP, EXECUTE, AND CHECK THE RESULTS OF MODF.
;
CALL:
      JSR PC,TTSUB
      .WORD X,X ; AC OPERAND (MULTIPLICAND).
      .WORD X,X ; FSRC OPERAND (MULTIPLIER).
      .WORD X,X ; RESULTING FRACTION (ACO).
      .WORD X,X ; RESULTING INTEGER (AC1).
      .WORD X,X ; FPS BEFORE AND EXP FPS AFTER.
      ; RETURN TO CALLER+24
;
THE OPERANDS ARE SELECTED USING THE CALLERS PC.
; AFTER EXECUTION THE RESULTING INTEGER, FRACTION, AND FPS
; ARE TESTED. IF ALL OK, RETURN.
; OTHERWISE, REPORT ERROR AND RETURN.
;
TTSUB: MOV (SP)+,$TMP2 ; SAVE CALL PC AS ERROR PC...
      LUPERR ; ; LOOP HERE ON ERROR IF SWR9 - 1.
      MOV $TMP2,R1 ; ...AND USE AS ARG POINTER.
      SETD
      LDD #0,ACO ; CLEAR ACO.
      LDD #0,AC1 ; AND AC1.
      MOV 20(R1),RO
      LDFPS RO ; SET INITIAL FPS (F MODE).
      MOV R1,RO
      LDF (RO),ACO ; LOAD THE MULTIPLICAND.
      MOV RO,$TMP5
      MOV R1,RO
      ADD #4,RO ; POINT TO MULTIPLIER.
```

4646	035230	010037	001174		MOV	R0,\$TMP6	
4647	035234	171410		2\$:	MODF	(R0),AC0	;TEST INSTRUCTION.
4648	035236	000240			NOP		
4649	035240	170204			STFPS	R4	;GET THE FPS.
4650	035242	010437	001166		MOV	R4,\$TMP3	
4651	035246	016137	000022	001170	MOV	22(R1),\$TMP4	; EXP FPS.
4652	035254	170011			SETD		
4653	035256	012700	035376		MOV	#20\$,R0	
(1)	035262	174010			STD	AC0,(R0)	:: STORE AC0
4654	035264	010037	001200		MOV	R0,\$TMP10	:...AND SET POINTER.
4655	035270	012700	035406		MOV	#21\$,R0	
(1)	035274	174110			STD	AC1,(R0)	:: STORE AC1
4656	035276	010037	001204		MOV	R0,\$TMP12	:...AND SET POINTER.
4657	035302	010100			MOV	R1,R0	
4658	035304	062700	000010		ADD	#10,R0	
4659	035310	010037	001176		MOV	R0,\$TMP7	; POINTS TO EXP FRACTION.
4660	035314	010037	035340		MOV	R0,3\$; IN THE CHECKER TOO.
4661	035320	062700	000004		ADD	#4,R0	
4662	035324	010037	001202		MOV	R0,\$TMP11	:...AND EXP INTEGER.
4663	035330	010037	035352		MOV	R0,4\$	
4664	035334	004537	004302		JSR	R5,CHECK2	; FRACTION CORRECT ??
4665	035340	000000	035376	3\$:	0,20\$		
4666	035344	001011			BNE	5\$; BR IF NOT.
4667	035346	004537	004302		JSR	R5,CHECK2	; YES, INTEGER CORRECT ??
4668	035352	000000	035406	4\$:	0,21\$		
4669	035356	001004			BNE	5\$; BR IF NOT.
4670	035360	023737	001166	001170	CMP	\$TMP3,\$TMP4	; FPS RIGHT ??
4671	035366	001401			BEQ	6\$; RETURN IF ALL OK.
4672							
4673	035370	104220		5\$:	ERROR	220	; FPS WRONG.
4674							
4675	035372	000161	000024	6\$:	JMP	24(R1)	; RETURN
4676							
4677	035376	000000	000000	000000	20\$:	.WORD	0,0,0,0 ; FRACTION BUFFER.
4678	035406	000000	000000	000000	21\$:	.WORD	0,0,0,0 ; INTEGER BUFFER.
4679							
4680	035416				TTDONE:		
(1)	035416	104412			CLRFPS		:: CLEAR FP STATUS...
(3)	035420	000400			BR	TST51	:...AND PROCEED.

4688
(3)
(4)
(4)
(4)
(3)
(2) 035422 000004
4689
4690
4691
4692 035424 004737 037026
4693 035430 000000 000000 000000
4694 035440 000000 000000 000000
4695 035450 000000 000000 000000
4696 035460 000000 000000 000000
4697 035470 000217 000204
4698
4699
4700
4701 035474 004737 037026
4702 035500 012345 067012 034567
4703 035510 000000 000000 000000
4704 035520 000000 000000 000000
4705 035530 000000 000000 000000
4706 035540 000217 000204
4707
4708
4709
4710 035544 004737 037026
4711 035550 000000 000000 000000
4712 035560 072727 127272 072727
4713 035570 000000 000000 000000
4714 035600 000000 000000 000000
4715 035610 000217 000204
4716
4717
4718
4719 035614 004737 037026
4720 035620 056252 125252 125252
4721 035630 040300 000000 000000
4722 035640 000000 000000 000000
4723 035650 056377 177777 177777
4724 035660 000217 000204
4725
4726
4727
4728 035664 004737 037026
4729 035670 140240 000000 000000
4730 035700 063714 146314 133572
4731 035710 000000 000000 000000
4732 035720 163777 177777 162531
4733 035730 000217 000204
4734
4735
4736

```
*****  
:TEST 51      MODD -- FSRC MODE 1  
:*****  
:THIS IS A TEST OF THE MODD INSTRUCTION.  
:A COMMON SUBROUTINE IS USED TO EXECUTE THE TEST AS BEFORE.  
:*****  
TST51: SCOPE  
:MODD WITH (FSRC=AC=0)  
:UU1:  JSR      PC,UUSUB  
:      .WORD    0,0,0,0      :AC  
:      .WORD    0,0,0,0      :FSRC  
:      .WORD    0,0,0,0      :FRACTIONAL RES.  
:      .WORD    0,0,0,0      :INTEGER RES.  
:      .WORD    217,204     :FPS BEFORE AND AFTER MODD.  
:MODD TEST WITH FSRC=0  
:UU2:  JSR      PC,UUSUB  
:      .WORD    012345,67012,34567,012345 :AC  
:      .WORD    0,0,0,0      :FSRC  
:      .WORD    0,0,0,0      :FRACTIONAL RES.  
:      .WORD    0,0,0,0      :INTEGER RES.  
:      .WORD    217,204     :FPS'S  
:MODD TEST WITH (AC=0)  
:UU3:  JSR      PC,UUSUB  
:      .WORD    0,0,0,0      :AC  
:      .WORD    72727,127272,72727,127272 :FSRC  
:      .WORD    0,0,0,0      :FRACTIONAL RES.  
:      .WORD    0,0,0,0      :INTEGER RES.  
:      .WORD    217,204     :FPS'S  
:MODD TEST WITH EXPONENT OF THE RESULT = 57  
:UU4:  JSR      PC,UUSUB  
:      .WORD    56252,125252,125252,125250 :AC  
:      .WORD    40300,0,0,0      :FSRC  
:      .WORD    0,0,0,0      :FRACTIONAL RES.  
:      .WORD    56377,-1,-1,-4 :INTEGER RES.  
:      .WORD    217,204     :FPS'S  
:MODD TEST WITH EXPONENT OF THE RESULT = 79  
:UU5:  JSR      PC,UUSUB  
:      .WORD    140240,0,0,0      :AC  
:      .WORD    63714,146314,133572,167737 :FSRC  
:      .WORD    0,0,0,0      :FRACTIONAL RES.  
:      .WORD    163777,-1,162531,125726 :INTEGER RES.  
:      .WORD    217,204     :FPS'S  
:MODD TEST WITH EXPONENT OF THE RESULT = 57  
:*****
```



```

4737 035734 004737 037026          UU6: JSR PC,UUSUB
4738 035740 056200 000000 000000 .WORD 56200,0,0,1      :AC
4739 035750 040340 000000 000000 .WORD 40340,0,0,0      :FSRC
4740 035760 000000 000000 000000 .WORD 0,0,0,0          :FRACTIONAL RES.
4741 035770 056340 000000 000000 .WORD 56340,0,0,1      :INTEGER RES.
4742 036000 000217 000204          .WORD 217,204          :FPS'S
4743
4744 :MODD TEST WITH EXPONENT OF THE RESULT = 56
4745
4746 036004 004737 037026          UU7: JSR PC,UUSUB
4747 036010 056000 000000 000000 .WORD 56000,0,0,1      :AC
4748 036020 040340 000000 000000 .WORD 40340,0,0,0      :FSRC
4749 036030 040100 000000 000000 .WORD 40100,0,0,0      :FRACTIONAL RES.
4750 036040 056140 000000 000000 .WORD 56140,0,0,1      :INTEGER RES.
4751 036050 000217 000200          .WORD 217,200          :FPS'S
4752
4753 :MODD TEST WITH EXPONENT OF THE RESULT = 36
4754
4755 036054 004737 037026          UU8: JSR PC,UUSUB
4756 036060 051177 177777 177777 .WORD 51177,-1,-1,-1   :AC
4757 036070 040200 000000 000000 .WORD 40200,0,0,0      :FSRC
4758 036100 040177 177760 000000 .WORD 40177,-20,0,0    :FRACTIONAL RES.
4759 036110 051177 177777 177760 .WORD 51177,-1,-20,0   :INTEGER RES.
4760 036120 000217 000200          .WORD 217,200          :FPS'S
4761
4762 :MODD TEST WITH EXPONENT OF THE RESULT = 30
4763
4764 036124 004737 037026          UU9: JSR PC,UUSUB
4765 036130 040200 000000 000000 .WORD 40200,0,0,0      :AC
4766 036140 047577 177777 176000 .WORD 47577,-1,176000,1 :FSRC
4767 036150 031600 000000 000000 .WORD 31600,0,0,0      :FRACTIONAL RES.
4768 036160 047577 177777 176000 .WORD 47577,-1,176000,0 :INTEGER RES.
4769 036170 000217 000200          .WORD 217,200          :FPS'S
4770
4771 :MODD TEST WITH EXPONENT OF THE RESULT = 31
4772
4773 036174 004737 037026          UU10: JSR PC,UUSUB
4774 036200 047777 177777 177000 .WORD 47777,-1,177000,0 :AC
4775 036210 040200 000000 000000 .WORD 40200,0,0,0      :FSRC
4776 036220 000000 000000 000000 .WORD 0,0,0,0          :FRACTIONAL RES.
4777 036230 047777 177777 177000 .WORD 47777,-1,177000,0 :INTEGER RES.
4778 036240 000217 000204          .WORD 217,204          :FPS'S
4779
4780 :MODD TEST WITH EXPONENT OF THE RESULT = 0
4781
4782 036244 004737 037026          UU11: JSR PC,UUSUB
4783 036250 040200 000000 000000 .WORD 40200,0,0,0      :AC
4784 036260 040177 072727 127272 .WORD 40177,72727,127272,72727 :FSRC
4785 036270 040177 072727 127272 .WORD 40177,72727,127272,72727 :FRACTIONAL RES.
4786 036300 000000 000000 000000 .WORD 0,0,0,0          :INTEGER RES.
4787 036310 000217 000200          .WORD 217,200          :FPS'S
4788
4789 :MODD TEST WITH EXPONENT OF THE RESULT = -115
4790
4791 036314 004737 037026          UU12: JSR PC,UUSUB
4792 036320 003377 177777 177777 .WORD 3377,-1,-1,52525 .AC
```

4793	036330	040200	000000	000000	.WORD	40200,0,0,0	:FSRC
4794	036340	003377	177777	177777	.WORD	3377,-1,-1,52525	:FRACTIONAL RES.
4795	036350	000000	000000	000000	.WORD	0,0,0,0	:INTEGER RES.
4796	036360	000217	000200		.WORD	217,200	:FPS'S
4797							
4798							
4799							
4800	036364	004737	037026		UU13:	JSR PC,UUSUB	
4801	036370	040300	000000	000000	.WORD	40300,0,0,0	:AC
4802	036400	020200	000000	000000	.WORD	20200,0,0,1	:FSRC
4803	036410	020300	000000	000000	.WORD	20300,0,0,2	:FRACTIONAL RES.
4804	036420	000000	000000	000000	.WORD	0,0,0,0	:INTEGER RES.
4805	036430	000217	000200		.WORD	217,200	:FPS'S
4806							
4807							
4808							
4809	036434	004737	037016		UU14:	JSR PC,UUSUB1	
4810	036440	060252	125252	125252	.WORD	60252,125252,125252,125252	:AC
4811	036450	060300	000000	000000	.WORD	60300,0,0,0	:FSRC
4812	036460	000000	000000	000000	.WORD	0,0,0,0	:FRAC...
4813	036470	000377	177777	177777	.WORD	377,-1,-1,-2	:...AND INT RESULT (FIV - 1).
4814	036500	041217	141206		.WORD	41217,141206	:FPS'S
4815							
4816							
4817							
4818	036504	004737	037016		UU15:	JSR PC,UUSUB1	
4819	036510	060252	125252	125252	.WORD	60252,125252,125252,125252	:AC
4820	036520	060100	000000	000000	.WORD	60100,0,0,0	:FSRC
4821	036530	000000	000000	000000	.WORD	0,0,0,0	:FRAC...
4822	036540	000177	177777	177777	.WORD	177,-1,-1,-1	:...AND INT RESULT (FIV = 1).
4823	036550	041217	141206		.WORD	41217,141206	:FPS'S
4824							
4825	036554	004737	037016		JSR	PC,UUSUB1	:SAME OPERANDS, FIV = 0.
4826	036560	060252	125252	125252	.WORD	60252,125252,125252,125252	
4827	036570	060100	000000	000000	.WORD	60100,0,0,0	
4828	036600	000000	000000	000000	.WORD	0,0,0,0	:FRAC...
4829	036610	000000	000000	000000	.WORD	0,0,0,0	:...AND INT RESULT (FIV = 0).
4830	036620	000217	000206		.WORD	217,206	
4831							
4832							
4833							
4834	036624	004737	037016		UU16:	JSR PC,UUSUB1	
4835	036630	020252	125252	125252	.WORD	20252,125252,125252,125252	:AC
4836	036640	017700	000000	000000	.WORD	17700,0,0,0	:FSRC
4837	036650	077777	177777	177777	.WORD	077777,-1,-1,-1	:FRAC...
4838	036660	000000	000000	000000	.WORD	0,0,0,0	:...AND INT RESULT (FIU = 1).
4839	036670	042217	142200		.WORD	42217,142200	:FPS'S
4840							
4841							
4842							
4843	036674	004737	037016		UU17:	JSR PC,UUSUB1	
4844	036700	020252	125252	125252	.WORD	20252,125252,125252,125252	:AC
4845	036710	020100	000000	000000	.WORD	20100,0,0,0	:FSRC
4846	036720	000177	177777	177777	.WORD	000177,-1,-1,-1	:FRAC...
4847	036730	000000	000000	000000	.WORD	0,0,0,0	:...AND INT RESULT (FIU = 1).
4848	036740	042217	142204		.WORD	42217,142204	:FPS'S

```

4849
4850 036744 004737 037016 JSR PC,UUSUB1 ; SAME OPERANDS, FIU = 0.
4851 036750 020252 125252 125252 .WORD 20252,125252,125252,125252
4852 036760 020100 000000 000000 .WORD 20100,0,0,0
4853 036770 000000 000000 000000 .WORD 0,0,0,0 ; FRAC...
4854 037000 000000 000000 000000 .WORD 0,0,0,0 ; ...AND INT RESULT (FIU = 0).
4855 037010 000217 000204 .WORD 217,204
4856
4857 037014 000525 BR UUDONE ; FINISHED.
4858
4859 ; SUBROUTINE TO SET-UP, EXECUTE, AND CHECK THE RESULTS OF MODD.
4860
4861 ; CALL:
4862 JSR PC,UUSUB ; R UUSUB1
4863 .WORD X,X,X,X ; A OPERAND (MULTIPLICAND).
4864 .WORD X,X,X,X ; FSRC OPERAND (MULTIPLIER).
4865 .WORD X,X,X,X ; RESULTING FRACTION (ACO).
4866 .WORD X,X,X,X ; RESULTING INTEGER (AC1).
4867 .WORD X,X ; FPS BEFORE AND EXP FPS AFTER.
4868 ; RETURN TO CALLER+44
4869
4870 ; THE OPERANDS ARE SELECTED USING THE CALLERS PC.
4871 ; AFTER EXECUTION THE RESULTING INTEGER, FRACTION, AND FPS
4872 ; ARE TESTED. IF ALL OK, RETURN.
4873 ; OTHERWISE, REPORT ERROR AND RETURN.
4874
4875 037016 112737 000040 056304 UUSUB1: MOVB #40,EM221X ; ENABLE MESSAGE EXTENSION.
4876 037024 000402 SKP2
4877 037026 105037 056304 UUSUB: CLR B EM221X ; DISABLE MESSAGE EXTENSION.
4878 037032 012637 001164 MOV (SP)+,$TMP2 ; SAVE CALL PC AS ERROR PC...
4879 037036 104411 LUPERR ;: LOOP HERE ON ERROR IF SWR9 1.
4880 037040 013701 001164 MOV $TMP2,R1 ; ...AND USE AS ARG POINTER.
4881 037044 170011 SETD
4882 037046 172427 000000 LDD #0,ACO ; CLEAR ACO.
4883 037052 172527 000000 LDD #0,AC1 ; AND AC1.
4884 037056 016100 000040 MOV 40(R1),R0
4885 037062 170100 LDFPS R0 ; SET INITIAL FPS.
4886 037064 010100 MOV R1,R0
4887 037066 172410 LDD (R0),ACO ; LOAD THE MULTIPLICAND.
4888 037070 010037 001172 MOV R0,$TMP5
4889 037074 010100 MOV R1,R0
4890 037076 062700 000010 ADD #10,R0 ; POINT TO MULTIPLIER.
4891 037102 010037 001174 MOV R0,$TMP6
4892 037106 171410 25: MODD (R0),ACO ; TEST INSTRUCTION.
4893 037110 000240 NOP
4894 037112 170204 STFPS R4 ; GET THE FPS.
4895 037114 010437 001166 MOV R4,$TMP3
4896 037120 016137 000042 001170 MOV 42(R1),$TMP4 ; EXP FPS.
4897 037126 170011 SETD
4898 037130 012700 037250 MOV #20$,R0
(1) 037134 174010 STD ACO,(R0) ;: STORE ACO
4899 037136 010037 001200 MOV R0,$TMP10 ; ...AND SET POINTER.
4900 037142 012700 037260 MOV #21$,R0
(1) 037146 174110 STD AC1,(R0) ;: STORE AC1
4901 037150 010037 001204 MOV R0,$TMP12 ; ...AND SET POINTER.
4902 037154 010100 MOV R1,R0

```

```

4903 037156 062700 000020      ADD      #20,R0
4904 037162 010037 001176      MOV      R0,$TMP7      ; POINTS TO EXP FRACTION.
4905 037166 010037 037212      MOV      R0,3$        ; IN THE CHECKER TOO.
4906 037172 062700 000010      ADD      #10,R0
4907 037176 010037 001202      MOV      R0,$TMP11     ;...AND EXP INTEGER.
4908 037202 010037 037224      MOV      R0,4$
4909 037206 004537 004312      JSR      R5,CHECK4     ; FRACTION CORRECT ??
4910 037212 000000 037250      3$:      0,20$
4911 037216 001011                BNE      5$            ; BR IF NOT.
4912 037220 004537 004312      JSR      R5,CHECK4     ; YES, INTEGER CORRECT ??
4913 037224 000000 037260      4$:      0,21$
4914 037230 001004                BNE      5$            ; BR IF NOT.
4915 037232 023737 001166 001170  CMP      $TMP3,$TMP4   ; FPS RIGHT ??
4916 037240 001401                BEQ      6$            ; RETURN IF ALL OK.
4917
4918 037242 104221                5$:      ERROR 221     ; FPS WRONG.
4919
4920 037244 000161 000044      6$:      JMP      44(R1)   ; RETURN
4921
4922 037250 000000 000000 000000 20$:     .WORD 0,0,0,0        ; FRACTION BUFFER.
4923 037260 000000 000000 000000 21$:     .WORD 0,0,0,0        ; INTEGER BUFFER.
4924
4925 037270      UUDONE:
(1) 037270 104412      CLRFP3      ;; CLEAR FP STATUS...
(2) 037272 000400      BR          $EOP      ;;...AND SIGNAL END-PASS
4926
4927          000051      LASTST- $TN-1      ; REMEMBER LAST TEST NUMBER.
  
```

```

4929          .SBTTL
4930          .SBTTL  END OF PASS ROUTINE
(1)
(2)          ::*****
(1)          ;*INCREMENT THE PASS NUMBER ($PASS)
(1)          ;*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
(1)          ;*TYPE 'END PASS #XXXXX TOTAL NUMBER OF ERRORS SINCE LAST REPORT YYYYYY'
(1)          ;*WHERE XXXXX AND YYYYYY ARE DECIMAL NUMBERS
(1)          ;*IF THERES A MONITOR GO TO IT
(1)          ;*IF THERE ISN'T JUMP TO LOOP
(1)
(1) 037274    $EOP:
(1) 037274    000004    SCOPE
(1) 037276    005037    001102    CLR          $STNM          ;;ZERO THE TEST NUMBER
(1) 037302    005037    001220    CLR          $TIMES        ;;ZERO THE NUMBER OF ITERATIONS
(1) 037306    005237    001242    INC          $PASS         ;;INCREMENT THE PASS NUMBER
(1) 037312    042737    100000    001242    BIC          #100000,$PASS ;;DON'T ALLOW A NEG. NUMBER
(1) 037320    005327    DEC          (PC)+        ;;LOOP?
(1) 037322    000001    $EOPCT: .WORD 1
(1) 037324    003063    BGT          $DOAGN        ;;YES
(1) 037326    012737    MOV          (PC)+,@(PC)+ ;;RESTORE COUNTER
(1) 037330    000001    $ENDLT: .WORD 1
(1) 037332    037322    $EOPCT
(2) 037334    104401    037342    TYPE        ,65$          ;;TYPE ASCIZ STRING
(2) 037340    000407    BR          64$           ;;GET OVER THE ASCIZ
(2)          ;;65$: .ASCIZ <12><15>/END PASS #/
(2) 037360    013746    001242    MOV          $PASS,-(SP)   ;;SAVE $PASS FOR TYPEOUT
(2)          ;;TYPE PASS NUMBER
(2) 037364    104405    TYPDS       ;;GO TYPE--DECIMAL ASCII WITH SIGN
(2) 037366    104401    037374    TYPE        ,67$          ;;TYPE ASCIZ STRING
(2) 037372    000421    BR          66$           ;;GET OVER THE ASCIZ
(2)          ;;67$: .ASCIZ / TOTAL ERRORS SINCE LAST REPORT /
(2) 037436    013746    001112    MOV          $ERTTL,-(SP)  ;;SAVE $ERTTL FOR TYPEOUT
(2)          ;;TOTAL NUMBER OF ERRORS
(2) 037442    104405    TYPDS       ;;GO TYPE--DECIMAL ASCII WITH SIGN
(1) 037444    104401    001231    TYPE        ,$CRLF        ;;TYPE CARRIAGE RETURN, LINE FEED
(1) 037450    005037    001112    CLR          $ERTTL       ;;CLEAR ERROR TOTAL
(1) 037454    013700    000042    $GET42: MOV    @#42,R0     ;;GET MONITOR ADDRESS
(1) 037460    001405    BEQ          $DOAGN        ;;BRANCH IF NO MONITOR
(1) 037462    000005    RESET       ;;CLEAR THE WORLD
(1) 037464    004710    $ENDAD: JSR   PC,(R0)     ;;GO TO MONITOR
(1) 037466    000240    NOP         ;;SAVE ROOM
(1) 037470    000240    NOP         ;;FOR
(1) 037472    000240    NOP         ;;ACT11
(1) 037474    $DOAGN:
(1) 037474    000137    JMP          @(PC)+        ;;RETURN
(1) 037476    004146    $RTNAD: .WORD LOOP
(1) 037500    377      377      000 $ENJLL: .BYTE -1,-1,0   ;;NULL CHARACTER STRING
(1)          037504    .EVEN
    
```

```

4932          .SBTTL SCOPE HANDLER ROUTINE
(1)          ;;*****
(1)          ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
(1)          ;*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
(1)          ;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
(1)          ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
(1)          ;*SW14=1      LOOP ON TEST
(1)          ;*SW11=1      INHIBIT ITERATIONS
(1)          ;*SW09=1      LOOP ON ERROR
(1)          ;*SW08=1      LOOP ON TEST IN SWR<6:0>
(1)          ;*CALL
(1)          ;*          SCOPE          ;;SCOPE=IOT
(1)          $SCOPE:
(1)          037504          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
(1)          037504 104407          1$:      BIT          #BIT14,@SWR          ;;LOOP ON PRESENT TEST?
(1)          037506 032777 040000 141424      BNE          $OVER          ;;YES IF SW14=1
(1)          037514 001133          ;#####START OF CODE FOR THE XOR TESTER#####
(1)          037516 000416          $XTSTR: BR          6$          ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
(1)          ;          MOV          @WERRVEC,-(SP)          ;;SAVE THE CONTENTS OF THE ERROR VECTOR
(1)          037520 013746 000004          MOV          #$$,@WERRVEC          ;;SET FOR TIMEOUT
(1)          037524 012737 037544 000004          TST          @#177060          ;;TIME OUT ON XOR?
(1)          037532 005737 177060          MOV          (SP)+,@WERRVEC          ;;RESTORE THE ERROR VECTOR
(1)          037536 012637 000004          BR          $SVLAD          ;;GO TO THE NEXT TEST
(1)          037542 000502          5$:      CMP          (SP)+,(SP)+          ;;CLEAR THE STACK AFTER A TIME OUT
(1)          037544 022626          MOV          (SP)+,@WERRVEC          ;;RESTORE THE ERROR VECTOR
(1)          037546 012637 000004          BR          7$          ;;LOOP ON THE PRESENT TEST
(1)          037552 000442          6$:;#####END OF CODE FOR THE XOR TESTER#####
(1)          037554          BIT          #BIT08,@SWR          ;;LOOP ON SPEC. TEST?
(1)          037554 032777 000400 141356          BEQ          2$          ;;BR IF NO
(1)          037562 001423          CLR          -(SP)          ;;CLEAR A TEMP. LOCATION
(1)          037564 005046          MOVB         @SWR,(SP)          ;;PICKUP THE DESIRED TEST NUMBER
(1)          037566 117716 141346          BIC          #$$SWRPMK,(SP)          ;;MASK OUT UNDESIRED BITS
(1)          037572 042716 000200          BEQ          8$          ;;BRANCH IF BAD TEST NUMBER IN SWR
(1)          037576 001414          CMP          #51,(SP)          ;;CHECK THE NUMBER IN THE SWR
(2)          037600 022716 000051          BLT          8$          ;;BRANCH IF TEST NUMBER IS OUT OF RANGE
(1)          037604 002411          MOV          (SP),$TSTNM          ;;UPDATE THE TEST NUMBER
(1)          037606 011637 001102          DEC          (SP)          ;;BACKUP BY ONE
(1)          037612 005316          ASL          (SP)          ;;SCALE THE TEST NUMBER AS AN INDEX
(1)          037614 006316          ADD          #$$SW08TBL,(SP)          ;;FORM THE ADDRESS OF TEST POINTER
(1)          037616 062716 040022          MOV          @(SP)+,$LPADR          ;;SET LOOP ADDRESS TO DESIRED TEST
(1)          037622 013637 001106          BR          $OVER          ;;GO LOOP ON THE TEST
(1)          037626 000466          8$:      TST          (SP)+          ;;CLEAN THE BAD TEST NUMBER OFF OF THE STACK
(1)          037630 005726          2$:      TSTB         $ERFLG          ;;HAS AN ERROR OCCURRED?
(1)          037632 105737 001103          BEQ          3$          ;;BR IF NO
(1)          037636 001421          CMPB         $ERMAX,$ERFLG          ;;MAX. ERRORS FOR THIS TEST OCCURRED?
(1)          037640 123737 001115 001103          BHI          3$          ;;BR IF NO
(1)          037646 101015          BIT          #BIT09,@SWR          ;;LOOP ON ERROR?
(1)          037650 032777 001000 141262          BEQ          4$          ;;BR IF NO
(1)          037656 001404          MOV          $LPERR,$LPADR          ;;SET LOOP ADDRESS TO LAST SCOPE
(1)          037660 013737 001110 001106          BR          $OVER
(1)          037666 000446          4$:      CLRB         $ERFLG          ;;ZERO THE ERROR FLAG
(1)          037670 105037 001103          CLR          $TIMES          ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
(1)          037674 005037 001220          BR          1$          ;;ESCAPE TO THE NEXT TEST
(1)          037700 000415
    
```

```

037702 032777 004000 141230 3$. BIT #BIT11,@SWR ;;INHIBIT ITERATIONS?
037710 001011 BNE 1$ ;;BR IF YES
037712 005737 001242 TST $PASS ;;IF FIRST PASS OF PROGRAM
037716 001406 BEQ 1$ ;; INHIBIT ITERATIONS
037720 005237 001104 INC $ICNT ;;INCREMENT ITERATION COUNT
037724 023737 001220 001104 CMP $TIMES,$ICNT ;;CHECK THE NUMBER OF ITERATIONS MADE
037732 002024 BGE $OVER ;;BR IF MORE ITERATION REQUIRED
037734 012737 000001 001104 1$: MOV #1,$ICNT ;;REINITIALIZE THE ITERATION COUNTER
037742 013737 040020 001220 MOV $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
037750 105237 001102 $SVLAD: $STNM ;;COUNT TEST NUMBERS
037754 113737 001102 001240 INCB $STNM,$STESTN ;;SET TEST NUMBER IN APT MAILBOX
037762 011637 001106 MOV (SP),$LPADR ;;SAVE SCOPE LOOP ADDRESS
037766 011637 001110 MOV (SP),$LPERR ;;SAVE ERROR LOOP ADDRESS
037772 005037 001222 CLR $ESCAPE ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
037776 112737 000001 001115 MOVB #1,$ERMAX ;;ONLY ALLOW ONE(1) ERROR ON NEXT TFST
040004 013777 001102 141130 $OVER: MOV $STNM,@DISPLAY ;;DISPLAY TEST NUMBER
040012 013716 001106 MOV $LPADR,(^P) ;;FUDGE RETURN ADDRESS
040016 000452 BR SCOPEX
040020 000001 $MXCNT: 1 ;;MAX. NUMBER OF ITERATIONS
040022 $SWOBTBL:
(3) 040022 004360 .WORD TST1+2 ;;STARTING ADDRESS OF TEST 1
(3) 040024 004542 .WORD TST2+2 ;;STARTING ADDRESS OF TEST 2
(3) 040026 004664 .WORD TST3+2 ;;STARTING ADDRESS OF TEST 3
(3) 040030 005136 .WORD TST4+2 ;;STARTING ADDRESS OF TEST 4
(3) 040032 005324 .WORD TST5+2 ;;STARTING ADDRESS OF TEST 5
(3) 040034 005464 .WORD TST6+2 ;;STARTING ADDRESS OF TEST 6
(3) 040036 006476 .WORD TST7+2 ;;STARTING ADDRESS OF TEST 7
(3) 040040 007300 .WORD TST10+2 ;;STARTING ADDRESS OF TEST 10
(3) 040042 010052 .WORD TST11+2 ;;STARTING ADDRESS OF TEST 11
(3) 040044 010574 .WORD TST12+2 ;;STARTING ADDRESS OF TEST 12
(3) 040046 011420 .WORD TST13+2 ;;STARTING ADDRESS OF TEST 13
(3) 040050 011764 .WORD TST14+2 ;;STARTING ADDRESS OF TEST 14
(3) 040052 012222 .WORD TST15+2 ;;STARTING ADDRESS OF TEST 15
(3) 040054 012456 .WORD TST16+2 ;;STARTING ADDRESS OF TEST 16
(3) 040056 012716 .WORD TST17+2 ;;STARTING ADDRESS OF TEST 17
(3) 040060 013160 .WORD TST20+2 ;;STARTING ADDRESS OF TEST 20
(3) 040062 013606 .WORD TST21+2 ;;STARTING ADDRESS OF TEST 21
(3) 040064 014234 .WORD TST22+2 ;;STARTING ADDRESS OF TEST 22
(3) 040066 014622 .WORD TST23+2 ;;STARTING ADDRESS OF TEST 23
(3) 040070 015224 .WORD TST24+2 ;;STARTING ADDRESS OF TEST 24
(3) 040072 015626 .WORD TST25+2 ;;STARTING ADDRESS OF TEST 25
(3) 040074 016214 .WORD TST26+2 ;;STARTING ADDRESS OF TEST 26
(3) 040076 016624 .WORD TST27+2 ;;STARTING ADDRESS OF TEST 27
(3) 040100 017070 .WORD TST30+2 ;;STARTING ADDRESS OF TEST 30
(3) 040102 017326 .WORD TST31+2 ;;STARTING ADDRESS OF TEST 31
(3) 040104 020064 .WORD TST32+2 ;;STARTING ADDRESS OF TEST 32
(3) 040106 021102 .WORD TST33+2 ;;STARTING ADDRESS OF TEST 33
(3) 040110 022330 .WORD TST34+2 ;;STARTING ADDRESS OF TEST 34
(3) 040112 023342 .WORD TST35+2 ;;STARTING ADDRESS OF TEST 35
(3) 040114 024040 .WORD TST36+2 ;;STARTING ADDRESS OF TEST 36
(3) 040116 024576 .WORD TST37+2 ;;STARTING ADDRESS OF TEST 37
(3) 040120 025624 .WORD TST40+2 ;;STARTING ADDRESS OF TEST 40
(3) 040122 026646 .WORD TST41+2 ;;STARTING ADDRESS OF TEST 41
(3) 040124 027634 .WORD TST42+2 ;;STARTING ADDRESS OF TEST 42
(3) 040126 030514 .WORD TST43+2 ;;STARTING ADDRESS OF TEST 43
(3) 040130 031172 .WORD TST44+2 ;;STARTING ADDRESS OF TEST 44

```



```

(1) 040422 000770 BR 7$ ;;LOOP
(1)
(1) ;HORIZONTAL TAB PROCESSOR
(1)
(1) 040424 112716 000040 8$: MOVB #' (SP) ;;REPLACE TAB WITH SPACE
(1) 040430 004737 040450 9$: JSR PC,$TYPEC ;;TYPE A SPACE
(1) 040434 132737 000007 040566 BITB #7,$CHARCNT ;;BRANCH IF NOT AT
(1) 040442 001372 BNE 9$ ;;TAB STOP
(1) 040444 005726 TST (SP)+ ;;POP SPACE OFF STACK
(1) 040446 000724 BR 2$ ;;GET NEXT CHARACTER
(1) 040450 $TYPEC:
(1) 040450 105777 140470 TSTB @STKS ;;CHAR IN KYBD BUFFER? ;:MJD001
(1) 040454 100022 BPL 10$ ;;BR IF NOT ;:MJD001
(1) 040456 017746 140464 MOV @STKB,-(SP) ;;GET CHAR ;:MJD001
(1) 040462 042716 177600 BIC #177600,(SP) ;;STRIP EXTRANEIOUS BITS ;:MJD001
(1) 040466 122716 000023 CMPB #$XOFF,(SP) ;;WAS CHAR XOFF ;:MJD001
(1) 040472 001012 BNE 102$ ;;BR IF NOT ;:MJD001
(1) 040474 105777 140444 101$: TSTB @STKS ;;WAIT FOR CHAR ;:MJD001
(1) 040500 100375 BPL 101$ ;:MJD001
(1) 040502 117716 140440 MOVB @STKB,(SP) ;;GET CHAR ;:MJD001
(1) 040506 042716 177600 BIC #177600,(SP) ;;STRIP IT ;:MJD001
(1) 040512 122716 000021 CMPB #$XON,(SP) ;;WAS IT XON? ;:MJD001
(1) 040516 001366 BNE 101$ ;;BR IF NOT ;:MJD001
(1) 040520 105777 140422 102$: TST (SP)+ ;;FIX STACK ;:MJD001
(1) 040522 005726 10$: TSTB @STPS ;;WAIT UNTIL PRINTER IS READY ;:MJD001
(1) 040522 105777 140422 BPL 10$ ;:MJD001
(1) 040526 100375 MOVB 2(SP),@STPB ;;LOAD CHAR TO BE TYPED INTO DATA REG. ;:MJD001
(1) 040530 116677 000002 140414 CMPB #CR,2(SP) ;;IS CHARACTER A CARRIAGE RETURN?
(1) 040536 122766 000015 000002 BNE 1$ ;;BRANCH IF NO
(1) 040544 001003 CLRB $CHARCNT ;;YES--CLEAR CHARACTER COUNT
(1) 040546 105037 040566 BR $TYPEX ;;EXIT
(1) 040552 000406 1$: CMPB #LF,2(SP) ;;IS CHARACTER A LINE FEED?
(1) 040554 122766 000012 000002 BEQ $TYPEX ;;BRANCH IF YES
(1) 040562 001402 INCB (PC)+ ;;COUNT THE CHARACTER
(1) 040564 105227 $CHARCNT: WORD 0 ;;CHARACTER COUNT STORAGE
(1) 040566 000000 $TYPEX: RTS PC
(1) 040570 000207
(1)
4963 ;////////////////////////
4964 ; NOW BACK UP AND PATCH $TYPEC TO ENABLE <^G> RECOGNITION
4965 ; DURING OUTPUT SEQUENCES.
4966 ;
4967 SVPC= ; SAVE THE PC...
4968 -- $TYPEC+50 ; ...AND POINT TO 102$.
4969 040520 000424 102$: BR $STCX ; BR TO PATCH...
4970 040522 10$: -- SVPC ; ...AND RETURN.
4971 040572 ; RESTORE PC.
4972
4973 $STCX: CMPB (SP)+,#7 ; <^G> ???
4974 040576 001020 BNE 1$ ; SKIP IF NOT.
4975 .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
(1) 040600 005737 000042 TST @#42 ;;ARE WE RUNNING UNDER XXDP/ACT?
(1) 040604 001012 BNE 64$ ;;BRANCH IF YES
(1) 040606 123727 001254 000001 CMPB $ENV,#1 ;;ARE WE RUNNING UNDER APT?
    
```



```

4979      .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
(1)
(2)      :*****
(1)      *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
(1)      *OCTAL (ASCII) NUMBER AND TYPE IT.
(1)      *$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
(1)      *CALL:
(1)      *      MOV      NUM,-(SP)          ;;NUMBER TO BE TYPED
(1)      *      TYPOS      ;;CALL FOR TYPEOUT
(1)      *      .BYTE   N                ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
(1)      *      .BYTE   M                ;;M=1 OR 0
(1)      *                                          ;;1=TYPE LEADING ZEROS
(1)      *                                          ;;0=SUPPRESS LEADING ZEROS
(1)      *
(1)      *$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
(1)      *$TYPOS OR $TYPOC
(1)      *CALL:
(1)      *      MOV      NUM,-(SP)          ;;NUMBER TO BE TYPED
(1)      *      TYPON      ;;CALL FOR TYPEOUT
(1)      *
(1)      *$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
(1)      *CALL:
(1)      *      MOV      NUM,-(SP)          ;;NUMBER TO BE TYPED
(1)      *      TYPOC      ;;CALL FOR TYPEOUT
(1)
(1)  040642 017646 000000          $TYPOS: MOV      @ (SP),-(SP)      ;;PICKUP THE MODE
(1)  040646 116637 000001  041065  MOV     1(SP),%OFILL      ;;LOAD ZERO FILL SWITCH
(1)  040654 112637 041067          MOV     (SP)+,%SOMODE+1  ;;NUMBER OF DIGITS TO TYPE
(1)  040660 062716 000002          ADD     #2,(SP)         ;;ADJUST RETURN ADDRESS
(1)  040664 000406                    BR      $TYPON
(1)  040666 112737 000001  041065  $TYPOC: MOV     #1,%OFILL      ;;SET THE ZERO FILL SWITCH
(1)  040674 112737 000006  041067  MOV     #6,%SOMODE+1    ;;SET FOR SIX(6) DIGITS
(1)  040702 112737 000005  041064  $TYPON: MOV     #5,%OCNT     ;;SET THE ITERATION COUNT
(1)  040710 010346                    MOV     R3,-(SP)       ;;SAVE R3
(1)  040712 010446                    MOV     R4,-(SP)       ;;SAVE R4
(1)  040714 010546                    MOV     R5,-(SP)       ;;SAVE R5
(1)  040716 113704 041067          MOV     %SOMODE+1,R4   ;;GET THE NUMBER OF DIGITS TO TYPE
(1)  040722 005404                    NEG     R4
(1)  040724 062704 000006                    ADD     #6,R4          ;;SUBTRACT IT FOR MAX. ALLOWED
(1)  040730 110437 041066                    MOV     R4,%SOMODE     ;;SAVE IT FOR USE
(1)  040734 113704 041065                    MOV     %OFILL,R4      ;;GET THE ZERO FILL SWITCH
(1)  040740 016605 000012          MOV     12(SP),R5     ;;PICKUP THE INPUT NUMBER
(1)  040744 005003                    CLR     R3             ;;CLEAR THE OUTPUT WORD
(1)  040746 006105          1$:  ROL     R5          ;;ROTATE MSB INTO "C"
(1)  040750 000404          BR      3$           ;;GO DO MSB
(1)  040752 006105          2$:  ROL     R5          ;;FORM THIS DIGIT
(1)  040754 006105          ROL     R5
(1)  040756 006105          ROL     R5
(1)  040760 010503          MOV     R5,R3
(1)  040762 006103          3$:  ROL     R3          ;;GET LSB OF THIS DIGIT
(1)  040764 105337 041066          DECB   %SOMODE        ;;TYPE THIS DIGIT?
(1)  040770 100016                    BPL    7$             ;;BR IF NO
(1)  040772 042703 177770          BIC    #177770,R3    ;;GET RID OF JUNK
(1)  040776 001002          BNE    4$             ;;TEST FOR 0
(1)  041000 005704          TST   R4             ;;SUPPRESS THIS 0?
(1)  041002 001403          BEQ   5$             ;;BR IF YES

```

(1)	041004	005204		4\$:	INC	R4	::DON'T SUPPRESS ANYMORE 0'S
(1)	041006	052703	000060		BIS	#'0,R3	::MAKE THIS DIGIT ASCII
(1)	041012	052703	000040	5\$:	BIS	#' ,R3	::MAKE ASCII IF NOT ALREADY
(1)	041016	110337	041062		MOVB	R3,8\$::SAVE FOR TYPING
(1)	041022	104401	041062		TYPE	,8\$::GO TYPE THIS DIGIT
(1)	041026	105337	041064	7\$:	DECB	\$OCNT	::COUNT BY 1
(1)	041032	003347			BGT	2\$::BR IF MORE TO DO
(1)	041034	002402			BLT	6\$::BR IF DONE
(1)	041036	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
(1)	041040	000744			BR	2\$::GO DO THE LAST DIGIT
(1)	041042	012605		6\$:	MOV	(SP)+,R5	::RESTORE R5
(1)	041044	012604			MOV	(SP)+,R4	::RESTORE R4
(1)	041046	012603			MOV	(SP)+,R3	::RESTORE R3
(1)	041050	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
(1)	041056	012616			MOV	(SP)+,(SP)	
(1)	041060	000002			RTI		::RETURN
(1)	041062	000		8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
(1)	041063	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
(1)	041064	000		\$OCNT:	.BYTE	0	::OCTAL DIGIT COUNTER
(1)	041065	000		\$OFILL:	.BYTE	0	::ZERO FILL SWITCH
(1)	041066	000000		\$OMODE:	.WORD	0	::NUMBER OF DIGITS TO TYPE

4981

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```
(1) (1) *****  
(1) (1) *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT  
(1) (1) *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE  
(1) (1) *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED  
(1) (1) *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE  
(1) (1) *REPLACED WITH SPACES.  
(1) (1) *CALL:  
(1) (1) *      MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK  
(1) (1) *      TYPDS      ;;GO TO THE ROUTINE  
(1) (1) $TYPDS:  
(3) (1) 041070 010046      MOV      R0,-(SP)      ;;PUSH R0 ON STACK  
(3) (1) 041072 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK  
(3) (1) 041074 010246      MOV      R2,-(SP)      ;;PUSH R2 ON STACK  
(3) (1) 041076 010346      MOV      R3,-(SP)      ;;PUSH R3 ON STACK  
(3) (1) 041100 010546      MOV      R5,-(SP)      ;;PUSH R5 ON STACK  
(1) (1) 041102 012746 020200  MOV      #20200,-(SP)  ;;SET BLANK SWITCH AND SIGN  
(1) (1) 041106 016605 000020  MOV      20(SP),R5    ;;GET THE INPUT NUMBER  
(1) (1) 041112 100004      BPL      1$          ;;BR IF INPUT IS POS.  
(1) (1) 041114 005405      NEG      R5          ;;MAKE THE BINARY NUMBER POS.  
(1) (1) 041116 112766 000055 000001  MOVVB   #'-,1(SP)    ;;MAKE THE ASCII NUMBER NEG.  
(1) (1) 041124 005000      CLR      R0          ;;ZERO THE CONSTANTS INDEX  
(1) (1) 041126 012703 041304  MOV      #$DBLK,R3    ;;SETUP THE OUTPUT POINTER  
(1) (1) 041132 112723 000040  MOVVB   #' ,(R3)+    ;;SET THE FIRST CHARACTER TO A BLANK  
(1) (1) 041136 005002      CLR      R2          ;;CLEAR THE BCD NUMBER  
(1) (1) 041140 016001 041274  MOV      $DTBL(R0),R1 ;;GET THE CONSTANT  
(1) (1) 041144 160105      SUB      R1,R5       ;;FORM THIS BCD DIGIT  
(1) (1) 041146 002402      BLT     4$          ;;BR IF DONE  
(1) (1) 041150 005202      INC     R2          ;;INCREASE THE BCD DIGIT BY 1  
(1) (1) 041152 000774      BR      3$          ;;  
(1) (1) 041154 060105      4$:  ADD     R1,R5       ;;ADD BACK THE CONSTANT  
(1) (1) 041156 005702      TST     R2          ;;CHECK IF BCD DIGIT=0  
(1) (1) 041160 001002      BNE     5$          ;;FALL THROUGH IF 0  
(1) (1) 041162 105716      TSTB   (SP)         ;;STILL DOING LEADING 0'S?  
(1) (1) 041164 100407      BMI     7$          ;;BR IF YES  
(1) (1) 041166 106316      5$:  ASLB   (SP)         ;;MSD?  
(1) (1) 041170 103003      BCC     6$          ;;BR IF NO  
(1) (1) 041172 116663 000001 177777  MOVVB   1(SP),-1(R3)  ;;YES--SET THE SIGN  
(1) (1) 041200 052702 000060      BIS     #'0,R2      ;;MAKE THE BCD DIGIT ASCII  
(1) (1) 041204 052702 000040      7$:  BIS     #' ,R2      ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT  
(1) (1) 041210 110223      MOVVB   R2,(R3)+    ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER  
(1) (1) 041212 005720      TST     (R0)+       ;;JUST INCREMENTING  
(1) (1) 041214 020027 000010      CMP     R0,#10     ;;CHECK THE TABLE INDEX  
(1) (1) 041220 002746      BLT     2$          ;;GO DO THE NEXT DIGIT  
(1) (1) 041222 003002      BGT     8$          ;;GO TO EXIT  
(1) (1) 041224 010502      MOV     R5,R2       ;;GET THE LSD  
(1) (1) 041226 000764      BR      6$          ;;GO CHANGE TO ASCII  
(1) (1) 041230 105726      8$:  TSTB   (SP)+       ;;WAS THE LSD THE FIRST NON-ZERO?  
(1) (1) 041232 100003      BPL     9$          ;;BR IF NO  
(1) (1) 041234 116663 177777 177776  MOVVB   -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING  
(1) (1) 041242 105013      9$:  CLRB   (R3)         ;;SET THE TERMINATOR  
(3) (1) 041244 012605      MOV     (SP)+,R5    ;;POP STACK INTO R5  
(3) (1) 041246 012603      MOV     (SP)+,R3    ;;POP STACK INTO R3  
(3) (1) 041250 012602      MOV     (SP)+,R2    ;;POP STACK INTO R2
```

```

(3) 041252 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
(3) 041254 012600      MOV      (SP)+,R0      ;;POP STACK INTO R0
(1) 041256 104401      TYPE     $DBLK         ;;NOW TYPE THE NUMBER
(1) 041262 016666      MOV      2(SP),4(SP)   ;;ADJUST THE STACK
(1) 041270 012616      MOV      (SP)+,(SP)
(1) 041272 000002      RTI              ;;RETURN TO USER
(1) 041274 023420      $DTBL: 10000.
(1) 041276 001750      1000.
(1) 041300 000144      100.
(1) 041302 000012      10.
(1) 041304 000004      $DBLK: .BLKW 4
4982 :////////////////////////////////////
4983 : NOW BACK UP AND PATCH $TYPDS TO REALLY NULL LEAD ZEROS
4984 : INSTEAD OF REPLACING THEM WITH SPACES.
4985 :
4986 : SVPC= : SAVE PC...
4987 :.= $TYPDS+110 : ...AND POINT TO 6$.
4988 041200 062702 177661 6$: ADD #60-177,R2 : CONVERT N TO ASCII N - NULL.
4989 041204 062702 000177 7$: ADD #177,R2 : CONVERT 0 TO NULL.
4990 :.- SVPC : RESTORE PC.
4991 :////////////////////////////////////
    
```

```

4993 .SBTTL APT COMMUNICATIONS ROUTINE
(1)
(2)
(1) 041314 112737 000001 041560 $ATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
(1) 041322 112737 000001 041556 $ATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
(1) 041330 000403 BR $ATYC
(1) 041332 112737 000001 041560 $ATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
(1) 041340 $ATYC:
(3) 041340 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
(3) 041342 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
(1) 041344 105737 041556 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
(1) 041350 001450 BEQ 5$ ;;IF NOT: BR
(1) 041352 122737 000001 001254 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
(1) 041360 001031 BNE 3$ ;;IF NOT: BR
(1) 041362 132737 000100 001255 BITB #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
(1) 041370 001425 BEQ 3$ ;;IF NOT: BR
(1) 041372 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
(1) 041376 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
(1) 041404 005737 001234 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
(1) 041410 001375 BNE 1$ ;;IF NOT: WAIT
(1) 041412 010037 001250 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
(1) 041416 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
(1) 041420 001376 BNE 2$
(1) 041422 163700 001250 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
(1) 041426 006200 ASR R0 ;;GET MESSAGE LNTH IN WORDS
(1) 041430 010037 001252 MOV R0,$MSGGLT ;;PUT LENGTH IN MAILBOX
(1) 041434 012737 000004 001234 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
(1) 041442 000413 BR 5$
(1) 041444 017637 000004 041470 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
(1) 041452 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
(3) 041460 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
(1) 041464 004737 040236 JSR PC,$TYPE ;;CALL TYPE MACRO
(1) 041470 000000 4$: .WORD 0
(1) 041472 5$:
(1) 041472 105737 041560 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
(1) 041476 001416 BEQ 12$ ;;IF NOT: BR
(1) 041500 005737 001254 TST $ENV ;;RUNNING UNDER APT?
(1) 041504 001413 BEQ 12$ ;;IF NOT: BR
(1) 041506 005737 001234 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
(1) 041512 001375 BNE 11$ ;;IF NOT: WAIT
(1) 041514 017637 000004 001236 MOV @4(SP),$FATAL ;;GET ERROR #
(1) 041522 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
(1) 041530 005237 001234 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
(1) 041534 105037 041560 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
(1) 041540 105037 041557 CLRB $LFLG ;;CLEAR LOG FLAG
(1) 041544 105037 041556 CLRB $MFLG ;;CLEAR MESSAGE FLAG
(3) 041550 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
(3) 041552 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
(1) 041554 000207 RTS PC ;;RETURN
(1) 041556 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
(1) 041557 000 $LFLG: .BYTE 0 ;;LOG FLAG
(1) 041560 000 $FFLG: .BYTE 0 ;;FATAL FLAG
(1) 041562 .EVEN
(1) 000200 APTSIZE-200
(1) 000001 APTENV-001
(1) 000100 APTSPOOL-100
  
```


AA -- LSI11/23 FPF11 DIAGNOSTIC, PART 1 MACY11 30G(1063) K 12
PAA.P11 28-JAN-81 09:50 APT COMMUNICATIONS ROUTINE 28-JAN-81 10:06 PAGE 3-12

(1) 000040 APTCSUP=040

SEQ 0153

```

4995      .SBITL TTY INPUT ROUTINE
(1)
(2)      ::*****
(1)      .ENABL LSB
(1)
(2)      ::*****
(1)      *SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
(1)      *ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
(1)      *SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
(1)      *WHEN OPERATING IN TTY FLAG MODE.
(1) 041562 022737 000176 001140 $CKSWR: CMP      #SWREG,SWR      ;; IS THE SOFT-SWR SELECTED?
(1) 041570 001074          BNE      15$          ;; BRANCH IF NO
(1) 041572 105777 137346      TSTB     @STKS          ;; CHAR THERE?
(1) 041576 100071          BPL      15$          ;; IF NO, DON'T WAIT AROUND
(1) 041600 117746 137342      MOVB     @STKB,-(SP)    ;; SAVE THE CHAR
(1) 041604 042716 177600      BIC      #'C177,(SP)  ;; STRIP-OFF THE ASCII
(1) 041610 022726 000007      CMP      #7,(SP)+     ;; IS IT A CONTROL G?
(1) 041614 001062          BNE      15$          ;; NO, RETURN TO USER
(1) 041616 123727 001134 000001      CMPB     $AUTOB,#1    ;; ARE WE RUNNING IN AUTO-MODE?
(1) 041624 001456          BEQ      15$          ;; BRANCH IF YES
(1)
(1) 041626 104401 042171          TYPE     ,SCNTLG      ;; ECHO THE CONTROL-G (^G)
(1) 041632 104401 042176      $GTSWR: TYPE     ,SMSWR      ;; TYPE CURRENT CONTENTS
(2) 041636 013746 000176      MOV      SWREG,-(SP)  ;; SAVE SWREG FOR TYPEOUT
(2) 041642 104402          TYPOC   ,              ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
(1) 041644 104401 042207          TYPE     ,SMNEW      ;; PROMPT FOR NEW SWR
(1) 041650 005046          19$:    CLR      -(SP)    ;; CLEAR COUNTER
(1) 041652 005046          CLR      -(SP)    ;; THE NEW SWR
(1) 041654 105777 137264          7$:    TSTB     @STKS          ;; CHAR THERE?
(1) 041660 100375          BPL      7$          ;; IF NOT TRY AGAIN
(1)
(1) 041662 117746 137260          MOVB     @STKB,-(SP)  ;; PICK UP CHAR
(1) 041666 042716 177600      BIC      #'C177,(SP)  ;; MAKE IT 7-BIT ASCII
(1)
(1)
(1) 041672 021627 000025          9$:    CMP      (SP),#25    ;; IS IT A CONTROL-U?
(1) 041676 001005          BNE      10$         ;; BRANCH IF NOT
(1) 041700 104401 042164          TYPE     ,SCNTLU     ;; YES, ECHO CONTROL-U (^U)
(1) 041704 062706 000006          20$:   ADD      #6,SP     ;; IGNORE PREVIOUS INPUT
(1) 041710 000757          BR      19$         ;; LET'S TRY IT AGAIN
(1)
(1)
(1) 041712 021627 000015          10$:   CMP      (SP),#15    ;; IS IT A <CR>?
(1) 041716 001022          BNE      16$         ;; BRANCH IF NO
(1) 041720 005766 000004          TST      4(SP)       ;; YES, IS IT THE FIRST CHAR?
(1) 041724 001403          BEQ      11$         ;; BRANCH IF YES
(1) 041726 016677 000002 137204      MOV      2(SP),@SWR   ;; SAVE NEW SWR
(1) 041734 062706 000006          11$:   ADD      #6,SP     ;; CLEAR UP STACK
(1) 041740 104401 001231          14$:   TYPE     ,$CRLF    ;; ECHO <CR> AND <LF>
(1) 041744 123727 001135 000001      CMPB     $INTAG,#1   ;; RE-ENABLE TTY KBD INTERRUPTS?
(1) 041752 001003          BNE      15$         ;; BRANCH IF NOT
(1) 041754 012777 000100 137162      MOV      #100,@STKS  ;; RE-ENABLE TTY KBD INTERRUPTS
(1) 041762 000002          15$:   RTI              ;; RETURN
(1) 041764 004737 040450          16$:   JSR      PC,$TYPEC  ;; ECHO CHAR
(1) 041770 021627 000060          CMP      (SP),#60   ;; CHAR < 0?
    
```

```

(1) 041774 002420          BLT    18$          ;;BRANCH IF YES
(1) 041776 021627 000067    CMP    (SP),#67      ;;CHAR > 7?
(1) 042002 003015          BGT    18$          ;;BRANCH IF YES
(1) 042004 042726 000060    BIC    #60,(SP)+    ;;STRIP-OFF ASCII
(1) 042010 005766 000002    TST    2(SP)        ;;IS THIS THE FIRST CHAR
(1) 042014 001403          BEQ    17$          ;;BRANCH IF YES
(1) 042016 006316          ASL    (SP)         ;;NO, SHIFT PRESENT
(1) 042020 006316          ASL    (SP)         ;;CHAR OVER TO MAKE
(1) 042022 006316          ASL    (SP)         ;;ROOM FOR NEW ONE.
(1) 042024 005266 000002    17$: INC    2(SP)        ;;KEEP COUNT OF CHAR
(1) 042030 056616 177776    BIS    -2(SP),(SP)  ;;SET IN NEW CHAR
(1) 042034 000707          BR     7$           ;;GET THE NEXT ONE
(1) 042036 104401 001230    18$: TYPE  $QUES    ;;TYPE ?<CR><LF>
(1) 042042 000720          BR     20$          ;;SIMULATE CONTROL-U
(1) .DSABL LSB
(1)
(1)
(2)
(1) *****
(1) *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
(1) *CALL:
(1) * RDCHR          ;;INPUT A SINGLE CHARACTER FROM THE TTY
(1) * RETURN HERE   ;;CHARACTER IS ON THE STACK
(1) *              ;;WITH PARITY BIT STRIPPED OFF
(1)
(1)
(1) 042044 011646          $RDCHR: MOV    (SP),-(SP)  ;;PUSH DOWN THE PC
(1) 042046 016666 000004 000002  MOV    4(SP),2(SP)      ;;SAVE THE PS
(1) 042054 105777 137064    1$: TSTB @STKS          ;;WAIT FOR
(1) 042060 100375          BPL    1$           ;;A CHARACTER
(1) 042062 117766 137060 000004  MOVB @STKB,4(SP)        ;;READ THE TTY
(1) 042070 042766 177600 000004  BIC    #^C<177>,4(SP)  ;;GET RID OF JUNK IF ANY
(1) 042076 026627 000004 000023  CMP    4(SP),#23      ;;IS IT A CONTROL-S?
(1) 042104 001013          BNE    3$           ;;BRANCH IF NO
(1) 042106 105777 137032    2$: TSTB @STKS          ;;WAIT FOR A CHARACTER
(1) 042112 100375          BPL    2$           ;;LOOP UNTIL ITS THERE
(1) 042114 117746 137026  MOVB @STKB,-(SP)        ;;GET CHARACTER
(1) 042120 042716 177600          BIC    #^C177,(SP)    ;;MAKE IT 7-BIT ASCII
(1) 042124 022627 000021          CMP    (SP)+,#21     ;;IS IT A CONTROL-Q?
(1) 042130 001366          BNE    2$           ;;IF NOT DISCARD IT
(1) 042132 000750          BR     1$           ;;YES, RESUME
(1) 042134 026627 000004 000140  3$: CMP    4(SP),#140   ;;IS IT UPPER CASE?
(1) 042142 002407          BLT    4$           ;;BRANCH IF YES
(1) 042144 026627 000004 000175  CMP    4(SP),#175     ;;IS IT A SPECIAL CHAR?
(1) 042152 003003          BGT    4$           ;;BRANCH IF YES
(1) 042154 042766 000040 000004  BIC    #40,4(SP)      ;;MAKE IT UPPER CASE
(1) 042162 000002          RTI                    ;;GO BACK TO USER
(1) 042164 052536 005015 000          $CNTLU: .ASCIZ /^U/<15><12>  ;;CONTROL 'U'
(1) 042171 136 006507 000012  $CNTLG: .ASCIZ /^G/<15><12>  ;;CONTROL 'G'
(1) 042176 005015 053523 020122  $MSWR: .ASCIZ <15><12>/SWR = /
(1) 042207 040 047040 053505  $MNEW: .ASCIZ / NEW - /

```

4997

.SBTTL TRAP DECODER

```

*****
*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION
*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
*GO TO THAT ROUTINE.
    
```

```

(1) 042220 010046          STRAP: MOV     RO,-(SP)      ;;SAVE RO
(1) 042222 016600 000002  MOV     2(SP),RO        ;;GET TRAP ADDRESS
(1) 042226 005740          TST     -(RO)           ;;BACKUP BY 2
(1) 042230 111000          MOVB   (RO),RO         ;;GET RIGHT BYTE OF TRAP
(1) 042232 006300          ASL    RO              ;;POSITION FOR INDEXING
(1) 042234 016000 042254  MOV     $TRPAD(RO),RO   ;;INDEX TO TABLE
(1) 042240 000200          RTS     RO             ;;GO TO ROUTINE
    
```

;;THIS IS USE TO HANDLE THE 'GETPRI' MACRO

```

(1) 042242 011646          STRAP2: MOV    (SP),-(SP)  ;;MOVE THE PC DOWN
(1) 042244 016666 000004 000002 MOV    4(SP),2(SP)      ;;MOVE THE PSW DOWN
(1) 042252 000002          RTI                    ;;RESTORE THE PSW
    
```

.SBTTL TRAP TABLE

```

*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
*BY THE 'TRAP' INSTRUCTION.
    
```

```

(3)          :          ROUTINE
(3)          :          -----
(3) 042254 042242  STRPAD: .WORD  STRAP2
(3) 042256 040236  $TYPE  ;;CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
(3) 042260 040666  $TYPOC ;;CALL=TYPOC    TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
(3) 042262 040642  $TYPOS ;;CALL=TYPOS    TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
(3) 042264 040702  $TYPON ;;CALL=TYPON     TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
(3) 042266 041070  $TYPDS ;;CALL=TYPDS    TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)
(1)          :
(3) 042270 041632  $GTSWR ;;CALL=GTSWR     TRAP+6(104406)  GET SOFT-SWR SETTING
(1)          :
(3) 042272 041562  $CKSWR ;;CALL=CKSWR     TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
(3) 042274 042044  $RDCHR ;;CALL=RDCHR     TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
4998 042276 042302  .LPER  ;;CALL=LUPERR   TRAP+11(104411) SET LOOP-ON-ERROR ADDRESS
4999 042300 042310  .CLRFP ;;CALL=CLRFPS     TRAP+12(104412) CLEAR FPS AND END TEST
    
```

\$TERM=-\$TRPAD

```

: THIS IS TO SET THE LOOP-ON-ERROR (SWR9) ADDRESS.
: CALLED VIA 'TRAP+11'.
    
```

```

5004 042302 011637 001110  .LPER: MOV     (SP),$LPERR
5006 042306 000002          RTI
    
```

```

: COME HERE AT END OF EACH TEST TO CLEAR FPS AND RESET VECTORS.
: CALLED VIA 'TRAP+12'.
    
```

```

5011 042310 012700 042342  .CLRFP: MOV    #1$,RO
5012 042314 010037 000244  MOV    RO,FPVEC      ; JUST IN CASE THE...
    
```

5013	042320	010037	000010		MOV	RO,RESVEC		
5014	042324	010037	000004		MOV	RO,ERRVEC		:...LDFPS IS BAD.
5015	042330	005000			CLR	RO		
5016	042332	170100			LDFPS	RO		: CLEAR FP STATUS.
5017	042334	000240	000240		240,240			
5018	042340	000401			SKP1			
5019	042342	022626		1\$:	CMR	(SP)+,(SP)+		: IF IT TRAPPED, JUST FIX THE STACK.
5020	042344	012737	004200	000244	MOV	#TRP244,FPVEC		: RESET ALL VECTORS.
5021	042352	012737	004234	000010	MOV	#TRP10,RESVEC		
5022	042360	012737	004224	000004	MOV	#TRP04,ERRVEC		
5023	042366	000002			RTI			

5025

.SBTTL POWER DOWN AND UP ROUTINES

```

(1) (2)
(1) (1) 042370 012737 042534 000024 $PWRDN: MOV #SILLUP,@#PWRVEC ;;SET FOR FAST UP
(1) (1) 042376 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;PRIO:7
(3) (3) 042404 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
(3) (3) 042406 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
(3) (3) 042410 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
(3) (3) 042412 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
(3) (3) 042414 010446 MOV R4,-(SP) ;;PUSH R4 ON STACK
(3) (3) 042416 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
(3) (3) 042420 017746 136514 MOV @SWR,-(SP) ;;PUSH @SWR ON STACK
(1) (1) 042424 010637 042540 MOV SP,$SAVR6 ;;SAVE SP
(1) (1) 042430 012737 042442 000024 MOV #PWRUP,@#PWRVEC ;;SET UP VECTOR
(1) (1) 042436 000000 HALT
(1) (1) 042440 000776 BR .-2 ;;HANG UP
(1) (2)
(1) (1) 042442 012737 042534 000024 $PWRUP: MOV #SILLUP,@#PWRVEC ;;SET FOR FAST DOWN
(1) (1) 042450 013706 042540 MOV $SAVR6,SP ;;GET SP
(1) (1) 042454 005037 042540 CLR $SAVR6 ;;WAIT LOOP FOR THE TTY
(1) (1) 042460 005237 042540 1$: INC $SAVR6 ;;WAIT FOR THE INC
(1) (1) 042464 001375 BNE 1$ ;;OF WORD
(3) (3) 042466 012677 136446 MOV (SP)+,@SWR ;;POP STACK INTO @SWR
(3) (3) 042472 012605 MOV (SP)+,R5 ;;POP STACK INTO R5
(3) (3) 042474 012604 MOV (SP)+,R4 ;;POP STACK INTO R4
(3) (3) 042476 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
(3) (3) 042500 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
(3) (3) 042502 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
(3) (3) 042504 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
(1) (1) 042506 012737 042370 000024 MOV #PWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
(1) (1) 042514 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;PRIO:7
(1) (1) 042522 104401 TYPE ;;REPORT THE POWER FAILURE
(1) (1) 042524 043304 $PWRMG: .WORD POWERM ;;POWER FAIL MESSAGE POINTER
(1) (1) 042526 012716 MOV (PC)+,(SP) ;;RESTART AT START
(1) (1) 042530 003542 $PWRAD: .WORD START ;;RESTART ADDRESS
(1) (1) 042532 000002 RTI
(1) (1) 042534 000000 $SILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
(1) (1) 042536 000776 BR .-2 ;; BEFORE THE POWER DOWN WAS COMPLETE
(1) (1) 042540 000000 $SAVR6: 0 ;;PUT THE SP HERE
  
```

```

5027          .SBTTL  ERROR HANDLER ROUTINE
(1)
(2)          ::*****
(1)          ::THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT.
(1)          ::SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
(1)          ::AND GO TO ERTYPE ON ERROR
(1)          ::THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
(1)          ::SW15=1      HALT ON ERROR
(1)          ::SW13=1      INHIBIT ERROR TYPEOUTS
(1)          ::SW10=1      BELL ON ERROR
(1)          ::SW09=1      LOOP ON ERROR
(1)          ::CALL
(1)          ::*      ERROR  N      ::ERROR=EMT AND N=ERROR ITEM NUMBER
(1)
(1)          $ERROR:
(1)          042542          CKSWR          ::TEST FOR CHANGE IN SOFT-SWR
(1)          042542  104407          7$:      INCB          $ERFLG          ::SET THE ERROR FLAG
(1)          042544  105237  001103      BEQ          7$          ::DON'T LET THE FLAG GO TO ZERO
(1)          042550  001775          MOV          $TSTNM,@DISPLAY ::DISPLAY TEST NUMBER AND ERROR FLAG
(1)          042552  013777  001102  136362      BIT          #BIT10,@SWR    ::BELL ON ERROR?
(1)          042560  032777  002000  136352      BEQ          1$          ::NO - SKIP
(1)          042566  001402          TYPE          $BELL          ::RING BELL
(1)          042570  104401  001224          INC          $ERTTL       ::COUNT THE NUMBER OF ERRORS
(1)          042574  005237  001112          MOV          (SP),$ERRPC  ::GET ADDRESS OF ERROR INSTRUCTION
(1)          042600  011637  001116          SUB          #2,$ERRPC
(1)          042604  162737  000002  001116      MOV          @SERRPC,$ITEMB ::STRIP AND SAVE THE ERROR ITEM CODE
(1)          042612  117737  136300  001114      BIT          #BIT13,@SWR    ::SKIP TYPEOUT IF SET
(1)          042620  032777  020000  136312      BNE          20$         ::SKIP TYPEOUTS
(1)          042626  001004          JSR          PC,ERTYPE    ::GO TO USER ERROR ROUTINE
(1)          042630  004737  042742          TYPE          $CRLF
(1)          042634  104401  001231          CMP          #APTENV,$ENV  ::RUNNING IN APT MODE
(1)          042640          BNE          2$          ::NO SKIP APT ERROR REPORT
(1)          042640  122737  000001  001254      MOV          $ITEMB,21$   ::SET ITEM NUMBER AS ERROR NUMBER
(1)          042646  001007          JSR          PC,$ATY4    ::REPORT FATAL ERROR TO APT
(1)          042650  113737  001114  042662
(1)          042656  004737  041332          .BYTE          0          21$:
(1)          042662          .BYTE          0
(1)          042663          .BYTE          0
(1)          042664  000777          BR          22$          ::APT ERROR LOOP
(1)          042666  005777  136246          TST          @SWR        ::HALT ON ERROR
(1)          042672  100002          BPL          3$          ::SKIP IF CONTINUE
(1)          042674  000000          HALT          ::HALT ON ERROR!
(1)          042676  104407          CKSWR          ::TEST FOR CHANGE IN SOFT-SWR
(1)          042700  032777  001000  136232      BIT          #BIT09,@SWR  ::LOOP ON ERROR SWITCH SET?
(1)          042706  001402          BEQ          4$          ::BR IF NO
(1)          042710  013716  001110          MOV          $LPERR,(SP)  ::FUDGE RETURN FOR LOOPING
(1)          042714  005737  001222          TST          $ESCAPE     ::CHECK FOR AN ESCAPE ADDRESS
(1)          042720  001402          BEQ          5$          ::BR IF NONE
(1)          042722  013716  001222          MOV          $ESCAPE,(SP) ::FUDGE RETURN ADDRESS FOR ESCAPE
(1)          042726          5$:
(1)          042726  022737  037464  000042      CMP          #$ENDAD,@#42 ::ACT-11 AUTO-ACCEPT?
(1)          042734  001001          BNE          6$          ::BRANCH IF NO
(1)          042736  000000          HALT          ::YES
(1)          042740          6$:
(1)          042740  000002          RTI          ::RETURN
    
```

5029
 5030
 5031
 5032
 5033
 5034
 5035
 5036
 5037
 5038
 5039
 5040
 5041
 5042
 5043
 5044
 5045
 5046
 5047
 5048
 5049
 5050
 5051
 5052
 5053
 5054
 5055
 5056
 5057
 5058
 5059
 5060
 5061
 5062
 5063
 5064
 5065
 5066
 5067
 5068
 5069
 5070
 5071
 5072
 5073
 5074
 5075
 5076
 5077
 5078
 5079
 5080
 5081
 5082
 5083
 5084

042742 010046
 042744 010146
 042746 010246
 042750 010346
 042752 104401 001231
 042756 113737 001102 001160
 042764 042737 177400 001160
 042772 013737 001116 001162
 043000 113700 001114
 043004 042700 177400
 043010 001524
 043012 005300
 043014 006300
 043016 006300
 043020 006300
 043022 062700 001312
 043026 012037 043036
 043032 001404
 043034 104401
 043036 000000
 043040 104401 001231
 043044 012037 043054
 043050 001404
 043052 104401
 043054 000000
 043056 104401 001231
 043062 012001
 043064 011000
 043066 005711
 043070 001474
 043072 105710
 043074 001003
 043076 013146
 043100 104402
 043102 000463
 043104 121027 000002
 043110 001010
 043112 013102
 043114 012246
 043116 104402
 043120 104401 043300
 043124 011246
 043126 104402
 043130 000450
 043132 121027 000003
 043136 001011

```

.SBTTL ERROR TYPE OUT ROUTINE
: THIS ROUTINE IS CALLED FROM $ERROR, TO PRINT THE VARIOUS
: ERROR SIGNATURES.
:
ERTYPE: MOV      RO,-(SP)          ;SAVE REGISTERS.
        MOV      R1,-(SP)
        MOV      R2,-(SP)
        MOV      R3,-(SP)
        TYPE     , $CRLF
        MOV      $STNM,$TMP0
        BIC      #^C377,$TMP0    ; SET TEST NUMBER...
        MOV      $ERRPC,$TMP1    ;...AND CALL PC.
        MOV      $ITEMB,RO       ; GET ERROR ITEM NUMBER.
        BIC      #^C377,RO
        BEQ      ERT4           ; JUST IGNORE ERROR 0.
:
2$:    DEC      RO              ; NOW MAKE INTO AN INDEX.
        ASL      RO
        ASL      RO
        ASL      RO
        ADD      # $ERRTB,RO     ; RO POINTS TO 'ITEM XX'.
        MOV      (RO)+,3$       ; GET EMXX POINTER.
        BEQ      4$
        TYPE     ; TYPE EM TEXT.
3$:    0
        TYPE     , $CRLF
4$:    MOV      (RO)+,5$       ; GET DHXX POINTER.
        BEQ      6$
        TYPE     ; TYPE DH TEXT.
5$:    0
        TYPE     , $CRLF
6$:    MOV      (RO)+,R1       ; R1 POINTS TO 'DTXX'...
        MOV      (RO),RO      ;...AND RO TO 'DFXX'.
ERT1:  TST      (R1)
        BEQ      ERT4         ; EXIT AT END OF DATA TABLE.
1$:    TSTB     (RO)           ; FORMAT 0 ??
        BNE      2$
        MOV      @ (R1)+,-(SP) ; YES, TYPE AN OCTAL VALUE.
        TYPOC
        BR       ERT2
2$:    CMPB     (RO),#2        ; FORMAT 2 ??
        BNE      3$
        MOV      @ (R1)+,R2    ; YES, TYPE 2 OCTAL VALUES.
        MOV      (R2)+,-(SP)
        TYPOC
        TYPE     ,SPAC1
        MOV      (R2),-(SP)
        TYPOC
        BR       ERT2
3$:    CMPB     (RO),#3        ; FORMAT 3 ??
        BNE      5$
    
```


5085	043140	012703	000004		MOV	#4,R3		; YES, TYPE 4 OCTAL VALUES.
5086	043144	013102			MOV	@(R1)+,R2		
5087	043146	012246		4\$:	MOV	(R2)+,-(SP)		
5088	043150	104402			TYPOC			
5089	043152	104401	043300		TYPE	,SPAC1		
5090	043156	077305			SOB	R3,4\$		
5091	043160	000434			BR	ERT2		
5092								
5093	043162	121027	000004	5\$:	CMPB	(R0),#4		; FORMAT 4 ??
5094	043166	001004			BNE	6\$		
5095	043170	013146			MOV	@(R1)+,-(SP)		; YES, TYPE 4 OCTAL DIGITS...
5096	043172	104403			TYPOS			;...SUPPRESS LEAD ZEROS.
5097	043174	004	000		.BYTE	4,0		
5098	043176	000425			BR	ERT2		
5099								
5100	043200	121027	000005	6\$:	CMPB	(R0),#5		; FORMAT 5 ??
5101	043204	001005			BNE	10\$		
5102	043206	012137	043214		MOV	(R1)+,7\$; YES, TYPE ASCII STRING.
5103	043212	104401			TYPE			
5104	043214	000000		7\$:	0			
5105	043216	000417			BR	ERT3		
5106								
5107	043220	121027	000012	10\$:	CMPB	(R0),#12		; FORMAT 12 ??
5108	043224	001011			BNE	12\$		
5109	043226	012703	000010		MOV	#8,R3		; YES, TYPE 8 OCTAL VALUES.
5110	043232	013102			MOV	@(R1)+,R2		
5111	043234	012246		11\$:	MOV	(R2)+,-(SP)		
5112	043236	104402			TYPOC			
5113	043240	104401	043300		TYPE	,SPAC1		
5114	043244	077305			SOB	R3,11\$		
5115	043246	000401			BR	ERT2		
5116	043250	000000		12\$:	HALT			; UNDEFINED FORMAT CODE.
5117								
5118	043252	104401	043302	ERT2:	TYPE	,HTAB		; PRINT A TAB (AFTER DATA ONLY).
5119	043256	005200		ERT3:	INC	R0		; POINT TO NEXT FORMAT BYTE.
5120	043260	000702			BR	ERT1		
5121								
5122	043262	104401	001231	ERT4:	TYPE	,\$CRLF		
5123	043266	012603			MOV	(SP)+,R3		; RESTORE REGISTERS.
5124	043270	012602			MOV	(SP)+,R2		
5125	043272	012601			MOV	(SP)+,R1		
5126	043274	012600			MOV	(SP)+,R0		
5127	043276	000207			RTS	PC		
5128								
5129	043300	040	000	SPAC1:	.BYTE	40,0		
5130	043302	011	000	HTAB:	.BYTE	11,0		

```

5132 .SBITL ASCII TEXT AND ERROR MESSAGES.
5133 ;
5134 ; FIRST SOME BITS AND PIECES COMMON TO MANY.
5135 ;
5136 .NLIST BEX
5137 043304 050200 053517 051105 POWERM: .ASCIZ <CRLF>'POWER FAIL -- RESTARTING.'<CRLF>
5138 043340 000 NULL: .BYTE 0
5139 043341 101 047502 052122 ABORT: .ASCIZ 'ABORTING TEST... '<CRLF>
5140 043363 200 054105 042520 EAC: .ASCIZ <CRLF>'EXPECTED AC'
5141 043377 060 020072 000 EACN: .ASCIZ '0: '
5142 043403 200 042522 042503 RAC: .ASCIZ <CRLF>'RECEIVED AC'
5143 043417 060 020072 000 RACN: .ASCIZ '0: '
5144 043423 200 047523 051125 BSRC: .ASCIZ <CRLF>'SOURCE DATA (BEFORE): '
5145 043453 200 047523 051125 ASRC: .ASCIZ <CRLF>'SOURCE DATA (AFTER): '
5146 043503 200 051050 024460 ARZ: .ASCIZ <CRLF>'(RO) AFTER EXECUTION: '
5147 043533 200 051123 020103 SRC: .ASCIZ <CRLF>'SRC DATA: '
5148 043547 200 054105 042520 EXP: .ASCIZ <CRLF>'EXPECTED: '
5149 043563 200 042522 042503 RCD: .ASCIZ <CRLF>'RECEIVED: '
5150 043577 200 054105 042520 EAC15: .ASCIZ <CRLF>'EXPECTED AC1 THRU AC5:'
5151 043627 200 042522 042503 RAC15: .ASCIZ <CRLF>'RECEIVED AC1 THRU AC5:'
5152 043657 200 041501 035060 ACZ: .ASCIZ <CRLF>'ACO: '
5153 043666 042600 050130 041505 ERES: .ASCIZ <CRLF>'EXPECTED RESULT: '
5154 043713 200 042522 042503 RRES: .ASCIZ <CRLF>'RECEIVED RESULT: '
5155 043740 042600 050130 041505 ESTAT: .ASCIZ <CRLF>'EXPECTED FPS AND FEC: '
5156 043770 051200 041505 044505 RSTAT: .ASCIZ <CRLF>'RECEIVED FPS AND FEC: '
5157 044020 020200 041501 047440 ACOPR: .ASCIZ <CRLF>' AC OPERAND: '
5158 044037 200 051123 020103 SOPR: .ASCIZ <CRLF>'SRC OPERAND: '
5159 044056 042200 052123 047440 DOPR: .ASCIZ <CRLF>'DST OPERAND: '
5160 044075 200 041501 020060 ACOB: .ASCIZ <CRLF>'ACO BEFORE: '
5161 044113 200 041501 020060 ACOA: .ASCIZ <CRLF>'ACO AFTER: '
5162 044131 200 054105 042120 EFRAC: .ASCIZ <CRLF>'EXPD FRACTION (ACO): '
5163 044160 051200 041505 020104 RFRAC: .ASCIZ <CRLF>'RECD FRACTION: '
5164 044207 200 054105 042120 EINT: .ASCIZ <CRLF>'EXPD INTEGER (AC1): '
5165 044236 051200 041505 020104 RINT: .ASCIZ <CRLF>'RECD INTEGER: '
5166 044265 200 041520 020054 REGS: .ASCIZ <CRLF>'PC, FPS, RO, AND ACO '
5167 044314 042502 047506 042522 BI: .ASCIZ 'BEFORE INTERRUPT:'<CRLF>
5168 044337 101 052106 051105 AI: .ASCIZ 'AFTER INTERRUPT:'<CRLF>
5169 ;
5170 ; ERROR MESSAGES:
5171 ;
5172 044361 114 043104 051520 EM1: .ASCIZ 'LDFPS AND STFPS FAILED.'
5173 044411 114 043104 051520 EM2: .ASCIZ 'LDFPS AND STFPS ERROR SUMMARY.'
5174 044450 051520 020127 047111 EM3: .ASCIZ 'PSW INCORRECT AFTER CFCC.'
5175 044502 050106 020123 047111 EM4: .ASCIZ 'FPS INCORRECT AFTER CFCC.'
5176 044534 047125 054105 042520 EM5: .ASCIZ 'UNEXPECTED FPP TRAP TO 244.'
5177 044570 047125 054105 042520 EM6: .ASCIZ 'UNEXPECTED CPU TRAP TO 4.'
5178 044622 047125 054105 042520 EM7: .ASCIZ 'UNEXPECTED CPU TRAP TO 10.'
5179 ;
5180 044655 106 051520 044440 EM12: .ASCIZ 'FPS INCORRECT AFTER SET'
5181 044704 020111 047111 052123 EM12X: .ASCIZ 'I INSTRUCTION.'
5182 044723 111 046114 043505 EM16: .ASCIZ 'ILLEGAL FP OPCODE DID NOT TRAP.'
5183 044763 106 051520 044440 EM17: .ASCIZ 'FPS INCORRECT AFTER ILLEGAL OPCODE TRAP.'
5184 045034 042506 020103 047111 EM20: .ASCIZ 'FEC INCORRECT AFTER ILLEGAL OPCODE TRAP.'
5185 ;
5186 045105 106 051520 044440 EM22: .ASCIZ 'FPS INCORRECT AFTER ILLEGAL OPCODE (INT DISABLED).'
5187 045170 042506 020103 047111 EM23: .ASCIZ 'FEC INCORRECT AFTER ILLEGAL OPCODE (INT DISABLED).'
    
```

5188	045253	111	046114	043505	EM24:	.ASCIZ	'ILLEGAL OPCODE TRAPPED WITH INTERRUPT DISABLED.'
5189	045333	123	052517	041522	EM25:	.ASCIZ	'SOURCE DATA ALTERED AFTER LDD (RO),ACO.'
5190	045403	122	020060	047111	EM26:	.ASCIZ	'RO INCORRECT AFTER LDD (RO),ACO.'
5191	045443	200	041050	052125		.ASCIZ	<CRLF>'(BUT FSRC) FAILED TO MODE 2 OR 4.'
5192							
5193	045506	030122	044440	041516	EM31:	.ASCIZ	'RO INCORRECT AFTER STD ACO,(RO).'
5194	045546	024200	052502	020124		.ASCIZ	<CRLF>'(BUT FDST) FAILED TO MODE 2 OR 4.'
5195							
5196	045611	123	042124	040440	EM34:	.ASCIZ	'STD ACO,(RO) EXECUTED WRONG DST MODE.'
5197	045656	024200	052502	020124		.ASCIZ	<CRLF>'(BUT GR7) FAILED TO IMMEDIATE MODE.'
5198	045723	114	042104	024040	EM35:	.ASCIZ	'LDD (RO),ACO EXECUTED WRONG SRC MODE.'
5199	045770	024200	052502	020124		.ASCIZ	<CRLF>'(BUT GR7) FAILED TO IMMEDIATE MODE.'
5200	046035	123	042124	040440	EM36:	.ASCIZ	'STD ACO,(RO) EXECUTED WRONG DATA MODE.'
5201	046103	200	041050	052125		.ASCIZ	<CRLF>'(BUT FD) FAILED TO SINGLE-PRECISION.'
5202	046151	114	042104	024040	EM37:	.ASCIZ	'LDD (RO),ACO EXECUTED WRONG DATA MODE.'
5203	046217	200	041050	052125		.ASCIZ	<CRLF>'(BUT FD) FAILED TO SINGLE-PRECISION.'
5204	046265	104	052101	020101	EM40:	.ASCIZ	'DATA INCORRECT AFTER LDD AND STD.'
5205	046327	106	051520	044440	EM41:	.ASCIZ	'FPS INCORRECT AFTER LOAD AND/OR STORE.'
5206	046376	042114	020104	051050	EM42:	.ASCIZ	'LDD (RO),ACO TRAPPED TO 4.<CRLF>
5207	046431	050	052502	020124		.ASCIZ	'(BUT FSRC) FAILED TO MODE 3, 5, 6, OR 7.'
5208	046502	052123	020104	041501	EM43:	.ASCIZ	'STD ACO,(RO) TRAPPED TO 4.<CRLF>
5209	046535	050	052502	020124		.ASCIZ	'(BUT FDST) FAILED TO MODE 3, 5, 6, OR 7.'
5210	046606	041501	052503	052515	EM44:	.ASCIZ	'ACCUMULATORS DATA TEST FAILED.'
5211							
5212	046645	101	041503	046525	EM46:	.ASCIZ	'ACCUMULATORS DUAL ADDRESSING TEST FAILED.'
5213	046717	114	057504	040440	EM47:	.ASCIZ	'LD AC1,ACO TRAPPED TO 4.<CRLF>
5214	046751	050	052502	020124		.ASCIZ	'(BUT FSRC) FORK FAILED IN FSRC FLOW.'
5215	047016	042114	020137	041501	EM50:	.ASCIZ	'LD AC1,ACO DATA FORMAT INCORRECT.<CRLF>
5216	047061	050	052502	020124		.ASCIZ	'(BUT FD) FORK FAILED IN FSRC FLOW.'
5217	047124	042114	020137	041501	EM51:	.ASCIZ	'LD AC1,ACO TRANSFERRED BAD DATA.'
5218	047166	042114	020104	051050	EM52:	.ASCIZ	'LDD (RO)+,ACO TRAPPED TO 4.'
5219	047222	030122	044440	041516	EM53:	.ASCIZ	'RO INCORRECT AFTER LDD (RO)+,ACO.'
5220	047264	040504	040524	044440	EM54:	.ASCIZ	'DATA INCORRECT AFTER LDD (RO)+,ACO.'
5221	047330	042114	020104	024055	EM55:	.ASCIZ	'LDD -(RO),ACO TRAPPED TO 4.'
5222	047364	030122	044440	041516	EM56:	.ASCIZ	'RO INCORRECT AFTER LDD -(RO),ACO.'
5223	047426	040504	040524	044440	EM57:	.ASCIZ	'DATA INCORRECT AFTER LDD -(RO),ACO.'
5224	047472	030122	044440	041516	EM60:	.ASCIZ	'RO INCORRECT AFTER LDF (RO)+,ACO.'
5225	047534	040504	040524	044440	EM61:	.ASCIZ	'DATA INCORRECT AFTER LDF (RO)+,ACO.'
5226	047600	040504	040524	043040	EM62:	.ASCIZ	'DATA FORMAT INCORRECT AFTER LDF (RO)+,ACO.'
5227	047652	024200	052502	020124		.ASCIZ	<CRLF>'(BUT FD) FORK FAILED IN FSRC FLOW.'
5228	047716	040504	040524	044440	EM63:	.ASCIZ	'DATA INCORRECT AFTER LDD #5204,ACO.'
5229	047761	200	041050	052125		.ASCIZ	<CRLF>'(BUT GR7) FORK FAILED IN FSRC FLOW.'
5230	050026	041520	044440	041516	EM64:	.ASCIZ	'PC INCORRECT AFTER LDD #5204,ACO.'
5231	050070	042114	020104	032443	EM65:	.ASCIZ	'LDD #5204,ACO TRAPPED TO 4.'
5232	050124	040504	040524	044440	EM66:	.ASCIZ	'DATA INCORRECT AFTER LDD #5204,ACO.'
5233	050170	042114	020104	024100	EM67:	.ASCIZ	'LDD @(RO)+,ACO TRAPPED TO 4.'
5234	050224	024200	052502	020124		.ASCIZ	<CRLF>'(BUT FSRC) FAILED TO MODE 5, 6, OR 7.'
5235		050170			EM70=EM67		
5236	050273	114	042104	040040	EM71:	.ASCIZ	'LDD @(RO)+,ACO EXECUTED WRONG FSRC MODE.'
5237	050343	200	041050	052125		.ASCIZ	<CRLF>'(BUT FSRC) FAILED TO MODE 0, 1, 2, OR 4.'
5238	050415	122	020060	047111	EM72:	.ASCIZ	'RO INCORRECT AFTER LDD @(RO)+,ACO.'
5239	050460	040504	040524	044440	EM73:	.ASCIZ	'DATA INCORRECT AFTER LDD @(RO)+,ACO.'
5240	050525	114	042104	040040	EM74:	.ASCIZ	'LDD @-(RO),ACO TRAPPED TO 4.'
5241	050561	200	041050	052125		.ASCIZ	<CRLF>'(BUT FSRC) FAILED TO MODE 3, 6, OR 7.'
5242		050525			EM75-EM74		
5243	050630	042114	020104	026500	EM76:	.ASCIZ	'LDD @-(RO),ACO EXECUTED WRONG FSRC MODE.'

5244	050700	024200	052502	020124		.ASCIZ	<CRLF>'(BUT FSRC) FAILED TO MODE 0, 1, 2, OR 4.'
5245	050752	030122	044440	041516	EM77:	.ASCIZ	'RO INCORRECT AFTER LDD @-(RO),ACO.'
5246	051015	104	052101	020101	EM100:	.ASCIZ	'DATA INCORRECT AFTER LDD @-(RO),ACO.'
5247	051062	042114	020104	032062	EM101:	.ASCII	'LDD 241(RO),ACO TRAPPED TO 4.'
5248	051117	200	041050	052125		.ASCIZ	<CRLF>'(BUT FSRC) FAILED TO EXECUTE MODE 6.'
5249	051165	122	020060	047111	EM102:	.ASCIZ	'RO INCORRECT AFTER LDD 241(RO),ACO.'
5250	051231	114	042104	031040	EM103:	.ASCII	'LDD 241(RO),ACO EXECUTED WRONG FSRC MODE.'
5251	051302	024200	052502	020124		.ASCIZ	<CRLF>'(BUT FSRC) FAILED TO MODE 0.'
5252	051340	040504	040524	044440	EM104:	.ASCIZ	'DATA INCORRECT AFTER LDD 241(RO),ACO.'
5253	051406	042114	020104	031100	EM105:	.ASCII	'LDD @241(RO),ACO TRAPPED TO 4.'
5254	051444	024200	052502	020124		.ASCIZ	<CRLF>'(BUT FSRC) FAILED TO EXECUTE MODE 7.'
5255	051512	030122	044440	041516	EM106:	.ASCIZ	'RO INCORRECT AFTER LDD @241(RO),ACO.'
5256	051557	114	042104	040040	EM107:	.ASCII	'LDD @241(RO),ACO EXECUTED WRONG FSRC MODE.'
5257	051631	200	041050	052125		.ASCIZ	<CRLF>'(BUT FSRC) FAILED TO MODE 0 OR 6.'
5258	051674	040504	040524	044440	EM110:	.ASCIZ	'DATA INCORRECT AFTER LDD @241(RO),ACO.'
5259	051743	114	042104	040440	EM111:	.ASCII	/LDD AC/
5260	051751	066	040454	030103	EM111X:	.ASCIZ	/6,ACO DIDN'T TRAP (ILLEGAL FSRC AC)./
5261	052016	042101	042104	040440	EM112:	.ASCII	/ADD AC/
5262	052025	066	040454	030103	EM112X:	.ASCIZ	/6,ACO DIDN'T TRAP (ILLEGAL FSRC AC)./
5263	052072	050106	020123	047111	EM113:	.ASCIZ	'FPS INCORRECT AFTER ILLEGAL AC TRAP.'
5264	052137	106	041505	044440	EM114:	.ASCIZ	'FEC INCORRECT AFTER ILLEGAL AC TRAP.'
5265	052204	046111	042514	040507	EM115:	.ASCIZ	'ILLEGAL AC REFERENCE TRAPPED TO 4 INSTEAD OF 244.'
5266							
5267	052266	052123	020137	041501	EM121:	.ASCII	'ST_ACO,AC1 TRAPPED TO 4.'<CRLF>
5268	052320	041050	052125	043040		.ASCIZ	'(BUT FDST) FORK FAILED IN FDST FLOW.'
5269	052365	123	057524	040440	EM122:	.ASCII	'ST_ACO,AC1 DATA FORMAT INCORRECT.'<CRLF>
5270	052430	041050	052125	043040		.ASCIZ	'(BUT FD) FORK FAILED IN FDST FLOW.'
5271	052473	123	057524	040440	EM123:	.ASCII	'ST_ACO,AC1 TRANSFERRED BAD DATA.'
5272							
5273	052535	106	051520	044440	EM125:	.ASCII	'FPS INCORRECT AFTER LDD (RO),ACO.'<CRLF>
5274	052577	050	052502	020124		.ASCIZ	'(BUT FZ) OR (BUT FN) FLOW FAILED.'
5275	052641	125	042116	043105	EM126:	.ASCII	'UNDEFINED VARIABLE (-O) TRAP DID NOT OCCUR.'
5276	052714	040600	030103	036440		.ASCIZ	<CRLF>'ACO = -O AND FIUV = 1 (INT ENABLED).'
5277	052762	047125	042504	044506	EM127:	.ASCII	'UNDEFINED VARIABLE (-O) TRAPPED TO 244.'
5278	053031	200	041501	020060		.ASCIZ	<CRLF>'ACO = -O AND FIUV = 0 (INT DISABLED).'
5279	053100	042506	020103	047111	EM130:	.ASCIZ	'FEC INCORRECT AFTER FIUV (-O) TRAP.'
5280							
5281	053144	042522	052523	052114	EM140:	.ASCII	'RESULT AND/OR STATUS INCORRECT ON ADD'
5282	053211	104	024040	030122	EM140X:	.ASCIZ	'D (RO),ACO.'
5283	053225	122	051505	046125	EM141:	.ASCII	'RESULT AND/OR STATUS INCORRECT ON SUB'
5284	053272	020104	051050	024460	EM141X:	.ASCIZ	'D (RO),ACO.'
5285							
5286	053306	052523	020115	047111	EM145:	.ASCIZ	'SUM INCORRECT ON ADD (RO),ACO.'
5287	053345	101	042104	020104	EM146:	.ASCIZ	'ADD (RO),ACO FAILED TO TRUNCATE (FT - 1).'
5288	053420	042101	057504	024040	EM147:	.ASCIZ	'ADD (RO),ACO FAILED TO ROUND (FT - 0).'
5289	053470	042101	042104	024040	EM150:	.ASCIZ	'ADD (RO),ACO ROUNDED IN F MODE.'
5290	053531	101	042104	020106	EM151:	.ASCIZ	'ADD (RO),ACO ROUNDED IN D MODE.'
5291	053572	052523	020115	047111	EM152:	.ASCII	'SUM INCORRECT ON ADD'
5292	053616	020104	051050	024460	EM152X:	.ASCII	'D (RO),ACO.'<CRLF>
5293	053632	051120	041117	041101		.ASCIZ	'PROBABLE FAULT IN (FDST) EXPONENT ALIGNMENT FLOW.'
5294	053714	052523	020115	047111	EM153:	.ASCII	'SUM INCORRECT ON ADD'
5295	053740	020104	051050	024460	EM153X:	.ASCII	'D (RO),ACO.'<CRLF>
5296	053754	051120	041117	041101		.ASCIZ	'PROBABLE FAULT IN (FSRC) EXPONENT ALIGNMENT FLOW.'
5297	054036	052523	020115	047111	EM154:	.ASCIZ	'SUM INCORRECT ON ADD (RO),ACO.'
5298	054076	044504	043106	051105	EM155:	.ASCIZ	'DIFFERENCE INCORRECT ON SUBD (RO),ACO.'
5299	054145	122	051505	046125	EM156:	.ASCII	'RESULT INCORRECT AFTER '

```

5300 054174 042101 042104 024040 EM156X: .ASCII 'ADDD (RO),ACO.'<CR LF>
5301 054213      120 047522 040502 .ASCIZ 'PROBABLE FAULT IN NORMALIZE FLOW.'
5302
5303 : THE REST OF THESE WERE FORMALLY IN PART 2 (OF 3).
5304
5305 054255      123 046525 047440 EM160: .ASCII 'SUM OR STATUS INCORRECT ON ADDD (RO),ACO.'
5306 054326 050200 047522 040502 .ASCIZ <CR LF>'PROBABLE FAULT IN ROUND/TRUNCATE FLOW.'
5307 054376 052523 020115 051117 EM162: .ASCIZ 'SUM OR FPS INCORRECT ON FORCED OVERFLOW.'
5308 054447      106 051117 042503 EM163: .ASCIZ 'FORCED OVERFLOW ON ADDD TRAPPED (FIV = 0).'
5309 054522 047506 041522 042105 EM164: .ASCIZ 'FORCED OVERFLOW ON ADDD DID NOT TRAP (FIV = 1).'
5310 054602 050106 020123 051117 EM165: .ASCIZ 'FPS OR FEC INCORRECT ON ADDD OVERFLOW TRAP.'
5311 054656 052523 020115 051117 EM166: .ASCIZ 'SUM OR FPS INCORRECT ON FORCED UNDERFLOW.'
5312 054730 047506 041522 042105 EM167: .ASCIZ 'FORCED UNDERFLOW ON ADDD TRAPPED (FIU = 0).'
5313 055004 047506 041522 042105 EM170: .ASCIZ 'FORCED UNDERFLOW ON ADDD DID NOT TRAP (FIU = 1).'
5314 055065      106 051520 047440 EM171: .ASCIZ 'FPS OR FEC INCORRECT ON ADDD UNDERFLOW TRAP.'
5315 055142 030122 044440 041516 EM172: .ASCII 'RO INCORRECT AFTER LDC'<177>
5316      055170      .=-1
5317      .EVEN
5318 055170 042106 024040 030122 EM172X: .ASCIZ 'FD (RO)+,ACO.'
5319 055206 040504 040524 044440 EM173: .ASCII 'DATA INCORRECT AFTER LDC'<177>
5320      .=-1
5321      .EVEN
5322 055236 042106 024040 030122 EM173X: .ASCIZ 'FD (RO)+,ACO.'
5323
5324 055254 050106 020123 047111 EM201: .ASCII 'FPS INCORRECT AFTER CMPD (RO),ACO '
5325 055316 044527 044124 024040 .ASCIZ 'WITH (FSRC)'<177>
5326      .=-1
5327      .EVEN
5328 055332 036440 024040 041501 EM201X: .ASCIZ ' - (AC).'
5329 055343      101 030103 053440 EM202: .ASCIZ 'ACO WAS ALTERED BY CMPD (RO),ACO.'
5330 055405      106 051520 047440 EM203: .ASCIZ 'FPS OR FEC INCORRECT AFTER DIVIDE BY 0 ERROR.'
5331 055463      104 053111 042111 EM204: .ASCIZ 'DIVIDE BY 0 ERROR FAILED TO TRAP (FID = 0).'
5332 055537      104 053111 042111 EM205: .ASCIZ 'DIVIDE BY 0 ERROR TRAPPED WITH FID = 1.'
5333 055607      122 051505 046125 EM206: .ASCIZ 'RESULT OR FPS INCORRECT AFTER DIVF (RO),ACO.'
5334 055664 042522 052523 052114 EM207: .ASCIZ 'RESULT OR FPS INCORRECT AFTER DIVD (RO),ACO.'
5335 055740 026400 020055 047506 EM207X: .ASCIZ '<0>'-- FORCED OVER\UNDERFLOW.'
5336 055773      122 051505 046125 EM210: .ASCIZ 'RESULT OR FPS INCORRECT AFTER MULF (RO),ACO.'
5337 056050 042522 052523 052114 EM211: .ASCII 'RESULT OR FPS INCORRECT AFTER MULD (RO),ACO.'
5338 056124 026400 020055 047506 EM211X: .ASCIZ '<0>'-- FORCED OVER\UNDERFLOW.'
5339
5340 056157      122 051505 046125 EM220: .ASCIZ 'RESULTS OR FPS INCORRECT ON MODF (RO),ACO.'
5341 056232 042522 052523 052114 EM221: .ASCII 'RESULTS OR FPS INCORRECT ON MODD (RO),ACO.'
5342 056304 026400 020055 047506 EM221X: .ASCIZ '<0>'-- FORCED OVER\UNDERFLOW.'
5343      056340      .EVEN
5344
5345 : DATA HEADERS
5346
5347 056340 042524 052123 004456 DH1: .ASCII 'TEST.'<TAB>'CALL PC.'<TAB>'ERROR PC.'
5348 056370 053411 047522 042524 .ASCIZ <TAB>'WROTE.'<TAB>'READ.'<TAB>'EXPECTED.'
5349 056420 042524 052123 004456 DH2: .ASCII 'TEST.'<TAB>'CALL PC.'<TAB>'ERR COUNT'
5350 056450 041011 042101 042040 .ASCIZ <TAB>'BAD DATA (AND)'<TAB>'BAD DATA (OR)'
5351 056506 042524 052123 004456 DH3: .ASCII 'TEST.'<TAB>'CALL PC.'<TAB>'ERROR PC.'
5352 056536 051011 040505 020104 .ASCIZ <TAB>'READ PSW.'<TAB>'EXPECTED PSW.'
5353 056567      124 051505 027124 DH4: .ASCII 'TEST.'<TAB>'CALL PC.'<TAB>'ERROR PC.'
5354 056617      011 051127 052117 .ASCIZ <TAB>'WROTE FPS.'<TAB>'FPS AFTER CFCC.'
5355 056653      124 051505 027124 DH5: .ASCII 'TEST.'<TAB>'CALL PC.'<TAB>'TRAP PC.'

```

```

5356 056702 020011 050106 004523 .ASCIZ <TAB>'FPS'<TAB><TAB>'FEC'
5357 056716 042524 052123 004456 DH6: .ASCIZ 'TEST.'<TAB>'CALL PC.'<TAB>'TRAP PC.'
5358 056716 DH7=DH6
5359
5360 056746 042524 052123 004456 DH12: .ASCII 'TEST.'<TAB>'CALL PC.'<TAB>'ERROR PC.'
5361 056776 051011 040505 020104 .ASCIZ <TAB>'READ FPS.'<TAB>'EXPECTED FPS.'
5362
5363 057027 124 051505 027124 DH16: .ASCII 'TEST.'<TAB>'CALL PC.'<TAB>'ERROR PC.'
5364 057057 011 050117 041440 .ASCIZ <TAB>'OP CODE.'<TAB>'FPS.'
5365 056746 DH17=DH12
5366 057077 124 051505 027124 DH20: .ASCII 'TEST.'<TAB>'CALL PC.'<TAB>'ERROR PC.'
5367 057127 011 042522 042101 .ASCIZ <TAB>'READ FEC'<TAB>'EXPECTED FEC'
5368
5369 056746 DH22=DH12
5370 057077 DH23=DH20
5371 057027 DH24=DH16
5372 057156 042524 052123 004456 DH25: .ASCII 'TEST.'<TAB>'CALL PC.'<TAB>'ERROR PC.'
5373 057206 020011 051050 024460 .ASCIZ <TAB>'(R0)'
5374 057156 DH26=DH25
5375
5376 057156 DH31=DH25
5377
5378 057156 DH34=DH25
5379 057156 DH35=DH25
5380 057156 DH36=DH25
5381 057156 DH37=DH25
5382 057156 DH40=DH25
5383 056746 DH41=DH12
5384 057156 DH42=DH25
5385 057156 DH43=DH25
5386 057215 124 051505 027124 DH44: .ASCIZ 'TEST.'<TAB>'CALL PC.'<TAB>'ERROR PC.'
5387
5388 057215 DH46=DH44
5389 057215 DH47=DH44
5390 057215 DH50=DH44
5391 057215 DH51=DH44
5392 057156 DH52=DH25
5393 057156 DH53=DH25
5394 057156 DH54=DH25
5395 057156 DH55=DH25
5396 057156 DH56=DH25
5397 057156 DH57=DH25
5398 057156 DH60=DH25
5399 057156 DH61=DH25
5400 057156 DH62=DH25
5401 057215 DH63=DH44
5402 057246 042524 052123 004456 DH64: .ASCII 'TEST.'<TAB>'CALL PC.'<TAB>'ERROR PC.'
5403 057276 051011 040505 020104 .ASCIZ <TAB>'READ PC'<TAB>'EXPECTED PC'
5404 057215 DH65=DH44
5405 057215 DH66=DH44
5406 057156 DH67=DH25
5407 057156 DH70=DH25
5408 057156 DH71=DH25
5409 057156 DH72=DH25
5410 057156 DH73=DH25
5411 057156 DH74=DH25

```

5412	057156			DH75=DH25
5413	057156			DH76=DH25
5414	057156			DH77=DH25
5415	057156			DH100=DH25
5416	057156			DH101=DH25
5417	057156			DH102=DH25
5418	057156			DH103=DH25
5419	057156			DH104=DH25
5420	057156			DH105=DH25
5421	057156			DH106=DH25
5422	057156			DH107=DH25
5423	057156			DH110=DH25
5424	057215			DH111=DH44
5425	057215			DH112=DH44
5426	056746			DH113=DH12
5427	057077			DH114=DH20
5428	056716			DH115=DH6
5429				
5430	057215			DH121=DH44
5431	057215			DH122=DH44
5432	057215			DH123=DH44
5433				
5434	056746			DH125=DH12
5435	057215			DH126=DH44
5436	057215			DH127=DH44
5437	057077			DH130=DH20
5438				
5439	056746			DH140=DH12
5440	056746			DH141=DH12
5441				
5442	057324	042524	052123 004456	DH145: .ASCII 'TEST.' <tab>'CALL PC.'<tab>'ERROR PC.'</tab></tab>
5443	057354	020011	050106 000123	.ASCIIZ <TAB>'FPS'
5444	057324			DH146=DH145
5445	057324			DH147=DH145
5446	057324			DH150=DH145
5447	057324			DH151=DH145
5448	057324			DH152=DH145
5449	057324			DH153=DH145
5450	057324			DH154=DH145
5451	057324			DH155=DH145
5452	057324			DH156=DH145
5453				
5454	056746			DH160=DH12
5455	056746			DH162=DH12
5456	056746			DH163=DH12
5457	056746			DH164=DH12
5458	056716			DH165=DH6
5459	056746			DH166=DH12
5460	056746			DH167=DH12
5461	056746			DH170=DH12
5462	056716			DH171=DH6
5463	057156			DH172=DH25
5464	057324			DH173=DH145
5465				
5466	056746			DH201=DH12
5467	056746			DH202=DH12

```

5468      057215      DH203=DH44
5469 057362 042524 052123 004456 DH204: .ASCII 'TEST.'

```


5524	057734				DT55=DT52	
5525	057532				DT56=DT26	
5526	057554				DT57=DT34	
5527	057532				DT60=DT26	
5528	057554				DT61=DT34	
5529	057554				DT62=DT34	
5530	057712				DT63=DT50	
5531	057450				DT64=DT2	
5532	057472				DT65=DT6	
5533	057712				DT66=DT50	
5534	057734				DT67=DT52	
5535	057734				DT70=DT52	
5536	057554				DT71=DT34	
5537	057532				DT72=DT26	
5538	057554				DT73=DT34	
5539	057734				DT74=DT52	
5540	057734				DT75=DT52	
5541	057554				DT76=DT34	
5542	057532				DT77=DT26	
5543	057554				DT100=DT34	
5544	057734				DT101=DT52	
5545	057532				DT102=DT26	
5546	057554				DT103=DT34	
5547	057554				DT104=DT34	
5548	057734				DT105=DT52	
5549	057532				DT106=DT26	
5550	057554				DT107=DT34	
5551	057554				DT110=DT34	
5552	057472				DT111=DT6	
5553	057472				DT112=DT6	
5554	057450				DT113=DT2	
5555	057450				DT114=DT2	
5556	057472				DT115=DT6	
5557						
5558	057472				DT121=DT6	
5559	057712				DT122=DT50	
5560	057712				DT123=DT50	
5561						
5562	057752	001160	001162	043302	DT125: .WORD	\$TMP0,\$TMP1,HTAB,\$TMP2,HTAB,\$TMP3,HTAB,\$TMP4,ACZ,\$TMP5,0
5563					DT126=DT6	
5564					DT127=DT6	
5565					DT130=DT125	
5566						
5567	060000	001160	001162	043302	DT140: .WORD	\$TMP0,\$TMP1,HTAB,\$TMP2,HTAB,\$TMP3,HTAB,\$TMP4
5568	060020	044037	001172	044020	.WORD	SOPR,\$TMP5,ACOPR,\$TMP6,ERES,\$TMP7,RRES,\$TMP10,0
5569		060000			DT141=DT140	
5570						
5571	060042	001160	001162	043302	DT145: .WORD	\$TMP0,\$TMP1,HTAB,\$TMP2,HTAB,\$TMP3,SOPR,\$TMP4
5572	060062	044020	001172	043666	.WORD	ACOPR,\$TMP5,ERES,\$TMP6,RRES,\$TMP7,0
5573		060042			DT146=DT145	
5574		060042			DT147=DT145	
5575		060042			DT150=DT145	
5576		060042			DT151=DT145	
5577		060042			DT152=DT145	
5578		060042			DT153=DT145	
5579		060042			DT154=DT145	

5580		060042			DT155=DT145	
5581		060042			DT156=DT145	
5582						
5583		060000			DT160=DT140	
5584		060000			DT162=DT140	
5585		060000			DT163=DT140	
5586		060000			DT164=DT140	
5587	060100	001160	001162	043302	DT165: .WORD	\$TMP0,\$TMP1,HTAB,\$TMP2,ESTAT,\$TMP3,\$TMP4,RSTAT,\$TMP5,\$TMP6,0
5588		060000			DT166=DT140	
5589		060000			DT167=DT140	
5590		060000			DT170=DT140	
5591		060100			DT171=DT165	
5592		057532			DT172=DT26	
5593	060126	001160	001162	043302	DT173: .WORD	\$TMP0,\$TMP1,HTAB,\$TMP2,HTAB,\$TMP3,SRC,\$TMP4
5594	060146	043547	001172	043563	.WORD	EXP,\$TMP5,RCD,\$TMP6,0
5595						
5596	060160	001160	001162	043302	DT201: .WORD	\$TMP0,\$TMP1,HTAB,\$TMP2,HTAB,\$TMP3,HTAB,\$TMP4
5597	060200	044037	001172	044020	.WORD	SOPR,\$TMP5,ACOPR,\$TMP6,0
5598	060212	001160	001162	043302	DT202: .WORD	\$TMP0,\$TMP1,HTAB,\$TMP2,HTAB,\$TMP3,HTAB,\$TMP4
5599	060232	044075	001172	044113	.WORD	ACOB,\$TMP5,ACOA,\$TMP6,0
5600	060244	001160	001162	043302	DT203: .WORD	\$TMP0,\$TMP1,HTAB,\$TMP2,ESTAT,\$TMP3,RSTAT,\$TMP4,0
5601	060266	001160	001162	043302	DT204: .WORD	\$TMP0,\$TMP1,HTAB,\$TMP2,HTAB,\$TMP7,HTAB,\$TMP10,0
5602		060266			DT205=DT204	
5603	060310	001160	001162	043302	DT206: .WORD	\$TMP0,\$TMP1,HTAB,\$TMP2,HTAB,\$TMP3,HTAB,\$TMP4
5604	060330	044020	001172	044037	.WORD	ACOPR,\$TMP5,SOPR,\$TMP6,ERES,\$TMP7,RRES,\$TMP10,0
5605		060310			DT207=DT206	
5606		060310			DT210=DT206	
5607		060310			DT211=DT206	
5608						
5609	060352	001160	001162	043302	DT220: .WORD	\$TMP0,\$TMP1,HTAB,\$TMP2,HTAB,\$TMP3,HTAB,\$TMP4
5610	060372	044020	001172	044037	.WORD	ACOPR,\$TMP5,SOPR,\$TMP6,EFRAC,\$TMP7,RFRAC,\$TMP10
5611	060412	044207	001202	044236	.WORD	EINT,\$TMP11,RINT,\$TMP12,0
5612		060352			DT221=DT220	
5613					.EVEN	
5614					:	
5615					: AND FINALLY, THE FORMAT CODES.	
5616					:	
5617	060424	004	000	005	DF1: .BYTE	4,0,5,0,5,0,0,0
5618	060434	004	000	005	DF2: .BYTE	4,0,5,4,5,0,5,0
5619	060444	004	000	005	DF3: .BYTE	4,0,5,0,5,0,5,0
5620		060444			DF4=DF3	
5621		060444			DF5=DF3	
5622	060454	004	000	005	DF6: .BYTE	4,0,5,0
5623		060454			DF7=DF6	
5624						
5625		060444			DF12=DF3	
5626						
5627		060444			DF16=DF3	
5628		060444			DF17=DF3	
5629		060444			DF20 DF3	
5630						
5631		060444			DF22=DF3	
5632		060444			DF23=DF3	
5633		060444			DF24=DF3	
5634	060460	004	000	005	DF25: .BYTE	4,0,5,0,5,0,5,3,5,3
5635		060444			DF26=DF3	

5636						
5637	060444				DF31=DF3	
5638						
5639	060460				DF34=DF25	
5640	060460				DF35=DF25	
5641	060460				DF36=DF25	
5642	060460				DF37=DF25	
5643	060460				DF40=DF25	
5644	060444				DF41=DF3	
5645	060444				DF42=DF3	
5646	060444				DF43=DF3	
5647	060472	004	000	005	DF44: .BYTE	4,0,5,0,5,3,5,3
5648						
5649	060502	004	000	005	DF46: .BYTE	4,0,5,0,5,5,3,5,3,5,3,5,3,5,3,5,3,5,3,5,5,3,5,3,5,3,5,3,5,3
5650	060454				DF47=DF6	
5651	060472				DF50=DF44	
5652	060472				DF51=DF44	
5653	060534	004	000	005	DF52: .BYTE	4,0,5,0,5,0
5654	060444				DF53=DF3	
5655	060460				DF54=DF25	
5656	060534				DF55=DF52	
5657	060444				DF56=DF3	
5658	060460				DF57=DF25	
5659	060444				DF60=DF3	
5660	060460				DF61=DF25	
5661	060460				DF62=DF25	
5662	060472				DF63=DF44	
5663	060444				DF64=DF3	
5664	060454				DF65=DF6	
5665	060472				DF66=DF44	
5666	060534				DF67=DF52	
5667	060534				DF70=DF52	
5668	060460				DF71=DF25	
5669	060444				DF72=DF3	
5670	060460				DF73=DF25	
5671	060534				DF74=DF52	
5672	060534				DF75=DF52	
5673	060460				DF76=DF25	
5674	060444				DF77=DF3	
5675	060460				DF100=DF25	
5676	060534				DF101=DF52	
5677	060444				DF102=DF3	
5678	060460				DF103=DF25	
5679	060460				DF104=DF25	
5680	060534				DF105=DF52	
5681	060444				DF106=DF3	
5682	060460				DF107=DF25	
5683	060460				DF110=DF25	
5684	060454				DF111=DF6	
5685	060454				DF112=DF6	
5686	060444				DF113=DF3	
5687	060444				DF114=DF3	
5688	060454				DF115=DF6	
5689						
5690	060454				DF121=DF6	
5691	060472				DF122=DF44	

5692	060472				DF123=DF44	
5693						
5694	060542	004	000	005	DF125: .BYTE	4,0,5,0,5,0,5,0,5,3
5695		060454			DF126=DF6	
5696		060454			DF127=DF6	
5697		060542			DF130=DF125	
5698						
5699	060554	004	000	005	DF140: .BYTE	4,0,5,0,5,0,5,0,5,3,5,3,5,3,5,3
5700		060554			DF141=DF140	
5701						
5702	060574	004	000	005	DF145: .BYTE	4,0,5,0,5,0,5,3,5,3,5,3,5,3
5703		060574			DF146=DF145	
5704		060574			DF147=DF145	
5705		060574			DF150=DF145	
5706		060574			DF151=DF145	
5707		060574			DF152=DF145	
5708		060574			DF153=DF145	
5709		060574			DF154=DF145	
5710		060574			DF155=DF145	
5711		060574			DF156=DF145	
5712						
5713		060554			DF160=DF140	
5714		060554			DF162=DF140	
5715		060554			DF163=DF140	
5716		060554			DF164=DF140	
5717	060612	004	000	005	DF165: .BYTE	4,0,5,0,5,0,0,5,0,0
5718		060554			DF166=DF140	
5719		060554			DF167=DF140	
5720		060554			DF170=DF140	
5721		060612			DF171=DF165	
5722		060444			DF172=DF3	
5723	060624	004	000	005	DF173: .BYTE	4,0,5,0,5,0,5,3,5,3,5,3
5724						
5725	060640	004	000	005	DF201: .BYTE	4,0,5,0,5,0,5,0,5,3,5,3
5726		060640			DF202=DF201	
5727	060654	004	000	005	DF203: .BYTE	4,0,5,0,5,2,5,2
5728		060444			DF204=DF3	
5729		060444			DF205=DF3	
5730	060664	004	000	005	DF206: .BYTE	4,0,5,0,5,0,5,0,5,2,5,2,5,2,5,2
5731	060704	004	000	005	DF207: .BYTE	4,0,5,0,5,0,5,0,5,3,5,3,5,3,5,3
5732		060664			DF210=DF206	
5733		060704			DF211=DF207	
5734						
5735	060724	004	000	005	DF220: .BYTE	4,0,5,0,5,0,5,0,5,2,5,2,5,2,5,2,5,2
5736	060750	004	000	005	DF221: .BYTE	4,0,5,0,5,0,5,0,5,3,5,3,5,3,5,3,5,3
5737					.EVEN	

5739
5740
5741
5742
5743
5744 060774 000240
5745 060776 000240
5746 061000 000240
5747 061002 000544
5748 061004 000144
5749 061314 042777 000200 117616 1\$:
5750 061322 104401 061330
(1) 061326 000420
(1)
(1) 061370
5751 061370 000207
5752
5753
5754 061372
5755 000001

```
.SBTTL AREA RESERVED FOR LOGIC ANALYZER SET-UP CODE (NOT INCLUDED).  
://///////  
: FOR FUTURE EXPANSION, LOGIC ANALYZER SET UP CODE MAY BE PLACED HERE.  
: CALLED AT END OF $SCOPE ROUTINE IF SWR<8:7> ARE BOTH SET.  
:  
ANALYZE: NOP ;  
NOP ; SETUP CODE CAN GO HERE.  
NOP ;  
BR 1$ ; BUT, SINCE WE HAVE NONE...  
;...JUST CLEAR THE "ANALYZE" BIT...  
.BLKW 100. ;...AND SAY SO.  
BIC #SW7,@SWR ; TYPE ASCIZ STRING  
TYPE ,65$ ; GET OVER THE ASCIZ  
BR 64$ ;  
::65$: .ASCIZ 'ANALYZER SET-UP NOT INSTALLED'<CRLF>  
64$:  
RTS PC  
:  
://///////  
LASTAD= .  
.END
```

AADONE 020056	AFATAL= 000000	BB16 021526	CCP4 021004	DD7 022432
AAOP0 017766	AI 044337	BB17 021560	CCP5 021014	DD8 022466
AAOP1 017776	AMADR1= 000000	BB2 021144	CCP6 021024	DF1 060424
AAOP2 020006	AMADR2= 000000	BB20 021630	CCP7 021034	DF100 = 060460
AAOP3 020016	AMADR3= 000000	BB21 021666	CCSUM 020734	DF101 = 060534
AAOP4 020026	AMADR4= 000000	BB26 021736	CC1 020064	DF102 = 060444
AAOP5 020036	AMAMS1= 000000	BB27 022000	CC13 020276	DF103 = 060460
AAOP6 020046	AMAMS2= 000000	BB3 021212	CC14 020342	DF104 = 060460
AASUM 017756	AMAMS3= 000000	BB32 022046	CC19 020412	DF105 = 060534
AA1 017326	AMAMS4= 000000	BB33 022102	CC2 020126	DF106 = 060444
AA10 017460	AMSGAD= 000000	BB4 021242	CC20 020450	DF107 = 060460
AA11 017520	AMSGLG= 000000	BB6 021310	CC25 020520	DF110 = 060460
AA2 017400	AMSGTY= 000000	BB7 021344	CC26 020562	DF111 = 060454
AA20 017616	AMTYP1= 000000	BDONE 004652	CC31 020630	DF112 = 060454
AA21 017662	AMTYP2= 000000	BI 044314	CC32 020664	DF113 = 060444
ABASE = 000000	AMTYP3= 000000	BIT0 = 000001	CC7 020174	DF114 = 060444
ABORT 043341	AMTYP4= 000000	BIT00 = 000001	CC8 020230	DF115 = 060454
ACDW1 = 000000	ANALYZ 060774	BIT01 = 000002	CDONE 005130	DF12 = 060444
ACDW2 = 000000	APASS = 000000	BIT02 = 000004	CHECK2 004302	DF121 = 060454
ACOPR 044020	APRIOR= 000000	BIT03 = 000010	CHECK4 004312	DF122 = 060472
ACPUOP= 000000	APTCU= 000040	BIT04 = 000020	CKSWR = 104407	DF123 = 060472
ACZ 043657	APTENV= 000001	BIT05 = 000040	CLRFPS= 104412	DF125 = 060542
ACO = %000000	APTSIZ= 000200	BIT06 = 000100	CR = 000015	DF126 = 060454
ACCA 044113	APTSPO= 000100	BIT07 = 000200	CRLF = 000200	DF127 = 060454
ACOB 044075	ARZ 043503	BIT08 = 000400	C1 005022	DF130 = 060542
AC1 = %000001	ASRC 043453	BIT09 = 001000	C15 005036	DF140 = 060554
AC2 = %000002	ASWREG= 000000	BIT1 - 000002	C25 005076	DF141 = 060554
AC3 = %000003	ATESTN= 000000	BIT10 = 002000	DDDONE 023334	DF145 = 060574
AC4 = %000004	AUNIT = 000000	BIT11 = 004000	DDISP = 177570	DF146 = 060574
AC5 = %000005	AUSWR = 000000	BIT12 = 010000	DDONE 005316	DF147 = 060574
AC6 = %000006	AVECT1 000000	BIT13 = 020000	DDP0 023214	DF150 = 060574
AC7 = %000007	AVECT2= 000000	BIT14 = 040000	DDP1 023224	DF151 = 060574
ADDW0 = 000000	A1 004404	BIT15 = 100000	DDP2 023234	DF152 = 060574
ADDW1 = 000000	A2 004406	BIT2 = 000004	DDP3 023244	DF153 = 060574
ADDW10= 000000	A3 004520	BIT3 = 000010	DDP4 023254	DF154 = 060574
ADDW11= 000000	A4 004526	BIT4 = 000020	DDP5 023264	DF155 = 060574
ADDW12= 000000	BBDONE 022322	BIT5 = 000040	DDP6 023274	DF156 = 060574
ADDW13= 000000	BBP0 022162	BIT6 = 000100	DDP7 023304	DF16 = 060444
ADDW14= 000000	BBP0A 022172	BIT7 = 000200	DDP8 023314	DF160 = 060554
ADDW15 000000	BBP1 022202	BIT8 = 000400	DDP9 023324	DF162 = 060554
ADDW2 = 000000	BBP10 022272	BIT9 = 001000	DDSUM 023204	DF163 = 060554
ADDW3 = 000000	BBP11 022302	BPTVEC= 000014	DD1 022330	DF164 = 060554
ADDW4 = 000000	BBP12 022312	BSRC 043423	DD12 022526	DF165 = 060612
ADDW5 = 000000	BBP2 022212	B1 004556	DD13 022562	DF166 = 060554
ADDW6 = 000000	BBP2A 022222	B2 004600	DD16 022622	DF167 = 060554
ADDW7 = 000000	BBP3 022232	CCDONE 021074	DD17 022656	DF17 = 060444
ADDW8 = 000000	BBP4 022242	CCP0 020744	DD2 022372	DF170 = 060554
ADDW9 = 000000	BBP5 022252	CCP1 020754	DD22 022716	DF171 = 060612
ADE VCT= 000000	BBP7 022262	CCP10 021044	DD23 022752	DF172 = 060444
ADE VM = 000000	BBSUM 022152	CCP11 021054	DD30 023012	DF173 060624
ADONE 004534	BB1 021102	CCP12 021064	DD31 023046	DF2 060434
AENV 000000	BB14 021412	CCP2 020764	DD36 023106	DF20 = 060444
AENVM = 000000	BB15 021456	CCP3 020774	DD37 023142	DF201 060640

DF 202 = 060640	DF 75 = 060534	DH201 = 056746	DH74 = 057156	DT171 = 057100
DF 203 = 060654	DF 76 = 060460	DH202 = 056746	DH75 = 057156	DT172 = 057552
DF 204 = 060444	DF 77 = 060444	DH203 = 057215	DH76 = 057156	DT173 = 060126
DF 205 = 060444	DH1 = 056340	DH204 = 057362	DH77 = 057156	DT2 = 057450
DF 206 = 060664	DH100 = 057156	DH205 = 057362	DISPLA 001142	DT20 = 057450
DF 207 = 060704	DH101 = 057156	DH206 = 056746	DISPRE 000174	DT201 = 060160
DF 210 = 060664	DH102 = 057156	DH207 = 056746	CJPR 044056	DT202 = 060212
DF 211 = 060704	DH103 = 057156	DH210 = 056746	DSWR 177570	DT203 = 060244
DF 22 = 060444	DH104 = 057156	DH211 = 056746	DT1 = 057426	DT204 = 060266
DF 220 = 060724	DH105 = 057156	DH22 = 056746	DT100 = 057554	DT205 = 060266
DF 221 = 060750	DH106 = 057156	DH220 = 056746	DT101 = 057734	DT206 = 060310
DF 23 = 060444	DH107 = 057156	DH221 = 056746	DT102 = 057532	DT207 = 060310
DF 24 = 060444	DH110 = 057156	DH23 = 057077	DT103 = 057554	DT210 = 060310
DF 25 = 060460	DH111 = 057215	DH24 = 057027	DT104 = 057554	DT211 = 060310
DF 26 = 060444	DH112 = 057215	DH25 = 057156	DT105 = 057734	DT22 = 057450
DF 3 = 060444	DH113 = 056746	DH26 = 057156	DT106 = 057532	DT220 = 060352
DF 31 = 060444	DH114 = 057077	DH3 = 056506	DT107 = 057554	DT221 = 060352
DF 34 = 060460	DH115 = 056716	DH31 = 057156	DT110 = 057554	DT23 = 057450
DF 35 = 060460	DH12 = 056746	DH34 = 057156	DT111 = 057472	DT24 = 057450
DF 36 = 060460	DH121 = 057215	DH35 = 057156	DT112 = 057472	DT25 = 057504
DF 37 = 060460	DH122 = 057215	DH36 = 057156	DT113 = 057450	DT26 = 057532
DF 4 = 060444	DH123 = 057215	DH37 = 057156	DT114 = 057450	DT3 = 057450
DF 40 = 060460	DH125 = 056746	DH4 = 056567	DT115 = 057472	DT31 = 057532
DF 41 = 060444	DH126 = 057215	DH40 = 057156	DT12 = 057450	DT34 = 057554
DF 42 = 060444	DH127 = 057215	DH41 = 056746	DT121 = 057472	DT35 = 057554
DF 43 = 060444	DH130 = 057077	DH42 = 057156	DT122 = 057712	DT36 = 057554
DF 44 = 060472	DH140 = 056746	DH43 = 057156	DT123 = 057712	DT37 = 057554
DF 46 = 060502	DH141 = 056746	DH44 = 057215	DT125 = 057752	DT4 = 057450
DF 47 = 060454	DH145 = 057324	DH46 = 057215	DT126 = 057472	DT40 = 057554
DF 5 = 060444	DH146 = 057324	DH47 = 057215	DT127 = 057472	DT41 = 057450
DF 50 = 060472	DH147 = 057324	DH5 = 056653	DT130 = 057752	DT42 = 057532
DF 51 = 060472	DH150 = 057324	DH50 = 057215	DT140 = 060000	DT43 = 057532
DF 52 = 060534	DH151 = 057324	DH51 = 057215	DT141 = 060000	DT44 = 057602
DF 53 = 060444	DH152 = 057324	DH52 = 057156	DT145 = 060042	DT46 = 057624
DF 54 = 060460	DH153 = 057324	DH53 = 057156	DT146 = 060042	DT47 = 057472
DF 55 = 060534	DH154 = 057324	DH54 = 057156	DT147 = 060042	DT5 = 057450
DF 56 = 060444	DH155 = 057324	DH55 = 057156	DT150 = 060042	DT50 = 057712
DF 57 = 060460	DH156 = 057324	DH56 = 057156	DT151 = 060042	DT51 = 057712
DF 6 = 060454	DH16 = 057027	DH57 = 057156	DT152 = 060042	DT52 = 057734
DF 60 = 060444	DH160 = 056746	DH6 = 056716	DT153 = 060042	DT53 = 057532
DF 61 = 060460	DH162 = 056746	DH60 = 057156	DT154 = 060042	DT54 = 057554
DF 62 = 060460	DH163 = 056746	DH61 = 057156	DT155 = 060042	DT55 = 057734
DF 63 = 060472	DH164 = 056746	DH62 = 057156	DT156 = 060042	DT56 = 057532
DF 64 = 060444	DH165 = 056716	DH63 = 057215	DT16 = 057450	DT57 = 057554
DF 65 = 060454	DH166 = 056746	DH64 = 057246	DT160 = 060000	DT6 = 057472
DF 66 = 060472	DH167 = 056746	DH65 = 057215	DT162 = 060000	DT60 = 057532
DF 67 = 060534	DH17 = 056746	DH66 = 057215	DT163 = 060000	DT61 = 057554
DF 7 = 060454	DH170 = 056746	DH67 = 057156	DT164 = 060000	DT62 = 057554
DF 70 = 060534	DH171 = 056716	DH7 = 056716	DT165 = 060100	DT63 = 057712
DF 71 = 060460	DH172 = 057156	DH70 = 057156	DT166 = 060000	DT64 = 057450
DF 72 = 060444	DH173 = 057324	DH71 = 057156	DT167 = 060000	DT65 = 057472
DF 73 = 060460	DH2 = 056420	DH72 = 057156	DT17 = 057450	DT66 = 057712
DF 74 = 060534	DH20 = 057077	DH73 = 057156	DT170 = 060000	DT67 = 057734

DT7 = 057472	EM12X 044704	EM211X 056124	ERT1 043066	GGP1 026560
DT70 = 057734	EM121 052266	EM22 045105	ERT2 043252	GGP2 026570
DT71 = 057554	EM122 052365	EM220 056157	ERT3 043256	GGP3 026600
DT72 = 057532	EM123 052473	EM221 056232	ERT4 043262	GGP4 026610
DT73 = 057554	EM125 052535	EM221X 056304	ESTAT 043740	GGP6 026620
DT74 = 057734	EM126 052641	EM23 045170	EXP 043547	GGP7 026630
DT75 = 057734	EM127 052762	EM24 045253	E1 005334	GGSUM 026540
DT76 = 057554	EM130 053100	EM25 045333	E2 005354	GG1 025624
DT77 = 057532	EM140 053144	EM26 045403	E244 005432	GG2 026004
D1 005144	EM140X 053211	EM3 044450	FDATE0 006420	GG244 026526
D2 005174	EM141 053225	EM31 045506	FDATE11 006422	GG3 026172
D244 005242	EM141X 053272	EM34 045611	FDATE12 006424	GG4 026336
D3 005216	EM145 053306	EM35 045723	FDATE13 006426	GG5 026524
D4 005270	EM146 053345	EM36 046035	FDATE00 006440	GPAT 010546
EAC 043363	EM147 053420	EM37 046151	FDATE01 006442	GTSWR = 104406
EACN 043377	EM150 053470	EM4 044502	FDATE02 006444	G1 010052
EAC15 043577	EM151 053531	EM40 046265	FDATE03 006446	G2 010140
EDONE 005456	EM152 053572	EM41 046327	FDONE 006470	G3 010164
EEDIFF 023732	EM152X 053616	EM42 046376	FERR10 006220	G4 010204
EEDONE 024032	EM153 053714	EM43 046502	FERR20 006224	G5 010212
EEP1 023742	EM153X 053740	EM44 046606	FERR25 006316	HA1R 011272
EEP2 023752	EM154 054036	EM46 046645	FERR6 006100	HA1W 011222
EEP3 023762	EM155 054076	EM47 046717	FERR7 006150	HA2R 011302
EEP4 023772	EM156 054145	EM5 044534	FFDONE 024570	HA2W 011232
EEP5 024002	EM156X 054174	EM50 047016	FFP0 024500	HA3R 011312
EEP6 024012	EM16 044723	EM51 047124	FFP1 024510	HA3W 011242
EEP7 024022	EM160 054255	EM52 047166	FFP2 024520	HA4R 011322
EE1 023542	EM162 054376	EM53 047222	FFP3 024530	HA4W 011252
EE2 023444	EM163 054447	EM54 047264	FFP4 024540	HA5R 011332
EE3 023540	EM164 054522	EM55 047330	FFP5 024550	HA5W 011262
EE4 023634	EM165 054602	EM56 047364	FFP6 024560	HCLR 011204
EE5 023730	EM166 054656	EM57 047426	FFSUM 024470	HDATE1 011342
EFRAC 044131	EM167 054730	EM6 044570	FF1 024040	HDATE2 011352
EINT 044207	EM17 044763	EM60 047472	FF2 024162	HDATE3 011362
EMTVEC = 000030	EM170 055004	EM61 047534	FF3 024256	HDATE4 011372
EM1 044361	EM171 055065	EM62 047600	FF4 024372	HDATE5 011402
EM100 051015	EM172 055142	EM63 047716	FF5 024466	HDONE 011412
EM101 051062	EM172X 055170	EM64 050026	FPVEC = 000244	HHDONE 025616
EM102 051165	EM173 055206	EM65 050070	FXDATE0 006460	HHP0 025456
EM103 051231	EM173X 055236	EM66 050124	FXDATE1 006462	HHP1 025466
EM104 051340	EM2 044411	EM67 050170	FXDATE2 006464	HHP10 025576
EM105 051406	EM20 045034	EM7 044622	FXDATE3 006466	HHP11 025606
EM106 051512	EM201 055254	EM70 = 050170	F1 005464	HHP2 025476
EM107 051557	EM201X 055332	EM71 050273	F10 005746	HHP3 025506
EM110 051674	EM202 055343	EM72 050415	F11 005750	HHP4 025516
EM111 051743	EM203 055405	EM73 050460	F3 005536	HHP5 025526
EM111X 051751	EM204 055463	EM74 050525	F4 005540	HHP6 025536
EM112 052016	EM205 055537	EM75 = 050525	F6 005664	HHP7 025546
EM112X 052025	EM206 055607	EM76 050630	GDATE 010556	HHP8 025556
EM113 052072	EM207 055664	EM77 050752	GDONE 010566	HHP9 025566
EM114 052137	EM207X 055740	ERES 043666	GGDONE 026640	HHSUM 025446
EM115 052204	EM210 055773	ERRVEC = 000004	GGFEC 026536	HH1 024576
EM12 044655	EM211 056050	ERTYPE 042742	GGP0 026550	HH11 025046

MM12	025076	JJP1	027526	LASTAD=	061372	NERR4	013500	PP13	033310
MM17	025174	JJP2	027536	LASTEM=	000223	NWDONE	032722	PP14	033334
MM18	025224	JJP3	027546	LASTST=	000051	NNSUB	032542	PP2	032754
MM2	024626	JJP4	027556	LDATIO	012670	NNSUB1	032532	PP3	033000
MM21	025316	JJP5	027566	LDAT00	012700	NN1	031770	PP4	033024
MM22	025346	JJP6	027576	LDONE	012710	NN2	032030	PP5	033050
MM7	024720	JJP7	027606	LF =	000012	NN3	032070	PP6	033074
MM8	024750	JJP8	027616	LLDONE	031164	NN4	032130	PP7	033120
HSTOR	011060	J11	026646	LLP1	031144	NN5	032170	PP8	033144
HT =	000011	JJ17	027172	LLP2	031154	NN6	032230	PP9	033170
HTAB	043302	JJ18	027230	LL0	030514	NN7	032270	PRGS17=	000142
H1	010600	JJ2	026716	LL2	030646	NN8	032330	PRO =	000000
H3	010646	JJ21	027304	LL244	031116	NN9	032430	PR1 =	000040
IDATIO	007262	JJ22	027334	LL4	030764	NPAT10	013560	PR2 =	000100
IDAT11	007264	JJ27	027410	LOOP	004146	NPAT20	013546	PR3 =	000140
IDAT12	007266	JJ28	027440	LPAT10	012650	NULL	043340	PR4 =	000200
IDAT13	007270	JJ29	027514	LPAT20	012660	N1	013160	PR5 =	000240
IDAT00	007252	JJ8	027016	LUPERR=	104411	N2	013232	PR6 =	000300
IDAT01	007254	JJ9	027070	L1	012456	N3	013234	PR7 =	000340
IDAT02	007256	J1	011764	L2	012530	N4	013236	PS =	177776
IDAT03	007260	J10	012126	L3	012532	N5	013276	PSW =	177776
IDONE	007272	J2	012022	L6	012646	ODATIO	014216	PWRVEC=	000024
IERR0	007046	J3	012024	MDAT00	013142	ODAT00	014154	P1	014234
IERR1	007136	J4	012026	MDONE	013152	ODONE	014226	P2	014306
IERR2	007164	J7	012104	MERR3	013062	OERR0	014002	P3 =	014310
IERR3	007170	K =	000223	MMDONE	031762	OERR1	014076	P4	014312
IERR4	007206	KBUFO	012420	MMSUB	031600	OERR10	014030	QDATIO	015206
IOIVEC=	000020	KDATIO	012410	MM1	031172	OERR11	014042	QDAT00	015176
IPAT10	007232	KDAT00	012430	MM10	031456	OERR2	014106	QDONE	015216
IPAT11	007234	KDONE	012450	MM11	031502	OERR3	014116	QERR0	015022
IPAT12	007236	KERR0	012344	MM12	031526	OERR4	014126	QPAT10	015156
IPAT13	007240	KKDONE	030506	MM13	031552	OPAT10	014206	QPAT20	015166
IPAT20	007242	KKSUB	030326	MM2	031216	OPAT20	014172	QQDONE	034430
IPAT21	007244	KK1	027634	MM3	031242	OPAT21	014174	QQSUB	034250
IPAT22	007246	KK10	030164	MM4	031266	01	013606	QQSUB1	034240
IPAT23	007250	KK11	030214	MM5	031312	02	013660	QQ1	033576
I1	006476	KK12	030244	MM6	031336	03	013662	QQ2	033636
I11	006666	KK13	030274	MM7	031362	04	013664	QQ3	033676
I14	006746	KK2	027664	MM8	031406	05	013724	QQ4	033736
I15	006750	KK3	027714	MM9	031432	PDATIO	014574	QQ5	033776
I16	006752	KK4	027744	MPAT10	013122	PDAT00	014604	QQ6	034036
I17	006764	KK5	027774	MPAT20	013132	PDONE	014614	QQ7	034136
I3	006574	KK6	030024	M1	012716	PERR0	014402	Q1	014622
I4	006576	KK7	030054	M2	012750	PIRQ =	177772	Q2	014674
I5	006600	KK8	030104	NDATIO	013570	PIRQVE=	000240	Q3 =	014676
JBUFO	012154	KK9	030134	NDAT00	013526	POWERM	043304	Q4	014700
JDATIO	012164	KPAT0	012440	NDONE	013600	PPAT10	014564	RAC	043403
JDAT00	012174	K1	012222	NERR0	013354	PPDONE	033570	RACN	043417
JDAT0	012204	K10	012364	NERR1	013450	PPSUB	033406	RAC15	043627
JDONE	012214	K2	012260	NERR10	013402	PP1	032730	RCD	043563
JERR0	012106	K3	012262	NERR11	013414	PP10	033214	RDCHR =	104410
JJDAT	027516	K4	012264	NERR2	013460	PP11	033240	REGS	044265
JJDONE	027626	K7	012342	NERR3	013470	PP12	033264	RESTAR	003542

RESVEC = 000010	S4 = 011616	TST32 = 020062	UERR3 = 015506	YOPO = 017022
RFRAC = 044160	TAB = 000011	TST33 = 021100	UERR4 = 015512	YOP1 = 017032
RINT = 044236	TBITVE = 000014	TST34 = 022326	UPAT0 = 015550	YOP2 = 017042
RRES = 043713	TDATIO = 010034	TST35 = 023340	UPAT1 = 015560	YRES = 017052
RSTAT = 043770	TDATI1 = 010036	TST36 = 024036	UPAT2 = 015570	Y1 = 016630
R6 = 2000006	TDATI2 = 010040	TST37 = 024574	UPAT3 = 015600	Y2 = 016656
R7 = 2000007	TDATI3 = 010042	TST4 = 005134	UPAT4 = 015610	Y3 = 016700
SCOPEX = 040144	TDATOC = 010024	TST40 = 025622	UUDONE = 037270	Y4 = 016736
SDAT = 011632	TDATO1 = 010026	TST41 = 026644	UUSUB = 037026	ZDONE = 017320
SDONE = 011756	TDATO2 = 010030	TST42 = 027632	UUSUB1 = 037016	ZOPO = 017260
SKP1 = 000401	TDATO3 = 010032	TST43 = 030512	UU1 = 035424	ZOP1 = 017270
SKP2 = 000402	TDONE = 010044	TST44 = 031170	UU10 = 036174	ZOP2 = 017300
SKP3 = 000403	TERR0 = 007620	TST45 = 031766	UU11 = 036244	ZRES = 017310
SOBR = 044037	TERR1 = 007710	TST46 = 032726	UU12 = 036314	Z1 = 017074
SPAC1 = 043300	TERR2 = 007736	TST47 = 033574	UU13 = 036364	Z2 = 017114
SRC = 043533	TERR3 = 007760	TST5 = 005322	UU14 = 036434	Z3 = 017130
STACK = 001100	TERR4 = 007742	TST50 = 034434	UU15 = 036504	Z4 = 017174
START = 003542	TKVEC = 000060	TST51 = 035422	UU16 = 036624	\$APTHD = 001000
STKMT = 177774	TPAT10 = 010004	TST6 = 005462	UU17 = 036674	\$ATYC = 041340
STRP1 = 011642	TPAT11 = 010006	TST7 = 006474	UU2 = 035474	\$ATY1 = 041314
STRP2 = 011736	TPAT12 = 010010	TTDONE = 035416	UU3 = 035544	\$ATY3 = 041322
SVPC = 041314	TPAT13 = 010012	TTSUB = 035160	UU4 = 035614	\$ATY4 = 041332
SWR = 001140	TPAT20 = 010014	TT1 = 034436	UU5 = 035664	\$AUTOB = 001134
SWREG = 000176	TPAT21 = 010016	TT10 = 034766	UU6 = 035734	\$BASE = 001310
SWO = 000001	TPAT22 = 010020	TT11 = 035016	UU7 = 036004	\$BDADR = 001122
SWO0 = 000001	TPAT23 = 010022	TT12 = 035046	UU8 = 036054	\$BDAT = 001126
SWO1 = 000002	TPVEC = 000064	TT13 = 035076	UU9 = 036124	\$BELL = 001224
SWO2 = 000004	TRAPVE = 000034	TT14 = 035126	U1 = 015236	\$CHARC = 040566
SWO3 = 000010	TRP04 = 004224	TT2 = 034466	U2 = 015246	\$CKSWR = 041562
SWO4 = 000020	TRP10 = 004234	TT3 = 034516	U244 = 015532	\$CMTAG = 001100
SWO5 = 000040	TRP244 = 004200	TT4 = 034546	U3 = 015416	\$CM3 = 000000
SWO6 = 000100	TRTVEC = 000014	TT5 = 034576	U4 = 015424	\$CM4 = 000020
SWO7 = 000200	TST1 = 004356	TT6 = 034626	U5 = 015440	\$CNTLG = 042171
SWO8 = 000400	TST10 = 007276	TT7 = 034656	WDONE = 016206	\$CNTLU = 042164
SWO9 = 001000	TST11 = 010050	TT8 = 034706	WERR1 = 016026	\$CPUOP = 001262
SW1 = 000002	TST12 = 010572	TT9 = 034736	WERR2 = 016050	\$CRLF = 001231
SW10 = 002000	TST13 = 011416	TYPDS = 104405	WERR3 = 016026	\$DBLK = 041304
SW11 = 004000	TST14 = 011762	TYPE = 104401	WERR4 = 016050	\$DEVCT = 001244
SW12 = 010000	TST15 = 012220	TYPIC = 104402	WOP1 = 016156	\$DOAGN = 037474
SW13 = 020000	TST16 = 012454	TYPON = 104404	WOP2 = 016166	\$DTBL = 041274
SW14 = 040000	TST17 = 012714	TYPOS = 104403	WRES = 016176	\$ENDAD = 037464
SW15 = 100000	TST2 = 004540	T1 = 007300	W1 = 015626	\$ENDCT = 037330
SW2 = 000004	TST20 = 013156	T11 = 007444	XDONE = 016616	\$ENULL = 037500
SW3 = 000010	TST21 = 013604	T14 = 007520	XERR1 = 016450	\$ENV = 001254
SW4 = 000020	TST22 = 014232	T15 = 007522	XERR2 = 016456	\$ENVM = 001255
SW5 = 000040	TST23 = 014620	T16 = 007524	XERR3 = 016450	\$EOP = 037274
SW6 = 000100	TST24 = 015222	T23 = 007616	XERR4 = 016456	\$EOPCT = 037322
SW7 = 000200	TST25 = 015624	T3 = 007376	YOP1 = 016556	\$ERFLG = 001103
SW8 = 000400	TST26 = 016212	T4 = 007400	YOP2 = 016566	\$ERMAX = 001115
SW9 = 001000	TST27 = 016622	T5 = 007402	XOP3 = 016576	\$ERROR = 042542
S1 = 011462	TST3 = 004662	UDONE = 015620	XRES = 016606	\$ERRPC = 001116
S2 = 011520	TST30 = 017066	UERR1 = 015462	X1 = 016214	\$ERRTB = 001312
S3 = 011560	TST31 = 017324	UERR2 = 015502	YDONE = 017062	\$ERTTL = 001112

\$ESCAP 001222	\$MAIL 001234	\$PWJRDN 042370	\$TMP11 001202	\$TYPEC 040450
\$ETABL 001254	\$MAMS1 001264	\$PWARMG 042524	\$TMP12 001204	\$TYPEX 040570
\$ETEND 001312	\$MAMS2 001270	\$PWURUP 042442	\$TMP13 001206	\$TYPOC 040666
\$FATAL 001236	\$MAMS3 001274	\$QUES 001230	\$TMP14 001210	\$TYPON 040702
\$FFLG 041560	\$MAMS4 001300	\$RDCHR 042044	\$TMP15 001212	\$TYPOS 040642
\$FILLC 001156	\$MBADR 001002	\$RDSZ - 000001	\$TMP16 001214	\$UNIT 001246
\$FILLS 001155	\$MFLG 041556	\$RTNAD 037476	\$TMP17 001216	\$UNITM 001010
\$GDADR 001120	\$MNEW 042207	\$SAVR6 042540	\$TMP2 001164	\$USWR 001260
\$GDDAT 001124	\$MSGAD 001250	\$SCOPE 037504	\$TMP3 001166	\$VECT1 001304
\$GET42 037454	\$MSGLG 001252	\$SETUP= 000137	\$TMP4 001170	\$VECT2 001306
\$GTSWR 041632	\$MSGTY 001234	\$STUP = 177777	\$TMP5 001172	\$XOFF = 000023
\$HD = 000003	\$MSWR 042176	\$SVLAD 037750	\$TMP6 001174	\$XON = 000021
\$HIBTS 001000	\$MTYP1 001265	\$SVPC = 001000	\$TMP7 001176	\$XTSTR 037516
\$ICNT 001104	\$MTYP2 001271	\$SWR = 167400	\$TN = 000052	\$GET4= 000000
\$ILLUP 042534	\$MTYP3 001275	\$SWREG 001256	\$TPB 001152	\$SW08= 000052
\$INTAG 001135	\$MTYP4 001301	\$SWRMK= 000200	\$TPFLG 001157	\$TCX 040572
\$ITEMB 001114	\$MXCNT 040020	\$SW08T 040022	\$TPS 001150	\$OFILL 041065
\$LF 001232	\$NULL 001154	\$TERM = 000026	\$TRAP 042220	. = 061372
\$LFLG 041557	\$NWTST= 000001	\$TESTN 001240	\$TRAP2 042242	.CLRFP 042310
\$LPADR 001106	\$SOCNT 041064	\$TIMES 001220	\$TRP = 000013	.LPER 042302
\$LPERR 001110	\$SOMODE 041066	\$TKB 001146	\$TRPAD 042254	.\$X = 001000
\$MADR1 001266	\$OVER 040004	\$TKS 001144	\$TSTM 001004	
\$MADR2 001272	\$PASS 001242	\$TMP0 001160	\$TSTNM 001102	
\$MADR3 001276	\$PASTM 001006	\$TMP1 001162	\$TYPDS 041070	
\$MADR4 001302	\$PWAD 042530	\$TMP10 001200	\$TYPE 040236	

. ABS. 061372 000 CON RO REL GBL D

ERRORS DETECTED: 0

(JFPAA,CJFPAA/LI:FOC=SYSMAC/ML,CJFPAA

RUN-TIME: 36 21 1 SECONDS

RUN-TIME RATIO: 555/59=9.3

CORE USED: 27K (53 PAGES)