

.REM 6

IDENTIFICATION

PRODUCT CODE: AC T794B MC
PRODUCT NAME: CZDHUBO DMU-11 FUNC TST PART1
PRODUCT DATE: 3 MARCH 1984
MAINTAINER: ENE DIAGNOSTICS GROUP
AUTHOR: ANTHONY HART
MODIFIED BY: ANTHONY HART

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1984 BY DIGITAL EQUIPMENT CORPORATION
THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

***** MODIFICATION HISTORY *****

ORIGINAL RELEASE: 15 DEC 83 ANTHONY HART

VERSION 80 3 MAR-84 ANTHONY HART

TWO NEW TESTS WERE INCLUDED IN THIS PART:

TEST 15 - CSR BIT 4 TEST.

TEST 25 DIAGNOSTIC FIELD (BMP) TEST.

TABLE OF CONTENTS

- 1.0 GENERAL PROGRAM CONSIDERATIONS
- 1.1 PROGRAM ABSTRACT
- 1.2 SYSTEM REQUIREMENTS
- 1.3 RELATED DOCUMENTS AND STANDARDS
- 1.4 DIAGNOSTIC HIERARCY PREREQUISITES
- 1.5 ASSUMPTIONS
- 2.0 OPERATING INSTRUCTIONS
- 2.1 COMMANDS
- 2.2 SWITCHES
- 2.3 FLAGS
- 2.4 EXTENDED COMMAND SYNTAX
- 2.4.1 START COMMAND
- 2.4.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>)
- 2.4.1.2 PASS SWITCH (/PASS:<PASS-CNT>)
- 2.4.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.1.4 END OF PASS SWITCH (/EOP:<INCR>)
- 2.4.1.5 EFFECT OF START COMMAND
- 2.4.2 RESTART COMMAND
- 2.4.2.1 TESTS, PASS, AND FLAGS SWITCHES
- 2.4.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>)
- 2.4.2.3 EFFECT OF RESTART COMMAND
- 2.4.3 CONTINUE COMMAND
- 2.4.3.1 FLAG SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.3.2 EFFECT OF CONTINUE COMMAND
- 2.4.4 PROCEED COMMAND
- 2.4.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.4.2 EFFECT OF PROCEED COMMAND
- 2.4.5 ADD COMMAND
- 2.4.6 EFFECT OF ADD COMMAND
- 2.4.7 DROP COMMAND
- 2.4.8 EFFECT OF DROP COMMAND
- 2.4.9 PRINT COMMAND
- 2.4.9.1 EFFECT OF PRINT COMMAND
- 2.4.10 DISPLAY COMMAND
- 2.4.10.1 EFFECT OF DISPLAY COMMAND
- 2.4.11 FLAGS COMMAND
- 2.4.11.1 EFFECT OF FLAGS COMMAND
- 2.4.12 ZFLAGS COMMAND
- 2.4.13 ZFLAGS COMMAND
- 2.4.14 CONTROL CHARACTERS
- 2.5 HARDWARE QUESTIONS
- 2.6 SOFTWARE QUESTIONS
- 2.7 EXTENDED P-TABLE DIALOGUE
- 2.8 QUICK START-UP PROCEDURE (xxDP*)
- 3.0 ERROR INFORMATION
- 3.1 TYPES OF ERROR MESSAGES
- 3.2 SPECIFIC ERROR MESSAGES
- 4.0 PERFORMANCE AND PROGRESS REPORTS
- 5.0 TEST SUMMARIES
- 6.0 EXAMPLE ERROR FREE PASS

1.0 GENERAL PROGRAM CONSIDERATIONS

1.1 PROGRAM ABSTRACT

CZDHUBO IS PART ONE OF THE DMU FUNCTIONAL VERIFICATION TEST. THIS PART OF THE TEST VERIFIES THE RESET, SELFTEST, REGISTER ACCESS, BMP CODE, AND INTERRUPT FUNCTIONS OF THE BOARD ARE FUNCTIONING CORRECTLY.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN THE OPERATING INSTRUCTIONS COMMANDS OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

THE FOLLOWING HARDWARE IS REQUIRED TO RUN THE DMU11 FVT:

- 0 UNIBUS PROCESSOR WITH AT LEAST 32K BYTES OF MEMORY.
- 0 DMU BOARDS INSTALLED ON THE UNIBUS.
- 0 APPROPRIATE PROGRAM LOAD DEVICE SUPPORTING XXDP+ MEDIA OR A DOWN LINE LOADING SYSTEM.

1.3 RELATED DOCUMENTS AND STANDARDS

- 0 XXDP+ USER'S MANUAL - DESCRIBES THE RUNNING OF DIAGNOSTICS UNDER THE XXDP+ MONITOR.

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE PROCESSOR, THE UNIBUS, THE SYSTEM MEMORY, THE CONSOLE TERMINAL AND THE LOAD MEDIA ARE ASSUMED TO HAVE BEEN TESTED AND FOUND WORKING BEFORE THIS PROGRAM IS RUN.

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES.
FOR DETAILED INFORMATION, REFER TO THE XXDP. USER'S MANUAL (CMQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES
(SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY
BRIEF DESCRIPTION OF THEM. THE XXDP. USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
---	-----
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER +C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP. MONITOR (XXDP. OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SEE PERFORMANCE AND PROGRESS REPORTS SECTION OF THIS DOCUMENT)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE FLAGS SECTION)
ZFLAGS	CLEAR ALL FLAGS (SEE FLAGS SECTION)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO
YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".
MORE INFORMATION CAN BE FOUND WITHIN THE SECTION LABELLED
EXTENDED COMMAND SYNTAX

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE /TESTS:1:5:7 10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDD	EXECUTE DDDD PASSES (DDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. SEE THE FLAGS SECTION OF THIS DOCUMENT.
/EOP:DDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDD PASSES ONLY. (DDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE /UNITS:0:5:10 12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESIS:1 5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS, WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS. NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
MOE	HALT ON ERROR CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXR*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST
EVL	EXECUTE EVALUATION (ON DIAGNOSTICS WHICH HAVE EVALUATION SUPPORT)

*SEE THE ERROR INFORMATION SECTION OF THIS DOCUMENT.

SEE THE XXDP* USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

/FLAGS:LOE:IER:BOE

2.4 EXTENDED COMMAND SYNTAX

2.4.1 START COMMAND -

STA(RT)/TESTS:<TEST-LIST>/PASS:<PASS CNT>/FLAGS:
<FLAG-LIST>/EOP:<INCR>

2.4.1.1 TESTS SWITCH (/TESTS:<TEST LIST>) -

<TEST-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.), SEPERATED BY COLONS, THAT SPECIFY THE TESTS TO BE EXECUTED. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS. ON THIS AND ALL SWITCHES, THE ANGLE BRACKETS <> ARE PUNCTUATION USED IN THE DEFINITION ONLY, AND ARE NOT TO BE TYPED BY THE OPERATOR. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

2.4.1.2 PASS SWITCH (/PASS:<PASS-CNT>) -

<PASS-CNT> IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS). THE DEFAULT IS NON-ENDING EXECUTION. IN THIS CASE, EXIT FROM THE PROGRAM IS ACCOMPLISHED EITHER BY TYPING A CONTROL/C OR BY OCCURANCE OF AN ERROR WITH THE HALT ON ERROR FLAG BEING SET. THE EXIT IS A RETURN TO COMMAND MODE. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

2.4.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPERATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

HOE	HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED.
LOE	LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR.
IER	INHIBIT ERROR REPORTING.
IBE	INHIBIT BASIC ERROR REPORTS.
IXE	INHIBIT EXTENDED ERROR REPORTS.
PRI	DIRECT ALL MESSAGES TO A LINE PRINTER.
PNT	PRINT NUMBER OF TEST BEING EXECUTED.
BOE	BELL ON ERROR (NOT RELATED TO BELL PROMPTING).
UAM	RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION (ILLEGAL FOR THIS DIAGNOSTIC).
ISR	INHIBIT STATISTICAL REPORTS.

IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC.
(HAS NO EFFECT IN THIS DIAGNOSTIC.)
LOT LOOP ON TEST.
THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE
CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT
GIVEN ALL FLAGS ARE CLEARED. SEE EXAMPLE AT END OF "EFFECT OF START
COMMAND" SECTION.

2.4.1.4 END OF PASS SWITCH (/EOP:<INCR>) -

<INCR> IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF
PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE
DEFAULT IS AT THE END OF EVERY PASS. SEE EXAMPLE AT END OF "EFFECT OF
START COMMAND" SECTION.

2.4.1.5 EFFECT OF START COMMAND -

THE EFFECT OF THE START COMMAND IS TO INITIATE THE HARDWARE
PARAMETER DIALOGUE, THE SOFTWARE PARAMETER DIALOGUE, THE
INITIALIZATION QUESTIONS, AND THEN THE DIAGNOSTIC COMMENCES TESTING.

THE HARDWARE PARAMETER DIALOGUE COMMENCES WITH THE QUESTION "4
UNITS (D) ?" TO WHICH THE OPERATOR SHOULD REPLY WITH THE NUMBER OF
UNITS TO BE TESTED. FOLLOWING THIS ARE THE QUESTIONS WHEREBY THE
P-TABLES THEMSELVES ARE BUILT. EACH P-TABLE IS A CORE-RESIDENT TABLE
CONTAINING ALL THE HARDWARE INFORMATION FOR ONE COMPLETE UNIT. EACH
QUESTION IS FOLLOWED BY THE RESPONSE RADIX (D FOR DECIMAL, B FOR
BINARY, O FOR OCTAL, L FOR YES/NO) IN PARENTHESES AND THE DEFAULT
VALUE AFTER THE PARENTHESES. FOR THE ACTUAL HARDWARE P TABLE
QUESTIONS SEE THE "HARDWARE PARAMETERS" SECTION.

FOLLOWING THE HARDWARE QUESTIONS ARE THE SOFTWARE QUESTIONS TO
BUILD THE SOFTWARE TABLES, WHICH DEFINE OPERATING PARAMETERS OF THE
DIAGNOSTIC PROGRAM. THESE QUESTIONS ARE DESCRIBED IN THE "SOFTWARE
PARAMETERS" SECTION.

EXAMPLE:

STA/TESTS:1:3-4:/PASS:3/FLAGS:IER:MOE=1

THIS COMMAND WILL CAUSE THREE PASSES TO BE MADE, WITH EACH PASS
CONSISTING OF TESTS 1,3, AND 4. THERE IS NO DIFFERENCE BETWEEN SAYING
<FLAG> AND SAYING <FLAG=1>. THE NOTATION <FLAG=0> IS MEANINGFUL ONLY
ON A COMMAND OTHER THAN START TO CLEAR A FLAG THAT WAS PREVIOUSLY SET.
NOTE THAT ON ALL COMMANDS ONLY THE FIRST THREE LETTERS ARE SCANNED.

2.4.2 RESTART COMMAND

```
*****  
RES(TART)/TESTS:<TEST-LIST>/PASS:<PASS CNT>/FLAGS:  
<FLAG-LIST>/UNITS:<UNIT-LIST>  
*****
```

2.4.2.1 TESTS, PASS, AND FLAGS SWITCHES

<TEST-LIST>, <PASS-CNT>, AND <FLAG-LIST> ARE AS IN THE START COMMAND.

2.4.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>) - <UNIT-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (0,1 ETC.) OR RANGES OF DECIMAL NUMBERS (0-5, 8-10 ETC.) THAT SPECIFY THE UNITS TO BE TESTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS MAY RANGE FROM 0 THRU N 1 (N IS THE NUMBER OF UNITS SPECIFIED IN THE PREVIOUS START COMMAND). THE NUMBER INDICATES THE POSITION OF THE P-TABLE AS THE DATA WAS ENTERED DURING THE HARDWARE DIAGLOGUE. THE UNITS WHICH ARE SELECTED MUST NOT HAVE BEEN DROPPED BY THE DROP COMMAND. SEE THE DISCUSSION OF ADD AND DROP COMMANDS BELOW. DEFAULT IS TO TEST ALL UNITS WHICH HAVE NOT BEEN DROPPED BY A DROP COMMAND.

2.4.2.3 EFFECT OF RESTART COMMAND

THE RESTART COMMAND DIFFERS FROM THE START COMMAND IN THAT THE P-TABLES FROM THE PREVIOUS START COMMAND (THERE MUST HAVE BEEN ONE) ARE USED, INSTEAD OF NEW ONES BEING BUILT. THE UNITS SWITCH SHOULD NOT BE USED WITH THIS PROGRAM. THE SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED (OPERATOR WILL BE ASKED). THE COMMAND CAN BE USED AFTER COMMAND MODE HAS BEEN REENTERED IN ANY OF THE THREE NORMAL WAYS: A) THE REQUESTED NUMBER OF PASSES HAVE BEEN MADE, B) AN ERROR WAS ENCOUNTERED WITH THE HALT ON ERROR FLAG SET, OR C) A CONTROL /C WAS ENTERED BY THE OPERATOR.

2.4.3 CONTINUE COMMAND -

```
*****  
CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG LIST>  
*****
```

2.4.3.1 FLAG SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS SAME AS IN THE START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

2.4.3.2 EFFECT OF CONTINUE COMMAND

CONTINUE MUST FOLLOW A START OR RESTART, AND COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

2.4.4 PROCEED COMMAND

PRO(CEED)/FLAGS:<FLAG-LIST>

2.4.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)

<FLAG-LIST> IS AS IN THE START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

2.4.4.2 EFFECT OF PROCEED COMMAND

PROCEED MUST FOLLOW A START, RESTART, OR CONTINUE. COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS MAY BE ALTERED.

2.4.5 ADD COMMAND -

ADD/UNITS:<UNIT-LIST>

2.4.6 EFFECT OF ADD COMMAND -

THE UNITS SPECIFIED ARE ADDED TO THE TEST SEQUENCE. EACH UNIT MUST HAVE A P-TABLE IN MEMORY DUE TO AN EARLIER HARDWARE DIALOGUE. THIS COMMAND MUST BE FOLLOWED BY A RESTART OR CONTINUE. THE UNITS SWITCH MUST BE SPECIFIED. THE ADD COMMAND IS MEANINGFUL ONLY FOR UNITS THAT WERE PREVIOUSLY DROPPED.

2.4.7 DROP COMMAND -

DRO(P)/UNITS:<UNIT LIST>

2.4.8 EFFECT OF DROP COMMAND
THE UNITS SPECIFIED WILL BE DROPPED FROM TESTING. THE UNITS
WILL BE RESELECTED ONLY BY THE EXECUTION OF AN ADD OR START
COMMAND. THE UNITS SWITCH MUST BE ENTERED. THIS COMMAND
MUST BE FOLLOWED BY A RESTART OR A CONTINUE COMMAND.

2.4.9 PRINT COMMAND -

PRI(NT)

2.4.9.1 EFFECT OF PRINT COMMAND
THE TOTAL NUMBER OF ERRORS FOR EACH UNIT SINCE THE LAST
START OR RESTART COMMAND ARE PRINTED. THE ISR (INHIBIT
STATISTICAL REPORTING) FLAG IS CLEARED.

2.4.10 DISPLAY COMMAND -

DIS(PLAY)/UNITS:<UNIT-LIST>

2.4.10.1 EFFECT OF DISPLAY COMMAND
THE HARDWARE P-TABLE FOR THE TEST STATION IS PRINTED IN THE
FORMAT IN WHICH IT WAS ENTERED.

2.4.11 FLAGS COMMAND -

FLA(GS)

2.4.11.1 EFFECT OF FLAGS COMMAND -
THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

2.4.12 ZFLAGS COMMAND

ZFL(AGS)

2.4.13 ZFLAGS COMMAND

ALL FLAGS ARE CLEARED.

2.4.14 CONTROL CHARACTERS -

- C A CONTROL/C (C) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES A RETURN TO COMMAND MODE.
- Z A CONTROL/Z (Z) ENTERED DURING ONE OF THE TWO OPERATOR DIALOGUES-- HARDWARE P TABLE DIALOGUE OR SOFTWARE P-TABLE DIALOGUE CAUSES THE DEFAULTS TO BE TAKEN FOR THE REMAINDER OF THAT DIALOGUE.
- O A CONTROL/O (O) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES ALL TELETYPE OUTPUT TO BE SUPPRESSED FOR THE REMAINDER OF THE DIAGNOSTIC OR UNTIL ANOTHER CONTROL/O IS TYPED, WHICH RESTORES NORMAL TELETYPE OUTPUT.

2.5 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 6 OF THE XXDP+ USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL). YOU WILL THEN BE ASKED THE FOLLOWING QUESTIONS FOR EACH UNIT.

1. CSR ADDRESS - THIS QUESTION REQUESTS THE CSR ADDRESS OF THE SPECIFIED DMU-11. THE DEFAULT ANSWER FOR THIS QUESTION IS ADDRESS 160460 (OCTAL).
2. INTERRUPT VECTOR ADDRESS THIS QUESTION REQUESTS THE INTERRUPT VECTOR ADDRESS OF THE SPECIFIED DMU-11. THE DEFAULT ANSWER IS 310 (OCTAL).
3. ACTIVE LINES BIT MAP - THIS QUESTION REQUESTS AN OCTAL BIT MAP OF THE SERIAL COMMUNICATION LINES ON THE DMU11 WHICH ARE BEING SELECTED FOR TESTING. IF THE BIT IN THE BIT MAP IS SET WHICH CORRESPONDS TO A PARTICULAR LINE (I.E. BIT 5 FOR LINE 5) THAT LINE WILL BE TESTED BY THE FVT.
4. BR LEVEL - THIS QUESTION REQUESTS THE INTERRUPT BR LEVEL OF THE SPECIFIED DMU-11. THE DEFAULT ANSWER IS BR 5.

2.6 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

1. REPORT UNIT NUMBER AS EACH UNIT IS TESTED - THIS QUESTION ASKS WHETHER THE PROGRAM SHOULD REPORT THE NUMBER OF THE UNIT WHICH IT IS TESTING AS IT BEGINS TO TEST THAT UNIT.
2. ROM VERSION PRINTOUT ON THE FIRST PASS - THIS QUESTION ASKS WHETHER THE PROGRAM SHOULD PRINTOUT THE VERSIONS OF THE ON BOARD PROCESSOR ROMS DURING THE FIRST PASS OF THE PROGRAM.
3. EXTENDED ERROR REPORTING - THIS QUESTION ASKS WHETHER EXTENDED ERROR INFORMATION IS REQUIRED OTHER THAN THE "TEST FAILED" MESSAGE, ON EACH ERROR REPORTED. THE DEFAULT IS "NO" I.E. ONLY A MESSAGE REPORTING THE FACT THAT THE TEST FAILED WILL BE PRINTED.
4. NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE THIS QUESTION IS ASKED ONLY IF THE PREVIOUS QUESTION WAS ANSWERED "YES". THE QUESTION ASKS FOR THE NUMBER OF DATA ERRORS WHICH SHOULD BE REPORTED INDIVIDUALLY BY THIS PROGRAM FOR EACH LINE FOR EACH TRANSMISSION TEST. ERRORS WHICH ARE NOT REPORTED INDIVIDUALLY ARE REPORTED IN SUMMARY ERROR REPORTS.

2.7 EXTENDED P TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A FICTIONAL DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q-FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

* UNITS (0) ? 8<CR>

UNIT 1

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 0<CR>

Q-FACTOR (0) 0 ? 1<CR>

UNIT 2

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 1<CR>

Q-FACTOR (0) 1 ? 0<CR>

UNIT 3

CSR ADDRESS (0) ? 160000<CR>

SUB DEVICE # (0) ? 2<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 4

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 3<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 5

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 4<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 6

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 5<CR>

Q FACTOR (0) 0 ? <CR>

UNIT 7

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 6<CR>

Q-FACTOR (0) 0 ? 1<CR>


```
UNIT 8  
CSR ADDRESS (0) 160000<CR>  
SUB-DEVICE # (0) ? 7<CR>  
Q-FACTOR (0) 1 ? <CR>
```

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER. LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION FEATURE.

```
# UNITS (0) ? 8<CR>
```

```
UNIT 1  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 0,1<CR>  
Q-FACTOR (0) 0 ? 1,0<CR>
```

```
UNIT 3  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 2-5<CR>  
Q-FACTOR (0) 0 ? 0<CR>
```

```
UNIT 7  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 6,7<CR>  
Q-FACTOR (0) 0 ? 1<CR>
```

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

```
# UNITS (0) ? 8<CR>
```

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0 7<CR>
Q-FACTOR (0) 0 ? 0.1,0....1,1<CR>

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING
A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

2.8 QUICK START-UP PROCEDURE (XXDP+)

TO START-UP THIS PROGRAM:

1. BOOT XXDP+
2. GIVE THE DATE AND ANSWER THE LSI/UNIBUS AND SOHZ (IF THERE IS A CLOCK) QUESTIONS. NOTE, NOT ALL VERSIONS OF XXDP+ ASK FOR THE CLOCK FREQUENCY
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE
DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. FOR DEFAULT INFORMATION
SEE THE SECTIONS WITHIN THIS DOCUMENT ON FLAGS, AND HARDWARE QUESTIONS.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SEE THE FLAGS SECTION OF THIS DOCUMENT).

THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX  
ERROR MESSAGE
```

.WHERE; NAME = DIAGNOSTIC NAME
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
NUMBER = ERROR NUMBER
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SEE THE FLAGS SECTION OF THIS DOCUMENT). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXR" FLAGS ARE SET (SEE THE FLAGS SECTION OF THIS DOCUMENT). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

THIS PROGRAM IS INTENDED TO PROVIDE A GO/NOGO INDICATION OF THE FUNCTIONALITY OF THE DHU-11 BOARDS. TO EXECUTE THE PROGRAM IN THIS MODE THE OPERATOR NEED ONLY ANSWER THE "EXTENDED ERROR REPORTING" SOFTWARE QUESTION WITH "NO", THE PROGRAM WILL THEN ONLY PRINT THE NAME OF THE FAILING TEST THE TEST AND ERROR NUMBERS. FOR A LIST OF THE TEST NAMES IN THIS PROGRAM SEE THE TEST SUMMARIES SECTION OF THIS DOCUMENT. AN EXAMPLE OF SUCH A AN ERROR MESSAGE IS THE FOLLOWING:

CZDMU DVC FTL ERR 01603 ON UNIT 02 TST 16 SUB 000 PC: XXXXXX
DEVICE REGISTER WORD READ/WRITE TEST FAILED.

THIS ERROR INDICATES THAT A FATAL ERROR WAS ENCOUNTERED WITHIN THE TEST WHICH TESTS THE READ/WRITE CAPABILITY OF THE DHU 11 REGISTERS.

IF THE OPERATOR HAD REQUESTED EXTENDED ERROR REPORTING THE SAME ERROR WOULD BE REPORTED AS FOLLOWS:

CZDMU DVC FTL ERR 01603 ON UNIT 02 TST 16 SUB 000 PC: XXXXXX
DEVICE REGISTER WORD READ/WRITE TEST FAILED.
BAD BIT(S) IN DEVICE TBUFFAD1 REGISTER FOR LINE 7 (D).
EXPECTED DATA: 000000 (0).
ACTUAL DATA: 000023 (0).

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. FOR FUTHER INFORMATION SEE THE SWITCHES SECTION OF THIS DOCUMENT.

5.0 TEST SUMMARIES

THE FOLLOWING ARE INCLUDED WITHIN CZDHUB:

1. DEVICE REGISTER ACCESS TEST - VERIFIES THAT THE UUT REGISTERS WILL RESPOND WITH THE CORRECT UNIBUS HANDSHAKING SIGNALS. VERIFIES THAT THE UUT IS AT THE CORRECT ADDRESS.
2. MASTER.RESET (SELFTEST) TEST - VERIFIES THAT THE MASTER.RESET BIT CLEARS WITHIN A SPECIFIED TIME OF IT BEING SET.
3. MASTER.RESET (SKIP SELFTEST) TEST - VERIFIES THAT THE MASTER RESET CLEARS WITHIN A SHORT TIME AFTER IT IS SET WHEN THE SKIP SELFTEST SEQUENCE IS USED.
4. RX.CHARACTER FIELD TEST - VERIFIES THAT THE DATA BITS OF THE CODES IN THE RXFIFO AFTER A MASTER RESET AND SKIP SELFTEST ARE CONSISTANT WITH THE SKIP SELFTEST CODES.
5. RX.FLAG FIELD TEST - VERIFIES THAT THE 3 DATA STATUS BITS (OVERRUN, FRAMTNG AND PARITY ERROR BITS) ARE ALL SET ON EACH OF THE SKIP SELFTEST CODES IN THE FIFO AFTER A MASTER RESET AND SKIP SELFTEST SEQUENCE.
6. RX.DATA.AVAIL TEST - VERIFIES THAT THE RX.DATA.AVAIL BIT IS SET WHEN THE SKIP SELFTEST CODES ARE IN THE FIFO AND THAT IT CLEARS AFTER THEY HAVE BEEN READ.
7. RX.DATA.VALID TEST - VERIFIES THAT THE RX.DATA.VALID BIT IS SET FOR ALL THE CODES IN THE FIFO AND CLEAR AFTER ALL THE CODES HAVE BEEN READ.
8. RX.LINE FIELD TEST - VERIFIES THAT THE RX.LINE LINE FIELDS ARE CORRECT FOR THE SKIP SELFTEST CODES.
9. BMP CHECK TEST - VERIFIES THAT THE DUT DOES NOT IMMEDIATELY FAIL THE BACKGROUND MONITOR PROGRAM, AS THIS MAY INVALIDATE FURTHER TESTS.
10. SKIP SELFTEST TEST - VERIFIES THAT THE DUT SKIPS THE SELFTEST IN THE TIME ALLOWED, AND THAT THE FIFO CONTAINS THE CORRECT CODES AFTER ITS COMPLEATION.
11. DIAGNOSTIC.FAIL (SKIP SELFTEST) TEST - VERIFIES USING THE SKIP SELFTEST SEQUENCE THAT THE DIAG.FAIL BIT GOES TO BOTH THE ACTIVE AND INACTIVE STATES WITHIN THE ALLOWED TIMES.
12. SELFTEST TEST - VERIFIES THAT THE DUT'S SELFTEST EXECUTES WITHIN THE CORRECT TIME AND THAT THE CORRECT CODES ARE RETURNED IN THE FIFO AFTER ITS COMPLEATION.
13. SELFTEST FAIL TEST - VERIFIES THAT THE DUT WILL REPORT ERRORS CORRECTLY WHEN IT IS FORCED TO FAIL.

14. ROM VERSION NUMBER - VERIFIES THAT THE ROM VERSION NUMBERS ARE REPORTED CORRECTLY AND IF REQUESTED PRINTS THEM OUT.
15. CSR BIT 4 TEST VERIFIES THAT WHEN SET THIS BIT CAUSES THE SELFTEST TO LOOP, AND WHEN CLEARED THE SKIP SELFTEST CODES ARE RETURNED IN THE RXFIFO.
16. WORD ACCESS READ/WRITE TEST - VERIFIES THAT THE REGISTERS RESPOND CORRECTLY TO READ AND WRITE ACCESSES.
17. WORD ACCESS READ/MODIFY/WRITE TEST - VERIFIES THAT THE REGISTERS WILL RESPOND CORRECTLY TO READ/MODIFY/WRITE ACCESSES.
18. BYTE ACCESS READ/WRITE TEST - VERIFIES THAT THE REGISTERS WILL RESPOND CORRECTLY TO BYTE READ/WRITE ACCESSES.
19. BYTE ACCESS READ/MODIFY/WRITE - VERIFIES THAT THE REGISTERS WILL RESPOND CORRECTLY TO BYTE READ/MODIFY/WRITE ACCESSES.
20. ID.BIT TEST - VERIFIES THAT THE ID BIT READS AS SET.
21. TX.ENABLE (INACTIVE) TEST - VERIFIES THAT WHEN A LINE'S TX.ENBL BIT IS CLEAR, TRANSMISSION WILL NOT TAKE PLACE ON THAT LINE.
22. TX.ENABLE (ACTIVE) TEST - VERIFIES THAT WHEN A LINE'S TX.ENBL BIT IS SET, TRANSMISSION WILL TAKE PLACE ON THAT LINE.
23. INTERRUPT TEST - VERIFIES THAT THE DUT WILL GENERATE RECEPTION AND TRANSMISSION INTERRUPTS CORRECTLY.
24. BR LEVEL TEST - VERIFIES THAT THE DUT INTERRUPTS AT THE CORRECT BUS REQUEST LEVEL.
25. DIAGNOSTIC FIELD (BMP) TEST - VERIFIES THAT A REQUEST TO THE DUT TO REPORT BMP STATUS CODES IS COMPLIED WITH WITHIN THE SPECIFIED TIME. ALL ACTIVE LINES ARE TESTED.
26. REPORT BMP CODES TEST - THIS PSEUDO TEST REPORTS THE FIRST 32 BMP CHARACTERS WHICH WERE DISCOVERED IN THE FIFO DURING THE EXECUTION OF THE OTHER TESTS. THIS AVOIDS INTERRUPTION OF THE OTHER TESTS BY THESE CODES IF THEY ARE NOT CRITICAL TO THE PERFORMANCE OF THE TESTS.

6.0 EXAMPLE ERROR FREE PASS

THE FOLLOWING IS AN EXAMPLE OF AN ERROR FREE PASS DIALOGUE:

.R CZDHUBO
CZDHUBO.BIN

DRS
CZDHU-B-0
DHU-11 FUNC TST PART1
UNIT IS DHU-11
RESTART ADDR: 147670
DR>STA/PAS:1

CHANGE HW (L) ? Y

* UNITS (D) ? 2

UNIT 0
CSR ADDRESS: (0) 160460 ? +Z

UNIT 1
CSR ADDRESS: (0) 160460 ? 160500
INTERRUPT VECTOR ADDRESS: (0) 310 ? 320
ACTIVE LINE BIT MAP: (0) 17777 ? <CR>
INTERRUPT BR LEVEL: (0) 5 ? <CR>

CHANGE SW (L) ? Y

REPORT UNIT NUMBER AS EACH UNIT IS TESTED: (L) Y ? <CR>
ROM VERSION PRINTOUT ON THE FIRST PASS: (L) Y ? <CR>
EXTENDED ERROR REPORTING: (L) N ? Y
NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE: (D) 0 ? 1

TESTING UNIT : 0(D)

ROM VERSION NUMBERS: PROC_1 = 2(D) PROC_2 = 2(D)

TESTING UNIT : 1(D)

ROM VERSION NUMBERS: PROC_1 = 2(D) PROC_2 = 2(D)

CZDHU EOP 1
0 TOTAL ERRS

DR>

E

```

1073          .LIST SEQ,LOC,BIN,MEB
1074          .MLIST CND
1082
1083
1084          .SBTTL PROGRAM HEADER
1085
1086
1087          .MCALL SVC
1088 000000          SVC                      ; INITIALIZE SUPERVISOR MACROS
1089
1090          ;*****
1091          ; IF STRUCTURED MACROS ARE TO BE USED, ADD ".MCALL STRUCT" AND "STRUCT"
1092          ; TO INITIALIZE THE STRUCTURED MACROS.
1093
1094          SVCINS= 1          ; LIST INSTRUCTIONS, SHIFTED RIGHT
1095          SVCTST= 1         ; LIST TEST TAGS, SHIFTED RIGHT
1096          SVCSUB= 1        ; LIST SUBTEST TAGS, SHIFTED RIGHT
1097          SVCGBL= 1        ; LIST GLOBAL TAGS, SHIFTED RIGHT
1098          SVCTAG= 1         ; LIST OTHER TAGS, SHIFTED RIGHT
1099
1100          ; CHANGE THE VALUES OF THE SVC... SYMBOLS TO BE ZERO IF YOU WISH
1101          ; TO ALIGN THE MACRO CALLS AND THEIR EXPANSIONS. CHANGE THE
1102          ; SYMBOLS TO BE MINUS-ONE TO NOT LIST THE EXPANSIONS. YOU MAY
1103          ; CHANGE THE SYMBOLS AT ANY POINT IN YOUR PROGRAM.
1104          ;*****
1105
1106 000000          .ENABL ABS
1107
1108          002000          .ENABL AMA
1109          "                "                2000
1110
1111          BGNMOD
1112
1113          ;**
1114          ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
1115          ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
1116          ;--
1117 002000          POINTER BGNRPT,BGNSW,BGNSFT,BGNDU,ERRTBL
1118
1119
1120
1121
1122
1123
1124
1125
1126 002000          HEADER CZDHU,B,0,16,0,PRI07
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136 002000          L$NAME::
1137          002000          103          .ASCII /C
1138          002001          132          .ASCII /Z/
1139          002002          104          .ASCII /D/
1140          002003          110          .ASCII /H/
1141          002004          125          .ASCII /U/
1142          002005          000          .BYTE 0
1143          002006          000          .BYTE 0
1144          002007          000          .BYTE 0
1145          002010          L$REV::

```


002010 102
002011
002011 060
002012
002012 000000
002014
002014 000016
002016
002016 036700
002020
002020 037072
002022
002022 002212
002024
002024 002224
002026
002026 037454
002030
002030 000000
002032
002032 000000
002034
002034 000000
002036
002036 000000
002040
002040 002124
002042
002042 000340
002044
002044 000000
002046
002046 0C0000
002050
002050 003
002051 003
002052
002052 000000
002054 000000
002056
002056 000000
002060
002060 004036
002062
002062 024222
002064
002064 000000
002066
002066 000000
002070
002070 000000
002072
002072 025076
002074
002074 000000
002076
002076 004046

L\$DEPO:: .ASCII /B/
L\$UNIT:: .ASCII /O/
L\$TIML:: .WORD 0
L\$MPCP:: .WORD 16
L\$SPCP:: .WORD L\$HARD
L\$MPTP:: .WORD L\$SOFT
L\$SPTP:: .WORD L\$HW
L\$LADP:: .WORD L\$SW
L\$STA:: .WORD L\$LAST
L\$CO:: .WORD 0
L\$DTYP:: .WORD 0
L\$APT:: .WORD 0
L\$DTP:: .WORD L\$DISPATCH
L\$PRIO:: .WORD PRI07
L\$ENVI:: .WORD 0
L\$EXP1:: .WORD 0
L\$MREV:: .BYTE C\$REVISION
L\$EF:: .BYTE C\$EDIT
L\$SPC:: .WORD 0
L\$DEVP:: .WORD L\$DVTYP
L\$REPP:: .WORD L\$RPT
L\$EXP4:: .WORD 0
L\$EXP5:: .WORD 0
L\$AUT:: .WORD 0
L\$DUT:: .WORD L\$DL
L\$LUN:: .WORD 0
L\$DESP:: .WORD L\$DESC

002100	
002100	104035
002102	
002102	003766
002104	
002104	024236
002106	
002106	025060
002110	
002110	025056
002112	
002112	024230
002114	
002114	000000
002116	
002116	000000
002120	
002120	000000

1137

L\$LOAD::	EMT	E\$LOAD
L\$ETP::	.WORD	L\$ERRTBL
L\$ICP::	.WORD	L\$INIT
L\$CCP::	.WORD	L\$CLEAN
L\$ACP::	.WORD	L\$AUTO
L\$PRT::	.WORD	L\$PROT
L\$TEST::	.WORD	0
L\$DLY::	.WORD	0
L\$HIME::	.WORD	0

1149
1150
1151
1152
1153
1154
1155
1156

.SBTTL DISPATCH TABLE

; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
;

DISPATCH 26

002122
002122 000032
002124
002124 025214
002126 025476
002130 025726
002132 026172
002134 026370
002136 026562
002140 027000
002142 027206
002144 027414
002146 027610
002150 030024
002152 030252
002154 030546
002156 031034
002160 031434
002162 031776
002164 032244
002166 032434
002170 032752
002172 033214
002174 033330
002176 033646
002200 034222
002202 035360
002204 036322
002206 036616

.WORD 26
L#DISPATCH:;
.WORD T1
.WORD T2
.WORD T3
.WORD T4
.WORD T5
.WORD T6
.WORD T7
.WORD T8
.WORD T9
.WORD T10
.WORD T11
.WORD T12
.WORD T13
.WORD T14
.WORD T15
.WORD T16
.WORD T17
.WORD T18
.WORD T19
.WORD T20
.WORD T21
.WORD T22
.WORD T23
.WORD T24
.WORD T25
.WORD T26

1157

1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191

002210
002210 000004
002212
002212
002212
160460
002214 000310
002216 177777
002220 005
002222
002222

.SBTTL DEFAULT HARDWARE P TABLE

; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
; THE TEST DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
; IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P TABLES.
; AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.

BGNHW DFPTBL

.WORD L10000 L\$HW/2
L\$HW::
DFPTBL::

.WORD 160460 ;DEFAULT CSR ADDRESS
.WORD 310 ;DEFAULT VECTOR ADDRESS
.WORD 177777 ;DEFAULT ACTIVE LINES BIT MAP
.BYTE 5 ;DEFAULT BR LEVEL
.EVEN

ENDHW

L10000:

1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211

002222
002222 000002
002224
002224

1212
1213 002224 000021
1214 002226 000000
1215
1216 002230
002230

.SBTTL SOFTWARE P TABLE

; THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
; PROGRAM AS OPERATIONAL PARAMETERS. THESE PARAMETERS ARE
; SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
; AT RUN TIME.

BGNSW SFPTBL

.WORD L10001 L\$SW/2
L\$SW::
SFPTBL::
L10001:

OPTION:: .WORD 21 ;BIT MAP OF PROGRAM CONTROL FLAGS
NDERPT:: .WORD 0 ;DEFAULT NUMBER OF INDIVIDUAL DATA ERRORS TO RPT.

ENDSW

1225
 1226
 1227
 1237
 1238
 1239
 1240
 1241
 1242
 1243
 1244
 1245
 1246
 1247
 1248
 1249
 1250
 1251
 1252
 1267 002230

.SBTTL GLOBAL EQUATES SECTION

```

; **
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
; --
    
```

```

NUMLNS==20 ;NUMBER OF LINES ON DMU11 IS 16.
MAPLNS==177777 ;BIT MAP OF LINES ON DMU11.

;***** DEVICE REGISTER OFFSETS FROM THE CSR'S ADDRESS *****
LPRO==4 ;LINE PARAMETER REGISTER OFFSET FROM THE CSR ADDRESS
FLSO==6 ;FIFOSIZE/STATUS REGISTER OFFSET FROM THE CSR ADDRESS
TXBFCO==16 ;TRANSMIT COUNT REGISTER OFFSET FROM THE CSR ADDRESS
    
```

EQUALS

```

;
; BIT DIFINITIONS
    
```

```

100000 BIT15== 100000
040000 BIT14== 40000
020000 BIT13== 20000
010000 BIT12== 10000
004000 BIT11== 4000
002000 BIT10== 2000
001000 BIT09== 1000
000400 BIT08== 400
000200 BIT07== 200
000100 BIT06== 100
000040 BIT05== 40
000020 BIT04== 20
000010 BIT03== 10
000004 BIT02== 4
000002 BIT01== 2
000001 BIT00== 1
    
```

```

;
BIT9== BIT09
BIT8== BIT08
BIT7== BIT07
BIT6== BIT06
BIT5== BIT05
BIT4== BIT04
BIT3== BIT03
BIT2== BIT02
BIT1== BIT01
BIT0== BIT00
    
```

```

;
; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
    
```

```

000040 EF.START== 32. ; START COMMAND WAS ISSUED
000037 EF.RESTART== 31. ; RESTART COMMAND WAS ISSUED
000036 EF.CONTINUE== 30. ; CONTINUE COMMAND WAS ISSUED
    
```

```

000035      EF.NEW==      29.
000034      EF.PWR==      28.
;
;
; PRIORITY LEVEL DEFINITIONS
;
000340      PRI07== 340
000300      PRI06== 300
000240      PRI05== 240
000200      PRI04== 200
000140      PRI03== 140
000100      PRI02== 100
000040      PRI01== 40
000000      PRI00== 0
;
; OPERATOR FLAG BITS
;
000004      EVL==      4
000010      LOT==      10
000020      ADR==      20
000040      IDU==      40
000100      ISR==     100
000200      UAM==     200
000400      BOE==     400
001000      PNT==    1000
002000      PRI==    2000
004000      IXE==    4000
010000      IBE==   10000
020000      IER==   20000
040000      LOE==   40000
100000      HOE==  100000

```

```

; A NEW PASS HAS BEEN STARTED
; A POWER FAIL/POWER UP OCCURRED

```

1268

1270
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292 002230 177777
1293 002232 000300
1294 002234 000304
1295 002236 000000
1296 002240 004
1297
1298
1299
1300
1301
1302 002242
1303 002242 160020
1304 002244 160022
1305 002246 160024
1306 002250 160026
1307
1308 002252 160030
1309 002254 160032
1310 002256 160034
1311 002260 160036
1312
1313
1314
1315
1316 002262 005464
1317 002264 005470
1318 002266 005475
1319 002270 005501
1320 002272 005517
1321 002274 005526
1322 002276 005537
1323 002300 005550
1324
1325
1326
1327
1328 002302 000000
1329 002304 000000
1330 002306 000000
1331 002310 000000
1332 002312 000000
1333 002314 000000

.SBTTL GLOBAL DATA SECTION

; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
; IN MORE THAN ONE TEST.
;--

; UNIT VARIABLE AREA

ACTLNS:: .WORD 177777 ;ACTIVE LINE BIT MAP.
RXVECA:: .WORD 300 ;RX VECTOR ADDRESS.
TXVECA:: .WORD 304 ;TX VECTOR ADDRESS.
UNITN:: .WORD 0 ;UNIT NUMBER.
BRLEVL:: .BYTE 4 ;INTERRUPT BUS REQUEST LEVEL
.EVEN

; DEVICE REGISTER ADDRESS TABLE

DRADRT::
CSRA:: .WORD 160020 ;DHU-11 CSR ADDRESS.
RXTMA:: RBUFA:: .WORD 160022 ;DHU 11 RECIEVE BUFFER/TIMER ADDRESS.
LPRA:: .WORD 160024 ;DHU-11 LINE PARAMETER REGISTER ADDRESS.
FDATA:: FLSA:: .WORD 160026 ;DHU-11 FIFO SIZE/LINE STATUS REGISTER ADDRESS,
;AND FIFO DATA REGISTER ADDRESS.
LNCTRA:: .WORD 160030 ;DHU-11 LINE CONTROL REGISTER ADDRESS.
TXAD1A:: .WORD 160032 ;DHU-11 TRANSMIT BUFFER 1 REGISTER ADDRESS
TXAD2A:: .WORD 160034 ;DHU-11 TRANSMIT BUFFER 2 REGISTER ADDRESS
TXBFCA:: .WORD 160036 ;DHU-11 TRANSMIT BUFFER COUNT REGISTER ADDRESS

; REGISTER MESSAGE ADDRESS TABLE

RMATBB:: .WORD DR00MG ;ADDRESS OF "CSR" MESSAGE.
.WORD DR02MG ;ADDRESS OF "RBUF" MESSAGE.
.WORD DR04MG ;ADDRESS OF "LPR" MESSAGE.
.WORD DR06MG ;ADDRESS OF "STAT" MESSAGE.
.WORD DR10MG ;ADDRESS OF "LNCTRL" MESSAGE.
.WORD DR12MG ;ADDRESS OF "TBUFFAD1" MESSAGE.
.WORD DR14MG ;ADDRESS OF "TBUFFAD2" MESSAGE.
.WORD DR16MG ;ADDRESS OF "TBUFFCT" MESSAGE.

; ASSORTED GLOBAL VARIABLES:

BUFPTR:: .WORD 0 ;STORAGE FOR RECEIVE CHARACTER BUFFER POINTER.
EXOERR:: .WORD 0 ;"EXIT ON ERROR" FLAG.
CTRLCF:: .WORD 0 ;STORAGE FOR THE CONTROL-C FLAG.
IESTAT:: .WORD 0 ;STORAGE FOR THE INTERRUPT ENABLE BIT STATES.
PASCNT:: .WORD 0 ;STO'G FOR PASS COUNT USED IN ROM VERSION TEST.
RXINTC:: .WORD 0 ;STORAGE FOR RECEIVER INTERRUPT FLAGS.


```

1334 002316 000000 RXINTF:: .WORD 0 ;STORAGE FOR RECEIVER INTERRUPT FLAGS.
1335 002320 000000 TP4FLG:: .WORD 0 ;FLAGS SET WHEN AN EXPECTED 004 TRAP OCCURS.
1336 002322 000000 TP4VEC:: .WORD 0 ;STORAGE FOR THE NORMAL 004 TRAP VECTOR.
1337 002324 000001 TSTNUM:: .WORD 1 ;STORAGE FOR THE TEST NUMBER.
1338 002326 000000 TXINTC:: .WORD 0 ;STORAGE FOR TRANSMIT INTERRUPT COUNT.
1339 002330 000000 TXINTF:: .WORD 0 ;STORAGE FOR TRANSMIT INTERRUPT FLAGS.
1340 002332 000000 WORD1:: .WORD 0 ;LOCATION FOR PASSING INDIRECT PARAMETERS.

```

1341

1342

1343

1344

1345 002334 177546

1346 002336 000300

1347 002340 000100

1348 002342 000074

1349 002344 000000

1350 002346 000000

1351 002350 000170

1352 002352 000170

1353 002354 000021

1354 002356 000062

1355

1356

1357

1358

1359 002360 177572

1360 002362 000000

1361 002364 000000

1362 002366 172340

1363

1364

1365

1366

1367 002370 137660

1368 002372 177777

1369 002374 000007

1370 002376 177777

1371 002400 166051

1372 002402 000000

1373 002404 177774

1374 002406 000000

1375

1376

1377

1378

1379 002410 000001

1380 002412 000002

1381 002414 000004

1382 002416 000010

1383 002420 000020

1384 002422 000040

1385 002424 000100

1386 002426 000200

1387 002430 000400

1388 002432 001000

1389 002434 002000

1390 002436 004000

```

;*****
; LINE TIME CLOCK VARIABLES AND STORAGE.
;*****

```

```

CLKCSR:: .WORD 177546 ;CSR ADDRESS OF THE LTC.
CLKBRL:: .WORD PRI06 ;INTERRUPT PRIORITY LEVEL OF THE LTC.
CLKVEC:: .WORD 100 ;INTERRUPT VECTOR ADDRESS OF THE LTC.
CLKHRZ:: .WORD 60. ;INTERRUPT FREQUENCY OF THE LTC.
TIMER1:: .WORD 0 ;HARDWARE CLOCK COUNTER #1.
TIMER2:: .WORD 0 ;HARDWARE CLOCK COUNTER #2.
TIMER3:: .WORD 120. ;HARDWARE BREAK COUNTER LOCATION.
BCOUNT:: .WORD 120. ;BREAK COUNT VALUE IN CLOCK TICKS.
MSTICK:: .WORD 17. ;NUMBER OF MILLI-SECONDS PER LTC TICK.
MSLCNT:: .WORD 62 ;LOOP COUNT (USED BY MSLOOP) TO DELAY 1 MS.

```

```

;*****
; MEMORY MANAGEMENT VARIABLES AND FLAGS.
;*****

```

```

MMSRO:: .WORD 177572 ;ADDRESS OF MEM MGT STATUS REGISTER #0.
MMPRES:: .WORD 0 ;MEM MGT PRESENT FLAG (0 IF MM NOT PRESENT).
MMENAB:: .WORD 0 ;MEM MGT ENABLED FLAG (0 IF MM NOT ENABLED).
PAROA:: .WORD 172340 ;ADDRESS OF MEM MGT PAR #0.

```

```

;*****
; BIT MASK TABLE OF UN-USED DMU DEVICE REGISTER BITS.
;*****

```

```

UNBITB:: .WORD 137660 ;UNUSED BIT MASK FOR THE CSR
          .WORD 177777 ;UNUSED BIT MASK FOR THE RBUF/RXTIMER REG
          .WORD 7 ;UNUSED BIT MASK FOR THE LPR
          .WORD 177777 ;UNUSED BIT MASK FOR THE STAT/FIFOSIZE/DATA REG
          .WORD 166051 ;UNUSED BIT MASK FOR THE LNCTRL
          .WORD 0 ;UNUSED BIT MASK FOR THE TBUFAD1
          .WORD 177774 ;UNUSED BIT MASK FOR THE TBUFAD2
          .WORD 0 ;UNUSED BIT MASK FOR THE TBUFFT

```

```

;*****
; TABLE OF WORDS WITH CORRESPONDING BIT SET FOR GENERATION OF BIT MAPS.
;*****

```

```

BITTBL:: .WORD 1 ;BIT 0 SET.
          .WORD 2 ;BIT 1 SET.
          .WORD 4 ;BIT 2 SET.
          .WORD 10 ;BIT 3 SET.
          .WORD 20 ;BIT 4 SET.
          .WORD 40 ;BIT 5 SET.
          .WORD 100 ;BIT 6 SET.
          .WORD 200 ;BIT 7 SET.
          .WORD 400 ;BIT 8 SET.
          .WORD 1000 ;BIT 9 SET.
          .WORD 2000 ;BIT 10 SET.
          .WORD 4000 ;BIT 11 SET.

```

1391 002440 010000
 1392 002442 020000
 1393 002444 040000
 1394 002446 100000
 1395
 1396
 1397
 1398
 1399 002450
 1400 002450 000000
 1401 002452 000000
 1402 002454 000000
 1403 002456 000000
 1404 002460 000000
 1405
 1406
 1407
 1408
 1409 002462 000000
 1410 002464
 1411
 1412
 1413
 1414
 1415 002524 000000
 1416 002526
 1417 002726
 1418
 1419
 1420
 1421
 1422 002726
 1423 002726
 1424 003326
 1425 003526
 1426 003726
 1427 003726
 1428
 1429
 1430
 1443 003766
 003766
 003766 000000
 003770 000000
 003772 000000
 003774 000000
 1444
 1445

```

        .WORD 10000          ;BIT 12 SET.
        .WORD 20000          ;BIT 13 SET.
        .WORD 40000          ;BIT 14 SET.
        .WORD 100000         ;BIT 15 SET.

;*****
;*      GPR SAVE AREA ZERO.
;*****
GPRSOB::          ;BASE OF GPR SAVE AREA NUMBER ZERO.
        .WORD 0              ;WORD 1, STORAGE FOR R1.
        .WORD 0              ;WORD 2, STORAGE FOR R2.
        .WORD 0              ;WORD 3, STORAGE FOR R3.
        .WORD 0              ;WORD 4, STORAGE FOR R4.
        .WORD 0              ;WORD 5, STORAGE FOR R5.

;*****
;*      TRANSMISSION AND RECEPTION VARIABLES, POINTERS, AND FLAGS.
;*****
ERSMRF:: .WORD 0          ;ERROR SUMMARY REPORT FLAGS.
ERCNTB:: .BLKW 16.       ;TABLE OF ERROR COUNTERS.

;*****
;      STORAGE AREA FOR THE BMP CODE QUEUE.
;*****
BMPCQP:: .WORD 0          ;POINTER USED TO ACCESS THE NEXT CELL IN QUE.
BMPCQB:: .BLKW 64.       ;STORAGE FOR 32 CELLS, TEST# PLUS BMP CODE.
BMPCQE::          ;LAST ADDRESS PLUS 2 OF THE BMP CODE QUEUE.

;*****
;      GENERAL TABLE AND BUFFER AREA--513 WORDS.
;*****
BUFBAS::          ;BASE OF MEMORY BUFFER.
ERLTBL:: .BLKW 128.      ;FIRST HALF OF GENERAL TABLE OR BUFFER.
BUFMID:: .BLKW 64.       ;SECOND HALF OF GENERAL TABLE OR BUFFER.
BUF3QT:: .BLKW 64.       ;LAST QUARTER OF THE BUFFER AREA.
BUFEND::          ;END OF GENERAL PURPOSE MEMORY BUFFER.
ENDETB:: .BLKW 16.       ;BUFFER OVERFLOW SPACE.

ERRTBL
L$ERRTBL::

ERRTYP:: .WORD 0
ERRNBR:: .WORD 0
ERRMSG:: .WORD 0
ERRBLK:: .WORD 0

.EVEN

```

1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483

```

.SBTTL GPR HANDLING ROUTINES FOR SUBROUTINE CALLS.
;*****
;* THERE ARE 4 ROUTINES AND MACRO DEFINITIONS USED FOR THE HANDLING OF
;* GPR VALUES DURING SUBROUTINE CALLS WITHIN THIS PROGRAM. THE FOUR
;* ROUTINES/MACRO CALLS HAVE THE FOLLOWING NAMES:
;*
;* SAVE MACRO DEFINITION USED AT THE BEGINNING OF A SUBROUTINE TO
;* SAVE THE GPR CONTENTS FOR LATER RESTORATION.
;* PASS - MACRO DEFINITION USED AT THE END OF A SUBROUTINE TO RESTORE
;* THE PREVIOUSLY SAVED GPR CONTENTS AND TO LEAVE THE CONTENTS
;* OF THE SPECIFIED GPR(S) INTACT (NOT RESTORED).
;* PREG05 SUBROUTINE WHICH IS CALLED FROM THE SAVE AND PASS MACRO
;* EXPANSIONS WHICH ACTUALLY PERFORMS THE ACTIONS ON THE GPRS.
;*
;* DURING A SUBROUTINE WHICH USES THESE GPR SAVE ROUTINES THE VALUES
;* OF THE GPRS ARE STORED ON THE STACK IN THE FOLLOWING STACK FRAME:
;*
;* SP -> RET PC INTO PREG05 ROUTINE.
;* SP+2 -> GPR R0 CONTENTS.
;* SP+4 -> GPR R1 CONTENTS.
;* SP+6 -> GPR R2 CONTENTS.
;* SP+8 -> GPR R3 CONTENTS.
;* SP+10 -> GPR R4 CONTENTS.
;* SP+12 -> GPR R5 CONTENTS.
;* SP+14 -> RET PC INTO CALLER OF SUB'TNE WHICH CALLED PREG05.
;*
;* EACH LEVEL OF SUB'TNE CALLING USES 8 WORDS OF STACK OVERHEAD.
;* THE SAVE AND PASS MACROS CAN ALSO BE USED IN "STRAIGHT LINE CODE"
;* TO SAVE AND RESTORE THE GPR VALUES. IN ANY CASE, AFTER THE
;* ISSUING OF A PASS CALL THE GPRS WILL BE RESTORED TO THE VALUES
;* THEY HAD PRIOR TO THE LAST SAVE CALL (EXCEPT FOR THE EXCEPTED,
;* OR PASSED INTACT, GPRS SPECIFIED AS PARAMETERS TO THE PASS CALL)
;* AND THE SP WILL ALSO BE RESTORED TO ITS CONDITION BEFORE THE LAST
;* SAVE CALL. THE PROGRAMMER MUST BE SURE THAT THE SP HAS THE SAME
;* VALUE WHEN THE PASS MACRO IS CALLED AS IT HAD IMMEDIATELY AFTER
;* THE SAVE MACRO WAS CALLED.
;*****

```

1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499

000036
000016
000014
000012
000010
000006
000004
000002

.SBTTL GPR FRAME ACCESS EQUATES

;***
;EQUATES THAT ALLOW ACCESS TO THE STACK FRAME. THESE ARE THE
;OFFSETS INTO THE STACK FOR REGISTERS SAVED DURING THE PREGOS
;ROUTINE.
;-
LPCSLT== 36 ;OFFSET FOR LAST RETURN PC.
PCSLT== 16 ;OFFSET FOR RETURN PC.
R5SLOT== 14 ;OFFSET FOR R5.
R4SLOT== 12 ;OFFSET FOR R4.
R3SLOT== 10 ;OFFSET FOR R3.
R2SLOT== 6 ;OFFSET FOR R2.
R1SLOT== 4 ;OFFSET FOR R1.
R0SLOT== 2 ;OFFSET FOR R0.

1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524

```
.SBTTL GLOBAL MACRO DEFINITION - SAVE
:*****
:* THIS MACRO IS USED AT THE BEGINNING OF A SUBROUTINE TO SAVE THE
:* CONTENTS OF THE GPRS R0 THRU R5.
:*
:* INPUTS: SP UNCHANGED SINCE SUBROUTINE WAS ENTERED
:* R5SL0T - OFFSET TO STACK SLOT FOR R5 (EQUATED TO 14 OCTAL)
:*
:* OUTPUTS: GPR SAVE AREA ON THE STACK IS LOADED WITH THE CONTENTS OF GPRS
:* TOP OF STACK LOADED WITH THE RETURN ADDRESS INTO PREG05
:*
:* CALLING SEQUENCE: SAVE
:*
:* COMMENTS: NO ARGUMENTS ARE ALLOWED.
:* THE PASS MACRO SHOULD BE CALLED TO RESTORE THE GPR VALUES.
:*
:* SUBORDINATE ROUTINES CALLED: PREG05.
:*****

.MACRO SAVE
.LIST JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
.NLIST
.ENDM SAVE
```

1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573

```
.SBTTL GLOBAL MACRO DEFINITION - PASS
;*****
;* THIS MACRO IS USED IN CONJUNCTION WITH THE SAVE MACRO. IT IS
;* CALLED AT END OF A SUBROUTINE TO PASS PARAMETERS IN GPRS BACK TO THE
;* CALLING ROUTINE BY ALTERING THE GPR SAVE AREA ON THE STACK AND THEN
;* RETURNING TO PREG05 TO RESTORE THE GPRS TO THEIR SAVED VALUES.
;*
;* INPUTS: ONLY ALLOWED ARGUMENTS ARE "R0" THRU "R5".
;* ROSLOT THRU R5SLOT MUST BE EQUATED TO THEIR RESPECTIVE GPR SAVE
;* SLOT OFFSETS BEFORE CALLING THIS MACRO.
;*
;* OUTPUTS: THE GPR VALUES ARE PUT IN THEIR RESPECTIVE SLOTS ON THE STACK.
;*
;* CALLING SEQUENCE: PASS R0,R1,...
;*
;* COMMENTS: ANY COMBINATION OF GPR ARGUMENTS MAY BE LISTED IN ANY ORDER.
;* FOR EXAMPLE, THE FOLLOWING ARE LEGAL:
;* PASS R1
;* PASS R4,R0,R2
;* THE GPRS LISTED AS ARGUMENTS WILL BE PASSED INTACT TO THE
;* CALLING ROUTINE, ALL OTHER GPRS WILL BE RESTORED.
;* THE SP MUST BE AT ITS ORIGINAL VALUE WHEN PASS IS CALLED.
;*
;* THE MACRO CALL
;* PASS R0,R3
;* EXPANDS INTO THE FOLLOWING ASSEMBLY CODE:
;* MOV R0,ROSLOT(SP) ;PUT R0 IN STACK SLOT.
;* MOV R3,R3SLOT(SP) ;PUT R3 IN STACK SLOT.
;* JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
;* IN THIS EXAMPLE GPRS R1, R2, R4, AND R5 WILL BE RESTORED TO
;* THEIR VALUES CONTAINED IN THE STACK FRAME AND R0 AND R3
;* WILL BE LEFT AT THEIR VALUES PRIOR TO THIS PASS CALL.
;*
;* SUBORDINATE ROUTINES CALLED: (PREGRT - LABEL WITHIN PREG05, VALUE ON STACK.)
;*****
; .MACRO PASS A,B,C,D,E,F
; .IRP X,<A,B,C,D,E,F>
; .IF NB,X
; .LIST
; MOV X,X'SLOT(SP) ;PUT X IN STACK SLOT.
; .NLIST
; .ENDC
; .ENDM
; .LIST
; JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
; .NLIST
; .ENDM PASS
```

1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600 003776
1601 003776 010446
1602 004000 010346
1603 004002 010246
1604 004004 010146
1605 004006 010046
1606 004010 010546
1607 004012 016605 000014
1608
1609 004016 004736
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619 004020 012605
1620 004022 012600
1621 004024 012601
1622 004026 012602
1623 004030 012603
1624 004032 012604
1625
1626 004034 000205
1627

```
.SBTTL GLOBAL SUBROUTINE - PREG05 -
;*****
;* PPFERVE REGISTERS R0 THROUGH R5 FOR SUBROUTINE CALLS.
;*
;* INPUTS: THE RETURN ADDRESS BACK INTO THE CALLING ROUTINE MUST BE IN
;* GPR R5. (I.E. MACROS USE "JSR R5,PREG05".)
;*
;* OUTPUTS: REGISTERS R0 THROUGH R5 ARE SAVED ON THE STACK.
;*
;*CALLING SEQUENCE: SAVE ;MACRO EXPANSION CALLS PREG05.
;* [SUBROUTINE CODE]...
;* PASS ;MACRO EXPANSION RECALLS PREG05.
;*
;*COMMENTS: THIS ROUTINE IS RE-ENTRANT.
;*
;* PARAMETERS MAY BE PASSED OUT OF A SUBROUTINE BY MODIFYING THE
;* REGISTER SAVE AREA ON THE STACK. USE THE PASS GPRN MACRO
;* TO RETURN GPR VALUES INTACT.
;* USE THE RNSLOT OFFSETS FROM THE SP TO PASS OTHER PARAMETERS.
;* [EXAMPLE: MOV VALUE,ROSLOT(SP) ]
;* MAKE SURE THE SP IS AT ITS ORIGINAL VALUE WHEN YOU DO THIS.
;*
;*SUBORDINATE ROUTINES CALLED: NONE.
;*****
PREG05: ;R5 HAS BEEN LOADED ON THE STACK BY THE SUBROUTINE CALL
MOV R4,-(SP) ;SAVE R4
MOV R3,-(SP) ;SAVE R3
MOV R2,-(SP) ;SAVE R2
MOV R1,-(SP) ;SAVE R1
MOV R0,-(SP) ;SAVE R0
MOV R5,-(SP) ;PUSH RETURN PC ON TOP OF STACK
MOV R5SLOT(SP),R5 ;RESTORE R5 TO VALUE IT HAD BEFORE CALLS
JSR PC,@(SP)+ ;CALL THE SUBROUTINE AT THE RETURN ADDRESS
;FROM THE PREG05 CALL, PUTTING THE PRESENT
;PC ON THE STACK AS A RETURN ADDRESS INTO
;THIS (PREG05) ROUTINE.
;+++
;THE FOLLOWING CODE IS EXECUTED WHEN THE CALLING ROUTINE DOES A
;"RETURN" [JSR PC,@(SP)+] USING THE PC DEPOSITED ON THE STACK ABOVE.
;---
PREGRT: MOV (SP)+,R5 ;PUT RETURN PC IN R5.
MOV (SP)+,R0 ;RESTORE R0.
MOV (SP)+,R1 ;RESTORE R1.
MOV (SP)+,R2 ;RESTORE R2.
MOV (SP)+,R3 ;RESTORE R3.
MOV (SP)+,R4 ;RESTORE R4.
RTS R5 ;RETURN TO THE SUBROUTINE WHICH CALLED PREG05.
;RESTORING R5 IN THE PROCESS.
```

1629
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647

.SBTTL GLOBAL TEXT SECTION

; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
; MORE THAN ONE TEST.
;

; NAMES OF DEVICES SUPPORTED BY PROGRAM

DEVTYPE <DMU 11>

L#DVTYP::
.ASCIZ /DMU 11/

.EVEN

1649
1655
1656
1657

; TEST DESCRIPTION

DESCRIPT <DMU 11 FUNC TST PART1>

L#DESC::
.ASCIZ /DMU-11 FUNC TST PAR

.EVEN

1658
004046
004046
004046
004051
004054
004057
004062
004065
004070
004073

004036				
004036	104	110	125	
004041	055	061	061	
004044	000			
004046	104	110	125	
004051	055	061	061	
004054	040	106	125	
004057	116	103	040	
004062	124	123	124	
004065	040	120	101	
004070	122	124	061	
004073	000			

*1/

1659
1660
1667

.EVEN


```

1676
1677      .NLIST BIN
1678
1679      ; ***** FORMAT STATEMENTS USED IN PRINT CALLS *****
1680
1681 004074 EF0503:: .ASCIZ /#T#N/
1682 004101 EF0505:: .ASCIZ /#A      #D5#A ILLEGAL INTERRUPTS RECEIVED.#N/
1683 004154 EF1401:: .ASCIZ /#N#A ROM VERSION NUMBERS: PROC_1 = #D2#A(D)  PROC 2 = #D2#A(D)#N/
1684 004256 EF1402:: .ASCIZ /#T#A ROM VERSION NUMBER #T#N/
1685 004313 EF1601:: .ASCIZ /#A      #T#A. TEST ABORTED #N/
1686 004345 EF1602:: .ASCIZ /#A      EXPECTED DATA: #D6#A (D).#N/
1687 004407 EF1603:: .ASCIZ /#A      ACTUAL DATA: #D6#A (D).#N/
1688 004451 EF1604:: .ASCIZ /#A      BAD BIT(S) IN DEVICE #T#A REGISTER FOR LINE #D2#A (D).#N/
1689 004546 EF3001:: .ASCIZ /#A      EXPECTED OR CORRECT VALUE: #D3#N/
1690 004615 EF3002:: .ASCIZ /#A      ACTUAL OR MEASURED VALUE: #D3#N/
1691 004664 EF9006:: .ASCIZ /#A      #T#A #D2#A(D)#N/
1692 004710 EF9010:: .ASCIZ /#A      NUMBER OF ERRORS DETECTED ON LINE #D2#A IS #D5#N/
1693 004777 EF9016:: .ASCIZ /#A      UNEXPECTED #T#A FOR LINE #D2#A(D) IN FIFO AFTER RESET:#N/
1694 005074 EF9017:: .ASCIZ /#A      #T#A (WITH ERROR FLAGS) IS #D6#A(D)#N/
1695 005150 EF9018:: .ASCIZ /#A      #T#A IN SELFTEST CODE FIFO SLOT FOR LINE #D2/
1696 005230      .ASCIZ /#A(D) AFTER RESET.#N/
1697 005255 EF9301:: .ASCIZ /#A      #T#D2#A(D). BMP CODE REPORTED :#D3#A(D)#N/
1698 005333 EF9302:: .ASCIZ /#A      OVERFLOW OCCURRED (MORE THAN 31 BMP CODES FOUND IN QUEUE)#N/
1699 005433 MFUNIT:: .ASCIZ /#N#A TESTING UNIT :#D4#N/
1700      .EVEN
1701      .LIST BIN

```

```

1710
1711      .NLIST BIN
1712
1713
1714      ;***** GLOBAL ERROR MESSAGES *****
1715
1716 005464 DR00MG:: .ASCIZ /CSR/
1717 005470 DR02MG:: .ASCIZ /RBUF/
1718 005475 DR04MG:: .ASCIZ /LPR/
1719 005501 DR06MG:: .ASCIZ /FIFOSIZE,STAT/
1720 005517 DR10MG:: .ASCIZ /LNCTRL/
1721 005526 DR12MG:: .ASCIZ /TBUFFAD1/
1722 005537 DR14MG:: .ASCIZ /TBUFFAD2/
1723 005550 DR16MG:: .ASCIZ /TBUFFCT/
1724 005560 EM0103:: .ASCIZ /DEVICE REGISTER ACCESS ERRORS/
1725 005616 EM0201:: .ASCIZ / MASTER RESET TEST FAILED./
1726 005651 EM0202:: .ASCIZ / MASTER RESET BIT DID NOT CLEAR AFTER BOARD RESET./
1727 005735      .ASCIZ /      WAITED 5 SECONDS. BIT DEFECTIVE OR FIRMWARE HUNG./
1728 006024 EM0203:: .ASCIZ / MASTER RESET BIT CLEAR IMMEDIATELY AFTER BOARD RESET./
1729 006114      .ASCIZ /      BIT DEFECTIVE OR BOARD FIRMWARE ERROR./
1730 006167 EM0204:: .ASCIZ \ MR BIT WENT CLEAR WITHIN 1/2 SECOND OF BOARD RESET.\
1731 006255      .ASCIZ /      BIT DEFECTIVE OR SELFTEST WAS (INCORRECTLY) SKIPPED./
1732 006346 EM0301:: .ASCIZ /MASTER RESET (SKIP SELFTEST) TEST FAILED./
1733 006420 EM0302:: .ASCIZ / MR BIT CLR WITHIN 10 MILLISECOND AFTER BOARD RESET./
1734 006505      .ASCIZ /      BIT DEFECTIVE OR BOARD FIRMWARE ERROR./
1735 006560 EM0303:: .ASCIZ \ MR BIT WENT CLEAR 1/5 TO 5 SECONDS AFTER RESET.\
1736 006642      .ASCIZ /      SELFTEST DID NOT GET SKIPPED (SHOULD HAVE BEEN SKIPPED)./
1737 006737 EM0401:: .ASCIZ /RBUF REGISTER RX CHARACTER FIELD TEST FAILED./
1738 007015 EM0402:: .ASCIZ / IMPROPER CODE FOUND IN RX FIFO AFTER DUT RESET./
1739 007077      .ASCIZ /      EXPECTED: SELFTEST CODE,      ACTUAL: IMPROPER CODE./
1740 007165 EM0501:: .ASCIZ /RBUF REGISTER ERROR FLAGS FIELD TEST FAILED/
1741 007241 EM0502:: .ASCIZ / RX ERROR FLAG(S) FOUND CLEAR ON SELFTEST CODE./
1742 007322      .ASCIZ /      EXPECTED: ALL ERROR FLAGS SET,      ACTUAL: FLAG(S) CLEAR./
1743 007415 EM0525:: .ASCIZ / RX INTERRUPT(S) RECEIVED WITH RX INTERRUPTS DISABLED./
1744 007505 EM0526:: .ASCIZ / TX INTERRUPT(S) RECEIVED WITH TX INTERRUPTS DISABLED./
1745 007575 EM0601:: .ASCIZ /CSR RX.DATA.AVAIL BIT TEST FAILED/
1746 007637 EM0602:: .ASCIZ / RX.DATA.AVAIL BIT FOUND CLEAR AFTER RESET COMPLETION./
1747 007727      .ASCIZ /      EXPECTED BIT TO BE SET FROM SELFTEST CODES IN FIFO./
1748 010017 EM0603:: .ASCIZ / RX.DATA.AVAIL BIT COULD NOT BE CLEARED BY PURGING FIFO./
1749 010111      .ASCIZ /      600 CHARS READ FROM FIFO WITHOUT R.D.A BIT CLEARING./
1750 010202 EM0701:: .ASCIZ /RBUF RX.DATA.VALID BIT TEST FAILED/
1751 010245 EM0702:: .ASCIZ / RX.DATA.VALID BIT FOUND CLEAR AFTER RESET COMPLETION./
1752 010335      .ASCIZ /      EXPECTED BIT TO BE SET FROM SELFTEST CODES IN FIFO./
1753 010425 EM0703:: .ASCIZ / RX.DATA.VALID BIT COULD NOT BE CLEARED BY PURGING FIFO./
1754 010517      .ASCIZ /      600 CHARS READ FROM FIFO WITHOUT R.D.V BIT CLEARING./
1755 010610 EM0801:: .ASCIZ /RBUF RX.LINE.NUMBER FIELD TEST FAILED/
1756 010656 EM0802:: .ASCIZ / LINE NUMBER WRONG ON A SELFTEST CODE./
1757 010726 EM0901:: .ASCIZ /CHECK FOR BMP_CODES TEST FAILED/
1758 010766 EM0902:: .ASCIZ /UNEXPECTED BMP_CODES FOUND./
1759 011022 EM1001:: .ASCIZ /SKIP SELF-TEST TEST FAILED/
1760 011055 EM1002:: .ASCIZ / SKIP SELF-TEST TOOK TOO LONG TO COMPLETE, > 50 MS./
1761 011142 EM1003:: .ASCIZ / SKIP SELF-TEST COMPLETED TOO SOON, < 10 MS./
1762 011220 EM1101:: .ASCIZ /DIAGNOSTIC FAIL (SKP SELFTEST) TEST FAILED/
1763 011273 EM1201:: .ASCIZ /SELF-TEST TEST FAILED/
1764 011321 EM1202:: .ASCIZ \ SELF-TEST TOOK TOO LONG TO COMPLETE, > 5 SECONDS.\
1765 011405 EM1203:: .ASCIZ \ SELF-TEST COMPLETED TOO SOON, < 1/2 SECOND.\
1766 011463 EM1204:: .ASCIZ / SELF-TEST DID NOT EXECUTE/

```

```

1767 011517 EM1205:: .ASCIZ / DIAG_FAIL BIT BAD/
1768 011543 EM1301:: .ASCIZ /FAIL_SELF-TEST TEST FAILED/
1769 011576 EM1302:: .ASCIZ / SELF-TEST ERROR REPORTING BAD/
1770 011635 EM1401:: .ASCIZ /ROM VERSION NUMBER TEST FAILED/
1771 011674 EM1402:: .ASCIZ / FIFO EMPTY, ONE OR MORE ROM VERSION NUMBERS MISSING/
1772 011762 EM1403:: .ASCIZ / ROM_VERSION_NUMBER FOUND OUT OF SEQUENCE/
1773 012035 EM1404:: .ASCIZ / ONE OR MORE ROM_VERSION_NUMBERS MISSING/
1774 012107 EM1405:: .ASCIZ / PROC_1/
1775 012122 EM1406:: .ASCIZ / PROC_2/
1776 012135 EM1407:: .ASCIZ /NOT FOUND/
1777 012147 EM1408:: .ASCIZ /FOUND/
1778 012155 EM1501:: .ASCIZ /CSR BIT 4 TEST FAILED/
1779 012203 EM1502:: .ASCIZ /CSR BIT 4 BAD/
1780 012221 EM1601:: .ASCIZ /TIMEOUT OCCURRED WAITING FOR MASTER RESET TO CLEAR/
1781 012304 EM1604:: .ASCIZ \DEVICE REGISTER WORD READ/WRITE TEST FAILED\
1782 012360 EM1701:: .ASCIZ \DEVICE REGISTER WORD READ/MODIFY/WRITE TEST FAILED\
1783 012443 EM1801:: .ASCIZ \DEVICE REGISTER BYTE READ/WRITE TEST FAILED\
1784 012517 EM1901:: .ASCIZ \DEVICE REGISTER BYTE READ/MODIFY/WRITE TEST FAILED\
1785 012602 EM2001:: .ASCIZ /DEVICE STAT REGISTER ID BIT TEST FAILED/
1786 012652 EM2002:: .ASCIZ /ID BIT BAD. EXPECTED: SET, ACTUAL: CLEAR./
1787 012725 EM2301:: .ASCIZ /TX_ENABLE (INACTIVE) BIT TEST FAILED/
1788 012772 EM2302:: .ASCIZ / TX_ENABLE BIT BAD ON LINE: /
1789 013030 EM2401:: .ASCIZ /TX_ENABLE (ACTIVE) BIT TEST FAILED/
1790 013073 EM2501:: .ASCIZ /RECEIVE INTERRUPT TEST FAILED/
1791 013131 EM2602:: .ASCIZ / NO RX INT GENERATED (DATA_VALID SET, RX INTS ENABLED)./
1792 013222 EM2603:: .ASCIZ / NO RX INT GENERATED (NO CODES IN FIFO AFTER RESET)./
1793 013310 EM2604:: .ASCIZ / NO RX INT GENERATED (RX_DATA_AVAIL CLR, RX INTS ENABLED)./
1794 013404 EM2605:: .ASCIZ / RX INTERRUPT GENERATED WITH RX_DATA_AVAIL CLEAR./
1795 013467 EM2606:: .ASCIZ /TRANSMIT INTERRUPT TEST ERROR:/
1796 013526 EM2607:: .ASCIZ / TX_ACTION SET REPEATEDLY AFTER BOARD RESET, NO DATA SENT./
1797 013622 EM2608:: .ASCIZ / TX_ACTION STUCK SET AFTER BOARD RESET./
1798 013673 EM2609:: .ASCIZ / TX INTERRUPT GENERATED WITH TX_ACTION CLEAR./
1799 013752 EM2610:: .ASCIZ / NO TX INTERRUPT WITH TX_ACTION SET AND TX INTS ENABLED./
1800 014044 EM2611:: .ASCIZ / TX_ACTION NOT SET AFTER CHARS SENT ON ALL LINES./
1801 014127 EM2612:: .ASCIZ / NO RX INT GENERATED (RX_DATA_AVAIL SET, RX INTS ENABLED)./
1802 014223 EM3001:: .ASCIZ /INTERRUPT BR LEVEL TEST FAILED/
1803 014262 EM3002:: .ASCIZ / NO RX_DATA_AVAIL FROM SELFTEST CODES IN FIFO AFTER RESET./
1804 014356 EM3003:: .ASCIZ / TX INTERRUPT GENERATED AT WRONG BR LEVEL:/
1805 014432 EM3004:: .ASCIZ / RX INTERRUPT GENERATED AT WRONG BR LEVEL:/
1806 014506 EM3005:: .ASCIZ / TX INTERRUPT GIVEN PRECEDENCE OVER SIMULTANEOUS RX INT./
1807 014600 EM3101:: .ASCIZ /DIAGNOSTIC FIELD (BMP) TEST FAILED/
1808 014643 EM3102:: .ASCIZ / DIAGNOSTIC FIELD (BMP REQUEST) BAD ON LINE: /
1809 014722 EM9014:: .ASCIZ /SUMMARY REPORTS FOR LINES WITH EXCESSIVE NUMBERS OF ERRORS:/
1810 015016 EM9017:: .ASCII / FIFO WILL NOT PURGE (DATA_VALID STUCK SET),/
1811 015073 .ASCIZ / REMAINDER OF TEST SKIPPED./
1812 015127 EM9018:: .ASCIZ /NO CODE/
1813 015137 EM9019:: .ASCIZ /NON-SELFTEST/
1814 015154 EM9020:: .ASCIZ /SELFTEST ERROR CODE/
1815 015200 EM9022:: .ASCIZ /DATA CHARACTER/
1816 015217 EM9023:: .ASCIZ /MODEM STATUS CODE/
1817 015241 EM9024:: .ASCIZ /SELFTEST CODE/
1818 015257 EM9301:: .ASCIZ /BMP CODES WERE REPORTED DURING THIS DIAGNOSTIC/
1819 015336 EM9302:: .ASCIZ /BMP CODE FOUND IN TEST /
1820 015366 EM9303:: .ASCIZ /THE LAST BMP CODE WAS FOUND IN TEST /
1821 015433 EM9304:: .ASCIZ /UNEXPECTED BMP CODES FOUND DURING THIS PASS/
1822 .EVEN
1823 .LIST BIN
    
```

GLOBAL TEXT SECTION
1832
1833
1834
1835
1836
1837
1838
1839
1840

.SBTTL GLOBAL ERROR REPORT SECTION

; THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS
; USED BY MORE THAN ONE TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB
; (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
;--

1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865 015510
1866 015510
1867 015510 004567 166262
1868 015514 012700 000100
1869 015520 046700 164500
1870 015524 001036
1871
1872
1873
1874
1875 015526 032705 000001
1876 015532 001410
1877 015534
1878 015554 032705 000004
1879 015560 001410
1880 015562
1881 015602
015602 012746 015763
015606 012746 000001
015612 010600
015614 104415
015616 062706 000004

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ERO!01
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
;* INFORMATION IF AN ERROR IS DETECTED IN TEST I (REGISTER ADDRESS
;* ACCESS TEST). IF THE "EXTENDED ERROR INFO" OPTION HAS BEEN SELECTED
;* THEN THIS SUBROUTINE WILL REPORT THE TYPE OF ACCESS (READ OR WRITE OR
;* BOTH) WHICH CAUSED A BUS TIME-OUT TRAP (004 TRAP).A MESSAGE INDICATING
;* THAT THE DHU MAY BE AT THE WRONG UNIBUS ADDRESS IS ALSO PRINTED.
;*
;* INPUTS:      R5 - ERROR FLAG WORD.
;*              IF BIT 0 IS SET, A READ ERROR OCCURED.
;*              IF BIT 1 IS SET, A WRITE ERROR OCCURED.
;*
;* OUTPUTS:     MESSAGES ARE PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE:  INCLUDE THE LABEL "ERO101" AS THE MESSAGE POINTER
;*                   PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
                BGNMSG  ERO101
                SAVE          ;SAVE THE GPR CONTENTS.
                                JSR          ;CALL REGISTER SAVE SUBRT.
                                R5,PREG05
                MOV          #BIT06,R0      ;SET-UP THE BIT MAP FOR 'REPORT EXT'D ERROR INFO
                BIC          OPTION,R0      ;TRY AND CLEAR THE FLAG.
                BNE          6$            ;EXIT IF OPTION NOT SELECTED.
;+
; REPORT EXTENDED ERROR INFOMATION
;-
                BIT          #BIT0,R5      ;TEST FOR READ ERROR.
                BEQ          2$            ;SKIP READ ERROR MSG IF NO READ ERROR.
                PRINTB      #MSG1         ;PRINT READ ERROR MESSAGE.
                                MOV          #MSG1,-(SP)
                                MOV          #1,-(SP)
                                MOV          SP,R0
                                TRAP        C$PNTB
                                ADD          #4,SP
                2$:        BIT          #BIT1,R5      ;TEST FOR WRITE ERROR.
                BEQ          4$            ;SKIP WRITE ERROR MSG IF NO WRITE ERROR.
                PRINTB      #MSG2         ;PRINT WRITE ERROR MESSAGE.
                                MOV          #MSG2,-(SP)
                                MOV          #1,-(SP)
                                MOV          SP,R0
                                TRAP        C$PNTB
                                ADD          #4,SP
                4$:        PRINTX      #MSG3         ;SUGGEST THAT DHU MAY BE AT WRONG ADDRESS.
                                MOV          #MSG3,-(SP)
                                MOV          #1,-(SP)
                                MOV          SP,R0
                                TRAP        C$PNTX
                                ADD          #4,SP
```

```

1882 015622          6$: PASS          ;RESTORE THE GPR CONTENTS.
      015622 004736          JSR          PC,B(SP);RETURN TO PREGOS SUBRT.
1883 015624          ENDMSG          L10002: TRAP C$MSG
      015624 104423
1884
1885 015626 045 101 102 MSG1:: .ASCIZ /#ABUS TIME OUT TRAP CAUSED BY READ ATTEMPT.#N/
      015631 125 123 040
      015634 124 111 115
      015637 105 055 117
      015642 125 124 040
      015645 124 122 101
      015650 120 040 103
      015653 101 125 123
      015656 105 104 040
      015661 102 131 040
      015664 122 105 101
      015667 104 040 101
      015672 124 124 105
      015675 115 120 124
      015700 056 045 116
      015703 000
1886 015704 045 101 102 MSG2:: .ASCIZ /#ABUS TIME-OUT TRAP CAUSED BY WRITE ATTEMPT.#N/
      015707 125 123 040
      015712 124 111 115
      015715 105 055 117
      015720 125 124 040
      015723 124 122 101
      015726 120 040 103
      015731 101 125 123
      015734 105 104 040
      015737 102 131 040
      015742 127 122 111
      015745 124 105 040
      015750 101 124 124
      015753 105 115 120
      015756 124 056 045
      015761 116 000
1887 015763 045 101 104 MSG3:: .ASCIZ /#ADHU MAY BE AT THE WRONG UNIBUS ADDRESS.#N#N/
      015766 110 125 040
      015771 115 101 131
      015774 040 102 105
      015777 040 101 124
      016002 040 124 110
      016005 105 040 127
      016010 122 117 116
      016013 107 040 125
      016016 116 111 102
      016021 125 123 040
      016024 101 104 104
      016027 122 105 123
      016032 123 056 045
      016035 116 045 116
      016040 000
1888
1889

```

.EVEN

```

1891 .SBTTL GLOBAL ERROR REPORTING ROUTINE ERO201
1892 ;*****
1893 ;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS 2 CONTIGUOUS
1894 ;* ASCII ERROR MESSAGES. THE ADDRESS OF THE FIRST MESSAGE IS PASSED
1895 ;* AS AN INPUT PARAMETER AND THE ADDRESS OF THE SECOND IS FOUND BY
1896 ;* SEARCHING FOR THE END OF THE FIRST MESSAGE. THE MESSAGES ARE ONLY
1897 ;* PRINTED IF EXT'D ERROR REPORTING HAS BEEN REQUESTED.
1898 ;*
1899 ;* INPUTS: R1 ADDRESS OF THE FIRST MESSAGE TO PRINT.
1900 ;*
1901 ;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
1902 ;*
1903 ;* CALLING SEQUENCE: LOAD THE ADDRESS OF THE FIRST MESSAGE IN R1.
1904 ;* INCLUDE THE LABEL "ERO201" AS THE MESSAGE POINTER
1905 ;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
1906 ;*
1907 ;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
1908 ;* THE SECOND MESSAGE SHOULD FOLLOW THE FIRST ONE IN THE PROGRAM
1909 ;* MEMORY. EACH MESSAGE SHOULD BE DEFINED USING .ASCII7
1910 ;*
1911 ;* SUBORDINATE ROUTINES USED: NONE.
1912 ;*****
1913
1914 016042 BGNMSG ERO201 ERO201::
1915 016042 SAVE ;SAVE THE GPR CONTENTS.
1916 016042 004567 165730 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
1917 016046 012700 000100 MOV #BIT06,R0 ;TRY TO CLEAR THE
1918 016052 046700 164146 BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
1919 016056 001025 BNE 4$ ;EXIT IF FLAG NOT SET.
1920
1921 016060 010102 MOV R1,R2
1922 016062 105722 2$: TSTB (R2)+ ;CHECK FOR A ZERO BYTE (END OF MESSAGE).
1923 016064 001376 BNE 2$ ;LOOP UNTIL NEXT MESSAGE IS FOUND.
1924
1925 016066 PRINTB #EF0503,R1 ;PRINT THE FIRST MESSAGE.
1926 016066 010146 MOV R1,(SP)
1927 016070 012746 004074 MOV #EF0503,-(SP)
1928 016074 012746 000002 MOV #2,-(SP)
1929 016100 010600 MOV SP,R0
1930 016102 104414 TRAP C$PNTB
1931 016104 062706 000006 ADD #6,SP
1932 016110 PRINTB #EF0503,R2 ;PRINT THE SECOND MESSAGE.
1933 016110 010246 MOV R2,-(SP)
1934 016112 012746 004074 MOV #EF0503,-(SP)
1935 016116 012746 000002 MOV #2,-(SP)
1936 016122 010600 MOV SP,R0
1937 016124 104414 TRAP C$PNTB
1938 016126 062706 000006 ADD #6,SP
1939
1940 016132 4$: PASS ;RESTORE THE GPR CONTENTS.
1941 016132 004736 JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
1942
1943 016134 ENDMMSG
1944 016134 104423 L10003: TRAP C$MSG

```

1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER0503
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS AN ADDITIONAL ERROR
;* MESSAGE WHOSE ADDRESS IS PASSED AS AN INPUT PARAMETER, PROVIDED
;* EXTENDED ERROR REPORTING HAS BEEN REQUESTED.
;*
;* INPUTS: R1 ADDRESS OF THE MESSAGE TO PRINT.
;*
;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: LOAD THE ADDRESS OF THE MESSAGE IN R1.
;* INCLUDE THE LABEL 'ER0503' AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

1951 016136
016136

BGNMSG ER0503

ER0503::

1952
1953 016136 012700 000100
1954 016142 046700 164056
1955 016146 001011

```
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG NOT SET.
```

1956
1957

1958 016150
016150 010146
016152 012746 004074
016156 012746 000002
016162 010600
016164 104414
016166 062706 000006

PRINTB #EF0503,R1 ;PRINT THE MESSAGE.

```
MOV R1, -(SP)
MOV #EF0503, (SP)
MOV #2, (SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
```

1959
1960

016172
016172
016172 104423

2\$: ENDMSG

L10004:

TRAP C\$MSG

1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ER0504
;*****
; THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
; MESSAGES WHEN ILLEGAL INTERRUPTS ARE RECEIVED.
;
; INPUTS:      R1  ADDRESS OF THE MESSAGE TO PRINT.
;              R2  NUMBER OF ILLEGAL INTERRUPTS RECEIVED.
;
; OUTPUTS:     MESSAGESS ARE PRINTED AT THE OPERATOR CONSOLE.
;
; CALLING SEQUENCE:  LOAD THE ADDRESS OF THE MESSAGE IN R1.
;                   LOAD THE NUMBER OF ILLEGAL INTS IN R2.
;                   INCLUDE THE LABEL "ER0504" AS THE MESSAGE POINTER
;                   PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;
; COMMENTS:
;
; SUBORDINATE ROUTINES USED: NONE.
;*****
```

1982 016174
016174

BGNMSG ER0504

ER0504::

1983
1984
1985
1986
1987

016174 012700 000100
016200 046700 164020
016204 001022

```
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG NOT SET.
```

1988

016206
016206 010146
016210 012746 004074
016214 012746 000002
016220 010600
016222 104414
016224 062706 000006

PRINTB #EF0503,R1 ;PRINT THE FIRST LINE OF THE MESSAGE.

```
MOV R1,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C#PNTB
ADD #6,SP
```

1989

016230
016230 010246
016232 012746 004101
016236 012746 000002
016242 010600
016244 104415
016246 062706 000006

PRINTX #EF0505,R2 ;PRINT THE NUMBER OF INTS RECEIVED.

```
MOV R2,-(SP)
MOV #EF0505,(SP)
MOV #2,(SP)
MOV SP,R0
TRAP C#PNTX
ADD #6,SP
```

1990

1991

016252
016252
016252 104423

2\$: ENDMSG

L10005:

TRAP C#MSG

```

1993 .SBTTL GLOBAL ERROR REPORTING ROUTINE ER1401
1994 ;*****
1995 ;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
1996 ;* INFORMATION (IF REQUESTED DURING THE SOFTWARE QUESTIONS) IF AN ERROR
1997 ;* IS DETECTED IN THE ROM VERSION TEST. THIS SUBROUTINE ANALYSES THE INPUT
1998 ;* PARAMETERS WHICH CONTAIN THE ROM VERSION NUMBERS FOR PROC_1 AND PROC_2
1999 ;* AND REPORTS THE APPROPRIATE ERROR MESSAGE TO THE OPERATOR.
2000 ;*
2001 ;* INPUTS: R1 CONTAINS THE ADDRESS OF THE FIRST MESSAGE TO BE REPORTED.
2002 ;* R3 - CONTAINS THE ROM VERSION NUMBER OF PROC_1.
2003 ;* R4 CONTAINS THE ROM VERSION NUMBER OF PROC_2.
2004 ;*
2005 ;* OUTPUTS: BASIC AND EXTENDED ERROR MESSAGES ARE REPORTED AT THE
2006 ;* OPERATORS CONSOLE.
2007 ;*
2008 ;* CALLING SEQUENCE: INCLUDE THE LABEL "ER1401" AS THE MESSAGE POINTER
2009 ;* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
2010 ;*
2011 ;* COMMENTS:
2012 ;*
2013 ;* SUBORDINATE ROUTINES USED: NONE.
2014 ;*****
2015
2016 016254 BGNMSG ER1401
2017 016254 ER1401::
2018 016254 012700 000100 MOV #BIT06,R0 ;TRY TO CLEAR THE
2019 016260 046700 163740 BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
2020 016264 001053 BNE 60$ ;EXIT IF FLAG NOT SET.
2021
2022 016266 PRINTB #EF0503,R1 ;REPORT THE ERROR MESSAGE PASSED IN.
2023 016266 010146 MOV R1,-(SP)
2024 016270 012746 004074 MOV #EF0503,-(SP)
2025 016274 012746 000002 MOV #2,-(SP)
2026 016300 010600 MOV SP,R0
2027 016302 104414 TRAP C#PNTB
2028 016304 062706 000006 ADD #6,SP
2029
2030 ;*
2031 ; DETERMINE WHICH ROM VERSION NUMBER(S) ARE MISSING.
2032 ;*
2033
2034 016310 012705 000143 MOV #99,R5 ;GET INVALID ROM NUMBER.
2035 016314 012701 012107 MOV #EM1405,R1 ;SELECT PROC_1 MESSAGE.
2036 016320 012702 012135 MOV #EM1407,R2 ;SELECT THE "NOT FOUND" MESSAGE.
2037 016324 120305 CMPB R3,R5 ;CHECK PROC_1 ROM VERSION NUMBER.
2038 016326 001402 BEQ 2$ ;GO REPORT PROC_1 CODE NOT FOUND.
2039 016330 012702 012147 MOV #EM1408,R2 ;SELECT "FOUND" MESSAGE.
2040 016334 004767 000026 2$: JSR PC,50$ ;GO REPORT MESSAGE.
2041
2042 016340 012701 012122 MOV #EM1406,R1 ;SELECT PROC_2 MESSAGE.
2043 016344 012702 012135 MOV #EM1407,R2 ;SELECT THE "NOT FOUND" MESSAGE.
2044 016350 120405 CMPB R4,R5 ;CHECK PROC_2 ROM VERSION NUMBER.
2045 016352 001402 BEQ 4$ ;GO REPORT PROC_2 CODE NOT FOUND.
2046 016354 012702 012147 MOV #EM1408,R2 ;SELECT "FOUND" MESSAGE.
2047 016360 004767 000002 4$: JSR PC,50$ ;GO REPORT THE MESSAGE.
2048 016364 000413 BR 60$ ;EXIT.

```

2043
2044 016366
016366 010246
016370 010146
016372 012746 004256
016376 012746 000003
016402 010600
016404 104415
016406 062706 000010
2045 016412 000207
2046 016414
016414
016414 104423

50\$: PRINTX #EF1402,R1,R2 ;REPORT THE MESSAGE.

60\$: RTS PC ;RETURN.
ENDMSG

MOV R2, (SP)
MOV R1, (SP)
MOV #EF1402, (SP)
MOV #3, (SP)
MOV SP,R0
TRAP C#PNTX
ADD #10,SP

L10006:
TRAP C#MSG

```

2048 .SBTTL GLOBAL ERROR REPORTING ROUTINE ER1601
2049 ;*****
2050 ;* THIS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
2051 ;* INFORMATION IF AN ERROR IS DETECTED IN ONE OF THE DEVICE REGISTER
2052 ;* ACCESS TESTS, PROVIDED EXTENDED ERROR REPORTING HAS BEEN REQUESTED.
2053 ;* THIS SUBROUTINE REPORTS THE ACTUAL AND EXPECTED FROM THE DEVICE
2054 ;* REGISTER(S) WHICH IS(ARE) IN FAULTY.
2055 ;*
2056 ;* INPUTS: R1 - ACTUAL DATA (UNUSED BITS SET TO 0).
2057 ;* R2 - EXPECTED DATA (UNUSED BITS SET TO 0).
2058 ;* R3 OFFSET (IN BYTES) TO THE REGISTER BEING TESTED.
2059 ;* R5 LINE NUMBER OF REGISTER BEING TESTED.
2060 ;* RMATBB - LABEL AT BASE OF REGISTER MESSAGE ADDRESS TABLE.
2061 ;*
2062 ;* OUTPUTS: MESSAGES ARE PRINTED AT THE OPERATORS CONSOLE.
2063 ;*
2064 ;* CALLING SEQUENCE: INCLUDE THE LABEL "ER1601" AS THE MESSAGE POINTER
2065 ;* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
2066 ;*
2067 ;* COMMENTS:
2068 ;*
2069 ;* SUBORDINATE ROUTINES CALLED: NONE
2070 ;*****
2071 016416 BGNMSG ER1601
2072 016416 ER1601::
2073 016416 012700 000100 MOV #BIT06,R0 ;TRY TO CLEAR THE
2074 016422 046700 163576 BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
2075 016426 001036 BNE 2$ ;EXIT IF FLAG NOT SET.
2076
2077
2078 016430 016304 002262 MOV RMATBB(R3),R4 ;FETCH ADDRESS OF REGISTER NAME MESSAGE.
2079
2080 016434 PRINTB #EF1604,R4,R5 ;REPORT BASIC MESSAGE (REG NAME AND LINE #).
016434 010546 MOV R5,(SP)
016436 010446 MOV R4,-(SP)
016440 012746 004451 MOV #EF1604,(SP)
016444 012746 000003 MOV #3,(SP)
016450 010600 MOV SP,R0
016452 104414 TRAP C$PNTB
016454 062706 000010 ADD #10,SP
2081 016460 PRINTX #EF1602,R2 ;PRINT THE EXPECTED DATA.
016460 010246 MOV R2,-(SP)
016462 012746 004345 MOV #EF1602,-(SP)
016466 012746 000002 MOV #2,-(SP)
016472 010600 MOV SP,R0
016474 104415 TRAP C$PNTX
016476 062706 000006 ADD #6,SP
2082 016502 PRINTX #EF1603,R1 ;PRINT THE ACTUAL DATA.
016502 010146 MOV R1,(SP)
016504 012746 004407 MOV #EF1603,-(SP)
016510 012746 000002 MOV #2,-(SP)
016514 010600 MOV SP,R0
016516 104415 TRAP C$PNTX
016520 062706 000006 ADD #6,SP
2083 016524 2$: ENDMMSG
016524

```

L10007:

B5

CZDMCNO DMU 11 FUNC TST PART1
GLOBAL ERROR REPORTING ROUTINE

MACRO M1200 15 MAR 84 09:15 PAGE 44 1
ER1601

GE0 53

016524 104423

TRAP CMSG

```

2085 .SBTTL GLOBAL ERROR REPORTING ROUTINE ER1603
2086 ;*****
2087 ;* THIS ERROR REPORTING ROUTINE IS USED TO PRINT OUT A BASIC ERROR
2088 ;* MESSAGE, ALONG WITH A MESSAGE INFORMING THE OPERATOR WHICH TEST IS
2089 ;* ABOUT TO BE ABORTED, PROVIDED EXTENDED ERROR INFORMATION HAS BEEN
2090 ;* REQUESTED, OTHERWISE ONLY A "TEST FAILURE" MESSAGE WILL BE PRINTED.
2091 ;*
2092 ;* INPUTS: R1 CONTAINS THE ADDRESS OF THE MESSAGE TO BE PRINTED.
2093 ;* ERRMSG - CONTAINS THE ADDRESS OF THE MESSAGE THAT INDICATES
2094 ;* THE TEST THAT IS BEING PERFORMED, EG DMA, BREAK ETC.
2095 ;*
2096 ;* OUTPUTS: MESSAGES ARE PRINTED AT THE OPERATORS CONSOLE.
2097 ;* "TESTNAME TEST ABORTED"
2098 ;*
2099 ;* CALLING SEQUENCE: INCLUDE THE LABEL "ER1603" AS THE MESSAGE POINTER
2100 ;* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
2101 ;*
2102 ;* COMMENTS:
2103 ;*
2104 ;*
2105 ;* SUBORDINATE ROUTINES CALLED: NONE.
2106 ;*****
2107 016526 BGNMSG ER1603
2108 016526 ER1603::
016526 SAVE ;SAVE THE CONTENTS OF THE GPRS.
004567 165244 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2109
2110 016532 012700 000100 MOV #BIT06,R0 ;TRY TO CLEAR THE
2111 016536 046700 163462 BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
2112 016542 001024 BNE 2$ ;EXIT IF FLAG NOT SET.
2113
2114
2115 016544 PRINTB #EF0503,R1 ;PRINT BASIC MESSAGE ON OPERATORS CONSOLE.
016544 010146 MOV R1,(SP)
016546 012746 004074 MOV #EF0503,-(SP)
016552 012746 000002 MOV #2,-(SP)
016556 010600 MOV SP,R0
016560 104414 TRAP C$PNTB
016562 062706 000006 ADD #6,SP
2116
2117 016566 016702 165200 MOV ERRMSG,R2 ;GET THE "TEST MESSAGE".
2118 016572 PRINTB #EF1601,R2 ;PRINT "TEST ABORTED" MESSAGE.
016572 010246 MOV R2,-(SP)
016574 012746 004313 MOV #EF1601,-(SP)
016600 012746 000002 MOV #2,-(SP)
016604 010600 MOV SP,R0
016606 104414 TRAP C$PNTB
016610 062706 000006 ADD #6,SP
2119
2120 016614 2$: PASS ;RESTORE THE CONTENTS OF THE GPRS.
016614 004736 JSR PC,8(SP) ;RETURN TO PREG05 SUBRT.
2121 016616 ENDMMSG
016616 L10010: TRAP C$MSG
016616 104423

```

2123
 2124
 2125
 2126
 2127
 2128
 2129
 2130
 2131
 2132
 2133
 2134
 2135
 2136
 2137
 2138
 2139
 2140
 2141
 2142
 2143
 2144

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ER3001
;*****
; THIS IS AN ERROR REPORTING SUBROUTINE WHICH IS INTENDED FOR USE IN THE
; INTERRUPT BR LEVEL TEST. IT REPORTS ADDITIONAL INFORMATION WHEN AN
; INTERRUPT HAS OCCURRED AT THE WRONG BR LEVEL. UNLESS EXTENDED ERROR
; REPORTING HAS BEEN REQUESTED, ONLY THE TEST FAIL MESSAGE
; BE PRINTED.
;
; INPUTS: R1 ADDRESS OF MESSAGE TO PRINT FIRST.
; R4 - BR LEVEL AT WHICH THE INT REQUEST OCCURRED.
; R5 EXPECTED OR CORRECT BR LEVEL FOR THE DUT.
;
; OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
;
; CALLING SEQUENCE: INCLUDE THE LABEL "ER3001" AS THE MESSAGE POINTER
; PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;
; COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
;
; SUBORDINATE ROUTINES USED: NONE.
;*****
```

2145 016620
 016620

BGMMSG ER3001

ER3001::

2146
 2147 016620 012700 000100
 2148 016624 046700 163374
 2149 016630 001033

```
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG NOT SET.
```

2150
 2151 016632
 016632 010146
 016634 012746 004074
 016640 012746 000002
 016644 010600
 016646 104414
 016650 062706 000006

PRINTB #EF0503,R1 ;PRINT THE FIRST LINE OF THE MESSAGE.

```
MOV R1,-(SP)
MOV #EF0503,(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
```

2152 016654
 016654 010546
 016656 012746 004546
 016662 012746 000002
 016666 010600
 016670 104415
 016672 062706 000006

PRINTX #EF3001,R5 ;REPORT EXPECTED BR LEVEL.

```
MOV R5,(SP)
MOV #EF3001,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTX
ADD #6,SP
```

2153 016676
 016676 010446
 016700 012746 004615
 016704 012746 000002
 016710 010600
 016712 104415
 016714 062706 000006

PRINTX #EF3002,R4 ;REPORT ACTUAL BR LEVEL.

```
MOV R4,-(SP)
MOV #EF3002,-(SP)
MOV #2,(SP)
MOV SP,R0
TRAP C$PNTX
ADD #6,SP
```

2154
 2155 016720
 016720
 016720 104423

2\$: ENDMSG

L10011: TRAP C\$MSG

2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ER9004
;*****
; THIS IS AN ERROR REPORTING SUBROUTINE WHICH REPORTS ERROR SUMMARIES
; FOR LINES WHICH HAVE EXCEEDED THE SPECIFIED MAXIMUM NUMBER OF
; INDIVIDUAL RECEPTION ERRORS, PROVIDED EXTENDED ERROR REPORTING HAS
; BEEN REQUESTED BY THE OPERATOR.
;
; INPUTS: R1 - ADDRESS OF MESSAGE TO PRINT FIRST.
; ERCNTB - LABEL AT BASE OF LINE ERROR COUNTERS TABLE.
; ERSMRF "REPORT ERROR SUMMARY FOR LINE" FLAGS.
;
; OUTPUTS: A MESSAGE IS PRINTED AT THE OPERATOR CONSOLE.
;
; CALLING SEQUENCE: INCLUDE THE LABEL "ER9004" AS THE MESSAGE POINTER
; PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;
; COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
; THE CONTENTS OF GPR'S R2, R3, R4, AND R5 ARE DESTROYED.
;
; SUBORDINATE ROUTINES USED: NONE.
;*****
```

2179 016722

BGNMSG ER9004

ER9004::

2180 016722 012700 000100
2181 016726 046700 163272
2182 016732 001040
2183 016734
016734 012746 014722
016740 012746 004074
016744 012746 000002
016750 010600
016752 104414
016754 062706 000006
2184 016760 005002
2185 016762 016703 163474
2186 016766 005004
2187 016770 000241
2188 016772 006003
2189 016774 103013
2190 016776
016776 016446 002464
017002 010246
017004 012746 004710
017010 012746 000003
017014 010600
017016 104415
017020 062706 000010
2191 017024 012405
2192 017026 005202
2193 017030 005703
2194 017032 001356
2195 017034
017034
017034 104423

```
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 6$ ;EXIT IF FLAG NOT SET.
PRINTB #EF0503,#EM9014 ;REPORT THE SECONDARY ERROR MESSAGE.
MOV #EM9014,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP

CLR R2 ;CLEAR THE LINE COUNTER.
MOV ERSMRF,R3 ;GET THE ERROR SUMMARY FLAGS.
CLR R4 ;CLEAR "LINE COUNTER TIMES 2" OFFSET.
2$: CLC ;CLEAR THE CARRY FOR THE FOLLOWING ROTATE.
ROR R3 ;SHIFT ANOTHER ERROR SUMMARY FLAG INTO CARRY.
BCC 4$ ;SKIP PRINTING MESSAGE IF FLAG FOR LINE CLEAR.
PRINTX #EF9010,R2,ERCNTB(R4)
MOV ERCNTB(R4),-(SP)
MOV R2,-(SP)
MOV #EF9010,-(SP)
MOV #3,(SP)
MOV SP,R0
TRAP C$PNTX
ADD #10,SP

4$: MOV (R4)+,R5 ;INCREMENT THE LINE OFFSET BY 2.
INC R2 ;INCREMENT THE LINE COUNTER.
TST R3 ;CHECK THE ERROR SUMMARY FLAGS.
BNE 2$ ;IF MORE FLAGS SET, LOOP TO DO OTHER LINES.

6$: ENDMMSG

L10012: TRAP C$MSG
```


2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ER9007
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH IS USED TO REPORT THAT
;* SOMETHING OTHER THAN A SELFTTEST CODE WAS FOUND IN A SELFTTEST CODE
;* FIFO SLOT DURING THE REMOVAL OF THE SELFTTEST CODES FROM THE FIFO.
;* THIS ROUTINE IS USED BY THE RSTRPT ROUTINE. EXTENDED ERROR INFOMATION
;* IS GIVEN ONLY WHEN REQUESTED IN THE SOFTWARE QUESTIONS.
;*
;* INPUTS:      R1 - ADDRESS OF ERROR MESSAGE QUALIFIER STRING.
;*              R2 - INCORRECT CODE AS READ FROM THE SELFTTEST CODE FIFO SLOT.
;*              R3 - LINE NUMBER ASSOCIATED WITH THE SELFTTEST FIFO SLOT.
;*
;* OUTPUTS:     A MESSAGE IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE:  INCLUDE THE LABEL "ER9007" AS THE MESSAGE POINTER
;*                   PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS:     THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

2219 017036
017036
2220
2221 017036 012700 000100
2222 017042 046700 163156
2223 017046 001026
2224
2225 017050 042703 177760
2226 017054
017054 010346
017056 010146
017060 012746 005150
017064 012746 000003
017070 010600
017072 104414
017074 062706 000010
2227 017100
017100 010246
017102 010146
017104 012746 005074
017110 012746 000003
017114 010600
017116 104415
017120 062706 000010
2228
2229 017124
017124
017124 104423

```
BGNMSG ER9007 ER9007::
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG NOT SET.
BIC #177760,R3 ;REMOVE ALL BUT LINE # BITS FROM LINE # WORD.
PRINTB #EF9018,R1,R3 ;REPORT SECONDARY ERROR MESSAGE.
MOV R3,(SP)
MOV R1,-(SP)
MOV #EF9018,(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
PRINTX #EF9017,R1,R2 ;REPORT THE ACTUAL INCORRECT CODE.
MOV R2,-(SP)
MOV R1,-(SP)
MOV #EF9017,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTX
ADD #10,SP
2$: ENMSG L10013: TRAP C$MSG
```

2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250

2251 017126
017126

2252
2253
2254
2255
2256
2257
2258
2259
2260

2261 017140 010203
2262 017142 000303 163066
2263 017144 042703 177760
2264 017150
017150 010346
017152 010146
017154 012746 004777
017160 012746 000003
017164 010600
017166 104414
017170 062706 000010

2265 017174
017174 010246
017176 010146
017200 012746 005074
017204 012746 000003
017210 010600
017212 104415
017214 062706 000010

2266
2267

017220
017220 104423

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ER9008
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH IS USED TO REPORT THAT
;* AN UNEXPECTED CODE OR CHARACTER HAS BEEN FOUND IN THE DUT RECEIVE
;* CHARACTER FIFO. THE ADDITIONAL ERROR IS REPORTED ONLY IF REQUESTED
;* DURING THE SOFTWARE QUESTIONS.
;*
;* INPUTS: R1 ADDRESS OF PARTIAL ERROR MESSAGE STRING.
;* R2 INCORRECT CODE AS READ FROM THE SELFTEST CODE FIFO SLOT.
;*
;* OUTPUTS: A MESSAGE IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: INCLUDE THE LABEL "ER9008" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

BGNMSG ER9008

ER9008::

```
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG NOT SET.
```

```
;*
;* EXTRACT THE LINE NUMBER FROM THE INCORRECT CODE OR CHARACTER WHICH WAS READ
;* FROM THE SELFTEST CODE FIFO SLOT.
;*
```

```
MOV R2,R3
SWAB R3
BIC #177760,R3 ;CALCULATE LINE NUMBER OF CODE.
PRINTB #EF9016,R1,R3 ;REPORT TYPE OF INCORRECT CODE FOUND.
```

```
MOV R3,-(SP)
MOV R1,-(SP)
MOV #EF9016,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C#PNTB
ADD #10,SP
```

```
PRINTX #EF9017,R1,R2 ;REPORT THE ACTUAL INCORRECT CODE.
```

```
MOV R2,-(SP)
MOV R1,-(SP)
MOV #EF9017,-(SP)
MOV #3,(SP)
MOV SP,R0
TRAP C#PNTX
ADD #10,SP
```

2\$: ENDMSG

L10014:

TRAP C#MSG

2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ER9101
;*****
;* THIS IS A GENERAL ERROR REPORTING SUBROUTINE WHICH REPORTS A MESSAGE
;* WHICH TAKES A SINGLE, 2 DIGIT DECIMAL ARGUMENT AFTER THE END OF AN
;* ASCII MESSAGE.
;*
;* INPUTS: R1 VALUE TO BE PRINTED AFTER MSG AS 2 DECIMAL DIGITS.
;* W2 ADDRESS OF MESSAGE TO PRINT FIRST.
;*
;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: INCLUDE THE LABEL "ER9101" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

2288 017222
017222

BGNMSG ER9101

ER9101::

2289
2290
2291
2292
2293
2294

017222 012700 000100
017226 046700 162772
017232 001012

```
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG NOT SET.
```

2295

017234
017234 010146
017236 010246
017240 012746 004664
017244 012746 000003
017250 010600
017252 104414
017254 062706 000010

```
PRINTB #EF9006,R2,R1 ;REPORT THE STRING FOLLOWED BY THE NUMBER.
MOV R1,(SP)
MOV R2,-(SP)
MOV #EF9006,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
```

2296
2297

017260
017260
017260 104423

2\$: ENDMSG

L10015: TRAP C\$MSG

```

2299 .SBTTL GLOBAL ERROR REPORTING ROUTINE ER9301
2300 ;*****
2301 ;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ANY BMP CODES
2302 ;* THAT ARE FOUND IN THE BMP CODE QUEUE, TOGETHER WITH THE THE NUMBER OF
2303 ;* THE TEST THAT WAS EXECUTING AT THE TIME THE BMP CODE WAS LOGGED.
2304 ;* PROVIDED EXTENDED ERROR REPORTING HAS BEEN ENABLED.
2305 ;*
2306 ;* INPUTS: R1 THE ADDRESS OF THE FIRST MESSAGE TO BE REPORTED.
2307 ;* R2 THE ADDRESS OF THE NEXT EMPTY CELL IN THE QUEUE.
2308 ;*
2309 ;* OUTPUTS: THE TEST NUMBER FOLLOWED BY THE BMP CODE ARE PRINTED AT THE
2310 ;* OPERATOR CONSOLE.
2311 ;*
2312 ;* CALLING SEQUENCE: INCLUDE THE LABEL "ER9301" AS THE MESSAGE POINTER
2313 ;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
2314 ;*
2315 ;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
2316 ;*
2317 ;* SUBORDINATE ROUTINES USED: NONE.
2318 ;*****
2319
2320 017262 BGNMSG ER9301
2321 017262 ER9301::
017262 SAVE ;SAVE THE GPRS ON THE STACK.
017262 004567 164510 JSR R5,PREGOS ;CALL REGISTER SAVE SUBRT.
2322
2323 017266 012700 000100 MOV #BIT06,R0 ;TRY TO CLEAR THE
2324 017272 046700 162726 BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
2325 017276 001064 BNE 60$ ;EXIT IF FLAG NOT SET.
2326
2327 017300 PRINTB #EF0503,R1 ;REPORT UNEXPECTED BMP CODES FOUND.
017300 010146 MOV R1,(SP)
017302 012746 004074 MOV #EF0503,(SP)
017306 012746 000002 MOV #2,(SP)
017312 010600 MOV SP,R0
017314 104414 TRAP C$PNTB
017316 062706 000006 ADD #6,SP
2328 017322 012703 002526 MOV #BMPQCB,R3 ;GET THE START ADDRESS OF THE BMP CODE QUEUE.
2329 017326 012705 015336 MOV #EM9302,R5 ;GET THE MESSAGE TO BE REPORTED.
2330 017332 012301 2$: MOV (R3)+,R1 ;GET THE NUMBER OF THE TEST THAT WAS EXECUTING.
2331 017334 012304 MOV (R3)+,R4 ;GET BMP CODE THAT WAS REPORTED OFF THE QUEUE.
2332 017336 004767 C00056 JSR PC,50$ ;GO REPORT THE BMP CODE.
2333 017342 020302 CMP R3,R2 ;CHECK IF ALL CODES HAVE BEEN REPORTED.
2334 017344 103772 BLO 2$ ;IF IT IS NOT THE LAST BMP CODE THEN LOOP.
2335
2336 ;*
2337 ;* CHECK IF OVERFLOW HAS OCCURRED.
2338 ;* THE CONDITIONS FOR OVERFLOW ARE: THE POINTER CONTAINS THE ADDRESS OF THE
2339 ;* LAST CELL IN THE QUEUE, AND A BMP CODE HAS ALREADY BEEN WRITTEN INTO THAT
2340 ;* CELL.
2341 017346 020227 002722 CMP R2,#BMPQCB-4 ;CHECK IF THE POINTER IS AT THE LAST LOCATION.
2342 017352 001036 BNE 60$ ;EXIT IF NOT AT THE LAST LOCATION.
2343 017354 005762 000002 TST 2(R2) ;CHECK FOR A BMP CODE IN THE LAST CELL
2344 017360 001433 BEQ 60$ ;EXIT IF NO OVERFLOW HAS OCCURED, CELL EMPT.
2345 017362 012301 MOV (R3)+,R1 ;GET THE TEST NUMBER OFF THE QUEUE.
2346 017364 011304 MOV (R3),R4 ;GET THE BMP CODE OFF THE QUEUE.
2347 017366 012705 015366 MOV #EM9303,R5 ;SELECT THE MESSAGE TO BE REPORTED.

```

```

2348 017372          PRINTX #EF9302          ;REPORT OVERFLOW CONDITION.
      017372 012746 005333
      017376 012746 000001
      017402 010600
      017404 104415
      017406 062706 000004
2349 017412 004767 000002          JSR      PC,50$          ;REPORT THE LAST BMP CODE PLACED ON THE
2350 017416 000414          BR      60$          ;EXIT.
2351
2352 017420          50$: PRINTX #EF9301,R5,R1,R4 ;PRINT THE MESSAGE.
      017420 010446
      017422 010146
      017424 010546
      017426 012746 005255
      017432 012746 000004
      017436 010600
      017440 104415
      017442 062706 000012
2353 017446 000207          RTS      PC          ;RETURN.
2354 017450          60$: PASS          ;RESTORE THE GPR CONTENTS.
      017450 004736          JSR      PC,@(SP)+    ;RETURN TO PREGOS SUBRT.
2355
2356 017452          ENDMSG
      017452
      017452 104423          L10016: TRAP      C$MSG

```

2358
2366
2367
2368
2369
2370
2371

.SBTTL GLOBAL SUBROUTINES SECTION

; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
; THAT ARE USED IN MORE THAN ONE TEST.
;

2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396
2397
2398
2399
2400
2401
2402
2403
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428

017454
017454 004567 164316

017460 010400
017462 005100
017464 040002
017466 016705 162616

017472 000241
017474 006003
017476 103006
017500 010577 162536
017504 011100
017506 040400
017510 050200
017512 010011
017514 005205
017516 005703
017520 001365

```
.SBTTL GLOBAL SUBROUTINE                ALYFLD
;*****
; - ALTER DEVICE REGISTER FIELDS ROUTINE
; THIS SUBROUTINE ALTERS THE SPECIFIED FIELD OF THE SPECIFIED DEVICE
; REGISTER FOR THE SPECIFIED LINES.  THIS ROUTINE CAN BE USED TO SET
; OR CLEAR BITS WITHIN SELECTED FIELDS OF SELECTED REGISTERS.
; USE EXAMPLES:  SET RX.BAUD.RATE FIELDS ON LINES 3 AND 6.
;                CLEAR TX.DMA BITS ON ALL LINES.
;
; INPUTS:      R1 - ADDRESS OF THE REGISTERS TO ALTER.
;              R2 - BIT FIELDS SET TO DESIRED STATES.
;              R3 - BIT MAP OF LINES FOR WHICH TO ALTER REGISTER.
;              R4 - MASK OF BITS TO ALTER (1 INDICATES CHANGE BIT).
;              CSRA - CONTAINS THE ADDRESS OF THE DEVICE CSR.
;              IESTAT - SAVED STATES OF THE INTERRUPT ENABLE BITS.
;
; OUTPUTS:     DEVICE REGISTERS - SPECIFIED REGISTER FIELDS ALTERED.
;              CSR IND.ADR.REG FIELD - DESTROYED.
;
; CALLING SEQUENCE:  JSR    PC,ALYFLD
;
; COMMENTS:      THIS ROUTINE READS THE SPECIFIED REGISTERS FOR ALL LINES
;                WITH NUMBERS LOWER THAN THE HIGHEST SPECIFIED LINE.
;                THIS ROUTINE DOES NOT READ THE CSR.
;
; SUBROUTINES CALLED:  NONE.
;*****
ALYFLD:: SAVE                ;SAVE CONTENTS OF GPRS R0 THRU R5.
;                               JSR    R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;
; SET UP TO LOOP FOR EACH LINE:
;   PREPARE THE WORD TO BE ORED INTO THE REGISTER CONTENTS.
;   SET UP THE WORD TO WRITE INTO THE IND.ADR.REG FIELD OF THE CSR.
;
;
;   MOV    R4,R0                ;CALCULATE THE NEW CONTENTS OF THE
;   COM    R0                    ; REGISTER FIELDS WHICH ARE TO BE
;   BIC    R0,R2                ; ALTERED BY THIS ROUTINE.
;   MOV    IESTAT,R5            ;SET UP TO WRITE IND.ADR.REG FIELD TO 0.
;
; LOOP ONCE FOR EACH LINE, ALTERING THE SPECIFIED FIELD IN THE SPECIFIED
; REGISTER IF THE LINE HAS BEEN SELECTED FOR ALTERING.
; EXIT THE LOOP IF NO MORE LINES TO ALTER, OR IF WE HAVE ALTERED THE MAX
; ALLOWABLE NUMBER OF LINES (AS SPECIFIED BY NUMLNS).
;
;
;   CLC                        ;PREPARE FOR ROTATE, "TST R5" DOES THIS BELOW.
2$:   ROR    R3                    ;GET THE LINE SELECT BIT FOR THIS LINE.
;   BCC    4$                    ;SKIP SETUP IF LINE IS NOT SELECTED.
;   MOV    R5,@CSRA            ;SET OUT CSR IND.ADR.REG FIELD TO THIS LINE.
;   MOV    (R1),R0              ;GET THE PRESENT CONTENTS OF THE REG TO ALTER.
;   BIC    R4,R0                ;CLEAR THE BIT FIELDS WE ARE TO ALTER.
;   BIS    R2,R0                ;OR IN THE NEW STATES OF THE FIELDS.
;   MOV    R0,(R1)              ;WRITE THE NEW REGISTER CONTENTS TO THE REG.
4$:   INC    R5                    ;SET LINE NUMBER TO THE NEXT LINE.
;   TST    R3                    ;CHECK FOR UNHANDLED LINES, CLEAR CARRY FLAG.
;   BNE    2$                    ;LOOP IF SELECTED LINE(S) IS NOT HANDLED.
```

2429							
2430	017522		604:	PASS			;RESTORE GPRS.
	017522	004736				JSR	PC,@(SP).
2431	017524	000207		RTS	PC		;RETURN TO PREGOS SUBRT.
							;RETURN TO CALLING ROUTNE.


```

2433 .SBTTL GLOBAL SUBROUTINE CALMSL
2434 :* *****
2435 :* - CALIBRATE MILLI SECOND LOOP COUNT SUBROUTINE
2436 :* THIS SUBROUTINE CALIBRATES THE TIMING LOOP WHICH IS USED IN THE MSLOOP
2437 :* ROUTINE. THIS SUBROUTINE CALCULATES A VALUE FOR THE MSLCNT VARIABLE
2438 :* WHICH IS THE NUMBER OF SOFTWARE LOOPS WHICH TAKES 1 MS TO EXECUTE IN
2439 :* THE MSLOOP ROUTINE. THIS ROUTINE CALIBRATES THE COUNT BY USING THE
2440 :* LINE TIME CLOCK (LTC), SO IF NO LTC IS AVAILABLE THE DEFAULT VALUE FOR
2441 :* THE DELAY COUNT MUST BE USED.
2442 :*
2443 :*
2444 :* INPUTS: MSLCNT DEFAULT 1 MS DELAY LOOP COUNT VALUE, OR
2445 :* VALUE FROM PREVIOUS CALIBRATION.
2446 :* MSTICK NUMBER OF MS PER LTC CLOCK TICK.
2447 :* TIMER1 - TIMER COUNTER CHANGED BY LTC INTERRUPT SERVICE RTN.
2448 :* CLKHRZ - NUMBER OF LTC CLICKS PER SECOND (50 OR 60).
2449 :*
2450 :* OUTPUTS: CARRY - SET IF LTC IS AVAILABLE, AND NEW CALIBRATION PERFORMED.
2451 :* MSLCNT - NEW 1 MS DELAY LOOP COUNT VALUE IF LTC AVAILABLE, OR
2452 :* UNCHANGED IF NO LTC IS AVAILABLE.
2453 :*
2454 :* CALLING SEQUENCE: JSR PC,CALMSL
2455 :*
2456 :* COMMENTS:
2457 :*
2458 :* SUBORDINATE ROUTINES CALLED: UNSDIV,OOPS.
2459 :* - *****
2460
2461 017526 CALMSL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
2462 017526 004567 164244 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2463 017532 005067 000210 CLR 6$ ;CLEAR THE 2ND TIME FLAG.
2464 :*
2465 ; SYNCHRONIZE WITH THE LTC.
2466 017536 012705 000001 2$: MOV #1,R5 ;SET OUTER LOOP COUNTER TO 1 LOOP.
2467 ;INCREASE THE VALUE LOADED INTO THIS COUNTER IF THE <<<
2468 ;FOLLOWING LOOP FAILS ON FUTURE, FASTER PROCESSORS. <<<
2469 017542 005000 CLR R0 ;CLEAR THE WAIT FOR CLOCK INT COUNTER.
2470 017544 012767 000001 162572 MOV #1,TIMER1 ;SET UP COUNT OF 1 TO SYNCH WITH LTC.
2471 017552 005767 162566 4$: TST TIMER1 ;CHECK FOR COUNTER HAVING GONE TO ZERO.
2472 017556 001410 BEQ 6$ ;JUMP OUT OF LOOP IF LTC HAS INTERRUPTED.
2473 017560 005200 INC R0 ;COUNT THIS ITERATION OF THE INNER LOOP.
2474 017562 001373 BNE 4$ ;LOOP IF COUNTER HAS NOT TURNED OVER.
2475 017564 005305 DEC R5 ;DECREMENT THE INNER LOOP COUNTER.
2476 017566 003371 BGT 4$ ;LOOP IF OUTER LOOP COUNT NOT UP.
2477 :*
2478 ; IF WE GOT NO LTC INTERRUPT, INDICATE THAT THERE IS NO LTC AVAILABLE.
2479 ; LTC MUST BE FLAKEY, OR NOT REALLY AN LTC AT ALL.
2480 :
2481 017570 005067 162546 CLR CLKHRZ ;CLEAR LTC FREQUENCY WORD TO INDICATE NO LTC.
2482 017574 000241 CLC ;INDICATE FAILURE FOR RETURN.
2483 017576 000461 BR 60$ ;BYPASS THE FOLLOWING CALIBRATION PROCEDURES.
2484 :*
2485 ; WE ARE NOW SYNCHRONIZED WITH THE LTC.
2486 ; SET UP FOR THE CALIBRATION LOOP.
2487 :
2488 017600 012704 002344 6$: MOV #TIMER1,R4 ;WILL TEST TIMER1 IN THE LOOP BELOW.

```

B6

```

2489 017604 005001      CLR      R1      ;CLEAR THE OUTER LOOP COUNTER.
2490 017606 005002      CLR      R2      ;INDICATE TO CHECK ALL BITS OF TIMER1.
2491 017610 005003      CLR      R3      ;INDICATE TO CHECK FOR TIMER1 CLEAR.
2492 017612 012714 000001  MOV      #1,(R4)  ;LOAD TIMER1 WITH COUNT OF 1.
2493
2494 017616 016705 162534 81:      MOV      MSLCNT,R5  ;LOAD MS LOOP COUNT.
2495 017622 011400 101:      MOV      (R4),R0  ;GET THE TIMER1 VALUE.
2496 017624 010067 000120      MOV      R0,641  ;SAVE WORD (LIKE IN THE REAL LOOP).
2497 017630 040200      BIC      R2,R0  ;LEAVE ALL THE BITS.
2498 017632 020003      CMP      R0,R3  ;COMPARE AGAINST ZERO.
2499 017634 000261      SEC      ;SET CARRY IN CASE OF SUCCESS.
2500 017636 001406      BEQ      121  ;EXIT LOOP IF TIMER1 HAS CLEARED.
2501 017640 005305      DEC      R5  ;COUNT DOWN THE INSIDE MS LOOP COUNT.
2502 017642 001367      BNE      101  ;LOOP IF MS NOT UP.
2503 017644 005301      DEC      R1  ;DECREMENT THE MS TIME COUNT.
2504 017646 001363      BNE      81  ;KEEP LOOPING.
2505 017650 004767 000440  JSR      PC,OOPS  ;WE OVERFLOWED, SOMETHING IS WRONG, ABORT.
2506
2507 ;*
2508 ; WE HAVE NOW HAVE LOOP COUNT INFORMATION FOR ONE CLOCK TICK.
2509 ; WE HAVE NEGATIVE OF NUMBER OF OUTER LOOPS IN R1, EACH IS MSLCNT INNER LOOPS.
2510 ; WE HAVE THE PORTION OF THE LAST OUTER LOOP NOT EXECUTED, IN R5.
2511 ; NOW WE CALCULATE THE TOTAL NUMBER OF INNER LOOPS EXECUTED.
2512
2512 017654 005401 121:      NEG      R1  ;GET NUMBER OF OUTER LOOPS.
2513 017656 016702 162474      MOV      MSLCNT,R2  ;GET THE NUMBER OF INNER LOOPS PER OUTER LOOP.
2514 017662 010203      MOV      R2,R3  ;COPY NUMBER OF LOOPS FOR MULTIPLY.
2515 017664 160502      SUB      R5,R2  ;CALC # OF INNER LOOPS DONE IN LAST OUTER LOOP
2516 017666 010204      MOV      R2,R4  ; AND ADD TO ACCUMULATOR LSWORD.
2517 017670 005005      CLR      R5  ;CLEAR ACCUMULATOR MSWORD.
2518 017672 005301 141:      DEC      R1  ;CHECK R1 FOR 0 CONDITION
2519 017674 100403      BMI      161  ; SKIP MULTIPLICATION IF ZERO
2520 017676 060304      ADD      R3,R4  ;MULTIPLY NUMBER OF INNER
2521 017700 005505      ADC      R5  ; LOOPS PER OUTER LOOP BY
2522 017702 000773      BR      141  ;NUMBER OF OUTER LOOPS PERFORMED.
2523
2524 ;*
2525 ; DIVIDE THE TOTAL NUMBER OF INNER LOOPS BY THE NUMBER OF MS PER LTC TICK.
2526
2526 017704 016701 162444 161:      MOV      MSTICK,R1  ;# OF MS PER LTC TICK IS DIVISOR.
2527 017710 010403      MOV      R4,R3  ;LSWORD OF LOOP COUNT IS LSWORD OF DIVIDEND.
2528 017712 010502      MOV      R5,R2  ;MSWORD OF LOOP COUNT IS MSWORD OF DIVIDEND.
2529 017714 004767 003140  JSR      PC,UNSDIV  ;DIVIDE NUMBER OF LOOPS BY MS PER LTC TICK.
2530 017720 103402      BCS      181  ;BYPASS OOPS IF WE'RE OK.
2531 017722 004767 000366  JSR      PC,OOPS  ;CLOCK ROUTINES ARE NOT LONG ENOUGH, OR BUG.
2532 017726 010167 162424 181:      MOV      R1,MSLCNT  ;SET NEW VALUE FOR MS LOOP COUNT.
2533 017732 005167 000010      COM      R21  ;SET THE 2ND ITERATION FLAGS IF 1ST ITERATION.
2534 017736 001277      BNE      21  ;BRANCH IF ONLY ONE ITERATION DONE.
2535 017740 000261      SEC      ;SET THE SUCCESS FLAG FOR EXIT.
2536
2537 017742 601:      PASS  ;RESTORE GPRS,
2538 017742 004736      RTS      PC      JSR      PC,@(SP)  ;RETURN TO "REG05 SUBR".
2539 017744 000207      ; CARRY - SUCCESS FLAG. SET IF SUC.
2540
2540 017746 000000 621:      .WORD  0  ;2ND CALIBRATION ITERATION FLAGS.
2541 017750 000000 641:      .WORD  0  ;DUMMY WORD FOR STORAGE OF THE READ WORD.

```

2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574

017752 004567 164020
017756 005067 162336
017762 011011
017764 005767 162330
017770 000261
017772 001401
017774 000241
017776 004736
020000 000207

```

SBTTL GLOBAL SUBROUTINE                                CKTRAP
;*****
; CHECK TRAP ROUTINE
; THIS SUBROUTINE IS USED TO CHECK FOR A BUS TIME-OUT TRAP (004 TRAP)
; WHICH IS CAUSED BY AN ACCESS TO A NON EXISTENT MEMORY OR I/O LOCATION.
; IF THE TRAP DOES NOT OCCUR, THIS ROUTINE RETURNS A SUCCESS INDICATION.
;
; INPUTS:      R0  SOURCE ADDRESS FOR MOVE.
;              R1  DESTINATION ADDRESS FOR MOVE.
;              (R0) - SOURCE FOR THE MOVE.
;
; OUTPUTS:     (R1) WRITTEN TO THE CONTENTS OF (R0).
;              CARRY FLAG - SET ON RETURN IF NO 004 TRAP DETECTED.
;              TP4FLG - NONZERO IF TRAP OCCURRED, CLEARED OTHERWISE.
;
; CALLING SEQUENCE:  JSR    PC,CKTRAP
;
; COMMENTS:      IF THIS SUBROUTINE CAUSES A TRAP, EITHER THE ADDRESS WHICH
;                IS LABELED ADRPTR WILL BE THE TRAP PC ADDRESS ON THE STACK.
;
; SUBORDINATE ROUTINES CALLED: NONE.
;*****
CKTRAP:: SAVE                                ;SAVE CONTENTS OF GPRS R0 THRU R5.
;              JSR    R5,PREG05             ;CALL REGISTER SAVE SUBRT.
;              CLR    TP4FLG                ;CLEAR THE 004 TRAP FLAGS.
;              MOV    (R0),(R1)            ;PERFORM THE MOVE IN QUESTION.
ADRPTR:: TST    TP4FLG                      ;CHECK FOR OCCURENCE OF TRAP.
;              SEC                                ;INDICATE SUCCESS.
;              BEQ    601                    ;EXIT WITH SUCCESS IF TRAP DID NOT OCCUR.
;              CLC                                ;INDICATE FAILURE.
601:      PASS    ;RESTORE GPRS.
;              JSR    PC,8(SP)              ;RETURN TO PREG05 SUBRT.
;              RTS    PC
    
```

```

2576 .SBTTL GLOBAL SUBROUTINE - CLNRST
2577 ;*****
2578 ;* - CLEAN RESET OF THE DEVICE UNDER TEST
2579 ;* THIS SUBROUTINE IS USED TO RESET THE DUT TO A KNOWN STATE.
2580 ;* THE DUT'S SELF-TEST IS SKIPPED, AND THE FIFO IS PURGED OF ANY ERROR
2581 ;* CODES, ETC.
2582 ;* IF THE RESET DOES NOT SUCCESSFULLY COMPLETE, THEN THE CARRY BIT IS
2583 ;* PASSED BACK TO THE CALLING ROUTINE (CLEAR).
2584 ;*
2585 ;* INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR
2586 ;* TXBFCA CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
2587 ;* ERRNBR ERROR NUMBER FOR POSSIBLE ERROR REPORT.
2588 ;* ERRIBL - ERRIBL, ERRTYP, ERNBR, AND ERRMSG SET UP CORRECTLY.
2589 ;*
2590 ;* OUTPUTS: THE DUT PERFORMS ITS RESET FUNCTION INTO A KNOWN STATE.
2591 ;* CARRY - CLEAR INDICATES THE TEST IS TO BE ABORTED.
2592 ;* ERRIBL VALUE MAY BE DESTROYED.
2593 ;* IESTAT - TX AND RX INTERRUPT FLAGS ARE CLEARED.
2594 ;* TX AND RX INTERRUPT ENABLE BITS IN THE DUT'S CSR ARE CLEARED.
2595 ;*
2596 ;* CALLING SEQUENCE: JSR PC, CLNRST
2597 ;*
2598 ;* COMMENTS: THIS SUBROUTINE CAN REPORT ERRORS WITH NUMBERS ERRNBR.
2599 ;* THIS ROUTINE DOES NOT DESTROY THE VALUE OF ERRNBR.
2600 ;*
2601 ;* SUBORDINATE ROUTINES CALLED: DELAY, MSLGET, PUFIFO, RESETT.
2602 ;*****
2603
2604 020002 CLNRST:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
020002 004567 163770 R5, PREGOS ;CALL REGISTER SAVE SUBRT.
2605 ;*
2606 ;* RESET THE DUT.
2607 ;* THIS ROUTINE REPORTS ERRORS WITH NUMBERS FROM ERNBR THRU ERRNBR+2.
2608 ;
2609 020006 004767 001344 JSR PC, RESETT ;RESET THE DUT TO A KNOWN STATE.
2610 020012 103002 BCC 60$ ;EXIT ROUTINE WITH ABORT TEST INDICATOR.
2611 ;*
2612 ;* PURGE THE FIFO OF ERROR CODES, SAVE ANY BMP CODES FOUND.
2613 ;*
2614 020014 004767 000522 JSR PC, PUFIFO ;PURGE THE FIFO.
2615 ;*
2616 020020 60$: ;EXIT THE TEST USING RESETT OR PUFIFO STATUS.
2617 020020 PASS ;RESTORE GPRS, PASS THE FOLLOWING INTACT:
020020 004736 JSR PC, @ (SP)+ ;RETURN TO PREGOS SUBRT.
2618 ;CARRY BIT: IF CLEAR, THEN ABORT THE TEST.
2619 020022 000207 RTS PC

```

2621
2622
2623
2624
2625
2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642
2643

020024
020024 004567 163746
020030 012701 000020
020034 005020
020036 005301
020040 001375
020042
020042 004736
020044 000207

```

.SBTTL GLOBAL SUBROUTINE CLR16W
;*****
;* - CLEAR SIXTEEN WORDS ROUTINE
;* THIS SUBROUTINE CLEARS 16 WORDS STARTING WITH THE SPECIFIED WORD.
;*
;* INPUTS:      RO - ADDRESS OF THE FIRST WORD TO CLEAR.
;*
;* OUTPUTS:     (RO) TO (RO+15) - 16 WORDS OF MEMORY ARE CLEARED TO 0.
;*
;* CALLING SEQUENCE:  JSR      PC,CLR16W
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
; - *****

CLR16W:: SAVE          ;SAVE CONTENTS OF GPRS R0 THRU R5.
                    JSR      RS,PREG05 ;CALL REGISTER SAVE SUBRT.
                    MOV     #16.,R1   ;SET THE LOOP COUNTER TO 16.
2$: CLR             (R0). ;CLEAR A WORD OF MEMORY.
                    DEC     R1        ;COUNT THIS LOOP.
                    BNE     2$        ;LOOP IF NOT 16 WORD CLEARED.
60$: PASS          ;RESTORE GPRS.
                    JSR      PC,@(SP). ;RETURN TO PREG05 SUBRT.
                    RTS     PC

```

```

2645 .SBTTL GLOBAL SUBROUTINE CNTERR
2646 ;* *****
2647 ;* - COUNT ERROR ROUTINE
2648 ;* THIS SUBROUTINE IS USED TO COUNT A "DATA" ERROR ON THE SPECIFIED
2649 ;* LINE. IT CHECKS WHETHER ERROR SUMMARY REPORTING IS ACTIVE, OR SHOULD
2650 ;* BE MADE ACTIVE ON THIS LINE, AND ACTIVATES IT IF NECESSARY.
2651 ;*
2652 ;* INPUTS: R5 LINE NUMBER OF LINE UNDER CONSIDERATION.
2653 ;* ERCNTB LABEL AT BASE OF ERROR COUNTERS TABLE.
2654 ;* ERSMRF - ERROR SUMMARY FLAGS (BIT SET IF LINE IN SUMMARY MODE).
2655 ;* NDERPT NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE.
2656 ;*
2657 ;* OUTPUTS: CARRY SET IF LINE IS IN ERROR SUMMARY MODE.
2658 ;* ERCNT ERROR COUNTER INCREMENTED FOR SPECIFIED LINE.
2659 ;* ERSMRF - BIT SET IF LINE SHOULD BE IN SUMMARY MODE.
2660 ;*
2661 ;* CALLING SEQUENCE: JSR PC,CNTERR
2662 ;*
2663 ;* COMMENTS:
2664 ;*
2665 ;* SUBORDINATE ROUTINES CALLED: NONE.
2666 ;* - - - - -
2667
2668 020046 CNTERR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
020046 004567 163724 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2669 ;*
2670 ; COUNT THE ERROR ON THE COUNTER FOR THE SPECIFIED LINE.
2671 ;
2672 020052 006305 ASL R5 ;FORM WORD OFFSET FROM LINE NUMBER.
2673 020054 016501 002464 MOV ERCNTB(R5),R1 ;GET THE PRESENT ERROR COUNT FOR THIS LINE.
2674 020060 005201 INC R1 ;COUNT ERROR.
2675 020062 103402 BCS 2$ ;OVERFLOW? YES, DON'T UPDATE COUNTER IN TABLE.
2676 020064 010165 002464 MOV R1,ERCNTB(R5) ;UPDATE ERROR COUNTER TABLE ENTRY.
2677 020070 005767 162132 2$: TST NDERPT
2678 020074 001411 BEQ 60$ ;SUMMARYS DISABLED? YES, EXIT WITH CARRY 0.
2679 020076 020167 162124 CMP R1,NDERPT ;NO, CHECK FOR ENOUGH ERRORS FOR SUMMARY USE.
2680 020102 101002 BHI 4$ ;ENOUGH ERRORS TO USE SUMMARY? YES, GO HANDLE.
2681 020104 000241 CLC ;INDICATE NOT TO USE SUMMARY REPORT YET.
2682 020106 000404 BR 60$ ;EXIT WITH CARRY 0.
2683 020110 056567 002410 162344 4$: BIS BITTBL(R5),ERSMRF ;SET THE ERROR SUMMARY FLAG FOR LINE.
2684 020116 000261 SEC ;INDICATE TO USE SUMMARY REPORT.
2685 020120 60$: PASS ;RESTORE GPRS.
020120 004736 JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
2686 020122 000207 RTS PC

```

2688
2689
2690
2691
2692
2693
2694
2695
2696
2697
2698
2699
2700
2701
2702
2703
2704
2705
2706
2707
2708
2709
2710
2711
2712
2713
2714
2715
2716
2717

020124
020124 004567 163646
020130 010401
020132 012702 177777
020136 005003
020140 012704 020162
020144 004767 000130
020150 103002
020152 004767 000136
020156
020156 004736
020160 000207
020162 177777

```

.SBTTL GLOBAL SUBROUTINE                                DELAY
:*****
:*          DELAY SUBROUTINE -
:*          THIS SUBROUTINE IS USED TO DELAY A VARIABLE NUMBER OF MILLI-SECONDS.
:*
:* INPUTS:      R4  CONTAINS THE NUMBER OF MS TO DELAY.
:*              MSLCNT.
:*
:* OUTPUTS:     NONE.
:*
:* CALLING SEQUENCE:  JSR    PC,DELAY
:*
:* COMMENTS:     IF NO HARDWARE CLOCK INTERRUPTS ARE OCCURING, CONTROL-CS WILL
:*              NOT BE HONORED FOR THE DURATION OF THE DELAY.
:*
:* SUBORDINATE ROUTINES CALLED: NONE.
:*****
DELAY:: SAVE
                JSR    PC,DELAY
                ;SAVE CONTENTS OF GPRS R0 THRU R5.
                RS,PREG05 ;CALL REGISTER SAVE SUBRT.
                ;PASS NUMBER OF MS DELAY AS TIME-OUT VALUE.
                ;TELL MSLOOP ROUTINE TO CHECK ALL BITS.
                ;TELL MSLOOP RTN TO CHECK FOR ALL BITS CLEAR.
                ;TELL MSLOOP TO CHECK DUMMY NON ZERO WORD.
                ;DELAY THE REQUESTED # OF MS.
                ;EXIT ROUTINE IF WE TIMED-OUT.]
                ;IF NO TIME-OUT, BAD PROGRAM OR HOST MACHINE.
                ;RESTORE GPRS.
60$: PASS      JSR    PC,MSLOOP
                ;RETURN TO PREG05 SUBRT.
                PC,@(SP)+
                ;DUMMY, NON ZERO WORD.
62$: .WORD    1

```

```

2719 .SBTTL GLOBAL SUBROUTINE MSLGET
2720 ;*****
2721 ; - MILLI SECONDS LOOP WHICH RETURNS READ WORD AND REMAINING TIME
2722 ;* THIS SUBROUTINE IS A GENERAL PURPOSE TEST LOOP SUBROUTINE. IT IS USED
2723 ;* TO VERIFY THAT A CERTAIN ACTION OCCURS BEFORE A TIME OUT PERIOD. THE
2724 ;* CALLING ROUTINE PASSES IN WHICH BITS SHOULD BE SET AND CLEARED FOR THE
2725 ;* DESIRED CONDITION AND THE TIME-OUT VALUE IN MILLI SECONDS.
2726 ;* THIS ROUTINE CHECKS FOR THE DESIRED CONDITION UPON ENTRANCE INTO THE
2727 ;* ROUTINE AND THEN ONCE EACH MILLI-SECOND THERE AFTER.
2728 ;* UPON RETURN, THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION
2729 ;* IS RETURNED BY THIS SUBROUTINE.
2730 ;*
2731 ;* INPUTS: R1 - TIME-OUT VALUE IN MILLI-SECONDS (UP TO 64K MS).
2732 ;* R2 - BIT MAP OF BITS TO TEST (1 INDICATES TO TEST THE BIT).
2733 ;* R3 - DESIRED STATES OF THE INDICATED FIELDS IN R2.
2734 ;* R4 - ADDRESS OF THE WORD TO TEST.
2735 ;* MSLCNT - MILLI SECOND SOFTWARE LOOP COUNT.
2736 ;*
2737 ;* OUTPUTS: R0 - THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION.
2738 ;* R1 - REMAINING NUMBER OF MS IN TIME-OUT TIME.
2739 ;* CARRY - SUCCESS FLAG (SET IF CONDITION IS MET BEFORE TIME OUT).
2740 ;*
2741 ;* CALLING SEQUENCE: JSR PC,MSLGET
2742 ;*
2743 ;* COMMENTS: THIS ROUTINE WORKS WITH OR WITHOUT A HARDWARE CLOCK, BUT THE
2744 ;* CALIBRATION IS ONLY GUARENTEED WHEN A LINE CLOCK IS AVAILABLE
2745 ;* ON THE SYSTEM.
2746 ;* THIS ROUTINE CAN BE USED AS A DELAY ROUTINE, BY SPECIFYING THE
2747 ;* DESIRED DELAY AS THE TIME-OUT AND SPECIFYING A CONDITION TO
2748 ;* LOOK FOR WHICH WILL NOT BE MET DURING THE DELAY.
2749 ;* IF A TIME-OUT VALUE OF 0 IS SPECIFIED, THIS ROUTINE CHECKS FOR
2750 ;* THE DESIRED CONDITION BEFORE RETURNING. IT INDICATES SUCCESS
2751 ;* IF THE CONDITION IS MET, FAILURE OTHERWISE.
2752 ;*
2753 ;*
2754 ;* SUBORDINATE ROUTINES CALLED: NONE.
2755 ;*****
2756
2757 020164 MSLGET:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
020164 004567 163606 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2758 ;*
2759 ; SET UP MASK FOR REMOVING UNUSED BITS IN THE TEST WORD, AND CLEAR UNUSED
2760 ; BITS IN THE DESIRED STATE WORD TO ALLOW DIRECT COMPARISON.
2761 ; -
2762 020170 COM R2 ;GET MASK OF UNUSED BITS.
020172 040203 BIC R2,R3 ;MASK OUT UNUSED BITS IN DESIRED STATE WORD.
2764 ;*
2765 ; HANDLE THE TEST AND EXIT IF WE HAVE A 0 TIME-OUT VALUE.
2766 ; -
2767 020174 TST R1 ;TEST THE TIME-OUT VALUE FOR ZERO.
020176 001011 BNE 2$ ;IF NON-ZERO TIME-OUT, GO LOOP AND TEST.
2769 020200 MOV (R4),R0 ;GET THE WORD TO TEST BEFORE EXITING.
2770 020202 MOV R0,62$ ;SAVE VALUE SO WE CAN RETURN IT.
2771 020206 BIC R2,R0 ;MASK OUT UNTESTED BITS OF WORD.
2772 020210 CMP R0,R3 ;COMPARE AGAINST DESIRED STATE WORD.
2773 020212 SEC ;INDICATE SUCCESS IN CASE WORDS ARE EQUAL.
2774 020214 BEQ 6$ ;EXIT WITH SUCCESS IF WORDS ARE EQUAL.

```



```

2775 020216 000241          CLC          ;INDICATE FAILURE (TIME OUT).
2776 020220 000416          BR          6$          ;EXIT WITH FAILURE, WORDS AREN'T EQUAL.
2777                          ;+
2778                          ; NON ZERO TIME OUT VALUE. LOOP, WAITING FOR CONDITION OR TIME OUT.
2779                          ;
2780 020222 016705 162130  2$:      MOV      MSLCNT,R5      ;LOAD MS LOOP COUNT.
2781 020226 011400          4$:      MOV      (R4),R0      ;GET THE WORD TO TEST.
2782 020230 010067 000042  MOV      R0,62$      ;SAVE WORD IN CASE THIS IS THE LAST.
2783 020234 040200          BIC      R2,R0      ;MASK OUT UNTESTED BITS OF WORD.
2784 020236 020003          CMP      R0,R3      ;COMPARE AGAINST DESIRED STATE WORD.
2785 020240 000261          SEC          ;SET CARRY IN CASE OF SUCCESS.
2786 020242 001405          BEQ      6$          ;EXIT WITH SUCCESS IF WORDS ARE EQUAL.
2787 020244 005305          DEC      R5          ;COUNT DOWN THE INSIDE MS LOOP COUNT.
2788 020246 001367          BNE      4$          ;LOOP IF MS NOT UP.
2789 020250 005301          DEC      R1          ;DECREMENT THE MS TIME COUNT.
2790 020252 001363          BNE      2$          ;IF TIME NOT UP, LOOP TO COUNT ANOTHER MS.
2791 020254 000241          CLC          ;CLEAR CARRY, WE TIMED-OUT.
2792                          ;+
2793                          ; HAVE EITHER FOUND CONDITION, OR TIMED OUT (POSSIBLY FROM 0 TIME OUT VALUE).
2794                          ; RESTORE THE LAST CONTENTS READ FROM THE TEST WORD. EXIT ROUTINE.
2795                          ;-
2796 020256 016700 000014  6$:      MOV      62$,R0      ;PASS OUT THE LAST READ WORD.
2797 020262 020262 010066 000002  60$:    PASS      R0,R1      ;RESTORE GPRS, EXCEPT THE FOLLOWING:
                                MOV      R0,R0SLOT(SP)      ;PUT R0 IN STACK SLOT.
                                MOV      R1,R1SLOT(SP)      ;PUT R1 IN STACK SLOT.
                                JSR      PC,@(SP)+          ;RETURN TO PREG05 SUBRT.
2798                          ;R0 LAST READ WORD CHECKED FOR CONDITION.
2799                          ;R1 REMAINING TIME (0 IF TIME OUT OCCURED).
2800 020274 000207          RTS      PC      ;CARRY SET IF SUCCESS, CLEAR IF TIME-OUT.
2801                          ;+
2802                          ; LOCAL STORAGE.
2803                          ;
2804 020276 000000          62$:    .WORD  0          ;STORAGE FOR THE LAST READ WORD.

```

2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835
2836
2837
2838
2839 020300
020300 004567 163472
2840
2841
2842
2843
2844
2845 020304 004767 177654
2846
2847 020310
020310 004736
2848 020312 000207

```
.SBTTL GLOEAL SUBROUTINE MSLOOP
:*****
:* TEST LOOP SUBROUTINE
:* THIS SUBROUTINE IS A GENERAL PURPOSE TEST LOOP SUBROUTINE. IT IS USED
:* TO VERIFY THAT A CERTAIN ACTION OCCURS BEFORE A TIME OUT PERIOD. THE
:* CALLING ROUTINE PASSES IN WHICH BITS SHOULD BE SET AND CLEARED FOR THE
:* DESIRED CONDITION AND THE TIME OUT VALUE IN MILLI-SECONDS.
:* THIS ROUTINE CHECKS FOR THE DESIRED CONDITION UPON ENTRANCE INTO THE
:* ROUTINE AND THEN ONCE EACH MILLI SECOND THEREAFTER.
:*
:* INPUTS: R1 - TIME-OUT VALUE IN MILLI SECONDS (UP TO 64K MS).
:* R2 BIT MAP OF BITS TO TEST (1 INDICATES TO TEST THE BIT).
:* R3 DESIRED STATES OF THE INDICATED FIELDS IN R2.
:* R4 ADDRESS OF THE WORD TO TEST.
:* MSLCNT - MILLI SECOND SOFTWARE LOOP COUNT.
:*
:* OUTPUTS: CARRY SUCCESS FLAG (SET IF CONDITION IS MET BEFORE TIME OUT).
:*
:* CALLING SEQUENCE: JSR PC,MSLOOP
:*
:* COMMENTS: THIS ROUTINE WORKS WITH OR WITHOUT A HARDWARE CLOCK, BUT THE
:* CALIBRATION IS ONLY GUARENTEED WHEN A LINE CLOCK IS AVAILABLE
:* ON THE SYSTEM.
:* THIS ROUTINE CAN BE USED AS A DELAY ROUTINE, BY SPECIFYING THE
:* DESIRED DELAY AS THE TIME-OUT AND SPECIFYING A CONDITION TO
:* LOOK FOR WHICH WILL NOT BE MET DURING THE DELAY.
:* IF A TIME OUT VALUE OF 0 IS SPECIFIED, THIS ROUTINE CHECKS FOR
:* THE DESIRED CONDITION BEFORE RETURNING. IT INDICATES SUCCESS
:* IF THE CONDITION IS MET, FAILURE OTHERWISE.
:*
:* SUBORDINATE ROUTINES CALLED: MSLGET.
:*****
MSLOOP:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;
; CALLING THE MSLGET ROUTINE FROM THE MSLOOP ROUTINE ISOLATES THE CALLER OF
; MSLOOP FROM THE RETURNED TEST WORD AND REMAINING TIME OUT VALUES.
;
; JSR PC,MSLGET ;CALL THE MULTI PURPOSE MS LOOP AND SEARCH RTN.
60$: PASS ;RESTORE GPRS,
;PC,@(SP). ;RETURN TO PREG05 SUBRT.
RTS PC ;CARRY SET IF SUCCESS, CLEAR IF TIME OUT.
```

```

2850
2851
2852
2853
2854
2855
2856
2857
2858
2859
2860
2861
2862
2863
2864
2865
2866
2867
2868
2869 020314
      020314 004567 163456
2870
2871 020320
      020320 104454
      020322 000145
      020324 020360
      020326 000000
2872
2873 020330
      020330 012746 020444
      020334 012746 000001
      020340 010600
      020342 104417
      020344 062706 000004
2874 020350
      020350 104422
2875 020352 000776
2876 020354
      020354 004736
2877 020356 000207
2878
2879 020360 110 117 123
      020363 124 040 103
      020366 117 115 120
      020371 125 124 105
      020374 122 040 110
      020377 101 122 104
      020402 127 101 122
      020405 105 040 117
      020410 122 040 123
      020413 117 106 124
      020416 127 101 122
      020421 105 040 102
      020424 125 107 040
      020427 105 116 103
      020432 117 125 116
      020435 124 105 122

```

```

.SBTTL GLOBAL SUBROUTINE OOPS
;*****
;* PROGRAM ABORT SUBROUTINE
;* THIS SUBROUTINE IS USED TO ABORT THE PROGRAM WHEN A FATAL ERROR IS
;* DETECTED IN THE PROGRAM OR THE HOST SYSTEM HARDWARE. AN ERROR MESSAGE
;* IS PRINTED GIVING SOME INFORMATION ABOUT THE NATURE OF THE ABORT.
;*
;* INPUTS: R1 ERROR CODE GIVING REASON FOR ABORT.
;*
;* OUTPUTS: AN ERROR MESSAGE IS PRINTED.
;* A LIST OF RETURN PC VALUES FOR ALL SUBROUTINE CALLS IS PRINTED.
;*
;* CALLING SEQUENCE: JSR PC,OOPS
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
OOPS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
      JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
; REPORT "HOST COMPUTER HARDWARE OR SOFTWARE BUG ENCOUNTERED." ERROR.
      ERRSF 101,EMO101
;
; REPORT "PROGRAM HUNG, WAITING FOR A CONTROL C."
      PRINTF #EMO102
;
      MOV #EMO102, (SP)
      MOV #1, (SP)
      MOV SP,R0
      TRAP C#PNTF
      ADD #4,SP
2$: BREAK ;LOOK FOR OPERATOR CONTROL C INPUT.
      TRAP C#BRK
; INFINITE LOOP.
60$: BR 2$
; DON'T NEED THIS, BUT SOMEBODY MAY CHANGE THIS
; RETURN TO PREG05 SUBRT.
      JSR PC,@(SP)
; ROUTINE IN THE FUTURE, SO BE CONSISTANT.
      RTS PC
EMO101:: .ASCIZ /HOST COMPUTER HARDWARE OR SOFTWARE BUG ENCOUNTERED./

```

	020440	105	104	056
	020443	000		
2880	020444	045	116	045
	020447	101	120	122
	020452	117	107	122
	020455	101	115	040
	020460	110	125	116
	020463	107	054	040
	020466	127	101	111
	020471	124	111	116
	020474	107	040	106
	020477	117	122	040
	020502	101	040	103
	020505	117	116	124
	020510	122	117	114
	020513	055	103	056
	020516	040	074	052
	020521	052	052	052
	020524	052	052	052
	020527	052	052	052
	020532	052	052	052
	020535	045	116	045
2881	020540	116	000	

EM0102:: .ASCIZ /~~N~~PROGRAM HUNG. WAITING FOR A CONTROL C. <*****~~N~~/

.EVEN

2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2900
2901
2902
2903
2904
2905
2906
2907
2908
2909
2910
2911
2912
2913
2914
2915
2916
2917
2918
2919
2920
2921
2922
2923
2924
2925
2926
2927
2928
2929
2930
2931

020542 004567 163230
020546 012701 001000
020552 016704 161466

020556 011402
020560 100016

020562 012700 070000
020566 040200
020570 001006

020572 012700 000301
020576 040200
020600 001002
020602 004767 001470

020606 005301
020610 001362
020612 000241
020614 000401
020616 000261

020620
020620 004736

020622 000207

```
.SBTTL GLOBAL SUBROUTINE PUFIFO
;*****
;* - PURGE THE FIFO
;* THIS ROUTINE TRIES TO REMOVE ALL THE CHARACTERS FROM THE FIFO.
;* ANY BMP CODES THAT ARE FOUND ARE SAVED ON THE BMP CODE QUEUE.
;*
;* INPUTS: RBUFA CONTAINS THE ADDRESS OF THE RECEIVER.
;*
;* OUTPUTS: CARRY BIT - INDICATES THE STATE OF THE FIFO, SET:= PURGED.
;* BMPQC - THE CONTENTS OF THE BMP CODE QUEUE MAY BE UPDATED.
;*
;* CALLING SEQUENCE: JSR PC,PUFIFO
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: SAVBMP.
;*****
PUFIFO::SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREGOS ;CALL REGISTER SAVE SUBRT.
MOV #512,R1 ;SET MAXIMUM TRY COUNT OF 512.
MOV RBUFA,R4 ;GET ADDRESS OF THE RECEIVER BUFFER REGISTER.
2$: MOV (R4),R2 ;GET THE CONTENTS OF THE RECEIVER BUFFER REG.
BPL 6$ ;EXIT IF THE FIFO IS EMPTY, DATA_VALID CLR.
;+
; CHECK IF THE READ CHARACTER IS ACTUALLY A BMP CODE.
; IF IT IS, THEN SAVE IT ON THE BMP CODE QUEUE TO BE REPORTED LATER.
;-
MOV #70000,R0 ;GENERATE A BIT MAP OF CHAR ERROR BITS
BIC R2,R0 ; WHICH ARE NOT SET FOR CHAR.
BNE 4$ ;THROW CHAR AWAY IF NOT BMP OR SELFTEST CODE.
;+
; CHECK IF THE READ DATA IS MODEM STATUS , BMP OR SELFTEST?.
;-
MOV #301,R0 ; CHECK IF BMP.
BIC R2,R0 ;TRY TO CLEAR BMP FLAGS IN THE READ DATA.
BNE 4$ ;IF IT IS MODEM OR SELFTEST CODE THROW IT AWAY.
JSR PC,SAVBMP ;SAVE BMP CODE ON THE QUEUE.
4$: DEC R1 ;DECREMENT THE TRY COUNT.
BNE 2$ ;LOOP TO TRY AGAIN.
CLC ;CLEAR CARRY,TO INDICATE FIFO NOT PURGED.
BR 60$ ;EXIT WITH CARRY CLEAR.
6$: SEC ;SET CARRY, TO INDICATE FIFO PURGED.
60$: PASS ;RESTORE GPRS,
;PC,@(SP); ;RETURN TO PREGOS SUBRT.
;CARRY BIT, SET INDICATES FIFO PURGED.
RTS PC
```

```

2933 .SBTTL GLOBAL SUBROUTINE RDPDR
2934 ;*****
2935 ;* READ AND VERIFY DATA PATTERN FROM DEVICE REGISTERS ROUTINE
2936 ;* THIS ROUTINE READS AND VERIFIES THE ROTATED DATA PATTERN WHICH HAS
2937 ;* BEEN WRITTEN BY THE WDPDR SUBROUTINE.
2938 ;* EACH ACTIVE LINE'S REGISTER'S CONTENTS IS READ AND COMPARED WITH THE
2939 ;* WRITTEN DATA.
2940 ;* AFTER THE UNUSED AND READ ONLY (RO) BITS ARE MASKED OUT, ANY ERRORS ARE
2941 ;* REPORTED FROM THIS ROUTINE.
2942 ;* THIS ROUTINE WILL TAKE INTO ACCOUNT THE TYPE OF WRITE OPERATION WHICH
2943 ;* WAS PERFORMED BY THE WDPDR SUBROUTINE.
2944 ;*
2945 ;* INPUTS: R2 - USED TO PASS IN THE DATA PATTERN TO BE ROTATED & VERIFIED.
2946 ;* R3 - BYTE INDICATOR (- => LO BYTE, + => HI BYTE, 0 => BOTH).
2947 ;* R4 - OPERATION TYPE INDICATOR (- => BIC, + => BIS, 0 => MOV).
2948 ;* ACTLNS - BIT MAP OF ACTIVE LINES ON THE DEVICE UNDER TEST.
2949 ;* CSRA - CONTAINS THE CSR ADDRESS OF THE DEVICE UNDER TEST.
2950 ;* DRADRT - BASE ADDRESS OF DEVICE REGISTER ADDRESS TABLE.
2951 ;* ERCNTB - LABEL AT BASE OF ERROR COUNTERS TABLE FOR LINES.
2952 ;* ERRMSG - SET UP WITH THE PROPER ERROR MESSAGE FOR THIS TEST.
2953 ;* ERRNBR - SET UP WITH THE PROPER ERROR NUMBER.
2954 ;* LPRO - EQUATED TO LPR REG OFFSET FROM DEVICE CSR ADDRESS.
2955 ;* NUMLNS - NUMBER OF LINES ON THE DEVICE UNDER TEST.
2956 ;* NDERPT - NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE.
2957 ;* TXBFCO - EQUATED TO TBUFFCT REG OFFSET FROM DEVICE CSR ADDRESS.
2958 ;* UNBTB - BASE ADDRESS OF THE UNUSED BIT TABLE.
2959 ;*
2960 ;* OUTPUTS: ERROR MESSAGES MAY BE PRINTED AT THE OPERATOR'S CONSOLE.
2961 ;* ERCNT - ERROR COUNTERS TABLE IS UPDATED FOR LINE UNDER TEST.
2962 ;* ERBLK - CONTENTS DESTROYED.
2963 ;* ERSRFR - ERROR SUMMARY FLAGS BIT SET IF LINE IN SUMMARY MODE.
2964 ;* UUT CSR - ALL BITS CLEARED, EXCEPT IND.ADR.REG FIELD DESTROYED.
2965 ;*
2966 ;* CALLING SEQUENCE: JSR PC,RDPDR
2967 ;*
2968 ;* COMMENTS: FOR BYTE ACCESSES, ONLY THE SPECIFIED BYTE IS VERIFIED.
2969 ;*
2970 ;* SUBORDINATE ROUTINES CALLED: ER1601,ROLDAP.
2971 ;*
2972 ;*
2973 RDPDR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
2974 020624 004567 163146 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2975 020630 012767 016416 163136 MOV #ER1601,ERRBLK ;SET UP THE ADDRESS OF THE ERROR REPORT RTN.
2976 ;*
2977 ;* DETERMINE WHETHER REGISTER DATA SHOULD BE INVERTED FROM DATA PATTERN.
2978 ;*
2979 020636 005704 TST R4 ;CHECK THE OPERAND TYPE INDICATOR.
2980 020640 100001 BPL 2$ ;BIC WRITE PERFORMED? NO, USE STANDARD DATA.
2981 020642 005102 COM R2 ;YES, INVERT THE DATA PATTERN.
2982 ;*
2983 ;* SET UP OUTER LOOP.
2984 020644 005005 2$: CLR R5 ;CLEAR LINE COUNTER TO SELECT LINE 0.
2985 ;*
2986 ;* THE OUTER LOOP FOLLOWS. EACH PASS THROUGH THIS LOOP READS AND COMPARES DATA
2987 ;* FROM ALL OF THE DEVICE REGISTERS FOR A PARTICULAR LINE IF THE LINE IS ACTIVE.
2988 ;

```

```

2989 020646 010267 000222      48:  MOV   R2,R0      ;SAVE THE OUTER LOOP DATA PATTERN.
2990 020652 010577 161364      MOV   R5,DCSRA   ;SET CSR IND.ADR.REG FIELD TO THIS LINE.
2991 020656 010500              MOV   R5,R0
2992 020660 006300              ASL   R0
2993 020662 036067 002410 161340  BIT   BITBL(R0),ACTLNS
2994 020670 001467              BEQ   168        ;IS THE LINE ACTIVE? NO, SKIP THE LINE.
2995 020672 012703 000004      MOV   @LPRO,R3   ;YES, INITIALIZE REGISTER OFFSET FOR LPR.
2996
2997      ;
2998      ; THE INNER LOOP FOLLOWS. EACH PASS THROUGH THIS LOOP READS AND COMPARES
2999      ; DATA FROM A DEVICE REGISTER.
3000 020676 010204      68:  MOV   R2,R4      ;SAVE THE INNER LOOP DATA PATTERN.
3001 020700 046302 002370      BIC   UNBITB(R3),R2 ;REMOVE UNUSED BITS FROM EXPECTED DATA.
3002 020704 016300 002242      MOV   DRADR(R3),R0
3003 020710 005766 000010      TST   R3SLOT(SP) ;CHECK THE ACCESS TYPE INDICATOR.
3004 020714 001002              BNE   88        ;BYTE ACCESS? YES, GO PERFORM BYTE READ.
3005 020716 011001              MOV   (R0),R1   ;NO, PERFORM WORD READ OF DEVICE REGISTER.
3006 020720 000416              BR   128
3007 020722 100410      88:  BMI   108       ;LOW BYTE ACCESS? YES, GO DO LOW BYTE READ.
3008 020724 005200              INC   R0        ;HIGH BYTE ACCESS. FORM HIGH BYTE ADDRESS.
3009 020726 111001              MOVB (R0),R1   ;READ THE HI BYTE OF THE DUT REGISTER.
3010 020730 000301              SWAB R1        ;PUT HI BYTE BACK INTO THE HI BYTE.
3011 020732 042701 000377      BIC   @377,R1   ;REMOVE THE UNUSED BYTE IN ACTUAL DATA.
3012 020736 042702 000377      BIC   @377,R2   ;REMOVE THE UNUSED BYTE IN EXPECTED DATA.
3013 020742 000405              BR   128
3014 020744 111001      108: MOVB (R0),R1   ;READ THE LOW BYTE OF THE DUT REGISTER.
3015 020746 042701 177400      BIC   @177400,R1 ;REMOVE THE UNUSED BYTE.
3016 020752 042702 177400      BIC   @177400,R2 ;FORM EXPECTED LOW BYTE FOR COMPARISON.
3017
3018 020756 046301 002370      128: BIC   UNBITB(R3),R1 ;REMOVE UNUSED BITS FROM ACTUAL DATA.
3019 020762 020102              CMP   R1,R2    ;COMPARE ACTUAL AND EXPECTED DATA.
3020 020764 001414              BEQ   148       ;ACTUAL = EXPECTED? YES, SKIP ERROR.
3021 020766 004767 177054      JSR   PC,ENTERR ;NO, COUNT THE ERROR, CHECK FOR ERROR SUMMARY.
3022 020772 103411              BCS   148       ;USE ERROR SUMMARY? YES, SKIP ERROR.
3023      ;NO, REPORT "BAD BIT(S) IN DEVICE XXXXX REGISTER FOR LINE NN (D)."
3024 020774              ERROR
3025      ;
3026      ;EXIT THIS ROUTINE AND SET THE "EXIT ON ERROR" FLAG, IF EXTENDED ERROR
3027      ;REPORTING HAS NOT BEEN REQUESTED.
3028      ;
3029 020774 032767 000100 161220      BIT   @BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
3030 021004 001004              BNE   148       ;BRANCH IF IT HAS.
3031 021006 012767 000001 161270      MOV   @1,EXOERR  ;SET THE EXIT ON ERROR FLAG.
3032 021014 000425              BR   608        ;EXIT THE ROUTINE.
3033
3034 021016 010402      148: MOV   R4,R2      ;RESTORE THE INNER LOOP DATA PATTERN.
3035 021020 004767 000444      JSR   PC,ROLDAP ;ROTATE DATA PATTERN LEFT, NOT THROUGH CARRY.
3036 021024 062703 000002      ADD   @2,R3     ;SET REGISTER OFFSET TO THE NEXT REGISTER.
3037 021030 020327 000006      CMP   R3,@FSLSD ;CHECK THAT THIS IS NOT THE FIFOSIZE/DATA REG.
3038 021034 001002              BNE   158       ;AVOID ALTERING THE OFFSET IF IT ISN'T
3039 021036 062703 000002      ADD   @2,R3     ;POINT AT THE NEXT REGISTER.
3040 021042 020327 000016      158: CMP   R3,@TXBFCO ;COMPARE REG OFFSET WITH OFFSET OF LAST REG.
3041 021046 003713              BLE   68        ;LOOP IF NOT ALL REG DONE FOR THIS LINE.
3042      ;
3043      ; BACK INTO THE OUTER LOOP. NOW SET UP FOR NEXT LINE. LOOP IF NOT DONE.
3044      ;

```

3045	021050	016702	000020	16:	MOV	70,R2		;SET UP TO ROTATE THE DATA PATTERN.
3046	021054	004767	000417		JSR	PC,ROLDAP		;ROTATE THE DATA PATTERN.
3047	021060	005205			INC	R5		;COUNT THIS LINE
3048	021062	020527	000020		CMP	R5,#NUMLNS		;COMPARE LINE COUNT WITH NUMBER OF LINES.
3049	021066	002667			BLT	4#		;LOOP IF SOME LINES NOT DONE.
3050								
3051	021070			60:	PASS			;RESTORE GPRS.
	021070	004736					JSR	PC,B(SP). ;RETURN TO PREG05 SUBRT.
3052	021072	000207			RTS	PC		
3053								
3054	021074	000000		70:	.WORD	0		; STORAGE FOR DATA PATTERN OUTSIDE INNER OOP.


```

3056 .SBTTL GLOBAL SUBROUTINE REGTST
3057 ;* *****
3058 ;* - REGISTERS TEST SUBROUTINE
3059 ;* SUBROUTINE TO TEST THE DEVICE UNDER TEST (DUT) REGISTERS. THE USED
3060 ;* BITS OF THE REGISTERS ARE EITHER ALL CLEARED OR ALL SET AND THEN THE
3061 ;* DATA PATTERN IS WRITTEN AND VERIFIED USING EITHER WORD OR BYTE
3062 ;* ACCESSES IN READ/WRITE OR READ/MODIFY/WRITE MODE.
3063 ;*
3064 ;* INPUTS: R3 BYTE INDICATOR (- => LOW, + => HIGH, 0 => BOTH BYTES).
3065 ;* R4 - ACCESS MODE ( 1 => SET THEN BIC, 1 => CLEAR THEN BIS,
3066 ;* (-2 => SET THEN MOV, +2 CLEAR THEN MOV).
3067 ;* ERRNBR SET UP WITH INITIAL ERROR NUMBER.
3068 ;*
3069 ;* OUTPUTS: GPRS0 - GPR SAVE AREA 0 IS DESTROYED.
3070 ;* DEVICE UNDER TEST REGISTERS ARE WRITTEN.
3071 ;* ERROR MESSAGES MAY BE PRINTED AT THE OPERATORS CONSOLE.
3072 ;*
3073 ;* CALLING SEQUENCE: JSR PC,REGTST
3074 ;*
3075 ;* COMMENTS: THIS ROUTINE LOOP 16 TIMES WRITING THE SAME DATA PATTERN
3076 ;* ROTATED LEFT ONCE EACH ITERATION.
3077 ;* THIS ROUTINE CAN REPORT ERRORS INITIAL ERRNBR THRU INITIAL+2.
3078 ;*
3079 ;* SUBORDINATE ROUTINES CALLED: RDPDR,ROLDAP,SWAPO,WOPDR
3080 ;* *****
3081
3082 021076 REGTST:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
021076 004567 162674 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3083 ;*
3084 ;* SET UP THE GPRS FOR THE WRITING OF THE DATA PATTERN.
3085 ;*
3086 021102 012705 000020 MOV #16,R5 ;SET UP LOOP COUNTER TO COUNT 16 ITERATIONS.
3087 021106 012702 167410 MOV #167410,R2 ;INITIALIZE THE DATA PATTERN.
3088 021112 032704 000001 BIT #BIT0,R4 ;TEST FOR R/W ACCESS.
3089 021116 001001 BNE 2$ ;R/M/W ACCESS? YES, R4 IS ALL SET UP.
3090 021120 005004 CLR R4 ;NO, INDICATE R/W ACCESS.
3091 021122 2$:
3092 ;*
3093 ;* SET UP THE GPRS FOR THE CLEARING OR SETTING OF ALL THE USED BITS.
3094 ;*
3095 021122 010400 MOV R4,R0 ;PASS OPERATION TYPE INDICATOR AROUND SWAPO.
3096 021124 004767 001272 JSR PC,SWAPO ;GET ALTERNATE GPR SET IN R1 THRU R5.
3097 021130 016701 162634 MOV ERRNBR,R1 ;SAVE THE INITIAL ERROR NUMBER.
3098 021134 010004 MOV R0,R4
3099 021136 005404 NEG R4 ;SET UP OP TYPE FOR CLEARING OR SETTING.
3100 021140 005002 CLR R2 ;SET UP CLEAR WRITE PATTERN.
3101 021142 026627 000012 000002 CMP R4,SLOT(SP),#2 ;TEST FOR CLEAR THEN MOV TEST SEQUENCE.
3102 021150 001401 BEQ 4$ ;CLEAR THEN MOV? YES, LEAVE WRITE PAT CLEAR.
3103 021152 005102 COM R2 ;NO, SET ALL BITS OF WRITE PATTERN.
3104 021154 005003 4$: CLR R3 ;INDICATE THAT WORD ACCESSES SHOULD BE USED.
3105 021156 005000 CLR R0 ;SET ALTERNATE BYTE EXPECTED DATA PAT TO CLEAR.
3106 021160 026627 000012 177776 CMP R4,SLOT(SP),# 2 ;TEST FOR SET THEN MOV TEST SEQUENCE.
3107 021166 001001 BNE 6$ ;SET THEN MOV? YES, LEAVE ALT BYTE PAT CLEAR.
3108 021170 005100 COM R0 ;NO, SET ALT BYTE EXPECTED DATA PAT TO ALL 1 S.
3109 021172 004767 001224 6$: JSR PC,SWAPO ;RESTORE SWAPPED GPR VALUES TO R1 THRU R5.
3110 ;*
3111 ;* START OF DATA PATTERN LOOP.

```

```

3112
3113 021176
3114
3115
3116
3117
3118 021176 004767 001220
3119 021202 004767 002136
3120 021206 010167 162556
3121 021212 004767 177406
3122
3123
3124
3125
3126 021216 005767 161062
3127 021222 001035
3128
3129 021224 004767 001172
3130
3131
3132
3133
3134 021230 004767 002110
3135 021234 005267 162530
3136 021240 004767 177360
3137
3138
3139
3140
3141 021244 005767 161034
3142 021250 001022
3143
3144 021252 005703
3145 021254 001414
3146
3147
3148
3149 021256 010201
3150 021260 010002
3151 021262 005403
3152 021264 005267 162500
3153 021270 004767 177330
3154
3155
3156
3157
3158 021274 005767 161004
3159 021300 001006
3160
3161 021302 005403
3162 021304 010102
3163
3164
3165
3166 021306 004767 000156
3167 021312 005305
3168 021314 003330

```

```

;
;
; SET OR CLEAR ALL THE USED BITS OF THE DEVICE REGISTERS FOR ALL LINES.
; VERIFY THAT ALL THE BITS WERE SET OR CLEARED CORRECTLY.
;
; JSR PC,SWAPO ;GET ALTERNATE GPRS FOR SETTING INITIAL STATES.
; JSR PC,WDPDR ;GO CLEAR ALL USED REGISTER BITS, ALL LINES.
; MOV R1,ERRNBR ;SET UP ERROR NUMBER TO INITIAL ERRNBR.
; JSR PC,RDPDR ;VERIFY ALL USED REGISTER BITS, ALL LINES.
;
; EXIT THIS ROUTINE IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING
; HAS BEEN REQUESTED, I.E. EXOERR IS NON ZERO.
;
; TST EXOERR ;HAS AN ERROR BEEN FOUND ?
; BNE 60$ ;EXIT THIS ROUTINE IF IT HAS.
;
; JSR PC,SWAPO ;RESTORE MAIN GPRS CONTENTS.
;
; WRITE DATA PATTERNS, ALL LOWER BYTE USED BITS, ALL REGISTERS, ALL LINES.
; VERIFY THAT THE DATA PATTERN WAS WRITTEN CORRECTLY.
;
; JSR PC,WDPDR ;WRITE DATA PATTERN TO DEVICE REGISTERS.
; INC ERRNBR ;SET ERROR NUMBER TO INITIAL+1.
; JSR PC,RDPDR ;VERIFY DATA PATTERN IN ALTERED BYTE(S).
;
; EXIT THIS ROUTINE IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING
; HAS BEEN REQUESTED.
;
; TST EXOERR ;HAS AN ERROR BEEN FOUND ?
; BNE 60$ ;EXIT THIS ROUTINE IF IT HAS.
;
; TST R3 ;CHECK THE BYTE INDICATOR.
; BEQ 10$ ;WORD ACCESS? YES, SKIP SECOND BYTE CHECK.
;
; CHECK THAT THE ALTERNATE (UNMODIFIED) BYTE IS CLEAR OR SET AS EXPECTED.
;
; MOV R2,R1 ;SAVE THE DATA PATTERN.
; MOV R0,R2 ;GET THE ALTERNATE BYTE EXPECTED DATA.
; NEG R3 ;INDICATE THAT OTHER BYTE IS TO BE CHECKED.
; INC ERRNBR ;SET ERROR NUMBER TO INITIAL+2.
; JSR PC,RDPDR ;VERIFY DATA PATS IN OTHER BYTES OF REGISTERS.
;
; EXIT THIS ROUTINE IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING
; HAS BEEN REQUESTED.
;
; TST EXOERR ;HAS AN ERROR BEEN FOUND ?
; BNE 60$ ;EXIT THIS ROUTINE IF IT HAS.
;
; NEG R3 ;RESTORE BYTE INDICATOR.
; MOV R1,R2 ;RESTORE DATA PATTERN.
;
; PREPARE THE NEXT DATA PATTERN AND LOOP IF NOT DONE.
;
; 10$: JSR PC,ROLDAP ;ROTATE DATA PATTERN LEFT, NOT THROUGH CARRY.
; DEC R5 ;COUNT THIS ITERATION OF THE LOOP.
; BGT 8$ ;ALL PATTERNS DONE? NO, LOOP.

```

3169
3170 021316 016767 161126 162444 604: MOV GPRS08,ERRNBR ;YES, RESTORE ERROR NUMBER AND EXIT.
3171 021324 PASS ;GET THE ERROR NUMBR FROM GPR SWAP STORAGE.
021324 004736 ;RESTORE GPRS.
3172 021326 000207 RTS PC JSR PC,@(SP); ;RETURN TO PREG05 SUBRT.

3174
3175
3176
3177
3178
3179
3180
3181
3182
3183
3184
3185
3186
3187
3188
3189
3190
3191
3192
3193
3194
3195
3196
3197
3198
3199
3200 021330
021330 004567 162442
3201 021334 005767 161122
3202 021340 001404
3203
3204
3205
3206 021342 012767 016722 162424
3207
3208
3209
3210
3211 021350
021350 104460
3212
3213 021352
021352 004736
3214 021354 000207

```
.SBTTL GLOBAL SUBROUTINE REPSMR
; * *****
; * REPORT ERROR SUMMARY ROUTINE
; * THIS SUBROUTINE REPORTS AN ERROR SUMMARY FOR THOSE LINES WHICH HAVE
; * EXCEEDED THE NUMBER OF INDIVIDUAL ERRORS TO REPORT FOR A SINGLE LINE
; * IN A SINGLE TEST. THIS PARAMETER CAN BE SPECIFIED BY THE OPERATOR IF
; * HE/SHE ANSWERS THE SOFTWARE PARAMETER QUESTIONS.
; *
; * INPUTS: ERCNTB LABEL AT BASE OF LINE ERROR COUNTERS TABLE.
; * ERRMSG - ADDRESS OF PRIMARY ERROR MESSAGE.
; * ERRNBR - ERROR NUMBER OF ERRORS IN THIS ROUTINE.
; * ERSMRF - "REPORT ERROR SUMMARY FOR LINE FLAGS.
; *
; * OUTPUTS: ERRBLK ADDRESS OF ERROR REPORTING ROUTINE (DESTROYED).
; * SUMMARY MESSAGES MAY BE PRINTED AT THE OPERATOR CONSOLE.
; *
; * CALLING SEQUENCE: JSR PC,REPSMR
; *
; * COMMENTS: IF NO LINES HAVE EXCEEDED THE MAXIMUM NUMBER OF INDIVIDUAL
; * ERRORS TO REPORT, NO MESSAGES ARE PRINTED BY THIS ROUTINE.
; * ERROR SUMMARIES IN THIS ROUTINE ARE REPORTED AS ERRORS.
; * THE CONTENTS OF ERRBLK ARE DESTROYED.
; *
; * SUBORDINATE ROUTINES CALLED:
; - *****
REPSMR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
; R5,PREG05 ;CALL REGISTER SAVE SUBRT.
TST ERSMRF JSR ;CHECK THE "PRINT LINE ERROR SUMMARY" FLAGS.
BEQ 60$ ;EXIT WITHOUT ACTION IF NO SUMMARY FLAGS SET.
; *
; * WE HAVE SOME ERROR SUMMARIES TO REPORT.
; -
MOV #ER9004,ERRBLK ;SELECT ERROR REPORTING ROUTINE.
; *
; * REPORT
; * "ERROR SUMMARY REPORT FOR LINES WITH EXCESSIVE NUMBERS OF ERRORS:"
; *
; * ERROR TRAP C$ERROR
60$: PASS ;RESTORE GPRS.
RTS PC JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
```

```

3216 .SBTTL GLOBAL SUBROUTINE RESETT
3217 ;*****
3218 ;* - RESET DEVICE UNDER TEST
3219 ;* THIS SUBROUTINE IS USED TO RESET THE DUT TO A KNOWN STATE.
3220 ;* IF RESET DOES NOT SUCCESSFULLY COMPLETE, IE. TIME-OUT OCCURS, THEN
3221 ;* AN ABORT TEST ERROR MESSAGE IS REPORTED.
3222 ;*
3223 ;* INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR
3224 ;* TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
3225 ;* ERRTBL ERRTP,ERNBR,AND ERRMSG SET UP CORRECTLY.
3226 ;*
3227 ;* OUTPUTS: THE DUT PERFORMS ITS RESET FUNCTION INTO A KNOWN STATE.
3228 ;* CARRY - CLEAR INDICATES THE TEST IS TO BE ABORTED.
3229 ;* ERRLK - VALUE MAY BE DESTROYED.
3230 ;* IESTAT - TX AND RX INTERRUPT FLAGS ARE CLEARED.
3231 ;* TX AND RX INTERRUPT ENABLE BITS IN THE DUT'S CSR ARE CLEARED.
3232 ;*
3233 ;* CALLING SEQUENCE: JSR PC,RESETT
3234 ;*
3235 ;* COMMENTS: THIS SUBROUTINE CAN REPORT ERRORS WITH NUMBERS INITIAL ERRNBR
3236 ;* THIS ROUTINE DOES NOT DESTROY THE VALUE OF ERRNBR.
3237 ;*
3238 ;* SUBORDINATE ROUTINES CALLED: DELAY,MSLGET.
3239 ;*****
3240
3241 021356 RESETT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
021356 004567 162414 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3242 021362 012702 000040 MOV #BIT05,R2 ;SET BIT MASK OF MASTER RESET BIT.
3243 ;*
3244 ;* TEST THE STATE OF THE MASTER RESET BIT IN THE CSR.
3245 ;* IF MR IS SET THEN WAIT FOR SELF TEST TO COMPLETE.
3246 ;* IF TIME-OUT OCCURS, REPORT THE ERROR AND PASS OUT ABORT TEST INDICATOR.
3247 ;*
3248 021366 016704 160650 MOV CSRA,R4 ;GET THE ADDRESS OF THE DUT'S CSR.
3249 021372 030214 BIT R2,(R4) ;CHECK STATE OF MASTER RESET BIT.
3250 021374 001406 BEQ 2# ;DON'T DELAY IF MR IS ALREADY CLEAR.
3251 021376 005003 CLR R3 ;SET UP DESIRED STATE OF MASTER RESET BIT.
3252 021400 012701 011610 MOV #5000.,R1 ;PASS TIME-OUT VALUE OF 5 SECONDS.
3253 021404 004767 176554 JSR PC,MSLGET ;WAIT FOR SELF-TEST TO COMPLETE, MR CLEAR.
3254 021410 103012 BCC 4# ;GO REPORT ERROR IF TIMEOUT OCCURRED.
3255 ;*
3256 ;* SET MASTER RESET BIT IN CSR. CLEAR TX AND RX ENABLE BITS, ETC.
3257 ;* SKIP THE SELFTEST.
3258 ;* TIME-OUT OF 5 SECS, JUST IN CASE THE SELF-TEST EXECUTES.
3259 ;*
3260 ;*
3261 021412 010277 160624 2#: MOV R2,@CSRA ;SET MASTER RESET BIT, DISABLE TX AND RX INTS.
3262 021416 004767 000722 JSR PC,SKPSTS ;TRY TO SKIP THE SELFTEST.
3263 ;*
3264 ;* SET SELF TEST TIME-OUT OF 5 SECONDS, AND WAIT FOR M.R TO CLEAR.
3265 ;* IF TIME-OUT OCCURS, THEN REPORT THE FATAL ERROR AND PASS-OUT THE ABORT
3266 ;* TEST INDICATOR.
3267 ;*
3268 021422 005003 CLR R3 ;SET UP DESIRED STATE OF MASTER RESET BIT.
3269 021424 012701 011610 MOV #5000.,R1 ;PASS TIME-OUT VALUE OF 5 SECONDS.
3270 021430 004767 176530 JSR PC,MSLGET ;WAIT FOR SELF TEST TO COMPLETE, MR CLEAR.
3271 021434 103410 BCS 6# ;SKIP ERROR REPORT IF MR CLEARED IN TIME.

```

```

3272
3273 ; SET UP ERROR MESSAGE TO REPORT "FATAL ERROR FOUND DURING RESET, TEST ABORTED .
3274 ; INDICATE TEST IS TO BE ABORTED BY CLEARING THE CARRY BIT.
3275 ;
3276 021436 012701 012221 4$: MOV #EM1601,R1 ;PASS ERROR MESSAGE TO REPORT.
3277 021442 012767 016526 162324 MOV #ER1603,ERRBLK ;PASS ADDRESS OF ERROR HANDLING ROUTINE.
3278 ;REPORT ERROR "TIME OUT OCCURRED WAITING FOR MASTER RESET TO CLEAR'
3279 ; "TEST ABORTED"
3280 021450 ERROR ; >>>> ERROR <<<<
021450 104460 TRAP C$ERROR
3281 021452 000241 CLC ;INDICATE TEST IS TO BE ABORTED.
3282 021454 000403 BR 60$ ;EXIT THIS SUBROUTINE, ABORT TEST INDICATOR.
3283 ;
3284 ; CLEAR TX AND RX INTERRUPT ENABLE STATUS FLAGS IN IESTAT.
3285 ; EXIT WITH CONTINUE TEST INDICATOR SET (IE,CARRY SET).
3286 ;
3287 021456 005067 160626 6$: CLR IESTAT ;CLEAR TX AND RX INTERRUPT STATUS FLAGS.
3288 021462 000261 SEC ;INDICATE SUCCESS, CONTINUE TEST.
3289 ;
3290 021464 004736 60$: PASS ;RESTORE GPRS, PASS THE FOLLOWING INTACT:
021464 JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
3291 ;CARRY BIT:IF CLEAR,INDICATES ABORT TEST.
3292 RTS PC
3293
    
```

```

3295 .SBTTL GLOBAL SUBROUTINE ROLDAP
3296 :*****
3297 :* - ROTATE LEFT DATA PATTERN
3298 :* THIS ROUTINE ROTATES THE PASSED INPUT DATA PATTERN LEFT,WITHOUT GOING
3299 :* THROUGH THE CARRY.THE CARRY IS INITIALLY SET OR CLEARED DEPENDING
3300 :* UPON THE STATE OF THE MSB OF THE DATA PATTERN,BEFORE A ROL INSTRUCTION
3301 :* IS EXECUTED.
3302 :*
3303 :* INPUTS: R2 CONTAINS THE DATA PATTERN TO BE ROTATED
3304 :*
3305 :* OUTPUTS: R2 CONTAINS THE ROTATED DATA PATTERN
3306 :*
3307 :* CALLING SEQUENCE: JSR PC,ROLDAP
3308 :*
3309 :* COMMENTS:
3310 :*
3311 :* SUBORDINATE ROUTINES CALLED: NONE
3312 :*****
3313
3314 021470 ROLDAP::SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
021470 004567 162302 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3315 021474 005702 ;CHECK MSB, AND CLEAR CARRY.
021476 100001 ;BRANCH IF CLEAR.
3317 021500 000261 ;SET CARRY IF MSB SET
3318 021502 006102 2%: ROL R2 ;ROTATE DATA PATTERN LEFT
3319 021504 010266 000006 60%: PASS R2 ;RESTORE GPRS,EXCEPT
021504 004736 MOV R2,R2SLOT(SP) ;PUT R2 IN STACK SLOT.
021510 JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
3320 ;R2 - CONTAINS THE ROTATED DATA PATTERN
3321 021512 000207 RTS PC

```

```

3323 .SBTTL GLOBAL SUBROUTINE RSTRPT
3324 ;* *****
3325 ;* REPORT ANY RESET ERRORS ROUTINE
3326 ;* THIS ROUTINE DETERMINES IF ANY ERROR CODES ARE AMONG THE DIAGNOSTIC
3327 ;* CODES REPORTED PLACED IN THE DUT RECEIVED CHARACTER FIFO BY THE
3328 ;* SELF TEST. IF ANY NON BMP ERROR CODES ARE FOUND, OR IF OTHER ERRORS
3329 ;* ARE ENCOUNTERED, APPROPRIATE ERRORS ARE REPORTED. ANY BMP CODES THAT
3330 ;* ARE FOUND, ARE PLACED ON THE BMP CODE QUEUE TO BE REPORTED LATER.
3331 ;* THIS ROUTINE ALSO PURGES THE DUT FIFO LOOKING FOR ANY CHARACTERS
3332 ;* OR MODEM STATUS CODES. IF ANY ARE FOUND, ERRORS ARE REPORTED.
3333 ;*
3334 ;* INPUTS: ERRMSG ADDRESS OF THE PRIMARY ERROR MESSAGE.
3335 ;* ERRNBR ERROR NUMBER OF FIRST ERROR REPORTED BY THIS ROUTINE.
3336 ;* NUMLNS EQUATED TO THE NUMBER OF LINE ON THE DUT.
3337 ;* RBUFA CONTAINS ADDRESS OF THE DUT RECEIVER FIFO.
3338 ;*
3339 ;* OUTPUTS: CARRY - SUCCESS FLAG (SET IF FIFO CLEARED SUCCESSFULLY).
3340 ;* ERRBLK ADDRESS OF THE ERROR REPORT ROUTINE (DESTROYED).
3341 ;* ERROR MESSAGES CAN BE PRINTED AT THE OPERATORS CONSOLE.
3342 ;*
3343 ;* CALLING SEQUENCE: JSR PC,RSTRPT
3344 ;*
3345 ;* COMMENTS: THIS SUBROUTINE CAN REPORT ERRORS WITH NUMBERS INITIAL ERRNBR
3346 ;* THRU INITIAL ERRNBR+4.
3347 ;* THIS ROUTINE DOES NOT DESTROY THE VALUE OF ERRNBR.
3348 ;*
3349 ;* SUBORDINATE ROUTINES CALLED: ER0503,ER9007,ER9008.SAVBMP.
3350 ;* --- *****
3351
3352 021514 RSTRPT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
021514 004567 162256 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3353 ;*
3354 ;* READ CORRECT NUMBER (NUMBER OF LINE ON DUT) OF CHARS FROM THE FIFO.
3355 ;* VERIFY THAT EACH CHAR IS A SELFTEST SUCCESS CODE.
3356 ;* ---
3357 021520 005003 CLR R3 ;CLEAR THE CODE COUNTER.
3358 021522 016705 162242 MOV ERRNBR,R5 ;SAVE ERRNBR FOR RESTORATION LATER.
3359 021526 017702 160512 2$: MOV @RBUFA,R2 ;READ A CHAR FROM THE DUT FIFO.
3360 021532 100422 BMI 4$ ;SKIP ERROR IF DATA.VALID SET FOR CHAR.
3361 ;*
3362 ;* WE EXPECT A SELFTEST CODE, BUT THIS FIFO SLOT IS EMPTY.
3363 ;* ---
3364 021534 010567 162230 MOV R5,ERRNBR ;RESTORE ERROR NUMBER TO INITIAL VALUE.
3365 021540 012701 015127 MOV @EM9018,R1 ;PASS ERROR MESSAGE INFO TO ER9007 ROUTINE.
3366 021544 012767 017036 162222 MOV @ER9007,ERRBLK ;SELECT PROPER ERROR REPORT ROUTINE.
3367 ;*
3368 ;* REPORT ERROR WITH NUMBER INITIAL ERRNBR.
3369 ;* 'NO SELFTEST CODE IN SELFTEST CODE FIFO SLOT FOR LINE NN AFTER RESET.
3370 ;*
3371 021552 ERROR ; >>>> ERROR <<<<<.
021552 104460 TRAP C$ERRCR
3372 ;*
3373 ;* EXIT THIS ROUTINE IF EXTENDED ERROR REPORTING HAS NOT BEEN REQUESTED.
3374 ;* ---
3375 021554 032767 000100 160442 BIT @BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED :
3376 021562 001003 BNE 3$ ;AVOID SET THE FLAG IF IT HAS.
3377 021564 012767 000001 160512 MOV @1,EXOERR ;SET THE EXIT ON ERROR FLAG

```



```

3378
3379
3380
3381 (21572 000261
3382 (21574 000167 000406
3383
3384
3385
3386 021600 012700 070001
3387 (21604 040200
3388 021606 001042
3389
3390
3391
3392
3393 021610 032702 000200
3394 021614 001462
3395 021615 120227 000203
3396 021622 001457
3397 021624 120227 000201
3398 021630 001454
3399 021632 012700 000300
3400 021636 040200
3401 021640 001003
3402 021642 004767 000430
3403 021646 000445
3404
3405
3406
3407 021650 010567 162114
3408 021654 005267 162110
3409 021660 012701 015154
3410 021664 012767 017126 162102
3411
3412
3413
3414
3415 021672
021672 104460
3416
3417
3418
3419 021674 032767 000100 160322
3420 021702 001027
3421
3422 021704 012767 000001 160372
3423 021712 000534
3424
3425
3426
3427
3428 021714 010567 162050
3429 021720 062767 000002 162042
3430 021726 012701 015137
3431 021732 012767 017036 162034
3432
3433
;
; INIDICATE 'SUCCESS" (BECAUSE FIFO IS PURGED), AND EXIT THIS ROUTINE.
;
3$: SEC ;SET SUCCESS FLAG.
JMP 60$ ;EXIT ROUTINE.
;
; DETERMINE IF THIS IS NOT A SELFTEST CODE.
;
4$: MOV #70001,R0 ;GENERATE BIT MAP OF ANY CLEAR ERROR BITS OR
BIC R2,R0 ; BIT 0 WHICH ARE CLEAR.
BNE 8$ ;GO TO REPORT ERROR IF THIS IS NOT A TEST CODE.
;
; WE HAVE A TEST CODE (EITHER BMP OR SELFTEST CODE).
; DETERMINE WHAT TYPE OF CODE WE HAVE.
;
BIT #BIT7,R2 ;TEST ROM VERSION CODE INDICATOR BIT.
BEQ 10$ ;SKIP ERRORS IF SELFTEST ROM VERSION CODE.
CMPB R2,#203 ;CHECK IF SKIP SELF TEST CODE.
BEQ 10$ ;SKIP FRROR REPORT IF SKIP SELF TEST CODE FOUND
CMPB R2,#201 ;CHECK IF NULL CODE PRESENT.
BEQ 10$ ;SKIP ERROR REPORT IF SELF TEST NULL CODE.
MOV #300,R0 ;TEST CODE TYPE BITS FOR BOTH CODE
BIC R2,R0 ; TYPE BITS SET (INDICATING BMP CODE).
BNE 6$ ;IF IT IS NOT A BMP CODE GO REPORT ERROR.
JSR PC,SAVBMP ;SAVE THE BMP CODE ON THE QUEUE.
BR 10$ ;GO GET THE NEXT CHARACTER FROM THE FIFO.
;
; WE HAVE A SELFTEST ERROR CODE.
;
6$: MOV R5,ERRNBR ;RESTORE ERROR NUMBER TO INITIAL VALUE.
INC ERRNBR ;CALCULATE INITIAL ERROR NUMBER PLUS 1.
MOV #EM9020,R1 ;PASS ERROR MESSAGE INFO TO ER9008 ROUTINE.
MOV #ER9008,ERRBLK ;SELECT PROPER ERROR REPORT ROUTINE.
;
; REPORT ERROR WITH NUMBER INITIAL ERRNBR + 1.
; "UNEXPECTED SELFTEST ERROR CODE FOR LINE NN IN FIFO AFTER RESET:"
;
ERROR ; >>>> ERROR <<<<<.
TRAP C$ERROR
;
; EXIT THIS ROUTINE IF EXTENDED ERROR REPORTING HAS NOT BEEN REQUESTED.
;
BIT #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
BNE 10$ ;AVOID SET THE FLAG IF IT HAS AND GO TO
;THE END OF THE LOOP.
MOV #1,EXOERR ;SET THE "EXIT ON ERROR" FLAG
BR 50$ ;EXIT THE ROUTINE WITH FAILURE SINCE THE FIFO
;IS NOT PRUGED.
;
; WE HAVE A NON-SELFTEST CODE (EITHER BMP CODE OR DATA CHAR).
;
8$: MOV R5,ERRNBR ;RESTORE ERROR NUMBER TO INITIAL VALUE.
ADD #2,ERRNBR ;CALCULATE INITIAL ERROR NUMBER PLUS 2.
MOV #EM9019,R1 ;PASS ERROR MESSAGE INFO TO ER9007 ROUTINE.
MOV #ER9007,ERRBLK ;SELECT PROPER ERROR REPORT ROUTINE.
;
; REPORT ERROR WITH NUMBER INITIAL ERRNBR + 2.

```

```

3434 ; "NON SELFTEST CODE IN SELFTEST CODE FIFO SLOT FOR LINE NN AFTER RESET.
3435 ;
3436 021740 ; ERROR ; >>>> ERROR <<<<<. TRAP C$ERROR
      021740 104460
3437 ;*
3438 ; EXIT THIS ROUTINE IF EXTENDED ERROR REPORTING HAS NOT BEEN REQUESTED.
3439 ;-
3440 021742 032767 000100 160254 BIT #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
3441 021750 001004 BNE 10$ ;AVOID SET THE FLAG IF IT HAS AND GO TO
3442 ;THE END OF THE LOOP.
3443 021752 012767 000001 150324 MOV #1,EXOERR ;SET THE "EXIT ON ERROR" FLAG
3444 021760 000511 BR 50$ ;EXIT THE ROUTINE WITH FAILURE.
3445
3446 ;*
3447 ; END C LOOP, LOOP IF NOT ALL CHARS HAVE BEEN READ FROM THE FIFO.
3448 ;-
3449 021762 005203 10$: INC R3 ;SET CODE COUNTER FOR NEXT ITERATION OF LOOP.
3450 021764 020327 000010 CMP R3,#8. ;TEST FOR ALL CODES READ.
3451 021770 002656 BLT 2$ ;LOOP IF NOT CHARS READ FROM FIFO.
3452 ;*
3453 ; PURGE THE FIFO UNTIL DATA.VALID IS CLEAR OR UNTIL TOO MANY CHARS ARE READ.
3454 ;
3455 021772 012704 000022 MOV #18,R4 ;INITIALIZE THE CHARACTER COUNTER.
3456 021776 010567 161766 MOV R5,ERRNBR ;GET INITIAL VALUE OF THE ERROR NUMBER.
3457 022002 062767 000003 161760 ADD #3,ERRNBR ;CALCULATE ERROR NUMBER OF NEXT ERROR.
3458 022010 012767 017126 161756 MOV #ER9008,ERRBLK ;SELECT PROPER ERROR REPORT ROUTINE.
3459 022016 017702 160222 12$: MOV #RBUFA,R2 ;READ A CHARACTER FROM THE DUT FIFO.
3460 022022 000261 SEC ;INDICATE SUCCESS IN CASE DATA.VALID IS CLEAR.
3461 022024 100070 BPL 60$ ;EXIT ROUTINE WITH SUCCESS IF DATA.VALID CLEAR.
3462 ;*
3463 ; WE HAVE A CHARACTER.
3464 ; DETERMINE IF CHARACTER IS A DATA CHARACTER.
3465 ;
3466 022026 012700 070000 MOV #70000,R0 ;TEST BITS 12 THRU 14 OF THE
3467 022032 040200 BIC R2,R0 ; CODE READ FROM THE DUT FIFO.
3468 022034 001403 BEQ 14$ ;SKIP THIS ERROR IF CODE IS NOT A DATA CHAR.
3469 ;*
3470 ; WE HAVE AN UNEXPECTED DATA CHARACTER: SET UP AND GO TO REPORT ERROR.
3471 ;
3472 022036 012701 015200 MOV #EM9022,R1 ;SELECT ERROR MSG INFO FOR ER0808 ROUTINE.
3473 022042 000423 BR 22$ ;GO TO REPORT THIS ERROR.
3474 ;*
3475 ; WE HAVE AN UNEXPECTED CODE.
3476 ; DETERMINE IF THE CODE IS A MODEM STATUS CODE.
3477 ;-
3478 022044 032702 000001 14$: BIT #BIT0,R2 ;TEST MODEM STATUS INDICATOR BIT OF CODE.
3479 022050 001003 BNE 16$ ;SKIP THIS ERROR IF NOT MODEM STATUS CODE.
3480 ;*
3481 ; WE HAVE A MODEM STATUS CODE: SET UP AND GO TO REPORT ERROR.
3482 ;
3483 022052 012701 015217 MOV #EM9023,R1 ;SELECT ERROR MSG INFO FOR ER0808 ROUTINE.
3484 022056 000415 BR 22$ ;GO TO REPORT THIS ERROR.
3485 ;*
3486 ; WE HAVE AN ONBOARD TEST CODE.
3487 ; DETERMINE IF THIS CODE IS A BMP CODE.
3488 ;
3489 022060 032702 000200 16$: BIT #BIT7,R2 ;TEST THE ROM VERSION BIT OF THE CODE.

```

```

3490 022064 001404          BEQ      18$          ;GOTO SET UP FOR SELFTEST CODE IF ROM VERSION.
3491 022066 012700 000300    MOV      #300,R0
3492 022072 040200          BIC      R2,R0        ;TEST THE ERROR TYPE BITS OF THE CODE.
3493 022074 001403          BEQ      20$          ;SKIP THIS ERROR IF BMP CODE.
3494
3495          ;+
3496          ; WE HAVE A SELFTEST CODE: SET UP AND GO TO REPORT ERROR.
3497 022076 012701 015241    18$:    MOV      #EM9024,R1    ;SELECT ERROR MSG INFO FOR ER0808 ROUTINE.
3498 022102 000403          BR       22$          ;GO TO REPORT THIS ERROR.
3499
3500          ;+
3501          ; WE HAVE A BMP CODE: SAVE IT ON THE QUEUE.
3502 022104 004767 000166    20$:    JSR      PC,SAVBMP    ;SAVE THE BMP CODE ON THE QUEUE.
3503 022110 000411          BR       24$          ;
3504
3505          ;+
3506          ; REPORT THE ERROR WITH ERROR NUMBER OF INITIAL ERRNBR + 3.
3507          ; "UNEXPECTED XXX XXXX FOR LINE NN IN FIFO AFTER RESET:"
3508 022112          22$:    ERROR          ;          >>>> ERROR <<<<<.
3509 022112 104460          TRAP      C$ERROR
3510
3511          ;+
3512          ; EXIT THIS ROUTINE IF EXTENDED ERROR REPORTING HAS NOT BEEN REQUESTED.
3513 022114 032767 000100 160102  BIT      #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
3514 022122 001004          BNE      24$          ;AVOID SETTING THE FLAG IF IT HAS AND GO TO
3515          ; THE END OF THE LOOP.
3516 022124 012767 000001 160152  MOV      #1,EXOERR    ;SET THE "EXIT ON ERROR" FLAG
3517 022132 000424          BR       50$          ;EXIT THE ROUTINE WITH FAILURE.
3518
3519          ;+
3520          ; END OF LOOP.
3521          ; COUNT THE CHARACTER WE JUST RECEIVED, AND CHECK FOR TOO MANY RECEIVED.
3522 022134 005304          24$:    DEC      R4          ;COUNT THIS CHARACTER.
3523 022136 001327          BNE      12$          ;LOOP IF NOT TOO MANY CHARACTERS PURGED.
3524
3525          ;+
3526          ; WE READ TOO MANY VALID CHARACTERS WHILE TRYING TO PURGE THE FIFO.
3527          ; REPORT ERROR AND EXIT WITHOUT SUCCESS.
3528          ; "FIFO WILL NOT PURGE (DATA.VALID STUCK SET), REMAINDER OF TEST SKIPPED."
3529 022140 012701 015016          MOV      #EM9017,R1    ;SELECT PROPER ERROR MESSAGE.
3530 022144 010567 161620          MOV      R5,ERRNBR    ;GET INITIAL ERROR NUMBER.
3531 022150 062767 000004 161612  ADD      #4,ERRNBR    ;CALCULATE INITIAL ERRNBR + 4.
3532 022156 012767 016136 161610  MOV      #ER0503,ERRBLK ;SELECT PROPER ERROR REPORT ROUTINE.
3533          ;PRINT ERROR REPORT.
3534 022164          ERROR          ;          >>>> ERROR <<<<<.
3535 022164 104460          TRAP      C$ERROR
3536
3537          ;+
3538          ; EXIT THIS ROUTINE IF EXTENDED ERROR REPORTING HAS NOT BEEN REQUESTED.
3539 022166 032767 000100 160030  BIT      #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
3540 022174 001003          BNE      50$          ;AVOID SETTING THE FLAG IF IT HAS.
3541 022176 012767 000001 160100  MOV      #1,EXOERR    ;SET THE "EXIT ON ERROR" FLAG
3542          ;
3543          ;
3544 022204 000241          50$:    CLC          ;CLEAR THE SUCCESS FLAG.
3545          ;
3546 022206          60$:    PASS          ;RESTORE GPRS.

```

022206 004736
3545 022210 000207

RTS PC

JSR

PC,@(SP)+
; CARRY

SUCCESS FLAG (SET IF FIFO IS PURGED).
; RETURN TO PREGOS SUBRT.

C8

```

3547 .SBTTL GLOBAL SUBROUTINE RXIEO
3548 ;* *****
3549 ;* RECEIVER INTERRUPT DISABLE
3550 ;* THIS ROUTINE IS USED TO DISABLE RECEIVER INTERRUPTS IN THE DMU11.
3551 ;*
3552 ;* INPUTS: NONE.
3553 ;*
3554 ;* OUTPUTS: THE RX.INT.ENBL BIT IS CLEARED IN THE DUT CSR.
3555 ;* IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
3556 ;* ENABLE BITS.
3557 ;*
3558 ;* CALLING SEQUENCE: JSR PC,RXIEO
3559 ;*
3560 ;* COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
3561 ;* THE DUT CSR ARE DESTROYED.
3562 ;*
3563 ;* SUBORDINATE ROUTINES CALLED: NONE.
3564 ;* *****
3565 022212 010046 RXIEO:: MOV RO,-(SP) ;SAVE CONTENTS OF RO ON THE STACK.
3566 022214 GETPRI -(SP) ;SAVE PROCESSOR PRIORITY ON STACK.
3567 022214 104440 TRAP C:GPRI
022216 010046 MOV RO,(SP)
022220 SETPRI @PRI07 ;IGNORE ANY INTERRUPT THAT MAY BE GENERATED.
022220 012700 000340 MOV @PRI07,RO
022224 104441 TRAP C:SPRI
3568 022226 042767 137777 160054 BIC @137777,IESTAT ;CLEAR RX.INT.ENBL BIT IN IESTAT.
3569 022234 016777 160050 160000 MOV IESTAT,@CSRA ;DISABLE RX INTERRUPTS.
3570 022242 SETPRI (SP)+ ;ENABLE INTERRUPTS TO THE PROCESSOR AGAIN.
022242 012600 MOV (SP)+,RO
022244 104441 TRAP C:SPRI
3571 022246 012600 MOV (SP)+,RO ;RESTORE RO.
3572 022250 000207 RTS PC
    
```

```

3574 .SBTTL GLOBAL SUBROUTINE RXIE1
3575 ;* *****
3576 ;* RECEIVER INTERRUPT ENABLE
3577 ;* THIS ROUTINE IS USED TO ENABLE RECEIVER INTERRUPTS IN THE DMU11.
3578 ;*
3579 ;* INPUTS: NONE.
3580 ;*
3581 ;* OUTPUTS: THE RX.INT.ENBL BIT IS SET IN THE DUT CSR.
3582 ;* IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
3583 ;* ENABLE BITS.
3584 ;*
3585 ;* CALLING SEQUENCE: JSR PC,RXIE1
3586 ;*
3587 ;* COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
3588 ;* THE DUT CSR ARE DESTROYED.
3589 ;*
3590 ;* SUBORDINATE ROUTINES CALLED: NONE.
3591 ;* - - *****
3592
3593 022252 052767 000100 160030 RXIE1:: BIS @BIT06,IESTAT ;SET RX.INT.ENBL BIT IN IESTAT.
3594 022260 042767 137677 160022 BIC @137677,IESTAT ;CLEAR ALL OTHER BITS, EXCEPT TX AND RX I.E.
3595 022266 016777 160016 157746 MOV IESTAT,@CSRA ;ENABLE RX INTERRUPTS.
3596 022274 000207 RTS PC

```

3598
3599
3600
3601
3602
3603
3604
3605
3606
3607
3608
3609
3610
3611
3612
3613
3614
3615
3616
3617
3618
3619
3620
3621 022276
022276 004567 161474
3622 022302 016704 160216
3623 022306 116724 160012
3624 022312 005204
3625 022314 042702 177400
3626 022320 010224
3627 022322 020427 002726
3628 022326 103402
3629 022330 162704 000004
3630 022334 010467 160164
3631
3632 022340
022340 004736
3633 022342 000207

```
.SBTTL GLOBAL SUBROUTINE - SAVBMP
; * *****
; * - SAVE BMP CODES ROUTINE
; * THIS ROUTINE SAVES THE PARAMETER PASSED IN, ONTO THE BMP CODE QUEUE
; * TOGETHER WITH THE NUMBER OF THE CURRENTLY EXECUTING TEST.
; *
; * INPUTS: R2 - CONTAINS THE BMP CODE THAT IS TO BE PLACED ON THE QUEUE.
; * BMPCQP - CONTAINS ADDRESS OF NEXT LOCATION IN THE BMP QUEUE.
; * BMPCQB - LABEL AT BASE OF THE BMP CODE QUEUE.
; * BMPCQE - LABEL OF NEXT LOCATION AFTER THE END OF THE BMP QUEUE.
; * TSTNUM - CONTAINS THE NUMBER OF THE CURRENT TEST.
; *
; * OUTPUTS: BMPCQP - INCREMENTED BY 4.
; * THE CONTENTS OF THE BMP CODE QUEUE ARE UPDATED.
; *
; * CALLING SEQUENCE: JSR PC,SAVBMP
; *
; * COMMENTS: IF THE OVERFLOW OCCURS THEN THE LAST LOCATION WILL BE
; * OVERWRITTEN BY ANY SUBSEQUENT ATTEMPTS TO UPDATE THE QUEUE.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; * - - *****
SAVBMP:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV BMPCQP,R4 ;GET THE POINTER TO THE NEXT LOCATION IN QUEUE.
MOVB TSTNUM,(R4)+ ;SAVE THE CURRENT TEST NUMBER ON THE QUEUE.
INC R4 ;INCREMENT THE POINTER TO GIVE AN EVEN ADDRESS.
BIC @177400,R2 ;CLEAR THE UNWANTED BITS FROM THE BMP CODE.
MOV R2,(R4)+ ;SAVE THE BMP CODE ON THE QUEUE.
CMP R4,@BMPCQE ;CHECK IF OVERFLOW WILL OCCUR THE NEXT TIME.
BLO 2$ ;GO SAVE THE POINTER IF WE WILL NOT OVERFLOW.
SUB @4,R4 ;RESET THE POINTER TO THE LAST LOCATION IN QUE.
2$: MOV R4,BMPCQP ;SAVE THE POINTER.

60$: PASS ;RESTORE GPRS.
JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.

RTS PC
```

```

3635 .SBTTL GLOBAL SUBROUTINE - SKPSTS
3636 ;* *****
3637 ;* - SKIP SEL TEST ROUTINE -
3638 ;* THIS SUBROUTINE IS USED TO SKIP THE SELFTEST AFTER A DUT RESET HAS BEEN
3639 ;* INITIATED. IT MUST BE ENTERED IMMEDIATELY AFTER SETTING THE DUT MASTER
3640 ;* RESET ROUTINE OR AFTER THE EXECUTION OF A BUS RESET (BECAUSE OF TIMING
3641 ;* CONSIDERATIONS).
3642 ;*
3643 ;* INPUTS: CSRA - CONTAINS ADDRESS OF THE DUT CSR.
3644 ;* TXBFCA CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
3645 ;*
3646 ;* OUTPUTS: SKIP SELFTEST CODES ARE WRITTEN TO THE DUT REGISTERS.
3647 ;*
3648 ;* CALLING SEQUENCE: JSR PC,SKPSTS
3649 ;*
3650 ;* COMMENTS:
3651 ;*
3652 ;* SUBORDINATE ROUTINES CALLED: DELAY.
3653 ;* - *****
3654
3655 022344 SKPSTS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
022344 004567 161426 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3656 022350 012704 000012 MOV #10.,R4 ;PASS DELAY VALUE OF 10 MILLI-SECONDS.
3657 022354 004767 175544 JSR PC,DELAY ;DELAY FOR 10 MILLI-SECONDS.
3658 ;*
3659 ; WRITE SKIP SELF-TEST CODE (52525) TO ALL THE INDEXED DUT REGISTERS.
3660 ; -
3661 022360 012701 000060 MOV #NUMLNS!BIT05,R1 ;FORM IND.ADR.REG FIELD (PLUS M.R. BIT) WORD.
3662 ; THE ABOVE INCLUSION OF THE M.R. BIT IS NECESSARY BECAUSE OF THE
3663 ; LACK OF A M.R. BIT WRITE LOCK-OUT ON THE DMU-11.
3664 022364 012703 052525 MOV #52525,R3 ;INITIALISE THE SKIP SELF-TEST CODE.
3665 022370 005301 4$: DEC R1 ;SELECT THE NEXT SET OF DEVICE REGISTERS.
3666 022372 016704 157644 MOV CSRA,R4 ;GET THE ADDRESS OF THE CSR OF THE DUT.
3667 022376 010124 MOV R1,(R4)+ ;SELECT A BANK OF DUT REGISTERS.
3668 022400 010324 6$: MOV R3,(R4)+ ;WRITE THE CODE TO A DUT REGISTER.
3669 022402 020467 157652 CMP R4,TXBFCA ;COMPARE POINTER WITH LAST REGISTER ADDRESS.
3670 022406 103774 BLO 6$ ;LOOP IF NOT ALL REGS DONE IN THIS BANK.
3671 022410 032701 000017 BIT #17,R1 ;TEST FOR IND.ADR.REG FIELD DECREMENTED TO 0.
3672 022414 001365 BNE 4$ ;LOOP UNTIL ALL REGISTERS CONTAIN THE CODE.
3673
3674 022416 60$: PASS ;RESTORE GPRS.
022416 004736 JSR PC,#(SP)+ ;RETURN TO PREG05 SUBRT.
3675 022420 000207 RTS PC

```


3677
3678
3679
3680
3681
3682
3683
3684
3685
3686
3687
3688
3689
3690
3691
3692
3693
3694
3695
3696
3697
3698
3699 022422 010046
3700
3701
3702
3703 022424 010146
3704 022426 010246
3705 022430 010346
3706 022432 010446
3707 022434 010546
3708
3709
3710
3711 022436 012700 002450
3712 022442 012001
3713 022444 012002
3714 022446 012003
3715 022450 012004
3716 022452 012005
3717
3718
3719
3720 022454 012640
3721 022456 012640
3722 022460 012640
3723 022462 012640
3724 022464 012640
3725
3726 022466 012600
3727
3728 022470 000207

```
.SBTTL GLOBAL SUBROUTINE SWAPO -
; * *****
; * SWAP GPRS WITH GPR SET 0 ROUTINE -
; * THIS SUBROUTINE SWAPS THE PRESENT CONTENTS OF GPRS R1 THRU R5 WITH
; * THE CONTENTS OF THE NUMBER ZERO GPR SAVE AREA. THE CONTENTS OF R0
; * ARE NOT ALTERED BY THIS SUBROUTINE.
; *
; * INPUTS: GPR CONTENTS R1 THRU R5.
; * GPRS0B LABEL AT BASE OF GPR SAVE AREA NUMBER ZERO.
; *
; * OUTPUTS: R1 THRU R5 CONTAIN THE PREVIOUS CONTENTS OF GPR SAVE AREA
; * ZERO WORDS 1 THRU 5 RESPECTIVELY.
; * GPRS0 GPR SAVE AREA 0 WORDS 1 THRU 5, CONTAIN PREVIOUS
; * CONTENTS OF GPRS R1 THRU R5 RESPECTIVELY.
; *
; * CALLING SEQUENCE: JSR PC,SWAPO
; *
; * COMMENTS: THE STATE OF THE CARRY FLAG IS NOT ALTERED BY THIS ROUTINE.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; - *****

SWAPO:: MOV R0,-(SP) ;SAVE THE CONTENTS OF R0.
; *
; * LOAD THE STACK FROM THE GPRS.
; -
MOV R1,-(SP) ;SAVE THE CONTENTS OF R1.
MOV R2,-(SP) ;SAVE THE CONTENTS OF R2.
MOV R3,-(SP) ;SAVE THE CONTENTS OF R3.
MOV R4,-(SP) ;SAVE THE CONTENTS OF R4.
MOV R5,-(SP) ;SAVE THE CONTENTS OF R5.
; *
; * LOAD THE GPRS FROM THE GPR SAVE AREA 0.
; -
MOV #GPRS0B,R0 ;GET THE BASE ADDRESS OF GPR SAVE AREA 0.
MOV (R0)+,R1 ;LOAD R1 WITH GPR SAVE AREA 0 WORD 1.
MOV (R0)+,R2 ;LOAD R1 WITH GPR SAVE AREA 0 WORD 2.
MOV (R0)+,R3 ;LOAD R1 WITH GPR SAVE AREA 0 WORD 3.
MOV (R0)+,R4 ;LOAD R1 WITH GPR SAVE AREA 0 WORD 4.
MOV (R0)+,R5 ;LOAD R1 WITH GPR SAVE AREA 0 WORD 5.
; *
; * LOAD THE GPR SAVE AREA 0 FROM THE STACK.
; -
MOV (SP)+,(R0) ;LOAD GPR SAVE AREA 0 WORD 5 WITH SAVED R5.
MOV (SP)+,-(R0) ;LOAD GPR SAVE AREA 0 WORD 4 WITH SAVED R4.
MOV (SP)+,-(R0) ;LOAD GPR SAVE AREA 0 WORD 3 WITH SAVED R3.
MOV (SP)+,-(R0) ;LOAD GPR SAVE AREA 0 WORD 2 WITH SAVED R2.
MOV (SP)+,(R0) ;LOAD GPR SAVE AREA 0 WORD 1 WITH SAVED R1.
MOV (SP)+,R0 ;RESTORE THE INITIAL VALUE OF R0.
RTS PC
```

```

3730
3731
3732
3733
3734
3735
3736
3737
3738
3739
3740
3741
3742
3743
3744
3745
3746
3747
3748
3749
3750
3751 022472
      022472 004567 161300
3752 022476 012701 022514
3753 022502 012767 016526 161264
3754 022510
      022510 104460
3755 022512 000432
3756 022514 040 116 117 2$:
      022517 116 055 122
      022522 105 114 101
      022525 124 105 104
      022530 040 124 105
      022533 123 124 040
      022536 105 122 122
      022541 117 122 040
      022544 106 117 125
      022547 116 104 040
      022552 104 125 122
      022555 111 116 107
      022560 040 124 105
      022563 123 124 040
      022566 105 130 105
      022571 103 125 124
      022574 111 117 116
      022577 000
3757
3758 022600
      022600 004736
3759 022602 000207

```

```

.SBTTL GLOBAL SUBROUTINE TSABRT
;*****
;* TEST ABORT ROUTINE -
;* THIS SUBROUTINE IS USED WHEN A NON TEST RELATED ERROR HAS BEEN FOUND
;* DURING THE EXECUTION OF THE CURRENT TEST.
;* IT IS USED TO INFORM THE OPERATOR THAT THE CURRENT TEST HAS BEEN
;* ABORTED.
;*
;* INPUTS: ERRMSG - CONTAINS THE NAME OF THE CURRENT TEST.
;*          ERRNBR - CONTAINS THE CORRECT ERROR NUMBER.
;*          THE REMAINDER OF THE ERRTBL IS CORRECTLY INITIALISED.
;*
;* OUTPUTS: MESSAGES ARE REPORTED TO THE OPERATOR.
;*
;* CALLING SEQUENCE: JSR PC,TSABRT
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: ER1603.
; - *****
TSABRT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
          JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
          MOV #2$,R1 ;PASS ADDRESS OF FIRST MESSAGE TO BE REPORTED.
          MOV #ER1603,ERRBLK ;SET-UP THE ERROR REPORTING ROUTINE.
          ERROR ; >>>> ERROR <<<<<. TRAP C$ERROR
          BR 60$ ;
2$: .ASCIZ / NON-RELATED TEST ERROR FOUND DURING TEST EXECUTION/
;
.EVEN
60$: PASS JSR ;RESTORE GPRS.
          RTS PC JSR PC,@(SP), ;RETURN TO PREG05 SUBRT.

```

```

3761 .SBTTL GLOBAL SUBROUTINE TXDSBL
3762 ;* *****
3763 ;* TRANSMITTER DISABLE
3764 ;* THIS SUBROUTINE IS USED TO DISABLE TRANSMISSION ON SELECTED LINES BY,
3765 ;* CLEARING THE ASSOCIATED TX.ENABLE BIT ON THE DUT.
3766 ;*
3767 ;* INPUTS: R5 BIT'S SET CORRESPOND TO LINES ON WHICH TO CLEAR TX.ENABLE.
3768 ;* CSRA CONTAINS THE ADDRESS OF THE DUT CSR.
3769 ;* IESTAT CONTAINS THE STATE OF TXIE AND RXIE BITS IN THE CSR.
3770 ;* NUMLNS EQUATED TO BE THE MAXIMUM NUMBER OF LINES AVAILABLE.
3771 ;* TXAD2A CONTAINS THE ADDRESS OF THE TBUFFAD2 REGISTER.
3772 ;*
3773 ;* OUTPUTS: R5 - BIT'S SET INDICATE THE INITIAL STATES OF ALL TX.ENABLE BITS.
3774 ;* TBUFFAD2 THE STATE OF THE TX.ENABLE BIT MAY BE ALTERED.
3775 ;* THE CONTENTS OF THE IND.ADD.REG FIELD IN THE CSR ARE DESTROYED.
3776 ;*
3777 ;* CALLING SEQUENCE: JSR PC,TXDSBL
3778 ;*
3779 ;* COMMENTS:
3780 ;*
3781 ;* SUBORDINATE ROUTINES CALLED: NONE.
3782 ;* *****
3783 ;
3784 TXDSBL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
022604 004567 161166 JSR R5,PREGOS ;CALL REGISTER SAVE SUBRT.
022610 010500 MOV R5,R0 ;COPY BIT MAP OF LINES TO DISABLE TRANSMISSION.
3785 022610 010500 MOV #BIT0,R1 ;INITIALIZE THE SELECTED LINE BIT MASK.
3786 022612 012701 000001 MOV TXAD2A,R2 ;GET THE ADDRESS OF THE TBUFFAD2 REGISTER.
3787 022616 016702 157434 INC R2 ;GET THE ADDRESS OF THE MSBYTE OF TBUFFAD2 REG.
3788 022622 005202 MOV #NUMLNS,R3 ;GET MAXIMUM LINE NUMBER PLUS ONE.
3789 022624 012703 000020 MOV IESTAT,R4 ;GET THE STATES OF THE INT ENABLE BITS.
3790 022630 016704 157454 MOV CLR R5 ;LOG POSSIBLE TX DISABLED ON ALL LINES.
3791 022634 005005
3792 ;*
3793 ; SELECT EVERY LINE IN TURN, AND LOG THE STATE OF EACH TX.ENABLE BIT.
3794 ;
3795 022636 010477 157400 2$: MOV R4,@CSRA ;WRITE TO DUT CSR TO SELECT LINE REGISTERS.
3796 022642 105712 TSTB (R2) ;CHECK STATE OF TX.ENABLE BIT ON SELECTED LINE.
3797 022644 100001 BPL 4$ ;SKIP NEXT INSTRUCTION IF TX.ENABLE CLEAR.
3798 022646 050105 BIS R1,R5 ;LOG TX ENABLE BIT SET FOR SELECTED LINE.
3799 ;*
3800 ; CLEAR TX.ENABLE ON LINES THAT HAVE A CORRESPONDING BIT SET IN THE TX DISABLE
3801 ; LINE BIT MAP.
3802 ;
3803 022650 030100 4$: BIT R1,R0 ;CHECK STATE OF DISABLE LINE BIT MAP.
3804 022652 001402 BEQ 6$ ;BRANCH IF THIS LINE TO REMAIN UNALTERED.
3805 022654 142712 000200 BICB #BIT7,(R2) ;CLEAR TX.ENABLE BIT ON SELECTED LINE.
3806 022660 005204 6$: INC R4 ;PREPARE TO SELECT REGISTERS FOR NEXT LINE.
3807 022662 006301 ASL R1 ;SHIFT BIT MAP FOR NEXT LINE.
3808 022664 005303 DEC R3 ;DECREMENT LINE NUMBER.
3809 022666 001363 BNE 2$ ;LOOP TO CHECK NEXT LINE.
3810 ;
3811 022670 60$: PASS R5 ;RESTORE GPRS,EXCEPT
022670 010566 000014 MOV R5,R5SLOT(SP) ;PUT R5 IN STACK SLOT.
022674 004736 JSR PC,@(SP) ;RETURN TO PREGOS SUBRT.
3812 ;R5 PREVIOUS STATES OF ALL TX.ENABLE BITS.
3813 022676 00C207 RTS PC

```

```

3815 .SBTTL GLOBAL SUBROUTINE TXENBL
3816 ;* *****
3817 ;* TRANSMITTER ENABLE
3818 ;* THIS SUBROUTINE IS USED TO ENABLE TRANSMISSION ON SELECTED LINES BY
3819 ;* SETTING THE ASSOCIATED TX.ENABLE BIT ON THE DUT.
3820 ;*
3821 ;* INPUTS: R5 BIT'S SET CORRESPOND TO LINES ON WHICH TO SET TX.ENABLE.
3822 ;* CSRA - CONTAINS THE ADDRESS OF THE DUT CSR.
3823 ;* IESTAT - CONTAINS THE STATE OF TXIE AND RXIE BITS IN THE CSR.
3824 ;* NUMLNS EQUATED TO BE THE MAXIMUM NUMBER OF LINES AVAILABLE.
3825 ;* TXAD2A CONTAINS THE ADDRESS OF THE TBUFAD2 REGISTER.
3826 ;*
3827 ;* OUTPUTS: R5 BIT'S SET INDICATE PREVIOUSLY DISABLED LINES.
3828 ;* TBUFAD2 - THE STATE OF THE TX.ENABLE BIT MAY BE ALTERED.
3829 ;* THE CONTENTS OF THE IND.ADD.REG FIELD IN THE CSR ARE DESTROYED.
3830 ;*
3831 ;* CALLING SEQUENCE: JSR PC,TXENBL
3832 ;*
3833 ;* COMMENTS:
3834 ;*
3835 ;* SUBORDINATE ROUTINES CALLED: NONE.
3836 ;*
3837 ;*
3838 TXENBL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
022700 004567 161072 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3839 022704 010500 MOV R5,R0 ;COPY BIT MAP OF LINES TO ENABLE.
3840 022706 012701 000001 MOV #BIT0,R1 ;INITIALIZE THE SELECTED LINE BIT MASK.
3841 022712 016702 157340 MOV TXAD2A,R2 ;GET THE ADDRESS OF THE TBUFAD2 REGISTER.
3842 022716 005202 INC R2 ;GET THE ADDRESS OF THE MSBYTE OF TBUFAD2 REG.
3843 022720 012703 000020 MOV #NUMLNS,R3 ;GET MAXIMUM LINE NUMBER.
3844 022724 016704 157360 MOV IESTAT,R4 ;GET THE STATES OF THE INT ENABLE BITS.
3845 022730 005005 CLR R5 ;CLEAR TX.ENABLE BIT LOG OF DISABLED LINES.
3846 ;*
3847 ;* SELECT EVERY LINE IN TURN,AND LOG ANY TX.ENABLE BIT THAT IS CLEAR.
3848 ;*
3849 022732 010477 157304 2$: MOV R4,@CSRA ;WRITE TO DUT CSR TO SELECT LINE REGISTERS.
3850 022736 105712 TSTB (R2) ;CHECK STATE OF TX.ENABLE BIT ON SELECTED LINE.
3851 022740 100401 BMI 4$ ;SKIP NEXT INSTRUCTION IF TX.ENABLE SET.
3852 022742 050105 BIS R1,R5 ;LOG TX ENABLE BIT CLEAR FOR SELECTED LINE.
3853 ;*
3854 ;* SET TX.ENABLE ON LINES THAT HAVE A CORRESPONDING BIT SET IN THE TX ENABLE
3855 ;* LINE BIT MAP.
3856 ;*
3857 022744 030100 4$: BIT R1,R0 ;CHECK STATE OF TX.ENABLE LINE BIT MAP.
3858 022746 001402 BEQ 6$ ;BRANCH IF THIS LINE TO REMAIN UNALTERED.
3859 022750 152712 000200 BISB #BIT7,(R2) ;ENABLE TRANSMISSION ON SELECTED LINE.
3860 022754 005204 6$: INC R4 ;PREPARE TO SELECT REGISTERS FOR NEXT LINE.
3861 022756 006301 ASL R1 ;SHIFT BIT MAP FOR NEXT LINE.
3862 022760 005303 DEC R3 ;DECREMENT LINE NUMBER.
3863 022762 001363 BNE 2$ ;LOOP TO CHECK NEXT LINE.
3864 ;*
3865 022764 010566 000014 60$: PASS R5 ;RESTORE GPRS,EXCEPT
022764 010566 000014 MOV R5,R5SLOT(SP) ;PUT R5 IN STACK SLOT.
022770 004736 JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
3866 ;R5 LINE BIT MAP CORRESPONDING TO THE
3867 ; PREVIOUS LINES THAT WERE DISABLED.
3868 022772 000207 RTS PC

```

```

3870 .SBTTL GLOBAL SUBROUTINE TXIEO
3871 ;* *****
3872 ;* TRANSMITTER INTERRUPT DISABLE
3873 ;* THIS ROUTINE IS USED TO DISABLE TRANSMITTER INTERRUPTS IN THE DMU11.
3874 ;*
3875 ;* INPUTS: NONE.
3876 ;*
3877 ;* OUTPUTS: THE TX.INT.ENBL BIT IS CLEARED IN THE DUT CSR.
3878 ;* IESTAT -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
3879 ;* ENABLE BITS.
3880 ;*
3881 ;* CALLING SEQUENCE: JSR PC,TXIEO
3882 ;*
3883 ;* COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
3884 ;* THE DUT CSR ARE DESTROYED.
3885 ;*
3886 ;* SUBORDINATE ROUTINES CALLED: NONE.
3887 ;* *****
3888 022774 010046 TXIEO:: MOV RO,-(SP) ;SAVE CONTENTS OF RO ON THE STACK.
3889 022776 GETPRI -(SP) ;SAVE CURRENT PROCESSOR PRIORITY ON THE STACK.
023000 010046 TRAP C$GPRI
3890 023002 SETPRI @PRI07 ;IGNORE ANY INTERRUPTS THAT MAY BE GENERATED.
023002 012700 000340 MOV @PRI07,RO
023006 104441 TRAP C$SPRI
3891 023010 042767 177677 157272 BIC @177677,IESTAT ;CLEAR TX.INT.ENBL BIT IN IESTAT.
3892 023016 016777 157266 157216 MOV IESTAT,@CSRA ;DISABLE TX INTERRUPTS.
3893 023024 SETPRI (SP)+ ;ENABLE INTERRUPTS TO THE PROCESSOR AGAIN.
023024 012600 MOV (SP)+,RO
023026 104441 TRAP C$SPRI
3894 023030 012600 MOV (SP)+,RO ;RESTORE RO.
3895 023032 000207 RTS PC

```

```

3897
3898
3899
3900
3901
3902
3903
3904
3905
3906
3907
3908
3909
3910
3911
3912
3913
3914
3915
3916 023034 052767 040000 157246
3917 023042 042767 137677 157240
3918 023050 016777 157234 157164
3919 023056 000207

```

```

.SBTTL GLOBAL SUBROUTINE - TXIE1
; * *****
; * TRANSMITTER INTERRUPT ENABLE
; * THIS ROUTINE IS USED TO ENABLE TRANSMITTER INTERRUPTS IN THE DHU11.
; *
; * INPUTS: NONE.
; *
; * OUTPUTS: THE TX.INT.ENBL BIT IS SET IN THE DUT CSR.
; * IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
; * ENABLE BITS.
; *
; * CALLING SEQUENCE: JSR PC,TXIE1
; *
; * COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
; * THE DUT CSR ARE DESTROYED.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; - - *****
TXIE1:: BIS #BIT14,IESTAT ;SET TX.INT.ENBL BIT IN IESTAT.
        BIC #137677,IESTAT ;CLEAR ALL BITS EXCEPT TX RX I.E BITS.
        MOV IESTAT,@CSRA ;ENABLE TX INTERRUPTS.
        RTS PC

```

```

3921 .SBTTL GLOBAL SUBROUTINE - UNSDIV
3922 ;* *****
3923 ;* - UNSIGNED DIVIDE ROUTINE -
3924 ;* THIS SUBROUTINE IS USED TO DIVIDE A 32 BIT UNSIGNED DIVIDEND BY A
3925 ;* 16 BIT UNSIGNED DIVISOR GIVING A 16 BIT QUOTIENT. ALL NUMBERS ARE
3926 ;* CONSIDERED TO BE UNSIGNED. A SUCCESS FLAG IS NOT SET ON RETURN IF
3927 ;* THE QUOTIENT WAS TOO BIG TO BE CONTAINED IN 16 BITS.
3928 ;*
3929 ;* INPUTS: R1 THE DIVISOR, UNSIGNED, 16 BITS.
3930 ;* R2 - MOST SIGNIFICANT WORD OF THE DIVIDEND, UNSIGNED, 16 BITS.
3931 ;* R3 - LEAST SIGNIFICANT WORD OF THE DIVIDEND, UNSIGNED, 16 BITS.
3932 ;*
3933 ;* OUTPUTS: R1 QUOTIENT, UNSIGNED, 16 BITS (177777 IF OVERFLOW).
3934 ;* CARRY - SUCCESS FLAG, SET IF COMPLETE QUOTIENT FITS IN 16 BITS.
3935 ;*
3936 ;* CALLING SEQUENCE: JSR PC,UNSDIV
3937 ;*
3938 ;* COMMENTS: IF THE DIVISOR IS 0 THE QUOTIENT IS RETURNED AS ALL ONES
3939 ;* (177777) AND THE CARRY IS CLEAR REGARDLESS OF THE DIVIDEND.
3940 ;*
3941 ;* SUBORDINATE ROUTINES CALLED: NONE.
3942 ;* - *****
3943
3944 023060 UNSDIV:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
023060 004567 160712 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3945 ;*
3946 ; CHECK FOR QUOTIENT GREATER THAN 16 BITS CONDITION.
3947 ; -
3948 023064 010204 MOV R2,R4 ;GET MSW OF DIVIDEND FOR SUBTRACT.
3949 023066 160104 SUB R1,R4 ;SUBTRACT DIVISOR FROM MSW OF DIVIDEND.
3950 023070 103403 BCS 2$ ;IF IT DIDN'T GO, WE HAVE QUOTIENT < 16 BITS.
3951 23072 012701 177777 MOV 0-1,R1 ;SET QUOTIENT TO ALL ONES (177777).
3952 023076 000442 BR 60$ ;EXIT WITH CARRY CLEAR.
3953 ;*
3954 ; SET UP COUNTERS AND VARIOUS WORKING GPRS.
3955 ; -
3956 023100 005004 2$: CLR R4 ;CLEAR THE LSW OF THE DIVISOR.
3957 023102 000241 CLC ;CLEAR CARRY FOR THE SHIFT OF THE DIVISOR.
3958 023104 006001 ROR R1 ;DIVISOR BY
3959 023106 006004 ROR R4 ; 2(UNSIGNED)
3960 023110 012700 000020 MOV 016.,R0 ;SET UP INITIAL SHIFT COUNT TO 16.
3961 ;*
3962 ; THE SUBTRACT AND SHIFT LOOP.
3963 ; -
3964 023114 010246 4$: MOV R2,(SP) ;SAVE MSWORD OF DIVIDEND.
3965 023116 010346 MOV R3,-(SP) ;SAVE LSWORD OF DIVIDEND.
3966 023120 160403 SUB R4,R3 ;LSWORD DIVIDEND - LSWORD OF DIVISOR.
3967 023122 005602 SBC R2 ;MSWORD DIVIDEND - BORROW
3968 023124 103402 BCS 6$ ;IF BORROW FROM BORROW SUBTRACT, IT DIDN'T GO.
3969 023126 160102 SUB R1,R2 ;MSWORD DIVIDEND - MSWORD OF DIVISOR.
3970 023130 103003 BCC 8$ ;IF NO BORROW, IT WENT, CARRY IS CLEAR.
3971 ;*
3972 ; IT DIDN'T GO, SO WE SHIFT A 1 INTO THE QUOTIENT (COMPLEMENTED LATER).
3973 ; CARRY IS SET.
3974 ; -
3975 023132 012603 6$: MOV (SP)+,R3 ;RESTORE LSWORD OF DIVIDEND.
3976 023134 012602 MOV (SP)+,R2 ;RESTORE MSWORD OF DIVIDEND.

```

```

3977 023136 000401          BR      10$          ;GOTO SHIFT 1 INTO THE QUOTIENT.
3978                      ;+
3979                      ; IT WENT, SO WE RESTORE THE STACK AND SHIFT A 0 INTO QUOTIENT (WILL BE
3980                      ; COMPLEMENTED LATER). CARRY IS CLEAR.
3981                      ;-
3982 023140 012626      8$:  MOV      (SP)+,(SP)+      ;POP THE SAVED DIVIDEND OFF OF THE STACK.
3983                      ;+
3984                      ; SHIFT THE RESULT OF THE SUBTRACT ATTEMPT INTO THE QUOTIENT SHIFT REG.
3985                      ;-
3986 023142 006105      10$:  ROL      R5          ;SHIFT NEXT BIT INTO THE INVERTED QUOTIENT.
3987 023144 000241          CLC          ;DIVIDE THE
3988 023146 006001          ROR      R1          ; DIVISOR BY
3989 023150 006004          ROR      R4          ; 2 (UNSIGNED).
3990 023152 005300          DEC      R0          ;COUNT THIS SHIFT AND SUBTRACT.
3991 023154 001357          BNE     4$          ;LOOP FOR ANOTHER SHIFT & SUB IF NOT DONE.
3992 023156 005105          COM      R5          ;GET QUOTIENT FROM INVERTED QUOTIENT.
3993                      ;+
3994                      ; NOW WE EITHER ROUND UP OR LEAVE QUOTIENT ALONE.
3995                      ;-
3996 023160 000241          CLC          ;CLEAR THE CARRY FOR THE SHIFT OF THE DIVIDEND.
3997 023162 006103          ROL      R3          ;MULTIPLY LSWORD OF DIVIDEND BY 2. MSWORD IS 0.
3998 023164 103402          BCS     12$         ;IF CARRY FROM SHIFT, ROUND UP.
3999 023166 160403          SUB      R4,R3      ;SUBTRACT DIVISOR FROM DIVIDEND.
4000 023170 103403          BCS     14$         ;IF BORROW, DON'T ROUND UP.
4001                      ;+
4002                      ; ROUND UP, EXTRA SUBTRACT WENT.
4003                      ;-
4004 023172 005205      12$:  INC      R5          ;INCREMENT THE QUOTIENT BY ONE.
4005 023174 001001          BNE     14$         ;IF NO OVERFLOW, WE LEAVE THE ROUND UP.
4006 023176 005305          DEC      R5          ;DON'T LET ROUNDING CAUSE OVERFLOW.
4007                      ;+
4008                      ; ALL DONE, PASS QUOTIENT AND EXIT.
4009                      ;-
4010 023200 010501      14$:  MOV      R5,R1          ;PASS QUOTIENT BACK IN R1.
4011 023202 000261          SEC          ;INDICATE NO OVERFLOW.
4012
4013 023204          60$:  PASS     R1          ;RESTORE GPRS, LEAVE THE FOLLOWING INTACT:
      023204 010166 000004          MOV      R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
      023210 004736          PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
4014                      ;R1 16 BIT, UNSIGNED QUOTIENT,
4015 023212 000207          RTS     PC          ;CARRY - SET INDICATES NO OVERFLOW (SUCCESS).

```



```

4017 .SBTTL GLOBAL SUBROUTINE WAIBIC
4018 ;* .....
4019 ;* WAIT FOR BIT CLEAR ROUTINE
4020 ;* THIS SUBROUTINE WAITS FOR THE SPECIFIED BIT TO BECOME CLEAR. IF THE
4021 ;* SPECIFIED BIT GOES TO A CLEAR STATE WITHIN THE SPECIFIED TIME OUT
4022 ;* PERIOD A SUCCESS INDICATION IS RETURNED BY THIS ROUTINE.
4023 ;* THE LAST VALUE WHICH IS READ LOOKING FOR THE CONDITION IS RETURNED TO
4024 ;* ALLOW THE USE OF THIS ROUTINE TO LOOK FOR DESTRUCTIVE READ CONDITIONS.
4025 ;*
4026 ;* INPUTS: R1 - TIME-OUT VALUE AND BIT NUMBER INDICATION:
4027 ;* BITS 15 THRU 12 NUMBER OF BIT TO TEST (RANGE 0 THRU 15)
4028 ;* BITS 11 THRU 0 - TIME-OUT VALUE IN MILLI SECONDS (4095 MAX).
4029 ;* R2 ADDRESS OF WORD CONTAINING THE BIT TO TEST.
4030 ;* MSLCNT.
4031 ;*
4032 ;* OUTPUTS: R2 - THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION.
4033 ;* CARRY - SUCCESS FLAG (CARRY SET IF BIT CLR BEFORE TIME-OUT).
4034 ;*
4035 ;* CALLING SEQUENCE: MOV #130040,R1 ;PASS BIT 11 (13 OCTAL) AND
4036 ;* ; 32 (40 OCTAL) MS DELAY.
4037 ;* MOV @LABEL,R2 ;TEST BIT IN WORD AT "LABEL".
4038 ;* JSR PC,WAIBIC ;WAIT 32 MS FOR BIT 11 TO CLR.
4039 ;*
4040 ;* COMMENTS:
4041 ;*
4042 ;* SUBORDINATE ROUTINES CALLED: MSLGET.
4043 ;* .....
4044 ;*
4045 023214 004567 160556 WAIBIC:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
4046 023220 010204 MOV R2,R4 ;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
4047 023222 010102 MOV R1,R2 ;SET UP THE ADDRESS PARAMETER FOR MSLGET.
4048 023224 042701 170000 BIC #170000,R1 ;SEPERATE DELAY COUNT OUT OF PASSED PARAMETER.
4049 023230 042702 007777 BIC #7777,R2 ;SEPERATE LINE NUMBER FIELD OF PASSED PARAM.
4050 023234 000302 SWAB R2 ;PUT LINE NUMBER FIELD IN LSBYTE.
4051 023236 006202 ASR R2 ;SHIFT THE LINE NUMBER FIELD INTO THE PROPER
4052 023240 006202 ASR R2 ; POSITION TO USE IT AS A WORD TABLE OFFSET
4053 023242 006202 ASR R2 ; FOR THE TABLE LOOKUP OF THE LINE BIT MAP.
4054 023244 016202 002410 MOV BITTBL(R2),R2 ;GET BIT MAP OF LINE TO TEST FROM TABLE.
4055 023250 005003 CLR R3 ;INDICATE THAT THE BIT SHOULD BE CLR.
4056 023252 004767 174706 JSR PC,MSLGET ;WAIT FOR THE BIT TO BE CLR WITHIN TIME OUT.
4057 ; CARRY IS CORRECT UPON MSLGET RETURN.
4058 023256 010002 MOV R0,R2 ;PASS LAST VALUE READ AS OUTPUT PARAMETER.
4059 023260 010266 000006 601: PASS R2 ;RESTORE GPRS, EXCEPT THE FOLLOWING:
4059 023264 004736 MOV R2,R2SLOT(SP) ;PUT R2 IN STACK SLOT.
4059 023264 004736 JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
4060 ; R2 LAST VALUE READ LOOKING FOR CONDITION.
4061 023266 000207 RTS PC ; CARRY SUCCESS FLAG (SET IF BIT FOUND CLR).

```

4063
 4064
 4065
 4066
 4067
 4068
 4069
 4070
 4071
 4072
 4073
 4074
 4075
 4076
 4077
 4078
 4079
 4080
 4081
 4082
 4083
 4084
 4085
 4086
 4087
 4088
 4089
 4090
 4091
 4092
 4093
 4094
 4095
 4096
 4097
 4098
 4099
 4100
 4101
 4102
 4103
 4104
 4105
 4106
 4107

023270
 023274
 023276
 023300
 023304
 023310
 023312
 023314
 023316
 023320
 023324
 023326
 023332
 023334
 023340
 023342

004567
 010204
 010102
 042701
 042702
 000302
 006202
 006202
 006202
 016202
 010203
 004757
 010002
 010266
 004736
 000207

160502
 170000
 007777
 002410
 174632
 000006

```

.SBTTL GLOBAL SUBROUTINE - WAIBIS
*****
;* - WAIT FOR BIT SET ROUTINE
;* THIS SUBROUTINE WAITS FOR THE SPECIFIED BIT TO BECOME SET. IF THE
;* SPECIFIED BIT GOES TO A SET STATE WITHIN THE SPECIFIED TIME OUT
;* PERIOD A SUCCESS INDICATION IS RETURNED BY THIS ROUTINE.
;* THE LAST VALUE WHICH IS READ LOOKING FOR THE CONDITION IS RETURNED TO
;* ALLOW THE USE OF THIS ROUTINE TO LOOK FOR DESTRUCTIVE READ CONDITIONS.
;*
;* INPUTS: R1 - TIME-OUT VALUE AND BIT NUMBER INDICATION:
;*          BITS 15 THRU 12 - NUMBER OF BIT TO TEST (RANGE 0 THRU 15).
;*          BITS 11 THRU 0 - TIME-OUT VALUE IN MILLI-SECONDS (4095 MAX).
;*          R2 - ADDRESS OF WORD CONTAINING THE BIT TO TEST.
;*              MSLCNT.
;*
;* OUTPUTS: R2 - THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION.
;*          CARRY - SUCCESS FLAG (CARRY SET IF BIT SET BEFORE TIME-OUT).
;*
;* CALLING SEQUENCE:  MOV    #130040,R1    ;PASS BIT 11 (13 OCTAL) AND
;*                   ; 32 (40 OCTAL) MS DELAY.
;*                   MOV    #LABEL,R2     ;TEST BIT IN WORD AT "LABEL".
;*                   JSR    PC,WAIBIS     ;WAIT 32 MS FOR BIT 11 TO SET.
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: MSLGET.
;-- *****

WAIBIS:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;SET UP THE ADDRESS PARAMETER FOR MSLGET.
        MOV    R2,R4
        MOV    R1,R2
        BIC    #170000,R1 ;SEPERATE DELAY COUNT OUT OF PASSED PARAMETER.
        BIC    #7777,R2  ;SEPERATE LINE NUMBER FIELD OF PASSED PARAM.
        SWAB   R2        ;PUT LINE NUMBER FIELD IN LSBYTE.
        ASR   R2        ;SHIFT THE LINE NUMBER FIELD INTO THE PROPER
        ASR   R2        ; POSITION TO USE IT AS A WORD TABLE OFFSET
        ASR   R2        ; FOR THE TABLE LOOKUP OF THE LINE BIT MAP.
        MOV    BITTBL(R2),R2 ;GET BIT MAP OF LINE TO TEST FROM TABLE.
        MOV    R2,R3    ;INDICATE THAT THE BIT SHOULD BE SET.
        JSR    PC,MSLGET ;WAIT FOR THE BIT TO BE SET WITHIN TIME-OUT.
; CARRY IS CORRECT UPON MSLGET RETURN.
;PASS LAST VALUE READ AS OUTPUT PARAMETER.
;RESTORE GPRS, EXCEPT THE FOLLOWING:
        MOV    R0,R2    ;PUT R2 IN STACK SLOT.
        PASS   R2      ;RETURN TO PREG05 SUBRT.
        MOV    R2,R2SLOT(SP)
        JSR    PC,@(SP)
; R2 - LAST VALUE READ LOOKING FOR CONDITION.
; CARRY - SUCCESS FLAG (SET IF BIT FOUND SET)

        RTS    PC
  
```

```

4109 .SBTTL GLOBAL SUBROUTINE - WDPDR
4110 ;* *****
4111 ;* - WRITE DATA PATTERN TO DEVICE REGISTERS
4112 ;* THIS ROUTINE WRITES A ROTATED DATA PATTERN TO EACH OF THE 6 DEVICE
4113 ;* REGISTERS OF EACH ACTIVE LINE OF THE DEVICE UNDER TEST.
4114 ;* THE DATA PATTERN IS ROTATED ONCE AFTER EACH WRITE TO A DEVICE REGISTER
4115 ;* ON A PARTICULAR LINE. THE STARTING DATA PATTERN FOR EACH LINE
4116 ;* IS ROTATED ONCE AFTER WRITING ALL THE REGISTERS ON A PARTICULAR
4117 ;* LINE. THIS LEADS TO THE FOLLOWING DATA PATTERN:
4118 ;* LINE 0, REGISTER 0 - SHIFTED 0 BIT POSITIONS
4119 ;* LINE 0, REGISTER 1 SHIFTED 1 BIT POSITION
4120 ;*
4121 ;* LINE 1, REGISTER 0 - SHIFTED 1 BIT POSITION
4122 ;* LINE 2, REGISTER 1 - SHIFTED 2 BIT POSITIONS
4123 ;*
4124 ;* ANY BITS FIELDS IN THE DEVICE REGISTERS THAT CANNOT BE ALTERED
4125 ;* ARE MASKED OUT OF THE DATA PATTERN BEFORE IT IS WRITTEN.
4126 ;* THIS ROUTINE WILL USE EITHER MOV, MOVB, BIS, BISB, BIC, OR BICB
4127 ;* INSTRUCTIONS. THE UPPER OR LOWER BYTE CAN BE SPECIFIED FOR WRITING.
4128 ;*
4129 ;* INPUTS: R2 - USED TO PASS IN THE DATA PATTERN TO BE ROTATED & WRITTEN.
4130 ;* R3 - BYTE INDICATOR (- => LO BYTE, + => HI BYTE, 0 => BOTH).
4131 ;* R4 OPERATION TYPE INDICATOR ( => BIC, + => BIS, 0 => MOV).
4132 ;* ACTLNS - BIT MAP OF THE ACTIVE LINES ON THE DEVICE UNDER TEST.
4133 ;* CSRA - CONTAINS THE CSR ADDRESS OF THE DEVICE UNDER TEST.
4134 ;* DRADRT BASE ADDRESS OF DEVICE REGISTER ADDRESS TABLE.
4135 ;* LPRO EQUATED TO LPR REG OFFSET FROM DEVICE CSR ADDRESS.
4136 ;* NUMLNS - NUMBER OF LINES ON THE DEVICE UNDER TEST.
4137 ;* TXBFCO EQUATED TO TBUFFCT REG OFFSET FROM DEVICE CSR ADDRESS.
4138 ;* UNBTB - BASE ADDRESS OF THE UNUSED BIT TABLE.
4139 ;*
4140 ;* OUTPUTS: DEVICE REGISTERS ON ALL ACTIVE DEVICE LINES ARE MODIFIED.
4141 ;*
4142 ;* CALLING SEQUENCE: JSR PC.WDPDR
4143 ;*
4144 ;* COMMENTS: THIS ROUTINE DOES NOT WRITE DATA TO THE FOLLOWING REGISTERS,
4145 ;* RBUF
4146 ;* RXIMER
4147 ;* STAT
4148 ;* FIFOSIZE
4149 ;* FIFODATA
4150 ;* THE CSR IS CLEARED EXCEPT FOR THE IND.ADR.REG FIELD.
4151 ;*
4152 ;* SUBORDINATE ROUTINES CALLED: ROLDAP.
4153 ;* *****
4154
4155 023344 WDPDR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
023344 004567 160426 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
4156 ;*
4157 ;* SET UP OUTER LOOP WHICH WRITES THE DATA PATTERN TO EACH LINE'S REGISTERS
4158 ;*
4159 023350 005005 CLR R5 ;CLEAR LINE COUNTER TO SELECT LINE 0.
4160 ;*
4161 ;* THE OUTER LOOP FOLLOWS. EACH PASS THROUGH THIS LOOP WRITES DATA TO ALL OF
4162 ;* THE DEVICE REGISTERS FOR A PARTICULAR LINE IF IT IS ACTIVE.
4163 ;*
4164 023352 010204 ;* MOV R2,R4 ;SAVE THE OUTER LOOP DATA PATTERN.

```

```

4165 023354 010577 156662      MOV    R5,@CSRA      ;SET CSR IND.ADR.REG FIELD TO THIS LINE.
4166 023360 006305              ASL    R5             ;TURN LINE NUMBER INTO A WORD OFFSET.
4167 023362 036567 002410 156640  BIT    BITBL(R5),ACTLNS
4168 023370 001456              BEQ    20$           ;LINE ACTIVE? NO, SKIP THIS LINE.
4169 023372 012701 000004      MOV    @LPRO,R1     ;YES, INITIALIZE THE REGISTER OFFSET.
4170
4171 ;
4172 ; THE INNER LOOP FOLLOWS. EACH PASS THROUGH THIS LOOP WRITES DATA TO A
4173 ; DEVICE REGISTER.
4174 ;
4174 023376 010200 4$:      MOV    R2,R0
4175 023400 046100              BIC    UNBITB(R1),R0 ;CLEAR BIT FIELDS FOR UNUSED REGISTER BITS.
4176 023404 016103 002370      MOV    DRADR(R1),R3 ;GET THE ADDRESS OF THE DEVICE REGISTER.
4177 023410 005766 000010      TST    R3SLOT(SP)   ;CHECK THE OPERAND TYPE INDICATOR.
4178 023414 003402              BLE    6$           ;HIGH BYTE? NO, SKIP HIGH BYTE ADDRESS SET UP.
4179 023416 005203              INC    R3           ;YES, SET THE REG ADDRESS TO THE HIGH BYTE.
4180 023420 000300              SWAB   R0           ;MOVE HIGH BYTE DATA INTO THE LOW BYTE.
4181 023422 005766 000010 6$:      TST    R3SLOT(SP)   ;CHECK THE OPERAND TYPE INDICATOR.
4182 023426 001412              BEQ    12$         ;WORD ACCESS? YES, GO PERFORM WORD ACCESS.
4183 ;
4184 ; PERFORM BYTE ACCESS TO THE SPECIFIED BYTE OF THE SPECIFIED REGISTER.
4185 ;
4186 023430 005766 000012      TST    R4SLOT(SP)   ;NO, CHECK THE ACCESS TYPE INDICATOR.
4187 023434 100403              BMI    8$           ;USE BIC? YES, GO PERFORM BICB INSTRUCTION.
4188 023436 001404              BEQ    10$          ;USE MOV? YES, GO PERFORM MOV B INSTRUCTION.
4189 023440 150013              BISB   R0,(R3)      ;NEITHER. PERFORM BISB ACCESS TO REGISTER.
4190 023442 000415              BR     18$
4191 023444 140013 8$:      BICB   R0,(R3)      ;PERFORM BICB ACCESS TO REGISTER.
4192 023446 000413              BR     18$
4193 023450 110013 10$:     MOV B   R0,(R3)      ;PERFORM MOV B ACCESS TO REGISTER.
4194 023452 000411              BR     18$
4195 ;
4196 ; PERFORM WORD ACCESS TO THE SPECIFIED REGISTER.
4197 ;
4198 023454 005766 000012 12$:     TST    R4SLOT(SP)   ;CHECK THE ACCESS TYPE INDICATOR.
4199 023460 100403              BMI    14$          ;USE BIC? YES, GO PERFORM BIC INSTRUCTION.
4200 023462 001404              BEQ    16$          ;USE MOV? YES, GO PERFORM MOV INSTRUCTION.
4201 023464 050013              BIS    R0,(R3)      ;NEITHER. PERFORM BIS ACCESS TO REGISTER.
4202 023466 000403              BR     18$
4203 023470 040013 14$:     BIC    R0,(R3)      ;PERFORM BIC ACCESS TO REGISTER.
4204 023472 000401              BR     18$
4205 023474 010013 16$:     MOV    R0,(R3)      ;PERFORM MOV ACCESS TO REGISTER.
4206 ;
4207 ; PREPARE THE DATA PATTERN AND OFFSET FOR THE NEXT REGISTER ON THIS LINE.
4208 ;
4209 023476 004767 175766 18$:     JSR    PC,ROLDAP    ;ROTATE DATA PATTERN LEFT, NOT THROUGH CARRY.
4210 023502 062701 000002      ADD    @2,R1        ;INCREMENT OFFSET FOR NEXT REGISTER.
4211 023506 020127 000006      CMP    R1,@FSLSO    ;CHECK IF THIS IS THE FIFOSIZE/DATA REG
4212 023512 001002              BNE    19$          ;AVOID ALTERING THE OFFSET IF IT ISN'T.
4213 023514 062701 000002      ADD    @2,R1        ;AVOID TESTING THESE REGISTERS.
4214 023520 020127 000016 19$:     CMP    R1,@TXBFCO   ;COMPARE REG OFFSET WITH OFFSET OF LAST REG.
4215 023524 003724              BLE    4$           ;LOOP IF NOT ALL REG DONE FOR THIS LINE.
4216 ;
4217 ; BACK INTO THE OUTER LOOP. NOW SET UP FOR NEXT LINE. LOOP IF NOT DONE.
4218 ;
4219 023526 010402 20$:     MOV    R4,R2        ;SET UP TO ROTATE THE DATA PATTERN.
4220 023530 004767 175734      JSR    PC,ROLDAP    ;ROTATE THE DATA PATTERN.
4221 023534 006205              ASR    R5           ;CONVERT BACK TO LINE NUMBER FROM WORD OFFSET.

```

```

4222 023536 005205          INC    R5          ;COUNT THIS LINE.
4223 023540 020527 000020  CMP    R5,#NUMLNS ;COMPARE LINE COUNT WITH NUMBER OF LINES.
4224 023544 002702          BLI    2$          ;LOOP IF SOME LINES NOT DONE.
4225
4226 023546          60$: PASS          ;RESTORE GPRS.
      023546 004736          JSR          PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
4227 023550 000207          RT@    PC

```

4229
4230
4231
4232
4233
4234
4235
4236
4237
4238
4239
4240
4241
4242
4243
4244
4245
4246
4247
4248
4249
4250
4251
4252 023552
023552 004567 160220
4253
4254
4255
4256 023556 016701 156470
4257 023562 010002
4258 023564 010503
4259 023566 012704 177777
4260
4261
4262
4263 023572 004767 173656
4264
4265 023576
023576 004736
4266 023600 000207

```
.SBTTL GLOBAL SUBROUTINE - WTWLNC
;*****
; LINE CONTROL REGISTER SETUP ROUTINE
; THIS SUBROUTINE IS USED TO SET THE DEVICE UNDER TEST (DUT) LINE
; CONTROL REGISTERS (LNCTRL) TO THE SPECIFIED STATE. ONLY THE LNCTRLS
; FOR THE SPECIFIED LINES ARE ALTERED.
;
; INPUTS: R0 NEW LINE PARAMETERS.
; R5 - BIT MAP OF LINES TO BE ALTERED
; CSRA - CONTAINS ADDRESS OF THE DUT CSR.
; IESTAT - CONTAINS THE CURRENT STATE OF THE TX AND RX INTERRUPT
; ENABLE BITS IN THE CSR.
; LNCTRA - CONTAINS ADDRESS OF THE DUT LNCTRL REGISTERS.
;
; OUTPUTS: LNCTRL - SPECIFIED DUT LINE CONTROL REGISTERS ARE ALTERED.
;
; CALLING SEQUENCE: JSR PC,WTWLNC
;
; COMMENTS:
;
; SUBORDINATE ROUTINES CALLED: ALTFLD.
; - *****
WTWLNC:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
; JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;
; SET UP THE PARAMETERS FOR THE CALL TO ALTFLD.
; -
MOV LNCTRA,R1 ;SET UP THE REGISTER ADDRESS PARAMETER.
MOV R0,R2 ;SET UP THE DESIRED REGISTER CONTENTS.
MOV R5,R3 ;SET UP THE BIT MAP OF LINES TO ALTER.
MOV # 1,R4 ;SELECT ALL REGISTER BITS TO BE ALTERED.
;
; CALL THE SUBROUTINE WHICH ALTERS THE REGISTER CONTENTS.
; -
JSR PC,ALTFLD ;ALTER THE REGISTER CONTENTS.
;
60: PASS ;RESTORE GPRS.
; JSR PC,@(SP), ;RETURN TO PREG05 SUBRT.
RTS PC
```

```

4268 .SBTTL GLOBAL SUBROUTINE WTWLPR
4269 ;* *****
4270 ;* LINE PARAMETER REGISTER SETUP ROUTINE
4271 ;* THIS SUBROUTINE IS USED TO SET THE DEVICE UNDER TEST (DUT) LINE
4272 ;* PARAMETER REGISTERS (LPR) TO THE SPECIFIED STATE. ONLY THE LPRS FOR
4273 ;* THE SPECIFIED LINES ARE ALTERED.
4274 ;*
4275 ;* INPUTS: R0 NEW LINE PARAMETERS.
4276 ;* R5 - BIT MAP OF LINES TO BE ALTERED.
4277 ;* CSRA - CONTAINS ADDRESS OF THE DUT CSR.
4278 ;* IESTAT - CONTAINS THE CURRENT STATE OF THE TX AND RX INTERRUPT
4279 ;* ENABLE BITS IN THE CSR.
4280 ;* LPRA CONTAINS ADDRESS OF THE DUT LPR.
4281 ;*
4282 ;* OUTPUTS: LPR SPECIFIED DUT LINE PARAMTER REGISTERS ARE ALTERED.
4283 ;*
4284 ;* CALLING SEQUENCE: JSR PC,WTWLPR
4285 ;*
4286 ;* COMMENTS:
4287 ;*
4288 ;* SUBORDINATE ROUTINES CALLED: ALTFLD.
4289 ;* *****
4290
4291 023602 WTWLPR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
023602 004567 160170 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
4292 ;*
4293 ;* SET UP THE PARAMETERS FOR THE CALL TO ALTFLD.
4294 ;*
4295 023606 016701 156434 MOV LPRA,R1 ;SET UP THE REGISTER ADDRESS PARAMETER.
4296 023612 010002 MOV R0,R2 ;SET UP THE DESIRED REGISTER CONTENTS.
4297 023614 010503 MOV R5,R3 ;SET UP THE BIT MAP OF LINES TO ALTER.
4298 023616 012704 177777 MOV # 1,R4 ;SELECT ALL REGISTER BITS TO BE ALTERED.
4299 ;*
4300 ;* CALL THE SUBROUTINE WHICH ALTERS THE REGISTER CONTENTS.
4301 ;*
4302 023622 004767 173626 JSR PC,ALTFLD ;ALTER THE REGISTER CONTENTS.
4303 ;*
4304 023626 004736 601: PASS ;RESTORE GPRS.
023626 004736 JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
4305 023630 000207 RTS PC

```

4307
 4308
 4309
 4310
 4311
 4312
 4313
 4314
 4315
 4316
 4317
 4318
 4319
 4320
 4321
 4322
 4323
 4324
 4325
 4326
 4327
 4328 023632
 4329 023636 004567 160140
 4330 023642 005201
 4331 023644 102001
 4332 023646 005301
 4333 023650 010167 156440
 4334 023654
 023654 004736
 4335 023656 000002

```

.SBTTL INTERRUPT SERVICE ROUTINE          CACHRX
;*****
;* CATCH RECEIVER INTERRUPT.
;* THIS ROUTINE IS USED IN SEVERAL TESTS, TO LOG A COUNT OF THE
;* NUMBER OF RECEIVER INTERRUPTS THAT OCCUR.
;*
;* INPUTS:      CSRA  CONTAINS THE ADDRESS OF THE CSR.
;*              RXINTC  HOLDS THE COUNT OF THE NUMBER OF RX INTERRUPTS
;*                    THAT OCCURRED.
;*
;* OUTPUTS:     RXINTC  CONTAINS THE UPDATED INTERRUPT COUNT.
;*
;* CALLING SEQUENCE:  PUT THE ADDRESS OF THE LABEL CACHRX IN THE VECTOR
;*                    LOCATION.
;*
;* COMMENTS:
;* SUBORDINATE ROUTINES CALLED: NONE
;*****
CACHRX::SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
      MOV     RXINTC,R1 ;GET THE RECEIVER INTERRUPT COUNT
      INC     R1        ;INCREMENT THE COUNT
      BVC    2$        ;BRANCH IF NO OVERFLOW OCCURRED
      DEC     R1        ;RESET THE COUNT TO 177777
      MOV     R1,RXINTC ;SAVE NEW COUNT VALUE
      PASS
;RESTORE GPRS.
      JSR    PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
      RTI
  
```


4337
4338
4339
4340
4341
4342
4343
4344
4345
4346
4347
4348
4349
4350
4351
4352
4353
4354
4355
4356
4357
4358
4359
4360
4361
4362
4363
4364
4365

023660
023660 004567 160112
023664 016701 156436
023670 005201
023672 102001
023674 005301
023676 010167 156424
023702
023702 004736
023704 000002

```
.SBTTL INTERRUPT SERVICE ROUTINE          CACHTX
;*****
;* CATCH TRANSMITER INTERRUPT.
;* THIS ROUTINE IS USED IN SEVERAL TESTS, TO LOG A COUNT OF THE
;* NUMBER OF TRANSMISSION INTERRUPTS THAT OCCUR.
;*
;* INPUTS:      CSRA  CONTAINS THE ADDRESS OF THE CSR.
;*              TXINTC  HOLDS THE COUNT OF THE NUMBER OF TX INTERRUPTS
;*                   THAT OCCURRED.
;*
;* OUTPUTS:     TXINTC  CONTAINS THE UPDATED INTERRUPT COUNT.
;*
;* CALLING SEQUENCE:  PUT THE ADDRESS OF THE LABEL CACHTX IN THE VECTOR
;*                   LOCATION.
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE
;-----*****
```

```
CACHTX::SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
RS,PREG05 ;CALL REGISTER SAVE SUBRT.
;GET THE TRANSMISSION INTERRUPT COUNT
MOV TXINTC,R1 ;INCREMENT THE COUNT
INC R1
BVC 2$ ;BRANCH IF NO OVERFLOW OCCURRED
DEC R1 ;RESET THE COUNT TO 177777
2$: MOV R1,TXINTC ;SAVE NEW COUNT VALUE
60$: PASS ;RESTORE GPRS.
;RETURN TO PREG05 SUBRT.
JSR PC,@(SP)+
RTI
```

109

4367
 4368
 4369
 4370
 4371
 4372
 4373
 4374
 4375
 4376
 4377
 4378
 4379
 4380
 4381
 4382
 4383
 4384
 4385
 4386
 4387
 4388
 4389
 4390
 4391
 4392
 4393
 4394
 4395
 4396
 4397
 4398
 4399
 4400
 4401
 4402

023706 005767 156432
 023712 001402
 023714 005367 156424
 023720 005767 156422
 023724 001402
 023726 005367 156414
 023732 005367 156412
 023736 001006
 023740 016767 156406 156402
 023746 010046
 023750
 023750 104422
 023752 012600
 023754 000002

```

.SBTTL INTERRUPT SERVICE ROUTINE - CLKINT -
;*****
;* THIS ROUTINE IS EXECUTED CLKHRZ TIMES PER SECOND. IT DECREASES THE
;* TWO TIMER COUNTERS DOWN TO ZERO.
;*
;* INPUTS: TIMER1 - TIMER COUNTER #1.
;*          TIMER2  TIMER COUNTER #2.
;*          TIMER3 - TIMER COUNTER FOR CALL OF BREAK MACRO.
;*
;* OUTPUTS: THE 2 TIMER COUNTERS ARE DECREMENTED IF THEY ARE NOT ZERO.
;*
;* CALLING SEQUENCE: PUT #CLKINT IN THE CLOCK INTERRUPT VECTOR SLOT.
;*                   PUT THE DESIRED TIME PERIOD (SECONDS TIMES CLKHRZ) IN
;*                   EITHER TIMER1 OR TIMER2 AND POLL THE RESPECTIVE TIMER
;*                   COUNTER TO DETECT ITS GOING TO 0 ON TIME OUT.
;*
;* COMMENTS: THE 2 COUNTERS WILL NOT WRAPAROUND BUT WILL STOP AT 0. THIS
;*            ALLOWS THE DETECTION OF A TIME-OUT ANY TIME AFTER THE TIME-OUT
;*            HAS OCCURRED UNTIL THE TIMER COUNTER IS SET TO ANOTHER VALUE.
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
CLKINT:: TST   TIMER1      ;CHECK FOR TIMER1 AT ZERO.
        BEQ   2$          ;BRANCH TO LEAVE IT AT ZERO IF IT IS ZERO.
        DEC   TIMER1      ;DECREMENT TIME COUNT.
2$:     TST   TIMER2      ;CHECK FOR TIMER2 AT ZERO.
        BEQ   4$          ;BRANCH TO LEAVE IT ALONE IF IT'S ALREADY ZERO.
        DEC   TIMER2      ;DECREMENT TIME COUNT.
4$:     DEC   TIMER3      ;DECREMENT THE BREAK COUNT.
        BNE   60$         ;EXIT IF NOT TIME TO CALL BREAK.
        MOV   BCOUNT,TIMER3 ;SET UP TIME TILL NEXT BREAK.
        MOV   RO,-(SP)     ;SAVE CONTENTS OF RO FROM BREAK MACRO.
        BREAK              ;CHECK FOR OPERATOR CONTROL/C.
                                TRAP   C$BRK
60$:   MOV   (SP)+,RO      ;RESTORE CONTENTS OF RO.
        RTI
  
```

4404
 4405
 4406
 4407
 4408
 4409
 4410
 4411
 4412
 4413
 4414
 4415
 4416
 4417
 4418
 4419
 4420
 4421
 4422
 4423
 4424
 4425
 4426
 4427
 4428
 4429
 4430
 4431
 4432
 4433
 4434
 4435
 4436
 4437
 4438
 4439
 4440
 4441
 4442
 4443

023756 004567 160014
 023762 017700 156256
 023766 016701 156322
 023772 005201
 023774 001402
 023776 010167 156312
 024002 016701 156310
 024006 052701 000001
 024012 032767 000001 156310
 024020 001402
 024022 052701 040000
 024026 010167 156264
 024032 004736
 024034 000002

```

.SBTTL  INTERRUPT SERVICE ROUTINE          - RXBRRT -
; ** *****
; * - BR LEVEL TEST RECEIVE INTERRUPT SERVICE ROUTINE
; * THIS SERVICE ROUTINE HANDLES RECEIVE INTERRUPTS DURING THE INTERRUPT
; * BR LEVEL TEST. THIS ROUTINE COUNTS THE INTERRUPT AND SETS A FLAG
; * TO INDICATE THAT THE INTERRUPT HAS OCCURRED. IT ALSO CHECKS THE
; * FLAG WHICH INDICATES THAT A TX INTERRUPT HAS OCCURRED. IF THE TX
; * INTERRUPT FLAG IS SET, THIS ROUTINE SETS AN INTERRUPT ORDER ERROR
; * FLAG INDICATING THAT A TRANSMIT INTERRUPT WAS SERVICED BEFORE A
; * SIMULTANEOUS RECEIVE INTERRUPT.
; *
; * INPUTS:      RXINTC - HOLDS THE COUNT OF THE NUMBER OF RX INTERUPTS.
; *              RXINTF  RX INTERRUPT FLAGS.
; *
; * OUTPUTS:     RXINTC - CONTAINS THE UPDATED INTERRUPT COUNT.
; *              RXINTF  RX INT FLAGS:
; *                    (BIT 0 SET, BIT 14 SET IF TXINTF BIT 0 IS SET.)
; *
; * CALLING SEQUENCE:  PUT THE ADDRESS OF THE LABEL RXBRRT IN THE VECTOR
; *                    LOCATION.
; *
; * COMMENTS:     NOTE: THE FIFO IS NOT PURGED BY THIS ROUTINE.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; -- *****

RXBRRT:: SAVE                                ;SAVE CONTENTS OF GPRS R0 THRU R5.
; R5,PREG05 ;CALL REGISTER SAVE SUBRT.
      MOV  @RBUFA,R0 ;READ THE CHAR OUT OF THE FIFO.
      MOV  RXINTC,R1 ;GET THE INTERRUPT COUNT.
      INC  R1        ;INCREMENT THE COUNT.
      BEQ  2$       ;BYPASS UPDATING COUNT IF OVERFLOW OCCURRED.
      MOV  R1,RXINTC ;SAVE NEW COUNT VALUE.
2$:   MOV  RXINTF,R1 ;GET THE RX INTERRUPT FLAGS.
      BIS  @BIT0,R1 ;SET THE RX INTERRUPT HAS OCCURRED FLAG.
      BIT  @BIT0,TXINTF ;TEST THE "TX INT HAS OCCURRED" FLAG.
      BEQ  4$       ;SKIP SETTING ERROR FLAG IF NO TX INT.
      BIS  @BIT14,R1 ;SET THE INTERRUPT ORDER ERROR FLAG.
4$:   MOV  R1,RXINTF ;UPDATE THE RX INTERRUPT FLAGS.
60$:  PASS        ;RESTORE GPRS.
      JSR  PC,@(SP), ;RETURN TO PREG05 SUBRT.
      RTI
  
```

```

4445 .SBTTL INTERUPT SERVICE ROUTINE - RXINPT
4446 ;* *****
4447 ;* - RECEIVE CHARACTER INPUT INTERRUPT SERVICE ROUTINE
4448 ;* THIS SERVICE ROUTINE INPUTS A CHARACTER FROM THE DUT AND LOADS THE
4449 ;* CHAR (COMPLETE WITH STATUS FLAGS) INTO A RECEIVE CHAR BUFFER IN
4450 ;* MEMORY. THE INTERRUPT IS ALSO COUNTED. THE RECEIVE CHAR BUFFER IS
4451 ;* MONITORED TO ENSURE THAT IT DOES NOT OVERFLOW.
4452 ;*
4453 ;* INPUTS: BUFEND - LABELS THE END OF THE HOST MEMORY BUFFER.
4454 ;*          BUFPTR - CONTAINS ADDRESS OF NEXT FREE BUFFER LOCATION.
4455 ;*          CSRA - CONTAINS THE ADDRESS OF THE DUT CSR.
4456 ;*          RBUFA - CONTAINS THE ADDRESS OF THE RBUF DUT REGISTER.
4457 ;*          RXINTC - HOLDS THE COUNT OF THE NUMBER OF RX INTERUPTS.
4458 ;*          RXINTF - RX INTERRUPT FLAGS.
4459 ;*
4460 ;* OUTPUTS: BUFPTR - CONTAINS UPDATED ADDRESS OF NEXT FREE BUFFER LOCATION.
4461 ;*          RXINTC - CONTAINS THE UPDATED INTERUPT COUNT.
4462 ;*          RXINTF - RX INT FLAGS (BIT 15 SET IF RX.DATA.AVAIL IS CLEAR).
4463 ;*
4464 ;* CALLING SEQUENCE: PUT THE ADDRESS OF THE LABEL RXINPT IN THE VECTOR
4465 ;*                   LOCATION.
4466 ;*
4467 ;* COMMENTS: IN CASE OF OVERFLOW OF THE MEMORY BUFFER, BUFPTR WILL BE
4468 ;*           MAINTAINED EQUAL TO BUFEND AND THE WORD AT BUFPTR WILL BE
4469 ;*           THE LAST WORD READ FROM THE DUT FIFO.
4470 ;*           NOTE: THIS ROUTINE CAN DESTROY TX.ACTIONS BY READING THE CSR.
4471 ;*
4472 ;* SUBORDINATE ROUTINES CALLED: NONE.
4473 ;* -- *****
4474
4475 024036 004567 157734 RXINPT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
024036 ;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
4476 024042 017701 156174 MOV @CSRA,R1 ;READ THE CONTENTS OF THE CSR.
4477 024046 032701 000200 BIT @BIT7,R1 ;TEST RX.DATA.AVAIL BIT.
4478 024052 001003 BNE 2$ ;BRANCH AROUND SETTING FLAG IF BIT IS SET.
4479 024054 052767 100000 156234 BIS @BIT15,RXINTF ;SET THE RX.DATA.AVAIL CLEAR FLAG.
4480 024062 016701 156226 2$: MOV RXINTC,R1 ;GET THE INTERRUPT COUNT.
4481 024066 005201 INC R1 ;INCPMENT THE COUNT.
4482 024070 001402 BEQ 4$ ;BYPASS UPDATING COUNT IF OVERFLOW OCCURRED.
4483 024072 010167 156216 MOV R1,RXINTC ;SAVE NEW COUNT VALUE.
4484 024076 016702 156200 4$: MOV BUFPTR,R2 ;GET THE POINTER TO NEXT FREE BUFFER WORD.
4485 024102 017722 156136 MOV @RBUFA,(R2)+ ;READ A CHAR FROM THE FIFO INTO BUFFER.
4486 024106 020267 157614 CMP R2,BUFEND ;TEST FOR POINTER BEYOND END OF BUFFER.
4487 024112 103002 BHIS 60$ ;SKIP THE PTR UPDATE IF PTR OUT OF BOUNDS.
4488 024114 010267 156162 MOV R2,BUFPTR ;UPDATE THE BUFFER POINTER.
4489 024120 60$: PASS ;RESTORE GPRS.
024120 004736 JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
4490 024122 000002 RTI

```

```

4492 .SBTTL GLOBAL TRAP SERVICE ROUTINE TP4RTN -
4493 ;*****
4494 ;* BUS TIME-OUT TRAP (004 TRAP) SERVICE ROUTINE
4495 ;* THIS ROUTINE DETERMINES IF THE 004 TRAP WAS CAUSED BY
4496 ;* AN "EXPECTED" ERROR OR NOT BY EXAMINING THE RETURN PC VALUE ON THE
4497 ;* STACK. IF THE TRAP IS UNEXPECTED, THIS ROUTINE JUMPS TO THE NORMAL
4498 ;* DIAGNOSTIC SUPERVISOR 004 TRAP HANDLING ROUTINE.
4499 ;*
4500 ;*
4501 ;* INPUTS: SP - POINTS TO THE PC WHERE THE TRAP OCCURED.
4502 ;* ADRPTR LABEL AT THE ADDRESS WHERE "EXPECTED" TRAPS OCCUR.
4503 ;* TP4FLG - 004 TRAP FLAGS.
4504 ;*
4505 ;* OUTPUTS: TP4FLG - BIT 15 IS SET IF "EXPECTED" TRAP OCCURED.
4506 ;*
4507 ;* CALLING SEQUENCE: PUT ADDRESS POINTED TO BY TP4RTN IN 004 VECTOR.
4508 ;* OCCURENCE OF 004 TRAP VECTORS TO THIS ROUTINE.
4509 ;*
4510 ;* COMMENTS: ANY 004 TRAP WHICH OCCURS AT AN ADDRESS OTHER THAN THAT LABELED
4511 ;* ADRPTR WILL BE HANDLED BY THE NORMAL 004 TRAP SERVICE ROUTINE.
4512 ;*
4513 ;* SUBORDINATE ROUTINES CALLED: NONE.
4514 ;*****
4515
4516 024124 021627 017764 TP4RTN:: CMP (SP),#ADRPTR ;COMPARE EXPECTED ADR AGAINST TRAP RET PC.
4517 024130 001402 BEQ 2$ ;IF THEY MATCH, CONTINUE THIS ROUTINE.
4518 024132 000177 156164 JMP @TP4VEC ;IF NOT,JUMP TO NORMAL 004 TRAP SERVICE RTN.
4519 024136 052767 100000 156154 2$: BIS #BIT15,TP4FLG ;SET THE 004 TRAP OCCURED FLAG.
4520 024144 000002 RTI ;ALL DONE, GO BACK TO THE TEST.

```

```

4522 .SBTTL INTERRUPT SERVICE ROUTINE - TXINTR
4523 ;* *****
4524 ;* - TRANSMIT INTERRUPT SERVICE ROUTINE -
4525 ;* THIS ROUTINE HANDLES A TRANSMIT INTERRUPT FROM THE DEVICE UNDER TEST
4526 ;* (DUT) BY COUNTING THE INTERRUPT AND READING THE DUT CSR TO CLEAR THE
4527 ;* INTERRUPT REQUEST. THIS ROUTINE ALSO SETS A FLAG TO INDICATE THAT
4528 ;* A TX INTERRUPT HAS OCCURRED AND SETS A FLAG IF THE TX.ACTION BIT IS
4529 ;* NOT SET IN THE READ CONTENTS OF THE DUT CSR.
4530 ;*
4531 ;* INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR.
4532 ;* TXINTC HOLDS THE COUNT OF THE NUMBER OF TX INTERRUPTS.
4533 ;* TXINTF TX INTERRUPT FLAGS.
4534 ;*
4535 ;* OUTPUTS: TXINTC CONTAINS THE UPDATED TX INTERRUPT COUNT.
4536 ;* TXINTF TX INT FLAGS (BIT 0 SET, BIT 15 SET IF TX.ACTION CLR).
4537 ;*
4538 ;* CALLING SEQUENCE: PUT THE ADDRESS OF THE LABEL TXINTR IN THE VECTOR
4539 ;* LOCATION.
4540 ;*
4541 ;* COMMENTS:
4542 ;*
4543 ;* SUBORDINATE ROUTINES CALLED: NONE
4544 ;* - *****
4545
4546 024146 TXINTR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
024146 004567 157624 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
4547 024152 016701 156150 MOV TXINTC,R1 ;GET THE TX INTERRUPT COUNT.
4548 024156 005201 INC R1 ;INCREMENT THE COUNT.
4549 024160 102001 BVC 2$ ;BRANCH IF NO OVERFLOW OCCURRED.
4550 024162 005301 DEC R1 ;RESET THE COUNT TO 177777.
4551 024164 010167 156136 2$: MOV R1,TXINTC ;SAVE NEW COUNT VALUE.
4552 024170 016703 156134 MOV TXINTF,R3 ;GET THE TX INTERRUPT FLAGS.
4553 024174 017702 156042 MOV @CSRA,R2 ;READ THE CSR.
4554 024200 100402 BMI 4$ ;SKIP SETTING OF FLAG IF TX.ACTION IS SET.
4555 024202 052703 100000 BIS @BIT15,R3 ;SET THE TX.ACTION CLEAR FLAG.
4556 024206 052703 000001 4$: BIS @BIT0,R3 ;SET THE TX INT HAS OCCURRED FLAG.
4557 024212 010367 156112 MOV R3,TXINTF ;UPDATE THE TX INTERRUPT FLAGS.
4558 024216 60$: PASS ;RESTORE GPRS.
024216 004736 JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
4559 024220 000002 RTI
  
```

4568
 4569
 4570
 4571
 4572
 4573
 4574
 4575
 4576
 4577 024222
 024222
 4578
 4579 024222
 024222 000167
 024224 000000
 4580
 4581
 4582
 4583 024226
 024226
 024226 104425

.SBTTL REPORT CODING SECTION

```

; *
; THE REPORT CODING SECTION CONTAINS THE
; 'PRINTS' CALLS THAT GENERATE STATISTICAL REPORTS.
;

```

BGNRPT

L1RPT::

EXIT RPT

```

.WORD JSJMP
.WORD L10017 2 .

```

.EVEN

ENDRPT

L10017:

TRAP C1RPT

4585
 4593
 4594
 4595
 4596
 4597
 4598
 4599
 4600 024230
 024230
 4601
 4602 024230 177777
 4603 024232 177777
 4604 024234 177777
 4605
 4606 024236
 4607

.SBTTL PROTECTION TABLE

;
 ; THIS TABLE IS USED BY THE RUNTIME SERVICES
 ; TO PROTECT THE LOAD MEDIA.
 ;

BGNPROT

L\$PROT::

1 ;OFFSET INTO P TABLE FOR CSR ADDRESS
 -1 ;OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
 1 ;OFFSET INTO P TABLE FOR DRIVE NUMBER

ENDPROT


```

4629
4630
4631
4632
4633
4634
4635
4636
4637
4638
4639
4640
4641
4642
4643 024236
4644 024236
4645 024236
4646 024244
4647 024246
4648 024246
4649 024254
4650 024256
4651 024256
4652 024264
4653 024266
4654 024266
4655 024274
4656 024276
4657 024302
4658 024302
4659
4660
4661
4662 024304
4663 024314
4664 024320
4665 024324
4666 024330
4667 024334
4668 024342

                                .SBTTL  INITIALIZE SECTION
                                ;**
                                ;*****
                                ;*      THIS SECTION CONTAINS THE CODE WHICH IS PERFORMED AT THE BEGINNING OF
                                ;*      EACH PASS OR AFTER A CONTINUE COMMAND.
                                ;*      THIS CODE PERFORMS THE FOLLOWING ACTIONS:
                                ;*
                                ;*      MOVES THE INFORMATION HELD IN THE HARDWARE P-TABLE INTO THE GLOBAL
                                ;*      DATA AREA.
                                ;*
                                ;*****
                                ;--
                                BGNINIT
                                ;SEE IF PROGRAM JUST STARTED, BR IF YES
                                READEF  @EF.START
                                ;SEE IF PROGRAM JUST RESTARTED, BR IF YES
                                READEF  @EF.RESTART
                                ;SEE IF THIS IS A NEW PASS, BR IF YES
                                READEF  @EF.NEW
                                ;SEE IF PROGRAM WAS JUST CONTINUED
                                READEF  @EF.CONTINUE
                                ;SET UP FOR LINE TIME CLOCK INTERRUPTS.
                                ;--
                                CLOCK  L,R1
                                ;GET THE CLOCK PARAMETERS.
                                ;STORE CLOCK CSR ADDRESS.
                                ;STORE CLOCK BUS REQ INT LEVEL.
                                ;STORE CLOCK INTERRUPT VECTOR.
                                ;STORE CLOCK FREQUENCY.
                                ;TEST FOR 50HZ LINE FREQUENCY.
                                ;BRANCH IF CLOCK IS NOT 50HZ.

                                L$INIT::
                                MOV     @EF.START,RO
                                TRAP   C$REFG
                                BCS    NEWSTA
                                MOV     @EF.RESTART,RO
                                TRAP   C$REFG
                                BCS    NEWRES
                                MOV     @EF.NEW,RO
                                TRAP   C$REFG
                                BCS    NEWPAS
                                MOV     @EF.CONTINUE,RO
                                TRAP   C$REFG
                                BCC    GETPRM
                                JMP     ENDIT
                                NEWSTA:
                                BRESET
                                ;RESET THE BUS TO PREVENT ILLEGAL INTERRUPTS.
                                TRAP   C$RESET
                                ;
                                ;
                                ;
                                MOV     (R1)+,CLKCSR
                                MOV     (R1)+,CLKBRL
                                MOV     (R1)+,CLKVEC
                                MOV     (R1)+,CLKHRZ
                                CMP     CLKHRZ,@50.
                                BNE     2$

```

```

4669 024344 012767 000024 156002      MOV    #20.,MSTICK      ;INDICATE 20MS PER CLOCK TICK.
4670 024352 000403                    BR     4$
4671 024354 012767 000021 155772 2$:  MOV    #17.,MSTICK      ;INDICATE 17 MS PER CLOCK TICK.
4672 024362 012767 000021 155772 4$:  SETVEC CLKVEC,#CLKINT,#PRI06 ;INITIALIZE CLOCK INTERRUPT VECTOR.
                                MOV    #PRI06,-(SP)
                                MOV    #CLKINT,-(SP)
                                MOV    CLKVEC,-(SP)
                                MOV    #3,(SP)
                                TRAP   C$SVEC
                                ADD    #10,SP
4673 024410 016700 155726      MOV    CLKHRZ,RO        ;INITIALIZE THE BREAK COUNT
4674 024414 006300                    ASL    RO                ; TO CAUSE A BREAK
4675 024416 010067 155730      MOV    RO,BCOUNT        ; EVERY 2 SECONDS.
4676 024422 012700 000240      SETPRI #PRI05           ;ALLOW CLOCK INTERRUPTS DISABLE OTHERS.
                                MOV    #PRI05,RO
                                TRAP   C$SPRI
4677                                ;+
4678                                ; ENABLE THE LINE TIME CLOCK (LTC) CHECKING TO MAKE SURE THAT THE CSR
4679                                ; IS ACCESSABLE.
4680                                ; FIRST SET UP TO CATCH ANY 004 TRAPS WHICH OCCUR:
4681                                ;-
4682 024430 016767 153350 155664      MOV    4,TP4VEC         ;SAVE THE EXISTING 004 TRAP VECTOR.
4683 024436 012767 024124 153340      MOV    #TP4RTN,4        ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4684                                ;+
4685                                ; ENABLE LTC CHECKING FOR 004 TRAP IN CASE CSR IS NOT THERE.
4686                                ;-
4687 024444 005067 155650                    CLR    TP4FLG           ;CLEAR THE 004 TRAP FLAG.
4688 024450 012767 000100 155654      MOV    #BIT6,WORD1      ;SET UP TO SET BIT6 OF THE LTC CSR.
4689 024456 012700 002332      MOV    #WORD1,RO        ;SET UP WORD1 AS THE CKTRAP MOVE SOURCE.
4690 024462 016701 155646      MOV    CLKCSR,R1        ;SET UP LTC CSR AS DESTINATION FOR CKTRAP MOVE.
4691 024466 004767 173260      JSR    PC,CKTRAP        ;MOVE AND CHECK FOR TRAP.
4692 024472 016767 155624 153304      MOV    TP4VEC,4         ;RESTORE THE NORMAL 004 TRAP VECTOR.
4693 024500 103403                    BCS    6$              ;IF NO TRAP, LTC IS THERE SO CONTINUE.
4694 024502 005067 155634      CLR    CLKHRZ           ;CLEAR LTC FREQUENCY WORD TO INDICATE NO LTC.
4695 024506 000402                    BR     8$              ;BYPASS THE FOLLOWING CALIBRATION PROCEDURES.
4696                                ;+
4697                                ; CALIBRATE THE DELAY ROUTINE MILLI-SECOND DELAY COUNT VALUE.
4698                                ;-
4699 024510 004767 173012      6$:  JSR    PC,CALMSL
4700                                ;+
4701                                ; CHECK FOR MEMORY MANAGEMENT PRESENT ON THIS MACHINE.
4702                                ; IF MEM MGT IS PRESENT, DISABLE IT.
4703                                ;-
4704 024514 016767 153264 155600      8$:  MOV    4,TP4VEC         ;SAVE THE EXISTING 004 TRAP VECTOR.
4705 024522 012767 024124 153254      MOV    #TP4RTN,4        ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4706 024530 005067 155564      CLR    TP4FLG           ;CLEAR THE 004 TRAP FLAG.
4707 024534 005067 155572      CLR    WORD1            ;PREPARE TO CLEAR THE MEM MGT SRO REGISTER.
4708 024540 012700 002332      MOV    #WORD1,RO        ;SELECT CLEARED WORD AS CKTRAP RTN SOURCE.
4709 024544 016701 155610      MOV    MMSRO,R1         ;SELECT MEM MGT SRO REGISTER AS DESTINATION.
4710 024550 005067 155606      CLR    MMPRES           ;INDICATE NO MEM MGT PRESENT IN CASE IT ISN'T.
4711 024554 005067 155604      CLR    MMENAB           ;INDICATE MEM MGT IS NOT ENABLED.
4712 024560 004767 173166      JSR    PC,CKTRAP        ;CLEAR THE MEM MGT SRO REG AND CHECK FOR TRAP.
4713 024564 016767 155532 153212      MOV    TP4VEC,4         ;RESTORE THE NORMAL 004 TRAP VECTOR.
4714 024572 103003                    BCC    10$             ;SKIP INDICATING MEM MGT PRESENT IF IT ISN'T.
4715 024574 012767 000001 155560      MOV    #1,MMPRES        ;INDICATE THAT MEM MGT IS PRESENT.
4716 024602 005067 155504      10$: CLR    PASCNT        ;CLR COUNTER USED IN REPORTING ROM VERSION #.
4717 024606 000167 000006      JMP    NEWPAS           ;SKIP AROUND THE BUS RESET, IT'S BEEN DONE.

```

```

4718
4719 024612          NEWRES: BRESET          ;RESET THE BUS TO PREVENT ILLEGAL INTERRUPTS.
      024612 104433          TRAP C$RESET
4720 024614 005067 155472          CLR PASCNT          ;CLR COUNTER USED IN REPORTING ROM VERSION #.
4721 024620          NEWPAS:
4722 024620 012767 177777 155410  MOV # 1,UNITN      ;RESET LOGICAL DEVICE TO -1
4723          ;*
4724          ; INCREMENT THE PASS COUNTER, CORRECT FOR ANY OVERFLOW.
4725          ; THIS COUNTER IS USED IN THE ROM VERSION TEST.
4726          ;-
4727 024626 005267 155460          INC PASCNT          ;INCREMENT THE PASS COUNTER.
4728 024632 001002          BNE GETPRM      ;BRANCH IF WE HAVE NOT YET! OVERFLOWED.
4729 024634 005367 155452          DEC PASCNT          ;SET PASS COUNT TO 177777 OCTAL.
4730
4731          ; GET THE HARDWARE PARAMETERS FOR THIS UNIT.
4732 024640          GETPRM:
4733 024640 005267 155372          INC UNITN          ;INCREMENT LOGICAL DEVICE NUMBER
4734 024644 026767 155366 155140  CMP UNITN,L$UNIT   ;SEE IF MAXIMUM UNIT NO. EXCEEDED
4735 024652 002362          BGE NEWPAS      ;BR IF YES
4736
4737 024654          GPHARD UNITN,R1      ;GET P TABLE POINTER INTO R1
      024654 016700 155356          MOV UNITN,R0
      024660 104442          TRAP C$GPHRD
      024662 010001          MOV R0,R1
4738 024664          BCOMPLETE 30$      ;BR IF DEVICE AVAILABLE
      024664 103401          BCS 30$
4739 024666 000764          BR GETPRM      ;SKIP THIS DEVICE
4740
4741
4742          ;***** HARDWARE PARAMETER MOVING CODE *****
4743 024670 012167 155346 30$: MOV (R1)+,CSRA      ;STORE DHU-11 CSR ADDRESS IN DEV.REG.ADDRESS TABLE
4744 024674 012102          MOV (R1)+,R2          ;GET THE RX INTERRUPT VECTOR ADDRESS.
4745 024676 010267 155330          MOV R2,RXVECA      ;STORE RX INT VECTOR ADDRESS.
4746 024702 062702 000004          ADD #4,R2          ;CALCULATE TX INTERRUPT VECTOR ADDRESS.
4747 024706 010267 155322          MOV R2,TXVECA      ;STORE TX INT VECTOR ADDRESS.
4748 024712 012167 155312          MOV (R1)+,ACTLNS   ;STORE DHU-11 ACTIVE LINE BIT MAP
4749 024716 111167 155316          MOV#B (R1),BRLEVL  ;STORE DHU 11 INTERUPT BUS REQUEST LEVEL
4750          ;*
4751          ; CALCULATE DEVICE REGISTER ADDRESSES,AND PUT THEM IN THE
4752          ; DEVICE REGISTER ADDRESS TABLE.
4753          ;-
4754 024722 016701 155314          MOV CSRA,R1        ;COPY CSR ADDRESS
4755 024726 005201          INC R1            ;INCREMENT CSR ADDRESS
4756 024730 005201          INC R1            ; COPY BY 2.
4757 024732 012703 000007          MOV #7,R3         ;SET UP REGISTER COUNT
4758 024736 012702 002244          MOV #RBUFA,R2    ;GET LOCATION WHERE RBUF ADDRESS GOES IN TABLE
4759 024742 010122          12$: MOV R1,(R2)+       ;STORE REGISTER ADDRESS IN TABLE
4760 024744 005201          INC R1            ;INCREMENT REGISTER ADDRESS
4761 024746 005201          INC R1            ; BY 2,FOR THE NEXT DEVICE REGISTER.
4762 024750 005303          DEC R3            ;DECREMENT REGISTER COUNT
4763 024752 001373          BNE 12$          ;LOOP IF NOT DONE
4764
4765          ;*
4766          ; INITIALISE THE BMP CODE QUEUE.
4767          ;
4768 024754 012700 002526          MOV #BMPCQB,R0    ;GET THE START ADDRESS OF THE QUEUE.
4769 024760 012701 002726          MOV #BMPCQE,R1    ;GET THE END ADDRESS OF THE QUEUE.

```

```

4770 024764 010067 155534      MOV    R0,BMPCQP      ;SET THE POINTER TO THE START OF THE QUEUE.
4771 024770 005020      CLR    (R0)+          ;CLEAR OUT THE CONTENTS OF THE QUEUE.
4772 024772 020001      CMP    R0,R1          ;CHECK IF END OF QUEUE HAS BEEN REACHED.
4773 024774 103775      BLO   14$            ;LOOP IF NOT ALL DONE.
4774                          ;+
4775                          ; REPORT THE UNIT NUMBER IF THE SOFTWARE P-TABLE QUESTION WAS ANSWERED YES,
4776                          ; AND THE MAXIMUM UNIT NUMBER IS GREATER THAN 1.
4777                          ;
4778 024776 032767 000020 155220      BIT    @BIT4,OPTION   ;CHECK IF THE QUESTION WAS ANSWERED YES.
4779 025004 001416      BEQ   16$            ;SKIP REPORTING UNIT NUMBER IF IT IS DISABLED.
4780 025006 026727 155000 000001      CMP    L$UNIT,@1     ;CHECK MAXIMUM NUMBER OF UNITS SELECTED.
4781 025014 003412      BLE   16$            ;DO NOT REPORT UNIT NUMBER IF MAX NUMBER < 1.
4782 025016      PRINTF @MFUNIT,UNITN ;REPORT UNIT NUMBER.
                                MOV    UNITN,(SP)
                                MOV    @MFUNIT,(SP)
                                MOV    @2,-(SP)
                                MOV    SP,R0
                                TRAP   C$PN*F
                                ADD    @6,SP
4783 025042      16$:
4784
4785 025042 005067 155240      ENDIT: CLR    CTRLCF      ;CLR THE CTRL C TEST ABORT FLAG.
4786                          ;+
4787                          ; SET THE PROCESSOR PRIORITY TO DISABLE ALL INTERRUPTS.
4788                          ;-
4789 025046      SETPRI @PRI07          ;SET PROCESSOR PRIORITY TO 7.
                                MOV    @PRI07,R0
                                TRAP   C$SPRI
4790 025054      ENDINIT
                                L10021:
                                TRAP   C$INIT
4791
4792      000000      TNUM == 0          ;INITIALIZE THE ASSEMBLER TEST NUMBER VARIABLE.

```

4801
4802
4803
4804
4805
4806
4807
4808
4809
4810
4811
4812
4813
4814
4821
4822

025056
025056

025056
025056
025056

104461

.SBTTL AUTODROP SECTION

;;
; THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
; THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO
; SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
; DROPPED FROM TESTING.
;

BGNAUTO

L\$AUTO::

ENDAUTO

L10022:

TRAP C\$AUTO

4831
4832
4833
4834
4835
4836
4837
4838
4839

.SBTTL CLEANUP CODING SECTION

; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
; AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
;

4840 025060
025060

BGNCLN

L\$CLEAN::

4841
4850 025060 005767 155222

TST CTRLCF
BEQ 2\$
BRESET

;DID WE GET HERE BY CTRL-C FROM TEST?
;CTRL-C FROM TEST? NO, SKIP BUS RESET.
;YES, CLR ANY DMAS OR OUTSTANDING INTERRUPTS.

4851 025064 001401
4852 025066 104433

TRAP C\$RESET

4853 025070
4854 025070 104432

2\$:

EXIT CLN

TRAP C\$EXIT
.WORD L10023-

025070 104432
025072 000002

4855
4867
4868
4869

.EVEN

4870 025074
025074
025074 104412

ENDCLN

L10023:

TRAP C\$CLEAN

4879
4880
4881
4882
4883
4884
4885
4886
4887

.SBTTL DROP UNIT SECTION

; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
; TO NO LONGER BE TESTED.
; -

4888 025076
025076
4897 025076 010046
025100 012746 025122
025104 012746 000002
025110 010600
025112 104417
025114 062706 000006
4898 025120 000427

BGNDU

PRINTF #DROP,RO

L\$DU:;
;REPORT UNIT THAT HAS BEEN DROPPED.

MOV RO,-(SP)
MOV #DROP,-(SP)
MOV #2,(SP)
MOV SP,RO
TRAP C\$PNTF
DU #6,SP

BR EDROP

;BRANCH AROUND THE MESSAGE.

4900 025122 045 101 040
025125 125 116 111
025130 124 045 104
025133 066 045 101
025136 040 104 122
025141 117 120 120
025144 105 104 040
025147 106 122 117
025152 115 040 106
025155 125 122 124
025160 110 105 122
025163 040 124 105
025166 125 124 111
025171 116 107 056
025174 045 116 000

DROP: .ASCIZ/##A UNIT#D6##A DROPPED FROM FURTHER TESTING.#N/

4901
4902 025200
4903 025200
025200 000167
025202 000000

EDROP: .EVEN

EXIT DU

.WORD J\$JMP
.WORD L10024-2-.

4904
4905
4906
4907 025204
025204
025204 104453

ENDDU

L10024:
TRAP C\$DU

4916
4917
4918
4919
4920
4921
4922
4923
4924
4925
4926
4927
4928
4929
4930
4931
4932
4933
4934
4935
4936
4937
4938
4939
4940
4941

025206
025206
025210
000167
000000
025212
025212
104452

.SBTTL ADD UNIT SECTION

; THE ADD UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
; TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
; TO THE TEST CYCLE.
;-

BGNAU

L\$AU::

; INSERT ADD CODE HERE. THIS CODE WILL BE EXECUTED AFTER
; AN "ADD" COMMAND. THE PURPOSE OF THIS CODE IS TO DO ANY
; HOUSEKEEPING THAT MAY BE NECESSARY AFTER A UNIT HAS BEEN ADDED.
; THIS SECTION IS OPTIONAL.

EXIT AU

.WORD J\$JMP
.WORD L10025 2-

.EVEN

ENDAU

L10025: TRAP C\$AU

4943
 4944
 4945
 4946
 4947
 4948
 4949
 4950
 4951
 4952
 4953
 4954
 4955
 4956
 4957 025214
 025214
 4958
 4959 025214 000001
 4960 025222 012767 000001 155102
 4961 025230 012767 000145 156532
 4962 025236 012767 005560 156526
 4963 025244 012767 015510 156522
 4964
 4965
 4966
 4967 025252 016767 152526 155042
 4968 025260 012767 024124 152516
 4969 025266 005005
 4970
 4971
 4972
 4973
 4974
 4975 025270 016700 154746
 4976 025274 012701 025466
 4977 025300 004767 172446
 4978 025304 103402
 4979 025306 052705 100001
 4980 025312 042767 000017 000146 4\$:
 4981 025320 010100
 4982 025322 016701 154714
 4983 025326 004767 172420
 4984 025332 103403
 4985 025334 052705 100002
 4986 025340 000434
 4987
 4988
 4989
 4990 025342 012702 000010
 4991 025346 016767 154670 000110
 4992 025354 016700 000104
 4993 025360 012701 025466
 4994 025364 004767 172362
 4995 025370 103402
 4996 025372 052705 100001
 4997 025376 010100
 4998 025400 016701 000060

```

.SBTL  HARDWARE TEST          ADRA
; **
; *****
; *                               - REGISTER ADDRESS TEST
; *
; * THIS TEST VERIFIES THAT THE DEVICE REGISTERS WILL RESPOND TO THE PROPER
; * UNIBUS HANDSHAKING SIGNALS WHEN ACCESSED. IF THE DHU11 DOES NOT RESPOND
; * TO THE ACCESS ATTEMPTS (IF THE DHU11 IS AT THE WRONG ADDRESS, FOR EXAMPLE)
; * THE 004 BUS TIME-OUT TRAP IS DETECTED BY THIS ROUTINE AND AN ERROR
; * IS REPORTED. THIS TEST IS PERFORMED ON LINE 0 ONLY.
; *
; *****
; --

BGNTST

                                T1::
4958      TNUM == TNUM + 1      ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
4959      MOV  @TNUM,TSTNUM     ;SET UP THE TEST NUMBER. (1)
4960      MOV  @-1,CTRLCF      ;INDICATE THAT WE ARE IN A TEST.
4961      MOV  @101,ERRNBR     ;SET THE TEST ERROR NUMBER IN THE TABLE.
4962      MOV  @EM0103,ERRMSG  ;SET UP THE TEST FAILURE MESSAGE IN THE TABLE.
4963      MOV  @ER0101,ERRBLK  ;SET-UP THE ERROR ROUTINE IN THE ERROR TABLE.
4964
; +
; SET UP TO CATCH ANY 004 TRAPS WHICH OCCUR:
; -
4967      MOV  4,TP4VEC        ;SAVE THE EXISTING 004 TRAP VECTOR.
4968      MOV  @TP4RTN,4       ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4969      CLR  R5              ;CLEAR THE ERROR FLAGS.
4970
; +
; HERE BEGINS THE LOOP TO TEST THE REGISTERS FOR A LINE.
; FIRST TEST THE CSR AND SET THE IND.ADR.REG (I.A.R) FIELD.
; -
4975      MOV  CSRA,R0         ;SET UP CSR AS THE CKTRAP MOVE SOURCE.
4976      MOV  @52$,R1         ;SET UP DESTINATION LOCATION FOR CKTRAP MOVE.
4977      JSR  PC,CKTRAP       ;MOVE AND CHECK FOR TRAP.
4978      BCS  4$              ;IF NO TRAP, BYPASS ERROR.
4979      BIS  @100001,R5      ;SET FATAL READ ERROR FLAGS.
4980      BIC  @17,52$         ;CLEAR THE I.A.R FIELD OF THE CSR DATA.
4981      MOV  R1,R0           ;USE OLD DESTINATION FOR SOURCE OF CKTRAP MOVE.
4982      MOV  CSRA,R1         ;SET UP CSR AS THE CKTRAP MOVE DESTINATION.
4983      JSR  PC,CKTRAP       ;MOVE AND CHECK FOR TRAP.
4984      BCS  6$              ;IF NO TRAP, BYPASS ERROR.
4985      BIS  @100002,R5      ;SET FATAL WRITE ERROR FLAGS.
4986      BR   40$            ;EXIT AND REPORT FATAL ERROR.
4987
; +
; NOW, WE TEST EACH REGISTER FOR THIS LINE.
; -
4990      MOV  @8$,R2          ;INIT REGISTER COUNTER TO 8.
4991      MOV  CSRA,50$        ;INITIALIZE THE REGISTER POINTER.
4992      MOV  50$,R0          ;SET UP REGISTER AS THE SOURCE FOR CKTRAP MOVE.
4993      MOV  @52$,R1         ;SET UP LOCAL STORAGE AS THE DES FOR CKTRAP.
4994      JSR  PC,CKTRAP       ;PERFORM THE MOVE, CHECK FOR TRAP.
4995      BCS  10$            ;IF NO TRAP, BYPASS THE SETTING OF ERROR FLAGS.
4996      BIS  @100001,R5      ;SET FATAL READ ERROR FLAGS.
4997      MOV  R1,R0           ;USE OLD DEST AS SRC FOR CKTRAP MOVE.
4998      MOV  50$,R1         ;SET UP REGISTER AS THE DEST FOR CKTRAP MOVE.

```

```

4999 025404 004767 172342      JSR      PC,CKTRAP      ;PERFORM THE MOVE, CHECK FOR TRAP.
5000 025410 103402              BCS      12$           ;IF NO TRAP, BYPASS THE SETTING OF ERROR FLAGS.
5001 025412 052705 100002      BIS      @100002,R5    ;SET FATAL WRITE ERROR FLAGS.
5002 025416 005267 000042      12$:    INC      50$           ;INCREMENT THE REGISTER
5003 025422 005267 000036      INC      50$           ; POINTER BY 2.
5004 025426 005302              DEC      R2            ;COUNT THE REGISTER.
5005 025430 001351      BNE      8$            ;LOOP TO TEST THE NEXT REGISTER ADDRESS.
5006
5007
5008      ;+
5009      ; DONE CHECKING DEVICE REGISTER ADDRESSES.
5010      ; REPORT ANY ERRORS AND EXIT.
5011      ;-
5012 025432 016767 154664 152344 40$:    MOV      TP4VEC,4      ;RESTORE THE NORMAL 004 TRAP VECTOR.
5013 025440 005705              TST      R5            ;CHECK THE ERROR FLAGS.
5014 025442 100012      BPL      60$           ;EXIT ROUTINE IF NO ERRORS.
5015
5016      ;+
5017      ; REPORT "DEVICE REGISTER ACCESS TEST FAILED"
5018      ;-
5018 025444 104460      ERROR
5019
5020
5021 025446 016700 154564      DODU     UNITN          ;DROP THIS UNIT FROM FUTHER TESTING.
5022 025452 104451              MOV      UNITN,R0     MOV      UNITN,R0
5023 025454 005067 154626      CLR      CTRLCF        ;INDICATE NO CTRL-C ABORT FROM TEST.
5024 025460 104444              DOCLN    C$DODU      TRAP      C$DODU
5025 025462 000402              BR       60$           ;ABORT THIS SUB PASS.
5026
5027 025464 000000      ;***** LOCAL STORAGE. *****
5028 025466 000000      50$:    .WORD 0          ;STORAGE FOR THE SOURCE OR DEST OF THE CKTRAP MOVE.
5029
5030      52$:    .WORD 0          ;STORAGE FOR THE SOURCE OR DEST OF THE CKTRAP MOVE.
5031
5031 025470 005067 154612      60$:    CLR      CTRLCF        ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5032 025474
5032 025474
5032 025474 104401      L10026: TRAP      C$ETST
    
```

```

5034 .SBTTL HARDWARE TEST - MRSTA
5035 ;* .....
5036 ;* - MASTER RESET WITH SELFTEST TEST
5037 ;* THIS TEST VERIFIES THAT THE MASTER RESET BIT WILL CLEAR AFTER A DEVICE
5038 ;* RESET AND THE PERFORMANCE OF THE DUT ROM BASED SELFTEST.
5039 ;*
5040 ;* .....
5041 ; BGNTST
5042 ; TNUM -- TNUM + 1 ; INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5043 025476 012767 000002 154620 MOV #TNUM,TSTNUM ; SET UP THE TEST NUMBER. (2)
5044 025504 012767 177777 154574 MOV #1,CTRLCF ; INDICATE THAT WE ARE IN A TEST.
5045 025512 SETPRI #PRIOS ; ALLOW LTC INTERRUPTS.
5046 025512 012700 000240 MOV #PRIOS,R0
5047 025516 104441 TRAP C1SPRI
5048 025520 012767 000001 156240 MOV #1,ERRTYP ; SET ERROR TYPE AS FATAL IN ERROR TABLE.
5049 025526 012767 005616 156236 MOV #EM0201,ERRMSG ; SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5050 025534 012767 016042 156232 MOV #ER0201,ERRBLK ; SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5051 ;*
5052 ; WAIT UP TO 5 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
5053 ;*
5054 025542 012701 011610 MOV #5000.,R1 ; TIME-OUT VALUE IS 5.0 SECONDS.
5055 025546 012702 000040 MOV #BIT05,R2 ; WAITING FOR MASTER RESET BIT.
5056 025552 005003 CLR R3 ; WAITING FOR BIT TO CLEAR.
5057 025554 016704 154462 MOV CSRA,R4 ; BIT IS IN THE DUT'S CSR.
5058 025560 004767 172400 JSR PC,MSLGET ; WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5059 025564 103410 BCS 21 ; SKIP TO RESET DUT IF MR CLEAR.
5060 ;*
5061 ; DUT MASTER RESET BIT DID NOT GO CLEAR. DEVICE MAY BE STUCK IN SOME
5062 ; ODD STATE. TRY TO RESET DEVICE WITH A BUS RESET.
5063 ;*
5064 025566 BRESET ; NO, TRY TO JOG DEVICE WITH BUS RESET.
5065 025566 104433 TRAP C1RESET
5066 025570 004767 174550 JSR PC,SKPSTS ; TRY TO SKIP THE SELFTEST.
5067 025574 012701 011610 MOV #5000.,R1 ; TIME-OUT VALUE IS 5.0 SECONDS.
5068 025600 004767 172360 JSR PC,MSLGET ; WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5069 025604 103016 BCC 41 ; GO REPORT ERROR IF MR BIT DID NOT CLEAR.
5070 ;*
5071 ; SET THE MASTER RESET BIT AND VERIFY THAT IT CLEARS WITHIN THE PROPER TIME.
5072 ;*
5073 21: MOV #5000.,R1 ; TIME-OUT VALUE IS 5.0 SECONDS.
5074 MOV R2,(R4) ; SET THE DUT MASTER RESET BIT.
5075 JSR PC,MSLGET ; WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5076 BCC 41 ; GO REPORT ERROR IF MR BIT DID NOT CLEAR.
5077 MOV #5000.,R2
5078 SUB R1,R2 ; CALCULATE # OF MS FOR MR TO CLEAR.
5079 BEQ 61 ; GO REPORT ERROR IF MR CLEAR IMMEDIATELY.
5080 CMP R2,#500.
5081 BLT 81 ; GO REPORT ERROR IF MR CLEAR IN < 1/2 SECOND.
5082 BR 601 ; EXIT THE TEST WITHOUT ERROR.
5083 ;*
5084 ; ERROR REPORTS:
5085 ;*
5086 ; REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
5087 41: MOV #201.,ERRNBR ; SET THE ERROR NUMBER IN ERROR TABLE.
5088 MOV #EM0202,R1 ; SELECT ERROR MESSAGE.
5089 ERROR ; REPORT ERROR. >>>> ERROR #201 <<<<

```

```

5087 025654 104460
5088 025656 000415 BR 60$ ;EXIT THE TEST. TRAP C$ERROR
5089 ;REPORT MR BIT CLEAR IMMEDIATELY AFTER DUT RESET.
5090 025660 012767 000312 156102 6$: MOV #202.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5091 025666 012701 006024 MUV #EM0203,R1 ;SELECT ERROR MESSAGE.
5092 025672 ERROR ;REPORT ERROR. >>>> ERROR #202 <<<<<
025672 104460 TRAP C$ERROR
5093 025674 000406 BR 60$ ;EXIT THE TEST.
5094
5095 ;REPORT MR CLEAR WITHIN 1/2 SECOND OF DUT RESET.
5096 025676 012767 000313 156064 6$: MOV #203.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5097 025704 012701 006167 MOV #EM0204,R1 ;SELECT ERROR MESSAGE.
5098 025710 ERROR ;REPORT ERROR. >>>> ERROR #203 <<<<<
025710 104460 TRAP C$ERROR
5099
5100 025712 60$: SETPRI #PRI07 ;DISABLE ALL INTERRUPTS. MOV #PRI07,RO
025712 012700 000340 TRAP C$SPRI
025716 104441
5101 025720 005067 154362 CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
5102 025724 ENDTST L10027: TRAP C$ETST
025724 104401

```

```

5104 .SBTTL  HARDWARE TEST          MRSSTA -
5105 ;* .....
5106 ;* - MASTER RESET WITH SKIP SELFTEST TEST
5107 ;* THIS TEST VERIFIES THAT THE MASTER RESET BIT WILL CLEAR AFTER A DEVICE
5108 ;* RESET AND THE SKIPPING OF THE DUT ROM BASED SELFTEST.
5109 ;*
5110 ;* .....
5111 ;-- .....
5111 025726          BGNTST
5111 025726
5112 000003          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5113 025726 012767 000003 154370          MOV #TNUM,TSTNUM          ;SET UP THE TEST NUMBER. (3)
5114 025734 012767 177777 154344          MOV #0-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
5115 025742          SETPRI #PRIOS          ;ALLOW LTC INTERRUPTS.
5115 025742 012700 000240          MOV #PRIOS,RO          TRAP C#SPRI
5115 025746 104441          TRAP C#SPRI
5116 025750 012767 000001 156010          MOV #1,ERRTP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5117 025756 012767 006346 156006          MOV #EMO301,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5118 025764 012767 016042 156002          MOV #ERO201,ERRBLK          ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5119 ;*
5120 ; WAIT UP TO 5 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
5121 ;--
5122 025772 012701 011610          MOV #5000.,R1          ;TIME-OUT VALUE IS 5.0 SECONDS.
5123 025776 012702 000040          MOV #BIT05,R2          ;WAITING FOR MASTER RESET BIT.
5124 026002 005003          CLR R3          ;WAITING FOR BIT TO CLEAR.
5125 026004 016704 154232          MOV CSRA,R4          ;BIT IS IN THE DUT'S CSR.
5126 026010 004767 172150          JSR PC,MSLGET          ;WAIT FOR DUT_CSP_MR BIT TO CLEAR.
5127 026014 103410          BCS 2$          ;SKIP TO RESET DUT IF MR CLEAR.
5128 ;*
5129 ; DUT MASTER RESET BIT DID NOT GO CLEAR. DEVICE MAY BE STUCK IN SOME
5130 ; ODD STATE. TRY TO RESET DEVICE WITH A BUS RESET.
5131 ;--
5132 026016          BRESET          ;NO, TRY TO JOG DEVICE WITH BUS RESET.
5132 026016 104433          TRAP C#RESET
5133 026020 004767 174320          JSR PC,SKPSTS          ;TRY TO SKIP THE SELFTEST.
5134 026024 012701 011610          MOV #5000.,R1          ;TIME-OUT VALUE IS 5.0 SECONDS.
5135 026030 004767 172130          JSR PC,MSLGET          ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5136 026034 103024          BCC 6$          ;GO REPORT ERROR IF MR BIT DID NOT CLEAR.
5137 ;*
5138 ; SET THE MASTER RESET BIT, TRY TO SKIP THE SELFTEST, AND VERIFY THAT THE
5139 ; MR BIT CLEARS WITHIN 1/5 SECOND.
5140 ;--
5141 026036 012701 000310          2$: MOV #200.,R1          ;TIME-OUT VALUE IS 1/5 SECOND.
5142 026042 010214          MOV R2,(R4)          ;SET THE DUT MASTER RESET BIT.
5143 026044 004767 174274          JSR PC,SKPSTS          ;TRY TO SKIP THE SELFTEST.
5144 026050 004767 172110          JSR PC,MSLGET          ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5145 026054 103007          BCC 4$          ;GO FIND OUT WHAT IS WRONG IF MR NOT CLEAR.
5146 026056 012702 000310          MOV #200.,R2
5147 026062 160102          SUB R1,R2          ;CALCULATE # OF MS FOR MR TO CLEAR.
5148 026064 020227 000012          CMP R2,#10.
5149 026070 002415          BLT 8$          ;GO REPORT ERROR IF MR CLEAR IN < 10 MS.
5150 026072 000431          BR 60$          ;EXIT THE TEST WITHOUT ERROR.
5151 ;*
5152 ; MR DID NOT CLEAR WITHIN 1/5 SECOND, SEE IF IT CLEARS WITHIN 5 SECONDS.
5153 ;--
5154 026074 012701 011300          4$: MOV #4800.,R1          ;TIME OUT VALUE IS 5 SECONDS MINUS 1 5 SECOND.
5155 026100 004767 172060          JSR PC,MSLGET          ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5156 026104 103416          BCS 10$          ;GO REPORT ERROR IF MR CLEARED FINALLY.
    
```

```

5157
5158 ; ERROR REPORTS:
5159 ;
5160 ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
5161 026106 012767 000455 155654 6$: MOV #0301.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5162 026114 012767 005651 MOV #EM0202,R1 ;SELECT ERROR MESSAGE.
5163 026120 ERROR ;REPORT ERROR. >>>> ERROR #0301 <<<<
026120 104460 TRAP C$ERROR
5164 026122 000415 BR 60$ ;EXIT THE TEST.
5165
5166 ;REPORT MR BIT CLEAR WITHIN 10 MS AFTER DUT RESET.
5167 026124 012767 000456 155636 8$: MOV #0302.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5168 026132 012701 006420 MOV #EM0302,R1 ;SELECT ERROR MESSAGE.
5169 026136 ERROR ;REPORT ERROR. >>>> ERROR #0302 <<<<
026136 104460 TRAP C$ERROR
5170 026140 000406 BR 60$ ;EXIT THE TEST.
5171
5172 ;REPORT MR CLEARED BETWEEN 1/5 SECOND AND 5 SECONDS OF DUT RESET.
5173 026142 012767 000457 155620 10$: MOV #0303.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5174 026150 012701 006560 MOV #EM0303,R1 ;SELECT ERROR MESSAGE.
5175 026154 ERROR ;REPORT ERROR. >>>> ERROR #0303 <<<<
026154 104460 TRAP C$ERROR
5176
5177 60$: SETPRI #PPI07 ;DISABLE ALL INTERRUPTS.
026156 012700 000340 MOV #PPI07,R0
026162 104441 TRAP C$SPRI
5178 026164 005067 154116 CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
5179 026170
026170 104401 L10030: TRAP C$ETST
    
```

```

5181 .SBTTL HARDWARE TEST RXCHRA
5182 ;* *****
5183 ;* - RBUF REGISTER RX CHARACTER FIELD TEST
5184 ;* THIS TEST VERIFIES THAT THE RX CHARACTER FIELD OF THE DUT RBUF REGISTER
5185 ;* APPEARS TO BE FUNCTIONING CORRECTLY. THIS TEST USES THE CODES WHICH
5186 ;* SHOULD BE IN THE FIFO AFTER A BOARD RESET AND SKIP SELFTEST SEQUENCE.
5187 ;*
5188 ;* *****
5189 ;* BGNTST
5190 ;* T4::
5190 SETPRI @PRI05 ;ALLOW LTC INTERRUPTS.
5190 026172 012700 000240
5190 026172 104441
5191 026176 000004 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5191 MOV @TNUM,TSTNUM ;SET UP THE TEST NUMBER. (4)
5192 026200 012767 000004 154116 MOV @-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
5193 026206 012767 177777 154072 MOV @1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5194 026214 012767 000001 155544 MOV @EM0401,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5195 026222 012767 006737 155542 MOV @ER0201,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5196 026230 012767 016042 155536
5197 ;*
5198 ;* SET THE DUT CSR MASTER RESET (MR) BIT, PERFORM THE SKIP SELFTEST SEQUENCE,
5199 ;* AND WAIT UP TO 5 SECONDS FOR THE MR BIT TO CLEAR.
5200 ;*
5201 026236 012701 011610 MOV @5000.,R1 ;TIME OUT VALUF IS 5.0 SECONDS.
5202 026242 012702 000040 MOV @BIT05,R2 ;WAITING FOR MASTER RESET BIT.
5203 026246 005003 CLR R3 ;WAITING FOR BIT TO CLEAR.
5204 026250 016704 153766 MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
5205 026254 010214 MOV R2,(R4) ;SET THE DUT MASTER RESET BIT.
5206 026256 004767 174062 JSR PC,SKPSTS ;SKIP THE SELFTEST.
5207 026262 004767 171676 JSR PC,MSLGET ;WAIT FOR DUT CSR MR BIT TO CLEAR.
5208 026266 103015 BCC 4$ ;GO REPORT ERROR IF MR DID NOT CLEAR.
5209 ;*
5210 ;* READ 6 CHARACTERS FROM THE DUT AND VERIFY THAT THEY ARE VALID SELFTEST
5211 ;* CODES.
5212 ;*
5213 026270 012400 MOV (R4)+,R0 ;INCREMENT POINTER TO POINT TO DUT RBUF REGSTR.
5214 026272 012701 000006 MOV @6,R1 ;INITIALIZE THE LOOP COUNTER.
5215 026276 011402 2$: MOV (R4),R2 ;READ A CHARACTER FROM THE DUT RBUF REGISTER.
5216 026300 010200 MOV R2,R0
5217 026302 042700 177476 BIC @177476,R0 ;REMOVE ALL BUT BITS SPECIFIC TO SELFTEST CODE.
5218 026306 020027 000201 CMP R0,@201 ;CHECK THAT BITS 0,6, AND 7 ARE CORRECT.
5219 026312 001012 BNE 5$ ;GO REPORT ERROR IF CODE IS NOT SELFTEST CODE.
5220 026314 005301 DEC R1 ;COUNT THIS LOOP ITERATION.
5221 026316 001367 BNE 2$ ;LOOP IF NOT ALL LINES DONE.
5222 026320 000415 BR 60$ ;EXIT TEST, NO ERROR FOUND.
5223 ;*
5224 ;*
5225 ;* ERROR REPORTS:
5226 ;*
5227 ;* ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
5228 026322 012767 000621 155440 4$: MOV @0401.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5229 026330 012701 005651 MOV @EM0202,R1 ;SELECT ERROR MESSAGE.
5230 026334 026334 ERROR ;REPORT ERROR. >>>>> ERROR #0401 <<<<<
5231 026336 000406 BR 60$ ;EXIT THE TEST. TRAP C$ERROR
5232 ;*
5233 ;* ;REPORT IMPROPER CODE FOUND IN DUT RBUF AFTER RESET (SKIP SELFTEST).

```



```

5242 .SBTTL  HARDWARE TEST          RXFFDA
5243 ;* *****
5244 ;*          RBUF REGISTER RX FLAG FIELD TEST -
5245 ;*          THIS TEST VERIFIES THAT THE FIELD OF 3 FLAG BITS IN THE RBUF READS
5246 ;*          AS ALL ONES WHEN THE SELFTEST CODES ARE BEING READ FROM THE DUT
5247 ;*          AFTER A BOARD RESET AND SKIP SELFTEST SEQUENCE.
5248 ;*
5249 ;* *****
5250 BGNTST
5251 026370          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T5::
      026370 012700 000240
      026374 104441
5252          TNUM  == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
      026376 012767 000005 153720      MOV    #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (5)
5253 026404 012767 177777 153674      MOV    #-1,CTRLCF          ;INDICATE THAT WE ARE WITHIN A TEST.
5254 026412 012767 000001 155346      MOV    #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5255 026420 012767 007165 155344      MOV    #EM0501,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5256 026426 012767 016042 155340      MOV    #ER0201,ERRBLK          ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5257
5258 ;*
5259 ;* SET THE DUT CSR MASTER RESET (MR) BIT, PERFORM THE SKIP SELFTEST SEQUENCE,
5260 ;* AND WAIT UP TO 5 SECONDS FOR THE MR BIT TO CLEAR.
5261 ;
5262 026434 012701 011610          MOV    #5000.,R1          ;TIME-OUT VALUE IS 5.0 SECONDS.
5263 026440 012702 000040          MOV    #BIT05,R2          ;WAITING FOR MASTER RESET BIT
5264 026444 005003          CLR    R3          ;WAITING FOR BIT TO CLEAR.
5265 026446 016704 153570          MOV    CSRA,R4          ;BIT IS IN THE DUT'S CSR.
5266 026452 010214          MOV    R2,(R4)          ;SET THE DUT MASTER RESET BIT.
5267 026454 004767 173664          JSR    PC,SKPSTS          ;SKIP THE SELFTEST.
5268 026460 004767 171500          JSR    PC,MSLGET          ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5269 026464 103013          BCC   4$          ;GO REPORT ERROR IF MR DID NOT CLEAR.
5270
5271 ;*
5272 ;* READ 8 CHARACTERS FROM THE DUT AND VERIFY THAT ALL 3 RX ERROR FLAGS ARE
5273 ;* SET FOR EACH CHARACTERS.
5274 ;*
5274 026466 012400          MOV    (R4)+,R0          ;INCREMENT POINTER TO POINT TO DUT RBUF REGSTR.
5275 026470 012701 000010          MOV    #8.,R1          ;INITIALIZE THE LOOP COUNTER.
5276 026474 011402          2$:  MOV    (R4),R2          ;READ A CHARACTER FROM THE DUT RBUF REGISTER.
5277 026476 012700 070000          MOV    #70000,R0
5278 026502 040200          BIC   R2,R0          ;CALCULATE BIT MAP OF CLEAR RX ERROR FLAGS.
5279 026504 001012          BNE   6$          ;GO REPORT ERROR IF NOT ALL RX ERROR FLAGS SET.
5280 026506 005301          DEC   R1          ;COUNT THIS LOOP ITERATION.
5281 026510 001371          BNE   2$          ;LOOP IF NOT ALL LINES DONE.
5282 026512 000415          BR    60$          ;EXIT TEST, NO ERROR FOUND.
5283
5284 ;*
5285 ;* ERROR REPORTS:
5286 ;*
5287 ;*
5288 026514 012767 000765 155246 4$:  ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
      MOV    #0501.,ERRNBR          ;SET THE ERROR NUMBER IN ERROR TABLE.
5289 026522 012701 005651          MOV    #EM0202,R1          ;SELECT ERROR MESSAGE.
5290 026526 104460          ERROR          ;REPORT ERROR.          >>>>> ERROR #0501 <<<<<
      TRAP   C$ERROR
5291 026530 000406          BR    60$          ;EXIT THE TEST.
5292
5293 ;*
5294 026532 012767 000766 155230 6$:  ;REPORT ONE OR MORE RX ERROR FLAGS FOUND CLEAR WITH SELFTEST CODE.
      MOV    #0502.,ERRNBR          ;SET THE ERROR NUMBER IN ERROR TABLE.
    
```

111

```
5295 026540 012701 007241      MOV      #EM0502,R1      ;SELECT ERROR MESSAGE.
5296 026544      ERROR      ;REPORT ERROR.      >>>>> ERROR #0502 <<<<<
      026544 104460      TRAP      C#ERROR
5297
5298 026546      60$: SETPRI #PRI07      ;DISABLE ALL INTERRUPTS.      MOV      #PRI07,R0
      026546 012700 000340      TRAP      C#SPRI
      026552 104441
5299 026554 005067 153526      CLR      CTRLCF      ;INDICATE THAT WE COMPLETED THE TEST.
5300 026560      ENDTST
      026560 104401      L10032: TRAP      C#ETST
```

```

5302 .SBTTL  HARDWARE TEST          RDA -
5303 :* *****
5304 :*          CSR RX DATA AVAILABLE BIT TEST
5305 :*          THIS TEST VERIFIES THAT THE DUT CSR RX DATA AVAILABLE BIT IS SET BY THE
5306 :*          INCLUSION OF THE SELFTEST CODES IN THE DUT FIFO AND THAT THE BIT CLEARS
5307 :*          AFTER THE FIFO HAS BEEN EMPTIED.
5308 :*
5309 :* *****
5310 :          BGNTST
5311 :          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T6::
5312 :          MOV          #5000.,R1          ;TIME OUT VALUE IS 5.0 SECONDS.
5313 :          MOV          #BIT05,R2          ;WAITING FOR MASTER RESET BIT.
5314 :          CLR          R3          ;WAITING FOR BIT TO CLEAR.
5315 :          MOV          CSRA,R4          ;BIT IS IN THE DUT'S CSR.
5316 :          MOV          R2,(R4)          ;SET THE DUT MASTER RESET BIT.
5317 :          JSR          PC,SKPSTS          ;SKIP THE SELFTEST.
5318 :          JSR          PC,MSLGET          ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5319 :          BCC          4$          ;GO REPORT ERROR IF MR DID NOT CLEAR.
5320 :*
5321 :          ; SET THE DUT CSR MASTER RESET (MR) BIT, PERFORM THE SKIP SELFTEST SEQUENCE,
5322 :          ; AND WAIT UP TO 5 SECONDS FOR THE MR BIT TO CLEAR.
5323 :          MOV          #5000.,R1          ;TIME OUT VALUE IS 5.0 SECONDS.
5324 :          MOV          #BIT05,R2          ;WAITING FOR MASTER RESET BIT.
5325 :          CLR          R3          ;WAITING FOR BIT TO CLEAR.
5326 :          MOV          CSRA,R4          ;BIT IS IN THE DUT'S CSR.
5327 :          MOV          R2,(R4)          ;SET THE DUT MASTER RESET BIT.
5328 :          JSR          PC,SKPSTS          ;SKIP THE SELFTEST.
5329 :          JSR          PC,MSLGET          ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5330 :          BCC          4$          ;GO REPORT ERROR IF MR DID NOT CLEAR.
5331 :*
5332 :          ; CHECK THAT THE RX DATA AVATLABLE BIT IS SET.
5333 :          BIT          #BIT7,(R4)          ;TEST THE DUT RX.DATA.AVAIL BIT.
5334 :          BEQ          6$          ;GO REPORT ERROR IF BIT IS NOT SET.
5335 :*
5336 :          ; READ CHARACTERS FROM THE DUT RX FIFO AND WAIT FOR RX.DATA.AVAIL TO GO CLEAR.
5337 :          MOV          #600.,R5          ;ALLOW READING 600 CHARS BEFORE ERROR.
5338 :          MOV          R4,R3
5339 :          MOV          (R3)+,R0          ;CALCULATE THE RBUF ADDRESS.
5340 :          MOV          (R3),R0          ;READ A CHARACTER FROM THE RX FIFO.
5341 :          BIT          #BIT7,(R4)          ;TEST THE DUT RX.DATA.AVAIL BIT.
5342 :          BEQ          60$          ;EXIT TEST WITHOUT ERROR IF RX.DATA.AVAIL CLR.
5343 :          DEC          R5          ;COUNT THE CHARACTER JUST READ.
5344 :          BNE          2$          ;LOOP IF NOT TOO MANY CHARS READ FROM FIFO.
5345 :          BR          8$          ;GO REPORT ERROR IF RX.DATA.AVAIL WOULDN T CLR.
5346 :          BR          8$
5347 :*
5348 :          ; ERROR REPORTS:
5349 :          ;
5350 :          ;
5351 :          ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
5352 :          MOV          #0601.,ERRNBR          ;SET THE ERROR NUMBER IN ERROR TABLE.
5353 :          MOV          #EM0202,R1          ;SELECT ERROR MESSAGE.
5354 :          ERROR          ;REPORT ERROR.          >>>> ERROR #0601 <<<<<
5355 :          TRAP          C$ERROR

```

K11

```

5355 026730 000415          BR      60$          ;EXIT THE TEST.
5356
5357
5358 026732 012767 001132 155030 6$: ;REPORT THAT RX.DATA.AVAIL BIT WAS NDT SET AFTER A RESET COMPLETION.
5359 026740 012701 0C7637          MOV    #0602.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5360 026744          MOV    #EM0602,R1   ;SELECT ERROR MESSAGE.
104460          ERROR          ;REPORT ERROR.          >>>> ERROR #0602 <<<<<
5361 026746 000406          BR      60$          ;EXIT THE TEST.
5362
5363          ;REPORT THAT RX.DATA.AVAIL BIT COULD NOT BE CLEARED BY PURGING FIFO.
5364 026750 012767 001133 155012 8$:          MOV    #0603.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5365 026756 012701 010017          MOV    #EM0603,R1   ;SELECT ERROR MESSAGE.
5366 026762          ERROR          ;REPORT ERROR.          >>>> ERROR #0603 <<<<<
104460          TRAP    C$ERROR
5367
5368 026764          60$:  SETPRI #PRI07          .DISABLE ALL INTERRUPTS.
026764 012700 000340          MOV    #PRI07,RO
026770 104441          TRAP    C$SPRI
5369 026772 005067 153310          CLR    CTRLCF          ;INDICATE THAT WE COMPLETED THE TEST.
5370 026776          ENDTST
026776          L10033:
104401          TRAP    C$ETST
    
```

```

5372 .SBTTL  HARDWARE TEST          - RDVA -
5373 ;* *****
5374 ;*          - RBUF RX DATA VALID BIT TEST -
5375 ;*          THIS TEST VERIFIES THAT THE DUT RBUF RX DATA VALID BIT IS SET BY THE
5376 ;*          INCLUSION OF THE SELFTEST CODES IN THE DUT FIFO AND THAT THE BIT CLEARS
5377 ;*          AFTER THE FIFO HAS BEEN EMPTIED.
5378 ;*
5379 ; *****
5380 027000          BGNST
5381 027000          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T7::
      027000 012700 000240          MOV          #PRI05,R0
      027004 104441          TRAP          C$SPRI
5382          TNUM  == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5383 027006 012767 000007 153310  MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (7)
5384 027014 012767 177777 153264  MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE WITHIN A TEST.
5385 027022 012767 000001 154736  MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5386 027030 012767 010202 154734  MOV          #EM0701,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5387 027036 012767 016042 154730  MOV          #ERO201,ERRBLK          ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5388 ;*
5389 ; SET THE DUT CSR MASTER RESET (MR) BIT, PERFORM THE SKIP SELFTEST SEQUENCE,
5390 ; AND WAIT UP TO 5 SECONDS FOR THE MR BIT TO CLEAR.
5391 ;-
5392 027044 012701 011610          MOV          #5000.,R1          ;TIME-OUT VALUE IS 5.0 SECONDS.
5393 027050 012702 000040          MOV          #BIT05,R2          ;WAITING FOR MASTER RESET BIT.
5394 027054 005003          CLR          R3          ;WAITING FOR BIT TO CLEAR.
5395 027056 016704 153160          MOV          CSRA,R4          ;BIT IS IN THE DUT'S CSR.
5396 027062 010214          MOV          R2,(R4)          ;SET THE DUT MASTER RESET BIT.
5397 027064 004767 173254          JSR          PC,SKPSTS          ;SKIP THE SELFTEST.
5398 027070 004767 171070          JSR          PC,MSLGET          ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5399 027074 103012          BCC          4$          ;GO REPORT ERROR IF MR DID NOT CLEAR.
5400 ;*
5401 ; CHECK THAT THE RX DATA VALID BIT IS SET.
5402 ;-
5403 027076 012400          MOV          (R4)+,R0          ;INCREMENT POINTER TO PNT TO DUT RBUF REG.
5404 027100 005714          TST          (R4)          ;TEST THE DUT RX.DATA.VALID BIT.
5405 027102 100016          BPL          6$          ;GO REPORT ERROR IF BIT IS NOT SET.
5406 ;*
5407 ; READ CHARACTERS FROM THE DUT RX FIFO AND WAIT FOR RX.DATA.VALID TO GO CLEAR.
5408 ;-
5409 027104 012705 001130          MOV          #600.,R5          ;ALLOW READING 600 CHARS BEFORE ERROR.
5410 027110 011400          2$: MOV          (R4),R0          ;READ A CHARACTER FROM THE RX FIFO.
5411 027112 100027          BPL          60$          ;EXIT TEST WITHOUT ERROR IF BIT IS CLEAR.
5412 027114 005305          DEC          R5          ;COUNT THE CHARACTER JUST READ.
5413 027116 001374          BNE          2$          ;LOOP IF NOT TOO MANY CHARS READ FROM FIFO.
5414 027120 000416          BR          8$          ;GO REPORT ERROR IF RX.DATA.VALID WOULDN'T CLR.
5415 ;*
5416 ;*
5417 ; ERROR REPORTS:
5418 ;-
5419 ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
5420 027122 012767 001275 154640 4$: MOV          #0701.,ERRNBR          ;SET THE ERROR NUMBER IN ERROR TABLE.
5421 027130 012701 005651          MOV          #EM0202,R1          ;SELECT ERROR MESSAGE.
5422 027134          ERROR          ;REPORT ERROR.          >>>>> ERROR #0701 <<<<<
      027134 104460          TRAP          C$ERROR
5423 027136 000415          BR          60$          ;EXIT THE TEST.
5424

```

```

5425 ;REPORT THAT RX.DATA.VALID BIT WAS NOT SET AFTER A RESET COMPLETION.
5426 027140 012767 001276 154622 6$: MOV #0702.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5427 027146 012701 010245 MOV #EM0702,R1 ;SELECT ERROR MESSAGE.
5428 027152 104460 ERROR ;REPORT ERROR. >>>> ERROR #0702 <<<<<
; TRAP C#ERROR
5429 027154 000406 BR 60$ ;EXIT THE TEST.
5430
5431 ;REPORT THAT RX.DATA.VALID BIT COULD NOT BE CLEARED BY PURGING FIFO.
5432 027156 012767 001277 154604 8$: MOV #0703.,ERRNBR ;SET THE ERROR NUMBER IN ERROR TABLE.
5433 027164 012701 010425 MOV #EM0703,R1 ;SELECT ERROR MESSAGE.
5434 027170 104460 ERROR ;REPORT ERROR. >>>> ERROR #0703 <<<<<
; TRAP C#ERROR
5435
5436 027172 60$: SETPRI #PRI07 ;DISABLE ALL INTERRUPTS.
027172 012700 000340 MOV #PRI07,RO
027176 104441 TRAP C#SPRI
5437 027200 005067 153102 CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
5438 027204 L10034:
027204 104401 TRAP C#ETST

```

```

5440 .SBTTL  HARDWARE TEST          - RLNA
5441 ;* *****
5442 ;* - RBUF RX LINE NUMBER FIELD TEST
5443 ;* THIS TEST VERIFIES THAT THE DUT RBUF RX LINE NUMBER FIELD IS WORKING
5444 ;* CORRECTLY BY UTILIZING THE SELFTEST CODES WHICH ARE PUT IN THE RX
5445 ;* FIFO AFTER A BOARD RESET.
5446 ;*
5447 ;* *****
5448 027206          BGNTST
5449 027206          SEIPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T8::
027206 012700 000240          MOV          #PRI05,R0
027212 104441          TRAP          C$SPRI
000010          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5451 027214 012767 000010 153102  MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (8)
5452 027222 012767 177777 153056  MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE WITHIN A TEST.
5453 027230 012767 000001 154530  MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5454 027236 012767 010610 154526  MOV          #EM0801,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5455 ;*
5456 ; SET THE DUT CSR MASTER RESET (MR) BIT, PERFORM THE SKIP SELFTEST SEQUENCE,
5457 ; AND WAIT UP TO 5 SECONDS FOR THE MR BIT TO CLEAR.
5458 ;-
5459 027244 012701 011610          MOV          #5000.,R1          ;TIME-OUT VALUE IS 5.0 SECONDS.
5460 027250 012702 000040          MOV          #BIT05,R2          ;WAITING FOR MASTER RESET BIT.
5461 027254 005003          CLR          R3          ;WAITING FOR BIT TO CLEAR.
5462 027256 016704 152760          MOV          CSRA,R4          ;BIT IS IN THE DUT'S CSR.
5463 027262 010214          MOV          R2,(R4)          ;SET THE DUT MASTER RESET BIT.
5464 027264 004767 173054          JSR          PC,SKPSTS          ;SKIP THE SELFTEST.
5465 027270 004767 170670          JSR          PC,MSLGET          ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5466 027274 103016          BCC          4$          ;GO REPORT ERROR IF MR DID NOT CLEAR.
5467 ;*
5468 ; READ CHARACTERS FROM THE DUT RX FIFO AND VERIFY THAT THE LINE NUMBERS ARE
5469 ; CORRECT.
5470 ; EIGHT CHARACTERS ARE READ FROM THE FIFO.
5471 ;-
5472 027276 005001          CLR          R1          ;CLEAR THE LINE COUNTER.
5473 027300 012400          MOV          (R4)+,R0          ;INCREMENT POINTER TO PNT TO THE DUT RBUF REG.
5474 027302 011402          MOV          (R4),R2          ;READ A CHARACTER FROM THE DUT RX FIFO.
5475 027304 010203          MOV          R2,R3
5476 027306 000303          SWAB          R3
5477 027310 042703 177760          BIC          #177760,R3          ;REMOVE ALL BUT LINE NUMBER BITS.
5478 027314 020301          CMP          R3,R1          ;COMPARE WITH EXPECTED LINE NUMBER.
5479 027316 001017          BNE          6$          ;GO REPORT ERROR IF LINE NUMBERS DON T MATCH.
5480 027320 005201          INC          R1          ;INCREMENT THE EXPECTED LINE NUMBER.
5481 027322 020127 000010          CMP          R1,#8.          ;COMPARE NUMBER OF CODES READ WITH MAX.
5482 027326 001365          BNE          2$          ;LOOP UNTIL CODES FOR ALL LINES ARE READ.
5483 027330 000423          BR          60$          ;EXIT TEST WITHOUT ERROR.
5484
5485 ;*
5486 ; ERROR REPORTS:
5487 ;-
5488 ;REPORT MR BIT WOULD NOT CLEAR AFTER A DUT RESET.
5489 027332 012767 001441 154430 4$: MOV          #0801.,ERRNBR          ;SET THE ERROR NUMBER IN ERROR TABLE.
5490 027340 012767 016136 154426  MOV          #ER0503,ERRBLK          ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5491 027346 012701 005651          MOV          #EM0202,R1          ;SELECT ERROR MESSAGE.
5492 027352          ERROR          ;REPORT ERROR.          >>>> ERROR #0801 <<<<<
027352 104460          TRAP          C$ERROR

```



```

5505 .SBTTL  HARDWARE TEST          BMPCHK
5506 ;* .....
5507 ;*          BMP CHECK TEST
5508 ;*          THIS TEST IS USED TO VERIFY THAT THE DUT DOES NOT IMMEDIATELY FAIL
5509 ;*          THE ON-BOARD BACKGROUND-MONITOR PROGRAM, AND HENCE INVALIDATE
5510 ;*          SUCCEEDING TESTS.
5511 ;*          THIS TEST LOOKS FOR BMP CODES IN THE FIFO FOR A SET PERIOD IMMEDIATELY
5512 ;*          AFTER THE SELF TEST IS SKIPPED.
5513 ;*          ANY BMP CODES THAT ARE FOUND ARE SAVED ON THE QUEUE AND ARE ALSO
5514 ;*          REPORTED IN THIS TEST.
5515 ;*
5516 ;* .....
5517 ;*          BGNST
5518 027414          SETPRI  @PRI05          ;ALLOW LTC INTERRUPTS.          T9::
5519 027414          012700  000240          MOV          @PRI05,R0
5520 027420          104441          TRAP          C@SPRI
5521 027422          000011          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5522 027422          012767  000011  152674  MOV          @TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (9)
5523 027430          012767  177777  152650  MOV          @-1,CTRLCF          ;INDICATE THAT WE ARE WITHIN A TEST.
5524 027436          012767  000001  154322  MOV          @1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5525 027444          012767  001605  154316  MOV          @0901.,ERRNBR          ;SET THE ERROR NUMBER.
5526 027452          012767  010726  154312  MOV          @EM0901,ERRMSG          ;SET THE ERROR MESSAGE
5527 ;*
5528 ;*          WAIT UP TO 3 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
5529 ;*          IF TIME OUT OCCURS, THEN EXIT THIS TEST.
5530 027460          012701  005670          MOV          @3000.,R1          ;TIME-OUT VALUE IS 3.0 SECONDS.
5531 027464          012702  000040          MOV          @BIT05,R2          ;WAITING FOR MASTER RESET BIT.
5532 027470          005003          CLR          R3          ;WAITING FOR BIT TO CLEAR.
5533 027472          016704  152544          MOV          CSRA,R4          ;BIT IS IN THE DUT'S CSR.
5534 027476          004767  170462          JSR          PC,MSLGET          ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5535 027502          103027          BCC         50$          ;ABORT THE TEST IF MR DID NOT CLEAR.
5536 ;*
5537 ;*          RESET THE DUT, SKIP THE SELF TEST.
5538 027504          010214          MOV          R2,(R4)          ;SET THE DUT MASTER RESET BIT.
5539 027506          004767  172632          JSR          PC,SKPSTS          ;WRITE THE SKIP SELFTEST CODES TO THE DUT.
5540 ;*
5541 ;*          WAIT FOR MASTER RESET TO CLEAR. DELAY FOR 500 MILLI-SECS BEFORE PURGING
5542 ;*          THE FIFO.
5543 ;*
5544 027512          012704  000764          MOV          @500.,R4          ;TIME-OUT VALUE IS 500 MILLI SECONDS.
5545 027516          004767  170402          JSR          PC,DELAY          ;WAIT FOR BMP TO BEGIN EXECUTION.
5546 027522          004767  171014          JSR          PC,PUFIFO          ;PURGE THE FIFO, SAVING ANY BMP CODES.
5547 027526          103015          BCC         50$          ;ABORT THE TEST IF THE FIFO DID NOT CLEAR.
5548 ;*
5549 ;*          REPORT THE ERROR IF ANY BMP CODES WERE FOUND.
5550 ;*
5551 027530          016702  152770          MOV          BMPCGP,R2          ;GET THE CONTENTS OF THE POINTER TO THE BMP Q.
5552 027534          012703  002526          MOV          @BMPQ08,R3          ;GET THE START ADDRESS OF THE QUEUE.
5553 027540          020203          CMP          R2,R3          ;SEE IF THE POINTER HAS MOVED FROM THE BASE.
5554 027542          001414          BEQ          60$          ;EXIT NO CODES IN THE QUEUE.
5555 ;*
5556 ;*          THERE IS AT LEAST ONE BMP CODE IN THE QUEUE. REPORT THE ERROR.
5557 ;*
5558 ;*          ;REPORT ERROR BMP CODE FOUND IN TEST NN, BMP CODE:NNNNNN
    
```

```

5559 027544 012701 010766      MOV    #EM0902,R1      ;PASS THE MESSAGE TO BE REPORTED.
5560 027550      ERRDF  0901,EM0901,ER9301 ;>>>> ERROR #0901 <<<<<.
      027550 104455      TRAP   C#ER9F
      027552 001605      .WORD  901
      027554 010726      .WORD  EM0901
      027556 017262      .WORD  ER9301
5561 027560 000405      BR     60$
5562
5563 027562 012767 001606 154200 50$:  MOV    #902,ERRNBR    ;SET >>>> ERROR #0902 <<<<<.
5564 027570 004767 172676      JSR    PC,TSABRT     ;REPORT NON TEST RELATED ERROR.
5565
5566 027574      60$:  SETPRI #PRI07        ;DISABLE ALL INTERRUPTS.
      027574 012700 000340      MOV    #PRI07,R0
      027600 104441      TRAP   C$SPRI
5567 027602 005067 152500      CLR    CTRLCF        ;INDICATE THAT WE COMPLETED THE TEST.
5568 027606      ENDTST
      027606 104401      L10036: TRAP   C$ETST

```

```

5570
5571
5572          .SBTTL  HARDWARE TEST          - SKSELF
5573          ;* *****
5574          ;*          SKIP SELF-TEST TEST
5575          ;*          THIS TEST VERIFIES THAT THE DUT SKIPS THE SELF TEST WITHIN THE
5576          ;*          TIME ALLOWED, AND THAT THE FIFO CONTAINS THE CORRECT CODES AFTER ITS
5577          ;*          COMPLETION.
5578          ;*
5579          ;* *****
5580 027610          BGNTST
5581 027610          SETPRI  @PRI05          ;ALLOW LTC INTERRUPTS.          T10::
5582 027610          012700  000240          MOV          @PRI05,R0
5583 027614          104441          TRAP          C@SPRI
5584 027616          000012          TNUM ** TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5585 027616          012767  000012  152500  MOV          @TNUM,TSTNUM          ;SET UP THE TEST NUMBER. (10)
5586 027624          012767  177777  152454  MOV          @-1,CTRLCF          ;INDICATE THAT WE ARE WITHIN A TEST.
5587 027632          012767  000001  154126  MOV          @1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5588 027640          012767  011022  154124  MOV          @EM1001,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5589 027646          012767  016136  154120  MOV          @E0503,ERRBLK          ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5590          ;*
5591          ;*          WAIT UP TO 5 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
5592          ;*          IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
5593          ;*
5594          ;*
5595          ;*
5596          ;*
5597          ;*
5598          ;*
5599          ;*
5600          ;*          DETERMINE IF THE DUT TAKES TOO SHORT OR TOO LONG A TIME TO SKIP THE SELF-TEST
5601          ;*          SET-UP A TIME-OUT OF 50 MILLI-SECOND, IF MR IS CLEAR IN LESS THAN 10 MILLI
5602          ;*          -SECOND, OR GREATER THAN 50 MILLI SECONDS, REPORT THE ERROR.
5603          ;*
5604          ;*
5605          ;*
5606          ;*
5607          ;*
5608          ;*
5609          ;*
5610          ;*
5611          ;*          SELF-TEST COMPLETED WITHIN 10 MILLI-SEC TO 50 MILLI-SECONDS.
5612          ;*          VERIFY THAT THE SELF TEST CODES IN THE FIFO ARE "GOOD" CODES ,IE THE DUT
5613          ;*          SUCCESSFULLY COMPLETED THE SELF-TEST.
5614          ;*          THIS SUBROUTINE REPORTS ERRORS WITH NUMBERS >>>> 1003 THRU 1007 <<<<<.
5615          ;*
5616          ;*
5617          ;*
5618          ;*
5619          ;*
5620          ;*
5621          ;*
5622          ;*
5623          ;*          ERROR REPORTS:
5624          ;*
5625          ;*
5626          ;*
5627          ;*
5628          ;*
5629          ;*
5630          ;*
5631          ;*
5632          ;*
5633          ;*
5634          ;*
5635          ;*
5636          ;*
5637          ;*
5638          ;*
5639          ;*
5640          ;*
5641          ;*
5642          ;*
5643          ;*
5644          ;*
5645          ;*
5646          ;*
5647          ;*
5648          ;*
5649          ;*
5650          ;*
5651          ;*
5652          ;*
5653          ;*
5654          ;*
5655          ;*
5656          ;*
5657          ;*
5658          ;*
5659          ;*
5660          ;*
5661          ;*
5662          ;*
5663          ;*
5664          ;*
5665          ;*
5666          ;*
5667          ;*
5668          ;*
5669          ;*
5670          ;*
5671          ;*
5672          ;*
5673          ;*
5674          ;*
5675          ;*
5676          ;*
5677          ;*
5678          ;*
5679          ;*
5680          ;*
5681          ;*
5682          ;*
5683          ;*
5684          ;*
5685          ;*
5686          ;*
5687          ;*
5688          ;*
5689          ;*
5690          ;*
5691          ;*
5692          ;*
5693          ;*
5694          ;*
5695          ;*
5696          ;*
5697          ;*
5698          ;*
5699          ;*
5700          ;*
5701          ;*
5702          ;*
5703          ;*
5704          ;*
5705          ;*
5706          ;*
5707          ;*
5708          ;*
5709          ;*
5710          ;*
5711          ;*
5712          ;*
5713          ;*
5714          ;*
5715          ;*
5716          ;*
5717          ;*
5718          ;*
5719          ;*
5720          ;*
5721          ;*
5722          ;*
5723          ;*
5724          ;*
5725          ;*
5726          ;*
5727          ;*
5728          ;*
5729          ;*
5730          ;*
5731          ;*
5732          ;*
5733          ;*
5734          ;*
5735          ;*
5736          ;*
5737          ;*
5738          ;*
5739          ;*
5740          ;*
5741          ;*
5742          ;*
5743          ;*
5744          ;*
5745          ;*
5746          ;*
5747          ;*
5748          ;*
5749          ;*
5750          ;*
5751          ;*
5752          ;*
5753          ;*
5754          ;*
5755          ;*
5756          ;*
5757          ;*
5758          ;*
5759          ;*
5760          ;*
5761          ;*
5762          ;*
5763          ;*
5764          ;*
5765          ;*
5766          ;*
5767          ;*
5768          ;*
5769          ;*
5770          ;*
5771          ;*
5772          ;*
5773          ;*
5774          ;*
5775          ;*
5776          ;*
5777          ;*
5778          ;*
5779          ;*
5780          ;*
5781          ;*
5782          ;*
5783          ;*
5784          ;*
5785          ;*
5786          ;*
5787          ;*
5788          ;*
5789          ;*
5790          ;*
5791          ;*
5792          ;*
5793          ;*
5794          ;*
5795          ;*
5796          ;*
5797          ;*
5798          ;*
5799          ;*
5800          ;*
5801          ;*
5802          ;*
5803          ;*
5804          ;*
5805          ;*
5806          ;*
5807          ;*
5808          ;*
5809          ;*
5810          ;*
5811          ;*
5812          ;*
5813          ;*
5814          ;*
5815          ;*
5816          ;*
5817          ;*
5818          ;*
5819          ;*
5820          ;*
5821          ;*
5822          ;*
5823          ;*
5824          ;*
5825          ;*
5826          ;*
5827          ;*
5828          ;*
5829          ;*
5830          ;*
5831          ;*
5832          ;*
5833          ;*
5834          ;*
5835          ;*
5836          ;*
5837          ;*
5838          ;*
5839          ;*
5840          ;*
5841          ;*
5842          ;*
5843          ;*
5844          ;*
5845          ;*
5846          ;*
5847          ;*
5848          ;*
5849          ;*
5850          ;*
5851          ;*
5852          ;*
5853          ;*
5854          ;*
5855          ;*
5856          ;*
5857          ;*
5858          ;*
5859          ;*
5860          ;*
5861          ;*
5862          ;*
5863          ;*
5864          ;*
5865          ;*
5866          ;*
5867          ;*
5868          ;*
5869          ;*
5870          ;*
5871          ;*
5872          ;*
5873          ;*
5874          ;*
5875          ;*
5876          ;*
5877          ;*
5878          ;*
5879          ;*
5880          ;*
5881          ;*
5882          ;*
5883          ;*
5884          ;*
5885          ;*
5886          ;*
5887          ;*
5888          ;*
5889          ;*
5890          ;*
5891          ;*
5892          ;*
5893          ;*
5894          ;*
5895          ;*
5896          ;*
5897          ;*
5898          ;*
5899          ;*
5900          ;*
5901          ;*
5902          ;*
5903          ;*
5904          ;*
5905          ;*
5906          ;*
5907          ;*
5908          ;*
5909          ;*
5910          ;*
5911          ;*
5912          ;*
5913          ;*
5914          ;*
5915          ;*
5916          ;*
5917          ;*
5918          ;*
5919          ;*
5920          ;*
5921          ;*
5922          ;*
5923          ;*
5924          ;*
5925          ;*
5926          ;*
5927          ;*
5928          ;*
5929          ;*
5930          ;*
5931          ;*
5932          ;*
5933          ;*
5934          ;*
5935          ;*
5936          ;*
5937          ;*
5938          ;*
5939          ;*
5940          ;*
5941          ;*
5942          ;*
5943          ;*
5944          ;*
5945          ;*
5946          ;*
5947          ;*
5948          ;*
5949          ;*
5950          ;*
5951          ;*
5952          ;*
5953          ;*
5954          ;*
5955          ;*
5956          ;*
5957          ;*
5958          ;*
5959          ;*
5960          ;*
5961          ;*
5962          ;*
5963          ;*
5964          ;*
5965          ;*
5966          ;*
5967          ;*
5968          ;*
5969          ;*
5970          ;*
5971          ;*
5972          ;*
5973          ;*
5974          ;*
5975          ;*
5976          ;*
5977          ;*
5978          ;*
5979          ;*
5980          ;*
5981          ;*
5982          ;*
5983          ;*
5984          ;*
5985          ;*
5986          ;*
5987          ;*
5988          ;*
5989          ;*
5990          ;*
5991          ;*
5992          ;*
5993          ;*
5994          ;*
5995          ;*
5996          ;*
5997          ;*
5998          ;*
5999          ;*
6000          ;*

```

```

5624 027750 012701 011055      MOV    #EM1002,R1      ;SELECT ERROR MESSAGE.
5625 027754      ERROR      ;REPORT ERROR.          >>>>> ERROR #1001 <<<<<
      027754 104460      TRAP    C#ERROR
5626 027756 000414      BR     60$           ;EXIT THE TEST.
5627
5628      ;REPORT SKIP SELF TEST COMPLETED TOO SOON.
5629 027760 012767 001752 154002 4$:  MOV    #1002,ERRNBR   ;SET THE ERROR NUMBER IN THE ERROR TABLE.
5630 027766 012701 011142      MOV    #EM1003,R1     ;SELECT ERROR MESSAGE.
5631 027772      ERROR      ;REPORT ERROR.          >>>>> ERROR #1002 <<<<<
      027772 104460      TRAP    C#ERROR
5632 027774 000405      BR     60$           ;EXIT THE TEST.
5633
5634 027776 012767 001753 153764 50$:  MOV    #1003,ERRNBR   ;SET ERROR NUMBER.
5635 030004 004767 172462      JSR    PC,TSABRT     ;REPORT NON TEST RCLATED ERROR.
5636
5637 030010      60$:  SETPRI #PRI07        ;DISABLE ALL INTERRUPTS.
      030010 012700 000340      MOV    #PRI07,R0
      030014 104441      TRAP    C#SPRI
5638 030016 005067 152264      CLR    CTRLCF        ;INDICATE THAT WE COMPLETED THE TEST.
5639 030022      ENDTST
      030022 104401      L10037: TRAP    C#ETST

```

```

5641
5642
5643 .SBTTL HARDWARE TEST - DFSKST -
5644 :* *****
5645 :* - DIAGNOSTIC FAIL BIT, SKIP SELF TEST
5646 :* THIS TEST VERIFIES THAT THE DIAGNOSTIC FAIL BIT OF THE DUT, CORRECTLY
5647 :* CHANGES STATE AS THE ON-BOARDED SELFTEST IS SKIPPED.
5648 :* *****
5649 :
5650 030024 BGNTST
5651 030024 SETPRI @PRI05 ;ALLOW LTC INTERRUPTS. T11::
5652 030024 012700 000240 MOV @PRI05,R0
5653 030030 104441 TRAP C$SPRI
5654 030030 000013 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5655 030032 012767 000013 152264 MOV @TNUM,TSTNUM ;SET UP THE TEST NUMBER. (11)
5656 030040 012767 177777 152240 MOV @-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
5657 030046 012767 000001 153712 MOV @1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5658 030054 012767 011220 153710 MOV @EM1101,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5659 030062 012767 016136 153704 MOV @ER0503,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5660 :*
5661 :* WAIT UP TO 5 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
5662 :* IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
5663 :*
5664 :* MOV @5000.,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
5665 :* MOV @BIT05,R2 ;WAITING FOR MASTER RESET BIT.
5666 :* CLR R3 ;WAITING FOR BIT TO CLEAR.
5667 :* MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
5668 :* JSR PC,MSLGET ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5669 :* BCC 50$ ;ABORT THE TEST IF MR DID NOT CLEAR.
5670 :*
5671 :* RESET THE DUT, SKIP THE SELF-TEST.
5672 :*
5673 :* MOV R2,(R4) ;SET THE DUT MASTER RESET BIT.
5674 :* JSR PC,SKPSTS ;WRITE THE SKIP SELFTEST CODES TO THE DUT.
5675 :*
5676 :* SET TIME OUT OF 5 MILLI SECONDS, WAIT FOR DIAG_FAIL BIT TO SET.
5677 :* IF TIME-OUT OCCURS GO REPORT THE ERROR.
5678 :*
5679 :* MOV @5,R1 ;TIME-OUT VALUE IS 5 MILLI-SECONDS.
5680 :* MOV @BIT13,R2 ;WAITING FOR DIAGNOSTIC FAIL BIT.
5681 :* MOV R2,R3 ;WAITING FOR BIT TO SET.
5682 :* MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
5683 :* JSR PC,MSLGET ;WAIT FOR DUT_CSR_DF BIT TO CLEAR.
5684 :* BCC 4$ ;IF DIAG_FAIL DID NOT SET, GO REPORT ERROR.
5685 :*
5686 :* SET TIME-OUT OF 15 MILLI-SECS, WAIT FOR DIAG_FAIL TO CLEAR.
5687 :* IF TIME-OUT OCCURS GO REPORT THE ERROR.
5688 :* VERIFY THE DIAG_FAIL BIT IS IN A STABLE STATE BEFORE CONTINUING. LOOP
5689 :* BACK IF THE STATE WAS TRANSITORY, USING THE REMAINDER OF THE 15 MS TIME-OUT.
5690 :*
5691 :* MOV @15.,R1 ;TIME-OUT VALUE IS 15 MILLI SECONDS.
5692 :* CLR R3 ;WAITING FOR BIT TO CLEAR.
5693 :* JSR PC,MSLGET ;WAIT FOR DUT_CSR_DF BIT TO CLEAR.
5694 :* BCC 4$ ;IF DIAG_FAIL DID NOT CLEAR, GO REPORT ERRJR.
5695 :* MOV R1,R5 ;SAVE THE REMAINING TIME OUT VALUE.
    
```

```

5695 030164 012701 000001      MOV    #1,R1      ;SET TIME OUT OF 1 MILLI-SECOND.
5696 030170 052703 020000      BIS    #BIT13,R3  ;WAIT FOR BIT TO SET
5697 030174 004767 167764      JSR    PC,MSLGET  ;DOUBLE CHECK TO ELIMINATE NOISE PROBLEMS.
5698 030200 103016      BCC    60$        ;EXIT IF DIAG_FAIL BIT STILL CLEAR.
5699 030202 010501      MOV    R5,R1     ;PASS THE REMAINING TIME-OUT VALUE.
5700 030204 000762      BR     2$        ;LOOP TO CHECK AGAIN.
5701
5702      ;
5703      ; ERROR REPORTS:
5704      ;
5705 030206 012767 002115 153554 4$: ;REPORT DIAGNOSTIC FAIL BIT BAD.
5706 030214 012701 011517      MOV    #1101,ERRNBR ;SET THE ERROR NUMBER IN THE ERROR TABLE.
5707 030220 104460      MOV    #EM1205,R1  ;SELECT ERROR MESSAGE.
5708 030222 000405      ERROR                                ;REPORT ERROR. >>>>> ERROR #1101 <<<<<
5709                                TRAP    C$ERROR
5710 030224 012767 002116 153536 50$: ;EXIT THE TEST.
5711 030232 004767 172234      BR     60$
5712                                ;SET THE ERROR NUMBER FOR TSABRT RTN.
5713 030236 012700 000340      MOV    #1102,ERRNBR ;REPORT NON TEST RELATED ERROR.
5714 030242 104441      JSR    PC,TSABRT
5715 030244 005067 152036      SETPRI #PRI07     ;DISABLE ALL INTERRUPTS.
5716 030250 104401      CLR    CTRLCF     ;INDICATE THAT WE COMPLETED A TEST.
5717 030250                                MOV    #PRI07,R0
5718                                TRAP    C$SPRI
5719                                L10040:
5720                                TRAP    C$ETST

```

```

5717 .SBTTL HARDWARE TEST - SELFTS
5718 ;* *****
5719 ;* - SELF-TEST TEST -
5720 ;* THIS TEST VERIFIES THAT THE DUT'S SELF-TEST EXECUTES WITHIN THE
5721 ;* TIME ALLOWED, AND THAT THE FIFO CONTAINS THE CORRECT CODES AFTER ITS
5722 ;* COMPLETION.
5723 ;*
5724 ;* *****
5725 030252 BGNSTST
5726 030252 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS. T12::
030252 012700 000240 MOV #PRI05,R0
030256 104441 TRAP C$SPRI
5727 000014 TNUM ** TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5728 030260 012767 000014 152036 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (12)
5729 030266 012767 177777 152012 MOV #1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
5730 030274 012767 000001 153464 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE
5731 030302 012767 011273 153462 MOV #EM1201,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5732 030310 012767 016136 153456 MOV #ER0503,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5733 ;*
5734 ; WAIT UP TO 5 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
5735 ; IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
5736 ;*
5737 030316 012701 011610 MOV #5000.,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
5738 030322 012702 000040 MOV #BIT05,R2 ;WAITING FOR MASTER RESET BIT.
5739 030326 005003 CLR R3 ;WAITING FOR BIT TO CLEAR.
5740 030330 016704 151706 MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
5741 030334 004767 167624 JSR PC,MSLGET ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5742 030340 103067 BCC 50$ ;ABORT THE TEST IF MR DID NOT CLEAR.
5743 ;*
5744 ; DETERMINE IF THE SELF-TEST TAKES TOO SHORT OR TOO LONG A TIME TO COMPLETE.
5745 ; SET-UP A TIME-OUT OF 5 SECONDS, IF MR IS CLEAR IN LESS THAN 1/2 SECOND, OR
5746 ; GREATER THAN 5 SECONDS, REPORT THE ERROR.
5747 ;*
5748 030342 012701 011610 MOV #5000.,R1 ;TIME OUT VALUE IS 5.0 SECONDS.
5749 030346 010214 MOV R2,(R4) ;SET THE DUT MASTER RESET BIT.
5750 030350 004767 167610 JSR PC,MSLGET ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
5751 030354 103034 BCC 4$ ;GO REPORT ERROR SELFTEST TOOK TOO LONG.
5752 030356 012702 011610 MOV #5000.,R2
5753 030362 160102 SUB R1,R2 ;CALCULATE # OF MS SELFTEST TO COMPLETE.
5754 030364 020227 000062 CMP R2,#50.
5755 030370 002435 BLT 6$ ;SELFTEST SKIPPED? YES, GO REPORT ERROR.
5756 030372 020227 000764 CMP R2,#500.
5757 030376 002441 BLT 8$ ;GO REP ERR IF SELFTEST COMPLETED IN < 1/2 SEC.
5758 ;*
5759 ; SELF-TEST COMPLETED WITHIN 1SEC TO 5 SECONDS.
5760 ; CHECK THE STATE OF THE DIAGNOSTIC FAIL BIT, REPORT ERROR IF IT IS SET.
5761 ;*
5762 030400 032714 020000 BIT #BIT13,(R4) ;DETERMINE IF THE DIAG_FAIL BIT IS CLEAR.
5763 030404 001412 BEQ 2$ ;SKIP ERROR REPORT IF BIT IS CLEAR.
5764 ;REPORT DIAGNOSTIC FAIL BIT BAD.
5765 030406 012767 002264 153354 MOV #1204.,ERRNBR ;SET ERROR NUMBER TO IN ERROR TABLE.
5766 030414 012701 011517 MOV #EM1205,R1 ;SELECT THE ERROR MESSAGE.
5767 030420 030420 104460 ERROR ; >>>> ERROR #1204 <<<<<
TRAP C$ERROR
5768 ;*
5769 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED

```



```

5810
5811 .SBTTL HARDWARE TEST - STFAIL -
5812 :* *****
5813 :* SELF TEST FAIL TEST
5814 :* THIS TEST VERIFIES THAT THE DUT WILL REPORT SELFTEST ERRORS VIA THE
5815 :* FIFO. AND THAT THE DIAGNOSTIC FAIL BIT WILL INDICATE THE ERROR.
5816 :* THIS IS ACCOMPLISHED VIA A SOFTWARE 'HOOK' IN THE SELF-TEST, WHICH
5817 :* FORCES A "PROCI TO RAM ERROR" TO BE PLACED IN THE FIFO.
5818 :*
5819 :* - - - - -
5820 030546 BGNTST
5821 030546 T13::
030546 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS.
030546 012700 000240 MOV #PRI05,R0
030552 104441 TRAP C#SPRI
5822 000015 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5823 030554 012767 000015 151542 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (13)
5824 030562 012767 177777 151516 MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
5825 030570 012767 000001 153170 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5826 030576 012767 011543 153166 MOV #EM1301,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5827 030604 012767 016136 153162 MOV #ER0503,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
5828 030612 012767 002425 153150 MOV #1301.,ERRNBR ;SET ERROR NUMBER TO 1301.
5829
5830 ;*
5831 ; WAIT UP TO 5 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
5832 ; IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
5833
5834 030620 012701 011610 MOV #5000.,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
5835 030624 012702 000040 MOV #BIT05,R2 ;WAITING FOR MASTER RESET BIT.
5836 030630 005003 CLR R3 ;WAITING FOR BIT TO CLEAR.
5837 030636 016704 151404 MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
5838 030642 103064 JSR PC,MSLGET ;WAIT FOR DUT_CSR MR BIT TO CLEAR.
5839 BCC 50$ ;GO REPORT ERROR IF MR DID NOT CLEAR.
5840
5841 ;*
5842 ; RESET THE DUT, DELAY FOR 25 MILLI-SECONDS BEFORE WRITING THE FAIL_SELF TEST
5843 ; CODE TO TBUFFCT REGISTER ON CHANNEL 0.
5844
5845 030644 012777 000040 151370 MOV #BIT05,BCSRA ;SET DUT MASTER RESET BIT, SELECT CHANNEL 0.
5846 030652 012704 000031 MOV #25.,R4 ;PASS DELAY PERIOD OF 25 MILLI SECS.
5847 030662 012777 146314 151370 JSR PC,DELAY ;WAIT FOR SELFTEST TO INITIALISE.
5848 MOV #146314,@TXBFCA ;WRITE THE FAIL SELF-TEST CODE TO TBUFFCT REG.
5849
5850 ;*
5851 ; WAIT UP TO 5 SECONDS FOR THE SELF-TEST TO COMPLETE.
5852 ; IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
5853
5854 030670 005267 153074 INC ERRNBR ;SET ERROR NUMBER TO 1302.
5855 030674 012701 011610 MOV #5000.,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
5856 030700 012702 000040 MOV #BIT05,R2 ;PASS THE BIT MAP OF THE BIT TO TEST.
5857 030704 005003 CLR R3 ;SET UP THE EXPECTED STATE.
5858 030706 016704 151330 MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
5859 030712 004767 167246 JSR PC,MSLGET ;WAIT FOR DUT_CSR MR BIT TO CLEAR.
5860 030716 103036 BCC 50$ ;GO REPORT ERROR IF MR DID NOT CLEAR.
5861
5862 ;*
5863 ; VERIFY THE DIAGNOSTIC FAIL BIT IS SET, INDICATING THE ERROR.
5864 ; REPORT ERROR IF DIAGNOSTIC FAIL BIT IS CLEAR.
5865
5866 030720 005267 153044 INC ERRNBR ;SET ERROR NUMBER TO 1303.

```


5896
5897
5898
5899
5900
5901
5902
5903
5904
5905
5906
5907
5908
5909
5910
5911
5912
5913
5914
5915
5916
5917
5918
5919
5920
5921
5922
5923
5924
5925
5926
5927
5928
5929
5930
5931
5932
5933
5934
5935
5936
5937
5938
5939
5940
5941
5942
5943
5944
5945
5946
5947
5948
5949

031034
031034
031034 012700 000240
031040 104441
000016
031042 012767 000016 151254
031050 012767 177777 151230
031056 012767 000001 152702
031064 012767 011635 152700
031072 012767 016136 152674

031100 012701 005670
031104 012702 000040
031110 005003
031112 016704 151124
031116 004767 167042
031122 103131

031124 010214
031126 004767 171212
031132 012701 011610
031136 004767 167022
031142 103121

031144 012705 000040
031150 012703 000143
031154 010304
031156 012767 002571 152604
031164 012701 011674

031170 017702 151050
031174 100077

```
.SBTTL HARDWARE TEST ROMVER
;*****
;* - ROM VERSION TEST -
;* THIS TEST VERIFIES THAT THE DUT'S SELF-TEST PLACES VALID ROM VERSION
;* NUMBERS IN THE FIFO AFTER IT HAS BEEN SKIPPED. THE ROM VERSION NUMBERS
;* WILL BE REPORTED (ON THE FIRST PASS ONLY), IF AN AFFIRMATIVE ANSWER
;* WAS GIVEN TO THE SOFTWARE P TABLE QUESTION.
;*****
;-
BGNTST
T14::
SETPRI #PRI05 ;ALLOW LTC INTERRUPTS.
MOV #PRI05 RO
TRAP C$SPRI
TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (14)
MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV #EM1401,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
MOV #ER0503,ERRBLK ;SET ERROR ROUTINE ADDRESS IN ERROR TABLE.
;
; WAIT UP TO 3 SECONDS FOR THE DUT MASTER RESET BIT TO CLEAR.
; IF TIME-OUT OCCURS, THEN EXIT THIS TEST.
;-
MOV #3000.,R1 ;TIME-OUT VALUE IS 3.0 SECONDS.
MOV #BIT05,R2 ;WAITING FOR MASTER RESET BIT.
CLR R3 ;WAITING FOR BIT TO CLEAR.
MOV CSRA,R4 ;BIT IS IN THE DUT'S CSR.
JSR PC,MSLGET ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
BCC 50# ;ABORT THE TEST IF MR DID NOT CLEAR.
;
; SET THE MASTER RESET BIT, AND SKIP THE SELF TEST.
;-
MOV R2,(R4) ;SET THE MASTER RESET BIT.
JSR PC,SKPSTS ;SKIP THE SELF TEST.
MOV #5000.,R1 ;TIME-OUT VALUE IS 5.0 SECONDS.
JSR PC,MSLGET ;WAIT FOR DUT_CSR_MR BIT TO CLEAR.
BCC 50# ;ABORT THE TEST IF MR DID NOT CLEAR.
;
; REMOVE CHARACTERS FROM THE FIFO UNTIL EITHER;
; (A) THE FIFO IS PURGED, GO REPORT THE ERROR.
; (B) THE MAXIMUM TRY COUNTER IS ZERO, GO REPORT THE ERROR.
; (C) PROC_1'S ROM VERSION NUMBER WAS FOUND BEFORE PROC_2'S, GO REPORT ERROR.
; (D) BOTH ROM VERSION NUMBERS HAVE BEEN FOUND.
;-
MOV #32.,R5 ;SET MAXIMUM TRY COUNTER.
MOV #99.,R3 ;SET AN INVALID ROM VERSION NUMBER FOR PROC_1.
MOV R3,R4 ;SET AN INVALID ROM VERSION NUMBER FOR PROC_2.
MOV #1401.,ERRNBR ;SET THE ERROR NUMBER TO 1401.
MOV #EM1402,R1 ;SELECT MESSAGE TO BE REPORTED IF FIFO EMPTY.
2# MOV #RBUFA,R2 ;READ THE NEXT CHAR FROM THE FIFO.
BPL 12# ;GO REPORT ERROR IF FIFO EMPTY.
;
; CHECK IF THE READ DATA IS A BMP CODE.
```

```

5950
5951 031176 012700 000301      ;
5952 031202 040200      MOV     #301,R0      ;SET-UP A BIT MASK OF A BMP CODE.
5953 031204 001003      BIC     R2,R0        ;TRY TO CLEAR THE BIT MASK WITH THE READ DATA.
5954 031206 004767 171064      BNE     4$           ;BRANCH IF NOT A BMP CODE.
5955 031212 000435      JSR     PC,SAVBMP    ;SAVE THE BMP CODE ON THE QUEUE.
5956                                BR      8$           ;
5957      ;+
5958      ; CHECK IF THE READ DATA IS A SELF-TEST CODE.
5959 031214 012700 000201      4$:     MOV     #201,R0      ;SET UP A BIT MASK OF A SELFTEST CODE.
5960 031220 040200      BIC     R2,R0        ;TRY TO CLEAR THE BIT MASK WITH THE READ DATA.
5961 031222 001431      BEQ     8$           ;BRANCH IF IT IS A SELFTEST CODE.
5962
5963      ;+
5964      ; THE READ DATA IS A ROM VERSION NUMBER, DETERMINE WHICH ONE IT IS.
5965      ;-
5966 031224 032702 000002      BIT     #BIT1,R2     ;CHECK THE PROCESSOR NUMBER BIT IN THE CODE.
5967 031230 001407      BEQ     6$           ;BRANCH IF IT IS PROC_1 ROM VERSION NUMBER.
5968 031232 010204      MOV     R2,R4        ;SAVE PROC 2 ROM VERSION NUMBER.
5969 031234 042704 177603      BIC     #177603,R4   ;CLEAR ANY UNWANTED BITS.
5970 031240 000241      CLC                    ;CLEAR THE CARRY BIT.
5971 031242 006004      ROR     R4           ;SHIFT THE CODES ALONG TO GET THE ROM
5972 031244 006004      ROR     R4           ; VERSION NUMBER IN THE LOW 5 BITS.
5973 031246 000417      BR      8$           ;
5974 031250 010203      6$:     MOV     R2,R3        ;SAVE PROC_1 ROM VERSION NUMBER.
5975 031252 042703 177603      BIC     #177603,R3   ;CLEAR ANY UNWANTED BITS.
5976 031256 000241      CLC                    ;CLEAR THE CARRY BIT.
5977 031260 006003      ROR     R3           ;SHIFT THE CODE ALONG TO GET THE ROM
5978 031262 006003      ROR     R3           ; VERSION NUMBER IN THE LOW 5 BITS.
5979 031264 020427 000143      CMP     R4,#99       ;CHECK IF WE HAVE RECEIVED PROC_2 ROM CODE.
5980 031270 001016      BNE     10$          ;GO REPORT BOTH ROM VERSION NUMBERS.
5981      ;+
5982      ; RECEIVED ROM VERSION NUMBERS OUT OF SEQUENCE.
5983      ; IE, PROC_1'S ROM VERSION NUMBER FOUND IN THE FIFO BEFORE PROC_2'S.
5984      ;-
5985 031272 012701 011762      MOV     #EM1403,R1   ;SELECT THE ERROR MESSAGE TO BE REPORTED.
5986 031276 012767 002572 152464      MOV     #1402,ERRNBR ;SET THE ERROR NUMBER.
5987 031304 000433      BR      12$         ;GO REPORT ERROR.
5988
5989 031306 005305      8$:     DEC     R5           ;DECREMENT THE MAX TRY COUNTER.
5990 031310 001327      BNE     2$           ;LOOP TO GET THE NEXT CHAR FROM THE FIFO.
5991 031312 012701 012035      MOV     #EM1404,R1   ;SELECT THE ERROR MESSAGE TO BE REPORTED.
5992 031316 012767 002573 152444      MOV     #1403,ERRNBR ;SET THE ERROR NUMBER.
5993 031324 000423      BR      12$         ;GIVE UP, GO REPORT ERROR.
5994
5995      ;+
5996      ; IF THIS IS THE FIRST PASS, AND SOFTWARE P-TABLE QUESTION WAS ANSWERED YES,
5997      ; THEN REPORT THE ROM VERSION NUMBERS TO THE OPERATOR.
5998      ;-
5999 031326 032767 000001 150670      10$:    BIT     #BIT0,OPTION ;CHECK ON THE STATE OF THE SOFTWARE SWITCH.
6000 031334 001431      BEQ     60$          ;EXIT IF NO ROM VERSION PRINTOUT WAS REQUESTED.
6001 031336 026727 150750 000001      CMP     PASCNT,#1    ;CHECK IF THIS IS THE FIRST PASS.
6002 031344 003025      BGT     60$          ;EXIT IF ROM VERS HAVE ALREADY BEEN REPORTED.
6003 031346      PRINTB #EF1401,R3,R4 ;PRINT THE ROM VERSION NUMBERS.
6004 031346 010446      MOV     R4,-(SP)
6005 031350 010346      MOV     R3,-(SP)
6006 031352 012746 004154      MOV     #EF1401,-(SP)
6007 031356 012746 000003      MOV     #3,-(SP)

```

```

031362 010600
031364 104414
031366 062706 000010
6003 031372 000412 BR 60$ ;EXIT THIS TEST.
6004
6005 ;
6006 ; ERROR REPORTS:
6007 031374 012767 016254 152372 12$: MOV @ER1401,ERRBLK ;SELECT THE ERROR REPORTING ROUTINE.
6008 031402 104460 ERROR ;REPORT ERROR. >>>>> ERROR <<<<<
6009 031404 000405 BR 60$ TRAP C$ERROR
6010
6011 031406 012767 002575 152354 50$: MOV @1405.,ERRNBR ;SET UP ERROR NUMBER FOR TSABRT RTN.
6012 031414 004767 171052 JSR PC,TSABRT ;REPORT NON TEST RELATED ERROR.
6013
6014 031420 012700 000340 60$: SETPRI @PRI07 ;DISABLE ALL INTERRUPTS.
031420
031424 104441 MOV @PRI07,RO
6015 031426 005067 150654 CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
6016 031432 031432 TRAP C$SPRI
031432 104401 L10043: TRAP C$ETST

```

```

6018 .SBTTL  HARDWARE TEST          CSR84
6019 :.....
6020 :*                               CSR BIT 4 TEST
6021 :*                               THIS TEST VERIFIES THAT WHEN THIS BIT IS SET (AT THE SAME TIME
6022 :*                               AS MASTER RESET) THE OUT REMAINS INACTIVE WITH THE MASTER RESET
6023 :*                               BIT SET; AND WHEN CSR BIT 4 IS SUBSEQUENTLY CLEARED, THE BOARD
6024 :*                               BECOMES ACTIVE AND REPORTS SIX SKIP SELFTEST CODES IN THE RXFIFO.
6025 :*                               ANY BMP CODES FOUND IN THE FIFO ARE SAVED TO BE REPORTED LATER.
6026 :*
6027 :* .....
6028
6029 031434          BGNTST
6030 031434          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T15::
        031434 012700 000240          MOV          #PRI05,R0
        031440 104441          TRAP          C:SPRI
6031
6032          000017          TNUM ** TNUM + 1          ;INCREMENT THE ASSMBLY TIME TEST COUNTER.
6033 031442 012767 000017 150654          MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.
6034 031450 012767 177777 150630          MOV          # 1,CTRLCF          ;INDICATE THAT WE ARE WITHIN A TEST.
6035 031456 012767 000001 152302          MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6036 031464 012767 002735 152276          MOV          #1501.,ERRNBR          ;SET THE ERROR NUMBER TO 1501.
6037 031472 012767 012155 152272          MOV          #EM1501,ERRMSG          ;SET THE ERROR MESSAGE ADJR.
6038 031500 012767 016136 152266          MOV          #ERC503,ERRBLK          ;SET THE ERROR REPORTING ROUTINE.
6039
6040 :*
6041 :* WAIT FOR THE MASTER RESET BIT TO CLEAR. REPORT THE ERROR IF IT FAILS
6042 :* TO CLEAR.
6043 :
6044 031506 012701 011610          MOV          #5000.,R1          ;SET THE TIME-OUT VALUE OF 5 SEC.
6045 031512 012702 000040          MOV          #BIT05,R2          ;INDICATE TO TEST BIT 5.
6046 031516 005003          CLR          R3          ;INDICATE TO TEST FOR BIT CLEAR.
6047 031520 016704 150516          MOV          CSRA,R4          ;INDICATE TO TEST THE CSR REG.
6048 031524 004767 166550          JSR          PC,MSLOOP          ;WAIT FOR THE BIT TO CLEAR
6049 031530 103115          BCC          50$          ;JUMP TO REPORT ERROR IF BIT FAILED TO CLEAR.
6050
6051 :*
6052 :* SET THE MASTER RESET AND CSR BIT 4 BIT, AND THEN WAIT 5.5 SECS TO ENSURE
6053 :* THAT THE MR BIT DOESN'T CLEAR.
6054 :
6055 031532 005267 152232          INC          ERRNBR          ;SET THE ERROR NUMBER TO 1502.
6056 031536 012777 000060 150476          MOV          #60,BCSRA          ;RESET THE BOARD WITH BIT 4 SET.
6057
6058 :*
6059 :* VERIFY THAT CSR BIT 4 IS SET.
6060 :
6060 031544 017700 150472          MOV          @CSRA,R0          ;READ THE CSR.
6061 031550 032700 000020          BIT          @BIT04,R0          ;TEST BIT 4.
6062 031554 001477          BEQ          40$          ;EXIT WITH ERROR IF THE BIT IS CLEAR.
6063
6064 :*
6065 :* WAIT 5 SECONDS FOR THE MR BIT TO CLEAR.
6066 :
6067 031556 005267 152206          INC          ERRNBR          ;SET THE ERROR NUMBER TO 1503.
6068 031562 012701 012574          MOV          #5500.,R1          ;SET THE TIME-OUT VALUE OF 5.5 SECS.
6069 031566 004767 166506          JSR          PC,MSLOOP          ;WAIT FOR THE MASTER RESET BIT TO CLEAR.
6070 031572 103470          BCS          40$          ;REPORT THE ERROR IF THE MR BIT CLEARED.
6071
    
```

```

6072 ; CLEAR CSR BIT 4 AND VERIFY THAT THE MASTFR RESET BIT ALSO CLEARS.
6073 ;
074 031574 017705 150442      MOV    @CSRA,R5      ;READ THE CSR.
6075 031600 042705 000020      BIC    @BIT04,R5    ;CLEAR BIT 4.
6076 031604 010577 150432      MOV    R5,@CSRA    ;RESTORE THE CONTENTS OF THE CSR.
6077 ;
6078 ;*
6079 ;VERIFY THAT CSR BIT 4 CLFARED.
6080 031610 005267 152154      INC    ERRNBR      ;SET THE ERROR NUMBER TO 1504.
6081 031614 017705 150422      MOV    @CSRA,R5    ;READ THE CSR.
6082 031620 032705 000020      BIT    @BIT04,R5    ;TEST BIT 4
6083 031624 001053              BNE    40$         ;BRANCH AND REPORT cRROR IF SET.
6084 ;
6085 ;*
6086 ;WAIT FOR THE MR BIT TO CLEAR.
6087 031626 005267 152136      INC    ERRNBR      ;SET THE ERROR NUMBER TO 1505.
6088 031632 012701 000764      MOV    #500.,R1    ;SET A TIME-OUT OF 1/2 SECS.
6089 031636 004767 166436      JSR    PC,MSLOOP   ;WAIT FOR THE MR BIT TO CLEAR.
6090 031642 103044              BCC    40$         ;JUMP AND REPORT ERROR.
6091 ;                               ; MR BIT FAILED TO CLEAR.
6092 ;*
6093 ; READ SIX CHARACTERS FROM THE RXFIFO AND VERIFY THEY ARE SKIP SELFTEST
6094 ; CODES.  SAVE ANY BMP CODES FOUND TO BE REPORTED LATER.
6095 ;
6096 031644 012767 017126 152122  MOV    @ER9008,ERRBLK ;SET UP THE ERROR ROUTINE.
6097 031652 012701 015241      MOV    @EM9024,R1  ;SET THE ERROR MESSAGE,
6098 ;                               ; "IMPROPER SELFTEST CODE FOUND".
6099 031656 012704 000006      MOV    @6.,R4      ;SET THE NUMBER OF CHAR'S TO READ.
6100 ;
6101 031662 012767 002742 152100 2$:  MOV    #1506.,ERRNBR ;SET THE ERROR NUMBER TO 1506.
6102 031670 017702 150350      MOV    @RBUFA,R2  ;READ A CODE FROM THE RXFIFO.
6103 031674 100033              BPL    50$         ;EXIT WITH ERROR IF THE FIFO IS EMPTY.
6104 031676 010203              MOV    R2,R3      ;COPY THE CODE.
6105 031700 042703 177400      BIC    @177400,R3 ;CLEAR THE LINE NUMBER AND ERROR FLAGS.
6106 031704 012705 000301      MOV    @301,R5    ;SET THE BMP CODE MASK.
6107 031710 040305              BIC    R3,R5      ;CHECK IF THE CODE IS A BMP CODE.
6108 031712 001003              BNE    4$         ;AVOID SAVING THE BMP CODE IF IT ISN T.
6109 031714 004767 170356      JSR    PC,SAVBMP  ;SAVE THE BMP CODE.
6110 031720 000760              BR     2$         ;AVOID COUNTING THIS CODE, AND BRANCH
6111 ;                               ; TO READ MORE DATA FROM THE RXFIFO.
6112 031722 020327 000203 4$:  CMP    R3,#203    ;IS THE CODE A SKIP SELFTEST ?
6113 031726 001407              BEQ    6$         ;BRANCH TO AVOID THE ERROR IF IT IS.
6114 ;
6115 ;*
6116 ; REPORT UNEXPECTED SELFTEST CODE FOUND.
6117 ;
6117 031730 005267 152034      INC    ERRNBR      ;SET THE ERROR NUMBER TO 1507.
6118 031734 104460      ERROR ;REPORT THE ERROR.
6119 ;                               THAP    C$ERROR
6120 ;*
6121 ; IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED THEN EXIT
6122 ; THE TEST WITH THE TEST FAILURE MESSAGE.
6123 031736 032767 000100 150260  BIT    @BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
6124 031744 001411              BEQ    60$        ;EXIT THE TEST IF IT HASN'T.
6125 ;
6126 031746 005304 6$:  DEC    R4          ;DECREMENT THE CODE COUNT.
6127 031750 001344              BNE    2$         ;BRANCH AND READ ANOTHER CODE IF NOT ALL

```



```

6150 .SBTTL  HARDWARE TEST          - REGWRW
6151 ;* *****
6152 ;* - DEVICE REGISTER WORD ACCESS READ AND WRITE TEST -
6153 ;*
6154 ;* THIS TEST VERIFIES THAT THE DEVICE REGISTERS CAN BE READ AND WRITTEN
6155 ;* CORRECTLY USING WORD ACCESSES.
6156 ;*
6157 ;* - *****
6158
6159 031776          BGNST
        031776
o160 031776          SETPRI @PRIOS          ;ALLOW THE LTC TO INTERRUPT.
        032002    012700    000240          ;
        032002    104441          ;
6161          000020          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6162 032004    012767    000020    150312    MOV    @TNUM,TSTNUM          ;SET UP THE TEST NUMBER. (16)
6163 032012    012767    177777    150266    MOV    @-1,CTRLCF          ;INDICATE THAT WE ARE WITHIN A TEST.
o164 032020    012767    000001    151740    MOV    @1,ERRTYP          ;SET UP DEVICE FATAL INDICATOR IN ERROR TYPE.
6165 032026    012767    003101    151734    MOV    @1601,ERRNBR          ;SET UP ERROR NUMBER IN THE ERROR TABLE.
6166 032034    012767    012304    151730    MOV    @EM1604,ERRMSG          ;SET UP ERROR MESSAGE FOR TEST IN ERROR TABLE.
6167 032042    005067    150414          CLR    ERSMRF          ;CLEAR THE ERROR SUMMARY FLAGS.
6168 032046    012700    002464          MOV    @ERCNTB,RO
6169 032052    004767    165746          JSR    PC,CLR16W          ;CLEAR THE ERROR COUNTER TABLE.
6170 032056    005067    150222          CLR    EXOERR          ;CLEAR THE "EXIT ON ERROR" FLAG
6171 ;*
6172 ; RESET THE DUT TO A KNOWN STATE, DO NOT REMOVE THE STATUS CODES FROM THE FIFO.
6173 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6174 ; THIS SUBROUTINE REPORTS ERRORS >>>> 1601 <<<<<.
6175 ;-
6176 032062    004767    167270          JSR    PC,RESET          ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
6177 032066    103402          BCS    .+6          ;FATAL RESET ERROR? NO, CONTINUE WITH TEST.
6178 032070    000167    000142          JMP    60$          ;YES, EXIT THE TEST.
6179 ;*
6180 ; VERIFY READ/WRITE CAPABILITY TO INDIRECT ADDRESS FIELD OF CSR
6181 ;-
6182 032074    005267    151670          INC    ERRNBR          ;SET THE ERROR REPORT NUMBER TO 1602.
6183 032100    012702    000017          MOV    @17,R2          ;SET LOOP COUNT.
6184 032104    016704    150132          MOV    CSRA,R4          ;GET CSR ADDRESS.
6185 032110    010214          2$: MOV    R2,(R4)          ;WRITE COUNT TO CSR.
6186 032112    011401          MOV    (R4),R1          ;READ BACK THE CONTENTS OF THE CSR
6187 032114    042701    177760          BIC    @177760,R1          ;MASK OUT ALL BUT THE IND.ADR.REG FIELD.
6188 032120    020102          CMP    R1,R2          ;CHECK FOR CORRECT DATA WRITTEN/READ.
6189 032122    001412          BEQ    4$          ;IS EXPECTED DATA BAD? NO, SKIP ERROR REPORT.
6190          ;REPORT "BAD BIT(S) IN DEVICE CSR REGISTER FOR LINE 0(D)."
6191 032124    012767    016416    151642    MOV    @ER1601,ERRBLK          ;SELECT THE PROPER ERROR REPORT ROUTINE.
6192 032132    005003          CLR    R3          ;SET OFFSET TO 0 TO CAUSE REPORT OF CSR REG.
6193 032134    005005          CLR    R5          ;CAUSE REPORT OF LINE 0.
6194 032136          ERROR          ; >>>> ERROR @ 1602 <<<<<
        032136    104460          TRAP    C$ERROR
6195 ;*
6196 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN REQUESTED.
6197 ;
6198 032140    032767    000100    150056    BIT    @BIT06,OPTION          ;HAS EXTENDED ERROR BEEN REQUESTED ?
6199 032146    001433          BEQ    60$          ;EXIT THE TEST IF IT HASN'T.
6200
6201 032150    005302          4$: DEC    R2          ;DECREMENT LOOP COUNT/IND.ADD.REG ADDRESS.
6202 032152    002356          BGE    2$          ;LOOP BACK TO TEST NEXT ADDRESS IF NOT DONE.
    
```

```

6203
6204 ; WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL REGISTERS ON ALL
6205 ; ACTIVE LINES. BEFORE WRITING EACH PATTERN, CLEAR ALL THE BITS.
6206 ; REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1603 - 1605 <<<<.
6207 ;
6208 032154 005267 151610 INC ERRNBR ;SET THE ERROR NUMBER TO 1603.
6209 032160 005003 CLR R3 ;INDICATE THAT WORD ACCESSES ARE TO BE USED.
6210 032162 012704 000002 MOV #2,R4 ;INDICATE R/W ACCESS, CLEAR FIRST.
6211 032166 004767 166704 JSR PC,REGTST ;WRITE AND VERIFY DATA PATTERNS.
6212 ;
6213 ; EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6214 ; NOT BEEN REQUESTED, I.E. EXOERR IS NON ZERO.
6215 ;
6216 032172 005767 150106 TST EXOERR ;IS THE "EXIT ON ERROR" FLAG SET ?
6217 032176 001017 BNE 60$ ;EXIT IF IT IS.
6218 ;
6219 ; WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL REGISTERS ON ALL
6220 ; ACTIVE LINES. BEFORE WRITING EACH PATTERN, SET ALL THE BITS.
6221 ; REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1606 - 1608 <<<<.
6222 ;
6223 032200 012767 003106 151562 MOV #1606.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6224 032206 005003 CLR R3 ;INDICATE THAT WORD ACCESSES ARE TO BE USED.
6225 032210 005404 NEG R4 ;INDICATE R/W ACCESS, SET FIRST.
6226 032212 004767 166660 JSR PC,REGTST ;WRITE AND VERIFY DATA PATTERNS.
6227 ;
6228 ; EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6229 ; NOT BEEN REQUESTED, I.E. EXOERR IS NON-ZERO.
6230 ;
6231 032216 005767 150062 TST EXOERR ;IS THE "EXIT ON ERROR" FLAG SET ?
6232 032222 001005 BNE 60$ ;EXIT IF IT IS.
6233 ;
6234 ; PRINT ERROR SUMMARY REPORTS IF NECESSARY.
6235 ; THE FOLLOWING ROUTINE REPORTS ERRORS WITH NUMBER >>>> ERROR # 1609 <<<<
6236 ;
6237 032224 012767 003111 151536 MOV #1609.,ERRNBR ;SET UP ERROR NUMBER FOR NEXT RTN.
6238 032232 004767 167072 JSR PC,REPSMR ;REPORT ERROR SUMMARY IF NECESSARY.
6239 032236 005067 150044 60$: CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
6240 032242
032242
032242 104401
L10045: TRAP C$ETST
  
```

```

6242 .SBTTL  HARDWARE TEST                REGWRM
6243 ;* *****
6244 ;* - DEVICE REGISTER WORD ACCESS READ/MODIFY/WRITE TEST
6245 ;*
6246 ;* THIS TEST VERIFIES THAT THE DEVICE REGISTERS CAN BE WRITTEN CORRECTLY
6247 ;* USING WORD READ/MODIFY/WRITE ACCESSES.
6248 ;*
6249 ;* - *****
6250
6251          BGNTST
6252          SETPRI #PRIOS                ;ALLOW THE LTC TO INTERRUPT.
6253          MOV          #PRIOS,RO
6254          TRAP        C$SPRI
6255          TNUM == TNUM + 1            ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6256          MOV          #TNUM,TSTNUM  ;SET UP THE TEST NUMBER. (17)
6257          MOV          #-1,CTRLCF    ;INDICATE THAT WE ARE WITHIN A TEST.
6258          MOV          #1,ERRTYP     ;SET UP DEVICE FATAL INDICATOR IN ERROR TYPE.
6259          MOV          #1701,ERRNBR  ;SET UP ERROR NUMBER IN THE ERROR TABLE.
6260          MOV          #EM1701,ERRMSG ;SET UP ERROR MESSAGE FOR TEST IN ERROR TABLE.
6261          CLR          ERSRFR        ;CLEAR THE ERROR SUMMARY FLAGS.
6262          JSR          PC,CLR16W     ;CLEAR THE ERROR COUNTER TABLE.
6263          CLR          EXOERR        ;CLEAR THE "EXIT ON ERROR" FLAG
6264
6265 ;*
6266 ;* RESET THE DUT TO A KNOWN STATE, DO NOT REMOVE THE STATUS CODES FROM THE FIFO.
6267 ;* CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6268 ;* THIS SUBROUTINE REPORTS ERRORS >>>> 1701 <<<<.
6269 ;*
6270          JSR          PC,RESETT     ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
6271          BCS          +6            ;FATAL RESET ERROR? NO, CONTINUE WITH TEST.
6272          JMP          60$           ;YES, EXIT THE TEST.
6273
6274 ;*
6275 ;* THE READ/MODIFY/WRITE CAPABILITY TO INDIRECT ADDRESS FIELD OF CSR IS
6276 ;* NOT TESTED THIS THIS FORM OF ACCESS IS ILLEGAL.
6277 ;*
6278 ;*
6279 ;* WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL REGISTERS ON ALL
6280 ;* ACTIVE LINES USING R/M/W. BEFORE WRITING EACH PATTERN, CLEAR ALL THE BITS.
6281 ;* REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1703 - 1705 <<<<.
6282 ;*
6283          MOV          #1703,ERRNBR  ;SET THE ERROR NUMBER TO 1703.
6284          CLR          R3            ;INDICATE THAT WORD ACCESSES ARE TO BE USED.
6285          MOV          #1,R4        ;INDICATE R/M/W ACCESS, CLEAR FIRST.
6286          JSR          PC,REGTST    ;WRITE AND VERIFY DATA PATTERNS.
6287
6288 ;*
6289 ;* EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6290 ;* NOT BEEN REQUESTED, I.E. EXOERR IS NON-ZERO.
6291 ;*
6292          TST          EXOERR        ;IS THE "EXIT ON ERROR" FLAG SET ?
6293          BNE          60$           ;EXIT IF IT IS.
6294
6295 ;*
6296 ;* WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL REGISTERS ON ALL
6297 ;* ACTIVE LINES USING R/M/W. BEFORE WRITING EACH PATTERN, SET ALL THE BITS.
6298 ;* REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1706 1708 <<<<.

```

```

6296
6297 032370 012767 003252 151372 ;      MOV    #1706.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6298 032376 005003          CLR    R3      ;INDICATE THAT WORD ACCESSES ARE TO BE USED.
6299 032400 005404          NEG    R4      ;INDICATE R/M/W ACCESS, SET FIRST.
6300 032402 004767 166470    JSR    PC,REGTST ;WRITE AND VERIFY DATA PATTERNS.
6301
6302 ;*
6303 ; EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6304 ; NOT BEEN REQUESTED, I.E. EXOERR IS NON ZERO.
6305 032406 005767 147672    ; -      TST    EXOERR      ;IS THE "EXIT ON ERROR" FLAG SET ?
6306 032412 001005          BNE    60$      ;EXIT IF IT IS.
6307
6308 ;*
6309 ; PRINT ERROR SUMMARY REPORTS IF NECESSARY.
6310 ; THE FOLLOWING ROUTINE REPORTS ERRORS WITH NUMBER >>>> ERROR # 1709 <<<<
6311 ; -
6312 032414 012767 003255 151346    MOV    #1709.,ERRNBR ;SET UP ERROR NUMBER FOR NEXT RTN.
6313 032422 004767 166702    JSR    PC,REPSMR ;REPORT ERROR SUMMARY IF NECESSARY.
6314 032426 005067 147654    60$:  CLR    CTRLCF   ;INDICATE THAT WE COMPLETED THE TEST.
6315 032432          ENDTST
        032432 104401          L10046: TRAP    C#ETST

```

```

6317 .SBTTL HARDWARE TEST - REGBRW
6318 ;** *****
6319 ;* - DEVICE REGISTER BYTE ACCESS READ AND WRITE TEST -
6320 ;*
6321 ;* THIS TEST VERIFIES THAT THE DEVICE REGISTERS CAN BE READ AND WRITTEN
6322 ;* CORRECTLY USING BYTE ACCESSES.
6323 ;*
6324 ;- *****
6325
6326 BGNTST
6327 032434 SETPRI #PRIOS ;ALLOW THE LTC TO INTERRUPT. T18::
032434 MOV #PRIOS,R0
032440 104441 TRAP C$SPRI
032440 000022
6328 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6329 032442 012767 000022 147654 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (18)
6330 032450 012767 177777 147630 MOV #-1,CTRLCF ;INDICATE THAT WE ARE WITHIN A TEST.
6331 032456 012767 000001 151302 MOV #1,ERRTYP ;SET UP DEVICE FATAL INDICATOR IN ERROR TYPE.
6332 032464 012767 003411 151276 MOV #1801,ERRNBR ;SET UP ERROR NUMBER IN THE ERROR TABLE.
6333 032472 012767 012443 151272 MOV #EM1801,ERRMSG ;SET UP ERROR MESSAGE FOR TEST IN ERROR TABLE.
6334 032500 005067 147756 CLR ERSMRF ;CLEAR THE ERROR SUMMARY FLAGS.
6335 032504 012700 002464 MOV #ERCNTB,R0
6336 032510 004767 165310 JSR PC,CLR16W ;CLEAR THE ERROR COUNTER TABLE.
6337 032514 005067 147564 CLR EXOERR ;CLEAR THE "EXIT ON ERROR" FLAG.
6338 ;*
6339 ; RESET THE DUT TO A KNOWN STATE, DO NOT REMOVE THE STATUS CODES FROM THE FIFO.
6340 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6341 ; THIS SUBROUTINE REPORTS ERRORS >>>> 1801 <<<<<.
6342 ;-
6343 032520 004767 166632 JSR PC,RESETT ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
6344 032524 103402 BCS .+6 ;FATAL RESET ERROR? NO, CONTINUE WITH TEST.
6345 032526 000167 000212 JMP 60$ ;YES, EXIT THE TEST.
6346 032532 012767 003412 151230 MOV #1802,ERRNBR ;SET THE ERROR REPORT NUMBER TO 1802.
6347 ;*
6348 ; VERIFY READ/WRITE CAPABILITY TO INDIRECT ADDRESS FIELD OF CSR.
6349 ; USE BYTE ACCESSES.
6350 ;-
6351 032540 012702 000017 MOV #17,R2 ;SET LOOP COUNT.
6352 032544 016704 147472 MOV CSRA,R4 ;GET CSR ADDRESS.
6353 032550 110214 2$: MOVB R2,(R4) ;WRITE COUNT TO CSR.
6354 032552 111401 MOVB (R4),R1 ;READ BACK THE CONTENTS OF THE CSR
6355 032554 042701 177760 BIC #177760,R1 ;MASK OUT ALL BUT THE IND.ADR.REG FIELD.
6356 032560 020102 CMP R1,R2 ;CHECK FOR CORRECT DATA WRITTEN/READ.
6357 032562 001412 BEQ 4$ ;IS EXPECTED DATA BAD? NO, SKIP ERROR REPORT.
6358 ;REPORT "BAD BIT(S) IN DEVICE CSR REGISTER FOR LINE 0 (D)."
6359 032564 012767 016416 151202 MOV #ER1601,ERRBLK ;SELECT THE PROPER ERROR REPORT ROUTINE.
6360 032572 005003 CLR R3 ;SET OFFSET TO 0 TO CAUSE REPORT OF CSR REG.
6361 032574 005005 CLR R5 ;CAUSE REPORT OF LINE 0.
6362 032576 104460 ERROR ; >>>> ERROR # 1802 <<<<< TRAP C$ERROR
032576
6363 ;*
6364 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
6365 ;
6366 032600 032767 000100 147416 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6367 032606 001456 BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
6368 ;DURING THE SOFTWARE QUESTIONS.
6369

```

```

6370 032610 005302      4$:   DEC   R2           ;DECREMENT LOOP COUNT/IND.ADD.REG ADDRESS.
6371 032612 002356      BGE   2$           ;LOOP BACK TO TEST NEXT ADDRESS IF NOT DONE.
6372
6373      ; WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL LOWER BYTES OF ALL
6374      ; REGISTERS ON ALL ACTIVE LINES. USE READ/WRITE ACCESSES. BEFORE WRITING
6375      ; EACH PATTERN, CLEAR ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6376      ; REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1803 - 1805 <<<<<.
6377
6378 032614 005267 151150      INC   ERRNBR       ;SET THE ERROR NUMBER TO 1803.
6379 032620 012703 177777      MOV   #-1,R3      ;INDICATE THAT LO BYTE ACCESSES ARE TO BE USED.
6380 032624 012704 000002      MOV   #2,R4       ;INDICATE R/W ACCESS. CLEAR FIRST.
6381 032630 004767 166242      JSR   PC,REGTST   ;WRITE AND VERIFY DATA PATTERNS.
6382
6383      ; EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6384      ; NOT BEEN REQUESTED, I.E. EXOERR IS NON-ZERO.
6385
6386 032634 005767 147444      TST   EXOERR      ;IS THE "EXIT ON ERROR" FLAG SET ?
6387 032640 001041      BNE   60$        ;EXIT IF IT IS.
6388
6389      ;
6390      ; WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL HIGH BYTES OF ALL
6391      ; REGISTERS ON ALL ACTIVE LINES. USE READ/WRITE ACCESSES. BEFORE WRITING
6392      ; EACH PATTERN, CLEAR ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6393      ; REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1806 - 1808 <<<<<.
6394
6395 032642 012767 003416 151120      MOV   #1806.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6396 032650 005403      NEG   R3          ;INDICATE THAT HI BYTE ACCESSES ARE TO BE USED.
6397 032652 004767 166220      JSR   PC,REGTST   ;WRITE AND VERIFY DATA PATTERNS.
6398
6399      ; EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6400      ; NOT BEEN REQUESTED, I.E. EXOERR IS NON-ZERO.
6401
6402 032656 005767 147422      TST   EXOERR      ;IS THE "EXIT ON ERROR" FLAG SET ?
6403 032662 001030      BNE   60$        ;EXIT IF IT IS.
6404
6405      ;
6406      ; WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL LOWER BYTES OF ALL
6407      ; REGISTERS ON ALL ACTIVE LINES. USE READ/WRITE ACCESSES. BEFORE WRITING
6408      ; EACH PATTERN, SET ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6409      ; REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1809 - 1811 <<<<<.
6410
6410 032664 012767 003421 151076      MOV   #1809.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6411 032672 005403      NEG   R3          ;INDICATE THAT LO BYTE ACCESSES ARE TO BE USED.
6412 032674 005404      NEG   R4          ;INDICATE R/W ACCESS, SET FIRST.
6413 032676 004767 166174      JSR   PC,REGTST   ;WRITE AND VERIFY DATA PATTERNS.
6414
6415      ; EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6416      ; NOT BEEN REQUESTED, I.E. EXOERR IS NON-ZERO.
6417
6418 032702 005767 147376      TST   EXOERR      ;IS THE "EXIT ON ERROR" FLAG SET ?
6419 032706 001016      BNE   60$        ;EXIT IF IT IS.
6420
6421      ;
6422      ; WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL HIGH BYTES OF ALL
6423      ; REGISTERS ON ALL ACTIVE LINES. USE READ/WRITE ACCESSES. BEFORE WRITING
6424      ; EACH PATTERN, SET ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6425      ; REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1812 - 1814 <<<<<.
6426 032710 012767 003424 151052      MOV   #1812.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.

```

```

6427 032716 005403          NEG    R3          ;INDICATE THAT HI BYTE ACCESSES ARE TO BE USED.
6428 032720 004767 166152  JSR    PC,REGTST   ;WRITE AND VERIFY DATA PATTERNS.
6429
6430          ;*
6431          ; EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6432          ; NOT BEEN REQUESTED, I.E. EXOERR IS NON-ZERO.
6433 032724 005767 147354  TST    EXOERR      ;IS THE "EXIT ON ERROR" FLAG SET ?
6434 032730 001005          BNE    60$        ;EXIT IF IT IS.
6435
6436          ;*
6437          ; PRINT ERROR SUMMARY REPORTS IF NECESSARY.
6438          ; THE FOLLOWING ROUTINE REPORTS ERRORS WITH NUMBER >>>> ERROR # 1815 <<<<<
6439 032732 012767 003427 151030  MOV    #1815,ERRNBR ;SET UP ERROR NUMBER FOR NEXT RTN.
6440 032740 004767 166364          JSR    PC,REPSMR   ;REPORT ERROR SUMMARY IF NECESSARY.
6441 032744 005067 147336 60$:   CLR    CTRLCF    ;INDICATE THAT WE COMPLETED THE TEST.
6442 032750          ENDTST
        032750
        032750 104401          L10047:
                                TRAP    C$ETST

```

```

6444 .SBTTL  HARDWARE TEST          REGBRM
6445 ;+ *****
6446 ;*          - DEVICE REGISTER BYTE ACCESS READ/MODIFY/WRITE TEST
6447 ;*
6448 ;* THIS TEST VERIFIES THAT THE DEVICE REGISTERS CAN BE READ AND WRITTEN
6449 ;* CORRECTLY USING BYTE ACCESSES IN READ/MODIFY/WRITE MODE.
6450 ;*
6451 ;- *****
6452
6453 032752          BGNTST
        032752
6454 032752          SETPRI #PRI05          ;ALLOW THE LTC TO INTERRUPT.
        032752 012700 000240          T19::
        032756 104441          MOV          #PRI05,RO
        000023          TRAP          C$SPRI
6455          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6456 032760 012767 000023 147336  MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER. (19)
6457 032766 012767 177777 147312  MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE WITHIN A TEST.
6458 032774 012767 000001 150764  MOV          #1,ERRTYP          ;SET UP DEVICE FATAL INDICATOR IN ERROR TYPE.
6459 033002 012767 003555 150760  MOV          #1901,ERRNBR          ;SET UP ERROR NUMBER IN THE ERROR TABLE.
6460 033010 012767 012517 150754  MOV          #EM1901,ERRMSG          ;SET UP ERROR MESSAGE FOR TEST IN ERROR TABLE.
6461 033016 005067 147440          CLR          ERSMRF          ;CLEAR THE ERROR SUMMARY FLAGS.
        033022 012700 002464          MOV          #ERCNTB,RO
6463 033026 004767 164772          JSR          PC,CLR16W          ;CLEAR THE ERROR COUNTER TABLE.
6464 033032 005067 147246          CLR          EXOERR          ;CLEAR THE "EXIT ON ERROR" FLAG.
6465 ;+
6466 ; RESET THE DUT TO A KNOWN STATE, DO NOT REMOVE THE STATUS CODES FROM THE FIFO.
6467 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6468 ; THIS SUBROUTINE REPORTS ERRORS >>>> 1901 <<<<<.
6469 ;-
6470 033036 004767 166314          JSR          PC,RESET          ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
6471 033042 103402          BCS          +6          ;FATAL RESET ERROR? NO, CONTINUE WITH TEST.
6472 033044 000167 000136          JMP          60$          ;YES, EXIT THE TEST.
6473 033050 012767 003557 150712  MOV          #1903,ERRNBR          ;SET THE ERROR REPORT NUMBER TO 1903.
6474 ;+
6475 ; THE READ/MODIFY/WRITE CAPABILITY TO INDIRECT ADDRESS FIELD OF CSR IS NOT
6476 ; TESTED SINCE THIS IS AN ILLEGAL FORM OF ACCESS TO THIS REGISTER.
6477 ;-
6478
6479
6480 ;+
6481 ; WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL LOWER BYTES OF ALL
6482 ; REGISTERS ON ALL ACTIVE LINES. USE READ/MODIFY/WRITE ACCESSES. BEFORE
6483 ; WRITING EACH PATTERN, CLEAR ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6484 ; REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1903 - 1905 <<<<<.
6485 ;-
6486 033056 005267 150706          INC          ERRNBR          ;SET THE ERROR NUMBER TO 1903.
6487 033062 012703 177777          MOV          #-1,R3          ;INDICATE THAT LO BYTE ACCESSES ARE TO BE USED.
6488 033066 012704 000001          MOV          #1,R4          ;INDICATE R/M/W ACCESS, CLEAR FIRST.
6489 033072 004767 166000          JSR          PC,REGTST          ;WRITE AND VERIFY DATA PATTERNS.
6490 ;+
6491 ; EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6492 ; NOT BEEN REQUESTED, I.E. EXOERR IS NON-ZERO.
6493 ;-
6494 033076 005767 147202          TST          EXOERR          ;IS THE "EXIT ON ERROR" FLAG SET ?
6495 033102 001041          BNE          60$          ;EXIT IF IT IS.
6496 ;+
6497 ; WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL HIGH BYTES OF ALL
    
```



```

6498 ; REGISTERS ON ALL ACTIVE LINES. USE READ/MODIFY/WRITE ACCESSES. BEFORE
6499 ; WRITING EACH PATTERN, CLEAR ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6500 ; REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1906 - 1908 <<<<.
6501 ;
6502 033104 012767 003562 150656 ; MOV #1906.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6503 033112 005403 ; NEG R3 ;INDICATE THAT HI BYTE ACCESSES ARE TO BE USED.
6504 033114 004767 165756 ; JSR PC,REGTST ;WRITE AND VERIFY DATA PATTERNS.
6505 ;
6506 ; EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6507 ; NOT BEEN REQUESTED, I.E. EXOERR IS NON ZERO.
6508 ;
6509 033120 005767 147160 ; TST EXOERR ;IS THE "EXIT ON ERROR" FLAG SET ?
6510 033124 001030 ; BNE 60$ ;EXIT IF IT IS.
6511 ;
6512 ; WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL LOWER BYTES OF ALL
6513 ; REGISTERS ON ALL ACTIVE LINES. USE READ/MODIFY/WRITE ACCESSES. BEFORE
6514 ; WRITING EACH PATTERN, SET ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6515 ; REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1909 - 1911 <<<<.
6516 ;
6517 033126 012767 003565 150634 ; MOV #1909.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6518 033134 005403 ; NEG R3 ;INDICATE THAT LO BYTE ACCESSES ARE TO BE USED.
6519 033136 005404 ; NEG R4 ;INDICATE R/M/W ACCESS. SET FIRST.
6520 033140 004767 165732 ; JSR PC,REGTST ;WRITE AND VERIFY DATA PATTERNS.
6521 ;
6522 ; EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6523 ; NOT BEEN REQUESTED, I.E. EXOERR IS NON-ZERO.
6524 ;
6525 033144 005767 147134 ; TST EXOERR ;IS THE "EXIT ON ERROR" FLAG SET ?
6526 033150 001016 ; BNE 60$ ;EXIT IF IT IS.
6527 ;
6528 ; WRITE AND VERIFY 16 DATA PATTERNS IN ALL USED BITS OF ALL HIGH BYTES OF ALL
6529 ; REGISTERS ON ALL ACTIVE LINES. USE READ/MODIFY/WRITE ACCESSES. BEFORE
6530 ; WRITING EACH PATTERN, SET ALL THE USED BITS OF ALL ACTIVE REGISTERS.
6531 ; REGTST ROUTINE REPORTS ERRORS WITH NUMBERS >>>> ERROR 1912 - 1914 <<<<.
6532 ;
6533 033152 012767 003570 150610 ; MOV #1912.,ERRNBR ;SET UP ERROR NUMBER FOR REGTST ROUTINE.
6534 033160 005403 ; NEG R3 ;INDICATE THAT HI BYTE ACCESSES ARE TO BE USED.
6535 033162 004767 165710 ; JSR PC,REGTST ;WRITE AND VERIFY DATA PATTERNS.
6536 ;
6537 ; EXIT THE TEST IF AN ERROR HAS BEEN FOUND AND EXTENDED ERROR REPORTING HAS
6538 ; NOT BEEN REQUESTED, I.E. EXOERR IS NON-ZERO.
6539 ;
6540 033166 005767 147112 ; TST EXOERR ;IS THE "EXIT ON ERROR" FLAG SET ?
6541 033172 001005 ; BNE 60$ ;EXIT IF IT IS.
6542 ;
6543 ; PRINT ERROR SUMMARY REPORTS IF NECESSARY.
6544 ; THE FOLLOWING ROUTINE REPORTS ERRORS WITH NUMBER >>>> ERROR # 1915 <<<<
6545 ;
6546 033174 012767 003573 150566 ; MOV #1915.,ERRNBR ;SET UP ERROR NUMBER FOR NEXT RTN.
6547 033202 004767 166122 ; JSR PC,REPSMR ;REPORT ERROR SUMMARY IF NECESSARY.
6548 033206 005067 147074 60$: CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
6549 033212 ;
6550 033212 ;
6551 033212 104401 ;

```

L10050: TRAP C#ETST

```

6551 .SBTTL HARDWARE TEST - IDBIT -
6552 ;* .....
6553 ;* - DEVICE REGISTER ID BIT TEST
6554 ;*
6555 ;* THIS TEST VERIFIES THAT THE DUT STAT REGISTER ID BIT READS AS SET.
6556 ;*
6557 ;* .....
6558 ;
6559 033214 BGNTST
033214 T20::
6560 033214 SETPRI #PRIOS ;ALLOW THE LTC TO INTERRUPT.
033214 012700 000240 MOV #PRIOS,R0
033220 104441 TRAP C$SPRI
000024
6561 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6562 033222 012767 000024 147074 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (20)
6563 033230 012767 177777 147050 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
6564 033236 012767 000001 150522 MOV #1,ERRTYP ;SET UP DEVICE FATAL INDICATOR IN ERROR TYPE.
6565 033244 012767 003721 150516 MOV #2001,ERRNBR ;SET UP ERROR NUMBER IN THE ERROR TABLE.
6566 033252 012767 012602 150512 MOV #EM2001,ERRMSG ;SET UP ERROR MESSAGE FOR TEST IN ERROR TABLE.
6567 ;
6568 ; RESET THE DUT TO A KNOWN STATE, DO NOT REMOVE THE STATUS CODES FROM THE FIFO.
6569 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6570 ; THIS SUBROUTINE REPORTS ERRORS >>>> 2001 <<<<<.
6571 ;
6572 033260 004767 166072 JSR PC,RESET ;RESET THE D'UJ-11, REPORT ANY ERRORS FOUND.
6573 033264 103016 BCC 60$ ;FATAL RESET ERROR? YES, EXIT THE TEST.
6574 ;
6575 ; READ THE STAT REGISTER ID BIT AND VERIFY THAT IT IS CLEAR.
6576 ;
6577 033266 017701 146756 MOV #FSLSA,R1 ;READ THE STAT REGISTER CONTENTS.
6578 033272 032701 000400 BIT #BIT8,R1 ;CHECK THE ID BIT.
6579 033276 001011 BNE 60$ ;ID BIT SET? YES, EXIT THE TEST.
6580 033300 012767 003722 150462 MOV #2002,ERRNBR ;NO, SET THE ERROR REPORT NUMBER TO 2002.
6581 033306 012701 012652 MOV #EM2002,R1 ;GET THE PROPER ERROR MESSAGE.
6582 033312 012767 016136 150454 MOV #ER0503,ERRBLK ;SELECT THE PROPER ERROR REPORT ROUTINE.
6583 033320 ERROR ;ERROR NUMBER >>>> 2002 <<<<<
033320 104460 TRAP C$ERROR
6584 033322 005067 146760 60$: CLR CTRLCF ;INDICATE THAT WE COMPLETED THE TEST.
6585 033326 ENDTST
033326 L10051:
033326 104401 TRAP C$ETST

```

```

6587 .SBTTL HARDWARE TEST TXENBI
6588 ;* *****
6589 ;* - TX_ENABLE (INACTIVE) TEST
6590 ;* THIS TEST VERIFIES THAT WHEN THE LINE UNDER TEST'S TX_ENABLE BIT IS
6591 ;* CLEAR, TRANSMISSION WILL NOT TAKE PLACE ON THAT LINE.
6592 ;* THIS TEST IS PERFORMED IN INTERNAL LOOPBACK, AND ON ALL ACTIVE LINES.
6593 ;*
6594 ;* *****
6595 ;*
6596 033330 BGNTST
033330
0597 033330 ;ETPRI @PRI05 ;ALLOW LTC INTERRUPTS. T21::
033330 0127 0 000240 MOV @PRI05,R0
033334 104441 TRAP C$SPRI
6598 000025 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6599 033336 012767 000025 146760 MOV @TNUM,TSTNUM ;SET UP THE TEST NUMBER. (23)
6600 033344 012767 177777 146734 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
6601 033352 012767 000001 150406 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6602 033360 012767 004375 150402 MOV #2301,ERRNBR ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
6603 033366 012767 012725 150376 MOV #EM2301,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERRTABL.
6604 033374 012767 017222 150372 MOV #ER9101,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
6605 ;*
6606 ;* RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
6607 ;* CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6608 ;* THIS SUBROUTINE REPORTS ERROR >>>> 2301 <<<<<.
6609 ;*
6610 033402 004767 164374 JSR PC,CLNRST ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
6611 033406 103114 BCC 60$ ;RESET FAILURE?, ABORT THIS TEST.
6612 ;*
6613 ;* SET INTERNAL LOOPBACK ON ALL ACTIVE LINES.
6614 ;* SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
6615 ;* 2 STOP BITS.
6616 ;* ENABLE TRANSMITTERS ON ALL LINES.
6617 ;*
6618 033410 016705 146614 MOV ACTLNS,R5 ;PASS THE ACTIVE LINE BIT MAP.
6619 033414 012700 000200 MOV #200,R0 ;PASS THE LNCTRL CONTENTS.
6620 033420 004767 170126 JSR PC,WTMLNC ;INITIALISE THE LNCTRL REGISTERS.
6621 033424 012700 177670 MOV #177670,R0 ;PASS THE LPR CONTENTS.
6622 033430 004767 170146 JSR PC,WTMLPR ;INITIALISE THE LPR REGISTERS ON ALL LINES.
6623 033434 012704 000012 MOV #10,R4 ;PASS DELAY TIME OF 10 MILLI-SECONDS.
6624 033440 004767 164460 JSR PC,DELAY ;WAIT FOR LNCTR AND LPR REGS TO BE UPDATED.
6625 033444 012705 177777 MOV #MAPLNS,R5 ;PASS THE BIT MAP CORRESPONDING TO ALL LINES.
6626 033450 004767 167224 JSR PC,TXENBL ;ENABLE TRANSMITTERS ON ALL LINES.
6627 ;*
6628 ;* TEST ALL ACTIVE LINES INDIVIDUALLY.
6629 ;* DISABLE TRANSMISSION ON EACH ACTIVE LINE.
6630 ;*
6631 033454 012703 000001 MOV #1,R3 ;SET UP THE LINE BIT MAP FOR CHANNEL 0.
6632 033460 005004 CLR R4 ;CLEAR THE LINE NUMBER COUNTER.
6633 033462 012767 004376 150300 2$: MOV #2302,ERRNBR ;SET THE ERROR NUMBER TO 2302.
6634 033470 030367 146534 BIT R3,ACTLNS ;CHECK IF THE LINE IS ACTIVE.
6635 033474 001453 BEQ 68$ ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
6636 ;*
6637 ;* CLEAR THE TX_ENABLE BIT IN TBUFFAD2 REGISTER.
6638 ;* SELECT THE LINE UNDER TEST.
6639 ;* VERIFY IT IS CLEAR, REPORT ERROR IF SET.
6640 ;*

```

```

6641 033476 010305
6642 033500 004767 167100
6643 033504 010477 146532
6644 033510 005777 146542
6645 033514 100433
6646
6647
6648
6649
6650
6651 033516 012767 004377 150244
6652 033524 112777 000012 146516
6653 033532 012701 170003
6654 033536 016702 146500
6655 033542 004767 167522
6656 033546 103416
6657
6658
6659
6660 033550 005267 150214
6661 033554 012701 070012
6662 033560 016702 146456
6663 033564 004767 167500
6664 033570 103405
6665 033572 005267 150172
6666 033576 017702 146442
6667 033602 100010
6668
6669 033604 010401
6670 033606 012702 012772
6671
6672 033612
033612 104460
6673
6674 033614 032767 000100 146402
6675 033622 001406
6676
6677
6678
6679
6680
6681 033624 000241
6682 033626 006103
6683 033630 005204
6684 033632 020427 000020
6685 033636 002711
6686
6687 033640 005067 146442
6688 033644
033644
033644 104401

MOV R3,R5 ;PASS THE BIT MAP OF THE LINE UNDER TEST.
JSR PC, TXDSBL ;DISABLE TRANSMISSION ON THE LINE UNDER TEST.
MOV R4, @CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
TST @TXAD2A ;VERIFY THE TX_ENABLE BIT IS SET.
BMI 4 ;GO REPORT ERROR IF TX_ENABLE BIT SET.

;*
; WRITE DATA BYTE (ASCII <LF>) TO THE OUTPUT FIFO.
; WAIT FOR A TX_ACTION TO BE RETURNED, REPORT ERROR IF A TX_ACTION
; IS FOUND BEFORE TIME-OUT OCCURS.
;-
MOV @2303, ERRNBR ;SET ERROR NUMBER TO 2303.
MOVB @12, @DATA ;WRITE THE DATA BYTE TO THE DUT'S OUTPUT FIFO.
MOV @17003, R1 ;TEST BIT 15, TIMEOUT OF 3 MILLI SECS.
MOV CSRA, R2 ;PASS THE ADDRESS OF THE REGISTER TO TEST.
JSR PC, WAIBIS ;WAIT FOR TX_ACTION TO COME BACK.
BCS 4 ;GO REPORT ERROR IF A TX-ACTION FOUND.

;*
; WAIT FOR THE DATA TO APPEAR IN THE FIFO, REPORT ERROR IF DATA FOUND.
;-
INC ERRNBR ;SET ERROR NUMBER TO 2304.
MOV @70012, R1 ;TEST BIT 7, TIMEOUT OF 10 MILLI SECS.
MOV CSRA, R2 ;PASS THE ADDRESS OF THE REGISTER TO TEST.
JSR PC, WAIBIS ;WAIT FOR RX_DATA_AVAILABLE TO SET.
BCS 4 ;REPORT ERROR IF DATA RECEIVED IN THE FIFO.
INC ERRNBR ;SET ERROR NUMBER TO 2305.
MOV @RBUFA, R2 ;READ THE DATA FROM THE FIFO.
BPL 6 ;SKIP ERROR REPORT IF DATA ISN'T THERE.

4 ; MOV R4, R1 ;PASS THE NUMBER OF CURRENT LINE UNDER TEST.
MOV @EM2302, R2 ;PASS THE MESSAGE TO BE REPORTED.
; "TX_ENABLE BIT BAD ON LINE: NN".
; >>>> ERROR <<<<<.
; TRAP C$ERROR

BIT @BIT06, OPTION ;EXIT THE TEST, WITH THE TEST FAILED MESSAGE.
BEQ 60 ;IF EXTENDED ERROR REPORTING HAS NOT BEEN
; REQUESTED.

;*
; VERIFY ALL ACTIVE LINES HAVE BEEN TESTED.
;-
6 ; CLC ;CLEAR THE CARRY BIT PRIOR TO ROTATION.
ROL R3 ;SHIFT THE BIT MAP FOR THE NEXT LINE.
INC R4 ;INCREMENT THE LINE NUMBER COUNTER.
CMP R4, @NUMLNS ;HAVE ALL THE LINES BEEN TESTED?.
BLT 2 ;NO; BRANCH TO TEST THE NEXT LINE.

60 ; CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
ENDTST
L10052: TRAP C$ETST

```

6690
6691
6692
6693
6694
6695
6696
6697
6698
6699 033646
033646
0700 033646
033646 012700 000240
033652 104441
6701 000026
6702 033654 012767 000026 146442
6703 033662 012767 177777 146416
6704 033670 012767 000001 150070
6705 033676 012767 004541 150064
6706 033704 012767 013030 150060
6707 033712 012767 017222 150054
6708
6709
6710
6711
6712
6713 033720 004767 164056
6714 033724 103133
6715
6716
6717
6718
6719
6720
6721 033726 016705 146276
6722 033732 012700 000200
6723 033736 004767 167610
6724 033742 012700 177670
6725 033746 004767 167630
6726 033752 012704 000012
6727 033756 004767 164142
6728 033762 012705 177777
6729 033766 004767 166612
6730
6731
6732
6733
6734 033772 012703 000001
6735 033776 005004
6736 034000 012767 004542 147762 2:
6737 034006 030367 146216
6738 034012 001467
6739
6740
6741
6742
6743

```

.SBTTL  HARDWARE TEST          TXENBA-
;... *****
; TX_ENABLE (ACTIVE) TEST
; THIS TEST VERIFIES THAT WHEN THE TX_ENABLE BIT IS SET IN THE APPROPRIATE
; LINE REGISTER, TRANSMISSION WILL TAKE PLACE ON THAT LINE.
; THIS TEST IS PERFORMED IN INTERNAL LOOPBACK, AND ON ALL ACTIVE LINES.
;... *****
;-- *****

BGNTST
                                T22::
SETPRI  #PRIOS                ;ALLOW LTC INTERRUPTS.
                                MOV    #PRIOS,R0
                                TRAP   C$SPRI

6701  TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6702  MOV  #TNUM,T$TNUM         ;SET UP THE TEST NUMBER. (24)
6703  MOV  #1,CTRLCF           ;INDICATE THAT WE ARE IN A TEST.
6704  MOV  #1,ERRTP            ;SET ERPOP TYPE AS FATAL IN ERROR TABLE.
6705  MOV  #2401,ERRNBR       ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
6706  MOV  #EM2401,ERRMSG     ;SET ERROR MESSAGE ADDRESS IN ERRTABL.
6707  MOV  #ER9101,ERRBLK     ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
;+
; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 2401 <<<<<.
;--
6713  JSR  PC,CLNRST           ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
6714  BCC  60$                ;RESET FAILURE?, ABORT THIS TEST.
;+
; SET INTERNAL LOOPBACK ON ALL ACTIVE LINES.
; SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
; 2 STOP BITS.
; DISABLE TRANSMITTERS ON ALL LINES.
;--
6721  MOV  ACTLNS,R5           ;PASS THE ACTIVE LINE BIT MAP.
6722  MOV  #200,R0            ;PASS THE LNCTRL CONTENTS.
6723  JSR  PC,WTLNLC          ;INITIALISE THE LNCTRL REGISTERS.
6724  MOV  #177670,R0        ;PASS THE LPR CONTENTS.
6725  JSR  PC,WTLPR          ;INITIALISE THE LPR REGISTERS ON ALL LINES.
6726  MOV  #10,R4            ;PASS DELAY TIME OF 10 MILLI-SECONDS.
6727  JSR  PC,DELAY          ;WAIT FOR LNCTR AND LPR REGS TO BE UPDATED.
6728  MOV  #MAPLNS,R5        ;PASS THE BIT MAP CORRESPONDING TO ALL LINES.
6729  JSR  PC,TXDSBL        ;DISABLE TRANSMITTERS ON ALL LINES.
;+
; TEST ALL ACTIVE LINES INDIVIDUALLY.
; ENABLE TRANSMISSION ON EACH ACTIVE LINE.
;--
6734  MOV  #1,R3              ;SET UP THE LINE BIT MAP FOR CHANNEL 0.
6735  CLR  R4                 ;CLEAR THE LINE NUMBER COUNTER.
6736  MOV  #2402,ERRNBR      ;SET THE ERROR NUMBER TO 2402.
6737  BIT  R3,ACTLNS         ;CHECK IF THE LINE IS ACTIVE.
6738  BEQ  8$                ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
;+
; SELECT THE LINE UNDER TEST.
; SET THE TX_ENABLE BIT IN T$BUFFAD2 REGISTER.
; VERIFY IT IS SET, REPORT ERROR IF CLEAR.
;

```

```

6744 034014 010305          MOV      R3,R5          ;PASS THE BIT MAP OF THE LINE UNDER TEST.
6745 034016 004767 166656   JSR      PC,TXENBL      ;ENABLE TRANSMISSION ON THE LINE UNDER TEST.
6746 034022 012705 000012   MOV      #10.,R5       ;SET TXCHAR/LOOP COUNT TO 10.
6747 034026 010477 146210   MOV      R4,@CSRA      ;SELECT THE LINE CURRENTLY UNDER TEST.
6748 034032 005777 146220   TST     @TXAD2A        ;VERIFY THE TX_ENABLE BIT IS SET.
6749 034036 100045          BPL      6$            ;GO REPORT ERROR IF TX_ENABLE BIT CLEAR.
6750                                     ;*
6751                                     ; WRITE DATA BYTE (ASCII <LF>) TO OUTPUT FIFO.
6752                                     ; WAIT FOR A TX ACTION TO BE RETURNED, REPORT ERROR IF NO TX ACTION
6753                                     ; FOUND BEFORE TIME OUT OCCURS.
6754                                     ;-
6755 034040 012767 004543 147722 4$:  MOV      #2403.,ERRNBR  ;SET ERROR NUMBER TO 2403.
6756 034046 112777 000012 146174   MOVVB   #12,@FDATA     ;WRITE THE DATA BYTE TO THE DUT'S OUTPUT FIFO.
6757 034054 012701 170004   MOV      #170004,R1    ;TEST BIT 15, TIMEOUT OF 4 MILLI SECS.
6758 034060 016702 146156   MOV      CSRA,R2       ;PASS THE ADDRESS OF THE REGISTER TO TEST.
6759 034064 004767 167200   JSR      PC,WAIBIS     ;WAIT FOR TX ACTION TO COME BACK.
6760 034070 103030          BCC      6$            ;GO REPORT ERROR IF NO TX ACTION FOUND.
6761                                     ;*
6762                                     ; WAIT FOR THE DATA TO APPEAR IN THE FIFO, REPORT ERROR IF TIME-OUT.
6763                                     ;-
6764 034072 005267 147672   INC      ERRNBR        ;SET ERROR NUMBER TO 2404.
6765 034076 012701 070012   MOV      #70012,R1    ;TEST BIT 7, TIMEOUT OF 10 MILLI SECS.
6766 034102 016702 146134   MOV      CSRA,R2       ;PASS THE ADDRESS OF THE REGISTER TO TEST.
6767 034106 004767 167156   JSR      PC,WAIBIS     ;WAIT FOR RX DATA AVAILABLE TO SET.
6768 034112 103017          BCC      6$            ;REPORT ERROR IF NO DATA RECEIVED IN THE FIFO.
6769 034114 005267 147650   INC      ERRNBR        ;SET ERROR NUMBER TO 2405.
6770 034120 017702 146120   MOV      @RBUFA,R2    ;READ THE DATA FROM THE FIFO.
6771 034124 100012          BPL      6$            ;GO REPORT ERROR IF THER IS'NT ANY DATA THERE.
6772 034126 005267 147636   INC      ERRNBR        ;SET ERROR NUMBER TO 2406.
6773 034132 000302          SWAB    R2             ;PUT THE LINE NUMBER IN THE LOW BYTE.
6774 034134 042702 177760   BIC     #177760,R2    ;CLEAR THE UNWANTED BITS.
6775 034140 020204          CMP     R2,R4          ;DID THE DATA COME FROM THE CORRECT LINE?.
6776 034142 001003          BNE     6$            ;NO; GO REPORT THE ERROR.
6777 034144 005305          DEC     R5             ;DECREMENT THE TXCHAR/LOOP COUNTER.
6778 034146 001334          BNE     4$            ;LOOP TO TX THE NEXT CHAR.
6779 034150 000410          BR      8$            ;GO TEST THE NEXT LINE.
6780
6781 034152 010401          6$:  MOV      R4,R1          ;PASS THE NUMBER OF CURRENT LINE UNDER TEST.
6782 034154 012702 012772   MOV      #EM2302,R2    ;PASS THE MESSAGE TO BE REPORTED.
6783                                     ; "TX_ENABLE BIT BAD ON LINE: NN".
6784 034160          ERROR          ; >>>> ERROR <<<<<.
6785 034160 104460          TRAP    C$ERROR
6786 034162 032767 000100 146034   BIT     @BIT06,OPTION  ;EXIT THE TEST IF EXTENDED ERROR REPORTING
6787 034170 001411          BEQ     60$           ;HAS NOT BEEN ENABLED, SINCE THE TEST HAS FAILED.
6788
6789                                     ;*
6790                                     ; VERIFY ALL ACTIVE LINES HAVE BEEN TESTED.
6791                                     ;-
6792 034172 010305          8$:  MOV      R3,R5          ;PASS THE BIT MAP OF THE LINE UNDER TEST.
6793 034174 004767 166404   JSR      PC,TXDSBL     ;CLEAR THE TX_ENABLE BIT ON THIS LINE.
6794 034200 000241          CLC                                     ;CLEAR THE CARRY BIT PRIOR TO ROTATION.
6795 034202 006103          ROL     R3             ;SHIFT THE BIT MAP FOR THE NEXT LINE.
6796 034204 005204          INC     R4             ;INCREMENT THE LINE NUMBER COUNTER.
6797 034206 020427 000020   CMP     R4,#NUMLNS     ;HAVE ALL THE LINES BEEN TESTED?.
6798 034212 002672          BLT     2$            ;NO; BRANCH TO TEST THE NEXT LINE.
6799

```

6800 034214 005067 :46066
6801 034220
034220
034220 104401

604: CLR CTRLCF
ENDTST

;INDICATE THAT WE ARE NOT WITHIN A TEST.

L10053: TRAP C#ETST

```

6803 .SBTTL  HARDWARE TEST - INTA
6804 ;* *****
6805 ;* - INTERRUPT TEST -
6806 ;* THIS TEST VERIFIES THAT THE DEVICE UNDEP TEST (DUT) WILL GENERATE
6807 ;* RECEPTION AND TRANSMISSION INTERRUPTS CORRECTLY. THIS TEST DOES
6808 ;* NOT DEPEND ON THE USE OF THE SERIAL LINE TRANSMISSION OR RECEPTION
6809 ;* CAPABILITIES OF THE DUT. THE LINES ARE PUT IN INTERNAL LOOPBACK
6810 ;* TO MINIMIZE ANY EXTERNAL EFFECTS THAT COULD BE CAUSED ON DEVICES
6811 ;* ATTACHED TO THE SERIAL LINES.
6812 ;*
6813 ;* *****
6814 ;*
6815 034222 BGNTST
034222
6816 034222 SETPRI @PRI05 ;ALLOW THE LTC TO INTERRUPT.
034222 012700 000240
034222 104441
034222 000027
6817 000027 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6818 034230 012767 000027 146066 MOV @TNUM,TSTNUM ;SET UP THE TEST NUMBER. (26)
6819 034236 012767 177777 146042 MOV @-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
6820 034244 012767 000001 147514 MOV @1,ERRTYP ;SET ERROR FATAL ERROR TYPE IN ERROR TABLE.
6821 034252 012767 003101 147510 MOV @1601.,ERRNBR ;SET FIRST ERROR REPORT NUMBER IN ERROR TABLE.
6822 034260 012767 013073 147504 MOV @EM2601.,ERRMSG ;SET TEST ERROR MESSAGE IN ERROR TABLE.
6823 ;*
6824 ;* RESET THE DUT TO A KNOWN STATE, DO NOT REMOVE THE STATUS CODES FROM THE FIFO.
6825 ;* CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6826 ;* THIS SUBROUTINE REPORTS ERRORS FROM >>>> 2601 THRU 2602 <<<<<.
6827 ;*
6828 034266 004767 165064 JSR PC,RESETT ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
6829 034272 103402 BCS 2$ ;SKIP AROUND ABORTING TEST IF NO ERROR FOUND.
6830 034274 000167 001044 JMP 60$ ;ABORT TEST IF FATAL ERROR FOUND DURING RESET.
6831 034300 012767 005053 147462 2$: MOV @2603.,ERRNBR ;SET THE ERROR REPORT NUMBER TO 2603.
6832 ;*
6833 ;* ENABLE TRANSMITTERS ON ALL LINES.
6834 ;*
6835 034306 012705 177777 4$: MOV @MAPLNS,R5 ;PASS ACTIVE LINE BIT MAP.
6836 034312 004767 166362 JSR PC,TXENBL ;ENABLE TRANSMISSION ON ALL LINES.
6837 ;*
6838 ;* TEST RECEPTION INTERRUPTS.
6839 ;* SET UP FOR RX AND TX INTERRUPTS:
6840 ;* RX INTERRUPT SERVICE ROUTINE INPUTS A CHAR AND COUNTS THE INTERRUPT.
6841 ;* TX INTERRUPT SERVICE ROUTINE COUNTS TX INTERRUPTS.
6842 ;*
6843 034316 005067 145772 CLR RXINTC ;CLEAR THE RX INTERRUPT COUNTER.
6844 034322 005067 145770 CLR RXINTF ;CLEAR THE RX INTERRUPT FLAGS.
6845 034326 005067 145774 CLR TXINTC ;CLEAR THE TX INTERRUPT COUNTER.
6846 034332 012767 002726 145742 MOV @BUFBAS,BUFPTR ;LOAD THE BUFFER PTR WITH THE BUFFER BASE ADR.
6847 034340 012746 000300 SETVEC RXVECA,@RXINPT,@PRI06 ;SET UP INTERRUPT VECTOR TO CATCH RX INT.
034340 012746 024036 MOV @PRI06,-(SP)
034344 012746 024036 MOV @RXINPT,-(SP)
034350 016746 145656 MOV RXVECA,-(SP)
034354 012746 000003 MOV @3,(SP)
034360 104437 TRAP C$SVEC
034362 062706 000010 ADD @10,SF
6848 034366 012746 000300 SETVEC TXVECA,@CACHTX,@PRI06 ;SET UP INTERRUPT VECTOR TO CATCH TX INT.
034366 012746 023660 MOV @PRI06,-(SP)
034372 012746 023660 MOV @CACHTX,(SP)

```



```

034376 016746 145632
034402 012746 000003
034406 104437
034410 062706 000010
6849 034414 SETPRI @PRI04 ;ALLOW DEVICE INTERRUPTS.
034414 012700 000200
034420 104441
6850 ;*
6851 ;ENABLE RECEPTION INTERRUPTS.
6852 ;DELAY 4 MS TO ALLOW TIME FOR THE INTERRUPTS TO TAKE PLACE.
6853 ;DISABLE RECEPTION INTERRUPTS.
6854 ;-
6855 034422 004767 165624 JSR PC,RXIE1 ;ENABLE THE RECEPTION INTERRUPTS.
6856 034426 012704 000004 MOV #4,R4 ;PASS 4 MS COUNT TO THE DELAY ROUTINE.
6857 034432 004767 163466 JSR PC,DELAY ;DELAY 4 MILLI SECONDS.
6858 034436 004767 165550 JSR PC,RXIE0 ;DISABLE RECEPTION INTERRUPTS.
6859 ;*
6860 ; VERIFY THAT THE CORRECT INTERRUPTS TOOK PLACE.
6861 ; TEST THE INT COUNTER TO VERIFY THAT INTERRUPTS TOOK PLACE.
6862 ;-
6863 034442 005767 145646 TST RXINTC ;CHECK THE RX INTERRUPT COUNT.
6864 034446 001017 BNE 6$ ;SKIP THE FOLLOWING ERRORS IF COUNT <> 0.
6865 ;*
6866 ; DETERMINE REASON FOR NO RX INTERRUPTS AND PRINT PROPER ERROR MESSAGE.
6867 ;-
6868 034450 012701 013310 MOV #EM2604,R1 ;SET UP MSG IN CASE "RX.DATA.AVAIL IS CLR".
6869 034454 032777 000200 145560 BIT #BIT7,@CSRA ;TEST THE RX.DATA.AVAIL BIT OF THE CSR.
6870 034462 001416 BEQ 8$ ;GO REPORT ERROR IF RX.DATA.AVAIL IS CLR.
6871 034464 012701 013222 MOV #EM2603,R1 ;SET UP MSG IN CASE "DATA.VALID IS CLEAR".
6872 034470 032777 100000 145546 BIT #BIT15,@RBUFA ;TEST THE DATA.VALID BIT OF THE FIFO.
6873 034476 001410 BEQ 8$ ;GO REPORT ERROR IF DATA.VALID IS CLEAR.
6874 034500 012701 013131 MOV #EM2602,R1 ;SET UP MSG,"DATA.VALID IS SET".
6875 034504 000405 BR 8$ ;GO REPORT THE ERROR.
6876 ;*
6877 ; IF RX INTS OCCURRED WITH RX.DATA.AVAIL CLEAR, REPORT THE ERROR.
6878 ;-
6879 034506 005767 145604 6$: TST RXINTF ;CHECK THE RX INTERRUPT FLAGS.
6880 034512 100014 BPL 10$ ;SKIP THE ERROR IF FLAG IS CLEAR.
6881 034514 012701 013404 MOV #EM2605,R1 ;SET UP THE PROPER MESSAGE.
6882 ;*
6883 ; REPORT THE ERROR WHICH HAS BEEN FOUND.
6884 ;-
6885 034520 8$: ERRDF 2603,EM2601,ER0503; >>>>> ERROR #2603 <<<<<.
034520 104455 TRAP C#ERDF
034522 005053 .WORD 2603
034524 013073 .WORD EM2601
034526 016136 .WORD ER0503
6886 ;*
6887 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
6888 ;-
6889 ;*
6890 ; EXIT WITH TEST FAILURE MESSAGE IF
6891 034530 032767 000100 145466 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6892 034536 001002 BNE .+6 ;
6893 034540 000167 000556 JMP 34$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
6894 ;*
6895 ;*

```

```

6896 ; VERIFY THAT NO TX INTERRUPTS HAVE BEEN GENERATED SO FAR IN THIS TEST.
6897 ;
6898 034544 016702 145556 10$: MOV TXINTC,R2 ;LOAD # OF TX INTERRUPTS FOR ERO504 RTN.
6899 034550 001414 BEQ 12$ ;SKIP ERROR IF NO TX INTERRUPTS.
6900 ;REPORT "TX INTERRUPTS(S) RECEIVED WITH TX INTERRUPTS DISABLED."
6901 034552 012701 007505 MOV #EM0526,R1 ;SET UP MESSAGE ADR FOR INDIRECT PRINT.
6902 034556 ERDF 2604,EM2601,ER0504; >>>> ERROR #2604 <<<<.
        034556 104455 TRAP C$ERDF
        034560 005054 .WORD 2604
        034562 013073 .WORD EM2601
        034564 016174 .WORD ERO504

6903 ;
6904 ;
6905 ;+
6906 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
6907 ;
6908 034566 032767 000100 145430 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6909 034574 001002 BNE .+6 ;
6910 034576 000167 000520 JMP 34$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED

6911 ;
6912 ;+
6913 ; CLEAN OUT THE INTERRUPT VECTORS USED IN THIS TEST.
6914 ;
6915 034602 12$: SETPRI #PRI06 ;DISABLE DEVICE INTERRUPTS.
        034602 012700 000300 MOV #PRI06,R0
        034606 104441 TRAP C$SPRI
6916 034610 CLRVEC RXVECA ;RETURN RX INT VECTOR TO UNUSED POOL.
        034610 016700 145416 MOV RXVECA,R0
        034614 104436 TRAP C$CVEC
6917 034616 CLRVEC TXVECA ;RETURN TX INT VECTOR TO UNUSED POOL.
        034616 016700 145412 MOV TXVECA,R0
        034622 104436 TRAP C$CVEC

6918 ;+
6919 ; TEST TRANSMISSION INTERRUPTS.
6920 ; SET UP FOR RX AND TX INTERRUPTS:
6921 ; RX INTERRUPT SERVICE ROUTINE COUNTS RX INTERRUPTS.
6922 ; TX INTERRUPT SERVICE ROUTINE COUNTS THE INTERRUPT AND SETS FLAGS.
6923 ;
6924 034624 005067 145464 CLR RXINTC ;CLEAR THE RX INTERRUPT COUNTER.
6925 034630 005067 145472 CLR TXINTC ;CLEAR THE TX INTERRUPT COUNTER.
6926 034634 005067 145470 CLR TXINTF ;CLEAR THE RX INTERRUPT FLAGS.
6927 034640 SETVEC RXVECA,#CACHRX,#PRI06 ;SET UP INTERRUPT VECTOR TO CATCH RX INT.
        034640 012746 000300 MOV #PRI06,-(SP)
        034644 012746 023632 MOV #CACHRX,-(SP)
        034650 016746 145356 MOV RXVECA,-(SP)
        034654 012746 000003 MOV #3,(SP)
        034660 104437 TRAP C$SVEC
        034662 062706 000010 ADD #10,SP
6928 034666 SETVEC TXVECA,#TXINTR,#PRI06 ;SET UP INT VECTOR TO TX INT ROUTINE.
        034666 012746 000300 MOV #PRI06,-(SP)
        034672 012746 024146 MOV #TXINTR,(SP)
        034676 016746 145332 MOV TXVECA,-(SP)
        034702 012746 000003 MOV #3,-(SP)
        034706 104437 TRAP C$SVEC
        034710 062706 000010 ADD #10,SP
6929 034714 SETPRI #PRI04 ;ALLOW DEVICE INTERRUPTS.
        034714 012700 000200 MOV #PRI04,R0

```

```

034720 104441 TRAP C$SPRI
6930
6931 ;*
6932 ; VERIFY THAT THE TX_ACTION BIT IS CLEAR.
6933 034722 012705 000022 MOV #18.,R5 ;INITIALIZE THE LOOP COUNTER.
6934 034726 012701 000144 MOV #100.,R1 ;SET 100 MS TIME OUT.
6935 034732 012702 100000 MOV #BIT15,R2 ;SELECT TX_ACTION BIT TO TEST.
6936 034736 016704 145300 MOV CSRA,R4 ;PASS OUT CSR AS THE WORD TO TEST.
6937 034742 012703 100000 14$: MOV #BIT15,R3 ;WAIT FOR TX_ACTION TO BE SET.
6938 034746 004767 163326 JSR PC,MSLOOP ;WAIT UP TO 100 MS FOR TX_ACTION SET.
6939 034752 103026 BCC 20$ ;IF TIME-OUT, CONSIDER TX_ACTION CLEAR.
6940 034754 005003 CLR R3 ;NOW, WAIT FOR TX_ACTION CLEAR.
6941 034756 004767 163316 JSR PC,MSLOOP ;WAIT UP TO 100 MS FOR TX_ACTION CLEAR.
6942 034762 103005 BCC 16$ ;IF TIME-OUT, REPORT TX_ACTION WON'T CLEAR.
6943 034764 005305 DEC R5 ;DECREMENT THE TX_ACTION SET COUNTER.
6944 034766 001365 BNE 14$ ;LOOP IF NOT TOO MANY TX_ACTIONS FOUND.
6945 ;REPORT "TX_ACTION SET REPEATEDLY AFTER RESET, NO DATA SENT."
6946 034770 012701 013526 MOV #EM2607,R1 ;SELECT ERROR MESSAGE.
6947 034774 000402 BR 18$ ;GO TO REPORT THE ERROR.
6948 034776 012701 013622 16$: MOV #EM2608,R1 ;SELECT TX ACTION STUCK SET MSG.
6949 035002 013622 18$: ERRDF 2605,EM2606,ER0503; >>>> ERROR #2605 <<<<<.
035002 104455 TRAP C$ERDF
035004 005055 .WORD 2605
035006 013467 .WORD EM2606
035010 016136 .WORD ER0503
6950
6951 ;*
6952 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABL=0
6953 ;-
6954 035012 032767 000100 145204 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6955 035020 001540 BEQ 34$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
6956 035022 004767 166006 JSR PC,TXIE1 ;ENABLE TX INTERRUPTS FOR THE TX_INT TESTING.
6957 035026 000430 BR 24$ ;GO TO TEST WITH TX_ACTION SET.
6958
6959 ;*
6960 ; VERIFY THAT NO INTERRUPTS OCCUR WITH TX_ACTION CLEAR.
6961 035030 004767 166000 20$: JSR PC,TXIE1 ;ENABLE TX_INTERRUPTS.
6962 035034 012704 000062 MOV #50.,R4 ;PASS 50 MS TIME TO THE DELAY ROUTINE.
6963 035040 004767 163060 JSR PC,DELAY ;DELAY 50 MILLI-SECONDS TO ALLOW INTS TO OCCUR.
6964 035044 005767 145256 TST TXINTC ;TEST THE TX_INTERRUPT COUNT.
6965 035050 001417 BEQ 24$ ;SKIP THE ERROR IF NO TX_INTERRUPTS.
6966 035052 012701 013526 MOV #EM2607,R1 ;SELECT MESSAGE IN CASE TX_INT FLAG CLEAR.
6967 035056 005767 145246 TST TXINTF ;TEST THE TX_INTERRUPT FLAGS.
6968 035062 100002 BPL 22$ ;GO REPORT ERROR IF TX_FLAG IS CLEAR.
6969 035064 012701 013673 MOV #EM2609,R1 ;TX_FLAG IS SET, SELECT PROPER ERROR MESSAGE.
6970 ;REPORT "TRANSMIT INTERRUPT TEST ERROR:..."
6971 035070 013673 22$: ERRDF 2606,EM2606,ER0503; >>>> ERROR #2606 <<<<<.
035070 104455 TRAP C$ERDF
035072 005056 .WORD 2606
035074 013467 .WORD EM2606
035076 016136 .WORD ER0503
6972
6973 ;*
6974 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
6975 ;-
6976 035100 032767 000100 145116 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6977 035106 001500 BEQ 32$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED

```

```

6978
6979
6980      ;+
        ; PREPARE TX INTERRUPT COUNTER AND FLAGS.
6981      ;
24$:    CLR    TXINTC      ;CLEAR THE TX INTERRUPT COUNT.
        CLR    TXINTF      ;CLEAR THE TX INTERRUPT FLAGS.
6984      ;+
        ; SET UP LINE PARAMETERS FOR TRANSMISSION.
6985      ;-
6986
6987      MOV    #MAPLNS,R5    ;PASS ACTIVE LINES BIT MAP.
6988      MOV    #200,R0      ;PASS INERT STATE, INTERNAL LOOPBACK.
6989      JSR    PC,WTWLNLC    ;DISABLE RECEPTION AND DMA, ETC. ON DUT.
6990      MOV    #156430,R0   ;SPECIFY 9600BPS,1STOP,NO PARITY,8BITS/CHAR.
6991      JSR    PC,WTWLPR    ;WRITE TO ALL LPR REGISTERS.
6992      ;+
6993      ; SEND A NULL CHAR TO EACH LINE.
6994      ;-
6995      MOV    IESTAT,R1     ;SET UP THE STATE OF THE INTERRUPT ENABLE BITS.
6996      CLR    R2            ;CLEAR THE LINE COUNTER.
6997      MOV    R1,@CSRA      ;SET UP THE LINE NUMBER AND INTERRUPT ENABLE
6998      ;BITS IN THE CSR.
6999      MOVB  #0,@FDATA      ;SEND A NULL CHARACTER TO THE OUTPUT FIFO.
7000      INC    R1            ;NEXT CSR CONTENTS.
7001      INC    R2            ;NEXT LINE.
7002      CMP    R2,#NUMLNS   ;IF ALL LINES HAVE NOT BEEN SERVICED THEN
7003      BLT    25$          ;BRANCH.
7004
7005      ;+
7006      ; DELAY 250 MILLI-SECONDS TO ALLOW INTERRUPTS TO OCCUR.
7007      ;-
7008      MOV    #250.,R4      ;SET UP FOR 250 MS DELAY.
7009      JSR    PC,DELAY      ;WAIT 250 MS.
7010      ;+
7011      ; VERIFY THAT TX INTERRUPTS OCCURRED.
7012      ;-
7013      TST    TXINIC        ;CHECK THE TX INTERRUPT COUNTER.
7014      BNE    26$          ;SKIP THE FOLLOWING ERROR IF WE GOT TX INTS.
7015      ;+
7016      ; DETERMINE THE REASON THAT WE RECEIVED NO INTERRUPTS.
7017      ;-
7018      MOV    #EM2610,R1    ;SET UP MSG IN CASE "TX_ACTION IS SET".
7019      TST    @CSRA         ;CHECK THE DUT CSR.
7020      BMI    28$          ;GO TO REPORT ERROR IF TX_ACTION IS SET.
7021      MOV    #EM2611,R1    ;SET UP "TX_ACTION NOT SET" MESSAGE.
7022      BR    28$          ;GO AND REPORT THE ERROR.
7023      ;+
7024      ; CHECK TO VERIFY THAT TX_ACTION WAS SET FOR EACH INTERRUPT.
7025      ;-
26$:    TST    TXINTF        ;CHECK THE TX INTERRUPT FLAGS.
        BPL    30$          ;SKIP ERROR IF TX_ACTION CLR FLAG IS CLEAR.
        MOV    #EM2609,R1    ;SET UP TX INT WITH "TX_ACTION CLR" MSG.
7028      ;+
7029      ; REPORT "TRANSMIT INTERRUPT TEST ERROR:...."
7030      ;-
28$:    ERRDF  2607,EM2606,ER0503;      >>>>> ERROR #2607 <<<<<.
        TRAP  C$ERDF
        .WORD 2607
        .WORD EM2606

```

```

035254 016136 .WORD ERO503
7032
7033
7034 ;+
7035 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
7036 035256 032767 000100 144740 ;-
7037 035264 001411 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
BEQ 32# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
7038
7039 ;+
7040 ; VERIFY THAT NO RX INTERRUPTS HAVE BEEN GENERATED SO FAR IN THIS TEST.
7041 ;-
7042 035266 016702 145022 30#: MOV RXINTC,R2 ;LOAD # OF RX INTERRUPTS FOR ERO504 RTN.
7043 035272 001406 BEQ 32# ;SKIP ERROR IF NO RX INTERRUPTS.
7044 035274 012701 007415 MOV #EM0525,R1 ;SET UP MESSAGE ADR FOR INDIRECT PRINT.
7045 ;REPORT "RX INTERRUPTS(S) RECEIVED WITH RX INTERRUPTS DISABLED."
7046 035300 ERRDF 2608,EM2606,ERO504; >>>> ERROR #2608 <<<<<.
035300 104455 TRAP C#ERDF
035302 005060 .WORD 2608
035304 013467 .WORD EM2606
035306 016174 .WORD ERO504
7047
7048 ;+
7049 ; DISABLE INTERRUPTS AND CLEAN OUT THE INTERRUPT VECTORS USED IN THIS TEST.
7050 035310 005001 32#: CLR R1 ;CLEAR BOTH TRANSMITTER
7051 035312 004767 165456 JSR PC,TXIEO ; INTERRUPT ENABLE AND RECEIVER
7052 035316 004767 164670 JSR PC,RXIEO ; INTERRUPT ENABLE BITS IN THE DUT CSR.
7053 035322 012700 000300 34#: SETPRI #PRI06 ;DISABLE DEVICE INTERRUPTS.
035322 104441 MOV #PRI06,R0
035326 104441 TRAP C#SPRI
7054 035330 016700 144676 CLRVEC RXVECA ;RETURN RX INT VECTOR TO UNUSED POOL.
035330 016700 144676 MOV RXVECA,R0
035334 104436 TRAP C#CVEC
7055 035336 016700 144672 CLRVEC TXVECA ;RETURN TX INT VECTOR TO UNUSED POOL.
035336 016700 144672 MOV TXVECA,R0
035342 104436 TRAP C#CVEC
7056
7057 035344 005067 144736 60#: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
7058 035350 012700 000340 SETPRI #PRI07 ;DISABLE ALL INTERRUPTS.
035350 012700 000340 MOV #PRI07,R0
035354 104441 TRAP C#SPRI
7059 035356 ENDTST
035356 104401 L10054:
035356 104401 TRAP C#ETST
7060

```

```

7062 .SBTTL HARDWARE TEST - BRLEVA
7063 ;* *****
7064 ;* BR LEVEL TEST B
7065 ;* THIS TEST VERIFIES THAT THE DEVICE UNDER TEST (DUT) WILL GENERATE
7066 ;* RECEPTION AND TRANSMISSION INTERRUPTS AT THE CORRECT BR LEVEL.
7067 ;* THIS TEST DOES NOT DEPEND ON THE USE OF THE SERIAL LINE TRANSMISSION
7068 ;* OR RECEPTION CAPABILITIES OF THE DUT. THE LINES ARE PUT IN INTERNAL
7069 ;* LOOPBACK TO MINIMIZE ANY EXTERNAL EFFECTS THAT COULD BE CAUSED ON
7070 ;* DEVICES ATTACHED TO THE SERIAL LINES.
7071 ;*
7072 ;* *****
7073 ;-- *****
7074 035360 BGNTST
035360
7075 035360 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS. T24::
035360 012700 000240 MOV #PRI05,R0
035364 104441 TRAP C$SPRI
7076 000030 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
7077 035366 012767 000030 144730 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (30)
7078 035374 012767 177777 144704 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
7079 035402 012767 000001 146356 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
7080 035410 012767 005671 146352 MOV #3001.,ERRNBR ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
7081 035416 012767 014223 146346 MOV #EM3001,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERTTBL.
7082 035424 005067 145032 CLR ERSMRF ;INITIALIZE THE "REPORT ERROR SUMMARY" FLAGS.
7083 ;+
7084 ; RESET THE DUT TO A KNOWN STATE, DO NOT REMOVE THE STATUS CODES FROM THE FIFO.
7085 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
7086 ; THIS SUBROUTINE REPORTS ERRORS FROM >>>> 3001 THRU 3002 <<<<<.
7087 ;-
7088 035430 004767 163722 JSR PC,RESET ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
7089 035434 103402 BCS 2$ ;SKIP AROUND ABORTING TEST IF NO ERROR FOUND.
7090 035436 000167 000644 JMP 60$ ;ABORT TEST IF FATAL ERROR FOUND DURING RESET.
7091 035442 012767 005673 146320 2$: MOV #3003.,ERRNBR ;SET THE ERROR REPORT NUMBER TO 3003.
7092 ;+
7093 ; ENABLE TRANSMITTERS ON ALL LINES.
7094 ;-
7095 035450 012705 177777 4$: MOV #MAPLNS,R5 ;PASS ACTIVE LINE BIT MAP.
7096 035454 004767 165220 JSR PC,TXENBL ;ENABLE TRANSMISSION ON ALL LINES.
7097 ;+
7098 ; GENERATE A TRANSMISSION INTERRUPT REQUEST.
7099 ; PROCESSOR PRIORITY SHOULD BE AT 7 DISABLING INTS.
7100 ;-
7101 035460 SETPRI #PRI07 ;DISABLE ALL INTERRUPTS.
035460 012700 000340 MOV #PRI07,R0
035464 104441 TRAP C$SPRI
7102 035466 SETVEC TXVECA,#TXINTR,#PRI07 ;SET UP INTERRUPT VECTOR TO CATCH TX INT.
035466 012746 000340 MOV #PRI07,-(SP)
035472 012746 024146 MOV #TXINTR,-(SP)
035476 016746 144532 MOV TXVECA,-(SP)
035502 012746 000003 MOV #3,-(SP)
035506 104437 TRAP C$SVEC
035510 062706 000010 ADD #10,SP
7103 ;+
7104 ; SET UP DUT FOR TRANSMISSION INTERRUPTS:
7105 ; SET UP INTERNAL LOOPBACK.
7106 ; SET UP LINE PARAMETERS FOR TRANSMISSION.
7107 ;

```

```

7108 035514 012705 177777      MOV    #MAPLNS,R5      ;PASS ACTIVE LINES BIT MASK.
7109 035520 012700 000200      MOV    #200,R0         ;PASS INERT STATE, INTERNAL LOOPBACK.
7110 035524 004767 166022      JSR    PC,WTWLNC       ;DISABLE RECEPTION AND DMA, ETC. ON DUT.
7111 035530 012700 156430      MOV    #156430,R0     ;SPECIFY 9600BPS,1STOP,NO PARITY,8BITS/CHAR.
7112 035534 004767 166042      JSR    PC,WTWLPR       ;WRITE INTO ALL LPR REGISTERS.
7113
7114      ; SEND A NULL CHAR TO EACH LINE.
7115
7116 035540 016701 144544      MOV    IESTAT,R1      ;SET UP THE STATE OF THE INTERRUPT ENABLE BITS.
7117 035544 010177 144472      58:   MOV    R1,BCSRA     ;SET UP THE LINE NUMBER AND INTERRUPT ENABLE
                                ;BITS IN THE CSR.
7118
7119 035550 112777 000000 144472      MOVB   #0,OFDATA      ;SEND A NULL CHARACTER TO THE OUTPUT FIFO.
7120 035556 005201                INC    R1              ;NEXT LINE.
7121 035560 020127 000020      CMP    R1,#NUMLNS     ;IF ALL LINES HAVE NOT BEEN SERVICED THEN
7122 035564 002767                BLT    58              ;BRANCH.
7123
7124      ; DELAY 50 MS TO ALLOW TIME FOR THE INTERRUPT TO BE GENERATED.
7125
7126 035566 012704 000062      MOV    #50.,R4        ;PASS 50 MS TIME TO THE DELAY ROUTINE.
7127 035572 004767 162326      JSR    PC,DELAY        ;DELAY 50 MILLI-SECONDS.
7128
7129      ; GENERATE A RECEPTION INTERRUPT REQUEST.
7130
7131      ; SETVEC RXVECA,#RXBRRT,#PRI07 ;SET UP INTERRUPT VECTOR TO CATCH RX INT.
                                MOV    #PRI07, -(SP)
                                MOV    #RXBRRT, (SP)
                                MOV    RXVECA, (SP)
                                MOV    #3, (SP)
                                TRAP   C#SVEC
                                ADD    #10,SP
7132
7133      ; SET UP FOR THE LOOP WHICH TESTS THE INTERRUPT BR LEVELS.
7134
7135 035624 012705 000340      MOV    #340,R5        ;SET UP THE PRIORITY LEVEL TO 7.
7136 035630 005003                CLR    R3              ;CLEAR THE RX PRIORITY STORE AND FLAGS.
7137 035632 005002                CLR    R2              ;CLEAR THE TX PRIORITY STORE AND FLAGS.
7138
7139      ; ENABLE TX AND RX INTERRUPTS.
7140      ; PROCESSOR PRIORITY SHOULD BE AT 7 DISABLING THE INTERRUPTS.
7141
7142 035634 004767 164412      JSR    PC,RXIE1       ;ENABLE RECEIVER INTERRUPTS.
7143 035640 004767 165170      JSR    PC,TXIE1       ;ENABLE TRANSMITTER INTERRUPTS.
7144
7145      ; LOOP, LOWERING THE PROCESSOR PRIORITY UNTIL THE DUT INTERRUPTS ON RX AND TX.
7146
7147 035644 005067 144456      68:   CLR    TXINTC       ;CLEAR THE TX INTERRUPT COUNTER.
7148 035650 005067 144454      CLR    TXINTF         ;CLEAR THE TX INTERRUPT FLAGS.
7149 035654 005067 144434      CLR    RXINTC        ;CLEAR THE RX INTERRUPT COUNTER.
7150 035660 005067 144432      CLR    RXINTF        ;CLEAR THE RX INTERRUPT FLAGS.
7151 035664                SETPRI R5             ;SET PROCESSOR PRIORITY TO THE SELECTED VALUE.
                                MOV    R5,R0
                                TRAP   C#SPRI
7152 035670 012704 000001      MOV    #1,R4          ;PASS 1 MS COUNT TO THE DELAY ROUTINE.
7153 035674 004767 162224      JSR    PC,DELAY        ;DELAY 1 MS TO ALLOW INTERRUPTS TO OCCUR.
7154
7155      ; DETERMINE IF ANY RX DUT INTERRUPTS OCCURRED.
7156      ; LOG THE PROCESSOR PRIORITY FOR THE RX INTERRUPT IF FIRST RX INT.
    
```

```
7157
7158 035700 005767 144410
7159 035704 001412
7160
7161
7162
7163 035706 005703
7164 035710 001010
7165 035712 010503
7166 035714 052703 100000
7167 035720 016700 144372
7168 035724 042700 137777
7169 035730 050003
7170
7171
7172
7173
7174 035732 005767 144370
7175 035736 001405
7176
7177
7178
7179 035740 005702
7180 035742 100403
7181 035744 010502
7182 035746 052702 100000
7183
7184
7185
7186
7187 035752 162705 000040
7188 035756 002402
7189 035760 030203
7190 035762 100330
7191
7192
7193
7194 035764
035764 012700 000340
035770 104441
7195 035772
035772 016700 144234
035776 104436
7196 036000
036000 016700 144230
036004 104436
7197
7198
7199
7200
7201
7202
7203 036006 005702
7204 036010 100420
7205
7206
7207

;
; TST RXINTC ;CHECK THE RECEIVE INTERRUPT COUNTER.
BEQ 8; ;SKIP THE PRIORITY LOG IF NO RX INT OCCURRED.
;
; IF THIS IS THE FIRST RX INTERRUPT, LOG THE PRIORITY.
;
; TST R3 ;CHECK THE RX PRIORITY STORE AND FLAGS.
BNE 8; ;GOTO TEST FOR TX INTS IF NOT THE FIRST RX INT.
MOV R5,R3 ;LOG THE PRESENT PRIORITY IN THE RX PRIO STORE.
BIS #BIT15,R3 ;SET THE RX INT HAS OCCURRED FLAG.
MOV RXINTF,RO ;GET THE RX INTERRUPT ROUTINE FLAGS.
BIC #13777,R0 ;CLEAR ALL BUT THE TX INT ERROR FLAG.
BIS R0,R3 ;IF TX INT ERROR, SET BIT 14 OF THE PRIO FLAGS.
;
; DETERMINE IF ANY TX DUT INTERRUPTS HAVE OCCURRED.
; LOG THE PRESENT PROCESSOR PRIORITY IF THIS IS THE FIRST TX INTERRUPT.
;
; TST TXINTC ;CHECK THE TRANSMIT INTERRUPT COUNTER.
BEQ 10; ;SKIP THE PRIORITY LOG IF NO TX INT OCCURRED.
;
; IF THIS IS THE FIRST TX INTERRUPT, LOG THE PRIORITY.
;
; TST R2 ;CHECK THE TX PRIORITY STORE AND FLAGS.
BMI 10; ;SKIP THE LOGGING IF NOT FIRST TX INTERRUPT.
MOV R5,R2 ;LOG THE PRESENT PRIORITY IN THE TX PRIO STORE.
BIS #BIT15,R2 ;SET THE TX INT HAS OCCURRED FLAG.
;
; SELECT NEXT PROCESSOR PRIORITY.
; TEST FOR BOTH RX AND TX INTERRUPTS HAVING OCCURRED, LOOP IF NOT.
;
; SUB #40,R5 ;DECREMENT PRIORITY LEVEL BY ONE.
BLT 12; ;GOTO CHECK FOR ERRORS IF BELOW PRIORITY ZERO.
BIT R2,R3 ;AND PRIO FLAGS TOGETHER, ALTER NONE OF THEM.
BPL 6; ;LOOP IF RX AND TX INTS HAVEN'T BOTH OCCURRED.
;
; DISABLE INTERRUPTS AND CLEAR INTERRUPT VECTORS.
;
; SETPRI #PRI07 ;DISABLE ALL INTERRUPTS.
MOV #PRI07,RO
TRAP C#SPRI
;
; CLRVEC RXVECA ;RETURN RX INT VECTOR TO UNUSED POOL.
MOV RXVECA,RO
TRAP C#CVEC
;
; CLRVEC TXVECA ;RETURN TX INT VECTOR TO UNUSED POOL.
MOV TXVECA,RO
TRAP C#CVEC
;
; VERIFY THAT RX AND TX INTERRUPTS OCCURRED,
; AT THE PROPER BR LEVEL, AND
; IN THE PROPER ORDER.
; DETERMINE IF TX INTERRUPT OCCURRED.
;
; TST R2 ;DETERMINE WHETHER TX INT OCCURRED OR NOT.
BMI 16; ;SKIP THESE ERRORS IF TX INT OCCURRED.
;
; DETERMINE REASON THAT NO TX INT OCCURRED.
;
```



```

7208 036012 012701 013752      MOV    #EM2610,R1      ;SELECT "NO TX INT FROM TX.ACTION" MESSAGE.
7209 036016 005777 144220      TST    @CSRA          ;CHECK THE TX.ACTION BIT OF THE DUT CSR.
7210 036022 100402              BMI    14$           ;SKIP TX.ACTION CLR MSG SELECTION IF IT IS SET.
7211 036024 012701 014044      MOV    #EM2611,R1      ;SELECT "TX.ACTION CLEAR AFTER CHARS SENT" MSG.
7212                                ;REPORT "INTERRUPT BR LEVEL TEST ERROR:"
7213 036030              14$:  ERRDF  3003,EM3001,ER0503;      >>>> ERROR #3003 <<<<<.
                                TRAP    C#ERDF
                                .WORD   3003
                                .WORD   EM3001
                                .WORD   ER0503
7214
7215
7216                                ;*
                                ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
7217                                ;-
7218 036040 032767 000100 144156  BIT    #BIT06,OPTION  ;EXIT WITH TEST FAILURE MESSAGE IF
7219 036046 001513              BEQ    26$           ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
7220
7221 036050 000427              BR     18$           ;SKIP THE BR LEVEL CHECK, NO TX INT OCCURRED.
7222                                ;*
7223                                ; VERIFY THAT THE TX INTERRUPT WAS AT THE PROPER BR LEVEL.
7224                                ;
7225 036052 010204              16$:  MOV    R2,P4      ;CALCULATE THE BR LEVEL
7226 036054 042704 177400      BIC    #177400,R4     ; THAT THE TRANSMIT
7227 036060 006204              ASR    R4             ; INTERRUPT WAS
7228 036062 006204              ASR    R4             ; REQUESTED AT, WHICH
7229 036064 006204              ASR    R4             ; IS ONE GREATER THAN
7230 036066 006204              ASR    R4             ; THE PROCESSOR PRIORITY
7231 036070 006204              ASR    R4             ; LEVEL AT WHICH THE
7232 036072 005204              INC    R4             ; TRANSMIT INTERRUPT OCCURRED.
7233 036074 116705 144140      MOVB   BRLEVL,R5     ;GET THE EXPECTED INTERRUPT BR LEVEL.
7234 036100 120405              CMPB  R4,R5          ;COMPARE THE INTERRUPT BR LEVEL WITH EXPECTED.
7235 036102 001412              BEQ    18$           ;SKIP THE ERROR IF BR LEVEL IS CORRECT.
7236                                ;REPORT "TX INTERRUPT GENERATED AT WRONG BR LEVEL: ..."
7237 036104 012701 014356      MOV    #EM3003,R1      ;SELECT THE ERROR MESSAGE FOR THE ERROR CALL.
7238 036110              ERRDF  3004,EM3001,ER3001;      >>>> ERROR #3004 <<<<<.
                                TRAP    C#ERDF
                                .WORD   3004
                                .WORD   EM3001
                                .WORD   ER3001
7239
7240                                ;*
7241                                ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
7242 036120 032767 000100 144076  BIT    #BIT06,OPTION  ;EXIT WITH TEST FAILURE MESSAGE IF
7243 036126 001463              BEQ    26$           ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
7244
7245                                ;*
7246                                ; DETERMINE IF RX INTERRUPT OCCURRED.
7247                                ;-
7248 036130 005703              18$:  TST    R3         ;CHECK THE RX INT OCCURRED FLAG.
7249 036132 100421              BMI    22$           ;SKIP THESE ERRORS IF RX INT OCCURRED.
7250
7251                                ;*
7252                                ; DETERMINE REASON THAT NO RX INT OCCURRED.
7253 036134 012701 014127              MOV    #EM2612,R1      ;SELECT "NO RX INT FROM RX.DATA.AVAIL" MSG.
7254 036140 032777 000200 144074  BIT    #BIT7,@CSRA     ;CHECK THE RX.DATA.AVAIL BIT OF THE DUT CSR.
7255 036146 001002              BNE   20$           ;SKIP RX.DATA.AVAIL CLR MSG IF BIT IS SET.
7256 036150 012701 014262              MOV    #EM3002,R1      ;SELECT "NO RX.DATA.AVAIL AFTER RESET" MSG.

```

```

7257 ;REPORT "INTERRUPT BR LEVEL TEST ERROR:"
7258 036154 20$: ERRDF 3005,EM3001,ER0503; >>>> ERROR #3005 <<<<.
      036154 104455 TRAP C$ERDF
      036156 005675 .WORD 3005
      036160 014223 .WORD EM3001
      036162 016136 .WORD ER0503

7259 ;*
7260 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
7261 ;-
7262 036164 032767 000100 144032 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
7263 036172 001441 BEQ 26$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
7264
7265 036174 000427 BR 24$ ;SKIP THE BR CHECK IF NO RX INT OCCURRED.
7266 ;*
7267 ; VERIFY THAT THE RX INTERRUPT WAS AT THE PROPER BR LEVEL.
7268 ;-
7269 036176 010304 22$: MOV R3,R4 ;CALCULATE THE BR LEVEL
7270 036200 042704 177400 BIC #177400,R4 ; THAT THE RECEIVE
7271 036204 006204 ASR R4 ; INTERRUPT WAS
7272 036206 006204 ASR R4 ; REQUESTED AT, WHICH
7273 036210 006204 ASR R4 ; IS ONE GREATER THAN
7274 036212 006204 ASR R4 ; THE PROCESSOR PRIORITY
7275 036214 006204 ASR R4 ; LEVEL AT WHICH THE
7276 036216 005204 INC R4 ; RECEIVE INTERRUPT OCCURRED.
7277 036220 116705 144014 MOV# BRLEVL,R5 ;GET THE EXPECTED INTERRUPT BR LEVEL.
7278 036224 120405 CMPB R4,R5 ;COMARE THE INTERRUPT BR LEVEL WITH EXPECTED.
7279 036226 001412 BEQ 24$ ;SKIP THE ERROR IF BR LEVEL IS CORRECT.
7280 ;REPORT "RX INTERRUPT GENERATED AT WRONG BR LEVEL: ..."
7281 036230 012701 014432 MOV #EM3004,R1 ;SELECT ERROR MESSAGE FOR THE ERROR CALL.
7282 036234 ERRDF 3006,EM3001,ER3001; >>>> ERROR #3006 <<<<.
      036234 104455 TRAP C$ERDF
      036236 005676 .WORD 3006
      036240 014223 .WORD EM3001
      036242 016620 .WORD ER3001

7283 ;*
7284 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
7285 ;-
7286 036244 032767 000100 143752 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
7287 036252 001411 BEQ 26$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
7288
7289 ;*
7290 ; TEST FOR INTERRUPTS OCCURING IN THE PROPER ORDER.
7291 ;-
7292 036254 032703 040000 24$: BIT #BIT14,R3 ;CHECK THE IMPROPER INT ORDER ERROR FLAG.
7293 036260 001406 BEQ 26$ ;SKIP ERROR REPORT IF ERROR DID NOT OCCUR.
7294 ;REPORT "TX INTERRUPT GIVEN PRECEDENCE OVER SIMULTANEOUS RX INT."
7295 036262 012701 014506 MOV #EM3005,R1 ;SELECT THE ERROR MESSAGE FOR INDIRECT PRINT.
7296 036266 ERRDF 3007,EM3001,ER0503; >>>> ERROR #3007 <<<<.
      036266 104455 TRAP C$ERDF
      036270 005677 .WORD 3007
      036272 014223 .WORD EM3001
      036274 016136 .WORD ER0503

7297 ;*
7298 ; CLEAN UP, EXIT THE TEST.
7299 ;-
7300 036276 004767 164472 26$: JSR PC,TXIEO ;CLEAR TRANSMITTER INTERRUPTS.
7301 036302 004767 163704 JSR PC,RXIEO ;CLEAR RECEIVER INTERRUPTS.

```

7302 036306 005067 143774
 7303 036312
 036312 012700 000340
 036316 104441
 7304 036320
 036320
 036320 104401
 7305

601: C12 CTRLCF
 C1PRI #PRI07

 ENDTST

;INDICATE THAT WE ARE NOT WITHIN A TEST.
 ;DISABLE ALL INTERRUPTS.

MOV #PRI07,RO
 TRAP C1SPRI

L10055:
 TRAP C1ETST

```

7307 .SBTTL  HARDWARE TEST          DIABMP
7308 :* *****
7309 :* - DIAGNOSTIC FIELD (BMP) TEST
7310 :* THIS TEST VERIFIES THAT A REQUEST TO THE DUT TO REPORT BMP STATUS
7311 :* CODES IS COMPLIED WITH, WITHIN THE SPECIFIED TIME.
7312 :* ALL ACTIVE LINES ARE TESTED.
7313 :* *****
7314
7315          BGNST
7316          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T25:
          036322          012700  000240          MOV          #PRI05,R0
          036322          104441          TRAP          C#SPRI
          036326          000031          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
7317          000031          MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (31)
7318 036330 012767 000031 143766          MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
7319 036336 012767 177777 143742          MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
7320 036344 012767 000001 145414          MOV          #3101.,ERRNBR          ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
7321 036352 012767 006035 145410          MOV          #EM3101,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERRTABL.
7322 036360 012767 014600 145404          MOV          #ER9101,ERRBLK          ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
7323 036366 012767 017222 145400
7324
7325 :* RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
7326 :* CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
7327 :* THIS SUBROUTINE REPORTS ERROR >>>> 3101 <<<<<.
7328
7329 036374 004767 161402          JSR          PC,CLNRST          ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
7330 036400 103103          BCC          60$          ;RESET FAILURE?, ABORT THIS TEST.
7331
7332 :* TEST ALL ACTIVE LINES INDIVIDUALLY.
7333 :* WRITE THE REQUEST CODE TO THE DIAGNOSTIC FIELD IN THE LPR REGISTER.
7334 :* VERIFY THAT A BMP CODE IS RETURNED WITHIN THE CORRECT TIME.
7335
7336 036402 016705 143622          MOV          ACTLNS,R5          ;GET THE ACTIVE LINE BIT MAP.
7337 036406 005004          CLR          R4          ;CLEAR THE LINE NUMBER COUNTER.
7338 036410 016703 143626          MOV          CSRA,R3          ;GET THE ADDRESS OF THE DUT'S CSR.
7339 036414 000241          CLC          ;CLEAR THE CARRY BIT PRIOR TO SHIFTING BIT MAP.
7340 036416 006005          ROR          R5          ;SHIFT THE BIT MAP INTO THE CARRY BIT.
7341 036420 103070          BCC          8$          ;DO NOT TEST THE LINE IF IT IS INACTIVE.
7342
7343 :* SELECT THE LINE UNDER TEST.
7344 :* WRITE THE BMP REQUEST CODE TO THE DIAG FIELD IN THE LPR REGISTER.
7345
7346 036422 012767 006036 145340          MOV          #3102.,ERRNBR          ;SET THE ERROR NUMBER TO 3102.
7347 036430 010413          MOV          R4,(R3)          ;SELECT THE LINE CURRENTLY UNDER TEST.
7348 036432 052777 000002 143606          BIS          #2,@LPR          ;WRITE THE BMP REQUEST CODE TO THE LPR.
7349
7350 :* WAIT FOR BMP REQUEST CODE TO BE CLEARED, REPORT ERROR IF TIME-OUT
7351 :* OCCURS.
7352
7353 036440 012701 011750          MOV          #11750,R1          ;TEST BIT 1, TIMEOUT OF 1 SEC.
7354 036444 016702 143576          MOV          LPR,R2          ;PASS THE ADDRESS OF THE REGISTER TO TEST.
7355 036450 004767 164540          JSR          PC,WAIBIC          ;WAIT FOR REQUEST CODE TO CLEAR.
7356 036454 103042          BCC          6$          ;GO REPORT ERROR IF CODE DID NOT CLEAR IN TIME.
7357
7358 :* WAIT FOR BMP CODE TO APPEAR IN THE FIFO, REPORT ERROR IF TIME OUT
7359 :* OCCURS.
7360
    
```

```

7361 036456 005267 145306      INC      ERRNBR      ;SET ERROR NUMBER TO 3103.
7362 036462 012701 070012      MOV      #70012,R1   ;TEST BIT 7, TIMEOUT OF 10 MILLI SECS.
7363 036466 016702 143550      MOV      CSRA,R2     ;PASS THE ADDRESS OF THE REGISTER TO TEST.
7364 036472 004767 164572      JSR      PC,WAI8IS   ;WAIT FOR RX_DATA_AVAILABLE TO SET.
7365 036476 103031              BCC      6$         ;GO REPORT ERROR IF CODE DID NOT CLEAR IN TIME.
7366                               ;*
7367                               ; READ THE BMP CODE (IF IT IS THERE) FROM THE RBUF REGISTER.
7368                               ; DETERMINE IF IT IS A VALID BMP CODE.
7369                               ; VERIFY THE BMP CODE WAS RECEIVED FROM THE CORRECT CHANNEL.
7370                               ; IF THE BMP CODE DOES NOT INDICATE DUT RUNNING OK, THEN SAVE IT ON
7371                               ; THE QUEUE TO BE REPORTED IN A LATER TEST.
7372                               ;
7373 036500 005267 145264      INC      ERRNBR      ;SET ERROR NUMBER TO 3104.
7374 036504 017702 143534      MOV      @RBUFA,R2   ;GET THE BMP CODE FROM THE FIFO.
7375 036510 100024              BPL      6$         ;GO REPORT ERROR IF NO BMP CODE FOUND.
7376 036512 005267 145252      INC      ERRNBR      ;SET ERROR NUMBER TO 3105.
7377 036516 012700 170301      MOV      #170301,R0  ;SET-UP A BMP CODE MASK.
7378 036522 040200              BIC      R2,R0       ;TRY TO CLEAR THE BMP MASK.
7379 036524 001016              BNE      6$         ;GO REPORT ERROR IF IT IS NOT A VALID BMP CODE.
7380 036526 005267 145236      INC      ERRNBR      ;SET THE ERROR NUMBER TO 3106.
7381 036532 010200              MOV      R2,R0       ;COPY THE BMP CODE.
7382 036534 000300              SWAB    R0           ;PUT THE LINE NUMBER IN THE LOW BYTE.
7383 036536 042700 177760      BIC      #177760,R0  ;CLEAR THE UNWANTED BITS.
7384 036542 120400              CMPB    R4,R0        ;DID THE BMP CODE COME FROM THE CORRECT LINE?.
7385 036544 001006              BNE      6$         ;NO; GO REPORT ERROR.
7386 036546 120227 000305      CMPB    R2,#305     ;IS THE BMP CODE A "GOOD ONE"?.
7387 036552 001413              BEQ      8$         ;YES; SKIP SAVING THE BMP CODE ON THE QUEUE.
7388 036554 004767 163516      JSR      PC,SAVBMP   ;SAVE THE BMP CODE ON THE QUEUE.
7389 036560 000410              BR       8$         ;GO SEE IF THERE ARE ANY MORE LINE TO TEST.
7390
7391 036562 010401              6$:     MOV      R4,R1     ;PASS THE LINE NUMBER TO BE REPORTED.
7392 036564 012702 014643      MOV      #EM3102,R2  ;PASS THE ERROR MESSAGE TO BE REPORTED.
7393                               ;"BMP REQUEST BIT BAD ON LINE:"
7394 036570              ERROR          ;
7395 036570 104460              ;                >>>> ERROR <<<<<.
7396                               ;                                TRAP      C$ERROR
7397                               ;*
7398                               ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
7399 036572 032767 000100 143424  BIT      #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
7400 036600 001403              BEQ      60$        ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
7401
7402                               ;*
7403                               ; VERIFY ALL ACTIVE LINES HAVE BEEN TESTED.
7404                               ;
7405 036602 005204              8$:     INC      R4     ;INCREMENT THE LINE NUMBER COUNTER.
7406 036604 005705              TST     R5           ;ARE THERE ANY MORE ACTIVE LINES TO TEST?.
7407 036606 001302              BNE     2$          ;YES; BRANCH TO TEST THE NEXT LINE.
7408 036610 005067 143472      60$:   CLR      CTRLCF    ;INDICATE THAT WE ARE NOT WITHIN A TEST.
7409 036614              ENDTST
036614 104401

```

L10056: TRAP C\$ETST

```

7411
7412 .SBTTL HARDWARE TEST - REPBM
7413 ;* *****
7414 ;* REPORT ANY BMP CODES IN THE QUEUE
7415 ;* THIS IS A PSEUDO-TEST USED TO REPORT ANY BMP CODES THAT WERE FOUND
7416 ;* IN THE DUT'S FIFO DURING PREVIOUS TEST, AND LOGGED IN THE BMP CODE
7417 ;* QUEUE.
7418 ;* IT IS UNLIKELY THAT RUNNING THIS PSEUDO TEST ALONE WILL PRODUCE ANY
7419 ;* ERROR REPORTS.
7420 ;*
7421 ;-- *****
7422 036616 BGNTST
036616
7423 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
7424 036616 012767 000032 143500 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (93)
7425 036624 012767 177777 143454 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
7426 036632 016702 143666 MOV BMPCQP,R2 ;GET THE CONTENTS OF THE POINTER.
7427 036636 012703 002526 MOV #BMPCQB,R3 ;GET THE START ADDRESS OF THE QUEUE.
7428 036642 020203 CMP R2,R3 ;SEE IF THE POINTER HAS MOVED FROM THE BASE.
7429 036644 001411 BEQ 60$ ;EXIT NO CODES IN THE QUEUE.
7430 ;*
7431 ; THERE IS AT LEAST ONE BMP CODE IN THE QUEUE. REPORT THE ERROR.
7432 ;
7433 ;REPORT ERROR BMP CODE FOUND IN TEST NN, BMP CODE:NNNNNN"
7434
7435 036646 012701 015433 MOV #EM9304,R1 ;PASS THE FIRST MESSAGE TO BE REORTED.
7436 036652 ERRDF 9301,EM9301,ER9301 ; >>>> ERROR #9301 <<<<<.
036652 104455 TRAP C$ERDF
036654 022125 .WORD 9301
036656 015257 .WORD EM9301
036660 017262 .WORD ER9301
7437
7438 036662 012767 002526 143634 MOV #BMPCQB,BMPCQP ;SET POINTER BACK TO THE BEGINING OF THE QUE.
7439
7440 036670 005067 143412 60$: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
7441 036674 ENDTST
036674 L10057: TRAP C$ETST
036674 104401

```

7450
7451
7452
7453
7454
7455
7456
7457
7458
7459
7460
7461
7462
7463
7464
7465 036676
C36676 000022
036700
7466
7476
7477 036700
036700 000031
036702 036744
036704 160000
036706 177776
7478
7479 036710
036710 001031
036712 036762
036714 000040
036716 000776
7480
7481 036720
036720 002032
036722 037015
036724 177777
036726 000000
036730 177777
7482
7483 036732
036732 003032
036734 037043
036736 000377
036740 000000
036742 000006
7484
7485
7486 036744
036744
7487
7494
7495 036744 103 123 122
036747 040 101 104
036752 104 122 105
036755 123 123 072
036760 040 000

.SBTTL HARDWARE PARAMETER CODING SECTION

; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
; WITH THE OPERATOR.
; -

BGNHRD

.WORD L10060 L\$HARD/?
L\$HARD:;

;DEVICE CSR ADDRESS QUESTION:
GPRMA HWPTQ1,0,0,160000,177776,YES

.WORD T\$CODE
.WORD HWPTQ1
.WORD T\$LLOLIM
.WORD T\$HILIM

;DEVICE INTERRUPT VECTOR QUESTION:
GPRMA HWPTQ2,2,0,40,776,YES

.WORD T\$CODE
.WORD HWPTQ2
.WORD T\$LLOLIM
.WORD T\$HILIM

;ACTIVE LINES BIT MAP QUESTION:
GPRMD HWPTQ3,4,0,MAPLNS,0,MAPLNS,YES

.WORD T\$CODE
.WORD HWPTQ3
.WORD MAPLNS
.WORD T\$LLOLIM
.WORD T\$HILIM

;INTERRUPT BR LEVEL QUESTION:
GPRMD HWPTQ4,6,0,377,0,6,YES

.WORD T\$CODE
.WORD HWPTQ4
.WORD 377
.WORD T\$LLOLIM
.WORD T\$HILIM

ENDHRD

.EVEN
L10060:

HWPTQ1: .ASCIZ /CSR ADDRESS: /

7496	036762	111	116	124
	036765	105	122	122
	036770	125	120	124
	036773	040	126	105
	036776	103	124	117
	037001	122	040	101
	037004	104	104	122
	037007	105	123	123
	037012	072	040	000
7497	037015	101	103	124
	037020	111	126	105
	037023	040	114	111
	037026	116	105	040
	037031	102	111	124
	037034	040	115	101
	037037	120	072	040
	037042	000		
7498	037043	111	116	124
	037046	105	122	122
	037051	125	120	124
	037054	040	102	122
	037057	040	114	105
	037062	126	105	114
	037065	072	040	000
7499				
7500				

HWPTQ2: .ASCIZ /INTERRUPT VECTOR ADDRESS: /

HWPTQ3: .ASCIZ /ACTIVE LINE BIT MAP: /

HWPTQ4: .ASCIZ /INTERRUPT BR LEVEL: /

.EVEN

7509
 7510
 7511
 7512
 7513
 7514
 7515
 7516
 7517
 7518
 7519
 7520
 7521

.SBTTL SOFTWARE PARAMETER CODING SECTION

```

; **
; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
; THAT ARE USED BY THE SUPERVISOR TO BUILD P TABLES. THE
; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
; WITH THE OPERATOR.
;

```

7522 037070
 037070 000017
 037072

BGNSFT

.WORD L10061-L\$SOFT/2
 L\$SOFT::

7523
 7532

```

;UNIT NUMBER PRINTOUT QUESTION:
GPRML SWPTQ1,0,20,YES

```

7533 037072
 037072 000130
 037074 037130
 037076 000020

.WORD T\$CODE
 .WORD SWPTQ1
 .WORD 20

7534
 7535

```

;ROM VERSION NUMBER PRINTOUT ON FIRST PASS QUESTION:
GPRML SWPTQ2,0,1,YES

```

037100
 037100 000130
 037102 037204
 037104 000001

.WORD T\$CODE
 .WORD SWPTQ2
 .WORD 1

7536
 7537

```

;EXTENDED ERROR REPORTING QUESTION:
GPRML SWPTQ3,0,100,YES

```

037106
 037106 000130
 037110 037255
 037112 000100

.WORD T\$CODE
 .WORD SWPTQ3
 .WORD 100

7538
 7539

```

; *
; IF EXTENDED ERROR REPORTING IS NOT REQUIRED THEN SKIP THE NEXT QUESTION.
; *

```

7540
 7541

XFERF ENDD

037114
 037114 006044

.WORD T\$CODE

7542
 7543

```

;NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE QUESTION:
GPRMD SWPTQ4,2,0,177777,0,177777,YES

```

7544 037116
 037116 001052
 037120 037310
 037122 177777
 037124 000000
 037126 177777

.WORD T\$CODE
 .WORD SWPTQ4
 .WORD 177777
 .WORD T\$LOLIM
 .WORD T\$HILIM

7545
 7546

.EVEN

7547 037130

ENDD: ENDSFT

.EVEN

037130

L10061:

7548
 7549

7556 037130 122 105 120
 037133 117 122 124
 037136 040 125 116
 037141 111 124 040
 037144 116 125 115

SWPTQ1: .ASCIZ /REPORT UNIT NUMBER AS EACH UNIT IS TESTED: /

	037147	102	105	122	
	037152	040	101	123	
	037155	040	105	101	
	037160	103	110	040	
	037163	125	116	111	
	037166	124	040	111	
	037171	123	040	124	
	037174	105	123	124	
	037177	105	104	072	
7557	037202	040	000		
	037204	122	117	115	SWPTQ2: .ASCIZ /ROM VERSION PRINTOUT ON THE FIRST PASS: /
	037207	040	126	105	
	037212	122	123	111	
	037215	117	116	040	
	037220	120	122	111	
	037223	116	124	117	
	037226	125	124	040	
	037231	117	116	040	
	037234	124	110	105	
	037237	040	106	111	
	037242	122	123	124	
	037245	040	120	101	
	037250	123	123	072	
	037253	040	000		
7558	037255	105	130	124	SWPTQ3: .ASCIZ /EXTENDED ERROR REPORTING: /
	037260	105	116	104	
	037263	105	104	040	
	037266	105	122	122	
	037271	117	122	040	
	037274	122	105	120	
	037277	117	122	124	
	037302	111	116	107	
	037305	072	040	000	
7559	037310	116	125	115	SWPTQ4: .ASCIZ /NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE: /
	037313	102	105	122	
	037316	040	117	106	
	037321	040	111	116	
	037324	104	111	126	
	037327	111	104	125	
	037332	101	114	040	
	037335	104	101	124	
	037340	101	040	105	
	037343	122	122	117	
	037346	122	123	040	
	037351	124	117	040	
	037354	122	105	120	
	037357	117	122	124	
	037362	040	117	116	
	037365	040	101	040	
	037370	114	111	116	
	037373	105	072	040	
7560	037376	000			.EVEN

7569

7570

7571 037400

\$PATCH: .BLKW 24

7572 037400

7573

7580

7581

7582

7583

7584 037450

LASTAD

.EVEN
.WORD 0
.WORD 0

037450 000000

037452 000000

037454

L\$LAST: ENDMOD

7585 037454

7586

7587

7588

7589

7590

7591

7592

7593 000001

.END

ACTLNS	002230	G	C#AU	000052	DROP	025122	EM0902	010766	G	EM9023	015217	G		
ADR	000020	G	C#AUTO	000061	DROOMG	005464	G	EM1001	011022	G	EM9024	015241	G	
ADRPTR	017764	G	C#BAK	000022	DRO2MG	005470	G	EM1002	011055	G	EM9301	015257	G	
ALYFLD	017454	G	C#BSEG	000004	DRO4MG	005475	G	EM1003	011142	G	EM9302	015336	G	
ASSEMB	000010	G	C#BSUB	000002	DRO6MG	005501	G	EM1101	011220	G	EM9303	015366	G	
BCOUNT	002352	G	C#CEFG	000045	DR10MG	005517	G	EM1201	011273	G	EM9304	015433	G	
BITTBL	002410	G	C#CLCK	000062	DR12MG	005526	G	EM1202	011321	G	ENDD	037130		
BIT0	000001	G	C#CLEA	000012	DR14MG	005537	G	EM1203	011405	G	ENDETB	003726	G	
BIT00	000001	G	C#CLOS	000035	DR16MG	005550	G	EM1204	011463	G	ENDIT	025042		
BIT01	000002	G	C#CLP1	000006	EDROP	025200		EM1205	011517	G	ERCNTB	002464	G	
BIT02	000004	G	C#CVEC	000036	EF.CON	000036	G	EM1301	011543	G	ERTBL	002726	G	
BIT03	000010	G	C#DCLN	000044	EF.NEW	000035	G	EM1302	011576	G	ERRBLK	003774	G	
BIT04	000020	G	C#DDDU	000051	EF.PWR	000034	G	EM1401	011635	G	ERRMSG	003772	G	
BIT05	000040	G	C#DRPT	000024	EF.RES	000037	G	EM1402	011674	G	ERRNBR	003770	G	
BIT06	000100	G	C#DU	000053	EF.STA	000040	G	EM1403	011762	G	ERRYP	003766	G	
BIT07	000200	G	C#EDIT	000003	EF0503	004074	G	EM1404	012035	G	ERSMRF	002462	G	
BIT08	000400	G	C#ERDF	000055	EF0505	004101	G	EM1405	012107	G	ER0101	015510	G	
BIT09	001000	G	C#ERMR	000056	EF1401	004154	G	EM1406	012122	G	ER0201	016042	G	
BIT1	000002	G	C#ERRO	000060	EF1402	004256	G	EM1407	012135	G	ER0503	016136	G	
BIT10	002000	G	C#ERSF	000054	EF1601	004313	G	EM1408	012147	G	ER0504	016174	G	
BIT11	004000	G	C#ERSO	000057	EF1602	004345	G	EM1501	012155	G	ER1401	016254	G	
BIT12	010000	G	C#ESCA	000010	EF1603	004407	G	EM1502	012203	G	ER1601	016416	G	
BIT13	020000	G	C#ESEG	000005	EF1604	004451	G	EM1601	012221	G	ER1603	016526	G	
BIT14	040000	G	C#ESUB	000003	EF3001	004546	G	EM1604	012304	G	ER3001	016620	G	
BIT15	100000	G	C#ETST	000001	EF3002	004615	G	EM1701	012360	G	ER9004	016722	G	
BIT2	000004	G	C#EXIT	000032	EF9006	004664	G	EM1801	012443	G	ER9007	017036	G	
BIT3	000010	G	C#GETB	000026	EF9010	004710	G	EM1901	012517	G	ER9008	017126	G	
BIT4	000020	G	C#GETW	000027	EF9016	004777	G	EM2001	012602	G	ER9101	017222	G	
BIT5	000040	G	C#GMAN	000043	EF9017	005074	G	EM2002	012652	G	ER9301	017262	G	
BIT6	000100	G	C#GPHR	000042	EF9018	005150	G	EM2301	012725	G	EVL	000004	G	
BIT7	000200	G	C#GPLD	000030	EF9301	005255	G	EM2302	012772	G	EXDERR	002304	G	
BIT8	000400	G	C#GPRI	000040	EF9302	005333	G	EM2401	013030	G	E#END	002100		
BIT9	001000	G	C#INIT	000011	EM0101	020360	G	EM2601	013073	G	E#LOAD	000035		
BMPDOB	002526	G	C#INLP	000020	EM0102	020444	G	EM2602	013131	G	FDATA	002250	G	
BMPDDE	002726	G	C#MANI	000050	EM0103	005560	G	EM2603	013222	G	F#LSA	002250	G	
BMPDOP	002524	G	C#MEM	000031	EM0201	005616	G	EM2604	013310	G	F#LSO	000006	G	
BOE	000400	G	C#MSG	000023	EM0202	005651	G	EM2605	013404	G	F#AU	000015		
BRLEVL	002240	G	C#OPEN	000034	EM0203	006024	G	EM2606	013467	G	F#AUTO	000020		
BUFAS	002726	G	C#PNTB	000014	EM0204	006167	G	EM2607	013526	G	F#BGN	000040		
BUFEND	003726	G	C#PNTF	000017	EM0301	006346	G	EM2608	013622	G	F#CLEA	000007		
BUFMID	003326	G	C#PNTS	000016	EM0302	006420	G	EM2609	013673	G	F#DU	000016		
BUFPT	002302	G	C#PNTX	000015	EM0303	006560	G	EM2610	013752	G	F#END	000041		
BUF3GT	003526	G	C#QIO	000377	EM0401	006737	G	EM2611	014044	G	F#HARD	000004		
CACHRX	023632	G	C#RDBU	000007	EM0402	007015	G	EM2612	014127	G	F#HW	000013		
CACHTX	023660	G	C#REFG	000047	EM0501	007165	G	EM3001	014223	G	F#INIT	000006		
CALMSL	017526	G	C#RESE	000033	EM0502	007241	G	EM3002	014262	G	F#JMP	000050		
CKTRAP	017752	G	C#REVI	000003	EM0525	007415	G	EM3003	014356	G	F#MOD	000000		
CLKBRL	002336	G	C#RFLA	000021	EM0526	007505	G	EM3004	014432	G	F#MSG	000011		
CLKCSR	002334	G	C#RPT	000025	EM0601	007575	G	EM3005	014506	G	F#PROT	000021		
CLKMRZ	002342	G	C#SEFG	000046	EM0602	007637	G	EM3101	014600	G	F#PWR	000017		
CLKINT	023706	G	C#SPRI	000041	EM0603	010017	G	EM3102	014643	G	F#RPT	000012		
CLKVEC	002340	G	C#SVEC	000037	EM0701	010202	G	EM9014	014722	G	F#SEG	000003		
CLNRST	020002	G	C#TPRI	000013	EM0702	010245	G	EM9017	015016	G	F#SOFT	000005		
CLR16W	020024	G	DELAY	020124	G	EM0703	010425	G	EM9018	015127	G	F#SRV	000010	
CNTERR	020046	G	DFPTBL	002212	G	EM0801	010610	G	EM9019	015137	G	F#SUB	000002	
CSRA	002242	G	DIAGMC	000000		EM0802	010656	G	EM9020	015154	G	F#SW	000014	
CTRLCF	002306	G	DRADRT	002242	G	EM0901	010726	G	EM9022	015200	G	F#TEST	000001	

GETPRM 024640
 GPRS08 002450 G
 G#CN1? 000200
 G#DELM 000372
 G#DISP 000003
 G#EXCP 000400
 G#HILI 000002
 G#LOLI 000001
 G#NO 000000
 G#OFFS 000400
 G#OFFSI 000376
 G#PRMA 000001
 G#PPMD 000002
 G#PRML 000000
 G#RADA 000140
 G#RADB 000000
 G#RADD 000040
 G#RADL 000120
 G#RADO 000020
 G#XFER 000004
 G#YES 000010
 HELP 000000
 MOE 100000 G
 MWPTQ1 036744
 MWPTQ2 036762
 MWPTQ3 037015
 MWPTQ4 037043
 IBE 010000 G
 IDU 000040 G
 IER 020000 G
 IESTAT 002310 G
 ISR 000100 G
 IXE 004000 G
 I#AU 000041
 I#AUTO 000041
 I#CLN 000041
 I#DIJ 000041
 I#HRD 000041
 I#INIT 000041
 I#MOD 000041
 I#MSG 000041
 I#PROT 000040
 I#PTAB 000041
 I#PLR 000041
 I#RPT 000041
 I#SEG 000041
 I#SETU 000041
 I#SFT 000041
 I#SRV 000041
 I#SUB 000041
 I#TST 000041
 J#JMP 000167
 LNCTRA 002252 G
 LOE 040000 G
 LOT 000010 G
 LPCSLT 000036 G
 LPRA 002246 G

LPRO 000004 G
 L#ACP 002110 G
 L#APT 002036 G
 L#AU 025206 G
 L#AUT 002070 G
 L#AUTO 025056 G
 L#CCP 002106 G
 L#CLEA 025060 G
 L#CO 002032 G
 L#DEPO 002011 G
 L#DESC 004046 G
 L#DESP 002076 G
 L#DEVP 002060 G
 L#DISP 002124 G
 L#DLY 002116 G
 L#DTP 002040 G
 L#DTYP 002034 G
 L#DU 025076 G
 L#DUT 002072 G
 L#DVTY 004036 G
 L#EF 002052 G
 L#ENVI 002044 G
 L#ERRT 003766 G
 L#ETP 002102 G
 L#EXP1 002046 G
 L#EXP4 002064 G
 L#EXP5 002066 G
 L#HARD 036700 G
 L#HIME 002120 G
 L#HPCP 002016 G
 L#HPTP 002022 G
 L#HW 002212 G
 L#ICP 002104 G
 L#INIT 024236 G
 L#LADP 002026 G
 L#LAST 037454 G
 L#LOAD 002100 G
 L#LUN 002074 G
 L#MREV 002050 G
 L#NAME 002000 G
 L#PRIO 002042 G
 L#PROT 024230 G
 L#PRT 002112 G
 L#REPP 002062 G
 L#REV 002010 G
 L#RPT 024222 G
 L#SOFT 037072 G
 L#SPC 002056 G
 L#SPCP 002020 G
 L#SPTP 002024 G
 L#STA 002030 G
 L#SW 002224 G
 L#TEST 002114 G
 L#TIML 002014 G
 L#UNIT 002012 G
 L10000 002222
 L10001 002230

L10002 015624
 L10003 016134
 L10004 016172
 L10005 016252
 L10006 016414
 L10007 016524
 L10010 016616
 L10011 016720
 L10012 017034
 L10013 017124
 L10014 017220
 L10015 017260
 L10016 017452
 L10017 024226
 L10021 025054
 L10022 025056
 L10023 025074
 L10024 025204
 L10025 025212
 L10026 025474
 L10027 025724
 L10030 026170
 L10031 026366
 L10032 026560
 L10033 026776
 L10034 027204
 L10035 027412
 L10036 027606
 L10037 030022
 L10040 030250
 L10041 030544
 L10042 031032
 L10043 031432
 L10044 031774
 L10045 032242
 L10046 032432
 L10047 032750
 L10050 033212
 L10051 033326
 L10052 033644
 L10053 034220
 L10054 035356
 L10055 036320
 L10056 036614
 L10057 036674
 L10060 036744
 L10061 037130
 MAPLNS 177777 G
 MFUNIT 005433 G
 MMENAB 002364 G
 MMPRES 002362 G
 MMSRO 002360 G
 MSG1 015626 G
 MSG2 015704 G
 MSG3 015763 G
 MSLCNT 002356 G
 MSLGET 020164 G

MSLOOP 020300 G
 MSTICK 002354 G
 NDERPT 002226 G
 NEWPAS 024620
 NEWRES 024612
 NEWSTA 024302
 NUMLNS 000020 G
 OOPS 020314 G
 OPTION 002224 G
 O#APTS 000000
 O#AU 000000
 O#BGNR 000001
 O#BGNS 000001
 O#DU 000001
 O#ERRT 000001
 O#GNSW 000001
 O#POIN 000001
 O#SETU 000000
 PAROA 002366 G
 PASCNT 002312 G
 PCSLOT 000016 G
 PNT 001000 G
 PREGRT 004020 G
 PREG05 003776
 PRI 002000 G
 PRI00 000000 G
 PRI01 000040 G
 PRI02 000100 G
 PRI03 000140 G
 PRI04 000200 G
 PRI05 000240 G
 PRI06 000300 G
 PRI07 000340 G
 PUFIFO 020542 G
 RBUFA 002244 G
 RDPDR 020624 G
 REGTST 021076 G
 REPSMR 021330 G
 RESETT 021356 G
 RMATBB 002262 G
 ROLDAP 021470 G
 RSTRPT 021514 G
 RXBRR 023756 G
 RXIEO 022212 G
 RXIE1 022252 G
 RXINPT 024036 G
 RXINTC 002314 G
 RXINTF 002316 G
 RXTHA 002244 G
 RXVECA 002232 G
 ROSLOT 000002 G
 R1SLOT 000004 G
 R2SLOT 000006 G
 R3SLOT 000010 G
 R4SLOT 000012 G
 R5SLOT 000014 G
 SAVBMP 022276 G

SFPTBL 002224 G
 SKPSTS 022344 G
 SVCGBL 000000
 SVCINS 000001
 SVCSUB 000001
 SVCTAG 000001
 SVCTST 000001
 SWAPO 022422 G
 SWPTQ1 037130
 SWPTQ2 037204
 SWPTQ3 037255
 SWPTQ4 037310
 SLSYM 010000
 TIMER1 002344 G
 TIMER2 002346 G
 TIMER3 002350 G
 TNUM 000032 G
 TP4FLG 002320 G
 TP4RTN 024124 G
 TP4VEC 002322 G
 TSABRT 022472 G
 TSTNUM 002324 G
 TXAD1A 002254 G
 TXAD2A 002256 G
 TXBFCA 002260 G
 TXBFCO 000016 G
 TXDSBL 022604 G
 TXENBL 022700 G
 TXIEO 022774 G
 TXIE1 023034 G
 TXINTC 002326 G
 TXINTF 002330 G
 TXINTR 024146 G
 TXVECA 002234 G
 T#ARGC 000003
 T#CODE 001052
 T#ERRN 022125
 T#EXCP 000000
 T#FLAG 000050
 T#GMAN 000000
 T#HILI 177777
 T#LAST 000001
 T#LOLI 000000
 T#LSYM 010000
 T#LTNO 000032
 T#NEST 177777
 T#NSO 000000
 T#NS1 000005
 T#PTNU 000000
 T#SAVL 177777
 T#SEGL 177777
 T#SUBN 000000
 T#TAGL 177777
 T#TAGN 010062
 T#TEMP 000000
 T#TEST 000032
 T#TSTM 177777

TSTSTS= 000001	TSSOF= 010061	T17	032244 G	T3	025726 G	WAIBIC	023214 G
TSSAU = 010025	TSSW = 010001	T18	032434 G	T4	026172 G	WAIBIS	023270 G
TSSAUT= 010022	TSTES= 010057	T19	032752 G	T5	026370 G	WDPDR	023344 G
TSSCLE= 010023	T1	T2	025214 G	T6	026562 G	WORD1	002332 G
TSSDU = 010024	T10	T20	027610 G	T7	027000 G	WTWLC	023552 G
TSSMAR= 010760	T11	T21	030024 G	T8	027206 G	WTWLP	023602 G
TSSMW = 010000	T12	T22	030252 G	T9	027414 G	X\$ALWA=	000000
TSSINI= 010021	T13	T23	030546 G	UAM	000200 G	X\$FALS=	000040
TSSMSG= 010016	T14	T24	031034 G	UNBTB	002370 G	X\$OFFS=	000400
TSSPRO= 010020	T15	T25	031434 G	UNITN	002236 G	X\$TRUE=	000020
TSSRPT= 010017	T16	T26	031776 G	UNSDIV	023060 G	\$PATCH	037400 G

. ABS. 037454 000
000000 001
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 28661 WORDS (112 PAGES)
DYNAMIC MEMORY: 20060 WORDS (77 PAGES)
ELAPSED TIME: 00:05:14
CZDHUBO.BIN,CZDHUBO.LST/-SP=SVC34R/ML,CZDHUBO.P11