

.REM 6

IDENTIFICATION

PRODUCT CODE: AC T796B MC
PRODUCT NAME: CZDMVBO DMU 11 FUNC TST PART2
PRODUCT DATE: 3 MARCH 1984
MAINTAINER: ENE - DIAGNOSTICS GROUP
AUTHOR: ANTHONY HART
MODIFIED BY: ANTHONY HART

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE OR EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1984 BY DIGITAL EQUIPMENT CORPORATION
THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

***** MODIFICATION HISTORY *****

ORIGINAL RELEASE:	15 DEC 83	ANTHONY HART
VERSION B0	3-MAR-84	ANTHONY HART

THE FOLLOWING MODIFICATIONS HAVE BEEN MADE TO THE OLD CZDHVA:

THE HARDWARE QUESTION "TYPE OF LOOPBACK" HAS BEEN ALTERED TO INCLUDE THE STAGGERED LOOPBACK CONNECTORS ON THE DMU11 DISTRIBUTION PANEL (H3029).

THE HARDWARE QUESTION "BR LEVEL" HAS BEEN REMOVED.

THE MODEM SIGNAL TESTS THAT WERE IN THE OLD VERSION (CZDHVA0) HAVE NOW BEEN REMOVED TO PART CZDHV. THEY WERE TESTS: 16 THRU 23. IN CZDHVA0.

THE FOLLOWING NEW TESTS HAVE BEEN ADDED TO THIS PART:

- TEST 13 - RXTIMER REGISTER TEST
- TEST 14 - TX_ACTION FIFO TEST
- TEST 15 - TX_FIFO TEST

TABLE OF CONTENTS

- 1.0 GENERAL PROGRAM CONSIDERATIONS
- 1.1 PROGRAM ABSTRACT
- 1.2 SYSTEM REQUIREMENTS
- 1.3 RELATED DOCUMENTS AND STANDARDS
- 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES
- 2.0 OPERATING INSTRUCTIONS
- 2.1 COMMANDS
- 2.2 SWITCHES
- 2.3 FLAGS
- 2.4 EXTENDED COMMAND SYNTAX
- 2.4.1 START COMMAND
- 2.4.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>)
- 2.4.1.2 PASS SWITCH (/PASS:<PASS-CNT>)
- 2.4.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.1.4 END OF PASS SWITCH (/EOP:<INCR>)
- 2.4.1.5 EFFECT OF START COMMAND
- 2.4.2 RESTART COMMAND
- 2.4.2.1 TESTS, PASS, AND FLAGS SWITCHES
- 2.4.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>)
- 2.4.2.3 EFFECT OF RESTART COMMAND
- 2.4.3 CONTINUE COMMAND
- 2.4.3.1 FLAG SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.3.2 EFFECT OF CONTINUE COMMAND
- 2.4.4 PROCEED COMMAND
- 2.4.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.4.2 EFFECT OF PROCEED COMMAND
- 2.4.5 ADD COMMAND
- 2.4.6 EFFECT OF ADD COMMAND
- 2.4.7 DROP COMMAND
- 2.4.8 EFFECT OF DROP COMMAND
- 2.4.9 PRINT COMMAND
- 2.4.9.1 EFFECT OF PRINT COMMAND
- 2.4.10 DISPLAY COMMAND
- 2.4.10.1 EFFECT OF DISPLAY COMMAND
- 2.4.11 FLAGS COMMAND
- 2.4.11.1 EFFECT OF FLAGS COMMAND
- 2.4.12 ZFLAGS COMMAND
- 2.4.13 ZFLAGS COMMAND
- 2.4.14 CONTROL CHARACTERS
- 2.5 HARDWARE QUESTIONS
- 2.6 SOFTWARE QUESTIONS
- 2.7 EXTENDED P-TABLE DIALOGUE
- 2.8 QUICK START-UP PROCEDURE (XXDP*)
- 3.0 ERROR INFORMATION
- 3.1 TYPES OF ERROR MESSAGES
- 3.2 SPECIFIC ERROR MESSAGES
- 4.0 PERFORMANCE AND PROGRESS REPORTS
- 5.0 TEST SUMMARIES
- 6.0 EXAMPLE ERROR FREE PASS

1.0 GENERAL PROGRAM CONSIDERATIONS

1.1 PROGRAM ABSTRACT

CZDHVBO IS PART OF THE DMU-11 FUNCTIONAL VERIFICATION TEST. THIS PART OF THE TEST VERIFIES THAT THE MAJOR COMMUNICATIONS FUNCTIONS OF THE BOARD ARE FUNCTIONING CORRECTLY. THIS PROGRAM DOES NOT PERFORM EXTENSIVE DATA TRANSMISSION AND RECEPTION TESTS.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN THE OPERATING INSTRUCTIONS-COMMANDS OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

THE FOLLOWING HARDWARE IS REQUIRED TO RUN THE DMU FVT:

- 0 UNIBUS PROCESSOR WITH AT LEAST 32K BYTES OF MEMORY.
- 0 DMU BOARDS INSTALLED ON THE UNIBUS.
- 0 APPROPRIATE PROGRAM LOAD DEVICE SUPPORTING XXDP+ MEDIA OR A DOWN LINE LOADING SYSTEM.

1.3 RELATED DOCUMENTS AND STANDARDS

- 0 XXDP+ USER'S MANUAL - DESCRIBES THE RUNNING OF DIAGNOSTICS UNDER THE XXDP+ MONITOR.

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE PROCESSOR, THE UNIBUS, THE SYSTEM MEMORY, THE CONSOLE TERMINAL AND THE LOAD MEDIA ARE ASSUMED TO HAVE BEEN TESTED AND FOUND WORKING BEFORE THIS PROGRAM IS RUN.

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES.
FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES
(SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY
BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ^C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SEE PERFORMANCE AND PROGRESS REPORTS SECTION OF THIS DOCUMENT)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE FLAGS SECTION)
ZFLAGS	CLEAR ALL FLAGS (SEE FLAGS SECTION)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO
YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".
MORE INFORMATION CAN BE FOUND WITHIN THE SECTION LABELLED
EXTENDED COMMAND SYNTAX

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDDD	EXECUTE DDDDD PASSES (DDDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. SEE THE FLAGS SECTION OF THIS DOCUMENT.
/EOP:DDDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
MOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXR*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST
EVL	EXECUTE EVALUATION (ON DIAGNOSTICS WHICH HAVE EVALUATION SUPPORT)

*SEE THE ERROR INFORMATION SECTION OF THIS DOCUMENT.

SEE THE XXDP* USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

/FLAGS:LOE:IER:BOE

2.4 EXTENDED COMMAND SYNTAX

2.4.1 START COMMAND -

```
*****  
STA(RT)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:  
  <FLAG-LIST>/EOP:<INCR>  
*****
```

2.4.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>) -

<TEST-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.), SEPERATED BY COLONS, THAT SPECIFY THE TESTS TO BE EXECUTED. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS. ON THIS AND ALL SWITCHES, THE ANGLE BRACKETS <> ARE PUNCTUATION USED IN THE DEFINITION ONLY, AND ARE NOT TO BE TYPED BY THE OPERATOR. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

2.4.1.2 PASS SWITCH (/PASS:<PASS-CNT>) -

<PASS-CNT> IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS). THE DEFAULT IS NON-ENDING EXECUTION. IN THIS CASE, EXIT FROM THE PROGRAM IS ACCOMPLISHED EITHER BY TYPING A CONTROL/C OR BY OCCURANCE OF AN ERROR WITH THE HALT ON ERROR FLAG BEING SET. THE EXIT IS A RETURN TO COMMAND MODE. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

2.4.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPERATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

HOE	HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED.
LOE	LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR.
IER	INHIBIT ERROR REPORTING.
IBE	INHIBIT BASIC ERROR REPORTS.
IXE	INHIBIT EXTENDED ERROR REPORTS.
PRI	DIRECT ALL MESSAGES TO A LINE PRINTER.
PNT	PRINT NUMBER OF TEST BEING EXECUTED.
BOE	BELL ON ERROR (NOT RELATED TO BELL PROMPTING).
UAM	RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION (ILLEGAL FOR THIS DIAGNOSTIC).
ISR	INHIBIT STATISTICAL REPORTS.

IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC.
(HAS NO EFFECT IN THIS DIAGNOSTIC.)
LOT LOOP ON TEST.
THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE
CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT
GIVEN ALL FLAGS ARE CLEARED. SEE EXAMPLE AT END OF "EFFECT OF START
COMMAND" SECTION.

2.4.1.4 END OF PASS SWITCH (/EOP:<INCR>) -

<INCR> IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF
PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE
DEFAULT IS AT THE END OF EVERY PASS. SEE EXAMPLE AT END OF "EFFECT OF
START COMMAND" SECTION.

2.4.1.5 EFFECT OF START COMMAND -

THE EFFECT OF THE START COMMAND IS TO INITIATE THE HARDWARE
PARAMETER DIALOGUE, THE SOFTWARE PARAMETER DIALOGUE, THE
INITIALIZATION QUESTIONS, AND THEN THE DIAGNOSTIC COMMENCES TESTING.

THE HARDWARE PARAMETER DIALOGUE COMMENCES WITH THE QUESTION "0
UNITS (D) ?" TO WHICH THE OPERATOR SHOULD REPLY WITH THE NUMBER OF
UNITS TO BE TESTED. FOLLOWING THIS ARE THE QUESTIONS WHEREBY THE
P-TABLES THEMSELVES ARE BUILT. EACH P-TABLE IS A CORE-RESIDENT TABLE
CONTAINING ALL THE HARDWARE INFORMATION FOR ONE COMPLETE UNIT. EACH
QUESTION IS FOLLOWED BY THE RESPONSE RADIX (D FOR DECIMAL, B FOR
BINARY, O FOR OCTAL, L FOR YES/NO) IN PARENTHESES AND THE DEFAULT
VALUE AFTER THE PARENTHESES. FOR THE ACTUAL HARDWARE P-TABLE
QUESTIONS SEE THE "HARDWARE PARAMETERS" SECTION.

FOLLOWING THE HARDWARE QUESTIONS ARE THE SOFTWARE QUESTIONS TO
BUILD THE SOFTWARE TABLES, WHICH DEFINE OPERATING PARAMETERS OF THE
DIAGNOSTIC PROGRAM. THESE QUESTIONS ARE DESCRIBED IN THE "SOFTWARE
PARAMETERS" SECTION.

EXAMPLE:

STA/TESTS:1:3-4:/PASS:3/FLAGS:IER:H0E=1

THIS COMMAND WILL CAUSE THREE PASSES TO BE MADE, WITH EACH PASS
CONSISTING OF TESTS 1,3, AND 4. THERE IS NO DIFFERENCE BETWEEN SAYING
<FLAG> AND SAYING <FLAG=1>. THE NOTATION <FLAG=0> IS MEANINGFUL ONLY
ON A COMMAND OTHER THAN START TO CLEAR A FLAG THAT WAS PREVIOUSLY SET.
NOTE THAT ON ALL COMMANDS ONLY THE FIRST THREE LETTERS ARE SCANNED.

2.4.2 RESTART COMMAND -

RES(TART)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:
<FLAG-LIST>/UNITS:<UNIT-LIST>

2.4.2.1 TESTS, PASS, AND FLAGS SWITCHES

<TEST-LIST>, <PASS CNT>, AND <FLAG LIST> ARE AS IN THE START
COMMAND.

2.4.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>) - <UNIT-LIST> IS A SEQUENCE
OF DECIMAL NUMBERS (0,1 ETC.) OR RANGES OF DECIMAL NUMBERS (0-5, 8-10
ETC.) THAT SPECIFY THE UNITS TO BE TESTED. THE NUMBERS ARE SEPARATED
BY COLONS. THE NUMBERS MAY RANGE FROM 0 THRU N-1 (N IS THE NUMBER OF
UNITS SPECIFIED IN THE PREVIOUS START COMMAND). THE NUMBER INDICATES
THE POSITION OF THE P-TABLE AS THE DATA WAS ENTERED DURING THE
HARDWARE DIAGLOGUE. THE UNITS WHICH ARE SELECTED MUST NOT HAVE BEEN
DROPPED BY THE DROP COMMAND. SEE THE DISCUSSION OF ADD AND DROP
COMMANDS BELOW. DEFAULT IS TO TEST ALL UNITS WHICH HAVE NOT BEEN
DROPPED BY A DROP COMMAND.

2.4.2.3 EFFECT OF RESTART COMMAND -

THE RESTART COMMAND DIFFERS FROM THE START COMMAND IN THAT THE
P-TABLES FROM THE PREVIOUS START COMMAND (THERE MUST HAVE BEEN ONE)
ARE USED, INSTEAD OF NEW ONES BEING BUILT. THE UNITS SWITCH SHOULD
NOT BE USED WITH THIS PROGRAM. THE SOFTWARE DIALOGUE MAY OPTIONALLY
BE REEXECUTED (OPERATOR WILL BE ASKED). THE COMMAND CAN BE USED AFTER
COMMAND MODE HAS BEEN REENTERED IN ANY OF THE THREE NORMAL WAYS: A)
THE REQUESTED NUMBER OF PASSES HAVE BEEN MADE, B) AN ERROR WAS
ENCOUNTERED WITH THE HALT ON ERROR FLAG SET, OR C) A CONTROL/C WAS
ENTERED BY THE OPERATOR.

2.4.3 CONTINUE COMMAND -

CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG-LIST>

2.4.3.1 FLAG SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS SAME AS IN THE START COMMAND. BUT UNSPECIFIED
FLAGS RETAIN THEIR CURRENT VALUE.

2.4.3.2 EFFECT OF CONTINUE COMMAND

CONTINUE MUST FOLLOW A START OR RESTART, AND COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

2.4.4 PROCEED COMMAND

PRO(CCEED)/FLAGS:<FLAG-LIST>

2.4.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS AS IN THE START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

2.4.4.2 EFFECT OF PROCEED COMMAND -

PROCEED MUST FOLLOW A START, RESTART, OR CONTINUE. COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS MAY BE ALTERED.

2.4.5 ADD COMMAND -

ADD/UNITS:<UNIT-LIST>

2.4.6 EFFECT OF ADD COMMAND -

THE UNITS SPECIFIED ARE ADDED TO THE TEST SEQUENCE. EACH UNIT MUST HAVE A P-TABLE IN MEMORY DUE TO AN EARLIER HARDWARE DIALOGUE. THIS COMMAND MUST BE FOLLOWED BY A RESTART OR CONTINUE. THE UNITS SWITCH MUST BE SPECIFIED. THE ADD COMMAND IS MEANINGFUL ONLY FOR UNITS THAT WERE PREVIOUSLY DROPPED.

2.4.7 DROP COMMAND -

DRO(P)/UNITS:<UNIT LIST>

2.4.8 EFFECT OF DROP COMMAND
THE UNITS SPECIFIED WILL BE DROPPED FROM TESTING. THE UNITS
WILL BE RESELECTED ONLY BY THE EXECUTION OF AN ADD OR START
COMMAND. THE UNITS SWITCH MUST BE ENTERED. THIS COMMAND
MUST BE FOLLOWED BY A RESTART OR A CONTINUE COMMAND.

2.4.9 PRINT COMMAND

PRI(NT)

2.4.9.1 EFFECT OF PRINT COMMAND -
THE TOTAL NUMBER OF ERRORS FOR EACH UNIT SINCE THE LAST
START OR RESTART COMMAND ARE PRINTED. THE ISR (INHIBIT
STATISTICAL REPORTING) FLAG IS CLEARED.

2.4.10 DISPLAY COMMAND -

DIS(PLAY)/UNITS:<UNIT-LIST>

2.4.10.1 EFFECT OF DISPLAY COMMAND -
THE HARDWARE P-TABLE FOR THE TEST STATION IS PRINTED IN THE
FORMAT IN WHICH IT WAS ENTERED.

2.4.11 FLAGS COMMAND -

FLA(GS)

2.4.11.1 EFFECT OF FLAGS COMMAND -
THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

2.4.12 ZFLAGS COMMAND -

ZFL(AGS)

2.4.13 ZFLAGS COMMAND -

ALL FLAGS ARE CLEARED.

2.4.14 CONTROL CHARACTERS -

- C A CONTROL/C (C) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES A RETURN TO COMMAND MODE.

- Z A CONTROL/Z (Z) ENTERED DURING ONE OF THE TWO OPERATOR DIALOGUES-- HARDWARE P-TABLE DIALOGUE OR SOFTWARE P-TABLE DIALOGUE CAUSES THE DEFAULTS TO BE TAKEN FOR THE REMAINDER OF THAT DIALOGUE.

- O A CONTROL/O (O) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES ALL TELETYPE OUTPUT TO BE SURPRESSED FOR THE REMAINDER OF THE DIAGNOSTIC OR UNTIL ANOTHER CONTROL/O IS TYPED, WHICH RESTORES NORMAL TELETYPE OUTPUT.

2.5 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 6 OF THE XXDP USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL). YOU WILL THEN BE ASKED THE FOLLOWING QUESTIONS FOR EACH UNIT.

1. CSR ADDRESS - THIS QUESTION REQUESTS THE CSR ADDRESS OF THE SPECIFIED DMU-11. THE DEFAULT ANSWER FOR THIS QUESTION IS ADDRESS 160460 (OCTAL).
2. INTERRUPT VECTOR ADDRESS - THIS QUESTION REQUESTS THE INTERRUPT VECTOR ADDRESS OF THE SPECIFIED DMU-11. THE DEFAULT ANSWER IS 310 (OCTAL).
3. ACTIVE LINES BIT MAP - THIS QUESTION REQUESTS AN OCTAL BIT MAP OF THE SERIAL COMMUNICATION LINES ON THE DMU11 WHICH ARE BEING SELECTED FOR TESTING. IF THE BIT IN THE BIT MAP IS SET WHICH CORRESPONDS TO A PARTICULAR LINE (I.E. BIT 5 FOR LINE 5) THAT LINE WILL BE TESTED BY THE FVT.
4. TYPE OF LOOPBACK (1=INTERNAL, 2=H3029 OR H3277) - THIS QUESTION REQUESTS THE TYPE OF LOOPBACK TO BE USED WHEN TESTING THE DMU-11. THE FOLLOWING TYPES ARE SUPPORTED:
 - 0 INTERNAL - ONLY INTERNAL UART LOOPBACK IS TO BE USED IN TESTING THE DMU-11.
 - 0 H3029 OR H3277 - STAGGERED LOOPBACK CONNECTORS ARE PROVIDED ON THE DMU11 DISTRIBUTION PANEL (H3029) IF THIS DISTRIBUTION PANEL IS NOT PRESENT THEN H3277 STAGGERED BERG CONNECTOR(S) MUST BE INSTALLED ON THE BERG CONNECTOR SOCKETS OF THE DMU11.
 - 0 H325 - SINGLE LINE, 25 PIN LOOPBACK CONNECTORS (TYPE H325) ARE INSTALLED ON THE LINES TO BE TESTED.

2.6 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

1. REPORT UNIT NUMBER AS EACH UNIT IS TESTED - THIS QUESTION ASKS WHETHER THE PROGRAM SHOULD REPORT THE NUMBER OF THE UNIT WHICH IT IS TESTING AS IT BEGINS TO TEST THAT UNIT.
2. EXTENDED ERROR REPORTING - THIS QUESTION ASKS WHETHER EXTENDED ERROR INFORMATION IS REQUIRED OTHER THAN THE "TEST FAILED" MESSAGE, ON EACH ERROR REPORTED. THE DEFAULT IS "NO" I.E. ONLY A MESSAGE REPORTING THE FACT THAT THE TEST FAILED WILL BE PRINTED.
3. NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE - THIS QUESTION IS ASKED ONLY IF THE PREVIOUS QUESTION WAS ANSWERED "YES". THE QUESTION ASKS FOR THE NUMBER OF DATA ERRORS WHICH SHOULD BE REPORTED INDIVIDUALLY BY THIS PROGRAM FOR EACH LINE FOR EACH TRANSMISSION TEST. ERRORS WHICH ARE NOT REPORTED INDIVIDUALLY ARE REPORTED IN SUMMARY ERROR REPORTS.

2.7 EXTENDED P-TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A FICTIONAL DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q-FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

* UNITS (0) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0<CR>
Q-FACTOR (0) 0 ? 1<CR>

UNIT 2
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 1<CR>
Q FACTOR (0) 1 ? 0<CR>

UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 4
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 3<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 5
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 4<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 6
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 5<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6<CR>
Q FACTOR (0) 0 ? 1<CR>


```
UNIT 8  
CSR ADDRESS (0) 160000<CR>  
SUB-DEVICE # (0) ? 7<CR>  
Q-FACTOR (0) 1 ? <CR>
```

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER. LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION FEATURE.

```
# UNITS (0) ? 8<CR>
```

```
UNIT 1  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 0,1<CR>  
Q-FACTOR (0) 0 ? 1,0<CR>
```

```
UNIT 3  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 2-5<CR>  
Q-FACTOR (0) 0 ? 0<CR>
```

```
UNIT 7  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 6,7<CR>  
Q-FACTOR (0) 0 ? 1<CR>
```

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

```
# UNITS (0) ? 8<CR>
```

```
UNIT 1
```

CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0 7<CR>
Q-FACTOR (0) 0 ? 0.1,0....1.1<CR>

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING
A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

2.8 QUICK START-UP PROCEDURE (XXDP.)

TO START UP THIS PROGRAM:

1. BOOT XXDP.
2. GIVE THE DATE AND ANSWER THE LSI/UNIBUS AND 50HZ (IF THERE IS A CLOCK) QUESTIONS. NOTE, NOT ALL VERSIONS OF XXDP. ASK FOR THE CLOCK FREQUENCY
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE
DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. FOR DEFAULT INFORMATION
SEE THE SECTIONS WITHIN THIS DOCUMENT ON FLAGS, AND HARDWARE QUESTIONS.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SEE THE FLAGS SECTION OF THIS DOCUMENT).

THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX  
ERROR MESSAGE
```

.WHERE: NAME = DIAGNOSTIC NAME
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
NUMBER = ERROR NUMBER
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SEE THE FLAGS SECTION OF THIS DOCUMENT). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXR" FLAGS ARE SET (SEE THE FLAGS SECTION OF THIS DOCUMENT). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

THIS PROGRAM IS INTENDED TO PROVIDE A GO/NOGO INDICATION OF THE FUNCTIONALITY OF THE DHU-11 BOARDS. TO EXECUTE THE PROGRAM IN THIS MODE THE OPERATOR NEED ONLY ANSWER THE "EXTENDED ERROR REPORTING" SOFTWARE QUESTION WITH "NO". THE PROGRAM WILL THEN ONLY PRINT THE NAME OF THE FAILING TEST THE TEST AND ERROR NUMBERS. FOR A LIST OF THE TEST NAMES IN THIS PROGRAM SEE THE TEST SUMMARIES SECTION OF THIS DOCUMENT. AN EXAMPLE OF SUCH A AN ERROR MESSAGE IS THE FOLLOWING:

```
CZDHV DVC FTL ERR 04106 ON UNIT 00 TST 003 SUB 000 PC: XXXXXX  
DMA_ABORT BIT TEST FAILED
```

THIS ERROR INDICATES THAT A FATAL ERROR WAS ENCOUNTERED DURING THE TEST WHICH TESTS THE DMA_ABORT BIT.

IF THE OPERATOR HAD REQUESTED EXTENDED ERROR REPORTING THE SAME ERROR WOULD BE REPORTED AS FOLLOWS:

```
CZDHV DVC FTL ERR 04106 ON UNIT 00 TST 003 SUB 000 PC: XXXXXX  
DMA_ABORT BIT TEST FAILED  
DMA_START BIT FOUND SET AFTER DMA ABORTED ON LINE: 8
```

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. FOR FUTHER INFORMATION SEE THE SWITCHES SECTION OF THIS DOCUMENT.

5.0 TEST SUMMARIES

THE FOLLOWING ARE INCLUDED WITHIN CZDMVB:

1. DEVICE REGISTER ACCESS TEST - VERIFIES THAT THE UUT REGISTERS WILL RESPOND WITH THE CORRECT UNIBUS HANDSHAKING SIGNALS. VERIFIES THAT THE UUT IS AT THE CORRECT ADDRESS.
2. DMA.START TEST - VERIFIES THAT EACH DMA START BIT WILL INITIATE A DMA TRANSMISSION ON A LINE
3. DMA.ABORT TEST - VERIFIES THAT EACH DMA ABORT BIT WILL STOP A DMA TRANSMISSION, RETURN A TX.ACTION AND SUCCESSFULLY RESTART THE DMA.
4. DMA.ERROR TEST - VERIFIES THAT THE DMA ERROR BIT IN THE CSR REPORTS DMA ERRORS CORRECTLY WHEN THEY OCCUR.
5. O.AUTO INACTIVE TEST - VERIFIES THAT THE DUT WILL NOT RESPOND TO INCOMING XON AND XOFF CHARACTERS WHEN O.AUTO IS CLEAR.
6. O.AUTO ACTIVE TEST - VERIFIES THAT THE DUT RESPONDS CORRECTLY TO INCOMING FLOW CONTROL CHARACTERS WHEN ACTIVE
7. I.AUTO INACTIVE TEST - VERIFIES THAT THE DUT WILL NOT GENERATE XON AND XOFF CHARACTERS IN RESPONSE TO THE APPROPRIATE FIFO CONDITIONS WHEN I.AUTO IS INACTIVE.
8. I.AUTO ACTIVE TEST - VERIFIES THAT THE DUT WILL GENERATE XON AND XOFF CHARACTERS IN RESPONSE TO THE APPROPRIATE FIFO CONDITIONS WHEN I.AUTO IS ACTIVE.
9. FIFO DATA TEST - VERIFIES THAT THE FIFO WILL HOLD 256 CHARACTERS WITHOUT CORRUPTING DATA.
10. FIFO 3/4 LEVEL INACTIVE TEST - VERIFIES THAT THE 3/4 LEVEL ALARM DOES NOT BECOME ACTIVE BELOW THE 3/4 LEVEL.
11. FIFO 3/4 LEVEL ACTIVE TEST - VERIFIES THAT THE 3/4 LEVEL ALARM BECOMES ACTIVE WHEN THE FIFO IS 3/4 FULL.
12. FIFO 3/4 LEVEL ACTIVE/INACTIVE TEST - VERIFIES THAT THE 3/4 LEVEL ALARM, ONCE ACTIVATED, REMAINS ACTIVE UNTIL THE FIFO IS REDUCED BELOW THE 1/2 LEVEL.
13. FIFO 1/2 LEVEL TEST - VERIFIES THAT THE FIFO 1/2 LEVEL ALARM SYSTEM BECOMES ACTIVE AND INACTIVE AT THE CORRECT LEVELS.
14. RXTIMER TEST - VERIFIES THAT THE HOLD OFF TIMER FOR RX INTERRUPTS IS OPERATING CORRECTLY, AND THAT THE 3/4 FULL LEVEL OVERRIDES THE TIMER.

15. TX ACTION FIFO TEST - VERIFIES THAT THE TX ACTION FIFO CAN HOLD 16 UNIQUE TX-ACTIONS, AND THAT ONLY ONE TX INTERRUPT OCCURS FOR ALL 16 TX-ACTIONS.
16. TX FIFO TEST - VERIFIES THAT THE FIFO WILL 64 UNIQUE CHARACTERS AND ALSO THAT ONLY ONE INTERRUPT OCCURS FOR ALL 64 CHARACTERS.
17. BREAK GENERATION TEST - VERIFIES THAT ALL SERIAL TRANSMIT LINES CAN GENERATE A BREAK BY SETTING THE BRK BIT IN THE ASSOCIATED LNCTRL REGISTER.
18. NO OVERRUN ERROR TEST - VERIFIES THAT THE DUT WILL NOT REPORT DATA OVERRUN ERRORS WHEN THEY DO NOT OCCUR.
19. OVERRUN ERROR TEST - VERIFIES THAT THE DUT WILL REPORT DATA OVERRUN ERRORS WHEN THEY OCCUR.
20. REPORT BMP CODES TEST - THIS PSEUDO TEST REPORTS THE FIRST 32 CHARACTERS WHICH WERE DISCOVERED IN THE FIFO DURING THE EXECUTION OF THE OTHER TESTS. THIS AVOIDS INTERRUPTION OF THE OTHER TESTS BY THESE CODES IF THEY ARE NOT CRITICAL TO THE PERFORMANCE OF THE TESTS.

6.0 EXAMPLE ERROR FREE PASS

THE FOLLOWING IS AN EXAMPLE OF AN ERROR FREE PASS DIALOGUE:

```
.R CZDHSV0
CZDHSV0.BIN
DRS
CZDHSV-B-0
DHU-11 FUNC TST PART2
UNIT IS DHU-11
RESTRT ADDR: 147670
DR>STA/PAS:1

CHANGE HW (L) ? Y

# UNITS (D) ? 2

UNIT 0
CSR ADDRESS: (0) 160460 ? +Z

UNIT 1
CSR ADDRESS: (0) 160460 ? 160500
INTERRUPT VECTOR ADDRESS: (0) 310 ? 320
ACTIVE LINE BIT MAP: (0) 177777 ? <CR>
TYPE OF LOOPBACK (1=INTERNAL, 2=H3029 OR H3277): (0) 2 ? 1

CHANGE SW (L) ? Y

REPORT UNIT NUMBER AS EACH UNIT IS TESTED: (L) Y ? <CR>
EXTENDED ERROR REPORTING: (L) N ? <CR>

TESTING UNIT : 0

TESTING UNIT : 1

CZDHSV EOP      1
0 TOTAL ERRS

DR>
```

1050
1051
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1112
1113

000000

000001
000001
000001
000001
000001

002000

002000

002000

103
132
104
110
126
000
000
000
102
060
000000
002014

```

.LIST SEQ,LOC,RIN,MEB
.NLIST CND

.SBTTL PROGRAM HEADER

.MCALL SVC ; INITIALIZE SUPERVISOR MACROS
SVC

;*****
; IF STRUCTURED MACROS ARE TO BE USED, ADD ".MCALL STRUCT" AND "STRUCT"
; TO INITIALIZE THE STRUCTURED MACROS.
;*****

SVCINS= 1 ; LIST INSTRUCTIONS, SHIFTED RIGHT
SVCTST= 1 ; LIST TEST TAGS, SHIFTED RIGHT
SVCSUB= 1 ; LIST SUBTEST TAGS, SHIFTED RIGHT
SVCGBL= 1 ; LIST GLOBAL TAGS, SHIFTED RIGHT
SVCTAG= 1 ; LIST OTHER TAGS, SHIFTED RIGHT

; CHANGE THE VALUES OF THE SVC... SYMBOLS TO BE ZERO IF YOU WISH
; TO ALIGN THE MACRO CALLS AND THEIR EXPANSIONS. CHANGE THE
; SYMBOLS TO BE MINUS-ONE TO NOT LIST THE EXPANSIONS. YOU MAY
; CHANGE THE SYMBOLS AT ANY POINT IN YOUR PROGRAM.
;*****

.ENABL ABS
;.ENABL AMA
. = 2000

BGNMOD

;+
; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
;--

POINTER BGNRPT,BGNSW,BGNSFT,BGNDU,ERRTBL

HEADER CZDHY,B,0,22,0,PRI07

L$NAME::
.ASCII /C/
.ASCII /Z/
.ASCII /D/
.ASCII /M/
.ASCII /V/
.BYTE 0
.BYTE 0
.BYTE 0

L$REV::
.ASCII /B/

L$DEPO::
.ASCII /O/

L$UNIT::
.WORD 0

L$TIML::

```


002014 000022
 002016
 002016 035156
 002020
 002020 035404
 002022
 002022 002176
 002024
 002024 002210
 002026
 002026 035706
 002030
 002030 000C00
 002032
 002032 000000
 002034
 002034 000000
 002036
 002036 000000
 002040
 002040 002124
 002042
 002042 000340
 002044
 002044 000000
 002046
 002046 000000
 002050
 002050 003
 002051 003
 002052
 002052 000000
 002054 000000
 002056
 002056 000000
 002060
 002060 004120
 002062
 002062 020030
 002064
 002064 000000
 002066
 002066 000000
 002070
 002070 000000
 002072
 002072 020704
 002074
 002074 000000
 002076
 002076 004130
 002100
 002100 104035
 002102
 002102 004050
 002104
 002104 020044

L\$MPCP:: .WORD 22
 L\$SPCP:: .WORD L\$HARD
 L\$MPTP:: .WORD 1 \$SOFT
 L\$SPTP:: .WORD L\$HW
 L\$LADP:: .WORD L\$SW
 L\$STA:: .WORD L\$LAST
 L\$CO:: .WORD 0
 L\$DTYP:: .WORD 0
 L\$APT:: .WORD 0
 L\$DTP:: .WORD 0
 L\$PRIO:: .WORD L\$DISPATCH
 L\$ENVI:: .WORD PRI07
 L\$EXP1:: .WORD 0
 L\$MREV:: .WORD 0
 L\$EF:: .BYTE C\$REVISION
 .BYTE C\$EDIT
 L\$SPC:: .WORD 0
 L\$DEVP:: .WORD 0
 L\$REPP:: .WORD L\$DVTYP
 L\$EXP4:: .WORD L\$RPT
 L\$EXP5:: .WORD 0
 L\$AUT:: .WORD 0
 L\$DUT:: .WORD 0
 L\$LUN:: .WORD L\$DU
 L\$DESP:: .WORD 0
 L\$LOAD:: .WORD L\$DESC
 EMT E\$LOAD
 L\$ETP:: .WORD L\$ERRTBL
 L\$ICP:: .WORD L\$INIT

PROGRAM HEADER

002106
002106 020666
002110
002110 020664
002112
002112 020036
002114
002114 000000
002116
002116 000000
002120
002120 000000

1114

L\$CCP:: .WORD L\$CLEAN
L\$ACP:: .WORD L\$AUTO
L\$PRT:: .WORD L\$PROT
L\$TEST:: .WORD 0
L\$DLY:: .WORD 0
L\$HIME:: .WORD 0

1126
1127
1128
1129
1130
1131
1132
1133

.SBTTL DISPATCH TABLE

; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
*-

DISPATCH 20

002122
002122 000024
002124
002124 021022
002126 021304
002130 021710
002132 022346
002134 022674
002136 023474
002140 024274
002142 024716
002144 025410
002146 025716
002150 026226
002152 026726
002154 027424
002156 030102
002160 031152
002162 031740
002164 032766
002166 033412
002170 034130
002172 035074

.WORD 20
L\$DISPATCH:;
.WORD T1
.WORD T2
.WORD T3
.WORD T4
.WORD T5
.WORD T6
.WORD T7
.WORD T8
.WORD T9
.WORD T10
.WORD T11
.WORD T12
.WORD T13
.WORD T14
.WORD T15
.WORD T16
.WORD T17
.WORD T18
.WORD T19
.WORD T20

1134

1149
 1150
 1151
 1152
 1153
 1154
 1155
 1156
 1157
 1158
 1159
 1160 002174
 002174 000004
 002176
 002176
 1161
 1162 002176 160460
 1163 002200 000310
 1164 002202 177777
 1165 002204 002
 1166
 1167 002206
 002206

.SBTTL DEFAULT HARDWARE P TABLE

```

; * *
; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
; THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
; IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P TABLES,
; AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.
; -
    
```

BGNHW DFPTBL

```

        .WORD L10000 L$HW/2
L$HW::
DFPTBL::
    
```

```

        .WORD 160460 ;DEFAULT CSR ADDRESS
        .WORD 310   ;DEFAULT VECTOR ADDRESS
        .WORD 177777 ;DEFAULT ACTIVE LINES BIT MAP
        .BYTE 2    ;DEFAULT LOOPBACK MODE
        .EVEN
    ENDPW
    
```

L10000:

1176
 1177
 1178
 1179
 1180
 1181
 1182
 1183
 1184
 1185
 1186
 1187
 1188
 1189
 1190
 1191
 1192

002206
 002206 000002
 002210
 002210
 002210 000020
 002212 000000
 002214
 002214

.SBTTL SOFTWARE P TABLE

```

; *
; THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
; PROGRAM AS OPERATIONAL PARAMETERS. THESE PARAMETERS ARE
; SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
; AT RUN TIME.
; --
    
```

BGNSW SFPTBL

```

        .WORD L10001-L$SW/2
L$SW::
SFPTBL::
    
```

```

OPTION::      .WORD 20      ;BIT MAP OF PROGRAM CONTROL FLAGS
NDERPT::     .WORD 0       ;DEFAULT NUMBER OF INDIVIDUAL DATA ERPORS TO RPT.
    
```

ENDSW

L10001:

1201
1202
1203
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1256

002214

.SBTTL GLOBAL EQUATES SECTION

```

; **
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
; **
    
```

```

NUMLNS==20 ;NUMBER OF LINES ON DHU11 IS 8.
MAPLNS==17777 ;BIT MAP OF LINES ON DHU11.
    
```

```

;***** DEVICE REGISTER OFFSETS FROM THE CSR'S ADDRESS *****
CSR0==0 ;CSR REGISTER OFFSET FROM THE CSR ADDRESS
RBUF0==2 ;RECEIVE REGISTER OFFSET FROM THE CSR ADDRESS
RXTIM0==2 ;RECEIVE TIMER REGISTER OFFSET FROM THE CSR ADDRESS
LPRO==4 ;LINE PARAMETER REGISTER OFFSET FROM THE CSR ADDRESS
FSLSO==6 ;FIFO SIZE/STATUS REGISTER OFFSET FROM THE CSR ADDRESS
FDATA==6 ;FIFO DATA REGISTER OFFSET FROM THE CSR ADDRESS
LNCTR0==10 ;LINE CONTROL REGISTER OFFSET FROM THE CSR ADDRESS
TXAD10==12 ;TRANSMIT ADDRESS 1 REGISTER OFFSET FROM THE CSR ADDRESS
TXAD20==14 ;TRANSMIT ADDRESS 2 REGISTER OFFSET FROM THE CSR ADDRESS
TXBFC0==16 ;TRANSMIT COUNT REGISTER OFFSET FROM THE CSR ADDRESS
    
```

```

;***** EQUATES USED WITH RESPECT TO THE RX BUFFER *****
RXBETX==16. ;LEVEL OF RX BUFFER AT WHICH TO RE-ENABLE TRANSMISSION.
RXBDTX==24. ;LEVEL OF RX BUFFER AT WHICH TO DISABLE TRANSMISSION.
RXBFUL==64. ;TOTAL CHARACTER CAPACITY OF THE RX BUFFER.
    
```

EQUALS

```

; BIT DEFINITIONS
    
```

```

100000 BIT15== 100000
040000 BIT14== 40000
020000 BIT13== 20000
010000 BIT12== 10000
004000 BIT11== 4000
002000 BIT10== 2000
001000 BIT09== 1000
000400 BIT08== 400
000200 BIT07== 200
000100 BIT06== 100
000040 BIT05== 40
000020 BIT04== 20
000010 BIT03== 10
000004 BIT02== 4
000002 BIT01== 2
000001 BIT00== 1

001000 BIT9== BIT09
000400 BIT8== BIT08
000200 BIT7== BIT07
000100 BIT6== BIT06
    
```

```

000040          BITS-- BIT05
000020          BIT4-- BIT04
000010          BIT3-- BIT03
000004          BIT2-- BIT02
000002          BIT1-- BIT01
000001          BIT0-- BIT00
;
; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;
000040          EF.START--      32.          ; START COMMAND WAS ISSUED
000037          EF.RESTART--   31.          ; RESTART COMMAND WAS ISSUED
000036          EF.CONTINUE--  30.          ; CONTINUE COMMAND WAS ISSUED
000035          EF.NEW--       29.          ; A NEW PASS HAS BEEN STARTED
000034          EF.PWR--       28.          ; A POWER FAIL/POWER-UP OCCURRED
;
; PRIORITY LEVEL DEFINITIONS
;
000340          PRI07-- 340
000300          PRI06-- 300
000240          PRI05-- 240
000200          PRI04-- 200
000140          PRI03-- 140
000100          PRI02-- 100
000040          PRI01-- 40
000000          PRI00-- 0
;
; OPERATOR FLAG BITS
;
000004          EVL--      4
000010          LOT--     10
000020          ADR--     20
000040          IDU--     40
000100          ISR--    100
000200          UAM--    200
000400          BOE--    400
001000          PNT--   1000
002000          PRI--   2000
004000          IXE--   4000
010000          IBE--  10000
020000          IER--  20000
040000          LOE--  40000
100000          MOE-- 100000

```

1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322

002214 000200
002216 000204
002220 177777
002222 000
002223 004
002224 000000

002226 160020
002230 160022
002232 160024
002234 160026

002236 160030
002240 160032
002242 160034
002244 160036

002246 000000
002250 000000
002252 000000
002254 000001
002256 000000
002260 031463
002262 146314
002264 000000
002266 000000
002270 000000
002272 000000
002274 000000
002276 000000
002300 000000
002302 000000

002304 177546
002306 000300

.SBTTL GLOBAL DATA SECTION

```

; **
; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
; IN MORE THAN ONE TEST.
; --
    
```

```

; *****
; UNIT VARIABLE AREA
; *****
    
```

```

RXVECA:: .WORD 200 ;RX VECTOR ADDRESS.
TXVECA:: .WORD 204 ;TX VECTOR ADDRESS.
ACTLNS:: .WORD 177777 ;ACTIVE LINE BIT MAP.
LOPBCK:: .BYTE 0 ;LOOPBACK MODE
BRLEVL:: .BYTE 4 ;INTERRUPT BUS REQUEST LEVEL
UNITN:: .WORD 0 ;UNIT NUMBER.
    
```

```

; *****
; DEVICE REGISTER ADDRESS TABLE
; *****
    
```

```

DRADRT::
CSRA:: .WORD 160020 ;DMU-11 CSR ADDRESS.
RXTMA:: RBUFA:: .WORD 160022 ;DMU-11 RECIEVE BUFFER/TIMER ADDRESS.
LPRA:: .WORD 160024 ;DMU-11 LINE PARAMETER REGISTER ADDRESS.
FDATA:: FLSA:: .WORD 160026 ;DMU-11 FIFO SIZE/LINE STATUS REGISTER ADDRESS.
;AND FIFO DATA REGISTER ADDRESS.
LNCTRA:: .WORD 160030 ;DMU-11 LINE CONTROL REGISTER ADDRESS.
TXAD1A:: .WORD 160032 ;DMU-11 TRANSMIT BUFFER 1 REGISTER ADDRESS
TXAD2A:: .WORD 160034 ;DMU-11 TRANSMIT BUFFER 2 REGISTER ADDRESS
TXBFCA:: .WORD 160036 ;DMU-11 TRANSMIT BUFFER COUNT REGISTER ADDRESS
    
```

```

; *****
; ASSORTED GLOBAL VARIABLES:
; *****
    
```

```

BUFPTR:: .WORD 0 ;STORAGE FOR RECEIVE CHARACTER BUFFER POINTER.
CTRLCF:: .WORD 0 ;STORAGE FOR THE CONTROL-C FLAG.
EXOERR:: .WORD 0 ; "EXIT ON ERROR" FLAG.
TSTNUM:: .WORD 1 ;STORAGE FOR THE TEST NUMBER.
IESTAT:: .WORD 0 ;STORAGE FOR STATES OF THE OUT INT ENABLE BITS.
LGRP1M:: .WORD 31463 ;BIT MAP OF LINES IN LINE GROUP I.
LGRP2M:: .WORD 146314 ;BIT MAP OF LINES IN LINE GROUP II.
PASCNT:: .WORD 0 ;STO'G FOR PASS COUNT USED IN ROM VERSION# TST.
RXINTC:: .WORD 0 ;STORAGE FOR RECEIVER INTERRUPT FLAGS.
RXINTF:: .WORD 0 ;STORAGE FOR RECEIVER INTERRUPT FLAGS.
TXINTC:: .WORD 0 ;STORAGE FOR TRANSMIT INTERRUPT COUNT.
TXINTF:: .WORD 0 ;STORAGE FOR TRANSMIT INTERRUPT FLAGS.
TP4VEC:: .WORD 0 ;STORAGE FOR THE NORMAL 004 TRAP VECTOR.
TP4FLG:: .WORD 0 ;FLAGS SET WHEN AN EXPECTED 004 TRAP OCCURS.
WORD1:: .WORD 0 ;LOCATION FOR PASSING INDIRECT PARAMETERS.
    
```

```

; *****
; LINE TIME CLOCK VARIABLES AND STORAGE.
; *****
CLKCSR:: .WORD 177546 ;CSR ADDRESS OF THE LTC.
CLKBRL:: .WORD PRI06 ;INTERRUPT PRIORITY LEVEL OF THE LTC.
    
```



```

1323 002310 000100 CLKVEC:: .WORD 100 ;INTERRUPT VECTOR ADDRESS OF THE LTC.
1324 002312 000074 CLKHRZ:: .WORD 60. ;INTERRUPT FREQUENCY OF THE LTC.
1325 002314 000000 TIMER1:: .WORD 0 ;HARDWARE CLOCK COUNTER #1.
1326 002316 000000 TIMER2:: .WORD 0 ;HARDWARE CLOCK COUNTER #2.
1327 002320 000170 TIMER3:: .WORD 120. ;HARDWARE BREAK COUNTER LOCATION.
1328 002322 000170 BCOUNT:: .WORD 120. ;BREAK COUNT VALUE IN CLOCK TICKS.
1329 002324 000021 MSTICK:: .WORD 17. ;NUMBER OF MILLI-SECONDS PER LTC TICK.
1330 002326 000062 MSLCNT:: .WORD 62 ;LOOP COUNT (USED BY MSLOOP) TO DELAY 1 MS.

```

```

1331
1332 ;*****
1333 ; MEMORY MANAGEMENT VARIABLES AND FLAGS.
1334 ;*****

```

```

1335 002330 177572 MMSRO:: .WORD 177572 ;ADDRESS OF MEM MGT STATUS REGISTER #0.
1336 002332 000000 MMPRES:: .WORD 0 ;MEM MGT PRESENT FLAG (0 IF MM NOT PRESENT).
1337 002334 000000 MMENAB:: .WORD 0 ;MEM MGT ENABLED FLAG (0 IF MM NOT ENABLED).

```

```

1338
1339 ;*****
1340 ; TABLE OF WORDS WITH CORRESPONDING BIT SET FOR GENERATION OF BIT MAPS.
1341 ;*****

```

```

1342 002336 000001 BITTBL:: .WORD 1 ;BIT 0 SET.
1343 002340 000002 .WORD 2 ;BIT 1 SET.
1344 002342 000004 .WORD 4 ;BIT 2 SET.
1345 002344 000010 .WORD 10 ;BIT 3 SET.
1346 002346 000020 .WORD 20 ;BIT 4 SET.
1347 002350 000040 .WORD 40 ;BIT 5 SET.
1348 002352 000100 .WORD 100 ;BIT 6 SET.
1349 002354 000200 .WORD 200 ;BIT 7 SET.
1350 002356 000400 .WORD 400 ;BIT 8 SET.
1351 002360 001000 .WORD 1000 ;BIT 9 SET.
1352 002362 002000 .WORD 2000 ;BIT 10 SET.
1353 002364 004000 .WORD 4000 ;BIT 11 SET.
1354 002366 010000 .WORD 10000 ;BIT 12 SET.
1355 002370 020000 .WORD 20000 ;BIT 13 SET.
1356 002372 040000 .WORD 40000 ;BIT 14 SET.
1357 002374 100000 .WORD 100000 ;BIT 15 SET.

```

```

1358
1359 ;*****
1360 ;* GPR SAVE AREAS ZERO AND ONE.
1361 ;*****

```

```

1362 002376 GPRS0B:: .WORD 0 ;BASE OF GPR SAVE AREA NUMBER ZERO.
1363 002376 000000 .WORD 0 ;WORD 1, STORAGE FOR R1.
1364 002400 000000 .WORD 0 ;WORD 2, STORAGE FOR R2.
1365 002402 000000 .WORD 0 ;WORD 3, STORAGE FOR R3.
1366 002404 000000 .WORD 0 ;WORD 4, STORAGE FOR R4.
1367 002406 000000 .WORD 0 ;WORD 5, STORAGE FOR R5.

```

```

1368 ;*****
1369 ; STORAGE AREA FOR THE BMP CODE QUEUE.
1370 ;*****

```

```

1371 002410 000000 BMPCQP:: .WORD 0 ;POINTER USED TO ACCESS THE NEXT CELL IN QUE.
1372 002412 BMPCQB:: .BLKW 64. ;STORAGE FOR 32 CELLS, TEST# PLUS BMP CODE.
1373 002612 BMPCQE:: ;LAST ADDRESS PLUS 2 OF THE BMP CODE QUEUE.

```

```

1374
1375 ;*****
1376 ; STORAGE AREA FOR ERROR SUMMARY TABLE AND FLAGS.
1377 ;*****

```

```

1378 002612 000000 ERSMRF:: .WORD 0 ;ERROR SUMMARY FLAGS.
1379 002614 ERCNTB:: .BLKW 16 ;TABLE OF ERROR COUNTS.

```

```

1380
1381
1382 ;*****
; GENERAL TABLE AND BUFFER AREA--513 WORDS.
1383 ;*****
1384 002650 BUFBAS:: ;BASE OF MEMORY BUFFER.
1385 002650 ERLTBL:: .BLKW 128. ;FIRST HALF OF GENERAL TABLE OR BUFFER.
1386 003250 DUFMID:: .BLKW 64. ;SECOND HALF OF GENERAL TABLE OR BUFFER.
1387 003450 BUF3QT:: .BLKW 64. ;LAST QUARTER OF THE BUFFER AREA.
1388 003650 BUFEND:: ;END OF GENERAL PURPOSE MEMORY BUFFER.
1389 003650 ENDETB:: .BLKW 16. ;BUFFER OVERFLOW SPACE.
1390
1391 ;*****
1392 ; RECEPTION TABLE OF COUNTERS
1393 ;*****
1394 003710 RXCNTB:: .BLKW 16. ;RECEPTION CHARACTER COUNTERS TABLE.
1395
1396 ;*****
1397 ;* TABLE FOR STORAGE OF RX/TX LINE NUMBER ASSOCIATIONS.
1398 ;* THE ASSOCIATIONS ARE STORED AS LINE NUMBER TIMES 2 FOR USE AS OFFSETS
1399 ;* WHEN ACCESSING A TABLE OF WORDS.
1400 ;* NOTE: DO NOT WRITE A NON-ZERO VALUE INTO THE UPPER BYTE OF ANY ENTRY.
1401 ;*****
1402 003750 TXRXLB:: ;BASE OF TX/RX LINE NUMBER ASSOCIATION TABLE.
1403 003750 000000 .WORD 0 ;TX/RX LINE OFFSET FOR RX/TX LINE 0.
1404 003752 000002 .WORD 2. ;TX/RX LINE OFFSET FOR RX/TX LINE 1.
1405 003754 000004 .WORD 4. ;TX/RX LINE OFFSET FOR RX/TX LINE 2.
1406 003756 000006 .WORD 6. ;TX/RX LINE OFFSET FOR RX/TX LINE 3.
1407 003760 000010 .WORD 8. ;TX/RX LINE OFFSET FOR RX/TX LINE 4.
1408 003762 000012 .WORD 10. ;TX/RX LINE OFFSET FOR RX/TX LINE 5.
1409 003764 000014 .WORD 12. ;TX/RX LINE OFFSET FOR RX/TX LINE 6.
1410 003766 000016 .WORD 14. ;TX/RX LINE OFFSET FOR RX/TX LINE 7.
1411 003770 000020 .WORD 16. ;TX/RX LINE OFFSET FOR RX/TX LINE 8.
1412 003772 000022 .WORD 18. ;TX/RX LINE OFFSET FOR RX/TX LINE 9.
1413 003774 000024 .WORD 20. ;TX/RX LINE OFFSET FOR RX/TX LINE 10.
1414 003776 000026 .WORD 22. ;TX/RX LINE OFFSET FOR RX/TX LINE 11.
1415 004000 000030 .WORD 24. ;TX/RX LINE OFFSET FOR RX/TX LINE 12.
1416 004002 000032 .WORD 26. ;TX/RX LINE OFFSET FOR RX/TX LINE 13.
1417 004004 000034 .WORD 28. ;TX/RX LINE OFFSET FOR RX/TX LINE 14.
1418 004006 000036 .WORD 30. ;TX/RX LINE OFFSET FOR RX/TX LINE 15.
1419 004010 TXRXLE:: ;END OF TX/RX LINE NUMBER ASSOCIATION TABLE.
1420 .EVEN ;GUARANTEE THAT NEXT TABLE IS ON WORD BOUNDARY.
1421 ;*****
1422 ;* TABLE FOR STORAGE OF RX/TX LINE NUMBER ASSOCIATIONS.
1423 ;* THE ASSOCIATIONS ARE STORED AS LINE NUMBERS WHICH CAN BE USED AS SUCH OR
1424 ;* AS OFFSETS WHEN ACCESSING A TABLE OF BYTES.
1425 ;*****
1426 004010 TXRLNB:: ;BASE OF TX/RX LINE NUMBER ASSOCIATION TABLE.
1427 004010 000 .BYTE 0 ;TX/RX LINE FOR RX/TX LINE 0.
1428 004011 001 .BYTE 1. ;TX/RX LINE FOR RX/TX LINE 1.
1429 004012 002 .BYTE 2. ;TX/RX LINE FOR RX/TX LINE 2.
1430 004013 003 .BYTE 3. ;TX/RX LINE FOR RX/TX LINE 3.
1431 004014 004 .BYTE 4. ;TX/RX LINE FOR RX/TX LINE 4.
1432 004015 005 .BYTE 5. ;TX/RX LINE FOR RX/TX LINE 5.
1433 004016 006 .BYTE 6. ;TX/RX LINE FOR RX/TX LINE 6.
1434 004017 007 .BYTE 7. ;TX/RX LINE FOR RX/TX LINE 7.
1435 004020 010 .BYTE 8. ;TX/RX LINE FOR RX/TX LINE 8.
1436 004021 011 .BYTE 9. ;TX/RX LINE FOR RX/TX LINE 9.

```

1437 004022 012
 1438 004023 013
 1439 004024 014
 1440 004025 015
 1441 004026 016
 1442 004027 017
 1443 004030
 1444
 1445
 1446
 1447
 1448
 1449
 1450
 1451
 1452 004030
 1453 004030 004
 1454 004031 006
 1455 004032 000
 1456 004033 002
 1457 004034 014
 1458 004035 016
 1459 004036 010
 1460 004037 012
 1461 004040 024
 1462 004041 026
 1463 004042 020
 1464 004043 022
 1465 004044 034
 1466 004045 036
 1467 004046 030
 1468 004047 032
 1469
 1482 004050
 004050
 004050 000000
 004052 000000
 004054 000000
 004056 000000
 1483
 1484

```

        .BYTE 10.      ;TX/RX LINE FOR RX/TX LINE 10.
        .BYTE 11.      ;TX/RX LINE FOR RX/TX LINE 11.
        .BYTE 12.      ;TX/RX LINE FOR RX/TX LINE 12.
        .BYTE 13.      ;TX/RX LINE FOR RX/TX LINE 13.
        .BYTE 14.      ;TX/RX LINE FOR RX/TX LINE 14.
        .BYTE 15.      ;TX/RX LINE FOR RX/TX LINE 15.
TXRLNE::
        .EVEN          ;END OF TX/RX LINE NUMBER ASSOCIATION TABLE.
                        ;GUARANTEE THAT NEXT TABLE IS ON WORD BOUNDARY.
;*****
;* TABLE OF TX/RX LINE NUMBER ASSOCIATIONS IN STAGGERED LOOPBACK.
;* THE ASSOCIATIONS ARE STORED AS LINE NUMBER TIMES 2 FOR USE AS OFFSETS
;* WHEN ACCESSING A TABLE OF WORDS.
;* THIS IS A TABLE OF DATA FOR READING ONLY. USE TO LOAD THE ABOVE TABLE.
;* NOTE: MUST CONVERT FROM BYTES TO WORDS WHEN LOADING ABOVE TABLE.
;*****
STGRB::
        .BYTE 4.      ;BASE OF STAGGERED TX/RX LINE NUMBER TABLE.
        .BYTE 6.      ;TX/RX LINE OFFSET FOR RX/TX LINE 0.
        .BYTE 0       ;TX/RX LINE OFFSET FOR RX/TX LINE 1.
        .BYTE 2.      ;TX/RX LINE OFFSET FOR RX/TX LINE 2.
        .BYTE 12.     ;TX/RX LINE OFFSET FOR RX/TX LINE 3.
        .BYTE 14.     ;TX/RX LINE OFFSET FOR RX/TX LINE 4.
        .BYTE 8.      ;TX/RX LINE OFFSET FOR RX/TX LINE 5.
        .BYTE 10.     ;TX/RX LINE OFFSET FOR RX/TX LINE 6.
        .BYTE 20.     ;TX/RX LINE OFFSET FOR RX/TX LINE 7.
        .BYTE 22.     ;TX/RX LINE OFFSET FOR RX/TX LINE 8.
        .BYTE 16.     ;TX/RX LINE OFFSET FOR RX/TX LINE 9.
        .BYTE 18.     ;TX/RX LINE OFFSET FOR RX/TX LINE 10.
        .BYTE 28.     ;TX/RX LINE OFFSET FOR RX/TX LINE 11.
        .BYTE 30.     ;TX/RX LINE OFFSET FOR RX/TX LINE 12.
        .BYTE 24.     ;TX/RX LINE OFFSET FOR RX/TX LINE 13.
        .BYTF 26.     ;TX/RX LINE OFFSET FOR RX/TX LINE 14.
        .EVEN         ;TX/RX LINE OFFSET FOR RX/TX LINE 15.
        ERRTBL        ;GUARANTEE THAT NEXT TABLE IS ON WORD BOUNDARY.
                        L$ERRTBL::
ERRTYP::          .WORD 0
ERRNBR::          .WORD 0
ERRMSG::          .WORD 0
ERRBLK::          .WORD 0
        .EVEN
    
```

1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522

```
.SBTTL GPR HANDLING ROUTINES FOR SUBROUTINE CALLS.  
;*****  
;* THERE ARE 4 ROUTINES AND MACRO DEFINITIONS USED FOR THE HANDLING OF  
;* GPR VALUES DURING SUBROUTINE CALLS WITHIN THIS PROGRAM. THE FOUR  
;* ROUTINES/MACRO CALLS HAVE THE FOLLOWING NAMES:  
;*  
;* SAVE - MACRO DEFINITION USED AT THE BEGINNING OF A SUBROUTINE TO  
;* SAVE THE GPR CONTENTS FOR LATER RESTORATION.  
;* PASS - MACRO DEFINITION USED AT THE END OF A SUBROUTINE TO RESTORE  
;* THE PREVIOUSLY SAVED GPR CONTENTS AND TO LEAVE THE CONTENTS  
;* OF THE SPECIFIED GPR(S) INTACT (NOT RESTORED).  
;* PREGOS - SUBROUTINE WHICH IS CALLED FROM THE SAVE AND PASS MACRO  
;* EXPANSIONS WHICH ACTUALLY PERFORMS THE ACTIONS ON THE GPRS.  
;*  
;* DURING A SUBROUTINE WHICH USES THESE GPR SAVE ROUTINES THE VALUES  
;* OF THE GPRS ARE STORED ON THE STACK IN THE FOLLOWING STACK FRAME:  
;*  
;* SP -> RET PC INTO PREGOS ROUTINE.  
;* SP+2 -> GPR R0 CONTENTS.  
;* SP+4 -> GPR R1 CONTENTS.  
;* SP+6 -> GPR R2 CONTENTS.  
;* SP+8 -> GPR R3 CONTENTS.  
;* SP+10 -> GPR R4 CONTENTS.  
;* SP+12 -> GPR R5 CONTENTS.  
;* SP+14 -> RET PC INTO CALLER OF SUB'TNE WHICH CALLED PREGOS.  
;*  
;* EACH LEVEL OF SUB'TNE CALLING USES 8 WORDS OF STACK OVERHEAD.  
;* THE SAVE AND PASS MACROS CAN ALSO BE USED IN "STRAIGHT LINE CODE"  
;* TO SAVE AND RESTORE THE GPR VALUES. IN ANY CASE, AFTER THE  
;* ISSUING OF A PASS CALL THE GPRS WILL BE RESTORED TO THE VALUES  
;* THEY HAD PRIOR TO THE LAST SAVE CALL (EXCEPT FOR THE EXCEPTED,  
;* OR PASSED INTACT, GPRS SPECIFIED AS PARAMETERS TO THE PASS CALL)  
;* AND THE SP WILL ALSO BE RESTORED TO ITS CONDITION BEFORE THE LAST  
;* SAVE CALL. THE PROGRAMMER MUST BE SURE THAT THE SP HAS THE SAME  
;* VALUE WHEN THE PASS MACRO IS CALLED AS IT HAD IMMEDIATELY AFTER  
;* THE SAVE MACRO WAS CALLED.  
;*****
```

1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538

000036
000016
000014
000012
000010
000006
000004
000002

.SBTTL GPR FRAME ACCESS EQUATES

!+++
;EQUATES THAT ALLOW ACCESS TO THE STACK FRAME. THESE ARE THE
;OFFSETS INTO THE STACK FOR REGISTERS SAVED DURING THE PREG05
;ROUTINE.
!---
LPCSLT== 36 ;OFFSET FOR LAST RETURN PC.
PCSL0T== 16 ;OFFSET FOR RETURN PC.
R5SLOT== 14 ;OFFSET FOR R5.
R4SLOT== 12 ;OFFSET FOR R4.
R3SLOT== 10 ;OFFSET FOR R3.
R2SLOT== 6 ;OFFSET FOR R2.
R1SLOT== 4 ;OFFSET FOR R1.
ROSL0T== 2 ;OFFSET FOR R0.

1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563

```
.SBTTL GLOBAL MACRO DEFINITION SAVE
:*****
:* THIS MACRO IS USED AT THE BEGINNING OF A SUBROUTINE TO SAVE THE
:* CONTENTS OF THE GPRS R0 THRU R5.
:*
:* INPUTS: SP - UNCHANGED SINCE SUBROUTINE WAS ENTERED
:* R5SLOT - OFFSET TO STACK SLOT FOR R5 (EQUATED TO 14 OCTAL)
:*
:* OUTPUTS: GPR SAVE AREA ON THE STACK IS LOADED WITH THE CONTENTS OF GPRS
:* TOP OF STACK LOADED WITH THE RETURN ADDRESS INTO PREG05
:*
:* CALLING SEQUENCE: SAVE
:*
:* COMMENTS: NO ARGUMENTS ARE ALLOWED.
:* THE PASS MACRO SHOULD BE CALLED TO RESTORE THE GPR VALUES.
:*
:* SUBORDINATE ROUTINES CALLED: PREG05.
:*****
.MACRO SAVE
.LIST JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
.NLIST
.ENDM SAVE
```

1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612

```

.SBTTL GLOBAL MACRO DEFINITION - PASS -
*****
; * THIS MACRO IS USED IN CONJUNCTION WITH THE SAVE MACRO. IT IS
; * CALLED AT END OF A SUBROUTINE TO PASS PARAMETERS IN GPRS BACK TO THE
; * CALLING ROUTINE BY ALTERING THE GPR SAVE AREA ON THE STACK AND THEN
; * RETURNING TO PREGOS TO RESTORE THE GPRS TO THEIR SAVED VALUES.
; *
; * INPUTS: ONLY ALLOWED ARGUMENTS ARE "R0" THRU "R5".
; * ROSLOT THRU RSSLOT MUST BE EQUATED TO THEIR RESPECTIVE GPR SAVE
; * SLOT OFFSETS BEFORE CALLING THIS MACRO.
; *
; * OUTPUTS: THE GPR VALUES ARE PUT IN THEIR RESPECTIVE SLOTS ON THE STACK.
; *
; * CALLING SEQUENCE: PASS R0,R1,...
; *
; * COMMENTS: ANY COMBINATION OF GPR ARGUMENTS MAY BE LISTED IN ANY ORDER.
; * FOR EXAMPLE, THE FOLLOWING ARE LEGAL:
; * PASS R1
; * PASS R4,R0,R2
; * THE GPRS LISTED AS ARGUMENTS WILL BE PASSED INTACT TO THE
; * CALLING ROUTINE, ALL OTHER GPRS WILL BE RESTORED.
; * THE SP MUST BE AT ITS ORIGINAL VALUE WHEN PASS IS CALLED.
; *
; * THE MACRO CALL
; * PASS R0,R3
; * EXPANDS INTO THE FOLLOWING ASSEMBLY CODE:
; * MOV R0,ROSLOT(SP) ;PUT R0 IN STACK SLOT.
; * MOV R3,R3SLOT(SP) ;PUT R3 IN STACK SLOT.
; * JSR PC,8(SP) ;RETURN TO PREGOS SUBRT.
; * IN THIS EXAMPLE GPRS R1, R2, R4, AND R5 WILL BE RESTORED TO
; * THEIR VALUES CONTAINED IN THE STACK FRAME AND R0 AND R3
; * WILL BE LEFT AT THEIR VALUES PRIOR TO THIS PASS CALL.
; *
; * SUBORDINATE ROUTINES CALLED: (PREGRT - LABEL WITHIN PREGOS, VALUE ON STACK.)
; * *****

.MACRO PASS A,B,C,D,E,F
.IRP X,<A,B,C,D,E,F>
.IF NB,X
.LIST
MOV X,X'SLOT(SP) ;PUT X IN STACK SLOT.
.NLIST
.ENDC
.ENDM
.LIST
JSR PC,8(SP) ;RETURN TO PREGOS SUBRT.
.NLIST
.ENDM PASS

```

1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639 004060
1640 004060 010446
1641 004062 010346
1642 004064 010246
1643 004066 010146
1644 004070 010046
1645 004072 010546
1646 004074 016605 000014
1647
1648 004100 004736
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658 004102 012605
1659 004104 012600
1660 004106 012601
1661 004110 012602
1662 004112 012603
1663 004114 012604
1664
1665 004116 000205
1666

```

.SBTTL GLOBAL SUBROUTINE                                PREG'5
;*****
; PRESERVE REGISTERS R0 THROUGH R5 FOR SUBROUTINE CALLS.
;
; INPUTS:      THE RETURN ADDRESS BACK INTO THE CALLING ROUTINE MUST BE IN
;              GPR R5. (I.E. - MACROS USE "JSR R5,PREG'5".)
;
; OUTPUTS:     REGISTERS R0 THROUGH R5 ARE SAVED ON THE STACK.
;
; CALLING SEQUENCE:  SAVE          ;MACRO EXPANSION CALLS PREG'5.
;                   [SUBROUTINE CODE]...
;                   PASS          ;MACRO EXPANSION RECALLS PREG'5.
;
; COMMENTS:     THIS ROUTINE IS RE-ENTRANT.
;
;               PARAMETERS MAY BE PASSED OUT OF A SUBROUTINE BY MODIFYING THE
;               REGISTER SAVE AREA ON THE STACK.  USE THE PASS GPRN MACRO
;               TO RETURN GPR VALUES INTACT.
;               USE THE RNSLOT OFFSETS FROM THE SP TO PASS OTHER PARAMETERS.
;               [EXAMPLE:  MOV  VALUE,R0SLOT(SP) ]
;               MAKE SURE THE SP IS AT ITS ORIGINAL VALUE WHEN YOU DO THIS.
;
; SUBORDINATE ROUTINES CALLED:  NONE.
;*****
PREG'5:
;R5 HAS BEEN LOADED ON THE STACK BY THE SUBROUTINE CALL
MOV     R4,(SP)      ;SAVE R4
MOV     R3,(SP)      ;SAVE R3
MOV     R2,.(SP)     ;SAVE R2
MOV     R1,.(SP)     ;SAVE R1
MOV     R0,.(SP)     ;SAVE R0
MOV     R5,.(SP)     ;PUSH RETURN PC ON TOP OF STACK
MOV     R5SLOT(SP),R5 ;RESTORE R5 TO VALUE IT HAD BEFORE CALLS
JSR     PC,@(SP)     ;CALL THE SUBROUTINE AT THE RETURN ADDRESS
;FROM THE PREG'5 CALL, PUTTING THE PRESENT
;PC ON THE STACK AS A RETURN ADDRESS INTO
;THIS (PREG'5) ROUTINE.

;---
;THE FOLLOWING CODE IS EXECUTED WHEN THE CALLING ROUTINE DOES A
;"RETURN" [JSR PC,@(SP).] USING THE PC DEPOSITED ON THE STACK ABOVE.
;---
PREGRT:; MOV     (SP),R5      ;PUT RETURN PC IN R5.
        MOV     (SP),R0      ;RESTORE R0.
        MOV     (SP),R1      ;RESTORE R1.
        MOV     (SP),R2      ;RESTORE R2.
        MOV     (SP),R3      ;RESTORE R3.
        MOV     (SP),R4      ;RESTORE R4.
RTS     R5                ;RETURN TO THE SUBROUTINE WHICH CALLED PREG'5.
;RESTORING R5 IN THE PROCESS.

```


1668
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687

004120				
004120				
004120	104	110	125	
004123	055	061	061	
004126	000			

.SBTTL GLOBAL TEXT SECTION

```

;***
; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
; MORE THAN ONE TEST.
;---

```

```

;
; NAMES OF DEVICES SUPPORTED BY PROGRAM
;
      DEVTYP <DHU-11>

```

```

L$DVTYP::
      .ASCIZ /DHU-11/

      .EVEN

```

1688
1694
1695
1696
1697

004130				
004130				
004130	104	110	125	
004133	055	061	061	
004136	040	106	125	
004141	116	103	040	
004144	124	123	124	
004147	040	120	101	
004152	122	124	062	
004155	000			

```

; TEST DESCRIPTION
;
      DESCRIPT      <DHU 11 FUNC TST PART2>

```

```

L$DESC::
      .ASCIZ /DHU-11 FUNC TST PAR

```

T2/

.EVEN

.EVEN

1698
1699
1706

```
1715
1716      .NLIST BIN
1717
1718
1719      ; ***** FORMAT STATEMENTS USED IN PRINT CALLS *****
1720
1721
1722 004156 EF0503:: .ASCIZ /#T#N/
1723 004163 EF1601:: .ASCIZ /#A #T#A, TEST ABORTED #N/
1724 004215 EF5801:: .ASCIZ /#A      RXTIMER VALUE USED WAS :#D3#A (D)#N/
1725 004270 EF5901:: .ASCIZ /#A      EXPECTED :#D3#A(D)#N/
1726 004320 EF5902:: .ASCIZ /#A      ACTUAL   :#D3#A(D)#N/
1727 004350 EF6401:: .ASCIZ /#A                                     #D2#N/
1728 004417 EF7801:: .ASCIZ /#T#A ON LINE #D2#A DECIMAL.#N/
1729 004455 EF9001:: .ASCIZ /#A UNEXPECTED #T#A FOUND IN RECEIVE CHAR FIFO:#N/
1730 004537 EF9002:: .ASCIZ /#A      CODE IS ASSOCIATED WITH LINE: #D2#N/
1731 004611 EF9003:: .ASCIZ /#A      CODE IS: #D3#N/
1732 004640 EF9004:: .ASCIZ /#A      #T#A VALUE: #D3#N/
1733 004670 EF9005:: .ASCIZ /#A      #T#A VALUE: NONE#N/
1734 004721 EF9006:: .ASCIZ /#A      #T#A #D2#A(D)#N/
1735 004745 EF9010:: .ASCIZ /#A      NUMBER OF ERRORS DETECTED ON LINE #D2#A IS #D5#N/
1736 005034 EF9019:: .ASCIZ /#A      #T#A #D6#N/
1737 005053 EF9301:: .ASCIZ /#A #T#D2#A(D), BMP CODE REPORTED :#D3#A(O)#N/
1738 005131 EF9302:: .ASCIZ /#A      OVERFLOW OCCURRED (MORE THAN 31 BMP CODES FOUND IN QUEUE)#N/
1739 005231 MFUNIT:: .ASCIZ /#N#A TESTING UNIT :#D4#N/
1740      .EVEN
1741      .LIST BIN
```

```

1750
1751      .NLIST BIN
1752
1753
1754      ;***** GLOBAL ERROR MESSAGES *****
1755
1756 005262 EM0103:: .ASCIZ /DEVICE REGISTER ACCESS ERRORS/
1757 005320 EM1601:: .ASCIZ /TIMEOUT OCCURRED WAITING FOR MASTER RESET TO CLEAR/
1758 005403 EM4001:: .ASCIZ /DMA_START BIT TEST FAILED/
1759 005435 EM4002:: .ASCIZ /DMA_START BIT BAD ON LINE: /
1760 005471 EM4101:: .ASCIZ /DMA_ABORT BIT TEST FAILED/
1761 005523 EM4102:: .ASCIZ /DMA_ABORT BIT BAD ON LINE: /
1762 005557 EM4103:: .ASCIZ /DMA_START BIT FOUND SET AFTER DMA ABORTED ON LINE: /
1763 005643 EM4201:: .ASCIZ /DMA_ERROR BIT TEST FAILED/
1764 005675 EM4202:: .ASCIZ /DMA_ERROR BIT BAD/
1765 005717 EM4901:: .ASCIZ /OAUTO (INACTIVE) BIT TEST FAILED/
1766 005760 EM4902:: .ASCIZ / OAUTO BIT BAD ON LINE: /
1767 006012 EM5001:: .ASCIZ /OAUTO (ACTIVE) BIT TEST FAILED/
1768 006051 EM5101:: .ASCIZ /IAUTO (INACTIVE) TEST FAILED/
1769 006106 EM5102:: .ASCIZ /IAUTO BIT FOUND SET ON LINE: /
1770 006144 EM5103:: .ASCIZ /IAUTO BIT BAD ON LINE: /
1771 006174 EM5201:: .ASCIZ /IAUTO (ACTIVE) TEST FAILED/
1772 006227 EM5202:: .ASCIZ /IAUTO BIT FOUND CLR ON LINE: /
1773 006265 EM5301:: .ASCIZ /FIFO VALID DATA TEST FAILED/
1774 006321 EM5302:: .ASCIZ /FIFO BAD, DATA FIELD CORRUPTED, TEST USED LINE:/
1775 006401 EM5303:: .ASCIZ /BMP CODE FOUND IN FIFO, TEST INVAILEDATED/
1776 006452 EM5401:: .ASCIZ \FIFO 3/4 ALARM (INACTIVE) TEST FAILED\
1777 006520 EM5402:: .ASCIZ /FIFO BAD, ALARM SIGNAL DEFECTIVE/
1778 006561 EM5501:: .ASCIZ \FIFO 3/4 ALARM (ACTIVE) TEST FAILED\
1779 006625 EM5601:: .ASCIZ \FIFO 3/4 ALARM (ACTIVE/INACTIVE) TEST FAILED\
1780 006702 EM5701:: .ASCIZ \FIFO 1/2 LEVEL (ACTIVE/INACTIVE) TEST FAILED\
1781 006757 EM5801:: .ASCIZ /RXTIMER TEST FAILED/
1782 007003 EM5802:: .ASCIZ /RXTIMER BAD, RX-INT DELAYED BY WRONG NUMBER OF MILLISECONDS/
1783 007077 EM5803:: .ASCIZ \RXTIMER BAD, RX-INT DIDN'T OCCUR IMMEDIATELY WITH RXFIFO 3/4 FULL\
1784 007201 EM5804:: .ASCIZ /RXTIMER BAD, RX-INT OCCURED WITH RXTIMER VALUE ZERO/
1785 007265 EM5805:: .ASCIZ /RXTIMER BAD, TIME-OUT OCCURED WAITING FOR RX-INT/
1786 007346 EM5901:: .ASCIZ / TX-ACTION FIFO TEST FAILED/
1787 007402 EM5902:: .ASCIZ / TX_ACTION FIFO BAD, TX-ACTION RECIEVED FROM THE WRONG LINE/
1788 007476 EM5903:: .ASCIZ / TX_ACTION FIFO BAD, INCORRECT NUMBER OF TX-ACTIONS FOUND/
1789 007570 EM5904:: .ASCIZ / TX_ACTION FIFO BAD, TX-ACTION FIFO WOULD NOT EMPTY/
1790 007654 EM5905:: .ASCIZ / TX INTERRUPT OCCURED AFTER THE TX_ACTION FIFO HAD BEEN EMPTIED/
1791 007754 EM6001:: .ASCIZ /TX FIFO TEST FAILED/
1792 010000 EM6002:: .ASCIZ /INCORRECT VALUE IN FIFOSIZE REG/
1793 010040 EM6003:: .ASCIZ /MORE THAN ONE TX-INT OCCURED, FROM A FULL TXFIFO/
1794 010120 EM6004:: .ASCIZ /TX FIFO BAD, RECIEVED CHAR INCORRECT/
1795 010165 EM6005:: .ASCIZ /TX FIFO BAD, CHARACTER RECIEVED ON WRONG LINE/
1796 010243 EM6006:: .ASCIZ /TX FIFO BAD, TOO FEW CHARS RECIEVED/
1797 010307 EM6401:: .ASCIZ /BREAK GENERATION TEST FAILED/
1798 010344 EM6402:: .ASCIZ / BREAK NOT RECEIVED ON LINE(S):/
1799 010405 EM6601:: .ASCIZ /NO OVERRUN ERROR TEST FAILED/
1800 010442 EM6602:: .ASCIZ / OVERRUN ERROR REPORTED WHEN NONE FORCED/
1801 010514 EM6701:: .ASCIZ /OVERRUN ERROR TEST FAILED/
1802 010546 EM6702:: .ASCIZ / NO OVERRUN ERROR REPORTED, OVERRUN FORCED/
1803 010623 EM9009:: .ASCIZ /EXPECTED OR CORRECT/
1804 010647 EM9010:: .ASCIZ /ACTUAL OR MEASURED /
1805 010673 EM9014:: .ASCIZ /SUMMARY REPORTS FOR LINES WITH EXCESSIVE NUMBERS OF ERRORS:/
1806 010767 EM9017:: .ASCII / FIFO WILL NOT PURGE (DATA.VALID STUCK SET),/

```

1807 011044 .ASCIZ / REMAINDER OF TEST SKIPPED./
1808 011100 EM9026:: .ASCIZ / LPR CONTENTS: /
1809 011124 EM9104:: .ASCIZ / UNEXPECTED DATA FOUND IN FIFO FROM LINE: /
1810 011200 EM9301:: .ASCIZ /BMP CODES WERE REPORTED DURING THIS DIAGNOSTIC/
1811 011257 EM9302:: .ASCIZ /BMP CODE FOUND IN TEST /
1812 011307 EM9303:: .ASCIZ /THE LAST BMP CODE WAS FOUND IN TEST /
1813 011354 EM9304:: .ASCIZ /UNEXPECTED BMP CODES FOUND DURING THIS PASS/
1814 .EVEN
1815 .LIST BIN

GLOBAL TEXT SECTION

1824
1825
1826
1827
1828
1829
1830
1831
1832

.SBTTL GLOBAL ERROR REPORT SECTION

!++
; THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS
; USED BY MORE THAN ONE TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB
; (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
!--

1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER0101 -
;*****
; THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
; INFORMATION IF AN ERROR IS DETECTED IN TEST 1 (REGISTER ADDRESS
; ACCESS TEST). IF THE "EXTENDED ERROR INFO" OPTION HAS BEEN SELECTED
; THEN THIS SUBROUTINE WILL REPORT THE TYPE OF ACCESS (READ OR WRITE OR
; BOTH) WHICH CAUSED A BUS TIME-OUT TRAP (004 TRAP). A MESSAGE INDICATING
; THAT THE DHU MAY BE AT THE WRONG UNIBUS ADDRESS IS ALSO PRINTED.
;
; INPUTS:      R5 - ERROR FLAG WORD.
;              IF BIT 0 IS SET, A READ ERROR OCCURED.
;              IF BIT 1 IS SET, A WRITE ERROR OCCURED.
;
; OUTPUTS:     MESSAGES ARE PRINTED AT THE OPERATOR CONSOLE.
;
; CALLING SEQUENCE:  INCLUDE THE LABEL "ER0101" AS THE MESSAGE POINTER
;                    PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
;
; COMMENTS:
;
; SUBORDINATE ROUTINES USED: NONE.
;*****
```

1856
1857 011430
011430
1858 011430
011430 004567 172424
1859
1860 011434 012700 000100
1861 011440 046700 170544
1862 011444 001036
1863
1864
1865
1866
1867 011446 032705 000001
1868 011452 001410
1869 011454
011454 012746 011546
011460 012746 000001
011464 010600
011466 104414
011470 062706 000004
1870 011474 032705 000002
1871 011500 001410
1872 011502
011502 012746 011624
011506 012746 000001
011512 010600
011514 104414
011516 062706 000004
1873 011522
011522 012746 011703
011526 012746 000001
011532 010600
011534 104415
011536 062706 000004

```
          BGNMSG ER0101
          ER0101::
SAVE          ;SAVE THE GPR CONTENTS.
          JSR   R5,PREG05 ;CALL REGISTER SAVE SUBRT.
          MOV   #BIT06,R0 ;SET-UP THE BIT MAP FOR 'REPORT EXT'D ERROR INFO'
          BIC   OPTION,R0 ;TRY AND CLEAR THE FLAG.
          BNE   6$ ;EXIT IF OPTION NOT SELECTED.
;
; REPORT EXTENDED ERROR INFOMATION
;
          BIT   #BIT0,R5 ;TEST FOR READ ERROR.
          BEQ   2$ ;SKIP READ ERROR MSG IF NO READ ERROR.
          PRINTB #MSG1 ;PRINT READ ERROR MESSAGE.
          MOV   #MSG1,-(SP)
          MOV   #1,(SP)
          MOV   SP,R0
          TRAP  C$PNTB
          ADD   #4,SP
2$:         BIT   #BIT1,R5 ;TEST FOR WRITE ERROR.
          BEQ   4$ ;SKIP WRITE ERROR MSG IF NO WRITE ERROR.
          PRINTB #MSG2 ;PRINT WRITE ERROR MESSAGE.
          MOV   #MSG2,-(SP)
          MOV   #1,-(SP)
          MOV   SP,R0
          TRAP  C$PNTB
          ADD   #4,SP
4$:         PRINTX #MSG3 ;SUGGEST THAT DHU MAY BE AT WRONG ADDRESS.
          MOV   #MSG3,(SP)
          MOV   #1,(SP)
          MOV   SP,R0
          TRAP  C$PNTX
          ADD   #4,SP
```

```
1874 011542          6#:  PASS          ;RESTORE THE GPR CONTENTS.  
      011542 004736          JSR          PC,0(SP);RETURN TO PREGOS SUBRT.  
1875 011544          ENDMSG          L10002: TRAP C#MSG  
      011544 104423  
1876  
1877 011546          045          101          102 MSG1:: .ASCIZ /#ABUS TIME-OUT TRAP CAUSED BY READ ATTEMPT.#N/  
      011551          125          123          040  
      011554          124          111          115  
      011557          105          055          117  
      011562          125          124          040  
      011565          124          122          101  
      011570          120          040          103  
      011573          101          125          123  
      011576          105          104          040  
      011601          102          131          040  
      011604          122          105          101  
      011607          104          040          101  
      011612          124          124          105  
      011615          115          120          124  
      011620          056          045          116  
      011623          000  
1878 011624          045          101          102 MSG2:: .ASCIZ /#ABUS TIME OUT TRAP CAUSED BY WRITE ATTEMPT.#N/  
      011627          125          123          040  
      011632          124          111          115  
      011635          105          055          117  
      011640          125          124          040  
      011643          124          122          101  
      011646          120          040          103  
      011651          101          125          123  
      011654          105          104          040  
      011657          102          131          040  
      011662          127          122          111  
      011665          124          105          040  
      011670          101          124          124  
      011673          105          115          120  
      011676          124          056          045  
      011701          116          000  
1879 011703          045          101          104 MSG3:: .ASCIZ /#ADMU MAY BE AT THE WRONG UNIBUS ADDRESS.#N#N/  
      011706          110          125          040  
      011711          115          101          131  
      011714          040          102          105  
      011717          040          101          124  
      011722          040          124          110  
      011725          105          040          127  
      011730          122          117          116  
      011733          107          040          125  
      011736          116          111          102  
      011741          125          123          040  
      011744          101          104          104  
      011747          122          105          123  
      011752          123          056          045  
      011755          116          045          116  
      011760          000  
1880  
1881          .EVEN
```

1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ERO503 -
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS AN ADDITIONAL ERROR
;* MESSAGE WHOSE ADDRESS IS PASSED AS AN INPUT PARAMETER, PROVIDED
;* EXTENDED ERROR REPORTING HAS BEEN REQUESTED.
;*
;* INPUTS: R1 - ADDRESS OF THE MESSAGE TO PRINT.
;*
;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: LOAD THE ADDRESS OF THE MESSAGE IN R1.
;* INCLUDE THE LABEL "ER0503" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

1902 011762
011762
1903
1904 011762 012700 000100
1905 011766 046700 170216
1906 011772 001011
1907
1908
1909 011774
011774 010146
011776 012746 004156
012002 012746 000002
012006 010600
012010 104414
012012 062706 000006
1910
1911 012016
012016
012016 104423

```
BGNMSG ERO503
;*****
ER0503::
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG NOT SET.

PRINTB #EF0503,R1 ;PRINT THE MESSAGE.

MOV R1,-(SP)
MOV #EF0503,(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP

2$: ENDMSG

L10003: TRAP C$MSG
```




```

1913 .SBTTL GLOBAL ERROR REPORTING ROUTINE - ER1603 -
1914 :*****
1915 :*****
1916 :* THIS ERROR REPORTING ROUTINE IS USED TO PRINT OUT A BASIC ERROR
1917 :* MESSAGE, ALONG WITH A MESSAGE INFORMING THE OPERATOR WHICH TEST IS
1918 :* ABOUT TO BE ABORTED, PROVIDED EXTENDED ERROR INFORMATION HAS BEEN
1919 :* REQUESTED, OTHERWISE ONLY A "TEST FAILURE" MESSAGE WILL BE PRINTED.
1920 :*
1921 :* INPUTS: R1 - CONTAINS THE ADDRESS OF THE MESSAGE TO BE PRINTED.
1922 :* ERRMSG - CONTAINS THE ADDRESS OF THE MESSAGE THAT INDICATES
1923 :* THE TEST THAT IS BEING PERFORMED, EG DMA, BREAK ETC.
1924 :*
1925 :* OUTPUTS: MESSAGES ARE PRINTED AT THE OPERATORS CONSOLE.
1926 :* "TESTNAME TEST ABORTED"
1927 :*
1928 :* CALLING SEQUENCE: INCLUDE THE LABEL "ER1603" AS THE MESSAGE POINTER
1929 :* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
1930 :*
1931 :* COMMENTS:
1932 :*
1933 :* SUBORDINATE ROUTINES CALLED: NONE.
1934 :*****
1935 012020 BGNMSG ER1603
1936 012020 ER1603::
1937 012020 004567 172034 SAVE JSR R5,PREG05 ;SAVE THE CONTENTS OF THE GPRS.
1938 012024 012700 000100 ;CALL REGISTER SAVE SUBRT.
1939 012030 046700 170154 MOV #BIT06,R0 ;TRY TO CLEAR THE
1940 012034 001024 BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
1941 ;EXIT IF FLAG NOT SET.
1942
1943 012036 PRINTB #EF0503,R1 ;PRINT BASIC MESSAGE ON OPERATORS CONSOLE.
1944 012036 010146 MOV R1,(SP)
1945 012040 012746 004156 MOV #EF0503,-(SP)
1946 012044 012746 000002 MOV #2,(SP)
1947 012050 010600 MOV SP,R0
1948 012052 104414 TRAP C$PNTB
1949 012054 062706 000006 ADD #6,SP
1950
1951 012060 016702 171770 MOV ERRMSG,R2 ;GET THE "TEST MESSAGE".
1952 012064 PRINTB #EF1601,R2 ;PRINT "TEST ABORTED" MESSAGE.
1953 012066 012746 004163 MOV R2,-(SP)
1954 012072 012746 000002 MOV #EF1601,-(SP)
1955 012076 010600 MOV #2,-(SP)
1956 012100 104414 MOV SP,R0
1957 012102 062706 000006 TRAP C$PNTB
1958 ADD #6,SP
1959
1960 2$: PASS ;RESTORE THE CONTENTS OF THE GPRS.
1961 012106 004736 JSR PC,B(SP) ;RETURN TO PREG05 SUBRT.
1962 012110 ENDMSG
1963 012110 L10004:
1964 012110 104423 TRAP C$MSG

```

1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ER5801 -
*****
; THIS IS AN ERROR REPORTING ROUTINE WHICH PRINTS THE MESSAGE PASSED
; AS A PARAMETER IN R1, AND THE RXTIMER VALUE IN R2, PROVIDED
; EXTENDED ERROR REPORTING HAS BEEN REQUESTED.
; THIS ROUTINE IS USED BY THE RXTIMER TEST.
;
; INPUTS: R1 - ADDRESS OF THE MESSAGE TO PRINT.
; R2 RXTIMER VALUE.
;
; OUTPUTS: THE MESSAGE FOLLOWED BY THE RXTIMER VALUE ARE PRINTED AT
; THE OPERATOR CONSOLE.
;
; CALLING SEQUENCE: INCLUDE THE LABEL ER5801 AS THE MESSAGE POINTER
; PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
;
; COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION AND THE
; RXTIMER VALUE IS PRINTED AS A 3 DIGIT DECIMAL NUMBER.
;
; SUBORDINATE ROUTINES USED: NONE.
*****
```

1973 012112
012112
1974 012112 032767 000100 170070
1975 012120 001422
1976
1977 012122
012122 010146
012124 012746 004156
012130 012746 000002
012134 010600
012136 104414
012140 062706 000006
1978 012144
012144 010246
012146 012746 004215
012152 012746 000002
012156 010600
012160 104414
012162 062706 000006
1979 012166
012166
012166 104423

```
BGNMSG ER5801
ER5801::
BIT #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
BEQ 2# ;EXIT WITH "TEST FAILED" MESSAGE IF NOT.

PRINTB #EF0503,R1
MOV R1,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C#PNTB
ADD #6,SP

PRINTB #EF5801,R2
MOV R2,(SP)
MOV #EF5801,-(SP)
MOV #2,(SP)
MOV SP,R0
TRAP C#PNTB
ADD #6,SP

2#: ENDMSG
L10005: TRAP C#MSG
```

1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017

012170
012170
012170 004567 171664
012174 032767 000100 170006
012202 001433
012204
012204 010346
012206 012746 004156
012212 012746 000002
012216 010600
012220 104414
012222 062706 000006
012226
012226 010146
012230 012746 004270
012234 012746 000002
012240 010600
012242 104415
012244 062706 000006
012250
012250 010246
012252 012746 004320
012256 012746 000002
012262 010600
012264 104415
012266 062706 000006

```

.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER5901 -
;*****
;* THIS IS AN ERROR REPORTING ROUTINE WHICH PRINTS AN ADDITIONAL
;* MESSAGE IN ADDITION TO THE "TEST FAILED" MESSAGE AND ALSO A
;* MESSAGE SHOWING THE EXPECTED VALUE OF A PIECE OF DATA AND THE
;* ACTUAL VALUE OF THAT DATA. THE DATA IS PRINTED AS A 3 DIGIT
;* DECIMAL NUMBER.
;*
;* INPUTS : R1 - EXPECTED VALUE OF DATA.
;*          R2 - ACTUAL VALUE OF DATA.
;*          R3 - ADDRESS OF THE MESSAGE TO PRINT.
;*
;* OUTPUTS : MESSAGES ARE PRINTED AT THE OPERATORS CONSOLE.
;*
;* CALLING SEQUENCE: INCLUDE THE LABEL "ER5901" AS THE MESSAGE POINTER
;*                   PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
;*
;* COMMENTS :
;*
;* SUBORDINATE ROUTINES USED : NONE.
;*****
                BGNMSG ER5901
;*****
                ER5901::
                SAVE                ;SAVE THE GPR CONTENTS.
                JSR R5,PREG05      ;CALL REGISTER SAVE SUBRT.
                BIT #BIT06,OPTION ;EXIT THE ROUTINE IF EXTENDED
                BEQ 60$             ;ERROR REPORTING IS NOT REQUESTED.
;*
;* REPORT EXTENDED ERROR INFORMATION
;*
                PRINTB #EF0503,R3 ;PRINT THE MESSAGE.
;*****
                PRINTX #EF5901,R1 ;PRINT THE "EXPECTED VALUE" MESSAGE.
;*****
                PRINTX #EF5902,R2 ;PRINT THE "ACTUAL VALUE" MESSAGE.
;*****
                MOV R3,-(SP)
                MOV #EF0503,(SP)
                MOV #2,-(SP)
                MOV SP,R0
                TRAP C$PNTB
                ADD #6,SP
                MOV R1,-(SP)
                MOV #EF5901,-(SP)
                MOV #2,-(SP)
                MOV SP,R0
                TRAP C$PNTX
                ADD #6,SP
                MOV R2,(SP)
                MOV #EF5902,-(SP)
                MOV #2,-(SP)
                MOV SP,R0
                TRAP C$PNTX
                ADD #6,SP
    
```

2018 012272
012272 004736
2019
2020 012274
012274
012274 104423

60\$: PASS
ENDMSG

JSR ;RESTORE THE GPR CONTENTS.
PC,0(SP)+ ;RETURN TO PREG05 SUBRT.

L10006: TRAP C#MSG

2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058

012276
012276
012276 032767 000100 167704
012304 001434
012306
012306 010446
012310 010346
012312 012746 004417
012316 012746 000003
012322 010600
012324 104414
012326 062706 000010
012332
012332 010146
012334 012746 004270
012340 012746 000002
012344 010600
012346 104415
012350 062706 000006
012354
012354 010246
012356 012746 004320
012362 012746 000002
012366 010600
012370 104415
012372 062706 000006

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER6001 -
;*****
; THIS IS AN ERROR REPORTING ROUTINE WHICH PRINTS OUT A MESSAGE
; AT THE CONSOLE INFORMING THE OPERATOR OF AN ERROR ON A PARTICULAR
; LINE. THE ROUTINE ALSO PRINTS OUT A MESSAGE INFORMING THE OPERATOR
; OF WHAT DATA WAS "EXPECTED" AND WHAT "ACTUAL" DATA WAS FOUND, IN THE
; FORM OF A 3 DIGIT DECIMAL NUMBER.
; IF EXTENDED ERROR REPORTING HAS NOT BEEN REQUESTED THEN ONLY THE
; "TEST FAILED" MESSAGE WILL BE PRINTED.
;
; INPUTS : R1 - EXPECTED DATA
;          R2 - ACTUAL DATA
;          R3 - ADDRESS OF THE MESSAGE TO PRINT
;          R4 - LINE NUMBER ON WHICH THE ERROR OCCURED
;
; OUTPUTS : MESSAGES ARE PRINTED AT THE OPERATOR CONSOLE
;           " 'MESSAGE' ON LINE # "
;           " EXPECTED : " ##
;           " ACTUAL : " ##
;
; CALLING SEQUENCE : INCLUDE THE LABEL "ER6001" AS THE ERROR ROUTINE
;                   POINTER PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
;
; SUBORDINATE ROUTINES CALLED : NONE
;*****
```

BGNMSG ER6001

ER6001::

```
BIT #BIT06,OPTION ;EXIT THE ROUTINE IF EXTENDED
BEQ 601 ;ERROR REPORTING IS NOT REQUESTED.
```

```
; REPORT EXTENDED ERROR INFORMATION
```

```
PRINTB #EF7801,R3,R4 ;PRINT THE MESSAGE WITH THE LINE NUMBR.
```

```
MOV R4, -(SP)
MOV R3, -(SP)
MOV #EF7801, -(SP)
MOV #3, -(SP)
MOV SP, R0
TRAP C#PNTB
ADD #10, SP
```

```
PRINTX #EF5901,R1 ;PRINT THE "EXPECTED" DATA MESSAGE.
```

```
MOV R1, -(SP)
MOV #EF5901, -(SP)
MOV #2, (SP)
MOV SP, R0
TRAP C#PNTX
ADD #6, SP
```

```
PRINTX #EF5902,R2 ;PRINT THE "ACTUAL" DATA MESSAGE.
```

```
MOV R2, -(SP)
MOV #EF5902, -(SP)
MOV #2, (SP)
MOV SP, R0
TRAP C#PNTX
ADD #6, SP
```

2059 012376
012376
012376 104423

501: ENDMSG

L10007: TRAP C1MSG

2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104

012400
012400
012400 004567 171454

012404 032767 000100 167576
012412 001433

012414 005002
012416 012703 000020
012422
012422 010146
012424 012746 004156
012430 012746 000002
012434 010600
012436 104414
012440 062706 000006
012444 000241
012446 006205
012450 103011
012452
012452 010246
012454 012746 004350
012460 012746 000002
012464 010600
012466 104414

```

.SBTTL GLOBAL ERROR REPORTING ROUTINE ER6401 -
;*****
; THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
; INFORMATION AFTER THE ERROR MESSAGE HEADER, PROVIDED EXTENDED ERROR
; REPORTING HAS BEEN ENABLED.
; THIS SUBROUTINE IS PASSED A GPR CONTAINING FLAGS WHICH INDICATE
; THE LINE(S) FOR WHICH THE ERROR CONDITION SHOULD BE REPORTED.
;
; INPUTS:      R1  ADDRESS OF THE MESSAGE TO BE PRINTED BY THIS ROUTINE.
;              R5  - CONTAINS THE ERROR FLAGS, (1 FLAG PER LINE).
;
; OUTPUTS:     MESSAGES ARE PRINTED AT THE OPERATOR CONSOLE.
;
; CALLING SEQUENCE:  LOAD THE ADDRESS OF THE MESSAGE IN R1.
;                   INCLUDE THE LABEL "ER6401" AS THE MESSAGE POINTER
;                   PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;
; COMMENTS:     THE OUTPUT FORMAT OF THIS MESSAGE IS:
;               TEXT MESSAGE
;               @NN
;               @NN
;               WHERE EACH "@NN" IS THE NUMBER OF A LINE WITH THE ERROR.
;
; SUBORDINATE ROUTINES USED: NONE.
;*****
    
```

```

                BGNMSG ER6401
                SAVE                                ER6401::
                JSR                                ;SAVE THE CONTENTS OF THE GPRS.
                R5,PREG05                          ;CALL REGISTER SAVE SUBRT.
;
; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
;
                BIT    @BIT06,OPTION                ;EXIT WITH TEST FAILURE MESSAGE IF
                BEQ    60$                          ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
                ;DURING THE SOFTWARE QUESTIONS.
;
                CLR    R2                            ;CLEAR LINE NUMBER TO ZERO.
                MOV    @NUMLNS,R3                   ;SET UP MAX LINE COUNT.
                PRINTB @EF0503,R1                   ;PRINT MESSAGE.
;
                CLC                                    ;CLEAR CARRY.
                ASR    R5                            ;SHIFT FLAG OUT INTO CARRY BIT.
                BCC    4$                             ;SKIP ERROR REPORT IF CLEAR.
                PRINTB @EF6401,R2                   ;PRINT MESSAGE.
;
                MOV    R1,-(SP)
                MOV    @EF0503,-(SP)
                MOV    @2,-(SP)
                MOV    SP,R0
                TRAP   C:PNTB
                ADD    @6,SP
;
                MOV    R2,-(SP)
                MOV    @EF6401,(SP)
                MOV    @2,-(SP)
                MOV    SP,R0
                TRAP   C:PNTB
    
```

012470 062706 000006
2105 012474 005202
2106 012476 020302
2107 012500 001362
2108 012502 004736
2109 012504 104423

4\$: INC R2
CMP R3,R2
BNE 2\$
60\$: PASS
ENDMSG

JSR

ADD 06,SP
; INCREMENT LINE COUNT.
; CHECK IF MAX LINE COUNT EXCEEDED.
; LOOP IF NOT DONE.
; RESTORE THE SAVED CONTENTS OF THE GPRS.
PC,0(SP)+ ; RETURN TO PREG05 SUBRT.

L10010:
TRAP C\$MSG


```

2111 .SBTTL GLOBAL ERROR REPORTING ROUTINE ER7801
2112 ;*****
2113 ;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS AN ADDITIONAL ERROR
2114 ;* MESSAGE WHOSE ADDRESS IS PASSED AS AN INPUT PARAMETER. A LINE NUMBER
2115 ;* IS INCLUDED AT THE END OF THE MESSAGE. THE MESSAGE IS PRINTED ONLY IF
2116 ;* EXTENDED ERROR REPORTING IS REQUESTED.
2117 ;*
2118 ;* INPUTS: R1 - ADDRESS OF THE MESSAGE TO PRINT.
2119 ;* R3 - NUMBER OF LINE ON WHICH ERROR OCCUPED.
2120 ;*
2121 ;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
2122 ;*
2123 ;* CALLING SEQUENCE: LOAD THE ADDRESS OF THE MESSAGE IN R1.
2124 ;* LOAD THE LINE NUMBER INTO R3.
2125 ;* INCLUDE THE LABEL "ER7801" AS THE MESSAGE POINTER
2126 ;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
2127 ;*
2128 ;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
2129 ;*
2130 ;* SUBORDINATE ROUTINES USED; NONE.
2131 ;*****
2132
2133 012506 BGNMSG ER7801
2134 012506 ER7801::
2135
2136 ;*
2137 ;* EXIT IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
2138 ;*
2139 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
2140 BEQ 2# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
2141 ;* DURING THE SOFTWARE QUESTIONS.
2142 PRINTB #EF7801,R1,R3 ;PRINT THE MESSAGE.
2143 012516 010346 MOV R3,-(SP)
2144 012516 010146 MOV R1,-(SP)
2145 012522 012746 004417 MOV #EF7801,(SP)
2146 012526 012746 000003 MOV #3,-(SP)
2147 012532 010600 MOV SP,R0
2148 012534 104414 TRAP C#PNTB
2149 012536 062706 000010 ADD #10,SP
2150
2151 2#:: ENDMMSG
2152
2153 L10011: TRAP C#MSG
  
```

```

2146 .SBTTL GLOBAL ERROR REPORTING ROUTINE ER9001 -
2147 ;*****
2148 ;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH REPORTS AN UNEXPECTED
2149 ;* CODE WHICH HAS BEEN FOUND IN THE DUT CSR. THIS CODE CAN BE A BMP
2150 ;* CODE, A SELF-TEST CODE, OR A MODEM STATUS CODE.
2151 ;*
2152 ;* INPUTS: R1 - ADDRESS OF MESSAGE TO PRINT FIRST.
2153 ;* R2 - SINGLE BYTE CODE WHICH HAS BEEN READ FROM THE DUT.
2154 ;* R4 - LINE NUMBER ASSOCIATED WITH THE CODE.
2155 ;*
2156 ;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
2157 ;*
2158 ;* CALLING SEQUENCE: INCLUDE THE LABEL "ER9001" AS THE MESSAGE POINTER
2159 ;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
2160 ;*
2161 ;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
2162 ;*
2163 ;* SUBORDINATE ROUTINES USED: NONE.
2164 ;*****
2165
2166 012544 BGNMSG ER9001
2167 012544 ER9001::
2168
2169 ;*
2170 ; EXIT IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
2171 ;*
2172 ;* BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
2173 ;* BEQ 2# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
2174 ;* ;DURING THE SOFTWARE QUESTIONS.
2175
2175 012554 PRINTB #EF9001,R1 ;REPORT TYPE OF CODE FOUND.
2176 012554 010146 MOV R1,(SP)
2177 012556 012746 004455 MOV #EF9001,(SP)
2178 012562 012746 000002 MOV #2,(SP)
2179 012566 010600 MOV SP,R0
2180 012570 104414 TRAP C$PNTB
2181 012572 062706 000006 ADD #6,SP
2182
2182 012576 PRINTX #EF9002,R4 ;REPORT THE LINE NUMBER OF THE CODE.
2183 012576 010446 MOV R4,-(SP)
2184 012600 012746 004537 MOV #EF9002,-(SP)
2185 012604 012746 000002 MOV #2,-(SP)
2186 012610 010600 MOV SP,R0
2187 012612 104415 TRAP C$PNTX
2188 012614 062706 000006 ADD #6,SP
2189
2189 012620 PRINTX #EF9003,R2 ;REPORT THE CODE WHICH WAS FOUND.
2190 012620 010246 MOV R2,(SP)
2191 012622 012746 004611 MOV #EF9003,(SP)
2192 012626 012746 000002 MOV #2,(SP)
2193 012632 010600 MOV SP,R0
2194 012634 104415 TRAP C$PNTX
2195 012636 062706 000006 ADD #6,SP
2196
2196 012642 2# : ENDMMSG
2197 012642
2198 012642 104423 L10012:
2199 012642 TRAP C$MSG

```

2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200
2201
2202
2203 012644
012644
2204
2205
2206
2207
2208 012644 032767 000100 167336
2209 012652 001462
2210
2211
2212 012654 006203
2213 012656 042702 177400
2214 012662
012662 010346
012664 010146
012666 012746 004721
012672 012746 000003
012676 010600
012700 104414
012702 062706 000010
2215 012706
012706 010246
012710 012746 010647
012714 012746 004640
012720 012746 000003
012724 010600
012726 104415
012730 062706 000010
2216 012734 005704
2217 012736 100414
2218 012740
012740 010446
012742 012746 010623
012746 012746 004640
012752 012746 000003

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9002 -
;*****
; THIS IS AN ERROR REPORTING SUBROUTINE WHICH IS INTENDED FOR USE IN THE
; TRANSMISSION AND RECEPTION TESTS. IT REPORTS THE TYPE OF ERROR WHICH
; HAS OCCURRED WHEN INCORRECT DATA IS RECEIVED FROM THE DUT. THIS
; ROUTINE ALSO REPORTS THE READ AND EXPECTED DATA VALUES.
;
; INPUTS:      R1 - ADDRESS OF MESSAGE TO PRINT FIRST.
;              R2 - DATA BYTE READ FROM THE DUT.
;              R3 - LINE NUMBER MULTIPLIED BY 2.
;              R4 - EXPECTED DATA BYTE, BIT 15 SET IF "NONE".
;
; OUTPUTS:     A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
;
; CALLING SEQUENCE:  INCLUDE THE LABEL "ER9002" AS THE MESSAGE POINTER
;                    PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;
; COMMENTS:     THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
;
; SUBORDINATE ROUTINES USED: PRTLPR.
;*****
```

BGNMSG ER9002

ER9002::

```
;
; EXIT IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
;-
    BIT    #BIT06,OPTION    ;EXIT WITH TEST FAILURE MESSAGE IF
    BEQ    62#              ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
                                ;DURING THE SOFTWARE QUESTIONS.

    ASR    R3                ;CALCULATE THE LINE NUMBER.
    BIC    #177400,R2        ;MASK OUT ALL BUT DATA IN READ CHAR.
    PRINTB #EF9006,R1,R3    ;PRINT THE FIRST LINE OF THE MESSAGE.

                                MOV    R3,-(SP)
                                MOV    R1,-(SP)
                                MOV    #EF9006,(SP)
                                MOV    #3,-(SP)
                                MOV    SP,R0
                                TRAP   C#PNTB
                                ADD    #10,SP

2215 PRINTX #EF9004,#EM9010,R2    ;PRINT ACTUAL DATA.

                                MOV    R2,-(SP)
                                MOV    #EM9010,(SP)
                                MOV    #EF9004,-(SP)
                                MOV    #3,(SP)
                                MOV    SP,R0
                                TRAP   C#PNTX
                                ADD    #10,SP

2216 TST    R4                ;CHECK FOR "NONE" CODE SET IN EXPECTED DATA.
2217 BMI    2#              ;BRANCH TO PRINT "NONE" MESSAGE IF FLAG SET.
2218 PRINTX #EF9004,#EM9009,R4    ;PRINT EXPECTED DATA.

                                MOV    R4,(SP)
                                MOV    #EM9009,(SP)
                                MOV    #EF9004,(SP)
                                MOV    #3,(SP)
```


2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9004 -
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH REPORTS ERROR SUMMARIES
;* FOR LINES WHICH HAVE EXCEEDED THE SPECIFIED MAXIMUM NUMBER OF
;* INDIVIDUAL RECEPTION ERRORS, PROVIDED EXTENDED ERROR REPORTING HAS
;* BEEN REQUESTED BY THE OPERATOR.
;*
;* INPUTS:      R1 - ADDRESS OF MESSAGE TO PRINT FIRST.
;*              ERCNTB - LABEL AT BASE OF LINE ERROR COUNTERS TABLE.
;*              ERSMRF - "REPORT ERROR SUMMARY FOR LINE" FLAGS.
;*
;* OUTPUTS:     A MESSAGE IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE:  INCLUDE THE LABEL "ER9004" AS THE MESSAGE POINTER
;*                    PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS:     THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
;*              THE CONTENTS OF GPR'S R2, R3, R4, AND R5 ARE DESTROYED.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

2246 013022

BGNMSG ER9004

ER9004::

2247 013022 012700 000100
2248 013026 046700 167156
2249 013032 001040
2250 013034

```
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 6; ;EXIT IF FLAG NOT SET.
PRINTB #EF0503,#EM9014 ;REPORT THE SECONDARY ERROR MESSAGE.
```

```
MOV #EM9014,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C;PNTB
ADD #6,SP
```

013034 012746 010673
013040 012746 004156
013044 012746 000002
013050 010600
013052 104414
013054 062706 000006

```
CLR R2 ;CLEAR THE LINE COUNTER.
MOV ERSMRF,R3 ;GET THE ERROR SUMMARY FLAGS.
CLR R4 ;CLEAR "LINE COUNTER TIMES 2" OFFSET.
2;: CLC ;CLEAR THE CARRY FOR THE FOLLOWING ROTATE.
ROR R3 ;SHIFT ANOTHER ERROR SUMMARY FLAG INTO CARRY.
BCC 4; ;SKIP PRINTING MESSAGE IF FLAG FOR LINE CLEAR.
PRINTX #EF9010,R2,ERCNTB(R4)
```

```
MOV ERCNTB(R4),(SP)
MOV R2,-(SP)
MOV #EF9010,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C;PNTX
ADD #10,SP
```

2251 013060 005002
2252 013062 016703 167524
2253 013066 005004
2254 013070 000241
2255 013072 006003
2256 013074 103013
2257 013076

2;:

6;:

013076 016446 002614
013102 010246
013104 012746 004745
013110 012746 000003
013114 010600
013116 104415
013120 062706 000010

```
4;: MOV (R4)+,R5 ;INCREMENT THE LINE OFFSET BY 2.
INC R2 ;INCREMENT THE LINE COUNTER.
TST R3 ;CHECK THE ERROR SUMMARY FLAGS.
BNE 2; ;IF MORE FLAGS SET, LOOP TO DO OTHER LINES.
ENDMSG
```

2258 013124 012405
2259 013126 005202
2260 013130 005703
2261 013132 001356
2262 013134
013134
013134 104423

```
L10014: TRAP C;MSG
```

2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292

013136
013136
013136 012700 000100
013142 046700 167042
013146 001012
013150
013150 010146
013152 010246
013154 012746 004721
013160 012746 000003
013164 010600
013166 104414
013170 062706 000010
013174
013174
013174 104423

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ER9101
;*****
;* THIS IS A GENERAL ERROR REPORTING SUBROUTINE WHICH REPORTS A MESSAGE
;* WHICH TAKES A SINGLE, 2 DIGIT DECIMAL ARGUMENT AFTER THE END OF AN
;* ASCII MESSAGE.
;*
;* INPUTS: R1 - VALUE TO BE PRINTED AFTER MSG AS 2 DECIMAL DIGITS.
;* R2 - ADDRESS OF MESSAGE TO PRINT FIRST.
;*
;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: INCLUDE THE LABEL "ER9101" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

BGNMSG ER9101

ER9101::

```
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2# ;EXIT IF FLAG NOT SET.
```

```
PRINTB #EF9006,R2,R1 ;REPORT THE STRING FOLLOWED BY THE NUMBER.
```

```
MOV R1,(SP)
MOV R2,(SP)
MOV #EF9006,(SP)
MOV #3,(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
```

2#: ENDMMSG

```
L10015: TRAP C$MSG
```

```

2294 .SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9301 -
2295 ;*****
2296 ; THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ANY BMP CODES
2297 ; THAT ARE FOUND IN THE BMP CODE QUEUE, TOGETHER WITH THE THE NUMBER OF
2298 ; THE TEST THAT WAS EXECUTING AT THE TIME THE BMP CODE WAS LOGGED.
2299 ; PROVIDED EXTENDED ERROR REPORTING HAS BEEN ENABLED.
2300 ;
2301 ; INPUTS: R1 - THE ADDRESS OF THE FIRST MESSAGE TO BE REPORTED.
2302 ; R2 - THE ADDRESS OF THE NEXT EMPTY CELL IN THE QUEUE.
2303 ;
2304 ; OUTPUTS: THE TEST NUMBER FOLLOWED BY THE BMP CODE ARE PRINTED AT THE
2305 ; OPERATOR CONSOLE.
2306 ;
2307 ; CALLING SEQUENCE: INCLUDE THE LABEL "ER9301" AS THE MESSAGE POINTER
2308 ; PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
2309 ;
2310 ; COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
2311 ;
2312 ; SUBORDINATE ROUTINES USED: NONE.
2313 ;*****
2314
2315 BGNMSG ER9301
2316 013176 013176 ER9301::
2317 013176 004567 170656 SAVE JSR ;SAVE THE GPRS ON THE STACK.
2318 013202 012700 000100 ;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2319 013206 046700 166776 MOV #BIT06,R0 ;TRY TO CLEAR THE
2320 013212 001064 BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
2321 ; BNE 60$ ;EXIT IF FLAG NOT SET.
2322 013214 PRINTB #EF0503,R1 ;REPORT UNEXPECTED BMP CODES FOUND
2323 013214 010146 MOV R1,-(SP)
2324 013216 012746 004156 MOV #EF0503,(SP)
2325 013222 012746 000002 MOV #2,(SP)
2326 013226 010600 MOV SP,R0
2327 013230 104414 TPAP C$PNTB
2328 013232 062706 000006 ADD #6,SP
2329 013236 012703 002412 MOV #BMPQ08,R3 ;GET THE START ADDRESS OF THE BMP CODE QUEUE.
2330 013242 012705 011257 MOV #EM9302,R5 ;GET THE MESSAGE TO BE REPORTED.
2331 2$: MOV (R3)+,R1 ;GET THE NUMBER OF THE TEST THAT WAS EXECUTING.
2332 MOV (R3)+,R4 ;GET BMP CODE THAT WAS REPORTED OFF THE QUEUE.
2333 JSR PC,50$ ;GO REPORT THE BMP CODE.
2334 CMP R3,R2 ;CHECK IF ALL CODES HAVE BEEN REPORTED.
2335 BLO 2$ ;IF IT IS NOT THE LAST BMP CODE THEN LOOP.
2336 ;
2337 ; CHECK IF OVERFLOW HAS OCCURRED.
2338 ; THE CONDITIONS FOR OVERFLOW ARE: THE POINTER CONTAINS THE ADDRESS OF THE
2339 ; LAST CELL IN THE QUEUE, AND A BMP CODE HAS ALREADY BEEN WRITTEN INTO THAT
2340 ; CELL.
2341 ;
2342 CMP R2,#BMPQ08-4 ;CHECK IF THE POINTER IS AT THE LAST LOCATION.
2343 BNE 60$ ;EXIT IF NOT AT THE LAST LOCATION.
2344 TST 2(R2) ;CHECK FOR A BMP CODE IN THE LAST CELL
2345 BEQ 60$ ;EXIT IF NO OVERFLOW HAS OCCURED, CELL EMPTY.
2346 MOV (R3)+,R1 ;GET THE TEST NUMBER OFF THE QUEUE.
2347 MOV (R3),R4 ;GET THE BMP CODE OFF THE QUEUE.
2348 MOV #EM9303,R5 ;SELECT THE MESSAGE TO BE REPORTED.

```

```

2343 013306          PRINTX  #EF9302          ;REPORT OVERFLOW CONDITION.
      013306 012746 005131
      013312 012746 000001
      013316 010600
      013320 104415
      013322 062706 000004
2344 013326 004767 000002
2345 013332 000414
2346
2347 013334          50$: PRINTX  #EF9301,R5,R1,R4 ;PRINT THE MESSAGE.
      013334 010446
      013336 010146
      013340 010546
      013342 012746 005053
      013346 012746 000004
      013352 010600
      013354 104415
      013356 062706 000012
2348 013362 000207
2349 013364          60$: RTS      PC          ;RETURN.
      013364 004736          PASS          ;RESTORE THE GPR CONTENTS.
2350
2351 013366          JSR      PC,@(SP).      ;RETURN TO PREG05 SUBR?.
      013366
      013366 104423          L10016: TRAP  C#MSG
    
```


2353
2361
2362
2363
2364
2365
2366

.SBTTL GLOBAL SUBROUTINES SECTION

; **
; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
; THAT ARE USED IN MORE THAN ONE TEST.
; --

2368
2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396 013370
013370 004567 170464
2397
2398
2399
2400
2401
2402
2403 013374 010400
2404 013376 005100
2405 013400 040002
2406 013402 016705 166650
2407
2408
2409
2410
2411
2412
2413 013406 000241
2414 013410 006003
2415 013412 103006
2416 013414 010577 166606
2417 013420 011100
2418 013422 040400
2419 013424 050200
2420 013426 010011
2421 013430 005205
2422 013432 005703
2423 013434 001365

```
.SBTTL GLOBAL SUBROUTINE                                ALTFLD
;*****
; - ALTER DEVICE REGISTER FIELDS ROUTINE -
; THIS SUBROUTINE ALTERS THE SPECIFIED FIELD OF THE SPECIFIED DEVICE
; REGISTER FOR THE SPECIFIED LINES. THIS ROUTINE CAN BE USED TO SET
; OR CLEAR BITS WITHIN SELECTED FIELDS OF SELECTED REGISTERS.
; USE EXAMPLES:  SET RX.BAUD.RATE FIELDS ON LINES 3 AND 6.
;                CLEAR TX.DMA BITS ON ALL LINES.
;
; INPUTS:  R1 - ADDRESS OF THE REGISTERS TO ALTER.
;          R2 - BIT FIELDS SET TO DESIRED STATES.
;          R3 - BIT MAP OF LINES FOR WHICH TO ALTER REGISTER.
;          R4 - MASK OF BITS TO ALTER (1 INDICATES CHANGE BIT).
;          CSRA - CONTAINS THE ADDRESS OF THE DEVICE CSR.
;          IESTAT - SAVED STATES OF THE INTERRUPT ENABLE BITS.
;
; OUTPUTS:  DEVICE REGISTERS - SPECIFIED REGISTER FIELDS ALTERED.
;          CSR IND.ADR.REG FIELD - DESTROYED.
;
; CALLING SEQUENCE:  JSR    PC,ALTFLD
;
; COMMENTS:  THIS ROUTINE READS THE SPECIFIED REGISTERS FOR ALL LINES
;            WITH NUMBERS LOWER THAN THE HIGHEST SPECIFIED LINE.
;            THIS ROUTINE DOES NOT READ THE CSR.
;
; SUBROUTINES CALLED:  NONE.
;*****
ALTFLD:: SAVE                                ;SAVE CONTENTS OF GPRS R0 THRU R5.
;                JSR    R5,PREG05          ;CALL REGISTER SAVE SUBRT.
;
; SET UP TO LOOP FOR EACH LINE:
; PREPARE THE WORD TO BE ORED INTO THE REGISTER CONTENTS.
; SET UP THE WORD TO WRITE INTO THE IND.ADR.REG FIELD OF THE CSR.
;
;                MOV    R4,R0              ;CALCULATE THE NEW CONTENTS OF THE
;                COM    R0                ; REGISTER FIELDS WHICH ARE TO BE
;                BIC    R0,R2              ; ALTERED BY THIS ROUTINE.
;                MOV    IESTAT,R5         ;SET UP TO WRITE IND.ADR.REG FIELD TO 0.
;
; LOOP ONCE FOR EACH LINE, ALTERING THE SPECIFIED FIELD IN THE SPECIFIED
; REGISTER IF THE LINE HAS BEEN SELECTED FOR ALTERING.
; EXIT THE LOOP IF NO MORE LINES TO ALTER, OR IF WE HAVE ALTERED THE MAX
; ALLOWABLE NUMBER OF LINES (AS SPECIFIED BY NUMLNS).
;
;                CLC                        ;PREPARE FOR ROTATE, "TST R5" DOES THIS BELOW.
21:          ROR     R3                    ;GET THE LINE SELECT BIT FOR THIS LINE.
;                BCC     41                ;SKIP SETUP IF LINE IS NOT SELECTED.
;                MOV    R5,DCSRA          ;SET OUT CSR IND.ADR.REG FIELD TO THIS LINE.
;                MOV    (R1),R0           ;GET THE PRESENT CONTENTS OF THE REG TO ALTER.
;                BIC    R4,R0             ;CLEAR THE BIT FIELDS WE ARE TO ALTER.
;                BIS    R2,R0             ;OR IN THE NEW STATES OF THE FIELDS.
;                MOV    R0,(R1)           ;WRITE THE NEW REGISTER CONTENTS TO THE REG.
41:          INC     R5                    ;SET LINE NUMBER TO THE NEXT LINE.
;                TST    R3                ;CHECK FOR UNHANDLED LINES, CLEAR CARRY FLAG.
;                BNE    21                ;LOOP IF SELECTED LINE(S) IS NOT HANDLED.
```

2424
2425 013436
013436 004736
2426 013440 000207

601: PASS JSR
RTS PC

;RESTORE GPRS.
PC,B(SP). ;RETURN TO PREG05 SUBRT.
;RETURN TO CALLING ROUTINE.

```

2428 .SBTTL GLOBAL SUBROUTINE ASLNTL
2429 ;* *****
2430 ;* - SETUP ASSOCIATED LINE NUMBER TABLES ROUTINE -
2431 ;* THIS ROUTINE SETS UP THE TWO TABLES WHICH ARE CONTAIN INFORMATION
2432 ;* ABOUT THE TX/RX LINE WHICH IS ASSOCIATED WITH A PARTICULAR RX/TX
2433 ;* LINE. ONE TABLE IS A TABLE OF WORDS WHICH CONTAINS WORD OFFSET
2434 ;* VALUES AND THE OTHER TABLE IS A TABLE OF BYTES WHICH CONTAINS
2435 ;* LINE NUMBER VALUES.
2436 ;*
2437 ;* INPUTS: LOPBCK - STORAGE FOR THE TYPE OF LOOPBACK ON THE DUT.
2438 ;* NUMLNS - EQUATED TO THE NUMBER OF LINES ON THE DUT.
2439 ;* STGTRB - LABEL AT BASE OF STAGGERED LINE ASSOCIATION TBL.
2440 ;* TXRLNB - LABEL AT BASE OF BYTE TX/RX LINE NUMBER TABLE.
2441 ;* TXRXLB - LABEL AT BASE OF WORD TX/RX LINE NUMBER TABLE.
2442 ;* TXRXLE - LABEL AT END OF WORD TX/RX LINE NUMBER TABLE.
2443 ;*
2444 ;* OUTPUTS: TXRXL, TXRLN - TABLES INITIALIZED FOR SELECTED LOOPBACK.
2445 ;*
2446 ;* CALLING SEQUENCE: JSR PC,ASLNTL
2447 ;*
2448 ;* COMMENTS:
2449 ;*
2450 ;* SUBORDINATE ROUTINES CALLED: NONE.
2451 ;* - - - - -
2452
2453 013442 ASLNTL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
013442 004567 170412 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2454 013446 126727 166550 000002 CMPB LOPBCK,#2 ;TEST FOR STAGGERED LOOPBACK.
2455 013454 001411 BEQ #1 ;GO SET UP STAGGERED TABLE IF STAGGERED LPBCK.
2456 ;*
2457 ;* SET UP THE WORD TABLE FOR NON-STAGGERED LOOPBACK.
2458 ;* - - -
2459 013456 005005 CLR R5 ;CLEAR THE LINE COUNTER
2460 013460 010565 003750 MOV R5, TXRXLB(R5) ;SET UP A WORD OF THE TABLE.
2461 013464 005205 INC R5
2462 013466 005205 INC R5 ;SET LINE COUNTER TO NEXT LINE OFFSET.
2463 013470 020527 000040 CMP R5,#2*NUMLNS ;TEST FOR ALL LINES DONE.
2464 013474 002771 BLT #2 ;LOOP UNTIL ALL LINES DONE.
2465 013476 000411 BR #8 ;GO SET UP THE BYTE TABLE.
2466 ;*
2467 ;* SET UP THE WORD TABLE FOR STAGGERED LOOPBACK.
2468 ;* - - -
2469 013500 012701 004030 MOV #STGTRB,R1 ;SET UP THE SOURCE POINTER.
2470 013504 012702 003750 MOV #TXRXLB,R2 ;SET UP THE DESTINATION POINTER.
2471 013510 112122 6#: MOVB (R1)+,(R2)+ ;MOVE A BYTE INTO THE TABLE.
2472 013512 105022 CLRB (R2)+ ;CLEAR THE UPPER BYTE OF WORD TABLE ENTRY.
2473 013514 020227 004010 CMP R2,#TXRXLE ;COMPARE POINTER WITH END ADR OF TABLE.
2474 013520 002773 BLT #6 ;LOOP IF NOT AT END YET.
2475 ;*
2476 ;* SET UP THE BYTE TABLE BASED ON THE WORD ASSOCIATION TABLE.
2477 ;* - - -
2478 013522 012701 003750 MOV #TXRXLB,R1 ;SET UP THE SOURCE POINTER.
2479 013526 012702 004010 MOV #TXRLNB,R2 ;SET UP THE DESTINATION POINTER.
2480 013532 012103 10#: MOV (R1)+,R3 ;GET THE WORD OFFSET VALUE FROM WORD TABLE.
2481 013534 006203 ASR R3 ;DIVIDE BY 2 TO GET LINE NUMBER VALUE.
2482 013536 110322 MOVB R3,(R2)+ ;LOAD THE BYTE LINE NUMBER INTO TABLE.
2483 013540 020127 004010 CMP R1,#TXRXLE ;COMPARE SOURCE POINTER WITH ADR OF TABLE END.

```

2484 013544 002772
2485
2486 013546 004736
013546
2487 013550 000207

BLT 10#
60#: PASS
RTS PC

JSR

;LOOP IF NOT AT END OF TABLE YET.

;RESTORE GPRS.
PC,B(SP).

;RETURN TO PREG05 SUBRT.

```

2489 .SBTTL GLOBAL SUBROUTINE CALMSL
2490 ;* *****
2491 ;* - CALIBRATE MILLI SECOND LOOP COUNT SUBROUTINE
2492 ;* THIS SUBROUTINE CALIBRATES THE TIMING LOOP WHICH IS USED IN THE MSLOOP
2493 ;* ROUTINE. THIS SUBROUTINE CALCULATES A VALUE FOR THE MSLCNT VARIABLE
2494 ;* WHICH IS THE NUMBER OF SOFTWARE LOOPS WHICH TAKES 1 MS TO EXECUTE IN
2495 ;* THE MSLOOP ROUTINE. THIS ROUTINE CALIBRATES THE COUNT BY USING THE
2496 ;* LINE TIME CLOCK (LTC), SO IF NO LTC IS AVAILABLE THE DEFAULT VALUE FOR
2497 ;* THE DELAY COUNT MUST BE USED.
2498 ;*
2499 ;*
2500 ;* INPUTS: MSLCNT - DEFAULT 1 MS DELAY LOOP COUNT VALUE, OR
2501 ;* VALUE FROM PREVIOUS CALIBRATION.
2502 ;* MSTICK - NUMBER OF MS PER LTC CLOCK TICK.
2503 ;* TIMER1 - TIMER COUNTER CHANGED BY LTC INTERRUPT SERVICE RTN.
2504 ;* CLKHRZ - NUMBER OF LTC CLICKS PER SECOND (50 OR 60).
2505 ;*
2506 ;* OUTPUTS: CARRY - SET IF LTC IS AVAILABLE, AND NEW CALIBRATION PERFORMED.
2507 ;* MSLCNT - NEW 1 MS DELAY LOOP COUNT VALUE IF LTC AVAILABLE, OR
2508 ;* UNCHANGED IF NO LTC IS AVAILABLE.
2509 ;*
2510 ;* CALLING SEQUENCE: JSR PC,CALMSL
2511 ;*
2512 ;* COMMENTS:
2513 ;*
2514 ;* SUBORDINATE ROUTINES CALLED: UNSDIV,OOPS.
2515 ;* - - - - -
2516
2517 013552 CALMSL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
013552 004567 170302 ;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2518 013556 005067 000210 CLR 62 ;CLEAR THE 2ND TIME FLAG.
2519 ;*
2520 ;* SYNCHRONIZE WITH THE LTC.
2521 ;* - - - - -
2522 013562 012705 000001 20: MOV #1,R5 ;SET OUTER LOOP COUNTER TO 1 LOOP.
2523 ;* INCREASE THE VALUE LOADED INTO THIS COUNTER IF THE ***
2524 ;* FOLLOWING LOOP FAILS ON FUTURE, FASTER PROCESSORS. ***
2525 013566 005000 CLR R0 ;CLEAR THE WAIT FOR CLOCK INT COUNTER.
2526 013570 012767 000001 166516 MOV #1,TIMER1 ;SET UP COUNT OF 1 TO SYNCH WITH LTC.
2527 013576 005767 166512 40: TST TIMER1 ;CHECK FOR COUNTER HAVING GONE TO ZERO.
2528 013602 001410 BEQ 60 ;JUMP OUT OF LOOP IF LTC HAS INTERRUPTED.
2529 013604 005200 INC R0 ;COUNT THIS ITERATION OF THE INNER LOOP.
2530 013606 001373 BNE 40 ;LOOP IF COUNTER HAS NOT TURNED OVER.
2531 013610 005305 DEC R5 ;DECREMENT THE INNER LOOP COUNTER.
2532 013612 003371 BGT 40 ;LOOP IF OUTER LOOP COUNT NOT UP.
2533 ;*
2534 ;* IF WE GOT NO LTC INTERRUPT, INDICATE THAT THERE IS NO LTC AVAILABLE.
2535 ;* LTC MUST BE FLAKEY, OR NOT REALLY AN LTC AT ALL.
2536 ;* - - - - -
2537 013614 005067 166472 CLR CLKHRZ ;CLEAR LTC FREQUENCY WORD TO INDICATE NO LTC.
2538 013620 000241 CLC ;INDICATE FAILURE FOR RETURN.
2539 013622 000461 BR 60 ;BYPASS THE FOLLOWING CALIBRATION PROCEDURES.
2540 ;*
2541 ;* WE ARE NOW SYNCHRONIZED WITH THE LTC.
2542 ;* SET UP FOR THE CALIBRATION LOOP.
2543 ;* - - - - -
2544 013624 012704 002314 60: MOV #TIMER1,R4 ;WILL TEST TIMER1 IN THE LOOP BELOW.

```

```

2545 013630 005001          CLR      R1          ;CLEAR THE OUTER LOOP COUNTER.
2546 013632 005002          CLR      R2          ;INDICATE TO CHECK ALL BITS OF TIMER1.
2547 013634 005003          CLR      R3          ;INDICATE TO CHECK FOR TIMER1 CLEAR.
2548 013636 012714 000001    MOV      #1,(R4)      ;LOAD TIMER1 WITH COUNT OF 1.
2549
2550 013642 016705 166460    8$:     MOV      MSLCNT,R5    ;LOAD MS LOOP COUNT.
2551 013646 011400    10$:    MOV      (R4),R0        ;GET THE TIMER1 VALUE.
2552 013650 010067 000120    MOV      R0,R4        ;SAVE WORD (LIKE IN THE REAL LOOP).
2553 013654 040200          BIC      R2,R0        ;LEAVE ALL THE BITS.
2554 013656 020003          CMP      R0,R3        ;COMPARE AGAINST ZERO.
2555 013660 000261          SEC          ;SET CARRY IN CASE OF SUCCESS.
2556 013662 001406          BEQ          ;EXIT LOOP IF TIMER1 HAS CLEARED.
2557 013664 005305          DEC      R5          ;COUNT DOWN THE INSIDE MS LOOP COUNT.
2558 013666 001367          BNE      10$        ;LOOP IF MS NOT UP.
2559 013670 005301          DEC      R1          ;DECREMENT THE MS TIME COUNT.
2560 013672 001363          BNE      8$         ;KEEP LOOPING.
2561 013674 004767 001160    JSR      PC,00PS     ;WE OVERFLOWED. SOMETHING IS WRONG. ABORT.
2562
2563          ;*
2564          ; WE HAVE NOW HAVE LOOP COUNT INFORMATION FOR ONE CLOCK TICK.
2565          ; WE HAVE NEGATIVE OF NUMBER OF OUTER LOOPS IN R1, EACH IS MSLCNT INNER LOOPS.
2566          ; WE HAVE THE PORTION OF THE LAST OUTER LOOP NOT EXECUTED, IN R5.
2567          ; NOW WE CALCULATE THE TOTAL NUMBER OF INNER LOOPS EXECUTED.
2568
2568 013700 005401          ;*
2569 013702 016702 166420    12$:    NEG      R1          ;GET NUMBER OF OUTER LOOPS.
2570 013706 010203          MOV      MSLCNT,R2    ;GET THE NUMBER OF INNER LOOPS PER OUTER LOOP.
2571 013710 160502          MOV      R2,R3        ;COPY NUMBER OF LOOPS FOR MULTIPLY.
2572 013712 010204          SUB      R5,R2        ;CALC # OF INNER LOOPS DONE IN LAST OUTER LOOP
2573 013714 005005          MOV      R2,R4        ; AND ADD TO ACCUMULATOR LSWORD.
2574 013716 005301          CLR      R5          ;CLEAR ACCUMULATOR MSWORD.
2575 013720 100403          14$:    DEC      R1          ;CHECK R1 FOR 0 CONDITION
2576 013722 060304          BMI      16$        ; SKIP MULTIPLICATION IF ZERO
2577 013724 005505          ADD      R3,R4        ;MULTIPLY NUMBER OF INNER
2578 013726 000773          ADC      R5          ; LOOPS PER OUTER LOOP BY
2579          BR      14$    ;NUMBER OF OUTER LOOPS PERFORMED.
2580
2581          ;*
2582          ; DIVIDE THE TOTAL NUMBER OF INNER LOOPS BY THE NUMBER OF MS PER LTC TICK.
2583
2582 013730 016701 166370    16$:    MOV      MSTICK,R1    ;# OF MS PER LTC TICK IS DIVISOR.
2583 013734 010403          MOV      R4,R3        ;LSWORD OF LOOP COUNT IS LSWORD OF DIVIDEND.
2584 013736 010502          MOV      R5,R2        ;MSWORD OF LOOP COUNT IS MSWORD OF DIVIDEND.
2585 013740 004767 003336    JSR      PC,UNSDIV    ;DIVIDE NUMBER OF LOOPS BY MS PER LTC TICK.
2586 013744 103402          BCS      18$        ;BYPASS OOPS IF WE'RE OK.
2587 013746 004767 001106    JSR      PC,00PS     ;CLOCK ROUTINES ARE NOT LONG ENOUGH, OR BUG.
2588 013752 010167 166350    18$:    MOV      R1,MSLCNT    ;SET NEW VALUE FOR MS LOOP COUNT.
2589 013756 005167 000010    COM      62$        ;SET THE 2ND ITERATION FLAGS IF 1ST ITERATION.
2590 013762 001277          BNE      2$         ;BRANCH IF ONLY ONE ITERATION DONE.
2591 013764 000261          SEC          ;SET THE SUCCESS FLAG FOR EXIT.
2592
2593          60$:    PASS          ;RESTORE GPRS,
2594 013770 000207          RTS      PC          ;PC,B(SP). ;RETURN TO PREG05 SUBRT.
2595          ; CARRY - SUCCESS FLAG. SET IF SUCCESS.
2596 013772 000000          62$:    .WORD 0          ;2ND CALIBRATION ITERATION FLAGS.
2597 013774 000000          64$:    .WORD 0          ;DUMMY WORD FOR STORAGE OF THE READ WORD.
    
```

```

2599 .SBTTL GLOBAL SUBROUTINE                                CHKBMP
2600 ;* *****
2601 ;* - CHECK IF CHARACTER IS A BMP CODE
2602 ;* THIS SUBROUTINE IS USED TO CHECK FOR BMP CODES.
2603 ;* IF A BMP CODE IS DETECTED, IT WILL BE SAVED ON THE QUEUE TO BE REPORTED
2604 ;* LATER. THE CARRY IS USED AS A FLAG TO INDICATE A CODE HAS BEEN FOUND.
2605 ;*
2606 ;* INPUTS:      R2 - CONTAINS THE DATA TO BE CHECKED.
2607 ;*
2608 ;* OUTPUTS:     R1 - CONTAINS THE MESSAGE TO BE REPORTED.
2609 ;* ERRBLK - CONTAINS THE ERROR REPORTING ROUTINE.
2610 ;* CARRY BIT IS USED TO INDICATE A BMP CODE FOUND, CARRY SET.
2611 ;*
2612 ;* CALLING SEQUENCE:  JSR    PC,CHKBMP
2613 ;*
2614 ;* COMMENTS:
2615 ;*
2616 ;* SUBORDINATE ROUTINES CALLED: SAVBMP.
2617 ;* -- *****
2618
2619 013776 013776 004567 170056 CHKBMP:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2620 014002 012700 170301      MOV    #170301,R0 ;SET UP THE FLAGS OF A BMP CODE.
;R2,R0 ;TRY TO CLEAR THE BMP CODE FLAGS.
2621 014006 040200      BIC    R2,R0 ;IF NOT A BMP CODE, EXIT WITH FAILURE.
2622 014010 001011      BNE    2# ;SAVE THE BMP CODE ON THE QUEUE.
2623 014012 004767 002462      JSR    PC,SAVBMP ;PASS THE MESSAGE TO BE REPORTED.
2624 014016 012701 006401      MOV    #EMS303,R1 ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
2625 014022 012767 012020 170026      MOV    #ER1603,ERRBLK ;PASS FLAG TO INDICATE SUCCESS, BMP CODE FOUND.
2626 014030 000261      SEC ;EXIT.
2627 014032 000401      BR    60# ;PASS FLAG TO INDICATE FAILURE.
2628 014034 000241      2# : CLC ;RESTORE GPRS, EXCEPT
2629 014036 010166 000004      60# : PASS R1      MOV    R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
;R1,R1SLOT(SP) ;RETURN TO PREG05 SUBRT.
;PC,#(SP).
2630 014042 004736      JSR    PC,#(SP). ;R1 - CONTAINS THE ADDRESS OF ERROR MESSAGE.
;CARRY BIT - SET INDICATES SUCCESS.
2631
2632 014044 000207      RTS    PC

```


2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660 014046
2661 014052 004567 170006
2662 014054 005204
2663 014056 006304
2664 014060 006304
2665 014062 160104
2666
2667
2668
2669 014064 012701 000005
2670 014070 010203
2671 014072 005002
2672 014074 004767 003202
2673 014100 010302
2674 014102 010305
2675 014104 160103
2676
2677 014106 060105
2678 014110 062705 000002
2679
2680
2681
2682
2683 014114 020504
2684 014116 002402
2685 014120 020304
2686 014122 002417
2687
2688
2689

```
.SBTTL GLOBAL SUBROUTINE                                CKRXTM
; * *****
; * - CHECK RX-INT DELAY TIME
; * THIS SUBROUTINE IS USED IN THE RXTIMER TEST AND IT CHECKS THAT THE
; * RX-INT WAS DELAYED BY +/- 20% OF THE VALUE SET IN THE RXTIMER REG.
; * IF THE ACTUAL DELAY TIME IS NOT WITHIN THIS MARGIN THEN AN ERROR
; * IS REPORTED.
; *
; * INPUTS:      R1 - REMAINING NUMBER OF MILLI SECS OF THE TIME OUT VALUE
; *              THE TIME-OUT VALUE BEING 4*(RXTIMER VALUE + 1).
; *              R2 - RXTIMER VALUE.
; *              ERRNBR - SET TO ERROR NUMBER OF FIRST ERROR IN THIS ROUTINE.
; *              ERBLK - SET UP BY THIS ROUTINE.
; *              EXOERR - "EXIT ON ERROR" FLAG.
; *
; * OUTPUTS:     ERBLK - MAY BE ALTERED.
; *              EXOERR - "EXIT ON ERROR" FLAG SET IF AN ERROR DETECTED AND
; *              EXTENDED ERROR REPORTING NOT REQUESTED.
; *
; * CALLING SEQUENCE:  JSR    PC,CKRXTM
; *
; * COMMENTS:      THIS ROUTINE REPORTS ONE ERROR WITH THE NUMBER IN ERRNBR.
; *
; * SUBORDINATE ROUTINES USED: ER5901,UNSDIV.
; * *****
CKRXTM:: SAVE
; *
; *          JSR    R5,PREG05      ;CALL REGISTER SAVE SUBRT.
; *          MOV    R2,R4          ;COPY THE RXTIMER VALUE.
; *          INC    R4              ;CALCULATE THE TIME-OUT VALUE,
; *          ASL    R4              ; AS 4*(RXTIMER VALUE+1)
; *          SUB    R1,R4          ;CALCULATE THE NUMBER OF MS THE RX-INT WAS DELAYED.
; *
; *          ; CALCULATE 20% OF THE RXTIMER VALUE.
; *          ; -
; *          MOV    #5,R1          ;PASS THE DIVISOR TO THE SUBR.
; *          MOV    R2,R3          ;LOAD THE RXTIMER VALUE INTO THE LSM OF THE DIVIDEND.
; *          CLR    R2              ;CLEAR THE MSW OF THE DIVIDEND.
; *          JSR    PC,UNSDIV      ;DIVIDE THE RXTIMER VALUE BY 5.
; *          MOV    R3,R2          ;PESTORE THE RXTIMER VALUE.
; *          MOV    R3,R5          ;COPY THE RXTIMER VALUE.
; *          SUB    R1,R3          ;REDUCE IT BY 20% TO OBTAIN THE LOLIMIT OF THE
; *                               ;PERMISSIBLE TIME DELAY.
; *          ADD    R1,R5          ;INCREASE THE RXTIMER VALUE BY 20% AND ADD A
; *          ADD    #2,R5          ;FURTHER 2 MS TO OBTAIN THE HILIMIT OF THE
; *                               ;PERMISSIBLE TIME DELAY.
; *
; *          ; CHECK IF THE RX-INT OCCURED WITHIN THE CALCULATED PERMISSIBLE LIMITS.
; *          ; -
; *          CMP    R5,R4          ;COMPARE HILIM WITH ACTUAL RX-INT DELAY.
; *          BLT    #2             ;REPORT THE ERROR IF THE DELAY WAS TOO LONG.
; *          CMP    R3,R4          ;COMPARE LOLIM WITH ACTUAL RX-INT DELAY.
; *          BLT    #60           ;AVOID ERROR IF DELAY WAS WITHIN THE LIMITS.
; *
; *          ; REPORT THE ERROR, INCORRECT DELAY ON RX INT.
; *          ; -
```



```

2704 .SBTTL GLOBAL SUBROUTINE CKTRAP
2705 ;*****
2706 ;* CHECK TRAP ROUTINE -
2707 ;* THIS SUBROUTINE IS USED TO CHECK FOR A BUS TIME OUT TRAP (004 TRAP)
2708 ;* WHICH IS CAUSED BY AN ACCESS TO A NON EXISTENT MEMORY OR I/O LOCATION.
2709 ;* IF THE TRAP DOES NOT OCCUR, THIS ROUTINE RETURNS A SUCCESS INDICATION.
2710 ;*
2711 ;* INPUTS: R0 SOURCE ADDRESS FOR MOVE.
2712 ;* R1 DESTINATION ADDRESS FOR MOVE.
2713 ;* (R0) - SOURCE FOR THE MOVE.
2714 ;*
2715 ;* OUTPUTS: (R1) - WRITTEN TO THE CONTENTS OF (R0).
2716 ;* CARRY FLAG - SET ON RETURN IF NO 004 TRAP DETECTED.
2717 ;* TP4FLG - NONZERO IF TRAP OCCURRED, CLEARED OTHERWISE.
2718 ;*
2719 ;* CALLING SEQUENCE: JSR PC,CKTRAP
2720 ;*
2721 ;* COMMENTS: IF THIS SUBROUTINE CAUSES A TRAP, EITHER THE ADDRESS WHICH
2722 ;* IS LABELED ADRPTR WILL BE THE TRAP PC ADDRESS ON THE STACK.
2723 ;*
2724 ;* SUBORDINATE ROUTINES CALLED: NONE.
2725 ;*****
2726
2727 014166 CKTRAP:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
014166 004567 167666 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2728 014172 005067 166102 CLR TP4FLG ;CLEAR THE 004 TRAP FLAGS.
MOV (R0),(R1) ;PERFORM THE MOVE IN QUESTION.
2729 014176 011011 ADRPTR:: TST TP4FLG ;CHECK FOR OCCURENCE OF TRAP.
SEC ;INDICATE SUCCESS.
2730 014200 005767 166074 BEQ 60$ ;EXIT WITH SUCCESS IF TRAP DID NOT OCCUR.
2731 014204 000261 CLC ;INDICATE FAILURE.
2732 014206 001401 60$: PASS ;RESTORE GPRS.
2733 014210 000241 60$: JSR PC,B(SP). ;RETURN TO PREG05 SUBRT.
2734 014212 004736
014212 000207 RTS PC
2735 014214 000207

```

```

2737 .SBTTL GLOBAL SUBROUTINE CLNRST
2738 ;*****
2739 ; - CLEAN RESET OF THE DEVICE UNDER TEST -
2740 ; THIS SUBROUTINE IS USED TO RESET THE DUT TO A KNOWN STATE.
2741 ; THE DUT'S SELF-TEST IS SKIPPED, AND THE FIFO IS PURGED OF ANY ERROR
2742 ; CODES, ETC.
2743 ; IF THE RESET DOES NOT SUCCESSFULLY COMPLETE, THEN THE CARRY BIT IS
2744 ; PASSED BACK TO THE CALLING ROUTINE (CLEAR).
2745 ;
2746 ; INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR
2747 ; TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
2748 ; ERRNBR - ERROR NUMBER FOR POSSIBLE ERROR REPORT.
2749 ; ERRTBL - ERRTP,ERNBR,AND ERRMSG SET UP CORRECTLY.
2750 ;
2751 ; OUTPUTS: THE DUT PERFORMS ITS RESET FUNCTION INTO A KNOWN STATE.
2752 ; CARRY - CLEAR INDICATES THE TEST IS TO BE ABORTED.
2753 ; ERRBLK - VALUE MAY BE DESTROYED.
2754 ; IESTAT - TX AND RX INTERRUPT FLAGS ARE CLEARED.
2755 ; TX AND RX INTERRUPT ENABLE BITS IN THE DUT'S CSR ARE CLEARED.
2756 ;
2757 ; CALLING SEQUENCE: JSR PC,CLNRST
2758 ;
2759 ; COMMENTS: THIS SUBROUTINE CAN REPORT ERRORS WITH NUMBERS ERRNBR.
2760 ; THIS ROUTINE DOES NOT DESTROY THE VALUE OF ERRNBR.
2761 ;
2762 ; SUBORDINATE ROUTINES CALLED: DELAY,MSLGET,PUFIFO,RESETT.
2763 ;*****
2764
2765 014216 CLNRST:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
014216 004567 167636 JSR R5,PREGOS ;CALL REGISTER SAVE SUBRT.
2766 ;
2767 ; RESET THE DUT.
2768 ; THIS ROUTINE REPORTS ERRORS WITH NUMBERS FROM ERRNBR THRU ERRNBR+2.
2769 ;-
2770 014222 004767 002054 JSR PC,RESETT ;RESET THE DUT TO A KNOWN STATE.
2771 014226 103002 BCC 60$ ;EXIT ROUTINE WITH ABORT TEST INDICATOR.
2772 ;
2773 ; PURGE THE FIFO OF ERROR CODES. SAVE ANY BMP CODES FOUND.
2774 ;-
2775 014230 004767 001134 JSR PC,PUFIFO ;PURGE THE FIFO.
2776 ;
2777 014234 60$: ;EXIT THE TEST USING RESETT OR PUFIFO STATUS.
2778 014234 004736 PASS ;RESTORE GPRS. PASS THE FOLLOWING INTACT:
; PC,@(SP). ;RETURN TO PREGOS SUBRT.
JSR
2779 ;CARRY BIT:IF CLEAR, THEN ABORT THE TEST.
2780 014236 000207 RTS PC

```

2782
 2783
 2784
 2785
 2786
 2787
 2788
 2789
 2790
 2791
 2792
 2793
 2794
 2795
 2796
 2797
 2798 014240
 014240 004567 167614
 2799 014244 012701 000020
 2800 014250 005020
 2801 014252 005301
 2802 014254 001375
 2803 014256
 014256 004736
 2804 014260 000207

```
.SBTTL GLOBAL SUBROUTINE - CLR16W
;*****
;* CLEAR SIXTEEN WORDS ROUTINE
;* THIS SUBROUTINE CLEARS 16 WORDS STARTING WITH THE SPECIFIED WORD
;*
;* INPUTS: R0 - ADDRESS OF THE FIRST WORD TO CLEAR.
;*
;* OUTPUTS: (R0) TO (R0+15) - 16 WORDS OF MEMORY ARE CLEARED TO 0.
;*
;* CALLING SEQUENCE: JSR PC,CLR16W
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;-- *****

CLR16W:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREGOS ;CALL REGISTER SAVE SUBRT
;SET THE LOOP COUNTER TO 16.
2$: MOV #16.,R1 ;CLEAR A WORD OF MEMORY.
CLR (R0)+ ;COUNT THIS LOOP.
DEC R1 ;LOOP IF NOT 16 WORD CLEARED.
BNE 2$ ;RESTORE GPRS.
60$: PASS ;RETURN TO PREGOS SUBRT.
;PC,B(SP)+

RTS PC
```

2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835

014262 004567 167572
014266 010401
014270 012702 177777
014274 005003
014276 012704 014320
014302 004767 000536
014306 103002
014310 004767 000544
014314 004736
014316 000207
014320 177777

```
.SBTTL GLOBAL SUBROUTINE - DELAY
;*****
;* - DELAY SUBROUTINE -
;* THIS SUBROUTINE IS USED TO DELAY A VARIABLE NUMBER OF MILLI-SECONDS.
;*
;* INPUTS: R4 - CONTAINS THE NUMBER OF MS TO DELAY.
;* MSLCNT.
;*
;* OUTPUTS: NONE.
;*
;* CALLING SEQUENCE: JSR PC,DELAY
;*
;* COMMENTS: IF NO HARDWARE CLOCK INTERRUPTS ARE OCCURING, CONTROL-CS WILL
;* NOT BE HONORED FOR THE DURATION OF THE DELAY.
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****

DELAY:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV R4,R1 ;PASS NUMBER OF MS DELAY AS TIME-OUT VALUE.
MOV #-1,R2 ;TELL MSLOOP ROUTINE TO CHECK ALL BITS.
CLR R3 ;TELL MSLOOP RTN TO CHECK FOR ALL BITS CLEAR.
MOV #62#,R4 ;TELL MSLOOP TO CHECK DUMMY NON ZERO WORD.
JSR PC,MSLOOP ;DELAY THE REQUESTED # OF MS.
BCC 60# ;EXIT ROUTINE IF WE TIMED-OUT.]
JSR PC,OOPS ;IF NO TIME-OUT, BAD PROGRAM OR HOST MACHINE.
PASS ;RESTORE GPRS.
;RETURN TO PREG05 SUBRT.
JSR PC,@(SP)+

RTS PC

60#: .WORD -1 ;DUMMY, NON-ZERO WORD.

62#: .WORD -1 ;DUMMY, NON-ZERO WORD.
```

2837
 2838
 2839
 2840
 2841
 2842
 2843
 2844
 2845
 2846
 2847
 2848
 2849
 2850
 2851
 2852
 2853
 2854
 2855
 2856
 2857
 2858
 2859
 2860
 2861
 2862
 2863
 2864
 2865
 2866
 2867
 2868
 2869
 2870
 2871
 2872
 2873
 2874
 2875
 2876
 2877
 2878
 2879
 2880
 2881
 2882
 2883
 2884

014322
 014322 004567 167532
 014326 012702 002650
 014332 004767 000042
 014336 103016
 014340 005267 167506
 014344 012701 170536
 014350 016702 165652
 014354 004767 003056
 014360 103005
 014362 012704 000005
 014366 004767 177670
 014372 000261
 014374
 014374 004736
 014376 000207

```

.SBTTL GLOBAL SUBROUTINE - DMABUF -
.....
; DMA FROM ADDR BUFAS -
THIS SUBROUTINE INITIATES A DMA FROM THE ADDRESS BUFAS AND WAITS
FOR IT TO COMPLETE AND THE LAST CHARACTER TO BE RECEIVED. THE LINE
ON WHICH TO PERFORM THE DMA AND THE NUMBER OF CHARACTERS TO TRANSMIT
ARE PASSED AS INPUT PARAMETERS.
;
; INPUTS: R1 LINE NUMBER ON WHICH TO PERFORM THE DMA.
; R3 - NUMBER OF CHARACTERS TO TRANSMIT.
; CSRA - CONTAINS THE ADDRESS OF THE CSR.
; ERRNBR - CONTAINS THE ERROR NUMBER OF THE FIRST ERROR
; IN THIS SUBROUTINE.
;
; OUTPUTS: CARRY - SUCCESS FLAG - SET IF DMA COMPLETED SUCCESSFULLY.
; CLEAR IF DMA START BIT FOUND SET OR
; NO TX-ACTION RECEIVED.
; ERRNBR - CONTENTS ALTERED TO INITIAL ERRNBR + 1.
;
; CALLING SEQUENCE: JSR PC,DMABUF
;
; COMMENTS: THIS ROUTINE RETURNS CARRY CLEAR IF AN ERROR OCCURED, WITH
; THE APPROPRIATE ERROR NUMBER IN ERRNBR. A NON-RELATED TEST
; ERROR SHOULD BE REPORTED, UPON RETURN TO THE TEST, IF THE CARRY
; FLAG IS CLEAR. THIS ROUTINE REPORTS ERRORS,
; INITIAL ERRNBR THRU INITIAL ERRNBR + 1.
;
; SUBORDINATE ROUTINES CALLED: DELAY,DODMA,WAIBIS.
; - - - - -
DMABUF:: SAVE
;
; JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV #BUFAS,R2 ;PASS THE START ADDR OF THE BUFFER TO TX.
JSR PC,DODMA ;INITIATE THE DMA.
BCC 601 ;RETURN WITH FAILURE IF DMA-START BIT FOUND SET.
;
; WAIT FOR THE DMA TO COMPLETE I.E A TX-ACTION BEING RETURNED, AND THEN WAIT
; FOR THE LAST CHARACTER TO BE RECEIVED.
; - - - - -
INC ERRNBR ;SET THE ERROR NUMBER TO INITIAL ERRNBR + 1.
MOV #170536,R1 ;INDICATE TO TEST BIT15 WITH TIME-OUT OF 350 MS
MOV CSRA,R2 ;PASS THE ADDR OF THE REG TO TEST.
JSR PC,WAIBIS ;WAIT FOR THE TX-ACTION.
BCC 601 ;RETURN WITH FAILURE IF NO TX-ACTION FOUND.
MOV #5,R4 ;SET THE DELAY OF 5 MS.
JSR PC,DELAY ;WAIT FOR THE LAST CHARACTER TO BE RECEIVED.
SEC ;SET THE CARRY FLAG TO INDICATE SUCCESS.
601: PASS
;
; JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
RTS PC ;RETURN.
    
```

```

2886
2887
2888
2889
2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2900
2901
2902
2903
2904
2905
2906
2907
2908
2909
2910
2911
2912
2913
2914
2915
2916 014400
      014400 004567 167454
2917 014404 012704 000200
2918
2919
2920
2921
2922
2923
2924
2925
2926
2927
2928 014410
      014410 104440
      014412 010005
2929 014414
      014414 012700 000340
      014420 104441
2930 014422 056701 165630
2931 014426 010177 165574
2932 014432 105777 165604
2933 014436 000241
2934 014440 100411
2935 014442 010377 165576
2936 014446 010277 165566
2937 014452 110477 165564

```

```

.SBTTL GLOBAL SUBROUTINE DODMA
; .. *****
; * - INITIATE DMA TRANSMISSION ROUTINE -
; * THIS ROUTINE WRITES THE DMA PARAMETER TO THE SPECIFIED DEVICE AND
; * INITIATES THE DMA TRANSMISSION.
; *
; * INPUTS: R1 - LINE NUMBER ON WHICH TO INITIATE THE DMA.
; * R2 - START ADDRESS OF THE DMA BUFFER (16 BIT VIRTUAL).
; * R3 - CHARACTER COUNT OF THE DMA BUFFER.
; * CSRA - CONTAINS ADDRESS OF THE DUT CSR.
; * IESTAT - STORAGE FOR STATES OF THE INTERRUPT ENABLE BITS.
; * TXAD1A - CONTAINS ADDRESS OF DMA TX BUFFER ADDRESS REG #1.
; * TXAD2A - CONTAINS ADDRESS OF DMA TX BUFFER ADDRESS REG #2.
; * TXBFCA - CONTAINS ADDRESS OF DMA CHARACTER COUNT REGISTER.
; *
; * OUTPUTS: CARRY - SUCCESS FLAG (SET IF DMA_START FOUND CLEAR).
; * DUT TBUFFAD1 - LS 16 BITS OF DMA BUFFER ADDRESS (INITIALIZED).
; * DUT TBUFFAD2 - MS 6 BITS OF DMA BUFFER ADDRESS (INITIALIZED),
; * DMA_START BIT SET.
; * DUT TBUFFCT - DMA BUFFER CHARACTER COUNT (INITIALIZED).
; *
; * CALLING SEQUENCE: JSR PC,DODMA
; *
; * COMMENTS: THIS ROUTINE ASSUMES MEMORY MANAGEMENT IS DISABLED AND
; * CLEARS THE TWO MSB OF THE DMA ADDRESS, I.E. BITS 0 AND 1
; * OF THE TBUFFAD2 REG.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; - - *****
DODMA:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
          JSR R5,PREGOS ;CALL REGISTER SAVE SUBRT.
          MOV #200,R4 ;PREPARE TO CLEAR UPPER 6 BITS OF DMA BUFF ADR.
; *
; * WRITE THE DMA PARAMETERS OUT TO THE DUT DMA REGISTERS.
; * DISABLE INTERRUPTS.
; * SET UP DUT CSR IND.ADR.REG FIELD.
; * WRITE THE DMA TRANSMIT CHARACTER COUNT.
; * WRITE THE LEAST SIGNIFICANT 16 BITS OF THE DMA BUFFER START ADDRESS.
; * WRITE THE MOST SIGNIFICANT 6 BITS OF THE ADDRESS.
; * SETTING THE DMA_START BIT, AND INITIATING THE DMA TRANSMISSION.
; -
68: GETPRI R5 ;GET THE PRESENT PROCESSOR PRIORITY.
          TRAP C:CPRI
          MOV RO,R5
          SETPRI #PRI07 ;DISABLE ALL HARDWARE INTERRUPTS.
          MOV #PRI07,RO
          TRAP C:SPRI
          BIS IESTAT,R1 ;PREPARE FOR SETUP OF LINE NUMBER IN DUT CSR.
          MOV R1,@CSRA ;SET UP THE DUT CSR IND.ADR.REG FIELD.
          TSTB @TXAD2A ;TEST THE DUT DMA_START BIT.
          CLC ;INDICATE FAILURE IN CASE DMA.HO BIT IS SET.
          BMI 60# ;EXIT WITH FAILURE IF DMA.HO BIT IS SET.
          MOV R3,@TXBFCA ;WRITE THE DMA CHARACTER COUNT.
          MOV R2,@TXAD1A ;WRITE THE LS 16 BITS OF BUFFER ADDRESS.
          MOV R4,@TXAD2A ;WRITE MS 6 BITS OF ADR AND START DMA Tx.

```


2938	014456		SETPRI	R5				;RESTORE THE PROCESSOR PRIORITY.
	014456	010500						MOV R5,R0
	014460	104441						TRAP C#SPRI
2939	014462	000261						
2940			SEC					;INDICATE SUCCESS.
2941	014464		601: PASS					;RESTORE GPRS,
	014464	004736			JSR			PC,B(SP);
2942	014466	000207	RTS	PC				;RETURN TO PREGOS SUBRT.
								; CARRY - SUCCESS FLAG (SET IF SUCCESS).

```

2944
2945
2946
2947
2948
2949
2950
2951
2952
2953
2954
2955
2956
2957
2958
2959
2960
2961
2962
2963 014470
      014470 004567 167364
2964
2965
2966
2967 014474 005001
2968 014476 012703 000020
2969 014502 016700 165512
2970 014506 012705 000001
2971 014512 030500
2972 014514 001006
2973 014516 006305
2974 014520 005201
2975 014522 020103
2976 014524 002772
2977 014526 000241
2978 014530 000401
2979 014532 000261
2980
2981 014534
      014534 010166 000004
      014540 010566 000014
      014544 004736
2982
2983
2984
2985 014546 000207
    
```

```

.SBTTL GLOBAL SUBROUTINE FINACT -
;*****
; - FIND FIRST ACTIVE LINE
; THIS SUBROUTINE CALCULATES THE NUMBER OF THE FIRST ACTIVE LINE THAT
; IS FOUND IN THE ACTIVE LINE BIT MAP ACTLNS.
;
; INPUTS: ACTLNS - CONTAINS THE ACTIVE LINE BIT MAP.
;
; OUTPUTS: R1 - CONTAINS THE NUMBER OF THE FIRST ACTIVE LINE.
;          R5 - CONTAINS THE BIT MAP REPRESENTATION OF THE ACTIVE LINE.
;          CARRY SET INDICATES SUCCESS.
;
; CALLING SEQUENCE: JSR PC,FINACT
;
; COMMENTS:
;
; SUBORDINATE ROUTINES CALLED: NONE.
;--*****
FINACT:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
;          R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;
; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
;
; CLR R1 ;CLEAR THE LINE NUMBER COUNTER.
; MOV #NUMLNS,R3 ;GET MAX LINE NUMBER.
; MOV ACTLNS,R0 ;GET THE ACTIVE LINE BIT MAP.
; MOV #1,R5 ;SET UP A LINE BIT MASK.
28: BIT R5,R0 ;LOOK FOR AN ACTIVE LINE.
; BNE 48 ;BRANCH TO BEGIN TEST IF A LINE HAS BEEN FOUND.
; ASL R5 ;SHIFT THE BIT MASK FOR THE NEXT LINE.
; INC R1 ;INCREMENT THE LINE NUMBER COUNTER.
; CMP R1,R3 ;CHECK IF ALL LINES HAVE BEEN TRIED.
; BLT 28 ;LOOP TO TRY THE NEXT LINE.
; CLC ;CLEAR CARRY BIT, NO ACTIVE LINE FOUND.
; BR 608 ;EXIT WITH FAILURE.
48: SEC ;SET CARRY, SUCCESS.
;
608: PASS R1,R5 ;RESTORE GPRS, EXCEPT
; MOV R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
; MOV R5,R5SLOT(SP) ;PUT R5 IN STACK SLOT.
; JSR PC,B(SP) ;RETURN TO PREG05 SUBRT.
; R1 - CONTAINS THE NUMBER OF FIRST ACTIVE LINE.
; R5 - CONTAINS THE BIT MAP OF THE ACTIVE LINE.
; CARRY - SET INDICATES SUCCESS.
RTS PC
    
```

```

2987 .SBTTL GLOBAL SUBROUTINE INDATP
2988 ; * *****
2989 ; * - INITIALISE DATA PATTERN -
2990 ; * THIS SUBROUTINE IS USED TO INITIALISE AN INCREMENTAL BYTE DATA PATTERN
2991 ; * IN THE GENERAL BUFFER AREA.
2992 ; * THE DATA PATTERN WILL BE SEQUENTIAL FROM 0 TO 255 (DECIMAL).
2993 ; *
2994 ; * INPUTS: BUFBAS - ADDRESS OF THE START OF THE GENERAL BUFFER AREA.
2995 ; * BUFMID - ADDRESS OF THE 255 TH LOCATION.
2996 ; *
2997 ; * OUTPUTS: THE FIRST 255 LOCATIONS OF THE GENERAL BUFFER AREA CONTAIN DATA
2998 ; *
2999 ; * CALLING SEQUENCE: JSR PC,INDATP
3000 ; *
3001 ; * COMMENTS:
3002 ; *
3003 ; * SUBORDINATE ROUTINES CALLED: NONE.
3004 ; - *****
3005
3006 014550 INDATP:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
014550 004567 167304 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3007
3008 014554 MOV #BUFBAS,R2 ;INITIALIZE THE DATA PATTERN IN THE GENERAL
3009 014560 CLR R3 ; DATA BUFFER TO A 256 BYTE PATTERN.
3010 014562 MOV R3,(R2) ;
3011 014564 INC R3 ;SELECT THE NEXT CHARACTER.
3012 014566 CMP R2,#BFMID ;CHECK IF WE HAVE 256 DATA PATTERNS.
3013 014572 BLO 2: ;
3014
3015 014574 60: PASS ;RESTORE GPRS.
014574 004736 JSR PC,(SP) ;RETURN TO PREG05 SUBRT.
3016 014576 RTS PC

```

```

3018 .SBTTL GLOBAL SUBROUTINE                                INDTPX
3019 ;* *****
3020 ;* - INITIALISE DATA PATTERN WITHOUT XON OR XOFF -
3021 ;* THIS SUBROUTINE IS USED TO INITIALISE AN INCREMENTAL BYTE DATA PATTERN
3022 ;* IN THE GENERAL BUFFER AREA.
3023 ;* THE DATA PATTERN WILL BE FROM 0 TO 255, BUT WILL EXCLUDE THE FOLLOWING
3024 ;* TWO CHARACTERS; (ASCII DC1, DC3) XON AND XOFF. THIS WILL CAUSE THE
3025 ;* LAST TWO DATA CHARACTERS TO BE THE SAME AS THE FIRST TWO.
3026 ;*
3027 ;* INPUTS:      BUFBAS - ADDRESS OF THE START OF THE GENERAL BUFFER AREA.
3028 ;*             BUFMID - ADDRESS OF THE 255 TH LOCATION.
3029 ;*
3030 ;* OUTPUTS:     THE FIRST 255 LOCATIONS OF THE GENERAL BUFFER AREA CONTAIN DATA
3031 ;*
3032 ;* CALLING SEQUENCE:  JSR      PC,INDTPX
3033 ;*
3034 ;* COMMENTS:
3035 ;*
3036 ;* SUBORDINATE ROUTINES CALLED: NONE.
3037 ;*-- *****
3038
3039 014600 014600 004567 167254 INDTPX:: SAVE                JSR      ;SAVE CONTENTS OF GPRS R0 THRU R5.
;                                     R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3040 ;*
3041 ; INITIALIZE THE 256 BYTE DATA PATTERN.
3042 ; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
3043 ; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
3044 ;-
3045 014604 012702 002650      MOV    #BUFBAS,R2      ;INITIALIZE THE DATA PATTERN IN THE GENERAL
3046 014610 005003            CLR    R3              ; DATA BUFFER TO A 256 BYTE PATTERN.
3047 014612 110322      2$:  MOVB   R3,(R2)+        ;
3048 014614 105203            INCB   R3              ;SELECT THE NEXT CHARACTER.
3049 014616 122703 000021      CMPB   #21,R3        ;CHECK FOR AN XON CHARACTER.
3050 014622 001001            BNE    4$            ;BRANCH IF CHAR NOT AN XON.
3051 014624 105203            INCB   R3              ;FORCE THE NEXT CHARACTER.
3052 014626 122703 000023      4$:  CMPB   #23,R3        ;CHECK FOR AN XOFF CHARACTER.
3053 014632 001001            BNE    6$            ;BRANCH IF NOT AN XOFF CHARACTER.
3054 014634 105203            INCB   R3              ;FORCE THE NEXT CHARACTER.
3055 014636 020227 003250      6$:  CMP    R2,#BUFMID    ;CHECK IF WE HAVE 256 DATA PATTERNS.
3056 014642 103763            BLO    2$              ;
3057
3058 014644 014644 004736      60$:  PASS                ;RESTORE GPRS.
;                                     PC,@(SP). ;RETURN TO PREG05 SUBRT.
3059 014646 000207            RTS     PC              ;

```

3061
3062
3063
3064
3065
3066
3067
3068
3069
3070
3071
3072
3073
3074
3075
3076
3077
3078
3079
3080
3081
3082
3083
3084
3085 014650
014650 004567 167204
3086 014654 042701 177760
3087 014660 006301
3088 014662 016100 002336
3089 014666
014666 010066 000002
014672 004736
3090 014674 000207

```
.SBTTL GLOBAL SUBROUTINE LINBIT
; * *****
; * - LINE NUMBER TO BIT MAP CONVERSION SUBROUTINE
; * THIS SUBROUTINE IS USED TO GENERATE A BIT MAP (ONE BIT OF 16 SET)
; * BASED ON A LINE NUMBER (RANGE: 1 TO 16). ONLY THE LS 4 BITS OF THE
; * LINE NUMBER WORD ARE USED, THE OTHERS ARE MASKED OUT (SO UNMASKED
; * MSBYTES OF DUT CSRS CAN BE PASSED TO THIS ROUTINE WITHOUT ERROR).
; *
; * INPUTS: R1 - LINE NUMBER (ONLY LS 4 BITS USED, OTHERS DISREGARDED).
; * BITTBL - BASE LABEL OF A 16 WORD BIT TABLE.
; *
; * OUTPUTS: R0 BIT MAP, BIT CORRESPONDING TO LINE NUMBER IS SET:
; * IF LINE NUMBER IS 3, THEN BIT3 IS SET, ETC.
; *
; * CALLING SEQUENCE: JSR PC,LINBIT
; *
; * COMMENTS: NO CHECKING IS PERFORMED TO VERIFY THAT THE LINE NUMBER IS
; * A LEGAL LINE NUMBER FOR THE DUT (IE - LESS THAN NUMLNS).
; * NOTE: THE LINE NUMBER IS NOT DESTROYED OR ALTERED, SO THIS
; * ROUTINE CAN BE USED EASILY IN LOOPS.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; * - - *****
LINBIT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
BIC #177760,R1 ;MASK OUT ALL BUT 4 LSBITS OF THE LINE #.
ASL R1 ;MULTIPLY LINE # BY 2 TO GET WORD TABLE OFFSET.
MOV BITTBL(R1),R0 ;GET THE SINGLE BIT BIT MAP.
60*: PASS R0 ;RESTORE GPRS, EXCEPT THE FOLLOWING.
MOV R0,ROSL0T(SP) ;PUT R0 IN STACK SLOT.
JSR PC,B(SP) ;RETURN TO PREG05 SUBRT.
RTS PC ;R0 BIT MAP WITH LINE # BIT SET.
```

3092
3093
3094
3095
3096
3097
3098
3099
3100
3101
3102
3103
3104
3105
3106
3107
3108 014676
014676 004567 167156
3109 014702 010201
3110 014704 001405
3111
3112 014706 005002
3113 014710 000261
3114
3115 014712 005502
3116 014714 006301
3117 014716 001375
3118
3119 014720
014720 010266 000006
014724 004736
3120 014726 000207

```

.SBTTL GLOBAL SUBROUTINE MAPCNT
; * *****
; * - COUNT BITS IN BIT MAP ROUTINE -
; * THIS SUBROUTINE COUNTS THE NUMBER OF BITS WHICH ARE SET IN A BIT MAP.
; *
; * INPUTS: R2 - THE BIT MAP FOR WHICH TO COUNT THE BITS.
; *
; * OUTPUTS: R2 - COUNT OF THE NUMBER OF BITS THAT WERE SET.
; *
; * CALLING SEQUENCE: JSR PC,MAPCNT
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; * - *****
MAPCNT:: SAVE R5,PREG05 JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
MOV R2,R1
BEQ 60$ ;EXIT WITH ZERO IF NO BITS ARE SET IN MAP.
CLR R2 ;CLEAR THE BIT COUNT.
SEC ;COUNT THE LAST BIT TO BE SHIFTED OUT.
2$: ADC R2 ;COUNT THE BIT IF IT WAS SET.
ASL R1 ;SHIFT ANOTHER BIT OUT OF THE MAP.
BNE 2$ ;LOOP IF ALL BITS NOT SHIFTED OUT OF MAP.
60$: PASS R2 ;RESTORE GPRS. EXCEPT THE FOLLOWING:
MOV R2,R2SLOT(SP) ;PUT R2 IN STACK SLOT.
JSR PC,B(SP) ;RETURN TO PREG05 SUBRT.
; R2 - COUNT OF BITS SET IN BIT MAP.
    
```

3122
3123
3124
3125
3126
3127
3128
3129
3130
3131
3132
3133
3134
3135
3136
3137
3138
3139
3140
3141
3142
3143
3144
3145
3146
3147
3148
3149
3150
3151
3152
3153
3154
3155
3156
3157
3158
3159
3160 014730
014730 004567 167124
3161
3162
3163
3164
3165 014734 005102
3166 014736 040203
3167
3168
3169
3170 014740 005701
3171 014742 001011
3172 014744 011400
3173 014746 010067 000070
3174 014752 040200
3175 014754 020003
3176 014756 000261
3177 014760 001420

```

.SBTTL GLOBAL SUBROUTINE - MSLGET
;*****
; - MILLI SECONDS LOOP WHICH RETURNS READ WORD AND REMAINING TIME
; THIS SUBROUTINE IS A GENERAL PURPOSE TEST LOOP SUBROUTINE. IT IS USED
; TO VERIFY THAT A CERTAIN ACTION OCCURS BEFORE A TIME-OUT PERIOD. THE
; CALLING ROUTINE PASSES IN WHICH BITS SHOULD BE SET AND CLEARED FOR THE
; DESIRED CONDITION AND THE TIME-OUT VALUE IN MILLI-SECONDS.
; THIS ROUTINE CHECKS FOR THE DESIRED CONDITION UPON ENTRANCE INTO THE
; ROUTINE AND THEN ONCE EACH MILLI-SECOND THERE AFTER.
; UPON RETURN, THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION
; IS RETURNED BY THIS SUBROUTINE.
;
; INPUTS:      R1 - TIME-OUT VALUE IN MILLI-SECONDS (UP TO 64K MS).
;              R2 - BIT MAP OF BITS TO TEST (1 INDICATES TO TEST THE BIT).
;              R3 - DESIRED STATES OF THE INDICATED FIELDS IN R2.
;              R4 - ADDRESS OF THE WORD TO TEST.
;              MSLCNT - MILLI SECOND SOFTWARE LOOP COUNT.
;
; OUTPUTS:     R0 - THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION.
;              R1 - REMAINING NUMBER OF MS IN TIME-OUT TIME.
;              CARRY - SUCCESS FLAG (SET IF CONDITION IS MET BEFORE TIME OUT).
;
; CALLING SEQUENCE:  JSR      PC,MSLGET
;
; COMMENTS:     THIS ROUTINE WORKS WITH OR WITHOUT A HARDWARE CLOCK, BUT THE
;               CALIBRATION IS ONLY GUARENTEED WHEN A LINE CLOCK IS AVAILABLE
;               ON THE SYSTEM.
;               THIS ROUTINE CAN BE USED AS A DELAY ROUTINE, BY SPECIFYING THE
;               DESIRED DELAY AS THE TIME-OUT AND SPECIFYING A CONDITION TO
;               LOOK FOR WHICH WILL NOT BE MET DURING THE DELAY.
;               IF A TIME-OUT VALUE OF 0 IS SPECIFIED, THIS ROUTINE CHECKS FOR
;               THE DESIRED CONDITION BEFORE RETURNING. IT INDICATES SUCCESS
;               IF THE CONDITION IS MET, FAILURE OTHERWISE.
;
; SUBORDINATE ROUTINES CALLED: NONE.
;*****
MSLGET:: SAVE                ;SAVE CONTENTS OF GPRS R0 THRU R5.
;              JSR          R5,PREG05      ;CALL REGISTER SAVE SUBRT.
;
; SET UP MASK FOR REMOVING UNUSED BITS IN THE TEST WORD, AND CLEAR UNUSED
; BITS IN THE DESIRED STATE WORD TO ALLOW DIRECT COMPARISON.
;
;
; COM      R2                ;GET MASK OF UNUSED BITS.
; BIC      R2,R3            ;MASK OUT UNUSED BITS IN DESIRED STATE WORD.
;
; HANDLE THE TEST AND EXIT IF WE HAVE A 0 TIME-OUT VALUE.
;
; TST      R1                ;TEST THE TIME-OUT VALUE FOR ZERO.
; BNE      Z#                ;IF NON-ZERO TIME-OUT, GO LOOP AND TEST.
; MOV      (R4),R0           ;GET THE WORD TO TEST BEFORE EXITING.
; MOV      R0,62#           ;SAVE VALUE SO WE CAN RETURN IT.
; BIC      R2,R0            ;MASK OUT UNTESTED BITS OF WORD.
; CMP      R0,R3            ;COMPARE AGAINST DESIRED STATE WORD.
; SEC                        ;INDICATE SUCCESS IN CASE WORDS ARE EQUAL.
; BEQ      6#                ;EXIT WITH SUCCESS IF WORDS ARE EQUAL.

```

```

3178 014762 000241          CLC          ;INDICATE FAILURE (TIME-OUT).
3179 014764 000416          BR          6$          ;EXIT WITH FAILURE, WORDS AREN'T EQUAL.
3180                          ;*
3181                          ; NON-ZERO TIME-OUT VALUE. LOOP, WAITING FOR CONDITION OR TIME OUT.
3182                          ;*
3183 014766 016705 165334    2$: MOV      MSLCNT,R5      ;LOAD MS LOOP COUNT.
3184 014772 011400          4$: MOV      (R4),R0      ;GET THE WORD TO TEST.
3185 014774 010067 000042    MOV      R0,62$        ;SAVE WORD IN CASE THIS IS THE LAST.
3186 015000 040200          BIC      R2,R0          ;MASK OUT UNTESTED BITS OF WORD.
3187 015002 020003          CMP      R0,R3          ;COMPARE AGAINST DESIRED STATE WORD.
3188 015004 000261          SEC          ;SET CARRY IN CASE OF SUCCESS.
3189 015006 001405          BEQ      6$          ;EXIT WITH SUCCESS IF WORDS ARE EQUAL
3190 015010 005305          DEC      R5          ;COUNT DOWN THE INSIDE MS LOOP COUNT.
3191 015012 001367          BNE      4$          ;LOOP IF MS NOT UP.
3192 015014 005301          DEC      R1          ;DECREMENT THE MS TIME COUNT.
3193 015016 001363          BNE      2$          ;IF TIME NOT UP, LOOP TO COUNT ANOTHER MS.
3194 015020 000241          CLC          ;CLEAR CARRY, WE TIMED-OUT.
3195                          ;*
3196                          ; HAVE EITHER FOUND CONDITION, OR TIMED-OUT (POSSIBLY FROM 0 TIME OUT VALUE).
3197                          ; RESTORE THE LAST CONTENTS READ FROM THE TEST WORD. EXIT ROUTINE.
3198                          ;*
3199 015022 016700 000014    6$: MOV      62$,R0      ;PASS OUT THE LAST READ WORD.
3200 015026          60$: PASS      R0,R1      ;RESTORE GPRS, EXCEPT THE FOLLOWING:
                                MOV      R0,R0SLOT(SP)      ;PUT R0 IN STACK SLOT.
                                MOV      R1,R1SLOT(SP)      ;PUT R1 IN STACK SLOT
                                JSR      PC,8(SP)          ;RETURN TO PREGO'S SUBRT.
                                ;R0 - LAST READ WORD CHECKED FOR CONDITION.
                                ;R1 - REMAINING TIME (0 IF TIME OUT OCCURED).
                                ;CARRY - SET IF SUCCESS, CLEAR IF TIME OUT.
3201                          ;*
3202                          ; LOCAL STORAGE.
3203 015040 000207          RTS      PC
3204                          ;*
3205                          ;*
3206                          ;*
3207 015042 000000          62$: .WORD 0          ;STORAGE FOR THE LAST READ WORD.
    
```



```

3209 .SBTTL GLOBAL SUBROUTINE MSLOOP
3210 ;*****
3211 ;* - TEST LOOP SUBROUTINE -
3212 ;* THIS SUBROUTINE IS A GENERAL PURPOSE TEST LOOP SUBROUTINE. IT IS USED
3213 ;* TO VERIFY THAT A CERTAIN ACTION OCCURS BEFORE A TIME-OUT PERIOD. THE
3214 ;* CALLING ROUTINE PASSES IN WHICH BITS SHOULD BE SET AND CLEARED FOR THE
3215 ;* DESIRED CONDITION AND THE TIME-OUT VALUE IN MILLI-SECONDS.
3216 ;* THIS ROUTINE CHECKS FOR THE DESIRED CONDITION UPON ENTRANCE INTO THE
3217 ;* ROUTINE AND THEN ONCE EACH MILLI-SECOND THEREAFTER.
3218 ;*
3219 ;* INPUTS: R1 - TIME-OUT VALUE IN MILLI-SECONDS (UP TO 64K MS).
3220 ;* R2 - BIT MAP OF BITS TO TEST (1 INDICATES TO TEST THE BIT).
3221 ;* R3 - DESIRED STATES OF THE INDICATED FIELDS IN R2.
3222 ;* R4 - ADDRESS OF THE WORD TO TEST.
3223 ;* MSLCNT - MILLI SECOND SOFTWARE LOOP COUNT.
3224 ;*
3225 ;* OUTPUTS: CARRY - SUCCESS FLAG (SET IF CONDITION IS MET BEFORE TIME-OUT).
3226 ;*
3227 ;* CALLING SEQUENCE: JSR PC,MSLOOP
3228 ;*
3229 ;* COMMENTS: THIS ROUTINE WORKS WITH OR WITHOUT A HARDWARE CLOCK, BUT THE
3230 ;* CALIBRATION IS ONLY GUARENTEED WHEN A LINE CLOCK IS AVAILABLE
3231 ;* ON THE SYSTEM.
3232 ;* THIS ROUTINE CAN BE USED AS A DELAY ROUTINE, BY SPECIFYING THE
3233 ;* DESIRED DELAY AS THE TIME-OUT AND SPECIFYING A CONDITION TO
3234 ;* LOOK FOR WHICH WILL NOT BE MET DURING THE DELAY.
3235 ;* IF A TIME-OUT VALUE OF 0 IS SPECIFIED, THIS ROUTINE CHECKS FOR
3236 ;* THE DESIRED CONDITION BEFORE RETURNING. IT INDICATES SUCCESS
3237 ;* IF THE CONDITION IS MET, FAILURE OTHERWISE.
3238 ;*
3239 ;* SUBORDINATE ROUTINES CALLED: MSLGET.
3240 ;*****
3241
3242 015044 MSLOOP:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
015044 004567 167010 R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3243
3244 ;*
3245 ;* CALLING THE MSLGET ROUTINE FROM THE MSLOOP ROUTINE ISOLATES THE CALLER OF
3246 ;* MSLOOP FROM THE RETURNED TEST WORD AND REMAINING TIME-OUT VALUES.
3247 ;*
3248 015050 004767 177654 JSR PC,MSLGET ;CALL THE MULTI-PURPOSE MS LOOP AND SEARCH RTN.
3249
3250 015054 60$: PASS ;RESTORE GPRS.
015054 004736 PC,8(SP) JSR ;RETURN TO PREG05 SUBRT.
3251 015056 000207 RTS PC ;CARRY - SET IF SUCCESS, CLEAR IF TIME OUT.

```

```

3253 .SBTTL GLOBAL SUBROUTINE OOPS
3254 .** *****
3255 :* - PROGRAM ABORT SUBROUTINE
3256 :* THIS SUBROUTINE IS USED TO ABORT THE PROGRAM WHEN A FATAL ERROR IS
3257 :* DETECTED IN THE PROGRAM OR THE HOST SYSTEM HARDWARE. AN ERROR MESSAGE
3258 :* IS PRINTED GIVING SOME INFORMATION ABOUT THE NATURE OF THE ABORT.
3259 :*
3260 :* INPUTS: R1 - ERROR CODE GIVING REASON FOR ABORT.
3261 :*
3262 :* OUTPUTS: AN ERROR MESSAGE IS PRINTED.
3263 :* A LIST OF RETURN PC VALUES FOR ALL SUBROUTINE CALLS IS PRINTED.
3264 :*
3265 :* CALLING SEQUENCE: JSR PC,OOPS
3266 :*
3267 :* COMMENTS:
3268 :*
3269 :* SUBORDINATE ROUTINES CALLED: NONE.
3270 :* -- *****
3271
3272 015060 OOPS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
015060 004567 166774 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3273 ; REPORT "HOST COMPUTER HARDWARE OR SOFTWARE BUG ENCOUNTERED." ERROR.
3274 ; ERRSF 101,EM0101
015064 104454 TRAP C$ERSF
015066 000145 .WORD 101
015070 015124 .WORD EM0101
015072 000000 .WORD 0
3275 ; REPORT "PROGRAM HUNG. WAITING FOR A CONTROL-C."
3276 PRINTF #EM0102
015074 012746 015210 MOV #EM0102, (SP)
015100 012746 000001 MOV #1, -(SP)
015104 010600 MOV SP,R0
015106 104417 TRAP C$PNTF
015110 062706 000004 ADD #4,SP
3277 015114 2#: BREAK ;LOOK FOR OPERATOR CONTROL-C INPUT.
015114 104422 TRAP C$BRK
3278 015116 000776 BR 2# ;INFINITE LOOP.
3279 015120 60#: PASS ;DON'T NEED THIS, BUT SOMEBODY MAY CHANGE THIS
015120 004736 JSR PC,@(SP); ;RETURN TO PREG05 SUBRT.
3280 015122 000207 RTS PC ; ROUTINE IN THE FUTURE, SO BE CONSISTANT.
3281
3282 015124 110 117 123 EM0101:: .ASCIZ /HOST COMPUTER HARDWARE OR SOFTWARE BUG ENCOUNTERED./
015127 124 040 103
015132 117 115 120
015135 125 124 105
015140 122 040 110
015143 101 122 104
015146 127 101 122
015151 105 040 117
015154 122 040 123
015157 117 106 124
015162 127 101 122
015165 105 040 102
015170 125 107 040
015173 105 116 103
015176 117 125 116
015201 124 105 122

```

	015204	105	104	056	
	015207	000			
3283	015210	045	116	045	EM0102:: .ASCIZ /NAPROGRAM HUNG, WAITING FOR A CONTROL-C. <*****N/N/
	015213	101	120	122	
	015216	117	107	122	
	015221	101	115	040	
	015224	110	125	116	
	015227	107	054	040	
	015232	127	101	111	
	015235	124	111	116	
	015240	107	040	106	
	015243	117	122	040	
	015246	101	040	103	
	015251	117	116	124	
	015254	122	117	114	
	015257	055	103	056	
	015262	040	074	052	
	015265	052	052	052	
	015270	052	052	052	
	015273	052	052	052	
	015276	052	052	052	
	015301	045	116	045	
	015304	116	000		
3284					.EVEN

3286
3287
3288
3289
3290
3291
3292
3293
3294
3295
3296
3297
3298
3299
3300
3301
3302
3303
3304
3305
3306
3307
3308
3309
3310
3311
3312
3313
3314
3315
3316
3317
3318
3319

015306		
015306	004567	166546
015312	016701	164710
015316	016702	164710
015322	042703	177760
015326	056703	164724
015332	010311	
015334	011204	
015336		
015336	010446	
015340	012746	011100
015344	012746	005034
015350	012746	000003
015354	010600	
015356	104415	
015360	062706	000010
015364		
015364	004736	
015366	000207	

```

.SBTTL GLOBAL SUBROUTINE          - PRTLPR
... *****
;
;          -PRINT THE CONTENTS OF THE LPR.
;          THIS ROUTINE IS USED TO PRINT OUT EXTENDED INFORMATION ON THE
;          CONTENTS OF THE LINE PARAMETER REGISTER (LPR).
;
; INPUTS:   R3   CONTAINS THE NUMBER OF THE LINE YOU WISH TO EXAMINE.
;           CSRA - CONTAINS THE ADDRESS OF THE DUT'S CSR.
;           IESTAT - CONTAINS THE CURRENT STATUS OF THE TX AND RX INTERRUPT
;           ENABLE BITS IN THE DUT'S CSR.
;           LPRA - CONTAINS THE ADDRESS OF THE DUT'S LPR REGISTER.
;
; OUTPUTS:  AN EXTENDED INFORMATION MESSAGE IS PRINTED ON THE OPERATORS
;           CONSOLE.
;
; CALLING SEQUENCE:  JSR    PC,PRTLPR
;
; COMMENTS:  THIS ROUTINE CHANGES THE INDIRECT ADDRESS FIELD OF THE DEVICE
;           UNDER TEST'S CSR.
;
; SUBORDINATE ROUTINES CALLED: NONE.
; - - - - -

```

```

PRTLPR::SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
JSR
;GET THE CSR ADDRESS.
MOV CSRA,R1
;GET THE LPR ADDRESS.
MOV LPRA,R2
;CLEAR ANY UNWANTED BITS.
BIC #177760,R3
;SET STATE OF TX AND RX INTERRUPT ENABLE BITS.
BIS IESTAT,R3
;SELECT LINE.
MOV R3,(R1)
;GET CONTENTS OF THE LPR.
MOV (R2),R4
;PRINT MESSAGE"CONTENTS OF THE LPR:NNNNN"
PRINTX #EF9019,#EM9026,R4;PRINT OUT MESSAGE ON OPERATORS CONSOLE.
MOV R4,-(SP)
MOV #EM9026,-(SP)
MOV #EF9019,(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #10,SP

601: PASS ;RESTORE GPRS.
JSR PC,B(SP). ;RETURN TO PREG05 SUBRT.

RTS FC

```

3321
3322
3323
3324
3325
3326
3327
3328
3329
3330
3331
3332
3333
3334
3335
3336
3337
3338
3339
3340
3341
3342
3343
3344
3345
3346
3347
3348
3349
3350
3351
3352
3353
3354
3355
3356
3357
3358
3359
3360
3361
3362
3363
3364
3365
3366
3367
3368
3369

015370
015374
015400
015404
015406
015410
015414
015416
015420
015424
015426
015430
015434
015436
015440
015442
015444
015446
015446
015450

004567
012701
016704
011402
100016
012700
040200
001006
012700
040200
001002
004767
000301
040200
001044
000241
000401
000261
004736
000207

166464
001000
164624
070000
001044

```
.SBTTL GLOBAL SUBROUTINE - PUFIFO
;*****
; - PURGE THE FIFO
; THIS ROUTINE TRIES TO REMOVE ALL THE CHARACTERS FROM THE FIFO.
; ANY BMP CODES THAT ARE FOUND ARE SAVED ON THE BMP CODE QUEUE.
;
; INPUTS: RBUFA- CONTAINS THE ADDRESS OF THE RECEIVER.
;
; OUTPUTS: CARRY BIT - INDICATES THE STATE OF THE FIFO, SET= PURGED.
;          BMPQ - THE CONTENTS OF THE BMP CODE QUEUE MAY BE UPDATED.
;
; CALLING SEQUENCE: JSR PC,PUFIFO
;
; COMMENTS:
;
; SUBORDINATE ROUTINES CALLED: SAVBMP.
;*****
PUFIFO::SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;RS,PREGOS ;CALL REGISTER SAVE SUBRT.
;SET MAXIMUM TRY COUNT OF 512.
;GET ADDRESS OF THE RECEIVER BUFFER REGISTER.
;
; GET THE CONTENTS OF THE RECEIVER BUFFER REG.
;EXIT IF THE FIFO IS EMPTY, DATA_VALID CLR.
;
; CHECK IF THE READ CHARACTER IS ACTUALLY A BMP CODE.
; IF IT IS, THEN SAVE IT ON THE BMP CODE QUEUE TO BE REPORTED LATER.
;
; GENERATE A BIT MAP OF CHAR ERROR BITS
; WHICH ARE NOT SET FOR CHAR.
; THROW CHAR AWAY IF NOT BMP OR SELFTEST CODE.
;
; CHECK IF THE READ DATA IS MODEM STATUS , BMP OR SELFTEST?.
;
; CHECK IF BMP.
; TRY TO CLEAR BMP FLAGS IN THE READ DATA.
; IF IT IS MODEM OR SELFTEST CODE THROW IT AWAY.
; SAVE BMP CODE ON THE QUEUE.
;
; DECREMENT THE TRY COUNT.
; LOOP TO TRY AGAIN.
; CLEAR CARRY, TO INDICATE FIFO NOT PURGED.
; EXIT WITH CARRY CLEAR.
; SET CARRY, TO INDICATE FIFO PURGED.
;
; RESTORE GPRS.
; PC,(SP). ;RETURN TO PREGOS SUBRT.
; CARRY BIT, SET INDICATES FIFO PURGED.
;
RTS PC
```

```

3371
3372
3373
3374
3375
3376
3377
3378
3379
3380
3381
3382
3383
3384
3385
3386
3387
3388
3389
3390
3391
3392
3393
3394
3395
3396
3397
3398
3399 015452
      015452 004567 166402
3400 015456 016746 166370
3401 015462 012705 001000
3402
3403
3404
3405
3406 015466 017702 164536
3407 015472 100063
3408
3409
3410
3411 015474 012700 070000
3412 015500 040200
3413 015502 001012
3414
3415
3416
3417
3418 015504 012767 012544 166344
3419 015512 012700 000300
3420 015516 040200
3421 015520 001003
3422 015522 004767 000752
3423 015526 000430
3424
3425
3426
    
```

```

.SBTTL GLOBAL SUBROUTINE PUFIFR
*****
; - PURGE FIFO REPORT ANY ERRORS FOUND.
; THIS ROUTINE REMOVES ALL DATA FROM THE FIFO. ANY BMP CODES THAT ARE
; FOUND ARE SAVE ON THE QUEUE TO BE REPORTED LATER IN THE BMP REPORT TEST.
; ANY UNEXPECTED DATA (IE ANY NON-STATUS INFORMATION) THAT ARE FOUND,
; ARE REPORTED AS AN ERROR.
; IF THE FIFO WILL NOT PURGE AFTER 512 ATTEMPTS, THEN THE CURRENT TEST
; THAT CALLED THIS ROUTINE RECEIVES A FAILURE FLAG THAT SHOULD BE USED
; TO ABORT THE TEST.
;
; INPUTS: ERRIBL ERRTYPE, ERRMSG, ERRMBR ARE SET UP CORRECTLY.
; RBUFA CONTAINS THE ADDRESS OF THE RECEIVER.
;
; OUTPUTS: CARRY BIT - ABORT TEST FLAG, CLR = ABORT TEST, SET = OK.
; ERRBLK - VALUE WILL BE DASTROYED.
; BMPCPQ - THE BMP CODE QUEUE POINTER MAY BE UPDATED.
; THE CONTENTS OF THE BMP CODE QUEUE MAY BE UDATED.
;
; CALLING SEQUENCE: JSR PC,PUFIFR
;
; COMMENTS: THIS ROUTINE REPORTS ERRORS WITH NUMBERS INITIAL ERRMBR
; THRU TO ERRMBR+2.
; THE ERRMBR IS RESTORED TO ITS INITIAL VALUE BEFORE RETURNING.
;
; SUBORDINATE ROUTINES CALLED: ER1603,ER9001,ER9002,SAVBMP.
*****
PUFIFR::SAVE
      JSR      #R5,REGOS ;SAVE CONTENTS OF GPRS R0 THRU R5.
      MOV     ERRMBR,-(SP) ;CALL REGISTER SAVE SUBRT.
      MOV     #512,R5 ;SAVE THE CONTENTS OF THE ERROR NUMBER.
                       ;SET MAXIMUM READ COUNTER TO 2*FIFO SIZE.
;
; READ DATA FROM THE FIFO UNTIL DATA VALID IS CLEAR OF READ COUNTER IS ZERO.
; REPORT ANY BMP OR UNEXPECTED DATA AS ERRORS.
;
; GET THE CONTENTS OF THE RECEIVER BUFFER REG.
; EXIT IF DATA VALID CLEAR, IE. FIFO PURGED.
      MOV     @RBUFA,R2
      BPL     @R2
;
; CHECK IF READ DATA IS STATUS OR UNEXPECTED CHARACTER.
;
; GENERATE A BIT MAP OF CHAR ERROR BITS
; WHICH ARE NOT SET FOR CHAR.
; SKIP BMP CHECK IF IT IS UNEXPECTED DATA.
      MOV     #70000,R0
      BIC     R2,R0
      BNE     @R2
;
; CHECK IF THE READ DATA IS MODEM STATUS, BMP OR SELFTEST?.
; IF IT IS A BMP CODE THEN SAVE IT ON THE QUEUE.
;
; SET UP THE CORRECT ERROR REPORTING ROUTINE.
; CHECK IF BMP OR _FTEST?.
; TRY TO CLEAR BMP _AGS IN THE READ DATA.
; SKIP BMP ERROR REPORT IF MODEM OR SELFTEST?.
; SAVE THE BMP CODE ON THE QUEUE.
; BRANCH TO CHECK READ COUNT.
      MOV     @ER9001,ERRBLK
      MOV     #300,R0
      BIC     R2,R0
      BNE     @R2
      JSR     PC,SAVBMP
      BR      @R2
;
; CHECK IF THE READ DATA IS MODEM, SELFTEST OR UNEXPECTED DATA.
;
    
```

```

3427 015530 032702 000001      4:  BIT    #BIT0,R2      ;TEST THE MODEM STATUS INDICATION BIT.
3428 015534 001425             BEQ    6:             ;DO NOT REPORT ANY ERROR IF MODEM STATUS.
3429 015536 012701 011124      MOV    #EM9104,R1    ;PASS THE CORRECT ERROR MESSAGE TO REPORT.
3430 015542 010203             MOV    R2,R3        ;EXTRACT THE LINE NUMBER FROM
3431 015544 000303             SWAB   R3           ;THE READ DATA.
3432 015546 042703 177760      BIC    #177760,R3    ;
3433 015552 006303             ASL    R3           ;FORM LINE NUMBER TIMES 2 FOR ER9002 ROUTINE.
3434 015554 052704 100000      BIS    #BIT15,R4    ;SET THE "NONE" EXPECTED MESSAGE FLAG.
3435 015560 005267 166266      INC    ERRNBR       ;SET ERROR NUMBER TO INTIAL ERRBR+1.
3436 015564 012767 012644 166264  MOV    #ER9002,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
3437                                ;REPORT ERROR "UNEXPECTED DATA FOUND IN FIFO".
3438 015572                                ;
015572 104460                                ;
3439                                ;
3440                                ; EXIT WITH FAILURE IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
3441                                ;
3442 015574 032767 000100 164406  BIT    #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
3443 015602 001415             BEQ    7:             ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
3444                                ;DURING THE SOFTWARE QUESTIONS.
3445
3446 015604 005367 166242      DEC    ERRNBR       ;RESTORE ERROR NUMBER TO INTIAL ERRNBR.
3447
3448 015610 005305             DEC    R5           ;DECREMENT READ COUNTER.
3449 015612 001325             BNE    2:           ;LOOP TO READ NEXT CHAR FROM FIFO IF COUNT > 0.
3450
3451                                ;
3452                                ; THE FIFO WILL NOT CLEAR, REPORT THE ERROR AND INDICATE THAT THE TEST IS TO
3453                                ; BE ABORTED.
3454 015614 062767 000002 166230  ADD    #2,ERRNBR    ;SET ERROR NUMBER TO INTIAL ERRNBR+2.
3455 015622 012767 012020 166226  MOV    #ER1603,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
3456 015630 012701 010767      MOV    #EM9017,R1    ;PASS THE MESSAGE TO BE REPORTED.
3457                                ;REPORT THE ERROR "FIFO WILL NOT PURGE, (DATA VALID STUCK SET)"
3458                                ;
3459 015634                                ;
015634 104460                                ;
3460 015636 000241             CLC                    ;INDICATE THE TEST IS TO BE ABOPTED.
3461 015640 000401             BR     10:           ;EXIT THIS ROUTINE AND ABOPT THE CURRENT TEST.
3462
3463 015642 000261             SEC                    ;SET THE CARRY. DO NOT ABOPT THE TEST.
3464
3465 015644 012667 166202      10:   MOV    (SP),ERRNBR  ;RESTORE INITIAL ERROR NUMBER.
3466 015650 004736             60:   PASS           ;RESTORE GPRS.
3467                                ;CARRY BIT, SET INDICATES FIFO PURCED, DO NOT
3468                                ; ABOPT THE TEST.
3469 015652 000207             RTS    PC
    
```

```

3471
3472
3473
3474
3475
3476
3477
3478
3479
3480
3481
3482
3483
3484
3485
3486
3487
3488
3489
3490
3491 015654
      015654 004567 166200
3492 015660 005001
3493 015662 016703 164342
3494 015666 011302
3495 015670 100015
3496
3497
3498
3499
3500
3501 015672 004767 176100
3502 015676 103410
3503 015700 120227 000021
3504 015704 001003
3505 015706 012701 006520
3506 015712 000402
3507 015714 005300
3508 015716 001363
3509 015720 000261
3510 015722 000401
3511 015724 000241
3512
3513 015726
      015726 010166 000004
      015732 004736
3514 015734 000207
    
```

```

.SBTTL GLOBAL SUBROUTINE - READBX
;*****
;* - READ CHARACTERS FROM THE FIFO AND CHECKS FOR BMPS AND XONS
;* THIS SUBROUTINE IS USED IN THE FIMAVL.TST.
;* IT READS THE SPECIFIED NUMBER OF CHARACTERS FROM THE FIFO AND CHECKS
;* FOR BMP CODES AND XON CHARACTERS.
;*
;* INPUTS: RO - CONTAINS THE NUMBER OF CHARS TO READ FROM THE FIFO.
;*
;* OUTPUTS: R1 - CONTAINS ADDRESS OF ERROR MESSAGE TO BE REPORTED
;* CLEAR IF NO ERROR FOUND.
;* CARRY USED TO INDICATE IF FIFO WAS FOUND EMPTY, CARRY CLEAR.
;*
;* CALLING SEQUENCE: JSR PC,READ
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: CHKBMP.
;*****
READBX:: SAVE
          JSR      R5,PREG05 ;SAVE CONTENTS OF GPRS R0 THRU R5.
          CLR      R1        ;CALL REGISTER SAVE SUBRT.
          MOV     RBUFA,R3   ;CLEAR GPR THAT HOLDS THE ADDRESS OF ERRMSG.
2$:      MOV     (R3),R2    ;GET THE ADDRESS OF THE RECEIVER BUFFER REG.
          BPL     8$        ;READ A CHARACTER FROM THE FIFO.
          ;BRANCH IF FIFO IS EMPTY.
;
; CHECK IF THE READ CHARACTER IS A BMP CODE.
; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
; ABORT THE TEST.
;
;
          JSR     PC,CHKBMP ;CHECK IF CHARACTER IS A BMP CODE.
          BCS     6$        ;BRANCH IF A BMP CODE WAS FOUND.
          CMPB   R2,#21    ;CHECK IF IT IS AN XON.
          BNE     4$        ;BRANCH IF NOT AN XON.
          MOV     #EM5402,R1 ;PASS THE MESSAGE TO BE REPORTED.
          BR     6$        ;GO EXIT TEST.
4$:      DEC     R0        ;DECREMENT THE READ COUNT.
          BNE     2$
6$:      SEC     CARRY    ;SET CARRY TO INDICATE SUCCESS.
          BR     8$
8$:      CLC     CARRY    ;EXIT
          ;CLEAR CARRY BIT TO INDICATE FAILURE.
60$:     PASS    R1
          MOV     R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
          JSR     PC,@(SP)    ;RETURN TO PREG05 SUBRT.
          RTS     PC
    
```



```

3516
3517
3518
3519
3520
3521
3522
3523
3524
3525
3526
3527
3528
3529
3530
3531
3532
3533
3534
3535
3536
3537
3538
3539
3540
3541
3542
3543
3544
3545
3546
3547
3548
3549 015736
      015736 004567 166116
3550 015742 005067 000304
3551 015746 012705 000200
3552 015752 000241
3553 015754 017702 164250
3554 015760 100132
3555
3556
3557
3558 015762 012700 170301
3559 015766 040200
3560 015770 001004
3561 015772 004767 000502
3562 015776 005305
3563 016000 001364
3564
3565
3566
3567 016002 010205
3568 016004 042702 177400
3569 016010 120203
3570 016012 001432
3571 016014 012767 000001 000230
    
```

```

.SBTTL GLOBAL SUBROUTINE REPDER
;+ *****
;+ - REPORT DATA ERRORS -
;+ THIS SUBROUTINE IS USED TO REPORT INCORRECT CHARACTERS AND LINE
;+ NUMBERS IN A WORD OF DATA READ FROM THE RXFIFO. THIS ROUTINE
;+ CHECKS FOR THE NUMBER OF INDIVIDUAL DATA ERRORS ON A LINE EXCEEDING
;+ THE REQUESTED AMOUNT AND SETS THE APPROPRIATE ERROR SUMMARY FLAG. IT
;+ THEN STOPS REPORTING ANY FURTHER ERRORS ON THAT LINE. ANY BMP CODES
;+ FOUND ARE SAVED ON THE BMP CODE QUEUE TO BE REPORTED LATER AND ANOTHER
;+ CHARACTER IS READ FROM THE RXFIFO.
;+
;+ INPUTS: R1 - CONTAINS THE NUMBER OF THE UUT.
;+ R3 - LOW BYTE CONTAINS THE EXPECTED CHAR.
;+ ERCNTB - ADDRESS OF THE BASE OF THE ERROR SUMMARY TABLE.
;+ ERRBLK - ADDRESS OF ERROR REPORTING ROUTINE IN ERROR TABLE.
;+ ERRNBR - SET TO THE ERROR NUMBER OF THE FIRST ERROR IN THIS ROUTINE.
;+ EXOERR - ADDRESS OF "EXIT ON ERROR" FLAG.
;+
;+ OUTPUTS: CARRY - CLEAR IF RXFIFO WAS EMPTY, SET OTHERWISE.
;+ ERCNTB - CONTENTS UPDATED TO REFLECT THE CURRENT STATE.
;+ ERRBLK - CONTENTS MAY BE ALTERED.
;+ ERSMRF - ERROR SUMMARY FLAGS UPDATED.
;+ EXOERR - 1 IF AT LEAST ONE ERROR OCCURED.
;+ 0 IF NO ERRORS OCCURED.
;+
;+ CALLING SEQUENCE: JSR PC,REPDER
;+
;+ COMMENTS: THIS ROUTINE REPORTS ERRORS WITH NUMBERS INITIAL ERRNBR
;+ THRU INITIAL ERRNBR+1.
;+
;+ SUBORDINATE ROUTINES CALLED: NONE
;+
;+ *****
REPDER:: SAVE
      JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
      CLR 62# ;CLEAR THE "AN ERROR OCCURED" INDICATOR.
      MOV #128.,R5 ;SET THE MAX BMP READ COUNT.
2# : CLC ;CLEAR THE CARRY IN CASE THE FIFO IS EMPTY.
      MOV BRBUFA,R2 ;READ THE RXFIFO.
      BPL 61# ;EXIT THIS SUBROUTINE WITH CARRY CLEAR IF FIFO EMPTY.
;+
;+ CHECK IF THE CHARACTER IS A BMP CODE.
;+
;+ MOV #170301,R0 ;SET UP THE BIT MASK FOR A BMP CODE.
;+ BIC R2,R0 ;TRY AND CLEAR THE BIT MASK.
;+ BNE 4# ;AVOID SAVING THE CODE IF IT IS NOT A BMP CODE.
;+ JSR PC,SAVBMP ;SAVE THE BMP CODE ON THE QUEUE.
;+ DEC R5 ;DECREMENT THE MAX BMP READ COUNT.
;+ BNE 2# ;READ ANOTHER CHARACTER FROM THE RXFIFO.
;+
;+ VERIFY THAT THE READ CHARACTER IS CORRECT.
;+
;+ MOV R2,R5 ;SAVE THE READ DATA.
;+ BIC #177400,R2 ;CLEAR THE CLUTTER FROM THE DATA CHAR.
;+ CMPB R2,R3 ;COMPARE THE READ CHAR WITH THE EXPECTED CHAR.
;+ BEQ 6# ;AVOID THE ERROR REPORT IF THE DATA IS CORRECT.
;+ MOV #1,62# ;INDICATE AN ERROR WAS OCCURED.
    
```



```
3627 016234 101003           BHI      60$           ;AVOID SETTING THE ERROR SUMMARY FLAG IF THE
3628                          ;NUMBER OF ERRORS REPORTED IS LESS THAN THE
3629                          ;NUMBER REQUESTED.
3630 016236 056467 002336 164346       BIS      BITTBL(R4),ERSMRF ;OTHERWISE SET THE APPROIATE ERROR FLAG.
3631                          ;
3632 016244 000261           60$:    SEC           ;SET THE CARRY FLAG AND INDICATE SUCCESS.
3633 016246           61$:    PASS
3634 016250 000207           RTS      PC      JSR      PC,0(SP)+           ;RETURN TO PREG05 SUBRT.
3635 016252 000000           62$:    .WORD    0           ;STORAGE FOR THE AT LEAST ONE ERROR" INDICATOR.
```

```

3637 .SBTTL GLOBAL SUBROUTINE REPSMR
3638 :* *****
3639 :* - REPORT ERROR SUMMARY ROUTINE -
3640 :* THIS SUBROUTINE REPORTS AN ERROR SUMMARY FOR THOSE LINES WHICH HAVE
3641 :* EXCEEDED THE NUMBER OF INDIVIDUAL ERRORS TO REPORT FOR A SINGLE LINE
3642 :* IN A SINGLE TEST. THIS PARAMETER CAN BE SPECIFIED BY THE OPERATOR IF
3643 :* HE/SHE ANSWERS THE SOFTWARE PARAMETER QUESTIONS.
3644 :*
3645 :* INPUTS: ERCNTB - LABEL AT BASE OF LINE ERROR COUNTERS TABLE.
3646 :* ERRMSG - ADDRESS OF PRIMARY ERROR MESSAGE.
3647 :* ERRNBR - ERROR NUMBER OF ERRORS IN THIS ROUTINE.
3648 :* ERSMRF - "REPORT ERROR SUMMARY FOR LINE" FLAGS.
3649 :*
3650 :* OUTPUTS: ERRBLK - ADDRESS OF ERROR REPORTING ROUTINE (DESTROYED).
3651 :* SUMMARY MESSAGES MAY BE PRINTED AT THE OPERATOR CONSOLE.
3652 :*
3653 :* CALLING SEQUENCE: JSR PC,REPSMR
3654 :*
3655 :* COMMENTS: IF NO LINES HAVE EXCEEDED THE MAXIMUM NUMBER OF INDIVIDUAL
3656 :* ERRORS TO REPORT, NO MESSAGES ARE PRINTED BY THIS ROUTINE.
3657 :* ERROR SUMMARIES IN THIS ROUTINE ARE REPORTED AS ERRORS.
3658 :* THE CONTENTS OF ERRBLK ARE DESTROYED.
3659 :*
3660 :* SUBORDINATE ROUTINES CALLED:
3661 :* - *****
3662
3663 016254 REPSMR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
3664 016254 004567 165600 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3665 016260 005767 164326 TST ERSMRF ;CHECK THE "PRINT LINE ERROR SUMMARY" FLAGS.
3666 016264 001404 BEQ 60$ ;EXIT WITHOUT ACTION IF NO SUMMARY FLAGS SET.
3667 :*
3668 :* WE HAVE SOME ERROR SUMMARIES TO REPORT.
3669 :* -
3669 016266 012767 013022 165562 MOV #ER9004,ERRBLK ;SELECT ERROR REPORTING ROUTINE.
3670 :*
3671 :* REPORT
3672 :* "ERROR SUMMARY REPORT FOR LINES WITH EXCESSIVE NUMBERS OF ERRORS:"
3673 :* -
3674 016274 ERROR
3675 016274 104460 TRAP C$ERROR
3676 016276 004736 60$: PASS ;RESTORE GPRS.
3677 016300 000207 RTS PC JSR PC,B(SP). ;RETURN TO PREG05 SUBRT.

```

```

3679 .SBTTL GLOBAL SUBROUTINE RESETT
3680 ;*****
3681 ;* - RESET DEVICE UNDER TEST -
3682 ;* THIS SUBROUTINE IS USED TO RESET THE DUT TO A KNOWN STATE.
3683 ;* IF RESET DOES NOT SUCCESSFULLY COMPLETE, IF. TIME-OUT OCCURS, THEN
3684 ;* AN ABORT TEST ERROR MESSAGE IS REPORTED.
3685 ;*
3686 ;* INPUTS: CSRA CONTAINS THE ADDRESS OF THE CSR
3687 ;* TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
3688 ;* ERTTBL- ERTTYP,ERNBR,AND ERRMSG SET UP CORRECTLY.
3689 ;*
3690 ;* OUTPUTS: THE DUT PERFORMS ITS RESET FUNCTION INTO A KNOWN STATE.
3691 ;* CARRY - CLEAR INDICATES THE TEST IS TO BE ABORTED.
3692 ;* ERRBLK - VALUE MAY BE DESTROYED.
3693 ;* IESTAT - TX AND RX INTERRUPT FLAGS ARE CLEARED.
3694 ;* TX AND RX INTERRUPT ENABLE BITS IN THE DUT'S CSR ARE CLEARED.
3695 ;*
3696 ;* CALLING SEQUENCE: JSR PC,RESETT
3697 ;*
3698 ;* COMMENTS: THIS SUBROUTINE CAN REPORT ERRORS WITH NUMBERS INITIAL ERRNBR
3699 ;* THIS ROUTINE DOES NOT DESTROY THE VALUE OF ERRNBR.
3700 ;*
3701 ;* SUBORDINATE ROUTINES CALLED: DELAY,MSLGET.
3702 ;*****
3703
3704 016302 RESETT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
016302 004567 165552 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3705 016306 012702 000040 MOV #BIT05,R2 ;SET BIT MASK OF MASTER RESET BIT.
3706
3707 ;*
3708 ;* TEST THE STATE OF THE MASTER RESET BIT IN THE CSR.
3709 ;* IF MR IS SET THEN WAIT FOR SELF-TEST TO COMPLETE.
3710 ;* IF TIME-OUT OCCURS, REPORT THE ERROR AND PASS-OUT ABORT TEST INDICATOR.
3711 016312 016704 163710 MOV CSRA,R4 ;GET THE ADDRESS OF THE DUT'S CSR.
3712 016316 030214 BIT R2,(R4) ;CHECK STATE OF MASTER RESET BIT.
3713 016320 001406 BEQ 2# ;DON'T DELAY IF MR IS ALREADY CLEAR.
3714 016322 005003 CLR R3 ;SET UP DESIRED STATE OF MASTER RESET BIT.
3715 016324 012701 011610 MOV #5000.,R1 ;PASS TIME-OUT VALUE OF 5 SECONDS.
3716 016330 004767 176374 JSR PC,MSLGET ;WAIT FOR SELF-TEST TO COMPLETE. MR CLEAR.
3717 016334 103012 BCC 4# ;GO REPORT ERROR IF TIMEOUT OCCURRED.
3718
3719 ;*
3720 ;* SET MASTER RESET BIT IN CSR. CLEAR TX AND RX ENABLE BITS, ETC.
3721 ;* SKIP THE SELFTEST.
3722 ;* TIME-OUT OF 5 SECS, JUST IN CASE THE SELF-TEST EXECUTES.
3723 ;*
3724 016336 010277 163664 2# MOV R2,#CSRA ;SET MASTER RESET BIT, DISABLE TX AND RX INTS.
3725 016342 004767 000246 JSR PC,SKPSTS ;TRY TO SKIP THE SELFTEST.
3726
3727 ;*
3728 ;* SET SELF-TEST TIME-OUT OF 5 SECONDS, AND WAIT FOR M.R TO CLEAR.
3729 ;* IF TIME-OUT OCCURS, THEN REPORT THE FATAL ERROR AND PASS-OUT THE ABORT
3730 ;* TEST INDICATOR.
3731 016346 005003 CLR R3 ;SET UP DESIRED STATE OF MASTER RESET BIT.
3732 016350 012701 011610 MOV #5000.,R1 ;PASS TIME-OUT VALUE OF 5 SECONDS.
3733 016354 004767 176350 JSR PC,MSLGET ;WAIT FOR SELF-TEST TO COMPLETE. MR CLEAR.
3734 016360 103410 BCS 6# ;SKIP ERROR REPORT IF MR CLEARED IN TIME.

```

```

3735
3736      ; SET UP ERROR MESSAGE TO REPORT "FATAL ERROR FOUND DURING RESET, TEST ABORTED".
3737      ; INDICATE TEST IS TO BE ABORTED BY CLEARING THE CARRY BIT.
3738
3739 016362 012701 005320      4$:   MOV     #EM1601,R1      ;PASS ERROR MESSAGE TO REPORT.
3740 016366 012767 012020 165462  MOV     #ER1603,ERRBLK ;PASS ADDRESS OF ERROR HANDLING ROUTINE.
3741      ;REPORT ERROR "TIME-OUT OCCURRED WAITING FOR MASTER RESET TO CLEAR"
3742      ; "TEST ABORTED"
3743 016374      ERROR      ;          >>>> ERROR <<<<<
3744 016374 104460      TRAP     C$ERROR
3745 016376 000241      CLC          ;INDICATE TEST IS TO BE ABORTED.
3746 016400 000403      BR      60$      ;EXIT THIS SUBROUTINE, ABORT TEST INDICATOR.
3747
3748      ; CLEAR TX AND RX INTERRUPT ENABLE STATUS FLAGS IN IESTAT.
3749      ; EXIT WITH CONTINUE TEST INDICATOR SET (IE,CARR SET).
3750 016402 005067 163650 6$:   CLR     IESTAT      ;CLEAR TX AND RX INTERRUPT STATUS FLAGS.
3751 016406 000261      SEC          ;INDICATE SUCCESS, CONTINUE TEST.
3752
3753 016410      60$:   PASS          ;RESTORE GPRS, PASS THE FOLLOWING INTACT:
3754 016410 004736      JSR          PC,@(SP);RETURN TO PREGO5 SUBRT.
3755      RTS     PC      ;CARRY BIT:IF CLEAR,INDICATES ABORT TEST.
3756

```

```

3758 .SBTTL GLOBAL SUBROUTINE RXIEO
3759 ;** *****
3760 ;* - RECEIVER INTERRUPT DISABLE -
3761 ;* THIS ROUTINE IS USED TO DISABLE RECEIVER INTERRUPTS IN THE DMU11.
3762 ;*
3763 ;* INPUTS: NONE.
3764 ;*
3765 ;* OUTPUTS: THE RX.INT.ENBL BIT IS CLEARED IN THE DUT CSR.
3766 ;* IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
3767 ;* ENABLE BITS.
3768 ;*
3769 ;* CALLING SEQUENCE: JSR PC,RXIEO
3770 ;*
3771 ;* COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
3772 ;* THE DUT CSR ARE DESTROYED.
3773 ;*
3774 ;* SUBORDINATE ROUTINES CALLED: NONE.
3775 ;-- *****
3776 016414 010046 RXIEO:: MOV RO,-(SP) ;SAVE CONTENTS OF RO ON THE STACK.
3777 016416 104440 GETPRI -(SP) ;SAVE PROCESSOR PRIORITY ON STACK.
016416 104440 TRAP C$GPRI
016420 010046 MOV RO,(SP)
3778 016422 SETPRI #PRI07 ;IGNORE ANY INTERRUPT THAT MAY BE GENERATED.
016422 012700 000340 MOV #PRI07,RO
016426 104441 TRAP C$SPRI
3779 016430 042767 137777 163620 BIC #137777,IESTAT ;CLEAR RX.INT.ENBL BIT IN IESTAT.
3780 016436 016777 163614 163562 MOV IESTAT,#CSRA ;DISABLE RX INTERRUPTS.
3781 016444 SETPRI (SP)+ ;ENABLE INTERRUPTS TO THE PROCESSOR AGAIN.
016444 012600 MOV (SP)+,RO
016446 104441 TRAP C$SPRI
3782 016450 012600 MOV (SP)+,RO ;RESTORE RO.
3783 016452 000207 RTS PC

```

3785
3786
3787
3788
3789
3790
3791
3792
3793
3794
3795
3796
3797
3798
3799
3800
3801
3802
3803
3804
3805
3806
3807

016454 052767 000100 163574
016462 042767 137677 163566
016470 016777 163562 163530
016476 000207

```

.SBTTL GLOBAL SUBROUTINE - RXIE1 -
; ** *****
; * - RECEIVER INTERRUPT ENABLE -
; * THIS ROUTINE IS USED TO ENABLE RECEIVER INTERRUPTS IN THE DHU11.
; *
; * INPUTS: NONE.
; *
; * OUTPUTS: THE RX.INT.ENBL BIT IS SET IN THE DUT CSR.
; * IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
; * ENABLE BITS.
; *
; * CALLING SEQUENCE: JSR PC,RXIE1
; *
; * COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
; * THE DUT CSR ARE DESTROYED.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; -- *****
RXIE1:: BIS #BIT06,IESTAT ;SET RX.INT.ENBL BIT IN IESTAT.
        BIC #137677,IESTAT ;CLEAR ALL OTHER BITS, EXCEPT TX AND RX I.E.
        MOV IESTAT,@CSRA ;ENABLE RX INTERRUPTS.
        RTS PC

```



```

3809
3810
3811
3812
3813
3814
3815
3816
3817
3818
3819
3820
3821
3822
3823
3824
3825
3826
3827
3828
3829
3830
3831
3832 016500
      016500 004567 165354
3833 016504 016704 163700
3834 016510 116724 163540
3835 016514 003204
3836 016516 042702 177400
3837 016522 010224
3838 016524 020427 002612
3839 016530 103402
3840 016532 162704 000004
3841 016536 010467 163646
3842
3843 016542
      016542 004736
3844 016544 000207
    
```

```

.SBTTL GLOBAL SUBROUTINE - SAVBMP
;*****
; - SAVE BMP CODES ROUTINE -
; THIS ROUTINE SAVES THE PARAMETER PASSED IN, ONTO THE BMP CODE QUEUE
; TOGETHER WITH THE NUMBER OF THE CURRENTLY EXECUTING TEST.
;
; INPUTS:      R2 - CONTAINS THE BMP CODE THAT IS TO BE PLACED ON THE QUEUE.
;              BMPCOB - CONTAINS ADDRESS OF NEXT LOCATION IN THE BMP QUEUE.
;              BMPCOB - LABEL AT BASE OF THE BMP CODE QUEUE.
;              BMPCOE - LABEL OF NEXT LOCATION AFTER THE END OF THE BMP QUEUE.
;              TSTNUM  CONTAINS THE NUMBER OF THE CURRENT TEST.
;
; OUTPUTS:     BMPCOB - INCREMENTED BY 4.
;              THE CONTENTS OF THE BMP CODE QUEUE ARE UPDATED.
;
; CALLING SEQUENCE:  JSR      PC,SAVBMP
;
; COMMENTS:      IF THE OVERFLOW OCCURS THEN THE LAST LOCATION WILL BE
;                OVERWRITTEN BY ANY SUBSEQUENT ATTEMPTS TO UPDATE THE QUEUE.
;
; SUBORDINATE ROUTINES CALLED: NONE.
;-----
SAVBMP:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;GET THE POINTER TO THE NEXT LOCATION IN QUEUE.
;SAVE THE CURRENT TEST NUMBER ON THE QUEUE.
;INCREMENT THE POINTER TO GIVE AN EVEN ADDRESS.
;CLEAR THE UNWANTED BITS FROM THE BMP CODE.
;SAVE THE BMP CODE ON THE QUEUE.
;CHECK IF OVERFLOW WILL OCCUR THE NEXT TIME.
;GO SAVE THE POINTER IF WE WILL NOT OVERFLOW.
;RESET THE POINTER TO THE LAST LOCATION IN QUE.
;SAVE THE POINTER.
      JSR
      MOV BMPCOB,R4
      MOV TSTNUM,(R4)
      INC R4
      BIC #177400,R2
      MOV R2,(R4)
      CMP R4,#BMPCOE
      BLO 2$
      SUB #4,R4
2$:   MOV R4,BMPCOB
60$:  PASS
      RTS PC JSR ;RESTORE GPRS.
      ;RETURN TO PREG05 SUBRT
    
```

```

3846 .SBTTL GLOBAL SUBROUTINE - SETPAR
3847 ;* *****
3848 ;* - SET TX AND CONTROL PARAMETERS -
3849 ;* THIS SUBROUTINE IS USED IN THE FIMAVL.TST.
3850 ;* IT INITIALISES THE SELECTED LINE TO THE FOLLOWING STATE:
3851 ;* INTERNAL LOOPBACK, I AUTO ENABLED, LPR:38.4K, 8 BITS/CHAR, 2 STOP,
3852 ;* ODD PARITY.
3853 ;*
3854 ;* INPUTS: R1 - CONTAINS NUMBER OF THE LINE TO BE INITIALISED.
3855 ;*
3856 ;* OUTPUTS: LNCTRL AND LPR REGISTERS FOR THE SELECTED LINE ARE DESTROYED.
3857 ;*
3858 ;* CALLING SEQUENCE: JSR PC,SETPAR
3859 ;*
3860 ;* COMMENTS:
3861 ;*
3862 ;* SUBORDINATE ROUTINES CALLED: DELAY,WTWLNLC,WTWLPR.
3863 ;* -- *****
3864
3865 016546 SETPAR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
016546 004567 165306 ;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3866 016552 004767 176072 JSR PC,LINBIT ;GET A BIT MAP FOR THIS LINE.
3867 016556 010005 MOV R0,R5 ;COPY THE LINE BIT MAP.
3868 016560 012700 000206 MOV #206,R0 ;PASS INTERNAL LOPBCK, ENABLE RX AND I AUTO.
3869 016564 004767 000762 JSR PC,WTWLNLC ;INITIALISE THE LINE CONTROL REGISTER.
3870 016570 012700 177670 MOV #177670,R0 ;PASS THE LPR CONTENTS.
3871 016574 004767 001002 JSR PC,WTWLPR ;SET THE LPR CONTENTS TO 38.4K BAUD.
3872 016600 012704 000012 MOV #10.,R4 ;PASS DELAY TIME OF 10 MILLI SECONDS.
3873 016604 004767 175452 JSR PC,DELAY ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
3874
3875 016610 601: PASS ;RESTORE GPRS.
016610 004736 JSR PC,B(SP). ;RETURN TO PREG05 SUBRT.
3876 016612 000207 RTS PC

```

3878
3879
3880
3881
3882
3883
3884
3885
3886
3887
3888
3889
3890
3891
3892
3893
3894
3895
3896
3897
3898 016614
3899 016620
3900 016624
3901
3902
3903
3904 016630
3905
3906
3907 016634
3908 016640
3909 016642
3910 016646
3911 016650
3912 016652
3913 016656
3914 016660
3915 016664
3916
3917 016666
3918 016670

016614 004567 165240
016620 012704 000012
016624 004767 175432

012701 000060

012703 052525
016640 005301
016704 163360
010124
010324
020467 163366
103774
032701 000017
001365

004736
000207

```

.SBTTL GLOBAL SUBROUTINE SKPSTS
; * *****
; * - SKIP SELFTEST ROUTINE -
; * THIS SUBROUTINE IS USED TO SKIP THE SELFTEST AFTER A DUT RESET HAS BEEN
; * INITIATED. IT MUST BE ENTERED IMMEDIATELY AFTER SETTING THE DUT MASTER
; * RESET ROUTINE OR AFTER THE EXECUTION OF A BUS RESET (BECAUSE OF TIMING
; * CONSIDERATIONS).
; *
; * INPUTS: CSRA - CONTAINS ADDRESS OF THE DUT CSR.
; * TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
; *
; * OUTPUTS: SKIP SELFTEST CODES ARE WRITTEN TO THE DUT REGISTERS.
; *
; * CALLING SEQUENCE: JSR PC,SKPSTS
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: DELAY.
; * - - - - -
SKPSTS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
; R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV #10,R4 ;PASS DELAY VALUE OF 10 MILLI-SECONDS.
JSR PC,DELAY ;DELAY FOR 10 MILLI-SECONDS.
; *
; * WRITE SKIP SELF-TEST CODE (52525) TO ALL THE INDEXED DUT REGISTERS.
; * - - - - -
MOV #NUMLNS!BIT05,R1 ;FORM IND.ADR.REG FIELD (PLUS M.R. BIT) WORD.
;THE ABOVE INCLUSION OF THE M.R. BIT IS NECESSARY BECAUSE OF THE
; LACK OF A M.R. BIT WRITE LOCK-OUT ON THE DMU-11.
MOV #52525,R3 ;INITIALISE THE SKIP SELF-TEST CODE.
4$: DEC R1 ;SELECT THE NEXT SET OF DEVICE REGISTERS.
MOV CSRA,R4 ;GET THE ADDRESS OF THE CSR OF THE DUT.
MOV R1,(R4)+ ;SELECT A BANK OF DUT REGISTERS.
6$: MOV R3,(R4)+ ;WRITE THE CODE TO A DUT REGISTER.
CMP R4,TXBFCA ;COMPARE POINTER WITH LAST REGISTER ADDRESS.
BLO 6$ ;LOOP IF NOT ALL REGS DONE IN THIS BANK.
BIT #17,R1 ;TEST FOR IND.ADR.REG FIELD DECREMENTED TO 0.
BNE 4$ ;LOOP UNTIL ALL REGISTERS CONTAIN THE CODE.
60$: PASS ;RESTORE GPRS.
; PC,B(SP). ;RETURN TO PREG05 SUBRT.
RTS PC JSR

```

3920
3921
3922
3923
3924
3925
3926
3927
3928
3929
3930
3931
3932
3933
3934
3935
3936
3937
3938
3939
3940
3941 016672
016672 004567 165162
3942 016676 012701 016714
3943 016702 012767 012020 165146
3944 016710
016710 104460
3945 016712 000432
3946 016714 040 116 117 28:
016717 116 055 122
016722 105 114 101
016725 124 105 104
016730 040 124 105
016733 123 124 040
016736 105 122 122
016741 117 122 040
016744 106 117 125
016747 116 104 040
016752 104 125 122
016755 111 116 107
016760 040 124 105
016763 123 124 040
016766 105 130 105
016771 103 125 124
016774 111 117 116
016777 000
3947
3948 017000
017000 004736
3949 017002 000207

```
.SBTTL GLOBAL SUBROUTINE - TSABRT
;*****
;* - TEST ABORT ROUTINE -
;* THIS SUBROUTINE IS USED WHEN A NON-TEST RELATED ERROR HAS BEEN FOUND
;* DURING THE EXECUTION OF THE CURRENT TEST.
;* IT IS USED TO INFORM THE OPERATOR THAT THE CURRENT TEST HAS BEEN
;* ABORTED.
;*
;* INPUTS: ERRMSG - CONTAINS THE NAME OF THE CURRENT TEST.
;* ERRNBR - CONTAINS THE CORRECT ERROR NUMBER.
;* THE REMAINDER OF THE ERRTB! IS CORRECTLY INITIALISED.
;*
;* OUTPUTS: MESSAGES ARE REPORTED TO THE OPERATOR.
;*
;* CALLING SEQUENCE: JSR PC,TSABRT
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: ER1603.
;-- *****
TSABRT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREGOS ;CALL REGISTER SAVE SUBRT.
MOV #28,R1 ;PASS ADDRESS OF FIRST MESSAGE TO BE REPORTED.
MOV #ER1603,ERRBLK ;SET-UP THE ERROR REPORTING ROUTINE.
ERROR ;>>>> ERROR <<<<<. TRAP C$ERROR
BR 60$ ;
;ASCIZ / NON-RELATED TEST ERROR FOUND DURING TEST EXECUTION/
.EVEN
60$: PASS ;RESTORE GPRS.
;PC,(SP); ;RETURN TO PREGOS SUBRT.
RTS PC
```

3951
3952
3953
3954
3955
3956
3957
3958
3959
3960
3961
3962
3963
3964
3965
3966
3967
3968
3969
3970
3971 017004
017004 004567 165050
3972 017010 010003
3973 017012 012702 002650
3974 017016 004767 175356
3975 017022
017022 004736
3976 017024 000207

```
.SBTTL GLOBAL SUBROUTINE - TXDATP
;*****
;* - TRANSMIT DATA PATTERN -
;* THIS SUBROUTINE IS USED IN THE F1HVL.TST.
;* IT TRANSMITS A SPECIFIED NUMBER OF DATA BYTES ON THE SPECIFIED LINE.
;*
;* INPUTS: R0 - CONTAINS THE NUMBER OF DATA BYTES TO TX.
;* R1 - CONTAINS LINE NUMB ON WHICH TRANSMISSION IS TO TAKE PLACE.
;* BUFBA5 TO BUFMD5 CONTAINS A 256 BYTE DATA PATTERN.
;*
;* OUTPUTS: DATA IS SENT OUT ON THE SPECIFIED LINE.
;* CARRY SET = TX SUCCESSFUL.
;*
;* CALLING SEQUENCE: TXDATP
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: DODMA.
;-- *****
TXDATP:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV R0,R3 ;PASS THE NUMBER OF CHARS TO TX.
MOV @BUFBA5,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
JSR PC,DODMA ;TRANSMIT THE DATA PATTERN.
601: PASS ;RESTORE GPRS.
;PC,(SP)+ ;RETURN TO PREG05 SUBRT.
RTS PC JSR
```

3978
3979
3980
3981
3982
3983
3984
3985
3986
3987
3988
3989
3990
3991
3992
3993
3994
3995
3996
3997
3998
3999
4000
4001 017026
4002 017032 004567 165026
4003 017034 012701 000001
4004 017040 016702 163176
4005 017044 005202
4006 017046 012703 000020
4007 017052 016704 163200
4008 017056 005005
4009
4010
4011
4012 017060 010477 163142
4013 017064 105712
4014 017066 100001
4015 017070 050105
4016
4017
4018
4019
4020 017072 030100
4021 017074 001402
4022 017076 142712 000200
4023 017102 005204
4024 017104 006301
4025 017106 005303
4026 017110 001363
4027
4028 017112
017112 010566 000014
017116 004736
4029
4030 017120 000207

```

.SBTTL GLOBAL SUBROUTINE - TXDSBL
;*****
;* - TRANSMITTER DISABLE -
;* THIS SUBROUTINE IS USED TO DISABLE TRANSMISSION ON SELECTED LINES BY,
;* CLEARING THE ASSOCIATED TX.ENABLE BIT ON THE DUT.
;*
;* INPUTS: R5 - BIT'S SET CORRESPOND TO LINES ON WHICH TO CLEAR TX.ENABLE.
;* CSRA - CONTAINS THE ADDRESS OF THE DUT CSR.
;* IESTAT - CONTAINS THE STATE OF TXIE AND RXIE BITS IN THE CSR.
;* NUMLNS - EQUATED TO BE THE MAXIMUM NUMBER OF LINES AVAILABLE.
;* TXAD2A - CONTAINS THE ADDRESS OF THE TBUFFAD2 REGISTER.
;*
;* OUTPUTS: R5 - BIT'S SET INDICATE THE INITIAL STATES OF ALL TX.ENABLE BITS.
;* TBUFFAD2 - THE STATE OF THE TX.ENABLE BIT MAY BE ALTERED.
;* THE CONTENTS OF THE INO.ADD.REG FIELD IN THE CSR ARE DESTROYED.
;*
;* CALLING SEQUENCE: JSR PC,TXDSBL
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
TXDSBL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;***** JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;*****
;***** ;COPY BIT MAP OF LINES TO DISABLE TRANSMISSION.
;***** ;INITIALIZE THE SELECTED LINE BIT MASK.
;***** ;GET THE ADDRESS OF THE TBUFFAD2 REGISTER.
;***** ;GET THE ADDRESS OF THE MSBYTE OF TBUFFAD2 REG.
;***** ;GET MAXIMUM LINE NUMBER PLUS ONE.
;***** ;GET THE STATES OF THE INT ENABLE BITS.
;***** ;LOG POSSIBLE TX DISABLED ON ALL LINES.
;*****
;***** ; SELECT EVERY LINE IN TURN, AND LOG THE STATE OF EACH TX.ENABLE BIT.
;*****
;***** ;WRITE TO DUT CSR TO SELECT LINE REGISTERS.
;***** ;CHECK STATE OF TX.ENABLE BIT ON SELECTED LINE.
;***** ;SKIP NEXT INSTRUCTION IF TX.ENABLE CLEAR.
;***** ;LOG TX ENABLE BIT SET FOR SELECTED LINE.
;*****
;***** ; CLEAR TX.ENABLE ON LINES THAT HAVE A CORRESPONDING BIT SET IN THE TX DISABLE
;***** ; LINE BIT MAP.
;*****
;***** ;CHECK STATE OF DISABLE LINE BIT MAP.
;***** ;BRANCH IF THIS LINE TO REMAIN UNALTERED.
;***** ;CLEAR TX.ENABLE BIT ON SELECTED LINE.
;***** ;PREPARE TO SELECT REGISTERS FOR NEXT LINE.
;***** ;SHIFT BIT MAP FOR NEXT LINE.
;***** ;DECREMENT LINE NUMBER.
;***** ;LOOP TO CHECK NEXT LINE.
;*****
;***** ;RESTORE GPRS,EXCEPT
;***** ;R5,RSSLOT(SP) ;PUT R5 IN STACK SLOT.
;***** ;PC,B(SP). ;RETURN TO PREG05 SUBRT.
;***** ;R5 - PREVIOUS STATES OF ALL TX.ENABLE BITS.
;*****
RTS PC

```

```

4032 .SBTTL GLOBAL SUBROUTINE TXENBL
4033 : * *****
4034 : * - TRANSMITTER ENABLE -
4035 : * THIS SUBROUTINE IS USED TO ENABLE TRANSMISSION ON SELECTED LINES BY
4036 : * SETTING THE ASSOCIATED TX.ENABLE BIT ON THE DUT.
4037 : *
4038 : * INPUTS: R5 - BIT'S SET CORRESPOND TO LINES ON WHICH TO SET TX.ENABLE.
4039 : * CSRA - CONTAINS THE ADDRESS OF THE DUT CSR.
4040 : * IESTAT - CONTAINS THE STATE OF TXIE AND RXIE BITS IN THE CSR.
4041 : * NUMLNS - EQUATED TO BE THE MAXIMUM NUMBER OF LINES AVAILABLE.
4042 : * TXAD2A - CONTAINS THE ADDRESS OF THE TBUFFAD2 REGISTER.
4043 : *
4044 : * OUTPUTS: R5 - BIT'S SET INDICATE PREVIOUSLY DISABLED LINES.
4045 : * TBUFFAD2 - THE STATE OF THE TX.ENABLE BIT MAY BE ALTERED.
4046 : * THE CONTENTS OF THE IND.ADD.REG FIELD IN THE CSR ARE DESTROYED.
4047 : *
4048 : * CALLING SEQUENCE: JSR PC,TXENBL
4049 : *
4050 : * COMMENTS:
4051 : *
4052 : * SUBORDINATE ROUTINES CALLED: NONE.
4053 : * - *****
4054
4055 TXENBL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
017122 004567 164732 JSR R5,PREG05
4056 017126 010500 MOV R5,R0 ;COPY BIT MAP OF LINES TO ENABLE.
4057 017130 012701 000001 MOV @BIT0,R1 ;INITIALIZE THE SELECTED LINE BIT MASK.
4058 017134 016702 163102 MOV TXAD2A,R2 ;GET THE ADDRESS OF THE TBUFFAD2 REGISTER.
4059 017140 005202 INC R2 ;GET THE ADDRESS OF THE MSBYTE OF TBUFFAD2 REG.
4060 017142 012703 000020 MOV @NUMLNS,R3 ;GET MAXIMUM LINE NUMBER.
4061 017146 016704 163104 MOV IESTAT,R4 ;GET THE STATES OF THE INT ENABLE BITS.
4062 017152 005005 CLR R5 ;CLEAR TX.ENABLE BIT LOG OF DISABLED LINES.
4063
4064 ; *
4065 ; SELECT EVERY LINE IN TURN,AND LOG ANY TX.ENABLE BIT THAT IS CLEAR.
4066 017154 010477 163046 20: MOV R4,BCSRA ;WRITE TO DUT CSR TO SELECT LINE REGISTERS.
4067 017160 105712 YSTB (R2) ;CHECK STATE OF TX.ENABLE BIT ON SELECTED LINE.
4068 017162 100401 BMI 40 ;SKIP NEXT INSTRUCTION IF TX.ENABLE SET.
4069 017164 050105 BIS R1,R5 ;LOG TX ENABLE BIT CLEAR FOR SELECTED LINE.
4070
4071 ; *
4072 ; SET TX.ENABLE ON LINES THAT HAVE A CORRESPONDING BIT SET IN THE TX ENABLE
4073 ; LINE BIT MAP.
4074 017166 030100 40: BIT R1,R0 ;CHECK STATE OF TX.ENABLE LINE BIT MAP.
4075 017170 001402 BEQ 60 ;BRANCH IF THIS LINE TO REMAIN UNALTERED.
4076 017172 152712 000200 BISB @BIT7,(R2) ;ENABLE TRANSMISSION ON SELECTED LINE.
4077 017176 005204 60: INC R4 ;PREPARE TO SELECT REGISTERS FOR NEXT LINE.
4078 017200 006301 ASL R1 ;SHIFT BIT MAP FOR NEXT LINE.
4079 017202 005303 DEC R3 ;DECREMENT LINE NUMBER.
4080 017204 001363 BNE 20 ;LOOP TO CHECK NEXT LINE.
4081
4082 017206 60: PASS R5 ;RESTORE GPRS,EXCEPT
017206 010566 000014 MOV R5,R5,SLOT(SP) ;PUT R5 IN STACK SLOT.
017212 004736 JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
4083 ;R5 - LINE BIT MAP CORRESPONDING TO THE
4084 ; PREVIOUS LINES THAT WERE DISABLED.
4085 017214 000207 RTS PC

```

```

4087 .SBTTL GLOBAL SUBROUTINE TXIEO -
4088 ;* *****
4089 ;* TRANSMITTER INTERRUPT DISABLE -
4090 ;* THIS ROUTINE IS USED TO DISABLE TRANSMITTER INTERRUPTS IN THE DMU11.
4091 ;*
4092 ;* INPUTS: NONE.
4093 ;*
4094 ;* OUTPUTS: THE TX.INT.ENBL BIT IS CLEARED IN THE DUT CSR.
4095 ;* IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
4096 ;* ENABLE BITS.
4097 ;*
4098 ;* CALLING SEQUENCE: JSR PC,TXIEO
4099 ;*
4100 ;* COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
4101 ;* THE DUT CSR ARE DESTROYED.
4102 ;*
4103 ;* SUBORDINATE ROUTINES CALLED: NONE.
4104 ;* *****
4105 017216 010046 TXIEO:: MOV RO,-(SP) ;SAVE CONTENTS OF RO ON THE STACK.
4106 017220 GETPRI -(SP) ;SAVE CURRENT PROCESSOR PRIORITY ON THE STACK.
017220 104440 TRAP C$GPRI
017222 010046 MOV RO,(SP)
4107 017224 SETPRI @PRI07 ;IGNORE ANY INTERRUPTS THAT MAY BE GENERATED.
017224 012700 000340 MOV @PRI07,RO
017230 104441 TRAP C$SPRI
4108 017232 042767 177677 163016 BIC @177677,IESTAT ;CLEAR TX.INT.ENBL BIT IN IESTAT.
4109 017240 016777 163012 162760 MOV IESTAT,@CSRA ;DISABLE TX INTERRUPTS.
4110 017246 SETPRI (SP)+ ;ENABLE INTERRUPTS TO THE PROCESSOR AGAIN.
017246 012600 MOV (SP)+,RO
017250 104441 TRAP C$SPRI
4111 017252 012600 MOV (SP)+,RO ;RESTORE RO.
4112 017254 000207 RTS PC

```



```
4114 .SBTTL GLOBAL SUBROUTINE TXIE1
4115 ;* *****
4116 ;* - TRANSMITTER INTERRUPT ENABLE *****
4117 ;* THIS ROUTINE IS USED TO ENABLE TRANSMITTER INTERRUPTS IN THE DMU11.
4118 ;*
4119 ;* INPUTS: NONE.
4120 ;*
4121 ;* OUTPUTS: THE TX.INT.ENBL BIT IS SET IN THE DUT CSR.
4122 ;* IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
4123 ;* ENABLE BITS.
4124 ;*
4125 ;* CALLING SEQUENCE: JSR PC,TXIE1
4126 ;*
4127 ;* COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
4128 ;* THE DUT CSR ARE DESTROYED.
4129 ;*
4130 ;* SUBORDINATE ROUTINES CALLED: NONE.
4131 ;* - *****
4132
4133 017256 052767 040000 162772 TXIE1:: BIS #BIT14,IESTAT ;SET TX.INT.ENBL BIT IN IESTAT.
4134 017264 042767 137677 162764 BIC #137677,IESTAT ;CLEAR ALL BITS EXCEPT TX RX I.E BITS.
4135 017272 016777 162760 162726 MOV IESTAT,@CSRA ;ENABLE TX INTERRUPTS.
4136 017300 000207 RTS PC
```

```

4138 .SBTTL GLOBAL SUBROUTINE - UNSDIV
4139 ;* *****
4140 ;* - UNSIGNED DIVIDE ROUTINE -
4141 ;* THIS SUBROUTINE IS USED TO DIVIDE A 32 BIT UNSIGNED DIVIDEND BY A
4142 ;* 16 BIT UNSIGNED DIVISOR GIVING A 16 BIT QUOTIENT. ALL NUMBERS ARE
4143 ;* CONSIDERED TO BE UNSIGNED. A SUCCESS FLAG IS NOT SET ON RETURN IF
4144 ;* THE QUOTIENT WAS TOO BIG TO BE CONTAINED IN 16 BITS.
4145 ;*
4146 ;* INPUTS: R1 - THE DIVISOR, UNSIGNED, 16 BITS.
4147 ;* R2 - MOST SIGNIFICANT WORD OF THE DIVIDEND, UNSIGNED, 16 BITS.
4148 ;* R3 - LEAST SIGNIFICANT WORD OF THE DIVIDEND, UNSIGNED, 16 BITS.
4149 ;*
4150 ;* OUTPUTS: R1 - QUOTIENT, UNSIGNED, 16 BITS (177777 IF OVERFLOW).
4151 ;* CARRY - SUCCESS FLAG, SET IF COMPLETE QUOTIENT FITS IN 16 BITS.
4152 ;*
4153 ;* CALLING SEQUENCE: JSR PC,UNSDIV
4154 ;*
4155 ;* COMMENTS: IF THE DIVISOR IS 0 THE QUOTIENT IS RETURNED AS ALL ONES
4156 ;* (177777) AND THE CARRY IS CLEAR REGARDLESS OF THE DIVIDEND.
4157 ;*
4158 ;* SUBORDINATE ROUTINES CALLED: NONE.
4159 ;* - *****
4160
4161 017302 UNSDIV:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
017302 004567 164552 JSR R5,PREGO5 ;CALL REGISTER SAVE SUBRT.
4162 ;*
4163 ;* CHECK FOR QUOTIENT GREATER THAN 16 BITS CONDITION.
4164 ;* -
4165 017306 010204 MOV R2,R4 ;GET MSW OF DIVIDEND FOR SUBTRACT.
4166 017310 160104 SUB R1,R4 ;SUBTRACT DIVISOR FROM MSW OF DIVIDEND.
4167 017312 103403 BCS 2$ ;IF IT DIDN'T GO, WE HAVE QUOTIENT < 16 BITS.
4168 017314 012701 MOV #1,R1 ;SET QUOTIENT TO ALL ONES (177777).
4169 017320 000442 BR 60$ ;EXIT WITH CARRY CLEAR.
4170 ;*
4171 ;* SET UP COUNTERS AND VARIOUS WORKING GPRS.
4172 ;* -
4173 017322 005004 2$: CLR R4 ;CLEAR THE LSW OF THE DIVISOR.
4174 017324 000241 CLC ;CLEAR CARRY FOR THE SHIFT OF THE DIVISOR.
4175 017326 006001 ROR R1 ;DIVISOR BY
4176 017330 006004 ROR R4 ; 2(UNSIGNED)
4177 017332 012700 000020 MOV #16.,R0 ;SET UP INITIAL SHIFT COUNT TO 16.
4178 ;*
4179 ;* THE SUBTRACT AND SHIFT LOOP.
4180 ;* -
4181 017336 010246 4$: MOV R2,-(SP) ;SAVE MSWORD OF DIVIDEND.
4182 017340 010346 MOV R3,-(SP) ;SAVE LSWORD OF DIVIDEND.
4183 017342 160403 SUB R4,R3 ;LSWORD DIVIDEND - LSWORD OF DIVISOR.
4184 017344 005602 SBC R2 ;MSWORD DIVIDEND - BORROW
4185 017346 103402 BCS 6$ ;IF BORROW FROM BORROW SUBTRACT, IT DIDN'T GO.
4186 017350 160102 SUB R1,R2 ;MSWORD DIVIDEND - MSWORD OF DIVISOR.
4187 017352 103003 BCC 8$ ;IF NO BORROW, IT WENT, CARRY IS CLEAR.
4188 ;*
4189 ;* IT DIDN'T GO, SO WE SHIFT A 1 INTO THE QUOTIENT (COMPLEMENTED LATER).
4190 ;* CARRY IS SET.
4191 ;* -
4192 017354 012603 6$: MOV (SP)+,R3 ;RESTORE LSWORD OF DIVIDEND.
4193 017356 012602 MOV (SP)+,R2 ;RESTORE MSWORD OF DIVIDEND.

```

```

4194 017360 000401          BR      10$          ;GOTO SHIFT 1 INTO THE QUOTIENT.
4195                      ;+
4196                      ; IT WENT, SO WE RESTORE THE STACK AND SHIFT A 0 INTO QUOTIENT (WILL BE
4197                      ; COMPLEMENTED LATER).  CARRY IS CLEAR.
4198                      ;-
4199 017362 012626      8$:  MOV      (SP)+,(SP)+      ;POP THE SAVED DIVIDEND OFF OF THE STACK.
4200                      ;+
4201                      ; SHIFT THE RESULT OF THE SUBTRACT ATTEMPT INTO THE QUOTIENT SHIFT REG.
4202                      ;-
4203 017364 006105      10$:  ROL      R5          ;SHIFT NEXT BIT INTO THE INVERTED QUOTIENT.
4204 017366 000241          CLC          ;DIVIDE THE
4205 017370 006001          ROR      R1          ; DIVISOR BY
4206 017372 006004          ROR      R4          ; 2 (UNSIGNED).
4207 017374 005300          DEC      R0          ;COUNT THIS SHIFT AND SUBTRACT.
4208 017376 001357          BNE      4$          ;LOOP FOR ANOTHER SHIFT & SUB IF NOT DONE.
4209 017400 005105          COM      R5          ;GET QUOTIENT FROM INVERTED QUOTIENT.
4210                      ;+
4211                      ; NOW WE EITHER ROUND UP OR LEAVE QUOTIENT ALONE.
4212                      ;-
4213 017402 000241          CLC          ;CLEAR THE CARRY FOR THE SHIFT OF THE DIVIDEND.
4214 017404 006103          ROL      R3          ;MULTIPLY LSWORD OF DIVIDEND BY 2, MSWORD IS 0.
4215 017406 103402          BCS      12$          ;IF CARRY FROM SHIFT, ROUND UP.
4216 017410 160403          SUB      R4,R3          ;SUBTRACT DIVISOR FROM DIVIDEND.
4217 017412 103403          BCS      14$          ;IF BORROW, DON'T ROUND UP.
4218                      ;+
4219                      ; ROUND UP, EXTRA SUBTRACT WENT.
4220                      ;-
4221 017414 005205      12$:  INC      R5          ;INCREMENT THE QUOTIENT BY ONE.
4222 017416 001001          BNE      14$          ;IF NO OVERFLOW, WE LEAVE THE ROUND UP.
4223 017420 005305          DEC      R5          ;DON'T LET ROUNDING CAUSE OVERFLOW.
4224                      ;+
4225                      ; ALL DONE, PASS QUOTIENT AND EXIT.
4226                      ;-
4227 017422 010501      14$:  MOV      R5,R1          ;PASS QUOTIENT BACK IN R1.
4228 017424 000261          SEC          ;INDICATE NO OVERFLOW.
4229                      ;+
4230 017426 010501      60$:  PASS      R1          ;RESTORE GPRS, LEAVE THE FOLLOWING INTACT:
4231 017426 010166 000004          MOV      R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
4232 017432 004736          JSR      PC,@(SP)+ ;RETURN TO PREGOS SUBRT.
                                ;R1 - 16 BIT, UNSIGNED QUOTIENT.
                                ;CARRY - SET INDICATES NO OVERFLOW (SUCCESS).

```

4234
4235
4236
4237
4238
4239
4240
4241
4242
4243
4244
4245
4246
4247
4248
4249
4250
4251
4252
4253
4254
4255
4256
4257
4258
4259
4260
4261
4262 017436
017436 004567 164416
4263 017442 010204
4264 017444 010102
4265 017446 042701 170000
4266 017452 042702 007777
4267 017456 000302
4268 017460 006202
4269 017462 006202
4270 017464 006202
4271 017466 016202 002336
4272 017472 010203
4273 017474 004767 175230
4274
4275 017500 010002
4276 017502
017502 010266 000006
017506 004736
4277
4278 017510 000207

```
.SBTTL GLOBAL SUBROUTINE - WAIBIS
;+ *****
;+ - WAIT FOR BIT SET ROUTINE -
;+ THIS SUBROUTINE WAITS FOR THE SPECIFIED BIT TO BECOME SET. IF THE
;+ SPECIFIED BIT GOES TO A SET STATE WITHIN THE SPECIFIED TIME OUT
;+ PERIOD A SUCCESS INDICATION IS RETURNED BY THIS ROUTINE.
;+ THE LAST VALUE WHICH IS READ LOOKING FOR THE CONDITION IS RETURNED TO
;+ ALLOW THE USE OF THIS ROUTINE TO LOOK FOR DESTRUCTIVE READ CONDITIONS.
;+
;+ INPUTS: R1 - TIME-OUT VALUE AND BIT NUMBER INDICATION:
;+ BITS 15 THRU 12 - NUMBER OF BIT TO TEST (RANGE 0 THRU 15).
;+ BITS 11 THRU 0 - TIME-OUT VALUE IN MILLI-SECONDS (4095 MAX).
;+ R2 - ADDRESS OF WORD CONTAINING THE BIT TO TEST.
;+ MSLCNT.
;+
;+ OUTPUTS: R2 - THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION.
;+ CARRY - SUCCESS FLAG (CARRY SET IF BIT SET BEFORE TIME-OUT).
;+
;+ CALLING SEQUENCE: MOV #130040,R1 ;PASS BIT 11 (13 OCTAL) AND
;+ ; 32 (40 OCTAL) MS DELAY.
;+ MOV #LABEL,R2 ;TEST BIT IN WORD AT "LABEL".
;+ JSR PC,WAIBIS ;WAIT 32 MS FOR BIT 11 TO SET.
;+
;+ COMMENTS:
;+
;+ SUBORDINATE ROUTINES CALLED: MSLGET.
;-- *****

WAIBIS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;SET UP THE ADDRESS PARAMETER FOR MSLGET.
MOV R2,R4
MOV R1,R2
BIC #170000,R1 ;SEPERATE DELAY COUNT OUT OF PASSED PARAMETER.
BIC #7777,R2 ;SEPERATE LINE NUMBER FIELD OF PASSED PARAM.
SWAB R2 ;PUT LINE NUMBER FIELD IN LSBYTE.
ASR R2 ;SHIFT THE LINE NUMBER FIELD INTO THE PROPER
; POSITION TO USE IT AS A WORD TABLE OFFSET
ASR R2 ; FOR THE TABLE LOOKUP OF THE LINE BIT MAP.
ASR R2 ;GET BIT MAP OF LINE TO TEST FROM TABLE.
MOV BITTBL(R2),R2 ;INDICATE THAT THE BIT SHOULD BE SET.
MOV R2,R3 ;WAIT FOR THE BIT TO BE SET WITHIN TIME OUT.
JSR PC,MSLGET ;CARRY IS CORRECT UPON MSLGET RETURN.
;PASS LAST VALUE READ AS OUTPUT PARAMETER.
;RESTORE GPRS, EXCEPT THE FOLLOWING:
MOV R0,R2 ;PUT R2 IN STACK SLOT.
PASS R2 ;RETURN TO PREG05 SUBRT.
MOV R2,R2SLOT(SP)
JSR PC,@(SP)
; R2 - LAST VALUE READ LOOKING FOR CONDITION.
; CARRY - SUCCESS FLAG (SET IF BIT FOUND SET).
```

```

4280 .SBTTL GLOBAL SUBROUTINE                                WAITTX
4281 ;** *****
4282 ;* - WAIT FOR TX TO FINISH
4283 ;* THIS SUBROUTINE IS USED IN THE FIHAWL.TST.
4284 ;* IT WAITS FOR TRANSMISSION TO COMPLETE IE TX_ACTION. THEN DELAYS
4285 ;* FOR 5 MILLISECONDS TO ALLOW TIME FOR THE LAST CHARACTER TO GET INTO
4286 ;* THE FIFO.
4287 ;*
4288 ;* INPUTS:      CSRA  CONTAINS THE ADDRESS OF THE CSR.
4289 ;*
4290 ;* OUTPUTS:     CARRY - SET INDICATES SUCCESS.
4291 ;*
4292 ;* CALLING SEQUENCE:  JSR      PC,WAITTX
4293 ;*
4294 ;* COMMENTS:
4295 ;*
4296 ;* SUBORDINATE ROUTINES CALLED: DELAY,WAIBIS.
4297 ;-- *****
4298
4299 017512          WAITTX:: SAVE                               ;SAVE CONTENTS OF GPRS R0 THRU R5.
017512 004567 164342          JSR                               RS,PREG05 ;CALL REGISTER SAVE SUBRT.
4300 017516 012701 170536          MOV #170536,R1             ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
4301 017522 016702 162500          MOV CSRA,R2                ;PASS THE ADDRESS OF THE CSR.
4302 017526 004767 177704          JSR PC,WAIBIS              ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
4303 017532 103005          BCC 60$                          ;BRANCH IF NO TX_ACTION, ABORT THE TEST.
4304 017534 012704 000005          MOV #5,R4                  ;PASS DELAY OF 5 MILLI SECS.
4305 017540 004767 174516          JSR PC,DELAY               ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
4306 017544 000261          SEC                                ;SET CARRY TO INDICATE SUCCESS.
4307
4308 017546          60$: PASS                                ;RESTORE GPRS.
017546 004736          JSR PC,B(SP)                          ;RETURN TO PREG05 SUBRT.
4309
4310 017550 000207          RTS PC                             ;PASS THE CARRY BIT, SET INDICATES SUCCESS.

```

4312
 4313
 4314
 4315
 4316
 4317
 4318
 4319
 4320
 4321
 4322
 4323
 4324
 4325
 4326
 4327
 4328
 4329
 4330
 4331
 4332
 4333
 4334
 4335 017552
 017552 004567 164302
 4336
 4337
 4338
 4339 017556 016701 162454
 4340 017562 010002
 4341 017564 010503
 4342 017566 012704 177777
 4343
 4344
 4345
 4346 017572 004767 173572
 4347
 4348 017576
 017576 004736
 4349 017600 000207

```

.SBTTL GLOBAL SUBROUTINE WTWLNC
;*****
;* - LINE CONTROL REGISTER SETUP ROUTINE
;* THIS SUBROUTINE IS USED TO SET THE DEVICE UNDER TEST (DUT) LINE
;* CONTROL REGISTERS (LNCTRL) TO THE SPECIFIED STATE. ONLY THE LNCTRLS
;* FOR THE SPECIFIED LINES ARE ALTERED.
;*
;* INPUTS: R0 - NEW LINE PARAMETERS.
;* R5 - BIT MAP OF LINES TO BE ALTERED.
;* CSRA - CONTAINS ADDRESS OF THE DUT CSR.
;* IESTAT - CONTAINS THE CURRENT STATE OF THE TX AND RX INTERRUPT
;* ENABLE BITS IN THE CSR.
;* LNCTRA CONTAINS ADDRESS OF THE DUT LNCTRL REGISTERS.
;*
;* OUTPUTS: LNCTRL - SPECIFIED DUT LINE CONTROL REGISTERS ARE ALTERED.
;*
;* CALLING SEQUENCE: JSR PC,WTWLNC
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: ALTFLD.
;*****
WTWLNC:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
; R5,PREGOS ;CALL REGISTER SAVE SUBRT.
;
; SET UP THE PARAMETERS FOR THE CALL TO ALTFLD.
;
MOV LNCTRA,R1 ;SET UP THE REGISTER ADDRESS PARAMETER.
MOV R0,R2 ;SET UP THE DESIRED REGISTER CONTENTS.
MOV R5,R3 ;SET UP THE BIT MAP OF LINES TO ALTER.
MOV #-1,R4 ;SELECT ALL REGISTER BITS TO BE ALTERED.
;
; CALL THE SUBROUTINE WHICH ALTERS THE REGISTER CONTENTS.
;
JSR PC,ALTFLD ;ALTER THE REGISTER CONTENTS.
;
601: PASS ;RESTORE GPRS.
RTS PC JSR PC,@(SP) ;RETURN TO PREGOS SUBRT.
    
```

4351
4352
4353
4354
4355
4356
4357
4358
4359
4360
4361
4362
4363
4364
4365
4366
4367
4368
4369
4370
4371
4372
4373
4374 017602
017602 004567 164252
4375
4376
4377
4378 017606 016701 162420
4379 017612 010002
4380 017614 010503
4381 017616 012704 177777
4382
4383
4384
4385 017622 004767 173542
4386
4387 017626
017626 004736
4388 017630 000207

```
.SBTTL GLOBAL SUBROUTINE                                WTWLPR
;*****
;* - LINE PARAMETER REGISTER SETUP ROUTINE -
;* THIS SUBROUTINE IS USED TO SET THE DEVICE UNDER TEST (DUT) LINE
;* PARAMETER REGISTERS (LPR) TO THE SPECIFIED STATE. ONLY THE LPRS FOR
;* THE SPECIFIED LINES ARE ALTERED.
;*
;* INPUTS:      RO - NEW LINE PARAMETERS.
;*              RS - BIT MAP OF LINES TO BE ALTERED.
;*              CSRA - CONTAINS ADDRESS OF THE DUT CSR.
;*              IESTAT - CONTAINS THE CURRENT STATE OF THE TX AND RX INTERRUPT
;*              ENABLE BITS IN THE CSR.
;*              LPRA  CONTAINS ADDRESS OF THE DUT LPR.
;*
;* OUTPUTS:     LPR - SPECIFIED DUT LINE PARAMTER REGISTERS ARE ALTERED.
;*
;* CALLING SEQUENCE:  JSR      PC,WTWLPR
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED:  ALTFLD.
;-- *****
WTWLPR:: SAVE                                ;SAVE CONTENTS OF GPRS R0 THRU R5.
;*                                           JSR      R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;*
;* SET UP THE PARAMETERS FOR THE CALL TO ALTFLD.
;*
;*      MOV     LPRA,R1      ;SET UP THE REGISTER ADDRESS PARAMETER.
;*      MOV     R0,R2       ;SET UP THE DESIRED REGISTER CONTENTS.
;*      MOV     R5,R3       ;SET UP THE BIT MAP OF LINES TO ALTER.
;*      MOV     #-1,R4      ;SELECT ALL REGISTER BITS TO BE ALTERED.
;*
;* CALL THE SUBROUTINE WHICH ALTERS THE REGISTER CONTENTS.
;*
;*      JSR     PC,ALTFLD   ;ALTER THE REGISTER CONTENTS.
;*
600:  PASS                                ;RESTORE GPRS.
;*                                           JSR      PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
;*      RTS     PC
```

4390
4391
4392
4393
4394
4395
4396
4397
4398
4399
4400
4401
4402
4403
4404
4405
4406
4407
4408
4409
4410
4411
4412
4413
4414
4415
4416
4417
4418
4419
4420
4421
4422
4423
4424
4425

017632 005767 162456
017636 001402
017640 005367 162450
017644 005767 162446
017650 001402
017652 005367 162440
017656 005367 162436
017662 001006
017664 016767 162432 162426
017672 010046
017674 104422
017676 012600
017700 000002

```
.SBTTL INTERRUPT SERVICE ROUTINE - CLKINT
;*****
; THIS ROUTINE IS EXECUTED CLKHRZ TIMES PER SECOND. IT DECREMENTS THE
; TWO TIMER COUNTERS DOWN TO ZERO.
;
; INPUTS:    TIMER1 - TIMER COUNTER #1.
;            TIMER2 - TIMER COUNTER #2.
;            TIMER3 - TIMER COUNTER FOR CALL OF BREAK MACRO.
;
; OUTPUTS:   THE 2 TIMER COUNTERS ARE DECREMENTED IF THEY ARE NOT ZERO.
;
; CALLING SEQUENCE:  PUT #CLKINT IN THE CLOCK INTERRUPT VECTOR SLOT.
;                    PUT THE DESIRED TIME PERIOD (SECONDS TIMES CLKHRZ) IN
;                    EITHER TIMER1 OR TIMER2 AND POLL THE RESPECTIVE TIMEP
;                    COUNTER TO DETECT ITS GOING TO 0 ON TIME-OUT.
;
; COMMENTS:   THE 2 COUNTERS WILL NOT WRAPAROUND BUT WILL STOP AT 0. THIS
;             ALLOWS THE DETECTION OF A TIME-OUT ANY TIME AFTER THE TIME-OUT
;             HAS OCCURRED UNTIL THE TIMER COUNTER IS SET TO ANOTHER VALUE.
;
; SUBORDINATE ROUTINES CALLED: NONE.
;-----*****
CLKINT:: TST    TIMER1      ;CHECK FOR TIMER1 AT ZERO.
        BEQ    2$          ;BRANCH TO LEAVE IT AT ZERO IF IT IS ZERO.
        DEC    TIMER1      ;DECREMENT TIME COUNT.
2$:     TST    TIMER2      ;CHECK FOR TIMER2 AT ZERO.
        BEQ    4$          ;BRANCH TO LEAVE IT ALONE IF IT'S ALREADY ZERO.
        DEC    TIMER2      ;DECREMENT TIME COUNT.
4$:     DEC    TIMER3      ;DECREMENT THE BREAK COUNT.
        BNE    60$         ;EXIT IF NOT TIME TO CALL BREAK.
        MOV    BCOUNT,TIMER3 ;SET UP TIME TILL NEXT BREAK.
        MOV    RO,-(SP)    ;SAVE CONTENTS OF RO FROM BREAK MACRO.
        BREAK              ;CHECK FOR OPERATOR CONTROL/C.          TRAP    C$BRK
60$:   MOV    (SP)+,RO     ;RESTORE CONTENTS OF RO.
        RTI
```



```

4427 .SBTTL INTERRUPT SERVICE ROUTINE RXDECT
4428 ;** *****
4429 ;* - RX INT DECTION ROUTINE
4430 ;* THIS ROUTINE DETECTS AN RX INTERRUPT BY SETTING THE RXINTC WORD TO 1.
4431 ;* THIS ROUTINE IS USED IN THE RXTIMER TESTS.
4432 ;*
4433 ;* INPUTS: RXINTC - STORGE FOR THE INTERRUPT COUNT.
4434 ;*
4435 ;* OUTPUTS: RXINTC - SET TO 1.
4436 ;*
4437 ;* CALLING SEQUENCE: PUT THE ADDRESS OF THE LABEL RXDECT IN THE VECTOR
4438 ;* LOCATION.
4439 ;*
4440 ;* COMMENTS: THIS ROUTINE DOES NOT READ THE RXFIFO.
4441 ;*
4442 ;* SUBORDINATE ROUTINES CALLED: NONE.
4443 ;-- *****
4444
4445 017702 012767 000001 162356 RXDECT:: MOV 01,RXINTC ;INDICATE THAT AN RX-INT HAS OCCURED.
4446 017710 000002 RTI

```

```

4448 .SBTTL GLOBAL TRAP SERVICE ROUTINE - TP4RTN
4449 ;*****
4450 ;* BUS TIME-OUT TRAP (004 TRAP) SERVICE ROUTINE -
4451 ;* THIS ROUTINE DETERMINES IF THE 004 TRAP WAS CAUSED BY
4452 ;* AN "EXPECTED" ERROR OR NOT BY EXAMINING THE RETURN PC VALUE ON THE
4453 ;* STACK. IF THE TRAP IS UNEXPECTED, THIS ROUTINE JUMPS TO THE NORMAL
4454 ;* DIAGNOSTIC SUPERVISOR 004 TRAP HANDLING ROUTINE.
4455 ;*
4456 ;*
4457 ;* INPUTS: SP - POINTS TO THE PC WHERE THE TRAP OCCURED.
4458 ;* ADRPTR - LABEL AT THE ADDRESS WHERE "EXPECTED" TRAPS OCCUR.
4459 ;* TP4FLG - 004 TRAP FLAGS.
4460 ;*
4461 ;* OUTPUTS: TP4FLG - BIT 15 IS SET IF "EXPECTED" TRAP OCCURED.
4462 ;*
4463 ;* CALLING SEQUENCE: PUT ADDRESS POINTED TO BY TP4RTN IN 004 VECTOR.
4464 ;* OCCURENCE OF 004 TRAP VECTORS TO THIS ROUTINE.
4465 ;*
4466 ;* COMMENTS: ANY 004 TRAP WHICH OCCURS AT AN ADDRESS OTHER THAN THAT LABELED
4467 ;* ADRPTR WILL BE HANDLED BY THE NORMAL 004 TRAP SERVICE ROUTINE.
4468 ;*
4469 ;* SUBORDINATE ROUTINES CALLED: NONE.
4470 ;*****
4471
4472 017712 021627 014200 TP4RTN:; CMP (SP),#ADRPTR ;COMPARE EXPECTED ADR AGAINST TRAP RET PC.
4473 017716 001402 BEQ 2$ ;IF THEY MATCH, CONTINUE THIS ROUTINE.
4474 017720 000177 162352 JMP @TP4VEC ;IF NOT, JUMP TO NORMAL 004 TRAP SERVICE RTN.
4475 017724 052767 100000 162346 2$: BIS #BIT15,TP4FLG ;SET THE 004 TRAP OCCURED FLAG.
4476 017732 000002 RTI ;ALL DONE, GO BACK TO THE TEST.
    
```

```

4478 .SBTTL INTERRUPT SERVICE ROUTINE TXAINT
4479 ;* *****
4480 ;* - TRANSMIT ACTION INTERRUPT SERVICE ROUTINE
4481 ;* THIS ROUTINE HANDLES A TX INTERRUPT BY COUNTING THE INTERRUPT,
4482 ;* SETTING A FLAG IF THE TX_ACTION BIT IS CLEAR, AND READING THE CSR
4483 ;* UNTIL THE TX_ACTION BIT CLEARS OR THE MAXIMUM READ COUNT IS EXCEEDED.
4484 ;*
4485 ;* INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR.
4486 ;* TXINTC - HOLDS THE COUNT OF THE NUMBER OF TX INTERRUPTS.
4487 ;* TXINTF - TX INTERRUPT FLAGS.
4488 ;*
4489 ;* OUTPUTS: TXINTC - CONTAINS THE UPDATED TX INTERRUPT COUNT.
4490 ;* TXINTF - TX INTERRUPT FLAGS (BIT 15 SET IF TX_ACTION CLEAR
4491 ;* BIT 14 SET IF MAX READ COUNT EXCEEDED)
4492 ;*
4493 ;* CALLING SEQUENCE: PUT THE ADDRESS OF THE LABEL TXAINT IN THE VECTOR
4494 ;* LOCATION.
4495 ;*
4496 ;* COMMENTS:
4497 ;*
4498 ;* SUBORDINATE ROUTINES CALLED: NONE
4499 ;*
4500 ;* - *****
4501
4502 TXAINT:: SAVE JSR R5,PREGOS ;CALL REGISTER SAVE SUBRT.
4503 017734 017734 004567 164120
4504 017740 016701 162326 MOV TXINTC,R1 ;GET THE TX INT COUNT.
4505 017744 005201 INC R1 ;INCREMENT THE COUNT.
4506 017746 102001 BVC 20 ;BRANCH IF NO OVERFLOW OCCURED.
4507 017750 005301 DEC R1 ;RESET THE COUNT TO 177777.
4508 017752 010167 162314 20: MOV R1,TXINTC ;SAVE THE NEW COUNT.
4509 017756 016703 162312 MOV TXINTF,R3 ;GET THE TX-INT FLAGS.
4510 017762 005777 162240 TST @CSRA ;READ THE CSR.
4511 017766 100402 BMI 40 ;AVOID SETTING THE ERROR FLAG IF
4512 ;THERE IS A TX_ACTION.
4513 017770 052703 100000 BIS @BIT15,R3 ;SET THE FLAG.
4514 017774 010367 162274 40: MOV R3,TXINTF ;UPDATE THE TX-INT FLAGS.
4515 020000 012702 000040 MOV @32.,R2 ;SET THE MAX TX_ACTION READ COUNT.
4516 ;*
4517 ;* READ THE CSR UNTIL THE TX_ACTION FIFO IS EMPTY OR THE MAX READ COUNT
4518 ;* IS EXCEEDED.
4519 ;*
4520 020004 005777 162216 60: TST @CSRA ;READ THE CSR.
4521 020010 100005 BPL 60 ;EXIT IF TX_ACTION FIFO IS EMPTY.
4522 020012 005302 DEC R2 ;DECREMENT THE MAX READ COUNT.
4523 020014 001373 BNE 60 ;BRANCH TO READ ANOTHER TX_ACTION IF MAX READ
4524 ;COUNT IS NOT EXCEEDED.
4525 020016 052767 040000 162250 BIS @BIT14,TXINTF ;SET THE "MAX TX_ACTION COUNT EXCEEDED" FLAG.
4526 020024 020024 004736 60: PASS
4527 020026 000002 RTI JSR PC,@(SP); ;RETURN TO PREGOS SUBRT.

```

110

4536
4537
4538
4539
4540
4541
4542
4543
4544

.SBTTL REPORT CODING SECTION

; THE REPORT CODING SECTION CONTAINS THE
; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.

4545 020030
020030
4546
4547 020030
020030 000167
020032 000000
4548
4549
4550
4551 020034
020034
020034 104425

BGNRPT

L\$RPT::

EXIT RPT

.WORD J\$JMP
.WORD L10017-2..

.EVEN

ENDRPT

L10017: TRAP C\$RPT

4553
4561
4562
4563
4564
4565
4566
4567
4568
4569
4570
4571
4572
4573
4574
4575

020036
020036
177777
020040 177777
020042 177777
020044

.SBTTL PROTECTION TABLE

; THIS TABLE IS USED BY THE RUNTIME SERVICES
; TO PROTECT THE LOAD MEDIA.

BGNPROT

L#PROT::

-1 ;OFFSET INTO P-TABLE FOR CSR ADDRESS
1 ;OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
-1 ;OFFSET INTO P-TABLE FOR DRIVE NUMBER

ENDPROT

```

4597
4598
4599
4600
4601
4602
4603
4604
4605
4606
4607
4608
4609
4610
4611 020044
      020044
4612
4613 020044 012700 000040
      020044 104447
      020050
4614 020052 103416
      020052
4615
4616 020054 012700 000037
      020054 104447
      020060
4617 020062 103556
      020062
4618
4619 020064 012700 000035
      020064 104447
      020070
4620 020072 103555
      020072
4621
4622 020074 012700 000036
      020074 104447
      020100
4623 020102 103161
      020102 103161
4624 020104 000167 000540
      020104
4625 020110
4626 020110 104433
      020110
4627
4628
4629
4630 020112 012700 000114
      020112 104462
      020116 010001
      020120
4631 020122 012167 162156
      020122 012167 162154
4632 020126 012167 162152
      020126 012167 162150
4633 020132 012167 162150
      020132 026727 162144 000062
4634 020136 026727 162144
      020136 001004
4635 020142
4636 020150

```

```

.SBTTL INITIALIZE SECTION
; **
; *****
; * THIS SECTION CONTAINS THE CODE WHICH IS PERFORMED AT THE BEGINNING OF
; * EACH PASS OR AFTER A CONTINUE COMMAND.
; * THIS CODE PERFORMS THE FOLLOWING ACTIONS:
; *
; * MOVES THE INFORMATION HELD IN THE HARDWARE P-TABLE INTO THE GLOBAL
; * DATA AREA.
; *
; *****
; --
      BGNINIT
;SEE IF PROGRAM JUST STARTED, BR IF YES
      READEF @F.START
;SEE IF PROGRAM JUST RESTARTED, BR IF YES
      READEF @EF.RESTART
;SEE IF THIS IS A NEW PASS, BR IF YES
      READEF @EF.NEW
;SEE IF PROGRAM WAS JUST CONTINUED
      READEF @EF.CONTINUE
      L$INIT::
      MOV TRAP @EF.START,RO
      BCS NEWSTA
      MOV TRAP @EF.RESTART,RO
      BCS NEWRES
      MOV TRAP @EF.NEW,RO
      BCS NEWPAS
      MOV TRAP @EF.CONTINUE,RO
      BCC GETPRM
      JMP ENDIT
NEWSTA:
      BRESET ;RESET THE BUS TO PREVENT ILLEGAL INTERRUPTS.
; *
; * SET UP FOR LINE TIME CLOCK INTERRUPTS.
; *
; * GET THE CLOCK PARAMETERS.
      CLOCK L,R1
      MOV @L,RO
      TRAP C$CLK
      MOV RO,R1
      MOV (R1)+,CLKCSR ;STORE CLOCK CSR ADDRESS.
      MOV (R1)+,CLKBRL ;STORE CLOCK BUS REQ INT LEVEL.
      MOV (R1)+,CLKVEC ;STORE CLOCK INTERRUPT VECTOR.
      MOV (R1)+,CLKHRZ ;STORE CLOCK FREQUENCY.
      CMP CLKHRZ,#50. ;TEST FOR 50HZ LINE FREQUENCY.
      BNE 2$ ;BRANCH IF CLOCK IS NOT 50HZ.

```

```

4637 020152 012767 000024 162144      MOV    #20.,MSTICK      ;INDICATE 20MS PER CLOCK TICK.
4638 020160 000403                BR      4#
4639 020162 012767 000021 162134 2# :   MOV    #17.,MSTICK      ;INDICATE 17 MS PER CLOCK TICK.
4640 020170 012746 000300                4# :   SETVEC CLKVEC,#CLKINT,#PRI06 ;INITIALIZE CLOCK INTERRUPT VECTOR.
                                MOV    #PRI06,(SP)
                                MOV    #CLKINT,(SP)
                                MOV    CLKVEC,-(SP)
                                MOV    #3,-(SP)
                                TRAP   C$SVEC
                                ADD    #10,SP
4641 020216 016700 162070      MOV    CLKHRZ,RO        ;INITIALIZE THE BREAK COUNT
4642 020222 006300                ASL    RO                ; TO CAUSE A BREAK
4643 020224 010067 162072      MOV    RO,BCOUNT        ; EVERY 2 SECONDS.
4644 020230 012700 000240      SETPRI #PRI05           ;ALLOW CLOCK INTERRUPTS DISABLE OTHERS.
                                MOV    #PRI05,RO
                                TRAP   C$SPRI
4645
4646 ;+
4647 ; ENABLE THE LINE TIME CLOCK (LTC) CHECKING TO MAKE SURE THAT THE CSR
4648 ; IS ACCESSABLE.
4649 ; FIRST SET UP TO CATCH ANY 004 TRAPS WHICH OCCUR:
4650 020236 016767 157542 162032      MOV    4,TP4VEC         ;SAVE THE EXISTING 004 TRAP VECTOR.
4651 020244 012767 017712 157532      MOV    #TP4RTN,4        ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4652
4653 ;+
4654 ; ENABLE LTC CHECKING FOR 004 TRAP IN CASE CSR IS NOT THERE.
4655 020252 005067 162022                CLR    TP4FLG           ;CLEAR THE 004 TRAP FLAG.
4656 020256 012767 000100 162016      MOV    #BIT6,WORD1      ;SET UP TO SET BIT6 OF THE LTC CSR.
4657 020264 012700 002302                MOV    #WORD1,RO        ;SET UP WORD1 AS THE CKTRAP MOVE SOURCE.
4658 020270 016701 162010                MOV    CLKCSR,R1        ;SET UP LTC CSR AS DESTINATION FOR CKTRAP MOVE.
4659 020274 004767 173666                JSR    PC,CKTRAP        ;MOVE AND CHECK FOR TRAP.
4660 020300 016767 161772 157476      MOV    TP4VEC,4         ;RESTORE THE NORMAL 004 TRAP VECTOR.
4661 020306 103403                BCS   6#                ;IF NO TRAP, LTC IS THERE SO CONTINUE.
4662 020310 005067 161776                CLR    CLKHRZ           ;CLEAR LTC FREQUENCY WORD TO INDICATE NO LTC.
4663 020314 000402                BR     8#                ;BYPASS THE FOLLOWING CALIBRATION PROCEDURES.
4664
4665 ;+
4666 ; CALIBRATE THE DELAY ROUTINE MILLI-SECOND DELAY COUNT VALUE.
4667 020316 004767 173230 6# :   JSR    PC,CALMSL
4668
4669 ;+
4670 ; CHECK FOR MEMORY MANAGEMENT PRESENT ON THIS MACHINE.
4671 ; IF MEM MGT IS PRESENT, DISABLE IT.
4672 020322 016767 157456 161746 8# :   MOV    4,TP4VEC         ;SAVE THE EXISTING 004 TRAP VECTOR.
4673 020330 012767 017712 157446      MOV    #TP4RTN,4        ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4674 020336 005067 161736                CLR    TP4FLG           ;CLEAR THE 004 TRAP FLAG.
4675 020342 005067 161734                CLR    WORD1            ;PREPARE TO CLEAR THE MEM MGT SRO REGISTER.
4676 020346 012700 002302                MOV    #WORD1,RO        ;SELECT CLEARED WORD AS CKTRAP RTN SOURCE.
4677 020352 016701 161752                MOV    MMSRO,R1         ;SELECT MEM MGT SRO REGISTER AS DESTINATION.
4678 020356 005067 161750                CLR    MMPRES           ;INDICATE NO MEM MGT PRESENT IN CASE IT ISN'T.
4679 020362 005067 161746                CLR    MMENAB           ;INDICATE MEM MGT IS NOT ENABLED.
4680 020366 004767 173574                JSR    PC,CKTRAP        ;CLEAR THE MEM MGT SRO REG AND CHECK FOR TRAP.
4681 020372 016767 161700 157404      MOV    TP4VEC,4         ;RESTORE THE NORMAL 004 TRAP VECTOR.
4682 020400 103003                BCC   10#              ;SKIP INDICATING MEM MGT PRESENT IF IT ISN'T.
4683 020402 012767 000001 161722      MOV    #1,MMPRES        ;INDICATE THAT MEM MGT IS PRESENT.
4684 020410 005067 161650 10# :   CLR    PASCNT          ;CLR COUNTER USED IN REPORTING ROM VERSION #.
4685 020414 000167 000006                JMP    NEWPAS           ;SKIP AROUND THE BUS RESET, IT'S BEEN DONE.

```

L10

```

4686
4687 020420          NEWRES: BRESET          ;RESET THE BUS TO PREVENT ILLEGAL INTERRUPTS.
      020420 104433          ;TRAP C$RESET
4688 020422 005067 161636          CLR PASCNT          ;CLR COUNTER USED IN REPORTING ROM VERSION #.
4689 020426          NEWPAS:
4690 020426 012767 177777 161570  MOV # -1,UNITN      ;RESET LOGICAL DEVICE TO -1
4691          ;*
4692          ; INCREMENT THE PASS COUNTER, CORRECT FOR ANY OVERFLOW.
4693          ; THIS COUNTER IS USED IN THE ROM VERSION TEST.
4694          ;-
4695 020434 005267 161624          INC PASCNT          ;INCREMENT THE PASS COUNTER.
4696 020440 001002          BNE GETPRM          ;BRANCH IF WE HAVE NOT YET! OVERFLOWED.
4697 020442 005367 161616          DEC PASCNT          ;SET PASS COUNT TO 177777 OCTAL.
4698
4699          ; GET THE HARDWARE PARAMETERS FOR THIS UNIT.
4700 020446          GETPRM:
4701 020446 005267 161552          INC UNITN          ;INCREMENT LOGICAL DEVICE NUMBER
4702 020452 026767 161546 161332  CMP UNITN,L$UNIT  ;SEE IF MAXIMUM UNIT NO. EXCEEDED
4703 020460 002362          BGE NEWPAS          ;BR IF YES
4704
4705 020462          GPHARD UNITN,R1          ;GET P-TABLE POINTER INTO R1
      020462 016700 161536          MOV UNITN,R0
      020466 104442          TRAP C$GPHRD
      020470 010001          MOV RO,R1
4706 020472          BCOMPLETE 30$          ;BR IF DEVICE AVAILABLE
      020472 103401          BCS 30$
4707 020474 000764          BR GETPRM          ;SKIP THIS DEVICE
4708
4709
4710          ;***** HARDWARE PARAMETER MOVING CODE *****
4711 020476 012167 161524 30$:  MOV (R1)+,CSRA      ;STORE DMU-11 CSR ADDRESS IN DEV.REG.ADDRESS TABLE
4712 020502 012102          MOV (R1)+,R2          ;GET THE RX INTERRUPT VECTOR ADDRESS.
4713 020504 010267 161504          MOV R2,RXVECA      ;STORE RX INT VECTOR ADDRESS.
4714 020510 062702 000004          ADD #4,R2          ;CALCULATE TX INTERRUPT VECTOR ADDRESS.
4715 020514 010267 161476          MOV R2,TXVECA      ;STORE TX INT VECTOR ADDRESS.
4716 020520 012167 161474          MOV (R1)+,ACTLNS   ;STORE DMU-11 ACTIVE LINE BIT MAP
4717 020524 111167 161472          MOV# (R1),LOP&CK   ;STORE DMU-11 LOOPBACK MODE
4718          ;*
4719          ; CALCULATE DEVICE REGISTER ADDRESSES,AND PUT THEM IN THE
4720          ; DEVICE REGISTER ADDRESS TABLE.
4721          ;-
4722 020530 016701 161472          MOV CSRA,R1          ;COPY CSR ADDRESS
4723 020534 005201          INC R1              ;INCREMENT CSR ADDRESS
4724 020536 005201          INC R1              ; COPY BY 2.
4725 020540 012703 000007          MOV #7,R3          ;SET UP REGISTER COUNT
4726 020544 012702 002230          MOV @RBUFA,R2      ;GET LOCATION WHERE RBUF ADDRESS GOES IN TABLE
4727 020550 010122          12$:  MOV R1,(R2)+          ;STORE REGISTER ADDRESS IN TABLE
4728 020552 005201          INC R1              ;INCREMENT REGISTER ADDRESS
4729 020554 005201          INC R1              ; BY 2,FOR THE NEXT DEVICE REGISTER.
4730 020556 005303          DEC R3              ;DECREMENT REGISTER COUNT
4731 020560 001373          BNE 12$            ;LOOP IF NOT DONE
4732
4733          ;*
4734          ; INITIALISE THE BMP CODE QUEUE.
4735          ;-
4736 020562 012700 002412          MOV @BMPQCB,R0      ;GET THE START ADDRESS OF THE QUEUE.
4737 020566 012701 002612          MOV @BMPQCE,R1      ;GET THE END ADDRESS OF THE QUEUE.
    
```



```

4738 020572 010067 161612      MOV    R0,BMPCQP      ;SET THE POINTER TO THE START OF THE QUEUE.
4739 020576 005020      CLR    (R0)+          ;CLEAR OUT THE CONTENTS OF THE QUEUE.
4740 020600 020001      CMP    R0,R1          ;CHECK IF END OF QUEUE HAS BEEN REACHED.
4741 020602 103775      BLO   14$            ;LOOP IF NOT ALL DONE.
4742                               ;*
4743                               ; REPORT THE UNIT NUMBER IF THE SOFTWARE P-TABLE QUESTION WAS ANSWERED YES.
4744                               ; AND THE MAXIMUM UNIT NUMBER IS GREATER THAN 1.
4745                               ;-
4746 020604 032767 000020 161376      BIT    #BIT4,OPTION   ;CHECK IF THE QUESTION WAS ANSWERED YES.
4747 020612 001416      BEQ   16$            ;SKIP REPORTING UNIT NUMBER IF IT IS DISABLED.
4748 020614 026727 161172 000001      CMP    L$UNIT,#1     ;CHECK MAXIMUM NUMBER OF UNITS SELECTED.
4749 020622 003412      BLE   16$            ;DO NOT REPORT UNIT NUMBER IF MAX NUMBER < 1.
4750 020624      PRINTF #MFUNIT,UNITN ;REPORT UNIT NUMBER.
      020624 016746 161374      MOV    UNITN,(SP)
      020630 012746 005231      MOV    #MFUNIT,-(SP)
      020634 012746 000002      MOV    #2,-(SP)
      020540 010600      MOV    SP,R0
      020642 104417      TRAP  C$PNTF
      020644 062706 000006      ADD   #6,SP
4751 020650      16$:
4752
4753 020650 005067 161374      ENDIT: CLR    CTRLCF      ;CLR THE CTRL-C TEST ABORT FLAG.
4754                               ;*
4755                               ; SET THE PROCESSOR PRIORITY TO DISABLE ALL INTERRUPTS.
4756                               ;-
4757 020654      SETPRI #PRI07          ;SET PROCESSOR PRIORITY TO 7.
      020654 012700 000340      MOV    #PRI07,R0
      020660 104441      TRAP  C$SPRI
4758 020662      ENDINIT
      020662      L10021:
      020662 104411      TRAP  C$INIT
4759
4760      TNUM == 0          ;INITIALIZE THE ASSEMBLER TEST NUMBER VARIABLE.
    
```

4769
4770
4771
4772
4773
4774
4775
4776
4777
4778
4779
4780

.SBTTL AUTODROP SECTION

;++
; THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
; THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO
; SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
; DROPPED FROM TESTING.
;--

4781 020664
020664

BGNAUTO

L\$AUTO::

4782
4789

4790 020664
020664
020664 104461

ENDAUTO

L10022: TRAP C\$AUTO

4799
 4800
 4801
 4802
 4803
 4804
 4805
 4806
 4807
 4808 020666
 020666
 4809
 4810 020666 005767 161356
 4811 020672 001401
 4812 020674
 020674 104433
 4813 020676
 4814
 4823
 4824 020676
 020676 104432
 020700 000002
 4825
 4837
 4838
 4839
 4840 020702
 020702
 020702 104412

.SBTTL CLEANUP CODING SECTION

 ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
 ; AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
 ;**

BGNCLN

L1CLEAN::

TST CTRLCF
 BEQ 2#
 BRESET

;DID WE GET HERE BY CTRL C FROM TEST?
 ;CTRL C FROM TEST? NO, SKIP BUS RESET.
 ;YES, CLR ANY DMAS OR OUTSTANDING INTERRUPTS.
 TRAP C1RESET

2#:

EXIT CLN

TRAP C1EXIT
 .WORD L10023 .

.EVEN

ENDCLN

L10023: TRAP C1CLEAN

4849
4850
4851
4852
4853
4854
4855
4856
4857
4858
4859
4860
4861
4862
4863
4864
4865
4866
4867
4868
4869
4870

020704
020704
020704 010046
020706 012746 020730
020712 012746 000002
020716 010600
020720 104417
020722 062706 000006
020726 000427

045 101 040
125 116 111
124 045 104
066 045 101
040 104 122
117 120 120
105 104 040
106 122 117
115 040 106
125 122 124
110 105 122
040 124 105
123 124 111
116 107 056
045 116 000

021006
021006 000167
021010 000000

021012
021012
021012 104453

.SBTTL DROP UNIT SECTION

; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
; TO NO LONGER BE TESTED.
;-

BGNDU

L#DU::

PRINTF #DROP,RO ;REPORT UNIT THAT HAS BEEN DROPPED.

MOV RO,-(SP)
MOV #DROP,-(SP)
MOV #2,-(SP)
MOV SP,RO
TRAP C#PRINTF
ADD #6,SP

BR EDROP ;BRANCH AROUND THE MESSAGE.

DROP: .ASCIZ/##A UNIT#D6##A DROPPED FROM FURTHER TESTING.##N/

EDROP: .EVEN

EXIT DU

.WORD J#JMP
.WORD L10024 2 .

ENDDU

L10024:
TRAP C#DL

4879
4880
4881
4882
4883
4884
4885
4886
4887
4888
4889
4890
4891
4892
4893
4894
4895
4896
4897

021014
021014
021014 000167
021016 000000

021020
021020
021020 104452

.SBTTL ADD UNIT SECTION

; THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
; TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
; TO THE TEST CYCLE.

BGNAU

L\$AU::

EXIT AU

.WORD JSJMP
.WORD L10025-2..

.EVEN

ENDAU

L10025:

TRAP C\$AU

```

4899 .SBTTL HARDWARE TEST - ADRA -
4900 ;**
4901 ;*****
4902 ; - REGISTER ADDRESS TEST -
4903 ;*
4904 ;* THIS TEST VERIFIES THAT THE DEVICE REGISTERS WILL RESPOND TO THE PROPER
4905 ;* UNIBUS HANDSHAKING SIGNALS WHEN ACCESSED. IF THE DMU11 DOES NOT RESPOND
4906 ;* TO THE ACCESS ATTEMPTS (IF THE DMU11 IS AT THE WRONG ADDRESS, FOR EXAMPLE)
4907 ;* THE 004 BUS TIME-OUT TRAP IS DETECTED BY THIS ROUTINE AND AN ERROR
4908 ;* IS REPORTED. THIS TEST IS PERFORMED ON LINE 0 ONLY.
4909 ;*
4910 ;*****
4911 ;
4912 ;
4913 021022 BGNTST
021022
4914 000001 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
4915 021022 012767 000001 161224 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (1)
4916 021030 012767 177777 161212 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
4917 021036 012767 000145 163006 MOV #101,ERRNBR ;SET THE TEST ERROR NUMBER IN THE TABLE.
4918 021044 012767 005262 163002 MOV #EM0103,ERRMSG ;SET UP THE TEST FAILURE MESSAGE IN THE TABLE.
4919 021052 012767 011430 162776 MOV #ER0101,ERRBLK ;SET-UP THE ERROR ROUTINE IN THE ERROR TABLE.
4920 ;*
4921 ; SET UP TO CATCH ANY 004 TRAPS WHICH OCCUR:
4922 ; -
4923 021060 016767 156720 161210 MOV 4,TP4VEC ;SAVE THE EXISTING 004 TRAP VECTOR.
4924 021066 012767 017712 156710 MOV #TP4RTN,4 ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4925 021074 005005 CLR R5 ;CLEAR THE ERROR FLAGS.
4926
4927 ;*
4928 ; HERE BEGINS THE LOOP TO TEST THE REGISTERS FOR A LINE.
4929 ; FIRST TEST THE CSR AND SET THE IND.ADR.REG (I.A.R) FIELD.
4930 ; -
4931 021076 016700 161124 MOV CSRA,R0 ;SET UP CSR AS THE CKTRAP MOVE SOURCE.
4932 021102 012701 021274 MOV #52,R1 ;SET UP DESTINATION LOCATION FOR CKTRAP MOVE.
4933 021106 004767 173054 JSR PC,CKTRAP ;MOVE AND CHECK FOR TRAP.
4934 021112 103402 BCS 4 ;IF NO TRAP, BYPASS ERROR.
4935 021114 052705 100001 BIS #100001,R5 ;SET FATAL READ ERROR FLAGS.
4936 021120 042767 000017 000146 4: BIC #17,52 ;CLEAR THE I.A.R FIELD OF THE CSR DATA.
4937 021126 010100 MOV R1,R0 ;USE OLD DESTINATION FOR SOURCE OF CKTRAP MOVE.
4938 021130 016701 161072 MOV CSRA,R1 ;SET UP CSR AS THE CKTRAP MOVE DESTINATION.
4939 021134 004767 173026 JSR PC,CKTRAP ;MOVE AND CHECK FOR TRAP.
4940 021140 103403 BCS 6 ;IF NO TRAP, BYPASS ERROR.
4941 021142 052705 100002 BIS #100002,R5 ;SET FATAL WRITE ERROR FLAGS.
4942 021146 000434 BR 40 ;EXIT AND REPORT FATAL ERROR.
4943 ;*
4944 ; NOW, WE TEST EACH REGISTER FOR THIS LINE.
4945 ; -
4946 021150 012702 000010 6: MOV #8,R2 ;INIT REGISTER COUNTER TO 8.
4947 021154 016767 161046 000110 MOV CSRA,50 ;INITIALIZE THE REGISTER POINTER.
4948 021162 016700 000104 8: MOV 50,R0 ;SET UP REGISTER AS THE SOURCE FOR CKTRAP MOVE.
4949 021166 012701 021274 MOV #52,R1 ;SET UP LOCAL STORAGE AS THE DES FOR CKTRAP.
4950 021172 004767 172770 JSR PC,CKTRAP ;PERFORM THE MOVE, CHECK FOR TRAP.
4951 021176 103402 BCS 10 ;IF NO TRAP, BYPASS THE SETTING OF ERROR FLAGS.
4952 021200 052705 100001 BIS #100001,R5 ;SET FATAL READ ERROR FLAGS.
4953 021204 010100 10: MOV R1,R0 ;USE OLD DEST AS SRC FOR CKTRAP MOVE.
4954 021206 016701 000060 MOV 50,R1 ;SET UP REGISTER AS THE DEST FOR CKTRAP MOVE.
    
```


G11

```

4990 .SBTTL HARDWARE TEST - DMASTA -
4991 ;* *****
4992 ;* - DMA START BIT TEST -
4993 ;* THIS TEST VERIFIES THAT THE DMA_START BIT IN THE DUT'S LINE CONTROL
4994 ;* REGISTERS WILL INITIATE DMA TRANSMISSION ON THE SELECTED LINE.
4995 ;* THIS TEST IS PERFORMED IN INTERNAL LOOPBACK, ON ALL ACTIVE LINES.
4996 ;*
4997 ;* *****
4998 021304 BGNTST
4999 021304 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS. T2::
021304 012700 000240 MOV #PRI05,RO
021310 104441 TRAP C$SPRI
000002
5000 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5001 021312 012767 000002 160734 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (40)
5002 021320 012767 177777 160722 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
5003 021326 012767 000001 162514 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5004 021334 012767 007641 162510 MOV #4001,ERRNBR ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
5005 021342 012767 005403 162504 MOV #EM4001,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERRTBL.
5006 021350 012767 013136 162500 MOV #ER9101,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
5007 ;*
5008 ;* RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
5009 ;* CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
5010 ;* THIS SUBROUTINE REPORTS ERROR >>>> 4001 <<<<.
5011 ;*
5012 021356 004767 172634 JSR PC,CLNRST ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
5013 021362 103145 BCC 501 ;RESET FAILURE?, ABORT THIS TEST.
5014
5015 021364 004767 173160 JSR PC,INDATP ;INITIALSE THE 256 BYTE DATA PATTERN.
5016 ;*
5017 ;* SET INTERNAL LOOPBACK,ENABLE RECEIVER FUNCTIONS ON ALL ACTIVE LINES.
5018 ;* SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
5019 ;* 2 STOP BITS.
5020 ;* ENABLE TRANSMITTERS ON ALL ACTIVE LINES.
5021 ;*
5022 021370 016705 160624 MOV ACTLNS,R5 ;PASS THE ACTIVE LINE BIT MAP.
5023 021374 012700 000204 MOV #204,RO ;PASS THE LNCTRL CONTENTS.
5024 021400 004767 176146 JSR PC,WTMLNC ;INITIALISE THE LNCTRL REGISTERS.
5025 021404 012700 177670 MOV #177670,RO ;PASS THE LPR CONTENTS.
5026 021410 004767 176166 JSR PC,WTMLPR ;INITIALSE THE LPR REGISTERS ON ALL LINES.
5027 021414 004767 175502 JSR PC,TXENBL ;ENABLE TRANSMITTERS ON ALL LINES.
5028 ;*
5029 ;* SET-UP OUTER LOOP TO TEST THE DMA_START BIT ON ALL ACTIVE LINES.
5030 ;*
5031 021420 016705 160574 MOV ACTLNS,R5 ;GET THE ACTIVE LINE BIT MAP.
5032 021424 005001 CLR R1 ;CLEAR THE LINE NUMBER COUNTER.
5033 021426 012767 007642 162416 21: MOV #4002,ERRNBR ;SET THE ERROR NUMBER TO 4002.
5034 021434 000241 CLC ;CLEAR THE CARRY BIT PRIOR TO SHIFTING BIT MAP.
5035 021436 006005 ROR R5 ;SHIFT THE BIT MAP INTO THE CARRY BIT.
5036 021440 103112 BCC 141 ;DO NOT TEST THE LINE IF IT IS INACTIVE.
5037 021442 004767 173722 JSR PC,PUFIFO ;PURGE THE FIFO.
5038 021446 103113 BCC 501 ;GO REPORT ERROR IF FIFO WILL NOT CLEAR.
5039 ;*
5040 ;* PERFORM DMA_START BIT TESTING ON EACH LINE INDIVIDUALLY.
5041 ;* TEST EACH DMA_START BIT BEFORE TX'ING DATA PATTERN, REPORT ERROR IF SET.
5042 ;* SET DMA_START BIT ON LUT, VERIFY IT IS SET, REPORT ERROR IF CLEAR.
5043 ;* WAIT FOR DMA TO COMPLETE.
    
```



```

5044      ; VERIFY DMA_START BIT IS CLEAR, REPORT ERROR IF SET.
5045      ; VERIFY CORRECT NUMBFR OF CHARS WERE RECEIVED, REPORT ERROR IF < EXPECTED.
5046      ;
5047 021450 005267 162376      INC      ERRNBR      ;SET ERROR NUMBER TO 4003.
5048 021454 012702 002650      MOV      #BUFBAS,R2  ;PASS THE START OF THE DATA PATTERN TO TX.
5049 021460 012703 000144      MOV      #100.,R3    ;PASS THE LENGTH OF THE DATA PATTERN.
5050 021464 004767 172710      JSR      PC,DODMA    ;TRANSMIT THE DATA PATTERN.
5051 021470 103067              BCC      12#         ;GO REPORT ERROR IF DMA_START BIT SET.
5052      ;
5053      ; TEST THE STATE OF THE DMA_START BIT ON THE LINE UNDER TEST.
5054      ; REPORT ERROR IF DMA_START BIT IS CLEAR.
5055      ;
5056 021472 005267 162354      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4004.
5057 021476 010177 160524      MOV      R1,BCSRA   ;SELECT THE LINE CURRENTLY UNDER TEST.
5058 021502 105777 160534      TSTB    BTXAD2A     ;TEST THE STATE OF THE DMA_START BIT.
5059 021506 100060              BPL      12#         ;GO REPORT ERROR IF BIT IS CLEAR.
5060      ;
5061      ; WAIT FOR DMA TRANSMISSION TO COMPLETE.
5062      ;
5063 021510 005267 162336      4# : INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4005.
5064 021514 010103              MOV      R1,R3       ;SAVE THE LINE NUMBER.
5065 021516 012701 170226      MOV      #170226,R1 ;TEST BIT 15, TIMEOUT OF 150 MILLI SECS.
5066 021522 016702 160500      MOV      CSRA,R2    ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5067 021526 004767 175704      JSR      PC,WAIBIS  ;WAIT FOR DMA TO COMPLETE.
5068 021532 103045              BCC      10#         ;GO REPORT ERROR IF TIMEOUT OCCURRED.
5069 021534 012704 000005      MOV      #5,R4      ;PASS DELAY OF 5 MILLI SECS.
5070 021540 004767 172516      JSR      PC,DELAY   ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
5071 021544 010301              MOV      R3,R1       ;RESTORE THE CURRENT LINE NUMBER.
5072      ;
5073      ; TEST THE STATE OF THE DMA_START BIT ON THE LINE UNDER TEST.
5074      ; REPORT ERROR IF DMA_START BIT IS SET.
5075      ;
5076 021546 005267 162300      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4006.
5077 021552 010177 160450      MOV      R1,BCSRA   ;SELECT THE LINE CURRENTLY UNDER TEST.
5078 021556 105777 160460      TSTB    BTXAD2A     ;TEST THE STATE OF THE DMA_START BIT.
5079 021562 100432              BMI      12#         ;GO REPORT ERROR IF BIT IS STILL SET.
5080      ;
5081      ; VERIFY THE NUMBER OF CHARS RECEIVED = NUMBER OF CHARS EXPECTED.
5082      ; REPORT ERROR IF COUNT IS INCORRECT.
5083      ; IF MORE THAN 128 BMP CODES ARE FOUND THEN REPORT ERROR AND EXIT TEST.
5084      ;
5085 021564 005003              CLR      R3          ;CLEAR THE READ COUNTER.
5086 021566 012704 000200      MOV      #128.,R4   ;SET UP MAX BMP CODE READ COUNT.
5087 021572 012767 007647 162252 6# : MOV      #4007.,ERRNBR ;SET ERROR NUMBER TO 4007.
5088 021600 017702 160424      MOV      #RBUFA,R2  ;READ THE CHARACTER FROM THE FIFO.
5089 021604 100021              BPL      12#         ;GO REPORT ERROR IF FIFO EMPTY TOO SOON.
5090 021606 012700 170301      MOV      #170301,R0 ;SET-UP BIT MASK OF A BMP CODE.
5091 021612 040200              BIC      R2,R0      ;TRY TO CLEAR THE BMP CODE MASK.
5092 021614 001007              BNE      8#         ;BRANCH IF NOT A BMP CODE.
5093 021616 005267 162230      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4008.
5094 021622 004767 174652      JSR      PC,SAVBMP  ;SAVE THE BMP CODE ON THE QUEUE.
5095 021626 005304              DEC      R4          ;DECREMENT MAX BMP CODE READ COUNT.
5096 021630 001422              BEQ      50#        ;GO REPORT ERROR IF TOO MANY BMP CODES FOUND.
5097 021632 000757              BR       6#         ;DO NOT COUNT THE BMP CODE AS A VALID CHAR.
5098 021634 005203 8# :      INC      R3          ;COUNT THIS CHARACTER.
5099 021636 020327 000144      CMP      R3,#100.   ;HAVE WE RECIEVED 100 CHARACTERS?.
5100 021642 002753              BLT      6#         ;LOOP UNTIL 100 (NON-BMP) CHARS ARE READ.
    
```

```

5101 021644 000410          BR      14$          ;SKIP AROUND THE ERROR REPORT.
5102
5103
5104
5105          ;*
          ; REPORT ERROR, SKIP FURTHER TESTING ON THIS LINE.
5106 021646 010301          10$:   MOV      R3,R1          ;RESTORE THE CURRENT LINE NUMBER.
5107
5108 021650 012702 005435    12$:   MOV      #EM4002,R2        ;PASS THE ERROR MESSAGE TO BE REPORTED.
5109
5110 021654          ERROR          ;
          ; >>>> ERROR <<<<<.
          ; TRAP      C#ERROR
5111
5112          ;*
5113          ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5114          ;
5115 021656 032767 000100 160324  BIT      #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5116 021664 001406          BEQ      60$          ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5117
5118 021666 005201          14$:   INC      R1          ;INCREMENT THE LINE NUMBER COUNTER.
5119 021670 005705          TST      R5          ;ARE THERE ANY MORE ACTIVE LINES TO TEST?.
5120 021672 001255          BNE      2$          ;YES; BRANCH TO TEST THE NEXT LINE.
5121 021674 000402          BR      60$          ;NO; EXIT THIS TEST.
5122
5123 021676 004767 174770    50$:   JSR      PC,TSABRT        ;REPORT TEST ABORTED. NON-TEST RELATED ERROR.
5124 021702 005067 160342    60$:   CLR      CTRLCF        ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5125
5126 021706          ENDTST
          ;
          ; L10027:
          ; TRAP      C#ETST
021706 104401
    
```

```

5128 .SBTTL HARDWARE TEST - DMABRT -
5129 ;* *****
5130 ;* - DMA ABORT/RESTART TEST -
5131 ;* THIS TEST VERIFIES THAT EACH DMA_ABORT BIT WILL CORRECTLY HALT
5132 ;* A DMA TRANSMISSION, AND RETURN A TX_ACTION.
5133 ;* IT WILL ALSO VERIFY THAT THE ABORTED DMA TRANSMISSION CAN BE RESUMMED,
5134 ;* AND THAT A TX_ACTION IS RETURNED UPON COMPLETION.
5135 ;* THIS TEST IS PERFORMED IN INTERNAL LOOPBACK, ON ALL ACTIVE LINES.
5136 ;*
5137 ;-- *****
5138 BGNTST
5139 021710 T3::
021710 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS.
021710 012700 000240 MOV #PRI05,R0
021714 104441 TRAP C#SPRI
5140 000003 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5141 021716 012767 000003 160330 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (41)
5142 021724 012767 177777 160316 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
5143 021732 012767 000001 162110 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5144 021740 012767 010005 162104 MOV #4101,ERRNBR ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
5145 021746 012767 005471 162100 MOV #EM4101,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERRTBL.
5146 021754 012767 013136 162074 MOV #ER9101,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
5147 ;*
5148 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
5149 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
5150 ; THIS SUBROUTINE REPORTS ERROR >>>> 4101 <<<<<.
5151 ;--
5152 021762 004767 172230 JSR PC,CLNRST ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
5153 021766 103164 BCC 60# ;RESET FAILURE?, ABORT THIS TEST.
5154 ;--
5155 021770 004767 172554 JSR PC,INDATP ;INITIALISE 256 BYTE DATA PATTERN.
5156 ;*
5157 ; SET INTERNAL LOOPBACK,ENABLE RECEIVER FUNCTIONS ON ALL ACTIVE LINES.
5158 ; SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY.
5159 ; 2 STOP BITS.
5160 ; ENABLE TRANSMITTERS ON ALL ACTIVE LINES.
5161 ;--
5162 021774 016705 160220 MOV ACTLNS,R5 ;PASS THE ACTIVE LINE BIT MAP.
5163 022000 012700 000204 MOV #204,R0 ;PASS THE LNCTRL CONTENTS.
5164 022004 004767 175542 JSR PC,WTMLNC ;INITIALISE THE LNCTRL REGISTERS.
5165 022010 012700 177670 MOV #177670,R0 ;PASS THE LPR CONTENTS.
5166 022014 004767 175562 JSR PC,WTMLPR ;INITIALISE THE LPR REGISTERS ON ALL LINES.
5167 022020 004767 175076 JSR PC,TXENBL ;ENABLE TRANSMITTERS ON ALL LINES.
5168 ;*
5169 ; PERFORM DMA_ABORT BIT TESTING ON EACH INDIVIDUAL (ACTIVE) LINE.
5170 ;--
5171 022024 016705 160170 MOV ACTLNS,R5 ;GET THE ACTIVE LINE BIT MAP.
5172 022030 005001 CLR R1 ;CLEAR THE LINE NUMBER COUNTER.
5173 022032 012767 010006 162012 2# MOV #4102,ERRNBR ;SET THE ERROR NUMBER TO 4102.
5174 022040 000241 CLC ;CLEAR THE CARRY BIT PRIOR TO SHIFTING BIT MAP.
5175 022042 006005 ROR R5 ;SHIFT THE BIT MAP INTO THE CARRY BIT.
5176 022044 103127 BCC 10# ;DO NOT TEST THE LINE IF IT IS INACTIVE.
5177 022046 004767 173316 JSR PC,PUFIFO ;PURGE THE FIFO.
5178 022052 103130 BCC 50# ;GO REPORT ERROR IF FIFO WILL NOT CLEAR.
5179 ;*
5180 ; CHECK THE DMA_ABORT BIT BEFORE ENABLING DMA, REPORT ERROR IF SET.
5181 ;--

```

```

5182 022054 005267 161772      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4103.
5183 022060 010177 160142      MOV      R1,@CSRA   ;SELECT THE LINE CURRENTLY UNDER TEST.
5184 022064 032777 000001 160144  BIT      @BIT0,@LNCTRA ;TEST THE STATE OF THE DMA_ABORT BIT.
5185 022072 001105                BNE      6$         ;GO REPORT ERROR IF BIT IS SET.
5186                                ;+
5187                                ; ENABLE DMA TX ON SELECTED LINE. WAIT FOR DMA TO TX APPROX 1/4 OF DATA.
5188                                ; ABORT THE DMA TRANSMISSION. WAIT FOR TX_ACTION TO BE RETURNED.
5189                                ;-
5190 022074 005267 161752      INC      ERRNBR      ;SET ERROR NUMBER TO 4104.
5191 022100 012702 002650      MOV      @BUFBA,R2  ;PASS THE START OF THE DATA PATTERN TO TX.
5192 022104 012703 000400      MOV      @256.,R3   ;PASS THE LENGTH OF THE DATA PATTERN.
5193 022110 004767 172264      JSR      PC,DODMA   ;TRANSMIT THE DATA PATTERN.
5194 022114 103107                BCC      50$         ;GO REPORT ERROR IF THERE ARE TX PROBLEMS.
5195                                ;+
5196                                ; WAIT FOR DMA TO TRANSMIT 1/4 OF THE DATA BEFORE ABORTING.
5197                                ;-
5198 022116 010177 160104      MOV      R1,@CSRA   ;SELECT THE LINE CURRENTLY UNDER TEST.
5199 022122 012704 000050      MOV      @40.,R4    ;PASS THE DELAY TIME OF 40 MILLI SECONDS.
5200 022126 004767 172130      JSR      PC,DELAY   ;WAIT FOR APPROX 1/4 OF DATA TO BE TX'D.
5201 022132 052777 000001 160076  BIS      @BIT0,@LNCTRA ;ABORT THE DMA TRANSMISSION.
5202                                ;+
5203                                ; WAIT FOR TX_ACTION TO BE RETURNED. REPORT ERROR IF TIME-OUT OCCURS.
5204                                ;-
5205 022140 005267 161706      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4105.
5206 022144 010103                MOV      R1,R3       ;SAVE THE LINE NUMBER.
5207 022146 012701 170012                MOV      @170012,R1  ;TEST BIT 15. TIMEOUT OF 10 MILLI SECS.
5208 022152 016702 160050                MOV      CSRA,R2     ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5209 022156 004767 175254                JSR      PC,WAIBIS   ;WAIT FOR DMA TO COMPLETE.
5210 022162 103050                BCC      4$         ;GO REPORT ERROR IF TIMEOUT OCCURRED.
5211 022164 010301                MOV      R3,R1       ;RESTORE THE CURRENT LINE NUMBER.
5212                                ;+
5213                                ; VERIFY DMA_START BIT CLEAR. REPORT ERROR IF SET.
5214                                ;-
5215 022166 005267 161660      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4106.
5216 022172 012702 005557                MOV      @EM103,R2   ;SELECT MESSAGE TO BE REPORTED.
5217                                ; "DMA_START BIT FOUND SET AFTER DMA ABORTED".
5218 022176 010177 160024      MOV      R1,@CSRA   ;SELECT THE LINE CURRENTLY UNDER TEST.
5219 022202 105777 160034      TSTB    @TXAD2A     ;TEST THE STATE OF THE DMA_START BIT.
5220 022206 100441                BMI      8$         ;GO REPORT ERROR IF IT IS SET.
5221                                ;+
5222                                ; RESUME DMA TRANSMISSION BY CLEARING DMA_ABORT AND SETTING DMA_START.
5223                                ;-
5224 022210 042777 000001 160020  BIC      @BIT0,@LNCTRA ;CLEAR THE DMA_ABORT BIT.
5225 022216 052777 000200 160016  BIS      @BIT7,@TXAD2A ;SET THE DMA_START BIT.
5226                                ;+
5227                                ; WAIT FOR DMA TRANSMISSION TO COMPLETE.
5228                                ;-
5229 022224 005267 161622      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4107.
5230 022230 010103                MOV      R1,R3       ;SAVE THE LINE NUMBER.
5231 022232 012701 170536                MOV      @170536,R1  ;TEST BIT 15. TIMEOUT OF 350 MILLI SECS.
5232 022236 016702 157764                MOV      CSRA,R2     ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5233 022242 004767 175170                JSR      PC,WAIBIS   ;WAIT FOR DMA TO COMPLETE.
5234 022246 103016                BCC      4$         ;GO REPORT ERROR IF TIMEOUT OCCURRED.
5235 022250 012704 000002                MOV      @2.,R4      ;PASS TIME-OUT OF 2 MILLI SECS.
5236 022254 004767 172002                JSR      PC,DELAY   ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
5237 022260 010301                MOV      R3,R1       ;RESTORE THE CURRENT LINE NUMBER.
5238                                ;+

```

111

```

5239 ; TEST THE STATE OF THE DMA_ABORT BIT ON THE LINE UNDER TEST.
5240 ; REPORT ERROR IF DMA_ABORT BIT IS SET.
5241 ;-
5242 022262 005267 161564 INC ERRNBR ;INCREMENT ERROR NUMBER TO 4108.
5243 022266 010177 157734 MOV R1,DCSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
5244 022272 032777 000001 157736 BIT #BIT0,BLNCTRA ;TEST THE STATE OF THE DMA_ABORT BIT.
5245 022300 001002 BNE 6$ ;GO REPORT ERROR IF BIT IS SET.
5246 022302 000410 BR 10$ ;BRANCH TO CHECK FOR ANY MORE LINES TO TEST.
5247 ;+
5248 ; REPORT ERROR, SKIP FURTHER TESTING ON THIS LINE.
5249 ;-
5250 022304 010301 4$: MOV R3,R1 ;RESTORE THE CURRENT LINE NUMBER.
5251
5252 022306 012702 005523 6$: MOV #EM4102,R2 ;PASS THE ERROR MESSAGE TO BE REPORTED.
5253 ; "DMA_ABORT BIT BAD ON LINE NN".
5254 022312 104460 8$: ERROR ; >>>> ERROR <<<<<.
; TRAP C$ERROR
5255
5256 ;+
5257 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5258 ;-
5259 022314 032767 000100 157666 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5260 022322 001406 BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
; DURING THE SOFTWARE QUESTIONS.
5261
5262 ;+
5263 ; VERIFY ALL ACTIVE LINES HAVE BEEN TESTED.
5264 ;-
5265 022324 005201 10$: INC R1 ;INCREMENT THE LINE NUMBER COUNTER.
5266 022326 005705 TST R5 ;ARE THERE ANY MORE ACTIVE LINES TO TEST?.
5267 022330 001240 BNE 2$ ;YES; BRANCH TO TEST THE NEXT LINE.
5268 022332 000402 RR 60$ ;NO; EXIT THIS TEST.
5269
5270 022334 004767 174332 50$: JSR PC,TSABRT ;REPORT TEST ABORTED. NON-TEST RELATED ERROR.
5271 022340 005067 157704 60$: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5272
5273 022344 ENDTST
; L10030: TRAP C$ETST
022344 104401

```

M11

5275
 5276
 5277
 5278
 5279
 5280
 5281
 5282
 5283
 5284
 5285
 5286
 5287
 5288 022346
 022346
 5289
 5290 022346
 022346 012700 000240
 022352 104441
 5291
 5292 000004
 5293 022354 012767 000004 157672
 5294 022362 012767 177777 157660
 5295 022370 012767 000001 161452
 5296 022376 012767 010151 161446
 5297 022404 012767 005643 161442
 5298 022412 012767 011762 161436
 5299
 5300
 5301
 5302
 5303
 5304 022420 004767 171572
 5305 022424 103120
 5306
 5307
 5308
 5309
 5310
 5311
 5312 022426 004767 172036
 5313 022432 103115
 5314 022434 010104
 5315 022436 012700 000204
 5316 022442 004767 175104
 5317 022446 012700 177670
 5318 022452 004767 175124
 5319 022456 004767 174440
 5320
 5321
 5322
 5323 022462 005267 161364
 5324 022466 032777 000200 157546
 5325 022474 001072
 5326
 5327
 5328

```
.SBTTL HARDWARE TEST - DMAERR -
;+ *****
;+ - DMA ERROR BIT TEST -
;+ THIS TEST VERIFIES THAT THE TX.DMA.ERROR BIT IN THE CSR IS
;+ FUNCTIONING CORRECTLY. THE DMA ERROR IS FORCED BY MAKING THE DUT
;+ ATTEMPT TO PERFORM A DMA TRANSFER FROM THE ADDRESS OF ITS OWN CSR.
;+ SINCE THE DEVICE CANNOT BE BOTH A BUS MASTER AND SLAVE AT THE SAME
;+ TIME, TIMEOUT WILL OCCUR WAITING FOR THE APPROPRIATE HANDSHAKE SIGNAL
;+ FROM THE DMA ADDRESS.
;+ THIS TEST IS PERFORMED IN INTERNAL LOOPBACK.
;+
;-- *****

BGNTST

T4::

SETPRI #PRI05 ;ALLOW LTC INTERRUPTS.

MOV #PRI05,R0
TRAP C$SPRI

TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (42)
MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV #4201,ERRNBR ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
MOV #EM4201,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERRTABL.
MOV #ER0503,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.

;+
;+ RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE rIFO.
;+ CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
;+ THIS SUBROUTINE REPORTS ERROR >>>> 4201 <<<<<.
;+
;+ JSR PC,CLNRST ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
;+ BCC 60$ ;RESET FAILURE?, ABORT THIS TEST.

;+
;+ SET INTERNAL LOOPBACK,ENABLE RECEIVER FUNCTIONS ON ALL LINES.
;+ SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY.
;+ 2 STOP BITS.
;+ ENABLE TRANSMITTERS ON ALL LINES.
;+
;+ JSR PC,FINACT ;FIND AN ACTIVE LINE.
;+ BCC 60$ ;EXIT THE TEST IF NO ACTIVE LINES.
;+ MOV R1,R4 ;SAVE THE LINE NUMBER.
;+ MOV #204,R0 ;PASS THE LNCTRL CONTENTS.
;+ JSR PC,WTWLNLC ;INITIALISE THE LNCTRL REGISTERS.
;+ MOV #177670,R0 ;PASS THE LPR CONTENTS.
;+ JSR PC,WTWLPRL ;INITIALISE THE LPR REGISTERS ON THE ACTIVE LINE.
;+ JSR PC,TXENBL ;ENABLE TRANSMITTERS ON THE ACTIVE LINE.

;+
;+ VERIFY THAT THE DMA.START BIT IS CLEAR BEFORE ATTEMPTING THE DMA TRANSFER.
;+
;+ INC ERRNBR ;SET THE ERROR NUMBER TO 4202.
;+ BIT #BIT07,$TXAD2A ;TEST THE DMA START BIT.
;+ BNE 50$ ;BRANCH TO REPORT THE ERROR IF THE BIT IS SET.

;+
;+ SET UP THE DMA REGISTERS TO PERFORM THE TRANSFER FROM THE ADDRESS OF THE CSR.
;+
;
```

```

5329 022476 016777 157524 157534      MOV    CSRA,@TXAD1A      ;SET UP THE LOW 16 BITS OF THE DMA ADDR.
5330 022504 012777 000001 157532      MOV    #1,@TXBFCA      ;SET UP TO DMA ONE CHARACTER.
5331 022512 112777 000203 157522      MOVB   #203,@TXAD2A    ;SET UP THE 2 MSB'S AND INITIATE THE DMA.
5332 022520 012701 170012          MOV    #170012,R1      ;TEST BIT 15, TIME OUT OF 10 MS.
5333 022524 016702 157476          MOV    CSRA,R2         ;INDICATE TO TEST THE CSR.
5334 022530 005267 161316          INC    ERRNBR          ;SET THE ERROR NUMBER TO 4203.
5335 022534 004767 174676          JSR    PC,WAIBIS       ;WAIT FOR A TX-ACTION.
5336 022540 103050          BCC    50$            ;REPORT THE ERROR IF NO TX-ACTION.
5337
5338      ;+
5339      ; VERIFY THAT THE DMA ERROR BIT IS SET AND THE DMA START BIT IS CLEAR.
5340 022542 005267 161304          INC    ERRNBR          ;SET THE ERROR NUMBER TO 4204.
5341 022546 032777 010000 157452      BIT    #BIT12,@CSRA    ;TEST THE DMA-ERROR BIT.
5342 022554 001436          BEQ    2$            ;REPORT THE ERROR IF BIT IS CLEAR.
5343 022556 005267 161270          INC    ERRNBR          ;SET THE ERROR NUMBER TO 4205.
5344 022562 032777 000200 157452      BIT    #BIT07,@TXAD2A  ;TEST THE DMA-START BIT.
5345 022570 001034          BNE    50$            ;REPORT THE ERROR IF THE BIT IS SET.
5346
5347      ;+
5348      ; VERIFY THAT THE DMA ERROR BIT CLEARS WHEN A "GOOD" DMA TRANSFER IS PERFORMED.
5349 022572 010401          MOV    R4,R1          ;SET UP THE ACTIVE LINE NUMBER.
5350 022574 012702 002650          MOV    @BUFBA,R2      ;SET UP THE START ADDRESS OF THE DMA BUFFER.
5351 022600 012703 000001          MOV    #1,R3          ;SET UP TO DMA ONE CHARACTER.
5352 022604 005267 161242          INC    ERRNBR          ;SET THE ERROR NUMBER TO 4206.
5353 022610 004767 171564          JSR    PC,DODMA       ;START THE DMA.
5354 022614 103022          BCC    50$            ;REPORT THE ERROR IF ONE OCCURED.
5355 022616 012701 170036          MOV    #170036,R1     ;SET UP TO TEST BIT15 WITH TIMEOUT OF 30 MS.
5356 022622 016702 157400          MOV    CSRA,R2         ;INDICATE TO TEST THE CSR.
5357 022626 005267 161220          INC    ERRNBR          ;SET THE ERROR NUMBER TO 4207.
5358 022632 004767 174600          JSR    PC,WAIBIS       ;WAIT FOR A TX-ACTION.
5359 022636 103011          BCC    50$            ;REPORT THE ERROR IF NO TX ACTION OCCURED.
5360 022640 005267 161206          INC    ERRNBR          ;SET THE ERROR NUMBER TO 4208.
5361 022644 032702 010000          BIT    #BIT12,R2      ;TEST THE DMA ERROR BIT OF THE LAST CSR WORD READ.
5362 022650 001406          BEQ    60$            ;EXIT THE TEST IF THE BIT IS CLEAR.
5363
5364      ;+
5365      ; REPORT THE ERROR, DMA ERROR BIT BAD.
5366 022652 012701 005675          2$:   MOV    #EM4202,R1  ;SET THE MESSAGE
5367      ERROR                                     ; "DMA ERROR BIT BAD".
5368      TRAP    C$ERROR
5369 022660 000402          BR     60$            ;EXIT THE TEST.
5370
5371 022662 004767 174004          50$:  JSR    PC,TSABRT      ;REPORT THE NON-RELATED TEST ERROR.
5372 022666 005067 157356          60$:  CLR    CTRLCF        ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5373
5374 022672          ENDTST
022672
022672 104401          L10031: TRAP    C$ETST

```

5376
 5377
 5378
 5379
 5380
 5381
 5382
 5383
 5384
 5385
 5386
 5387 022674
 022674
 5388 022674 126727 157322 000002
 5389 022702 001402
 5390 022704 000167 000556
 5391 022710
 022710 012700 000240
 022714 104441
 5392 000005
 5393 022716 012767 000005 157330
 5394 022724 012767 177777 157316
 5395 022732 012767 000001 161110
 5396 022740 012767 011445 161104
 5397 022746 012767 005717 161100
 5398 022754 012767 013136 161074
 5399
 5400
 5401
 5402
 5403
 5404 022762 004767 171230
 5405 022766 103402
 5406 022770 000167 000472
 5407
 5408
 5409
 5410 022774 004767 170442
 5411
 5412
 5413
 5414
 5415
 5416
 5417 023000 016705 157214
 5418 023004 012700 000004
 5419 023010 004767 174536
 5420 023014 012705 177777
 5421 023020 012700 177670
 5422 023024 004767 174552
 5423 023030 004767 174066
 5424
 5425
 5426
 5427 023034 012703 100000
 5428 023040 016705 157154
 5429 023044 046705 157212

```

.SBTTL  HARDWARE TEST          - OAUTOI -
.....
- OAUTO BIT INACTIVE TEST -
.....
THIS TEST VERIFIES THAT THE DUT'S OAUTO FUNCTION BEHAVES CORRECTLY
WHEN INACTIVE, IE OAUTO BIT CLEAR.
THIS TEST WILL ONLY EXECUTE IF STAGGERED LOOPBACK MODE IS SELECTED.
THE SPECIAL STAGGERED LOOPBACK CONNECTOR MUST BE FITTED.
.....
BGNTST
TS::
CMPB  LOPBCK,#2      ;CHK CK MODE SELECTED.
BEQ    .+6           ;DO NOT EXIT IF STAGGERD LOPBCK MODE SELECTED.
JMP    608           ;EXIT THIS TEST.
SETPRI @PRIOS       ;ALLOW LTC INTERRUPTS.
MOV    @PRIOS,R0
TRAP   C@SPRI
TNUM  ** TNUM + 1    ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV    @TNUM,TSTNUM  ;SET UP THE TEST NUMBER. (49)
MOV    @-1,CTRLCF    ;INDICATE THAT WE ARE IN A TEST.
MOV    @1,ERRTYP     ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV    @4901,ERRNBR  ;SET ERROR NUMBER TO 4901.
MOV    @EM4901,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
MOV    @ER9101,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
;
; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 4901 <<<<.
;
JSR    PC,CLMRST     ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
BCS    .+6           ;DO NOT EXIT IF RESET WAS SUCCESSFUL.
JMP    608           ;EXIT THIS TEST.
;
; SET-UP THE ASSOCIATED TX/RX LINE NUMBER TABLES.
;
JSR    PC,ASLNTL     ;INITIALISE THE ASSOCIATED TX/RX TABLES.
;
; SET EXTERNAL LOOPBACK, DISABLE OAUTO AND ENABLE RECEIVER ON ALL ACTIVE LINES.
; SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
; 2 STOP BITS.
; ENABLE TRANSMITTERS ON ALL LINES.
;
MOV    ACTLNS,R5     ;PASS THE ACTIVE LINE BIT MAP.
MOV    @4,R0         ;PASS THE LNCTRL CONTENTS.
JSR    PC,WTLNLC     ;INITIALISE THE LNCTRL REGISTERS.
MOV    @MAPLNS,R5    ;PASS BIT MAP OF ALL LINES.
MOV    @177670,R0    ;PASS THE LPR CONTENTS.
JSR    PC,WTLPR      ;INITIALISE THE LPR REGISTERS ON ALL LINES.
JSR    PC,TXENBL     ;ENABLE TRANSMITTERS ON ALL LINES.
;
; SET UP OUTER LOOP FOR TESTING ACTIVE LINES IN BOTH LINE GROUPS.
;
MOV    @100000,R3    ;SET-UP LOOP CONTROL FLAG.
MOV    ACTLNS,R5     ;GET THE ACTIVE LINE BIT MAP.
BIC    LGRP2M,R5     ;REMOVE LINES IN GROUP 2.
    
```



```

5430 023050 010567 000404      2:      MOV      R5,45:      ;SAVE THE CURRENT LINE GROUP.
5431 023054 005067 000376      CLR      40:      ;CLEAR THE LINE NUMBER COUNTER.
5432 023060 016701 000372      4:      MOV      40:,R1    ;COPY THE LINE NUMBER.
5433 023064 000241      CLC      ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
5434 023066 006005      ROR      R5        ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
5435 023070 103064      BCC      8:        ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
5436
5437      ;*
5438      ; TEST THE STATE OF THE OAUTO BIT ON THE LINE UNDER TEST.
5439      ; REPORT ERROR IF IT IS FOUND SET, AND SKIP FURTHER TESTING OF THAT LINE.
5440 023072 012767 011446 160752      -      MOV      #4902,ERRNBR ;SET THE ERROR NUMBER TO 4902.
5441 023100 010177 157122      MOV      R1,BCSRA  ;SELECT THE LINE TO BE TESTED.
5442 023104 032777 000020 157124      BIT      #BIT4,BLNCTRA ;TEST THE STATE OF THE OAUTO BIT.
5443 023112 001410      BEQ      6:        ;SKIP ERROR REPORT IF OAUTO BIT IS CLEAR.
5444 023114 012702 005760      MOV      #EM4902,R2 ;PASS THE ERROR MESSAGE.
5445      ; "OAUTO BIT BAD ON LINE NN"
5446 023120      ERROR      ;
5447 023120 104460      ;          >>>> ERROR #4902 <<<<<.
5448      ;          TRAP      C#ERROR
5449
5450      ;*
5451      ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5452 023122 032767 000100 157060      -      BIT      #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5453 023130 001556      BEQ      60:      ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5454      ; DURING THE SOFTWARE QUESTIONS.
5455 023132 000443      BR       8:        ;SKIP FURTHER TESTING OF THIS LINE.
5456
5457      ;*
5458      ; TRANSMIT THE XOFF (ASCII DC3) ON THE ASSOCIATED LINE.
5459 023134 116177 004010 157064 6:      -      MOVB   TXRLNB(R1),BCSRA ;SELECT THE ASSOCIATED TX LINE.
5460 023142 112777 000023 157064      MOVB   #23,BFDATA  ;TRANSMIT THE XOFF CHARACTER TO THE LUT.
5461
5462      ;*
5463      ; WAIT FOR TRANSMISSION TO COMPLETE.
5464 023150 005267 160676      -      INC      ERRNBR    ;INCREMENT ERROR NUMBER TO 4903.
5465 023154 012701 170012      MOV      #170012,R1 ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
5466 023160 016702 157042      MOV      CSRA,R2   ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5467 023164 004767 174246      JSR     PC,WAIBIS  ;WAIT FOR TRANSMISSION TO COMPLETE.
5468 023170 103134      BCC     50:      ;ABORT TEST IF TIMEOUT OCCURRED.
5469 023172 012704 000005      MOV      #5,R4     ;PASS TIME-OUT OF 5 MILLI SECS.
5470 023176 004767 171060      JSR     PC,DELAY   ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
5471
5472      ;*
5473      ; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
5474      ; REPORT ERROR IF TX_ENABLE BIT IS CLEAR.
5475 023202 005267 160644      -      INC      ERRNBR    ;INCREMENT ERROR NUMBER TO 4904.
5476 023206 016701 000244      MOV      40:,R1    ;GET THE NUMBER OF THE LINE TEST.
5477 023212 010177 157010      MOV      R1,BCSRA  ;SELECT THE LINE CURRENTLY UNDER TEST.
5478 023216 005777 157020      TST     #TXAD2A    ;TEST THE STATE OF THE TX_ENABLE BIT.
5479 023222 100407      BMI     8:        ;SKIP ERROR REPORT IF BIT IS SET.
5480 023224 012702 005760      MOV      #EM4902,R2 ;PASS THE MESSAGE TO BE REPORTED.
5481      ; "OAUTO BIT BAD ON LINE NN".
5482 023230      ERROR      ;
5483 023230 104460      ;          >>>> ERROR #4904 <<<<<.
5484      ;          TRAP      C#ERROR

```

```

5485 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5486 ;
5487 023232 032767 000100 156750 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5488 023240 001512 BEQ 60# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5489 ; DURING THE SOFTWARE QUESTIONS.
5490
5491 023242 005267 000210 8# : INC 40# ;INCREMENT THE LINE NUMBER,
5492 023246 005705 TST R5 ;CHECK IF THERE ARE ANY MORE LINES TO TEST.
5493 023250 001303 BNE 4# ;
5494 ;
5495 ; DISABLE TRANSMITTERS ON THE SELECTED LINES IN THE CURRENT LINE GROUP.
5496 ;
5497 023252 016705 000202 MOV 45#,R5 ;RESTORE THE CURRENT LINE ACTIVE LINE GROUP.
5498 023256 004767 173544 JSR PC,TXDSBL ;DISABLE TRANSMITTERS ON THE SELECTED LINES.
5499 023262 016705 000172 MOV 45#,R5 ;GET THE CURRENT ACTIVE LINE GROUP AGAIN.
5500 023266 005067 000164 CLR 40# ;CLEAR THE LINE COUNTER.
5501 023272 012767 011451 160552 10# : MOV #4905.,ERRNBR ;SET ERROR NUMBER TO 4905.
5502 023300 016701 000152 MOV 40#,R1 ;COPY THE LINE NUMBER.
5503 023304 000241 CLC ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
5504 023306 006005 ROR R5 ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
5505 023310 103041 BCC 12# ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
5506 ;
5507 ; TRANSMIT THE XON (ASCII DC1) ON THE ASSOCIATED LINE.
5508 ;
5509 023312 116177 004010 156706 MOVB TXRLNB(R1),@CSRA ;SELECT THE ASSOCIATED TX LINE.
5510 023320 112777 000021 156706 MOVB #21,@FDATA ;TRANSMIT THE XON CHARACTER TO THE LUT.
5511 ;
5512 ; WAIT FOR TRANSMISSION TO COMPLETE.
5513 ;
5514 023326 012701 170012 MOV #170012,R1 ;TEST BIT 15. TIMEOUT OF 10 MILLI SECS.
5515 023332 016702 156670 MOV CSRA,R2 ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5516 023336 004767 174074 JSR PC,WAIBIS ;WAIT FOR TRANSMISSION TO COMPLETE.
5517 023342 103047 BCC 50# ;ABORT TEST IF TIMEOUT OCCURRED.
5518 023344 012704 000005 MOV #5,R4 ;PASS TIME-OUT OF 5 MILLI SECS.
5519 023350 004767 170706 JSR PC,DELAY ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
5520 ;
5521 ; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
5522 ; REPORT ERROR IF TX_ENABLE BIT IS SET.
5523 ;
5524 023354 005267 160472 INC ERRNBR ;INCREMENT ERROR NUMBER TO 4906.
5525 023360 016701 000072 MOV 40#,R1 ;GET THE NUMBER OF THE LINE UNDER TEST.
5526 023364 010177 156636 MOV R1,@CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
5527 023370 005777 156646 TST @TXAD2A ;TEST THE STATE OF THE TX_ENABLE BIT.
5528 023374 100007 BPL 12# ;SKIP ERROR REPORT IF BIT IS CLEAR.
5529 023376 012702 005760 MOV #EM4902,R2 ;PASS THE MESSAGE TO BE REPORTED.
5530 ; "OAUTO BIT BAD ON LINE NN".
5531 023402 ERROR ; >>>>> ERROR #4906 <<<<<.
5532 023402 104460 TRAP C#ERROR
5533 ;
5534 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5535 ;
5536 023404 032767 000100 156576 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5537 023412 001425 BEQ 60# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5538 ; DURING THE SOFTWARE QUESTIONS.
5539 ;
5540 023414 005267 000036 12# : INC 40# ;INCREMENT THE LINE NUMBER.

```

```

5541 023420 005705          TST   R5          ;CHECK IF THERE ARE ANY MORE LINES TO TEST.
5542 023422 001323          BNE   R3          ;
5543                          ;*
5544                          ; CHECK LOOP CONTROL FLAG TO DETERMINE IF BOTH SETS OF LINES HAVE BEEN TESTED
5545                          ; IF THIS IS THE FIRST TIME AROUND, RE-ENABLE TX ON ALL LINES, GENERATE ACTIVE
5546                          ; BIT MAP FOR SECOND LINE GROUP.
5547                          ;-
5548 023424 005703          TST   R3          ;HAVE BOTH LINE GROUPS BEEN TESTED?.
5549 023426 001417          BEQ   R3          ;YES; THEN EXIT THIS TEST.
5550 023430 005003          CLR   R3          ;NO; CLEAR THE LOOP CONTROL FLAG.
5551 023432 012705 177777    MOV   #MAPLNS,R5 ;PASS THE BIT MAP OF ALL AVAILABLE LINE.
5552 023436 004767 173460    JSR   PC,TXENBL  ;RE-ENABLE TRANSMISSION ON ALL LINES.
5553 023442 016705 156552    MOV   ACTLNS,R5 ;GET THE ACTIVE LINE BIT MAP.
5554 023446 046705 156606    BIC   LGRP1M,R5 ;REMOVE ALL ACTIVE LINES IN GROUP 1.
5555 023452 000167 177372    JMP   R2          ;ONCE MORE AROUND AND WE ARE DONE.
5556
5557 023456 000000          40#: .WORD 0      ;STORAGE FOR CURRENT LINE NUMBER.
5558 023460 000000          45#: .WORD 0      ;STORAGE FOR CURRENT ACTIVE LINE BIT MAP.
5559 023462 004767 173204    50#: JSR   PC,TSABRT ;REPORT TEST ABORTED. NON TEST RELATED ERROR.
5560 023466 005067 156556    60#: CLR   CTRLCF  ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5561
5562 023472          ENDTST
                                L10032: TRAP   C:ETST
023472          104401
    
```

5564
5565
5566
5567
5568
5569
5570
5571
5572
5573
5574
5575
5576 023474
023474
5577 023474 126727 156522 000002
5578 023502 001402
5579 023504 000167 000556
5580 023510
023510 012700 000240
023514 104441
5581 000006
5582 023516 012767 000006 156530
5583 023524 012767 177777 156516
5584 023532 012767 000001 160310
5585 023540 012767 011611 160304
5586 023546 012767 006012 160360
5587 023554 012767 013136 160274
5588
5589
5590
5591
5592
5593 023562 004767 170430
5594 023566 103402
5595 023570 000167 000472
5596
5597
5598
5599 023574 004767 167642
5600
5601
5602
5603
5604
5605
5606 023600 016705 156414
5607 023604 012700 000024
5608 023610 004767 173736
5609 023614 012705 177777
5610 023620 012700 177670
5611 023624 004767 173752
5612 023630 004767 173266
5613
5614
5615
5616 023634 012703 100000
5617 023640 016705 156354

```
.SBTTL HARDWARE TEST - DAUTOA -
;*****
; - DAUTO BIT ACTIVE TEST -
;
; THIS TEST VERIFIES THAT THE DUT'S DAUTO FUNCTION BEHAVES CORRECTLY
; WHEN ACTIVE, IE DAUTO BIT ASSERTED HIGH.
; THIS TEST WILL ONLY EXECUTE IF THE STAGGERED LOOPBACK MODE IS SELECTED.
; THE SPECIAL STAGGERED LOOPBACK CONNECTOR MUST BE FITTED.
;*****
BGNTST
;*****
; T6::
CMBP LOPBCK,#2 ;CHECK MODE SELECTED.
BEQ #6 ;DO NOT EXIT IF STAGGERD LOPBCK MODE SELECTED.
JMP 60H ;EXIT THIS TEST.
SETPRI #PRI05 ;ALLOW LTC INTERRUPTS.
;*****
MOV #PRI05,R0
TRAP C#SPRI
TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (50)
MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV #5001,ERRNBR ;SET ERROR NUMBER TO 5001.
MOV #EM5001,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
MOV #ER9101,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
;
; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 5001 <<<<.
;
; JSR PC,CLRST ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
; BCS #6 ;DO NOT EXIT IF RESET WAS SUCCESSFUL.
; JMP 60H ;EXIT THIS TEST.
;
; SET UP THE ASSOCIATED TX/RX LINE NUMBER TABLES.
;
; JSR PC,ASLNTL ;INITIALISE THE ASSOCIATED TX/RX TABLES.
;
; SET EXTERNAL LOOPBACK,ENABLE DAUTO AND RECEIVER FUNCTIONS ON ALL ACTIVE LINES
; SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
; 2 STOP BITS.
; ENABLE TRANSMITTERS ON ALL LINES.
;
; MOV ACTLNS,R5 ;PASS THE ACTIVE LINE BIT MAP.
; MOV #24,R0 ;PASS THE LNCTRL CONTENTS.
; JSR PC,WTWLMC ;INITIALISE THE LNCTRL REGISTERS.
; MOV #MAPLNS,R5 ;PASS BIT MAP OF ALL LINES.
; MOV #177670,R0 ;PASS THE LPR CONTENTS.
; JSR PC,WTWLPN ;INITIALISE THE LPR REGISTERS ON ALL LINES.
; JSR PC,TXENBL ;ENABLE TRANSMITTERS ON ALL LINES.
;
; SET UP OUTER LOOP FOR TESTING ACTIVE LINES IN BOTH LINE GROUPS.
;
; MOV #100000,R3 ;SET-UP LOOP CONTROL FLAG.
; MOV ACTLNS,R5 ;GET THE ACTIVE LINE BIT MAP.
```

```

5618 023644 046705 156412          BIC    LGRP2M,R5      ;REMOVE LINES IN GROUP 2.
5619 023650 010567 000404          2#:   MOV    R5,45#    ;SAVE THE CURRENT LINE GROUP.
5620 023654 005067 000376          CLR    40#          ;CLEAR THE LINE NUMBER COUNTER.
5621 023660 016701 000372          4#:   MOV    40#,R1    ;COPY THE LINE NUMBER.
5622 023664 000241                CLC                    ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
5623 023666 006005                ROR    R5             ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
5624 023670 103064                BCC    8#            ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
5625
5626          ;*
5627          ; TEST THE STATE OF THE OAUTO BIT ON THE LINE UNDER TEST.
5628          ; REPORT ERROR IF IT IS FOUND CLEAR, AND SKIP FURTHER TESTING OF THAT LINE.
5629 023672 012767 011612 160152          MOV    #5002,ERRNBR  ;SET THE ERROR NUMBER TO 5002.
5630 023700 010177 156322          MOV    R1,BCSRA     ;SELECT THE LINE TO BE TESTED.
5631 023704 032777 000020 156324          BIT    #BIT4,BLNCTRA ;TEST THE STATE OF THE OAUTO BIT.
5632 023712 001010                BNE    6#            ;SKIP ERROR REPORT IF OAUTO BIT IS SET.
5633 023714 012702 005760          MOV    #EM4902,R2   ;PASS THE ERROR MESSAGE.
5634          ; "OAUTO BIT BAD ON LINE NN"
5635 023720          ERROR                                ;
5636          ;          >>>> ERROR #5002 <<<<<.
5637          ;          TRAP    C#ERROR
5638
5639          ;*
5640          ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5641 023722 032767 000100 156260          BIT    #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5642          BEQ    60#    ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5643          ; DURING THE SOFTWARE QUESTIONS.
5644 023732 000443                BR     8#            ;SKIP FURTHER TESTING OF THIS LINE.
5645
5646          ;*
5647          ; TRANSMIT THE XOFF (ASCII DC3) ON THE ASSOCIATED LINE.
5648 023734 116177 004010 156264          6#:   MOV    TXRLNB(R1),BCSRA ;SELECT THE ASSOCIATED TX LINE.
5649 023742 112777 000023 156264          MOV    #23,BFDATA   ;TRANSMIT THE XOFF CHARACTER TO THE LUT.
5650
5651          ;*
5652          ; WAIT FOR TRANSMISSION TO COMPLETE.
5653 023750 005267 160076          INC    ERRNBR       ;INCREMENT ERROR NUMBER TO 5003.
5654 023754 012701 170012          MOV    #170012,R1   ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
5655 023760 016702 156242          MOV    CSRA,R2     ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5656 023764 004767 173446          JSR    PC,WAIBIS    ;WAIT FOR TRANSMISSION TO COMPLETE.
5657 023770 103134                BCC    50#          ;ABORT TEST IF TIMEOUT OCCURRED.
5658 023772 012704 000005          MOV    #5,R4        ;PASS TIME-OUT OF 5 MILLI SECS.
5659 023776 004767 170260          JSR    PC,DELAY     ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
5660
5661          ;*
5662          ; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
5663          ; REPORT ERROR IF TX_ENABLE BIT IS SET.
5664 024002 005267 160044          INC    ERRNBR       ;INCREMENT ERROR NUMBER TO 5004.
5665 024006 016701 000244          MOV    40#,R1       ;GET THE NUMBER OF THE LINE TEST.
5666 024012 010177 156210          MOV    R1,BCSRA     ;SELECT THE LINE CURRENTLY UNDER TEST.
5667 024016 005777 156220          TST    BTXAD2A     ;TEST THE STATE OF THE TX_ENABLE BIT.
5668 024022 100007                BPL    8#            ;SKIP ERROR REPORT IF BIT IS CLEAR.
5669 024024 012702 005760          MOV    #EM4902,R2   ;PASS THE MESSAGE TO BE REPORTED.
5670          ; "OAUTO BIT BAD ON LINE NN".
5671 024030          ERROR                                ;
5672          ;          >>>> ERROR #5004 <<<<<.
5673          ;          TRAP    C#ERROR
    
```

```

5673
5674
5675
5676 024032 032767 000100 156150
5677 024040 001512
5678
5679
5680 024042 005267 000210
5681 024046 005705
5682 024050 001303
5683
5684
5685
5686 024052 016705 000202
5687 024056 004767 172744
5688 024062 016705 000172
5689 024066 005067 000164
5690 024072 012767 011615 157752 10:
5691 024100 016701 000152
5692 024104 000241
5693 024106 006005
5694 024110 103041
5695
5696
5697
5698 024112 116177 004010 156106
5699 024120 112777 000021 156106
5700
5701
5702
5703 024126 012701 170012
5704 024132 016702 156070
5705 024136 004767 173274
5706 024142 103047
5707 024144 012704 000005
5708 024150 004767 170106
5709
5710
5711
5712
5713 024154 005267 157672
5714 024160 016701 000072
5715 024164 010177 156036
5716 024170 005777 156046
5717 024174 100407
5718 024176 012702 005760
5719
5720 024202
    024202 104460
5721
5722
5723
5724
5725 024204 032767 000100 155776
5726 024212 001425
5727
5728
    ;*
    ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
    ;*
    ; BIT #BIT06.OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
    ; BEQ 60: ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
    ; ;DURING THE SOFTWARE QUESTIONS.
    ;*
    ; INC 40: ;INCREMENT THE LINE NUMBER,
    ; TST R5 ;CHECK IF THERE ARE ANY MORE LINES TO TEST.
    ; RNE 4: ;
    ;*
    ; DISABLE TRANSMITTERS ON THE SELECTED LINES IN THE CURRENT LINE GROUP.
    ;*
    ; MOV 45,R5 ;RESTORE THE CURRENT LINE ACTIVE LINE GROUP.
    ; JSR PC,TXDSBL ;DISABLE TRANSMITTERS ON THE SELECTED LINES.
    ; MOV 45,R5 ;GET THE CURRENT LINE ACTIVE LINE GROUP AGAIN.
    ; CLR 40: ;CLEAR THE LINE COUNTER.
    ; MOV #5005,ERRNBR ;SET ERROR NUMBER TO 5005.
    ; MOV 40,R1 ;COPY THE LINE NUMBER.
    ; CLC ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
    ; ROR R5 ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
    ; BCC 12: ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
    ;*
    ; TRANSMIT THE XON (ASCII DC1) ON THE ASSOCIATED LINE.
    ;*
    ; MOVB TXRLNB(R1),@CSRA ;SELECT THE ASSOCIATED TX LINE.
    ; MOVB #21,@FDATA ;TRANSMIT THE XON CHARACTER TO THE LUT.
    ;*
    ; WAIT FOR TRANSMISSION TO COMPLETE.
    ;*
    ; MOV #170012,R1 ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
    ; MOV CSRA,R2 ;PASS THE ADDRESS OF THE REGISTER TO TEST.
    ; JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE.
    ; BCC 50: ;ABORT TEST IF TIMEOUT OCCURRED.
    ; MOV #5,R4 ;PASS TIME-OUT OF 5 MILLI SECS.
    ; JSR PC,DELAY ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
    ;*
    ; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
    ; REPORT ERROR IF TX_ENABLE BIT IS CLEAR.
    ;*
    ; INC ERRNBR ;INCREMENT ERROR NUMBER TO 5006.
    ; MOV 40,R1 ;GET THE NUMBER OF THE LINE UNDER TEST.
    ; MOV R1,@CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
    ; TST @TXAD2A ;TEST THE STATE OF THE TX_ENABLE BIT.
    ; BMI 12: ;SKIP ERROR REPORT IF BIT IS SET.
    ; MOV #EM4902,R2 ;PASS THE MESSAGE TO BE REPORTED.
    ; ; "OAUTO BIT BAD ON LINE NN".
    ; ERROR ;
    ; >>>> ERROR #5006 <<<<<.
    ; TRAP C:ERROR
    ;*
    ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
    ;*
    ; BIT #BIT06.OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
    ; BEQ 60: ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
    ; ;DURING THE SOFTWARE QUESTIONS.
    ;*
    
```

```

5729 024214 005267 000036      12$:   INC   40$      ;INCREMENT THE LINE NUMBER,
5730 024220 005705              TST   R5          ;CHECK IF THERE ARE ANY MORE LINES TO TEST.
5731 024222 001323              BNE   10$          ;
5732                          ;*
5733                          ; CHECK LOOP CONTROL FLAG TO DETERMINE IF BOTH SETS OF LINES HAVE BEEN TESTED
5734                          ; IF THIS IS THE FIRST TIME AROUND, RE-ENABLE TX ON ALL LINES, GENERATE ACTIVE
5735                          ; BIT MAP FOR SECOND LINE GROUP.
5736                          ;-
5737 024224 005703              TST   R3          ;HAVE BOTH LINE GROUPS BEEN TESTED?.
5738 024226 001417              BEQ   60$          ;YES, THEN EXIT THIS TEST.
5739 024230 005003              CLR   R3          ;NO; CLEAR THE LOOP CONTROL FLAG.
5740 024232 012705 177777      MOV   @MAPLNS,R5 ;PASS THE BIT MAP OF ALL AVAILABLE LINE.
5741 024236 004767 172660      JSR   PC,TXENBL  ;RE-ENABLE TRANSMISSION ON ALL LINES.
5742 024242 016705 155752      MOV   ACTLNS,R5 ;GET THE ACTIVE LINE BIT MAP.
5743 024246 046705 156006      BIC   LGRP1M,R5 ;REMOVE ALL ACTIVE LINES IN GROUP 1.
5744 024252 000167 177372      JMP   2$          ;ONCE MORE AROUND AND WE ARE DONE.
5745
5746 024256 000000      40$:   .WORD  0      ;STORAGE FOR CURRENT LINE NUMBER.
5747 024260 000000      45$:   .WORD  0      ;STORAGE FOR CURRENT ACTIVE LINE BIT MAP.
5748 024262 004767 172404      50$:   JSR   PC,TSABRT ;REPORT TEST ABORTED. NON-TEST RELATED ERROR.
5749 024266 005067 155756      60$:   CLR   CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5750
5751 024272              ENDTST
           024272
           024272 104401
    
```

L10033: TRAP C#ETST

512

```

5753
5754 .SBTTL  HARDWARE TEST          - IAUTOI -
5755 ;*****
5756 ;*                               - IAUTO BIT INACTIVE TEST
5757 ;*
5758 ;* THIS TEST VERIFIES THAT THE DUT'S IAUTO FUNCTION BEHAVES CORRECTLY
5759 ;* WHEN INACTIVE, IE. IAUTO BIT CLEAR.
5760 ;* ALL ACTIVE LINES ARE TESTED INDIVIDUALLY BY FILLING THE FIFO
5761 ;* THEN READING THE RECEIVED DATA CHECKING FOR THE PRESENCE OF
5762 ;* XOFF(ASCII DC3) OR XON(ASCII DC1) CHARACTERS.
5763 ;* IF ANY ARE FOUND THEN APPROPRIATE ERRORS ARE REPORTED.
5764 ;* ANY BMP CODES THAT ARE FOUND WILL BE PLACED ON THE BMP CODE QUEUE.
5765 ;* TO BE REPORTED LATER.
5766 ;* THE CHARACTERS ARE TRANSMITTED ON ALL ACTIVE LINES, IN INTERNAL
5767 ;* LOOPBACK MODE.
5768 ;*
5769 ;-----*****
5770
5771 024274          BGNTST
5772 024274          SETPRI  #PRIOS          ;ALLOW LTC INTERRUPTS.          T7::
5773 024274          012700  000240          MOV          #PRIOS,RC
5774 024300          104441          TRAP          C$GPRI
5775 024302          012767  000007  155744          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5776 024310          012767  177777  155732          MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (51)
5777 024316          012767  000001  157524          MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
5778 024324          012767  011755  157520          MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5779 024332          012767  006051  157514          MOV          #5101,ERRNBR          ;SET ERROR NUMBER TO 5101.
5780 024340          012767  013136  157510          MOV          #EMS101,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5781 ;*                               ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
5782 ;*
5783 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
5784 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
5785 ; THIS SUBROUTINE REPORTS ERROR >>>> 5101 <<<<<.
5786 ;-
5787 JSR          PC,CLRST          ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
5788 BCC          601          ;EXIT TEST IF FATAL ERROR FOUND.
5789 ;*
5790 ; INITIALIZE THE 256 BYTE DATA PATTERN.
5791 ; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
5792 ; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
5793 ;-
5794 JSR          PC,INDTPX          ;INITIALISE DATA PATTERN.
5795 ;*
5796 ; SET INTERNAL LOOPBACK, DISABLE IAUTO, ENABLE RECEIVER ON THE SELECTED LINE.
5797 ; SET LPR TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
5798 ;-
5799 MOV          ACTLNS,R5          ;PASS THE ACTIVE LINE BIT MAP.
5800 MOV          #204,R0          ;PASS INT'L LOOPBACK, ENABLE RX, DISABLE IAUTO.
5801 JSR          PC,WTWLNLC          ;INITIALISE THE LINE CONTROL REGISTER.
5802 MOV          #177670,R0          ;PASS THE LPR CONTENTS.
5803 JSR          PC,WTWLPRL          ;SET THE LPR CONTENTS TO 38.4K BAUD.
5804 MOV          #10,R4          ;PASS DELAY TIME OF 10 MILLI SECONDS.
5805 JSR          PC,DELAY          ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
5806 ;*

```



```

5807 ; SET UP LOOP FOR ALL ACTIVE LINES.
5808 ; TEST THE STATE OF THE IAUTO BIT PRIOR TO TRANSMITTING THE DATA PATTERN.
5809 ; IF THE BIT IS SET, THEN REPORT THE ERROR AND SKIP TRANSMITTING
5810 ; THE DATA PATTERN ON THE SELECTED LINE.
5811 ; TRANSMIT A 256 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
5812 ; EMPTY THE FIFO, AND VERIFY NO XOFF OR XON CHARS WERE FOUND.
5813 ;-
5814 024414 005001          CLR    R1          ;CLEAR THE LINE NUMBER COUNTER.
5815 024416 005067 000264 CLR    55          ;CLEAR STORAGE FOR LINE NUMBER.
5816 024422 012767 011756 157422 2:  MOV    #5102.,ERRNBR ;SET THE ERROR NUMBER TO 5102.
5817 024430 004767 170734      JSR    PC,PUFIFO   ;PURGE THE FIFO.
5818 024434 103121          BCC    50          ;GO REPORT ERROR IF FIFO DID NOT PURGE.
5819 024436 000241          CLC          ;CLEAR CARRY PRIOR TO ROTATING BIT MAP.
5820 024440 006005          ROR    R5          ;ROTATE THE BIT MAP INTO THE CARRY BIT.
5821 024442 103107          BCC    12          ;BRANCH IF LINE IS INACTIVE.
5822 ;+
5823 ; TEST THE IAUTO BIT ON THE SELECTED ACTIVE LINE.
5824 ; REPORT ERROR IF IT IS SET.
5825 ; DO NOT TRANSMIT THE DATA PATTERN ON THE SELECTED LINE.
5826 ;-
5827 024444 005267 157402      INC    ERRNBR      ;SET ERROR NUMBER TO 5103.
5828 024450 010177 155552      MOV    R1,BCSRA   ;SELECT LINE TO TEST.
5829 024454 032777 000002 155554 BIT    #BIT1,BLNCTRA ;TEST THE STATE OF THE IAUTO BIT ON THIS LINE.
5830 024462 001410          BEQ    4          ;SKIP ERROR IF IAUTO BIT CLEAR
5831 024464 012702 006106      MOV    #EMS102,R2 ;PASS THE CORRECT ERROR MESSAGE.
5832 024470          ERROR          ; >>>> ERROR <<<<<
5833          104460          TRAP    C$ERROR
5834 ;+
5835 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5836 ;-
5837 024472 032767 000100 155510 BIT    #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5838 024500 001503          BEQ    60          ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5839 ; DURING THE SOFTWARE QUESTIONS.
5840 ;-
5841 024502 000467          BR     12          ;SKIP TRANSMITTING DATA PATTERN.
5842 ;+
5843 ; TRANSMIT DATA PATTERN OF 256 CHARS.
5844 ;-
5845 4: INC    ERRNBR      ;SET ERROR NUMBER TO 5104.
5846 024504 005267 157342      MOV    #0UFBAS,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
5847 024510 012702 002650      MOV    #256.,R3   ;PASS THE LENGTH OF THE DATA PATTERN.
5848 024514 012703 000400      JSR    PC,DODMA   ;TRANSMIT THE DATA PATTERN.
5849 024520 004767 167654      BCC    50          ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
5850 024524 103065
5851 ;+
5852 ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER PLUS XOFF
5853 ; TO ARRIVE IN THE FIFO.
5854 ;-
5855 5856 024526 005267 157320      INC    ERRNBR      ;SET ERROR NUMBER TO 5105.
5857 024532 012701 170536      MOV    #170536,R1 ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
5858 024536 016702 155464      MOV    CSRA,R2    ;PASS THE ADDRESS OF THE CSR.
5859 024542 004767 172670      JSR    PC,WAIBIS  ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
5860 024546 103054          BCC    50          ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
5861 024550 012704 000012      MOV    #10.,R4    ;PASS DELAY OF 10 MILLI SECS.
5862 024554 004767 167502      JSR    PC,DELAY   ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.

```

```

5863
5864
5865      ; READ 256 CHARS FROM THE FIFO. REPORT ERROR IF ANY XOFF'S OR XON'S
5866      ; ARE FOUND.
5867      ;-
5868      INC   ERRNBR           ;INCREMENT ERROR NUMBER TO 5106.
5869      MOV   #256,R1         ;INITIALISE THE READ COUNTER.
5870      MOV   @RBUF,R2        ;READ CHAR FROM THE FIFO.
5871      BPL   50#             ;GO REPORT ERROR IF FIFO EMPTY.
5872      ;+
5873      ; CHECK FOR BMP CODE IN THE FIFO. SAVE ANY FOUND ON THE QUEUE.
5874      ;-
5875      MOV   #170301,R0      ;SET UP BMP BIT MASK.
5876      BIC   R2,R0           ;TRY TO CLEAR ALL THE BMP BITS.
5877      BNE   8#             ;SKIP BMP SAV IF NOT A BMP CODE.
5878      JSR   PC,SAVBMP      ;SAVE THE BMP CODE ON THE QUEUE.
5879      ;+
5880      ; CHECK FOR XOFF AND XON CHARACTERS.
5881      ;-
5882      CMPB  R2,#23         ;IS IT AN XOFF CHARACTER?.
5883      BEQ   10#            ;YES; GO REPORT ERROR.
5884      CMPB  R2,#21         ;NO; IS IT AN XON CHARACTER?.
5885      BEQ   10#            ;YES; GO REPORT ERROR.
5886      DEC   R1             ;DECREMENT THE READ COUNT.
5887      BNE   6#             ;LOOP TO READ THE NEXT CHAR.
5888      BR    12#           ;GO CHECK FOR ANY UNTESTED ACTIVE LINES.
5889
5890      INC   ERRNBR           ;SET ERROR NUMBER TO 5107.
5891      MOV   55#,R1          ;PASS THE LINE NUMBER TO BE REPORTED.
5892      MOV   #EMS103,R2     ;PASS THE ERROR MESSAGE TO BE REPORTED.
5893      ERROR                                ;
5894      TRAP  C$ERROR
5895
5896      ;+
5897      ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5898      ;-
5899      BIT   #BIT06,OPTION   ;EXIT WITH TEST FAILURE MESSAGE IF
5900      BEQ   60#             ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5901      ;DURING THE SOFTWARE QUESTIONS.
5902
5903      ;+
5904      ; CHECK IF ALL ACTIVE LINES HAVE BEEN TESTED.
5905      ;-
5906      INC   55#            ;INCREMENT LINE NUMBER.
5907      MOV   55#,R1         ;GET NUMBER OF THE NEXT LINE TO TEST.
5908      TST   R5             ;ARE THERE ANY MORE ACTIVE LINES TO TEST?.
5909      BNE   2#             ;LOOP TO CHECK NEXT LINE.
5910      BR    60#           ;EXIT TEST.
5911
5912      JSR   PC,TSABRT       ;REPORT TEST ABORTED. NON-TEST RELATED ERROR.
5913      BR    60#           ;EXIT THIS TEST.
5914      .WORD 0              ;STORAGE FOR LINE NUMBER.
5915      CLR   CTRLCF         ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5916
5917      ENDTST
5918
5919      L10034:
5920      TRAP  C$ETST

```

```

5917 .SBTTL  HARDWARE TEST          - IAUTOA -
5918 ;*****
5919 ;*                               - IAUTO BIT ACTIVE TEST
5920 ;*
5921 ;* THIS TEST VERIFIES THAT THE DUT'S IAUTO FUNCTION BEHAVES CORRECTLY
5922 ;* WHEN ACTIVE, IE IAUTO ASSERTED HIGH.
5923 ;* ALL ACTIVE LINES ARE TESTED INDIVIDUALLY BY FILLING THE FIFO, AND
5924 ;* CHECKING FOR THE PRESENCE OF AT LEAST ONE XOFF(ASCII DC3) CHARACTER
5925 ;* AND ONE XON (ASCII DC1) CHARACTER.
5926 ;* ANY BMP CODES THAT ARE FOUND WILL BE PLACED ON THE BMP CODE QUEUE,
5927 ;* TO BE REPORTED LATER.
5928 ;* THE CHARACTERS ARE TRANSMITTED ON ALL ACTIVE LINES, IN INTERNAL
5929 ;* LOOPBACK MODE.
5930 ;*
5931 ;*-----*****
5932
5933          BGNTST
5934          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          TB::
5935          024716 012700 000240          MOV          #PRI05,R0
5936          024716 103441          TRAP          C$SPRI
5937          024722 000010          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5938          024724 012767 000010 155322  MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (52)
5939          024732 012767 177777 155310  MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
5940          024740 012767 000001 157102  MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5941          024746 012767 012121 157076  MOV          #5201,ERRNBR          ;SET ERROR NUMBER TO 5201.
5942          024754 012767 006174 157072  MOV          #EM5201,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5943          024762 012767 013136 157066  MOV          #ER9101,ERRBLK          ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
5944 ;*
5945 ;* RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
5946 ;* CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
5947 ;* THIS SUBROUTINE REPORTS ERROR >>>> 5201 <<<<<.
5948 ;*
5949          024770 004767 167222          JSR          PC,CLRST          ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
5950          024774 103402          BCS          .+6
5951          024776 000167 000400          JMP          60$          ;EXIT TEST IF FATAL ERROR FOUND.
5952 ;*
5953 ;* INITIALIZE THE 256 BYTE DATA PATTERN.
5954 ;* ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
5955 ;* NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
5956 ;*
5957          025002 004767 167572          JSR          PC,INDTPX          ;INITIALISE DATA PATTERN.
5958 ;*
5959 ;* SET INTERNAL LOOPBACK, ENABLE IAUTO AND RECEIVER ON THE SELECTED LINE.
5960 ;* SET LPR TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
5961 ;*
5962          025006 016705 155206          MOV          ACTLNS,R5          ;PASS THE ACTIVE LINE BIT MAP.
5963          025012 012700 000206          MOV          #206,R0          ;PASS INTERNAL LOOPBACK, ENABLE RX AND IAUTO.
5964          025016 004767 172530          JSR          PC,WTWLNLC          ;INITIALISE THE LINE CONTROL REGISTER.
5965          025022 012700 177670          MOV          #177670,R0          ;PASS THE LPR CONTENTS.
5966          025026 004767 172550          JSR          PC,WTWLPR          ;SET THE LPR CONTENTS TO 38.4K BAUD.
5967          025032 012704 000012          MOV          #10.,R4          ;PASS DELAY TIME OF 10 MILLI SECONDS.
5968          025036 004767 167220          JSR          PC,DELAY          ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
5969 ;*
5970 ;* SET UP LOOP FOR ALL ACTIVE LINES.
    
```

```

5971 ; TEST THE STATE OF THE OAUTO BIT PRIOR TO TRANSMITTING THE DATA PATTERN.
5972 ; IF THE BIT IS CLEAR, THEN REPORT THE ERROR AND SKIP TRANSMITTING
5973 ; THE DATA PATTERN ON THE SELECTED LINE.
5974 ; TRANSMIT A 224 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
5975 ; EMPTY THE FIFO, AND COUNT THE XOFF AND AN XON CHARS FOUND.
5976 ;-
5977 025042 005001 CLR R1 ;CLEAR THE LINE NUMBER COUNTER.
5978 025044 005067 000330 CLR 55$ ;CLEAR STORAGE FOR LINE NUMBER.
5979 025050 012767 012122 156774 2$: MOV #5202.,ERRNBR ;SET THE ERROR NUMBER TO 5202.
5980 025056 004767 170306 JSR PC,PUFIFO ;PURGE THE FIFO.
5981 025062 103143 BCC 50$ ;GO REPORT ERROR IF FIFO DID NOT PURGE.
5982 025064 000241 CLC ;CLEAR CARRY PRIOR TO ROTATING BIT MAP.
5983 025066 006005 ROR R5 ;ROTATE THE BIT MAP INTO THE CARRY BIT.
5984 025070 103131 BCC 16$ ;BRANCH IF LINE IS INACTIVE.
5985 ;+
5986 ; TEST THE IAUTO BIT ON THE SELECTED ACTIVE LINE.
5987 ; REPORT ERROR IF IT IS CLEAR.
5988 ; DO NOT TRANSMIT THE DATA PATTERN ON THE SELECTED LINE.
5989 ;-
5990 025072 005267 156754 INC ERRNBR ;SET ERROR NUMBER TO 5203.
5991 025076 010177 155124 MOV R1,@CSRA ;SELECT LINE TO TEST.
5992 025102 032777 000002 155126 BIT #BIT1,&LNCTRA ;TEST THE STATE OF THE IAUTO BIT ON THIS LINE.
5993 025110 001010 BNE 4$ ;SKIP ERROR IF IAUTO BIT SET.
5994 025112 012702 006227 MOV #EM5202,R2 ;PASS THE CORRECT ERROR MESSAGE.
5995 ; "IAUTO BIT FOUND CLEAR ON LINE NN"
5996 025116 ERROR ;
5997 025116 104460 ; >>>> ERROR <<<<<. TRAP C$ERROR
5998 ;+
5999 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
6000 ;-
6001 025120 032767 000100 155062 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6002 025126 001525 BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
6003 ; DURING THE SOFTWARE QUESTIONS.
6004
6005 025130 000511 BR 16$ ;SKIP TRANSMITTING DATA PATTERN.
6006
6007 ;+
6008 ; TRANSMIT DATA PATTERN TO FILL THE FIFO. 223 CHARS + 32 XOFF'S + XON.
6009 ;-
6010 025132 005267 156714 4$: INC ERRNBR ;SET ERROR NUMBER TO 5204.
6011 025136 012702 002650 MOV #BUFBAS,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
6012 025142 012703 000337 MOV #223.,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
6013 025146 004767 167226 JSR PC,DODMA ;TRANSMIT THE DATA PATTERN.
6014 025152 103107 BCC 50$ ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6015
6016 ;+
6017 ; WAIT FOR DMA TO COMPLETE. THEN WAIT FOR THE LAST CHARACTER PLUS XOFF
6018 ; TO ARRIVE IN THE FIFO.
6019 ;-
6020 025154 005267 156672 INC ERRNBR ;SET ERROR NUMBER TO 5205.
6021 025160 012701 170454 MOV #170454,R1 ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6022 025164 016702 155036 MOV CSRA,R2 ;PASS THE ADDRESS OF THE CSR.
6023 025170 004767 172242 JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6024 025174 103076 BCC 50$ ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6025 025176 012704 000012 MOV #10.,R4 ;PASS DELAY OF 10 MILLI SECS.
6026 025202 004767 167054 JSR PC,DELAY ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.

```

```

6027
6028
6029      ; READ 256 CHARS FROM THE FIFO. COUNT ANY XOFF OR XON CHARS FOUND.
6030
6031      CLR      R3          ;CLEAR XOFF COUNTER.
6032      CLR      R4          ;CLEAR XON COUNTER.
6033      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 5206.
6034      MOV      @256,R1     ;INITIALISE THE READ COUNTER.
6035      MOV      @RBUF,R2    ;READ CHAR FROM THE FIFO.
6036      BPL      508         ;GO REPORT ERROR IF FIFO EMPTY.
6037
6038      ; CHECK FOR BMP CODE IN THE FIFO. SAVE ANY FOUND ON THE QUEUE.
6039
6040      MOV      @170301,R0   ;SET UP BMP BIT MASK.
6041      BIC      R2,R0       ;TRY TO CLEAR ALL THE BMP BITS.
6042      BNE      88         ;SKIP BMP SAV IF NOT A BMP CODE.
6043      JSR      PC,SAVBMP   ;SAVE THE BMP CODE ON THE QUEUE.
6044
6045      ; CHECK FOR XOFF AND XON CHARACTERS.
6046
6047      CMPB     R2,#25      ;IS IT AN XOFF CHARACTER?.
6048      BNE      108        ;NO, BRANCH TO SEE IF IT IS AN XON.
6049      INC      R3          ;COUNT THE XOFF CHAR.
6050      CMPB     R2,#21     ;IS IT AN XON CHARACTER?.
6051      BNE      128        ;NO, SKIP THE NEXT INSTRUCTION.
6052      INC      R4          ;COUNT THE XON.
6053      DEC      R1         ;DECREMENT THE READ COUNT.
6054      BEQ      138        ;BRANCH IF ALL CHARACTERS READ.
6055
6056      ; CHECK IF THE FIFO HAS BEEN EMPTIED BELOW THE HALF LEVEL. IF IT
6057      ; HAS DELAY FOR 1MS TO ALLOW THE XON TO BE GENERATED.
6058
6059      CMP      R1,#126     ;IS THE FIFO LEVEL = 126 ?
6060      BNE      68         ;LOOP TO READ THE NEXT CHARACTER IF NOT.
6061      MOV      R4,R0       ;SAVE THE XON COUNT, ALTHOUGH THERE SHOULDN'T
6062      ;BE ANY.
6063      MOV      #1,R4       ;SET THE DELAY TO 1MS.
6064      JSR      PC,DELAY    ;PERFORM THE DELAY.
6065      MOV      R0,R4       ;RESTORE THE XON COUNT.
6066      BR      68         ;LOOP TO READ THE NEXT CHAR.
6067
6068      ; VERIFY THAT AT LEAST 1 XOFF AND 1 XON WAS FOUND IN THE FIFO.
6069      ; REPORT ERROR IF NONE WERE FOUND.
6070
6071      TST      R3          ;CHECK XOFF COUNT.
6072      BEQ      148        ;GO REPORT ERROR IF NONE FOUND.
6073      CMP      R4,#1      ;CHECK XON COUNT = 1.
6074      BEQ      168        ;SKIP THE ERROR REPORT IF ONE XON WAS FOUND.
6075      INC      ERRNBR      ;SET ERROR NUMBER TO 5207.
6076      MOV      55,R1     ;PASS THE LINE NUMBER TO BE REPORTED.
6077      MOV      @EM5103,R2 ;PASS THE ERROR MESSAGE TO BE REPORTED.
6078
6079      ERROR                                ; "IAUTO BIT BAD ON LINE NN".
6080      025342      104460                                ; >>>> ERROR <<<<<.
6081                                                     TRAP      C!ERROR
6082
; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
  
```

```

6083
6084 025344 032767 000100 154636      BIT      #BITOC,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6085 025352 001413                      BEQ      608      ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
6086                                     ;DURING THE SOFTWARE QUESTIONS.
6087
6088      ; CHECK IF ALL ACTIVE LINES HAVE BEEN TESTED.
6089
6090 025354 005267 000020      168:    INC      558      ;INCREMENT LINE NUMBER.
6091 025360 016701 000014      MOV      558,R1    ;GET NUMBER OF THE NEXT LINE TO TEST.
6092 025364 005705                      TST      R5        ;ARE THERE ANY MORE ACTIVE LINES TO TEST?.
6093 025366 001250                      BNE      28        ;LOOP TO CHECK NEXT LINE.
6094 025370 000404                      BR       608      ;EXIT TEST.
6095
6096 025372 004767 171274      508:    JSR      PC,TSABRT ;REPORT TEST ABORTED. NON-TEST RELATED ERROR.
6097 025376 000401                      BR       608      ;EXIT THIS TEST.
6098 025400 000000      558:    .WORD   0        ;STORAGE FOR LINE NUMBER.
6099 025402 005067 154642      608:    CLR      CTRLCF   ;INDICATE THAT WE ARE NOT WITHIN A TEST.
6100
6101 025406                      ENDTST
        025406
        025406 104401
    L10035: TRAP      C0ETST
    
```

```

6103 .SBTTL  HARDWARE TEST          FIFDAT -
6104 :-----
6105 : - FIFO VALID DATA TEST -
6106 :
6107 : THIS TEST VERIFIES THAT THE DUT IS CAPABLE OF HOLDING 256 VALID
6108 : CHARACTERS IN ITS FIFO.
6109 : THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
6110 : INTERNAL LOOPBACK MODE.
6111 : THE DATA FOUND IN THE FIFO IS COMPARED WITH THE EXPECTED DATA, AND ANY
6112 : DISCREPANCIES ARE REPORTED.
6113 : ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
6114 : HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
6115 : REPORTED LATER.
6116 :
6117 :-----
6118 :
6119 : BGNTST
6120 : SETPRI @PRI05          ;ALLOW LTC INTERRUPTS.          T9::
6121 :                                MOV @PRI05,R0
6122 :                                TRAP C@SPRI
6123 :                                TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6124 :                                MOV @TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (53)
6125 :                                MOV @-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
6126 :                                MOV @1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6127 :                                MOV @5301,ERRNBR          ;SET ERROR NUMBER TO 5301.
6128 :                                MOV @EM5301,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
6129 :
6130 : ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
6131 : ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6132 : ; THIS SUBROUTINE REPORTS ERROR >>>> 5301 <<<<.
6133 :
6134 : JSR PC,CLRST          ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
6135 : BCC 60$          ;EXIT TEST IF FATAL ERROR FOUND.
6136 :
6137 : ; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
6138 : ; INITIALISE 256 BYTE DATA PATTERN.
6139 :
6140 : JSR PC,FINACT          ;FIND AN ACTIVE LINE.
6141 : BCC 60$          ;EXIT IF NO ACTIVE LINES FOUND.
6142 : JSR PC,INDATP          ;INITIALISE THE DATA PATTERN.
6143 :
6144 : ; TRANSMIT A 265 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
6145 : ; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
6146 :
6147 : ;
6148 : ; SET INTERNAL LOOPBACK ON THE SELECTED LINE.
6149 : ; TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
6150 :
6151 : MOV @204,R0          ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
6152 : JSR PC,WTWLNLC          ;INITIALISE THE LINE CONTROL REGISTER.
6153 : MOV @177670,R0          ;PASS THE LPR CONTENTS.
6154 : JSR PC,WTWLPR          ;SET THE LPR CONTENTS TO 38.4K BAUD.
6155 : MOV @10,R4          ;PASS DELAY TIME OF 10 MILLI SECONDS.
6156 : JSR PC,DELAY          ;WAIT FOR LNCRTL AND LPR REGS TO BE UPDATED.
6157 : MOV @BUFBAS,R2          ;PASS THE START OF THE DATA PATTERN TO TX.
6158 : MOV @BUFMID-BUFBAS,R3 ;PASS THE LENGTH OF THE DATA PATTERN.

```

E13

```

6157 025524 005267 156312          INC   ERRNBR      ;SET ERROR NUMBER TO 5302.
6158 025540 004767 166634          JSR   PC,DOIDMA  ;TRANSMIT THE DATA PATTERN.
6159 025544 103057                    BCC   50$        ;ABORT TEST IF ERROR FOUND DURING DMA TX.
6160                                     ;*
6161                                     ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
6162                                     ; THE FIFO.
6163                                     ;-
6164 025546 005267 156300          INC   ERRNBR      ;SET ERROR NUMBER TO 5303.
6165 025552 010103                    MOV   R1,R3      ;SAVE THE NUMBER OF THE SELECTED ACTIVE LINE.
6166 025554 012701 170536          MOV   #170536,R1 ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
6167 025560 016702 154442          MOV   CSRA,R2   ;PASS THE ADDRESS OF THE CSR.
6168 025564 004767 171646          JSR   PC,WAIBIS  ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6169 025570 103045                    BCC   50$        ;BRANCH IF FIFO EMPTY, ABORT THE TEST.
6170 025572 012704 000005          MOV   #5,R4     ;PASS DELAY OF 5 MILLI SECS.
6171 025576 004767 166460          JSR   PC,DELAY   ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
6172                                     ;*
6173                                     ; READ THE FIFO CHECKING FOR DATA CORRUPTION, REPORT ANY ERRORS FOUND.
6174                                     ; ABORT THE TEST IF A BMP CODE WAS FOUND IN THE FIFO.
6175                                     ;-
6176 025602 006303                    ASL   R3         ;MULTIPLY BY 2.
6177 025604 005004                    CLR   R4         ;INITIALISE THE EXPECTED DATA.
6178 025606 016705 154416          MOV   RBUFA,R5  ;GET THE ADDRESS OF THE RECEIVER BUFFER REG.
6179 025612 012767 012270 156232 2$: MOV   #5304,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
6180 025620 011502                    MOV   (R5),R2   ;GET THE ACTUAL DATA FROM THE FIFO.
6181 025622 100030                    BPL   50$        ;ABORT THE TEST IF THE FIFO IS EMPTY.
6182                                     ;*
6183                                     ; CHECK IF THE READ CHARACTER IS A BMP CODE.
6184                                     ; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
6185                                     ; ABORT THE TEST.
6186                                     ;-
6187 025624 005267 156222          INC   ERRNBR      ;SET ERROR NUMBER TO 5305.
6188 025630 004767 166142          JSR   PC,CHKBMP ;CHECK IF CHARACTER IS A BMP CODE.
6189 025634 103002                    BCC   4$        ;BRANCH IF NOT A BMP CODE.
6190 025636 104460                    ERROR >>>> ERROR 5305 <<<<<.
6191                                     ; TRAP C$ERROR
6192 025640 000423                    BR    60$        ;ABORT THIS TEST.
6193                                     ;*
6194 025642 005267 156204          4$: INC   ERRNBR      ;SET ERROR NUMBER TO 5306.
6195 025646 120402                    CMPB  R4,R2     ;COMPARE THE EXPECTED WITH THE ACTUAL DATA.
6196 025650 001412                    BEQ   8$        ;SKIP ERROR REPORT IF DATA IS OK.
6197 025652 012767 012644 156176  MOV   #ER9002,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
6198 025660 012701 006321          MOV   #EM5302,R1 ;PASS THE MESSAGE TO BE REPORTED.
6199                                     ;REPORT THE ERROR "FIFO BAD, DATA FIELD CORRUPTED"
6200 025664 104460          6$: ERROR >>>> ERROR 5306 <<<<<.
6201                                     ; TRAP C$ERROR
6202                                     ;*
6203                                     ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
6204                                     ;-
6205 025666 032767 000100 154314  BIT   #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6206 025674 001405                    BEQ   60$        ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
6207                                     ; DURING THE SOFTWARE QUESTIONS.
6208                                     ;*
6209 025676 105204          8$: INCB  R4         ;INCREMENT THE EXPECTED DATA.
6210 025700 001344                    BNE  2$        ;LOOP IF NOT DONE.
6211 025702 000402                    BR   60$        ;EXIT
    
```


6212
6213 025704 004767 170762 504: JSR PC.TSABRT ;ABORT THE TEST, REASON SHOWN BY ERROR NUMBER.
6214 025710 005067 154334 604: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
6215
6216 025714 ENDTST
025714
025714 104401 L10036: TRAP C#ETST

GIS

```

6218 .SBTTL HARDWARE TEST - FI3QLI -
6219 ;*****
6220 ; - FIFO 3/4 LEVEL INACTIVE TEST
6221 ;*
6222 ;* THIS TEST VERIFIES THAT THE DUT'S FIFO 3/4 LEVEL ALARM SYSTEM
6223 ;* REMAINS INACTIVE WHILE IT CONTAINS 191 CHARACTERS OR LESS.
6224 ;* THE TEST LOOKS FOR AN XOFF (ASCII DC3) CHARACTER IN THE FIFO.
6225 ;* IF ANY XOFF'S ARE FOUND AN ERROR WILL BE REPORTED AND THE TEST ABORTED.
6226 ;* ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
6227 ;* HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
6228 ;* REPORTED LATER.
6229 ;* THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
6230 ;* INTERNAL LOOPBACK MODE.
6231 ;
6232 ;-----
6233
6234 025716 BGNIST
6235 025716 T10::
025716 SETPRI @PRIOS ;ALLOW LTC INTERRUPTS.
025716 012700 000240 MOV @PRIOS,RO
025722 104441 TRAP C$SPRI
6236 000012 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6237 025724 012767 000012 154322 MOV @TNUM,TSTNUM ;SET UP THE TEST NUMBER. (54)
6238 025732 012767 177777 154310 MOV @-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
6239 025740 012767 000001 156102 MOV @1,ERRTYP ;SET FATAL ERROR TYPE IN ERROR TABLE.
6240 025746 012767 012431 156076 MOV ^,401,ERRNBR ;SET ERROR NUMBER TO 5401.
6241 025754 012767 006452 156072 MOV @EMS401,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
6242 025762 012767 011762 156066 MOV @ER0503,ERRBLK ;SELECT THE CORRECT ERPOP REPORTING ROUTINE.
6243 ;*
6244 ;* RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
6245 ;* CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6246 ;* THIS SUBROUTINE REPORTS ERROR >>>> 5401 <<<<.
6247 ;*
6248 025770 004767 166222 JSR PC,CLRST ;RESET THE DMU-11. REPORT ANY ERRORS FOUND.
6249 025774 103111 BCC 60$ ;EXIT TEST IF FATAL ERROR FOUND.
6250 ;*
6251 ;* FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
6252 ;*
6253 025776 004767 166466 JSR PC,FINACT ;FIND THE NUMBER OF THE FIRST ACTIVE LINE.
6254 026002 103106 BCC 60$ ;EXIT IF NO LINES ARE AVAILABLE.
6255 ;*
6256 ;*
6257 ;* INITIALIZE THE 256 BYTE DATA PATTERN.
6258 ;* ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
6259 ;* NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
6260 ;*
6261 026004 004767 166570 JSR PC,INDTPX ;INITIALISE THE DATA PATTERN.
6262 ;*
6263 ;* TRANSMIT A 191 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
6264 ;* AT 38.4K BAUD, 8 BITS PER CHARACTER, ODC PARITY, 2 STOP BITS.
6265 ;*
6266 ;*
6267 ;* SET INTERNAL LOOPBACK, ENABLE IAUTO AND RX ON THE SELECTED LINE.
6268 ;* TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
6269 ;*
6270 026010 012700 000206 MOV @206,RO ;PASS INTERNAL LOOPBACK, ENABLE RX AND IAUTO.
6271 026014 004767 171532 JSR PC,WTWLCN ;INITIALISE THE LINE CONTROL REGISTER.
    
```

```

6272 026020 012700 177670      MOV      #177670,R0      ;PASS THE LPR CONTENTS.
6273 026024 004767 171552      JSR      PC,WTWLPR      ;SET THE LPR CONTENTS TO 38.4K BAUD.
6274 026030 012704 000012      MOV      #10.,R4        ;PASS DELAY TIME OF 10 MILLI SECONDS.
6275 026034 004767 166222      JSR      PC,DELAY        ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
6276 026040 012702 002650      MOV      #8UFBAS,R2     ;PASS THE START OF THE DATA PATTERN TO TX.
6277 026044 012703 000277      MOV      #191.,R3       ;PASS THE LENGTH OF THE DATA PATTERN.
6278 026050 004767 166324      JSR      PC,DODMA       ;TRANSMIT THE DATA PATTERN.
6279 026054 103057                BCC      50$            ;IF ERROR FOUND DURING DMA THEN ABORT TEST.
6280
6281
6282                ;*
6283                ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
6284                ; THE FIFO.
6285 026056 005267 155770      INC      ERRNBR          ;SET ERROR NUMBER TO 5402.
6286 026062 012701 170454      MOV      #170454,R1     ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6287 026066 016702 154134      MOV      CSRA,R2        ;PASS THE ADDRESS OF THE CSR.
6288 026072 004767 171340      JSR      PC,WAIBIS      ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6289 026076 103046                BCC      50$            ;IF FIFO EMPTY, REPORT ERROR, ABORT THE TEST.
6290 026100 012704 000005      MOV      #5,R4          ;PASS DELAY OF 5 MILLI SECS.
6291 026104 004767 166152      JSR      PC,DELAY        ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
6292
6293                ;*
6294                ; READ THE CONTENTS OF THE FIFO. IF ANY OF THE FOLLOWING CONDITIONS OCCUR
6295                ; REPORT THE ERROR AND ABORT THE TEST:
6296                ; FIFO EMPTY TOO SOON.
6297                ; BMP CODE FOUND.
6298                ; XOFF CODE FOUND.
6299                ; EXTRA (192) CHARACTER FOUND IN FIFO.
6300 026110 005004                CLR      R4              ;CLEAR THE CHARACTER COUNT.
6301 026112 016705 154112      MOV      RBUFA,R5       ;GET THE ADDRESS OF THE RECEIVER BUFFER REG.
6302 026116 012767 012433 155726 2$:  MOV      #5403.,ERRNBR  ;SET ERROR NUMBER TO 5403.
6303 026124 011502                MOV      (R5),R2        ;GET THE ACTUAL DATA FROM THE FIFO.
6304 026126 100032                BPL      50$            ;FIFO EMPTY, ABORT TEST.
6305 026130 005204                INC      R4              ;COUNT THE CHARACTER.
6306
6307                ;*
6308                ; CHECK IF THE READ CHARACTER IS A BMP CODE.
6309                ; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
6310                ; ABORT THE TEST.
6311 026132 005267 155714      INC      ERRNBR          ;SET ERROR NUMBER TO 5404.
6312 026136 004767 165634      JSR      PC,CHKBMP      ;CHECK IF CHARACTER IS A BMP CODE.
6313 026142 103001                BCC      4$             ;BRANCH IF NOT A BMP CODE.
6314                ;REPORT ERROR "BMP CODE FOUND IN FIFO, TEST INVALIDATED".
6315 026144 000421                BR      8$              ;REPORT THE ERROR AND ABORT THE TEST.
6316
6317                ;*
6318                ; CHECK IF THE CHARACTER IS AN XOFF. REPORT THE ERROR IF ONE IS FOUND.
6319                ;
6320 026146 005267 155700      4$:  INC      ERRNBR          ;SET ERROR NUMBER TO 5405.
6321 026152 122702 000023      CMPB    #23,R2          ;CHECK IF THE READ DATA IS AN XOFF.
6322 026156 001003                BNE      6$             ;BRANCH IF NOT AN XOFF.
6323 026160 012701 006520      MOV      #EM5402,R1     ;PASS THE MESSAGE TO BE REPORTED.
6324                ;REPORT THE ERROR "FIFO BAD, ALARM SIGNAL DEFECTIVE".
6325 026164 000411                BR      8$              ;GO REPORT THE ERROR AND ABORT THE TEST.
6326
6327 026166 005267 155660      6$:  INC      ERRNBR          ;SET ERROR NUMBER TO 5406.
6328 026172 020427 000277      CMP     R4,#191.        ;CHECK IF WE HAVE READ ALL THE CHARACTERS.
    
```


J13

```

6344 .SBTTL  HARDWARE TEST          - FI3QLA -
6345 ;+-----+
6346 ;*
6347 ;*
6348 ;*
6349 ;*
6350 ;*
6351 ;*
6352 ;*
6353 ;*
6354 ;*
6355 ;*
6356 ;*
6357 ;*
6358 ;*
6359 ;*
6360 ;+-----+
6361 026226          BGNTST
6362 026226          SETPRI  #PRIOS          ;ALLOW LTC INTERRUPTS.          T11::
        026226 012700 000240
        026232 104441
6363 000013          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6364 026234 012767 000013 154012          MOV  #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (55)
6365 026242 012767 177777 154000          MOV  #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
6366 026250 012767 000001 155572          MOV  #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6367 026256 012767 012575 155566          MOV  #5501,ERRNBR          ;SET ERROR NUMBER TO 5501.
6368 026264 012767 006561 155562          MOV  #EMS501,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
6369 ;+
6370 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
6371 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6372 ; THIS SUBROUTINE REPORTS ERROR >>>> 5501 <<<<<.
6373 ;-
6374 026272 004767 165720          JSR  PC,CLRST          ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
6375 026276 103402          BCS  .+6          ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
6376 026300 000167 000414          JMP  60$          ;EXIT TEST FATAL ERROR FOUND.
6377 ;+
6378 ; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
6379 ;-
6380 026304 004767 166160          JSR  PC,FINACT          ;FIND AN ACTIVE LINE.
6381 026310 103402          BCS  .+6          ;SKIP EXIT OF TEST IF ACTIVE LINE FOUND.
6382 026312 000167 000402          JMP  60$          ;EXIT TEST.
6383 ;+
6384 ; INITIALIZE THE 256 BYTE DATA PATTERN.
6385 ; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
6386 ; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
6387 ;-
6388 026316 004767 166256          JSR  PC,INDTPX          ;INITIALISE DATA PATTERN.
6389 ;+
6390 ; TRANSMIT A 191 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
6391 ; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
6392 ;-
6393 ;+
6394 ; SET INTERNAL LOOPBACK, ENABLE IAUTO AND RECEIVER ON THE SELECTED LINE.
6395 ; TRANSMIT THE FIRST 191 CHARACTERS ON THE FIRST AVAILABLE ACTIVE LINE.
6396 ;-
6397 026322 005267 155524          2$: INC  ERRNBR          ;SET ERROR NUMBER TO 5502.
    
```

```

6398 026326 012700 000206      MOV      #206,R0      ;PASS INTERNAL LOPBCK, ENABLE RX AND IAUTO.
6399 026332 004767 171214      JSR      PC,WTWLNLC  ;INITIALISE THE LINE CONTROL REGISTER.
6400 026336 012700 177670      MOV      #177670,R0  ;PASS THE LPR CONTENTS.
6401 026342 004767 171234      JSR      PC,WTWLPR   ;SET THE LPR CONTENTS TO 38.4K BAUD.
6402 026346 012704 000012      MOV      #10.,R4     ;PASS DELAY TIME OF 10 MILLI SECONDS.
6403 026352 004767 165704      JSR      PC,DELAY    ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
6404 026356 010105                MOV      R1,R5       ;COPY THE LINE NUMBER.
6405 026360 012702 002650      MOV      #BUFBAS,R2  ;PASS THE START OF THE DATA PATTERN TO TX.
6406 026364 012703 000277      MOV      #191.,R3   ;PASS THE LENGTH OF THE DATA PATTERN.
6407 026370 004767 166004      JSR      PC,DODMA    ;TRANSMIT THE DATA PATTERN.
6408 026374 103147                BCC      50$         ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6409
6410
6411
6412
6413
6414 026376 005267 155450      INC      ERRNBR      ;SET ERROR NUMBER TO 5503.
6415 026402 012701 170454      MOV      #170454,R1  ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6416 026406 016702 153614      MOV      CSRA,R2     ;PASS THE ADDRESS OF THE CSR.
6417 026412 004767 171020      JSR      PC,WAIBIS   ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6418 026416 103136                BCC      50$         ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6419 026420 012704 000005      MOV      #5,R4       ;PASS DELAY OF 5 MILLI SECS.
6420 026424 004767 165632      JSR      PC,DELAY    ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
6421
6422
6423
6424 026430 005267 155416      INC      ERRNBR      ;SET ERROR NUMBER TO 5504.
6425 026434 010501                MOV      R5,R1       ;PASS THE LINE NUMBER.
6426 026436 012702 002650      MOV      #BUFBAS,R2  ;PASS THE START OF THE DATA PATTERN TO TX.
6427 026442 012703 000001      MOV      #1,R3       ;PASS THE NUMBER OF CHARACTERS TO TX.
6428 026446 004767 165726      JSR      PC,DODMA    ;TX A NULL CHARACTER TO CAUSE AN XOFF.
6429 026452 103120                BCC      50$         ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6430
6431
6432
6433 026454 005267 155372      INC      ERRNBR      ;SET ERROR NUMBER TO 5505.
6434 026460 012701 170012      MOV      #170012,R1  ;PASS TIME-OUT VALUE OF 10 MILLI SECS.
6435 026464 016702 153536      MOV      CSRA,R2     ;PASS THE ADDRESS OF THE CSR.
6436 026470 004767 170742      JSR      PC,WAIBIS   ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6437 026474 103107                BCC      50$         ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6438 026476 012704 000005      MOV      #5,R4       ;PASS DELAY OF 5 MILLI SECS.
6439 026502 004767 165554      JSR      PC,DELAY    ;WAIT FOR XOFF TO GET INTO THE FIFO.
6440
6441
6442
6443 026506 012702 002650      MOV      #BUFBAS,R2  ;INITIALIZE THE DATA PATTERN TO BE
6444 026512 105022                CLR      (R2),#0     ; ALL NULLS.
6445 026514 020227 003250      CMP      R2,#BUF MID ;
6446 026520 103774                BLO      4$         ;
6447
6448
6449
6450
6451
6452 026522 005267 155324      INC      ERRNBR      ;SET ERROR NUMBER TO 5506.
6453 026526 010501                MOV      R5,R1       ;PASS THE LINE NUMBER.
6454 026530 012702 002650      MOV      #BUFBAS,R2  ;PASS THE START OF THE DATA PATTERN TO TX.
    
```

113

```

6455 026534 012703 000037      MOV    #31.,R3      ;PASS THE LENGTH OF THE DATA PATTERN.
6456 026540 004767 165634      JSR    PC,DODMA    ;TRANSMIT THE DATA PATTERN
6457 026544 103063      BCC    50$         ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6458
6459      ;+
6460      ; WAIT FOR THE XOFF'S AND THE NULL CHARACTERS  TO BE RECEIVED.
6461      ; THERE ARE NOW 255 CHARACTERS IN THE FIFO.
6462 026546 005267 155300      ;-
6463 026552 012701 170454      INC    ERRNBR      ;SET ERROR NUMBER TO 5507.
6464 026556 016702 153444      MOV    #170454,R1  ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6465 026562 004767 170650      MOV    CSRA,R2     ;PASS THE ADDRESS OF THE CSR.
6466 026566 103052      JSR    PC,WAIBIS   ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6467 026570 012704 000005      BCC    50$         ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6468 026574 004767 165462      MOV    #5,R4       ;PASS DELAY OF 5 MILLI SECS.
6469      JSR    PC,DELAY  ;WAIT FOR XOFF TO GET INTO THE FIFO.
6470      ;+
6471      ; READ THE FIFO UNTIL EMPTY. COUNTING THE NUMBER OF XOFF CHARACTERS
6472      ; THAT ARE FOUND.
6473 026600 005004      ;-
6474 026602 005003      CLR    R4          ;CLEAR CHARACTER COUNTER.
6475 026604 012701 170001      CLR    R3          ;CLEAR THE XOFF FOUND COUNTER.
6476 026610 012767 012604 155234 6$:  MOV    #170001,R1  ;INDICATE TO TEST DATA.VALID BIT, TIME-OUT 1MS.
6477 026616 016702 153406      MOV    #5508.,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND THE LOOP.
6478 026622 004767 170610      MOV    RBUFA,R2    ;INDICATE TO CHECK RECEIVE BUFFER REGISTER.
6479 026626 103032      JSR    PC,WAIBIS   ;WAIT FOR RECEIVED CHAR OR TIME-OUT.
6480 026630 005204      BCC    50$         ;GO REPORT ERROR IF FIFO EMPTY.
6481      INC    R4       ;COUNT THE CHARACTER.
6482      ;+
6483      ; CHECK FOR BMP CODES IN THE FIFO. ABORT THE TEST IF ANY ARE FOUND.
6484      ; SAVE THE BMP CODE ON THE QUEUE TO BE REPORTED LATER.
6485 026632 005267 155214      ;-
6486 026636 004767 165134      INC    ERRNBR      ;SET ERROR NUMBER TO 5509.
6487 026642 103422      JSR    PC,CHKBMP   ;CHECK IF WE HAVE GOT A BMP CODE.
6488      BCS    12$     ;GO REPORT THE ERROR IF WE FOUND A BMP CODE.
6489      ;+
6490      ; CHECK FOR XOFF CHARACTER.
6491 026644 122702 000023      8$:  CMPB   #23,R2     ;CHECK IF THE RECEIVED CHARACTER WAS AN XOFF.
6492 026650 001001      BNE    10$         ;BRANCH IF CHARACTER WAS NOT AN XOFF.
6493 026652 005203      INC    R3          ;INCREMENT XOFF FOUND COUNT.
6494      ;+
6495      ; CHECK IF ALL THE CHARACTERS INCLUDING THE XON HAVE BEEN REMOVED.
6496      ;-
6497 026654 020427 000400      10$:  CMP    R4,#256.   ;CHECK IF WE HAVE REMOVED ALL THE CHARACTERS.
6498 026660 002753      BLT    6$         ;GO GET THE NEXT CHAR IF WE HAVE NOT FINISHED.
6499
6500      ;+
6501      ; CHECK IF THE CORRECT NUMBER OF XOFF'S WERE FOUND IN THE FIFO.
6502      ; REPORT ERROR IF COUNT IS INCORRECT.
6503      ;-
6504 026662 012767 012606 155162      MOV    #5510.,ERRNBR ;SET UP THE ERROR NUMBER TO 5510.
6505 026670 022703 000040      CMP    #32.,R3     ;COMPARE EXPECTED XOFF COUNT WITH ACTUAL COUNT.
6506 026674 001411      BEQ    60$         ;EXIT TEST IF SUCCESS.
6507 026676 012767 011762 155152      MOV    #E0503,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
6508 026704 012701 006520      MOV    #E5402,R1   ;PASS THE MESSAGE TO BE REPORTED.
6509      ;REPORT THE ERROR "FIFO BAD, ALARM SIGNAL DEFECTIVE".
6510 026710 104460      12$:  ERROR  ;
        >>>> ERROR <<<<<.
        TRAP    C$ERROR
    
```

6511	026712	000402			BR	60\$;ABORT THE TEST.
6512								
6513	026714	004767	167752	50\$:	JSR	PC,TSABRT		;REPORT TEST ABORTED. ERROR # SHOWS REASON.
6514	026720	005067	153324	60\$:	CLR	CTRLCF		;INDICATE THAT WE ARE NOT WITHIN A TEST.
6515								
6516	026724				ENDTST			
	026724							
	026724	104401						
							L10040:	TRAP C#ETST

6518
6519
6520
6521
6522
6523
6524
6525
6526
6527
6528
6529
6530
6531
6532 026726
026726
6533 026726 012700 000240
026726 104441
026732
6534 000014
6535 026734 012767 000014 153312
6536 026742 012767 177777 153300
6537 026750 012767 000001 155072
6538 026756 012767 012741 155066
6539 026764 012767 006625 155062
6540
6541
6542
6543
6544
6545 026772 004767 165220
6546 026776 103402
6547 027000 000167 000412
6548 027004
6549
6550
6551
6552 027004 004767 165460
6553 027010 103402
6554 027012 000167 000400
6555
6556
6557
6558
6559
6560 027016 004767 165556
6561
6562
6563
6564
6565
6566
6567
6568
6569 027022 005267 155024
6570 027026 012700 000206
6571 027032 004767 170514

```

.SBTTL  HARDWARE TEST          - FI3QAI -
;*****
; - FIFO 3/4 ALARM LEVEL ACTIVE/INACTIVE TEST -
;
; THIS TEST VERIFIES THAT THE DUT'S FIFO 3/4 LEVEL ALARM SYSTEM
; BECOMES ACTIVE AND INACTIVE AT THE CORRECT LEVELS.
; ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
; HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
; REPORTED LATER.
; THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
; INTERNAL LOOPBACK MODE.
;*****
;-----
BGNTST
                                T12::
6533  SETPRI  #PRI05              ;ALLOW LTC INTERRUPTS.
                                MOV  #PRI05,R0
                                TRAP C$SPRI
6534  TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER
6535  MOV  #TNUM,TSTNUM        ;SET UP THE TEST NUMBER. (56)
6536  MOV  #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
6537  MOV  #1,ERRTYP           ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6538  MOV  #5601,ERRNBR        ;SET ERROR NUMBER TO 5601.
6539  MOV  #EMS601,ERRMSG      ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
;
; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 5601 <<<<.
;
;
; JSR  PC,CLNRST              ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
; BCS  2$                     ;SKIP EXITING TEST A SUCCESSFUL RESET.
; JMP  60$                     ;EXIT THIS TEST.
2$:
;
; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
;
; JSR  PC,FINACT              ;FIND AN ACTIVE LINE.
; BCS  .+6                     ;SKIP EXIT OF TEST IF ACTIVE LINE FOUND.
; JMP  60$                     ;EXIT TEST.
;
; INITIALIZE THE 256 BYTE DATA PATTERN.
; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
;
; JSR  PC,INDTPX              ;INITIALISE THE DATA PATTERN.
;
; TRANSMIT A 256 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
;
;
; SET INTERNAL LOOPBACK, ENABLE IAUTO AND RECEIVER ON THE SELECTED LINE.
; TRANSMIT THE FIRST 191 CHARACTERS ON THE FIRST AVAILABLE ACTIVE LINE.
;
; INC  ERRNBR                  ;SET ERROR NUMBER TO 5602.
; MOV  #206,R0                 ;PASS INTERNAL LOPBCK, ENABLE RX AND IAUTO.
; JSR  PC,WTWLNCR              ;INITILAISE THE LINE CONTROL REGISTER.

```

6572	027036	012700	177670	MOV	#177670,R0	;PASS THE LPR CONTENTS.
6573	027042	004767	170534	JSR	PC,WTMLPR	;SET THE LPR CONTENTS TO 38.4K BAUD.
6574	027046	012704	000012	MOV	#10.,R4	;PASS DELAY TIME OF 10 MILLI SECONDS.
6575	027052	004767	165204	JSR	PC,DELAY	;WAIT FOR LNCtrl AND LPR REGS TO BE UPDATED.
6576	027056	010105		MOV	R1,R5	;COPY THE LINE NUMBER.
6577	027060	012702	002650	MOV	#BUFBA5,R2	;PASS THE START OF THE DATA PATTERN TO TX.
6578	027064	012703	000277	MOV	#191.,R3	;PASS THE LENGTH OF THE DATA PATTERN.
6579	027070	004767	165304	JSR	PC,DDDMA	;TRANSMIT THE DATA PATTERN.
6580	027074	103146		BCC	S01	;EXIT IF ERROR FOUND DURING DMA TX.
6581						
6582						
6583						
6584						
6585	027076	005267	154750	INC	ERRNBR	;SET ERROR NUMBER TO 5603.
6586	027102	012701	170454	MOV	#170454,R1	;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6587	027106	016702	153114	MOV	CSRA,R2	;PASS THE ADDRESS OF THE CSR.
6588	027112	004767	170320	JSR	PC,WAIBIS	;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
6589	027116	103135		BCC	S01	;BRANCH IF FIFO EMPTY, ABORT THE TEST.
6590	027120	012704	000005	MOV	#5,R4	;PASS DELAY OF 5 MILLI SECS.
6591	027124	004767	165132	JSR	PC,DELAY	;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
6592						
6593						
6594						
6595						
6596	027130	005267	154716	INC	ERRNBR	;SET ERROR NUMBER TO 5604.
6597	027134	010501		MOV	R5,R1	;PASS THE LINE NUMBER.
6598	027136	012702	002650	MOV	#BUFBA5,R2	;PASS THE START OF THE DATA PATTERN TO TX.
6599	027142	012703	000001	MOV	#1,R3	;PASS THE NUMBER OF
6600	027146	004767	165226	JSR	PC,DDDMA	;TX A NULL CHARACTER TO CAUSE AN XOFF.
6601	027152	103117		BCC	S01	;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6602						
6603						
6604						
6605	027154	005267	154672	INC	ERRNBR	;SET ERROR NUMBER TO 5605.
6606	027160	012701	170012	MOV	#170012,R1	;PASS TIME-OUT VALUE OF 10 MILLI SECS.
6607	027164	016702	153036	MOV	CSRA,R2	;PASS THE ADDRESS OF THE CSR.
6608	027170	004767	170242	JSR	PC,WAIBIS	;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
6609	027174	103106		BCC	S01	;IF NO TX ACTION WAS RECEIVED, ABORT THE TEST.
6610	027176	012704	000005	MOV	#5,R4	;PASS DELAY OF 5 MILLI SECS.
6611	027202	004767	165054	JSR	PC,DELAY	;WAIT FOR XOFF TO GET INTO THE FIFO.
6612						
6613	027206	010577	153014	MOV	R5,BCSRA	;SELECT THE LINE READY FOR TRANSMISSION.
6614						
6615						
6616						
6617						
6618						
6619						
6620	027212	005005		CLR	R5	;CLEAR THE TX FLAG.
6621	027214	005004		CLR	R4	;CLEAR THE CHARACTER COUNTER.
6622	027216	012703	000300	MOV	#192.,R3	;SET UP READ COUNTER FOR THE FIRST 192 CHARS.
6623						
6624	027222	012700	000003	MOV	#3,R0	;SET READ COUNTER.
6625	027226	012701	170005	MOV	#170005,R1	;INDICATE TO TEST DATA VALID BIT, TIME-OUT 5MS.
6626	027232	016702	152772	MOV	RBUFA,R2	;INDICATE TO CHECK RECEIVE BUFFER REGISTER.
6627	027236	004767	170174	JSR	PC,WAIBIS	;WAIT FOR RECEIVED CHAR OR TIME-OUT.
6628	027242	103046		BCC	141	;EXIT LOOP IF TIME OUT, FIFO EMPTY.

```

6629 027244 005300          DEC R0          ;DECREMENT READ COUNTER.
6630 027246 005303          DEC R3          ;DECREMENT CHAR COUNTER.
6631 027250 005002          BGT 81          ;SKIP DISBL'G TX IF FIRST 192 CHARS NOT READ.
6632 027252 052705 100000  BIS #BIT15,R5   ;DISABLE ANY FURTHER TRANSMISSIONS.
6633
6634          ;
6635          ; CHECK IF THE READ CHARACTER IS A BMP CODE.
6636          ; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
6637          ; ABORT THE TEST.
6638 027256 012767 012746 154566 81:  MOV #5606,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
6639 027264 004767 164506          JSR PC,CHKBMP   ;CHECK IF CHARACTER IS A BMP CODE.
6640 027270 103446          BCS 168         ;GO REPORT ERROR AND ABORT TEST IF BMP FOUND.
6641
6642          ;
6643          ; CHECK FOR XOFF CHARACTER. IF ONE IS FOUND, COUNT IT.
6644          ; TRANSMIT A NULL CHARACTER UNTIL THE FIRST 192 CHARS HAVE BEEN READ.
6645 027272 122702 000023 108:  CMPR #23,R2     ;CHECK IF THE RECEIVED CHARACTER WAS AN XOFF.
6646 027276 001001          BNE 128         ;BRANCH IF CHARACTER WAS NOT AN XOFF.
6647 027300 005204          INC R4          ;INCREMENT THE XOFF CHAR FOUND COUNTER.
6648
6649 027302 005700          128:  TST R0          ;CHECK READ COUNT, TO SEE IF A CHAR CAN BE TX.
6650 027304 001350          BNE 68          ;BRANCH IF 3 CHARS HAVE NOT YET BEEN READ.
6651 027306 005705          TST R5          ;CHECK THE TRANSMISSION ENABLED FLAG.
6652 027310 100744          BMI 48          ;SKIP TRANSMITTING A CHARACTER IF TX DISABLED.
6653 027312 112777 000000 152714  MOVB #0,BFDATA ;TX A NULL CHARACTER.
6654 027320 010446          MOV R4,-(SP)    ;SAVE THE XOFF COUNT ON THE STACK.
6655
6656          ;
6657          ; WAIT FOR THE CHARACTER TO BE RECEIVED BEFORE CONTINUING THE TEST.
6658 027322 005267 154524          INC ERRNBR      ;SET ERROR NUMBER TO 5607.
6659 027326 012701 170012          MOV #170012,R1 ;PASS TIME-OUT VALUE OF 10 MILLI SECS.
6660 027332 016702 152670          MOV CSRA,R2    ;PASS THE ADDRESS OF THE CSR.
6661 027336 004767 170074          JSR PC,WAITBIS ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6662 027342 103023          BCC 508        ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6663 027344 012704 000005          MOV #5,R4      ;PASS DELAY OF 5 MILLI SECS.
6664 027350 004767 164706          JSR PC,DELAY   ;WAIT FOR XOFF TO GET INTO THE FIFO.
6665 027354 012604          MOV (SP),R4    ;RESTORE THE XOFF COUNT.
6666 027356 000721          BR 48          ;GO RESET THE READ COUNT AND GET NEXT CHAR.
6667
6668          ;
6669          ;
6670          ; CHECK IF THE CORRECT NUMBER OF XOFF'S WERE FOUND IN THE FIFO
6671          ; REPORT ERROR IF COUNT IS INCORRECT.
6672 027360 012767 012750 154464 148:  MOV #5608,ERRNBR ;SET ERROR NUMBER TO 5608.
6673 027366 020427 000077          CMP R4,#63     ;COMPARE THE EXPECTED AND ACTUAL XOFF COUNTS.
6674 027372 001411          BEQ 608        ;EXIT TEST IF SUCCESS.
6675 027374 012767 011762 154454  MOV #ER0503,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
6676 027402 012701 006520          MOV #EM5402,R1 ;PASS THE MESSAGE TO BE REPORTED.
6677          ;REPORT THE ERROR "FIFO BAD, ALARM SIGNAL DEFECTIVE".
6678 027406          168:  ERROR          ;
6679 027410 104460          BR 608         ;EXIT THIS TEST.
6680
6681 027412 004767 167254 508:  JSR PC,TSABRT  ;REPORT TEST ABORTED. ERROR # INDICATES FAULT.
6682 027416 005067 152626 608:  CLR CTRLCF     ;INDICATE THAT WE ARE NOT WITHIN A TEST.
6683
6684 027422          ENDTST
    
```

027422
027422 104401

L10041: TRAP C0ETST

```

6686 .SBTTL HARDWARE TEST - FIMAVL -
6687 ;*****
6688 ; - FIFO HALF LEVEL ACTIVE/INACTIVE TEST
6689 ;
6690 ; THIS TEST CHECKS THAT THE DUT'S FIFO HALF LEVEL ALARM SYSTEM
6691 ; BECOMES ACTIVE AND INACTIVE AT THE CORRECT LEVELS.
6692 ; ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
6693 ; HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
6694 ; REPORTED LATER.
6695 ; THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
6696 ; INTERNAL LOOPBACK MODE.
6697 ;
6698 ;-----
6699
6700 BGNTST
6701 027424 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS. T13::
        027424 012700 000240 MOV #PRI05,R0
        027430 104441 TRAP C#SPRI
6702 5702 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6703 027432 012767 000015 152614 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (57)
6704 027440 012767 177777 152602 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
6705 027446 012767 000001 154374 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6706 027454 012767 013105 154370 MOV #5701,ERRNBR ;SET ERROR NUMBER TO 5701.
6707 027462 012767 006702 154364 MOV #EM5701,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
6708 027470 012767 011762 154360 MOV #ER0503,ERRBLK ;SELECT THE ERROR REPORTING ROUTINE.
6709 ;
6710 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
6711 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6712 ; THIS SUBROUTINE REPORTS ERROR >>>> 5701 <<<<<.
6713 ;
6714 027476 004767 164514 JSR PC,CLRST ;RESET THE DHU-11. REPORT ANY ERRORS FOUND.
6715 027502 103402 BCS 2# ;SKIP EXITING TEST A SUCCESSFUL RESET.
6716 027504 000167 000364 JMP 60# ;EXIT THIS TEST.
6717 027510
6718 2#::
6719 ;
6720 ; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
6721 027510 004767 164754 JSR PC,FINACT ;FIND AN ACTIVE LINE.
6722 027514 103167 BCC 60# ;EXIT IF NO ACTIVE LINES AVAILABLE.
6723 ;
6724 ; INITIALIZE THE 256 BYTE DATA PATTERN.
6725 ; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
6726 ; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
6727 ;
6728 027516 004767 165056 JSR PC,INDTPX ;INITIALISE THE DATA PATTERN.
6729 ;
6730 ; FILL THE FIFO AND THE UART'S 3 CHAR BUFFER BY TRANSMITTING 225 CHARS
6731 ; (IE 225 + 34 XOFF'S). TRANSMIT DATA PATTERN USING DMA, ON A SINGLE CHANNEL
6732 ; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
6733 ;
6734 ;
6735 ; SET INTERNAL LOOPBACK, ENABLE IAUTO AND RECEIVER ON THE SELECTED LINE.
6736 ; TRANSMIT THE 225 CHARACTERS ON THE FIRST AVAILABLE ACTIVE LINE.
6737 ;
6738 027522 005267 154324 INC ERRNBR ;SET ERROR NUMBER TO 5702.
6739 027526 004767 167014 JSR PC,SETPAR ;SET UP PARAMETERS FOR TRANSMISSION.
    
```

```

6740 027532 012700 000341      MOV    #225.,R0      ;PASS LENGTH OF DATA PATTERN.
6741 027536 004767 167242      JSR    PC,TXDATP    ;TRANSMIT DATA PATTERN.
6742 027542 103152          BCC    50$          ;EXIT IF ERROR FOUND DURING TX.
6743 027544 010105          MOV    R1,R5        ;COPY THE LINE NUMBER.
6744
6745      ;*
6746      ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
6747      ; THE FIFO.
6748 027546 005267 154300      INC    ERRNBR       ;SET ERROR NUMBER TO 5703.
6749 027552 004767 167734      JSR    PC,WAITTX    ;WAIT FOR TRANSMISSION TO COMPLETE.
6750 027556 103144          BCC    50$          ;GO REPORT ERROR IF TX FAILED TO COMPLETE.
6751
6752      ;*
6753      ; READ THE FIRST 130 CHARACTERS FROM THE FIFO, IF ANY XON'S ARE FOUND
6754      ; REPORT THE ERROR. IF ANY BMP CODES ARE FOUND THEN SAVE THEM ON THE QUEUE
6755      ; AND ABORT THE TEST.
6756 027560 005267 154266      INC    ERRNBR       ;SET ERROR NUMBER TO 5704.
6757 027564 012700 000202      MOV    #130.,R0    ;PASS THE NUMBER OF CHARS TO READ.
6758 027570 004767 166060      JSR    PC,READBX    ;READ THE FIRST 130 CHARS FROM THE FIFO.
6759 027574 103135          BCC    50$          ;GO REPORT ERROR IF BMP CODE FOUND.
6760 027576 005267 154250      INC    ERRNBR       ;SET ERROR NUMBER TO 5705.
6761 027602 005701          TST    R1           ;CHECK IF AN XON WAS FOUND.
6762 027604 001125          BNE    30$          ;GO REPORT ERROR IF AN XON WAS FOUND.
6763
6764
6765      ;*
6766      ; TRANSMIT A NULL CHARACTER (WHICH CAUSES AN XOFF TO BE GENERATED).
6767 027606 010577 152414      MOV    R5,BCSRA     ;SELECT THE LINE READY FOR TRANSMISSION.
6768 027612 112777 000000 152414      MOVB   #0,$FDATA    ;TRANSMIT A NULL CHARACTER.
6769 027620 005267 154226      INC    ERRNBR       ;SET ERROR NUMBER TO 5706.
6770 027624 004767 167662      JSR    PC,WAITTX    ;WAIT FOR TX TO COMPLETE.
6771 027630 103117          BCC    50$          ;GO REPORT ERROR IF TX DID NOT COMPLETE.
6772
6773      ;*
6774      ; READ THREE CHARACTERS, TO CAUSE THE XON TO BE GENERATED.
6775 027632 005267 154214      INC    ERRNBR       ;SET ERROR NUMBER TO 5707.
6776 027636 012700 000003      MOV    #3,R0        ;SET THE READ COUNT TO 3.
6777 027642 004767 166006      JSR    PC,READBX    ;READ 3 CHARACTERS FROM THE FIFO.
6778 027646 103110          BCC    50$          ;GO REPORT ERROR IF FIFO EMPTY.
6779 027650 005267 154176      INC    ERRNBR       ;SET ERROR NUMBER TO 5708.
6780 027654 005701          TST    R1           ;CHECK IF AN XON WAS FOUND.
6781 027656 001102          BNE    40$          ;GO REPORT ERROR IF AN XON WAS FOUND.
6782
6783      ;*
6784      ; TRANSMIT 62 CHARACTERS TO BRACKET THE XON AND FILL THE FIFO WITH 191 CHARS.
6785 027660 012700 000076      MOV    #62.,R0     ;PASS LENGTH OF DATA PATTERN.
6786 027664 010501          MOV    R5,R1        ;PASS THE LINE NUMBER.
6787 027666 005267 154160      INC    ERRNBR       ;SET ERROR NUMBER TO 5709.
6788 027672 004767 167106      JSR    PC,TXDATP    ;TRANSMIT DATA PATTERN.
6789 027676 103074          BCC    50$          ;EXIT IF ERROR FOUND DURING TX.
6790
6791
6792      ;*
6793      ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
6794      ; THE FIFO.
6795 027700 005267 154146      INC    ERRNBR       ;SET ERROR NUMBER TO 5710.
6796 027704 004767 167602      JSR    PC,WAITTX    ;WAIT FOR TX TO COMPLETE.

```

014

```

6797 027710 103067          BCC 50$          ;GO REPORT ERROR IF TX FAILED TO COMPLETE.
6798
6799          ;*
6800          ; READ THE FIRST 126 CHARACTERS.
6801          ; READ THE NEXT 4 CHARACTERS AND CHECK IF THEY ARE IN THE FOLLOWING ORDER
6802          ; NULL, XOFF, XON, NULL.
6803          ;-
6803 027712 005267 154134      INC  ERRNBR          ;SET ERROR NUMBER TO 5711.
6804 027716 012700 000176      MOV  #126.,R0        ;SET UP READ COUNTER.
6805 027722 004767 165726      JSR  PC,READBX      ;READ THE FIRST 126 CHARS.
6806 027726 103060          BCC 50$          ;GO REPORT THE ERROR IF FIFO EMPTY.
6807 027730 005267 154116      INC  ERRNBR          ;SET ERROR NUMBER TO 5712.
6808 027734 005701          TST  R1             ;CHECK IF AN XON WAS FOUND.
6809 027736 001052          BNE  40$          ;GO REPORT ERROR IF AN XON WAS FOUND.
6810 027740 005267 154106      INC  ERRNBR          ;SET ERROR NUMBER TO 5713.
6811 027744 012701 006520      MOV  #EMS402,R1     ;PASS THE MESSAGE TO BE REPORTED.
6812 027750 016703 152254      MOV  RBUFA,R3       ;GET THE RECEIVER BUFFER ADDRESS.
6813 027754 011302          MOV  (R3),R2        ;READ THE NULL CHARACTER FROM THE FIFO.
6814 027756 120227 000000      CMPB R2,#000       ;CHECK IF IT IS A NULL CHARACTER.
6815 027762 001040          BNE  40$          ;GO REPORT THE ERROR IF NOT THE SAME.
6816 027764 005267 154062      INC  ERRNBR          ;SET ERROR NUMBER TO 5714.
6817 027770 011302          MOV  (R3),R2        ;READ THE XOFF FROM THE FIFO.
6818 027772 120227 000023      CMPB R2,#23        ;CHECK IF THE READ CHAR IS AN XOFF.
6819 027776 001032          BNE  40$          ;GO REPORT THE ERROR IF NOT THE SAME.
6820 030000 011302          MOV  (R3),R2        ;READ THE XON FROM THE FIFO.
6821 030002 005267 154044      INC  ERRNBR          ;SET ERROR NUMBER TO 5715.
6822 030006 120227 000021      CMPB R2,#21        ;CHECK IF THE READ CHARACTER IS AN XON.
6823 030012 001024          BNE  40$          ;GO REPORT THE ERROR IF NOT THE SAME.
6824 030014 005267 154032      INC  ERRNBR          ;SET ERROR NUMBER TO 5716.
6825 030020 011302          MOV  (R3),R2        ;READ THE NULL CHARACTER FROM THE FIFO.
6826 030022 120227 000000      CMPB R2,#000       ;CHECK IF IT IS A NULL CHARACTER.
6827 030026 001016          BNE  40$          ;GO REPORT THE ERROR IF NOT THE SAME.
6828
6829
6830          ;*
6831          ; READ THE REMAINING CHARACTERS FROM THE FIFO.
6832          ;-
6832 030030 012700 000075      6$:  MOV  #61.,R0        ;SET UP READ COUNTER.
6833 030034 005267 154012      INC  ERRNBR          ;SET ERROR NUMBER TO 5717.
6834 030040 004767 165610      JSR  PC,READBX      ;READ THE FIRST 61 CHARS.
6835 030044 103011          BCC 50$          ;GO REPORT THE ERROR IF FIFO EMPTY.
6836 030046 005267 154000      INC  ERRNBR          ;SET ERROR NUMBER TO 5718.
6837 030052 005701          TST  R1             ;CHECK IF AN XON WAS FOUND.
6838 030054 001003          BNE  40$          ;GO REPORT ERROR IF AN XON WAS FOUND.
6839 030056 000406          BR   60$          ;EXIT THE TEST.
6840 030060 012701 006520      30$: MOV  #EMS402,R1     ;SET UP THE MESSAGE
6841          ; "FIFO ALARM SIGNAL DEFECTIVE".
6842 030064          40$: ERROR          ;          >>>> ERROR <<<<<
6843 030066 104460          BR   60$          ;EXIT THE TEST.
6844 030066 000402          TRAP C$ERROR
6845 030070 004767 166576      50$: JSR  PC,TSABRT     ;REPORT TEST ABORTED. ERROR # INDICATES FAULT.
6846 030074 005067 152150      60$: CLR  CTRLCF      ;INDICATE THAT WE ARE NOT WITHIN A TEST.
6847
6848          ENDTST
030100
030100 104401          L10042: TRAP C$ETST
    
```

```

6850 .SBTTL HARDWARE TEST RXTIMER
6851 ;* *****
6852 ;* - RXTIMER REG TEST -
6853 ;* THIS TEST VERIFIES THAT THE RXTIMER DELAYS ANY RX-INTS BY THE
6854 ;* REQUESTED AMOUNT AND THAT WHEN THE RXFIFO IS MORE THAN 3/4 FULL
6855 ;* THE RXTIMER VALUE IS IGNORED AND AN INTERRUPT OCCURS IMMEDIATELY.
6856 ;* DUE TO THE DIFFERANCES IN LTC HANDLING OF DIFFERENT VERSIONS OF
6857 ;* THE DRS AND LTC AVAILABILITY ON DIFFERENT PDP-11 MACHINES THE
6858 ;* RX-INT CAN ONLY BE TIMED TO WITHIN +/- 20% OF THE RXTIMER VALUE.
6859 ;* THIS TEST IS PERFORMED IN INTERNAL LOOPBACK ON THE FIRST ACTIVE LINE.
6860 ;*
6861 ;* *****
6862
6863 030102 BGNST
        030102
6864 030102 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS. T14::
        030102 012700 000240
        030106 104441
        030106 104441 MOV #PRI05,R0
        030106 000016 TRAP C$SPRI
6865 TNUM == TNUM + 1 ;INCREMENT ASSEMBLY TIME TEST COUNTER
6866 030110 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER.
        030110 012767 000016 152136
6867 030116 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
        030116 012767 177777 152124
6868 030124 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
        030124 012767 000001 153715
6869 030132 MOV #5801,ERRNBR ;SET THE ERROR NUMBER TO 5801.
        030132 012767 013251 153712
6870 030140 MOV #EMS801,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
        030140 012767 006757 153706
6871 030146 CLR EXOERR ;CLEAR THE "EXIT ON ERROR" FLAG.
6872
6873 ;*
6874 ;* RESET THE DEVICE AND LEAVE THE SELFTEST CODES IN THE FIFO.
6875 030152 JSR PC,RESETT ;RESET THE DUT.
        030152 004767 166124
6876 030156 BCS .+6 ;CONTINUE IF FIFO PURGED
        030156 103402
6877 030160 JMP 60$ ;REPORT THE RESET FAILURE.
        030160 000167 000732
6878
6879 ;*
6880 ;* SET UP THE INTERRUPT SERVICE ROUTINE THAT DETECTS THE RX-INT.
6881 030164 SETVEC RXVECA,#RXDECT,#PRI06
        030164 012746 000300
        030170 012746 017702 MOV #PRI06,(SP)
        030174 016746 152014 MOV #RXDECT,(SP)
        030200 012746 000003 MOV RXVECA,(SP)
        030204 104437 TRAP C$SVEC
        030206 062706 000010 ADD #10,SP
6882 030212 SETPRI #PRI04 ;ALLOW DEVICE INTERRUPTS.
        030212 012700 000200 MOV #PRI04,R0
        030216 104441 TRAP C$SPRI
6883 030220 CLR RXINTC ;CLEAR THE RX-INT COUNT.
        030220 005067 152042
6884
6885 ;*
6886 ;* ENABLE RX-INTS AND WAIT FOR ONE TO OCCUR.
6887 030224 JSR PC,RXIE1 ;ENABLE RX-INTS.
        030224 004767 166224
6888 030230 MOV #5,R4 ;SET THE DELAY OF 5 MILLI SECS.
        030230 012704 000005
6889 030234 JSR PC,DELAY ;DELAY WHILE THE INT OCCURS.
        030234 004767 164022
6890 030240 JSR PC,RXIE0 ;DISABLE RX-INTS.
        030240 064767 166150
6891 030244 INC ERRNBR ;SET THE ERROR NUMBER TO 5802.
        030244 005267 153602
6892 030250 TST RXINTC ;TEST IF AN INTERRUPT OCCURED.
        030250 005767 152012
6893 030254 BNE .+6 ;CONTINUE IF AN INTERRUPT OCCURED.
        030254 001002
6894 030256 JMP 50$ ;REPORT THE ERROR IF NO INTERRUPT.
        030256 000167 000630
6895
    
```



```

6896 ; SET INTERNAL LOOPBACK ON THE FIRST ACTIVE LINE AND ENABLE RECIEVERS. SET UP
6897 ; THE LPR'S TO 38.4K BAUD, 8 BITS/CHARA, ODD PARITY, 2 STOP BITS.
5898 ;
6899 030262 004767 164202 JSR PC,FINACT ;FIND AN ACTIVE LINE FOR THIS TEST.
6900 030266 103402 BCS .+6 ;CONTINUE IF A LINE HAS BEEN FOUND.
6901 030270 000167 000622 JMP 604 ;EXIT THE TEST IF NO LINES ACTIVE.
6902 030274 012700 000204 MOV #204,R0 ;PASS PARAMETER FOR INTERNAL LOOPBACK,
;ENABLE RECIEVERS.
6903 JSR PC,WTWLNLC ;INITIALISE THE LINE CONTROL REGS.
6904 030300 004767 167246 MOV #177670,R0 ;PASS THE LPR CONTENTS.
6905 030304 012700 177670 JSR PC,WTWLPR ;SET THE LPR'S TO 38.4K BAUD.
6906 030310 004767 167265 MOV #10.,R4 ;PASS DELAY TIME OF 10 MILLI SECS.
6907 030314 012704 000012 JSR PC,DELAY ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
6908 030320 004767 163736 ;
6909 ;
6910 ; SET UP THE LOOP TO TEST THE RXTIMER WITH DELAYS OF 15,31,63,127 AND 255 MS.
6911 ; DMA 191 CHARACTERS INTO THE FIFO AND THEN ENABLE INTERRUPTS, VERIFY THAT
6912 ; THE INTERRUPT OCCURS WITHIN +/- 20% OF THE RXTIMER VALUE.
6913 ;
6914 030324 010167 000616 MOV R1,704 ;SAVE THE LINE NUMBER.
6915 030330 012705 000020 MOV #16.,R5 ;SET THE FIRST (RXTIMER VALUE + 1).
6916 030334 012767 013253 153510 24: MOV #5803.,ERRNBR ;SET THE ERROR NUMBER TO 5803.
6917 030342 004767 165022 JSR PC,PUFIFO ;PURGE THE RXFIFO.
6918 030346 103402 BCS .+6 ;CONTINUE IF SUCCESSFUL.
6919 030350 000167 000536 JMP 504 ;REPORT THE ERROR IF FIFO FAILED TO PURGE.
6920 030354 016701 000566 MOV 704.,R1 ;PASS THE LINE NUMBER.
6921 030360 012703 000277 MOV #191.,R3 ;PASS THE NUMBER OF CHARS TO DMA.
6922 030364 005267 153462 INC ERRNBR ;SET THE ERROR NUMBER TO 5804.
6923 030370 004767 163726 JSR PC,DMABUF ;PERFORM THE DMA FROM ADDR #BUFBA5.T.:IS SUBR
;PRODUCES ERRORS >>>> 5804 THRU 5805 <<<<.
6924 BCS .+6 ;CONTINUE IF SUCCESSFUL.
6925 030374 103402 JMP 504 ;REPORT THE ERROR IF ONE OCCURED.
6926 030376 000167 000510 ;
6927 ;
6928 ; CALCULATE THE TIME-OUT VALUE FOR THE RX-INT, SET UP THE RXTIMER, AND
6929 ; WAIT FOR THE RX-INT.
6930 ;
6931 030402 010501 MOV R5,R1 ;COPY THE RXTIMER VALUE + 1.
6932 030404 006301 ASL R1 ; MULTIPLY BY 4 TO OBTAIN,
6933 030406 006301 ASL R1 ;THE TIME-OUT FOR THE RX-INT.
6934 030410 105077 151612 CLR8 #CSRA ;CLEAR THE IND.ADDR.REG BITS OF THE CSR READY,
;FOR THE WRITE TO THE RXTIMER REG.
6935 MOV R5,R0 ;COPY THE RXTIMER VALUE +1.
6936 030414 010500 DEC R0 ;GET THE RXTIMER VALUE
6937 030416 005300 MOV8 R0,#RXTMA ;LOAD THE RXTIMER REG.
6938 030420 110077 151604 MOV #2,R4 ;SET DELAY OF 2 MS.
6939 030424 012704 000002 JSR PC,DELAY ;DELAY TO ALLOW THE RXTIMER VALUE TO UPDATE.
6940 030430 004767 163626 MOV #BIT0,R2 ;INDICATE TO TEST BIT0.
6941 030434 012702 000001 MOV R2,R3 ;INDICATE TO TEST FOR A "1".
6942 030440 010203 MOV #RXINTC,R4 ;PASS ADDR OF WORD TO TEST.
6943 030442 012704 002266 CLR RXINTC ;CLEAR THE RX-INT COUNT.
6944 030446 005067 151614 MOV #BIT06,IESTAT ;SET THE RX-INT-ENBL BIT IN IESTAT.
6945 030452 012767 000100 151576 MOV IESTAT,#CSRA ;ENABLE RX-INTS.
6946 030460 016777 151572 151540 JSR PC,MSLGET ;WAIT FOR THE INT TO OCCUR.
6947 030466 004767 164236 BCS 4 ;AVOID ERROR REPORT IF THE INTERRUPT OCCURED.
6948 030472 103415 ;
6949 ;
6950 ; REPORT THE TIME-OUT ERROR. >>>> 5806 <<<<.
6951 ;
6952 030474 010502 MOV R5,R2 ;PASS THE RXTIMER VALUE TO.
    
```

J14

```

6953 030476 005302          DEC      R2          ;THE ERROR REPORTING ROUTINE.
6954 030500 012701 007265  MOV      #EM5805,R1   ;PASS THE MESSAGE,
6955                                     ; "RXTIMER BAD, TIME-OUT OCCURED WAITING FOR
6956                                     ; THE RX-INT".
6957
6958 030504          ERRDF   5806,EM5801,ER5801 ;REPORT ERROR 5806.
      030504 104455
      030506 013256          TRAP   C#ERDF
      030510 006757          .WORD  5806
      030512 012112          .WORD  EM5801
      .WORD  ER5801
6959
6960 030514 032767 000100 151466  BIT      #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
6961 030522 001575          BEQ      60#          ;EXIT THE TEST IF IT HASN'T.
6962 030524 000454          BR       6#          ;BRANCH TO TEST ANOTHER RXTIMER VALUE.
6963
6964                                     ;+
6965                                     ; CHECK THAT THE INTERRUPT OCCURED WITHIN +/- 20% OF THE RXTIMER VALUE.
6966                                     ; THIS SUBROUTINE REPORTS ERROR >>>> 5807 <<<<.
6967
6967 030526 012767 013257 153316 4#:  MOV      #5807.,ERRNBR ;SET THE ERROR NUMBER TO 5807.
6968 030534 010502          MOV      R5,R2      ;PASS THE RXTIMER VALUE TO,
6969 030536 005302          DEC      R2          ;THE "CHECK TIME" SUBR.
6970 030540 004767 163302  JSR      PC,CKRXTM   ;CHECK THE TIME TAKEN AND REPORT ANY ERROR.
6971 030544 005767 151502  TST      EXOERR      ;TEST THE "EXIT ON ERROR" FLAG.
6972 030550 001162          BNE     60#          ;EXIT IF SET.
6973 030552 004767 165636  JSR      PC,RXIE0    ;DISABLE RX-INTS.
6974
6975                                     ;+
6976                                     ; DMA ANOTHER CHARACTER TO FILL THE FIFO TO THE 75% LEVEL, AND CHECK THAT THE
6977                                     ; RX-INT OCCURS IMMEDIATELY.
6978
6978 030556 016701 000364          MOV      70#,R1     ;PASS THE LINE NUMBER.
6979 030562 012703 000001  MOV      #1,R3      ;PASS THE NUMBER OF CHARS TO DMA.
6980 030566 005267 153260  INC      ERRNBR     ;SET THE ERROR NUMBER TO 5808.
6981 030572 004767 163524  JSR      PC,DMABUF   ;PERFORM THE DMA FROM ADDR #BUFBAS,THIS SUBR
6982                                     ; PRODUCES ERRORS >>>> 5808 THRU 5809 <<<<.
6983 030576 103145          BCC     50#          ;REPORT THE ERROR IF ONE OCCURED.
6984 030600 005067 151462  CLR      RXINTC     ;CLEAR THE RX-INT COUNT.
6985 030604 012701 000005  MOV      #5,R1      ;SET THE TIME-OUT TO 5 MS.
6986 030610 012702 002266  MOV      #RXINTC,R2 ;PASS ADDR OF WORD TO TEST.
6987 030614 004767 165634  JSR      PC,RXIE1   ;ENABLE INTERRUPTS.
6988 030620 004767 166612  JSR      PC,WAIBIS   ;WAIT FOR THE INT TO OCCUR.
6989 030624 103414          BCS     6#          ;AVOID THE ERROR IF AN INTERRUPT OCCURED.
6990
6991                                     ;+
6992                                     ; REPORT THE ERROR, RX-INT DID NOT OCCUR IMMEDIATELY >>>> 5810 <<<<.
6993
6993 030626 010502          MOV      R5,R2      ;PASS THE RXTIMER VALUE.
6994 030630 005302          DEC      R2
6995 030632 012701 007077  MOV      #EM5803,R1 ;PASS THE MESSAGE,
6996                                     ; "RXTIMER BAD, RX-INT DID NOT OCCUR
6997                                     ; IMMEDIATELY WHEN RXFIFO 3/4 FULL".
6998
6999 030636          ERRDF   5810,EM5801,ER5801 ; REPORT ERROR 5810.
      030636 104455          TRAP   C#ERDF
      030640 013262          .WORD  5810
      030642 006757          .WORD  EM5801
      030644 012112          .WORD  ER5801
7000
7001 030646 032767 000100 151334  BIT      #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
    
```

```

7002 030654 001520          BEQ      60$          ;EXIT THE TEST IF IT HASN'T.
7003                          ;+
7004                          ; SELECT ANOTHER VALUE FOR THE RXTIMER OR IF ALL VALUES HAVE BEEN TESTED THEN
7005                          ; TEST THE RXTIMER WITH INDEFINATE DELAY SET.
7006                          ;
7007 030656 004767 165532    6$:   JSR      PC,RXIE0      ;DISABLE INTERRUPTS.
7008 030662 006305          ASL      W5          ;MULTIPLY (RXTIMER VALUE + 1) BY 2.
7009 030664 020527 000400    CMP      R5,#256.    ;HAVE ALL VALUES BEEN TESTED ?
7010 030670 003621          BLE      2$          ;BRANCH AND TEST ANOTHER VALUE IF NOT.
7011                          ;+
7012                          ; VERIFY THAT WHEN RXTIMER VALUE IS 0 THE INTERRUPT IS DELAYED INDEFINITELY.
7013                          ; UNLESS THE PXFIFO IS 75% FULL OR MORE.
7014                          ;-
7015 030672 012767 013263 153152    MOV      #5811.,ERRNBR ;SET THE ERROR NUMBER TO 5811.
7016 030700 004767 164464    JSR      PC,PUFIFO    ;PURGE THE RXFIFO.
7017 030704 103102          BCC      50$          ;REPORT THE ERROR IF THE FIFO FAILED TO PURGE.
7018 030706 016701 000234    MOV      70$,R1       ;PASS THE LINE NUMBER.
7019 030712 012703 000277    MOV      #191.,R3     ;PASS THE NUMBER OF CHARS TO DMA.
7020 030716 005267 153130    INC      ERRNBR       ;SET THE ERROR NUMBER TO 5812.
7021 030722 004767 163374    JSR      PC,DMABUF    ;PERFORM THE DMA FROM ADDR #BUFBAS,THIS SUBR
7022                          ; PRODUCES ERRORS >>>> 5812 THRU 5813 <<<<<.
7023 030726 103071          BCC      50$          ;REPORT THE ERROR IF ONE OCCURED.
7024 030730 012701 001750    MOV      #1750,R1     ;INDICATE TO TEST BIT0 WITH TIME OUT OF 1 SEC.
7025 030734 012702 002266    MOV      #RXINTC,R2   ;PASS THE ADDR OF THE WORD TO TEST.
7026 030740 005067 151322    CLR      RXINTC       ;CLEAR THE RX-INT COUNT.
7027 030744 105077 151256    CLRB    #CSRA        ;CLEAR THE IND.ADDR.REG BITS OF THE CSR READY.
7028                          ; FOR THE WRITE TO THE RXTIMER REG.
7029 030750 105077 151254    CLRB    #RXTMA       ;SET THE VALUE 0 IN THE RXTIMER.
7030 030754 012704 000002    MOV      #2,R4        ;SET THE DELAY OF 2 MS.
7031 030760 004767 163276    JSR      PC,DELAY     ;DELAY TO ALLOW THE RXTIMER VALUE TO UPDATE.
7032 030764 004767 165464    JSR      PC,RXIE1     ;ENABLE RX-INTS.
7033 030770 004767 166442    JSR      PC,WAIBIS    ;WAIT FOR THE INTERRUPT TO OCCUR.
7034 030774 103007          BCC      8$          ;AVOID THE ERROR IF NO INTERRUPT.
7035                          ;+
7036                          ; REPORT THE ERROR, RX-INT OCCURED WITH RXTIMER VALUE ZERO.>>>> 5814 <<<<<.
7037                          ;-
7038 030776 012701 007201    MOV      #EM5804,R1   ;PASS THE MESSAGE,
7039                          ; "RXTIMER BAD, RX-INT OCCURED WITH RXTIMER
7040                          ; VALUE ZERO".
7041
7042 031002          ERDF      5814,EM5801,ER0503 ; REPORT ERROP 5814.
                                TRAP      C#ERDF
                                .WORD     5814
                                .WORD     EM5801
                                .WORD     ER0503
7043
7044 031012 000441          BR       60$          ;EXIT THE TEST.
7045                          ;+
7046                          ; VERIFY THAT WHEN THE FIFO IS 75% FULL THE INTERRUPT OCCURS IMMEDIATELY.
7047                          ;-
7048 031014 004767 165374    8$:   JSR      PC,RXIE0      ;DISABLE RX-INTS.
7049 031020 012767 013267 153024    MOV      #5815.,ERRNBR ;SET THE ERROR NUMBER TO 5815.
7050 031026 016701 000114    MOV      70$,R1       ;PASS THE LINE NUMBER.
7051 031032 012703 000001    MOV      #1,R3        ;PASS THE NUMBER OF CHARS TO DMA.
7052 031036 004767 163260    JSR      PC,DMABUF    ;PERFORM THE DMA FROM ADDR #BUFBAS,THIS SUBR
7053                          ; PRODUCES ERRORS >>>> 5815 THRU 5816 <<<<<.
7054 031042 103023          BCC      50$          ;REPORT THE ERROR IF ONE OCCURED.
    
```

L14

```

7055 031044 005067 151216 CLR RXINTC ;CLEAR THE RX-INT COUNT.
7056 031050 012701 000005 MOV #5,R1 ;SET THE TIME-OUT TO 5 MS.
7057 031054 012702 002266 MOV #RXINTC,R2 ;PASS ADDR OF WORD TO TEST.
7058 031060 004767 165370 JSR PC,RXIE1 ;ENABLE INTERRUPTS.
7059 031064 004767 166346 JSR PC,WAIBIS ;WAIT FOR THE INT TO OCCUR.
7060 031070 103412 BCS 60$ ;EXIT THE TEST IF AN INTERRUPT OCCURED.
7061 ;+
7062 ; REPORT THE ERROR, RX-INT DID NOT OCCUR IMMEDIATLEY.>>>> 5817 <<<<.
7063 ;-
7064 031072 005002 CLR R2 ;PASS THE RXTIMER VALUE.
7065 031074 012701 007077 MOV #EM5803,R1 ;PASS THE MESSAGE.
7066
7067 031100 ERRDF 5817,EM5801,ER5801 ; REPORT ERROR 5817.
031100 104455 TRAP C$ERDF
031102 013271 .WORD 5817
031104 006757 .WORD EM5801
031106 012112 .WORD ER5801
7068
7069 031110 000402 BR 60$ ;EXIT THE TEST.
7070
7071 031112 004767 165554 50$: JSR PC,TSABRT ;REPORT NON-RELATED TEST ERROR.
7072 031116 012700 000340 60$: SETPRI #PRI07 ;DISABLE ALL INTERRUPTS.
031122 104441 MOV #PRI07,R0
031124 004767 165264 JSR PC,RXIE0 ;DISABLE DEVICE RX-INTS.
7073 031130 016700 151060 CLRVEC RXVECA ;CLEAR DOWN THE RX VECTOR.
7074 031134 104436 TRAP C$CVEC
031136 005067 151106 CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
7075 031142 104432 TRAP C$EXIT
7076 031144 000004 .WORD L10043-.
031146 000000 70$: .WORD 0 ;LOCAL STORAGE FOR LINE NUMBER USED IN THE TEST.
031150 .WORD 0
031150 104401 L10043: TRAP C$ETST
    
```

HARDWARE TEST - TXACTF

```

7080
7081
7082
7083
7084
7085
7086
7087
7088
7089
7090
7091
7092
7093
7094 031152
      031152
7095
7096 031152 012700 000240
      031152 104441
7097
7098      000017
7099 031160 012767 000017 151066
7100 031166 012767 177777 151054
7101 031174 012767 000001 152646
7102 031202 012767 013415 152642
7103 031210 012767 007346 152636
7104 031216 012767 012170 152632
7105
7106
7107
7108
7109
7110
7111 031224 004767 162766
7112 031230 103402
7113 031232 000167 000474
7114
7115
7116
7117
7118
7119 031236 012705 177777
7120 031242 012700 000204
7121
7122 031246 004767 166300
7123 031252 012700 177670
7124 031256 004767 166320
7125 031262 012704 000012
7126 031266 004767 162770
7127
7128
7129
7130
7131 031272 005001
7132 031274 012702 002650
7133 031300 012703 000001

```

```

.SBTTL  HARDWARE TEST          - TXACTF -
;+ *****
;+                                     - TX ACTION FIFO TEST -
;+
;+   THIS TEST VERIFIES THAT THE DUT'S TX-ACTION FIFO CAN CORRECTLY
;+   HOLD 16 TX-ACTIONS.  ONE CHARACTER IS TRANSMITTED ON EACH LINE
;+   USING DMA, THE TX-ACTIONS ARE THEN READ FROM THE FIFO, VERIFYING
;+   THAT THEY ARE IN THE CORRECT ORDER AND THAT THERE ARE 16 OF THEM.
;+   THE TEST ALSO VERIFIES THAT THE DUT WILL NOT SEND TX-INTS AFTER
;+   THE TX ACTION FIFO HAS BEEN EMPTIED.
;+   THIS TEST IS PERFORMED IN INTERNAL LOOPBACK ON ALL LINES.
;+
;+ *****
;+
;+                                     BGMTST
;+
;+                                     T15::
;+
;+   SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.
;+
;+   MOV      #PRI05,R0
;+   TRAP    C:SPRI
;+
;+   TNUM == TNUM + 1      ;INCREMENT ASSEMBLY TIME TEST COUNTER
;+   MOV      #TNUM,TSTNUM ;SET UP THE TEST NUMBER.
;+   MOV      #-1,CTRLCF   ;INDICATE THAT WE ARE IN A TEST.
;+   MOV      #1,ERRTYP    ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
;+   MOV      #5901,ERRNBR ;SET THE ERROR NUMBER TO 5901.
;+   MOV      #EMS901,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
;+   MOV      #ER5901,ERRBLK ;SET THE ERROR REPORTING ROUTINE.
;+
;+
;+   ; RESET THE DUT TO A KNOWN STATE, REMOVE ANY STATUS CODES IN THE FIFO.
;+   ; CLEAR THE RX AND TX ENABLE BITS IN THE CSR.
;+   ; THIS SUBROUTINE REPORTS ERROR >>>> 5901 <<<<.
;+
;+
;+   JSR      PC,CLNRST    ;RESET THE DHU-11 REPORT ANY ERRORS FOUND.
;+   BCS      .+6          ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
;+   JMP      60$         ;EXIT THE TEST IF FATAL ERROR FOUND.
;+
;+
;+   ; SET INTERNAL LOOPBACK ON ALL LINES AND ENABLE RECIEVERS.  SET UP THE
;+   ; LPR'S TO 38.4K BAUD, 8 BITS/CHARA, ODD PARITY, 2 STOP BITS.
;+
;+
;+   MOV      #MAPLNS,R5   ;INDICATE TO SET UP ALL LINES.
;+   MOV      #204,R0      ;PASS PARAMETER FOR INTERNAL LOOPBACK.
;+                       ;ENABLE RECIEVERS.
;+   JSR      PC,WTWLNLC   ;INITIALISE THE LINE CONTROL REGS.
;+   MOV      #177670,R0  ;PASS THE LPR CONTENTS.
;+   JSR      PC,WTWLPR    ;SET THE LPR'S TO 38.4K BAUD.
;+   MOV      #10,R4       ;PASS DELAY TIME OF 10 MILLI SECS.
;+   JSR      PC,DELAY     ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
;+
;+
;+   ; INITIATE A DMA ON EACH LINE AND WAIT FOR ALL DMA'S TO COMPLETE.
;+
;+
;+   CLR      R1           ;PASS THE FIRST LINE NUMBER.
;+   MOV      #BUFBAS,R2  ;PASS THE START OF THE DATA PATTERN TO TX.
;+   MOV      #1,R3       ;PASS THE LENGTH OF THE DATA PATTERN.

```

```

7134 031304 012704 000005      MOV    #5,R4      ;PASS THE DELAY TIME OF 5 MILLI SECS.
7135 031310 005267 152536      INC    ERRNBR     ;SET THE ERROR NUMBER TO 5902.
7136 031314 004767 163060      JSR    PC,DODMA   ;TRANSMIT THE DATA PATTERN.
7137 031320 103402             BCS    .+6        ;CONTINUE IF SUCCESSFUL.
7138 031322 000167 000400      JMP    50$        ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
7139                               ;+
7140                               ; WAIT FOR THE DMA TO COMPLEATE BEFORE INITIATING ANOTHER.
7141                               ;-
7142 031326 004767 162730      JSR    PC,DELAY   ;WAIT 5 MILLI SECS FOR THE DMA TO COMPLEATE.
7143 031332 005201             INC    R1         ;INCREMENT THE LINE NUMBER.
7144 031334 022701 000020      CMP    #16.,R1   ;BRANCH TO INITIATE ANOTHER DMA IF
7145 031340 001365             BNE    2$        ;NOT ALL LINES SERVED.
7146                               ;+
7147                               ; READ THE TX-ACTIONS FROM THE TX_ACTION FIFO AND VERIFY THAT THEY OCCURED
7148                               ; IN THE CORRECT ORDER.
7149                               ;-
7150 031342 005267 152504      INC    ERRNBR     ;SET THE ERROR NUMBER TO 5903.
7151 031346 012703 007402      MOV    #EM5902,R3 ;SET THE ERROR MESSAGE TO,
7152                               ; "TX-ACTION RECIEVED FROM THE WRONG LINE".
7153 031352 005001             CLR    R1         ;CLEAR THE LINE NUMBER.
7154 031354 017702 150646      MOV    @CSRA,R2  ;READ THE CSR.
7155 031360 100150             BPL    14$        ;BRANCH TO REPORT ERROR >>5904<<, IF NO TX ACT.
7156 031362 000302             SWAB   R2         ;PUT THE TX LINE NUMBER IN THE LOW BYTE.
7157 031364 042702 177760      BIC    #177760,R2 ;CLEAR THE CLUTTER FROM THE LINE NUMBER.
7158 031370 020201             CMP    R2,R1     ;COMPARE THE ACTUAL LINE NUMBER OF THE
7159                               ;TX-ACTION WITH THE EXPECTED NUMBER.
7160 031372 001405             BEQ    6$        ;SKIP THE ERROR REPORT IF CORRECT.
7161 031374             ERROR   ;REPORT THE ERROR >>>> 5903 <<<<<.
7162 031376 032767 000100 150604 BIT    #BIT06,OPTION ;EXIT IF EXTENDED ERROR REPORTING HAS NOT
7163 031404 001552             BEQ    60$        ;BEEN REQUESTED.
7164 031406 005201             INC    R1         ;INCREMENT THE EXPECTED LINE NUMBER.
7165 031410 022701 000020      CMP    #16.,R1   ;BRANCH AND READ ANOTHER TX-ACTION IF,
7166 031414 001357             BNE    4$        ;NOT ALL LINES HAVE BEEN SERVICED.
7167                               ;+
7168                               ; 16 TX-ACTIONS HAVE BEEN READ, THE TX-ACTION BIT SHOULD NOW BE CLEAR.
7169                               ; CHECK THAT IT IS CLEAR, IF IT ISN'T THEN COUNT THE NUMBER OF EXTRA
7170                               ; TX-ACTIONS RECIEVED AND REPORT THE ERROR.
7171                               ;-
7172                               ;+
7173 031416 005777 150604      TST    @CSRA     ;READ THE CSR.
7174 031422 100024             BPL    10$        ;BRANCH IF THE TX-ACTION BIT IS CLEAR, TO
7175                               ;TEST THE TX-INTERRUPTS.
7176 031424 012767 013421 152420 MOV    #5905.,ERRNBR ;SET THE ERROR NUMBER TO 5905.
7177 031432 012702 000021      MOV    #17.,R2   ;SET R2 TO BE THE NUMBER OF TX ACTIONS FOUND.
7178 031436 005777 150564      TST    @CSRA     ;READ THE CSR.
7179 031442 100123             BPL    16$        ;BRANCH AND REPORT ERROR IF THE TX-ACTION FIFO,
7180                               ;FINALLY CLEARED.
7181 031444 005202             INC    R2         ;INCREMENT THE NUMBER OF TX-ACTIONS FOUND.
7182 031446 022702 000145      CMP    #101.,R2  ;IF LESS THAN 100 TX-ACTIONS HAVE BEEN READ,
7183 031452 001371             BNE    8$        ;THEN CONTINUE READING THE CSR.
7184                               ; OTHERWISE REPORT THE ERROR.
7185                               ;+
7186                               ; REPORT THE ERROR "TX-ACTION FIFO WOULD NOT EMPTY"
7187                               ;-
7188 031454 005267 152372      INC    ERRNBR     ;SET THE ERROR NUMBER TO 5906.
7189 031460 012701 007570      MOV    #EM5904,R1 ;SET THE ERROR MESSAGE TO,

```

```

7190
7191 031464 012767 011762 152364      MOV    #ER0503,ERRBLK    ; "TX ACTION FIFO WOULD NOT EMPTY"
7192 031472 000513                    BR     18$              ; SET UP THE ERROR REPORTING ROUTINE.
7193                                     ; GO REPORT THE ERROR.
7194
7195 ; NOW VERIFY THAT NO TX_INTS OCCUR AFTER THE TX_ACTION FIFO HAS BEEN EMPTIED.
7196 ; OF TX_ACTIONS, I.E. NO INTERRUPTS OCCUR WITH THE TX_ACTION BIT CLEAR.
7197
7198 031474 005001      10$: CLR    R1              ; PASS THE NUMBER OF THE FIRST LINE
7199
7200
7201 ; INITIATE A DMA ON ALL LINES AND WAIT FOR ALL DMA'S TO COMPLETE.
7202
7203 031476 012767 013423 152346      MOV    #5907,ERRNBR    ; SET THE ERROR NUMBER TO 5907.
7204 031504 012702 002650            MOV    #BUFBA5,R2     ; PASS THE START OF THE DMA PATTERN TO TX.
7205 031510 012703 000001            MOV    #1,R3         ; PASS THE LENGTH OF THE DATA PATTERN.
7206 031514 004767 162660      12$: JSR    PC,DODMA     ; TRANSMIT THE DATA PATTERNS.
7207 031520 103102                    BCC   50$            ; ABORT THE TEST IF ERROR FOUND DURING DMA TX.
7208 031522 005201                    INC    R1            ; INCREMENT THE LINE NUMBER.
7209 031524 022701 000020            CMP    #16.,R1      ; BRANCH TO INITIATE ANOTHER DMA IF,
7210 031530 001371      12$:      BNE   12$            ; ALL LINES NOT SERVED.
7211 031532 012704 000144            MOV    #100.,R4     ; SET THE DELAY OF 100 MILLI SECS.
7212 031536 004767 162520      12$: JSR    PC,DELAY     ; WAIT FOR THE DMA'S TO COMPLETE.
7213
7214 ; SET UP THE INTERRUPT SERVICE ROUTINE THAT WILL READ THE TX_ACTION FIFO
7215 ; UNTIL EMPTY AND CHECK FOR ANY SUBSEQUENT INTERRUPTS WITH NO TX_ACTION.
7216 ; ENABLE TX INTERRUPTS.
7217
7218 031542 005067 150524            CLR    TXINTC        ; CLEAR THE TX INT COUNTER.
7219 031546 005067 150522            CLR    TXINTF        ; CLEAR THE TX INT FLAGS.
7220
7221                                SETVEC TXVECA,@TXAINT,@PRI06
7222                                MOV    #PRI06,-(SP)
7223                                MOV    @TXAINT,-(SP)
7224                                MOV    TXVECA,-(SP)
7225                                MOV    #3,-(SP)
7226                                TRAP   C15VEC
7227                                ADD    #10,SP
7228 031600                                SETPRI #PRI04        ; ALLOW DEVICE INTERRUPTS.
7229 031600 012700 000200                                MOV    #PRI04,R0
7230 031604 104441                                TRAP   C15PRI
7231 031606 004767 165444            JSR    PC,TXIE1     ; ENABLE TX INTERRUPTS.
7232
7233 ; WAIT FOR THE INTERRUPTS TO OCCUR
7234
7235 ;
7236                                MOV    #5,R4         ; SET THE DELAY FOR 5 MILLI SECS.
7237 031612 012704 000005      12$: JSR    PC,DELAY     ; DELAY FOR 5 MS.
7238 031616 004767 162440
7239
7240 ; DISABLE INTERRUPTS AND CLEAR DOWN THE INTERRUPT SERVICE ROUTINE.
7241
7242 ;
7243                                SETPRI #PRI07        ; DISABLE ALL INTERRUPTS.
7244                                MOV    #PRI07,R0
7245                                TRAP   C15PRI
7246 031622 012700 000340
7247 031626 104441
7248 031630 004767 165362            JSR    PC,TXIE0     ; DISABLE OUT TX INTERRUPTS
7249 031634                                CLRVEC TXVECA       ; CLEAR THE TX INT VECTOR
7250 031634 016700 150356                                MOV    TXVECA,R0
7251 031640 104436                                TRAP   C15VEC
    
```


015

```

7269 .SBTTL  HARDWARE TEST          - TXFIFO -
7270 ;* .. *****
7271 ;* - TXFIFO TEST -
7272 ;*
7273 ;* THIS TEST IS USED TO VERIFY THAT THE DUT'S TRANSMIT FIFO'S CAN HOLD
7274 ;* 64 CHARACTERS AND THAT ONLY ONE TX INTERRUPT OCCURS FOR ALL 64
7275 ;* CHARACTERS. THE TEST ALSO EXERCISES THE BYTE SWAPPER BY USING
7276 ;* ALTERNATE WORD AND BYTE WRITES TO THE TX FIFO, AS WELL AS CHECKING THAT
7277 ;* THE FIFOSIZE REGISTER REPORTS THE NUMBER OF CHARACTERS IN THE FIFO
7278 ;* CORRECTLY. ANY BMP CODES FOUND ARE SAVED ON THE QUE TO BE REPORTED
7279 ;* LATER.
7280 ;* THE TEST IS PERFORMED IN INTERNAL LOOPBACK ON ALL ACTIVE LINES.
7281 ;* .. *****
7282 031740          BGNTST
7283 031740
7284 031740          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.
7285 031740 012700 000240          MOV          #PRI05,R0
7286 031744 104441          TRAP          C$SPRI
7287 031746 000020          TNUM  == TNUM + 1          ;INCREMENT ASSEMBLY TIME TEST COUNTER
7288 031746 012767 000020 150300  MOV          #TNUM,T$TNUM          ;SET UP THE TEST NUMBER.
7289 031754 012767 177777 150266  MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
7290 031762 012767 000001 152060  MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
7291 031770 012767 013561 152054  MOV          #6001,ERRNBR          ;SET THE ERROR NUMBER TO 6001.
7292 031776 012767 007754 152050  MOV          #EM6001,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
7293 032004 005067 150602          CLR          ERSRFR          ;CLEAR THE ERROR SUMMARY FLAGS.
7294 032010 005067 150236          CLR          EXOERR          ;CLEAR THE "EXIT ON ERROR" FLAG.
7295 032014 012700 002614          MOV          #ERCNTB,R0          ;SET UP THE START ADDRESS FOR THE BLCK.
7296 032020 004767 162214          JSR          PC,CLR16W          ;CLEAR THE BLOCK OF 16 WORDS.
7297 ;*
7298 ;* RESET THE DUT TO A KNOWN STATE, REMOVE ANY STATUS CODES IN THE FIFO.
7299 ;* CLEAR THE RX AND TX ENABLE BITS IN THE CSR.
7300 ;* THIS SUBROUTINE REPORTS ERROR >>>> 6001 <<<<<.
7301 ;*
7302 JSR          PC,CLRST          ;RESET THE DMU-11 REPORT ANY ERRORS FOUND.
7303 BCS          .+6          ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
7304 JMP          621          ;EXIT THE TEST IF FATAL ERROR FOUND.
7305 ;*
7306 ;* SET INTERNAL LOOPBACK ON ALL ACTIVE LINES AND ENABLE RECIEVERS. SET UP THE
7307 ;* LPR'S TO 38.4K BAUD, 8 BITS/CHARA, ODD PARITY, 2 STOP BITS. DISABLE
7308 ;* TRANSMITTERS ON ALL LINES.
7309 ;*
7310 MOV          #MAPLNS,R5          ;INDICATE TO DISABLE ALL LINES.
7311 JSR          PC,TXDSBL          ;DISABLE TX ON ALL LINES.
7312 MOV          ACTLNS,R5          ;INDICATE TO SET UP ACTIVE LINES ONLY.
7313 MOV          #204,R0          ;PASS PARAMETER FOR INTERNAL LOOPBACK,
7314 ;* ENABLE RECIEVERS.
7315 JSR          PC,WTWLNCR          ;INITIALISE THE LINE CONTROL REGS.
7316 MOV          #177670,R0          ;PASS THE LPR CONTENTS.
7317 JSR          PC,WTWLPRA          ;SET THE LPR'S TO 38.4K BAUD.
7318 MOV          #10.,R4          ;PASS DELAY TIME OF 10 MILLI SECS.
7319 JSR          PC,DELAY          ;WAIT FOR LNCRTL AND LPR REGS TO BE UPDATED.
7320 ;*
7321 ;* SET UP THE TX INTERRUPT SERVICE ROUTINE AND VECTOR. THE ROUTINE COUNTS
7322 ;* THE NUMBER OF INTERRUPTS AND CHECKS FOR ANY INTERRUPTS OCCURING WITH
7323 ;* NO TX-ACTION.
7324 ;
    
```

```

7323 032102          SETVEC TXVECA,@TXAINT,@PRI06
      032102 012746 000300          MOV @PRI06,-(SP)
      032106 012746 017734          MOV @TXAINT,-(SP)
      032112 016746 150100          MOV TXVECA,-(SP)
      032116 012746 000003          MOV @3,-(SP)
      032122 104437          TRAP C$SVEC
      032124 062706 000010          ADD @10,SP
7324 032130 004767 165122          JSR PC,TXIE1 ;SET THE TX INT ENABLE BIT IN THE CSR.
7325
7326 ; WRITE 64 CHARACTERS TO ALL TXFIFO'S USING ALTERNATE WORD/BYTE WRITES
7327 ; TO EXERCISE THE BYTE SWAPPER. AFTER THE FIRST 9 CHARACTERS HAVE BEEN
7328 ; WRITTEN CHECK THAT THE FIFOSIZE REGISTER SHOWS THE CORRECT NUMBER OF
7329 ; FREE BYTES IN THE FIFO.
7330
7331 032134 016705 150060          MOV ACTLNS,R5 ;SET UP THE ACTIVE LINE BIT MAP.
7332 032140 005001          CLR R1 ;SET UP THE FIRST LINE NUMBER.
7333
7334 032142 000241          28: CLC ;CLEAR THE CARRY BIT READY FOR THE ROTATION.
7335 032144 006005          ROR R5 ;ROTATE THE ACTIVE LINE BIT MAP INTO THE CARRY.
7336 032146 103067          BCC 10$ ;AVOID TESTING THIS LINE IF ITS INACTIVE.
7337 032150 110177 150052          MOV R1,@CSRA ;LOAD THE LINE NUMBER OF THE UUT INTO THE CSR.
7338 032154 010103          MOV R1,R3 ;INITIALISE THE DATA PATTERN FOR THIS LINE BY
7339 032156 000303          SWAB R3 ;PUTTING THE LINE NUMBER IN THE HI BYTE AND
7340 ;CLEARING THE LO BYTE.
7341
7342 ; LOAD 9 CHARACTERS INTO THE TXFIFO AND CHECK THE FIFOSIZE REGISTER.
7343
7344 032160 01270C 000003          ; LOOP COUNT.
7345 032164 010377 150044          4$: MOV R3,@FDATA ;MOVE A WORD OF DATA INTO THE FIFO.
7346 032170 105203          INCB R3 ;INCREMENT THE LO BYTE OF THE DATA PATTERN.
7347 032172 110377 150036          MOV R3,@FDATA ;MOVE A BYTE OF DATA INTO THE FIFO.
7348 032176 062703 000401          ADJ @401,R3 ;INCREMENT THE HIGH AND LOW BYTE OF THE DATA.
7349 032202 005300          DEC R0 ;DECREMENT THE LOOP COUNT.
7350 032204 001367          BNE 4$ ;BRANCH IF NOT ALL 9 CHARACTERS WRITTEN.
7351 032206 005002          CLR R2 ;CLEAR THE UPPER AND LOWER BYTE OF R2.
7352 032210 117702 150020          MOV @FSLSA,P2 ;READ THE FIFOSIZE REGISTER.
7353 032214 122702 000067          CMPB @55.,R2 ;COMPARE THE EXPECTED SIZE WITH THE ACTUAL.
7354 032220 001425          BEQ 6$ ;AVOID THE ERROR REPORT IF THE SIZE IS CORRECT.
7355
7356 ; REPORT THE ERROR, INCORRECT VALUE. >>>> 6002 <<<<<.
7357
7358 032222 010104          ; PASS THE LINE NUMBER TO THE ERROR ROUTINE.
7359 032224 012701 000067          MOV R1,R4 ;PASS THE EXPECTED FIFO SIZE.
7360 032230 010346          MOV R3,-(SP) ;SAVE THE DATA PATTERN.
7361 032232 012767 013562 151612          MOV @6002.,ERRNBR ;SET THE ERROR NUMBER TO 6002.
7362 032240 012703 010000          MOV @EM6002,R3 ;PASS THE MESSAGE.
7363 ; "INCORRECT VALUE IN FIFOSIZE REGISTER".
7364 032244 012767 012276 151604          MOV @ER6001.ERRBLK ;SET THE ERROR REPORTING ROUTINE.
7365 032252          ERROR
7366 032252 104460          TRAP C$ERROR
7367 032254 012603          MOV (SP),P3 ;RESTORE THE PATTERN.
7368 032256 010401          MOV R4,R1 ;RESTORE THE LINE NUMBER.
7369 032260 032767 000100 147722          BIT @BIT06.OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
7370 032266 001002          BNE 6$ ;CONTINUE IF IT HAS.
7371 032270 000167 000444          JMP 60$ ;EXIT THE TEST IF IT HASN'T.
7372
; CONTINUE FILLING UP THE FIFO UNTIL 64 CHARACTERS HAVE BEEN LOADED.

```

```

7373
7374 032274 012700 000022      ;
6$:   MOV    #18.,R0           ;SET UP THE OUTER LOOP.
7375 032300 010377 147730      8$:   MOV    R3,@FDATA         ;MOVE A WORD OF DATA INTO THE FIFO.
7376 032304 105203             ;INCB    R3                   ;INCREMENT THE LOBYTE OF THE DATA PATTERN.
7377 032306 110377 147722      MOVB   R3,@FDATA         ;MOVE A BYTE OF DATA INTO THE FIFO.
7378 032312 062703 000401      ADD    #401,R3            ;INCREMENT THE HIGH AND LOW BYTE OF THE DATA.
7379 032316 005300             DEC    R0                  ;DECREMENT THE LOOP COUNT.
7380 032320 001367             BNE    #8$                 ;BRANCH IF NOT ALL 54 CHARACTERS WRITTEN.
7381 032322 110377 147706      MOVB   R3,@FDATA         ;LOAD THE LAST CHARACTER.
7382
7383      ; LOOP UNTIL THE TXFIFO'S ON ALL ACTIVE LINES HAVE BEEN FILLED.
7384
7385 032326 005705             10$:  TST    R5              ;HAVE ALL FIFOS BEEN FILLED.
7386 032330 001402             BEQ    12$                 ;YES, THEN GO AND TRANSMIT THE CHARACTERS.
7387 032332 005201             INC    R1                  ;OTHERWISE SELECT THE NEXT LINE.
7388 032334 000702             BR     2$                  ;AND BRANCH TO TEST IF ITS ACTIVE.
7389
7390      ; ENABLE TRANSMISSION ON EACH LINE IN TURN AND WAIT FOR 100 MS TO ALLOW
7391      ; ANY INTERRUPTS TO OCCUR BEFORE DISABLING TRANSMISSION. VERIFY THAT ONLY
7392      ; INTERRUPT OCCURED AND CHECK THAT THE CHARACTERS WERE TRANSMITTED UNCORRUPTED
7393      ; AND ON THE CORRECT LINE.
7394
7395 032336 016705 147656      12$:  MOV    ACTLNS,R5       ;SET UP THE ACTIVE LINE BIT MAP.
7396 032342 005001             CLR    R1                  ;SET UP THE FIRST LINE NUMBER.
7397
7398 032344 000241             14$:  CLC                    ;CLEAR THE CARRY BIT READY FOR THE ROTATION.
7399 032346 006005             ROR    R5                  ;ROTATE THE ACTIVE LINE BIT MAP INTO THE CARRY.
7400 032350 103157             BCC   24$                 ;AVOID TESTING THIS LINE IF ITS INACTIVE.
7401 032352 110177 147650      MOVB   R1,@CSRA          ;LOAD THE LINE NUMBER OF THE OUT INTO THE CSR.
7402 032356 010103             MOV    R1,R3              ;INITIALISE THE "EXPECTED" DATA PATTERN FOR
7403 032360 000303             SWAB   R3                 ;THIS LINE.
7404 032362 012767 013563 151462 MOV    #6003.,ERRNBR     ;SET THE ERROR NUMBER TO 6003.
7405 032370 004767 162774      JSR    PC,PURFIFO        ;PURGE THE RXFIFO.
7406 032374 103151             BCC   50$                 ;REPORT THE ERROR IF THE FIFO WOULD NOT PURGE.
7407 032376 005067 147670      CLR    TXINTC            ;CLEAR THE INTERRUPT COUNT.
7408 032402 005067 147666      CLR    TXINTF            ;CLEAR THE INTERRUPT FLAGS.
7409 032406 052777 100000 147626 BIS    #BIT15,@TXAD2A    ;ENABLE TRANSMISSION ON THIS LINE.
7410 032414             SETPRI #PRI04            ;ALLOW DEVICE INTERRUPTS.
7411      ;
7412      ;
7413      ;
7414      ;
7415      ;
7416      ;
7417      ;
7418      ;
7419 032446 005267 151400             INC    ERRNBR             ;SET THE ERROR NUMBER TO 6004.
7420 032452 005767 147614             TST    TXINTC            ;HAS AN INTERRUPT OCCURED ?
7421 032456 001520             BEQ    50$                 ;REPORT THE ERROR IF NO INTERRUPT OCCURED.
7422 032460 005267 151366             INC    ERRNBR             ;SET THE ERROR NUMBER TO 6005.
7423 032464 005767 147604             TST    TXINTF            ;HAS AN INTERRUPT OCCURED WITHOUT A TX-ACTION ?
7424 032470 100513             BMI    50$                 ;REPORT THE ERROR IF IT HAS.
7425 032472 022767 000001 147572 CMP    #1,TXINTC          ;DID ONLY ONE INT OCCUR ?

```

```

7426 032500 001424          BEQ      16$          ;AVOID THE ERROR IF ONLY ONE INTERRUPT.
7427                          ;*
7428                          ; REPORT THE ERROR, MORE THAN ONE INTERRUPT. >>>> 6006 <<<<
7429                          ;
7430 032502 016702 147564    MOV      TXINTC,R2      ;PASS THE ACTUAL NUMBER OF INTERRUPTS.
7431 032506 010104          MOV      R1,R4         ;PASS THE LINE NUMBER.
7432 032510 012701 000001    MOV      #1,R1        ;PASS THE EXPECTED NUMBER OF INTS.
7433 032514 010346          MOV      R3,-(SP)      ;SAVE THE DATA PATTERN.
7434 032516 012703 010040    MOV      @EM6003,R3   ;PASS THE MESSAGE,
7435                          ; "MORE THAN ONE TX-INT OCCURED FROM A FULL
7436                          ; TX FIFO".
7437 032522 005267 151324    INC      ERRNBR       ;SET THE ERROR NUMBER TO 6006.
7438 032526 012767 012276 151322  MOV      @ER6001,ERRBLK ;SET UP THE ERROR BLOCK.
7439 032534          ERROR
7440 032534 104460          MOV      (SP)+,R3     ;RESTORE THE DATA PATTERN.          TRAP      C$ERROR
7441 032540 010401          MOV      R4,R1        ;RESTORE THE LINE NUMBER.
7442 032542 032767 000100 147440  BIT      @BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
7443 032550 001473          BEQ      60$          ;EXIT THE TEST IF IT HAS.
7444
7445
7446                          ;*
7447                          ; READ THE CHARACTERS FROM THE RXFIFO AND VERIFY THEY ARE CORRECT AND WERE
7448                          ; RECIEVED ON THE CORRECT LINE.
7449                          ; THIS SUBROUTINE REPORTS ERRORS. >>>> 6007 THRU 6008 <<<<.
7450                          ;-
7451 032552 012767 013567 151272 16$:  MOV      @6007.,ERRNBR ;SET UP THE ERROR NUMBER TO 6007.
7452 032560 005000          CLR      R0           ;INITIALISE THE NUMBER OF CHARS READ COUNT.
7453 032562 012704 000025    MOV      @21.,R4     ;SET UP THE OUTER LOOP COUNT.
7454 032566 012702 000003    18$:  MOV      @3,R2    ;SET UP THE INNER LOOP COUNT.
7455 032572 004767 163140    20$:  JSR      PC,REPDER ;READ A CHARACTER FROM THE RXFIFO, VERIFY THAT
7456                          ; IT IS CORRECT AND CAME FROM THE UUT. REPORT
7457                          ; ANY ERRORS. >>>> 6007 THRU 6008 <<<<.
7458 032576 103022          BCC      22$          ;BRANCH TO REPORT THE ERROR IF THE FIFO EMPTY.
7459 032600 005767 147446    TST     EXOERR        ;TEST THE "EXIT ON ERROR" FLAG.
7460 032604 001055          BNE     60$          ;EXIT THE TEST IF SET, I.E. AN ERROR OCCURED,
7461                          ; AND NO EXTENDED ERROR REPORTING WAS REQUESTED.
7462 032606 005200          INC      R0           ;INCREMENT THE READ CHAR COUNT.
7463 032610 105203          INCB   R3            ;INCREMENT THE LOBYTE OF THE DATA PATTERN.
7464 032612 000303          SWAB  R3            ;SWAP BYTES TO PLACE EXPECTED CHAR IN LOBYTE.
7465 032614 005302          DEC      R2         ;DECREMENT THE INNER LOOP COUNTER.
7466 032616 001365          BNE     20$          ;BRANCH TO READ ANOTHER CHAR IF 3 CHARS HAVE
7467                          ; NOT BEEN READ.
7468 032620 000303          SWAB  R3            ;RESTORE THE DATA BYTES TO THE CORRECT POSITION
7469 032622 005304          DEC      R4         ;DECREMENT THE OUTER LOOP COUNTER.
7470 032624 001360          BNE     18$          ;BRANCH TO READ ANOTHER 3 CHARACTERS IF NOT
7471                          ; ALL 63 HAVE BEEN READ.
7472 032626 004767 163104    JSR     PC,REPDER    ;READ AND CHECK THE LAST CHARACTER.
7473 032632 103004          BCC      22$          ;BRANCH TO REPORT THE ERROR IF THE FIFO EMPTY.
7474 032634 005767 147412    TST     EXOERR        ;TEST THE "EXIT ON ERROR" FLAG.
7475 032640 001037          BNE     60$          ;EXIT THE TEST IF SET.
7476 032642 000422          BR      24$          ;OTHERWISE GO AND TEST ANOTHER LINE.
7477                          ;*
7478                          ; REPORT THE ERROR, NOT ALL CHARACTERS TRANSMITTED. >>>> 6009 <<<<.
7479                          ;-
7480 032644 012767 013571 151200 22$:  MOV      @6009.,ERRNBR ;SET THE ERROR NUMBER TO 6009.
7481 032652 012703 010243    MOV      @EM6006,R3   ;PASS THE MESSAGE,

```



```

7511 .SBTTL  HARDWARE TEST          - BREAKB -
7512 ;*****
7513 ;*          - BREAK GENERATION TEST -
7514 ;* THIS TEST VERIFIES THAT ALL SERIAL TRANSMIT LINES CAN GENERATE A BREAK
7515 ;* BY SETTING THE BRK BIT IN THE ASSOCIATED LNCTRL REGISTER.
7516 ;* USE OF THE INTERNAL LOOPBACK FEATURE OF THE DUARTS IS MADE TO MINIMISE
7517 ;* ANY EXTERNAL EFFECTS CAUSED ON THE SERIAL LINES BY THIS TEST.
7518 ;* FRAMING ERROR DETECTION IS USED TO INDICATE THE PRESENCE OF A BREAK,
7519 ;* BY SETTING THE APPROPRIATE BIT IN THE RBUF REGISTER.
7520 ;*****
7521 ;-----
7522 032766          BGNTST
7523 032766
7524 032766 012767 177777 147254      MOV    #1,CTRLCF      ;INDICATE THAT WE ARE IN A TEST.
7525          000021          TNUM = TNUM + 1      ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
7526 032774 012767 000021 147252      MOV    #TNUM,TSTNUM  ;SET UP THE TEST NUMBER. (64)
7527 033002 012767 000001 151040      MOV    #1,ERR;YP     ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
7528 033010 012767 014401 151034      MOV    #6401.,ERRNBR ;SET THE FIRST ERPOP NUMBER IN ERROR TABLE.
7529 033016 012767 010307 151030      MOV    #EM6401,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERRTBL.
7530
7531 ;*
7532 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
7533 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
7534 ; THIS SUBROUTINE REPORTS ERROR >>>> 6401 <<<<.
7535 033024 004767 161166          JSR    PC,CLRST      ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
7536 033030 103165          BCC    60$          ;EXIT TEST IF FATAL ERROR FOUND.
7537
7538 ;*
7539 ; SET UP DEVICE UNDER TEST (DUT) TO:
7540 ; DISABLE TRANSMISSION AND RECEPTION INTERRUPTS.
7541 ; DELAY FOR 10 MILLI-SECONDS TO ALLOW TIME TO CLEAR ANY BREAKS.
7542 033032 012705 177777          MOV    #MAPLNS,R5    ;PASS ACTIVE LINE BIT MAP.
7543 033036 012700 000200          MOV    #200,R0       ;PASS INTERNAL LOOPBACK MODE.
7544 033042 004767 164504          JSR    PC,WTWLNLC    ;SELECT INTERNAL LOOPBACK,DISABLE DMA.
7545 033046 012704 000012          MOV    #10.,R4      ;PASS DELAY TIME OF 10 MILLI SECONDS.
7546 033052 004767 161204          JSR    PC,DELAY      ;DELAY TO ALLOW ANY BREAKS TO BE CLEARED.
7547
7548 ;*
7549 ; SET UP TRANSMISSION AN RECEPTION PARAMETERS FOR ALL LINES.
7550 ; 9600 BAUD,8 CHAR,1 STOPBIT,NO PARITY.
7551 033056 012700 156430          MOV    #156430,R0    ;SET UP BAUD RATE,ETC.
7552 033062 004767 164514          JSR    PC,WTWLPR     ;SET COMMUNICATION PARAMETERS ON ALL LINES.
7553
7554 ;*
7555 ; ENABLE TRANSMITTERS ON ALL ACTIVE LINES.
7556 033066 016705 147126          MOV    #ACTLNS,R5    ;PASS ACTIVE LINE BIT MAP.
7557 033072 004767 164024          JSR    PC,TXENBL    ;ENABLE TRANSMISSIONS ON ALL LINES.
7558
7559 ;*
7560 ; PURGE THE FIFO OF ANY UNWANTED CHARACTERS.
7561 ; THIS ROUTINE REPORTS ERRORS WITH NUMBERS >>>> 6402 THRU 6404 <<<<.
7562 033076 005267 150750          INC    ERRNBR        ;SET ERROR NUMBER TO 6402.
7563 033102 004767 162344          JSR    PC,PUFIFR    ;PURGE FIFO.
7564 033106 103136          BCC    60$          ;ABORT TEST IF FIFO WILL NOT CLEAR.
7565
7566 ;*
7567 ; VERIFY BREAK GENERATION ON INDIVIDUAL LINES.
    
```

```

7567 ; CLEAR BREAKS ON ALL LINES.
7568 ; DELAY FOR 10 MILLI-SECONDS TO ALLOW TIME FOR ANY BREAKS TO BE CLEARED.
7569 ; SELECT LINE,SET BREAK BIT IN LNCTRL REGISTER.
7570 ; TEST FOR A CHARACTER IN THE FIFO WITH FRAME ERROR.
7571 ;
7572 033110 005002 2#: CLR R2 ;CLEAR LINE COUNTER.
7573 033112 012703 000001 MOV #1,R3 ;SET UP ACTIVE LINE BIT MASK.
7574 033116 030367 147076 4#: BIT R3,ACTLNS ;CHECK IF THIS LINE IS ACTIVE.
7575 033122 001440 BEQ 8# ;GO SELECT NEXT LINE IF THIS ONE IS INACTIVE.
7576 033124 012700 000200 MOV #200,R0 ;SET UP PARAMETER TO CLEAR BREAK BITS.
7577 033130 004767 164416 JSR PC,WTWLNLC ;CLEAR BREAK BIT,RESELECT INTERNAL LOOPBACK.
7578 033134 012704 000012 MOV #10.,R4 ;PASS DELAY TIME OF 10 MILLI SECONDS.
7579 033140 004767 161116 JSR PC,DELAY ;DELAY TO ALLOW BREAKS TO BE CLEARED.
7580 ;
7581 ; SET BREAK BIT ON SELECTED LINE.
7582 ; SET UP PARAMETERS TO TEST FOR THE FRAME ERROR BIT SET IN RBUF.
7583 ; TIME-OUT = 5 MILLI SECONDS.
7584 ; CALL ROUTINE TO CHECK FOR CONDITION FOUND.
7585 ;
7586 033144 010305 6#: MOV R3,R5 ;COPY ACTIVE LINE BIT MASK.
7587 033146 012700 000214 MOV #214,R0 ;SET BREAK,RESELECT LOOPBACK,ENABLE RECEPTION.
7588 033152 004767 164374 JSR PC,WTWLNLC ;SET BREAK ON SELECTED LINE.
7589 ;
7590 ; DELAY FOR 5 MS TO ALLOW TIME FOR BREAK TO BE GENERATED AND RECEIVED.
7591 ; VERIFY RECEPTION OF A CHARACTER WITH FRAME ERROR BIT SET.
7592 ;
7593 033156 012704 000005 MOV #5.,R4 ;SET DELAY VALUE TO 5 MILLI SECS.
7594 033162 004767 161074 JSR PC,DELAY ;ALLOW TIME FOR CHARACTER RECEPTION.
7595 033166 017700 147036 MOV @RBUFA,R0 ;GET CHARACTER FROM RBUF REGISTER.
7596 033172 032700 020000 BIT #BIT13,R0 ;CHECK FOR FRAME ERROR BIT.
7597 033176 001012 BNE 8# ;SKIP ERROR REPORT IF SET.
7598 033200 012701 010344 MOV #EM6402,R1 ;SELECT MESSAGE TO BE PRINTED.
7599 ;REPORT ERROR"BREAK NOT RECEIVED ON LINE #NN"
7600 033204 ERRDF 6405,EM6401,ER6401 ; >>>>> ERROR #6405 <<<<<.
033204 104455 TRAP C$ERDF
033206 014405 .WORD 6405
033210 010307 .WORD EM6401
033212 012400 .WORD ER6401
7601 ;
7602 ;
7603 ; * EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
7604 ;
7605 033214 032767 000100 146766 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
7606 033222 001470 BEQ 60# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
7607 ; DURING THE SOFTWARE QUESTIONS.
7608 ;
7609 033224 006303 8#: ASL R3 ;SHIFT BIT MASK FOR NEXT LINE.
7610 033226 005202 INC R2 ;NEXT LINE
7611 033230 020227 000020 CMP R2,#NUMLNS ;CHECK FOR MAX LINE COUNT.
7612 033234 001330 BNE 4# ;IF <>,LOOP TO CHECK NEXT LINE
7613 ;
7614 ; VERIFY BREAK GENERATION ON ALL LINES SIMULTANEOUSLY.
7615 ; CLEAR BREAKS ON ALL LINES.
7616 ; DELAY FOR 10 MILLI-SECONDS TO ALLOW TIME FOR ANY BREAKS TO BE CLEARED.
7617 ; PURGE THE FIFO.
7618 ; SET BREAK BIT IN LNCTRL REGISTERS ON ALL ACTIVE LINES.
7619 ; TEST FOR CHARACTERS IN THE FIFO WITH FRAME ERROR.

```



```

7667 .SBTTL  HARDWARE TEST          NORERR -
7668 ;*****
7669 ;*                               - NO OVERRUN ERROR TEST -
7670 ;*
7671 ;* THIS TEST VERIFIES THAT THE DUT WILL NOT REPORT DATA OVERRUN
7672 ;* ERRORS WHEN THEY DO NOT OCCUR.
7673 ;* THIS TEST PUTS 256 CHARACTERS IN THE DUT FIFO PLUS 4 IN EACH ACTIVE
7674 ;* UART AND VERIFIES THAT NO OVERRUN ERRORS ARE REPORTED.
7675 ;* ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
7676 ;* HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
7677 ;* REPORTED LATER.
7678 ;*
7679 ;*
7680 ;-----
7681 033412          BGNTST
7682 033412          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T18::
7683 033412          012700  000240          MOV          #PRI05,R0
7684 033416          104441          TRAP          C$SPRI
7685 033420          000022          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
7686 033426          012767  000022  146626  MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (66)
7687 033434          012767  177777  146614  MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
7688 033442          012767  000001  150406  MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
7689 033450          012767  014711  150402  MOV          #6601,ERRNBR          ;SET ERROR NUMBER TO 6601.
7690 033450          012767  010405  150376  MOV          #EM6601,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
7691 ;*
7692 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
7693 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
7694 ; THIS SUBROUTINE REPORTS ERROR >>>> 6601 <<<<<.
7695 ;-
7696 JSR          PC,CLNRST          ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
7697 BCS          .+6          ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
7698 JMP          60$          ;EXIT THE TEST, FATAL ERROR WAS FOUND.
7699 ;*
7700 ; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
7701 ; INITIALIZE THE 256 BYTE DATA PATTERN.
7702 ;-
7703 JSR          PC,FINACT          ;FIND AN ACTIVE LINE.
7704 BCS          .+6          ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
7705 JMP          60$          ;EXIT THE TEST, FATAL ERROR WAS FOUND.
7706 JSR          PC,INDATP          ;INITIALISE DATA PATTERN.
7707 ;*
7708 ; TRANSMIT A 265 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
7709 ; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
7710 ;-
7711 ;*
7712 ; SET INTERNAL LOOPBACK ON THE SELECTED LINE.
7713 ; TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
7714 ;-
7715 INC          ERRNBR          ;SET THE ERROR REPORT NUMBER TO 6602.
7716 MOV          #204,R0          ;PASS PARAMETER FOR INTERNAL LOOPBACK,ENABLE RX.
7717 JSR          PC,WTWLNLC          ;INITIALISE THE LINE CONTROL REGISTER.
7718 MOV          #177670,R0          ;PASS THE LPR CONTENTS.
7719 JSR          PC,WTWLPR          ;SET THE LPR CONTENTS TO 38.4K BAUD.
7720 MOV          #10,R4          ;PASS DELAY TIME OF 10 MILLI SECONDS.
7721 JSR          PC,DELAY          ;WAIT FOR LNCRTL AND LPR REGS TO BE UPDATED.
7722 MOV          #BUF8AS,R2          ;PASS THE START OF THE DATA PATTERN TO TX.
    
```

```

7721 033546 012703 000400      MOV      #BUF MID BUF BAS,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
7722 033552 004767 160622      JSR      PC,DODMA             ;TRANSMIT THE DATA PATTERN.
7723 033556 103157              BCC      50$                 ;EXIT IF ERROR FOUND DURING DMA TX.
7724
7725      ;+
7726      ; WAIT FOR DMA TO COMPLETE. THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
7727      ; THE FIFO.
7728 033560 005267 150266      INC      ERRNBR              ;SET ERROR NUMBER TO 6603.
7729 033564 012701 170536      MOV      #170536,R1         ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
7730 033570 016702 146432      MOV      CSRA,R2            ;PASS THE ADDRESS OF THE CSR.
7731 033574 004767 163636      JSR      PC,WAIBIS          ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
7732 033600 103146              BCC      50$                 ;ABORT THE TEST IF TIME-OUT ON DMA COMPLETION.
7733 033602 012704 000005      MOV      #5,R4              ;PASS DELAY OF 5 MILLI SECS.
7734 033606 004767 160450      JSR      PC,DELAY           ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
7735
7736      ;+
7737      ; TRANSMIT 4 CHARACTERS ON EACH ACTIVE LINE.
7738      ;-
7739 033612 016705 146402      MOV      ACTLNS,R5          ;ALTER PARAMETERS FOR ALL ACTIVE LINES.
7740 033616 012700 000204      MOV      #204,R0            ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
7741 033622 004767 163724      JSR      PC,WTWLNCR         ;INITIALISE THE LINE CONTROL REGISTER.
7742 033626 012700 177670      MOV      #177670,R0         ;PASS THE LPR CONTENTS.
7743 033632 004767 163744      JSR      PC,WTWLPRA         ;SET THE LPR CONTENTS TO 38.4K BAUD.
7744 033636 012704 000012      MOV      #10,R4             ;PASS DELAY TIME OF 10 MILLI SECONDS.
7745 033642 004767 160414      JSR      PC,DELAY           ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
7746
7747 033646 012702 002650      MOV      #BUF BAS,R2        ;PASS THE START OF THE DATA PATTERN TO TX.
7748 033652 012703 000004      MOV      #4,R3              ;PASS THE LENGTH OF THE DATA PATTERN.
7749 033656 005001              CLR      R1                  ;CLEAR THE LINE COUNTER.
7750 033660 005267 150166      INC      ERRNBR              ;SET ERROR NUMBER TO 6604.
7751 033664 010100      2$:    MOV      R1,R0
7752 033666 006300      ASL      R0                  ;CALCULATE THE LINE OFFSET FROM THE LINE #.
7753 033670 036067 002336 146322  BIT      BITTBL(R0),ACTLNS ;TEST FOR THIS LINE BEING ACTIVE.
7754 033676 001403      BEQ      4$                 ;SKIP THE TX ON THIS LINE IF IT IS NOT ACTIVE.
7755 033700 004767 160474      JSR      PC,DODMA           ;TRANSMIT THE 5 CHAR DATA PATTERN.
7756 033704 103104              BCC      50$                 ;ABORT IF ERROR FOUND DURING DMA TX.
7757 033706 005201      4$:    INC      R1              ;INCREMENT THE LINE COUNTER.
7758 033710 020127 000020      CMP      R1,#NUMLNS         ;TEST FOR ALL POSSIBLE LINES HANDLED
7759 033714 002763      BLT      2$                 ;LOOP IF NOT ALL LINES HANDLED.
7760
7761 033716 005267 150130      INC      ERRNBR              ;SET ERROR NUMBER TO 6605.
7762 033722 012701 170040      MOV      #170040,R1         ;PASS TIME-OUT VALUE OF 32 MILLI SECS.
7763 033726 016702 146274      MOV      CSRA,R2            ;PASS THE ADDRESS OF THE CSR.
7764 033732 004767 163500      JSR      PC,WAIBIS          ;WAIT FOR A DMA TO COMPLETE, TX_ACTION SET.
7765 033736 103067              BCC      50$                 ;ABORT THE TEST IF TIME-OUT ON DMA COMPLETION.
7766 033740 012704 000005      MOV      #5,R4              ;PASS DELAY OF 5 MILLI SECS.
7767 033744 004767 160312      JSR      PC,DELAY           ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
7768
7769      ;+
7770      ; READ THE FIFO CHECKING FOR OVERRUN ERRORS. REPORT ERRORS IF FOUND.
7771      ; ABORT THE TEST IF A BMP CODE WAS FOUND IN THE FIFO.
7772      ;-
7772 033750 016702 146244      MOV      ACTLNS,R2
7773 033754 004767 160716      JSR      PC,MAPCNT         ;GET THE NUMBER OF ACTIVE LINES.
7774 033760 006302      ASL      R2
7775 033762 006302      ASL      R2                  ;MULTIPLY NUMBER OF ACTIVE LINES BY 4.
7776 033764 012705 000400      MOV      #256,R5
7777 033770 060205      ADD      R2,R5              ;CALCULATE NUMBER OF CHARACTERS TO RX.

```



```

7824 .SBTTL HARDWARE TEST - ORERR
7825 ;-----
7826 ; - OVERRUN ERROR TEST -
7827 ;
7828 ; THIS TEST VERIFIES THAT THE DUT WILL REPORT DATA OVERRUN ERRORS WHEN
7829 ; THEY OCCUR.
7830 ; THIS TEST PUTS 256 CHARACTERS IN THE DUT FIFO PLUS 5 IN EACH ACTIVE
7831 ; UART AND VERIFIES THAT OVERRUN ERRORS ARE REPORTED ON ALL ACTIVE LINES.
7832 ; ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
7833 ; HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
7834 ; REPORTED LATER.
7835 ;
7836 ;-----
7837
7838 034130 BGMTST
7839 034130 SETPRI @PRI05 ;ALLOW LTC INTERRUPTS. T19::
7840 034130 MOV @PRI05,R0
7841 034130 TRAP C1SPRI
7842 034134 012700 000240 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
7843 034134 000023 MOV @TNUM,TSTNUM ;SET UP THE TEST NUMBER. (67)
7844 034136 012767 177777 146110 MOV @-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
7845 034144 012767 060001 146076 MOV @1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
7846 034152 012767 015055 147670 MOV @6701,ERRNBR ;SET ERROR NUMBER TO 6701.
7847 034160 012767 010514 147664 MOV @EM6701,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERRCR TABLE.
7848 ;
7849 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
7850 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
7851 ; THIS SUBROUTINE REPORTS ERROR >>>> 6701 <<<<.
7852 ;
7853 034174 004767 160016 JSR PC,CLRST ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
7854 034200 103402 BCS .+6 ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
7855 034202 000167 000660 JMP 609 ;EXIT THE TEST, FATAL ERROR WAS FOUND.
7856 ;
7857 ; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
7858 ; INITIALIZE THE 256 BYTE DATA PATTERN.
7859 ;
7860 034206 004767 160256 JSR PC,FINACT ;FIND AN ACTIVE LINE.
7861 034212 103402 BCS .+6 ;IF ACTIVE LINE IS FOUND, DON'T ABORT TEST.
7862 034214 000167 000646 JMP 609 ;ABORT THE TEST, NO ACTIVE LINES WERE FOUND.
7863 034220 004767 160324 JSR PC,INDATP ;INITIALISE DATA PATTERN.
7864 ;
7865 ; TRANSMIT A 265 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
7866 ; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
7867 ;
7868 ; SET INTERNAL LOOPBACK ON THE SELECTED LINE.
7869 ; TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
7870 ;
7871 034224 005267 147622 INC ERRNBR ;SET ERROR NUMBER TO 6702.
7872 034230 012700 000204 MOV @204,R0 ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
7873 034234 004767 163312 JSR PC,WTMLNC ;INITILAISE THE LINE CONTROL REGISTER.
7874 034240 012700 177670 MOV @177670,R0 ;PASS THE LPR CONTENTS.
7875 034244 004767 163332 JSR PC,WTMLPR ;SET THE LPR CONTENTS TO 38.4K BAUD.
7876 034250 012704 000012 MOV @10,R4 ;PASS DELAY TIME OF 10 MILLI SECONDS.
7877 034254 004767 160002 JSR PC,DELAY ;WAIT FOR LNCRTL AND LPR REGS TO BE UPDATED.
7878 034260 012702 002650 MOV @BUFAS,R2 ;PASS THE START OF THE DATA PATTERN TO Tx.
    
```

010

```

7878 034264 012703 000400      MOV    #BUF MID BUF BAS,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
7879 034270 004767 160104      JSR    PC,DODMA             ;TRANSMIT THE DATA PATTERN.
7880 034274 103402              BCS    .+6                 ;IF NO ERROR FOUND DURING DMA TX, DON'T ABORT.
7881 034276 000167 000560      JMP    50$                 ;ABORT TEST, ERROR FOUND DURING DMA TX.
7882
7883 ;
7884 ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
7885 ; THE FIFO.
7886 034302 005267 147544      INC    ERRNBR              ;SET ERROR NUMBER TO 6703.
7887 034306 012701 170536      MOV    #170536,R1         ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
7888 034312 016702 145710      MOV    CSRA,R2            ;PASS THE ADDRESS OF THE CSR.
7889 034316 004767 163114      JSR    PC,WAIBIS          ;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
7890 034322 103402              BCS    .+6                 ;IF NO TIME-OUT ON DMA COMPLETION, DON'T ABORT.
7891 034324 000167 000532      JMP    50$                 ;ABORT TEST, TIME-OUT ON DMA COMPLETION.
7892 034330 012704 000005      MOV    #5,R4              ;PASS DELAY OF 5 MILLI SECS.
7893 034334 004767 157722      JSR    PC,DELAY           ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
7894
7895 ;
7896 ; TRANSMIT 5 CHARACTERS ON EACH ACTIVE LINE.
7897
7898      MOV    ACTLNS,R5       ;ALTER PARAMETERS FOR ALL ACTIVE LINES.
7899      MOV    #204,R0        ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
7900      JSR    PC,WTWLNCR    ;INITIALISE THE LINE CONTROL REGISTER.
7901      MOV    #177670,R0    ;PASS THE LPR CONTENTS.
7902      JSR    PC,WTWLPRL    ;SET THE LPR CONTENTS TO 38.4K BAUD.
7903      MOV    #10,R4        ;PASS DELAY TIME OF 10 MILLI SECONDS.
7904      JSR    PC,DELAY       ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
7905
7906      MOV    #BUF BAS,R2   ;PASS THE START OF THE DATA PATTERN TO TX.
7907      MOV    #5,R3         ;PASS THE LENGTH OF THE DATA PATTERN.
7908      CLR    R1            ;CLEAR THE LINE COUNTER.
7909      INC    ERRNBR       ;SET ERROR NUMBER TO 6704.
7910      MOV    R1,R0        ;
7911      ASL    R0           ;CALCULATE LINE OFFSET FROM THE LINE #.
7912      BIT    BITTBL(R0),ACTLNS ;TEST FOR THIS LINE BEING ACTIVE.
7913      BEQ    4$          ;SKIP THE TX ON THIS LINE IF IT IS NOT ACTIVE.
7914      JSR    PC,DODMA     ;TRANSMIT THE 5 CHAR DATA PATTERN.
7915      BCS    .+6         ;IF NO TIME-OUT ON DMA COMPLETION, DON'T ABORT.
7916      JMP    50$         ;ABORT TEST, TIME-OUT ON DMA COMPLETION.
7917      INC    R1          ;INCREMENT THE LINE NUMBER COUNTER.
7918      CMP    R1,#NUMLNS  ;TEST FOR ALL POSSIBLE LINES HANDLED
7919      BLT    2$          ;LOOP IF NOT ALL LINES HANDLED.
7920
7921      INC    ERRNBR       ;SET ERROR NUMBER TO 6705.
7922      MOV    #170040,R1   ;PASS TIME-OUT VALUE OF 32 MILLI SECS.
7923      MOV    CSRA,R2     ;PASS THE ADDRESS OF THE CSR.
7924      JSR    PC,WAIBIS   ;WAIT FOR A DMA TO COMPLETE, TX ACTION SET.
7925      BCC    50$        ;ABORT THE TEST IF TIME-OUT ON DMA COMPLETION.
7926      MOV    #5,R4       ;PASS DELAY OF 5 MILLI SECS.
7927      JSR    PC,DELAY     ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
7928
7929 ;
7930 ; READ 256 CHARS FROM THE FIFO CHECKING FOR BMP CODES.
7931 ; ABORT THE TEST IF A BMP CODE WAS FOUND IN THE FIFO.
7932
7933      MOV    #256,R4      ;SET UP THE CHARACTER COUNTER.
7934      MOV    #6706,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
7935      MOV    BRBUFA,R2   ;READ A CHARACTER FROM THE FIFO.
7936      BPL    50$        ;ABORT THE TEST IF DATA.VALID IS CLEAR.

```

145574

147336

D16

```

7935 034522 005267 147324          INC      ERRNBR      ;SET ERROR NUMBER TO 6707.
7936 034526 004767 157244          JSR      PC,CHKBMP   ;CHECK IF CHARACTER IS A BMP CODE.
7937 034532 103551                   BCS     24$          ;REPORT ERROR AND ABORT TEST IF A BMP CODE.
7938 034534 005304                   DEC     R4           ;COUNT THIS CHARACTER.
7939 034536 001363                   BNE     6$          ;LOOP IF NOT 256 CHARS READ FROM FIFO.
7940
7941          ; READ THE REMAINING AND VERIFY 1 OVERRUN PLUS 1 CHAR FROM EACH LINE.
7942
7943 034540 005004                   CLR     R4           ;CLEAR THE OVERRUN ERROR FLAGS.
7944 034542 012700 003710          MOV     @RXCNTB,R0   ;CLEAR RX CHAR COUNT TABLE.
7945 034546 004767 157466          JSR     PC,CLR16W    ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
7946 034552 012767 015064 147272 8$:  MOV     @6708,ERRNBR ;READ A CHARACTER FROM THE FIFO.
7947 034560 017702 145444          MOV     @RBUFA,R2   ;GO ANALYZE THE RESULTS IF ALL CHARS READ.
7948 034564 100047                   BPL     14$          ;CHECK IF CHAR IS A BMP CODE.
7949 034566 004767 157204          JSR     PC,CHKBMP   ;REPORT ERROR AND ABORT TEST IF A BMP CODE.
7950 034572 103551                   BCS     24$          ;SET ERROR NUMBER TO 6709.
7951 034574 005267 147252          INC     ERRNBR
7952 034600 010200                   MOV     R2,R0
7953 034602 000300                   SWAB   R0
7954 034604 042700 177760          BIC     @177760,R0  ;CALCULATE THE LINE NUMBER OF THE CHAR.
7955 034610 006300                   ASL     R0           ;FORM WORD TABLE OFFSET FOR TABLE ACCESS.
7956 034612 042702 007400          BIC     @7400,R2    ;REMOVE LINE NUMBER FROM THE READ CHAR.
7957 034616 036067 002336 145374          BIT     BITTBL(R0),ACTLNS ;TEST FOR ACTIVE LINE.
7958 034624 001516                   BEQ     50$          ;ABORT TEST IF FOR INACTIVE LINE.
7959 034626 005267 147220          INC     ERRNBR      ;SET ERROR NUMBER TO 6710.
7960 034632 005760 003710          TST     RXCNTB(R0)  ;CHECK THE RX CHAR COUNTER FOR THIS LINE.
7961 034636 001006                   BNE     10$          ;IS THIS FIRST CHAR ON LINE?
7962 034640 020227 140000          CMP     R2,@140000 ;YES, TEST FOR NULL CHAR WITH OVERRUN.
7963 034644 001414                   BEQ     12$          ;IS CHAR A NULL?
7964 034646 056004 002336          BIS     BITTBL(R0),R4 ;NO, SET THE OVERRUN BIT ERROR FLAG FOR LINE.
7965 034652 000411                   BR      12$          ;GO COUNT THE CHAR AND CONTINUE.
7966 034654 026027 003710 000004 10$:  CMP     RXCNTB(R0),#50 ;5TH CHAR ON THIS LINE? YES, ABORT.
7967 034662 002077                   BGE     50$
7968 034664 032702 040000          BIT     @BIT14,R2   ;NO, CHECK OVERRUN BIT.
7969 034670 001402                   BEQ     12$          ;IS OVERRUN BIT CLEAR? YES, GO COUNT CHAR.
7970 034672 056004 002336          BIS     BITTBL(R0),R4 ;NO, SET THE OVERRUN BIT ERROR FLAG FOR LINE.
7971 034676 005260 003710 12$:  INC     RXCNTB(R0)  ;COUNT THIS CHARACTER.
7972 034702 000723                   BR      8$          ;LOOP UNTIL ALL CHARS ARE READ FROM FIFO.
7973
7974          ; TEST FOR ABORT CONDITIONS. ONLY NONE ABORT CONDITIONS ARE:
7975          ; 1) 2 CHARS RXED ON A LINE AND NO OVERRUN ERROR BIT FAILURE DETECTED.
7976          ; 2) 2 TO 4 CHARS RXED ON A LINE AND AN OVERRUN BIT FAILURE DETECTED.
7977
7978 034704 005001 147136 14$:  CLR     R1           ;INITIALIZE LINE LOOP, CLEAR LINE OFFSET.
7979 034706 012767 015067 147136 16$:  MOV     @6711,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
7980 034714 036167 002336 145276          BIT     BITTBL(R1),ACTLNS
7981 034722 001415                   BEQ     18$          ;LINE ACTIVE? NO, NEXT LINE.
7982 034724 026127 003710 000002          CMP     RXCNTB(R1),#2 ;YES.
7983 034732 002453                   BLT     50$          ;FEWER THAN 2 CHARS RXED? YES, ABORT.
7984 034734 036104 002336          BIT     BITTBL(R1),R4 ;NO.
7985 034740 001006                   BNE     18$          ;OVERRUN BIT ERROR FLAG SET? YES, NEXT LINE.
7986 034742 005267 147104          INC     ERRNBR      ;SET LINE NUMBER TO 6712.
7987 034746 026127 003710 000002          CMP     RXCNTB(R1),#2
7988 034754 001042                   BNE     50$          ;NOT 2 CHARS RXED? YES, ABORT. NO, NEXT LINE.
7989 034756 062701 000002 18$:  ADD     @2,R1        ;SET LINE OFFSET TO THE NEXT LINE.
7990 034762 020127 000040          CMP     R1,@NUMLNS+2
7991 034766 002747                   BLT     16$          ;ALL LINES DONE? NO, LOOP. YES, CONTINUE.

```

```

7992
7993          ; CHECK FOR OVERRUN ERROR BIT FAILURES, PRINT ERROR MESSAGE IF FOUND.
7994          ;
7995 034770 012767 015071 147054          MOV    #6713,ERRNBR ;SET UP ERROR NUMBER.
7996 034776 005001                          CLR    R1           ;INITIALIZE LOOP. CLEAR LINE OFFSET.
7997 035000 010102                          MOV    R1,R2       ;COPY THE LINE OFFSET.
7998 035002 036104 002336          20%:  BIT    BITTBL(R1),R4 ;OVERRUN BIT FAILURE FLAGS ARE IN R4.
7999 035006 001415                          BEQ    22%         ;ERROR FLAG CLEAR? YES, NEXT LINE.
8000 035010 010103                          MOV    R1,R3
8001 035012 006203                          ASR    R3           ;CALCULATE LINE NUMBER FROM LINE OFFSET.
8002 035014 012767 012506 147034          MOV    #ER7801,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
8003 035022 012701 010546          MOV    #EM6702,R1  ;PASS THE MESSAGE TO BE REPORTED.
8004          ;REPORT "OVERRUN ERROR NOT REPORTED CORRECTLY WHEN FORCED, ON LINE NN ...
8005 035026          ERROR                      ;          >>>> ERROR #6713 <<<<<.
          035026 104460                          TRAP   C#ERROR
8006
8007          ;
8008          ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLD
8009          ;
8010 035030 032767 000100 145152          BIT    #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
8011 035036 001413                          BEQ    60%         ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
8012          ;DURING THE SOFTWARE QUESTIONS.
8013
8014 035040 010201                          MOV    R2,R1       ;RESTORE THE LINE OFFSET THAT WAS DESTROYED.
8015 035042 046104 002336          22%:  BIC    BITTBL(R1),R4 ;CLEAR THE LINE ERROR FLAG WE JUST HANDLED.
8016 035046 001407                          BEQ    60%         ;ALL FAILURE BITS HANDLED? YES, EXIT TEST.
8017 035050 062701 000002          ADD    #2,R1       ;NO, INCREMENT THE LINE OFFSET.
8018 035054 000751                          BR     20%         ;LOOP TO HANDLE THE NEXT LINE.
8019
8020 035056          24%:  ;REPORT "BMP CODE FOUND IN FIFO, TEST INVAILEDATED."
8021 035056          ERROR                      ;          >>>> ERROR <<<<<.
          035056 104460                          TRAP   C#ERROR
8022 035060 000402                          BR     60%         ;EXIT THIS TEST.
8023
8024 035062 004767 161604          50%:  JSR    PC,TSABRT ;ABORT THE TEST. ERROR # INDICATES FAULT TYPE.
8025 035066 005067 145156          60%:  CLR    CTRLCF   ;INDICATE THAT WE ARE NOT WITHIN A TEST.
8026
8027          ENDTST
          035072          L10050:
          035072          TRAP   C#ETST
          035072 104401
    
```

```

8029 .SBTTL HARDWARE TEST REP8MP -
8030 ;* *****
8031 ;* - REPORT ANY BMP CODES IN THE QUEUE -
8032 ;* THIS IS A PSEUDO-TEST USED TO REPORT ANY BMP CODES THAT WERE FOUND
8033 ;* IN THE DUT'S FIFO DURING PREVIOUS TEST, AND LOGGED IN THE BMP CODE
8034 ;* QUEUE.
8035 ;* IF IS UNLIKELY THAT RUNNING THIS PSEUDO-TEST ALONE WILL PRODUCE ANY
8036 ;* ERROR REPORTS.
8037 ;*
8038 ;-- *****
8039 035074 BGNTST
      035074
8040 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
8041 035074 012767 000024 145152 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (93)
8042 035102 012767 177777 145140 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
8043 035110 016702 145274 MOV BMPCQP,R2 ;GET THE CONTENTS OF THE POINTER.
8044 035114 012703 002412 MOV #BMPCQB,R3 ;GET THE START ADDRESS OF THE QUEUE.
8045 035120 020203 CMP R2,R3 ;SEE IF THE POINTER HAS MOVED FROM THE BASE.
8046 035122 001411 BEQ 60$ ;EXIT NO CODES IN THE QUEUE.
8047 ;*
8048 ; THERE IS AT LEAST ONE BMP CODE IN THE QUEUE. REPORT THE ERROR.
8049 ;--
8050 ;REPORT ERROR BMP CODE FOUND IN TEST NN, BMP CODE:NNNNNN"
8051
8052 035124 012701 011354 MOV #EM9304,R1 ;PASS THE FIRST MESSAGE TO BE REORTED.
8053 035130 ERRDF 9301,EM9301,ER9301 ; >>>>> ERROR #9301 <<<<<.
      035130 104455 TRAP C#ERDF
      035132 022125 .WORD 9301
      035134 011200 .WORD EM9301
      035136 013176 .WORD ER9301
8054
8055 035140 012767 002412 145242 MOV #BMPCQB,BMPCQP ;SET POINTER BACK TO THE BEGINING OF THE QUE.
8056
8057 035146 005067 145076 60$: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
8058 035152 ENDTST
      035152 104401 L10051: TRAP C#ETST
    
```


516

```

8067
8068
8069          .SBTTL  HARDWARE PARAMETER CODING SECTION
8070
8071
8072
8073          ;**
8074          ; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
8075          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
8076          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
8077          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
8078          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
8079          ; WITH THE OPERATOR.
8080          ;--
8081
8082          BGNHRD
8083
8084          035154      000022
8085          035154
8086          035156
8087
8088          ;DEVICE CSR ADDRESS QUESTION:
8089          GPRMA  HWPTQ1,0,0,160000,177776,YES
8090
8091          035156      000031
8092          035160      035222
8093          035162      160000
8094          035164      177776
8095
8096          ;DEVICE INTERRUPT VECTOR QUESTION:
8097          GPRMA  HWPTQ2,2,0,40,776,YES
8098
8099          035166      001031
8100          035170      035240
8101          035172      000040
8102          035174      000776
8103
8104          ;ACTIVE LINES BIT MAP QUESTION:
8105          GPRMD  HWPTQ3,4,0,MAPLNS,0,177777,YES
8106
8107          035176      002032
8108          035200      035273
8109          035202      177777
8110          035204      000000
8111          035206      177777
8112
8113          ;TYPE OF LOOPBACK QUESTION:
8114          GPRMD  HWPTQ4,6,0,377,1,2,YES
8115
8116          035210      003032
8117          035212      035321
8118          035214      000377
8119          035216      000001
8120          035220      000007
8121
8122          8101
8123          8102
8124          8103      035222
8125
8126          035222
8127
8128          8104
8129          8111
8130          8112      035222      103      123      122      HWPTQ1: .ASCIZ  /CSR ADDRESS: /
8131          035225      040      101      104
8132          035230      104      122      105
8133          035233      123      123      072
8134          035236      040      000

```

.WORD L10052 L\$HARD/2
L\$HARD::

.WORD T\$CODE
.WORD HWPTQ1
.WORD T\$LLOLIM
.WORD T\$HILIM

.WORD T\$CODE
.WORD HWPTQ2
.WORD T\$LLOLIM
.WORD T\$HILIM

.WORD T\$CODE
.WORD HWPTQ3
.WORD MAPLNS
.WORD T\$LLOLIM
.WORD T\$HILIM

.WORD T\$CODE
.WORD HWPTQ4
.WORD 377
.WORD T\$LLOLIM
.WORD T\$HILIM

.EVEN
L10052:

8113	035240	111	116	124	HWPTQ2: .ASCIZ /INTERRUPT VECTOR ADDRESS: /
	035243	105	122	122	
	035246	125	120	124	
	035251	040	126	105	
	035254	103	124	117	
	035257	122	040	101	
	035262	104	104	122	
	035265	105	123	123	
	035270	072	040	000	
8114	035273	101	103	124	HWPTQ3: .ASCIZ /ACTIVE LINE BIT MAP: /
	035276	111	126	105	
	035301	040	114	111	
	035304	116	105	040	
	035307	102	111	124	
	035312	040	115	101	
	035315	120	072	040	
	035320	000			
8115	035321	124	131	120	HWPTQ4: .ASCIZ /TYPE OF LOOPBACK (1=INTERNAL, 2=M3029 OR M3277): /
	035324	105	040	117	
	035327	106	040	114	
	035332	117	117	120	
	035335	102	101	103	
	035340	113	040	050	
	035343	061	075	111	
	035346	116	124	105	
	035351	122	116	101	
	035354	114	054	040	
	035357	062	075	110	
	035362	063	060	062	
	035365	071	040	117	
	035370	122	040	110	
	035373	063	062	067	
	035376	067	051	072	
	035401	000			

8116
8117

.EVEN

```

8126
8127
8128
8129
8130
8131
8132
8133
8134
8135
8136
8137
8138
3139 035402          BGNSFT
      035402 000014
      035404
                                     .WORD L10053 L$SOFT/2
                                     L$SOFT::

8140
8149
8150 035404          ;UNIT NUMBER PRINTOUT QUESTION:
      035404 000130      GPRML SWPTQ1,0,20,YES
      035406 035434
      035410 000020
                                     .WORD T$CODE
                                     .WORD SWPTQ1
                                     .WORD 20

8151
8152 035412          ;EXTENDED ERROR REPORTING QUESTION:
      035412 000130      GPRML SWPTQ2,0,100,YES
      035414 035510
      035416 000100
                                     .WORD T$CODE
                                     .WORD SWPTQ2
                                     .WORD 100

8153
8154
8155
8156 035420          ;*
      035420 006044      ; IF EXTENDED ERROR REPORTING IS NOT REQUIRED THEN SKIP THE NEXT QUESTION.
      ;*
      XFERF ENDD
                                     .WORD T$CODE

8157
8158
8159 035422          ;NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE QUESTION:
      035422 001052      GPRMD SWPTQ3,2,0,17777,0,17777,YES
      035424 035543
      035426 177777
      035430 000000
      035432 177777
                                     .WORD T$CODE
                                     .WORD SWPTQ3
                                     .WORD 177777
                                     .WORD T$LOLIM
                                     .WORD T$HILIM

8160
8161
8162
8163 035434          .EVEN
      ENDD: ENDSFT
                                     .EVEN
                                     L10053:

8164
8165
8172 035434          SWPTQ1: .ASCIZ /REPORT UNIT NUMBER AS EACH UNIT IS TESTED: /
      035437 122 105 120
      035442 117 122 124
      035445 040 125 116
      035445 111 124 040
      035450 116 125 115
      035453 102 105 122
      035456 040 101 123
      035461 040 105 101
      035464 103 110 040
    
```

	035467	125	116	111
	035472	124	040	111
	035475	123	040	124
	035500	105	123	124
	035503	105	104	072
8173	035506	040	000	
	035510	105	130	124
	035513	105	116	104
	035516	105	104	040
	035521	105	122	122
	035524	117	122	040
	035527	122	105	120
	035532	117	122	124
	035535	111	116	107
	035540	072	040	000
8174	035543	116	125	115
	035546	102	105	122
	035551	040	117	106
	035554	040	111	116
	035557	104	111	126
	035562	111	104	125
	035565	101	114	040
	035570	104	101	124
	035573	101	040	105
	035576	122	122	117
	035601	122	123	040
	035604	124	117	040
	035607	122	105	120
	035612	117	122	124
	035615	040	117	116
	035620	040	101	040
	035623	114	111	116
	035626	105	072	040
8175	035631	000		

SWPTQ2: .ASCIZ /EXTENDED ERROR REPORTING: /

SWPTQ3: .ASCIZ /NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE: /

.EVEN

```

8184
8185
8186 035632          $PATCH::
8187 035632          .BLKW  24
8188
8195
8196
8197
8198
8199 035702          LASTAD
                                .EVEN
                                .WORD  0
                                .WORD  0
                                035702 000000
                                035704 000000
                                035706
8200 035706          L$LAST::
                                ENDMOD
8201
8202
8203
8204
8205
8206
8207
8208          000001          .END

```

ACTLNS	002220	G	CTRLCF	002250	G	DMABUF	014322	G	EM5804	007201	G	FDATA	000006	G
ADR	000020	G	C\$AU	000052		DODMA	014400	G	EM5805	007265	G	FINACT	014470	G
ADRPTR	014200	G	C\$AUTO	000061		DRADRT	002226	G	EM5901	007346	G	FSLSA	002234	G
ALTFLD	013370	G	C\$BRK	000022		DROP	020730		EM5902	007402	G	FSLSO	000006	G
ASLNTL	013442	G	C\$BSEG	000004		EDROP	021006		EM5903	007476	G	F\$AU	000015	
ASSEMB	000010		C\$BSUB	000002		EF.CON	000036	G	EM5904	007570	G	F\$AUTO	000020	
BCOUNT	002322	G	C\$CEFG	000045		EF.NEW	000035	G	EM5905	007654	G	F\$BGN	000040	
BITTBL	002336	G	C\$CLCK	000062		EF.PWR	000034	G	EM6001	007754	G	F\$CLEA	000007	
BIT0	000001	G	C\$CLEA	000012		EF.RES	000037	G	EM6002	010000	G	F\$DU	000016	
BIT00	000001	G	C\$CLOS	000035		EF.STA	000040	G	EM6003	010040	G	F\$END	000041	
BIT01	000002	G	C\$CLP1	000006		EF0503	004156	G	EM6004	010120	G	F\$HARD	000004	
BIT02	000004	G	C\$CVEC	000036		EF1601	004163	G	EM6005	010165	G	F\$HW	000013	
BIT03	000010	G	C\$DCLN	000044		EF5801	004215	G	EM6006	010243	G	F\$INIT	000006	
BIT04	000020	G	C\$DODU	000051		EF5901	004270	G	EM6401	010307	G	F\$JMP	000050	
BIT05	000040	G	C\$DRPT	000024		EF5902	004320	G	EM6402	010344	G	F\$MOD	000000	
BIT06	000100	G	C\$DU	000053		EF6401	004350	G	EM6601	010405	G	F\$MSG	000011	
BIT07	000200	G	C\$EDIT	000003		EF7801	004417	G	EM6602	010442	G	F\$PRDT	000021	
BIT08	000400	G	C\$ERDF	000055		EF9001	004455	G	EM6701	010514	G	F\$PWR	000017	
BIT09	001000	G	C\$ERNR	000056		EF9002	004537	G	EM6702	010546	G	F\$RPT	000012	
BIT1	000002	G	C\$ERR0	000060		EF9003	004611	G	EM9009	010623	G	F\$SEG	000003	
BIT10	002000	G	C\$ERSF	000054		EF9004	004640	G	EM9010	010647	G	F\$SOFT	000005	
BIT11	004000	G	C\$ERSO	000057		EF9005	004670	G	EM9014	010673	G	F\$SRV	000010	
BIT12	010000	G	C\$ESCA	000010		EF9006	004721	G	EM9017	010767	G	F\$SUB	000002	
BIT13	020000	G	C\$ESEG	000005		EF9010	004745	G	EM9026	011100	G	F\$SW	000014	
BIT14	040000	G	C\$ESUB	000003		EF9019	005034	G	EM9104	011124	G	F\$TEST	000001	
BIT15	100000	G	C\$ETST	000001		EF9301	005053	G	EM9301	011200	G	GETPRM	020446	
BIT2	000004	G	C\$EXIT	000032		EF9302	005131	G	EM9302	011257	G	GPRSOB	002376	G
BIT3	000010	G	C\$GETB	000026		EM0101	015124	G	EM9303	011307	G	G\$CNT0	000200	
BIT4	000020	G	C\$GETW	000027		EM0102	015210	G	EM9304	011354	G	G\$DELM	000372	
BIT5	000040	G	C\$GMAN	000043		EM0103	005262	G	END0	035434		G\$DISP	000003	
BIT6	000100	G	C\$GPHR	000042		EM1601	005320	G	ENDETB	003650	G	G\$EXCP	000400	
BIT7	000200	G	C\$GPLO	000030		EM4001	005403	G	ENDIT	020650		G\$HILI	000002	
BIT8	000400	G	C\$GPRI	000040		EM4002	005435	G	ERCNTB	002614	G	G\$LOLI	000001	
BIT9	001000	G	C\$INIT	000011		EM4101	005471	G	ERLTBL	002650	G	G\$NO	000000	
BMPQCB	002412	G	C\$INLP	000020		EM4102	005523	G	ERRBLK	004056	G	G\$OFFS	000400	
BMPQCE	002612	G	C\$MANI	000050		EM4103	005557	G	ERRMSG	004054	G	G\$OF SI	000376	
BMPQCP	002410	G	C\$MEM	000031		EM4201	005643	G	ERRNBR	004052	G	G\$PRMA	000001	
BOE	000400	G	C\$MSG	000023		EM4202	005675	G	ERRTYP	004050	G	G\$PRMD	000002	
BRLEVL	002223	G	C\$OPEN	000034		EM4901	005717	G	ERSHRF	002612	G	G\$PRML	000000	
BUFBAS	002650	G	C\$PNTB	000014		EM4902	005760	G	ER0101	011430	G	G\$RADA	000140	
BUFEND	003650	G	C\$PNTF	000017		EM5001	006012	G	ER0503	011762	G	G\$RADB	000000	
BUF MID	003250	G	C\$PNTS	000016		EM5101	006051	G	ER1603	012020	G	G\$RADD	000040	
BUF PTR	002246	G	C\$PNTX	000015		EM5102	006106	G	ER5801	012112	G	G\$RADL	000120	
BUF3QT	003450	G	C\$QIO	000377		EM5103	006144	G	ER5901	012170	G	G\$RADO	000020	
CALMSL	013552	G	C\$RDBU	000007		EM5201	006174	G	ER6001	012276	G	G\$XFER	000004	
CHKBMP	013776	G	C\$REFG	000047		EM5202	006227	G	ER6401	012400	G	G\$YES	000010	
CKRX TM	014046	G	C\$RESE	000033		EM5301	006265	G	ER7801	012506	G	HELP	000000	
CKTRAP	014166	G	C\$REVI	000003		EM5302	006321	G	ER9001	012544	G	HOE	100000	G
CLKBRL	002306	G	C\$RFLA	000021		EM5303	006401	G	ER9002	012644	G	HMPTQ1	035222	
CLKCSR	002304	G	C\$RPT	000025		EM5401	006452	G	ER9004	013022	G	HMPTQ2	035240	
CLKHRZ	002312	G	C\$SEFG	000046		EM5402	006520	G	ER9101	013136	G	HMPTQ3	035273	
CLKINT	017632	G	C\$SPRI	000041		EM5501	006561	G	ER9301	013176	G	HMPTQ4	035321	
CLKVEC	002310	G	C\$SVEC	000037		EM5601	006625	G	EVL	000004	G	IBE	010000	G
CLNRST	014216	G	C\$TPRI	000013		EM5701	006702	G	EXOERR	002252	G	IDU	000040	G
CLR16W	014240	G	DELAY	014262	G	EM5801	006757	G	E\$END	002100		IER	020000	G
CSRA	002226	G	DFPTBL	002176	G	EM5802	007003	G	E\$LOAD	000035		IESTAT	002256	G
CSRO	000000	G	DIAGMC	000000		EM5803	007077	G	FDATA	002234	G	INDATP	014550	G

INDTPX	014600	G	L\$EXP4	002064	G	L10034	024714	PRI06	=	000300	G	TXBFCA	002244	G			
ISR	=	000100	G	L\$EXP5	002066	G	L10035	025406	PRI07	=	000340	G	TXBFCD	=	000016	G	
IXE	=	004000	G	L\$HARD	035156	G	L10036	025714	PRTLPR	015306	G	TXDATP	017004	G			
I\$AU	=	000041	L\$HIME	002120	G	L10037	026224	PUFIFO	015370	G	TXDSBL	017026	G				
I\$AUTO	=	000041	L\$HPCP	002016	G	L10040	026724	PUFIFR	015452	G	TXENBL	017122	G				
I\$CLN	=	000041	L\$HPTP	002022	G	L10041	027422	RBUFA	002230	G	TXIEO	017216	G				
I\$DU	=	000041	L\$HW	002176	G	L10042	030100	RBUFO	=	000002	G	TXIE1	017256	G			
I\$HRD	=	000041	L\$ICP	002104	G	L10043	031150	READBX	015654	G	TXINTC	002272	G				
I\$INIT	=	000041	L\$INIT	020044	G	L10044	031736	REPDER	015736	G	TXINTF	002274	G				
I\$MOD	=	000041	L\$LADP	002026	G	L10045	032764	REPSMR	016254	G	TXRLNB	004010	G				
I\$MSG	=	000041	L\$LAST	035706	G	L10046	033410	RESET	016302	G	TXRLNE	004030	G				
I\$PROT	=	000040	L\$LOAD	002100	G	L10047	034126	RXBOTX	=	000030	G	TXRXLB	003750	G			
I\$PTAB	=	000041	L\$LUN	002074	G	L10050	035072	RXBETX	=	000020	G	TXRXLE	004010	G			
I\$PWR	=	000041	L\$MREV	002050	G	L10051	035152	RXBFUL	=	000100	G	TXVECA	002216	G			
I\$RPT	=	000041	L\$NAME	002000	G	L10052	035222	RXCNTB	003710	G	T\$ARGC	=	000002				
I\$SEG	=	000041	L\$PRIO	002042	G	L10053	035434	RXDECT	017702	G	T\$CODE	=	001052				
I\$SETU	=	000041	L\$PROT	020036	G	MAPCNT	014676	G	RXIEO	016414	G	T\$ERRN	=	022125			
I\$SFT	=	000041	L\$PRT	002112	G	MAPLNS	=	177777	G	RXIE1	016454	G	T\$EXCP	=	000000		
I\$SRV	=	000041	L\$REPP	002062	G	MFUNIT	005231	G	RXINTC	002266	G	T\$FLAG	=	000040			
I\$SUB	=	000041	L\$REV	002010	G	MMENAB	002334	G	RXINTF	002270	G	T\$GMAN	=	000000			
I\$TST	=	000041	L\$RPT	020030	G	MPRES	002332	G	RXTIMO	=	000002	G	T\$HILI	=	177777		
J\$JMP	=	000167	L\$SOFT	035404	G	MMSRO	002330	G	RXTMA	002230	G	T\$LAST	=	000001			
LGRP1M	002260	G	L\$SPC	002056	G	MSG1	011546	G	RXVECA	002214	G	T\$LOLI	=	000000			
LGRP2M	002262	G	L\$SPCP	002020	G	MSG2	011624	G	ROSLOT	=	000002	G	T\$LSYM	=	010000		
LINBIT	014650	G	L\$SPTP	002024	G	MSG3	011703	G	R1SLOT	=	000004	G	T\$LTNO	=	000024		
LNCTRA	002236	G	L\$STA	002030	G	MSLCNT	002326	G	R2SLOT	=	000006	G	T\$NEST	=	177777		
LNCTRO	=	000010	G	L\$SW	002210	G	MSLGET	014730	G	R3SLOT	=	000010	G	T\$NSO	=	000000	
LOE	=	040000	G	L\$TEST	002114	G	MSLOOP	015044	G	R4SLOT	=	000012	G	T\$NS1	=	000005	
LOPCK	002222	G	L\$TIML	002014	G	MSTICK	002324	G	R5SLOT	=	000014	G	T\$PTNU	=	000000		
LOT	=	000010	G	L\$UNIT	002012	G	NDERPT	002212	G	SAVBMP	016500	G	T\$SAVL	=	177777		
LPCSLT	=	000036	G	L10000	002206		NEWPAS	020426		SETPAR	016546	G	T\$SEGL	=	177777		
LPRA	002232	G	L10001	002214		NEWRES	020420		SFPTBL	002210	G	T\$SUBN	=	000000			
LPRO	=	000004	G	L10002	011544		NEWSTA	020110		SKPSTS	016614	G	T\$TAGL	=	177777		
L\$ACP	002110	G	L10003	012016		NUMLNS	=	000020	G	STGTRB	004030	G	T\$TAGN	=	010054		
L\$APT	002036	G	L10004	012110		OOPS	015060	G	SVCGBL	=	000000		T\$TEMP	=	000000		
L\$AU	021014	G	L10005	012166		OPTION	002210	G	SVCINS	=	000001		T\$TEST	=	000024		
L\$AUT	002070	G	L10006	012274		O\$APTS	=	000000		SVCSUB	=	000001		T\$TSTM	=	177777	
L\$AUTO	020664	G	L10007	012376		O\$AU	=	000000		SVCTAG	=	000001		T\$TSTS	=	000001	
L\$CCP	002106	G	L10010	012504		O\$BGNR	=	000001		SVCTST	=	000001		T\$TAU	=	010025	
L\$CLEA	020666	G	L10011	012542		O\$BGNS	=	000001		SWPTQ1	035434		T\$TAUT	=	010022		
L\$CO	002032	G	L10012	012642		O\$DU	=	000001		SWPTQ2	035510		T\$TCLE	=	010023		
L\$DEPO	002011	G	L10013	013020		O\$ERRT	=	000001		SWPTQ3	035543		T\$TDU	=	010024		
L\$DESC	004130	G	L10014	013134		O\$GNSW	=	000001		S\$LSYM	=	010000		T\$THAR	=	010052	
L\$DESP	002076	G	L10015	013174		O\$POIN	=	000001		TIMER1	002314	G	T\$THW	=	010000		
L\$DEVP	002060	G	L10016	013366		O\$SETU	=	000000		TIMER2	002316	G	T\$TINI	=	010021		
L\$DISP	002124	G	L10017	020034		PASCNT	002264	G	TIMER3	002320	G	T\$TMSG	=	010016			
L\$DLY	002116	G	L10021	020662		PCSLT	=	000016	G	TNUM	=	000024	G	T\$TPRO	=	010020	
L\$DTP	002040	G	L10022	020664		PNT	=	001000	G	TP4FLG	002300	G	T\$TRPT	=	010017		
L\$DTYP	002034	G	L10023	020702		PREGRT	004102	G	TP4RTN	017712	G	T\$TSOF	=	010053			
L\$DU	020704	G	L10024	021012		PREG05	004060		TP4VEC	002276	G	T\$TSW	=	010001			
L\$DUT	002072	G	L10025	021020		PRI	=	002000	G	TSABRT	016672	G	T\$TTES	=	010051		
L\$DVTY	004120	G	L10026	021302		PRI00	=	000000	G	TSTNUM	002254	G	T1	021022	G		
L\$EF	002052	G	L10027	021706		PRI01	=	000040	G	TXAD1A	002240	G	T10	025716	G		
L\$ENVI	002044	G	L10030	022344		PRI02	=	000100	G	TXAD10	=	000012	G	T11	026226	G	
L\$ERRT	004050	G	L10031	022672		PRI03	=	000140	G	TXAD2A	002242	G	T12	026726	G		
L\$ETP	002102	G	L10032	023472		PRI04	=	000200	G	TXAD20	=	000014	G	T13	027424	G	
L\$EXP1	002046	G	L10033	024272		PRI05	=	000240	G	TXAINT	017734	G	T14	030102	G		

SYMBOL TABLE

T15	031152 G	T20	035074 G	T8	024716 G	WAIBIS	017436 G	X\$ALWA=	000000
T16	031740 G	T3	021710 G	T9	025410 G	WAITTX	017512 G	X\$FALS=	000040
T17	032766 G	T4	022346 G	UAM	= 000200 G	WORD1	002302 G	X\$OFFS=	000400
T18	033412 G	T5	022674 G	UNITN	002224 G	WTWLNK	017552 G	X\$TRUE=	000020
T19	034130 G	T6	023474 G	UNSDIV	017302 G	WTWLPR	017602 G	\$PATCH	035632 G
T2	021304 G	T7	024274 G						

. ABS. 035706 000
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 28661 WORDS (112 PAGES)
DYNAMIC MEMORY: 20060 WORDS (77 PAGES)
ELAPSED TIME: 00:05:03
CZDHVBO.BIN,CZDHVBO.LST/-SP=SVC34R/ML,CZDHVBO.P11

.