



(1)		.LIST	BIN	
(1)		.SBTTL	EQUATES	
(1)	000000	RO	=%0	
(1)	000001	R1	=%1	
(1)	000002	R2	=%2	
(1)	000003	R3	=%3	
(1)	000004	R4	=%4	
(1)	000005	R5	=%5	
(1)	000006	R6	=%6	
(1)	000006	SP	=%6	
(1)	000007	PC	=%7	
(1)	000000	OPEN	=0	
(1)	177776	PS	=177776	
(1)	177776	PSW	=177776	
(1)	000340	PRTY7	=340	
(1)	177716	XWCTR	=-62	: INDEX TO WRITE COUNTER.
(1)	177720	XFLMOD	=-60	: INDEX TO FILE MODE INDICATOR
(1)	177722	XFLCNT	=-56	: INDEX TO FILE COUNT
(1)	177724	XSVMAP	=-54	
(1)	177726	XSVCNT	=-52	
(1)	177730	XSVBLK	=-50	
(1)	177732	XSVNAM	=-46	: PHONY UFD BLOCK POINTERS
(1)	177736	XSVEXT	=-42	
(1)	177740	XSVDAT	=-40	
(1)	177742	XSVXX	=-36	
(1)	177744	X1STBK	=-34	
(1)	177746	XBKLG1	=-32	
(1)	177750	XLSTBK	=-30	
(1)	177752	XSVUPT	=-26	
(1)	177754	XBT	=-24	: INDEX TO BOOT ROUTINE.
(1)	177756	DRT	=-22	: INDEX TO DIRECTORY ROUTINE
(1)	177760	ZER	=-20	: INDEX TO ZERO ROUTINE
(1)	177762	DLT	=-16	: INDEX TO DELETE ROUTINE
(1)	177764	CLS	=-14	: INDEX TO CLOSE ROUTINE
(1)	177766	ETR	=-12	: INDEX TO ENTER ROUTINE
(1)	177770	SRH	=-10	: INDEX TO LOKUP ROUTINE
(1)	177772	ALC	=-8	: INDEX TO ALLOCATE ROUTINE
(1)	177774	XSV	=-4	: INDEX TO SERVICE ROUTINE (DRIVER).
(1)	177776	XDN	=-2	: DRIVE NUMBER INDEX
(1)	000000	XCM	=0	: INDEX TO COMMAND REGISTER
(1)	000002	XWC	=2	: INDEX TO WORD COUNT
(1)	000004	XBA	=4	: INDEX TO BUS ADDRESS
(1)	000006	XDT	=6	: INDEX TO BLOCK NUMBER
(1)	000010	XCO	=10	: INDEX TO COMMAND
(1)	000012	XRD	=12	: INDEX TO READ COMMAND
(1)	000014	XWT	=14	: INDEX TO WRITE COMMAND
(1)	000016	XBC	=16	: INDEX TO REQUESTED BLOCK COUNT
(1)	000020	XDR	=20	: INDEX TO 1ST DIR BLOCK POINTER.
(1)	000022	XNB	=22	: INDEX TO LAST BLOCK # ALLOCATED.
(1)	000024	XXNAM	=24	: INDEX TO ASCII NAME IN DDB
(1)				
(1)	010000	MONCNT	=10000	: MONITOR SIZE IS 4K
(1)	000024	MNBK	=24	: POINTER TO MONITOR CORE IMAGE.
(1)				
(1)	000033	ALTMOD	=33	
(1)	000033	ALT1	=33	

```

(1)          000175        ALT2    =175
(1)          000176        ALT3    =176
(1)
(1)
(1)          .SBTTL  GLOBAL REFERENCE DEFINITIONS
(1)          ;EXTERNAL GLOBAL DEFINITIONS
(1)
(1)          .GLOBL  SETMTD
(1)          .GLOBL  CREWIND,CRDHDR
(1)
(1)          000000        .ASECT
(2)          164002        MTST     =164002
(2)          164000        MTCM     =164000
(2)          164004        MTWC     =164004
(2)          164006        MTBA     =164006

```

E01

```

(2) .SBTTL ONCE ONLY BOOT LOADER
(2)
(2) .=0
(2) 000000 000240 .240
(2) 000002 012700 036000 MOV #36000,R0 ;RELOCATION ADDRESS
(2) 000006 005001 CLR R1 ;INITIALIZE TO OLD ADDRESS
(2) 000010 012702 000400 MOV #256.,R2 ;SET COUNT OF TRANSFERS
(2) 000014 112120 15: MOVE (R1)+,(R0)+ ;MOVE BYTE TO UPER CORE
(2) 000016 005302 DEC R2 ;COUNT
(2) 000020 001375 BNE 15 ;LOOP BACK IF NOT DONE
(2) 000022 000137 036070 JMP @#36070 ;JUMP TO BOOT LOAD SUB ROUTIN
(2)
(2) .=40
(2) 000040 000000 000000 000000 .WORD 0,0,0,0,0,0,0,0,0,0,0
(2) 000046 000000 000000 000000
(2) 000054 000000 000000 000000
(2) 000062 000000 000000 000000
(2)
(2)
(2)
(2)
(2)
(2)
(2)
(2)
(2)
(2) 000070 000070 .=70
(2) 000072 000240 INIT: NOP ;RESET PERIPHERALS
(2) 000076 012706 040000 MOV #40000,SP ;INITIALIZE STACK POINTER
(2) ;CHECK IF MTU READY AND AT LOAD POINT
(2) 000076 004767 000160 JSR PC,READY ;TEST FOR DONE
(2) 000102 032737 000040 164002 BIT #40,@#MTST ;TEST FOR LOAD POINT INDICATOR
(2) ;IF YES READ ID BURST, IF NO REWIND TAPE TO LOAD POINT
(2) 000110 001007 BNE BURST ;BRANCH IF @ LOAD POINT
(2) 000112 005037 164002 RWND: CLR @#MTST ;CLEAR STATUS REG.
(2) 000116 012737 000021 164000 MOV #21,@#MTCM ;REWIND COMMAND
(2) 000124 004767 000132 JSR PC,READY ;WAIT FOR DONE
(2) 000130 005037 164002 BURST: CLR @#MTST ;CLEAR STATUS REG.
(2) 000134 012737 000005 164000 MOV #5,@#MTCM ;READ COMMAND
(2) 000142 004767 000114 JSR PC,READY ;DONE??
(2) 000146 032737 000020 164002 BIT #20,@#MTST ;IDB BIT INDICATOR SET ??
(2) ;IO BURST IS TESTED FOR, IF NOT PRESENT AT BEGINNING OF TAPE
(2) ;THE TAPE HALTS.
(2)
(2)
(2) 000154 001454 BEQ TAPERR
(2) 000156 005037 164002 CLR @#MTST ;CLEAR STATUS REG.
(2) 000162 012737 000005 164000 MOV #5,@#MTCM ;SET READ FUNCTION
(2) 000170 004767 000066 JSR PC,READY ;WAIT FOR DONE
(2) 000174 005004 CLR R4 ;SET INITIAL LOAD ADDRESS TO 0
(2) 000176 010437 164006 REED: MOV R4,@#MTBA ;R4 HOLDS INITIAL LOOP ADDRESS DURING DMA
(2) 000202 012737 177000 164004 MOV #-512.,@#MTWC ;SET BLOCK SIZE TO READ 256. (DECIMAL)
(2) ;CHARACTERS
(2)
(2)
(2) 000210 005037 164002 CLR @#MTST
(2) 000214 012737 000005 164000 MOV #5,@#MTCM
(2) 000222 004767 000034 JSR PC,READY
(2) 000226 032737 000010 164002 BIT #10,@#MTST ;CHECK IF END OF FILE MARK HAS BEEN READ
(2) 000234 001402 BEQ 35
(2) 000236 000137 001000 JMP @#1000 ;JUMP TO THE BEGIN OF TROP PROG.
(2)
(2)
(2) ;CHARACTERS HAVE BEEN TRANSFERRED FROM TAPE TO CORE, BEGIN TO
(2) ;PACK THE CHARACTERS INTO WORDS.
(2)
(2)
(2) 000242 012703 177000 35: MOV #-512.,R3 ;COUNTER
    
```

(2)	000246	010405			MOV	R4,R5		;R4 USED TO POINT TO WORD ADDRESSES
(2)	000250	112524			PACK: MOVB	(R5)+,(R4)+		;R5 USED TO POINT TO BYTE ADDRESSES
(2)	000252	005205			INC	R5		
(2)	000254	005203			INC	R3		;COUNT # OF WORDS
(2)	000256	001374			BNE	PACK		;IF NOT, KEEP PACKING
(2)	000260	000746			BR	REED		;IF YES, GO BACK AND GET ANOTHER
(2)								;BLOCK FROM TAPE
(2)	000262	105737	164000		READY: TSTB	Q#MTCM		;CHECK IF TAPE CONTROLLER READY
(2)	000266	100375			BPL	READY		;WAIT UNTIL READY
(2)	000270	005737	164000		TST	Q#MTCM		;CHECK IF ERROR BIT SET
(2)	000274	100005			BPL	RTN		;IF NO THEN RETURN
(2)	000276	032737	011000	164002	BIT	#11000,Q#MTST		;IF YES, THEN CHECK IF EITHER A
(2)								;READ COUNT OF SINGLE TRACK ERROR
(2)								;HAS OCCURRED.
(2)	000304	001001			BNE	RTN		
(2)	000306	000000			TAPERR: HALT			;HALT BECAUSE OF TAPE ERROR
(2)	000310	000207			RTN: RTS	PC		;IF YES, IGNORE AND RETURN

```

(1) .SBTTL SIZER, MONITOR RELOCATOR, AND OTHER GOODIES.
(1) .=1000
(1) 001000 012706 000050' BEGIN: MOV #SPBOT,R6 ;SET UP STACK.
(1) ;SIZE CORE AND UPDATE THE LITERALS OF RESIDENT MONITOR.
(1) 001004 012767 001072 176772 MOV #3$,4 ;POINT TIMEOUT TRAP TO 3$
(1) 001012 012700 174000 MOV #-4000,R0 ;DETERMINE TOP OF CORE IN 1K CHUNKS.
(1) 001016 005001 CLR R1
(1) 001020 062700 004000 1$: ADD #4000,R0
(1) 001024 062710 000000 ADD #0,(0) ;REFERENCE UNKNOWN LOC.
(1) 001030 005201 INC R1 ;IF HERE, NO TRAP OCCURRED.
(1) 001032 022701 000034 CMP #28.,R1 ;DONE 28 TIMES?
(1) 001036 001370 BNE 1$ ;BR IF NOT.
(1) 001040 062700 004000 ADD #4000,R0
(1) 001044 012767 000006 176732 2$: MOV #6,4 ;RESTORE ERROR TRAP.
(1) 001052 020127 000010 CMP R1,#8. ;BK OR GREATER?
(1) 001056 002010 BGE 4$ ;BR IF YES.
(1) 001060 004567 000642' JSR R5,MES ;INSUFFICIENT CORE MESSAGE.
(1) 001064 001434 NOCORE
(1) 001066 000000 HALT
(1) 001070 000777 BR ;LOCK IN HALT.
(1) 001072 012716 001044 3$: MOV #2$, (6) ;TRAPPED TO HERE. EXIT TO 2$
(1) 001076 000002 RTI
(1) 001100 006301 4$: ASL R1 ;READY TO TYPE CORE SIZE.
(1) 001102 116167 001236 000301 MOV# KCODE(1),AK+1
(1) 001110 116167 001237 000274 MOV# KCODE+1(1),AK+2
(1) 001116 166700 000112 SUB LIMIT+2,R0 ;SET UP NEW LOAD ADDRESS
(1) 001122 010001 MOV RD,R1
(1) 001124 010167 000652' MOV R1,RELCNT ;SAVE IT AT RELTMP
(1) 001130 012702 002622 MOV #SLITB,R2
(1) 001134 022712 177777 51$: CMP #-1,(R2) ;END OF TABLE?
(1) 001140 001402 BEQ 6$ ;BR IF YES.
(1) 001142 060132 ADD R1,2(R2)+ ;CORRECT FOR RELOCATION.
(1) 001144 000773 BR 51$
(1) ;RELOCATE MONITOR TO TOP OF CORE.
(1) 001146 005001 6$: CLR R1 ;WHERE PROGRAM STARTS.
(1) 001150 016702 000060 MOV LIMIT+2,R2
(1) 001154 112120 7$: MOV# (1)+,(0)+ ;RELOCATE ONE BYTE AT A TIME.
(1) 001156 005302 DEC R2 ;DONE?
(1) 001160 001375 BNE 7$ ;CONTINUE RELOCATION.
(1) 001162 004567 000642' JSR R5,MES ;TYPE TITLE AND CORE SIZE.
(1) 001166 001330 NAME
(1) 001170 004567 000642' JSR R5,MES ;TYPE RESTART ADDR.
(1) 001174 001415 ARSTRT
(1) 001176 016703 000136' MOV $COMC3,R3
(1) 001202 004767 001232' JSR PC,ITOA
(1) 001206 004567 000642' JSR R5,MES ;TYPE FOR HELP MESSAGE.
(1) 001212 001457 FHLP
(1) 001214 004567 000642' JSR R5,MES ;TYPE THE HELP MESSAGE
(1) 001220 001546 MNINST
(1) 001222 004767 000202' JSR PC,DELAY ;WAIT A BIT.
(1) 001226 016707 000136' MOV $COMC3,PC ;GOTO RESIDENT MONITOR.
(1) 001232 000000 000000 LIMIT: .LIMIT
(1) .EVEN
(1) 001236 030040 030440 031040 KCODE: .ASCII ' 0 1 2 3 4 5 6 7 8 9'
(1) 001244 031440 032040 032440
(1) 001252 033040 033440 034040
    
```

(1)	001260	034440				
(1)	001262	030061	030461	031061	.ASCII	'1011121314151617181920'
(1)	001270	031461	032061	032461		
(1)	001276	033061	033461	034061		
(1)	001304	034461	030062			
(1)	001310	030462	031062	031462	.ASCII	'2122232425262728'
(1)	001316	032062	032462	033062		
(1)	001324	033462	034062			
(1)	001330	052045	042122	020120	NAME:	.ASCII "%TRDP - XXDP TR79F MONITOR M-11-DMQUB-B 1-MAR-77"
(1)	001336	020055	054130	050104		
(1)	001344	052040	033522	043071		
(1)	001352	046440	047117	052111		
(1)	001360	051117	046440	030455		
(1)	001366	026461	046504	052521		
(1)	001374	026506	020102	026461		
(1)	001402	040515	026522	033467		
(1)	001410	020040	045440	000	AK:	.ASCIZ ' K'
(1)	001415	045	042522	052123	ARSTR:	.ASCIZ '%RESTART ADDR:'
(1)	001422	051101	020124	042101		
(1)	001430	051104	000072			
(1)	001434	044445	051516	043125	NOCORE:	.ASCIZ '%INSUFFICIENT CORE'
(1)	001442	044506	044503	047105		
(1)	001450	020124	047503	042522		
(1)	001456	000				
(1)	001457	045	047524	040440	FHELP:	.ASCIZ '%TO ABORT THE FOLLOWING HELP MESSAGE TYPE CTRL C (^C)%'
(1)	001464	047502	052122	052040		
(1)	001472	042510	043040	046117		
(1)	001500	047514	044527	043516		
(1)	001506	044040	046105	020120		
(1)	001514	042515	051523	043501		
(1)	001522	020105	054524	042520		
(1)	001530	041440	051124	020114		
(1)	001536	020103	057050	024503		
(1)	001544	000045				
(1)	001546	022445	054524	042520	MNINST:	.ASCII '%TYPE:'
(1)	001554	072				
(1)	001555	045	036106	051103	.ASCII	'%F<CR> TO SET CONSOLE FILL COUNT'
(1)	001562	020076	047524	051440		
(1)	001570	052105	041440	047117		
(1)	001576	047523	042514	043040		
(1)	001604	046111	020114	047503		
(1)	001612	047125	124			
(1)	001615	045	036104	051103	.ASCII	'%D<CR> FOR DIRECTORY ON CONSOLE, OR'
(1)	001622	020076	047506	020122		
(1)	001630	044504	042522	052103		
(1)	001636	051117	020131	047117		
(1)	001644	041440	047117	047523		
(1)	001652	042514	020054	051117		
(1)	001660	042045	043057	041474	.ASCII	'%D/F<CR> FOR SHORT DIRECTORY ON CONSOLE, OR'
(1)	001666	037122	043040	051117		
(1)	001674	051440	047510	052122		
(1)	001702	042040	051111	041505		
(1)	001710	047524	054522	047440		
(1)	001716	020116	047503	051516		
(1)	001724	046117	026105	047440		
(1)	001732	122				

(1)	001733	045	027504	036114	.ASCII '%D/L<CR> FOR DIRECTORY ON LINE PRINTER, OR'
(1)	001740	051103	020076	047506	
(1)	001746	020122	044504	042522	
(1)	001754	052103	051117	020131	
(1)	001762	047117	046040	047111	
(1)	001770	020105	051120	047111	
(1)	001776	042524	026122	047440	
(1)	002004	122			
(1)	002005	045	027504	027514	.ASCII '%D/L/F<CR> FOR SHORT DIRECTORY ON LINE PRINTER,'
(1)	002012	036106	051103	020076	
(1)	002020	047506	020122	044123	
(1)	002026	051117	020124	044504	
(1)	002034	042522	052103	051117	
(1)	002042	020131	047117	046040	
(1)	002050	047111	020105	051120	
(1)	002056	047111	042524	026122	
(1)	002064	051045	041440	050117	.ASCII '%R COPY<CR> TO RUN COPY PROGRAM,'
(1)	002072	036131	051103	020076	
(1)	002100	047524	051040	047125	
(1)	002106	041440	050117	020131	
(1)	002114	051120	043517	040522	
(1)	002122	026115			
(1)	002124	051045	043040	046111	.ASCII '%R FILENAME<CR> TO RUN ANY OTHER PROGRAM.'
(1)	002132	047105	046501	036105	
(1)	002140	051103	020076	047524	
(1)	002146	051040	047125	040440	
(1)	002154	054516	047440	044124	
(1)	002162	051105	050040	047522	
(1)	002170	051107	046501	056	
(1)	002175	045	020114	044506	.ASCII '%L FILENAME<CR> TO LOAD A PROGRAM ONLY'
(1)	002202	042514	040516	042515	
(1)	002210	041474	037122	052040	
(1)	002216	020117	047514	042101	
(1)	002224	040440	050040	047522	
(1)	002232	051107	046501	047440	
(1)	002240	046116	131		
(1)	002243	045	036123	051103	.ASCII '%S<CR> TO START THE PROGRAM JUST LOADED,'
(1)	002250	020076	047524	051440	
(1)	002256	040524	052122	052040	
(1)	002264	042510	050040	047522	
(1)	002272	051107	046501	045040	
(1)	002300	051525	020124	047514	
(1)	002306	042101	042105	054	
(1)	002313	045	020123	042101	.ASCII '%S ADDR<CR> TO START THE PROGRAM AT SPECIFIC ADDRESS'
(1)	002320	051104	041474	037122	
(1)	002326	052040	020117	052123	
(1)	002334	051101	020124	044124	
(1)	002342	020105	051120	043517	
(1)	002350	040522	020115	052101	
(1)	002356	051440	042520	044503	
(1)	002364	044506	020103	042101	
(1)	002372	051104	051505	123	
(1)	002377	045	020103	044506	.ASCII '%C FILENAME<CR> TO RUN A CHAIN,'
(1)	002404	042514	040516	042515	
(1)	002412	041474	037122	052040	
(1)	002420	020117	052522	020116	



```

(1) 002426 020101 044103 044501
(1) 002434 026116
(1) 002436 041445 043040 046111
(1) 002444 047105 046501 027505
(1) 002452 053121 041474 037122
(1) 002460 052040 020117 052522
(1) 002466 020116 020101 044103
(1) 002474 044501 020116 047111
(1) 002502 050410 044525 045503
(1) 002510 053040 051105 043111
(1) 002516 020131 047515 042504
(1) 002524 056
(1) 002525 045 042522 042506
(1) 002532 020122 047524 054040
(1) 002540 042130 020120 051525
(1) 002546 051105 046440 047101
(1) 002554 040525 020114 042115
(1) 002562 030455 026461 055104
(1) 002570 054121 020101 047506
(1) 002576 020122 042101 044504
(1) 002604 044524 047117 046101
(1) 002612 044040 046105 027120
(1) 002620 000045

```

.ASCII '%C FILENAME/QV<CR> TO RUN A CHAIN IN QUICK VERIFY MODE.'

.ASCIZ '%REFER TO XXDP USER MANUAL MD-11-DZQXA FOR ADDITIONAL HELP.%'

.EVEN

```

(1) 002622 000154'
(1) 002624 001570'
(1) 002626 001550'
(1) 002630 000332'
(1) 002632 000334'
(1) 002634 000270'
(1) 002636 000272'
(1) 002640 000250'
(1) 002642 000252'
(1) 002644 001510'
(1) 002646 002540'
(1) 002650 000054'
(1) 002652 000374'
(1) 002654 000342'
(1) 002656 002276'
(1) 002660 002152'
(1) 002662 001462'
(1) 002664 000136'
(1) 002666 000146'
(1) 002670 001032'
(1) 002672 003120'
(1) 002674 002102'
(1) 002676 002072'
(1) 002700 002156'
(1) 002702 001452'
(1) 002704 177777
(1)
(1) 000000'

```

```

$LITTB: $REL1
          $REL2+2
          $REL3
          $REL4
          $REL4+2
          $REL5
          $REL5+2
          $REL6
          $REL6+2
          $REL7
          $REL10+2
          $REL11+2
          $REL12+2
          $REL13+2
          $REL14+2
          $REL15+2
          $REL16+2
          $COMC3
          COMCON+2
          GETIND+2
          LOAD4+2
          $BUF
          $BUF2
          $TXNAM
          $IDDB
          -1

```

.CSECT MTDIRT

```

(1) .SBTTL NON-RESIDENT CODE
(1) 000000' .CSECT
(1) :DIRECTORY ROUTINE.
(1) 000000' 005726 NRDIR: TST (SP)+ ;POP OFF 1ST STACK ELEMENT.
(1) 000002' 012667 002410' MOV (SP)+,FILLCT ;GET FILL COUNT.
(1) 000006' 012667 001466' MOV (SP)+,CURDRV ;GET THE CURRENT DRIVE NUMBER.
(1) 000012' 012667 000136' MOV (SP)+,$COMC3 ;GET RES MONITOR RESTA:RT ADDR.
(1) 000016' 012667 001124' MOV (SP)+,KBPTR ;GET KYBD POINTER.
(1) 000022' 005002 CLR R2 ;FOR DEVICE SET ROUTINE.
(1) 000024' 004767 001442' JSR PC,SETI ;SET INPUT. NO NAME.
(1) 000030' 105067 000030 CLRB FSTMOD ;ASSUME NO FAST MODE SWITCH.
(1) 000034' 004767 000034 JSR PC,NRGTSW ;GET SWITCHES.
(1) 000040' 004567 002114' JSR R5,BCLEAR ;CLEAR NAME TO 'S
(1) 000044' 004506' 000077 000011 IFNAM,77,9.
(1) 000052' 010565 177720 MOV R5,XFLMOD(R5) ;INDICATE WILD MODE.
(1) 000056' 004775 177756 JSR PC,@DRT(R5) ;GO OUTPUT DIRECTORY.
(1) 000062' 000207 RTS PC ;RETURN.
(1) 000064' 000 FSTMOD: .BYTE 0
(1) 000066' 000066' .EVEN
(1) 000066' 105267 177772 SETFST: INCB FSTMOD ;SET FAST MODE.
(1) 000072' 000400 BR NRGTSW
(1) 000074' 012701 000144' NRGTSW: MOV #NRSWTB,R1 ;POINT TO NON-RESIDENT SWITCH TABLE.
(1) 000100' 000167 000552' JMP GTOKK ;GO SET SWITCHES.
(1) 000104' 016767 000030 001004' LPSW: MOV LPS,MREG ;CHANGE STATUS REG.
(1) 000112' 016767 000024 001000' MOV LPB,MOUT ;CHANGE BUFFER REG.
(1) 000120' 052767 000200 002410' BIS #200,FILLCT ;MAKE FILLCOUNT NEGATIVE.
(1) 000126' 012702 000014 MOV #14,R2 ;OUTPUT A FORM FEED.
(1) 000132' 004767 000202' JSR PC,DELAY ;WAIT FOR FORM FEED DONE.
(1) 000136' 000756 BR NRGTSW ;SEE ABOUT OTHER SWITCHES.
(1) 000140' 177514 LPS: 177514 ;LINE PRINTER STAT REG ADDR.
(1) 000142' 177516 LPB: 177516 ;LINE PRINTER BUFFER REG ADDR.
(1) 000144' NRSWTB:
(2) 000144' 000066' .WORD SETFST ;DISPATCH ADDRESS FOR /F
(2) 000154' 000104' .WORD LPSW ;DISPATCH ADDRESS FOR /L
(2) 000164' 000212' .WORD RTSPC ;DISPATCH ADDRESS FOR <15>
(2) 000172' 000546' .WORD GTOK ;DISPATCH ADDRESS FOR <40>
(1) 000200' 177777 -1 ;TERMINATOR.
    
```

1)						
(2)	000202'					
(2)	000202'	004467	002040			
(1)	000206'	016703	002156'			
(1)	000212'	005001				
(1)	000214'	112302		1\$:	MOV	(R3)+,R2
(1)	000216'	004767	000666'	2\$:	JSR	PC,ME\$1
(1)	000222'	005201			INC	R1
(1)	000224'	020127	000006		CMP	R1,#6
(1)	000230'	103771			BLO	1\$
(1)	000232'	101003			BHI	3\$
(1)	000234'	112702	000056		MOV	#',R2
(1)	000240'	000766			BR	2\$
(1)	000242'	120127	000012	3\$:	CMPB	R1,#10.
(1)	000246'	103762			BLO	1\$
(2)	000250'	004767	002052'		JSR	PC,RST04
(1)	000254'	000167	000752'		JMP	TAB

:SUB TO TYPE FILE NAME.

\$TPNM1::

:SAVE REGS 0-4  
 :ADDR OF NAME TO R3.  
 :CHAR COUNTER.  
 :GET A CHAR.  
 :TYPE IT.  
 :UP CHAR COUNT.  
 :DONE 6?  
 :BR IF NOT YET.  
 :BR IF MORE THAN 6.  
 :SIX. TYPE A DOT.  
 :GO TYPE THE DOT.  
 :DONE 10?  
 :BR IF NOT.  
 :RESTORE REGS 0-4  
 :GO TAB AND RTS PC.

```

(1)          .SBTTL BINARY TO DECIMAL CONVERT AND TYPE SUBROUTINE
(2) 000260'          BCD CV::
(2) 000260' 004467 002040' JSR R4, SAVD4          ;SAVE REGS 0-4
(1) 000264' 012504          MOV (R5)+, R4          ;NUMBER OF DIGITS
(1) 000266' 012700 000374' MOV #DECTAB, R0        ;TABLE OF DECIMAL NUMBERS
(1) 000272' 005046          CLR -(SP)            ;STACK WORD FOR INDICATOR.
(1) 000274' 005740          BCD1: TST -(R0)            ;STEP TO THE LARGEST DIGIT
(1) 000276' 005304          DEC R4
(1) 000300' 003375          BGT BCD1
(1) 000302' 005002          BCD2: CLR R2              ;R2 IS TO RECEIVE THE QUOTIENT
(1) 000304' 012001          MOV (R0)+, R1          ;THE DIVISOR
(1) 000306' 001422          BEQ BCD3              ;EXIT IF ZERO
(1) 000310' 160103          BCD5: SUB R1, R3          ;DIVIDE BY SUBTRACTING
(1) 000312' 103402          BCS BCD4
(1) 000314' 005202          INC R2                ;UP THE QUOTIENT AFTER EACH SUB
(1) 000316' 000774          BR BCD5
(1) 000320' 060103          BCD4: ADD R1, R3          ;GONE TOO FAR
(1) 000322' 005702          TST R2              ;QUOTIENT = 0?
(1) 000324' 001005          BNE BCD6              ;NO
(1) 000326' 005716          TST (SP)            ;LEADING ZERO'S?
(1) 000330' 001003          BNE BCD6              ;NO
(1) 000332' 012702 000040' MOV #40, R2          ;YES PRINT SPACE
(1) 000336' 000403          BR BCD7
(1) 000340' 005216          BCD6: INC (SP)          ;NOMORE LEADING ZERO'S
(1) 000342' 062702 000060' ADD #0, R2          ;MAKE IT ASCII
(1) 000346' 004767 000776' BCD7: JSR PC, CHROUT      ;PRINT IT
(1) 000352' 000753          BR BCD2
(1) 000354' 005726          BCD3: TST (SP)+          ;POP INDICATOR WORD.
(2) 000356' 000167 002236' JMP RESR5          ;GO RESTORE REGS 0-4, DO RTS R5.
(1) 000362' 023420 001750 000144 .WORD 10000., 1000., 100., 10., 1
(1) 000370' 000012 000001          DECTAB: .WORD 0
(1) 000374' 000000

```

```

(1)          .SBTTL DATE UNPACK AND TYPE SUBROUTINE
(1) 000376' 004467 002040' DATUPK: JSR R4, SAV04 ;SAVE THEM
(1) 000402' 012704 000105'      MOV #59, R4 ;BASE YEAR IS 1970
(1) 000406' 042703 100000'      BIC #100000, R3 ;GET RID OF CONFIG BIT
(1) 000412' 005204          DATUP1: INC R4 ;SEE!
(1) 000414' 162703 001750'      SUB #1000., R3 ;FIND WHAT YEAR
(1) 000420' 003374          BGT DATUP1
(1) 000422' 062703 001750'      ADD #1000., R3 ;WENT TOO FAR
(1) 000426' 012767 000034 000066'  MOV #28., DATTAB+2 ;ASSUME LEAN YEAR.
(1) 000434' 032704 000003'      BIT #3, R4 ;LEAP YEAR?
(1) 000440' 001002          BNE DATUP4 ;BR IF NOT.
(1) 000442' 005267 000054'      INC DATTAB+2 ;YES, CORRECT FOR FEB.
(1) 000446' 012700 000520'  DATUP4: MOV #DATTAB, R0 ;GO FIND WHAT MONTH
(1) 000452' 020310  DATUP3: CMP R3, (R0) ;LESS THAN WHAT THIS MON HAS
(1) 000454' 003402          BLE DATUP2 ;YES, FOUND THE MONTH
(1) 000456' 162003          SUB (R0)+, R3 ;NO, ADVANCE MONTH
(1) 000460' 000774          BR DATUP3
(1) 000462' 004567 177572'  DATUP2: JSR R5, BCDCV ;PRINT OUT THE DAY FIRST
(1) 000466' 000002          .WORD 2
(1) 000470' 016067 000030 000004'  MOV #24. (R0), DATUP5 ;POINT TO MONTH NAME
(1) 000476' 004567 000642'  JSR R5, MES ;AND PRINT IT
(1) 000502' 000000          DATUPS: .WORD 0
(1) 000504' 010403          MOV R4, R3 ;NOW THE YEAR
(1) 000506' 004567 177546'  JSR R5, BCDCV ;PRINT THAT OUT
(1) 000512' 000002          .WORD 2
(2) 000514' 000167 002022'  JMP RESR7 ;GO RESTORE REGS 0-4, DO RTS PC.
(1) 000520' 000037 000034 000037'  DATTAB: .WORD 31., 28., 31., 30.
(1) 000526' 000036          .WORD 0
(1) 000530' 000037 000036 000037'  .WORD 31., 30., 31., 31.
(1) 000536' 000037          .WORD 0
(1) 000540' 000036 000037 000036'  .WORD 30., 31., 30., 31.
(1) 000546' 000037          .WORD 0
(1) 000550' 000600'          $JAN
(1) 000552' 000606'          $FEB
(1) 000554' 000614'          $MAR
(1) 000556' 000622'          $APR
(1) 000560' 000630'          $MAY
(1) 000562' 000636'          $JUN
(1) 000564' 000644'          $JUL
(1) 000566' 000652'          $AUG
(1) 000570' 000660'          $SEP
(1) 000572' 000666'          $OCT
(1) 000574' 000674'          $NOV
(1) 000576' 000702'          $DEC
(1) 000600' 045055 047101 000055'  $JAN: .ASCIZ '-JAN-'
(1) 000606' 043055 041105 000055'  $FEB: .ASCIZ '-FEB-'
(1) 000614' 046455 051101 000055'  $MAR: .ASCIZ '-MAR-'
(1) 000622' 040455 051120 000055'  $APR: .ASCIZ '-APR-'
(1) 000630' 046455 054501 000055'  $MAY: .ASCIZ '-MAY-'
(1) 000636' 045055 047125 000055'  $JUN: .ASCIZ '-JUN-'
(1) 000644' 045055 046125 000055'  $JUL: .ASCIZ '-JUL-'
(1) 000652' 040455 043525 000055'  $AUG: .ASCIZ '-AUG-'
(1) 000660' 051455 050105 000055'  $SEP: .ASCIZ '-SEP-'
(1) 000666' 047455 052103 000055'  $OCT: .ASCIZ '-OCT-'
(1) 000674' 047055 053117 000055'  $NOV: .ASCIZ '-NOV-'
(1) 000702' 042055 041505 000055'  $DEC: .ASCIZ '-DEC-'

```

B02

TRDP - XXDP TR79F MONITOR M-11-DMQUF-B MACY11 27(732) 01-MAR-77 10:34 PAGE 1-13  
DMQUF3.P11 DATE UNPACK AND TYPE SUBROUTINE

SEQ 0014

.1.

.EVEN

(1)  
(1) 000000' 000000'  
(1) 000000' 00040C  
(1)  
(1) 000000'

RUNBUF: .SBTTL CHAIN BUFFER  
.CSECT RUNBUF  
.BLKW 256.  
.SBTTL PAK & UNPAK TR BUF  
.CSECT TRBF

```

(1)          .SBTTL  COMMAND DECODER, INI, AND DELAY ROUTINES
(1)          000000'
(1)          .CSECT  RES' N
(1)          .PROGRAM STACK
(1) 000000' 000024  R6STCK: .BLKW  20.
(1) 000050'
(1)          SPBOT:
(1)
(1)          .END OF PASS CHAIN MODE ENTRY POINT.
(1) 000050' 005046 000060'  RSTRT:: CLR      -(6)          ;CLEAR T BIT.
(1) 000052' 012746 000060'  $REL11: MOV     #RSTRT1,-(6)      ;WILL RTI TO RSTRT1
(1) 000056' 000002
(1) 000060' 004767 000730  RSTRT1: JSR     PC,CROUT2      ;CHECK FOR CTL C.
(1) 000064' 005737 000042  TST     #42                ;ABORT CURRENT PROGRAM?
(1) 000070' 001425
(1) 000072' 105767 000121  BEQ     COMCON             ;BR IF YES.
(1) 000076' 001022
(1) 000100' 005327
(1) 000102' 000000
(1) 000104' 001417
(1) 000106' 000207
(1)          PCOUNT: .WORD  0
(1)          BEQ     COMCON             ;QUICK VERIFY MODE?
(1)          RTS     PC                ;BR IF YES, DO NEXT CHAIN ENTRY.
(1)          ;ALL PASSES DONE?
(1)          ;PASS COUNTER.
(1)          ;BR IF YES.
(1)          ;NO. RETURN TO CURRENT PROGRAM.
(1)
(1)          .ERROR REPORTING ROUTINE
(1) 000110' 004767 000066  COMCO1: JSR     PC,DELAY      ;WAIT A BIT.
(2) 000114' 004467 001720  JSR     R4,SAV04          ;SAVE REGS 0-4
(1) 000120' 010500
(1) 000122' 004567 000526  MOV     R5,R0            ;GET ADDR OF ASCII MESSAGE.
(1) 000126' 105767 00437C  JSR     R5,MES0          ;TYPE ERROR MESSAGE.
(1) 000132' 001004
(1) 000134' 012707
(1) 000136' 000140'
(1)          TSTB    RUMID
(1)          BNE     COMCON             ;WAS IT RUN COMMAND?
(1)          MOV     (PC)+,PC          ;BR IF YES. CONTINUE CHAIN MODE.
(1)          $COMC3: COMC03
(1)          ;GO TO COMC03.
(1)
(1)          .CHAIN MODE IS CLEARED HERE.
(1) 000140' 005027
(1) 000142' 000000
(1)          COMC03: CLR     (PC)+
(1)          CHN:   .WORD  0
(1)          ;CLEAR CHAIN MODE.
(1)          ;CHAIN MODE INDICATOR.
(1)
(1)          .WHERE EVERYTHING STARTS
(1) 000144' 012706 000050'  COMCON: MOV     #SPBOT,SP    ;SET UP THE STACK
(1) 000150' 004567 001740  JSR     R5,BCLR          ;CLEAR BUFFERS, VARIABLES.
(1) 000154' 003400' 000000 001135 $REL1: CLRBEG,0,CLREND-CLRBEG
(1)
(1) 000162' 004567 000454  COMC02: JSR     R5,MES     ;TYPE A DOT 1ST.
(1) 000166' 004535'
(1) 000170' 004567 000630  JSR     R5,INPUT        ;GO FETCH A COMMAND
(1) 000174' 004767 000346  COMC05: JSR     PC,GTOK   ;CHECK COMMAND SYNTAX
(1) 000200' 000761
(1)          BR      COMC04
(1)          ;TILL EVERYTHING IS DONE
(1)
(1) 000202' 005046
(1) 000204' 005316
(1) 000206' 100776
(1) 000210' 005726
(1) 000212' 000207
(1)          DELAY:: CLR     -(SP)
(1)          IS:   DEC     (SP)
(1)          BMI     IS
(1)          TST     (SP)+
(1)          RTSPC: RTS     PC
(1)          ;DELAY A LITTLE BIT.
(1)          ;RESTORE STACK.
(1)          ;DONE. RETURN.

```





```

(1)
(1) 000414' 020001
(1) 000416' 001021
(1) 000420' 016746 177744
(1) 000424' 004767 177736
(1) 000430' 026726 177734
(1) 000434' 001412
(1) 000436' 016746 177500
(1) 000442' 016746 002672
(1) 000446' 004767 177610
(1) 000452' 012667 002662
(1) 000456' 012667 177460
(1) 000462' 016703 177454
(1) 000466' 016704 002646
(1) 000472' 005304
(1) 000474' 100003
(1) 000476' 004767 177554
(1) 000502' 000767
(1) 000504' 112302
(1) 000506' 001614
(1) 000510' 120227 000012
(1) 000514' 001766
(1) 000516' 010367 177420
(1) 000522' 010467 002612
(1) 000526' 000207
    
```

```

.SBTTL CHAIN EXECUTION ROUTINE
CHAIN:  CMP    RD,R1          ; AT START OF KYBD BUFFER?
        BNE    CHAIN0       ; BR IF NOT.
        MOV    RCKSM, -(SP)  ; SAVE BATCH CHECKSUM.
        JSR    PC,RCKSUM     ; RECHECKSUM THE BUFFER.
        CMP    RCKSM, (SP)+  ; MATCH?
        BEQ    CHAIN0       ; BR IF YES.
        MOV    CHN, -(SP)   ; NO. SAVE CHN
        MOV    RNBK, -(SP)  ; SAVE RNBK
        JSR    PC,D02       ; GET THE BLOCK.
        MOV    (SP)+, RNBK  ; RESTORE RNBK.
        MOV    (SP)+, CHN   ; RESTORE CHN.
CHAIN0: MOV    CHN,R3       ; NEXT COMMAND
        MOV    RNBK,R4     ; COUNT
CHAIN1: DEC    R4
        BPL    CHAIN2      ; BR IF POSITIVE
        JSR    PC,D01      ; NO. NEED NEW BUFFER.
        BR    CHAIN0
CHAIN2: MOVB  (R3)+, R2    ; GET A BYTE
        BEQ    COMC03      ; BACK TO COMC03.
        CMPB  R2,#12      ; LINE FEED?
        BEQ    CHAIN1      ; DISREGARD IT.
        MOV   R3,CHN      ; SAVE IT
        MOV   R4,RNBK     ; THAT TOO
        RTS    PC         ; RETURN.
    
```

```

(1)
(1) 000530' 004767 000654      SETCNT: JSR      .SB^TL  COMMAND DECODER
(1) 000534' 010267 003760      MOV      PC,ATOI      ;GET THE COUNT
(1) 000540' 000402                BR       R2,ICOUNT    ;STORE IT.
(1)
(1) 000542' 105267 177451      SETQV:  INCB     QVMODE ;SET QV MODE.
(1)
(1) 000546'
(1) 000546' 012701 004542'      GTOK:GTSM:
(1) 000552' 016702 000074      GTOKK:  MOV      #COMTAB,R1 ;DEVICE DECODING COMES HERE
(1) 000555' 060201                ADD     RELOCNT,R2      ;GET RELOCATION FACTOR.
(1)                                ADD     R2,R1            ;CORRECT R1 FOR RELOCATION.
(1)
(1) 000560' 016700 000340      GTOKX:  MOV      KBPTR,R0 ;GET STRING POINTER
(1) 000564' 012104                GTOK1:  MOV      (1)+,R4   ;GET DISPATCH ADDR.
(1) 000566' 012103                MOV      (1)+,R3         ;GET POINTER TO NEXT ENTRY.
(1) 000570' 122021                GTOK2:  CMPB     (R0)+,(R1)+ ;MATCH THE CHARACTER?
(1) 000572' 001007                BNE     GTOKY            ;
(1) 000574' 105711                GTOK3:  TSTB     (R1)      ;LAST CHR IN ENTRY?
(1) 000576' 001374                BNE     GTOK2           ;NO,CHECK THE OTHER CHR'S
(1) 000600' 010067 000320      MOV      R0,KBPTR      ;SAVE STRING POINTER.
(1) 000604' 060204                GTOK4:  ADD     R2,R4     ;CORRECT FOR RELOCATION.
(1) 000606' 005002                CLR     R2              ;
(1) 000610' 000114                JMP     (R4)            ;DISPATCH WHERE NEEDED.
(1)
(1) 000612' 010301                GTOKY:  MOV      R3,R1    ;POINT TO NEXT ENTRY.
(1) 000614' 060201                ADD     R2,R1          ;CORRECT FOR RELOCATION.
(1) 000616' 022711 177777      CMP      #-1,(1)       ;FILLED?
(1) 000622' 001356                BNE     GTOKX          ;BR IF YES. KEEP LOOKING.
(1)
(1) 000624' 004567 177260      INVCMD:: JSR      R5,COMCO1 ;REPORT INVALID COMMAND/SW
(1) 000630' 047111 041526 042115 .ASCIZ  'INVCMD/SW
(1) 000636' 051457 000127
(1)
(1)                                .EVEN

```

```

(1) .SBTTL MESSAGE ROUTINES
(2) 000642' 004467 001172 MES:: JSR R4, SAVD4 ;SAVE REGS 0-4
(1) 000646' 012500 MOV (R5)+, R0 ;MESSAGE BUFFER TO R0
(1) 000650' 062700 ADD (PC)+, R0 ;CORRECT FOR RELOCATION.
(1) 000652' 000000 RELCNT: .WORD 0 ;RELOCATION FACTOR.
(1) 000654' 112002 MESD: MOV (R0)+, R2 ;PICK UP ONE CHR TO R2
(1) 000656' 001525 BEQ GEXD4 ;BR IF 0.
(1) 000660' 004767 000002 JSR PC, MES1 ;GO OUTPUT CHAR.
(1) 000664' 000773 BR MESD ;GO FOR MORE.
(1) 000666' 120227 000011 MES1: CMPB R2, #11 ;TAB CODE?
(1) 000672' 001427 BEQ TAB ;BR IF YES TO DO A TAB.
(1) 000674' 120227 000045 CMPB R2, #'% ;%?
(1) 000700' 001036 BNE CHROUT ;BR IF NOT.
(1) 000702' 010246 CRLF: MOV R2, -(SP) ;SAVE R2.
(1) 000704' 012702 005015 MOV #5015, R2 ;OUTPUT CR.
(1) 000710' 004767 000062 JSR PC, CHROUT
(1) 000714' 000302 SWAB R2 ;OUTPUT LINE FEED.
(1) 000716' 004767 000054 JSR PC, CHROUT
(1) 000722' 116702 001462 MOVB FILLCT, R2 ;GET READY FOR FILLER CHARS.
(1) 000726' 005077 000046 1$: CLR #MOUT ;FILLER IS 0.
(1) 000732' 004767 000044 JSR PC, CROUT1
(1) 000736' 005302 DEC R2 ;DONE?
(1) 000740' 003372 BGT 1$ ;BR IF NOT.
(1) 000742' 005027 CLR (PC)+ ;CLEAR THE CHAR COUNT.
(1) 000744' 000000 CHRCNT: .WORD 0 ;CHAR COUNT VARIABLE.
(1) 000746' 012602 CRLF1: MOV (SP)+, R2 ;RESTORE R2.
(1) 000750' 000207 RTS PC ;DONE. RETURN.
(1) ;TAB SUBROUTINE.
(1) 000752' 010246 TAB: MOV R2, -(SP) ;SAVE R2.
(1) 000754' 012702 000040 1$: MOV #40, R2 ;SPACES DO THE TABBING.
(1) 000760' 004767 000012 JSR PC, CHROUT ;OUTPUT A SPACE.
(1) 000764' 142767 000370 177752 BICB #370, CHRCNT ;SEE IF DONE.
(1) 000772' 001370 BNE 1$ ;BR IF NOT DONE.
(1) 000774' 000764 BR CRLF1 ;GO EXIT.
(1) ;SUB TO OUTPUT CHARACTER TO CONSOLE OR LINE PRINTER
(1) 000776' 110237 CHROUT: MOV R2, @(PC)+ ;OUTPUT CHAR.
(1) 001000' 177566 MOUT: .WORD 177566
(1) 001002' CROUT1: TSTB @(PC)+ ;WAIT FOR READY.
(1) 001002' 105737 MREG: .WORD 177564
(1) 001004' 177564 BPL CROUT1 ;BACK IF NOT READY.
(1) 001006' 100375 INCB CHRCNT ;UP CHARACTER COUNT.
(1) 001010' 105267 177730 CROUT2: JSR PC, CKYBD ;CHECK KEYBOARD.
(1) 001014' 004767 000116 RTS PC ;EXIT. NO CHAR.
(1) 001020' 000207 BR GETCR1 ;CHECK FOR CTRL C.
(1) 001022' 000470
    
```

```

(1)          .SBTTL INPUT ROUTINE
(1)          :TO CALL 'INPUT' DO A JSR  RS,INPUT
(1)          :FOLLOWED BY          +   ADR OF MESSAGE TO BE TYPED PRIOR TO INPUT
(1) INPUT:
(2) GETIN:
(2) 001024' 004467 001010 JSR  R4,SAV04 ;SAVE REGS 0-4
(1) 001030' 012700 003354' GETINO: MOV  #KBUF,R0 ;INPUT BUFFER
(1) 001034' 010001 MOV  R0,R1 ;SAVE THE ADDRESS
(1) 001036'
(1) 001036' 004767 000120 GETIO1: JSR  PC,GETCHR ;GET A CHARACTER
(1) 001042' 120227 000141 2$: CMPB R2,#141 ;LESS THAN LOWER CASE A?
(1) 001046' 103405 BLC 1$ ;BR IF YES.
(1) 001050' 120227 000172 3$: CMPB R2,#172 ;HIGHER THAN LOWER CASE Z?
(1) 001054' 101002 BHI 1$ ;BR IF YES.
(1) 001056' 162702 000040 SUB  #40,R2 ;MAKE IT UPPER CASE.
(1) 001062' 120227 000177 1$: CMPB R2,#177 ;RUBOUT?
(1) 001066' 001407 BEQ  GETIO2 ;YES
(1) 001070' 110220 GETIO6: MOVB R2,(R0)+ ;STORE IT. NOT SPECIAL CHAR.
(1) 001072' 120227 000015 CMPB R2,#15 ;CARRIAGE RETURN?
(1) 001076' 001407 BEQ  GETIO8 ;QUITTING TIME
(1) 001100' 004767 177562 GETIO3: JSR  PC,MES1 ;ECHO THE CHARACTER
(1) 001104' 000754 BR   GETIO1 ;CONTINUE INPUT
(1) 001106' 020100 GETIO2: CMP  R1,R0 ;RUBOUT, BUFFER EMPTY?
(1) 001110' 001752 BEQ  GETIO1 ;YEP,ECHO CRLF
(1) 001112' 114002 GETI11: MOVB -(R0),R2 ;GET THE LAST CHR
(1) 001114' 000771 BR   GETIO3 ;AND ECHO IT
(1) 001116' 112720 000012 GETIO8: MOVB #12,(R0)+ ;STORE LF TOO.
(1) 001122' 010127 MOV  R1,(PC)+ ;POINT TO START OF KEYBOARD BUFFER.
(1) 001124' 000000 KBPTR: .WORD 0 ;KEYBOARD POINTER.
(1) 001126' 004767 177550 GEX02: JSR  PC,CRLF ;CRLF.
(2) 001132'
(2) 001132' 000167 001100 GEX04: JMP  RESRS ;GO RESTORE REGS 0-4, DO R'S RS.
(1)
(1) 001136' 105737 CKYBD: TSTB @PC+ ;KEYBOARD ACTIVE?
(1) 001140' 177560 KTKS: .WORD 177560
(1) 001142' 100006 BPL  CKYBD1 ;BR IF NOT.
(1) 001144' 013702 MOV  @PC+,R2 ;GET CHARACTER.
(1) 001146' 177562 KTKB: .WORD 177562
(1) 001150' 042702 177600 BIC  #177600,R2 ;CLEAR OUT JUNK BITS.
(1) 001154' 062716 000002 ADD  #2,(SP) ;SET UP CHARACTER IN BUFFER RETURN.
(1) 001160' 000207 CKYBD1: RTS  PC ;EXIT.
(1)
(1) 001162' 005767 176754 GETCHR: TST  CHN ;IN CHAIN MODE?
(1) 001166' 001403 BEQ  1$ ;BR IF NOT.
(1) 001170' 004767 177220 JSR  PC,CHAIN ;YES. GET CHAR FROM CHAIN FILE.
(1) 001174' 000403 BR   GETCR1
(1) 001176' 004767 177734 1$: JSR  PC,CKYBD ;WAIT FOR CHARACTER.
(1) 001202' 000775 BR   1$ ;LOOP TILL YOU GOT ONE.
(1) 001204' 120227 000003 GETCR1: CMPB R2,#3 ;CTRL C?
(1) 001210' 001363 BNE  CKYBD1 ;BR IF NOT.
(1) 001212' 016707 176720 MOV  $COMC3,PC ;YES. TIME TO QUIT.

```

J02

\*RDP - XXDP TR79F MONITOR M-11-DMQUB-B MACY11 27(732) 01-MAR-77 10:34 PAGE 1-21  
DMQUB.P11 ERROR MESSAGE ROUTINES.

SEQ 0022

(1)					.SBTTL	ERROR MESSAGE ROUTINES.	
(1)	001216	004567	176666		DEVERR::	JSR AS,COMCO1	;REPORT DEVICE ERRCR.
(1)	001222	042504	042526	051122	.ASCIZ	'DEVERR'	
(1)	001230	JOC					
(1)		001232			.EVEN		

```

(1)          .SBTT, ITOA SUBROUTINE
(1)          ; BINARY TO ASCII ROUTINE
(1)          ; TAKES WHAT'S IN R3 AND SHIFTS THREE BITS INTO R2
(1)          ; THEN CALLS PRINTOUT ROUTINE TO OUTPUT THEM
(1) 001232' 004467 000602      ITOA:: JSR   R4, SAV04      ; I GET SCREWED WHEN I DON'T
(1) 001236' 012704 000006      MOV   #6, R4        ; DO ONLY SIX TIMES
(1) 001242' 005002              CLR   R2            ; WHERE THE DIGITS GO
(1) 001244' 000413              BR    ITOA3
(1) 001246' 062702 000060      ITOA1: ADD   #'0, R2      ; MAKE IT ASCII
(1) 001252' 004767 177520      JSR   PC, CHROUT   ; TYPE IT
(1) 001256' 005304              DEC   R4            ; ONE DOWN
(1) 001260' 003410              BLE   ITOA2        ; IF NOMORE TO GO
(1) 001262' 005002              CLR   R2            ; GET RID OF OLD STUFF
(1) 001264' 006303              ASL   R3            ; SHIFT COMBINED
(1) 001266' 006102              ROL   R2            ; THREE TIMES
(1) 001270' 006303              ASL   R3            ; THIS IS
(1) 001272' 006102              ROL   R2            ; ACTUALLY FASTER
(1) 001274' 006303      ITOA3: ASL   R3            ; AND MORE EFFICIENT
(1) 001276' 006102              ROL   R2            ; THAN A DO LOOP
(1) 001300' 000762              BR    ITOA1        ; KEEP GOING
(2) 001302'                                ITOA2:
(2) 001302' 000167 000514      JMP   RESR7        ; GO RESTORE REGS 0-4, DO RTS PC.
(1)

```

```

(1)                                     .SBTTL GETNUM/ATOI SUBROUTINES
(1)
(1)
(1) 001306' 016700 177612      GETNUM: MOV      KBPTR,R0      ;GET STRING POINTER.
(1) 001312' 005001      GTNMI:  CLR      R1          ;DATA
(1) 001314' 005027      CLR      (PC)+
(1) 001316' 000000      YES:   .WORD    0
(1) 001320' 112002      25:   MOV8     (R0)+,R2      ;GET A BYTE
(1) 001322' 120227 000040      CMPB    R2,#40      ;SPACE?
(1) 001326' 001771      BEQ     GTNMI       ;YES, IGNORE IT
(1) 001330' 122702 000015      CMPB    #15,R2      ;CR?
(1) 001334' 001417      BEQ     3$          ;YES, RETURN
(1) 001336' 120227 000060      CMPB    R2,#'0      ;LOW LIMIT
(1) 001342' 002414      BLT     3$          ;TOO LOW
(1) 001344' 120227 000067      CMPB    R2,#'7      ;HIGH LIMIT
(1) 001350' 003011      BGT     3$          ;TOO HIGH
(1) 001352' 006301      ASL     R1          ;SHIFT OLD STUFF
(1) 001354' 006301      ASL     R1          ;3 TIMES LEFT
(1) 001356' 006301      ASL     R1          ;I.E. MULT. BY OCTAL 10
(1) 001360' 060201      ADD     R2,R1       ;ADD NEW TO OLD
(1) 001362' 162701 000060      SUB     #'0,R1      ;BUT GET RID OF ASCII STUFF
(1) 001366' 105267 177724      INCB   YES         ;SET FLAG
(1) 001372' 000752      BR     25          ;MORE, MORE
(1)
(1) 001374' 005300      3$:
(1) 001376' 010067 177522      GTNMO: DEC      R0          ;SAVE STRING POINTER.
(1) 001402' 105767 177710      MOV     R0,KBPTR
(1) 001406' 000207      GTNUM1: TSTB   YES
(1)                                     RTS      PC          ;NOMORE
(1)
(1)                                     ;DECIMAL ASCII TO BINARY CONVERT SUBROUTINE.
(1) ATOI:  MOV     KBPTR,R0      ;POINT TO STRING
(1) ATOI1: MOV8   (R0)+,R3      ;GET DIGIT.
(1)       SUB     #'0,R3       ;CONVERT TO BINARY
(1)       BMI    GTNMO        ;NOT A DIGIT.
(1)       CMP    R3,#9        ;CHECK UPPER LIMIT.
(1)       BGT    GTNMO        ;TOO HIGH.
(1)
(1)       ASL    R2
(1)       ASL    R2
(1)       ADD   R3,R2
(1)       BR    ATOI1
(1)                                     ;ALL DONE.
    
```



```

(1) .SBTTL DEVICE SETUP ROUTINE, INPUT INIT ROUTINE
(1) 001442' 005046 SETI: CLR -(SP) ;INDICATE NO NAME.
(1) 001444' 000401 BR DVSET
(1) 001446' 010746 SETIN: MOV PC, -(SP) ;INDICATE NAME NEEDED.
(1) 001450' 012705 DVSET: MOV (PC)+, R5 ;INPUT DDB ADDR TO R5.
(1) 001452' 004462' $IDDB: .WORD INDEV
(1) 001454' 016746 177172 MOV RELOCNT, -(SP) ;PUT RELOC FACTOR IN STACK.
(1) 001460' 012700 004656' $REL16: MOV #DEVTAB, R0 ;GET DEVICE TABLE ADDR.
(1) 001464' 062700 ADD (PC)+, R0 ;ADD OFFSET FOR DESIRED DEVICE.
(1) 001466' 000000 CURDRV: .WORD 0 ;HOLDS CURRENT DRIVE # TIMES 2.
(1) 001470' 011000 MOV (R0), R0 ;GET DEVICE SET UP ADDR.
(1) 001472' 061600 ADD (SP), R0 ;CORRECT FOR RELOCATION.
(1) 001474' 004710 JSR PC, (R0) ;GO SET UP DEVICE.
(1) 001476' 061600 ADD (SP), R0 ;CORRECT PARAM ADDR FOR RELOCATION.
(1) 001500' 010067 000006 MOV R0, $REL7+2
(1) 001504' 004567 000374 JSR R5, BMOVE ;MOVE DEVICE INFO TO DDB.
(1) 001510' 004436' 000000 000050 $REL7: INBOOT, OPEN, IFNAM-INBOOT ;DEST, SOURCE, COUNT.
(1) 001516' 016703 177766 MOV $REL7, R3
(1) 001522' 012701 000011 MOV #9, R1 ;NUMBER OF ENTRIES TO RELOCATE.
(1) 001526' 061623 5$: ADD (SP), (R3)+ ;RELOCATE ENTRY.
(1) 001530' 005301 DEC R1 ;DONE?
(1) 001532' 001375 BNE 5$ ;BR IF NOT.
(1) 001534' 062665 000020 ADD (SP)+, XDR(R5) ;ANOTHER ONE NEEDS IT.
(1) 001540' 005726 TST (SP)+ ;NAME NEEDED?
(1) 001542' 001531 BEQ RESR7A ;BR IF NOT.
(1) 001544' 004567 000344 FILNAM: JSR R5, BCLEAR ;CLEAR NAME AREA TO BLANKS
(1) 001550' 004506' 000040 000006 $REL3: IFNAM, 40, 6.
(2) 001556' 004467 000256 FNAM3: JSR R4, SAVD4 ;SAVE REGS 0-4
(1) 001562' 016700 177336 MOV KBPTR, R0 ;KYBD BUFFER POINTER TO R0.
(1) 001566' 012704 004506' $REL2: MOV #IFNAM, R4
(1) 001572' 012703 000006 MOV #6, R3 ;UP TO 6 DIGITS FOR NAME
(1) 001576' 112002 FNAM1: MOVB (R0)+, R2 ;GET A CHARACTER.
(1) 001600' 120227 000077 CMPB R2, #'?' ;QUESTION MARK?
(1) 001604' 001003 BNE 1$ ;BR IF NOT.
(1) 001606' 010565 177720 MOV R5, XFLMOD(R5) ;SET FILE MODE INDICATOR.
(1) 001612' 000416 1$: CMPB R2, #15 ;CR?
(1) 001614' 120227 000015 BEQ 2$ ;BR IF YES.
(1) 001620' 001411 CMPB R2, #40 ;SPACE?
(1) 001622' 120227 000040 BEQ FNAM1 ;BR IF YES.
(1) 001626' 001763 CMPB R2, #'0 ;LESS THAN 0?
(1) 001630' 120227 000060 BLO 2$ ;BR IF YES. NOT ALPHA-NUMERIC
(1) 001634' 103403 BLO 2$ ;HIGHER THAN Z?
(1) 001636' 120227 000132 CMPB R2, #'Z ;BR IF NOT. ALPHA-NUMERIC CHAR.
(1) 001642' 101402 BLOS 3$ ;MOVE POINTER BACK ONE.
(1) 001644' 005300 2$: DEC R0
(1) 001646' 000403 BR 5$ ;GO CLEAN UP.
(1) 001650' 110224 3$: MOVB R2, (R4)+ ;STORE THE CHARACTER.
(1) 001652' 005303 4$: DEC R3 ;DONE 6 CHARS?
(1) 001654' 003350 BGT FNAM1 ;BR IF NOT.
(1) 001656' 020327 000006 5$: CMP R3, #6 ;ANY NAME CHARS?
(1) 001662' 001403 BEQ INVNAM ;BR IF NONE. ERROR.
(1) 001664' 010067 177234 MOV R0, KBPTR ;SAVE STRING POINTER.
(1) 001670' 000454 BR RESR7 ;RESTORE REGS. DO RTS PC
    
```

N02

TROP - XXDP TR79F MONITOR M-11-DMQUB-8 MACY11 27(732) 01-MAR-77 10:34 PAGE 1-25  
DMQUB.P11 DEVICE SETUP ROUTINE, INPUT INIT ROUTINE

SEQ 0026

(1) 001672' 004567 176212      INVNAM: JSR      RS.COMC01                    :REPORT INVALID NAME.  
(1) 001676' 047111 047126 046501    .ASCIZ 'INVNAM'  
(1) 001704'      000  
(1)            001706'                    .EVEN

```

(1)          .SBTTL READL, READC, AND BKREAD SUBROUTINES.
(1)          ;SUB TO READ ONE BLOCK, SET R0 AND R1 POINTERS.
(1) 001706' 01670C 000160  GTDATA: MOV  $BUF2,R0          ;ADDR OF 1ST DATA BYTE.
(1) 001712' 012701 000776          MOV  #510.,R1          ;SET BYTE COUNT IN R1.
(1)
(1)          ;SUBROUTINE TO READ LINKED FILE BLOCK INTO BUF
(1) 001716' 016705 177530  READL:  MOV  $IDDB,R5          ;POINT TO INPUT DOB.
(1) 001722' 105267 002575          INCB  PIPFLG          ;SET PIP MODE.
(1) 001726' 005765 000006          TST  XDT(R5)          ;LAST BLOCK?
(1) 001732' 001436          BEQ  EOMERR          ;BR IF YES, ERROR.
(1) 001734' 004767 000024          JSR  READ            ;READ BLOCK.
(1) 001740' 016765 001434 000006  MOV  BUF,XDT(R5)       ;SAVE NEXT BLOCK ADDRESS.
(1) 001746' 000207          READL1: RTS  PC          ;DONE. RETURN.
(1)
(1)          ;SUB TO INPUT/OUTPUT NEXT BLOCK.
(1) 001750' 016765 001424 000006  NXTBLK:: MOV  BUF,XDT(R5)          ;GET BLOCK NUMBER.
(1) 001756' 001773          BEQ  READL1          ;IF 0, NO MORE. ERROR RETURN.
(1) 001760' 062716 000002          ADD  #2,(SP)         ;SET FOR NORMAL RETURN.
(1)
(1)          ;SUBROUTINE TO READ A BLOCK INTO BUF.
(1) 001764' 004767 000076          BKREAD:: JSR  PC,CLRBUF          ;CLEAR THE BUFFER 1ST.
(1) 001770' 016765 000106 000004  MOV  $BUF,XBA(R5)       ;SET READ ADDRESS.
(1) 001776' 012765 000400 000002  BKRD0: MOV  #256.,XWC(R5)   ;SET WORD COUNT.
(1) 002004' 016565 000012 000010  READBK:: MOV  XRD(R5),XCO(R5) ;SET READ COMMAND.
(2) 002012'          XYBK:          JSR  R4,SAV04          ;SAVE REGS 0-4
(1) 002016' 004467 000022          JSR  PC,XXSV(R5)       ;DO IT.
(1)
(2) 002022'          RESR7::          JSR  PC,RST04          ;RESTORE REGS 0-4
(2) 002022' 004767 000024          RESR7A: RTS  PC          ;RETURN.
(1) 002026' 000207
(1)
(1) 002030' 004567 176054          EOMERR:: JSR  RS,COMC01          ;REPORT END OF MEDIUM ERROR.
(1) 002034' 047505 000115          .ASCIZ 'EOM'
(1)          .EVEN
    
```

```

(1)
(1)
(1) 002040' 010346 SAVD4:: MOV R3,-(SP) ;SAVE R3
(1) 002042' 010246 MOV R2,-(SP) ;SAVE R2
(1) 002044' 010146 MOV R1,-(SP) ;SAVE R1
(1) 002046' 010046 MOV R0,-(SP) ;SAVE R0
(1) 002050' 010407 MOV R4,PC ;R5 IS ALREADY SAVED
(1)
(1)
(1) 002052' 012604 RST04:: MOV (SP)+,R4 ;RETURN ADDRESS
(1) 002054' 012600 MOV (SP)+,R0 ;RESTORE R0
(1) 002056' 012601 MOV (SP)+,R1 ;R1
(1) 002060' 012602 MOV (SP)+,R2 ;R2
(1) 002062' 012603 MOV (SP)+,R3
(1) 002064' 000204 RTS R4 ;RESTORE R4 AND RETURN
(1)
    
```

```

(1)          :SUB TO CLEAR BUFFER.
(1) 002066' 004567' 000022' 000776 CLRBUF:: JSR    R5,BCLEAR          ;CALL BYTE CLEAR SUB.
(1) 002072' 003402' 000000'          SBUF2:: BUF+2,0,510.        ;DEST,CLEAR VALUE,COUNT
(1) 002100' 000207'          RTS    PC                    ;EXIT.
(1) 002102' 003400'          SBUF::  BUF

(1)          :ROUTINE TO MOVE BYTE FIELDS.
(1) 002104' 012767' 112120' 000022 BMOVE:: MOV    #112120,BMC2        ;SET A MOVB (1)+,(0)+
(1) 002112' 000403'          BR      BMC1

(1)          :ROUTINE TO CLEAR BYTE FIELDS TO SPECIFIC VALUE.
(1) 002114' 012767' 110120' 000012 BCLEAR:: MOV    #110120,BMC2        ;SET A MOVB R1,(0)+
(2) 002122'          BMC1:
(2) 002122' 004467' 177712          JSR    R4,SAV04          ;SAVE REGS 0-4
(1) 002126' 012500          MOV    (5)+,R0          ;GET DEST ADDR.
(1) 002130' 012501          MOV    (5)+,R1          ;GET SOURCE.
(1) 002132' 012502          MOV    (5)+,R2          ;GET COUNT.
(1) 002134' 000000          BMC2: OPEN
(1) 002136' 005302          DEC    R2              ;DONE?
(1) 002140' 001375          BNE   BMC2              ;BR IF NOT.
(1) 002142' 000435          BMC3: BR      UPKNM1

(1)          :CMPNAM SUBROUTINE. COMPARES TWO 9 CHARACTER NAMES. WILD CHARS ALLOWED.
(2) 002144'          CMPNAM::
(2) 002144' 004467' 177670          JSR    R4,SAV04          ;SAVE REGS 0-4
(1) 002150' 012700' 004506'          $REL15: MOV    #IFNAM,R0          ;DESIRED NAME ADDRESS.
(1) 002154' 012701          MOV    (PC)+,R1        ;ADDR OF NAME UNDER QUESTION.
(1) 002156' 004524'          $TXNAM:: .WORD TXNAM
(1) 002160' 012702' 000011          MOV    #9.,R2          ;COMPARE UP TO 9 CHARACTERS.
(1) 002164'          1$:
(1) 002164' 122710' 000077          CMPB  #'?',(0)          ;CHAR A WILD CHARACTER?
(1) 002170' 001002          BNE   11$              ;BR IF NOT.
(1) 002172' 122021          CMPB  (R0)+,(R1)+      ;POINT TO NEXT CHAR.
(1) 002174' 000402          BR    2$
(1) 002176' 122021          11$: CMPB  (0)+,(1)+      ;COMPARE CHARACTERS.
(1) 002200' 001003          BNE   3$              ;BR IF NOT SAME.
(1) 002202' 005302          2$: DEC    R2              ;MATCH DECREMENT COUNT.
(1) 002204' 001367          BNE   1$              ;BR IF NOT DONE YET.
(1) 002206' 005725          TST   (R5)+            ;DONE. SET UP MATCH EXIT.
(1) 002210' 000412          3$: BR      UPKNM1

(1)          :SUBROUTINE TO CONVERT RAD50 FILE NAME TO ASCII.
(2) 002212'          UPKNAM::
(2) 002212' 004467' 177622          JSR    R4,SAV04          ;SAVE REGS 0-4
(1) 002216' 012501          MOV    (R5)+,R1        ;GET ASCII ADDR.
(1) 002220' 012500          MOV    (R5)+,R0        ;GET RAD50 ADDR.
(2) 002222' 004567' 000026          JSR    R5,UNPACK        ;UNPACK 2 WORDS INTO 6 ASCII BYTES.
(1) 002226' 062700' 000004          ADD   #4,R0            ;POINT TO EXT ADDR.
(2) 002232' 004567' 000006          JSR    R5,UPACK1       ;UNPACK 1 WORD INTO 3 ASCII BYTES.
(1) 002236'          UPKNM1:
(2) 002236'          RESR5::
(2) 002236' 004767' 177610          JSR    PC,RST04        ;RESTORE REGS 0-4
(1) 002242' 000205          RTS    R5              ;DONE. RETURN.

```

```

(1)          .SBTTL RAD50 UNPACK SUBROUTINE
(1)          INPUT:  RD=ADR OF MOD40 NUMBER (2 WORDS)
(1)          R1=ADR OF ASCII STRING (6 BYTES)
(1)          OUTPUT: R1 POINTS ONE PAST LAST GENERATED CHARACTER
(1)          IF N IS THE MOD40 NUMBER, THEN
(1)          N=C1*50+2+C2*50+C3
(1)          THUS, N/50+2 IS C1 AND THE REMAINDER IS C2*50+C3
(1)          THE REMAINDER IS DIVIDED BY 50 TO GET C2 ETC.
(1) 002244' 012727 177777 UNPACK1:  MOV    #-1,(PC)+    ;UNPACK ONE WORD ONLY.
(1) 002250' 000000 PAKTMP:  .WORD    0
(1) 002252' 000403 BR        UNPA07
(1) 002254' 012767 177776 177766 UNPACK:  MOV    #-2,PAKTMP    ;MAJOR LOOP COUNT
(2) 002262' 002262 UNPA07:
(2) 002262' 004467 177552 JSR     R4,SAV04    ;SAVE REGS 0-4
(2) 002266' 012704 177775 UNPA09: MOV    #-3,R4    ;MINOR LOOP COUNT
(1) 002272' 011000 MOV    (R0),R0    ;GET MOD40 WORD
(1) 002274' 012702 002400' $REL14: MOV    #COEFF,R2 ;PTR TO COEFFICIENT TABLE
(1) 002300' 005003 UNPA06: CLR    R3    ;0 QUOTIENT
(1)          ; DIVIDE BY COEFFICIENTS
(1) 002302' 020012 UNPA02: CMP    R0,(R2) ;DONE WITH DIVIDE
(1) 002304' 103403 BLO   UNPA01    ;YES
(1) 002306' 161200 SUB    (R2),R0   ;NO-SUBTRACT COEFF.
(1) 002310' 005203 INC    R3        ;ADD 1 TO QUOTIENT
(1) 002312' 000773 BR     UNPA02
(1)          ; DIVIDE DONE. QUOT IN R3, REMAINDER IN R0
(1)          ; CONVERT TO AN ASCII CHARACTER
(1) 002314' 105703 UNPA01: TSTB  R3
(1) 002316' 001406 BEQ   UNPA03    ;"BLANK"
(1) 002320' 120327 000033 CMPB  R3,#33
(1) 002324' 001407 BEQ   UNPA05    ;"5"
(1) 002326' 003004 BGT   UNPA04    ;" " OR "0-9"
(1) 002330' 062703 000040 ADD    #40,R3    ;"A-Z"
(1) 002334' 062703 000016 UNPA03: ADD    #16,R3
(1) 002340' 062703 000011 UNPA04: ADD    #11,R3
(1) 002344' 062703 000011 UNPA05: ADD    #11,R3
(1) 002350' 110321 MOVB  R3,(R1)+    ;STORE CHARACTER
(1) 002352' 005722 TST   (R2)+     ;ADVANCE TO NEXT COEFF.
(1) 002354' 005204 INC   R4        ;DONE 3 CHARS?
(1) 002356' 002750 BLT   UNPA06    ;NO-DO MORE
(1) 002360' 011600 MOV   (SP),R0   ;RESTORE ORIGINAL R0 AND
(1) 002362' 005720 TST  (R0)+     ;MOVE TO NEXT WORD
(1) 002364' 005267 177660 INC   PAKTMP    ;DONE 2 WORDS
(1) 002370' 002736 BLT   UNPA09    ;NO
(1)          ; DONE--PUT CURRENT R1 ONTO THE STACK
(1) 002372' 010166 000002 UNPA08: MOV   R1,2(SP)
(1) 002376' 000717 BR    UPKNM1    ;GO EXIT.
(1) 002400' 003100 000050 000001 COEFF:  .WORD  1600.,40.,1. ;40.†2, 40.†1,40.†0
    
```

```

(1)          .SBTTL FILL, RUN, AND START ROUTINES
(1) 002406' 012703 FILL: MOV (PC)+,R3 ;GET READY TO TYPE FILL COUNT.
(1) 002410' 000014 FILLCT: .WORD 14
(1) 002412' 004767 176614 JSR PC,ITOA ;PRINT THAT OUT
(1) 002416' 004767 176330 JSR PC,TAB ;TAB OVER.
(1) 002422' 004567 176376 JSR R5,INPUT ;WAIT FOR INPUT
(1) 002426' 004767 176654 JSR PC,GETNUM ;CONVERT INPUT STRING TO BINARY
(1) 002432' 001402 BEQ MOD1 ;JUST A CR, DO NOTHING
(1) 002434' 010167 177750 MOD1: MOV R1,FILLCT ;PUT WHAT HE ENTERED THERE
(1) 002440' 000207 RTS PC
(1)
(1)          .START ROUTINE
(1) 002442' 004767 176640 START: JSR PC,GETNUM ;FETCH STARTING ADR
(1) 002446' 001420 BEQ RUN10 ;BR IF NO DATA TYPED.
(1) 002450' 006201 ASR R1 ;GOOD ADDRESS?
(1) 002452' 103404 BCS INVADR ;BR IF NOT (ODD).
(1) 002454' 060101 ADD R1,R1 ;RESTORE ADDR.
(1) 002456' 010167 000454 MOV R1,STADR ;SAVE ADDR.
(1) 002462' 000412 BR RUN10 ;DATA TYPED.
(1) 002464' 004567 175420 INVADR: JSR R5,COMCO1 ;REPORT INVALID ADDRESS.
(1) 002470' 047111 040526 051104 .ASCIZ 'INVADR'
(1) 002476' 000 .EVEN
(1) 002500' 105267 002016 RUN: INCB RUN10 ;SET RUN INDICATOR.
(1) 002504' 004767 000216 JSR PC,LOAD ;DO A LOAD 1ST.
(1) 002510' 004767 176032 RUN10: JSR PC,SW ;GET SWITCHES.
(1) 002514' 016767 002000 175360 MOV PCOUNT,PCOUNT ;GET I COUNT IF ANY.
(1) 002522' 001002 BNE RUN11 ;BR IF NON ZERO.
(1) 002524' 005267 175352 INC PCOUNT ;MAKE IT ONE.
(1) 002530' 005767 175406 RUN11: TST CHN ;CHAIN MODE?
(1) 002534' 001403 BEQ RUN20 ;BR IF NOT.
(1) 002536' 012737 000050' 000042 $REL10: MOV #RESTR,2#42 ;SET RESTART ADDR IN LOC 42.
(1) 002544' 016701 RUN20: MOV STADR,R1
(1) 002550' 006201 ASR R1
(1) 002552' 103002 BCC RUN30 ;BR IF EVEN ADDR.
(1) 002554' 012701 000100 MOV #100,R1 ;ODD ADDR START AT 200.
(1) 002560' 006301 RUN30: ASL R1 ;RESTORE THE ADDR.
(1) 002562' 016746 177622 RUN40: MOV FILLCT,-(SP) ;PASS THE FILL COUNT.
(1) 002566' 012746 012345 MOV #12345,-(SP) ;INDICATE XXDP MONITOR LOAD.
(1) 002572' 000111 JMP (R1) ;START THE PROGRAM.
(1)
    
```

```

(1)
(1) 002574' 004767 176642 DIR: JSR SBTTL DIR ROUTINE
(1) 002600' 012746 MOV PC SETI ;NO NAME NEEDED.
(1) 002602' 000001 FILCNT: WORD (PC)+,-(SP) ;GET FILE POSITION COUNT.
(1) 002604' 004767 000000G JSR PC,CREWIND ;REWIND TAPE.
(1) 002610' 004767 000000G JSR PC,CROWDR ;READ FILE LABEL.
(1) 002614' 000436 BR FLNOTF ;EOT RETURN.
(1) 002616' 005316 DEC (SP) ;GOT TO FILE?
(1) 002620' 001373 BNE IS ;BR IF NOT.
(1) 002622' 005726 TST (SP)+ ;RESTORE STACK.
(1) 002624' 012765 010000 000002 MOV #MONCNT,XWC(R5) ;4K'S WORTH. STARTING AT LOC 0
(1) 002632' 005065 000004 CLR XBA(R5) ;XFR STARTS AT 0.
(1) 002636' 004767 177142 JSR PC,READBK ;DO IT.
(1) 002642' 012701 000000' MOV #NRDIR,R1 ;POINT TO NON-RES DIR ROUTINE.
(1) 002646' 016746 176252 MOV KBPTR,-(SP) ;PASS THE BUFFER POINTER.
(1) 002652' 016746 175260 MOV $COMC3,-(SP) ;PASS MONITOR RESTART ADDR.
(1) 002656' 016746 176604 MOV CURDRV,-(SP) ;PASS CURRENT DRIVE.
(1) 002662' 000737 BR RUN40 ;GO TO NON-RESIDENT DIR ROUTINE.
(1) ;VIA RUN40.
(1)
(1)
(1) ;INPUT INIT ROUTINE
(1) 002664' 016705 176562 INITI: MOV $IDDB,R5 ;POINT TO INPUT DDB.
(1) 002670' 010565 177744 MOV R5,X1STBK(R5) ;DUMMY BLOCK NUMBER.
(1) 002674' 004775 177770 JSR PC,JSRH(R5) ;FILE SEARCH.
(1) 002700' 000404 BR ZS ;FILE NOT FOUND.
(1) 002702' 016565 177744 000006 MOV X1STBK(R5),XDT(R5) ;1ST BLOCK # TO INDT
(1) 002710' 000207 RTS PC ;FOUND. RETURN.
(1) 002712' 004567 175172 ZS: JSR R5,COMC01 ;REPORT FILE NOT FOUND.
(1) 002716' 042516 043130 046111 FLNOTF:: .ASCIZ 'NEXFIL'
(1) 002724' 000 .EVEN
(1) 002726'
    
```



```

(1) .SBTTL LOAD ROUTINE. ;.BIN OR .BIC FILES ONLY
(2) 002726' .LOAD: JSR PC,SETIN ;SET INPUT DEVICE. NAME NEEDED.
(2) 002726' 004767 176514 MOV #BI,IFNAM+6 ;SET UP BIC EXTENSION.
(1) 002732' 012767 044502 001554 MOV #C,IFNAM+8.
(1) 002740' 112767 000103 001550 TST CHN ;IN CHAIN MODE?
(1) 002746' 005767 175170 BNE IS ;BR IF YES.
(1) 002752' 001005 MOVB #?,IFNAM+8. ;NO. MAKE LAST CHAR WILD.
(1) 002754' 112767 000077 001534 MOV R5,XFLMOD(R5) ;INDICATE FILE MODE.
(1) 002762' 010565 177720
(2) 002766' IS: JSR PC,INITI ;INIT FOR INPUT.
(2) 002766' 004767 177672 LOAD1: JSR PC,GTDATA ;INPUT A BLOCK OF DATA
(1) 002772' 004767 176710 LOAD2: CLR (PC)+ ;INITIALIZE CHECKSUM
(1) 002776' 005027 CHKSUM: .WORD 0
(1) 003000' 000000 JSR PC,RDFRAM ;READ A SYNC WORD
(1) 003002' 004767 000154 TST R3 ;GOT A NULL?
(1) 003006' 005703 BEQ LOAD2 ;IF YES, KEEP READING.
(1) 003010' 001772 DEC R3 ;SEE IF IT'S A ONE
(1) 003012' 005303 BNE CKSMER ;IF NOT, LOAD ERROR.
(1) 003014' 001025 JSR PC,RDFRAM ;SYNC IS A WORD
(1) 003016' 004767 000140 TSTB R3 ;OF 1
(1) 003022' 105703 BNE CKSMER ;SO THE SECOND HALF MUST BE 0
(1) 003024' 001021 JSR PC,RD2FRM ;2 BYTES=1 WORD
(1) 003026' 004767 000154 MOV R3,R4 ;ASSUMING NOT DONE YET
(1) 003032' 010304 SUB #4,R4 ;MINUS THE HEADER
(1) 003034' 162704 000004 CMP #2,R4 ;BYTE COUNT=6?
(1) 003040' 022704 000002 BEQ LJMP ;IT IS, THE END IS NEAR
(1) 003044' 001431 JSR PC,RD2FRM ;GET LOAD ADR
(1) 003046' 004767 000134 MOV R3,R2 ;INTO R2
(1) 003052' 010302 LOAD3: JSR PC,RDFRAM ;GET A BYTE
(1) 003054' 004767 000102 BPL LOAD4 ;BYTE COUNT NOT ZERO YET
(1) 003060' 100016 TSTB CHKSUM ;CHECK SUM SHOULD BE ZERO
(1) 003062' 105767 177712 BEQ LOAD2 ;IT IS
(1) 003066' 001743 CKSMER: JSR R5,COMCO1 ;REPORT LOAD ERROR.
(1) 003070' 004567 175014 .ASCIZ 'CKSMER'
(1) 003074' 045503 046523 051105
(1) 003102' 000
(1) 003104' 003104' .EVEN
(1) 003104' 004567 175000 POFLOW: JSR R5,COMCO1 ;PROGRAM OVERFLOW MESSAGE.
(1) 003110' 047520 046106 000117 .ASCIZ 'POFLO'
(1) 003116' 020227 000000' LOAD4: CMP R2,#R6STCK ;PROTECT THE MONITOR
(1) 003122' 103370 BHIS POFLOW ;ABORT
(1) 003124' 110322 MOVB R3,(R2)+ ;STORE THE BYTE.
(1) 003126' 000752 BR LOAD3 ;GO GET MORE
(1) 003130' 004767 000052 LJMP: JSR PC,RD2FRM ;GET THE JUMP ADR
(1) 003134' 010327 MOV R3,(PC)+ ;STORE IT FOR RAINY DAYS
(1) 003136' 000001 STADR: .WORD 1
(1) 003140' 004767 000016 JSR PC,RDFRAM ;MAKE SURE THE CHECKSUM IS OK
(1) 003144' 105767 177630 TSTB CHKSUM ;WE CHECK EVERY BLOCK
(1) 003150' 001347 BNE CKSMER
(1) 003152' 112737 000004 000041 MOVB #4,#41 ;SET LOAD MEDIUM INDICATOR.
(1) 003160' 000207 RTS PC ;DONE. GET OUT.
(1) 003162' 005301 RDFRAM: DEC R1 ;BYTE COUNT IN BUFFER
(1) 003164' 100003 BPL RDFRAM ;SOMETHING IN BUFFER
(1) 003166' 004767 176514 JSR PC,GTDATA ;NO, GET ANOTHER BUFFER FULL
(1) 003172' 000773 BR RDFRAM ;DO THE HOUSE KEEPING
    
```

```

(1) 003174' 112003
(1) 003176' 060367 177576
(1) 003202' 005304
(1) 003204' 000207
(1) 003206' 004767 177750
(1) 003212' 010327
(1) 003214' 000000
(1) 003216' 004767 177740
(1) 003222' 110367 177767
(1) 003226' 016703 177762
(1) 003232' 000207

```

```

RDFRMA: MOVB (R0)+,R3
          ADD R3,CHKSUM
          DEC R4
RDFRMB: RTS PC
RD2FRM: JSR PC,RDFRAM
          MOV R3,(PC)+
LTEMP: .WORD 0
          JSR PC,RDFRAM
          MOVB R3,LTEMP+1
          MOV LTEMP,R3
          RTS PC

```

```

:PICK UP CHR
:DO THE CHECKSUM STUFF
:LOAD BYTE COUNT

:GET ONE BYTE FIRST
:STORE IT TEMPORARILY
:TEMP STORAGE
:GET THE OTHER BYTE
:INTO THE HIGH BYTE
:BACK INTO R3
:RETURN

```

```

(1) .SBTTL BATCH DEVICE DESCRIPTOR BLOCK (DDB)
(1) 003234' BTCDOB:
(1) 003234' 000000 RACTR: 0
(1) 003236' 000000 RFLMOD: 0
(1) 003240' 000000 RFLCNT: 0
(1) 003242' 000000 RSVMAP: 0
(1) 003244' 000000 RSVCNT: 0
(1) 003246' 000000 RSVBLK: 0
(1) 003250' 000000 000000 RSVNAM: 0,0
(1) 003254' 000000 RSVEXT: 0
(1) 003256' 000000 RSVDAT: 0
(1) 003260' 000000 RSVXX: 0
(1) 003262' 000000 R1STBK: 0
(1) 003264' 000000 RBKLG: 0
(1) 003266' 000000 RLSTBK: 0
(1) 003270' 000000 RSVUPT: 0
(1) 003272' 000000 RBOOT: 0
(1) 003274' 000000 RDRT: 0
(1) 003276' 000000 RZER: 0
(1) 003300' 000000 RDLT: 0
(1) 003302' 000000 RCLS: 0
(1) 003304' 000000 RRETR: 0
(1) 003306' 000000 RSRCH: 0
(1) 003310' 000000 RALC: 0
(1) 003312' 000000 RSRV: 0
(1) 003314' 000000 RDRV: 0
(1) 003316' 000000 RCM: 0
(1) 003320' 000000 RWC: 0
(1) 003322' 000000 RBA: 0
(1) 003324' 000000 RDT: 0
(1) 003326' 000000 RCOM: 0
(1) 003330' 000000 RPRC: 0
(1) 003332' 000000 RPPWC: 0
(1) 003334' 000000 RRBKCT: 0
(1) 003336' 000000 RDIR: 0
(1) 003340' 000000 RNBK: 0
(1) 003342' 000 000 000 RFNAM: .BYTE 0,0,0,0,0,0,0,0
(1) 003345' 000 000 000
(1) 003350' 000 000 000
(1) 003353' BTCEND:
(1) 003354' .EVEN

```

K03

TROP - XXDP TR79F MONITOR M-11-DMQUB-B MACY11 27(732) 01-MAR-77 10:34 PAGE 1-35  
DMQUB.P11 BATCH DEVICE DESCRIPTOR BLOCK (DDB)

SEG 0036

(1)  
(1) 003354' 000012  
(1)  
(1)  
(1) 003400'  
(1)  
(1) 003400' 003400

.KEYBOARD BUFFER.  
KBUF: .BLKW 10.  
.SBTTL START OF CLEARABLE CORE (DURING INIT)  
CLRBEQ: .BEGINNING OF CLEARABLE AREA (DURING INIT).  
.MAIN READ - WRITE BUFFER  
BUF:: .BLKW 256.

```

(1)          .SBTTL INPUT DEVICE DESCRIPTOR BLOCK (DOB)
(1) 004400' DOBSTR: INDOB:
(1) 004400' 000000 IACTR: .WORD 0 ;XWCTR OUTPUT FILE OPEN FLAG
(1) 004402' 000000 IFLMOD: .WORD 0 ;XFLMOD FILE MODE FLAG
(1) 004404' 000000 IFLCNT: .WORD 0 ;XFLCNT FILE COUNT
(1) 004406' 000000 ISVMAP: .WORD 0 ;XSVMAP BLK # OF FILE'S MAP BLOCK
(1) 004410' 000000 ISVCNT: .WORD 0 ;XSVCNT ENTRY # OF CURR FILE IN UFD
(1) 004412' 000000 ISVBLK: .WORD 0 ;XSVBLK BLK # OF CURR FILE'S UFD
(1)
(1)          :UFD DIRECTORY ENTRY DATA FOR FILE
(1) 004414' 000000 000000 ISVNAM: .WORD 0,0 ;XSVNAM FILE'S FILENAME IN RAD50 (2 WORDS,
(1) 004420' 000000 ISVEXT: .WORD 0 ;XSVEXT FILE'S EXTENSION IN RAD50
(1) 004422' 000000 ISVDAT: .WORD 0 ;XSVDAT FILE'S CREATION DATE IN DOS FORMAT
(1) 004424' 000000 ISVXX: .WORD 0 ;XSVXX (NOT USED?)
(1) 004426' 000000 I1STBK: .WORD 0 ;X1STBK BLOCK # OF FILE'S FIRST DATA BLY
(1) 004430' 000000 IBKLG: .WORD 0 ;XBKLG # OF BLOCKS IN THE FILE
(1) 004432' 000000 ILSTBK: .WORD 0 ;XLSTBK BLOCK # OF LAST DATA BLOCK WRITTEN
(1) 004434' 000000 ISVUPT: .WORD 0 ;XSVUPT (NOT USED?)
(1)          ;END OF DIRECTORY ENTRIES
(1)
(1) 004436' 000000 INBOOT: .WORD 0 ;XBT ADDRESS OF "BOOT" ROUTINE
(1) 004440' 000000 INDIR: .WORD 0 ;XDIR ADDRESS OF "DIRECTORY" ROUTINE
(1) 004442' 000000 INZER: .WORD 0 ;XZER ADDRESS OF "ZERO" ROUTINE
(1) 004444' 000000 INDLT: .WORD 0 ;XDLT ADDRESS OF "DELETE" ROUTINE
(1) 004446' 000000 INCLS: .WORD 0 ;XCLS ADDRESS OF "CLOSE" ROUTINE
(1) 004450' 000000 INETR: .WORD 0 ;XETR ADDRESS OF "ENTER" (CREATE) ROUTINE
(1) 004452' 000000 INSRH: .WORD 0 ;XSRH ADDRESS OF "LOOKUP" (SEARCH) ROUTINE
(1) 004454' 000000 INALC: .WORD 0 ;XALC ADDRESS OF "ALLOCATE" ROUTINE
(1) 004456' 000000 INSRV: .WORD 0 ;XSV ADDRESS OF DEVICE DRIVER ROUTINE
(1) 004460' 000000 INDRV: .WORD 0 ;XDN CURRENT DRIVE (UNIT) NUMBER
(1) 004462' INDEV: ;RS POINTS HERE
(1) 004462' 000000 INCM: .WORD 0 ;XCM ADDRESS OF DEVICE'S COMMAND REGISTER
(1) 004464' 000000 INWC: .WORD 0 ;XWC CURRENT WORD COUNT
(1) 004466' 000000 INBA: .WORD 0 ;XBA CURRENT BUS (MEMORY) ADDRESS
(1) 004470' INBLK:
(1) 004470' 000000 INDT: .WORD 0 ;XDT CURRENT BLOCK NUMBER
(1) 004472' 000000 INCOM: .WORD 0 ;XCO CURRENT COMMAND CODE
(1) 004474' 000000 INPRC: .WORD 0 ;XRD READ COMMAND CODE
(1) 004476' 000000 INPWC: .WORD 0 ;XWT WRITE COMMAND CODE
(1) 004500' 000000 INBKCT: .WORD 0 ;XBC REQUESTED BLOCK COUNT
(1) 004502' 000000 INDIR: .WORD 0 ;XDR ADDRESS OF FIRST DIRECTORY BLK #
(1) 004504' 000000 INNBK: .WORD 0 ;XNB LAST BLOCK # ALLOCATED (NEXT BLK #)
(1) 004506' 000 000 000 IFNAM: .BYTE 0,0,0,0,0,0,0,0 ;XXNAM FILE'S NAME IN ASCII (9 CHAR'S)
(1) 004511' 000 000
(1) 004514' 000 000
(1) 004520' 004520' .EVEN
(1) 004520' DOBEND:

```

```

(1)                                     .SBTTL  INITIALIZABLE VARIABLES/ASCII STRINGS
(1)
(1) 004520' 00000C          ICOUNT: .WORD  0
(1) 004522'   000          RUNID:  .BYTE  0
(1) 004523'   000          PIPFLG:  .BYTE  0
(1) 004524'   000   000   000  TXNAM:  .BYTE  0,0,0,0,0,0
(1) 004527'   000   000   000
(1) 004532'   000   000   000  TXEXT:  .BYTE  0,0,0
(1) 004535'          CLREND:
(1)
(1)                                     ;ASCII STRINGS
(1) 004535'   045  000056  ADOT:   .ASCIZ  '%.'
(1) 004540'   011   000  ATAB:   .BYTE  11,0
(1)                                     .EVEN
(1)

```

```

(1) .SBTTL COMMAND, SWITCH, AND DEVICE TABLES
(1) ;ALL COMMANDS ARE CHECKED AGAINST THE QUOTES
(1) ;NO ABBREVIATIONS ALLOWED
(1) COMTAB:
(1) 004542' 000542' .WORD SETQV ;DISPATCH ADDRESS FOR /QV
(2) 004542' 000542' .WORD SETCNT ;DISPATCH ADDRESS FOR /
(2) 004552' 000530' .WORD COMCON ;DISPATCH ADDRESS FOR :
(2) 004560' 000144' .WORD FILL ;DISPATCH ADDRESS FOR F
(2) 004566' 002406' .WORD START ;DISPATCH ADDRESS FOR S
(2) 004574' 002442' .WORD LOAD ;DISPATCH ADDRESS FOR L
(2) 004602' 002726' .WORD RUN ;DISPATCH ADDRESS FOR R
(2) 004610' 002500' .WORD DOIT ;DISPATCH ADDRESS FOR C
(2) 004616' 000214' .WORD DIR ;DISPATCH ADDRESS FOR D
(2) 004624' 002574' .WORD RTSPC ;DISPATCH ADDRESS FOR E
(2) 004632' 000212' .WORD RTSPC ;DISPATCH ADDRESS FOR <15>
(2) 004640' 000212' .WORD GTOK ;DISPATCH ADDRESS FOR <40>
(2) 004646' 000546' .WORD -1
(1) 004654' 177777
(1)
(1)
(1) 004656' DEVTAB:
(1) 004656' 000000G .WORD SETMTO
1334 ;END OF SOURCE.
1335 000001 .END
    
```

ROOT	004535R	005	1333#
AK	001410		1333##
ALC	= 177772		1333#
ALTM00	= 000033		1333#
ALT1	= 000033		1333#
ALT2	= 000175		1333#
ALT3	= 000176		1333#
ARSTRY	001415		1333#
ATAB	004540R	005	1333#
ATO1	001410R	005	1333#
ATO11	001414R	005	1333#
BCDCV	000260R G		1333#
BCD1	000274R		1333#
BCD2	000302R		1333#
BCD3	000354R		1333#
BCD4	000320R		1333#
BCD5	000310R		1333#
BCD6	000340R		1333#
BCD7	000346R		1333#
BCLEAR	002114R G	005	1333#
BEGIN	001000		1333#
BKCT	000216R	005	1333##
BKRD0	001776R	005	1333#
BKREAD	001764R G	005	1333#
BMC1	002122R	005	1333#
BMC2	002134R	005	1333##
BMC3	002142R	005	1333#
BMOVE	002104R G	005	1333#
BTCDOB	003234R	005	1333#
BTCEND	003353R	005	1333#
BUF	003400R G	005	1333#
BURST	000130		1333#
CHAIN	000414R	005	1333#
CHAIN0	000462R	005	1333#
CHAIN1	000472R	005	1333#
CHAIN2	000504R	005	1333#
CHKSUM	003000R	005	1333##
CHN	000142R	005	1333##
CHRCNT	000744R	005	1333##
CHR0UT	000776R G	005	1333#
CKSMER	003070R	005	1333#
CKYB0	001136R	005	1333#
CKYB01	001160R	005	1333#
CLRBEQ	003400R	005	1333#
CLRBUF	002066R G	005	1333#
CLREND	004535R	005	1333#
CLS	= 177764		1333#
CMPIAM	002144R G	005	1333#
COEFF	002400R	005	1333#
COMCON	000144R	005	1333#
COMC01	000110R	005	1333#
COMC02	000162R	005	1333#
COMC03	000140R	005	1333#
COMC05	000174R	005	1333#
COMTAB	004542R	005	1333#
CROHOR	= ***** G		1333#



CREWNO= *****	G		1333c
CRLF		005	1333#
CRLF1		005	1333#
CROUT1		005	1333#
CROUT2		005	1333#
CURDRV		005	1333#*
DATYAB			1333#*
DATJPK	G		1333#
DATJP1			1333#
DATUP2			1333#
DATUP3			1333#
DATUP4			1333#
DATUPS			1333#*
DOBEND		005	1333#
DOBSTR		005	1333#
DECTAB			1333#
DELAY	G	005	1333#
DEVERR	G	005	1333#
DEVTAB		005	1333#
DIR		005	1333#
DLT =			177762
DOIT		005	1333#
DO1		005	1333#
DO2		005	1333#
DO3		005	1333#
DRT =			177756
DYSET		005	1333#
EOMERR	G	005	1333#
ETR =			177766
FHELP			1333#
FILCNT		005	1333#
FILL		005	1333#
FILLCT		005	1333#*
FILNAM		005	1333#
FLNOTF	G	005	1333#
FNAM1		005	1333#
FNAM3		005	1333#
FSTHOP	G		1333#*
GETCHR		005	1333#
GETCR1		005	1333#
GETIN		005	1333#
GETINO		005	1333#
GETIO1		005	1333#
GETIO2		005	1333#
GETIO3		005	1333#
GETIO6		005	1333#
GETIO8		005	1333#
GETI11		005	1333#
GETNUM		005	1333#
GEX02		005	1333#
GEX04		005	1333#
GTDATA		005	1333#
GTNMO		005	1333#
GTMM1		005	1333#
GTNUM1		005	1333#
GTOX		005	1333#

GTOKK	000552R	005	1333#
GTOKX	000560R	005	1333#
GTOKY	000612R	005	1333#
GTOK1	000564R	005	1333#
GTOK2	000570R	005	1333#
GTOK3	000574R	005	1333#
GTOK4	000604R	005	1333#
GTSW	000546R	005	1333#
IBKLG	004430R	005	1333#
ICOUNT	004520R	005	1333#*
IPLCNT	004404R	005	1333#
IFLMOO	004402R	G	005 1333#
IFNAM	004506R	005	1333#*
ILSTBK	004432R	005	1333#
INALC	004454R	005	1333#
INBR	004466R	005	1333#
INBKCT	004500R	005	1333#
INBLK	004470R	005	1333#
INBOOT	004436R	005	1333#
INCLS	004446R	005	1333#
INCM	004462R	005	1333#
INCOM	004472R	005	1333#
INDOB	004400R	005	1333#
INDEV	004462R	005	1333#
INDIR	004502R	005	1333#
INDLT	004444R	005	1333#
INDRT	004440R	005	1333#
INDRV	004460R	005	1333#
INDT	004470R	005	1333#
INETR	004450R	005	1333#
INIT	000070		1333#
INITI	002664R	005	1333#
INNBK	004504R	005	1333#
INPRC	004474R	005	1333#
INPUT	001024R	005	1333#
INPWC	004476R	005	1333#
INSRH	004452R	005	1333#
INSRV	004456R	005	1333#
INVADR	002464R	005	1333#
INVCMO	000624R	G	005 1333#
INVNAM	001672R	005	1333#
INWC	004464R	005	1333#
INZER	004442R	005	1333#
ISBLK	004412R	005	1333#
ISVCH	004410R	005	1333#
ISVDAT	004422R	005	1333#
ISVEXT	004420R	005	1333#
ISVMAP	004406R	005	1333#
ISVNAM	004414R	005	1333#
ISVUPT	004434R	005	1333#
ISVXX	004424R	005	1333#
ITOA	001232R	G	005 1333#
ITOA1	001246R	005	1333#
ITOA2	001302R	005	1333#
ITOA3	001274R	005	1333#
IWCTR	004400R	005	1333#

I1STBK	004426R	005	1333#
KBPTR	001124R	005	1333#*
KBUF	003354R	005	1333#
KCODE	001236		1333#
KTKB	001146R	005	1333#
KTKS	001140R	005	1333#
LIMIT	001232		1333#
LJMP	003130R	005	1333#
LOAD	002726R	005	1333#
LOAD1	002772R	005	1333#
LOAD2	002776R	005	1333#
LOAD3	003054R	005	1333#
LOAD4	003116R	005	1333#
LPE	000142R		1333#
LPS	000140R		1333#
LPSW	000104R		1333#
LTEMP	003214R	005	1333#*
MES	000642R G	005	1333#
MESO	000654R	005	1333#
MESI	000666R	005	1333#
MIBK =	000024		1333#
MININST	001546		1333#
MOO1	002440R	005	1333#
MONCNT =	010000		1333#
MOUT	001000R	005	1333#*
MREG	001004R	005	1333#*
MTBA =	164006		1333#*
MTCH =	164000		1333#*
MTST =	164002		1333#*
MTWC =	164004		1333#*
N3ME	001330		1333#
NOCORE	001434		1333#
NROIR	000000R		1333#
NRGTSW	000074R		1333#
NRSMTB	000144R		1333#
NXTBLK	001750R G	005	1333#
OPEN =	000000		1333#
PACK	000250		1333#
PAKTMP	002250R	005	1333#*
PC =	000007		1333#*
PCOUNT	000102R	005	1333#*
PIPFLG	004523R G	005	1333#*
POFLOW	003104R	005	1333#
PTY7 =	000340		1333#
PS =	177776		1333#
PSW =	177776		1333#
QVMOOE	000217R	005	1333#*
RALC	003310R	005	1333#
RBA	003322R	005	1333#
RBLGT	003264R	005	1333#
RBOOT	003272R	005	1333#
RCKSM	000370R	005	1333#*
RCKSUM	000366R	005	1333#
RCLS	003302R	005	1333#
RCH	003316R	005	1333#
RCOM	003326R	005	1333#

RDFRAM	003162R	005	1333#
RDFRMA	003174R	005	1333#
RDFRMB	003204R	005	1333#
RDIR	003336R	005	1333#
RDLT	003300R	005	1333#
RDRT	003274R	005	1333#
RDRV	003314R	005	1333#
RDT	003324R	005	1333#
RD2FRM	003206R	005	1333#
READBK	002004R	G 005	1333#
READL	001716R	005	1333#
READL1	001746R	005	1333#
READY	000262		1333#
REED	000176		1333#
RELCNT	000652R	G 005	1333#*
RESRS	002236R	G 005	1333#
RESR7	002022R	G 005	1333#
RESR7A	002026R	005	1333#
RESTR	000050R	G 005	1333#
RFLCNT	003240R	005	1333#
RFLMOD	003236R	005	1333#
RFNAM	003342R	005	1333#
RLSTBK	003266R	005	1333#
RNBK	003340R	005	1333#*
RPRC	003330R	005	1333#
RREBKCT	003334R	005	1333#
RRETR	003304R	005	1333#
RPPMC	003332R	005	1333#
RSRCH	003306R	005	1333#
RSRV	003312R	005	1333#
RSTR1	000060R	005	1333#
RST04	002052R	G 005	1333#
RSVBLK	003246R	005	1333#
RSVCNT	003244R	005	1333#
RSVDAT	003256R	005	1333#
RSVEXT	003254R	005	1333#
RSVMAP	003242R	005	1333#
RSVNAM	003250R	005	1333#
RSVUPT	003270R	005	1333#
RSVXX	003260R	005	1333#
RTN	000310		1333#
RTSPC	000212R	005	1333#
RUN	002500R	005	1333#
RUNBUF	000000R	003	1333#
RUN10	004522R	005	1333#*
RUN10	002510R	005	1333#
RUN11	002530R	005	1333#
RUN20	002544R	005	1333#
RUN30	002560R	005	1333#
RUN40	002562R	005	1333#
RWC	003320R	005	1333#
RWCTR	003234R	005	1333#
RWNO	000112		1333#
RZER	003276R	005	1333#
R0	=%000000		1333#*
R1	=%000001		1333#*

R1STBK	003262R	005	1333#
R2	=%000002		1333#*
R3	=%000003		1333#*
R4	=%000004		1333#*
R5	=%000005		1333#*
R6	=%000006		1333#*
R6STCK	000000R	005	1333#
SAV04	002040R G	005	1333#
SETCNT	000530R	005	1333#
SETFST	000066R		1333#
SETI	001442R	005	1333#
SETIN	001446R	005	1333#
SETMTO=	***** G		1333#
SETQV	000542R	005	1333#
SP	=%000006		1333#*
SPBOT	000050R	005	1333#
SRH	= 177770		1333#
STADR	003136R	005	1333#*
START	002442R	005	1333#
TAB	000752R G	005	1333#
TADP	= ***** U		1333
TAPEERR	000306		1333#
TROP	= 000000		1253 1333
TTEXT	004532R	005	1333#
TXNAM	004524R G	005	1333#
UNPACK	002254R G	005	1333#
UNPA01	002314R	005	1333#
UNPA02	002302R	005	1333#
UNPA03	002334R	005	1333#
UNPA04	002340R	005	1333#
UNPA05	002344R	005	1333#
UNPA06	002300R	005	1333#
UNPA07	002262R	005	1333#
UNPA08	002372R	005	1333#
UNPA09	002266R	005	1333#
UPACK1	002244R G	005	1333#
UPKNAM	002212R G	005	1333#
UPKNM1	002236R	005	1333#
XBA	= 000004		1333#*
XBC	= 000016		1333#
XBKLG	= 177746		1333#
XBT	= 177754		1333#
XCM	= 000000		1333#
XCO	= 000010		1333#*
XDN	= 177776		1333#
XDR	= 000020		1333#*
XDT	= 000006		1333#*
XFLCNT=	177722		1333#
XFLMOD=	177720		1333#*
XLSTBK=	177750		1333#
XNB	= 000022		1333#
XRD	= 000012		1333#
XSV	= 177774		1333#
XSVBLK=	177730		1333#
XVCNT=	177726		1333#
XVDATE=	177740		1333#

XSVEXT=	177736		1333#
XSVMAP=	177724		1333#
XSVNAM=	177732		1333#
XSVUPT=	177752		1333#
XSVXX =	177742		1333#
XWAC =	000002		1333##
XWCTR =	177716		1333#
XWT =	000014		1333#
XXNAM =	000024		1333#
XYBK	002012R	005	1333#
X1STBK=	177744		1333##
YES	001316R	005	1333##
ZER =	177760		1333#
\$APR	000622R		1333#
\$AUG	000652R		1333#
\$BUF	002102R	G 005	1333#
\$BUF2	002072R	G 005	1333#
\$COMC3	000136R	005	1333##
\$DEC	000702R		1333#
\$FEB	000606R		1333#
\$IDOB	001452R	G 005	1333#
\$JAN	000600R		1333#
\$JUL	000644R		1333#
\$JUN	000636R		1333#
\$LITB	002622		1333#
\$MAR	000614R		1333#
\$MAY	000630R		1333#
\$NOV	000674R		1333#
\$OCT	000666R		1333#
\$REL1	000154R	005	1333#
\$REL10	002536R	005	1333#
\$REL11	000052R	005	1333#
\$REL12	000372R	005	1333#
\$REL13	000340R	005	1333#
\$REL14	002274R	005	1333#
\$REL15	002150R	005	1333#
\$REL16	001460R	005	1333#
\$REL2	001566R	005	1333#
\$REL3	001550R	005	1333#
\$REL4	000332R	005	1333#
\$REL5	000270R	005	1333#
\$REL6	000250R	005	1333#
\$REL7	001510R	005	1333##
\$SEP	000660R		1333#
\$TPM1	000202R	G	1333#
\$TXNAM	002156R	G 005	1333#
=	004660R	005	1333#

INITI	41#	1333
READL	50#	1333
RESREG	26#	1333
RESRS	29#	1333
RESR7	32#	1333
ROUTIN	53#	
SAVREG	23#	1333
SETBN	47#	
SETIN	44#	1333
TOKN	5#	1333
TOKNS	14#	1333
UNPACK	35#	1333
UPACK1	38#	1333
XDPMON	109#	1333
\$BOOT	1254#	1333
\$IDENT	63#	1333

ADD	1333	
ASL	1333	
ASR	1333	
BCC	1333	
BCS	1333	
BEQ	1333	
BGE	1333	
BGT	1333	
BHI	1333	
BHIS	1333	
BIC	1333	
BICB	1333	
BIS	1333	
BIT	1333	
BLE	1333	
BLO	1333	
BLOS	1333	
BLT	1333	
BMI	1333	
BNE	1333	
BPL	1333	
BR	1333	
CLR	1333	
CLRB	1333	
CMP	1333	
CMPB	1333	
DEC	1333	
HALT	1333	
INC	1333	
INCB	1333	
JMP	1333	
JSR	1333	
MOV	1333	
MOVB	1333	
NOP	1333	
ROL	1333	
RTI	1333	
RTS	1333	
SUB	1333	
SWAB	1333	
TST	1333	
*STB	1333	
.ASCII	1333	
.ASCIZ	1333	
.ASECT	1333	
.BLKW	1333	
.BYTE	1333	
.CSECT	1333	
.END	1335	
.ENOC	1332	1333
.EVEN	1333	
.GLOBL	1333	
.YDF	1253	1333
.YF	1333	
.YF	1333	
.YF	1333	



K04

TRDP - XXDP TR79F MONITOR M-11-DMQUB-B MACY11 27(732) 01-MAR-77 10:34 PAGE 4-1  
DMQUB.P11 CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

SEQ 0049

.LIMIT	1333																
.LIST	3	4	1333														
.MACRO	5	14	23	26	29	32	35	38	41	44	47	50	53	63	109		
	1254																
.MLIST	1	2	1333														
.PAGE	1333																
.REM	1333																
.SBTTL	1333																
.TITLE	1333																
.WORD	1333																

ABS.	002706	000
	000710	001
MTDIRT	000000	002
RUNBUF	001000	003
TRBF	000000	004
RESMON	004660	005

ERRORS DETECTED: 0  
DEFAULT GLOBALS GENERATED: 0

\*TRDPM,TRDPM.LST/CRF=DMQUB.P11/EQ:TRDP  
RUN-TIME: 3 4 .6 SECONDS  
RUN-TIME RATIO: 295/9=32.5  
CORE USED: 16k (31 PAGES)

1  
2  
1000  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)  
(1)

000000  
000001  
000002  
000003  
000004  
000005  
000006  
000006  
000007  
177776  
000000  
000200  
100000  
177716  
177720  
177722  
177724  
177726  
177730  
177732  
177736  
177740  
177742  
177744  
177746  
177750  
177752  
177754  
177756  
177760  
177762  
177764  
177766  
177770  
177772  
177774  
177776  
000000  
000002  
000004  
000006  
000010  
000012  
000014  
000016  
000020  
000022  
000024

.LIST ME  
.NLIST MC, MD, CND, TOC  
.TITLE TR79F - XXDP TR79F MODULE READ-ONLY  
.SBTTL EQUATES

R0 =%0  
R1 =%1  
R2 =%2  
R3 =%3  
R4 =%4  
R5 =%5  
R6 =%6  
SP =%6  
PC =%7  
PS =177776  
OPEN =0  
DONE =200  
ERROR =100000  
XWCTR =-62  
XFLMOD =-60  
XFLCNT =-56  
XSVMAP =-54  
XSVCNT =-52  
XSVBLK =-50  
XSVNAM =-46  
XSVEXT =-42  
XSVDAT =-40  
XSVXX =-36  
XISTBK =-34  
XBKLGIT =-32  
XLSTBK =-30  
XSVUPT =-26  
XBT =-24  
DRT =-22  
ZER =-20  
DLT =-16  
CLS =-14  
ETR =-12  
SRH =-10  
ALC =-6  
XSV =-4  
XDN =-2  
XCM =0  
XWC =2  
XBA =4  
XDT =6  
XCO =10  
XRD =12  
XWT =14  
XBC =16  
XDR =20  
XNB =22  
XXNAM =24

: INDEX TO WRITE COUNTER.  
: INDEX TO FILE MODE INDICATOR  
: INDEX TO FILE COUNT  
: PHONY UFD BLOCK POINTERS  
: INDEX TO BOOT ROUTINE.  
: INDEX TO DIRECTORY ROUTINE  
: INDEX TO ZERO ROUTINE  
: INDEX TO DELETE ROUTINE  
: INDEX TO CLOSE ROUTINE  
: INDEX TO ENTER ROUTINE  
: INDEX TO LOOKUP ROUTINE  
: INDEX TO ALLOCATE ROUTINE  
: INDEX TO SERVICE ROUTINE (DRIVER).  
: DRIVE NUMBER INDEX  
: INDEX TO COMMAND REGISTER  
: INDEX TO WORD COUNT  
: INDEX TO BUS ADDRESS  
: INDEX TO BLOCK NUMBER  
: INDEX TO COMMAND  
: INDEX TO READ COMMAND  
: INDEX TO WRITE COMMAND  
: INDEX TO REQUESTED BLOCK COUNT  
: INDEX TO 1ST DIR BLOCK POINTER.  
: INDEX TO LAST BLOCK # ALLOCATED.  
: INDEX TO ASCII NAME IN DDB

```
(1) .SBTTL GLOBAL REFERENCE DEFINITIONS
(1) ;EXTERNAL GLOBAL DEFINITIONS
(1)
(1) .GLOBL BMOVE,BCLEAR,CHROUT,CRLF
(1) .GLOBL CLRBUF,CMPNAM
(1) .GLOBL DEVERR,ITOA,MES
(1) .GLOBL NXTBLK,IXNAM,RELCNT
(1) .GLOBL FLNOTF,READBK
(1) .GLOBL RSTO4,SAVO4,UNPACK,UPACK1
(1) .GLOBL EOMERR,BKREAD
(1) .GLOBL BUF,DELAY
(1) .GLOBL PIPFLG,UPKNAM,IFLMD
(1) .GLOBL $TXNAM,$BUF2,$BUF
(1) .GLOBL RESR7,INVCMD
(1) .GLOBL BCDCV
(1) .GLOBL DATUPK
(1) .GLOBL TAB
(1) .GLOBL $TPNM1
(1) .GLOBL FSTMOD
```

1001  
(1) 000000' 000000G  
(1) 000002' 000000'  
(1) 000004' 000000G  
(1) 000006' 000000G  
(1) 000010' 000000G  
(1) 000012' 000000G  
(1) 000014' 000040'  
(1) 000016' 000000G  
(1) 000020' 000570'  
(1) 000022' 000000  
(1) 000024' 164000  
(1) 000026' 000000  
(1) 000030' 000000  
(1) 000032' 000000  
(1) 000034' 000000  
(1) 000036' 000005  
(1) 000040' 000003  
(1) 000042' 000000  
(1) 000044' 000050'  
(1) 000046' 000000  
(1) 000050'

.SBTTL PARAMETER TABLE

PARAM: INVCMD  
DIRECT  
INVCMD  
INVCMD  
INVCMD  
INVCMD  
LOOKUP  
INVCMD  
DRIVER  
UNIT: 0  
CMDREG: 164000  
WCOUNT: 0  
BUSADR: 0  
BLOCK: 0  
COMD: 0  
READ: 5  
WRITE: 3  
RBKCT: 0  
DIRPTR: DIRBLK  
LSTBLK: 0  
PAREND:

:UNIT #  
:COMMAND REGISTER ADDR  
:WORD COUNT  
:BUS ADDRESS  
:BLOCK NUMBER  
:COMMAND  
:READ COMMAND  
:WRITE COMMAND  
:REQUESTED BLOCK COUNT  
:POINTS TO 1ST DIR BLOCK.  
:LAST BLOCK # ALLOCATED

1002  
(1) 000050' 177777  
(1) 000052' 000106'  
(1) 000054' 000142'  
(1) 000056' 000000G  
(1) 000060' 000000G  
(1) 000062' 000000G  
(1) 000064' 000352'  
(1) 000066' 000000G  
(1)  
1003 000070' 164002  
1004 000072' 164000  
1005 000074' 164004  
1006 000076' 164006  
1007

.PARAMETER TABLE FOR MTCOM SECTION.

DIRBLK: -1  
REWIND  
SKIPR  
INVCMD  
INVCMD  
INVCMD  
RDHDR  
INVCMD  
MTST: 164002  
MTCM: 164000  
MTWC: 164004  
MTBA: 164006

:-1 INDICATES SEQUENTIAL FILE DEVICE.  
:POINTS TO REWIND ROUTINE.  
:POINTS TO SKIP REVERSE BLOCK ROUTINE.  
:CLRHDR POINTER.  
:WRTHDR POINTER.  
:WRTEOF POINTER.  
:POINTS TO RDHDR ROUTINE.  
:WEOT POINTER

TR79F - XXDP R79F MODULE READ-ONLY  
DMAQUB.P12 SETMT ROUTINE

MACY11 27(732) 01-MAR-77 10:27 PAGE 1-3

SEQ 0053

1009  
1010 00010C'  
1012 000100' 01270C 00000C'  
1013 000104' 000207  
1014

.SBTTL SETMT ROUTINE  
SETMTD::  
MOV #PARAM,RO  
RTS PC

;POINT TO PARAM TABLE.  
;DONE. RETURN.

```

1016
1017 000106' 004767 000062 REWIND: JSR .SBTTL MAGTAPE ROUTINES
1018 000112' 032777 00004C 177750 BIT PC, MTD0V ; SELECT DRIVE
1019 000120' 001005 BNE #40, MNTST ; AT LOAD PIONT
1020 000122' 042703 000377 BIC #377, R3 ; BRANCH IF YES
1021 000126' 052703 000021 BIS #21, R3 ; CLEAR OUT GARBAGE
1022 000132' 000440 BR MTD0 ; REWIND
1023 000134' 004767 000026 IS: JSR PC, WRTIDB ; CHCK FOR DONE
1024 000140' 000207 RTS PC ; GO WRITE IDB
1025 000142' 004767 000026 SKIPR: JSR PC, MTD0V ; RETURN
1026 000146' 042703 000377 BIC #377, R3 ; SELECT DRIVE
1027 000152' 052703 000011 BIS #11, R3 ; CLEAR OUT GARBAGE
1028 000156' 012765 000001 MOV #1, XWC(R5) ; BACK SPACE
1029 000164' 000423 BR MTD0
1030 000166' 012703 000005 WRTIDB: MOV #5, R3 ; W/R IDB
1031 000172' 000420 BR MTD0 ;
1032 000174' 005003 MTD0V: CLR R3 ;
1033 000176' 116503 000013 MOVB XRD+1(R5), R3 ; GET DRIVE NUMBER
1034 000202' 000303 SWAB R3 ; PUT IN LEFT HALF
1035 000204' 010377 177662 MOV R3, MNTCM ; SELECT THE DRIVE.
1036 000210' 004767 000066 JSR PC, MTD02 ; WAIT FOR DRIVE RDY
1037 000214' 000207 RTS PC ; RETURN.
1053
1054
1055 000216' 012767 000002' 000000' TRBSET: MOV #TRBUF, TRBF ;
1056 000224' 066767 00000C' 000000' ADD RELCNT, TRBF ;
1057 000232' 000207 RTS PC ;
1058
1059
1060
1061
1062 000234' 016577 000002 177632 MTD0: MOV XWC(R5), MNTWC ; GET WORD COUNT
1063 000242' 005477 177626 NEG MNTWC
1064 000246' 004767 177744 JSR PC, TRBSET
1065 000252' 016777 000000' 177616 MOV TRBF, MNTBA ; MEM. ADDR.
1066 000260' 005077 177604 IS: CLR MNTST ; CLEAR STATUS
1067 000264' 010377 177602 MOV R3, MNTCM ; SET THE FUNCTION AND GO
1068 000270' 032777 100200 177574 MTD01: BIT #ERROR+DONE, MNTCM ; DONE?
1069 000276' 001774 BEQ MTD01 ; WAITING
1070 000300' 100413 BMI MTERR ; ERROR
1071 000302' 032777 000001 177560 MTD02: BIT #1, MNTST ; DRIVE READY?
1072 000310' 001774 BEQ MTD02 ; LOOP TILL DONE
1073 000312' 032777 000040 177550 BIT #40, MNTST ; LOAD PIONT
1074 000320' 001402 BEQ IS
1075 000322' 004767 177640 JSR PC, WRTIDB
1076 000326' 000207 IS: RTS PC ;
1077 000330' 032777 000010 177532 MTERR: BIT #10, MNTST ; EOF?
1078 000336' 001403 BEQ MTER1 ; NO
1079 000340' 105267 000000' INCB EOFSEN ; SET EOF SEEN FLAG
1080 000344' 000756 BR MTD02 ; WAIT FOR DRIVE TO SETTLE DOWN
1081 000346' 000167 000000G MTER1: JMP DEVERR ; DEVICE ERROR.
1087
1088
1089
1090
1091

```

1092  
1093  
1094  
1095  
1096  
1097  
1098  
1099  
1100  
1101  
1102  
1103  
1104  
1105  
1106  
1107  
1108  
1109  
1110  
1111  
1112  
1113  
1114  
1115  
1116  
1117  
1118  
1119  
1120  
1121  
1122  
1123  
1124  
1125  
1126  
1127  
1128  
1129  
1130  
1131  
1132  
1133  
1134  
1135  
1136  
1137  
1138  
1139  
1140  
1141  
1142  
1143  
1144  
1145  
1146

000352' 105067 000000'  
000356' 004767 177612  
000362' 012767 177762 000176  
000370' 012777 177762 177476  
000376' 016767 000000G 000160  
000404' 004767 177606  
000410' 016777 000000' 177460  
000416' 005077 177446  
000422' 016577 000012 177442  
000430' 004767 177646  
000434' 032777 100200 177430  
000442' 001774  
000444' 100422  
000446' 032777 000010 177414  
000454' 001407  
000456' 105267 000000'  
000462' 022767 000003 000000'  
000470' 001405  
000472' 000731  
000474' 062716 000002  
000500' 004767 000020  
000504' 005767 000000G  
000510' 000207  
000512' 032777 001000 177350  
000520' 001316  
000522' 000711

RHDR: CLR B EOFFSEN  
RHDRS: JSR PC, MDRV  
MOV #-14, BYTCNT  
MOV #-14, JMTWC  
MOV \$BUF, DES  
JSR PC, TRBSET  
MOV TRBF, JMTBA  
CLR JMTST  
MOV XRD(R5), JMTCM  
JSR PC, MTD02  
RHDR1: BIT #ERROR+DONE, JMTCM  
BEQ RHDR1  
BMI RHDR3  
RHDR2: BIT #10, JMTST  
BEQ RHDR6  
INCB EOFFSEN  
CMP #3, EOFFSEN  
BEQ RHDR4  
BR RHDR5  
RHDR6: ADD #2, JSP  
JSR PC, PAK  
RHDR4: TST BUF  
RTS PC  
RHDR3: BIT #1000, JMTST  
BNE RHDR5  
BR MTER1

;KEEP TRACK OF EOF'S SEEN  
;SEE WHAT HAPPENS  
;SET BYTE COUNT  
;  
;CLEAR INHIBIT  
;DO A READ  
;TEMP FIX MAKE SURE OF DONE  
;DONE?  
;NO  
;ERROR  
;EOF?  
;NO  
;UP COUNT OF EOF'S SEEN.  
;SEEN 3?  
;BR IF YES. EOT.  
;NO ERRORS SKIP RETURN  
;GO PACK THE BUFFER  
;  
;BLOCK LENGTH ERROR?  
;DATA BLOCK  
;SOME KINDA ERROR.  
;SAVE REGS 0-4  
;GET INPUT BUFFER  
;GET OUTPUT BUFFER  
;PACK IT IN  
;POINT TO NEXT WORD  
;COUNT THE BYTE  
;BR IF NOT FINISHED  
;RESTORE REGS 0-4

PAK:  
JSR R4, SAV04  
JSR PC, TRBSET  
MOV TRBF, RO  
MOV DES, R1  
IS: MOV B (RO)+, (R1)+  
INC RO  
INC BYTCNT  
BNE IS  
JSR PC, RST04  
RTS PC

1147  
1148  
1149  
1150  
1151  
1152  
1153  
1154  
1180  
1181  
1182  
1183  
1184  
1185  
1186  
1187  
1188  
1189  
1190  
1191  
1192  
1193  
1194  
1195  
1196  
1197  
1203  
1204  
1205  
1206  
1207  
1208  
1209  
1214  
1215  
1216  
1217  
1218  
1219  
1220  
1221  
1222

000564' 000000  
000566' 000000  
  
000570' 105067 000000'  
000574' 016567 000004 177762  
000602' 012767 177000 177756  
000610' 012777 177000 177256  
000616' 004767 177374  
000622' 016777 000000' 177246  
000630' 004767 177340  
000634' 005077 177230  
000640' 016577 000010 177224  
000646' 004767 177416  
000652' 004767 177646  
000656' 062767 001000 177700  
000664' 105767 000000'  
000670' 001007  
000672' 105767 000000G  
000676' 001004  
000700' 162765 000400 000002  
000706' 003335  
000710' 000207

DES: 000  
BYTCNT: 000

:THE DRIVER  
DRIVER: CLRB

1\$: MOV  
11\$: MOV  
JSR  
MOV  
JSR  
CLR  
MOV  
JSR  
JSR  
2\$: ADD  
TSTB  
BNE  
TSTB  
BNE  
SUB  
BGT  
3\$: RTS

EOFSN  
XBA(R5), DES  
#-512., BYTCNT  
#-512., AMTWC  
PC, TRBSET  
TRBF, AMTBA  
PC, MTD0V  
AMTST  
XCO(R5), AMTCM  
PC, MTD01  
PC, PAK  
#512., DES  
EOFSN  
3\$  
PIPLFG  
3\$  
#256., XWC(R5)  
1\$  
PC

:SAW NO EOF YET  
:LOAD POINTER  
:256 WORDS PER RECORD  
:SET WORD COUNT IN DEVICE  
:  
:SELECT THE DRIVE.  
:CLEAR INHIBIT  
:EXECUTE COMMAND  
:WAIT FOR DONE  
:  
:UPDATE  
:EOF ???  
:BRANCH IF YES  
:PIP MODE?  
:YES, EXIT  
:DECREMENT WC  
:NOT DONE YET



TR79F - XXDP TR79F MODULE READ-ONLY  
DMQUB.P12 MAGTAPE ROUTINES

MACY11 27.732) 01-MAR-77 10:27 PAGE 1-7

SEQ 0057

- 1224
- 1225
- 1226
- 1227
- 1228
- 1229
- 1230



```

(1)                                     .SBTTL  LOOKUP ROUTINE
(1)
(1) 000040' 005765 177722 LOOKUP: TST XFLCNT(R5) ; FILE COUNT 0?
(1) 000044' 001403 BEQ 1$ ; BR IF YES. GO REWIND.
(1) 000046' 005765 177720 TST XFLMOD(R5) ; IN FILE MODE?
(1) 000052' 001002 BNE SEARCH ; BR IF YES.
(1) 000054' 004767 177722 1$: JSR PC, CREWIND ; REWIND TAPE.
(1) 000060' 004767 177732 SEARCH: JSR PC, CRDHDR ; READ HEADER BLOCK.
(1) 000064' 000443 BR 4$ ; NOT FOUND. AT EOT.
(1) 000066' 005265 177722 INC XFLCNT(R5) ; INCREMENT FILE COUNT.
(1) 000072' 005767 000000G TST BUF ; DELETED FILE?
(1) 000076' 001770 BEQ SEARCH ; BR IF YES. SKIP IT.
(1) 000100' 016767 000000G 000012 MOV $TXNAM, 2$
(1) 000106' 016767 000000G 000006 MOV $BUF, 2$+2
(1) 000114' 004567 000000G JSR R5, UPKNAM ; CONVERT NAME TO ASCII.
(1) 000120' 000000 000000 2$: OPEN, OPEN
(1) 000124' 004567 000000G JSR R5, CMPNAM ; COMPARE NAMES.
(1) 000130' 000753 BR SEARCH ; NO MATCH.
(1) 000132' 016765 000000G 177732 MOV BUF, XSVNAM(R5) ; STORE NAME IN DDB.
(1) 000140' 016765 000002G 177734 MOV BUF+2, XSVNAM+2(R5)
(1) 000146' 016765 000004G 177736 MOV BUF+4, XSVEXT(R5) ; STORE EXTENSION.
(1) 000154' 016765 000012G 177740 MOV BUF+10, XSVDAT(R5) ; THE DATE TOO.
(1) 000162' 016765 000014G 177746 MOV BUF+12, XBKLG(R5) ; FILE LENGTH ALSO.
(1) 000170' 062716 000002 ADD #2, (SP) ; SET UP SUCCESS EXIT.
(1) 000174' 000207 4$: RTS PC ; DONE. RETURN.
(1)
(1)
(1)

```

TR79F - XXOP TR79F MODULE READ-ONLY  
DMQUB.F.P12 LOOKUP ROUTINE

MACY11 27(732) 01-MAR-77 10:27 PAGE 1-10

SEQ 006C

```

(1)          000000'
(1) 000000' 000002'
(1) 000002' 001000
(1)
(1)          000000'
(1) 000000' 004567' 000000G
(1) 000004' 000074'
(1) 000006' 004767' 000040'
(1) 000012' 000426
(1) 000014' 004767' 000000G
(1) 000020' 016503 177722
(1) 000024' 004767' 000000G
(1) 000030' 004767' 000000G
(1) 000034' 004767' 000000G
(1) 000040' 016503 177740
(1) 000044' 004767' 000000G
(1) 000050' 005765 177740
(1) 000054' 100354
(1) 000056' 112702 000103
(1) 000062' 004767' 000000G
(1) 000066' 000747
(1) 000070' 000167 000002'
(1) 000074'
(1) 000074' 042445 052116 054522
(1) 000102' 004443 044506 047114
(1) 000110' 046501 042456 052130
(1) 000116' 042011 052101 022505
(1) 000124' 000
(1)          000126'
2310          000001

```

```

.CSECT TRBF
TRBF: TRBUF
TRBUF: .BLKW 512.
       .SBTTL DIRECTORY ROUTINE
       .CSECT MDIRT
DIRECT: JSR RS,MES ;WHAT KINDA TAPE
        HEADER
1$: JSR PC,LOOKUP ;FIND A FILE.
   BR 2$ ;BR IF NO MORE.
   JSR PC,CRLF ;CRLF
   MOV XFLCNT(R5),R3 ;TYPE FILE COUNT.
   JSR PC,ITOA ;DO IT.
   JSR PC,TAB ;TAB.
   JSR PC,STPNM1 ;TYPE FILE NAME.
   MOV XSV DAT(R5),R3 ;TYPE FILE DATE.
   JSR PC,DATUPK ;DO IT.
   TST XSV DAT(R5) ;CONTIGUOUS FILE?
   BPL 1$ ;BR IF NOT.
   MOVB #'C,R2 ;YES. TYPE A C.
   JSR PC,CHROUT ;DO IT.
   BR 1$ ;GO FOR MORE.
2$: JMP CREWND ;REWIND TAPE

HEADER: .ASCIZ '%ENTRY#'<11>'FILNAM.EXT'<11>'DATE%'

.EVEN
.END

```

ALC = 177772		1000#							
BCDCV = *****	G	1000#							
BCLFAR= *****	G	1000#							
BKREAD= *****	G	1000#							
BLOCK 000032R		1001#							
BMOVE = *****	G	1000#							
BUF = *****	G	1000#	1126	1231					
BUSADR 000030R		1001#							
BYTCNT 000566R		1107#	1143#	1192#	1197#				
CCLMD = 000006		1231#							
CDIR = 000000		1231#							
CHROUT= *****	G	1000#	1231						
CLRBUF= *****	G	1000#							
CLS = 177764		1000#							
CMDREG 000024R		1001#							
CMPNAM= *****	G	1000#	1231						
COMD 000034R		1001#							
COMMON 000022R	002	1231#							
CRDHR 000016R	G 002	1231#							
CREWID 000002R	G 002	1231#							
CRHD = 000014		1231#							
CRLF = *****	G	1000#	1231						
CRWD = 000002		1231#							
CSKIPR 000010R	002	1231#							
CSKPR = 000004		1231#							
CMEOF = 000012		1231#							
CWTHD = 000010		1231#							
DATUPK= *****	G	1000#	1231						
DELAY = *****	G	1000#							
DES 000564R		1109#	1140	1191#	1196#	1215#			
DEVERR= *****	G	1000#	1086						
DIRBLK 000050R		1001	1002#						
DIRECT 000000R	004	1001	1231#						
DIRPTR 000044R		1001#							
DLT = 177762		1000#							
DONE = 000200		1000#	1073	1115					
DRIVER 000570R		1001	1195#						
DRT = 177756		1000#							
EOFSEN 000000R	002	1084#	1105#	1120#	1121	1195#	1216	1231#	
EOMERR= *****	G	1000#							
ERROR = 100000		1000#	1073	1115					
ETR = 177766		1000#							
FLNOTF= *****	G	1000#							
FSTM00= *****	G	1000#							
HEADER 000074R	004	1231#							
IFLM00= *****	G	1000#							
INVCMD= *****	G	1000#	1001	1002					
ITOA = *****	G	1000#	1231						
LOOKUP 000040R	002	1001	1231#						
LS'BLK 000046R		1001#							
MES = *****	G	1000#	1231						
MTBA 000076R		1006#	1065#	1111#	1205#				
MTCH 000072R		1004#	1035#	1072#	1073	1113#	1115	1208#	
MTD0 000234R		1022	1029	1031	1062#				
MTD01 000270R		1073#	1074	1209					
MTD02 000302R		1036	1076#	1077	1085	1114			



TR79F = 000000		999		
TXNAM = *****	G	1000#		
UNIT = 000022R		1001#		
UNPACK = *****	G	1000#		
UPACK1 = *****	G	1000#		
UPKNAM = *****	G	1000#	1231	
WCOUNT = 000026R		1001#		
WRITE = 000040R		1001#		
WRTIOB = 000166R		1023	1030#	1080
XBA = 000004		1000#	1196	
XBC = 000016		1000#		
XBKLG1 = 177746		1000#	1231*	
XBT = 177754		1000#		
XCM = 000000		1000#		
XCO = 000010		1000#	1208	
XDM = 177776		1000#		
XDR = 000020		1000#	1231	
XDT = 000006		1000#		
XFLCNT = 177722		1000#	1231*	
XFLMOD = 177720		1000#	1231	
XLSTBK = 177750		1000#		
XNB = 000022		1000#		
XRD = 000012		1000#	1033	1113
XSV = 177774		1000#		
XSVBLK = 177730		1000#		
XSVCNT = 177726		1000#		
XSVDAT = 177740		1000#	1231*	
XSVEXT = 177736		1000#	1231*	
XSVMAP = 177724		1000#		
XSVNAM = 177732		1000#	1231*	
XSVUPT = 177752		1000#		
XSVXX = 177742		1000#		
XWC = 000002		1000#	1028*	1062 1220*
XWCTR = 177716		1000#		
XWT = 000014		1000#		
XXNAM = 000024		1000#		
XXXXX = *****	L	3		
X1STBK = 177744		1000#		
ZER = 177760		1000#		
\$BUF = *****	G	1000#	1109	1231
\$BUF2 = *****	G	1000#		
\$TPNM1 = *****	G	1000#	1231	
\$TXNAM = *****	G	1000#	1231	
= 000126R		004	1231#	

DKCOMM	250#	
CKPAM	209#	
NTCOMM	820#	1231
MTPAM	225#	1002
PACK	54#	
PACK1	58#	
PARAM	170#	1001
RESREG	45#	1145
RESRS	48#	
RESR7	51#	
ROUTIN	32#	
SAVREG	42#	1137
TITLE	70#	1000
UNPACK	62#	
UPACK1	66#	





ERRORS DETECTED: 0  
DEFAULT GLOBALS GENERATED: 0

\*TR79FR,TR79FR.LST/CRF=DMQUB.P12/EQ:TR79F/EQ:RONLY  
RUN-TIME: 2 2 .3 SECONDS  
RUN-TIME RATIO: 167/5=28.6  
CORE USED: 13K (25 PAGES)

LNKX11 V022 1-MAR-77 10:41

#DMQUB.BIN/T:20000,TRDP.MAP=TRDPH,TR79FR/E

LOAD MAP

TRANSFER ADDRESS: 000001  
LOW LIMIT: 005750  
HIGH LIMIT: 020000

\*\*\*\*\*

MODULE	TRDP	ADDRESS	SIZE
SECTION ENTRY			
(.ABS.)		000000	000000
(. )		005750	000710
BCDCV		006230	
DATUPK		006346	
FSTMOD		006034	
STPMM1		006152	
(MTDIRT)		006660	000126
(RUNBUF)		007006	001000
(TRBF)		010006	002002
(RESMON)		012010	004660
BCLEAR		014124	
BKREAD		013774	
BMOVE		014114	
BUF		015410	
CHROUT		013006	
CLRBUF		014076	
CMFNAM		014154	
CRLF		012712	
DELAY		012212	
DEVERR		013226	
EOMERR		014040	
FLNOTF		014722	
IFLMOD		016412	
INVCMD		012634	
ITOA		013242	
MES		012652	
NXTBLK		013760	
PIPFLG		016533	
READBK		014014	
RELCNT		012662	
RESAS		014246	
RESR7		014032	
RESTR		012060	

RST04 014062  
SAY04 014050  
TAB 012762  
TXNAM 016534  
UNPACK 014264  
UPACK1 014254  
UPKNAM 014222  
SBUF 014112  
SBUF2 014102  
\$ID08 013462  
\$TXNAM 014166

\*\*\*\*\*

MODULE	TR79F	ADDRESS	SIZE
SECTION	ENTRY		
(	)	016670	000712
	SETMTD	016770	
(MTCOMM)		017602	000176
	CRDHDR	017620	
	CREMNO	017604	

RUN-TIME: 0 SECONDS

006