

.REPT B

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZLPA-B-D
SUPERCEDES 11-D2CA
PRODUCT NAME: LP11 LINE PRINTER TEST
DATE: DECEMBER, 1975
MAINTAINER: DIAGNOSTIC GROUP
AUTHOR: EARL HAIGHT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1972,1975 BY DIGITAL EQUIPMENT CORPORATION

AI

47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97

1. ABSTRACT

THE LP11 LINE PRINTER DIAGNOSTIC TEST PROGRAM IS DESIGNED TO PROVIDE A THOROUGH CHECK-OUT OF THE PRINTER CONTROL INTERFACE ELECTRONICS AS WELL AS THE ELECTRONIC AND MECHANICAL PORTIONS OF THE LINE PRINTER MECHANISM ITSELF. THE PROGRAM CONSISTS OF A SERIES OF SEVEN (7) TEST AND DRIVE ROUTINES, EACH OF WHICH CAN BE SELECTED AND OPERATED INDEPENDENTLY OF THE OTHERS USING SPECIAL ENTRY POINTS. INTERNALLY DETECTED ERROR CONDITIONS ARE DISPLAYED ON THE TELEPRINTER WHILE DETAILED DESCRIPTIONS OF EACH ERROR AND WHAT WAS HAPPENING AT THE TIME THE ERROR OCCURRED, IS PRESENTED IN THE LISTING. PRINT PATTERNS USED IN THESE TESTS HAVE BEEN CHOSEN FOR EASE OF VISUAL VERIFICATION.

THE FIRST TEST (TEST 1) IS COMPOSED OF SEVERAL TESTS DESIGNED TO CHECK-OUT THE PROCESSOR INTERFACE CONTROL ELECTRONICS AND INTERCOMMUNICATIONS DATA PATHS. TEST 2, 3, AND 4 USE WORST CASE PATTERNS TO TEST PRINTER PERFORMANCE AND ENDURANCE WHILE TESTS 5 AND 6 PROVIDE DRIVE FOR PRINTER HAMMER ALIGNMENT AND INTENSITY ADJUSTMENT PROCEDURES AND A TEST OF THE PAPER SLEM AND CLUTCH OPERATIONS.

TEST 7 CONSISTS OF SEVERAL SUB-TESTS AND MAINTENANCE AIDS AMONG THEM A SCOPE DRIVE TEST, FOR HELPING THE TECHNICIAN TO DERUG THE HARDWARE.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 PROCESSOR
TELETYPE MODEL 33 ASCII KEYBOARD PRINTER
DATA PRODUCTS, MODEL 2318, LINE PRINTER
LP11 LINE PRINTER CONTROL UNIT

2.2 STORAGE

MEMORY LOCATION 0 TO 7000

2.3 PRELIMINARY PROGRAMS (NONE)

3. LOADING PROCEDURE

98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151

3.1 METHOD

POWER DOWN THE LINE PRINTER
POWER UP THE PDP-11 ONLY
LOAD THE ABSOLUTE LOADER
LOAD THE LP11 DIAGNOSTIC PROGRAM TAPE
AFTER LOADING HAS BEEN COMPLETED, LOAD ADDRESS 0200
DEPRESS STANT AND PROCEED WITH THE LINE PRINTER POWER-UP TEST
SEQUENCE.

4. STARTING PROCEDURE

4.1 STARTING ADDRESS OR ADDRESSES

THE INITIAL STARTING ADDRESS FOR THE LP11 LINE PRINTER TEST IS
LOC. 0200. THE RESTART ADDRESS IS 600.

4.2 PROGRAM AND/OR OPERATOR ACTION

DURING INITIAL START-UP OF THE LINE PRINTER DIAGNOSTIC TEST
THE HEADER MESSAGE "MAINDEC-11-D2CA LINE PRINTER TEST" WILL BE
TYPED ON THE TELEPRINTER FOLLOWED BY RESTART ADDRESS 600
EXECUTION OF THE PRINTER READY PORTION OF TEST 1. PRINTING OF
THE MESSAGE "POWER-UP" ON THE TELEPRINTER INDICATES START OF
THIS TEST SEQUENCE. THIS TEST IS CARRIED OUT BY AN
INTERACTIVE EXCHANGE BETWEEN THE TEST AND THE USER.

5. SWITCH REGISTER SETTINGS

THE USE OF THIS PROGRAM ON PROCESSORS NOT HAVING A HARDWARE
SWITCH REGISTER NECESSITATES OPERATOR INTERACTION. THE
OPERATOR MUST SET UP LOCATION 174 WITH THE SOFTWARE DISPLAY
VALUES AND LOCATION 176 WITH THE SOFTWARE SWITCH VALUES.

SWITCH

15 SET	HALT AFTER ERROR PRINTOUT (OPTIONAL IN STATIC TEST ONLY)
15 RESET	CONTINUE AFTER ERROR PRINTOUT
14 SET	132 COL. LINE PRINTER
14 RESET	80 COL. LINE PRINTER
13 SET	96 CHARACTER LINE PRINTER
13 RESET	64 CHARACTER LINE PRINTER
12 SET	LOOP ON ROUTINE
12 RESET	CONTINUE TO THE NEXT

152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205

5.2 ADDRESS ENTHY POINTS

600 CONTROL TEST (TEST 1, SECTION 1)
610 TEST DATA PATHS (TEST 1, SECTION 2)
614 TEST CHARACTER GENERATOR (TEST 1, SECTION 3)
620 TEST ZONE AND FORMAT CONTROL (TEST 1, SECTION 4)
624 TEST WORST CASE NOISE
630 ROTATING PATTERN
634 DOUBLE WEDGE PATTERN
640 HAMMER ALIGNMENT TEST
644 SLEW TEST
650 SCOPE LOOP TEST

6. ERRORS

6.1 COMPUTER DETECTED ERRORS

THE FOLLOWING DISCUSSION DESCRIBES IN GENERAL THE METHOD USED FOR INTERNAL ERROR DETECTION AND ERROR DISPLAY BY THE LINE PRINTER DIAGNOSTIC TEST PROGRAM. MONITORING OF THE CURRENT CONDITION OF THE READY LINE (BIT 7 OF LPS) AND THE ERROR FLAG FLIP-FLOP (BIT 15 OF LPS) AFTER EACH OPERATION AS WELL AS TIME TIME OUT OF THE PRINT CYCLE (PRT TIM), LINE FEED (LF TIME), AND FORM FEED (PF TIM), CYCLES IS CARRIES ON CONTINUOUSLY DURING ALL TESTS WHERE APPROPRIATE AND IS DESCRIBED IN THE FOLLOWING PARAGRAPHS. HOWEVER, ADDITIONAL TESTING IS PERFORMED ESPECIALLY DURING EXECUTION OF THE FIRST SEGMENT OF TEST 1. FOR A COMPLETE DESCRIPTION OF THESE TESTING PROCEDURES USED IN TEST 1 AND THE CORRESPONDING ERROR CONDITIONS, THE READER IS REFERRED TO THE DESCRIPTION OF THE TEST AND THE TEST LISTING.

6.2 ERROR REPORTS

XXX ERROR COUNT
/
EQUALS THE ERROR TAG IN THE ASSEMBLY LISTING.
CONSULT THE ASSEMBLY FOR A DEFINITION OF THE ERROR.

6.3 VISUALLY DETECTED ERRORS

SINCE THE COMPUTER CAN ONLY DETECT THE CURRENT CONDITION OF THE READY AND DEMAND RETURN LINES AND DOES NOT RECEIVE ANY ADDITIONAL DATA BACK FROM THE LINE PRINTER, IT IS NECESSARY TO EXAMINE THE PRINT PATTERNS PRODUCED BY THE VARIOUS TEST ROUTINES OR RESORT TO MANUAL SCOPING PROCEDURES AS PROVIDED BY TEST 7 TO DETECT AND DIAGNOSE ADDITIONAL DIFFICULTIES.

MAIN, MACY11 27(657) 17-SEP-75 12154 PAGE 5
DZLPAB.SRC

286
287

DETAILED DESCRIPTIONS OF EACH TEST PATTERN APPEARS IN THE
DESCRIPTION OF THE CORRESPONDING TEST ROUTINES.

200
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259

7. PROGRAM DESCRIPTION

7.1 GENERAL

7.2 TEST DESCRIPTIONS

7.2.1 TEST 1 COMPREHENSIVE DATA TRANSFER AND CONTROL TEST

TEST 1 IS MADE UP OF SEVERAL SECTIONS LINKED TOGETHER AND EXECUTED AS A SINGLE TEST.

7.2.1.1 TEST 1, SECTION 1 COMMAND DECODE AND CONTROL INTERFACE TEST

THIS PORTION OF TEST 1 IS DESIGNED AS A COMMAND DECODE AND CONTROL INTERFACE TEST AND INCLUDES CHECKOUT OF THE PRINTER INTERRUPT FACILITY. UPON INITIAL ENTRY INTO THIS ROUTINE, MANUAL INTERVENTION IS REQUIRED TO TEST THE VARIOUS TESTABLE ERROR (NON-READY) CONDITIONS OF THE PRINTER. THE OPERATING SEQUENCE IS DESCRIBED IN DETAIL BELOW. AFTER INITIAL ENTRY, THE MANUAL INTERVENTION PART OF THIS TEST WILL NOT BE ENTERED AGAIN.

THE PRINTER ERROR LINE CONTINUOUSLY MONITORS THE FOLLOWING CONDITIONS WITHIN THE PRINTER AND ITS TRUE STATE AT THE CONTROL ELECTRONICS INTERFACE IS CONDITIONAL UPON NONE OF THEM EXISTING.

- A. PAPER OUT OR TORN.
- B. DRUM GATE OPEN.
- C. PAPER FEED MOTOR OVER-TEMPERATURE.
- D. POWER SUPPLY FAULT.
- E. DRUM NOT UP TO SPEED.

THE MANUAL-INTERACTIVE TEST SEQUENCE WHICH FOLLOWS IS DESIGNED TO TEST THE PROPER OPERATION OF THE READY LINE AS IT APPEARS AT THE INTERFACE ELECTRONICS WITH RESPECT TO THOSE OF THE ABOVE ITEMS WHICH ARE TESTABLE (I.E., (A.), (B.) AND (C.)).

INITIAL MANUAL TEST SEQUENCE:

1. AFTER "POWER-UP" HAS BEEN TYPED ON THE TELEPRINTER, BRING POWER-UP ON THE LINE PRINTER, MAKING SURE THAT THE PAPER IS IN PLACE IN THE TRACTORS AND THAT THE DRUM GATE IS CLOSED.

260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301

7.2.1.2 TEST 1, SECTION 2 DATA TRANSFER PATHS TEST

THIS PORTION OF TEST 1 IS DESIGNED TO TEST THE DATA TRANSFER PATHS FROM THE PROCESSOR INTERFACE, THRU THE LINE PRINTER INPUT REGISTER AND INTO THE PRINTER'S 8 X 20 BUFFER MEMORY. SINCE PRINTING WILL ALSO TAKE PLACE, THIS TEST PROVIDES A PRELIMINARY TEST OF THAT FUNCTION AS WELL. AN ALTERNATING STRING OF "0" AND "1" CHARACTERS IS TRANSMITTED TO THE PRINTER ON A FULL 80 COLUMN BASIS. SINCE THESE CHARACTERS ARE COMPLIMENTARY BITWISE, THEY PROVIDE BOTH A ONES AND ZEROS CHECK OF ALL TRANSMISSION LINES. AUTOMATIC PRINTING TAKES PLACE AFTER EACH 20 CHARACTERS IS RECEIVED BY THE PRINTER PROVIDING A CHECK ON ZONE ADVANCE AND HAMMER DRIVER SWITCHING. END OF LINE IS SENSED WITH THE PROCESSOR AND A "LINE FEED" CHARACTER TRANSMITTED AFTER COMPLETION OF THE LAST PRINT CYCLE FOR EACH LINE. PRINTING OF THE TEST LINE IS REPEATED TEN (10) TIMES ALTERNATING THE COLUMN POSITIONS OF THE "0" AND "1" CHARACTERS. COMPLETION OF THIS SECTION OF TEST 1 INITIATES SECTION 3 OF TEST 1 DIRECTLY.

7.2.1.3 TEST 1, SECTION 3 CHARACTER GENERATOR AND COMPARATOR TEST

SECTION 3 OF TEST 1 IS DESIGNED PRIMARILY TO TEST THE LINE PRINTER CHARACTER GENERATOR AND COMPARATOR LOGIC AND ITS ABILITY TO DETECT AND ACT ON BOTH PRINTABLE AND ILLEGAL CHARACTERS. A SERIES OF ALL 64 (OR 96) PRINTABLE CHARACTERS ARE TRANSMITTED IN SEQUENCE TO THE LINE PRINTER AND PRINTED ON A SINGLE LINE BEGINNING WITH THE SPACE CHARACTER (SEE TABLES II AND III FOR THE CHARACTER SEQUENCE).

THIS IS FOLLOWED BY AN ALTERNATE LINE OF ALL 64 ILLEGAL CHARACTERS EACH OF WHICH SHOULD BE CONVERTED TO A SPACE CHARACTER PRODUCING NO VISIBLE PRINTING. THIS SEQUENCE OF ALTERNATING ALL PRINTABLE CHARACTERS FOLLOWED BY ALL ILLEGAL CHARACTERS (NON-PRINTING CHARACTER) IS REPEATED 10 TIMES PRODUCING 20 LINES OF PRINT. COMPLETION OF THIS TEST INITIATES SECTION 4 OF TEST 1 DIRECTLY.

302
 303
 304
 305
 306
 307
 308
 309
 310
 311
 312
 313
 314
 315
 316
 317
 318
 319
 320
 321
 322
 323
 324
 325
 326
 327
 328
 329
 330
 331
 332
 333
 334
 335
 336
 337
 338
 339
 340
 341
 342
 343
 344
 345
 346
 347
 348
 349
 350
 351
 352
 353
 354

TABLE II

CHARACTER SEQUENCE AND ASCII CODES
 FOR STANDARD 64-CHARACTER DRUM

ROWS 1-16 -----	ROWS 17-32 -----	ROWS 33-48 -----	ROWS 49-64 -----
SPACE (40)	0 (60)	0 (100)	P (120)
! (41)	1 (61)	A (101)	Q (121)
" (42)	2 (62)	B (102)	R (122)
# (43)	3 (63)	C (103)	S (123)
\$ (44)	4 (64)	D (104)	T (124)
% (45)	5 (65)	E (105)	U (125)
& (46)	6 (66)	F (106)	V (126)
' (47)	7 (67)	G (107)	W (127)
((50)	8 (70)	H (110)	X (130)
) (51)	9 (71)	I (111)	Y (131)
* (52)	! (72)	J (112)	Z (132)
+ (53)	! (73)	K (113)	[(133)
, (54)	! (74)	L (114)	(134)
- (55)	! (75)	M (114)] (135)
. (56)	> (76)	N (116)	(136)
/ (57)	? (77)	O (117)	(137)

TABLE III

CHARACTER SEQUENCE AND ASCII CODES FOR
 OPTIONAL 96-CHARACTER DRUM

ROWS 1-16 -----	ROWS 17-32 -----	ROWS 33-48 -----	ROWS 49-64 -----	ROWS 65-80 -----	ROWS 81-96 -----
SPACE (40)	0 (60)	0 (100)	P (120)	(140)	P (160)
! (41)	1 (61)	A (101)	Q (121)	A (141)	Q (161)
" (42)	2 (62)	B (102)	R (122)	B (142)	R (162)
# (43)	3 (63)	C (103)	S (123)	C (143)	S (163)
\$ (44)	4 (64)	D (104)	T (124)	D (144)	T (164)
% (45)	5 (65)	E (105)	U (125)	E (145)	U (165)
& (46)	6 (66)	F (106)	V (126)	F (146)	V (166)
' (47)	7 (67)	G (107)	W (127)	G (147)	W (167)
((50)	8 (70)	H (110)	X (130)	H (150)	X (170)
) (51)	9 (71)	I (111)	Y (131)	I (151)	Y (171)
* (52)	! (72)	J (112)	Z (132)	J (152)	Z (172)
+ (53)	! (73)	K (113)	[(133)	K (153)	(173)
, (54)	! (74)	L (114)	(134)	L (154)	(174)
- (55)	! (75)	M (115)] (135)	M (155)	(175)
. (56)	> (76)	N (116)	(136)	N (156)	(176)
/ (57)	? (77)	O (117)	(137)	O (157)	(177)

H/

355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404

7.2.1.4 TEST 1, SECTION 4 FORMAT CONTROL CHARACTER TEST

SECTION 4 OF TEST 1 IS DESIGNED TO TEST THE ABILITY OF THE LINE PRINTER TO DETECT AND ACT UPON EACH OF THE FORMAT CONTROL CHARACTERS, "CR", "LF", AND "FF". THE TEST IS PERFORMED BY FIRST TRANSMITTING 20 SPACE CHARACTERS (ONE FULL SEGMENT) FOLLOWED BY A "CR" CHARACTER. THIS SEQUENCE WILL CAUSE THE FIRST SEGMENT OF THE PRINTER TO BE LOADED AND PRINTED AFTER WHICH THE PRINTER'S ZONE COUNTER WILL BE RESET TO COLUMN 1. PAPER FEED SHOULD NOT TAKE PLACE DURING THIS CYCLE. THE PRECEDING STRING IS THEN FOLLOWED BY 20 "A" CHARACTERS, A "CR" AND FINALLY A "FF" CHARACTER. THIS SHOULD AGAIN CAUSE PRINTING AND RETURN OF THE ZONE COUNTER TO COLUMN 1 OVER-PRINTING THE "A"'S ON THE PREVIOUSLY PRINTED SPACES. THIS SEQUENCE OF FIRST PRINTING SPACES AND THEN OVER-PRINTING "A"'S IS CONTINUED 4 MORE TIMES, EACH TIME INCREASING THE LINE LENGTH BY AN ADDITIONAL 20 "SPACE" AND "A" CHARACTERS UNTIL ALL 4 SEGMENTS OF THE 80 COLUMN PRINT LINE HAVE BEEN COVERED. THE WHOLE TEST SEQUENCE IS REPEATED 10 TIMES PRODUCING A SERIES OF 10 LEFT TRIANGLES EXTENDING DOWN THE PAPER APPARENTLY MADE UP OF THE LETTER "A". THE FINAL CHARACTER TRANSMITTED IN THIS TEST TO THE LINE PRINTER IS THE FORM FEED (FF) CHARACTER WHICH SHOULD PRODUCE A BLEW TO TOP OF PAGE TERMINATING TEST 1.

7.2.2 TEST 2 SINGLE CHARACTER, ALL COLUMNS TEST

THIS TEST IS DESIGNED AS A WORST CASE HAMMER DRIVER AND SUPPLY TEST AS WELL AS A PRINTER ENDURANCE TEST. 80 COLUMNS OF EACH OF THE 64 PRINTABLE CHARACTERS IS TRANSMITTED TO THE LINE PRINTER AND PRINTED IN ROTATION. THE COMPLETE CHARACTER SEQUENCE IS AS SHOWN IN TABLE II AND A SAMPLE OF THE PRINTOUT SHOWN BELOW.

```

- - - - -
1111 - - - - -111
-- - - - -
-- - - - -
-- - - - -
AAAA - - - - -AAA
BBBB - - - - -BBB
-- - - - -
-- - - - -
-- - - - -
- - - - -

```

405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457

7.2.3 TEST 3 ROTATING PATTERN TEST

THIS TEST IS DESIGNED AS A WORST CASE NOISE AND ENDURANCE TEST OF THE LINE PRINTER. A ROTATING, 88 COLUMN PATTERN FOLLOWING THE CHARACTER SEQUENCE SHOWN IN TABLE II IS TRANSMITTED TO THE LINE PRINTER AND PRINTED. A SAMPLE OF THE PRINT PATTERN IS SHOWN BELOW:

1"08- - - - -ABC- - - - -)
1"09- - - - -ABC- - - - -)

7.2.4 TEST 4 RIGHT AND LEFT HAND WEDGE PATTERN TEST

THIS TEST IS DESIGNED TO DETECT SPURIOUS HAMMER FIRINGS DURING OPERATION OF THE LINE PRINTER. THE PATTERNS WHICH ARE PRODUCED ARE RIGHT AND LEFT HAND WEDGES EACH COMPOSED OF 88 LINES OF "9" CHARACTERS AS SHOWN BELOW:

	----	----
	LEFT-HAND	
	CYCLE (88 LINES)	
PRINTED		
AREA	----	FULL CYCLE
"9" CHAR.		(160 LINES)
	RIGHT-HAND	
	CYCLE (88 LINES)	
	----	----

A FULL CYCLE CONSISTS OF BOTH THE RIGHT AND LEFT HAND WEDGES. THE LEFT HAND WEDGE IS FORMED SIMPLY BY TRANSMITTING AND PRINTING DECREASING NUMBERS OF CHARACTERS TO THE PRINTER ON SUCCESSIVE LINES UNTIL THE NUMBER OF CHARACTERS TO BE TRANSMITTED BECOMES ZERO. EACH LINE IS TERMINATED BY A "LF" CHARACTER CAUSING PAPER FEED TO OCCUR. THE RIGHT HAND WEDGE HOWEVER, REQUIRES THAT INCREASING NUMBERS OF LEADING SPACES BE TRANSMITTED FOLLOWED BY "9" CHARACTERS TO FILL OUT THE LINE. AGAIN, EACH LINE IS TERMINATED WITH A "LF" CHARACTER.

7.2.5 TEST 5 HAMMER ALIGNMENT TEST

THIS ROUTINE IS DESIGNED TO BE USED AS A DRIVER FOR MANUAL HAMMER ALIGNMENT AND INTENSITY ADJUSTMENTS OF THE LINE PRINTER. NO INTERNAL ERROR TESTS ARE MADE DURING THE EXECUTION OF THIS ROUTINE. IN OPERATION, THIS TEST PRINTS A FULL 88 COLUMN LINES OF "E" CHARACTERS. MORE DETAIL CONCERNING THE OPERATION OF THE ROUTINE MAY BE OBTAINED FROM THE PROGRAM LISTINGS.

458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510

7.2.6 TEST 6 SLEW TEST

THE PURPOSE OF THIS TEST IS TO INSURE THAT THE PAPER FEED DRIVE AND CLUTCH ARE OPERATING PROPERLY AND THAT THE FUNCTION OF MULTIPLE LINE SLEWS CAN BE PERFORMED CORRECTLY. IN THE LATTER CASE, THE DEMAND LINE FROM THE LINE PRINTER GOES HIGH BEFORE THE ACTUAL END OF THE PREVIOUS LINE FEED OPERATION HAS BEEN COMPLETED. IF A SECOND LINE FEED APPEARS AS THE FIRST CHARACTER TRANSMITTED FOR THE NEW LINE, SLEWING WILL CONTINUE TO THE NEXT LINE WITHOUT A STOP IN BETWEEN. THIS MODE OF OPERATION WILL IN FACT CONTINUE AS LONG AS LINE FEEDS ARE TRANSMITTED AS THE FIRST CHARACTER AND BEFORE THE END OF SLEW HAS OCCURRED FOR THE CURRENT LINE. THE TEST CONSISTS OF A ROUTINE TO PRINT A LINE OF E'S FOLLOWED BY MULTIPLE LINE SLEWS AS DETERMINED BY A LINE SLEW TABLE. THE ENTRIES IN THE TABLE ARE AS FOLLOWS:

LINE NO.	NO. OF LINES SLEWED AFTER PRINTING
-----	-----
1	3
2	2
3	18
4	14
5	6
6	3
7	8
8	4
9	5
10	5
11	3

THE TOTAL NUMBER OF LINES SLEWED AND PRINTED IS 63 OR ONE FULL PAGE. CAREFUL EXAMINATION OF THE PRINTED LINES SHOULD DETERMINE IF ANY CLUTCH SLIPPAGE IS TAKING PLACE.

NO INTERNAL ERRORS ARE DETECTED DURING THIS TEST AND THE READER IS REFERRED TO THE PROGRAM LISTING FOR FURTHER DETAILS ON THE OPERATION OF THE ROUTINE.

7.2.7 TEST 7 SCOPE DRIVE ROUTINE

THE PURPOSE OF THIS TEST SEQUENCE IS TO PROVIDE THE OPERATOR WITH A SHORT BUT COMPREHENSIVE SCOPE DRIVER ROUTINE FOR USE IN TROUBLE SHOOTING THE PRINTER INTERFACE CONTROL MODULE WITH THE SCOPE.

.ENDR

```

511      )
512      )*****LP11 PRINTER TEST*****
513      )
514      )
515      )
516      )
517      )
518      )DATA PRODUCTS 2310 LINE PRINTER
519      )
520      )LIST OF SWITCH SETTINGS USED IN THIS TEST
521      )SWITCH NO.      DESCRIPTION
522      )15              SET HALT AFTER ERROR PRINT OUT (OPTIONAL IN STATIC TEST ONLY).
523      )14              SET - 132 COL. PRINTER.
524      )13              "DOWN" 64 CHAR./"UP"-96 CHAR OPTION
525      )12              LOOP ON TEST
526      )
527      )
528      )
529      )ENABL  ABS
530      )ENABL  AMA
531      )
532      )
533      )
534      )
535      )
536      000007      PC=X7
537      000006      SP=X6
538      )
539      100000      BIT15=100000
540      040000      BIT14=400000
541      020000      BIT13=200000
542      010000      BIT12=100000
543      004000      BIT11=400000
544      002000      BIT10=200000
545      001000      BIT9=100000
546      000400      BIT8=400000
547      000200      BIT7=200000
548      000100      BIT6=100000
549      000040      BIT5=400000
550      000020      BIT4=200000
551      000010      BIT3=100000
552      000004      BIT2=400000
553      000002      BIT1=200000
554      000001      BIT0=100000
555      )
556      )
557      )
558      )
559      000000      )=0
560      )
561      )THE FIRST 100 LOCATIONS WILL HAVE
562      )      +2
563      )      HALT
564      )AS TRAP CATCHERS

```

```

565
566
567 000030 000030      .=30
568 000032 000746      TYP
569      000042 000340      340
570 000042 000000      .=42
571      000046 000046      0
572 000046 000424      .=46
573      000052 000052      LOGICAL
574 000052 040000      .=52
575      000174 000174      BIT14
576      000174 000000      .=174
577 000174 000000      DISPREG: 0
578 000176 000000      SHREG: 0
579
580      000200 000200      .=200
581 000200 012706 001000      MOV      #1000,X6
582 000204 000137 001056      JMP      SETUP
583      000600 000600      .=600
584 000600 012706 001000      MOV      #1000,X6
585 000604 000137 002074      JMP      TEST2A
586 000610 000137 002422      JMP      TEST2B
587 000614 000137 003240      JMP      TEST3
588 000620 000137 003732      JMP      SNGCHR
589 000624 000137 004304      JMP      ROTATE
590 000630 000137 005052      JMP      TST6
591 000634 000137 006110      JMP      HAMALN
592 000640 000137 006254      JMP      SLWTST
593 000644 000137 007514      JMP      SCOPE
594 000650 000137 001316      JMP      TEST1
595      001000 001000      .=1000
596
597      ;LINE PRINTER HARDWARE REGISTERS
598
599 001000 177514      LPB:      177514      ;STATUS REGISTER
600
601
602
603 001002 177516      LPB:      177516      ;BIT 15=ERROR
604
605
606
607
608 001004 177570      SHR:      177570      ;BIT 7=READY
609 001006 177570      DISPLAY:177570      ;BIT 6=INTERRUPT ENABLE
610 001010 177776      PS:       177776      ;DATA BUFFER REGISTER
611 001012 177566      TPB:      177566      ;BITS 0-6=7 BIT ASCII CHARACTER BUFFER
612 001014 177562      TKB:      177562      ;BITS 7-15=NOT USED
613 001016 177564      TPB:      177564
614 001020 177560      TKB:      177560
615
616      000240      NOP=240
617      000000      N=0
618

```

YM(

```

619                                     |
620                                     |MACRO FOR SETTING UP ERROR COUNT
621 .MACR  ERROR X
622 ERR'X': MOV BX, ERCOUNT           |SET UP ERROR COUNT X
623     NON+1
624     .ENDM
625 |
626 |
627 |
628 |MEMORY LOCATIONS USED AS PROGRAM FLAGS AND COUNTERS
629 |
630 SEGCNT: 0                          |SEGMENT COUNTER
631 CHRCNT: 0
632 CHRCNT: 0
633 LINCNT: 0
634 CYCCNT: 0
635 ERNOI: 0
636 TSTNO: 0
637 LOCAL: 0
638 TSTSW: 0
639 WORKI: 0
640 SAVEI: 0
641 ERCOUNT: 0
642 WIDTHI: 0
643 SEGMNT: 0
644 |
645 |ROUTINE TO TEST THE MECH. OPERATION OF THE 1310
646 |
647 |
648 SETUP:  RESET
649     MOV     4,-(SP)                |SAVE CURRENT VECTORS
650     MOV     6,-(SP)                |
651     MOV     @18,4                  |SET UP TIMEOUT VECTOR
652     TST     @SWR                   |TRY TO REFERENCE HARDWARE SWR
653     BR      ZS                     |BRANCH IF NO TIMEOUT TRAP OCCURS
654
655     19:  MOV     @SWREG,SWR          |POINT TO SOFTWARE SWITCH REG
656     MOV     @DISPREG,DISPLAY       |POINT TO DISPLAY REGISTER
657     CMP     (SP)+,(SP)+           |RESTORE STACK
658
659     29:  MOV     (SP)+,4             |RESTORE TIMEOUT VECTORS
660     MOV     (SP)+,6               |
661     EMT     +0
662     MES1
663     EMT     +0
664     MES2
665     EMT     +0                   |TYPE "POWER-UP"
666     MES3
667     HALT
668     STP1:  TST     @LPS             |TEST FOR ERROR
669     BPL     STP2                   |NO ERROR TEST FOR READY
670     ERROR  \N                      |REPORT ERROR
671     MOV     @0,ERCOUNT            |SET UP ERROR COUNT 0
672     NON+1
  
```

AZ

```

673 001164 004537 007152 JSR XS,STAER ;REPORT ERROR BIT SET
674 001170 000767 BR STP1 ;GO TEST FOR ERROR NOT
675
676 001172 105777 177602 STP2: TSTB 0LPS ;TEST FOR READY
677 001176 100406 BMI STP3 ;READY SET OK
678 001209 ERROR \N ;REPORT READY NOT SET
679 001200 012737 000001 001050 ERR1: MOV #1, ERCCOUNT ;SET UP ERROR COUNT 1
680 000002 N=N+1
681 001206 004537 007152 JSR XS,STAER ;REPORT READY NOT SET
682 001212 000767 BR STP2 ;GO TEST FOR READY
683 001214 104000 STP3: EMT +0 ;REPORT
684 001216 007352 MES4 ;PRINTER OK "READY SET" TRY TORN PAPER SWITCH
685 001220 000000 HALT ;DEPRESS CONTINUE WHEN READY
686 001222 STP4:
687 001222 012777 000014 177552 MOV #14,0LPB ;SEND A "FF" TO THE PRINTER
688 001230 012777 000015 177544 MOV #15,0LPB ;ATTEMPT "FF" BY SENDING "CR"
689 001236 005777 177536 TST 0LPS ;TEST FOR ERROR
690 001242 100406 BMI STP5
691 001244 ERROR \N ;REPORT ERROR NOT SET
692 001244 012737 000002 001050 ERR2: MOV #2, ERCCOUNT ;SET UP ERROR COUNT 2
693 000003 N=N+1
694 001252 004537 007152 JSR XS,STAER ;REPORT ERROR
695 001256 000761 BR STP4 ;LOOP ON ERROR
696 001260 104000 STP5: EMT +0
697 001262 007414 MES5 ;
698 001264 000000 HALT ;DEPRESS CONTINUE WHEN READY
699 001266 005777 177506 STP6: TST 0LPS
700 001272 100406 BMI STP7
701 001274 ERROR \N
702 001274 012737 000003 001050 ERR3: MOV #3, ERCCOUNT ;SET UP ERROR COUNT 3
703 000004 N=N+1
704 001302 004537 007152 JSR XS,STAER
705 001306 000767 BR STP6
706 001310 104000 STP7: EMT +0
707 001312 007457 MES6
708 001314 000000 HALT
709
710 ;
711 ;TEST 1, SECTION 1
712 ;PERFORMS PRELIMINARY COMMAND AND REGISTER TESTING.
713 ;
714 ;
715 ;IS THE PRINTER FREE OF ERRORS
716 001316 000005 TEST1: RESET ;CLEAR THE WORLD
717 001320 005777 177454 TST 0LPS ;IS ERROR FLAG CLEAR
718 001324 100006 BPL TEST1A ;ERROR IS CLEAR OK
719 001326 ERROR \N
720 001326 012737 000004 001050 ERR4: MOV #4, ERCCOUNT ;SET UP ERROR COUNT 4
721 000005 N=N+1
722 001334 004537 007152 JSR XS,STAER ;REPORT ERROR SET
723 001340 000766 BR TEST1 ;LOOP ON ERROR
724 ;
725 ;IS READY SET (NO ERRORS EXIST)
726 001342 000005 TEST1A: RESET ;CLEAR THE WORLD

```

B2

```

727 001344 105777 177430          TSTB  @LPS          JIS READY SET
728 001350 100406          BMI   TEST10       JREADY SET; PRINTER OK
729 001352          ERROR  \N          JREPORT READY NOT SET
730 001352 012737 000007 001050 ERR5:  MOV #5, ERCOUNT  JSET UP ERROR COUNT 5
731          000006          N=N+1
732 001360 004537 007152          JSR   X5,STAER     JREPORT READY NOT SET
733 001364 000766          BR    TEST1A       JLOOP ON ERROR
734
735          JDOES LOADING THE BUFFER RESET READY
736
737 001366 032777 040000 177410 TEST10: BIT  @BIT14,@SWR  JIS THE PRINTER 132 COL
738 001374 001043          BNE  TESTIC        JYES SKIP THIS TEST
739 001376 005037 001044          CLR  WORK          JCLEAR COUNTER
740 001402 012777 000015 177372  MOV  @15,@LPB      JLOAD CARRIAGE RETURN INTO BUFFER
741 001410 105777 177364          TSTB @LPS          JIS READY CLEAR
742 001414 100006          BPL  LP1           JREADY IO CLEAR OK;
743 001416          ERROR  \N          JREPORT READY STILL SET
744 001416 012737 000006 001050 ERR6:  MOV #6, ERCOUNT  JSET UP ERROR COUNT 6
745          000007          N=N+1
746 001424 004537 007152          JSR   X5,STAER     JREPORT READY STILL SET
747 001430 000756          BR    TEST10       JLOOP ON ERROR
748 001432 005777 177342  LP1:  TST  @LPS        JIS THERE AN ERROR
749 001436 100006          BPL  LP2           JNO ERROR CONTINUE
750 001440          ERROR  \N
751 001440 012737 000007 001050 ERR7:  MOV #7, ERCOUNT  JSET UP ERROR COUNT 7
752          000010          N=N+1
753 001446 004537 007152          JSR   X5,STAER     JREPORT ERROR OCCURRED
754 001452 000745          BR    TEST10       JLOOP ON ERROR
755
756 001454 105777 177320  LP2:  TSTB @LPS          JIS THE PRINTER STILL BUSY
757 001460 100411          BMI  TESTIC        JNO! GO TO NEXT TEST
758 001462 005237 001044          INC  WORK          JYES! GO CHECK FLAGS
759 001466 001361          BNE  LP1           JPRINTER STILL BUSY WAIT
760 001470          ERROR  \N
761 001470 012737 000010 001050 ERR10: MOV #10, ERCOUNT  JSET UP ERROR COUNT 10
762          000011          N=N+1
763 001476 004537 007152          JSR   X5,STAER     JERROR REPORT TIME OUT
764 001502 000731          BR    TEST10       JLOOP ON ERROR
765
766          JCHECK INTERRUPT LEVEL OF PRINTER
767          JTHE PRINTER SHOULD BE AT LEVEL 4
768
769          JTEST THAT THE PRINTER WILL NOT INTERRUPT AT LEVEL 7
770 001504 012737 001740 000200 TESTIC: MOV  @INTIC,200  JSET UP INT VECTOR
771 001512 012737 000340 000202          MOV  @340,202
772 001520 005777 177254          TST  @LPS          JTEST FOR ERROR
773 001524 100006          BPL  LP3           JNO ERROR CONTINUE
774 001526          ERROR  \N          JREPORT ERROR SET
775 001526 012737 000011 001050 ERR11: MOV #11, ERCOUNT  JSET UP ERROR COUNT 11
776          000012          N=N+1
777 001534 004537 007152          JSR   X5,STAER     JREPORT ERROR SET
778 001540 000761          BR    TESTIC        JLOOP ON ERROR
779 001542 105777 177232  LP3:  TSTB @LPS        JTEST FOR READY
780 001546 100406          BMI  LP3X          JREADY SET OK

```



```

781 001550          ERROR  \N          IREPORT READY NOT SET
782 001550 012737 000F12 001050 ERR12: MOV #12,          ERCOUNT          ISET UP ERROR COUNT 12
783          000013          N=N+1
784 001556 004537 007152          JSR  X5,STAER          IREPORT READY NOT SET
785 001562 000750          BR  TESTIC          ILOOP ON ERROR
786 001564          LP3X1  ERROR  \N
787 001564 012737 000013 001050 ERR13: MOV #13,          ERCOUNT          ISET UP ERROR COUNT 13
788          000014          N=N+1
789 001572 012777 000340 177210          MOV  #340,0PS          ILOCKUP PROCESSOR
790 001600 052777 000100 177172          BIS  #100,0LPS          ISET PRINTER INTO ENABLE
791 001606 000240          NOP
792 001610 042777 000100 177162          BIC  #100,0LPS          ICLEAR PRINTER INT. ENABLE
793
794          ITEST THAT THE PRINTER WILL NOT INTERRUPT AT LEVEL 6
795 001616          ERROR  \N
796 001616 012737 000014 001050 ERR14: MOV #14,          ERCOUNT          ISET UP ERROR COUNT 14
797          000015          N=N+1
798 001624 012777 000300 177156          MOV  #300,0PS          ISET PROCESSOR PRIORITY LEVEL 6
799 001632 052777 000100 177140          BIS  #100,0LPS          ISET PRINTER INT ENABLE
800 001640 000240          NOP
801 001642 042777 000100 177130          BIC  #100,0LPS          ICLEAR PRINTER INT. ENABLE
802
803          ITEST THAT THE PRINTER WILL NOT INT. AT
804          IPROCESSOR LEVEL 5
805
806 001650          ERROR  \N
807 001650 012737 000015 001050 ERR15: MOV #15,          ERCOUNT          ISET UP ERROR COUNT 15
808          000016          N=N+1
809 001656 012777 000240 177124          MOV  #240,0PS          ISET UP PROCESSOR TO LEVEL 5
810 001664 052777 000100 177106          BIS  #100,0LPS          ISET PRINTER INT ENABLE
811 001672 000240          NOP
812 001674 042777 000100 177076          BIC  #100,0LPS          ICLEAR INT ENABLE PRINTER OK
813
814          I
815          ITEST THAT THE PRINTER WILL NOT INT
816          IWHEN THE PROCESSOR IS AT LEVEL 4
817
818 001702          ERROR  \N
819 001702 012737 000016 001050 ERR16: MOV #16,          ERCOUNT          ISET UP ERROR COUNT 16
820          000017          N=N+1
821 001710 012777 000200 177072          MOV  #200,0PS          ISET PROCESSOR TO LEVEL 4
822 001716 052777 000100 177054          BIS  #100,0LPS          ISET PRINTER INT. ENABLE
823 001724 000240          NOP
824 001726 042777 000100 177044          BIC  #100,0LPS          ICLEAR PRINTER INT ENABLE
825 001734 000137 001752          JMP  TEST1D          IPRINTER OK CONTINUE
826
827          I
828          I
829          IINTERRUPT HANDLE FOR TESTIC
830          IRESTORE STACK AND REPORT ERROR
831
832 001740 022626          INT1C: CMP  (6)+,(6)+          IRESTORE STACK
833 001742 004537 007152          JSR  X5,STAER          IREPORT ERROR
834 001746 000137 001504          JMP  TESTIC          IRE-ENTER TESTIC

```

D2

```

035
036
037
038
039
040
041
042 001752 012737 002064 000200 TEST10: MOV #INT10,200 ;SET UP INTERRUPT VECTOR
043 001760 012737 000340 000202 MOV #340,202 ;LOCK UP PRIORITIES
044 001766 005777 177006 TST #LPS ;IS THERE A PRINTER ERROR
045 001772 100006 BPL LPA ;NO! CONTINUE
046 001774 ERROR \N
047 001774 012737 000017 001050 ERR17: MOV #17, ERCOUNT ;SET UP ERROR COUNT 17
048 000020 N=N+1
049 002002 004537 007152 JSR #5,STAER ;REPORT PRINTER ERROR
050 002006 000761 BR TEST10 ;LOOP ON ERROR
051 002010 105777 176764 LP4: TSTR #LPS ;IS READY SET
052 002014 100006 BMI LPS ;YES - PRINTER READY
053 002016 ERROR \N
054 002016 012737 000020 001050 ERR20: MOV #20, ERCOUNT ;SET UP ERROR COUNT 20
055 000021 N=N+1
056 002024 004537 007152 JSR #5,STAER ;REPORT READY NOT SET
057 002030 000750 BR TEST10 ;LOOP ON ERROR
058 002032 012777 000140 176750 LP5: MOV #140,#PS ;SET PRIORITY TO LEVEL 3
059 002040 052777 000100 176732 BIS #100,#LPS ;SET PRINTER INTERRUPT ENABLE
060 002046 000240 NOP
061 002050 ERROR \N
062 002050 012737 000021 001050 ERR21: MOV #21, ERCOUNT ;SET UP ERROR COUNT 21
063 000022 N=N+1
064 002056 004537 007152 JSR #5,STAER ;REPORT ERROR
065 002062 000733 BR TEST10 ;LOOP ON ERROR
066
067 ;INTERRUPT HANDLER FOR TEST10
068
069 002064 022626 INT10: CMP (6)+,(6)+ ;RESET STACK
070 002066 042777 000100 176704 BIC #100,#LPS ;CLEAR INT, ENABLE FOR PRINTER
071 ;ENTER NEXT TEST
072
073 ;TEST1: SECTION 2
074 ;TESTS INTERFACE AND PRINTER DATA PATHS
075 ;WITH ALTERNATING ONES AND ZEROS
076
077 002074 004737 006566 TEST2A: JSR #7,SIZE
078 002100 004537 006700 JSR #5,PRINT ;INITIALIZE PRINTER
079 002104 000406 BR TST2AX
080 002106 ERROR \N
081 002106 012737 000022 001050 ERR22: MOV #22, ERCOUNT ;SET UP ERROR COUNT 22
082 000023 N=N+1
083 002114 004537 007152 JSR #5,STAER ;REPORT PRINTER NOT READY
084 002120 000000 HALT
085 002122 012737 177737 001032 TST2AX: MOV #41,CYCNT ;SET UP PASS COUNT
086 002130 013737 001052 001030 MOV WIDTH,LINCNT ;RESET ZONE COUNT
087 002136 013737 001054 001022 MOV SEGMENT,SEGCNT ;RESET SEGMENT COUNT
088 002144 013737 002416 002414 MOV #CMRSH,CHARSH ;SET CHAR, SWITCH TO #

```

```

089 002152 005777 176622      T3A:  TST      0LPB      ITEST FOR ERROR
090 002156 100006                SPL      LP2B      INO ERROR CONTINUE
091 002160                ERROR      \N          ISET UP ERROR COUNT
092 002160 012737 000023 001050 ERR23:  MOV #23,  ERCOUNT  ISET UP ERROR COUNT 23
093                000024                N=N+1
094 002166 004537 007152                JSR      X5,STAER  IREPORT ERROR SET
095 002172 000F00                HALT                    IOPERATOR MUST TAKE ACTION
096 002174 000177 000214      LP2B:  JMP      0CHARSW
097 002200 013737 002416 002414 T1A:  MOV      SCHARSW,CHARSW ISET CHAR, SWITCH TO 0
098 002206 012737 000100 001046      MOV      #100,SAVE
099 002214 013777 001046 176560 T5A:  MOV      SAVE,0LPB  ILOAD BUFFER
100 002222 005237 001022                INC      SEGCNT  IINC SEGMENT COUNT
101 002226 001401                BEQ      ,+4
102 002230 000750                BR       T3A
103 002232 013737 001054 001022      MOV      SEGMENT,SEGCNT IRESET SEGMENT COUNT
104 002240 004537 006632      JSR      X5,PRTH  ITEST CHAR, PRINT TIME
105 002244 000405                BR       LPSA
106 002246                ERROR      \N          IREPORT TOO LONG TO PRINT
107 002246 012737 000024 001050 ERR24:  MOV #24,  ERCOUNT  ISET UP ERROR COUNT 24
108                000025                N=N+1
109 002254 004537 007152      JSR      X5,STAER
110 002260 005237 001030      LPSA:  INC      LINCNT  IINC. ZONE COUNT
111 002264 001414                BEQ      XLINF
112 002266 032777 040000 176510      BIT      @BIT14,@SWR
113 002274 001726                BEQ      T3A
114 002276 022737 177777 001030      CMP      #-1,LINCNT
115 002304 001322                BNE     T3A
116 002306 012737 177764 001022      MOV      #-12,,SEGCNT
117 002314 000716                BR       T3A
118 002316 013737 001052 001030 XLINF:  MOV      WIDTH,LINCNT  IRESET ZONE COUNT
119 002324 012777 000012 176450      MOV      #12,0LPB  IISSUE LINE FEED
120 002332 004537 006642      JSR      X5,SLWTIM  ICHECK SLEW TIME
121 002336 000405                BR       LPSB
122 002340                ERROR      \N          IREPORT TOO LONG OF TIME FOR SLOW
123 002340 012737 000025 001050 ERR25:  MOV #25,  ERCOUNT  ISET UP ERROR COUNT 25
124                000026                N=N+1
125 002346 004537 007152      JSR      X5,STAER
126 002352 005237 001032      LPSB:  INC      CYCCNT  IINC CYCLE COUNT
127 002356 001401                BEQ      ,+4
128 002360 000674                BR       T3A
129 002362 032777 010000 176414      BIT      @BIT12,@SWR
130 002370 001241                BNE     TEST2A
131 002372 000413                BR       TEST2B
132
133      /
134      /
135      /
136 002374 013737 002420 002414 T2A:  MOV      RCHARSW,CHARSW IRESET CHAR, SWITCH
137 002402 012737 000077 001046      MOV      #77,SAVE
138 002410 000137 002214                JMP     T5A  ILOAD CHAR.
139
140      /
141      /
142 002414 000000                CHARSW= 0

```

```

943 002416 002374 3CHRSM: T2A
944 002420 002200 RCHRSM: T1A
945
946
947
948
949
950
951
952 002422 004737 006566 TEST20: JSR X7,SIZE
953 002426 032777 020000 176350 BIT 00IT13,PSNR ;TEST FOR 96 CHR SW.
954 002434 001412 BEQ LP2C ;NOT 96 = 64 CHARACTERS
955 002436 012737 177766 001032 MOV 0-12,CYCCNT ;SET 10 CYCLES, 30 LINES
956 002444 012737 002624 003234 MOV 0T207,NOCHRS ;SET NO. CHAR. SWITCH
957 002452 012737 177640 003236 MOV 0-96.,LEGCHR ;STORE CHAR. CNT
958 002460 000411 BR T204 ;GO PRINT
959 002462 012737 177761 001032 LP2C1: MOV 0-17,CYCCNT ;SET CYCLE FOR 30 LINES
960 002470 012737 002720 003234 MOV 0T202,NOCHRS ;RESET NO. CHAR. SW.
961 002476 012737 177700 003236 MOV 0-64.,LEGCHR ;STORE 64 CHAR. CNT
962 002504 013737 001052 001030 T2001: MOV WIDTH,LINCNT ;SET UP LINE CNT
963 002512 012737 000440 001026 MOV 040,CHRGEN ;SET FIRST CHAR.
964 002520 013737 003236 001024 MOV LEGCHR,CHRCNT ;SET CHAR: COUNT
965 002526 013737 001054 001022 MOV SEGMENT,SEGCNT ;RESET SEG. COUNT
966 002534 005777 176240 T2011: TST PLPS ;DOES THE PRINTER HAVE AN ERROR
967 002540 100006 BPL LP2E ;BRANCH IF NO ERROR
968 002542 ERROR \N
969 002542 012737 000026 001050 ERR26: MOV 026, ERRCOUNT ;SET UP ERROR COUNT 26
970 000027 NNN+1
971 002550 004537 007152 JSR X5,STAER ;REPORT ERROR
972 002554 000000 HALT ;ERROR SET OPERATOR MUST TAKE ACTION
973 002556 013777 001026 176216 LP2E1: MOV CHRGEN,PLPB ;PRINT CHARACTER
974 002564 005237 001022 INC SEGCNT ;INC. SEGMENT COUNT
975 002570 001053 ONE T202
976 002572 013737 001054 001022 MOV SEGMENT,SEGCNT
977 002600 004537 006632 JSR X5,PRTYM ;CHECK PRINT TIME
978 002604 000405 BR LP2F ;BRANCH IF NO PRINT TIME ERROR
979 002606 ERROR \N
980 002606 012737 000027 001050 ERR27: MOV 027, ERRCOUNT ;SET UP ERROR COUNT 27
981 000030 NNN+1
982 002614 004537 007152 JSR X5,STAER ;REPORT PRINT TIME ERROR
983 002620 000177 000410 LP2F1: JMP 0NOCHRS
984 002624 005237 001030 T2071: INC LINCNT
985 002630 001414 BEQ REFILE
986 002632 032777 040000 176144 BIT 00IT14,PSNR
987 002640 001427 BEQ T202
988 002642 022737 177777 001030 CMP 0-1,LINCNT
989 002650 001025 BNE T202
990 002652 012737 177764 001022 MOV 0-12.,SEGCNT
991 002660 000417 BR T202
992 002662 013737 001052 001030 REFILE: MOV WIDTH,LINCNT ;RESET LINE COUNT
993 002670 012777 000012 176104 MOV 012,PLPB ;ISSUE LINE FEED
994 002676 004537 006642 JSR X5,SLWTIM ;CHECK SLEW TIME
995 002702 000406 BR T202 ;TIME OK
996 002704 ERROR \N

```

997	002704	012737	000030	001050	ERR30:	MOV #30,	ERCOUNT	1SET UP ERROR COUNT 30
998		000031				NON+1		
999	002712	004537	007152			JSR X5,STAER		1REPORT SLEW TIME TOO LONG
1000	002716	000000				HALT		
1001	002720	005237	001026		T202:	INC CHRGEN		1SET UP NEXT CHARACTER
1002	002724	005237	001024			INC CHR CNT		1INC. CHAR. COUNT
1003	002730	001301				BNE T201		
1004	002732	012777	000012	176042		MOV #12,@LPB		1ISSUE LINE FEED
1005	002740	004537	006642			JSR X5,SLWTIM		1CHECK SLEW TIME
1006	002744	000406				BR LP2H		1SLEW TIME OK
1007	002746					ERROR \N		
1008	002746	012737	000031	001050	ERR31:	MOV #31,	ERCOUNT	1SET UP ERROR COUNT 31
1009		000032				NON+1		
1010	002754	004537	007152			JSR X5,STAER		1REPORT TIME TOO LONG
1011	002760	000000				HALT		
1012	002762	013737	001054	001022	LP2H:	MOV SEG HNT,SEG CNT		1RESET SEGMENT COUNT
1013	002770	012737	000200	001024		MOV #200,CHR CNT		
1014	002776	063737	003236	001024		ADD LEGCHR,CHR CNT		1SETUP # OF ILLEGAL CHARACTERS
1015	003004	005137	001024			COM CHR CNT		
1016	003010	005237	001024			INC CHR CNT		
1017								
1018	003014	005777	175760		T203:	TST @LPB		1TEST FOR ERROR
1019	003020	100000				RPL LOCH		1BRANCH IF NO ERROR
1020	003022					ERROR \N		
1021	003022	012737	000032	001050	ERR32:	MOV #32,	ERCOUNT	1SET UP ERROR COUNT 32
1022		000033				NON+1		
1023	003030	004537	007152			JSR X5,STAER		1REPORT ERROR SET
1024	003034	000000				HALT		
1025	003036	013777	001026	175736	LDCH:	MOV CHRGEN,@LPB		1TRANSMIT CHARACTER
1026	003044	005237	001022			INC SEG CNT		1+1 SEGMENT COUNT
1027	003050	001014				BNE T204		
1028	003052	013737	001054	001022		MOV SEG HNT,SEG CNT		1RESET SEGMENT COUNT
1029	003060	004537	006632			JSR X5,PRYTH		1CHECK PRINT TIME
1030	003064	000406				BR T204		
1031	003066					ERROR \N		
1032	003066	012737	000033	001050	ERR33:	MOV #33,	ERCOUNT	1SET UP ERROR COUNT 33
1033		000034				NON+1		
1034	003074	004537	007152			JSR X5,STAER		1PRINT TOOK TOO LONG
1035	003100	000000				HALT		
1036	003102	005237	001024		T204:	INC CHR CNT		1+1 CHARACTER COUNT
1037	003106	001422				BEO T205		
1038	003110	005237	001026			INC CHRGEN		
1039	003114	042737	177600	001026		BIC #177600,CHRGEN		
1040	003122	022737	000012	001026		CMP #12,CHRGEN		1TEST FOR LINE FEED
1041	003130	001764				BEO T204		
1042	003132	022737	000014	001026		CMP #14,CHRGEN		1TEST FOR SLEW
1043	003140	001760				BEO T204		
1044	003142	022737	000015	001026		CMP #15,CHRGEN		1TEST FOR CARRIAGE RETURN
1045	003150	001754				REQ T204		
1046	003152	000720				BR T203		1LOAD CHARACTER
1047					/			
1048					/			
1049					/			
1050	003154	012777	000012	175620	T205:	MOV #12,@LPB		1ISSUE LINE FEED

1051	003162	004537	006642		JSR	X5,8LWTIM	ICHECK SLEW TIME
1052	003166	000406			BR	LP20X	
1053	003170				ERROR	\N	
1054	003170	012737	000034	001050	ERR34:	MOV #34,	ERCOUNT
1055		000035			N#N#1		ISSET UP ERROR COUNT 34
1056	003176	004537	007152		JSR	X5,8TAER	ISLEW TIME TOO LONG
1057	003202	000000			HALT		
1058	003204	005237	001032		LP20X:	INC	CYC CNT
1059	003210	001402			BEO	,+6	
1060	003212	000137	002504		JMP	T200	
1061	003216	032777	010000	175560	BIT	#BIT12,#8WR	ICHECK 10 LOOP ON TEST
1062	003224	001402			BEO	,+6	
1063	003226	000137	002422		JMP	TEST2B	
1064	003232	000402			BR	TEST3	
1065							
1066	003234	000000			NOCHR:	0	
1067	003236	000000			LEGCHR:	0	
1068					;		
1069					;		
1070					;		
1071					;		

```

1072
1073
1074
1075
1076 003240 004737 006566
1077 003244 013737 003716 003720
1078 003252 032777 040000 175524
1079 003260 001404
1080 003262 012737 000007 003730
1081 003270 000403
1082 003272 012737 000005 003730
1083 003300 004537 006700
1084 003304 000406
1085 003306
1086 003306 012737 000035 001050
1087 000036
1088 003314 004537 007152
1089 003320 000000
1090 003322 012737 177777 003722
1091 003330 012737 003506 003724
1092 003336 012737 003422 003726
1093 003344 012737 177777 001032
1094 003352 013737 001054 001022
1095 003360 005777 175414
1096 003364 100006
1097 003366
1098 003366 012737 000036 001050
1099 000037
1100 003374 004537 007152
1101 003400 000000
1102 003402 105777 175372
1103 003406 100403
1104 003410
1105 003410 012737 000037 001050
1106 000040
1107 003416 000177 000304
1108 003422 012777 000040 175352
1109 003430 005237 001022
1110 003434 001351
1111 003436 013737 001054 001022
1112 003444 004537 006632
1113 003450 000406
1114 003452
1115 003452 012737 000040 001050
1116 000041
1117 003460 004537 007152
1118 003464 000000
1119 003466 005237 001032
1120 003472 001332
1121 003474 013737 003722 001032
1122 003502 000177 000216
1123 003506 012737 003550 003724
1124 003514 012737 003540 003726
1125 003522 012777 000015 175252

/
/TEST 1, SECTION 4
/TESTS PRINTER ZONE AND FORMAT CONTROL
/
TEST3: JSR X7,SIZE
MOV XN,T3NCNT /SET UP CYCLE COUNT
BIT 14,08NR /IS PRINTER 132 COL.
DEG Z00Z /NO IT IS AN 80 COL PRINTER
MOV 07,ZCOUNT /IT IS AN 132 COL PRINTER
OR FORMF
Z00Z: MOV 05,ZCOUNT /SET UP FOR 80 COL PRINTER
FORMF: JSR X5,PRINT /INITIALIZE PRINTER
OR T0
ERROR \N
ERR35: MOV #35, ERCOUNT /SET UP ERROR COUNT 35
N=N+1
JSR X5,STAER /PRINTER NOT READY
HALT
T0: MOV 0-1,CYCTST /
MOV 07,PHFLG /PRESET PHASE FLAG
MOV 075,SPCFLG /PRESET SPACE FLAG
MOV 0-1,CVCCNT
MOV SEGMENT,SEGCNT /SET UP SEGMENT COUNT
T1: TST 0LPB /TEST FOR ERROR
OPL XT1A /NO ERROR
ERROR \N
ERR36: MOV #36, ERCOUNT /SET UP ERROR COUNT 36
N=N+1
JSR X5,STAER
HALT
XT1A: TST 0LPB /TEST FOR READY
BNI T1X /READY SET
ERROR \N
ERR37: MOV #37, ERCOUNT /SET UP ERROR COUNT 37
N=N+1
T1X: JMP 08PCFLG
T5: MOV 040,0LPB /LOAD A SPACE
T5X: INC SEGCNT /+1 SEGMENT CNT
BNE T1 /TEST FOR END
MOV SEGMENT,SEGCNT
JSR X5,PRTH /CHECK PRINT OUT
OR INCCY /TIME OK
ERROR \N
ERR40: MOV #40, ERCOUNT /SET UP ERROR COUNT 40
N=N+1
JSR X5,STAER /IT TOOK TOO LONG TO PRINT
HALT
INCCY: INC CVCCNT
BNE T1
MOV CYCTST,CVCCNT
T8: JMP 0PHFLG
MOV 077,PHFLG /SET PHASE FLAG
MOV 074,SPCFLG /SET SPACE FLAG
MOV 015,0LPB /LOAD CARRIAGE RETURN

```

1126	003530	105777	175244		TSTB	PLPB		WAIT FOR SEGMENT DIODES
1127	003534	100375			DPL	.-4		TO SETTLE
1128	003536	000710			BR	T1		
1129								
1130								
1131	003540	012777	000101	175234	T41	MOV	0101,PLPB	LOAD CHARACTER "A"
1132	003546	000730			BR	TSX		
1133	003550	012737	003506	003724	T71	MOV	0T8,PHFLG	SET PHASE FLAG
1134	003556	012737	003422	003726		MOV	0T5,SPCFLG	SET SPACE /A FLAG
1135	003564	012777	000012	175210		MOV	012,PLPB	ISSUE LINE FEED
1136	003572	004537	006642		JBR	K5,SLWTIM		CHECK SLEN TIME
1137	003576	000405			BR	LPT7X		
1138	003600					ERROR	\N	
1139	003600	012737	000041	001050	ERR41:	MOV #41,	ERCOUNT	SET UP ERROR COUNT 41
1140		000042				N=N+1		
1141	003606	004537	007152		JBR	K5,STAER		REPORT SLEN TOOK TOO LONG
1142								
1143	003612	005337	003722		LPT7X:	DEC	CYCTST	
1144	003616	013737	003722	001032		MOV	CYCTST,CYCCNT	RESET CYCLE COUNT
1145	003624	013737	003722	001044		MOV	CYCTST,WORK	
1146	003632	063737	003730	001044		ADD	ZCOUNT,WORK	
1147	003640	001247			BNE	T1		
1148	003642	005237	003720		INC	T3CNT		TEST ALL CYCLES
1149	003646	001225			BNE	T9		
1150	003650	012777	000014	175124		MOV	014,PLPB	
1151	003656	004537	006502		JBR	K5,FRPTIM		CHECK FORM FEED
1152	003662	000406			BR	XLPX2		
1153	003664					ERROR	\N	
1154	003664	012737	000042	001050	ERR42:	MOV #42,	ERCOUNT	SET UP ERROR COUNT 42
1155		000043				N=N+1		
1156	003672	004537	007152		JBR	K5,STAER		FORM FEED TOOK TOO LONG
1157	003676	000000				HALT		
1158	003700	032777	010000	175076	XLPX2:	RIT	00IT12,08MR	CHECK TO LOOP ON TEST
1159	003706	001402			BEG	.-6		
1160	003710	000137	003240		JMP	TEST3		LOOP ON TEST
1161	003714	000406			BR	8NGCHR		
1162								
1163	003716	177764			XN1	-14		
1164	003720	000000			T3CNT:	0		
1165	003722	000000			CYCTST:	0		
1166	003724	000000			PHFLG:	0		
1167	003726	000000			SPCFLG:	0		
1168	003730	000000			ZCOUNT:	0		
1169								
1170								
1171								
1172								
1173	003732	004737	006566		8NGCHR:	JBR	K7,SIZE	
1174	003736	013737	001854	001022		MOV	SEGMENT,SEGCNT	SET UP SEGMENT COUNT
1175	003744	032777	020000	175032		BIT	00IT13,08MR	TEST FOR 96 CHAR.
1176	003752	001404			BEG	82		
1177	003754	012737	177640	001024		MOV	0-96,,CHRCNT	96 CHAR.
1178	003762	000403			BR	.-10		
1179	003764	012737	177700	001024	82:	MOV	0-64,,CHRCNT	64 CHAR.

K2

1180	003772	013737	001052	001030		MOV	WIDTH,LINCNT	ISET UP LINE COUNT
1181	004000	012737	000040	001026		MOV	040,CHRGEN	ISET UP SPACE
1182	004006	005777	174766		S11	TST	0LPB	I TEST FOR ERRORS
1183	004012	100006				BPL	0S1X	I BRANCH IF NO ERRORS
1184	004014					ERROR	\N	
1185	004014	012737	000043	001050	ERR431	MOV 043,	ERCOUNT	ISET UP ERROR COUNT 43
1186		000044				NON+1		
1187	004022	004537	007152			JSR	05,0TAER	I REPORT ERROR
1188	004026	000000				HALT		I HALT ON ERROR
1189	004030	013777	001026	174744	0S1X1	MOV	CHRGEN,0LPB	I LOAD PRINTER BUFFER
1190	004036	005237	001022			INC	SEGCNT	
1191	004042	001361				BNE	01	
1192	004044	013737	001054	001022		MOV	SEGMNT,SEGCNT	ISET UP NEW SEGMENT CNT
1193	004052	005237	001030			INC	LINCNT	I+1 LINE COUNT
1194	004056	001424				BEQ	04	IEND OF LINE
1195	004060	032777	040060	174716		BIT	0BIT14,03WR	
1196	004066	001407				BEQ	LINPT	
1197	004070	022737	177777	001030		CMF	0-1,LINCNT	
1198	004074	001003				BNE	LINPT	
1199	004100	012737	177764	001022		MOV	0-12.,SEGCNT	
1200	004106	004537	006632		LINPT1	JSR	05,PRTH	I PRINT SEGMENT
1201	004112	000735				BR	01	I FETCH NEXT SEGMENT
1202	004114					ERROR	\N	
1203	004114	012737	000044	001050	ERR441	MOV 044,	ERCOUNT	ISET UP ERROR COUNT 44
1204		000045				NON+1		
1205	004122	004537	007152			JSR	05,0TAER	I REPORT PRINT TIME TOO LONG
1206	004126	000000				HALT		
1207								
1208	004130	013737	001052	001030	041	MOV	WIDTH,LINCNT	ISET UP LINE COUNT
1209	004136	004537	006632			JSR	05,PRTH	IEND OF LINE PRINT
1210	004142	000406				BR	04X	I PRINT TIME OK
1211	004144					ERROR	\N	
1212	004144	012737	000045	001050	ERR451	MOV 045,	ERCOUNT	ISET UP ERROR COUNT 45
1213		000046				NON+1		
1214	004152	004537	007152			JSR	05,0TAER	I REPORT TOO LONG TO PRINT
1215	004156	000000				HALT		
1216	004160	005777	174614		04X1	TST	0LPB	I TEST FOR ERROR
1217	004164	100006				BPL	04X1	I BRANCH IF NO ERROR
1218	004166					ERROR	\N	
1219	004166	012737	000046	001050	ERR461	MOV 046,	ERCOUNT	ISET UP ERROR COUNT 46
1220		000047				NON+1		
1221	004174	004537	007152			JSR	05,0TAER	I REPORT ERROR SET
1222	004200	000000				HALT		
1223	004202	005777	174572		04X11	TSTB	0LPB	I TEST FOR READY
1224	004206	100406				BMI	04X2	I BRANCH IF READY SET
1225	004210					ERROR	\N	
1226	004210	012737	000047	001050	ERR471	MOV 047,	ERCOUNT	ISET UP ERROR COUNT 47
1227		000050				NON+1		
1228	004216	004537	007152			JSR	05,0TAER	I REPORT READY NOT SET
1229	004222	000000				HALT		
1230	004224	012777	000012	174550	04X21	MOV	012,0LPB	I ISSUE LINE FEED
1231	004232	004537	006642			JSR	05,SLWTIM	I CHECK SLEW TIME
1232	004236	000406				BR	07	
1233	004240					ERROR	\N	

```

1234 004240 012737 000050 001050 ERR50: MOV 050,          ERCOUNT      ISET UP ERROR COUNT 50
1235                000051                N=N+1
1236 004246 004537 007152                JSR      X5,STAER      IREPORT BLEW TOO LONG
1237 004252 000000                HALT
1238 004254 005237 001026                S7: INC      CHRGEN      I+1 CHAR.
1239 004260 005237 001024                INC      CHR CNT      I+1 CHAR. COUNT
1240 004264 001401                BEQ      LPS7
1241 004266 000647                BR      81
1242 004270 032777 010P00 174506 LP07: BIT      00IT12,08HR      ICHECK TO LOOP ON TEST
1243 004276 001402                BEQ      .+6           IDO NOT LOOP ON TEST
1244 004300 000137 003732                JMP      8NGCHR      ILOOP ON TEST
1245                I
1246                I
1247
1248                I
1249                ITEST 3
1250                IROTATING PATTERN CHARACTER TEST
1251                I
1252                I
1253 004304 004737 006566                ROTATE: JSR      X7,SIZE
1254 004310 013737 001054 001022                MOV      SEGMENT,SEGCNT      ISET UP SEGMENT COUNT
1255 004316 013737 001052 001030                MOV      WIDTH,LIN CNT      ISET UP LINE COUNT
1256 004324 013737 005036 005032                MOV      R08GFL,SEGFLG      ISET SEGMENT FLAG
1257 004332 013737 005044 005040                MOV      R08LNFL,LINFLG      ISET LINE FLAG
1258 004340 032777 020000 174436 ROT3: BIT      00IT13,08HR      ITEST FOR 96 CHAR.
1259 004346 001404                BEQ      ROT7         I64 CHAR. PRINTER
1260 004350 012737 177640 005050                MOV      0=96,,STRCNT      ISET UP FOR 96 CHAR.
1261 004356 000403                BR      .+10
1262 004360 012737 177700 005050 ROT7: MOV      0=64,,STRCNT      ISET UP FOR 64 CHAR.
1263 004366 012737 000040 005046                MOV      040,STRCHR      IFETCH A SPACE
1264 004374 013737 005046 001026 ROT11: MOV     STRCHR,CHRGEN
1265 004402 013737 005050 001024                MOV     STRCNT,CHR CNT
1266 004410 005777 174364                ROT1: TST     0LPB
1267 004414 100006                BPL     ROT112
1268 004416                ERROR     \N
1269 004416 012737 000051 001050 ERR51: MOV 051,          ERCOUNT      ISET UP ERROR COUNT 51
1270                000052                N=N+1
1271 004424 004537 007152                JSR      X5,STAER
1272 004430 000000                HALT
1273 004432 013777 001026 174342 ROT112: MOV    CHRGEN,0LPB      ILOAD CHARACTER
1274 004440 005237 001022                INC     SEGCNT          I+1 SEGMENT COUNT
1275 004444 001425                BEQ     ROT8           IEND OF SEG.
1276 004446 005237 001026                ROT9: INC     CHRGEN      I+1 CHAR. GENERATOR
1277 004452 005237 001024                INC     CHR CNT      I+1 CHAR. COUNT
1278 004456 001454                BEQ     ROT10         IROLL OVER
1279 004460 000177 000354                ROT4: JMP     0LINFLG
1280 004464 000177 000342                ROT5: JMP     0SEGFLG
1281 004470 013737 005036 005032 ROT2: MOV     R08GFL,SEGFLG
1282 004476 004537 006632                JSR     X5,PRYTH
1283 004502 000742                BR      ROT1
1284 004504                ERROR     \N
1285 004504 012737 000052 001050 ERR52: MOV 052,          ERCOUNT      ISET UP ERROR COUNT 52
1286                000053                N=N+1
1287 004512 004537 007152                JSR     X5,STAER      IREPORT PRINT TIME TOO LONG

```

M2

1288	004516	000000				MALT		
1289								
1290								
1291								
1292	004520	013737	001P54	001022	ROT8:	MOV	SEGMY,SEGCNT	ISET UP SEGMENT COUNT
1293	004526	013737	005030	005032		MOV	BTSGFL,SEGFLG	ISET SEGMENT FLAG
1294	004530	005237	001030			INC	LINCNT	I+1 LINE COUNT
1295	004540	001410				BEQ	ROT8X	
1296	004542	032777	000000	174234		BIT	0BIT10,0SHR	
1297	004550	001736				BEQ	ROT9	
1298	004552	022737	177777	001030		CMP	0=1,LINCNT	
1299	004562	001332				BNE	ROT9	
1300	004562	012737	177764	001022		MOV	0=12,,SEGCNT	
1301	004570	000726				BR	ROT9	
1302	004572	013737	001052	001030	ROT8X:	MOV	WIDTH,LINCNT	IRESET LINE COUNT
1303	004600	013737	005042	005040		MOV	STLNFL,LINFLG	ISET LINE FLAG
1304	004606	000717				BR	ROT9	
1305	004610	012737	000040	001026	ROT10:	MOV	040,CHRCNT	IRESET CHAR. GFM
1306	004616	032777	020000	174160		BIT	0BIT13,0SHR	ISET FOR 96 CHAR.
1307	004624	001404				BEQ	.+12	164 CHAR.
1308	004626	012737	177640	001024		MOV	0=96,,CHRCNT	196 CHAR COUNT
1309	004634	000403				BR	.+10	
1310	004636	012737	177700	001024		MOV	0=64,,CHRCNT	164 CHAR.
1311	004644	000705				BR	ROT4	
1312	004646	013737	005044	005040	ROT6:	MOV	RSLNFL,LINFLG	ISET UP LINE FLG.
1313	004654	013737	005036	005032		MOV	RSSGFL,SEGFLG	ISET UP SEG. FLG.
1314	004662	004537	006632			JSR	X5,PRTH	I CHECK PRINTIME
1315	004666	000406				BR	ROT6X	ITIME OK
1316	004670					ERROR	\N	
1317	004670	012737	000053	001050	ERR53:	MOV #53,	ERCOUNT	ISET UP ERROR COUNT 53
1318		000054				N=N+1		
1319	004676	004537	007152			JSR	X5,STAER	I PRINT TIME TOO LONG
1320	004702	000000				MALT		
1321	004704	005777	174070		ROT6X:	TST	0LPB	I CHECK FOR ERROR
1322	004710	100006				BPL	ROT6X1	I BRANCH IF NO ERROR
1323	004712					ERROR	\N	
1324	004712	012737	000054	001050	ERR54:	MOV #54,	ERCOUNT	ISET UP ERROR COUNT 54
1325		000055				N=N+1		
1326	004720	004537	007152			JSR	X5,STAER	I REPORT PRINTER ERROR
1327	004724	000000				MALT		
1328	004726	105777	174046		ROT6X1:	TSTB	0LPB	I TEST FOR READY
1329	004732	100406				BMI	ROT6X2	I BRANCH IF READY
1330	004734					ERROR	\N	
1331	004734	012737	000055	001050	ERR55:	MOV #55,	ERCOUNT	ISET UP ERROR COUNT 55
1332		000056				N=N+1		
1333	004742	004537	007152			JSR	X5,STAER	I REPORT PRINTER NOT READY
1334	004746	000000				MALT		
1335	004750	012777	000012	174024	ROT6X2:	MOV	012,0LPB	I ISSUE LINE FEED
1336	004756	004537	006642			JSR	X5,0LWTH	I CHECK BLEW TIME
1337	004762	000406				BR	ROT6X3	I SLEW OK
1338	004764					ERROR	\N	
1339	004764	012737	000056	001050	ERR56:	MOV #56,	ERCOUNT	ISET UP ERROR COUNT 56
1340		000057				N=N+1		
1341	004772	004537	007152			JSR	X5,STAER	I REPORT BLEW TOOK TOO LONG

1342	004774	000000				HALT			
1343	005000	005237	005046		ROT6X3:	INC	STRCHR	I+1 START CHAR.	
1344	005004	005237	005050			INC	STRCNT	I+1 CTR, CHAR, CNT.	
1345	005010	001402				BEQ	+6		
1346	005012	000137	004374			JMP	ROT11	I NO ROLL OVER	
1347	005016	032777	010000	173760		BIT	0BIT12,08WR	I LOOP ON TEST	
1348	005020	001412				BEQ	T66	I NO DO NOT LOOP	
1349	005024	000137	004340			JMP	ROT3		
1350									
1351									
1352	005032	004410				SEGFLG:	ROT1		
1353	005034	004470				STSGFL:	ROT2		
1354	005036	004410				RSSGFL:	ROT1		
1355	005040	004464				LINFLG:	ROT5		
1356	005042	004464				STLNFL:	ROT6		
1357	005044	004464				R0LNFL:	ROT5		
1358	005046	000000				STRCHR:	0		
1359	005050	000000				STRCNT:	0		
1360									
1361									
1362									
1363						I TEST 4			
1364						I DOUBLE WEDGE PATTERN			
1365	005052	012737	000077	001026		T61:	MOV	077,CHRGEN	I FETCH?
1366	005060	004737	006566				JBR	X7,SIZE	
1367	005064	032777	040000	173712			BIT	0BIT14,08WR	
1368	005072	001404					BEQ	X66X	
1369	005074	012737	177574	006106			MOV	0-132,,T6LNLC	
1370	005102	000403					BR	+10	
1371	005104	012737	177660	006106	X66X:	MOV	0-00,,T6LNLC		
1372	005112	013737	006106	006102		MOV	T6LNLC,T6LNCT		
1373	005120	013737	001054	001022		MOV	SEGMNT,SEGCNT	I SET UP SEGMENT CNT	
1374	005126	013737	001052	001030		MOV	WIDTH,LINCNT	I SET UP LINE CNT	
1375	005134	005777	173640		T61:	TST	0LPS	I TEST FOR ERROR	
1376	005140	100006				BPL	T61Z	I BRANCH IF NO ERROR	
1377	005142					ERROR	\N		
1378	005142	012737	000057	001050	ERR57:	MOV	057, ERRCOUNT	I SET UP ERROR COUNT 57	
1379		000060				NON+1			
1380	005150	004537	007152			JBR	X5,STAER	I REPORT PRINTER ERROR	
1381	005154	000000				HALT			
1382	005156	013777	001026	173616	T61Z:	MOV	CHRGEN,0LPS	I LOAD CHAR.	
1383	005160	005237	001022			INC	SEGCNT	I+1 SEGMENT CNT	
1384	005170	001013				BNE	T65		
1385	005172	013737	001054	001022		MOV	SEGMNT,SEGCNT	I RESET SEGMENT COUNT	
1386	005200	004537	006632			JBR	X5,PRYTM	I CHECK PRINT TIME	
1387	005204	000405				BR	T65	I PRINT TIME OK	
1388	005206					ERROR	\N		
1389	005206	012737	000060	001050	ERR60:	MOV	060, ERRCOUNT	I SET UP ERROR COUNT 60	
1390		000061				NON+1			
1391	005214	004537	007152			JBR	X5,STAER	I REPORT PRINT TIME TOO LONG	
1392	005220	005237	006102		T65:	INC	T6LNCT		
1393	005224	001343				BNE	T61		
1394	005226	005777	173546			TST	0LPS	I TEST FOR ERROR	
1395	005232	100006				BPL	T65X	I BRANCH IF NO ERROR	

1396	005234					ERROR	\N			
1397	005234	012737	R00061	001050	ERR611	MOV 061,		ERCOUNT		ISET UP ERROR COUNT 61
1398		000062				NON+1				
1399	005242	004537	007152			JSR	X5,STAER			IREPORT PRINTER ERROR
1400	005246	000000				HALT				
1401	005250	012777	000012	173524	T65X1	MOV	012,PLPB			IISSUE LINE FEED
1402	005256	004537	006642			JSR	X5,SLNTIM			ICHECK SLEM TIME
1403	005262	000406				BR	T65Z			IBRANCH IF TIME OK
1404	005264					ERROR	\N			
1405	005264	012737	R00062	001050	ERR621	MOV 062,		ERCOUNT		ISET UP ERROR COUNT 62
1406		000063				NON+1				
1407	005272	004537	007152			JSR	X5,STAER			IREPORT SLEM TIME TOO LONG
1408	005276	000000				HALT				
1409	005300	013737	001054	001022	T65Z1	MOV	SEGMENT,SEGCNT			IRESET SEGMENT CNT
1410	005306	005237	R06106			INC	T6LNLG			I+1 LINE LENGTH
1411	005312	001405				BEQ	T6PT2			
1412	005314	013737	006106	006102		MOV	T6LNLG,T6LNCT			ISET UP NEW LINE CNT
1413	005322	000137	005134			JMP	T61			
1414										
1415										
1416	005326	032777	040000	173450	T6PT21	BIT	00IT14,08WR			
1417	005334	001404				BEQ	X00X			
1418	005336	012737	177574	001032		MOV	0-132,,CYCCNT			
1419	005344	000403				BR	X00X+6			
1420	005346	012737	177660	001032	X00X1	MOV	0-00,,CYCCNT			IPRESET CYCLE COUNT
1421	005354	013737	001054	001022		MOV	SEGMENT,SEGCNT			ISET UP SEG. COUNT
1422	005362	013737	001052	001030		MOV	WIDTH,LINCNT			ISET UP LINE COUNT
1423	005370	005777	173404		T661	TST	0LPS			ICHECK FOR ERROR
1424	005374	100006				DPL	T66X			IBRANCH IF NO ERROR
1425	005376					ERROR	\N			
1426	005376	012737	R00063	001050	ERR631	MOV 063,		ERCOUNT		ISET UP ERROR COUNT 63
1427		000064				NON+1				
1428	005404	004537	007152			JSR	X5,STAER			IREPORT PRINTER ERROR
1429	005410	000000				HALT				
1430	005412	105777	173362		T66X1	TST0	0LPS			ITEST FOR READY
1431	005416	100406				BMI	T66Z			IBRANCH IF READY
1432	005420					ERROR	\N			
1433	005420	012737	R00064	001050	ERR641	MOV 064,		ERCOUNT		ISET UP ERROR COUNT 64
1434		000065				NON+1				
1435	005426	004537	007152			JSR	X5,STAER			IREPORT PRINTER NOT READY
1436	005432	000000				HALT				
1437	005434	013777	001026	173340	T66Z1	MOV	CHRGEN,0LPS			ILOAD CHARACTER
1438	005442	005237	R01022			INC	SEGCNT			I+1 SEG. CNT
1439	005446	001350				BNE	T66			ILOAD NEXT CHARACTER
1440	005450	013737	001054	001022		MOV	SEGMENT,SEGCNT			IRESET SEG. CNT
1441	005456	004537	006632			JSR	X5,PRTYM			ICHECK PRINT TIME
1442	005462	000406				BR	T66Z1			ITIME OK
1443	005464					ERROR	\N			
1444	005464	012737	R00065	001050	ERR651	MOV 065,		ERCOUNT		ISET UP ERROR COUNT 65
1445		000066				NON+1				
1446	005472	004537	007152			JSR	X5,STAER			IREPORT PRINT TIME TOO LONG
1447	005476	000000				HALT				
1448	005500	005237	001030		T66Z11	INC	LINCNT			I+1 LINE COUNT
1449	005504	001414				BEQ	T66Z1X			

1450	005506	032777	000000	173270		BIT	00IT14,08HR	
1451	005514	001729				BEQ	T66	
1452	005516	022737	177777	001030		CMF	0-1,LINCNT	
1453	005524	001321				ONE	T66	
1454	005526	012737	177764	001022		MOV	0-12,,SEGCNT	
1455	005534	000719				OR	T66	
1456	005536	013737	001052	001030	T66Z1X1	MOV	WIDTH,LINCNT	IRESET LINE COUNT
1457	005544	005777	173230			TST	0LPS	ICHECK FOR ERROR
1458	005550	100006				BPL	T70	IBRANCH IF NO ERROR
1459	005552					ERROR	\N	
1460	005552	012737	000066	001050	ERR66:	MOV #66,	ERCOUNT	ISET UP ERROR COUNT 66
1461		000067				NON+1		
1462	005560	004537	007152			JBR	IS,STAER	IREPORT PRINTED ERROR
1463	005564	000000				HALT		
1464	005566	105777	173206		T70:	TSTB	0LPS	ITEST FOR READY
1465	005572	100406				OMI	T70X	IBRANCH IF READY
1466	005574					ERROR	\N	
1467	005574	012737	000067	001050	ERR67:	MOV #67,	ERCOUNT	ISET UP ERROR COUNT 67
1468		000070				NON+1		
1469	005602	004537	007152			JBR	IS,STAER	IREPORT PRINTED NOT READY
1470	005606	000000				HALT		
1471	005610	012777	000012	173164	T70X:	MOV	012,0LPS	ISSUE LINE FEED
1472	005616	004537	006642			JBR	IS,SLMTIM	ICHECK BLEW TIME
1473	005622	000406				OR	T71	
1474	005624					ERROR	\N	
1475	005624	012737	000070	001050	ERR70:	MOV #70,	ERCOUNT	ISET UP ERROR COUNT 70
1476		000071				NON+1		
1477	005632	004537	007152			JBR	IS,STAER	IREPORT BLEW TONK TOO LONG
1478	005636	000000				HALT		
1479	005640	005237	001032		T71:	INC	CYCCNT	I+1 CYCLE COUNT
1480	005644	001006				ONE	T72	
1481	005646	032777	010000	173130		BIT	00IT12,08HR	ICHECK TO LOOP ON TEST
1482	005654	001515				BEQ	HAMALN	IFNO GO TO NEXT TEST
1483	005656	000137	005052			JMP	T8T6	ILOOP ON TEST
1484	005662	013737	001054	001022	T72:	MOV	SEGMNT,SEGCNT	
1485	005670	032777	040000	173106		BIT	00IT14,08HR	
1486	005676	001404				BEQ	T72X	
1487	005700	012737	000204	006104		MOV	0132,,T6SPCT	
1488	005706	000403				OR	+10	
1489	005710	012737	000120	006104	T72X:	MOV	000,,T6SPCT	IGET CYCLE COUNT AND
1490	005716	063737	001032	006104		ADD	CYCCNT,T6SPCT	IDERIVE SPACE COUNTER
1491								
1492	005724	005777	173050		T69:	TST	0LPS	ITEST FOR ERROR
1493	005730	100006				BPL	T69X	IBRANCH IF NO ERROR
1494	005732					ERROR	\N	
1495	005732	012737	000071	001050	ERR71:	MOV #71,	ERCOUNT	ISET UP ERROR COUNT 71
1496		000072				NON+1		
1497	005740	004537	007152			JBR	IS,STAER	IREPORT PRINTER ERROR
1498	005744	000000				HALT		
1499	005746	105777	173026		T69X:	TSTB	0LPS	ITEST FOR READY
1500	005752	100406				OMI	T69Z	IBRANCH IF READY
1501	005754					ERROR	\N	
1502	005754	012737	000072	001050	ERR72:	MOV #72,	ERCOUNT	ISET UP ERROR COUNT 72
1503		000073				NON+1		

1504	005762	004537	007152			JSR	X5,STAER		IREPORT PRINTER NOT READY
1505	005766	000000				HALT			
1506	005770	012777	000040	173004	T69Z1	MOV	040,0LPB		ILOAD SPACE
1507	005776	005237	001022			INC	SEGCNT		
1508	006002	001032				BNE	T60X		
1509	006004	013737	001054	001022		MOV	SEGMNT,SEGCNT		
1510	006012	004537	006632			JSR	X5,PRTYM		I CHECK PRINT TIME
1511	006016	020406				BR	T60		I PRINT TIME OK
1512	006020					ERRDR	\N		
1513	006020	012737	000073	001050	ERR731	MOV	073, ERCCOUNT		ISET UP ERROR COUNT 73
1514		000074				N=N+1			
1515	006026	004537	007152			JSR	X5,STAER		IREPORT PRINT TIME TOO LONG
1516	006032	000000				HALT			
1517	006034	005237	001030		T601	INC	LINCNT		
1518	006040	001416				BEQ	T60Z		
1519	006042	032777	040000	172734		BIT	00IT14,0SWR		
1520	006050	001407				BEQ	T60X		
1521	006052	022737	177777	001030		CMF	0=1,LINCNT		
1522	006060	001003				BNE	T60X		
1523	006062	012737	177764	001022		MOV	0=12,,SEGCNT		
1524	006070	005337	006104		T60X1	DEC	T60PCT		
1525	006074	001313				BNE	T60		
1526	006076	000137	005370		T60Z1	JMP	T66		
1527	006102	000000				T6LNC1:	0		
1528	006104	000000				T6SPCT:	0		
1529	006106	000000				T6LNLG1:	0		
1530									
1531						/			
1532						/			
1533						/			
1534						IHAMMER ALIGNMENT			
1535						/			
1536	006110	012737	177702	006252	HAMALN1	MOV	0=76,HAMCNT		ISET UP FOR 63 LINES
1537	006116	032777	040000	172660	HAMIX1	BIT	00IT14,0SWR		
1538	006124	001404				BEQ	HAM1		
1539	006126	012737	177574	001030		MOV	0=132,,LINCNT		
1540	006134	000403				BR	HAM2		
1541	006136	012737	177660	001030	HAM11	MOV	0=00,,LINCNT		ISET UP LINE COUNT
1542	006144	005777	172630		HAM21	TST	0LPS		I CHECK FOR ERROR
1543	006150	100006				BPL	XHAM1		I BRANCH IF NO ERROR
1544	006152					ERROR	\N		
1545	006152	012737	000074	001050	ERR741	MOV	074, ERCCOUNT		ISET UP ERROR COUNT 74
1546		000075				N=N+1			
1547	006160	004537	007152			JSR	X5,STAER		IREPORT ERROR OCCURRED
1548	006164	000000				HALT			
1549	006166	105777	172606		XHAM11	TSTB	0LPS		I CHECK FOR READY
1550	006172	100375				BPL	0=4		
1551	006174	012777	000105	172600	XHAMIX1	MOV	0105,0LPB		I TRANSMIT E TO PRINTER
1552	006202	005237	001030			INC	LINCNT		I+1 LINE COUNT
1553	006206	001356				BNE	HAM2		I TRANSMIT ANOTHER CHAR.
1554	006210	105777	172564			TSTB	0LPS		
1555	006214	100375				BPL	0=4		
1556	006216	012777	000012	172556		MOV	012,0LPB		I TRANSMIT LINE FEED
1557	006224	105777	172550			TSTB	0LPS		I TEST FOR READY

```

1550 006230 100375          SPL      =4          IWAIT FOR READY
1550 006232 005237 006252  INC      HAMCNT      I+1 COUNT
1560
1561 006236 001327          ONE      HAMIX          IGO DO NEXT LINE
1562 006240 032777 010000 172536  BIT      @BIT12,@SWR    ICHECK TO LOOP ON TEST
1563 006246 001320          ONE      HAMALN         ILOOP ON TEST
1564 006250 000401          BR       =4
1565 006252 000000          HAMCNT: 0
1566
1567
1568 ITEST 4, SLEW TEST ROUTINE
1569
1570
1571 006254 012737 006454 006450  SLWTSY: MOV      @TABSTR, @TPTR  IPRESET LINE COUNT
1572 006262 032777 040000 172514  SLWIX:  BIT      @BIT14,@SWR
1573 006270 001404          BEQ     SLW1=6
1574 006272 012737 177574 001030  MOV     @-132,,LINCNT
1575 006300 000403          BR     SLW1
1576 006302 012737 177660 001030  MOV     @-80,,LINCNT  ISET UP LINC LENGTH
1577 006310 012777 000105 172464  SLW1:  MOV     @105,@LPS  ILOAD CHARACTER "E"
1578 006316 005777 172456          TST    @LPS           ITEST FOR ERROR
1579 006322 100003          SPL     XSLW1         IBRANCH IF NO ERROR
1580 006324          ERROR  IN          IAN ERROR OCCURRED
1581 006324 012737 000075 001050  ERR75: MOV     @75,    ERCOUNT  ISET UP ERROR COUNT 75
1582          NON+1
1583 006332 105777 172442          XSLW1: TST@    @LPS           ITEST FOR READY
1584 006336 100367          SPL     SLW1+6       IBRANCH BACK NOT READY
1585 006340 005237 001030          INC     LINCNT       I+1 LINE COUNT
1586 006344 001361          ONE     SLW1
1587 006346 017737 000076 006452  MOV     @TPTR, @SLWCNT  ISET UP SLEW CNT
1588 006354 012777 000012 172420  SLEW1  MOV     @12,@LPS    IISS E LINE FEED
1589 006362 105777 172412          TST@    @LPS           ITEST FOR READY
1590 006366 100375          SPL     =4
1591 006370 005237 006452          INC     SLWCNT
1592 006374 001367          BNE     SLEW         IISSUE NEXT SLEW
1593 006376 023727 006450 006500  CMP     @TPTR, @TABEND  I
1594 006404 001015          BNE     INCSLW
1595 006406 032777 010000 172370  BIT     @BIT12,@SWR    ICHECK TO LOOP ON TEST
1596 006414 001317          BNE     SLWTSY       IYES LOOP ON TEST
1597 006416 013700 000042          MOV     @042,@0
1598 006422 001404          BEQ     INCSLW-4
1599 006424 004710          LOGICAL: JBR      @7,(0)
1600          NOP
1601          NOP
1602          NOP
1603 006434 000137 001316          JMP     TEST1
1604 006440 062737 000002 006450  INCSLW: ADD     @2, @TPTR  IRECYCLE TEST
1605 006446 000705          BR     SLWIX         ISET UP NEW SLEW CNT
1606
1607
1608 006450 000000          TOPTR: 0
1609 006452 000000          SLWCNT: 0
1610 006454 177775          TABSTR: -3
1611 006456 177776          =2
          ISLEW 3 LINES
          ISLEW 2 LINES

```


1612	006460	177766			-12				ISLEW 12 LINES
1613	006462	177762			-16				ISLEW 16 LINES
1614	006464	177772			-6				ISLEW 6 LINES
1615	006466	177775			-3				ISLEW 3 LINES
1616	006470	177770			-10				ISLEW 10 LINES
1617	006472	177774			-4				ISLEW 4 LINES
1618	006474	177773			-5				ISLEW 5 LINES
1619	006476	177773			-5				ISLEW 5 LINES
1620	006500	177775				TABEND1	-3		ISLEW 3 LINES
1621						/			
1622						/			
1623						/			
1624	006502	013737	006556	006564		PRFTIM:	MOV	FFTIMU,FFCNT2	ISSET UP TIMER ASSUME /5INC/SEC
1625	006510	013737	006560	006562			MOV	FFTIML,FFCNT1	
1626	006516	105777	172256			FFRDY:	TSTB	PLPB	ITEST FOR READY
1627	006522	100001					OPL	,+4	IPRINTER NOT READY
1628	006524	000205					RTB	Z5	IEXIT HERE IF READY SEC
1629	006526	005237	006562				INC	FFCNT1	
1630	006532	001371					ONE	FFRDY	
1631	006534	013737	006560	006562			MOV	FFTIML,FFCNT1	
1632	006542	005237	006564				INC	FFCNT2	
1633	006546	001363					ONE	FFRDY	
1634	006550	062705	000002				ADD	R2,Z5	IEXIT TIME TOO LONG
1635	006554	000205					RTB	Z5	
1636							/		
1637	006556	177210				FFTIMU:	-570		
1638	006560	177210				FFTIML:	-570		
1639	006562	000000				FFCNT1:	0		
1640	006564	000000				FFCNT2:	0		
1641						/			
1642	006566	032777	040000	172210		SIZE:	BIT	001714,08WR	
1643	006574	001407					BEQ	COL00	
1644	006576	012737	177750	001054			MOV	R=24,,SEGMNT	
1645	006604	012737	177772	001052			MOV	R=6,WIDTH	
1646	006612	000207					RTB	Z7	
1647	006614	012737	177754	001054		COL00:	MOV	R=20,,SEGMNT	
1648	006622	012737	177774	001052			MOV	R=4,WIDTH	
1649	006630	000207					RTB	Z7	
1650						/			
1651						/			
1652						MISC. ROUTINE			
1653						WAIT 144 MSEC. FOR CHARACTER TO BE PRINTED			
1654						WAIT 136 MSEC FOR SLEW TO BE EXECUTED			
1655						/			
1656	006632	012737	140000	001044		PRFTM:	MOV	R140000,WORK	ISSET UP FOR 144 MSEC COUNT
1657	006640	000403					BR	PTIMU	/
1658	006642	012737	140000	001044		SLWTIME:	MOV	R140000,WORK	ISSET UP FOR 136 MSEC COUNT
1659	006650	005777	172124			PTIMU:	TST	PLPB	IS THERE AN ERROR
1660	006654	100406					BMI	PITML	IBRANCH IF ERROR
1661	006656	105777	172116				TSTB	PLPB	ITEST FOR READY COND.
1662	006662	100405					BMI	PTIML	IBRANCH IF READY
1663	006664	005237	001044				INC	WORK	IWAIT FOR FLAG
1664	006670	001367					ONE	PTIMU	IEND FLAG WAIT
1665	006672	062705	000002			PITML:	ADD	R2,Z5	ISSET UP FOR ERROR REPORT

```

1666 006676 000205          PTIML: RTS      X5          IEXIT
1667                          /
1668                          /
1669                          /
1670                          /
1671                          /
1672          IROUTINE TO INITIALIZE PRINTER
1673          IENTER FROM JSR X5, PRINT
1674          /
1675 006700 105777 172074    PRINT: TSTB      0LPS          ITEST FOR READY
1676 006704 100403          BMI      ROYOK          IREADY SET OK
1677 006706 062705 000002          ADD      02,X5          ISET UP FOR ERROR REPORT
1678 006712 000205          RTS      X5          IREPORT READY NOT SET
1679 006714 012777 000014 172060 ROYOK: MOV      010,0LPS          IISSUE FOR FEED
1680 006722 105777 172052          TSTB      0LPS          ITEST FOR READY NOT SET
1681 006726 100003          BPL      NTRDY          IREADY NOT SET OK
1682 006730 062705 000012          ADD      012,X5          ISET UP FOR REPORT
1683 006734 000205          RTS      X5          IEXIT AND REPORT
1684 006736 105777 172036    NTRDY: TSTB      0LPS
1685 006742 100375          BPL      -4
1686 006744 000205          RTS      X5          ITEST FORRDY SET
1687                          /
1688                          /
1689                          /
1690                          /
1691                          /
1692                          /
1693          ISUBROUTINE TO OUTPUT ASCII MESSAGES ON TELETYPE PRINTER
1694          /
1695 006746 011600          TYP:  MOV      026,X0          IGET ADDR. THAT CONTAINS MESS.
1696 006750 062716 000002          ADD      02,026          ISET UP EXIT
1697 006754 011800          MOV      020,X0          IADDRESS OF MESSAGE IN R0
1698
1699 006756 112037 007066          TYP:  MOVB    (0)+,TYPDAT          IGET CHARACTER
1700 006762 122737 000100 007066          CMPB    0100,TYPDAT          ICHECK FOR "0" CHARACTER
1701 006770 001001          BNE     TYPC          IBRANCH IF NOT "0"
1702 006772 000002          RTI     TYPC          IBYTE EQUALED "0" EXIT
1703 006774 122737 000045 007066          TYP:  CMPB    045,TYPDAT          ICHECK FOR "X"
1704 007002 001416          BEQ     TYPF          IBRANCH IF "X"
1705 007004 122737 000042 007066          CMPB    042,TYPDAT          ICHECK FOR "0"
1706 007012 001417          BEQ     TYPG          IBRANCH IF "0"
1707 007014 004737 007022          JSR     X7,TY.          ITYPE CHARACTER IN TYPDAT
1708 007020 000756          BR     TYPA
1709 007022 113777 007066 171762          TYP:  MOVB    TYPDAT,0TPB          IOUTPUT CHARACTER TO PRINTER
1710 007030 105777 171762          TSTB    0TPB          IWAIT FOR DONE FLAG
1711 007034 100375          BPL     -4
1712 007036 000207          RTS     X7
1713 007040 112737 000015 007066          TYP:  MOVB    015,TYPDAT          ICHAR, TYPED EXIT
1714 007046 004737 007022          JSR     X7,TYP          IOUTPUT CARRIAGE RETURN
1715 007052 112737 000012 007066          TYP:  MOVB    012,TYPDAT          I60 TYPE CHAR,
1716 007060 004737 007022          JSR     X7,TYP          IOUTPUT LINE FEED
1717 007064 000734          BR     TYP
1718 007066 000000          TYPDAT: B
1719                          /

```

```

1720
1721
1722
1723
1724
1725
1726
1727
1728
1729 007070 013537 007150
1730 007074 012501
1731 007076 012502
1732 007100 000201
1733 007102 013703 007150
1734 007106 042703 177770
1735 007112 062703 000060
1736 007116 110341
1737 007120 000241
1738 007122 006037 007150
1739 007126 000241
1740 007130 006037 007150
1741 007134 000241
1742 007136 006037 007150
1743 007142 005302
1744 007144 001356
1745 007146 000205
1746
1747 007150 000000
1748
1749
1750
1751
1752
1753
1754
1755
1756 007152 004537 007070
1757 007156 001050
1758 007160 007210
1759 007162 000003
1760 007164 104000
1761 007166 007206
1762 007170 104000
1763 007172 007210
1764 007174 005777 171604
1765 007200 100001
1766 007202 000000
1767 007204 000205
1768
007206 040045
007210 020040 020040 051105

/
/ROUTINE TO CONVERT OCTAL TO ASCII
/
/ENTER ROUTINE AS FOLLOWS
/   JSR      RS,CONV
/XXXXXXXX=ADDRESS OF NUMBER TO BE CONVERTED
/XXXXXXXX=ADDRESS OF ASCII MESSAGE
/XXXXXXXX=NUMBER OF OCTAL NO.'S TO BE CONVERTED
/
CONV:  MOV     0(5)+,ACNVX  /ADDRESS OF NO. TO BE CONVERTED
      MOV     (5)+,X1     /ADDRESS OF MESSAGE
      MOV     (5)+,X2     /NUMBER OF ASCII CHARACTERS
      ADD     X2,X1
ACVX:  MOV     ACNVX,X3     /ISOLATE LEAST SIGNIFICANT BIT
      BIC     0177770,X3
      ADD     060,X3      /SET UP ASCII CHARACTER
      MOVB   X3,-(1)     /STORE CHARACTER
      CLC
      ROR     ACNVX
      CLC
      ROR     ACNVX
      CLC
      ROR     ACNVX
      DEC     X2          /I-1 FROM ASCII CHAR, CNT
      ONE    ACVN        /CONVERT NEXT CHARACTER
      RTS     RS         /EXIT; CONVERSION DONE
/
ACVX:  0                /WORK REGISTER
/
/
/
/
/
/ROUTINE TO REPORT ERROR COUNT
/
STAER: JSR     RS,CONV    /CONVERT OCTAL TO ASCII
      ERCOUNT
      MED1
      S
      ENT     +0         /PRINT MESSAGE
      MEDIA
      ENT     +0
      MED1
      TST    08=R       /TEST FOR HALT ON ERROR
      BPL    .+6
      HALT
      RTS     RS
MEDIA: .ASCII /X0/
/
/
MED1:  .ASCII / ERROR COUNT0/
/

```

```

      /
      /
      /
007230 046445 044501 042110 ME811 .ASCII /BMAINDEC-11-DZLPA-8 LINE PRINTER TEST0/
      /
007276 051045 051505 040524 ME821 .ASCII /XRESTART ADDRESS 6000/
      /
007323 045 047520 042527 ME831 .ASCII /XPOWER ON-TURN ON LINE0/
      /
007352 047445 020116 044514 ME841 .ASCII /XON LINE OK-TRY TORN PAPER SWITCH0/
      /
007414 042445 051122 051117 ME851 .ASCII /XERROR SET OK-TRY DRUM GATE SWITCH0/
      /
007457 045 051105 047522 ME861 .ASCII /XERROR SET OK-TURN ON LINE 0/
      /
      /
      /
  
```

```

/PLP11 SCOPE LOOP ROUTINE
/SET CHARACTER IN SWITCH REGISTER 5-0.
  
```

```

      007514 .EVEN
1769 007514 004737 006966 SCOPE: JSR 57,01ZE
1770 007520 017737 171260 MOV 05WR,SAVE /FETCH SWITCHES
1771 007526 013737 001054 001022 MOV 05MNT,SEGCNT
1772 007534 013737 001052 001030 MOV WIDTH,LINCNT
1773 007542 042737 177600 001046 BIC 017760,SAVE /MASK CHARACTER
1774 007550 105777 171224 LDLPX: TSTB 0LPS /TEST FOR READY
1775 007554 100375 BPL =4 /WAIT FOR READY
1776 007556 013777 001046 171216 MOV SAVE,0LPS /LOAD PRINTER BUFFER
1777 007564 005777 171210 TST 0LPS /TEST FOR ERROR
1778 007570 100006 BPL LPSCOPE /BRANCH IF NO ERROR
1779 007572 ERROR \N
1780 007572 012737 000076 001050 ERR76: MOV 076, ERCCOUNT /SET UP ERROR COUNT 76
1781 000077 NON+1
1782 007600 004537 007152 JSR 55,5TAER /REPORT ERROR SET
1783 007604 000000 HALT /OPERATOR MUST TAKE ACTION
1784 007606 005237 001022 LPSCOPE: INC SEGCNT
1785 007612 001356 ONE LDLPX
1786 007614 013737 001054 001022 MOV 05MNT,SEGCNT
1787 007622 005237 001030 INC LINCNT
1788 007626 001414 BEQ LOBCOP
1789 007630 032777 040000 171146 BIT 001714,05WR
1790 007636 001746 BEQ LDLPX
  
```

```

1791 007640 022737 177777 001030      CMP      S-1,LINCNT
1792 007646 001340                      BNE      LDLPX
1793 007650 012737 177764 001022      MOV      S-12.,SEGCNT
1794 007656 000734                      BR       LDLPX
1795 007660 013737 001052 001030  LOSCOPE: MOV      WIDTH,LINCNT
1796 007666 012777 000012 171106      MOV      @12,PLPB
1797 007674 105777 171100                      TSTB    PLPB
1798 007700 100375                      SPL      .-4
1799 007702 017737 171076 007150  SRCHAN: MOV      @BWR,ACNVX
1800 007710 042737 177600 007150      BIC      @177600,ACNVX
1801 007716 023737 007150 001046      CMP      ACNVX,SAVE
1802 007720 001273                      BNE      SCOPE
1803 007726 000674                      BR       SCOPE+4
1804
1805
1806
1807
1808
1809
1810      000001                      .END
  
```

```

)TEST FOR READY
)WAIT FOR READY
)
)HAS SR CHANGED
)NEW SR
)SR HAS NOT CHANGED
  
```

ACNVX	007150	17290	1733	17380	17400	17420	17470	17990	18000	1801				
ACVN	007102	17330	1740											
BIT0	000001	5540												
BIT1	000002	5530												
BIT10	002000	5440												
BIT11	004000	5430												
BIT12	010000	5420	920	1061	1150	1242	1347	1401	1562	1595				
BIT13	020000	5410	953	1175	1250	1306								
BIT14	040000	5400	574	737	912	906	1070	1195	1296	1367	1416	1450	1485	1519
		1537	1572	1642	1700									
BIT15	100000	5390												
BIT2	000004	5520												
BIT3	000010	5510												
BIT4	000020	5500												
BIT5	000040	5490												
BIT6	000100	5480												
BIT7	000200	5470												
BIT8	000400	5460												
BIT9	001000	5450												
CHARSW	002414	8800	896	8970	9360	9420								
CHRCNT	001024	6310	9600	10020	10130	10140	10150	10160	10360	11770	11790	12390	12650	12770
		13000	13100											
CHRCNT	001026	6320	9630	973	10010	1025	10300	10390	1040	1042	1044	11010	1109	12300
		12640	1273	12760	13050	13650	1302	1437						
COL00	006614	1643	16470											
CONV	007070	17200	1756											
CYCCNT	001032	6340	8050	9260	9550	9590	10500	10930	11190	11210	11440	14100	14200	14790
		1490												
CYCYST	003722	10900	1121	11430	1144	1145	11650							
DISPLA	001006	6090	6560											
DISPRE	000174	5770	656											
ERCOU	001050	6410	6710	6790	6920	7020	7200	7300	7440	7510	7610	7750	7820	7870
		7960	8070	8190	8470	8540	8620	8810	8920	9070	9230	9690	9800	9970
		10000	10210	10320	10540	10860	10900	11050	11150	11390	11540	11850	12030	12120
		12190	12260	12340	12690	12850	13170	13240	13310	13390	13700	13890	13970	14050
		14260	14330	14440	14600	14670	14750	14950	15020	15130	15450	15010	1757	17800
ERNO	001034	6350												
ERR0	001156	6710												
ERR1	001200	6790												
ERR10	001470	7610												
ERR11	001526	7750												
ERR12	001550	7820												
ERR13	001564	7870												
ERR14	001616	7960												
ERR15	001650	8070												
ERR16	001702	8190												
ERR17	001774	8470												
ERR2	001244	6920												
ERR20	002016	8540												
ERR21	002050	8670												
ERR22	002106	8810												
ERR23	002160	8920												
ERR24	002246	9070												
ERR25	002340	9230												

ERR26	002542	9690			
ERR27	002606	9800			
ERR3	001274	7020			
ERR30	002700	9970			
ERR31	002746	10000			
ERR32	003022	10210			
ERR33	003066	10320			
ERR34	003170	10540			
ERR35	003306	10860			
ERR36	003366	10980			
ERR37	003410	11050			
ERR4	001326	7200			
ERR40	003452	11150			
ERR41	003600	11390			
ERR42	003664	11540			
ERR43	004014	11850			
ERR44	004114	12030			
ERR45	004144	12120			
ERR46	004166	12190			
ERR47	004210	12260			
ERR5	001352	7300			
ERR50	004240	12340			
ERR51	004416	12690			
ERR52	004504	12850			
ERR53	004670	13170			
ERR54	004712	13240			
ERR55	004734	13310			
ERR56	004764	13390			
ERR57	005142	13780			
ERR6	001416	7440			
ERR60	005206	13890			
ERR61	005234	13970			
ERR62	005264	14050			
ERR63	005376	14260			
ERR64	005420	14330			
ERR65	005464	14440			
ERR66	005552	14600			
ERR67	005574	14670			
ERR7	001440	7510			
ERR70	005624	14750			
ERR71	005732	14950			
ERR72	005754	15020			
ERR73	006020	15130			
ERR74	006152	15450			
ERR75	006324	15810			
ERR76	007572	17800			
FFCNT1	006562	16290	16290	16310	16390
FFCNT2	006564	16240	16320	16400	
FPRDY	006516	16260	1630	1633	
FFYIML	006560	1629	1631	16380	
FFYIMU	006556	1624	16370		
FORMP	003300	1001	10030		
FRPYIM	006502	1151	16240		
HAMALN	006110	591	1482	15360	1563

M3

HAMCNY	006252	1536	1550	1565																
HAM1	006136	1538	15410																	
HAM1X	006116	1537	1561																	
HAM2	006148	1540	15420	1593																
MED1	007210	1758	1763	1768																
MEDIA	007206	1761	1768																	
INCCY	003466	1113	1119																	
INCOLW	006440	1594	1598	1624																
INTIC	001740	770	832																	
INTID	002064	842	869																	
LDCH	003036	1019	1025																	
LOLPX	007550	1774	1785	1798	1792	1794														
LEGCHR	003236	957	961	964	1014	1067														
LINCNT	001030	633	886	918	918	918	962	984	988	992	1108	1193	1197	1208						
		1255	1294	1298	1382	1374	1422	1448	1452	1456	1517	1521	1539	1541						
		1552	1574	1576	1585	1772	1787	1791	1795											
LINFLG	005040	1257	1279	1303	1312	1355														
LINPT	004186	1196	1198	1200																
LOCA	001840	637																		
LOGICA	006424	572	1599																	
LOSCOP	007660	1788	1795																	
LPB	001002	693	687	688	740	899	919	973	993	1004	1025	1050	1108	1129						
		1131	1135	1150	1189	1230	1273	1335	1382	1401	1437	1471	1506	1551						
		1556	1577	1588	1679	1776	1796													
LPS	001000	599	668	676	689	699	717	727	741	748	756	772	779	798						
		792	799	801	818	812	822	824	844	851	859	870	889	966						
		1018	1095	1102	1126	1182	1216	1223	1266	1321	1328	1375	1394	1423						
		1438	1457	1464	1492	1499	1542	1549	1554	1557	1578	1583	1589	1626						
		1659	1661	1675	1680	1684	1774	1777	1797											
LPSCOP	007606	1774	1784																	
LP87	004270	1240	1242																	
LPT7X	003612	1137	1143																	
LP1	001432	742	748	759																
LP2	001454	749	756																	
LP20	002174	890	896																	
LP20X	003204	1052	1058																	
LP2C	002462	954	950																	
LP2E	002556	967	973																	
LP2F	002628	978	983																	
LP2H	002762	1006	1012																	
LP3	001542	773	779																	
LP3X	001564	780	786																	
LP4	002010	845	851																	
LP5	002032	852	858																	
LP5A	002260	905	910																	
LP80	002352	921	926																	
ME01	007230	662	1768																	
ME02	007276	664	1768																	
ME03	007323	666	1768																	
ME04	007352	684	1768																	
ME05	007414	697	1768																	
ME06	007457	707	1768																	
N	000077	617	678	672	678	688	691	693	701	703	719	721	729	731						
		743	745	750	752	760	762	774	776	781	783	786	788	795						

		7970	806	8080	818	8200	846	8480	853	8550	861	8630	880	8820
		891	8930	906	9080	922	9240	968	9700	970	9810	996	9980	1007
		10090	1020	10220	1031	10330	1053	10550	1085	10870	1097	10990	1104	11060
		1114	11160	1130	11400	1153	11550	1184	11860	1202	12040	1211	12130	1210
		12200	1229	12270	1233	12350	1268	12700	1284	12860	1316	13180	1323	13250
		1330	13320	1330	13400	1377	13790	1388	13900	1396	13980	1404	14060	1429
		14270	1432	14340	1443	14450	1450	14610	1466	14680	1474	14760	1494	14960
		1501	15030	1512	15140	1544	15460	1580	15820	1779	17810			
		9560	9600	983	10660									
NOCHRS	003234													
NOP	000240	6160												
NTRDY	006736	1601	16040											
PC	0000007	5360												
PHFLG	003724	10910	1122	11230	11330	11660								
PITML	006672	1660	16650											
PRTINT	006780	870	1003	16750										
PRTYM	006632	904	977	1029	1112	1200	1200	1202	1314	1386	1441	1510	16960	
PS	001010	6100	7090	7900	8090	8210	8500							
PTIHL	006676	1662	16660											
PTIMU	006650	1657	16590	1664										
RCHRSH	002420	936	9440											
RDYOK	006714	1676	16790											
REFIL	002662	985	9920											
ROTATE	004304	509	12530											
ROT1	004410	12660	1283	1352	1354									
ROT10	004610	1270	13050											
ROT11	004374	12640	1346											
ROT11Z	004432	1267	12730											
ROT2	004470	12810	1353											
ROT3	004340	12500	1349											
ROT4	004460	12790	1311											
ROT5	004464	12000	1355	1357										
ROT6	004446	13120	1356											
ROT6X	004704	1315	13210											
ROT6X1	004726	1322	13280											
ROT6X2	004750	1329	13350											
ROT6X3	005000	1337	13430											
ROT7	004360	1259	12620											
ROT8	004520	1275	12920											
ROT8X	004572	1295	13020											
ROT9	004446	12760	1297	1299	1301	1304								
RSLNFL	005044	1257	1312	13570										
RS00FL	005036	1256	1281	1313	13540									
SAVE	001046	6400	8980	899	9370	17700	17730	1776	1801					
SCHRSH	002416	888	897	9430										
SCOPE	007514	593	17690	1802	1803									
SEGCNT	001022	6300	8870	9000	9030	9160	9650	9740	9760	9900	10120	10260	10280	10940
		11090	11110	11740	11900	11920	11990	12540	12740	12920	13000	13730	13830	13850
		14090	14210	14300	14400	14540	14840	15070	15090	15230	17710	17840	17860	17930
SEGPLG	005032	12560	1280	12810	12930	13130	13920							
SEGMNT	001054	6430	887	903	965	976	1012	1020	1094	1111	1170	1192	1294	1292
		1373	1385	1409	1421	1440	1484	1509	16440	16470	1771	1786		
SETUP	001056	582	6400											
SIZE	006566	877	952	1076	1173	1253	1366	16420	1769					
BLEW	006354	15800	1592											

SLWCNT	006452	1587*	1591*	1609*														
SLWTIM	006642	920	994	1005	1051	1136	1231	1336	1402	1472	16500							
SLWYST	006254	592	15710	1596														
SLWI	006310	1573	1575	1577*	1584	1586												
SLWIX	006262	1572*	1605															
SNOCHR	003732	580	1161	1173*	1244													
SP	*X000006	537*	649*	650*	657	659	660											
SPCPLG	003726	1092*	1107	1124*	1134*	1167*												
SRCHAN	007702	1799*																
STAER	007152	673	681	694	704	722	732	746	753	763	777	784	833	840				
		856	864	883	894	909	925	971	982	999	1010	1023	1034	1056				
		1088	1100	1117	1141	1156	1187	1205	1214	1221	1220	1236	1271	1307				
		1319	1326	1333	1341	1380	1391	1399	1407	1420	1435	1446	1462	1469				
		1477	1497	1504	1515	1547	1756*	1782										
STLNFL	005042	1303	1356*															
STP1	001150	660*	674															
STP2	001172	669	676*	682														
STP3	001214	677	683*															
STP4	001222	686*	695															
STP5	001260	698	696*															
STP6	001266	699*	705															
STP7	001310	700	706*															
STRCHR	005046	1263*	1264	1343*	1350*													
STRCNT	005050	1268*	1262*	1265	1344*	1359*												
STBOPF	005234	1293	1353*															
SWR	001004	688*	652	655*	737	912	929	953	986	1061	1078	1158	1175	1195				
		1242	1258	1296	1306	1347	1367	1416	1450	1481	1485	1519	1537	1562				
		1572	1595	1642	1764	1770	1789	1799										
SWREG	000176	578*	655															
S1	004006	1102*	1191	1201	1241													
S2	003764	1176	1179*															
S4	004130	1194	1200*															
S4X	004160	1210	1216*															
S4X1	004202	1217	1223*															
S4X2	004224	1224	1230*															
S7	004254	1232	1230*															
TABEND	006500	1593	1620*															
TABSTR	006454	1571	1610*															
TOPYR	006450	1571*	1587	1593	1604*	1600*												
TEST1	001316	594	716*	723	1603													
TEST1A	001342	710	726*	733														
TEST10	001366	720	737*	747	754	764												
TEST1C	001504	730	757	770*	778	785	834											
TEST10	001752	825	842*	850	857	865												
TEST2A	002074	585	877*	930														
TEST2B	002422	596	931	952*	1063													
TEST3	003240	587	1064	1076*	1160													
TKB	001014	612*																
TKB	001020	614*																
YPB	001012	611*	1709*															
YPS	001016	613*	1710															
TSYNO	001036	636*																
TSYSN	001042	638*																
TST2AX	002122	879	885*															

TBT6	005052	590	1340	13650	1483																
TYP	006746	567	16950																		
TYPA	006756	16990	1700	1717																	
TYPC	006774	1701	17030																		
TYPD	007022	1707	17090	1714	1716																
TYPDAT	007066	16990	1700	1703	1705	1709	17130	17150	17180												
TYPF	007040	1704	17130																		
TYPG	007052	1706	17150																		
T1	003360	10950	1110	1120	1120	1147															
T1A	002200	8970	944																		
T1X	003416	1103	11070																		
T2A	002374	9360	943																		
T200	002504	950	9620	1060																	
T201	002534	9660	1003																		
T202	002720	960	975	987	989	991	995	10010													
T203	003014	10100	1046																		
T204	003102	1027	1030	10360	1041	1043	1045														
T205	003154	1037	10500																		
T207	002624	956	9840																		
T3A	002152	8890	902	913	915	917	920														
T3NCMT	003720	10770	11400	11640																	
T4	003540	1124	11310																		
T5	003422	1092	11000	1134																	
T5A	002214	8990	930																		
T5X	003430	11090	1132																		
T6LNCT	006102	13720	13920	14120	15270																
T6LNLO	006106	13690	13710	1372	14100	1412	15290														
T6PT2	005326	1411	14160																		
T6SPCT	006104	14070	14090	14000	15240	15200															
T61	005134	13750	1393	1413																	
T61Z	005156	1376	13820																		
T65	005220	1384	1387	13920																	
T65X	005250	1395	14010																		
T65Z	005300	1403	14090																		
T66	005370	14230	1439	1451	1453	1455	1526														
T66X	005412	1424	14300																		
T66Z	005434	1431	14370																		
T66Z1	005500	1442	14480																		
T66Z1X	005536	1449	14560																		
T60	006034	1511	15170																		
T60X	006070	1500	1520	1522	15240																
T60Z	006076	1510	15260																		
T69	005724	14920	1525																		
T69X	005746	1493	14990																		
T69Z	005770	1500	15060																		
T7	003550	1123	11330																		
T70	005566	1450	14640																		
T70X	005610	1465	14710																		
T71	005640	1473	14790																		
T72	005662	1480	14840																		
T72X	005710	1486	14890																		
T0	003506	1091	11230	1133																	
T9	003322	1004	10900	1149																	
WIDTH	001052	6420	806	910	962	992	1100	1200	1255	1302	1374	1422	1456	16450							

WORK	001044	1640*	1772	1795															
XHAM1	006166	6390	739*	750*	1145*	1146*	1656*	1658*	1663*										
XHAMIX	006174	1543	15490																
XLINF	002316	15510																	
XLPIX2	003700	911	9180																
XN	003716	1152	11500																
XBLW1	006332	1077	11630																
X81X	004030	1579	15030																
X71A	003402	1103	11090																
X66X	005104	1096	11020																
X80X	005346	1360	13710																
ZCOUNT	003730	1417	1419	14200															
Z80Z	005272	1080*	1082*	1146	11600														
.	007730	1079	10820																
		5590	5660	5690	5710	5730	5760	5800	5830	5950	901	927	1059	1062					
		1127	1159	1170	1243	1261	1307	1309	1345	1370	1400	1550	1555	1550					
		1564	1590	1627	1605	1711	1765	17600	1775	1790									

ERROR	6210	670	678	691	701	710	720	743	750	760	770	781	786	795	806
	810	846	853	861	880	891	906	922	960	970	996	1007	1020	1031	1053
	1085	1097	1104	1114	1130	1153	1184	1202	1211	1210	1225	1233	1260	1204	1316
	1323	1330	1330	1377	1380	1396	1404	1425	1432	1443	1459	1466	1474	1494	1501
	1512	1544	1580	1779											

ADD	1014	1146	1490	1604	1634	1665	1677	1682	1696	1732	1735				
BEQ	901	911	913	927	954	985	987	1037	1041	1043	1045	1050	1042	1079	1159
	1176	1194	1196	1240	1243	1259	1275	1270	1295	1297	1307	1349	1340	1360	1411
	1417	1449	1451	1482	1486	1510	1520	1530	1573	1590	1643	1704	1706	1700	1790
BIC	792	801	812	824	870	1039	1734	1773	1800						
BIS	790	799	810	822	859										
BIT	737	912	929	953	986	1061	1078	1150	1175	1195	1242	1250	1296	1306	1347
	1367	1416	1450	1481	1485	1519	1537	1562	1572	1595	1642	1709			
BMI	677	690	700	720	757	780	852	1103	1224	1329	1431	1465	1900	1660	1662
	1676														
BNE	730	759	915	930	975	989	1003	1027	1110	1120	1147	1149	1191	1190	1290
	1304	1393	1439	1453	1480	1500	1522	1525	1553	1561	1563	1586	1592	1590	1596
	1630	1633	1664	1701	1744	1785	1792	1802							
BPL	669	710	742	749	773	845	890	967	1019	1096	1127	1103	1217	1267	1300
	1376	1395	1424	1450	1493	1543	1550	1555	1550	1579	1584	1590	1627	1681	1685
	1711	1765	1775	1778	1790										
BR	653	674	682	695	705	723	733	747	754	764	770	785	850	857	865
	879	902	905	917	921	928	931	950	970	991	995	1006	1030	1046	1052
	1064	1081	1084	1113	1120	1132	1137	1152	1161	1170	1201	1210	1232	1241	1261
	1283	1301	1304	1309	1311	1315	1337	1370	1387	1403	1419	1442	1455	1473	1480
	1511	1540	1564	1575	1605	1657	1700	1717	1794	1803					
	1737	1739	1741												
CLC	739														
CLR	657	832	869	914	988	1040	1042	1044	1197	1290	1452	1521	1593	1791	1801
CMP	1700	1703	1705												
CMPB	1015														
COM	1143	1524	1743												
DEC	661	663	665	683	696	706	1760	1762							
EMT	566	667	685	690	708	804	895	972	1000	1011	1024	1035	1057	1089	1101
HALT	1118	1157	1180	1206	1215	1222	1229	1237	1272	1280	1320	1327	1334	1342	1381
	1400	1400	1429	1436	1447	1463	1470	1470	1490	1505	1516	1540	1766	1783	
INC	750	900	910	926	974	984	1001	1002	1016	1026	1036	1030	1050	1109	1119
	1140	1190	1193	1230	1239	1274	1276	1277	1294	1343	1344	1383	1392	1410	1430
	1440	1479	1507	1517	1552	1559	1585	1591	1629	1632	1663	1704	1707		
JMP	502	505	506	507	508	509	590	591	592	593	594	825	834	896	930
	983	1060	1063	1107	1122	1160	1244	1279	1280	1346	1349	1413	1483	1526	1603
JSR	673	681	694	704	722	732	746	753	763	777	784	833	849	856	864
	877	878	883	894	904	909	920	925	952	971	977	982	994	999	1005
	1010	1023	1029	1034	1051	1056	1076	1083	1080	1100	1112	1117	1136	1141	1151
	1156	1173	1187	1200	1205	1209	1214	1221	1220	1231	1236	1253	1271	1282	1307
	1314	1319	1326	1333	1336	1341	1366	1380	1386	1391	1399	1402	1407	1420	1435
	1441	1446	1462	1469	1472	1477	1497	1504	1510	1515	1547	1590	1707	1714	1716
	1756	1769	1782												
MOV	501	504	649	650	651	655	656	659	660	671	679	687	688	692	702
	720	730	740	744	751	761	770	771	775	782	787	789	796	798	807
	809	819	821	842	843	847	854	850	862	881	885	886	887	888	892
	897	898	899	903	907	916	918	919	923	936	937	955	956	957	959
	960	961	962	963	964	965	969	973	976	980	990	992	993	997	1004
	1000	1012	1013	1021	1025	1028	1032	1050	1054	1077	1080	1082	1086	1090	1091
	1092	1093	1094	1098	1103	1100	1111	1115	1121	1123	1124	1125	1131	1133	1134
	1135	1139	1144	1145	1150	1154	1174	1177	1179	1180	1181	1185	1189	1192	1199
	1203	1200	1212	1219	1226	1230	1234	1254	1255	1256	1257	1260	1262	1263	1264
	1265	1269	1273	1281	1285	1292	1293	1300	1302	1303	1305	1300	1310	1312	1313
	1317	1324	1331	1335	1339	1365	1369	1371	1372	1373	1374	1370	1382	1385	1389

	1397	1401	1405	1409	1412	1410	1420	1421	1422	1426	1433	1437	1440	1444	1454
	1456	1460	1467	1471	1475	1484	1487	1489	1495	1502	1506	1509	1513	1523	1536
	1539	1541	1545	1551	1556	1571	1574	1576	1577	1581	1587	1588	1597	1624	1629
	1631	1644	1645	1647	1648	1656	1658	1679	1695	1697	1720	1730	1731	1733	1770
	1771	1772	1776	1780	1786	1793	1795	1796	1799						
MOV8	1699	1789	1713	1715	1736										
NOP	791	808	811	823	868	1600	1601	1602							
RESET	648	716	726												
ROR	1730	1740	1742												
RTI	1702														
RTS	1620	1635	1646	1649	1666	1678	1683	1686	1712	1745	1767				
TST	692	668	689	699	717	748	772	844	889	966	1018	1095	1102	1216	1266
	1321	1375	1394	1423	1457	1492	1542	1578	1657	1764	1777				
TSTB	676	727	741	756	779	851	1102	1126	1223	1328	1430	1464	1499	1549	1554
	1557	1583	1589	1626	1661	1675	1688	1684	1710	1774	1797				
.ABCTI	1768														
.ENABL	529	530													
.END	1810														
.EVEN	1768														
.LIST	566	1760													
.MACR	621														
.NLIST	566	1768													
.PAGE	511														
.REPT	1	566													

ERRORS DETECTED: 0

*DZLPAB,DZLPAB_DZLPAB.SRC/CRF/SOL
 RUN-TIME: 0 15 2 SECONDS
 CORE USED: 12K