

## Table of contents

3-	1	WINCHR	-- Process next output character
4-	1	REGCHR	-- Process regular characters
5-	1	DOCTRL	-- Process control characters
6-	1	WCSCCHK	-- Check for start of control sequence
7-	1	WCPESC	-- Escape processing
8-	1	EPCH1	-- Accrue a terminal control sequence
10-	1	ACRCS	-- Store a character into control seq buffer
11-	1	CSFIN	-- Process received control sequence
13-	1	CSPARM	-- Extract parameter value from control string
14-	1	TCBS	-- Process backspace character
15-	1	TCHT	-- Process horizontal tab character
16-	1	TCCR	-- Process carriage return
17-	1	TCUP	-- Move cursor up specified number of lines
18-	1	TCDOWN	-- Move cursor down specified number of lines
19-	1	TCLF	-- Process Line Feed character
20-	1	TCESCE	-- Move to 1st column of next line
21-	1	TCIXUP	-- Index up one line
22-	1	TCRIT	-- Move cursor right specified number of chars
23-	1	TCLEFT	-- Move cursor left specified number of chars
24-	1	TCCADR	-- Do direct cursor addressing
25-	1	TCCPSV	-- Save current cursor position
25-	23	TCCPRS	-- Restore cursor position
26-	1	TCINSL	-- Insert lines
27-	1	TCDELL	-- Delete specified number of lines
28-	1	TCGOAS	-- Designate G0 as ascii character set
28-	11	TCGODS	-- Designate G0 as DEC supplemental character set
28-	21	TCGOUK	-- Designate G0 as UK national character set
28-	31	TCGOGR	-- Designate G0 as graphics character set
29-	1	TCG1AS	-- Designate G1 as ascii character set
29-	11	TCG1DS	-- Designate G1 as DEC supplemental character set
29-	21	TCG1UK	-- Designate G1 as UK national character set
29-	31	TCG1GR	-- Designate G1 as graphics character set
30-	1	TCG2AS	-- Designate G2 as ascii character set
30-	11	TCG2DS	-- Designate G2 as DEC supplemental character set
30-	21	TCG2GR	-- Designate G2 as graphics character set
31-	1	TCG3AS	-- Designate G3 as ascii character set
31-	11	TCG3DS	-- Designate G3 as DEC supplemental character set
31-	21	TCG3GR	-- Designate G3 as graphics character set
32-	1	TCSD	-- Shift-out character - Lock shift G1 to G1
32-	11	TCSI	-- Shift-in character - Lock shift G0 to G1
32-	21	TCLS2	-- Lock shift G2 to G1
32-	31	TCLS3	-- Lock shift G3 to G1
32-	41	TCLS1R	-- Lock shift G1 into GR
32-	51	TCLS2R	-- Lock shift G2 into GR
32-	61	TCLS3R	-- Lock shift G3 into GR
32-	71	TCSS2	-- Single shift G2 to G1
32-	82	TCSS3	-- Single shift G3 to G1
33-	1	TCSAA	-- Set ANSI attribute
33-	15	TCRAA	-- Reset ANSI attribute
33-	29	TCSDA	-- Set DEC attribute
33-	43	TCRDA	-- Reset DEC attribute
34-	1	TCSTA	-- Set terminal attribute
35-	1	TCRTA	-- Reset terminal attribute
36-	1	CVTTAV	-- Convert terminal attribute value to flag
37-	1	CKTAC	-- Check for complex mode changes
38-	1	TCAKM	-- Select application keypad mode
38-	11	TCNKM	-- Select numeric keypad mode

## Table of contents

39-	1	TCN3	-- Set line attributes
40-	1	TCSCA	-- Set character attributes
42-	1	TC100	-- Select VT100/VT200 mode
43-	1	TCREST	-- Terminal reset
44-	1	TCPRT	-- Printer control operation
45-	1	TCLERS	-- Erase within a line
46-	1	TCPERS	-- Erase within a page
47-	1	TCSSR	-- Set scrolling region
48-	1	SETHOM	-- Set cursor to the home position
49-	1	SCRUP	-- Scroll screen up one line
50-	1	SCRDN	-- Scroll screen down one line
51-	1	SCRCHK	-- Check for scrolling limits
52-	1	WINSPN	-- Suspend job until it reattaches to terminal
53-	1	ERSLIN	-- Erase the current line
54-	1	ERSCTL	-- Erase from cursor to the end of the line
55-	1	ERSLTC	-- Erase from beginning of line to cursor
56-	1	ERSCTP	-- Erase from cursor to the end of the page
57-	1	ERSPTC	-- Erase from beginning of page to cursor
58-	1	ERSPAC	-- Clear entire page to spaces
59-	1	CLRLIN	-- Clear a line to spaces
60-	1	CPYLIN	-- Copy characters from one line to another
61-	1	SETLAB	-- Set attributes for current line
62-	1	GETLAB	-- Get attributes for current line
63-	1	SETLIN	-- Select a line as current line
64-	1	WINSF	-- Switch from a job with a display window
65-	1	WINST	-- Switch to job with a window
66-	1	WINDSP	-- Redisplay current window for job
67-	1	REFRSH	-- Refresh screen from window contents
68-	1	SNDLIN	-- Send line of characters to terminal
69-	1	GENCLR	-- Gen control sequence to clear screen
70-	1	GENCAF	-- Generate sequence to set character attributes
71-	1	GENCSC	-- Generate terminal sequence to select char set
72-	1	GENMAP	-- Generate sequence to set up char set mapping
73-	1	GENSSS	-- Generate sequence for split screen scrolling
74-	1	GENTEM	-- Turn VT52 emulation mode on or off
75-	1	GENWAF	-- Generate terminal sequence to set window attrib
76-	1	GENAAS	-- Generate control sequence for ANSI attributes
77-	1	GENDAS	-- Generate control sequence for DEC attributes
78-	1	GENLAF	-- Generate terminal sequence to set line attrib
79-	1	GENSPC	-- Generate sequence to move cursor over
80-	1	GENCSR	-- Generate cursor addressing sequence
81-	1	GENESC	-- Generate escape character
81-	8	GENCSI	-- Generate CSI character sequence
81-	30	GENCHR	-- Send a character to the terminal
82-	1	GENVAL	-- Convert value to digits and send
83-	1	EMTWIN	-- Dispatch window control EMT's
84-	1	WFNEW	-- EMT to create a new window
85-	1	WFMAP	-- EMT to select a window as the current window
86-	1	WFDEL	-- EMT to delete a window
87-	1	WFSPND	-- Suspend window processing
87-	15	WFRSUM	-- Resume window processing
88-	1	WFPRT	-- Cause contents of a window to be printed
89-	1	WFREAD	-- Copy window information to program buffer
90-	1	WFSTT	-- EMT to set terminal type for windowing
91-	1	WINSTT	-- Set terminal type for a window
92-	1	WINREL	-- Release all display windows for a job
93-	1	WINDEL	-- Delete a window

Table of contents

94-	1	WINSRC	-- Locate control block for a window
95-	1	MAKWSB	-- Create named region for window screen buffer
96-	1	MAKRDB	-- Make a region definition block
97-	1	FREWSB	-- Free memory used by window screen buffer
98-	1	WININI	-- TSWIN initialization
99-	1	WINPRT	-- Window print-screen function

```

1          .TITLE  TSWIN -- TSX-Plus Display Windows
2          .ENABL  LC
3          .ENABL  AMA
4          .DSABL  GBL
5          .CSECT  TSWIN
6 000000    TSWIN: .RAD50  /WIN/          ;Overlay region id
7          ;
8          ; TSWIN is the TSX-Plus system overlay that provides display window support.
9          ;
10         ; Copyright (c) 1985.
11         ; S&H Computer Systems, Inc.
12         ; Nashville, Tennessee USA
13         ; All rights reserved.
14         ;
15         ; Global definitions
16         ;
17         .GLOBL  WINCHR, EMIWIN, WININI, WINREL, WINDSP
18         .GLOBL  WINST, WINSF, WINPRT
19         ;
20         ; Global references
21         ;
22         .GLOBL  LSW11, $V52EM, LNPRIM
23         .GLOBL  LSTSL, LPRC1, LPRC2, LBRKCG, NMFREQ, GETRTQ
24         .GLOBL  IOGSIZ, CQ#R1, QCOMPL, VALADW, VALADB
25         .GLOBL  P2#CXT, PRIVC2, $BBIT, LSW2, AW#PRT
26         .GLOBL  RC#EXC, RC#FLG, LOTSIZ, LOTSPC, LOTNXT, LOTPNT
27         .GLOBL  $CTRLD, LSW3, $RFRSH, LSW4, AW$SPN
28         .GLOBL  $WDISP, LSW6, $#OTWT, LSTATE, RC#BLK, RC#CNT
29         .GLOBL  $VNOTT, LSW, PCSPND, FRKPRI, FORCEX
30         .GLOBL  DW#CSB, DW#CSR, DW#CSP, TCSBSZ, LWINDO
31         .GLOBL  ESC, CSICHR, SS3CHR, AW$52, DW$AW, BUFCHR, AW$552
32         .GLOBL  KPAR6, VPAR6, OVRHC, INTPRI, PSW, PR7
33         .GLOBL  DW#CCA, DW#COL, DW#CPL, DW#LIN, DW#SRB
34         .GLOBL  DW#SRT, DW#LPP, DW#TLN, DW#LPT, DW#MAP
35         .GLOBL  DW#RID, DW#JOB, DW#ID, RC#BAS, R. GID
36         .GLOBL  R. GSIZ, R. GSTS, R. NAME, RS. CGR, RS. PVT
37         .GLOBL  RS. GBL, EMTBLK, SETERR, EMTXIT, RS. EGR
38         .GLOBL  DW##SZ, CR, LF, AC#BLD, AC#BLK, AC#REV
39         .GLOBL  CORUSR, AC#ULN, AL#DHT, AL#DHB, AL#DWD
40         .GLOBL  BUFCHR, VMXWIN, VT52, VT2007, VT2008, LTRMTP
41         .GLOBL  AW$200, AW$132, AW$INS, AW$ACK, AW$REV, AW$ORS
42         .GLOBL  AW$AKM, AW#VCR, LSW7, $SLON, $SLKED, LCOL
43         .GLOBL  AW#PRM, $DETC, LSW, LSW6, $WDISP, AW#RPT
44         .GLOBL  AW$SS, DW#CLS, DW#GLM, DW#GRM, AC#SET
45         .GLOBL  DW#MSL, DW#NSL, AW#DDC
46         .GLOBL  DW#GOM, DW#G1M, DW#G2M, DW#G3M
47         .GLOBL  DW#SLN, DW#SCL, DW#SCA, WINTOP

```

```

1 ;-----
2 ; Macro definitions
3 ;
4 ; Macros to enable and disable interrupts
5 ;
6 ; .MACRO DISABL ;Disable interrupts
7 BIS #PR7,@#PSW
8 .ENDM DISABL
9
10 ; .MACRO ENABL ;Enable interrupts
11 BIC INTPRI,@#PSW
12 .ENDM ENABL
13 ;
14 ; Macro to call a system overlay
15 ;
16 ; .MACRO OCALL ENTADD
17 ; IF B,ENTADD
18 ; ERROR ;OCALL without entry address
19 ; ENDC
20 CALL OVRHC
21 ; WORD ENTADD
22 ; ENDM OCALL
23 ;
24 ; Macros to map to screen buffer and restore mapping
25 ;
26 ; .MACRO BUFMAP
27 DISABL
28 MOV @#KPAR6,MAPHLD
29 MOV DW$MAP(R2),@#KPAR6
30 ; ENDM BUFMAP
31
32 ; .MACRO UNMAP
33 MOV MAPHLD,@#KPAR6
34 ENABL
35 ; ENDM UNMAP
36 ;
37 ; Macro to send a character to the terminal
38 ;
39 ; .MACRO SEND CHAR
40 MOVB CHAR,R0
41 CALL GENCHR
42 ; ENDM SEND
43 ;-----
44 ;
45 ; Data areas and parameters
46 ;
47 SEMI = 73 ; Semicolon
48 ;
49 DWBAS: .WORD WINTOP ; Pointer to 1st window control block
50 DWEND: .WORD 0 ; Pointer past last window control block
51 MAPHLD: .WORD 0 ; Temp cell used by BUFMAP/UNMAP macros
52 R5OWIN: .RAD50 /WIN/
53 R5OPRT: .RAD50 /PRT/
54 CSBUF: .BLKB 16. ; Cursor string work buffer
55 .EVEN

```

WINCHR -- Process next output character

```

1          .SBTTL  WINCHR -- Process next output character
2          ;-----
3          ; This routine is called to process each character sent to the terminal
4          ; by a running program.  It determines if the character is part of an
5          ; escape sequence or is a regular character.
6          ;
7          ; Inputs:
8          ;   R0 = Character being sent.
9          ;   R1 = Job index number.
10         ;
11         ; Outputs:
12         ;   C-flag set ==> Do not send this char to terminal now.
13         ;
14 000034 010046 WINCHR: MOV     R0,-(SP)
15 000036 010246         MOV     R2,-(SP)
16 000040 010546         MOV     R5,-(SP)
17 000042 010005         MOV     R0,R5          ;Carry character in R5
18         ;
19         ; Get pointer to current window control block for job
20         ;
21 000044 016102 0000000 MOV     LWINDO(R1),R2  ;Get pointer to window control block
22         ;
23         ; See if processing is suspended for this window
24         ;
25 000050 032762 0000000 0000000 BIT     #AW$SPN,DW$AW(R2); Is window processing suspended?
26 000056 001045         BNE     B$          ;Br if yes -- Just pass through the char
27         ;
28         ; Mask character to 7 bits unless 8 bit support has been enabled
29         ;
30 000060 032761 0000000 0000000 BIT     ##8BIT,LSW2(R1) ; Is 8 bit char support wanted?
31 000066 001002         BNE     1$          ;Br if yes
32 000070 042705 177600         BIC     #^C<177>,R5   ;Mask character to 7 bits
33         ;
34         ; Ignore nulls
35         ;
36 000074 105705 1$:      TSTB   R5          ; Is character null?
37 000076 001427         BEQ     7$          ; Br if null
38         ;
39         ; Determine if this character begins a terminal control sequence
40         ;
41 000100 004737 000510'     CALL    WCSCHK        ; Check for control sequence start
42 000104 103024         BCC     7$          ; Br if start of control sequence
43         ;
44         ; See if we are currently accepting a terminal control sequence
45         ;
46 000106 016200 0000000     MOV     DW$CSR(R2),R0  ; Are we processing a control sequence?
47 000112 001402         BEQ     3$          ; Br if not
48 000114 004710         CALL    (R0)         ; Call routine to process this character
49 000116 000417         BR     7$          ; Finished with this character
50         ;
51         ; If output is being directed to the terminal printer port, then
52         ; don't update window image with this character.
53         ;
54 000120 032762 0000000 0000000 3$:   BIT     #AW$PRT,DW$AW(R2); Is output going to printer?
55 000126 001013         BNE     7$          ; Br if yes -- Bypass window update
56         ;
57         ; Determine if this is a normal or control character

```

WINCHR -- Process next output character

```
58 ;
59 000130 010500          MOV     R5,R0          ;Get the character
60 000132 042700 177600   BIC     #^C<177>,R0     ;Mask to 7 bits
61 000136 020027 000037   CMP     R0,#37         ;Is this a control character?
62 000142 101003          BHI     4$             ;Br if not
63 000144 004737 000370'  CALL    DOCTRL         ;Process a control character
64 000150 000402          BR      7$             ;
65 ;
66 ; Process regular character
67 ;
68 000152 004737 000204'  4$:     CALL    REGCHR         ;Process a regular character
69 ;
70 ; See if we should display this character now
71 ;
72 000156 032762 000000G 000000G 7$:     BIT     #AW#DDC,DW$AW(R2);Should we suppress char display?
73 000164 001402          BEQ     8$             ;Br if not
74 ;
75 ; We don't want to display this character
76 ;
77 000166 000261          SEC                      ;Signal to not display the character
78 000170 000401          BR      9$             ;
79 ;
80 ; We want to display this character
81 ;
82 000172 000241          8$:     CLC                      ;Signal to display the character
83 ;
84 ; Finished
85 ;
86 000174 012605          9$:     MOV     (SP)+,R5
87 000176 012607          MOV     (SP)+,R2
88 000200 012600          MOV     (SP)+,R0
89 000202 000207          RETURN
```

```

1          .SBTTL  REGCHR -- Process regular characters
2          ;-----
3          ; Process regular characters which are stored into the appropriate
4          ; cell of the character matrix.
5          ;
6          ; Inputs:
7          ;   R2 = Pointer to window control block
8          ;   R5 = Character
9          ;
10         000204 010346 REGCHR: MOV     R3, -(SP)
11         000206 010546         MOV     R5, -(SP)
12         ;
13         ; Get pointer to 1st character on current line
14         ;
15         000210 016203 0000000 MOV     DW$LPT(R2), R3 ;Get pointer to 1st char on line
16         ;
17         ; Get pointer to current character on the line
18         ;
19         000214 016200 0000000 MOV     DW$COL(R2), R0 ;Get current column number
20         000220 005300         DEC     R0             ;1st column is # 1
21         000222 006300         ASL     R0             ;Two bytes used per column
22         000224 060003         ADD     R0, R3        ;Get pointer to char byte for current col
23         ;
24         ; Get number of character set for this character
25         ;
26         000226 116200 0000000 MOVB   DW$GRM(R2), R0 ;Assume character is in GR
27         000232 032705 000200   BIT     #200, R5      ;Is character in GR (8 bit character)
28         000236 001013         BNE    1$           ;Br if yes
29         000240 116200 0000000 MOVB   DW$GLM(R2), R0 ;Determine which set GL is mapped to
30         000244 032762 0000000 0000000 BIT     #AW$SS, DW$AW(R2);Are we single-shifting this character?
31         000252 001405         BEQ    1$           ;Br if not
32         000254 116200 0000000 MOVB   DW$GLS(R2), R0 ;Get single-shift mapping for char
33         000260 042762 0000000 0000000 BIC     #AW$SS, DW$AW(R2);Reset single-shift flag
34         000266 060200         1$: ADD     R2, R0      ;Add base address of window control block
35         000270 116000 0000000 MOVB   DW$GOM(R0), R0 ;Get char set for this character
36         000274 042705 177600   BIC     #^C<177>, R5 ;Mask character to 7 bits
37         ;
38         ; Get character attribute flags (bold, blinking, etc.)
39         ;
40         000300 156200 0000000 BISB   DW$CCA(R2), R0 ;Add character attribute flags
41         ;
42         ; Store character and attribute into that cell
43         ;
44         000304         BUFMAP ;;;Map to screen buffer
45         000326 110523 MOVB   R5, (R3)+ ;;;Store character
46         000330 110023 MOVB   R0, (R3)+ ;;;Store character attribute flags
47         000332         UNMAP ;Restore mapping
48         ;
49         ; Advance column number unless we are at the end of the line
50         ;
51         000346 026262 0000000 0000000 CMP     DW$COL(R2), DW$CPL(R2);Are we at the end of the line now?
52         000354 103002         BHIS  9$           ;Br if at end of the line now
53         000356 005262 0000000         INC     DW$COL(R2) ;Advance to next column
54         ;
55         ; Finished
56         ;
57         000362 012605 9$: MOV     (SP)+, R5

```



58 000364 012603  
59 000366 000207

MOV (SP)+,R3  
RETURN

```

1          .SBTTL DOCTRL -- Process control characters
2          ;-----
3          ; This routine is called when the character being output is a
4          ; control character (000 - 037).
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ; R5 = Character
9          ;
10         DOCTRL:
11         ;
12         ; Call processing routine for this character
13         ;
14         000370 010500          MOV     R5,R0          ;Get the character
15         000372 042700 177600  BIC     #^C<177>,R0    ;Mask to 7 bits
16         000376 006300          ASL     R0              ;Convert to word table index
17         000400 004770 000406' CALL    @CCRTN(R0)     ;Call appropriate processing routine
18         ;
19         ; Finished
20         ;
21         000404 000207          RETURN
22         ;-----
23         ;
24         ; Branch table for control character processing routines
25         ;
26         000406 000506' CCRTN: .WORD  CCEXIT          ; 000 - NUL
27         000410 000506'          .WORD  CCEXIT          ; 001 - SOH
28         000412 000506'          .WORD  CCEXIT          ; 002 - STX
29         000414 000506'          .WORD  CCEXIT          ; 003 - ETX
30         000416 000506'          .WORD  CCEXIT          ; 004 - EDT
31         000420 000506'          .WORD  CCEXIT          ; 005 - ENQ
32         000422 000506'          .WORD  CCEXIT          ; 006 - ACK
33         000424 000506'          .WORD  CCEXIT          ; 007 - BEL
34         000426 002230'          .WORD  TCBS          ; 010 - BS
35         000430 002246'          .WORD  TCHT          ; 011 - HT
36         000432 002454'          .WORD  TCLF          ; 012 - LF
37         000434 002454'          .WORD  TCLF          ; 013 - VT
38         000436 002454'          .WORD  TCLF          ; 014 - FF
39         000440 002306'          .WORD  TCCR          ; 015 - CR
40         000442 003516'          .WORD  TCSD          ; 016 - SD
41         000444 003526'          .WORD  TCSI          ; 017 - SI
42         000446 000506'          .WORD  CCEXIT          ; 020 - DLE
43         000450 000506'          .WORD  CCEXIT          ; 021 - DC1
44         000452 000506'          .WORD  CCEXIT          ; 022 - DC2
45         000454 000506'          .WORD  CCEXIT          ; 023 - DC3
46         000456 000506'          .WORD  CCEXIT          ; 024 - DC4
47         000460 000506'          .WORD  CCEXIT          ; 025 - NAK
48         000462 000506'          .WORD  CCEXIT          ; 026 - SYN
49         000464 000506'          .WORD  CCEXIT          ; 027 - ETB
50         000466 000506'          .WORD  CCEXIT          ; 030 - CAN
51         000470 000506'          .WORD  CCEXIT          ; 031 - EM
52         000472 000204'          .WORD  REGCHR         ; 032 - SUB (ctrl-Z)
53         000474 000506'          .WORD  CCEXIT          ; 033 - ESC
54         000476 000506'          .WORD  CCEXIT          ; 034 - FS
55         000500 000506'          .WORD  CCEXIT          ; 035 - GS
56         000502 000506'          .WORD  CCEXIT          ; 036 - RS
57         000504 000506'          .WORD  CCEXIT          ; 037 - US

```

```
58 ;  
59 ; Immediate return for most control characters  
60 ;  
61 000506 000207 CCEXIT: RETURN
```

```
1          .SBTTL  WCSCHK -- Check for start of control sequence
2          ;-----
3          ; This routine is called to determine if the current character begins
4          ; a terminal control sequence.
5          ;
6          ; Inputs:
7          ; R2 = Window control block.
8          ; R5 = Current character
9          ;
10         ; Outputs:
11         ; C-flag cleared ==> Start of control sequence
12         ; C-flag set    ==> Not start of control sequence
13         ;
14 000510   WCSCHK:
15         ;
16         ; See if this is the start of an escape sequence
17         ;
18 000510   120527 0000000   CMPB    R5,#ESC      ;Is this character escape?
19 000514   001003                BNE     1$          ;Br if not
20 000516   004737 000546'   CALL    WCPESC     ;Begin escape sequence
21 000522   000405                BR     8$          ;
22         ;
23         ; See if this character is CSI, beginning of VT200 control sequence
24         ;
25 000524   120527 0000000   1$:    CMPB    R5,#CSICHR  ;CSI character?
26 000530   001004                BNE     7$          ;Br if not
27 000532   004737 000600'   CALL    WPCSI     ;Start VT200 control sequence
28         ;
29         ; We began a control sequence
30         ;
31 000536   000241                8$:    CLC          ;Signal control sequence began
32 000540   000401                BR     9$          ;
33         ;
34         ; We did not begin a control sequence
35         ;
36 000542   000261                7$:    SEC          ;Signal that not control sequence
37         ;
38         ; Finished
39         ;
40 000544   000207                9$:    RETURN
```

WCPESC -- Escape processing

```

1          .SBTTL  WCPESC -- Escape processing
2          ;-----
3          ; Process an Escape character
4          ;
5          ; Inputs:
6          ;   R2 = Window control block
7          ;   R5 = Escape character
8          ;
9 000546   WCPESC:
10         ;
11         ; Initialize control sequence buffer pointer
12         ;
13 000546   005062   0000000   CLR      DW#CSP(R2)      ; Say no chars accrued yet
14         ;
15         ; Set address of routine to be called to process 1st character after
16         ; escape.
17         ;
18 000552   012700   000624'   MOV      #EPCH1,R0      ; Routine for 1st character after escape
19 000556   032762   0000000 0000000   BIT      #<AW$52!AW$552>,DW#AW(R2); Is terminal in VT52 emulation mode?
20 000564   001402   BEQ      1$             ; Br if not
21 000566   012700   000710'   MOV      #EP52,R0      ; Set routine for VT52 mode
22 000572   010062   0000000   1$:     MOV      R0,DW#CSR(R2) ; Set address of processing routine
23 000576   000207   RETURN
24
25         ;-----
26         ; Received a CSI control character for a VT200 terminal.
27         ;
28         ; Inputs:
29         ;   R2 = Window control block address
30         ;
31 000600   012762   000624' 0000000   WCPCSI: MOV      #EPCH1,DW#CSR(R2) ; Set address of routine for next char
32 000606   005062   0000000   CLR      DW#CSP(R2)      ; Say no chars accrued yet
33 000612   112700   000133   MOVB    #'I,R0          ; Treat CSI char like ESC I
34 000616   004737   001136'   CALL    ACRC5           ; Store "I" as 1st char of sequence
35 000622   000207   RETURN

```

EPCH1 -- Accrue a terminal control sequence

```

1          .SBTTL  EPCH1  -- Accrue a terminal control sequence
2          ;-----
3          ; EPCH1 is called to accrue a VT100 or VT200 control sequence.
4          ;
5          ; There are two types of "control" sequences:
6          ;
7          ; Escape sequence format:  ESC I...I F
8          ;     I = Intermediate character in the range 040 to 057
9          ;     F = Final character in the range 060 to 176
10         ;
11         ; Control sequence format:  ESC P...P I...I F
12         ;     CSI = CSI character or ESC [
13         ;     P   = Parameter values in the range 060 to 077
14         ;     I   = Intermediate characters in the range 040 to 057
15         ;     F   = Final character in the range 100 to 176
16         ;
17         ; Inputs:
18         ;     R2 = Address of window control block.
19         ;     R5 = Received character
20         ;
21 000624 010546 EPCH1:  MOV     R5, -(SP)
22 000626 042705 177600      BIC     #^C<177>, R5      ;Mask character to 7 bits
23         ;
24         ; Add received character to end of control sequence already received
25         ;
26 000632 010500      MOV     R5, R0      ;Get received character
27 000634 004737 001136'    CALL    ACRC5      ;Store into control sequence buffer
28         ;
29         ; Determine if this character terminates the control sequence
30         ;
31 000640 120527 000060      CMPB   R5, #60      ;Is this the terminating character?
32 000644 103417      BLD     9$      ;Br if not
33 000646 120527 000176      CMPB   R5, #176     ;Is this the terminating character?
34 000652 101014      BHI     9$      ;Br if not
35 000654 120527 000133      CMPB   R5, #'[     ;Is this part of string header?
36 000660 001411      BEQ     9$      ;Br if string header
37 000662 120527 000100      CMPB   R5, #100    ;100 to 176 always terminates
38 000666 103004      BHIS   1$      ;
39 000670 126227 0000000 000133  CMPB   DW$CSB(R2), #'[ ;Is this an escape or control sequence?
40 000676 001402      BEQ     9$      ;Br if control sequence. Only 100-176 term
41         ;
42         ; This is the final character of the control sequence
43         ;
44 000700 004737 001174'    1$:    CALL    CSFIN      ;End of control sequence
45         ;
46         ; Finished
47         ;
48 000704 012605      9$:    MOV     (SP)+, R5
49 000706 000207      RETURN

```

EPCH1 -- Accrue a terminal control sequence

```

1      ;-----
2      ; Accrue VT52 control sequences.
3      ; All VT52 control sequences consist of ESC followed by a single character
4      ; except for the cursor addressing sequence ESC Y line col.
5      ; The VT52 sequences are converted to VT52 compatible sequences.
6      ;
7      ; Inputs:
8      ; R2 = Address of window control block
9      ; R5 = Received character
10     ;
11     000710 010546 EP52:  MOV    R5, -(SP)
12     000712 042705 177600      BIC    #^C<177>, R5      ;Mask character to 7 bits
13     ;
14     ; If this character is a letter, insert "[" in front of it.
15     ;
16     000716 120527 000101      CMPB   R5, #'A          ;Letter
17     000722 103416              BLO    2$              ;Br if not
18     000724 120527 000132      CMPB   R5, #'Z          ;Letter
19     000730 101013              BHI    2$              ;Br if not
20     000732 012700 000133      MOV    #'[, R0         ;Store "["
21     000736 004737 001136'     CALL   ACRC5
22     ;
23     ; Determine if this is the cursor addressing function
24     ;
25     000742 120527 000131      CMPB   R5, #'Y          ;Cursor addressing function?
26     000746 001004              BNE    2$              ;Br if not
27     000750 012762 000776' 000000G MOV    #EP52L, DW$CSR(R2); Set routine to process next char
28     000756 000405              BR     9$
29     ;
30     ; This character terminates the control sequence.
31     ;
32     000760 010500 2$:      MOV    R5, R0          ;Get received character
33     000762 004737 001136'     CALL   ACRC5          ;Add to string we are accruing
34     000766 004737 001174'     CALL   CSFIN         ;This terminates the control sequence
35     ;
36     ; Finished
37     ;
38     000772 012605 9$:      MOV    (SP)+, R5
39     000774 000207              RETURN
40     ;-----
41     ;
42     ; Accept the character which represents the line number in a VT52
43     ; cursor addressing sequence.
44     ;
45     ; Inputs:
46     ; R2 = Address of window control block
47     ; R5 = Received character (whose binary value is line number + 037)
48     ;
49     000776 042705 177600 EP52L: BIC    #^C<177>, R5      ;Mask character to 7 bits
50     001002 120527 000070      CMPB   R5, #70         ;Octal 70 ==> Remain on current line
51     001006 103404              BLO    1$              ;Br if new line specified
52     001010 016205 000000G     MOV    DW$LIN(R2), R5  ;Get current line number
53     001014 062705 000037      ADD    #37, R5         ;Convert to ascii character
54     001020 004737 001066'     1$:   CALL   CV52          ;Convert char to digit string
55     001024 112700 000073      MOVB   #SEMI, R0       ;Get parameter separator character
56     001030 004737 001136'     CALL   ACRC5          ;Store after line number value
57     001034 012762 001044' 000000G MOV    #EP52C, DW$CSR(R2); Set routine to process column number char

```

EPCH1 -- Accrue a terminal control sequence

```

58 001042 000207                RETURN
59
60
61 ; -----
62 ; Accept the character which represents the column number in a VT52
63 ; cursor addressing sequence.
64 ;
65 ; Inputs:
66 ; R2 = Address of window control block
67 ; R5 = Received character (whose binary value is column number + 037)
68 001044 004737 001066' EP52C: CALL CV52 ;Convert char to digit string
69 001050 112700 000110      MOV  #'H,R0 ;Store terminating character
70 001054 004737 001136'      CALL ACRC ;
71 001060 004737 001174'      CALL CSFIN ;This terminates the control sequence
72 001064 000207                RETURN
73
74 ; -----
75 ; Convert a received character whose binary value represents a line
76 ; number or a column number in a VT52 cursor addressing sequence
77 ; into an ascii digit string and store into the accrued control
78 ; sequence.
79 ;
80 ; Inputs:
81 ; R2 = Address of window control block
82 ; R5 = Received character whose binary value - 37 is the stored result
83 ;
84 001066 010446 CV52: MOV R4,-(SP)
85 001070 010546      MOV R5,-(SP)
86 ;
87 ; Subtract bias of 37
88 ;
89 001072 162705 000037      SUB #37,R5 ;Remove bias from character value
90 ;
91 ; Convert to digit string
92 ;
93 001076 005004      CLR R4 ;Clear high-order for divide
94 001100 071427 000012      DIV #10.,R4 ;Split into two decimal digits
95 001104 062704 000060      ADD #'0,R4 ;Form high-order ascii digit
96 001110 010400      MOV R4,R0 ;Get the character
97 001112 004737 001136'      CALL ACRC ;Store into control string
98 001116 062705 000060      ADD #'0,R5 ;Form low-order ascii digit
99 001122 010500      MOV R5,R0 ;Get the character
100 001124 004737 001136'      CALL ACRC ;Store into control string
101 ;
102 ; Finished
103 ;
104 001130 012605      MOV (SP)+,R5
105 001132 012604      MOV (SP)+,R4
106 001134 000207                RETURN

```



ACRCS -- Store a character into control seq buffer

```

1          .SBTTL  ACRCS  -- Store a character into control seq buffer
2          ;-----
3          ; This routine is called to add another character to the end of the
4          ; accrued control sequence in the DW$CSB buffer area.
5          ;
6          ; Inputs:
7          ; R0 = Character to be added to end of string
8          ; R2 = Address of window descriptor block
9          ;
10         ACRCS:  MOV     R3, -(SP)
11         001136 010346      BIC     #^C<177>, R0      ;Mask character to 7 bits
12         001140 042700 177600
13         ; Make sure we don't overflow the control sequence buffer
14         ;
15         001144 016203 0000000      MOV     DW$CSP(R2), R3      ;Get # chars in buffer now
16         001150 020327 1777770      CMP     R3, #TCSBSZ-1      ;Is buffer full already?
17         001154 103005      BHIS    9$      ;Br if yes -- Ignore this character
18         ;
19         ; Store character into buffer
20         ;
21         001156 060203      ADD     R2, R3      ;Point to next char pos in buffer
22         001160 110063 0000000      MOVB   R0, DW$CSB(R3)      ;Store char into buffer
23         001164 005262 0000000      INC     DW$CSP(R2)      ;Increment character count
24         ;
25         ; Finished
26         ;
27         001170 012603      9$:    MOV     (SP)+, R3
28         001172 000207      RETURN

```

CSFIN -- Process received control sequence

```

1          .SBTTL  CSFIN  -- Process received control sequence
2          ;-----
3          ; We have finished accruing a control sequence, process it.
4          ;
5          ; Inputs:
6          ; R2 = Address of window control block.
7          ;
8 001174 010346 CSFIN:  MOV    R3,-(SP)
9 001176 010446      MOV    R4,-(SP)
10 001200 010546      MOV    R5,-(SP)
11          ;
12          ; Store null at end of control sequence string
13          ;
14 001202 010203      MOV    R2,R3          ;Get address of window control block
15 001204 066203 0000000 ADD    DW$CSP(R2),R3 ;Point to next char pos in buffer
16 001210 105063 0000000 CLRB  DW$CSB(R3)      ;Store null at end of string
17          ;
18          ; Move control sequence to work buffer and remove any parameter characters
19          ;
20 001214 012705 000014' MOV    #CSBUF,R5      ;Point to work buffer
21 001220 010203      MOV    R2,R3          ;Get address of buffer with full string
22 001222 062703 0000000 ADD    #DW$CSB,R3
23 001226 121327 000133  CMPB  (R3),#'E        ;Do we need to exclude parameter values?
24 001232 001014      BNE   3$             ;Br if not
25          ;
26          ; This is a control sequence. Ignore parameter value characters in the
27          ; range 060 to 076.
28          ;
29 001234 112300 1$:   MOVB  (R3)+,R0      ;Get next char from input string
30 001236 001410      BEQ   4$             ;Br if hit end of string
31 001240 120027 000060  CMPB  R0,#060        ;Is this a parameter character?
32 001244 103403      BLO   2$             ;Br if not
33 001246 120027 000076  CMPB  R0,#076        ;Parameter character?
34 001252 101770      BLOS  1$             ;Br if parameter character
35 001254 110025 2$:   MOVB  R0,(R5)+      ;Store char into work buffer
36 001256 000766      BR    1$             ;Keep moving
37 001260 105025 4$:   CLRB  (R5)+      ;Store null at end of string
38 001262 000402      BR    5$
39          ;
40          ; This is an escape sequence. We don't have to remove parameter values.
41          ;
42 001264 112325 3$:   MOVB  (R3)+,(R5)+      ;Move char to work buffer
43 001266 001376      BNE   3$             ;Loop till null moved
44          ;
45          ; The control sequence is now in the work buffer (CSBUF) with any parameter
46          ; value strings removed.
47          ; Begin loop to try to identify the control sequence.
48          ;
49 001270 012704 001432' 5$:   MOV    #CSTBLL,R4      ;Point to 1st set of control sequences
50 001274 126527 177776 000140  CMPB  -2(R5),#140    ;Is final char of sequence less than 140?
51 001302 103002      BHIS  10$            ;Br if not
52 001304 012704 001560'  MOV    #CSTBLU,R4      ;Point to control seq table for final < 140
53          ;
54          ; Compare accrued control sequence with sequence stored in table
55          ;
56 001310 012703 000014' 10$:  MOV    #CSBUF,R3      ;Point to accrued control sequence
57 001314 122324 12$:  CMPB  (R3)+,(R4)+      ;Compare the strings

```

CSFIN -- Process received control sequence

```

58 001316 001004          BNE      13$      ;Br if mismatch
59 001320 105764 177777   TSTB    -1(R4)    ;Was that the end of both strings?
60 001324 001373          BNE      12$      ;Br if not
61 001326 000412          BR       14$      ;We have a match
62                          ;
63                          ; Strings do not match --- Move on to next table entry
64                          ;
65 001330 005304          13$:    DEC      R4          ;Point to last char compared in table
66 001332 105724          15$:    TSTB    (R4)+      ;Search for null at end of asciz string
67 001334 001376          BNE      15$      ;Loop till null found
68 001336 062704 000003   ADD     #3,R4     ;Bound up and skip over following word
69 001342 042704 000001   BIC     #1,R4     ;Get to word boundary
70 001346 005714          TST     (R4)      ;Reached end of table?
71 001350 001357          BNE      10$      ;Loop if not
72 001352 000417          BR       20$      ;Control sequence is not in our table
73                          ;
74                          ; We found the control sequence in our table.
75                          ; Call processing routine.
76                          ; Set R5 to point to start of any possible parameter string in control seq.
77                          ;
78 001354 010205          14$:    MOV     R2,R5      ;Point to window control block
79 001356 062705 0000010  ADD     #DW$CSB+1,R5 ;Point to start of possible parameter string
80 001362 005204          INC     R4         ;Bound up to next word
81 001364 042704 000001   BIC     #1,R4     ;Get to word boundary
82 001370 011404          MOV     (R4),R4   ;Get address of routine to call
83 001372 032762 0000000 0000000  BIT     #AW$PRT,DW$AW(R2);Are we directing output to printer port?
84 001400 001403          BEQ     16$      ;Br if not
85 001402 020427 004666'  CMP     R4,#TCPRT ;Is this printer control operation?
86 001406 001001          BNE      20$      ;Br if not -- Ignore till printer turned off
87 001410 004714          16$:    CALL    (R4)    ;Call processing routine
88                          ;
89                          ; Finished with control sequence
90                          ;
91 001412 005062 0000000  20$:    CLR     DW$CSP(R2) ;No accrued chars in control sequence
92 001416 005062 0000000  CLR     DW$CSR(R2) ;Not accruing a control sequence now
93 001422 012605          MOV     (SP)+,R5
94 001424 012604          MOV     (SP)+,R4
95 001426 012603          MOV     (SP)+,R3
96 001430 000207          RETURN

```

CSFIN -- Process received control sequence

```

1      ;-----
2      ; Generate table of terminal control sequences and associated processing
3      ; routines.
4      ;
5      .MACRO ESCSEQ STRING,RTN
6      .ASCIZ /STRING/
7      .EVEN
8      .WORD RTN
9      .ENDM ESCSEQ
10     ;
11     ; Table for control sequences whose final character is in the
12     ; range 140 to 177
13     ;
14     001432 CSTBLL:
15     001432 ESCSEQ <[f>,TCCADR ;Cursor addressing
16     001440 ESCSEQ <[p>,TC100 ;Select VT100/VT200 mode
17     001446 ESCSEQ <[h>,TCSAA ;Set ANSI terminal attribute
18     001454 ESCSEQ <[l>,TCRAA ;Reset ANSI terminal attribute
19     001462 ESCSEQ <[?h>,TCSDA ;Set DEC terminal attribute
20     001470 ESCSEQ <[?l>,TCRDA ;Reset DEC terminal attribute
21     001476 ESCSEQ <[i>,TCPRT ;Printer control code
22     001504 ESCSEQ <[m>,TCSCA ;Set character attribute
23     001512 ESCSEQ <[r>,TCSSR ;Set scrolling region
24     001520 ESCSEQ <[!p>,TCREGY ;Soft reset
25     001526 ESCSEQ <[c>,TCREST ;Hard reset
26     001532 ESCSEQ <[~>,TCLSR ;Lock shift G1 as GR character set
27     001536 ESCSEQ <[n>,TCLSR2 ;Lock shift G2 as GL character set
28     001542 ESCSEQ <[o>,TCLSR3 ;Lock shift G3 as GL character set
29     001546 ESCSEQ <[>>,TCLSR2 ;Lock shift G2 as GR character set
30     001552 ESCSEQ <[!>,TCLSR3 ;Lock shift G3 as GR character set
31     001556 000000 .WORD 0 ;End of table
32     ;
33     ; Table for control sequences whose final character is in the
34     ; range 60 to 137
35     ;
36     001560 CSTBLU:
37     001560 ESCSEQ <[A>,TCUP ;Move cursor up
38     001566 ESCSEQ <[B>,TCDOWN ;Move cursor down
39     001574 ESCSEQ <[C>,TCRIT ;Move cursor right
40     001602 ESCSEQ <[D>,TCLEFT ;Move cursor left
41     001610 ESCSEQ <[F>,TCGODS ;Select graphic char set for VT52
42     001616 ESCSEQ <[G>,TCGOAS ;Select normal char set for VT52
43     001624 ESCSEQ <[H>,TCCADR ;Cursor addressing
44     001632 ESCSEQ <[I>,TCIXUP ;Reverse index (VT52)
45     001640 ESCSEQ <[J>,TCPERS ;Erase within a page
46     001646 ESCSEQ <[K>,TCLERS ;Erase within a line
47     001654 ESCSEQ <[L>,TCINSL ;Insert lines
48     001662 ESCSEQ <[M>,TCDELL ;Delete lines
49     001670 ESCSEQ <[D>,TCLF ;Index (Move cursor down one line)
50     001674 ESCSEQ <[E>,TCESCE ;Move to 1st column of next line
51     001700 ESCSEQ <[M>,TCIXUP ;Reverse index (move up 1 line)
52     001704 ESCSEQ <[N>,TCSS2 ;Single shift next char to G2
53     001710 ESCSEQ <[O>,TCSS3 ;Single shift next char to G3
54     001714 ESCSEQ <[A>,TCGOUK ;Designate G0 as UK
55     001722 ESCSEQ <[B>,TCGOAS ;Designate G0 as ascii
56     001730 ESCSEQ <[O>,TCGOGR ;Designate G0 as graphics
57     001736 ESCSEQ <[A>,TCG1AS ;Designate G1 as UK

```

CSFIN -- Process received control sequence

58	001744			ESCSEQ	<B>,TCG1AS	;Designate G1 as ascii
59	001752			ESCSEQ	<O>,TCG1GR	;Designate G1 as graphics
60	001760			ESCSEQ	<*B>,TCG2AS	;Designate G2 as ascii
61	001766			ESCSEQ	<*O>,TCG2GR	;Designate G2 as graphics
62	001774			ESCSEQ	<+B>,TCG3AS	;Designate G3 as ascii
63	002002			ESCSEQ	<+O>,TCG3GR	;Designate G3 as graphics
64	002010			ESCSEQ	<#3>,TCN3	;Line is top half of double-high line
65	002016			ESCSEQ	<#4>,TCN4	;Line is bottom half of double high
66	002024			ESCSEQ	<#5>,TCN5	;Line is single width
67	002032			ESCSEQ	<#6>,TCN6	;Line is double width
68	002040			ESCSEQ	<7>,TCCPSV	;Save cursor position
69	002044			ESCSEQ	<8>,TCCPRG	;Restore cursor position
70	002050			ESCSEQ	<=>,TCAKM	;Select application keypad mode
71	002054	050	074	.ASCIZ	/(</>74>	; "<"
72				.EVEN		
73	002060	003354'		.WORD	TCG0DS	;Designate G0 as DEC supplemental graphics
74	002062	051	074	.ASCIZ	/)/<74>	; ">"
75				.EVEN		
76	002066	003412'		.WORD	TCG1DS	;Designate G1 as DEC supplemental graphics
77	002070	057	074	.ASCIZ	/*/<74>	; "*<"
78				.EVEN		
79	002074	003450'		.WORD	TCG2DS	;Designate G2 as DEC supplemental graphics
80	002076	053	074	.ASCIZ	/+</>74>	; "+<"
81				.EVEN		
82	002102	003476'		.WORD	TCG3DS	;Designate G3 as DEC supplemental graphics
83	002104	074	000	.ASCIZ	<74>	;Select ANSI mode with "<" character
84	002106	004466'		.WORD	TC100	;Select ANSI mode
85	002110	076	000	.ASCIZ	<76>	;Generate entry with ">" character
86	002112	004232'		.WORD	TCNKM	;Select numeric keypad mode
87	002114	000000		.WORD	0	;End of table

```

1          .SBTTL  CSPARM -- Extract parameter value from control string
2          ;-----
3          ; CSPARM obtains the next parameter value from the control string.
4          ; If there is no parameter value, 0 is returned as the value.
5          ; Non-parameter characters are skipped over.
6          ;
7          ; Inputs:
8          ; R5 = Pointer into control string where parameter may start.
9          ;
10         ; Outputs:
11         ; C-flag set ==> No more parameter values.
12         ; R0 = Accrued parameter value.
13         ; R5 = Points past end of parameter value.
14         ;
15 002116 010146 CSPARM: MOV     R1, -(SP)
16 002120 005001      CLR     R1          ;Accrue the value in R1
17         ;
18         ; Scan up to the start of a parameter value
19         ;
20 002122 112500 1$:      MOVB   (R5)+, R0      ;Get next char from control seq
21 002124 001430      BEQ     5$          ;Br if hit end of the string
22 002126 120027 000073  CMPB   R0, #SEMI      ;Semicolon is value separator
23 002132 001432      BEQ     7$          ;Br if no value specified for this param
24 002134 120027 000071  CMPB   R0, #'9        ;Is this a parameter character?
25 002140 101370      BHI     1$          ;Br if not
26 002142 120027 000060  CMPB   R0, #'0        ;
27 002146 103765      BLO     1$          ;Br if not digit
28         ;
29         ; We found the start of a parameter value.  Accrue it.
30         ;
31 002150 000412      BR      4$          ;Enter loop in middle
32 002152 112500 3$:      MOVB   (R5)+, R0      ;Get next char of parameter
33 002154 001420      BEQ     2$          ;Br if hit null at end of string
34 002156 120027 000071  CMPB   R0, #'9        ;Is this char part of parameter?
35 002162 101016      BHI     7$          ;Br if not
36 002164 120027 000060  CMPB   R0, #'0        ;
37 002170 103413      BLO     7$          ;Br if not
38 002172 070127 000012  MUL    #10., R1      ;Multiply previous value by 10.
39 002176 162700 000060 4$:      SUB    #'0, R0      ;Convert ascii digit to binary value
40 002202 060001      ADD    R0, R1      ;Add into previous value
41 002204 000762      BR      3$          ;Keep accruing
42         ;
43         ; There are no more parameter values
44         ;
45 002206 005305 5$:      DEC    R5          ;Point to string terminator
46 002210 005000      CLR    R0          ;Return 0 as "value"
47 002212 000261      SEC          ;Signal that there are no more parameters
48 002214 000403      BR      9$
49         ;
50         ; Finished getting the parameter value
51         ;
52 002216 005305 2$:      DEC    R5          ;Point to parameter terminator
53 002220 010100 7$:      MOV    R1, R0      ;Get accrued value
54 002222 000241      CLC          ;Signal success on return
55         ;
56         ; Finished
57         ;

```

58	002224	012601	7%:	MOV	(SP)+, R1
59	002226	000207		RETURN	

TCBS -- Process backspace character

```

1          .SBTTL  TCBS  -- Process backspace character
2          ;-----
3          ; Process a backspace character.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ;
8 002230   TCBS:
9          ;
10         ; Set column number back one unless we are already at column one
11         ;
12 002230   026227 0000000 000001      CMP     DW$COL(R2),#1  ;Are we already at column 1?
13 002236   001402      BEQ     9$      ;Br if yes
14 002240   005362 0000000      DEC     DW$COL(R2)    ;Move column number back one
15         ;
16         ; Finished
17         ;
18 002244   000207      9$:  RETURN

```



TCHT --- Process horizontal tab character

```

1          .SBTTL  TCHT  --- Process horizontal tab character
2          ;-----
3          ; Process horizontal tab character.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ;
8 002246   TCHT:
9          ;
10         ; Get current column number and advance to next multiple of 8
11         ;
12 002246   016200   0000000   MOV     DW$COL(R2),R0   ;Get current column number
13 002252   005300   DEC     R0           ;Make 1st column be # 0
14 002254   062700   000010   ADD     #8.,R0        ;Advance to next tab stop
15 002260   042700   000007   BIC    #7,R0         ;Bound to next multiple of 8
16 002264   005200   INC     R0           ;Make 1st column be # 1
17         ;
18         ; Make sure we don't go beyond end of line
19         ;
20 002266   020062   0000000   CMP    R0,DW$CPL(R2) ;Compare with # columns per line
21 002272   101402   BLOS   1$           ;Br if within line
22 002274   016200   0000000   MOV    DW$CPL(R2),R0 ;Force to end of line
23 002300   010062   0000000 1$: MOV    R0,DW$COL(R2) ;Set new column number
24         ;
25         ; Finished
26         ;
27 002304   000207   RETURN

```

TCCR -- Process carriage return

```
1 .SBTTL TCCR -- Process carriage return
2 ;-----
3 ; Process carriage return, move to 1st char of current line.
4 ;
5 ; Inputs:
6 ; R2 = Pointer to window control block.
7 ;
8 002306 012762 000001 0000006 TCCR: MOV #1,DW#COL(R2) ; Say current column = 1
9 ;
10 ; Finished
11 ;
12 002314 000207 RETURN
```

TCUP --- Move cursor up specified number of lines

```

1          .SBTTL  TCUP  -- Move cursor up specified number of lines
2          ;-----
3          ; Move the cursor up the page the specified number of lines.
4          ; Do not scroll if we reach the bottom of the page.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ; R5 = Pointer to parameter value in control sequence
9          ;
10         TCUP:
11         ;
12         ; Get count of number of lines to move up
13         ;
14         002316 004737 002116'          CALL  CSPARM          ;Accrue parameter value
15         002322 005700                  TST    R0            ;Was specified value 0?
16         002324 001001                  BNE    1$            ;Br if not
17         002326 005200                  INC    R0            ;Treat 0 like 1
18         ;
19         ; Move up specified number of lines
20         ;
21         002330 005400          1$:     NEG    R0            ;Get negative number of lines to move
22         002332 066200 00000000        ADD    DW$LIN(R2),R0 ;Compute new line
23         002336 003002                  BGT    2$            ;Br if didn't go past top of page
24         002340 012700 000001          MOV    #1,R0         ;Constrain to top of page
25         002344 026262 0000000 0000000 2$:  CMP    DW$LIN(R2),DW$SRT(R2);Were we already above top of scroll rgn?
26         002352 103405                  BLO    3$            ;Br if yes -- Don't constrain
27         002354 020062 00000000        CMP    R0,DW$SRT(R2) ;Would this put us above top of scroll regn?
28         002360 103002                  BHIS   3$            ;Br if not
29         002362 016200 00000000        MOV    DW$SRT(R2),R0 ;Constrain to top of scroll region
30         002366 004737 006702'          3$:     CALL  SETLIN          ;Set new line for cursor
31         ;
32         ; Finished
33         ;
34         002372 000207          RETURN

```

TCDOWN -- Move cursor down specified number of lines

```

1          .SBTTL  TCDOWN -- Move cursor down specified number of lines
2          ;-----
3          ; Move the cursor down the page the specified number of lines.
4          ; Do not scroll if we reach the bottom of the page.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ; R5 = Pointer to parameter value in control sequence
9          ;
10         002374 TCDOWN:
11         ;
12         ; Get count of number of lines to move down
13         ;
14         002374 004737 002116'          CALL  CSPARM          ;Accrue parameter value
15         002400 005700          TST    RO          ;Was specified value 0?
16         002402 001001          BNE   1$          ;Br if not
17         002404 005200          INC    RO          ;Treat 0 like 1
18         ;
19         ; Move down specified number of lines
20         ;
21         002406 066200 0000000 1$:  ADD    DW$LIN(R2),RO  ;Compute new line
22         002412 020062 0000000      CMP    RO,DW$LPP(R2)  ;Would this go past end of page?
23         002416 101402          BLOS  3$          ;Br if not
24         002420 016200 0000000      MOV    DW$LPP(R2),RO  ;Constrain to bottom of page
25         ;
26         ; If we are currently with the scroll region, don't move out
27         ;
28         002424 026262 0000000 0000000 3$:  CMP    DW$LIN(R2),DW$SRB(R2);Were we already past end of scroll?
29         002432 101005          BHI   2$          ;Br if past end -- Don't constrain
30         002434 020062 0000000      CMP    RO,DW$SRB(R2)  ;Did we go past end of scroll region?
31         002440 101402          BLOS  2$          ;Br if not
32         002442 016200 0000000      MOV    DW$SRB(R2),RO  ;Stop at bottom of scroll region
33         002446 004737 006702' 2$:  CALL  SETLIN          ;Set new line for cursor
34         ;
35         ; Finished
36         ;
37         002452 000207          RETURN

```

TCLF --- Process Line Feed character

```

1          .SBTTL  TCLF  --- Process Line Feed character
2          ;-----
3          ; Process a line feed character.  Move down to the next line.
4          ;
5          ; Inputs:
6          ;   R2 = Pointer to window control block
7          ;
8 002454   TCLF:
9          ;
10         ; If we are not at the bottom line of a scrolling region, simply
11         ; advance the line number.
12         ;
13 002454   016200   0000000   MOV     DW$LIN(R2),R0   ;Get the current line number
14 002460   020062   0000000   CMP     R0,DW$SRB(R2)  ;Are we at bottom of scrolling region?
15 002464   001411                   BEQ     1$             ;Br if yes
16 002466   005200                   INC     R0             ;Increment the line number
17 002470   020062   0000000   CMP     R0,DW$LPP(R2) ;Are we past the end of the page?
18 002474   101402                   BLOS   2$             ;Br if not
19 002476   016200   0000000   MOV     DW$LPP(R2),R0 ;Constrain to bottom of page
20 002502   004737   006702'   2$:    CALL   SETLIN   ;Set this as current line
21 002506   000402                   BR     9$
22         ;
23         ; We are at the bottom line of a scroll region.
24         ; We must scroll up one line.
25         ;
26 002510   004737   005146'   1$:    CALL   SCRLUP   ;Scroll up one line
27         ;
28         ; Finished
29         ;
30 002514   000207                   9$:    RETURN

```

TCESCE -- Move to 1st column of next line

```
1 .SBTTL TCESCE -- Move to 1st column of next line
2 ;-----
3 ; Move to first column of next line. Equivalent to carriage-return,
4 ; line-feed.
5 ;
6 ; Inputs:
7 ; R2 = Pointer to window control block.
8 ;
9 002516 004737 002306' TCESCE: CALL TCCR ; Simulate carriage return
10 002522 004737 002454' CALL TCLF ; Simulate line feed
11 002526 000207 RETURN
```

TCIXUP -- Index up one line

```

1          .SBTTL  TCIXUP -- Index up one line
2          ;-----
3          ; Move the cursor up one line.  Scroll the screen if we are on the top line.
4          ;
5          ; Inputs:
6          ;   R2 = Pointer to window control block
7          ;   R5 = Pointer to parameter value start in control sequence
8          ;
9 002530   TCIXUP:
10         ;
11         ; If we are not at the top line of a scrolling region,
12         ; simply decrement the line number.
13         ;
14 002530   016200   0000000   MOV     DW$LIN(R2),R0   ;Get current line number
15 002534   020062   0000000   CMP     R0,DW$SRT(R2) ;Are we at top of scrolling region?
16 002540   001406   BEQ     1$           ;Br if yes
17 002542   005300   DEC     R0           ;Decrement line number
18 002544   003001   BGT     2$           ;Br if didn't go past line 1
19 002546   005200   INC     R0           ;Constrain to line 1
20 002550   004737   006702'  2$:    CALL    SETLIN   ;Set this as current line
21 002554   000407   BR      9$
22         ;
23         ; We are at the top line of a scroll region.
24         ; We must scroll down one line.
25         ;
26 002556   004737   005266'  1$:    CALL    SCRLDN   ;Scroll down one line
27         ;
28         ; Finished
29         ;
30 002562   000207   9$:    RETURN

```

TCRIT -- Move cursor right specified number of chars

```

1          .SBTTL  TCRIT  -- Move cursor right specified number of chars
2          ;-----
3          ; Move cursor right a specified number of characters.
4          ;
5          ; Inputs:
6          ;   R2 = Pointer to window control block
7          ;   R5 = Pointer to parameter value in control sequence
8          ;
9 002564   TCRIT:
10         ;
11         ; Get parameter value of number of chars to move
12         ;
13 002564   004737   002116'   ; CALL    CSPARM           ;Get parameter value
14         ;
15         ; Translate parameter value of 0 to 1
16         ;
17 002570   005700   ; TST     R0           ;Parameter value zero?
18 002572   001001   ; BNE    1$           ;Br if not
19 002574   005200   ; INC    R0           ;Translate to 1
20         ;
21         ; Move the cursor the specified number of columns but don't go past
22         ; right margin.
23         ;
24 002576   066200   000000G   1$:   ADD    DW$COL(R2),R0   ;Get updated cursor column
25 002602   020062   000000G   ; CMP    R0,DW$CPL(R2)   ;Did we go past right column?
26 002606   101402   ; BLOS   2$           ;Br if not
27 002610   016200   000000G   ; MOV    DW$CPL(R2),R0   ;Constrain to right column
28 002614   010062   000000G   2$:   MOV    R0,DW$COL(R2) ;Set new column number
29         ;
30         ; Finished
31         ;
32 002620   000207   ; RETURN

```



TCLEFT -- Move cursor left specified number of chars

```

1          .SBTTL  TCLEFT -- Move cursor left specified number of chars
2          ;-----
3          ; Move cursor left a specified number of characters.
4          ;
5          ; Inputs:
6          ;   R2 = Pointer to window control block
7          ;   R5 = Pointer to parameter value in control sequence
8          ;
9 002622   TCLEFT:
10         ;
11         ; Get parameter value of number of chars to move
12         ;
13 002622   004737   002116'      CALL    CSPARM          ;Get parameter value
14         ;
15         ; Translate parameter value of 0 to 1
16         ;
17 002626   005700          TST     RO          ;Parameter value zero?
18 002630   001001          BNE     1$         ;Br if not
19 002632   005200          INC     RO          ;Translate to 1
20         ;
21         ; Move the cursor the specified number of columns but don't go past
22         ; left margin.
23         ;
24 002634   005400   1$:      NEG     RO          ;Get negative movement count
25 002636   066200   000000G   ADD     DW#COL(R2),RO  ;Get updated cursor column
26 002642   003002          BGT     2$         ;Br if didn't go past column 1
27 002644   012700   000001   MOV     #1,RO        ;Constrain to column 1
28 002650   010062   000000G   2$:      MOV     RO,DW#COL(R2) ;Set new column number
29         ;
30         ; Finished
31         ;
32 002654   000207          RETURN

```

```

1          .SBTTTL  TCCADR -- Do direct cursor addressing
2          ;-----
3          ; Move cursor to a specified line and column.
4          ;
5          ; Inputs:
6          ;   R2 = Pointer to window control block.
7          ;   R5 = Pointer to parameter string within control sequence
8          ;
9 002656   TCCADR:
10         ;
11         ; Get line number parameter
12         ;
13 002656   004737   002116'       CALL    CSPARM       ;Accrue line number parameter
14 002662   005700           TST      RO           ;Translate 0 to 1
15 002664   001001           BNE      1$
16 002666   005200           INC      RO           ;Force to 1
17 002670   032762   0000000 0000000 1$:  BIT      #AW$ORS,DW$AW(R2); Is origin relative to scrolling region?
18 002676   001410           BEQ      5$           ;Br if not
19 002700   066200   0000000       ADD      DW$SRT(R2),RO  ;Bias line number by top of scrolling region
20 002704   005300           DEC      RO           ;Top line number is 1
21 002706   020062   0000000       CMP      RO,DW$SRB(R2) ;Don't allow to go past end of scroll region
22 002712   101402           BLOS    5$           ;Br if ok
23 002714   016200   0000000       MOV      DW$SRB(R2),RO ;Constrain to bottom of scroll region
24 002720   020062   0000000       5$:    CMP      RO,DW$LPP(R2) ;Don't go past bottom of page
25 002724   101402           BLOS    2$           ;Br if ok
26 002726   016200   0000000       MOV      DW$LPP(R2),RO ;Constrain to bottom of page
27 002732   004737   006702'       2$:    CALL    SETLIN       ;Set new line as current line
28         ;
29         ; Get column number parameter
30         ;
31 002736   004737   002116'       CALL    CSPARM       ;Accrue column number parameter
32 002742   005700           TST      RO           ;Don't allow column 0
33 002744   001001           BNE      3$           ;Br if non zero
34 002746   005200           INC      RO           ;Translate 0 to 1
35 002750   020062   0000000       3$:    CMP      RO,DW$CPL(R2) ;Don't allow to go past right margin
36 002754   101402           BLOS    4$           ;Br if ok
37 002756   016200   0000000       MOV      DW$CPL(R2),RO ;Constrain to right margin
38 002762   010062   0000000       4$:    MOV      RO,DW$COL(R2) ;Set new column number
39         ;
40         ; Finished
41         ;
42 002766   000207           RETURN

```

```
1          .SBTTL  TCCPSV -- Save current cursor position
2          ;-----
3          ; Save the current cursor position and character attributes.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block.
7          ;
8 002770   TCCPSV:
9          ;
10         ; Save cursor position
11         ;
12 002770   116262 0000000 0000000      MOVB    DW$LIN(R2),DW$SLN(R2); Save current line number
13 002776   116262 0000000 0000000      MOVB    DW$COL(R2),DW$SCL(R2); Save current column number
14         ;
15         ; Save character attributes
16         ;
17 003004   116262 0000000 0000000      MOVB    DW$CCA(R2),DW$SCA(R2); Save character attribute flags
18         ;
19         ; Finished
20         ;
21 003012   000207      RETURN
22
23         .SBTTL  TCCPRS -- Restore cursor position
24         ;-----
25         ; Restore cursor position and character attributes from saved data.
26         ;
27         ; Inputs:
28         ; R2 = Pointer to window control block.
29         ;
30 003014   TCCPRS:
31         ;
32         ; Restore the column number
33         ;
34 003014   116262 0000000 0000000      MOVB    DW$SCL(R2),DW$COL(R2); Restore column number
35         ;
36         ; Restore the line number
37         ;
38 003022   116200 0000000      MOVB    DW$SLN(R2),R0      ; Get saved line number
39 003026   004737 006702'      CALL    SETLIN          ; Set as current line number
40         ;
41         ; Restore character attributes
42         ;
43 003032   116262 0000000 0000000      MOVB    DW$SCA(R2),DW$CCA(R2); Restore character attribute flags
44         ;
45         ; Finished
46         ;
47 003040   000207      RETURN
```

TCINSL -- Insert lines

```

1          .SBTTL  TCINSL -- Insert lines
2          ;-----
3          ; Insert a specified number of lines in front of the line in which
4          ; the cursor is currently resting.  The cursor is left positioned
5          ; at column 1 of the first inserted line.
6          ;
7          ; Inputs:
8          ; R2 = Pointer to window control block
9          ; R5 = Pointer to command string argument
10         ;
11 003042 010146 TCINSL: MOV     R1,-(SP)
12 003044 010346          MOV     R3,-(SP)
13 003046 010446          MOV     R4,-(SP)
14 003050 010546          MOV     R5,-(SP)
15         ;
16         ; Ignore this command if we are not within the scroll region
17         ;
18 003052 016203 0000000  MOV     DW$LIN(R2),R3  ;Get current line number
19 003056 020362 0000000  CMP     R3,DW$SRT(R2) ;Are we above top to scroll region?
20 003062 103444          BLO     9$             ;Br if yes
21 003064 020362 0000000  CMP     R3,DW$SRB(R2) ;Are we below bottom of scroll region?
22 003070 101041          BHI     9$             ;Br if yes
23         ;
24         ; Determine how many lines will be inserted
25         ;
26 003072 004737 002116'  CALL    CSPARM         ;Get command parameter
27 003076 005700          TST     R0             ;Was 0 specified?
28 003100 003002          BGT     1$             ;Br if not
29 003102 012700 0000001  MOV     #1,R0          ;Set it to 1
30 003106 016201 0000000  1$:    MOV     DW$SRB(R2),R1 ;Get bottom line # of scroll region
31 003112 160301          SUB     R3,R1          ;Get # lines from current to end of region
32 003114 005201          INC     R1             ;This is max # inserted lines
33 003116 020100          CMP     R1,R0          ;Can we scroll as many as requested?
34 003120 101413          BLOS   2$             ;Br if all lines are scrolled off
35         ;
36         ; Scroll down lines to make room for inserted lines
37         ;
38 003122 010103          MOV     R1,R3          ;Get number of lines to scroll
39 003124 160003          SUB     R0,R3          ;
40 003126 010001          MOV     R0,R1          ;Get # lines being inserted
41 003130 016205 0000000  MOV     DW$SRB(R2),R5  ;Get # of line at bottom of scroll reg
42 003134 010504          3$:    MOV     R5,R4          ;
43 003136 160104          SUB     R1,R4          ;Get # of line to copy to bottom
44 003140 004737 006346'  CALL    CPYLIN         ;Copy a line down
45 003144 005305          DEC     R5             ;Get next destination line number
46 003146 077306          SOB     R3,3$         ;Loop if more lines to scroll down
47         ;
48         ; Blank fill inserted lines
49         ;
50 003150 016203 0000000  2$:    MOV     DW$LIN(R2),R3 ;Get top line to blank
51 003154 010300          4$:    MOV     R3,R0          ;Get # of line to clear
52 003156 004737 006232'  CALL    CLRLIN         ;Clear that line
53 003162 005203          INC     R3             ;Advance line number
54 003164 077105          SOB     R1,4$         ;Loop if more lines to clear
55         ;
56         ; Move cursor to column 1
57         ;

```

```
58 003166 012762 000001 0000000      MOV      #1,DW$COL(R2) ;Say cursor is at column 1
59                                     ;
60                                     ; Finished
61                                     ;
62 003174 012605      9#:      MOV      (SP)+,R5
63 003176 012604      MOV      (SP)+,R4
64 003200 012603      MOV      (SP)+,R3
65 003202 012601      MOV      (SP)+,R1
66 003204 000207      RETURN
```

TCDELL -- Delete specified number of lines

```

1          .SBTTL  TCDELL -- Delete specified number of lines
2          ;-----
3          ; Delete the specified number of lines starting with the one in which
4          ; the cursor is positioned.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ; R5 = Pointer to command string argument
9          ;
10         003206 010146 TCDELL: MOV     R1,-(SP)
11         003210 010346         MOV     R3,-(SP)
12         003212 010446         MOV     R4,-(SP)
13         003214 010546         MOV     R5,-(SP)
14         ;
15         ; Ignore this command if we are not within the scroll region
16         ;
17         003216 016203 0000000  MOV     DW$LIN(R2),R3 ;Get current line number
18         003222 020362 0000000  CMP     R3,DW$SRT(R2) ;Are we above top to scroll region?
19         003226 103442         BLO    9$ ;Br if yes
20         003230 020362 0000000  CMP     R3,DW$SRB(R2) ;Are we below bottom of scroll region?
21         003234 101037         BHI    9$ ;Br if yes
22         ;
23         ; Determine how many lines will be deleted
24         ;
25         003236 004737 002116'   CALL    CSPARM ;Get command parameter
26         003242 005700         TST    R0 ;Was 0 specified?
27         003244 003002         BGT    1$ ;Br if not
28         003246 012700 0000001   MOV     #1,R0 ;Set it to 1
29         003252 016201 0000000 1$:  MOV     DW$SRB(R2),R1 ;Get bottom line # of scroll region
30         003256 160301         SUB    R3,R1 ;Get # lines from current to end of region
31         003260 005201         INC    R1 ;This is max # deleted lines
32         003262 020100         CMP    R1,R0 ;Can we delete as many as requested?
33         003264 101412         BLOS   2$ ;Br if all lines are deleted
34         ;
35         ; Scroll up the remaining lines.
36         ;
37         003266 010305         MOV    R3,R5 ;Get current line number
38         003270 010103         MOV    R1,R3 ;Get number of lines to scroll
39         003272 160003         SUB    R0,R3
40         003274 010001         MOV    R0,R1 ;Get # lines being inserted
41         003276 010504 3$:  MOV    R5,R4
42         003300 060104         ADD    R1,R4 ;Get line to copy from
43         003302 004737 006346'   CALL    CPYLIN ;Copy a line up
44         003306 005205         INC    R5 ;Advance line number
45         003310 077306         SOB    R3,3$ ;Br if more lines to copy
46         ;
47         ; Blank fill lines at end of scrolling region
48         ;
49         003312 016203 0000000 2$:  MOV    DW$SRB(R2),R3 ;Get # of line at bottom of region
50         003316 010300 4$:  MOV    R3,R0 ;Get # of line to blank fill
51         003320 004737 006232'   CALL    CLRLIN ;Blank the line
52         003324 077104         SOB    R1,4$ ;Loop if more lines to blank
53         ;
54         ; Say cursor is at column 1
55         ;
56         003326 012762 000001 0000000 MOV    #1,DW$COL(R2) ;Say cursor is at column 1
57         ;

```

```
58 ; Finished  
59 ;  
60 003334 012605 9#: MOV (SP)+,R5  
61 003336 012604 MOV (SP)+,R4  
62 003340 012603 MOV (SP)+,R3  
63 003342 012601 MOV (SP)+,R1  
64 003344 000207 RETURN
```

TCGOAS -- Designate GO as ascii character set

```

1          .SBTTL  TCGOAS -- Designate GO as ascii character set
2          ;-----
3          ; Designate the GO character set as ascii characters.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ;
8 003346 105062 0000000 TCGOAS: CLRB   DW$GOM(R2)   ;Set character set number
9 003352 000207          RETURN

```

```

10         .SBTTL  TCGODS -- Designate GO as DEC supplemental character set
11         ;-----
12         ; Designate the GO character set as DEC supplemental character set.
13         ;
14         ; Inputs:
15         ; R2 = Pointer to window control block.
16         ;
17         ;
18 003354 112762 000001 0000006 TCGODS: MOVB  #1,DW$GOM(R2) ;Set character set number
19 003362 000207          RETURN

```

```

20         .SBTTL  TCGOUK -- Designate GO as UK national character set
21         ;-----
22         ; Designate the GO character set as UK national character set.
23         ;
24         ; Inputs:
25         ; R2 = Pointer to window control block.
26         ;
27         ;
28 003364 112762 000002 0000006 TCGOUK: MOVB  #2,DW$GOM(R2) ;Set character set number
29 003372 000207          RETURN

```

```

30         .SBTTL  TCGOGR -- Designate GO as graphics character set
31         ;-----
32         ; Designate the GO character set as graphics characters.
33         ;
34         ; Inputs:
35         ; R2 = Pointer to window control block.
36         ;
37         ;
38 003374 112762 000003 0000006 TCGOGR: MOVB  #3,DW$GOM(R2) ;Set character set number
39 003402 000207          RETURN

```



TCG1AS -- Designate G1 as ascii character set

```

1          .SBTTL  TCG1AS -- Designate G1 as ascii character set
2          ;-----
3          ; Designate the G1 character set as ascii characters.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ;
8 003404 105062 0000000 TCG1AS: CLRB    DW#G1M(R2)    ;Set character set number
9 003410 000207          RETURN

```

```

11         .SBTTL  TCG1DS -- Designate G1 as DEC supplemental character set
12         ;-----
13         ; Designate the G1 character set as DEC supplemental character set.
14         ;
15         ; Inputs:
16         ; R2 = Pointer to window control block.
17         ;
18 003412 112762 000001 0000000 TCG1DS: MOVB   #1,DW#G1M(R2)  ;Set character set number
19 003420 000207          RETURN

```

```

21         .SBTTL  TCG1UK -- Designate G1 as UK national character set
22         ;-----
23         ; Designate the G1 character set as UK national character set.
24         ;
25         ; Inputs:
26         ; R2 = Pointer to window control block.
27         ;
28 003422 112762 000002 0000000 TCG1UK: MOVB   #2,DW#G1M(R2)  ;Set character set number
29 003430 000207          RETURN

```

```

31         .SBTTL  TCG1GR -- Designate G1 as graphics character set
32         ;-----
33         ; Designate the G1 character set as graphics characters.
34         ;
35         ; Inputs:
36         ; R2 = Pointer to window control block.
37         ;
38 003432 112762 000003 0000000 TCG1GR: MOVB   #3,DW#G1M(R2)  ;Set character set number
39 003440 000207          RETURN

```

TCG2AS -- Designate G2 as ascii character set

```

1          .SBTTL  TCG2AS -- Designate G2 as ascii character set
2          ;-----
3          ; Designate the G2 character set as ascii characters.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ;
8 003442 105062 000000G TCG2AS: CLRB   DW$G2M(R2)   ;Set character set number
9 003446 000207          RETURN

```

```

10         .SBTTL  TCG2DS -- Designate G2 as DEC supplemental character set
11        ;-----
12        ; Designate the G2 character set as DEC supplemental character set.
13        ;
14        ; Inputs:
15        ; R2 = Pointer to window control block.
16        ;
17        ;
18 003450 112762 000001 000000G TCG2DS: MOVB  #1,DW$G2M(R2) ;Set character set number
19 003456 000207          RETURN

```

```

20        .SBTTL  TCG2GR -- Designate G2 as graphics character set
21        ;-----
22        ; Designate the G2 character set as graphics characters.
23        ;
24        ; Inputs:
25        ; R2 = Pointer to window control block.
26        ;
27        ;
28 003460 112762 000003 000000G TCG2GR: MOVB  #3,DW$G2M(R2) ;Set character set number
29 003466 000207          RETURN

```

TCG3AS -- Designate G3 as ascii character set

```

1          .SBTTL  TCG3AS -- Designate G3 as ascii character set
2          ;-----
3          ; Designate the G3 character set as ascii characters.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ;
8 003470 105062 0000000 TCG3AS: CLRB    DW$G3M(R2)    ;Set character set number
9 003474 000207          RETURN

```

```

10         .SBTTL  TCG3DS -- Designate G3 as DEC supplemental character set
11         ;-----
12         ; Designate the G3 character set as DEC supplemental character set.
13         ;
14         ; Inputs:
15         ; R2 = Pointer to window control block.
16         ;
17         ;
18 003476 112762 000001 0000000 TCG3DS: MOVB   #1,DW$G3M(R2)  ;Set character set number
19 003504 000207          RETURN

```

```

20         .SBTTL  TCG3GR -- Designate G3 as graphics character set
21         ;-----
22         ; Designate the G3 character set as graphics characters.
23         ;
24         ; Inputs:
25         ; R2 = Pointer to window control block.
26         ;
27         ;
28 003506 112762 000003 0000000 TCG3GR: MOVB   #3,DW$G3M(R2)  ;Set character set number
29 003514 000207          RETURN

```

TCSO -- Shift-out character - Lock shift G1 to GL

```

1          .SBTTL  TCSO  -- Shift-out character - Lock shift G1 to GL
2          ;-----
3          ; The shift-out character is used to lock character set G1 to GL.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ;
8 003516 112762 000001 000000G TCSO:  MOVB   #1,DW$GLM(R2) ;Map GL to G1
9 003524 000207                RETURN
10         ;
11         .SBTTL  TCSI  -- Shift-in character - Lock shift G0 to GL
12         ;-----
13         ; The shift-in character is used to lock character set G0 to GL.
14         ;
15         ; Inputs:
16         ; R2 = Pointer to window control block.
17         ;
18 003526 105062 000000G TCSI:  CLRB   DW$GLM(R2) ;Map GL to G0
19 003532 000207                RETURN
20         ;
21         .SBTTL  TCLS2  -- Lock shift G2 to GL
22         ;-----
23         ; Set G2 as current GL character set.
24         ;
25         ; Inputs:
26         ; R2 = Pointer to window control block.
27         ;
28 003534 112762 000002 000000G TCLS2: MOVB   #2,DW$GLM(R2) ;Map GL to G2
29 003542 000207                RETURN
30         ;
31         .SBTTL  TCLS3  -- Lock shift G3 to GL
32         ;-----
33         ; Set G3 as current GL character set.
34         ;
35         ; Inputs:
36         ; R2 = Pointer to window control block.
37         ;
38 003544 112762 000003 000000G TCLS3: MOVB   #3,DW$GLM(R2) ;Map GL to G3
39 003552 000207                RETURN
40         ;
41         .SBTTL  TCLS1R -- Lock shift G1 into GR
42         ;-----
43         ; Set G1 as current GR character set.
44         ;
45         ; Inputs:
46         ; R2 = Pointer to window control block.
47         ;
48 003554 112762 000001 000000G TCLS1R: MOVB   #1,DW$GRM(R2) ;Map GR to G1
49 003562 000207                RETURN
50         ;
51         .SBTTL  TCLS2R -- Lock shift G2 into GR
52         ;-----
53         ; Set G2 as the GR character set.
54         ;
55         ; Inputs:
56         ; R2 = Pointer to window control block.
57         ;

```

```
58 003564 112762 000002 000000G TCLS2R: MOVB #2,DW$GRM(R2) ;Map GR to G2
59 003572 000207 RETURN
60
61 .SBTTL TCLS3R -- Lock shift G3 into GR
62 ;-----
63 ; Set G3 as the GR character set.
64 ;
65 ; Inputs:
66 ; R2 = Pointer to window control block.
67 ;
68 003574 112762 000003 000000G TCLS3R: MOVB #3,DW$GRM(R2) ;Map GR to G3
69 003602 000207 RETURN
70
71 .SBTTL TCSS2 -- Single shift G2 to GL
72 ;-----
73 ; Set G2 as GL for next character only.
74 ;
75 ; Inputs:
76 ; R2 = Pointer to window control block.
77 ;
78 003604 112762 000002 000000G TCSS2: MOVB #2,DW$GLS(R2) ;Map GL to G2 for next character only
79 003612 052762 000000G 000000G BIS #AW$SS,DW$AW(R2);Remember single shift is pending
80 003620 000207 RETURN
81
82 .SBTTL TCSS3 -- Single shift G3 to GL
83 ;-----
84 ; Set G3 as GL for next character only.
85 ;
86 ; Inputs:
87 ; R2 = Pointer to window control block.
88 ;
89 003622 112762 000003 000000G TCSS3: MOVB #3,DW$GLS(R2) ;Map GL to G3 for next character only
90 003630 052762 000000G 000000G BIS #AW$SS,DW$AW(R2);Remember single shift is pending
91 003636 000207 RETURN
```

```
1 .SBTTL TCSAA -- Set ANSI attribute
2 -----
3 ; Set an ANSI terminal attribute.
4 ;
5 ; Inputs:
6 ; R2 = Pointer to window control block
7 ; R5 = Pointer to parameter values
8 ;
9 003640 010346 TCSAA: MOV R3, -(SP)
10 003642 012703 004112' MOV #ASATAT, R3 ; Point to ANSI conversion table
11 003646 004737 003730' CALL TCSTA ; Go set the attribute
12 003652 012603 MOV (SP)+, R3
13 003654 000207 RETURN
```

```
14 .SBTTL TCRAA -- Reset ANSI attribute
15 -----
16 ; Reset an ANSI terminal attribute.
17 ;
18 ; Inputs:
19 ; R2 = Pointer to window control block
20 ; R5 = Pointer to parameter values
21 ;
22 ;
23 003656 010346 TCRAA: MOV R3, -(SP)
24 003660 012703 004112' MOV #ASATAT, R3 ; Point to ANSI conversion table
25 003664 004737 003766' CALL TCRTA ; Reset the attribute
26 003670 012603 MOV (SP)+, R3
27 003672 000207 RETURN
```

```
28 .SBTTL TCSDA -- Set DEC attribute
29 -----
30 ; Set a DEC terminal attribute
31 ;
32 ; Inputs:
33 ; R2 = Pointer to window control block
34 ; R5 = Pointer to parameter values
35 ;
36 ;
37 003674 010346 TCSDA: MOV R3, -(SP)
38 003676 012703 004120' MOV #DECTAT, R3 ; Point to DEC conversion table
39 003702 004737 003730' CALL TCSTA ; Set the attribute
40 003706 012603 MOV (SP)+, R3
41 003710 000207 RETURN
```

```
42 .SBTTL TCRDA -- Reset DEC attribute
43 -----
44 ; Reset a DEC terminal attribute
45 ;
46 ; Inputs:
47 ; R2 = Pointer to window control block
48 ; R5 = Pointer to parameter values
49 ;
50 ;
51 003712 010346 TCRDA: MOV R3, -(SP)
52 003714 012703 004120' MOV #DECTAT, R3 ; Point to DEC conversion table
53 003720 004737 003766' CALL TCRTA ; Reset the attribute
54 003724 012603 MOV (SP)+, R3
55 003726 000207 RETURN
```

```

1          .SBTTL  TCSTA  -- Set terminal attribute
2          ;-----
3          ; Set a terminal attribute
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ; R3 = Pointer to table to convert attribute value to flag bit
8          ; R5 = Pointer to parameter values
9          ;
10         003730  010446  TCSTA:  MOV      R4, -(SP)
11         ;
12         ; Begin loop to accrue attribute parameters until end of string hit
13         ;
14         003732  004737  002116'  1$:    CALL    CSPARM      ;Accrue next parameter value
15         003736  103411          BCS     9$           ;Br if no more parameter values
16         ;
17         ; Convert parameter value into flag mask
18         ;
19         003740  010004          MOV     R0, R4      ;Save parameter value
20         003742  004737  004060'  CALL    CVTTAV      ;Convert parameter value into flag mask
21         003746  103771          BCS     1$           ;Br if parameter not recognized
22         ;
23         ; Set appropriate flag bit
24         ;
25         003750  050062  0000000  BIS     R0, DW$AW(R2) ;Set appropriate attribute flag
26         ;
27         ; See if this change requires doing more than setting a flag bit
28         ;
29         003754  004737  004152'  CALL    CKTAC      ;Check for additional changes
30         ;
31         ; See if there are more attributes to set
32         ;
33         003760  000764          BR     1$
34         ;
35         ; Finished
36         ;
37         003762  012604  9$:    MOV     (SP)+, R4
38         003764  000207          RETURN

```

TCRTA -- Reset terminal attribute

```

1          .SBTTL  TCRTA  -- Reset terminal attribute
2          ;-----
3          ; Reset a terminal attribute
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ; R3 = Pointer to table to convert attribute value to flag bit
8          ; R5 = Pointer to parameter values
9          ;
10         003766 010446 TCRTA:  MOV    R4,-(SP)
11         ;
12         ; Begin loop to accrue attribute parameters until end of string hit
13         ;
14         003770 004737 002116' 1$:   CALL   CSPARM      ;Accrue next parameter value
15         003774 103427          BCS    9$           ;Br if no more parameters
16         ;
17         ; Check for special parameter value 2 which means select VT52 mode
18         ;
19         003776 020027 000002          CMP    R0,#2        ;Select VT52 mode?
20         004002 001013          BNE    2$           ;Br if not
21         004004 052762 0000000 0000000  BIS    #AW$S52,DW$AW(R2);Enable VT52 simulation mode for window
22         004012 116204 0000000          MOVB  DW$JOB(R2),R4  ;Get out job index number
23         004016 116404 0000000          MOVB  LNPRIM(R4),R4 ;Get our primary job #
24         004022 052764 0000000 0000000  BIS    #$V52EM,LSW11(R4);Say we are emulating a VT52
25         004030 000757          BR    1$
26         ;
27         ; Convert parameter value into flag mask
28         ;
29         004032 010004          2$:   MOV    R0,R4        ;Save parameter value
30         004034 004737 004060'          CALL   CVTTAV      ;Convert parameter value into flag mask
31         004040 103753          BCS    1$           ;Br if parameter value not recognized
32         ;
33         ; Reset appropriate flag bit
34         ;
35         004042 040062 0000000          BIC    R0,DW$AW(R2) ;Reset appropriate attribute flag
36         ;
37         ; See if this change requires doing more than clearing a bit
38         ;
39         004046 004737 004152'          CALL   CKTAC      ;Check for special mode changes
40         ;
41         ; See if there are more attributes to reset
42         ;
43         004052 000746          BR    1$
44         ;
45         ; Finished
46         ;
47         004054 012603          9$:   MOV    (SP)+,R3
48         004056 000207          RETURN

```



CVTTAV -- Convert terminal attribute value to flag

```

1          .SBTTL  CVTTAV -- Convert terminal attribute value to flag
2          ;-----
3          ; Convert a terminal attribute parameter value into a flag mask.
4          ;
5          ; Inputs:
6          ;   R0 = Attribute value
7          ;   R3 = Pointer to table to convert attribute value to flag bit
8          ;
9          ; Outputs:
10         ;   C-flag set ==> Attribute value not recognized
11         ;   R0 = Flag mask if attribute value recognized
12         ;
13 004060  010346  CVTTAV: MOV      R3, -(SP)
14         ;
15         ; See if we can find attribute value in table
16         ;
17 004062  020023  1$:      CMP      R0, (R3)+      ; Is next entry for our value?
18 004064  001406          BEQ      2$              ; Br if yes
19 004066  005723          TST      (R3)+      ; Skip over flag mask
20 004070  005713          TST      (R3)        ; Is there another entry in table?
21 004072  001373          BNE      1$              ; Br if yes
22         ;
23         ; Attribute value is not in table
24         ;
25 004074  005000          CLR      R0              ; Return no flag mask
26 004076  000261          SEC              ; Signal failure on return
27 004100  000402          BR       9$
28         ;
29         ; We found the attribute in the table
30         ;
31 004102  011300  2$:      MOV      (R3), R0      ; Get the flag mask
32 004104  000241          CLC              ; Signal success on return
33         ;
34         ; Finished
35         ;
36 004106  012603  9$:      MOV      (SP)+, R3
37 004110  000207          RETURN
38         ;-----
39         ;
40         ; Table to relate ANSI attribute values with flag masks
41         ;
42 004112  000004  0000006  ASATAT: .WORD  4, AW$INS      ; Insert mode
43 004116  000000          .WORD  0
44         ;
45         ; Table to relate DEC attribute values with flag masks
46         ;
47 004120  000001  0000006  DECTAT: .WORD  1, AW$ACK      ; Application mode for cursor keys
48 004124  000003  0000006          .WORD  3, AW$132      ; 132 column mode
49 004130  000005  0000006          .WORD  5, AW$REV      ; Reverse video
50 004134  000006  0000006          .WORD  6, AW$ORS      ; Origin relative to scroll region
51 004140  000010  0000006          .WORD  8, AW$RPT      ; Automatic keypad repeat
52 004144  000031  0000006          .WORD 25, AW$VCR      ; Make cursor visible
53 004150  000000          .WORD  0              ; End of table

```

CKTAC -- Check for complex mode changes

```

1          .SBTTL  CKTAC  -- Check for complex mode changes
2          ;-----
3          ; This routine is called each time a terminal attribute changes to see
4          ; if we must do things other than setting or clearing an attribute flag.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ; R4 = Parameter value specified with attribute change command.
9          ;
10         004152  CKTAC:
11         ;
12         ; If we just changed the origin mode, home the cursor
13         ;
14         004152  020427  000006          CMP      R4,#6          ;Change origin mode?
15         004156  001003          BNE      1$          ;Br if not
16         004160  004737  005110'      CALL    SETHOM        ;Say cursor has moved to home
17         004164  000415          BR      9$
18         ;
19         ; If we just changed line width (80/132 mode), clear the screen,
20         ; set scrolling region to full screen, and home the cursor.
21         ;
22         004166  020427  000003  1$:    CMP      R4,#3          ;Change line width?
23         004172  001012          BNE      9$          ;Br if not
24         004174  012762  000001  000000G  MOV     #1,DW$SRT(R2) ;Set top scroll line to 1
25         004202  016262  000000G 000000G  MOV     DW$LPP(R2),DW$SRB(R2) ;Set bottom scroll line to end of page
26         004210  004737  005110'      CALL    SETHOM        ;Set cursor to home position
27         004214  004737  006210'      CALL    ERSPA0        ;Erase the entire page
28         ;
29         ; Finished
30         ;
31         004220  000207  9$:    RETURN

```

TCAKM -- Select application keypad mode

```
1 .SBTTL TCAKM -- Select application keypad mode
2 ;-----
3 ; Select application keypad mode
4 ;
5 ; Inputs:
6 ; R2 = Pointer to window control block
7 ;
8 004222 052762 000000G 000000G TCAKM: BIS #AW$AKM,DW$AW(R2);Say we are in application keypad mode
9 004230 000207 RETURN
```

```
10
11 .SBTTL TCNKM -- Select numeric keypad mode
12 ;-----
13 ; Select numeric keypad mode
14 ;
15 ; Inputs:
16 ; R2 = Pointer to window control block
17 ;
18 004232 042762 000000G 000000G TCNKM: BIC #AW$AKM,DW$AW(R2);Reset application keypad mode
19 004240 000207 RETURN
```

TCN3 -- Set line attributes

```

1          .SBTTL  TCN3  -- Set line attributes
2          ;-----
3          ; Set attributes for the current line.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ;
8          ; Line is top half of double-high line
9          ;
10         004242 004737 006612' TCN3:  CALL  GETLAB      ;Get current line attribute flags
11         004246 042700 0000000  BIC   #AL$DHB,RO  ;Clear double-high-bottom flag
12         004252 052700 0000000  BIS   #AL$DHT,RO  ;Set double-high-top flag
13         004256 004737 006522'  CALL  SETLAB      ;Store new attribute flags for line
14         004262 000207          RETURN
15         ;
16         ; Line is bottom half of double-high line
17         ;
18         004264 004737 006612' TCN4:  CALL  GETLAB      ;Get current line attribute flags
19         004270 042700 0000000  BIC   #AL$DHT,RO  ;Clear double-high-top flag
20         004274 052700 0000000  BIS   #AL$DHB,RO  ;Set double-high-bottom flag
21         004300 004737 006522'  CALL  SETLAB      ;Store new attribute flags for line
22         004304 000207          RETURN
23         ;
24         ; Line is single width
25         ;
26         004306 004737 006612' TCN5:  CALL  GETLAB      ;Get current line attribute flags
27         004312 042700 0000000  BIC   #AL$DWD,RO  ;Clear double-wide attribute
28         004316 004737 006522'  CALL  SETLAB      ;Store new attribute flags for line
29         004322 000207          RETURN
30         ;
31         ; Line is double width
32         ;
33         004324 004737 006612' TCN6:  CALL  GETLAB      ;Get current line attribute flags
34         004330 052700 0000000  BIS   #AL$DWD,RO  ;Set double-wide flag
35         004334 004737 006522'  CALL  SETLAB      ;Store new attribute flags for line
36         004340 000207          RETURN

```

TCSCA -- Set character attributes

```

1          .SBTTL  TCSCA  -- Set character attributes
2          ;-----
3          ; Specify attributes for characters that follow
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ; R5 = Pointer to start of parameter values
8          ;
9 004342  010346  TCSCA:  MOV      R3, -(SP)
10         ;
11         ; If no parameters were specified, reset all character attributes
12         ;
13 004344  121527  000155          CMPB   (R5), #'m      ; Any attributes specified?
14 004350  001004          BNE    1$           ; Br if yes
15 004352  142762  000000C 000000G  BICB  #<AC$BLD!AC$BLK!AC$REV!AC$ULN>, DW$CCA(R2); Clear all attributes
16 004360  000422          BR     9$           ; Finished
17         ;
18         ; Begin loop to accrue and process each parameter
19         ;
20 004362  004737  002116'  1$:    CALL   CSPARM      ; Accrue next parameter value
21 004366  103417          BCS    9$           ; Br if no more parameter values
22         ;
23         ; Look up parameter value to determine which attribute flags
24         ; are to be set and reset.
25         ;
26 004370  012703  004432'          MOV    #CATABL, R3    ; Point to attribute table
27 004374  120023  2$:    CMPB   R0, (R3)+  ; Search for parameter value in table
28 004376  001406          BEQ    3$           ; Br if found it
29 004400  062703  000002          ADD   #2, R3        ; Skip over flag bytes
30 004404  020327  004465'          CMP   R3, #CATEND   ; Reached end of table?
31 004410  103771          BLD   2$           ; Keep looking if not
32 004412  000763          BR    1$           ; Cannot find this parameter value
33         ;
34         ; Found parameter value in table.
35         ; Set and reset some flags
36         ;
37 004414  152362  000000G  3$:    BISB   (R3)+, DW$CCA(R2); Set some attributes
38 004420  142362  000000G          BICB   (R3)+, DW$CCA(R2); Reset some attributes
39 004424  000756          BR    1$           ; Process any other attributes
40         ;
41         ; Finished
42         ;
43 004426  012603  9$:    MOV    (SP)+, R3
44 004430  000207          RETURN

```

TCSCA -- Set character attributes

```

1
2 ; -----
3 ; Table to convert attribute parameter values into flags to be
4 ; set and reset.
5 ; Each entry has three values: (1) numeric parameter value that
6 ; occurs in control sequence; (2) flags to be set; (3) flags to
7 ; be reset.
8 004432      000      000      000C CATABL: .BYTE 0.,0,AC$BLD!AC$BLK!AC$REV!AC$ULN
9 004435      001      000G      000      .BYTE 1.,AC$BLD,0
10 004440     004      000G      000      .BYTE 4.,AC$ULN,0
11 004443     005      000G      000      .BYTE 5.,AC$BLK,0
12 004446     007      000G      000      .BYTE 7.,AC$REV,0
13 004451     026      000      000G      .BYTE 22.,0,AC$BLD
14 004454     030      000      000G      .BYTE 24.,0,AC$ULN
15 004457     031      000      000G      .BYTE 25.,0,AC$BLK
16 004462     033      000      000G      .BYTE 27.,0,AC$REV
17 004465
18 CATEND: .EVEN

```

TC100 -- Select VT100/VT200 mode

```

1          .SBTTL  TC100  -- Select VT100/VT200 mode
2          ;-----
3          ; Set terminal to VT100 or VT200 mode of operation
4          ;
5          ; Inputs:
6          ;   R2 = Pointer to window control block
7          ;   R5 = Pointer to parameter values
8          ;
9 004466   TC100:
10         ;
11         ; Say terminal is not in VT52 mode and not in VT200 mode
12         ; (i.e., set to VT100 mode)
13         ;
14 004466   042762  000000C 000000G      BIC      #<AW$52!AW$552!AW$200>,DW$AW(R2) ;Terminal is in VT100 mode
15         ;
16         ; Reset VT52 emulation-mode flag in entry for primary line so that
17         ; other windows connected to this terminal will know.
18         ;
19 004474   116200  000000G      MOVVB   DW$JOB(R2),R0   ;Get our line index number
20 004500   116000  000000G      MOVVB   LNPRIM(R0),R0  ;Get number of primary line
21 004504   042760  000000G 000000G      BIC      #$V52EM,LSW11(R0) ;Say terminal not emulating a VT52
22         ;
23         ; If job's terminal type is VT200, set that mode
24         ;
25 004512   116200  000000G      MOVVB   DW$JOB(R2),R0   ;Get job index number
26 004516   032760  000000C 000000G      BIT      #<VT2007!VT2008>,LTRMTP(R0);Is terminal a VT200?
27 004524   001005          BNE      1$              ;Br if yes
28         ;
29         ; Get 1st parameter value and see if we should go to VT200 mode
30         ;
31 004526   004737  002116'      CALL    CSPARM          ;Accrue 1st parameter value
32 004532   020027  000076          CMP     R0,#62.         ;VT200 mode?
33 004536   001003          BNE     9$              ;Br if not
34         ;
35         ; Set terminal type to VT200
36         ;
37 004540   052762  000000G 000000G 1$:   BIS     #AW$200,DW$AW(R2);Set VT200 mode
38         ;
39         ; Finished
40         ;
41 004546   000207 9$:   RETURN

```

TCREST -- Terminal reset

```

1          .SBTTL  TCREST -- Terminal reset
2          ;-----
3          ; Perform a terminal reset operation
4          ;
5          ; Inputs:
6          ;   R2 = Pointer to window control block
7          ;
8 004550 010146 TCREST: MOV     R1, -(SP)
9          ;
10         ; Turn off VT52 emulation mode
11         ;
12 004552 042762 000000G 000000G      BIC     #AW$S52, DW$AW(R2); Turn off attribute for window
13 004560 116201 000000G      MOVB    DW$JOB(R2), R1    ; Get our job index number
14 004564 116100 000000G      MOVB    LNPRIM(R1), R0   ; Get primary line number
15 004570 042760 000000G 000000G      BIC     ##V52EM, LSW11(R0); Say terminal is not in VT52 mode
16         ;
17         ; Reset scrolling region
18         ;
19 004576 012762 000001 000000G      MOV     #1, DW$SRT(R2)  ; Set top scroll line to 1
20 004604 016262 000000G 000000G      MOV     DW$LPP(R2), DW$SRB(R2); Set bottom scroll line to end of page
21         ;
22         ; Reset misc window status flags
23         ;
24 004612 042762 000000C 000000G      BIC     #<AW$132!AW$INS!AW$ACK!AW$ORS!AW$AKM!AW$SS!AW$PRT>, DW$AW(R2)
25         ;
26         ; Say cursor is at home
27         ;
28 004620 004737 005110'      CALL    SETHOM        ; Set cursor to home position
29         ;
30         ; Erase the entire page
31         ;
32 004624 004737 006210'      CALL    ERSPAG        ; Erase the entire page
33         ;
34         ; Reset character set mapping for a VT200
35         ;
36 004630 032761 000000C 000000G      BIT     #<VT2007!VT2008>, LTRMTP(R1); Is this a VT200?
37 004636 001411      BEQ     9$          ; Br if not
38 004640 112762 000001 000000G      MOVB    #1, DW$G2M(R2)  ; Map G2 to DEC supplemental chars
39 004646 112762 000001 000000G      MOVB    #1, DW$G3M(R2)  ; Map G3 to DEC supplemental chars
40 004654 112762 000002 000000G      MOVB    #2, DW$GRM(R2)  ; Map GR to G2
41         ;
42         ; Finished
43         ;
44 004662 012601      9$:  MOV     (SP)+, R1
45 004664 000207      RETURN

```



```
1          .SBTTL  TCPRT  -- Printer control operation
2          ;-----
3          ; Direct output to printer or back to terminal.
4          ;
5          ; Inputs:
6          ;   R2 = Pointer to window control block
7          ;   R5 = Pointer to start of parameter value
8          ;
9 004666   TCPRT:
10         ;
11         ; Get first parameter value and see if we should direct output to printer
12         ; or to terminal.
13         ;
14 004666   004737   002116'       CALL   CSPARM       ;Get first parameter value
15 004672   020027   000005       CMP    RO,#5         ;Direct output to printer?
16 004676   001004           BNE    1$              ;Br if not
17 004700   052762   000000G 000000G  BIS    #AW$PRT,DW$AW(R2);Direct output to printer
18 004706   000406           BR     9$
19 004710   020027   000004       1$:  CMP    RO,#4         ;Direct output to terminal?
20 004714   001003           BNE    9$              ;Br if not
21 004716   042762   000000G 000000G  BIC    #AW$PRT,DW$AW(R2);Direct output to terminal
22         ;
23         ; Finished
24         ;
25 004724   000207       9$:   RETURN
```

TCLERS -- Erase within a line

```

1          .SBTTL  TCLERS -- Erase within a line
2          ;-----
3          ; Erase within a line.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ; R5 = Pointer to start of parameter value
8          ;
9 004726   TCLERS:
10         ;
11         ; Accrue parameter value to determine what type of erase this is
12         ;
13 004726  004737  002116'      CALL    CSPARM      ;Accrue parameter value
14 004732  005700              TST      RO          ;Parameter = 0?
15 004734  001003              BNE     1$          ;Br if not
16 004736  004737  005632'      CALL    ERSCTL     ;Erase from cursor to end of line
17 004742  000413              BR      9$
18 004744  020027  000001      1$:    CMP     RO,#1      ;Parameter = 1?
19 004750  001003              BNE     2$          ;Br if not
20 004752  004737  005744'      CALL    ERSLTC     ;Erase from beginning of line to cursor
21 004756  000405              BR      9$
22 004760  020027  000002      2$:    CMP     RO,#2      ;Parameter = 2?
23 004764  001002              BNE     9$          ;Br if not
24 004766  004737  005546'      CALL    ERSLIN     ;Erase entire line
25         ;
26         ; Finished
27         ;
28 004772  000207      9$:    RETURN

```

TCPERS -- Erase within a page

```

1          .SBTTL  TCPERS -- Erase within a page
2          ;-----
3          ; Erase characters within the current page.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ; R5 = Pointer to start of parameter value
8          ;
9 004774   TCPERS:
10         ;
11         ; Accrue parameter value and determine how much to erase
12         ;
13 004774   004737   002116'       CALL    CSPARM       ;Accrue parameter
14 005000   005700           TST      R0                ;Parameter = 0?
15 005002   001003           BNE     1$                ;Br if not
16 005004   004737   006030'       CALL    ERSCTP       ;Erase from cursor to end of page
17 005010   000413           BR      9$
18 005012   020027   000001   1$:   CMP      R0,#1        ;Parameter = 1?
19 005016   001003           BNE     2$                ;Br if not
20 005020   004737   006112'       CALL    ERSPTC       ;Erase from beginning of page to cursor
21 005024   000405           BR      9$
22 005026   020027   000002   2$:   CMP      R0,#2        ;Parameter = 2?
23 005032   001002           BNE     9$                ;Br if not
24 005034   004737   006210'       CALL    ERSPAG       ;Erase entire page
25         ;
26         ; Finished
27         ;
28 005040   000207   9$:   RETURN

```

TCSSR -- Set scrolling region

```

1          .SBTTL  TCSSR  -- Set scrolling region
2          ;-----
3          ; Set the scrolling region.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ; R5 = Pointer to parameter values
8          ;
9 005042   TCSSR:
10         ;
11         ; Accrue scrolling region top value
12         ;
13 005042  004737  002116'      CALL  CSPARM      ;Accrue scrolling region top line
14 005046  005700              TST    R0            ;Was top line number specified?
15 005050  001002              BNE    1$           ;Br if yes
16 005052  012700  000001      MOV    #1,R0          ;Set 1 as top line
17 005056  010062  0000000    1$:  MOV    R0,DW$SRT(R2) ;Set top line of scrolling region
18         ;
19         ; Accrue scrolling region bottom value
20         ;
21 005062  004737  002116'      CALL  CSPARM      ;Accrue scrolling region bottom line
22 005066  005700              TST    R0            ;Was bottom line specified?
23 005070  001002              BNE    2$           ;Br if yes
24 005072  016200  0000000    MOV    DW$LPP(R2),R0 ;Set last line as bottom of region
25 005076  010062  0000000    2$:  MOV    R0,DW$SRB(R2) ;Set bottom line of scrolling region
26         ;
27         ; Set the cursor to the home position
28         ;
29 005102  004737  005110'      CALL  SETHOM     ;Set cursor to home position
30         ;
31         ; Finished
32         ;
33 005106  000207              RETURN

```

SETHOM -- Set cursor to the home position

```

1          .SBTTL  SETHOM -- Set cursor to the home position
2          ;-----
3          ; This routine is called to set the current cursor position to
4          ; home.  The home line depends on whether absolute or relative
5          ; origin has been selected.
6          ;
7          ; Inputs:
8          ; R2 = Pointer to window control block.
9          ;
10         SETHOM:
11         ;
12         ; Set the cursor line number.
13         ; See if absolute or relative origin has been selected.
14         ;
15         005110 032762 0000000 0000000      BIT    #AW$ORS,DW$AW(R2); Is origin relative to scroll region?
16         005116 001403                      BEQ    1$          ; Br if not
17         005120 016200 0000000              MOV    DW$SRT(R2),RO  ; Say cursor is at top of scroll reg
18         005124 000402                      BR     2$
19         005126 012700 000001              1$:  MOV    #1,RO          ; Say cursor is at line 1
20         005132 004737 006702'            2$:  CALL   SETLIN        ; Set the line number
21         ;
22         ; Set column to 1
23         ;
24         005136 012762 000001 0000000      MOV    #1,DW$COL(R2) ; Say cursor is at column 1
25         ;
26         ; Finished
27         ;
28         005144 000207                      RETURN

```

SCRLUP -- Scroll screen up one line

```

1          .SBTTL  SCRLUP -- Scroll screen up one line
2          ;-----
3          ; Scroll the screen up one line.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block.
7          ;
8 005146  010346  SCRLUP: MOV     R3,-(SP)
9 005150  010446          MOV     R4,-(SP)
10 005152  010546          MOV     R5,-(SP)
11          ;
12          ; See if we are allowed to scroll any more lines
13          ;
14 005154  012700  000001          MOV     #1,R0          ;We are scrolling up one line
15 005160  004737  005414'        CALL    SCRCHK          ;See if scrolling allowed
16          ;
17          ; If the scrolling region is the entire screen, we can do the scrolling
18          ; by simply changing the number of the top line.
19          ;
20 005164  026227  000000G 000001          CMP     DW$SRT(R2),#1    ;Top line of scrolling region = 1?
21 005172  001013          BNE     2$              ;Br if not
22 005174  026262  000000G 000000G        CMP     DW$SRB(R2),DW$LPP(R2);Scrolling region go to bottom of page?
23 005202  001007          BNE     2$              ;Br if not
24          ;
25          ; Scrolling region covers the entire page
26          ;
27 005204  005362  000000G          DEC     DW$TLN(R2)      ;Change top line number
28 005210  003016          BGT     1$              ;Br if did not just scroll line 1
29 005212  016262  000000G 000000G        MOV     DW$LPP(R2),DW$TLN(R2);Cycle to last line on page
30 005220  000412          BR      1$
31          ;
32          ; The scrolling region does not cover the entire page.
33          ; Move characters from line to line to do the scrolling.
34          ;
35 005222  016203  000000G        2$:    MOV     DW$SRT(R2),R3 ;Get top line # of scrolling region
36 005226  010305        3$:    MOV     R3,R5        ;Set number of line to copy to
37 005230  005203          INC     R3
38 005232  010304          MOV     R3,R4          ;Set number of line to copy from
39 005234  004737  006346'        CALL    CPYLIN         ;Copy characters from one line to another
40 005240  020362  000000G        CMP     R3,DW$SRB(R2)  ;Have we copied all that is needed?
41 005244  103770          BLD     3$              ;Loop if not
42          ;
43          ; Clear the line at the bottom of the scrolling region
44          ;
45 005246  016200  000000G        1$:    MOV     DW$SRB(R2),R0 ;Get # of line at bottom of scrolling regn
46 005252  004737  006232'        CALL    CLRLIN         ;Clear that line
47          ;
48          ; Finished
49          ;
50 005256  012605          MOV     (SP)+,R5
51 005260  012604          MOV     (SP)+,R4
52 005262  012603          MOV     (SP)+,R3
53 005264  000207          RETURN

```

SCRLDN -- Scroll screen down one line

```

1          .SBTTL  SCRLDN -- Scroll screen down one line
2          ;-----
3          ; Scroll the screen down one line.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block.
7          ;
8 005266 010346 SCRLDN: MOV     R3, -(SP)
9 005270 010446      MOV     R4, -(SP)
10 005272 010546      MOV     R5, -(SP)
11         ;
12         ; See if we are allowed to scroll any more lines
13         ;
14 005274 012700 177777      MOV     #-1, R0      ; Say we are scrolling down one line
15 005300 004737 005414'    CALL    SCRCHK      ; See if we are allowed to scroll more
16         ;
17         ; If the scrolling region is the entire screen, we can do the scrolling
18         ; by simply changing the number of the top line.
19         ;
20 005304 026227 0000000 000001      CMP     DW$SRT(R2), #1 ; Top line of scrolling region = 1?
21 005312 001016           BNE     2$           ; Br if not
22 005314 026262 0000000 0000000    CMP     DW$SRB(R2), DW$LPP(R2); Scrolling region go to bottom of page?
23 005322 001012           BNE     2$           ; Br if not
24         ;
25         ; Scrolling region covers the entire page
26         ;
27 005324 005262 0000000           INC     DW$TLN(R2)    ; Change top line number
28 005330 026262 0000000 0000000    CMP     DW$TLN(R2), DW$LPP(R2); Did we just scroll last line?
29 005336 101416           BLOS   1$           ; Br if not
30 005340 012762 000001 0000000    MOV     #1, DW$TLN(R2) ; Cycle back to line 1
31 005346 000412           BR     1$
32         ;
33         ; The scrolling region does not cover the entire page.
34         ; Move characters from line to line to do the scrolling.
35         ;
36 005350 016203 0000000    2$:    MOV     DW$SRB(R2), R3 ; Get bottom line # of scrolling region
37 005354 010305    3$:    MOV     R3, R5      ; Set number of line to copy to
38 005356 005303           DEC     R3
39 005360 010304           MOV     R3, R4      ; Set number of line to copy from
40 005362 004737 006346'    CALL    CPYLIN      ; Copy characters from one line to another
41 005366 020362 0000000    CMP     R3, DW$SRT(R2) ; Have we copied all that is needed?
42 005372 101370           BHI    3$           ; Loop if not
43         ;
44         ; Clear the line at the top of the scrolling region
45         ;
46 005374 016200 0000000    1$:    MOV     DW$SRT(R2), R0 ; Get # of line at top of scrolling regn
47 005400 004737 006232'    CALL    CLRLIN      ; Clear that line
48         ;
49         ; Finished
50         ;
51 005404 012605           MOV     (SP)+, R5
52 005406 012604           MOV     (SP)+, R4
53 005410 012603           MOV     (SP)+, R3
54 005412 000207           RETURN

```

SCRCHK -- Check for scrolling limits

```

1          .SBTTL  SCRCHK -- Check for scrolling limits
2          ;-----
3          ; Determine if we are allowed to scroll the screen any further while the
4          ; job is detached from the terminal.  If we have reached the limit of
5          ; our scrolling, the job is suspended until the terminal is reconnected.
6          ;
7          ; Inputs:
8          ; R0 = +1 if scrolling up, -1 if scrolling down.
9          ; R2 = Pointer to window control block.
10         ;
11 005414 010146  SCRCHK: MOV     R1,-(SP)
12         ;
13         ; See if job is currently attached to terminal
14         ;
15 005416 032762 000000G 000000G      BIT     #AW#DDC,DW$AW(R2);Are we suppressing char display?
16 005424 001426                BEQ     9$           ;Br if not
17 005426 116201 000000G                MOVB   DW$JOB(R2),R1  ;Get number of job
18 005432 032761 000000G 000000G      BIT     #$VNOTT,LSW(R1) ;Is job currently connected to terminal?
19 005440 001420                BEQ     9$           ;Br if yes
20         ;
21         ; Job is not currently attached to the terminal.
22         ; See if we are allowed to scroll an unlimited number of lines.
23         ;
24 005442 116201 000000G                MOVB   DW$MSL(R2),R1  ;Are we allowed to scroll unlimited # lines?
25 005446 002415                BLT     9$           ;Br if yes
26 005450 001412                BEQ     2$           ;Br if no scrolling is allowed
27         ;
28         ; See if this scroll would exceed limit.
29         ;
30 005452 116201 000000G                MOVB   DW$NSL(R2),R1  ;Get # lines scrolled so far
31 005456 060001                ADD     R0,R1         ;Add number scrolled this time
32 005460 110162 000000G                MOVB   R1,DW$NSL(R2) ;Save new total
33 005464 002001                BGE     1$           ;Br if total is positive
34 005466 005401                NEG     R1           ;Get positive line count
35 005470 120162 000000G 1$:        CMPB   R1,DW$MSL(R2) ;Would this exceed max allowed scroll?
36 005474 101402                BLOS   9$           ;Br if not
37         ;
38         ; Suspend job until job reattaches to the terminal
39         ;
40 005476 004737 005506' 2$:        CALL   WINSPN      ;Suspend job
41         ;
42         ; Finished
43         ;
44 005502 012601 9$:        MOV     (SP)+,R1
45 005504 000207                RETURN

```



WINSPN -- Suspend job until it reattaches to terminal

```

1          .SBTTL  WINSPN -- Suspend job until it reattaches to terminal
2          ;-----
3          ; Suspend the execution of a job until it reattaches to a terminal.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ;
8 005506 010146 WINSPN: MOV     R1,-(SP)
9          ;
10         ; Never suspend if we are running at fork level (doing character echoing)
11         ;
12 005510 105737 0000000  TSTB   FRKPRI      ;Are we running at fork level?
13 005514 001012          BNE    9$          ;Br if yes
14         ;
15         ; See if job has reattached to the terminal
16         ;
17 005516 116201 0000000 1$:   MOVB   DW$JOB(R2),R1  ;Get job index number
18 005522 032761 0000000 0000000 BIT    #$VNOTT,LSW(R1) ;Is job attached to terminal?
19 005530 001404          BEQ    9$          ;Br if yes
20         ;
21         ; Suspend the job
22         ;
23 005532          DCALL  PCSPND      ;Suspend execution of the job
24 005540 000766          BR     1$          ;Wait till job reconnects to terminal
25         ;
26         ; Finished
27         ;
28 005542 012601 9$:   MOV    (SP)+,R1
29 005544 000207          RETURN

```

ERSLIN -- Erase the current line

```

1          .SBTTL  ERSLIN -- Erase the current line
2          ;-----
3          ; Erase the current line.  Do not change the line attributes and leave
4          ; the cursor where it is.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ;
9 005546  010346  ERSLIN: MOV      R3, -(SP)
10         ;
11         ; Store blanks with all attributes cleared into all line columns
12         ;
13 005550  016203  0000000  MOV      DW#LPT(R2), R3  ;Get pointer to 1st char in line
14 005554  016200  0000000  MOV      DW#CPL(R2), R0  ;Get number of columns per line
15 005560          1$:  BUFMAP          ;;;Map to display buffer
16 005602  112723  000040  MOV      #40, (R3)+      ;;;Store blank as the character
17 005606  105023          CLR      (R3)+          ;;;Clear all attribute flags
18 005610          UNMAP          ;Restore mapping
19 005624  077023          SOB      R0, 1$      ;Clear entire line
20         ;
21         ; Finished
22         ;
23 005626  012603          MOV      (SP)+, R3
24 005630  000207          RETURN

```

ERSCTL -- Erase from cursor to the end of the line

```

1          .SBTTL  ERSCTL -- Erase from cursor to the end of the line
2          ;-----
3          ; Erase all characters from the cursor position to the end of the line.
4          ; The cursor does not move. Character attributes are reset for all
5          ; erased characters.
6          ;
7          ; Inputs:
8          ; R2 = Pointer to window control block
9          ;
10         ERSCTL:  MOV     R3,-(SP)
11                MOV     R4,-(SP)
12         ;
13         ; Get pointer to current cursor position and to end of line
14         ;
15         MOV     DW$COL(R2),R3 ;Get current column number
16         DEC     R3           ;Convert to column offset
17         ASL     R3           ;Two bytes are used by each column
18         ADD     DW$LPT(R2),R3 ;Point to byte for current column
19         MOV     DW$CPL(R2),R4 ;Get number of columns per line
20         DEC     R4           ;Convert to offset
21         ASL     R4           ;Two bytes per column
22         ADD     DW$LPT(R2),R4 ;Get pointer to byte for last column
23         ;
24         ; Clear the line to blanks
25         ;
26         1$:     BUFMAP ;;;Map to display buffer
27                MOVB   #40,(R3)+ ;;;Store blank as character
28                CLRB   (R3)+ ;;;Clear attribute flags
29                UNMAP ;Restore mapping
30                CMP    R3,R4 ;Finished line?
31                BLOS   1$ ;Loop if not
32         ;
33         ; Finished
34         ;
35         MOV     (SP)+,R4
36         MOV     (SP)+,R3
37         RETURN

```

ERSLTC -- Erase from beginning of line to cursor

```

1          .SBTTL  ERSLTC -- Erase from beginning of line to cursor
2          ;-----
3          ; Erase from the beginning of the line up to and including the character
4          ; pointed to by the cursor.  The cursor does not move.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block.
8          ;
9 005744  010346  ERSLTC: MOV      R3, -(SP)
10         ;
11         ; Set up pointer to start of line and to cursor position
12         ;
13 005746  016203  0000000  MOV      DW$LPT(R2), R3  ;Get pointer to 1st byte for the line
14 005752  016200  0000000  MOV      DW$COL(R2), R0  ;Get current cursor column
15         ;
16         ; Blank the characters
17         ;
18 005756          1$:  BUFMAP          ;;Map to display buffer
19 006000  112723  000040  MOVB     #40, (R3)+      ;;Store blank as the character
20 006004  105023          CLRB     (R3)+          ;;Clear attribute flags
21 006006          UNMAP          ;Restore mapping
22 006022  077023          SOB      R0, 1$      ;Loop if more characters to clear
23         ;
24         ; Finished
25         ;
26 006024  012603  MOV      (SP)+, R3
27 006026  000207  RETURN

```

```

1          .SBTTL  ERSCTP -- Erase from cursor to the end of the page
2          ;-----
3          ; Erase from the current cursor position to the end of the page.
4          ; The cursor does not move.  Line attributes for completely erased
5          ; lines are reset.
6          ;
7          ; Inputs:
8          ; R2 = Pointer to window control block
9          ;
10         006030 010546 ERSCTP: MOV     R5,-(SP)
11         006032 016246 0000000  MOV     DW$LIN(R2),-(SP); Save the current line number
12         ;
13         ; Initialize the line number to the current line
14         ;
15         006036 016205 0000000  MOV     DW$LIN(R2),R5 ; Get current line number
16         ;
17         ; Determine if we are clearing all of the current line
18         ;
19         006042 026227 0000000 000001  CMP     DW$COL(R2),#1 ; Is cursor at column 1 of current line?
20         006050 001403  BEQ     1$ ; Br if yes -- Clear all of current line
21         ;
22         ; Clear from cursor to end of current line
23         ;
24         006052 004737 005632'  CALL   ERSCTL ; Erase to end of current line
25         006056 005205  INC     R5 ; Advance line number
26         ;
27         ; Now clear all lines below current line
28         ;
29         006060 020562 0000000 1$:  CMP     R5,DW$LPP(R2) ; Have we erased all lines?
30         006064 101005  BHI     9$ ; Br if yes
31         006066 010500  MOV     R5,R0 ; Get number of line to be cleared
32         006070 004737 006232'  CALL   CLRLIN ; Clear the line
33         006074 005205  INC     R5 ; Increment line number
34         006076 000770  BR      1$ ; See if there are more to clear
35         ;
36         ; Finished
37         ;
38         006100 012600 9$:  MOV     (SP)+,R0 ; Recover original line number
39         006102 004737 006702'  CALL   SETLIN ; Restore line number
40         006106 012605  MOV     (SP)+,R5
41         006110 000207  RETURN

```

ERSPTC -- Erase from beginning of page to cursor

```

1          .SBTTL  ERSPTC -- Erase from beginning of page to cursor
2          ;-----
3          ; Erase all of the characters from the beginning of the page up to and
4          ; including the character under the cursor.  Line attributes are cleared
5          ; for lines that are completely erased.
6          ;
7          ; Inputs:
8          ; R2 = Pointer to window control block
9          ;
10         006112  010446  ERSPTC:  MOV     R4,-(SP)
11         006114  010546          MOV     R5,-(SP)
12         ;
13         ; Initialize line numbers
14         ;
15         006116  016205  0000000  MOV     DW$LIN(R2),R5  ;Get number of current line
16         006122  012704  0000001  MOV     #1,R4         ;Get number of first line
17         ;
18         ; Erase all lines up to, but not including, current line
19         ;
20         006126  020405  1$:      CMP     R4,R5      ;Have we reached current line?
21         006130  103005          BHIS    2$           ;Br if yes
22         006132  010400          MOV     R4,R0       ;Get number of line to erase
23         006134  004737  006232'  CALL    CLRLIN      ;Erase the line
24         006140  005204          INC     R4          ;Advance the line number
25         006142  000771          BR     1$           ;See if more lines to erase
26         ;
27         ; Erase the line the cursor is on
28         ;
29         006144  010400  2$:      MOV     R4,R0       ;Get number of current line
30         006146  026262  0000000  0000000  CMP     DW$COL(R2),DW$CPL(R2);Is cursor at the end of the line?
31         006154  001003          BNE    3$           ;Br if not
32         006156  004737  006232'  CALL    CLRLIN      ;Clear it
33         006162  000404          BR     9$           ;
34         006164  004737  006702'  3$:      CALL    SETLIN     ;Select current line
35         006170  004737  005744'  CALL    ERSLTC      ;Erase up to cursor
36         ;
37         ; Finished
38         ;
39         006174  010500  9$:      MOV     R5,R0       ;Get back current line number
40         006176  004737  006702'  CALL    SETLIN     ;Select as current line
41         006202  012605          MOV     (SP)+,R5
42         006204  012604          MOV     (SP)+,R4
43         006206  000207          RETURN
44
45

```

```
1 .SBTTL ERSPAG -- Clear entire page to spaces
2 -----
3 ; Clear the entire page to spaces
4 ;
5 ; Inputs:
6 ; R2 = Pointer to window control block
7 ;
8 006210 010546 ERSPA0: MOV R5, -(SP)
9 ;
10 ; Begin loop to clear all lines
11 ;
12 006212 016205 0000000 ; MOV DW$LPP(R2), R5 ; Get last line number
13 006216 010500 1$: MOV R5, R0 ; Get number of line to clear
14 006220 004737 006232' ; CALL CLRLIN ; Clear line to spaces
15 006224 077504 ; SOB R5, 1$ ; Loop if more lines to clear
16 ;
17 ; Finished
18 ;
19 006226 012605 ; MOV (SP)+, R5
20 006230 000207 ; RETURN
```

CLRLIN -- Clear a line to spaces

```

1          .SBTTL  CLRLIN -- Clear a line to spaces
2          ;-----
3          ; Clear a line to spaces and set the line attributes to single high,
4          ; single wide.
5          ;
6          ; Inputs:
7          ; R0 = Number of line to be cleared
8          ; R2 = Pointer to window control block
9          ;
10         CLRLIN: MOV     R3, -(SP)
11         MOV     R4, -(SP)
12         MOV     DW$LIN(R2), -(SP); Save current line number
13         ;
14         ; Select the line to be cleared
15         ;
16         CALL    SETLIN          ; Select line to be cleared
17         ;
18         ; Blank the line
19         ;
20         MOV     DW$LPT(R2), R3  ; Get pointer to start of line
21         MOV     DW$CPL(R2), R4  ; Get # columns in the line
22         1$: BUFMAP              ;;; Map to screen buffer
23         MOV     #40, (R3)+      ;;; Store blank character
24         CLRB   (R3)+           ;;; Clear character attributes
25         UNMAP              ; Restore mapping
26         SOB    R4, 1$         ; Loop if need to store more blanks
27         ;
28         ; Reset line attributes
29         ;
30         CLR     R0              ; Set attribute to 0
31         CALL    SETLAB         ; Reset all line attributes
32         ;
33         ; Finished
34         ;
35         MOV     (SP)+, R0       ; Get back original line #
36         CALL    SETLIN         ; Reselect original line
37         MOV     (SP)+, R4
38         MOV     (SP)+, R3
39         RETURN

```



CPYLIN -- Copy characters from one line to another

```

1          .SBTTL  CPYLIN -- Copy characters from one line to another
2          ;-----
3          ; Copy the characters and attributes from one line to another.
4          ; The line attribute is also copied.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ; R4 = Number of line to copy from
9          ; R5 = Number of line to copy to
10         ;
11 006346 010346 CPYLIN: MOV     R3,-(SP)
12 006350 010446      MOV     R4,-(SP)
13 006352 010546      MOV     R5,-(SP)
14 006354 016246 0000000 MOV    DW$LIN(R2),-(SP); Save current line number
15         ;
16         ; Copy the line attribute byte
17         ;
18 006360 010400      MOV     R4,R0          ;Get source line #
19 006362 004737 006702' CALL   SETLIN        ;Set up info about that line
20 006366 004737 006612' CALL   GETLAB        ;Get line attribute information (to R0)
21 006372 010003      MOV     R0,R3          ;Save line attribute
22 006374 010500      MOV     R5,R0          ;Get dest line #
23 006376 004737 006702' CALL   SETLIN        ;Set up info about that line
24 006402 010300      MOV     R3,R0          ;Get line attribute byte
25 006404 004737 006522' CALL   SETLAB        ;Set line attribute byte
26         ;
27         ; Get pointers to characters in from and to lines
28         ;
29 006410 010400      MOV     R4,R0          ;Get # of line we are copying from
30 006412 004737 006702' CALL   SETLIN        ;Set up information about the line
31 006416 016204 0000000 MOV    DW$LPT(R2),R4  ;Get pointer to 1st char in from line
32 006422 010500      MOV     R5,R0          ;Get # of line we are copying to
33 006424 004737 006702' CALL   SETLIN        ;Set up information about the line
34 006430 016205 0000000 MOV    DW$LPT(R2),R5  ;Get pointer to 1st char in to line
35         ;
36         ; Begin loop to copy the characters
37         ;
38 006434 016200 0000000 MOV    DW$CPL(R2),R0  ;Get # columns to copy
39 006440      1$:  BUFMAP      ;;;Map to screen buffer
40 006462 112425      MOVVB  (R4)+,(R5)+    ;;;Copy character
41 006464 112425      MOVVB  (R4)+,(R5)+    ;;;Copy attribute
42 006466      UNMAP      ;Restore mapping
43 006502 077022      SOB    R0,1$      ;Loop to copy all chars in the line
44         ;
45         ; Finished
46         ;
47 006504 012600      MOV    (SP)+,R0      ;Get back original line #
48 006506 004737 006702' CALL   SETLIN        ;Reselect that line
49 006512 012605      MOV    (SP)+,R5
50 006514 012604      MOV    (SP)+,R4
51 006516 012603      MOV    (SP)+,R3
52 006520 000207      RETURN

```

SETLAB -- Set attributes for current line

```

1          .SBTTL  SETLAB -- Set attributes for current line
2          ;-----
3          ; SETLAB is called to set the line attribute byte for the current line.
4          ;
5          ; Inputs:
6          ;   R0 = Line attribute byte value
7          ;   R2 = Pointer to window control block
8          ;
9 006522  010346  SETLAB: MOV      R3, -(SP)
10         ;
11         ; Compute virtual address of byte with attribute for current line
12         ;
13 006524  016203  0000000  MOV      DW$LIN(R2), R3  ;Get current line number
14 006530  166203  0000000  SUB      DW$TLN(R2), R3  ;Get offset from line at top of buffer
15 006534  002002          BGE      1$              ;Br if line greater than 1st line
16 006536  066203  0000000  ADD      DW$LPP(R2), R3  ;Get offset to line we want
17 006542  062703  0000000  1$: ADD   #VPAR6, R3      ;Add virtual base address
18         ;
19         ; Store the new attribute byte
20         ;
21 006546          BUFMAP          ;;;Map to screen buffer
22 006570  110013  MOV      R0, (R3)        ;;;Store new attribute for line
23 006572          UNMAP          ;Restore mapping
24         ;
25         ; Finished
26         ;
27 006606  012603  MOV      (SP)+, R3
28 006610  000207  RETURN

```

GETLAB -- Get attributes for current line

```

1          .SBTTL  GETLAB -- Get attributes for current line
2          ;-----
3          ; GETLAB is called to get the line attribute byte for the current line.
4          ;
5          ; Inputs:
6          ;   R2 = Pointer to window control block
7          ;
8          ; Outputs:
9          ;   R0 = Line attribute byte for current line.
10         ;
11 006612  010346  GETLAB: MOV      R3, -(SP)
12         ;
13         ; Compute virtual address of byte with attribute for current line
14         ;
15 006614  016203  0000000  MOV      DW$LIN(R2),R3  ;Get current line number
16 006620  166203  0000000  SUB      DW$TLN(R2),R3  ;Get offset from line at top of buffer
17 006624  002002  BGE      1$             ;Br if line greater than 1st line
18 006626  066203  0000000  ADD      DW$LPP(R2),R3  ;Get offset to line we want
19 006632  062703  0000000  1$: ADD   #VPAR6,R3     ;Add virtual base address
20         ;
21         ; Get the attribute byte
22         ;
23 006636  BUFMAP                ;;;Map to screen buffer
24 006660  111300  MOV      (R3),R0       ;;;Get the line attribute byte
25 006662  UNMAP                  ;Restore mapping
26         ;
27         ; Finished
28         ;
29 006676  012603  MOV      (SP)+,R3
30 006700  000207  RETURN

```

SETLIN -- Select a line as current line

```

1          .SBTTL  SETLIN -- Select a line as current line
2          ;-----
3          ; Select a specified line as the current line and set up pointer information
4          ; for it.
5          ;
6          ; Inputs:
7          ; R0 = Line number being selected (1-24)
8          ; R2 = Pointer to window control block
9          ;
10         ; Outputs:
11         ; DW$LIN(R2) = Set to current line number
12         ; DW$LPT(R2) = Virtual address of 1st character on current line
13         ;
14 006702 010146 SETLIN: MOV      R1, -(SP)
15         ;
16         ; Set the current line number in WCB
17         ;
18 006704 010062 0000000 MOV      R0, DW$LIN(R2) ; Set current line number
19         ;
20         ; Compute virtual address of 1st character in this line
21         ;
22 006710 166200 0000000 SUB      DW$TLN(R2), R0 ; Get # lines from top to line wanted
23 006714 002002 BGE     1$ ; Br if top line is LE one wanted
24 006716 066200 0000000 ADD      DW$LPP(R2), R0 ; Add total number of lines per page
25 006722 010001 1$: MOV     R0, R1 ; Get # lines offset to line we want
26 006724 070162 0000000 MUL      DW$CPL(R2), R1 ; Multiply by number of columns per line
27 006730 006301 ASL     R1 ; Times two because of attribute bytes
28 006732 066201 0000000 ADD      DW$LPP(R2), R1 ; Skip over bytes with line attributes
29 006736 062701 0000000 ADD      #VPAR6, R1 ; Add base virtual address
30 006742 010162 0000000 MOV      R1, DW$LPT(R2) ; This is virtual addr of start of line
31         ;
32         ; Finished
33         ;
34 006746 012601 MOV      (SP)+, R1
35 006750 000207 RETURN

```

WINSF -- Switch from a job with a display window

```

1          .SRTTL  WINSF  -- Switch from a job with a display window
2          ;-----
3          ; WINSF is called from TSTTY when we are switching from a job which
4          ; has an active display window.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to display window control block for job being switched from
8          ;
9 006752   WINSF:
10         ;
11         ; Set flag which prevents characters from being passed through to the
12         ; screen.
13         ;
14 006752  052762  0000000 0000000      BIS      #AW$DDC,DW$AW(R2);Don't pass through any more chars
15         ;
16         ; Reset number of lines scrolled since we disconnected from window
17         ;
18 006760  105062  0000000      CLRB     DW$NSL(R2)      ;No lines scrolled yet
19         ;
20         ; Finished
21         ;
22 006764  000207      RETURN

```

WINST -- Switch to job with a window

```

1          .SBTTL  WINST  -- Switch to job with a window
2          ;-----
3          ;  WINST is called from TSTTY when we are switching to a job that has
4          ;  a display window active.
5          ;
6          ;  Inputs:
7          ;  R2 = Pointer to current window control block for job being switched to
8          ;
9 006766  010146  WINST:  MOV     R1, -(SP)
10         ;
11         ;  Get job index number
12         ;
13 006770  116201  0000000  MOVB   DW$JOB(R2), R1  ;Get job index number
14         ;
15         ;  Set flag which will cause the window to be redisplayed when the
16         ;  job resumes execution.
17         ;
18 006774  052761  0000000 0000000  BIS    #$WDISP, LSW6(R1); Set flag saying to redisplay window
19         ;
20         ;  If job is in terminal-output-wait state, restart its execution
21         ;
22 007002  026127  0000000 0000000  CMP    LSTATE(R1), #S$OTWT; TT-output-wait state?
23 007010  001002  BNE    9$                ;Br if not
24 007012  004737  0000000  CALL   FORCEX            ;Restart execution of job
25         ;
26         ;  Finished
27         ;
28 007016  012601  9$:    MOV    (SP)+, R1
29 007020  000207  RETURN

```

```
1 .SBTTL WINDSP -- Redisplay current window for job
2 -----
3 ; WINDSP is called from the scheduler when it is about ready to
4 ; reenter a job whose window needs to be redisplayed.
5 ;
6 ; Inputs:
7 ; R1 = Current job index number
8 ;
9 007022 010246 WINDSP: MOV R2,-(SP)
10 ;
11 ; Reset flag that says window redisplay needed
12 ; and set flag that says a window refresh is being done.
13 ;
14 007024 042761 0000000 0000000 BIC ##WDISP,LSW6(R1);Window redisplay no longer needed
15 007032 052761 0000000 0000000 BIS ##RFRSH,LSW4(R1);Window refresh currently being done
16 ;
17 ; Redisplay current window for job
18 ;
19 007040 016102 0000000 MOV LWINDO(R1),R2 ;Get addr of current window control block
20 007044 001402 BEQ 9$ ;Br if job is not doing windowing
21 007046 004737 007064' CALL REFRSH ;Redisplay window
22 ;
23 ; Finished
24 ;
25 007052 042761 0000000 0000000 9$: BIC ##RFRSH,LSW4(R1);Say window refresh is finished
26 007060 012602 MOV (SP)+,R2
27 007062 000207 RETURN
```

```

1          .SBTTL  REFRSH -- Refresh screen from window contents
2          ;-----
3          ; This routine is called to clear the screen and refresh its contents
4          ; from the screen buffer.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ;
9 007064 010146 REFRSH: MOV     R1,-(SP)
10 007066 010546      MOV     R5,-(SP)
11          ;
12          ; Stop characters from being passed from program to screen while we are
13          ; doing the refresh
14          ;
15 007070 052762 0000000 0000000      BIS     #AW$DDC,DW$AW(R2); Suppress character pass-through
16          ;
17          ; Clear contents of line's output buffer and reset control-0 flag
18          ;
19 007076 116201 0000000      MOV     DW$JOB(R2),R1 ;Get job index number
20 007102      DISABL      ;;; Disable interrupts
21 007110 016161 0000000 0000000      MOV     LOTSIZ(R1),LOTSPC(R1);; Clear contents of line's output buffer
22 007116 016161 0000000 0000000      MOV     LOTNXT(R1),LOTPNT(R1);;
23 007124      ENABL      ; Enable interrupts
24 007132 042761 0000000 0000000      BIC     #$CTRL0,LSW3(R1); Reset control-0 flag
25          ;
26          ; See if we need to turn VT52 emulation mode on or off
27          ;
28 007140 004737 011110'      CALL     GENTEM      ; Check VT52 emulation mode status
29          ;
30          ; Clear the screen
31          ;
32 007144 004737 007612'      CALL     GENCLR      ; Clear the screen
33          ;
34          ; Set overall window attributes
35          ;
36 007150 004737 011240'      CALL     GENWAF      ; Set overall window attributes
37          ;
38          ; Initialize character attribute flags
39          ;
40 007154 005005      CLR     R5      ; No character attribute flags
41          ;
42          ; Begin loop to send each line to the screen
43          ;
44 007156 016246 0000000      MOV     DW$LIN(R2),-(SP); Save current line number
45 007162 012701 0000001      MOV     #1,R1      ; Get 1st line number
46 007166 010100      1$:  MOV     R1,R0      ; Get line number
47 007170 004737 006702'      CALL     SETLIN      ; Select as current line
48 007174 004737 007302'      CALL     SNDLIN      ; Send line to screen
49 007200 005201      INC     R1      ; Increment line number
50 007202 020162 0000000      CMP     R1,DW$LPP(R2) ; Have we done all lines?
51 007206 101767      BLOS    1$      ; Loop if not
52          ;
53          ; Reset line number
54          ;
55 007210 012600      MOV     (SP)+,R0      ; Get back line where we should be
56 007212 004737 006702'      CALL     SETLIN      ; Set this as the current line
57          ;

```



```
58 ; Set up scrolling region status
59 ;
60 007216 004737 010746' CALL GENSSS ;Set up split screen scrolling
61 ;
62 ; Place cursor where it should be
63 ;
64 007222 004737 012104' CALL GENCSR ;Gen cursor positioning commands
65 007226 016200 0000000 MOV DW$COL(R2),R0 ;Get current column number
66 007232 005300 DEC R0 ;Make 1st column be 0
67 007234 116201 0000000 MOVB DW$JOB(R2),R1 ;Get our job number
68 007240 110061 0000000 MOVB R0,LCOL(R1) ;Tell TSTTY where cursor is
69 ;
70 ; Make sure character attribute is set correctly
71 ;
72 007244 120562 0000000 CMPB R5,DW$CCA(R2) ;Is character attribute set correctly?
73 007250 001404 BEQ 2$ ;Br if yes
74 007252 116200 0000000 MOVB DW$CCA(R2),R0 ;Get needed character attribute
75 007256 004737 010122' CALL GENCAF ;Set character attribute
76 ;
77 ; Set up correct character set mapping
78 ;
79 007262 004737 010534' 2$: CALL GENMAP ;Set up correct character set mapping
80 ;
81 ; Now allow characters to be passed to the screen
82 ;
83 007266 042762 0000000 0000000 BIC #AW$DDC,DW$AW(R2);Enable character pass-through
84 ;
85 ; Finished
86 ;
87 007274 012605 9$: MOV (SP)+,R5
88 007276 012601 MOV (SP)+,R1
89 007300 000207 RETURN
```

SNDLIN -- Send line of characters to terminal

```

1          .SBTTL  SNDLIN -- Send line of characters to terminal
2          ;-----
3          ; Send a line of characters from the screen buffer to the terminal.
4          ; The currently selected line is the one sent.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block.
8          ; R5 = Current character attribute flags
9          ;
10         ; Outputs:
11         ; R5 = Character attribute flags for last character on line
12         ;
13 007302 010146  SNDLIN: MOV     R1,-(SP)
14 007304 010346          MOV     R3,-(SP)
15 007306 010446          MOV     R4,-(SP)
16 007310 016246 0000000  MOV     DW$COL(R2),-(SP); Save current column number
17         ;
18         ; Set line attribute flag and determine number of columns to display
19         ;
20 007314 004737 006612'   CALL    GETLAB      ;Get line attribute flags for cur line to R0
21 007320 012701 000120   MOV     #80.,R1     ;Assume 80 columns to display
22 007324 032762 0000000 0000000  BIT     #AW$132,DW$AW(R2); Are we in 132 column mode?
23 007332 001402          BEQ     1$          ;Br if not in 132 col mode
24 007334 012701 000204   MOV     #132.,R1    ;Say we need to display 132 columns
25 007340 132700 0000000  1$:    BITB    #<AL$DHT!AL$DHB!AL$DWD>,R0 ;Double wide line?
26 007344 001401          BEQ     3$          ;Br if not double wide
27 007346 006201          ASR     R1          ;Only need to display half as many chars
28 007350 004737 011622'  3$:    CALL    GENLAF    ;Generate line attribute flag info
29         ;
30         ; Store number of columns to display on top of stack
31         ;
32 007354 020162 0000000   CMP     R1,DW$CPL(R2) ;Are we storing as many cols as needed?
33 007360 101402          BLOS   5$          ;Br if yes
34 007362 016201 0000000   MOV     DW$CPL(R2),R1 ;Get # columns we are storing
35 007366 010146 5$:    MOV     R1,-(SP)    ;Store # columns to display on top of stack
36         ;
37         ; Begin loop to output the characters on the line
38         ;
39 007370 012701 000001   MOV     #1,R1       ;Init column number
40 007374 010162 0000000   MOV     R1,DW$COL(R2) ;Init col where next character goes
41 007400 016203 0000000   MOV     DW$LPT(R2),R3 ;Get pointer to 1st char on this line
42         ;
43         ; Scan over spaces that have no attributes set
44         ;
45 007404 4$:    BUFMAP          ;;;Map to screen buffer
46 007426 112304   MOVVB  (R3)+,R4     ;;;Get character
47 007430 112300   MOVVB  (R3)+,R0     ;;;Get attribute flags for character
48 007432          UNMAP          ;Restore mapping
49 007446 120427 000040   CMPB   R4,#40      ;Is character a space?
50 007452 001005          BNE    2$          ;Br if not
51 007454 120005          CMPB   R0,R5       ;Are attributes changing?
52 007456 001003          BNE    2$          ;Br if yes
53 007460 032700 0000000  BIT     #<AC$BLD!AC$BLK!AC$REV!AC$ULN>,R0 ;Bold, blink, reverse, under
54 007464 001420          BEQ    8$          ;Br if not
55         ;
56         ; We found a character that we need to send.
57         ; (R4 = character, R0 = attribute flags)

```

SNDLIN -- Send line of characters to terminal

```

58      ; Position to correct column for the character.
59      ;
60 007466 020162 0000000 2$:      CMP      R1,DW$COL(R2) ;Are we at correct column now?
61 007472 001404          BEQ      6$          ;Br if yes
62 007474 010046          MOV      RO,-(SP)   ;Save character attribute flags
63 007476 004737 011736'  CALL     GENSPC   ;Generate spaces to move to correct col
64 007502 012600          MOV      (SP)+,RO   ;Restore character attribute flags
65      ;
66      ; See if we need to change attributes for this character
67      ;
68 007504 120005 6$:      CMPB     RO,R5          ;Do we need to change attributes?
69 007506 001402          BEQ      7$          ;Br if not
70 007510 004737 010122'  CALL     GENCAF   ;Set character attribute flags
71      ;
72      ; Send the character to the terminal
73      ;
74 007514 010400 7$:      MOV      R4,RO          ;Get character to send
75 007516 004737 012314'  CALL     GENCHR   ;Send the character to the terminal
76 007522 005262 0000000  INC      DW$COL(R2) ;Increment current column number
77      ;
78      ; Advance to next character
79      ;
80 007526 005201 8$:      INC      R1          ;Increment column number
81 007530 020116          CMP      R1,(SP)   ;Done all columns?
82 007532 101724          BLOS    4$          ;Loop if not
83      ;
84      ; Output carriage-return line-feed at the end of the line
85      ;
86 007534 026262 0000000 0000000  CMP      DW$LIN(R2),DW$LPP(R2);Is this the last line on the page?
87 007542 001414          BEQ      20$         ;Br if yes -- Don't send CR-LF
88 007544 026227 0000000 0000001  CMP      DW$COL(R2),#1 ;Are we still at col 1 (entire line blank)?
89 007552 001404          BEQ      10$         ;Br if yes
90 007554          SEND     #CR          ;Send carriage return
91 007564          10$:      SEND     #LF          ;Send line feed
92      ;
93      ; Finished
94      ;
95 007574 005726 20$:      TST      (SP)+          ;Pop number of columns per line
96 007576 012662 0000000  MOV      (SP)+,DW$COL(R2);Restore cursor column number
97 007602 012604          MOV      (SP)+,R4
98 007604 012603          MOV      (SP)+,R3
99 007606 012601          MOV      (SP)+,R1
100 007610 000207          RETURN

```

GENCLR -- Gen control sequence to clear screen

```

1          .SBTTL  GENCLR -- Gen control sequence to clear screen
2          ;-----
3          ; Generate the appropriate terminal control sequence to clear the screen.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ;
8 007612   GENCLR:
9          ;
10         ; See if we need to generate a VT100 or VT52 sequence
11         ;
12 007612  032762  000000C 000000G      BIT      #<AW$52!AW$52>,DW$AW(R2);VT52?
13 007620  001115                      BNE      1$          ;Br if yes
14         ;
15         ; Generate VT100 sequence
16         ; Reset scrolling region
17         ;
18 007622  004737  012272'      CALL     GENCSI      ;Generate CSI header
19 007626                      SEND     #'r          ;Reset scrolling region
20         ;
21         ; Set absolute origin
22         ;
23 007636  004737  012272'      CALL     GENCSI      ;Generate CSI header
24 007642                      SEND     #'?          ;Send ?
25 007652                      SEND     #'6          ;Send 6
26 007662                      SEND     #'1          ;Send 1
27         ;
28         ; Home cursor and clear to end of screen
29         ;
30 007672  004737  012272'      CALL     GENCSI      ;Generate CSI header
31 007676                      SEND     #'H          ;Send H -- Home cursor
32 007706  004737  012272'      CALL     GENCSI      ;Generate CSI header
33 007712                      SEND     #'J          ;Send J -- Clear to end of screen
34         ;
35         ; Reset character attributes
36         ;
37 007722  004737  012272'      CALL     GENCSI      ;Send CSI O m to reset char attributes
38 007726                      SEND     #'O
39 007736                      SEND     #'m
40         ;
41         ; Map GL to G0 and designate G0 as ascii
42         ;
43 007746                      SEND     #17          ;Send shift-in -- Lock shift G0 to GL
44 007756  004737  012260'      CALL     GENESC      ;Send escape
45 007762                      SEND     #'(          ;Select G0
46 007772                      SEND     #'B          ;Map G0 to ascii
47         ;
48         ; Map GR to G2 and designate G2 as ascii
49         ;
50 010002  032762  000000G 000000G      BIT      #AW$200,DW$AW(R2);Is this a VT200 terminal?
51 010010  001443                      BEQ      9$          ;Br if not -- Don't have to mess with GR
52 010012  004737  012260'      CALL     GENESC      ;Send ESC
53 010016                      SEND     #'}          ;Lock shift GR to G2
54 010026  004737  012260'      CALL     GENESC      ;Send escape
55 010032                      SEND     #'*          ;Select G2
56 010042                      SEND     #'B          ;Designate ascii
57 010052  000422                      BR       9$

```

GENCLR -- Gen control sequence to clear screen

```
58 ;  
59 ; Generate VT52 sequence  
60 ;  
61 010054 004737 012260' 1$: CALL GENESC ;Generate ESC character  
62 010060 SEND #'H ;Send H -- Home cursor  
63 010070 004737 012260' CALL GENESC ;Generate ESC character  
64 010074 SEND #'J ;Send J -- Clear to end of screen  
65 010104 004737 012260' CALL GENESC ;Generate ESC character  
66 010110 SEND #'G ;Select ascii character set  
67 ;  
68 ; Finished  
69 ;  
70 010120 000207 9$: RETURN
```

GENCAF -- Generate sequence to set character attributes

```

1          .SBTTL  GENCAF -- Generate sequence to set character attributes
2          ;-----
3          ; Generate the terminal sequence to set character attributes.
4          ;
5          ; Inputs:
6          ; R0 = Character attribute wanted
7          ; R2 = Pointer to window control block
8          ; R5 = Current character attribute
9          ;
10         ; Outputs:
11         ; R5 = New character attributes
12         ;
13 010122  010146  GENCAF: MOV     R1,-(SP)
14 010124  010346      MOV     R3,-(SP)
15 010126  010446      MOV     R4,-(SP)
16 010130  010001      MOV     R0,R1      ;Carry new attributes in R1
17         ;
18         ; See if we need to change character sets
19         ;
20 010132  004737  010354'  CALL    GENCSC      ;See if we need to do character set change
21         ;
22         ; Don't have to worry about attributes if this is a VT52
23         ;
24 010136  032762  000000C 000000G  BIT     #<AW$52!AW$552>,DW$AW(R2); Is this a VT52?
25 010144  001076      BNE     9$          ;Br if yes
26         ;
27         ; See if character attributes have changed
28         ;
29 010146  010103      MOV     R1,R3      ;Get new attributes
30 010150  010504      MOV     R5,R4      ;Get current attributes
31 010152  042703  000000C  BIC     #^C<AC$BLD!AC$BLK!AC$REV!AC$ULN>,R3
32 010156  042704  000000C  BIC     #^C<AC$BLD!AC$BLK!AC$REV!AC$ULN>,R4
33 010162  020304      CMP     R3,R4      ;Have attributes changed?
34 010164  001466      BEQ     9$          ;Br if not
35         ;
36         ; Initialize control sequence and turn off all attributes
37         ;
38 010166  004737  012272'  CALL    GENCSI      ;Send CSI
39 010172      SEND    #'0      ;Send 0
40         ;
41         ; See if bold is wanted
42         ;
43 010202  032701  000000G  BIT     #AC$BLD,R1   ;Is bold wanted?
44 010206  001410      BEQ     1$          ;Br if not
45 010210      SEND    #SEMI      ;Send ';'
46 010220      SEND    #'1          ;
47         ;
48         ; See if underscore is wanted
49         ;
50 010230  032701  000000G  1$: BIT     #AC$ULN,R1 ;Underline wanted?
51 010234  001410      BEQ     2$          ;Br if not
52 010236      SEND    #SEMI      ;Send ";"
53 010246      SEND    #'4          ;
54         ;
55         ; See if blinking is wanted
56         ;
57 010256  032701  000000G  2$: BIT     #AC$BLK,R1 ;Blinking wanted?

```

```
58 010262 001410          BEQ      3$          ;Br if not
59 010264          SEND     #SEMI      ;Send ";5"
60 010274          SEND     #'5
61                ;
62                ; See if reverse video is wanted
63                ;
64 010304 032701 0000000 3$:     BIT      #AC$REV,R1      ;Reverse video wanted?
65 010310 001410          BEQ      7$          ;Br if not
66 010312          SEND     #SEMI      ;Send ";7"
67 010322          SEND     #'7
68                ;
69                ; Terminate the string by sending "m"
70                ;
71 010332          7$:     SEND     #'m          ;Send "m"
72                ;
73                ; Finished
74                ;
75 010342 010105          9$:     MOV      R1,R5          ;Change current attributes to new attributes
76 010344 012604          MOV      (SP)+,R4
77 010346 012603          MOV      (SP)+,R3
78 010350 012601          MOV      (SP)+,R1
79 010352 000207          RETURN
```

GENCSC -- Generate terminal sequence to select char set

```

1          .SBTTL  GENCSC -- Generate terminal sequence to select char set
2          ;-----
3          ; Generate terminal control sequence to select the correct character
4          ; set for the next character.
5          ;
6          ; Inputs:
7          ; R0 = Character attribute wanted
8          ; R2 = Pointer to window control block
9          ; R5 = Current character attribute
10         ;
11 010354 010046 GENCSC: MOV     R0, -(SP)
12 010356 010146      MOV     R1, -(SP)
13 010360 010346      MOV     R3, -(SP)
14 010362 010446      MOV     R4, -(SP)
15 010364 010001      MOV     R0, R1          ; Carry new attributes in R1
16         ;
17         ; Determine if character set has changed
18         ;
19 010366 010103      MOV     R1, R3          ; Get new attributes
20 010370 042703 000000C BIC     #^C<AC$SET>, R3 ; Select character set number only
21 010374 010504      MOV     R5, R4          ; Get current attributes
22 010376 042704 000000C BIC     #^C<AC$SET>, R4 ; Select character set number only
23 010402 020304      CMP     R3, R4          ; Has character set changed?
24 010404 001443      BEQ     9$          ; Br if char set has not changed
25         ;
26         ; Character set has changed
27         ;
28 010406 032762 000000C 000000G BIT     #<AW$52!AW$552>, DW$AW(R2); Is this a VT52 terminal?
29 010414 001031      BNE     1$          ; Br if VT52
30         ;
31         ; VT100/VT200 terminal.
32         ; Generate sequence to map G0 and G2 to correct character set
33         ;
34 010416 004737 012260' CALL    GENESC          ; Send ESC character
35 010422      SEND    #'(          ; Select G0
36 010432      SEND    SET200(R3)    ; Send char to map G0 to correct char set
37 010442 032762 000000G 000000G BIT     #AW$200, DW$AW(R2); Is this a VT200 terminal?
38 010450 001421      BEQ     9$          ; Br if not -- Don't need to change G2
39 010452 004737 012260' CALL    GENESC          ; Send ESC character
40 010456      SEND    #'*          ; Select G2
41 010466      SEND    SET200(R3)    ; Send char to map G2 to correct char set
42 010476 000406      BR     9$
43         ;
44         ; VT52 terminal.
45         ; Select ascii or graphics character set.
46         ;
47 010500 004737 012260' 1$: CALL    GENESC          ; Send ESC character
48 010504      SEND    SET52(R3)    ; Select ascii or graphics characters
49         ;
50         ; Finished
51         ;
52 010514 012604 9$: MOV     (SP)+, R4
53 010516 012603      MOV     (SP)+, R3
54 010520 012601      MOV     (SP)+, R1
55 010522 012600      MOV     (SP)+, R0
56 010524 000207      RETURN
57         ;

```



GENCSC -- Generate terminal sequence to select char set

```
58 ; Characters to be sent to change GO character set designation
59 ;
60 010526 102 074 101 SET200: .ASCII /B<AO/
   010531 060
61 ;
62 ; Characters to select ascii or graphics mode on a VT52
63 ;
64 010532 107 106 SET52: .ASCII /GF/
65 .EVEN
```

GENMAP -- Generate sequence to set up char set mapping

```

1          .SBTTL  GENMAP -- Generate sequence to set up char set mapping
2          ;-----
3          ; Generate control sequence to set up the correct character set
4          ; mapping for GL, GR, G0, G1, G2, and G3.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ;
9 010534 010346 GENMAP: MOV     R3, -(SP)
10 010536 032762 000000C 000000G BIT     #<AW$52!AW$552>, DW$AW(R2); Is this a VT52 terminal?
11 010544 001060          BNE     5$          ; Br if VT52
12          ;
13          ; This is a VT100/VT200 terminal.
14          ; Set up mapping for GL.
15          ;
16 010546 116203 000000G          MOVVB  DW$GLM(R2), R3 ; Get mapping for GL
17 010552 120327 000001          CMPB  R3, #1          ; Mapping to G0 or G1?
18 010556 101402          BLOS  1$          ; Br if yes
19 010560 004737 012260'          CALL  GENESC          ; Send ESC
20 010564          1$: SEND   LSLCHR(R3) ; Send correct lock shift character
21          ;
22          ; Set up mapping for GR
23          ;
24 010574 032762 000000G 000000G BIT     #AW$200, DW$AW(R2); Is this a VT200?
25 010602 001410          BEQ     2$          ; Br if not -- Don't need to mess with GR
26 010604 116203 000000G          MOVVB  DW$GRM(R2), R3 ; Get mapping for GR
27 010610 004737 012260'          CALL  GENESC          ; Send ESC
28 010614          SEND   LSRCHR(R3) ; Send correct lock shift character
29          ;
30          ; Set up mapping for G0, G1, G2, and G3
31          ;
32 010624 012703 000001          2$: MOV     #1, R3          ; Assume we only need to map G0 and G1
33 010630 032762 000000G 000000G BIT     #AW$200, DW$AW(R2); Is this a VT200?
34 010636 001402          BEQ     3$          ; Br if not
35 010640 012703 000003          MOV     #3, R3          ; Map G2 and G3 too
36 010644 004737 012260'          3$: CALL  GENESC          ; Send ESC
37 010650          SEND   GNMCHR(R3) ; Select G#
38 010660 010300          MOV     R3, R0          ; Get G number
39 010662 060200          ADD     R2, R0          ; Point into window control block
40 010664 116000 000000G          MOVVB  DW$GOM(R0), R0 ; Get mapping wanted for G#
41 010670          SEND   SET200(R0) ; Set mapping for the G#
42 010700 005303          DEC     R3          ; Have more G# to do?
43 010702 002360          BGE     3$          ; Loop if yes
44 010704 000410          BR      9$
45          ;
46          ; Set up mapping for a VT52 terminal
47          ;
48 010706 004737 012260'          5$: CALL  GENESC          ; Generate ESC character
49 010712 116203 000000G          MOVVB  DW$GOM(R2), R3 ; Get ascii/graphics mapping code
50 010716          SEND   SET52(R3) ; Select correct mapping
51          ;
52          ; Finished
53          ;
54 010726 012603          9$: MOV     (SP)+, R3
55 010730 000207          RETURN
56          ;
57          ; Characters used to lock shift a mapping into GL

```

```
58 ;  
59 010732 017 016 156 LSLCHR: .ASCII <17><16>/no/  
010735 157  
60 ;  
61 ; Characters used to lock shift a mapping into GR  
62 ;  
63 010736 077 176 175 LSRCHR: .ASCII /?~}!/  
010741 174  
64 ;  
65 ; Characters used to select G0, G1, G2, or G3 for mapping  
66 ;  
67 010742 050 051 052 GNMCHR: .ASCII /()*+/  
010745 053  
68 .EVEN
```

```

1          .SBTTL  GENSSS -- Generate sequence for split screen scrolling
2          ;-----
3          ; Generate the terminal control sequence needed to set the terminal to
4          ; split screen scrolling mode if that is needed.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ;
9 010746   GENSSS:
10         ;
11         ; We never set split screen scrolling for VT52 terminals
12         ;
13 010746   032762 0000000 0000000      BIT      #<AW$52!AW$S52>,DW$AW(R2);Is this a VT52?
14 010754   001054          BNE      9$          ;Br if yes
15         ;
16         ; See if we need to set split screen scrolling
17         ;
18 010756   026227 0000000 0000001      CMP      DW$SRT(R2),#1      ;Is top line of scrolling region 1?
19 010764   001004          BNE      2$          ;Br if not
20 010766   026262 0000000 0000000      CMP      DW$SRB(R2),DW$LPP(R2);Is bottom scroll line bottom of page?
21 010774   001444          BEQ      9$          ;Br if yes
22         ;
23         ; Declare scrolling region
24         ;
25 010776   004737 012272' 2$:      CALL      GENCSI          ;Generate CSI character
26 011002   016200 0000000      MOV      DW$SRT(R2),R0      ;Get top line # of scrolling region
27 011006   004737 012334'      CALL      GENVAL          ;Cvt to ascii digits and send them
28 011012          SEND      #SEMI          ;Send semicolon
29 011022   016200 0000000      MOV      DW$SRB(R2),R0      ;Get bottom line of scrolling region
30 011026   004737 012334'      CALL      GENVAL          ;Cvt to ascii digits and send them
31 011032          SEND      #'r          ;Terminate control sequence
32         ;
33         ; See if we need to set relative origin mode
34         ;
35 011042   032762 0000000 0000000      BIT      #AW$ORS,DW$AW(R2);Is origin to be relative to scroll region?
36 011050   001416          BEQ      9$          ;Br if not
37 011052   004737 012272'      CALL      GENCSI          ;Generate CSI character
38 011056          SEND      #'?          ;Send ?
39 011066          SEND      #'6          ;Send 6
40 011076          SEND      #'h          ;Send h
41         ;
42         ; Finished
43         ;
44 011106   000207 9$:      RETURN

```

```

1          .SBTTL  GENTEM -- Turn VT52 emulation mode on or off
2          ;-----
3          ; Generate the terminal control sequence to turn VT52 emulation mode
4          ; on or off as needed by this window.
5          ;
6          ; Inputs:
7          ;   R2 = Pointer to window control block
8          ;
9          ;
10         ; See if we need to go into VT52 emulation mode
11         ;
12 011110 116200 0000000  GENTEM: MOVB  DW#JOB(R2),R0  ;Get our job index number
13 011114 116000 0000000  MOVB  LNPRIM(R0),R0  ;Get our primary line index number
14 011120 032762 0000000 0000000  BIT   #AW#S52,DW#AW(R2) ;Does window want VT52 emulation mode?
15 011126 001426          BEQ   2$          ;Br if not
16 011130 032760 0000000 0000000  BIT   ##V52EM,LSW11(R0);Is VT52 emulation mode on now?
17 011136 001037          BNE   9$          ;Br if yes
18 011140 052760 0000000 0000000  BIS   ##V52EM,LSW11(R0);Say we are turning on VT52 emulation
19 011146 004737 012272'  CALL  GENCSI          ;Send CSI character
20 011152          SEND  #'?          ;Send "?21" to reset ANSI mode
21 011162          SEND  #'2
22 011172          SEND  #'1
23 011202 000415          BR    9$
24         ;
25         ; See if we need to turn off VT52 emulation mode
26         ;
27 011204 032760 0000000 0000000 2$:  BIT   ##V52EM,LSW11(R0);Is VT52 emulation mode on now?
28 011212 001411          BEQ   9$          ;Br if not
29 011214 042760 0000000 0000000  BIC   ##V52EM,LSW11(R0);Say we are turning off VT52 emulation
30 011222 004737 012260'  CALL  GENESC          ;Send ESC
31 011226          SEND  #'<          ;Tell VT52 to enter ANSI mode
32         ;
33         ; Finished
34         ;
35 011236 000207          9$:  RETURN

```

GENWAF -- Generate terminal sequence to set window attrib

```

1          .SBTTL  GENWAF -- Generate terminal sequence to set window attrib
2          ;-----
3          ; Generate the terminal control sequence needed to set attributes for
4          ; the entire window.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ;
9 011240 010346 GENWAF: MOV     R3,-(SP)
10 011242 010446      MOV     R4,-(SP)
11          ;
12          ; Get control flags for the window attributes
13          ;
14 011244 016203 0000000 MOV     DW$AW(R2),R3 ;Get window attribute flags
15          ;
16          ; Generate control sequence to reset some flags
17          ;
18 011250 005103      COM     R3 ;Set flags that should be reset
19 011252 012704 000154 MOV     #'l,R4 ;Terminate string with lower-case L
20 011256 004737 011350' CALL    GENAAS ;Generate for ANSI attributes
21 011262 004737 011412' CALL    GENDAS ;Generate for DEC attributes
22          ;
23          ; Generate control sequence to set some flags
24          ;
25 011266 005103      COM     R3 ;Set flags that should be set
26 011270 012704 000150 MOV     #'h,R4 ;Terminate string with lower-case H
27 011274 004737 011350' CALL    GENAAS ;Generate for ANSI attributes
28 011300 004737 011412' CALL    GENDAS ;Generate for DEC attributes
29          ;
30          ; See if we should set or reset application keypad mode
31          ;
32 011304 004737 012260' CALL    GENESC ;Send escape
33 011310 032762 0000000 0000000 BIT     #AW$AKM,DW$AW(R2);Is application keypad mode wanted?
34 011316 001405      BEQ     1$ ;Br if not
35 011320      SEND    #'= ;Send equal sign
36 011330 000404      BR     9$
37 011332      1$: SEND    #'> ;Send greater-than sign
38          ;
39          ; Finished
40          ;
41 011342 012604      9$: MOV     (SP)+,R4
42 011344 012603      MOV     (SP)+,R3
43 011346 000207      RETURN

```

```
1 .SBTTL GENAAS -- Generate control sequence for ANSI attributes
2 ;-----
3 ; Generate the control sequence to set or reset ANSI attribute flags.
4 ;
5 ; Inputs:
6 ; R2 = Pointer to window control block
7 ; R3 = Word with flags
8 ; R4 = Character to terminate string with
9 ;
10 011350 GENAAS:
11 ;
12 ; Don't send anything if this is a VT52
13 ;
14 011350 032762 0000000 0000000 BIT #<AW$52!AW$552>,DW$AW(R2);Is this a VT52?
15 011356 001014 BNE 9$ ;Br if yes
16 ;
17 ; See if insert mode is wanted
18 ;
19 011360 032703 0000000 BIT #AW$INS,R3 ;Insert mode wanted?
20 011364 001411 BEQ 9$ ;Br if not
21 011366 004737 012272' CALL GENCSI ;Send CSI character
22 011372 SEND #'4 ;Send 4
23 011402 SEND R4 ;terminate string
24 ;
25 ; Finished
26 ;
27 011410 000207 9$: RETURN
```

GENDAS -- Generate control sequence for DEC attributes

```

1          .SBTTTL  GENDAS -- Generate control sequence for DEC attributes
2          ;-----
3          ; Generate a terminal control sequence to set or reset DEC attributes.
4          ;
5          ; Inputs:
6          ;   R2 = Pointer to window control block
7          ;   R3 = AW#xxx attribute flags
8          ;   R4 = Character to terminate string with
9          ;
10         011412  010146  GENDAS:  MOV     R1, -(SP)
11         011414  010346          MOV     R3, -(SP)
12         011416  010546          MOV     R5, -(SP)
13         ;
14         ; We don't have to set any DEC private attributes for VT52 terminals.
15         ;
16         011420  032762  000000C 000000G      BIT     #<AW$52!AW$552>, DW$AW(R2); Is this a VT52?
17         011426  001056          BNE     9$          ;Br if VT52
18         ;
19         ; VT100/VT200
20         ; If this is a VT100, clear VT200-only attribute flags.
21         ;
22         011430  032762  000000G 000000G      BIT     #AW$200, DW$AW(R2); Is this a VT200?
23         011436  001002          BNE     5$          ;Br if VT200
24         011440  042703  000000G          BIC     #AW$VCR, R3      ;Clear VT200-only flags
25         ;
26         ; Init flag that says string hasn't been initiated yet
27         ;
28         011444  005005  5$:      CLR     R5          ;Nothing sent yet
29         ;
30         ; Begin loop to decide what values need to be sent
31         ;
32         011446  012701  011574'          MOV     #DECAT, R1      ;Point to attribute table
33         ;
34         ; See if next attribute needs to be selected
35         ;
36         011452  036103  0000002  1$:      BIT     2(R1), R3      ;Is this attribute needed?
37         011456  001431          BEQ     4$          ;Br if not
38         ;
39         ; We need to select this attribute, see if we need to send
40         ; CSI to start the string or semicolon to separate parameter values
41         ;
42         011460  005705          TST     R5          ;Have we initiated the string?
43         011462  001010          BNE     2$          ;Br if yes
44         011464  004737  012272'          CALL   GENCSI        ;Send CSI character
45         011470          SEND    #'?          ;Send question mark
46         011500  005205          INC     R5          ;Remember string started
47         011502  000404          BR     3$          ;
48         011504  2$:      SEND    #SEMI        ;Send semicolon
49         ;
50         ; Now send the parameter value to selete the attribute
51         ;
52         011514  011100  3$:      MOV     (R1), R0      ;Get parameter value for attribute
53         011516  004737  012334'          CALL   GENVAL        ;Convert value to digit string and send
54         ;
55         ; If this is a VT100, terminate the string for each attribute.
56         ;
57         011522  032762  000000G 000000G      BIT     #AW$200, DW$AW(R2); VT200?

```



GENDAS -- Generate control sequence for DEC attributes

```

58 011530 001004          BNE      4$          ;Br if yes
59 011532                SEND     R4          ;Send terminating character
60 011540 005000          CLR      R5          ;Say string is not in progress
61                      ;
62                      ; See if more attributes need to be selected
63                      ;
64 011542 062701 000004 4$:  ADD     #4,R1        ;Point to next attribute entry
65 011546 005711          TST     (R1)        ;Reached end of table?
66 011550 001340          BNE     1$          ;Loop if not
67                      ;
68                      ; If we started the string, terminate it
69                      ;
70 011552 005705          TST     R5          ;Did we start the string?
71 011554 001403          BEQ     9$          ;Br if not
72 011556                SEND     R4          ;Send terminating character
73                      ;
74                      ; Finished
75                      ;
76 011564 012605          9$:  MOV     (SP)+,R5
77 011566 012603          MOV     (SP)+,R3
78 011570 012601          MOV     (SP)+,R1
79 011572 000207          RETURN
80                      ;
81                      ;-----
82                      ; Table of attribute values and DEC attribute flags
83                      ;
84 011574 000001 0000000 DECAT: .WORD 1,AW$ACK      ;Application mode for cursor keys
85 011600 000003 0000000 .WORD 3,AW$132      ;132 column mode
86 011604 000005 0000000 .WORD 5,AW$REV      ;Reverse video mode
87 011610 000010 0000000 .WORD 8,AW$RPT      ;Automatic keypad repeat
88 011614 000031 0000000 .WORD 25,AW$VCR     ;Make cursor visible
89 011620 000000          .WORD 0          ;End of table

```

```

1          .SBTTL  GENLAF -- Generate terminal sequence to set line attrib
2          ;-----
3          ; Generate the terminal control sequence needed to set the line attribute.
4          ;
5          ; Inputs:
6          ; RO = Line attribute flags (AL$xxx)
7          ;
8 011622 010546 GENLAF: MOV     R5,-(SP)
9 011624 010005         MOV     RO,R5          ;Get attribute flags
10         ;
11         ; See if double height wanted
12         ;
13 011626 032705 0000000 BIT     #<AL$DHT!AL$DHB>,R5; Double high wanted?
14 011632 00142?     BEQ     1$          ;Br if not
15 011634 004737 012260' CALL    GENESC          ;Send ESC
16 011640         SEND    #'#          ;Send "#"
17 011650 032705 0000000 BIT     #AL$DHT,R5      ;Top or bottom half of char?
18 011654 00140?     BEQ     2$          ;Br if bottom
19 011656         SEND    #'3          ;Send 3
20 011666 000404     BR      1$
21 011670 2$:        SEND    #'4          ;Send 4
22         ;
23         ; See if double width is wanted
24         ;
25 011700 032705 0000000 1$:        BIT     #AL$DWD,R5      ;Is double width wanted?
26 011704 00141?     BEQ     9$          ;Br if not
27 011706 004737 012260' CALL    GENESC          ;Send ESC
28 011712         SEND    #'#          ;Send "#"
29 011722         SEND    #'6          ;Send 6
30         ;
31         ; Finished
32         ;
33 011732 012605 9$:        MOV     (SP)+,R5
34 011734 000207         RETURN

```

GENSPC -- Generate sequence to move cursor over

```

1          .SBTTL  GENSPC -- Generate sequence to move cursor over
2          ;-----
3          ; Generate spaces or a control sequence to move the cursor right
4          ; from the current cursor position (specified by DW$COL(R2)) to
5          ; a specified column.
6          ;
7          ; Inputs:
8          ;   R2 = Pointer to window control block
9          ;   R1 = Column number we are to move to
10         ;
11 011736 010346 GENSPC: MOV      R3,-(SP)
12         ;
13         ; Determine how many columns we want to move over
14         ;
15 011740 010103         MOV      R1,R3          ;Get destination column
16 011742 166203 0000006 SUB      DW$COL(R2),R3      ;Subtract current column number
17 011746 003452         BLE      9$           ;Br if don't need to move at all
18         ;
19         ; If we need to move no more than 5 columns, output spaces
20         ;
21 011750 020327 000005         CMP      R3,#5          ;Need to move more than 5 columns?
22 011754 003006         BGT      2$           ;Br if yes
23 011756         1$: SEND      #40          ;Send a space
24 011766 077305         SOB      R3,1$       ;Loop to send more
25 011770 000441         BR       9$           ;Finished
26         ;
27         ; We need to move more than 5 columns; generate control sequence.
28         ; Determine terminal type.
29         ;
30 011772 032762 000000C 0000006 2$: BIT      #<AW$52!AW$S52>,DW$AW(R2);VT52 terminal?
31 012000 001012         BNE      5$           ;Br if VT52
32         ;
33         ; Generate control sequence for VT100
34         ;
35 012002 004737 012272'         CALL     GENCSI          ;Generate CSI header
36 012006 010300         MOV      R3,R0          ;Get # columns we need to move
37 012010 004737 012334'         CALL     GENVAL          ;Convert and output that value
38 012014         SEND      #'C           ;Terminate control sequence
39 012024 000423         BR       9$
40         ;
41         ; Generate control sequence for VT52
42         ;
43 012026 004737 012260'         5$: CALL     GENESC          ;Generate escape
44 012032         SEND      #'Y           ;Start of cursor addressing sequence
45 012042 016200 0000006         MOV      DW$LIN(R2),R0      ;Get current line number
46 012046 062700 000037         ADD      #37,R0          ;Form ascii char for line number
47 012052         SEND      R0           ;Send it
48 012060 010100         MOV      R1,R0          ;Get wanted column number
49 012062 062700 000037         ADD      #37,R0          ;Form ascii char for column number
50 012066         SEND      R0           ;Send it
51         ;
52         ; Change current column number
53         ;
54 012074 010162 0000006         9$: MOV      R1,DW$COL(R2)      ;Say we have moved up to this column
55         ;
56         ; Finished
57         ;

```

58 012100 012603  
59 012102 000207

MOV (SP)+, R3  
RETURN

GENCSR -- Generate cursor addressing sequence

```

1          .SBTTL  GENCSR -- Generate cursor addressing sequence
2          ;-----
3          ; Generate the appropriate terminal control sequence to move the
4          ; cursor to the current line and column.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ; DW$LIN(R2) = Current line number
9          ; DW$COL(R2) = Current column number
10         ;
11 012104  GENCSR:
12         ;
13         ; Determine what type of terminal this is
14         ;
15 012104  032762  000000C 000000G          BIT    #<AW$52!AW$552>,DW$AW(R2);Is this a VT52?
16 012112  001035          BNE    5$          ;Br if VT52
17         ;
18         ; Generate sequence for a VT100
19         ;
20 012114  004737  012272'          CALL   GENCSI          ;Generate CSI character
21 012120  016200  000000G          MOV    DW$LIN(R2),RO    ;Get line number
22 012124  032762  000000G 000000G          BIT    #AW$ORS,DW$AW(R2);Is origin relative to scroll region?
23 012132  001406          BEQ    1$          ;Br if not
24 012134  166200  000000G          SUB    DW$SRT(R2),RO    ;Subtract top line of scroll region
25 012140  005200          INC    RO              ;1st line is 1
26 012142  003002          BGT    1$          ;Br if we are within scroll region
27 012144  012700  000001          MOV    #1,RO          ;Force to 1st line of scroll region
28 012150  004737  012334'          1$:   CALL   GENVAL          ;Convert to ascii digit string
29 012154          SEND   #SEMI          ;Send semicolon
30 012164  016200  000000G          MOV    DW$COL(R2),RO    ;Get column number
31 012170  004737  012334'          CALL   GENVAL          ;Convert to ascii digit string
32 012174          SEND   #'H          ;Terminate sequence
33 012204  000424          BR    9$
34         ;
35         ; Generate control sequence for VT52
36         ;
37 012206  004737  012260'          5$:   CALL   GENESC          ;Generate escape
38 012212          SEND   #'Y          ;Start of cursor addressing sequence
39 012222  016200  000000G          MOV    DW$LIN(R2),RO    ;Get current line number
40 012226  062700  000037          ADD    #37,RO          ;Form ascii char for line number
41 012232          SEND   RO              ;Send it
42 012240  016200  000000G          MOV    DW$COL(R2),RO    ;Get current column number
43 012244  062700  000037          ADD    #37,RO          ;Form ascii char for column number
44 012250          SEND   RO              ;Send it
45         ;
46         ; Finished
47         ;
48 012256  000207          9$:   RETURN

```

GENESC -- Generate escape character

```

1          .SBTTL  GENESC -- Generate escape character
2          ;-----
3          ; Send an escape character to the terminal
4          ;
5 012260   GENESC: SEND   #33          ;Send escape to the terminal
6 012270   000207   RETURN
7
8          .SBTTL  GENCSI -- Generate CSI character sequence
9          ;-----
10         ; Send a CSI (ESC [) sequence to the terminal.
11         ;
12 012272   GENCSI:
13         ;
14         ; Send 8-bit CSI character to VT200 terminals
15         ;
16         ;     BIT      #AW$200,DW$AW(R2);Is this a VT200 terminal?
17         ;     BEQ      1$          ;Br if not
18         ;     SEND     #CSICHR     ;Send 8-bit CSI character to VT200
19         ;     BR       9$
20         ;
21         ; Send ESC [ to VT100 terminals
22         ;
23 012272   1$:      SEND     #33          ;Send escape
24 012302   SEND     #'[           ;Send "["
25         ;
26         ; Finished
27         ;
28 012312   000207   9$:      RETURN
29
30         .SBTTL  GENCHR -- Send a character to the terminal
31         ;-----
32         ; Send a single character to the terminal
33         ;
34         ; Inputs:
35         ;   R0 = Character to be sent
36         ;   R2 = Pointer to window control block
37         ;
38 012314   010146   GENCHR: MOV     R1,-(SP)
39 012316   116201   0000006   MOVB   DW$JOB(R2),R1  ;Get # of job we are sending to
40 012322   DCALL   BUFCHR     ;Send the character
41 012330   012601   MOV     (SP)+,R1
42 012332   000207   RETURN

```

GENVAL -- Convert value to digits and send

```

1          .SBTTL  GENVAL -- Convert value to digits and send
2          ;-----
3          ; Convert a binary value to an ascii digit string and send to the
4          ; terminal.
5          ;
6          ; Inputs:
7          ; RO = Value to be converted and sent
8          ;
9 012334 010446 GENVAL: MOV     R4, -(SP)
10 012336 010546      MOV     R5, -(SP)
11 012340 010005      MOV     R0, R5          ;Get value to be converted
12          ;
13          ; Convert to digits and stack the digits
14          ;
15 012342 005046      CLR     -(SP)          ;Store null on stack to indicate end
16 012344 005004 1$: CLR     R4              ;Clear high-order for divide
17 012346 071427 000012 DIV    #10, R4          ;Divide R4-R5 by 10.
18 012352 062705 000060 ADD    #'0, R5          ;Convert remainder to ascii digit
19 012356 010546      MOV     R5, -(SP)      ;Stack the character
20 012360 010405      MOV     R4, R5          ;Get quotient
21 012362 001370      BNE    1$              ;Loop if more digits to convert
22          ;
23          ; Now pop the digits and send them
24          ;
25 012364 012600 2$: MOV     (SP)+, R0        ;Get next char to send
26 012366 001404      BEQ    9$              ;Br if finished
27 012370      SEND    R0                    ;Send a digit
28 012376 000772      BR     2$              ;Send rest of number
29          ;
30          ; Finished
31          ;
32 012400 012605 9$: MOV     (SP)+, R5
33 012402 012604      MOV     (SP)+, R4
34 012404 000207      RETURN

```

```

1          .SBTTL  EMTWIN -- Dispatch window control EMT's
2          ;-----
3          ; EMTWIN is entered from EMT processing when a window control EMT
4          ; is executed.  It dispatches control to the correct processing
5          ; routine based on the subfunction code.
6          ;
7          ; Inputs:
8          ; R1 = Job index number
9          ; EMTBLK = EMT argument block
10         ;
11 012406  EMTWIN:
12         ;
13         ; Ignore window control EMT's if this is a detached job
14         ;
15 012406  113700  0000000  MOVB  EMTBLK,RO  ;Get EMT subfunction code
16 012412  020027  0000006  CMP   RO,#6      ;Read-window-data function?
17 012416  001407                BEQ   2$        ;Br if yes -- OK for detached jobs
18 012420  032761  0000000 0000000  BIT   ##DETC,LSW(R1) ;Is this a detached job?
19 012426  001403                BEQ   2$        ;Br if not
20 012430  005000                CLR   RO        ;Return error 0 for detached job
21 012432  000137  0000000  JMP   SETERR
22         ;
23         ; Get EMT subfunction code and make sure it is valid
24         ;
25 012436  006300  2$:  ASL   RO        ;Convert subfun code to word table index
26 012440  020027  000020  CMP   RO,#MAXSFC  ;Is the subfunction code valid?
27 012444  103403                BLO   1$        ;Br if yes
28 012446  005000                CLR   RO        ;Return error code 0 if not
29 012450  000137  0000000  JMP   SETERR
30         ;
31         ; Enter processing routine
32         ;
33 012454  000170  012460'  1$:  JMP   @WINVEC(RO) ;Enter processing routine
34         ;
35         ; Branch vector for subfunction codes
36         ;
37 012460  012500'  WINVEC: .WORD  WFNEW      ;0 - Create a new window
38 012462  013170'      .WORD  WFMAP      ;1 - Select a window
39 012464  013236'      .WORD  WFDEL      ;2 - Delete a window
40 012466  013350'      .WORD  WFSPND     ;3 - Suspend window processing
41 012470  013370'      .WORD  WFRSUM     ;4 - Resume window processing
42 012472  013410'      .WORD  WFPRNT     ;5 - Print the specified window
43 012474  013456'      .WORD  WFREAD     ;6 - Read window data into program buffer
44 012476  013740'      .WORD  WFSTT      ;7 - Set terminal type
45         000020  MAXSFC =  .-WINVEC ;Highest branch vector index
46

```



WFNEW -- EMT to create a new window

```

1          .SBTTL  WFNEW  -- EMT to create a new window
2          ;-----
3          ; WINNEW is the EMT used to define a new window.
4          ; The form of the EMT argument block is:
5          ;
6          ;     .BYTE  0,161
7          ;     .BYTE  window_number,perm_flag
8          ;     .BYTE  window_width,max_scroll
9          ;     .WORD  copy_window,copy_job
10         ;     .WORD  0
11         ;
12         ; Inputs:
13         ; R1 = Job index number
14         ; EMTBLK = EMT argument block
15         ;
16 012500  WFNEW:
17         ;
18         ; If a window with this number already exists for this job, delete it.
19         ;
20 012500  113702  0000020  MOVB  EMTBLK+2,R2  ;Get specified window number
21 012504  004737  014140'  CALL  WINSRC:    ;Try to locate window control block
22 012510  103402  BCS   1$        ;Br if that window not currently defined
23 012512  004737  014104'  CALL  WINDEL.   ;Delete the window
24         ;
25         ; Try to find a free window control block
26         ;
27 012516  013702  000002'  1$:  MOV   DWBAS,R2  ;Point to 1st window control block
28 012522  105762  0000000  2$:  TSTB  DW$JOB(R2) ;Is this block free?
29 012526  001411  BEQ   5$        ;Br if yes
30 012530  062702  0000000  ADD   #DW$$SZ,R2  ;Point to next window block
31 012534  020237  000004'  CMP   R2,DWEND   ;Checked all blocks?
32 012540  103770  BLO   2$        ;Br if yes
33 012542  012700  000001  MOV   #1,R0      ;Return error 0 if no free blocks
34 012546  000137  0000000  JMP   SETERR
35         ;
36         ; Initialize the window control block
37         ;
38 012552  012700  0000000  5$:  MOV   #DW$$SZ/2,R0 ;Get # words in window block
39 012556  010203  MOV   R2,R3      ;Get pointer to control block
40 012560  005023  3$:  CLR   (R3)+     ;Zero the entire block
41 012562  077002  SOB   R0,3$
42 012564  110162  0000000  MOVB  R1,DW$JOB(R2) ;Set our job number
43 012570  113762  0000020 0000000  MOVB  EMTBLK+2,DW$ID(R2);Set window ID number
44 012576  012762  0000000 0000000  MOV   #<AW$VCR!AW$RPT>,DW$AW(R2);Initialize window attribute flags
45 012604  113700  0000040  MOVB  EMTBLK+4,R0  ;Get # columns per line
46 012610  042700  177400  BIC   #^C<377>,R0 ;Kill sign extension
47 012614  001002  BNE   11$       ;Br if width not zero
48 012616  012700  000120  MOV   #80.,R0    ;Set width to 80
49 012622  020027  000204  11$:  CMP   R0,#132.  ;Compare with max width allowed
50 012626  101402  BLOS  12$       ;Br if ok
51 012630  012700  000204  MOV   #132.,R0  ;Constrain to 132
52 012634  010062  0000000  12$:  MOV   R0,DW$CPL(R2) ;Set number of columns per line
53 012640  012762  000030  0000000  MOV   #24.,DW$LPP(R2) ;Set number of lines per page
54 012646  113762  0000050 0000000  MOVB  EMTBLK+5,DW$MSL(R2);Set max-scrolled-lines parameter
55 012654  012762  000001  0000000  MOV   #1,DW$TLN(R2) ;Say line 1 is at top of buffer
56 012662  012762  000001  0000000  MOV   #1,DW$SRT(R2) ;Say line 1 is top of scrolling region
57 012670  016262  0000000 0000000  MOV   DW$LPP(R2),DW$SRB(R2);scrolling region goes to end of page

```

```

58 ;
59 ; Initialize terminal type
60 ;
61 012676 004737 013774' CALL WINSTT ;Set correct terminal type
62 ;
63 ; Initialize character set mapping for a VT200
64 ;
65 012702 032761 000000C 000000G BIT #<VT2007!VT2008>,LTRMTP(R1);Is terminal a VT200?
66 012710 001411 BEQ 7$ ;Br if not
67 012712 112762 000001 000000G MOVB #1,DW$G2M(R2) ;Map G2 to DEC supplemental chars
68 012720 112762 000001 000000G MOVB #1,DW$G3M(R2) ;Map G3 to DEC supplemental chars
69 012726 112762 000002 000000G MOVB #2,DW$GRM(R2) ;Map GR to G2
70 ;
71 ; Set application keypad mode if Single line editor is in KED mode
72 ;
73 012734 032761 000000G 000000G 7$: BIT ##SLON,LSW7(R1) ;Is single-line editor turned on?
74 012742 001407 BEQ 10$ ;Br if not
75 012744 032761 000000G 000000G BIT ##SLKED,LSW7(R1);Is SL in KED mode?
76 012752 001403 BEQ 10$ ;Br if not
77 012754 052762 000000G 000000G BIS #AW$AKM,DW$AW(R2);Set application keypad mode
78 ;
79 ; See if this window should be permanent
80 ;
81 012762 105737 000003G 10$: TSTB EMTBLK+3 ;Is permanent-window flag set?
82 012766 001403 BEQ 8$ ;Br if not
83 012770 052762 000000G 000000G BIS #AW$PRM,DW$AW(R2);Remember window is permanent
84 ;
85 ; See if we should copy any window attributes from an existing window
86 ;
87 012776 005737 000006G 8$: TST EMTBLK+6 ;Should we copy attributes from another windo?
88 013002 001443 BEQ 13$ ;Br if not
89 013004 010203 MOV R2,R3 ;Save addr of new window control block
90 013006 013702 000006G MOV EMTBLK+6,R2 ;Get window_id and job number
91 013012 010201 MOV R2,R1
92 013014 042702 177400 BIC #^C<377>,R2 ;Clear all but window ID
93 013020 000301 SWAB R1 ;Get job # to low-order byte
94 013022 042701 177400 BIC #^C<377>,R1 ;Clear all but job number
95 013026 006301 ASL R1 ;Get job index number
96 013030 001002 BNE 14$ ;Br if job number specified
97 013032 113701 000000G MOVB CORUSR,R1 ;Assume current job
98 013036 004737 014140' 14$: CALL WINSRC ;Try to find existing window control block
99 013042 103422 BCS 15$ ;Br if could not find one
100 013044 016263 000000G 000000G MOV DW$LPP(R2),DW$LPP(R3) ;Copy # lines per page
101 013052 016263 000000G 000000G MOV DW$CPL(R2),DW$CPL(R3) ;Copy # columns per line
102 013060 116263 000000G 000000G MOVB DW$MSL(R2),DW$MSL(R3) ;Copy max # scroll lines
103 013066 016200 000000G MOV DW$AW(R2),R0 ;Get window attribute flags
104 013072 042700 000000C BIC #^C<AW$132!AW$REV>,R0 ;Leave only ones to be copied
105 013076 042763 000000C 000000G BIC #<AW$132!AW$REV>,DW$AW(R3) ;Clear in new control block
106 013104 050063 000000G BIS R0,DW$AW(R3) ;Transfer the flags
107 013110 010302 15$: MOV R3,R2 ;Get back address of new window control block
108 ;
109 ; Create a named local region for the screen buffer for the window
110 ;
111 013112 004737 014204' 13$: CALL MAKWSB ;Make a window screen buffer
112 013116 103006 BCC 4$ ;Br if we made the region
113 013120 004737 014104' CALL WINDEL ;Delete the window
114 013124 012700 000002 MOV #2,R0 ;Return error code 2

```

```
115 013130 000137 0000000      JMP      SETERR
116                               ;
117                               ; Clear entire screen contents to blanks
118                               ;
119 013134 004737 006210'      4*:     CALL      ERSPAG      ; Clear all positions to spaces
120                               ;
121                               ; Set line 1, column 1 as cursor position
122                               ;
123 013140 012700 000001      MOV      #1,R0      ; Get value 1
124 013144 110062 0000000      MOVB    R0,DW$SLN(R2) ; Init saved line # to 1
125 013150 110062 0000000      MOVB    R0,DW$SCL(R2) ; Init saved column # to 1
126 013154 010062 0000000      MOV      R0,DW$COL(R2) ; Set column = 1
127 013160 004737 006702'      CALL    SETLIN      ; Set line =1
128                               ;
129                               ; Finished
130                               ;
131 013164 000137 0000000      JMP      EMTXIT
```

```
1          .SBTTL  WFMAP  -- EMT to select a window as the current window
2          ;-----
3          ; Select a window as the current window for the job and refresh
4          ; the display screen from the window contents.
5          ;
6          ; Inputs:
7          ; R1 = Job index number
8          ; EMTBLK = EMT argument block
9          ;
10         013170 WFMAP:
11         ;
12         ; If current window number is zero, switch back to no window
13         ;
14         013170 013702 0000020      MOV     EMTBLK+2,R2      ;Get specified window number
15         013174 001003              BNE     2$              ;Br if some window specified
16         013176 005061 0000000      CLR     LWINDO(R1)     ;Say we are not doing windowing
17         013202 000413              BR      9$
18         ;
19         ; Locate the window control block for the specified window
20         ;
21         013204 004737 014140' 2$:  CALL    WINSRC      ;Find window control block
22         013210 103004              BCC     1$              ;Br if found it
23         013212 012700 0000003      MOV     #3,R0          ;Error 3 if not
24         013216 000137 0000000      JMP     SETERR
25         ;
26         ; Set this window as the current window for the job
27         ;
28         013222 010261 0000000 1$:  MOV     R2,LWINDO(R1) ;Say this is current window for job
29         ;
30         ; Refresh the display from selected window
31         ;
32         013226 004737 007064'      CALL    REFRSH        ;Refresh display from window contents
33         ;
34         ; Finished
35         ;
36         013232 000137 0000000 9$:  JMP     EMTXIT
```

WFDEL -- EMT to delete a window

```

1          .SBTTL  WFDEL  -- EMT to delete a window
2          ;-----
3          ; EMT to delete a window.
4          ;
5          ; Inputs:
6          ; R1 = Job index number
7          ;
8 013236   WFDEL:
9          ;
10         ; Try to locate control block for the window
11         ;
12 013236 113702 0000020      MOVB    EMTBLK+2,R2      ;Get specified window number
13 013242 001406              BEQ     3$                ;Br if window number is zero
14 013244 120227 177777      CMPB    R2,#-1          ;Is window number -1?
15 013250 001024              BNE     2$                ;Br if not
16         ;
17         ; Delete all windows for job (temp and permanent)
18         ;
19 013252 004737 014052'     CALL    WINREL          ;Release all windows for the job
20 013256 000432              BR     9$
21         ;
22         ; Window number zero means delete all temporary windows
23         ;
24 013260 013702 000002'     3$:    MOV     DWBAS,R2      ;Point to 1st window control block
25 013264 120162 0000000     5$:    CMPB   R1,DW$JOB(R2) ;Does this window belong to our job?
26 013270 001006              BNE     4$                ;Br if not
27 013272 032762 0000000 0000000  BIT    #AW$PRM,DW$AW(R2);Is this a perm or temp window?
28 013300 001002              BNE     4$                ;Br if permanent window
29 013302 004737 014104'     CALL    WINDEL          ;Delete this window
30 013306 062702 0000000     4$:    ADD    #DW$$SZ,R2      ;Point to next window control block
31 013312 020237 000004'     CMP     R2,DWEND        ;Checked all?
32 013316 103762              BLO    5$                ;Br if not
33 013320 000411              BR     9$
34         ;
35         ; We are deleting a specific window
36         ;
37 013322 004737 014140'     2$:    CALL    WINSRC          ;Try to locate window control block
38 013326 103004              BCC    1$                ;Br if located the window control block
39 013330 012700 0000003     MOV     #3,R0           ;Error code 3 if cannot locate window
40 013334 000137 0000000     JMP     SETERR
41         ;
42         ; Delete the window
43         ;
44 013340 004737 014104'     1$:    CALL    WINDEL          ;Delete the window
45         ;
46         ; Finished
47         ;
48 013344 000137 0000000     9$:    JMP     EMTXIT

```

WFSPND -- Suspend window processing

```

1          .SBTTL  WFSPND -- Suspend window processing
2          ;-----
3          ; Suspend window processing.  After executing this emt, window
4          ; processing is suspended.  Characters are passed through to the
5          ; screen without being processed by the window routine.
6          ;
7          ; Inputs:
8          ; R1 = Job index number
9          ;
10         013350 016102 0000000  WFSPND: MOV     LWINDO(R1),R2  ;Get pointer to current window control block
11         013354 001403          BEQ     9$                ;Br if job has no window active now
12         013356 052762 0000000 0000000  BIS     #AW$SPN,DW$AW(R2);Set flag suspending window processing
13         013364 000137 0000000 9$:      JMP     EMTXIT          ;Finished
14
15         .SBTTL  WFRSUM -- Resume window processing
16         ;-----
17         ; Resume window processing.
18         ;
19         ; Inputs:
20         ; R1 = Job index number
21         ;
22         013370 016102 0000000  WFRSUM: MOV     LWINDO(R1),R2  ;Get pointer to current window control block
23         013374 001403          BEQ     9$                ;Br if job has no window active now
24         013376 042762 0000000 0000000  BIC     #AW$SPN,DW$AW(R2);Say window no longer suspended
25         013404 000137 0000000 9$:      JMP     EMTXIT          ;Finished

```

WFPRNT -- Cause contents of a window to be printed

```

1          .SBTTL  WFPRNT -- Cause contents of a window to be printed
2          ;-----
3          ; Cause the contents of a window for the current job to be printed.
4          ;
5          ; Inputs:
6          ; R1 = Job index number
7          ;
8          ; EMT argument block:
9          ;
10         ; .BYTE 5,161
11         ; .BYTE window_id,0
12         ;
13 013410  WFPRNT:
14         ;
15         ; Locate the window control block for the specified window
16         ;
17 013410 113702 0000020      MOVB    EMTBLK+2,R2      ;Get specified window ID
18 013414 001403              BEQ     3$              ;Zero is invalid
19 013416 004737 014140'     CALL   WINSRC        ;Find window control block
20 013422 103004              BCC    1$              ;Br if found it
21 013424 012700 000003     3$:    MOV    #3,R0      ;Error 3 if invalid window ID
22 013430 000137 0000000     JMP    SETERR
23         ;
24         ; Print this window
25         ;
26 013434 004737 014710'     1$:    CALL   WINPRT      ;Try to print the window
27 013440 103004              BCC    9$              ;Br if successful
28 013442 012700 000004     MOV    #4,R0      ;Error 4 if can't print
29 013446 000137 0000000     JMP    SETERR
30         ;
31         ; Finished
32         ;
33 013452 000137 0000000     9$:    JMP    EMTXIT

```

WFREAD -- Copy window information to program buffer

```

1          .SBTTL  WFREAD -- Copy window information to program buffer
2          ;-----
3          ; Copy window data into buffer in program area.
4          ;
5          ; EMT argument block:
6          ;
7          ;     .BYTE  6,161
8          ;     .BYTE  window_id,job_number
9          ;     .WORD  buffer_address
10         ;     .WORD  buffer_size
11         ;
12 013456  WFREAD:
13         ;
14         ; Make sure specified buffer address and size is ok
15         ;
16 013456  013700  0000040  MOV     EMTBLK+4,R0    ;Get base address of buffer
17 013462  004737  0000000  CALL   VALADW       ;Make sure it's ok
18 013466  063700  0000060  ADD    EMTBLK+6,R0  ;Add specified size
19 013472  004737  0000000  CALL   VALADB       ;Make sure end is ok too
20         ;
21         ; Get the number of the job whose window we want to read
22         ;
23 013476  113701  0000030  MOVB   EMTBLK+3,R1  ;Get specified job number
24 013502  006301  ; ASL    R1           ;Convert to job index number
25 013504  001002  ; BNE   1$           ;Br if job number specified
26 013506  113701  0000000  MOVB   CORUSR,R1    ;Get current job index number
27 013512  120137  0000000  1$:  CMPB  R1,CORUSR  ;Are we reading window for our job?
28 013516  001410  ; BEQ   5$           ;Br if yes
29 013520  032737  0000000  0000000  BIT    #P2#CXT,PRIVC2 ;Do we have GETCXT privilege?
30 013526  001004  ; BNE   5$           ;Br if yes
31 013530  012700  0000001  MOV    #1,R0        ;Error 1 if not
32 013534  000137  0000000  JMP    SETERR
33         ;
34         ; Find the specified window control block
35         ;
36 013540  113702  0000020  5$:  MOVB   EMTBLK+2,R2  ;Get window ID
37 013544  004737  014140'  CALL   WINSRC       ;Search for specified window
38 013550  103004  ; BCC   2$           ;Br if found the window control blk
39 013552  012700  0000003  MOV    #3,R0        ;Invalid window ID
40 013556  000137  0000000  JMP    SETERR
41         ;
42         ; Determine how much data must be copied
43         ;
44 013562  016203  0000000  2$:  MOV    DW$LPP(R2),R3 ;Get # lines on page
45 013566  070362  0000000  MUL   DW#CPL(R2),R3 ;Times # columns per line
46 013572  006303  ; ASL   R3           ;Need two bytes for each char cell
47 013574  066203  0000000  ADD   DW$LPP(R2),R3 ;Add space used by line attrib vector
48 013600  005203  ; INC   R3           ;Round up to next word
49 013602  042703  0000001  BIC   #1,R3
50 013606  010300  ; MOV   R3,R0        ;Get # bytes of window buffer data
51 013610  062700  0000006  ADD   #3*2,R0       ;Add # bytes for parameter words
52 013614  020037  0000006  CMP   R0,EMTBLK+6  ;Is buffer large enough?
53 013620  101404  ; BLOS  3$           ;Br if yes
54 013622  012700  0000004  MOV   #4,R0        ;Error 4 if buffer too small
55 013626  000137  0000000  JMP   SETERR
56         ;
57         ; Copy some window parameter information before actual window buffer

```



```
58 ;  
59 013632 013705 0000040 3#: MOV EMTBLK+4,R5 ;Get address of user's buffer  
60 013636 016246 0000000 MOV DW$TLN(R2),-(SP);Store top line number  
61 013642 106625 MTPD (R5)+  
62 013644 016246 0000000 MOV DW$LPP(R2),-(SP);Store # lines per page  
63 013650 106625 MTPD (R5)+  
64 013652 016246 0000000 MOV DW$CPL(R2),-(SP);Store # columns per line  
65 013656 106625 MTPD (R5)+  
66 ;  
67 ; Copy data from window region to user's buffer  
68 ;  
69 013660 006203 ASR R3 ;Get # words to copy  
70 013662 012704 0000000 MOV #VPA6,R4 ;Get virt address of window region  
71 013666 4#: BUFMAP ;;;Map to window region  
72 013710 012400 MOV (R4)+,R0 ;;;Get a word from screen region  
73 013712 UNMAP ;Restore mapping  
74 013726 010046 MOV R0,-(SP) ;Push word we are transferring  
75 013730 106625 MTPD (R5)+ ;Store data into user's buffer  
76 013732 077323 SOB R3,4# ;Loop if more data to copy  
77 ;  
78 ; Finished  
79 ;  
80 013734 000137 0000000 JMP EMTXIT
```

WFSTT -- EMT to set terminal type for windowing

```

1          .SBTTL  WFSTT  -- EMT to set terminal type for windowing
2          ;-----
3          ; Reset the terminal type for all windows being used by this job.
4          ;
5          ; Inputs:
6          ; R1 = Job index number.
7          ;
8 013740   WFSTT:
9          ;
10         ; Begin loop to process all windows belonging to this job
11         ;
12 013740   013702 000002'      MOV     DWBAS,R2      ;Point to 1st window control block
13 013744   120162 0000000     1$:   CMPB   R1,DW$JOB(R2)  ;Does this one belong to this job?
14 013750   001002              BNE    2$           ;Br if not
15 013752   004737 013774'      CALL  WINSTT      ;Reset terminal type for this window
16 013756   062702 0000000     2$:   ADD    #DW$$SZ,R2    ;Point to next window control block
17 013762   020237 000004'      CMP    R2,DWEND   ;Checked all?
18 013766   103766              BLO   1$           ;Loop if not
19         ;
20         ; Finished
21         ;
22 013770   000137 0000000     JMP    EMTXIT

```

WINSTT -- Set terminal type for a window

```

1          .SBTTL  WINSTT -- Set terminal type for a window
2          ;-----
3          ; WINSTT sets up the terminal type in the window control block
4          ; attribute word based on the terminal type specified for the job.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ;
9 013774 010146 WINSTT: MOV  R1,-(SP)
10 013776 116201 0000000 MOVB  DW$JOB(R2),R1 ;Get job index number
11          ;
12          ; Determine terminal type based on line type
13          ;
14 014002 042762 0000000 0000000 BIC   #<AW$52!AW$200>,DW$AW(R2) ;Say not VT52 and not VT200
15          ;
16          ; See if terminal is a VT52
17          ;
18 014010 032761 0000000 0000000 BIT   #VT52,LTRMTP(R1);Is this a VT52?
19 014016 001404 BEQ   1$ ;Br if not
20 014020 052762 0000000 0000000 BIS   #AW$52,DW$AW(R2);Set VT52 as terminal type
21 014026 000407 BR    9$
22          ;
23          ; See if terminal is a VT200
24          ;
25 014030 032761 0000000 0000000 1$: BIT   #<VT2007!VT2008>,LTRMTP(R1) ;VT200 terminal?
26 014036 001403 BEQ   9$ ;Br if not
27 014040 052762 0000000 0000000 BIS   #AW$200,DW$AW(R2);Set VT200 as terminal type
28          ;
29          ; Finished
30          ;
31 014046 012601 9$:  MOV  (SP)+,R1
32 014050 000207 RETURN

```

WINREL --- Release all display windows for a job

```

1          .SBTTL  WINREL --- Release all display windows for a job
2          ;-----
3          ; Release all display windows for the current job.
4          ;
5          ; Inputs:
6          ; R1 = Job index number for job whose windows are to be released.
7          ;
8 014052   WINREL:
9          ;
10         ; Begin loop to search for window control blocks belonging to this
11         ; job.
12         ;
13 014052  013702  000002'      MOV     DWBAS,R2      ;Point to first window control block
14 014056  120162  0000000     1$:    CMPB   R1,DW$JOB(R2)  ;Is this one belong to our job?
15 014062  001002              BNE     2$          ;Br if not
16 014064  004737  014104'      CALL  WINDEL      ;Delete the windoe
17 014070  062702  0000000     2$:    ADD   #DW#$SZ,R2  ;Point to next window control block
18 014074  020237  000004'      CMP    R2,DWEND   ;Checked all?
19 014100  103766              BLD   1$          ;Loop if not
20         ;
21         ; Finished
22         ;
23 014102  000207              RETURN

```

WINDEL -- Delete a window

```

1          .SBTTL  WINDEL -- Delete a window
2          ;-----
3          ; Delete a window and release its screen buffer region.
4          ;
5          ; Inputs:
6          ; R2 = Pointer to window control block
7          ;
8 014104   WINDEL:
9          ;
10         ; If this is the current window, reset window info for job
11         ;
12 014104   116200 0000000  MOVB   DW#JOB(R2),R0  ;Get # of job that owns this window
13 014110   020260 0000000  CMP    R2,LWINDO(R0)  ;Is this current window for the job?
14 014114   001002          BNE    1$              ;Br if not
15 014116   005060 0000000  CLR   LWINDO(R0)      ;Say job is not doing windowing
16         ;
17         ; Free the region used for the screen buffer
18         ;
19 014122   004737 014514' 1$:   CALL  FREWSB      ;Free the window screen buffer
20         ;
21         ; Free the window control block
22         ;
23 014126   105062 0000000  CLRB  DW#ID(R2)       ;Say block is free
24 014132   105062 0000000  CLRB  DW#JOB(R2)     ;Say no job using block
25         ;
26         ; Finished
27         ;
28 014136   000207          RETURN

```

WINSRC -- Locate control block for a window

```

1          .SBTTL  WINSRC -- Locate control block for a window
2          ;-----
3          ; Locate a window control block for a specified window for the current
4          ; job.
5          ;
6          ; Inputs:
7          ; R1 = Index number of job that owns the window
8          ; R2 = Window number
9          ;
10         ; Outputs:
11         ; C-flag cleared ==> Found window control block
12         ; C-flag set    ==> Cannot find window control block
13         ; R2 = Pointer to window control block if found
14         ;
15 014140  WINSRC:
16         ;
17         ; Search for specified window control block
18         ;
19 014140  010200          MOV     R2,R0          ;Get window ID
20 014142  013702  000002'  MOV     DWBAS,R2        ;Point to first window control block
21 014144  120062  0000000  1$:    CMPB   R0,DW$ID(R2)    ;Does this block have correct ID?
22 014152  001003          BNE     2$                ;Br if not
23 014154  120162  0000000  CMPB   R1,DW$JOB(R2)    ;Is this control block for right job?
24 014160  001407          BEQ     3$                ;Br if yes
25 014162  062702  0000000  2$:    ADD     #DW$$SZ,R2    ;Point to next control block
26 014164  020237  000004'  CMP    R2,DWEND        ;Checked all?
27 014172  103765          BLO    1$                ;Loop if not
28         ;
29         ; Cannot find specified window control block
30         ;
31 014174  000261          SEC                      ;Signal error on return
32 014176  000401          BR     9$
33         ;
34         ; Found the window control block
35         ;
36 014200  000241  3$:    CLC                      ;Signal success on return
37         ;
38         ; Finished
39         ;
40 014202  000207  9$:    RETURN

```

MAKWSB -- Create named region for window screen buffer

```

1          .SBTTL  MAKWSB -- Create named region for window screen buffer
2          ;-----
3          ; Create a named local region large enough to hold the window
4          ; screen buffer.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ; EMTBLK+2 = Arg block for EMT to create the window
9          ;
10         ; Outputs:
11         ; C-flag cleared ==> Successfully created region
12         ; C-flag set    ==> Unable to create region
13         ;
14 014204 010146 MAKWSB: MOV     R1,-(SP)
15 014206 010346      MOV     R3,-(SP)
16 014210 010446      MOV     R4,-(SP)
17 014212 010546      MOV     R5,-(SP)
18 014214 010605      MOV     SP,R5          ; Save original stack pointer in R5
19         ;
20         ; Calculate number of 64-byte blocks needed for region
21         ;
22 014216 016203 0000000 MOV     DW$LPP(R2),R3  ; Get # lines on page
23 014222 070362 0000000 MUL     DW$CPL(R2),R3  ; Times number of columns
24 014226 006303      ASL     R3              ; Need two bytes per character
25 014230 066203 0000000 ADD     DW$LPP(R2),R3  ; Need byte vector for line attributes
26 014234 062703 0000077 ADD     #63.,R3        ; Bound up to 64-byte boundary
27 014240 072327 177772  ASH     #-6.,R3        ; Get # 64-byte blocks needed
28         ;
29         ; Build a region definition block on the stack
30         ;
31 014244 162706 000012  SUB     #10.,SP        ; Allocate space for region def block
32 014250 010604      MOV     SP,R4          ; Get pointer to start of RDB
33 014252 004737 014404' CALL    MAKRDB         ; Make a region definition block on the stack
34 014256 010364 0000000 MOV     R3,R.GSIZ(R4)  ; Set # 64-byte units needed
35 014262 012764 0000000 0000000 MOV     #<RS.GBL!RS.CGR>,R.GSTS(R4) ; Set status flags
36         ;
37         ; Build EMT argument block on stack
38         ;
39 014270 162706 000004  SUB     #4.,SP        ; Allocate space for EMT arg block
40 014274 010601      MOV     SP,R1          ; Save pointer to EMT arg block
41 014276 010600      MOV     SP,R0          ; Get pointer to EMT arg block area
42 014300 012710 017000  MOV     #<36*400>,(R0) ; Set EMT function code
43 014304 010460 000002  MOV     R4,2(R0)      ; Set address of region def block
44         ;
45         ; Try to create the region
46         ;
47 014310 104375      EMT     375            ; Try to create the region
48 014312 103426      BCS     9$              ; Br if error on region creation
49         ;
50         ; We successfully created the region.
51         ; Set up information in the window control block.
52         ;
53 014314 016403 0000000 MOV     R.GID(R4),R3  ; Get region control block address
54 014320 016362 0000000 0000000 MOV     RC$BLK(R3),DW$RID(R2); Save addr of global RCB
55 014326 016362 0000000 0000000 MOV     RC$BAS(R3),DW$MAP(R2); Save mapping base for region
56         ;
57         ; Now detach from the global region

```

MAKWSB -- Create named region for window screen buffer

```

58 ;
59 014334 005064 0000000 CLR R.GSTS(R4) ;Clear all status flags
60 014340 010100 MOV R1,R0 ;Get pointer to EMT arg block
61 014342 012710 017001 MOV #<<36*400>+1>, (R0);Set .ELRG function code
62 014346 104375 EMT 375 ;Detach from the region
63 ;
64 ; Now go back and set the exclusive-access flag in the global region
65 ; control block and increment its attachment count by one.
66 ;
67 014350 016203 0000000 MOV DW#RID(R2),R3 ;Get pointer to global RCB
68 014354 052763 0000000 0000000 BIS #RC#EXC,RC#FLG(R3);Set exclusive-use flag
69 014362 105263 0000000 INCB RC#CNT(R3) ;Increment attachment count
70 ;
71 ; Successful completion
72 ;
73 014366 000241 CLC ;Signal success on return
74 ;
75 ; Finished -- Carry flag indicates results
76 ;
77 014370 010506 9#: MOV R5,SP ;Reset stack pointer
78 014372 012605 MOV (SP)+,R5
79 014374 012604 MOV (SP)+,R4
80 014376 012603 MOV (SP)+,R3
81 014400 012601 MOV (SP)+,R1
82 014402 000207 RETURN

```



MAKRDB -- Make a region definition block

```

1          .SBTTL  MAKRDB -- Make a region definition block
2          ;-----
3          ; Initialize a region definition block to access a global region
4          ; used as a window buffer.
5          ;
6          ; Inputs:
7          ; R2 = Pointer to window control block
8          ; R4 = Pointer to area where region definition block is to be built
9          ;
10         014404 010146 MAKRDB: MOV     R1,-(SP)
11         014406 010346         MOV     R3,-(SP)
12         ;
13         ; Initially zero some cells in the RDB
14         ;
15         014410 005064 00000000 CLR     R.GID(R4)      ;Zero addr of region control block
16         014414 005064 00000000 CLR     R.GSTS(R4)     ;No status flags
17         014420 005064 00000000 CLR     R.GSIZ(R4)     ;No size specified yet
18         ;
19         ; Construct name for global region.
20         ; The first three characters are "WIN".
21         ; The next two characters are the job number.
22         ; The last character indicates the window ID.
23         ;
24         014424 013764 000010' 00000000 MOV     R5OWIN,R.NAME(R4);Set 1st 3 chars of name to "WIN"
25         014432 116201 00000000 MOVE    DW#JOB(R2),R1  ;Get job index number
26         014436 006201          ASR     R1              ;Convert to job number
27         014440 005000          CLR     R0              ;Clear high-order for divide
28         014442 071027 000012    DIV     #10.,R0        ;Split job number into two digits
29         014446 062701 000036    ADD     #36,R1        ;Convert binary value to rad50 digit
30         014452 070127 000050    MUL     #50,R1        ;Shift remainder left 1 rad50 digit position
31         014456 010103          MOV     R1,R3          ;Save shifted low-order digit of job #
32         014460 010001          MOV     R0,R1          ;Get high-order digit of job #
33         014462 062701 000036    ADD     #36,R1        ;Convert binary value to rad50 digit
34         014466 070127 003100    MUL     #3100,R1     ;Shift over 2 rad50 digits
35         014472 060103          ADD     R1,R3          ;Job # is two high-order digits
36         014474 116201 00000000 MOVE    DW#ID(R2),R1  ;Get window number
37         014500 060103          ADD     R1,R3          ;Put window number as 3rd digit of word
38         014502 010364 00000200 MOV     R3,R.NAME+2(R4);Set 2nd word of name
39         ;
40         ; Finished
41         ;
42         014506 012603          MOV     (SP)+,R3
43         014510 012601          MOV     (SP)+,R1
44         014512 000207          RETURN

```

```

1          .SBTTL  FREWSB -- Free memory used by window screen buffer
2          ;-----
3          ; Free the memory region used for a window screen buffer.
4          ;
5          ; Inputs:
6          ;   R2 = Pointer to window control block
7          ;
8 014514  010146  FREWSB: MOV     R1, -(SP)
9 014516  010446          MOV     R4, -(SP)
10 014520  010546          MOV     R5, -(SP)
11 014522  010605          MOV     SP, R5          ; Save initial stack pointer
12          ;
13          ; See if this window has an associated region
14          ;
15 014524  016204  0000000  MOV     DW#RID(R2), R4  ; Does window have an assoc region?
16 014530  001436          BEQ     9$          ; Br if not
17          ;
18          ; Decrement attachment-count in global region RCB and
19          ; reset exclusive-use flag.
20          ;
21 014532  105364  0000000  DECB   RC#CNT(R4)      ; Say one less job using region
22 014536  042764  0000000  0000000  BIC     #RC#EXC, RC#FLG(R4); Clear exclusive-use flag
23          ;
24          ; Build region definition block on the stack
25          ;
26 014544  162706  000012    SUB     #10, SP        ; Reserve room for region def block
27 014550  010604          MOV     SP, R4        ; Get addr of base of region def block
28 014552  004737  014404'   CALL   MAKRDB         ; Build the region definition block
29 014556  012764  0000000  0000000  MOV     #RS.GBL, R.GSTS(R4); Set global status flag in RDB
30          ;
31          ; Build EMT argument block on stack to attach to region
32          ;
33 014564  162706  000004    SUB     #4, SP        ; Reserve room for EMT arg block
34 014570  010601          MOV     SP, R1        ; Save pointer to EMT arg block
35 014572  010600          MOV     SP, R0        ; Get pointer to arg block area
36 014574  012710  017000    MOV     #<<36*400>+0>, (R0); Set function code
37 014600  010460  000002    MOV     R4, 2(R0)     ; Set address of region def block
38 014604  104375          EMT     375           ; Try to attach to the region
39 014606  103407          BCS    9$           ; Br if cannot attach to region
40          ;
41          ; Eliminate the region
42          ;
43 014610  012764  0000000  0000000  MOV     #<RS.GBL!RS.EGR>, R.GSTS(R4); Set status flags
44 014616  010100          MOV     R1, R0        ; Point to EMT argument block
45 014620  012710  017001    MOV     #<<36*400>+1>, (R0); Set EMT function code
46 014624  104375          EMT     375           ; Eliminate the region
47          ;
48          ; Finished
49          ;
50 014626  010506  9$:   MOV     R5, SP        ; Restore stack pointer
51 014630  012605          MOV     (SP)+, R5
52 014632  012604          MOV     (SP)+, R4
53 014634  012601          MOV     (SP)+, R1
54 014636  000207          RETURN

```

WININI -- TSWIN initialization

```

1                                     .SBTTL  WININI -- TSWIN initialization
2                                     ;-----
3                                     ; WININI is called during system initialization to initialize the
4                                     ; display management system.
5                                     ;
6 014640 010546 WININI: MOV      R5, -(SP)
7                                     ;
8                                     ; Allocate space for the window control blocks
9                                     ;
10 014642 013705 0000000 MOV     VMXWIN, R5      ;Get # control blocks wanted
11 014646 070527 0000000 MUL     #DW*#SZ, R5     ;Times size of each block
12 014652 062705 015050' ADD     #WINTOP, R5    ;Add base of area
13 014656 020527 0000000 CMP     R5, #140000-DW*#SZ ;Would this overflow available area?
14 014662 101402          BLOS    1$                ;Br if not
15 014664 012705 0000000 MOV     #140000-DW*#SZ, R5 ;Constrain to available area
16 014670 010537 000004' 1$: MOV    R5, DWEND          ;Set pointer to end of control blocks
17                                     ;
18                                     ; Zero the entire display control block area
19                                     ;
20 014674 005045          2$: CLR     -(R5)           ;Zero entire area
21 014676 020537 000002' CMP     R5, DWBAS        ;Reached start of area?
22 014702 101374          BHI     2$                ;Loop if not
23                                     ;
24                                     ; Finished
25                                     ;
26 014704 012605          MOV     (SP)+, R5
27 014706 000207          RETURN

```

WINPRT -- Window print-screen function

```

1          .SBTTL  WINPRT -- Window print-screen function
2          ;-----
3          ; WINPRT is called when a control character is received that means
4          ; that we should perform a print-screen function for the current
5          ; window for the job.
6          ;
7          ; Inputs:
8          ;   R2 = Pointer to current window control block for job
9          ;
10         ; Outputs:
11         ;   C-flag set on return if unable to print the window.
12         ;
13 014710 010146 WINPRT: MOV     R1,-(SP)
14 014712 010446         MOV     R4,-(SP)
15 014714 010546         MOV     R5,-(SP)
16         ;
17         ; See if "WINPRT" detached job is running now
18         ;
19 014716 012701 0000000 MOV     #LSTSL,R1      ;Get index to last job
20 014722 026137 0000000 000010' 1$:  CMP     LPRG1(R1),R50WIN; Is this the WINPRT program?
21 014730 001004         BNE     2$          ;Br if not
22 014732 026137 0000000 000012'     CMP     LPRG2(R1),R50PRT
23 014740 001404         BEQ     3$          ;Br if yes
24 014742 162701 0000002 2$:  SUB     #2,R1      ;More jobs to check?
25 014746 003365         BGT     1$          ;Loop if yes
26 014750 000432         BR      8$          ;WINPRT program is not running
27         ;
28         ; The WINPRT program is running.
29         ; Schedule a completion routine to tell it to print a window.
30         ;
31 014752 016104 0000000 3$:  MOV     LBRKCQ(R1),R4   ;Get address of its completion Q element
32 014756 001427         BEQ     8$          ;Br if no completion routine pending
33 014760 005737 0000000     TST     NMFREQ      ;Can we get a free queue element?
34 014764 003424         BLE     8$          ;Br if not
35 014766 004737 0000000     CALL    GETRTQ     ;Get a free completion Q element (R1=addr)
36 014772 012700 0000000     MOV     #IQSIZ/2,R0   ;Get # words in queue element
37 014776 010105         MOV     R1,R5          ;Get pointer to new queue element
38 015000 012425 4$:  MOV     (R4)+,(R5)+   ;Copy original completion Q element
39 015002 077002         SOB     R0,4$
40 015004 116200 0000000     MOVVB  DW#JOB(R2),R0   ;Get # of job whose window to print
41 015010 006200         ASR     R0          ;Convert to job number
42 015012 110061 0000010     MOVVB  R0,CQ#R1+1(R1) ;Set job # in high byte of R1
43 015016 116261 0000000 0000000     MOVVB  DW#ID(R2),CQ#R1(R1); Set window ID in low byte of R1
44 015024 010104         MOV     R1,R4          ;Get addr of compl Q element for QCOMPL
45 015026 004737 0000000     CALL    QCOMPL     ;Queue the completion request for WINPRT
46 015032 000241         CLC          ;Signal success on return
47 015034 000401         BR      9$
48         ;
49         ; Unable to print the window
50         ;
51 015036 000261 8$:  SEC          ;Signal failure on return
52         ;
53         ; Finished
54         ;
55 015040 012605 9$:  MOV     (SP)+,R5
56 015042 012604         MOV     (SP)+,R4
57 015044 012601         MOV     (SP)+,R1

```

58 015046 000207  
59  
60  
61  
62  
63  
64 015050  
65  
66 000001

RETURN

;  
-----  
; Top of TSWIN code (Window control blocks are allocated from this  
; point to the end of the overlay).  
;  
WINTOP:  
;  
.END

Errors detected: 0

\*\*\* Assembler statistics

Work file reads: 0  
Work file writes: 0  
Size of work file: 8354 Words ( 33 Pages)  
Size of core pool: 17920 Words ( 70 Pages)  
Operating system: RT-11

Elapsed time: 00:01:45.32  
DK: TSWIN, LP: TSWIN=DK: TSWIN, MAC/C/N: SYM











SS3CHR	1-31					
TC100	12-16	12-84	42-9#			
TCAKM	12-70	38-8#				
TCBS	5-34	14-8#				
TCCADR	12-15	12-43	24-9#			
TCCPRS	12-69	25-30#				
TCCPSV	12-68	25-8#				
TCCR	5-39	16-8#	20-9			
TCDELL	12-48	27-10#				
TCDOWN	12-38	18-10#				
TCESCE	12-50	20-9#				
TCGOAS	12-42	12-55	28-8#			
TCGODS	12-41	12-73	28-18#			
TCGGR	12-56	28-38#				
TCGOUK	12-54	28-28#				
TCG1AS	12-57	12-58	29-8#			
TCG1DS	12-76	29-18#				
TCG1GR	12-59	29-38#				
TCG1UK	29-28#					
TCG2AS	12-60	30-8#				
TCG2DS	12-79	30-10#				
TCG2GR	12-61	30-20#				
TCG3AS	12-62	31-8#				
TCG3DS	12-82	31-10#				
TCG3GR	12-63	31-28#				
TCHT	5-35	15-8#				
TCINSL	12-47	26-11#				
TCIXUP	12-44	12-51	21-9#			
TCLEFT	12-40	23-9#				
TCLERS	12-46	45-9#				
TCLF	5-36	5-37	5-38	12-49	19-8#	20-10
TCLS1R	12-26	32-40#				
TCLS2	12-27	32-28#				
TCLS2R	12-29	32-58#				
TCLS3	12-28	32-38#				
TCLS3R	12-30	32-68#				
TCN3	12-64	39-10#				
TCN4	12-65	39-18#				
TCN5	12-66	39-26#				
TCN6	12-67	39-30#				
TCNKM	12-86	38-18#				
TCPERS	12-45	46-9#				
TCPRT	11-85	12-21	44-9#			
TCRAA	12-18	33-23#				
TCRDA	12-20	33-51#				
TCREST	12-24	12-25	43-8#			
TCRIT	12-39	22-9#				
TCRTA	33-25	33-53	35-10#			
TCSAA	12-17	33-9#				
TCBSZ	1-30	10-16				
TCSCA	12-22	40-9#				
TCSDA	12-19	33-37#				
TCSEI	5-41	32-13#				
TCSD	5-40	32-8#				
TCSS2	12-52	32-78#				
TCSS3	12-53	32-89#				

TCSSR	12-23	47-9#				
TCSTA	33-11	33-39	34-10#			
TCUP	12-37	17-10#				
TSWIN	1-6#					
VALADB	1-24	89-19				
VALADW	1-24	89-17				
VMXWIN	1-40	98-10				
VPAR6	1-32	61-17	62-19	63-29	89-70	
VT2007	1-40	42-26	43-36	84-65	91-25	
VT2008	1-40	42-26	43-36	84-65	91-25	
VT52	1-40	91-18				
WCPCSI	6-27	7-31#				
WCPESC	6-20	7-9#				
WCSCHK	3-41	6-14#				
WFDEL	83-39	84-8#				
WFMAP	83-38	85-10#				
WFNEW	83-37	84-16#				
WFPRNT	83-42	88-13#				
WFREAD	83-43	89-12#				
WFRSUM	83-41	87-22#				
WFSPND	83-40	87-10#				
WFSTT	83-44	90-8#				
WINCHR	1-17	3-14#				
WINDEL	84-23	84-113	86-29	86-44	92-16	93-8#
WINDSP	1-17	66-9#				
WININI	1-17	98-6#				
WINPRT	1-18	88-26	99-13#			
WINREL	1-17	86-19	92-8#			
WINSF	1-18	64-9#				
WINSFN	51-40	52-8#				
WINSRC	84-21	84-98	85-21	86-37	88-19	89-37 94-15#
WINST	1-18	65-9#				
WINSTT	84-61	90-15	91-9#			
WINTOP	1-47	2-49	98-12	99-64#		
WINVEC	83-33	83-37#	83-45			

BUFMAP	2-26#	4-44	53-15	54-26	55-18	59-22	60-39	61-21	62-23	68-45	89-71	
DISABL	2-6#	4-44	53-15	54-26	55-18	59-22	60-39	61-21	62-23	67-20	68-45	89-71
ENABL	2-10#	4-47	53-18	54-29	55-21	59-25	60-42	61-23	62-25	67-23	68-48	89-73
ESCSEQ	12-5#	12-15	12-16	12-17	12-18	12-19	12-20	12-21	12-22	12-23	12-24	12-25
	12-26	12-27	12-28	12-29	12-30	12-37	12-38	12-39	12-40	12-41	12-42	12-43
	12-44	12-45	12-46	12-47	12-48	12-49	12-50	12-51	12-52	12-53	12-54	12-55
	12-56	12-57	12-58	12-59	12-60	12-61	12-62	12-63	12-64	12-65	12-66	12-67
	12-68	12-69	12-70									
	DCALL	2-16#	52-23	81-40								
SEND	2-39#	68-90	68-91	69-19	69-24	69-25	69-26	69-31	69-33	69-38	69-39	69-43
	69-45	69-46	69-53	69-55	69-56	69-62	69-64	69-66	70-39	70-45	70-46	70-52
	70-53	70-59	70-60	70-66	70-67	70-71	71-35	71-36	71-40	71-41	71-48	72-20
	72-28	72-37	72-41	72-50	73-28	73-31	73-38	73-39	73-40	74-20	74-21	74-22
	74-31	75-35	75-37	76-22	76-23	77-45	77-48	77-59	77-72	78-16	78-19	78-21
	78-28	78-29	79-23	79-38	79-44	79-47	79-50	80-29	80-32	80-38	80-41	80-44
	81-5	81-23	81-24	82-27								
	UNMAP	2-32#	4-47	53-18	54-29	55-21	59-25	60-42	61-23	62-25	68-48	89-73